# ETSI TS 100 940 V7.21.0 (2003-12)

**Technical Specification** 

Digital cellular telecommunications system (Phase 2+); Mobile radio interface layer 3 specification (3GPP TS 04.08 version 7.21.0 Release 1998)



Reference RTS/TSGN-010408v7l0

> Keywords GSM

#### ETSI

#### 650 Route des Lucioles F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C Association à but non lucratif enregistrée à la Sous-Préfecture de Grasse (06) N° 7803/88

#### Important notice

Individual copies of the present document can be downloaded from: http://www.etsi.org

The present document may be made available in more than one electronic version or in print. In any case of existing or perceived difference in contents between such versions, the reference version is the Portable Document Format (PDF). In case of dispute, the reference shall be the printing on ETSI printers of the PDF version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status. Information on the current status of this and other ETSI documents is available at http://portal.etsi.org/tb/status/status.asp

> If you find errors in the present document, send your comment to: editor@etsi.org

#### **Copyright Notification**

No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

> © European Telecommunications Standards Institute 2003. All rights reserved.

**DECT**<sup>TM</sup>, **PLUGTESTS**<sup>TM</sup> and **UMTS**<sup>TM</sup> are Trade Marks of ETSI registered for the benefit of its Members. **TIPHON**<sup>TM</sup> and the **TIPHON logo** are Trade Marks currently being registered by ETSI for the benefit of its Members. **3GPP**<sup>TM</sup> is a Trade Mark of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

### Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (http://webapp.etsi.org/IPR/home.asp).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

### Foreword

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under <u>http://webapp.etsi.org/key/queryform.asp</u>.

### Contents

Intellectual Property Rights	
Foreword	2
Foreword	27
Introduction	27
0 Scope	
0.1 Scope of the Technical Specification	
0.2 Application to the interface structures	
0.3 Structure of layer 3 procedures	
0.4 Test procedures	
<ul><li>0.5 Use of logical channels</li><li>0.6 Overview of control procedures</li></ul>	
0.6.1     List of procedures	
0.7 Applicability of implementations	
0.7.1 Voice Group Call Service (VGCS) and Voice Broadcast Service (VBS)	
0.7.2 General Packet Radio Service (GPRS)	
1 References	22
1 References	
2 Definitions and abbreviations	
2.1 Random values	
2.2 Vocabulary	
3 Radio Resource management procedures	37
3.1 Overview/General	
3.1.1 General	
3.1.2 Services provided to upper layers	
3.1.2.1 Idle mode	
3.1.2.2 Dedicated mode	
3.1.2.3 Group receive mode	
3.1.2.4 Group transmit mode	
3.1.2.5 Packet idle mode	
<ul> <li>3.1.2.6 Packet transfer mode</li></ul>	
3.1.4     Change of dedicated channels	
3.1.4Change of dedicated channels using SAPI = 0	
3.1.4.2 Change of dedicated channels using other SAPIs than 0	
3.1.4.3 Sequenced message transfer operation	
3.1.4.3.1 Variables and sequence numbers	
3.1.4.3.1.2 Send sequence number N(SD)	40
3.1.4.3.2 Procedures for the initiation, transfer execution and termination of the sequenced message	
transfer operation	
3.1.4.3.2.2 Transfer Execution	
<ul><li>3.1.5 Procedure for Service Request and Contention Resolution</li></ul>	
3.2 Idle mode procedures and general procedures in packet idle and packet transfer modes	
3.2.1 Mobile Station side	
3.2.2 Network side	
3.2.2.1 System information broadcasting	
3.2.2.2 Paging	
3.3 RR connection establishment	44
3.3.1 RR connection establishment initiated by the mobile station	
3.3.1.1 Entering the dedicated mode : immediate assignment procedure	
3.3.1.1.1 Permission to access the network	
3.3.1.1.2 Initiation of the immediate assignment procedure	
3.3.1.1.3Answer from the network3.3.1.1.3.1On receipt of a CHANNEL REQUEST message	
5.5.1.1.5.1 OII receipt of a CHAININEL REQUEST message	

#### 3GPP TS 04.08 version 7.21.0 Release 1998

2 2 1 1 2 2		17
3.3.1.1.3.2		
3.3.1.1.4	Assignment completion	
3.3.1.1.4.1		
3.3.1.1.4.2		
3.3.1.1.5	Abnormal cases	
3.3.1.2	Entering the group transmit mode: uplink access procedure	
3.3.1.2.1	Mobile station side	
3.3.1.2.1.1	Uplink investigation procedure	49
3.3.1.2.1.2	Uplink access procedure	49
3.3.1.2.2	Network side	
3.3.1.2.3	Abnormal cases	
3.3.1.3	Dedicated mode and GPRS	
3.3.2	Paging procedure for RR connection establishment	
3.3.2.1	Paging initiation by the network	
3.3.2.1.1	Paging initiation using paging subchannel on CCCH	
3.3.2.1.2	Paging initiation using paging subchannel on PCCCH	
3.3.2.1.3	Paging initiation using PACCH.	
3.3.2.2	Paging response	
3.3.2.3	Abnormal cases	
3.3.3	Notification procedure	
3.3.3.1	Notification of a call	
3.3.3.2	Joining a VGCS or VBS call	
3.3.3.3	Reduced NCH monitoring mechanism.	
3.3.3.4		
	Notification response procedure	
3.4	Procedures in dedicated mode and in group transmit mode	
3.4.1	SACCH procedures	
3.4.1.1	General	
3.4.1.2	Measurement report	
3.4.1.3	Extended measurement report \$(MAFA)\$	
3.4.2	Transfer of messages and link layer service provision	
3.4.3	Channel assignment procedure	
3.4.3.1	Channel assignment initiation	
3.4.3.2	Assignment completion	
3.4.3.3	Abnormal cases	
3.4.4	Handover procedure	
3.4.4.1	Handover initiation	
3.4.4.2	Physical channel establishment	
3.4.4.2.1	Finely synchronized cell case	62
3.4.4.2.2	Non synchronized cell case	62
3.4.4.2.3	Pseudo-synchronized cell case	63
3.4.4.2.4	Pre-synchronized cell case	63
3.4.4.3	Handover completion	63
3.4.4.4	Abnormal cases	64
3.4.5	Frequency redefinition procedure	65
3.4.5.1	Abnormal cases	
3.4.6	Channel mode modify procedure	
3.4.6.1	Normal channel mode modify procedure	
3.4.6.1.1	Initiation of the channel mode modify procedure	
3.4.6.1.2	Completion of channel mode modify procedure	
3.4.6.1.3	Abnormal cases	
3.4.6.2	Channel mode modify procedure for a voice group call talker	
3.4.6.2.1	Initiation of the channel mode modify procedure	
3.4.6.2.2	Completion of mode change procedure	
3.4.6.2.3	Abnormal cases	
3.4.7	Ciphering mode setting procedure	
3.4.7.1	Ciphering mode setting initiation	
3.4.7.2	Ciphering mode setting completion	
3.4.7.2	Additional channel assignment procedure	
3.4.8 3.4.8.1	Additional assignment procedure initiation	
3.4.8.1		
3.4.8.2 3.4.8.3	Additional assignment procedure completion	
	Abnormal cases	
3.4.9	Partial channel release procedure	

2 4 0 1		<b>CO</b>
3.4.9.1	Partial release procedure initiation	
3.4.9.2	Abnormal cases	
3.4.10	Classmark change procedure	
3.4.11	Classmark interrogation procedure	
3.4.11.1	Classmark interrogation initiation	
3.4.11.2	Classmark interrogation completion	
3.4.12	Indication of notifications and paging information	70
3.4.13	RR connection release procedure	70
3.4.13.1	Normal release procedure	70
3.4.13.1.1	Channel release procedure initiation in dedicated mode and in group transmit mode	70
3.4.13.1.2	Abnormal cases	
3.4.13.2	Radio link failure in dedicated mode	
3.4.13.2.1	Mobile side	
3.4.13.2.2	Network side	
3.4.13.3	RR connection abortion in dedicated mode	
3.4.13.4	Uplink release procedure in group transmit mode	
3.4.13.5	Radio link failure in group transmit mode	
3.4.13.5.1	Mobile side	
3.4.13.5.2		
	Network side	
3.4.14	Receiving a RR STATUS message by a RR entity	
3.4.15	Group receive mode procedures	
3.4.15.1	Mobile station side	
3.4.15.1.1	Reception of the VGCS or VBS channel	
3.4.15.1.2	Monitoring of downlink messages and related procedures	
3.4.15.1.2.1	Spare	74
3.4.15.1.2.2	Spare	74
3.4.15.1.2.3	Channel mode modify procedure	74
3.4.15.1.2.4	Notification and paging information	74
3.4.15.1.2.4.1		
3.4.15.1.2.5	Uplink status messages	
3.4.15.1.2.6	Channel release message	
3.4.15.1.2.7	Information on paging channel restructuring	
3.4.15.1.3	Uplink reply procedure	
3.4.15.1.4	Leaving the group receive mode	
3.4.15.2	Network side	
3.4.15.2.1	Provision of messages on the VGCS or VBS channel downlink	
3.4.15.2.2	Release of the VGCS or VBS Channels	
3.4.15.2.2	Failure cases	
3.4.16	Configuration change procedure	
3.4.16.1	Configuration change initiation	
3.4.16.2	Configuration change completion	
3.4.16.3	Abnormal cases	
3.4.17	Mapping of user data substreams onto timeslots in a multislot configuration	
3.4.18	Handling of classmark information at band change	
3.4.19	Assignment to a Packet Data channel	
3.4.19.1	Assignment to PDCH initiation	
3.4.19.2	Completion of the Assignment to PDCH procedure	
3.4.19.3	Abnormal cases	80
3.4.20	RR-Network Commanded Cell Change Order	80
3.4.20.1	RR-network commanded cell change order initiation	81
3.4.20.2	Network controlled cell reselection completion	81
3.4.20.3	Abnormal cases	
3.4.21	Application Procedures	
3.4.21.1	General	
3.4.21.2	Application Information Transfer	
3.4.21.2.1	Normal Procedure without Segmentation	
3.4.21.2.2	Normal Procedure with Segmentation	
3.4.21.2.3	Abnormal Cases	
	procedures on CCCH related to temporary block flow establishment	
3.5.1 KK	Packet paging procedure using CCCH	
3.5.1.1	Packet paging initiation by the network	
3.5.1.2	On receipt of a packet paging request	
5.5.1.4		

3.5.2	Packet access procedure using CCCH	84
3.5.2.1	Entering the packet transfer mode: packet access procedure	
3.5.2.1.1	Permission to access the network	
3.5.2.1.2	Initiation of the packet access procedure: channel request	
3.5.2.1.3	Packet immediate assignment	
3.5.2.1.4	Packet access completion	
3.5.2.1.5	Abnormal cases	
3.5.2.2	Sending an RLC/MAC control message: single block packet access procedure	
3.5.3	Packet downlink assignment procedure using CCCH	
3.5.3.1	Entering the packet transfer mode: packet downlink assignment procedure	
3.5.3.1.2	Initiation of the packet downlink assignment procedure	
3.5.3.1.3	Packet downlink assignment completion	
3.5.3.2	Sending an RLC/MAC control message: single block packet downlink assignment procedure	
	nentary procedures for Mobility Management	
	General	
4.1.1	MM and GMM procedures	
4.1.1.1	Types of MM and GMM procedures	
4.1.1.2	MM-GMM co-ordination for GPRS MS's	
4.1.1.2.1	GPRS MS operating in mode A or B in a network that operates in mode I	
4.1.1.2.2	GPRS MS operating in mode A or B in a network that operates in mode II or III	
4.1.2	MM sublayer states	
4.1.2.1	MM sublayer states in the mobile station	
4.1.2.1.1	Main states	
4.1.2.1.2	Substates of the MM IDLE state	
4.1.2.2	The update Status	
4.1.2.3	MM sublayer states on the network side	
4.1.3	GPRS mobility management (GMM) sublayer states	
4.1.3.1	GMM states in the MS	
4.1.3.1.1	Main states	
4.1.3.1.1.1	GMM-NULL	
4.1.3.1.1.2	GMM-DEREGISTERED	
4.1.3.1.1.3	GMM-REGISTERED-INITIATED	
4.1.3.1.1.4	GMM-REGISTERED	
4.1.3.1.1.5	GMM-DEREGISTERED-INITIATED	
4.1.3.1.2.5	GMM-DEREGISTERED.NO-IMSI	
4.1.3.1.2.6	GMM-DEREGISTERED.NO-CELL-AVAILABLE	
4.1.3.1.2.7	GMM-DEREGISTERED.PLMN-SEARCH	
4.1.3.1.2.8	GMM-DEREGISTERED.SUSPENDED	
4.1.3.1.3	Substates of state GMM-REGISTERED	
4.1.3.1.3.1	GMM-REGISTERED.NORMAL-SERVICE	
4.1.3.1.3.2	GMM-REGISTERED.SUSPENDED	
4.1.3.1.3.3	GMM-REGISTERED.UPDATE-NEEDED	
4.1.3.1.3.4	GMM-REGISTERED.ATTEMPTING-TO-UPDATE	
4.1.3.1.3.5	GMM-REGISTERED.NO-CELL-AVAILABLE	
4.1.3.1.3.7	GMM-REGISTERED.ATTEMPTING-TO-UPDATE-MM	
4.1.3.1.3.8	GMM-REGISTERED.IMSI-DETACH-INITIATED	
4.1.3.2	GPRS update status	104
4.1.3.3	GMM mobility management states on the network side	105
4.1.3.3.1	Main States	
4.1.3.3.1.1	GMM-DEREGISTERED	
4.1.3.3.1.2	GMM-COMMON-PROCEDURE-INITIATED	
4.1.3.3.1.3	GMM-REGISTERED	
4.1.3.3.1.4	GMM-DEREGISTERED-INITIATED	
4.1.3.3.2	Substates of state GMM-REGISTERED	
4.1.3.3.2.1	GMM-REGISTERED.NORMAL-SERVICE	
4.1.3.3.2.2	GMM-REGISTERED.SUSPENDED	
	Sehaviour of the MS in MM Idle state, GMM-DEREGISTERED state and GMM-REGISTERED state	
4.2.1	Primary Service State selection	
4.2.1.1	Selection of the Service State after Power On	
4.2.1.2	Other Cases	107

4.2.2	Detailed Description of the MS behaviour in MM IDLE State	108
4.2.2.1	Service State, NORMAL SERVICE	108
4.2.2.2	Service State, ATTEMPTING TO UPDATE	108
4.2.2.3	Service State, LIMITED SERVICE	109
4.2.2.4	Service State, NO IMSI	109
4.2.2.5	Service State, SEARCH FOR PLMN, NORMAL SERVICE	110
4.2.2.6	Service State, SEARCH FOR PLMN	
4.2.2.7	Service State, RECEIVING GROUP CALL (NORMAL SERVICE)	
4.2.2.8	Service State, RECEIVING GROUP CALL (LIMITED SERVICE)	
4.2.3	Service state when back to state MM IDLE from another state	
4.2.4	Behaviour in state GMM-DEREGISTERED.	
4.2.4.1	Primary substate selection	
4.2.4.1.1	Selection of the substate after power on or enabling the MS's GPRS capability	
4.2.4.1.2	Other Cases	
4.2.4.2	Detailed description of the MS behaviour in state GMM-DEREGISTERED	
4.2.4.2.1	Substate, NORMAL-SERVICE	
4.2.4.2.2	Substate, ATTEMPTING-TO-ATTACH	
4.2.4.2.3	Substate, LIMITED-SERVICE	
4.2.4.2.4	Substate, NO-IMSI	
4.2.4.2.5	Substate, NO-CELL	
4.2.4.2.6	Substate, PLMN-SEARCH	
4.2.4.2.7	Substate, ATTACH-NEEDED	
4.2.4.2.7	Substate, SUSPENDED	
4.2.4.3	Substate, SUST ENDED	
4.2.5	Behaviour in state GMM-REGISTERED.	
4.2.5	Detailed description of the MS behaviour in state GMM-REGISTERED	
4.2.5.1	Substate, NORMAL-SERVICE	
4.2.5.1.1	Substate, SUSPENDED	
4.2.5.1.2		
	Substate, UPDATE-NEEDED	
4.2.5.1.4	Substate, ATTEMPTING-TO-UPDATE	
4.2.5.1.5	Substate, NO-CELL-AVAILABLE	
4.2.5.1.6	Substate, LIMITED-SERVICE	
4.2.5.1.7	Substate, ATTEMPTING-TO-UPDATE-MM	
4.3	MM common procedures	
4.3.1	TMSI reallocation procedure	
4.3.1.1	TMSI reallocation initiation by the network	
	TMSI reallocation completion by the mobile station	
4.3.1.3	TMSI reallocation completion in the network	
4.3.1.4	Abnormal cases	
4.3.2	Authentication procedure	
4.3.2.1	Authentication request by the network	
4.3.2.2	Authentication response by the mobile station	
4.3.2.3	Authentication processing in the network	
4.3.2.4	Ciphering key sequence number	
4.3.2.5	Unsuccessful authentication	
4.3.2.6	Abnormal cases	
4.3.3	Identification procedure	
4.3.3.1	Identity request by the network	
4.3.3.2	Identification response by the mobile station	
4.3.3.3	Abnormal cases	
4.3.4	IMSI detach procedure	
4.3.4.1	IMSI detach initiation by the mobile station	
4.3.4.2	IMSI detach procedure in the network	
4.3.4.3	IMSI detach completion by the mobile station	
4.3.4.4	Abnormal cases	
4.3.5	Abort procedure	
4.3.5.1	Abort procedure initiation by the network	
4.3.5.2	Abort procedure in the mobile station	
4.3.6	MM information procedure	
4.3.6.1	MM information procedure initiation by the network	
4.3.6.2	MM information procedure in the mobile station	
4.4	MM specific procedures	122

4.4.1	Location updating procedure	
4.4.2	Periodic updating	
4.4.3	IMSI attach procedure	
4.4.4	Generic Location Updating procedure	
4.4.4.1	Location updating initiation by the mobile station	
4.4.4.1a	Network Request for Additional mobile station Capability Information	
4.4.4.2	Identification request from the network	
4.4.4.3	Authentication by the network	
4.4.4.4	Ciphering mode setting by the network	
4.4.4.5	Attempt Counter	
4.4.4.6	Location updating accepted by the network	
4.4.4.7	Location updating not accepted by the network	
4.4.4.8	Release of RR connection after location updating	
4.4.4.9	Abnormal cases on the mobile station side	
4.4.4.10	Abnormal cases on the network side	
4.5	Connection management sublayer service provision	
4.5.1	MM connection establishment	
4.5.1.1	MM connection establishment initiated by the mobile station	
4.5.1.2	Abnormal cases	
4.5.1.3	MM connection establishment initiated by the network	
4.5.1.3.1	Mobile Terminating CM Activity	
4.5.1.3.2	Mobile Originating CM Activity \$(CCBS)\$	
4.5.1.4	Abnormal cases	
4.5.1.5	MM connection establishment for emergency calls	
4.5.1.6	Call re-establishment	
4.5.1.6.1	Call re-establishment, initiation by the mobile station	
4.5.1.6.2	Abnormal cases	
4.5.1.7	Forced release during MO MM connection establishment	
4.5.2	MM connection information transfer phase	
4.5.2.1	Sending CM messages	
4.5.2.2	Receiving CM messages	
4.5.2.3	Abnormal cases	
4.5.2.5	MM connection release	
4.5.3.1	Release of associated RR connection	
4.5.3.2	Uplink release in a voice group call	
4.6 4.7	Receiving a MM STATUS message by a MM entity Elementary mobility management procedures for GPRS services	
4.7.1	General	
	Lower laver failure	
4.7.1.1 4.7.1.2		
	Ciphering of messages	
4.7.1.3	P-TMSI signature	
4.7.1.4	Radio resource sublayer address handling	
4.7.1.5	P-TMSI handling	
4.7.1.6	Change of network mode of operation	
4.7.1.7	(void)	
4.7.1.8	List of forbidden PLMNs for GPRS service	
4.7.2	GPRS Mobility management timers	
4.7.2.1	READY timer behaviour	
4.7.2.2	Periodic routing area updating	
4.7.3	GPRS attach procedure	
4.7.3.1	GPRS attach procedure for GPRS services	
4.7.3.1.1	GPRS attach procedure initiation	
4.7.3.1.2	GMM common procedure initiation	
4.7.3.1.3	GPRS attach accepted by the network	
4.7.3.1.4	GPRS attach not accepted by the network	
4.7.3.1.5	Abnormal cases in the MS	
4.7.3.1.6	Abnormal cases on the network side	
4.7.3.2	Combined GPRS attach procedure for GPRS and non-GPRS services	
4.7.3.2.1	Combined GPRS attach procedure initiation	
4.7.3.2.2	GMM Common procedure initiation	
4.7.3.2.3	Combined GPRS attach accepted by the network	
4.7.3.2.3.1	Combined attach successful for GPRS and non-GPRS services	

4.7.3.2.3.2	Combined attach successful for GPRS services only	150
4.7.3.2.4	Combined GPRS attach not accepted by the network	
4.7.3.2.5	Abnormal cases in the MS	
4.7.3.2.6	Abnormal cases on the network side	
4.7.4	GPRS detach procedure	
4.7.4.1	MS initiated GPRS detach procedure	
4.7.4.1.1	MS initiated GPRS detach procedure initiation	
4.7.4.1.2	MS initiated GPRS detach procedure completion for GPRS services only	
4.7.4.1.3	MS initiated combined GPRS detach procedure completion	
4.7.4.1.4	Abnormal cases in the MS	
4.7.4.2	Network initiated GPRS detach procedure	
4.7.4.2.1	Network initiated GPRS detach procedure initiation	
4.7.4.2.2	Network initiated GPRS detach procedure completion by the MS	
4.7.4.2.3	Network initiated GPRS detach procedure completion by the network	
4.7.4.2.4	Abnormal cases on the network side	
4.7.5	Routing area updating procedure	
4.7.5.1	Normal and periodic routing area updating procedure	
4.7.5.1.1	Normal and periodic routing area updating procedure initiation	
4.7.5.1.2	GMM Common procedure initiation	
4.7.5.1.3	Normal and periodic routing area updating procedure accepted by the network	159
4.7.5.1.4	Normal and periodic routing area updating procedure not accepted by the network	
4.7.5.1.4	Abnormal cases in the MS	
4.7.5.1.6	Abnormal cases on the network side	
4.7.5.2	Combined routing area updating procedure	
4.7.5.2.1	Combined routing area updating procedure initiation	
4.7.5.2.2	GMM Common procedure initiation	
4.7.5.2.3	Combined routing area updating procedure accepted by the network	
4.7.5.2.3.1	Combined routing area updating successful for CDPS services cells	
4.7.5.2.3.2	Combined routing are updating successful for GPRS services only	
4.7.5.2.4	Combined routing area updating not accepted by the network	
4.7.5.2.5	Abnormal cases in the MS	
4.7.5.2.6	Abnormal cases on the network side	
4.7.6	P-TMSI reallocation procedure.	
4.7.6.1	P-TMSI reallocation initiation by the network	
4.7.6.2	P-TMSI reallocation completion by the MS	
4.7.6.3	P-TMSI reallocation completion by the network	
4.7.6.4	Abnormal cases on the network side	
4.7.7	Authentication and ciphering procedure	
4.7.7.1	Authentication and ciphering initiation by the network	
4.7.7.2	Authentication and ciphering response by the MS	
4.7.7.3	Authentication and ciphering completion by the network	
4.7.7.4	GPRS ciphering key sequence number	
4.7.7.5	Unsuccessful authentication and ciphering	
4.7.7.6	Abnormal cases on the network side	
4.7.8	Identification procedure	
4.7.8.1	Identification initiation by the network	
4.7.8.2	Identification response by the MS	
4.7.8.3	Identification completion by the network	
4.7.8.4	Abnormal cases on the network side	
4.7.9	Paging procedure	
4.7.9.1	Paging for GPRS services	
4.7.9.1.1	Paging for GPRS services using P-TMSI	
4.7.9.1.2	Paging for GPRS services using IMSI	
4.7.9.2	Paging for non-GPRS services	
4.7.10	Receiving a GMM STATUS message by a GMM entity	
4.7.11	GMM support for anonymous access	
4.7.11.1	MS side	
4.7.11.2	Network side	
4.7.12	GMM Information procedure	
4.7.12.1	GMM information procedure initiation by the network	
4.7.12.2	GMM information procedure in the mobile station	176

5	Elementary procedures for circuit-switched Call Control	176
5.1	Overview	
5.1.1	General	176
5.1.2	Call Control States	180
5.1.2.1		
5.1.2.1	.1 Null (State U0)	180
5.1.2.1	.2 MM Connection pending (U0.1)	180
5.1.2.1	.2a CC prompt present (U0.2) \$(CCBS)\$	181
5.1.2.1	.2b Wait for network information (U0.3) \$(CCBS)\$	181
5.1.2.1	.2c CC-Establishment present (U0.4) \$(CCBS)\$	181
5.1.2.1	.2d CC-Establishment confirmed (U0.5) \$(CCBS)\$	181
5.1.2.1	.2e Recall present (U0.6) \$(CCBS)\$	181
5.1.2.1		
5.1.2.1	.4 Mobile originating call proceeding (U3)	181
5.1.2.1	.5 Call delivered (U4)	181
5.1.2.1	.6 Call present (U6)	181
5.1.2.1	.7 Call received (U7)	181
5.1.2.1		
5.1.2.1		
5.1.2.1		
5.1.2.1		
5.1.2.1		
5.1.2.1		
5.1.2.1		
5.1.2.1	.15 Mobile terminating modify (U27)	182
5.1.2.2	Network call states	182
5.1.2.2	.1 Null (State N0)	182
5.1.2.2	.2 MM connection pending (N0.1)	182
5.1.2.2	$\Gamma = \mathcal{B}(\mathcal{A}, \mathcal{A})$	
5.1.2.2	$\Gamma = \partial \langle \rangle \langle \rangle \rangle$	
5.1.2.2		
5.1.2.2		
5.1.2.2	.3 Call initiated (N1)	183
5.1.2.2		
5.1.2.2	.5 Call delivered (N4)	183
5.1.2.2		
5.1.2.2		
5.1.2.2		
5.1.2.2	8	
5.1.2.2		
5.1.2.2		
5.1.2.2		
5.1.2.2		
5.1.2.2		
5.1.2.2		
5.1.2.2		
5.2	Call establishment procedures	
5.2.1	Mobile originating call establishment	
5.2.1.1	Call initiation	
5.2.1.2		
5.2.1.3		
5.2.1.4		
5.2.1.4	6 6	
5.2.1.4	1 0	
5.2.1.5		
5.2.1.6		
5.2.1.7	5	
5.2.1.8		
5.2.1.9	6 6 6	
5.2.1.1		
5.2.2	Mobile terminating call establishment	
5.2.2.1	Call indication	189

5 2 2 2		100
5.2.2.2 5.2.2.3	Compatibility checking Call confirmation	
5.2.2.3.1	Response to SETUP	
5.2.2.3.1	Receipt of CALL CONFIRMED and ALERTING by the network	
5.2.2.3.3	Call failure procedures	
5.2.2.3.4	Called mobile station clearing during mobile terminating call establishment	
5.2.2.4	Notification of interworking in connection with mobile terminating call establishment	
5.2.2.5	Call accept	
5.2.2.6	Active indication	192
5.2.2.7	Traffic channel assignment at mobile terminating call establishment	192
5.2.2.8	Call queuing at mobile terminating call establishment	
5.2.2.9	User connection attachment during a mobile terminating call	
5.2.3	Network initiated MO call \$(CCBS)\$	
5.2.3.1	Initiation	
5.2.3.2	CC-Establishment present	
5.2.3.2.1	Recall Alignment Procedure	
5.2.3.3 5.2.3.4	CC-Establishment confirmation	
5.2.3.4	Recall present Traffic channel assignment during network initiated mobile originating call establishment	
	Signalling procedures during the "active" state	
5.3.1	User notification procedure.	
5.3.2	Call rearrangements	
5.3.3	Not used	
5.3.4	Support of Dual Services	
5.3.4.1	Service Description	
5.3.4.2	Call establishment	
5.3.4.2.1	Mobile Originating Establishment	
5.3.4.2.2	Mobile Terminating Establishment	
5.3.4.3	Changing the Call Mode	
5.3.4.3.1	Initiation of in-call modification	
5.3.4.3.2	Successful completion of in-call modification	
5.3.4.3.3	Change of the channel configuration	
5.3.4.3.4	Failure of in-call modification	
5.3.4.3.4.1		
5.3.4.3.4.2 5.3.4.3.4.3		
5.3.4.5.4.5 5.3.4.4	Time-out recovery Abnormal procedures	
5.3.5	User initiated service level up- and downgrading	
5.3.5.1	Initiation of service level up- and downgrading	
5.3.5.2	Successful completion of service level up- and downgrading	
5.3.5.3	Rejection of service level up- and downgrading	
5.3.5.4	Time-out recovery	
5.4	Call clearing	
5.4.1	Terminology	201
5.4.2	Exception conditions	202
5.4.3	Clearing initiated by the mobile station	
5.4.3.1	Initiation of call clearing	
5.4.3.2	Receipt of a DISCONNECT message from the mobile station	
5.4.3.3	Receipt of a RELEASE message from the network	
5.4.3.4	Receipt of a RELEASE COMPLETE message from the mobile station	
5.4.3.5	Abnormal cases	
5.4.4 5.4.4.1	Clearing initiated by the network.	
5.4.4.1	Clearing initiated by the network: mobile does not support "Prolonged Clearing Procedure"	
5.4.4.1.1	Clearing when tones/announcements provided Clearing when tones/announcements not provided	
5.4.4.1.2	Completion of clearing	
5.4.4.2	Clearing initiated by the network: mobile supports "Prolonged Clearing Procedure"	
5.4.4.2.1	Clearing when tones/announcements provided and the network does not indicate that "CCBS	
	activation is possible"	205
5.4.4.2.2	Clearing when the network indicates that "CCBS activation is possible"	
5.4.4.2.3	Clearing when tones/announcements are not provided and the network does not indicate that	-
	"CCBS activation is possible"	206

5.4.4.2.4	Receipt of a RELEASE message from the mobile station	
5.4.4.2.5	Completion of clearing	
5.4.5	Clear collision	
5.5	Miscellaneous procedures	
5.5.1	In-band tones and announcements	
5.5.2	Call collisions	
5.5.3	Status procedures	
5.5.3.1	Status enquiry procedure	
5.5.3.2	Reception of a STATUS message by a CC entity	
5.5.3.2.1	STATUS message with incompatible state	
5.5.3.2.2	STATUS message with compatible state	
5.5.4	Call re-establishment, mobile station side	
5.5.4.1	Indication from the mobility management sublayer	
5.5.4.2	Reaction of call control	
5.5.4.3	Completion of re-establishment	
5.5.4.4	Unsuccessful outcome	
5.5.5	Call re-establishment, network side	
5.5.5.1	State alignment.	
5.5.6	Progress	
5.5.7	DTMF protocol control procedure	
5.5.7.1	Start DTMF request by the mobile station	
5.5.7.2	Start DTMF response by the network	
5.5.7.3	Stop DTMF request by the mobile station	
5.5.7.4	Stop DTMF response by the network	
5.5.7.5	Sequencing of subsequent start DTMF requests by the mobile station	211
6 Su	pport for packet services	212
6.1	GPRS Session management	
6.1.1	General	
6.1.1.1	Radio resource sublayer address handling for anonymous access	
6.1.2	Session management states	
6.1.2.1	Session management states in the MS	
6.1.2.1.1	PDP-INACTIVE	
6.1.2.1.2	PDP-ACTIVE-PENDING	
6.1.2.1.2	PDP-ACTIVE-PENDING	
6.1.2.1.4	PDP-ACTIVE-FENDING	
6.1.2.2	Session management states on the network side	
6.1.2.2.1 6.1.2.2.2	PDP-INACTIVE	
****	PDP-ACTIVE-PENDING	
6.1.2.2.3	PDP-INACTIVE-PENDING	
6.1.2.2.4	PDP-ACTIVE	
6.1.2.2.5	PDP-MODIFY-PENDING	
6.1.3	Session Management procedures	
6.1.3.1	PDP context activation	
6.1.3.1.1	Successful PDP context activation initiated by the mobile station	
6.1.3.1.2	Successful PDP context activation requested by the network	
6.1.3.1.3	Unsuccessful PDP context activation initiated by the MS	
6.1.3.1.4	Unsuccessful PDP context activation requested by the network	
6.1.3.1.5	Abnormal cases	
6.1.3.2	PDP context modification procedure	
6.1.3.2.1	Abnormal cases	
6.1.3.3	PDP context deactivation procedure	
6.1.3.3.1	PDP context deactivation initiated by the MS	
6.1.3.3.2	PDP context deactivation initiated by the network	
6.1.3.3.3	Abnormal cases	
6.1.3.4	AA PDP context activation	
6.1.3.4.1	Successful AA PDP context activation initiated by the mobile station	
6.1.3.4.2	Unsuccessful AA PDP context activation	
6.1.3.4.3	Abnormal cases	
6.1.3.5	AA PDP context deactivation	
6.1.3.5.1	Implicit AA PDP context deactivation	
6.1.3.5.2	Explicit AA PDP context deactivation	
	1	

6.1.3.5 6.1.3.6		
7	Examples of structured procedures	
7.1	General	
7.1.1	Paging request	
7.1.2	Immediate assignment	
7.1.3	Service request and contention resolution	223
7.1.4	Authentication	
7.1.5	Ciphering mode setting	
7.1.6	Transaction phase	
7.1.6.1		
7.1.7	Channel release	
7.2 7.3	Abnormal cases	
7.3.1	Selected examples	
7.3.2	Location updating Mobile originating call establishment	
7.3.3	Mobile terminating call establishment	
7.3.4	Call clearing	
7.3.5	DTMF protocol control	
7.3.6	Handover	
7.3.7	In-call modification	
7.3.8	Call re-establishment	
7.3.9	Network initiated mobile originating call \$(CCBS)\$	238
0	Handling of unknown unforescen and amongous motional data	242
8	Handling of unknown, unforeseen, and erroneous protocol data	
8.1 8.2		
8.2 8.3	Message too short Unknown or unforeseen transaction identifier	
8.3.1	Call Control	
8.3.2	Session Management	
8.4	Unknown or unforeseen message type	
8.5	Non-semantical mandatory information element errors	
8.5.1	Radio resource management	
8.5.2	Mobility management	
8.5.3	Call control	
8.5.4	GMM mobility management	247
8.5.5	Session management	
8.6	Unknown and unforeseen IEs in the non-imperative message part	
8.6.1	IEIs unknown in the message	
8.6.2	Out of sequence IEs	
8.6.3	Repeated IEs	
8.7	Non-imperative message part errors.	
8.7.1 8.7.2	Syntactically incorrect optional IEs Conditional IE errors	
8.8	Messages with semantically incorrect contents	
0.0		
9	Message functional definitions and contents	
9.1	Messages for Radio Resources management	
9.1.1	Additional assignment	
9.1.1.1		
9.1.1.2	6	
9.1.2	Assignment command.	
9.1.2.1		
9.1.2.2 9.1.2.3	1	
9.1.2.3		
9.1.2.4		
9.1.2.6	-	
9.1.2.7		
9.1.2.8	1	
9.1.2.9	1 6	
9.1.2.1		

9.1.3       Assignment complete.       255         9.1.5       Channel Inode modify.       256         9.1.5.1       Channel Inode modify.       256         9.1.5.2       VGCS target mode Indication.       256         9.1.5.3       Muhi Rate configuration.       257         9.1.6       Channel release.       257         9.1.7       Channel description and mobile allocation.       257         9.1.7.1       Channel description and mobile allocation.       258         9.1.8       Channel request.       258         9.1.9       Ciphering mode command.       260         9.1.10.1       Mohib Faljoringment Identity.       261         9.1.11.1       Additional Mobib Station Classmark Information.       261         9.1.12       Mohib Faljoringment Identity.       261         9.1.12       Mobib Station Classmark Information.       261         9.1.12       Mohib Station Classmark Information.       262         9.1.12       Mohib Station Classmark Information.       262         9.1.12       Configuration change reject.       263         9.1.12       Configuration change reject.       263         9.1.12       Configuration change reject.       263         9.1.12       <	9.1.2.11	Multi Rate configuration	255
9.1.5.         Chamel mode modify         256           9.1.5.1         Chamel Description         256           9.1.5.2         VGCS target mode Indication         257           9.1.6         Chamel mode modify acknowledge         257           9.1.6         Chamel mode Scription and mobile allocation         258           9.1.7.1         Chamel release         258           9.1.7.2         Group Cipher Key Number         258           9.1.8         Chamel request         258           9.1.9         Ciphering mode compand         260           9.1.10         Ciphering mode complet         260           9.1.10         Mobile Equipment Identity         261           9.1.11         Additional Mobile Station Classmark Information         261           9.1.11         Additional Mobile Station Classmark Information         261           9.1.12         Classmark Anage         261           9.1.12         Configuration Change achowledge         263           9.1.13         Frequency redefinition	9.1.3	•	
9.15.1       Channel Description       256         9.15.2       VGCS target mode Indication       257         9.16       Channel mode modify acknowledge       257         9.17       Channel description and nobile allocation       258         9.17.1       Channel description and nobile allocation       258         9.17.2       Group Cipber Key Number       258         9.18       Channel request       258         9.19       Ciphering mode command       260         9.10.1       Mobile Equipment Identity       261         9.110.1       Mobile Station Classmark       261         9.111.1       Additional Mobile Station Classmark Information       261         9.112.1       Mobile Station Classmark       261         9.112       Mobile Station Classmark       262         9.112       Mobile Station Classmark       262         9.112       Configuration change command       262         9.112       Mode of Channel Set X** (1-K-X       263         9.112       Configuration change reject       263         9.112       Configuration change reject       263         9.113       Frequency redefinition       264         9.113.4       Cell Channel Set X**(1-K-X-	9.1.4		
9.1.5.2       VGCS target mode Indication       257         9.1.5.3       Multi Rate configuration       257         9.1.6       Channel mode modify acknowledge       257         9.1.7       Channel description and mobile allocation       258         9.1.7.1       Channel request       258         9.1.7.2       Group Cipher Key Number       258         9.1.8       Channel request       260         9.1.10       Ciphering mode command       260         9.1.10       Mobile Equipment Identity       261         9.1.11       Additional Mobile Station Classmark. Information       261         9.1.11.1       Additional Mobile Station Classmark. Information       261         9.1.12       Classmark change       262         9.1.12       Classmark change command       262         9.1.12       Mobile Of Channel See: X" (1=-X<8)	9.1.5	Channel mode modify	256
9.1.5.3Multi Rate configuration2579.1.6Channel node molify acknowledge2579.1.7Channel description and mobile allocation2589.1.7.1Group Cipher Key Number2589.1.8Channel request2589.1.9Ciphering mode complete2609.1.10Mobile Fagiument Identity2619.1.10.1Mobile Station Classmark2619.1.11.1Additional Mobile Station Classmark2619.1.12Mobile Station Classmark2619.1.12Mobile Station Classmark2619.1.12Spare2619.1.12Spare2629.1.12Spare2629.1.12Description of the multislot allocation2629.1.12Onfiguration change command2629.1.12Configuration change command2639.1.12Configuration change command2639.1.12Configuration change command2649.1.13Cell Channel Description2649.1.13Cell Channel Description2649.1.13Cell Channel Description2649.1.13Cell Channel Description2649.1.13Cell Channel Description2649.1.13Cell Channel Description2669.1.13Cell Channel Description2669.1.13Gell Sagment command2669.1.13Gell Scannel Description2669.1.14Handover access2779.1.15Handover complet2	9.1.5.1	Channel Description	256
9.1.6Channel mode modify acknowledge2579.1.7.1Channel description and mobile allocation2589.1.7.2Group Cipber Key Number2589.1.8Channel request2589.1.9Cipbering mode complete2609.1.10Mobile Equipment Identity2619.1.11Classmark change2619.1.11Additional Mobile Station Classmark Information2619.1.11Additional Mobile Station Classmark Information2619.1.12Classmark change2629.1.12Classmark change2629.1.12Description of the multisot allocation2629.1.12Description of the multisot allocation2629.1.12bConfiguration change economand2629.1.12bDescription of the multisot allocation2629.1.12bConfiguration change acknowledge2639.1.12aConfiguration change acknowledge2639.1.12bConfiguration change acknowledge2639.1.12aConfiguration change acknowledge2639.1.13aFrequency redefinition2649.1.13aFrequency redefinition2649.1.13aFrequency redefinition2649.1.13aReference cell frequency list, after the starting time2659.1.13aReference cell frequency list, after the starting time2669.1.13bGPRS suspension request2669.1.13cSuspension request2669.1.13bHandover access267 <td< td=""><td>9.1.5.2</td><td>VGCS target mode Indication</td><td>256</td></td<>	9.1.5.2	VGCS target mode Indication	256
9.1.7Channel release2579.1.7.1Channel release2589.1.7.2Group Cipher Key Number2589.1.8Channel request2589.1.9Ciphering mode command2609.1.10Mobile Equipment Identity2619.1.10.1Mobile Equipment Identity2619.1.11.1Additional Mobile Station Classmark Information2619.1.12Mobile Station Classmark Information2619.1.12Mobile Station Classmark Information2619.1.12Classmark change2619.1.12Configuration change command2629.1.12bDescription of the multislot allocation2629.1.12bOrnfiguration change command2629.1.12bMode of Channel Set "X" ( $1=)2639.1.12bConfiguration change acknowledge2639.1.12bConfiguration change reject2639.1.12bConfiguration change reject2639.1.13aCell Channel Description2649.1.13aCell Channel Description2649.1.13aStatting Time2659.1.13a.3Reference cell frequency list, after the starting time2669.1.13aSubject and Description2669.1.13bGPRS suspension request2669.1.13cPacket Assignment2669.1.13cPacket Assignment2669.1.13cSubject and Description2669.1.13bHandover access2679.1.13cMode of t$	9.1.5.3	Multi Rate configuration	257
9.17.1Channel description and mobile allocation2589.1.72Group Cipber Key Number2589.1.8Channel request2589.1.9Cipbering mode compate2609.1.10Mobile Equipment Identity2619.1.11Mobile Equipment Identity2619.1.11Additional Mobile Station Classmark Information2619.1.11.1Mobile Station Classmark Anarge2619.1.12Classmark change2629.1.12Classmark change2629.1.12Configuration change command2629.1.12bDescription of the multislot allocation2629.1.12bMode of Channel Set "X" (1=<<< 2.1.2b.12639.1.12bConfiguration change extension2639.1.12bConfiguration change reject2639.1.12cConfiguration change reject2639.1.13Frequency redefinition2649.1.13Cell Guantel Description2649.1.13aPDCH Assignment command2649.1.13aStating Time2659.1.13a.2Stating Time2669.1.13aReference cell frequency list, after the stating time2669.1.13aReference cell frequency list, after the stating time2669.1.13aStating Time2669.1.13aReference cell frequency list, after the stating time2669.1.13aPacket Assignment2669.1.13bSynchronization Indication2679.1.13bSynchronization Indi	9.1.6		
9.1.7.2       Group Cipher Key Number.	9.1.7		
9.1.8Channel request			
9.1.9Ciphering mode command.2609.1.10.1Mobile Equipment Identity2619.1.10.1Mobile Equipment Identity2619.1.11.1Additional Mobile Station Classmark Information2619.1.11.1Mobile Station Classmark2619.1.12Mobile Station Classmark2619.1.12Classmark enquiry2619.1.12Configuration change command.2629.1.12bConfiguration change economand.2629.1.12b.1Description of the multislot allocation2639.1.12b.2Mode of Channel Set 'X' (1= <x<=\$)< td="">2639.1.12bConfiguration change acknowledge.2639.1.13aCell Channel Description2639.1.13aCell Channel Description2649.1.13aCell Channel Prepription2649.1.13aCell Channel Prepription2669.1.13aReference cell frequency List, after the starting time.2669.1.13a.2Starting Time.2669.1.13a.3Reference cell frequency List, after the starting time.2669.1.13a.4Cell Channel Description2669.1.13bGPRS suppension request2669.1.13bGPRS suppension request2669.1.15.1Synchronization Indication2679.1.15.2Mode of the First Channel (Channel Set 'X' (2=<x<=\$)< td=""><td>× · · · · · · =</td><td></td><td></td></x<=\$)<></x<=\$)<>	× · · · · · · =		
9.1.10.1Ciphering mode complete			
9.1.10.1       Mobile Equipment Identity       261         9.1.11       Additional Mobile Station Classmark Information       261         9.1.11.2       Mobile Station Classmark       261         9.1.12       Mobile Station Classmark       261         9.1.12       Mobile Station Classmark       261         9.1.12       Spare       262         9.1.12b       Configuration change command       262         9.1.12b.1       Description of the multislot allocation       263         9.1.12b       Mode of Channel Set "X" (1= <x=×3)< td="">       263         9.1.12c       Configuration change archowledge       263         9.1.13       Frequency redefinition       263         9.1.13       Frequency redefinition       264         9.1.13a       Mobile Allocation and Frequency List, after the starting time       266         9.1.13a       Mobile Allocation and Frequency List, after the starting time       266         9.1.13a       Refrence cell frequency List, after the starting time       266         9.1.13a       Refrence cell requency List, after the starting time       266         9.1.13a       Refrence cell frequency List, after the starting time       266         9.1.13a       Reference cell frequency List, after the starting time       267</x=×3)<>			
9.1.11Classmark change2619.1.11.1Additional Mobile Station Classmark2619.1.11.2Mobile Station Classmark2619.1.12Classmark enquiry2619.1.12Classmark enquiry2629.1.12Description of the multislot allocation2629.1.12bConfiguration change command2629.1.12bMode of Channel Set 'X' ( $1 < X < = 8$ )2639.1.12bConfiguration change acknowledge2639.1.12cConfiguration change acknowledge2639.1.13Frequency redefinition2639.1.13Cell Channel Description2649.1.13aPDCH Assignment command2649.1.13aMobile Allocation and Frequency List, after the starting time2669.1.13a.1Kelference cell frequency list2669.1.13a.3Reference cell requency list2669.1.13aCell Channel Description2669.1.13aReference cell requency list2669.1.13bPacket Assignment2669.1.13bMadover command2679.1.15Handover access2679.1.15Mode of the First Channel (Channel Set 1) and Mode of Channel Set 'X' ( $2 < X < = 8$ )2.099.1.15.2Mode of the Second Channel.2699.1.15.4Mode of the Second Channel.2699.1.15.5Frequency Channel Sequence, Frequency List, Frequency short list and Mobile Allocation, aftertime27011.15.1Wold coft the Second Channel.271 <td></td> <td></td> <td></td>			
9.1.11.1       Additional Mobile Station Classmark.			
9.1.11.2       Mobile Station Classmark       261         9.1.12       Classmark enquiry       261         9.1.12       Classmark enquiry       262         9.1.12b       Configuration of the multislot allocation       262         9.1.12b.1       Description of the multislot allocation       262         9.1.12b       Configuration change acknowledge       263         9.1.12c       Configuration change reject.       263         9.1.13       Frequency redefinition       263         9.1.13       Frequency redefinition       264         9.1.13a       PDCH Assignment command       264         9.1.13a.1       Mobile Allocation and Frequency List, after the starting time       265         9.1.13a.3       Reference cell frequency list, after the starting time       266         9.1.13a.4       Cell Channel Description       266         9.1.13a.5       Packet Assignment       266         9.1.13a.6       Packet Assignment       266         9.1.13a       Reference cell frequency list, after the starting time       267         9.1.13a.5       Packet Assignment       266         9.1.13a       Reference cell frequency list, after the starting time       267         9.1.15.1       Synchronization Indication			
9.1.12       Classmark enquiry			
9.1.12a         Spare         262           9.1.12b         Configuration change command.         262           9.1.12b.1         Description of the multislot allocation         262           9.1.12b.2         Mode of Channel Set "X" (1=-X<=8)			
9.1.12b         Configuration change command         262           9.1.12b.1         Description of the multislot allocation         263           9.1.12c         Configuration change acknowledge.         263           9.1.12d         Configuration change reject         263           9.1.12d         Configuration change reject         263           9.1.13a         Cell Channel Set X** (1=<			
9.1.12b.1Description of the multislot allocation2629.1.12b.2Mode of Channel Set "X" ( $1=)2639.1.12cConfiguration change acknowledge2639.1.13dConfiguration change reject2639.1.13Frequency redefinition2649.1.13aPDCH Assignment command2649.1.13aMobile Allocation and Prequency List, after the starting time2659.1.13a.1Mobile Allocation and Prequency List, after the starting time2669.1.13a.2Starting Time2669.1.13a.3Reference cell frequency list2669.1.13a.4Cell Channel Description2669.1.13a.5Packet Assignment2669.1.13b.5Packet Assignment2669.1.14Handover command2679.1.15Handover command2679.1.15.1Handover command2679.1.15.2Mode of the First Channel Set 1) and Mode of Channel Set "X" (2=)2699.1.15.4Mode of the Second Channel2699.1.15.5Frequency Channel Sequence, Frequency List, Frequency short list and Mobile Allocation, aftertime2709.1.15.4Mode of the Second Channel2719.1.15.5Trequency complete2719.1.15.1VGCS target mode indication2719.1.15.2Description of the solid allocation2719.1.15.3Description of the multislot allocation2719.1.15.4Hode of the Second Channel2709.1.15.5Frequency channel Se$			
9.1.12b.2       Mode of Channel Set "X" ( 1= <x<=8)< td=""><td></td><td></td><td></td></x<=8)<>			
9.1.12c       Configuration change reject       263         9.1.13       Frequency redefinition       263         9.1.13       Frequency redefinition       264         9.1.13a       PDCH Assignment command.       264         9.1.13a       PDCH Assignment command.       264         9.1.13a       Reference cell frequency List, after the starting time.       265         9.1.13a.2       Starting Time.       266         9.1.13a.4       Cell Channel Description       266         9.1.13a.5       Packet Assignment       266         9.1.13b       GPRS suspension request       266         9.1.15       Handover access       267         9.1.15.4       Mode of the First Channel (Channel Set 1) and Mode of Channel Set "X" (2= <x<=8).< td="">       269         9.1.15.5       Frequency Channel Sequence, Frequency List, Frequency short list and Mobile Allocation, after       269         9.1.15.5       Frequency Channel Sequence, Frequency List, Frequency Short list and Mobile Allocation, after       270         9.1.15.6       Starting T</x<=8).<>			
9.1.12d       Configuration change reject.       .263         9.1.131       Frequency redefinition       .263         9.1.131       Cell Channel Description       .264         9.1.13a       PDCH Assignment command       .264         9.1.13a.1       Mobile Allocation and Frequency List, after the starting time.       .265         9.1.13a.3       Reference cell frequency list.       .266         9.1.13a.4       Cell Channel Description       .266         9.1.13b       GPRS suspension request       .266         9.1.14       Handover command       .266         9.1.15       Handover command       .266         9.1.15       Handover command       .266         9.1.15       Handover command       .267         9.1.15       Handover command       .267         9.1.15       Handover command       .269         9.1.15       Mode of the First Channel (Channel Set 1) and Mode of Channel Set "X" (2= <x<=8)< td="">       .269         9.1.15.4       Mode of the Second Channel       .269       .1.15.4         9.1.15.5       Frequency Channel Sequence, Frequency List, Frequency short list and Mobile Allocation, after       .269         9.1.15.6       Starting Time       .270       .270         9.1.15.7       <td< td=""><td>,</td><td></td><td></td></td<></x<=8)<>	,		
9.1.13       Frequency redefinition       263         9.1.13.1       Cell Channel Description       264         9.1.13a       PDCH Assignment command       264         9.1.13a.1       Mobile Allocation and Frequency List, after the starting time.       265         9.1.13a.2       Starting Time.       266         9.1.13a.3       Reference cell frequency list.       266         9.1.13a.4       Cell Channel Description       266         9.1.13a.5       Packet Assignment       266         9.1.13b       GPRS suspension request       266         9.1.15       Handover access       267         9.1.15       Handover access       267         9.1.15.1       Synchronization Indication       269         9.1.15.2       Mode of the First Channel (Channel Set 1) and Mode of Channel Set "X" (2= <x<=8)< td="">       269         9.1.15.4       Mode of the Second Channel       269         9.1.15.5       Frequency Channel Sequence, Frequency List, Frequency short list and Mobile Allocation, after       270         9.1.15.7       Reference cell frequency list.       270         9.1.15.8       Real Time Difference       271         9.1.15.1       VGCS target mode indication       271         9.1.15.1       VGCS target mode ind</x<=8)<>			
9.1.13.1       Cell Channel Description       264         9.1.13a       PDCH Assignment command       265         9.1.13a.1       Mobile Allocation and Frequency List, after the starting time.       265         9.1.13a.2       Starting Time.       265         9.1.13a.3       Reference cell frequency list.       266         9.1.13a.4       Cell Channel Description       266         9.1.13a.5       Packet Assignment.       266         9.1.13a       GPRS suspension request       266         9.1.14       Handover access       267         9.1.15       Handover access       267         9.1.15       Handover access       267         9.1.15.1       Synchronization Indication       267         9.1.15.2       Mode of the First Channel (Channel Set 1) and Mode of Channel Set "X" (2= <x<=8)< td="">       269         9.1.15.3       Description of the Second Channel       269       269         9.1.15.4       Mode of the Second Channel       269       269         9.1.15.5       Frequency Channel Sequence, Frequency List, Frequency short list and Mobile Allocation, after       270         9.1.15.6       Starting Time.       270       270         9.1.15.7       Reference cell frequency list.       270</x<=8)<>			
9.1.13a       PDCH Assignment command			
9.1.13a.1       Mobile Allocation and Frequency List, after the starting time.       265         9.1.13a.2       Starting Time			
9.1.13a.2       Starting Time       265         9.1.13a.4       Cell Channel Description       266         9.1.13a.5       Packet Assignment       266         9.1.13a.5       Packet Assignment       266         9.1.13a.5       Packet Assignment       266         9.1.13b       GPRS suspension request       266         9.1.15       Handover command       267         9.1.15       Handover command       267         9.1.15.1       Synchronization Indication       269         9.1.15.2       Mode of the First Channel (Channel Set 1) and Mode of Channel Set "X" (2= <x<=8)< td="">       269         9.1.15.4       Mode of the Second Channel       269         9.1.15.5       Frequency Channel sequence, Frequency List, Frequency short list and Mobile Allocation, after       269         9.1.15.6       Starting Time       270         9.1.15.7       Reference cell frequency list       270         9.1.15.8       Real Time Difference       270         9.1.15.9       Timing Advance.       271         9.1.15.1       VGCS target mode indication       271         9.1.15.1       VGCS target mode indication       271         9.1.15.1       Moli Bobserved Time Difference       271         9.1.1</x<=8)<>			
9.1.13a.3       Reference cell frequency list.       266         9.1.13a.4       Cell Channel Description       266         9.1.13a.5       Packet Assignment.       266         9.1.13b       GPRS suspension request.       266         9.1.14       Handover access.       267         9.1.15       Handover command.       269         9.1.15.1       Synchronization Indication       269         9.1.15.2       Mode of the First Channel (Channel Set 1) and Mode of Channel Set "X" (2= <x<=8).< td="">       269         9.1.15.4       Mode of the Second Channel       269         9.1.15.5       Frequency Channel Sequence, Frequency List, Frequency short list and Mobile Allocation, after       269         9.1.15.7       Reference cell frequency list.       270         9.1.15.8       Real Time Difference       270         9.1.15.9       Timing Advance.       271         9.1.15.10       Cipher Mode Setting       2711         9.1.15.11       VGCS target mode indication       271         9.1.15.12       Description of the multislot allocation       271         9.1.15.10       Cipher Mode Setting       2711         9.1.15.11       VGCS target mode indication       271         9.1.15.13       MultiRateconfiguration</x<=8).<>			
9.1.13a.4       Cell Channel Description       266         9.1.13a.5       Packet Assignment       266         9.1.13b       GPRS suspension request       266         9.1.14       Handover access       267         9.1.15       Handover command       267         9.1.15       Synchronization Indication       269         9.1.15.2       Mode of the First Channel (Channel Set 1) and Mode of Channel Set "X" (2= <x<=8).< td="">       269         9.1.15.3       Description of the Second Channel       269         9.1.15.4       Mode of the Second Channel       269         9.1.15.5       Frequency Channel Sequence, Frequency List, Frequency short list and Mobile Allocation, after       269         9.1.15.6       Starting Time.       269         9.1.15.7       Reference cell frequency list.       270         9.1.15.8       Real Time Difference       270         9.1.15.9       Timing Advance       271         9.1.15.10       Cipher Mode Setting       271         9.1.15.11       VGCS target mode indication       271         9.1.15.12       Description of the multislot allocation       271         9.1.15.13       MultiRateconfiguration       271         9.1.15.14       Mobile Observed Time Difference       27</x<=8).<>			
9.1.13a.5       Packet Assignment       266         9.1.13b       GPRS suspension request       266         9.1.14       Handover access       267         9.1.15       Handover command       267         9.1.15.1       Synchronization Indication       269         9.1.15.2       Mode of the First Channel (Channel Set 1) and Mode of Channel Set "X" (2= <x<=8)< td="">       269         9.1.15.3       Description of the Second Channel       269         9.1.15.4       Mode of the Second Channel       269         9.1.15.5       Frequency Channel Sequence, Frequency List, Frequency short list and Mobile Allocation, after       269         9.1.15.6       Starting Time       270         9.1.15.7       Reference cell frequency list       270         9.1.15.8       Real Time Difference       270         9.1.15.9       Timing Advance       271         9.1.15.11       VGCS target mode indication       271         9.1.15.12       Description of the multislot allocation       271         9.1.15.13       MultiRateconfiguration       271         9.1.15.13       MultiRateconfiguration       271         9.1.15.14       Handover complete       271         9.1.15.13       MultiRateconfiguration       271     <td>9.1.13a.4</td><td></td><td></td></x<=8)<>	9.1.13a.4		
9.1.13b       GPRS suspension request       266         9.1.14       Handover access       267         9.1.15       Handover command       267         9.1.15.1       Synchronization Indication       269         9.1.15.2       Mode of the First Channel (Channel Set 1) and Mode of Channel Set "X" (2= <x<=8)< td="">       269         9.1.15.3       Description of the Second Channel       269         9.1.15.4       Mode of the Second Channel       269         9.1.15.5       Frequency Channel Sequence, Frequency List, Frequency short list and Mobile Allocation, after       269         9.1.15.6       Starting Time       270         9.1.15.7       Reference cell frequency list       270         9.1.15.8       Real Time Difference       270         9.1.15.9       Timing Advance       271         9.1.15.10       Cipher Mode Setting       271         9.1.15.11       VGCS target mode indication       271         9.1.15.12       Description of the multislot allocation       271         9.1.15.13       MultiRateconfiguration       271         9.1.15.14       Handover complete       271         9.1.15       Mode indication       271         9.1.15.11       VGCS target mode indication       271</x<=8)<>	9.1.13a.5		
9.1.15       Handover command       267         9.1.15.1       Synchronization Indication       269         9.1.15.2       Mode of the First Channel (Channel Set 1) and Mode of Channel Set "X" (2= <x<=8)< td=""><td>9.1.13b</td><td></td><td></td></x<=8)<>	9.1.13b		
9.1.15.1         Synchronization Indication         269           9.1.15.2         Mode of the First Channel (Channel Set 1) and Mode of Channel Set "X" (2= <x<=8)< td=""><td>9.1.14</td><td>Handover access</td><td>267</td></x<=8)<>	9.1.14	Handover access	267
9.1.15.2Node of the First Channel (Channel Set 1) and Mode of Channel Set "X" (2= <x<=8)< td=""><td>9.1.15</td><td></td><td></td></x<=8)<>	9.1.15		
9.1.15.3Description of the Second Channel2699.1.15.4Mode of the Second Channel2699.1.15.5Frequency Channel Sequence, Frequency List, Frequency short list and Mobile Allocation, aftertime2699.1.15.6Starting Time.2709.1.15.79.1.15.8Real Time Difference2709.1.15.89.1.15.9Timing Advance.2712719.1.15.10Cipher Mode Setting2719.1.15.129.1.15.12Description of the multislot allocation2719.1.15.139.1.16.1Handover complete2712719.1.16.1Mobile Observed Time Difference2729.1.179.1.18.0Dedicated mode or TBF2739.1.18.0a20.18.0cPacket Channel Description2739.1.18.0d20.18.0dRequest Reference2739.1.18.1Mobile Allocation2739.1.18.1Mobile Allocation2739.1.18.14.118.25.118.2	9.1.15.1		
9.1.15.4Mode of the Second Channel2699.1.15.5Frequency Channel Sequence, Frequency List, Frequency short list and Mobile Allocation, after time2699.1.15.6Starting Time2709.1.15.7Reference cell frequency list2709.1.15.8Real Time Difference2709.1.15.9Timing Advance2719.1.15.10Cipher Mode Setting2719.1.15.11VGCS target mode indication2719.1.15.12Description of the multislot allocation2719.1.15.13MultRateconfiguration2719.1.16.1Handover complete2729.1.17Handover failure2729.1.18Immediate assignment2729.1.18Channel Description2739.1.18.0Channel Description2739.1.18.0Request Reference2739.1.18.1Mobile Allocation2749.1.18.2Starting Time274			
9.1.15.5Frequency Channel Sequence, Frequency List, Frequency short list and Mobile Allocation, after timetime			
time         269           9.1.15.6         Starting Time.         270           9.1.15.7         Reference cell frequency list         270           9.1.15.7         Reference cell frequency list         270           9.1.15.8         Real Time Difference         270           9.1.15.9         Timing Advance         271           9.1.15.0         Cipher Mode Setting         271           9.1.15.10         Vipher Mode Setting         271           9.1.15.11         VGCS target mode indication         271           9.1.15.12         Description of the multislot allocation         271           9.1.15.13         MultiRateconfiguration         271           9.1.16         Handover complete         271           9.1.16.1         Mobile Observed Time Difference         272           9.1.17         Handover failure         272           9.1.18         Immediate assignment         272           9.1.18.0a         Dedicated mode or TBF         273           9.1.18.0b         Channel Description         273           9.1.18.0c         Packet Channel Description         273           9.1.18.0b         Request Reference         273           9.1.18.0c         Timing Advance			269
9.1.15.6       Starting Time	9.1.15.5		• • • •
9.1.15.7       Reference cell frequency list.       270         9.1.15.8       Real Time Difference       270         9.1.15.8       Real Time Difference       270         9.1.15.9       Timing Advance       271         9.1.15.10       Cipher Mode Setting       271         9.1.15.11       VGCS target mode indication       271         9.1.15.12       Description of the multislot allocation       271         9.1.15.13       MultiRateconfiguration       271         9.1.16       Handover complete       271         9.1.16.1       Mobile Observed Time Difference       272         9.1.17       Handover failure       272         9.1.18       Immediate assignment       272         9.1.18       Immediate assignment       273         9.1.18.0b       Channel Description       273         9.1.18.0c       Packet Channel Description       273         9.1.18.0d       Request Reference       273         9.1.18.0e       Timing Advance       274         9.1.18.1       Mobile Allocation       274         9.1.18.2       Starting Time       274	01156		
9.1.15.8       Real Time Difference       270         9.1.15.9       Timing Advance       271         9.1.15.10       Cipher Mode Setting       271         9.1.15.11       VGCS target mode indication       271         9.1.15.12       Description of the multislot allocation       271         9.1.15.13       MultiRateconfiguration       271         9.1.16       Handover complete       271         9.1.16       Handover failure       272         9.1.17       Handover failure       272         9.1.18       Immediate assignment       272         9.1.18.0a       Dedicated mode or TBF       273         9.1.18.0b       Channel Description       273         9.1.18.0c       Packet Channel Description       273         9.1.18.0d       Request Reference       273         9.1.18.0e       Timing Advance       274         9.1.18.1       Mobile Allocation       274		•	
9.1.15.9       Timing Advance       271         9.1.15.10       Cipher Mode Setting       271         9.1.15.11       VGCS target mode indication       271         9.1.15.12       Description of the multislot allocation       271         9.1.15.13       MultiRateconfiguration       271         9.1.16       Handover complete       271         9.1.16.1       Mobile Observed Time Difference       272         9.1.17       Handover failure       272         9.1.18       Immediate assignment       272         9.1.18.0a       Dedicated mode or TBF       273         9.1.18.0b       Channel Description       273         9.1.18.0c       Packet Channel Description       273         9.1.18.0d       Request Reference       273         9.1.18.0e       Timing Advance       274         9.1.18.1       Mobile Allocation       274			
9.1.15.10Cipher Mode Setting2719.1.15.11VGCS target mode indication2719.1.15.12Description of the multislot allocation2719.1.15.13MultiRateconfiguration2719.1.16Handover complete2719.1.16.1Mobile Observed Time Difference2729.1.17Handover failure2729.1.18Immediate assignment2729.1.18.0aDedicated mode or TBF2739.1.18.0bChannel Description2739.1.18.0cPacket Channel Description2739.1.18.0dRequest Reference2739.1.18.1Mobile Allocation2749.1.18.1Mobile Allocation2749.1.18.2Starting Time274			
9.1.15.11VGCS target mode indication2719.1.15.12Description of the multislot allocation2719.1.15.13MultiRateconfiguration2719.1.16Handover complete2719.1.16.1Mobile Observed Time Difference2729.1.17Handover failure2729.1.18Immediate assignment2729.1.18.0aDedicated mode or TBF2739.1.18.0bChannel Description2739.1.18.0cPacket Channel Description2739.1.18.0dRequest Reference2739.1.18.0eTiming Advance2749.1.18.1Mobile Allocation2749.1.18.2Starting Time274			
9.1.15.12Description of the multislot allocation2719.1.15.13MultiRateconfiguration2719.1.16Handover complete2719.1.16.1Mobile Observed Time Difference2729.1.17Handover failure2729.1.18Immediate assignment2729.1.18.0aDedicated mode or TBF2739.1.18.0bChannel Description2739.1.18.0cPacket Channel Description2739.1.18.0dRequest Reference2739.1.18.0eTiming Advance2749.1.18.1Mobile Allocation2749.1.18.2Starting Time274			
9.1.15.13MultiRateconfiguration2719.1.16Handover complete2719.1.16.1Mobile Observed Time Difference2729.1.17Handover failure2729.1.18Immediate assignment2729.1.18.0aDedicated mode or TBF2739.1.18.0bChannel Description2739.1.18.0cPacket Channel Description2739.1.18.0dRequest Reference2739.1.18.0eTiming Advance2749.1.18.1Mobile Allocation2749.1.18.2Starting Time274			
9.1.16Handover complete2719.1.16.1Mobile Observed Time Difference2729.1.17Handover failure2729.1.18Immediate assignment2729.1.18.0aDedicated mode or TBF2739.1.18.0bChannel Description2739.1.18.0cPacket Channel Description2739.1.18.0dRequest Reference2739.1.18.0eTiming Advance2749.1.18.1Mobile Allocation2749.1.18.2Starting Time274			
9.1.16.1Mobile Observed Time Difference2729.1.17Handover failure2729.1.18Immediate assignment2729.1.18.0aDedicated mode or TBF2739.1.18.0bChannel Description2739.1.18.0cPacket Channel Description2739.1.18.0dRequest Reference2739.1.18.0eTiming Advance2749.1.18.1Mobile Allocation2749.1.18.2Starting Time274			
9.1.17       Handover failure       272         9.1.18       Immediate assignment       272         9.1.18.0a       Dedicated mode or TBF.       273         9.1.18.0b       Channel Description       273         9.1.18.0c       Packet Channel Description       273         9.1.18.0d       Request Reference.       273         9.1.18.0e       Timing Advance       274         9.1.18.1       Mobile Allocation       274         9.1.18.2       Starting Time.       274			
9.1.18Immediate assignment2729.1.18.0aDedicated mode or TBF.2739.1.18.0bChannel Description2739.1.18.0cPacket Channel Description2739.1.18.0dRequest Reference2739.1.18.0eTiming Advance2749.1.18.1Mobile Allocation2749.1.18.2Starting Time274			
9.1.18.0aDedicated mode or TBF.2739.1.18.0bChannel Description.2739.1.18.0cPacket Channel Description2739.1.18.0dRequest Reference.2739.1.18.0eTiming Advance.2749.1.18.1Mobile Allocation2749.1.18.2Starting Time.274			
9.1.18.0b         Channel Description         273           9.1.18.0c         Packet Channel Description         273           9.1.18.0d         Request Reference         273           9.1.18.0e         Timing Advance         274           9.1.18.1         Mobile Allocation         274           9.1.18.2         Starting Time         274		•	
9.1.18.0c       Packet Channel Description       273         9.1.18.0d       Request Reference       273         9.1.18.0e       Timing Advance       274         9.1.18.1       Mobile Allocation       274         9.1.18.2       Starting Time       274			
9.1.18.0d       Request Reference	9.1.18.0c		
9.1.18.1       Mobile Allocation       274         9.1.18.2       Starting Time       274	9.1.18.0d	-	
9.1.18.2 Starting Time	9.1.18.0e	0	
9.1.18.3 IA Rest Octets (Frequency parameters, before time)			
	9.1.18.3	IA Rest Octets (Frequency parameters, before time)	274

9.1.18.4	IA Rest Octets (assignment of uplink or downlink TBF)	
9.1.19	Immediate assignment extended	274
9.1.19.1	Unnecessary IEs	275
9.1.19.2	Mobile Allocation	275
9.1.19.3	Starting Time	275
9.1.19.4	Maximum message length	275
9.1.19.5	IAX Rest Octets	
9.1.20	Immediate assignment reject	
9.1.20.1	Use of the indexes	
9.1.20.2	Filling of the message	276
9.1.20.3	Wait Indication	
9.1.20.4	IAR Rest Octets	
9.1.21	Measurement report	
9.1.21a	Notification/FACCH	
9.1.21a.1	Spare	
9.1.21a.2	Spare	
9.1.21a.3	Spare	
9.1.21a.4	Spare	
9.1.21b	Notification/NCH	
9.1.21b.1	Spare	
9.1.21b.2	Spare	
9.1.21d	Notification response	
9.1.21e	RR-Cell Change Order	
9.1.22	Paging request type 1	
9.1.22.1	Unnecessary IE	
9.1.22.2	Channels needed for Mobiles 1 and 2	
9.1.22.3	Mobile Identities	
9.1.22.4	P1 Rest Octets	
9.1.23	Paging request type 2	
9.1.23.1	Channels needed for Mobiles 1 and 2	
9.1.23.2	Mobile Identity 3	
9.1.23.3	P2 Rest Octets	
9.1.24	Paging request type 3	
9.1.24.1	Channels needed for Mobiles 1 and 2	
9.1.24.2	P3 Rest Octets	
9.1.25	Paging response	
9.1.25.1	Mobile Station Classmark	
9.1.26	Partial release	
9.1.26.1	Channel Description	
9.1.27	Partial release complete	
9.1.28	Physical information	
9.1.28.a 9.1.29	RR Initialisation Request	
9.1.29	RR Status	
9.1.30	Synchronization channel information	
9.1.31	System information Type 1 System information type 2	
9.1.32	System information type 2	
9.1.33	System information type 2013	
9.1.34	System information type 2 services and a service system information type 3	
9.1.35	System information type 4	
9.1.36.1	CBCH Channel description.	
9.1.36.2	CBCH Mobile Allocation	
9.1.36.3	SI 4 Rest Octets	
9.1.30.3	System information type 5	
9.1.37	System information type 5	
9.1.39	System information type 50ts	
9.1.40	System information type 6	
9.1.40.1	Cell Identity.	
9.1.40.2	Location Area Identification	
9.1.40.3	Cell Options	
9.1.40.4	NCC permitted	
9.1.41	System information type 7	
	J	

9.1.43a       System information Type 13.       295         9.1.43b       System information type 13.       296         9.1.43c       ISparcl       296         9.1.43d       System information type 16.       296         9.1.43d       System information type 17.       296         9.1.44a       System information type 17.       296         9.1.44       Takker inficiation       297         9.1.44       Takker inficiation       297         9.1.44       Uplink access       297         9.1.45       Uplink free       298         9.1.44       Tubker inficiation       299         9.1.44       Tubker inficiation       299         9.1.45       Uplink free       298         9.1.44       Tubker inficiation       300         9.1.51       EXTENDED MEASUREMENT ORDER       300         9.1.52       Extended measurement report       301         9.2       Authentication reject       302         9.2.1       Authentication reject       303         9.2.2       Authentication reject       303         9.2.3       Authentication reject       303         9.2.4       Location infation type 105       304	9.1.42	System information type 9	204
9.143a System information Type 13			
9.1.43b         [Spare]			
9.1.43c         [Spare]         296           9.1.43b         System information type 16.         296           9.1.43c         System information type 17.         296           9.1.44         Talker indication.         297           9.1.44         Uplink access         297           9.1.45         Uplink recess         297           9.1.46         Uplink recess         298           9.1.47         Uplink release         299           9.1.48         Uplink release         299           9.1.50         System information type 10 \$(ASCDS)         300           9.1.51         Extended measurement report.         301           9.2.2         Messages for mobility management.         302           9.2.1         Authentication reject.         303           9.2.2         Authentication regoest         303           9.2.3         Authentication regoest         304           9.2.4         Mobilis Station Classmark.         304           9.2.5         CM service propent \$(CCBS)S.         304           9.2.4         Mobilis Station Classmark.         307           9.2.9         Priority         307           9.2.1         Mobilis Station Classmark.         306 <td></td> <td>• • • • • • • • • • • • • • • • • • • •</td> <td></td>		• • • • • • • • • • • • • • • • • • • •	
9.1.43d       System information type 16			
9.1.44       System information type 17.	9.1.43d	- 1 -	
91.45       Uplink access       297         91.46       Uplink ree       298         91.48       Uplink release       299         91.48       Uplink release       299         91.50       System information type 10 \$(ASCI)\$       300         91.51       EXTENDED DMEASUREMENT ORDER       300         91.52       Extended measurement report       301         92       Messages for mobility management       302         92.1       Authentication request       303         92.1       Authentication request       303         92.2       Authentication request       303         92.3       Authentication request       303         92.4       CM e-estabilishment request       304         92.4.1       Location acre identification.       304         92.4.2       Mobils Station Classmark       304         92.5.3       CM service rompt \$(CCB\$)\$       305         92.7       CM service request       306         92.5.4       CM service request       306         92.5.7       CM service request       307         92.6       CM service request       307         92.9       Priority       307         9	9.1.43e		
9.1.46       Upink free	9.1.44	Talker indication	
9.1.47         Uplink freé         298           9.1.48         Uplink release         299           9.1.49         VGCs uplink grant         299           9.1.50         System information type 10 \$(ASCI)\$         300           9.1.51         EXTENDED MEASUREMENT ORDER         300           9.1.52         Extended measurement report.         301           9.1.53         Application Information reject.         302           9.2.1         Authentication reject.         303           9.2.2         Authentication request.         303           9.2.3         Authentication request.         304           9.2.4         CM Re-establishment request.         304           9.2.4.1         Location area identification         304           9.2.5a         CM service accept.         304           9.2.5a         CM service reject.         305           9.2.7         CM service reject.         305           9.2.8         Abort.         306           9.2.9         Priority         307           9.2.9         Priority         307           9.2.10         Identity request.         307           9.2.11         Identity request.         307		•	
9.1.48         Upink release         299           9.1.49         VGCS uplink grant         299           9.1.50         System information type 10 S(ASCI)5         300           9.1.51         EXTENDED MEASUREMENT ORDER         300           9.1.52         Extended measurement report.         301           9.1.53         Application Information         301           9.2         Authentication reject.         302           9.2.1         Authentication response         303           9.2.4         CM Re-establishment request.         303           9.2.4         Location reai identification         304           9.2.5         CM service prompt S(CCBS)S.         305           9.2.6         CM service roject.         305           9.2.7         CM service reject.         305           9.2.8         Abort.         306           9.2.9         Priority.         307           9.2.9         Priority.         307           9.2.10         Identity request         307           9.2.11         Identity request         307           9.2.12         Mobile Station Classmark.         308           9.2.13         Location updating accept.         308			
9.1.49         VCCS uplink grant         299           9.1.50         System information type 10 \$(ASCI)s         300           9.1.51         EXTENDED MEASUREMENT ORDER         300           9.1.52         Extended measurement report.         301           9.1.53         Application Information         301           9.2.1         Authentication reject.         302           9.2.2         Authentication request.         303           9.2.3         Authentication request.         303           9.2.4         CM Re-establishment request.         304           9.2.4.1         Location area identification.         304           9.2.4         Mobile Station Classmark.         304           9.2.5         CM service accept.         304           9.2.6         CM service accept.         305           9.2.7         CM service accept.         305           9.2.8         Abort.         306           9.2.9         CM service request.         306           9.2.9.1         Mobile Station Classmark         307           9.2.9.2         Priority         307           9.2.9.2         Priority         307           9.2.9.1         Mobile Station Classmark         309 <td></td> <td>1</td> <td></td>		1	
9.1.50         System information type 10 \$(ASCD)         300           9.1.51         EXTENDED MEASUREMENT ORDER         300           9.1.52         Extended measurement report.         301           9.1.53         Application Information         301           9.2         Messages for mobility management.         302           9.2.1         Authentication reject.         303           9.2.3         Authentication request.         303           9.2.4         CM Re-establishment request.         303           9.2.4         Location area identification.         304           9.2.4.1         Location area identification.         304           9.2.5         CM service accept.         304           9.2.5         CM service accept.         304           9.2.6         CM service abort.         305           9.2.7         CM service request.         306           9.2.9         Priority.         307           9.2.10         Identity request.         307           9.2.11         Identity request.         306           9.2.12         Mobile Station Classmark         307           9.2.12         Identity request.         307           9.2.13         Location updating acc		1	
9.1.51         EXTENDED MEASUREMENT ORDER         300           9.1.52         Extended measurement report.         301           9.2         Messages for mobility management.         302           9.2.1         Authentication reject.         302           9.2.1         Authentication request.         303           9.2.3         Authentication request.         303           9.2.4         CM Re-establishment request.         304           9.2.4.1         Location area identification.         304           9.2.4.2         Mobile Station Classmark.         304           9.2.5.3         CM service accept.         304           9.2.5.4         CM service reject.         305           9.2.6         CM service reject.         305           9.2.7         CM service reject.         306           9.2.8         Abort         306           9.2.9         Priority request.         307           9.2.9.1         Mobile Station Classmark.         307           9.2.10         Identity request.         307           9.2.11         Identity request.         307           9.2.12         IMobile Station Classmark.         309           9.2.13.1         Coration updating request. <td></td> <td></td> <td></td>			
9.1.52       Extended measurement report.       301         9.1.53       Application Information       301         9.2       Messages for mobility management.       302         9.2.1       Authentication reject.       303         9.2.2       Authentication response.       303         9.2.3       Authentication request.       303         9.2.4       CM Re-establishment request.       304         9.2.5       CM service accept.       304         9.2.5       CM service accept.       304         9.2.5       CM service abort.       306         9.2.6       CM service reject.       305         9.2.7       CM service reguest.       306         9.2.8       Abort.       306         9.2.9.1       Mobile Station Classmark.       307         9.2.9.2       Priority.       307         9.2.10       Identity request.       307         9.2.11       Identity request.       309         9.2.12       Mobile Station Classmark.       309         9.2.13       Location updating accept.       309         9.2.14       Location updating request.       310         9.2.15.1       Location updating request.       310			
9.153       Application Information       301         9.2       Messages for mobility management.       302         9.2.1       Authentication reject.       302         9.2.2       Authentication regest.       303         9.2.4       CM Re-stablishment request.       304         9.2.4.1       Location area identification.       304         9.2.4.2       Mobile Station Classmark.       304         9.2.5.3       CM service accept.       304         9.2.5.4       CM service reject.       305         9.2.6       CM service reject.       306         9.2.7       CM service request .       306         9.2.8       Abort.       306         9.2.9       CM service request .       307         9.2.9.1       Mobile Station Classmark.       307         9.2.10.1       Identity request.       307         9.2.11       Identity request.       307         9.2.12.1       Mobile Station Classmark.       309         9.2.13.1       Follow on proceed.       309         9.2.14       Location updating request.       310         9.2.15.1       Location updating request.       310         9.2.15.2       Mobile Station Classmark.			
9.2.1       Authentication reject.       302         9.2.1       Authentication reguest.       303         9.2.3       Authentication request.       303         9.2.4       CM Re-establishment request.       304         9.2.4.1       Location area identification.       304         9.2.4.2       Mobile Station Classmark.       304         9.2.5       CM service accept.       304         9.2.6       CM service reject.       305         9.2.6       CM service reject.       305         9.2.7       CM service request       306         9.2.8       Abort.       306         9.2.9       Priority request.       307         9.2.10       Identity request.       307         9.2.11       Identity request.       307         9.2.12       Mobile Station Classmark.       309         9.2.13       Location updating accept.       309         9.2.14       Identity request.       309         9.2.13       Follow on procced.       309         9.2.14       Location updating accept.       309         9.2.15.1       Location updating reject.       310         9.2.15.2       Mobile Station Classmark.       310		1	
9.2.1       Authentication reject.       302         9.2.2       Authentication request.       303         9.2.3       Authentication request.       303         9.2.4       CM Re-establishment request.       304         9.2.4.1       Location area identification.       304         9.2.4.2       Mobile Station Classmark.       304         9.2.5       CM service accept.       304         9.2.5.2       CM service prompt \$(CCBS)\$.       305         9.2.6       CM service reject.       306         9.2.7       CM service reject.       306         9.2.8       Abort.       306         9.2.9       CM service reject.       306         9.2.9       CM service request.       306         9.2.9       Priority       307         9.2.10       Identity request.       307         9.2.11       Identity request.       309         9.2.12       IMSI detach indication.       308         9.2.13       Location updating accept.       309         9.2.14       Location updating reject.       310         9.2.15       Location updating reject.       310         9.2.14       Location updating reject.       310 <tr< td=""><td></td><td>••</td><td></td></tr<>		••	
9.2.2       Authentication request       303         9.2.3       Authentication response       303         9.2.4       CM Re-establishment request       304         9.2.4.1       Location area identification       304         9.2.4.2       Mobile Station Classmark       304         9.2.5       CM service accept       304         9.2.6       CM service rompt \$(CCBS)\$       305         9.2.6       CM service reject       306         9.2.7       CM service request       306         9.2.8       Abort       306         9.2.9       Mobile Station Classmark       307         9.2.9.1       Mobile Station Classmark       307         9.2.9.2       Priority       307         9.2.10       Identity request       307         9.2.11       Identity request       309         9.2.12       IMSI detach indication       308         9.2.12.1       Mobile Station Classmark       309         9.2.13       Location updating accept       309         9.2.13       Location updating reject       310         9.2.14       Location updating reject       310         9.2.15       Location updating reject       310      <			
9.2.3       Authentication response.       303         9.2.4       CM Re-establishment request.       304         9.2.4.1       Location area identification.       304         9.2.4.2       Mobile Station Classmark.       304         9.2.5       CM service accept.       304         9.2.5       CM service reject.       305         9.2.6       CM service reject.       305         9.2.7       CM service request.       306         9.2.9       CM service request.       306         9.2.9.1       Mobile Station Classmark.       307         9.2.9.2       Priority.       307         9.2.10       Identity request.       306         9.2.11       Identity response.       308         9.2.12.1       Mobile Station Classmark.       309         9.2.13       Location updating accept.       309         9.2.14       Location updating reject.       310         9.2.15       Location updating reject.       310         9.2.15.1       Location updating reject.       310         9.2.15.2       Mobile Station Classmark.       311         9.2.15.1       Location updating reject.       310         9.2.15.2       Mobile Station Classmark	9.2.2		
9.2.4.1       Location area identification       304         9.2.4.2       Mobile Station Classmark       304         9.2.5       CM service accept       304         9.2.5       CM service accept       305         9.2.6       CM service reject       305         9.2.7       CM service rejuest       306         9.2.8       Abort       306         9.2.9       CM service request       306         9.2.9       Priority       307         9.2.9       Priority       307         9.2.10       Identity request       306         9.2.12       IMSI detach indication       308         9.2.12       IMSI detach indication       308         9.2.13       Location updating accept       309         9.2.13       Location updating reject       310         9.2.14       Location updating reject       310         9.2.15.1       Location updating reject       310         9.2.15.2       Mobile Station Classmark       310         9.2.15.4       Location updating reject       310         9.2.15.4       Location updating reject       310         9.2.15.4       Mobile Station Classmark       311         9.2	9.2.3		
9.2.4.2       Mobile Station Classmark	9.2.4	CM Re-establishment request	
9.2.5       CM service accept	9.2.4.1		
9.2.5a       CM service prompt \$(CCBS)\$			
92.6       CM service reject       305         9.2.7       CM service abort       306         9.2.8       Abort       306         9.2.9       CM service request       306         9.2.9.1       Mobile Station Classmark       307         92.9.2       Priority       307         92.9.1       Identity request       307         92.10       Identity request       308         92.11       Identity request       308         92.12       IMSI detach indication       308         92.12.1       Mobile Station Classmark       309         92.13       Location updating accept       309         92.13.1       Follow on proceed.       309         92.14       Location updating reject       310         92.15.1       Location area identification       310         92.15.2       Mobile Station Classmark       310         92.15.2       Mobile Station Classmark       311         92.15.4       Location area identification       310         92.15.5       Location area identification       311         92.15.4       Universal time and time zone       311         92.15.5       LSA Identity       311 <td< td=""><td></td><td></td><td></td></td<>			
9.2.7       CM service abort			
9.2.8       Abort       306         9.2.9       CM service request       306         9.2.9.1       Mobile Station Classmark       307         9.2.9.2       Priority       307         9.2.10       Identity request       307         9.2.11       Identity response       308         9.2.12       IMSI detach indication       308         9.2.13       Location updating accept       309         9.2.13       Location updating reject       309         9.2.14       Location updating reject       310         9.2.15       Location updating request       310         9.2.15       Location updating request       310         9.2.15       Location updating request       310         9.2.15.1       Location classmark       311         9.2.15.2       Mobile Station Classmark       311         9.2.15.2       Mobile Station Classmark       311         9.2.15.3       Location near identification       310         9.2.15.4       Mu information       311         9.2.15.5       Mobile Station Classmark       311         9.2.15.1       Location network       311         9.2.15.2       Mobile Station Classmark       311			
9.2.9       CM service request       306         9.2.9.1       Mobile Station Classmark       307         9.2.9.2       Priority       307         9.2.10       Identity request       307         9.2.11       Identity request       308         9.2.12       IMSI detach indication       308         9.2.12.1       Mobile Station Classmark       309         9.2.13       Location updating accept       309         9.2.14       Location updating reject       309         9.2.15       Location updating reject       310         9.2.15       Location updating request       310         9.2.15       Location updating request       310         9.2.15.1       Location updating request       310         9.2.15.2       Mobile Station Classmark       311         9.2.15.4       Mu information       311         9.2.15.2       Mobile Station Classmark       311         9.2.15.3       Network time zone       311         9.2.15.4       Full name for network       311         9.2.15.3       LSA Identity       311         9.2.15.4       Universal time and time zone       311         9.2.15.5       LSA Identity       312			
9.2.9.1       Mobile Station Classmark			
9.2.9.2       Priority			
9.2.10       Identity request			
9.2.11       Identify response       308         9.2.12       IMSI detach indication       308         9.2.12.1       Mobile Station Classmark       309         9.2.13       Location updating accept       309         9.2.13.1       Follow on proceed       309         9.2.13.2       CTS permission       309         9.2.14       Location updating reject       310         9.2.15       Location updating request       310         9.2.15.1       Location classmark       311         9.2.15.2       Mobile Station Classmark       311         9.2.15.3       Molie Station Classmark       311         9.2.15.4       Location updating request       310         9.2.15.5       Mobile Station Classmark       311         9.2.15.2       Mobile Station Classmark       311         9.2.15.3       Full name for network       311         9.2.15a.3       Network time zone       311         9.2.15a.4       Universal time and time zone       311         9.2.15a.5       LSA Identity       312         9.2.17       TMSI reallocation command       312         9.2.18       TMSI reallocation complete       312         9.2.19       MM Null <td></td> <td>•</td> <td></td>		•	
9.2.12.1       Mobile Station Classmark	9.2.11		
9.2.13Location updating accept3099.2.13.1Follow on proceed3099.2.13.2CTS permission3099.2.14Location updating reject3109.2.15Location updating request3109.2.16.1Location area identification3109.2.15.2Mobile Station Classmark3119.2.15.3MM information3119.2.15.4Full name for network3119.2.15.5Short name for network3119.2.15.3Network time zone3119.2.15.4Universal time and time zone3119.2.15.5LSA Identity3119.2.15.6JSA Identity3129.2.159.3.1Alerting3129.3.1Alerting3139.3Messages for circuit-switched call control3139.3.1.1Facility3149.3.1.1.2Progress indicator3159.3.1.1.3User-user315	9.2.12	IMSI detach indication	
9.2.13.1       Follow on proceed.       309         9.2.13.2       CTS permission	9.2.12.1	Mobile Station Classmark	
9.2.13.2       CTS permission       309         9.2.14       Location updating reject       310         9.2.15       Location updating request       310         9.2.15.1       Location area identification       310         9.2.15.2       Mobile Station Classmark       311         9.2.15.a       MM information       311         9.2.15.a       Full name for network       311         9.2.15.a.1       Full name for network       311         9.2.15a.2       Short name for network       311         9.2.15a.3       Network time zone       311         9.2.15a.4       Universal time and time zone       311         9.2.15a.5       LSA Identity       311         9.2.16       MM Status       312         9.2.17       TMSI reallocation command       312         9.2.18       TMSI reallocation complete       312         9.2.19       MM Null       313         9.3       Messages for circuit-switched call control       313         9.3.1       Alerting (network to mobile station direction)       314         9.3.1.1       Facility.       315         9.3.1.1.3       User-user       315			
9.2.14       Location updating reject       310         9.2.15       Location updating request       310         9.2.15.1       Location area identification       310         9.2.15.2       Mobile Station Classmark       311         9.2.15.3       Memory for network       311         9.2.15.4       Universal time for network       311         9.2.15.5       LSA Identity       311         9.2.16       MM Status       312         9.2.17       TMSI reallocation command       312         9.2.18       TMSI reallocation complete       312         9.2.19       MM Null       313         9.3       Messages for circuit-switched call control       313         9.3.1       Alerting (network to mobile station direction)       314         9.3.1.1       Facility       315         9.3.1.1.3       User-user       315			
9.2.15       Location updating request			
9.2.15.1       Location area identification       310         9.2.15.2       Mobile Station Classmark       311         9.2.15.2       MM information       311         9.2.15.1       Full name for network       311         9.2.15a.1       Full name for network       311         9.2.15a.2       Short name for network       311         9.2.15a.3       Network time zone       311         9.2.15a.4       Universal time and time zone       311         9.2.15a.5       LSA Identity       311         9.2.16       MM Status       312         9.2.17       TMSI reallocation command       312         9.2.18       TMSI reallocation complete       313         9.3       Messages for circuit-switched call control       313         9.3.1       Alerting       314         9.3.1.1       Alerting (network to mobile station direction)       314         9.3.1.1       Facility       315         9.3.1.1.3       User-user       315			
9.2.15.2       Mobile Station Classmark       311         9.2.15a       MM information       311         9.2.15a.1       Full name for network       311         9.2.15a.2       Short name for network       311         9.2.15a.3       Network time zone       311         9.2.15a.4       Universal time and time zone       311         9.2.15a.5       LSA Identity       311         9.2.16       MM Status       312         9.2.17       TMSI reallocation command       312         9.2.18       TMSI reallocation complete       313         9.2.19       MM Null       313         9.3       Messages for circuit-switched call control       313         9.3.1       Alerting       314         9.3.1.1       Facility       315         9.3.1.1.2       Progress indicator       315         9.3.1.1.3       User-user       315			
9.2.15a       MM information       311         9.2.15a.1       Full name for network       311         9.2.15a.2       Short name for network       311         9.2.15a.3       Network time zone       311         9.2.15a.4       Universal time and time zone       311         9.2.15a.5       LSA Identity       311         9.2.16       MM Status       312         9.2.17       TMSI reallocation command       312         9.2.18       TMSI reallocation complete       313         9.3       Messages for circuit-switched call control       313         9.3.1       Alerting       314         9.3.1.1       Facility       315         9.3.1.1.2       Progress indicator       315         9.3.1.1.3       User-user       315			
9.2.15a.1       Full name for network       311         9.2.15a.2       Short name for network       311         9.2.15a.3       Network time zone       311         9.2.15a.4       Universal time and time zone       311         9.2.15a.5       LSA Identity       311         9.2.15a.6       MM Status       312         9.2.17       TMSI reallocation command       312         9.2.18       TMSI reallocation complete       313         9.2.19       MM Null       313         9.3       Messages for circuit-switched call control       313         9.3.1       Alerting (network to mobile station direction)       314         9.3.1.1       Facility       315         9.3.1.1.2       Progress indicator       315         9.3.1.1.3       User-user       315			
9.2.15a.2       Short name for network       311         9.2.15a.3       Network time zone       311         9.2.15a.4       Universal time and time zone       311         9.2.15a.5       LSA Identity       311         9.2.15a.5       LSA Identity       311         9.2.16       MM Status       312         9.2.17       TMSI reallocation command       312         9.2.18       TMSI reallocation complete       313         9.2.19       MM Null       313         9.3       Messages for circuit-switched call control       313         9.3.1       Alerting       314         9.3.1.1       Facility       315         9.3.1.1.2       Progress indicator       315         9.3.1.1.3       User-user       315			
9.2.15a.3       Network time zone       311         9.2.15a.4       Universal time and time zone       311         9.2.15a.5       LSA Identity       311         9.2.16       MM Status       312         9.2.17       TMSI reallocation command       312         9.2.18       TMSI reallocation complete       313         9.2.19       MM Null       313         9.3       Messages for circuit-switched call control       313         9.3.1       Alerting       314         9.3.1.1       Facility       315         9.3.1.1.2       Progress indicator       315         9.3.1.1.3       User-user       315			
9.2.15a.5       LSA Identity			
9.2.16       MM Status       312         9.2.17       TMSI reallocation command       312         9.2.18       TMSI reallocation complete       312         9.2.19       MM Null       313         9.3       Messages for circuit-switched call control       313         9.3.1       Alerting       314         9.3.1.1       Facility       315         9.3.1.2       Progress indicator       315         9.3.1.3       User-user       315	9.2.15a.4	Universal time and time zone	
9.2.17       TMSI reallocation command       312         9.2.18       TMSI reallocation complete       312         9.2.19       MM Null       313         9.3       Messages for circuit-switched call control       313         9.3.1       Alerting       314         9.3.1.1       Facility       315         9.3.1.2       Progress indicator       315         9.3.1.3       User-user       315	9.2.15a.5	LSA Identity	
9.2.18TMSI reallocation complete3129.2.19MM Null3139.3Messages for circuit-switched call control3139.3.1Alerting3149.3.1.1Alerting (network to mobile station direction)3149.3.1.1.1Facility3159.3.1.1.2Progress indicator3159.3.1.1.3User-user315			
9.2.19       MM Null       313         9.3       Messages for circuit-switched call control       313         9.3.1       Alerting       314         9.3.1.1       Alerting (network to mobile station direction)       314         9.3.1.1.1       Facility       315         9.3.1.1.2       Progress indicator       315         9.3.1.1.3       User-user       315			
9.3Messages for circuit-switched call control3139.3.1Alerting3149.3.1.1Alerting (network to mobile station direction)3149.3.1.1.1Facility3159.3.1.1.2Progress indicator3159.3.1.1.3User-user315			
9.3.1       Alerting			
9.3.1.1       Alerting (network to mobile station direction)		•	
9.3.1.1.1       Facility			
9.3.1.1.2       Progress indicator       315         9.3.1.1.3       User-user       315			
9.3.1.1.3 User-user			
<b>7.3.1.2</b> Alciting (mobile station to network uncertoin)	9.3.1.2	Alerting (mobile station to network direction)	
9.3.1.2.1 Facility			
9.3.1.2.2 User-user		•	

9.3.1.2.3       SS version         9.3.2       Call confirmed         9.3.2.1       Repeat indicator         9.3.2.2       Bearer capability 1 and bearer capability 2         9.3.2.3       Cause         9.3.2.4       CC Capabilities         9.3.3       Call proceeding         9.3.3.1       Repeat indicator         9.3.3.2       Bearer capability 1 and bearer capability 2         9.3.3.3       Facility         9.3.3.4       Progress Indicator         9.3.3.5       Priority granted         9.3.4.1       Cause         9.3.5.2       Connect (network to mobile station direction)         9.3.5.1.1       Facility.         9.3.5.1.2       Progress indicator         9.3.5.1.3       User-user         9.3.5.1       Connect (mobile station direction)         9.3.5.1.2       Progress indicator         9.3.5.1.3       User-user         9.3.5.2       Connet (mobile station to network direction)         9.3.5.2.1       Facility.         9.3.5.2.3       SS version         9.3.5.2.4       User-user         9.3.5.2.5       Connect (mobile station to network direction)         9.3.5.2.3       SS version	
9.3.2.1Repeat indicator9.3.2.2Bearer capability 1 and bearer capability 29.3.2.3Cause9.3.2.4CC Capabilities9.3.3Call proceeding9.3.3.1Repeat indicator9.3.3.2Bearer capability 1 and bearer capability 29.3.3.3Facility9.3.3.4Progress Indicator9.3.3.5Priority granted9.3.4Congestion control9.3.5.1Connect (network to mobile station direction)9.3.5.1.2Progress indicator9.3.5.1.3User-user9.3.5.2Connect (mobile station to network direction)9.3.5.2.1Facility9.3.5.2Sversion9.3.5.3Sversion9.3.5.4Gonnect (mobile station to network direction)9.3.5.1.3User-user9.3.5.2Connect (mobile station to network direction)9.3.5.2.3SS version9.3.5.3Sy ersion9.3.5.3So for net is a construction in the isometal in th	
9.3.2.2Bearer capability 1 and bearer capability 29.3.2.3Cause9.3.2.4CC Capabilities9.3.3Call proceeding9.3.3.1Repeat indicator9.3.3.2Bearer capability 1 and bearer capability 29.3.3.3Facility9.3.3.4Progress Indicator9.3.3.5Priority granted9.3.4Congestion control9.3.5Connect9.3.5.1Connect (network to mobile station direction)9.3.5.1.2Progress indicator9.3.5.3User-user9.3.5.4Connect (mobile station to network direction)9.3.5.2Connect (mobile station to network direction)9.3.5.2.1Facility9.3.5.2Sy version9.3.5.3Sy version9.3.5.4Gonnect (mobile station to network direction)9.3.5.2.3SS version9.3.5.3Sy version9.3.5.4Connect (mobile station to network direction)9.3.5.2.3SS version9.3.5Si version9.3.5Si version9.3.5Sy version9.3.5Si version9.3.5Si version9.3.5Si version9.3.6Connect (acknowledge9.3.7Disconnect	
9.3.2.3Cause9.3.2.4CC Capabilities9.3.3Call proceeding9.3.3.1Repeat indicator9.3.3.2Bearer capability 1 and bearer capability 29.3.3.3Facility9.3.3.4Progress Indicator9.3.5.5Priority granted9.3.4Congestion control9.3.5Connect9.3.5.1Connect (network to mobile station direction)9.3.5.1.2Progress indicator9.3.5.3User-user9.3.5.4Connect (mobile station to network direction)9.3.5.1.3User-user9.3.5.4Connect (mobile station to network direction)9.3.5.2.1Facility9.3.5.2Sy version9.3.5.2.3SS version9.3.5Sy version9.3.5Si version9.3.5Sy version9.3.5Sy version9.3.5Sy version9.3.5Sy version9.3.5Sy version9.3.5Sy version9.3.5Sy version9.3.6Connect	
9.3.3Call proceeding9.3.3.1Repeat indicator9.3.3.2Bearer capability 1 and bearer capability 29.3.3.3Facility9.3.3.4Progress Indicator9.3.3.5Priority granted9.3.4Congestion control9.3.5Connect (network to mobile station direction)9.3.5.1Connect (network to mobile station direction)9.3.5.2Connect (mobile station to network direction)9.3.5.2Connect (mobile station to network direction)9.3.5.2System9.3.5.2Connect (mobile station to network direction)9.3.5.2System9.3.5.2System9.3.5.2Connect (mobile station to network direction)9.3.5.2System9.3.5.2System9.3.5.3System9.3.5.4System9.3.5.5Connect (mobile station to network direction)9.3.5.2System9.3.5.3System9.3.5.4System9.3.5.5System9.3.5.7Disconnect	
9.3.3.1Repeat indicator9.3.3.2Bearer capability 1 and bearer capability 29.3.3.3Facility9.3.3.4Progress Indicator9.3.5Priority granted9.3.4Congestion control9.3.5Connect9.3.5Connect (network to mobile station direction)9.3.5.1.1Facility9.3.5.1.2Progress indicator9.3.5.1.3User-user9.3.5.2Connect (mobile station to network direction)9.3.5.2S9.3.5.2S9.3.5.2S9.3.5.2S9.3.5.2S9.3.5.2S9.3.5.2S9.3.5.3S9.3.5.4S9.3.5.5.3S9.3.5.49.3.5.4S9.3.5.5S9.3.5.7S9.3.5.7S9.3.5.7S9.3.5.7S9.3.5.7S9.3.5.7S9.3.5.7S9.3.5.7S9.3.5.7S9.3.5.7S9.3.6S9.3.7Disconnect	317
9.3.3.2Bearer capability 1 and bearer capability 29.3.3.3Facility9.3.3.4Progress Indicator9.3.3.5Priority granted9.3.4Congestion control9.3.4.1Cause9.3.5Connect9.3.5.1Connect (network to mobile station direction)9.3.5.1.2Progress indicator9.3.5.1.3User-user9.3.5.2Connect (mobile station to network direction)9.3.5.2S version9.3.5.3S version9.3.5.4S version9.3.5.5Onnect (mobile station to network direction)9.3.5.2S version9.3.5.3S version9.3.5.4S version9.3.5.7S version9.3.5.7S version9.3.5.7Disconnect	317
9.3.3.3Facility9.3.3.4Progress Indicator9.3.3.5Priority granted9.3.4Congestion control9.3.4.1Cause9.3.5Connect9.3.5.1Connect (network to mobile station direction)9.3.5.1.2Progress indicator9.3.5.1.3User-user9.3.5.2Connect (mobile station to network direction)9.3.5.2.1Facility9.3.5.2.2User-user9.3.5.3S version9.3.5.4Facility9.3.5.5Onnect (mobile station to network direction)9.3.5.2.1Facility9.3.5.2.3SS version9.3.5.3S version9.3.5.3Disconnect	
9.3.3.4Progress Indicator9.3.3.5Priority granted9.3.4Congestion control9.3.4Cause9.3.5Connect9.3.5.1Connect (network to mobile station direction)9.3.5.1.2Progress indicator9.3.5.1.3User-user9.3.5.2Connect (mobile station to network direction)9.3.5.2.1Facility9.3.5.2.3SS version9.3.5.3User-user9.3.5.4Oracle acknowledge9.3.5.7Disconnect	
9.3.3.5       Priority granted         9.3.4       Congestion control         9.3.4.1       Cause         9.3.5       Connect         9.3.5.1       Connect (network to mobile station direction)         9.3.5.1.1       Facility         9.3.5.1.2       Progress indicator         9.3.5.1.3       User-user         9.3.5.2       Connect (mobile station to network direction)         9.3.5.2.1       Facility         9.3.5.2       Connect (mobile station to network direction)         9.3.5.2.1       Facility         9.3.5.2.2       User-user         9.3.5.2.3       SS version         9.3.5.2.3       SS version         9.3.6       Connect acknowledge         9.3.7       Disconnect	
9.3.4Congestion control.9.3.4.1Cause.9.3.5Connect.9.3.5.1Connect (network to mobile station direction).9.3.5.1.1Facility.9.3.5.1.2Progress indicator	
9.3.4.1Cause	
9.3.5Connect9.3.5.1Connect (network to mobile station direction)9.3.5.1.1Facility9.3.5.1.2Progress indicator9.3.5.1.3User-user9.3.5.2Connect (mobile station to network direction)9.3.5.2.1Facility9.3.5.2.2User-user9.3.5.2.3SS version9.3.5.2.3SS version9.3.5.2.3Disconnect	
9.3.5.1Connect (network to mobile station direction).9.3.5.1.1Facility9.3.5.1.2Progress indicator9.3.5.1.3User-user9.3.5.2Connect (mobile station to network direction).9.3.5.2.1Facility9.3.5.2.2User-user9.3.5.2.3SS version.9.3.5.2.3SS version.9.3.6Connect acknowledge9.3.7Disconnect	
9.3.5.1.1       Facility	
9.3.5.1.2       Progress indicator         9.3.5.1.3       User-user         9.3.5.2       Connect (mobile station to network direction)         9.3.5.2.1       Facility         9.3.5.2.2       User-user         9.3.5.2.3       SS version         9.3.6       Connect acknowledge         9.3.7       Disconnect	
9.3.5.1.3       User-user         9.3.5.2       Connect (mobile station to network direction)         9.3.5.2.1       Facility         9.3.5.2.2       User-user         9.3.5.2.3       SS version         9.3.6       Connect acknowledge         9.3.7       Disconnect	
9.3.5.2Connect (mobile station to network direction)9.3.5.2.1Facility9.3.5.2.2User-user9.3.5.2.3SS version9.3.6Connect acknowledge9.3.7Disconnect	
9.3.5.2.1       Facility	
9.3.5.2.2         User-user           9.3.5.2.3         SS version           9.3.6         Connect acknowledge           9.3.7         Disconnect	
9.3.6     Connect acknowledge       9.3.7     Disconnect	
9.3.7 Disconnect	320
9371 Disconnect (network to mobile station direction)	
9.3.7.1.1 Facility	
9.3.7.1.2 Progress indicator	
9.3.7.1.3 User-user	
9.3.7.1.4 Allowed actions \$(CCBS)\$	
9.3.7.2 Disconnect (mobile station to network direction)	
9.3.7.2.1         Facility	
9.3.7.2.3 SS version	
9.3.8 Emergency setup	
9.3.8.1 Bearer capability	
9.3.9 Facility	
9.3.9.1 Facility (network to mobile station direction)	
9.3.9.2 Facility (mobile station to network direction)	
9.3.9.2.1 SS version	324
9.3.10 Hold	324
9.3.11 Hold Acknowledge	
9.3.12 Hold Reject	
9.3.13 Modify	
9.3.13.1 Low layer compatibility	
9.3.13.2 High layer compatibility	
9.3.13.3 Reverse call setup direction.	
9.3.14 Modify complete	
9.3.14.1     Low layer compatibility       9.3.14.2     High layer compatibility	
9.3.14.2High layer compatibility9.3.14.3Reverse call setup direction	
9.3.15 Modify reject	
9.3.15.1 Low layer compatibility	
9.3.15.2 High layer compatibility	
9.3.16 Notify	
9.3.17 Progress	
9.3.17.1 User-user	
9.3.17a CC-Establishment \$(CCBS)\$	
9.3.17a.2 Setup container	
9.3.17b CC-Establishment confirmed \$(CCBS)\$	
9.3.17b.1 Repeat indicator	
9.3.17b.2 Bearer capability 1 and bearer capability 2	330

9.3.17b.9	Cause	
9.3.18	Release	
9.3.18.1	Release (network to mobile station direction)	
9.3.18.1.1	Cause	
9.3.18.1.2	Second cause	
9.3.18.1.3	Facility	
9.3.18.1.4	User-user	
9.3.18.2	Release (mobile station to network direction)	
9.3.18.2.1	Cause	
9.3.18.2.2	Second cause	
9.3.18.2.3	Facility	
9.3.18.2.4	User-user	
9.3.18.2.5	SS version	
9.3.18a	Recall \$(CCBS)\$	
9.3.18a.1	Recall Type	
9.3.18a.2	Facility	
9.3.19	Release complete	
9.3.19.1	Release complete (network to mobile station direction)	
9.3.19.1.1	Cause	
9.3.19.1.2	Facility	
9.3.19.1.3 9.3.19.2	User-user Release complete (mobile station to network direction)	
9.3.19.2 9.3.19.2.1	Cause	
9.3.19.2.1	Facility	
9.3.19.2.2	User-user	
9.3.19.2.3	SS version	
9.3.20	Retrieve	
9.3.20	Retrieve Acknowledge	
9.3.22	Retrieve Reject	
9.3.23	Setup	
9.3.23.1	Setup (mobile terminated call establishment)	
9.3.23.1.1	BC repeat indicator	
9.3.23.1.2	Bearer capability 1 and bearer capability 2	
9.3.23.1.3	Facility	
9.3.23.1.4	Progress indicator	
9.3.23.1.4a	Called party BCD number	
9.3.23.1.5	Called party subaddress	
9.3.23.1.6	LLC repeat indicator	
9.3.23.1.7	Low layer compatibility I	
9.3.23.1.8	Low layer compatibility II	
9.3.23.1.9	HLC repeat indicator	
9.3.23.1.10	High layer compatibility i	
9.3.23.1.11	High layer compatibility ii	
9.3.23.1.12	User-user	
9.3.23.1.13	Redirecting party BCD number	
9.3.23.1.14	Redirecting party subaddress	
9.3.23.1.15	Priority	
9.3.23.1.16	Alert \$(Network Indication of Alerting in the MS )\$	
9.3.23.2	Setup (mobile originating call establishment)	
9.3.23.2.1	BC repeat indicator	
9.3.23.2.2	Facility	
9.3.23.2.3	LLC repeat indicator	
9.3.23.2.4	Low layer compatibility I	
9.3.23.2.5	Low layer compatibility II	
9.3.23.2.6	HLC repeat indicator	
9.3.23.2.7	High layer compatibility i	
9.3.23.2.8	High layer compatibility ii	
9.3.23.2.9	User-user	
9.3.23.2.10	SS version	
9.3.23.2.11	CLIR suppression	
9.3.23.2.12	CLIR invocation	
9.3.23.2.13	CC Capabilities	

9.3.23aStart CC \$(CCBS)\$9.3.23a.1CC Capabilities9.3.24Start DTMF9.3.25Start DTMF Acknowledge9.3.26Start DTMF reject9.3.27Status9.3.28Status enquiry9.3.29Stop DTMF9.3.30Stop DTMF acknowledge9.3.31User information9.3.31.2More data9.4GPRS Mobility Management Messages	.342 .343 .343 .343 .343 .343 .343 .343
9.3.24Start DTMF9.3.25Start DTMF Acknowledge9.3.25.1Keypad facility9.3.26Start DTMF reject9.3.27Status9.3.27Status9.3.28Status enquiry9.3.29Stop DTMF9.3.30Stop DTMF acknowledge9.3.31User information9.3.31.2More data9.4GPRS Mobility Management Messages9.4.1Attach request	.342 .343 .343 .343 .343 .344 .344 .344
9.3.25.1Keypad facility9.3.26Start DTMF reject9.3.27Status9.3.27.1Auxiliary states9.3.28Status enquiry9.3.29Stop DTMF9.3.30Stop DTMF acknowledge9.3.31User information9.3.31.1User-user9.3.31.2More data9.4GPRS Mobility Management Messages9.4.1Attach request	.343 .343 .343 .344 .344 .344 .344 .345 .345
9.3.26Start DTMF reject.9.3.27Status9.3.27.1Auxiliary states9.3.28Status enquiry9.3.29Stop DTMF.9.3.30Stop DTMF acknowledge9.3.31User information9.3.31.1User-user9.3.31.2More data9.4GPRS Mobility Management Messages9.4.1Attach request	.343 .343 .344 .344 .344 .345 .345 .345
9.3.27Status9.3.27.1Auxiliary states9.3.28Status enquiry9.3.29Stop DTMF9.3.30Stop DTMF acknowledge9.3.31User information9.3.31.1User-user9.3.31.2More data9.4GPRS Mobility Management Messages9.4.1Attach request	.343 .344 .344 .344 .345 .345 .345 .346 .346 .346 .346 .346 .346 .346 .347 .347 .347
9.3.27.1Auxiliary states9.3.28Status enquiry9.3.29Stop DTMF9.3.30Stop DTMF acknowledge9.3.31User information9.3.31.1User-user9.3.31.2More data9.4GPRS Mobility Management Messages9.4.1Attach request	.344 .344 .345 .345 .345 .346 .346 .346 .346 .346 .346 .346 .347 .347 .347
9.3.28Status enquiry9.3.29Stop DTMF9.3.30Stop DTMF acknowledge9.3.31User information9.3.31.1User-user9.3.31.2More data9.4GPRS Mobility Management Messages9.4.1Attach request	.344 .344 .345 .345 .346 .346 .346 .346 .346 .346 .346 .347 .347 .347
9.3.29Stop DTMF9.3.30Stop DTMF acknowledge9.3.31User information9.3.31.1User-user9.3.31.2More data9.4GPRS Mobility Management Messages9.4.1Attach request	.344 .345 .345 .346 .346 .346 .346 .346 .346 .346 .347 .347 .347
9.3.30Stop DTMF acknowledge9.3.31User information9.3.31.1User-user9.3.31.2More data9.4GPRS Mobility Management Messages9.4.1Attach request	.345 .345 .346 .346 .346 .346 .346 .346 .346 .347 .347 .347 .347
9.3.31User information9.3.31.1User-user9.3.31.2More data9.4GPRS Mobility Management Messages9.4.1Attach request	.345 .346 .346 .346 .346 .346 .346 .346 .347 .347 .347
9.3.31.1User-user9.3.31.2More data9.4GPRS Mobility Management Messages9.4.1Attach request	.346 .346 .346 .346 .346 .346 .347 .347 .347 .347
9.3.31.2     More data       9.4     GPRS Mobility Management Messages       9.4.1     Attach request	.346 .346 .346 .346 .346 .347 .347 .347 .347
<ul> <li>9.4 GPRS Mobility Management Messages</li> <li>9.4.1 Attach request</li> </ul>	.346 .346 .346 .346 .347 .347 .347 .347
9.4.1 Attach request	.346 .346 .347 .347 .347 .347 .347
	.346 .346 .347 .347 .347 .347
	.346 .347 .347 .347 .347
9.4.1.1 Old P-TMSI signature 9.4.1.2 Requested READY timer value	.347 .347 .347 .347
9.4.1.2     Requested READY timer value       9.4.1.3     TMSI status	.347 .347 .347
9.4.1.5 TMSI status 9.4.2 Attach accept	.347 .347
9.4.2 Attach accept	.347
9.4.2.1 P-TWSI signature 9.4.2.2 Negotiated READY timer	
9.4.2.3 Allocated P-TMSI	3/17
9.4.2.4 MS identity	
9.4.2.5 GMM cause	
9.4.3 Attach complete	
9.4.4 Attach reject	
9.4.5 Detach request	
9.4.5.1 Detach request (mobile terminated detach)	
9.4.5.1.1 GMM cause	
9.4.5.2 Detach request (mobile originating detach)	
9.4.6 Detach accept	
9.4.6.1 Detach accept (mobile terminated detach)	.349
9.4.6.2 Detach accept (mobile originating detach)	
9.4.7 P-TMSI reallocation command	
9.4.7.1 P-TMSI signature	
9.4.8 P-TMSI reallocation complete	
9.4.9 Authentication and ciphering request	
9.4.9.1 Authentication Parameter RAND	
9.4.9.2 GPRS ciphering key sequence number	
9.4.10 Authentication and ciphering response	
9.4.10.1 Authentication Parameter SRES	
9.4.10.2 IMEISV 9.4.11 Authentication and ciphering reject	
9.4.11       Authentication and ciphering reject         9.4.12       Identity request	
9.4.12     Identity request       9.4.13     Identity response	
9.4.14 Routing area update request	
9.4.14.1 Old P-TMSI signature	
9.4.14.2 Requested READY timer value	
9.4.14.3 DRX parameter	
9.4.14.4 TMSI status	
9.4.14.5 MS network capability	
9.4.15 Routing area update accept	
9.4.15.1 P-TMSI signature	
9.4.15.2 Allocated P-TMSI	
9.4.15.3 MS identity	
9.4.15.4 List of Receive N-PDU Numbers	
9.4.15.5 Negotiated READY timer value	
9.4.15.6 GMM cause	
9.4.16 Routing area update complete	
9.4.16.1 List of Receive N-PDU Numbers	
9.4.17 Routing area update reject	.356

9.4.18	GMM Status	
9.4.19	GMM Information	
9.4.19.1	Full name for network	
9.4.19.2	Short name for network	
9.4.19.3	Network time zone	
9.4.19.4	Universal time and time zone	
9.4.19.5	LSA Identity	
9.5	GPRS Session Management Messages	
9.5.1	Activate PDP context request	
9.5.1.1	Access point name	
9.5.1.2	Protocol configuration options	
9.5.2	Activate PDP context accept	
9.5.2.1	PDP address	
9.5.2.2	Protocol configuration options	
9.5.3	Activate PDP context reject	
9.5.3.1	Protocol configuration options	
9.5.4	Request PDP context activation	
9.5.5	Request PDP context activation reject	
9.5.6	Modify PDP context request	
9.5.7	Modify PDP context accept	
9.5.8	Deactivate PDP context request	
9.5.9	Deactivate PDP context accept	
9.5.10	Activate AA PDP context request	
9.5.10.1	Access point name	
9.5.10.2	Protocol configuration options	
9.5.10.3	Requested AA-READY timer value	
9.5.11	Activate AA PDP context accept	
9.5.11.1	Protocol configuration options	
9.5.11.2	Negotiated AA-Ready timer value	
9.5.12	Activate AA PDP context reject	
9.5.12.1	Protocol configuration options	
9.5.13	Deactivate AA PDP context request	
9.5.14	Deactivate AA PDP context accept	
9.5.14 9.5.15	Deactivate AA PDP context accept SM Status	
9.5.14 9.5.15 10 Ge	Deactivate AA PDP context accept SM Status eneral message format and information elements coding	
9.5.14 9.5.15 10 Ge 10.1	Deactivate AA PDP context accept SM Status eneral message format and information elements coding Overview	
9.5.14 9.5.15 10 Ge 10.1 10.2	Deactivate AA PDP context accept SM Status eneral message format and information elements coding Overview Protocol Discriminator	
9.5.14 9.5.15 10 Ge 10.1 10.2 10.3	Deactivate AA PDP context accept	
9.5.14 9.5.15 10 Ge 10.1 10.2	Deactivate AA PDP context accept	
9.5.14 9.5.15 10 Ge 10.1 10.2 10.3 10.3.1 10.3.2	Deactivate AA PDP context accept	
9.5.14 9.5.15 10 Ge 10.1 10.2 10.3 10.3.1	Deactivate AA PDP context accept	
9.5.14 9.5.15 10 Ge 10.1 10.2 10.3 10.3.1 10.3.2 10.4	Deactivate AA PDP context accept	
9.5.14 9.5.15 10 Ge 10.1 10.2 10.3 10.3.1 10.3.2 10.4 10.5	Deactivate AA PDP context accept	
9.5.14 9.5.15 10 Ge 10.1 10.2 10.3 10.3.1 10.3.2 10.4 10.5 10.5.1	Deactivate AA PDP context accept	
9.5.14 9.5.15 10 Ge 10.1 10.2 10.3 10.3.1 10.3.2 10.4 10.5 10.5.1 10.5.1.1	Deactivate AA PDP context accept	
9.5.14 9.5.15 10 Ge 10.1 10.2 10.3 10.3.1 10.3.2 10.4 10.5 10.5.1 10.5.1.1 10.5.1.2	Deactivate AA PDP context accept	
9.5.14 9.5.15 10 Ge 10.1 10.2 10.3 10.3.1 10.3.2 10.4 10.5 10.5.1 10.5.1.1 10.5.1.2 10.5.1.3	Deactivate AA PDP context accept	
9.5.14 9.5.15 10 Ge 10.1 10.2 10.3 10.3.1 10.3.2 10.4 10.5 10.5.1 10.5.1.1 10.5.1.2 10.5.1.3 10.5.1.4	Deactivate AA PDP context accept	
9.5.14 9.5.15 10 Ge 10.1 10.2 10.3 10.3.1 10.3.2 10.4 10.5 10.5.1 10.5.1.1 10.5.1.2 10.5.1.3 10.5.1.4 10.5.1.5	Deactivate AA PDP context accept	
9.5.14 9.5.15 10 Ge 10.1 10.2 10.3 10.3.1 10.3.2 10.4 10.5 10.5.1 10.5.1.1 10.5.1.2 10.5.1.3 10.5.1.4 10.5.1.5 10.5.1.6	Deactivate AA PDP context accept	
9.5.14 9.5.15 10 Ge 10.1 10.2 10.3 10.3.1 10.3.2 10.4 10.5 10.5.1 10.5.1.1 10.5.1.2 10.5.1.3 10.5.1.4 10.5.1.5 10.5.1.6 10.5.1.7	Deactivate AA PDP context accept	
9.5.14 9.5.15 10 Ge 10.1 10.2 10.3 10.3.1 10.3.2 10.4 10.5 10.5.1 10.5.1.1 10.5.1.2 10.5.1.3 10.5.1.4 10.5.1.5 10.5.1.6 10.5.1.7 10.5.1.8	Deactivate AA PDP context accept	
9.5.14 9.5.15 10 Ge 10.1 10.2 10.3 10.3.1 10.3.2 10.4 10.5 10.5.1 10.5.1.1 10.5.1.2 10.5.1.3 10.5.1.4 10.5.1.5 10.5.1.6 10.5.1.7 10.5.1.8 10.5.1.9	Deactivate AA PDP context accept SM Status	
9.5.14 9.5.15 10 Ge 10.1 10.2 10.3 10.3.1 10.3.2 10.4 10.5 10.5.1 10.5.1.1 10.5.1.2 10.5.1.3 10.5.1.4 10.5.1.5 10.5.1.6 10.5.1.7 10.5.1.8 10.5.1.9 10.5.1.10 10.5.1.10 10.5.1.11	Deactivate AA PDP context accept	
9.5.14 9.5.15 10 Ge 10.1 10.2 10.3 10.3.1 10.3.2 10.4 10.5 10.5.1 10.5.1.1 10.5.1.2 10.5.1.3 10.5.1.4 10.5.1.5 10.5.1.6 10.5.1.7 10.5.1.8 10.5.1.9 10.5.1.10 10.5.1.11 10.5.2	Deactivate AA PDP context accept SM Status	
9.5.14 9.5.15 10 Ge 10.1 10.2 10.3 10.3.1 10.3.2 10.4 10.5 10.5.1 10.5.1.1 10.5.1.2 10.5.1.3 10.5.1.4 10.5.1.5 10.5.1.6 10.5.1.7 10.5.1.8 10.5.1.9 10.5.1.10 10.5.1.10 10.5.1.11 10.5.2 10.5.2.1a	Deactivate AA PDP context accept	
9.5.14 9.5.15 10 Ge 10.1 10.2 10.3 10.3.1 10.3.2 10.4 10.5 10.5.1 10.5.1.1 10.5.1.2 10.5.1.3 10.5.1.4 10.5.1.5 10.5.1.6 10.5.1.7 10.5.1.8 10.5.1.10 10.5.1.10 10.5.1.10 10.5.1.11 10.5.2 10.5.2.1a 10.5.2.1b	Deactivate AA PDP context accept SM Status meral message format and information elements coding. Overview Protocol Discriminator Skip indicator and transaction identifier. Skip indicator Transaction identifier Message Type. Other information elements Common information elements. Cell identity Ciphering Key Sequence Number. Location Area Identification Mobile Identity Mobile Identity Mobile Station Classmark 1 Mobile Station Classmark 2 Mobile Station Classmark 3 Spare Half Octet. Descriptive group or broadcast call reference Group Cipher Key Number. A PD and SAPI \$(CCBS)\$ Priority Level Radio Resource management information elements. BA Range. Cell Channel Description	
9.5.14 9.5.15 10 Ge 10.1 10.2 10.3 10.3.1 10.3.2 10.4 10.5 10.5.1 10.5.1.1 10.5.1.2 10.5.1.3 10.5.1.4 10.5.1.5 10.5.1.6 10.5.1.7 10.5.1.8 10.5.1.10 10.5.1.10 10.5.1.10 10.5.1.10 10.5.2.110 10.5.2.110	Deactivate AA PDP context accept SM Status meral message format and information elements coding. Overview Protocol Discriminator Skip indicator and transaction identifier. Skip indicator Transaction identifier. Message Type. Other information elements Common information elements. Cell identity Ciphering Key Sequence Number. Location Area Identification Mobile Identity. Mobile Station Classmark 1 Mobile Station Classmark 2 Mobile Station Classmark 3 Spare Half Octet. Descriptive group or broadcast call reference. Group Cipher Key Number. A PD and SAPI \$(CCBS)\$ Priority Level. Radio Resource management information elements. Cell Channel Description 1 General description.	
9.5.14 9.5.15 10 Ge 10.1 10.2 10.3 10.3.1 10.3.2 10.4 10.5 10.5.1 10.5.1.1 10.5.1.2 10.5.1.3 10.5.1.4 10.5.1.5 10.5.1.6 10.5.1.7 10.5.1.8 10.5.1.10 10.5.1.10 10.5.1.10 10.5.1.11 10.5.2 10.5.2.1a 10.5.2.1b	Deactivate AA PDP context accept	

10 5 2 1h 4	Dongo 512 format	206
10.5.2.1b.4 10.5.2.1b.5	Range 512 format Range 256 format	
10.5.2.1b.6	Range 128 format	
10.5.2.1b.7	Variable bit map format	
10.5.2.1c	BA List Pref	
10.5.2.2	Cell Description	
10.5.2.3	Cell Options (BCCH)	
10.5.2.3a	Cell Options (SACCH)	
10.5.2.4	Cell Selection Parameters	
10.5.2.4a	MAC Mode and Channel Coding Requested	
10.5.2.5	Channel Description	
10.5.2.5a	Channel Description 2	
10.5.2.6	Channel Mode	
10.5.2.7	Channel Mode 2	
10.5.2.8	Channel Needed	
10.5.2.8a	Channel Request Description	
10.5.2.9	Cipher Mode Setting	
10.5.2.10	Cipher Response	
10.5.2.11	Control Channel Description	
10.5.2.12	Frequency Channel Sequence	
10.5.2.13	Frequency List	
10.5.2.13.1	General description	
10.5.2.13.2	Bit map 0 format	
10.5.2.13.3 10.5.2.13.4	Range 1024 format	
10.5.2.13.4	Range 512 format Range 256 format	
10.5.2.13.6	Range 128 format	
10.5.2.13.7	Variable bit map format	
10.5.2.14	Frequency Short List	
10.5.2.14a	Frequency Short List 2	
10.5.2.14b	Group Channel Description	
10.5.2.14c	GPRS Resumption	
10.5.2.15	Handover Reference	
10.5.2.16	IA Rest Octets	
10.5.2.17	IAR Rest Octets	
10.5.2.18	IAX Rest Octets	
10.5.2.19	L2 Pseudo Length	
10.5.2.20	Measurement Results	
10.5.2.20a 10.5.2.21	GPRS Measurement Results Mobile Allocation	
10.5.2.21 10.5.2.21a	Mobile Time Difference	
10.5.2.21a 10.5.2.21aa	MultiRate configuration	
10.5.2.21aa 10.5.2.21b	Multislot Allocation	
10.5.2.21c	NC mode	
10.5.2.22	Neighbour Cells Description	
10.5.2.22 10.5.2.22a	Neighbour Cells Description 2	
10.5.2.22c	NT/N Rest Octets	
10.5.2.23	P1 Rest Octets	
10.5.2.24	P2 Rest Octets	
10.5.2.25	P3 Rest Octets	
10.5.2.25a	Packet Channel Description	
10.5.2.25b	Dedicated mode or TBF	
10.5.2.25c	RR Packet Uplink Assignment	
10.5.2.25d	RR Packet Downlink Assignment	
10.5.2.26	Page Mode	
10.5.2.26a	Spare	
10.5.2.26b	Spare	
10.5.2.26c	Spare	
10.5.2.26d	Spare	
10.5.2.27 10.5.2.28	NCC Permitted Power Command	
10.5.2.28 10.5.2.28a	Power Command and access type	
10. <i>3</i> .2.20a	rower commune and access type	

10.5.2.29	RACH Control Parameters	465
10.5.2.30	Request Reference	
10.5.2.30	RR Cause	
10.5.2.31	SI 1 Rest Octets	
10.5.2.32	SI 2bis Rest Octets	
10.5.2.33a	SI 2013 Rest Octets	
10.5.2.34	SI 2 Rest Octets	
10.5.2.34	SI 4 Rest Octets	
10.5.2.35a	SI 6 Rest Octets	
10.5.2.36	SI 7 Rest Octets	
10.5.2.37	SI 8 Rest Octets	
10.5.2.37a	SI 9 Rest Octets	
10.5.2.37b	SI 13 Rest Octets	
10.5.2.37c	[Spare]	
10.5.2.37d	[Spare]	
10.5.2.37e	SI 16 Rest Octets	
10.5.2.37f	SI 17 Rest Octets	
10.5.2.38	Starting Time	
10.5.2.39	Synchronization Indication	
10.5.2.40	Timing Advance	
10.5.2.41	Time Difference	
10.5.2.41a	TLLI	
10.5.2.42	TMSI/P-TMSI	
10.5.2.42a	VGCS target mode Indication	
10.5.2.43	Wait Indication	
10.5.2.44	SI10 rest octets \$(ASCI)\$	
10.5.2.45	EXTENDED MEASUREMENT RESULTS	
10.5.2.46	Extended Measurement Frequency List	
10.5.2.47	Suspension Cause	
10.5.2.48	APDU ID	
10.5.2.49	APDU Flags	
10.5.2.50	APDU Data	
10.5.3	Mobility management information elements	
10.5.3.1	Authentication parameter RAND	
10.5.3.2	Authentication parameter SRES	
10.5.3.3	CM service type	
10.5.3.4	Identity type	
10.5.3.5	Location updating type	
10.5.3.5a	Network Name	
10.5.3.6	Reject cause	
10.5.3.7	Follow-on Proceed	
10.5.3.8	Time Zone	
10.5.3.9	Time Zone and Time	
10.5.3.10	CTS permission	
10.5.3.11	LSA Identifier	
10.5.4	Call control information elements	
10.5.4.1	Extensions of codesets	
10.5.4.2	Locking shift procedure	
10.5.4.3	Non-locking shift procedure	
10.5.4.4	Auxiliary states	
10.5.4.5	Bearer capability	
10.5.4.5.1	Static conditions for the bearer capability IE contents	
10.5.4.5a	Call Control Capabilities	
10.5.4.6 10.5.4.7	Called party BCD number	
10.5.4.7 10.5.4.8	Called party BCD number	
10.5.4.8 10.5.4.9	Called party subaddress	
10.5.4.9	Calling party BCD number Calling party subaddress	
10.5.4.10	Cause	
10.5.4.11 10.5.4.11a	CLIR suppression	
10.5.4.11a 10.5.4.11b	CLIR suppression	
10.5.4.110	Congestion level	
10.2.1.12		

10.5.4.13	Connected number	520
10.5.4.15	Connected number Connected subaddress	
10.5.4.15	Facility	
10.5.4.16	High layer compatibility	
10.5.4.16.1	Static conditions for the high layer compatibility IE contents	
10.5.4.17	Keypad facility	
10.5.4.18	Low layer compatibility	
10.5.4.19	More data	
10.5.4.20	Notification indicator	
10.5.4.21	Progress indicator	
10.5.4.21a	Recall type \$(CCBS)\$	
10.5.4.21b	Redirecting party BCD number	
10.5.4.21c	Redirecting party subaddress	
10.5.4.22	Repeat indicator	
10.5.4.22a	Reverse call setup direction.	
10.5.4.22b	SETUP Container \$(CCBS)\$	
10.5.4.23	Signal	
10.5.4.24	SS Version Indicator	
10.5.4.25 10.5.4.26	User-user	
10.5.4.20	Alerting Pattern \$(NIA)\$ Allowed actions \$(CCBS)\$	
10.5.4.27	GPRS mobility management information elements	
10.5.5.1	Attach result	
10.5.5.2	Attach type	
10.5.5.3	Ciphering algorithm	
10.5.5.4	[Spare]TMSI status	
10.5.5.5	Detach type	
10.5.5.6	DRX parameter	
10.5.5.7	Force to standby	
10.5.5.8	P-TMSI signature	
10.5.5.9	Identity type 2	
10.5.5.10	IMEISV request	
10.5.5.11	Receive N-PDU Numbers list	
10.5.5.12	MS network capability	
10.5.5.12a	MS Radio Access capability	
10.5.5.13	Spare	
10.5.5.14	GMM cause	
10.5.5.15	Routing area identification	
10.5.5.16 10.5.5.17	Spare	
10.5.5.17	Update type	
10.5.5.19	A&C reference number	
10.5.6	Session management information elements	557
10.5.6.1	Access Point Name	
10.5.6.2	Network service access point identifier	
10.5.6.3	Protocol configuration options	
10.5.6.4	Packet data protocol address	
10.5.6.5	Quality of service	
10.5.6.6	SM cause	
10.5.6.7	Spare	
10.5.6.8	AA deactivation cause	
10.5.6.9	LLC service access point identifier	
10.5.7	GPRS Common information elements	
10.5.7.1	[Spare]	
10.5.7.2	Radio priority	
10.5.7.3	GPRS Timer	
	of system parameters	
	imers and counters for radio resource management	
11.1.1	Timers on the mobile station side	
11.1.2	Timers on the network side	
11.1.3	Other parameters	

11.2 11.2.1 11.2.2	Timer T3240 and Timers of GPRS	nanagement I Timer T3241 mobility management	574 575
11.2.3 11.3		n management itched call control	
Anne	x A (informative):	Example of subaddress information element coding	580
Anne	x B (normative):	Compatibility checking	581
B.1	Introduction		
B.2 B.2.1 B.2.2	Compatibility check	ility checking ing of the CM SERVICE REQUEST message ription checking of the SETUP message	581
B.3 B.3.1 B.3.2 B.3.3	Compatibility check Network-to-MS com	lity checking ing with addressing information patibility checking ibility checking	582 582
B.4	High layer compatibil	ity checking	
Anne	x C (normative):	Low layer information coding principles	
C.1	Purpose		
C.2			
C.2.1		f information	
C.2.2 C.2.3		vork formation	
C.2.3 C.2.4		and III information	
C.2.5		n bearer capability and low layer compatibility information elements	
Anne	x D (informative):	Examples of bearer capability information element coding	585
Anne D.1	Coding for speech for	a full rate support only mobile station	
D.1 D.1.1	Coding for speech for Mobile station to net	a full rate support only mobile station	585 585
D.1	Coding for speech for Mobile station to net	a full rate support only mobile station	585 585
D.1 D.1.1 D.1.2 D.2	Coding for speech for Mobile station to net Network to mobile s An example of a codin	a full rate support only mobile station work direction tation direction ng for modem access with V22-bis, 2,4 kbit/s, 8 bit no parity	585 585 585 
D.1 D.1.1 D.1.2 D.2 D.2.1	Coding for speech for Mobile station to net Network to mobile s An example of a codin Mobile station to net	a full rate support only mobile station work direction tation direction ng for modem access with V22-bis, 2,4 kbit/s, 8 bit no parity work direction, data compression allowed	
D.1 D.1.1 D.1.2 D.2 D.2.1 D.2.2	Coding for speech for Mobile station to net Network to mobile s An example of a codin Mobile station to net Network to mobile s	a full rate support only mobile station	
D.1 D.1.1 D.1.2 D.2 D.2.1 D.2.2 D.3	Coding for speech for Mobile station to net Network to mobile s An example of a codin Mobile station to net Network to mobile s An example of a codin	a full rate support only mobile station	
D.1 D.1.1 D.1.2 D.2 D.2.1 D.2.2 D.3 D.3.1	Coding for speech for Mobile station to net Network to mobile s An example of a codin Mobile station to net Network to mobile s An example of a codin Mobile station to net	a full rate support only mobile station	
D.1 D.1.1 D.1.2 D.2 D.2.1 D.2.2 D.3 D.3.1 D.3.2	Coding for speech for Mobile station to net Network to mobile s An example of a codin Mobile station to net Network to mobile s An example of a codin Mobile station to net Network to mobile s	a full rate support only mobile station	
D.1 D.1.1 D.1.2 D.2 D.2.1 D.2.2 D.3 D.3.1 D.3.2	Coding for speech for Mobile station to net Network to mobile s An example of a codin Mobile station to net Network to mobile s An example of a codin Mobile station to net	a full rate support only mobile station	
D.1 D.1.1 D.1.2 D.2 D.2.1 D.2.2 D.3 D.3.1 D.3.2 <b>Anne</b>	Coding for speech for Mobile station to net Network to mobile s An example of a codin Mobile station to net Network to mobile s An example of a codin Mobile station to net Network to mobile s	a full rate support only mobile station	
D.1 D.1.1 D.1.2 D.2 D.2.1 D.2.2 D.3 D.3.1 D.3.2 <b>Anne</b>	Coding for speech for Mobile station to net Network to mobile s An example of a codin Mobile station to net Network to mobile s An example of a codin Mobile station to net Network to mobile s <b>x E (informative):</b>	a full rate support only mobile station	
D.1 D.1.1 D.1.2 D.2 D.2.1 D.2.2 D.3 D.3.1 D.3.2 <b>Anne</b>	Coding for speech for Mobile station to net Network to mobile s An example of a codin Mobile station to net Network to mobile s An example of a codin Mobile station to net Network to mobile s <b>x E (informative):</b> <b>x F (informative):</b> <b>x G (informative):</b>	a full rate support only mobile station	
D.1 D.1.1 D.1.2 D.2 D.2.1 D.2.2 D.3 D.3.1 D.3.2 Anne Anne	Coding for speech for Mobile station to net Network to mobile s An example of a codin Mobile station to net Network to mobile s An example of a codin Mobile station to net Network to mobile s <b>x E (informative):</b> <b>x F (informative):</b> <b>x G (informative):</b> Causes related to MS	a full rate support only mobile station	
D.1 D.1.1 D.2 D.2.1 D.2.2 D.3 D.3.1 D.3.2 Anne G.1	Coding for speech for Mobile station to net Network to mobile s An example of a codin Mobile station to net Network to mobile s An example of a codin Mobile station to net Network to mobile s <b>x E (informative):</b> <b>x F (informative):</b> <b>x G (informative):</b> Causes related to MS Cause related to subsc	a full rate support only mobile station	
D.1 D.1.1 D.2 D.2.1 D.2.2 D.3 D.3.1 D.3.2 Anne G.1 G.2	Coding for speech for Mobile station to net Network to mobile s An example of a codin Mobile station to net Network to mobile s An example of a codin Mobile station to net Network to mobile s <b>x E (informative):</b> <b>x F (informative):</b> <b>x G (informative):</b> Causes related to MS Causes related to PLM	a full rate support only mobile station	
D.1 D.1.1 D.2 D.2.1 D.2.2 D.3 D.3.1 D.3.2 Anne G.1 G.2 G.3	Coding for speech for Mobile station to net Network to mobile s An example of a codin Mobile station to net Network to mobile s An example of a codin Mobile station to net Network to mobile s <b>x E (informative):</b> <b>x F (informative):</b> <b>x G (informative):</b> Causes related to MS Causes related to pLM Causes related to natu	a full rate support only mobile station	
D.1 D.1.1 D.2 D.2.1 D.2.2 D.3 D.3.1 D.3.2 <b>Anne</b> G.1 G.2 G.3 G.4	Coding for speech for Mobile station to net Network to mobile s An example of a codin Mobile station to net Network to mobile s An example of a codin Mobile station to net Network to mobile s <b>x E (informative):</b> <b>x F (informative):</b> <b>x G (informative):</b> Causes related to MS Causes related to subsc Causes related to PLM Causes related to natu Causes related to inva	a full rate support only mobile station	

H.1	Normal class	
H.1.1	Cause No. 1 "unassigned (unallocated) number"	599
H.1.2	Cause No. 3 "no route to destination"	599
H.1.3	Cause No. 6 "channel unacceptable"	599
H.1.4	Cause No. 8 "operator determined barring"	
H.1.5	Cause No.16 "normal call clearing"	
H.1.6	Cause No.17 "user busy"	
H.1.7	Cause No. 18 "no user responding"	
H.1.8	Cause No. 19 "user alerting, no answer"	
H.1.9	Cause No. 21 "call rejected"	
H.1.10	$\partial$	
H.1.11		600
H.1.12	$\partial \theta$	
H.1.13		
H.1.14	$\mathbf{I}$	
H.1.15		600
H.1.16	6 Cause No. 30 "response to STATUS ENQUIRY"	600
H.1.17	7 Cause No. 31 "normal, unspecified"	600
H.2	Resource unavailable class	600
H.2.1	Cause No. 34 "no circuit/channel available"	
H.2.2	Cause No. 38 "network out of order"	
H.2.3	Cause No. 41 "temporary failure"	
H.2.4	Cause No. 42 "switching equipment congestion"	
H.2.5	Cause No. 43 "access information discarded"	
H.2.6	Cause No. 44 "requested circuit/channel not available"	
H.2.7	Cause No. 47 "resource unavailable, unspecified"	
H.3	Service or option not available class	
H.3.1	Cause No. 49 "quality of service unavailable"	
H.3.2	Cause No. 50 "Requested facility not subscribed"	
H.3.3	Cause No. 55 "Incoming calls barred within the CUG"	
H.3.4	Cause No. 57 "bearer capability not authorized"	
H.3.5	Cause No. 58 "bearer capability not presently available"	
H.3.6	Cause No. 63 "service or option not available, unspecified"	
H.3.7	Cause No. 68 "ACM equal to or greater than ACMmax"	602
H.4	Service or option not implemented class	
H.4.1	Cause No. 65 "bearer service not implemented"	
H.4.2	Cause No. 69 "Requested facility not implemented"	
H.4.3	Cause No. 70 "only restricted digital information bearer capability is available"	
H.4.4	Cause No. 79 "service or option not implemented, unspecified"	602
H.5	Invalid message (e.g., parameter out of range) class	602
H.5.1	Cause No. 81 "invalid transaction identifier value"	
H.5.2	Cause No. 87 "user not member of CUG"	
H.5.3	Cause No. 87 "user not member of COO" Cause No. 88 "incompatible destination"	
H.5.4	Cause No. 91 "invalid transit network selection"	
H.5.5	Cause No. 97 "Invalue transfer network selection"	
H.6	Protocol error (e.g., unknown message) class	
H.6.1	Cause No. 96 "invalid mandatory information"	
H.6.2	Cause No. 97 "message type non-existent or not implemented"	
H.6.3	Cause No. 98 "message type not compatible with protocol state"	603
H.6.4	Cause No. 99 "information element non-existent or not implemented"	
H.6.5	Cause No. 100 "conditional IE error"	
H.6.6	Cause No. 101 "message not compatible with protocol state"	
H.6.7	Cause No. 102 "recovery on timer expiry"	604
H.6.8	Cause No. 111 "protocol error, unspecified"	604
H.7	Interworking class	604
H.7.1	Cause No. 127 "interworking, unspecified"	
Anne	ex I (informative): GSM specific cause values for session management	605

I.1	Causes related to natu	re of request	605
I.2	Causes related to inva	lid messages	606
Ann	ex J (informative):	Algorithm to encode frequency list information elements	607
J.1	Introduction		607
J.2	General principle		607
J.3	Performances		609
J.4	Encoding algorithm		610
J.5	Decoding		612
J.6	A detailed example		613
Ann	ex K (informative):	Default Codings of Information Elements	615
<b>K</b> .1	Common information	elements	615
K.2	Radio Resource mana	gement information elements	615
K.3	Mobility management information elements		617
K.4	Call control information	on elements	617
Ann	ex L (informative):	Allocation of responsibilities between STCs	619
Ann	ex M (normative):	Additional Requirements for backward compatibility with PCS 190 for NA revision 0 ME	
Ann	ex N (informative):	Change Record	620
Histo	ory		624

### Foreword

This Technical Specification has been produced by the 3<sup>rd</sup> Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
  - 1 presented to TSG for information;
  - 2 presented to TSG for approval;
  - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

### Introduction

The present document includes references to features which are not part of the Phase 2+ Release 96 of the GSM Technical specifications. All sub-clauses which were changed as a result of these features contain a marker (see table below) relevant to the particular feature.

The following table lists all features that were introduced after Release 1996.

Feature	Designator
BA Range IE handling	\$(impr-BA-range-handling)\$
Advanced Speech Call Item	\$(ASCI)\$
Call Completion Busy Subscriber	\$(CCBS)\$
Mobile Assisted Frequency Allocation	\$(MAFA)\$
Network Indication of Alerting in MS	\$(NIA)\$

### 0 Scope

The present document specifies the procedures used at the radio interface (Reference Point Um, see 3GPP TS 04.02) for Call Control (CC), Mobility Management (MM), Radio Resource (RR) management and Session Management (SM).

When the notations for "further study" or "FS" or "FFS" are present in the present document they mean that the indicated text is not a normative portion of the present document.

These procedures are defined in terms of messages exchanged over the control channels of the radio interface. The control channels are described in 3GPP TS 04.03.

The structured functions and procedures of this protocol and the relationship with other layers and entities are described in general terms in 3GPP TS 04.07.

### 0.1 Scope of the Technical Specification

The procedures currently described in the present document are for the call control of circuit-switched connections, session management for GPRS services, mobility management and radio resource management for circuit-switched and GPRS services.

3GPP TS 04.10 contains functional procedures for support of supplementary services.

3GPP TS 04.11 contains functional procedures for support of point-to-point short message services.

3GPP TS 04.12 contains functional description of short message - cell broadcast.

3GPP TS 04.60 contains procedures for radio link control and medium access control (RLC/MAC) of packet data physical channels.

3GPP TS 04.71 contains functional descriptions and procedures for support of location services.

NOTE: "layer 3" includes the functions and protocols described in the present document. The terms "data link layer" and "layer 2" are used interchangeably to refer to the layer immediately below layer 3.

### 0.2 Application to the interface structures

The layer 3 procedures apply to the interface structures defined in 3GPP TS 04.03. They use the functions and services provided by layer 2 defined in 3GPP TS 04.05 and 3GPP TS 04.06. 3GPP TS 04.07 gives the general description of layer 3 including procedures, messages format and error handling.

### 0.3 Structure of layer 3 procedures

A building block method is used to describe the layer 3 procedures.

The basic building blocks are "elementary procedures" provided by the protocol control entities of the three sublayers, i.e. radio resource management, mobility management and connection management sublayer.

Complete layer 3 transactions consist of specific sequences of elementary procedures. The term "structured procedure" is used for these sequences.

### 0.4 Test procedures

Test procedures of the GSM radio interface signalling are described in 3GPP TS 11.10 and 3GPP TS 11.2x series.

### 0.5 Use of logical channels

The logical control channels are defined in 3GPP TS 05.02. In the following those control channels are considered which carry signalling information or specific types of user packet information:

- i) Broadcast Control CHannel (BCCH): downlink only, used to broadcast Cell specific information;
- ii) Synchronization CHannel (SCH): downlink only, used to broadcast synchronization and BSS identification information;
- iii) Paging CHannel (PCH): downlink only, used to send page requests to Mobile Stations (MSs);
- iv) Random Access CHannel (RACH): uplink only, used to request a Dedicated Control CHannel;
- v) Access Grant CHannel (AGCH): downlink only, used to allocate a Dedicated Control CHannel;
- vi) Standalone Dedicated Control CHannel (SDCCH): bi-directional;

vii)Fast Associated Control CHannel (FACCH): bi-directional, associated with a Traffic CHannel;

- viii) Slow Associated Control CHannel (SACCH): bi-directional, associated with a SDCCH or a Traffic CHannel;
- ix) Cell Broadcast CHannel (CBCH): downlink only used for general (not point to point) short message information.
- x) Notification CHannel (NCH): downlink only, used to notify mobile stations of VBS (Voice Broadcast Service) calls or VGCS (Voice Group Call Service) calls.

Two service access points are defined on signalling layer 2 which are discriminated by their Service Access Point Identifiers (SAPI) (see 3GPP TS 04.06):

- i) SAPI 0: supports the transfer of signalling information including user-user information;
- ii) SAPI 3: supports the transfer of user short messages.

Layer 3 selects the service access point, the logical control channel and the mode of operation of layer 2 (acknowledged, unacknowledged or random access, see 3GPP TS 04.05 and 3GPP TS 04.06) as required for each individual message.

### 0.6 Overview of control procedures

### 0.6.1 List of procedures

The following procedures are specified in the present document:

- a) Clause 3 specifies elementary procedures for Radio Resource management:
  - system information broadcasting (sub-clause 3.2.2);
  - RR connection establishment (sub-clause 3.3):
    - entering the dedicated mode: immediate assignment procedure (sub-clause 3.3.1.1);
    - paging procedure for RR connection establishment (sub-clause 3.3.2);
    - notification procedure (sub-clause 3.3.3);
  - Procedures in dedicated mode and in group transmit mode (sub-clause 3.4):
    - measurement report procedure (sub-clause 3.4.1.2);
    - intracell change of channels (sub-clause 3.4.3);
    - intercell change of channels (sub-clause 3.4.4);
    - frequency redefinition procedure (sub-clause 3.4.5);

- channel mode change procedure (sub-clause 3.4.6);
- ciphering mode setting procedure (sub-clause 3.4.7);
- additional channel assignment procedure (sub-clause 3.4.8);
- partial channel release procedure (sub-clause 3.4.9);
- radio resources connection release (sub-clause 3.4.13);
- specific RR procedures for voice broadcast channels and voice group call channels (sub-clause 3.4.15);
- application procedures (sub-clause 3.4.21);
- RR procedures on CCCH related to temporary block flow establishment (sub-clause 3.5):
  - packet paging procedure using CCCH (sub-clause 3.5.1);
  - packet access procedure using CCCH (sub-clause 3.5.2);
- packet downlink assignment procedure using CCCH (sub-clause 3.5.3);
- RR procedures on DCCH related to temporary block flow establishment:
  - Assignment to Packet Data Channel procedure (sub-clause 3.4.19);
  - Network commanded cell reselection (sub-clause 3.4.20).
- b) Clause 4 specifies elementary procedures for Mobility Management:
  - mobility management common procedures (sub-clause 4.3):
    - TMSI reallocation procedure (sub-clause 4.3.1);
    - authentication procedure (sub-clause 4.3.2);
    - identification procedure (sub-clause 4.3.3);
    - IMSI detach procedure (sub-clause 4.3.4);
    - abort procedure (sub-clause 4.3.5);
    - MM information procedure (sub-clause 4.3.6);
  - mobility management specific procedures (sub-clause 4.4):
    - location updating procedure (sub-clause 4.4.1);
    - periodic updating (sub-clause 4.4.2);
    - IMSI attach procedure (sub-clause 4.4.3);
    - generic location updating procedure (sub-clause 4.4);
  - connection management sublayer service provision:
    - mobility management connection establishment (sub-clause 4.5.1);
    - mobility management connection information transfer phase (sub-clause 4.5.2);
    - mobility management connection release (sub-clause 4.5.3);
  - GPRS specific mobility management procedures (sub-clause 4.7):
    - GPRS attach procedure (sub-clause 4.7.3);
    - GPRS detach procedure (sub-clause 4.7.4);
    - GPRS routing area updating procedure (sub-clause 4.7.5);

- GPRS common mobility management procedures (sub-clause 4.7):
  - GPRS P-TMSI reallocation procedure (sub-clause 4.7.6);
  - GPRS authentication and ciphering procedure (sub-clause 4.7.7);
  - GPRS identification procedure (sub-clause 4.7.8);
  - GPRS information procedure (sub-clause 4.7.12).
- c) Clause 5 specifies elementary procedures for circuit switched Call Control comprising the following elementary procedures:
  - mobile originating call establishment (sub-clause 5.2.1);
  - mobile terminating call establishment (sub-clause 5.2.2);
  - signalling procedures during the active state (sub-clause 5.3):
    - user notification procedure (sub-clause 5.3.1);
    - call rearrangements (sub-clause 5.3.2);
    - DTMF protocol control procedure (sub-clause 5.5.7);
    - in-call modification (sub-clause 5.3.4);
  - call clearing initiated by the mobile station (sub-clause 5.4.3);
  - call clearing initiated by the network (sub-clause 5.4.4);
  - miscellaneous procedures:
    - in-band tones and announcements (sub-clause 5.5.1);
    - status enquiry procedure (sub-clause 5.5.3);
    - call re-establishment procedure (sub-clause 5.5.4).
- d) Clause 6 specifies elementary procedures for session management:
  - GPRS session management procedures (sub-clause 6.1):
    - PDP context activation (sub-clause 6.1.1);
    - PDP context modification (sub-clause 6.1.2);
    - PDP context deactivation (sub-clause 6.1.3);
    - anonymous PDP context activation (sub-clause 6.1.4);
    - anonymous PDP context deactivation (sub-clause 6.1.5).

The elementary procedures can be combined to form structured procedures. Examples of such structured procedures are given in clause 7. This part of the Technical Specification is only provided for guidance to assist implementations.

Clause 8 specifies actions to be taken on various error conditions and also provides rules to ensure compatibility with future enhancements of the protocol.

### 0.7 Applicability of implementations

The applicability of procedures of the present document for the mobile station is dependent on the services and functions which are to be supported by a mobile station.

## 0.7.1 Voice Group Call Service (VGCS) and Voice Broadcast Service (VBS)

For mobile stations supporting the Voice Group Call Service or the Voice Broadcast Service, it is explicitly mentioned throughout the present document if a certain procedure is applicable only for such a service and, if necessary, how mobile stations not supporting such a service shall behave.

For VGCS and VBS, the following possible mobile station implementations exist:

- support of listening to voice broadcast calls (VBS listening).
- support of originating a voice broadcast call (VBS originating).
- support of listening to voice group calls (VGCS listening).
- support of talking in voice group calls (VGCS talking. This always includes the implementation for VGCS listening).
- support of originating a voice group call (VGCS originating. This always includes the implementation for VGCS talking).

Apart from the explicitly mentioned combinations, all possible combinations are optional and supported by the present document.

The related terms are used in the present document, if information on these implementation options is required.

### 0.7.2 General Packet Radio Service (GPRS)

For mobile stations supporting the General Packet Radio Service (GPRS), it is explicitly mentioned throughout the technical specification if a certain procedure is applicable only for such a service and, if necessary, how mobile stations not supporting such a service shall behave.

A GPRS MS may operate in one of the following MS operation modes, see 03.60 [74]:

- MS operation mode A;
- MS operation mode B; or
- MS operation mode C.

The MS operation mode depends on the services that the MS is attached to, i.e., only GPRS or both GPRS and non-GPRS services, and upon the MS's capabilities to operate GPRS and other GSM services simultaneously. Mobile stations that are capable to operate GPRS services are referred to as GPRS MSs.

NOTE: Other GSM technical specifications may refer to the MS operation modes A, B, and C as GPRS class-A MS, GPRS class-B MS, and GPRS class-C MS.

It should be noted that it is possible that for a GPRS MS, the GMM procedures currently described in the ETS do not support combinations of VGCS, VBS and GPRS. The possible interactions are not studied yet.

### 1 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the same Release as the present document*.
- [1] 3GPP TS 01.02: "General description of a GSM Public Land Mobile Network (PLMN)".
- [2] 3GPP TS 01.04: "Abbreviations and acronyms".
- [3] 3GPP TS 02.02: "Bearer Services (BS) supported by a GSM Public Land Mobile Network (PLMN)".
- [4] 3GPP TS 02.03: "Teleservices supported by a GSM Public Land Mobile Network (PLMN)".
- [5] 3GPP TS 02.09: "Security aspects".
- [6] 3GPP TS 02.11: "Service accessibility".
- [7] 3GPP TS 02.17: "Subscriber Identity Modules (SIM); Functional characteristics".
- [8] 3GPP TS 02.40: "Procedure for call progress indications".
- [9] 3GPP TS 03.01: "Network functions".
- [10] 3GPP TS 03.03: "Numbering, addressing and identification".
- [11] 3GPP TS 03.13: "Discontinuous Reception (DRX) in the GSM system".
- [12] 3GPP TS 03.14: "Support of Dual Tone Multi-Frequency signalling (DTMF) via the GSM system".
- [12a] 3GPP TS 03.71: "Location Services (LCS); (Functional description) Stage 2".
- [13] 3GPP TS 03.20: "Security related network functions".
- [14] 3GPP TS 03.22: "Functions related to Mobile Station (MS) in idle mode and group receive mode".
- [15] 3GPP TS 04.02: "GSM Public Land Mobile Network (PLMN) access reference configuration".
- [16] 3GPP TS 04.03: "Mobile Station Base Station System (MS BSS) interface; Channel structures and access capabilities".
- [17] 3GPP TS 04.04: "Layer 1; General requirements".
- [18] 3GPP TS 04.05: "Data Link (DL) layer; General aspects".
- [19] 3GPP TS 04.06: "Mobile Station Base Station System (MS BSS) interface; Data Link (DL) layer specification".
- [20] 3GPP TS 04.07: "Mobile radio interface signalling layer 3; General aspects".
- [21] 3GPP TS 04.10: "Mobile radio interface layer 3 Supplementary services specification; General aspects".
- [22] 3GPP TS 04.11: "Point-to-Point (PP) Short Message Service (SMS) support on mobile radio interface".

- [23] 3GPP TS 04.12: "Short Message Service Cell Broadcast (SMSCB) support on the mobile radio interface".
- [23a] 3GPP TS 04.71: "Mobile radio interface layer 3 Location Services (LCS) specification.
- [23b] 3GPP TS 04.31: "Location Services (LCS); Mobile Station (MS) Serving Mobile Location Centre (SMLC) Radio Resource LCS Protocol (RRLP)".
- [24] 3GPP TS 04.80: "Mobile radio interface layer 3 supplementary services specification; Formats and coding".
- [25] 3GPP TS 04.81: "Line identification supplementary services; Stage 3".
- [26] 3GPP TS 04.82: "Call Forwarding (CF) supplementary services; Stage 3".
- [27] 3GPP TS 04.83: "Call Waiting (CW) and Call Hold (HOLD) supplementary services; Stage 3".
- [28] 3GPP TS 04.84: "Multi Party (MPTY) supplementary services; Stage 3".
- [29] 3GPP TS 04.85: "Closed User Group (CUG) supplementary services; Stage 3".
- [30] 3GPP TS 04.86: "Advice of Charge (AoC) supplementary services; Stage 3".
- [31] 3GPP TS 04.88: "Call Barring (CB) supplementary services; Stage 3".
- [32] 3GPP TS 05.02: "Multiplexing and multiple access on the radio path".
- [33] 3GPP TS 05.05: "Radio transmission and reception".
- [34] 3GPP TS 05.08: "Radio subsystem link control".
- [35] 3GPP TS 05.10: "Radio subsystem synchronization".
- [36] 3GPP TS 07.01: "General on Terminal Adaptation Functions (TAF) for Mobile Stations (MS)".
- [37] 3GPP TS 09.02: "Mobile Application Part (MAP) specification".
- [38] 3GPP TS 09.07: "General requirements on interworking between the Public Land Mobile Network (PLMN) and the Integrated Services Digital Network (ISDN) or Public Switched Telephone Network (PSTN)".
- [39] 3GPP TS 11.10: "Mobile Station (MS) conformance specification".
- [40] 3GPP TS 11.21: "Base Station System (BSS) equipment specification; Radio aspects".
- [41] ISO/IEC 646 (1991): "Information technology ISO 7-bit coded character set for information interchange".
- [42] ISO/IEC 6429: "Information technology Control functions for coded character sets".
- [43] ISO 8348 (1987): "Information processing systems Data communications Network service definition".
- [44] ITU-T Recommendation E.163: "Numbering plan for the international telephone service".
- [45] ITU-T Recommendation E.164: "The international public telecommunication numbering plan".
- [46] ITU-T Recommendation E.212: "The international identification plan for mobile terminals and mobile users".
- [47] ITU-T Recommendation F.69 (1993): "Plan for telex destination codes".
- [48] ITU-T Recommendation I.330: "ISDN numbering and addressing principles".
- [49] ITU-T Recommendation I.440 (1989): "ISDN user-network interface data link layer General aspects".
- [50] ITU-T Recommendation I.450 (1989): "ISDN user-network interface layer 3 General aspects".

- [51] ITU-T Recommendation I.500 (1993): "General structure of the ISDN interworking Recommendations".
- [52] ITU-T Recommendation T.50: "International Reference Alphabet (IRA) (Formerly International Alphabet No. 5 or IA5) Information technology 7-bit coded character set for information interchange".
- [53] ITU Recommendation Q.931: "ISDN user-network interface layer 3 specification for basic control".
- [54] ITU-T Recommendation V.21: "300 bits per second duplex modem standardized for use in the general switched telephone network".
- [55] ITU-T Recommendation V.22: "1200 bits per second duplex modem standardized for use in the general switched telephone network and on point-to-point 2-wire leased telephone-type circuits".
- [56] ITU-T Recommendation V.22bis: "2400 bits per second duplex modem using the frequency division technique standardized for use on the general switched telephone network and on point-to-point 2-wire leased telephone-type circuits".
- [57] ITU-T Recommendation V.23: "600/1200-baud modem standardized for use in the general switched telephone network".
- [58] ITU-T Recommendation V.26ter: "2400 bits per second duplex modem using the echo cancellation technique standardized for use on the general switched telephone network and on point-to-point 2-wire leased telephone-type circuits".
- [59] ITU-T Recommendation V.32: "A family of 2-wire, duplex modems operating at data signalling rates of up to 9600 bit/s for use on the general switched telephone network and on leased telephone-type circuits".
- [60] ITU-T Recommendation V.110: "Support by an ISDN of data terminal equipments with V-Series type interfaces".
- [61] ITU-T Recommendation V.120: "Support by an ISDN of data terminal equipment with V-Series type interfaces with provision for statistical multiplexing".
- [62] ITU-T Recommendation X.21: "Interface between Data Terminal Equipment and Data Circuitterminating Equipment for synchronous operation on public data networks".
- [63] ITU-T Recommendation X.25: "Interface between Data Terminal Equipment (DTE) and Data Circuit-terminating Equipment (DCE) for terminals operating in the packet mode and connected to public data networks by dedicated circuit".
- [64] ITU-T Recommendation X.28: "DTE/DCE interface for a start-stop mode Data Terminal Equipment accessing the Packet Assembly/Disassembly facility (PAD) in a public data network situated in the same country".
- [65] ITU-T Recommendation X.30: "Support of X.21, X.21 bis and X.20 bis based Data Terminal Equipments (DTEs) by an Integrated Services Digital Network (ISDN)".
- [66] ITU-T Recommendation X.31: "Support of packet mode terminal equipment by an ISDN".
- [67] ITU-T Recommendation X.32: "Interface between data terminal equipment (DTE) and data circuit-terminating equipment (DCE) for terminals operating in the packet mode and accessing a packet switched public data network through a public switched telephone network or an integrated services digital network or a circuit switched public data network".
- [68] ITU-T Recommendation X.75 (1988): "Packet-switched signalling system between public networks providing data transmission services".
- [69] ITU-T Recommendation X.121: "International numbering plan for public data networks".
- [70] ETS 300 102-1: "Integrated Services Digital Network (ISDN); User-network interface layer 3; Specifications for basic call control".

- [71] ETS 300 102-2: "Integrated Services Digital Network (ISDN); User-network interface layer 3; Specifications for basic call control; Specification Description Language (SDL) diagrams".
- [72] ISO/IEC 10646: "Information technology Universal Multiple-Octet Coded Character Set (UCS) -Part 1: Architecture and Basic Multilingual Plane".
- [73] 3GPP TS 02.60: "General Packet Radio Service (GPRS); Service description; Stage 1".
- [74] 3GPP TS 03.60: "General Packet Radio Service (GPRS); Service description; Stage 2".
- [75] 3GPP TS 03.64: "General Packet Radio Service (GPRS); Overall description of the GPRS radio interface; Stage 2".
- [76] 3GPP TS 04.60: "General Packet Radio Service (GPRS); Mobile Station (MS) Base Station System (BSS) interface; Radio Link Control/Medium Access Control (RLC/MAC) protocol".
- [77] IETF RFC 1034: "Domain names Concepts and Facilities".
- [78] 3GPP TS 04.65: "General Packet Radio Service (GPRS); Mobile Station (MS) Serving GPRS Support Node (SGSN); Subnetwork Dependent Convergence Protocol (SNDCP)".
- 2 Definitions and abbreviations

Abbreviations used in the present document are listed in 3GPP TS 01.04.

### 2.1 Random values

In a number of places in the present document, it is mentioned that some value must take a "random" value, in a given range, or more generally with some statistical distribution. Such cases interest only the Mobile Station.

It is required that there is a low probability that two MSs in the same conditions (including the case of two MSs of the same type from the same manufacturer) will choose the same value. Moreover, it is required that, if it happens that two MSs in similar conditions choose the same value, the probability of their choices being identical at the next occasion is the same as if their first choices had been different.

The meaning of such a specification is that any statistical test for these values, done on a series of similar events, will obtain a result statistically compatible with the specified distribution. This shall hold even in the cases where the tests are conducted with a subset of possible events, with some common parameters. Moreover, basic tests of independence of the values within the series shall pass.

Data against which correlation with the values shall not be found are the protocol state, or the IMSI, or identities or other unrelated information broadcast by the network, or the current TDMA frame number.

### 2.2 Vocabulary

The following terms are used in the present document:

- **idle mode:** In this mode, the mobile station is not allocated any dedicated channel; it listens to the CCCH and the BCCH;
- **group receive mode:** (only applicable for mobile stations supporting VGCS listening or VBS listening) In this mode, the mobile station is not allocated a dedicated channel with the network; it listens to the downlink of a voice broadcast channel or voice group call channel allocated to the cell. Occasionally, the mobile station has to listen to the BCCH of the serving cell as defined in 3GPP TS 03.22 and 05.08;
- **dedicated mode:** In this mode, the mobile station is allocated at least two dedicated channels, only one of them being a SACCH;
- **group transmit mode:** (only applicable for mobile stations supporting VGCS talking) In this mode, one mobile station of a voice group call is allocated two dedicated channels, one of them being a SACCH. These channels can be allocated to one mobile station at a time but to different mobile stations during the voice group call;

- **packet idle mode**: (only applicable for mobile stations supporting GPRS) In this mode, mobile station is not allocated any radio resource on a packet data physical channel; it listens to the PBCCH and PCCCH or, if those are not provided by the network, to the BCCH and the CCCH, see 3GPP TS 04.60.
- **packet transfer mode**: (only applicable for mobile stations supporting GPRS) In this mode, the mobile station is allocated radio resource on one or more packet data physical channels for the transfer of LLC PDUs.
- **main DCCH:** In Dedicated mode and group transmit mode, only two channels are used as DCCH, one being a SACCH, the other being a SDCCH or a FACCH; the SDCCH or FACCH is called here "the main DCCH";
- A channel is **activated** if it can be used for transmission, in particular for signalling, at least with UI frames. On the SACCH, whenever activated, it must be ensured that a contiguous stream of layer 2 frames is sent;
- A TCH is **connected** if circuit mode user data can be transferred. A TCH cannot be connected if it is not activated. A TCH which is activated but not connected is used only for signalling, i.e. as a DCCH;
- The data link of SAPI 0 on the main DCCH is called the **main signalling link**. Any message specified to be sent on the main signalling link is sent in acknowledged mode except when otherwise specified;
- The term **"to establish"** a link is a short form for **"to establish the multiframe mode"** on that data link. It is possible to send UI frames on a data link even if it is not established as soon as the corresponding channel is activated. Except when otherwise indicated, a data link layer establishment is done without an information field.
- "channel set" is used to identify TCHs that carry related user information flows, e.g., in a multislot configuration used to support circuit switched connection(s), which therefore need to be handled together.
- A **temporary block flow** (TBF) is a physical connection used by the two RR peer entities to support the unidirectional transfer of LLC PDUs on packet data physical channels, see 3GPP TS 04.60.
- **RLC/MAC block:** A RLC/MAC block is the protocol data unit exchanged between RLC/MAC entities, see 3GPP TS 04.60.
- A GMM context is established when a GPRS attach procedure is successfully completed.
- -- Network operation mode

The three different network operation modes I, II, and III are defined in 3GPP TS 03.60 [74].

The network operation mode shall be indicated as system information. For proper operation, the network operation mode should be the same in each cell of one routing area.

#### - GPRS MS operation mode

The three different GPRS MS operation modes A, B, and C are defined in 3GPP TS 03.60 [74].

- Anonymous access refers to limited service provisioning to an MS whose identity is unknown in the network.

### 3 Radio Resource management procedures

### 3.1 Overview/General

#### 3.1.1 General

Radio Resource management procedures include the functions related to the management of the common transmission resources, e.g. the physical channels and the data link connections on control channels.

The general purpose of Radio Resource procedures is to establish, maintain and release RR connections that allow a point-to-point dialogue between the network and a mobile station. This includes the cell selection/reselection and the handover procedures. Moreover, Radio Resource management procedures include the reception of the uni-directional BCCH and CCCH when no RR connection is established. This permits automatic cell selection/reselection.

If VGCS listening or VBS listening are supported, the radio resource management also includes the functions for the reception of the voice group call channel or the voice broadcast channel, respectively, and the automatic cell reselection of the mobile station in Group receive mode.

If VGCS talking is supported, the radio resource management also includes the functions for the seizure and release of the voice group call channel.

If GPRS point-to-point services are supported, the radio resource management procedures includes functions related to the management of transmission resources on packet data physical channels. This includes the broadcast of system information to support a mobile station in packet idle and packet transfer modes, see also 3GPP TS 04.60.

- NOTE 1: This chapter includes some procedures used for multislot operation and for the TCH/H + TCH/H configuration which need not be supported by simple mobile stations.
- NOTE 2: The procedures and the information content relating to the TCH/H + TCH/H configuration in RR messages is for further study.

### 3.1.2 Services provided to upper layers

A RR connection is a physical connection used by the two peer entities to support the upper layers' exchange of information flows.

#### 3.1.2.1 Idle mode

In idle mode no RR connection exists.

The RR procedures include (on the mobile station side) those for automatic cell selection/reselection. The RR entity indicates to upper layers the unavailability of a BCCH/CCCH and the cell change when decided by the RR entity. Upper layers are advised of the BCCH broadcast information when a new cell has been selected, or when a relevant part of this information changes.

In Idle mode, upper layers can require the establishment of an RR connection.

#### 3.1.2.2 Dedicated mode

In dedicated mode, the RR connection is a physical point-to-point bi-directional connection, and includes a SAPI 0 data link connection operating in multiframe mode on the main DCCH. If dedicated mode is established, RR procedures provide the following services:

- establishment/release of multiframe mode on data link layer connections other than SAPI 0, on the main DCCH or on the SACCH associated with the channel carrying the main signalling link;
- transfer of messages on any data link layer connection;
- indication of temporary unavailability of transmission (suspension, resuming);
- indication of loss of RR connection;
- automatic cell reselection and handover to maintain the RR connection;
- setting/change of the transmission mode on the physical channels, including change of type of channel, change of the coding/decoding/transcoding mode and setting of ciphering;
- allocation/release of an additional channel (for the TCH/H + TCH/H configuration);
- allocation/release of additional channels for multislot operation;
- release of an RR connection.

#### 3.1.2.3 Group receive mode

Only applicable for mobile stations supporting VGCS listening or VBS listening.

In this mode, the RR procedures on the mobile station side provide the services:

- local connection to the voice broadcast channel or voice group call channel;
- reception of messages in unacknowledged mode;
- automatic cell reselection for the mobile station in Group receive mode;
- local disconnection from the received voice group call or broadcast call channels.

For mobile stations supporting both VGCS listening and VGCS transmit, in addition, the RR procedures on the mobile station side provide the service:

- uplink access procedures to establish the RR connection.

#### 3.1.2.4 Group transmit mode

Only applicable for mobile stations supporting VGCS talking.

In group transmit mode, the RR connection is a physical point-to-point bi-directional connection, and includes a SAPI 0 data link connection operating in multiframe mode on the main DCCH. If the group transmit mode is established, RR procedures provide the following services:

- transfer of messages on the SAPI 0 of the data link layer connection;
- indication of loss of RR connection;
- automatic cell reselection and handover to maintain the RR connection;
- setting of the transmission mode on the physical channels, change of type of channel and setting of ciphering;
- release of the RR connection..

#### 3.1.2.5 Packet idle mode

Only applicable for mobile stations supporting GPRS.

In packet idle mode, no temporary block flow exists (see 3GPP TS 04.60). Upper layers may require the transfer of a LLC PDU, which implicitly triggers the establishment of a temporary block flow.

#### 3.1.2.6 Packet transfer mode

Only applicable for mobile stations supporting GPRS.

In packet transfer mode, the mobile station is allocated radio resource providing a temporary block flow on one or more packet data physical channels. The RR sublayer provides the following services, see also 3GPP TS 04.60:

- transfer of LLC PDUs in acknowledged mode;
- transfer of LLC PDUs in unacknowledged mode.

Depending on the GPRS mode of operation (class A or B), the mobile station may leave both packet idle mode and packet transfer mode before entering dedicated mode, group receive mode or group transmit mode.

Cell reselection in packet idle and packet transfer modes is specified in 3GPP TS 05.08. The RR entity on the mobile station side indicates to the upper layers the availability of a cell and a cell change when decided by the RR sublayer. Upper layers are advised of system information broadcast in the cell when a new cell has been selected, or when a relevant part of this information changes.

### 3.1.3 Services required from data link and physical layers

The RR sublayer uses the services provided by the data link layer as defined in 3GPP TS 04.05.

Moreover, the RR sublayer directly uses services provided by the physical layer such as BCCH searching and transfer of RLC/MAC blocks, as defined in 3GPP TS 04.04.

### 3.1.4 Change of dedicated channels

### 3.1.4.1 Change of dedicated channels using SAPI = 0

In case a change of dedicated channels is required using a dedicated assignment and handover procedure, respectively, the RR sublayer will request the data link layer to suspend multiple frame operation before the mobile station leaves the old channel. When the channel change has been completed, layer 3 will request the data link layer to resume multiple frame operation again. The layer 2 suspend/resume procedures are described in 3GPP TS 04.05 and 04.06.

These procedures are specified in such a way that a loss of a layer 3 message cannot occur on the radio interface. However, messages sent from the mobile station to the network may be duplicated by the data link layer if a message has been transmitted but not yet completely acknowledged before the mobile station leaves the old channel (see 3GPP TS 04.06).

As the RR sublayer is controlling the channel change, a duplication of RR messages does not occur. However, there are some procedures for which a duplication is possible, e.g. DTMF procedures. For all upper layer procedures using the transport service of the RR sub-layer (e.g., MM and CM procedures), the request messages sent by the mobile station contain a sequence number in order to allow the network to detect duplicated messages, which are then ignored by the network. The procedures for sequenced transmission on layer 3 are described in sub-clause 3.1.4.2.

#### 3.1.4.2 Change of dedicated channels using other SAPIs than 0

For SAPIs other than 0, the data link procedures described in 3GPP TS 04.06 do not provide any guarantee against message loss or duplication.

Therefore, if an application uses a SAPI other than 0 and if this application is sensitive to message loss or duplication, then it has to define its own protection mechanism. No general protection mechanism is provided by the protocol defined in the present document.

#### 3.1.4.3 Sequenced message transfer operation

Upper layer messages sent using the RR sub-layer transport service from the mobile station to the network can be duplicated by the data link layer in the following case:

- a channel change of dedicated channels is required (assignment or handover procedure) and the last layer 2 frame has not been acknowledged by the peer data link layer before the mobile station leaves the old channel.

In this case, the mobile station does not know whether the network has received the message correctly. Therefore, the mobile station has to send the message again after the new dedicated channel is established (see 3GPP TS 04.06).

The network must be able to detect the duplicated received message. Therefore, each concerned upper layer message must be marked with a send sequence number.

To allow for different termination points in the infrastructure of the messages of different PDs, the sequence numbering is specific to each PD. For historical reasons, an exception is that messages sent with the CC, SS and MM PDs share the same sequence numbering. In the following, the phrase **upper layer message flow** refers to a flow of messages sharing the same sequence numbering. The different upper layer flows are MM+CC+SS, GCC, BCC, PDSS1 and PDSS2.

#### 3.1.4.3.1 Variables and sequence numbers

#### 3.1.4.3.1.1 Send state variable V(SD)

The RR sublayer of the mobile station shall have one associated send state variable V(SD) ("Send Duplicated") for each upper layer message flow. The send state variable denotes the sequence number of the next in sequence numbered message in the flow to be transmitted. The value of the corresponding send state variable shall be incremented by one with each numbered message transmission. Arithmetic operations on V(SD) are performed modulo 2.

#### 3.1.4.3.1.2 Send sequence number N(SD)

At the time when such a message to be numbered is designated for transmission, the value of N(SD) for the message to be transferred is set equal to the value of the send state variable V(SD). See 3GPP TS 04.07.

# 3.1.4.3.2 Procedures for the initiation, transfer execution and termination of the sequenced message transfer operation

#### 3.1.4.3.2.1 Initiation

The sequenced message transfer operation is initiated by establishing a RR connection. The send state variables V(SD) are set to 0.

#### 3.1.4.3.2.2 Transfer Execution

The network must compare the send sequence numbers of pairs of subsequent messages in the same upper layer messages flow. In case the send sequence numbers of two subsequent messages in a flow are not identical, no duplication has occurred. In case the send sequence numbers are identical, the network must ignore the second one of the received messages.

#### 3.1.4.3.2.3 Termination

The sequenced message transfer operation is terminated by the RR connection release procedure.

### 3.1.5 Procedure for Service Request and Contention Resolution

Upon seizure of the assigned dedicated channel, the mobile station establishes the main signalling link on this channel by sending a layer 2 SABM frame containing a layer 3 service request message. The data link layer will store this message to perform the contention resolution. The service request message will be returned by the network in the UA frame.

The data link layer in the mobile station compares the content of the information field (i.e. the layer 3 service request message) received in the UA frame with the stored message and leaves the channel in case they do not match. This procedure resolves contentions in the case where several mobile stations have accessed at the same random access slot and with the same random reference and one has succeeded due to capture. The full description of the procedure is given in 3GPP TS 04.06.

The purpose of the service request message is to indicate to the network which service the mobile station is requesting. This then allows the network to decide how to proceed (e.g. to authenticate or not).

The service request message must contain the identity of the mobile station and may include further information which can be sent without encryption.

The layer 3 service request message is typically one of the following:


- CM SERVICE REQUEST
- LOCATION UPDATING REQUEST
- IMSI DETACH
- PAGING RESPONSE
- CM RE-ESTABLISHMENT REQUEST
- NOTIFICATION RESPONSE
- IMMEDIATE SETUP
- RR INITIALISATION REQUEST

```
Mobile Station Network

SABM ("layer 3 service request message")

UA ("layer 3 service request message")

<------+
```



#### 3.1.6 Preemption

The datalink layer provides the capability to assign a priority to any message transferred in dedicated mode on SAPI 0 with multiframe operation. The available message priorities defined in 3GPP TS 04.06 are "high", "normal" and "low". Messages assigned a "high" priority are enabled to preempt, in the data link layer, all preceeding untransmitted and partially transmitted messages assigned a "low" priority that are using the same data link connection (same SAPI and logical channel). Messages or message portions that are preempted are discarded without notification to higher layers except that the first 2\*N201 octets of any partially transmitted message are not discarded. The following priority assignments are defined for those Radio Resource, Mobility Management and Connection Management messages that use SAPI 0.

Priority	Messages	
Low	RR Application Information message	
Normal	All MM messages	
	All CM messages	
	All other RR messages using SAPI 0 not listed	
	here	
High	RR Channel Establishment:	
	ADDITIONAL ASSIGNMENT	
	RR Configuration Change:	
	CONFIGURATION CHANGE COMMAND	
	RR Handover related	
	ASSIGNMENT COMMAND	
	HANDOVER COMMAND	
	RR-CELL CHANGE ORDER	
	PDCH ASSIGNMENT COMMAND	
	RR Channel release	
	CHANNEL RELEASE	
	PARTIAL RELEASE	

Table 2.1/3GPP TS 04.08: Priority Values of Layer 3 Messages

Use of the preemption capability by layer 3 is not required in a BSS or MS that does not send any "low" priority message. In this case, all messages may be treated as having "normal" priority.

Preemption capabilities in Layer 3 are not applicable to the Uplink messages, hence all UL messages are treated as having "normal" priority.

NOTE: The "Suspension and Resumption of Multiple frame operation" (See 3GPP TS 04.06) will affect the order in which the layer 3 messages are delivered on the Uplink.

# 3.2 Idle mode procedures and general procedures in packet idle and packet transfer modes

### 3.2.1 Mobile Station side

In idle mode, the MS listens to the BCCH and to the paging sub-channel for the paging group the MS belongs to in idle mode (cf. 3GPP TS 03.13); it measures the radio propagation for connection with other cells.

In packet idle and packet transfer modes (applicable only to a GPRS mobile station), the mobile station listens to either the PBCCH, if that is present in the cell, or BCCH. The requirements for the monitoring of system information is further specified in 3GPP TS 04.60. Moreover, the mobile station measures the radio propagation for connection with other cells.

In packet idle mode (applicable only to a GPRS mobile station), the mobile station listens to the paging sub-channels on the PCCCH or CCCH. Paging sub-channels are monitored according to the paging group determined for the mobile station and its current discontinuous reception (DRX) mode. The determination of paging group for the mobile station is defined in 3GPP TS 05.02. The DRX procedures are defined in 3GPP TS 04.60 and 3GPP TS 05.02.

Measurements are treated to assess the need of a cell change as specified in 3GPP TS 05.08. When the decision to change cells is made, the mobile station switches to the BCCH or PBCCH of the new cell. The broadcast information is then checked to verify the allowance to camp on this cell (cf. sub-clause 3.2.2). Dependent on the mobile station type and configuration, the mobile station may be required to try to read further BCCH and PBCCH information. If allowed, the cell change is confirmed, and the broadcast information is then treated for Mobility Management actions (cf. sub-clause 4). Similarly, physical contexts are updated (list of neighbouring cells frequencies, thresholds for some actions, etc. (cf. 3GPP TS 05.08 and sub-clause 3.2.2)).

### 3.2.2 Network side

#### 3.2.2.1 System information broadcasting

SYSTEM INFORMATION TYPE 2 to 4 messages, and optionally TYPE 1, 2bis, 2ter, 7, 8, 13, 16 and 17 and further types are regularly broadcast by the network on the BCCH. Based on this information the mobile station is able to decide whether and how it may gain access to the system via the current cell. The SYSTEM INFORMATION TYPE 2bis message shall be sent if and only if the EXT-IND bit in the Neighbour Cells Description IE in both the TYPE 2 and TYPE 2bis messages indicates that each IE only carries part of the BA. SYSTEM INFORMATION TYPE 2ter message shall be sent if and only if this is indicated in SYSTEM INFORMATION TYPE 3 message.

A GSM 900 mobile station which only supports the primary GSM band P-GSM 900 (cf. 3GPP TS 05.05) may consider the EXT-IND bit in the Neighbour Cells Description IE in the SYSTEM INFORMATION TYPE 2 message as a spare bit. If it does so it shall assume that the information element carries the complete BA and it shall ignore any SYSTEM INFORMATION TYPE 2bis and 2ter messages.

If the additional cell reselection parameters are broadcast then SYSTEM INFORMATION TYPE 3 message shall always contain these parameters. In addition to SYSTEM INFORMATION TYPE 3 at least either SYSTEM INFORMATION TYPE 4 or SYSTEM INFORMATION TYPE 7 and 8 messages shall contain these parameters too.

If additional SoLSA specific parameters are broadcast then SYSTEM INFORMATION TYPE 16 and 17 messages, shall always contain these parameters. In addition to SYSTEM INFORMATION TYPE 16 and 17 messages at least either SYSTEM INFORMATION TYPE 4 or SYSTEM INFORMATION TYPE 7 and 8 messages shall contain these SoLSA specific parameters too.

The support of GPRS shall be indicated in SYSTEM INFORMATION TYPE 3 message. In addition, the support of GPRS shall be indicated in either SYSTEM INFORMATION TYPE 4 or SYSTEM INFORMATION TYPE 7 and 8 messages. If GPRS is supported, SYSTEM INFORMATION TYPE 13 message shall be sent. SI 13 message shall not be sent if GPRS is not supported. Additional requirements for the broadcast of system information in a cell supporting GPRS are specified in 3GPP TS 04.60.

NOTE 1: The allowed scheduling of SYSTEM INFORMATION messages on the BCCH are specified in 3GPP TS 05.02.

- NOTE 2: The network should take into account limitations of certain mobile stations to understand SYSTEM INFORMATION TYPE 2bis, TYPE 2ter, the EXT-IND bit in the Neighbour Cells Description, the indication of 2ter in SYSTEM INFORMATION TYPE 3 and formats used in the Neighbour Cells Description IE and Cell Channel Description IE used in SYSTEM INFORMATION messages, see this sub-clause, sub-clause 10.5.2.1b, and sub-clause 10.5.2.22.
- NOTE 3: The network should take into account the limitations of earlier version of mobile equipments to understand the 3-digit MNC format of the location area identification, see sub-clause 10.5.1.3.

The information broadcast may be grouped in the following classes:

- information giving unique identification of the current network, location area and cell;
- information used for candidate cell measurements for handover and cell selection procedures;
- information describing the current control channel structure;
- information controlling the random access channel utilization;
- information defining different options supported within the cell; and
- information about the length of the part of the message belonging to the phase 1 protocol.

The network may send to the mobile station BCCH scheduling information as specified below:

- The BCCH scheduling information may be contained in the SYSTEM INFORMATION TYPE 9 messages. If so, SYSTEM INFORMATION TYPE 3 specifies where to find SYSTEM INFORMATION TYPE 9 messages carrying BCCH scheduling information.
- 2) If the mobile station has received BCCH scheduling information, it shall assume that this BCCH scheduling information is valid in the location area until new scheduling information is received. It may store the information in the ME and assume its validity after switch on in the same location area.
- 3) The network need not indicate the schedule of all SYSTEM INFORMATION messages in SYSTEM INFORMATION 9. For any System Information message, the MS shall monitor all blocks specified in 3GPP TS 05.02 for that System Information message and all blocks specified in the SYSTEM INFORMATION TYPE 9 message for that System Information message.
- 4) When the mobile station detects that the BCCH information is not scheduled as defined in the last received SI 9 message, it shall read the SYSTEM INFORMATION TYPE 3 message. If presence of BCCH scheduling information in SYSTEM INFORMATION TYPE 9 message is indicated, it shall try to read the information and continue as in 2 above. If presence of BCCH scheduling information in SYSTEM INFORMATION TYPE 9 message is not indicated, it shall assume that there is no valid BCCH scheduling information.

#### 3.2.2.2 Paging

The network is required to send valid layer 3 messages continuously on all paging subchannels on CCCH.

### 3.3 RR connection establishment

### 3.3.1 RR connection establishment initiated by the mobile station

The purpose of the immediate assignment procedure is to establish an RR connection between the mobile station and the network.

#### 3.3.1.1 Entering the dedicated mode : immediate assignment procedure

The immediate assignment procedure can only be initiated by the RR entity of the mobile station. Initiation is triggered by request from the MM sublayer or LLC layer to enter the dedicated mode or by the RR entity in response to a PAGING REQUEST message or to initiate a notification response procedure. Upon such a request,

- if access to the network is allowed (as defined in sub-clause 3.3.1.1.1), the RR entity of the mobile station initiates the immediate assignment procedure as defined in sub-clause 3.3.1.1.2;
- otherwise, it rejects the request.

The request from the MM sublayer to establish an RR connection specifies an establishment cause. Similarly, the request from the RR entity to establish a RR connection in response to a PAGING REQUEST 1, 2 or 3 message specifies one of the establishment causes "answer to paging"; the request from the RR entity to establish an RR connection in order to initiate a notification response procedure specifies one of the establishment causes " procedures that can be completed with a SDCCH".

#### 3.3.1.1.1 Permission to access the network

All mobile stations with an inserted SIM are members of one out of 10 access classes numbered 0 to 9. The access class number is stored in the SIM. In addition, mobile stations may be members of one or more out of 5 special access classes (access classes 11 to 15) (see 3GPP TS 02.11), this is also held on the SIM card.

The system information messages on the BCCH broadcast the list of authorized access classes and authorized special access classes in the system information messages, and whether emergency calls are allowed in the cell to all mobile stations or only to the members of authorized special access classes.

If the establishment cause for the request of the MM sublayer is not "emergency call", access to the network is allowed if and only if the mobile station is a member of at least one authorized:

- access class; or
- special access class.

If the establishment cause for the request of the MM sublayer is "emergency call", access to the network is allowed if and only if:

- emergency calls are allowed to all mobile stations in the cell; or
- the mobile station is a member of at least one authorized special access class.

#### 3.3.1.1.2 Initiation of the immediate assignment procedure

The RR entity of the mobile station initiates the immediate assignment procedure by scheduling the sending on the RACH and leaving idle mode (in particular, the mobile station shall ignore PAGING REQUEST messages).

It then sends maximally M + 1 CHANNEL REQUEST messages on the RACH in a way such that:

- the number of slots belonging to the mobile station's RACH between initiation of the immediate assignment procedure and the first CHANNEL REQUEST message (excluding the slot containing the message itself) is a random value drawn randomly for each new initial assignment initiation with uniform probability distribution in the set {0, 1, ..., max (T,8) 1};
- the number of slots belonging to the mobile station's RACH between two successive CHANNEL REQUEST messages (excluding the slots containing the messages themselves) is a random value drawn randomly for each new transmission with uniform probability distribution in the set {S, S + 1, ..., S + T 1};
- here, T is the value of the parameter "Tx-integer" broadcast on the BCCH;
- M is the value of the parameter "max retrans" broadcast on the BCCH;
- S is a parameter depending on the CCCH configuration and on the value of Tx-integer as defined in table 3.1/3GPP TS 04.08.

The CHANNEL REQUEST messages are sent on the RACH (cf. sub-clause 1.5) and contain as parameters:

- an establishment cause which corresponds to the establishment cause given by the MM sublayer and the broadcast NECI value, or which corresponds to one of the establishment causes "answer to paging" given by the RR entity in response to a PAGING REQUEST message including the Channel Needed information, or which corresponds to one of the establishment causes " procedures that can be completed with a SDCCH" given by the RR entity in order to initiate a notification response procedure;
- a random reference which is drawn randomly from a uniform probability distribution for every new transmission.

After sending the first CHANNEL REQUEST message, the mobile station shall start listening to the BCCH; it shall also listen to the full downlink CCCH timeslot corresponding to its CCCH group.

Having sent M + 1 CHANNEL REQUEST messages, the RR entity of the mobile station starts timer T3126. At expiry of timer T3126, the immediate assignment procedure is aborted; if the immediate assignment procedure was triggered by a request from the MM sublayer, a random access failure is indicated to the MM sublayer.

TX-integer	non combined CCCH	combined CCH/SDCCH
3, 8, 14, 50	55	41
4, 9, 16	76	52
5, 10, 20	109	58
6, 11, 25	163	86
7, 12, 32	217	115

#### Table 3.1/3GPP TS 04.08: Values of parameter S

#### 3.3.1.1.3 Answer from the network

#### 3.3.1.1.3.1 On receipt of a CHANNEL REQUEST message

The network may allocate a dedicated channel to the mobile station by sending an IMMEDIATE ASSIGNMENT message or IMMEDIATE ASSIGNMENT EXTENDED message in unacknowledged mode on the same CCCH timeslot on which it has received the CHANNEL REQUEST. There is no further restriction on what part of the downlink CCCH an IMMEDIATE ASSIGNMENT message or IMMEDIATE ASSIGNMENT EXTENDED message can be sent. The type of channel allocated (SDCCH or TCH; the channel mode shall be set to signalling only) is a network operator decision. Timer T3101 is then started on the network side.

NOTE: There are two types of immediate assignment messages:

- IMMEDIATE ASSIGNMENT message, containing assignment information for one mobile station only;
- IMMEDIATE ASSIGNMENT EXTENDED message, containing assignment information for two mobile stations at the same time.

The IMMEDIATE ASSIGNMENT or IMMEDIATE ASSIGNMENT EXTENDED message contains:

- the description of the assigned channel;
- the information field of the CHANNEL REQUEST message and the frame number of the frame in which the CHANNEL REQUEST message was received;
- the initial timing advance (cf. 3GPP TS 04.04);
- optionally, a starting time indication.

If frequency hopping is applied, the mobile station uses the last CA received on the BCCH to decode the Mobile Allocation.

On receipt of an IMMEDIATE ASSIGNMENT or IMMEDIATE ASSIGNMENT EXTENDED message corresponding to one of its 3 last CHANNEL REQUEST messages, the mobile station stops T3126 (if running), stops sending CHANNEL REQUEST messages, switches to the assigned channels, sets the channel mode to signalling only and

activates the assigned channels. It then establishes the main signalling link with an SABM containing an information field (see sub-clause 3.1.5).

An IMMEDIATE ASSIGNMENT or IMMEDIATE ASSIGNMENT EXTENDED message may indicate a frequency change in progress, with a starting time and possibly alternative channel descriptions.

In the case of the reception of an IMMEDIATE ASSIGNMENT EXTENDED message, or of an IMMEDIATE ASSIGNMENT message which contains only the description of a channel to be used after the starting time, the mobile station shall wait up to the starting time before accessing the channel. If the starting time has already elapsed, the mobile shall access the channel as an immediate reaction to the reception of the message (see 3GPP TS 05.10 for the timing constraints).

If the message contains both the description of a channel to be used after the indicated time and of a channel to be used before, the mobile station accesses a channel as an immediate reaction to the reception of the message. If the moment the mobile station is ready to access is before the indicated time, the mobile station accesses the channels described for before the starting time. The mobile station then changes to the channel described for after the starting time at the indicated time. New parameters can be frequency list and MAIO. Other parameters describing the channel to be used before the starting time are taken from the description of the channel defined for use after the starting time. If the moment the mobile station is ready to access is after the starting time, the mobile station accesses the channel described for after the starting time.

If frequency hopping is applied, the mobile station uses the last CA received on the BCCH.

#### 3.3.1.1.3.2 Assignment rejection

If no channel is available for assignment, the network may send to the mobile station an IMMEDIATE ASSIGNMENT REJECT message in unacknowledged mode on the same CCCH timeslot on which the channel request message was received. There is no further restriction on what part of the downlink CCCH timeslot an IMMEDIATE ASSIGNMENT REJECT message can be sent. This message contains the request reference and a wait indication.

On receipt of an IMMEDIATE ASSIGNMENT REJECT message corresponding to one of its 3 last CHANNEL REQUEST messages, the mobile station, stops sending CHANNEL REQUEST messages, starts timer T3122 with the indicated value, ("wait indication" information element), starts T3126 if it has not already been started, and listens to the downlink CCCH until T3126 expires. During this time, additional IMMEDIATE ASSIGNMENT REJECT messages are ignored, but any immediate assignment corresponding to any other of its 3 last CHANNEL REQUEST messages make the mobile station follow the procedure in sub-clause 3.3.1.2. If no such immediate assignment is received, the mobile station returns to CCCH idle mode (listening to its paging channel).

As an option the mobile station may return to CCCH idle mode as soon as it has received responses from the network on all, or in case more than 3 were sent the last 3, of its CHANNEL REQUEST messages.

The mobile station is not allowed to make a new attempt to establish a non emergency RR connection in the same cell until T3122 expires. Provided that an IMMEDIATE ASSIGNMENT REJECT message has not been received for an emergency RR connection attempt, the mobile station may attempt to enter the dedicated mode for an emergency call in the same cell before T3122 has expired.

The Wait Indication IE (i.e. T3122) relates to the cell from which it was received.

The mobile station in packet idle mode (only applicable to mobile station supporting GPRS) may initiate packet access in the same cell before T3122 has expired, see 3GPP TS 04.60 and sub-clause 3.5.2.1.3.4.

After T3122 expiry, no CHANNEL REQUEST message shall be sent as a response to a page until a PAGING REQUEST message for the mobile station is received.

#### 3.3.1.1.4 Assignment completion

The immediate assignment procedure is terminated on the network side when the main signalling link is established. Timer T3101 is stopped and the MM sublayer on the network side is informed that the RR entity has entered the dedicated mode.

On the mobile station side, the procedure is terminated when the establishment of the main signalling link is confirmed. The MM sublayer is informed that the RR entity has entered the dedicated mode.

#### 3GPP TS 04.08 version 7.21.0 Release 1998

#### 3.3.1.1.4.1 Early classmark sending

Early classmark sending consists in the mobile station sending as early as possible after access a CLASSMARK CHANGE message to provide the network with additional classmark information.

A mobile station which implements the "Controlled Early Classmark Sending" option shall perform the early classmark sending if and only if explicitly accepted by the network, as indicated in the last reception in the accessed cell of the SYSTEM INFORMATION TYPE 3 message.

A mobile station which implements one or more of the "multiple band support" options shall also implement the "Controlled Early Classmark Sending" option.

A mobile station which implements the "multislot capability" option shall also implement the "Controlled Early Classmark Sending" option.

A mobile station that implements some form of treatment of UCS2 alphabet (see TS 3GPP TS 03.38) encoded character string (e.g., in short message, or in USSD string) may indicate so in the classmark. (An example is a Mobile Equipment able to display UCS2 encoded character string.) In such a case, it should also implement the "Controlled Early Classmark Sending" option. It is the mobile station responsibility to provide the UCS2 support information in due time. If the network needs this information and the mobile station did not provide it, the network may assume that the Mobile Equipment does not support UCS2.

A mobile station which implements the R-GSM band (see 3GPP TS 05.05) shall also implement the "Controlled Early Classmark Sending" option.

A mobile station which implements the extended measurement function shall also implement the "Controlled Early Classmark Sending" option.

A mobile station which implements the "GPRS" option shall also implement the "Controlled Early Classmark Sending" option.

A mobile station which implements the "SoLSA" option shall also implement the "Controlled Early Classmark Sending" option.

A mobile station which implements the "LCS" option shall also implement the "Controlled Early Classmark Sending" option.

A mobile station which implements the "Controlled Early Classmark Sending" option shall indicate it in the classmark (ES IND bit).

#### 3.3.1.1.4.2 GPRS suspension procedure

This procedure enables the network to suspend GPRS services packet flow in the downlink direction.

The GPRS suspension procedure is initiated by the mobile station by sending a GPRS SUSPENSION REQUEST message. This can be done as early as possible after access but shall be done after sending a CLASSMARK CHANGE message. The RR sublayer of the mobile station shall indicate a RR GPRS suspend condition to the MM sublayer, see sub-clause 4.

When a mobile station which is IMSI attached for GPRS services (sub-clause 4) enters the dedicated mode, and when the mobile station limitations make it unable to handle both dedicated mode and either packet idle mode or packet transfer mode simultaneously, the mobile station shall perform the GPRS suspension procedure.

#### 3.3.1.1.5 Abnormal cases

If a lower layer failure occurs on the mobile station side on the new channel before the successful establishment of the main signalling link, the allocated channels are released; the subsequent behaviour of the mobile station depends on the type of failure and previous actions.

- If the failure is due to information field mismatch in the contention resolution procedure, see sub-clause 3.1.5, and no repetition as described in this paragraph has been performed, the immediate assignment procedure shall be repeated.

- If the failure is due to any other reason or if a repetition triggered by a contention resolution failure has been performed. The mobile station returns to idle mode (RR connection establishment failure), transactions in progress are aborted and cell reselection then may take place.

If the information available in the mobile station, after the reception of an IMMEDIATE ASSIGNMENT message does not satisfactorily define a channel, an RR connection establishment failure has occurred.

If the Mobile Allocation IE indexes frequencies in more than one frequency band then a RR connection establishment failure has occurred.

If an IMMEDIATE ASSIGNMENT message indicates (a) channel(s) in a different frequency band to which the CHANNEL REQUEST message was sent then, if the frequency band is supported by the mobile station, the mobile station shall access the indicated channel(s) with the same power control level as used for the CHANNEL REQUEST message.

If an IMMEDIATE ASSIGNMENT message indicates a channel in non-supported frequency band then a RR connection establishment failure has occurred.

On the network side, if timer T3101 elapses before the main signalling link is established, the newly allocated channels are released and the request is forgotten. Note that the network has no means to distinguish repeated attempts from initial attempts from a mobile station.

#### 3.3.1.2 Entering the group transmit mode: uplink access procedure

Only applicable for mobile stations supporting "VGCS transmit".

The purpose of the uplink control procedure is to establish an RR connection on a VGCS channel between a mobile station which is in group receive mode on that channel and the network.

The mobile station enters the group transmit mode when a successful establishment of the RR connection is indicated. The channel mode assumed by the mobile station is the one derived from the channel description.

#### 3.3.1.2.1 Mobile station side

#### 3.3.1.2.1.1 Uplink investigation procedure

The mobile station in group receive mode shall consider the uplink as free if the last message indicating the uplink as being free was received less than 480 ms ago and if no UPLINK BUSY message has been received since the last message indicating the uplink as free.

On receipt of a request from the upper layer to access the uplink and if the uplink is not free, the mobile station starts the timer T3128.

If the uplink is free or becomes free before expiry of timer T3128, then the uplink investigation procedure is terminated, the mobile station shall stop T3128, and start the uplink access procedure.

NOTE: The start of the uplink access procedure is not subject to the access class of the mobile station.

If the uplink is not indicated free before the timer expires, the mobile station shall remain in the group receive mode and indicate a reject of the uplink request to the upper layer.

#### 3.3.1.2.1.2 Uplink access procedure

The mobile station shall send UPLINK ACCESS messages on the voice group call channel with the appropriate establishment cause. The first UPLINK ACCESS message shall be transmitted by the mobile station with a random delay between 0 and 20ms. The UPLINK ACCESS messages shall be repeated after a further period of 100ms plus a random delay between 0 and 20ms.

If an uplink identity code (UIC) of the current cell has been provided by the network in the UPLINK FREE message, the mobile station shall use this UIC IE for the coding of the UPLINK ACCESS messages (see 3GPP TS 05.03). If no UIC is provided, the mobile station shall use the BSIC received from the current cell, for instance from the initial synchronization.

Having sent the first UPLINK ACCESS message, the mobile station starts timer T3130. At expiry of timer T3130, the mobile station shall repeat the same procedure if the uplink is free. A maximum of three attempts is allowed and after that a rejection of the uplink request is indicated to the upper layers.

If no VGCS UPLINK GRANT or UPLINK BUSY message is received by the mobile station 480 ms after having sent the first UPLINK ACCESS message, the mobile station shall stop sending UPLINK ACCESS messages and wait in order to receive a VGCS UPLINK GRANT or UPLINK BUSY message.

On receipt of an VGCS UPLINK GRANT message corresponding to one of its UPLINK ACCESS messages, the mobile station stops T3130, stops sending UPLINK ACCESS messages, and establishes the main signalling link with an SABM containing the TALKER INDICATION message in the information field. Early classmark sending shall be performed if applicable. If a UA is received containing the message sent, the mobile station enters the group transmit mode and indicates the successful seizure of the uplink to the upper layer. If a UA is received with a message different from the message sent, the mobile station shall remain in the group receive mode and indicate the rejection of the uplink request to the upper layers.

When receiving an UPLINK BUSY message or a VGCS UPLINK GRANT message aimed to another mobile station (i.e., not corresponding to one of its UPLINK ACCESS messages), the mobile station stops T3130 and stops sending UPLINK ACCESS messages. The mobile shall remain in the group receive mode and shall indicate a rejection of the uplink request to the upper layers.

#### 3.3.1.2.2 Network side

On receipt of an UPLINK ACCESS message the network shall perform, if necessary, contention resolution and grant the uplink to one mobile station by sending a VGCS UPLINK GRANT message to the mobile station in unacknowledged mode on the main signalling link. Furthermore, the network shall provide UPLINK BUSY messages on the main signalling link in all cells of the group call area. After having sent the first message, the network starts T3115. If the timer expires before the reception of a correctly decoded frame from the MS, the network repeats the VGCS UPLINK GRANT message to the mobile station. If the VGCS UPLINK GRANT message has been repeated Ny2 times without a correctly decoded frame being received from the MS, the network shall stop sending VGCS UPLINK GRANT messages and provide an UPLINK FREE message on the main signalling channel and wait for a new UPLINK ACCESS message. The correct decoding of a frame means that the decoding algorithm and the error detection tests, if any, indicate no error.

After the data link layer is established, the RR entity of the network shall analyse the TALKER INDICATION message received from the mobile station, adapt the RR procedures to the new classmark if necessary and provide the mobile subscriber identity to the upper layer.

#### 3.3.1.2.3 Abnormal cases

If a lower link failure has occurred or an indication of the release of the data link layer was provided by the lower layer and no RR release request was previously received from the upper layer, the network shall provide an UPLINK FREE message on the main signalling channel and wait for a new UPLINK ACCESS message.

#### 3.3.1.3 Dedicated mode and GPRS

A mobile station whose Channel Request message contained a packet access establishment cause may receive an Immediate Assignment message to a Channel which is to be used in dedicated mode. A mobile station supporting the <<<GPRS>> option shall obey this command. When establishing the main signalling link the information field in the SABM shall contain an RR INITIALISATION REQUEST message.

This message contains:

- TLLI;
- MS Classmark type 2;
- Ciphering Key Sequence Number;
- MAC Mode and Channel Coding Requested;
- Channel Request Description.

Following a successful contention resolution procedure, the mobile station shall implement the Early Classmark Sending option. Then, the upper layers in the mobile station shall wait for commands from the network, eg for the allocation of a GPRS resource.

While on the dedicated channel the mobile station shall obey the RR management procedures of 04.08, in particular the mobile station shall send measurement reports on the SACCH.

### 3.3.2 Paging procedure for RR connection establishment

The network can initiate the establishment of an RR connection by the paging procedure for RR connection establishment. Such a procedure can only be initiated by the network.

### 3.3.2.1 Paging initiation by the network

The network initiates the paging procedure to trigger RR connection establishment by broadcasting a paging request message on the appropriate paging subchannel on CCCH or PCCCH, and starts timer T3113. The paging subchannels on CCCH and PCCCH are specified in 3GPP TS 05.02 and 3GPP TS 03.13.

The network may also send paging related information on PACCH to a mobile station in packet transfer mode, see subclause 3.3.2.1.3.

The network may also broadcast paging related information on any voice broadcast or voice group call channel downlink.

#### 3.3.2.1.1 Paging initiation using paging subchannel on CCCH

Paging initiation using the paging subchannel on CCCH is used when sending paging information to a mobile station in idle mode. It is also used when sending paging information to a mobile station in packet idle mode, if PCCCH is not present in the cell.

NOTE 1: There are 3 types of paging messages which may be used on CCCH:

- PAGING REQUEST TYPE 1;
- PAGING REQUEST TYPE 2; and
- PAGING REQUEST TYPE 3.

In a PAGING REQUEST message on CCCH to trigger RR connection establishment, the mobile station shall be identified by the TMSI (non-GPRS TMSI) or its IMSI. If the mobile station is identified by the TMSI, it shall proceed as specified in sub-clause 3.3.2.2.

If the mobile station in packet idle mode is identified by its IMSI, it shall parse the message for a corresponding *Packet Page Indication* field:

- if the *Packet Page Indication* field indicates a paging procedure for RR connection establishment, or the field is not present in the message, the mobile station shall proceed as specified in sub-clause 3.3.2.2;
- if the *Packet Page Indication* field indicates a packet paging procedure, the mobile station shall proceed as specified in sub-clause 3.5.1.2.

A PAGING REQUEST message on CCCH includes for each mobile station that is paged to trigger RR connection establishment an indication which defines how mobiles of different capabilities shall code the establishment cause field in the CHANNEL REQUEST message. The information received in the CHANNEL REQUEST can be used by the network to assign a suitable channel.

A PAGING REQUEST message on CCCH may include more than one mobile station identification.

A PAGING REQUEST TYPE 1 message on CCCH may have additionally a notification message coded in the P1 rest octets information element.

A PAGING REQUEST message on CCCH may also include priority levels related to the mobile station identifications. A mobile station in group receive mode supporting eMLPP shall take into account this information to decide whether to respond to this PAGING REQUEST and, if the call is answered, the mobile station shall store the priority level for the

duration of the call. A mobile station not supporting eMLPP shall ignore this information element when received in a PAGING REQUEST message.

NOTE 2: A mobile station not supporting VGCS or VBS may ignore this information element when received in a PAGING REQUEST message, since the priority level is also provided in the SETUP message.

If VGCS or VBS is supported by the network and the network supports reduced NCH monitoring, messages sent on the PCH may also include an indication of the change of the information sent on the NCH (see sub-clause 3.3.3.2).

The choice of the message type depends on the number of mobile stations to be paged and of the types of identities that are used. The maximum number of paged mobile stations per message is 4 when using only TMSIs for identification of the mobile stations.

The mobile station in idle mode is required to receive and analyse the paging messages and immediate assignment messages sent on the paging subchannel corresponding to its paging subgroup, as specified in 3GPP TS 05.02.

## NOTE 3: The possible immediate assignment messages are: the IMMEDIATE ASSIGNMENT, the IMMEDIATE ASSIGNMENT EXTENDED and the IMMEDIATE ASSIGNMENT REJECT messages.

The paging and immediate assignment type messages contain a page mode information element. This information element controls possible additional requirements on mobile stations belonging to the paging subgroup corresponding to the paging subchannel the message was sent on. This implies that a given mobile station shall take into account the page mode information element of any message sent on its own paging subchannel whatever the nature of this message (paging messages or immediate assignment messages). This further implies that the mobile station does not take into account page mode information element of messages sent on paging subchannels other than its own paging subchannel. The requirements yielded by the page mode information element are as follows:

- a) normal paging: no additional requirements;
- b) extended paging: the mobile station is required in addition to receive and analyse the next but one message on the PCH;
- c) paging reorganization: The mobile station shall receive all messages on the CCCH regardless of the BS-AG-BLKS-RES setting. It is required to receive all BCCH messages. When the mobile station receives the next message to its (possibly new) paging subgroup the subsequent action is defined in the page mode information element in that message.
- d) same as before: No change of page mode from the previous page mode.

Note that a mobile station takes into account the page mode information only in messages of its own paging subchannel whatever the currently applied requirements (a, b, c or d).

When the mobile station selects a new PCH, the initial page mode in the mobile station shall be set to paging reorganization. If a message in the paging subchannel is not received correctly, the message is ignored and the previous page mode is assumed.

#### 3.3.2.1.2 Paging initiation using paging subchannel on PCCCH

Paging initiation using a paging subchannel on PCCCH, see 3GPP TS 04.60, applies when sending paging information to a mobile station in packet idle mode and PCCCH is provided in the cell.

The paging initiation procedure and the paging request message used on PCCCH are specified in 3GPP TS 04.60.

#### 3.3.2.1.3 Paging initiation using PACCH

Paging initiation using PACCH, see 3GPP TS 04.60, applies to a mobile station in packet transfer mode.

The paging initiation procedure and the message used to carry paging related information on PACCH are specified in 3GPP TS 04.60.

#### 3.3.2.2 Paging response

Upon receipt of a paging request message, or other message containing information to trigger the establishment of a RR connection, and if access to the network is allowed, the addressed mobile station shall, when camped on a cell as

specified in 3GPP TS 03.22, initiate the immediate assignment procedure as specified in 3.3.1. The establishment of the main signalling link is then initiated by use of an SABM with information field containing the PAGING RESPONSE message (see sub-clause 3.1.5). The MM sublayer in the mobile station is informed that the RR entity has entered the dedicated mode.

Upon receipt of the PAGING RESPONSE message the network stops timer T3113. The MM sublayer in the network is informed that an RR connection exists.

#### 3.3.2.3 Abnormal cases

Lower layer failure occurring during the immediate assignment procedure is treated as specified for that procedure.

If timer T3113 expires and a PAGING RESPONSE message has not been received, the network may repeat the paging request message and start timer T3113 again. The number of successive paging attempts is a network dependent choice.

mobile station	network
PAGING REQUEST	Start T3113
RANDOM ACCESS	
IMM ASSIGN	Start T3101
SABM (PAGING RESPONSE)	Stop T3101, T3113

#### Figure 3.2/3GPP TS 04.08: Paging sequence

### 3.3.3 Notification procedure

The support of notification procedure is mandatory for mobile stations supporting "VGCS receive" and/or "VBS receive".

The network informs the mobile station of starting or on-going voice broadcast calls and voice group calls with the notification procedure.

In cases where the mobile station has initiated a VGCS call, if the channel mode modify procedure is applied to turn the dedicated channel into a VGCS channel and ciphering may be applied for that call, in this case the network should suspend transmission of notification messages until ciphering with the group cipher key has started on the dedicated channel.

#### 3.3.3.1 Notification of a call

The mobile station may receive a notification that a voice broadcast call or a voice group call is established. Notifications may be sent on the NCH, on the PCH, or on the FACCH when in dedicated mode or group receive mode. The presence of an NCH is indicated on the PCH in the Pi Rest Octets IE. A notification contains the group call reference and possibly other related information. This notification may be contained:

- in a NOTIFICATION/NCH message sent on the NCH to notify mobile stations of VBS or VGCS calls in the current cell, possibly together with a description of the related VBS or VGCS channel;
- in a NOTIFICATION/FACCH message sent in unacknowledged mode on the main DCCH to notify mobile stations in dedicated mode or on the main DCCH of a VGCS or VBS channel, of other VBS or VGCS calls in the current cell, possibly together with a description of the related VBS or VGCS channel;
- in the rest octets part of a PAGING REQUEST TYPE 1 message.

A mobile station supporting neither VGCS listening nor VBS listening may ignore the notifications sent on the NCH or PCH. It may also ignore the notifications sent on the main DCCH except that a RR-STATUS message shall be sent to the network with cause #97, "message not existent or not implemented".

Upon receipt of every notification message a mobile station supporting VGCS listening or VBS listening shall give an indication containing the notified group call reference(s) to upper layers in the mobile station which may then decide:

- not to react on the notification; or
- join the voice broadcast call or the voice group call, if needed after having stopped on going activities.

#### 3.3.3.2 Joining a VGCS or VBS call

In order to join a VGCS or a VBS call the following procedures apply.

In this sub-clause, the term **notification** refers to the notification which has triggered the decision to join a VGCS or VBS call.

If the notification on the main DCCH concerns a VBS or VGCS in the current cell and does not contain a description of the VGCS or VBS channel, the mobile station shall read the corresponding notification on the NCH.

If the description of the VGCS or VBS channel was included in the notification for the current cell, RR connection establishment shall not be initiated, instead, the mobile station shall enter the group receive mode.

If no description for the VGCS or VBS channel is included in the notification, the mobile station shall establish a RR connection in dedicated mode in order to initiate the notification response procedure.

#### 3.3.3.3 Reduced NCH monitoring mechanism

This sub-clause applies to mobile stations which read the NCH in idle mode in order to receive the notification messages for the voice broadcast call and the voice group call, which read the PCH to receive pagings and which aim at reducing the reception load.

A reduced NCH monitoring mechanism may be used on the NCH. When the mobile station in idle mode enters a cell and deduces from the BCCH that an NCH is present, it shall read the NCH until it has received at least two messages on the NCH indicating NLN, with the two last received NLN being identical. Then it may stop reading the NCH until it receives on the PCH an NLN(PCH) different from the last previously received NLN or on the SACCH an NLN(SACCH) different from the last previously received NLN.

A mobile is able to determine the reduced NCH monitoring is active in the network if it receives an NLN in any message. Once received, the mobile shall assume that NCH monitoring is active for a certain period of time which is not specified.

For this, parameters are provided:

- NLN: Notification List Number;

The NLN is a modulo 4 counter which is changed every time a notification for a new VGCS or VBS call is started on the NCH. If the reduced NCH monitoring is indicated, the NLN provides information on new notifications provided on the NCH.

- NLN status:

The NLN status is a single bit field which indicates the status of the content of the NOTIFICATION/NCH messages for a particular NLN value. A change of the NLN status field indicates a change of information on the NCH which is not related to new calls (e.g. There may have been a release of a previous notified call or change of priority, etc ...).

If the reduced NCH monitoring is active in the network, the network has to provide both NLN and NLN status parameters.

These parameters may be provided on the NCH, PCH and SACCH:

- NLN(NCH): Notification List Number (received on the NCH).
- NLN(PCH): Notification List Number (received on the PCH).
- NLN(SACCH): Notification List Number (received on the SACCH).
- NLN status(PCH): NLN status (received on the PCH).

- NLN status(SACCH): NLN status (received on the SACCH).

A mobile station supporting neither VGCS listening nor VBS listening shall ignore the NLN(NCH), NLN(PCH), NLN(SACCH) and NLN status fields.

If a mobile station (supporting VGCS listening and/or VBS listening) receives a NLN parameters on the NLN(PCH) or NLN(SACCH) field different from the last received NLN value it shall read the NCH until it has received at least two messages on the NCH indicating NLN with the two last received NLN being identical.

If a message in the paging subchannel is not received correctly, or if a paging message does not contain the information on the notification status, the mobile station shall read the NCH until it has received at least two messages on the NCH indicating NLN, with the two last received NLN being identical.

#### 3.3.3.4 Notification response procedure

In order to initiate the notification response procedure, if access to the network is allowed, the mobile station shall, when camped on a cell as specified in 3GPP TS 03.22, initiate the immediate assignment procedure as specified in 3.3.1. The establishment of the main signalling link is then initiated by use of an SABM with information field containing the NOTIFICATION RESPONSE message (see sub-clause 3.1.5). The MM sublayer in the mobile station is informed that the RR entity has entered the dedicated mode.

Upon receipt of the NOTIFICATION RESPONSE message the network stops timer T3101. The MM sublayer in the network may be informed that an RR connection exists; in this case, the MM sublayer may initiate MM common procedures.

### 3.4 Procedures in dedicated mode and in group transmit mode

Procedures described in this sub-clause apply to the dedicated mode and/or the group transmit mode.

Those procedures which are specific for group transmit mode or refer to transitions to the group transmit mode are only applicable for mobile stations supporting VGCS talking.

Direct transition between dedicated mode and group transmit mode is possible in both directions by use of the following procedures:

- Channel assignment procedure;
- Handover procedure;
- Channel mode modify procedure.

### 3.4.1 SACCH procedures

#### 3.4.1.1 General

In dedicated mode and group transmit mode, the SACCH is used in signalling layer at least for measurement results transmission from the mobile station.

The SACCH has the particularity that continuous transmission must occur in both directions at least on the channel carrying the main signalling link. For that purpose, in the mobile station to network direction, measurement result messages are sent at each possible occasion when nothing else has to be sent (see sub-clause 3.4.1.2). Similarly, SYSTEM INFORMATION TYPE 5, 6 and optionally 5bis and 5ter messages are sent in the network to mobile station direction in UI frames when nothing else has to be sent.

In a multislot configuration the SYSTEM INFORMATION TYPE 5, 6 and optionally 5bis and 5ter messages shall be sent on the SACCH associated with the channel carrying the main signalling link.

In a multislot configuration the mobile station shall ignore all messages received on the SACCH(s) that are not associated with the channel carrying the main signalling link.

On a VGCS channel, the network may send additional or alternative system information messages for both mobile stations in group transmit mode and those in group receive mode (see sub-clause 3.4.15.2.1).

A mobile station with extended measurement capabilities which receives EXTENDED MEASUREMENT ORDER (EMO) messages on the SACCH, shall perform and report extended measurements, see sub-clause 3.4.1.3.

The SYSTEM INFORMATION TYPE 5bis message shall be sent if and only if the EXT IND bit in the Neighbour Cell Description information element in both the SYSTEM INFORMATION TYPE 5 and TYPE 5bis messages indicates that each information element only carries part of the BA.

A GSM 900 mobile station which only supports the primary GSM band P-GSM 900 (cf. 3GPP TS 05.05) may consider the EXT-IND bit in the Neighbour Cells Description IE in the SYSTEM INFORMATION TYPE 5 message bit as a spare bit, assume that the information element carries the complete BA, and ignore any SYSTEM INFORMATION TYPE 5bis messages.

NOTE: The network should take into account limitations of certain mobile stations to understand SYSTEM INFORMATION TYPE 5ter and TYPE 5bis messages, the EXT-IND bit in the Neighbour Cells Description, and formats used in the Neighbour Cells Description information element and Cell Channel Description information element used in SYSTEM INFORMATION messages, see sub-clause 10.5.2.1b, and sub-clause 10.5.2.22.

As specified in 3GPP TS 05.08, problems occurring in the reception of SACCH frames are interpreted as a loss of communication means and appropriate procedures are then triggered as specified in sub-clause 3.4.13.

#### 3.4.1.2 Measurement report

When in dedicated mode or group transmit mode, the mobile station regularly sends MEASUREMENT REPORT messages to the network. These messages contain measurement results about reception characteristics from the current cell and from neighbour cells. The BA (list) which is the basis for the measurements is derived from information received on the BCCH in System Information 2 and optionally 2bis and/or 2ter and on the SACCH in System Information 5 and optionally 5bis and/or 5ter.

When the information is received in more than one message the mobile station shall only combine information from messages received on the same channel and indicating the same value of the BCCH allocation sequence number without any message indicating a different value of the BCCH allocation sequence number received in between. If neighbouring cell information for the serving cell is not available, the mobile station indicates this in the MEASUREMENT REPORT message. These measurement results are obtained as specified in 3GPP TS 05.08.

These messages are sent on the slow ACCH, in unacknowledged mode.

If no other message is scheduled on the SACCH at the instant when a layer 2 frame is due to be sent, then the mobile station shall send a MEASUREMENT REPORT message or an EXTENDED MEASUREMENT REPORT message (see sub-clause 3.4.1.3) in that frame. The interval between two successive layer 2 frames containing measurement report messages shall not exceed one layer 2 frame.

#### 3.4.1.3 Extended measurement report \$(MAFA)\$

Only applicable to mobile stations which support extended measurement.

When in dedicated mode or group transmit mode, a mobile station may receive an EXTENDED MEASUREMENT ORDER (EMO) message, from the network. The mobile station shall then, as defined in 3GPP TS 05.08, for one reporting period perform measurements on the frequencies specified by this EMO message. The mobile station shall thereafter send an EXTENDED MEASUREMENT REPORT message. This message contains the measurement results as defined in 3GPP TS 05.08.

If the mobile station has not started to send its EXTENDED MEASUREMENT REPORT within 10 seconds after the reception of the EMO message, no EXTENDED MEASUREMENT REPORT shall be sent. The mobile station shall after a successful channel change abort any pending measurements or reporting related to an EMO message received on the old channel.

If a mobile station receives an EMO message indicating the same value of the sequence code as an EMO message received earlier on the same channel without having received any EMO message indicating a different value of the sequence code in between, that EMO message shall be ignored. If the mobile station, before the reporting related to an EMO message has started, receives a new EMO message with a different value of the sequence code, any pending measurements or reporting related to the earlier EMO message shall be aborted and the new message treated.

The EMO message and the EXTENDED MEASUREMENT REPORT message are sent on the SACCH, in unacknowledged mode.

### 3.4.2 Transfer of messages and link layer service provision

When in dedicated mode or in group transmit mode, upper layers can send messages in multiframe or unacknowledged mode on SAPI 0.

Moreover, but only when in dedicated mode, upper layers have access to the full link layer services for SAPIs other than 0, with the exception of the error indication and local end release that are directly treated by the RR sublayer, as specified in particular places of sub-clause 3.

### 3.4.3 Channel assignment procedure

In dedicated mode or in group transmit mode, an intracell change of channel can be requested by upper layers for changing the channel type, or decided by the RR sublayer, e.g. for an internal handover. This change may be performed through the dedicated channel assignment procedure.

The purpose of the channel assignment procedure is to completely modify the physical channel configuration of the mobile station without frequency redefinition or change in synchronization while staying in the same cell.

This procedure shall not be used for changing between dependent configurations, i.e. those sharing Radio Resource for the main signalling link. An example of dependent channels is a full rate channel and one of the corresponding half rate channels. In multislot operation however, it is allowed to use the same timeslots before and after the assignment, as long as the main signalling link has been changed. The only procedures provided for changing between dependent configurations for the main signalling link are the additional assignment and the partial release procedures.

The channel assignment procedure happens only in dedicated mode and in group transmit mode. This procedure cannot be used in the idle mode; in this case the immediate assignment procedure is used.

The channel assignment procedure includes:

- the suspension of normal operation except for RR management (layer 3).
- the release of the main signalling link, and of the other data links as defined in sub-clause 3.1.4, and the disconnection of TCHs if any.
- the deactivation of previously assigned channels (layer 1).
- the activation of the new channels and their connection if applicable.
- The triggering of the establishment of the data link connections for SAPI = 0.

The channel assignment procedure is always initiated by the network.

#### 3.4.3.1 Channel assignment initiation

The network initiates the channel assignment procedure by sending an ASSIGNMENT COMMAND message to the mobile station on the main signalling link. It then starts timer T3107.

NOTE: The network should take into account limitations of certain mobile stations to understand formats used in the Frequency List IE and Cell Channel Description IE used in the ASSIGNMENT COMMAND message, see sub-clause 10.5.2.13 and sub-clause 10.5.2.1b.

When sending this message on the network side, and when receiving it on the mobile station side, all transmission of signalling layer messages except for those RR messages needed for this procedure and for abnormal cases is suspended until resumption is indicated. These RR messages can be deduced from sub-clauses 3.4.3 and 8.8 Radio Resource management.

Upon receipt of the ASSIGNMENT COMMAND message, the mobile station initiates a local end release of link layer connections, disconnects the physical channels, commands the switching to the assigned channels and initiates the establishment of lower layer connections (this includes the activation of the channels, their connection and the establishment of the main signalling links).

The ASSIGNMENT COMMAND message contains the description of the new configuration, including for the multislot configuration and the TCH/H + TCH/H + ACCHs configuration, the exact ACCHs to be used and a power command. The power level defined in this power command shall be used by the mobile station for the initial power on the new channel(s). It shall not affect the power used on the old channel(s). The message may also contain definitions of the channel mode to be applied for one or several channel sets. If a previously undefined channel set is defined by the ASSIGNMENT COMMAND message, a definition of the channel mode for the new channel set shall be included in the message.

If the channel mode to be applied corresponds to an initial assignment of a multi-rate speech codec, the ASSIGNMENT COMMAND message shall contain the MultiRate Configuration IE, which defines the set of codec modes and related information to use on the new channel.

If the assignment is related to an intra-cell handover from a multi-rate speech codec to a multi-rate speech codec, the MultiRate Configuration IE shall be included in the case of full rate to half rate. If not included in this case, the mobile station shall behave as if the MultiRate Configuration IE was inconsistent. If not included in other cases, the MS shall use on the new channel the AMR configuration it was using on the old channel when it received the ASSIGNMENT COMMAND message.

An ASSIGNMENT COMMAND message may indicate a frequency change in progress, with a starting time and possibly alternative channel descriptions.

In the case of the reception of an ASSIGNMENT COMMAND message which contains only the description of a channel to be used after the starting time, the mobile station shall wait up to the starting time before accessing the channel. If the starting time has already elapsed, the mobile shall access the channel as an immediate reaction to the reception of the message (see 3GPP TS 05.10 for the timing constraints).

If the message contains both the description of a channel to be used after the indicated time and of a channel to be used before, the mobile station accesses a channel as an immediate reaction to the reception of the message. If the moment the mobile station is ready to access is before the indicated time, the mobile station accesses the channels described for before the starting time. The mobile station then changes to the channel described for after the starting time at the indicated time. New parameters can be frequency list, MAIO and HSN. Other parameters describing the allocated channels must be identical to the parameters described for before the starting time. If the moment the mobile station is ready to access is after the starting time, the mobile station accesses the channel described for after the starting time.

If frequency hopping is applied, the cell allocation if present in the message is used to decode the mobile allocation. If the cell allocation is not included, the mobile station uses its current cell allocation, the current CA is the last CA received on the BCCH. Afterward, the current CA may be changed by some messages sent on the main signalling link containing a CA (the possible messages are: ASSIGNMENT COMMAND, HANDOVER COMMAND and FREQUENCY REDEFINITION). Note that there are cases in which the current CA is undefined, see sub-clause 3.4.3.3.

The ASSIGNMENT COMMAND message may contain a cipher mode setting IE. In that case, this ciphering mode has to be applied on the new channel. If no such information is present, the ciphering mode is the same as on the previous channel. In either case the ciphering key shall not be changed. The ASSIGNMENT COMMAND message shall not contain a cipher mode setting IE that indicates "start ciphering" unless a CIPHERING MODE COMMAND message has been transmitted earlier in the RR connection: if such an ASSIGNMENT COMMAND message is received it shall be regarded as erroneous, an ASSIGNMENT FAILURE with cause "Protocol error unspecified" message shall be returned immediately, and no further action taken.

In a voice group call, the ASSIGNMENT COMMAND message may contain a VGCS target mode information element defining which RR mode is to be used on the new channel (i.e. dedicated mode or group transmit mode). If this information element is not present, the mode shall be assumed to be the same as on the previous channel. The VGCS target mode information element shall also indicate the group cipher key number for the group cipher key to be used on the new channel or if the new channel is non ciphered. If the information element is not present, the ciphering mode and group cipher key shall be the same as on the previous channel. Mobile stations not supporting VGCS talking shall ignore the ASSIGNMENT COMMAND message if the VGCS target mode information element is included in the message and shall send an RR STATUS message to the network with cause #96. If a VGCS target mode information element and a cipher mode setting information element is included in the same message, then a mobile station supporting VGCS talking mobile shall regard the ASSIGNMENT COMMAND message as erroneous, an ASSIGNMENT FAILURE message with cause "Protocol error unspecified" shall be returned immediately, and no further action taken.

#### 3.4.3.2 Assignment completion

After the main signalling link is successfully established, the mobile station returns an ASSIGNMENT COMPLETE message, specifying cause "normal event", to the network on the main DCCH.

The sending of this message on the mobile station side and its receipt on the network side allow the resumption of the transmission of signalling layer messages other than those belonging to RR management.

At the receipt of the ASSIGNMENT COMPLETE message, the network releases the previously allocated resources and stops timer T3107.

#### 3.4.3.3 Abnormal cases

If the mobile station has no current CA and if it needs a CA to analyse the ASSIGNMENT COMMAND message, it stays on the current channel(s) and sends an ASSIGNMENT FAILURE message with cause "no cell allocation available".

If the ASSIGNMENT COMMAND message instructs the mobile station to use a Channel Description or Mode that it does not support, or if the Channel Mode to use is not defined for all channel sets, then the mobile station shall return an ASSIGNMENT FAILURE message with cause "channel mode unacceptable", and the mobile station shall remain on the current channel(s) and uses the old Channel Description or Channel Mode(s).

If the mobile station receives an ASSIGNMENT COMMAND message containing an inconsistent MultiRate Configuration IE, then the mobile station shall return an ASSIGNMENT FAILURE message with cause "channel mode unacceptable", and the mobile station shall remain on the current channel(s) and uses the old Channel Description or Channel Mode(s).

The MultiRate Configuration IE shall be considered as inconsistent by the MS if:

- the active set does not include any codec mode or the active set includes more than four codec modes; or
- one or more codec modes of the active codec set are not supported by the assigned channel; or
- the threshold and hysteresis values are not set according to requirements given in 3GPP TS 05.09.

If during the initial assignment of the multirate speech the mobile station receives an ASSIGNMENT COMMAND message and the MultiRate Configuration IE is not present, then the mobile station shall return an ASSIGNMENT FAILURE message with cause "channel mode unacceptable", and the mobile station shall remain on the current channel(s) and uses the old Channel Description or Channel Mode(s).

If the ASSIGNMENT COMMAND message instructs the mobile station to use a frequency that it is not capable of, then the mobile station shall return an ASSIGNMENT FAILURE message with cause "frequency not implemented", and the mobile station shall remain on the current channel(s).

If the mobile station receives an ASSIGNMENT COMMAND message with a Frequency List IE indicating frequencies that are not all in one band, then the mobile station shall stay on the current channel(s) and send an ASSIGNMENT FAILURE message with cause "frequency not implemented". If the mobile station receives an ASSIGNMENT COMMAND message with a Mobile Allocation IE indexing frequencies that are not all in one band, then the mobile station shall stay on the current channel(s) and send an ASSIGNMENT index (s) and send an ASSIGNMENT FAILURE message with cause "frequency not implemented".

NOTE: An ASSIGNMENT COMMAND message sent to a multi band mobile station shall not be considered invalid because it indicates frequencies that are all in a different frequency band to that of the current channel.

On the mobile station side, if a lower layer failure happens on the new channel before the ASSIGNMENT COMPLETE message has been sent, the mobile station deactivates the new channels, reactivates the old channels, reconnects the TCHs if any and triggers the establishment of the main signalling link. It then sends a ASSIGNMENT FAILURE message, cause "protocol error unspecified" on the main DCCH and resumes the normal operation, as if no assignment attempt had occurred. The operational parameters (e.g. ciphering mode) when returning on the old channel are those applied before the procedure.

When receiving the ASSIGNMENT FAILURE message, the network stops T3107.

If a lower layer failure happens while attempting to connect back to the old channels, the radio link failure procedure is applied (see sub-clause 3.4.13.2 for dedicated mode and sub-clause 3.4.13.5 for group transmit mode).

On the network side, if timer T3107 elapses before either the ASSIGNMENT COMPLETE message has been received on the new channels or an ASSIGNMENT FAILURE message is received on the old channels, the old channels and the new channels are released if they both were dedicated channels and, unless the mobile station has re-established the call, all contexts related to the connections with that mobile station are cleared. If one of the channels was a VGCS channel, it shall be maintained and the uplink shall be set free. If both channels were VGCS channels, the network shall maintain one of the channels and the uplink shall be set free.

On the network side, lower layer failure occurring on the old channels after the sending of the ASSIGNMENT COMMAND message are ignored. Lower layer failures occurring after the receipt of the SABM Frame on the new main signalling link are treated following the general rules (cf. sub-clause 3.5.2).

### 3.4.4 Handover procedure

In dedicated mode or group transmit mode, an intercell or intracell change of channel(s) can be requested by the network RR sublayer. This change may be performed through the handover procedure.

NOTE: The decision to do a handover and the choice of the new cell is out of the scope of the present document.

The purpose of the handover procedure is to completely modify the channels allocated to the mobile station e.g. when the cell is changed. A change in the channel configuration nature is possible. This procedure is used only while in dedicated mode or group transmit mode.

The handover procedure is also used by Location Services as described in 3GPP TS 03.71.

The handover procedure shall not be used for changing between dependent configurations (see sub-clause 3.4.3). An exception to this is when the handover procedure is used by Location Services. In this case the mobile may be commanded to attempt a handover to the same channel as currently assigned to the MS. The MS shall attempt to perform a handover to this unchanged channel, which includes the transmission of access bursts.

The handover procedure includes:

- The suspension of normal operation except for RR management (layer 3).
- The disconnection of the main signalling link, and of the other links via local end release (layer 2), and the disconnection of the TCH(s) if any.
- The disconnection and the deactivation of previously assigned channels and their release (layer 1).
- The activation of the new channels, and their connection if applicable.
- The triggering of the establishment of data link connection for SAPI = 0 on the new channels.

The handover procedure is always initiated by the network.

#### 3.4.4.1 Handover initiation

The network initiates the handover procedure by sending a HANDOVER COMMAND message to the mobile station on the main DCCH. It then starts timer T3103.

NOTE: The network should take into account limitations of certain mobile stations to understand formats used in the Frequency List IE, Frequency Short List IE, and Cell Channel Description IE used in the HANDOVER COMMAND message, see sub-clause 10.5.2.13, sub-clause 10.5.2.14, and sub-clause 10.5.2.1b.

When sending this message on the network side, and when receiving it on the mobile station side, all transmission of signalling layer messages except for those RR messages needed for this procedure and for abnormal cases, is suspended until resuming is indicated. These RR messages can be deduced from sub-clause 3.4.3 and 8.5.1 "Radio Resource management".

Upon receipt of the HANDOVER COMMAND message, the mobile station initiates, as described in sub-clause 3.1.4, the release of link layer connections, disconnects the physical channels, commands the switching to the assigned

channels and initiates the establishment of lower layer connections (this includes the activation of the channels, their connection and the establishment of the data links).

The HANDOVER COMMAND message contains:

- The characteristics of the new channels, including for the multislot configuration and the TCH/H + TCH/H + ACCHs configuration the exact ACCHs to be used. The message may also contain definitions of the channel mode to be applied for one or several channel sets. If a previously undefined channel set is defined by the HANDOVER COMMAND message, a definition of the channel mode for the new channel set shall be included in the message.
- The characteristics of the new cell that are necessary to successfully communicate (e.g. frequency list in the case of slow frequency hopping), including the data that allows the mobile station to use the pre-knowledge about synchronization it acquires by the measurement process (i.e. BSIC + BCCH frequency).
- A power command (cf. 3GPP TS 05.08). The power level defined in this power command shall be used by the mobile station for the initial power on the new channel(s). It shall not affect the power used on the old channel(s).
- An indication of the physical channel establishment procedure to be used.
- A handover reference, used as specified in the following sub-clause. The choice of the handover reference by the network is out of the scope of the present document and left to the manufacturers.
- Optionally a timing advance to be used on the new cell.
- Optionally a cipher mode setting. In that case, this ciphering mode has to be applied on the new channel. If no such information is present, the ciphering mode is the same as on the previous channel. In either case the ciphering key shall not be changed. The HANDOVER COMMAND message shall not contain a cipher mode setting IE that indicates "start ciphering" unless a CIPHERING MODE COMMAND message has been transmitted previously in this instance of the dedicated mode: if such a HANDOVER COMMAND message is received it shall be regarded as erroneous, a HANDOVER FAILURE message with cause "Protocol error unspecified" shall be returned immediately, and no further action taken.
- Optionally, in a voice group call, a VGCS target mode information element defining which RR mode is to be used on the new channel (i.e. dedicated mode or group transmit mode). If this information element is not present, the mode shall be assumed to be the same as on the previous channel. The VGCS target mode information element shall also indicate the group cipher key number for the group cipher key to be used on the new channel or if the new channel is non ciphered. If the information element is not present, the ciphering mode and ciphering key shall be the same as on the previous channel. Mobile stations not supporting VGCS talking shall ignore the HANDOVER COMMAND message if the VGCS target mode information element is included in the message and shall send an RR STATUS message to the network with cause #96. If a VGCS target mode information element and a cipher mode setting information element is included in the same message, then a mobile station supporting VGCS talking shall regard the HANDOVER COMMAND message as erroneous, an HANDOVER FAILURE message with cause "Protocol error unspecified" shall be returned immediately, and no further action taken.
- Optionally, when the channel mode indicates that a multi-rate speech codec must be applied, the MultiRateconfiguration to be used in the new cell. The MultiRate Configuration IE defines the set of codec mode and related information to use after the handover. When accessing the new channel, the mobile station shall use for the Initial Codec Mode the mode specified in the MultiRate Configuration IE, if present, or apply by default the implicit rule defined in 3GPP TS 05.09.

In addition, a HANDOVER COMMAND message may indicate a frequency change in progress, with a starting time and possibly alternative channel descriptions.

In the case of the reception of a HANDOVER COMMAND message which contains only the description of a channel to be used after the starting time, the mobile station shall wait up to the starting time before accessing the channel. If the starting time has already elapsed, the mobile shall access the channel as an immediate reaction to the reception of the message (see 3GPP TS 05.10 for the timing constraints).

If the message contains both the description of a channel to be used after the indicated time and of a channel to be used before, the mobile station accesses a channel as an immediate reaction to the reception of the message. If the moment the mobile station is ready to access is before the indicated time, the mobile station accesses the channels described for

before the starting time. The mobile station then changes to the channel described for after the starting time at the indicated time. New parameters can be frequency list, MAIO and HSN. Other parameters describing the allocated channels must be identical to the parameters described for before the starting time. If the moment the mobile station is ready to access is after the starting time, the mobile station accesses the channel described for after the starting time.

If the channel mode indicates that a multi-rate speech codec must be applied, and the MultiRateConfiguration IE is not included in the HANDOVER COMMAND message, then the mobile station shall use on the new channel the AMR configuration it was using on the old channel when it received the HANDOVER COMMAND message. The MultiRate Configuration IE shall be included in the case of full rate channel to half rate channel handover. If not included in this case, the mobile station shall behave as if the MultiRate Configuration IE was inconsistent.

#### 3.4.4.2 Physical channel establishment

Four procedures are defined. The support of three of them is mandatory in the mobile station. The pseudosynchronization case is optional in the mobile station. A pseudo-synchronized handover can be commanded only to a mobile station that can support it, as indicated in the classmark.

#### 3.4.4.2.1 Finely synchronized cell case

If the mobile station knows that the timing advance with the new cell is not out of range, i.e. smaller than or equal to the maximum timing advance that can be coded as specified in 3GPP TS 04.04, or if the new cell does accept out of range timing advance as indicated in the HANDOVER COMMAND message, the mobile station proceeds as follows.

After having switched to the assigned channels, the mobile station sends four times the HANDOVER ACCESS message in four successive layer 1 frames on the main DCCH. This message is sent in an access burst. Its content is reduced to the handover reference information element. The transmission of these four messages is optional if so indicated by the network in the HANDOVER COMMAND message.

Before completion of the 4 access bursts on the DCCH, additional access bursts may also be sent on the SACCH.

It then activates the channels in sending and receiving mode and connects the channels if need be.

If applicable, ciphering is immediately started . The access bursts are not ciphered.

#### 3.4.4.2.2 Non synchronized cell case

After having switched to the assigned channels, the mobile station starts repeating the HANDOVER ACCESS message in successive layer 1 frames on the main DCCH and optionally on the SACCH. This message is sent in an access burst. Its content is reduced to the handover reference information element. The mobile station starts timer T3124 at the start point of the timeslot in which the HANDOVER ACCESS message is sent the first time on the main DCCH.

The mobile station then activates the channels in receiving mode and connects the channels if need be (only for reception).

If applicable, deciphering is then immediately started . The access bursts are not ciphered.

When the network has the RF characteristics that are necessary, it sends in unacknowledged mode a PHYSICAL INFORMATION message to the mobile station on the main DCCH. If applicable, ciphering and deciphering is immediately started (i.e., before even the reception of a correct access burst), and the message is sent enciphered.

The PHYSICAL INFORMATION message contains various physical layer related information, allowing a proper transmission by the mobile station.

When sending the PHYSICAL INFORMATION message, the network starts timer T3105. If this timer times out before the reception of a correctly decoded layer 2 frame in format A or B (see 3GPP TS 04.06), or a correctly decoded TCH frame from the mobile station, the network repeats the PHYSICAL INFORMATION message and restarts timer T3105. The maximum number of repetitions is Ny1.

The correct decoding of a frame means that the decoding algorithm and the error detection tests, if any, indicate no error.

When the mobile station receives a PHYSICAL INFORMATION message, it stops timer T3124, stops sending access bursts, activates the physical channels in sending and receiving mode and connects the channels if need be. If the

allocated channel is an SDCCH (+ SACCH), performance of the mobile station must enable the mobile station to accept a correct PHYSICAL INFORMATION message sent by the network in any block while T3124 is running.

#### 3.4.4.2.3 Pseudo-synchronized cell case

The details of the use of this procedure are described in 3GPP TS 05.10. The mobile station computes the timing advance to be used with the new cell from the real time difference value given in the HANDOVER COMMAND message. If the mobile station knows that the timing advance with the new cell is not out of range , i.e. smaller or equal to the maximum timing advance that can be coded as specified in 3GPP TS 04.04, or if the new cell accepts an out of range timing advance as indicated in the HANDOVER COMMAND message, the mobile station switches to the new channel and proceeds as follows.

After having switched to the assigned channels, the mobile station sends in four successive slots on the main DCCH a HANDOVER ACCESS message. This message is sent in random mode and thus does not follow the basic format. Its content is reduced to the handover reference information element. The transmission of these four messages is optional if so indicated by the network in the HANDOVER COMMAND message.

Before completion of the 4 access bursts on the DCCH, additional access bursts may also be sent on the SACCH.

The mobile station then activates the channels in sending and receiving mode and connects the channels if need be. The mobile station may activate the channels in receiving mode and connect the channels while sending access bursts.

If applicable, ciphering is then immediately started. The access bursts are not ciphered.

#### 3.4.4.2.4 Pre-synchronized cell case

The details of the use of this procedure are described in 3GPP TS 05.10. The mobile station switches to the new channel and proceeds as follows.

After having switched to the assigned channels, the mobile station sends in four successive slots on the main DCCH a HANDOVER ACCESS message. This message is sent in an access burst and thus does not follow the basic format. Its content is reduced to the handover reference information element. The transmission of these four messages is optional if so indicated by the network in the HANDOVER COMMAND message.

Before completion of the 4 access bursts on the DCCH, additional access bursts may also be sent on the SACCH.

The mobile station then activates the channel in sending and receiving mode and connects the channels if need be. The timing advance value to be used with the new cell is:

- either the value contained in the HANDOVER COMMAND message if the timing advance information element is present;
- or the default value for pre-synchronized handover as defined in 3GPP TS 05.10, if the timing advance information element is not included in the HANDOVER COMMAND message. The MS may activate the channels in receiving mode and connect the channels while sending access bursts.

If applicable, ciphering is immediately started. The access bursts are not ciphered.

#### 3.4.4.3 Handover completion

After lower layer connections are successfully established, the mobile station returns a HANDOVER COMPLETE message, specifying cause "normal event", to the network on the main DCCH.

The sending of this message on the mobile station side and its receipt on the network side allow the resumption of the transmission of signalling layer messages other than those for RR management.

When receiving the HANDOVER COMPLETE message, the network stops timer T3103 and releases the old channels.

If requested to do so in the HANDOVER COMMAND message, the mobile station includes the observed time difference it has measured when performing the handover, corrected by half the timing advance, in the HANDOVER COMPLETE message (detailed specifications are given in 3GPP TS 05.10).

### 3.4.4.4 Abnormal cases

In the case of a synchronous or pseudo-synchronous handover, if the mobile station knows that the timing advance with the new cell is out of range, i.e. is bigger than the maximum timing advance that can be coded as specified in 3GPP TS 04.04, and if the new cell does not accept out of range timing advance as indicated in the HANDOVER COMMAND message, the mobile station sends a HANDOVER FAILURE message, cause "handover impossible, timing advance out of range", on the main signalling link and does not attempt that handover.

If the HANDOVER COMMAND message instructs the mobile station to use a Channel Description or Mode that it does not support, or if the Channel Mode to use is not defined for all channel sets, then the MS shall return a HANDOVER FAILURE message with cause "channel mode unacceptable", and the MS shall remain on the current channel(s) and uses the old Channel Description or Mode(s).

If the mobile station receives a HANDOVER COMMAND message containing an inconsistent MultiRateConfiguration IE, then the mobile station shall return a HANDOVER FAILURE message with cause "channel mode unacceptable", and the mobile station shall remain on the current channel(s) and uses the old Channel Description or Mode(s).

The MultiRate Configuration IE shall be considered as inconsistent by the MS if:

- the active set does not include any codec mode or the active set includes more than four codec modes; or
- one or more codec modes of the active codec set are not supported by the assigned channel; or
- the threshold and hysteresis values are not set according to requirements given in 3GPP TS 05.09.

If the HANDOVER COMMAND message instructs the mobile station to use a frequency that it is not capable of, then the mobile station shall return a HANDOVER FAILURE message with cause "frequency not implemented", and the mobile station shall remain on the current channel(s).

If the mobile station receives a HANDOVER COMMAND message with a Frequency List IE or Frequency Short List IE indicating frequencies that are not all in one band, then the mobile station shall stay on the current channel(s) and send a HANDOVER FAILURE message with cause "frequency not implemented". If the mobile station receives a HANDOVER COMMAND message with a Mobile Allocation IE indexing frequencies that are not all in one band, then the mobile station shall stay on the current channel(s) and send a HANDOVER FAILURE message with a Mobile Allocation IE indexing frequencies that are not all in one band, then the mobile station shall stay on the current channel(s) and send a HANDOVER FAILURE message with cause "frequency not implemented".

NOTE: A HANDOVER COMMAND message sent to a multi band mobile station shall not be considered invalid because it indicates target channel frequencies that are all in a different frequency band to that of the ARFCN in the Cell Description IE.

On the mobile station side, if timer T3124 times out (only in the non- synchronized case) or if a lower layer failure happens on the new channel before the HANDOVER COMPLETE message has been sent, the mobile station deactivates the new channels, reactivates the old channels, reconnects the TCHs if any and triggers the establishment of the main signalling link. It then sends a HANDOVER FAILURE message on the main signalling link and resumes normal operation as if no handover attempt had occurred. The operational parameters (e.g. ciphering mode) when returning on the old channel are those applied before the HANDOVER COMMAND message was received.

When the HANDOVER FAILURE message has been received, the network releases the new channels if they were dedicated channels and stops timers T3105 and stops T3103 in the non-synchronized case. If the new channels were VGCS channels, they shall be maintained.

If a lower layer failure happens while attempting to connect back to the old channels, the standard rules are applied (cf. sub-clause 3.4.13.2 for dedicated mode and 3.4.13.5 for group transmit mode).

On the network side, if timer T3103 elapses before either the HANDOVER COMPLETE message is received on the new channels, or a HANDOVER FAILURE message is received on the old channels, or the mobile station has reestablished the call, the old channels are released if they were dedicated channels and all contexts related to the connections with that mobile station are cleared. If the old channel was a VGCS channel, it shall be maintained and the uplink shall be set free.

On the network side, if neither a correctly layer 2 frame in format A or B nor a correctly TCH frame have been received from the mobile station on the new channel, the newly allocated channels are released if they were dedicated channels. If the new channels were VGCS channels, they shall be maintained and the uplink shall be set free.

On the network side, lower layer failures occurring on the old channels after the sending of the HANDOVER COMMAND message are ignored. Lower layer failures occurring after the receipt of the SABM frame on the new main signalling link are treated following a general scheme (cf. sub-clause 3.4.13.2 for dedicated mode and sub-clause 3.4.13.5 for group transmit mode).

### 3.4.5 Frequency redefinition procedure

In dedicated mode and group transmit mode, this procedure is used by the network to change the frequencies and hopping sequences of the allocated channels. This is meaningful only in the case of frequency hopping.

The network sends to the mobile station a FREQUENCY REDEFINITION message containing the new parameters together with a starting time indication.

NOTE: The network should take into account limitations of certain mobile stations to understand formats used in the Cell Channel Description IE used in the FREQUENCY REDEFINITION message, see sub-clause 10.5.2.13.

When receiving such a message, the mobile station modifies the frequencies/hopping sequences it uses at the exact indicated time slot, i.e. the indicated time slot is the first with new parameters. All other functions are not disturbed by this change. New parameters can be the cell channel description, the mobile allocation and the MAIO. In case of multislot configuration, the Channel Description IE shall describe the channel carrying the main signalling link, the new parameters however, shall be used for all assigned timeslots. Other parameters describing the allocated channels must be identical to the current parameters.

#### 3.4.5.1 Abnormal cases

If the mobile station receives a FREQUENCY REDEFINITION message with a Mobile Allocation IE indexing frequencies that are not all in one band and a Starting Time IE indicating a time that has not elapsed, then the mobile station shall stay on the current channel(s) and send a RR STATUS message with cause "frequency not implemented".

If the mobile station receives a FREQUENCY REDEFINITION message with a Mobile Allocation IE indexing frequencies that are not all in one band and a Starting Time IE indicating a time that has elapsed, then the mobile station shall locally abort the radio connection and, if permitted, attempt Call Re-establishment.

If the mobile station receives a FREQUENCY REDEFENITION message on a channel for which it has a pending redefinition (defined by the immediate assignment, assignment or handover procedure or a previous frequency redefinition procedure) the frequencies, hopping and starting time parameters defined by the new frequency redefinition procedure supersedes those of the pending one.

NOTE: A FREQUENCY REDEFINITION message sent to a multi band mobile station shall not be considered invalid because it indicates new frequencies that are all in a different frequency band to that of the ARFCN of the serving cell.

### 3.4.6 Channel mode modify procedure

In dedicated mode or group transmit mode, higher layers can request the setting of the channel mode.

The channel mode modify procedure allows the network to request the mobile station to set the channel mode for one channel or one channel set. The procedure shall not be used if the multislot configuration contains more than one channel set. The channel mode covers the coding, decoding and transcoding mode used on the indicated channel.

This procedure is always initiated by the network.

NOTE: Direct transitions between full rate speech coder version 1 and full rate speech coder version 2 (and vice versa) may cause unpleasant audio bursts.

#### 3.4.6.1 Normal channel mode modify procedure

#### 3.4.6.1.1 Initiation of the channel mode modify procedure

The network initiates the procedure by sending a CHANNEL MODE MODIFY message to the mobile station. This message contains:

- a channel description of the channel(s) on which the mode in the CHANNEL MODE MODIFY message shall be applied; and
- the mode to be used on that channel, or on all the channels of a channel set in a multislot configuration;
- Optionally, when the channel mode indicates that a multi-rate speech codec must be applied, the MultiRateconfiguration to be used. The MultiRateConfiguration IE defines the set of codec mode and related information to use after the mode modify procedure.

If the channel mode is changed from a non multi-rate speech codec to a multi-rate speech codec, the CHANNEL MODE MODIFY message shall contain the MultiRate Configuration IE, which defines the set of codec modes and related information to use as a new mode.

If the old channel mode and the new channel mode are both multi-rate speech codec, the MultiRate Configuration IE may not be present. If not present, the MS shall go on with the current multi-rate speech configuration.

#### 3.4.6.1.2 Completion of channel mode modify procedure

When it has received the CHANNEL MODE MODIFY message, the mobile station sets the mode for the indicated channel, and if that is in a multislot configuration, the whole channel set and then replies by a CHANNEL MODE MODIFY ACKNOWLEDGE message indicating the ordered channel mode.

This applies whether the mode commanded by the CHANNEL MODE MODIFY is different from the one used by the mobile station or whether it is already in use.

#### 3.4.6.1.3 Abnormal cases

If the new mode is multi-rate speech codec and if the MultiRate Configuration IE is inconsistent, the MS shall ignore the CHANNEL MODE MODIFY message and shall not send CHANNEL MODE MODIFY ACKNOWLEDGE message to the network.

No other specific action for a lower layer failure is specified in this sub-clause. If the mobile station does not support the indicated mode, it shall retain the old mode and return the associated channel mode information in the CHANNEL MODE MODIFY ACKNOWLEDGE message.

#### 3.4.6.2 Channel mode modify procedure for a voice group call talker

#### 3.4.6.2.1 Initiation of the channel mode modify procedure

The network initiates the procedure by sending a CHANNEL MODE MODIFY message to the mobile station. This message contains:

- a channel description of the channel on which the CHANNEL MODE MODIFY message is sent; and
- the new channel mode to be used on the channel; and
- optionally, the VGCS target mode information element defining which RR mode is to be used with the new channel mode (i.e. dedicated mode or group transmit mode). If this information element is not present, the RR mode shall be assumed to be the same as with the previous channel mode. The VGCS target mode information element shall also indicate the group cipher key number for the group cipher key to be used on the new channel or if the new channel is non ciphered. If the information element is not present, the ciphering mode and ciphering key shall be the same as with the previous channel mode. Mobile stations not supporting VGCS talking shall ignore the CHANNEL MODE MODIFY message if the VGCS target mode information element is included in the message and shall send an RR STATUS message to the network with cause #96.

The start of ciphering with a group cipher key with the new channel mode is only possible when the mode on the old channel was not ciphered.

If a VGCS target mode information element indicating a group cipher key number is included in the message and the previous mode is not non ciphered and the group cipher key number is different to the previous cipher key number, the mobile station shall behave as if it would not support the indicated channel mode.

#### 3.4.6.2.2 Completion of mode change procedure

When it has received the CHANNEL MODE MODIFY message, the mobile station changes the mode for the indicated channel and then replies by a CHANNEL MODE MODIFY ACKNOWLEDGE message indicating the new channel mode.

#### 3.4.6.2.3 Abnormal cases

No specific action for a lower layer failure is specified in this sub-clause. If the mobile station does not support the indicated mode, it shall retain the old mode and return the associated channel mode information in the CHANNEL MODE MODIFY ACKNOWLEDGE message.

### 3.4.7 Ciphering mode setting procedure

In dedicated mode, the ciphering mode setting procedure is used by the network to set the ciphering mode, i.e. whether or not the transmission is ciphered, and if so which algorithm to use. The procedure shall only be used to change from "not ciphered" mode to "ciphered" mode, or vice-versa, or to pass a CIPHERING MODE COMMAND message to the mobile station while remaining in the "not ciphered" mode. The ciphering mode setting procedure is always triggered by the network and it only applies to dedicated resources.

The cipher mode setting procedure shall not be applied in group transmit mode.

#### 3.4.7.1 Ciphering mode setting initiation

The network initiates the ciphering mode setting procedure by sending a CIPHERING MODE COMMAND message to the mobile station on the main signalling link, indicating whether ciphering shall be used or not, and if yes which algorithm to use.

Additionally, the network may, by the use of the cipher response information element, request the mobile station to include its IMEISV in the CIPHERING MODE COMPLETE message.

The new mode is applied for reception on the network side after the message has been sent.

#### 3.4.7.2 Ciphering mode setting completion

Whenever the mobile station receives a valid CIPHERING MODE COMMAND message, it shall, if a SIM is present and considered valid by the ME and the ciphering key sequence number stored on the SIM indicates that a ciphering key is available, load the ciphering key stored on the SIM into the ME. A valid CIPHERING MODE COMMAND message is defined to be one of the following:

- one that indicates "start ciphering" and is received by the mobile station in the "not ciphered" mode;
- one that indicates "no ciphering" and is received by the MS in the "not ciphered" mode; or
- one that indicates "no ciphering" and is received by the mobile station in the "ciphered" mode.

Other CIPHERING MODE COMMAND messages shall be regarded as erroneous, an RR STATUS message with cause "Protocol error unspecified" shall be returned, and no further action taken.

Upon receipt of the CIPHERING MODE COMMAND message indicating ciphering, the mobile station shall start transmission and reception in the indicated mode.

When the appropriate action on the CIPHERING MODE COMMAND has been taken, the mobile station sends back a CIPHERING MODE COMPLETE message. If the "cipher response" field of the cipher response information element in the CIPHERING MODE COMMAND message specified "IMEI must be included" the mobile station shall include its IMEISV in the CIPHERING MODE COMPLETE message.

Upon receipt of the CIPHERING MODE COMPLETE message or any other correct layer 2 frame which was sent in the new mode, the network starts transmission in the new mode.

mobile station		network
	CIPH MOD CMI	)
start> transmission and reception in new mode	CIPH MOD CON	<pre>&lt; start reception     in new mode     ß     ß 4&gt;</pre>
		< start trans- mission in new mode

Figure 3.3/3GPP TS 04.08: Ciphering mode setting sequence

### 3.4.8 Additional channel assignment procedure

NOTE: In the present state of 3GPP TS 04.03, this procedure is only possible for the TCH/H + ACCHs to TCH/H + TCH/H + ACCHs transition. As a consequence it is not needed for simple mobile stations. The description of the procedure is in general terms to cope with possible evolution.

In dedicated mode, a change of channel configuration to include an additional channel can be requested by upper layers.

The additional channel assignment procedure shall not be applied in group transmit mode.

The purpose of the additional assignment procedure is to allocate an additional dedicated channel to a mobile station while keeping the previously allocated channels. In particular the main DCCH and the SACCH are not modified, and signalling exchanges are not interrupted.

The additional assignment procedure may happen only in dedicated mode. It is used for instance for the transition from the TCH/H + ACCHs configuration to the TCH/H + TCH/H + ACCHs configuration.

The additional assignment procedure is always initiated by the network.

#### 3.4.8.1 Additional assignment procedure initiation

The network initiates the procedure by sending an ADDITIONAL ASSIGNMENT message to the mobile station on the main DCCH. The ADDITIONAL ASSIGNMENT message contains the description of the newly assigned channel.

On receipt of the message, the mobile station activates the new channel.

#### 3.4.8.2 Additional assignment procedure completion

The mobile station sends an ASSIGNMENT COMPLETE message to the network on the channel, on which it receives the ADDITIONAL ASSIGNMENT message.

#### 3.4.8.3 Abnormal cases

A lower layer failure occurring during the procedure is treated according to the general case (see sub-clause 3.4.13.2).

The network considers the channel as allocated from the sending of the ADDITIONAL ASSIGNMENT message. As a consequence, if a re-establishment occurs, the network will consider the context as if the mobile station has received the message, and the new configuration allocated after the re-establishment may differ from the one the mobile station had before the re-establishment.

### 3.4.9 Partial channel release procedure

In dedicated mode, a change of channel configuration to release one channel can be requested by upper layers.

The partial channel release procedure shall not be applied in group transmit mode.

The purpose of this procedure is to deactivate part of the dedicated channels in use. The channel configuration remains dedicated.

NOTE: In the present state of 3GPP TS 04.03, this procedure is only possible for the TCH/H + TCH/H + ACCHs to TCH/H + ACCHs transition. As a consequence it is not needed for simple mobile stations.

The partial release procedure is always initiated by the network.

### 3.4.9.1 Partial release procedure initiation

The network initiates the partial release by sending a PARTIAL RELEASE message to the mobile station on the main DCCH.

On receipt of the PARTIAL RELEASE message the mobile station:

- Initiates the disconnection of all the link layer connections carried by the channel to be released;
- Simultaneously initiates the connection on remaining channels of the data link layer connections that have been released;
- Deactivates the physical channels to be released.
- Sends a PARTIAL RELEASE COMPLETE to the network on the (possibly new) main signalling link.

### 3.4.9.2 Abnormal cases

A lower layer failure is treated following the general rules as specified in sub-clause 3.4.13.2.

Moreover, on the network side, the channel configuration nature is set from the sending of the PARTIAL RELEASE message onward. As a consequence, any new assignment after a re-establishment may concern a different channel configuration nature from the one known by the mobile station before the re-establishment.

### 3.4.10 Classmark change procedure

In dedicated mode or in group transmit mode, this procedure allows the mobile station to indicate to the network a change of characteristics reflected in the classmark (e.g. due to addition of power amplification). Furthermore, a mobile station which implements the "controlled early classmark sending " option may also send a CLASSMARK CHANGE message as described in sub-clause 3.3.1.1.4, even if no change of characteristics has occurred.

The mobile station sends a CLASSMARK CHANGE message to the network. This message contains the new mobile station classmark 2 information element. It may also contain a Classmark 3 Information Element. There is no acknowledgement from the network at layer 3.

### 3.4.11 Classmark interrogation procedure

This procedure allows the network to request additional classmark information from the mobile station (e.g. if the information initially sent by the mobile station is not sufficient for network decisions).

### 3.4.11.1 Classmark interrogation initiation

The network initiates the classmark interrogation procedure by sending a CLASSMARK ENQUIRY message to the mobile station on the main DCCH.

### 3.4.11.2 Classmark interrogation completion

On receipt of the CLASSMARK ENQUIRY message the mobile station sends a CLASSMARK CHANGE message to the network on the main DCCH. This message contains the mobile station classmark 2 information element. It may also contain a Classmark 3 Information Element.

### 3.4.12 Indication of notifications and paging information

Only applicable for mobile stations supporting VGCS listening or VBS listening:

In dedicated mode or in group transmit mode, the RR entity shall provide indications to the upper layer on all received notifications for voice group calls or voice broadcast calls according to the VGCS or VBS subscription data stored in the mobile station. The indication shall include the notified group or broadcast call reference and possibly the related priority, if provided.

In group transmit mode, if the mobile station has received a paging message with the own mobile station identity on the PCH or on the voice group call channel downlink, the RR entity shall provide an indication to the upper layers, together with the related priority, if applicable.

In group transmit mode, if the RR entity receives information on the voice group call channel of the existence of a paging message in its paging subgroup of the PCH, the RR entity shall pass this information to the upper layers together with the related priority if provided (see also sub-clauses 3.3.2 and 3.3.3).

### 3.4.13 RR connection release procedure

#### 3.4.13.1 Normal release procedure

The release of the RR connection can be requested by upper layers.

The purpose of this procedure is to deactivate all the dedicated channels in use. When the channels are released, the mobile station returns to the CCCH configuration, idle mode. The channel release procedure can be used in a variety of cases, including TCH release after a call release, and DCCH release when a dedicated channel allocated for signalling is released.

In dedicated mode and group transmit mode, the channel release procedure is always initiated by the network.

If the mobile station is IMSI attached for GPRS services (sub-clause 4) at release of the RR connection, the mobile station shall return to packet idle mode, or if a temporary block flow is established, continue in packet transfer mode.

# 3.4.13.1.1 Channel release procedure initiation in dedicated mode and in group transmit mode

The network initiates the channel release by sending a CHANNEL RELEASE message to the mobile station on the main DCCH, starts timer T3109 and deactivates the SACCH.

On receipt of a CHANNEL RELEASE message the mobile station starts timer T3110 and disconnects the main signalling link. When T3110 times out, or when the disconnection is confirmed, the mobile station deactivates all channels, considers the RR connection as released, and returns to CCCH idle mode.

NOTE 1: Data Links other than the main signalling link are disconnected by local end link release.

If case of dedicated mode, on the network side, when the main signalling link is disconnected, the network stops timer T3109 and starts timer T3111. When timer T3111 times out, the network deactivates the channels, they are then free to be allocated to another connection.

NOTE 2: The sole purpose of timer T3111 is to let some time to acknowledge the disconnection and to protect the channel in case of loss of the acknowledge frame.

If timer T3109 times out, the network deactivates the channels; they are then free to be allocated to another connection.

The CHANNEL RELEASE message will include an RR cause indication as follows:

#0	if it is a normal release, e.g. at the end of a call or at normal release of a DCCH.
#1	to indicate an unspecified abnormal release.
#2, #3 or #4	to indicate a specific release event.
#5	if the channel is to be assigned for servicing a higher priority call (e.g. an emergency call).
#65	if e.g. a handover procedure is stopped because the call has been cleared.

#### 3GPP TS 04.08 version 7.21.0 Release 1998

The CHANNEL RELEASE message may include the information element BA Range which may be used by a mobile station in its selection algorithm (see 3GPP TS 05.08 and 3GPP TS 03.22).

Mobile stations not supporting VGCS or VBS listening shall consider Group Channel Description and Group Cipher Key Number information elements as unnecessary in the message and perform the channel release procedure as normal.

For mobile stations supporting VGCS listening, the following procedures apply:

The CHANNEL RELEASE message may include the information element Group Channel Description. In this case, the mobile station shall release the layer 2 link, enter the group receive mode and give an indication to the upper layer. If a CHANNEL RELEASE message with no Group Channel Description is received, the normal behaviour applies.

If ciphering is applied on the VGCS or VBS channel, the network shall provide in the CHANNEL RELEASE message with the Group Cipher Key Number information element for the group cipher key to be used by the mobile station for reception of the VGCS or VBS channel. If this information element is not included, no ciphering is applied on the VGCS or VBS channel.

A mobile station not supporting the "GPRS " option shall consider the GPRS Resumption information element as an information element unknown in the message and continue the channel release procedure as normal.

For a mobile station supporting the "GPRS " option, the following additional procedures also apply:

The CHANNEL RELEASE message may include the information element GPRS Resumption. If the GPRS Resumption information element indicates that the network has resumed GPRS services, the RR sublayer of the mobile station shall indicate a RR GPRS resumption complete to the MM sublayer, see clause 4. If the GPRS Resumption information element indicates that the network has not successfully resumed GPRS services, the RR sublayer of the mobile station shall indicate a RR GPRS resumption failure to the MM sublayer, see sub-clause 4.

If the mobile station has performed the GPRS suspension procedure (sub-clause 3.3.1.1.4.2) and the GPRS Resumption information element is not included in the message, the RR sublayer of the mobile station shall indicate a RR GPRS resumption failure to the MM sublayer, see sub-clause 4.

If the mobile station has not performed the GPRS suspension procedure and the GPRS Resumption information element is not included in the message, the mobile station shall continue the channel release procedure as normal.

#### 3.4.13.1.2 Abnormal cases

Abnormal cases are taken into account in the main part of the description of the procedure.

#### 3.4.13.2 Radio link failure in dedicated mode

The main part of these procedures concerns the "normal" cases, i.e. those without any occurrence of loss of communication means. A separate paragraph at the end of the description of each procedure treats the cases of loss of communication, called a radio link failure. In dedicated mode, in most of the cases the reaction of the mobile station or the network is the same. Those reactions are described in this sub-clause to avoid repetitions.

A radio link failure can be detected by several ways:

- 1) By analysis of reception at layer 1, as specified in 3GPP TS 05.08 and sub-clause 3.4.1.1.
- 2) By a data link layer failure as specified in 3GPP TS 04.06, on the main signalling link. A data link failure on any other data link shall not be considered as a radio link failure.
- 3) When a lower layer failure happens while the mobile station attempts to connect back to the old channels in a channel assignment procedure, handover procedure, PDCH assignment procedure or RR-cell change order procedure.
- 4) In some cases where timers are started to detect the lack of answer from the other party, as described in subclause 3.

The two first cases are known by the term "lower layer failure".

# 3.4.13.2.1 Mobile side

When a radio link failure is detected by the mobile station,

- the MS shall perform a local end release on all signalling links unless otherwise specified;
- the mobile station shall deactivate all channels;
- the RR sublayer of the mobile station shall indicate an RR connection failure to the MM sublayer unless otherwise specified.
- NOTE: Upper layers may decide on a re-establishment (cf. sub-clause 5.5.4).

When a mobile station which has performed the GPRS suspension procedure (sub-clause 3.3.1.1.4.2) detects a radio link failure, the RR sublayer of the mobile station shall indicate a RR GPRS resumption failure to the MM sublayer, see sub-clause 4.

# 3.4.13.2.2 Network side

In dedicated mode, the reaction of the network to a lower layer failure depends on the context. Except when otherwise specified, it is to release the connection either with the channel release procedure as specified in sub-clause 3.5.1, or with the following procedure. The network starts timer T3109 and deactivates the SACCH (and hence to stop transmission on the SACCH).

When a radio link failure has been detected, an indication is passed to the upper Mobility Management sublayer on the network side.

When timer T3109 expires, the network can regard the channels as released and free for allocation.

This procedure relies on the fact that if a mobile station does not receive the SACCH for some time, it completely releases the channels (cf. 3GPP TS 05.08).

NOTE: The network should maintain for a while the transaction context in order to allow call re-establishment. The length of timer is for further study.

When a mobile station which has performed the GPRS suspension procedure (sub-clause 3.3.1.1.4.2) detects a radio link failure, the RR sublayer of the mobile station shall indicate a RR GPRS resumption failure to the MM sublayer, see sub-clause 4.

# 3.4.13.3 RR connection abortion in dedicated mode

The mobile station aborts the RR connection by initiating a normal release of the main signalling link, performing local end releases on all other signalling links and disconnecting all traffic channels, if any.

When a mobile station which has performed the GPRS suspension procedure (sub-clause 3.3.1.1.4.2) aborts the RR connection, the RR sublayer of the mobile station shall indicate a RR GPRS resumption failure to the MM sublayer, see sub-clause 4.

# 3.4.13.4 Uplink release procedure in group transmit mode

If the uplink release is requested by the upper layer the mobile station shall send an UPLINK RELEASE message on the voice group call channel uplink, perform a release of the main signalling link and go back to the group receive mode.

If the UPLINK RELEASE message is received from the network on the voice group call channel downlink, the MS shall perform a release of the main signalling link and go back to the group receive mode.

# 3.4.13.5 Radio link failure in group transmit mode

The main part of these procedures concerns the "normal" cases, i.e. those without any occurrence of loss of communication means. A separate paragraph at the end of the description of each procedure treats the cases of loss of communication, called a radio link failure. In group transmit mode, in most of the cases the reaction of the mobile station or the network is the same. Those reactions are described in this sub-clause to avoid repetitions.

A radio link failure can be detected by several ways:

- 1) By analysis of reception at layer 1, as specified in 3GPP TS 05.08 and sub-clause 3.4.1.1.
- 2) By a data link layer failure as specified in 3GPP TS 04.06, on the main signalling link. A data link failure on any other data link shall not be considered as a radio link failure.
- 3) When a lower layer failure happens while the mobile station attempts to connect back to the old channels in a channel assignment procedure or handover procedure.
- 4) In some cases where timers are started to detect the lack of answer from the other party, as described in subclause 3.

The two first cases are known by the term "lower layer failure".

#### 3.4.13.5.1 Mobile side

When a radio link failure is detected by the mobile station:

- the MS shall perform a local end release on all signalling links;
- the mobile station shall go back to idle mode and, when possible, to group receive mode;
- the RR sublayer of the mobile station shall indicate an RR connection failure to the MM sublayer unless otherwise specified.

#### 3.4.13.5.2 Network side

When the uplink has been allocated and the network detects a lower layer failure, the network shall set the uplink free and provide an UPLINK FREE message on the main signalling channel, when appropriate.

When a radio link failure has been detected, an indication is passed to the upper Mobility Management sublayer on the network side.

# 3.4.14 Receiving a RR STATUS message by a RR entity

If the RR entity of the mobile station receives a RR STATUS message no transition and no specific action shall be taken as seen from the radio interface, i.e. local actions are possible.

The actions to be taken on receiving a RR STATUS message in the network are an implementation dependent option see also sub-clause 8.

# 3.4.15 Group receive mode procedures

Only applicable for support of VGCS listening or VBS listening.

#### 3.4.15.1 Mobile station side

#### 3.4.15.1.1 Reception of the VGCS or VBS channel

In group receive mode, the mobile station receives the downlink of the voice broadcast channel or voice group call channel for which the channel description was provided within the notification message or in the related command message. The mobile station should also listen to the CCCH of the serving cell. Moreover, it measures the received levels on the serving cell and on the neighbour cells to assess the need for a cell reselection as specified in 3GPP TS 05.08. The general cell reselection procedure for the mobile station in group receive mode is described in 3GPP TS 03.22.

Information on neighbour cells used for cell reselection and reception of the VGCS or VBS channel in the neighbour cells may be provided on the downlink messages (see sub-clause 3.4.15.1.2). If no such information is provided or information is missing, the mobile station shall try to read this information on the BCCH and NCH of the neighbour cells.

#### 3.4.15.1.2 Monitoring of downlink messages and related procedures

Mobile stations in group receive mode shall monitor messages related to the following procedures on the VGCS or VBS channel downlink and act appropriately in order to be able to keep receiving the VGCS or VBS channel downlink.

All messages for mobile stations in group receive mode shall be sent in UI format on the VGCS or VBS channel downlink. Mobile stations in group receive mode shall ignore all messages which are not sent in UI format or which are not related to the following mentioned procedures.

The mobile should also monitor messages on the PCH or NCH of the current cell.

3.4.15.1.2.1	Spare
--------------	-------

3.4.15.1.2.2 Spare

#### 3.4.15.1.2.3 Channel mode modify procedure

The mobile station shall receive CHANNEL MODE MODIFY messages. The mobile station shall use the new channel mode but shall not transmit any response to the network.

#### 3.4.15.1.2.4 Notification and paging information

The mobile station shall monitor messages related to notification and paging procedures.

The RR entity shall provide indications on all received notifications for voice group calls or voice broadcast calls to the upper layer. The indication shall include the notified group or broadcast call reference and, if provided, and if the mobile station supports eMLPP the related priority.

On request by the upper layer to join another voice broadcast call or voice group call for which a corresponding notification has been received on the VGCS or VBS channel downlink, the RR entity shall read the corresponding notification on the NCH.

If the mobile station has received a paging message with its own mobile station identity on the PCH or on the voice broadcast channel or voice group call channel downlink, the RR entity shall provide an indication to the upper layers, together with the related priority, if applicable.

#### 3.4.15.1.2.4.1 Use of Reduced NCH monitoring

This sub-clause applies to mobile stations which are in group receive mode or group transmit mode of dedicated mode and which in addition want to receive notification messages for other voice broadcast calls or voice group calls and which aim at reducing the reception load.

If the reduced NCH monitoring mechanism is used on the NCH as defined in sub-clause 3.3.3.3, when the MS in group receive mode or group transmit mode enters a cell, it should read the NCH until it has received at least two messages on the NCH indicating NLN, with the two last received NLN being identical. Then it should stop reading the NCH until it receives on the SACCH an NLN(SACCH) different from the last previously received NLN.

For this, a parameter is provided on the SACCH in the SYSTEM INFORMATION TYPE 6 message:

- NLN(SACCH): Notification List Number (received on the SACCH).

If a mobile station receives on the SACCH an NLN(SACCH) different from the last received NLN it may read the NCH until it has received at least two messages on the NCH indicating NLN with the two last received NLN being identical.

If a message in the SACCH is not received correctly the MS may read the NCH until it has received at least two messages on the NCH indicating NLN, with the two last received NLN being identical.

NOTE: If the NLN(SACCH) is not provided on the SACCH, the mobile station, depending on its particular implementation, may either read the NCH while being in group receive mode or group transmit mode or may not be able to receive notifications for other voice group calls or voice broadcast calls other than those notifications provided on the FACCH.

#### 3.4.15.1.2.5 Uplink status messages

Mobile stations supporting VGCS talking shall monitor the VGCS uplink control related messages UPLINK FREE and UPLINK BUSY.

#### 3.4.15.1.2.6 Channel release message

The mobile station shall receive CHANNEL RELEASE messages. On receipt of a CHANNEL RELEASE message, the RR entity shall go to idle mode and give an indication to the upper layer. (See also sub-clause 3.4.15.1.4.1, 4<sup>th</sup> paragraph.)

#### 3.4.15.1.2.7 Information on paging channel restructuring

On receipt of a SYSTEM INFORMATION TYPE 6 message indicating that paging channel restructuring has taken place, if the mobile station wants to be able to read its paging subchannel while in group receive mode or group transmit mode, the mobile station should read the related messages on the BCCH to know the position of its paging group.

#### 3.4.15.1.3 Uplink reply procedure

Only applicable for mobile stations supporting "VGCS talking".

On receipt of an UPLINK FREE message with an uplink access request indication from the network on the voice group call channel downlink, the mobile station shall send two UPLINK ACCESS messages on the voice group call channel with establishment cause "Reply on uplink access request" and then stop immediately transmitting on the uplink.

The first UPLINK ACCESS message shall be transmitted by the mobile station with a random delay between 0 and 20 ms. The second UPLINK ACCESS messages shall be repeated after a further period of 100 ms plus a random delay between 0 and 20 ms.

If an uplink identity code (UIC) of the current cell has been provided by the network in the UPLINK FREE message, the mobile station shall use this UIC for the coding of the UPLINK ACCESS messages. If no UIC is provided, the mobile station shall use the BSIC received of the serving cell, for instance as received from the initial synchronization.

#### 3.4.15.1.4 Leaving the group receive mode

#### 3.4.15.1.4.1 Returning to idle mode

If the mobile station enters a new cell in which:

- notifications for the current group or broadcast call are sent; but
- no VGCS or VBS channel description for the current group or broadcast call is provided;
- the mobile station shall go to idle mode and give an indication to the upper (sub-)layers.
- NOTE: Upper (sub-)layers then can request the establishment of an RR connection in order to be informed about the channel description by the network.

If the mobile station enters a cell in which notifications for the current group or broadcast call are not sent, the mobile station shall disconnect locally the TCH, go to idle mode and give an indication to the upper (sub-)layers.

On request by the upper layer in order to respond to a paging message the RR entity shall go to the idle mode in order to establish a dedicated RR connection.

On receipt of a CHANNEL RELEASE message in UI format from the network the RR entity shall go to idle mode and give an indication to the upper layer.

If the upper layer requests to abort the group receive mode, the mobile station shall go back to idle mode.

#### 3.4.15.1.4.2 Going to group transmit mode

Only applicable for mobile stations supporting VGCS talking.

If the upper layer requests an uplink access, the mobile station shall perform the uplink investigation procedure as defined in sub-clause 3.3.1.2.1.1.

If the uplink investigation procedure is not successful, the mobile station shall give an indication to the upper layers and remain in group receive mode.

If the uplink investigation procedure is successful, the uplink access procedure is initiated as defined in subclause 3.3.1.2.1.2.

If the uplink access procedure is successful, the mobile station shall give an indication to the upper layers and enter the group transmit mode.

If the uplink access procedure is not successful, the mobile station shall give an indication to the upper layers and remain in group receive mode.

#### 3.4.15.2 Network side

#### 3.4.15.2.1 Provision of messages on the VGCS or VBS channel downlink

#### 3.4.15.2.1.1 General

The network shall provide all messages directed to mobile stations in group receive mode (see sub-clause 3.4.15.1.2) in unacknowledged mode. Those messages which are also sent to the mobile station in group transmit mode in acknowledged mode have therefore to be repeated in addition as UI messages on the VGCS channel downlink if they shall also be received by mobile stations in group receive mode.

#### 3.4.15.2.1.2 Provision of general information messages

In the case where the group call area exceeds one cell, the network should provide the SYSTEM INFORMATION TYPE 6 message on the SACCH related to the voice broadcast channel or voice group call channel.

In addition, if the group call area exceeds one cell, the network should provide SYSTEM INFORMATION TYPE 5 (possibly together with TYPE 5bis and 5ter) on the SACCH related to the voice broadcast channel or voice group call channel.

- The SYSTEM INFORMATION TYPE 5, TYPE 5bis and TYPE 5ter messages provide information on the BCCH frequency of the neighbour cells.
- The SYSTEM INFORMATION TYPE 6 message provides information on the location area of the current cell, possibly the status of the NCH, and an indication of whether paging channel restructuring has taken place.
- \$(ASCI)\$ Optional messages of the SYSTEM INFORMATION TYPE 10 message type provide information improving cell re-selection in group receive mode.

The network may also provide layer 3 messages for notification on the VGCS or VBS channel downlink FACCH.

#### 3.4.15.2.1.3 Provision of messages related to the voice group call uplink channel

Only applicable for the support of VGCS talking.

The network shall provide UPLINK FREE messages on the main signalling link of all voice group call channels when the uplink is set free. The provision of UPLINK FREE messages shall be repeated as long as no uplink is granted to a mobile station.

The network shall provide an UPLINK BUSY message on the main signalling link of all voice group call when the uplink has been granted to a mobile station.

The network may send UPLINK FREE messages containing an uplink access request on the main signalling channel of the VGCS channels in order to obtain knowledge on whether any listening mobile is present in a cell or not. If there is no mobile station responding to the uplink access request, the network may decide to clear the VGCS channel in that cell.

# 3.4.15.2.2 Release of the VGCS or VBS Channels

If a release request for a voice group call is received from the upper layer, the network, after having released the RR connection with the mobile station in group transmit mode, shall stop the notification procedures for that voice group call and clear all related voice group call channels.

If a release request for a voice broadcast call is received from the upper layer, the network shall stop the notification procedures for that voice broadcast call and locally disconnect any channel related to the voice broadcast call.

# 3.4.15.3 Failure cases

If the mobile station looses the voice group call channel or voice broadcast channel, the mobile station shall search all possible channel positions on the current cell and the neighbour cells for which a channel description is known for that call.

# 3.4.16 Configuration change procedure

This is only applicable for multislot configuration.

The configuration change procedure is used by the network to change the number of timeslots used in a multislot configuration. The procedure can also be used to change the channel mode of one or several channels and change their allocation. The main signalling link however, cannot be changed by the configuration change procedure. If a change of the main signalling link is needed, the assignment or handover procedures shall be used.

The network shall not initiate a new configuration change procedure before a response to the previous CONFIGURATION CHANGE COMMAND message has been received from the mobile station.

# 3.4.16.1 Configuration change initiation

The procedure starts when the network sends a CONFIGURATION CHANGE COMMAND to the mobile station on the main DCCH. The message indicates:

- which timeslots to use in uplink;
- which timeslots to use in downlink; and
- which channel set each timeslot belongs to.

The message may also contain definitions of the channel mode to be applied for one or several channel sets. If a previously undefined channel set is defined by the CONFIGURATION CHANGE COMMAND a definition of the channel mode for the new channel set shall be included in the message.

# 3.4.16.2 Configuration change completion

When the mobile station receives the CONFIGURATION CHANGE COMMAND it changes its configuration in accordance with the message contents and returns a CONFIGURATION CHANGE ACKNOWLEDGE on the same channel as the command message was received, confirming the new channel configuration. This applies irrespective of whether the new configuration is different from the one already in use by the mobile station or if it is the same.

# 3.4.16.3 Abnormal cases

If the CONFIGURATION CHANGE COMMAND message instructs the mobile station to use a Channel Configuration or Mode(s) that it does not support, or if the channel mode to use is not defined for all channel sets, the mobile station shall return a CONFIGURATION CHANGE REJECT message with cause 'channel mode unacceptable', and the mobile station shall remain on the current channel(s) and use the old Channel Configuration and Channel Mode(s).

# 3.4.17 Mapping of user data substreams onto timeslots in a multislot configuration

For multislot configurations the following rules for mapping of the user data substreams onto timeslots shall apply for each channel set:

- at initial assignment (using assignment procedure), the lowest numbered user data substream shall be mapped to the lowest numbered timeslot etc. in ascending order (the user data substreams are numbered 0 to (n-1), where n is the number of substreams).
- at channel changes using handover procedure or assignment procedure (where none of the timeslots are present in both the old and the new configuration), the lowest numbered user data substream shall be mapped to the lowest numbered timeslot etc. in ascending order (the user data substreams are numbered 0 to (n-1), where n is the number of substreams).
- at channel changes using assignment procedure (where at least one of the timeslots is the same in both the old and the new configuration) or configuration change procedure:
  - user data substream(s) mapped to timeslot(s) that are present in both the old and the new configuration shall continue to be mapped to the same timeslot(s) as before the channel change; and
  - possibly added timeslot(s) shall carry the lowest numbered available user data substream so that the lowest numbered data substream among the added is mapped to the lowest numbered added timeslot and so on in ascending order.
- NOTE: The user data substream number is a number that need not be the same as the inband number used for transparent services. The user data substream number is only used as a point of reference to a specific user data substream.

# 3.4.18 Handling of classmark information at band change

The coding of some fields in the *Mobile Station Classmark 1* and in the *Mobile Station Classmark 2* information elements depends on the band in use as described in sub-clause 10.5.1.5 and sub-clause 10.5.1.6. When a command to change the frequency band (GSM 900, DCS 1800) has been received (by, e.g., an IMMEDIATE ASSIGNMENT message, an ASSIGNMENT COMMAND message, a HANDOVER COMMAND message or a FREQUENCY REDEFINITION message) the following applies:

- When an IMMEDIATE ASSIGNMENT message is received, "the band used" for the purpose of coding the classmark information in the service request message, see sub-clause 3.1.5, shall be understood as the band used for the CHANNEL REQUEST message or (one of) the band(s) indicated by the IMMEDIATE ASSIGNMENT message.
- For other cases "the band used" for the purpose of coding the classmark information shall be understood as one of the bands used or attempted to be used within the 2 seconds preceding the passing of the layer 3 message containing the classmark information to the layer 2 send queue as described in 3GPP TS 04.06.
- NOTE: This definition means that when a band change is being done the network must take appropriate actions to handle possible ambiguities in the frequency band related information in the classmark.

# 3.4.19 Assignment to a Packet Data channel

This sub-clause is only applicable to mobile stations supporting the "GPRS" option.

When in dedicated mode or in group transmit mode, the network may wish to change the resources used by a mobile station that supports the "GPRS option". This change may be performed through the assignment to a Packet Data Channel procedure.

The purpose of the assignment to PDCH channel procedure is to completely modify the physical channel configuration of the mobile station without frequency redefinition or change in synchronization while staying in the same cell.

The assignment to PDCH procedure only commences in dedicated mode or in group transmit mode. This procedure cannot be used in the idle mode.

The assignment to PDCH procedure includes:

- the suspension of normal operation.
- the release of the main signalling link, and of the other data links as defined in sub-clause 3.1.4, and the disconnection of TCHs if any.

- the deactivation of previously assigned channels (layer 1)
- the triggering of the establishment of a Temporary Block Flow.

The assignment to PDCH procedure is always initiated by the network.

#### 3.4.19.1 Assignment to PDCH initiation

The network initiates the assignment to PDCH procedure by sending a PDCH ASSIGNMENT COMMAND message to the mobile station on the main signalling link. It then starts timer T3117.

NOTE: The network should take into account limitations of certain mobile stations to understand formats used in the Frequency List IE and Cell Channel Description IE used in the PDCH ASSIGNMENT COMMAND message, see sub-clause 10.5.2.13 and sub-clause 10.5.2.1b.

When sending this message on the network side, and when receiving it on the mobile station side, all transmission of signalling layer messages except for those RR messages needed for this procedure and for abnormal cases is suspended until resumption is indicated. These RR messages can be deduced from sub-clauses 3.4.3 and 8.8 Radio Resource management.

Upon receipt of the PDCH ASSIGNMENT COMMAND message, the mobile station initiates a local end release of dedicated mode link layer connections, disconnects the physical channels, commands the switching to the identified channels and obeys the procedures relevant to the establishment of the Temporary Block Flow. The mobile station starts timer T3190.

The PDCH ASSIGNMENT COMMAND message contains the description of either the uplink TBF or the downlink TBF.

The information on the power to be used on the target TBF shall not affect the power used on the old channel(s).

A PDCH ASSIGNMENT COMMAND message may indicate a frequency change in progress, with a starting time and possibly alternative channel descriptions.

In the case of the reception of a PDCH ASSIGNMENT COMMAND message which contains only the description of a TBF to be used after the starting time, the mobile station shall wait up to the starting time before using the TBF. If the starting time has already elapsed, the mobile shall use the TBF as an immediate reaction to the reception of the message (see 3GPP TS 05.10 for the timing constraints).

If the message contains both the description of a TBF to be used after the indicated time and of a TBF to be used before, the mobile station uses the TBF as an immediate reaction to the reception of the message. If the moment the mobile station is ready to access is before the indicated time, the mobile station uses the TBF described for before the starting time. The mobile station then changes to the TBF described for after the starting time at the indicated time. New parameters can be frequency list, MAIO and HSN. Other parameters describing the allocated channels shall be identical to the parameters described for before the starting time. If the moment the mobile station is ready to access is after the starting time, the mobile station uses the TBF described for after the starting time.

If frequency hopping is applied, the cell allocation if present in the message is used to decode the mobile allocation. If the cell allocation is not included, the mobile station uses its current cell allocation, the current CA is the last CA received on the BCCH. Afterward, the current CA may be changed by some messages sent on the main signalling link containing a CA (the possible messages are: ASSIGNMENT COMMAND, HANDOVER COMMAND and FREQUENCY REDEFINITION). Note that there are cases in which the current CA is undefined, see sub-clause 3.4.3.3.

The PDCH ASSIGNMENT COMMAND does not contain a cipher mode setting IE. Any RR layer ciphering that may have been applied in dedicated mode shall not be applied to the target TBF.

# 3.4.19.2 Completion of the Assignment to PDCH procedure

The network regards the procedure as successfully completed when RLC/MAC blocks are received from the mobile station on the target TBF. The network then stops timer T3117.

The mobile station regards the procedure as successfully completed when RLC/MAC blocks with any TFI are received on the new PDCH.

# 3.4.19.3 Abnormal cases

If the mobile station has no current CA and if it needs a CA to analyse the PDCH ASSIGNMENT COMMAND message, it stays on the current channel(s) and sends an ASSIGNMENT FAILURE message with cause "no cell allocation available".

If the PDCH ASSIGNMENT COMMAND message instructs the mobile station to use a Coding Scheme that it does not support then the mobile station shall return an ASSIGNMENT FAILURE message with cause "channel mode unacceptable", and the mobile station shall remain on the current channel(s) and uses the old Channel Description or Channel Mode(s).

If the PDCH ASSIGNMENT COMMAND message instructs the mobile station to use a frequency that it is not capable of, then the mobile station shall return an ASSIGNMENT FAILURE message with cause "frequency not implemented", and the mobile station shall remain on the current channel(s).

If the mobile station receives a PDCH ASSIGNMENT COMMAND message with a Frequency List IE indicating frequencies that are not all in one band, then the mobile station shall stay on the current channel(s) and send an ASSIGNMENT FAILURE message with cause "frequency not implemented". If the mobile station receives a PDCH ASSIGNMENT COMMAND message with a Mobile Allocation IE indexing frequencies that are not all in one band, then the mobile station shall stay on the current channel(s) and send an ASSIGNMENT FAILURE message with a Mobile Allocation IE indexing frequencies that are not all in one band, then the mobile station shall stay on the current channel(s) and send an ASSIGNMENT FAILURE message with cause "frequency not implemented".

NOTE: A PDCH ASSIGNMENT COMMAND message sent to a multi band mobile station shall not be considered invalid because it indicates frequencies that are all in a different frequency band to that of the current channel.

On the mobile station side, if RLC/MAC blocks are not successfully received within T3190 seconds, the mobile station reactivates the old channels, reconnects the TCHs if any and triggers the establishment of the main signalling link. It then sends an ASSIGNMENT FAILURE message, cause "protocol error unspecified" on the main DCCH and resumes the normal operation, as if no assignment attempt had occurred. The operational parameters (e.g. ciphering mode) when returning on the old channel are those applied before the procedure.

When receiving the ASSIGNMENT FAILURE message, the network stops T3117.

If a lower layer failure happens while attempting to connect back to the old channels, the radio link failure procedure is applied (see sub-clause 3.4.13.2).

On the network side, if timer T3117 elapses before either the network receives an RLC/MAC block from the mobile station on the new channel, or, an ASSIGNMENT FAILURE message is received on the old channels, then the old channels and the new resources are released, except that, if the old channel was a VGCS channel, the old channel shall be maintained and the uplink shall be set free.

On the network side, lower layer failure occurring on the old channels after the sending of the PDCH ASSIGNMENT COMMAND message are ignored.

# 3.4.20 RR-Network Commanded Cell Change Order

This sub-clause is only applicable to mobiles supporting the <<<GPRS>> option.

In dedicated mode or in group transmit mode, intracell or intercell change of channel(s) can be requested by the network RR sublayer. This change may be performed through the RR-network commanded cell change order procedure.

The purpose of the RR-network commanded cell change order procedure is to permit the complete modification of the channels allocated to the mobile station e.g. when the cell is changed. This procedure only commences while in dedicated mode or in group transmit mode.

The RR-network commanded cell change order procedure includes:

- The suspension of normal operation except for RR management (layer 3).
- The disconnection of the main signalling link, and of the other links via local end release (layer 2), and the disconnection of the TCH(s) if any.

- The disconnection and the deactivation of previously assigned channels and their release (layer 1).
  - The complete acquisition of BCCH or PBCCH messages of the target cell.
- The triggering of the establishment of a Temporary Block Flow.

The RR-network controlled cell change order procedure is always initiated by the network.

## 3.4.20.1 RR-network commanded cell change order initiation

The network initiates the RR-network controlled cell change order procedure by sending a RR-CELL CHANGE ORDER message to the mobile station on the main DCCH. The network then starts timer T3119.

When a handover has taken place during dedicated connection, the network shall send a RR-CELL CHANGE ORDER message to the mobile station in order to establish TBF. In this case the target cell is equal to the old cell.

When sending this message on the network side, and when receiving it on the mobile station side, all transmission of signalling layer messages except for those RR messages needed for this procedure and for abnormal cases, is suspended until resuming is indicated. These RR messages can be deduced from sub-clauses 3.4.3 and 8.5.1 "Radio Resource management".

Upon receipt of the RR-CELL CHANGE ORDER message, the mobile station starts timer T3134, and initiates, as described in sub-clause 3.1.4, the release of link layer connections, disconnects the physical channels, commands the switching to the identified cell, performs a complete acquisition of BCCH or PBCCH messages (see 3GPP TS 04.60), and obeys the procedures relevant to the establishment of the Temporary Block Flow. The mobile station shall obey the RR-CELL CHANGE ORDER irrespective of whether or not the mobile station has any knowledge of the relative synchronisation of the target cell to the serving cell.

The RR-CELL CHANGE ORDER message contains:

- The characteristics of the new cell that are necessary to identify it (i.e. BSIC + BCCH frequency).
- the NC mode to be initially applied on the new cell.

The RR-CELL CHANGE ORDER does not contain a cipher mode setting IE. Any RR layer ciphering that may have been applied in dedicated mode shall not be applied to the target TBF or with the target cell.

#### 3.4.20.2 Network controlled cell reselection completion

The network regards the procedure as successfully completed when it knows that communication has been established with that mobile station via the new cell (e.g. the network has received a RLC/MAC Block containing the mobile station's identity). The network then stops timer T3119.

The mobile station regards the procedure as successfully completed when it has received a response to a (PACKET) CHANNEL REQUEST message on the new cell which allocates it a resource on the new cell.

# 3.4.20.3 Abnormal cases

If the RR-CELL CHANGE ORDER message instructs the mobile station to use a frequency that it is not capable of, then the mobile station shall return a HANDOVER FAILURE message with cause "frequency not implemented", and the mobile station shall remain on the current channel(s).

On the mobile station side, if timer T3134 times out before a response to the (PACKET) CHANNEL REQUEST message has been received, or, if an IMMEDIATE ASSIGNMENT REJECT message or a PACKET ACCESS REJECT is received from the new cell, or, if the contention resolution procedure fails on the new cell then the mobile station shall reactivate the old channels, reconnect the TCHs if any and trigger the establishment of the main signalling link. It then sends a HANDOVER FAILURE message on the main signalling link and resumes normal operation as if no handover attempt had occurred. The operational parameters (e.g. ciphering mode) when returning on the old channel are those applied before the RR-CELL CHANGE ORDER message was received.

When the HANDOVER FAILURE message has been received, the network stops T3119.

If a lower layer failure happens while attempting to connect back to the old channels, the standard rules are applied (cf. sub-clause 3.4.13.2).

On the network side, if timer T3119 elapses before either the mobile station has been recognised on the new cell, or a HANDOVER FAILURE message is received on the old channels, then the old channels are released, except that, if the old channel was a VGCS channel, the old channel shall be maintained and the uplink shall be set free.

On the network side, lower layer failures occurring on the old channels after the sending of the RR-CELL CHANGE ORDER message are ignored.

# 3.4.21 Application Procedures

#### 3.4.21.1 General

While in dedicated mode, the following applications associated with the Radio Resource management layer may be supported in the network and MS:

- Location Services (LCS).

Common procedures are defined in the Radio Resource management layer to assist these applications.

## 3.4.21.2 Application Information Transfer

The Application Information Transfer procedure enables an Application on the network side and a peer application in the MS to exchange Application Protocol Data Units (APDUs).

#### 3.4.21.2.1 Normal Procedure without Segmentation

The maximum size of an APPLICATION INFORMATION message is 251 octets as defined in 3GPP TS 04.06. Segmentation shall not be used when an APDU fits into a single APPLICATION INFORMATION message of maximum or smaller size.

#### Figure 3.4/3GPP TS 04.08: Application Information Transfer without segmentation

Either the network or MS may send an APPLICATION INFORMATION message once the MS is in dedicated mode. The APDU Data in the APPLICATION INFORMATION message shall contain a complete APDU according to the protocol in use. The APDU ID IE identifies the protocol and associated application. The APDU Flags IE indicates "First or Only Segment", "Last or Only Segment" and conveys a C/R flag transparently between the communicating applications. The C/R Flag may be used to distinguish a command from other messages and a final response from a non-final response. The use of the C/R flag is defined with respect to each application. On receiving an APPLICATION INFORMATION message, the receiving layer 3 entity shall deliver the message contents to the identified local application.

#### 3.4.21.2.2 Normal Procedure with Segmentation

Segmentation is applicable when an APDU is too large to fit into a single APPLICATION INFORMATION message. The procedure is applicable for either direction of transfer.

 Mobile Station or Network
 Network or Mobile Station

 APPLICATION INFORMATION [APDU segment, First Segment, not Last Segment]

 APPLICATION INFORMATION [APDU segment, not First Segment, not Last Segment]

 APPLICATION INFORMATION [APDU segment, not First Segment, Last Segment, C/R]

Figure 3.5/3GPP TS 04.08: Application Information Transfer with segmentation

The sending layer 3 entity shall segment an APDU by dividing it into one or more segments exactly fitting into maximum sized APPLICATION INFORMATION messages plus a final segment fitting into an APPLICATION INFORMATION message of maximum size or smaller. Once segmented, the resulting APPLICATION INFORMATION messages shall be transferred in sequence to the data link layer for transmission, without being intersperced by other level 3 messages. The first APPLICATION INFORMATION message in the sequence shall indicate "First Segment" and "Not Last Segment". Subsequent APPLICATION INFORMATION messages except for the last shall indicate "Not First Segment" and "Not Last Segment". The last APPLICATION INFORMATION message shall indicate "Not First Segment" and shall include a C/R flag as provided by the sending application.

The receiving layer 3 entity shall reassemble any segmented APDU before transfer to the local application. The receiver may employ a timer to detect possible loss of APDU segments. If employed, the timer shall be started when the first APDU segment is received and cancelled after the last segment is received.

# 3.4.21.2.3 Abnormal Cases

APPLICATION INFORMATION messages are sent using "low" priority at the data link layer. This can lead to message loss or truncation when preempted by other "high" priority messages. A receiving layer 3 entity shall detect APDU truncation if an APPLICATION INFORMATION message is received carrying an APDU or APDU segment that is shorter than indicated by the length indicator for the APDU Data IE. This test is reliable because preemption in the data link layer guarantees that at least the first 2\*N201 octets of any truncated message will be reliably transferred.

An APPLICATION INFORMATION transfer error shall be detected due to any of the following:

- (a) Receipt of a truncated APDU or APDU segment;
- (b) While performing APDU reassembly:
  - receipt of any other layer 3 message defined to use SAPI 0 on the main DCCH;
  - receipt of an APDU or APDU segment indicating "First or Only Segment";
  - expiration of the reassembly timer (if supported);
- (c) While not performing APDU reassembly, receipt of an APDU segment indicating "not First or only segment";
- (d) Detection of any other error for a received message as defined in sub-clause 8.

If APDU reassembly was in process when the error occurred, the receiving layer 3 entity shall discard the partially reassembled APDU and reprocess any received APDU or APDU segment that caused the error provided not an error defined in clause 8. In all other cases, any received APDU or APDU segment shall be discarded.

# 3.5 RR procedures on CCCH related to temporary block flow establishment

The establishment of a temporary block flow (TBF) on a packet data physical channel is supported by procedures on CCCH when PCCCH is not provided in the cell. The procedures for temporary block flow establishment using CCCH are only applicable to a mobile station supporting GPRS. The procedures are optional for the network.

These procedures constitute a complement to the corresponding procedures for temporary block flow establishment using PCCCH, defined in 3GPP TS 04.60, and include the procedures using CCCH for *packet paging* (sub-clause 3.5.1), *packet access* (sub-clause 3.5.2) and *packet downlink assignment* (sub-clause 3.5.3).

# 3.5.1 Packet paging procedure using CCCH

The network can initiate the packet paging procedure in order to cause upper layers in the mobile station to respond, see clause 4. The packet paging procedure can only be initiated by the network.

# 3.5.1.1 Packet paging initiation by the network

The packet paging procedure is initiated by the RR entity of the network side. It is triggered by a page request from the MM sublayer, see 3GPP TS 04.07.

The network initiates the paging procedure by sending a paging request message on an appropriate paging subchannel on CCCH or PCCCH. Paging initiation using a paging subchannel on CCCH is used when sending paging information to a mobile station and PCCCH is not present in the cell.

NOTE 1: There are three types of paging request messages that are applicable:

- PAGING REQUEST TYPE 1;
- PAGING REQUEST TYPE 2; and
- PAGING REQUEST TYPE 3.

In a PAGING REQUEST message used for the packet paging procedure, the mobile station shall be identified by the P-TMSI (GPRS TMSI) or its IMSI. If the mobile station is identified by the P-TMSI, it shall proceed as specified in subclause 3.5.1.2.

If the mobile station identified by its IMSI, it shall parse the message for a corresponding Packet Page Indication field:

- if the *Packet Page Indication* field indicates a paging procedure for RR connection establishment, or the field is not present in the message, the mobile station shall proceed as specified in sub-clause 3.3.2.2;
- if the *Packet Page Indication* field indicates a packet paging procedure, the mobile station shall proceed as specified in sub-clause 3.5.1.2.

A PAGING REQUEST message may include more than one mobile station identification.

The mobile station in packet idle mode is required to receive and analyse the paging messages and immediate assignment messages sent on the paging subchannels on CCCH corresponding to the paging groups determined for it in packet idle mode, as specified in 3GPP TS 05.02. These messages contain a page mode information element.

NOTE 2: The possible immediate assignment messages are: the IMMEDIATE ASSIGNMENT, the IMMEDIATE ASSIGNMENT EXTENDED and the IMMEDIATE ASSIGNMENT REJECT messages.

The treatment of page mode information, including the procedure when the mobile station selects a new PCH, and the procedure if a message in a paging subchannel is not received correctly are defined in sub-clause 3.3.2.1.1.

#### 3.5.1.2 On receipt of a packet paging request

On the receipt of a paging request message, the RR sublayer of addressed mobile station indicates the receipt of a paging request to the MM sublayer, see 3GPP TS 04.07.

# 3.5.2 Packet access procedure using CCCH

The packet access procedure using CCCH may be used to establish a temporary block flow to support the transfer of LLC PDUs in the direction from the mobile station to the network. Establishment using one phase and two phase packet access, see 3GPP TS 04.60, are supported. The two phase packet access is supported by means of the single block packet access option in this procedure, allowing the transfer of a PACKET RESOURCE REQUEST message to the network.

The single block packet access option in this procedure may also be used by a mobile station in packet idle mode to transfer an RLC/MAC control message other than the PACKET RESOURCE REQUEST message to the network, see sub-clause 3.5.2.2.

# 3.5.2.1 Entering the packet transfer mode: packet access procedure

The establishment of an uplink temporary block flow may be initiated by the RR entity of the mobile station using the packet access procedure. The procedure is triggered by a request from upper layers to transfer a LLC PDU, see 3GPP TS 04.07. The request from upper layers specifies *radio priority* and an *RLC mode* associated with the packet transfer or it indicates that the packet to be transferred contains signalling.

Upon such a request:

- if access to the network is allowed (sub-clause 3.5.2.1.1), the RR entity of the mobile station initiates the packet access procedure as defined in sub-clause 3.5.2.1.2;

- otherwise, it rejects the request.

If the request from upper layers indicates signalling, the highest *radio priority* level shall be used at determination if access to the network is allowed, and the acknowledged RLC mode shall be used.

#### 3.5.2.1.1 Permission to access the network

Access to the network is allowed:

- if the mobile station is a member of at least one authorized access class or special access class as defined in subclause 3.3.1.1.1, and
- if packet access is allowed in the cell for the *radio priority* level associated with the packet transfer, as indicated by the PRIORITY\_ACCESS\_THR parameter broadcast in SI 13 message;
- if the cell belongs to one of the allowed LSAs for the mobile station, as indicated on the SIM, in the case where the mobile station is a LSA only access subscriber.

#### 3.5.2.1.2 Initiation of the packet access procedure: channel request

The mobile station initiates the packet access procedure by scheduling the sending of CHANNEL REQUEST messages on RACH and leaving the packet idle mode. In particular, the mobile station shall ignore PAGING REQUEST messages indicating a packet paging procedure.

A mobile station belonging to GPRS MS class A or B shall continue to monitor its paging subchannel on CCCH for PAGING REQUEST messages indicating an establishment of RR connection. A mobile station belonging to GPRS MS class B may abort the packet access procedure at the receipt of a PAGING REQUEST messages indicating an establishment of RR connection.

The mobile station schedules CHANNEL REQUEST messages on RACH as defined in sub-clause 3.3.1.1.2.

The CHANNEL REQUEST messages are sent on RACH and contain the parameters:

- an establishment cause which indicates packet access, and as applicable, a request for one phase packet access or single block packet access (sub-clause 9.1.8);
- a random reference which is drawn randomly from an uniform probability distribution for every new transmission.

If the requested RLC mode is *unacknowledged mode*, the mobile station shall request a single block packet access and attempt a two phase packet access.

If the purpose of the packet access procedure is to send a Page Response, Cell update, for a GPRS Mobility Management or a GPRS Session Management procedure, (i.e. the access is for Layer 3 signalling only, and not for a Layer 3 data transfer), the mobile station shall request a one phase packet access.

After sending the first CHANNEL REQUEST message, the mobile station shall start listening to the BCCH; it shall also listen to the full downlink CCCH timeslot corresponding to its CCCH group.

Having sent the maximum number of CHANNEL REQUEST messages, the mobile station starts timer T3146. At expiry of timer T3146, the packet access procedure is aborted and a packet access failure is indicated to upper layers.

If the mobile station receives an IMMEDIATE ASSIGNMENT message during the packet access procedure indicating a packet downlink assignment procedure, the mobile station shall abort the packet access procedure and respond to the IMMEDIATE ASSIGNMENT message as specified in sub-clause 3.5.3.1.2. The mobile station shall then attempt an establishment of uplink TBF, using the procedure specified in 3GPP TS 04.60 which is applicable in packet transfer mode.

#### 3.5.2.1.3 Packet immediate assignment

#### 3.5.2.1.3.1 On receipt of a CHANNEL REQUEST message

On receipt of a CHANNEL REQUEST message indicating a packet access, the network may allocate a temporary flow identity and assign a packet uplink resource comprising one PDCH for an uplink temporary block flow.

If the establishment cause in the CHANNEL REQUEST message indicates a request for a single block packet access, the network shall grant only the single block period on the assigned packet uplink resource if the network allocates resource for the mobile station.

If the establishment cause in the CHANNEL REQUEST message indicates a request for one phase packet access, the network may grant either a one phase packet access or a single block packet access for the mobile station. If a single block packet access is granted, it forces the mobile station to perform a two phase packet access.

The packet uplink resource is assigned to the mobile station in an IMMEDIATE ASSIGNMENT message sent in unacknowledged mode on the same CCCH timeslot on which the network has received the CHANNEL REQUEST message. There is no further restriction on what part of the downlink CCCH timeslot the IMMEDIATE ASSIGNMENT message can be sent. Timer T3141 is started on the network side.

The IMMEDIATE ASSIGNMENT message contains:

- the information field of the CHANNEL REQUEST message and the frame number of the frame in which the CHANNEL REQUEST message was received;
- the packet channel description;
- the initial timing advance;
- the packet uplink assignment construction.

If frequency hopping is applied, the network may use the indirect encoding or the direct encoding of the frequency configuration in the *Packet Channel Description* information element. If the indirect encoding is used, the mobile station uses information received in system information or stored from a previous assignment to determine the frequency parameters, see 3GPP TS 04.60. If the direct encoding is used, the mobile station uses the cell allocation defined for the cell to decode the mobile allocation.

If the *indirect encoding* is used, the IMMEDIATE ASSIGNMENT message may contain a CHANGE\_MARK\_1 field. If that is present, the mobile station shall verify the validity of the SI13\_CHANGE\_MARK associated with the GPRS mobile allocation to which the message refers, see 3GPP TS 04.60. If the CHANGE\_MARK\_1 field and the SI13\_CHANGE\_MARK do not match, the message does not satisfactorily define a PDCH.

If the mobile station receives an IMMEDIATE ASSIGNMENT message and the *Dedicated mode or TBF* information element indicates that this is the first message in a two-message assignment, the mobile station shall continue to listen to the full CCCH. The network may send a second IMMEDIATE ASSIGNMENT message to the mobile station within two multiframe periods following the first IMMEDIATE ASSIGNMENT message, specifying the packet channel description and, if required, a mobile allocation for the assignment. The two IMMEDIATE ASSIGNMENT messages in a two-message assignment shall have the same contents of the *Request Reference* information elements.

If the mobile station does not receive the second IMMEDIATE ASSIGNMENT messages in a two-message assignment within two multiframe periods following the first message, the mobile station shall discard the first IMMEDIATE ASSIGNMENT message received.

On receipt of an IMMEDIATE ASSIGNMENT message or, in case of a two-message assignment, a matching pair of IMMEDIATE ASSIGNMENT messages corresponding to one of its 3 last CHANNEL REQUEST messages, the mobile station stops T3146 (if running), stops sending CHANNEL REQUEST messages, and switches to the assigned PDCH.

The content of the packet uplink assignment construction indicates which type of packet access is granted: *one phase packet access* or *single block packet access* 

#### 3.5.2.1.3.2 One phase packet access

In the case the one phase packet access is granted, the packet uplink assignment construction contains:

- the temporary flow identity;
- the USF value, if the medium access method is dynamic allocation; or
- the fixed allocation bitmap, if the medium access method is fixed allocation;
- the channel coding scheme for RLC data blocks;

- the power control parameters;
- the polling bit;
- optionally, the timing advance index (see 3GPP TS 05.10);
- optionally, the TBF starting time (note: TBF starting time is mandatory if medium access method is fixed allocation).

The medium access method is *dynamic allocation* or *fixed allocation* and the RLC mode is *acknowledged mode*, see 3GPP TS 04.60.

The mobile station shall start timer T3164 and proceed with the contention resolution at one phase access defined in 3GPP TS 04.60.

If the medium access method is *fixed allocation*, and the number of blocks allocated in the ALLOCATION\_BITMAP is not sufficient to transfer all the RLC/MAC blocks that the MS has to transmit at the time the packet uplink assignment construction is received, the MS shall request additional resources by sending a PACKET RESOURCE REQUEST on one of the allocated blocks.

If the timing advance index (TAI) is included in the packet uplink assignment construction, the mobile station shall use the continuous update timing advance mechanism, see 3GPP TS 05.10, using PTCCH in the same timeslot as the assigned PDCH. If a timing advance index (TAI) field is not included, the continuous update timing advance mechanism shall not be used.

In case the packet uplink assignment construction contains a TBF starting time and the mobile station receives the message before the TBF starting time has expired, it shall wait until the frame number indicated by the TBF starting time before accessing the channel. If the mobile station receives the message after the TBF starting time has expired, it shall ignore the TBF starting time and may immediately access the channel.

If the Polling bit is set to 1, MS shall send a PACKET CONTROL ACKNOWLEDGEMENT message (see 04.60) on the assigned PDCH, in the uplink block specified by the TBF Starting Time. In this case the TBF Starting Time is used both to indicate when the assigned PDCH becomes valid and to specify the uplink block. If the TBF Starting Time is not present or has expired, the MS shall ignore the polling request.

#### 3.5.2.1.3.3 Single block packet access

In the case the single block packet access is granted, the packet uplink resource description contains:

- the power control parameter setting;
- the TBF starting time.

If the mobile station receives the IMMEDIATE ASSIGNMENT message before the TBF starting time has expired, it shall wait until the block period indicated by the TBF starting time. The network shall use the TBF starting time to indicate the first frame number belonging to the single block period granted for packet access. The mobile station may either use the assigned block period to send a PACKET RESOURCE REQUEST message to initiate the two phase packet access procedure defined in 3GPP TS 04.60, or to send an RLC/MAC control message other than the PACKET RESOURCE REQUEST message to the network, see sub-clause 3.5.2.2.

If the mobile station receives the IMMEDIATE ASSIGNMENT message after the TBF starting time has expired, a failure has occurred.

If a failure occurs and the packet access attempt was due to a request from upper layers to transfer a LLC PDU, a TBF establishment failure has occurred and the mobile station proceeds as specified in sub-clause 3.5.2.1.5. If a failure occurs and the packet access attempt was due to the sending of an RLC/MAC control message, the packet access is aborted, the mobile station returns to packet idle mode.

#### 3.5.2.1.3.4 Packet access rejection

The network may send to the mobile station an IMMEDIATE ASSIGNMENT REJECT message in unacknowledged mode on the same CCCH timeslot on which the channel request message was received. There is no further restriction on what part of the downlink CCCH timeslot an IMMEDIATE ASSIGNMENT REJECT message can be sent. This message contains the request reference and a wait indication.

On receipt of an IMMEDIATE ASSIGNMENT REJECT message corresponding to one of its 3 last CHANNEL REQUEST messages, the mobile station stops sending CHANNEL REQUEST messages, starts timer T3142 with the indicated value, ("wait indication" information element), starts T3146 if it has not already been started, and listens to the downlink CCCH until T3146 expires. During this time, additional IMMEDIATE ASSIGNMENT REJECT messages are ignored, but any immediate assignment corresponding to any other of its 3 last CHANNEL REQUEST messages make the mobile station follow the procedure in sub-clause 3.5.2.1.3.1. If no such immediate assignment is received, the mobile station returns to packet idle mode and notify higher layers (TBF establishment failure).

If the mobile station has received responses from the network on all, or in case more than 3 were sent the last 3, of its CHANNEL REQUEST messages, it shall immediately return to packet idle mode and notify higher layers.

The mobile station is not allowed to make a new attempt for packet access in the same cell until T3142 expires, but may attempt packet access in an other cell after successful cell reselection for radio conditions reasons (see 3GPP TS 05.08). The value of the wait indication (i.e. T3142) relates to the cell from which it was received.

The mobile station may initiate RR connection establishment in the same cell before T3142 has expired, see subclause 3.3.1.1.3.2.

#### 3.5.2.1.4 Packet access completion

The one phase packet access procedure is completed at a successful contention resolution. The mobile station has entered the packet transfer mode. Timer T3141 is stopped on the network side. Timer T3164 is stopped on the mobile station side.

#### 3.5.2.1.5 Abnormal cases

If a failure occurs on the mobile station side before a successful contention resolution procedure is completed, the allocated temporary block flow is released; the mobile station returns to packet idle mode, upper layers are notified (TBF establishment failure), transactions in progress are aborted:

- If a TLLI mismatch has occurred during the contention resolution procedure, and the repetition of the packet access has been repeated the maximum number of times as defined in 3GPP TS 04.60, a TBF establishment failure has occurred.
- If the information available in the mobile station, after the reception of an IMMEDIATE ASSIGNMENT message or the second IMMEDIATE ASSIGNMENT message of a two-message assignment, does not satisfactorily define a PDCH, a TBF establishment failure has occurred.
- If the mobile allocation indexes frequencies in more than one frequency band then a TBF establishment failure has occurred.
- If an IMMEDIATE ASSIGNMENT message indicates a PDCH in a non-supported frequency band then a TBF establishment failure has occurred.

On the network side, if timer T3141 elapses before a successful contention resolution procedure is completed, the newly allocated temporary block flow is released as specified in 3GPP TS 04.60 and the packet access is forgotten.

# 3.5.2.2 Sending an RLC/MAC control message: single block packet access procedure

The sending of an RLC/MAC control message other than the PACKET RESOURCE REQUEST message from a mobile station in packet idle mode to the network may be initiated by the RR entity on the mobile station side using the packet access procedure. If access to the network is allowed (sub-clause 3.5.2.1.1), the packet access is done according to the procedures defined in sub-clauses 3.5.2.1.2 and 3.5.2.1.3, using the single block packet access option defined in sub-clause 3.5.2.1.3.3.

Further action depends on the RLC/MAC control message sent by the mobile station, see 3GPP TS 04.60. Unless otherwise indicated by the RLC/MAC control message, the mobile station remains in packet idle mode.

# 3.5.3 Packet downlink assignment procedure using CCCH

The packet downlink assignment procedure using CCCH may be used to establish a temporary block flow to support the transfer of LLC PDUs in the direction from the network to the mobile station.

This procedure may also be used to assign a single downlink block on a PDCH to support the transfer of an RLC/MAC control message from the network to a mobile station in packet idle mode, see sub-clause 3.5.3.2.

# 3.5.3.1 Entering the packet transfer mode: packet downlink assignment procedure

The establishment of a downlink temporary block flow may be initiated by the RR entity on the network side using the packet downlink assignment procedure. The procedure is triggered by a request from upper layers to transfer a LLC PDU, see 3GPP TS 04.07. The request from upper layers specifies an optional *Priority* level, a QoS profile including the requested *RLC mode*, optional *DRX parameters*, an optional *IMSI* and an optional *MS Radio Access Capability* associated with the packet transfer.

Upon such a request, the network shall determine whether the mobile station is in packet idle mode or packet transfer mode. The packet downlink assignment procedure using CCCH is applicable when the mobile station is in packet idle mode and when there is no PCCCH present in the cell.

The network may allocate a temporary flow identity and assign a packet downlink resource comprising one PDCH for a downlink temporary block flow.

#### 3.5.3.1.2 Initiation of the packet downlink assignment procedure

The network initiates the packet downlink assignment procedure by sending an IMMEDIATE ASSIGNMENT message in unacknowledged mode on the CCCH timeslot corresponding to CCCH group the mobile station belongs to. The appropriate CCCH group is calculated from the IMSI, see 05.02. The behaviour of the network when the RR entity does not receive the IMSI from the upper layers is implementation dependent for the calculation of the CCCH group where the IMMEDIATE ASSIGNMENT message has to be sent. If the mobile station is in non-DRX mode or if the RR entity does not receive the IMSI or the DRX parameters from the upper layers, there is no further restriction on what part of the downlink CCCH timeslot the IMMEDIATE ASSIGNMENT message, or the first part of the IMMEDIATE ASSIGNMENT message (in the case of a two-message assignment), can be sent. If the mobile station applies DRX, the IMMEDIATE ASSIGNMENT message, or the first part of the IMMEDIATE ASSIGNMENT message (in the case of a two-message assignment), shall be sent in a CCCH block corresponding to a paging group determined for the mobile station in packet idle mode, see 3GPP TS 05.02.

The IMMEDIATE ASSIGNMENT message contains:

- the packet channel description;
- the initial timing advance;
- the packet downlink assignment construction.

The contents of the packet downlink assignment construction determines the further action. At the establishment of a downlink temporary block flow, the packet downlink assignment construction shall contain:

- the TLLI;
- the temporary flow identity;
- the RLC mode;
- the power control parameters;
- the polling bit;
- the initial timing advance validity flag;
- optionally, the timing advance index (see 3GPP TS 05.10);
- optionally, the TBF starting time.

If frequency hopping is applied, the network may use the indirect encoding or the direct encoding of the frequency configuration in the *Packet Channel Description* information element. If the indirect encoding is used, the mobile station uses information received in system information or stored from a previous assignment to determine the frequency parameters, see 3GPP TS 04.60. If the direct encoding is used, the mobile station uses the cell allocation defined for the cell to decode the mobile allocation.

If the *indirect encoding* is used, the IMMEDIATE ASSIGNMENT message may contain a CHANGE\_MARK\_1 field. If that is present, the mobile station shall verify the validity of the SI *change mark* associated with the GPRS mobile allocation to which the message refers, see 3GPP TS 04.60. If the CHANGE\_MARK\_1 field and the SI *change mark* do not match, the message does not satisfactorily define a PDCH.

If the mobile station receives an IMMEDIATE ASSIGNMENT message and the *Dedicated mode or TBF* information element indicates that this is the first message in a two-message assignment, the mobile station shall start listen to the full CCCH. The network may send a second IMMEDIATE ASSIGNMENT message to the mobile station within two multiframe periods following the first IMMEDIATE ASSIGNMENT message, specifying the packet channel description and, if required, a mobile allocation for the assignment. The two IMMEDIATE ASSIGNMENT message assignment shall have the same contents of the *Request Reference* information elements.

If the mobile station was operating in DRX mode when it received the first message of a two-message assignment, the network shall not send the second IMMEDIATE ASSIGNMENT message within the two block periods immediately following the first message.

If the mobile station does not receive the second IMMEDIATE ASSIGNMENT messages in a two-message assignment within two multiframe periods following the first message, the mobile station shall discard the first IMMEDIATE ASSIGNMENT message received. After the two multiframe periods following the first message, the mobile station may resume to DRX mode.

On receipt of an IMMEDIATE ASSIGNMENT message or, in case of a two-message assignment, a matching pair of IMMEDIATE ASSIGNMENT messages, the mobile station stops monitoring downlink CCCH and switches to the assigned PDCH and starts listening for downlink RLC/MAC blocks identified by the assigned TFI; it starts timer T3190.

The IMMEDIATE ASSIGNMENT message may indicate a TBF starting time. If the mobile station receives the message before the TBF starting time has expired, it shall wait until the frame number indicated by the TBF starting time, start timer T3190 and switch to the assigned PDCH. If the mobile station receives the message after the TBF starting time has expired, it shall ignore the indicated TBF starting time, immediately start timer T3190 and switch to the assigned PDCH.

If the Polling bit is set to 1, MS shall send a PACKET CONTROL ACKNOWLEDGEMENT message (see 04.60) on the assigned PDCH, in the uplink block specified by the TBF Starting Time. In this case the TBF Starting Time is used both to indicate when the assigned PDCH becomes valid and to specify the uplink block. If the TBF Starting Time is not present or has expired, the MS shall ignore the polling request.

An IMMEDIATE ASSIGNMENT message may indicate a timing advance index (TAI) in the packet timing advance IE. The mobile station shall then use the continuous update timing advance mechanism, see 3GPP TS 05.10, using PTCCH in the same timeslot as the assigned PDCH. If there is no indication of a timing advance index, the continuous update timing advance mechanism shall not be used.

The TA\_VALID flag indicates if the value of the *Timing Advance* IE is valid or not.

If the network does not have a valid timing advance value for the mobile station to include in the IMMEDIATE ASSIGNMENT message, the network shall use the procedures defined in 3GPP TS 04.60 on the assigned TBF, or the polling mechanism defined in the above paragraph if the PACKET CONTROL ACKNOWLEDGEMENT format is set to four access bursts, to obtain a timing advance value and to update the initially assigned timing advance value before the mobile station is required to transmit other than access burst on the newly assigned channel.

#### 3.5.3.1.3 Packet downlink assignment completion

After having sent the packet downlink assignment, the network starts sending downlink RLC/MAC blocks on the assigned packet downlink resource and the packet downlink assignment procedure is completed at the network side.

On the mobile station side, the procedure is completed when the mobile station receives an RLC/MAC block identified by the assigned temporary flow identity. The mobile station stops timer T3190. The mobile station has entered packet transfer mode.

#### 3.5.3.1.4 Abnormal cases

If a failure occurs on the mobile station side before the packet downlink assignment procedure is completed (TBF establishment failure), the temporary block flow is released; the mobile station returns to packet idle mode:

- If the mobile station does not receive a RLC/MAC block on the assigned PDCHs before timer T3190 expires, then a TBF establishment failure has occurred.
- If the information available in the mobile station, after the reception of an IMMEDIATE ASSIGNMENT message or the second IMMEDIATE ASSIGNMENT message of a two-message assignment, does not satisfactorily define a PDCH, then a TBF establishment failure has occurred.
- If the mobile allocation in the frequency parameters indexes frequencies in more than one frequency band, then a TBF establishment failure has occurred.

If an IMMEDIATE ASSIGNMENT message indicates a PDCH in a non-supported frequency band, then a TBF establishment failure has occurred.

## 3.5.3.2 Sending an RLC/MAC control message: single block packet downlink assignment procedure

The sending of an RLC/MAC control message to a mobile station in packet idle mode may be initiated by the RR entity on network side using the packet downlink assignment procedure. The procedure is used to assign a single downlink block on a PDCH for the transfer of the RLC/MAC control message.

The single downlink block assignment is done according to the procedure defined in 3.5.3.1.2, with the following exceptions:

The packet downlink assignment construction in the IMMEDIATE ASSIGNMENT message shall contain only:

- the TLLI; and
- the TBF starting time.

If the mobile station receives the IMMEDIATE ASSIGNMENT message before the TBF starting time has expired, it shall wait until the frame number indicated by the TBF starting time. The network shall use the TBF starting time to indicate the first frame number belonging to the single block period assigned to the mobile station. The mobile station shall switch to the assigned PDCH and attempt to decode an RLC/MAC control message in the assigned downlink block. Further action depends on the RLC/MAC control message sent by the network, see 3GPP TS 04.60. Unless otherwise indicated by the RLC/MAC control message, the mobile station remains in packet idle mode. If the mobile station remains in packet idle mode, it shall continue to monitor downlink CCCH once the block period indicated by the TBF starting time has passed.

If the mobile station fails to decode or does not receive an RLC/MAC control message in the assigned downlink block, it shall remain in packet idle mode and continue to monitor downlink CCCH once the block period indicated by the TBF starting time has passed.

If the mobile station receives the IMMEDIATE ASSIGNMENT message after the TBF starting time has expired, it shall ignore the assignment.

If a failure occurs on the mobile station side due to any other reason, the mobile station shall ignore the assignment.

# 4 Elementary procedures for Mobility Management

# 4.1 General

This sub-clause describes the procedures used for mobility management for non-GPRS services and for GPRS-services at the radio interface (Reference Point Um).

The main function of the Mobility Management sublayer is to support the mobility of user terminals, such as informing the network of its present location and providing user identity confidentiality.

A further function of the MM sublayer is to provide connection management services to the different entities of the upper Connection Management (CM) sublayer (see 3GPP TS 04.07).

There are two sets of procedures defined in this chapter:

- MM procedures for non-GPRS services (performed by the MM entity of the MM sublayer); and
- GMM procedures for GPRS services (performed by the GMM entity and GMM-AA entity of the MM sublayer), see 3GPP TS 04.07 [20].

All the MM procedures described in this sub-clause can only be performed if a RR connection has been established between the MS and the network. Else, the MM sublayer has to initiate the establishment of a RR connection according to the procedures specified in sub-clause 3.3. The GMM procedures described in this sub-clause, use services provided by the RR sublayer without prior RR connection establishment.

GMM procedures are mandatory and applicable only for GPRS MSs and networks supporting those MSs. For GPRS MSs which are IMSI attached for both GPRS and non-GPRS services, some MM procedures are replaced by GMM combined procedures provided that the network operates in network operation mode I, i.e. is supporting combined GMM procedures. GMM combined procedures are not applicable for the GPRS MS operation mode C but are mandatory for the GPRS MS operation modes A and B and networks supporting network operation mode I, see 3GPP TS 03.60.

# 4.1.1 MM and GMM procedures

#### 4.1.1.1 Types of MM and GMM procedures

Depending on how they can be initiated, three types of MM procedures can be distinguished:

1) MM common procedures:

A MM common procedure can always be initiated whilst a RR connection exists. The procedures belonging to this type are:

Initiated by the network:

- TMSI reallocation procedure;
- authentication procedure;
- identification procedure;
- MM information procedure;
- abort procedure.

However, abort procedure is used only if an MM connection is being established or has already been established i.e. not during MM specific procedures or during IMSI detach procedure, see sub-clause 4.3.5.

Initiated by the mobile station:

- IMSI detach procedure (with the exceptions specified in sub-clause 4.3.4).
- ii) MM specific procedures:

A MM specific procedure can only be initiated if no other MM specific procedure is running or no MM connection exists. The procedures belonging to this type are:

- normal location updating procedure;
- periodic updating procedure;
- IMSI attach procedure.

iii) MM connection management procedures:

These procedures are used to establish, maintain and release a MM connection between the mobile station and the network, over which an entity of the upper CM layer can exchange information with its peer. A MM connection establishment can only be performed if no MM specific procedure is running. More than one MM connection may be active at the same time. Depending on how they can be initiated, two types of GMM procedures can be distinguished:

i) GMM common procedures:

Initiated by the network when a GMM context has been established:

- P-TMSI (re-) allocation;
- GPRS authentication and ciphering;
- GPRS identification;
- GPRS information.
- ii) GMM specific procedures:

Initiated by the network and used to detach the IMSI in the network for GPRS services and/or non-GPRS services and to release a GMM context:

- GPRS detach.

Initiated by the MS and used to attach or detach the IMSI in the network for GPRS services and/or non-GPRS services and to establish or release a GMM context:

- GPRS attach and combined GPRS attach;
- GPRS detach and combined GPRS detach.

Initiated by the MS when a GMM context has been established:

- normal routing area updating and combined routing area updating;
- periodic routing area updating.

## 4.1.1.2 MM-GMM co-ordination for GPRS MS's

## 4.1.1.2.1 GPRS MS operating in mode A or B in a network that operates in mode I

If the network operates in mode I, GPRS MSs that operate in mode A or B and wish to be or are simultaneously IMSI attached for GPRS and non-GPRS services, shall use the combined GPRS attach and the combined and periodic routing area updating procedures instead of the corresponding MM specific procedures IMSI attach and normal and periodic location area updating.

NOTE 1: A GPRS MS operating in mode A or B in a network that operates in mode I, shall perform the combined GPRS attach or routing area update procedure regardless the value of the ATT flag.

If a GPRS MS is operating in mode A or B in a network that operates in mode I the IMSI detach shall be performed by the GMM using the combined GPRS detach procedure.

NOTE 2: A GPRS MS operating in mode A or B in a network that operates in mode I, shall perform the combined GPRS detach procedure regardless the value of the ATT flag.

A GPRS MS operating in mode A or B in network that operates in mode I, uses the combined GMM specific procedures in place of the MM specific procedures, so all conditions describing when to trigger a MM specific procedure listed in sub-clauses 4.3 and 4.4 shall not apply.

A GPRS MS operating in mode A or B in a network that operates in mode I should not use any MM timers relating to MM specific procedures, (e.g T3210, T3211, T3212, T3213) except in some error and abnormal cases. If the MM timers are already running, the MS should not react on the expiration of the timers.

NOTE 3: Whenever GMM performs a combined GMM procedure, a GPRS MS enters the MM state MM LOCATION UPDATING PENDING in order to prevent the MM to perform a location update procedure.

If the authentication procedure is performed by MM and the authentication is rejected by the network (i.e upon receive of AUTHENTICATION REJECT), the MS shall in addition set the GPRS update status to GU3 ROAMING NOT ALLOWED and shall, if available, delete the P-TMSI, P-TMSI signature, RAI and GPRS ciphering key sequence number stored. The SIM shall be considered as invalid for GPRS and non-GPRS services until switching off or the SIM is removed. The MS shall abort any GMM procedure and shall enter state GMM-DEREGISTERED.

#### 4.1.1.2.2 GPRS MS operating in mode A or B in a network that operates in mode II or III

If the network operates in mode II or III, a GPRS MSs that operate in mode A or B and wish to be or are simultaneously IMSI attached for GPRS and non-GPRS services, shall use the MM specific procedures listed in sub-clauses 4.3 and 4.4 and the GMM specific procedures listed in sub-clauses 4.7.3, 4.7.4 and 4.7.5. The applicability of periodic location updating is further specified in sub-clause 4.4.2 and the periodic routing area updating is specified in sub-clause 4.7.2.2.

If the authentication procedure is performed by MM and the authentication is rejected by the network (i.e upon receive of AUTHENTICATION REJECT), the MS shall in addition set the GPRS update status to GU3 ROAMING NOT ALLOWED and shall, if available, delete the P-TMSI, P-TMSI signature, RAI and GPRS ciphering key sequence number stored. The SIM shall be considered as invalid for GPRS and non-GPRS services until switching off or the SIM is removed. The MS shall abort any GMM procedure and shall enter state GMM-DEREGISTERED.

# 4.1.2 MM sublayer states

The description of the states for the MM sublayer is organized as follows. The main states for the MS side, related to the procedures, are described in sub-clause 4.1.2.1.1. The MM IDLE state is subdivided in substates for the description of the behaviour in idle mode (sub-clause 4.1.2.1.2). This behaviour depends on an update status, described in 4.1.2.2. The states for the network side are described in 4.1.2.3.

# 4.1.2.1 MM sublayer states in the mobile station

In this sub-clause, the possible states for the MM sublayer in the mobile station is described. In figure 4.1/3GPP TS 04.08 an overview of the MM sublayer protocol is given.

#### 4.1.2.1.1 Main states

0 NULL

The mobile station is inactive (e.g. power down). Important parameters are stored. Only manual action by the user may transfer the MM sublayer to another state.

### **3** LOCATION UPDATING INITIATED

A location updating procedure has been started and the MM awaits a response from the network. The timer T3210 is running.

5 WAIT FOR OUTGOING MM CONNECTION

The MM connection establishment has been started, and the MM awaits a response from the network. The timer T3230 is running.

## 6 MM CONNECTION ACTIVE

The MM sublayer has a RR connection to its peer entity on the network side. One or more MM connections are active.

## 7 IMSI DETACH INITIATED

The IMSI detach procedure has been started. The timer T3220 is running.

## 8 PROCESS CM SERVICE PROMPT

The MM sublayer has a RR connection to its peer entity on the network side. The Mobile Station has received a CM SERVICE PROMPT message but has not yet responded \$(CCBS)\$.

# 9 WAIT FOR NETWORK COMMAND

The MM sublayer has a RR connection to its peer entity in the network, but no MM connection is established. The mobile station is passive, awaiting further commands from the network. The timer T3240 may be running.

## 10 LOCATION UPDATE REJECTED

A location updating procedure has been rejected and RR connection release is awaited. The timer T3240 is running.





Figure 4.1a / 3GPP TS 04.08: Overview mobility management protocol / MS Side

**ETSI** 

96



Additions to Figure 4.1.a/3GPP TS 04.08

#### 13. WAIT FOR RR CONNECTION (LOCATION UPDATING)

The MM sublayer has requested RR connection establishment for starting the location updating procedure.

#### 14. WAIT FOR RR CONNECTION (MM CONNECTION)

The MM sublayer has requested RR connection establishment for dedicated mode for starting the MM connection establishment.

#### 15. WAIT FOR RR CONNECTION (IMSI DETACH)

The MM sublayer has requested RR connection establishment for starting the IMSI detach procedure.

#### 17. WAIT FOR REESTABLISH

A lower layer failure has occurred and re-establishment may be performed from the disturbed CM layer entities.

#### 18. WAIT FOR RR ACTIVE

The MM sublayer has requested activation of the RR sublayer.

#### 19. MM IDLE

There is no MM procedure running and no RR connection exists except that a local MM context may exist when the RR sublayer is in Group Receive mode. This is a compound state, and the actual behaviour of the mobile station to Connection Management requests is determined by the actual substate as described hereafter.

#### 20. WAIT FOR ADDITIONAL OUTGOING MM CONNECTION.

The MM connection establishment for an additional MM connection has been started, and the MM awaits response from the network.

#### 21. MM CONNECTION ACTIVE (GROUP TRANSMIT MODE)

(Only applicable for mobile stations supporting VGCS talking:) The MM sublayer has a RR connection on the VGCS channel to its peer entity on the network side. Only one MM connection is active.

#### 22. WAIT FOR RR CONNECTION (GROUP TRANSMIT MODE)

(Only applicable for mobile stations supporting VGCS talking:) The MM sublayer has requested to perform an uplink access on the VGCS channel.

#### 23. LOCATION UPDATING PENDING

(Only applicable for GPRS MS operation modes A and B; not shown in figure 4.1a) A location updating has been started using the combined GPRS routing area updating procedure.

#### 24. IMSI DETACH PENDING

(Only applicable for GPRS MS operation modes A and B; not shown in figure 4.1a) An IMSI detach for non-GPRS services has been started using the combined GPRS detach procedure at not switching off.

#### 25. RR CONNECTION RELEASE NOT ALLOWED

(Only applicable for mobile stations supporting RRLP procedures). All MM connections are released by their CM entities, but the RR connection is maintained by the network due to an ongoing RRLP procedure (see 3GPP TS 04.31 [23b]).

#### 4.1.2.1.2 Substates of the MM IDLE state

For the description of the behaviour of the MS the MM IDLE state is subdivided in several substates, also called the service states. The service state pertains to the whole MS (ME alone if no SIM is inserted, or ME plus SIM.). The service state depends on the update status (see sub-clause 4.1.2.2) and on the selected cell.

#### **19.1 NORMAL SERVICE**

Valid subscriber data are available, update status is U1, a cell is selected that belongs to the LA where the subscriber is registered.

In this state, all requests from the CM layers are treated normally.

#### **19.2 ATTEMPTING TO UPDATE**

Valid subscriber data are available, update status is U2 and a cell is selected. Requests from upper layers are accepted. Emergency call requests are treated normally, otherwise the request triggers first a location updating attempt in the selected cell, and then triggers the needed procedure only in case of successful location updating, otherwise the request is rejected.

#### **19.3 LIMITED SERVICE**

Valid subscriber data are available, update status is U3, and a cell is selected, which is known not to be able to provide normal service. Only emergency services are offered.

#### 19.4 NO IMSI

No valid subscriber data (no SIM, or the SIM is not considered valid by the ME), and a cell is selected. Only emergency services are offered.

#### 19.5 NO CELL AVAILABLE

No cell can be selected. This state is entered after a first intensive search failed (state 19.7). Cells are searched at a low rhythm. No services are offered.

#### **19.6 LOCATION UPDATE NEEDED**

Valid subscriber data are available, and for some reason a location updating must be done as soon as possible (for instance update status is U1 but the selected cell is not in the registered LA, or the timer has expired, ...). This state is usually of no duration, but can last, e.g., in the case of access class blocking.

#### 19.7 PLMN SEARCH

The mobile station is searching for PLMNs, and the conditions for state 19.8 are not met. This state is ended when either a cell is selected (the new state is 19.1, 19.3 or 19.6), or when it is concluded that no cell is available for the moment (the new state is 19.5).

#### 19.8 PLMN SEARCH, NORMAL SERVICE

Valid subscriber data are available, update status is U1, a cell is selected which belongs to the LA where the subscriber is registered, and the mobile station is searching for PLMNs. This state is ended when either a cell is selected (the new state is 19.1, 19.3 or 19.6), or when it is concluded that no cell is available for the moment (the new state is 19.5).

#### 19.9 RECEIVING GROUP CALL (NORMAL SERVICE)

Only applicable for mobile stations supporting VGCS listening or VBS listening. Valid subscriber data are available, update status is U1, a VGCS channel or VBS channel is received in a cell that belongs to the LA where the subscriber is registered.

In this state, only requests from the GCC or BCC layers are treated.

#### 19.10 RECEIVING GROUP CALL (LIMITED SERVICE)

Only applicable for mobile stations supporting VGCS listening or VBS listening. Valid subscriber data are available, update status is U3, a VGCS channel or VBS channel is received in a cell which is known not to be able to provide normal service.

In this state, only requests from the GCC or BCC layers for the reception of VGCS or VBS calls are treated and group call emergency services are offered.

## 4.1.2.2 The update Status

In parallel with the sublayer states described in sub-clause 4.1.2.1 and which control the MM sublayer protocol, an update status exists.

The update status pertains to a specific subscriber embodied by a SIM. This status is defined even when the subscriber is not activated (SIM removed or connected to a switched-off ME). It is stored in a non volatile memory in the SIM. The update status is changed only as a result of a location updating procedure attempt (with the exception of an authentication failure and of some cases of CM service rejection). In some cases, the update status is changed as a result of a GPRS attach, GPRS routing area update, or network initiated GPRS detach procedure.

#### U1 UPDATED

The last location updating attempt was successful (correct procedure outcome, and the answer was acceptance from the network). With this status, the SIM contains also the LAI of the LA where the subscriber is registered, and possibly valid TMSI, ciphering key and ciphering key sequence number. The "Location update status" stored on the SIM shall be "updated".

#### **U2 NOT UPDATED**

The last location updating attempt made failed procedurally (no significant answer was received from the network, including the cases of failures or congestion inside the network).

For this status, the SIM does not contain any valid LAI, TMSI, ciphering key or ciphering key sequence number. For compatibility reasons, all these fields must be set to the "deleted" value at the moment the status is set to NOT UPDATED. However the presence of other values shall not be considered an error by the mobile station. The "Location update status" stored on the SIM shall be "not updated".

#### **U3 ROAMING NOT ALLOWED**

The last location updating attempt run correctly, but the answer from the network was negative (because of roaming or subscription restrictions).

For this status, the SIM does not contain any valid LAI, TMSI, ciphering key or ciphering key sequence number. For compatibility reasons, all these fields must be set to the "deleted" value at the moment the status is set to ROAMING NOT ALLOWED. However the presence of other values shall not be considered an error by the mobile station. The "Location update status" stored on the SIM shall be "Location Area not allowed".

#### 4.1.2.3 MM sublayer states on the network side

#### 1. IDLE

The MM sublayer is not active except possibly when the RR sublayer is in Group Receive mode.

#### 2. WAIT FOR RR CONNECTION

The MM sublayer has received a request for MM connection establishment from the CM layer. A RR connection to the mobile station is requested from the RR sublayer (i.e. paging is performed).

#### 3. MM CONNECTION ACTIVE

The MM sublayer has a RR connection to a mobile station. One or more MM connections are active, or no MM connection is active but an RRLP procedure is ongoing.

#### 4. IDENTIFICATION INITIATED

The identification procedure has been started by the network. The timer T3270 is running.

#### 5. AUTHENTICATION INITIATED

The authentication procedure has been started by the network. The timer T3260 is running.

#### 6. TMSI REALLOCATION INITIATED

The TMSI reallocation procedure has been started by the network. The timer T3250 is running.

#### 7. CIPHERING MODE INITIATED

The cipher mode setting procedure has been requested to the RR sublayer.

#### 8a. WAIT FOR MOBILE ORIGINATED MM CONNECTION

A CM SERVICE REQUEST message is received and processed, and the MM sublayer awaits the "opening message" of the MM connection.

#### 8b. WAIT FOR NETWORK ORIGINATED MM CONNECTION

A CM SERVICE PROMPT message has been sent by the network and the MM sublayer awaits the "opening message" of the MM connection \$(CCBS)\$.

#### 9. WAIT FOR REESTABLISHMENT

The RR connection to a mobile station with one or more active MM connection has been lost. The network awaits a possible re-establishment request from the mobile station.

#### 10. WAIT OF A GROUP CALL

Only applicable in case for mobile station supporting VGCS talking. The MM sublayer has received a request for establishing a VGCS from the GCC sublayer. The request for establishing a VGCS channels is given to the RR sublayer.

#### 11. GROUP CALL ACTIVE

Only applicable in case of mobile station supporting VGCS talking. A VGCS channel is established by the RR sublayer. An RR connection to the talking mobile station can be established by the RR sublayer on the VGCS channel. The MM sublayer is active but no sending of MM message between the network and the mobile station has occurred.

#### 12. MM CONNECTION ACTIVE (GROUP CALL)

Only applicable in case of mobile station supporting VGCS talking. The MM sublayer has a RR connection to the talking mobile station on the VGCS channel. Only one MM connection is active.

#### 13. WAIT FOR BROADCAST CALL

Only applicable in case of VBS. The MM sublayer has received a request for a VBS establishment from the BCC sublayer. The request for establishment of VBS channels is given to the RR sublayer.

#### 14. BROADCAST CALL ACTIVE

Only applicable in case of VBS. A VBS channel is established by the RR sublayer. The MM sublayer is active but no explicit MM establishment between the Network and the mobile station has occurred.

# 4.1.3 GPRS mobility management (GMM) sublayer states

In this sub-clause, the GMM protocol of the MS and the network are described by means of two different state machines. In sub-clause 4.1.3.1, the states of the GMM entity in the MS are introduced. The behaviour of the MS depends on a GPRS update status that is described in sub-clause 4.1.3.2. The states for the network side are described in sub-clause 4.1.3.3.

#### 4.1.3.1 GMM states in the MS

In this sub-clause, the possible GMM states are described of a GMM entity in the mobile station. sub-clause 4.1.3.1.1 summarises the main states of a GMM entity, see figure 4.1b/3GPP TS 04.08. The substates that have been defined are described in sub-clause 4.1.3.1.2 and sub-clause 4.1.3.1.3.

However, it should be noted that this sub-clause does not include a description of the detailed behaviour of the MS in the single states and does not cover abnormal cases. Thus, figure 4.1b/3GPP TS 04.08 is rather intended to give an overview of the state transitions than to be a complete state transition diagram. A detailed description of the behaviour of the MS is given in sub-clause 4.2. Especially, with respect to the behaviour of the MS in abnormal cases it is referred to sub-clause 4.7.

#### 4.1.3.1.1 Main states

#### 4.1.3.1.1.1 GMM-NULL

The GPRS capability is disabled in the MS. No GPRS mobility management function shall be performed in this state.

#### 3GPP TS 04.08 version 7.21.0 Release 1998

102

#### 4.1.3.1.1.2 GMM-DEREGISTERED

The GPRS capability has been enabled in the MS, but no GMM context has been established. In this state, the MS may establish a GMM context by starting the GPRS attach or combined GPRS attach procedure.

#### 4.1.3.1.1.3 GMM-REGISTERED-INITIATED

A GPRS attach or combined GPRS attach procedure has been started and the MS is awaiting a response from the network.

#### 4.1.3.1.1.4 GMM-REGISTERED

A GMM context has been established, i.e. the GPRS attach or combined GPRS attach procedure has been successfully performed. In this state, the MS may activate PDP contexts, may send and receive user data and signalling information and may reply to a page request. Furthermore, cell and routing area updating are performed.

#### 4.1.3.1.1.5 GMM-DEREGISTERED-INITIATED

The MS has requested release of the GMM context by starting the GPRS detach or combined GPRS detach procedure. This state is only entered if the MS is not being switched off at detach request.

#### 4.1.3.1.1.6 GMM-ROUTING-AREA-UPDATING-INITIATED

A routing area updating procedure has been started and the MS is awaiting a response from the network.

#### 4.1.3.1.2 Substates of state GMM-DEREGISTERED

The GMM-DEREGISTERED state is subdivided into several substates as explained below. The substates pertain to the whole MS (ME alone if no SIM is inserted, or ME plus SIM). The selection of the appropriate substate depends on the GPRS update status, see sub-clause 4.1.3.2, and on the selected cell.

#### 4.1.3.1.2.1 GMM-DEREGISTERED.NORMAL-SERVICE

Valid subscriber data is available, the GPRS update status is GU1 or GU2, a cell has been selected. In this state, a request for GPRS attach is performed using the stored temporary mobile subscriber identity for GPRS (P-TMSI), routing area identification (RAI) and GPRS ciphering key sequence number in case of GU1. If the GPRS update status is GU2, the IMSI shall be used to attach for GPRS services.

#### 4.1.3.1.2.2 GMM-DEREGISTERED.LIMITED-SERVICE

Valid subscriber data is available, GPRS update status is GU3, and a cell is selected, which is known not to be able to provide normal service.

#### 4.1.3.1.2.3 GMM-DEREGISTERED.ATTACH-NEEDED

Valid subscriber data is available and for some reason a GPRS attach must be performed as soon as possible. This state is usually of no duration, but can last, e.g. if the access class is blocked.

#### 4.1.3.1.2.4 GMM-DEREGISTERED.ATTEMPTING-TO-ATTACH

The GPRS update status is GU2, a cell is selected, a previous GPRS attach was rejected. The execution of further attach procedures depends on the GPRS attach attempt counter. No GMM procedure except GPRS attach shall be initiated by the MS in this substate.

#### 4.1.3.1.2.5 GMM-DEREGISTERED.NO-IMSI

No valid subscriber data is available (no SIM, or the SIM is not considered valid by the ME) and a cell has been selected.

#### 4.1.3.1.2.6 GMM-DEREGISTERED.NO-CELL-AVAILABLE

No cell can be selected. This substate is entered after a first intensive search failed (substate PLMN SEARCH). Cells are searched for at a low rhythm. No services are offered.

#### 4.1.3.1.2.7 GMM-DEREGISTERED.PLMN-SEARCH

The mobile station is searching for PLMNs. This substate is left either when a cell has been selected (the new substate is NORMAL-SERVICE or LIMITED-SERVICE) or when it has been concluded that no cell is available at the moment (the new substate is NO-CELL-AVAILABLE).

#### 4.1.3.1.2.8 GMM-DEREGISTERED.SUSPENDED

The MS shall enter this substate when entering dedicated mode and the MS limitations make it unable to communicate on GPRS channels. The MS shall leave this substate when leaving dedicated mode.

#### 4.1.3.1.3 Substates of state GMM-REGISTERED

The state GMM-REGISTERED is subdivided into several substate as explained below. The substates pertain to the whole MS (ME alone if no SIM is inserted, or ME plus SIM.).

#### 4.1.3.1.3.1 GMM-REGISTERED.NORMAL-SERVICE

User data and signalling information may be sent and received.

#### 4.1.3.1.3.2 GMM-REGISTERED.SUSPENDED

The MS shall enter this substate when entering dedicated mode and when the MS limitations makes it unable to communicate on GPRS channels... In this substate, no user data should be sent and no signalling information shall be sent. The MS shall leave this substate when leaving dedicated mode.

#### 4.1.3.1.3.3 GMM-REGISTERED.UPDATE-NEEDED

The MS has to perform a routing area updating procedure, but its access class is not allowed in the cell. The procedure will be initiated as soon as access is granted (this might be due to a cell-reselection or due to change of the access class of the current cell). No GMM procedure except routing area updating shall be initiated by the MS in this substate. In this substate, no user data and no signalling information shall be sent.

#### 4.1.3.1.3.4 GMM-REGISTERED.ATTEMPTING-TO-UPDATE

A routing area updating procedure failed due to a missing response from the network. The MS retries the procedure controlled by timers and a GPRS attempt counter. No GMM procedure except routing area updating shall be initiated by the MS in this substate. No data shall be sent or received.

#### 4.1.3.1.3.5 GMM-REGISTERED.NO-CELL-AVAILABLE

GPRS coverage has been lost. In this substate, the MS shall not initiate any GMM procedures except of cell (and PLMN) reselection.




Figure 4.1b/3GPP TS 04.08: GMM main states in the MS

#### 4.1.3.1.3.6 GMM-REGISTERED.LIMITED-SERVICE

A cell is selected, which is known not to be able to provide normal service. The MS will remain in this sub-state until a cell is selected which is able to provide normal service.

#### 4.1.3.1.3.7 GMM-REGISTERED.ATTEMPTING-TO-UPDATE-MM

A combined routing area updating procedure or a combined GPRS attach procedure was successful for GPRS services only. The MS retries the procedure controlled by timers and a GPRS attempt counter. User data and signalling information may be sent and received.

#### 4.1.3.1.3.8 GMM-REGISTERED.IMSI-DETACH-INITIATED

The MS performs a combined GPRS detach procedure for non-GPRS services only (detach type "IMSI Detach"). This state is entered if the MS is attached for GPRS and non-GPRS services in a network that operates in network mode I and wants to detach for non-GPRS services only. User data and signalling information may be sent and received.

# 4.1.3.2 GPRS update status

In addition to the GMM sublayer states described so far, a GPRS update status exists.

The GPRS update status pertains to a specific subscriber embodied by a SIM. This status is defined even when the subscriber is not activated (SIM removed or connected to a switched off ME). It is stored in a non volatile memory in the SIM. The GPRS update status is changed only after execution of a GPRS attach, network initiated GPRS detach, authentication procedure, or routing area updating procedure.

#### **GU1: UPDATED**

The last GPRS attach or routing area updating attempt was successful (correct procedure outcome, and the answer was accepted by the network). The SIM contains the RAI of the routing area (RA) to which the subscriber was attached, and possibly a valid P-TMSI, GPRS ciphering key and GPRS ciphering key sequence number.

#### GU2: NOT UPDATED

The last GPRS attach or routing area updating attempt failed procedurally, i.e. no response was received from the network. This includes the cases of failures or congestion inside the network.

In this case, the SIM may contain the RAI of the routing area (RA) to which the subscriber was attached, and possibly also a valid P-TMSI, GPRS ciphering key and GPRS ciphering key sequence number. For compatibility reasons, all these fields shall be set to the "deleted" value if the RAI is deleted. However, the presence of other values shall not be considered an error by the MS.

#### **GU3: ROAMING NOT ALLOWED**

The last GPRS attach or routing area updating attempt was correctly performed, but the answer from the network was negative (because of roaming or subscription restrictions).

For this status, the SIM does not contain any valid RAI, P-TMSI, GPRS ciphering key or GPRS ciphering key sequence number. For compatibility reasons, all these fields must be set to the value "deleted" at the moment the status is set to ROAMING NOT ALLOWED. However, the presence of other values shall not be considered an error by the MS.

#### 4.1.3.3 GMM mobility management states on the network side

In this sub-clause, the possible states are described for the GMM on the network side. sub-clause 4.1.3.3.1 summarises the main states. The corresponding substates are described in sub-clause 4.1.3.3.2.

However, it should be noted that this sub-clause does not include a description of the detailed behaviour of the network in the single states and does not cover abnormal cases. Thus, figure 4.1c/3GPP TS 04.08 is rather intended to give an overview of the state transitions than to be a complete state transition diagram. A detailed description of the behaviour of the MS is given in sub-clause 4.2. Especially, with respect to the behaviour of the MS in abnormal cases it is referred to sub-clause 4.7.

#### 4.1.3.3.1 Main States

#### 4.1.3.3.1.1 GMM-DEREGISTERED

The network has no GMM context or the GMM context is marked as detached, the MS is detached. In this state, the network may answer to a GPRS attach or combined GPRS attach procedure initiated by the MS.

#### 4.1.3.3.1.2 GMM-COMMON-PROCEDURE-INITIATED


A common GMM procedure, as defined in sub-clause 4.1.1, has been started. The network is awaiting the answer from the MS.

#### 4.1.3.3.1.3 GMM-REGISTERED

The GMM context has been established and the GPRS attach procedure has been successfully performed.

#### 4.1.3.3.1.4 GMM-DEREGISTERED-INITIATED

The network has started a GPRS detach procedure and is awaiting the answer from the MS.



#### Figure 4.1c/3GPP TS 04.08: GMM main states on the network side

## 4.1.3.3.2 Substates of state GMM-REGISTERED

The state GMM-REGISTERED is subdivided into two substates as explained below.

#### 4.1.3.3.2.1 GMM-REGISTERED.NORMAL-SERVICE

User data and signalling information may be sent and received.

#### 4.1.3.3.2.2 GMM-REGISTERED.SUSPENDED

In this substate, the lower layers shall be prevented of sending user data or signalling information.

# 4.2 Behaviour of the MS in MM Idle state, GMM-DEREGISTERED state and GMM-REGISTERED state

In this sub-clause, the detailed behaviour of the MS in the main states MM IDLE, GMM-DEREGISTERED and GMM-REGISTERED is described. Sub-clauses 4.2.1 to 4.2.3 refer to the state MM IDLE, whereas sub-clause 4.2.4 and sub-clause 4.2.5 refer to the states GMM-DEREGISTERED and GMM-REGISTERED, respectively.

The MM IDLE state is entered when none of the MM procedures are running and no RR connection exists. It is left when one of the MM procedures are triggered or a RR connection is established.

The specific behaviour in the MM IDLE state depends on the service state of the mobile station as described in subclause 4.1.2.1.2. The service state depends in particular on the update status which is defined in sub-clause 4.1.2.2.

How an appropriate service state is chosen after power on is described in sub-clause 4.2.1, and the specific behaviour of the mobile station in MM IDLE state is described in sub-clause 4.2.2. The service state chosen when the MM IDLE state is returned to from any state except NULL state is described in 4.2.3.

It should be noted that transitions between the various MM idle states are caused by (e.g.):

- results of procedures on RR connected mode (see sub-clause 4.2.3);
- insertion or removal of the SIM;
- cell selection/reselection (see also 3GPP TS 03.22);
- PLMN search;
- loss of coverage.

How various MM procedures affects the service state and the update status is described in the detailed descriptions of the procedures in sub-clauses 4.3 to 4.5.

# 4.2.1 Primary Service State selection

# 4.2.1.1 Selection of the Service State after Power On

When mobility management is activated after power-on, the service state is 19.7 PLMN SEARCH. The detailed processing in this state is described in detail in 3GPP TS 03.22 and 05.08, where procedures for power on and selection of PLMN is described in detail. If the "Location update status" stored on the SIM is different from "updated", then the mobile shall act as if the "Location update status" stored on the SIM is "not updated".

The service state when the PLMN SEARCH state is left depends on the outcome of the search and on the presence of the SIM:

- if no cell has been found, the state is NO CELL AVAILABLE, until a cell is found;
- if no SIM is present the state is NO IMSI;
- if the mobile station has been continuously activated since loosing coverage and then returns to coverage, and if the selected cell is in the location area where the mobile station is registered and the timer T3212 has not expired, then the state is NORMAL SERVICE;
- if the selected cell is in the location area where the mobile station is registered and IMSI ATTACH is not required and timer T3212 has not expired, then the state is NORMAL SERVICE;
- if the mobile station is in automatic network selection mode and the selected cell is in a forbidden PLMN or a forbidden LA, then the mobile station enters the LIMITED SERVICE state;
- if the mobile station is in manual network selection mode and no cell of the selected PLMN has been found, then the mobile station enters the LIMITED SERVICE state;
- otherwise, the mobile station enters the LOCATION UPDATE NEEDED state.

# 4.2.1.2 Other Cases

The state PLMN SEARCH is also entered in the following cases:

- In state NO IMSI, a SIM is inserted;
- In any state except NO IMSI, NO CELL AVAILABLE, NORMAL SERVICE and RECEIVING GROUP CALL (NORMAL SERVICE) after the user has asked for a PLMN selection;
- In any state except NO IMSI and NO CELL AVAILABLE, coverage is lost;
- Roaming is denied;
- optionally, when the mobile station is in the ATTEMPTING TO UPDATE state and is in Automatic Network Selection mode and location update attempt counter is greater than or equal to 4.

The service state when the PLMN SEARCH is left depends on the outcome of the search and on the presence of the SIM as specified in sub-clause 4.2.1.1.

## 4.2.2 Detailed Description of the MS behaviour in MM IDLE State

In the MM IDLE state the mobile station shall behave according to the service state. In the following sub-clauses the behaviour is described for the non transient service states. It should be noted that after procedures in RR connected mode, e.g. location updating procedures, sub-clause 4.2.3 applies which specifies the selection of the MM idle state. Furthermore when in sub-state NORMAL SERVICE, if a PLMN selection is requested, the MS enters sub-state SEARCH FOR PLMN, NORMAL SERVICE.

#### 4.2.2.1 Service State, NORMAL SERVICE

When in state MM IDLE and service state NORMAL SERVICE, the mobile station shall:

- perform normal location updating when a new location area is entered;
- perform location updating procedure at expiry of timer T3211 or T3213;
- perform periodic updating at expiration of timer T3212;
- perform IMSI detach;
- support requests from the CM layer;
- respond to paging.

In addition, mobile stations supporting VGCS listening or VBS listening shall:

- indicate notifications to the GCC or BCC sublayer;
- respond to notification if the GCC or BCC sublayer requests the reception of a voice group or broadcast call for which no channel description has been received in the notification by the RR sublayer;
- request the RR sublayer to receive a voice group or broadcast call if the GCC or BCC sublayer requests the reception of a voice group or broadcast call for which a channel description has been received in the notification by the RR sublayer and then go to the service state RECEIVING GROUP CALL (NORMAL SERVICE).

#### 4.2.2.2 Service State, ATTEMPTING TO UPDATE

When in state MM IDLE and service state ATTEMPTING TO UPDATE the mobile station shall:

- perform location updating procedure at expiry of timer T3211 or T3213;
- perform normal location updating when the location area identification of the serving cell changes;
- if entry into this state was caused by c) or d) or f) (with cause different from "abnormal release, unspecified") or g) (with cause "retry upon entry into a new cell") of sub-clause 4.4.4.9, then location updating shall be performed when a new cell is entered;
- if entry into this state was caused by e) or f) (with cause "abnormal release, unspecified") or g) (with cause different from "retry upon entry into a new cell") of sub-clause 4.4.4.9, then location updating shall not be performed because a new cell is entered;
- perform normal location updating at expiry of timer T3212;
- not perform IMSI detach;
- support request for emergency calls;
- use other request from CM layer as triggering of normal location updating procedure (if the location updating procedure is successful, then the request for MM connection is accepted, see sub-clause 4.5.1);
- respond to paging (with IMSI).

In addition, mobile stations supporting VGCS listening or VBS listening shall:

- indicate notifications to the GCC or BCC sublayer for which a channel description has been received in the notification by the RR sublayer;
- reject requests of the GCC or BCC sublayer to respond to notifications for which no channel description has been received in the notification by the RR sublayer;
- request the RR sublayer to receive a voice group or broadcast call if the GCC or BCC sublayer requests the reception of a voice group or broadcast call for which a channel description has been received in the notification by the RR sublayer and then go to the service state RECEIVING GROUP CALL (LIMITED SERVICE).

#### 4.2.2.3 Service State, LIMITED SERVICE

When in state MM IDLE and service state LIMITED SERVICE the mobile station shall:

- not perform periodic updating;
- not perform IMSI detach;
- reject any requests from CM entities for MM connections except for emergency calls;
- perform normal location updating when a cell is entered which may provide normal service (e.g. location area not in one of the forbidden LAI lists.);
- it may respond to paging (with IMSI).

In addition, mobile stations supporting VGCS listening or VBS listening shall:

- indicate notifications to the GCC or BCC sublayer for which a channel description has been received in the notification by the RR sublayer;
- reject requests of the GCC or BCC sublayer to respond to notifications for which no channel description has been received in the notification by the RR sublayer;
- request the RR sublayer to receive a voice group or broadcast call if the GCC or BCC sublayer requests the reception of a voice group or broadcast call for which a channel description has been received in the notification by the RR sublayer and then go to the service state RECEIVING GROUP CALL (LIMITED SERVICE).

#### 4.2.2.4 Service State, NO IMSI

When in state MM IDLE and service state NO IMSI the mobile station shall (see sub-clause 3.2, 3GPP TS 03.22 and 3GPP TS 05.08):

- not start any normal location updating attempt;
- not perform periodic updating;
- not perform IMSI detach if powered down;
- reject any request from CM entities for MM connections except for emergency calls;
- not respond to paging;
- only perform default cell selection.

In addition, mobile stations supporting VGCS listening or VBS listening shall:

- not indicate notifications to the GCC or BCC layer.

#### 4.2.2.5 Service State, SEARCH FOR PLMN, NORMAL SERVICE

When in state MM IDLE and service state SEARCH FOR PLMN, NORMAL SERVICE the mobile station shall:

- if timer T3211 or T3213 expires in this state perform a location updating procedure at the latest if and when back to NORMAL SERVICE state and if the cell is not changed;
- if timer T3212 expires in this state perform a periodic location updating procedure at the latest if and when back to NORMAL SERVICE state;
- perform IMSI detach;
- support requests from the CM layer;
- listen as far as possible to paging, and respond.

In addition, mobile stations supporting VGCS listening or VBS listening shall:

- listen as far as possible to notifications and indicate notifications to the GCC or BCC layer;
- respond to notification if the GCC or BCC sublayer requests the reception of a voice group or broadcast call for which no channel description has been received in the notification by the RR sublayer;
- request the RR sublayer to receive a voice group or broadcast call if the GCC or BCC sublayer requests the reception of a voice group or broadcast call for which a channel description has been received in the notification by the RR sublayer.

#### 4.2.2.6 Service State, SEARCH FOR PLMN

When in state MM IDLE and service state SEARCH FOR PLMN the mobile station shall:

- not start any normal location updating attempt;
- not perform periodic updating;
- not perform IMSI detach if powered down;
- reject any request from CM entities for MM connections except emergency calls;
- not respond to paging.

#### 4.2.2.7 Service State, RECEIVING GROUP CALL (NORMAL SERVICE)

Only applicable for mobile stations supporting VGCS listening or VBS listening:

When in state MM IDLE and service state RECEIVING GROUP CALL (NORMAL SERVICE), the mobile station shall:

- perform normal location updating when a new location area is entered;
- perform location updating procedure at expiry of timer T3211 or T3213;
- perform periodic updating at expiration of timer T3212;
- perform IMSI detach;
- support requests from the GCC or BCC layers;
- indicate notifications or paging information to the GCC or BCC layer;
- respond to notification if the GCC or BCC sublayer requests the reception of a voice group or broadcast call for which no channel description has been received in the notification by the RR sublayer;
- request the RR sublayer to receive another voice group or broadcast call if the GCC or BCC sublayer requests the reception of a voice group or broadcast call for which a channel description has been received in the notification by the RR sublayer.

#### 4.2.2.8 Service State, RECEIVING GROUP CALL (LIMITED SERVICE)

Only applicable for mobile stations supporting VGCS listening or VBS listening.

When in state MM IDLE and service state RECEIVING GROUP CALL (LIMITED SERVICE), the mobile station shall:

- not perform periodic updating;
- not perform IMSI detach;
- reject any requests from CM entities for MM connections except for emergency calls;
- perform normal location updating when a cell is entered which may provide normal service (e.g. location area not in one of the forbidden LAI lists.);
- it may respond to paging (with IMSI);
- indicate notifications to the GCC or BCC sublayer for which a channel description has been received in the notification by the RR sublayer;
- reject requests of the GCC or BCC sublayer to respond to notifications for which no channel description has been received in the notification by the RR sublayer;
- request the RR sublayer to receive a voice group or broadcast call if the GCC or BCC sublayer requests the reception of a voice group or broadcast call for which a channel description has been received in the notification by the RR sublayer and then go to the service state RECEIVING GROUP CALL (LIMITED SERVICE).

## 4.2.3 Service state when back to state MM IDLE from another state

When returning to MM IDLE, e.g., after a location updating procedure, the mobile station selects the cell as specified in 3GPP TS 03.22. With one exception, this is a normal cell selection.

If this return to idle state is not subsequent to a location updating procedure terminated with reception of cause "Roaming not allowed in this location area" the service state depends on the result of the cell selection procedure, on the update status of the mobile station, on the location data stored in the mobile station and on the presence of the SIM:

- if no cell has been found, the state is NO CELL AVAILABLE, until a cell is found;
- if no SIM is present, or if the inserted SIM is considered invalid by the MS, the state is NO IMSI;
- if the selected cell is in the location area where the MS is registered, then the state is NORMAL SERVICE; it shall be noted that this also includes an abnormal case described in sub-clause 4.4.9;
- (Only applicable for mobile stations supporting VGCS listening or VBS listening.) if the mobile stations was in the service state RECEIVING GROUP CALL (NORMAL SERVICE) or RECEIVING GROUP CALL (LIMITED SERVICE) before the location updating procedure and the selected cell is in the location area where the mobile station is registered, then the state is RECEIVING GROUP CALL (NORMAL SERVICE);
- if the selected cell is in a location area where the mobile station is not registered but in which the MS is allowed to attempt a location update, then the state is LOCATION UPDATE NEEDED;
- if the selected cell is in a location area where the mobile station is not allowed to attempt a location update, then the state is LIMITED SERVICE;
- (Only applicable for MSs supporting VGCS listening or VBS listening.) if the MSs was in the service state RECEIVING GROUP CALL (NORMAL SERVICE) or RECEIVING GROUP CALL (LIMITED SERVICE) before the location updating procedure and the selected cell is in the location area where the MS is not allowed to attempt a location update, then the state is RECEIVING GROUP CALL (LIMITED SERVICE);
- after some abnormal cases occurring during an unsuccessful location updating procedure, as described in subclause 4.4.4.9, the state is ATTEMPTING TO UPDATE.

In case of a return from a location updating procedure to which was answered "Roaming not allowed in this location area", the service state PLMN SEARCH is entered as specified in sub-clause 4.2.1.2.

## 4.2.4 Behaviour in state GMM-DEREGISTERED

The state GMM-DEREGISTERED is entered when:

- the MS is switched on;
- the GPRS capability has been enabled in the MS;
- a GPRS detach or combined GPRS detach procedure has been performed; or
- a GMM procedure has failed (except routing area updating, see sub-clause 4.7.5).

The selection of the appropriate substate of GMM-DEREGISTERED after switching on is described in sub-clause 4.2.4.1. The specific behaviour of the MS in state GMM-DEREGISTERED is described in sub-clause 4.2.4.2. The substate chosen when the GMM-DEREGISTERED state is returned to from another state except state GMM-NULL is described in sub-clause 4.2.4.3.

It should be noted that transitions between the various substates of GMM-DEREGISTERED are caused by (e.g.):

- insertion or removal of the SIM;
- cell selection/reselection (see also 3GPP TS 03.22 [14]);
- PLMN search;
- loss/regain of coverage; or
- change of RA.

How various GMM procedures affect the GMM-DEREGISTERED substates and the GPRS update status is described in the detailed description of the GMM procedures in sub-clause 4.7.

#### 4.2.4.1 Primary substate selection

#### 4.2.4.1.1 Selection of the substate after power on or enabling the MS's GPRS capability

When the MS is switched on, the substate shall be PLMN-SEARCH in case the SIM is inserted and valid. See 3GPP TS 03.22 [14] and 05.08 [34] for further details.

When the GPRS capability in an activated MS has been enabled, the selection of the GMM-DEREGISTERED substate depends on the MM state and the GPRS update status.

The substate chosen after PLMN-SEARCH, in case of power on or after enabling of the GPRS capability is:

- if the cell is not supporting GPRS, the substate shall be NO-CELL-AVAILABLE;
- if no SIM is present the substate shall be NO-IMSI;
- if a cell supporting GPRS has been found and the PLMN or LA is not in the forbidden list, then the substate shall be NORMAL-SERVICE;
- if the selected cell supporting GPRS is in a forbidden PLMN or a forbidden LA, then the MS shall enter the substate LIMITED-SERVICE;
- if the MS is in manual network selection mode and no cell supporting GPRS of the selected PLMN has been found, the MS shall enter the substate NO-CELL-AVAILABLE.

#### 4.2.4.1.2 Other Cases

When the MM state is IDLE, the GMM substate PLMN-SEARCH shall also be entered in the following cases:

- when a SIM is inserted in substate NO-IMSI;
- when the user has asked for a PLMN selection in any substate except NO IMSI and NO CELL AVAILABLE;

- when coverage is lost in any substate except NO IMSI and NO CELL AVAILABLE;
- Roaming is denied;
- optionally, when the MS is in automatic network selection mode and the maximum allowed number of subsequently unsuccessful attach attempts controlled by the GPRS attach attempt counter (sub-clause 4.7.3) have been performed;
- optionally, when the MS is in automatic network selection mode and the maximum allowed number of subsequently unsuccessful routing area update attempts controlled by the GPRS routing area update attempt counter (sub-clause 4.7.5) have been performed.

#### 4.2.4.2 Detailed description of the MS behaviour in state GMM-DEREGISTERED

In state GMM-DEREGISTERED, the MS shall behave according to the substate. In the following sub-clauses, the behaviour is described for the non transient substates.

#### 4.2.4.2.1 Substate, NORMAL-SERVICE

The MS shall:

- perform GPRS attach.

#### 4.2.4.2.2 Substate, ATTEMPTING-TO-ATTACH

The MS shall:

- perform GPRS attach on the expiry of timers T3311 or T3302;
- perform GPRS attach when the routing area of the serving cell has changed and the location area this cell is belonging to is not in the list of forbidden LAs;
- if entry into this state was caused by b) or d) with cause "Retry upon entry into a new cell"," of sub-clause 4.7.3.1.5, GPRS attach shall be performed when a new cell is entered; and
- if entry into this state was caused by c) or d) with cause different from "Retry upon entry into a new cell" of subclause 4.7.3.1.5, GPRS attach shall not be performed when a new cell is entered.
- use requests from CM layers to trigger the combined GPRS attach procedure, if the network operates in network operation mode I. Depending on which of the timers T3311 or T3302 is running the MS shall stop the relevant timer and act as if the stopped timer has expired.

#### 4.2.4.2.3 Substate, LIMITED-SERVICE

The MS shall:

- perform GPRS attach when a cell is entered which may provide normal service (e.g. location area is not in one of the forbidden lists);

#### 4.2.4.2.4 Substate, NO-IMSI

The MS shall:

- only perform default cell selection;

#### 4.2.4.2.5 Substate, NO-CELL

The MS shall:

- perform cell selection according to 3GPP TS 03.22 [14] and shall choose an appropriate substate.

#### 4.2.4.2.6 Substate, PLMN-SEARCH

No specific action is required in this substate.

#### 4.2.4.2.7 Substate, ATTACH-NEEDED

The MS shall start a GPRS attach procedure if still needed as soon as the access class allows network contact in the selected cell.

#### 4.2.4.2.8 Substate, SUSPENDED

The MS :

- shall not send any user data; and
- shall not send any signalling information.

# 4.2.4.3 Substate when back to state GMM-DEREGISTERED from another GMM state

When returning to state GMM-DEREGISTERED, the MS shall select a cell as specified in 3GPP TS 03.22 [14].

The substate depends on the result of the cell selection procedure, the outcome of the previously performed GMM specific procedures, on the GPRS update status of the MS, on the location area data stored in the MS and on the presence of the SIM:

- if no cell has been found, the substate is NO-CELL-AVAILABLE, until a cell is found;
- if no SIM is present or if the inserted SIM is considered invalid by the MS, the substate shall be NO-IMSI;
- if the selected cell is in a location area where the MS is allowed to roam, the substate shall be NORMAL-SERVICE;
- if a GPRS attach shall be performed (e.g. network requested reattach), the substate shall be ATTEMPTING-TO-ATTACH
- if a PLMN reselection (according to 3GPP TS 03.22 [14]) is needed, the substate shall be PLMN SEARCH
- if the selected cell is in a location area where the MS is not allowed to roam, the state shall be LIMITED-SERVICE.

## 4.2.5 Behaviour in state GMM-REGISTERED

The state GMM-REGISTERED is entered when:

- a GMM context is established, i.e. the MS is IMSI attached for GPRS services only or for GPRS and non-GPRS services.

The specific behaviour of the MS in state GMM-REGISTERED is described in sub-clause 4.2.5.1. The primary substate when entering the state GMM-REGISTERED is always NORMAL-SERVICE.

It should be noted that transitions between the various substates of GMM-REGISTERED are caused by (e.g.):

- cell selection/reselection (see also 3GPP TS 03.22);
- change of RA;
- loss/regain of coverage.

How various GMM procedures affect the GMM-REGISTERED substates is described in the detailed description of the procedures in sub-clause 4.7.

#### 4.2.5.1 Detailed description of the MS behaviour in state GMM-REGISTERED

In state GMM-REGISTERED, the MS shall behave according to the substate as explained below.

#### 4.2.5.1.1 Substate, NORMAL-SERVICE

The MS shall:

- perform cell selection/reselection according to 3GPP TS 03.22 [14];
- perform normal and periodic routing area updating; and
- receive and transmit user data and signalling information.

GPRS MSs in operation modes C or A shall answer to paging requests.

GPRS MS in operation mode B may answer to paging requests.

#### 4.2.5.1.2 Substate, SUSPENDED

#### The MS:

- shall not send any user data;
- shall not send any signalling information; and
- shall not perform cell-updates.

#### 4.2.5.1.3 Substate, UPDATE-NEEDED

The MS shall:

- not send any user data;
- not send any signalling information;
- perform cell selection/reselection according to 3GPP TS 03.22 [14]; and
- chose the appropriate new substate depending on the GPRS update status as soon as the access class allows network contact in the selected cell.

#### 4.2.5.1.4 Substate, ATTEMPTING-TO-UPDATE

#### The MS:

- should not send any user data;
- shall perform routing area update on the expiry of timers T3311 or T3302;
- shall perform routing area update when the routing area of the serving cell has changed and the location area this cell is belonging to is not in the list of forbidden LAs;
- shall if entry into this state was caused by b) or d) with cause "Retry upon entry into a new cell", of sub-clause 4.7.5.1.5, perform routing area updating when a new cell is entered; and
- shall if entry into this state was caused by c) or d) with cause different from "Retry upon entry into a new cell" of sub-clause 4.7.5.1.5, not perform routing area updating when a new cell is entered;
- shall use request from CM layers as triggering the combined routing area update procedure, if the network operates in network operation mode I. Depending which of the timers T3311 or T3302 is running the MS shall stop the relevant timer and act as if the stopped timer has expired.

#### 4.2.5.1.5 Substate, NO-CELL-AVAILABLE

The MS shall perform cell selection/reselection according to 3GPP TS 03.22 [14].

#### 4.2.5.1.6 Substate, LIMITED-SERVICE

The MS shall perform cell selection/reselection according to 3GPP TS 03.22 [14];

#### 4.2.5.1.7 Substate, ATTEMPTING-TO-UPDATE-MM

The MS shall:

- perform cell selection/reselection according to 3GPP TS 03.22 [14];
- receive and transmit user data and signalling information;
- perform routing area update indicating "combined RA/LA updating with IMSI attach" on the expiry of timers T3311 or T3302;
- perform routing area update indicating "combined RA/LA updating with IMSI attach" when the routing area of the serving cell has changed and the location area this cell is belonging to is not in the list of forbidden LAs.

GPRS MSs in operation modes C or A shall answer to paging requests.

GPRS MS in operation mode B may answer to paging requests.

## 4.3 MM common procedures

As described in sub-clause 4.1.1, a MM common procedure can be initiated at any time whilst a RR connection exists between the network and the mobile station.

## 4.3.1 TMSI reallocation procedure

The purpose of the TMSI reallocation procedure is to provide identity confidentiality, i.e. to protect a user against being identified and located by an intruder (see 3GPP TS 02.09 and 03.20).

If the identity confidentiality service is applied for an IMSI, a Temporary Mobile Subscriber Identity (TMSI) is used for identification within the radio interface signalling procedures.

The structure of the TMSI is specified in 3GPP TS 03.03. The TMSI has significance only within a location area. Outside the location area it has to be combined with the Location Area Identifier (LAI) to provide for an unambiguous identity.

Usually the TMSI reallocation is performed at least at each change of a location area. (Such choices are left to the network operator).

The reallocation of a TMSI can be performed either by a unique procedure defined in this sub-clause or implicitly by a location updating procedure using the TMSI. The implicit reallocation of a TMSI is described together with that procedure.

If a TMSI provided by a mobile station is unknown in the network e.g. due to a data base failure, the network may require the mobile station to provide its International Mobile Subscriber Identity (IMSI). In this case the identification procedure (see sub-clause 4.3.3) should be used before the TMSI reallocation procedure may be initiated.

The TMSI reallocation can be initiated by the network at any time whilst a RR connection exists between the network and the mobile station.

NOTE 1: Usually the TMSI reallocation is performed in ciphered mode.

NOTE 2: Normally the TMSI reallocation will take place in conjunction with another procedure, e.g. at location updating or at call setup (see 3GPP TS 09.02).

#### 4.3.1.1 TMSI reallocation initiation by the network

The network initiates the TMSI reallocation procedure by sending a TMSI REALLOCATION COMMAND message to the mobile station and starts the timer T3250.

The TMSI REALLOCATION COMMAND message contains a new combination of TMSI and LAI allocated by the network or a LAI and the IMSI if the used TMSI shall be deleted. Usually the TMSI-REALLOCATION COMMAND message is sent to the mobile station using a RR connection in ciphered mode (see 3GPP TS 03.20).

#### 4.3.1.2 TMSI reallocation completion by the mobile station

Upon receipt of the TMSI REALLOCATION COMMAND message the mobile station stores the Location Area Identifier (LAI) in the SIM. If the received identity is the IMSI of the relevant mobile station, the mobile station deletes any TMSI. If the received identity is a TMSI the mobile station stores the TMSI in the SIM. In both cases the mobile station sends a TMSI REALLOCATION COMPLETE message to the network.

#### 4.3.1.3 TMSI reallocation completion in the network

Upon receipt of the TMSI REALLOCATION COMPLETE message, the network stops the timer T3250 and either considers the new TMSI as valid or, if an IMSI was sent to the mobile station, considers the old TMSI as deleted.

If the RR connection is no more needed, then the network will request the RR sublayer to release it (see sub-clause 3.5).

#### 4.3.1.4 Abnormal cases

Mobile station side:

 The mobile station shall consider the new TMSI and new LAI, if any, as valid and the old TMSI and old LAI as deleted as soon as a TMSI REALLOCATION COMMAND or another message containing a new TMSI (e.g. LOCATION UPDATING ACCEPT) is correctly received. Any RR connection failure at a later stage shall not have any impact on the TMSI and LAI storage.

Network side:

(a) RR connection failure:

If the RR connection is lost before the TMSI REALLOCATION COMPLETE message is received, all MM connections (if any) shall be released and both the old and the new TMSIs should be considered as occupied for a certain recovery time.

During this period the network may:

- use the IMSI for paging in the case of network originated transactions on the CM layer. Upon response from the mobile station the TMSI reallocation is restarted;
- consider the new TMSI as valid if it is used by the mobile station in mobile originated requests for RR connection;
- use the Identification procedure followed by a new TMSI reallocation if the mobile station uses the old TMSI.

Other implementations are possible.

(b) Expiry of timer T3250:

The TMSI reallocation is supervised by the timer T3250 in the network. At the first expiry of timer T3250 the network may release the RR connection. In this case, the network shall abort the reallocation procedure release all MM connections if any, and follow the rules described for RR connection failure above.

mobile station network TMSI REAL CMD <------ Start T3250 TMSI REAL COM ------> Stop T3250

#### Figure 4.1/3GPP TS 04.08: TMSI reallocation sequence

## 4.3.2 Authentication procedure

The purpose of the authentication procedure is twofold:

- First to permit the network to check whether the identity provided by the mobile station is acceptable or not (see 3GPP TS 03.20).
- Second to provide parameters enabling the mobile station to calculate a new ciphering key.

The cases where the authentication procedure should be used are defined in 3GPP TS 02.09.

The authentication procedure is always initiated and controlled by the network.

#### 4.3.2.1 Authentication request by the network

The network initiates the authentication procedure by transferring an AUTHENTICATION REQUEST message across the radio interface and starts the timer T3260. The AUTHENTICATION REQUEST message contains the parameters necessary to calculate the response parameters (see 3GPP TS 03.20). It also contains the ciphering key sequence number allocated to the key which may be computed from the given parameters.

#### 4.3.2.2 Authentication response by the mobile station

The mobile station shall be ready to respond upon an AUTHENTICATION REQUEST message at any time whilst a RR connection exists. It shall process the challenge information and send back an AUTHENTICATION RESPONSE message to the network. The new ciphering key calculated from the challenge information shall overwrite the previous one and be stored on the SIM before the AUTHENTICATION RESPONSE message is transmitted. The ciphering key stored in the SIM shall be loaded in to the ME when any valid CIPHERING MODE COMMAND is received during an RR connection (the definition of a valid CIPHERING MODE COMMAND message is given in sub-clause 3.4.7.2). The ciphering key sequence number shall be stored together with the calculated key.

#### 4.3.2.3 Authentication processing in the network

Upon receipt of the AUTHENTICATION RESPONSE message, the network stops the timer T3260 and checks the validity of the response (see 3GPP TS 03.20).

#### 4.3.2.4 Ciphering key sequence number

The security parameters for authentication and ciphering are tied together in sets, i.e. from a challenge parameter RAND both the authentication response SRES and the ciphering key can be computed given the secret key associated to the IMSI.

In order to allow start of ciphering on a RR connection without authentication, the ciphering key sequence numbers are introduced. The sequence number is managed by the network in the way that the AUTHENTICATION REQUEST message contains the sequence number allocated to the key which may be computed from the RAND parameter carried in that message.

The mobile station stores this number with the key, and indicates to the network in the first message (LOCATION UPDATING REQUEST, CM SERVICE REQUEST, PAGING RESPONSE, CM RE-ESTABLISHMENT REQUEST) which sequence number the stored key has. When the deletion of the sequence number is described this also means that the associated key shall be considered as invalid.

The network may choose to start ciphering with the stored key (under the restrictions given in 3GPP TS 02.09) if the stored sequence number and the one given from the mobile station are equal.

#### 4.3.2.5 Unsuccessful authentication

If authentication fails, i.e. if the response is not valid, the network may distinguish between the two different ways of identification used by the mobile station:

- the TMSI was used;
- the IMSI was used.

If the TMSI has been used, the network may decide to initiate the identification procedure. If the IMSI given by the mobile station then differs from the one the network had associated with the TMSI, the authentication should be restarted with the correct parameters. If the IMSI provided by the MS is the expected one (i.e. authentication has really failed), the network should proceed as described below.

If the IMSI has been used, or the network decides not to try the identification procedure, an AUTHENTICATION REJECT message should be transferred to the mobile station.

After having sent this message, all MM connections in progress (if any) are released and the network should initiate the RR connection release procedure described in sub-clause 3.5.

Upon receipt of an AUTHENTICATION REJECT message, the mobile station shall set the update status in the SIM to U3 ROAMING NOT ALLOWED, delete from the SIM the stored TMSI, LAI and ciphering key sequence number. The SIM shall be considered as invalid until switching off or the SIM is removed.

If the AUTHENTICATION REJECT message is received in the state IMSI DETACH INITIATED the mobile station shall follow sub-clause 4.3.4.3.

If the AUTHENTICATION REJECT message is received in any other state the mobile station shall abort any MM specific, MM connection establishment or call re-establishment procedure, stop any of the timers T3210 or T3230 (if running), release all MM connections (if any), start timer T3240 and enter the state WAIT FOR NETWORK COMMAND, expecting the release of the RR connection. If the RR connection is not released within a given time controlled by the timer T3240, the mobile station shall abort the RR connection. In both cases, either after a RR connection release triggered from the network side or after a RR connection abort requested by the MS-side, the MS enters state MM IDLE, substate NO IMSI.

#### 4.3.2.6 Abnormal cases

(a) RR connection failure:

Upon detection of a RR connection failure before the AUTHENTICATION RESPONSE is received, the network shall release all MM connections (if any) and abort any ongoing MM specific procedure.

(b) Expiry of timer T3260:

The authentication procedure is supervised on the network side by the timer T3260. At expiry of this timer the network may release the RR connection. In this case the network shall abort the authentication procedure and any ongoing MM specific procedure, release all MM connections if any, and initiate the RR connection release procedure described in sub-clause 3.5.

#### Figure 4.2/3GPP TS 04.08: Authentication sequence: (a) authentication; (b) authentication rejection

#### 4.3.3 Identification procedure

The identification procedure is used by the network to request a mobile station to provide specific identification parameters to the network e.g. International Mobile Subscriber Identity, International Mobile Equipment Identity (cf. 3GPP TS 03.03). For the presentation of the IMEI, the requirements of 3GPP TS 02.09 apply.

#### 4.3.3.1 Identity request by the network

The network initiates the identification procedure by transferring an IDENTITY REQUEST message to the mobile station and starts the timer T3270. The IDENTITY REQUEST message specifies the requested identification parameters in the identity type information element.

#### 4.3.3.2 Identification response by the mobile station

The mobile station shall be ready to respond to an IDENTITY REQUEST message at any time whilst a RR connection exists.

Upon receipt of the IDENTITY REQUEST message the mobile station sends back an IDENTITY RESPONSE message. The IDENTITY RESPONSE message contains the identification parameters as requested by the network.

Upon receipt of the IDENTITY RESPONSE the network shall stop timer T3270.

#### 4.3.3.3 Abnormal cases

(a) RR connection failure:

Upon detection of a RR connection failure before the IDENTITY RESPONSE is received, the network shall release all MM connections (if any) and abort any ongoing MM specific procedure.

(b) Expiry of timer T3270:

The identification procedure is supervised by the network by the timer T3270. At expiry of the timer T3270 the network may release the RR connection. In this case, the network shall abort the identification procedure and any ongoing MM specific procedure, release all MM connections if any, and initiate the RR connection release procedure as described in sub-clause 3.5.

mobile station		network
	ID REQ	
<	ID RES	Start T3270
		> Stop T3270

#### Figure 4.3/3GPP TS 04.08: Identification sequence

#### 4.3.4 IMSI detach procedure

The IMSI detach procedure may be invoked by a mobile station if the mobile station is deactivated or if the Subscriber Identity Module (see 3GPP TS 02.17) is detached from the mobile station. A flag (ATT) broadcast in the SYSTEM INFORMATION TYPE 3 message on the BCCH is used by the network to indicate whether the detach procedure is required. The value of the ATT flag to be taken into account shall be the one broadcast when the mobile station was in MM idle.

The procedure causes the mobile station to be indicated as inactive in the network.

#### 4.3.4.1 IMSI detach initiation by the mobile station

The IMSI detach procedure consists only of the IMSI DETACH INDICATION message sent from the mobile station to the network. The mobile station then starts timer T3220 and enters the MM sublayer state IMSI DETACH INITIATED.

If no RR connection exists, the MM sublayer within the mobile station will request the RR sublayer to establish a RR connection. If establishment of the RR connection is not possible because a suitable cell is not (or not yet) available then, the mobile station shall try for a period of at least 5 seconds and for not more than a period of 20 seconds to find a suitable cell. If a suitable cell is found during this time then, the mobile station shall request the RR sublayer to establish an RR connection, otherwise the IMSI detach is aborted.

If a RR connection exists, the MM sublayer will release locally any ongoing MM connections before the IMSI DETACH INDICATION message is sent.

The IMSI detach procedure may not be started if a MM specific procedure is active. If possible, the IMSI detach procedure is then delayed until the MM specific procedure is finished, else the IMSI detach is omitted.

#### 4.3.4.2 IMSI detach procedure in the network

When receiving an IMSI DETACH INDICATION message, the network may set an inactive indication for the IMSI. No response is returned to the mobile station. After reception of the IMSI DETACH INDICATION message the network shall release locally any ongoing MM connections, and start the normal RR connection release procedure (see sub-clause 3.5).

Only applicable for a network supporting VGCS: If an IMSI DETACH INDICATION message is received from the talking mobile station in a group call while the network is in service state MM CONNECTION ACTIVE (GROUP TRANSMIT MODE), the network shall release locally the ongoing MM connection and then go to the service state GROUP CALL ACTIVE.

#### 4.3.4.3 IMSI detach completion by the mobile station

Timer T3220 is stopped when the RR connection is released. The mobile station should, if possible, delay the local release of the channel to allow a normal release from the network side until T3220 timeout. If this is not possible (e.g. detach at power down) the RR sublayer on the mobile station side should be aborted.

#### 4.3.4.4 Abnormal cases

If the establishment of an RR connection is unsuccessful, or the RR connection is lost, the IMSI detach is aborted by the mobile station.

mobile station network

#### Figure 4.4/3GPP TS 04.08: IMSI detach sequence

## 4.3.5 Abort procedure

The abort procedure may be invoked by the network to abort any on-going MM connection establishment or already established MM connection. The mobile station shall treat ABORT message as compatible with current protocol state only if it is received when at least one MM connection exists or an MM connection is being established.

#### 4.3.5.1 Abort procedure initiation by the network

The abort procedure consists only of the ABORT message sent from the network to the mobile station. Before the sending of the ABORT message the network shall locally release any ongoing MM connection. After the sending the network may start the normal RR connection release procedure.

The Cause information element indicates the reason for the abortion. The following cause values may apply:

- #6: Illegal ME;
- #17: Network failure.

#### 4.3.5.2 Abort procedure in the mobile station

At the receipt of the ABORT message the mobile station shall abort any MM connection establishment or call reestablishment procedure and release all MM connections (if any). If cause value #6 is received the mobile station shall delete any TMSI, LAI and ciphering key sequence number stored in the SIM, set the update status to ROAMING NOT ALLOWED (and store it in the SIM according to sub-clause 4.1.2.2) and consider the SIM invalid until switch off or the SIM is removed. As a consequence the mobile station enters state MM IDLE, substate NO IMSI after the release of the RR connection.

The mobile station shall then wait for the network to release the RR connection - see sub-clause 4.5.3.1.

## 4.3.6 MM information procedure

The MM information message support is optional in the network.

The MM information procedure may be invoked by the network at any time during an RR connection.

#### 4.3.6.1 MM information procedure initiation by the network

The MM information procedure consists only of the MM INFORMATION message sent from the network to the mobile station. During an RR connection, the network shall send none, one, or more MM INFORMATION messages to the mobile station. If more than one MM INFORMATION message is sent, the messages need not have the same content.

NOTE: The network may be able to select particular instants where it can send the MM INFORMATION message without adding delay to, or interrupting, any CM layer transaction, e.g. immediately after the AUTHENTICATION REQUEST message.

#### 4.3.6.2 MM information procedure in the mobile station

When the mobile station (supporting the MM information message) receives an MM INFORMATION message, it shall accept the message and optionally use the contents to update appropriate information stored within the mobile station.

If the mobile station does not support the MM information message the mobile station shall ignore the contents of the message and return an MM STATUS message with cause #97.

## 4.4 MM specific procedures

A MM specific procedure can only be started if no other MM specific procedure is running or no MM connection exists between the network and the mobile station. The end of the running MM specific procedure or the release of all MM connections have to be awaited before a new MM specific procedure can be started.

During the lifetime of a MM specific procedure, if a MM connection establishment is requested by a CM entity, this request will either be rejected or be delayed until the running MM specific procedure is terminated (this depends on the implementation).

Any MM common procedure (except IMSI detach) may be initiated during a MM specific procedure.

Unless it has specific permission from the network (follow-on proceed) the mobile station side should await the release of the RR connection used for a MM specific procedure before a new MM specific procedure or MM connection establishment is started.

NOTE: The network side may use the same RR connection for MM connection management.

## 4.4.1 Location updating procedure

The location updating procedure is a general procedure which is used for the following purposes:

- normal location updating (described in this sub-clause);
- periodic updating (see sub-clause 4.4.2);
- IMSI attach (see sub-clause 4.4.3).

The normal location updating procedure is used to update the registration of the actual Location Area of a mobile station in the network. The location updating type information element in the LOCATION UPDATING REQUEST message shall indicate normal location updating. The conditions under which the normal location updating procedure is used by a mobile station in the MM IDLE state are defined for each service state in sub-clause 4.2.2.

Only applicable for mobile stations supporting VGCS listening or VBS listening: A mobile station in RR group receive mode is in the MM IDLE state, substate RECEIVING GROUP CALL (NORMAL SERVICE) or RECEIVING GROUP CALL (LIMITED SERVICE). To perform a location updating, the MS in RR group receive mode shall leave the group receive mode, establish an independent dedicated RR connection to perform the location updating as described above and return to the RR group receive mode afterwards.

The normal location updating procedure shall also be started if the network indicates that the mobile station is unknown in the VLR as a response to MM connection establishment request.

To limit the number of location updating attempts made, where location updating is unsuccessful, an attempt counter is used. The attempt counter is reset when a mobile station is switched on or a SIM card is inserted.

Upon successful location updating the mobile station sets the update status to UPDATED in the SIM, and stores the received Location Area Identification in the SIM. The attempt counter shall be reset.

The detailed handling of the attempt counter is described in sub-clauses 4.4.4.6 to 4.4.4.9.

The Mobile Equipment shall contain a list of "forbidden location areas for roaming", as well as a list of "forbidden location areas for regional provision of service". These lists shall be erased when the MS is switched off or when the SIM is removed, and periodically (with period in the range 12 to 24 hours). The location area identification received on the BCCH that triggered the location updating request shall be added to the suitable list whenever a location update reject message is received with the cause "Roaming not allowed in this location area" or with the cause "Location Area not allowed". The lists shall accommodate each 10 or more location area identifications. When the list is full and a new entry has to be inserted, the oldest entry shall be deleted.

The cell selection processes in the different states are described in 3GPP TS 03.22 and 3GPP TS 05.08.

The location updating procedure is always initiated by the mobile station.

## 4.4.2 Periodic updating

Periodic updating may be used to notify periodically the availability of the mobile station to the network. Periodic updating is performed by using the location updating procedure. The location updating type information element in the LOCATION UPDATING REQUEST message shall indicate periodic updating.

The procedure is controlled by the timer T3212 in the mobile station. If the timer is not already started, the timer is started each time the mobile station enters the MM IDLE substate NORMAL SERVICE or ATTEMPTing TO UPDATE. When the MS leaves the MM Idle State the timer T3212 shall continue running until explicitly stopped.

The timer is stopped (shall be set to its initial value for the next start) when:

- a LOCATION UPDATING ACCEPT or LOCATION UPDATING REJECT message is received;
- an AUTHENTICATION REJECT message is received;
- the first MM message is received, or ciphering mode setting is completed in the case of MM connection establishment, except when the most recent service state is LIMITED SERVICE;
- the mobile station has responded to paging and thereafter has received the first correct layer 3 message except RR message;
- the mobile station is deactivated (i.e. equipment powered down or SIM removed).

When the timer T3212 expires, the location updating procedure is started and the timer shall be set to its initial value for the next start. If the mobile station is in other state than MM Idle when the timer expires the location updating procedure is delayed until the MM Idle State is entered.

The conditions under which the periodic location updating procedure is used by a mobile station in the MM IDLE state are defined for each service state in sub-clause 4.2.2.

If the mobile station is in service state NO CELL AVAILABLE, LIMITED SERVICE, PLMN SEARCH or PLMN SEARCH-NORMAL SERVICE when the timer expires the location updating procedure is delayed until this service state is left. The (periodic) location updating procedure is not started if the BCCH information at the time the procedure is triggered indicates that periodic location shall not be used. The timeout value is broadcasted in the SYSTEM INFORMATION TYPE 3 message on the BCCH, in the Control channel description IE, see sub-clause 10.5.2.11.

The T3212 timeout value shall not be changed in the NO CELL AVAILABLE, LIMITED SERVICE, PLMN SEARCH and PLMN SEARCH-NORMAL SERVICE states.

When a change of the T3212 timeout value has to be taken into account and the timer is running (at change of the serving cell or, change of the broadcast value of T3212), the MS shall behave as follows:

- Let t1 be the new T3212 timeout value and let t be the current timer value at the moment of the change to the new T3212 timeout value; then the timer shall be restarted with the value t modulo t1.

When the mobile station is activated, or when a change of the T3212 timeout value has to be taken into account and the timer is not running, the mobile station shall behave as follows:

- Let t1 be the new T3212 timeout value, the new timer shall be started at a value randomly, uniformly drawn between 0 and t1.

## 4.4.3 IMSI attach procedure

The IMSI attach procedure is the complement of the IMSI detach procedure (see sub-clause 4.3.4). It is used to indicate the IMSI as active in the network. A flag (ATT) is broadcast in the SYSTEM INFORMATION TYPE 3 message. It indicates whether the attach and detach procedures are required to be used or not.

The IMSI attach procedure is invoked if the detach/attach procedures are required by the network and an IMSI is activated in a mobile station (i.e. activation of a mobile station with plug-in SIM, insertion of a card in a card-operated mobile station etc.) within coverage area from the network or a mobile station with an IMSI activated outside the coverage area enters the coverage area. The IMSI attach procedure is used only if the update status is UPDATED and if the stored Location Area Identification is the same as the one which is actually broadcasted on the BCCH of the current serving cell. Otherwise a normal location updating procedure (see sub-clause 4.4.1) is invoked independently of the ATT flag indication.

IMSI attach is performed by using the location updating procedure. The location updating type information element in the LOCATION UPDATING REQUEST message shall in this case indicate IMSI attach.

## 4.4.4 Generic Location Updating procedure

#### 4.4.4.1 Location updating initiation by the mobile station

Any timer used for triggering the location updating procedure (e.g. T3211, T3212) is stopped if running.

As no RR connection exists at the time when the location updating procedure has to be started, the MM sublayer within the mobile station will request the RR sublayer to establish a RR connection and enter state WAIT FOR RR CONNECTION (LOCATION UPDATE). The procedure for establishing an RR connection is described in sub-clause 3.3.

The mobile station initiates the location updating procedure by sending a LOCATION UPDATING REQUEST message to the network, starts the timer T3210 and enters state LOCATION UPDATING INITIATED. The location updating type information element shall indicate what kind of updating is requested.

#### 4.4.4.1a Network Request for Additional mobile station Capability Information

The network may initiate the classmark interrogation procedure, for example, to obtain further information on the mobile station's encryption capabilities.

#### 4.4.4.2 Identification request from the network

The network may initiate the identification procedure, e.g. if the network is unable to get the IMSI based on the TMSI and LAI used as identification by the mobile station (see sub-clause 4.3.3).

#### 4.4.4.3 Authentication by the network

The authentication procedure (see sub-clause 4.3.2) may be initiated by the network upon receipt of the LOCATION UPDATING REQUEST message from the mobile station. (See the cases defined in 3GPP TS 02.09).

#### 4.4.4.4 Ciphering mode setting by the network

The ciphering mode setting procedure (see sub-clause 3.4.7) may be initiated by the network, e.g., if a new TMSI has to be allocated.

#### 4.4.4.5 Attempt Counter

To limit the number of location updating attempts made, where location updating is unsuccessful, an attempt counter is used. It counts the number of consecutive unsuccessful location update attempts.

The attempt counter is incremented when a location update procedure fails. The specific situations is specified in subclause 4.4.4.9.

The attempt counter is reset when:

- the mobile station is powered on;
- a SIM is inserted;
- location update is successfully completed;
- location update completed with cause #11, #12 or #13 (see sub-clause 4.4.4.7).

and in case of service state ATTEMPTING to UPDATE:

- a new location area is entered;
- expiry of timer T3212;
- location update is triggered by CM sublayer requests.

The attempt counter is used when deciding whether to re-attempt a location update after timeout of timer T3211.

#### 4.4.4.6 Location updating accepted by the network

If the location updating is accepted by the network a LOCATION UPDATING ACCEPT message is transferred to the mobile station.

In case the identity confidentiality service is active (see sub-clause 4.3.1 and 4.4.4.4), the TMSI reallocation may be part of the location updating procedure. The TMSI allocated is then contained in the LOCATION UPDATING ACCEPT message together with the location area identifier LAI. The network shall in this case start the supervision timer T3250 as described in sub-clause 4.3.1.

If the network wishes to prolong the RR connection to allow the mobile station to initiate MM connection establishment (for example if the mobile station has indicated in the LOCATION UPDATING REQUEST that it has a follow-on request pending) the network shall send "follow on proceed" in the LOCATION UPDATING ACCEPT and start timer T3255.

The mobile station receiving a LOCATION UPDATING ACCEPT message shall store the received location area identification LAI, stop timer T3210, reset the attempt counter and set the update status in the SIM to UPDATED. If the message contains an IMSI, the mobile station is not allocated any TMSI, and shall delete any TMSI in the SIM accordingly. If the message contains a TMSI, the mobile station is allocated this TMSI, and shall store this TMSI in the SIM and a TMSI REALLOCATION COMPLETE shall be returned to the network. If neither IMSI nor TMSI is received in the LOCATION UPDATING ACCEPT message, the old TMSI if any available shall be kept.

If the LAI or PLMN identity contained in the LOCATION UPDATING ACCEPT message is a member of any of the "forbidden lists" then any such entries shall be deleted.

After that, the mobile station shall act according to the presence of the "Follow-on proceed" information element in the LOCATION UPDATING ACCEPT; if this element is present and the mobile station has a CM application request pending, it shall send a CM SERVICE REQUEST to the network and proceed as in sub-clause 4.5.1.1. Otherwise, it shall start timer T3240 and enter state WAIT FOR NETWORK COMMAND.

Furthermore, the network may grant authorisation for the mobile station to use GSM-Cordless Telephony System (CTS) in the Location Area and its immediate neighbourhood. The mobile should memorise this permission in non-volatile memory. If the "CTS permission" IE is not present in the message, the mobile is not authorised to use GSM-CTS, and shall accordingly delete any memorised permission.

NOTE: the interaction between CTS and GPRS procedures are not yet defined.

#### 4.4.4.7 Location updating not accepted by the network

If the location updating cannot be accepted the network sends a LOCATION UPDATING REJECT message to the mobile station. The mobile station receiving a LOCATION UPDATING REJECT message shall stop the timer T3210, store the reject cause, start T3240, enter state LOCATION UPDATING REJECTED await the release of the RR connection triggered by the network. Upon the release of the RR connection the mobile station shall take the following actions depending on the stored reject cause:

- # 2: IMSI unknown in HLR;
- # 3: Illegal MS; or
- # 6: Illegal ME.

The mobile station shall set the update status to ROAMING NOT ALLOWED (and store it in the SIM according to sub-clause 4.1.2.2), and delete any TMSI, stored LAI and ciphering key sequence number and shall consider the SIM as invalid until switch-off or the SIM is removed.

- # 11: PLMN not allowed;
- #12: Location Area not allowed; or
- #13: Roaming not allowed in this location area.

The mobile station shall delete any LAI, TMSI and ciphering key sequence number stored in the SIM, reset the attempt counter, set the update status to ROAMING NOT ALLOWED (and store it in the SIM according to subclause 4.1.2.2). The mobile station shall store the LAI or the PLMN identity in the suitable forbidden list, i.e. in the "forbidden PLMN list" for cause #11, in the list of "forbidden location areas for regional provision of service" for cause #12, and in the list of "forbidden location areas for roaming" for cause #13. In addition, the MS will memorize if cause #13 was received, so to perform a PLMN selection instead of a cell selection when back to the MM IDLE state.

Other values are considered as abnormal cases and the specification of the mobile station behaviour in those cases is given in sub-clause 4.4.4.9.

#### 4.4.4.8 Release of RR connection after location updating

When the Location updating procedure is finished (see sub-clauses 4.4.4.6 and 4.4.4.7) the mobile station shall (except in the case where the mobile has a follow-on CM application request pending and has received the follow-on proceed indication, see 4.4.4.6) set timer T3240 and enter the state WAIT FOR NETWORK COMMAND, expecting the release of the RR connection. The network may decide to keep the RR connection for network initiated establishment of a MM connection, or to allow for mobile initiated MM connection establishment.

Any release of the RR connection shall be initiated by the network according to sub-clause 3.5. If the RR connection is not released within a given time controlled by the timer T3240, the mobile station shall abort the RR connection. In both cases, either after a RR connection release triggered from the network side or after a RR connection abort requested by the MS-side, the MS shall return to state MM IDLE.

At transition to state MM IDLE, substates NORMAL SERVICE or RECEIVING GROUP CALL (NORMAL SERVICE) or ATTEMPTING TO UPDATE either timer T3212 or timer T3211 is started as described in subclause 4.4.4.9.

#### 4.4.4.9 Abnormal cases on the mobile station side

The different abnormal cases that can be identified are the following:

a) Access barred because of access class control

The location updating procedure is not started. The mobile station stays in the current serving cell and applies normal cell reselection process. The procedure is started as soon as possible and if still necessary (when the barred state is ended or because of a cell change)

b) The answer to random access is an IMMEDIATE ASSIGNMENT REJECT message

The location updating is not started. The mobile station stays in the chosen cell and applies normal cell selection process. The waiting timer T3122 is reset when a cell change occurs. The procedure is started as soon as possible after T3122 timeout if still necessary.

c) Random access failure

Timer T3213 is started. When it expires the procedure is attempted again if still necessary.

NOTE: As specified in 3GPP TS 05.08, a cell reselection then takes place, with return to the cell inhibited for 5 seconds if there is at least one other suitable cell. Typically the selection process will take the mobile station back to the cell where the random access failed after 5 seconds.

If at the expiry of timer T3213 a new cell has not been selected due to the lack of valid information (see 3GPP TS 05.08), the mobile station may as an option delay the repeated attempt for up to 8 seconds to allow cell re-selection to take place. In this case the procedure is attempted as soon as a new cell has been selected or the mobile station has concluded that no other cell can be selected.

If random access failure occurs for two successive random access attempts for location updating the mobile station proceeds as specified below.

d) RR connection failure

The procedure is aborted and the mobile station proceeds as specified below.

e) T3210 timeout

The procedure is aborted, the RR connection is aborted and the MS proceeds as specified below.

f) RR release before the normal end of procedure

The procedure is aborted and the mobile station proceeds as specified below.

g) Location updating reject, other causes than those treated in sub-clause 4.4.4.7

The MS waits for release of the RR connection as specified in sub-clause 4.4.4.8, and then proceeds as specified below.

In cases d) to g) above and for repeated failures as defined in c) above the mobile station proceeds as follows. Timer T3210 is stopped if still running. The RR Connection is aborted in case of timer T3210 timeout. The attempt counter is incremented. The next actions depend on the Location Area Identities (stored and received from the BCCH of the current serving cell) and the value of the attempt counter.

- the update status is UPDATED, and the stored LAI is equal to the one received on the BCCH from the current serving cell and the attempt counter is smaller than 4:

The mobile station shall keep the update status to UPDATED, the MM IDLE sub-state after the RR connection release is NORMAL SERVICE. The mobile station shall memorize the location updating type used in the location updating procedure. It shall start timer T3211 when the RR connection is released. When timer T3211 expires the location updating procedure is triggered again with the memorized location updating type;

 either the update status is different from UPDATED, or the stored LAI is different from the one received on the BCCH from the current serving cell, or the attempt counter is greater or equal to 4: The mobile station shall delete any LAI, TMSI, ciphering key sequence number stored in the SIM, set the update status to NOT UPDATED and enter the MM IDLE sub-state ATTEMPTING TO UPDATE when the RR connection is released (See sub-clause 4.2.2.2 for the subsequent actions). If the attempt counter is smaller than 4, the mobile station shall memorize that timer T3211 is to be started when the RR connection is released, otherwise it shall memorize that timer T3212 is to be started when the RR connection is released.

#### 4.4.4.10 Abnormal cases on the network side

a) RR connection failure

If a RR connection failure occurs during a common procedure integrated with the location updating procedure, the behaviour of the network should be according to the description of that common procedure.

If a RR connection failure occurs when a common procedure does not exist, the location updating procedure towards the mobile station should be aborted.

b) protocol error

If the LOCATION UPDATING REQUEST message is received with a protocol error, the network should, if possible, return a LOCATION UPDATING REJECT message with one of the following Reject causes:

- #96: Mandatory information element error
- #99: Information element non-existent or not implemented
- #100: Conditional IE error
- #111: Protocol error, unspecified

Having sent the response, the network should start the channel release procedure (see sub-clause 3.5).

mobile s		network
Start T3210	LOC U	JPD REQ
	LOC U	JPD ACC
Stop T3210	<>	JPD REJ
II	<	

#### Figure 4.5/3GPP TS 04.08: Location updating sequence

## 4.5 Connection management sublayer service provision

The concept of MM connection is introduced in this sub-clause. This concept is mainly a descriptive tool: The establishment of an MM connection by the network can be local (i.e. it is achieved by the transmission of the first CM layer message and without the transmission of any MM layer messages) or can be achieved by the transmission of a CM SERVICE PROMPT message (eg. in the case of certain ring back services). The release of an MM connection by the network or by the mobile station is always local, i.e. these purposes can be achieved without sending any MM messages over the radio interface. (On the contrary, establishment of an MM connection by the mobile station requires the sending of MM messages over the radio interface. An exception is VGCS, where an MM connection will be established as result of an uplink access procedure (see sub-clause 3.7.2.1.1).)

The Mobility Management (MM) sublayer is providing connection management services to the different entities of the upper Connection management (CM) sublayer (see 3GPP TS 04.07). It offers to a CM entity the possibility to use an MM connection for the exchange of information with its peer entity. An MM connection is established and released on request from a CM entity. Different CM entities communicate with their peer entity using different MM connections. Several MM connections may be active at the same time.

An MM connection requires an RR connection. All simultaneous MM connections for a given mobile station use the same RR connection.

In the following sub-clauses, the procedures for establishing, re-establishing, maintaining, and releasing an MM connection are described, usually separately for the mobile station and the network side.

## 4.5.1 MM connection establishment

#### 4.5.1.1 MM connection establishment initiated by the mobile station

Upon request of a CM entity to establish an MM connection the MM sublayer first decides whether to accept, delay, or reject this request:

- An MM connection establishment may only be initiated by the mobile station when the following conditions are fulfilled:
  - Its update status is UPDATED.
  - The MM sublayer is in one of the states MM IDLE, RR CONNECTION RELEASE NOT ALLOWED or MM connection active but not in MM connection active (Group call).

An exception from this general rule exists for emergency calls (see sub-clause 4.5.1.5). A further exception is defined in the following sub-clause.

- If an MM specific procedure is running at the time the request from the CM sublayer is received, and the LOCATION UPDATING REQUEST message has been sent, the request will either be rejected or delayed, depending on implementation, until the MM specific procedure is finished and, provided that the network has not sent a "follow-on proceed" indication, the RR connection is released. If the LOCATION UPDATING REQUEST message has not been sent, the mobile station may include a "follow-on request" indicator in the message. The mobile station shall then delay the request until the MM specific procedure is completed, when it may be given the opportunity by the network to use the RR connection: see sub-clause 4.4.4.6.

In order to establish an MM connection, the mobile station proceeds as follows:

- a) If no RR connection exists, the MM sublayer requests the RR sublayer to establish an RR connection and enters MM sublayer state WAIT FOR RR CONNECTION (MM CONNECTION). This request contains an establishment cause and a CM SERVICE REQUEST message. When the establishment of an RR connection is indicated by the RR sublayer (this indication implies that the CM SERVICE REQUEST message has been successfully transferred via the radio interface, see sub-clause 2.2), the MM sublayer of the mobile station starts timer T3230, gives an indication to the CM entity that requested the MM connection establishment, and enters MM sublayer state WAIT FOR OUTGOING MM CONNECTION.
- b) If an RR connection is available, the MM sublayer of the mobile station sends a CM SERVICE REQUEST message to the network, starts timer T3230, stops and resets timer T3241, gives an indication to the CM entity that requested the MM connection establishment, and enters:
  - MM sublayer state WAIT FOR OUTGOING MM CONNECTION, if no MM connection is active;
  - MM sublayer state WAIT FOR ADDITIONAL OUTGOING MM CONNECTION, if at least one MM connection is active;
  - If an RR connection exists but the mobile station is in the state WAIT FOR NETWORK COMMAND then any requests from the CM layer that are received will either be rejected or delayed until this state is left.
- c) Only applicable for mobile stations supporting VGCS talking:
  - If a mobile station which is in the MM sublayer state MM IDLE, service state RECEIVING GROUP CALL (NORMAL SERVICE), receives a request from the GCC sublayer to perform an uplink access, the MM sublayer requests the RR sublayer to perform an uplink access procedure and enters MM sublayer state WAIT FOR RR CONNECTION (GROUP TRANSMIT MODE).
  - When a successful uplink access is indicated by the RR sublayer, the MM sublayer of the mobile station gives an indication to the GCC sublayer and enters MM sublayer state MM CONNECTION ACTIVE (GROUP TRANSMIT MODE).
  - When an uplink access reject is indicated by the RR sublayer, the MM sublayer of the mobile station gives an indication to the GCC sublayer and enters the MM sublayer state MM IDLE, service state RECEIVING GROUP CALL (NORMAL SERVICE).

 In the network, if an uplink access procedure is performed, the RR sublayer in the network provides an indication to the MM sublayer together with the mobile subscriber identity received in the TALKER INDICATION message. The network shall then enter the MM sublayer state MM CONNECTION ACTIVE (GROUP TRANSMIT MODE).

The CM SERVICE REQUEST message contains the

- mobile identity according to sub-clause 10.5.1.4;
- mobile station classmark 2;
- ciphering key sequence number; and
- CM service type identifying the requested type of transaction (e.g. mobile originating call establishment, emergency call establishment, short message service, supplementary service activation), location services)

A MS supporting eMLPP may optionally include a priority level in the CM SERVICE REQUEST message.

A collision may occur when a CM layer message is received by the mobile station in MM sublayer state WAIT FOR OUTGOING MM CONNECTION or in WAIT FOR ADDITIONAL OUTGOING MM CONNECTION. In this case the MM sublayer in the MS shall establish a new MM connection for the incoming CM message as specified in subclause 4.5.1.3.

Upon receiving a CM SERVICE REQUEST message, the network shall analyse its content. The type of semantic analysis may depend on other on going MM connection(s). Depending on the type of request and the current status of the RR connection, the network may start any of the MM common procedures and RR procedures.

The network may initiate the classmark interrogation procedure, for example, to obtain further information on the mobile station's encryption capabilities.

The identification procedure (see sub-clause 4.3.3) may be invoked for instance if a TMSI provided by the mobile station is not recognized.

The network may invoke the authentication procedure (see sub-clause 4.3.2) depending on the CM service type.

The network decides also if the ciphering mode setting procedure shall be invoked (see sub-clause 3.4.7).

NOTE: If the CM\_SERVICE\_REQUEST message contains a priority level the network may use this to perform queuing and pre-emption as defined in 3GPP TS 03.67.

An indication from the RR sublayer that the ciphering mode setting procedure is completed, or reception of a CM SERVICE ACCEPT message, shall be treated as a service acceptance indication by the mobile station. The MM connection establishment is completed, timer T3230 shall be stopped, the CM entity that requested the MM connection shall be informed, and MM sublayer state MM CONNECTION ACTIVE is entered. The MM connection is considered to be active.

If the service request cannot be accepted, the network returns a CM SERVICE REJECT message to the mobile station.

The reject cause information element (see sub-clause 10.5.3.6 and Annex G) indicates the reason for rejection. The following cause values may apply:

- #4: IMSI unknown in VLR.
- #6: Illegal ME.
- #17: Network failure.
- #22: Congestion.
- #32: Service option not supported.
- #33: Requested service option not subscribed.
- #34: Service option temporarily out of order.

If no other MM connection is active, the network may start the RR connection release (see sub-clause 3.5) when the CM SERVICE REJECT message is sent.

If a CM SERVICE REJECT message is received by the mobile station, timer T3230 shall be stopped, the requesting CM sublayer entity informed. Then the mobile station shall proceed as follows:

- If the cause value is not #4 or #6 the MM sublayer returns to the previous state (the state where the request was received). Other MM connections shall not be affected by the CM SERVICE REJECT message.
- If cause value #4 is received, the mobile station aborts any MM connection, deletes any TMSI, LAI and ciphering key sequence number in the SIM, changes the update status to NOT UPDATED (and stores it in the SIM according to sub-clause 4.1.2.2), and enters the MM sublayer state WAIT FOR NETWORK COMMAND. If subsequently the RR connection is released or aborted, this will force the mobile station to initiate a normal location updating). Whether the CM request shall be memorized during the location updating procedure, is a choice of implementation.
- If cause value #6 is received, the mobile station aborts any MM connection, deletes any TMSI, LAI and ciphering key sequence number in the SIM, changes the update status to ROAMING NOT ALLOWED (and stores it in the SIM according to sub-clause 4.1.2.2), and enters the MM sublayer state WAIT FOR NETWORK COMMAND. The mobile station shall consider the SIM as invalid until switch-off or the SIM is removed.

#### 4.5.1.2 Abnormal cases

Mobile station side:

a) RR connection failure or IMSI deactivation

If an RR connection failure occurs or the IMSI is deactivated during the establishment of an MM connection, the MM connection establishment is aborted, timers T3230 is stopped, and an indication is given to the CM entity that requested the MM connection establishment. This shall be treated as a rejection for establishment of the new MM connection, and the MM sublayer shall release all active MM connections.

b) T3230 expiry

If T3230 expires (i.e. no response is given but a RR connection is available) the MM connection establishment is aborted and the requesting CM sublayer is informed. If no other MM connection exists then the mobile station shall proceed as described in sub-clause 4.5.3.1 for release of the RR connection. Otherwise the mobile station shall return to the MM sublayer state where the request of an MM connection was received, i.e. to MM sublayer state MM connection active. Other ongoing MM connections (if any) shall not be affected.

c) Reject cause values #95, #96, #97, #99, #100, #111 received

The same actions as on timer expiry shall be taken by the mobile station.

d) Random access failure or RR connection establishment failure

If the mobile station detects a random access failure or RR connection establishment failure during the establishment of an MM connection, it aborts the MM connection establishment and gives an indication to the CM entity that requested the MM connection establishment.

NOTE: Further actions of the mobile station depend on the RR procedures and MM specific procedures during which the abnormal situation has occurred and are described together with those procedures.

#### Network side:

a) RR connection failure

The actions to be taken upon RR connection failure within a MM common procedure are described together with that procedure. A RR connection failure occurring outside such MM common procedures, shall trigger the release of all active MM connections if any.

b) Invalid message or message content

Upon reception of an invalid initial message or a CM SERVICE REQUEST message with invalid content, a CM SERVICE REJECT message shall be returned with one of the following appropriate Reject cause indications:

# 95: Semantically incorrect message

- # 96: Mandatory information element error
- # 97: Message type non-existent or not implemented
- # 99: Information element non-existent or not implemented
- # 100: Conditional IE error
- # 111: Protocol error, unspecified

When the CM SERVICE REJECT message has been sent, the network may start RR connection release if no other MM connections exist or if the abnormal condition also has influence on the other MM connections.

#### 4.5.1.3 MM connection establishment initiated by the network

#### 4.5.1.3.1 Mobile Terminating CM Activity

When a CM sublayer entity in the network requests the MM sublayer to establish a MM connection, the MM sublayer will request the establishment of an RR connection to the RR sublayer if no RR connection to the desired mobile station exists. The MM sublayer is informed when the paging procedure is finished (see sub-clause 3.3.2) and the mobile station shall enter the MM state WAIT FOR NETWORK COMMAND.

When an RR connection is established (or if it already exists at the time the request is received), the MM sublayer may initiate any of the MM common procedures (except IMSI detach); it may request the RR sublayer to perform the RR classmark interrogation procedure, and/or the ciphering mode setting procedure.

When all MM and RR procedures are successfully completed which the network considers necessary, the MM sublayer will inform the requesting mobile terminating CM sublayer entity on the success of the MM connection establishment.

If an RR connection already exists and no MM specific procedure is running, the network may also establish a new mobile terminating MM connection by sending a CM message with a new PD/TI combination.

If the MS receives the first CM message in the MM states WAIT FOR NETWORK COMMAND or RR CONNECTION RELEASE NOT ALLOWED, the MS shall stop and reset the timers T3240 and T3241 and shall enter the MM state MM CONNECTION ACTIVE.

If the establishment of an RR connection is unsuccessful, or if any of the MM common procedures or the ciphering mode setting fail, this is indicated to the CM layer with an appropriate error cause.

If an RR connection used for a MM specific procedure exists to the mobile station, the CM request may be rejected or delayed depending on implementation. When the MM specific procedure has been completed, the network may use the same RR connection for the delayed CM request.

Only applicable in case of VGCS talking:

- In the MM CONNECTION ACTIVE (GROUP TRANSMIT MODE) the mobile station is in RR Group transmit mode. There shall be only one MM connection active.
- When in MM CONNECTION ACTIVE (GROUP TRANSMIT MODE) state, the MM sublayer in the network shall reject the request for the establishment of another MM connection by any CM layer.
- If the RR sublayer in the network indicates a request to perform a transfer of the mobile station from RR connected mode to RR Group transmit mode which will result in a transition from MM CONNECTION ACTIVE state to MM CONNECTION ACTIVE (GROUP TRANSMIT MODE) state in the MM sublayer, the MM sublayer shall not allow the transition if more than one MM connection is active with the mobile station.

#### 4.5.1.3.2 Mobile Originating CM Activity \$(CCBS)\$

When a CM sublayer entity in the network requests the MM sublayer to establish a MM connection, the MM sublayer will request the establishment of an RR connection to the RR sublayer if no RR connection to the desired mobile station exists. The MM sublayer is informed when the paging procedure is finished (see sub-clause 3.3.2) and the mobile station shall enter the MM state WAIT FOR NETWORK COMMAND.

When an RR connection is established (or if it already exists at the time the request is received), the MM sublayer may initiate any of the MM common procedures (except IMSI detach), it may request the RR sublayer to perform the RR classmark interrogation procedure and/or the ciphering mode setting procedure.

The network should use the information contained in *the Mobile Station Classmark Type 2* IE on the mobile station's support for "Network Initiated MO CM Connection Request" to determine whether to:

- not start this procedure (eg if an RR connection already exists); or
- to continue this procedure; or
- to release the newly established RR connection.

In the case of a "Network Initiated MO CM Connection Request" the network shall use the established RR connection to send a CM SERVICE PROMPT message to the mobile station.

If the mobile station supports "Network Initiated MO CM Connection Request", the MM sublayer of the MS gives an indication to the CM entity identified by the CM SERVICE PROMPT message and enters the MM sublayer state PROCESS CM SERVICE PROMPT. In the state PROCESS CM SERVICE PROMPT the MM sublayer waits for either the rejection or confirmation of the recall by the identified CM entity. Any other requests from the CM entities shall either be rejected or delayed until this state is left.

When the identified CM entity informs the MM sublayer, that it has send the first CM message in order to start the CM recall procedure the MM sublayer enters the state MM CONNECTION ACTIVE.

If the identified CM entity indicates that it will not perform the CM recall procedure and all MM connections are released by their CM entities the MS shall proceed according to sub-clause 4.5.3.1.

If the CM SERVICE PROMPT message is received by the MS in MM sublayer states WAIT FOR OUTGOING MM CONNECTION or in WAIT FOR ADDITIONAL OUTGOING MM CONNECTION then the mobile station shall send an MM STATUS message with cause " Message not compatible with protocol state".

A mobile that does not support "Network Initiated MO CM Connection Request" shall return an MM STATUS message with cause #97 "message type non-existent or not implemented" to the network.

If the mobile station supports "Network Initiated MO CM Connection Request" but the identified CM entity in the mobile station does not provide the associated support, then the mobile station shall send an MM STATUS message with cause "Service option not supported". In the case of a temporary CM problem (eg lack of transaction identifiers) then the mobile station shall send an MM STATUS message with cause "Service option temporarily out of order".

If an RR connection already exists and no MM specific procedure is running, the network may use it to send the CM SERVICE PROMPT message.

If the establishment of an RR connection is unsuccessful, or if any of the MM common procedures or the ciphering mode setting fail, this is indicated to the CM layer in the network with an appropriate error cause.

If an RR connection used for a MM specific procedure exists to the mobile station, the "Network Initiated MO CM Connection Request" may be rejected or delayed depending on implementation. When the MM specific procedure has been completed, the network may use the same RR connection for the delayed "Network Initiated MO CM Connection Request".

#### 4.5.1.4 Abnormal cases

The behaviour upon abnormal events is described together with the relevant RR procedure or MM common procedure.

#### 4.5.1.5 MM connection establishment for emergency calls

A MM connection for an emergency call may be established in all states of the mobility management sublayer which allow MM connection establishment for a normal originating call. In addition, establishment may be attempted in all service states where a cell is selected (see sub-clause 4.2.2) but not in the MM CONNECTION ACTIVE state (GROUP TRANSMIT MODE) state. However, as a network dependent option, a MM connection establishment for emergency call may be rejected in some of the states.

When a user requests an emergency call establishment the mobile station will send a CM SERVICE REQUEST message to the network with a CM service type information element indicating emergency call establishment. If the network does not accept the emergency call request, e.g., because IMEI was used as identification and this capability is not supported by the network, the network will reject the request by returning a CM SERVICE REJECT message to the mobile station.

The reject cause information element indicates the reason for rejection. The following cause values may apply:

- #3 "Illegal MS";
- #4 "IMSI unknown in VLR";
- #5 "IMEI not accepted";
- #6 "Illegal ME";
- #17 "Network failure";
- #22 "Congestion";
- #32 "Service option not supported";
- #34 "Service option temporarily out of order".

With the above defined exceptions, the procedures described for MM connection establishment in sub-clause 4.5.1.1 and sub-clause 4.5.1.2 shall be followed.

- NOTE: Normally, the mobile station will be identified by an IMSI or a TMSI. However, if none of these identifiers is available in the mobile station, then the mobile station shall use the IMEI for identification purposes. The network may in that case reject the request by returning a CM SERVICE REJECT message with reject cause:
- #5 "IMEI not accepted".

#### 4.5.1.6 Call re-establishment

The re-establishment procedure allows a MS to resume a connection in progress after a radio link failure, possibly in a new cell and possibly in a new location area. The conditions in which to attempt call re-establishment or not depend on the call control state, see sub-clause 5.5.4 and, whether or not a cell allowing call re-establishment has been found (as described in 3GPP TS 05.08). MM connections are identified by their protocol discriminators and transaction identifiers: these shall not be changed during call re-establishment.

The re-establishment takes place when a lower layer failure occurs and at least one MM connection is active (i.e. the mobile station's MM sublayer is either in state 6 "MM CONNECTION ACTIVE" or state 20 "WAIT FOR ADDITIONAL OUTGOING MM CONNECTION").

NOTE: During a re-establishment attempt the mobile station does not return to the MM IDLE state; thus no location updating is performed even if the mobile is not updated in the location area of the selected cell.

No call re-establishment shall be performed for voice group and broadcast calls.

#### 4.5.1.6.1 Call re-establishment, initiation by the mobile station

NOTE: The network is unable to initiate call re-establishment.

If at least one request to re-establish an MM connection is received from a CM entity as a response to the indication that the MM connection is interrupted (see sub-clause 4.5.2.3.) the mobile station initiates the call re-establishment procedure. If several CM entities request re-establishment only one re-establishment procedure is initiated. If any CM entity requests re-establishment, then re-establishment of all transactions belonging to all Protocol Discriminators that permit Call Re-establishment shall be attempted.

Upon request of a CM entity to re-establish an MM connection the MM sublayer requests the RR sublayer to establish an RR connection and enters MM sublayer state WAIT FOR REESTABLISH. This request contains an establishment cause and a CM RE-ESTABLISHMENT REQUEST message. When the establishment of an RR connection is indicated by the RR sublayer (this indication implies that the CM RE-ESTABLISHMENT REQUEST message has been successfully transferred via the radio interface, see sub-clause 2.2), the MM sublayer of the mobile station starts timer T3230, gives an indication to all CM entities that are being re-established, and remains in the MM sublayer state WAIT FOR REESTABLISH.

The CM RE-ESTABLISHMENT REQUEST message contains the:

- mobile identity according to sub-clause 10.5.1.4;
- mobile station classmark 2;
- ciphering key sequence number.
- NOTE: Whether or not a CM entity can request re-establishment depends upon the Protocol Discriminator. The specifications for Short Message Service (3GPP TS 04.11), Call Independent Supplementary Services (3GPP TS 04.10) and Location Services (3GPP TS 04.71) do not currently specify any re-establishment procedures.

Upon receiving a CM RE-ESTABLISHMENT REQUEST message, the network shall analyse its content. Depending on the type of request, the network may start any of the MM common procedures and RR procedures.

The network may initiate the classmark interrogation procedure, for example, to obtain further information on the mobile station's encryption capabilities.

The identification procedure (see sub-clause 4.3.3) may be invoked.

The network may invoke the authentication procedure (see sub-clause 4.3.2).

The network decides if the ciphering mode setting procedure shall be invoked (see sub-clause 3.4.7).

An indication from the RR sublayer that the ciphering mode setting procedure is completed, or reception of a CM SERVICE ACCEPT message, shall be treated as a service acceptance indication by the mobile station. The MM connection re-establishment is completed, timer T3230 shall be stopped, all CM entities associated with the re-establishment shall be informed, and MM sublayer state MM CONNECTION ACTIVE is re-entered. All the MM connections are considered to be active.

If the network cannot associate the re-establishment request with any existing call for that mobile station, a CM SERVICE REJECT message is returned with the reject cause:

#38 "call cannot be identified".

If call re-establishment cannot be performed for other reasons, a CM SERVICE REJECT is returned, the appropriate reject cause may be any of the following (see annex G):

- #4 "IMSI unknown in VLR";
- #6 "illegal ME";
- #17 "network failure";
- #22 "congestion";
- #32 "service option not supported";

#34 "service option temporarily out of order".

Whatever the reject cause a mobile station receiving a CM SERVICE REJECT as a response to the CM RE-ESTABLISHMENT REQUEST shall stop T3230, release all MM connections and proceed as described in subclause 4.5.3.1. In addition:

- if cause value #4 is received, the mobile station deletes any TMSI, LAI and ciphering key sequence number in the SIM, changes the update status to NOT UPDATED (and stores it in the SIM according to sub-clause 4.1.2.2), and enters the MM sublayer state WAIT FOR NETWORK COMMAND. If subsequently the RR connection is released or aborted, this will force the mobile station to initiate a normal location updating). The CM reestablishment request shall not be memorized during the location updating procedure.
- if cause value #6 is received, the mobile station deletes any TMSI, LAI and ciphering key sequence number in the SIM, changes the update status to ROAMING NOT ALLOWED (and stores it in the SIM according to subclause 4.1.2.2), and enters the MM sublayer state WAIT FOR NETWORK COMMAND. The MS shall consider the SIM as invalid until switch-off or the SIM is removed.

#### 4.5.1.6.2 Abnormal cases

Mobile station side:

a) Random access failure or RR connection establishment failure

If the mobile station detects a random access failure or RR connection establishment failure during the reestablishment of an MM connection, the re-establishment is aborted and all MM connections are released.

b) RR connection failure

If a RR connection failure occurs, timer T3230 is stopped, the re-establishment is aborted and all active MM connections are released.

c) IMSI deactivation

If the IMSI deactivated during the re-establishment attempt then timer T3230 is stopped, the re-establishment is aborted and all MM connections are released.

d) T3230 expires

If T3230 expires (i.e. no response is given but a RR connection is available) the re-establishment is aborted, all active MM connections are released and the mobile station proceeds as described in sub-clause 4.5.3.1.

e) Reject causes #96, #97, #99, #100, #111 received

The mobile station shall perform the same actions as if timer T3230 had expired.

Network side:

a) RR connection failure

If a RR connection failure occurs after receipt of the CM RE-ESTABLISHMENT REQUEST the network shall release all MM connections.

b) Invalid message content

Upon reception an invalid initial of message or a CM RE-ESTABLISHMENT REQUEST message with invalid content, a CM SERVICE REJECT message shall be returned with one of the following appropriate Reject cause indications:

- #96: Mandatory information element error
- #99: Information element non-existent or not implemented
- #100: Conditional IE error
- #111: Protocol error, unspecified

When the CM SERVICE REJECT message has been sent, the network shall release the RR connection.

#### 4.5.1.7 Forced release during MO MM connection establishment

If the mobile station's CM layer initiated the MM connection establishment but the CM layer wishes to abort the establishment prior to the completion of the establishment phase, the mobile station shall send a CM SERVICE ABORT message any time after the completion of the RR connection and not after the first CM message (e.g. SETUP) is sent.

If the first CM message has already been sent, the normal release procedure defined by the appropriate CM protocol applies and the CM SERVICE ABORT shall not be sent.

Sending of the CM SERVICE ABORT message is only allowed during the establishment of the first MM connection, where no other MM connection exists in parallel. If parallel MM connections exist already, a new connection establishment cannot be aborted and normal MM connection release according to 4.5.3 applies after MM connection establishment.

Upon transmission of the CM SERVICE ABORT message the mobile station shall set timer T3240 and enter the state WAIT FOR NETWORK COMMAND, expecting the release of the RR connection.

Upon receipt of the CM SERVICE ABORT message the network shall abort ongoing processes, release the appropriate resources, and unless another MM connection establishment is pending, initiate a normal release of the RR connection.

If the RR connection is not released within a given time controlled by timer T3240, the mobile station shall abort the RR connection. In both cases, either after a RR connection release triggered from the network side or after a RR connection abort requested by the mobile station side the mobile station shall return to state MM IDLE; the service state depending upon the current update status as specified in sub-clause 4.2.3.

## 4.5.2 MM connection information transfer phase

After the MM connection has been established, it can be used by the CM sublayer entity for information transfer. According to the protocol architecture described in 3GPP TS 04.07, each CM entity will have its own MM connection. These different MM connections are identified by the protocol discriminator PD and, additionally, by the transaction identifier TI.

All MM common procedures may be initiated at any time while MM connections are active. Except for Short Message Control which uses a separate layer 2 low priority data link, no priority mechanism is defined between the CM, MM and RR sublayer messages.

#### 4.5.2.1 Sending CM messages

A CM sublayer entity, after having been advised that a MM connection has been established, can request the transfer of CM messages. The CM messages passed to the MM sublayer are then sent to the other side of the interface with the PD and TI set according to the source entity.

#### 4.5.2.2 Receiving CM messages

Upon receiving a CM message, the MM sublayer will distribute it to the relevant CM entity according to the PD value and TI value. However, if the received CM message is the first for the MM connection (identified by PD and TI), the MM sublayer will in addition indicate to the CM entity that a new MM connection has been established.

#### 4.5.2.3 Abnormal cases

RR connection failure:

- If the RR connection failure occurs during a RR or MM common procedure, the consequent actions are described together with that procedure.

- In other cases, the following applies:
  - Mobile station:
    - The MM sublayer shall indicate to all CM entities associated with active MM connections that the MM connection is interrupted, the subsequent action of the MM sublayer (call re-establishment, see 4.5.1.6, or local release) will then depend on the decisions by the CM entities.
  - Network:
    - The MM sublayer shall locally release all active MM connections. As an option the network may delay the release of all or some of the MM connections to allow the mobile station to initiate call re-establishment

#### 4.5.3 MM connection release

An established MM connection can be released by the local CM entity. The release of the CM connection will then be done locally in the MM sublayer, i.e. no MM message are sent over the radio interface for this purpose.

#### 4.5.3.1 Release of associated RR connection

If all MM connections are released by their CM entities, and no RRLP procedure (see 3GPP TS 04.31 [23b]) is ongoing, the mobile station shall set timer T3240 and enter the state WAIT FOR NETWORK COMMAND, expecting the release of the RR connection.

If all MM connections are released by their CM entities and an RRLP procedure is ongoing, the MS shall start the timer T3241 and enter the state RR CONNECTION RELEASE NOT ALLOWED.

If the MS is expecting the release of the RR connection in MM state WAIT FOR NETWORK COMMAND and an RRLP procedure is started, the MS shall stop the timer T3240, start the timer T3241 and enter the state RR CONNECTION RELEASE NOT ALLOWED.

If the MS is in MM state RR CONNECTION RELEASE NOT ALLOWED and the ongoing RRLP procedure is finished, the MS shall stop the timer T3241, reset and start the timer T3240 and shall enter the state WAIT FOR NETWORK COMMAND.

In the network, if the last MM connection is released by its user, the MM sublayer may decide to release the RR connection by requesting the RR sublayer according to sub-clause 3.5. The RR connection may be maintained by the network, e.g. in order to establish another MM connection.

If the RR connection is not released within a given time controlled by the timer T3240 or T3241, the mobile station shall abort the RR connection. In both cases, either after a RR connection release triggered from the network side or after a RR connection abort requested by the MS-side, the MS shall return to MM IDLE state; the service state depending upon the current update status as specified in sub-clause 4.2.3.

#### 4.5.3.2 Uplink release in a voice group call

(Only applicable for mobile stations supporting VGCS talking:)

If a mobile station which is in the MM sublayer state MM CONNECTION ACTIVE (GROUP TRANSMIT MODE) receives a request from the GCC sublayer to perform an uplink release, the MM sublayer requests the RR sublayer to perform an uplink release procedure and enters the MM sublayer state RECEIVING GROUP CALL (NORMAL SERVICE).

## 4.6 Receiving a MM STATUS message by a MM entity

If the MM entity of the mobile station receives a MM STATUS message no state transition and no specific action shall be taken as seen from the radio interface, i.e. local actions are possible.

With the exceptions described for the responses to the CM SERVICE PROMPT message, the actions to be taken on receiving a MM STATUS message in the network are an implementation dependent option.

# 4.7 Elementary mobility management procedures for GPRS services

## 4.7.1 General

This sub-clause describes the basic functions offered by the mobility management (GMM) sublayer at the radio interface (reference point  $U_m$ ). The functionality is described in terms of timers and procedures. During GMM procedures, session management procedures, see chapter 6, are suspended.

#### 4.7.1.1 Lower layer failure

The LLC sublayer shall indicate a logical link failure or an RR sublayer failure to the GMM sublayer. The failure indicates an error that cannot be corrected by the lower layers.

#### 4.7.1.2 Ciphering of messages

If ciphering is to be applied on a GMM context, all GMM messages shall be ciphered except the following messages:

- ATTACH REQUEST;
- ATTACH REJECT;
- AUTHENTICATION AND CIPHERING REQUEST;
- AUTHENTICATION AND CIPHERING RESPONSE;
- AUTHENTICATION AND CIPHERING REJECT;
- IDENTITY REQUEST;
- IDENTITY RESPONSE;
- ROUTING AREA UPDATE REQUEST; and
- ROUTING AREA UPDATE REJECT.

#### 4.7.1.3 P-TMSI signature

The network may assign a P-TMSI signature to an MS in an attach, routing area update, or P-TMSI reallocation procedure. Only in combination with a valid P-TMSI, this P-TMSI signature is used by the MS for authentication and identification purposes in the subsequent attach or routing area update procedure. If the MS has no valid P-TMSI it shall not use the P-TMSI signature in the subsequent attach or routing area update procedure. Upon successful completion of the subsequent attach or routing area update procedure shall be deleted.

#### 4.7.1.4 Radio resource sublayer address handling

While a packet TMSI (P-TMSI) is used in the GMM sublayer for identification of an MS, a temporary logical link identity (TLLI) is used for addressing purposes at the RR sublayer. This sub-clause describes how the RR addressing is managed by GMM. For the detailed coding of the different TLLI types and how a TLLI can be derived from a P-TMSI, see 3GPP TS 03.03 [10].

Two cases can be distinguished:

- a valid P-TMSI is available in the MS; or
- no valid P-TMSI is available in the MS
- NOTE: For anonymous access, the RR address assignment is handled by the SM sublayer as described in subclause 6.1.1.1.

i) valid P-TMSI available

If the MS has stored a valid P-TMSI, the MS shall derive a foreign TLLI from that P-TMSI and shall use it for transmission of the:

- ATTACH REQUEST message of any GPRS combined/non-combined attach procedure; other GMM messages sent during this procedure shall be transmitted using the same foreign TLLI until the ATTACH ACCEPT message or the ATTACH REJECT message is received; and
- ROUTING AREA UPDATE REQUEST message of a combined/non-combined RAU procedure if the MS has entered a new routing area, or if the GPRS update status is not equal to GU1 UPDATED. Other GMM messages sent during this procedure shall be transmitted using the same foreign TLLI, until the ROUTING AREA UPDATE ACCEPT message or the ROUTING AREA UPDATE REJECT message is received.

After a successful GPRS attach or routing area update procedure, independent whether a new P-TMSI is assigned, if the MS has stored a valid P-TMSI then the MS shall derive a local TLLI from the stored P-TMSI and shall use it for addressing at lower layers.

- NOTE: Although the MS derives a local TLLI for addressing at lower layers, the network should not assume that it will receive only LLC frames using a local TLLI. Immediately after the successful GPRS attach or routing area update procedure, the network must be prepared to continue accepting LLC frames from the MS still using the foreign TLLI.
- ii) no valid P-TMSI available

When the MS has not stored a valid P-TMSI, i.e. the MS is not attached to GPRS, the MS shall use a randomly selected random TLLI for transmission of the:

- ATTACH REQUEST message of any combined/non-combined GPRS attach procedure.

The same randomly selected random TLLI value shall be used for all message retransmission attempts and for the cell updates within one attach attempt.

Upon receipt of an ATTACH REQUEST message, the network shall assign a P-TMSI to the MS. The network derives a local TLLI from the assigned P-TMSI, and transmits the assigned P-TMSI to the MS.

Upon receipt of the assigned P-TMSI, the MS shall derive the local TLLI from this P-TMSI and shall use it for addressing at lower layers.

NOTE: Although the MS derives a local TLLI for addressing at lower layers, the network should not assume that it will receive only LLC frames using a local TLLI. Immediately after the successful GPRS attach, the network must be prepared to continue accepting LLC frames from the MS still using the random TLLI.

In both cases, the MS shall acknowledge the reception of the assigned P-TMSI to the network. After receipt of the acknowledgement, the network shall use the local TLLI for addressing at lower layers.

#### 4.7.1.5 P-TMSI handling

If a new P-TMSI is assigned by the network the MS and the network shall handle the old and the new P-TMSI as follows:

- Upon receipt of a GMM message containing a new P-TMSI the MS shall consider the new P-TMSI and new RAI and also the old P-TMSI and old RAI as valid in order to react to paging requests and downlink transmission of LLC frames. For uplink transmission of LLC frames the new P-TMSI shall be used.
- The MS shall consider the old P-TMSI and old RAI as invalid as soon as an LLC frame is received with the local TLLI derived from the new P-TMSI.
- Upon the transmission of a GMM message containing a new P-TMSI the network shall consider the new P-TMSI and new RAI and also the old P-TMSI and old RAI as valid in order to be able to receive LLC frames from the MS.
- The network shall consider the old P-TMSI and old RAI as invalid as soon as an LLC frame is received with the local TLLI derived from the new P-TMSI.

#### 4.7.1.6 Change of network mode of operation

Whenever an MS moves to a new RA, the procedures executed by the MS depend on the network mode of operation in the old and new routing area.

In case the MS is in state GMM-REGISTERED or GMM-ROUTING-AREA-UPDATING-INITIATED and is in operation mode:

a) A or B (with the exceptions in b and c below), the MS shall execute.

Network operation mode change	Procedure to execute
$I \rightarrow II \text{ or } I \rightarrow III$	Normal Location Update (see note),
	followed by a Normal Routing Area Update
$\parallel \rightarrow \parallel \parallel \text{ or } \parallel \parallel \rightarrow \parallel$	Normal Location Update (see sub-clause 4.2.2),
	followed by a Normal Routing Area Update
$II \rightarrow I \text{ or } III \rightarrow I$	Combined Routing Area Update with IMSI attach

#### Table 4.7.1.6.1/3GPP TS 04.08: Mode A or B

b) B which reverts to operation mode C in network operation mode III, the MS shall execute:

Network operation mode change	Procedure to execute
$  \rightarrow   $	Normal Location Update (see note),
	followed by a Normal Routing Area Update
$I \rightarrow III \text{ or } II \rightarrow III$	IMSI Detach (see sub-clause 4.3.4),
	followed by a Normal Routing Area Update
$II \rightarrow I \text{ or } III \rightarrow I$	Combined Routing Area Update with IMSI attach
$    \rightarrow   $	IMSI attach (see sub-clause 4.4.3),
	followed by a Normal Routing Area Update

c) B which reverts to IMSI attached for CS services only in network operation mode III, the MS shall execute:

## Table 4.7.1.6.3/3GPP TS 04.08: Mode B which reverts into IMSI attached for CS services only in network operation mode III

Network operation mode change	Procedure to execute
$  \rightarrow   $	Normal Location Update (see note),
	followed by a Normal Routing Area Update
$I \rightarrow III$	Normal Location Update (see note),
	followed by a GPRS Detach with type indicating "GPRS Detach"
$\parallel \rightarrow \parallel \parallel$	Normal Location Update (see sub-clause 4.2.2),
	followed by a GPRS Detach with detach type indicating "GPRS Detach"
$\parallel \rightarrow \parallel$	Combined Routing Area Update with IMSI attach
$III \rightarrow I$	Combined GPRS Attach
$ \Pi \rightarrow \Pi$	Normal Location Update (see sub-clause 4.2.2),
	followed by a Normal GPRS Attach

NOTE: Intended to remove the Gs association in the MSC/VLR.

Further details are implementation issues.

#### 4.7.1.7 (void)

[is already used in 24.008 from R99 onwards]

#### 4.7.1.8 List of forbidden PLMNs for GPRS service

The Mobile Equipment shall contain a list of "forbidden PLMNs for GPRS service". This lists shall be erased when the MS is switched off or when the SIM is removed. The PLMN identification received on the BCCH shall be added to the list whenever a GPRS attach, GPRS detach or routing area update is rejected by the network with the cause "GPRS services not allowed in this PLMN". The maximum number of possible entries in this list is implementation dependant, but must be at least one entry. When the list is full and a new entry has to be inserted, the oldest entry shall be deleted.

### 4.7.2 GPRS Mobility management timers

#### 4.7.2.1 READY timer behaviour

The READY timer, T3314 is used in the MS and in the network per each assigned P-TMSI to control the cell updating procedure.

When the READY timer is running or has been deactivated the MS shall perform cell update each time a new cell is selected (see 3GPP TS 03.22 [14]). If a routing area border is crossed, a routing area updating procedure shall be performed instead of a cell update.

When the READY timer has expired the MS shall:

- perform the routing area updating procedure when a routing area border is crossed;
- not perform a cell update when a new cell is selected.

All other GMM procedures are not affected by the READY timer.

The READY timer is started:

- in the MS when the GMM entity receives an indication from lower layers that an LLC frame has been transmitted on the radio interface; and
- in the network when the GMM entity receives an indication from lower layers that an LLC frame has been successfully received by the network.

Within GMM signalling procedures the network includes a "force to standby" information element, in order to indicate whether or not the READY timer shall be stopped when returning to the GMM-REGISTERED state. If the "force to standby" information element is received within more than one message during a ongoing GMM specific procedure, the last one received shall apply. If the READY timer is deactivated and the network indicates "force to standby" with the 'force to standby' information element, this shall not cause a modification of the READY timer.

The READY timer is not affected by state transitions to and from the GMM-REGISTERED.SUSPENDED sub-state.

The value of the READY timer may be negotiated between the MS and the network using the GPRS attach or GPRS routing area updating procedure.

- If the MS wishes to indicate its preference for a READY timer value it shall include the preferred values into the ATTACH REQUEST and/or ROUTING AREA UPDATE REQUEST messages. The preferred values may be smaller, equal to or greater than the default values or may be equal to the value requesting the READY Timer function to be deactivated.
- Regardless of whether or not a timer value has been received by the network in the ATTACH REQUEST or ROUTING AREA UPDATE REQUEST messages, the network may include a timer value for the READY timer (different or not from the default value) into the ATTACH ACCEPT or ROUTING AREA UPDATE ACCEPT messages, respectively. If the READY Timer value was included, it shall be applied for the GMM context by the network and by the MS.
- When the MS proposes a READY Timer value and the Network does not include any READY Timer Value in its answer, then the value proposed by the MS shall be applied for the GMM context by the Network and by the MS.
- When neither the MS nor the Network proposes a READY Timer value into the ATTACH ACCEPT or ROUTING AREA UPDATE ACCEPT message, then the default value shall be used.

If the negotiated READY timer value indicates that the ready timer function is deactivated, the READY timer shall always run without expiry. If the negotiated READY timer value indicates that the ready timer function is deactivated, and within the same procedure the network indicates 'force to standby' with the 'force to standby' information element, the READY timer shall always run without expiry. If the negotiated READY timer value is set to zero, READY timer shall be stopped immediately.

To account for the LLC frame uplink transmission delay, the READY timer value should be slightly shorter in the network than in the MS. This is a network implementation issue.

If a new READY timer value is negotiated, the MS shall upon the reception of the ATTACH ACCEPT or ROUTING AREA UPDATE ACCEPT message perform a initial cell update (either by transmitting a LLC frame or, if required, a ATTACH COMPLETE or ROUTING AREA UPDATE COMPLETE message), in order to apply the new READY timer value immediately. If the new READY timer value is set to zero or if the network indicates 'force to standby' with the 'force to standby' IE, the initial cell update should not be done.

#### 4.7.2.2 Periodic routing area updating

Periodic routing area updating is used to periodically notify the availability of the MS to the network. The procedure is controlled in the MS by the periodic RA update timer, T3312. The value of timer T3312 is sent by the network to the MS in the messages ATTACH ACCEPT and ROUTING AREA UPDATE ACCEPT. The value of the timer T3312 shall be unique within a RA.

The timer T3312 is reset and started with its the initial value, when the READY timer is stopped or expires. The timer T3312 is stopped and shall be set to its initial value for the next start when the READY timer is started. If after a READY timer negotiation the READY timer value is set to zero, timer T3312 is reset and started with its the initial value. If the initial READY timer value is zero, the timer T3312 is reset and started with its the initial value, when the ROUTING AREA UPDATE REQUEST message is transmitted.

When timer T3312 expires, the periodic routing area updating procedure shall be started and the timer shall be set to its initial value for the next start.

If the MS is in other state than GMM-REGISTERED.NORMAL-SERVICE when the timer expires the periodic routing area updating procedure is delayed until the MS returns to GMM-REGISTERED.NORMAL-SERVICE. If the MS in MS operation mode B is in the state GMM-REGISTERED.SUSPENDED when the timer expires the periodic routing area updating procedure is delayed until the state is left.

The network supervises the periodic routing area updating procedure by means of the Mobile Reachable timer. The Mobile Reachable timer shall be longer than the periodic RA update timer. When the Mobile Reachable timer expires, typically the network stops sending paging messages to the mobile and may take other appropriate actions.

The Mobile Reachable timer is reset and started with its the initial value, when the READY timer is stopped or expires. The Mobile Reachable timer is stopped and shall be set to its initial value for the next start when the READY timer is started.

If after a READY timer negotiation the READY timer value is set to zero the Mobile Reachable timer is reset and started with its the initial value. If the initial READY timer value is zero, the Mobile Reachable is reset and started with its the initial value, when the ROUTING AREA UPDATE REQUEST message is received.

If the MS is both IMSI attached for GPRS and non-GPRS services , and if the MS lost coverage of the registered PLMN and timer T3312 expires, then:

- a) if the MS returns to coverage in a cell that supports GPRS and that indicates that the network is in network operation mode I, then the MS shall either perform the combined routing area update procedure indicating "combined RA/LA updating with IMSI attach"; or
- b) if the MS returns to coverage in a cell in the same RA that supports GPRS and that indicates that the network is in network operation mode II or III, then the MS shall perform the periodic routing area updating procedure indicating "Periodic updating" and shall perform the periodic location updating procedure; or
- c) if the MS returns to coverage in a cell that does not support GPRS, then, depending upon the LA of the cell, the MS shall either perform the periodic location updating procedure or a normal location updating procedure. In addition, the MS shall perform a combined routing area update procedure indicating "combined RA/LA updating with IMSI attach" when the MS enters a cell that supports GPRS and that indicates that the network is in network operation mode I; or

d) if the MS returns to coverage in a new RA the description given in sub-clause 4.7.5 applies.

If the MS is both IMSI attached for GPRS and non-GPRS services in a network that operates in network operation mode I, and if the MS has camped on a cell that does not support GPRS, and timer T3312 expires, then the MS shall start an MM location updating procedure. In addition, the MS shall perform a combined routing area update procedure indicating "combined RA/LA updating with IMSI attach" when the MS enters a cell that supports GPRS and indicates that the network is in operation mode I.

Timer T3312 shall not be stopped when a GPRS MS enters state GMM-REGISTERED.SUSPENDED.

## 4.7.3 GPRS attach procedure

The GPRS attach procedure is used for two purposes:

- normal GPRS attach, performed by the MS to IMSI attach for GPRS services only. The normal GPRS attach
  procedure shall be used by GPRS MSs in MS operation mode C, independent of the network operation mode. It
  shall also be used by GPRS MSs in MS operation modes A or B if the network operates in network operation
  mode II or III.
- combined GPRS attach procedure, used by GPRS MSs in MS operation modes A or B to attach the IMSI for GPRS and non-GPRS services provided that the network operates in network operation mode I.

With a successful GPRS attach procedure a GMM context is established.

Sub-clause 4.7.3.1 describes the GPRS attach procedure to attach the IMSI only for GPRS services. The combined GPRS attach procedure used to attach the IMSI for both GPRS and non-GPRS services is described in sub-clause 4.7.3.2.

If an IMSI attach for non-GPRS services is requested and a GMM context exists, the routing area updating procedure shall be used as described in sub-clause 4.7.5.2.

To limit the number of subsequently rejected attach attempts, a GPRS attach attempt counter is introduced. The GPRS attach attempt counter shall be incremented as specified in sub-clause 4.7.3.1.5. Depending on the value of the GPRS attempt counter, specific actions shall be performed. The GPRS attach attempt counter shall be reset when:

- the MS is powered on;
- a SIM is inserted;
- a GPRS attach procedure is successfully completed; or
- a combined GPRS attach procedure is completed for GPRS services only with cause #2, #16, #17 or #22;
- a GPRS attach procedure is completed with cause #11, #12 or #13;

and additionally when the MS is in substate ATTEMPTING-TO-ATTACH:

- expiry of timer T3302;
- a new routing area is entered; or
- an attach is triggered by CM sublayer requests.

The mobile equipment shall contain a list of "forbidden location areas for roaming", as well as a list of "forbidden location areas for regional provision of service". The handling of these lists is described in sub-clause 4.4.1; the same lists are used by GMM and MM procedures.

### 4.7.3.1 GPRS attach procedure for GPRS services

The GPRS attach procedure is a GMM procedure used by GPRS MSs to IMSI attach for GPRS services.

The attach type information element shall indicate "GPRS attach".

## 4.7.3.1.1 GPRS attach procedure initiation

In state GMM-DEREGISTERED, the MS initiates the GPRS attach procedure by sending an ATTACH REQUEST message to the network, starts timer T3310 and enters state GMM-REGISTERED-INITIATED.

The MS shall include a valid P-TMSI, if any is available, the P-TMSI signature associated with the P-TMSI and the routing area identity associated with the P-TMSI in the ATTACH REQUEST message. If there is no valid P-TMSI available, the IMSI shall be included instead of the P-TMSI and P-TMSI signature.

The MS shall also indicate within the DRX parameters whether it supports the split pg cycle option on CCCH. The optional support of the split pg cycle on CCCH by the network is indicated in SI13 or PSI1. Split pg cycle on CCCH is applied by both the network and the MS when the split pg cycle option is supported by both (see 3GPP TS 05.02).

## 4.7.3.1.2 GMM common procedure initiation

The network may initiate GMM common procedures, e.g. the GMM identification and GMM authentication and ciphering procedure, depending on the received information such as IMSI, CKSN, old RAI, P-TMSI and P-TMSI signature.

## 4.7.3.1.3 GPRS attach accepted by the network

If the GPRS attach request is accepted by the network, an ATTACH ACCEPT message is sent to the MS.

The P-TMSI reallocation may be part of the GPRS attach procedure. The P-TMSI that shall be allocated is then included in the ATTACH ACCEPT message together with the routing area identifier. The network shall, in this case, change to state GMM-COMMON-PROCEDURE-INITIATED and shall start timer T3350 as described in sub-clause 4.7.6. Furthermore, the network may assign a P-TMSI signature for the GMM context which is then also included in the ATTACH ACCEPT message. If the LAI or PLMN identity that has been transmitted in the ATTACH ACCEPT message is a member of any of the "forbidden" lists, any such entry shall be deleted. Additionally, the network shall include the radio priority level to be used by the MS for mobile originated SMS transfer in the ATTACH ACCEPT message.

The MS, receiving an ATTACH ACCEPT message, stores the received routing area identification, stops timer T3310, reset the GPRS attach attempt counter, reset the routing area updating attempt counter, enters state GMM-REGISTERED and sets the GPRS update status to GU1 UPDATED.

If the message contains a P-TMSI, the MS shall use this P-TMSI as the new temporary identity for GPRS services. In this case, an ATTACH COMPLETE message is returned to the network. The MS shall delete its old P-TMSI and shall store the new one. If no P-TMSI has been included by the network in the ATTACH ACCEPT message, the old P-TMSI, if any available, shall be kept.

If the message contains a P-TMSI signature, the MS shall use this P-TMSI signature as the new temporary signature for the GMM context. The MS shall delete its old P-TMSI signature, if any is available, and shall store the new one. If the message contains no P-TMSI signature, the old P-TMSI signature, if available, shall be deleted.

The network receiving an ATTACH COMPLETE message stops timer T3350, changes to GMM-REGISTERED state and considers the P-TMSI sent in the ATTACH ACCEPT message as valid.

## 4.7.3.1.4 GPRS attach not accepted by the network

If the attach request cannot be accepted by the network, an ATTACH REJECT message is transferred to the MS. The MS receiving the ATTACH REJECT message stops timer T3310 and takes one of the following actions depending upon the reject cause:

- # 3 (Illegal MS);
- # 6 (Illegal ME);

The MS shall set the GPRS update status to GU3 ROAMING NOT ALLOWED (and shall store it according to sub-clause 4.1.3.2) and shall delete any P-TMSI, P-TMSI signature, RAI and GPRS ciphering key sequence number. The new GMM state is GMM-DEREGISTERED. The SIM shall be considered as invalid for GPRS services until switching off or the SIM is removed.

If the MS is IMSI attached via MM procedures, the MS shall in addition set the update status to U3 ROAMING NOT ALLOWED, shall delete any TMSI, LAI and ciphering key sequence number. The new MM state is MM IDLE. The SIM shall be considered as invalid also for non-GPRS services until switching off or the SIM is removed.

# 7 (GPRS services not allowed);

The MS shall set the GPRS update status to GU3 ROAMING NOT ALLOWED (and shall store it according to sub-clause 4.1.3.2) and shall delete any P-TMSI, P-TMSI signature, RAI and GPRS ciphering key sequence number. The SIM shall be considered as invalid for GPRS services until switching off or the SIM is removed. The new state is GMM-DEREGISTERED.

#8 (GPRS services and non-GPRS services not allowed);

The MS shall set the GPRS update status to GU3 ROAMING NOT ALLOWED (shall store it according to sub-clause 4.1.3.2) and shall delete any P-TMSI, P-TMSI signature, RAI and GPRS ciphering key sequence number. The new GMM state is GMM-DEREGISTERED. The new MM state is MM IDLE.

The MS shall set the update status to U3 ROAMING NOT ALLOWED, shall delete any TMSI, LAI and ciphering key sequence number. The SIM shall be considered as invalid for GPRS and non-GPRS services until switching off or the SIM is removed.

- #11 (PLMN not allowed);
- #12 (Location area not allowed);
- #13 (Roaming not allowed in this location area); or

The MS shall delete any RAI, P-TMSI, P-TMSI signature, and GPRS ciphering key sequence number stored, shall set the GPRS update status to GU3 ROAMING NOT ALLOWED (and shall store it according to subclause 4.1.3.2), shall reset the GPRS attach attempt counter and shall change to state GMM-DEREGISTERED.

If the MS is IMSI attached via MM procedures, the MS shall in addition set the update status to U3 ROAMING NOT ALLOWED, shall delete any TMSI, LAI and ciphering key sequence number and shall reset the location update attempt counter. The new MM state is MM IDLE.

The MS shall store the LAI or the PLMN identity in the appropriate forbidden list, i.e. in the "forbidden PLMN list" for cause #11, in the list of "forbidden location areas for regional provision of service" for cause #12 or in the list of "forbidden location areas for roaming" for cause #13. If cause #11 or #13 was received, the MS shall perform a PLMN selection instead of a cell selection.

#14 (GPRS services not allowed in this PLMN)

The MS shall delete any RAI, P-TMSI, P-TMSI signature, and GPRS ciphering key sequence number stored, shall set the GPRS update status to GU3 ROAMING NOT ALLOWED (and shall store it according to subclause 4.1.3.2) and shall change to state GMM-DEREGISTERED.

The MS shall store the PLMN identity in the "forbidden PLMNs for GPRS service" list. A GPRS MS operating in MS operation mode C shall perform a PLMN selection instead of a cell selection.

A GPRS MS operating in MS operation mode A or B in network operation mode II or III, is still IMSI attached for CS services in the network.

Other values are considered as abnormal cases. The specification of the MS behaviour in those cases is specified in subclause 4.7.3.1.5.

## 4.7.3.1.5 Abnormal cases in the MS

The following abnormal cases can be identified:

a) Access barred because of access class control

The GPRS attach procedure shall not be started. The MS stays in the current serving cell and applies normal cell reselection process. The GPRS attach procedure is started as soon as possible, i.e. when access is granted or because of a cell change.

b) Lower layer failure before the ATTACH ACCEPT or ATTACH REJECT message is received

The procedure shall be aborted. The MS shall proceed as described below.

c) T3310 time-out

On the first expiry of the timer, the MS reset and restart timer T3310 and shall retransmit the ATTACH REQUEST message. This retransmission is repeated four times, i.e. on the fifth expiry of timer T3310, the GPRS attach procedure shall be aborted and the MS shall proceed as described below.

d) ATTACH REJECT, other causes than those treated in sub-clause 4.7.3.1.4

The MS shall proceed as described below.

e) Change of cell within the same RA

If a cell change occurs within the same RA when the MS is in state GMM-REGISTERED-INITIATED, then the cell update procedure shall be performed before completion of the attach procedure.

f) Change of cell into a new routing area

If a cell change into a new routing area occurs before an ATTACH ACCEPT or ATTACH REJECT message has been received, the GPRS attach procedure shall be aborted and re-initiated immediately. If a routing area border is crossed when the ATTACH ACCEPT message is received but before an ATTACH COMPLETE message is sent, the GPRS attach procedure shall be aborted and the routing area updating procedure shall be initiated. If a P-TMSI was allocated during the GPRS attach procedure, this P-TMSI shall be used in the routing area updating procedure, this P-TMSI signature was allocated together with the P-TMSI during the GPRS attach procedure, this P-TMSI signature shall be used in the routing area updating procedure.

g) Mobile originated detach required

If the MS is in state GMM-REGISTERED-INITIATED, the GPRS attach procedure shall be aborted and the GPRS detach procedure shall be performed (see 4.7.4.1).

h) Procedure collision

If the MS receives a DETACH REQUEST message from the network in state GMM-REGISTERED-INITIATED, the GPRS detach procedure shall be progressed and the GPRS attach procedure shall be aborted. If the cause IE, in the DETACH REQUEST message, indicated a "reattach request", the GPRS attach procedure shall be progressed and the DETACH REQUEST message shall be ignored.

In cases b), c) and d) the MS shall proceed as follows. Timer T3310 shall be stopped if still running. The GPRS attach attempt counter shall be incremented.

If the GPRS attach attempt counter is less than 5:

- timer T3311 is started and the state is changed to GMM-DEREGISTERED.ATTEMPTING-TO-ATTACH.

If the GPRS attach attempt counter is greater than or equal to 5:

- the MS shall delete any RAI, P-TMSI, P-TMSI signature, and GPRS ciphering key sequence number, shall set the GPRS update status to GU2 NOT UPDATED, shall start timer T3302. The state is changed to GMM-DEREGISTERED..ATTEMPTING-TO-ATTACH or optionally to GMM-DEREGISTERED.PLMN-SEARCH (see sub-clause 4.2.4.1.2).

#### 4.7.3.1.6 Abnormal cases on the network side

The following abnormal cases can be identified:

a) Lower layer failure

If a low layer failure occurs before the message ATTACH COMPLETE has been received from the MS and a new P-TMSI (or a new P-TMSI and a new P-TMSI signature) has been assigned, the network shall consider both the old and new P-TMSI each with its corresponding P-TMSI-signature as valid until the old P-TMSI can be considered as invalid by the network (see sub-clause 4.7.1.5) and shall not resent the message ATTACH ACCEPT. During this period the network may:

- use the identification procedure followed by a P-TMSI reallocation procedure if the old P-TMSI is used by the MS in a subsequent message.
- b) Protocol error

If the ATTACH REQUEST message is received with a protocol error, the network shall return an ATTACH REJECT message with one of the following reject causes:

- #96: Mandatory information element error;
- #99: Information element non-existent or not implemented;
- #100: Conditional IE error;
- #111: Protocol error, unspecified.
- c) T3350 time-out

On the first expiry of the timer, the network shall retransmit the ATTACH ACCEPT message and shall reset and restart timer T3350.

This retransmission is repeated four times, i.e. on the fifth expiry of timer T3350, the GPRS attach procedure shall be aborted. If a new P-TMSI or a new P-TMSI together with a new P-TMSI signature were allocated in the ATTACH ACCEPT message, the network shall consider both the old and new P-TMSI each together with the corresponding P-TMSI signatures as valid until the old P-TMSI can be considered as invalid by the network (see sub-clause 4.7.1.5). During this period the network acts as specified for case a.

#### d1) ATTACH REQUEST received

If one or more of the information elements in the ATTACH REQUEST message differ from the ones received within the previous ATTACH REQUEST message, the previously initiated GPRS attach procedure shall be aborted and the new GPRS attach procedure shall be progressed; or

If no information element differ, then the ATTACH ACCEPT message shall be resent.

d2)More than one ATTACH REQUEST received and no ATTACH ACCEPT or ATTACH REJECT message has been sent

If one or more of the information elements in the ATTACH REQUEST message differs from the ones received within the previous ATTACH REQUEST message, the previously initiated GPRS attach procedure shall be aborted and the new GPRS attach procedure shall be progressed;


If the information elements do not differ, then the network shall continue with the previous attach procedure and shall not treat any further this ATTACH REQUEST message.

#### e) ATTACH REQUEST received in state GMM-REGISTERED

If an ATTACH REQUEST message is received in state GMM-REGISTERED the network may initiate the GMM common procedures; if it turned out that the ATTACH REQUEST message was send by an MS that has already been attached, the GMM context and PDP contexts, if any, are deleted and the new ATTACH REQUEST is progressed.

f) ROUTING AREA UPDATE REQUEST message received before ATTACH COMPLETE message.

Timer T3350 shall be stopped. The allocated P-TMSI shall be considered as valid and the routing area updating procedure shall be progressed as described in sub-clause 4.7.5.



## Figure 4.7.3/1 3GPP TS 04.08: GPRS attach procedure and combined GPRS attach procedure

## 4.7.3.2 Combined GPRS attach procedure for GPRS and non-GPRS services

The combined GPRS attach procedure is a GMM procedure used by a GPRS MS operating in MS operation modes A or B for IMSI attach for GPRS and non-GPRS services if the network operates in network operation mode I.

If a GPRS MS operating in MS operation modes A or B is already attached for non-GPRS services by use of the MM specific IMSI attach procedure, but additionally wishes to perform an IMSI attach for GPRS services, the combined GPRS attach procedure shall also be used.

The attach type information element shall indicate "combined GPRS attach". In this case, the messages ATTACH ACCEPT, ATTACH COMPLETE, and ATTACH REJECT used by the combined GPRS attach procedure carry information for both the GPRS and the non-GPRS services.

## 4.7.3.2.1 Combined GPRS attach procedure initiation

If the MS is in GMM state GMM-DEREGISTERED and in MM state MM IDLE, the MS initiates the combined GPRS attach procedure by sending an ATTACH REQUEST message to the network, starts timer T3310 and enters state GMM-REGISTERED-INITIATED and MM LOCATION UPDATING PENDING.

The MS shall include a valid P-TMSI, if available, the P-TMSI signature associated with the P-TMSI and the routing area identity associated with the P-TMSI in the ATTACH REQUEST message. If there is no valid P-TMSI available, the IMSI shall be included instead of the P-TMSI and P-TMSI signature. Furthermore the MS shall include the TMSI status IE if no valid TMSI is available.

## 4.7.3.2.2 GMM Common procedure initiation

The network may initiate GMM common procedures, e.g. the GMM identification and GMM authentication and ciphering procedure, depending on the received information such as IMSI, CKSN, old RAI, P-TMSI and P-TMSI signature.

#### 4.7.3.2.3 Combined GPRS attach accepted by the network

Depending on the value of the attach result IE received in the ATTACH ACCEPT message, two different cases can be distinguished:

Case 1)	The attach result IE value indicates "combined GPRS attach": IMSI attach for GPRS and non-GPRS services have been successful.
Case 2)	The attach result IE value indicates "GPRS only": IMSI attach for GPRS services has been successful but IMSI attach for non-GPRS services has not been successful.

#### 4.7.3.2.3.1 Combined attach successful for GPRS and non-GPRS services

The description for IMSI attach for GPRS services as specified in sub-clause 4.7.3.1.3 shall be followed. In addition, the following description for IMSI attach for non-GPRS services applies.

The TMSI reallocation may be part of the combined GPRS attach procedure. The TMSI allocated is then included in the ATTACH ACCEPT message together with the location area identification (LAI). The network shall, in this case, change to state GMM-COMMON-PROCEDURE-INITIATED and shall start timer T3350 as described in sub-clause 4.7.6.

The MS, receiving an ATTACH ACCEPT message, stores the received location area identification, stops timer T3310, reset the location update attempt counter and sets the update status to U1 UPDATED. If the message contains an IMSI, the mobile station is not allocated any TMSI, and shall delete any TMSI accordingly. If the message contains a TMSI, the MS shall use this TMSI as the new temporary identity. The MS shall delete its old TMSI and shall store the new TMSI. In this case, an ATTACH COMPLETE message is returned to the network. If neither a TMSI nor an IMSI has been included by the network in the ATTACH ACCEPT message, the old TMSI, if any available, shall be kept. The new MM state is MM IDLE, the new GMM state is GMM-REGISTERED.

Any timer used for triggering the location update procedure (e.g T3211, T3212) shall be stopped if running.

The network receiving an ATTACH COMPLETE message stops timer T3350, changes to state GMM-REGISTERED and considers the new TMSI as valid.

#### 4.7.3.2.3.2 Combined attach successful for GPRS services only

The description for IMSI attach for GPRS services as specified in sub-clause 4.7.3.1.3 shall be followed. In addition, the following description for IMSI attach for non-GPRS services applies.

The MS receiving the ATTACH ACCEPT message takes one of the following actions depending on the reject cause:

# 2 (IMSI unknown in HLR);

The MS shall set the update status to U3 ROAMING NOT ALLOWED and shall delete any TMSI, LAI and ciphering key sequence number. The new MM state is MM IDLE. The SIM shall be considered as invalid for non-GPRS services until switching off or the SIM is removed.

- #16 (MSC temporarily not reachable);
- #17 (Network failure); or
- #22 (Congestion);

The MS shall change to state GMM-REGISTERED.ATTEMPTING-TO-UPDATE-MM. Timer T3310 shall be stopped if still running. The routing area updating attempt counter shall be incremented.

If the routing area updating attempt counter is less than 5, and the stored RAI is equal to the RAI of the current serving cell and the GMM update status is equal to GU1 UPDATED:

 the MS shall keep the GMM update status GU1 UPDATED and changes state to GMM-REGISTERED.ATTEMPTING-TO-UPDATE-MM. The MS shall start timer T3311. When timer T3311 expires the combined routing area update procedure indicating "combined RA/LA updating with IMSI attach" is triggered again. If the routing area updating attempt counter is greater than or equal to 5:

- the MS shall start timer T3302 and shall change to state GMM-REGISTERED.ATTEMPTING-TO-UPDATE-MM;
- a GPRS MS operating in MS operation mode A shall then proceed with appropriate MM specific procedure;
   a GPRS MS operating in MS operation mode B may then proceed with appropriate MM specific procedures.
   The MM sublayer shall act as in network operation mode II as long as the combined GMM procedures are not successful and no new RA is entered. The new MM state is MM IDLE.

Other values are considered as abnormal cases. The combined attach procedure shall be considered as failed for GPRS and non-GPRS services. The behaviour of the MS in those cases is specified in sub-clause 4.7.3.2.5.

#### 4.7.3.2.4 Combined GPRS attach not accepted by the network

If the attach request can neither be accepted by the network for GPRS nor for non-GPRS services, an ATTACH REJECT message is transferred to the MS. The MS receiving the ATTACH REJECT message stops timer T3310 and takes one of the following actions depending upon the reject cause:

- # 3 (Illegal MS);
- # 6 (Illegal ME);
- # 8 (GPRS services and non-GPRS services not allowed);

The MS shall set the GPRS update status to GU3 ROAMING NOT ALLOWED (shall store it according to sub-clause 4.1.3.2) and shall delete any P-TMSI, P-TMSI signature, RAI and GPRS ciphering key sequence number. The new GMM state is GMM-DEREGISTERED. The new MM state is MM IDLE.

The MS shall set the update status to U3 ROAMING NOT ALLOWED, shall delete any TMSI, LAI and ciphering key sequence number. The SIM shall be considered as invalid for GPRS and non-GPRS services until switching off or the SIM is removed.

#7 (GPRS services not allowed);

The MS shall set the GPRS update status to GU3 ROAMING NOT ALLOWED (and shall store it according to sub-clause 4.1.3.2) and shall delete any P-TMSI, P-TMSI signature, RAI and GPRS ciphering key sequence number. The SIM shall be considered as invalid for GPRS services until switching off or the SIM is removed. The new GMM state is GMM-DEREGISTERED; the MM state is MM IDLE. A GPRS MS operating in MS operation mode A shall then perform an IMSI attach for non-GPRS services by use of the MM IMSI attach procedure; a GPRS MS operating in MS operation mode B shall then perform an IMSI attach for non-GPRS services by use of the MM IMSI attach for non-GPRS services by use of the MM IMSI attach procedure.

- #11 (PLMN not allowed);
- #12 (Location area not allowed);
- #13 (Roaming not allowed in this location area); or

The MS shall delete any RAI, P-TMSI, P-TMSI signature and GPRS ciphering key sequence number stored, shall set the GPRS update status to GU3 ROAMING NOT ALLOWED (and shall store it according to subclause 4.1.3.2), shall reset the routing area updating attempt counter and reset the GPRS attach attempt counter and changes to state GMM-DEREGISTERED. The MS shall set the update status to U3 ROAMING NOT ALLOWED, reset the location update attempt counter and shall delete any TMSI, LAI and ciphering key sequence number. The new MM state is MM IDLE.

The MS shall store the LAI or the PLMN identity in the appropriate forbidden list, i.e. in the "forbidden PLMN list" for cause #11, in the list of "forbidden location areas for regional provision of service" for cause #12 or in the list of "forbidden location areas for roaming" for cause #13. If cause #11 or #13 was received, the MS shall perform a PLMN selection instead of a cell selection.

# 14 (GPRS services not allowed in this PLMN)

The MS shall delete any RAI, P-TMSI, P-TMSI signature, and GPRS ciphering key sequence number stored, shall set the GPRS update status to GU3 ROAMING NOT ALLOWED (and shall store it according to subclause 4.1.3.2) and shall change to state GMM-DEREGISTERED.

The MS shall store the PLMN identity in the "forbidden PLMNs for GPRS service" list.

A GPRS MS operating in MS operation mode A or B shall then perform an IMSI attach for non-GPRS services by use of the MM IMSI attach procedure.

Other values are considered as abnormal cases. The specification of the MS behaviour in those cases is specified in subclause 4.7.3.2.5.

#### 4.7.3.2.5 Abnormal cases in the MS

The abnormal cases specified in sub-clause 4.7.3.1.5 apply with the following modification:

- If the GPRS attach attempt counter is less than 5, the MM state remains MM LOCATION UPDATING PENDING.
- If the GPRS attach attempt counter is incremented according to sub-clause 4.7.3.1.5 the next actions depend on the Location Area Identities (stored on SIM and the one of the current serving cell) and the value of the attach attempt counter:
  - if the update status is U1 UPDATED, and the stored LAI is equal to the one of the current serving cell and the attach attempt counter is smaller than 5, then the mobile station shall keep the update status to U1 UPDATED, the new MM state is MM IDLE substate NORMAL SERVICE; or
  - if the update status is different from U1 UPDATED, or the stored LAI is different from the one of the current serving cell, or the attach attempt counter is greater or equal to 5, then the mobile station shall delete any LAI, TMSI, ciphering key sequence number stored in the SIM and set the update status to U2 NOT UPDATED. The new MM state is MM IDLE substate ATTEMPTING TO UPDATE.

#### 4.7.3.2.6 Abnormal cases on the network side

The abnormal cases specified in sub-clause 4.7.3.1.6 apply with the exceptions for cases a and c in which in addition to the P-TMSI and P-TMSI signature the old TMSI shall be considered occupied until the new TMSI is used by the MS in a subsequent message.

## 4.7.4 GPRS detach procedure

The GPRS detach procedure is used:

- to detach the IMSI for GPRS services only. Independent of the network operation mode, this procedure is used by all kind of GPRS MSs;
- as a combined GPRS detach procedure used by GPRS MSs operating in MS operation mode A or B to detach the IMSI for GPRS and non-GPRS services or for non-GPRS services only, if the network operates in network operation mode I; or
- in the case of a network failure condition to indicate to the MS that a re-attach with successive activation of previously active PDP contexts shall be performed.

After completion of a GPRS detach procedure or combined GPRS detach procedure for GPRS and non-GPRS services the GMM context is released.

The GPRS detach procedure shall be invoked by the MS if the MS is switched off, the SIM card is removed from the MS or if the GPRS or non-GPRS capability of the MS is disabled. The procedure may be invoked by the network to detach the IMSI for GPRS services. The GPRS detach procedure causes the MS to be marked as inactive in the network for GPRS services, non-GPRS services or both services.

If the GPRS detach procedure is performed, the PDP contexts are deactivated locally without peer to peer signalling between the SM and LLC entities in the MS and the network.

## 4.7.4.1 MS initiated GPRS detach procedure

#### 4.7.4.1.1 MS initiated GPRS detach procedure initiation

The GPRS detach procedure is initiated by the MS by sending a DETACH REQUEST message. The detach type information element may indicate "GPRS detach with switching off", "GPRS detach without switching off", "IMSI detach", "GPRS/IMSI detach with switching off" or "GPRS/IMSI detach without switching off". If the MS is not switched off, timer T3321 shall be started after the DETACH REQUEST message has been sent. If the detach type information element value indicates "IMSI Detach" the MS shall enter GMM-REGISTERED.IMSI-DETACH\_INITIATED, otherwise the MS shall enter the state GMM-DEREGISTERED-INITIATED. If the detach type information element value indicates "IMSI Detach" or "GPRS/IMSI Detach", state MM IMSI DETACH PENDING is entered.

If the detach type information element value indicates "GPRS detach without switching off " and the MS is attached for GPRS and non-GPRS services and the network operates in network operation mode I, then if in the MS the timer T3212 is not already running, the timer T3212 shall be set to its initial value and restarted after the DETACH REQUEST message has been sent.

#### 4.7.4.1.2 MS initiated GPRS detach procedure completion for GPRS services only

When the DETACH REQUEST message is received by the network, the network shall send a DETACH ACCEPT message to the MS, if the detach type IE value indicates that the detach request has not been sent due to switching off. If switching off was indicated, the procedure is completed when the network receives the DETACH REQUEST message. The network and the MS shall deactivate the PDP contexts and deactivate the logical link(s), if any.

The MS is marked as inactive in the network for GPRS services; state GMM-DEREGISTERED is entered in the MS and the network.

NOTE: When the DETACH REQUEST message is received by the network, and if the detach type IE value indicates that the detach is not due to power off, the authentication and ciphering procedure as well as the identification procedure may be performed.

#### 4.7.4.1.3 MS initiated combined GPRS detach procedure completion

When the DETACH REQUEST message is received by the network, a DETACH ACCEPT message shall be sent to the MS, if the detach type IE value indicates that the detach request has not been sent due to switching off. Depending on the value of the detach type IE the following applies:

- GPRS/IMSI detach:

The MS is marked as inactive in the network for GPRS and for non-GPRS services. The network and the MS shall deactivate the PDP contexts and deactivate the logical link(s), if any. The States GMM-DEREGISTERED and MM NULL are entered in both the MS and the network.

- IMSI detach:

The MS is marked as inactive in the network for non-GPRS services. State MM NULL is entered in the MS and the network.

### 4.7.4.1.4 Abnormal cases in the MS

The following abnormal cases can be identified:

a) T3321 time-out

On the first expiry of the timer, the MS shall retransmit the DETACH REQUEST message and shall reset and restart timer T3321. This retransmission is repeated four times, i.e. on the fifth expiry of timer T3321, the GPRS detach procedure shall be aborted, the MS shall change to state:

- MM-NULL if "IMSI detach" was requested;
- GMM-REGISTERED.NORMAL-SERVICE if "IMSI Detach" was requested;
- GMM-DEREGISTERED if "GPRS detach" was requested;

- GMM-DEREGISTERED and MM-NULL if "GPRS/IMSI" detach was requested.
- b) Lower layer failure before reception of DETACH ACCEPT message

The detach procedure is aborted and the MS shall change to state:

- MM-NULL if "IMSI detach" was requested;
- GMM-REGISTERED.NORMAL-SERVICE if "IMSI Detach" was requested
- GMM-DEREGISTERED if "GPRS detach" was requested;
- GMM-DEREGISTERED and MM-NULL if "IMSI/GPRS" detach was requested.
- c) Detach procedure collision

If the MS receives a DETACH REQUEST message before the MS initiated GPRS detach procedure has been completed, a DETACH ACCEPT message shall be sent to the network.

d) Detach and GMM common procedure collision

GPRS detach containing cause "power off":

- If the MS receives a message used in a GMM common procedure before the GPRS detach procedure has been completed, this message shall be ignored and the GPRS detach procedure shall continue.

GPRS detach containing other causes than "power off":

- If the MS receives a P-TMSI REALLOCATION COMMAND, a GMM STATUS, or a GMM INFORMATION message before the GPRS detach procedure has been completed, this message shall be ignored and the GPRS detach procedure shall continue.
- If the MS receives an AUTHENTICATION AND CIPHERING REQUEST or IDENTITY REQUEST message, before the GPRS detach procedure has been completed, the MS shall respond to it as described in sub-clause 4.7.7 and 4.7.8 respectively.
- e) Change of cell within the same RA

If a cell change occurs within the same RA before a DETACH ACCEPT message has been received, then the cell update procedure shall be performed before completion of the detach procedure.

f) Change of cell into a new routing area

If a cell change into a new routing area occurs before a DETACH ACCEPT message has been received, the GPRS detach procedure shall be aborted and re-initiated after successfully performing a routing area updating procedure.

Start T3321 DETACH REQUEST DETACH ACCEPT		MS	Network
Stop T3321 DETACH ACCEPT	Start T3321	DETACH REQUEST	
	Stop T3321	DETACH ACCEPT	
DETACH REQUEST		-	

Figure 4.7.4/1 3GPP TS 04.08: MS initiated GPRS detach procedure

## 4.7.4.2 Network initiated GPRS detach procedure

#### 4.7.4.2.1 Network initiated GPRS detach procedure initiation

The network initiates the GPRS detach procedure by sending a DETACH REQUEST message to the MS. The DETACH REQUEST message shall include a detach type IE. In addition, the network may include a cause IE to specify the reason for the detach request. The network shall start timer T3322. If the detach type IE indicates "re-attach not required" or "re-attach required", the network shall deactivate the PDP contexts and deactivate the logical link(s), if any, and shall change to state GMM-DEREGISTERED-INITIATED.

#### 4.7.4.2.2 Network initiated GPRS detach procedure completion by the MS

When receiving the DETACH REQUEST message and the detach type IE indicates "re-attach required", the MS shall deactivate the PDP contexts and deactivate the logical link(s), if any. The MS shall then send a DETACH ACCEPT message to the network and shall change state to GMM-DEREGISTERED. The MS shall, after the completion of the GPRS detach procedure, initiate a GPRS attach procedure. The MS should also activate PDP context(s) to replace any previously active PDP contexts.

NOTE: In some cases, user interaction may be required and then the MS cannot activate the PDP context(s) automatically.

A GPRS MS operating in MS operation mode A or B in network operation mode I, which receives an DETACH REQUEST message with detach type indicating "re-attach required" or "re-attach not required" and no cause code, is only detached for GPRS services in the network.

When receiving the DETACH REQUEST message and the detach type IE indicates "IMSI detach", the MS shall not deactivate the PDP contexts. A MS in operation mode A or B in network operation mode I may send a DETACH ACCEPT message to the network, and shall re-attach to non-GPRS service by performing the combined routing area updating procedure, sending a ROUTING AREA UPDATE REQUEST message with Update type IE indicating "combined RA/LA updating with IMSI attach". An MS in operation mode C, or in MS operation mode A or B in network operation mode II or III, shall send a DETACH ACCEPT message to the network.

If the detach type IE indicates "IMSI detach" or "re-attach required", then the MS shall ignore the cause code if received.

If the detach type information element value indicates "re-attach required" or "re-attach not required" and the MS is attached for GPRS and non-GPRS services and the network operates in network operation mode I, then if in the MS the timer T3212 is not already running, the timer T3212 shall be set to its initial value and restarted.

When receiving the DETACH REQUEST message and the detach type IE indicates "re-attach not required" and the cause code is not "#2 (IMSI unknown in HLR)", the MS shall deactivate the PDP contexts and deactivate the logical link(s), if any. The MS shall then send a DETACH ACCEPT message to the network and shall change state to GMM-DEREGISTERED.

If the detach type IE indicates "re-attach not required", then, depending on the received cause code, the MS shall act as follows:

# 2 (IMSI unknown in HLR);

The MS shall set the update status to U3 ROAMING NOT ALLOWED and shall delete any TMSI, LAI and ciphering key sequence number. The new MM state is MM IDLE. The SIM shall be considered as invalid for non-GPRS services until switching off or the SIM is removed.

A GPRS MS operating in MS operation mode A or B in network operation mode I, is still IMSI attached for GPRS services in the network.

- # 3 (Illegal MS);
- # 6 (Illegal ME);

The MS shall set the GPRS update status to GU3 ROAMING NOT ALLOWED (and shall store it according to sub-clause 4.1.3.2) and shall delete any P-TMSI, P-TMSI signature, RAI and GPRS ciphering key sequence number. The new GMM state is GMM-DEREGISTERED. The SIM shall be considered as invalid for GPRS services until switching off or the SIM is removed.

A GPRS MS operating in MS operation mode A or B shall in addition set the update status to U3 ROAMING NOT ALLOWED, shall delete any TMSI, LAI and ciphering key sequence number. The new MM state is MM idle. The SIM shall be considered as invalid also for non-GPRS services until switching off or the SIM is removed.

# 7 (GPRS services not allowed);

The MS shall set the GPRS update status to GU3 ROAMING NOT ALLOWED (and shall store it according to sub-clause 4.1.3.2) and shall delete any P-TMSI, P-TMSI signature, RAI and GPRS ciphering key sequence number. The SIM shall be considered as invalid for GPRS services until switching off or the SIM is removed. The new state is GMM-DEREGISTERED.

A GPRS MS operating in MS operation mode A or B in network operation mode I shall set the timer T3212 to its initial value and restart it, if it is not already running.

A GPRS MS operating in MS operation mode A or B in network operation mode I, is still IMSI attached for CS services in the network.

#8 (GPRS services and non-GPRS services not allowed)

The MS shall set the GPRS update status to GU3 ROAMING NOT ALLOWED and the update status to U3 ROAMING NOT ALLOWED (and shall store it according to sub-clause 4.1.3.2). Furthermore, it shall delete any P-TMSI, P-TMSI signature, TMSI, RAI, LAI, ciphering key sequence number and GPRS ciphering key sequence number and shall consider the SIM as invalid for GPRS and non-GPRS services until switching off or the SIM is removed.

- #11 (PLMN not allowed);
- # 12 (Location area not allowed); or
- #13 (Roaming not allowed in this location area)

The MS shall delete any RAI or LAI, P-TMSI, P-TMSI signature and GPRS ciphering key sequence number, shall set the GPRS update status to GU3 ROAMING NOT ALLOWED (and shall store it according to subclause 4.1.3.2).

A GPRS MS operating in MS operation mode A or B shall in addition set the update status to U3 ROAMING NOT ALLOWED and shall delete any TMSI, LAI and ciphering key sequence number. The new MM state is MM IDLE.

The MS shall store the LAI or the PLMN identity in the appropriate forbidden list, i.e. in the "forbidden PLMN list" for cause #11, in the list of "forbidden location areas for regional provision of service" for cause #12 or in the list of "forbidden location areas for roaming" for cause #13. If #11or #13 was received, the MS shall perform a PLMN selection instead of a cell selection.

# 14 (GPRS services not allowed in this PLMN)

The MS shall delete any RAI, P-TMSI, P-TMSI signature, and GPRS ciphering key sequence number stored, shall set the GPRS update status to GU3 ROAMING NOT ALLOWED (and shall store it according to subclause 4.1.3.2) and shall change to state GMM-DEREGISTERED.

The MS shall store the PLMN identity in the "forbidden PLMNs for GPRS service" list.

A GPRS MS operating in MS operation mode A or B in network operation mode I shall set the timer T3212 to its initial value and restart it, if it is not already running.

A GPRS MS operating in MS operation mode A or B, is still IMSI attached for CS services in the network.

Other cause values shall not impact the update status. Further actions of the MS are implementation dependent.

#### 4.7.4.2.3 Network initiated GPRS detach procedure completion by the network

The network shall, upon receipt of the DETACH ACCEPT message, stop timer T3322 and shall change state to GMM-DEREGISTERED.

#### 4.7.4.2.4 Abnormal cases on the network side

The following abnormal cases can be identified:

a) T3322 time-out

On the first expiry of the timer, the network shall retransmit the DETACH REQUEST message and shall start timer T3322. This retransmission is repeated four times, i.e. on the fifth expiry of timer T3322, the GPRS detach procedure shall be aborted and the network changes to state GMM-DEREGISTERED.

b) Low layer failure

The GPRS detach procedure is aborted and the network changes to state GMM-DEREGISTERED.

c) GPRS detach procedure collision

If the network receives a DETACH REQUEST message with "switching off" indicated, before the network initiated GPRS detach procedure has been completed, both procedures shall be considered completed.

If the network receives a DETACH REQUEST message without "switching off" indicated, before the network initiated GPRS detach procedure has been completed, the network shall send a DETACH ACCEPT message to the MS.

d) GPRS detach and GPRS attach procedure collision

If the network receives an ATTACH REQUEST message before the network initiated GPRS detach procedure has been completed, the network shall ignore the ATTACH REQUEST message, except when the detach type IE value, sent in the DETACH REQUEST message, indicated that the MS shall perform a GPRS attach procedure. In this case, the detach procedure is aborted and the GPRS attach procedure shall be progressed after the PDP contexts have been deleted.

e) GPRS detach and routing area updating procedure collision

GPRS detach containing detach type "re-attach required" or "re-attach not required" ":

If the network receives a ROUTING AREA UPDATE REQUEST message before the network initiated GPRS detach procedure has been completed, the detach procedure shall be progressed, i.e. the ROUTING AREA UPDATE REQUEST message shall be ignored.

GPRS detach containing detach type "IMSI detach":

If the network receives a ROUTING AREA UPDATE REQUEST message before the network initiated GPRS detach procedure has been completed, the network shall abort the detach procedure, shall stop T3322 and shall progress the routing area update procedure.

MS		Network	
←	DETACH REQUEST		Start T3322
	DETACH ACCEPT		Stop T3322

#### Figure 4.7.4/2 3GPP TS 04.08: Network initiated GPRS detach procedure

## 4.7.5 Routing area updating procedure

This procedure is used for:

- normal routing area updating to update the registration of the actual routing area of an MS in the network. This procedure is used by GPRS MSs in MS operation mode C and by GPRS MSs in MS operation modes A or B that are IMSI attached for GPRS and non-GPRS services if the network operates in network operation mode II or III;
- combined routing area updating to update the registration of the actual routing and location area of an MS in the network. This procedure is used by GPRS MSs in MS operation modes A or B that are IMSI attached for GPRS and non-GPRS services provided that the network operates in network operation mode I; or
- periodic routing area updating. This procedure is used by GPRS MSs in MS operation mode C and by GPRS MSs in MS operation modes A or B that are IMSI attached for GPRS or for GPRS and non-GPRS services independent of the network operation mode;
- IMSI attach for non-GPRS services when the MS is IMSI attached for GPRS services. This procedure is used by GPRS MSs in MS operation modes A or B, if the network operates in network operation mode I.
- resuming GPRS services when the RR sublayer indicated a resumption failure after dedicated mode was left, see sub-clause 3.4.13.1.1.
- updating the network with the new MS Radio Access Capability IE when the content of the IE has changed. Normal or combined routing area updating procedure is used.

Sub-clause 4.7.5.1 describes the routing area updating procedures for updating the routing area only. The combined routing area updating procedure used to update both the routing and location area is described in sub-clause 4.7.5.2.

The routing area updating procedure is always initiated by the MS. It is only invoked in state GMM-REGISTERED.

To limit the number of subsequently rejected routing area update attempts, a routing area updating attempt counter is introduced. The routing area updating attempt counter shall be incremented as specified in sub-clause 4.7.5.1.5. Depending on the value of the routing area updating attempt counter, specific actions shall be performed. The routing area updating attempt counter shall be reset when:

- a GPRS attach procedure is successfully completed; or
- a routing area updating procedure is successfully completed;

and additionally when the MS is in substate ATTEMPTING-TO-UPDATE:

- a new routing area is entered;
- expiry of timer T3302; or
- at request from registration function.

The mobile equipment shall contain a list of "forbidden location areas for roaming", as well as a list of "forbidden location areas for regional provision of service". The handling of these lists is described in sub-clause 4.4.1.

User data transmission in the MS shall be suspended during the routing area updating procedure; user data reception shall be possible. User data transmission in the network shall be suspended during the routing area updating procedure, if a new P-TMSI is assigned.

## 4.7.5.1 Normal and periodic routing area updating procedure

Periodic routing area updating is used to periodically notify the availability of the MS to the network. The value of the update type IE in the ROUTING AREA UPDATE REQUEST message shall indicate "periodic updating". The procedure is controlled in the MS by timer T3312. When timer T3312 expires, the periodic routing area updating procedure is started. Start and reset of timer T3312 is described in sub-clause 4.7.2.2.

The normal routing area updating procedure is initiated when the MS detects a change of the routing area in state GMM-REGISTERED or when the MS determines that GPRS resumption shall be performed or when the MS needs to update the network with the new MS Radio Access Capability IE. The ROUTING AREA UPDATE REQUEST message shall always be the first data sent by the MS when a routing area border is crossed. The routing area identification is broadcast on the broadcast channel(s). A normal routing area updating shall abort any ongoing GMM procedure. Aborted GMM procedures shall be repeated after the normal routing area updating procedure has been successfully performed. The value of the update type IE included in the message shall indicate "normal routing area updating".

#### 4.7.5.1.1 Normal and periodic routing area updating procedure initiation

To initiate the normal routing area updating procedure, the MS sends the message ROUTING AREA UPDATE REQUEST to the network, starts timer T3330 and changes to state GMM-ROUTING-AREA-UPDATING-INITIATED. The message ROUTING AREA UPDATE REQUEST shall contain the P-TMSI signature when received within a previous ATTACH ACCEPT or ROUTING AREA UPDATE ACCEPT message.

## 4.7.5.1.2 GMM Common procedure initiation

The network may initiate GMM common procedures, e.g. the GMM authentication and ciphering procedure.

#### 4.7.5.1.3 Normal and periodic routing area updating procedure accepted by the network

If the routing area updating request has been accepted by the network, a ROUTING AREA UPDATE ACCEPT message shall be sent to the MS. The network may assign a new P-TMSI and/or a new P-TMSI signature for the MS. If a new P-TMSI and/or P-TMSI signature have been assigned to the MS, it/they shall be included in the ROUTING AREA UPDATE ACCEPT message together with the routing area identification. The network shall change to state GMM-COMMON-PROCEDURE-INITIATED and shall start the supervision timer T3350 as described in sub-clause 4.7.6.

If the LAI or PLMN identity contained in the ROUTING AREA UPDATE ACCEPT message is a member of any of the "forbidden" lists then any such entry shall be deleted.

Upon receipt of a ROUTING AREA UPDATE ACCEPT message, the MS stores the received routing area identification, stops timer T3330, shall reset the routing area updating attempt counter and sets the GPRS update status to GU1 UPDATED. If the message contains a P-TMSI, the MS shall use this P-TMSI as new temporary identity for GPRS services and shall store the new P-TMSI. If no P-TMSI was included by the network in the ROUTING AREA UPDATING ACCEPT message, the old P-TMSI shall be kept. Furthermore, the MS shall store the P-TMSI signature if received in the ROUTING AREA UPDATING ACCEPT message. If no P-TMSI signature was included in the message, the old P-TMSI signature, if available, shall be deleted.

A ROUTING AREA UPDATE COMPLETE message shall be returned to the network if the ROUTING AREA UPDATE ACCEPT message contained:

- a P-TMSI; and/or
- Receive N-PDU Numbers (see 04.65 [78]).

In this case the Receive N-PDU Numbers values valid in the MS, shall be included in the ROUTING AREA UPDATE COMPLETE message.

# 4.7.5.1.4 Normal and periodic routing area updating procedure not accepted by the network

If the routing area updating cannot be accepted, the network sends a ROUTING AREA UPDATE REJECT message to the MS. An MS that receives a ROUTING AREA UPDATE REJECT message stops timer T3330. The MS shall then take different actions depending on the received reject cause value:

# 3 (Illegal MS);

#### #6 (Illegal ME);

The MS shall set the GPRS update status to GU3 ROAMING NOT ALLOWED (and shall store it according to sub-clause 4.1.3.2) and enter the state GMM-DEREGISTERED. Furthermore, it shall delete any P-TMSI, P-TMSI signature, RAI and GPRS ciphering key sequence number and shall consider the SIM as invalid for GPRS services until switching off or the SIM is removed.

If the MS is IMSI attached via MM procedures, the MS shall in addition set the update status to U3 ROAMING NOT ALLOWED, shall delete any TMSI, LAI and ciphering key sequence number. The new MM state is MM IDLE. The SIM shall be considered as invalid also for non-GPRS services until switching off or the SIM is removed.

# 7 (GPRS services not allowed);

The MS shall set the GPRS update status to GU3 ROAMING NOT ALLOWED (and shall store it according to sub-clause 4.1.3.2.9) and shall delete any P-TMSI, P-TMSI signature, RAI and GPRS ciphering key sequence number. The SIM shall be considered as invalid for GPRS services until switching off or the SIM is removed. The new state is GMM-DEREGISTERED.

If the update type is "periodic updating" a GPRS MS operating in MS operation mode A or B in networkoperation mode I shall set the timer T3212 to its initial value and restart it, if it is not already running.

#9 (MS identity cannot be derived by the network);

The MS shall set the GPRS update status to GU2 NOT UPDATED (and shall store it according to subclause 4.1.3.2), enter the state GMM-DEREGISTERED, and shall delete any P-TMSI, P-TMSI signature, RAI and GPRS ciphering key sequence number. Subsequently, the MS may automatically initiate the GPRS attach procedure.

# 10 (Implicitly detached);

The MS shall change to state GMM-DEREGISTERED.NORMAL-SERVICE. The MS shall then perform a new attach procedure. The MS should also activate PDP context(s) to replace any previously active PDP contexts.

- NOTE: In some cases, user interaction may be required and then the MS cannot activate the PDP context(s) automatically.
- #11 (PLMN not allowed);
- #12 (Location area not allowed);
- #13 (Roaming not allowed in this location area); or

The MS shall delete any RAI, P-TMSI, P-TMSI signature and GPRS ciphering key sequence number, shall set the GPRS update status to GU3 ROAMING NOT ALLOWED (and shall store it according to sub-clause 4.1.3.2) and enter the state GMM-DEREGISTERED.

If the MS is IMSI attached via MM procedures, the MS shall in addition set the update status to U3 ROAMING NOT ALLOWED shall delete any TMSI, LAI and ciphering key sequence number and shall reset the location update attempt counter. The new MM state is MM IDLE.

The MS shall store the LAI or the PLMN identity in the appropriate forbidden list, i.e. in the "forbidden PLMN list" for cause #11, in the list of "forbidden location areas for regional provision of service" for cause #12 or in the list of "forbidden location areas for roaming" for cause #13. If #11or #13 was received, the MS shall perform a PLMN selection instead of a cell selection.

# 14 (GPRS services not allowed in this PLMN)

The MS shall delete any RAI, P-TMSI, P-TMSI signature, and GPRS ciphering key sequence number stored, shall set the GPRS update status to GU3 ROAMING NOT ALLOWED (and shall store it according to subclause 4.1.3.2) and shall change to state GMM-DEREGISTERED.

The MS shall store the PLMN identity in the "forbidden PLMNs for GPRS service" list. A GPRS MS operating in MS operation mode C shall perform a PLMN selection instead of a cell selection.

If the update type is "periodic updating" a GPRS MS operating in MS operation mode A or B in network operation mode I shall set the timer T3212 to its initial value and restart it, if it is not already running.

A GPRS MS operating in MS operation mode A or B in network operation mode II or III, is still IMSI attached for CS services in the network.

Other values are considered as abnormal cases. The specification of the MS behaviour in those cases is described in sub-clause 4.7.5.1.5.

#### 4.7.5.1.5 Abnormal cases in the MS

The following abnormal cases can be identified:

a) Access barred because of access class control

The routing area updating procedure shall not be started. The MS stays in the current serving cell and applies the normal cell reselection process. The procedure is started as soon as possible and if still necessary, i.e. when the barred state is removed or because of a cell change.

b) Lower layer failure before the ROUTING AREA UPDATE ACCEPT or ROUTING AREA UPDATE REJECT message is received

The procedure shall be aborted. The MS shall proceed as described below.

c) T3330 time-out

The procedure is restarted four times, i.e. on the fifth expiry of timer T3330, the MS shall abort the procedure. The MS shall proceed as described below.

d) ROUTING AREA UPDATE REJECT, other causes than those treated in sub-clause 4.7.5.1.4

The MS shall proceed as described below.

- e) If a routing area border is crossed, when the MS is in state GMM-ROUTING-AREA-UPDATE-INITIATED, the routing area updating procedure shall be aborted and re-initiated immediately. The MS shall set the GPRS update status to GU2 NOT UPDATED.
- f) If a cell change occurs within the same RA, when the MS is in state GMM-ROUTING-AREA-UPDATE-INITIATED, the cell update procedure is performed, before completion of the routing area updating procedure.
- g) Routing area updating and detach procedure collision

GPRS detach containing detach type "re-attach required" or "re-attach not required":

If the MS receives a DETACH REQUEST message before the routing area updating procedure has been completed, the routing area updating procedure shall be aborted and the GPRS detach procedure shall be progressed.

GPRS detach containing detach type "IMSI detach":

If the MS receives a DETACH REQUEST message before the routing area updating procedure has been completed, the routing area updating procedure shall be progressed, i.e. the DETACH REQUEST message shall be ignored.

h) Routing area updating and P-TMSI reallocation procedure collision

If the MS receives a P-TMSI REALLOCATION REQUEST message before the routing area updating procedure has been completed, the P-TMSI reallocation procedure shall be aborted and the routing area updating procedure shall be progressed.

In cases b, c and d the MS shall proceed as follows:

Timer T3330 shall be stopped if still running. The routing area updating attempt counter shall be incremented.

If the routing area updating attempt counter is less than 5, and the stored RAI is equal to the RAI of the current serving cell and the GMM update status is equal to GU1 UPDATED:

- the MS shall keep the GMM update status to GU1 UPDATED and changes state to GMM-REGISTERED.NORMAL-SERVICE. The MS shall start timer T3311. When timer T3311 expires the routing area updating procedure is triggered again.

If the routing area updating attempt counter is less than 5, and the stored RAI is different to the RAI of the current serving cell or the GMM update status is different to GU1 UPDATED:

- the MS shall start timer T3311, shall set the GPRS update status to GU2 NOT UPDATED and changes state to GMM-REGISTERED.ATTEMPTING-TO-UPDATE.

If the routing area updating attempt counter is greater than or equal to 5:

 the MS shall start timer T3302, shall set the GPRS update status to GU2 NOT UPDATED and shall change to state GMM-REGISTERED.ATTEMPTING-TO-UPDATE or optionally to GMM-REGISTERED.PLMN-SEARCH(see sub-clause 4.2.4.1.2).

#### 4.7.5.1.6 Abnormal cases on the network side

The following abnormal cases can be identified:

- a) If a lower layer failure occurs before the message ROUTING AREA UPDATE COMPLETE has been received from the MS and a P-TMSI and/or PTMSI signature has been assigned, the network shall abort the procedure and shall consider both, the old and new P-TMSI and the corresponding P-TMSI signatures as valid until the old P-TMSI can be considered as invalid by the network (see sub-clause 4.7.1.5). During this period the network may:
  - use the identification procedure followed by a P-TMSI reallocation procedure if the old P-TMSI is used by the MS in a subsequent message.NOTE: Optionally, paging with IMSI may be used if paging with old and new P-TMSI fails. Paging with IMSI causes the MS to re-attach as described in sub-clause 4.7.9.1.
- b) Protocol error

If the ROUTING AREA UPDATE REQUEST message has been received with a protocol error, the network shall return a ROUTING AREA UPDATE REJECT message with one of the following reject causes:

- #96: Mandatory information element error;
- #99: Information element non-existent or not implemented;
- #100: Conditional IE error;
- #111: Protocol error, unspecified.
- c) T3350 time-out

On the first expiry of the timer, the network shall retransmit the ROUTING AREA UPDATE ACCEPT message and shall reset and restart timer T3350. The retransmission is performed four times, i.e. on the fifth expiry of timer T3350, the routing area updating procedure is aborted. Both, the old and the new P-TMSI and the corresponding P-TMSI signatures shall be considered as valid until the old P-TMSI can be considered as invalid by the network(see sub-clause 4.7.1.5). During this period the network acts as described for case a above.




Figure 4.7.5/1 3GPP TS 04.08: Routing and combined routing area updating procedure

## 4.7.5.2 Combined routing area updating procedure

Within a combined routing area updating procedure the messages ROUTING AREA UPDATE ACCEPT and ROUTING AREA UPDATE COMPLETE carry information for the routing area updating and the location area updating.

## 4.7.5.2.1 Combined routing area updating procedure initiation

The combined routing area updating procedure is initiated only by a GPRS MS operating in MS operation modes A or B, if the MS is in state GMM-REGISTERED and if the network operates in network operation mode I:

- when a GPRS MS that is IMSI attached for GPRS and non-GPRS services detects a change of the routing area in state GMM-REGISTERED and MM-IDLE;
- when a GPRS MS that is IMSI attached for GPRS services wants to perform an IMSI attach for non-GPRS services;
- after termination of a non-GPRS service via non-GPRS channels to update the association if the MS has changed the LA during that non-GPRS service transaction;
- after termination of non-GPRS service via non-GPRS channels to update the association if GPRS services were suspended during the non-GPRS service but no resume is received. See 3GPP TS 03.60 subsub-clause 16.2.1;
- after a CM SERVICE REJECT message with cause value #4 is received by the mobile station (see subclause 4.5.1.1), in which case the update type IE shall be set to "Combined RA/LA updating with IMSI attach"; or
- when a GPRS MS needs to update the network with the new MS Radio Access Capability IE.

The routing and location area identification are broadcast on the broadcast channel(s). A combined routing area updating procedure shall abort any ongoing GMM procedure. Aborted GMM procedures shall be repeated after the combined routing area updating procedure has been successfully performed. The ROUTING AREA UPDATE REQUEST message shall always be the first message sent from the MS in the new routing area after routing area change.

To initiate a combined routing area updating procedure the MS sends the message ROUTING AREA UPDATE REQUEST to the network, starts timer T3330 and changes to state GMM-ROUTING-UPDATING-INITIATED and MM LOCATION UPDATING PENDING. The value of the update type IE in the message shall indicate "combined RA/LA updating". If for the last attempt to update the registration of the location area a MM specific procedure was performed, the value of the update type IE in the ROUTING AREA UPDATE REQUEST message shall indicate "combined RA/LA updating with IMSI attach". Furthermore the MS shall include the TMSI status IE if no valid TMSI is available.

A GPRS MS in MS operation modes A or B that is in an ongoing circuit-switched transaction, shall initiate the combined routing area updating procedure after the circuit-switched transaction has been released, if the MS has changed the RA during the circuit-switched transaction and if the network operates in network operation mode I.

A GPRS MS in MS operation mode A shall initiate the combined routing area updating procedure with IMSI attach after the circuit-switched transaction has been released if a GPRS attach was performed during the circuit-switched transaction and provided that the network operates in network operation mode I.

A GPRS MS in MS operation mode A shall perform the normal routing area update procedure during an ongoing circuit-switched transaction.

#### 4.7.5.2.2 GMM Common procedure initiation

The network may initiate GMM common procedures, e.g. the GMM authentication and ciphering procedure.

#### 4.7.5.2.3 Combined routing area updating procedure accepted by the network

Depending on the value of the update result IE received in the ROUTING AREA UPDATE ACCEPT message, two different cases can be distinguished:

- Case 1) The update result IE value indicates "combined RA/LA": Routing and location area updating is successful;
- Case 2) The update result IE value indicates "RA only": Routing area updating is successful, but location area updating is not successful.

A ROUTING AREA UPDATE COMPLETE message shall be returned to the network if the ROUTING AREA UPDATE ACCEPT message contains:

- a P-TMSI and/or a TMSI; and/or
- Receive N-PDU Numbers (see 04.65 [78]).

In the latter case, the Receive N-PDU Numbers that are valid in the MS shall be included in the ROUTING AREA UPDATE COMPLETE message.

#### 4.7.5.2.3.1 Combined routing area updating successful

The description for normal routing area update as specified in sub-clause 4.7.5.1.3 shall be followed. In addition, the following description for location area updating applies.

The handling at the receipt of the ROUTING AREA UPDATE ACCEPT depends on the value received in the update result IE as specified below.

The TMSI reallocation may be part of the combined routing area updating procedure. The TMSI allocated is then included in the ROUTING AREA UPDATE ACCEPT message together with the location area identification (LAI). The network shall, in this case, change to state GMM-COMMON-PROCEDURE-INITIATED and shall start the timer T3350 as described in sub-clause 4.7.6.

The MS, receiving a ROUTING AREA UPDATE ACCEPT message, stores the received location area identification, stops timer T3330, enters state MM IDLE, reset the location update attempt counter and sets the update status to U1 UPDATED. If the ROUTING AREA UPDATE ACCEPT message contains an IMSI, the mobile station is not allocated any TMSI, and shall delete any TMSI accordingly. If the ROUTING AREA UPDATE ACCEPT message contains a TMSI, the MS shall use this TMSI as new temporary identity. The MS shall delete its old TMSI and shall store the new TMSI. In this case, a ROUTING AREA UPDATE COMPLETE message is returned to the network. If neither a TMSI nor an IMSI has been included by the network in the ROUTING AREA UPDATE ACCEPT message, the old TMSI, if any is available, shall be kept.

Any timer used for triggering the location updating procedure (e.g. T3211, T3212) shall be stopped if running.

The network receiving a ROUTING AREA UPDATE COMPLETE message stops timer T3350, changes to GMM-REGISTERED state and considers the new TMSI as valid.

#### 4.7.5.2.3.2 Combined routing are updating successful for GPRS services only

The description for normal routing area update as specified in sub-clause 4.7.5.1.3 shall be followed. In addition, the following description for location area updating applies.

The MS receiving the ROUTING AREA UPDATE ACCEPT message takes one of the following actions depending on the reject cause:

# 2 (IMSI unknown in HLR)

The MS shall set the update status to U3 ROAMING NOT ALLOWED and shall delete any TMSI, LAI and ciphering key sequence number. The new MM state is MM IDLE. The SIM shall be considered as invalid for non-GPRS services until switching off or the SIM is removed.

- #16 (MSC temporarily not reachable);
- #17 (Network failure); or
- #22 (Congestion)

The MS shall change to state GMM-REGISTERED.ATTEMPTING-TO-UPDATE-MM. Timer T3330 shall be stopped if still running. The routing area updating attempt counter shall be incremented. If the routing area updating attempt counter is less than 5, and the stored RAI is equal to the RAI of the current serving cell and the GMM update status is equal to GU1 UPDATED:

The MS shall keep the GMM update status GU1 UPDATED and changes state to GMM-REGISTERED.ATTEMPTING-TO-UPDATE-MM. The MS shall start timer T3311. When timer T3311 expires the combined routing area update procedure indicating "combined RA/LA updating with IMSI attach" is triggered again.

If the routing area updating attempt counter is greater than or equal to 5:

- the MS shall start timer T3302 and shall change to state GMM-REGISTERED.ATTEMPTING-TO-UPDATE-MM;
- a GPRS MS operating in MS operation mode A shall then proceed with appropriate MM specific procedure; a GPRS MS operating in MS operation mode B may then proceed with appropriate MM specific procedures. The MM sublayer shall act as in network operation mode II as long as the combined GMM procedures are not successful and no new RA is entered. The new MM state is IDLE.

Other values are considered as abnormal cases. The combined routing area updating shall be considered as failed for GPRS and non-GPRS services. The specification of the MS behaviour in those cases is specified in sub-clause 4.7.5.2.5.

#### 4.7.5.2.4 Combined routing area updating not accepted by the network

If the combined routing area updating cannot be accepted, the network sends a ROUTING AREA UPDATE REJECT message to the MS. An MS that receives a ROUTING AREA UPDATE REJECT message stops timer T3330 and enters state MM IDLE. The MS shall then take different actions depending on the received reject cause:

# 3 (Illegal MS);

- #6 (Illegal ME);
- # 8 (GPRS services and non GPRS services not allowed);

The MS shall set the GPRS update status to GU3 ROAMING NOT ALLOWED and the update status to U3 ROAMING NOT ALLOWED (and shall store it according to sub-clause 4.1.3.2) and enter the state GMM-DEREGISTERED. Furthermore, it shall delete any P-TMSI, P-TMSI signature, TMSI, RAI, LAI, ciphering key sequence number and GPRS ciphering key sequence number and shall consider the SIM as invalid for GPRS and non GPRS services until switching off or the SIM is removed.

#7 (GPRS services not allowed);

The MS shall set the GPRS update status to GU3 ROAMING NOT ALLOWED (and shall store it according to sub-clause 4.1.3.2) and shall delete any P-TMSI, P-TMSI signature, RAI and GPRS ciphering key sequence number. The SIM shall be considered as invalid for GPRS services until switching off or the SIM is removed. The new state is GMM-DEREGISTERED. If in the MS the timer T3212 is not already running, the timer shall be set to its initial value and restarted.

A GPRS MS operating in MS operation mode A or B in network operation mode I, is still IMSI attached for CS services in the network and shall then proceed with the appropriate MM specific procedure according to the MM service state.

#9 (MS identity cannot be derived by the network);

The MS shall set the GPRS update status to GU2 NOT UPDATED (and shall store it according to sub-clause 4.1.3.2), enter the state GMM-DEREGISTERED, and shall delete any P-TMSI, P-TMSI signature, RAI and GPRS ciphering key sequence number. Subsequently, the MS may automatically initiate the GPRS attach procedure.

A GPRS MS operating in MS operation mode A or B in network operation mode I, is still IMSI attached for CS services in the network.

#10 (Implicitly detached);

A GPRS MS operating in MS operation mode A or B in network operation mode I, is IMSI detached for both GPRS and CS services in the network.

The MS shall change to state GMM-DEREGISTERED.NORMAL-SERVICE. The MS shall then perform a new attach procedure. The MS should also activate PDP context(s) to replace any previously active PDP contexts.

- NOTE: In some cases, user interaction may be required and then the MS cannot activate the PDP context(s) automatically.
- #11 (PLMN not allowed);
- #12 (Location area not allowed);
- #13 (Roaming not allowed in this location area); or

The MS shall set the GPRS update status to GU3 ROAMING NOT ALLOWED and the update status to U3 ROAMING NOT ALLOWED (and shall store it according to sub-clause 4.1.3.2) and enter the state GMM-DEREGISTERED. Furthermore, it shall delete any P-TMSI, P-TMSI signature, TMSI, RAI, LAI, ciphering key sequence number GPRS ciphering key sequence number and reset the location update attempt counter.

The MS shall store the LAI or the PLMN identity in the appropriate forbidden list, i.e. in the "forbidden PLMN list" for cause #11, in the list of "forbidden location areas for regional provision of service" for cause #12 or in the list of "forbidden location areas for roaming" for cause #13. If #11 or #13 was received, the MS shall then perform a PLMN selection instead of a cell selection.

# 14 (GPRS services not allowed in this PLMN)

The MS shall delete any RAI, P-TMSI, P-TMSI signature, and GPRS ciphering key sequence number stored, shall set the GPRS update status to GU3 ROAMING NOT ALLOWED (and shall store it according to subclause 4.1.3.2) and shall change to state GMM-DEREGISTERED. If in the MS the timer T3212 is not already running, the timer shall be set to its initial value and restarted. The MS shall store the PLMN identity in the "forbidden PLMNs for GPRS service" list.

A GPRS MS operating in MS operation mode A or B in network operation mode I, is still IMSI attached for CS services in the network and shall then proceed with the appropriate MM specific procedure according to the MM service state.

Other values are considered as abnormal cases. The specification of the MS behaviour in those cases is described in sub-clause 4.7.5.2.5.

#### 4.7.5.2.5 Abnormal cases in the MS

The abnormal cases specified in sub-clause 4.7.5.1.5 apply with the following modification:

If the GPRS routing area updating counter is less than 5, the MM state remains MM LOCATION UPDATING PENDING.

If the GPRS routing area updating attempt counter is incremented according to sub-clause 4.7.5.1.5 the next actions depend on the Location Area Identities (stored on SIM and the one of the current serving cell) and the value of the routing area updating attempt counter.

- if the update status is U1 UPDATED, and the stored LAI is equal to the one of the current serving cell and the routing area updating attempt counter is smaller than 5, then the mobile station shall keep the update status to U1 UPDATED, the new MM state is MM IDLE substate NORMAL SERVICE; or
- if the update status is different from U1 UPDATED, or the stored LAI is different from the one of the current serving cell, or the routing area updating attempt counter is greater or equal to 5, the mobile station shall delete any LAI, TMSI, ciphering key sequence number stored in the SIM and set the update status to U2 NOT UPDATED. The new MM state is MM IDLE substate ATTEMPTING TO UPDATE.

### 4.7.5.2.6 Abnormal cases on the network side

The abnormal cases specified in sub-clause 4.7.5.1.6 apply with the exceptions for cases a and c in which in addition to the P-TMSI and P-TMSI signature the old TMSI shall be considered occupied until the new TMSI is used by the MS in a subsequent message.

## 4.7.6 P-TMSI reallocation procedure

A temporary mobile station identity for GPRS services, the Packet-TMSI (P-TMSI), is used for identification within the radio interface signalling procedures. The structure of the P-TMSI is specified in 3GPP TS 03.03 [10]. The P-TMSI has significance only within a routing area. Outside the routing area it has to be combined with the routing area identification (RAI) to provide for an unambiguous identity.

The purpose of the P-TMSI reallocation procedure is to provide identity confidentiality, i.e. to protect a user against being identified and located by an intruder (see 3GPP TS 02.09 [5] and 03.20 [34]).

Usually, P-TMSI reallocation is performed at least at each change of a routing area. (Such choices are left to the network operator).

The reallocation of a P-TMSI is performed by the unique procedure defined in this sub-clause. This procedure can only be initiated by the network in state GMM-REGISTERED.

P-TMSI can also be implicitly reallocated in the attach or routing area updating procedures. The implicit reallocation of a P-TMSI is described in the corresponding sub-clauses.

NOTE: Normally, the P-TMSI reallocation will take place in conjunction with another GMM procedure, e.g. at routing area updating (see 3GPP TS 09.02 [37]).

#### 4.7.6.1 P-TMSI reallocation initiation by the network

The network initiates the P-TMSI reallocation procedure by sending a P-TMSI REALLOCATION COMMAND message to the MS and starts the timer T3350.

The P-TMSI REALLOCATION COMMAND message contains a new combination of P-TMSI, RAI and optionally a P-TMSI signature allocated by the network.

The network shall not send any user data during the P-TMSI reallocation procedure.

## 4.7.6.2 P-TMSI reallocation completion by the MS

Upon receipt of the P-TMSI REALLOCATION COMMAND message, the MS stores the Routing Area Identifier (RAI) and the P-TMSI and sends a P-TMSI REALLOCATION COMPLETE message to the network.

If a P-TMSI signature is present in the P-TMSI REALLOCATION COMMAND message, the MS shall store the new P-TMSI signature and shall if available delete the old P-TMSI signature. If no P-TMSI signature is present in the P-TMSI REALLOCATION COMMAND message, the old P-TMSI signature, if available, shall be kept.

## 4.7.6.3 P-TMSI reallocation completion by the network

Upon receipt of the P-TMSI REALLOCATION COMPLETE message, the network stops the timer T3350 and considers both the old and the new P-TMSI and the corresponding P-TMSI signatures as valid until the old P-TMSI can be considered as invalid by the network (see sub-clause 4.7.1.5).

The GMM layer shall notify the LLC layer that the P-TMSI has been changed (see 3GPP TS 04.64 [76]).

## 4.7.6.4 Abnormal cases on the network side

The following abnormal cases can be identified:

a) Lower layer failure

If a lower layer failure is detected before the P-TMSI REALLOCATION COMPLETE message is received, the old and the new P-TMSI shall be considered as occupied until the old P-TMSI can be considered as invalid by the network (see sub-clause 4.7.1.5).

During this period the network:

may first use the old P-TMSI for paging for an implementation dependent number of paging attempts in the case of network originated transactions. Upon response from the MS, the network may re-initiate the P-TMSI reallocation. If no response is received to the paging attempts, the network may use the new P-TMSI for paging for an implementation dependent number of paging attempts. Upon response from the MS the network shall consider the new P-TMSI as valid and the old P-TMSI as invalid. If no response is received to the paging attempts, the network may use the IMSI for paging attempts, the network may use the IMSI for paging attempts;

NOTE: Paging with IMSI causes the MS to re-attach as described in sub-clause 4.7.9.1.

shall consider the new P-TMSI as valid if it is used by the MS (see sub-clause 4.7.1.5); or

may use the identification procedure followed by a new P-TMSI reallocation if the MS uses the old P-TMSI.

b) Expiry of timer T3350

The P-TMSI reallocation procedure is supervised by the timer T3350. The network shall, on the first expiry of timer T3350, reset and restart timer T3350 and shall retransmit the P-TMSI REALLOCATION COMMAND. This retransmission is repeated four times, i.e. on the fifth expiry of timer T3350, the network shall abort the reallocation procedure and shall follow the rules for case a as described above.

c) P-TMSI reallocation and GPRS attach procedure collision

If the network receives an ATTACH REQUEST message before the ongoing P-TMSI reallocation procedure has been completed the network shall proceed with the GPRS attach procedure after deletion of the GMM context.

d) P-TMSI reallocation and an MS initiated GPRS detach procedure collision

If the network receives a DETACH REQUEST message before the ongoing P-TMSI reallocation procedure has been completed, the network shall abort the P-TMSI reallocation procedure and shall progress the GPRS detach procedure.

e) P-TMSI reallocation and a routing area updating procedure collision

If the network receives a ROUTING AREA UPDATE REQUEST message before the ongoing P-TMSI reallocation procedure has been completed, the network shall abort the P-TMSI reallocation procedure and shall progress the routing area updating procedure. The network may then perform a new P-TMSI reallocation.

If there are different new P-TMSI included in subsequent P-TMSI REALLOCATION COMMAND messages, due to an aborted or repeated P-TMSI reallocation procedure, the MS always regards the newest and its existing P-TMSI as valid for the recovery time.




Figure 4.7.6/1 3GPP TS 04.08: P-TMSI reallocation procedure

## 4.7.7 Authentication and ciphering procedure

The purpose of the authentication and ciphering procedure is threefold:

- to permit the network to check whether the identity provided by the MS is acceptable or not, see 3GPP TS 03.20 [13]);
- to provide parameters enabling the MS to calculate a new GPRS ciphering key; and
- to let the network set the ciphering mode (ciphering/no ciphering) and algorithm.

The authentication and ciphering procedure can be used for either:

- authentication only;
- setting of the ciphering mode and the ciphering algorithm only; or
- authentication and the setting of the ciphering mode and the ciphering algorithm.

The cases in which the authentication and ciphering procedure shall be used are defined in 3GPP TS 02.09 [5].

The authentication and ciphering procedure is always initiated and controlled by the network. It shall be performed in a non ciphered mode because of the following reasons:

- the network cannot decipher a ciphered AUTHENTICATION AND CIPHERING RESPONSE from an unauthorised MS and put it on the black list; and
- to be able to define a specific point in time from which on a new GPRS ciphering key should be used instead of the old one.

The network should not send any user data during the authentication and ciphering procedure.

## 4.7.7.1 Authentication and ciphering initiation by the network

The network initiates the authentication and ciphering procedure by transferring an AUTHENTICATION AND CIPHERING REQUEST message across the radio interface and starts timer T3360. The AUTHENTICATION AND CIPHERING REQUEST message shall contain all parameters necessary to calculate the response parameters when authentication is performed (see 3GPP TS 03.20 [13]).

If authentication is requested, then the AUTHENTICATION AND CIPHERING REQUEST message shall contain the GPRS ciphering key sequence number, allocated to the GPRS ciphering key and the RAND. If authentication is not requested, then the AUTHENTICATION AND CIPHERING REQUEST message shall contain neither the GPRS ciphering key sequence number nor the RAND.

If ciphering is requested, then the AUTHENTICATION AND CIPHERING REQUEST message shall indicate the GPRS ciphering algorithm.

The network includes the A&C reference number information element in the AUTHENTICATION AND CIPHERING REQUEST message. Its value is chosen in order to link an AUTHENTICATION AND CIPHERING REQUEST in a RA with its RESPONSE. The A&C reference number value might be based on the RA Colour Code value.

Additionally, the network may request the MS to include its IMEISV in the AUTHENTICATION AND CIPHERING RESPONSE message.

## 4.7.7.2 Authentication and ciphering response by the MS

An MS that is attached to GPRS shall be ready to respond upon an AUTHENTICATION AND CIPHERING REQUEST message at any time. If the AUTHENTICATION AND CIPHERING REQUEST message includes the authentication parameters RAND and GPRS CKSN, then upon receipt of the message, the MS processes the challenge information and sends an AUTHENTICATION AND CIPHERING RESPONSE message to the network. The value of the received A&C reference number information element shall be copied into the A&C reference number information element shall be copied into the A&C reference number information element shall be copied into the A&C reference number information element shall be copied into the A&C reference number information element shall be copied into the A&C reference number information element shall be copied into the A&C reference number information element shall be copied into the A&C reference number information element shall be copied into the A&C reference number information element shall be copied into the A&C reference number information element in the AUTHENTICATION AND CIPHERING RESPONSE message. The new GPRS ciphering key calculated from the challenge information shall overwrite the previous one. It shall be stored and shall be loaded into the ME before the AUTHENTICATION AND CIPHERING RESPONSE message is transmitted. The GPRS ciphering key sequence number shall be stored together with the calculated key.

If the AUTHENTICATION AND CIPHERING REQUEST message does not include the authentication parameters RAND and GPRS CKSN, then upon receipt of the message, the MS replies by sending an AUTHENTICATION AND CIPHERING RESPONSE message to the network.

The GMM layer shall notify the LLC layer if ciphering shall be used or not and if yes which algorithm and GPRS ciphering key that shall be used (see 3GPP TS 04.64 [76]).

## 4.7.7.3 Authentication and ciphering completion by the network

Upon receipt of the AUTHENTICATION AND CIPHERING RESPONSE message, the network stops the timer T3360 and checks the validity of the response (see 3GPP TS 03.20 [13]). For this, it may use the A&C reference number information element within the AUTHENTICATION AND CIPHERING RESPONSE message to determine whether the response is correlating to the last request that was sent.

The GMM layer shall notify the LLC sublayer if ciphering shall be used or not and if yes which algorithm and GPRS ciphering key that shall be used (see 3GPP TS 04.64 [76]).

## 4.7.7.4 GPRS ciphering key sequence number

The security parameters for authentication and ciphering are tied together in sets, i.e. from a challenge parameter RAND both the authentication response SRES and the GPRS ciphering key can be computed given the secret key associated to the IMSI.

In order to allow start of ciphering on a logical link without authentication, GPRS ciphering key sequence numbers are introduced. The sequence number is managed by the network such that the AUTHENTICATION AND CIPHERING REQUEST message contains the sequence number allocated to the key which may be computed from the RAND parameter carried in that message.

The MS stores this number with the key, and includes the corresponding sequence number in the ROUTING AREA UPDATE REQUEST and ATTACH REQUEST messages. If the sequence number is deleted, the associated key shall be considered as invalid.

The network may choose to start ciphering with the stored key (under the restrictions given in 3GPP TS 02.09) if the stored sequence number and the one given from the MS are equal and the previously negotiated ciphering algorithm is known and supported in the network. When ciphering is requested at GPRS attach, the authentication and ciphering procedure shall be performed since the MS does not store the ciphering algorithm at detach.

Upon GPRS attach, if ciphering is to be used, an AUTHENTICATION AND CIPHERING REQUEST message shall be sent to the MS to start ciphering.

If the GPRS ciphering key sequence number stored in the network does not match the GPRS ciphering key sequence number received from the MS in the ATTACH REQUEST message, then the network should authenticate the MS.

The MS starts ciphering after sending the AUTHENTICATION AND CIPHERING RESPONSE message. The SGSN starts ciphering when a valid AUTHENTICATION AND CIPHERING RESPONSE is received from the MS.

As an option, the network may decide to continue ciphering without sending an AUTHENTICATION AND CIPHERING REQUEST message after receiving a ROUTING AREA UPDATE REQUEST message with a valid GPRS ciphering key sequence number. Both the MS and the network shall use the latest ciphering parameters. The SGSN starts ciphering when sending the ciphered ROUTING AREA UPDATE ACCEPT message to the MS. The MS starts ciphering after receiving a valid ciphered ROUTING AREA UPDATE ACCEPT message from the network.

## 4.7.7.5 Unsuccessful authentication and ciphering

If authentication and ciphering fails, i.e. if the response is not valid, the network considers whether the MS has used the P-TMSI or the IMSI for identification.

- If the P-TMSI has been used, the network may decide to initiate the identification procedure. If the IMSI given by the MS differs from the one the network had associated with the P-TMSI, the authentication should be restarted with the correct parameters. If the IMSI provided by the MS is the expected one (i.e. authentication has really failed), the network should proceed as described below.
- If the IMSI has been used, or the network decides not to try the identification procedure, an AUTHENTICATION AND CIPHERING REJECT message should be transferred to the MS.

Upon receipt of an AUTHENTICATION AND CIPHERING REJECT message, the MS shall set the GPRS update status to GU3 ROAMING NOT ALLOWED and shall delete the P-TMSI, P-TMSI signature, RAI and GPRS ciphering key sequence number stored. If available, also the TMSI, LAI, ciphering key sequence number shall be deleted and the update status shall be set to U3 ROAMING NOT ALLOWED. The SIM shall be considered as invalid until switching off or the SIM is removed.

If the AUTHENTICATION AND CIPHERING REJECT message is received, the MS shall abort any GMM procedure, shall stop the timers T3310 and T3330 (if running) and shall enter state GMM-DEREGISTERED.

## 4.7.7.6 Abnormal cases on the network side

The following abnormal cases can be identified:

a) Lower layer failure

Upon detection of a lower layer failure before the AUTHENTICATION AND CIPHERING RESPONSE is received, the network shall abort the procedure.

b) Expiry of timer T3360

The network shall, on the first expiry of the timer T3360, retransmit the AUTHENTICATION AND CIPHERING REQUEST and shall reset and start timer T3360. This retransmission is repeated four times, i.e. on the fifth expiry of timer T3360, the procedure shall be aborted.

c) Collision of an authentication and ciphering procedure with a GPRS attach procedure

If the network receives an ATTACH REQUEST message before the ongoing authentication procedure has been completed and no GPRS attach procedure is pending on the network (i.e. no ATTACH ACCEPT/REJECT message has to be sent as an answer to an ATTACH REQUEST message), the network shall abort the authentication and ciphering procedure and proceed with the new GPRS attach procedure.

d) Collision of an authentication and ciphering procedure with a GPRS attach procedure when the authentication and ciphering procedure has been caused by a previous GPRS attach procedure

If the network receives an ATTACH REQUEST message before the ongoing authentication procedure has been completed and a GPRS attach procedure is pending (i.e. an ATTACH ACCEPT/REJECT message has still to be sent as an answer to an earlier ATTACH REQUEST message), then:

- If one or more of the information elements in the ATTACH REQUEST message differs from the ones received within the previous ATTACH REQUEST message, the network shall not treat the authentication any further and proceed with the GPRS attach procedure; or
- If the information elements do not differ, then the network shall not treat any further this new ATTACH REQUEST.

Collision of an authentication and ciphering procedure with a GPRS detach procedure.

GPRS detach containing cause "power off":

If the network receives a DETACH REQUEST message before the ongoing authentication and ciphering procedure has been completed, the network shall abort the authentication and ciphering procedure and shall progress the GPRS detach procedure.

GPRS detach containing other causes than "power off":

If the network receives a DETACH REQUEST message before the ongoing authentication and ciphering procedure has been completed, the network shall complete the authentication and ciphering procedure and shall respond to the GPRS detach procedure as described in sub-clause 4.7.4.

e) Collision of an authentication and ciphering procedure with a routing area updating procedure

If the network receives a ROUTING AREA UPDATE REQUEST message before the ongoing authentication procedure has been completed, the network shall progress both procedures.




Figure 4.7.7/1 3GPP TS 04.08: Authentication and ciphering procedure

## 4.7.8 Identification procedure

The identification procedure is used by the network to request an MS to provide specific identification parameters to the network e.g. International Mobile Subscriber Identity, International Mobile Equipment Identity (see 3GPP TS 03.03). For the presentation of the IMEI, the requirements of 3GPP TS 02.09 apply.

## 4.7.8.1 Identification initiation by the network

The network initiates the identification procedure by transferring an IDENTITY REQUEST message to the MS and starts the timer T3370. The IDENTITY REQUEST message specifies the requested identification parameters in the identity type information element.

## 4.7.8.2 Identification response by the MS

An MS that has been attached to GPRS shall be ready to respond to an IDENTITY REQUEST message at any time.

Upon receipt of the IDENTITY REQUEST message the MS sends back an IDENTITY RESPONSE message. The IDENTITY RESPONSE message shall contain the identification parameters as requested by the network.

## 4.7.8.3 Identification completion by the network

Upon receipt of the IDENTITY RESPONSE the network shall stop timer T3370.

## 4.7.8.4 Abnormal cases on the network side

The following abnormal cases can be identified:

a) Lower layer failure

Upon detection of a lower layer failure before the IDENTITY RESPONSE is received, the network shall abort any ongoing GMM procedure.

b) Expiry of timer T3370

The identification procedure is supervised by the network by the timer T3370. The network shall, on the first expiry of the timer T3370, retransmit the IDENTITY REQUEST message and reset and restart the timer T3370. This retransmission is repeated four times, i.e. on the fifth expiry of timer T3370, the network shall abort the identification procedure and any ongoing GMM procedure.

c) Collision of an identification procedure with a GPRS attach procedure

If the network receives an ATTACH REQUEST message before the ongoing identification procedure has been completed and no GPRS attach procedure is pending on the network (i.e. no ATTACH ACCEPT/REJECT message has still to be sent as an answer to an ATTACH REQUEST message), the network shall proceed with the GPRS attach procedure.

d) Collision of an identification procedure with a GPRS attach procedure when the identification procedure has been caused by a GPRS attach procedure

If the network receives an ATTACH REQUEST message before the ongoing identification procedure has been completed and a GPRS attach procedure is pending (i.e. an ATTACH ACCEPT/REJECT message has to be sent as an answer to an earlier ATTACH REQUEST message), then:

- If one or more of the information elements in the ATTACH REQUEST message differs from the ones received within the previous ATTACH REQUEST message, the network shall proceed with the GPRS attach procedure; or
- If the information elements do not differ, then the network shall not treat any further this new ATTACH REQUEST.

Collision of an identification procedure with an MS initiated GPRS detach procedure.

GPRS detach containing cause "power off":

If the network receives a DETACH REQUEST message before the ongoing identification procedure has been completed, the network shall abort the identification procedure and shall progress the GPRS detach procedure.

GPRS detach containing other causes than "power off":

If the network receives a DETACH REQUEST message before the ongoing identification procedure has been completed, the network shall complete the identification procedure and shall respond to the GPRS detach procedure as described in sub-clause 4.7.4.

e) Collision of an identification procedure with a routing area updating procedure

If the network receives a ROUTING AREA UPDATE REQUEST message before the ongoing identification procedure has been completed, the network shall progress both procedures.




Figure 4.7.8/1 3GPP TS 04.08: Identification procedure

## 4.7.9 Paging procedure

## 4.7.9.1 Paging for GPRS services

Paging is used by the network to identify the cell the MS has currently selected, or to prompt the mobile to re-attach if necessary as a result of network failure. If the MS is not GPRS attached when it receives a paging for GPRS services, the MS shall ignore the paging.

## 4.7.9.1.1 Paging for GPRS services using P-TMSI

The network shall initiate the paging procedure for GPRS services using P-TMSI when GMM signalling messages or user data is pending to be sent to the MS while the Mobile Reachable timer is running. The network may page only GPRS MSs which are GMM-REGISTERED and identified by a local P-TMSI.

To initiate the procedure the GMM entity requests the RR sublayer to start paging (see clause 3 and 3GPP TS 04.60 [75]) and starts timer T3313. Upon reception of a paging indication, the MS shall respond to the paging (see 3GPP TS 04.07 [20] and 3GPP TS 03.60 [74]).

The network shall stop timer T3313 when a response is received from the MS. When the timer T3313 expires the network may reinitiate paging.

The network shall stop timer T3313 when a response is received from the MS and shall start the READY timer. When the timer T3313 expires the network may reinitiate paging.

## 4.7.9.1.2 Paging for GPRS services using IMSI

Paging for GPRS services using IMSI is an abnormal procedure used for error recovery in the network.

The network may initiate paging using IMSI if the P-TMSI is not available due to a network failure.

To initiate the procedure the GMM entity in the network requests the RR sublayer to start paging (see chapter 3 and 3GPP TS 04.60 [75]).

Upon reception of a paging indication for GPRS services using IMSI, the MS shall locally deactivate any active PDP contexts and locally detach from GPRS. The local detach includes deleting any RAI, P-TMSI, P-TMSI signature and GPRS ciphering key sequence number stored, setting the GPRS update status to GU2 NOT UPDATED and changing state to GMM-DEREGISTERED.

After performing the local detach, the MS shall then perform a GPRS attach or combined GPRS attach procedure.

After performing the attach, a MS should activate PDP context(s) to replace any previously active PDP context(s).

- NOTE 1: In some cases, user interaction may be required and then the MS cannot activate the PDP context(s) automatically.
- NOTE 2: The MS does not respond to the paging except with the Attach Request. Hence timer T3313 in the network is not used when paging with IMSI.
- NOTE 3: Paging without DRX parameters may require a considerable extension of the paging duration.

## 4.7.9.2 Paging for non-GPRS services

The network may initiate the paging procedure for non-GPRS services when the MS is IMSI attached for non-GPRS services. To initiate the procedure the GMM entity requests the RR sublayer to initiate paging (see clause 3 and 3GPP TS 04.60 [75]) for non-GPRS services. The MS identity used for paging shall be the allocated TMSI if acknowledged by the MS, otherwise the IMSI.

## 4.7.10 Receiving a GMM STATUS message by a GMM entity

If the MS receives a GMM STATUS message no state transition and no specific action shall be taken as seen from the radio interface, i.e. local actions are possible. The actions to be taken on receiving a GMM STATUS message in the network are an implementation dependent option.

## 4.7.11 GMM support for anonymous access

The GMM-AA entity within the MM sublayer (see 3GPP TS 04.07) supports SM message routing for anonymous PDP context handling independently of the GMM procedures described throughout sub-clause 4.7 as described in sub-clause 6.1.1.1. There are no dedicated signalling procedures specified for the GMM-AA entity.

An AA-READY timer is implemented in the GMM-AA entity. This timer is used to supervise the time an anonymous access may be active without user data transfer.

## 4.7.11.1 MS side

The AA-READY timer value shall either be the default value or a value set by the network and sent to the MS by means of an SM message. The AA-READY timer shall be reset and restarted in the MS when the GMM-AA entity receives an indication from lower layers that an LLC frame has been transmitted on the radio interface. When the AA-READY timer expires or a routing area border is crossed, the MS shall deactivate the anonymous access locally, i.e. no signalling messages are exchanged between the MS and the network.

While the AA-READY timer is running, the MS shall perform cell updates when a new cell is selected within the same RA.

## 4.7.11.2 Network side

The AA-READY timer value shall either be the default value or a value received from the MS and possibly modified by the network and sent to the MS by means of an SM message. The AA-READY timer shall be reset and restarted by the network when the GMM-AA entity receives an indication from lower layers that an LLC frame has been successfully received by the network. When the AA-READY timer expires, the network shall deactivate the anonymous access locally, i.e. no signalling messages are exchanged between the network and the MS.

To account for the LLC frame uplink transmission delay, the AA-READY timer value should be slightly shorter in the network than in the MS. This is a network implementation issue.

## 4.7.12 GMM Information procedure

The GMM information message support is optional in the network. The MM information procedure may be invoked by the network at any time during an established GMM context.

## 4.7.12.1 GMM information procedure initiation by the network

The GMM information procedure consists only of the GMM INFORMATION message sent from the network to the mobile station. During an established GMM context, the network may send none, one, or more GMM INFORMATION messages to the mobile station. If more than one GMM INFORMATION message is sent, the messages need not have the same content.

## 4.7.12.2 GMM information procedure in the mobile station

When the mobile station (supporting the GMM information message) receives an GMM INFORMATION message, it shall accept the message and optionally use the contents to update appropriate information stored within the mobile station.

If the mobile station does not support the GMM information message the mobile station shall ignore the contents of the message and return an GMM STATUS message with cause #97.

# 5 Elementary procedures for circuit-switched Call Control

## 5.1 Overview

## 5.1.1 General

This sub-clause describes the call control (CC) protocol, which is one of the protocols of the Connection Management (CM) sublayer (see 3GPP TS 04.07).

Every mobile station must support the call control protocol. If a mobile station does not support any bearer capability at all then it shall respond to a SETUP message with a RELEASE COMPLETE message as specified in subclause 5.2.2.2.

In the call control protocol, more than one CC entity are defined. Each CC entity is independent from each other and shall communicate with the correspondent peer entity using its own MM connection. Different CC entities use different transaction identifiers.

With a few exceptions the present document describes the call control protocol only with regard to two peer entities. The call control entities are described as communicating finite state machines which exchange messages across the radio interface and communicate internally with other protocol (sub)layers. This description is only normative as far as the consequential externally observable behaviour is concerned.

Certain sequences of actions of the two peer entities compose "elementary procedures" which are used as a basis for the description in this sub-clause. These elementary procedures may be grouped into the following classes:

- call establishment procedures;
- call clearing procedures;
- call information phase procedures;
- miscellaneous procedures.

The terms "mobile originating" or "mobile originated" (MO) are used to describe a call initiated by the mobile station. The terms "mobile terminating" or "mobile terminated" (MT) are used to describe a call initiated by the network.

Figure 5.1a/3GPP TS 04.08 gives an overview of the main states and transitions on the mobile station side.

The MS side extension figure 5.1a.1/3GPP TS 04.08 shows how for the Network Initiated MO call the MS reaches state U1.0 from state U0 \$(CCBS)\$.

Figure 5.1b/3GPP TS 04.08 gives an overview of the main states and transitions on the network side.

The Network side extension figure 5.1b.1/3GPP TS 04.08 shows for Network Initiated MO Calls the Network reaches state N1.0 from state N0 \$(CCBS)\$.




Figure 5.1a/3GPP TS 04.08: Overview call control protocol/MS side




Figure 5.1a.1/3GPP TS 04.08: Overview call control protocol/MS side, extension:





Figure 5.1b/3GPP TS 04.08: Overview call control protocol/Network side



### Figure 5.1b.1/3GPP TS 04.08: Overview call control protocol/Network side, extension:

# 5.1.2 Call Control States

## 5.1.2.1 Call states at the mobile station side of the interface

The states which may exist on the mobile station side of the radio interface are defined in this sub-clause.

NOTE: States U0.1, U0.2, U0.3, U0.4, U0.5, U0.6, U26, and U27 are GSM specific. All other states are ITU-T defined.

## 5.1.2.1.1 Null (State U0)

No call exists.

### 5.1.2.1.2 MM Connection pending (U0.1)

This state exists for a mobile originating call, when the mobile station requests the establishment of a MM connection.

# 5.1.2.1.2a CC prompt present (U0.2) \$(CCBS)\$

This state exists for a mobile originating call when the network has prompted the mobile station to establish a CC connection but the mobile station has not yet responded.

NOTE: This state is transient.

### 5.1.2.1.2b Wait for network information (U0.3) \$(CCBS)\$

This state exists for a mobile originating call when the mobile station has responded to the prompt from the network to establish a CC connection and the mobile station is waiting for further information from the network.

# 5.1.2.1.2c CC-Establishment present (U0.4) \$(CCBS)\$

This state exists for a mobile originating call when the mobile station has received a CC-establishment request but has not yet responded.

NOTE: This state is transient.

### 5.1.2.1.2d CC-Establishment confirmed (U0.5) \$(CCBS)\$

This state exists for a mobile originating call when the mobile station has sent the acknowledgement that the mobile station has received all the CC information that is needed.

### 5.1.2.1.2e Recall present (U0.6) \$(CCBS)\$

This state exists for a mobile originating call when the mobile station has received a recall request but has not yet responded.

NOTE: This state is transient.

### 5.1.2.1.3 Call initiated (U1)

This state exists for a mobile originating call, when the MS requests call establishment from the network.

### 5.1.2.1.4 Mobile originating call proceeding (U3)

This state exists for a mobile originating call when the mobile station has received acknowledgement that the network has received all call information necessary to effect call establishment.

### 5.1.2.1.5 Call delivered (U4)

This state exists for a mobile originating call, when the calling mobile station has received an indication that remote user alerting has been initiated.

### 5.1.2.1.6 Call present (U6)

This state exists for a mobile terminating call when the mobile station has received a call establishment request but has not yet responded.

## 5.1.2.1.7 Call received (U7)

This state exists for a mobile terminating call when the mobile station has indicated alerting but has not yet answered.

### 5.1.2.1.8 Connect Request (U8)

This state exists for a mobile terminating call, when the mobile station has answered the call and is waiting to be awarded the call.

### 5.1.2.1.9 Mobile terminating call confirmed (U9)

This state exists for a mobile terminating call when the mobile station has sent acknowledgement that the mobile station has received all call information necessary to effect call establishment.

### 5.1.2.1.10 Active (U10)

This state exists for a mobile terminating call when the MS has answered the call. This state exists for a mobile originating call when the MS has received an indication that the remote user has answered the call.

### 5.1.2.1.11 Disconnect request (U11)

This state exists when the mobile station has requested the network to clear the end-to-end connection (if any) and is waiting for a response.

### 5.1.2.1.12 Disconnect indication (U12)

This state exists when the mobile station has received an invitation to disconnect because the network has disconnected the end-to-end connection (if any).

### 5.1.2.1.13 Release request (U19)

This state exists when the MS has requested the network to release and is waiting for a response.

### 5.1.2.1.14 Mobile originating modify (U26)

This state exists when the mobile station has sent a request to the network for a new mode but has not yet received an answer.

### 5.1.2.1.15 Mobile terminating modify (U27)

This state exists when the mobile station has received a request from the network for a new mode and has not yet sent a response to this request.

### 5.1.2.2 Network call states

NOTE: States N0.1, N0.2, N0.3, N0.4, N0.5, N0.6, N26, N27, N28, N3a, N4,a, N7a, and N9a are GSM specific. All other states are ITU-T defined.

The call states that may exist on the network side of the radio interface are defined in this sub-clause.

### 5.1.2.2.1 Null (State N0)

No call exists.

### 5.1.2.2.2 MM connection pending (N0.1)

This state exists for a mobile terminating call, when the network requests the establishment of a MM connection.

### 5.1.2.2.2a CC connection pending (N0.2) \$(CCBS)\$

This state exists for a mobile originating call when the network has requested the mobile station to establish a CC connection.

### 5.1.2.2.2b Network answer pending (N0.3) \$(CCBS)\$

This state exists for a mobile originating call when the mobile station has established a CC connection upon the request of the network, but the network has not yet informed the mobile station of the reason for the network's action.

# 5.1.2.2.2c CC-Establishment present (N0.4) \$(CCBS)\$

This state exists for a mobile originating call when the network has sent a CC establishment request but has not yet received a satisfactory response.

### 5.1.2.2.2d CC-Establishment confirmed (N0.5) \$(CCBS)\$

This state exists for a mobile originating call when the network has received acknowledgement that the mobile station has received all call information necessary to effect call establishment.5.1.2.2.2e Recall present (N0.6) (CCBS)

This state exists for a mobile originating call when the network has sent a recall request but has not yet received a satisfactory response.

### 5.1.2.2.3 Call initiated (N1)

This state exists for a mobile originating call when the network has received a call establishment request but has not yet responded.

### 5.1.2.2.4 Mobile originating call proceeding (N3)

This state exists for a mobile originating call when the network has sent acknowledgement that the network has received all call information necessary to effect call establishment.

### 5.1.2.2.5 Call delivered (N4)

This state exists for a mobile originating call when the network has indicated that remote user alerting has been initiated.

### 5.1.2.2.6 Call present (N6)

This state exists for a mobile terminating call when the network has sent a call establishment request but has not yet received a satisfactory response.

## 5.1.2.2.7 Call received (N7)

This state exists for a mobile terminating call when the network has received an indication that the mobile station is alerting but has not yet received an answer.

### 5.1.2.2.8 Connect request (N8)

This state exists for a mobile terminating call when the network has received an answer but the network has not yet awarded the call.

### 5.1.2.2.9 Mobile terminating call confirmed (N9)

This state exists for a mobile terminating call when the network has received acknowledgement that the mobile station has received all call information necessary to effect call establishment.

### 5.1.2.2.10 Active (N10)

This state exists for a mobile terminating call when the network has awarded the call to the called mobile station. This state exists for a mobile originating call when the network has indicated that the remote user has answered the call.

### 5.1.2.2.11 Not used

### 5.1.2.2.12 Disconnect indication (N12)

This state exists when the network has disconnected the end- to-end connection (if any) and has sent an invitation to disconnect the mobile station to network connection.

### 5.1.2.2.13 Release request (N19)

This state exists when the network has requested the MS to release and is waiting for a response.

### 5.1.2.2.14 Mobile originating modify (N26)

This state exists when the network has received a request from the mobile station for a new mode but has not yet sent a response.

### 5.1.2.2.15 Mobile terminating modify (N27)

This state exists when the network has sent a request to the mobile station for a new mode but has not yet received an answer.

### 5.1.2.2.16 Connect Indication (N28)

This state exists for a mobile originating call when the network has indicated that the remote user has answered the call and the network is waiting for acknowledgement by the mobile station.

# 5.2 Call establishment procedures

Establishment of a call is initiated by request of upper layer in either the mobile station or the network; it consists of:

- the establishment of a CC connection between the mobile station and the network;
- the activation of the codec or interworking function.

Whenever it is specified in 3GPP TS 04.08, clause 5 that the mobile station shall attach the user connection, this means that the mobile station shall activate the codec or interworking function as soon as an appropriate channel is available. The mobile station shall de-activate the codec or interworking function whenever an appropriate channel is no longer available. As soon as an appropriate channel is (again) available, the codec or interworking function shall be re-activated. If a new order to attach the user connection is received, the new order shall supersede the previous one.

A channel shall be considered as appropriate if it is consistent with the possibly negotiated bearer capability applicable for the actual phase of the call. The mobile station shall not consider a channel as not appropriate because the type of the channel (full rate/half rate) is not the preferred one. If:

- the user connection has to be attached but no appropriate channel is available for a contiguous time of 30 seconds; or if
- the codec or interworking function is de-activated for a contiguous time of 30 seconds;

then the mobile station may initiate call clearing.

Upon request of upper layers to establish a call, restricting conditions for the establishment of the call are examined. These restricting conditions concern the states of parallel CC entities and are defined elsewhere. If these restricting conditions are fulfilled, the call establishment is rejected. Otherwise a CC entity in state U0, "null", is selected to establish the call. It initiates the establishment by requesting the MM sublayer to establish an MM connection.

# 5.2.1 Mobile originating call establishment

The call control entity of the mobile station initiates establishment of a CC connection by requesting the MM sublayer to establish a mobile originating MM connection and entering the "MM connection pending" state. There are two kinds of a mobile originating call: basic call and emergency call. The request to establish an MM connection shall contain a parameter to specify whether the call is a basic or an emergency call. This information may lead to specific qualities of services to be provided by the MM sublayers. Timer T303 is started when the CM SERVICE REQUEST message is sent.

For mobile stations supporting eMLPP basic calls may optionally have an associated priority level as defined in 3GPP TS 03.67. This information may also lead to specified qualities of service to be provided by the MM sublayers.

While being in the "MM connection pending" state, the call entity of the mobile station may cancel the call prior to sending the first call control message according to the rules given in sub-clause 4.5.1.7.

Having entered the "MM connection pending" state, upon MM connection establishment, the call control entity of the mobile station sends a setup message to its peer entity. This setup message is

- a SETUP message, if the call to be established is a basic call, and
- an EMERGENCY SETUP message, if the call to be established is an emergency call.

It then enters the "call initiated" state. Timer T303 is not stopped.

The setup message shall contain all the information required by the network to process the call. In particular, the SETUP message shall contain the called party address information.

If timer T303 elapses in the "MM connection pending" state, the MM connection in progress shall be aborted and the user shall be informed about the rejection of the call.

### 5.2.1.1 Call initiation

The "call initiated" state is supervised by timer T303.For normal MO calls, this timer will have already been started after entering the "MM connection pending" state. For network-initiated MO calls this timer will be started in the recall present state as defined in sub-clause 5.2.3.4.

When the call control entity of the mobile station is in the "call initiated" state and if it receives:

- i) a CALL PROCEEDING message, it shall proceed as described in sub-clause 5.2.1.3;
- ii) an ALERTING message, it shall proceed as described in sub-clause 5.2.1.5;
- iii) a CONNECT message, it shall proceed as described in sub-clause 5.2.1.6;
- iv) a RELEASE COMPLETE message it shall proceed as described in sub-clause 5.2.1.2.

Abnormal case:

- If timer T303 elapses in the "call initiated" state before any of the CALL PROCEEDING, ALERTING, CONNECT or RELEASE COMPLETE messages has been received, the clearing procedure described in subclause 5.4 is performed.

### 5.2.1.2 Receipt of a setup message

In the "null" or "recall present" states, upon receipt of a setup message (a SETUP message or an EMERGENCY SETUP message, see sub-clause 5.2.1.1), the call control entity of the network enters the "call initiated" state. It shall then analyse the call information contained in the setup message.

- i) If, following the receipt of the setup message, the call control entity of the network determines that the call information received from the mobile station is invalid (e.g. invalid number), then the network shall initiate call clearing as defined in sub-clause 5.4 with one of the following cause values:
  - #1 "unassigned (unallocated) number"
  - # 3 "no route to destination"
  - # 22 "number changed"
  - #28 "invalid number format (incomplete number)"
- ii) If, following the receipt of the setup message, the call control entity of the network determines that a requested service is not authorized or is not available, it shall initiate call clearing in accordance with sub-clause 5.4.2 with one of the following cause values:
  - #8 "operator determined barring",
  - # 57 "bearer capability not authorized",

- # 58 "bearer capability not presently available",
- # 63 "service or option not available, unspecified", or
- # 65 "bearer service not implemented".


iii) Otherwise, the call control entity of the network shall either:

- send a CALL PROCEEDING message to its peer entity to indicate that the call is being processed; and enter the "mobile originating call proceeding" state.
- or: send an ALERTING message to its peer entity to indicate that alerting has been started at the called user side; and enter the "call received" state.
- or: send a CONNECT message to its peer entity to indicate that the call has been accepted at the called user side; and enter the "connect request" state.

The call control entity of the network may insert bearer capability information element(s) in the CALL PROCEEDING message to select options presented by the mobile station in the Bearer Capability information element(s) of the SETUP message. The bearer capability information element(s) shall contain the same parameters as received in the SETUP except those presenting a choice. Where choices were offered, appropriate parameters indicating the results of those choices shall be included.

The CALL\_PROCEEDING message may also contain the priority of the call in the case where eMLPP is applied and where the network has assigned a different priority to the call than that requested by the user, or where the user has not requested a priority and the network has assigned a default priority. Mobile stations supporting eMLPP shall indicate this priority level to higher sublayers and store this information for the duration of the call for further action. Mobile stations not supporting eMLPP shall ignore this information element if provided in a CALL PROCEEDING message.

The call control entity of the network having entered the "mobile originating call proceeding" state, the network may initiate the assignment of a traffic channel according to sub-clause 5.2.1.9 (early assignment).



### Figure 5.2/3GPP TS 04.08: Mobile originated call initiation and possible subsequent responses

### 5.2.1.3 Receipt of a CALL PROCEEDING message


Having entered the "call initiated" state, when the call control entity of the mobile station receives a CALL PROCEEDING message, it shall stop timer T303; start timer T310 unless

- the CALL PROCEEDING message contains a *progress indicator* IE specifying progress description #1, #2, or #64; or
- it has received a PROGRESS message containing a *progress indicator* IE specifying progress description #1, #2, or #64 prior to the CALL PROCEEDING message

and enter the "mobile originating call proceeding" state.

Abnormal case:

If timer T310 elapses before any of the ALERTING, CONNECT or DISCONNECT messages has been received, the mobile station shall perform the clearing procedure described in sub-clause 5.4.



### Figure 5.3/3GPP TS 04.08: Call proceeding sequence at mobile originating call establishment

### 5.2.1.4 Notification of progressing mobile originated call

In this sub-clause, the term "interworking" is used only in the meaning of interworking with a network other than PLMN or ISDN, not as interworking between PLMN and ISDN since this is the normal case. In this sense, PLMN and ISDN are seen within the same environment, called the PLMN/ISDN environment.

#### 5.2.1.4.1 Notification of interworking in connection with mobile originated call establishment

During call establishment, the call may leave a PLMN/ISDN environment; e.g., because of interworking with another network, with a non-PLMN/ISDN user, or with non-PLMN/ISDN equipment within the called user's premises; the call may also return to a PLMN/ISDN environment. When such situations occur, the network may send a *progress indicator* information element to the calling mobile station either:

- a) in an appropriate call control message, if a state change is required (e.g. ALERTING or CONNECT); or,
- b) in the PROGRESS message, if no state change is appropriate.

This progress indicator information element shall contain one of the following progress description values:

- a) #1 "call is not end-to-end PLMN/ISDN; further call progress information may be available in-band".
- b) #2 "destination address is non-PLMN/ISDN".
- c) #4 "call has returned to PLMN/ISDN.

See also sub-clauses 5.5.1 and 5.5.6 for further reactions of the mobile station.

### 5.2.1.4.2 Call progress in the PLMN/ISDN environment

In order to inform the mobile station that the call is progressing in the PLMN/ISDN environment the network may send a *progress indicator* information element to the calling mobile station either:

- a) in an appropriate call control message, if a state change is required (e.g., ALERTING or CONNECT); or
- b) in the PROGRESS message, if no state change is appropriate.

This *progress indicator* information element shall contain progress description value #32 "Call is end-to-end ISDN/PLMN". See also sub-clause 5.5.6 for further reactions of the mobile station.

### 5.2.1.5 Alerting

Having entered the "mobile originating call proceeding" state, upon receiving an indication that user alerting has been initiated at the called address, the call control entity of the network shall: send an ALERTING message to its peer entity at the calling mobile station and enter the "call delivered" state.

When the call control entity of the mobile station in the "call initiated" state or "mobile originating call proceeding" state receives an ALERTING message then, the call control entity of the mobile station shall stop timer T303 and T310 (if running) and shall enter the "call delivered" state. In this state, for speech calls:

- an alerting indication should be given to the user. If the mobile station has not attached the user connection then the mobile station shall internally generate an alerting indication. If the mobile station has attached the user connection then the network is responsible for generating the alerting indication and the mobile station need not generate one.

Abnormal cases:

On the mobile station side, if timer T310 expires, the call control entity of the mobile station shall initiate call clearing as described in sub-clause 5.4.



#### Figure 5.4/3GPP TS 04.08: Call confirmation at mobile originating call establishment

### 5.2.1.6 Call connected

Upon receiving an indication that the call has been accepted, the call control entity of the network shall: through connect the traffic channel (including the connection of an interworking function, if required) and send a CONNECT message to its peer entity at the calling mobile station; start timer T313 and enter the "connect indication" state.

This message indicates to the call control entity of the calling mobile station that a connection has been established through the network.

The call control entity of the mobile station in the "call initiated" state, in the "mobile originating call proceeding" state or in the "call delivered" state, shall, upon receipt of a CONNECT message:

- attach the user connection;
- return a CONNECT ACKNOWLEDGE message;
- stop any locally generated alerting indication (if applied);
- stop timer T303 and T310 (if running);
- enter the "active" state.

#### Abnormal cases:


- On the mobile station side, if timer T303 or T310 expires, the call control entity of the mobile station shall initiate call clearing as described in sub-clause 5.4.
- NOTE: The mobile station may have applied an additional internal alerting supervision which causes initiation of call clearing prior to the expiry of T303 or T310.

The call control of the network in the "connect indication" state, shall, upon receipt of a CONNECT ACKNOWLEDGE message:

- stop timer T313 and enter the "active" state.

Abnormal cases:

On the network side, if timer T313 elapses before a CONNECT ACKNOWLEDGE message has been received, the network shall perform the clearing procedure as described in sub-clause 5.4.



### Figure 5.5/3GPP TS 04.08: Call acceptance sequence at mobile originating call establishment

### 5.2.1.7 Call rejection

Upon receiving an indication that the network or the called user is unable to accept the call, the network shall initiate call clearing at the radio interface to the mobile which originated the call, as described in sub-clause 5.4 using the cause provided by the terminating network or the called user.

### 5.2.1.8 Transit network selection

NOTE: For further study.

### 5.2.1.9 Traffic channel assignment at mobile originating call establishment

It is a network dependent decision when to initiate the assignment of an appropriate traffic channel during the mobile originating call establishment phase. Initiation of a suitable RR procedure to assign an appropriate traffic channel does neither change the state of a call control entity nor affect any call control timer.

NOTE: During certain phases of such an RR procedure, transmission of CC and MM messages may be suspended, see 3GPP TS 04.08, clause 3 and 3GPP TS 08.08.

The assignment procedure does not affect any call control timer.

# 5.2.1.10 Call queuing at mobile originating call establishment

The conditions to apply queuing are described in 3GPP TS 03.01.

If an idle traffic channel is not available at the assignment instant, the network may place the traffic channel request in a queue. Calls arriving when all positions in the queue are occupied shall be cleared by the network using the cause #34 "no circuit/channel available".

The maximum queuing interval is supervised by the network. The limit is a network dependent choice. In case the network is not able to allocate a traffic channel within the queuing limit, the network will release the call using cause #34 "no circuit/channel available".

Optionally, e.g. if eMLPP is used, the network may decide to pre-empt existing calls or to place the traffic channel request at some preferential position within the queue.

Specific indications provided in the network to the remote user are a network dependent choice.

# 5.2.2 Mobile terminating call establishment

Before call establishment can be initiated in the mobile station, the MM connection must be established by the network.


### 5.2.2.1 Call indication

After the arrival of a call from a remote user, the corresponding call control entity in the network shall: initiate the MM connection establishment according to clause 4 and enter the "MM connection pending" state. The request to establish the MM connection is passed from the CM sublayer to the MM sublayer. It contains the necessary routing information derived from the SETUP message.

Upon completion of the MM connection, the call control entity of the network shall: send the SETUP message to its peer entity at the mobile station, start timer T303 and enter the "call present" state.

Upon receipt of a SETUP message, the mobile station shall perform compatibility checking as described in 5.2.2.2. If the result of the compatibility checking was compatibility, the call control entity of the mobile station shall enter the "call present" state. An incompatible mobile station shall respond with a RELEASE COMPLETE message in accordance with sub-clause 5.2.2.3.4.

If no response to the SETUP message is received by the call control entity of the network before the expiry of timer T303, the procedures described in sub-clause 5.2.2.3.3 shall apply.



### Figure 5.6/3GPP TS 04.08: Mobile terminating call initiation and possible subsequent responses

### 5.2.2.2 Compatibility checking

The mobile station receiving a SETUP message shall perform compatibility checking before responding to that SETUP message. Annex B defines compatibility checking to be performed by the mobile station upon receiving a SETUP message.

## 5.2.2.3 Call confirmation

#### 5.2.2.3.1 Response to SETUP

Having entered the "call present state" the call control entity of the mobile station shall - with the exception of the cases described below - acknowledge the SETUP message by a CALL CONFIRMED message, and enter the "mobile terminating call confirmed" state.

The call control entity of the mobile station may include in the CALL CONFIRMED message to the network one or two bearer capability information elements to the network, either preselected in the mobile station or corresponding to a service dependent directory number (see 3GPP TS 09.07). The mobile station may also include one or two bearer capabilities in the CALL CONFIRMED message to define the radio channel requirements. In any case the rules specified in sub-clause 9.3.2.2 shall be followed.

NOTE: The possibility of alternative responses (e.g., in connection with supplementary services) is for further study.

A busy MS which satisfies the compatibility requirements indicated in the SETUP message shall respond either with a CALL CONFIRMED message if the call setup is allowed to continue or a RELEASE COMPLETE message if the call setup is not allowed to continue, both with cause #17 "user busy".

If the mobile user wishes to refuse the call, a RELEASE COMPLETE message shall be sent with the cause #21 "call rejected".

In the cases where the mobile station responds to a SETUP message with RELEASE COMPLETE message the mobile station shall release the MM connection and enter the "null" state after sending the RELEASE COMPLETE message.

The network shall process the RELEASE COMPLETE message in accordance with sub-clause 5.4.

### 5.2.2.3.2 Receipt of CALL CONFIRMED and ALERTING by the network

The call control entity of the network in the "call present" state, shall, upon receipt of a CALL CONFIRMED message: stop timer T303, start timer T310 and enter the "mobile terminating call confirmed" state.

The call control entity of the mobile station having entered the "mobile terminating call confirmed" state, if the call is accepted at the called user side, the mobile station proceeds as described in 5.2.2.5. Otherwise, if the signal information element was present in the SETUP message user alerting is initiated at the mobile station side; if the signal information element was not present in the SETUP message, user alerting is initiated when an appropriate channel is available.

Here, initiation of user alerting means:

- the generation of an appropriate tone or indication at the mobile station; and
- sending of an ALERTING message by the call control entity of the MS to its peer entity in the network and entering the "call received" state.

The call control entity of the network in the "mobile terminated call confirmed" state shall, upon receipt of an ALERTING message: send a corresponding ALERTING indication to the calling user; stop timer T310; start timer T301, and enter the "call received" state.

In the "mobile terminating call confirmed" state or the "call received" state, if the user of a mobile station is User Determined User Busy then a DISCONNECT message shall be sent with cause #17 "user busy". In the "mobile terminating call confirmed" state, if the user of a mobile station wishes to reject the call then a DISCONNECT message shall be sent with cause #21 "call rejected".

### 5.2.2.3.3 Call failure procedures

In case of abnormal behaviour the following call failure procedures apply:

- i. If the network does not receive any response to the SETUP message prior to the expiration of timer T303, then the network shall: initiate clearing procedures towards the calling user with cause #18 "no user responding"; and initiate clearing procedures towards the called mobile station in accordance with 5.4.4 using cause #102 "recovery on timer expiry".
- ii. If the network has received a CALL CONFIRMED message, but does not receive an ALERTING, CONNECT or DISCONNECT message prior to the expiration of timer T310, then the network shall:
  - initiate clearing procedures towards the calling user with cause #18 "no user responding"; and
  - initiate clearing procedures towards the called MS in accordance with sub-clause 5.4.4 using cause #102 "recovery on timer expiry".
- iii. If the network has received an ALERTING message, but does not receive a CONNECT or DISCONNECT message prior to the expiry of timer T301 (or a corresponding internal alerting supervision timing function), then the network shall: initiate clearing procedures towards the calling user with cause #19 "user alerting, no answer"; and initiate clearing procedures towards the called mobile station in accordance with sub-clause 5.4.4, using cause #102 "recovery on timer expiry" or using cause #31 "normal, unspecified".
- NOTE: The choice between cause #31 and cause #102 may have consequences on indications generated by the mobile station, see 3GPP TS 02.40.

### 5.2.2.3.4 Called mobile station clearing during mobile terminating call establishment

See sub-clause 5.4.2.

# 5.2.2.4 Notification of interworking in connection with mobile terminating call establishment

In this sub-clause, the term "interworking" is used only in the meaning of interworking with a network other than PLMN or ISDN, not as interworking between PLMN and ISDN since this is the normal case. In this sense, PLMN and ISDN are seen within the same environment, called the PLMN/ISDN environment.

During call establishment the call may enter an PLMN/ISDN environment, e.g., because of interworking with another network, with a non-PLMN/ISDN user, or with non-PLMN/ISDN equipment within the calling or called user's premises. When this occurs, the network may include a *progress indicator* information element to be included in the SETUP message to be sent to the called mobile station specifying progress description value

- a) #1 "call is not end-to-end PLMN/ISDN; further call progress information may be available in-band"; or
- b) #3 "origination address is non-PLMN/ISDN".

See also sub-clause 5.5.1 for further reactions of the mobile station.

### 5.2.2.5 Call accept

In the "mobile terminating call confirmed" state or the "call received" state, the call control entity in the mobile station indicates acceptance of a mobile terminating call by:


- sending a CONNECT message to its peer entity in the network;
- starting Timer T313; and
- entering the "connect request" state.

## 5.2.2.6 Active indication

In the "mobile terminated call confirmed" state or in the "call received" state, the call control entity of the network shall, upon receipt of a CONNECT message: through connect the traffic channel (including the connection of an interworking function, if required), stop timers T310, T303 or T301 (if running); send a CONNECT ACKNOWLEDGE message to its peer entity at the mobile station of the called user; initiate procedures to send a CONNECT message towards the calling user and enter the "active" state.

In the "connect request" state, the call control entity of the mobile station shall, upon receipt of a CONNECT ACKNOWLEDGE message: stop timer T313 and enter the "active" state.

When timer T313 expires prior to the receipt of a CONNECT ACKNOWLEDGE message, the mobile station shall initiate clearing in accordance with sub-clause 5.4.3.



# Figure 5.7/3GPP TS 04.08: Call acceptance and active indication at mobile terminating call establishment

### 5.2.2.7 Traffic channel assignment at mobile terminating call establishment

It is a network dependent decision when to initiate the assignment of a traffic channel during the mobile terminating call establishment phase.

Initiation of the assignment phase does not directly change the state of a CC entity nor affect any call control timer, but may have some secondary effects (see e.g. sub-clause 5.2.2.3.2).

### 5.2.2.8 Call queuing at mobile terminating call establishment

The principles described in sub-clause 5.2.1.10 apply accordingly.

NOTE: The interworking to the fixed network has to fulfil the network specific requirements.

# 5.2.2.9 User connection attachment during a mobile terminating call

For speech calls:

- The mobile station shall attach the user connection at latest when sending the connect message.

For data calls:

- The mobile station shall attach the user connection when receiving the CONNECT ACKNOWLEDGE message from the network.

# 5.2.3 Network initiated MO call \$(CCBS)\$

The procedures of sub-clause 5.2.3 are mandatory for mobile stations supporting "Network initiated MO call".

NOTE: The behaviour of a mobile station that does not support "Network initiated MO call" is described in subclause 4.

### 5.2.3.1 Initiation

Before call establishment can be initiated in the mobile station, the MM connection shall be established by the network.

After the arrival of an appropriate stimulus (for example a Remote User Free Indication), the corresponding call control entity in the network shall initiate the MM connection establishment according to sub-clause 4, enter the "CC connection pending" state and start timer T331. The request to establish the MM connection is passed from the CM sublayer to the MM sublayer. It contains the necessary routing information derived from the received stimulus.

Upon completion of the MM connection, the call control entity of the mobile station shall send a START CC message to its peer entity in the network. The mobile station shall then enter the "Wait for network information" state and start timer T332.

If the network receives a START CC message while in the "CC connection pending" state, the network stops T331, sends the CC-ESTABLISHMENT message, starts timer T333 and enters the "CC-establishment present" state.

The MM connection establishment may be unsuccessful for a variety of reasons, in which case the MM sublayer in the network will inform the CC entity in the network with an indication of the reason for the failure. The CC entity shall then stop all running timers, enter the "Null" state and inform all appropriate entities within the network.

If timer T331 expires, the network shall abort the MM connection establishment attempt, stop all running CC timers, enter the "Null" state and inform all appropriate entities within the network.

# 5.2.3.2 CC-Establishment present

In the "CC establishment present" state, the mobile station, upon receipt of the CC-ESTABLISHMENT message, shall stop timer T332.

The CC-ESTABLISHMENT message contains information which the mobile station shall use for the subsequent SETUP message (if any) related to this CC-ESTABLISHMENT.

The CC-ESTABLISHMENT message shall contain the Setup Container IE.

If no CC-ESTABLISHMENT message is received by the call control entity of the mobile station before the expiry of timer T332, then the mobile station shall initiate clearing procedures towards the network using a RELEASE COMPLETE message with cause #102 "recovery on timer expiry" and proceed in accordance with sub-clause 5.4.2.

Upon receipt of a CC-ESTABLISHMENT message the mobile station shall perform checks on the Setup Container IE in order to align the contained information with the mobile's present capabilities and configuration. The "recall alignment procedure" is defined later on in this sub-clause.

If the recall alignment procedure has succeeded, the call control entity of the Mobile Station shall:

- form and store the SETUP message for sending later in the "Recall present" state;
- acknowledge the CC-ESTABLISHMENT message with a CC-ESTABLISHMENT CONFIRMED message;

- start timer T335; and
- enter the "CC-establishment confirmed" state.

#### Exception:

- A busy mobile station which has successfully performed the recall alignment procedure shall respond with a CC-ESTABLISHMENT CONFIRMED message with cause #17 "user busy", and proceed as stated above.

A mobile station, for which the recall alignment procedure failed, shall respond with a RELEASE COMPLETE message in accordance with sub-clause 5.4.2 with the appropriate cause code as indicated in the description of the recall alignment procedure.

The SETUP message is constructed from the *Setup Container IE* received in the CC ESTABLISHMENT MESSAGE. The mobile station shall assume that the *Setup Container IE* contains an entire SETUP message with the exception of the Protocol Discriminator, Transaction ID and Message Type elements. The mobile station may assume that the contents of the *Setup Container IE* are the same as were sent from the subscriber in a previous SETUP message of the mobile originating call establishment attempt. The mobile station shall copy the *Setup Container* to the SETUP message and not modify the contents except as defined in the recall alignment procedure and as defined in *exceptions* below. The mobile station shall not add other Information Elements to the end of the SETUP message.

#### Exceptions:

- *Bearer Capability IE(s), HLC IE(s) and LLC (s) IE(s) (*including *Repeat Indicator(s),* if there are 2 bearer capabilities) require handling as described in the recall alignment procedure below.
- If the *CC Capabilities* in the *Setup Container IE* is different to that supported by the mobile station, the mobile station shall modify the *CC Capabilities* in the SETUP message to indicate the true capabilities of the mobile station.
- *Facility IE(s) and SS Version IE(s)* require handling as described in the recall alignment procedure.

If no response to the CC-ESTABLISHMENT message is received by the call control entity of the network before the expiry of timer T333, then the network shall initiate clearing procedures towards the called mobile station using a RELEASE COMPLETE message with cause #102 "recovery on timer expiry" and inform all appropriate entities within the network, proceeding in accordance with sub-clause 5.4.2.

MS +		Ne	etwork	
cc	C-ESTABI	ISHMENT		
CC-ES	STABLISH	IMENT_CONF	IRMED	(i)
	RELEASE	COMPLETE	- >	(ii)
+			+	

#### Figure 5.7a/3GPP TS 04.08: Call initiation and possible subsequent responses

### 5.2.3.2.1 Recall Alignment Procedure

The recall alignment procedure consists of two parts:

- basic service group alignment; and
- facility alignment.

Basic service group alignment:

The mobile station shall check that the *Bearer Capability*, *HLC* and *LLC* and *Repeat Indicator* fields, which are embedded in the *Setup Container IE*, match a basic service group supported by the mobile station.

If this check fails, then the recall alignment procedure has failed. The mobile station shall use the cause #88 "incompatible destination" afterwards.

Otherwise, the mobile station is allowed to alter the content within the *Bearer Capability*, *HLC* and *LLC* Information Elements (e.g. the speech coder version(s), the data rate, the radio channel requirement) provided that the basic service group is not changed. The result shall be that the mobile station has derived *Bearer Capability*, *HLC* and *LLC* Information Elements, which it can use for a later call setup according to its configuration and capabilities.

Facility alignment:

- This only applies if the *Setup Container* contains 1 or more *Facility IEs*. Each *Facility IE* within the *Setup Container* will be associated with the common *SS Version IE*, if present. The handling for each *Facility IE* is defined below. The mobile station shall align each facility IE contained in the *Setup Container*. The rules defined in 3GPP TS 04.10 also apply.

The *Facility IE* is encoded as 'simple recall alignment', 'advanced recall alignment' or 'recall alignment not essential' (see 3GPP TS 04.10). If the encoding indicates, that:

- a simple recall alignment is required, the mobile station shall copy the Facility IE and the common SS version IE from the *Setup Container* to the SETUP message without modifying the content.
- an advanced recall alignment is required, the mobile station must recognise and support the operation defined in the facility. If the mobile station does not recognise or support the operation, then the recall alignment procedure has failed and the mobile station shall use the cause #29 "facility rejected" in the subsequent rejection of the CC establishment request.
- the recall alignment is not essential, then the facility operation is not an essential part of the SETUP. If the MS does not recognise the operation then the SS Version IE and Facility IE are discarded, and NOT copied into the SETUP message.
- NOTE: A mobile station may include a *Facility IE* without an associated *SS Version IE*. This would indicate that the SS operation is encoded using Phase 1 protocols.

Further details on Facility handling are given in 3GPP TS 04.10.

## 5.2.3.3 CC-Establishment confirmation

The call control entity of the network in the "CC-establishment present" state, shall, upon receipt of a CC-ESTABLISHMENT CONFIRMED message, stop timer T333 and enter the "CC-establishment confirmed" state.

In the "CC-establishment confirmed" state, the network sends a RECALL message. This message initiates user alerting and also shall include the Facility IE (providing additional information to be presented to the user for notification). The network starts timer T334 and enters the "recall present" state.

Upon reception of the RECALL message the Mobile station stops T335 and enters the "recall present" state.



### 5.2.3.4 Recall present

In the "recall present" state, the call control entity in the mobile station waits for acceptance of the Recall by the user. Once confirmation is received, the mobile station indicates acceptance of a recall by:

- sending a SETUP message to its peer entity in the network;
- starting Timer T303; and
- entering the "call initiated" state and proceeding as described in sub-clause 5.2.1.1.


The MS shall ensure that the contents of the *Bearer Capability IE*(s) sent in the SETUP message are the same as the *Bearer Capability IE*(s) in the previous CC-ESTABLISHMENT CONFIRMED message related to this Network Initiated MO Call.

In the "recall-present" state, if the user of a mobile station is User Determined User Busy then a RELEASE COMPLETE message shall be sent with cause #17 "user busy" In the "recall-present" state. If the user of a mobile station wishes to reject the recall then a RELEASE COMPLETE message shall be sent with cause #21 "call rejected".

In either case, the mobile shall release the connection in accordance with sub-clause 5.4.2.

On receipt of the SETUP message in the "recall present" state, the network shall stop timer T334 and proceed as specified in sub-clause 5.2.1.2.

If the call control entity of the network does not receive a SETUP message before the expiry of timer T334, then the network shall send a RELEASE COMPLETE message to the mobile using cause #102 "recovery on timer expiry", release the MM connection, enter the "null" state and shall inform all appropriate entities within the network.



### Figure 5.7b/3GPP TS 04.08: Recall acceptance or rejection by user

# 5.2.3.5 Traffic channel assignment during network initiated mobile originating call establishment

It is a network dependent decision whether or not to initiate the assignment of a traffic channel during the "CC-establishment confirmed" state.

# 5.3 Signalling procedures during the "active" state

# 5.3.1 User notification procedure

The mobile terminating user notification procedure allows the network to notify a mobile station of any appropriate call-related event during the "active" state of a call. The procedure consists in the network sending a NOTIFY message to the mobile station. No state change occurs at any of the interface sides following the sending or the receipt of this message (but an appropriate indication may optionally be generated in the mobile station).

The mobile originating notification procedure allows the mobile station to notify the remote user of any appropriate call-related event during the "active" state of a call by sending a NOTIFY message containing a notification indicator to the network; upon receipt of this message, the network sends a NOTIFY message containing the same notify indicator to the other user involved in the call. No state change occurs at any of the interface sides following the sending or the receipt of this message.

# 5.3.2 Call rearrangements

Call rearrangements on the radio interface are not supported by explicit messages (e.g. SUSPEND and RESUME messages as defined in ETS 300 102-1). However if a remote non-PLMN user initiates call rearrangements, the network shall inform the mobile station by means of a NOTIFY message. In a similar way the mobile station can inform the network about rearrangements by sending a NOTIFY message (e.g. change of user equipment connected to the mobile station).

# 5.3.3 Not used

# 5.3.4 Support of Dual Services

The behaviour described in this sub-clause is used to realize the following required services throughout subclause 5.3.4. The mobile station is not obliged to support the network originated in-call modification procedure. In that case, the mobile station shall, when receiving a MODIFY message, treat the message as unknown and react as described in sub-clause 8.4. If the mobile station is already prepared to support the procedure in both directions, it shall act as described in this sub-clause.

- a) Alternate Speech/Data (BS 61 according to 3GPP TS 02.02);
- b) Speech followed by Data (BS 81 according to 3GPP TS 02.02);
- c) Alternate Speech/Group 3 fax (Teleservice 61 according to 3GPP TS 02.03).

# 5.3.4.1 Service Description

This circuit switched service allows the two users on a point-to-point connection to use the connection between them for different information transfer during the same call, but not at the same time.

If the negotiation during call establishment leads to the recognition of the above mentioned services, the in-call modification procedure is allowed to be executed within the current call by changing from one call mode to the other.

In some cases the in-call modification procedure makes it necessary to change the channel configuration by allocating a new channel and in other cases to change channel configuration parameters while keeping the previously allocated channel. This change is determined by the network, which initiates either the channel assignment procedure, handover procedure or channel mode modify procedure (see sub-clause 3).

The capability and the initial mode desired must be identified by the mobile station by identifying each mode of operation with a separate information element during call establishment. Further the type of change between the modes must be identified by means of the repeat indicator:

- mode 1 "alternate" mode 2; or
- mode 1 "and then" mode 2.

# 5.3.4.2 Call establishment

For both mobile originating and mobile terminating calls, the normal call establishment procedures apply.

### 5.3.4.2.1 Mobile Originating Establishment

The service is requested by the originating mobile station by transferring a SETUP message to the network containing the *BC repeat indicator* IE, the *bearer capability 1* information element, and the *bearer capability 2* information element. The first mode of operation ("call mode") shall be indicated by the *bearer capability 1* information element and the second call mode by the *bearer capability 2* information element.

A low layer compatibility may optionally be specified for each call mode in a *low layer compatibility I* and *low layer compatibility II* information element. In that case:

- the SETUP message shall contain the *LLC repeat indicator* IE and both *low layer compatibility I* and *low layer compatibility II* information elements. The *low layer compatibility I* information element then corresponds to the *bearer capability 1* information element and the *low layer compatibility II* information element to the *bearer capability 2* information element;
- if no low layer compatibility specification applies for one of the two call modes, the corresponding low layer compatibility IE (*low layer compatibility I* or *low layer compatibility II*) shall indicate "not applicable";
- the LLC repeat indicator shall specify the same repeat indication as the BC repeat indicator IE.

Similarly, a high layer compatibility may optionally be specified for each call mode in a *high layer compatibility i* and *high layer compatibility ii* information element. In that case:

- the SETUP message shall contain the *HLC repeat indicator* IE and both *high layer compatibility i* and *high layer compatibility ii* information elements. The *high layer compatibility i* information element then corresponds to the *bearer capability 1* information element and the *high layer compatibility ii* information element to the *bearer capability 2* information element;
- if no high layer compatibility specification applies for one of the two call modes, the corresponding high layer compatibility IE (*high layer compatibility i* or *high layer compatibility ii*) shall indicate "not applicable";
- the *HLC repeat indicator* shall specify the same repeat indication as the *BC repeat indicator* IE.

The receiving entity shall ignore whether the *LLC repeat indicator* IE or *HLC repeat indicator* are contained in the message or not; it shall also ignore the repeat indication of an *LLC repeat indicator* IE or *HLC repeat indicator* IE. If the *low layer compatibility II* IE is not contained in the message and the *low layer compatibility I* IE is contained in the message, the receiving entity shall relate it to a call mode indicated in the message that does not specify speech (if any). If the *high layer compatibility ii* IE is not contained in the message and the *high layer compatibility ii* IE is contained in the message, the receiving entity shall relate it to a call mode indicated in the message that does not specify speech (if any).

The specific part of the network which is sensitive to the call mode shall examine each mode described in the bearer capabilities included in the SETUP message by performing compatibility checking as defined in Annex B. If as a result of this compatibility checking the network decides to reject the call, then the network shall initiate call clearing as specified in sub-clause 5.4 with the following causes:

- a) #57 "bearer capability not authorized";
- b) #58 "bearer capability not presently available";
- c) #65 "bearer service not implemented";
- d) #70 "only restricted digital information bearer capability is available".

### 5.3.4.2.2 Mobile Terminating Establishment

The service is indicated to the called mobile station by a SETUP message coded in the same manner as in the mobile originating call establishment. As specified for normal terminating call establishment, the service may be indicated by the called mobile station in the CALL CONFIRMED message.

The destination mobile station shall perform the compatibility checking as defined in Annex B for both required modes if indicated in the SETUP message. If as a result of compatibility checking the mobile station decides to reject the call, the mobile station shall initiate call clearing according to the procedures of sub-clause 5.4 with one of the following causes:

- a) #57 "bearer capability not authorized";
- b) #58 "bearer capability not presently available";
- c) #65 "bearer service not implemented";
- d) #88 "incompatible destination".

The mobile station may accept the call if the first mode indicated is free irrespective of whether the other mode is free or busy.

## 5.3.4.3 Changing the Call Mode

In order to change the call mode, the following in-call modification procedures shall be used.

Either side of the radio interface may act as the requesting user to invoke the in-call modification.

Upon each successful completion of the in-call modification procedure, the call changes to the next mode negotiated and agreed during the establishment phase of the call.

The in-call modification procedures are completely symmetrical at the radio interface.

NOTE: Considering a possible future evolution, in-call modification is specified as a symmetrical procedure.

### 5.3.4.3.1 Initiation of in-call modification

The procedure is initiated by the requesting originating side in the "active" state of the call. It shall send a MODIFY message including the new mode to be changed to; start timer T323; and enter the "mobile originating modify" state (mobile station side) or the "mobile terminating modify" state (network side). Any internal resources necessary to support the next call mode shall be reserved. The new mode given in the MODIFY message shall be one of those already negotiated and agreed during the establishment phase of the call. If the data call direction is different from the direction of the call setup a reverse call setup direction IE shall be included in the MODIFY message; otherwise this IE shall not be included. The MODIFY originating side shall stop sending Bm-channel information; and stop interpreting received Bm-channel information according to the old call mode.

Upon receipt of the MODIFY message, the destination side shall check to ensure that the requested call mode can still be supported and if so, it shall initiate the reservation of any resources necessary to support the next call mode and enter the "mobile originating modify" (network side) or "mobile terminating modify" state (mobile station side).

### 5.3.4.3.2 Successful completion of in-call modification

If the destination network/mobile station receives a MODIFY message with a new mode which is already the actual one of the call the network/mobile station shall remain in the "active" state; send a MODIFY COMPLETE message with the actual mode; and shall not initiate anything else.

If the requested mode is not the actual one and can be supported by the destination interface it shall change the channel configuration, if required, and step on to any internal resources necessary to support the next call mode. If the requested mode is a data or facsimile mode, it shall also perform the appropriate means to take the direction of the data call into account. After successful change of the channel configuration it shall start sending user information according to the next call mode; send a MODIFY COMPLETE message with the new call mode included and enter the "active" state (mobile station or network side). If the MODIFY message had contained a *reverse call setup direction* IE, the same IE shall be included in the MODIFY COMPLETE message.

In case of an alternate speech/data or alternate speech/facsimile group 3 service (refer to sub-clause 5.3.4) the old resources may still be kept reserved, in case of speech followed by data service they may be released.

Upon receipt of the MODIFY COMPLETE message the originating side shall: initiate the alternation to those resources necessary to support the next call mode; stop timer T323; and enter the "active" state (mobile station or network side). The reaction of the originating side if it had included a reverse call setup direction IE in the MODIFY message, but the destination side did not include the IE in the MODIFY COMPLETE message is implementation dependent.

### 5.3.4.3.3 Change of the channel configuration

In case the requested bearer capability cannot be supported by the current channel configuration the network shall initiate the assignment procedure and change the channel configuration accordingly.

### 5.3.4.3.4 Failure of in-call modification

### 5.3.4.3.4.1 Network rejection of in-call modification

If the network cannot support the change to the requested call mode or if the change of the channel configuration fails the network shall: release the resources which had been reserved for the alternation: send a MODIFY REJECT message with the old bearer capability and with cause # 58 "bearer capability not presently available" to the initiating mobile station; and enter the "active" state. If the change of the channel configuration fails, the network shall return to the internal resources required for the old call mode.

Upon receipt of the MODIFY REJECT message with the old bearer capability the initiating mobile station shall: stop timer T323; release any resources which had been reserved for the alternation; resume sending user channel information according to the present call mode; resume interpreting received user channel information according to the present call mode; and enter the "active" state.

### 5.3.4.3.4.2 Mobile station rejection of in-call modification

If the mobile station cannot support the change to the requested call mode, the mobile station shall: release any resources which had been reserved for the alternation; send a MODIFY REJECT message with the old bearer capability and cause # 58 "bearer capability not presently available", and enter the "active" state.

Upon receipt of the MODIFY REJECT message the network shall: stop timer T323, release any resources which had been reserved for the alternation.

### 5.3.4.3.4.3 Time-out recovery

Upon expiration of T323 in either the mobile station or the network the procedures for call clearing shall be initiated with cause # 102 "recovery on timer expiry".

## 5.3.4.4 Abnormal procedures

If a MODIFY, MODIFY COMPLETE or MODIFY REJECT message is received in the "disconnect indication", "disconnect request" (mobile station side only) or "release request" state then the received message shall be discarded and no action shall be taken.

If a MODIFY COMPLETE message indicating a call mode which does not correspond to the requested one is received or if a MODIFY REJECT message indicating a call mode which does not correspond to the actual one is received then the received message shall be discarded and no action shall be taken.

If a MODIFY message indicating a call mode which does not belong to those negotiated and agreed during the establishment phase of the call, is received, then a MODIFY REJECT message with the actual call mode and with cause # 57 "bearer capability not authorized" shall be sent back.





Figure 5.10a/3GPP TS 04.08: In-call modification sequence initiated by MS





# 5.3.5 User initiated service level up- and downgrading

The user initiated service level up- and downgrading is applicable for non-transparent multislot data services, only. By means of this procedure the user can request a change of the "maximum number of traffic channels" and/or "wanted air interface user rate" parameters, to be assigned by the network.

### 5.3.5.1 Initiation of service level up- and downgrading

The procedure is initiated by the mobile station in the "active" state of the call. It shall:

- send a MODIFY message including the wanted value of the "maximum number of traffic channels" and/or the "wanted air interface user rate" parameters;
- not change any of the other, possibly negotiated, parameters of the bearer capability information element;
- start timer T323; and
- enter the "mobile originating modify" state.

Any internal resources necessary to support the next service parameters shall be reserved. If a dual service was negotiated at call setup, the mobile station shall initiate the service level up- or down-grading only during the data phase of the dual service.

Upon receipt of the MODIFY message, the network shall check if the indicated maximum number of traffic channels can be supported and enter the "mobile originating modify" state.

### 5.3.5.2 Successful completion of service level up- and downgrading

The network may upon reception of the MODIFY message initiate a change of the channel configuration assigned to the mobile station.

As a response to the MODIFY message the network sends a MODIFY COMPLETE message including the bearer capability negotiated at call setup and enters the "active" state.

Upon receipt of the MODIFY COMPLETE message the mobile station shall stop timer T323 and enter the "active" state.

### 5.3.5.3 Rejection of service level up- and downgrading

If a change of bearer service is requested together with a change of the "maximum number of traffic channels" and/or the "wanted air interface user rate", or if the current used service is not a data service where up- and downgrading is applicable, or if the receiver chooses not to grant the request, the network shall:

- send a MODIFY REJECT message with bearer capability negotiated at call setup and with cause #58 "bearer capability not presently available";
- enter the "active" state.

Upon receipt of the MODIFY REJECT message with the bearer capability negotiated at call setup, the mobile station shall: stop timer T323 and enter the "active" state.

### 5.3.5.4 Time-out recovery

Upon expiration of T323 in the mobile station the procedures for call clearing shall be initiated with cause #102 "recovery on timer expiry".

# 5.4 Call clearing

# 5.4.1 Terminology

The following terms are used in the present document in the description of clearing procedures:

- A traffic channel (see 3GPP TS 04.03) is "connected" when the channel is part of a circuit-switched connection established according to the present document.
- A traffic channel is "disconnected" when the channel is no longer part of a circuit-switched connection, but is not yet available for use in a new connection.

# 5.4.2 Exception conditions

Under normal conditions, the call control entity of the mobile station or of the network initiates call clearing by sending a DISCONNECT message to its peer entity; then both entities follow the procedures defined in sub-clauses 5.4.3 and 5.4.4 respectively.

As an exception to the above rule, the call control entity of the mobile station or of the network, in response to a SETUP or START CC or CC-ESTABLISHMENT CC-ESTABLISHMENT CONFIRMED or RECALL message, can reject a call by stopping all running call control timers, responding with a RELEASE COMPLETE message, releasing the MM connection, and returning to the "null" state, provided no other response has previously been sent.

As a further exception, the call control entity of the network may initiate call clearing by stopping all running call control timers, sending a RELEASE message, starting timer T308, and entering the "release request" state.

NOTE 1: This way to initiate call clearing by sending a RELEASE message should not be used by the network:

- if in-band tones/announcements are provided and the network decides to use the procedure described in sub-clauses 5.4.4.1.1.1 or 5.4.4.2.1;
- if the network wants to have the opportunity to respond to information sent by the mobile station during call clearing, e.g. when the network indicates that "CCBS activation is possible".

A call control entity shall accept an incoming RELEASE COMPLETE message used to initiate the call clearing even though the cause information element is not included.

A control entity shall accept an incoming RELEASE message used to initiate the call clearing even though the cause information element is not included.

Furthermore, a call control entity shall regard an incoming RELEASE COMPLETE message as consistent with any of its states; a call control entity shall regard an incoming RELEASE message as consistent with any of its states except the null state: a call control entity of the mobile station shall regard an incoming DISCONNECT message as consistent with any of its call control states except the "null" state, the "release request" state, and the "disconnect indication" state; a call control entity of the network shall regard an incoming DISCONNECT message as consistent with any of its call control states except the "null" state, the "release request" state, and the "disconnect indication" state; a call control entity of the network shall regard an incoming DISCONNECT message as consistent with any of its call control states except the "null" state and the "release request" state.

NOTE 2: This allows the introduction of shorter call clearing procedures in the future.

# 5.4.3 Clearing initiated by the mobile station

## 5.4.3.1 Initiation of call clearing

Apart from the exceptions identified in sub-clause 5.4.2, the call control entity of the mobile station shall initiate clearing by: stopping all running call control timers, sending a DISCONNECT message; starting timer T305; and entering the "disconnect request" state.

## 5.4.3.2 Receipt of a DISCONNECT message from the mobile station

The call control entity in the network in any state except the "null" state and the "release request" state shall, upon receipt of a DISCONNECT message:

- stop all running call control timers;
- initiate procedures to clear the network connection and the call to the remote user;
- send a RELEASE message to its peer entity;
- start timer T308; and
- enter the "release request" state.
- NOTE: The RELEASE message has only local significance and does not imply an acknowledgement of clearing from the remote user.

# 5.4.3.3 Receipt of a RELEASE message from the network

The call control entity of the mobile station in any state except the "null" state and the "release request" state, shall, upon receipt of a RELEASE message: stop all running call control timers; send a RELEASE COMPLETE message; release the MM connection; and return to the "null" state.

## 5.4.3.4 Receipt of a RELEASE COMPLETE message from the mobile station

A call control entity of the network in any call control state shall, upon receipt of a RELEASE COMPLETE message from its peer entity in the mobile station: stop all running call control timers; release the MM connection; and return to the "null" state.

## 5.4.3.5 Abnormal cases

The call control entity of the mobile station in the "disconnect request" state, shall upon expiry of timer T305: send a RELEASE message to the network with the cause number originally contained in the DISCONNECT message and optionally, a second cause information element with cause #102 "recovery on timer expiry", start timer T308, and enter the "release request" state.

The call control entity of the network in the "release request" state, shall, at first expiry of timer T308, retransmit the RELEASE message, start timer T308, and stay in the "release request" state. At second expiry of timer T308, the call control entity of the network shall: release the MM connection; and return to the "null" state.

# 5.4.4 Clearing initiated by the network

Apart from the exception conditions identified in sub-clause 5.4.2, the call control entity of the network shall initiate clearing by: sending a DISCONNECT message; and entering the "disconnect indication" state. The DISCONNECT message is a local invitation to clear the call.

NOTE: When the network initiates clearing by sending a RELEASE message, the procedures described in subclauses 5.4.3., 5.4.3.4 and 5.4.3.5 are followed.

A mobile station that does not support the "Prolonged Clearing Procedure" shall comply with the requirements of subclause 5.4.4.1 and shall ignore sub-clause 5.4.4.2. A mobile station that supports the "Prolonged Clearing Procedure" shall comply with the requirements of sub-clause 5.4.4.2 and shall ignore sub-clause 5.4.4.1.

# 5.4.4.1 Clearing initiated by the network: mobile does not support "Prolonged Clearing Procedure"

Sub-clause 5.4.4.1 only applies to mobile stations that do not support the "Prolonged Clearing Procedure" option.

### 5.4.4.1.1 Clearing when tones/announcements provided

When in-band tones/announcements are provided (see sub-clause 5.5.1), the call control entity of the network may initiate clearing by sending a DISCONNECT message containing progress indicator #8 "in-band information or appropriate pattern now available", starting timer T306, and entering the "disconnect indication" state.

### 5.4.4.1.1.1 Receipt of a DISCONNECT message with progress indicator #8 from the network

The call control entity of the MS in any state except the "null" state, the "disconnect indication" state, and the "release request" state, shall, upon receipt of a DISCONNECT message with progress indicator #8:

- i) if an appropriate speech traffic channel is not connected, continue clearing as defined in sub-clause 5.4.4.1.2.1 without connecting to the in-band tone/announcement;
- ii) if an appropriate speech traffic channel is connected, attach the user connection for speech if it is not yet attached and enter the "disconnect indication" state. In that state, if upper layers request the clearing of the call, the call control entity of the MS shall proceed as defined in sub-clause 5.4.4.1.2.1.

### 5.4.4.1.1.2 Expiry of timer T306

The call control entity of the network, having entered the "disconnect indication" state after sending a disconnect message with the progress indicator #8, shall, upon expiry of timer T306, continue clearing by sending a RELEASE message with the cause number originally contained in the DISCONNECT message; starting timer T308; and entering the "release request" state.

### 5.4.4.1.2 Clearing when tones/announcements not provided

When in-band tones and announcements are not provided, the call control entity of the network shall initiate call clearing by stopping all running call control timers, sending a DISCONNECT message without progress indicator, starting timer T305 and entering the "disconnect indication" state.

# 5.4.4.1.2.1 Receipt of a DISCONNECT message without progress indicator or with progress indicator different from #8 from the network

The call control entity of the mobile station in any state except the "null" state, the "disconnect indication" state, and the "release request" state, shall, upon the receipt of a DISCONNECT message without progress indicator information element or with progress indicator different from #8:

- stop all running call control timers;
- send a RELEASE message;
- start timer T308; and
- enter the "release request" state.

### 5.4.4.1.2.2 Receipt of a RELEASE message from the mobile station

The call control entity of the network in any state except the "null" state and the "release request" state, shall, upon receipt of a RELEASE message: stop all running call control timers; send a RELEASE COMPLETE message; release the MM connection; and return to the "null" state.

### 5.4.4.1.2.3 Abnormal cases

The call control entity of the network, having entered the "disconnect indication" state after sending a DISCONNECT message without progress indicator or with progress indicator different from #8, shall upon expiry of timer T305: send a RELEASE message to the mobile station with the cause number originally contained in the DISCONNECT message; start timer T308; and enter the "release request" state. In addition to the original clearing cause, the RELEASE message may contain a second cause information element with cause #102 "recovery on timer expiry".

### 5.4.4.1.3 Completion of clearing

A call control entity of the mobile station in any call control state shall, upon receipt of a RELEASE COMPLETE message from its peer entity in the network: stop all running call control timers ; release the MM connection; and return to the "null" state.

### 5.4.4.1.3.1 Abnormal cases

The call control entity of the mobile station in the "release request" state shall at first expiry of timer T308 retransmit the RELEASE message and restart timer T308. At second expiry of timer T308, the call control entity of the mobile station shall: release the MM connection; and return to the "null" state.

# 5.4.4.2 Clearing initiated by the network: mobile supports "Prolonged Clearing Procedure"

Sub-clause 5.4.4.2 only applies to mobile stations that support the "Prolonged Clearing Procedure" option.

# 5.4.4.2.1 Clearing when tones/announcements provided and the network does not indicate that "CCBS activation is possible"

When in-band tones/announcements are provided (see sub-clause 5.5.1) and CCBS is not applicable, the call control entity of the network may initiate clearing by sending a DISCONNECT message containing progress indicator #8 "inband information or appropriate pattern now available", either not containing an *Allowed Actions* IE or containing an *Allowed Actions* IE indicating "CCBS activation is not possible", starting timer T306, and entering the "disconnect indication" state.

### 5.4.4.2.1.1 Receipt of a DISCONNECT message

The call control entity of the MS in any state except the "null" state, the "disconnect indication" state, and the "release request" state, shall, upon receipt of a DISCONNECT message with progress indicator #8 and, either not containing an *Allowed Actions* IE or containing an *Allowed Actions* IE indicating "CCBS activation is not possible":

- i) if an appropriate speech traffic channel is not connected:
  - stop all running call control timers;
  - send a RELEASE message;
  - start timer T308; and
  - enter the "release request" state.
  - not connect to the in-band tone/announcement;
- ii) if an appropriate speech traffic channel is connected, attach the user connection for speech if it is not yet attached and enter the "disconnect indication" state. In that state, if upper layers request the clearing of the call, the call control entity of the MS shall:
  - stop all running call control timers;
  - send a RELEASE message;
  - start timer T308; and
  - enter the "release request" state.

### 5.4.4.2.1.2 Expiry of timer T306

The call control entity of the network, having entered the "disconnect indication, shall, upon expiry of timer T306, continue clearing by sending a RELEASE message with the cause number originally contained in the DISCONNECT message; starting timer T308; and entering the "release request" state.

### 5.4.4.2.2 Clearing when the network indicates that "CCBS activation is possible"

When Activation of CCBS is possible, the call control entity of the network may initiate clearing by sending a DISCONNECT message containing the *Allowed Actions* IE with an indication that "Activation of CCBS is possible" and starting T338. Optionally, progress indicator #8 "in-band information or appropriate pattern now available" may also be contained in the DISCONNECT message (in which case, T338 shall not be greater than T306).

### 5.4.4.2.2.1 Receipt of a DISCONNECT

Relative to the current state the following procedures apply:

- The call control entity of the MS in the "null" state, the "disconnect indication" state and the "release request" state, shall, upon receipt of a DISCONNECT message react as described in sub-clause 8.
- The call control entity of the MS in the "disconnect request" state, shall, upon receipt of a DISCONNECT message:
  - stop all running call control timers;

- send a RELEASE message;
- start timer T308; and
- enter the "release request" state.
- The call control entity of the MS in any other states, shall, upon receipt of a DISCONNECT message with an *Allowed Actions* IE indicating "Activation of CCBS is possible" pass the "Activation of CCBS is possible" indication to the upper layer, enter the "disconnect indication" state, stop all running call control timers and await a response from the upper layers.

If the DISCONNECT message contained the progress indicator #8 "in-band information or appropriate pattern now available" and an appropriate speech traffic channel is connected, then the MS shall attach the user connection for speech if it is not yet attached. If the DISCONNECT message did not contain the progress indicator #8 "in-band information or appropriate pattern now available" any connected speech traffic channel shall be disconnected.

Response from the upper layers:

- i) If the upper layers request the clearing of the call, the call control entity of the MS shall:
  - stop all running call control timers;
  - send a RELEASE message;
  - start timer T308; and
  - enter the "release request" state.
- ii) If the upper layers request that the "CCBS activation is to be attempted" then the MS shall
  - send a RELEASE message containing a *Facility* IE including an Invoke=CCBSRequest to the network;
  - stop all running call control timers;
  - start timer T308; and
  - enter the "release request" state.

If an appropriate speech traffic channel is connected, transmission of this RELEASE message shall not cause it to be disconnected.

### 5.4.4.2.2.2 Expiry of timer T338

The call control entity of the network, having entered the "disconnect indication" state after sending a DISCONNECT message with an *Allowed Actions* IE indicating "Activation of CCBS is possible" shall, upon expiry of timer T338, continue clearing by sending a RELEASE message with the cause number originally contained in the DISCONNECT message; starting timer T308; and entering the "release request" state.

# 5.4.4.2.3 Clearing when tones/announcements are not provided and the network does not indicate that "CCBS activation is possible"

When in-band tones and announcements are not provided, and, the network does not wish to indicate in the *Allowed Actions* IE that "CCBS is possible", the call control entity of the network shall initiate call clearing by stopping all running call control timers, sending a DISCONNECT message without progress indicator, either without the *Allowed Actions* IE or with the *Allowed Actions* IE indicating that "CCBS is not possible", starting timer T305 and entering the "disconnect indication" state.

### 5.4.4.2.3.1 Receipt of a DISCONNECT message

The call control entity of the mobile station in any state except the "null" state, the "disconnect indication" state, and the "release request" state, shall, upon the receipt of a DISCONNECT message either without progress indicator information element or with progress indicator different from #8, and, either without the *Allowed Actions* IE or with the *Allowed Actions* IE indicating that "CCBS is not possible":

- stop all running call control timers;

- send a RELEASE message;
- start timer T308; and
- enter the "release request" state.

#### 5.4.4.2.3.2 Abnormal cases

The call control entity of the network, having entered the "disconnect indication", shall upon expiry of timer T305: send a RELEASE message to the mobile station with the cause number originally contained in the DISCONNECT message; start timer T308; and enter the "release request" state.

### 5.4.4.2.4 Receipt of a RELEASE message from the mobile station

#### 5.4.4.2.4.1 Release, CCBS not requested

For a network that does not support the "CCBS activation" option:

The call control entity of the network in any state except the "null" state and the "release request" state, shall, upon receipt of a RELEASE message: stop all running call control timers; send a RELEASE COMPLETE message; release the MM connection; and return to the "null" state.

For a network that does support the "CCBS activation" option:

The call control entity of the network in any state except the "null" state and the "release request" state, shall, upon receipt of a RELEASE message without a *Facility* IE including an Invoke=CCBSRequest: stop all running call control timers; send a RELEASE COMPLETE message; release the MM connection; and return to the "null" state.

#### 5.4.4.2.4.2 Release, CCBS Requested

For a network that does not support the "CCBS activation" option:

The call control entity of the network in any state except the "null" state and the "release request" state, shall, upon receipt of a RELEASE message: stop all running call control timers; send a RELEASE COMPLETE message; release the MM connection; and return to the "null" state.

For a network that does support the "CCBS activation" option:

The call control entity of the network in any state except the "null" state and the "release request" state, shall, upon receipt of a RELEASE message containing a *Facility* IE including an Invoke=CCBSRequest: stop all running call control timers; then attempt to activate the recall; then send a RELEASE COMPLETE message indicating the success or failure of the recall activation attempt; release the MM connection; and return to the "null" state.

### 5.4.4.2.5 Completion of clearing

A call control entity of the mobile station in any call control state shall, upon receipt of a RELEASE COMPLETE message from its peer entity in the network: stop all running call control timers ; release the MM connection; and return to the "null" state.

#### 5.4.4.2.5.1 Abnormal cases

The call control entity of the mobile station in the "release request" state shall at first expiry of timer T308 retransmit the RELEASE message and restart timer T308. At second expiry of timer T308, the call control entity of the mobile station shall: release the MM connection; and return to the "null" state.

The retransmitted RELEASE message need not contain the *Facility* IE including an Invoke=CCBSRequest, even if the original RELEASE message did contain this IE.

# 5.4.5 Clear collision

Clear collision occurs when both the mobile station and the network simultaneously transfer DISCONNECT messages specifying the same call.

The behaviour of the network call control entity receiving a DISCONNECT message whilst in the "disconnect indication" state is specified in sub-clause 5.4.3. The behaviour of the MS call control entity receiving a DISCONNECT message whilst in the "disconnect request" state is defined in sub-clause 5.4.4.

Clear collision can also occur when both sides simultaneously transfer RELEASE messages related to the same call. The entity receiving such a RELEASE message whilst within the "release request" state shall: stop timer T308; release the MM connection; and enter the "null" state (without sending a RELEASE COMPLETE message).

# 5.5 Miscellaneous procedures

# 5.5.1 In-band tones and announcements

When the network wants to make the mobile station attach the user connection (e.g. in order to provide in-band tones/announcement) before the mobile station has reached the "active" state of a call, the network may include a *progress indicator* IE indicating user attachment in a suitable CC message:

- Either it includes the IE in a SETUP, CALL PROCEEDING, ALERTING, or CONNECT message that is send during call establishment.
- it sends a PROGRESS message containing the IE.

A *progress indicator* IE indicates user attachment if it specifies a progress description in the set  $\{1, 2, 3\}$  or in the set  $\{6, 7, 8, ..., 20\}$ .

On reception of a SETUP, CALL PROCEEDING, ALERTING, CONNECT, or PROGRESS message the mobile station shall proceed as specified elsewhere in sub-clause 5; if the *progress indicator* IE indicated user attachment and a speech mode traffic channel is appropriate for the call the mobile station shall in addition: attach the user connection for speech as soon as an appropriate channel in speech mode is available. (If a new order to attach the user connection is received before the attachment has been performed, the new order shall supersede the previous one.)

Under certain conditions the MS will have to attach the user connection before the CONNECT message. It is up to the network to ensure that no undesired end-to-end through connection takes place during the establishment of a MT call.

NOTE: This allows the use of *progress indicator* IEs independently from the channel modes appropriate for the call.

# 5.5.2 Call collisions

Call collisions as such cannot occur at the network. Any simultaneous mobile originating or mobile terminating calls are dealt with separately assigned and different transaction identifiers.

# 5.5.3 Status procedures

## 5.5.3.1 Status enquiry procedure

Whenever a call control entity wishes to check the call state of its peer entity, it may initiate the status enquiry procedure.

NOTE: This may, in particular, apply to procedural error conditions described in sub-clause 8.

A call control entity initiates the status enquiry procedure by sending the STATUS ENQUIRY message and starting timer T322. While timer T322 is running, the call control entity shall not send further STATUS ENQUIRY messages.

Upon receipt of a STATUS ENQUIRY message, the receiver shall respond with a STATUS message, reporting the current call state and cause value #30 "response to STATUS ENQUIRY". Receipt of the STATUS ENQUIRY shall not result in a state change relating to any protocol and connection of the receiver.

If a STATUS message is received that contains cause value #30 "response to status enquiry", timer T322 shall be stopped and further appropriate actions taken, based on the information in that STATUS message, relative to the current state of the receiver of the STATUS message. These further "appropriate actions" are implementation dependent. However, the actions prescribed in sub-clause 5.5.3.2 shall apply.

If a clearing message is received while timer T322 is running, timer T322 shall be stopped, and call clearing shall continue.

If timer T322 expires, the STATUS ENQUIRY message may be retransmitted maximally once. If T322 expires after the STATUS ENQUIRY has been transmitted the maximum number of times, clearing of the call shall be initiated with cause value #41, "temporary failure", in the first call clearing message.

# 5.5.3.2 Reception of a STATUS message by a CC entity

### 5.5.3.2.1 STATUS message with incompatible state

On receipt of a STATUS message reporting an incompatible call control state, the receiving entity shall clear the call by sending a RELEASE COMPLETE message with cause # 101 "message not compatible with protocol state". The reported call control state is incompatible if the combination of call control states at the sender and receiver side cannot occur, do not match or cannot be aligned by actions of the receiver; the exact definition is implementation dependent.

### 5.5.3.2.2 STATUS message with compatible state

A STATUS message may be received indicating a compatible call state but containing one of the following causes:

- # 95 "semantically incorrect message"; or
- # 96 "invalid mandatory information"; or
- # 97 "message type non-existent or not implemented"; or
- # 98 "message type not compatible with protocol state"; or
- # 99 "information element non-existent or not implemented"; or
- # 100 "conditional IE error".

This indicates that the transmitter of the STATUS message was unable to accept some information sent by the recipient of the STATUS message. This allow the recipient to retransmit some or all of the information. Other actions are possible and are implementation dependent; they may include releasing the call.

# 5.5.4 Call re-establishment, mobile station side

This sub-clause describes the internal handling in the mobile station as far as call control is concerned.

### 5.5.4.1 Indication from the mobility management sublayer

When a MM connection is active, an indication may be given by the MM sublayer to the call control entity to announce that the current MM connection has been interrupted but might be re-established on request of call control.

## 5.5.4.2 Reaction of call control

Depending whether call re-establishment is allowed or not and on its actual state, call control shall decide to either request re-establishment or to release the MM connection.

a) Re-establishment not required

If the call is in the call establishment or call clearing phase, i.e. any state other than the "active" state or the "mobile originating modify" state, call control shall release the MM connection.

#### b) Re-establishment required

If the call is in the "active" state or "mobile originating modify" state, the indication from MM that reestablishment is possible shall cause call control to request re-establishment from the MM connection, suspend any further message to be sent and await the completion of the re-establishment procedure.

## 5.5.4.3 Completion of re-establishment

Call Control is notified when the MM connection is re-established and shall then resume the transmission of possibly suspended messages and resume user data exchange when an appropriate channel is available.

### 5.5.4.4 Unsuccessful outcome

If the attempt to re-establish the connection was unsuccessful, the MM connection will be released and a release indication will be given to call control, see sub-clause 4.5.1.6.

# 5.5.5 Call re-establishment, network side

This sub-clause describes the handling in the network as far as call control is concerned.

### 5.5.5.1 State alignment

After a successful call re-establishment it is a network responsibility to identify (e.g. by using the status enquiry procedure, if needed, and resolve, if possible, any call state or auxiliary state mismatch between the network and the mobile station.

# 5.5.6 Progress

At any time during the establishment or release of a call and during an active call the network may send a PROGRESS message to the mobile station.

On receipt of a PROGRESS message during the establishment or release of a call the mobile station shall stop all call control timers related to that call.

NOTE: If the PROGRESS has been received before the receipt of a CALL PROCEEDING message, the mobile station will not start timer T310 on receipt of a CALL PROCEEDING message, see sub-clause 5.2.1.1.3.

MS Network
PROGRESS

#### Figure 5.11/3GPP TS 04.08: Progress

# 5.5.7 DTMF protocol control procedure

Dual Tone Multi Frequency (DTMF) is an inband one out of four plus one out of four signalling system primarily used from terminal instruments in telecommunication networks. The support of DTMF in the network is described in 3GPP TS 03.14.

The mobile station shall be capable of transmitting DTMF messages if and only if the mobile station has the user connection for speech attached and an appropriate channel is available.

The transaction identifier used by the DTMF messages shall be that of the attached speech call.

- NOTE 1: The present document means that DTMF messages can generally be sent in the active state of a call in speech transmission mode or when a traffic channel is available during setup or release and the *progress indicator* IE has been received.
- NOTE 2: Since the DTMF protocol messages are sent in a store and forward mode on the signalling channels the control of the device at the far end may be delayed dependent on the load or quality of the channels.

NOTE 3: The procedures described in this paragraph support DTMF only in the direction mobile station to network.

### 5.5.7.1 Start DTMF request by the mobile station

A user may cause a DTMF tone to be generated e.g. by depression of a key in the mobile station. The relevant action is interpreted by the mobile station as a requirement for a DTMF digit to be sent in a START DTMF message on an established FACCH. This message contains the value of the digit to be transmitted (0, 1, ..., 9, A, B, C, D, \*, #).

Only a single digit will be transferred in each START DTMF message.

### 5.5.7.2 Start DTMF response by the network

Upon receiving the START DTMF message the network will reconvert the received digit back into a DTMF tone which is applied toward the remote user and returns a START DTMF ACKNOWLEDGE message to the mobile station. This acknowledgement may be used in the mobile station to generate an indication as a feedback for a successful transmission.

If the network cannot accept the START DTMF message a START DTMF REJECT message will be sent to the mobile station.

## 5.5.7.3 Stop DTMF request by the mobile station

When the user indicates that the DTMF sending should cease e.g. by releasing the key the mobile station will send a STOP DTMF message to the network.

### 5.5.7.4 Stop DTMF response by the network

Upon receiving the STOP DTMF message the network will stop sending the DTMF tone and return a STOP DTMF ACKNOWLEDGE message to the mobile station.

### 5.5.7.5 Sequencing of subsequent start DTMF requests by the mobile station

The minimum length of tone generated by the network should be according to CEPT recommendation T/CS 46-02.

The minimum gap between two subsequent tones should be according to CEPT recommendation T/CS 46-02.

There is no defined maximum length to the tone, which will normally cease when a STOP DTMF message is received from the MS. However, the operator may choose to put a pre-defined time limit on the duration of tones sent.

The appropriate sequencing of DTMF control messages is shown in figures 5.8 and 5.9.

- NOTE 1: The network may implement the time limit option where the DTMF tone duration is controlled by the network irrespective of the receipt of a STOP DTMF message from the mobile station.
- NOTE 2: The transmission time of the messages over the radio interface on FACCH/F or FACCH/H, see 3GPP TS 05.02, ensures that the minimum length of tones and minimum gap between tones according to T/CS 46-02 are fulfilled.

Mobile Station	Network
START DTMF	>
START DTMF ACK	
STOP DTMF	>
STOP DTMF ACK	

ß

#### Figure 5.8/3GPP TS 04.08: Single DTMF transmission

Mobile Station	Network	
START DTMF (x)	>	
START DTMF ACK		
STOP DTMF		ß
STOP DTMF ACK	>	
START DTMF (y)	·	ß
START DTMF ACK		
·		
· · ·		

#### Figure 5.9/3GPP TS 04.08: Multiple DTMF transmission

# 6 Support for packet services

This chapter contains the description of the procedures for the session management of GPRS point-to-point data services at the radio interface (Reference point  $U_m$ ).

# 6.1 GPRS Session management

# 6.1.1 General

The main function of the session management (SM) is to support PDP context handling of the user terminal. The SM comprises procedures for

- identified PDP context activation, deactivation and modification; and
- anonymous PDP context activation and deactivation.

SM procedures for identified access can only be performed if a GMM context has been established between the MS and the network. If no GMM context has been established, the MM sublayer has to initiate the establishment of a GMM context by use of the GMM procedures as described in chapter 4. After GMM context establishment, SM uses services offered by GMM (see 3GPP TS 04.07 [20]). Ongoing SM procedures are suspended during GMM procedure execution.

For anonymous access no GMM context is established.

### 6.1.1.1 Radio resource sublayer address handling for anonymous access

In the case of anonymous access, no P-TMSI shall be used by the MS or by the network. The MS shall use a randomly selected random TLLI for transmission of the ACTIVATE AA PDP CONTEXT REQUEST message in order to activate the AA PDP context.

Upon receipt of the ACTIVATE AA PDP CONTEXT REQUEST message, the network assigns an auxiliary TLLI (A-TLLI) to the AA PDP context and transmits the assigned A-TLLI to the MS. After receipt of the assigned A-TLLI, the MS shall use it for further data transmission to the network for the lifetime of the AA PDP context.

# 6.1.2 Session management states

In this sub-clause, the SM states are described for one SM entity (see 3GPP TS 04.07 [20]). Each SM entity is associated with one PDP context. sub-clause 6.1.2.1 describes the SM states in the MS and sub-clause 6.1.2.2 describes the SM states on the network side.

## 6.1.2.1 Session management states in the MS

In this sub-clause, the possible states of an SM entity in the mobile station are described. As illustrated in figure 6.1/3GPP TS 04.08 there are four SM states in the MS.

### 6.1.2.1.1 PDP-INACTIVE

This state indicates that no PDP context exists.

### 6.1.2.1.2 PDP-ACTIVE-PENDING


This state exists when PDP context activation was requested by the MS.

### 6.1.2.1.3 PDP-INACTIVE-PENDING

This state exists when deactivation of the PDP contexts was requested by the MS.

### 6.1.2.1.4 PDP-ACTIVE

This state indicates that the PDP context is active.



DR: GMMSM-DATA-REQUEST (Message), i.e. message sent by an MS DI: GMMSM-DATA-INDICATION (Message), i.e. message received by an MS

### Figure 6.1/3GPP TS 04.08: Session management states in the MS (overview)

### 6.1.2.2 Session management states on the network side

In this sub-clause, the possible states of an SM entity on the network side are described. As illustrated in figure 6.2/3GPP TS 04.08 there are five SM states on the network side.

### 6.1.2.2.1 PDP-INACTIVE

This state indicates that the PDP context is not active.

## 6.1.2.2.2 PDP-ACTIVE-PENDING

This state exists when the PDP context activation was initiated by the network.

### 6.1.2.2.3 PDP-INACTIVE-PENDING


This state exists when deactivation of the PDP context was requested by the network.

### 6.1.2.2.4 PDP-ACTIVE

This state indicates that the PDP context is active.

### 6.1.2.2.5 PDP-MODIFY-PENDING

This state exists when modification of the PDP context was requested by the network.



DR: GMMSM-DATA-REQUEST (Message), i.e. message sent by network DI: GMMSM-DATA-INDICATION (Message), i.e. message received by the network

### Figure 6.2/3GPP TS 04.08: Session management states on the network side (overview)

# 6.1.3 Session Management procedures

## 6.1.3.1 PDP context activation

The purpose of this procedure is to establish a PDP context between the MS and the network for a specific QoS on a specific NSAPI. The PDP context activation may be initiated by the MS or the initiation may be requested by the network.

### 6.1.3.1.1 Successful PDP context activation initiated by the mobile station

In order to request a PDP context activation, the MS sends an ACTIVATE PDP CONTEXT REQUEST message to the network, enters the state PDP-ACTIVE-PENDING and starts timer T3380. The message contains the selected NSAPI, PDP type and, if the MS requests a static address, the PDP address. The MS shall ensure that the selected NSAPI is not currently being used by another Session Management entity in the MS.

Upon receipt of an ACTIVATE PDP CONTEXT REQUEST message, the network selects a radio priority level based on the QoS negotiated and may reply with an ACTIVATE PDP CONTEXT ACCEPT message. Upon receipt of the message ACTIVATE PDP CONTEXT ACCEPT the MS shall stop timer T3380, shall enter the state PDP-ACTIVE and shall initiate establishment of the logical link for the LLC SAPI indicated by the network with the offered QoS and selected radio priority level if no logical link has been already established for that SAPI. If the offered QoS parameters received from the network differ from the QoS requested by the MS, the MS shall either accept the negotiated QoS or initiate the PDP context deactivation procedure. If the LLC SAPI indicated by the network can not be supported by the MS, the MS shall initiate the PDP context deactivation procedure.

### 6.1.3.1.2 Successful PDP context activation requested by the network

In order to request a PDP context activation, the network sends a REQUEST PDP CONTEXT ACTIVATION message to the MS and starts timer T3385. If available, the APN shall be included in the REQUEST PDP CONTEXT ACTIVATION message.

Upon receipt of a REQUEST PDP CONTEXT ACTIVATION message, the MS shall than either initiate the PDP context activation procedure as described in the previous sub-clause or shall reject the activation request by sending a REQUEST PDP CONTEXT ACTIVATION REJECT message as described in sub-clause 6.1.3.1.4. The value of the reject cause IE of the REQUEST PDP CONTEXT ACTIVATION REJECT message shall indicate the reason for rejection, e.g. "insufficient resources to activate another context".

The ACTIVATE PDP CONTEXT REQUEST message sent by the MS in order to initiate the PDP context activation procedure shall contain the PDP address, PDP Type and APN requested by the network in the REQUEST PDP CONTEXT ACTIVATION message.

Upon receipt of the ACTIVATE PDP CONTEXT REQUEST message, the network shall stop timer T3385.

The same procedures then apply as described for MS initiated PDP context activation.

### 6.1.3.1.3 Unsuccessful PDP context activation initiated by the MS

Upon receipt of an ACTIVATE PDP CONTEXT REQUEST message the network may reject the MS initiated PDP context activation by sending an ACTIVATE PDP CONTEXT REJECT message to the MS. The message shall contain a cause code that typically indicates one of the following causes:

- # 26: insufficient resources;
- # 27: missing or unknown APN;
- # 28: unknown PDP address or PDP type;
- # 29: user authentication failed;
- # 30: activation rejected by GGSN;
- # 31: activation rejected, unspecified;
- # 32: service option not supported;
- # 33: requested service option not subscribed;
- # 34: service option temporarily out of order;
- # 35: NSAPI already used; or
- # 95 111: protocol errors.

Upon receipt of an ACTIVATE PDP CONTEXT REJECT message, the MS shall stop timer T3380 and enter/remain in state PDP-INACTIVE.

#### 6.1.3.1.4 Unsuccessful PDP context activation requested by the network

Upon receipt of the REQUEST PDP CONTEXT ACTIVATION message, the MS may reject the network requested PDP context activation by sending the REQUEST PDP CONTEXT ACTIVATION REJECT message to the network. The message contains the same TI as included in the REQUEST PDP CONTEXT ACTIVATION and an additional cause code that typically indicates one of the following causes:

- # 26: insufficient resources;
- # 31: activation rejected, unspecified;
- # 40: feature not supported; or
- #95 111: protocol errors.

The network shall stop timer T3385 and enter state PDP-INACTIVE.

#### 6.1.3.1.5 Abnormal cases

The following abnormal cases can be identified:

- a) Expiry of timers
  - In the mobile station:

On the first expiry of the timer T3380, the MS shall resend the ACTIVATE PDP CONTEXT REQUEST and shall reset and restart timer T3380. This retransmission is repeated four times, i.e. on the fifth expiry of timer T3380, the MS shall release all resources possibly allocated for this invocation and shall abort the procedure; no automatic PDP context activation re-attempt shall be performed.

On the network side:

On the first expiry of the timer T3385, the network shall resent the message REQUEST PDP CONTEXT ACTIVATION and shall reset and restart timer T3385. This retransmission is repeated four times, i.e. on the fifth expiry of timer T3385, the network shall release possibly allocated resources for this activation and shall abort the procedure.

b) Collision of MS initiated and network requested PDP context activation

Dynamic PDP address collision case:

If the MS uses dynamic PDP addressing that turns out to collide with the network requested PDP address, then there is no detection of collision specified but left for network implementation.

Static PDP address collision detected within the mobile station:

A collision of an MS initiated and a network requested PDP context activation procedure is identified by the MS if a REQUEST PDP CONTEXT ACTIVATION message is received from the network after the MS has sent an ACTIVATE PDP CONTEXT REQUEST message, and the MS has not yet received an ACTIVATE PDP CONTEXT ACCEPT or ACTIVATE PDP CONTEXT REJECT message.

NOTE: In general, the MS is unable to test if the PDP type, PDP address and APN in the REQUEST PDP CONTEXT ACTIVATION message are the same as those for the PDN to which it is attempting to activate a context. This is because the MS may have omitted one or more of the parameters in the ACTIVATE PDP CONTEXT REQUEST message, since it is relying on default values to be provided by the network.

In the case of such a collision, the MS initiated PDP context activation shall take precedence over the network requested PDP context activation. If the MS is able to compare the PDP type, PDP address and APN requested in the ACTIVATE PDP CONTEXT REQUEST message with those requested in the REQUEST PDP CONTEXT ACTIVATION message and these parameters are equal, then the MS shall discard the REQUEST PDP CONTEXT REQUEST message and shall wait for the network response to its ACTIVATE PDP CONTEXT REQUEST message. If the MS is not able to compare the PDP type, PDP address, and APN requested in the ACTIVATE PDP CONTEXT REQUEST message, then the MS shall send a REQUEST PDP CONTEXT ACTIVATION message, then the MS shall send a REQUEST PDP CONTEXT ACTIVATION REJECT message with the cause 'insufficient resources' to the network, and wait for an ACTIVATE PDP CONTEXT ACCEPT message.

Static PDP address collision detected on the network side:

A collision is detected by the network in the case where the PDP address, PDP type and APN derived (according to 03.60 annex A) from the ACTIVATE PDP CONTEXT REQUEST message received from the MS match those in the REQUEST PDP CONTEXT ACTIVATION message sent to the MS.

In the case of such a collision, the MS initiated PDP context activation shall take precedence over the network requested PDP context activation. The network shall terminate the network requested PDP context activation procedure, and proceed with the MS initiated PDP context activation procedure.




Figure 6.3/3GPP TS 04.08: MS initiated PDP context activation procedure




Figure 6.4/3GPP TS 04.08: Network initiated PDP context activation procedure

### 6.1.3.2 PDP context modification procedure

The PDP context modification procedure is invoked by the network in order to change the QoS negotiated during the PDP context activation procedure or at previously performed PDP context modification procedures. The procedure can be initiated by the network at any time when a PDP context is active.

In order to initiate the procedure, the network sends the MODIFY PDP CONTEXT REQUEST message to the MS and starts timer T3386. The message shall contain the new QoS and the radio priority level that shall be used by the MS at the lower layers for the transmission of data related to the PDP context.

Upon receipt of this message the MS shall reply with the MODIFY PDP CONTEXT ACCEPT message, if the MS accepts the new QoS and the indicated LLC SAPI.

If the MS does not accept the new QoS or the indicated LLC SAPI, the MS shall initiate the PDP context deactivation procedure for the PDP context - the reject cause IE value of the DEACTIVATE PDP CONTEXT REQUEST message shall indicate "QoS not accepted".

The network shall upon receipt of the MODIFY PDP CONTEXT ACCEPT message stop timer T3386 and shall establish, reconfigure or continue using the logical link with the new QoS for the LLC SAPI indicated in the MODIFY PDP CONTEXT REQUEST message.

#### 6.1.3.2.1 Abnormal cases

On the first expiry of timer T3386, the network shall resend the MODIFY PDP CONTEXT REQUEST message reset and restart timer T3386. This retransmission is repeated four times, i.e. on the fifth expiry of timer T3386, the network may continue to use the previously negotiated QoS or it may initiate the PDP context deactivation procedure.




Figure 6.5/3GPP TS 04.08: PDP context modification procedure

#### 6.1.3.3 PDP context deactivation procedure

The purpose of this procedure is to deactivate an existing PDP context between the MS and the network. The PDP context deactivation may be initiated by the MS or by the network.

#### 6.1.3.3.1 PDP context deactivation initiated by the MS

In order to deactivate a PDP context, the MS sends a DEACTIVATE PDP CONTEXT REQUEST message to the network, enters the state PDP-INACTIVE-PENDING and starts timer T3390. The message contains the transaction identifier in use for the PDP context to be deactivated and a cause code that typically indicates one of the following causes:

#### # 25: LLC or SNDCP failure;

- # 26: insufficient resources;
- # 36: regular PDP context deactivation; or
- # 37: QoS not accepted.

The network shall reply with the DEACTIVATE PDP CONTEXT ACCEPT message. Upon receipt of the DEACTIVATE PDP CONTEXT ACCEPT message, the MS shall stop timer T3390. Both the MS and the network shall initiate local release of the logical link if it is not used by another PDP context.

#### 6.1.3.3.2 PDP context deactivation initiated by the network

In order to deactivate a PDP context, the network sends a DEACTIVATE PDP CONTEXT REQUEST message to the MS and starts timer T3395. The message contains the transaction identifier in use for the PDP context to be deactivated and a cause code that typically indicates one of the following causes:

- # 25: LLC or SNDCP failure;
- # 36: regular PDP context deactivation;
- # 38: network failure; or
- # 39: reactivation requested.

The MS shall, upon receipt of this message, reply with a DEACTIVATE PDP CONTEXT ACCEPT message. Upon receipt of the DEACTIVATE PDP CONTEXT ACCEPT message, the network shall stop the timer T3395. Both the MS and the network shall initiate local release of the logical link if it is not used by another PDP context.

#### 6.1.3.3.3 Abnormal cases

The following abnormal cases can be identified:

a) Expiry of timers

In the mobile station:

On the first expiry of timer T3390, the MS shall resent the message DEACTIVATE PDP CONTEXT REQUEST and shall reset and restart the timer T3390. This retransmission is repeated four times, i.e. on the fifth expiry of timer T3390, the MS shall release all resources allocated and shall erase the PDP context related data.

On the network side:


On the first expiry of timer T3395, the network shall resent the message DEACTIVATE PDP CONTEXT REQUEST and shall reset and restart timer T3395. This retransmission is repeated four times, i.e. on the fifth expiry of timer T3395, the network shall erase the PDP context related data for that MS.

b) Collision of MS and network initiated PDP context deactivation requests

If the MS and the network initiated PDP context deactivation requests collide, the MS and the network shall each reply with the messages DEACTIVATE PDP CONTEXT ACCEPT and shall stop timer T3390 and T3395, respectively.

	MS	Network
Start T3390		DEACTIVATE PDP CONTEXT REQUEST
Stop T3390		DEACTIVATE PDP CONTEXT ACCEPT

#### Figure 6.6/3GPP TS 04.08: MS initiated PDP context deactivation procedure



#### Figure 6.7/3GPP TS 04.08: Network initiated PDP context deactivation procedure

#### 6.1.3.4 AA PDP context activation

The purpose of this procedure is to anonymously establish a PDP context between the MS and the network for a specific QoS on a specific NSAPI. The AA PDP context activation shall only be initiated by the MS.

#### 6.1.3.4.1 Successful AA PDP context activation initiated by the mobile station

In order to activate an anonymous PDP context, the MS sends an ACTIVATE AA PDP CONTEXT REQUEST message to the network, enters the state PDP-ACTIVE-PENDING and starts timer T3380. As long as no auxiliary TLLI is allocated to the MS, a random TLLI is used for addressing on lower layers.

Upon receipt of an ACTIVATE AA PDP CONTEXT REQUEST message, the network selects a radio priority level based on the QoS negotiated, assigns a AA-TID to the PDP context and sends an ACTIVATE AA PDP CONTEXT ACCEPT message to the MS. The message shall contain a the selected radio priority level and negotiated QoS allocated by the network. If the offered QoS parameters received from the network differ from the QoS requested by the MS, the MS shall accept the QoS offered by the network. If the LLC SAPI indicated by the network can not be supported by the MS, the MS shall initiate the implicit AA PDP context deactivation procedure. Upon receipt of the message ACTIVATE AA PDP CONTEXT ACCEPT, the MS shall stop timer T3380, shall enter the state PDP-ACTIVE and shall initiate establishment of the logical link for the LLC SAPI indicated by the network with the negotiated QoS.

#### 6.1.3.4.2 Unsuccessful AA PDP context activation

Upon receipt of the ACTIVATE AA PDP CONTEXT REQUEST message the network may indicate the failure of the MS initiated AA PDP context activation by sending the ACTIVATE AA PDP CONTEXT REJECT message to the MS. The message contains a cause code that typically indicates one of the following causes:

- # 32: service option not supported;
- # 34: service option temporarily out of order;
- # 90 111: protocol errors.


The MS shall stop the timer T3380.

#### 6.1.3.4.3 Abnormal cases

a) Expiry of timers

On the first expiry of timer T3380, the MS shall retransmit the ACTIVATE AA PDP CONTEXT REQUEST message and shall reset and restart timer T3380.

This retransmission is repeated four times, i.e. on the fifth expiry of timer T3380, the MS shall indicate the failure of the AA PDP context activation procedure to the register functions, shall release all resources possibly allocated for this invocation and shall abort the procedure; no automatic AA PDP context activation re-attempt shall be performed.



#### Figure 6.8 3GPP TS 04.08: MS initiated AA PDP context activation procedure

#### 6.1.3.5 AA PDP context deactivation

#### 6.1.3.5.1 Implicit AA PDP context deactivation

The implicit deactivation is performed without signalling message exchange as specified below.

The AA PDP context on the network side shall be deactivated when:

#### - the AA READY timer expires in the GMM-AA entity.

The AA PDP context in the MS shall be deactivated when:

- the AA READY timer expires in the GMM-AA entity;
- the MS changes the routing area;
- the LLC SAPI indicated by the network can not be supported by the MS during activation; or
- user requested.

#### 6.1.3.5.2 Explicit AA PDP context deactivation

An explicit AA PDP context deactivation shall only be initiated by the network. The procedure shall be performed when a misuse of the anonymous PDP context has been detected.

In order to deactivate the AA PDP context, the network sends the message DEACTIVATE AA PDP CONTEXT REQUEST and starts timer T3397. The message shall contain the transaction identifier in use for the AA PDP context to be deactivated. After sending the message the network initiates the release of the logical link.

The MS shall, upon receipt of this message, reply with the DEACTIVATE AA PDP CONTEXT ACCEPT message after the logical link has been released.


Upon receipt of the DEACTIVATE AA PDP CONTEXT ACCEPT message, the network shall stop the timer T3397.

#### 6.1.3.5.3 Abnormal cases

a) Expiry of timers

On the first expiry of timer T3397, the network shall retransmit the message DEACTIVATE AA PDP CONTEXT REQUEST and shall reset and restart timer T3397.

This retransmission is repeated four times, i.e. on the fifth expiry of timer T3397, the network shall release all remaining resources allocated for that MS and shall erase the AA PDP context related data for that MS.



#### Figure 6.9/3GPP TS 04.08: Network initiated AA PDP context deactivation procedure

b) Lower layer failure

If a lower layer failure is indicated before the DEACTIVATE AA PDP CONTEXT ACCEPT message is sent, the MS shall abort the procedure and shall locally de-allocate the P-TMSI from the LLC sublayer.

If a lower layer failure is indicated before the DEACTIVATE AA PDP CONTEXT ACCEPT message is received, the network shall abort the procedure and shall locally de-allocate the P-TMSI from the LLC sublayer.

#### 6.1.3.6 Receiving a SM STATUS message by a SM entity

If the SM entity of the MS receives a SM STATUS message no state transition and no specific action shall be taken as seen from the radio interface, i.e. local actions are possible.

The actions to be taken on receiving a SM STATUS message in the network are an implementation dependent option.

# 7 Examples of structured procedures

Clause 7 is informative.

## 7.1 General

Clause 7 contains examples of how the network may group together the elementary procedures (i.e. the procedures defined in clauses 3 to 5) in order to provide normal service.

The layer 3 signalling at the radio interface may be divided into so-called structured procedures which consist of specific combinations of elementary procedures. In sub-clause 7.3, selected examples of structured procedures are described. A structured procedure consists of (not necessarily all) components shown in figure 7.1. These components are characterized by the purpose of their use in structured procedures and their message flow in the following sub-clauses 7.1.1 to 7.1.7.




Figure 7.1/3GPP TS 04.08: Components of structured procedures

## 7.1.1 Paging request

The paging procedure is used to locate a mobile station to which a connection shall be established.

Upon receipt of a PAGING REQUEST message the addressed mobile station initiates the immediate assignment procedure.

Mobile	Station		Network
		REQUEST	
< -			

#### Figure 7.2/3GPP TS 04.08: Paging request

## 7.1.2 Immediate assignment

The immediate assignment procedure is always initiated by the mobile station. It may be triggered by a paging request or by a mobile originating service request.

The mobile station sends a CHANNEL REQUEST message on the Random Access Channel. The network responds with an IMMEDIATE ASSIGNMENT message which causes the mobile station to seize the indicated dedicated channel.

Mobile Station	Network
CHANNEL REQUEST	->
IMMEDIATE ASSIGNMENT	

#### Figure 7.3/3GPP TS 04.08: Immediate assignment

## 7.1.3 Service request and contention resolution

The initial service request message (a PAGING RESPONSE, LOCATION UPDATING REQUEST, IMSI DETACH, CM SERVICE REQUEST, or CM RE-ESTABLISHMENT REQUEST message) is sent by the mobile station to the network piggy-backed in the L2 SABM frames establishing the main signalling link. Its purpose is

- to provide non-confidential information relevant to the service requested for the RR and MM sublayer in the network;
- in particular to identify the user in the network without jeopardising the confidentiality of the user's identity; this is achieved by using as mobile identity the TMSI, which was never before transmitted un-encrypted over the radio interface;

- to allow for contention resolution;
- optionally, in the CM SERVICE REQUEST message to inform the network of the priority level associated with the call.


Contention resolution provides a resolution process when more than one MS try to seize a channel allocated during the immediate assignment procedure (because they happened to use the same random reference at the same time during random access). This is achieved by the network including in a L2 UA frame the same information field as that one received in the L2 SABM frame to which the UA frame responds. By comparing the two information fields the MS can verify whether it was the originator of the L2 establishment, because the service request contains the mobile identity.

Mobile Station Network
SABM(service request)
UA(service request)
<------

#### Figure 7.4/3GPP TS 04.08: Service request and contention resolution

## 7.1.4 Authentication

The purpose of authentication is to validate the identity provided by the mobile station. It is initiated by the network. The authentication procedure also provides the mobile station with information from which a new ciphering key can be derived. The network decides whether or not to use authentication. This may depend on the context.



## 7.1.5 Ciphering mode setting

Ciphering mode setting is initiated by the network. Its purpose is to instruct the mobile station whether or not to use ciphering and which algorithm to use.

Where ciphering is used, this procedure synchronizes the start of ciphering at the mobile station and in the network.

Mobile Station Network
CIPHer MODE CoMmanD
CIPHer MODe COMplete

#### Figure 7.6/3GPP TS 04.08: Ciphering mode setting

## 7.1.6 Transaction phase

A variety of elementary procedures described in clauses 3 to 5 may be performed during the transaction phase. In this sub-clause, only the channel mode modify procedure is characterized.

#### 7.1.6.1 Channel mode modify

The channel mode modify procedure may be used when a traffic channel has been assigned e.g.:

- during the in-call modification procedure in order that the channel mode of the TCH be changed to that one requested by call control;

- during call establishment with very early assignment in order that the channel mode of the TCH be changed from signalling only to the mode requested by call control;
- during the active phase of a data call in order that the speed of the data transmission be changed.

The channel mode modify procedure is initiated by the network sending a CHANNEL MODE MODIFY message and completed by the mobile station changing the mode of the TCH and sending back a CHANNEL MODE MODIFY ACKNOWLEDGE message.

Mobile Station Network CHANNEL MODE MODIFY <------CHANNEL MODE MODIFY ACKNOWLEDGE

#### Figure 7.7/3GPP TS 04.08: Channel mode change

## 7.1.7 Channel release

Once the transaction phase has been completed, the channel is released by the channel release procedure. The data link layer is released explicitly as described in 3GPP TS 04.06. After the channel release is completed, the radio resources which were in use may be reallocated by the network.

Mobile Station Network CHANNEL RELEASE

------

#### Figure 7.8/3GPP TS 04.08: Channel release

## 7.2 Abnormal cases

Abnormal cases are not described in the examples of clause 7. They may arise from:

- a) failure at a lower layer (e.g. loss of radio connection);
- b) failure of an elementary procedure;
- c) errors in an elementary procedure.

## 7.3 Selected examples

The following examples are considered:

- location updating
- mobile originating call establishment
  - a) without OACSU (early assignment)
  - b) with OACSU
  - c) with very early assignment
- mobile terminating call establishment
  - a) without OACSU (early assignment)
  - b) with OACSU

- call clearing:
  - a) network initiated
  - b) mobile initiated
- DTMF protocol control.
- handover:
  - a) between finely synchronized cells
  - b) between non-synchronized cells
  - c) handover failure, where reconnection of the old channel is possible
- in-call modification
- call re-establishment
- network initiated MO call, e.g. CCBS Recall \$(CCBS)\$:
  - a) assignment before A party alerting
  - b) assignment before B party alerting
  - c) assignment after A and B party alerting

## 7.3.1 Location updating

The location updating procedure is always initiated by the mobile station e.g. when it finds itself in a different location area from the one in which it was registered before. The cases where the procedure is triggered are described in subclause 4.

The procedure is shown in figure 7.9/3GPP TS 04.08. The network may decide whether to allocate a new TMSI during location updating, and this option is reflected in this example.

The mobile station initiates immediate assignment, service request using the LOCATION UPDATING REQUEST message, and contention resolution.

The network requires authentication (this again is an option).

As the network intends to allocate a new TMSI, it should activate ciphering. The network includes the new TMSI in the LOCATION UPDATING ACCEPT message (it could also use the explicit TMSI reallocation procedure, see sub-clause 4). The mobile station sends a TMSI REALLOCATION COMPLETE message to the network to acknowledge the receipt of the new TMSI. Upon receipt of the TMSI REALLOCATION COMPLETE message the network initiates the channel release if no further transactions are scheduled.




Figure 7.9/3GPP TS 04.08: Location updating: successful case

## 7.3.2 Mobile originating call establishment

The mobile station initiates immediate assignment, service request using the CM SERVICE REQUEST message, and contention resolution. The network may initiate authentication and may start the ciphering mode setting.

After sending the CIPHERING MODE COMPLETE message, the mobile station initiates call establishment by sending the SETUP message to the network. The network answers with a CALL PROCEEDING message.

a) Non-OACSU option (early assignment)

With this option the network allocates a traffic channel to the mobile station before it initiates call establishment in the fixed network.

If call queuing is applied, it may cause variable delay in the traffic channel assignment.

When user alerting has been initiated at the called side, an ALERTING message is sent to the mobile station. The network may optionally instruct the MS to attach the user connection at this stage of the call, by means of the progress indicator information element set to the value #1 or #8(if the ringing tone will be sent by the remote end) in the ALERTING message. In that case, an alerting ringing tone has to be generated by the network.

NOTE: The speech codec is transparent for supervisory tones.

A CONNECT message and its acknowledgement CONNECT ACKNOWLEDGE complete the call establishment when the called party has answered.

The mobile originating call setup with early assignment is shown in figure 7.10a/3GPP TS 04.08.

b) OACSU option (late assignment)

The network determines when the traffic channel is to be assigned. The assignment may be performed at any time after call establishment has been initiated in the fixed network. In the following the case is considered where the network will only allocate a traffic channel after the called party has answered the call (late assignment).

As in a) an ALERTING message is sent to the mobile station when user alerting has been initiated at the called side. If the ringing tone is needed, it has to be generated locally at the mobile station as no traffic channel is allocated. When the called party has answered, the network will initiate the channel assignment procedure in order to allocate a traffic channel to the mobile station. If call queuing is applied, it may cause variable delay in the traffic channel assignment. Once the channel assignment has been completed the network will send a CONNECT message to the mobile station. The MS attaches then the user connection. The CONNECT ACKNOWLEDGE message will complete the call setup.

The mobile originating call setup with late assignment is shown in figure 7.10b/3GPP TS 04.08.

c) Very early assignment.

The network assigns the traffic channel at the earliest possible moment, i.e. in the immediate assignment procedure. The mode of the traffic channel is changed from signalling only to the mode necessary for the call by means of the channel mode change procedure. An appropriate moment for that change is after the network has sent the CALL PROCEEDING message, when the call is established towards the called user.

With this option, call queuing is never applied.

The further establishment of the call is as in a).

The mobile originating call setup with very early assignment is shown in figure 7.10c/3GPP TS 04.08.




Figure 7.10a/3GPP TS 04.08: Mobile originating call establishment without OACSU (early assignment)

**ETSI** 




Figure 7.10b/3GPP TS 04.08: Mobile originating call establishment with OACSU (late assignment)

Mobile Station Network CHANNEL REQUEST RR connection establishment IMMEDIATE ASSIGNMENT(TCH) (MO) CM SERVICE REQUEST Service request AUTHentication REQuest Authentication AUTHENTICATION RESPONSE -----> CIPHER MODE COMMAND Ciphering CIPHer MODe COMplete mode setting -----> SETUP Call initiation \_\_\_\_\ CALL PROCeeding CHANNEL MODE MODIFY Transmission CHANNEL MODE MODIFY ACKNOWLEDGE mode change -----> ALERTING User alerting -+ CONNect Call accepted CONNect ACKnowledge

Figure 7.10c/3GPP TS 04.08: Mobile originating call establishment with very early assignment

## 7.3.3 Mobile terminating call establishment

Mobile terminating call establishment is initiated by the network sending a PAGING REQUEST message (see figure 7.11a/3GPP TS 04.08). Upon receiving this message the mobile station initiates the immediate assignment procedure and responds to the network by sending the PAGING RESPONSE message within a layer 2 SABM frame. The network returns a layer 2 UA frame containing the same information field as was sent in the SABM frame.

Authentication and ciphering are treated by the network in the same way as defined for the mobile originating call establishment (sub-clause 7.3.2). After ciphering has been started, the network sends a SETUP message to the mobile station. The capability of the mobile station (at that time) to accept the call is confirmed when the mobile station returns a CALL CONFIRMED message to the network.

a) Non-OACSU option (early assignment)

With this option the network initiates the assignment of a traffic channel upon receiving the CALL CONFIRMED message.

The signal IE is not included in the SETUP message, therefore user alerting is initiated only after a traffic channel has been allocated. An ALERTING message will be sent to the network.

When the called user answers, the mobile station sends a CONNECT message to the network. Upon receiving the CONNECT message the network completes the through connection of the communication path and sends a CONNECT ACK message to the mobile station.

b) OACSU option (late assignment)

In that option, the signalling IE is included in the SETUP message. Consequently, user alerting is initiated as soon as the MS has accepted the call.

The network determines when the traffic channel is to be assigned. The assignment may be performed at any time after user alerting has been initiated. In the following the case is considered where the network will only allocate a traffic channel to the mobile station after having received the CONNECT message sent from the mobile station (see figure 7.11b).

Upon receiving the ASSIGNMENT COMPLETE message from the mobile station, the network completes the through connection of the communication path and sends a CONNECT ACKNOWLEDGE message to the mobile station.





Figure 7.11a/3GPP TS 04.08: Mobile terminating: call establishment without OACSU (early assignment)



#### Figure 7.11b/3GPP TS 04.08: Mobile terminating: call establishment with OACSU (late assignment)

## 7.3.4 Call clearing

a) initiated by the network

The network initiates the clearing of a call by sending a DISCONNECT message to the mobile station (see also sub-clause 5.4.4).

Upon receiving the DISCONNECT message from the network the mobile station sends a RELEASE message to the network.

Upon receiving the RELEASE message from the mobile station, the network sends a RELEASE COMPLETE to the mobile station and, if the traffic channel is longer needed (e.g. last activity on the traffic channel), performs the channel release procedure as described in sub-clause 7.1.7.

Upon receiving the RELEASE COMPLETE message and if the cleared call was the last activity on the traffic channel, the mobile station waits for the release of the channel which is always initiated by the network.

Call clearing initiated by the network is shown in figure 7.12a.


b) initiated by the mobile station

The mobile station initiates the clearing of a call by sending a DISCONNECT message to the network (see also sub-clause 5.4.3).

Upon receiving the DISCONNECT message from the mobile station the network sends a RELEASE message to the mobile station.


Upon receiving the RELEASE message from the network, the mobile station sends a RELEASE COMPLETE to the network, which, if the traffic channel is no longer needed (e.g. last activity on the traffic channel), performs the channel release procedure as described in sub-clause 7.1.6.

Call clearing initiated by the mobile station is shown in figure 7.12b.



a) Call clearing initiated by the network





b) Call clearing initiated by the MS



## 7.3.5 DTMF protocol control

Figure 7.13 shows the structured procedure for DTMF protocol control.




Figure 7.13/3GPP TS 04.08: DTMF protocol control

## 7.3.6 Handover

Figure 7.14 shows the structured procedure for handover to a finely synchronized cell, successful case.

Figure 7.15 shows the structured procedure for handover to a non-synchronized cell, successful case.

Figure 7.16 shows the structured procedure for handover failure, and reconnection to the old traffic channel.




Figure 7.14/3GPP TS 04.08: Handover to a finely synchronized cell, successful case




Figure 7.15/3GPP TS 04.08: Handover to a non-synchronized cell, successful case




Figure 7.16/3GPP TS 04.08: Handover failure, reconnection to the old traffic channel

## 7.3.7 In-call modification

Figure 7.17/3GPP TS 04.08 shows the structured procedure for in-call modification.




Figure 7.17/3GPP TS 04.08: In-call modification

## 7.3.8 Call re-establishment

Figure 7.18/3GPP TS 04.08 shows the structured procedure for call re-establishment.




Figure 7.18/3GPP TS 04.08: Call re-establishment

## 7.3.9 Network initiated mobile originating call \$(CCBS)\$

Network initiated mobile originating call establishment (which is used, for example, for CCBS Service) is initiated by the network sending a PAGING REQUEST message. Upon receiving this message the mobile station initiates the immediate assignment procedure and responds to the network by sending the PAGING RESPONSE message within a layer 2 SABM frame. The network returns a layer 2 UA frame containing the same information field as was sent in the SABM frame.

Authentication and ciphering are treated by the network in the same way as defined for the mobile originating call establishment (sub-clause 7.3.2). After ciphering has been started, the network sends a CM SERVICE PROMPT message, indicating that the CM protocol is to be started, to the mobile station. The basic capability of the mobile station to accept any form of recall service is confirmed when the mobile station returns a START CC message to the network.

a) assignment before A party alerting

With this option the network allocates a traffic channel to the mobile station before the mobile station alerts its user.

The network responds to the START CC message with a CC-ESTABLISHMENT message. The MS answers with a CC-ESTABLISHMENT CONFIRMED message indicating the wanted channel characteristics. The network then initiates traffic channel assignment.

When the traffic channel has been assigned, the network indicates a pending recall by sending a RECALL message.

If the calling user accepts the recall, a SETUP message is sent to the network. The network responds with a CALL PROCEEDING message and initiates call establishment in the fixed network.

When user alerting has been initiated at the called side, an ALERTING message is sent to the mobile station. The network may optionally instruct the MS to attach the user connection at this stage of the call, by means of the progress indicator information element set to the value #1 or #8(if the ringing tone will be sent by the remote end) in the ALERTING message. In that case, an alerting ringing tone has to be generated by the network.

NOTE 1: The speech codec is transparent for supervisory tones.

A CONNECT message and its acknowledgement CONNECT ACKNOWLEDGE complete the call establishment when the called party has answered.

The network initiated mobile originating call establishment with assignment before A part alerting is shown in figure 7.19/3GPP TS 04.08.

b) assignment before B party alerting

With this option the network allocates a traffic channel to the mobile station after the mobile station has alerted its user and after its user has accepted the recall but before the network initiates call establishment in the fixed network.

The network responds to the START CC message with a CC-ESTABLISHMENT message. The MS answers with a CC-ESTABLISHMENT CONFIRMED message indicating the wanted channel characteristics.

The network indicates a pending recall by sending a RECALL message. If the calling user accepts the recall, a SETUP message is sent to the network. The network responds with a CALL PROCEEDING message and initiates traffic channel assignment.

When the traffic channel has been assigned, the network initiates call establishment in the fixed network.

When user alerting has been initiated at the called side, an ALERTING message is sent to the mobile station. The network may optionally instruct the MS to attach the user connection at this stage of the call, by means of the progress indicator information element set to the value #1 or #8(if the ringing tone will be sent by the remote end) in the ALERTING message. In that case, an alerting ringing tone has to be generated by the network.

NOTE 2: The speech codec is transparent for supervisory tones.

A CONNECT message and its acknowledgement CONNECT ACKNOWLEDGE complete the call establishment when the called party has answered.

The network initiated mobile originating call establishment with assignment before B party alerting is shown in figure 7.20/3GPP TS 04.08.

c) assignment after A and B party alerting

With this option, the network determines when the traffic channel is to be assigned. The assignment may be performed at any time after call establishment has been initiated in the fixed network. In the following, the case is considered where the network will only allocate a traffic channel after the called party has answered the call (late assignment).

The network responds to the START CC message with a CC-ESTABLISHMENT. The MS answers with a CC-ESTABLISHMENT CONFIRMED message indicating the wanted channel characteristics.

The network indicates a pending recall by sending a RECALL message. If the calling user accepts the recall, a SETUP message is sent to the network. The network responds with a CALL PROCEEDING message and initiates call establishment in the fixed network.

As in a) and b) an ALERTING message is sent to the mobile station when user alerting has been initiated at the called side. If the ringing tone is needed, it has to be generated locally at the mobile station as no traffic channel is allocated. When the called party has answered, the network will initiate the channel assignment procedure in order to allocate a traffic channel to the mobile station. Once the channel assignment has been completed the network will send a CONNECT message to the mobile station. The MS attaches then the user connection. The CONNECT ACKNOWLEDGE message will complete the call setup.

The network initiated mobile originating call establishment with assignment after A and B party alerting is shown in figure 7.21/3GPP TS 04.08.




Figure 7.19/3GPP TS 04.08: Network initiated mobile originating call establishment with assignment before A party alerting




Figure 7.20/3GPP TS 04.08: Network initiated mobile originating call establishment with assignment before B party alerting




Figure 7.21/3GPP TS 04.08: Network initiated mobile originating call establishment with assignment after A and B party alerting

**ETSI** 

# 8 Handling of unknown, unforeseen, and erroneous protocol data

## 8.1 General

The procedures specified in 3GPP TS 04.08 and call-related supplementary service handling in 3GPP TS 04.10 apply to those messages which pass the checks described in this sub-clause.

This sub-clause also specifies procedures for the handling of unknown, unforeseen, and erroneous protocol data by the receiving entity. These procedures are called "error handling procedures", but in addition to providing recovery mechanisms for error situations they define a compatibility mechanism for future extensions of the protocols.

Error handling concerning the value part of the Facility IE and of the SS Version Indicator IE are not in the scope of the present document. It is defined in 3GPP TS 04.10 and the 3GPP TS 04.8x series.

Sub-clauses 8.1 to 8.8 shall be applied in order of precedence.

Most error handling procedures are mandatory for the mobile station.

Detailed error handling procedures in the network are implementation dependent and may vary from PLMN to PLMN. However, when extensions of this protocol are developed, networks will be assumed to have the error handling that is indicated in this sub-clause as mandatory ("shall") and that is indicated as strongly recommended ("should"). Sub-clauses 8.2, 8.3, 8.4, 8.5 and 8.7.2 do not apply to the error handling in the network applied to the receipt of initial layer 3 message: If the network diagnoses an error described in one of these sub-clauses in the initial layer 3 message received from the mobile station, it shall either:

- try to recognize the classmark and then take further implementation dependent actions; or
- release the RR-connection.

Also, the error handling of the network is only considered as mandatory or strongly recommended when certain thresholds for errors are not reached during a dedicated connection.

In this sub-clause the following terminology is used:

- An IE is defined to be syntactically incorrect in a message if it contains at least one value defined as "reserved" in sub-clause 10, or if its value part violates rules of clause 10. However it is not a syntactical error that a type 4 IE specifies in its length indicator a greater length than defined in sub-clause 10.
- A message is defined to have semantically incorrect contents if it contains information which, possibly dependent on the state of the receiver, is in contradiction to the resources of the receiver and/or to the procedural part (i.e. sub-clauses 3, 4, 5) of 3GPP TS 04.08, 3GPP TS 04.10, or relevant 3GPP TS 04.8X series.

# 8.2 Message too short

When a message is received that is too short to contain a complete message type information element, that message shall be ignored, cf. 3GPP TS 04.07.

# 8.3 Unknown or unforeseen transaction identifier

## 8.3.1 Call Control

The mobile station and network shall ignore a call control message received with TI value "111". For a call control message received with TI different from "111", the following procedures shall apply:

a) For a network that does not support the "Network initiated MO call" option and for all mobile stations:

Whenever any call control message except EMERGENCY SETUP, SETUP or RELEASE COMPLETE is received specifying a transaction identifier which is not recognized as relating to an active call or to a call in progress, the receiving entity shall send a RELEASE COMPLETE message with cause #81 "invalid transaction identifier value" using the received transaction identifier value and remain in the Null state.

For a network that does support the "Network initiated MO call" option \$(CCBS)\$.

Whenever any call control message except EMERGENCY SETUP, SETUP, START CC or RELEASE COMPLETE is received specifying a transaction identifier which is not recognized as relating to an active call or to a call in progress, the receiving entity shall send a RELEASE COMPLETE message with cause #81 "invalid transaction identifier value" using the received transaction identifier value and remain in the Null state.

- b) When a RELEASE COMPLETE message is received specifying a transaction identifier which is not recognized as relating to an active call or to a call in progress, the MM connection associated with that transaction identifier shall be released.
- c) For a network that does not support the "Network initiated MO call" option and for all mobile stations:

When an EMERGENCY SETUP or, a SETUP message is received specifying a transaction identifier which is not recognized as relating to an active call or to a call in progress, and with a transaction identifier flag incorrectly set to "1", this message shall be ignored.

For a network that does support the "Network initiated MO call" option \$(CCBS)\$.

When an EMERGENCY SETUP, a START CC or, a SETUP message is received specifying a transaction identifier which is not recognised as relating to an active call or to a call in progress, and with a transaction identifier flag incorrectly set to "1", this message shall be ignored.

- d) When a SETUP message is received by the mobile station specifying a transaction identifier which is recognized as relating to an active call or to a call in progress, this SETUP message shall be ignored.
- e) For a network that does not support the "Network initiated MO call" option:

When an EMERGENCY SETUP message or a SETUP message is received by the network specifying a transaction identifier which is recognized as relating to an active call or to a call in progress, this message need not be treated and the network may perform other actions.

For a network that does support the "Network initiated MO call" option \$(CCBS)\$.

When an EMERGENCY SETUP message or a START CC message is received by the network specifying a transaction identifier which is recognised as relating to an active call or to a call in progress, this message need not be treated and the network may perform other actions.

The same applies to a SETUP message unless the transaction has been established by a START\_CC message and the network is in the "recall present" state (N0.6).

## 8.3.2 Session Management

The mobile station and network shall reject a session management message other than SM-STATUS received with TI value "111" by immediately sending an SM-STATUS message with TI value "111". For a session management message received with TI different from "111", the following procedures shall apply:

- a) Whenever any session management message except ACTIVATE PDP CONTEXT REQUEST, ACTIVATE AA PDP CONTEXT REQUEST or SM-STATUS is received by the network specifying a transaction identifier which is not recognized as relating to an active context or to a context that is in the process of activation or deactivation or has been [recently] deactivated, the network should send a SM-STATUS message with cause #81 "invalid transaction identifier value" using the received transaction identifier value and remain in the PDP-INACTIVE state.
- b) Whenever any session management message except REQUEST PDP CONTEXT ACTIVATION or SM-STATUS is received by the MS specifying a transaction identifier which is not recognized as relating to an active context or to a context that is in the process of activation or deactivation or has been [recently] deactivated, the MS shall send a SM-STATUS message with cause #81 "invalid transaction identifier value" using the received transaction identifier value and remain in the PDP-INACTIVE state.
- c) When an ACTIVATE AA PDP CONTEXT REQUEST or REQUEST PDP CONTEXT ACTIVATION message is received with a transaction identifier flag set to "1", this message shall be ignored.
- d) When an ACTIVATE PDP CONTEXT REQUEST message is received specifying a transaction identifier which is not recognized as relating to a context that is in the process of activation, and with a transaction identifier flag set to "1", this message shall be ignored.
- e) Whenever an ACTIVATE PDP CONTEXT REQUEST or ACTIVATE AA PDP CONTEXT REQUEST message is received by the network specifying a transaction identifier relating to a PDP context not in state PDP-INACTIVE, the network shall deactivate the old PDP context relating to the received transaction identifier without notifying the MS. Furthermore, the network shall continue with the activation procedure of a new PDP context as indicated in the received message.
- f) Whenever a REQUEST PDP CONTEXT ACTIVATION message is received by the MS specifying a transaction identifier relating to a PDP context not in state PDP-INACTIVE, the MS shall locally deactivate the old PDP context relating to the received transaction identifier. Furthermore, the MS shall continue with the activation procedure of a new PDP context as indicated in the received message.

# 8.4 Unknown or unforeseen message type

If a mobile station receives an RR, MM or CC message with message type not defined for the PD or not implemented by the receiver in unacknowledged mode, it shall ignore the message.

If a mobile station receives an RR, MM or CC message with message type not defined for the PD or not implemented by the receiver in acknowledged mode, it shall return a status message (STATUS, RR STATUS or MM STATUS depending on the protocol discriminator) with cause # 97 "message type non-existent or not implemented".

If a mobile station receives a GMM message or SM message with message type not defined for the PD or not implemented by the receiver, it shall return a status message (GMM STATUS or SM STATUS depending on the protocol discriminator) with cause # 97 "message type non-existent or not implemented".

If the network receives an RR message or MM message with message type not defined for the PD or not implemented by the receiver in a protocol state where reception of an unsolicited message with the given PD from the mobile station is not foreseen in the protocol, the network actions are implementation dependent. Otherwise, if the network receives a message with message type not defined for the PD or not implemented by the receiver, it shall ignore the message except that it should return a status message (STATUS, RR STATUS, MM STATUS, GMM STATUS or SM STATUS depending on the protocol discriminator) with cause #97 "message type non-existent or not implemented".

NOTE 1: A message type not defined for the PD in the given direction is regarded by the receiver as a message type not defined for the PD, see 3GPP TS 04.07 [20].

If the mobile station receives a message not compatible with the protocol state, the mobile station shall ignore the message except for the fact that, if an RR connection exists, it returns a status message (STATUS, RR STATUS or MM STATUS depending on the protocol discriminator) with cause #98 "Message type not compatible with protocol state". When the message was a GMM message the GMM-STATUS message with cause #98 "Message type not compatible with protocol state" shall be returned. When the message was a SM message the SM-STATUS message with cause #98 "Message type not compatible with protocol state" shall be returned.

If the network receives a message not compatible with the protocol state, the network actions are implementation dependent.

NOTE 2: The use by GMM and SM of unacknowledged LLC may lead to messages "not compatible with the protocol state".

# 8.5 Non-semantical mandatory information element errors

When on receipt of a message:

- an "imperative message part" error; or
- a "missing mandatory IE" error

is diagnosed or when a message containing:

- a syntactically incorrect mandatory IE; or
- an IE unknown in the message, but encoded as "comprehension required" (see sub-clause 3GPP TS 04.07); or
- an out of sequence IE encoded as "comprehension required" (see sub-clause 3GPP TS 04.07)

#### is received:

- the mobile station shall proceed as follows:
  - If the message is not one of the messages listed in sub-clauses 8.5.1, 8.5.2, 8.5.3, 8.5.4 and 8.5.5 a), b) or c), the mobile station shall ignore the message except for the fact that, if an RR connection exists, it shall return a status message (STATUS, RR STATUS or MM STATUS depending on the protocol discriminator) with cause # 96 "Invalid mandatory information". If the message was a GMM message the GMM-STATUS message with cause #96 " Invalid mandatory information" shall be returned. If the message was an SM message the SM-STATUS message with cause # 96 "invalid mandatory information" shall be returned.
- the network shall proceed as follows:
  - When the message is not one of the messages listed in sub-clause 8.5.3 b), c), d) or e) and 8.5.5 a), b), d) or e), the network shall either:
    - try to treat the message (the exact further actions are implementation dependent); or
    - ignore the message except that it should return a status message (STATUS, RR STATUS, MM STATUS (depending on the protocol discriminator), GMM STATUS, or SM STATUS) with cause # 96 "Invalid mandatory information".

## 8.5.1 Radio resource management

For the mobile station the following procedures shall apply:

- a) If the message is a CHANNEL RELEASE message, the actions taken shall be the same as specified in 3.5 "RR connection release".
- b) If the message is a PARTIAL RELEASE message, the reactions of the MS are for further study.

## 8.5.2 Mobility management

No exceptional cases are described for mobility management messages.

## 8.5.3 Call control

- a) If the message is a SETUP message, a RELEASE COMPLETE message with cause # 96 "invalid mandatory information" shall be returned.
- b) If the message is a DISCONNECT message, a RELEASE message shall be returned with cause value # 96 "invalid mandatory information" and sub-clause 5.4 "call clearing" applies as normal.
- c) If the message is a RELEASE message, a RELEASE COMPLETE message shall be returned with cause value # 96 "invalid mandatory information".
- d) If the message is a RELEASE COMPLETE message, it shall be treated as a normal RELEASE COMPLETE message.
- e) If the message is a HOLD REJECT or RETRIEVE REJECT message, it shall be treated as a normal HOLD REJECT or RETRIEVE REJECT message.
- f) If the message is a STATUS message and received by the network, a RELEASE COMPLETE message may be returned with cause value # 96 "invalid mandatory information".

## 8.5.4 GMM mobility management

No exceptional cases are described for mobility management messages.

## 8.5.5 Session management

- a) If the message is a DEACTIVATE PDP CONTEXT REQUEST, a DEACTIVATE PDP CONTEXT ACCEPT message shall be returned. All resources allocated for that context shall be released.
- b) If the message is a DEACTIVATE AA PDP CONTEXT REQUEST, a DEACTIVATE AA PDP CONTEXT ACCEPT message shall be returned. All resources allocated for that context shall be released.
- c) If the message is a REQUEST PDP CONTEXT ACTIVATION, a REQUEST PDP CONTEXT REJECT message with cause # 96 "Invalid mandatory information" shall be returned.
- d) If the message is an ACTIVATE PDP CONTEXT REQUEST, an ACTIVATE PDP CONTEXT REJECT message with cause # 96 "Invalid mandatory information" shall be returned.

If the message is an ACTIVATE AA PDP CONTEXT REQUEST, an ACTIVATE AA PDP CONTEXT REJECT message with cause # 96 "Invalid mandatory information" shall be returned.

# 8.6 Unknown and unforeseen IEs in the non-imperative message part

## 8.6.1 IEIs unknown in the message

The MS shall ignore all IEs unknown in a message which are not encoded as "comprehension required" (see 3GPP TS 04.07).

The network shall take the same approach.

## 8.6.2 Out of sequence IEs

The MS shall ignore all out of sequence IEs in a message which are not encoded as "comprehension required" (see 3GPP TS 04.07).

The network should take the same approach.

## 8.6.3 Repeated IEs

If an information element with format T, TV, or TLV is repeated in a message in which repetition of the information element is not specified in clause 9 of the present document, only the contents of the information element appearing first shall be handled and all subsequent repetitions of the information element shall be ignored. When repetition of information elements is specified, only the contents of specified repeated information elements shall be handled. If the limit on repetition of information elements is exceeded, the contents of information elements appearing first up to the limit of repetitions shall be handled and all subsequent repetitions of the information element shall be ignored.

The network should follow the same procedures.

## 8.7 Non-imperative message part errors

This category includes:

- syntactically incorrect optional IEs;
- conditional IE errors.

## 8.7.1 Syntactically incorrect optional IEs

The MS shall treat all optional IEs that are syntactically incorrect in a message as not present in the message.

The network shall take the same approach.

## 8.7.2 Conditional IE errors

When the MS upon receipt of an RR, MM or CC message diagnoses a "missing conditional IE" error or an "unexpected conditional IE" error or when it receives an RR, MM or CC message containing at least one syntactically incorrect conditional IE, it shall ignore the message except for the fact that, if an RR connection exists, it shall return a status message (STATUS, RR STATUS, or MM STATUS depending on the PD) with cause value # 100 "conditional IE error".

When the MS upon receipt of a GMM or SM message diagnoses a "missing conditional IE" error or an "unexpected conditional IE" error or when it receives a GMM or SM message containing at least one syntactically incorrect conditional IE, it shall ignore the message and it shall return a status message (GMM STATUS or SM STATUS depending on the PD) with cause value # 100 "conditional IE error".

When the network receives a message and diagnose a "missing conditional IE" error or an "unexpected conditional IE" error or when it receives a message containing at least one syntactically incorrect conditional IE, the network shall either

- try to treat the message (the exact further actions are implementation dependent); or
- ignore the message except that it should return a status message (STATUS, RR STATUS, MM STATUS, GMM STATUS or SM STATUS depending on the protocol discriminator) with cause # 100 "conditional IE error".

# 8.8 Messages with semantically incorrect contents

When a message with semantically incorrect contents is received, the foreseen reactions of the procedural part of 3GPP TS 04.08 (i.e. of sub-clauses 3, 4, 5) are performed. If however no such reactions are specified, the MS shall ignore the message except for the fact that, if an RR connection exists, it returns a status message (STATUS, RR STATUS, or MM STATUS depending on the PD) with cause value # 95 "semantically incorrect message".

The network should follow the same procedure except that a status message is not normally transmitted.

Semantic checking of the Facility information element value part (defined in 3GPP TS 04.80) is the subject of the technical specifications 3GPP TS 04.10 and the 3GPP TS 04.8x series.

# 9 Message functional definitions and contents

This sub-clause defines the structure of the messages of those layer 3 protocols defined in 3GPP TS 04.08. These are standard L3 messages as defined in 3GPP TS 04.07 with the exception of those sent on the SCH, RACH, and the HANDOVER ACCESS message.

Each definition given in the present sub-clause includes:

- a) a brief description of the message direction and use, including whether the message has:
  - 1. Local significance, i.e. relevant only on the originating or terminating access;
  - 2. Access significance, i.e. relevant in the originating and terminating access, but not in the network;
  - 3. Dual significance, i.e. relevant in either the originating or terminating access and in the network; or
  - 4. Global significance, i.e. relevant in the originating and terminating access and in the network.
- b) a table listing the information elements known in the message and their order of their appearance in the message. In messages for circuit-switched call control also a *shift* information element shall be considered as known even if not included in the table. All information elements that may be repeated are explicitly indicated. (V and LV formatted IEs, which compose the imperative part of the message, occur before T, TV, and TLV formatted IEs which compose the non-imperative part of the message, cf. 3GPP TS 04.07.) In a (maximal) sequence of consecutive information elements with half octet length, the first information element with half octet length occupies bits 1 to 4 of octet N, the second bits 5 to 8 of octet N, the third bits 1 to 4 of octet N+1 etc. Such a sequence always has an even number of elements.

For each information element the table indicates:

- 1. the information element identifier, in hexadecimal notation, if the IE has format T, TV, or TLV. Usually, there is a default IEI for an information element type; default IEIs of different IE types of the same protocol are different. If the IEI has half octet length, it is specified by a notation representing the IEI as a hexadecimal digit followed by a "-" (example: B-).
- NOTE The same IEI may be used for different information element types in different messages of the same protocol.
  - 2. the name of the information element (which may give an idea of the semantics of the element). The name of the information element (usually written in italics) followed by "IE" or "information element" is used in 3GPP TS 04.08 as reference to the information element within a message.
  - 3. the name of the type of the information element (which indicates the coding of the value part of the IE), and generally, the referenced sub-clause of clause 10 of 3GPP TS 04.08 describing the value part of the information element.
  - 4. the presence requirement indication (M, C, or O) for the IE as defined in 3GPP TS 04.07.
  - 5. The format of the information element (T, V, TV, LV, TLV) as defined in 3GPP TS 04.07.
  - 6. The length of the information element (or permissible range of lengths), in octets, in the message, where "?" means that the maximum length of the IE is only constrained by link layer protocol, and in the case of the Facility IE by possible further conditions specified in 3GPP TS 04.10. This indication is non-normative.
- c) sub-clauses specifying, where appropriate, conditions for IEs with presence requirement C or O in the relevant message which together with other conditions specified in 3GPP TS 04.08 define when the information elements shall be included or not, what non-presence of such IEs means, and for IEs with presence requirement C the static conditions for presence and/or non-presence of the IEs (cf. 3GPP TS 04.07).

# 9.1 Messages for Radio Resources management

Table 9.1/3GPP TS 04.08 summarizes the messages for Radio Resources management.

Channel establishment messages:	Reference
	9.1.1
	9.1.18
IMMEDIATE ASSIGNMENT EXTENDED IMMEDIATE ASSIGNMENT REJECT	9.1.19 9.1.20
Ciphering messages: CIPHERING MODE COMMAND	Reference
CIPHERING MODE COMMAND	9.1.9 9.1.10
Handover messages:	Reference
ASSIGNMENT COMMAND	9.1.2
ASSIGNMENT COMPLETE	9.1.3
ASSIGNMENT FAILURE	9.1.4
PDCH ASSIGNMENT COMMAND	9.1.13a
HANDOVER ACCESS	9.1.14
HANDOVER COMMAND	9.1.15
HANDOVER COMPLETE	9.1.16
HANDOVER FAILURE	9.1.17
RR-CELL CHANGE ORDER	9.1.21e
PHYSICAL INFORMATION	9.1.28
RR INITIALISATION REQUEST	9.1.28a
HANDOVER ACCESS	9.1.14
HANDOVER COMMAND	9.1.15
	9.1.16
HANDOVER FAILURE	9.1.17
PHYSICAL INFORMATION	9.1.28
Channel release messages:	Reference
CHANNEL RELEASE	9.1.7
PARTIAL RELEASE PARTIAL RELEASE COMPLETE	9.1.26 9.1.27
Paging messages:	Reference
PAGING REQUEST TYPE 1	9.1.22
PAGING REQUEST TYPE 2	9.1.23
PAGING REQUEST TYPE 3	9.1.24
PAGING RESPONSE	9.1.25
SYSTEM INFORMATION TYPE 1	9.1.31
SYSTEM INFORMATION TYPE 2	9.1.32
SYSTEM INFORMATION TYPE 2bis	9.1.33
SYSTEM INFORMATION TYPE 2ter	9.1.34
SYSTEM INFORMATION TYPE 3	9.1.35
SYSTEM INFORMATION TYPE 4	9.1.36
SYSTEM INFORMATION TYPE 5	9.1.37
SYSTEM INFORMATION TYPE 5bis	9.1.38
SYSTEM INFORMATION TYPE 5ter	9.1.39
SYSTEM INFORMATION TYPE 6 SYSTEM INFORMATION TYPE 7	9.1.40
SYSTEM INFORMATION TYPE 7 SYSTEM INFORMATION TYPE 8	9.1.41 9.1.42
SYSTEM INFORMATION TYPE 9	9.1.42
SYSTEM INFORMATION TYPE 13	9.1.43 9.1.43a
SYSTEM INFORMATION TYPE 16	9.1.43d
SYSTEM INFORMATION TYPE 17	9.1.43e
Specific messages for VBS/VGCS:	Reference
NOTIFICATION/FACCH	9.1.21a
NOTIFICATION/NCH	9.1.21b
NOTIFICATION RESPONSE	9.1.21d
TALKER INDICATION	9.1.44
UPLINK ACCESS	9.1.45
UPLINK BUSY	9.1.46
UPLINK FREE	9.1.47
UPLINK RELEASE	9.1.48
VGCS UPLINK GRANT	9.1.49

Table 9.1/3GPP TS 04.08: Messages for Radio Resources management

Channel establishment messages:	Reference		
EXTENDED MEASUREMENT ORDER	9.1.51		
EXTENDED MEASUREMENT REPORT	9.1.52		
Miscellaneous messages:	Reference		
CHANNEL MODE MODIFY	9.1.5		
CHANNEL MODE MODIFY ACKNOWLEDGE	9.1.6		
CHANNEL REQUEST	9.1.8		
CLASSMARK CHANGE	9.1.11		
CLASSMARK ENQUIRY	9.1.12		
FREQUENCY REDEFINITION	9.1.13		
MEASUREMENT REPORT	9.1.21		
SYNCHRONIZATION CHANNEL INFORMATION	9.1.30		
RR STATUS	9.1.29		
GPRS SUSPENSION REQUEST	9.1.13b		
Configuration Change messages:	Reference		
CONFIGURATION CHANGE COMMAND	9.1.12b		
CONFIGURATION CHANGE ACKNOWLEDGE	9.1.12c		
CONFIGURATION CHANGE REJECT	9.1.12d		
Application messages:	Reference		
APPLICATION INFORMATION	9.1.53		

## 9.1.1 Additional assignment

This message is sent on the main DCCH by the network to the mobile station to allocate an additional dedicated channel while keeping the previously allocated channels. See table 9.2/3GPP TS 04.08.

Message type: ADDITIONAL ASSIGNMENT

Significance: dual

Direction: network to mobile station

#### Table 9.2/3GPP TS 04.08: ADDITIONAL ASSIGNMENT message content

IEI	Information element	Type / Reference	Presence	Format	length
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Additional Assignment Message Type	Message Type 10.4	М	V	1
	Channel Description	Channel Description 10.5.2.5	М	V	3
72	Mobile Allocation	Mobile Allocation 10.5.2.21	С	TLV	3-10
7C	Starting Time	Starting Time 10.5.2.38	0	TV	3

### 9.1.1.1 Mobile Allocation

This information element shall appear if the Channel Description information element indicates frequency hopping.

If the *Channel Description* IE does not indicate frequency hopping and the information element is present it shall be considered as an IE unnecessary in the message.

#### 9.1.1.2 Starting Time

This information element appears in particular if e.g., a change of frequency is planned.

# 9.1.2 Assignment command

This message is sent on the main DCCH by the network to the mobile station to change the channel configuration to another independent dedicated channel configuration, when no timing adjustment is needed. See table 9.3/3GPP TS 04.08

Message type: ASSIGNMENT COMMAND

Significance: dual

Direction: network to mobile station

#### Table 9.3/3GPP TS 04.08: ASSIGNMENT COMMAND message content

RR management Protocol Discriminator Skip Indicator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator 10.3.1	М	V	1/2
Assignment command Message Type	Message Type 10.4	М	V	1
Description of the First Channel, after time	Channel Description 2 10.5.2.5a	М	V	3
Power Command	Power Command	М	V	1
Frequency List, after time	Frequency List 10.5.2.13	С	TLV	4-132
Cell Channel Description	Cell Channel Description 10.5.2.1b	0	TV	17
Description of the	Multislot Allocation	С	TLV	3-12
Mode of the First	Channel Mode	0	TV	2
Mode of Channel Set 2	Channel Mode	0	TV	2
Mode of Channel Set 3	Channel Mode	0	TV	2
Mode of Channel Set 4	Channel Mode	0	TV	2
Mode of Channel Set 5	Channel Mode	0	TV	2
Mode of Channel Set 6	Channel Mode	0	TV	2
Mode of Channel Set 7	Channel Mode	0	TV	2
Mode of Channel Set 8	Channel Mode	0	TV	2
Description of the Second Channel, after time	Channel Description	0	TV	4
Mode of the Second	Channel Mode 2	0	TV	2
Mobile Allocation,	Mobile Allocation	С	TLV	3-10
Starting Time	Starting Time	0	TV	3
Frequency List, before time	Frequency List	С	TLV	4-132
Description of the First Channel, before time	Channel Description 2	0	TV	4
Description of the	Channel Description	0	TV	4
Frequency channel sequence	Frequency channel sequence	С	TV	10
before time Mobile Allocation,	10.5.2.12 Mobile Allocation	С	TLV	3-10
	Power Command         Frequency List, after time         Cell Channel         Description         Description of the         multislot configuration         Mode of the First         Channel (Channel Set 1)         Mode of Channel Set 2         Mode of Channel Set 3         Mode of Channel Set 4         Mode of Channel Set 5         Mode of Channel Set 6         Mode of Channel Set 7         Mode of Channel Set 8         Description of the         Second Channel Set 8         Description of the Second         Channel         Mode of the Second         Channel         Mobile Allocation,         after time         Starting Time         Frequency List, before time         Description of the         First Channel, before time         Description of the         Second Channel, before time         Description of the         Second Channel, before time	Power CommandPower Command 10.5.2.28Frequency List, after timeFrequency List 10.5.2.13Cell ChannelCell Channel Description 10.5.2.1bDescription of the multislot configurationMultislot Allocation 10.5.2.21bMode of the First Channel (Channel Set 1)Channel Mode 10.5.2.6Mode of Channel Set 2Channel Mode 10.5.2.6Mode of Channel Set 3Channel Mode 10.5.2.6Mode of Channel Set 4Channel Mode 10.5.2.6Mode of Channel Set 5Channel Mode 10.5.2.6Mode of Channel Set 6Channel Mode 10.5.2.6Mode of Channel Set 7Channel Mode 10.5.2.6Mode of Channel Set 6Channel Mode 10.5.2.6Mode of Channel Set 7Channel Mode 10.5.2.6Mode of Channel Set 8Channel Mode 10.5.2.6Mode of Channel Set 8Channel Mode 10.5.2.7Mode of the Second ChannelChannel Mode 2 10.5.2.7Mobile Allocation, after timeMobile Allocation 10.5.2.13Description of the Frequency List, before timeFrequency List 10.5.2.5aDescription of the First Channel, before timeChannel Description 2 10.5.2.5aDescription of the Second Channel, before timeChannel Description 10.5.2.5aDescription of the Second Channel, before timeChannel Description 10.5.2.12Mobile Allocation, Mobile Allocation	Power Command 10.5.2.28MFrequency List, after timeFrequency List requency List, after timeCFrequency List, after timeFrequency List 10.5.2.13CCell Channel DescriptionCell Channel Description 10.5.2.1bODescription of the multislot configurationMultislot Allocation 10.5.2.21bCMode of the First Channel Set 1)Channel Mode 10.5.2.6OMode of Channel Set 2Channel Mode 10.5.2.6OMode of Channel Set 3Channel Mode 10.5.2.6OMode of Channel Set 4Channel Mode 10.5.2.6OMode of Channel Set 5Channel Mode 10.5.2.6OMode of Channel Set 6Channel Mode 10.5.2.6OMode of Channel Set 7Channel Mode 10.5.2.6OMode of Channel Set 7Channel Mode 10.5.2.6OMode of Channel Set 7Channel Mode 10.5.2.6OMode of Channel Set 8Channel Mode 10.5.2.6OMode of Channel Set 7Channel Mode 10.5.2.6OMode of Channel Set 8Channel Mode 10.5.2.6OMode of Channel Set 8Channel Mode 2 10.5.2.6OMode of the Second Channel Mode 2O10.5.2.7OMobile Allocation, after timeMobile Allocation 10.5.2.7Mobile Allocation, after timeCStarting Time 10.5.2.38CFrequency List, before time 10.5.2.5CFrequency List, before time 10.5.2.5CPercuption of the	Power Command         Power Command         M         V           Frequency List, after time         Frequency List         C         TLV           0.5.2.28         0         TV         10.5.2.13         C         TLV           Cell Channel         Cell Channel Description         0         TV         10.5.2.15         O         TV           Description         10.5.2.15         0         TV         10.5.2.15         O         TV           Mode of the First         Channel Mode         0         TV         TV         10.5.2.6         O         TV           Mode of Channel Set 1         10.5.2.6         0         TV         10.5.2.6         O         TV           Mode of Channel Set 3         Channel Mode         0         TV         10.5.2.6         O         TV           Mode of Channel Set 4         Channel Mode         0         TV         10.5.2.6         O         TV           Mode of Channel Set 5         Channel Mode         0         TV         10.5.2.6         O         TV           Mode of Channel Set 6         Channel Mode         0         TV         10.5.2.6         O         TV           Mode of Channel Set 8         Channel Mode         0

IEI	Information element	Type / Reference	Presence	Format	length
9-	Cipher Mode Setting	Cipher Mode Setting	0	TV	1
		10.5.2.9			
01	VGCS target mode Indication	VGCS target mode	0	TLV	3
		Indication			
		10.5.2.42a			
03	Multi-Rate	MultiRate configuration	0	TLV	4-8
	configuration	10.5.2.21aa			

# 9.1.2.1 Mode of the First Channel (Channel Set 1) and Mode of Channel Set "X" (2=<X=<8)

If this information element is not present the channel mode of the previously allocated channel or channels for Channel Set "X"  $(1 = \langle X \langle = 8 \rangle$  shall be assumed.

If Channel Set "X" is not defined for the configuration, the *Mode of Channel Set* "X" IE shall be considered as an IE unnecessary in the message.

NOTE: Sub-clause 3.4.3.1 defines cases when one or several *Mode of Channel Set "X"* IEs shall be included in the message.

## 9.1.2.2 Description of the Second Channel

These information elements appear in the case of an assignment occurring if the mobile station carries two connections (on two dedicated channels, for the TCH/H + TCH/H configuration).

The connection using the channel previously defined in the *Description of the First Channel* IEs of an ASSIGNMENT COMMAND or HANDOVER COMMAND message shall use the channel defined in the *Description of the First Channel* IEs of the ASSIGNMENT COMMAND message defining the new configuration.

The channel described in the *Description of the First Channel* IEs carries the main DCCH. The SACCH used is the one associated with that channel.

## 9.1.2.3 Mode of the Second Channel

If no *Description of the Second Channel* IE is present but the information element is present it shall be considered as an IE unnecessary in the message.

This information element appears at least when the channel mode is changed for the channel defined in the second channel description information elements.

### 9.1.2.4 Mobile Allocation and Frequency List, after the starting time

If at least one of the channel descriptions for the starting time indicates frequency hopping, one and only one of the following information elements shall be present and apply to all assigned channels:

- Mobile Allocation, after time;
- Frequency List, after time.

If neither of the Channel Description IEs for after time indicate frequency hopping, if decoding of Channel Description IEs for before time does not require a frequency list for after time (see next sub-clause), and one or both of the two information elements are present they shall be considered as IEs unnecessary in the message.

### 9.1.2.5 Starting Time

The *starting time* information element is included when the network wants the mobile station to change the frequency parameters of the channels more or less at the moment a change of channel occurs. In this case a number of information elements may be included to give the frequency parameters to be used before the starting time.

If the *starting time* information element is present and none of the information elements referring to before the starting time are present, the mobile station waits and accesses the channels at the indicated time.

If the *starting time* information element is present and at least one of the information elements referring to before the starting time is present, the mobile station does not wait for the indicated time and accesses the channel using the frequency parameters for before the starting time.

If the *starting time* information element is not present and at some of the information elements referring to before the starting time is present, these information elements shall be considered as IEs unnecessary in the message.

If the *description of the first channel, before time* IE is not present, the channel description to apply for before the time, if needed, is given by the *description of the first channel, after time* IE.

If the *description of the second channel, after time* IE is present, the *description of the second channel, before time* IE not present, and a description of the configuration for before the time needed, the channel configuration before the starting time is nevertheless of two traffic channels, and the channel description to apply to the second channel before the starting time is given by the *description of the second channel, after time* IE.

If the *starting time* IE is present and at least one of the channel descriptions for before the starting time indicates frequency hopping, one and only one of the following information elements may be present and applies before the starting time to all assigned channels

- *Mobile Allocation, before time* IE;
- Frequency list, before time IE;
- Frequency channel sequence, before time IE.

If the *starting time* IE is present and at least one of the channel descriptions for before the starting time indicates frequency hopping, and none of the above mentioned IE is present, a frequency list for after the starting time must be present (see sub-clause 9.1.2.4), and this list applies also for the channels before the starting time.

#### 9.1.2.6 Reference cell frequency list

If any of the *mobile allocation* information elements is present, then the network must ensure that either the mobile station has received in a previous message the proper reference cell frequency list (CA), or that the *cell channel description* IE is present.

If the *cell channel description* IE is present, it is used to decode the *mobile allocation* IEs in the message, as well as in later messages until reception of a new reference cell frequency list or the cell is left.

#### 9.1.2.7 Cell Channel Description

If present, this information element shall be used to decode the *Mobile Allocation* IE in the same message and in subsequent messages.

### 9.1.2.8 Cipher Mode Setting

If this information element is omitted, the mode of ciphering is not changed after the mobile station has switched to the assigned channel.

#### 9.1.2.9 VGCS target mode Indication

This information element is identified as "comprehension required". Only mobile stations supporting "VGCS talking " are required to accept the presence of the element. The presence of the element shall trigger an exception handling if received by a mobile station not supporting "VGCS talking".

This IE indicates which mode is to be used on the new channel (i.e. dedicated mode or group transmit mode). If this information element is not present, the mode shall be the same as on the previous channel.

The IE also indicates the group cipher key number for the group cipher key to be used on the new channel or if the new channel is non ciphered. If the information element is not present, the ciphering mode shall be the same as on the previous channel.

NOTE: A mobile station supporting VGCS talking shall not consider a syntactical error when this IE is present and the channel mode is not speech.

### 9.1.2.10 Description of the multislot allocation

This information element is included if so indicated by the channel type and TDMA offset field in the *Channel Description* information element and is used to assign channels that do not carry a main signalling link in a multislot configuration. It indicates how the used timeslots are divided into separate channel sets.

If the *Channel Description* IE does not require the presence of the information element the *Description of the multislot allocation* IE shall be considered as an IE unnecessary in the message.

If multislot configuration is indicated by the *Channel Description* IE but the *Multislot Allocation* IE is not present, all channels in the configuration belong to one channel set, "Channel Set 1".

NOTE: As a change of timeslot number cannot occur for the channel described after the starting time, the *Multislot Allocation* IE does not have to be included more than once.

### 9.1.2.11 Multi Rate configuration

This information element appears if the Mode of the First Channel indicates a multi-rate speech codec, and if the assigned configuration is new, i.e. it is different from the MultiRateconfiguration of a previously allocated channel in the cell.

# 9.1.3 Assignment complete

This message is sent on the main DCCH from the mobile station to the network to indicate that the mobile station has established the main signalling link successfully. See table 9.4/3GPP TS 04.08.

Message type: ASSIGNMENT COMPLETE

Significance: dual

Direction: mobile station to network

#### Table 9.4/3GPP TS 04.08: ASSIGNMENT COMPLETE message content

IEI	Information element	Type / Reference	Presence	Format	length
	RR management	Protocol Discriminator	М	V	1/2
	Protocol Discriminator	10.2			
	Skip Indicator	Skip Indicator	М	V	1/2
		10.3.1			
	Assignment Complete	Message Type	М	V	1
	Message Type	10.4			
	RR Cause	RR Cause	М	V	1
		10.5.2.31			

## 9.1.4 Assignment failure

This message is sent on the main DCCH on the old channel from the mobile station to the network to indicate that the mobile station has failed to seize the new channel. See table 9.5/3GPP TS 04.08.

Message type: ASSIGNMENT FAILURE

Significance: dual

IEI	Information element	Type / Reference	Presence	Format	length
	RR management	Protocol Discriminator	М	V	1/2
	Protocol Discriminator	10.2			
	Skip Indicator	Skip Indicator	М	V	1/2
		10.3.1			
	Assignment Failure	Message Type	М	V	1
	Message Type	10.4			
	RR cause	RR Cause	М	V	1
		10.5.2.31			

Table 9.5/3GPP TS 04.08: ASSIGNMENT FAILURE message content

# 9.1.5 Channel mode modify

This message is sent on the main DCCH by the network to the mobile station to request the setting of the mode for the indicated channel(s). The message can be used to change the channel mode of a Multislot Configuration which only contains one channel set. See table 9.6/3GPP TS 04.08.

Message type: CHANNEL MODE MODIFY

Significance: local

Direction: network to mobile station

#### Table 9.6/3GPP TS 04.08: CHANNEL MODE MODIFY message content

IEI	Information element	Type / Reference	Presence	Format	length
	RR management	Protocol Discriminator	М	V	1/2
	Protocol Discriminator	10.2			
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Channel Mode Modify	Message Type	М	V	1
	Message Type	10.4			
	Channel Description	Channel Description 2 10.5.2.5a	М	V	3
	Channel Mode	Channel Mode 10.5.2.6	М	V	1
01	VGCS target mode Indication	VGCS target mode Indication 10.5.2.42a	0	TLV	3
03	Multi-Rate configuration	MultiRate configuration 10.5.2.21aa	0	TLV	4-8

### 9.1.5.1 Channel Description

This is sufficient to identify the channel in the case of a TCH/H + TCH/H configuration. If used for a multislot configuration, the IE shall describe the present channel configuration with TN indicating the main channel. The IE shall not indicate a new channel configuration when included in the Channel Mode Modify message.

## 9.1.5.2 VGCS target mode Indication

This information element is identified as "comprehension required". Only mobile stations supporting "VGCS talking " are required to accept the presence of the element. The presence of the element shall trigger an exception handling if received by a mobile station not supporting "VGCS talking".

This IE indicates which RR mode is to be used with the new channel mode (i.e. dedicated mode or group transmit mode). If this information element is not present, the RR mode shall be the same as with the previous channel mode.

The IE also indicates the group cipher key number for the group cipher key to be used on the new channel or if the new channel is non ciphered. If the information element is not present, the ciphering mode shall be the same as with the previous channel mode.

NOTE: A mobile station supporting VGCS Talking shall not consider a syntactical error if this IE is present and the channel mode is not speech.

#### 9.1.5.3 Multi Rate configuration

This information element appears if the Channel Mode IE indicates a multi-rate speech codec.

# 9.1.6 Channel mode modify acknowledge

This message is sent on the main DCCH by the mobile station to the network to indicate the successful or unsuccessful execution of a channel mode modify request. See table 9.7/3GPP TS 04.08.

Message type: CHANNEL MODE MODIFY ACKNOWLEDGE

Significance: local

Direction: mobile station to network

## Table 9.7/3GPP TS 04.08: CHANNEL MODE MODIFY ACKNOWLEDGE message content

IEI	Information element	Type / Reference	Presence	Format	length
	RR management	Protocol Discriminator	М	V	1/2
	Protocol Discriminator	10.2			
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Channel Mode Modify Acknowledge Message Type	Message Type 10.4	М	V	1
	Channel Description	Channel Description 2 10.5.2.5a	М	V	3
	Channel Mode	Channel Mode 10.5.2.6	М	V	1

# 9.1.7 Channel release

This message is sent on the main DCCH from the network to the mobile station to initiate deactivation of the dedicated channel used. See table 9.8/3GPP TS 04.08

Message type: CHANNEL RELEASE

Significance: dual

Direction: network to mobile station

IEI	Information element	Type / Reference	Presence	Format	length
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Channel Release Message Type	Message Type 10.4	М	V	1
	RR Cause	RR Cause 10.5.2.31	M	V	1
73	BA Range	BA Range 10.5.2.1a	0	TLV	6 - ?
74	Group Channel Description	Group Channel Description 10.5.2.14b	0	TLV	4-13
8x	Group Cipher Key Number	Group Cipher Key Number 10.5.1.10	С	TV	1
Сх	GPRS Resumption	GPRS Resumption 10.5.2.14c	0	TV	1
75	BA List Pref	BA List Pref 10.5.2.1c	0	TLV	3-?

#### Table 9.8/3GPP TS 04.08: CHANNEL RELEASE message content

## 9.1.7.1 Channel description and mobile allocation

If a CHANNEL RELEASE is send to a mobile station which is in dedicated mode and which is involved in a voice group call or has responded to a notification to a voice group call or voice broadcast call, a group channel description may be included, describing the voice group call channel or voice broadcast channel to which the mobile station shall go after the channel release procedure.

Mobile stations not supporting VGCS listening or VBS listening shall consider this information element as unnecessary.

## 9.1.7.2 Group Cipher Key Number

This IE may be present only if the Group channel description IE is provided. The presence of this IE indicates that the mobile station shall use the Group Cipher Key indicated by the Group Cipher Key Number IE for deciphering on the VGCS or VBS channel. If this IE is not present, no ciphering is applied on the VGCS or VBS channel.

Mobile stations not supporting VGCS listening or VBS listening shall ignore this information element.

## 9.1.8 Channel request

This message is sent in random mode on the RACH. It does not follow the basic format. The possible formats are presented directly below, without reference to information fields. The order of bit transmission is defined in 3GPP TS 04.04.

The message is only one octet long, coded as shown in figure 9.1/GSM 4.08 and table 9.9/3GPP TS 04.08.




Figure 9.1/3GPP TS 04.08: CHANNEL REQUEST message content

#### ESTABLISHMENT CAUSE (octet 1)

This information field indicates the reason for requesting the establishment of a connection. This field has a variable length (from 3 bits up to 6 bits).

#### RANDOM REFERENCE (octet 1)

This is an unformatted field with variable length (from 5 bits down to 2 bits).

The Channel Request message is coded as follows: (Random Reference field is filled with "x").

Table 9.9/3GPP TS 04.08:	CHANNEL	REQUEST	message	content
TADIC 3.3/JOFF 13 04.00.	CHANNEL	REQUEST	messaye (	Jointeint

MS codes bits 8 1	According to Establishment cause:	
101xxxxx	Emergency call	
110xxxxx TCH/H v set NECI	Call re-establishment; TCH/F was in use, or yas in use but the network does not bit to 1	
011010xx network s	Call re-establishment; TCH/H was in use and the sets NECI bit to 1	
011011xx and the n	Call re-establishment; TCH/H + TCH/H was in use etwork sets NECI bit to 1	e
100xxxxx 0010xxxx	Answer to paging	
0010xxxx 0011xxxx 0001xxxx	See table 9.9a/3GPP TS 04.08	
procedure	Originating call and TCH/F is needed, or originating etwork does not set NECI bit to 1, or es that can be completed with a SDCCH and the loes not set NECI bit to 1.	ng call note 1
0100xxxx is sufficie	Originating speech call from dual-rate mobile stati ent and supported by the MS for speech calls and the ne	
0101xxxx is sufficie	Originating data call from dual-rate mobile station and supported by the MS for data calls and the network	
000xxxxx	Location updating and the network does not set NI	ECI bit to 1
0000xxxx	Location updating and the network sets NECI bit t	io 1
0001xxxx an SDCC	Other procedures which can be completed with H and the network sets NECI bit to 1	note 1
011110xx 01111x0x 01111xx0	One phase packet access with request for single tir transmission; one PDCH is needed.	neslot uplink
01110xxx two phase	Single block packet access; one block period on a e packet access or other RR signalling purpose.	PDCH is needed for
01100111	LMU establishment	note 2
01100xx0 01100x01	Reserved for future use	
01100011		note 2a
01100011		note 2a

NOTE 1: Examples of these procedures are: IMSI detach, Short Message Service (SMS), Supplementary Service management, Location Services.

NOTE 2: If such messages are received by a network, an SDCCH shall be allocated.

NOTE 2a: If such messages are received by a network, an SDCCH may be allocated.

NOTE 2b: This value shall not be used by the mobile station on RACH. If such message is received by the network, it may be ignored.

++ MS Capability ++ Paging ++ Indication 3) +	Full rate only	Dual rate (note 5)	SDCCH only
Any channel	100xxxxx	100xxxxx	100xxxxx
SDCCH	0001xxxx	0001xxxx	0001xxxx
TCH/F	100xxxxx	0010xxxx	0001xxxx
TCH/H or TCH/F	100xxxxx	0011xxxx	0001xxxx

Table 9.9a/3GPP TS 04.08: CHANNEL REQUEST message (when answering to paging for RR connection establishment)

- NOTE 3: The Paging Indication is provided by the Channel Needed IE (or the Channel Needed field) associated with the page which triggered the sending of the CHANNEL REQUEST message.
- NOTE 4: In some cases the established connection will be used only to allow a default rejection mechanism to take place (typically the mobile station will send a RELEASE COMPLETE message with cause #88 "incompatible destination" as an answer to the incoming SETUP message).
- NOTE 5: In this sub-clause, "dual rate capability" means that the MS supports both full rate and half-rate channels at least for the signalling channel mode. In addition, it may support either speech channel mode, or data channel modes, or both on half-rate channels.

# 9.1.9 Ciphering mode command

This message is sent on the main DCCH from the network to the mobile station to indicate that the network has started deciphering and that enciphering and deciphering shall be started in the mobile station, or to indicate that ciphering will not be performed. See table 9.10/3GPP TS 04.08.

Message type: CIPHERING MODE COMMAND

Significance: dual

Direction: network to mobile station

#### Table 9.10/3GPP TS 04.08: CIPHERING MODE COMMAND message content

IEI	Information element	Type / Reference	Presence	Format	length
	RR management	Protocol Discriminator	M	V	1/2
	Protocol Discriminator	10.2			
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Cipher Mede Command		M	V	1
	Cipher Mode Command Message Type	Message Type 10.4	М	V	1
	Ciphering Mode Setting	Cipher Mode Setting 10.5.2.9	М	V	1/2
	Cipher Response	Cipher Response 10.5.2.10	М	V	1/2

# 9.1.10 Ciphering mode complete

This message is sent on the main DCCH from the mobile station to the network to indicate that enciphering and deciphering has been started in the MS. See table 9.11/3GPP TS 04.08.

Message type: CIPHERING MODE COMPLETE

Significance: dual

IEI	Information element	Type / Reference	Presence	Format	length
	RR management	Protocol Discriminator	М	V	1/2
	Protocol Discriminator	10.2			
	Skip Indicator	Skip Indicator	М	V	1/2
		10.3.1			
	Cipher Mode Complete	Message Type	М	V	1
	Message Type	10.4			
17	Mobile Equipment	Mobile Identity	0	TLV	3-11
	Identity	10.5.1.4			

Table 9.11/3GPP TS 04.08: CIPHERING MODE COMPLETE message content

#### 9.1.10.1 Mobile Equipment Identity

This information element is included if and only if the mobile station shall include its IMEISV (see sub-clause 3.4.7). This information element shall only refer to IMEISV.

# 9.1.11 Classmark change

This message is sent on the main DCCH by the mobile station to the network to indicate a classmark change or as a response to a classmark enquiry. See table 9.12/3GPP TS 04.08.

Message type: CLASSMARK CHANGE

Significance: dual

Direction: mobile station to network

IEI	Information element	Type / Reference	Presence	Format	length
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Classmark Change Message Type	М	V	1	
	Mobile Station Classmark	Mobile Station Classmark 2 10.5.1.6	M	LV	4
20	Additional Mobile Station Classmark Information	Mobile Station Classmark 3 10.5.1.7	С	TLV	3-14

#### 9.1.11.1 Additional Mobile Station Classmark Information

This IE shall be included if and only if the CM3 bit in the Mobile Station Classmark IE is set to 1.

#### 9.1.11.2 Mobile Station Classmark

This IE shall include for multiband MS the Classmark 2 corresponding to the frequency band in use.

## 9.1.12 Classmark enquiry

This message is sent on the main DCCH by the network to the mobile station to request classmark information. See table 9.12a/3GPP TS 04.08.

Message type: CLASSMARK ENQUIRY

Significance: dual

Direction: network to mobile station

#### Table 9.12a/3GPP TS 04.08: CLASSMARK ENQUIRY message content

IEI	Information element	Type / Reference	Presence	Format	length
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Classmark Enquiry Message Type	Message Type 10.4	М	V	1

# 9.1.12a Spare

# 9.1.12b Configuration change command

This message is sent on the main DCCH from the network to the mobile station to change the channel configuration of a multislot configuration. See table 9.12b/3GPP TS 04.08.

Message type: CONFIGURATION CHANGE COMMAND

Significance: dual

Direction: network to mobile station

#### Table 9.12b/3GPP TS 04.08: CONFIGURATION CHANGE COMMAND message contents

IEI	Information element	Type/Reference	Presence	Format	length
	RR management	Protocol Discriminator	М	V	1/2
	Protocol Discriminator	10.2			
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Configuration change Message Type	Message Type 10.4	М	V	1
	Description of the multislot configuration	Multislot Allocation 10.5.2.21b	М	LV	2-11
63	Mode of Channel Set 1	Channel Mode 10.5.2.6	0	TV	2
11	Mode of Channel Set 2	Channel Mode 10.5.2.6	0	TV	2
13	Mode of Channel Set 3	Channel Mode 10.5.2.6	0	TV	2
14	Mode of Channel Set 4	Channel Mode O 10.5.2.6		TV	2
15	Mode of Channel Set 5	Channel Mode 10.5.2.6	0	TV	2
16	Mode of Channel Set 6	Channel Mode 10.5.2.6	0	TV	2
17	Mode of Channel Set 7	Channel Mode 10.5.2.6	0	TV	2
18	Mode of Channel Set 8	Channel Mode 10.5.2.6	0	TV	2

#### 9.1.12b.1 Description of the multislot allocation

This information element is used to assign channels that do not carry the main signalling link in a multislot configuration. It indicates if multiple channel sets are used.

## 9.1.12b.2 Mode of Channel Set "X" (1=<X<=8)

If this information element is not present the channel mode of the previously allocated channel or channels for Channel Set "X" shall be assumed.

If Channel Set "X" is not defined for the configuration, the *Mode of Channel Set "X"* IE shall be considered as an IE unnecessary in the message.

NOTE: Sub-clause 3.4.16.1 defines cases when one or several *Mode of Channel Set "X"* IEs shall be included in the message.

## 9.1.12c Configuration change acknowledge

This message is sent on the main DCCH from the mobile station to the network to indicate that the mobile station has changed to the ordered channel configuration successfully. See table 9.12c/3GPP TS 04.08.

Message type: CONFIGURATION CHANGE ACKNOWLEDGE

Significance: dual

Direction: mobile station to network

#### Table 9.12c/3GPP TS 04.08: CONFIGURATION CHANGE ACKNOWLEDGE message contents

IEI	Information element	Type/Reference	Presence	Format	length
	RR management	Protocol Discriminator	M	V	1/2
	Protocol Discriminator	10.2			
	Skip Indicator	Skip Indicator	M	V	1/2
		10.3.1			
	Configuration Change	Message Type	M	V	1
	Acknowledge Message Type	10.4			

# 9.1.12d Configuration change reject

This message is sent on the main DCCH from the mobile station to the network to indicate that the mobile station has not managed to switch to the channel configuration ordered by the configuration change command and is still using the previous configuration. See table 9.12d/3GPP TS 04.08.

Message type: CONFIGURATION CHANGE REJECT

Significance: dual

Direction: mobile station to network

#### Table 9.12d/3GPP TS 04.08: CONFIGURATION CHANGE REJECT message contents

IEI	Information element	Type/Reference	Presence	Format	length
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Configuration Change Reject Message Type	Message Type 10.4	М	V	1
	RR Cause	RR Cause 10.5.2.31	М	V	1

# 9.1.13 Frequency redefinition

This message is sent on the main DCCH from the network to the MS to indicate that the frequencies and the hopping sequence of the allocated channels shall be changed. See table 9.13/3GPP TS 04.08

Message type: FREQUENCY REDEFINITION

Significance: dual

Direction: network to MS

#### Table 9.13/3GPP TS 04.08: FREQUENCY REDEFINITION message content

IEI	Information element	Type / Reference	Presence	Format	length
	RR management	Protocol Discriminator	М	V	1/2
	Protocol Discriminator	10.2			
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Frequency Redefinition	Message Type	М	V	1
	Message Type	10.4			
	Channel Description	Channel Description 10.5.2.5	М	V	3
	Mobile Allocation	Mobile Allocation 10.5.2.21	М	LV	1-9
	Starting Time	Starting Time 10.5.2.38	М	V	2
62	Cell Channel Description	Cell Channel Description 10.5.2.1b	0	TV	17

#### 9.1.13.1 Cell Channel Description

If it does not appear, the cell channel description is assumed to be unchanged.

# 9.1.13a PDCH Assignment command

This message is sent on the main DCCH by the network to the mobile station to change the channel configuration to a PDCH, when no timing adjustment is needed. See table 9.13a/3GPP TS 04.08.

A mobile station that does not support the <<<GRPS>> option shall regard this message as an unknown message.

Message type: PDCH ASSIGNMENT COMMAND

Significance: dual

Direction: network to mobile station

IEI	Information element	Type / Reference	Presence	Format	length
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	PDCH Assignment command Message Type	Message Type 10.4	М	V	1
	Description of the Channel, after time	Channel Description 10.5.2.5	М	V	3
62	Cell Channel Description	Cell Channel Description 10.5.2.1b	0	TV	17
05	Frequency List, after time	Frequency List 10.5.2.13	С	TLV	4-132
72	Mobile Allocation, after time	Mobile Allocation 10.5.2.21	С	TLV	3-10
7C	Starting Time	Starting Time 10.5.2.38	0	TV	3
19	Frequency List, before time	Frequency List 10.5.2.13	С	TLV	4-132
1C	Description of the Channel, before time	Channel Description 10.5.2.5	0	TV	4
1E	Frequency channel sequence before time	Frequency channel sequence 10.5.2.12	С	TV	10
21	Mobile Allocation, before time	Mobile Allocation 10.5.2.21	С	TLV	3-10
22	RR Packet Uplink Assignment	RR Packet Uplink Assignment 10.5.2.25c	С	TLV	3-?
23	RR Packet Downlink Assignment	RR Packet Downlink Assignment 10.5.2.25d	С	TLV	3-?

Table 9.13a/3GPP TS 04.08: PDCH ASSIGNMENT COMMAND message content

### 9.1.13a.1 Mobile Allocation and Frequency List, after the starting time

If the channel description for after the starting time indicates frequency hopping, one and only one of the following information elements shall be present

- Mobile Allocation, after time;
- Frequency List, after time.

If the Channel Description IE for after time does not indicate frequency hopping, if decoding of Channel Description IE for before time does not require a frequency list for after time (see next sub-clause), and one or both of the two information elements are present they shall be considered as IEs unnecessary in the message.

### 9.1.13a.2 Starting Time

The *starting time* information element is included when the network wants the mobile station to change the frequency parameters of the channels more or less at the moment the change to a TBF occurs. In this case a number of information elements may be included to give the frequency parameters to be used before the starting time.

If the *starting time* information element is present and none of the information elements referring to before the starting time are present, the mobile station waits and uses the TBFfrom the indicated time.

If the *starting time* information element is present and at least one of the information elements referring to before the starting time is present, the mobile station does not wait for the indicated time and uses the TBF using the frequency parameters for before the starting time.

If the *starting time* information element is not present and some of the information elements referring to before the starting time is present, these information elements shall be considered as IEs unnecessary in the message.

If the *description of the channel, before time* IE is not present, the channel description to apply for before the time, if needed, is given by the *description of the channel, after time* IE.

If the *starting time* IE is present and the channel description for before the starting time indicates frequency hopping, one and only one of the following information elements may be present and applies before the starting time:

- Mobile Allocation, before time IE;
- Frequency list, before time IE;
- Frequency channel sequence, before time IE.

If the *starting time* IE is present and the channel description for before the starting time indicates frequency hopping, and none of the above mentioned IE is present, a frequency list for after the starting time must be present (see subclause 9.1.2.4), and this list applies also for the TBF before the starting time.

### 9.1.13a.3 Reference cell frequency list

If any of the *mobile allocation* information elements are present, then the network shall ensure that either the mobile station has received in a previous message the proper reference cell frequency list (CA), or that the *cell channel description* IE is present.

If the *cell channel description* IE is present, it is used to decode the *mobile allocation* IEs in the message, as well as in later dedicated mode messages until reception of a new reference cell frequency list or the cell is left.

### 9.1.13a.4 Cell Channel Description

If present, this information element shall be used to decode the *Mobile Allocation* IE in the same message and in subsequent messages.

#### 9.1.13a.5 Packet Assignment

One and only one of the following information elements shall be present:

- RR Packet Uplink Assignment;
- RR Packet Downlink Assignment.

# 9.1.13b GPRS suspension request

This message is sent on the main DCCH by the mobile station to the network to request a suspension of GPRS services. See table 9.13b/3GPP TS 04.08.

Message type: GPRS SUSPENSION REQUEST

Significance: dual

IEI	Information element	Type / Reference	Presence	Format	length
	RR management	Protocol Discriminator	М	V	1/2
	Protocol Discriminator	10.2			
	Skip Indicator	Skip Indicator	М	V	1/2
		10.3.1			
	GPRS Suspension Request	Message Type	М	V	1
	Message Type	10.4			
	Temporary Logical Link	TLLI	M	V	4
	Identity	10.5.2.41a			
	Routeing Area Identification	Routeing Area Identification	M	V	6
		10.5.5.15			
	Suspension cause	Suspension cause	M	V	1
		10.5.2.47			

Table 9.13b/3GPP TS 04.08: GPRS SUSPENSION REQUEST message content

# 9.1.14 Handover access

This message is sent in random mode on the main DCCH during a handover procedure. It does not follow the basic format. The format is presented directly below without reference to information elements. The order of bit transmission is defined in 3GPP TS 04.04.

This message is only one octet long, coded as shown in figure 9.2/3GPP TS 04.08 and table 9.14/3GPP TS 04.08.

<b>.</b>	8	7	6	5	4	3	2	1		
handover reference   octet						1				
+								+		

#### Figure 9.2/3GPP TS 04.08: HANDOVER ACCESS message content

#### Table 9.14/3GPP TS 04.08: HANDOVER ACCESS message content

```
HANDOVER REFERENCE
This is an unformatted 8 bit field.
(also described in sub-clause 10.5.2.15)
```

# 9.1.15 Handover command

This message is sent on the main DCCH by the network to the mobile station to change the dedicated channel configuration, timing adjustment needed. See table 9.15/3GPP TS 04.08.

Message type:	HANDOVER COMMAND
Significance:	dual
Direction:	network to mobile station

IEI	Information element	Type / Reference	Presence	Format	length
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Handover Command Message Type	Message Type 10.4	М	V	1
	Cell Description	Cell description 10.5.2.2	М	V	2
	Description of the first channel, after time	Channel Description 2 10.5.2.5a	М	V	3
	Handover Reference	Handover Reference 10.5.2.15	М	V	1
	Power Command and Access type	Power Command and Access type 10.5.2.28a	М	V	1
D-	Synchronization Indication	Synchronization Indication 10.5.2.39	0	TV	1
02	Frequency Short List, after time	Frequency Short List 10.5.2.14	С	TV	10
05	Frequency List, after time	Frequency List 10.5.2.13	С	TLV	4-131
62	Cell Channel Description	Cell Channel Description 10.5.2.1b	С	TV	17
10	Description of the multislot configuration	Multislot Allocation 10.5.2.21b	С	TLV	3-12
63	Mode of the First Channel(Channel Set 1))	Channel Mode 10.5.2.6	0	TV	2
11	Mode of Channel Set 2	Channel Mode 10.5.2.6	0	TV	2
13	Mode of Channel Set 3	Channel Mode 10.5.2.6	0	TV	2
14	Mode of Channel Set 4	Channel Mode 10.5.2.6	0	TV	2
15	Mode of Channel Set 5	Channel Mode 10.5.2.6	0	TV	2
16	Mode of Channel Set 6	Channel Mode 10.5.2.6	0	TV	2
17	Mode of Channel Set 7	Channel Mode 10.5.2.6	0	TV	2
18	Mode of Channel Set 8	Channel Mode 10.5.2.6	0	TV	2
64	Description of the Second Channel, after time	Channel Description 10.5.2.5	0	TV	4
66	Mode of the Second Channel	Channel Mode 2 10.5.2.7	0	TV	2
69	Frequency Channel Sequence, after time	Frequency Channel Sequence 10.5.2.12	С	TV	10
72	Mobile Allocation, after time	Mobile Allocation 10.5.2.21	С	TLV	3-10
7C	Starting Time	Starting Time 10.5.2.38	0	TV	3
7B	Real Time Difference	Time Difference 10.5.2.41	С	TLV	3
7D	Timing Advance	Timing Advance 10.5.2.40	С	TV	2
12	Frequency Short List, before time	Frequency Short List 10.5.2.14	С	TV	10
19	Frequency List, before time	Frequency List 10.5.2.13	С	TLV	4-131
1C	Description of the First Channel, before time	Channel Description 2 10.5.2.5a	0	TV	4

IEI	Information element	Type / Reference	Presence	Format	length
1D	Description of the	Channel Description	0	ΤV	4
	Second Channel, before time	10.5.2.5			
1E	Frequency channel sequence	Frequency channel sequence	С	TV	10
	before time	10.5.2.12			
21	Mobile Allocation,	Mobile Allocation	С	TLV	3-10
	before time	10.5.2.21			
9-	Cipher Mode Setting	Cipher Mode Setting	0	ΤV	1
		10.5.2.9			
01	VGCS target mode Indication	VGCS target mode Indication	0	TLV	3
		10.5.2.42a			
03	Multi-Rate	MultiRate configuration	0	TLV	4-8
	configuration	10.5.2.21aa			

#### 9.1.15.1 Synchronization Indication

If this information element does not appear, the assumed value is "non-synchronized".

# 9.1.15.2 Mode of the First Channel (Channel Set 1) and Mode of Channel Set "X" (2=<X<=8)

If this information element is not present the channel mode of the previously allocated channel or channels for Channel Set "X" (1 = < X <= 8) shall be assumed.

If Channel Set "X" is not defined for the configuration, the *Mode of Channel Set "X"* IE shall be considered as an IE unnecessary in the message.

NOTE: Sub-clause 3.4.4.1 defines cases when one or several *Mode of Channel Set "X"* IEs shall be included in the message.

#### 9.1.15.3 Description of the Second Channel

These information element appear if the mobile station carries two connections (on two dedicated channels, for the TCH/H+TCH/H configuration).

The connection using the channel previously defined in the *Description of the First Channel* IE of an ASSIGNMENT COMMAND or HANDOVER COMMAND message shall use the channel defined in the first channel description IE of the HANDOVER COMMAND message defining the new configuration.

The channel described in the *Description of the First Channel* IE carries the main DCCH. The SACCH used is the one associated with that channel.

## 9.1.15.4 Mode of the Second Channel

If the *Description of the Second Channel* IE is not present and the information element is present it shall be considered as an IE unnecessary in the message.

This element appears at least when the channel mode is changed for the channel defined in the Description of the Second Channel information element.

# 9.1.15.5 Frequency Channel Sequence, Frequency List, Frequency short list and Mobile Allocation, after time

If at least one of the channel descriptions for after time indicates frequency hopping, one and only one of the following information elements shall be present:

- Frequency Channel Sequence, after time;
- Frequency list, after time;
- Frequency Short List, after time;

#### - Mobile Allocation, after time.

If neither of the Channel Description IEs indicate frequency hopping, if they are not required for the decoding of Channel Description IEs for before time, and if any of the four information elements are present they shall be considered as IEs unnecessary in the message.

The *Frequency Channel Sequence* information element shall not be used unless all the ARFCNs that it indicates are in the P-GSM band.

#### 9.1.15.6 Starting Time

The *starting time* information element is included when the network wants the mobile station to change the frequency parameters of the channels more or less at the moment a change of channel occurs. In this case a number of information elements may be included to give the frequency parameters to be used before the starting time.

The starting time information element refers to the new cell time.

If the *starting time* information element is present and none of the information elements referring to before the starting time are present, the mobile station waits and accesses the channels at the indicated time.

If the *starting time* information element is present and at least one of the information elements referring to before the starting time is present, the mobile station does not wait for the indicated time and accesses the channel using the frequency parameters for before the starting time.

If the *starting time* information element is not present and some of the information elements referring to before the starting time is present, these information elements shall be considered as IEs unnecessary in the message.

If the *description of the first channel, before time* IE is not present, the channel description to apply for before the time, if needed, is given by the *description of the first channel, after time* IE.

If the *description of the second channel, after time* IE is present, the *description of the second channel, before time* IE not present, and a description of the configuration for before the time needed, the channel configuration before the starting time is nevertheless of two traffic channels, and the channel description to apply to the second channel before the starting time is given by the *description of the second channel, after time* IE.

If the *starting time* IE is present and at least one of the channel descriptions for before the starting time indicates frequency hopping, one and only one of the following information elements may be present and applies before the starting time to all assigned channels:

- Mobile Allocation, before time IE;
- Frequency Short list, before time IE;
- Frequency list, before time IE;
- Frequency channel sequence, before time IE.

If the *starting time* IE is present and at least one of the channel descriptions for before the starting time indicates frequency hopping, and none of the above mentioned IE is present, a frequency list for after the starting time must be present (see 9.1.2.4), and this list applies also for the channels before the starting time.

### 9.1.15.7 Reference cell frequency list

If any of the *mobile allocation* information elements is present, then the *cell channel description* IE must be present. It is used to decode the *mobile allocation* IEs in the message.

In addition, if no information elements pertaining to before the starting time is present in the message, the frequency list defined by the *cell channel description* IE is used to decode the *mobile allocation* IEs in later messages received in the new cell until reception of a new reference cell frequency list or the new cell is left.

#### 9.1.15.8 Real Time Difference

This information element shall appear if the *Synchronization Indication* information element indicates a pseudo-synchronous handover otherwise it shall be considered as an unnecessary information element.

# 9.1.15.9 Timing Advance

This information element shall appear if the "synchronization indication" element indicates a presynchronized handover. If not included for a presynchronized handover, then the default value as defined in 3GPP TS 05.10 shall be used. For other types of handover it shall be considered as an unnecessary information element.

# 9.1.15.10 Cipher Mode Setting

If this information element is omitted, the mode of ciphering is not changed after the mobile station has switched to the assigned channel.

Only applicable for mobile stations supporting VGCS talking:

The cipher mode setting IE shall not be included if a HANDOVER COMMAND message is sent on a VGCS channel or in a HANDOVER COMMAND message on a dedicated channel for a handover to a VGCS channel.

# 9.1.15.11 VGCS target mode indication

This information element is identified as "comprehension required". Only mobile stations supporting "VGCS talking " are required to accept the presence of the element. The presence of the element shall trigger an exception handling if received by a mobile station not supporting "VGCS talking ".

This IE indicates which mode is to be used on the new channel (i.e. dedicated mode or group transmit mode). If this information element is not present, the mode shall be the same as on the previous channel.

The IE also indicates the group cipher key number for the group cipher key to be used on the new channel or if the new channel is non ciphered. If the information element is not present, the ciphering mode shall be the same as on the previous channel.

NOTE: A mobile station supporting VGCS Talking shall not consider a syntactical error if this IE is present and the channel mode is not speech.

# 9.1.15.12 Description of the multislot allocation

This information element is included if so indicated by the channel type and TDMA offset field in the *Channel Description* information element and is used to assign channels that do not carry a main signalling link in a multislot configuration. It indicates how the used timeslots are divided into separate channel sets.

If the *Channel Description* IE does not require the presence the information element it shall be considered as an IE unnecessary in the message.

If multislot configuration is indicated by the *Channel Description* IE but the *Multislot Allocation* IE is not present, all channels in the configuration belong to one channel set, "Channel Set 1".

NOTE: As a change of timeslot number cannot occur for the channel described for after the starting time, the *Multislot Allocation* IE does not have to be included more than once.

# 9.1.15.13 MultiRateconfiguration

This information element appears if the Mode of the First Channel indicates a multi-rate speech codec, and if the assigned configuration is new, i.e. it is different from the MultiRateconfiguration used in the serving cell. If the Mode of the First Channel indicates a multi-rate speech codec, and this IE is not included, then the mobile station shall assume that the MultiRateconfiguration has not changed.

# 9.1.16 Handover complete

This message is sent on the main DCCH from the mobile station to the network to indicate that the mobile station has established the main signalling link successfully. See table 9.16/3GPP TS 04.08.

Message type: HANDOVER COMPLETE

Significance: dual

Direction: mobile station to network

#### Table 9.16/3GPP TS 04.08: HANDOVER COMPLETE message content

IEI	Information element	Type / Reference	Presence	Format	length
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Handover Complete Message Type	Message Type 10.4	М	V	1
	RR Cause	RR Cause 10.5.2.31	М	V	1
77	Mobile Observed Time Difference	Mobile Time Difference 10.5.2.21a	0	TLV	5

#### 9.1.16.1 Mobile Observed Time Difference

This information element is included if and only if the Synchronization Indication IE in the HANDOVER COMMAND message requests it to be sent.

## 9.1.17 Handover failure

This message is sent on the main DCCH on the old channel from the mobile station to the network to indicate that the mobile station has failed to seize the new channel. See table 9.17/3GPP TS 04.08.

Message type: HANDOVER FAILURE

Significance: dual

Direction: mobile station to network

#### Table 9.17/3GPP TS 04.08: HANDOVER FAILURE message content

IEI	Information element	Type / Reference	Presence	Format	length
	RR management	Protocol Discriminator	М	V	1/2
	Protocol Discriminator	10.2			
	Skip Indicator	Skip Indicator	М	V	1/2
		10.3.1			
	Handover Failure	Message Type	М	V	1
	Message Type	10.4			
	RR Cause	RR Cause	М	V	1
		10.5.2.31			

## 9.1.18 Immediate assignment

This message is sent on the CCCH by the network to the mobile station in idle mode to change the channel configuration to a dedicated configuration while staying in the same cell or to the mobile station in packet idle mode to change the channel configuration to either an uplink or a downlink packet data channel configuration in the cell. See table 9.18/3GPP TS 04.08.

The L2 pseudo length of this message is the sum of lengths of all information elements present in the message except the *IA Rest Octets* and *L2 Pseudo Length* information elements.

Message type:	IMMEDIATE ASSIGNMENT
Significance:	dual
Direction:	network to mobile station

IEI	Information element	Type / Reference	Presence	Format	length
	L2 Pseudo Length	L2 Pseudo Length 10.5.2.19	М	V	1
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Immediate Assignment Message Type	Message Type 10.4	М	V	1
	Page Mode	Page Mode 10.5.2.26	М	V	1/2
	Dedicated mode or TBF	Dedicated mode or TBF 10.5.2.25b	М	V	1/2
	Channel Description	Channel Description 10.5.2.5	С	V	3
	Packet Channel Description	Packet Channel Description 10.5.2.25a	С	V	3
	Request Reference	Request Reference 10.5.2.30	М	V	3
	Timing Advance	Timing Advance 10.5.2.40	М	V	1
	Mobile Allocation	Mobile Allocation 10.5.2.21	М	LV	1-9
7C	Starting Time	Starting Time 10.5.2.38	0	TV	3
	IA Rest Octets	IA Rest Octets 10.5.2.16	М	V	0-11

Table 9.18/3GPP TS 04.08: IMMEDIATE ASSIGNMENT message content

## 9.1.18.0a Dedicated mode or TBF

A mobile station not supporting GPRS may ignore the contents of this information element and regard it as an unnecessary IE. Such mobile station shall assume that this message assigns a dedicated mode resource.

## 9.1.18.0b Channel Description

If the *Dedicated mode or TBF* IE indicates that the message assigns a dedicated mode resource, the mobile station shall consider this information element present in the message.

## 9.1.18.0c Packet Channel Description

If the *Dedicated mode or TBF* IE indicates that the message assigns a Temporary Block Flow (TBF), the mobile station shall consider this information element present in the message. If the *Dedicated mode or TBF* IE indicates that this message is the first of two in a two-message assignment of an uplink or downlink TBF, the mobile station shall ignore the contents of this information element and regard it as an unnecessary IE.

## 9.1.18.0d Request Reference

If this message is used in an assignment of a downlink TBF, the network shall code this information element, e.g. by using a suitably offset frame number, such that the resource reference cannot be confused with any CHANNEL REQUEST message sent by a mobile station.

If the *IA Rest Octets* IE indicates that this message is the second message of a two-message assignment of an uplink or downlink TBF, this information element shall have the same contents as the first message of the assignment.

## 9.1.18.0e Timing Advance

If the *IA Rest Octets* IE indicates that this message is the second message of a two-message assignment of an uplink or downlink TBF, the mobile station shall ignore the contents of this information element and regard it as an unnecessary IE.

## 9.1.18.1 Mobile Allocation

If this message assigns a dedicated mode resource and the *Channel Description* IE does not indicate frequency hopping , the length indicator of this information element shall be set to zero, and the mobile station shall consider the IE as an unnecessary IE.

If this message assigns a TBF and the *Packet Channel Description* IE does not indicate frequency hopping or if it uses indirect encoding of a hopping RF channel configuration, the length indicator of this information element shall be set to zero, and the mobile station shall consider the IE as an unnecessary IE.

## 9.1.18.2 Starting Time

This information element appears if e.g. a frequency change is in progress.

If this message is used in an assignment of an uplink or downlink TBF, the mobile station shall ignore the contents of the Starting Time information element if included and consider it as an unnecessary IE.

## 9.1.18.3 IA Rest Octets (Frequency parameters, before time)

The sum of the length of this IE and the L2 Pseudo Length of the message equals 22.

If the *starting time* IE is present but not the *frequency parameters, before time* construction, the mobile stations must wait until the starting time before accessing the channel.

If the *starting time* IE is present and the *Channel Description* IE does not indicate frequency hopping the mobile station shall consider the *frequency parameters, before time* construction as unnecessary in the message and the mobile must wait until the starting time before accessing the channel.

If the *starting time* IE is not present, the mobile station shall consider the *frequency parameters, before time* construction as unnecessary in the message.

## 9.1.18.4 IA Rest Octets (assignment of uplink or downlink TBF)

If the *Dedicated mode or TBF* IE indicates that this message is used in an assignment of a TBF, this information element shall contain a *Packet Uplink Assignment*, *Packet Downlink Assignment* or *Second Part Packet Assignment* construction.

If the *Dedicated mode or TBF* IE indicates that this message assigns a dedicated mode resource, but not that the mobile station is identified in the *IA Rest Octets* IE information element, the mobile station shall consider the *Packet Uplink Assignment, Packet Downlink Assignment* and *Second Part Packet Assignment* constructions as unnecessary in the message.

# 9.1.19 Immediate assignment extended

This message is sent on the CCCH by the network to two mobile stations in idle mode to change their channel configurations to different dedicated configurations while they stay in the same cell. See table 9.19/3GPP TS 04.08

The L2 pseudo length of this message is the sum of lengths of all information elements present in the message except the *IAX Rest Octets* and *L2 Pseudo Length* information elements.

Message type:	IMMEDIATE ASSIGNMENT EXTENDED
Significance:	dual
Direction:	network to mobile station

IEI	Information element	Type / Reference	Presence	Format	length
	L2 Pseudo Length	L2 Pseudo Length 10.5.2.19	М	V	1
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Immediate Assignment Ex tended Message Type	Message Type 10.4	М	V	1
	Page Mode	Page Mode 10.5.2.26	М	V	1/2
	Spare Half Octet	Spare Half Octet 10.5.1.8	М	V	1/2
	Channel Description 1	Channel Description 10.5.2.5	М	V	3
	Request Reference 1	Request Reference 10.5.2.30	М	V	3
	Timing Advance 1	Timing Advance 10.5.2.40	М	V	1
	Channel Description 2	Channel Description 10.5.2.5	М	V	3
	Request Reference 2	Request Reference 10.5.2.30	М	V	3
	Timing Advance 2	Timing Advance 10.5.2.40	М	V	1
	Mobile Allocation	Mobile Allocation 10.5.2.21	М	LV	1-5
C	Starting Time	Starting Time 10.5.2.38	0	TV	3
	IAX Rest Octets	IAX Rest Octets 10.5.2.18	М	V	0-4

Table 9.19/3GPP TS 04.08: IMMEDIATE ASSIGNMENT EXTENDED message content

NOTE: Index 1 refers to the first mobile station, index 2 refers to the second mobile station.

#### 9.1.19.1 Unnecessary IEs

A mobile station which reacts on the request reference 1 shall consider all information elements as unnecessary IEs except *for Requests Reference 1, Channel Description 1, Timing advance 1, Starting Time* and if *Channel Description 1* IE indicates frequency hopping mobile allocation.

A mobile station which reacts on the request reference 2 shall consider all information elements as unnecessary IE except *Requests Reference 2*, *Channel Description 2*, *Timing advance 2*, *Starting Time* and if *channel description 2* IE indicates frequency hopping mobile allocation.

A mobile station in idle mode shall consider all information elements as unnecessary IEs except for the Page Mode IE.

#### 9.1.19.2 Mobile Allocation

If both channel description IE do not indicate frequency hopping, the length indicator shall be set to zero.

### 9.1.19.3 Starting Time

This information element appears if a frequency change is in progress. If included the starting time is common to the two referenced mobile stations.

#### 9.1.19.4 Maximum message length

As the maximum length of the resulting layer 3 data cannot exceed 22 octets, it is not possible to use this message type if the total length of the value part of the *Mobile Allocation* plus, optionally, the length of the *Starting Time* IE exceeds 5 octets. In this case it is necessary to use the IMMEDIATE ASSIGNMENT message.

#### 9.1.19.5 IAX Rest Octets

The sum of the length of this IE and the L2 Pseudo Length of the message equals 22.

# 9.1.20 Immediate assignment reject

This message is sent on the CCCH by the network to up to four mobile stations to indicate that no channel is available for assignment. See table 9.20/3GPP TS 04.08. This message has L2 pseudo length 19.

Message type: IMMEDIATE ASSIGNMENT REJECT

Significance: dual

Direction: network to mobile station

#### Table 9.20/3GPP TS 04.08: IMMEDIATE ASSIGNMENT REJECT message content

IEI	Information element	Type / Reference	Presence	Format	length
	L2 Pseudo Length	L2 Pseudo Length 10.5.2.19	М	V	1
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Immediate Assignment Reject Message Type	Message Type 10.4	М	V	1
	Page Mode	Page Mode 10.5.2.26	М	V	1/2
	Spare Half Octet	Spare Half Octet 10.5.1.8	М	V	1/2
	Request Reference 1	Request Reference 10.5.2.30	М	V	3
	Wait Indication 1	Wait Indication 10.5.2.43	М	V	1
	Request Reference 2	Request Reference 10.5.2.30	М	V	3
	Wait Indication 2	Wait Indication 10.5.2.43	М	V	1
	Request Reference 3	Request Reference 10.5.2.30	М	V	3
	Wait Indication 3	Wait Indication 10.5.2.43	М	V	1
	Request Reference 4	Request Reference 10.5.2.30	М	V	3
	Wait Indication 4	Wait Indication 10.5.2.43	М	V	1
	IAR Rest Octets	IAR Rest Octets 10.5.2.17	М	V	3

NOTE: Index 1 refers to the first mobile station, index 2 refers to the second MS and so on.

#### 9.1.20.1 Use of the indexes

A request reference information element and the following wait indication information element refer to the same mobile station. So it is possible to reject up to four channel requests with this message.

#### 9.1.20.2 Filling of the message

If necessary the request reference information element and the wait indication information element should be duplicated to fill the message.

#### 9.1.20.3 Wait Indication

When IMMEDIATE ASSIGNMENT REJECT message is for RR connection establisment then this IE contains timeout value for T3122. If IMMEDIATE ASSIGNMENT REJECT message is for TBF establisment for GPRS MS then this IE contain timeout value for T3142.

#### 9.1.20.4 IAR Rest Octets

The sum of the length of this IE and the L2 Pseudo Length of the message equals 22.

## 9.1.21 Measurement report

This message is sent on the SACCH by the mobile station to the network to report measurement results about the dedicated channel and about neighbour cells. See table 9.21/3GPP TS 04.08.

Message type: MEASUREMENT REPORT

Significance: dual

Direction: mobile station to network

#### Table 9.21/3GPP TS 04.08: MEASUREMENT REPORT message content

IEI	Information element	Type / Reference	Presence	Format	length
	RR management	Protocol Discriminator	М	V	1/2
	Protocol Discriminator	10.2			
	Skip Indicator	Skip Indicator	М	V	1/2
		10.3.1			
	Measurement Report	Message Type	М	V	1
	Message Type	10.4			
	Measurement Results	Measurement Results	М	V	16
		10.5.2.20			

# 9.1.21a Notification/FACCH

The understanding of this message is only required for mobile stations supporting VGCS listening or VBS listening.

This message is sent on the main DCCH, in unacknowledged mode using the RR short protocol discriminator by the network to notify the mobile stations in dedicated mode or in on-going voice broadcast calls or voice group calls on other voice broadcast calls or voice group calls in that cell.

Notification/FACCH messages for VBS or VGCS calls are differentiated by a flag in the call reference.

The message shall not exceed a maximum length of 20 octets.

Mobile stations not supporting VGCS listening or VBS listening shall ignore this message.

See table 9.21a/3GPP TS 04.08.

Message type: NOTIFICATION/FACCH

Significance: dual

Direction: network to mobile station

#### Table 9.21a/3GPP TS 04.08: NOTIFICATION/FACCH message content

<notification facch=""> ::= <rr :="" bit="" pd="" short=""></rr></notification>	See 3GPP TS 04.07	
<message :="" bit(5)="" type=""></message>	See 10.4	
<short 2="" :="" bit(2)="" header="" layer=""></short>	See 3GPP TS 04.06	
{0 <group call="" information=""></group>		
1 <paging information="">}</paging>		

<spare padding="">;</spare>	
<group call="" information=""> ::= <group :="" bit(36)="" call="" reference=""></group></group>	
{0 1 <group channel="" description="">};</group>	

<Group Call Reference>

This field is syntactically and semantically equivalent to octets 2-5 and bits 5 to 8 of octet 6 of the *Descriptive Group or Broadcast Call Reference* information element.

The <Group Channel Description> field is optionally present. When present only the Channel description is provided in the case of non hopping channels. In the case where the channel is hopping then either a mobile allocation or a frequency short list is provided.

<bit string> ::= null | bit <bit string> ;

<Channel Description>

This field is syntactically and semantically equivalent to octets 2-4 of the *Channel Description* information element. See sub-clause 10.5.2.5

#### <Frequency Short List>

This field is syntactically and semantically equivalent to octets 1-8 of the *Frequency Short List 2* information element. See sub-clause 10.5.2.14a

<Mobile Allocation>

This field is syntactically and semantically equivalent to octet 2 to n+2 of the *Mobile Allocation* information element. See sub-clause 10.5.2.21

The <Paging Information> field may be used to inform the mobile station in Group Receive or in Group Transmit mode that the corresponding mobile identity is paged in that cell.

<Paging Information> ::= <mobile identity : <bit string>> <channel first: bit(2)> {0|1 <eMLPP priority : bit(3)>}; <bit string> ::= null | bit <bit string> ;

<mobile identity>

This field is syntactically and semantically equivalent to octet 2-n of the *Mobile Identity* information element. See subclause 10.5.1.4.

<channel first>

This field is syntactically and semantically equivalent to bits 1 and 2 of the *Channel Needed* information element. See sub-clause 10.5.2.8.

#### <eMLPP priority>

This field is coded as the <Priority1> field in the P1 Rest Octets information element. See sub-clause 10.5.2.23

9.1.21a.1 Spare

- 9.1.21a.2 Spare
- 9.1.21a.3 Spare
- 9.1.21a.4 Spare

## 9.1.21b Notification/NCH

The understanding of this message is only required for mobile stations supporting VGCS listening or VBS listening.

This message is sent on the NCH by the network to notify mobile stations of VBS or VGCS calls in the current cell. The VBS or VGCS calls are identified by their broadcast call reference or group call reference, respectively. For each reference, the corresponding VBS or VGCS call channel may be indicated. See table 9.21b/3GPP TS 04.08.

Notification/NCH messages for VBS or VGCS calls are differentiated by a flag in the call reference.

The L2 pseudo length of this message has a value one

Mobile stations not supporting VGCS listening or VBS listening shall ignore this message.

Message type: NOTIFICATION/NCH

Significance: dual

Direction: network to mobile station

#### Table 9.21b/3GPP TS 04.08: NOTIFICATION/NCH message content

IEI	Information element	Type / Reference	Presence	Format	length
	L2 Pseudo Length	L2 Pseudo Length	M	V	1
		10.5.2.19			
	RR management	Protocol Discriminator	M	V	1/2
	Protocol Discriminator	10.2			
	Skip Indicator	Skip Indicator	M	V	1/2
		10.3.1			
	Notification/NCH	Message Type	M	V	1
	Message Type	10.4			
	NT/N Rest Octets	NT/N Rest Octets	M	V	1-20
		10.5.2.22c			

#### 9.1.21b.1 Spare

#### 9.1.21b.2 Spare

# 9.1.21d Notification response

This message is sent by the mobile station to the network to respond on a notification for a voice group call or voice broadcast call. See table 9.21d/3GPP TS 04.08.

Message type: NOTIFICATION RESPONSE

Significance: dual

IEI	Information element	Type / Reference	Presence	Format	Length
	RR management Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Notification response Message type	Message type 10.4	М	V	1
	Mobile station Classmark	Mobile station classmark 2 10.5.1.6	M	LV	4
	Mobile identity	Mobile identity 10.5.1.4	М	LV	2-9
	Group or broadcast Call reference	Call reference 10.5.1.9	М	V	5

Table 9.21d/3GPP TS 04.08: NOTIFICATION RESPONSE message content

# 9.1.21e RR-Cell Change Order

This message is sent on the main DCCH by the network to the mobile station to order it to reselect a cell. See table 9.21e/3GPP TS 04.08.

A mobile station that does not support the <<GRPS>> option shall regard this message as an unknown message.

Message type: RR-CELL CHANGE ORDER

Significance: dual

Direction: network to mobile station

IEI	Information element	Type / Reference	Presence	Format	length
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	RR-Cell Change Order Message Type	Message Type	М	V	1
	Cell Description	Cell description 10.5.2.2	М	V	2
	NC mode for target cell	NC mode 10.5.2.21c	М	V	1/2
	Spare half octet	Spare half octet 10.5.1.8	М	V	1/2

### Table 9.21e/3GPP TS 04.08: RR-CELL CHANGE ORDER message content

# 9.1.22 Paging request type 1

This message is sent on the CCCH by the network to up to two mobile stations. It may be sent to a mobile station in idle mode to trigger channel access. It may be sent to a mobile station in packet idle mode to transfer MM information (i.e. trigger of cell update procedure). The mobile stations are identified by their TMSI/P-TMSI or IMSI. See table 9.22/3GPP TS 04.08.

The L2 pseudo length of this message is the sum of lengths of all information elements present in the message except the *P1 Rest Octets* and *L2 Pseudo Length* information elements.

Message type: PAGING REQUEST TYPE 1 Significance: dual

Direction: network to mobile station

IEI	Information element	Type / Reference	Presence	Format	length
	L2 Pseudo Length	L2 Pseudo Length 10.5.2.19	М	V	1
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Paging Request Type 1 Message Type	Message Type 10.4	М	V	1
	Page Mode	Page Mode 10.5.2.26	М	V	1/2
	Channels Needed for Mobiles 1 and 2	Channel Needed 10.5.2.8	М	V	1/2
	Mobile Identity 1	Mobile Identity 10.5.1.4	М	LV	2-9
17	Mobile Identity 2	Mobile Identity 10.5.1.4	0	TLV	3-10
	P1 Rest Octets	P1 Rest Octets 10.5.2.23	М	V	0-17

Table 9.22/3GPP TS 04.08: PAGING REQUEST TYPE 1 message content

## 9.1.22.1 Unnecessary IE

A mobile station in idle mode shall consider all information elements as unnecessary IEs except for the Page Mode IE.

## 9.1.22.2 Channels needed for Mobiles 1 and 2

The first CHANNEL field of *Channel Needed* IE is associated with *Mobile Identity 1*. The second CHANNEL field of *Channel Needed* IE is associated with *Mobile Identity 2*.

If this message is used in the packet paging procedure, the *Channel Needed* IE associated with the corresponding *Mobile Identity 1 or 2* shall be coded with the value 00 (any channel) by the network. The mobile station receiving a packet paging request shall treat this information element as unnecessary in the message.

### 9.1.22.3 Mobile Identities

The Mobile Identity 1 and 2 IEs shall not refer to IMEI.

## 9.1.22.4 P1 Rest Octets

The sum of the length of this IE and the L2 Pseudo Length of the message equals 22.

This IE may contain a *notification list number* field and/or, referring to each one of the *Mobile Identity 1 and 2* IEs, a *Priority 1 and 2* field and/or a *Packet Page Indication 1 and 2* field.

# 9.1.23 Paging request type 2

This message is sent on the CCCH by the network to two or three mobile stations. It may be sent to a mobile station in idle mode to trigger channel access. It may be sent to a mobile station in packet idle mode to transfer MM information (i.e. trigger of cell update procedure). Two of the mobile stations are identified by their TMSI/P-TMSI while the third is identified by its TMSI/P-TMSI or IMSI. See table 9.23/3GPP TS 04.08.

The L2 pseudo length of this message is the sum of lengths of all information elements present in the message except the *P2 Rest Octets* and *L2 Pseudo Length* information elements.

Message type:	PAGING REQUEST TYPE 2
Significance:	dual
Direction:	network to mobile station

IEI	Information element	Type / Reference	Presence	Format	length
	L2 Pseudo Length	L2 Pseudo Length 10.5.2.19	М	V	1
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Paging Request Type 2 Message Type	Message Type 10.4	М	V	1
	Page Mode	Page Mode 10.5.2.26	М	V	1/2
	Channels Needed for Mobiles 1 and 2	Channel Needed 10.5.2.8	М	V	1/2
	Mobile Identity 1	TMSI/P-TMSI 10.5.2.42	М	V	4
	Mobile Identity 2	TMSI/P-TMSI 10.5.2.42	М	V	4
17	Mobile Identity 3	Mobile Identity 10.5.1.4	0	TLV	3-10
	P2 Rest Octets	P2 Rest Octets 10.5.2.24	М	V	1-11

#### Table 9.23/3GPP TS 04.08: PAGING REQUEST TYPE 2 message content

## 9.1.23.1 Channels needed for Mobiles 1 and 2

The first CHANNEL field of Channel Needed IE is associated with Mobile Identity 1. The second CHANNEL field of *Channel Needed* IE is associated with *Mobile Identity* 2.

If this message is used in the packet paging procedure, the *Channel Needed* IE associated with the corresponding *Mobile Identity 1 or 2* shall be coded with the value 00 (any channel) by the network. The mobile station receiving a packet paging request shall treat this information element as unnecessary in the message.

### 9.1.23.2 Mobile Identity 3

The Mobile Identity 3 information element shall not refer to IMEI.

### 9.1.23.3 P2 Rest Octets

The sum of the length of this IE and the L2 Pseudo Length of the message equals 22.

This IE contains the channel needed indication related to the paging of *Mobile Identity 3*. The treatment of this indication in the case this message is used in a packet paging procedure is specified in sub-clause 9.1.23.1.

This IE may further contain a *notification list number* field and/or, referring to each one of the *Mobile Identity 1, 2 and 3* IEs, a *Priority 1, 2 and 3* field and/or, referring to the *Mobile Identity 3* IE, a *Packet Page Indication 3* field.

# 9.1.24 Paging request type 3

This message is sent on the CCCH by the network to four mobile stations. It may be sent to a mobile station in idle mode to trigger channel access. It may be sent to a mobile station in packet idle mode to transfer MM information (i.e. trigger of cell update procedure). The mobile stations are identified by their TMSIs/P-TMSIs. See table 9.24/3GPP TS 04.08.

This message has a L2 Pseudo Length of 19.

Message type:	PAGING REQUEST TYPE 3
Significance:	dual
Direction:	network to mobile station

IEI	Information element	Type / Reference	Presence	Format	length
	L2 Pseudo Length	L2 Pseudo Length 10.5.2.19	М	V	1
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Paging Request Type 3 Message Type	Message Type 10.4	М	V	1
	Page Mode	Page Mode 10.5.2.26	М	V	1/2
	Channels Needed for Mobiles 1 and 2	Channel Needed 10.5.2.8	М	V	1/2
	Mobile Identity 1	TMSI/P-TMSI 10.5.2.42	М	V	4
	Mobile Identity 2	TMSI/P-TMSI 10.5.2.42	М	V	4
	Mobile Identity 3	TMSI/P-TMSI 10.5.2.42	М	V	4
	Mobile Identity 4	TMSI/P-TMSI 10.5.2.42	М	V	4
	P3 Rest Octets	P3 Rest Octets 10.5.2.25	М	V	3

Table 9.24/3GPP TS 04.08: PAGING REQUEST TYPE 3 message content

#### 9.1.24.1 Channels needed for Mobiles 1 and 2

The first CHANNEL field of *Channel Needed* IE is associated with *Mobile Identity 1*. The second CHANNEL field of *Channel Needed* IE is associated with *Mobile Identity 2*.

If this message is used in the packet paging procedure, the *Channel Needed* IE associated with the corresponding *Mobile Identity 1 or 2* shall be coded with the value 00 (any channel) by the network. The mobile station receiving a packet paging request shall treat this information element as unnecessary in the message.

### 9.1.24.2 P3 Rest Octets

This IE contains the channel needed indication related to the paging of *Mobile Identity 3 and 4*. The treatment of these indications in the case this message is used in a packet paging procedure is specified in sub-clause 9.1.24.1.

This IE may further contain a *notification list number* field and/or, referring to each one of the *Mobile Identity 1, 2, 3* and 4 IEs, a *Priority 1, 2, 3 and 4* field.

## 9.1.25 Paging response

This message is sent on the main DCCH by the mobile station to the network in connection with establishment of the main signalling link as a response to the paging request message. See table 9.25/3GPP TS 04.08.

Message type: PAGING RESPONSE

Significance: dual

IEI	Information element	Type / Reference	Presence	Format	length
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Paging Response Message Type	Message Type 10.4	М	V	1
	Ciphering Key Sequence Number	Ciphering Key Sequence Number 10.5.1.2	М	V	1/2
	Spare Half Octet	Spare Half Octet 10.5.1.8	М	V	1/2
	Mobile Station Classmark	Mobile Station Classmark 2 10.5.1.6	M	LV	4
	Mobile Identity	Mobile Identity 10.5.1.4	М	LV	2-9

Table 9.25/3GPP TS 04.08: PAGING RESPONSE message content

## 9.1.25.1 Mobile Station Classmark

This IE shall include for multiband mobile station the Classmark 2 corresponding to the frequency band in use.

# 9.1.26 Partial release

This message is sent on the main DCCH by the network to the mobile station to deactivate part of the dedicated channels in use. See table 9.26/3GPP TS 04.08.

Message type: PARTIAL RELEASE Significance: dual

Direction: network to mobile station

#### Table 9.26/3GPP TS 04.08: PARTIAL RELEASE message content

IEI	Information element	Type / Reference	Presence	Format	length
	RR management	Protocol Discriminator	М	V	1/2
	Protocol Discriminator	10.2			
	Skip Indicator	Skip Indicator	М	V	1/2
	-	10.3.1			
	Partial Release	Message Type	М	V	1
	Message Type	10.4			
	Channel Description	Channel Description	М	V	3
		10.5.2.5			

#### 9.1.26.1 Channel Description

This information element describes the channel to be released.

# 9.1.27 Partial release complete

This message is sent on the main DCCH by the mobile station to the network to indicate that a part of the dedicated channels has been deactivated. See table 9.27/3GPP TS 04.08.

Message type: PARTIAL RELEASE COMPLETE Significance: dual

IEI	Information element	Type / Reference	Presence	Format	length
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Partial release Complete Message Type	Message Type 10.4	М	V	1

Table 9.27/3GPP TS 04.08: PARTIAL RELEASE COMPLETE message content

# 9.1.28 Physical information

This message is sent on the main DCCH by the network to the mobile station to stop the sending of access bursts from the mobile station. See table 9.28/3GPP TS 04.08.

Message type: PHYSICAL INFORMATION

Significance: dual

Direction: network to mobile station

#### Table 9.28/3GPP TS 04.08: PHYSICAL INFORMATION message content

IEI	Information element	Type / Reference	Presence	Format	length
	RR management	Protocol Discriminator	М	V	1/2
	Protocol Discriminator	10.2			
	Skip Indicator	Skip Indicator	М	V	1/2
		10.3.1			
	Physical Information	Message Type	M	V	1
	Message Type	10.4			
	Timing Advance	Timing Advance	М	V	1
	-	10.5.2.40			

# 9.1.28.a RR Initialisation Request

This message is sent on the main DCCH by the mobile station to request establishment of dedicated mode.

Message type: RR Initialisation Request

Significance: local

IEI	Information element	Type / Reference	Presence	Format	length
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	RR Initialisation Request Message Type	Message Type 10.4	М	V	1
	Ciphering Key Sequence Number	Ciphering Key sequence Number 10.5.1.2	M	V	1/2
	MAC Mode and Channel Coding Requested	Channel Coding Requested 10.5.2.4a	М	V	1/2
	Mobile station classmark	Mobile station classmark 2 10.5.1.6	М	LV	4
	TLLI	TLLI 10.5.2.41a	М	V	4
	Channel Request Description	Channel Request Description 10.5.2.8a	М	V	5
	GPRS Measurement Results	GPRS Measurement Results 10.5.2.20a	М	V	2

Table 9.28a/3GPP TS 04.08: RR Initialisation Request message content

# 9.1.29 RR Status

This message is sent by the mobile station or the network at any time to report certain error conditions as described in clause 8. See table 9.28a/3GPP TS 04.08.

Message type:	RR STATUS		
Significance:	local		
Direction:	both		

#### Table 9.28a/3GPP TS 04.08: RR STATUS message content

IEI	Information element	Type / Reference	Presence	Format	length
	RR management	Protocol Discriminator	М	V	1/2
	Protocol Discriminator	10.2			
	Skip Indicator	Skip Indicator	М	V	1/2
		10.3.1			
	RR Status	Message Type	М	V	1
	Message Type	10.4			
	RR Cause	RR Cause	М	V	1
		10.5.2.31			

# 9.1.30 Synchronization channel information

This message is sent on the SCH, which is one of the broadcast channels (ref. 3GPP TS 05.02 sub-clause 3.3.2). Its purpose is to support the synchronization of a mobile station to a BSS. It does not follow the basic format. Its length is 25 bits. The order of bit transmission is defined in 3GPP TS 04.04. See figure 9.3/3GPP TS 04.08 and table 9.29/3GPP TS 04.08.

Message type: SYNCHRONIZATION CHANNEL INFORMATION

Significance: dual

Direction: network to mobile station




Figure 9.3/3GPP TS 04.08: Frame synchronization information element

Table 9.29/3GPP TS 04.08: Synchronization channel information message contents

```
BSIC, the base station identity code of the base
station
T1, T2 and T3', the 3 parts of the reduced TDMA frame
number (RFN) as specified in TS. GSMß05.02 sub-clause
3.3.2.
```

# 9.1.31 System information Type 1

This message is sent on the BCCH by the network to all mobile stations within the cell giving information of control of the RACH and of the cell allocation. See table 9.30/3GPP TS 04.08. Special requirements for the transmission of this message apply, see 3GPP TS 05.02. This message has a L2 Pseudo Length of 21.

Message type: SYSTEM INFORMATION TYPE 1

Significance: dual

Direction: network to mobile station

IEI	Information element	Type / Reference	Presence	Format	length
	L2 pseudo length	L2 pseudo length 10.5.2.19	M	V	1
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	System Information Type 1 Message Type	Message Type 10.4	М	V	1
	Cell Channel Description	Cell Channel Description 10.5.2.1b	M	V	16
	RACH Control Parameter	RACH Control Parameters 10.5.2.29	М	V	3
	SI 1 Rest Octets	SI 1 Rest Octets 10.5.2.32	M	V	1

#### Table 9.30/3GPP TS 04.08: SYSTEM INFORMATION TYPE 1 message content

## 9.1.32 System information type 2

This message is sent on the BCCH by the network to all mobile stations within the cell giving information of control of the RACH and of the BCCH allocation in the neighbour cells. See table 9.31/3GPP TS 04.08. Special requirements for the transmission of this message apply, see 3GPP TS 05.02. This message has a L2 Pseudo Length of 22.

Message type: SYSTEM INFORMATION TYPE 2

V

V

V

V

V

1/2

1

16

1

3

Μ

Μ

Μ

Μ

Μ

Significance: dual

Skip Indicator

NCC Permitted

System Information

Type 2 Message Type

**BCCH Frequency List** 

**RACH** Control Parameter

Direction: network to mobile station

IEI	Information element	Type / Reference	Presence	Format	length
	L2 Pseudo Length	L2 Pseudo Length 10.5.2.19	М	V	1
	RR management	Protocol Discriminator	М	V	1/2
	Protocol Discriminator	10.2			

Neighbour Cell Description

**RACH Control Parameters** 

Skip Indicator

Message Type

NCC permitted

10.3.1

10.4

10.5.2.22

10.5.2.27

10.5.2.29

#### Table 9.31/3GPP TS 04.08: SYSTEM INFORMATION TYPE 2 message content

# 9.1.33 System information type 2bis

This message is sent optionally on the BCCH by the network to all mobile stations within the cell giving information on control of the RACH and of the extension of the BCCH allocation in the neighbour cells. See

table 9.31a/3GPP TS 04.08. Special requirements for the transmission of this message apply, see 3GPP TS 05.02.

A GSM 900 mobile station which only supports the primary GSM band P-GSM 900 (cf. 3GPP TS 05.05) may ignore this message, see sub-clause 3.2.2.1.

This message has a L2 pseudo length of 21.

Message type: SYSTEM INFORMATION TYPE 2bis

Significance: dual

Direction: network to mobile station

#### Table 9.31a/3GPP TS 04.08: SYSTEM INFORMATION TYPE 2bis message content

IEI	Information element	Type / Reference	Presence	Format	length
	L2 Pseudo Length	L2 Pseudo Length 10.5.2.19	М	V	1
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	System Information Type 2bis Message Type	Message Type 10.4	М	V	1
	Extended BCCH Frequency List	Neighbour Cell Description 10.5.2.22	М	V	16
	RACH Control Parameters	RACH Control Parameters 10.5.2.29	М	V	3
	SI 2bis Rest Octets	SI 2bis Rest Octets 10.5.2.33	М	V	1

# 9.1.34 System information type 2ter

This message is sent optionally on the BCCH by the network to all mobile stations within the cell giving information on the extension of the BCCH allocation in the neighbour cells. See table 9.31b/3GPP TS 04.08. Special requirements for the transmission of this message apply, see 3GPP TS 05.02.

A mobile station that supports either:

- only the primary GSM band P-GSM 900 (cf. 3GPP TS 05.05); or
- only the DCS 1800 band (cf. 3GPP TS 05.05);
- may ignore this message, see sub-clause 3.2.2.1.

This message has a L2 pseudo length of 18. This message may be sent by the network with either a L2 pseudo length of 18 or some other value. A mobile station that does not ignore this message shall not discard the message due to a received L2 pseudo length different from 18.

Message type: SYSTEM INFORMATION TYPE 2ter

Significance: dual

Direction: network to mobile station

#### Table 9.31b/3GPP TS 04.08: SYSTEM INFORMATION TYPE 2ter message content

IEI	Information element	Type / Reference	Presence	Format	length
	L2 Pseudo Length	L2 Pseudo Length 10.5.2.19	М	V	1
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	System Information Type 2ter Message Type	Message Type 10.4	М	V	1
	Extended BCCH Frequency List	Neighbour Cell Description 2 10.5.2.22a	M	V	16
	SI 2ter Rest Octets	SI 2ter Rest Octets 10.5.2.33a	М	V	4

# 9.1.35 System information type 3

This message is sent on the BCCH by the network giving information of control on the RACH, the location area identification, the cell identity and various other information about the cell. See table 9.32/3GPP TS 04.08. Special requirements for the transmission of this message apply, see 3GPP TS 05.02. This message has a L2 Pseudo Length of 18.

Message type: SYSTEM INFORMATION TYPE 3

Significance: dual

Direction: network to mobile station

IEI	Information element	Type / Reference	Presence	Format	length
	L2 Pseudo Length	L2 Pseudo Length 10.5.2.19	М	V	1
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	System Information Type 3 Message Type	Message Type 10.4	М	V	1
	Cell Identity	Cell Identity 10.5.1.1	М	V	2
	Location Area Identification	Location Area Identification 10.5.1.3	М	V	5
	Control Channel Description	Control Channel description 10.5.2.11	М	V	3
	Cell Options	Cell Options (BCCH) 10.5.2.3	М	V	1
	Cell Selection Parameters	Cell Selection Parameters 10.5.2.4	М	V	2
	RACH Control Parameters	RACH Control Parameters 10.5.2.29	М	V	3
	SI 3 Rest Octets	SI 3 Rest Octets 10.5.2.34	М	V	4

Table 9.32/3GPP TS 04.08: SYSTEM INFORMATION TYPE 3 message content

# 9.1.36 System information type 4

This message is sent on the BCCH by the network giving information on control of the RACH, the location area identification, the cell identity and various other information about the cell. See table 9.33/3GPP TS 04.08. Special requirements for the transmission of this message apply, see 3GPP TS 05.02. The L2 pseudo length of this message is the sum of lengths of all information elements present in the message except the *SI 4 Rest Octets* and *L2 Pseudo Length* information elements.

Message type: SYSTEM INFORMATION TYPE 4

Significance: dual

Direction: network to mobile station

IEI	Information element	Type / Reference	Presence	Format	length
	L2 Pseudo Length	L2 Pseudo Length 10.5.2.19	М	V	1
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	System Information Type 4 Message Type	Message Type 10.4	М	V	1
	Location Area Identification	Location Area Identification 10.5.1.3	М	V	5
	Cell Selection Parameters	Cell Selection Parameters 10.5.2.4	М	V	2
	RACH Control Parameters	RACH Control Parameters 10.5.2.29	М	V	3
64	CBCH Channel Description	Channel description 10.5.2.5	0	ΤV	4
72	CBCH Mobile Allocation	Mobile Allocation 10.5.2.21	С	TLV	3-6
	SI 4 Rest Octets	SI 4 Rest Octets 10.5.2.35	М	V	0-10

Table 9.33/3GPP TS 04.08: SYSTEM INFORMATION TYPE 4 message content

### 9.1.36.1 CBCH Channel description

This information element is present if SMSCB is active in the cell and indicates (together with the *CBCH Mobile Allocation* IE) where to find the CBCH.

### 9.1.36.2 CBCH Mobile Allocation

If the *CBCH Channel Description* Information Element indicates frequency hopping, the *CBCH Mobile Allocation* IE shall be present. If the *CBCH Channel Description* does not indicate frequency hopping, the *CBCH Mobile Allocation* IE shall be considered as an unnecessary IE in the message.

# 9.1.36.3 SI 4 Rest Octets

The sum of the length of this IE and the L2 pseudo length of the message equals 22.

# 9.1.37 System information type 5

This message is sent on the SACCH by the network to mobile stations within the cell giving information on the BCCH allocation in the neighbour cells. See table 9.34/3GPP TS 04.08.

When received this information shall be used as the list of BCCH frequencies of the neighbouring cells to be reported on. Any change in the neighbour cells description must overwrite any old data held by the mobile station. The mobile station must analyse all correctly received system information type 5 messages. This message has a L2 Pseudo Length of 18.

Message type:SYSTEM INFORMATION TYPE 5Significance:dualDirection:network to mobile station

IEI	Information element	Type / Reference	Presence	Format	length
	L2 pseudo length	L2 pseudo length 10.5.2.19	M	V	1
	RR management Protocol Discriminator	Protocol Discriminator 10.2	M	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	M	V	1/2
	System Information Type 5 Message Type	Message Type 10.4	M	V	1
	BCCH Frequency List	Neighbour Cell Description 10.5.2.22	М	V	16

Table 9.34/3GPP TS 04.08: SYSTEM INFORMATION TYPE 5 message content

# 9.1.38 System information type 5bis

This message is sent optionally on the SACCH by the network to mobile stations within the cell giving information on the extension of the BCCH allocation in the neighbour cells. See table 9.34a/3GPP TS 04.08.

A GSM 900 mobile station which only supports the primary GSM band P-GSM 900 (cf. 3GPP TS 05.05) may ignore this message, see sub-clause 3.2.2.1.

When received (and not ignored) this information must be used as the list of neighbouring cells to be reported on. Any change in the neighbour cells description must overwrite any old data held by the mobile station. The mobile station must, with the exception stated above, analyse all correctly received system information type 5 messages. This message has a L2 Pseudo Length of 18.

Message type: SYSTEM INFORMATION TYPE 5bis

Significance: dual

Direction: network to mobile station

IEI	Information element	Type / Reference	Presence	Format	length
	L2 pseudo length	L2 pseudo length 10.5.2.19	М	V	1
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	System Information Type 5 bis Message Type	Message Type 10.4	М	V	1
	Extension of the BCCH Frequency List Description	Neighbour Cell Description 10.5.2.22	M	V	16

# 9.1.39 System information type 5ter

This message is sent optionally on the SACCH by the network to mobile stations within the cell giving information on the extension of the BCCH allocation in the neighbour cells. See table 9.34b/3GPP TS 04.08.

A mobile station that supports either:

- only the primary GSM band P-GSM 900 (cf. 3GPP TS 05.05); or
- only the DCS 1800 band (cf. 3GPP TS 05.05);
- may ignore this message, see sub-clause 3.2.2.1.

When received (and not ignored) this information must be used as part of the list of neighbouring cells to be reported on. Any change in the neighbour cells description must overwrite this part of any old data held by the mobile station. The mobile station shall, with the exception stated above, analyse all correctly received system information type 5ter messages. This message has a L2 Pseudo Length of 18.

Message type: SYSTEM INFORMATION TYPE 5ter

Significance: dual

Direction: network to mobile station

#### Table 9.34b/3GPP TS 04.08: SYSTEM INFORMATION TYPE 5ter message content

IEI	Information element	Type / Reference	Presence	Format	length
	L2 pseudo length	L2 pseudo length 10.5.2.19	М	V	1
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	System Information Type 5ter Message Type	Message Type 10.4	М	V	1
	Extended BCCH Frequency List	Neighbour Cell Description 2 10.5.2.22a	М	V	16

# 9.1.40 System information type 6

This message is sent on the SACCH by the network to mobile stations within the cell giving information of location area identification, of cell identity and various other information. See table 9.35/3GPP TS 04.08. If received correctly by the mobile station this message is treated as in Sub-clauses 9.1.40.1 to 9.1.40.4.

This message has a L2 Pseudo Length of 11.

Message type: SYSTEM INFORMATION TYPE 6

Significance: dual

Direction: network to mobile station

#### Table 9.35/3GPP TS 04.08: SYSTEM INFORMATION TYPE 6 message content

IEI	Information element	Type / Reference	Presence	Format	length
	L2 pseudo length	L2 pseudo length 10.5.2.19	М	V	1
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	System Information Type 6 Message Type	Message Type 10.4	М	V	1
	Cell Identity	Cell Identity 10.5.1.1	М	V	2
	Location Area Identification	Location Area Identification 10.5.1.3	М	V	5
	Cell Options	Cell Options (SACCH) 10.5.2.3	М	V	1
	NCC Permitted	NCC Permitted 10.5.2.27	М	V	1
	SI 6 Rest Octets	SI6 Rest Octets 10.5.2.35a	М	V	7

# 9.1.40.1 Cell Identity

Only applicable for mobile stations supporting SIM Application Toolkit class 2 or higher:

- if a new Cell Identity is identified, an indication shall be given to the upper layer together with the new identity.

Other mobile stations may ignore this IE.

# 9.1.40.2 Location Area Identification

Only applicable for mobile stations supporting VGCS listening and VBS listening or SIM Application Toolkit class 2 or higher:

- if a new Location Area Identification is identified, an indication shall be given to the upper layer together with the new identification.

Other mobile stations may ignore this IE.

# 9.1.40.3 Cell Options

When correctly received, this information shall be used as the current Cell Options information. Any change in the Cell Options shall overwrite any old Cell Options data held by the mobile station.

# 9.1.40.4 NCC permitted

As for BCCH Frequency List in SYSTEM INFORMATION TYPE 5.

# 9.1.41 System information type 7

This message is sent on the BCCH by the network giving information about cell reselection parameters to be used in that cell. See table 9.36/3GPP TS 04.08. Special requirements for the transmission of this message apply, see 3GPP TS 05.02. The L2 pseudo length of this message has the value 1.

Message type: SYSTEM INFORMATION TYPE 7

Significance: dual

Direction: network to mobile station

IEI	Information element	Type / Reference	Presence	Format	length
	L2 pseudo length	L2 pseudo length 10.5.2.19	М	V	1
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	System Information Type 7 Message Type	Message Type 10.4	М	V	1
	SI 7 Rest Octets	SI 7 Rest Octets 10.5.2.36	М	V	20

### Table 9.36/3GPP TS 04.08: SYSTEM INFORMATION TYPE 7 message content

# 9.1.42 System information type 8

This message is sent on the BCCH by the network giving information about cell reselection parameters to be used in that cell. See table 9.37/3GPP TS 04.08. Special requirements for the transmission of this message apply, see 3GPP TS 05.02. The L2 Pseudo Length of this message has the value 1.

Message type: SYSTEM INFORMATION TYPE 8

Significance: dual

Direction: network to mobile station

#### Table 9.37/3GPP TS 04.08: SYSTEM INFORMATION TYPE 8 message content

IEI	Information element	Type / Reference	Presence	Format	length
	L2 Pseudo Length	L2 Pseudo Length 10.5.2.19	М	V	1
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	System Information Type 8 Message Type	Message Type 10.4	М	V	1
	SI 8 Rest Octets	SI 8 Rest Octets 10.5.2.37	М	V	20

# 9.1.43 System information Type 9

This message is sent on the BCCH by the network to all mobile stations within the cell giving some, but not necessarily all information on the scheduling of information on the BCCH. See table 9.37a/3GPP TS 04.08. Special requirements for the transmission of this message apply, see sub-clause 3.2.2.1 and 3GPP TS 05.02. This message has a L2 Pseudo Length of 1.

Message type: SYSTEM INFORMATION TYPE 9

Significance: dual

Direction: network to mobile station

IEI	Information element	Type / Reference	Presence	Format	length
	L2 pseudo length	L2 pseudo length 10.5.2.19	М	V	1
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	System Information Type 9 Message Type	Message Type 10.4	М	V	1
	RACH Control Parameter	RACH Control Parameters 10.5.2.29	М	V	3
SI 9 Rest Octets		SI 9 Rest Octets 10.5.2.37a	М	V	17

#### Table 9.37a/3GPP TS 04.08: SYSTEM INFORMATION TYPE 9 message content

# 9.1.43a System information Type 13

This message is sent on the BCCH if indicated in at least one of the SYSTEM INFORMATION TYPE 3, 4, 7 or 8 messages. The message is sent by the network to provide information related to GPRS in the cell. See table 9.37b/GSM04.08. Special requirements for the transmission of this message apply, see 3GPP TS 05.02.

A mobile station not supporting GPRS shall treat this message as an unknown message type.

The L2 Pseudo Length of this message has the value 0.

Message type:	SYSTEM INFORMATION TYPE 13
Significance:	dual
Direction:	network to mobile station

IEI	Information element	Type / Reference	Presence	Format	length
	L2 Pseudo Length	L2 Pseudo Length 10.5.2.19	М	V	1
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	System Information Type 13 Message Type	Message Type 10.4	М	V	1
	SI 13 Rest Octets	SI 13 Rest Octets 10.5.2.37b	М	V	20

Table 9.37b/3GPP TS 04.08: SYSTEM INFORMATION TYPE 13 message content

# 9.1.43b [Spare]

### 9.1.43c [Spare]

# 9.1.43d System information type 16

This message is sent on the BCCH if indicated in the SYSTEM INFORMATION TYPE 3 message. The message is sent by the network giving information about cell selection and reselection parameters to be used in that cell. See table 9.37e/3GPP TS 04.08. Special requirements for the transmission of this message applies, see 3GPP TS 05.02.

The L2 pseudo length of this message has the value 1.

Message type: SYSTEM INFORMATION TYPE 16

Significance: dual

Direction: network to mobile station

Table 9.37e/3GPP TS 04.08: SYSTEM INFORMATION TYPE 16 message content

IEI	Information element	Type / Reference	Presence	Format	length
	L2 pseudo length	L2 pseudo length 10.5.2.19	М	V	1
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	System Information Type 16 Message Type	Message Type 10.4	М	V	1
	SI 16 Rest Octets	SI 16 Rest Octets 10.5.2.37e	М	V	20

# 9.1.43e System information type 17

This message is sent on the BCCH if indicated in the SYSTEM INFORMATION TYPE 3 message. The message is sent by the network giving information about cell selection and reselection parameters to be used in that cell. See table 9.37f/3GPP TS 04.08. Special requirements for the transmission of this message applies, see 3GPP TS 05.02.

The L2 pseudo length of this message has the value 1.

Message type:	SYSTEM INFORMATION TYPE 17
Significance:	dual
Direction:	network to mobile station

IEI	Information element	Type / Reference	Presence	Format	length
	L2 Pseudo Length	L2 Pseudo Length	М	V	1
		10.5.2.19			
	RR management	Protocol Discriminator	М	V	1/2
	Protocol Discriminator	10.2			
	Skip Indicator	Skip Indicator	M	V	1/2
		10.3.1			
	System Information	Message Type	М	V	1
	Type 17 Message Type	10.4			
	SI 17 Rest Octets	SI 17 Rest Octets	М	V	20
		10.5.2.37f			

Table 9.37f/3GPP TS 04.08: SYSTEM INFORMATION TYPE 17 message content

# 9.1.44 Talker indication

This message is sent on the main DCCH by the mobile station to the network to give the talker information when a new layer 2 connection is established on a VGCS channel after an uplink access. See table 9.44/3GPP TS 04.08.

Message type: TALKER INDICATION

Significance: dual

Direction: mobile station to network

#### Table 9.44/3GPP TS 04.08: TALKER INDICATION message content

IEI	Information element	ent Type / Reference		Format	length
	RR management	Protocol Discriminator	M	V	1/2
	Protocol Discriminator	10.2			
	Skip Indicator	Skip Indicator	М	V	1/2
		10.3.1			
	Talker Indication	Message Type	M	V	1
Message Type		10.4			
Mobile Station		Mobile Station	М	LV	4
	Classmark	Classmark 2			
		10.5.1.6			
	Mobile Identity	Mobile Identity	M	LV	2-9
		10.5.1.4			

# 9.1.45 Uplink access

Only applicable for mobile stations supporting VGCS talking.

This message is sent in random mode on the voice group call channel uplink. It does not follow the basic format. The possible formats are presented directly below, without reference to information fields. The order of bit transmission is defined in 3GPP TS 04.04.

The message is only one octet long, coded as shown in figure 9.4/3GPP TS 04.08 and table 9.45/3GPP TS 04.08.

	8	7	б	5	4	3	2	1	
	ESTA	ABLISHM	IENT		RANDC	M REFI	ERENCE		octet1
+-		CAUSE							-

#### Figure 9.4/3GPP TS 04.08: UPLINK ACCESS message content

#### ESTABLISHMENT CAUSE (octet 1)

This information field indicates the reason for requesting the establishment of a connection. This field has a variable length (from 3 bits up to 8 bits).

RANDOM REFERENCE (octet 1)

This is an unformatted field with variable length (from 5 bits down to 0 bits).

The Channel Request message is coded as follows:

(Random Reference field is filled with "x").

#### Table 9.45/3GPP TS 04.08: UPLINK ACCESS message content

Message 81	Meaning of Establishment Cause
110xxxxx	Subsequent talker uplink request
00100101	Reply on uplink access request
other values	reserved for future use

# 9.1.46 Uplink busy

The understanding of this message is only required for mobile stations supporting VGCS talking.

This message is broadcasted on the voice group call channel on the main DCCH, SAPI=0, by the network in unacknowledged mode to inform the mobile station of the uplink status of the voice group call channel. See table 9.46/3GPP TS 04.08.

Message type: UPLINK BUSY Significance: dual Direction: network to mobile station

#### Table 9.46/3GPP TS 04.08: UPLINK BUSY message content

IEI	Information element	Type / Reference	Presence	Format	length
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
Skip Indicator		Skip Indicator 10.3.1	М	V	1/2
	Uplink busy Message Type	Message Type 10.4	М	V	1

# 9.1.47 Uplink free

This message is sent on the main DCCH, in unacknowledged mode using the RR short protocol discriminator by the network to inform the mobile station of the uplink status of the voice group call channel. See table 9.47/3GPP TS 04.08. The message indicates the uplink as free unless the Uplink Access Request field indicates the uplink as not free.

This message may also be used by the network to request the mobile station to perform an uplink reply procedure.

Message type:	UPLINK FREE
Significance:	dual
Direction:	network to mobile station

#### Table 9.47/3GPP TS 04.08: UPLINK FREE message content

<uplink free=""> ::=</uplink>	<rr :="" bit="" pd="" short=""></rr>	See 3GPP TS 04.07
	<message :="" bit(5)="" type=""></message>	See 10.4
	<short 2="" :="" bit(2)<="" header="" layer="" td=""><td>See 3GPP TS 04.06</td></short>	See 3GPP TS 04.06

<Uplink Access Request bit>

{L|H <Uplink Identity Code bit(6)>}

<implicit spare>;

Uplink Access Request :

- L Mobile station shall not perform the uplink reply procedure;
- H Mobile station shall perform the uplink reply procedure.

When set to H, this element also indicates the uplink as not free for the uplink access procedure

Uplink Identity Code :

This field is coded as the binary representation of the UIC.

If provided by the network, the Uplink Identity Code shall be used by the mobile for the coding of the UPLINK ACCESS message

# 9.1.48 Uplink release

Only applicable for mobile stations supporting VGCS talking.

This message is sent on the uplink of the voice group call channel to initiate a deactivation of the group transmit mode and to set the uplink free or on the downlink of the voice group call channel in order to reject an uplink access which was already granted by the network. See table 9.48/3GPP TS 04.08

Message type: UPLINK RELEASE Significance: local

Direction: both

#### Table 9.48/3GPP TS 04.08: UPLINK RELEASE message content

IEI	Information element	Type / Reference	Presence	Format	length
	RR management	Protocol Discriminator	М	V	1/2
	Protocol Discriminator	10.2			
	Skip Indicator	Skip Indicator	М	V	1/2
		10.3.1			
	Uplink Release	Message Type	М	V	1
	Message Type	10.4			
	RR Cause	RR Cause	М	V	1
		10.5.2.31			

# 9.1.49 VGCS uplink grant

The understanding of this message is only required for mobile stations supporting VGCS talking.

This message is sent in unacknowledged mode on the main signalling channel by the network to the mobile station to stop the sending of access bursts from the mobile station and to change the channel configuration to a dedicated configuration. See table 9.49/3GPP TS 04.08.

Message type: VGCS UPLINK GRANT Significance: dual Direction: network to mobile station

IEI	Information element	Type / Reference	Presence	Format	length
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	VGCS Uplink Grant Message Type	Message Type 10.4	М	V	1
	Request Reference	Request Reference 10.5.2.30	М	V	3
	Timing Advance	Timing Advance 10.5.2.40	М	V	1

#### Table 9.49/3GPP TS 04.08: VGCS UPLINK GRANT message content

# 9.1.50 System information type 10 \$(ASCI)\$

The understanding of messages of this message type is only required for mobile stations supporting VGCS listening and VBS listening. A mobile station not understanding the message shall treat it as unknown message.

Messages of this message type are optionally sent by the network in unacknowledged mode on the SACCH. SYSTEM INFORMATION TYPE 10 messages contain information about neighbour cells. When sent on the SACCH of a VGCS or VBS downlink, SYSTEM INFORMATION TYPE 10 messages address all mobile stations receiving that downlink within the cell. There may be different SYSTEM INFORMATION TYPE 10 messages sent on the same SACCH.

They are not standard layer 3 messages. They shall be transferred using the short header format for SACCH messages sent in unacknowledged mode specified in 3GPP TS 04.07.

Each SYSTEM INFORMATION TYPE 10 message defines a list of cells and may contain further information for cells of that list, a cell being identified by the pair of ARFCN and BSIC of the BCCH. Newer information about a cell received in SYSTEM INFORMATION TYPE 10 messages shall replace older information.

Message type: SYSTEM INFORMATION TYPE 10

Significance: dual

Direction: network to mobile station

<SYSTEM INFORMATION TYPE 10> ::=

<RR short PD : bit> -- See 3GPP TS 04.07 <message type : bit(5)> -- See 10.4 <short layer 2 header : bit(2)> -- See 3GPP TS 04.06 -- See 3GPP TS 04.06 -- See 10.5.2.44

# 9.1.51 EXTENDED MEASUREMENT ORDER

This message is sent on the SACCH by the network to the mobile station, to order the mobile station to send one extended measurement report. See table 9.1.51.1/3GPP TS 04.08.

A mobile station which does not support Extended Measurements shall discard this message.

This message has a L2 Pseudo Length of 18.

Message type: EXTENDED MEASUREMENT ORDER

Significance: dual

Direction: network to mobile station

IEI	Information element	Type / Reference	Presence	Format	length
	L2 pseudo length	L2 pseudo length 10.5.2.19	М	V	1
	RR management Protocol Discriminator	Protocol Discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Extended Measurement Order	Message Type 10.4	М	V	1
	Extended Measurement Frequency List	Extended Measurement Frequency List 10.5.2.46	M	V	16

Table 9.1.51.1/3GPP TS 04.08: EXTENDED MEASUREMENT ORDER message content

# 9.1.52 Extended measurement report

This message is sent on the SACCH by the mobile station to the network to report extended measurement results about the signal strength on specified carriers. See table 9.1.52.1/3GPP TS 04.08.

Message type: EXTENDED MEASUREMENT REPORT

Significance: dual

Direction: mobile station to network

#### Table 9.1.52.1/3GPP TS 04.08: EXTENDED MEASUREMENT REPORT message content

IEI	Information element	Type / Reference	Presence	Format	length
	RR management	Protocol Discriminator	М	V	1/2
	Protocol Discriminator	10.2			
	Skip Indicator	Skip Indicator	М	V	1/2
		10.3.1			
	Extended Measurement Report	Message Type	М	V	1
	Message Type	10.4			
	Extended Measurement	Extended Measurement	М	V	16
	Results	Results			
		10.5.2.45			

# 9.1.53 Application Information

This message is sent on the main DCCH by the network or the mobile station to convey an embedded Application Protocol Data Unit (APDU) or APDU segment between the network and the mobile station. See table 9.1.53.1/3GPP TS 04.08.

Message type:	Application
Significance:	global
Direction:	both

IEI	Information Element	Type/Reference	Presence	Format	Length
	RR management Protocol Discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Application Information message type	Message type 10.4	М	V	1
	APDU ID	APDU ID `0.5.2.48	М	V	1/2
	APDU Flags	APDU Flags 10.5.2.49	М	V	1/2
	APDU Data	APDU Data 10.5.2.50	М	LV	2 to N

Table 9.1.53.1/3GPP TS 04.08: Application Information message content

# 9.2 Messages for mobility management

Table 9.2.1/3GPP TS 04.08 summarizes the messages for mobility management.

Registration messages:	Reference
IMSI DETACH INDICATION	9.2.12
LOCATION UPDATING ACCEPT	9.2.13
LOCATION UPDATING REJECT	9.2.14
LOCATION UPDATING REQUEST	9.2.15
Security messages:	Reference
AUTHENTICATION REJECT	9.2.1
AUTHENTICATION REQUEST	9.2.2
AUTHENTICATION RESPONSE	9.2.3
IDENTITY REQUEST	9.2.10
IDENTITY RESPONSE	9.2.11
TMSI REALLOCATION COMMAND	9.2.17
TMSI REALLOCATION COMPLETE	9.2.18
Connection management messages:	Reference
CM SERVICE ACCEPT	9.2.5
CM SERVICE REJECT	9.2.6
CM SERVICE ABORT	9.2.7
CM SERVICE REQUEST	9.2.9
CM RE-ESTABLISHMENT REQUEST	9.2.4
ABORT	9.2.8
Miscellaneous message:	Reference
MM INFORMATION	9.2.15a
MM STATUS	9.2.16
MM NULL	9.2.19

# 9.2.1 Authentication reject

This message is sent by the network to the mobile station to indicate that authentication has failed (and that the receiving mobile station shall abort all activities). See table 9.2.2/3GPP TS 04.08.

Message type: AUTHENTICATION REJECT Significance: dual Direction: network to mobile station

IEI	Information element	Type / Reference	Presence	Format	Length
	Mobility management protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Authentication Reject message type	Message type 10.4	М	V	1

Table 9.2.2/3GPP TS 04.08: AUTHENTICATION REJECT message content

# 9.2.2 Authentication request

This message is sent by the network to the mobile station to initiate authentication of the mobile station identity. See table 9.2.3/3GPP TS 04.08.

Message type: AUTHENTICATION REQUEST

Significance: dual

Direction: network to mobile station

#### Table 9.2.3/3GPP TS 04.08: AUTHENTICATION REQUEST message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Mobility management protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Authentication Request message type	Message type 10.4	М	V	1
	Ciphering key sequence number	Ciphering key sequence number 10.5.1.2	М	V	1/2
	Spare half octet	Spare half octet 10.5.1.8	М	V	1/2
	Authentication parameter RAND	Auth. parameter RAND 10.5.3.1	М	V	16

# 9.2.3 Authentication response

This message is sent by the mobile station to the network to deliver a calculated response to the network. See table 9.2.4/3GPP TS 04.08.

Message type: AUTHENTICATION RESPONSE

Significance: dual

Direction: mobile station to network

#### Table 9.2.4/3GPP TS 04.08: AUTHENTICATION RESPONSE message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Mobility management	Protocol discriminator	М	V	1/2
	protocol discriminator	10.2			
	Skip Indicator	Skip Indicator	М	V	1/2
		10.3.1			
	Authentication Response	Message type	М	V	1
	message type	10.4			
	Authentication	Auth. parameter SRES	М	V	4
	parameter SRES	10.5.3.2			

# 9.2.4 CM Re-establishment request

This message is sent by the mobile station to the network to request re-establishment of a connection if the previous one has failed. See table 9.2.5/3GPP TS 04.08.

Message type: CM RE-ESTABLISHMENT REQUEST

Significance: dual

Direction: mobile station to network

#### Table 9.2.5/3GPP TS 04.08: CM RE-ESTABLISHMENT REQUEST message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Mobility management	Protocol discriminator	M	V	1/2
	protocol discriminator	10.2			
	Skip Indicator	Skip Indicator	М	V	1/2
		10.3.1			
	CM Re-Establishment	Message type	М	V	1
	Request message type	10.4			
	Ciphering key sequence	Ciphering key sequence	М	V	1/2
	number	number			
		10.5.1.2			
	Spare half octet	Spare half octet	М	V	1/2
		10.5.1.8			
	Mobile station	Mobile station	М	LV	4
	classmark	classmark 2			
		10.5.1.6			
	Mobile identity	Mobile identity	M	LV	2-9
		10.5.1.4			
13	Location area	Location area	С	TV	6
	identification	identification			
		10.5.1.3			

### 9.2.4.1 Location area identification

The *location area identification* information element shall appear when a TMSI is used as mobile identity, to render that mobile identity non-ambiguous. This is the LAI stored in the SIM.

### 9.2.4.2 Mobile Station Classmark

This IE shall include for multiband mobile station the Classmark 2 corresponding to the frequency band in use.

# 9.2.5 CM service accept

This message is sent by the network to the mobile station to indicate that the requested service has been accepted. See table 9.2.6/3GPP TS 04.08.

Message type: CM SERVICE ACCEPT

Significance: dual

Direction: network to mobile station

IEI	Information element	Type / Reference	Presence	Format	Length
	Mobility management protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	CM Service Accept message type	Message type 10.4	М	V	1

#### Table 9.2.6/3GPP TS 04.08: CM SERVICE ACCEPT message content

# 9.2.5a CM service prompt \$(CCBS)\$

A mobile station that does not support the "Network initiated MO call" option shall treat this message as a message with message type not defined for the PD.

This message is sent by the network to the mobile station to request the mobile to establish a service for the specified CM protocol using the specified SAPI, e.g. circuit switched connection establishment on SAPI 0, supplementary services activation on SAPI 0, or short message transfer on SAPI 3. See Table 9.2.7/3GPP TS 04.08.

Message type: CM SERVICE PROMPT

Significance: dual

Direction: network to mobile station

#### Table 9.2.7/3GPP TS 04.08: CM SERVICE PROMPT message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Mobility management	Protocol discriminator	М	V	1/2
	protocol discriminator	10.2			
	Skip Indicator	Skip Indicator	М	V	1/2
		10.3.1			
	CM Service Prompt	Message type	М	V	1
	message type	10.4			
	PD and SAPI of CM	PD and SAPI	М	V	1
		10.5.1.10a			

# 9.2.6 CM service reject

This message is sent by the network to the mobile station to indicate that the requested service cannot be provided. See table 9.2.8/3GPP TS 04.08.

Message type: CM SERVICE REJECT

Significance: dual

Direction: network to mobile station

#### Table 9.2.8/3GPP TS 04.08: CM SERVICE REJECT message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Mobility management protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	CM Service Reject message type	Message type 10.4	М	V	1
	Reject cause	Reject cause 10.5.3.6	М	V	1

# 9.2.7 CM service abort

This message is sent by the mobile station to the network to request the abortion of the first MM connection establishment in progress and the release of the RR connection. See table 9.2.9/3GPP TS 04.08.

Message type: CM SERVICE ABORT

Significance: dual

Direction: mobile station to network

#### Table 9.2.9/3GPP TS 04.08: CM SERVICE ABORT message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Mobility management	Protocol discriminator	М	V	1/2
	protocol discriminator	10.2			
	Skip Indicator	Skip Indicator	М	V	1/2
		10.3.1			
	CM Service Abort	Message type	М	V	1
	message type	10.4			

# 9.2.8 Abort

This message is sent by the network to the mobile station to initiate the abortion of all MM connections and to indicate the reason for the abortion. See table 9.2.10/3GPP TS 04.08.

Message type: ABORT

Significance: dual

Direction: network to mobile station

#### Table 9.2.10/3GPP TS 04.08: ABORT message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Mobility management	Protocol discriminator	М	V	1/2
	protocol discriminator	10.2			
	Skip Indicator	Skip Indicator	М	V	1/2
		10.3.1			
	Abort	Message type	М	V	1
	message type	10.4			
	Reject cause	Reject cause	М	V	1
		10.5.3.6			

# 9.2.9 CM service request

This message is sent by the mobile station to the network to request a service for the connection management sublayer entities, e.g. circuit switched connection establishment, supplementary services activation, short message transfer, location services. See table 9.2.11/3GPP TS 04.08.

Message type: CM SERVICE REQUEST

Significance: dual

Direction: mobile station to network

IEI	Information element	Type / Reference	Presence	Format	Length
	Mobility management protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	CM Service Request message type	Message type 10.4	М	V	1
	CM service type	CM service type 10.5.3.3	М	V	1/2
	Ciphering key sequence number	Ciphering key sequence number 10.5.1.2	М	V	1/2
	Mobile station classmark	Mobile station classmark 2 10.5.1.6	М	LV	4
	Mobile identity	Mobile identity 10.5.1.4	М	LV	2-9
8-	Priority	Priority Level 10.5.1.11	0	TV	1

Table 9.2.11/3GPP TS 04.08: CM SERVICE REQUEST message content

### 9.2.9.1 Mobile Station Classmark

This IE shall include for multiband mobile station the Classmark 2 corresponding to the frequency band in use.

# 9.2.9.2 Priority

May be included by mobile station supporting eMLPP to indicate the priority requested.

This information element is only meaningful when the CM service type is:

- Mobile originating call establishment;
- Emergency call establishment;
- Voice group call establishment;
- Voice broadcast call establishment.

# 9.2.10 Identity request

This message is sent by the network to the mobile station to request a mobile station to submit the specified identity to the network. See table 9.2.12/3GPP TS 04.08.

Message type:IDENTITY REQUESTSignificance:dualDirection:network to mobile station

IEI	Information element	Type / Reference	Presence	Format	Length
	Mobility management protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Identity Request message type	Message type 10.4	М	V	1
	Identity type	Identity type 10.5.3.4	М	V	1/2
	Spare half octet	Spare half octet 10.5.1.8	М	V	1/2

Table 9.2.12/3GPP TS 04.08: IDENTITY REQUEST message content

# 9.2.11 Identity response

This message is sent by the mobile station to the network in response to an IDENTITY REQUEST message providing the requested identity. See table 9.2.13/3GPP TS 04.08.

Message type: IDENTITY RESPONSE

Significance: dual

Direction: mobile station to network

#### Table 9.2.13/3GPP TS 04.08: IDENTITY RESPONSE message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Mobility management	Protocol discriminator	М	V	1/2
	protocol discriminator	10.2			
	Skip Indicator	Skip Indicator	М	V	1/2
		10.3.1			
	Identity Response	Message type	М	V	1
	message type	10.4			
	Mobile identity	Mobile identity	М	LV	2-10
	_	10.5.1.4			

# 9.2.12 IMSI detach indication

This message is sent by the mobile station to the network to set a deactivation indication in the network. See table 9.2.14/3GPP TS 04.08.

Message type: IMSI DETACH INDICATION

Significance: dual

Direction: mobile station to network

IEI	Information element	Type / Reference	Presence	Format	Length
	Mobility management protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	IMSI Detach Indication message type	Message type 10.4	М	V	1
	Mobile station classmark	Mobile station classmark 1 10.5.1.5	M	V	1
	Mobile identity	Mobile identity 10.5.1.4	М	LV	2-9

Table 9.2.14/3GPP TS 04.08: IMSI DETACH INDICATION message content

## 9.2.12.1 Mobile Station Classmark

This IE shall include for multiband mobile station the Classmark 1 corresponding to the frequency band in use.

# 9.2.13 Location updating accept

This message is sent by the network to the mobile station to indicate that updating or IMSI attach in the network has been completed. See table 9.2.15/3GPP TS 04.08.

Message type: LOCATION UPDATING ACCEPT

Significance: dual

Direction: network to mobile station

#### Table 9.2.15/3GPP TS 04.08: LOCATION UPDATING ACCEPT message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Mobility management protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Location Updating Accept message type	Message type 10.4	М	V	1
	Location area identification	Location area identification 10.5.1.3	М	V	5
17	Mobile identity	Mobile identity 10.5.1.4	0	TLV	3-10
A1	Follow on proceed	Follow on proceed 10.5.3.7	0	Т	1
A2	CTS permission	CTS permission 10.5.3.10	0	Т	1

#### 9.2.13.1 Follow on proceed

The *follow on proceed* information element appears if the network wishes to indicate that the mobile station may attempt an MM connection establishment using the same RR connection.

### 9.2.13.2 CTS permission

The *CTS permission* information element appears if the network wishes to allow the mobile station to use GSM-Cordless Telephony System in the Location Area.

# 9.2.14 Location updating reject

This message is sent by the network to the mobile station to indicate that updating or IMSI attach has failed. See table 9.2.16/3GPP TS 04.08.

Message type: LOCATION UPDATING REJECT

Significance: dual

Direction: network to mobile station

#### Table 9.2.16/3GPP TS 04.08: LOCATION UPDATING REJECT message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Mobility management protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Location Updating Reject message type	Message type 10.4	М	V	1
	Reject cause	Reject cause 10.5.3.6	М	V	1

# 9.2.15 Location updating request

This message is sent by the mobile station to the network either to request update of its location file (normal updating or periodic updating) or to request IMSI attach. See table 9.2.17/3GPP TS 04.08.

Message type: LOCATION UPDATING REQUEST

Significance: dual

Direction: mobile station to network

#### Table 9.2.17/3GPP TS 04.08: LOCATION UPDATING REQUEST message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Mobility management protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	Location Updating Request message type	Message type 10.4	М	V	1
	Location updating type	Location updating type 10.5.3.5	М	V	1/2
	Ciphering key sequence number	Ciphering key sequence number 10.5.1.2	M	V	1/2
	Location area identification	Location area identification 10.5.1.3	М	V	5
	Mobile station classmark	Mobile station classmark 1 10.5.1.5	M	V	1
	Mobile identity	Mobile identity 10.5.1.4	М	LV	2-9

### 9.2.15.1 Location area identification

The location area identification stored in the SIM is used.

## 9.2.15.2 Mobile Station Classmark

This IE shall include for multiband MS the Classmark 1 corresponding to the frequency band in use.

# 9.2.15a MM information

This message is sent by the network to the mobile station to provide the mobile station with subscriber specific information. See table 9.2.18/3GPP TS 04.08.

Message type:	MM INFORMATION
Significance:	dual
Direction:	network to mobile station

IEI	Information element	Type / Reference	Presence	Format	Length
	Mobility management protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	MM Information message type	Message type 10.4	М	V	1
43	Full name for network	Network Name 10.5.3.5a	0	TLV	3-?
45	Short name for network	Network Name 10.5.3.5a	0	TLV	3-?
46	Universal time zone	Time Zone 10.5.3.8	0	TV	2
47	Network time and time zone	Time Zone and Time 10.5.3.9	0	TV	8
48	LSA Identity	LSA Identifier 10.5.3.11	0	TLV	2-5

#### Table 9.2.18/3GPP TS 04.08: MM INFORMATION message content

# 9.2.15a.1 Full name for network

This IE may be sent by the network. If this IE is sent, the contents of this IE indicate the "full length name of the network" that the network wishes the mobile station to associate with the MCC and MNC contained in the Location Area Identification of the cell to which the mobile station sent its Channel Request message.

# 9.2.15a.2 Short name for network

This IE may be sent by the network. If this IE is sent, the contents of this IE indicate the "abbreviated name of the network" that the network wishes the mobile station to associate with the MCC and MNC contained in the Location Area Identification of the cell to which the mobile station sent its Channel Request message.

### 9.2.15a.3 Network time zone

This IE may be sent by the network. The mobile station should assume that this time zone applies to the Location Area of the cell to which the Channel Request message was sent.

### 9.2.15a.4 Universal time and time zone

This IE may be sent by the network. The mobile station should assume that this time zone applies to the Location Area of the cell to which the Channel Request message was sent. The mobile station shall not assume that the time information is accurate.

### 9.2.15a.5 LSA Identity

This IE may be sent by the network. The contents of this IE indicate the LSA identity of the serving cell.

# 9.2.16 MM Status

This message is sent by the mobile station or the network at any time to report certain error conditions listed in clause 8. See table 9.2.19/3GPP TS 04.08.

Message type:	MM STATUS
Significance:	local

Direction: both

### Table 9.2.19/3GPP TS 04.08: MM STATUS message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Mobility management protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	MM Status message type	Message type 10.4	М	V	1
	Reject cause	Reject cause 10.5.3.6	М	V	1

# 9.2.17 TMSI reallocation command

This message is sent by the network to the mobile station to reallocate or delete a TMSI. See table 9.2.20/3GPP TS 04.08.

Message type: TMSI REALLOCATION COMMAND

Significance: dual

Direction: network to mobile station

### Table 9.2.20/3GPP TS 04.08: TMSI REALLOCATION COMMAND message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Mobility management protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip Indicator	Skip Indicator 10.3.1	М	V	1/2
	TMSI Reallocation Command message type	Message type 10.4	М	V	1
	Location area identification	Location area identification 10.5.1.3	M	V	5
	Mobile identity	Mobile identity 10.5.1.4	М	LV	2-9

# 9.2.18 TMSI reallocation complete

This message is sent by the mobile station to the network to indicate that reallocation or deletion of a TMSI has taken place. See table 9.2.21/3GPP TS 04.08.

Message type: TMSI REALLOCATION COMPLETE Significance: dual

Significance. duai

Direction: mobile station to network

IEI Information element Type / Reference Presence Length Format Mobility management Protocol discriminator Μ 1/2 V 10.2 protocol discriminator Skip Indicator Skip Indicator Μ V 1/2 10.3.1 TMSI Reallocation Message type Μ V 1 Complete message type 10.4

#### Table 9.2.21/3GPP TS 04.08: TMSI REALLOCATION COMPLETE message content

# 9.2.19 MM Null

This message is sent in mobile to network direction.

This message is not used on the radio interface. When received by the network it shall be ignored.

The introduction of this message solves interworking issues.

Message type: MM NULL

#### Table 9.2.22/3GPP TS 04.08: MM NULL message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Mobility management	Protocol discriminator	М	V	1/2
	protocol discriminator	10.2			
	Skip Indicator	Skip Indicator	М	V	1/2
		10.3.1			
	MM Null message	Message type	М	V	1
	type	10.4			

# 9.3 Messages for circuit-switched call control

Table 9.54/3GPP TS 04.08 summarizes the messages for circuit-switched call control.

Call establishment messages:	Reference
ALERTING	9.3.1
CALL CONFIRMED 1)	9.3.2
CALL PROCEEDING	9.3.3
CONNECT	9.3.5
CONNECT ACKNOWLEDGE	9.3.6
EMERGENCY SETUP 1)	9.3.8
PROGRESS	9.3.17
SETUP	9.3.23
Call information phase messages:	Reference
MODIFY 1)	9.3.13
MODIFY COMPLETE 1)	9.3.14
MODIFY REJECT 1)	9.3.15
USER INFORMATION	9.3.31
Call clearing messages:	Reference
DISCONNECT	9.3.7
RELEASE	9.3.18
RELEASE COMPLETE	9.3.19
Messages for supplementary service control	Reference
FACILITY	9.3.9
HOLD 1)	9.3.10
HOLD ACKNOWLEDGE 1)	9.3.11
HOLD REJECT 1)	9.3.12
RETRIEVE 1)	9.3.20
RETRIEVE ACKNOWLEDGE 1)	9.3.21
RETRIEVE REJECT 1)	9.3.22
Miscellaneous messages	Reference
CONGESTION CONTROL	9.3.4
NOTIFY	9.3.16
START DTMF 1)	9.3.24
START DTMF ACKNOWLEDGE 1)	9.3.25
START DTMF REJECT 1)	9.3.26
STATUS	9.3.27
STATUS ENQUIRY	9.3.28
STOP DTMF 1)	9.3.29
STOP DTMF ACKNOWLEDGE 1)	9.3.30

Table 9.54/3GPP TS 04.08: Messages for circuit-mode connections call control

NOTE: Not supported by Blue Book ITU-T Recommendation Q.931.

# 9.3.1 Alerting

### 9.3.1.1 Alerting (network to mobile station direction)

This message is sent by the network to the calling mobile station to indicate that the called user alerting has been initiated.

See table 9.55/3GPP TS 04.08.

Message type:	ALERTING
Significance:	global
Direction:	network to mobile station

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Alerting message type	Message type 10.4	M	V	1
1C	Facility	Facility 10.5.4.15	0	TLV	2-?
1E	Progress indicator	Progress indicator 10.5.4.21	0	TLV	4
7E	User-user	User-user 10.5.4.25	0	TLV	3-131

#### Table 9.55/3GPP TS 04.08: ALERTING message content (network to mobile station direction)

#### 9.3.1.1.1 Facility

This information element may be used for functional operation of supplementary services.

#### 9.3.1.1.2 Progress indicator

This information element may be included by the network:

- in order to pass information about the call in progress, e.g., in the event of interworking; and/or
- to make the mobile station attach the user connection for speech.

#### 9.3.1.1.3 User-user

This information element may be included by the network if the called remote user included a *user-user* information element in the ALERTING message.

#### 9.3.1.2 Alerting (mobile station to network direction)

This message is sent by the called mobile station to the network, to indicate that the called user alerting has been initiated.

See table 9.55a/3GPP TS 04.08.

Message type: ALERTING Significance: global

Direction: mobile station to network

#### Table 9.55a/3GPP TS 04.08: ALERTING message content (mobile station to network direction)

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Alerting message type	Message type 10.4	М	V	1
1C	Facility	Facility 10.5.4.15	0	TLV	2-?
7E	User-user	User-user 10.5.4.25	0	TLV	3-131
7F	SS version	SS version indicator 10.5.4.24	0	TLV	2-3

#### 9.3.1.2.1 Facility

This information element may be used for functional operation of supplementary services.

#### 9.3.1.2.2 User-user

This information element may be included when the called mobile station wants to return information to the calling remote user.

#### SS version 9.3.1.2.3

This information element shall not be included if the *facility* information element is not present in this message.

This information element shall be included or excluded as defined in 3GPP TS 04.10. This information element should not be transmitted unless explicitly required by 3GPP TS 04.10.

#### Call confirmed 9.3.2

This message is sent by the called mobile station to confirm an incoming call request.

See table 9.56/3GPP TS 04.08.

Message type: CALL CONFIRMED

Significance: local

Direction: mobile station to network

		-		
Information element	Type / Reference	Presence	Format	I
l control	Protocol discriminator	М	V	

Table 9.56/3GPP TS 04.08: CALL CONFIRMED message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control	Protocol discriminator	М	V	1/2
	protocol discriminator	10.2			
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Call confirmed message type	Message type 10.4	М	V	1
D-	Repeat Indicator	Repeat Indicator 10.5.4.22	С	TV	1
04	Bearer capability 1	Bearer capability 10.5.4.5	0	TLV	3-15
04	Bearer capability 2	Bearer capability 10.5.4.5	0	TLV	3-15
08	Cause	Cause 10.5.4.11	0	TLV	4-32
15	CC Capabilities	Call Control Capabilities 10.5.4.5a	0	TLV	3

#### 9.3.2.1 Repeat indicator

The repeat indicator information element shall be included if bearer capability 1 information element and bearer capability 2 IE are both included in the message.

#### 9.3.2.2 Bearer capability 1 and bearer capability 2

The bearer capability 1 information element shall be included if and only if at least one of the following six cases holds:

- the mobile station wishes another bearer capability than that given by the *bearer capability 1* information element of the incoming SETUP message;
- the *bearer capability 1* information element is missing or not fully specified in the SETUP message;

- the *bearer capability 1* information element received in the SETUP message is accepted and the "radio channel requirement" of the mobile station is other than "full rate support only mobile station";
- the *bearer capability 1* information element received in the SETUP message indicates speech and is accepted and the mobile station supports CTM text telephony;
- the *bearer capability 1* information element received in the SETUP message indicates speech and is accepted and the mobile station supports other speech versions than GSM version 1;
- the *bearer capability 1* information element received in the SETUP message included the "fixed network user rate" parameter.

When the *bearer capability 1* information element is followed by the *bearer capability 2* IE in the SETUP, the above rules apply to both *bearer capability 1* IE and bearer capability 2 IE. Except those cases identified in 3GPP TS 07.01, if either *bearer capability* needs to be included, both shall be included.

Furthermore, both *bearer capability* information elements may be present if the mobile station wishes to reverse the order of occurrence of the *bearer capability* information elements (which is referred to in the *repeat indicator* information element, see sub-clause 10.5.4.22) in cases identified in 3GPP TS 07.01.

#### 9.3.2.3 Cause

This information element is included if the mobile station is compatible but the user is busy.

#### 9.3.2.4 CC Capabilities

This information element may be included by the mobile station to indicate its call control capabilities.

# 9.3.3 Call proceeding

This message is sent by the network to the calling mobile station to indicate that the requested call establishment information has been received, and no more call establishment information will be accepted.

See table 9.57/3GPP TS 04.08.

Message type: CALL PROCEEDING

Significance: local

Direction: network to mobile station

#### Table 9.57/3GPP TS 04.08: CALL PROCEEDING message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	M	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Call proceeding message type	Message type 10.4	М	V	1
D-	Repeat Indicator	Repeat Indicator 10.5.4.22	С	TV	1
04	Bearer capability 1	Bearer capability 10.5.4.5	0	TLV	3-15
04	Bearer capability 2	Bearer capability 10.5.4.5	0	TLV	3-15
1C	Facility	Facility 10.5.4.15	0	TLV	2-?
1E	Progress indicator	Progress indicator 10.5.4.21	0	TLV	4
8-	Priority granted	Priority Level 10.5.1.11	0	TV	1

### 9.3.3.1 Repeat indicator

This information element is included if and only if *bearer capability 1* IE and *bearer capability 2 IE* are both contained in the message.

### 9.3.3.2 Bearer capability 1 and bearer capability 2

The *bearer capability 1* information element is included if the network has to specify at least one of the negotiable parameters described in 3GPP TS 07.01, or if the *bearer capability 1* information element received in the SETUP message included the "fixed network user rate" parameter.

When the *bearer capability 1* information element is followed by the *bearer capability 2* IE in the SETUP, the above rule applies to both *bearer capability 1* IE and *bearer capability 2* IE. Except those cases identified in 3GPP TS 07.01, if either *bearer capability* needs to be included, both shall be included.

### 9.3.3.3 Facility

This information element may be used for functional operation of supplementary services.

### 9.3.3.4 Progress Indicator

This information element may be included:

- in order to pass information about the call in progress e.g. in the event of interworking; and/or
- to make the MS attach the user connection for speech.

### 9.3.3.5 Priority granted

The priority field is provided by the network in the case that eMLPP is used and the priority assigned by the network is not the same as that requested by the mobile station.

# 9.3.4 Congestion control

This message is sent by the network to indicate the establishment or termination of flow control on the transmission of USER INFORMATION messages.

See table 9.58/3GPP TS 04.08.

Message type: CONGESTION CONTROL

Significance: local (note)

Direction: network to mobile station

# Table 9.58/3GPP TS 04.08: CONGESTION CONTROL message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Congestion control message type	Message type 10.4	М	V	1
	Congestion level	Congestion level 10.5.4.12	M	V	1/2
	Spare half octet	Spare half octet 10.5.1.8	M	V	1/2
08	Cause	Cause 10.5.4.11	0	TLV	4-32

NOTE: This message has local significance, but may carry information of global significance.

# 9.3.4.1 Cause

This information element is included if the user to user information has been discarded as a result of the congestion situation.

# 9.3.5 Connect

# 9.3.5.1 Connect (network to mobile station direction)

This message is sent by the network to the calling mobile station to indicate call acceptance by the called user.

See table 9.59/3GPP TS 04.08.

Message type: CONNECT

Significance: global

Direction: network to mobile station

### Table 9.59/3GPP TS 04.08: CONNECT message content(network to mobile station direction)

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Connect message type	Message type 10.4	М	V	1
1C	Facility	Facility 10.5.4.15	0	TLV	2-?
1E	Progress indicator	Progress indicator 10.5.4.21	0	TLV	4
4C	Connected number	Connected number 10.5.4.13	0	TLV	3-14
4D	Connected subaddress	Connected subaddress 10.5.4.14	0	TLV	2-23
7E	User-user	User-user 10.5.4.25	0	TLV	3-131

# 9.3.5.1.1 Facility

This information element may be used for functional operation of supplementary services.

# 9.3.5.1.2 Progress indicator

This information element may be included by the network:

- in order to pass information about the call in progress e.g. in the event of interworking; and/or
- to make the MS attach the user connection for speech.

# 9.3.5.1.3 User-user

This information element may be included by the network if the remote user awarded the call included a user- user information element in the CONNECT message.

# 9.3.5.2 Connect (mobile station to network direction)

This message is sent by the called mobile station to the network to indicate call acceptance by the called user.

See table 9.59a/3GPP TS 04.08.

Message type: CONNECT

Significance: global

Direction: mobile station to network

#### Table 9.59a/3GPP TS 04.08: CONNECT message content (mobile station to network direction)

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Connect message type	Message type 10.4	М	V	1
1C	Facility	Facility 10.5.4.15	0	TLV	2-?
4D	Connected subaddress	Connected subaddress 10.5.4.14	0	TLV	2-23
7E	User-user	User-user 10.5.4.25	0	TLV	3-131
7F	SS version	SS version indicator 10.5.4.24	0	TLV	2-3

#### 9.3.5.2.1 Facility

This information element may be used for functional operation of supplementary services.

#### 9.3.5.2.2 User-user

This information element is included when the answering mobile station wants to return user information to the calling remote user.

#### 9.3.5.2.3 SS version

This information element shall not be included if the *facility* information element is not present in this message.

This information element shall be included or excluded as defined in 3GPP TS 04.10. This information element should not be transmitted unless explicitly required by 3GPP TS 04.10.

### 9.3.6 Connect acknowledge

This message is sent by the network to the called mobile station to indicate that the mobile station has been awarded the call. It shall also be sent by the calling mobile station to the network to acknowledge the offered connection.

See table 9.60/3GPP TS 04.08.

Message type: CONNECT ACKNOWLEDGE

Significance: local

Direction: both

#### Table 9.60/3GPP TS 04.08: CONNECT ACKNOWLEDGE message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Connect acknowledge message type	Message type 10.4	М	V	1

# 9.3.7 Disconnect

# 9.3.7.1 Disconnect (network to mobile station direction)

This message is sent by the network to indicate that the end-to-end connection is cleared.

See table 9.61/3GPP TS 04.08.

Message type: DISCONNECT

Significance: global

Direction: network to mobile station

# Table 9.61/3GPP TS 04.08: DISCONNECT message content (network to mobile station direction)

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Disconnect message type	Message type 10.4	М	V	1
	Cause	Cause 10.5.4.11	М	LV	3-31
1C	Facility	Facility 10.5.4.15	0	TLV	2-?
1E	Progress indicator	Progress indicator 10.5.4.21	0	TLV	4
7E	User-user	User-user 10.5.4.25	0	TLV	3-131
7B	Allowed actions \$(CCBS)\$	Allowed actions 10.5.4.26	0	TLV	3

# 9.3.7.1.1 Facility

This information element may be used for functional operation of supplementary services, such as the user-user service.

# 9.3.7.1.2 Progress indicator

This information element is included by the network to make the MS attach the user connection for speech and react in a specific way during call clearing (see sub-clause 5.4.4).

# 9.3.7.1.3 User-user

This information element may be included by the network when the remote user initiates call clearing and included a user-user information element in the DISCONNECT message.

# 9.3.7.1.4 Allowed actions \$(CCBS)\$

This information element may be included by the network to inform the MS about further possible reactions.

# 9.3.7.2 Disconnect (mobile station to network direction)

This message is sent by the mobile station to request the network to clear an end-to-end connection.

See table 9.61a/3GPP TS 04.08.

Message type: DISCONNECT

Significance: global

Direction: mobile station to network

#### Table 9.61a/3GPP TS 04.08: DISCONNECT message content (mobile station to network direction)

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Disconnect message type	Message type 10.4	М	V	1
	Cause	Cause 10.5.4.11	М	LV	3-31
1C	Facility	Facility 10.5.4.15	0	TLV	2-?
7E	User-user	User-user 10.5.4.25	0	TLV	3-131
7F	SS version	SS version indicator 10.5.4.24	0	TLV	2-3

#### 9.3.7.2.1 Facility

This information element may be used for functional operation of supplementary services, such as the user-user service.

#### 9.3.7.2.2 User-user

This information element is included when the mobile station initiates call clearing and wants to pass user information to the remote user at call clearing time.

#### 9.3.7.2.3 SS version

This information element shall not be included if the *facility* information element is not present in this message.

This information element shall be included or excluded as defined in 3GPP TS 04.10. This information element should not be transmitted unless explicitly required by 3GPP TS 04.10.

# 9.3.8 Emergency setup

This message is sent from the mobile station to initiate emergency call establishment.

See table 9.62/3GPP TS 04.08.

Message type: EMERGENCY SETUP

Significance: global

Direction: mobile station to network

#### Table 9.62/3GPP TS 04.08: EMERGENCY SETUP message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Emergency setup message type	Message type 10.4	М	V	1
04	Bearer capability	Bearer capability 10.5.4.5	0	TLV	3-9

### 9.3.8.1 Bearer capability

If the element is not included, the network shall by default assume speech and select full rate speech version 1. If this information element is included, it shall indicate speech, the appropriate speech version(s) and have the appropriate value of radio channel requirement field.

This information element shall be included by an ME supporting CTM text telephony.

# 9.3.9 Facility

### 9.3.9.1 Facility (network to mobile station direction)

This message is sent by the network to the mobile station to request or acknowledge a supplementary service. The supplementary service to be invoked and its associated parameters are specified in the facility information element.

See table 9.62a/3GPP TS 04.08.

Message type:FACILITYSignificance:local (note 1)Direction:network to mobile station

#### Table 9.62a/3GPP TS 04.08: FACILITY message content (network to mobile station direction)

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control	Protocol discriminator	М	V	1/2
	protocol discriminator	10.2			
	Transaction identifier	Transaction identifier	М	V	1/2
		10.3.2			
	Facility	Message type	М	V	1
	message type	10.4			
	Facility (note 2)	Facility	М	LV	1-?
		10.5.4.15			

NOTE 1: This message has local significance; however, it may carry information of global significance.

NOTE 2: The *facility* information element has no upper length limit except that given by the maximum number of octets in a L3 message, see 3GPP TS 04.06.

### 9.3.9.2 Facility (mobile station to network direction)

This message is sent by the mobile station to the network to request or acknowledge a supplementary service. The supplementary service to be invoked and its associated parameters are specified in the facility information element.

See table 9.62b/3GPP TS 04.08.

Message type:	FACILITY
Significance:	local (note 1)
Direction:	mobile station to network

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Facility message type	Message type 10.4	М	V	1
	Facility (note 2)	Facility 10.5.4.15	М	LV	1-?
7F	SS version	SS version indicator 10.5.4.24	0	TLV	2-3

### Table 9.62b/3GPP TS 04.08: FACILITY message content (mobile station to network direction)

NOTE 1: This message has local significance; however, it may carry information of global significance.

NOTE 2: The *facility* information element has no upper length limit except that given by the maximum number of octets in a L3 message, see 3GPP TS 04.06.

### 9.3.9.2.1 SS version

This information element shall be included or excluded as defined in 3GPP TS 04.10. This information element should not be transmitted unless explicitly required by 3GPP TS 04.10.

## 9.3.10 Hold

This message is sent by the mobile user to request the hold function for an existing call.

See table 9.62c/3GPP TS 04.08 for the content of the HOLD message.

For the use of this message, see 3GPP TS 04.10.

Message type: HOLD Significance: local Direction: mobile station to network

#### Table 9.62c/3GPP TS 04.08: HOLD message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control	Protocol discriminator	М	V	1/2
	protocol discriminator	10.2			
	Transaction identifier	Transaction identifier	М	V	1/2
		10.3.2			
	Hold	Message type	М	V	1
	message type	10.4			

## 9.3.11 Hold Acknowledge

This message is sent by the network to indicate that the hold function has been successfully performed.

See table 9.62d/3GPP TS 04.08 for the content of the HOLD ACKNOWLEDGE message.

For the use of this message, see 3GPP TS 04.10.

Message type:HOLD ACKNOWLEDGESignificance:localDirection:network to mobile station

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier	М	V	1/2
		10.3.2			
	Hold Acknowledge message type	Message type 10.4	М	V	1

Table 9.62d/3GPP TS 04.08: HOLD ACKNOWLEDGE message content

## 9.3.12 Hold Reject

This message is sent by the network to indicate the denial of a request to hold a call.

See table 9.62e/3GPP TS 04.08 for the content of the HOLD REJECT message.

For the use of this message, see 3GPP TS 04.10.

Message type: HOLD REJECT

Significance: local

Direction: network to mobile station

#### Table 9.62e/3GPP TS 04.08: HOLD REJECT message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control	Protocol discriminator	М	V	1/2
	protocol discriminator	10.2			
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Hold Reject message type	Message type 10.4	М	V	1
	Cause	10.5.4.11	М	LV	3-31

## 9.3.13 Modify

This message is sent by the mobile station to the network or by the network to the mobile station to request a change in bearer capability for a call.

See table 9.63/3GPP TS 04.08.

Message type:	MODIFY
Significance:	global
Direction:	both

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Modify message type	Message type 10.4	М	V	1
	Bearer capability	Bearer capability 10.5.4.5	М	LV	2-14
7C	Low layer comp.	Low layer comp. 10.5.4.18	0	TLV	2-15
7D	High layer comp.	High layer comp. 10.5.4.16	0	TLV	2-5
A3	Reverse call setup direction	Reverse call setup direction 10.5.4.22a	0	Т	1

### Table 9.63/3GPP TS 04.08: MODIFY message content

## 9.3.13.1 Low layer compatibility

This information element shall be included if it was included in the initial SETUP message.

## 9.3.13.2 High layer compatibility

This information element shall be included if it was included in the initial SETUP message.

### 9.3.13.3 Reverse call setup direction

This information element is included or omitted in the mobile to network direction according to the rules defined in subclause 5.3.4.3.1.

## 9.3.14 Modify complete

This message is sent by the mobile station to the network or by the network to the mobile station to indicate completion of a request to change bearer capability for a call.

See table 9.64/3GPP TS 04.08.

Message type: MODIFY COMPLETE

Significance: global

Direction: both

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Modify complete message type	Message type 10.4	М	V	1
	Bearer capability	Bearer capability 10.5.4.5	M	LV	2-14
7C	Low layer comp.	Low layer comp. 10.5.4.18	0	TLV	2-15
7D	High layer comp.	High layer comp. 10.5.4.16	0	TLV	2-5
A3	Reverse call setup direction	Reverse call setup direction 10.5.4.22a	0	Т	1

### Table 9.64/3GPP TS 04.08: MODIFY COMPLETE message content

### 9.3.14.1 Low layer compatibility

This information element shall be included if it was included in the initial SETUP message.

## 9.3.14.2 High layer compatibility

This information element shall be included if it was included in the initial SETUP message.

### 9.3.14.3 Reverse call setup direction

This information element is included or omitted according to the rules defined in sub-clause 5.3.4.3.2.

## 9.3.15 Modify reject

This message is sent by the mobile station to the network or by the network to the mobile station to indicate failure of a request to change the bearer capability for a call.

See table 9.65/3GPP TS 04.08.

Message type: MODIFY REJECT

Significance: global

Direction: both

### Table 9.65/3GPP TS 04.08: MODIFY REJECT message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control	Protocol discriminator	М	V	1/2
	protocol discriminator	10.2			
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Modify reject message type	Message type 10.4	М	V	1
	Bearer capability	Bearer capability 10.5.4.5	М	LV	2-14
	Cause	Cause	М	LV	3-31
		10.5.4.11			
7C	Low layer comp.	Low layer comp. 10.5.4.18	0	TLV	2-15
7D	High layer comp.	High layer comp. 10.5.4.16	0	TLV	2-5

## 9.3.15.1 Low layer compatibility

This information element shall be included if it was included in the initial SETUP message.

## 9.3.15.2 High layer compatibility

This information element shall be included if it was included in the initial SETUP message.

## 9.3.16 Notify

This message is sent either from the mobile station or from the network to indicate information pertaining to a call, such as user suspended.

See table 9.66/3GPP TS 04.08.

Message type: NOTIFY Significance: access

Direction: both

#### Table 9.66/3GPP TS 04.08: NOTIFY message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Notify message type	Message type 10.4	М	V	1
	Notification indicator	Notification indicator 10.5.4.20	М	V	1

## 9.3.17 Progress

This message is sent from the network to the mobile station to indicate the progress of a call in the event of interworking or in connection with the provision of in-band information/patterns.

See table 9.67/3GPP TS 04.08.

Message type: PROGRESS

Significance: global

Direction: network to mobile station

#### Table 9.67/3GPP TS 04.08: PROGRESS message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Progress message type	Message type 10.4	М	V	1
	Progress indicator	Progress indicator 10.5.4.21	М	LV	3
7E	User-user	User-user 10.5.4.25	0	TLV	3-131

## 9.3.17.1 User-user

This information element is included when the PROGRESS message is sent by the network when the call has been cleared by the remote user before it reached the active state to indicate that the remote user wants to pass user information at call clearing time.

## 9.3.17a CC-Establishment \$(CCBS)\$

A mobile station that does not support the "Network initiated MO call" option shall treat this message as a message with message type not defined for the PD.

This message is sent from the network to the mobile station to provide information on the call that the mobile station should attempt to establish.

See Table 9.67a/3GPP TS 04.08.

Message type: CC-ESTABLISHMENT

Significance: local

Direction: network to mobile station

#### Table 9.67a/3GPP TS 04.08: CC-Establishment message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	CC-Establishment message type	Message type 10.4	М	V	1
	Setup container	Container 10.5.4.22a	М	LV	3-n

NOTE: From the 4th IE onwards the message is coded in the same way as the SETUP message in MS to network direction from the 4th IE onwards.

## 9.3.17a.2 Setup container

This information element contains the contents of a SETUP message (Mobile Station to Network).

## 9.3.17b CC-Establishment confirmed \$(CCBS)\$

A Network that does not support the "Network initiated MO call" option shall treat this message as a message with message type not defined for the PD.

This message is sent by the mobile station to the network to indicate the requested channel characteristics for the call which may be initiated by the mobile station.

See Table 9.67b/3GPP TS 04.08.

Message type:	CC-ESTABLISHMENT CONFIRMED
Significance:	local
Direction:	mobile station to network

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	CC-Establishment confirmed message type	Message type 10.4	М	V	1
D-	Repeat Indicator	Repeat Indicator 10.5.4.22	С	TV	1
04	Bearer capability 1	Bearer capability 10.5.4.5	М	TLV	3-10
04	Bearer capability 2	Bearer capability 10.5.4.5	0	TLV	3-10
08	Cause	Cause 10.5.4.11	0	TLV	4-32

### Table 9.67b/3GPP TS 04.08: CC-ESTABLISHMENT CONFIRMED message content

### 9.3.17b.1 Repeat indicator

The *repeat indicator* information element shall be included if *bearer capability 1* information element and *bearer capability 2* IE are both included in the message.

### 9.3.17b.2 Bearer capability 1 and bearer capability 2

If, in any subsequent SETUP message to be sent on this transaction the *bearer capability 1* information element is to be followed by the *bearer capability 2* IE, then the *bearer capability 2* IE shall be included in this message.

### 9.3.17b.9 Cause

This information element is included if the mobile station is compatible but the user is busy.

## 9.3.18 Release

## 9.3.18.1 Release (network to mobile station direction)

This message is sent, from the network to the mobile station to indicate that the network intends to release the transaction identifier, and that the receiving equipment shall release the transaction identifier after sending RELEASE COMPLETE.

See table 9.68/3GPP TS 04.08.

Message type:	RELEASE
Significance:	local (note)
Direction:	network to mobile station

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Release message type	Message type 10.4	М	V	1
08	Cause	Cause 10.5.4.11	0	TLV	4-32
08	Second cause	Cause 10.5.4.11	0	TLV	4-32
1C	Facility	Facility 10.5.4.15	0	TLV	2-?
7E	User-user	User-user 10.5.4.25	0	TLV	3-131

### Table 9.68/3GPP TS 04.08: RELEASE message content (network to mobile station direction)

NOTE: This message has local significance; however, it may carry information of global significance when used as the first call clearing message.

### 9.3.18.1.1 Cause

This information element shall be included if this message is used to initiate call clearing.

### 9.3.18.1.2 Second cause

This information element may be included under the conditions described in sub-clause 5.4.4.1.2.3 "Abnormal cases" (Clearing initiated by the network).

#### 9.3.18.1.3 Facility

This information element may be included for functional operation of supplementary services.

#### 9.3.18.1.4 User-user

This information element may be included in the network to mobile station direction, when the RELEASE message is used to initiate call clearing, in order to transport user-user information from the remote user.

### 9.3.18.2 Release (mobile station to network direction)

This message is sent from the mobile station to the network to indicate that the mobile station intends to release the transaction identifier, and that the receiving equipment shall release the transaction identifier after sending RELEASE COMPLETE.

See table 9.68a/3GPP TS 04.08.

Message type:	RELEASE
Significance:	local (note)
Direction:	mobile station to network direction

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Release message type	Message type 10.4	М	V	1
08	Cause	Cause 10.5.4.11	0	TLV	4-32
08	Second cause	Cause 10.5.4.11	0	TLV	4-32
1C	Facility	Facility 10.5.4.15	0	TLV	2-?
7E	User-user	User-user 10.5.4.25	0	TLV	3-131
7F	SS version	SS version indicator 10.5.4.24	0	TLV	2-3

#### Table 9.68a/3GPP TS 04.08: RELEASE message content (mobile station to network direction)

NOTE: This message has local significance; however, it may carry information of global significance when used as the first call clearing message.

#### 9.3.18.2.1 Cause

This information element shall be included if this message is used to initiate call clearing.

### 9.3.18.2.2 Second cause

This information element may be included under the conditions described in sub-clause 5.4.3.5 "Abnormal cases" (Clearing initiated by the mobile station).

### 9.3.18.2.3 Facility

This information element may be included for functional operation of supplementary services.

#### 9.3.18.2.4 User-user

This information element is included when the RELEASE message is used to initiate call clearing and the mobile station wants to pass user information to the remote user at call clearing time.

#### 9.3.18.2.5 SS version

This information element shall not be included if the *facility* information element is not present in this message.

This information element shall be included or excluded as defined in 3GPP TS 04.10. This information element should not be transmitted unless explicitly required by 3GPP TS 04.10.

## 9.3.18a Recall \$(CCBS)\$

A mobile station that does not support the "Network initiated MO call" option shall treat this message as a message with message type not defined for the PD.

This message is sent from the network to the mobile station to initiate the sending of the SETUP message. In addition it provides information for user notification.

See Table 9.68b/3GPP TS 04.08.

Message type: RECALL

Significance: local

Direction: network to mobile station

### Table 9.68b/3GPP TS 04.08: Recall message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Recall message type	Message type 10.4	М	V	1
	Recall Type	Recall Type 10.5.4.21a	М	V	1
	Facility	Facility 10.5.4.15	М	LV	2-n

### 9.3.18a.1 Recall Type

The purpose of the recall type information element is to describe the reason for the recall.

### 9.3.18a.2 Facility

The information element shall be included for functional operation of supplementary services.

## 9.3.19 Release complete

### 9.3.19.1 Release complete (network to mobile station direction)

This message is sent from the network to the mobile station to indicate that the network has released the transaction identifier and that the mobile station shall release the transaction identifier.

See table 9.69/3GPP TS 04.08.

Message type: RELEASE COMPLETE

Significance: local (note)

Direction: network to mobile station direction

# Table 9.69/3GPP TS 04.08: RELEASE COMPLETE message content (network to mobile station direction)

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control	Protocol discriminator	М	V	1/2
	protocol discriminator	10.2			
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Release complete message type	Message type 10.4	М	V	1
08	Cause	Cause 10.5.4.11	0	TLV	4-32
1C	Facility	Facility 10.5.4.15	0	TLV	2-?
7E	User-user	User-user 10.5.4.25	0	TLV	3-131

NOTE: This message has local significance; however, it may carry information of global significance when used as the first call clearing message.

### 9.3.19.1.1 Cause

This information element shall be included if the message is used to initiate call clearing.

## 9.3.19.1.2 Facility

This information element may be included for functional operation of supplementary services.

## 9.3.19.1.3 User-user

This information element is included in the network to mobile station direction, when the RELEASE COMPLETE message is used to initiate call clearing, in order to transport user-user information from the remote user.

## 9.3.19.2 Release complete (mobile station to network direction)

This message is sent from the mobile station to the network to indicate that the mobile station has released the transaction identifier and that the network shall release the transaction identifier.

See table 9.69a/3GPP TS 04.08.

Message type:RELEASE COMPLETESignificance:local (note)Direction:mobile station to network direction

# Table 9.69a/3GPP TS 04.08: RELEASE COMPLETE message content (mobile station to network direction)

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control	Protocol discriminator	М	V	1/2
	protocol discriminator	10.2			
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Release complete message type	Message type 10.4	М	V	1
08	Cause	Cause 10.5.4.11	0	TLV	4-32
1C	Facility	Facility 10.5.4.15	0	TLV	2-?
7E	User-user	User-user 10.5.4.25	0	TLV	3-131
7F	SS version	SS version indicator 10.5.4.24	0	TLV	2-3

NOTE: This message has local significance; however, it may carry information of global significance when used as the first call clearing message.

### 9.3.19.2.1 Cause

This information element shall be included if the message is used to initiate call clearing.

## 9.3.19.2.2 Facility

This information element may be included for functional operation of supplementary services.

## 9.3.19.2.3 User-user

This information element is included in the mobile station to network direction when the RELEASE COMPLETE message is used to initiate call clearing and the mobile station wants to pass user information to the remote user at call clearing time.

#### 9.3.19.2.4 SS version.

This information element shall not be included if the *facility* information element is not present in this message.

This information element shall be included or excluded as defined in 3GPP TS 04.10. This information element should not be transmitted unless explicitly required by 3GPP TS 04.10.

## 9.3.20 Retrieve

This message is sent by the mobile user to request the retrieval of a held call.

See table 9.69b/3GPP TS 04.08 for the content of the RETRIEVE message.

For the use of this message, see 3GPP TS 04.10.

Message type: RETRIEVE

Significance: local

Direction: mobile station to network

#### Table 9.69b/3GPP TS 04.08: RETRIEVE message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Retrieve message type	Message type 10.4	М	V	1

## 9.3.21 Retrieve Acknowledge

This message is sent by the network to indicate that the retrieve function has been successfully performed.

See table 9.69c/3GPP TS 04.08 for the content of the RETRIEVE ACKNOWLEDGE message.

For the use of this message, see 3GPP TS 04.10.

Message type: RETRIEVE ACKNOWLEDGE

Significance: local

Direction: network to mobile station

#### Table 9.69c/3GPP TS 04.08: RETRIEVE ACKNOWLEDGE message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control	Protocol discriminator	М	V	1/2
	protocol discriminator	10.2			
	Transaction identifier	Transaction identifier	M	V	1/2
		10.3.2			
	Retrieve Acknowledge	Message type	М	V	1
	message type	10.4			

## 9.3.22 Retrieve Reject

This message is sent by the network to indicate the inability to perform the requested retrieve function.

See table 9.69d/3GPP TS 04.08 for the content of the RETRIEVE REJECT message.

For the use of this message, see 3GPP TS 04.10.

Message type: RETRIEVE REJECT

Significance: local

Direction: network to mobile station

#### Table 9.69d/3GPP TS 04.08: RETRIEVE REJECT message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control	Protocol discriminator	М	V	1/2
	protocol discriminator	10.2			
	Transaction identifier	Transaction identifier	М	V	1/2
		10.3.2			
	Retrieve Reject	Message type	M	V	1
	message type	10.4			
	Cause	10.5.4.11	М	LV	3-31

## 9.3.23 Setup

## 9.3.23.1 Setup (mobile terminated call establishment)

This message is sent by the network to the mobile station to initiate a mobile terminated call establishment.

See table 9.70/3GPP TS 04.08.

Message type: SETUP Significance: global Direction: network to mobile station

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Setup message type	Message type 10.4	М	V	1
D-	BC repeat indicator	Repeat indicator 10.5.4.22	С	ΤV	1
04	Bearer capability 1	Bearer capability 10.5.4.5	0	TLV	3-15
04	Bearer capability 2	Bearer capability	0	TLV	3-15
		10.5.4.5			
1C	Facility	Facility 10.5.4.15	0	TLV	2-?
1E	Progress indicator	Progress indicator 10.5.4.21	0	TLV	4
34	Signal	Signal 10.5.4.23	0	TV	2
5C	Calling party BCD number	Calling party BCD num. 10.5.4.9	0	TLV	3-14
5D	Calling party sub- address	Calling party subaddr. 10.5.4.10	0	TLV	2-23
5E	Called party BCD number	Called party BCD num. 10.5.4.7	0	TLV	3-19
6D	Called party sub- address	Called party subaddr. 10.5.4.8	0	TLV	2-23
74	Redirecting party BCD number	Redirecting party BCD num. 10.5.4.21a	0	TLV	3-19
75	Redirecting party sub-address	Redirecting party subaddress. 10.5.4.21b	0	TLV	2-23
D-	LLC repeat indicator	Repeat indicator 10.5.4.22	0	TV	1
7C	Low layer compatibility I	Low layer comp. 10.5.4.18	0	TLV	2-15
7C	Low layer compatibility II	Low layer comp. 10.5.4.18	С	TLV	2-15
D-	HLC repeat indicator	Repeat indicator 10.5.4.22	0	TV	1
7D	High layer compatibility i	High layer comp. 10.5.4.16	0	TLV	2-5
7D	High layer compatibility ii	High layer comp. 10.5.4.16	С	TLV	2-5
7E	User-user	User-user 10.5.4.25	0	TLV	3-35
8-	Priority	Priority Level 10.5.1.11	0	TV	1
19	Alert	Alerting Pattern 10.5.4.26	0	TLV	3

#### Table 9.70/3GPP TS 04.08: SETUP message content (network to mobile station direction)

## 9.3.23.1.1 BC repeat indicator

The *BC repeat indicator* information element is included if and only if *bearer capability* 1 information element and *bearer capability* 2 IE are both present in the message.

### 9.3.23.1.2 Bearer capability 1 and bearer capability 2

The *bearer capability 1* information element may be omitted in the case where the mobile subscriber is allocated only one directory number for all services (ref.: 3GPP TS 09.07). The *bearer capability 2* IE is missing at least if the *bearer capability 1* IE is missing.

### 9.3.23.1.3 Facility

This information element may be included for functional operation of supplementary services.

### 9.3.23.1.4 Progress indicator

This information element is included by the network

- in order to pass information about the call in progress e.g. in the event of interworking; and/or
- to make the MS attach the user connection for speech.

### 9.3.23.1.4a Called party BCD number

For all bands except for PCS1900, the maximum length of this IE sent by the network shall be 13 octets

#### 9.3.23.1.5 Called party subaddress

Included in the Network-to-mobile station direction if the calling user includes a *called party subaddress* information element in the SETUP message.

### 9.3.23.1.6 LLC repeat indicator

The LLC repeat indicator information element is included if and only if both following conditions hold:

- The BC repeat indicator IE is contained in the message.
- The *low layer compatibility I* IE is contained in the message.

If included, the LLC repeat indicator shall specify the same repeat indication as the BC repeat indicator IE.

### 9.3.23.1.7 Low layer compatibility I

Included in the network-to-mobile station direction if the calling user specified a low layer compatibility.

### 9.3.23.1.8 Low layer compatibility II

Included if and only if the LLC repeat indicator information element is contained in the message.

#### 9.3.23.1.9 HLC repeat indicator

The HLC repeat indicator information element is included if and only both following conditions hold:

- The BC repeat indicator IE is contained in the message.
- The high layer compatibility i IE is contained in the message.

If included, the HLC repeat indicator shall specify the same repeat indication as the BC repeat indicator IE.

#### 9.3.23.1.10 High layer compatibility i

Included in the network-to-mobile station direction if the calling user specified a high layer compatibility.

### 9.3.23.1.11 High layer compatibility ii

Included if and only if the HLC repeat indicator information element is contained in the message.

### 9.3.23.1.12 User-user

May be included in the network to called mobile station direction when the calling remote user included a user-user information element in the SETUP message.

### 9.3.23.1.13 Redirecting party BCD number

May be included in the network to called mobile station direction when the call has been redirected.

### 9.3.23.1.14 Redirecting party subaddress

May be included in the network to called mobile station direction when the calling remote user included a called party subaddress in the SETUP message and the call has been redirected

### 9.3.23.1.15 Priority

May be included by the network to indicate the priority of the incoming call if eMLPP is used.

### 9.3.23.1.16 Alert \$(Network Indication of Alerting in the MS )\$

May be included by the network to give some indication about alerting (category or level). If supported in the MS, this optional indication is to be used by the MS as specified in 3GPP TS 02.07.

### 9.3.23.2 Setup (mobile originating call establishment)

This message is sent from the mobile station to the network to initiate a mobile originating call establishment.

See table 9.70a/3GPP TS 04.08.

Message type:SETUPSignificance:globalDirection:mobile station to network

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control	Protocol discriminator	М	V	1/2
	protocol discriminator Transaction identifier	10.2 Transaction identifier 10.3.2	М	V	1/2
	Setup	Message type	М	V	1
	message type	10.4			
D-	BC repeat indicator	Repeat indicator 10.5.4.22	С	TV	1
04	Bearer capability 1	Bearer capability 10.5.4.5	М	TLV	3-16
04	Bearer capability 2	Bearer capability 10.5.4.5	0	TLV	3-16
1C	Facility(simple recall alignment)	Facility 10.5.4.15	0	TLV	2-
5D	Calling party sub- address	Calling party subaddr. 10.5.4.10	0	TLV	2-23
5E	Called party BCD number	Called party BCD num. 10.5.4.7	М	TLV	3-43
6D	Called party sub- address	Called party subaddr. 10.5.4.8	0	TLV	2-23
D-	LLC repeat indicator	Repeat indicator 10.5.4.22	0	TV	1
7C	Low layer compatibility I	Low layer comp. 10.5.4.18	0	TLV	2-15
7C	Low layer compatibility II	Low layer comp. 10.5.4.18	0	TLV	2-15
D-	HLC repeat indicator	Repeat indicator 10.5.4.22	0	TV	1
7D	High layer compatibility i	High layer comp. 10.5.4.16	0	TLV	2-5
7D	High layer compatibility ii	High layer comp. 10.5.4.16	0	TLV	2-5
7E	User-user	User-user 10.5.4.25	0	TLV	3-35
7F	SS version	SS version indicator 10.5.4.24	0	TLV	2-3
A1	CLIR suppression	CLIR suppression 10.5.4.11a	С	Т	1
A2	CLIR invocation	CLIR invocation 10.5.4.11b	С	Т	1
15	CC capabilities	Call Control Capabilities 10.5.4.5a	0	TLV	3
1D	Facility \$(CCBS)\$ (advanced recall alignment)	Facility 10.5.4.15	0	TLV	2-?
1B	Facility (recall alignment Not essential) \$(CCBS)\$	Facility 10.5.4.15	0	TLV	2-?

### Table 9.70a/3GPP TS 04.08: SETUP message content (mobile station to network direction)

## 9.3.23.2.1 BC repeat indicator

The *BC repeat indicator* information element is included if and only if *bearer capability 1* IE and *bearer capability 2* IE are both present in the message.

### 9.3.23.2.2 Facility

The information element may be included for functional operation of supplementary services.

Three different codings of this IE exist, for further details see 3GPP TS 04.10.

## 9.3.23.2.3 LLC repeat indicator

The LLC repeat indicator information element is included if and only if both following conditions hold:

- The BC repeat indicator IE is contained in the message.
- The *low layer compatibility I* IE is contained in the message.

If included, the LLC repeat indicator shall specify the same repeat indication as the BC repeat indicator IE.

## 9.3.23.2.4 Low layer compatibility I

The information element is included in the MS-to-network direction when the calling MS wants to pass low layer compatibility information to the called user.

## 9.3.23.2.5 Low layer compatibility II

Included if and only if the LLC repeat indicator information element is contained in the message.

## 9.3.23.2.6 HLC repeat indicator

The HLC repeat indicator information element is included if and only if both following conditions hold:

- The BC repeat indicator IE is contained in the message.
- The *high layer compatibility i* IE is contained in the message.

If included, the HLC repeat indicator shall specify the same repeat indication as the BC repeat indicator IE.

## 9.3.23.2.7 High layer compatibility i

The information element is included when the calling MS wants to pass high layer compatibility information to the called user.

## 9.3.23.2.8 High layer compatibility ii

Included if and only if the HLC repeat indicator information element is contained in the message.

## 9.3.23.2.9 User-user

The information element is included in the calling mobile station to network direction when the calling mobile station wants to pass user information to the called remote user.

## 9.3.23.2.10 SS version

This information element shall not be included if the *facility* information element is not present in this message.

This information element shall be included or excluded as defined in 3GPP TS 04.10. This information element should not be transmitted unless explicitly required by 3GPP TS 04.10.

## 9.3.23.2.11 CLIR suppression

The information element may be included by the MS (see 3GPP TS 04.81). If this information element is included the *CLIR invocation* IE shall not be included.

## 9.3.23.2.12 CLIR invocation

The information element may be included by the MS (see 3GPP TS 04.81). If this information element is included the *CLIR suppression* IE shall not be included.

### 9.3.23.2.13 CC Capabilities

This information element may be included by the mobile station to indicate its call control capabilities.

## 9.3.23a Start CC \$(CCBS)\$

A Network that does not support the "Network initiated MO call" option shall treat this message as a message with message type not defined for the PD.

This message is sent by the mobile station to the network to open a Call Control transaction which the network has requested the mobile station to open.

See Table 9.70b/3GPP TS 04.08.

Message type: START CC

Significance: local

Direction: mobile station to network

#### Table 9.70b/3GPP TS 04.08: START CC message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Start CC message type	Message type 10.4	М	V	1
15	CC Capabilities	Call Control Capabilities 10.5.4.5a	0	TLV	3

### 9.3.23a.1 CC Capabilities

This information element may be included by the mobile station to indicate its call control capabilities

## 9.3.24 Start DTMF

This message is sent by the mobile station to the network and contains the digit the network should reconvert back into a DTMF tone which is then applied towards the remote user.

See table 9.71/3GPP TS 04.08.

Message type:	START DTMF

Significance: local

Direction: mobile station to network

#### Table 9.71/3GPP TS 04.08: START DTMF message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	M	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Start DTMF message type	Message type 10.4	М	V	1
2C	Keypad facility	Keypad facility 10.5.4.17	М	TV	2

## 9.3.25 Start DTMF Acknowledge

This message is sent by the network to the mobile station to indicate the successful initiation of the action requested by the START DTMF message (conversion of the digit contained in this message into a DTMF tone).

See table 9.72/3GPP TS 04.08.

Message type:	START DTMF ACKNOWLEDGE
Significance:	local

Direction: network to mobile station

### Table 9.72/3GPP TS 04.08: START DTMF ACKNOWLEDGE message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Start DTMF acknowledge message type	Message type 10.4	М	V	1
2C	Keypad facility	Keypad facility 10.5.4.17	М	TV	2

## 9.3.25.1 Keypad facility

This information element contains the digit corresponding to the DTMF tone that the network applies towards the remote user.

## 9.3.26 Start DTMF reject

This message is sent by the network to the mobile station, if the network can not accept the START DTMF message.

See table 9.73/3GPP TS 04.08.

Message type: START DTMF REJECT

Significance: local

Direction: network to mobile station

### Table 9.73/3GPP TS 04.08: START DTMF REJECT message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control	Protocol discriminator	М	V	1/2
	protocol discriminator	10.2			
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Start DTMF reject message type	Message type 10.4	М	V	1
	Cause	Cause 10.5.4.11	М	LV	3-31

## 9.3.27 Status

This message is sent by the mobile station or the network at any time during a call to report certain error conditions listed in clause 8. It shall also be sent in response to a STATUS ENQUIRY message.

See table 9.74/3GPP TS 04.08.

Message type: STATUS

Significance: local

Direction: both

#### Table 9.74/3GPP TS 04.08: STATUS message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Status message type	Message type 10.4	М	V	1
	Cause	Cause 10.5.4.11	М	LV	3-31
	Call state	Call state 10.5.4.6	М	V	1
24	Auxiliary states	Auxiliary states 10.5.4.4	0	TLV	3

### 9.3.27.1 Auxiliary states

The information element is included if and only if the call state is "active" or "mobile originating modify" and any auxiliary state is different from "idle". For the definition of the auxiliary states see 3GPP TS 04.83 and 3GPP TS 04.84

## 9.3.28 Status enquiry

This message is sent by the mobile station or the network at any time to solicit a STATUS message from the peer layer 3 entity. Sending of STATUS message in response to a STATUS ENQUIRY message is mandatory.

See table 9.75/3GPP TS 04.08.

Message type:	STATUS ENQUIRY
Significance:	local
Direction:	both

#### Table 9.75/3GPP TS 04.08: STATUS ENQUIRY message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Status enquiry message type	Message type 10.4	М	V	1

## 9.3.29 Stop DTMF

This message is sent by a mobile station to the network and is used to stop the DTMF tone sent towards the remote user.

See table 9.76/3GPP TS 04.08.

Message type:	STOP DTMF
Significance:	local
Direction:	mobile station to network

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Stop DTMF message type	Message type 10.4	М	V	1

#### Table 9.76/3GPP TS 04.08: STOP DTMF message content

## 9.3.30 Stop DTMF acknowledge

This message is sent by the network to the mobile station to indicate that the sending of the DTMF tone has been stopped.

See table 9.77/3GPP TS 04.08.

Message type: STOP DTMF ACKNOWLEDGE

Significance: local

Direction: network to mobile station

#### Table 9.77/3GPP TS 04.08: STOP DTMF ACKNOWLEDGE message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control	Protocol discriminator	М	V	1/2
	protocol discriminator	10.2			
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Stop DTMF acknowledge message type	Message type 10.4	М	V	1

## 9.3.31 User information

This message is sent by the mobile station to the network to transfer information to the remote user. This message is also sent by the network to the mobile station to deliver information transferred from the remote user. This message is used if the user-to-user transfer is part of an allowed information transfer as defined in 3GPP TS 04.10.

See table 9.78/3GPP TS 04.08.

Message type: USER INFORMATION

Significance: access

Direction: both

### Table 9.78/3GPP TS 04.08: USER INFORMATION message content

IEI	Information element	Type / Reference	Presence	Format	Length
	Call control protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	User Information	Message type	М	V	1
	message type	10.4			
	User-user	User-user 10.5.4.25	М	LV	3-130
A0	More data	More data 10.5.4.19	0	Т	1

## 9.3.31.1 User-user

Some networks may only support a maximum length of 35 octets. Procedures for interworking are not currently defined and are for further study.

## 9.3.31.2 More data

The information element is included by the sending user to indicate that another USER INFORMATION message pertaining to the same message block will follow.

## 9.4 GPRS Mobility Management Messages

## 9.4.1 Attach request

This message is sent by the MS to the network in order to perform a GPRS or combined GPRS attach. See table 9.4.1/3GPP TS 04.08.

Message type: ATTACH REQUEST

Significance: dual

Direction: MS to network

## Table 9.4.1/3GPP TS 04.08: ATTACH REQUEST message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip indicator	Skip indicator 10.3.1	М	V	1/2
	Attach request message identity	Message type 10.4	М	V	1
	MS network capability	MS network capability 10.5.5.12	М	LV	2-3
	Attach type	Attach type 10.5.5.2	М	V	1/2
	GPRS ciphering key sequence number	Ciphering key sequence number 10.5.1.2	М	V	1/2
	DRX parameter	DRX parameter 10.5.5.6	М	V	2
	P-TMSI or IMSI	Mobile identity 10.5.1.4	М	LV	6 - 9
	Old routing area identification	Routing area identification 10.5.5.15	М	V	6
	MS Radio Access capability	MS Radio Access capability 10.5.5.12a	М	LV	6 - 13
19	Old P-TMSI signature	P-TMSI signature 10.5.5.8	0	TV	4
17	Requested READY timer value	GPRS Timer 10.5.7.3	0	TV	2
9-	TMSI status	TMSI status 10.5.5.4	0	TV	1

## 9.4.1.1 Old P-TMSI signature

This IE is included if a valid P-TMSI and P-TMSI signature are stored in the MS.

## 9.4.1.2 Requested READY timer value

This IE may be included if the MS wants to indicate a preferred value for the READY timer.

## 9.4.1.3 TMSI status

This IE shall be included if the MS performs a combined GPRS attach and no valid TMSI is available.

## 9.4.2 Attach accept

This message is sent by the network to the MS to indicate that the corresponding attach request has been accepted. See table 9.4.2/3GPP TS 04.08.

Message type:	ATTACH ACCEPT
a: : <i>c</i> :	

Significance: dual

Direction: network to MS

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip indicator	Skip indicator 10.3.1	М	V	1/2
	Attach accept message identity	Message type 10.4	М	V	1
	Attach result	Attach result 10.5.5.1	М	V	1/2
	Force to standby	Force to standby 10.5.5.7	М	V	1/2
	Periodic RA update timer	GPRS Timer 10.5.7.3	М	V	1
	Radio priority for SMS	Radio priority 10.5.7.2	М	V	1/2
	Spare half octet	Spare half octet 10.5.1.8	М	V	1/2
	Routing area identification	Routing area identification 10.5.5.15	М	V	6
19	P-TMSI signature	P-TMSI signature 10.5.5.8	0	TV	4
17	Negotiated READY timer value	GPRS Timer 10.5.7.3	0	TV	2
18	Allocated P-TMSI	Mobile identity 10.5.1.4	0	TLV	7
23	MS identity	Mobile identity 10.5.1.4	0	TLV	7-10
25	GMM cause	GMM cause 10.5.5.14	0	TV	2

### Table 9.4.2/3GPP TS 04.08: ATTACH ACCEPT message content

## 9.4.2.1 P-TMSI signature

This IE may be included to assign an identity to the MS's GMM context.

## 9.4.2.2 Negotiated READY timer

This IE may be included to indicate a value for the READY timer.

## 9.4.2.3 Allocated P-TMSI

This IE may be included to assign a P-TMSI to an MS in case of a GPRS or combined GPRS attach.

### 9.4.2.4 MS identity

This IE may be included to assign or unassign a TMSI to an MS in case of a combined GPRS attach.

## 9.4.2.5 GMM cause

This IE shall be included when IMSI attach for non-GPRS services was not successful during a combined GPRS attach procedure.

## 9.4.3 Attach complete

This message is sent by the MS to the network if a P-TMSI and/or a TMSI was included within the *attach accept* message. See table 9.4.3/3GPP TS 04.08.

Message type: ATTACH COMPLETE

Significance: dual

Direction: MS to network

### Table 9.4.3/3GPP TS 04.08: ATTACH COMPLETE message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip indicator	Skip indicator 10.3.1	М	V	1/2
	Attach complete message identity	Message type 10.4	М	V	1

## 9.4.4 Attach reject

This message is sent by the network to the MS to indicate that the corresponding attach request has been rejected. See table 9.4.4/3GPP TS 04.08.

Message type: ATTACH REJECT

Significance: dual

Direction: network to MS

### Table 9.4.4/3GPP TS 04.08: ATTACH REJECT message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip indicator	Skip indicator 10.3.1	М	V	1/2
	Attach reject message identity	Message type 10.4	М	V	1
	GMM cause	GMM cause 10.5.5.14	М	V	1

## 9.4.5 Detach request

### 9.4.5.1 Detach request (mobile terminated detach)

This message is sent by the network to request the release of a GMM context. See table 9.4.5.1/3GPP TS 04.08.

Message type: DETACH REQUEST

Significance: dual

Direction: network to MS

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip indicator	Skip indicator 10.3.1	M	V	1/2
	Detach request message identity	Message type 10.4	М	V	1
	Detach type	Detach type 10.5.5.5	М	V	1/2
	Force to standby	Force to standby 10.5.5.7	М	V	1/2
25	GMM cause	GMM cause 10.5.5.14	0	TV	2

Table 9.4.5.1/3GPP TS 04.08: DETACH REQUEST message content

## 9.4.5.1.1 GMM cause

This IE shall be included in case the detach reason has to be indicated to the MS, e.g. due to a failed IMEI check.

### 9.4.5.2 Detach request (mobile originating detach)

This message is sent by the MS to request the release of a GMM context. See table 9.4.5.2/3GPP TS 04.08.

Message type: DETACH REQUEST

Significance: dual

Direction: MS to network

#### Table 9.4.5.2/3GPP TS 04.08: DETACH REQUEST message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip indicator	Skip indicator 10.3.1	М	V	1/2
	Detach request message identity	Message type 10.4	М	V	1
	Detach type	Detach type 10.5.5.5	М	V	1/2
	Spare half octet	Spare half octet 10.5.1.8	М	V	1/2

## 9.4.6 Detach accept

## 9.4.6.1 Detach accept (mobile terminated detach)

This message is sent by the MS to indicate that the detach procedure has been completed. See table 9.4.6.1/3GPP TS 04.08.

Message type: DETACH ACCEPT

Significance: dual

Direction: MS to network

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip indicator	Skip indicator 10.3.1	М	V	1/2
	Detach accept message identity	Message type 10.4	М	V	1

### Table 9.4.6.1/3GPP TS 04.08: DETACH ACCEPT message content

### 9.4.6.2 Detach accept (mobile originating detach)

This message is sent by the network to indicate that the detach procedure has been completed. See table 9.4.6.2/3GPP TS 04.08.

Message type: DETACH ACCEPT

Significance: dual

Direction: network to MS

### Table 9.4.6.2/3GPP TS 04.08: DETACH ACCEPT message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip indicator	Skip indicator 10.3.1	М	V	1/2
	Detach accept message identity	Message type 10.4	М	V	1
	Force to standby	Force to standby 10.5.5.7	М	V	1/2
	Spare half octet	Spare half octet 10.5.1.8	М	V	1/2

## 9.4.7 P-TMSI reallocation command

This message is sent by the network to the MS to reallocate a P-TMSI. See table 9.4.7/3GPP TS 04.08.

Message type: P-TMSI REALLOCATION COMMAND

Significance: dual

Direction: network to MS

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip indicator	Skip indicator 10.3.1	М	V	1/2
	P-TMSI reallocation command message identity	Message type 10.4	М	V	1
	Allocated P-TMSI	Mobile identity 10.5.1.4	М	LV	6
	Routing area identification	Routing area identification 10.5.5.15	М	V	6
	Force to standby	Force to standby 10.5.5.7	М	V	1/2
	Spare half octet	Spare half octet 10.5.1.8	М	V	1/2
19	P-TMSI signature	P-TMSI signature 10.5.5.8	0	TV	4

Table 9.4.7/3GPP TS 04.08: P-TMSI REALLOCATION COMMAND message content

### 9.4.7.1 P-TMSI signature

This IE may be included to assign an identity to the MS's GMM context.

## 9.4.8 P-TMSI reallocation complete

This message is sent by the MS to the network to indicate that reallocation of a P-TMSI has taken place. See table 9.4.8/3GPP TS 04.08.

Message type: P-TMSI REALLOCATION COMPLETE

Significance: dual

Direction: MS to network

### Table 9.4.8/3GPP TS 04.08: P-TMSI REALLOCATION COMPLETE message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip indicator	Skip indicator 10.3.1	М	V	1/2
	P-TMSI reallocation complete message identity	Message type 10.4	М	V	1

## 9.4.9 Authentication and ciphering request

This message is sent by the network to the MS to initiate authentication of the MS identity. Additionally, the ciphering mode is set, indicating whether ciphering will be performed or not. See table 9.4.9/3GPP TS 04.08.

Message type: AUTHENTICATION AND CIPHERING REQUEST

Significance: dual

Direction: network to MS

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip indicator	Skip indicator 10.3.1	М	V	1/2
	Authentication and ciphering request message identity	Message type 10.4	М	V	1
	Ciphering algorithm	Ciphering algorithm 10.5.5.3	М	V	1/2
	IMEISV request	IMEISV request 10.5.5.10	М	V	1/2
	Force to standby	Force to standby 10.5.5.7	М	V	1/2
	A&C reference number	A&C reference number 10.5.5.19	М	V	1/2
21	Authentication parameter RAND	Authentication parameter RAND 10.5.3.1	0	TV	17
8	GPRS ciphering key sequence number	Ciphering key sequence number 10.5.1.2	С	ΤV	1

#### Table 9.4.9/3GPP TS 04.08: AUTHENTICATION AND CIPHERING REQUEST message content

### 9.4.9.1 Authentication Parameter RAND

This IE shall only be included if authentication shall be performed.

### 9.4.9.2 GPRS ciphering key sequence number

This IE is included if and only if the Authentication parameter RAND is contained in the message.

## 9.4.10 Authentication and ciphering response

This message is sent by the MS to the network in response to an *Authentication and ciphering request* message. See table 9.4.10/3GPP TS 04.08.

Message type: AUTHENTICATION AND CIPHERING RESPONSE

Significance: dual

Direction: MS to network

#### Table 9.4.10/3GPP TS 04.08: AUTHENTICATION AND CIPHERING RESPONSE message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip indicator	Skip indicator 10.3.1	М	V	1/2
-	Authentication and ciphering response message identity	GPRS message type 10.4	М	V	1
	A&C reference number	A&C reference number 10.5.5.19	М	V	1/2
	Spare half octet	Spare half octet 10.5.1.8	М	V	1/2
22	Authentication parameter SRES	Authentication parameter SRES 10.5.3.2	0	TV	5
23	IMEISV	Mobile identity 10.5.1.4	0	TLV	11

### 9.4.10.1 Authentication Parameter SRES

This IE is included if authentication was requested within the corresponding *authentication and ciphering request* message.

### 9.4.10.2 IMEISV

This IE is included if requested within the corresponding authentication and ciphering request message.

## 9.4.11 Authentication and ciphering reject

This message is sent by the network to the MS to indicate that authentication has failed (and that the receiving MS shall abort all activities). See table 9.4.11/3GPP TS 04.08.

Message type: AUTHENTICATION AND CIPHERING REJECT

Significance: dual

Direction: network to MS

#### Table 9.4.11/3GPP TS 04.08: AUTHENTICATION AND CIPHERING REJECT message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip indicator	Skip indicator 10.3.1	М	V	1/2
	Authentication and ciphering reject message identity	Message type 10.4	М	V	1

## 9.4.12 Identity request

This message is sent by the network to the MS to request submission of the MS identity according to the specified identity type. See table 9.4.12/3GPP TS 04.08.

Message type: IDENTITY REQUEST

Significance: dual

Direction: network to MS

#### Table 9.4.12/3GPP TS 04.08: IDENTITY REQUEST message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip indicator	Skip indicator 10.3.1	М	V	1/2
	Identity request message identity	Message type 10.4	М	V	1
	Identity type	Identity type 2 10.5.5.9	М	V	1/2
	Force to standby	Force to standby 10.5.5.7	М	V	1/2

## 9.4.13 Identity response

This message is sent by the MS to the network in response to an *identity request* message providing the requested identity. See table 9.4.13/3GPP TS 04.08.

Message type: IDENTITY RESPONSE

Significance: dual

Direction: MS to network

#### Table 9.4.13/3GPP TS 04.08: IDENTITY RESPONSE message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip indicator	Skip indicator 10.3.1	М	V	1/2
	Identity response message identity	Message type 10.4	М	V	1
	Mobile identity	Mobile identity 10.5.1.4	М	LV	4 - 10

## 9.4.14 Routing area update request

This message is sent by the MS to the network either to request an update of its location file or to request an IMSI attach for non-GPRS services. See table 9.4.14/3GPP TS 04.08.

Message type: ROUTING AREA UPDATE REQUEST

Significance: dual

Direction: MS to network

### Table 9.4.14/3GPP TS 04.08: ROUTING AREA UPDATE REQUEST message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip indicator	Skip indicator 10.3.1	М	V	1/2
	Routing area update request message identity	Message type 10.4	М	V	1
	Update type	Update type 10.5.5.18	М	V	1/2
	GPRS ciphering key sequence number	Ciphering key sequence number 10.5.1.2	М	V	1/2
	Old routing area identification	Routing area identification 10.5.5.15	М	V	6
	MS Radio Access capability	MS Radio Access capability 10.5.5.12a	М	LV	6 - 13
19	Old P-TMSI signature	P-TMSI signature 10.5.5.8	0	TV	4
17	Requested READY timer value	GPRS Timer 10.5.7.3	0	TV	2
27	DRX parameter	DRX parameter 10.5.5.6	0	TV	3
9-	TMSI status	TMSI status 10.5.5.4	0	TV	1
31	MS network capability	MS network capability 10.5.5.12	0	TLV	3-4

### 9.4.14.1 Old P-TMSI signature

This IE is included by the MS if it was received from the network in an ATTACH ACCEPT or ROUTING AREA UPDATE ACCEPT message.

## 9.4.14.2 Requested READY timer value

This IE may be included if the MS wants to indicate a preferred value for the READY timer.

### 9.4.14.3 DRX parameter

This IE may be included if the MS wants to indicate new DRX parameters.

### 9.4.14.4 TMSI status

This IE shall be included if the MS performs a combined routing area update and no valid TMSI is available.

### 9.4.14.5 MS network capability

This IE shall be included by the MS to indicate it's capabilities to the network, if the MS supports in addition to GEA/1 at least one of the GPRS Encryption Algorithm GEA/2 to GEA/7.

## 9.4.15 Routing area update accept

This message is sent by the network to the MS to provide the MS with GPRS mobility management related data in response to a *routing area update request* message . See table 9.4.15/3GPP TS 04.08.

Message type: routing area update accept

Significance: dual

Direction: network to MS

### Table 9.4.15/3GPP TS 04.08: ROUTING AREA UPDATE ACCEPT message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip indicator	Skip indicator 10.3.1	М	V	1/2
	Routing area update accept message identity	Message type 10.4	М	V	1
	Force to standby	Force to standby 10.5.5.7	М	V	1/2
	Update result	Update result 10.5.5.17	М	V	1/2
	Periodic RA update timer	GPRS Timer 10.5.7.3	М	V	1
	Routing area identification	Routing area identification 10.5.5.15	М	V	6
19	P-TMSI signature	P-TMSI signature 10.5.5.8	0	TV	4
18	Allocated P-TMSI	Mobile identity 10.5.1.4	0	TLV	7
23	MS identity	Mobile identity 10.5.1.4	0	TLV	7-10
26	List of Receive N-PDU Numbers	Receive N-PDU Number list 10.5.5.11	0	TLV	4 - 19
17	Negotiated READY timer value	GPRS Timer 10.5.7.3	0	TV	2
25	GMM cause	GMM cause 10.5.5.14	0	ΤV	2

### 9.4.15.1 P-TMSI signature

This IE may be included to assign an identity to the MS's GMM context.

### 9.4.15.2 Allocated P-TMSI

This IE may be included to assign a P-TMSI to an MS in case of a GPRS or combined routing area updating procedure.

### 9.4.15.3 MS identity

This IE may be included to assign or unassign a TMSI to a MS in case of a combined routing area updating procedure.

### 9.4.15.4 List of Receive N-PDU Numbers

This IE shall be included in case of an inter SGSN routing area updating, if there are PDP contexts that have been activated in acknowledged transfer mode.

### 9.4.15.5 Negotiated READY timer value

This IE may be included to indicate a value for the READY timer.

### 9.4.15.6 GMM cause

This IE shall be included if IMSI attach was not successful for non-GPRS services during a combined GPRS routing area updating procedure.

## 9.4.16 Routing area update complete

This message shall be sent by the MS to the network in response to a *routing area update accept message* if a P-TMSI and/or a TMSI has been assigned and/or if there are established LLC connections. See table 9.4.16/3GPP TS 04.08.

Message type: routing area update complete

Significance: dual

Direction: MS to network

#### Table 9.4.16/3GPP TS 04.08: ROUTING AREA UPDATE COMPLETE message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip indicator	Skip indicator 10.3.1	М	V	1/2
	Routing area update complete message identity	Message type 10.4	М	V	1
26	List of Receive N-PDU Numbers	Receive N-PDU Number list 10.5.5.11	0	TLV	4 - 19

### 9.4.16.1 List of Receive N-PDU Numbers

This IE shall be included if the routing area update accept message contained this IE.

## 9.4.17 Routing area update reject

This message is sent by the network to the MS in order to reject the routing area update procedure. See table 9.4.17/3GPP TS 04.08.

Message type:	routing area update reject
Significance:	dual
Direction:	network to MS

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip indicator	Skip indicator 10.3.1	М	V	1/2
	Routing area update reject message identity	Message type 10.4	М	V	1
	GMM cause	GMM cause 10.5.5.14	М	V	1
	Force to standby	Force to standby 10.5.5.7	М	V	1/2
	Spare half octet	Spare half octet 10.5.1.8	М	V	1/2

Table 9.4.17/3GPP TS 04.08: ROUTING AREA UPDATE REJECT message content

## 9.4.18 GMM Status

This message is sent by the MS or by the network at any time to report certain error conditions listed in clause 8. See table 9.4.18/3GPP TS 04.08.

Message type:	GMM STATUS
Significance:	local
Direction:	both

### Table 9.4.18/3GPP TS 04.08: GMM STATUS message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Skip indicator	Skip indicator 10.3.1	М	V	1/2
	GMM Status message identity	Message type 10.4	М	V	1
	GMM cause	GMM cause 10.5.5.14	М	V	1

## 9.4.19 GMM Information

This message is sent by the network at any time to sent certain information to the MS. See table 9.4.19/3GPP TS 04.08.

Message type: GMM INFORMATION

Significance: local

Direction: network to MS

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	M	V	1/2
	Skip indicator	Skip indicator 10.3.1	М	V	1/2
	GMM information message identity	Message type 10.4	M	V	1
43	Full name for network	Network name 10.5.3.5a	0	TLV	3 - ?
45	Short name for network	Network name 10.5.3.5a	0	TLV	3 - ?
46	Network time zone	Time zone 10.5.3.8	0	TV	2
47	Universal time and time zone	Time zone and time 10.5.3.9	0	TV	8
48	LSA Identity	LSA Identifier 10.5.3.11	0	TLV	2-5

Table 9.4.19/3GPP TS 04.08: GMM INFORMATION message content

## 9.4.19.1 Full name for network

This IE may be sent by the network. If this IE is sent, the contents of this IE indicate the "full length name of the network" that the network wishes the mobile station to associate with the MCC and MNC contained in the routing area identification of the current cell.

## 9.4.19.2 Short name for network

This IE may be sent by the network. If this IE is sent, the contents of this IE indicate the "abbreviated name of the network" that the network wishes the mobile station to associate with the MCC and MNC contained in the routing area identification of the cell the MS is currently in.

### 9.4.19.3 Network time zone

This IE may be sent by the network. The mobile station should assume that this time zone applies to the routing area of the cell the MS is currently in.

### 9.4.19.4 Universal time and time zone

This IE may be sent by the network. The mobile station should assume that this time zone applies to the routing area the MS is currently in. The mobile station shall not assume that the time information is accurate.

### 9.4.19.5 LSA Identity

This IE may be sent by the network. The contents of this IE indicate the LSA identity of the serving cell.

## 9.5 GPRS Session Management Messages

## 9.5.1 Activate PDP context request

This message is sent by the MS to the network to request activation of a PDP context. See table 9.5.1/3GPP TS 04.08.

Message type:	ACTIVATE PDP CONTEXT REQUEST
Significance:	global
Direction:	MS to network

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Activate PDP context request message identity	Message type 10.4	М	V	1
	Requested NSAPI	Network service access point identifier 10.5.6.2	М	V	1
	Requested LLC SAPI	LLC service access point identifier 10.5.6.9	М	V	1
	Requested QoS	Quality of service 10.5.6.5	М	LV	4
	Requested PDP address	Packet data protocol address 10.5.6.4	М	LV	3 - 19
28	Access point name	Access point name 10.5.6.1	0	TLV	3 - 102
27	Protocol configuration options	Protocol configuration options 10.5.6.3	0	TLV	3 - 253

#### Table 9.5.1/3GPP TS 04.08: ACTIVATE PDP CONTEXT REQUEST message content

### 9.5.1.1 Access point name

This IE is included in the message when the MS selects a specific external network to be connected to.

### 9.5.1.2 Protocol configuration options

This IE is included in the message when the MS provides protocol configuration options for the external PDN.

## 9.5.2 Activate PDP context accept

This message is sent by the network to the MS to acknowledge activation of a PDP context. See table 9.5.2/3GPP TS 04.08.

Message type: ACTIVATE PDP CONTEXT ACCEPT

Significance: global

Direction: network to MS

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier	М	V	1/2
		10.3.2			
	Activate PDP context accept message identity	Message type 10.4	М	V	1
	Negotiated LLC SAPI	LLC service access point identifier 10.5.6.9	М	V	1
	Negotiated QoS	Quality of service 10.5.6.5	М	LV	4
	Radio priority	Radio priority 10.5.7.2	М	V	1/2
	Spare half octet	Spare half octet 10.5.1.8	М	V	1/2
2B	PDP address	Packet data protocol address 10.5.6.4	0	TLV	4 - 20
27	Protocol configuration options	Protocol configuration options 10.5.6.3	0	TLV	3 - 253

Table 9.5.2/3GPP TS 04.08: ACTIVATE PDP CONTEXT ACCEPT message content

## 9.5.2.1 PDP address

If the MS did not request a static address in the corresponding ACTIVATE PDP CONTEXT REQUEST message, the network shall include the PDP address IE in this ACTIVATE PDP CONTEXT ACCEPT message.

If the MS requested a static address in the corresponding ACTIVATE PDP CONTEXT REQUEST message, the network shall not include the PDP address IE in this ACTIVATE PDP CONTEXT ACCEPT message.

## 9.5.2.2 Protocol configuration options

This IE is included in the message when the network wishes to transmit protocol configuration options for the external PDN.

# 9.5.3 Activate PDP context reject

This message is sent by the network to the MS to reject activation of a PDP context. See table 9.5.3/3GPP TS 04.08.

Message type: ACTIVATE PDP CONTEXT REJECT

Significance: global

Direction: network to MS

## Table 9.5.3/3GPP TS 04.08: ACTIVATE PDP CONTEXT REJECT message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier	М	V	1/2
	Activate PDP context reject message identity	Message type 10.4	M	V	1
	SM cause	SM Cause 10.5.6.6	М	V	1
27	Protocol configuration options	Protocol configuration options 10.5.6.3	0	TLV	3 - 253

## 9.5.3.1 Protocol configuration options

The protocol configuration options IE may only be inserted by the network (see 3GPP TS 09.60) if the SM Cause indicates "activation rejected by GGSN".

## 9.5.4 Request PDP context activation

This message is sent by the network to the MS to initiate activation of a PDP context. See table 9.5.4/3GPP TS 04.08.

Message type:REQUEST PDP CONTEXT ACTIVATIONSignificance:globalDirection:network to MS

#### Table 9.5.4/3GPP TS 04.08: REQUEST PDP CONTEXT ACTIVATION message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Request PDP context activation message identity	Message type 10.4	М	V	1
	Offered PDP address	Packet data protocol address 10.5.6.4	М	LV	3 - 19
28	Access point name	Access point name 10.5.6.1	0	TLV	3 – 102

# 9.5.5 Request PDP context activation reject

This message is sent by the MS to the network to reject initiation of a PDP context activation. See table 9.5.5/3GPP TS 04.08.

Message type: REQUEST PDP CONTEXT ACTIVATION REJECT

Significance: global

Direction: MS to network

#### Table 9.5.5/3GPP TS 04.08: REQUEST PDP CONTEXT ACTIVATION REJECT message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Request PDP context act. reject message identity	Message type 10.4	М	V	1
	SM cause	SM cause 10.5.6.6	М	V	1

## 9.5.6 Modify PDP context request

This message is sent by the network to the MS to request modification of an active PDP context. See table 9.5.6/3GPP TS 04.08.

Message type: MODIFY PDP CONTEXT REQUEST

Significance: global

Direction: network to MS

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Modify PDP context request message identity	Message type 10.4	М	V	1
	Radio priority	Radio priority 10.5.7.2	М	V	1/2
	Spare half octet	Spare half octet 10.5.1.8	М	V	1/2
	Requested LLC SAPI	LLC service access point identifier 10.5.6.9	М	V	1
	New QoS	Quality of service 10.5.6.5	М	LV	4

#### Table 9.5.6/3GPP TS 04.08: MODIFY PDP CONTEXT REQUEST message content

## 9.5.7 Modify PDP context accept

This message is sent by the MS to the network to acknowledge the modification of an active PDP context. See table 9.5.7/3GPP TS 04.08.

Message type: MODIFY PDP CONTEXT ACCEPT

Significance: global

Direction: MS to network

#### Table 9.5.7/3GPP TS 04.08: MODIFY PDP CONTEXT ACCEPT message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Modify PDP context accept message identity	Message type 10.4	М	V	1

## 9.5.8 Deactivate PDP context request

This message is sent to request deactivation of an active PDP context. See table 9.5.8/3GPP TS 04.08.

Message type: DEACTIVATE PDP CONTEXT REQUEST

Significance: global

Direction: both

## Table 9.5.8/3GPP TS 04.08: DEACTIVATE PDP CONTEXT REQUEST message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Deactivate PDP context request message identity	Message type 10.4	М	V	1
	SM cause	SM cause 10.5.6.6	М	V	1

## 9.5.9 Deactivate PDP context accept

This message is sent to acknowledge deactivation of the PDP context requested in the corresponding *Deactivate PDP context request* message. See table 9.5.9/3GPP TS 04.08.

Message type: DEACTIVATE PDP CONTEXT ACCEPT

Significance: global

Direction: both

#### Table 9.5.9/3GPP TS 04.08: DEACTIVATE PDP CONTEXT ACCEPT message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator	М	V	1/2
		10.2			
	Transaction identifier	Transaction identifier	М	V	1/2
		10.3.2			
	Deactivate PDP context accept	Message type	М	V	1
	message identity	10.4			

## 9.5.10 Activate AA PDP context request

This message is sent by the MS to the network to initiate activation of an AA PDP context. See table 9.5.10/3GPP TS 04.08.

Message type: ACTIVATE AA PDP CONTEXT REQUEST

Significance: global

Direction: MS to network

#### Table 9.5.10/3GPP TS 04.08: ACTIVATE AA PDP CONTEXT REQUEST message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Activate AA PDP context request message identity	Message type 10.4	М	V	1
	Requested NSAPI	Network service access point identifier 10.5.6.2	М	V	1
	Requested LLC SAPI	LLC service access point identifier 10.5.6.9	М	V	1
	Requested QoS	Quality of service 10.5.6. 5	М	LV	4
	Requested packet data protocol address	Packet data protocol address 10.5.6.4	М	LV	3 - 19
28	Access point name	Access point name 10.5.6.1	0	TLV	3 - 102
27	Protocol configuration options	Protocol configuration options 10.5.6.3	0	TLV	3 - 253
29	Requested AA-READY timer value	GPRS Timer 10.5.7.3	0	TV	2

## 9.5.10.1 Access point name

This IE is included in the message when the MS selects a specific external network to be connected to.

## 9.5.10.2 Protocol configuration options

This IE is included in the message when the MS provides protocol configuration options for the external PDN.

## 9.5.10.3 Requested AA-READY timer value

This IE may be included if the MS wants to indicate a preferred value for the AA-READY timer.

## 9.5.11 Activate AA PDP context accept

This message is sent by the network to the MS to acknowledge the activation of an AA PDP context. See table 9.5.11/3GPP TS 04.08.

Message type: ACTIVATE AA PDP CONTEXT ACCEPT

Significance: global

Direction: network to MS

## Table 9.5.11/3GPP TS 04.08: ACTIVATE AA PDP CONTEXT ACCEPT message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Activate AA PDP context accept message identity	Message type 10.4	М	V	1
	Negotiated LLC SAPI	LLC service access point identifier 10.5.6.9	М	V	1
	Negotiated QoS	Quality of service 10.5.6.5	М	LV	4
	Allocated P-TMSI	Mobile identity 10.5.1.4	М	LV	6
	Packet data protocol address	Packet data protocol address 10.5.6.4	М	LV	3 - 19
	Radio priority	Radio priority 10.5.7.2	М	V	1/2
	Spare half octet	Spare half octet 10.5.1.8	М	V	1/2
27	Protocol configuration options	Protocol configuration options 10.5.6.3	0	TLV	3 - 253
29	Negotiated AA-Ready timer value	GPRS Timer 10.5.7.3	0	TV	2

## 9.5.11.1 Protocol configuration options

This IE may be included if the network wishes to transmit protocol configuration options from the external PDN.

## 9.5.11.2 Negotiated AA-Ready timer value

This IE may be included if the network wants to indicate a value for the AA-READY timer.

## 9.5.12 Activate AA PDP context reject

This message is sent by the network to the MS to reject the activation of an AA PDP context. See table 9.5.12/3GPP TS 04.08.

Message type: ACTIVATE AA PDP CONTEXT REJECT

Significance: global

Direction: network to MS

#### Table 9.5.12/3GPP TS 04.08: ACTIVATE AA PDP CONTEXT REJECT message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Activate AA PDP context reject message identity	Message type 10.4	М	V	1
	SM Cause	SM Cause 10.5.6.6	М	V	1
27	Protocol configuration options	Protocol configuration options 10.5.6.3	0	TLV	3 - 253

## 9.5.12.1 Protocol configuration options

The protocol configuration options IE may only be inserted by the network (see 3GPP TS 09.60) if the SM Cause indicates "activation rejected by GGSN".

## 9.5.13 Deactivate AA PDP context request

This message is sent to request deactivation of an active AA PDP context. See table 9.5.13/3GPP TS 04.08.

Message type: DEACTIVATE AA PDP CONTEXT REQUEST

Significance: global

Direction: network to MS

#### Table 9.5.13/3GPP TS 04.08: DEACTIVATE AA PDP CONTEXT REQUEST message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Deactivate AA PDP context request message identity	Message type 10.4	М	V	1
	AA deactivation cause	AA deactivation cause 10.5.6.8	М	V	1/2
	Spare half octet	Spare half octet 10.5.1.8	М	V	1/2

## 9.5.14 Deactivate AA PDP context accept

This message is sent to acknowledge deactivation of an AA PDP context requested by the corresponding *Deactivate AA PDP context request* message. See table 9.5.14/3GPP TS 04.08.

Message type: DEACTIVATE AA PDP CONTEXT ACCEPT

Significance: global

Direction: MS to network

Table 9.5.14/3GPP TS 04.08: DEACTIVATE AA PDP CONTEXT ACCEPT message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	Deactivate AA PDP context accept message identity	Message type 10.4	М	V	1

## 9.5.15 SM Status

This message is sent by the network or the MS to pass information on the status of the indicated context and report certain error conditions (eg. as listed in sub-clause 8). See table 9.5.15/3GPP TS 04.08.

Message type: SM Status

Significance: local

Direction: both

#### Table 9.5.15/3GPP TS 04.08: SM STATUS message content

IEI	Information Element	Type/Reference	Presence	Format	Length
	Protocol discriminator	Protocol discriminator 10.2	М	V	1/2
	Transaction identifier	Transaction identifier 10.3.2	М	V	1/2
	SM Status message identity	Message type 10.4	М	V	1
	SM Cause	SM Cause 10.5.6.6	М	V	1

# 10 General message format and information elements coding

The figures and text in this sub-clause describe the Information Elements contents.

# 10.1 Overview

Within the Layer 3 protocols defined in 3GPP TS 04.08, every message with the exception of the messages sent on the BCCH, downlink CCCH, SCH, RACH, and the HANDOVER ACCESS message, is a standard L3 message as defined in 3GPP TS 04.07 [20]. This means that the message consists of the following parts:

- a) protocol discriminator;
- b) transaction identifier;
- c) message type;
- d) other information elements, as required.

This organization is illustrated in the example shown in figure 10.1/3GPP TS 04.08.

	8	7	б	5	4	3	2	1	
	Transac or Ski		identi dicator		Proto	ocol d	iscrim	inator	octet 1
Ţ			Mes	sage 1	type				octet 2
+	Oth	er in	nformat	ion e	lements	s as r	equire	d +	etc

#### Figure 10.1/3GPP TS 04.08: General message organization example

Unless specified otherwise in the message descriptions of sub-clause 9, a particular information element shall not be present more than once in a given message.

The term "default" implies that the value defined shall be used in the absence of any assignment, or that this value allows negotiation of alternative values in between the two peer entities.

When a field extends over more than one octet, the order of bit values progressively decreases as the octet number increases. The least significant bit of the field is represented by the lowest numbered bit of the highest numbered octet of the field.

# 10.2 Protocol Discriminator

The Protocol Discriminator (PD) and its use are defined in 3GPP TS 04.07 [20]. 3GPP TS 04.08 defines the protocols relating to the PD values:

#### bits 4321

- 0011 Call Control; call related SS messages
- 0101 Mobility Management messages for non-GPRS services
- 0 1 1 0 Radio Resource management messages
- 1000 Mobility Management messages for GPRS services
- 1010 Session Management messages

except the call related SS procedures, which are defined in 3GPP TS 04.10.

# 10.3 Skip indicator and transaction identifier

## 10.3.1 Skip indicator

Bits 5 to 8 of the first octet of every Radio Resource management message and Mobility Management message and GPRS MobilityManagement message contains the skip indicator. A message received with skip indicator different from 0000 shall be ignored. A message received with skip indicator encoded as 0000 shall not be ignored (unless it is ignored for other reasons). A protocol entity sending a Radio Resource management message or a Mobility Management message shall encode the skip indicator as 0000.

## 10.3.2 Transaction identifier

Bits 5 to 8 of the first octet of every message belonging to the protocols "Call Control; call related SS messages" and "Session Management" contain the transaction identifier (TI). The transaction identifier and its use are defined in 3GPP TS 04.07 [20].

# 10.4 Message Type

The message type IE and its use are defined in 3GPP TS 04.07 [20]. Tables 10.3/3GPP TS 04.08, 10.4/3GPP TS 04.08, and 10.4a/3GPP TS 04.08 define the value part of the message type IE used in the Radio Resource management protocol, the Mobility Management protocol, the Call Control protocol, and Session management protocol.

Table 10.1/3GPP TS 04.08 (page 1 of 2): Message types for Radio Resource management

8	7	6	5	4	3	2	1	
0	0	1	1	1	1 0 1	- 0 1 0 1	1	Channel establishment messages: - RR INITIALISATION REQUEST - ADDITIONAL ASSIGNMENT - IMMEDIATE ASSIGNMENT - IMMEDIATE ASSIGNMENT EXTENDED - IMMEDIATE ASSIGNMENT REJECT
0	0	1	1	0	- 1 0	0	- 1 0	Ciphering messages: - CIPHERING MODE COMMAND - CIPHERING MODE COMPLETE
0	0	1	1	0		- 0 0 1		Configuration change messages: - CONFIGURATION CHANGE COMMAND - CONFIGURATION CHANGE ACK. - CONFIGURATION CHANGE REJECT
0	0	1	0	1	0 1 0 1	1 0 1 1 0 0	1 1 0	Handover messages: - ASSIGNMENT COMMAND - ASSIGNMENT COMPLETE - ASSIGNMENT FAILURE - HANDOVER COMMAND - HANDOVER COMPLETE - HANDOVER FAILURE - PHYSICAL INFORMATION
0 0	0 0	0 1	0 0	1 0	0 0	0 1	0 1	- RR-CELL CHANGE ORDER - PDCH ASSIGNMENT COMMAND
0	0	0	0	1	1	0 1		Channel release messages: - CHANNEL RELEASE - PARTIAL RELEASE - PARTIAL RELEASE COMPLETE
0	0	1	0	0	0 0 1 0 1 1	1 0 1 0	1 0 1	Paging and Notification messages: - PAGING REQUEST TYPE 1 - PAGING REQUEST TYPE 2 - PAGING REQUEST TYPE 3 - PAGING RESPONSE - NOTIFICATION/NCH - NOTIFICATION/FACCH - NOTIFICATION RESPONSE - Reserved (see NOTE)
0	0	0	1	1	-00001111	-00110011	- 0 1 0 1 0 1 0 1	System information messages: - SYSTEM INFORMATION TYPE 8 - SYSTEM INFORMATION TYPE 1 - SYSTEM INFORMATION TYPE 2 - SYSTEM INFORMATION TYPE 3 - SYSTEM INFORMATION TYPE 4 - SYSTEM INFORMATION TYPE 5 - SYSTEM INFORMATION TYPE 6 - SYSTEM INFORMATION TYPE 7
0	0	0	0	0	- 0 1 1 0	- 1 0 1 0 0	- 0 1 0 0 0	System information messages: - SYSTEM INFORMATION TYPE 2bis - SYSTEM INFORMATION TYPE 2ter - SYSTEM INFORMATION TYPE 5bis - SYSTEM INFORMATION TYPE 5ter - SYSTEM INFORMATION TYPE 9 - SYSTEM INFORMATION TYPE 13
0	0	1	1	1		- 0 1	- 1 0	System information messages: - SYSTEM INFORMATION TYPE 16 - SYSTEM INFORMATION TYPE 17
_	-	0	1	-	-00111101	-01100111	- 0 1 0 1 0 1 0	Miscellaneous messages: - CHANNEL MODE MODIFY - RR STATUS - CHANNEL MODE MODIFY ACKNOWLEDGE - FREQUENCY REDEFINITION - MEASUREMENT REPORT - CLASSMARK CHANGE - CLASSMARK ENQUIRY - EXTENDED MEASUREMENT REPORT

	0 0 0 0	) 1 ) 1	1 1	0 0	1 1	1 0	1 0	- EXTENDED MEASUREMENT ORDER - GPRS SUSPENSION REQUEST
								VGCS uplink control messages:
	000	) 0 ) 0 ) 1	0 0 0	1 1 1	1 1 0	1 0 1	0 0 0	<ul> <li>VGCS UPLINK GRANT</li> <li>UPLINK RELEASE</li> <li>UPLINK FREE</li> <li>UPLINK BUSY</li> <li>TALKER INDICATION</li> </ul>
								Application messages:
	0 0	) 1	1	1	0	0	0	- Application Information

NOTE: This value was allocated but never used in earlier phases of the protocol.

Bit 8 is reserved for possible future use as an extension bit, see 3GPP TS 04.07.

Table 10.1a/3GPP TS 04.08: Message types for Radio Resource management messages using the RR short protocol discriminator

4						
Ì	5	4	3	2	1	
	Ō	0 0 0	Ō	Ō	ĩ	SYSTEM INFORMATION TYPE 10 NOTIFICATION/FACCH UPLINK FREE
-						

+-----+



	8	7	6	5	4	3	2	1	
	0	x	0	0	- 0 0 1	1	0 1 0	- 1 0 0 0	Registration messages: - IMSI DETACH INDICATION - LOCATION UPDATING ACCEPT - LOCATION UPDATING REJECT - LOCATION UPDATING REQUEST
	0	x	0	1	0 0 1 1	0 1 0 0 0	1 0 0 0 1	0 0 1 0	Security messages: - AUTHENTICATION REJECT - AUTHENTICATION REQUEST - AUTHENTICATION RESPONSE - IDENTITY REQUEST - IDENTITY RESPONSE - TMSI REALLOCATION COMMAND - TMSI REALLOCATION COMPLETE
	0	x	1	0	0	0	0 1	1	Connection management messages: - CM SERVICE ACCEPT - CM SERVICE REJECT - CM SERVICE ABORT - CM SERVICE REQUEST - CM SERVICE PROMPT - Reserved (see NOTE) - CM RE-ESTABLISHMENT REQUEST - ABORT
+-	0	x	1	1	0	0 0	0 0	0	- MM STATUS

NOTE: This value was allocated but never used in earlier phases of the protocol.

Bit 8 is reserved for possible future use as an extension bit, see 3GPP TS 04.07.

Bit 7 is reserved for the send sequence number in messages sent from the mobile station. In messages sent from the network, bit 7 is coded with a "0". See 3GPP TS 04.07.

Table 10.3/3GPP TS 04.08: Message types for Call Control and call related SS messages

87654321 escape to nationally specific message types ; see 1) below  $0 \times 0 0 0 0 0 0$ 0 x 0 0 Call establishment messages: \_ - ALERTING - CALL CONFIRMED 0 001 1 0 0 0 0 0 1 0 - CALL PROCEEDING 0 - CONNECT 1 1 1 CONNECT ACKNOWLEDGEEMERGENCY SETUP  $\begin{array}{ccc}1&1&1\\1&1&0\end{array}$ 1 1 0 - PROGRESS 0 1 1 0 1 0 0 - CC-ESTABLISHMENT - CC-ESTABLISHMENT CONFIRMED 0 1 1 0 - RECALL - START CC - SETUP 1 1 0 1 1 1 0 0 0 1 0 1 0 x 0 1 \_ \_ \_ \_ Call information phase messages: - MODIFY - MODIFY COMPLETE 0 1 1 1 1 0 1 1 1 - MODIFY REJECT 0 1 1 0 0 0 1 0 0 - USER INFORMATION - HOLD 0 0 1 0 0 1 - HOLD ACKNOWLEDGE 1 0 1 0 - HOLD REJECT 1 1 0 0 - RETRIEVE 0 1 1 - RETRIEVE ACKNOWLEDGE 1 1 ī ĩ Ō - RETRIEVE REJECT \_ \_ - -0 x 1 0 Call clearing messages: 0 1 0 1 - DISCONNECT 0 1 - RELEASE - RELEASE COMPLETE \_ \_ \_ \_ 0 x 1 1 Miscellaneous messages: - CONGESTION CONTROL 1 0 0 1 1 1 1 0 - NOTIFY 1 1 0 0 1 - STATUS 1 1 0 0 - STATUS ENQUIRY 0 0 1 - START DTMF Ō 0 - STOP DTMF 0 1 Ō 0 1 0 - STOP DTMF ACKNOWLEDGE \_ START DTMF ACKNOWLEDGE START DTMF REJECT 0 1 1 0 0 1 1 1 \_ 0 1 0 - FACILITY 1

1): When used, the message type is defined in the following octet(s), according to the national specification.

Bit 8 is reserved for possible future use as an extension bit, see 3GPP TS 04.07.

Bit 7 is reserved for the send sequence number in messages sent from the mobile station. In messages sent from the network, bit 7 is coded with a "0". See 3GPP TS 04.07.

Table 10.4/3GPP TS 04.08: Message types for GPRS mobility management

```
Bits
87654321
0 0 - - - - - -
                    Mobility management messages
  0 0 0 0 0 0 1
0
                    Attach request
             1 0
                    Attach accept
0
  0
    0
      0
         0
           0
0
  0
    0
      0
         0
           0
             1
                1
                    Attach complete
0
  0
    0 0 0 1 0 0
                    Attach reject
0
0
  Detach request
             1 0
                   Detach accept
0
  0
    0
      0
         1
           0 0 0
                   Routing area update request
                    Routing area update accept
        1 0 0 1
0
  0
    0
      0
    1 0
1 1
0
  0
                    Routing area update complete
0
  0
                   Routing area update reject
                   P-TMSI reallocation command
P-TMSI reallocation complete
0
  0
    0
      1
         0
           0
             0
                0
0
      1
         0
  0
    0
           0 0 1
             \begin{array}{c}1&\overline{0}\\1&1\end{array}
0
  0
    0
      1
1
         0
           0
                   Authentication and ciphering req
0
  0
    0
         0
           0
                    Authentication and ciphering resp
      1
1
1
           1
1
0
  0
    0
         0
             0
                0
                    Authentication and ciphering rej
                    Identity request
Identity response
0
  0
    0
         0
             0
                1
      1
0
  0
    0
         0
           1
                0
             1
      0 0 0 0 0
0
  0
    1
                    GMM status
    1
0
  0
      0
         0
           0 0
                1
                    GMM information
```

Table 10.4a/3GPP TS 04.08: Message types for GPRS session management

```
Bits
87654321
0 1 - - - - - -
                Session management messages
 1 0 0 0 0 0 1
                Activate PDP context request
Ω
0
 1 0 0 0 0 1 0
                Activate PDP context accept
 1 0 0 0 0 1 1
0
                Activate PDP context reject
 1 0 0 0 1 0 0
                Request PDP context activation
0
 1000101
Ω
                Request PDP context activation rej.
0 1 0 0 0 1 1 0
                Deactivate PDP context request
0 1 0 0 0 1 1 1
                Deactivate PDP context accept
 1 0 0 1 0 0 0
                Modify PDP context request
Ω
0 1 0 0 1 0 0 1
                Modify PDP context accept
0 1 0 1 0 0 0 0
                Activate AA PDP context request
 0
                Activate AA PDP context accept
0
                Activate AA PDP context reject
0
 1 0 1 0 0 1 1
                Deactivate AA PDP context request
 1 0 1 0 1 0 0
                Deactivate AA PDP context accept
0
 1 0 1 0 1 0 1
                SM Status
0
```

## 10.5 Other information elements

The different formats (V, LV, T, TV, TLV) and the four categories of information elements (type 1, 2, 3, and 4) are defined in 3GPP TS 04.07.

The first octet of an information element in the non-imperative part contains the IEI of the information element. If this octet does not correspond to an IEI known in the message, the receiver shall determine whether this IE is of type 1 or 2 (i.e. it is an information element of one octet length) or an IE of type 4 (i.e. that the next octet is the length indicator indicating the length of the remaining of the information element) (see 3GPP TS 04.07).

This allows the receiver to jump over unknown information elements and to analyse any following information elements.

The information elements which are common for at least two of the three protocols Radio Resources management, Mobility Management and Call Control, are listed in sub-clause 10.5.1.

The information elements for the protocols Radio Resources management, Mobility Management and Call Control are listed in sub-clauses 10.5.2, 10.5.3 and 10.5.4 respectively. Default information element identifiers are listed in annex K.

NOTE: Different information elements may have the same default information element identifier if they belong to different protocols.

The descriptions of the information element types in sub-clauses 10.5.1, 10.5.2, 10.5.3, and 10.5.4 are organized in alphabetical order of the IE types. Each IE type is described in one sub-clause.

The sub-clause may have an introduction:

- possibly explaining the purpose of the IE;
- possibly describing whether the IE belongs to type 1, 2, 3, 4 or 5;
- possibly indicating the length that the information element has if it is either type 5 or if it is used in format TV (type 1 and 3) or TLV (type 4).

A figure of the sub-clause defines the structure of the IE indicating:

- possibly the position and length of the IEI. (However it depends on the message in which the IE occurs whether the IE contains an IEI.);
- the fields the IE value part is composed of;
- possibly the position and length of the length indicator. (However it depends on the IE type whether the IE contains a length indicator or not.);
- possibly octet numbers of the octets that compose the IE (see sub-clause a) below).

Finally, the sub-clause contains tables defining the structure and value range of the fields that compose the IE value part. The order of appearance for information elements in a message is defined in sub-clause 9.

The order of the information elements within the imperative part of messages has been chosen so that information elements with 1/2 octet of content (type 1) go together in succession. The first type 1 information element occupies bits 1 to 4 of octet N, the second bits 5 to 8 of octet N, the third bits 1 to 4 of octet N + 1 etc. If the number of type 1 information elements is odd then bits 5 to 8 of the last octet occupied by these information elements contains a spare half octet IE in format V.

Where the description of information elements in the present document contains bits defined to be "spare bits", these bits shall set to the indicated value (0 or 1) by the sending side, and their value shall be ignored by the receiving side. With few exceptions, spare bits are indicated as being set to "0" in 3GPP TS 04.08.

The following rules apply for the coding of type 4 information elements:

- a) The octet number of an octet (which is defined in the figure of a sub-clause) consists of a positive integer, possibly of an additional letter, and possibly of an additional asterisk, see sub-clause f). The positive integer identifies one octet or a group of octets.
- b) Each octet group is a self contained entity. The internal structure of an octet group may be defined in alternative ways.
- c) An octet group is formed by using some extension mechanism. The preferred extension mechanism is to extend an octet (N) through the next octet(s) (Na, Nb, etc.) by using bit 8 in each octet as an extension bit.

The bit value "0" indicates that the octet group continues through to the next octet. The bit value "1" indicates that this octet is the last octet of the group. If one octet (Nb) is present, the preceding octets (N and Na) shall also be present.

In the format descriptions appearing in sub-clauses 10.5.1 to 10.5.4, bit 8 is marked "0/1 ext" if another octet follows. Bit 8 is marked "1 ext" if this is the last octet in the extension domain.

Additional octets may be defined in later versions of the protocols ("1 ext" changed to "0/1 ext") and equipments shall be prepared to receive such additional octets; the contents of these octets shall be ignored. However the length indicated in clauses 9 and 10 only takes into account this version of the protocols.

- d) In addition to the extension mechanism defined above, an octet (N) may be extended through the next octet(s) (N+1, N+2 etc.) by indications in bits 7-1 (of octet N).
- e) The mechanisms in c) and d) may be combined.
- f) Optional octets are marked with asterisks (\*).

## 10.5.1 Common information elements

## 10.5.1.1 Cell identity

The purpose of the Cell Identity information element is to identify a cell within a location area.

The *Cell Identity* information element is coded as shown in figure 10.5.1/3GPP TS 04.08 and table 10.5.1/3GPP TS 04.08.

The Cell Identity is a type 3 information element with 3 octets length.

	8	7	б	5	4	3	2	1		
+	 		Cel	l Ider	ntity 1	 [E] 			octet	1
+			CI	value					octet	2
+			CI val	ue (co	ontinue	ed)			octet	3

#### Figure 10.5.1/3GPP TS 04.08: Cell Identity information element

Table 10.5.1/3GPP TS 04.08: Cell Identity information element

CI value, Cell identity value (octet 2 and 3) In the CI value field bit 8 of octet 2 is the most significant bit and bit 1 of octet 3 the least significant bit. The coding of the cell identity is the responsibility of each administration. Coding using full hexadecimal representation may be used. The cell identity consists of 2 octets.

## 10.5.1.2 Ciphering Key Sequence Number

The purpose of the *Ciphering Key Sequence Number* information element is to make it possible for the network to identify the ciphering key Kc which is stored in the mobile station without invoking the authentication procedure. The ciphering key sequence number is allocated by the network and sent with the AUTHENTICATION REQUEST message to the mobile station where it is stored together with the calculated ciphering key Kc.

The *Ciphering Key Sequence Number* information element is coded as shown in figure 10.5.2/3GPP TS 04.08 and table 10.5.2/3GPP TS 04.08.

The ciphering key sequence number is a type 1 information element.

<b>.</b>	8	7	6	5	4	3	2	1	<b>т</b>	
		Cipher Sequen	ing Ke ce Nun IEI	≥y nber	0 spare	key	sequei	nce	octet	1

Figure 10.5.2/3GPP TS 04.08: Ciphering Key Sequence Number information element

Table 10.5.2/3GPP TS 04.08: Ciphering Key Sequence Number information element

```
Key sequence (octet 1)
Bits
3 2 1
0 0 0
through Possible values for the ciphering key
1 1 0 sequence number
1 1 1 No key is available (MS to network);
Reserved (network to MS)
```

## 10.5.1.3 Location Area Identification

The purpose of the *Location Area Identification* information element is to provide an unambiguous identification of location areas within the area covered by the GSM system.

The *Location Area Identification* information element is coded as shown in figure 10.5.3/3GPP TS 04.08 and table 10.5.3/3GPP TS 04.08.

The Location Area Identification is a type 3 information element with 6 octets length.




Figure 10.5.3/3GPP TS 04.08: Location Area Identification information element

Table 10.5.3/3GPP TS 04.08: Location Area Identification information element

MCC, Mobile country code (octet 2 and 3) The MCC field is coded as in ITU-T Rec. E212, Annex A. If the LAI is deleted the MCC and MNC shall take the value from the deleted LAI. In abnormal cases, the MCC stored in the mobile station can contain elements not in the set {0, 1 ... 9}. In such cases the mobile station should transmit the stored values using full hexadecimal encoding. When receiving such an MCC, the network shall treat the LAI as deleted. MNC, Mobile network code (octet 3 bits 5 to 8, octet 4) The coding of this field is the responsibility of each administration but BCD coding shall be used. The MNC shall consist of 2 or 3 digits. For PCS 1900 for NA, Federal regulation mandates that a 3-digit MNC shall be used. However a network operator may decide to use only two digits in the MNC in the LAI over the radio interface. In this case, bits 5 to 8 of octet 3 shall be coded as "1111". Mobile equipment shall accept LAI coded in such a way. Note 1: In earlier versions of this protocol, the possibility to use a one digit MNC in LAI was provided on the radio interface. However as this was not used this possibility has been deleted. Note 2: In earlier versions of this protocol, bits 5 to 8 of octet 3 were coded as "1111". Mobile equipment compliant with these earlier versions of the protocol may be unable to understand the 3-digit MNC format of the LAI, and therefore unable to register on a network broadcasting the LAI in this format. In abnormal cases, the MNC stored in the mobile station can have - digit 1 or 2 not in the set {0, 1 ... 9}, or - digit 3 not in the set {0, 1 ...9, F} hex. In such cases the mobile station shall transmit the stored values using full hexadecimal encoding. When receiving such an MNC, the network shall treat the LAI as deleted. The same handling shall apply for the network, if a 3-digit MNC is sent by the mobile station to a network using only a 2-digit MNC. LAC, Location area code (octet 5 and 6) In the LAC field bit 8 of octet 5 is the most significant bit and bit 1 of octet 6 the least significant bit. The coding of the location area code is responsibility of each administration except that is the two values are used to mark the LAC, and hence the LAI, as deleted. Coding using full hexadecimal representation may be used. The location area code consists of 2 octets. If a LAI has to be deleted then all bits of the location area code shall be set to one with the exception of the least significant bit which shall be set to zero. If a SIM is inserted in a Mobile Equipment with the location area code containing all zeros, then the Mobile Equipment shall recognise this LAC as part of a deleted LAI

#### 10.5.1.4 Mobile Identity

The purpose of the *Mobile Identity* information element is to provide either the international mobile subscriber identity, IMSI, the temporary mobile subscriber identity, TMSI/P-TMSI, the international mobile equipment identity, IMEI or the international mobile equipment identity together with the software version number, IMEISV.

The IMSI shall not exceed 15 digits, the TMSI/P-TMSI is 4 octets long, and the IMEI is composed of 15 digits, the IMEISV is 16 digits (see 3GPP TS 03.03).

For packet paging the network shall select the mobile identity type with the following priority:

- 1) P-TMSI: The P-TMSI shall be used if it is available.
- 2) IMSI: The IMSI shall be used in cases where no P-TMSI is available.

For all other transactions except emergency call establishment, emergency call re-establishment, mobile terminated call establishment, the identification procedure, the GMM identification procedure, the GMM authentication and ciphering procedure and the ciphering mode setting procedure, the mobile station and the network shall select the mobile identity type with the following priority:

- 1) TMSI: The TMSI shall be used if it is available.
- 2) IMSI: The IMSI shall be used in cases where no TMSI is available.

For mobile terminated call establishment the mobile station shall select the same mobile identity type as received from the network in the PAGING REQUEST message.

For emergency call establishment and re-establishment the mobile station shall select the mobile identity type with the following priority:

- 1) TMSI: The TMSI shall be used if it is available.
- 2) IMSI: The IMSI shall be used in cases where no TMSI is available.
- 3) IMEI: The IMEI shall be used in cases where no SIM is available or the SIM is considered as not valid by the mobile station or no IMSI or TMSI is available.

In the identification procedure and in the GMM identification procedure the mobile station shall select the mobile identity type which was requested by the network.

In the ciphering mode setting procedure and in the GMM authentication and ciphering procedure the mobile shall select the IMEISV.

The *Mobile Identity* information element is coded as shown in figure 10.5.4/3GPP TS 04.08 and table 10.5.4/3GPP TS 04.08.

The *Mobile Identity* is a type 4 information element with a minimum length of 3 octet and 11 octets length maximal. Further restriction on the length may be applied, e.g. number plans.

	8	7	6	5	4	3	2	2	1		
+		 	Mobile	Idei	ntity 1	EI				octet	1
+	]	Length	of mobi	le io	dentity	conte	nts	3		octet	2
	Ide	entity	digit 1		odd/ even indic	Туре	of	iden	tity	octet	3
+	Ide	entity	digit p	+1	Ide	entity	die	git p	+	octet	4*

Figure 10.5.4/3GPP TS 04.08: Mobile Identity information element

Table 10.5.4/3GPP TS 04.08: Mobile Identity information element

```
Type of identity (octet 3)
Bits
3 2 1
0 0 1
               IMSI
0 1 0
               IMEI
0 1 1
               IMEISV
1 0 0
              TMSI/P-TMSI
0 0 0
              No Identity
                                    (note)
All other values are reserved.
Odd/even indication (octet 3)
Bit
4
              even number of identity digits and also when the \ensuremath{\mathsf{TMSI/P}\text{-}\mathsf{TMSI}} is used
0
1
              odd number of identity digits
Identity digits (octet 3 etc)
For the IMSI, IMEI and IMEISV this field is coded using
BCD coding. If the number of identity digits is even
then bits 5 to 8 of the last octet shall be filled
with an end mark coded as "1111".
If the mobile identity is the TMSI/P-TMSI then bits 5 to 8 of octet 3 are coded as "1111" and bit 8 of octet 4 is the most significant bit and bit 1 of the last
octet the least significant bit. The coding of the
TMSI/P-TMSI is left open for each administration.
                                                                                   ____+
```

NOTE: This can be used in the case when a fill paging message without any valid identity has to be sent on the paging subchannel.

## 10.5.1.5 Mobile Station Classmark 1

The purpose of the *Mobile Station Classmark 1* information element is to provide the network with information concerning aspects of high priority of the mobile station equipment. This affects the manner in which the network handles the operation of the mobile station. The Mobile Station Classmark information indicates general mobile station characteristics and it shall therefore, except for fields explicitly indicated, be independent of the frequency band of the channel it is sent on.

The *Mobile Station Classmark 1* information element is coded as shown in figure 10.5.5/3GPP TS 04.08 and table 10.5.5/3GPP TS 04.08.

The Mobile Station Classmark 1 is a type 3 information element with 2 octets length.

8	7	6	5	4	3	2	1		
Ĭ		Mobil	e Stati	ion Cla	ssmark	: 1 IEI	[	octet	1
0   spar		sion rel	ES IND	A5/1	R Cap	RF powe abilit	er Sy	octet	2

Figure 10.5.5/3GPP TS 04.08: Mobile Station Classmark 1 information element

#### Table 10.5.5/3GPP TS 04.08: Mobile Station Classmark 1 information element

Revision level (octet 2)
Bits <b>7 6</b> 0 0 Reserved for phase 1 0 1 Used by phase 2 mobile stations
All other values are reserved for future use. If the network receives a revision level specified as 'reserved for future use', then it shall use the highest revision level supported by the network.
ES IND (octet 2, bit 5) "Controlled Early Classmark Sending" option implementation
0 "Controlled Early Classmark Sending" option is not implemented in the MS
1 "Controlled Early Classmark Sending" option is implemented in the MS
NOTE: The value of the ES IND gives the implementation in the MS. It's value is <b>not</b> dependent on the broadcast SI 3 Rest Octet <early classmark="" control="" sending=""> value.</early>
A5/1 algorithm supported (octet 2, bit 4)
<ul> <li>0 encryption algorithm A5/1 available</li> <li>1 encryption algorithm A5/1 not available</li> </ul>
RF power capability (octet 2)
When the GSM P, E [or R] 900 MHz band is used (for exceptions see 3.4.18): Bits <b>3 2 1</b>
0 0 0 class 1 0 0 1 class 2 0 1 0 class 3
0 1 1 class 4 1 0 0 class 5
All other values are reserved.
When the DCS 1800 or PCS 1900 band is used (for exceptions see 3.4.18): Bits <b>3 2 1</b>
0 0 0 class 1
0 0 1 class 2 0 1 0 class 3
All other values are reserved.

## 10.5.1.6 Mobile Station Classmark 2

The purpose of the *Mobile Station Classmark 2* information element is to provide the network with information concerning aspects of both high and low priority of the mobile station equipment. This affects the manner in which the network handles the operation of the mobile station. The Mobile Station Classmark information indicates general mobile station characteristics and it shall therefore, except for fields explicitly indicated, be independent of the frequency band of the channel it is sent on.

The *Mobile Station Classmark 2* information element is coded as shown in figure 10.5.6/3GPP TS 04.08, table 10.5.6a/3GPP TS 04.08 and table 10.5.6b/3GPP TS 04.08.

The Mobile Station Classmark 2 is a type 4 information element with 5 octets length.

	8	7	6	5	4	3	2	1		
-	+		Mobile	stat:	ion cla	assmarl	< 2 IE]		octet	1
_	Length of mobile station classmark 2 contents									2
	0 spare	Revision ES A5/1 RF power level IND capability						octet	3	
	0 spare	PS capa.	SS Sc Indic		SM ca pabi.	VBS	VGCS	FC	octet	4
	СМ3	0 Spare	LCSVA Cap	0 spare	Solsa	CMSP	A5/3	A5/2	octet	5
-								+	•	

Figure 10.5.6/3GPP TS 04.08: Mobile Station Classmark 2 information element

NOTE: Owing to backward compatibility problems, bit 8 of octet 4 should not be used unless it is also checked that the bits 8, 7 and 6 of octet 3 are not "0 0 0".

## Table 10.5.6a/3GPP TS 04.08: Mobile Station Classmark 2 information element

Revision level (octet 3) Bits								
76								
0 0 Reserved for phase 1								
0 1 Used by phase 2 mobile stations								
All other values are reserved for future use If the network receives a revision level specified as 'reserved for future use', then it shall use the highest revision level supported by the network.								
ES IND (octet 3, bit 5) "Controlled Early Classmark Sending" option implementation								
0 "Controlled Early Classmark Sending" option is not implemented in the MS 1 "Controlled Early Classmark Sending" option is implemented in the MS								
NOTE: The value of the ES IND gives the implementation in the MS. It's value is <b>not</b> dependent on the broadcast SI 3 Rest Octet <early classmark="" control="" sending=""> value.</early>								
A5/1 algorithm supported (octet 3, bit 4)								
<ul> <li>0 encryption algorithm A5/1 available</li> <li>1 encryption algorithm A5/1 not available</li> </ul>								
RF Power Capability (Octet 3) When GSM 900 P, E [or R] band is used (for exceptions see 3.4.18): Bits <b>3 2 1</b>								
0 0 0 class 1								
0 0 1 class 2								
010 class 3								
011 class 4								
1 0 0 class 5								
All other values are reserved.								
When the DCS 1800 or PCS 1900 band is used (for exceptions see 3.4.18): Bits								
0 0 0 class 1 0 0 1 class 2								
010 class 3								
All other values are reserved.								
PS capability (pseudo-synchronization capability) (octet 4)								
Bit <b>7</b> 0 PS capability not present								
1 PS capability present								
SS Screening Indicator (octet 4) Bits								
0 0 defined in 3GPP TS 04.80								
0 1 defined in 3GPP TS 04.80 1 0 defined in 3GPP TS 04.80								
1 1 defined in 3GPP TS 04.80								
SM capability (MT SMS pt to pt capability) (octet 4) Bit <b>4</b>								
0 Mobile station does not support mobile terminated point to point SMS								
1 Mobile station supports mobile terminated point to point SMS								

VBS notification reception (octet 4) Bit <b>3</b>
<ul> <li>no VBS capability or no notifications wanted</li> <li>VBS capability and notifications wanted</li> </ul>
VGCS notification reception (octet 4) Bit 2
<ul> <li>0 no VGCS capability or no notifications wanted</li> <li>1 VGCS capability and notifications wanted</li> </ul>
FC Frequency Capability (octet 4) When a GSM 900 band is used (for exceptions see 3.4.18):
Bit 1 0 The MS does not support the E-GSM or R-GSM band (For definition of frequency bands
see 3GPP TS 05.05)
1 The MS does support the E-GSM or R-GSM (For definition of frequency bands see
3GPP TS 05.05) Note : For mobile station supporting the R-GSM band further information can be found in MS
Classmark 3.
When the DCS 1800 band is used (for exceptions see 3.4.18):
Bit 1
0 Reserved for future use (for definition of frequency bands see 3GPP TS 05.05)
NOTE: This bit conveys no information about support or non support of the E-GSM or R-GSM band when transmitted on a DCS 1800 channel.
CM3 (octet 5, bit 8)
<ul> <li>0 The MS does not support any options that are indicated in CM3</li> <li>1 The MS supports options that are indicated in classmark 3 IE</li> </ul>
LCS VA capability (LCS value added location request notification capability) (octet 5,bit 6)
<ul> <li>LCS value added location request notification capability not supported</li> <li>LCS value added location request notification capability supported</li> </ul>
SoLSA (octet 5, bit 4) 0 The ME does not support SoLSA.
1 The ME supports SoLSA.
CMSP: CM Service Prompt (octet 5, bit 3) \$(CCBS)\$ 0 "Network initiated MO CM connection request" not supported.
1 "Network initiated MO CM connection request" supported for at least one CM
protocol.
A5/3 algorithm supported (octet 5, bit 2) 0 encryption algorithm A5/3 not available
1 encryption algorithm A5/3 available
A5/2 algorithm supported (octet 5, bit 1)
<ul><li>0 encryption algorithm A5/2 not available</li><li>1 encryption algorithm A5/2 available</li></ul>

#### Table 10.5.6b/3GPP TS 04.08: Mobile Station Classmark 2 information element

NOTE: Additional mobile station capability information might be obtained by invoking the classmark interrogation procedure.

## 10.5.1.7 Mobile Station Classmark 3

The purpose of the *Mobile Station Classmark 3* information element is to provide the network with information concerning aspects of the mobile station. The contents might affect the manner in which the network handles the operation of the mobile station. The Mobile Station Classmark information indicates general mobile station characteristics and it shall therefore, except for fields explicitly indicated, be independent of the frequency band of the channel it is sent on.

The MS Classmark 3 is a type 4 information element with a maximum of 14 octets length.

The value part of a *MS Classmark 3* information element is coded as shown in figure 10.5.7/3GPP TS 04.08 and table 10.5.7/3GPP TS 04.08.

NOTE: The 14 octet limit is so that the CLASSMARK CHANGE message will fit in one layer 2 frame.

SEMANTIC RULE : a multiband mobile station shall provide information about all frequency bands it can support. A single band mobile station shall not indicate the band it supports in the *Multiband Supported* field in the MS Classmark 3.

SEMANTIC RULE : a mobile station shall include the MS Measurement Capability field if the *Multi Slot Class* field contains a value of 19 or greater (see 3GPP TS 05.02).

Typically, the number of spare bits at the end is the minimum to reach an octet boundary. The receiver may add any number of bits set to "0" at the end of the received string if needed for correct decoding.

<Classmark 3 Value part> ::= <spare bit> <Multiband supported : {000}> { <A5 bits> | <Multiband supported : { 101 | 110}> <A5 bits> <Associated Radio Capability 2 : bit(4)> <Associated Radio Capability 1 : bit(4)> | <Multiband supported : {001 | 010 | 100 }> <A5 bits> <spare bit>(4) <Associated Radio Capability 1 : bit(4)> }  $\{ 0 \mid 1 < R \text{ Support} > \}$ { 0 | 1 < Multi Slot Capability>} <UCS2 treatment: bit> <Extended Measurement Capability : bit> { 0 | 1 < MS measurement capability> } { 0 | 1 < MS Positioning Method Capability> } <spare bit>; <A5 bits> ::= <A5/7 : bit> <A5/6 : bit> <A5/5 : bit> <A5/4 : bit> ; <R Support>::= < **R-GSM band Associated Radio Capability** : bit(3)>; <Multi Slot Capability> ::= <**Multi Slot Class** : bit(5)>; < MS Measurement capability > ::= < **SMS VALUE** : bit (4) >< **SM\_VALUE** : bit (4) >; < MS Positioning Method Capability > ::= < MS Positioning Method : bit(5)>;

#### Figure 10.5.7/3GPP TS 04.08: Mobile Station Classmark 3 information element

Table 10.5.7/3GPP TS 04.08: Mobile Station Classmark 3 information element

Multiband Supported (3 bit field)

Band 1 supported

Bit 1

0	P-GSM not supported
1	P-GSM supported
Band	1 2 supported
Bit 2	
0	E-GSM or R-GSM not supported
1	E-GSM or R-GSM supported
Band	1 3 supported
Bit 3	
0	DCS 1800 not supported
1	DCS 1800 supported
The i	indication of support of P-GSM band or E-GSM or R-GSM band is mutually exclusive.
	n the 'Band 2 supported' bit indicates support of E-GSM or R-GSM, the presence of the <r support=""> field, see</r>
below	w, indicates if the E-GSM or R-GSM band is supported.
T. d.	
	is version of the protocol, the sender indicates in this field either none or two of these 3 bands supported. However, ly one band is indicated, the receiver shall ignore the Associated Radio Capability 2.
For s	ingle band mobile station all bits are set to 0.
A5/4	
0	encryption algorithm A5/4 not available
1	encryption algorithm A5/4 available
A5/5	
0	encryption algorithm A5/5 not available
1	encryption algorithm A5/5 available
A5/6	
0	encryption algorithm A5/6 not available
1	encryption algorithm A5/6 available

## A5/7

- 0 encryption algorithm A5/7 not available
- 1 encryption algorithm A5/7 available

Associated Radio capability 1 and 2

If either of P-GSM or E-GSM or R-GSM is supported, the radio capability 1 field indicates the radio capability for P-GSM, E-GSM or R-GSM, and the radio capability 2 field indicates the radio capability for DCS1800 if supported, and is spare otherwise.

If none of P-GSM or E-GSM or R-GSM are supported, the radio capability 1 field indicates the radio capability for DCS1800, and the radio capability 2 field is spare.

The radio capability contains the binary coding of the power class associated with the band indicated in multiband support bits (see GSMB05.05).

R Support

In case where the R-GSM band is supported the R-GSM band assciated radio capability field contains the binary coding of the power class associated(see GSMß05.05). A mobile station supporting the R-GSM band shall also when appropriate, see 10.5.1.6, indicate its support in the 'FC' bit in the Mobile Station Classmark 2 information element.

Note: the coding of the power class for P-GSM, E-GSM, R-GSM and DCS 1800 in radio capability 1 and/or 2 is different to that used in the Mobile Station Classmark 1 and Mobile Station Classmark 2 information elements.

Multi Slot Class (5 bit field)

In case the MS supports the use of multiple timeslots then the Multi Slot Class field is coded as the binary representation of the multislot class defined in TS 3GPP TS 05.02.

UCS2 treatment

This information field indicates the likely treatment by the mobile station of UCS2 encoded character strings. If not included, the value 0 shall be assumed by the receiver.

- 0 the ME has a preference for the default alphabet (defined in 3GPP TS 03.38) over UCS2.
- 1 the ME has no preference between the use of the default alphabet and the use of UCS2.

Extended Measurement Capability							
This hit is directed where the machile station compared "Enter ded Macananante" or not							
This bit indicates whether the mobile station supports 'Extended Measurements' or not							
0 the MS does not support Extended Measurements							
1 the MS supports Extended Measurements							
<b>SMS_VALUE (Switch-Measure-Switch)</b> (4 bit field) The SMS field indicates the time needed for the mobile station to switch from one radio channel to another, perform a							
neighbour cell power measurement, and the switch from that radio channel to another radio channel.							
Bits							
4 3 2 1 0 0 0 0 1/4 timeslot (~144 microseconds)							
0 0 0 1 2/4 timeslot (~288 microseconds)							
0 0 1 0 3/4 timeslot (~433 microseconds)							
1 1 1 1 1 16/4 timeslot (~2307 microseconds)							
SM_VALUE (Switch-Measure) (4 bit field)							
The SM field indicates the time needed for the mobile station to switch from one radio channel to another and perform a neighbour cell power measurement.							
Bits							
4 3 2 1							
0 0 0 0 1/4 timeslot (~144 microseconds) 0 0 0 1 2/4 timeslot (~288 microseconds)							
0 0 1 0 $3/4$ timeslot (~200 incroseconds) 0 0 1 0 $3/4$ timeslot (~433 microseconds)							
1 1 1 1 16/4 timeslot (~2307 microseconds)							
MS Positioning Method Capability This bit indicates whether the MS supports Positioning Method or not for the provision of Location Services.							
<b>MS Positioning Method</b> (5 bit field) This field indicates the Positioning Method(s) supported by the mobile station.							
MS assisted E-OTD							
Bit 5							
0: MS assisted E-OTD not supported							
1: MS assisted E-OTD supported							
MS hard E OTD							
MS based E-OTD							
Bit 4							
0: MS based E-OTD not supported							

1:	MS based E-OTD supported
MS as	ssisted GPS
Bit 3	
0:	MS assisted GPS not supported
1:	MS assisted GPS supported
MS ba	ased GPS
Bit 2	
0:	MS based GPS not supported
1:	MS based GPS supported
MS co	onventional GPS
Bit 1	
0:	conventional GPS not supported
1:	conventional GPS supported
1: MS co Bit 1 0:	MS based GPS supported onventional GPS conventional GPS not supported

## 10.5.1.8 Spare Half Octet

This element is used in the description of messages in clause 9 when an odd number of half octet type 1 information elements are used. This element is filled with spare bits set to zero and is placed in bits 5 to 8 of the octet unless otherwise specified.

## 10.5.1.9 Descriptive group or broadcast call reference

The purpose of the *Descriptive Group or Broadcast Call Reference* is to provide information describing a voice group or broadcast call. The IE of the *Descriptive Group or Broadcast Call Reference* is composed of the group or broadcast call reference together with a service flag, an acknowledgement flag, the call priority and the group cipher key number.

The *Descriptive Group or Broadcast Call Reference* information element is coded as shown in figure 10.5.8/3GPP TS 04.08 and Table10.5.8/3GPP TS 04.08.

The Descriptive Group or Broadcast Call Reference is a type 3 information element with 6 octets length.

. 8	7	б	5	4	3	2	1		
+	Grou	up or b	roadca	st cal	l refei	rence l		octet	1
		coding Terence	of the	group	or bro	adcast	: 	octet	2
+								octet	3
								octet	4
 +			SF	AF	call	prior	rity	octet	5
Ciph	ering	inform	ation	0	Spare 0	e 0	0	octet	6




Table 10.5.8/3GPP TS 04.08: Descriptive Group or Broadcast Call Reference

Binary code of the group or broadcast call reference The length of the binary code has 27 bits which is encoded in the octet 2, 3, 4 and Bits 8,7,6 (octet 5). The highest bit of the BC is the bit 8 in the octet 2 and the lowest bit is allocated in the bit 6 in the octet 5. (see also GSMB03.03) SF Service flag (octet 5) Bit 5 Õ VBS (broadcast call reference) 1 VGCS (group call reference) AF Acknowledgement flag (octet 5) Bit 4 0 acknowledgement is not required 1 acknowledgement is required Call priority (octet 5) Bit 3 2 1 0 0 0 no priority applied call priority level call priority level 0 0 1 Ō 1 0 3 0 1 1 call priority level 2 call priority level 1 call priority level 0 1 0 0 1 0 1 1 1 0
 1 1 1call priority level B call priority level A Ciphering information (octet 6) Bit 7 65 8 0 0 0 0 no ciphering ciphering with cipher key number 0 0 0 1 ciphering with cipher key number 2 ciphering with cipher key number 3 0 0 0 1 0 0 1 1 ciphering with cipher key number 4 ciphering with cipher key number 5 0 0 0 ciphering with cipher key number 6 ciphering with cipher key number 7 ciphering with cipher key number 8 0 1 1 1 1 ciphering with cipher key number 9 ciphering with cipher key number A 0 1 1 ciphering with cipher key number B ciphering with cipher key number C ciphering with cipher key number D 1 1 0 0 1 1 0 1 1 1 0 ciphering with cipher key number E 1 1 1 1 1 ciphering with cipher key number F

### 10.5.1.10 Group Cipher Key Number

The purpose of the *Group Cipher Key Number* is to provide information on the group cipher key to be used for ciphering and deciphering by the mobile station.

The *Group Cipher Key Number* information element is coded as shown in figure 10.5.9/3GPP TS 04.08 and Table10.5.9/3GPP TS 04.08

The Group Cipher Key Number is a type 1 information element with 1 octet length.

8 7 6 5 4 3 2 1 Group cipher key number IEI Group cipher key number

Figure 10.5.9/3GPP TS 04.08: Group Cipher Key Number

0 0 1 0 cipl 0 0 1 1 cipl 0 1 0 0 cipl 0 1 0 1 cipl 0 1 0 1 cipl 0 1 1 0 cipl 1 0 0 1 cipl 1 0 0 1 cipl 1 0 1 1 cipl 1 0 1 1 cipl 1 1 0 0 cipl 1 1 0 1 cipl 1 1 0 0 cipl	
--	--


 Table 10.5.9/3GPP TS 04.08: Group Cipher Key Number

## 10.5.1.10a PD and SAPI \$(CCBS)\$

The purpose of the *PD and SAPI* information element is to provide information concerning Protocol Discriminators and Service Access Point Identifiers.

The *PD and SAPI* information element is coded as shown in figure 10.5.10/3GPP TS 04.08 and table 10.5.10/3GPP TS 04.08.

The *PD and SAPI* is a type 3 information element with 2 octets length.



#### Figure 10.5.10/3GPP TS 04.08: PD and SAPI information element

 Table 10.5.1.10/3GPP TS 04.08: PD and SAPI information element

SAPI: Service Access Point Identifier (octet 2) Bits 6 5 0 0 SAPI 0 0 1 reserved 1 0 reserved 1 1 SAPI 3 PD: Protocol Discriminator (octet 2) bits 4-1 Encoded as specified in sub-clauses 11.2.1 of 04.07.

#### 10.5.1.11 Priority Level

The purpose of the *Priority Level* is to provide information defining the priority level requested or applied. The *Priority Level* IE may be included in CM\_SERVICE\_REQUEST, CALL\_PROCEEDING and SETUP messages.

The *Priority Level* information element is coded as shown in figure 10.5.11/3GPP TS 04.08 and table 10.5.11/3GPP TS 04.08.

The *Priority Level* is a type 1 information element with 1 octet length.

8	7	6	5	4	3	2	1	г	
1	Prior	rity Le IEI	evel	0 spare	call	prio	rity	octet	1

#### Figure 10.5.11/3GPP TS 04.08: Priority Level

#### Table 10.5.11/3GPP TS 04.08: Priority Level

Call priority (octet 1) Bit 3 2 1 0 0 0 no priority applied 0 0 1 call priority level 4 0 1 0 call priority level 3 0 1 1 call priority level 2 1 0 0 call priority level 1 1 0 1 call priority level 0 1 1 0 call priority level B 1 1 1 call priority level A
---

## 10.5.2 Radio Resource management information elements

## 10.5.2.1a BA Range

The purpose of the BA Range information element is to provide the mobile station with ARFCN range information which can be used in the cell selection procedure.

The BA Range information element is coded as shown in figure 10.5.12/3GPP TS 04.08 and table 10.5.12/3GPP TS 04.08.

The BA Range is a type 4 information element with a minimum length of 6 octets. No upper length limit is specified except for that given by the maximum number of octets in a L3 message (see 3GPP TS 04.06).

8	7	6	5	4	3	2	1				
+			BA R	ANGE I	EI			octet	1		
+	Length of BA Range contents										
+		Numbe	r of R	anges				octet	3		
+	RANGE	C1_LOWE	R (hig	h part	.)			octet	4		
	l_LOWEF w part)			RANGE1 (high	HIGH n part			octet	5		
	NGE1_HI low par			 RA (	NGE2_ high	LOWER part)		octet	6		
+	F	RANGE2_ (low p			   R	ANGE2_ (high	_HIGHER part)	octet	7		
+	RANGE	2_HIGH	IER (lo	w part	.)			octet	8		
+	RANGE	E3_LOWE	R (hig	h part				octet	9		
	3_LOWEF w part)			RANGE3 (high	B_HIGH			octet	10		
	NGE3_HI low par				NGE4_ high	LOWER part)		octet	11		
+	F	ANGE4_ (low p			R		_HIGHER part)	octet	12		
+	RANGE4_HIGHER (low part)										
+					·			octet	n		

Figure 10.5.12/3GPP TS 04.08: BA RANGE information element

Number of Ranges parameter The number of Ranges parameter indicates in binary the number of ranges to be transmitted in the IE. It shall have a minimum value of 1. RANGEI LOWER If \$(impr-BA-range-handling)\$ is not supported: \$begin The RANGEI\_LOWER is coded as the binary representaof frequencies to be used by the mobile station in cell selection (see GSM£05.08 and GSM£03.22) \$end If \$(impr-BA-range-handling)\$ is supported: \$begin The RANGEI\_LOWER is coded as the binary representation of the ARFCN used as the lower limit of a range of frequencies which could be used by the mobile station in cell selection (see GSMS05.08 and GSMB03.22) \$end RANGE1\_HIGHER If \$(impr-BA-range-handling)\$ is not supported: \$begin The RANGEi\_HIGHER is coded as the binary representation of the ARFCN used as the higher limit of a range of frequencies to be used by the mobile station in cell selection (see GSMB05.08 and GSMB03.22) \$end If \$(impr-BA-range-handling)\$ is supported: \$begin The RANGEi HIGHER is coded as the binary representa-tion of the ARFCN used as the higher limit of a range of frequencies which could be used by the mobile station in cell selection (see 3GPP TS 05.08 and 3GPP TS 03.22) \$end If the length of the BA range information element is greater than the number of octets required to carry the Number of Ranges given in octet 3, then any unused octets or parts of octets at the end of the IE shall be considered as spare. If \$(impr-BA-range-handling)\$ is supported: If a mobile station receives range information which has ranges or part of the ranges which are not supported by the mobile station, the mobile station shall take into account those parts of the ranges which it does support. \_\_\_\_\_

#### Table 10.5.12/3GPP TS 04.08: BA Range information element

#### 10.5.2.1b Cell Channel Description

The purpose of the *Cell Channel Description* information element is to provide the reference frequency list to be used to decode the mobile allocation information element.

The Cell Channel Description is a type 3 information element with 17 octets length.

There are several formats for the *Cell Channel Description* information element, distinguished by the "format indicator" subfield. Some formats are frequency bit maps, the others use a special encoding scheme.

NOTE: No more than 64 RF channels should be encoded in the Cell Allocation since this is the maximum number of RF channels which can be referenced in the Mobile Allocation IE.

## 10.5.2.1b.1 General description

Figure 10.5.13/04.08 shows only a special bit numbering. The different general format is described in table 10.5.13/04.08.

	8	7	6	5	4	3	2	1	
Ī			Cell	Channe	el Deso	criptio	on IEI		octet 1
	Bit 128	Bit 127	0 spare	0 spare	Bit 124	Bit 123	Bit 122	Bit 121	octet 2
	Bit 120	Bit 119	Bit 118	Bit 117	Bit 116	Bit 115	Bit 114	Bit 113	octet 3
-4		· 	' +	, 		, +	' +	, +	1
4	Bit 008	Bit 007	Bit 006	Bit 005	Bit 004	Bit 003	Bit 002	Bit 001	octet 17

Figure 10.5.13/3GPP TS 04.08: Cell Channel Description information element (general format)

\_\_\_\_\_ FORMAT-ID, Format Identifier (Bit 128 and next) The different formats are distinguished by the bits of higher number. The possible values are the following: format notation Bit Bit Bit Bit Bit 128 127 124 123 122 bit map 0 1024 range 0 0 Х Х Х 
 0
 X
 X

 1
 0
 0

 1
 0
 1
 0 1 512 range 256 range 128 range 1 0 1 0 1 0 1 1 0 1 1 1 0 1 variable bit map All other combinations are reserved for future use. A GSMß900 mobile station which only supports the primary GSMßband P-GSMß900 (cf. GSMß05.05) may consider all values except the value for bit map 0 as reserved. The significance of the remaining bits depends on the FORMAT-ID. The different cases are specified in the next sub-clauses. Mobile stations shall treat all ARFCNs in the set  $\{0, 1, 2 \dots 1023\}$  as valid ARFCN values even if the mobile station is unable to transmit or receive on that ARFCN. \_\_\_\_\_

Table 10.5.13/3GPP TS 04.08: Cell Channel Description information element, general format

#### 10.5.2.1b.2 Bit map 0 format

	8	7	6	5	4	3	2	1		
		Cell Channel Description IEI								
-	0 FORMAT	0 T-ID	0 spare	0 spare	CA ARFCN 124	CA ARFCN 123	CA ARFCN 122	CA ARFCN 121	octet 2	
-	CA ARFCN 120	CA ARFCN 119	CA ARFCN 118	CA ARFCN 117	CA ARFCN 116	CA ARFCN 115	CA ARFCN 114	CA ARFCN 113	octet 3	
-	<b>-</b>									
-	+ CA ARFCN 008 +	CA ARFCN 007	CA ARFCN 006	CA ARFCN 005	CA ARFCN 004	CA ARFCN 003	CA ARFCN 002	CA ARFCN 001	octet 17	

Figure 10.5.14/3GPP TS 04.08: Cell Channel Description information element, bit map 0 format

Table 10.5.14/3GPP TS 04.08: Cell channel Description information element, bit map 0 format

\_\_\_\_\_

CA ARFCN N, Cell Allocation Absolute RF Channel Number N (octet 2 etc.) For a RF channel with ARFCN = N belonging to the cell allocation the CA ARFCN N bit is coded with a "1"; N = 1, 2, ..., 124. For a RF channel with ARFCN = N not belonging to the cell allocation the CA ARFCN N bit is coded with a "0"; N = 1, 2 ..., 124.

8 7	б	5	4	3	2		1		
+	octet	1							
1 0 FORMAT-ID	0 spare	0 spare	0 FORMA T-ID	FO	(hi	W( gh j	1) part)	octet	2
+	W(1) (low part)								
	W(2) (high part)								
W(2) (low)	W(2) W(3) low) (high part)								5
W(3) (low part)								octet	б
W(4) (low part)									7
W(5) (low part)		(h:	W(6) igh pai	ct)				octet	8
W(6) (low part)		(h:	W(7) igh pai	ct)				octet	9
W(7) (low part)		(h:	W(8) igh pai	ct)				octet	10
W(8) (low)		W ( 9	9)					octet	11
	W(10	))					W(11) high	octet	12
W(11) (low part) W(12) (high part)								octet	13
W(12) (lo		W(13) (high part)						14	
W(13) (lo	= )	W(14) (high part)				octet	15		
W(14) (low	W(14) (low part)   W(15) (high part)						t)	octet	16
W(15) (low part)			W(16)	)				octet	17

#### 10.5.2.1b.3 Range 1024 format

Figure 10.5.15/3GPP TS 04.08: Cell Channel Description information element (1024 range format)

Table 10.5.15/3GPP TS 04.08: Cell Channel Description information element, range 1024 format

F0, frequency 0 indicator (octet 2, bit 3): 0 ARFCN 0 is not a member of the set 1 ARFCN 0 is a member of the set W(i), i from 1 to 16 (octet 2 to 17): Each W(i) encodes a non negative integer in binary format. If W(k) is null, W(k+1) to W(16) must be null also. Each non null W(k) allows to compute, together with some previous W(i) the ARFCN F(k) of a frequency in the set. The computation formulas are given in sub-clause 10.5.2.13.3.

### 10.5.2.1b.4 Range 512 format

8 7	6	5	4	3	2	1		
	Cell	Channe	el De	escriptio	on IEI		octet	1
1 0 FORMAT-ID	0 spare	0 spare	1	0 FORMAT-I	0 ID	ORIG- ARFCN high	octet	2
OR:	IG-ARFC	N (mic	ldle	part)			octet	3
ORIG- ARFCN low		₩(1 (high		5)			octet	4
W(1) (low part)		W(2 (high		.)			octet	5
W(2) (low part)		W(3 (high		.)			octet	6
W(3) (low part)		W(4 (high		.)			octet	7
W(4) low		W (	5)				octet	8
W	(6)					W(7) high	octet	9
	(7) part)				W(8 (high	) part)	octet	10
W(8) (low	v part)		W (	(9) (higł	n part	)	octet	11
W(9) (low part)			W(10	))			octet	12
	W(1	1)			W(1 (high	2) part)	octet	13
W(12) (low	v part)		W (	(13) (h	lgh pa	rt)	octet	14
W(13) (low part)			W(14	1)			octet	15
	W(1	5)			W(1 (high	6) part)	octet	16
W(16) (low	part)			W(17)		+	octet	17

Figure 10.5.16/3GPP TS 04.08: Cell Channel Description information element (512 range format)

Table 10.5.16/3GPP TS 04.08: Cell Channel Description information element, range 512 format

ORIG-ARFCN, origin ARFCN (octet 2, 3 and 4)
This field encodes the ARFCN of one frequency
belonging to the set. This value is also used to
decode the rest of the element.

W(i), i from 1 to 17 (octet 4 to 17):
Each W(i) encodes a non negative integer in binary
format.
If W(k) is null, W(k+1) to W(17) must be null also.
Each non null W(k) allows to compute, together with
some previous W(i) the ARFCN F(k) of a frequency in
the set. The computation formulas are given in sub-clause
10.5.2.13.4.

\_\_\_\_\_

### 10.5.2.1b.5 Range 256 format

	8	7	б	5	4	3	2	1		
			Cell	Channe	el Des	scriptio	on IEI	C	octet	1
	1 FORM2	0 AT-ID	0 spare	0 spare	1 F	0 FORMAT-I	1 ID	ORIG- ARFCN high	octet	2
		OR	IG-ARF	CN (mi	.ddle	part)			octet	3
	ORIG- ARFCN low		[]	W(1) high pa					octet	4
	W(1) low	+		W(2)					octet	5
				W(3)				W(4) high	octet	6
		W(4)	(low pa	art)		W(5)	(higł	n part)	octet	7
	W(5)	(low )	part)	W (	6) (	high pa	art)		octet	8
	W(6) low		W	(7)				W(8) high	octet	9
	W(8	3) (la	ow par	t)	 W (	(9) (hig	gh par	rt)	octet	10
	W(9) low		W(10)				W(11 (high	L) 1 part)	octet	11
	W(11)	) (low	part)			W(12)			octet	12
		W	(13)			W(14	)(higł	n part)	octet	13
	W(14) low			W (	15)			W(16) high	octet	14
		(16) w part	)		W(17	7)		W(18) high	octet	15
		(18) w part	)		W(19	ə)		W(20) high	octet	16
-		(20) w part	)		W(21	L)		0 Spare	octet	17

Figure 10.5.17/3GPP TS 04.08: Cell Channel Description information element, range 256 format

Table 10.5.17/3GPP TS 04.08: Cell Channel Description information element, range 256 format

ORIG-ARFCN, origin ARFCN (octet 2, 3 and 4) This field encodes the ARFCN of one frequency belonging to the set. This value is also used to decode the rest of the element. W(i), i from 1 to 21 (octet 4 to 17): Each W(i) encodes a non negative integer in binary format. If W(k) is null, W(k+1) to W(21) must be null also. Each non null W(k) allows to compute, together with some previous W(i) the ARFCN F(k) of a frequency in the set. The computation formulas are given in sub-clause 10.5.2.13.5.

10.5.2.1b.6 Range 128 format

7 6 5 4 3 2 1 8 Cell Channel Description IEI octet 1 
 1
 0
 0
 1
 1
 0
 ORIG 

 FORMAT-ID
 spare
 spare
 FORMAT-ID
 ARFCN
 octet 2 high ORIG-ARFCN octet 3 (middle part) -----ORIGoctet 4 ARFCN W(1)low \_\_\_\_\_\_ W(3) (high part) W(2) octet 5 W(3) (low part) | W(4) (high part) octet 6 W(6) W(4) W(5) octet 7 (high part) low \_\_\_\_\_ W(6) (low part) W(7)octet 8 · · · W(9) W(8) octet 9 W(10) W(11) octet 10 W(12) W(13) octet 11 W(14) W(15) octet 12 \_\_\_\_ W(18) W(17) octet 13 W(16) (high part) -----W(20) W(21) high W(18) W(19) low W(21) octet 14 \_\_\_\_\_ \_\_\_\_\_ \_ \_ \_ \_ . W(21) W(22) W(23) octet 15 (low part) W(24) W(25) W(26) (high part) octet 16 W(26) W(27) W(28) 0 octet 17 low spare 

Figure 10.5.18/3GPP TS 04.08: Cell Channel Description information element, range 128 format

Table 10.5.18/3GPP TS 04.08: Cell Channel Description information element, range 128 format

ORIG-ARFCN, origin ARFCN (octet 2, 3 and 4)
This field encodes the ARFCN of one frequency
belonging to the set. This value is also used to
decode the rest of the element.
W(i), i from 1 to 28 (octet 4 to 17):
Each W(i) encodes a non negative integer in binary
format.
If W(k) is null, W(k+1) to W(28) must be null also.
Each non null W(k) allows to compute, together with
some previous W(i) the ARFCN F(k) of a frequency in
the set. The computation formulas are given in
sub-clause 10.5.2.13.6.

10.5.2.1b.7 Variable bit map format

	8	7	6	5	4	3	2	1	
ļ			Cell	Channe	el Deso	criptio	on IEI		octet 1
	1 FORMA	0 AT-ID	0 spare	0 spare	1 F(	1 DRMAT-I	1 ID	ORIG- ARFCN high	octet 2
		octet 3							
+	ORIG- ARFCN low	RRFCN 1	RRFCN 2	RRFCN 3	RRFCN 4	RRFCN 5	RRFCN 6	RRFCN 7	octet 4
+		+	+	+	+	+	+	+	
+	RRFCN 104	RRFCN 105	RRFCN 106	RRFCN 107	RRFCN 108	RRFCN 109	RRFCN 110	RRFCN 111	octet 17

Figure 10.5.19/3GPP TS 04.08: Cell Channel Description information element, variable bit map format

Table 10.5.19/3GPP TS 04.08: Cell Channel Description information element, variable bit map format

ORIG-ARFCN, origin ARFCN (octet 2, 3 and 4)
This field encodes the ARFCN of one frequency
belonging to the set. This value is also used as
origin of the bit map to generate all other frequencies.
RRFCN N, relative radio frequency channel number N
(octet 4 etc.)
For a RF channel with ARFCN = (ORIG-ARFCN + N) mod 1024
belonging to the set, RRFCN N bit is coded with a
"1"; N = 1, 2, ..., 111
For a RF channel with ARFCN = (ORIG-ARFCN + N) mod 1024
not belonging to the set, RRFCN N bit is coded with a
"0"; N = 1, 2, ..., 111

### 10.5.2.1c BA List Pref

The purpose of the BA List Pref information element is to provide the mobile station with ARFCN information which can be used in the cell selection/reselection procedure.

The BA List Pref is a type 4 information element with a minimum length of 3 octets. No upper length limit is specified except for that given by the maximum number of octets in a L3 message (see 3GPP TS 04.06).

<BA List Pref>::=

<LENGTH OF BA LIST PREF : bit (8)>

{1 <RANGE LIMITS >}\*\*0

{1 <BA FREQ : bit (10)>}\*\*0

<spare padding>;

<RANGE LIMITS>::=

<RANGE LOWER : bit (10)>

<RANGE UPPER : bit (10)>;

The RANGE LOWER is coded as the binary representation of the ARFCN used as the lower limit of a range of frequencies to be used by the mobile station in cell selection and reselection (see 3GPP TS 05.08 and 3GPP TS 03.22).

The RANGE HIGHER is coded as the binary representation of the ARFCN used as the higher limit of a range of frequencies to be used by the mobile station in cell selection and reselection (see 3GPP TS 05.08 and 3GPP TS 03.22).

BA FREQ is coded as the binary representation of the ARFCN indicating a single frequency to be used by the mobile station in cell selection and reselection (see 3GPP TS 05.08 and 3GPP TS 03.22).

## 10.5.2.2 Cell Description

The purpose of the *Cell Description* information element is to provide a minimum description of a cell, e.g. to allow the mobile station to use its pre-knowledge about synchronization.

The *Cell Description* information element is coded as shown in figure 10.5.20/3GPP TS 04.08 and table 10.5.20/3GPP TS 04.08.

The Cell Description is a type 3 information element with 3 octets length.




Figure 10.5.20/3GPP TS 04.08: Cell Description information element

Table 10.5.20/3GPP TS 04.08: Cell Description information element

NCC, PLMN colour code (octet 2) The NCC field is coded as the binary representation of the PLMN colour code (see TS. GSME03.03) BCC, BS colour code (octet 2) The BCC field is coded as the binary representation of the BS colour code (see TS. GSME03.03). BCCH ARFCN (octet 2, bits 7 and 8, and octet 3) The BCCH ARFCN number field is coded as the binary representation of the BCCH carriers absolute RF channel number. Range: 0 to 1023

# 10.5.2.3 Cell Options (BCCH)

The purpose of the Cell Options (BCCH) information element is to provide a variety of information about a cell.

The *Cell Options* (BCCH) information element is coded as shown in figure 10.5.21/3GPP TS 04.08 and table 10.5.21/3GPP TS 04.08.

The Cell Options (BCCH) is a type 3 information element with 2 octets length.

8		7 6	5 5	4	3	2	1	. т	
Ì			Cell	l Opt	ions (B	CCH)	IEI	octet	1
	0 spare	PWRC	DTX		RADIO-	LINK		octet	2

#### Figure 10.5.21/3GPP TS 04.08: Cell Options (BCCH) information element

# 10.5.2.3a Cell Options (SACCH)

The purpose of the Cell Options (SACCH) information element is to provide a variety of information about a cell.

The *Cell Options* (SACCH) information element is coded as shown in figure 10.5.22 /3GPP TS 04.08 and table 10.5.22/3GPP TS 04.08.

The Cell Options (SACCH) is a type 3 information element with 2 octets length.

8	7	6	5	4	3	2	1			
+			Cell	L Opt	ions (S	ACCH)	IEI	<	octet	1
D	TX   PW	RC	DTX		RADIO-	LINK-	TIMEOUT	+ c	octet	2

Figure 10.5.22/3GPP TS 04.08: Cell Options (SACCH) information element

Table 10.5.21/3GPP TS 04.08: Cell Options (BCCH) information element

PWRC Power control indicator (octet 2) Note 1 bit 7 0 PWRC is not set 1 PWRC is set
<pre>DTX, DTX indicator (octet 2) Note 3 Bit 6 5 0 0 The MSs may use uplink discontinuous transmission 0 1 The MSs shall use uplink discontinuous transmission 1 0 The MS shall not use uplink discontinuous transmission</pre>
RADIO-LINK_TIMEOUT (octet 2) Note 2 Bits 4 3 2 1 0 0 0 0 4 0 0 0 1 8 0 0 1 0 12
1 1 1 0 60 1 1 1 1 64

NOTE 1: The precise meaning of the PWRC parameter can be found in 3GPP TS 05.08.

NOTE 2: The precise meaning of RADIO-LINK-TIMEOUT parameter can be found in 3GPP TS 05.08.

NOTE 3: The DTX indicator field is not related to the use of downlink discontinuous transmission.

Table 10.5.22/3GPP TS 04.08: Cell Options (SACCH) information element

PWRC Power control indicator (octet 2) Note 1 bit 7 0 PWRC is not set 1 PWRC is set DTX, DTX indicator (octet 2) Note 3 Bit 8 6 5 0 0 0 The MS may use uplink discontinuous transmission on a TCH-F. The MS shall not use uplink discontinuous transmission on TCH-H. 0 0 1 The MS shall use uplink discontinuous transmission on a TCH-F. The MS shall not use uplink discontinuous transmission on TCH-H. 0 1 0 The MS shall not use uplink discontinuous transmission on a TCH-F. The MS shall not use uplink discontinuous transmission on TCH-H. 0 1 1 Note 4: The MS shall use uplink discontinuous transmission on a TCH-F. The MS may use uplink discontinuous transmission on TCH-H. 1 0 0 The MS may use uplink discontinuous transmission on a TCH-F. The MS may use uplink discontinuous transmission on TCH-H. 1 0 1 The MS shall use uplink discontinuous transmission on a TCH-F. The MS shall use uplink discontinuous transmission on TCH-H. 1 1 0 The MS shall not use uplink discontinuous transmission on a TCH-F. The MS shall use uplink discontinuous transmission on TCH-H. 1 1 1 Note 4: The MS may use uplink discontinuous transmission on a TCH-F. The MS shall use uplink discontinuous transmission on TCH-H. RADIO-LINK\_TIMEOUT (octet 2) Note 2 Bits  $\begin{array}{ccc} 4 & 3 & 2 \\ 0 & 0 & 0 \end{array}$ 1 0 4 0 0 0 1 8 0 0 1 0 12 1 1 1 0 60 1 1 1 1 64

NOTE 1: The precise meaning of the PWRC parameter can be found in 3GPP TS 05.08.

NOTE 2: The precise meaning of RADIO-LINK-TIMEOUT parameter can be found in 3GPP TS 05.08.

- NOTE 3: The DTX indicator field is not related to the use of downlink discontinuous transmission.
- NOTE 4: These codes shall not be sent to mobile stations that implement an earlier version of this protocol in which these codes were not defined.

## 10.5.2.4 Cell Selection Parameters

The purpose of the Cell Selection Parameters information element is to provide a variety of information about a cell.

The *Cell Selection Parameters* information element is coded as shown in figure 10.5.23/3GPP TS 04.08 and table 10.5.23/3GPP TS 04.08.

The Cell Selection Parameters information element is a type 3 information element with 3 octets length.

	8	7	6	5	4	3	2	1		
Ī			Cell S	elect	ion Par	ameter	s IEI		octet	1
	CELL-RESELECT MS-TXPWR-MAX-CCH HYSTERESIS									2
+	ACS	NECI		RZ	XLEV-AC	CESS-M	IIN		octet	3
+									+	

Figure 10.5.23/3GPP TS 04.08: Cell Selection Parameters information element

Table 10.5.23/3GPP TS 04.08: Cell Selection Parameters information element

```
CELL-RESELECT-HYSTERESIS (octet 2)
The usage of this information is defined in GSM
                                                              ß
05.08
Bits
8 7
     6
0 0 0
           0 dB RXLEV hysteresis for LA re-selection
Ō
 0 1
           2 dB RXLEV hysteresis for LA re-selection
0
  1 0
            4 dB RXLEV hysteresis for LA re-selection
            6 dB RXLEV hysteresis for LA re-selection
0
  1 1
          8 dB RXLEV hysteresis for LA re-selection
10 dB RXLEV hysteresis for LA re-selection
12 dB RXLEV hysteresis for LA re-selection
14 dB RXLEV hysteresis for LA re-selection
1 0 0
1 0 1
1 1 0
1 1 1
MS-TXPWR-MAX-CCH (octet 2)
The MS-TXPWR-MAX-CCH field is coded as the binary
representation of the "power control level" in TS
GSMB05.05 corresponding to the maximum TX power
level an MS may use when accessing on a Control
Channel CCH. This value shall be used by the Mobile
Station according to 3GPP TS 05.08.
Range: 0 to 31.
RXLEV-ACCESS-MIN (octet 3)
The RXLEV-ACCESS-MIN field is coded as the binary
representation of the minimum received signal level
    the MS for which it is permitted to access the
at
system.
Range: 0 to 63.
                                   (See TS GSMB05.08).
ACS, ADDITIONAL RESELECT PARAM IND (octet 3) Bit 8:
  In System Information type 3 message:
          The SI 4 rest octets, if present, and SI 7
and SI 8 rest octets, if so indicated in the
SI 4 rest octets shall be used to derive the
     0
          value of PI and possibly C2 parameters and/or
          other parameters
     1
           System information type 16 and 17 are
           broadcast on the BCCH.
     A mobile station which does not support System
     information type 16 and 17 may consider this bit
     as "0".
  In System Information type 4 message:
     0
          The SI 4 rest octets, if present, shall be
          used to derive the value of PI and possibly
          C2 parameters and/or other parameters
          The value of PI and possibly C2 parameters and/or other parameters in a System
     1
          information type 7 or type 8 message shall
          be used
NECI: HALF RATE SUPPORT (octet 3)
Bit 7:
     Ω
          New establishment causes are not supported
          New establishment causes are supported
     1
```

### 10.5.2.4a MAC Mode and Channel Coding Requested

The purpose of the *MAC Mode and Channel Coding Requested* information element is for the mobile station to indicate to the network which channel coding rate the mobile station desires the network to use on the downlink.

The *MAC Mode and Channel Coding Requested* information element is coded as shown in figure 10.5.24/3GPP TS 04.08 and table 10.5.24/3GPP TS 04.08.

The MAC Mode and Channel Coding Requested is a type 1 information element.

8	7	б	5	4	3	2	1	. т	
	MAC Chan C	Mode od Rec		MAC mod	-	CS		octet	1

Figure 10.5.24/3GPP TS 04.08: MAC Mode and Channel Coding Requested information element

Table 10.5.24/3GPP TS 04.08: MAC Mode and Channel Coding Requested information element

\_\_\_\_\_ CS : Coding Scheme This field indicates to network the channel coding scheme (see GSM£05.03) that the network should use on the downlink. The field is encoded according to the following table: bits 2 1 0 0 CS 1 CS 2 CS 3 CS 4 0 1 1 0 1 1 MAC Mode (bits 3-4, octet 1) This field is encoded the same as the MAC\_MODE field in the PACKET RESOURCE REQUEST message described in 3GPP TS 04.60. 

# 10.5.2.5 Channel Description

The purpose of the *Channel Description* information element is to provide a description of an allocable channel together with its SACCH.

The *Channel Description* information element is coded as shown in figure 10.5.25/3GPP TS 04.08 and table 10.5.25/3GPP TS 04.08.

The Channel Description is a type 3 information element with 4 octets length.

8 7 б 5 2 1 4 3 Channel Description IEI octet 1 \_\_\_\_\_ Channel type octet 2 and TDMA offset TNH=1-> MAIO (high part) +- H -+- - - - - - - - - -TSC octet 3 ARFCN 0 H=0-> spare (high part) MATO HSN (low part) octet 4 \_ \_ \_ \_ \_ \_ \_ \_ \_ \_ \_ \_ \_ \_ ARFCN (low part)

Figure 10.5.25/3GPP TS 04.08: Channel Description information element

Table 10.5.25/3GPP TS 04.08: Channel Description information element

Channel type and TDMA offset (octet 2) Bits 8 7 6 5 4 TCH/F + ACCHs  $0 \ 0 \ 0 \ 0 \ 1$ 0 0 0 1 T 0 0 1 T T TCH/H + ACCHs SDCCH/4 + SACCH/C4 or CBCH (SDCCH/4) SDCCH/8 + SACCH/C8 or CBCH (SDCCH/8) 0 1 T T T The T bits indicate the subchannel number coded in binary. All other values are reserved. The Channel Type and TDMA offset field shall be ignored and all bits treated as spare when received in a PDCH ASSIGNMENT COMMAND message. The sender set the spare bits to the coding for TCH/F+ACCHs TN, Timeslot number (octet 2) The TN field is coded as the binary representation of the timeslot number as defined in GSMB05.10. Range: 0 to 7. The Timeslot number field shall be ignored and all bits treated as spare when received in a PDCH ASSIGNMENT COMMAND message. The sender sets the spare bits as '000' TSC, Training Sequence Code (octet 3) The TSC field is coded as the binary representation of the Training Sequence code as defined in GSM 05.03 Range: 0 to 7. H, Hopping channel (octet 3) Bit 5 0 Single RF channel 1 RF hopping channel Note: The value of H affects the semantics of the channel selector field Channel selector (octet 3 and 4) H = "0": The channel selector field consists of the absolute RF channel number Octet 3 Bits 4 3 0 0 Spare ARFCN, (octet 3, bits 2 and 1, and octet 4, bits 8 to 1) The ARFCN is coded as the binary representation of the absolute RF channel number Range: 0 to 1023 H = "1": The channel selector field consists of the mobile allocation index offset, MAIO, and the hopping sequence number, HSN. MAIO, (octet 3 bit 4 to 1 high part and octet 4 bit 8 to 7 low part) The MAIO field is coded as the binary rep-resentation of the mobile allocation index offset as defined in GSMB05.02. Range: 0 to 63. HSN, (octet 4 bit 6 to 1) The HSN field is coded as the binary repres-

```
entation of the hopping sequence number
as defined in GSMB05.02
Range 0 to 63.
```

# 10.5.2.5a Channel Description 2

The purpose of the *Channel Description* 2 information element is to provide a description of an allocable channel configuration together with its SACCH.

The *Channel Description* 2 information element is coded as shown in figure 10.5.26 /3GPP TS 04.08 and table 10.5.26/3GPP TS 04.08.

The Channel Description 2 is a type 3 information element with 4 octets length.




Figure 10.5.26/3GPP TS 04.08: Channel Description 2 information element

Table 10.5.26/3GPP TS 04.08: Channel Description 2 information element

Channel type and TDMA offset (octet 2) Bits 87654 0 0 0 0 0 TCH/F + FACCH/F and SACCH/M at the timeslot indicated by TN, and additional bidirectional or undirectional TCH/Fs and SACCH/Ms  $\,$ according to the multislot allocation information element 0 0 0 0 1 TCH/F + FACCH/F and SACCH/F 0 0 0 1 T 0 0 1 T T TCH/H + ACCHs SDCCH/4 + SACCH/C4 or CBCH (SDCCH/4) 0 1 T T T SDCCH/8 + SACCH/C8 or CBCH (SDCCH/8) The T bits indicate the subchannel number coded in binary. In the description below "n" is the timeslot number indicated by TN. The description is valid only if all the indicated timeslot numbers are in the range 0 to 7. 1 0 X X X TCH/F + FACCH/F and SACCH/M at the time slot indicated by TN, and additional bidirectional TCH/Fs and SACCH/Ms at other timeslots according to the following: x x x: 0 0 no additional timeslots 0 0 0 1 at timeslot n-1 0 1 0 at timeslot n+1, n-1 0 1 1 at timeslot n+1, n-1 and n-2at timeslot n+1, n-1, n-2, and n-3at timeslot n+1, n-1, n-2, n-3 and n-41 0 0 1 0 1 1 1 0 at timeslot n+1, n-1, n-2, n-3, n-4 and n-51 1 1 at timeslot n+1, n-1, n-2, n-3, n-4, n-5 and n-61 1 0 0 1 to 1 1 0 1 1 TCH/F + FACCH/F and SACCH/M at the time slot indicated by TN and additional unidirectional TCH/FDs and SACCH/MDs at other timeslots according to the following: at timeslot n-1 1 1 0 0 1 at timeslot n+1, n-1 at timeslot n+1, n-1 and n-2 TCH/F + FACCH/F and SACCH/M at the time slot indicated by TN and additional bidirectional TCH/F and SACCH/M at 1 1 1 1 0 timeslot n+1 and unidirectional TCH/FD and SACCH/MD at timeslot n-1 All other values are reserved. TN, Timeslot number (octet 2) The TN field is coded as the binary representation of the timeslot number as defined in TS GSMB05.10. Range: 0 to 7. TSC, Training Sequence Code (octet 3) The TSC field is coded as the binary representation of the Training Sequence code as defined in TS GSMß 05.03 Range: 0 to 7. Hopping channel (octet 3) Η. Bit 5 0 Single RF channel

RF hopping channel 1 Note: The value of H affects the semantics of the channel selector field Channel selector (octet 3 and 4) H = "0": The channel selector field consists of the absolute RF channel number Octet 3 Bits 4 3 0 0 Spare ARFCN, (octet 3, bits 2 and 1, and octet 4, bits 8 to 1) The ARFCN is coded as the binary representation of the absolute RF channel number Range: 0 to 1023 H = "1": The channel selector field consists of the mobile allocation index offset, MAIO, and the hopping sequence number, HSN. MAIO, (octet 3 bit 4 to 1 high part and octet 4 bit 8 to 7 low part) The MAIO field is coded as the binary rep-resentation of the mobile allocation index offset as defined in TS GSMB05.02. Range: 0 to 63. HSN, (octet 4 bit 6 to 1) The HSN field is coded as the binary representation of the hopping sequence number as defined in TS GSMB05.02 Range 0 to 63. \_\_\_\_\_

# 10.5.2.6 Channel Mode

The *Channel Mode* information element gives information of the mode on coding/decoding and transcoding. The exact mode is determined by the contents of this IE and the channel type.

The *Channel Mode* information element is coded as shown in figure 10.5.27/3GPP TS 04.08 and table 10.5.27/3GPP TS 04.08.

The Channel Mode is a type 3 information element with 2 octets length.

3 7 5 8 б 4 2 1 \_\_\_\_\_ Channel Mode IEI octet 1 \_\_\_\_\_ octet 2 Mode \_\_\_\_\_



```
The mode field is encoded as follows:
(octet 2)
Bits
8
  7
    6
      5
        4 3 2 1
0
0
  1 0 0 0 0 1 speech full rate or half rate version 3
0 0 0 1 1 1 1 data, 14.5 kbit/s radio interface rate
             1 1
                   data, 14.5 kbit/s radio interface rate
                  data, 12.0 kbit/s radio interface rate
data, 6.0 kbit/s radio interface rate
data, 3.6 kbit/s radio interface rate
0
  0 0 0 0 0 1 1
 0
0
Other values are reserved for future use.
Note 1: The speech full rate or half rate version 3 is
       also referred as the adaptive multi-rate full rate
       or half rate speech version 1
                                           _____+
```

Table 10.5.27/3GPP TS 04.08: Channel Mode information element

# 10.5.2.7 Channel Mode 2

The Channel Mode 2 information element gives information of the mode of coding/decoding and transcoding.

The *Channel Mode 2* information element is coded as shown in figure 10.5.28/3GPP TS 04.08 and table 10.5.28/3GPP TS 04.08.

The Channel Mode 2 is a type 3 information element with 2 octets length.






Table 10.5.28/3GPP TS 04.08: Channel Mode 2 information element

```
The mode field is encoded as follows:
(octet 2)
Bits
8 7 6
            54
                     321

      0
      0
      0
      0
      0
      0
      signalling only

      0
      0
      0
      1
      0
      speech half rate version 1

      0
      1
      0
      1
      1
      speech half rate version 2

      1
      0
      0
      1
      1
      speech half rate version 3

      0
      0
      1
      1
      dete
      6
      kbit (g radio int)

0
0
0
0
0
    0 0 0 1
                     1 1 1
                                         data, 6.0 kbit/s radio interface rate
0
   0 0 1 0 1 1 1
                                         data, 3.6 kbit/s radio interface rate
Other values are reserved for future use.
NOTE:
                The speech half rate version 3 is
                 also referred as the adaptive multi-rate half rate speech version 1
```

### 10.5.2.8 Channel Needed

The purpose of the *Channel Needed* information element is to indicate to up to two mobile stations which type of channel is needed (for each mobile station) for the transaction linked to the paging procedure.

The *Channel Needed* information element is coded as shown in figure 10.5.29/3GPP TS 04.08 and table 10.5.29/3GPP TS 04.08.

The Channel Needed is a type 1 information element.

- <b>- -</b>	8	7	6	5	4	3	2	1	1
	Channel Needed IEI				CHAN (sec	NEL cond)	CHAI (fi:	NNEL rst)	octet 1

Figure 10.5.29/3GPP TS 04.08: Channel Needed information element

Table 10.5.29/3GPP TS 04.08: Channel Needed information element

\_\_\_\_\_ CHANNEL (octet 1) Bits 2/41/3 Any channel. SDCCH. 0 0 0 1 0 TCH/F (Full rate). 1 1 1 TCH/H or TCH/F (Dual rate). If this information element is used for only one mobile station, then the first CHANNEL field is used and the second CHANNEL field is spare.

## 10.5.2.8a Channel Request Description

The purpose of the *Channel Request Description* information element is to indicate to the network the type of requested uplink resources or to indicate the type of paging that is being responded to.

The *Channel Request Description* information element is coded as shown in figure 10.5.30/3GPP TS 04.08 and table 10.5.30/3GPP TS 04.08.

The Channel Request Description is a type 3 information element with a length of 6 octets.

8	7	6	5	4	3	2	1				
		(	Channel R	equest Des	scription IE	ΞI		octet 1			
	0	0	0	0	0	0	0				
=0->				spare							
MT/MO	/MO										
=1->				pric	ority	mode	frame				
							type				
0	0	0	0	0	0	0	0				
			spa								
		Requeste	d bandwid	tn (INSB-V	alue field)			octet 3			
0	0	0	0	0	0	0	0				
0	0	0	Sp	•	0	0	0	octet 4			
		Requeste	ed bandwid		alue field)			00101 4			
		rioquooid									
0	0	0	0	0	0	0	0				
· ·	Ū	C C	Sp	are	Ŭ	Ū	°,				
RLC Octet Count (MSB-Value field)											
0	0	0	0	0	0	0	0				
			Sp	are				octet 6			
		RLC O	ctet Count	(LSB-Valu	e field)						



### Table 10.5.30/3GPP TS 04.08: Channel Request Description information element details

MT/MO (bit 8, octet 2)

1 Mobile originated (MO)

0 Mobile terminated (MT)

PRIORITY (bits 3-4, octet 2) When MT/MO indicates MO, this field indicates the priority of the requested TBF bit 4 3\_ 0 0 Priority Level 1 (Highest priority) 0 1 Priority Level 2 1 0 Priority Level 3

1 1 Priority Level 4 (Lower priority)

**RLC\_MODE** (bit 2, octet 2) When MT/MO indicates MO, this field indicates the RLC mode of the requested TBF.

0 RLC acknowledged mode

1 RLC unacknowledged mode

### LLC\_FRAME\_TYPE (bit 1, octet 2)

When MT/MO indicates MO, this field indicates the type of the first LLC frame to be transmitted over the requested uplink TBF.

0 LLC frame is SACK or NACK

1 LLC frame is not SACK or NACK

**REQUESTED\_BANDWIDTH** (16 bits field, octets 3 and 4) When MT/MO indicates MO, this field indicates the useful uplink bandwidth requested in bit rate.

The bit rate field is the binary encoding of the rate information expressed in 100 bits/s, starting from 0 x 100 bits/s until  $65535 \times 100$  bits/s.

The throughput granted by BSS may be higher to cope with protocol overhead and retransmissions.

**RLC\_OCTET\_COUNT** (16 bits field, octets 5 and 6) When MT/MO indicates MO, this field indicates the number of octets of RLC data the mobile station wishes to transfer: see 3GPP TS 04.60.

# 10.5.2.9 Cipher Mode Setting

The purpose of the *Cipher Mode Setting* information element is to indicate whether stream ciphering shall be started or not and if it is to be started, which algorithm to use.

The *Cipher Mode Setting* information element is coded as shown in figure 10.5.31/3GPP TS 04.08 and table 10.5.31/3GPP TS 04.08.

The Cipher Mode Setting is a type 1 information element.




Figure 10.5.31/3GPP TS 04.08: Cipher Mode Setting information element

```
algorithm identifier
If SC=1 then:
bits
4 3 2
0
 0 0
       cipher with algorithm A5/1
0
0
       cipher with algorithm A5/2
 0 1
 1 0
       cipher with algorithm A5/3
0
  1
    1
       cipher with algorithm A5/4
  0 0
1
       cipher with algorithm A5/5
       cipher with algorithm A5/6
cipher with algorithm A5/7
1
  0 1
1
  1 0
1 1 1
       reserved
If SC=0 then bits 4, 3 and 2 are spare and set to "0"
SC (octet 1)
Bit
1
0
         No ciphering
1
         Start ciphering
                             _____
```

Table 10.5.31/3GPP TS 04.08: Cipher Mode Setting information element

# 10.5.2.10 Cipher Response

The *Cipher Response* information element is used by the network to indicate to the mobile station which information the mobile station has to include in the CIPHERING MODE COMPLETE message.

The *Cipher Response* information element is coded as shown in figure 10.5.32/3GPP TS 04.08 and table 10.5.32/3GPP TS 04.08.

The Cipher Response is a type 1 information element.






Table 10.5.32/3GPP TS 04.08: Cipher Response information element

CR Cipher Response (octet 1) Bit 1 0 IMEISV shall not be included 1 IMEISV shall be included

## 10.5.2.11 Control Channel Description

The purpose of the Control Channel Description information element is to provide a variety of information about a cell.

The *Control Channel Description* information element is coded as shown in figure 10.5.33/3GPP TS 04.08 and table 10.5.33/3GPP TS 04.08.

The Control Channel Description is a type 3 information element with 4 octets length.

	8	7	6	5	4	3	2	1	L		
Ī			Contro	ol Char	nnel De	escript	ion IE	EI	octet 1	1	
Ĭ	0 spare	ATT	ATT BS-AG-BLKS-RES CCCH-CONF								
Ĭ	0 spare	0 spare	0 spare	0 spare	0 spare	BS-	-PA-MFF	RMS	octet 3	3	
+			_	3212 out val	lue				octet 4	4	

Figure 10.5.33/3GPP TS 04.08: Control Channel Description information element

Table 10.5.33/3GPP TS 04.08: Control Channel Description information element

ATT, Attach-detach allowed (octet 2) Bit 7 0 MSs in the cell are not allowed to apply IMSI attach and detach procedure. MSs in the cell shall apply IMSI attach 1 and detach procedure. BS-AG-BLKS-RES (octet 2) The BS-AG-BLKS-RES field is coded as the binary representation of the number of blocks reserved for access grant. Range 0 to 2 if CCCH-CONF = "001" 0 to 7 for other values of CCCH-CONF All other values are reserved in the first case CCCH-CONF (octet 2) bits  $\begin{array}{ccc} 3 & 2 & 1 \\ 0 & 0 & 0 \end{array}$ 1 basic physical channel used for CCCH, not combined with SDCCHs 1 basic physical channel used for CCCH, combined with SDCCHs 0 0 1 0 1 0 2 basic physical channel used for CCCH, not combined with SDCCHs 3 basic physical channel used for CCCH, 1 0 0 not combined with SDCCHs 4 basic physical channels used for CCCH, not combined with SDCCHs 1 1 0 all other values are reserved BS-PA-MFRMS (octet 3) Bits  $\begin{array}{ccc} 3 & 2 & 1 \\ 0 & 0 & 0 \end{array}$ 2 multiframes period for transmission of PAGING REQUEST messages to the same paging subgroup 0 0 1 3 multiframes period for transmission of PAGING REQUEST messages to the same paging subgroup 4 multiframes period for transmission of PAGING REQUEST messages to the same paging subgroup 0 1 0 1 1 1 9 multiframes period for transmission of PAGING REQUEST messages to the same paging subgroup Note: The number of different paging subchannels on the CCCH is: for other values of CCCH-CONF T3212 timeout value (octet 4) The T3212 timeout value field is coded as the binary representation of the timeout value for periodic updating in decihours. Range: 1 to 255 The value 0 is used for infinite timeout value i.e. periodic updating shall not be used within the cell. \_\_\_\_\_

# 10.5.2.12 Frequency Channel Sequence

The purpose of the *Frequency Channel Sequence* information element is to provide the absolute radio frequency channel numbers used in the mobile hopping sequence. This information element shall only be used for radio frequency channels in the primary GSM band (see 3GPP TS 05.05).

The *Frequency Channel Sequence* information element is coded as shown in figure 10.5.34/3GPP TS 04.08 and table 10.5.34/3GPP TS 04.08.

The Frequency Channel Sequence is a type 3 information element with 10 octets length.

8 6 4 5 3 2 Frequency Channel Sequence IEI octet 1 \_\_\_\_\_ 0 Lowest ARFCN octet 2 spare inc skip of ARFCN 01 | inc skip of ARFCN 02 octet 3 -----\_\_\_\_\_ +----inc skip of ARFCN 15 | inc skip of ARFCN 16 octet 10 -----+

Figure 10.5.34/3GPP TS 04.08: Frequency Channel Sequence information element

Table 10.5.34/3GPP TS 04.08: Frequency Channel Sequence information element

\_\_\_\_\_ Lowest ARFCN (octet 2) The lowest ARFCN field is coded as the binary representation of the lowest absolute RF channel number appearing in the sequence of channels used in the frequency hopping. Range: 1 to 124 All other values are reserved. Increment skip ARFCN n (octet 3 to 10) The increment skip ARFCN n is coded as the binary representation of the increment of the preceding absolute RF channel number appearing in the sequence of channels used in the frequency hopping: n = 1,...,16. Range: 0 to 15 The value 0 indicates that the increment value is 15 but the concerned channel is not used and the next field, i.e. Increment skip ARFCN n+1 (if present) must be added to the increment to determine the next absolute RF channel number in the sequence of channels used in the frequency hopping.

# 10.5.2.13 Frequency List

The purpose of the *Frequency List* information element is to provide the list of the absolute radio frequency channel numbers used in a frequency hopping sequence.

The Frequency List information element is a type 4 information element.

There are several formats for the *Frequency List* information element, distinguished by the "format indicator" subfield. Some formats are frequency bit maps, the others use a special encoding scheme.

## 10.5.2.13.1 General description

Table 10.5.35/3GPP TS 04.08: Frequency List information element, general format

```
FORMAT-ID, Format Identifier (part of octet 3)
The different formats are distinguished by the FORMAT-ID field. The possible values are the
following:
                                format notation
  Bit Bit Bit Bit Bit
         7
   8
              4
                    3
                         2
   0
        0
                  х х
                                                 bit map 0
             Х
               0 X
1 0
                                                  1024 range
         0
   1
                           Х
                                                 512 range
256 range
128 range
         õ
   1
1
                           0
                    Ō
         0
               1
                           1
   1
         0
               1
                     1
                           0
                                                  variable bit map
   1
         0
               1
                     1
                           1
All other combinations are reserved for future use. A GSMß900 mobile station which only supports the primary GSMßband P-GSMß900 (cf. GSMß05.05) may consider all values except the value for bit map 0 as reserved.
The significance of the remaining bits depends on the FORMAT-ID. The different cases are specified in
the next sub-clauses.
```

### 10.5.2.13.2 Bit map 0 format

	8	7	6	5	4	3	2	1	
ļ			octet 1						
	0 Le	0 ength d	0 of free	1 quency	0 list d	0 content	0 IS	0	octet 2
Ī	0 FORMAT	0 Г-ID	0 spa	0 are	ARFCN 124	ARFCN 123	ARFCN 122	ARFCN 121	octet 3
	ARFCN 120	ARFCN 119	ARFCN 118	ARFCN 117		ARFCN 115	ARFCN 114	ARFCN 113	octet 4
+	ARFCN 008	ARFCN 007	ARFCN 006	ARFCN 005	ARFCN 004	ARFCN 003	ARFCN 002	ARFCN 001	octet 18

Figure 10.5.35/3GPP TS 04.08: Frequency List information element, bit map 0 format

Table 10.5.36/3GPP TS 04.08: Frequency List information element, bit map 0 format

ARFCN N, Absolute RF Channel Number N (octet 3 etc.) For a RF channel with ARFCN = N belonging to the frequency list the ARFCN N bit is coded with a "1"; N = 1, 2, ..., 124. For a RF channel with ARFCN = N not belonging to the frequency list the ARFCN N bit is coded with a "0"; N = 1, 2 ..., 124.

## 10.5.2.13.3 Range 1024 format

The information element contains a header, and W(1) to W(M) for some M. If, due to octet boundaries, some bits are not used at the end of the last octet, these bits must be set to 0.

8 7 б 5 4 3 2 1 ------\_\_\_\_\_+ Frequency List IEI octet 1 octet 2 Length of Frequency List contents \_\_\_\_\_ octet 3 \_\_\_\_\_ W(1) (low part) octet 4 -----W(2) to W(3) are on 9 bits, when present W(4) to W(7) are on 8 bits, when present W(8) to W(15) are on 7 bits, when present W(16) to W(31) are on 6 bits, when present  $W(2^k)$  to  $W(2^{(k+1)}-1)$  are on 10-k bits when present and so on \_\_\_\_\_

Figure 10.5.36/3GPP TS 04.08: Frequency List information element (Range 1024 format)

**ETSI** 

```
F0, frequency 0 indicator (octet 3, bit 3):
          ARFCN 0 is not a member of the set
          ARFCN 0 is a member of the set
1
W(i), i from 1 to M (octet 3 and next):
Each W(i) encodes a non negative integer in binary
format.
If W(k) is null, W(i) for i > k must be null also.
Each non null W(k) allows to compute, together with
some previous W(i) the ARFCN F(k) of a frequency in the set. The first computation formulas are given
hereafter, with the following conventions:
   Wi denotes W(i);
   Fi denotes F(i);
         indicates the natural integer addition;
       indicates the natural integer multiplication;
   n mod m indicates the remainder of the euclidian division of n by m, ie 0 \le (n \mod m) \le m-1 and there exists k such that n = (k*m) + (n \mod m);
   n smod m indicates the offset remainder of the euclidian division of n by m, ie 1 \le (n \mod m) \le m and there exists k such that
      n = (k*m) + (n \mod m);
     F1 = W1

F2 = (W1 - 512 + W2) \mod 1023
     F3 = (W1)
                              + W3) smod 1023
     F4 = (W1 - 512 + (W2 - 256 + W4) \text{ smod } 511) \text{ smod } 1023

F5 = (W1 - 4000 + (W3 - 256 + W5) \text{ smod } 511) \text{ smod } 1023
    F5 = (W1 - 512 + (W2 + W6) \text{ smod } 511) \text{ smod } 1023
F7 = (W1 - 512 + (W2 + W6) \text{ smod } 511) \text{ smod } 1023
F8 = (W1 - 512 + (W2 - 256 + (W4 - 128 + W8))
                smod 255) smod 511) smod 1023
W1 + (W3 - 256 + (W5 - 128 + W9))
   F9 = (W1)
   F9 = (W1 + (W3 - 256 + (W5 - 128 + W9))

smod 255) smod 511) smod 1023

F10 = (W1 - 512 + (W2 + (W6 - 128 + W10))

smod 255) smod 511) smod 1023

F11 = (W1 + (W3 + (W7 - 128 + W11)))

smod 255) smod 511) smod 1023

F12 = (W1 - 512 + (W2 - 256 + (W4 - 128 + W12)))
   F12 = (W1 - 512 + (W2 - 256 + (W4
                                                                           + W12)
                smod 255) smod 511) smod 1023
W1 + (W3 - 256 + (W5
   F13 = (W1)
                                                                         + W13)
    \begin{array}{c} \text{F13} = (\text{W1} + (\text{W3} - 230 + (\text{W3} - 230)) \\ \text{smod } 255) \text{ smod } 511) \text{ smod } 1023 \\ \text{F14} = (\text{W1} - 512 + (\text{W2} + (\text{W6} - 512))) \\ \text{smod } 255) \text{ smod } 511) \text{ smod } 1023 \\ \end{array} 
                                                                          + W14)
           = (W1 + (W3 + (W7 + W7)))
smod 255) smod 511) smod 1023
= (W1 - 512 + (W2 - 256 + (W4 - 128 + (W8 - 64 + W16))))
smod 127)
= (W8 - 64 + W16) 
smod 127)
   F15 = (W1)
                                                                          + W15)
   F16
                smod 255) smod 511) smod 1023
More generally, the computation of F(K) can be done
with the following program, using ADA language (declarative parts are skipped and should be obvious):
INDEX := K;
J := GREATEST_POWER_OF_2_LESSER_OR_EQUAL_TO(INDEX);
N := W(INDEX);
while INDEX>1 loop
if 2*INDEX < 3*J then
      INDEX := INDEX - J/2; ---
N := (N + W(PARENT) - 1024/J - 1) mod
                                                                     -- left child
                 (2048/J - 1) + 1;
   else
                                                                   -- right child
       INDEX := INDEX - J;
      N := (N + W(PARENT) - 1) mod (2048/J - 1) + 1;
   end if;
```

	J := J/2; end loop; F(K) := N;	
-	+	÷

## 10.5.2.13.4 Range 512 format

The information element contains a header, and W(1) to W(M) for some M. If, due to octet boundaries, some bits are not used at the end of the last octet, these bits must be set to 0.

8 7 6 5 4 3 2 1 \_\_\_\_\_ Frequency List IEI octet 1 \_\_\_\_\_ octet 2 Length of Frequency List contents 1 0 0 1 0 | 0 | 0 | ORIGoctet 3 FORMAT-ID spare spare FORMAT-ID ARFCN high ORIG-ARFCN (middle part) octet 4 \_ \_ \_ \_ \_ \_ \_\_\_\_\_ ORIG-W(1) octet 5 ARFCN (high part) low \_ \_ \_ -W(1) W(2) octet 6 (low part) (high part) \_\_\_\_\_ W(2) to W(3) are on 8 bits, when present W(4) to W(7) are on 7 bits, when present W(8) to W(15) are on 6 bits, when present W(16) to W(31) are on 5 bits, when present  $W(2^k)$  to  $W(2^{(k+1)}-1)$  are on 9-k bits when present and so on . \_\_\_\_\_ ---+

Figure 10.5.37/3GPP TS 04.08: Frequency List information element (Range 512 format)

#### Table 10.5.38/3GPP TS 04.08: Frequency List information element, range 512 format

ORIG-ARFCN, origin ARFCN (octet 3, 4 and 5) This field encodes the ARFCN of one frequency belonging to the set. This value is also used to decode the rest of the element. W(i), i from 1 to M (octet 5 and next): Each W(i) encodes a non negative integer in binary format If W(k) is null, W(i) for i>k must be null also. Each non null W(k) allows to compute, together with some previous W(i) the ARFCN F(k) of a frequency in the set. The first computation formulas are given hereafter, with the following conventions: Wi denotes W(i); W0 denotes the value of ORIG-ARFCN Fi denotes F(i); indicates the natural integer addition; indicates the natural integer multiplication; n mod m indicates the remainder of the euclidian division of n by m, ie  $0 \le (n \mod m) \le m-1$  and there exists k such that  $n = (k*m) + (n \mod m);$ smod m indicates the offset remainder of the euclidian division of n by m, ie n smod m  $1 \le (n \mod m) \le m$  and there exists k such that  $n = (k*m) + (n \mod m);$ F1  $= (W0 + W1) \mod 1024$  $= (W0 + W1) \mod 1024$ = (W0 + (W1 - 256 + W2) smod 511) mod 1024 = (W0 + (W1 + W3) smod 511) mod 1024 = (W0 + (W1 - 256 + (W2 - 128 + W4) smod 255) F2 F3 F4 smod 511) mod 1024 = (W0 + (W1 + (W3smod 511) mod 1024)= (W0 + (W1 - 256 + (W2smod 511) mod 1024)F5  $(W3 - 128 + W5) \mod 255)$ Fб + W6) smod 255) + W13) + W14) + W15) smod 63) smod 127) smod 255) smod 511) mod 1024 More generally, the computation of F(K) can be done with the following program, using ADA language (declarative parts are skipped and should be obvious): INDEX := K; J := GREATEST\_POWER\_OF\_2\_LESSER\_OR\_EQUAL\_TO(INDEX); N := W(INDEX); while INDEX>1 loop

```
if 2*INDEX < 3*J then -- left child
INDEX := INDEX - J/2;
N := (N + W(PARENT) - 512/J - 1) mod
(1024/J - 1) + 1;
else -- right child
INDEX := INDEX - J;
N := (N + W(_INDEX) - 1) mod (1024/J - 1) + 1;
end if;
J := J/2;
end loop;
F(K) := (W(0) + N) mod 1024;
```

## 10.5.2.13.5 Range 256 format

The information element contains a header, and W(1) to W(M) for some M. If, due to octet boundaries, some bits are not used at the end of the last octet, these bits must be set to 0.

```
7
  8
             6
                    5
                                      2
                                            1
                          4
                                3
            Frequency List IEI
                                                 octet 1
            _ _ _ _
                _ _ _ _ _ _
                      ____
                            - - - -
                                                 octet 2
    Length of Frequency List contents
  1
       0
             0
                   0
                         1
                               0
                                      1
                                          ORIG-
                                          ARFCN
                                                 octet 3
 FORMAT-ID
                           FORMAT-ID
           spare spare
                                          high
        ORIG-ARFCN (middle part)
                                                 octet 4
                    W(1)
ORIG-
                                                 octet 5
ARFCN
                 (high part)
low
W(1)
                    W(2)
                                                 octet 6
low
       -----
W(2) to W(3) are on 7 bits, when present
 W(4) to W(7) are on 6 bits, when present
 W(8) to W(15) are on 5 bits, when present
 W(16) to W(31) are on 4 bits, when present
 W(2^k) to W(2^{(k+1)}-1) are on 8-k bits when present
 and so on
```

Figure 10.5.38/3GPP TS 04.08: Frequency List information element (Range 256 format)

Table 10.5.39/3GPP TS 04.08: Frequency List information element, range 256 format

\_\_\_\_\_

ORIG-ARFCN, origin ARFCN (octet 3, 4 and 5) This field encodes the ARFCN of one frequency belonging to the set. This value is also used to decode the rest of the element. W(i), i from 1 to M (octet 5 and next): Each W(i) encodes a non negative integer in binary format. If W(k) is null, W(i) for i > k must be null also. Each non null W(k) allows to compute, together with some previous W(i) the ARFCN F(k) of a frequency in the set. The first computation formulas are given hereafter, with the following conventions: Wi denotes W(i); W0 denotes the value of ORIG-ARFCN Fi denotes F(i); indicates the natural integer addition; indicates the natural integer multiplication; n mod m indicates the remainder of the euclidian division of n by m, ie  $0 \le (n \mod m) \le m-1$  and there exists k such that  $n = (k*m) + (n \mod m);$ n smod m indicates the offset remainder of the euclidian division of n by m, ie  $1 \le (n \mod m) \le m$  and there exists k such that  $n = (k*m) + (n \mod m);$  $= (W0 + W1) \mod 1024$ F1  $= (W0 + (W1 - 128 + W2) \mod 255) \mod 1024$ = (W0 + (W1 - 128 + W3) smod 255) mod 1024 = (W0 + (W1 - 128 + (W2 - 64 + W4) smod 127) smod 255) F2 F3 F4 mod 1024 F5 = (W0 +(W1 + (W3 - 64 + W5) smod 127) smod 255) mod 1024 = (W0 + (W1 - 128 + (W2F6 + W6) smod 127) smod 255) mod 1024 F7 = (W0 + (W1))+ (W3 + W7) smod 127) smod 255) mod 1024 = (W0 + (W1 - 128 + (W2 - 64 + (W4 - 32 + W8)) smod 63)F8 smod 127 smod 255 mod 1024= (W0 + (W1 + (W3 - 64 + (W5 - 32 + W9 ) smod 63) F9 = (W0 + (W1)) $\begin{array}{rcl} F9 &= (W0 + (W1 & + (W3 - 64 + (W5 - smod 127) smod 255) mod 1024 \\ F10 &= (W0 + (W1 - 128 + (W2 & + (W6 - smod 127) smod 255) mod 1024 \\ F11 &= (W0 + (W1 & + (W3 & + (W7 - smod 127) smod 255) mod 1024 \\ F12 &= (W0 + (W1 - 128 + (W2 - 64 + (W4 - smod 127) smod 255) mod 1024 \end{array}$  $+ (W6 - 32 + W10) \mod 63)$  $+ (W7 - 32 + W11) \mod 63)$ + W12) smod 63) smod 127) smod 255) mod 1024 F13 = (W0 + (W1 + (W3 - 64 + + (W3 - 64 + (W5))+ W13) smod 63) F13 = (W0 + (W1 + (W3 - 04 + smod 127) smod 255) mod 1024 F14 = (W0 + (W1 - 128 + (W2 + smod 127) smod 255) mod 1024 + (₩б + W14) smod 63) F15 = (W0 + (W1 + (W3 + W3 + W3))) + (W1 + (W3 + W3)) + (W1 + (W3 + W3)) + (W1 + (W1 + (W1 + W3)) + (W1 + (W1 + (W1 + W3)) + (W1 + (W1 + (W1 + (W1 + W3))) + (W1 + (W1 + (W1 + (W1 + (W1 + (W1 + W3))) + (W1 ++ (W7 + W15) smod 63)  $\begin{array}{c} F16 = (W0 + (W1 - 128 + (W2 - 64 + (W4 - 32 + (W8 - smod 31) smod 63) smod 127) smod 255) mod 1024 \\ \end{array}$ - 16 + W16)  $\begin{array}{l} \text{F17} = (W0 + (W1 + (W3 - 64 + (W5 - 32 + (W9 - \text{smod } 31) \text{ smod } 63) \text{ smod } 127) \text{ smod } 255) \text{ mod } 1024 \\ \text{F18} = (W0 + (W1 - 128 + (W2 + (W6 - 32 + (W10 - \text{smod } 31) \text{ smod } 63) \text{ smod } 127) \text{ smod } 255) \text{ mod } 1024 \\ \text{F19} = (W0 + (W1 + (W3 + (W7 - 32 + (W11 - \text{smod } 31) \text{ smod } 63) \text{ smod } 127) \text{ smod } 255) \text{ mod } 1024 \\ \text{F19} = (W0 + (W1 + (W3 + (W7 - 32 + (W11 - \text{smod } 31) \text{ smod } 63) \text{ smod } 127) \text{ smod } 255) \text{ mod } 1024 \\ \end{array}$ 16 + W17)- 16 + W18) 16 + W19)(W1 - 128 + (W2 - 64 + (W4F20 = (W0 ++ (W12 16 + W20)smod 31) smod 63) smod 127) smod 255) mod 1024 =(W0 + (W1 + (W3 - 64 + (W5 + (W13 -smod 31) smod 63) smod 127) smod 255) mod 1024 F21 = (W0 + (W1))+ (W13 - 16 + W21) More generally, the computation of F(K) can be done with the following program, using ADA language (declarative parts are skipped and should be obvious):

## 10.5.2.13.6 Range 128 format

The information element contains a header, and W(1) to W(M) for some M. If, due to octet boundaries, some bits are not used at the end of the last octet, these bits must be set to 0.

```
7
 8
           б
                5
                               2
                     4
                        3
                                    1
          Frequency List IEI
                                        octet 1
         _____
                  _____
                                        octet 2
   Length of Frequency List contents
      0
           0
               0
                     1
                       1 0
                                  ORIG-
 1
                                  ARFCN
                                        octet 3
FORMAT-ID
                     FORMAT-ID
         spare spare
                                   high
      ORIG-ARFCN (middle part)
                                        octet 4
      -------
                 W(1)
ORIG-
                                        octet 5
ARFCN
              (high part)
low
         _____
W(2) to W(3) are on 6 bits, when present
W(4) to W(7) are on 5 bits, when present
W(8) to W(15) are on 4 bits, when present
W(16) to W(31) are on 3 bits, when present
W(2^k) to W(2^{(k+1)}-1) are on 7-k bits when present
and so on
 -----+
```

Figure 10.5.39/3GPP TS 04.08: Frequency List information element (Range 128 format)

Table 10.5.40/3GPP TS 04.08: Frequency List information element, range 128 format

ORIG-ARFCN, origin ARFCN (octet 3, 4 and 5) This field encodes the ARFCN of one frequency belonging to the set. This value is also used to decode the rest of the element. W(i), i from 1 to M (octet 5 and next): Each W(i) encodes a non negative integer in binary format. If W(k) is null, W(i) for i>k must be null also. Each non null W(k) allows to compute, together with some previous W(i) the ARFCN F(k) of a frequency in the set. The first computation formulas are given hereafter, with the following conventions: Wi denotes W(i); WO denotes the value of ORIG-ARFCN Fi denotes F(i); indicates the natural integer addition; indicates the natural integer multiplication; n mod m indicates the remainder of the euclidian division of n by m, ie  $0 \le (n \mod m) \le m-1$  and there exists k such that  $n = (k*m) + (n \mod m);$ n smod m indicates the offset remainder of the euclidian division of n by m, ie  $1 \le (n \mod m) \le m$  and there exists k such that  $n = (k*m) + (n \mod m);$  $F1 = (W0 + W1) \mod 1024$  $F_{2} = (W0 + (W1 - 64 + W2) \text{ smod } 127) \text{ mod } 1024$   $F_{3} = (W0 + (W1 - 64 + W3) \text{ smod } 127) \text{ mod } 1024$   $F_{4} = (W0 + (W1 - 64 + (W2 - 32 + W4) \text{ smod } 63) \text{ smod } 127)$ mod 1024 F5 = (W0 +(W1 + (W3 - 32 + W5) smod 63) smod 127) mod 1024 F6 = (W0 + (W1 - 64 + (W2 + W6) smod 63) smod 127)mod 1024 F7 = (W0 + (W1))+ (W3 + W7) smod 63) smod 127) mod 1024 (W1 - 64 + (W2 - 32 + (W4 - 16 + W8)) smod 31)F8 = (WO +smod 63) smod 127) mod 1024 = (W0 + (W1 + (W3 - 32 + (W5 - 16 + W9 ) smod 31) F9 = (W0 + (W1))smod 63) smod 127) mod 1024 F10 = (W0 + (W1 - 64 + (W2 + smod 63) smod 127) mod 1024 $+ (W6 - 16 + W10) \mod 31)$ F11 = (W0 + (W1 + (W3 + (W7 - smod 63) smod 127) mod 1024F12 = (W0 + (W1 - 64 + (W2 - 32 + (W4 + (W2 - 32) + (W4 + (W4 - 64))))+ (W7 - 16 + W11) smod 31) + W12) smod 31) smod 63) smod 127) mod 1024 = (W0 + (W1 + (W3 - 32 + (W5 F13 = (W0 + (W1))+ W13) smod 31) smod 63) smod 127) mod 1024 F14 = (W0 + (W1 - 64 + (W2 + smod 63) smod 127) mod 1024+ (Жб + W14) smod 31) F15 = (W0 + (W1))+ (W3 + (W7 + W15) smod 31)  $\begin{array}{c} \text{F15} = (W0 + (W1 + (W3 + (W7 + W15)) \\ \text{smod } 63) \text{ smod } 127) \text{ mod } 1024 \\ \text{F16} = (W0 + (W1 - 64 + (W2 - 32 + (W4 - 16 + (W8 - \\ \text{smod } 15) \text{ smod } 31) \text{ smod } 63) \text{ smod } 127) \text{ mod } 1024 \\ \text{F17} = (W0 + (W1 + (W3 - 32 + (W5 - 16 + (W9 + (W1 + (W3 - 32 + (W5 - 16 + (W9 + (W1 + (W3 - 32 + (W5 - 16 + (W9 + (W1 + (W3 - 32 + (W5 - 16 + (W9 + (W1 + (W3 - 32 + (W5 - 16 + (W9 + (W1 + (W3 - 32 + (W5 - 16 + (W9 + (W1 + (W3 - 32 + (W5 - 16 + (W9 + (W1 + (W3 - 32 + (W5 - 16 + (W9 + (W1 + (W1 + (W3 - 32 + (W5 - 16 + (W9 + (W1 + (W1 + (W1 + (W3 + 16 + (W1 +$ - 8 + W16)  $\begin{array}{rcl} F17 &= (W0 + (W1 & + (W3 - 32 + (W5 - 16 + (W9 - 8 + W17 \\ & \text{smod } 15) \text{ smod } 31) \text{ smod } 63) \text{ smod } 127) \text{ mod } 1024 \\ F18 &= (W0 + (W1 - 64 + (W2 & + (W6 - 16 + (W10 - 8 + W18) \\ & \text{w18}) \text{ smod } 16 + (W10 - 8 + W18) \\ \end{array}$ -8 + W17) smod 15) smod 31) smod 63) smod 127) mod 1024 F24 = (W0 + (W1 - 64 + (W2 - 32 + (W4 - 16 + (W8 - 16)))))+ W24)

smod 15) smod 31) smod 63) smod 127) mod 1024
= (W0 + (W1 + (W3 - 32 + (W5 - 16 + (W9
smod 15) smod 31) smod 63) smod 127) mod 1024 F25 = (W0 + (W1))+ W25) F26 = (W0 + (W1 - 64 + (W2 + (W6 - 16 + (W10 smod 15) smod 31) smod 63) smod 127) mod 1024+ W26) F27 = (W0 + (W1 + (W3 + (W7 - 16 + (W11 smod 15) smod 31) smod 63) smod 127) mod 1024+ W27) F28 = (W0 + (W1 - 64 + (W2 - 32 + (W4 + (W12 smod 15) smod 15) smod 31) smod 63) smod 127) mod 1024+ W28 = (W0 + (W1 + (W3 - 32 + (W5 + (W13 smod 15) smod 31) smod 63) smod 127) mod 1024 F29 = (W0 + (W1))+ W29 More generally, the computation of F(K) can be done with the following program, using ADA language (declarative parts are skipped and should be obvious): INDEX := K; J := GREATEST\_POWER\_OF\_2\_LESSER\_OR\_EQUAL\_TO(INDEX); N := W(INDEX);N -= W(INDEX)/ while INDEX>1 loop if 2\*INDEX < 3\*J then -- left child INDEX := INDEX - J/2; N := (N + W(INDEX) - 128/J - 1) mod (256/J - 1) + 1; -- right c INDEX := INDEX - J; N := (N + W(INDEX) - 1) mod (256/J - 1) + 1; end if; -- right child J := J/2;end loop;  $F(K) := (W(0) + N) \mod 1024;$ \_\_\_\_\_

10.5.2.13.7 Variable bit map format




Figure 10.5.40/3GPP TS 04.08: Frequency List information element, variable bit map format

Table 10.5.41/3GPP TS 04.08: Frequency List information element, variable bit map format

ORIG-ARFCN, origin ARFCN (octet 3, 4 and 5) This field encodes the ARFCN of one frequency belonging to the set. This value is also used as origin of the bit map to generate all the other frequencies. RRFCN N, relative radio frequency channel number N (octet 5 etc.) For a RF channel with ARFCN = (ORIG-ARFCN + N) mod 1024 belonging to the set, RRFCN N bit is coded with a "1"; N = 1, 2, ..., 8M+7 with  $1 \le M \le 127$ For a RF channel with ARFCN = (ORIG-ARFCN + N) mod 1024 not belonging to the set, RRFCN N bit is coded with a "0"; N = 1, 2, ..., 8M+7 with  $1 \le M \le 127$ 

## 10.5.2.14 Frequency Short List

The purpose of the *Frequency Short List* information element is to provide the list of the absolute radio frequency channel numbers used in a frequency hopping sequence, in a small fixed length information element to obtain when possible the HANDOVER COMMAND message in a single block.

The Frequency Short List information element is a type 3 information element of 10 octet length.

This element is encoded exactly as the *Frequency List* information element, except that it has a fixed length instead of a variable length and does not contain a length indicator and that it shall not be encoded in bitmap 0 format.

# 10.5.2.14a Frequency Short List 2

The purpose of the *Frequency Short List 2* information element is to provide the list of the absolute radio frequency channel numbers used in a frequency hopping sequence, in a small fixed length information element to obtain the SYSTEM INFORMATION TYPE 11 and NOTIFICATION FACCH messages in a single block.

The Frequency Short List information element is a type 3 information element of 8 octet length.

This element is encoded exactly as the *Frequency List* information element, except that it has a fixed length instead of a variable length and does not contain a length indicator and that it shall not be encoded in bitmap 0 format.

# 10.5.2.14b Group Channel Description

The purpose of the *Group Channel Description* information element is to provide a description of an allocable voice group call or voice broadcast call channel together with its SACCH and that part of the RF channels belonging to the cell allocation which is used in the mobile hopping sequence if applicable.

The *Group Channel Description* information element is coded as shown in figure 10.5.41/3GPP TS 04.08 and table 10.5.42/3GPP TS 04.08.

The Group Channel Description is a type 4 information element with 4 to 13 octets length.

	8	7	б	5	4	3	2	1	1	
Į	Group Channel Description IEI Length of mobile allocation contents									: 1
Ī										2
	Channel type and TDMA offset TN								octet	53
-		TSC		H=1-> +- H H=0->	+	 D	gh par  ARF( (high		octet	- 4
+	MAIO HSN (low part)								octet	- 5
ļ	ARFCN (low part)								UCLEI	_ J
+	MA C 8n	MA C 8n-1	MA C 8n-2	MA C 8n-3	MA C 8n-4	MA C 8n-5	MA C 8n-6	MA C 8n-7	octet	5 6
+		+	+	+	+	+	+	+		
	MA C 008	MA C 007	MA C 006	MA C 005	MA C 004	MA C 003	MA C 002	MA C 001	octet	n+5

Figure 10.5.41/3GPP TS 04.08: Group Channel Description information element

Table 10.5.42/3GPP TS 04.08: Group Channel Description information element

Channel type and TDMA offset (octet 3) Bits 7654 8 TCH/FS + ACCHs (speech codec version 1) 0 0 0 0 1 0 0 0 1 T 0 0 1 T T TCH/HS + ACCHs (speech codec version 1) SDCCH/4 + SACCH/C4 0 1 T T T SDCCH/8 + SACCH/C8 The T bits indicate the subchannel number coded in binary. All other values are reserved for future use. TN, Timeslot number (octet 3) The TN field is coded as the binary representation of the timeslot number as defined in GSMB05.10. Range: 0 to 7. TSC, Training Sequence Code (octet 4) The TSC field is coded as the binary representation of the Training Sequence code as defined in GSM ß 05.03 Range: 0 to 7. H, Hopping channel (octet 4) Bit 5 0 Single RF channel RF hopping channel 1 Note 1: The value of H affects the semantics of the channel selector field Note 2: If H=0, the information element terminates with octet 5 Channel selector (octet 4 and 5) H = "0": The channel selector field consists of the absolute RF channel number Octet 4 Bits 4 3 0 0 Spare ARFCN, (octet 4, bits 2 and 1, and octet 5, bits 8 to 1) The ARFCN is coded as the binary representation of the absolute RF channel number Range: 0 to 1023 H = "1": The channel selector field consists of the mobile allocation index offset, MAIO, and the hopping sequence number, HSN. Range: 0 to 63. HSN, (octet 5 bit 6 to 1) The HSN field is coded as the binary representation of the hopping sequence number as defined in GSMB05.02 Range 0 to 63. MA C i, Mobile allocation RF channel i (octet 4 etc.), i = 1, 2, ..., NF The MA C i bit indicates whether or not the Mobile allocation frequency list includes the i'th frequency in the cell allocation frequency list. In the cell allocation frequency list the absolute

RF channel numbers are placed in increasing order of ARFCN, except that ARFCN 0, if included in the set, is put in the last position in the list, For a RF channel belonging to the mobile allocation the MA C i bit is coded with a "1"; i = 1, 2,..., NF. For a RF channel not belonging to the mobile allocation the MA C i bit is coded with a "0"; i = 1, 2,..., NF. If NF mod 8 <> 0 then bits NF to 8n in octet 4 must be coded with a "0" in each.

# 10.5.2.14c GPRS Resumption

The purpose of the *GPRS Resumption* information element is to indicate whether the network has successfully resumed GPRS services or not.

The *GPRS Resumption* information element is coded as shown in figure 10.5.42/3GPP TS 04.08 and table 10.5.43/3GPP TS 04.08.

The GPRS Resumption is a type 1 information element.

	8	7	6	5	4	3	2	1	L
Į	GPRS resumption IEI			spare 0 0 0			ACK	octet 1	

## Figure 10.5.42/3GPP TS 04.08: GPRS Resumption information element

### Table 10.5.43/3GPP TS 04.08: GPRS Resumption information element

The ACK field (1 bit) is the binary acknowledge of a successful resumption of GPRS services:

- 0 resumption of GPRS services not successfully acknowledged;
- 1 resumption of GPRS services successfully acknowledged.

# 10.5.2.15 Handover Reference

The purpose of the *Handover Reference* information element is to provide a handover reference value used for access identification.

The *Handover Reference* information element is coded as shown in figure 10.5.43/3GPP TS 04.08 and table 10.5.44/3GPP TS 04.08.

The Handover Reference is a type 3 information element with 2 octets length.




Figure 10.5.43/3GPP TS 04.08: Handover Reference information element

Table 10.5.44/3GPP TS 04.08: Handover Reference information element

```
Handover reference value (octet 2)
The handover reference value field is coded using
binary representation.
Range: 0 to 255.
```

### 10.5.2.16 IA Rest Octets

The *IA Rest Octets* information element contains spare bits and possibly either a *packet uplink assignment* construction, a *packet downlink assignment* construction, a *second part packet assignment* construction or a *frequency parameters*, *before time* construction.

The *frequency parameters, before time* construction combines a mobile allocation (see 10.5.2.21) and a MAIO (see the *channel description* information element).

The *IA Rest Octets* information element is coded according to the syntax specified below and described in table 10.5.45/3GPP TS 04.08.

The IA Rest Octets information element is a type 5 information element with 1-12 octets length.

```
<IA Rest Octets> ::=
          { LL
          |LH
          | HL
             < Length of frequency parameters : bit (6) >
             < Frequency Parameters, before time >
          | HH
             { 00 < Packet Uplink Assignment >
                  < Packet Downlink Assignment >
             01
                   < Second Part Packet Assignment : null > }
             1
          }
          <spare padding>;
< Packet Uplink Assignment > ::=
            { 1
             < TFI ASSIGNMENT : bit (5) >
             < POLLING : bit >
             { 0
                                              -- Dynamic Allocation
                \langle \mathbf{USF}: \text{bit} (3) \rangle
                < USF GRANULARITY : bit >
                   \{ 0 \mid 1 < \mathbf{P0} : \text{bit } (4) >
                   < PR_MODE : bit (1) > }
            | 1
                                              -- Fixed Allocation
                < ALLOCATION_BITMAP_LENGTH : bit (5) >
                < ALLOCATION_BITMAP : bit (val(ALLOCATION_BITMAP_LENGTH)) >
                \{ 0 \mid 1 < \mathbf{P0} : bit (4) >
                   < BTS_PWR_CTRL_MODE : bit (1) >
                   < PR_MODE : bit (1) > }
             }
                < CHANNEL_CODING_COMMAND : bit (2) >
                   < TLLI_BLOCK_CHANNEL_CODING : bit >
          \{ 0 \mid 1 < ALPHA : bit (4) > \}
          \langle GAMMA : bit (5) \rangle
          { 0 | 1 < TIMING_ADVANCE_INDEX : bit (4) > }
          { 0 | 1 < TBF_STARTING_TIME : bit (16) > }
                   -- Single Block Allocation
        0
         \{ 0 | 1 < ALPHA : bit (4) > \}
          < GAMMA : bit (5) >
         01
               -- See Note 1
```

```
< TBF_STARTING_TIME : bit (16) >
 \{ L | H < P0 : bit (4) >
        < BTS_PWR_CTRL_MODE : bit (1) >
        < PR_MODE : bit (1) >}
};
< Packet Downlink Assignment > ::=
 < TLLI : bit (32) >
 {0|1
        < TFI ASSIGNMENT : bit (5) >
        < RLC MODE : bit >
        \{0 \mid 1 < ALPHA : bit (4) > \}
        \langle GAMMA : bit (5) \rangle
        < POLLING : bit >
        < TA_VALID : bit (1) >
  0 \mid 1 < \text{TIMING ADVANCE INDEX} : bit (4) > }
 { 0 | 1 < TBF_STARTING_TIME : bit (16) > }
 { 0 | 1 < P0 : bit (4) >
     < BTS_PWR_CTRL_MODE : bit (1) >
     < PR_MODE : bit (1) > } :
< Frequency Parameters, before time > ::=
 { null
                                  -- Length of frequency parameters = 0
    00
     < MAIO : bit (6) >
     < Mobile Allocation : octet (val (Length of frequency parameters) - 1)
 };
```

NOTE 1: A 'Timing Advance index' shall not be allocated at a Single Block allocation. A 'TBF Starting Time' shall be allocated at a Single Block allocation. The control bits set to fixed values to specify these requirements in a way compatible with early GPRS mobile stations in release 97.

## Table 10.5.45/3GPP TS 04.08: IA Rest Octet information element

### Packet Uplink Assignment

The POLLING field (1 bit) indicates if the MS is being polled for a PACKET CONTROL ACKNOWLEDGEMENT.

0 ; no action is required from MS.

1 : MS shall send a PACKET CONTROL ACKNOWLEDGEMENT message in the uplink block specified by TBF Starting Time, on the assigned PDCH.

The **TFI\_ASSIGNMENT** field (5 bit) is the binary representation of the Temporary Flow Identity, see 3GPP TS 04.60. Range: 0 to 31.

The **USF** field (3 bit) is the binary representation of the uplink state flag, see 3GPP TS 04.60. Range: 0 to 7.

The **USF\_GRANULARITY** field (1 bit) indicates the USF granularity to be applied by the mobile station when it is assigned a TBF using Dynamic Allocation, see 3GPP TS 04.60:

- 0 the mobile station shall transmit one RLC/MAC block;
- 1 the mobile station shall transmit four consecutive RLC/MAC blocks.

The **ALLOCATION\_BITMAP\_LENGTH** field (5 bit) specifies the number of bits in the ALLOCATION\_BITMAP. Range 0 to 31.

The **ALLOCATION\_BITMAP** field (variable length field) represents uplink radio blocks, each bit representing one radio block. Each bit indicates whether the mobile station is permitted to transmit during the corresponding uplink radio block. The bitmap describes a one dimensional array of block periods, indexed as follows:

block period[z]

z = n for n = 0 to L,

where:

L = number of bits in the ALLOCATION\_BITMAP - 1;

- z = block period relative to TBF\_STARTING\_TIME;
- n = bit number index into the ALLOCATION\_BITMAP, range 0 to L;
- TBF\_STARTING\_TIME indicates the first block period of the assigned allocation

The value of each bit is encoded as:

0 block period[n] is not part of the assigned allocation

1 block period[n] is part of the assigned allocation

The **CHANNEL\_CODING\_COMMAND** field (2 bit) indicates the coding scheme to be used for transmission, see 3GPP TS 05.03:

- 0.0 coding scheme 1, CS-1;
- 0 1 coding scheme 2, CS-2;
- 1 0 coding scheme 3, CS-3;
- 1 1 coding scheme 4, CS-4.

The **TLLI\_BLOCK\_CHANNEL\_CODING** field (1 bit) indicates the channel coding to be used for RLC data block comprising TLLI for contention resolution:

- 0 mobile station shall use CS-1;
- 1 mobile station shall use coding scheme as specified by the CHANNEL CODING COMMAND field.

The **ALPHA** field (4 bit) is the binary representation of the parameter  $\alpha$  for MS output power control, see 3GPP TS 05.08:

 $\begin{array}{rrrr} 0 & 0 & 0 & 0 & \alpha = 0.0 \\ 0 & 0 & 0 & 1 & \alpha = 0.1 \\ \vdots & & \vdots \\ 1 & 0 & 1 & 0 & \alpha = 1.0 \end{array}$ 

All other values are reserved in this version of the protocol and shall be interpreted by the mobile station as  $\alpha = 1.0$ .

The **GAMMA** field (5 bit) is the binary representation of the parameter  $\Gamma_{CH}$  for MS output power control in units of 2 dB, see 3GPP TS 05.08.

The **TIMING\_ADVANCE\_INDEX** field (4 bit) is the binary representation of the timing advance index (TAI), see 3GPP TS 05.10 and 3GPP TS 04.04. Range: 0 to 15.

The **TBF\_STARTING\_TIME** field (16 bit) defines a starting time for the packet uplink assignment. The TBF starting time is coded using the same coding as the V format of the type 3 information element *Starting Time* (10.5.2.38).

**P0** (4 bit field)

For description and encoding, see the Packet Uplink Assignment message in 3GPP TS 04.60.

**BTS\_PWR\_CTRL\_MODE** (1 bit field) For description and encoding, see the Packet Uplink Assignment message in 3GPP TS 04.60.

**PR\_MODE** (1 bit field)

For description and encoding, see the Packet Uplink Assignment message in 3GPP TS 04.60.

#### Packet Downlink Assignment

The **TLLI** field (32 bit) is the binary representation of a TLLI. The coding of TLLI is left open for each administration using the structure specified in 3GPP TS 03.03.

The **TFI\_ASSIGNMENT** field (5 bit) is the binary representation of the Temporary Flow Identity, see 3GPP TS 04.60. Range: 0 to 31.

The **RLC\_MODE** field (1 bit) indicates the RLC mode, see 3GPP TS 04.60:

- 0 RLC acknowledged mode;
- 1 RLC unacknowledged mode.

The **ALPHA** field (4 bit) and the **GAMMA** field (5 bit) are the binary representations of the respective parameters  $\alpha$  and  $\Gamma_{CH}$  for MS output power control, see *Packet Uplink Assignment* construction.

The POLLING field (1 bit) indicates if the MS is being polled for a PACKET CONTROL ACKNOWLEDGEMENT.

- 0 ; no action is required from MS.
- 1 : MS shall send a PACKET CONTROL ACKNOWLEDGEMENT message in the uplink block specified by TBF Starting Time, on the assigned PDCH.

The TA\_VALID field (1 bit) indicates the validity of the timing advance value given in the *Timing Advance* IE.

- 0 the timing advance value is not valid ;
- 1 the timing advance value is valid.

The **TIMING\_ADVANCE\_INDEX** field (4 bit) is the binary representation of the timing advance index (TAI), see 3GPP TS 05.10 and 3GPP TS 04.04. Range: 0 to 15.

The **TBF\_STARTING\_TIME** field (16 bit) defines a starting time for the packet downlink assignment. The TBF starting time is coded using the same coding as the V format of the type 3 information element *Starting Time* (10.5.2.38).

#### **P0** (4 bit field)

For description and encoding, see the Packet Uplink Assignment message in 3GPP TS 04.60.

#### BTS\_PWR\_CTRL\_MODE (1 bit field)

For description and encoding, see the Packet Uplink Assignment message in 3GPP TS 04.60.

#### **PR\_MODE** (1 bit field)

For description and encoding, see the Packet Uplink Assignment message in 3GPP TS 04.60.

### Second Part Packet Assignment

The presence of the Second Part Packet Assignment is the indication that this message is the second message of two IMMEDIATE ASSIGNMENT messages in an assignment of an uplink or downlink Temporary Block Flow (TBF).

### Frequency parameters, before time

#### Length of frequency parameters (6 bit field)

This field is coded as the binary representation of the number of octets occupied by the frequency parameters, before time field. If this length is 0, the frequency parameters, before time is not present.

The MAIO field (6 bit field) is coded as the binary representation of the mobile allocation index offset. Range: 0 to 63.

The **Mobile Allocation** field (k octet field (k = Length of frequency parameters -1)) contains a bitmap referring to the *Cell Channel Description* IE in SI 1 message. The length of the bitmap is 8k, where k = ((NF-1) div 8 + 1) and where NF denotes the number of ARFCNs contained in the cell channel description. The different bit positions in the mobile allocation bitmap are assigned indices i = 1 to 8k, starting with i = 8k in the most significant bit position and ending with i = 1 in the least significant bit position. The bit position with index i corresponds to the i'th frequency in the cell channel description arranged in ascending order of ARFCN (except that ARFCN = 0, if included, is put last) and numbered from 1 to NF. Each bit position in the mobile allocation bitmap is coded:

- 0 RF channel not belonging to mobile allocation;
- 1 RF channel belonging to mobile allocation.

If NF mod 8 <> 0, then bit positions i = NF+1 to 8k in octet 3 shall each be coded with a "0".

## 10.5.2.17 IAR Rest Octets

The *IAR Rest Octets* information element contains only spare bits. Its purpose is to allow the upward compatible introduction of new information on the AGCH in later phases.

The IAR Rest Octets information element is a type 5 information element with 4 octets length.

8	7	б	5	4	3	2	1	
		I <i>I</i>	AR Rest	c Octet	s IEI			octet 1
0 spare	0 spare	1 spare	0 spare	1 spare	0 spare	1 spare	1 spare	octet 2
0 spare	0 spare	1 spare	0 spare	1 spare	0 spare	1 spare	1 spare	octet 3
0 spare	0 spare	1 spare	0 spare	1 spare	0 spare	1 spare	1 spare	octet 4



## 10.5.2.18 IAX Rest Octets

The *IAX Rest Octets* information element contains only spare bits only. Its purpose is to allow the upward compatible introduction of new information on the AGCH in later phases.

The IAX Rest Octets information element is a type 5 information element with 1-5 octets length.

	8	7	б	5	4	3	2	1		
			I <i>I</i>	AX Rest	c Octet	ts IEI			octet	1
	0 spare	0 spare	1 spare	0 spare	1 spare	0 spare	1 spare	1 spare	octet	2*
	0 spare	0 spare	1 spare	0 spare	1 spare	0 spare	1 spare	1 spare	octet	3*
	·	r				r		·	•	
-	 0 spare	 0 spare	+ 1 spare	 0 spare	 1 spare	 0 spare	+ 1 spare	+ 1 spare	octet	n*
-									F	

Figure 10.5.45/3GPP TS 04.08: IAX Rest Octets information element

## 10.5.2.19 L2 Pseudo Length

The *L2 Pseudo Length* information element indicates the number of octets following it in the message which are to be interpreted in the scope of the phase 1 protocol, i.e. the total number of octets (excluding the Rest Octets) for which T, V, TV, LV, or TLV formatting is used (reference Table 11.1/3GPP TS 04.07).

The *L2 Pseudo Length* information element is the first part of e.g. SYSTEM INFORMATION messages which are mentioned as exceptions in sub-clause 10.1. It occupies the first octet of such messages.

For any of the SYSTEM INFORMATION messages sent on the BCCH, a mobile station should ignore the contents of the L2 Pseudo Length value contained in the *L2 Pseudo Length* information element. For some specific messages, further requirements are specified in sub-clause 9.

The L2 Pseudo Length Information element is an element with 2 octets length:

	8	7	б	5	4	3	2	1			
Ĭ				L2 Pseu	ıdo Ler	ngth I	EI			octet	1
+-		L2 I	Pseudo	Length	value		0	1	_	octet	2

#### Figure 10.5.46/3GPP TS 04.08: L2 Pseudo Length information element

Table 10.5.46/3GPP TS 04.08: L2 Pseudo Length information element

L2 pseudo length value (octet 2) The coding of the L2 pseudo length value field is the binary representation of the L2 pseudo length of the message in which the L2 pseudo length information element occurs.

NOTE: bits 1 and 2 are not spare.

### 10.5.2.20 Measurement Results

The purpose of the *Measurement Results* information element is to provide the results of the measurements made by the mobile station on the serving cell and the neighbour cells.

The *Measurement Results* information element is coded as shown in figure 10.5.47/3GPP TS 04.08 and table 10.5.47/3GPP TS 04.08.

The Measurement Results is a type 3 information element with 17 octets length.

. 8	8	7	6	5	4	3	2	1			
+			Measurement Results IEI								
	A- SED	DTX USED		octet	2						
	0 are	MEAS- VALID	 I	RXLEV-	SUB-SEI	RVING-0	CELL		octet	3	
	 0 are	-	QUAL-FU			XQUAL-; RVING-(		NO- NCELL M (high part)	octet	4	
		ELL-M part)		RXL	EV-NCE				octet	5	
+		BCCH-F	FREQ-NO	CELL 1			C-NCEL gh par		octet	б	
+		C-NCELI bw part				V-NCELI gh par			octet	7	
NCI (10	LEV ELL 2 SW rt)	в(		EQ-NCE			2	NCELL part)	octet	8	
+	 I	BSIC-NC				LEV-No (high )			octet	9	
I	-	EV- LL 3 part)		BCCH		NCELL	3	BSIC- NCELL 3 (high part)	octet	10	
+			-NCELL part)	3			EV-NCE igh pa		octet	11	
+		EV-NCEI ow part			BCCH	-FREQ-I	NCELL	4	octet	12	
+		BS	SIC-NCI	 ELL 4				-NCELL 5 part)	octet	13	
+	I	RXLEV-N (low	NCELL ! part)	5	BC	CH-FRE (high	Q-NCEL part)	L 5	octet	14	
FRI NCI 5 ( 1	CH- EQ- ELL low rt)		I	BSIC-N	CELL 5			RXLEV NCELL 6 (high part)	octet	15	
+	I	RXLEV-N (low p		5			FREQ-N igh pa	 CELL 6 rt)	octet	16	
1	NCEI	FREQ- LL 6 part)		B:	SIC-NC	ELL 6			octet	17	

Figure 10.5.47/3GPP TS 04.08: Measurement Results information element (continued)

#### Table 10.5.47/3GPP TS 04.08: Measurement Results information element

BA-USED (octet 2), the value of the BA-IND field of the neighbour cells description information element or elements defining the BCCH allocation used for the coding of BCCH-FREQ-NCELL fields. Range 0 to 1.

DTX-USED (octet 2) This bit indicates whether or not the mobile station used DTX during the previous measurement period.

Bit 7

- 0 DTX was not used
- 1 DTX was used

RXLEV-FULL-SERVING-CELL and RXLEV-SUB-SERVING-CELL, (octets 2 and 3) Received signal strength on serving cell, measured respectively on all slots and on a subset of slots (see 3GPP TS 05.08)

The RXLEV-FULL-SERVING-CELL and RXLEV-SUB-SERVING-CELL fields are coded as the binary representation of a value N. N corresponds according to the mapping defined in 3GPP TS 05.08 to the received signal strength on the serving cell.

Range: 0 to 63

MEAS-VALID (octet 3) This bit indicates if the measurement results for the dedicated channel are valid or not

Bit 7

- 0 The measurement results are valid
- 1 the measurement results are not valid

RXQUAL-FULL-SERVING-CELL and RXQUAL-SUB-SERVING-CELL (octet 4) Received signal quality on serving cell, measured respectively on all slots and on a subset of the slots (see TS. 3GPP TS 05.08)

(continued...)

#### CELL fields are coded as the binary representation of the received signal quality on the serving cell. Range: 0 to 7 (See 3GPP TS 05.08) NO-NCELL-M, Number of neighbouring cell measurements (octets 4 and 5) Bits 187 000 No neighbour cell measurement result .. " 001 1 ., 010 " " 2 011 ... " " " 3 100 " " " " 4 " " " " 101 5 110 6 " " " " 111 Neighbour cell information not available for serving cell RXLEV-NCELL i, Received signal strength on the i'th neighbouring cell (octet 5, 7, 8, 9, 10, 11, 12, 13, 14, 15 and 16) The RXLEV-NCELL field is coded as the binary representation of a value N. N corresponds according to the mapping defined in TS. 3GPP TS 05.08 to the received signal strength on the i'th neighbouring cell. See note 1 & 2. Range: 0 to 63.

#### Table 10.5.47/3GPP TS 04.08: Measurement Results information element (continued)

BCCH-FREQ-NCELL i, BCCH carrier of the i'th neighbouring cell (octet 6, 8,10, 12, 14, 15, 16 and 17)

The BCCH-FREQ-NCELL i field is coded as the binary representation of the position, starting with 0, of the i'th neighbouring cells BCCH carrier in the BCCH channel list. The BCCH channel list is composed of one or two BCCH channel sub lists, each sub list is derived from the set of frequencies defined by reference neighbour cells description information element or elements. In the latter case the set is the union of the two sets defined by the two neighbour cells description information elements.

In each BCCH channel sub list the absolute RF channel numbers are placed in increasing order of ARFCN, except that ARFCN 0, if included in the set, is put in the last position in the sub list. The BCCH channel list consists either of only the sub list derived from the neighbour cells description information element(s) in System Information 2/5 (and possible 2bis/5bis) or of that sub list immediately followed by the sub list derived from the neighbour cells description information element in System Information 2ter/5ter for the case System Information 2ter/5ter is also received. If the set of ARFCNs defined by the reference neighbour cells description information element or elements includes frequencies that the mobile station does not support then these ARFCNs shall be included in the list. The notation 2/5 etc. means that the rules above apply to the neighbour cells description information elements received in System Information 2, 2bis and 2ter and to those received in System Information 2, 2bis and 5ter separately.

See note 1 & 2.

Range: 0 to 31.

BSIC-NCELL i, Base station identity code of the i'th neighbouring cell (octet 6, 7, 8, 9, 10, 11, 13, 15 and 17)

The BSIC-NCELL i field is coded as the binary representation of the base station identity code of the i'th neighbouring cell. See note 1 & 2.

Range: 0 to 63.

**NOTE 1:** If the field extends over two octets the highest numbered bit of the lowest numbered octet is the most significant and the lowest numbered bit of the highest numbered octet is the least significant.

**NOTE 2:** If NO-NCELL-M < 6 the remaining RXLEV-NCELL i, BS-FREQ-NCELL i and BSIC-NCELL i fields (NO-NCELL-M <  $i \le 6$ ) shall be coded with a "0" in each bit.

### 10.5.2.20a GPRS Measurement Results

The purpose of the *GPRS Measurement Results* information element is to provide the results of the GPRS measurements made by the GPRS mobile station on the serving cell.

The *GPRS Measurement Results* information element is coded as shown in figure 10.5.48/3GPP TS 04.08 and table 10.5.48/3GPP TS 04.08.

The GPRS Measurement Results is a type 3 information element with 3 octets length.

	8	7	6	5	4	3	2	1		
			GPRS N	leasure	nent Re	esults	IEI		octet	1
-			C_1	ALUE			RX (high	QUAL part)	octet	2
-	RXQ-L (low)	0 spare	e		SIGN_	VAR			octet	3

Figure 10.5.48/3GPP TS 04.08: GPRS Measurement Results information element

Table 10.5.48/3GPP TS 04.08: GPRS Measurement Results information element

C\_VALUE (octet 1), the value of the C parameter calculated by the GPRS mobile station (see 3GPP TS 05.08). This field is encoded as the binary representation of the C parameter value defined in 3GPP TS 05.08. Range 0 to 63. RXQUAL (octets 1 and 2), contains the RXQUAL parameter field calculated by the GPRS mobile station (see 3GPP TS 05.08). This field is encoded as defined in 3GPP TS 05.08. Range 0 to 7. SIGN\_VAR (octet 3), contains the signal variance parameter SIGN\_VAR calculated by the mobile station (see 3GPP TS 05.08). This field is encoded as defined in 3GPP TS 04.60.

### 10.5.2.21 Mobile Allocation

The purpose of the *Mobile Allocation* information element is to provide that part of the RF channels belonging to the cell allocation (coded with a "1" in the cell channel description information element) which is used in the mobile hopping sequence.

The *Mobile Allocation* information element is coded as shown in figure 10.5.49/3GPP TS 04.08 and table 10.5.49/3GPP TS 04.08.

The *Mobile Allocation* is a type 4 information element with 3 to 10 octets length except for the cases specified in subclause 9.1.18.1 and 9.1.19.2.

	8	7	б	5	4	3	2	1		
Ţ		I	Mobile	Alloca	ation 3	IEI			octet	1
+		Leng	th of 1	mobile	alloca	ation	conten	ts	octet	2
	MA C 8n	MA C 8n-1	MA C 8n-2	MA C 8n-3	MA C 8n-4	MA C 8n-5	MA C 8n-6	MA C 8n-7	octet	3
+	MA C 008	MA C 007	MA C 006	MA C 005	+ MA C 004	MA C 003	MA C 002	+ MA C 001	octet	n+2

Figure 10.5.49/3GPP TS 04.08: Mobile Allocation information element

Table 10.5.49/3GPP TS 04.08: Mobile Allocation information element

MA C i, Mobile allocation RF channel i (octet 3 etc.), i = 1, 2,..., NF The MA C i bit indicates whether or not the Mobile allocation frequency list includes the i'th frequency in the cell allocation frequency list. The cell allocation frequency list is derived from the set of frequencies defined by the reference cell channel description information element. NF denotes the number of frequencies in the cell allocation frequency list. In the cell allocation frequency list the absolute RF channel numbers are placed in increasing order of ARFCN, except that ARFCN 0, if included in the set, is put in the last position in the list, a RF channel belonging to the mobile allocation MA C i bit is coded with a "1"; i = 1, 2,..., For the NF. channel not belonging to the mobile the MA C i bit is coded with a "0"; i = For a RF mobile allocation 1, 2,..., NF. If NF mod 8 <> 0 then bits NF to 8n in octet 3 must be coded with a "0" in each.

## 10.5.2.21a Mobile Time Difference

A *Mobile Time Difference* information element encodes a time related to the synchronization difference between the time bases of two base stations. This type of information is used in conjunction with the HANDOVER COMPLETE message.

The *Mobile Time Difference* information element is coded as shown in figure 10.5.50/3GPP TS 04.08 and table 10.5.50/3GPP TS 04.08.

The Mobile Time Difference information element is a type 4 information element with 5 octets length.

8	7	6	5	4	3	2	1		
			Mobile	e Time Differe	ence IEI			Octet 1	
		Lengt	n of Mobile Ti	me difference	e contents			Octet 2	
		Mc	bile Time Diff	ference value	(high)			Octet 3	
	Mobile Time Difference value (contd) Oc								
	Mobile T	ime Difference	value (low)		0	0	0	Octet 5	
					spare	spare	spare		

#### Figure 10.5.50/3GPP TS 04.08: Mobile Time Difference information element

#### Table 10.5.50/3GPP TS 04.08: Mobile Time Difference information element

Mobile Time Difference value (octet 3, 4 and 5) The coding of the Mobile Time Difference value field is the binary representation of the time difference in half bit periods and modulo  $2^{21}$  half bit periods; 1/2 bit period = 24/13 µs.

#### 10.5.2.21aa MultiRate configuration

The MultiRate configuration information element gives all parameters related to a multi-rate speechcodec.

The *MultiRate configuration* information element is coded as shown in figure 10.5.2.47/3GPP TS 04.08 and table 10.5.2.47/3GPP TS 04.08.

The MultiRate *configuration* is a type 4 information element with a minimum length of 4 octets and a maximum length of 8 octets.







Figure 10.5.2.47/3GPP TS 04.08: MultiRate configuration information element






	8	7	6	5	4	3	2	1		
-		Se	et of A	MR co	dec mo	des			octet	4
	Spa 0	are 0		Thi	reshol	d 1			octet	5
_	Ну	stere	sis 1		0	Spa: 0	re 0	0	octet	б

Figure 10.5.2.47b/3GPP TS 04.08: Parameters for multirate speech fiel for the MR version 1 when a set with two codec modes is chosen








Figure 10.5.2.47d/3GPP TS 04.08: Parameters for multirate speech fiel for the MR version 1 when a set of four modes is chosen

# Table 10.5.2.47/3GPP TS 04.08: MultiRate configuration information element

Bi 8	octet 3 its 7 6	<b>Multirate speech version</b> Adaptive Multirate speech version 1
0	other values re	served
Bi 0	it 5	Spare
Bi	it 4	Initial Codec Mode Indicator
0 1		The initial codec mode is defined by the implicit rule provided in 3GPP TS 05.09 The initial codec mode is defined by the Start Mode field
Ві <b>3</b>	it	
0		Spare
Bi 2	its 1	Start Mode,
		The initial codec mode is coded as in 3GPP TS 05.09 sub-clause 3.4.1
		e speech version field indicates Adaptive Multirate 1 then the remaining fields are coded as follows:
c 3 H h j	orresponds to GPP TS 05.09 IYSTj (4 bits) hysteresis valu j = 1 correspor	s coded as the binary representation of a value N. N the threshold of C/I in dB, as defined in 9; is coded as the binary representation of the e associated to THRj, as defined in 3GPP TS 05.09. nds to the lowest value of threshold in dB, $j = 2$ to the j = 3 to the highest value.

Set of adaptive multirate codec modes field (octet 4) Bit 8 0 12,2 kbit/s codec rate is not part of the subset; 12,2 kbit/s codec rate is part of the subset; 1 Bit 7 0 10,2 kbit/s codec rate is not part of the subset; 1 10,2 kbit/s codec rate is part of the subset; Bit 6 0 7,95 kbit/s codec rate is not part of the subset; 7,95 kbit/s codec rate is part of the subset; 1 Bit 5 7,40 kbit/s codec rate is not part of the subset; 0 7,40 kbit/s codec rate is part of the subset; 1 Bit 4 0 6,70 kbit/s codec rate is not part of the subset; 6,70 kbit/s codec rate is part of the subset; 1 Bit 3 0 5,90 kbit/s codec rate is not part of the subset; 5,90 kbit/s codec rate is part of the subset; 1 Bit 2 0 5,15 kbit/s codec rate is not part of the subset; 1 5,15 kbit/s codec rate is part of the subset; Bit 1 4,75 kbit/s codec rate is not part of the subset; 0 4,75 kbit/s codec rate is part of the subset; 1

### 10.5.2.21b Multislot Allocation

The purpose of the *Multislot Allocation* information element is to provide a description of which channels are used in downlink and uplink respectively, in a multislot configuration. It also groups the channels into channel sets, the channel mode for each channel set can be defined by a separate information element.

The *Multislot Allocation* information element is coded as shown in figure 10.5.51/3GPP TS 04.08 and table 10.5.51/3GPP TS 04.08.

The multislot allocation information element is a type 4 information element with a minimum length of 3 octets and a maximum length of 12 octets.

	8	7	6	5	4	3	2	1		
			Mu]	tislot	alloc	ction 1	LEI		octet	1
	Leng	gth of	the mu	ltislo	ot allo	catior	n conte	ents	octet	2
	0/1 ext	DA 7	DA 6	DA 5	DA 4	DA 3	DA 2	DA 1	octet	3
+	1 ext	UA 7	UA 6	UA 5	UA 4	UA 3	UA 2	UA 1	octet	3a*
+			Chanr	nel set	 - 1				octet	4*
+			Chanr	nel set	2				octet S	5*
:									:	
 +			Chanr	nel set					octet +	11*

Figure 10.5.51/3GPP TS 04.08: Multislot Allocation information element

Table 10.5.51/3GPP TS 04.08: Multislot allocation information element

DA 1-7, Downlink assignment (octet 3) Indicates additional downlink channel allocation. If bit DA n is set to "1" this indicates that timeslot TN = (n + TNm)mod8 is assigned. If bit DA n is set to "0" the corresponding timeslot is not assigned. TNm is the timeslot number of the main link. UA 1-7, Uplink assignment (octet 3a) Indicates additional uplink channel allocation. If bit UA n is set to "1" this indicates that timeslot TN = (n + TNm)mod8 is assigned. If bit UA n is set to "0" the corresponding timeslot is not assigned. TNm is the timeslot number of the main link. If octet 3a is not included the timeslots indicated by octet 3 are allocated in both downlink and uplink direction. NOTE1: Allocation of timeslots only in uplink is FFS. NOTE2: In combination with the channel description IE, all types of channels can be indicated. The channel carrying the main signalling link (indicated by the channel description IE is of type 1 (see below)), all other channels allocated both in downlink and uplink are of type 2 and channels with allocation in only one direction are of type 3. Type 1: TCH/F + FACCH/F + SACCH/M bidirectional Type 2: TCH/F + SACCH/M bidirectional Type 3: TCH/F + SACCH/M unidirectional Channel set n (octet 4 to 11 (if included)) If octets 4-11 are omitted, all channels belong to channel set 1. If bit m of Channel set n is set to "1" then timeslot m-1 is included in channel set n. If bit m of Channel set n is set to "0" then timeslot m-1 is not included in channel set n. Each allocated timeslot, including the timeslot carrying the main signalling link, shall be included in one (and only one) channel set.

#### 10.5.2.21c NC mode

The purpose of the *NC mode* information element is for the network to inform the mobile station of the NC mode to be implemented on the target cell.

The *NC mode* information element is coded as shown in figure 10.5.52/3GPP TS 04.08 and table 10.5.52/3GPP TS 04.08.

The NC mode is a type 1 information element.




Figure 10.5.52 /3GPP TS 04.08: NC mode information element

```
-----+
NC mode
This field indicates to the mobile the NC mode for
the target cell (see GSM£04.60). The field is encoded
according to the following table:
bits
2
0
0
  1
  0
     NC 0
NC 1
     NC 1
NC 2
  1
1
1
  0
      information on NC mode to be gathered from the
  1
       target cell
                      -----+
_ _ _ _ _
```

### Table 10.5.52/3GPP TS 04.08: NC Mode information element

### 10.5.2.22 Neighbour Cells Description

The purpose of the *Neighbour Cells Description* information element is to provide the absolute radio frequency channel numbers of the BCCH carriers to be monitored by the mobile stations in the cell.

The *Neighbour Cells Description* information element is coded as the *Cell Channel Description* information element, as specified in sub-clause 10.5.2.1b, with the exception of bits 5 and 6 of octet 2. figure 10.5.53/3GPP TS 04.08 and table 10.5.53/3GPP TS 04.08 contains the difference of specifications.

The Neighbour Cells Description information element is a type 3 information element with 17 octets length.

	8	7	6	5	4	3	2	1	
		1	Neighbo	our Ce	lls Des	script	ion IE:	I	octet 1
	Bit 128	Bit 127	EXT- IND	BA- IND	Bit 124	Bit 123	Bit 122	Bit 121	octet 2
	Bit 120	Bit 119	Bit 118	Bit 117	Bit 116	Bit 115	Bit 114	Bit 113	octet 3
		, +	•		' +	, +	, +	, +	1
-	Bit 008	Bit 007	Bit 006	Bit 005	Bit 004	Bit 003	Bit 002	Bit 001	octet 17 +

Figure 10.5.53/3GPP TS 04.08: Neighbour Cells Description information element

#### Table 10.5.53/3GPP TS 04.08: Neighbour Cells Description information element

EXT-IND, Extension indication (octet 2, bit 6)
If received in System Information 2, 2bis, 5 or 5bis this bit indicates whether the information element carries the complete information of a BCCH channel sub list or whether a complementary information element is sent in another message. A GSM 900 mobile station which only supports the primary GSM band P-GSM 900 (cf. 3GPP TS 05.05) may consider this bit as a spare bit and assume that the information element carries the complete BA, see sub-clause 3.2.2.1.
NOTE: This indicator is set to 1 in the neighbour cells description information elements in System Information 2 and 2bis and 5 and 5bis respectively when more than one is needed to describe a BCCH channel sub list.
Bit 6
0 The information element carries the complete BA
1 The information element carries only a part of the BA
BA-IND, BCCH allocation sequence number indication (octet 2). Range 0 to 1
The BA-IND is needed to allow the network to discriminate measurements results related to different BAs (e.g. BA(BCCH) and BA(SACCH)) sent to the MS.

## 10.5.2.22a Neighbour Cells Description 2

The purpose of the *Neighbour Cells Description 2* information element is to provide the absolute radio frequency channel numbers of the BCCH carriers to be monitored by the mobile stations in the cell.

The *Neighbour Cells Description 2* information element is coded as the *Cell Channel Description* information element, as specified in sub-clause 10.5.2.1b, with the exception of bits 5 to 7 of octet 2. figure 10.5.54/3GPP TS 04.08 and table 10.5.54/3GPP TS 04.08 contains the difference of specifications.

The Neighbour Cells Description 2 information element is a type 3 information element with 17 octets length.

	8	7	6	5	4	3	2	1	
		Neighbour Cells Description IEI							octet 1
	Bit 128		iband rting	BA IND	Bit 124	Bit 123	Bit 122	Bit 121	octet 2
	Bit 120	Bit 119	Bit 118	Bit 117	Bit 116	Bit 115	Bit 114	Bit 113	octet 3
-			+		+	+	+	+	
Ŧ	Bit 008	Bit 007	Bit 006	Bit 005	Bit 004	Bit 003	Bit 002	Bit 001	octet 17

### Figure 10.5.54/3GPP TS 04.08: Neighbour Cells Description 2 information element

#### Table 10.5.54/3GPP TS 04.08: Neighbour Cells Description 2 information element

Octet 2 bit 8, 4, 3 and 2

FORMAT-ID, Format Identifier (Bit 128 and next)

The different formats are distinguished by the bits of higher number. As an exception to the general format for the neighbour cell description the format ID is coded as follows :

Bit	Bit	Bit 1	Bit format notation
128	124	123 12	22
0	Х	X	X bit map 0
1	0	XX	K 1024 range
1	1	0 0	512 range
1	1	0 1	256 range
1	1	1 0	128 range
1	1	1 1	variable bit map

Bits 6 and 7 of Octet 2

Multiband reporting

Binary encoding of multiband reporting parameter as specified in 3GPP TS 05.08.

Range: 0 to 3

Bit 5 of octet 2

BA-IND, BCCH allocation sequence number indication.

The BA-IND is needed to allow the network to discriminate measurements results related to different BAs (e.g. BA(BCCH) and BA(SACCH)) sent to the MS.

Range 0 to 1.

## 10.5.2.22c NT/N Rest Octets

NT/N Rest Octets ::= {0 I 1<NLN(PCH) : bit (2)>} <list of Group Call NCH information> <Spare padding>; <List of Group Call NCH information> ::= 0 | 1 <Group Call information> <List of Group Call NCH information> ; NLN(PCH) This field gives the NLN value to be used as specified in 3.3.3 <Group Call information>

## 10.5.2.23 P1 Rest Octets

See sub-clause 9.1.21a

The *P1 Rest Octets* information element contains information about the status of information on an existing NCH, priority levels and packet page indications applied for mobile station identities and spare bits.

The P1 Rest Octets information element is a type 5 information element with 1-18 octets length.

```
<P1 Rest Octets> ::=
{L I H <NLN(PCH) : bit (2)> <NLN status : bit>}
{L I H <Priority1 ::= Priority>}
{L I H <Priority2 ::= Priority>}
{L | H <Group Call information>}
<Packet Page Indication 1 : {L | H} >
<Packet Page Indication 2 : {L | H} >
<spare padding>;
<Priority> ::= <bit (3)>;
<Group Call information>
```

See sub-clause 9.1.21a

NOTE: The value 17h shall not be used as a value of the first octet when this information element is used in the PAGING REQUEST TYPE 1 message. This will prevent mobile stations misinterpreting this information as the Mobile Identity IEI.

#### Table 10.5.55/3GPP TS 04.08: P1 Rest Octets information element

#### NLN(PCH) Notification List Number

The presence of the *NLN(PCH)* field indicates that if an NCH is present, reduced NCH monitoring can be used, and gives the NLN(PCH) value, to be used as specified in 3.3.3.

**Priority**: **Priority i** relates to *Mobile Station Identity i* (i = 1, 2)

000no priority applied001call priority level 4

- 0 1 0 call priority level 3
- 0 1 1 call priority level 2
- 1 0 0 call priority level 1
- 1 0 1 call priority level 0
- 1 1 0 call priority level B
- 1 1 1 call priority level A

The **Packet Page Indication i** field relates to *Mobile Station Identity i* (i = 1, 2) and indicates the kind of paging procedure associated with the mobile station identity. If the identity is not IMSI the Packet Page Indication has no meaning and is ignored.

L paging procedure for RR connection establishment; H packet paging procedure.

### 10.5.2.24 P2 Rest Octets

The *P2 Rest Octets* information element contains information on the channel needed by the network and information about the status of information on an existing NCH, priority levels and packet page indications applied for mobile station identities and spare bits.

The P2 Rest Octets information element is a type 5 information element with 2-12 octets length.

```
<P2 Rest Octets> ::=
{L I H <CN3: bit (2)>}
{L I H <NLN : bit (2)> <NLN status : bit>}
{L I H <Priority1 ::= Priority>}
{L I H <Priority2 ::= Priority>}
{L I H <Priority3 ::= Priority>}
< Packet Page Indication 3 : {L | H} >
<spare padding>;
```

```
<Priority> ::= <bit(3)>;
```

NOTE: The value 17h shall not be used as a value of the first octet when this information element is used in the PAGING REQUEST TYPE 2 message. This will prevent mobile stations misinterpreting this information as the Mobile Identity IEI.

#### Table 10.5.56/3GPP TS 04.08: P2 Rest Octets information element

### CN3 Channel Needed for Mobile Identity 3

The values and semantics used in the *CN3* field are those of the CHANNEL field of *Channel Needed* IE (see 10.5.2.8). The *CN3* field is associated with the Mobile Identity 3 IE of the PAGING REQUEST TYPE 2 message.

If the *CN3* field is not present, the default value is 00 (any channel).

	NLN Notification List Number See P1 Rest Octets.								
<b>Priority</b> : <b>Priority</b> i relates to <i>Mobile Station Identity</i> $i$ (i = 1, 2, 3)									
0 0 0	0 no priority applied								
0 0 1	1 call priority level 4								
0 1 0	0 call priority level 3								
0 1 1	1 call priority level 2								
1 0 0	0 call priority level 1								
1 0 1	1 call priority level 0								
110	0 call priority level B								
1 1 1	1 call priority level A								
The <b>Packet Page Indication 3</b> field relates to <i>Mobile Station Identity 3</i> and indicates the kind of paging procedure associated with the mobile station identity. If the identity is not IMSI the Packet Page Indication has no meaning and is ignored.									
L	paging procedure for RR connection establishment;								

L	paging procedure for KK connection establishine
Н	packet paging procedure.

## 10.5.2.25 P3 Rest Octets

The *P3 Rest Octets* information element contains information on the channel needed by the network and information about the status of information on an existing NCH, priority levels applied for mobile station identities and spare bits. The purpose of the spare bits is to allow the upward compatible introduction of new information on the PCH in later phases.

The P3 Rest Octets information element is a type 5 information element with 4 octets length.

```
<P3 Rest Octets> ::=

{L I H <CN3 : bit (2)> <CN4 : bit (2)>}

{L I H <NLN : bit (2)> <NLN status : bit>}

{L I H <Priority1 ::= Priority>}

{L I H <Priority2 ::= Priority>}

{L I H <Priority3 ::= Priority>}

{L I H <Priority4 ::= Priority>}
```

<**Priority**> ::= <**bit**(3)>;

Table 10.5.57/3GPP TS 04.08: P3 Rest Octets information element

CN3 Channel Needed for Mobile Identity 3 The values and semantics used in the CN3 field are those of the CHANNEL field of Channel Needed IE (see 10.5.2.8). The CN3 field is associated with the Mobile Identity 3 IE of the PAGING REQUEST TYPE 3 message. If the CN3 field is not present, the default value is 00 (any channel) CN4 Channel Needed for Mobile Identity 4 The values and semantics used in the CN43 field are those of the CHANNEL field of Channel Needed IE (see 10.5.2.8). The CN4 field is associated with the Mobile Identity 4 IE of the PAGING REQUEST TYPE 3 message. If the CN4 field is not present, the default value is 00 (any channel) NLN Notification List Number See P1 Rest Octets no priority applied call priority level 0 0 0 0 0 1 0 1 0 call priority level 3 call priority level call priority level 0 1 1 2 1 call priority level 0 call priority level B 1 1 1 call priority level A

#### 10.5.2.25a Packet Channel Description

The purpose of the *Packet Channel Description* information element is to provide a description of a packet data physical channel (PDCH).

The *Packet Channel Description* information element is coded according to the syntax specified below and described in table 10.58/3GPP TS 04.08.

The Packet Channel Description is a type 3 information element with 4 octets length.

```
< Packet Channel Description > ::=
 < Channel type : bit (5) >
 <TN : bit (3) >
 < TSC : bit (3) >
 { 0
     \{ 0 < \text{spare bit} > \}
        < ARFCN : bit (10) >
                                                   -- non-hopping RF channel configuration
     |1 < \text{spare bit} >
        < MAIO : bit (6) >
                                                   -- indirect encoding of hopping RF channel configuration
        < MA NUMBER IND : bit >
        \{0 < \text{spare bits} : \text{bit} (2) >
        | 1 < CHANGE_MARK_1 : bit (2) >
        }
     }
 |1
     < MAIO : bit (6) >
                                                   -- direct encoding of hopping RF channel configuration
     <HSN : bit (6) >
 };
```

### Table 10.5.58/3GPP TS 04.08: Packet Channel Description information element

The **Channel type** field (5 bit) shall be ignored by the receiver and all bits treated as spare. For backward compatibility reasons, the sender shall set the spare bits to binary '00001'.

The TN field (3 bit) is the binary representation of the timeslot number as defined in 3GPP TS 05.10. Range: 0 to 7

The **TSC** field (3 bit) is the binary representation of the training sequence code as defined in 3GPP TS 05.02. Range: 0 to 7.

#### Non-hopping RF channel configuration

The **ARFCN** field (10 bit) is the binary representation of the absolute RF channel number, see 3GPP TS 05.05. Range: 0 to 1023.

#### Indirect encoding of hopping RF channel configuration

The **MAIO** field (6 bit) is the binary representation of the mobile allocation index offset, see 3GPP TS 05.02. Range: 0 to 63.

The **MA\_NUMBER\_IND** field (1 bit) is the binary representation of the MA\_NUMBER to use as reference to a GPRS mobile allocation:

- 0 MA\_NUMBER = 14
- 1  $MA_NUMBER = 15$

The **CHANGE\_MARK\_1** field (2 bit) is the binary representation of the allowed value of the SI *change mark* associated with the GPRS mobile allocation to which the MA\_NUMBER refers. Range: 0 to 3.

If the *indirect encoding* is used, this information element may contain the CHANGE\_MARK\_1 field. If that is present, the mobile station being assigned the TBF shall verify the validity of the SI *change mark* associated with the GPRS mobile allocation to which this information element refers, see 3GPP TS 04.60. The CHANGE\_MARK\_1 field shall not be included in this information element if MA\_NUMBER = 15 is used.

#### Direct encoding of hopping RF channel configuration

The **MAIO** field (6 bit) is the binary representation of the mobile allocation index offset, see 3GPP TS 05.02. Range: 0 to 63.

The HSN field (6 bit) is the binary representation of the hopping sequence number, see 3GPP TS 05.02. Range: 0 to 63.

## 10.5.2.25b Dedicated mode or TBF

The *Dedicated mode or TBF* information element is used by the network to indicate to the mobile station whether the rest of the message shall be decoded as an IMMEDIATE ASSIGNMENT message allocating a channel in dedicated mode or whether the rest of the message shall be decoded as the allocation of a Temporary Block Flow.

This IE also indicates:

- whether the IMMEDIATE ASSIGNMENT message relates to a downlink TBF for a mobile station in packet idle mode; and
- whether the IMMEDIATE ASSIGNMENT message is the first message of two IMMEDIATE ASSIGNMENT messages in a two-message assignment of an uplink or downlink TBF.

The *Dedicated mode or TBF* information element is coded as shown in figure 10.5.55/3GPP TS 04.08 and table 10.5.59/3GPP TS 04.08.

The *Dedicated mode or TBF* is a type 1 information element.

8	7	б	5	4	3	2	1		
	Dedica or TB		ode	spare 0	TMA	down- link	T/D	octet	1

#### Figure 10.5.55/3GPP TS 04.08: Dedicated mode or TBF information element

#### Table 10.5.59/3GPP TS 04.08: Dedicated mode or TBF information element

T/D : TBF or dedicated mode (octet 1)
Bit
1
0 this message assigns a dedicated mode resource
1 this message assigns a Temporary Block Flow (TBF).
Downlink : Downlink assignment to mobile in packet idle mode
Bit
2
0 No meaning
1 this message assigns a resource to the mobile station identified in the IA rest octets. The type of resource (either dedicated mode or TBF) is indicated by bit 1.
TMA : Two-message assignment
Bit
3
0 No meaning
1 This message is the first message of two in a two-message assignment of an uplink or downlink TBF.

### 10.5.2.25c RR Packet Uplink Assignment

The *RR Packet Uplink Assignment* information element is sent by the network to the mobile station to indicate the assigned uplink resources.

The *RR Packet Uplink Assignment* information element is coded as shown in tables 10.5.60/3GPP TS 04.08 and 10.5.61/3GPP TS 04.08.

The RR Packet Uplink Assignment is a type 4 information element.

#### Table 10.5.60: RR PACKET UPLINK ASSIGNMENT information element

< RR Packet Uplink Assignment message content > ::= < LENGTH\_IN\_OTECTS : bit (8) > < CHANNEL\_CODING\_COMMAND : bit (2) > < TLLI\_BLOCK\_CHANNEL\_CODING : bit (1) > < Packet Timing Advance : Packet Timing Advance IE > {01 < Dynamic Allocation : Dynamic Allocation struct> | 10 **<Single Block Allocation** : Single Block Allocation struct> | 11 < Fixed Allocation : Fixed Allocation struct> | 00 <Extension>} < N\_SPARE\_BITS : bit(N) > ; <Extension> : := -- Future extension can be done by modifying this structure null; <Dynamic Allocation struct > ::= < Extended Dynamic Allocation : bit(1)>  $\{ 0 \mid 1 < \mathbf{P0} : bit(4) >$ <**PR\_MODE** : bit (1) > }

< USF GRANULARITY : bit (1) >  $\{ 0 \mid 1 < \mathbf{UPLINK\_TFI\_ASSIGNMENT} : bit (5) > \}$  $\{ 0 \mid 1 < \mathbf{RLC}_\mathbf{DATA}_\mathbf{BLOCKS}_\mathbf{GRANTED} : bit (8) > \}$ { 0 -- Timeslot Allocation  $\{ 0 \mid 1 < USF_TN0 : bit (3) > \}$  $\{ 0 | 1 < USF TN1 : bit (3) > \}$  $\{ 0 | 1 < USF TN2 : bit (3) > \}$ { 0 | 1 < **USF\_TN3** : bit (3) >}  $\{ 0 \mid 1 < USF_TN4 : bit (3) > \}$  $\{ 0 | 1 < USF_TN5 : bit (3) > \}$  $\{ 0 \mid 1 < USF_TN6 : bit (3) > \}$  $\{ 0 \mid 1 < USF_TN7 : bit (3) > \}$ -- Timeslot Allocation with Power Control Parameters |1 < **ALPHA** : bit (4) > $\{ 0 \mid 1 < USF_TN0 : bit (3) > \}$ < **GAMMA\_TN0** : bit (5) > } { 0 | 1 < **USF\_TN1** : bit (3) > < **GAMMA\_TN1** : bit (5) > }  $\{ 0 \mid 1 < USF_TN2 : bit (3) > \}$ < **GAMMA TN2** : bit (5) > } { 0 | 1 < **USF\_TN3** : bit (3) > < **GAMMA\_TN3** : bit (5) > }  $\{ 0 \mid 1 < USF_TN4 : bit (3) > \}$  $\langle GAMMA_TN4 : bit (5) \rangle \}$  $\{ 0 | 1 < USF_TN5 : bit (3) >$ < **GAMMA\_TN5** : bit (5) > }  $\{ 0 \mid 1 < USF TN6 : bit (3) >$ < GAMMA TN6 : bit (5) > { 0 | 1 < **USF\_TN7** : bit (3) > < **GAMMA\_TN7** : bit (5) > }}; <Single Block Allocation struct > ::= < TIMESLOT\_NUMBER : bit (3) >  $\{ 0 | 1 < ALPHA : bit (4) >$ < GAMMA\_TN : bit (5) >}  $\{ 0 \mid 1 < P0 : bit (4) >$ < BTS\_PWR\_CTRL\_MODE : bit (1) >  $\langle \mathbf{PR} | \mathbf{MODE} : \mathrm{bit}(1) \rangle \}$ <Fixed Allocation struct > ::= { 0 | 1 < UPLINK\_TFI\_ASSIGNMENT : bit (5) > } < FINAL\_ALLOCATION : bit (1)> < DOWNLINK\_CONTROL\_TIMESLOT: bit(3)>  $\{ 0 | 1 < P0 : bit (4) \}$ < BTS\_PWR\_CTRL\_MODE : bit (1) > < **PR\_MODE** : bit (1) > } { 0 < TIMESLOT\_ALLOCATION : bit (8) > |1 < Power Control Parameters : Power Control Parameters IE > } < HALF\_DUPLEX\_MODE : bit (1) > -- with length of allocation bitmap  $\{0, 0, 0\}$ < BLOCKS\_OR\_BLOCK\_PERIODS : bit (1) > < ALLOCATION\_BITMAP\_LENGTH : bit (7) > < ALLOCATION\_BITMAP : bit (val(ALLOCATION\_BITMAP\_LENGTH) > -- without length of Allocation Bitmap (fills remainder of this IE) 1 < ALLOCATION\_BITMAP : bit \*\* > } ! < Message escape : 1 bit (\*) = <no string> > };

Editors note: This IE has a number of differences to the contents of the PACKET UPLINK ASSIGNMENT message described in 3GPP TS 04.60:

- the PAGE\_MODE is not included because this IE is sent on a DCCH, not on the PCH/AGCH;
- the Referenced Address is not included because this IE is sent in a dedicated mode message and hence has only one intended recipient;
- the CONTENTION\_RESOLUTION\_TLLI is not included because this IE is sent after dedicated mode contention resolution;
- the 3GPP TS 04.60 Frequency Parameters are not included because the dedicated mode message(s) carry this information in other information elements (eg Mobile Allocation);
- the TBF\_STARTING\_TIME is not included because it duplicates the information in the *Starting Time* IE;
- the ALLOCATION\_REFERENCE is not included because this IE is in a message sent in dedicated mode using a reliable data link.

### Table 10.5.61: RR PACKET UPLINK ASSIGNMENT information element details

#### LENGTH\_IN\_OCTETS (8 bit field)

This field encodes (in binary) the number that is equal to one eighth of the number of bits in the *RR Packet Uplink Assignment* information element that follow the end of this field.

#### TIMESLOT\_ALLOCATION (8 bit field)

This field is encoded as the TIMESLOT\_ALLOCATION field in the PACKET UPLINK ASSIGNMENT message in 3GPP TS 04.60.

#### CHANNEL\_CODING\_COMMAND (2 bit field)

This field is encoded as the CHANNEL\_CODING\_COMMAND field in the PACKET UPLINK ASSIGNMENT message in 3GPP TS 04.60.

#### TLLI\_BLOCK\_CHANNEL\_CODING (1 bit field)

This field is encoded as the TLLI\_BLOCK\_CHANNEL\_CODING field in the PACKET UPLINK ASSIGNMENT message in 3GPP TS 04.60.

#### Packet Timing Advance IE

This field is encoded as the Packet Timing Advance IE in the PACKET UPLINK ASSIGNMENT message in 3GPP TS 04.60.

#### **Dynamic Allocation struct**

This information element contains parameters necessary to define the radio resources of a dynamic allocation or an extended dynamic allocation.

#### Extended Dynamic Allocation (1 bit field)

This information field indicates the medium access mode to be used during the TBF.

- 0 Dynamic Allocation
- 1 Extended Dynamic Allocation

### UPLINK\_TFI\_ASSIGNMENT (5 bit field)

If present, this field is encoded as the UPLINK\_TFI\_ASSIGNMENT information element in the PACKET UPLINK ASSIGNMENT message in 3GPP TS 04.60.

#### **Power Control Parameters IE**

If present, this field is encoded as the Power Control Parameters IE in the PACKET UPLINK ASSIGNMENT message in 3GPP TS 04.60.

#### RLC\_DATA\_BLOCKS\_GRANTED (8 bit field)

If present, this field is encoded as the RLC\_DATA\_BLOCKS\_GRANTED field in the PACKET UPLINK ASSIGNMENT message in 3GPP TS 04.60.

USF for Timeslot Number 0 (TN0) (3 bit field) USF for Timeslot Number 1 (TN1) (3 bit field) USF for Timeslot Number 2 (TN2) (3 bit field) USF for Timeslot Number 3 (TN3) (3 bit field) USF for Timeslot Number 4 (TN4) (3 bit field) USF for Timeslot Number 5 (TN5) (3 bit field)

USF for Timeslot Number 6 (TN6) (3 bit field)

**USF for Timeslot Number 7 (TN7) (3 bit field)** 

If present, these fields are encoded as the USF for Timeslot Number X field (where 0=<X<8) in the PACKET UPLINK ASSIGNMENT message in 3GPP TS 04.60.

### N\_SPARE\_BITS (N bit field)

This field contains N spare bits. 0 = < N < 8. The sender shall set the spare bits are set to 0. The receiver shall ignore the value of these bits. N is chosen so that the *RR Packet Uplink Assignment* IE contains an integer number of octets.

#### Single Block Allocation struct

This information element contains parameters necessary to define the radio resources of a Single Block allocation. For example for sending of a PACKET RESOURCE REQUEST message in a two phase access or a Measurement report.

#### **ALPHA** (4 bit field)

The ALPHA Power control parameter field is coded according to the following table:

bits

 $\begin{array}{c} \underline{4\ 3\ 2\ 1} \\ 0\ 0\ 0\ 0 \\ \vdots \\ \vdots \\ 1\ 0\ 0\ 1 \\ \alpha = 0.1 \\ \alpha = 0.1 \\ \vdots \\ 1\ 0\ 0\ 1 \\ \alpha = 0.9 \\ 1\ 0\ 1\ 0 \\ \alpha = 1.0 \end{array}$ 

All other values are reserved in this version of the protocol and shall be interpreted by the mobile station as  $\alpha = 1.0$ .

#### **TIMESLOT\_NUMBER** (3 bit field)

If present, this field is encoded as the TIMESLOT\_NUMBER field in the PACKET UPLINK ASSIGNMENT message in 3GPP TS 04.60.

#### GAMMA\_TN (5 bit field)

The GAMMA\_TN field is the binary representation of the parameter  $\Gamma_{CH}$  for MS output power control in units of 2 dB, see 3GPP TS 05.08.

#### PO, BTS\_PWR\_CTRL\_MODE and PR\_MODE fields

These fields are optional downlink power control parameters and are encoded as in the PACKET UPLINK ASSIGNMENT message in 3GPP TS 04.60.

#### **Fixed Allocation struct**

This information element contains parameters necessary to define the radio resources of a fixed allocation.

#### **FINAL\_ALLOCATION** (1 bit field)

This field indicates whether this allocation is the last allocation of the TBF.

0 this allocation is not the last allocation of the TBF

1 this allocation is the last allocation of the TBF

#### DOWNLINK\_CONTROL\_TIMESLOT (3 bit field)

This information field indicates the downlink timeslot that mobile station operating in fixed allocation mode shall monitor for downlink PACCH. This field is coded as the binary representation of the timeslot number as defined in 3GPP TS 05.10.

Range 0 to 7

#### HALF\_DUPLEX\_MODE (1 bit field)

This information field indicates, for multislot class 19 to 29, whether the mobile station shall operate in half duplex mode.

Bit

- 0 the MS shall not operate in half duplex mode
- 1 the MS shall operate in half duplex mode

### BLOCKS\_OR\_BLOCK\_PERIODS (1 bit field)

If present, this field is encoded as the BLOCKS\_OR\_BLOCK\_PERIODS field in the PACKET UPLINK ASSIGNMENT message in 3GPP TS 04.60.

### ALLOCATION\_BITMAP\_LENGTH (7 bit field)

If present, this field is encoded as the ALLOCATION\_BITMAP\_LENGTH field in the PACKET UPLINK ASSIGNMENT message in 3GPP TS 04.60.

#### ALLOCATION\_BITMAP (variable length field)

If present, this field is encoded as the ALLOCATION\_BITMAP field in the PACKET UPLINK ASSIGNMENT message in 3GPP TS 04.60. If the ALLOCATION\_BITMAP\_LENGTH field is not present, the ALLOCATION\_BITMAP fills the remainder of the information element. However the network shall ensure, that in the case of a missing ALLOCATION\_BITMAP\_LENGTH, the length of the ALLOCATION\_BITMAP shall not exceed the maximum length of 256 bits. If the network includes more bits than this maximum length the network has to take into account that there may be two kinds of mobiles: mobiles which are capable of handling the large allocation bitmap, and mobiles which would only use the 256 highest numbered ALLOCATION\_BITMAP bit number indexes (as the BLOCKS\_OR\_BLOCK\_PERIOD field is missing) and would ignore the bits with lower indices (i.e. the MS would react after 256 blocks as if the allocation had exhausted (3GPP TS 04.60)).

Extension and Message escape fields

For mobile stations implemented according to this version of the protocol, those fields shall be considered as reserved values.

## 10.5.2.25d RR Packet Downlink Assignment

The *RR Packet Downlink Assignment* information element is sent by the network to the mobile station to indicate the assigned downlink resources.

The *RR Packet Downlink Assignment* information element is coded as shown in tables 10.5.62/3GPP TS 04.08 and 10.5.63/3GPP TS 04.08.

The RR Packet Downlink Assignment is a type 4 information element.

For a mobile station assigned to operate in the fixed allocation MAC mode, the network may assign regularly repeating intervals during which the mobile station shall measure neighbour cell power levels.

### Table 10.5.62: RR PACKET DOWNLINK ASSIGNMENT information element

< RR Packet Downlink Assignment IE > ::= < LENGTH\_IN\_OCTETS : bit (8) > < MAC\_MODE : bit (2) > < RLC\_MODE : bit (1) > < TIMESLOT\_ALLOCATION : bit (8) > < Packet Timing Advance : Packet Timing Advance IE > { 0 | 1 < P0 : bit (4) > < BTS\_PWR\_CTRL\_MODE : bit(1) > } < PR\_MODE : bit (1) > } { 0 | 1 < Power Control Parameters : Power Control Parameters IE > } { 0 | 1 < Power Control Parameters : Power Control Parameters IE > } { 0 | 1 < MEASUREMENT\_STARTING\_TIME : bit (16) > < MEASUREMENT\_INTERVAL : bit (5) > < MEASUREMENT\_BITMAP : bit (8) > } < N\_SPARE\_BITS : bit (N) > ; Editors note: This IE has a number of differences to the contents of the PACKET DOWNLINK ASSIGNMENT message described in 3GPP TS 04.60:

- the PAGE\_MODE is not included because this IE is sent on a DCCH not on the PCH/AGCH;
- Referenced Address is not included because this IE is sent in a dedicated mode message and hence has only one intended recipient.
- the 3GPP TS 04.60 Frequency Parameters are not included because the dedicated mode message(s) carry this information in other information elements (eg Mobile Allocation);
- the TBF\_STARTING\_TIME is not included because it duplicates the information in the *Starting Time* IE.

#### Table 10.5.63: RR PACKET DOWNLINK ASSIGNMENT information element details

#### LENGTH\_IN\_OCTETS (8 bit field)

This field encodes (in binary) the number that is equal to one eighth of the number of bits in the *RR Packet Downlink Assignment* information element that follow the end of this field.

#### MAC\_MODE (2 bit field)

This field is encoded as the MAC\_MODE information field in the PACKET DOWNLINK ASSIGNMENT message in 3GPP TS 04.60.

### **RLC\_MODE** (1 bit field)

This field is encoded as the RLC\_MODE field in the PACKET DOWNLINK ASSIGNMENT message in 3GPP TS 04.60.

#### TIMESLOT\_ALLOCATION (8 bit field)

This field is encoded as the TIMESLOT\_ALLOCATION field in the PACKET DOWNLINK ASSIGNMENT message in 3GPP TS 04.60.

#### Packet Timing Advance IE

This field is encoded as the Packet Timing Advance IE in the PACKET DOWNLINK ASSIGNMENT message in 3GPP TS 04.60.

#### PO, BTS PWR CTRL MODE and PR MODE fields

These fields are optional downlink power control parameters and are encoded as in the PACKET UPLINK ASSIGNMENT message in 3GPP TS 04.60.

#### **Power Control Parameters IE**

This field is encoded as the Power Control Parameters IE in the PACKET DOWNLINK ASSIGNMENT message in 3GPP TS 04.60.

### DOWNLINK\_TFI\_ASSIGNMENT (5 bit field)

If present, this field is encoded as the DOWNLINK\_TFI\_ASSIGNMENT information element in the PACKET DOWNLINK ASSIGNMENT message in 3GPP TS 04.60.

#### MEAUREMENT\_STARTING\_TIME (16 bit field)

If present, this field is encoded as 16-bit *value part* of the Starting Time IE defined in sub-clause 10.5.2.38 (starting with bit 8 of octet 2 and ending with bit 1 of octet 3 of the Starting Time IE).

The frame number shall be aligned to a PDCH block period according to the requirements defined for the 'Absolute Frame Number Encoding' in the 'Starting Time Frame Number Description' IE defined in 3GPP TS 04.60.

#### MEASUREMENT\_BITMAP (8 bit field)

If present, this field is encoded as the MEASUREMENT BITMAP information field in the PACKET DOWNLINK ASSIGNMENT message in 3GPP TS 04.60.

#### MEASUREMENT\_INTERVAL (5 bit field)

If present, this field is encoded as the MEASUREMENT\_INTERVAL field in the PACKET DOWNLINK ASSIGNMENT message in 3GPP TS 04.60.

#### N\_SPARE\_BITS (N bit field)

This field contains N spare bits. 0 = < N < 8. The sender shall set the spare bits are set to 0. The receiver shall ignore the value of these bits. N is chosen so that the *RR Packet Downlink Assignment* IE contains an integer number of octets.

## 10.5.2.26 Page Mode

The purpose of the *Page Mode* information element is to control the action of the mobile station belonging to the paging subgroup corresponding to the paging subchannel.

The *Page Mode* information element is coded as shown in figure 10.5.56/3GPP TS 04.08 and table 10.5.64/3GPP TS 04.08.

The Page Mode is a type 1 information element.



Table 10.5.64/3GPP TS 04.08: Page Mode information element

PM (00 Bits 2 1	ctet 1)
0 0 0 1 1 0 1 1	Normal paging. Extended paging. Paging reorganization. Same as before.
Note:	The value "same as before" has been defined instead of "reserved" to allow the use of this coding with another meaning in an upwards compatible way in later phases of the GSMSsystem.

- 10.5.2.26a Spare
- 10.5.2.26b Spare
- 10.5.2.26c Spare
- 10.5.2.26d Spare
- 10.5.2.27 NCC Permitted

The purpose of the *NCC Permitted* information element is to provide a definition of the allowed NCCs on the BCCH carriers to be reported in the MEASUREMENT REPORT message by the mobile stations in the cell.

The *NCC Permitted* information element is coded as shown in figure 10.5.57/3GPP TS 04.08 and table 10.5.65/3GPP TS 04.08.

The NCC Permitted is a type 3 information element with 2 octets length.




Figure 10.5.57/3GPP TS 04.08: NCC Permitted information element

### Table 10.5.65/3GPP TS 04.08: NCC Permitted information element

+
NCC permitted (octet 2)
The NCC permitted field is coded as a bit map, i.e.
bit N is coded with a "0" if the BCCH carrier with
NCC = N-1 is not permitted for monitoring and with a
"1" if the BCCH carrier with NCC = N-1 is permitted
for monitoring; $N = 1, 2, \dots, 8$ .
++

### 10.5.2.28 Power Command

The purpose of the Power Command information element is to provide the power level to be used by the mobile station.

The *Power Command* information element is coded as shown in figure 10.5.58/3GPP TS 04.08 and table 10.5.66/3GPP TS 04.08.

The *Power Command* is a type 3 information element with 2 octets length.

8	7	6	5	4	3	2	1	_	
		I	Power (	Command	d IEI			octet	1
0 spare	0 spare	0 spare	I	POWER	LEVEL			octet	2

#### Figure 10.5.58/3GPP TS 04.08: Power Command information element

Table 10.5.66/3GPP TS 04.08: Power Command information element

Power level (octet 2) The power level field is coded as the binary representation of the "power control level", see TS GSMB05.05. This value shall be used by the mobile station according to GSMB05.08. Range: 0 to 31.

### 10.5.2.28a Power Command and access type

The purpose of the *Power Command and access type* information element is to provide the power level to be used by the mobile station and the indication that the mobile station can avoid the transmission of handover access.

The *Power Command and access type* information element is coded as shown in figure 10.5.59/3GPP TS 04.08 and table 10.5.67/3GPP TS 04.08.

The Power Command and access type is a type 3 information element with 2 octets length.

8	7	6	5	4	3	2	1		
+	Pot	wer Com	mand a	and Aco	cess Ty	/pe IEI		octet	1
ATC	0 spare	0 spare	F	POWER I	LEVEL			octet	2

Figure 10.5.59/3GPP TS 04.08: Power Command and access type information element

Table 10.5.67/3GPP TS 04.08: Power Command and access type information element

ATC (Access Type Control) (octet 2) bit 8 0 Sending of Handover access is mandatory 1 Sending of Handover access is optional Power level (octet 2) The power level field is coded as the binary representation of the "power control level", see TS GSMS05.05. This value shall be used by the mobile station according to GSMS05.08. Range: 0 to 31.

## 10.5.2.29 RACH Control Parameters

The purpose of the *RACH Control Parameters* information element is to provide parameters used to control the RACH utilization. This information element is broadcast to mobile stations in SYSTEM INFORMATION TYPE 1, 2, 2bis, 3, and 4 messages.

The *RACH Control Parameters* information element is coded as shown in figure 10.5.60/3GPP TS 04.08 and table 10.5.68/3GPP TS 04.08.

The RACH Control Parameters is a type 3 information element with 4 octets length.

	8	7	б	5	4	3	2	1	
-	RACH Control Parameters IEI								octet 1
	Max retrans Tx-integer CELL RE BARR ACCESS						octet 2		
	AC C15	AC C14	AC C13	AC C12	AC C11	EC C10	AC C09	AC C08	octet 3
-	AC C07	AC C06	AC C05	AC C04	AC C03	AC C02	AC C01	AC C00	octet 4

Figure 10.5.60/3GPP TS 04.08: RACH Control Parameters information element

Table 10.5.68/3GPP TS 04.08: RACH Control Parameters information element

```
Max retrans, Maximum number of retransmissions
(octet 2)
Bits
8
0
   0
      Maximum 1 retransmission
       Maximum 2 retransmissions
0
   1
      Maximum 4 retransmissions
Maximum 7 retransmissions
1
   0
1
   1
Tx-integer, Number of slots to spread transmission
(octet 2)
Bits
       4
б
   5
          3
                 3 slots used to spread transmission
4 slots used to spread transmission
   0
0
       0
          0
0
   0
       0
          1
0
   0
          0
       1
                 5 slots used to spread transmission
0
   0
       1
          1
                 6 slots used to spread transmission
0
   1
       0
          0
                 7 slots used to spread transmission
0
   1
       0
                 8 slots used to spread transmission
          1
0
   1
          0
                 9 slots used to spread transmission
       1
0
                10 slots used to spread transmission
   1
       1
          1
1
   0
       0
          0
                11 slots used to spread transmission
1
   0
                12 slots used to spread transmission
      0
          1
1
   0
       1
          0
                14 slots used to spread transmission
1
   0
       1
          1
                16 slots used to spread transmission
          0
1
   1
       0
                20 slots used to spread transmission
1
   1
       0
          1
                25 slots used to spread transmission
   1
          0
                32 slots used to spread transmission
1
       1
1
   1
       1
          1
                50 slots used to spread transmission
  CELL_BAR_ACCESS, Cell Barred for Access (octet 2)
Bit
2
   The cell is not barred, see TS. {\rm GSM}\pm03.22 The cell is barred, see TS. {\rm GSM}\pm03.22
0
1
RE, Call reestablishment allowed (octet 2)
Bit
1
0
   Call Reestablishment allowed in the cell
1 Call Reestablishment not allowed in the cell
EC Emergency Call allowed (octet 3 bit 3)
3
0
   Emergency call allowed in the cell to all MSs
   Emergency call not allowed in the cell except
1
   for the MSs that belong to one of the classes
   between 11 to 15
AC CN, Access Control Class N (octet 3(except bit 3)
and octet 4)
For a mobile station with AC C = N access is not barred if the AC CN bit is coded with a "0"; N = 0, 1, ... 9,11, ..., 15.
                            _____+
```

### 10.5.2.30 Request Reference

The purpose of the *Request Reference* information element is to provide the random access information used in the channel request and the frame number, FN modulo 42432 in which the channel request was received.

The *Request Reference* information element is coded as shown in figure 10.5.61/3GPP TS 04.08 and table 10.5.69/3GPP TS 04.08.

The *Request Reference* is a type 3 information element with 4 octets length.




Figure 10.5.61/3GPP TS 04.08: Request Reference information element

Table 10.5.69/3GPP TS 04.08: Request Reference information element


```
RA, Random Access Information (octet 2)
This is an unformatted 8 bit field. Typically the
contents of this field are coded the same as the
CHANNEL REQUEST message shown in Table 9.9,
sub-clause 9.1.8
T1' (octet 2)
The T1' field is coded as the binary representation
of (FN div 1326) mod 32.
T3 (octet 3 and 4)
The T3 field is coded as the binary representation
of FN mod 51. Bit 3 of octet 2 is the most
significant bit and bit 6 of octet 3 is the least
significant bit.
T2 (octet 4)
The T2 field is coded as the binary representation
of FN mod 26.
NOTE 1: The frame number, FN modulo 42432 can be cal-
culated as 51x((T3-T2) mod 26)+T3+51x26xT1'
```


## 10.5.2.31 RR Cause

The purpose of the *RR Cause* information element is to provide the reason for release or the reason for completion of an assignment or handover.

The *RR Cause* information element is coded as shown in figure 10.5.62/3GPP TS 04.08 and table 10.5.70/3GPP TS 04.08.

The *RR Cause* is a type 3 information element with 2 octets length.





```
RR cause value (octet 2)
Bits
8 7 6
      5
        4 3 2 1
0 0 0 0 0 0 0 0
                  Normal event
0 0 0 0 0 0 0 0 1 Abnormal release, unspecified
0 0 0 0 0 0 1 0 Abnormal release, channel
                       unacceptable
0 0 0 0 0 0 1 1 Abnormal release, timer expired
0 0 0 0 0 1 0 0 Abnormal release, no activity on
                       the radio path
0 0 0 0 0 1 0 1
                     Preemptive release
0 0 0 0 1 0 0 0
                   Handover impossible, timing advance
                     out of range
 0 0 0 1 0 0 1
                     Channel mode unacceptable
0
 Call already cleared
Semantically incorrect message
0
0
Õ
                    Invalid mandatory information
Message type non-existent or not
0
  1
    1
       0 0 0 0 0
0 1 1 0 0 0 0 1
                        implemented
                     Message type not compatible with protocol state
0 1 1 0 0 0 1 0
0 1 1 0 0 1 0 0
                     Conditional IE error
0 1 1 0 0 1 0 1
                     No cell allocation available
                     Protocol error unspecified
0 1 1 0 1 1 1 1
All other cause values shall be treated as 0000 0000,
'normal event'
The listed RR cause values are defined in Annex F.
```

Table 10.5.70/3GPP TS 04.08: RR Cause information element

### 10.5.2.32 SI 1 Rest Octets

The SI 1 Rest Octets information element contains the position about the NCH and spare bits.

The SI 1 Rest Octets information element is a type 5 information element with 1 octet length.

<SI1 Rest Octets> ::= {L |H <NCH Position : bit (5)> }; <spare padding> ; Table 10.5.71/3GPP TS 04.08: SI 1 Rest Octets information element

\_\_\_\_\_ NCH Position on the CCCH The values in the NCH Position field indicates the block number of the CCCH block which is used for the first NCH block and the number of blocks used for the NCH. (The block numbering corresponds to table 5 in clause 7 of GSMB05.02) The absence of the NCH position field indicates that there is no NCH in the cell/on the carrying CCCH slot The following coding applies if 1 or more basic physical channels are used for CCCH, not combined with SDCCHs. No of blocks Number of first block Value 0 0 0 0 0 0 0 1 0 1 0 56 Ō 0 0 0 0 1 0 0 0 0 1 2 3 4 5 1 1 1 1 1 1 1 0 0 0 2 2 2 2 2 2 Ō 0 0 1 2 3 4 Ō 0 1 Ō 1 2 3 0 Ō 0 0 2 0 0 0 0 1 1 1 Other values are reserved for future use. A mobile station receiving a reserved value shall behave as if the NCH position was not present

In the case the CCCH configuration is not compatible with the NCH position (e.g., CCCH with combined SDCCH and the value different from 00001, 00010 or 00111), the mobile station shall behave as if the NCH Position field was not present.

## 10.5.2.33 SI 2bis Rest Octets

The *SI 2bis Rest Octets* information element contains only spare bits. Its purpose is to allow the upward compatible introduction of new information on the BCCH in later phases.

The SI 2bis Rest Octets information element is a type 5 information element with1 octet length.

```
<SI2bis Rest Octets> ::=
<spare padding> ;
```

## 10.5.2.33a SI 2ter Rest Octets

The *SI 2ter Rest Octets* information element contains only spare bits. Its purpose is to allow the upward compatible introduction of new information on the BCCH in later phases.

The SI 2ter Rest Octets information element is a type 5 information element with 4 octets length.

<SI2ter Rest Octets> ::= <spare padding> ;

## 10.5.2.34 SI 3 Rest Octets

The *SI 3 Rest Octets* information element is coded according to the syntax specified below and described in tables 10.5.72/3GPP TS 04.08, 10.5.73/3GPP TS 04.08 and 10.5.74/3GPP TS 04.08(See sub-clause 10.5.2.35).

The SI 3 Rest Octets information element is a type 5 information element with 5 octets length.

#### Table 10.5.72/3GPP TS 04.08: SI 3 Rest Octets information element is a type 5 information element

<si3 oc<="" rest="" th=""><th>xtet&gt; ::=</th></si3>	xtet> ::=
	<optional parameters="" selection=""></optional>
	<optional offset="" power=""></optional>
	<system 2ter="" indicator="" information=""></system>
	<early classmark="" control="" sending=""></early>
	<scheduling and="" if="" where=""></scheduling>
	{ L   H <gprs indicator=""> }</gprs>
<	<spare padding=""> :</spare>
<optional se<="" td=""><td>ection Parameters&gt; ::=</td></optional>	ection Parameters> ::=
	L   <b>H</b> <selection parameters="">;</selection>
	arameters> ::=
	< <b>CBQ</b> : bit (1)>
	<cell_reselect_offset: (6)="" bit=""></cell_reselect_offset:>
	<temporary_offset: (3)="" bit=""></temporary_offset:>
<	< <b>PENALTY_TIME</b> : bit (5)>;
<optional pc<="" td=""><td>ower Offset&gt; ::=</td></optional>	ower Offset> ::=
	L   H <power (2)="" bit="" offset:="">;</power>
<system info<="" td=""><td>ormation 2ter Indicator&gt; ::=</td></system>	ormation 2ter Indicator> ::=
]	L   <b>H</b> ;
(Early Class	mark Sanding Controls of
•	mark Sending Control> ::= L   <b>H;</b>
1	L   <b>II</b> ,
<scheduling< td=""><td>if and where&gt;::=</td></scheduling<>	if and where>::=
	L   <b>H</b> < <b>WHERE</b> : bit (3)>;
<gprs indic<="" td=""><td>cator&gt; ::=</td></gprs>	cator> ::=
	< <b>RA COLOUR</b> : bit (3) $>$
<	< SI13 POSITION : bit >;

CBQ, CELL\_BAR\_QUALIFY (1 bit field)

CELL\_BAR\_QUALIFY is used by the network to control mobile station cell selection and reselection. The use and coding of this parameter is defined in 3GPP TS 05.08.

CELL\_RESELECT\_OFFSET (6 bit field)

CELL\_RESELECT\_OFFSET is coded as the binary representation of the "CELL\_RESELECT\_OFFSET" in 3GPP TS 05.08. It is a value used by the mobile station to apply a positive or negative offset to the value of C2 as defined in 3GPP TS 03.22 and 3GPP TS 05.08.

TEMPORARY\_OFFSET (3 bit field)

The TEMPORARY\_OFFSET field is coded as the binary representation of the "TEMPORARY\_OFFSET" in 3GPP TS 05.08. It is used by the mobile station as part of its calculation of C2 for the cell reselection process as described in 3GPP TS 05.08. It is used to apply a negative offset to C2 for the duration of PENALTY\_TIME.

PENALTY\_TIME (5 bit field)

The PENALTY\_TIME is coded as the binary representation of the "PENALTY\_TIME" in 3GPP TS 05.08. It defines the length of time for which TEMPORARY\_OFFSET is active. The usage of PENALTY\_TIME is described in 3GPP TS 03.22 and 3GPP TS 05.08.

Power Offset (2 bit field)

Power Offset is used only by DCS 1800 Class 3 MSs to add a power offset to the value of MS\_TXPWR\_MAX\_CCH used for its random access attempts. It is also used by the MS in its calculation of C1 and C2 parameters. Its use is defined in 3GPP TS 05.08

If this parameter is transmitted on a BCCH carrier within the DCS 1800 band, its meaning shall be described below:

Value Meaning

- 00 0 dB power offset
- 01 2 dB power offset
- 10 4 dB power offset
- 11 6 dB power offset

If this parameter is transmitted on a BCCH carrier outside the DCS 1800 band, then all bit positions shall be treated as spare.

System Information 2ter Indicator (1 bit field)

- L SYSTEM INFORMATION TYPE 2ter message is not available
- H SYSTEM INFORMATION TYPE 2ter message is available

Early Classmark Sending Control (1 bit field)

- L Early Classmark Sending is forbidden
- H Early Classmark Sending is allowed

WHERE (3 bit field)

If the **WHERE** field is not contained in the information element, this indicates that BCCH scheduling information is not sent in SYSTEM INFORMATION TYPE 9 on the BCCH.

If the **WHERE** field is contained in the information element, this indicates that BCCH scheduling information is sent in SYSTEM INFORMATION TYPE 9 on the BCCH and that SYSTEM INFORMATION TYPE 9 messages are sent in the blocks of the BCCH norm for which ((FN DIV 51) mod (8) = 4 AND (((FN DIV 51) DIV 8) mod (n+1))= 0), where n is the value encoded in binary in WHERE.

GPRS Indicator

The **GPRS Indicator** contains the RA COLOUR field and the SI13\_POSITION field. If the GPRS Indicator is contained in the information element, it indicates that GPRS is supported in the cell.

### RA COLOUR (3 bit field)

If the mobile station receives different values of the RA COLOUR field in different cell, the mobile station shall interpret the cell re-selection information as if the two cells belong to different routeing areas.

#### SI13\_POSITION (1 bit field)

The SI13 POSITION field indicates the minimum schedule for where the SYSTEM INFORMATION TYPE 13 message is sent on BCCH, see 3GPP TS 05.02:

- 0 SYSTEM INFORMATION TYPE 13 message is sent on BCCH Norm;
- 1 SYSTEM INFORMATION TYPE 13 message is sent on BCCH Ext.

## 10.5.2.35 SI 4 Rest Octets

The *SI 4 Rest Octets* information element includes parameters which are used by the mobile station for cell selection and reselection purposes. It may also include the POWER OFFSET parameter used by DCS 1800 Class 3 MS.

Its content is described in Table 10.5.73/3GPP TS 04.08 and 10.5.74/3GPP TS 04.08.

NOTE: In the future evolution of this standard the values 64h and 72h shall not be used as values of the first octet when this information element is used in the SYSTEM INFORMATION TYPE 4 message. This will prevent mobile stations misinterpreting this information as the CBCH IEIs.

The SI 4 Rest Octets information element is a type 5 information element with 1 to 11 octets length.

```
<SI4 Rest Octets> ::= <SI4 Rest Octets_O>
            {L<Break indicator>| H<SI Rest Octets S}
            <spare padding>;
<SI4 Rest Octets O> ::= <Optional selection parameters>
            <Optional Power offset>
            {L | H < GPRS Indicator >};
<SI4 Rest Octets_S> ::= {L | H <LSA Parameters>}
            {\mathbf{L} | \mathbf{H} < \text{Cell Identity} : \text{bit(16)} }
            {L | H <LSA ID information>};
\langle Break Indicator \rangle : := L | H ;
<SI7 Rest Octets> ::= <SI4 Rest Octets O><SI4 Rest Octets S> |<SI4 Rest Octets S>;
<SI8 Rest Octets> ::= <SI4 Rest Octets O><SI4 Rest Octets S> |<SI4 Rest Octets S>;
<Optional Selection Parameters> ::= L | H <Selection Parameters> ;
<Selection Parameters> ::=
                                 <CBQ : bit (1)>
                                 <CELL RESELECT OFFSET : bit (6)>
                                 <TEMPORARY OFFSET : bit (3)>
                                 < PENALTY_TIME : bit (5)>;
<Optional Power Offset> ::=
                                 \mathbf{L} \mid \mathbf{H} < \text{Power Offset} : bit(2) > ;
<GPRS Indicator> ::=
                                 < RA COLOUR : bit (3) >
                                 < SI13 POSITION : bit >;
<LSA Parameters> ::=
                                 <PRIO_THR : bit (3)>
                                 <LSA OFFSET : bit (3)>
                                 {0 | 1 <MCC : bit (12)>
                                  <MNC : bit (12)>};
<LSA ID information> ::=
                                    <LSA identity>
                                 {0 | 1 <LSA_ID information>};
                                 {0<LSA_ID : bit (24)>
<LSA identity> ::=
```

## |1<ShortLSA\_ID : bit (10)>}

If "ACS " in the System information type 4 message is set to "1" then the SI 7 and SI 8 rest octets consists of "SI4 Rest Octets\_O" and "SI4 Rest Octets\_S", otherwise of only "SI4 Rest Octets\_S".

#### Table 10.5.73/3GPP TS 04.08

CBQ, CELL\_BAR\_QUALIFY (1 bit field)

CELL\_BAR\_QUALIFY is used by the network to control mobile station cell selection and reselection. The use and coding of this parameter is defined in 3GPP TS 05.08.

CELL\_RESELECT\_OFFSET (6 bit field)

CELL\_RESELECT\_OFFSET is coded as the binary representation of the "CELL\_RESELECT\_OFFSET" in 3GPP TS 05.08. It is a value used by the mobile station to apply a positive or negative offset to the value of C2 as defined in 3GPP TS 03.22 and 3GPP TS 05.08.

TEMPORARY\_OFFSET (3 bit field)

The TEMPORARY\_OFFSET field is coded as the binary representation of the "TEMPORARY\_OFFSET" in 3GPP TS 05.08. It is used by the mobile station as part of its calculation of C2 for the cell reselection process as described in 3GPP TS 05.08. It is used to apply a negative offset to C2 for the duration of PENALTY\_TIME.

PENALTY\_TIME (5 bit field)

The PENALTY\_TIME is coded as the binary representation of the "PENALTY\_TIME" in 3GPP TS 05.08. It defines the length of time for which TEMPORARY\_OFFSET is active. The usage of PENALTY\_TIME is described in 3GPP TS 03.22 and 3GPP TS 05.08.

### Table 10.5.74/3GPP TS 04.08

POWER OFFSET (2 bit field)

POWER OFFSET is used only by DCS 1800 Class 3 MSs to add a power offset to the value of MS\_TXPWR\_MAX\_CCH used for its random access attempts. It is also used by the MS in its calculation of C1 and C2 parameters. Its use is defined in 3GPP TS 05.08

If this parameter is transmitted on a BCCH carrier within the DCS 1800 band, its meaning shall be described below:

Value Meaning

- 00 0 dB power offset
- 01 2 dB power offset
- 10 4 dB power offset
- 11 6 dB power offset

If this parameter is transmitted on a BCCH carrier outside the DCS 1800 band, then all bit positions shall be treated as spare.

### **GPRS Indicator**

The **GPRS Indicator** contains the RA COLOUR field and the SI13\_POSITION field. If the GPRS Indicator is contained in the information element, it indicates that GPRS is supported in the cell.

#### RA COLOUR (3 bit field)

If the mobile station receives different values of the RA COLOUR field in different cell, the mobile station shall interpret the cell re-selection information as if the two cells belong to different routeing areas.

### SI13\_POSITION (1 bit field)

The SI13 POSITION field indicates the minimum schedule for where the SYSTEM INFORMATION TYPE 13 message is sent on BCCH, see 3GPP TS 05.02:

- 0 SYSTEM INFORMATION TYPE 13 message is sent on BCCH Norm;
- 1 SYSTEM INFORMATION TYPE 13 message is sent on BCCH Ext.

#### Break Indicator

The Break Indicator indicates if parameters in addition to those in SI 4 rest octets are sent in SI7 and SI8.

- L Additional parameters are not sent in SYSTEM INFORMATION TYPE 7 and 8.
- H Additional parameters, "SI4 Rest Octets\_S" are sent in SYSTEM INFORMATION TYPE 7 and 8.

### PRIO\_THR (3 bit field)

The PRIO\_THR field is a signal threshold used by the mobile station to determine whether prioritised cell re-selection shall apply. The use and coding of this parameters is defined in 3GPP TS 05.08.

#### LSA\_OFFSET (3 bit field)

The LSA\_OFFSET field applies an offset for LSA reselection between cells with same LSA priorities. The use and coding of this parameters is defined in 3GPP TS 05.08.

#### MCC and MNC (24 bit field)

If the escape PLMN is broadcast in SI3 and SI4 the cell is used for SoLSA exclusive access and the MCC and MNC field shall be included. The MS shall then for all purposes use the MCC and MNC values received in the LSA Parameters instead of the ones received in the Location Area information element in SI3 and 4, eg when deriving the PLMN identity, the Location Area Identity and Cell Global Identity broadcast by the cell. The MCC and MNC value field is coded as specified in Figure 10.5.3/3GPP TS 04.08 and Table 10.5.3/3GPP TS 04.08.

### Cell Identity (16 bit field)

The purpose of the Cell Identity is to identify a cell within a location area. The Cell Identity is coded as shown in figure 10.2/3GPP TS 04.08 and table 10.5/3GPP TS 04.08.

LSA\_ID (24 bit field) The purpose of the LSA\_ID field is to identify a LSA. The LSA ID value field is specified in 3GPP TS 03.03.

### Short LSA\_ID (10 bit field)

The purpose of the Short LSA\_ID field is to identify a LSA. The LSA ID defined by the Short LSA\_ID is a LSA\_ID as specified in 3GPP TS 03.03 with bit 0 set to "0" bit 1 to 10 set to the value of the Short LSA\_ID field (LSB in bit 1, MSB in bit 10) and bit 11 to 23 set to "0".

## 10.5.2.35a SI 6 Rest Octets

The *SI 6 Rest Octet* information element may contain information concerning the paging, notification channels, VBS and VGCS services of the cell.

Mobile stations not supporting VGCS listening or VBS listening can ignore the information contained in this information element.

The value part is as shown below:

<SI6 rest octets> ::= {L I H <PCH and NCH info>} {L I H <VBS/VGCS options : bit(2)>} <implicit spare >;

<PCH and NCH info> ::= <Paging channel restructuring> <NLN(SACCH) : bit(2)>  $\{0 \text{ I } 1 < \text{Call priority : bit } (3) > \}$ <NLN status : bit >; <paging channel restructuring>::= -- paging channel is restructured 1 0 -- paging channel is not restructured <VBS/VGCS options> ::= <inband notifications> <inband pagings>; <inband notifications>::= -- the network does not provide notification on FACCH so that the mobile should 0 inspect the NCH for notifications 1 -- the mobile shall be notified on incoming high priority VBS/VGCS calls through NOTIFICATION/FACCH, the mobile need not to inspect the NCH <inband pagings>::= 0 -- the network does not provide paging information on FACCH so that the mobile should inspect the PCH for pagings 1 -- the mobile shall be notified on incoming high priority point-to-point calls through NOTIFICATION/FACCH, the mobile need not to inspect the PCH

#### Attributes, field contents:

- 1. For <NLN(SACCH): bit(2)>: see sub-clause 10.5.2.23.
- 2. For <call priority>: see sub-clause 10.5.2.23. Indication of the highest priority associated with VBS/VGCS calls in a cell.

## 10.5.2.36 SI 7 Rest Octets

The *SI* 7 *Rest Octets* information element includes parameters which are used by the mobile station for cell selection and reselection purposes. It may also include the POWER OFFSET parameter used by a DCS 1800 Class 3 MS.

The SI 7 Rest Octets information element is a type 5 information element with 21 octets length.

The *SI* 7 *Rest Octets* information element is coded as the *SI* 4 *Rest Octets*. Its contents is described in Table 10.5.2.35a-b/3GPP TS 04.08.

## 10.5.2.37 SI 8 Rest Octets

The *SI 8 Rest Octets* information element includes parameters which are used by the mobile station for cell selection and reselection purposes. It may also include the POWER OFFSET parameter used by a DCS 1800 Class 3 MS.

The SI 8 Rest Octets information element is a type 5 information element with 21 octets length.

The *SI* 8 *Rest Octets* information element is coded as the *SI* 4 *Rest Octets*. Its contents is described in table 10.5.73/3GPP TS 04.08 and 10.5.74/3GPP TS 04.08.

## 10.5.2.37a SI 9 Rest Octets

The SI 9 Rest Octets information element contains information about scheduling of some or all of the information on the BCCH.

The SI 9 Rest Octets information element is a type 5 information element with 17 octets length.

<si9 octets="" rest=""></si9>	::= {L   H <scheduling info="">} <spare padding="">;</spare></scheduling>
<scheduling info=""></scheduling>	::= <info type=""> <positions> {0   1 <scheduling info="">};</scheduling></positions></info>
<info type=""></info>	::= 0 <info_type_4: (4)="" bit="">   1 0 <info_type_5: (5)="" bit="">   1 1 <info_type_6: bit6)="">;</info_type_6:></info_type_5:></info_type_4:>
<positions> :</positions>	$:=  \langle \text{Position} \rangle \{ 0 \mid 1 \langle \text{Position} \rangle \}$
	::= < <b>Modulus</b> : bit(4)> < <b>Relative_position</b> : <bit>&gt;length depends on modulus &lt;<b>Bcch_type</b>: bit(1)&gt;;</bit>

### Attributes

The *scheduling info* indicates one or more information types (in *info type*) together with their *positions*. Here, a *position* specifies at which relative position P (specified in **relative\_position**) modulo a position modulus M (specified in **modulus**) messages of the given information type are sent, on the BCCH norm or BCCH ext (see 3GPP TS 05.02) as indicated in **bcch\_type**. Precisely, messages of the given information type are sent in the multiframes for which

((frame number) DIV 51) mod (M)) = P.

If the position modulus M equals 0, the information type is not sent.

#### **Field contents**

The fields of the SI 9 Rest Octets information element are coded as shown in table 10.75/3GPP TS 04.08.

### Table 10.5.75/3GPP TS 04.08: SI 9 rest octet information element

### Info\_type\_4\_(4 bits)

This field contains a binary encoded non-negative integer number assigned to a type of information sent on the BCCH. All values indicate unknown, unnecessary information and are reserved for future use.

#### Info\_type\_5 (5 bits)

This field contains a binary encoded non-negative integer number assigned to a type of information sent on the BCCH. All values except those defined below indicate unknown, unnecessary information and are reserved for future use.

Info\_type\_5:

0 0000System Information type 1

0 0001 System Information type 2

0 0010System Information type 2bis

0 0011 System Information type 2ter

0 0100System Information type 3

0 0101 System Information type 4

0 0110System Information type 7

0 0111 System Information type 8

0 1000System Information type 9

- 0 1001 System Information type 13
- 0 1011 System Information type 16
- 0 1100System Information type 17

#### Info\_type\_6\_(6 bits)

This field contains a binary encoded non-negative integer number assigned to a type of information sent on the BCCH. All values indicate unknown, unnecessary information and are reserved for future use.

modulus (4 bits)

This field encodes the **position modulus**, according to the following encoding method. Let N be the integer encoded in binary in the **modulus** field; the **position modulus** is then defined as follows :

If N=0, the **position modulus** is 0,

if N>0, the **position modulus** is  $2^{N+1}$ .

relative position (0 bits if the non-negative integer n contained in the modulus field is 0; n+1 bits, if the non-negative integer N encoded in the modulus field is > 0.

This field contains the N+1 bit binary encoding of a non-negative integer number  $< 2^{N+1}$ .

bcch\_type (1 bit)

0 BCCH norm(as defined in 3GPP TS 05.08)

1 BCCH ext (as defined in 3GPP TS 05.08)

## 10.5.2.37b SI 13 Rest Octets

The *SI 13 Rest Octets* information element is coded according to the syntax specified below and described in table 10.5.76/3GPP TS 04.08.

The SI 13 Rest Octets information element is a type 5 information element with 21 octets length.

```
< SI 13 Rest Octets > ::=
 { L | H
    < BCCH CHANGE MARK : bit (3) >
    < SI_CHANGE_FIELD : bit (4) >
    { 0 | 1 < SI13 CHANGE MARK : bit (2) >
          < GPRS Mobile Allocation : GPRS Mobile Allocation IE > }
                                                                        -- Defined in
3GPP TS 04.60
    { 0
                       -- PBCCH not present in cell :
       <RAC : bit (8) >
       < SPGC_CCCH_SUP : bit >
       < PRIORITY_ACCESS_THR : bit (3) >
       < NETWORK CONTROL ORDER : bit (2) >
       < GPRS Cell Options : GPRS Cell Options IE >
                                                                         -- Defined in
3GPP TS 04.60
       < GPRS Power Control Parameters : GPRS Power Control Parameters struct >
    |1
                       -- PBCCH present in cell :
       < PSI1 REPEAT PERIOD : bit (4) >
       < PBCCH Description : PBCCH Description struct >
    }
 }
 < spare padding > ;
< GPRS Power Control Parameters struct > ::=
```

< AL	<b>PHA</b> : bit (4) >
< <b>T_</b> A	$\mathbf{WG}_{\mathbf{W}}$ : bit (5) >
< <b>T_</b> A	$\mathbf{AVG}_{\mathbf{T}}$ : bit (5) >
< <b>PC</b>	_ <b>MEAS_CHAN</b> : bit >
< <b>N_</b> A	<b>AVG_I</b> : bit (4) >;
< PBCC	CH Description struct > ::=
< <b>Pb</b> :	bit (4)
< TS0	C: bit (3) >
< <b>TN</b>	: bit (3) >
{ <b>00</b> }	BCCH carrier
01	< <b>ARFCN</b> : bit (10) >
1	< <b>MAIO</b> : bit (6) $>$ ;

#### Table 10.5.76/3GPP TS 04.08: SI 13 Rest Octets information element

#### BCCH\_CHANGE\_MARK (3 bit field)

This field indicates the status of the information on BCCH. The value of this field may be changed when information on BCCH is changed, see 3GPP TS 04.60.

#### SI\_CHANGE\_FIELD (4 bit field)

This field is the binary representation of which information was changed at the last indication in BCCH\_CHANGE\_MARK, see 3GPP TS 04.60. Range 0 to 15:

- 0 Update of *unspecified* SI message or SI messages;
- 1 Update of SI1 message;
- 2 Update of SI2, SI2 bis or SI2 ter message;
- 3 Update of SI3, SI4, SI7 or SI8 message;
- 4 Update of SI9 message;

All other values shall be interpreted as 'update of unknown SI message type'.

#### SI13\_CHANGE\_MARK (2 bit field)

This field is the binary representation of the SI change mark identifying the GPRS Mobile Allocation provided in SI13 and PSI13 messages. Range: 0 to 3.

#### GPRS Mobile Allocation (information element)

This information element is the representation of the GPRS mobile allocation provided in SI13 and PSI13 messages. It is identified by MA\_NUMBER = 14 when referenced from a packet assignment message. The *GPRS Mobile Allocation* information element is defined in 3GPP TS 04.60. When used in SI13 or PSI13 message, this information element shall refer to the cell allocation defined for the cell in SI1 or PSI2.

#### RAC (8 bit field)

This field is the binary representation of the Routing Area Code, see 3GPP TS 03.03.

### **SPGC\_CCCH\_SUP** (bit field)

This field indicates the support of the parameter SPLIT\_PG\_CYCLE on CCCH from the network side:

- 0 SPLIT\_PG\_CYCLE is not supported on CCCH in this cell;
- 1 SPLIT\_PG\_CYCLE is supported on CCCH in this cell.

The **PRIORITY\_ACCESS\_THR** field (3 bit) is the binary representation of the parameter PRIORITY\_ACCESS\_THR:

- 000 packet access is not allowed in the cell;
- 0 0 1 spare, shall be interpreted as '000' (packet access not allowed);
- 0 1 0 spare, shall be interpreted as '000' (packet access not allowed);
- 011 packet access is allowed for priority level 1;
- 1 0 0 packet access is allowed for priority level 1 to 2;
- 1 0 1 packet access is allowed for priority level 1 to 3;
- 1 1 0 packet access is allowed for priority level 1 to 4;
- 1 1 1 spare, shall be interpreted as '110' (packet access allowed).

The **NETWORK\_CONTROL\_ORDER** field (2 bit) is the binary representation of the parameter NETWORK\_CONTROL\_ORDER, see 3GPP TS 04.60:

- 0.0 NC0: MS controlled cell re-selection, no measurement reporting.
- 01 NC1: MS controlled cell re-selection, MS sends measurement reports.
- 10 NC2: Network controlled cell re-selection, MS sends measurement reports.
- 1 1 Reserved for future use, interpreted as NC0 by mobile station.

### GPRS Cell Options (information element)

The GPRS Cell Option information element is defined in 3GPP TS 04.60.

### **PSI1\_REPEAT\_PERIOD** (4 bit field)

This field is the representation of the PSI1 repeat period. The field is coded according to the following table:

- 0000 PSI1 repeat period = 1 multiframe
- 0001 PSI1 repeat period = 2 multiframes
- 1111 PSI1 repeat period = 16 multiframes

### **GPRS Power Control Parameters struct**

The **ALPHA** field (4 bit) is the binary representation of the parameter  $\alpha$  for MS output power control in units of 0.1, see 3GPP TS 05.08: Range: 0 to 10. Values greater than 10 shall be interpreted as 10 by the mobile station.

The **T\_AVG\_W** field (5 bit) is the binary representation of the parameter  $T_{AVG_W}$  for MS output power control, see 3GPP TS 05.08: Range: 0 to 25. Values greater than 25 shall be interpreted as 25 by the mobile station.

The **T\_AVG\_T** field (5 bit) is the binary representation of the parameter  $T_{AVG_T}$  for MS output power control, see 3GPP TS 05.08: Range: 0 to 25. Values greater than 25 shall be interpreted as 25 by the mobile station.

The **PC\_MEAS\_CHAN** field (bit) indicates the type of channel which shall be used for downlink measurements for power control:

- 0 BCCH;
- 1 PDCH.

The N\_AVG\_I field (4 bit) is the binary representation of the parameter  $N_{AVG_I}$  for MS output power control, see 3GPP TS 05.08: Range: 0 to 15.

## **PBCCH Description struct**

The PBCCH description struct provides the channel description for the PBCCH. The frequency description for the PBCCH may be specified by an ARFCN (non-hopping radio frequency channel) or a MAIO (hopping radio frequency channel) field. In case of a hopping radio frequency channel, the PBCCH shall use the GPRS mobile allocation specified in this message. If none of the ARFCN or MAIO fields are present, the PBCCH shall use the BCCH carrier.

Pb (4bit) (for encoding and description see the Global Power Control Parameters IE)

The **TSC** field (3 bit) is the binary representation of the training sequence code used for PBCCH and PCCCHs. Range: 0 to 7.

The **TN** field (3 bit) is the binary representation of the timeslot number for the PBCCH and the corresponding PCCCH. Range: 0 to 7.

The ARFCN field (10 bit) is the binary representation of the absolute RF channel number. Range: 0 to 1023.

The MAIO field (6 bit) is the binary representation of the mobile allocation index offset. Range: 0 to 63.

10.5.2.37c [Spare]

10.5.2.37d [Spare]

## 10.5.2.37e SI 16 Rest Octets

The SI 16 Rest Octets information element includes parameters which are used by the mobile station for cell selection and reselection purposes.

The *SI 16 Rest Octets* information element is coded according to the syntax specified below. Its contents is described in Table 10.52c/3GPP TS 04.08.

The SI 16 Rest Octets information element is a type 5 information element with 21 octets length.

<si16 octets="" rest=""> ::={L   H</si16>	I <lsa parameters="">} <spare padding=""> ;</spare></lsa>
<si17 octets="" rest=""> ::=&lt; SI16</si17>	5 Rest Octets>;
<lsa parameters=""> ::=</lsa>	<prio_thr (3)="" :="" bit=""> <lsa_offset (3)="" :="" bit=""> {<b>0</b>   <b>1</b> <mcc (12)="" :="" bit=""> <mnc (12)="" :="" bit="">} <lsa id="" information="">;</lsa></mnc></mcc></lsa_offset></prio_thr>
<lsa id="" information=""> ::=</lsa>	<lsa identity=""> {<b>0</b>   <b>1</b> <lsa id="" information="">} ;</lsa></lsa>
<lsa identity=""> : :=</lsa>	{0 <lsa_id (24)="" :="" bit="">  1 <shortlsa_id (10)="" :="" bit="">};</shortlsa_id></lsa_id>

### Table 10.52c/3GPP TS 04.08

PRIO\_THR (3 bit field)

The PRIO\_THR field is a signal threshold used by the mobile station to determine whether prioritised cell re-selection shall apply. The use and coding of this parameters is defined in 3GPP TS 05.08.

### LSA\_OFFSET (3 bit field)

The LSA\_OFFSET field applies an offset for LSA reselection between cells with same LSA priorities. The use and coding of this parameters is defined in 3GPP TS 05.08.

### MCC and MNC (24 bit field)

If the escape PLMN is broadcast in SI3 and SI4 the cell is used for SoLSA exclusive access and the MCC and MNC field shall be included. The MS shall then for all purposes use the MCC and MNC values received in the LSA Parameters instead of the ones received in the Location Area information element in SI3 and 4, eg when deriving the PLMN identity, the Location Area Identity and Cell Global Identity broadcast by the cell. The MCC and MNC value field is coded as specified in Figure 10.5.3/3GPP TS 04.08 and Table 10.5.3/3GPP TS 04.08.

LSA\_ID (24 bit field)

The purpose of the LSA\_ID field is to identify a LSA. The LSA ID value field is coded as specified in 3GPP TS 03.03.

Short LSA\_ID (10 bit field)

The purpose of the Short LSA\_ID field is to identify a LSA. The LSA ID defined by the Short LSA\_ID is a LSA\_ID as specified in 3GPP TS 03.03 with bit 0 set to "0" bit 1 to 10 set to the value of the Short LSA\_ID field (LSB in bit 1, MSB in bit 10) and bit 11 to 23 set to "0".

## 10.5.2.37f SI 17 Rest Octets

The *SI 17 Rest Octets* information element includes parameters, which are used by the mobile station for cell selection and reselection purposes.

The SI 17 Rest Octets information element is a type 5 information element with 21 octets length.

The *SI 17 Rest Octets* information element is coded as the *SI 16 Rest Octets*. Its contents is described in Table 10.52c/3GPP TS 04.08.

## 10.5.2.38 Starting Time

The purpose of the *Starting Time* information element is to provide the start TDMA frame number, FN modulo 42432.

The *Starting Time* information element is coded as shown in figure 10.5.65/3GPP TS 04.08 and table 10.5.79/3GPP TS 04.08.

The *Starting Time* is a type 3 information element with 3 octets length.

	8	7	6	5	4	3	2	1	
Ĭ				Star	ting 1	ime II	EI		octet 1
Ī		T1	'			(hig	T3 gh part	 ;)	octet 2
+-		T3 w part	)		 ד 				octet 3

#### Figure 10.5.65/3GPP TS 04.08: Starting Time information element

Table 10.5.79/3GPP TS 04.08: Starting Time information element

\_\_\_\_\_ Tl' (octet 2) The T1' field is coded as the binary representation of (FN div 1326) mod 32. (octet 2 and 3) Т3 The T3 field is coded as the binary representation of FN mod 51. Bit 3 of octet 2 is the mos significant bit and bit 6 of octet 3 is the leas Bit 3 of octet 2 is the most and bit 6 of octet 3 is the least significant bit. (octet 3) т2 The T2 field is coded as the binary representation of FN mod 26. NOTE 1: The frame number, FN modulo 42432 can be calculated as 51x((T3-T2) mod 26)+T3+51x26xT1' \_\_\_\_\_

The starting time and the times mentioned above are with reference to the frame numbering in the concerned cell. They are given in units of frames (around 4.615 ms).

The *Starting Time* IE can encode only an interval of time of 42 432 frames, that is to say around 195.8 seconds. To remove any ambiguity, the specification for a reception at time T is that the encoded interval is (T-10808, T+31623). In rigorous terms, if we note ST the starting time:

- if  $0 \le (ST-T) \mod 42432 \le 31623$ , the indicated time is the next time when FN mod 42432 is equal to ST.
- If  $32024 \le (ST-T) \mod 42432 \le 42431$ , the indicated time has already elapsed.

The reception time T is not specified here precisely. To allow room for various MS implementations, the limit between the two behaviours above may be anywhere within the interval defined by

-  $31624 \le (ST-T) \mod 42432 \le 32023.$ 

### 10.5.2.39 Synchronization Indication

The purpose of *Synchronization Indication* information element is to indicate which type of handover is to be performed.

The *Synchronization Indication* information element is coded as shown in figure 10.5.66/3GPP TS 04.08 and table 10.5.80/3GPP TS 04.08.

The Synchronization Indication is a type 1 information element.



Table 10.5.80/3GPP TS 04.08: Synchronization Indication information element

ROT: Report Observed Time Difference (Octet1 bit 3) 0 Mobile Time Difference IE shall not be included in the HANDOVER COMPLETE message Mobile Time Difference IE shall be included in 1 the HANDOVER COMPLETE message SI: Synchronization indication (octet 1) Bit 2 1 0 0 Non-synchronized 0 1 Synchronized 1 0 Pre-synchronised 1 1 Pseudo-synchronised NCI: Normal cell indication (octet 1, bit 4) 0 Out of range timing advance is ignored 1 Out of range timing advance shall trigger a handover failure procedure

### 10.5.2.40 Timing Advance

The purpose of the *Timing Advance* information element is to provide the timing advance value.

The *Timing Advance* information element is coded as shown in figure 10.5.67/3GPP TS 04.08 and table 10.5.81/3GPP TS 04.08

The *Timing Advance* is a type 3 information element with 2 octets length.




Figure 10.5.67/3GPP TS 04.08: Timing Advance information element

Table 10.5.81/3GPP TS 04.08: Timing Advance information element

Timing advance value (octet 2) The coding of the timing advance value field is the binary representation of the timing advance in bit periods; 1 bit period = 48/13 4s.

## 10.5.2.41 Time Difference

The purpose of the *Time Difference* information element is to provide information about the synchronization difference between the time bases of two Base Stations. This type of information element is used in relation with the pseudo-synchronization scheme, see 3GPP TS 05.10.

The *Time Difference* information element is coded as shown in figure 10.5.68/3GPP TS 04.08 and table 10.5.82/3GPP TS 04.08.

The *Time Difference* information element is a type 4 information element with 3 octets length.

	8	7	б	5	4	3	2	1	
Ì			Time D:	ifferend	ce IEI				octet 1
Ì		Lengt	ch of T	ime Difi	ference	conten	ts		octet 2
				Time	differ	ence va	lue	+	octet 3
	Fie	uuro 10 F	60/2CD		Q. Timo I	Difforono	oinforma	tion ol	omont

Figure 10.5.68/3GPP TS 04.08: *Time Difference* information element

Table 10.5.82/3GPP TS 04.08: Time Difference information element


```
Time Difference value (octet 3)
The coding of the time difference value field is the binary
representation of time difference in half bit periods,
modulo 256 half bit periods;
1/2 bit period = 24/13 s.
```

## 10.5.2.41a TLLI

The purpose of the *TLLI* information element is to provide the Temporary Logical Link Identifier.

The TLLI information element is coded as shown in figure 10.5.69/3GPP TS 04.08 and table 10.5.83/3GPP TS 04.08.

The TLLI is a type 3 information element with 5 octets length.






Table 10.5.83/3GPP TS 04.08: TLLI information element

TLLI value (octet 2, 3, 4 and 5) Bit 8 of octet 2 is the most significant bit and bit 1 of octet 5 is the least significant bit. The TLLI is encoded as a binary number with a length of 4 octets. TLLI is defined in 3GPP TS 03.03.

### 10.5.2.42 TMSI/P-TMSI

The purpose of the *TMSI/P-TMSI* information element is to provide the Temporary Mobile Subscriber Identity for paging purposes.

The *TMSI/P-TMSI* information element is coded as shown in figure 10.5.70/3GPP TS 04.08 and table 10.5.84/3GPP TS 04.08.

The *TMSI/P-TMSI* is a type 3 information element with 5 octets length.




Figure 10.5.70/3GPP TS 04.08: TMSI/P-TMSI information element

#### Table 10.5.84/3GPP TS 04.08: TMSI/P-TMSI information element

TMSI/P-TMSI value (octet 2, 3, 4 and 5)

Bit 8 of octet 2 is the most significant bit and bit 1 of octet 5 is the least significant bit.

The coding of the TMSI/P-TMSI is left open for each administration according to 3GPP TS 03.03. The length is 4 octets.

NOTE: For purposes other than paging the TMSI/P-TMSI should be provided using the mobile identity information element.

### 10.5.2.42a VGCS target mode Indication

The VGCS target mode Indication information element is a type 4 information element with 3 octets length.

8	7	б	5	4	3	2	1	
	VG	CS targ	get mod	e Ind	ic. IEI			octet 1
	Lengtl	n of VG	CS tar	get m	ode Ind	ic.		octet 2
Targe	t mode	Group	cipher	key	number		1 spare	octet 3



Table 10.5.85/3GPP TS 04.08: VGCS target mode information element

```
Target mode (octet 3)
Bit
8 7
    dedicated mode
group transmit mode
0 0
0 1
Other values are reserved for future use.
Group cipher key number (octet 3)
Bit
65
   4 3
0 0 0 0
          no ciphering
 cipher key number 1
0000000111111
           cipher key number 2
  0 1
      1
            cipher key number
                                3
 cipher key number 4
           cipher key number
cipher key number
                                5
                                6
           cipher key number
                                7
            cipher key number
                                8
           cipher key number 9
  cipher key number A
cipher key number B
  \begin{array}{ccc} 0 & 1 & 1 \\ 1 & 0 & 0 \end{array}
           cipher key number C
           cipher key number D
cipher key number E
  1
    0 1
1
 1 1 0
1 1 1 1
           cipher key number F
 _____
```

## 10.5.2.43 Wait Indication

The purpose of the *Wait Indication* information element is to provide the time the mobile station shall wait before attempting another channel request.

The *Wait Indication* information element is coded as shown in figure 10.5.72/3GPP TS 04.08 and table 10.5.86/3GPP TS 04.08.

The *Wait Indication* is a type 3 information element with 2 octets length.






Table 10.5.86/3GPP TS 04.08: Wait Indication information element

T3122/T3142 timeout value (octet 2) This field is coded as the binary representation of the T3122/T3142 timeout value in seconds.

NOTE: The timeout value is used for T3122 when received in IMMEDIATE\_ASSIGNMENT REJECT message for RR connection establishment. For GPRS MS the timeout value is used for T3142 when received in IMMEDIATE ASSIGNMENT REJECT message for TBF establishment.

## 10.5.2.44 SI10 rest octets \$(ASCI)\$

The SI 10 rest octets information element contains information for cell re-selection in group receive mode.

The value part is coded as shown below:

<SI10 rest octets> ::= <BA ind : bitstring(1)> { L <implicit spare> | H <neighbour information> }; <neighbour information> ::= <first frequency: bitstring(5)> <cell info> { **H** <info field> }\* **L** <implicit spare>; <cell info> ::=  $\langle \text{bsic} : \text{bitstring}(6) \rangle \{ \mathbf{H} \langle \text{cell parameters} \mid \mathbf{L} \}$ <cell parameters> ::= <cell barred> | L <further cell info> <cell barred> ::= Η <further cell info> ::= <la different> <ms txpwr max cch : bitstring(5)> <rxlev access min : bitstring(6)> <cell reselect offset : bitstring(6)> <temporary offset : bitstring(3)> <penalty time : bitstring(5)> <la different> ::= {  $\mathbf{H} < \text{cell reselect hysteresis : bitstring(3)> | L }$ <info field> ::= <next frequency>\* L <differential cell info>; <next frequency> ::= H; <differential cell info> ::= { H <BCC : bitstring(3)> | L <bsic : bitstring(6)> } {  $\mathbf{H} < \text{diff cell pars} | \mathbf{L}$  } <cell barred> | L <further diff cell info><diff cell pars> ::= <further diff cell info> ::= <la different> {  $\mathbf{H} < ms \text{ txpwr max cch} : bitstring(5) > | \mathbf{L}$  } {  $\mathbf{H} < \operatorname{rxlev} \operatorname{access} \min : \operatorname{bitstring}(6) > | \mathbf{L}$  } { **H** <cell reselect offset : bitstring(6)> | **L** } { **H** <temporary offset : bitstring(3)> | **L** } {  $\mathbf{H} < \text{penalty time : bitstring(5)> | } \mathbf{L}$  }

#### Static and dynamic conditions:

- Information from the last received neighbour cells description in SYSTEM INFORMATION TYPE 5/5bis/5ter is necessary for the mobile station to interpret <neighbour information>. If <BA ind> is different from the last received BA IND value indicated in SYSTEM INFORMATION TYPE 5/5bis/5ter, <neighbour information> cannot be interpreted by the mobile station.
- 2) If the correspondence between neighbour cell frequencies and sets of pairs (BSIC, cell information) cannot be established following the rules below, or if more than one set of such pairs corresponds to one neighbour cell frequency, the mobile station shall diagnose an imperative message part error.

#### Attributes, field contents:

- <cell info> defines a BSIC given by <bsic : bitstring(6)>. It also defines cell information. If <cell parameters> is contained in <cell info>, this cell information is the cell information given by <cell parameters>; if <cell parameters> is not contained in <cell info>, this cell i
- 2) <differential cell info> defines a BSIC given by <bsic : bitstring(6)> or by <BCC : bitstring(3)>, see below. It also defines cell information. If <diff cell pars> is contained in <differential cell info>, this cell information is the cell information given by <diff cell pars>; if <diff cell pars> is not contained in <differential cell info>, this cell info>.
- 3) <cell parameters> either indicates a barred cell (by presence of <cell barred>)or specifies cell information given by <further cell info>.

- 4) Each occurrence of <diff cell pars> either indicates a barred cell (by presence of <cell barred>)or specifies cell information given by <further diff cell info>.
- 5) <further cell info> specifies cell information given by its components:
  - <la different>
  - <ms txpwr max cch : bitstring(5)>
  - <rxlev access min : bitstring(6)>
  - <cell reselect offset : bitstring(6)>
  - <temporary offset : bitstring(3)>
  - <penalty time : bitstring(5)>

as defined below.

6) For each occurrence of <further diff cell info>, a cell information is defined. This information is given by <la different> and remaining cell information established as follows:

The remaining cell information defined for the first occurrence of <further diff cell info> consists of the cell information given by its actual components plus the cell information specified by <further cell info> corresponding to its missing components.

The remaining cell information defined for a later occurrence of <further diff cell info> consists of the cell information given by its actual components plus the remaining cell information corresponding to its missing components which is defined for the previous occurrence of <further diff cell info>.

Here, the

"actual components" of an occurrence of <further diff cell info> denotes those parameters among

- <ms txpwr max cch : bitstring(5)>
- <rxlev access min : bitstring(6)>
- <cell reselect offset : bitstring(6)>
- <temporary offset : bitstring(3)>
- <penalty time : bitstring(5)>

which are present in that occurrence.

"missing components" of an occurrence of <differential cell info> denote those parameters among

- <ms txpwr max cch : bitstring(5)>
- <rxlev access min : bitstring(6)>
- <cell reselect offset : bitstring(6)>
- <temporary offset : bitstring(3)>
- <penalty time : bitstring(5)>

which are not present in that occurrence.

- 7) Each occurrence of <bsic : bitstring(6)> specifies a BSIC by encoding its binary representation.
  <BCC : bitstring(3)> specifies a BCC by encoding its binary representation; it specifies the BSIC given by that BCC and the NCC of the BSIC specified by the previous occurrence of <BCC : bitstring(3)> or
  <bsic : bitstring(6)>. All occurrences of <bsic: bitstring(6)> and <BCC : bitstring(3)> establish a list of BSIC.
- 8) <first frequency : bitstring(5)> is the 5 bit binary coding of an integer n with 0 <= n <= 31. It specifies a first frequency number n+1.

9) <SI10 rest octets> defines a correspondence between neighbour cell frequencies and sets of pairs (BSIC, cell information) defining the parameters for cell re-selection of any corresponding neighbour cell with BCCH on that frequency and having that BSIC:

Let a(1),..., a(n) be the list of neighbour cell frequencies, in the order determined by the mobile station. Let i be the first frequency number specified by <first frequency : bitstring(5)> (see above).

The first BSIC and the cell information specified by <cell info> build a pair belonging to the set corresponding to a(i).

If an m-th occurrence of  $\langle info \text{ field} \rangle$  is present (where m  $\geq 2$ ), having established the correspondence of the (m-1)-th BSIC to a neighbour frequency a(k), the m-th BSIC and following  $\langle differential \text{ cell info} \rangle$ 

- belong to a(k), if <next frequency> is not present in the m-th occurrence of <info field>,
- belong to a((smod(k+t)), if <next frequency> is present exactly t times in the m-th occurrence of <info field>.

Here, for an integer j,  $smod(j) := ((j-1) \mod n) + 1$ .

10)If <la different> contains a <cell reselect hysteresis : bitstring(3)>, this means that the cell is to be considered by the mobile station to belong to a different location area and that for the cell, the cell reselect hysteresis specified in <cell reselect hysteresis : bitstring(3)> applies.

If <la different> doesn't contain a <cell reselect hysteresis : bitstring(3)>, this means that the cell is to be considered by the mobile station to belong to the same location area.

11)<same LA indicator : bitstring(1)> defines whether the location area is the same as the location area of the serving cell

12)For <cell reselect hysteresis : bitstring(3)>: see sub-clause 10.5.2.4.

13)For <ms txpwr max cch : bitstring(5)>: see sub-clause 10.5.2.4.

14)For <rxlev access min : bitstring(6)> see sub-clause 10.5.2.4.

15)For <cell reselect offset : bitstring(6)>: see sub-clause 10.5.2.35.

16)For <temporary offset : bitstring(3)>: see sub-clause 10.5.2.35.

17)For <penalty time : bitstring(5)>: see sub-clause 10.5.2.35.

## 10.5.2.45 EXTENDED MEASUREMENT RESULTS

The purpose of the *Extended Measurement Results* information element is to provide the results of the measurements made by the mobile station on the carriers specified in the EXTENDED MEASUREMENT ORDER.

The *Extended Measurement Results* information element is coded as shown in figure 10.5.73/3GPP TS 04.08 and table 10.5.87/3GPP TS 04.08.

The Extended Measurement Results is a type 3 information element with 17 octets length.




Figure 10.5.73/3GPP TS 04.08: Extended Measurement Results information element

#### Table 10.5.87/3GPP TS 04.08: Extended Measurement Results information element

SC USED (octet 2), indicates the value of the SEQ-CODE in the extended measurement frequency list information element used for defining the list of frequencies reported on.

Range: 0 to 1.

DTX USED (octet 2) This bit indicates whether or not the mobile station used DTX during the previous measurement period.

Bit 7

- 0 DTX was not used
- 1 DTX was used

RXLEV carrier 'N' (octets 2 to 17). This field is coded as the binary representation of a value M. M corresponds according to the mapping defined in TS. 3GPP TS 05.08 to the received signal strength on carrier N. N is the index to the frequency in the sorted list of frequencies defined in the EXTENDED MEASUREMENT ORDER message. The list is sorted in increasing order of ARFCN, except that ARFCN 0, if included in the EXTENDED MEASUREMENT ORDER, is put in the last position of the sorted list. If the EXTENDED MEASUREMENT ORDER contains more than 21 carriers, only the signal strength of the carriers 0-20 shall be measured and reported.

Range: 0 to 63

If the EXTENDED MEASUREMENT ORDER message contains less than 21 carriers, the fields in the EXTENDED MEASUREMENT REPORT not referring to any specified carrier shall have RXLEV values set to zero.

## 10.5.2.46 Extended Measurement Frequency List

The purpose of *Extended Measurement Frequency List* information element is to provide the absolute radio frequency channel numbers of carriers to measure signal strength on.

The *Extended Measurement Frequency List* information element is coded as the *Cell Channel Description* information element, as specified in sub-clause 10.5.2.1b, with the exception of bit 5 of octet 2. figure 10.5.74/3GPP TS 04.08 and table 10.5.88/3GPP TS 04.08 contains the difference of specifications.

The Extended Measurement Frequency List information element is a type 3 information element with 17 octets length.

8	7	6	5	4	3	2	1	
+	 Ex +	tended	d Measur	ement	Frequen	cy Lis	t IEI 	octet 1
Bit 128			· · · · z			Bit 122	Bit 121	octet 2
Bit 120					Bit 115	Bit 114	Bit 113	octet 3
+	+	+	+	-+	-+	+	+	
Bit 008					Bit 003	Bit 002	Bit 001	octet 17

Figure 10.5.74/3GPP TS 04.08: Extended Measurement Frequency List information element

Table 10.5.88/3GPP TS 04.08: Extended Measurement Frequency List information element

```
SEQ-CODE, Sequence code (octet 2, bit 5).
Range 0 to 1.
```

### 10.5.2.47 Suspension Cause

The purpose of the *Suspension Cause* information element is to provide the reason for the establishment of the dedicated circuit which generated the GPRS suspension.

The *Suspension Cause* information element is coded as shown in figure 10.5.2.47/3GPP TS 04.08 and table 10.5.2.47/3GPP TS 04.08.

The Suspension Cause is a type 3 information element with 2 octets length.






Table 10.5.2.47/3GPP TS 04.08: Suspension Cause information element

Suspension cause value (octet 2) Bits 87654321 Emergency call, mobile originating call or call re-establishment 0 0 0 0 0 0 0 0 Location Area Update 0 0 0 0 0 0 0 1 0 0 0 0 0 0 1 0 MO Short message service (note 1) 0 0 0 0 0 0 1 1 Other procedure which can be completed with an SDCCH 0 0 0 0 0 1 0 0 MO Voice broadcast or group call (note 2) 0 0 0 0 0 1 0 1 Answer to paging Note 1: As an option, cause value 0000 0011 may be used for an MO Short message service Note 2: As an option, cause value 0000 0000 may be used for an MO Voice broadcast or group call All other cause values shall be treated as 0000 0000 \_\_\_\_\_

## 10.5.2.48 APDU ID

The APDU ID information element identifies the particular protocol and associated application for an APDU.

The *APDU ID* information element is coded as shown in figure 10.5.2.48/3GPP TS 04.08 and table 10.5.2.48/3GPP TS 04.08.

The APDU ID is a type 1 information element.




Figure 10.5.2.48/3GPP TS 04.08: APDU ID information element

#### Table 10.5.2.48/3GPP TS 04.08: APDU ID information element format

Protocol Bits 4 3 2 1	identifier (octet 1) Protocol / Application
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	RRLP (3GPP TS 04.31)/ LCS
to 1 1 1 1	reserved for future use

### 10.5.2.49 APDU Flags

The APDU Flags information element provides segmentation and control information for an associated APDU.

The *APDU Flags* information element is coded as shown in figure 10.5.2.49/3GPP TS 04.08 and table 10.5.2.49/3GPP TS 04.08.

The APDU Flags is a type 1 information element.

8	7	6	5	4	3	2	1	
	APDU	Flags	IEI	0 spare	C/R	first    seg.	last seg.	octet 1

#### Figure 10.5.2.49/3GPP TS 04.08: APDU Flags information element

Table 10.5.2.49/3GPP TS 04.08: APDU Flags information element format

```
Last Segment (octet 1)

bit 1

0 Last or only segment

1 Not last or only segment

First Segment (octet 1)

bit 2

0 First or only segment

1 Not first or only segment

C/R (octet 1)

If last seg. = 0, then:

bit 3

0 Command or Final Response

1 Not Command or Final Response

If last seg. = 1, then bit 3 is spare and set to 0
```

## 10.5.2.50 APDU Data

The purpose of the information element is to provide an APDU or APDU segment.

The *APDU Data* information element is coded as shown in figure 10.5.2.50/3GPP TS 04.08 and table 10.5.2.50/3GPP TS 04.08.

The APDU Data is a type 4 information element with minimum length of 2 octets. No upper length limit is specified except for that given by the maximum number of octets in a L3 message (3GPP TS 04.06).






Table 10.5.2.50/3GPP TS 04.08: APDU Data information element format


## 10.5.3 Mobility management information elements

### 10.5.3.1 Authentication parameter RAND

The purpose of the *Authentication Parameter RAND* information element is to provide the mobile station with a nonpredictable number to be used to calculate the authentication response signature SRES and the ciphering key Kc.

The *Authentication Parameter RAND* information element is coded as shown in figure 10.5.75/3GPP TS 04.08 and table 10.5.89/3GPP TS 04.08.

The Authentication Parameter RAND is a type 3 information element with 17 octets length.



#### Figure 10.5.75/3GPP TS 04.08: Authentication Parameter RAND information element

Table 10.5.89/3GPP TS 04.08: Authentication Parameter RAND information element

RAND value (octet 2, 3,... and 17) The RAND value consists of 128 bits. Bit 8 of octet 2 is the most significant bit while bit 1 of octet 17 is the least significant bit.

## 10.5.3.2 Authentication parameter SRES

The purpose of the *authentication parameter SRES* information element is to provide the network with the authentication response signature calculated in the mobile station.

The *Authentication Parameter SRES* information element is coded as shown in figure 10.5.76/3GPP TS 04.08 and table 10.5.90/3GPP TS 04.08.

The Authentication Parameter SRES is a type 3 information element with 5 octets length.

8 7 б 5 4 3 2 1 Authentication parameter SRES IEI octet 1 \_\_\_\_\_ SRES value octet 2 : : octet 5 \_\_\_\_\_

Figure 10.5.76/3GPP TS 04.08: Authentication Parameter SRES information element

Table 10.5.90/3GPP TS 04.08: Authentication Parameter SRES information element

## 10.5.3.3 CM service type

The purpose of the CM Service Type information element is to specify which service is requested from the network.

The *CM Service Type* information element is coded as shown in figure 10.5.77/3GPP TS 04.08 and table 10.5.91/3GPP TS 04.08.

The CM Service Type is a type 1 information element.




Figure 10.5.77/3GPP TS 04.08: CM Service Type information element

Table 10.5.91/3GPP TS 04.08: CM Service Type information element

Service type (octet 1) Bits
4 3 2 1 0 0 0 1 Mobile originating call establishment
or packet mode connection establishment 0 0 1 0 Emergency call establishment 0 1 0 0 Short message service 1 0 0 0 Supplementary service activation 1 0 0 1 Voice group call establishment
1 0 1 0 Voice broadcast call establishment 1 0 1 1 Location Services
All other values are reserved.

### 10.5.3.4 Identity type

The purpose of the *Identity Type* information element is to specify which identity is requested.

The *Identity Type* information element is coded as shown in figure 10.5.78/3GPP TS 04.08 and table 10.5.92/3GPP TS 04.08.

The *Identity Type* is a type 1 information element .

8 7 6 5 4 3 2 1 | Identity type IEI 0 type of identity octet 1



#### Table 10.5.92/3GPP TS 04.08: Identity Type information element


	Type of Bits 3 2 1	identity	(octet	1)
	$\begin{array}{cccccccccccccccccccccccccccccccccccc$	IMSI IMEI IMEISV TMSI		
+	All oth	er values	are rea	served.

## 10.5.3.5 Location updating type

The purpose of the *Location Updating Type* information element is to indicate whether a normal updating, a periodic updating or an IMSI attach is wanted. It may also indicate that a follow-on request has been received from the mobile station CM layer.

The *Location Updating Type* information element is coded as shown in figure 10.5.79/3GPP TS 04.08 and table 10.5.93/3GPP TS 04.08.

The Location Updating Type is a type 1 information element.



### Figure 10.5.79/3GPP TS 04.08: Location Updating Type information element

Table 10.5.93/3GPP TS 04.08: Location Updating Type information element

```
_____
LUT (octet 1)
Bits
2 1
0 0
       Normal location updating
       Periodic updating
0 1
1 0
        IMSI attach
1 1
        Reserved
FOR (octet 1)
The Follow-On Request bit (FOR) is coded as
follows:
Bit
4
0
        No follow-on request pending
1
        Follow-on request pending
                                    ----+
```

## 10.5.3.5a Network Name

The purpose of this information element is to pass a text string to the mobile station.

The *Network Name* information element is coded as shown in figure 10.5.80/3GPP TS 04.08 and table 10.5.94/3GPP TS 04.08.

The *Network Name* is a type 4 information element with a minimum length of 3 octets. No upper length limit is specified except for that given by the maximum number of octets in a L3 message (see 3GPP TS 04.06).

	8	7	6	5	4	3	2	1		
1	Network Name IEI									1
			octet	2						
	ext 1	co	ding so	cheme	Add CI	Number bits in	of sj last	pare octet	octet	3
	Text String								octet	4
4								+	octet	n

Figure 10.5.80/3GPP TS 04.08: Network Name information element

#### Table 10.5.94/3GPP TS 04.08: Network Name information element


Number of spare bits in last octet (octet 3, bits 1 to 3) 001 bit 8 is spare and set to "0" in octet n 0 1 0 bits 7 and 8 are spare and set to "0" in octet n 0 1 1 bits 6 to 8(inclusive) are spare and set to "0" in octet n 1 0 0 bits 5 to 8(inclusive) are spare and set to "0" in octet n 1 0 1 bits 4 to 8(inclusive) are spare and set to "0" in octet n 1 1 0 bits 3 to 8(inclusive) are spare and set to "0" in octet n 1 1 1 bits 2 to 8(inclusive) are spare and set to "0" in octet n 0 0 0 this field carries no information about the number of spare bits in octet n Add CI (octet 3, bit 4) 0 The MS should not add the letters for the Country's Initials to the text string The MS should add the letters for the Country's Initials and a separator 1 (e.g. a space) to the text string Coding Scheme (octet 3, bits 5-7) 0 0 0 Cell Broadcast data coding scheme defined in 3GPP TS 03.38 0 0 1 UCS2 (16 bit) [72] 010 to reserved 111 Text String (octet 4 to octet n, inclusive) Encoded according to the Coding Scheme defined by octet 3, bits 5-7

## 10.5.3.6 Reject cause

The purpose of the *Reject Cause* information element is to indicate the reason why a request from the mobile station is rejected by the network.

The *Reject Cause* information element is coded as shown in figure 10.5.81/3GPP TS 04.08 and table 10.5.95/3GPP TS 04.08.

The *Reject Cause* is a type 3 information element with 2 octets length.



#### Figure 10.5.81/3GPP TS 04.08: Reject Cause information element

Reject cause value (octet 2) Bits 8 7 654321 0 0 0 0 0 1 0 0 IMSI unknown in HLR 0 0 0 0 0 0 1 1 Illegal MS IMSI unknown in VLR IMEI not accepted 0 0 0 0 0 1 0 0 0 0 0 0 0 1 0 1 0 0 Illegal ME PLMN not allowed 0 0 0 0 1 1 0 0 Location Area not allowed 0 0 0 1 1 0 1 Roaming not allowed in this location area 0 0 0 1 0 0 0 1 0 Network failure 1 1 0 0 0 0 1 0 Congestion Service option not supported 0 0 1 0 0 0 0 0 0 0 1 0 0 0 0 1 Requested service option not subscribed 0 0 1 0 0 0 1 0Service option temporarily out of order 0 0 1 0 0 1 1 0 Call cannot be identified } } 0 0 1 1 0 0 0 0 retry upon entry into a new cell to 0 0 1 1 1 1 1 1 1 1 Semantically incorrect message 0 1 0 1 1 1 0 1 1 0 0 0 0 0 Invalid mandatory information 0 1 1 0 0 0 0 1 Message type non-existent or not implemented 0 1 1 0 0 0 1 0 Message type not compatible with the protocol state 0 1 1 0 0 0 1 1 Information element non-existent or not implemented 0 1 1 0 0 1 0 0 Conditional IE error 0 1 1 0 0 1 0 1 Message not compatible with the protocol state 0 1 1 0 1 1 1 1 Protocol error, unspecified Any other value received by the mobile station shall be treated as 0010 0010, 'Service option temporarily out of order'. Any other value received by the network shall be treated as 0110 1111, 'Protocol error, unspecified'. NOTE: The listed reject cause values are defined in Annex G. \_\_\_\_\_

Table 10.5.95/3GPP TS 04.08: Reject Cause information element


\_\_\_\_\_

### 10.5.3.7 Follow-on Proceed

The purpose of the *Follow-on Proceed* information element is to indicate that an MM connection may be established on an existing RR connection.

The Follow-on Proceed information element is coded as shown in figure 10.5.82/3GPP TS 04.08.

The Follow-on Proceed is a type 2 information element.




#### Figure 10.5.82/3GPP TS 04.08: Follow-on Proceed information element

### 10.5.3.8 Time Zone

The purpose of this information element is to encode the offset between universal time and local time in steps of 15 minutes.

The *Time Zone* information element is coded as shown in figure 10.5.83/3GPP TS 04.08 and table 10.5.96/3GPP TS 04.08.

The *Time Zone* is a type 3 information element with a length of 2 octets.



#### Figure 10.5.83/3GPP TS 04.08: Time Zone information element

Table 10.5.96/3GPP TS 04.08: Time Zone information element

Time Zone (octet 2, bits 1-8) This field uses the same format as the Timezone field used in the TP-Service-Centre-Time-Stamp, which is defined in GSM 03.40, and its value shall be set as defined in 3GPP TS 02.42

## 10.5.3.9 Time Zone and Time

The purpose of the timezone part of this information element is to encode the offset between universal time and local time in steps of 15 minutes.

The purpose of the time part of this information element is to encode the universal time at which this information element may have been sent by the network.

The *Time Zone and Time* information element is coded as shown in figure 10.5.84/3GPP TS 04.08 and table 10.5.97/3GPP TS 04.08.

The *Time Zone and Time* is a type 3 information element with a length of 8 octets.




Figure 10.5.84/3GPP TS 04.08: Time Zone and Time information element

#### Table 10.5.97/3GPP TS 04.08: Timezone and Time information element


Year (octet 2, bits 1-8) This field uses the same format as the Year field used in the TP-Service-Centre-Time-Stamp, which is defined in 3GPP TS 03.40, and its value shall be set as defined in 3GPP TS 02.42. Month (octet 3, bits 1-8) This field uses the same format as the Month field used in the TP-Service-Centre-Time-Stamp, which is defined in 3GPP TS 03.40, and its value shall be set as defined in 3GPP TS 02.42. Day (octet 4, bits 1-8) This field uses the same format as the Day field used in the TP-Service-Centre-Time-Stamp, which is defined in 3GPP TS 03.40, and its value shall be set as defined in 3GPP TS 02.42. Hour (octet 5, bits 1-8) This field uses the same format as the Hour field used in the TP-Service-Centre-Time-Stamp, which is defined in 3GPP TS 03.40, and its value shall be set as defined in 3GPP TS 02.42. Minute (octet 6, bits 1-8) This field uses the same format as the Minute field used in the TP-Service-Centre-Time-Stamp, which is defined in 3GPP TS 03.40, and its value shall be set as defined in 3GPP TS 02.42. Second (octet 7, bits 1-8) This field uses the same format as the Second field used in the TP-Service-Centre-Time-Stamp, which is defined in 3GPP TS 03.40, and its value shall be set as defined in 3GPP TS 02.42. Time Zone (octet 8, bits 1-8) This field uses the same format as the Time Zone field used in the TP-Service-Centre-Time-Stamp, which is defined in 3GPP TS 03.40, and its value shall be set as defined in 3GPP TS 02.42.

NOTE: Due to ambiguities in earlier versions of the protocol specifications, some mobile stations may interpret the received NITZ time as local time. This may result in incorrect time settings in the mobile.

## 10.5.3.10 CTS permission

The purpose of the *CTS permission* information element is to indicate that the mobile station is allowed to use GSM-Cordless Telephony System in the Location Area. The *CTS permission* information element is coded as shown in figure 10.5.84a/3GPP TS 04.08.

The CTS permission is a type 2 information element.




### Figure 10.5.84a/3GPP TS 04.08: CTS permission information element

### 10.5.3.11 LSA Identifier

This element uniquely identifies a LSA.

The LSA Identifier information element is coded as shown in figure 10.68c/3GPP TS 04.08.

The LSA Identifier is a type 4 information element with a length of 2 or 5 octets.



#### Figure 10.68c/3GPP TS 04.08: LSA Identifier information element

If the Length = 0, then no LSA ID is included. This is used to indicate that the MS has moved to an area where there is no LSA available for that MS.

Octets 3-5 are coded as specified in 3GPP TS 03.03, 'Identification of Localised Service Area'. Bit 8 of octet 3 is the most significant bit.

# 10.5.4 Call control information elements

## 10.5.4.1 Extensions of codesets

There is a certain number of possible information element identifier values using the formatting rules described in subclause 10.5: 128 from the type 3 & 4 information element format and at least 8 from the type 1 & 2 information element format.

One value in the type 1 format is specified for shift operations described below. One other value in both the type 3 & 4 and type 1 format is reserved. This leaves 133 information element identifier values available for assignment.

It is possible to expand this structure to eight codesets of 133 information element identifier values each. One common value in the type 1 format is employed in each codeset to facilitate shifting from one codeset to another. The contents of this shift information element identifies the codeset to be used for the next information element or elements. The codeset in use at any given time is referred to as the "active codeset". By convention, codeset 0 is the initially active codeset.

Two codeset shifting procedures are supported: locking shift and non-locking shift.

Codeset 5 is reserved for information elements reserved for national use.

Codeset 6 is reserved for information elements specific to the local network (either public or private).

Codeset 7 is reserved for user-specific information elements.

The coding rules specified in sub-clause 10.5 shall apply for information elements belonging to any active codeset.

Transitions from one active codeset to another (i.e. by means of the locking shift procedure) may only be made to a codeset with a higher numerical value than the codeset being left.

An information element belonging to codeset 5, 6 or 7 may appear together with information elements belonging to codeset 0, by using the non-locking shift procedure (see sub-clause 10.5.4.3).

A user or network equipment shall have the capability to recognize a shift information element and to determine the length of the following information element, although the equipment need not be able to interpret and act on the content of the information element. This enables the equipment to determine the start of the subsequent information element.

## 10.5.4.2 Locking shift procedure

The locking shift procedure employs an information element to indicate the new active codeset. The specified codeset remains active until another locking shift information element is encountered which specifies the use of another codeset. For example, codeset 0 is active at the start of message content analysis. If a locking shift to codeset 5 is encountered, the next information elements will be interpreted according to the information element identifiers assigned in codeset 5, until another shift information element is encountered. This procedure is used only to shift to a higher order codeset than the one being left.

The locking shift is valid only within that message which contains the locking shift information element. At the start of every message content analysis, the active codeset is codeset 0.

The locking shift information element uses the type 1 information element format and coding shown in figure 10.5.85/3GPP TS 04.08 and table 10.5.98/3GPP TS 04.08.

"0" in this position indicates locking shift

#### Figure 10.5.85/3GPP TS 04.08: Locking shift element

#### Table 10.5.98/3GPP TS 04.08: Locking shift element

Codeset identification (octet 1): bits 3 2 1 0 0 0 not applicable 0 0 1 to 1 0 0 reserved codeset 5: information elements 1 0 1 for national use codeset 6: information elements specific 1 1 0 to the local network (either public or private) codeset 7: user-specific information 1 1 1 elements \_\_\_\_\_


## 10.5.4.3 Non-locking shift procedure

The non-locking shift procedure provides a temporary shift to the specified lower or higher codeset. The non-locking shift procedure uses a type 1 information element to indicate the codeset to be used to interpret the next information element. After the interpretation of the next information element, the active codeset is again used for interpreting any following information elements. For example, codeset 0 is active at the beginning of message content analysis. If a non-locking shift to codeset 6 is encountered, only the next information element is interpreted according to the information element identifiers assigned in codeset 6. After this information element is interpreted, codeset 0 will again be used to interpret the following information elements. A non-locking shift information element indicating the current codeset shall not be regarded as an error.

A locking shift information element shall not follow directly a non-locking shift information element. If this combination is received, it shall be interpreted as though a locking shift information element had been received.

The non-locking shift information element uses the type 1 information format and coding shown in figure 10.5.86/3GPP TS 04.08 and table 10.5.99/3GPP TS 04.08.

8 7 6 5 4 3 2 1 Shift identifier | 1 | Temporary codeset | octet 1 identification | 1" in this position indicates non-locking shift



	 dese ts 3			fication (octet 1):
21		Ō		codeset 0 (initially active): GSMB04.08 information elements
		0		
to	1			reserved
	1	0	1	codeset 5: information elements for national use
	1	1	0	codeset 6: information elements specific to the local network (either public or private)
	1	1	1	codeset 7: user-specific information elements.

Table 10.5.99/3GPP TS 04.08: Non-locking shift element

## 10.5.4.4 Auxiliary states

The purpose of the auxiliary states information element is to describe the current status of the auxiliary states of a call in the call control states "active" and "mobile originating modify". (See TSs 3GPP TS 04.83 and 04.84)

The auxiliary states information element is coded as shown in figure 10.5.87/3GPP TS 04.08, table 10.5.100/3GPP TS 04.08 and table 10.5.101/3GPP TS 04.08.

The auxiliary states is a type 4 information element with 3 octets length.

	8	7	6	5	4	3	2	1		
+			Αι	uxilia	ry stat	es IE	 I		octet	1
		Lengt	h of a	auxilia	ary sta	tes c	ontents	3	octet	2
	1 ext	0	0 spare	0	hold stat		MPTY sta	aux. ate	octet	3

### Figure 10.5.87/3GPP TS 04.08: Auxiliary states information element

Table 10.5.100/3GPP TS 04.08: Auxiliary states information element

Hold auxiliary state (octet 3) Bits 4 3 0 0 idle Note 1 0 1 hold request Note 1 1 0 call held Note 1 1 1 retrieve request Note 1 Note 1: These states are defined in Rec GSMB04.83.

#### Table 10.5.101/3GPP TS 04.08: Auxiliary states information element

+ Multi party auxiliary Bits 2 1	state (octet 3)
0 0 idle 0 1 MPTY request 1 0 call in MPTY 1 1 split request	Note 2 Note 2 Note 2 Note 2
NOTE 2: These states a	re defined in Rec GSMB04.84.

## 10.5.4.5 Bearer capability

The purpose of the bearer capability information element is to describe a bearer service. The use of the bearer capability information element in relation to compatibility checking is described in annex B.

The bearer capability information element is coded as shown in figure 10.5.88/3GPP TS 04.08 and tables 10.5.102/3GPP TS 04.08 to 10.5.115/3GPP TS 04.08.

The bearer capability is a type 4 information element with a minimum length of 3 octets and a maximum length of 15 octets.

8	7	6	5	4	3	2	1	L	
 +		Bea	arer ca	apabil:	ity IEI	C 		octet	1
L.	ength o	of the	beare	r capal	oility	conte	nts	octet	2
0/1 ext	char	dio nnel cement	co- ding std	trans fer mode	tra	ormation ansfer ability	-	octet	3
0/1 ext	0 co- ding	СТМ	0 spare	spee	ech ver ndicati	rsion lon		octet 3	3a*
0/1 ext	0 co- ding	0 spa	0 are		ech ver ndicati			octet 3	3b etc*
1 ext	comp- ress.	stru	cture	dupl. mode	confi gur.	NIRR	esta- bli.	octet	4*
0/1 ext	0 access	0 s id.	rat adapt			gnalli ss pro		octet	5*
0/1 ext	Othei	C ITC	Other adapt	r rate tion	0	0 Spare	0	octet	5a*
1 ext		Multi frame	Mode		Assig nor/e		0 Spare	octet	5b*
0/1 ext	0 layer	1 1 id.			protoco		sync/ async	octet	б*
0/1 ext	numb. stop bits	nego- tia- tion	numb. data bits		user 1	rate		octet	ба*
0/1 ext	inter rat	cmed.	NIC on TX	NIC on RX	Pa	arity		octet	6b*
0/1 ext	conneo eler	ction ment		modem	type			octet	бс*
0/1 ext	Oth modem		Fixe	ed netv	work us	ser ra	te	octet	6d*
0/1 ext	+	Accept chani codii	nel			um numl Lc chai	ber of nnels	octet	бе*
0/1 ext	+	UIMI			ed air rate	inter	face	octet	6f*
1   ext +	1 layer	0 2 id.	U:   1a	ser in ayer 2	formati protoc	lon col		octet	7*

### Figure 10.5.88/3GPP TS 04.08: Bearer capability information element

NOTE: The coding of the octets of the bearer capability information element is not conforming to TS ITU-T Recommendation Q.931.

# Table 10.5.102/3GPP TS 04.08: Bearer capability information element

Ra	
1	dio channel requirement (octet 3), network to MS direction
	s 6 and 7 are spare bits. The sending side (i.e. the network) shall set bit 7 to value 0 and bit 6 t ue 1.
Ra	dio channel requirement (octet 3) MS to network direction
Bits 76 00 101	
ind Bits <b>7 6</b> 0 0	
	<ul><li>1 1 dual rate support MS/full rate speech version 1 preferred, half rate speech version 1 also supported</li></ul>
ind Bits	
<b>76</b>	
00	
	reserved
	reserved 0 1 the mobile station supports at least full rate speech version 1 but does not support half rate
	<ul> <li>reserved</li> <li>0 1 the mobile station supports at least full rate speech version 1 but does not support half rate speech version 1. The complete voice codec preference is specified in octet(s) 3a etc.</li> <li>1 0 The mobile station supports at least full rate speech version 1 and half rate speech version 1. The mobile station has a greater preference for half rate speech version 1 than for full rate speech version 1. The complete voice codec preference is specified in octet(s) 3a etc.</li> <li>1 1 The mobile station supports at least full rate speech version 1 and half rate speech version 1. The complete voice codec preference is specified in octet(s) 3a etc.</li> <li>1 1 The mobile station supports at least full rate speech version 1 and half rate speech version 1. The mobile station has a greater preference for full rate speech version 1 and half rate speech version 1. The mobile station has a greater preference for full rate speech version 1 than for half</li> </ul>
Co Bit <b>5</b>	<ul> <li>reserved</li> <li>0 1 the mobile station supports at least full rate speech version 1 but does not support half rate speech version 1. The complete voice codec preference is specified in octet(s) 3a etc.</li> <li>1 0 The mobile station supports at least full rate speech version 1 and half rate speech version 1. The mobile station has a greater preference for half rate speech version 1 than for full rate speech version 1. The complete voice codec preference is specified in octet(s) 3a etc.</li> <li>1 1 The mobile station supports at least full rate speech version 1 and half rate speech version 1. The complete voice codec preference is specified in octet(s) 3a etc.</li> <li>1 1 The mobile station supports at least full rate speech version 1 and half rate speech version</li> </ul>

Transfer mode (octet 3)
Bit
4
0 circuit mode
1 packet mode
Information transfer capability (octet 3)
Bits
321
0 0 0 speech
0 0 1 unrestricted digital information
0 1 0 3.1 kHz audio, ex PLMN
0 1 1 facsimile group 3
1 0 1 Other ITC (See Octet 5a)
1 1 1 reserved, to be used in the network.
The meaning is: alternate speech/facsimile group 3 - starting with speech.
All other values are reserved

# Table 10.5.103/3GPP TS 04.08: Bearer capability information element

Octet(s) 3a etc. MS to network direction
Coding Bit 7
<ul> <li>0 octet used for extension of information transfer capability</li> <li>1 octet used for other extension of octet 3</li> </ul>
When information transfer capability (octet 3) indicates speech and coding (bit 7 in octet 3a etc.) is coded as 0, bits 1 through 6 are coded:
CTM text telephony indication (octet 3a) Bit <b>6</b>
0 CTM text telephony is not supported 1 CTM text telephony is supported
In this version of the protocol, bit 6 in octet 3a shall be ignored by the network.
Bit 6 in octet(s) 3b etc. is spare.
Bit 5 in octet(s) 3a etc. is spare.
Speech version indication (octet(s) 3a etc.) Bits <b>4 3 2 1</b> 0 0 0 0GSM full rate speech version 1 0 0 1 0GSM full rate speech version 2 0 1 0 0GSM full rate speech version 3 0 0 0 1 GSM half rate speech version 1 0 1 0 1GSM half rate speech version 3
All other values have the meaning "speech version tbd" and shall be ignored when received.
If octet 3 is extended with speech version indication(s) (octets 3a etc.), all speech versions supported shall be indicated and be included in order of preference (the first octet (3a) has the highest preference and so on).
If information transfer capability (octet 3) indicates speech and coding (bit 7 in octet 3a etc.) is coded as 1, or the information transfer capability does not indicate speech, then the extension octet shall be ignored.
Octet(s) 3a etc. network to MS direction
The octet(s) 3a etc. shall be ignored by the MS.

· · · · · · · · · · · · · · · · · · ·
Compression (octet 4), network to MS direction: Bit 7
<ul> <li>data compression not possible</li> <li>data compression possible</li> </ul>
Compression (octet 4), MS to network direction: Bit 7
<ul><li>0 data compression not allowed</li><li>1 data compression allowed</li></ul>
Structure (octet 4)
Bits 6 5
0 0 service data unit integrity 1 1 unstructured
All other values are reserved.
Duplex mode (octet 4) Bit <b>4</b>
0 half duplex 1 full duplex
Configuration (octet 4) Bit <b>3</b>
0 point-to-point
All other values are reserved.
NIRR (octet 4) (Negotiation of Intermediate Rate Requested) Bit <b>2</b>
<ul> <li>No meaning is associated with this value.</li> <li>Data up to and including 4.8 kb/s, full rate, non-transparent, 6 kb/s radio interface rate is requested.</li> </ul>
Establishment (octet 4) Bit 1
0 demand
All other values are reserved

Table 10.5.104/3GPP TS 04.08: Bearer capability information element

Access identity (octet 5)
Bits
7 6
0 0 octet identifier
All other values are reserved
Rate adaption (octet 5)
Bits
5 4
0 0 no rate adaption
0 1 V.110/X.30 rate adaptation 1 0 ITU-T X.31 flag stuffing
1 1 Other rate adaption (see octet 5a)
T Tother rate adaption (see octer sa)
Signalling access protocol (octet 5)
Bits
321
0 0 1 1.440/450
010 X.21
0 1 1 X.28 - dedicated PAD, individual NUI
1 0 0 X.28 - dedicated PAD, universal NUI
1 0 1 X.28 - non dedicated PAD
110 X.32
All other values are reserved.

### Table 10.5.105/3GPP TS 04.08: Bearer capability information element

### Table 10.5.106/3GPP TS 04.08: Bearer capability information element

Other ITC (octet 5a) If the value "Other ITC" is not signalled in the field "ITC" then the contents of this field shall be ignored.

Bit **7 6** 

0 0 restricted digital information

All other values are reserved

Other rate adaption (octet 5a) If the value " Other rate adaption" is not signalled in the field "Rate adaption" then the contents of this field shall be ignored.

Bit **5 4** 0 0 V.120

All other values are reserved.

# Table 10.5.107/3GPP TS 04.08: Bearer capability information element

Ra	te adaption header/no header (octet 5b)
Bit	
<b>7</b> 0 1	Rate adaption header not included Rate adaption header included
IVIL	Iltiple frame establishment support in data link (octet 5b)
Bit 6	
0 1	Multiple frame establishment not supported, only UI frames allowed Multiple frame establishment supported
Mo	ode of operation (octet 5b)
Bit	
<b>5</b> 0	Bit transparent mode of operation
1	Protocol sensitive mode of operation
Lo	gical link identifier negotiation (octet 5b)
Bit	
<b>4</b> 0	Default, LLI=256 only
1	Full protocol negotiation, (note: A connection over which protocol negotiation will be executed is indicated in bit 2 of octet 5b)
As	signor/Assignee (octet 5b)
Bit	
<b>3</b> 0	Message originator is "default assignee"
1	Message originator is "assignor only"
In	band/Out of band negotiation (octet 5b)
Bit	
<b>2</b> 0	Negotiation is done in-band using logical link zero
1	Negotiation is done with USER INFORMATION messages on a temporary signalling connection
Bit	1 is spare and set to the value "0"

Table 10.5.108/3GPP TS 04.08: Bearer capability information element

Layer 1 identity (octet 6)
Bits
76
0 1 octet identifier
All other values are reserved
User information layer 1 protocol (octet 6)
Bits
5 4 3 2
0 0 0 0 default layer 1 protocol
All other values reserved.
Synchronous/asynchronous (octet 6)
Bit
1
0 synchronous
1 asynchronous

### Table 10.5.109/3GPP TS 04.08: Bearer capability information element

```
Number of Stop Bits (octet 6a)
Bit
7
  1 bit (This value is also used in the case of synchronous mode)
0
   2 bits
1
Negotiation (octet 6a)
Bit
6
0 in-band negotiation not possible
NOTE: See Rec. V.110 and X.30
All other values are reserved
Number of data bits excluding parity bit if present (octet 6a)
Bit
5
0 7 bits
1
  8 bits (this value is also used in the case of bit oriented protocols)
User rate (octet 6a)
Bits
4321
0 0 0 10.3 kbit/s Recommendation X.1 and V.110
0 0 1 01.2 kbit/s Recommendation X.1 and V.110
0 0 1 12.4 kbit/s Recommendation X.1 and V.110
0 1 0 04.8 kbit/s Recommendation X.1 and V.110
0 1 0 19.6 kbit/s Recommendation X.1 and V.110
0 1 1 012.0 kbit/s transparent (non compliance with X.1 and V.110)
0 1 1 11.2 kbit/s/75 bit/s Recommendation V.23, (asymmetric) X.1,V.110.
All other values are reserved.
For facsimile group 3 calls the user rate indicates the first and maximum speed the mobile station
is using.
```

# Table 10.5.110/3GPP TS 04.08: Bearer capability information element

Octet 6b for V.110/X.30 rate adaptation Intermediate rate (octet 6b)
Bits
76
0 0 reserved
0 1 reserved
1 08 kbit/s
1 1 16 kbit/s
Network independent clock (NIC) on transmission (Tx) (octet 6b) (See Rec. V.110 and X.30)
Bit
5
<ul><li>0 does not require to send data with network independent clock</li><li>1 requires to send data with network independent clock</li></ul>
Network independent clock (NIC) on reception (Rx) (octet 6b) (See Rec. V.110 and X.30)
Bit
4
0 cannot accept data with network independent clock (i.e. sender does not support this
optional procedure) 1 can accept data with network independent clock (i.e. sender does support this optional
procedure)
Devity information (acted Ch)
Parity information (octet 6b) Bits
3 2 1
0 0 0 odd
010 even
011 none
1 0 0 forced to 0
1 0 1 forced to 1
All other values are reserved.

### Table 10.5.111/3GPP TS 04.08: Bearer capability information element

Connection element (octet 6c)								
Bit								
76								
0 0 transparent								
0 1 non transparent (RLP)								
1 0 both, transparent preferred								
1 1 both, non transparent preferred								
The requesting end (e.g. the one sending the SETUP message) should use the 4 values depending on its capabilities to support the different modes. The answering party shall only use the codings 00 or 01, based on its own capabilities and the proposed choice if any. If both MS and network support both transparent and non transparent, priority should be given to the MS preference.								
Modem type (octet 6c) Bits								
5 4 3 2 1								
00000 none								
00001 V.21								
00010 V.22								
0 0 0 1 1 V.22 bis								
00100 V.23								
0 0 1 0 1 V.26 ter								
00110 V.32								
0 0 1 1 1 modem for undefined interface								
0 1 0 0 0 autobauding type 1								
All other values are reserved.								

### Table 10.5.112/3GPP TS 04.08: Bearer capability information element

Other modem type (octet 6d) Bits 76 0 0 no other modem type specified in this field 10 V.34 All other values are reserved. Fixed network user rate (octet 6d) Bit 54321 0 0 0 0 0 Fixed network user rate not applicable/No meaning is associated with this value. 0 0 0 0 1 9.6 kbit/s Recommendation X.1 and V.110 0 0 0 1 0 14.4 kbit/s Recommendation X.1 and V.110 0 0 0 1 1 19.2 kbit/s Recommendation X.1 and V.110 0 0 1 0 0 28.8 kbit/s Recommendation X.1 and V.110 0 0 1 0 1 38.4 kbit/s Recommendation X.1 and V.110 0 0 1 1 0 48.0 kbit/s Recommendation X.1 and V.110(synch) 0 0 1 1 1 56.0 kbit/s Recommendation X.1 and V.110(synch) /bit transparent 0 1 0 0 0 64.0 kbit/s bit transparent All other values are reserved.

# Table 10.5.113/3GPP TS 04.08: Bearer capability information element

	ceptable channel codings (octet 6e), mobile station to network direction:
Bit 7	
	TCH/F14.4 not acceptable
1	TCH/F14.4 acceptable
Bit	
6	
0	Spare
Bit	
5	
	TCH/F9.6 not acceptable
1	TCH/F9.6 acceptable
Bit	
<b>4</b> 0	TCH/E4.9 not accontable
	TCH/F4.8 not acceptable TCH/F4.8 acceptable
	ceptable channel codings (octet 6e), network to MS direction: s 4 to 7 are spare and shall be set to "0".
Dita	s 4 to 7 are spare and shall be set to 0.
Ma Bits	ximum number of traffic channels (octet 6e), MS to network direction:
3 2	
0 0	
00	-
01 01	
10	-
10	
11 11	
	ximum number of traffic channels (octet 6e), network to MS direction:
Bits	s 1 to 3 are spare and shall be set to "0".

## Table 10.5.114/3GPP TS 04.08: Bearer capability information element

1	UIMI, User initiated modification indication (octet 6f),
	765
	0 0 0 User initiated modification not allowed/required
	0 0 1 User initiated modification up to 1 TCH/F allowed/may be requested
	0 1 0 User initiated modification up to 2 TCH/F allowed/may be requested
	0 1 1 User initiated modification up to 3 TCH/F allowed/may be requested
	1 0 0 User initiated modification up to 4 TCH/F allowed/may be requested
	All other values shall be interpreted as "User initiated modification up to 4 TCH/F may be requested".
	Wanted air interface user rate (octet 6f), MS to network direction:
	Bits
	0 0 0 OAir interface user rate not applicable/No meaning associated with this value
	0 0 0 19.6 kbit/s
	0 0 1 014.4 kbit/s 0 0 1 119.2 kbit/s
	0 1 0 1 28.8 kbit/s
	0 1 1 0 38.4 kbit/s
	0 1 1 143.2 kbit/s
	1 0 0 0 57.6 kbit/s
	1 0 0 1 interpreted by the network as 38.4 kbit/s in this version of the protocol
	1 0 1 0 interpreted by the network as 38.4 kbit/s in this version of the protocol
	1 0 1 1 interpreted by the network as 38.4 kbit/s in this version of the protocol
	1 1 0 0interpreted by the network as 38.4 kbit/s in this version of the protocol
	All other values are reserved.
	Wanted air interface user rate (octet 6f), network to MS direction: Bits 1 to 4 are spare and shall be set to "0".

### Table 10.5.115/3GPP TS 04.08: Bearer capability information element

Layer 2 identity (octet 7) Bits <b>7 6</b> 1 0 octet identifier									
All other values are reserved									
User information layer 2 protocol (octet 7)									
Bits <b>5 4 3 2 1</b> 0 0 1 1 0 recommendation X.25, link level 0 1 0 0 0 ISO 6429, codeset 0 (DC1/DC3) 0 1 0 0 1 reserved: was allocated but never used in earlier phases of the protocol 0 1 0 1 0 videotex profile 1 0 1 1 0 0 COPnoFICt (Character oriented Protocol with no Flow Control mechanism) 0 1 1 0 1 X.75 layer 2 modified (CAPI)									
All other values are reserved.									

## 10.5.4.5.1 Static conditions for the bearer capability IE contents

If the information transfer capability field (octet 3) indicates "speech", octets 4, 5, 5a, 5b, 6, 6a, 6b, 6c, 6d, 6e, 6f and 7 shall not be included.

If the information transfer capability field (octet 3) indicates "speech", octet 3a etc. shall be included only if the mobile station supports CTM text telephony or if it supports at least one speech version other than:

- GSM full rate speech version 1; or
- GSM half rate speech version 1.

If the information transfer capability field (octet 3) indicates a value different from "speech", octets 4, 5, 6, 6a, 6b, and 6c shall be included, octets 6d, 6e and 6f are optional. In the network to MS direction in case octet 6d is included, octets 6e and 6f may be included. In the MS to network direction in case octet 6d is included octet 6e shall also be included and 6f may be included.

If the information transfer capability field (octet 3) indicates "facsimile group 3", the modem type field (octet 6c) shall indicate "none".

If the information transfer capability field (octet 3) indicates "other ITC" or the rate adaption field (octet 5) indicates "other rate adaption", octet 5a shall be included.

If the rate adaption field (octet 5) indicates "other rate adaption" and the other rate adaption field (octet 5a) indicates "V.120", octet 5b shall be included.

The modem type field (octet 6c) shall not indicate "autobauding type 1" unless the connection element field (octet 6c) indicates "non transparent".

## 10.5.4.5a Call Control Capabilities

The purpose of the Call Control Capabilities information element is to identify the call control capabilities of the mobile station.

The Call Control Capabilities information element is coded as shown in figure 10.5.89/3GPP TS 04.08 and table 10.5.116/3GPP TS 04.08.

The Call Control Capabilities is a type 4 information element with a length of 3 octets.

8	7		б	5	4	3	2		1		
+			Call	Control	Capal	oiliti	les	IEI		octet	1
ļ	Length	of	Call	Control	Capal	oiliti	es	cont	ents	octet	2
	0	0	0	0 spare	0	0		PCP	DTMF	octet	3

#### Figure 10.5.89/3GPP TS 04.08: Call Control Capabilities information element

```
DTMF (octet 3, bit 1)
0 This value is reserved for earlier versions of
    the protocol.
1 This value indicates that the mobile station
    supports DTMF as specified in sub-clause 5.5.7 of
    the present document.
PCP (octet 3, bit 2)
0 This value indicates that the mobile station
    does not support the Prolonged Clearing Procedure
1 This value indicates that the mobile station
    supports the Prolonged Clearing Procedure.
```

### Table 10.5.116/3GPP TS 04.08: Call Control Capabilities

#### 10.5.4.6 Call state

The purpose of the call state information element is to describe the current status of a call, (see sub-clause 5.1).

The call state information element is coded as shown in figure 10.5.90/3GPP TS 04.08 and table 10.5.117/3GPP TS 04.08.

The call state is a type 3 information element with 2 octets length.

	8	7	б	5	4	3	2	1		
Ţ				call :	state	IEI			octet	1
+		ding ndard	call	state	value	(coded	in	binary)	octet	2

Figure 10.5.90/3GPP TS 04.08: Call state information element

Table 10.5.117/3GPP TS 04.08: Call state information element

0 0 standardized coding as described in ITU-T Rec. Q.931 0 1 reserved for other international standards 1 0 national standard 1 1 standard defined for the GSM&PLMNS as described below Coding standards other than "1 1 - Standard defined for the GSM&PLMNS" shall not be used if the call state can be represented with the GSM&standardized coding. The mobile station or network need not support any other coding standard than "1 1 - Standard defined for the GSM& PLMNS". If a call state IE indicating a coding standard not supported by the receiver is received, call state "active" shall be assumed. Call state value (octet 2) Bits 6 5 4 3 2 1 0 0 0 0 0 1 0 U0 null NO - null 0 0 0 0 1 0 U0.2- CC prompt present NO.1- MM connection pending 1 0 0 1 0 1 0 U0.2- CC prompt present NO.3- Network answer 1 0 0 1 0 1 0 U0.4- CC-Establishment NO.4- CC-Establish- confirmed ment confirmed ment confirmed 1 0 0 1 0 1 0 U0.5- CC-Establishment NO.4- CC-Establish- confirmed NI - call initiated 1 0 0 1 1 0 U0.6- Recall present NI - call present 0 0 0 0 0 1 UI - call initiated NI - call proceeding 1 0 0 1 0 1 0 U0.6- Recall present NI - call proceeding 1 0 0 1 0 U4 - call gelivered NI - call proceeding 0 0 0 1 0 U3 - mobile originating 0 0 1 0 0 U4 - call present NI - call proceeding 0 0 1 0 0 U4 - call confirmed NI - call delivered 0 0 0 1 1 U3 - mobile terminating NI - mobile origina- call confirmed NI - call delivered NI - call proceeding 0 0 1 0 0 U4 - call delivered NI - call delivered 0 0 1 0 1 0 U2- disconnect request NI - call confirmed 0 0 1 0 1 0 U2- disconnect request NI - call confirmed 0 0 1 0 1 0 U2- disconnect request NI - call confirmed 0 1 0 0 1 0 U2- disconnect request NI - call confirmed 0 1 0 0 1 0 U2- disconnect request NI - call confirmed 0 1 0 0 1 0 U2- mobile terminating NI - mobile termina- ting modify NI - call state request NI - release request 0 1 0 0 1 1 U2- mobile terminating NI - mobile termina- ting modify NI - mobile terminating NI - mobile terminating NI - mobil	Coding standard (octet 2) Bits	+										
standards 1 0 national standard 1 1 standard defined for the GSM&PLMNS as described below Coding standards other than "1 1 - Standard defined for the GSM&PLMNS" shall not be used if the call state can be represented with the GSM&Standardized coding. The mobile station or network need not support any other coding standard than "1 1 - Standard defined for the GSM& PLMNS". If a call state IE indicating a coding standard not supported by the receiver is received, call state "active" shall be assumed. Call state value (octet 2) Bits 6 5 4 3 2 1 0 0 0 1 0 U0.1- MM connection pending 1 0 0 0 1 0 U0.2- CC prompt present N0.2- CC connection pending 1 0 0 1 1 U0.3- Wait for network N0.3- Network answer information pending 1 0 0 1 0 U 0.4- CC-Establishment N0.4- CC-Establish- ment present 1 0 0 1 1 U 0.5- CC-Establishment N0.6- Recall present 1 0 0 1 1 U 0.6- Recall present N0.6- Recall present 1 0 0 1 1 U 0.6- Recall present N0.6- Recall present 1 0 0 1 0 U 0 4- call initiated N1 - call initiated 1 0 0 1 0 U 0 4- call delivered N4 - call delivered 0 0 1 1 1 U 0 - active N7 - call received 0 0 1 0 1 0 U 0 - call present N6 - call present 0 0 0 1 0 U 1 - call present N8 - call present 0 0 1 0 0 U 8 - connect request N8 - connect request 0 0 1 0 0 1 0 U 9 - mobile terminating N9 - mobile termina- call confirmed T1 - call initiated N1 - call indication 0 1 0 0 1 0 U 0 - active N10 - active 0 1 0 1 0 U 0 - active N10 - active 0 1 0 1 0 U 0 - active N10 - active 0 1 0 1 0 U 0 - active N10 - active 0 1 0 0 1 0 U 0 - active N10 - active 0 1 0 0 1 0 U 0 - active N10 - active 0 1 0 1 0 U 0 - active N10 - active 0 1 0 0 1 0 0 U 2- mobile terminating N2- mobile termina- ting modify N2- connect indication N12-disconnect 1 ndication 0 1 0 0 1 1 U2- mobile terminating N2- mobile termina- ting modify N2- connect indication N12-disconnect 1 ndication 0 1 0 1 1 U2- mobile terminating N2- mobile termina- ting modify N2- connect indication N12-disconnect indication 0 1 0 1 1 U2- mobile termin	ITU-T Rec. Q.931											
Coding standards other than "1 1 - Standard defined for the GSMSPLMNS" shall not be used if the call state can be represented with the GSMSstandardized coding. The mobile station or network need not support any other coding standard than "1 1 - Standard defined for the GSMS PLMNS". If a call state IE indicating a coding standard not supported by the receiver is received, call state "active" shall be assumed. Call state value (octet 2) Bits 6 5 4 3 2 1 0 0 0 0 1 0 U0.1 - MM connection N0.1 - MM connection pending pending 1 0 0 0 1 1 U0.2 - CC prompt present N0.2 - CC connection pending 1 0 0 1 0 1 0 U0.2 - CC prompt present N0.3 - Metwork answer information pending 1 0 0 1 0 1 0 U0.4 - CC-Establishment N0.4 - CC-Establish- present Metal present 1 0 0 1 0 U0.6 - Recall present N0.6 - Recall present 1 0 0 1 1 U1 - call initiated N1 - call initiated 0 0 0 0 1 1 U3 - mobile originating N3 - mobile originan- call proceeding ting call proceeding 0 0 1 1 0 U4 - call delivered N4 - call delivered 0 0 1 1 0 U8 - connect request N8 - connect request 0 0 1 0 0 U8 - connect request 0 0 1 0 1 0 U9 - mobile terminating N9 - mobile termina- call confirmed N1 - call present N1 - call present 0 0 1 0 0 U8 - connect request N8 - connect request 0 1 0 0 1 0 U8 - connect request N10 - active 0 1 0 0 1 1 0 U2 - disconnect request 0 1 0 0 1 1 0 U2 - disconnect request 0 1 0 0 1 1 0 U2 - disconnect request 0 1 0 0 1 1 0 U2 - disconnect request 0 1 0 0 1 1 0 U2 - mobile originating N2 - mobile termina- ting modify 0 1 1 0 1 1 U2 - mobile originating N2 - mobile termina- diff M2 - mobile originating N2 - mobile termina- ting modiffy 0 1 1 0 1 1 U2 - mobile terminating N2 - mobile termina- ting modiffy 0 1 1 0 1 1 U2 - mobile terminating N2 - mobile termina- ting modiffy 0 1 1 0 1 1 U2 - mobile terminating N2 - mobile termina- ting modiffy 0 1 1 0 1 1 U2 - mobile terminating N2 - mobile termina- ting modiffy	standards 1 0 national standard 1 1 standard defined for the GSMßPLMNS											
GSMSPLMNS" shall not be used if the call state can be represented with the GSMSstandardized coding.The mobile station or network need not support any other coding standard than "1 1 - Standard defined for the GSMS PLMNS".If a call state IE indicating a coding standard not supported by the receiver is received, call state "active" shall be assumed.Call state value (octet 2)Bits 6 5 4 3 2 1 0 0 0 0 1 0 U0.1- MM connection pendingNO nullNO nullNO nullNO nullNO nullNO nullNO nullNO nullNO null0 0 0 1 0 UO colspan="2">NO null0 0 - nullNO null0 0 - nullNO null0 0 - nullNO null0 0 0 10 U0.2- CC prompt presentNO.2- CC connection pending- notation- notationpending1 0 0 1 0 U0.3- Wait for networkNO.2- CC connection pending- notation- notation- notation- notation- notation- notation- notation- notation- notation- notation <td colspan="11">as described below</td>	as described below											
coding standard than "1 1 - Standard defined for the GSMS PLMNS".If a call state IE indicating a coding standard not supported by the receiver is received, call state "active" shall be assumed.Call state value (octet 2)Bits 6 5 4 3 2 1 0 0 0 0 0 0 UO - nullNO - nullO 0 0 1 0 UO - Recent pending1 0 0 1 1 UO.3- Wait for networkNO.4- CC EstablishmentNO.4- CC-EstablishmentNO.5- CC-Establish- ment confirmedment confirmed1 0 0 1 0 U.6- Recall presentNO.6- Recall presentNO.6- Recall presentNO.6- Recall present0 0 0 1 1 U3 - call receivedN1 - call receivedN1 - call presentNO.6- Recall presentNO.6- Recall presentNO.6- Recall presentNO.6- Recall presentN0 - call received </td <td colspan="12" rowspan="2"><pre>GSMBPLMNS" shall not be used if the call state can be represented with the GSMBstandardized coding. The mobile station or network need not support any other coding standard than "1 1 - Standard defined for the GSMB</pre></td>	<pre>GSMBPLMNS" shall not be used if the call state can be represented with the GSMBstandardized coding. The mobile station or network need not support any other coding standard than "1 1 - Standard defined for the GSMB</pre>											
If a call state IE indicating a coding standard not supported by the receiver is received, call state "active" shall be assumed.Call state value (octet 2)Bits 6 5 4 3 2 1 0 0 0 0 1 0 U0 - nullNO - null pending pending1 0 0 0 1 0 U0.1- MM connection pendingNO - null pending1 0 0 0 1 0 U0.2- CC prompt presentNO.2- CC connection pending1 0 0 0 1 1 U0.3- Wait for network no - cC-EstablishmentNO.4- CC-Establish- ment present1 0 0 1 0 1 0 0.5- CC-Establishment confirmedNO.5- CC-Establish- ment confirmed1 0 0 1 1 0 U0.6- Recall presentNO.6- Recall present0 0 0 0 1 U1 - call initiated 0 0 0 1 1 U3 - mobile originating call proceeding ting call proceeding ting call proceeding ting call proceeding ting call present0 0 1 0 0 U4 - Call delivered 0 0 1 1 0 U6 - call received 0 0 1 1 0 U10- activeN1 - call initiated N7 - call received N8 - connect request N8 - connect request 0 0 1 0 0 U10 active0 0 1 0 1 1 0 U10- active 0 1 1 0 11 0 U10- activeN10- active N10- active0 0 1 1 0 11 0 U2- 0 1 1 0 11 0 U2- mobile originating modifyN19- release request N10- active0 1 1 0 1 1 0 0 0 12- 0 1 1 0 11 0 0 0 12- 0 1 1 0 11 0 0 0 0 0 0 0 0 0 0 0 0 0 0												
Bits       6 5 4 3 2 1       NO - null       NO - null         0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	If a call state IE indicating a coding s supported by the receiver is received, c	tandard not all state "active"										
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	Call state value (octet 2)											
1001001001001001001001001001001000100001000001000	6 5 4 3 2 1 0 0 0 0 0 0 UO - null 0 0 0 0 1 0 UO.1- MM connection	N0.1- MM connection										
10011110.3-Wait for networkN0.3-Network answerinformationpending101000.4-CC-EstablishmentN0.4-CC-Establish-presentment presentment present101000.5-CC-EstablishmentN0.5-CC-Establish-confirmedment confirmed100110.6-Recall presentN0.6-Recall present000111- call initiatedN1 - call initiated000111- call proceedingting call proceeding000110- call presentN6 - call present001100- call presentN7 - call received00110011010011101011110101110101110101110101110111110111110111110111110111110111<		N0.2- CC connection										
101000.4-CC-EstablishmentN0.4-CC-Establish- ment present101010.5-CC-EstablishmentN0.5-CC-Establish- ment confirmed00110.6-Recall presentN0.6-Recall present000111-call initiatedN1-call initiated000110-call initiatedN3-mobile origina- ting call proceeding0001004-call deliveredN4-call delivered001004-call deliveredN7-call present00110.7-call receivedN7-call received00110004-call confirmednde0011004-call confirmedndende0011004-call confirmedndende0100004-call confirmedndende0100000ndendende0010000ndende0100000ndende0100000ndende0100000ndend		N0.3- Network answer										
101010.5-CC-EstablishmentN0.5-CC-Establish- ment confirmed101100.6-Recall presentN0.6-Recall present000111- call initiatedN1- call initiated000111- call initiatedN1- call initiated000111- call initiatedN1- call initiated000100- call initiatedN1- call initiated0001000- call initiatedN1- call initiated0010000- call initiatedN1- call initiated00100000- call initiatedN1- call initiated00000000- call initiatedN1- call initiated00000000- call initiatedN4- call delivered00000000- call presentN6- call present00000000- call receivedN7- call received00100000- connect requestN8- connect request00100000<		N0.4- CC-Establish-										
confirmedment confirmed1 0 0 1 1 0 00.6- Recall presentN0.6- Recall present0 0 0 0 1 1 01 - call initiatedN1 - call initiated0 0 0 0 1 1 01 - call initiatedN1 - call initiated0 0 0 0 1 1 01 - call deliveredN3 - mobile origina- ting call proceeding0 0 0 1 1 0 0 04 - call deliveredN4 - call delivered0 0 0 1 1 0 04 - call presentN6 - call present0 0 0 1 1 0 04 - call receivedN7 - call received0 0 0 1 1 0 04 - call receivedN7 - call received0 0 1 1 0 04 - call receivedN8 - connect request0 0 1 0 0 1 09 - mobile terminatingN9 - mobile termina- ting call confirmed0 0 1 0 0 1 00 11 09 - mobile terminatingN10 - active0 0 1 0 1 1 00 00 00 00 00 00 00 00 00 0	present	ment present										
00001U1 - call initiatedN1 - call initiated00011U3 - mobile originating call proceedingN3 - mobile origina- ting call proceeding0010U4 - call deliveredN4 - call delivered00110U6 - call presentN6 - call present0011U7 - call receivedN7 - call received00100U8 - connect requestN8 - connect request00101U9 - mobile terminatingN9 - mobile termina- ting call confirmed0010U10 - activeN10 - active0100U12 - disconnect requestN12-disconnect0100U12 - disconnect indicationN19 - release request0100U2 - mobile originatingN26 - mobile origina- ting modify0101U27 - mobile terminatingN27 - mobile termina- ting modify0110U27 - mobile terminatingN27 - mobile termina- ting modify0110U27 - mobile terminatingN28 - connect indication	confirmed	ment confirmed										
0001113- mobile originating call proceedingN3- mobile origina- ting call proceeding0010004- call deliveredN4- call delivered001100- call presentN6- call present001100- call presentN7- call present0011000- call presentN8- connect request0010000- call presentN9- mobile termina- ting call confirmed0100100- activeN10- active0100110- activeN10- active0110011- release requestN12- disconnect0110012- release requestN12- disconnect0110110- release requestN12- release request0110110- release requestN26- mobile terminating011010- release requestN27mobile termina- ting modify011010N28- connect indication												
00010014- call deliveredN4- call delivered0011006- call presentN6- call present0011107- call receivedN7- call received001110008- connect requestN8- connect request0010018- connect requestN8- connect request01001010- activeN10- active010110011- activeN10- active0110012- disconnect indicationN12-disconnect indicationN12-disconnect indication0100110012- mobile originatingN26mobile originating0110110N27mobile terminatingN27mobile terminating0110110N28connect indication	0 0 0 0 1 1 U3 - mobile originating	N3 - mobile origina-										
0011107- call receivedN7- call received00100008- connect requestN8- connect request001001109- mobile terminatingN9- mobile termina- ting call confirmed001010activeN10activeN10-0011011disconnect requestN12-disconnect0110012-disconnect indicationN12-disconnect010011U19-release requestN19-011012-mobile originatingN26-mobile origina- ting modify0110110127-mobile terminatingN27-mobile termina- ting modify01100126-mobile terminatingN27-mobile termina- ting modify0110010N28-connect indication	0 0 0 1 0 0 U4 - call delivered	N4 - call delivered										
00100018- connect requestN8- connect request0010119- mobile terminating call confirmedN9- mobile termina- ting call confirmed001010activeN10-active0011011-disconnect requestN10-active00110012-disconnect requestN12-disconnect0110012-disconnect indicationN12-disconnect010010U19-release requestN19-release request010012-mobile originating modifyN26-mobile origina- ting modify01101U27-mobile terminating modifyN27-mobile termina- ting modify01100N28-connect indication		N6 - call present N7 - call received										
call confirmedting call confirmed0 0 1 0 1 0 U10- activeN10- active0 0 1 0 1 1 U11- disconnect requestN10- active0 0 1 1 0 0 U12- disconnect indicationN12-disconnect0 1 0 0 1 1 U19- release requestN19- release request0 1 0 0 1 1 U19- release requestN19- release request0 1 0 0 1 1 U19- release requestN19- release request0 1 1 0 1 0 U26- mobile originatingN26- mobile originatingmodifynobile terminating0 1 1 0 1 1 U27- mobile terminatingN27- mobile terminating0 1 1 1 0 0N28- connect indication		N8 - connect request										
0010111	call confirmed	ting call confirmed										
<pre>indication 0 1 0 0 1 1 U19- release request 0 1 1 0 1 0 U26- mobile originating modify 0 1 1 0 1 1 U27- mobile terminating modify 0 1 1 1 0 0 indication N19- release request N26- mobile origina- ting modify N27- mobile termina- ting modify N28- connect indication</pre>		NIU- active										
0 1 0 0 1 1U19- release requestN19- release request0 1 1 0 1 0U26- mobile originating modifyN26- mobile origina- ting modify0 1 1 0 1 1U27- mobile terminating modifyN27- mobile termina- ting modify0 1 1 1 0 0N28- connect indication	0 0 1 1 0 0 U12- disconnect indication											
0 1 1 0 1 1 U27- mobile terminating modifyN27- mobile termina- ting modify0 1 1 1 0 0N28- connect indication	0 1 1 0 1 0 U26- mobile originating	N19- release request N26- mobile origina-										
0 1 1 1 0 0 N28- connect indication	0 1 1 0 1 1 U27- mobile terminating	N27- mobile termina-										

## 10.5.4.7 Called party BCD number

The purpose of the called party BCD number information element is to identify the called party.

The called party BCD number information element is coded as shown in figure 10.5.91/3GPP TS 04.08 and table 10.5.118/3GPP TS 04.08.

The called party BCD number is a type 4 information element with a minimum length of 3 octets and a maximum length of 43 octets. For PCS 1900 the maximum length is 19 octets.

	8	7	б	5	4	3	2	1		
+			Called	part	y BCD	number	IEI		octet	1
+	Lei	ngth of	called	part	y BCD	number	conte	nts 	octet	2
	1 ext		be of Nber		Nun ide	octet	3			
	N	umber d	ligit 2		Νι	umber di	igit 1		octet	4*
	N	umber d	ligit 4		Nu	umber di	igit 3		octet	5*
1		2)		+					:	
+									+	

#### Figure 10.5.91/3GPP TS 04.08: Called party BCD number information element

- NOTE 1: The number digit(s) in octet 4 precedes the digit(s) in octet 5 etc. The number digit which would be entered first is located in octet 4, bits 1 to 4.
- NOTE 2: If the called party BCD number contains an odd number of digits, bits 5 to 8 of the last octet shall be filled with an end mark coded as "1111".

Since the information element must contain the complete called party BCD number there is no need for an additional complete indication.

Type of	number (octet 3) (Note 1)
Bits 765 000 001 010 011 100 101 110 110	unknown (Note 2) international number (Note 3, Note 5) national number (Note 3) network specific number (Note 4) dedicated access, short code reserved reserved reserved for extension

#### Table 10.5.118/3GPP TS 04.08: Called party BCD number

- NOTE 1: For the definition of "number" see ITU-T Recommendation I.330 and 3GPP TS 03.03.
- NOTE 2: The type of number "unknown" is used when the user or the network has no knowledge of the type of number, e.g. international number, national number, etc. In this case the number digits field is organized according to the network dialling plan, e.g. prefix or escape digits might be present.
- NOTE 3: Prefix or escape digits shall not be included.
- NOTE 4: The type of number "network specific number" is used to indicate administration/service number specific to the serving network, e.g. used to access an operator.
- NOTE 5: The international format shall be accepted by the MSC when the call is destined to a destination in the same country as the MSC.

Table 10.5.118/3GPP TS 04.08: Called party BCD number (continued)

```
Numbering plan identification (octet 3)
Number plan (applies for type of number = 000, 001, 010 and 100)
Bits
4 3 2 1
0 0 0 0 unknown
0 0 0 1 ISDN/telephony numbering plan
              (Rec. E.164/E.163)
  0 1 1 data numbering plan (Recommendation X.121)
1 0 0 telex numbering plan (Recommendation F.69)
0 0 0 national numbering plan
0 0 1 private numbering plan
1 1 reserved for CTS (see 3GPP TS 04.56)
0 0 1
0
1
1
0
  1 1
1 1 1 1 1 reserved for extension
All other values are reserved.
                                 ------
```

When an MS is the recipient of number information from the network, any incompatibility between the number digits and the number plan identification shall be ignored and a STATUS message shall not be sent to the network.

In the case of numbering plan "unknown", the number digits field is organized according to the network dialling plan; e.g. prefix or escape digits might be present.

### Table 10.5.118/3GPP TS 04.08: Called party BCD number (continued)

Number digits           Bits           4 3 2 1 or           8 7 6 5           0 0 0 0           0 0 1 0           0 1 0           0 1 0           0 1 0           0 1 0           0 1 1           0 1 0           0 1 1 0           0 1 1 1           1 0 0 1           1 0 0 1	(octets 4, etc.) Number digit value 0 1 2 3 4 5 6 7 8 9
1 0 1 0 1 0 1 1 1 1 0 0 1 1 0 1 1 1 0 1 1 1 1 0 1 1 1 1 num	* # a b c used as an endmark in the case of an odd mber of number digits

## 10.5.4.8 Called party subaddress

The purpose of the Called party subaddress is to identify the subaddress of the called party of a call. For the definition of a subaddress see ITU-T Recommendation I.330.

The Called party subaddress information element is coded as shown in figure 10.5.92/3GPP TS 04.08 and table 10.5.119/3GPP TS 04.08

The called party subaddress is a type 4 information element with a minimum length of 2 octets and a maximum length of 23 octets.

	. 8	7	6	5	4	3	2	1			
-	+		Calle	ed part	y Suba	ddres	s IEI		octet 1		
	Ler	octet 2									
_	1 ext		pe of baddres		odd/ev Indica		0 spare	0	octet 3*		
	Subaddress information										
-	: : : : +										

#### Figure 10.5.92/3GPP TS 04.08: Called party subaddress

Table 10.5.119/3GPP TS 04.08: Called party subaddress

Type of subaddress (octet 3) Bits 765 0 0 0 NSAP (X.213/ISO 8348 AD2) User specified 0 1 0 All other values are reserved Odd/even indicator (octet 3) Bit 4 0 even number of address signals 1 odd number of address signals NOTE: The odd/even indicator is used when the type of subaddress is "user specified" and the coding is BCD. Subaddress information (octet 4, etc...) The NSAP X.213/ISO8348AD2 address shall be formatted as specified by octet 4 which contains the Authority and Format Identifier (AFI). The encoding is made ac-cording to the "preferred binary encoding" as defined in X.213/ISO8348AD2. For the definition of this type of subaddress, see Rec. ITU-T I.334. A coding example is given in ANNEX A. For User-specific subaddress, this field is encoded according to the user specification, subject to a maximum length of 20 octets. When interworking with X.25 networks BCD coding should be applied. NOTE: It is recommended that users apply NSAP subaddress type since this subaddress type allows the use of decimal, binary and IA5 characters in a standardised manner. \_\_\_\_\_

### 10.5.4.9 Calling party BCD number

The purpose of the calling party BCD number information element is to identify the origin of a call.

The calling party BCD number information element is coded as shown in figure 10.5.93/3GPP TS 04.08 and table 10.5.120/3GPP TS 04.08.

The calling party BCD number is a type 4 information element. In the network to mobile station direction it has a minimum length of 3 octets and a maximum length of 14 octets. (This information element is not used in the mobile station to network direction.)

\*

	8	7	6	5	4	3	2	1		
1	Calling party BCD number IEI									1
	Lei	ents	octet	2						
	0/1 ext	type numl		Numbering plan identification			octet	3		
	1 ext	present indica		0	0 spare	0	scree		octet	3a'
	Nı	umber d:	igit 2		Nun	nber d	igit 1		octet	4*
ļ	N	umber d:	igit 4		Number digit 3				octet	5*
									:	
4								+	-	

#### Figure 10.5.93/3GPP TS 04.08: Calling party BCD number information element

The contents of octets 3, 4, etc. are coded as shown in table 10.5.118. The coding of octet 3a is defined in table 10.5.120.

If the calling party BCD number contains an odd number of digits, bits 5 to 8 of the last octet shall be filled with an end mark coded as "1111".

#### Table 10.5.120/3GPP TS 04.08: Calling party BCD number

Presentation indicator (octet 3a) Bits 76 0 0 Presentation allowed 0 1 Presentation restricted 1 0 Number not available due to interworking 1 1 Reserved If octet 3a is omitted the value "00 - Presentation allowed" is assumed. Screening indicator (octet 3a) Bits 2 1 0 0 User-provided, not screened User-provided, verified and passed User-provided, verified and failed 0 1 1 0 1 1 Network provided If octet 3a is omitted the value "0 0 - User provided, not screened" is assumed. 

#### 10.5.4.10 Calling party subaddress

The purpose of the Calling party subaddress is to identify a subaddress associated with the origin of a call. For the definition of a subaddress see Rec. ITU-T I.330.

The Calling party subaddress information element is coded as shown in figure 10.5.94/3GPP TS 04.08 and table 10.5.121/3GPP TS 04.08

The calling party subaddress is a type 4 information element with a minimum length of 2 octets and a maximum length of 23 octets.

	8	7	6	5	4	3	2	1		
			Calli	.ng pai	rty Sub	addres	s IEI		octet	1
	Ler	ngth of	calli	.ng pai	rty sub	addres	s con	tents	octet	2
	1 ext		pe of Daddres	s	odd/ev Indica		0	0	octet	3*
			Subac	ldress	inform	ation			octet	4*
• : -+				·	: 				etc.	

#### Figure 10.5.94/3GPP TS 04.08: Calling party subaddress

Table 10.5.121/3GPP TS 04.08: Calling party subaddress

```
Type of subaddress (octet 3)
Bits
765
0 0 0
          NSAP (X.213/ISO 8348 AD2)
         User specified
0 1 0
All other values are reserved
Odd/even indicator (octet 3)
Bit
4
0
           even number of address signals
           odd number of address signals
1
The odd/even indicator is used when the type of
subaddress is "user specified" and the coding is BCD
Subaddress information (octet 4, etc...)
The NSAP X.213/ISO8348AD2 address shall be formatted
as specified by octet 4 which contains the Authority
and Format Identifier (AFI). The encoding is made ac-
cording to the "preferred binary encoding" as defined
in X.213/ISO8348AD2. For the definition of this type
of this type of subaddress, see Rec. ITU-T I.332.
A coding example is given in ANNEX A.
For User-specific subaddress, this field is encoded
according to the user specification, subject to a maximum length of 20 octets. When interworking with X.25 networks BCD coding should be applied.
NOTE: It is recommended that users apply NSAP subad-
dress type since this subaddress type allows the use
of decimal, binary and IA5 characters in a standar-
dised manner.
         _____
```


## 10.5.4.11 Cause

The purpose of the cause information element is to describe the reason for generating certain messages, to provide diagnostic information in the event of procedural errors and to indicate the location of the cause originator.

The cause information element is coded as shown in figure 10.5.95/3GPP TS 04.08 and tables 10.5.122 and 10.5.123/3GPP TS 04.08.

The cause is a type 4 information element with a minimum length of 4 octets and a maximum length of 32 octets.

The cause information element may be repeated in a message.



### Figure 10.5.95/3GPP TS 04.08: Cause information element

If the default value applies for the recommendation field, octet 3a shall be omitted.

#### Table 10.5.122/3GPP TS 04.08: Cause information element

Coding standard (octet 3) Bits 76 0 0 Coding as specified in ITU-T Rec. Q.931 Reserved for other international standards National standard 0 1 1 0 Standard defined for the GSMßPLMNS as described 1 1 below and in table 10.86/GSMB04.08 Coding standards other than "1 1 - Standard defined for the GSM $\mbox{SPLMNS}$ " shall not be used if the cause can be represented with the GSMßstandardized coding. The mobile station or network need not support any other coding standard than "1 1 - Standard defined for the GSMß  $\,$ PLMNS If a cause IE indicating a coding standard not supported by the receiver is received, cause "interworking, unspecified" shall be assumed. Location (octet 3) Bits 4 3 2 1 0 0 0 0 user 0 0 0 1 0 0 1 0 private network serving the local user public network serving the local user 0 0 1 1 transit network 1 0 0 0 public network serving the remote user 0 1 0 1 private network serving the remote user international network network beyond interworking point All other values are reserved. Recommendation (octet 3a) Octet 3a shall not be included if the coding standard is coded as "1 1 - Standard defined for GSMBPLMNS". If the coding standard is different from "1 1 - Standard defined for GSM&PLMNS", the coding of octet 3a, if included, and octets 4 to N is according to that coding standard. Cause value (octet 4) The cause value is divided in two fields: a class (bits 5 through 7) and a value within the class (bits 1 through 4). The class indicates the general nature of the event. Class (000): normal event Class (000): normal event Class (001): normal event Class (010): resource unavailable Class (011): service or option not available Class (100): service or option not implemented Class (101): invalid message (e.g. parameter out of range) Class (110): protocol error (e.g. unknown message) Class (111): interworking The cause values are listed in Table 10.86/GSMB04.08 below and defined in Annex H. Diagnostic(s) (octet 5) Diagnostic information is not available for every cause, see Table 10.86/GSMB04.08 below. When available, the diagnostic(s) is coded in the same way as the corresponding information element in clause 10. The inclusion of diagnostic(s) is optional.

Table 10.5.123/3GPP TS 04.08: Cause information element values

Cause value Cause Cause

Cla	ass	Va	alı	ıe		num.		nostic
7	65	4	3	2	1			
0	0 0	0	0	0	1	1.	Unassigned (unallocated) number	Note 9
0 0 0 0	0 0 0 0 0 1 0 1 0 1 0 1	0 1 0 0 0	0 1 0 0 0 0 0	1 0 0 1	0 0 0 1 0	3. 6. 8. 16. 17. 18. 19.	No route to destination Channel unacceptable Operator determined barring Normal call clearing User busy No user responding User alerting, no answer	Note 9  Note 9 Note 1 
0	0 1	0	1	0	1	21.	Call rejected	Note 9 - user supplied diag-
0	0 1	0	1	1	0	22.	Number changed	nostic (note 4) New destination (note 5)
0	0 1 0 1 0 1 0 1	1 1	0 0 0 1	1 1	0 1	25 26. 27. 28.	Pre-emption Non selected user clearing Destination out of order Invalid number format (in-	
0	0 1 0 1 0 1 1 0	1 1	1 1 1 0	1 1	0 1	29. 30. 31. 34.	<pre>complete number) Facility rejected Response to STATUS ENQUIRY Normal, unspecified No circuit/channel available</pre>	Note 1 - - Note 1
0 1	1 0 1 0 1 0 1 0	0 1	1 0 0	1	0 1	38. 41. 42.	Network out of order Temporary failure Switching equipment conges- tion	
	1 0		0			43.	Access information discarded	Discarded info- mation element identifiers (note 6)
0 :	1 0	1	1	0	0	44.	requested circuit/channel not available	-
0	1 0	1	1	1	1	47.	Resources unavailable, un- specified	-
0	1 1	0	0	0	1	49.	Quality of service unavailable	Note 9
0	1 1	0	0	1	0	50.	Requested facility not sub- scribed	Note 1
0	1 1	0	1	1	1	55.	Incoming calls barred with- in the CUG	Note 1
0	1 1	1	0	0	1	57.	Bearer capability not au- thorized	Note 3
0	1 1	1	0	1	0	58.	Bearer capability not pre-	Note 3
0	1 1	1	1	1	1	63.	sently available Service or option not	-
1	0 0	0	0	0	1	65.	available, unspecified Bearer service not	Note 3
1	0 0	0	1	0	0	68.	implemented ACM equal to or greater	
1	0 0	0	1	0	1	69.	than ACMmax Requested facility not	Note 1
1	0 0	0	1	1	0	70.	implemented Only restricted digital information bearer capability is available	
1	0 0	1	1	1	1	79.	Service or option not implemented, unspecified	-
1	0 1	0	0	0	1	81.	Invalid transaction iden- tifier value	_
1	0 1	0	1	1	1	87.	User not member of CUG	Note 1
	0 1					88.	Incompatible destination	Incompatible parameter (Note 2)
1	0 1					91.	Invalid transit network se- lection	-
1	0 1	1	1	1	1	95.	Semantically incorrect message	-
1 :	1 0	0	0	0	0	96.	Invalid mandatory informa- tion	Information element identifier(s)
1 1	1 0	0	0	0	1	97.	Message type non-existent or not implemented	Message type
1 1	1 0	0	0	1	0	98.	Message type not compatible	Message type

1	1	0	0	0	1	1	99.	with protocol state Information element non-ex- istent or not implemented	Information element
1	1	0	0	1	0	0	100.	Conditional IE error	identifier(s) (notes 6,7) Information element identifier(s)
1	1	0	0	1	0	1	101.	Message not compatible with protocol state	(note 6) Message type
1	1	0	0	1	1	0	102.	Recovery on timer expiry	Timer number (note 8)
1 1	1 1	0 1	1 1				111. 127.	Protocol error, unspecified Interworking, unspecified	-

All other values in the range 0 to 31 shall be treated as cause 31.

All other values in the range 32 to 47 shall be treated as cause 47.

All other values in the range 48 to 63 shall be treated as cause 63.

All other values in the range 64 to 79 shall be treated as cause 79.

All other values in the range 80 to 95 shall be treated as cause 95.

All other values in the range 96 to 111 shall be treated as cause 111.

All other values in the range 112 to 127 shall be treated as cause 127.

NOTE 1: Diagnostics for supplementary services are handled as follows:

octet 5, bit 8:

This is an extension bit as defined in the preliminary part of sub-clause 10.5. In this version of this protocol, this bit shall be set to 1. If it is set to zero, the contents of the following octets shall be ignored.

octet 5, bit 7-1:

0000001 - Outgoing calls barred within CUG

0000010 - No CUG selected

0000011 - Unknown CUG index

0000100 - CUG index incompatible with requested basic service

0000101 - CUG call failure, unspecified

0000110 - CLIR not subscribed

0000111 - CCBS possible

0001000 - CCBS not possible

All other values shall be ignored.

NOTE 2: The incompatible parameter is composed of the incompatible information element identifier.

- NOTE 3: The format of the diagnostic field for cause numbers 57, 58 and 65 is as shown in figure 10.5.88/3GPP TS 04.08 and tables 10.5.102/3GPP TS 04.08 to 10.5.115/3GPP TS 04.08.
- NOTE 4: The user supplied diagnostics field is encoded according to the user specification, subject to the maximum length of the cause information element. The coding of user supplied diagnostics should be made in such a way that it does not conflict with the coding described in note 9 below.
- NOTE 5: The new destination is formatted as the called party BCD number information element, including information element identifier.

- NOTE 6: Locking and non-locking shift procedures described in sub-clauses 10.5.4.2 and 3 are applied. In principle, information element identifiers are ordered in the same order as the information elements in the received message.
- NOTE 7: When only the locking shift information element is included and no information element identifier follows, it means that the codeset in the locking shift itself is not implemented.
- NOTE 8: The timer number is coded in IA5 characters, e.g., T308 is coded as "3" "0" "8". The following coding is used in each octet:

bit 8 : spare "0"

bits 7-1 : IA5 character

Octet 5 carries "3", octet 5a carries "0", etc.

NOTE 9: The following coding is used for octet 5:

bit 8 : 1


- bits 7-3 : 00000
- bits 2-1 : condition as follows:
  - 00 unknown
  - 01 permanent
  - 10 transient

### 10.5.4.11a CLIR suppression

The CLIR suppression information element may be sent by the mobile station to the network in the SETUP message. The use is defined in 3GPP TS 04.81.

The CLIR suppression information element is coded as shown in figure 10.5.96/3GPP TS 04.08.

The CLIR suppression is a type 2 information element.




#### Figure 10.5.96/3GPP TS 04.08: CLIR suppression information element

## 10.5.4.11b CLIR invocation

The CLIR invocation information element may be sent by the mobile station to the network in the SETUP message. The use is defined in 3GPP TS 04.81.

The CLIR invocation information element is coded as shown in figure 10.5.97/3GPP TS 04.08.

The CLIR invocation is a type 2 information element.



## Figure 10.5.97/3GPP TS 04.08: CLIR invocation information element

#### 10.5.4.12 Congestion level

The purpose of the congestion level information element is to describe the congestion status of the call.

The congestion level information element is coded as shown in figure 10.5.98/3GPP TS 04.08 and table 10.5.124/3GPP TS 04.08.

The congestion level is a type 1 information element.

Figure 10.5.98/3GPP TS 04.08: Congestion level information element

Table 10.5.124/3GPP TS 04.08: Congestion level information element

+	+
	Congestion level (octet 1)
	bits
	4 3 2 1
	0 0 0 0 receiver ready
	1 1 1 1 receiver not ready
	-
	All other values are reserved.
÷	+

## 10.5.4.13 Connected number

The purpose of the connected number information element is to identify the connected party of a call.

The connected number information element is coded as shown in figure 10.5.99/3GPP TS 04.08

The connected number is a type 4 information element with a minimum length of 3 octets and a maximum length of 14 octets.

_	8	7	б	5	4	3	2	1	±
			Co	nnecte	d numb	er IEl			octet 1
		Ler	ngth of	conne	cted n	umber	conte	nts	octet 2
	0/1 ext	Tyr	pe of n	umber			er pl ifica		octet 3 note 1)
	1 ext		sentati licator		0 Spare	0		reening dicator	octet 3a* note 1)
	Nu	mber	digit	2		Number	digi	t 1	octet 4* note 1)
	Nu	mber	digit	4		Number	digi	t 3	octet 5* note 1)
1	n	ote 2	2)						+ :
									1 C C C C C C C C C C C C C C C C C C C

#### Figure 10.5.99/3GPP TS 04.08

The contents of octets 3,4,5, etc. ... are coded as shown in table 10.5.118/3GPP TS 04.08. The coding of octet 3a is defined in table 10.5.120/3GPP TS 04.08.


If the connected number contains an odd number of digits, bits 5 to 8 of the last octet shall be filled with the end mark coded as "1111".

## 10.5.4.14 Connected subaddress

The purpose of the connected subaddress information element is to identify a subaddress associated with the connected party of a call.

The connected subaddress information element is coded as shown in figure 10.5.100/3GPP TS 04.08

The connected subaddress is a type 4 information element with a minimum length of 2 octets and a maximum length of 23 octets.



### Figure 10.5.100/3GPP TS 04.08

The coding for Type of subaddress, odd/even indicator, and subaddress information is in table 10.5.119/3GPP TS 04.08.

## 10.5.4.15 Facility

The purpose of the facility information element is to transport supplementary service related information. Within the scope of 3GPP TS 04.08 the content of the Facility information field is an array of octets. The usage of this transportation mechanism is defined in 3GPP TS 04.80.

The facility information element is coded as shown in figure 10.5.101/3GPP TS 04.08

The facility is a type 4 information element with a minimum length of 2 octets. No upper length limit is specified except for that given by the maximum number of octets in a L3 message (see 3GPP TS 04.06).




Figure 10.5.101/3GPP TS 04.08

## 10.5.4.16 High layer compatibility

The purpose of the high layer compatibility information element is to provide a means which should be used by the remote user for compatibility checking. See annex B.

The high layer compatibility information element is coded as shown in figure 10.5.102/3GPP TS 04.08 and table 10.5.125/3GPP TS 04.08.

The high layer compatibility is a type 4 information element with a minimum length of 2 octets and a maximum length of 5 octets.

NOTE: The high layer compatibility information element is transported transparently by a PLMN between a call originating entity (e.g. a calling user) and the addressed entity (e.g. a remote user or a high layer function network node addressed by the call originating entity). However, if explicitly requested by the user (at subscription time), a network which provides some capabilities to realize teleservices may interpret this information to provide a particular service.

	8	7 6	5	4	3	2	1		
	+	High	layer (	compati	bility	/ IEI		octet	1
	Lei	ngth of high	layer	compat	ibilit	cy cont	ents	octet	2
	1 ext	coding standard	inte	erpreta	tion	presen method protoc profil	of ol	octet	3*
	0/1 ext	High layer o	charact	teristi	cs ide	entific	ation	octet	4*
	1 ext	Extended l	nigh la dentif:	ayer ch ication	aracte	eristic	s	octet 4 (note)	
-								÷	



If the value part of the IE is empty, the IE indicates "not applicable".

NOTE: Octet 4a may be present e.g. when octet 4 indicates Maintenance or Management.

Table 10.5.125/3GPP TS 04.08: High layer compatibility information element

Coding standard (octet 3) see ITU-T Recommendation Q.931. Interpretation (octet 3) see ITU-T Recommendation Q.931. Presentation method of protocol profile (octet 3) see ITU-T Recommendation Q.931. High layer characteristics identification (octet 4) see ITU-T Recommendation Q.931. Extended high layer characteristics identification (octet 4a) see ITU-T Recommendation Q.931.

### 10.5.4.16.1 Static conditions for the high layer compatibility IE contents

Either the value part of the IE is empty, or it contains at least octet 3 and 4.

## 10.5.4.17 Keypad facility

The purpose of the keypad facility information element is to convey IA5 characters, e.g. entered by means of a terminal keypad. (Note).

The keypad facility information element is coded as shown in figure 10.5.103/3GPP TS 04.08.

The keypad facility is a type 3 information element with 2 octets length.

	8	7	б	5	4	3	2	1		
			Ke	eypad fa	acilit	y IEI			octet	1
_	Spare 0	Кеур	ad in:	Eormatic	on (IA	15 char	acter	)	octet	2

Figure 10.5.103/3GPP TS 04.08: Keypad facility information element

NOTE: In the GSM system this information element is only used to transfer one DTMF digit (0, 1, ..., 9, A, B, C, D, \*, #) as one IA5 character.

## 10.5.4.18 Low layer compatibility

The purpose of the low layer compatibility information element is to provide a means which should be used for compatibility checking by an addressed entity (e.g., a remote user or an interworking unit or a high layer function network node addressed by the calling user). The low layer compatibility information element is transferred transparently by a PLMN between the call originating entity (e.g. the calling user) and the addressed entity.

Except for the information element identifier, the low layer compatibility information element is coded as in ETS 300 102-1.

The low layer compatibility is a type 4 information element with a minimum length of 2 octets and a maximum length of 15 octets.

	8	7	6	5	4	3	2	1		
Ī			Low lay	er cor	mpatibi	ility 1	EI		octet	1
Ţ	Lengt	h of	the low	layeı	r compa	atibili	lty con	tents	octet	2
1			follow	ing of	ntota a	are cor			octet	3*
			describ						:	
									:	
+								+	•	

#### Figure 10.5.104/3GPP TS 04.08: Low layer compatibility information element

If the value part of the IE is empty, the IE indicates "not applicable".

### 10.5.4.19 More data

The more data information element is sent by the mobile station to the network or to the network to the mobile station in a USER INFORMATION message. The presence of the more data information element indicates to the destination remote user/mobile station that another USER INFORMATION message will follow containing information belonging to the same block.

The use of the more data information element is not supervised by the network.

The more data information element is coded as shown in figure 10.5.105/3GPP TS 04.08.

The more data is a type 2 information element.

<b>.</b>	8	7	б	5	4	3	2	1	L
				More d	lata IE	:I			octet 1

## Figure 10.5.105/3GPP TS 04.08: More data information element

## 10.5.4.20 Notification indicator

The purpose of the notification indicator information element is to indicate information pertaining to a call.

The notification indicator element is coded as shown in figure 10.5.106/3GPP TS 04.08 and table 10.5.126/3GPP TS 04.08.

The notification indicator is a type 3 information element with 2 octets length.

	8	7	6	5	4	3	2	1		
Ţ			Notifi	.catior	n indio	cator 1	LEI		octet	1
+	1 ext		Not	ificat	cion de	escript	cion		octet	2

### Figure 10.5.106/3GPP TS 04.08: Notification indicator information element

Table 10.5.126/3GPP TS 04.08: Notification indicator information element

7	ts 6		4	3	2	1	
0	0	0	0	0	0	0	User suspended
							User resumed
0	0	0	0	0	1	0	Bearer change

## 10.5.4.21 Progress indicator

The purpose of the progress indicator information element is to describe an event which has occurred during the life of a call.

The progress indicator information element is coded as shown in figure 10.5.107/3GPP TS 04.08 and table 10.5.127/3GPP TS 04.08.

The progress indicator is a type 4 information element with a length of 4 octets.




Figure 10.5.107/3GPP TS 04.08: Progress indicator information element

Table 10.5.127/3GPP TS 04.08: Progress indicator information element

-----+ Coding standard (octet 3) Bits 76 0 0 Standardized coding, as described in ITU-T Rec. 0.931 0 1 Reserved for other international standards 1 0 National standard 1 1 Standard defined for the GSMBPLMNS as described below Coding standards other than "1 1 - Standard defined for the GSMBPLMNS" shall not be used if the progress description can be represented with the GSMBstandardized coding. The mobile station or network need not support any other coding standard than "1 1 - Standard defined for the GSMs  $\,$ PLMNS". If a progress indicator IE indicating a coding standard not supported by the receiver is received, progress description "Unspecific" shall be assumed. Location (octet 3) Bits 4 3 2 1 0 0 0 0 User 0 0 0 1 Private network serving the local user 0 0 1 0 Public network serving the local user 0 1 0 0 Public network serving the remote user 0 1 0 1 Private network serving the remote user 1 0 1 0 Network beyond interworking point All other values are reserved. Depending on the location of the users, the local Note: public network and remote public network may be the same network. Progress description (octet 4) Bits 7 6 5 4 3 2 1 No. 1. Call is not end-to-end PLMN/ISDN, 0 0 0 0 0 0 1 further call progress information may be available in-band 0 0 0 0 1 0 2. Destination address in non-PLMN/ISDN 0 0 0 0 1 1 3. Origination address in non-PLMN/ISDN 0 0 0 1 0 0 4. Call has returned to the PLMN/ISDN 0 0 0 1 0 0 0 8. In-band information or appropriate pattern now available 0 1 0 0 0 0 0 32. Call is end 1 0 0 0 0 0 64. Queueing All other values Unspecific Call is end-to-end PLMN/ISDN \_\_\_\_\_

## 10.5.4.21a Recall type \$(CCBS)\$

The purpose of the recall type information element is to describe the reason for the recall.

The recall type information element is coded as shown in Figure 10.5.108/3GPP TS 04.08 and Table 10.5.128/3GPP TS 04.08.

The recall type is a type 3 information element with 2 octets length.




Figure 10.5.108/3GPP TS 04.08: Recall type information element

#### Table 10.5.128/3GPP TS 04.08: Recall type information element

```
recall type (octet 2, bits 1 to 4)
Bits
3 2 1
0 0 0 - CCBS
0 0 1 }
to }- shall be treated as CCBS (intended for other
1 1 0 } similar types of Recall)
1 1 1 - reserved
```

## 10.5.4.21b Redirecting party BCD number

The purpose of the redirecting party BCD number information element is to identify the redirecting party.

The redirecting party BCD number information element is coded as shown in Figure 10.88a.

The redirecting party BCD number is a type 4 information element. In the network to mobile station direction it has a minimum length of 3 octets and a maximum length of 19 octets.

8	7	6	5	4	3	2	1				
		Redir	recting	party B	CD numbe	r IEI		octet 1			
I	Length of r	edire pe of	cting pa	arty BCI		contents	8	octet 2 octet 3			
ext		mber				lication		(note 1)			
1 ext	presenta indicat		0	0 spare	0	Scree indic		octet 3a* (note 1)			
	Number dig	git 2				octet 4* (note 1)					
	Number digit 4 Number digit 3										
				l				:			
	Note 2)										

NOTE 1: The contents of octets 3, 4, etc. are coded as shown in Table 10.81. The coding of octet 3a is defined in table 10.83.

NOTE 2: If the redirecting party BCD number contains an odd number of digits, bits 5 to 8 of the last octet shall be filled with an end mark coded as "1111".


#### Figure 10.88a/3GPP TS 04.08: Redirecting party BCD number information element

### 10.5.4.21c Redirecting party subaddress

The purpose of the Redirecting party subaddress is to identify a subaddress associated with the redirecting party. For the definition of a subaddress see Rec. ITU-T I.330.

The Redirecting party subaddress information element is coded as shown in Figure 10.88b and Table 10.84.

The Redirecting party subaddress is a type 4 information element with a minimum length of 2 octets and a maximum length of 23 octets.



#### Figure 10.88b/3GPP TS 04.08: Redirecting party subaddress information element

## 10.5.4.22 Repeat indicator

The purpose of the repeat indicator information element is to indicate how the associated repeated information elements shall be interpreted, when included in a message. The repeat indicator information element is included immediately before the first occurrence of the associated information element which will be repeated in a message. "Mode 1" refers to the first occurrence of that information element, "mode 2" refers to the second occurrence of that information element in the same message.

The repeat indicator information element is coded as shown in figure 10.5.109/3GPP TS 04.08 and table 10.5.129/3GPP TS 04.08.

The repeat indicator is a type 1 information element.

8 7 6 5 4 3 2 1 repeat indicator repeat indication octet 1 IEI

### Figure 10.5.109/3GPP TS 04.08: Repeat indicator information element

Table 10.5.129/3GPP TS 04.08: Repeat indicator information element

Repeat : Bits 4 3 2 1	indication (octet 1)
0 0 0 1	Circular for successive selection "mode 1 alternate mode 2" Sequential for successive selection
All othe	"mode 1 and then mode 2" er values are reserved.
+	+

## 10.5.4.22a Reverse call setup direction

This information element may be included in a MODIFY and MODIFY COMPLETE message to indicate that the direction of the data call to which the MODIFY message relates is opposite to the call setup direction.

The reverse call setup direction information element is coded as shown in figure 10.5.110/3GPP TS 04.08.

The reverse call setup direction is a type 2 information element

. 8	7	б	5	4 3		2	1		
+	reverse	call	setup	direction	n	IEI		octet	1


#### Figure 10.5.110/3GPP TS 04.08: Reverse call setup direction information element

## 10.5.4.22b SETUP Container \$(CCBS)\$

This information element contains the contents of a SETUP message (Mobile Station to Network). This means that the Call Control protocol discriminator IE, the Transaction Identifier IE and the Setup message type IE are not included.

The SETUP Container information element is coded as shown in figure 10.5.111/3GPP TS 04.08

The SETUP Container is a type 4 information. No upper length limit is specified except for that given by the maximum number of octets in a L3 message (see 3GPP TS 04.06).




#### Figure 10.5.111/3GPP TS 04.08: Octet j (j = 3, 4 ... n) is the unchanged octet j of the SETUP message

## 10.5.4.23 Signal

The purpose of the signal information element is to allow the network to convey information to a user regarding tones and alerting signals (see sub-clauses 5.2.2.3.2 and 7.3.3.).

The signal information element is coded as shown in figure 10.5.112/3GPP TS 04.08 and table 10.5.130/3GPP TS 04.08.

The signal is a type 3 information element with 2 octets length.



### Figure 10.5.112/3GPP TS 04.08: Signal information element

#### Table 10.5.130/3GPP TS 04.08: Signal information element


```
_____
Signal value (octet 2)
Bits
8 7 6 5
         4 3 2 1
0
  0
    0 0
          0 0 0 0
                      dial tone on
0
  0
    0
      0
          0 0 0 1
                      ring back tone on
                     intercept tone on
  0
0
0
0
0
    0
      0
         0 0 1 0
0
0
      0
0
                      network congestion tone on
            \begin{array}{ccc}1&0&0\\1&0&1\end{array}
                     busy tone on
confirm tone on
    0
      0
          0
    0
      0
          0
            1
              1 0
                      answer tone on
  Ō
         0 1
                      call waiting tone on
    0 0
              1 1
  0 0 0
                      off-hook warning tone on
         1
          1
            1
              1
                1
                      tones off
 1
    0 0
          1
            1 1 1
                      alerting off
All other values are reserved.
```

## 10.5.4.24 SS Version Indicator


The purpose of the SS version indicator information element is to aid the decoding of the Facility information element as described in 3GPP TS 04.10. Within the scope of 3GPP TS 04.08 the contents of the SS Version information field is an array of one or more octets. The usage of the SS version information field is defined in 3GPP TS 04.80.

The SS version indicator information element is coded as shown in figure 10.5.113/3GPP TS 04.08

The SS version indicator is a type 4 information element with a minimum length of 2 octets. No upper length limit is specified except for that given by the maximum number of octets in a L3 message (see 3GPP TS 04.06).



#### Figure 10.5.113/3GPP TS 04.08




### 10.5.4.25 User-user

The purpose of the user-user information element is to convey information between the mobile station and the remote ISDN user.


The user-user information element is coded as shown in figure 10.5.114/3GPP TS 04.08 and table 10.5.131/ 3GPP TS 04.08. There are no restrictions on the content of the user-user information field.

The user-user is a type 4 information element with a minimum length of 3 octets and a maximum length of either 35 or 131 octets. In the SETUP message the user-user information element has a maximum size of 35 octets in a GSM PLMN. In the USER INFORMATION, ALERTING, CONNECT, DISCONNECT, PROGRESS, RELEASE and RELEASE COMPLETE messages the user-user information element has a maximum size of 131 octets in a GSM PLMN.

In other networks than GSM PLMNs the maximum size of the user-user information element is 35 or 131 octets in the messages mentioned above. The evolution to a single maximum value is the long term objective; the exact maximum value is the subject of further study.



NOTE: The user-user information element is transported transparently through a GSM PLMN.



User-user protocol discriminator (octet 3) Bits 7 543 8 6 0 0 0 0 0 0 0 0 User specific protocol (Note 1) OSI high layer protocols X.244 (Note 2) 0 0 0 0000011 Reserved for system management convergence function IA5 characters (Note 3) 0 0 0 0 0 1 0 0 Rec.V.120 rate adaption Q.931 (I.451) user-network call control 0 0 0 0 0 1 1 1 0 0 0 0 1 0 0 0 messages 0 0 0 1 0 0 0 0 Reserved for other network layer or layer 3 protocols including Rec.X.25 (Note 4) through 0 0 1 1 1 1 1 1 0 1 0 0 0 0 0 0through National use 0 1 0 0 1 1 1 1  $0 \ 1 \ 0 \ 1 \ 0 \ 0 \ 0 \ 0$ Reserved for other network layer or layer 3 protocols including Rec.X.25 (Note 4) through 1 1 1 1 1 1 1 0 All other values are reserved Note 1: The user information is structured according to user needs. Note 2: The user information is structured according to Rec.X.244 which specifies the structure of X.25 call user data. Note 3: The user information consists of IA5 characters. Note 4: These values are reserved to discriminate these protocol discriminators from the first octet of a protocol discriminators from the first octet X.25 packet including general format identifier.

#### Table 10.5.131/3GPP TS 04.08: User-user information element

### 10.5.4.26 Alerting Pattern \$(NIA)\$

The purpose of the Alerting Pattern information element is to allow the network to convey information related to the alert to be used by the MS (see 3GPP TS 02.07).

The Alerting Pattern information element is coded as shown in figure 10.5.115/3GPP TS 04.08 and table 10.5.132/3GPP TS 04.08.

The Alerting Pattern IE is a type 4 information element with 3 octet length.

	8	7	б	5	4	3	2	1		
			Al	erting	Patter	n IEI			octet	1
Ì		lengtl	n of a	alertin	g patt	cern co	ontent		octet	2
+	0	0 spare	0	0	A]	lerting val	g Patte lue	ern	octet	3

#### Figure 10.5.115/3GPP TS 04.08: Alerting Pattern information element

Table 10.5.132/3GPP TS 04.08: Alerting Pattern information element

```
Alerting Pattern value (octet 3)
Bits
4 3 2 1
        alerting pattern 1
alerting pattern 2
0 0 0 0
0 0 0 1
0 0 1 0
          alerting pattern 3
          alerting pattern 5
0 1 0 0
          alerting pattern 6
alerting pattern 7
0
 1 0 1
0
 1 1 0
0
 1 1 1
           alerting pattern 8
1 0 0 0
          alerting pattern 9
all other values are reserved
_____
```

Alerting pattern 1, 2 and 3 indicate alerting levels 0, 1 and 2.

Alerting pattern 5 to 9 indicate alerting categories 1 to 5

### 10.5.4.27 Allowed actions \$(CCBS)\$

The purpose of the *Allowed actions* information element is to provide the mobile station with information about further allowed procedures.

The *Allowed actions* information element is coded as shown in figure 10.5.116/3GPP TS 04.08 and table 10.5.133/3GPP TS 04.08

The Allowed actions is a type 4 information element with 3 octets length






Table 10.5.133/3GPP TS 04.08: Allowed actions information element

```
CCBS activation (octet 3)
Bit
8
0 Activation of CCBS not possible
1 Activation of CCBS possible
```

### 10.5.5 GPRS mobility management information elements

#### 10.5.5.1 Attach result

The purpose of the attach result information element is to specify the result of a GPRS attach procedure.

The attach result is a type 1 information element.

#### 3GPP TS 04.08 version 7.21.0 Release 1998

542

The *attach result* information element is coded as shown in figure 10.5.117/3GPP TS 04.08 and table 10.5.134/3GPP TS 04.08.




Figure 10.5.117/3GPP TS 04.08: Attach result information element

Table 10.5.134/3GPP TS 04.08: Attach result information element

```
Result of attach (octet 1)
Bits
3 2 1
0 0 1 GPRS only attached
0 1 1 Combined GPRS/IMSI attached
All other values are reserved.
```

### 10.5.5.2 Attach type

The purpose of the *attach type* information element is to indicate the type of the requested attach, i.e. whether the MS wants to perform a GPRS or combined GPRS attach.

The attach type is a type 1 information element.

The *attach type* information element is coded as shown in figure 10.5.118/3GPP TS 04.08 and table 10.5.135/3GPP TS 04.08.




Figure 10.5.118/3GPP TS 04.08: Attach type information element

Table 10.5.135/3GPP TS 04.08: Attach type information element

Type of attach (octet 1) Bits 3 2 1 0 0 1 GPRS attach 0 1 0 GPRS attach while IMSI attached 0 1 1 Combined GPRS/IMSI attach All other values are interpreted as GPRS attach in this version of the protocol.

### 10.5.5.3 Ciphering algorithm

The purpose of the ciphering algorithm information element is to specify which ciphering algorithm shall be used.

The ciphering algorithm is a type 1 information element.

The *ciphering algorithm* information element is coded as shown in figure 10.5.119/3GPP TS 04.08 and table 10.5.136/3GPP TS 04.08.




Figure 10.5.119/3GPP TS 04.08: Ciphering algorithm information element

Table 10.5.136/3GPP TS 04.08: Ciphering algorithm information element

Type o	of algorithm (octet 1)
Bits	
321	
000	ciphering not used
001	GPRS Encryption Algorithm GEA/1
010	GPRS Encryption Algorithm GEA/2
011	GPRS Encryption Algorithm GEA/3
100	GPRS Encryption Algorithm GEA/4
101	GPRS Encryption Algorithm GEA/5
110	GPRS Encryption Algorithm GEA/6
111	GPRS Encryption Algorithm GEA/7

In this version of the protocol the network shall not allocate values other than 000 or 001 to the MS.

### 10.5.5.4 [Spare]TMSI status

The purpose of the TMSI status information element is to indicate whether a valid TMSI is available in the MS or not.

The TMSI status is a type 1 information element.

The *TMSI status* information element is coded as shown in figure 10.5.120/3GPP TS 04.08 and table 10.5.137/3GPP TS 04.08.

8	7	6	5	4	3	2	1	
	TMSI ]	status IEI		0	0 0 spare		TMSI flag	octet 1

Figure 10.5.120/3GPP TS 04.08: TMSI status information element

Table 10.5.137/3GPP TS 04.08: TMSI status information element

```
TMSI flag (octet 1)
Bit
1
0 no valid TMSI available
1 valid TMSI available
```

### 10.5.5.5 Detach type

The purpose of the *detach type* information element is to indicate which type of detach is requested by the MS. In the network to MS direction the *detach type* information element is used to indicate the reason why a detach request is sent.

The *detach type* is a type 1 information element.

The *detach type* information element is coded as shown in figure 10.5.121/3GPP TS 04.08 and table 10.5.138/3GPP TS 04.08.

8	7	б	5	4	3	2	1	
	Detac	ch type IEI		Power off	Туре	of de	etach	octet 1

Figure 10.5.121/3GPP TS 04.08: Detach type information element

Table 10.5.138/3GPP TS 04.08: Detach type information element

```
Type of detach
                      (octet 1)
In the MS to network direction:
Bits
\begin{array}{ccc} 3 & 2 & 1 \\ 0 & 0 & 1 \end{array}
           GPRS detach
0 1 0
           IMSI detach
0 1 1
           Combined GPRS/IMSI detach
All other values are interpreted as Combined GPRS/IMSI detach by this version
of the protocol.
In the network to MS direction:
Bits
\begin{array}{ccc} 3 & 2 & 1 \\ 0 & 0 & 1 \end{array}
           re-attach required
re-attach not required
IMSI detach (after VLR failure)
All other values are interpreted as re-
attach not required by this version of
the protocol.
Power off (octet 1)
In the MS to network direction:
Bit
4
0 normal detach
1 power switched off
In the network to MS direction the Power
off bit shall be spare and set to zero.
```

#### 10.5.5.6 DRX parameter

The purpose of the *DRX parameter* information element is to indicate whether the MS uses DRX mode or not. The *DRX parameter* is a type 3 information element with a length of 3 octets.

The value part of a DRX parameter information element is coded as shown in table 10.5.139/3GPP TS 04.08.

8	7	6	5	4	3	2	1	
		DRX	parame	eter I	EI			octet 1
		SPLIT	PG C	YCLE C	ODE			octet 2
		0 0 0 pare		SPLIT on CCCH		n-DRX imer		octet 3

Figure 10.5.122/3GPP TS 04.08: DRX parameter information element

SPLIT PG CYCLE CODE, octet 2 The octet contains the binary coded value of the SPLIT PG CYCLE CODE. The SPLIT PG CYCLE value is derived from the SPLIT PG CYCLE CODE as follows:
SPLIT PG CYCLE CODESPLIT PG CYCLE value0704 (equivalent to no DRX)1 to 641 to 64, respectively
65 71
66 72
67 74
68 75
69 77
70 79
71 80
72 83
73 86
74 88
75 90 76 92
76         92           77         96
78 101
79 103
80 107
81 112
82 116
83 118
84 128
85 141
86         144           87         150
88 160
89 171
90 176
91 192
92 214
93 224
94 235
95         256           96         288
90 288 97 320
98 352
All other values are reserved and shall be interpreted as 1 by this version of the protocol.
SPLIT on CCCH, octet 3 (bit 4)
0 Split pg cycle on CCCH is not supported by the mobile station 1 Split pg cycle on CCCH is supported by the mobile station
non-DRX timer, octet 3 bit 3 2 1
0 0 0 no non-DRX mode after transfer state 0 0 1 max. 1 sec non-DRX mode after transfer state 0 1 0 max. 2 sec non-DRX mode after transfer state 0 1 1 max. 4 sec non-DRX mode after transfer state 1 0 0 max. 8 sec non-DRX mode after transfer state 1 0 1 max. 16 sec non-DRX mode after transfer state
1 1 0 max. 32 sec non-DRX mode after transfer state 1 1 1 max. 64 sec non-DRX mode after transfer state
Bits 8 to 5 of octet 3 are spare and shall be coded all zeros.

Table 10.5.139/3GPP TS 04.08: DRX parameter information element

#### 10.5.5.7 Force to standby

The purpose of the *force to standby* information element is to force the MS to stop the READY timer in order to prevent the MS to perform cell updates.

The *force to standby* is a type 1 information element.

The *force to standby* information element is coded as shown in figure 10.5.123/3GPP TS 04.08 and table 10.5.140/3GPP TS 04.08.

 8	7	6	5	4	3	2	1	_
Fc	orce t	to standby IEI		0 spare	Fo: stand	rce t lby va	o lue	octet 1




Table 10.5.140/3GPP TS 04.08: Force to standby information element

Force to standby value (octet 1) Bits 3 2 1 0 0 0 Force to standby not indicated 0 0 1 Force to standby indicated All other values are interpreted as force to standby not indicated by this version of the protocol.

#### 10.5.5.8 P-TMSI signature

The purpose of the *P-TMSI signature* information element is to identify a GMM context of an MS.

The *P-TMSI signature* is a type 3 information element with 4 octets length.

The *P-TMSI signature* information element is coded as shown in figure 10.5.124/3GPP TS 04.08 and table 10.5.141/3GPP TS 04.08.






Table 10.5.141/3GPP TS 04.08: *P-TMSI signature* information element

P-TMSI signature value Octets 2, 3 and 4 contain the binary representation of the P-TMSI signature. Bit 1 of octet 4 is the least significant bit and bit 8 of octet 2 is the most significant bit.

#### 10.5.5.9 Identity type 2

The purpose of the *identity type 2* information element is to specify which identity is requested.

The *identity type 2* is a type 1 information element.

The *identity type 2* information element is coded as shown in figure 10.5.125/3GPP TS 04.08 and table 10.5.142/3GPP TS 04.08.

Identity type 20Type ofIEIspareidentity	octet 1

Figure 10.5.125/3GPP TS 04.08: Identity type 2 information element

Table 10.5.142/3GPP TS 04.08: Identity type 2 information element

```
Type of identity (octet 1)
Bits
3 2 1
0 0 1 IMSI
0 1 0 IMEI
0 1 1 IMEISV
1 0 0 TMSI
All other values are interpreted as
IMSI by this version of the protocol.
```

### 10.5.5.10 IMEISV request

The purpose of the *IMEISV request* information element is to indicate that the IMEISV shall be included by the MS in the authentication and ciphering response message.

The IMEISV request is a type 1 information element.

The *IMEISV request* information element is coded as shown in figure 10.5.126/3GPP TS 04.08 and table 10.5.143/3GPP TS 04.08.




Figure 10.5.126/3GPP TS 04.08: IMEISV request information element

Table 10.5.143/3GPP TS 04.08: IMEISV request information element

```
IMEISV request value (octet 1)
Bits
3 2 1
0 0 0 IMEISV not requested
0 0 1 IMEISV requested
All other values are interpreted as
IMEISV not requested by this version
of the protocol.
```

#### 10.5.5.11 Receive N-PDU Numbers list

The purpose of the *Receive N-PDU Numbers list* information element is to specify the current SNDCP Receive N-PDU Number values.

The Receive N-PDU Number list is a type 4 information element with a length of 4 to 19 octets.

The value part of a *Receive N-PDU Number list* information element is coded as shown in figure 10.5.127/3GPP TS 04.08 and table 10.5.144/3GPP TS 04.08.

8	7	б	5	4	3	2	1		
	Red	ceive N-	PDU Nu	mber	list II	ΞI		octet	1
	Lengtl	n of Rec	eive N conter		Number	list		octet	2
								octet	3
	I	Receive 1	N-PDU	Numbe	er-list			octet	4
								octet	n*

Figure 10.5.127/3GPP TS 04.08: Receive N-PDU Number list information element

#### Table 10.5.144/3GPP TS 04.08: Receive N-PDU Number list information element

**Receive N-PDU Number -list value ::=** { < Receive N-PDU Number -list > < Padding bits> }; < Receive N-PDU Number-list > ::= < sapi : bit-string(4) > < Receive N-PDU Number-value : bit-string(8) > { < Receive N-PDU Number-list> | < null > }; < nsapi > ::= { 0101 }; |-- NSAPI 5 { 0110 }; | -- NSAPI 6 { 0111 }; | -- NSAPI 7 { 1000 }; | -- NSAPI 8 { 1001 }; | -- NSAPI 9 { 1010 }; | -- NSAPI 10 { 1011 }; | -- NSAPI 11 { 1100 }; | -- NSAPI 12 { 1101 }; | -- NSAPI 13 { 1110 }; | -- NSAPI 14 { 1111 }; -- NSAPI 15 < **Receive N-PDU Number-value** > ::=  $\{ 0 | 1 \} (8) ;$ -- Contains the binary coded representation of the receive N-PDU Number value. -- The first bit in transmission order is the most significant bit. <Padding bits> ::= null | 0000;

### 10.5.5.12 MS network capability

The purpose of the *MS network capability* information element is to provide the network with information concerning aspects of the mobile station related to GPRS. The contents might affect the manner in which the network handles the operation of the mobile station. The *MS network capability* information indicates general mobile station characteristics and it shall therefore, except for fields explicitly indicated, be independent of the frequency band of the channel it is sent on.

The MS network capability is a type 4 information element with a minimum of 3 and a maximum of 4 octets length.

Octet 4 shall be included by the MS, if it supports in addition to GEA/1 at least one of the GPRS Encryption Algorithm GEA/2 to GEA/7. In this version of the protocol the network shall ignore octet 4.

The value part of a *MS network capability* information element is coded as shown in figure 10.5.128/3GPP TS 04.08 and table 10.5.145/3GPP TS 04.08.




Figure 10.5.128/3GPP TS 04.08: MS network capability information element

Table 10.5.145/3GPP TS 04.08: MS network capability information element

<ms capability="" network="" part="" value=""> ::=</ms>
<pre><gea1 bit=""> <gea1 bit=""> <gea1< td=""></gea1<></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></gea1></pre>
< <b>GEA1 bit&gt;</b> ::= < <b>GEA/1</b> :bit>;
<extended bits="" gea=""> ::= <gea 2:bit=""><gea 3:bit="">&lt; GEA/4:bit &gt;&lt; GEA/5:bit &gt;&lt; GEA/6:bit &gt;<gea 7:bit="">;</gea></gea></gea></extended>
<spare bits=""> ::= null   {<spare bit=""> &lt; Spare bits &gt;};</spare></spare>
SS Screening Indicator 0 0 defined in 3GPP TS 04.80 0 1 defined in 3GPP TS 04.80 1 0 defined in 3GPP TS 04.80 1 1 defined in 3GPP TS 04.80
<ul> <li>SM capabilities via dedicated channels</li> <li>0 Mobile station does not support mobile terminated point to point SMS via dedicated signalling channels</li> <li>1 Mobile station supports mobile terminated point to point SMS via dedicated signalling channels</li> </ul>
<ul> <li>SM capabilities via GPRS channels</li> <li>0 Mobile station does not support mobile terminated point to point SMS via GPRS packet data channels</li> <li>1 Mobile station supports mobile terminated point to point SMS via GPRS packet data channels</li> </ul>
<ul> <li>UCS2 support</li> <li>This information field indicates the likely treatment by the mobile station of UCS2 encoded character strings.</li> <li>0 the ME has a preference for the default alphabet (defined in 3GPP TS 03.38) over UCS2.</li> </ul>

1 the ME has no preference between the use of the default alphabet and the

use of UCS2.
GPRS Encryption Algorithm GEA/1
0 encryption algorithm <b>GEA/1</b> not available 1 encryption algorithm <b>GEA/1</b> available
SoLSA Capability 0 The ME does not support SoLSA.
1 The ME supports SoLSA.
GPRS Encryption Algorithm GEA/2
0 encryption algorithm <b>GEA/2</b> not available
1 encryption algorithm <b>GEA/2</b> available
GPRS Encryption Algorithm GEA/3
0 encryption algorithm <b>GEA/3</b> not available
1 encryption algorithm <b>GEA/3</b> available
GPRS Encryption Algorithm GEA/4
0 encryption algorithm GEA/4 not available
1 encryption algorithm <b>GEA/4</b> available
CDDS Enormation Algorithm CEA/5
<b>GPRS Encryption Algorithm GEA/5</b> 0 encryption algorithm <b>GEA/5</b> not available
1 encryption algorithm GEA/5 available
GPRS Encryption Algorithm GEA/6
0 encryption algorithm GEA/6 not available
1 encryption algorithm <b>GEA/6</b> available
GPRS Encryption Algorithm GEA/7
0 encryption algorithm GEA/7 not available

1 encryption algorithm GEA/7 available

### 10.5.5.12a MS Radio Access capability

The purpose of the *MS RA capability* information element is to provide the radio part of the network with information concerning radio aspects of the mobile station. The contents might affect the manner in which the network handles the operation of the mobile station.

The *MS RA capability* is a type 4 information element, with a minimum length of 6 octets and a maximum length of 14 octets.

The value part of a MS RA capability information element is coded a shown table 10.5.146/3GPP TS 04.08.

- SEMANTIC RULE : Among the three Access Type Technologies GSM 900-P, GSM 900-E and GSM 900-R only one shall be present.
- Error handling : If a received Access Technology Type is unknown to the receiver, it shall ignore all the corresponding fields;
- If within a known Access Technology Type a receiver recognizes an unknown field it shall ignore it.
- See more details about error handling of MS radio access capability in TS 3GPP TS 08.18.
- Due to shared radio frequency channel numbers between 1800 and 1900, the mobile should provide MS Radio Access capability for either 900/1800 band(s) OR 1900 band.

#### Table 10.5.146/3GPP TS 04.08: Mobile Station Radio Access Capability Information Element

```
< MS Radio Access capability IE > ::=
<MS Radio Access capability IEI : 00100100 >
<Length of MS RA capability: <octet>> -- length in octets of MS RA capability value part and spare bits
< MS RA capability value part : < MS RA capability value part struct >>
<spare bits>**; -- may be used for future enhancements
<MS RA capability value part struct >::= --recursive structure allows any number of Access technologies
< Access Technology Type: bit (4) >
< Access capabilities : < Access capabilities struct> >
\{ 0 \mid 1 < MS RA capability value part struct > \};
< Access capabilities struct > ::=
   < Length : bit (7) > -- length in bits of Content and spare bits
   <Access capabilities : <Content>>
   <spare bits>**; -- expands to the indicated length
           -- may be used for future enhancements
< Content > ::=
   < RF Power Capability : bit (3) >
   \{0 \mid 1 < A5 \text{ bits} : < A5 \text{ bits} > \} -- zero means that the same values apply for parameters as in the immediately
preceeding Access capabilities field within this IE
   -- The presence of the A5 bits is mandatory in the 1^{st} Access capabilities struct within this IE.
   <ES IND : bit >
   < PS : bit >
   < VGCS : bit >
   < VBS : bit >
   \{ 0 \mid 1 < Multislot capability : Multislot capability struct > \}; -- zero means that the same values apply for
multislot parameters as in the immediately preceeding Access capabilities field within this IE.
   -- The presence of the Multislot capability struct is mandatory in the 1<sup>st</sup> Access capabilities struct within this IE.
< Multislot capability struct > ::=
   \{ 0 \mid 1 < \mathbf{HSCSD} \text{ multislot class} : bit (5) > \}
   { 0 | 1 < GPRS multislot class : bit (5) > < GPRS Extended Dynamic Allocation Capability : bit > }
   \{ 0 | 1 < SMS_VALUE : bit (4) > < SM_VALUE : bit (4) > \};
<A5 bits> ::= < A5/1 : bit> <A5/2 : bit> <A5/3 : bit> <A5/4 : bit> <A5/5 : bit> <A5/6 : bit> <A5/7 : bit> ; -- bits for
circuit mode ciphering algorithms
```

Continued...

# Table 10.5.146/3GPP TS 04.08 (continued): Mobile Station Radio Access Capability Information Element

	echnology Type
	indicates the access technology type to be associated with the following access capabilities.
Bits 4 3 2 1	
0000	GSM P
0001	GSM E note that GSM E covers GSM P
0010	GSM Rnote that GSM R covers GSM E and GSM P
0011 0100	GSM 1800 GSM 1900
	values are treated as unknown by the receiver.
RF Powe	r Capability
	is coded as radio capability in Classmark 3 for the indicated band: it contains the binary coding of he powe ociated (see 3GPP TS 05.05 paragraph 4.1 output power and paragraph 4.1.1 Mobile Station).
A5/1	
	otion algorithm A5/1 not available otion algorithm A5/1 available
0 encry	otion algorithm A5/2 not available
1 encryp A5/3	ption algorithm A5/2 available
0 encry	otion algorithm A5/3 not available
	otion algorithm A5/3 available
A5/4	otion algorithm A5/4 not available
	otion algorithm A5/4 available
A5/5	
	otion algorithm A5/5 not available
1 encryp A5/6	otion algorithm A5/5 available
0 encry	ption algorithm A5/6 not available
	ption algorithm A5/6 available
A5/7 0 encrvr	otion algorithm A5/7 not available
	otion algorithm A5/7 available
ES IND -	(Controlled early Classmark Sending)
0 "contr	olled early Classmark Sending" option is not implemented
1 "contr	olled early Classmark Sending" option is implemented
	eudo Synchronisation)
	pability not present
1 PS ca	pability present
	Voice Group Call Service)
	CS capability or no notifications wanted
1 VGCS	capability and notifications wanted
VBS - (V	oice Broadcast Service)
0 no VB	S capability or no notifications wanted
1 VBS c	apability and notifications wanted
HSCSD I	Multi Slot Class
	Slot Class field is coded as the binary representation of the multislot class defined in TS 3GPP TS 05.02. to 18, all other values are reserved.
GPRS M	ulti Slot Class
	S Multi Slot Class field is coded as the binary representation of the multislot class defined in TS
3GPP TS	

0 Extended Dynamic Allocation Capability for GPRS is not implemented

Extended Dynamic Allocation Capability for GPRS is implemented

SMS\_VALUE (Switch-Measure-Switch) (4 bit field)

The SMS field indicates the time needed for the mobile station to switch from one radio channel to another, perform a neighbor cell power measurement, and the switch from that radio channel to another radio channel.

Bits

1

4321

0 0 0 0 1/4 timeslot (~144 microseconds)

0 0 0 1 2/4 timeslot (~288 microseconds)

0 0 1 0 3/4 timeslot (~433 microseconds)

1 1 1 1 1 16/4 timeslot (~2307 microseconds)

#### (SM\_VALUE) Switch-Measure (4 bit field)

The SM field indicates the time needed for the mobile station to switch from one radio channel to another and perform a neighbor cell power measurement.

Bits 4 3 2 1 0 0 0 0 1/4 timeslot (~144 microseconds) 0 0 0 1 2/4 timeslot (~288 microseconds) 0 0 1 0 3/4 timeslot (~433 microseconds) ... 1 1 1 1 16/4 timeslot (~2307 microseconds)

### 10.5.5.13 Spare

This is intentionally left spare.

#### 10.5.5.14 GMM cause

The purpose of the GMM cause information element is to indicate the reason why a GMM request from the mobile station is rejected by the network.

The GMM cause information element is coded as shown in figure 10.5.129/3GPP TS 04.08 and table 10.5.147/3GPP TS 04.08.

The GMM cause is a type 3 information element with 2 octets length.




Figure 10.5.129/3GPP TS 04.08: GMM cause information element

Cause value (oct	et 2) ¬
Bits	
87654321	
00000010	IMSI unknown in HLR
00000011	Illegal MS
00000110	Illegal ME
00000111	GPRS services not allowed
00001000	GPRS services and non-GPRS services not allowed
00001001	MS identity cannot be derived by the network
00001010	Implicitly detached
00001011	PLMN not allowed
00001100	Location Area not allowed
00001101	Roaming not allowed in this location area
00001110	GPRS services not allowed in this PLMN
00010000	MSC temporarily not reachable
00010001	Network failure
00010110	Congestion
00110000	to } retry upon entry into a new cell
00111111	
01011111	Semantically incorrect message
01100000	Invalid mandatory information
01100001	Message type non-existent or not implemented
01100010	Message type not compatible with the protocol state
01100011	Information element non-existent or not implemented
01100100	Conditional IE error
01100101	Message not compatible with the protocol state
01101111	Protocol error, unspecified
Any other value r	eceived by the mobile station shall be treated as 0110 1111, 'Protocol error,'
	other value received by the network shall be treated as 0110 1111, 'Protocol
error, unspecified	
	ted reject cause values are defined in annex G.
<u>.</u>	·

#### Table 10.5.147/3GPP TS 04.08: GMM cause information element

### 10.5.5.15 Routing area identification

The purpose of the *routing area identification* information element is to provide an unambiguous identification of routing areas within the area covered by the GSM system.

The *routing area identification* is a type 3 information element with 7 octets length.

The *routing area identification* information element is coded as shown in figure 10.5.130/3GPP TS 04.08 and table 10.5.148/3GPP TS 04.08.

8	7	б	5	4	3	2	1	
	Rou	ting Area	a Ide	entific	ation	IEI		octet 1
	MCC c	ligit 2			MCC di	git 1		octet 2
	MNC c	ligit 3			MCC di	git 3		octet 3
	MNC c	ligit 2			MNC di	git 1		octet 4
			LZ	AC				octet 5
		L	AC c	ont'd				octet 6
			R	AC				octet 7

Figure 10.5.130/3GPP TS 04.08: Routing area identification information element

#### Table 10.5.148/3GPP TS 04.08: Routing area identification information element

MCC, Mobile country code (octet 2 and 3) The MCC field is coded as in ITU-T Rec. E212, Annex A. If the RAI is deleted, the MCC and MNC shall take the value from the deleted RAI. In abnormal cases, the MCC stored in the mobile station can contain elements not in the set {0, 1 ... 9}. In such cases the mobile station should transmit the stored values using full hexadecimal encoding. When receiving such an MCC, the network shall treat the RAI as deleted. MNC, Mobile network code (octet 3 bits 5 to 8, octet 4) The coding of this field is the responsibility of each administration but BCD coding shall be used. The MNC shall consist of 2 or 3 digits. For PCS 1900 for NA, Federal regulation mandates that a 3-digit MNC shall be used. However a network operator may decide to use only two digits in the MNC in the RAI over the radio interface. In this case, bits 5 to 8 of octet 3 shall be coded as "1111". Mobile equipment shall accept RAI coded in such a way. Note 1: In earlier versions of this protocol, the possibility to use a one digit MNC in RAI was provided on the radio interface. However as this was not used this possibility has been deleted. Note 2: In earlier versions of this protocol, bits 5 to 8 of octet 3 were coded as "1111". Mobile equipment compliant with these earlier versions of the protocol may be unable to understand the 3-digit MNC format of the RAI, and therefore unable to attach to a network broadcasting the RAI in this format. In abnormal cases, the MNC stored in the mobile station can have - digit 1 or 2 not in the set {0, 1 ... 9} or - digit 3 not in the set {0, 1 ...9, F} hex. In such cases the mobile station shall transmit the stored values using full hexadecimal encoding. When receiving such an MNC, the network shall treat the RAI as deleted. The same handling shall apply for the network, if a 3-digit MNC is sent by the mobile station to a network using only a 2-digit MNC. LAC, Location area code (octet 5 and 6) In the LAC field bit 8 of octet 5 is the most significant bit and bit 1 of octet 6 the least significant bit. The coding of the location area code is the responsibility of each administration except that two values are used to mark the LAC, and hence the RAI, as deleted. Coding using full hexadecimal representation may be used. The location area code consists of 2 octets. If a RAI has to be deleted then all bits of the location area code shall be set to one with the exception of the least significant bit which shall be set to zero. If a SIM is inserted in a Mobile Equipment with the location area code containing all zeros, then the Mobile Equipment shall recognise this LAC as part of a deleted RAI. RAC, Routing area code (octet 7) In the RAC field bit 8 of octet 7 is the most significant. The coding of the routing area code is the responsibility of each administration. Coding using full hexadecimal representation may be used. The routing area code consists of 1 octet.

### 10.5.5.16 Spare

This is intentionally left spare.

#### 10.5.5.17 Update result

The purpose of the *update result* information element is to specify the result of the associated updating procedure.

#### 3GPP TS 04.08 version 7.21.0 Release 1998

556

The update result is a type 1 information element.

The *update result* information element is coded as shown in figure 10.5.131/3GPP TS 04.08 and table 10.5.149/3GPP TS 04.08.

8	7	б	5	4	3	2	1	
	Update	e result IEI		0 spare	Updat v	e res alue	ult	octet 1

Figure 10.5.131/3GPP TS 04.08: Update result information element

Table 10.5.149/3GPP TS 04.08: Update result information element

Upda	ate result value	(octet 1)
Bit: 3 2	-	
	0 RA updated 1 combined RA/LA	updated
All	other values are r	eserved.

#### 10.5.5.18 Update type

The purpose of the update type information element is to specify the area the updating procedure is associated with.

The update type is a type 1 information element.

The *update type* information element is coded as shown in figure 10.5.132/3GPP TS 04.08 and table 10.5.150/3GPP TS 04.08.

8	7	6	5	4	3	2	1	
	Update	type		0	Upd	ate t	уре	octet 1
	IE	I		spare		value		
						-	-	•

Figure 10.5.132/3GPP TS 04.08: Update type information element

Table 10.5.150/3GPP TS 04.08: Update type information element


Upda	te t	ype valu	e	(octet 1)	
Bits 3 2	1				
0 0	1 co 0 co		RA/LA RA/LA	updating updating	with
0 1		eriodic		ina	

### 10.5.5.19 A&C reference number

The purpose of the A&C reference number information element is to indicate to the network in the AUTHENTICATION AND CIPHERING RESPONSE message which AUTHENTICATION AND CIPHERING REQUEST message the MS is replying to.

The A&C reference number is a type 1 information element.

The A&C reference number information element is coded as shown in figure 10.5.123/3GPP TS 04.08 and table 10.5.140/3GPP TS 04.08.



#### Figure 10.5.134/3GPP TS 04.08: A&C reference number information element

Table 10.5.152/3GPP TS 04.08: A&C reference number information element

```
A&C reference number value (octet 1)
Unformatted 4 bit field
```

### 10.5.6 Session management information elements

#### 10.5.6.1 Access Point Name

The purpose of the *access point name* information element is to identify the packet data network to which the GPRS user wishes to connect and to notify the access point of the packet data network that wishes to connect to the MS.

The Access Point Name is a label or a full qualified domain name according to DNS naming conventions (see 3GPP TS 03.03 [10]).

The *access point name* is a type 4 information element with a minimum length of 3 octets and a maximum length of 102 octets.

The *access point name* information element is coded as shown in figure 10.5.134/3GPP TS 04.08 and table 10.5.152/3GPP TS 04.08.




Figure 10.5.134/3GPP TS 04.08: Access point name information element

The value part is defined in 03.03 [10].

#### 10.5.6.2 Network service access point identifier

The purpose of the *network service access point identifier* information element is to identify the service access point that is used for the GPRS data transfer at layer 3.

The network service access point identifier is a type 3 information element with a length of 2 octets.

The value part of a *network service access point identifier* information element is coded as shown in figure 10.5.135/3GPP TS 04.08 and table 10.5.153/3GPP TS 04.08.




Figure 10.5.135/3GPP TS 04.08: Network service access point identifier information element

Table 10.5.153/3GPP TS 04.08: Network service access point identifier information element

NSZ	API ·	value (octet	t 2)
Bit 4 3 0 0 0 0 0 1 0 1 0 1 0 1 1 0 1 0 1 0 1 0	3 0 0 0 1 0 1 0 1 0 1 0 1 0 1 0 1	1 0 reserved 1 reserved 0 reserved 1 reserved 1 NSAPI 5 0 NSAPI 6 1 NSAPI 7 0 NSAPI 7 0 NSAPI 8 1 NSAPI 9 0 NSAPI 10 1 NSAPI 12 1 NSAPI 12 1 NSAPI 14 1 NSAPI 15	

### 10.5.6.3 Protocol configuration options

The purpose of the *protocol configuration options* information element is to transfer external network protocol options associated with a PDP context activation.

The *protocol configuration options* is a type 4 information element with a minimum length of 2 octets and a maximum length of 253 octets.

The *protocol configuration options* information element is coded as shown in figure 10.5.136/3GPP TS 04.08 and table 10.5.154/3GPP TS 04.08.

8	7	6	5	4		3	2	1		
	Proto	col conf	Eigura	tion	opt	cions	IEI		octet	: 1
Leng	gth of	protoco	l cont	fig.	opt	ions	cont	ents	octet	2
1 ext		0 0 0 Spar	-		(		gurat otoco		octet	2 3
		Pr	otoco	l ID	1				octet	
	Leng	th of pi	rotoco	l ID	1 c	conte	nts		octet	5 6
		Protoco	ol ID	1 cor	nter	nts			octet	: 7
									octet	z m
		Pr	otoco	l ID	2				octet octet	
					_				octet	m+4
		Protoco	DI ID	2 cor	nter	nts			octet	: n
									octet	n+1
			•••	•					octet	z x
		Pro	tocol	ID n	-1				octet octet	
	Lengt	h of pro	otocol	ID r	n-1	cont	ents		octet	x+3
				-					octet	x+4
		Protocol	LIDn	-1 CC	onte	ents			octet	z y
		Pr	otocol	l ID	n				octet octet	-
	Leng	th of pi	rotoco	l ID	n c	conte	nts		octet	y+3
		Ductors		20 0 0 0		ta			octet	y+4
		Protoco	UT TO	11 COI	uter	ICS			octet	z

Figure 10.5.136/3GPP TS 04.08: *Protocol configuration options* information element

Table 10.5.154/3GPP TS 04.08: Protocol configuration options information element

Configuration protocol (octet 3) Bits 321 000 PPP for use with IP PDP type All other values are interpreted as PPP in this version of the protocol. Configuration protocol options list (octets 4 to z) The configuration protocol options list contains a variable number of logical units, the may occur in an arbitrary order within the configuration protocol options list. Each unit is of variable length and consists of a protocol identifier (2 octets); the length of the protocol identifier contents of the unit (1 octet); and the protocol identifier contents itself (n octets). The protocol identifier field contains the hexadecimal coding of the configuration protocol identifier. Bit 8 of the first octet of the protocol identifier field contains the most significant bit and bit 1 of the second octet of the protocol identifier field contains the least significant bit. If the configuration protocol options list contains a protocol identifier that is not supported by the receiving entity the corresponding unit shall be discarded. The length of the protocol identifier contents field contains the binary coded representation of the length of the protocol identifier contents field of a unit. The first bit in transmission order is the most significant bit. The protocol identifier contents field of each unit contains information specific to the configuration protocol specified by the protocol identifier. PPP At least the following protocol identifiers (as defined in RFC 1700) shall be supported in this version of the protocol: C021H (LCP; C023H (PAP); C223H (CHAP);and 8021H (IPCP). The support of other protocol identifiers is implementation dependent and outside the scope of the present document. The protocol identifier contents field of each unit corresponds to a 'Packet' as defined in RFC 1661 that is stripped off the 'Protocol' and the 'Padding' octets. The detailed coding of the *protocol identifier contents* field is specified in the RFC that is associated with the protocol identifier of that unit.

### 10.5.6.4 Packet data protocol address

The purpose of the packet data protocol address information element is to identify an address associated with a PDP.

The *packet data protocol address* is a type 4 information element with minimum length of 4 octets and a maximum length of 20 octets.

The *packet data protocol address* information element is coded as shown in figure 10.5.137/3GPP TS 04.08 and table 10.5.155/3GPP TS 04.08.




Figure 10.5.137/3GPP TS 04.08: Packet data protocol address information element

#### Table 10.5.155/3GPP TS 04.08: Packet data protocol address information element

```
Length of PDP address contents (octet 2)
    If the value of octet 2 equals 0000 0010, then :
    - No PDP address is included in this information
    element; and
    - If the PDP type is IP, dynamic addressing is
    applicable.
NOTE : For PPP no address is required in this information
element.
    PDP type organisation (octet 3)
    Bits
    4 3 2 1
    In MS to network direction :
    0 0 0 0 ETSI allocated address (e.g. X.121)
    0 0 0 1 IETF allocated address
    1 1 1 1 Empty PDP type
    All other values are reserved.
    In network to MS direction :
    0 0 0 0 ETSI allocated address (e.g. X.121)
    0 0 0 1 IETF allocated address
    All other values are reserved.
    If bits 4,3,2,1 of octet 3 are coded 0 0 0 0
    PDP type number value (octet 4)
    Bits
    8 7 6 5 4 3 2 1
    0 0 0 0 0 0 0 0 0 0 X.121 address
0 0 0 0 0 0 0 1 PDP-type PPP
    All other values shall be interpreted as X.121 address
    in this version of the protocol.
    If bits 4,3,2,1 of octet 3 are coded 0 0 0 1
    PDP type number value (octet 4)
    Bits
    8 7 6 5 4 3 2 1
    0 0 1 0 0 0 0 1 IPv4 address
    0 1 0 1 0 1 1 1 IPv6 address
    All other values shall be interpreted as IPv4 address
    in this version of the protocol.
    In MS to network direction:
    If bits 4,3,2,1 of octet 3 are coded 1 1 1 1
    PDP type number value (octet 4)
    bits 8 to 1 are spare and shall be coded all 0.
    Octet 3, bits 7, 6, and 5 are spare and shall be coded
    all 0.
```

8	7	6	5	4	3	2	1	_	
	di	lgit 2			digit	1		octet	5
	di	lgit 4			digit	3		octet	6
	dig	git m+l			digit	m		octet	n*

If PDP type number indicates X.121, the Address information is coded as follows:

Digit 1 contains the first BCD coded digit of the X.121 address. If the X.121 address has an odd number of digits, digit m+1 shall be padded with HEX(F).

If PDP type number indicates IPv4, the Address information in octet 5 to octet 8 contains the IPv4 address. Bit 8 of octet 5 represents the most significant bit of the IP address and bit 1 of octet 8 the least significant bit .

If PDP type number indicates IPv6, the Address information in octet 5 to octet 20 contains the IPv6 address. Bit 8 of octet 5 represents the most significant bit of the IP address and bit 1 of octet 20 the least significant bit.

### 10.5.6.5 Quality of service

The purpose of the quality of service information element is to specify the QoS parameters for a PDP context.

The quality of service is a type 4 information element with a length of 5 octets.

The *quality of service* information element is coded as shown in figure 10.5.138/3GPP TS 04.08 and table 10.5.156/3GPP TS 04.08.

 8	7	6	5	4	3	2	1	
		Quali	ty of	servic	e IEI			octet 1
	Leng	gth of	qualit	ty of :	service	e IE		Octet 2
0 spa	0 re		Delay class		Rel	iabil class	-	octet 3
		ak ghput		0 spare		eceder class		octet 4
	0 0 0 spare			th	Mean roughp	ut		octet 5

Figure 10.5.138/3GPP TS 04.08: Quality of service information element

eliability class, octet 3 (see 3GPP TS 03.60) its 2 1 n MS to network direction:
21
MS to network direction.
0 0 Subscribed reliability class
n network to MS direction:
0 0 Reserved
MS to network direction and in network to MS direction :
01 Acknowledged GTP, LLC, and RLC; Protected data
10 Unacknowledged GTP; Acknowledged LLC and RLC, Protected data
1 1 Unacknowledged GTP and LLC; Acknowledged RLC, Protected data
<ul><li>0 0 Unacknowledged GTP, LLC, and RLC, Protected data</li><li>0 1 Unacknowledged GTP, LLC, and RLC, Unprotected data</li></ul>
1 1 Reserved
1 1 Keselveu
Il other values are interpreted as Unacknowledged GTP and LLC; Acknowledged RLC, Protected data in this version
f the protocol.
Delay class, octet 3 (see 3GPP TS 02.60 and 3GPP TS 03.60)
its
54
n MS to network direction:
0.0 Subscribed delay class
n network to MS direction:
00 Reserved
n MS to network direction and in network to MS direction :
0 1 Delay class 1
10 Delay class 2
1 1 Delay class 3
0 0 Delay class 4 (best effort)
11 Reserved
$\mathbf{H}_{\mathbf{r}}(\mathbf{h}_{\mathbf{r}}) = \mathbf{h}_{\mathbf{r}}(\mathbf{h}_{\mathbf{r}}) + \mathbf{h}_{\mathbf{r}}(\mathbf{h}_{\mathbf$
Il other values are interpreted as <i>Delay class 4 (best effort)</i> in this version
f the protocol.
it 7 and 8 of octet 3 are spare and shall be coded all 0.
it 7 and 8 of octet 5 are spare and shall be coded an 0.
recedence class, octet 4 (see 3GPP TS 03.60)
its
21
n MS to network direction:
0 0 Subscribed precedence
n network to MS direction:
00 Reserved
n MS to network direction and in network to MS direction :
0.1 High priority
10 Normal priority
1 1 Low priority
11 Reserved

### Table 10.5.156/3GPP TS 04.08: Quality of service information element

	tet 4 is spare and shall be coded as 0.
Peak throu	ighput, octet 4
Bits	
8765	
In MS to r	network direction:
	oscribed peak throughput
	to MS direction:
0 0 0 0 Res	
	network direction and in network to MS direction :
	Up to 1 000 octet/s
	Up to 2 000 octet/s
	Up to 4 000 octet/s
	Up to 8 000 octet/s
	Up to 16 000 octet/s
	Up to 32 000 octet/s
	Up to 64 000 octet/s
	Up to 128 000 octet/s
	Up to 256 000 octet/s Reserved
	ughput, octet 5
Bits	ugnput, octer 5
54321	
	network direction:
111 1010 10 1	
00000	
00000 In network	Subscribed mean throughput c to MS direction:
	Subscribed mean throughput
In network 0 0 0 0 0 0	Subscribed mean throughput to MS direction:
In network 0 0 0 0 0 In MS to r	Subscribed mean throughput to MS direction: Reserved
In network 0 0 0 0 0 0	Subscribed mean throughput c to MS direction: Reserved network direction and in network to MS direction :
In network 0 0 0 0 0 In MS to r 0 0 0 0 1 0 0 0 1 0 0 0 0 1 1	Subscribed mean throughput t to MS direction: Reserved network direction and in network to MS direction : 100 octet/h
In network 0 0 0 0 0 In MS to r 0 0 0 0 1 0 0 0 1 0 0 0 0 1 1 0 0 1 0 0	Subscribed mean throughput to MS direction: Reserved network direction and in network to MS direction : 100 octet/h 200 octet/h 500 octet/h 1 000 octet/h
In network 0 0 0 0 0 In MS to r 0 0 0 0 1 0 0 0 1 0 0 0 0 1 1 0 0 1 0 0 0 0 1 0 1	Subscribed mean throughput t to MS direction: Reserved network direction and in network to MS direction : 100 octet/h 200 octet/h 500 octet/h 1 000 octet/h 2 000 octet/h
In network 0 0 0 0 0 In MS to r 0 0 0 0 1 0 0 0 1 0 0 0 1 0 0 0 0 1 0 1	Subscribed mean throughput t to MS direction: Reserved network direction and in network to MS direction : 100 octet/h 200 octet/h 500 octet/h 1 000 octet/h 2 000 octet/h 5 000 octet/h
In network 0 0 0 0 0 In MS to r 0 0 0 0 1 0 0 0 1 0 0 0 1 0 1 0 0 1 0 1	Subscribed mean throughput t to MS direction: Reserved network direction and in network to MS direction : 100 octet/h 200 octet/h 500 octet/h 1 000 octet/h 2 000 octet/h 5 000 octet/h 10 000 octet/h 10 000 octet/h
$ \begin{array}{c} \text{In network} \\ 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 \\ \text{In MS tor} \\ 0 & 0 & 0 & 1 \\ 0 & 0 & 0 & 1 & 0 \\ 0 & 0 & 1 & 1 & 0 \\ 0 & 0 & 1 & 0 & 1 \\ 0 & 0 & 1 & 1 & 0 \\ 0 & 0 & 1 & 1 & 1 \\ 0 & 1 & 0 & 0 & 0 \\ \end{array} $	Subscribed mean throughput t to MS direction: Reserved network direction and in network to MS direction : 100 octet/h 200 octet/h 500 octet/h 1 000 octet/h 2 000 octet/h 5 000 octet/h 10 000 octet/h 200 octet/h 10 000 octet/h 10 000 octet/h
In network 0 0 0 0 0 In MS to r 0 0 0 0 1 0 0 0 1 0 0 0 1 1 0 0 1 0 1 0 0 1 1 1 0 0 1 1 1 0 0 1 1 1 0 1 0 0 0 0 1 0 1	Subscribed mean throughput t to MS direction: Reserved network direction and in network to MS direction : 100 octet/h 200 octet/h 500 octet/h 1 000 octet/h 2 000 octet/h 10 000 octet/h 5 000 octet/h 10 000 octet/h 50 000 octet/h 20 000 octet/h 50 000 octet/h
In network 0 0 0 0 0 In MS to r 0 0 0 0 1 0 0 0 1 0 0 0 1 1 0 0 1 0 1 0 0 1 1 0 0 0 1 1 1 0 1 0 0 0 0 1 0 1	Subscribed mean throughput t to MS direction: Reserved network direction and in network to MS direction : 100 octet/h 200 octet/h 500 octet/h 1 000 octet/h 2 000 octet/h 5 000 octet/h 10 000 octet/h
$\begin{array}{c} \text{In network} \\ 0 & 0 & 0 & 0 & 0 \\ \text{In MS to r} \\ 0 & 0 & 0 & 1 & 1 \\ 0 & 0 & 0 & 1 & 0 \\ 0 & 0 & 1 & 1 & 0 \\ 0 & 0 & 1 & 0 & 1 \\ 0 & 0 & 1 & 1 & 1 \\ 0 & 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 1 & 0 \\ 0 & 1 & 0 & 1 & 0 \\ 0 & 1 & 0 & 1 & 1 \end{array}$	Subscribed mean throughput a to MS direction: Reserved network direction and in network to MS direction : 100 octet/h 200 octet/h 500 octet/h 1 000 octet/h 2 000 octet/h 5 000 octet/h 10 000 octet/h 20 000 octet/h 10 000 octet/h 20 000 octet/h 20 000 octet/h 20 000 octet/h 20 000 octet/h 20 000 octet/h 20 000 octet/h
$\begin{array}{c} \text{In network} \\ 0 & 0 & 0 & 0 & 0 \\ \text{In MS to r} \\ 0 & 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 & 1 \\ 0 & 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 1 & 1 \\ 0 & 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 1 & 0 \\ 0 & 1 & 0 & 1 & 0 \\ 0 & 1 & 0 & 1 & 1 \\ 0 & 1 & 0 & 1 & 0 \\ 0 & 1 & 1 & 1 & 0 \end{array}$	Subscribed mean throughput t to MS direction: Reserved network direction and in network to MS direction : 100 octet/h 200 octet/h 500 octet/h 2 000 octet/h 5 000 octet/h 10 000 octet/h 20 000 octet/h 10 000 octet/h 50 000 octet/h 50 000 octet/h 50 000 octet/h 50 000 octet/h 50 000 octet/h 50 000 octet/h 500 000 octet/h 500 000 octet/h 500 000 octet/h
In network 0 0 0 0 0 0 In MS to r 0 0 0 1 0 0 0 0 1 0 0 0 1 1 0 0 1 0 0 0 0 1 1 1 0 0 1 1 0 0 0 1 1 1 0 1 0 0 0 0 1 0 1 0 1 0 1	Subscribed mean throughput a to MS direction: Reserved network direction and in network to MS direction : 100 octet/h 200 octet/h 500 octet/h 1 000 octet/h 5 000 octet/h 10 000 octet/h 20 000 octet/h 10 000 octet/h 20 000 octet/h 100 000 octet/h 1 000 000 octet/h
In network 0 0 0 0 0 0 In MS to r 0 0 0 1 0 0 0 0 1 0 0 0 1 1 0 0 1 0 0 0 0 1 1 1 0 0 1 0 1	Subscribed mean throughput t to MS direction: Reserved network direction and in network to MS direction : 100 octet/h 200 octet/h 500 octet/h 1 000 octet/h 5 000 octet/h 10 000 octet/h 20 000 octet/h 10 000 octet/h 20 000 octet/h 50 000 octet/h 100 000 octet/h 100 000 octet/h 100 000 octet/h 100 000 octet/h 200 000 octet/h 100 000 octet/h 100 000 octet/h 200 000 octet/h 1000 000 octet/h 200 000 octet/h
$\begin{array}{c} \text{In network} \\ 0 & 0 & 0 & 0 & 0 \\ \text{In MS to r} \\ 0 & 0 & 0 & 1 & 1 \\ 0 & 0 & 0 & 1 & 1 \\ 0 & 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 & 1 \\ 0 & 0 & 1 & 0 & 1 \\ 0 & 0 & 1 & 1 & 1 \\ 0 & 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 1 & 1 \\ 0 & 1 & 0 & 1 & 0 \\ 0 & 1 & 1 & 1 & 0 \\ 0 & 1 & 1 & 1 & 1 \\ 0 & 1 & 1 & 1 & 1 \\ \end{array}$	Subscribed mean throughput to MS direction: Reserved network direction and in network to MS direction : 100 octet/h 200 octet/h 1 000 octet/h 2 000 octet/h 2 000 octet/h 5 000 octet/h 10 000 octet/h 20 000 octet/h 10 000 octet/h 20 000 octet/h 100 000 octet/h 50 000 octet/h 100 000 octet/h 100 000 octet/h 200 000 octet/h 100 000 octet/h 5 000 000 octet/h 5 000 000 octet/h 5 000 000 octet/h 1 000 000 octet/h 5 000 000 octet/h
In network 0 0 0 0 0 In MS to r 0 0 0 0 1 0 0 0 1 0 0 0 0 1 0 0 0 1 0 1	Subscribed mean throughput           ct o MS direction:           Reserved           network direction and in network to MS direction :           100 octet/h           200 octet/h           500 octet/h           1 000 octet/h           2 000 octet/h           5 000 octet/h           10 000 octet/h           200 octet/h           10 000 octet/h           200 000 octet/h           100 000 octet/h           200 000 octet/h           100 000 octet/h           100 000 octet/h           100 000 octet/h           100 000 octet/h           200 000 octet/h           100 000 octet/h           100 000 octet/h           100 000 octet/h           1000 000 octet/h           5 000 000 octet/h           10 000 000 octet/h           10 000 000 octet/h
$ \begin{array}{c} \text{In network} \\ 0 & 0 & 0 & 0 & 0 \\ \text{In MS tor} \\ 0 & 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 & 1 & 0 \\ 0 & 0 & 1 & 0 & 1 & 0 \\ 0 & 0 & 1 & 1 & 1 & 0 \\ 0 & 1 & 0 & 1 & 0 & 0 \\ 0 & 1 & 0 & 1 & 0 & 0 \\ 0 & 1 & 0 & 1 & 1 & 0 \\ 0 & 1 & 1 & 1 & 0 & 0 \\ 0 & 1 & 1 & 1 & 1 \\ 1 & 0 & 0 & 0 & 0 \\ 1 & 0 & 0 & 0 & 1 \\ \end{array} $	Subscribed mean throughput           ct to MS direction:           Reserved           network direction and in network to MS direction :           100 octet/h           200 octet/h           500 octet/h           1 000 octet/h           2 000 octet/h           5 000 octet/h           10 000 octet/h           2 000 octet/h           5 000 octet/h           10 000 octet/h           20 000 octet/h           10 000 octet/h           20 000 octet/h           100 000 octet/h           100 000 octet/h           200 000 octet/h           100 000 octet/h           200 000 octet/h           100 000 octet/h           100 000 octet/h           2000 000 octet/h           1 000 000 octet/h           1 000 000 octet/h           1 000 000 octet/h           2 000 000 octet/h           1 000 000 octet/h           1 000 000 octet/h           2 000 000 octet/h           1 0 000 000 octet/h           2 0000 000 octet/h           2
In network 0 0 0 0 0 In MS to r 0 0 0 0 1 0 0 0 1 0 0 0 0 1 0 0 0 1 0 1	Subscribed mean throughput           ct o MS direction:           Reserved           network direction and in network to MS direction :           100 octet/h           200 octet/h           500 octet/h           1 000 octet/h           2 000 octet/h           5 000 octet/h           10 000 octet/h           200 octet/h           10 000 octet/h           200 000 octet/h           100 000 octet/h           200 000 octet/h           100 000 octet/h           100 000 octet/h           100 000 octet/h           100 000 octet/h           200 000 octet/h           100 000 octet/h           100 000 octet/h           100 000 octet/h           1000 000 octet/h           5 000 000 octet/h           10 000 000 octet/h           10 000 000 octet/h

The value Best effort indicates that throughput shall be made available to the MS on a per need and availability basis.

All other values are interpreted as *Best effort* in this version of the protocol. Bits 8 to 6 of octet 5 are spare and shall be coded all 0.

### 10.5.6.6 SM cause

The purpose of the *SM cause* information element is to indicate the reason why a session management request is rejected.

The SM cause is a type 3 information element with 2 octets length.

The *SM cause* information element is coded as shown in figure 10.5.139/3GPP TS 04.08 and table 10.5.157/3GPP TS 04.08.





Figure 10.5.139/3GPP TS 04.08: SM cause information element



Cause value (octet 2)
Bits 8 7 6 5 4 3 2 10 0 0 1 1 0 0 1 LLC or SNDCP failure 0 0 0 1 1 0 1 0 Insufficient resources 0 0 0 1 1 0 1 1 Missing or unknown APN 0 0 0 1 1 1 0 0 Unknown PDP address or PDP type 0 0 0 1 1 1 0 1 User Aauthentication failed 0 0 0 1 1 1 1 0 Activation rejected by GGSN
0 0 0 1 1 1 1 1 Activation rejected by GSAN 0 0 0 1 1 1 1 1 Activation rejected, unspecified 0 0 1 0 0 0 0 0 Service option not supported 0 0 1 0 0 0 0 1 Requested service option not subscribed
0 0 1 0 0 0 1 0 Service option temporarily
<pre>out of order 0 0 1 0 0 0 1 1 NSAPI already used 0 0 1 0 0 1 0 0 Regular deactivation 0 0 1 0 0 1 0 1 QoS not accepted 0 0 1 0 0 1 1 0 Network failure 0 0 1 0 0 1 1 1 Reactivation required 0 0 1 0 0 1 1 1 Reactivation required 0 1 0 1 0 0 0 Feature not supported 0 1 0 1 0 0 0 1 Invalid transaction identifier value 0 1 0 1 1 1 1 1 Semantically incorrect message 0 1 1 0 0 0 0 0 Invalid mandatory information 0 1 1 0 0 0 0 1 Message type non-existent or not implemented 0 1 1 0 0 0 1 0 Message type not compatible with the protocol state 0 1 1 0 0 0 1 1 Information element non-existent or not implemented 0 1 1 0 0 1 0 0 Conditional IE error 0 1 1 0 0 1 0 1 Message not compatible with the protocol state</pre>
0 1 1 0 1 1 1 1 Protocol error, unspecified
Any other value received by the mobile station shall be treated as 0010 0010, 'Service option temporarily out of order'. Any other value received by the network shall be treated as 0110 1111, 'Protocol error, unspecified'.
NOTE: The listed cause values are defined in Annex I

### 10.5.6.7 Spare

This is intentionally left spare.

### 10.5.6.8 AA deactivation cause

The purpose of the AA deactivation cause information element is to indicate the reason why a AA PDP context was deactivated by the network.

The AA deactivation cause information element is coded as shown in figure 10.5.140/3GPP TS 04.08 and table 10.5.158/3GPP TS 04.08.

The AA deactivation cause is a type 1 information element.

8	7	6	5	4	3	2	1		
AA	deactiv indica	ation ( tor IE		0 spare				octet	1

Figure 10.5.140/3GPP TS 04.08: AA deactivation cause information element

#### Table 10.5.158/3GPP TS 04.08: AA deactivation cause information element

```
AA deactivation cause value (octet 1)
Bits
3 2 1
         Normal, unspecified
Server address violation
0
  0 0
0
  0 1
         Network overload
0
  1 0
  1 1
0
         Server not reachable
All other values are interpreted as Normal, unspecified by this version
of the protocol.
```

### 10.5.6.9 LLC service access point identifier

The purpose of the *LLC service access point identifier* information element is to identify the service access point that is used for the GPRS data transfer at LLC layer.

The *LLC service access point identifier* is a type 3 information element with a length of 2 octets.

The value part of a *LLC service access point identifier* information element is coded as shown in figure 10.5.141/3GPP TS 04.08 and table 10.5.159/3GPP TS 04.08.

8	7	6	5	4	3	2	1	
			LLC SA	API IEI	Ľ			octet 1
		0 0 are			LLC S val			octet 2



#### Table 10.5.159/3GPP TS 04.08: LLC service access point identifier information element

LLC SAPI value (octet 2)
Bit 4 3 2 1 0 0 1 1 SAPI 3 0 1 0 1 SAPI 5 1 0 0 1 SAPI 9 1 0 1 1 SAPI 11
All other values are reserved.

### 10.5.7 GPRS Common information elements

10.5.7.1 [Spare]

#### 10.5.7.2 Radio priority

The purpose of the *radio priority* information element is to specify the priority level that the MS shall use at the lower layers for transmission of data related to a PDP context or for mobile originated SMS transmission.

The *radio priority* information element is coded as shown in figure 10.5.143/3GPP TS 04.08 and table 10.5.161/3GPP TS 04.08.

The radio priority is a type 1 information element.

8 7 6 5 4 3 2 1 Radio priority IEI 0 Radio priority octet 1 spare level value

Figure 10.5.143/3GPP TS 04.08: Radio priority information element

Table 10.5.161/3GPP TS 04.08: Radio priority information element

```
Radio priority level value (octet 1)
Bits
3 2 1
          priority level priority level
0
   0
      1
                                 1
                                    (highest)
   1 0
                                 2
0
          priority level 3
priority level 4 (lowest)
0
  1 1
   0 0
1
All other values are interpreted as priority level 4 by this version
of the protocol.
```

### 10.5.7.3 GPRS Timer

The purpose of the *GPRS timer* information element is to specify GPRS specific timer values, e.g. for the READY timer.

The GPRS timer is a type 3 information element with 2 octets length.

The *GPRS timer* information element is coded as shown in figure 10.5.144/3GPP TS 04.08 and table 10.5.162/3GPP TS 04.08.




Figure 10.5.144/3GPP TS 04.08: GPRS Timer value information element

Table 10.5.162/3GPP TS 04.08: GPRS Timer value information element

```
Timer value (octet 2)
Bits 5 to 1 represent the binary coded timer
value.
Bits 6 to 8 defines the timer value unit
for the GPRS timer as follows:
Bits
8 7 6
0 0 0
       value is incremented in multiples of 2
       seconds
0 0 1
       value is incremented in multiples of 1
       minute
0 1 0
       value is incremented in multiples of
       decihours
       value indicates that the timer is deactivated.
1 1 1
Other values shall be interpreted as multiples
of 1 minute in this version of the protocol.
```

## 11 List of system parameters

The description of timers in the following table should be considered a brief summary. The precise details are found in clauses 3 to 6, which should be considered the definitive descriptions.

### 11.1 Timers and counters for radio resource management

### 11.1.1 Timers on the mobile station side

T3122:	This timer is used during random access, after the receipt of an IMMEDIATE ASSIGN REJECT message.
	Its value is given by the network in the IMMEDIATE ASSIGN REJECT message.
T3124:	This timer is used in the seizure procedure during a hand-over, when the two cells are not synchronized.
	Its purpose is to detect the lack of answer from the network to the special signal.
	Its value is set to 675 ms if the channel type of the channel allocated in the HANDOVER COMMAND is an SDCCH (+ SACCH); otherwise its value is set to 320 ms.
T3126:	This timer is started either
	after sending the maximum allowed number of CHANNEL REQUEST messages during an immediate assignment procedure.
	or
	on receipt of an IMMEDIATE ASSIGNMENT REJECT message,
	whichever occurs first.
	It is stopped at receipt of an IMMEDIATE ASSIGNMENT message, or an IMMEDIATE ASSIGNMENT EXTENDED message.

At its expiry, the immediate assignment procedure is aborted.

The minimum value of this timer is equal to the time taken by T+2S slots of the mobile station's RACH. S and T are defined in sub-clause 3.3.1.2. The maximum value of this timer is 5 seconds.

T3128:	This timer is started when the mobile station starts the uplink investigation procedure and the uplink is busy.
	It is stopped at receipt of the first UPLINK FREE message.
	At its expiry, the uplink investigation procedure is aborted.
	The value of this timer is set to 1 second.
T3130:	This timer is started after sending the first UPLINK ACCESS message during a VGCS uplink access procedure.
	It is stopped at receipt of a VGCS ACCESS GRANT message.
	At its expiry, the uplink access procedure is aborted.
	The value of this timer is set to 5 seconds.
T3110:	This timer is used to delay the channel deactivation after the receipt of a (full) CHANNEL RELEASE. Its purpose is to let some time for disconnection of the main signalling link.
	Its value is set to such that the DISC frame is sent twice in case of no answer from the network. (It should be chosen to obtain a good probability of normal termination (i.e. no time out of T3109) of the channel release procedure.)
T3134	This timer is used in the seizure procedure during an RR network commanded cell change order procedure. Its purpose is to detect the lack of answer from the network or the lack of availability of the target cell.
	Its value is set to 5 seconds.
T3142:	The timer is used during packet access on CCCH, after the receipt of an IMMEDIATE ASSIGNMENT REJECT message.
	Its value is given by the network in the IMMEDIATE ASSIGNMENT REJECT message.
T3146:	This timer is started either
	after sending the maximum allowed number of CHANNEL REQUEST messages during a packet access procedure.
	or
	on receipt of an IMMEDIATE ASSIGNMENT REJECT message during a packet access procedure,
	whichever occurs first.
	It is stopped at receipt of an IMMEDIATE ASSIGNMENT message, or an IMMEDIATE ASSIGNMENT EXTENDED message.
	At its expiry, the packet access procedure is aborted.
	The minimum value of this timer is equal to the time taken by T+2S slots of the mobile station's RACH. S and T are defined in sub-clause 3.3.1.2. The maximum value of this timer is 5 seconds.
T3164:	This timer is used during packet access using CCCH. It is started at the receipt of an IMMEDIATE ASSIGNMENT message.
	It is stopped at the transmission of a RLC/MAC block on the assigned temporary block flow, see 3GPP TS 04.60.
	At expire, the mobile station returns to the packet idle mode.
	The value of the timer is 5 seconds.

**T3190:** The timer is used during packet downlink assignment on CCCH. It is started at the receipt of an IMMEDIATE ASSIGNMENT message or of an PDCH ASSIGNMENT COMMAND message when in dedicated mode.

It is stopped at the receipt of a RLC/MAC block on the assigned temporary block flow, see 3GPP TS 04.60.

At expiry, the mobile station returns to the packet idle mode.

The value of the timer is 5 s.

### 11.1.2 Timers on the network side

**T3101:** This timer is started when a channel is allocated with an IMMEDIATE ASSIGNMENT message. It is stopped when the MS has correctly seized the channels.

Its value is network dependent.

- NOTE 1: It could be higher than the maximum time for a L2 establishment attempt.
- **T3103:** This timer is started by the sending of a HANDOVER message and is normally stopped when the MS has correctly seized the new channel. Its purpose is to keep the old channels sufficiently long for the MS to be able to return to the old channels, and to release the channels if the MS is lost.

Its value is network dependent.

- NOTE 2: It could be higher than the maximum transmission time of the HANDOVER COMMAND, plus the value of T3124, plus the maximum duration of an attempt to establish a data link in multiframe mode.)
- **T3105:** This timer is used for the repetition of the PHYSICAL INFORMATION message during the handover procedure.

Its value is network dependent.

- NOTE 3: This timer may be set to such a low value that the message is in fact continuously transmitted.
- **T3107:** This timer is started by the sending of an ASSIGNMENT COMMAND message and is normally stopped when the MS has correctly seized the new channels.

Its purpose is to keep the old channel sufficiently long for the MS to be able to return to the old channels, and to release the channels if the MS is lost.

Its value is network dependent.

- NOTE 4: It could be higher than the maximum transmission time of the ASSIGNMENT COMMAND message plus twice the maximum duration of an attempt to establish a data link multiframe mode.
- **T3109:** This timer is started when a lower layer failure is detected by the network, when it is not engaged in a RF procedure. It is also used in the channel release procedure.

Its purpose is to release the channels in case of loss of communication.

Its value is network dependent.

- NOTE 5: Its value should be large enough to ensure that the MS detects a radio link failure.
- **T3111:** This timer is used to delay the channel deactivation after disconnection of the main signalling link. Its purpose is to let some time for possible repetition of the disconnection.

Its value is equal to the value of T3110.

**T3113:** This timer is started when the network has sent a PAGING REQUEST message and is stopped when the network has received the PAGING RESPONSE message.

Its value is network dependent.

- NOTE 6: The value could allow for repetitions of the Channel Request message and the requirements associated with T3101.
- **T3115:** This timer is used for the repetition of the VGCS UPLINK GRANT message during the uplink access procedure.

Its value is network dependent.

- NOTE 7: This timer may be set to such a low value that the message is in fact continuously transmitted.
- **T3117:** This timer is started by the sending of a PDCH ASSIGNMENT COMMAND message and is normally stopped when the MS has correctly accessed the target TBF.

Its purpose is to keep the old channel sufficiently long for the MS to be able to return to the old channels, and to release the channels if the MS is lost.

Its value is network dependent.

- NOTE 8: It could be higher than the maximum transmission time of the PDCH ASSIGNMENT COMMAND message plus T3132 plus the maximum duration of an attempt to establish a data link in multiframe mode.
- **T3119:** This timer is started by the sending of a RR-CELL CHANGE ORDER message and is normally stopped when the MS has correctly accessed the new cell. Its purpose is to keep the old channels sufficiently long for the MS to be able to return to the old channels, and to release the channels if the MS is lost.

Its value is network dependent.

- NOTE 9: It could be higher than the maximum transmission time of the RR\_CELL CHANGE ORDER, plus T3134, plus the maximum duration of an attempt to establish a data link in multiframe mode.
- **T3141:** This timer is started when a temporary block flow is allocated with an IMMEDIATE ASSIGNMENT message during a packet access procedure. It is stopped when the mobile station has correctly seized the temporary block flow.

Its value is network dependent.

### 11.1.3 Other parameters

- **Ny1:** The maximum number of repetitions for the PHYSICAL INFORMATION message during a handover (see sub-clause 3.4.4.2.2). The value is network dependent.
- **Ny2:** The maximum number of repetitions for the VGCS UPLINK GRANT message during an uplink access procedure (see sub-clause 3.3.1.2.2). The value is network dependent.

## 11.2 Timers of mobility management

Table 11.1/3GPP TS 04.08: Mobility management timers - MS-side

TIMER NUM.	ST		CAUSE FOR START	NORMAL STOP	AT THE EXPIRY
T3210	3	20s	-LOC_UPD_REQ sent	<ul> <li>LOC_UPD_ACC</li> <li>LOC_UPD_REJ</li> <li>AUTH_REJ</li> <li>Lower layer failure</li> </ul>	Start T3211
T3211	1 2	15s	-LOC_UPD_REJ with cause #17 netw. failure -lower layer failure or RR conn. released after RR conn. abort during loc. updating	<ul> <li>Time out</li> <li>cell change</li> <li>request for MM connec- tion establish- ment</li> <li>change of LA</li> </ul>	
T3212	1, 2	Note 1	-termination of MM ser- vice or MM signalling	-initiation of MM ser- vice or MM signalling	initiate periodic updating
T3213	1 2 11	4s	-location up dating fai lure	- expiry - change of BCCH para- meter	new random attempt
T3220	7	5s	-IMSI DETACH	- release from RM- sublayer	enter Null or Idle, AT TEMPTING TO UPDATE
T3230	5	15s	-CM SERV REQ CM REEST REQ	- Cipher mode setting - CM SERV REJ - CM SERV ACC	provide release ind
40 9 1 	LOs 10	see	sub-clause 11.2.1	see sub-claus 11.2.1	se   abort RR connec- tion
41 25 3 	300s	s  see	e sub-clause 11.2.1	see sub-claus 11.2.1	se   abort RR connec- tion

NOTE 1: The timeout value is broadcasted in a SYSTEM INFORMATION message.

+	TIMER NUM.	ST	TIME OUT VAL.	CAUSE FOR START	NORMAL STOP	AT THE FIRST EXPIRY	AT THE SECOND EXPIRY
-	т3250	6	12s	TMSI-REAL- CMD or LOC UPD ACC with new TMSI sent	TMSI-REALL- COM received	Optionally Release RR connec- tion	
-	T3255		Note	LOC UPD ACC sent with "Follow on Proceed"	CM SERVICE REQUEST	Release RR Connection or use for mobile sta- tion termi- nating call	
-	Т3260	5	12s	AUTHENT- REQUEST sent	AUTHENT- RESPONSE received	Optionally Release RR connec- tion	
-	т3270	4	12s	IDENTITY REQUEST sent	IDENTITY RESPONSE received	Optionally Release RR connec- tion	

Table 11.2/3GPP TS 04.08: Mobility management timers - network-side

NOTE 2: The value of this timer is not specified by this recommendation.

### 11.2.1 Timer T3240 and Timer T3241

Timer T3240 is started in the mobile station when:

- the mobile station receives a LOCATION UPDATING ACCEPT message completing a location updating procedure in the cases specified in sub-clause 4.4.4.6 and 4.4.4.8;
- the mobile station receives a LOCATION UPDATING REJECT message in the cases specified in sub-clause 4.4.4.7;
- the mobile station has sent a CM SERVICE ABORT message as specified in sub-clause 4.5.1.7;
- the mobile station has released or aborted all MM connections in the cases specified in 4.3.2.5, 4.3.5.2, 4.5.1.1, and 4.5.3.1.

Timer T3240 is stopped, reset, and started again at receipt of an MM message.

Timer T3240 is stopped and reset (but not started) at receipt of a CM message that initiates establishment of an CM connection (an appropriate SETUP, REGISTER, or CP-DATA message as defined in 3GPP TS 04.08, 3GPP TS 04.10 or 3GPP TS 04.11).

Timer T3241 is started in the mobile station when entering MM state RR CONNECTION RELEASE NOT ALLOWED.

Timer T3241 is stopped and reset (but not started) when the MM state RR CONNECTION RELEASE NOT ALLOWED is left.

If timer T3241 expires, the MS shall abort the RR connection and enter the MM state MM IDLE.

## 11.2.2 Timers of GPRS mobility management

### Table 11.3/3GPP TS 04.08: GPRS Mobility management timers - MS side

<b>TIMER</b> <b>NUM.</b> T3310	TIMER VALUE	STATE GMM- REG-INIT	CAUSE OF START	ATTACH ACCEPT	ON THE 1 <sup>st</sup> , 2 <sup>nd</sup> , 3 <sup>rd</sup> , 4 <sup>th</sup> EXPIRY Note 3 Retransmission of ATTACH REQ
				ATTACH REJECT received	
T3311	15s	GMM-DEREG ATTEMPTING TO ATTACH or GMM-REG ATTEMPTING TO UPDATE	ATTACH REJ with other cause values as described in chapter 'GPRS Attach' ROUTING AREA UPDATE REJ with other cause values as described in chapter 'Routing Area Update' Low layer failure	Change of the routing area	Restart of the Attach or the RAU procedure with updating of the relevant attempt counter
T3321	15s	GMM- DEREG-INIT	DETACH REQ sent	DETACH ACCEPT received	Retransmission of the DETACH REQ
T3330	15s	GMM- ROUTING- UPDATING- INITIATED	ROUTING AREA UPDATE REQUEST sent	ROUTING AREA UPDATE ACC received ROUTING AREA UPDATE REJ received	Retransmission of the ROUTING AREA UPDATE REQUEST message

### Table 11.3a/3GPP TS 04.08: GPRS Mobility management timers – MS side

TIMER NUM.	TIMER VALUE	STATE	CAUSE OF START	NORMAL STOP	ON EXPIRY			
T3302	T3212	GMM-DEREG	At attach failure and the attempt counter is greater than or equal		initiation of the			
	Note 4	GMM-REG	to 5. At routing area updating failure and the attempt counter is greater than or equal to 5.	routing area updating	GPRS attach procedure or RAU procedure			
T3312	Default 54 min Note1	GMM-REG	When READY state is left.	When entering state GMM-DEREG				
T3314 READY	Default 44 sec Note 2	All except GMM- DEREG	Transmission of a PTP PDU	-	No cell-updates are performed			
T3316 AA- READY	Default 44 sec Note 2	-	Transmission of a PTP PDU	-	-			
NOTE 2:	NOTE 1: The value of this timer is used if the network does not indicate another value in a GMM signalling procedure.							
NOTE 3:								
NOTE 4:	T3302 is load	led with the same	value which is used to load T3212.					

TIMER	TIMER	STATE	CAUSE OF START	NORMAL STOP	ON THE
NUM.	VALUE				1 <sup>st</sup> , 2 <sup>nd</sup> , 3 <sup>rd</sup> , 4 <sup>th</sup>
					EXPIRY Note 3
T3322	6s	GMM- DEREG-INIT	DETACH REQ sent	DETACH ACCEPT received	Retransmission of DETACH REQUEST
T3350	6s	GMM- COMMON- PROC-INIT	ATTACH ACCEPT sent with P-TMSI and/or TMSI RAU ACCEPT sent with P-TMSI and/or TMSI P-TMSI REALLOC COMMAND sent	ATTACH COMPLETE received RAU COMPLETE received P-TMSI REALLOC COMPLETE received	Retransmission of the same message type, i.e. ATTACH ACCEPT, RAU ACCEPT or REALLOC COMMAND
T3360	6s	GMM- COMMON- PROC-INIT	AUTH AND CIPH REQUEST sent	AUTH AND CIPH RESPONSE received	Retransmission of AUTH AND CIPH REQUEST
T3370	6s	GMM- COMMON- PROC-INIT	IDENTITY REQUEST sent	IDENTITY RESPONSE received	Retransmission of IDENTITY REQUEST

Table 11.4/3GPP TS 04.08: GPRS Mobility management timers - network side

#### Table 11.4a/3GPP TS 04.08: GPRS Mobility management timers - network side

TIMER NUM.	TIMER VALUE	STATE	CAUSE OF START	NORMAL STOP	ON EXPIRY
T3313	Note1	GMM_REG	Paging procedure initiated	Paging procedure completed	Network dependent
T3314 READY		All except GMM- DEREG	Receipt of a PTP PDU	Forced to Standby	The network shall page the MS if a PTP PDU has to be sent to the MS
T3316 AA- READY	Default 44 sec Note 2	-	Receipt of a PTP PDU	-	-
	Default 4 min greater than T3312	DEREG	Change from READY to STANDBY state	PTP PDU received	Network dependent but typically paging is halted on 1st expiry
NOTE 2: T s tt NOTE 3: T	he default va ends this val nan in the MS ypically, the	ue, in a signalling 5, this is a networł	s used if neither the MS nor the Network procedure. The value of this timer s c implementation issue. ported on the fifth expiry of the relev	should be slightly sho	rter in the network

## 11.2.3 Timers of session management

TIMER NUM.	TIMER VALUE	STATE	CAUSE OF START	NORMAL STOP	ON THE 1 <sup>st</sup> , 2 <sup>nd</sup> , 3 <sup>rd</sup> , 4 <sup>th</sup> EXPIRY		
T3380	30s	PDP- ACTIVE-PEND	ACTIVATE PDP CONTEXT REQUEST sent	ACTIVATE PDP CONTEXT ACCEPT received ACTIVATE PDP CONTEXT REJECT received	Retransmission of ACTIVATE PDP CONTEXT REQ		
T3390     8s     PDP- INACT-PEND     DEACTIVATE PDP CONTEXT REQUEST sent     DEACTIVATE PDP CONTEXT ACC received     Retransmission of DEACTIVATE PDP CONTEXT REQUEST							
NOTE:	•••	procedures are a procedure desc	L borted on the fifth expiry of the rele ription.	evant timer. Exceptions			

#### Table 11.2c/3GPP TS 04.08: Session management timers - MS side

#### Table 11.2d/3GPP TS 04.08: Session management timers - network side

TIMER NUM.	TIMER VALUE	STATE	CAUSE OF START	NORMAL STOP	ON THE 1 <sup>st</sup> , 2 <sup>nd</sup> , 3 <sup>rd</sup> , 4 <sup>th</sup> EXPIRY
T3385	8s	PDP- ACT-PEND	REQUEST PDP CONTEXT ACTIVATION sent	ACTIVATE PDP CONTEXT REQ received	Retransmission of REQUEST PDP CONTEXT ACTIVATION
T3386	8s	PDP- MOD-PEND	MODIFY PDP CONTEXT REQUEST sent	MODIFY PDP CONTEXT ACC received	Retransmission of MODIFY PDP CONTEXT REQ
T3395	8s	PDP- INACT-PEND	DEACTIVATE PDP CONTEXT REQUEST sent	DEACTIVATE PDP CONTEXT ACC received	Retransmission of DEACTIVATE PDP CONTEXT REQ
T3397	8s	PDP- INACT-PEND	DEACTIVATE AA PDP CONTEXT REQUEST sent	DEACTIVATE AA PDP CONTEXT ACCEPT received	Retransmission of DEACTIVATE AA PDP CONTEXT REQUEST
		procedures are a g procedure descr	borted on the fifth expiry of the relev iption.	ant timer. Exceptions	are described in the

## 11.3 Timers of circuit-switched call control

	М. ЛМ.	TIM VAL	STATE OF CALL	CAUSE OF START	NORMAL STOP	AT FIRST EXPIRY	AT SECOND EXPIRY
T3	803	30s	Call initiated	CM SER RQ sent	CALL PROC, or REL COMP received	Clear the call	Timer is not restarted
т3	805	30s	Disconnect Request	DISC sent	REL or DISC received	REL sent.	Timer is not restarted
Т3	808	30s	Release request	REL sent	REL COMP or REL received	Retrans. RELEASE restart T308	Call ref. release
-	10 te	30s	Outgoing call Proceeding	CALL PROC received	ALERT,CONN, DISC or PROG rec.	Send DISC	Timer is not restarted
Т3	313	30s	Connect Request	CONN sent	CONNect ACKnowledge received	Send DISC	Timer is not restarted
т3	23	30s	Modify Request	MOD sent	MOD COMP or MOD REJ received	Clear the call	Timer is not restarted
т3	32	30s	Wait for network info.	START_CC sent	CC-EST. received	Clear the call	Timer is not restarted
Т3	35	30s	CC-Est. Confirmed	CC-EST CONF.sent	RECALL received	Clear the call	Timer is not restarted

Table 11.3/3GPP TS 04.08: Call control timers - MS side

NOTE: T310 is not started if progress indicator #1, #2, or #64 has been delivered in the CALL PROCEEDING message or in a previous PROGRESS message.

+ TIM. NUM.	DFT TIM VAL	STATE OF CALL	CAUSE FOR START	NORMAL STOP	AT FIRST EXPIRY	AT SECON EXPIRY
T301 Note 1		Call received	ALERT received	CONN received	Clear the call	Timer is not restarted
Т303	Note 2	Call present	SETUP sent	CALL CONF or REL COMP received	Clear the call	Timer is not restarted
т305	30s	Disconnect Indication		REL or DISC received	Network sends RELEASE	Timer is not restarted
T306	30s	Disconnect Indication		REL or DISC received	Stop the tone/ announc. Send REL	is not
Т308	Note 2	Release request	REL sent	REL COMP or REL received	Retrans. RELEASE restart T308	Release call reference
Т310	Note 2	Incoming call pro- ceeding	CALL CONF received	ALERT, CONN or DISC received	Clear the call	Timer is not restarted
Т313	Note 2	Connect Indication	CON sent	CON ACK received	Clear the call	Timer is not restarted
Т323	30s	Modify request	MOD sent	MOD COMP or MOD REJ received	Clear the call	Timer is not restarted
Т331	Note 2	CC Connec. Pending	CM-SERV PROMPT sent	START CC received	Clear the call	Timer is not restarted
Т333	Note 2	CC-Est. Present	START CC received		Clear the call	Timer is not restarted
T334 Note 3	Min 15s	CC-Est. Confirmed	RECALL sent	SETUP received	Clear the call	Timer is not restarted
T338	Note 2	Disconnect indication	DISC with CCBS possible	REL or DISC received	stop any tone/ announc. Send REL	is not

#### Table 11.4/3GPP TS 04.08: Call control timers - network side

- NOTE 1: The network may already have applied an internal alerting supervision function; e.g. incorporated within call control. If such a function is known to be operating on the call, then timer T301 is not used.
- NOTE 2: These time values are set by the network operator.
- NOTE 3: When applied to the supplementary service CCBS, the timer T334 can either represent the recall timer T4 or the notification timer T10 (see 3GPP TS 03.93). Thus the timer T334 can take two different values. 3GPP TS 03.93 defines the range of these values.

## Annex A (informative): Example of subaddress information element coding

This annex is informative.

This annex gives an example of how the Called Party Subaddress IE is encoded to carry subaddress digits that use IA5 characters. This example is also applicable to the Calling Party Subaddress IE.

	8	7	6	5	4	3	2	1	octet
	0	1	1 cal	0 led part	1 Ly subac	1 ddress	0 IEI	1	1
	0	0	0	0 Lengtl	0 1	1	1	1	2
	1 not ext	0 (X.213	0 NSAP /ISO 83	0 48 AD2)	X odd/ev note 1		0 note 2	0	3
	0	1	0	l AFI (not	0 ce 3)	0	0	0	4
			IA5 (	Characte	er (note	e 4)			5
			IA5	Characte	er (note +	e 4)			6
+			IA5 (	Characte	er (note	e 4)		+	9, • note 5

NOTE 1: The value of this bit has no significance when the type of subaddress is "NSAP".

- NOTE 2: These bits are spare.
- NOTE 3: The Authority and Format Identifier code 50 (in BCD) indicates that the subaddress consists of IA5 characters (see ISO standard 8348 AD2).
- NOTE 4: IA5 character as defined in ITU-T Recommendation T.50/ISO 646 and then encoded into two semi-octets according to the "preferred binary encoding" defined in X.213/ISO 8348 AD2. (Each character is converted into a number in the range 32 to 127 using the ISO 646 encoding with zero parity and the parity bit in the most significant position. This number is then reduced by 32 to give a new number in the range 0 to 95. The new number is then treated as a pair of decimal digits with the value of each digit being encoded in a semi-octet.)

NOTE 5: the number of IA5 characters in the subaddress may vary, subject to an upper limit of 19 IA5 characters.

## Annex B (normative): Compatibility checking

This annex is normative.

## B.1 Introduction

This annex describes the various compatibility checks which shall be carried out to ensure that the best matched MS and network capabilities are achieved on a call between a PLMN and the ISDN.

Three different processes of compatibility checking shall be performed:

- i) at the user-to-network interface on the calling side (see B.2);
- ii) at the network-user interface on the called side (see B.3.2);
- iii) user-to-user (see B 3.3).
- NOTE: In this context and throughout this annex the term "called user" is the end point entity which is explicitly addressed.

For details on the coding of the information required for compatibility checking, see annex C.

## B.2 Calling side compatibility checking

## B.2.1 Compatibility checking of the CM SERVICE REQUEST message

The network shall check if the service requested in the CM SERVICE REQUEST message is permitted for that subscriber.

## B.2.2 Compatibility/Subscription checking of the SETUP message

At the calling side the network shall check that the basic service(s) requested by the calling MS in the Bearer Capability information element(s) match(es) with the basic services provided to that subscriber by the PLMN. If for at least one bearer capability information element contained in the SETUP message a mismatch is detected, then the network shall proceed as follows:

- if the SETUP message contained two bearer capability information elements for only one of which a mismatch is detected, the network shall either:
  - under the conditions specified in 3GPP TS 07.01 (e.g. TS 61 and TS 62), accept the SETUP message with a CALL PROCEEDING message containing the, possibly negotiated, bearer capability information element for which no mismatch is detected, or
  - reject the call using one of the causes listed in annex H.
- otherwise the network shall reject the call using one of the causes listed in annex H.

Network services are described in 3GPP TS 02.02 and 3GPP TS 02.03 as bearer services and teleservices, respectively.

## B.3 Called side compatibility checking

In this sub-clause, the word "check" means that the MS examines the contents of the specified information element.

#### B.3.1 Compatibility checking with addressing information

If an incoming SETUP message is offered to the MS with addressing information (i.e. sub-address or called party number) the following shall occur:

a) if the MS has a DDI number or a sub-address, then the information in any Called Party BCD Number or any Called Party subaddress information elements of the incoming SETUP message shall be checked by the MS against the corresponding part of the number assigned to the user (e.g. for DDI) or the user's own sub-address.

In the cases of a mismatch, the MS shall release the call. In the case of a match, the compatibility checking described in B.3.2 and B.3.3 shall be performed.

- b) if the MS has no DDI number and no sub-address, then the Called Party BCD Number and Called Party Subaddress information element shall be ignored for the purposes of compatibility checking. The compatibility checking described in B.3.2 and B.3.3 shall be performed.
- NOTE: According to the user's requirements, compatibility checking can be performed in various ways from the viewpoint of execution order and information to be checked, e.g. first DDI number/sub-address and then bearer capability or vice versa.

## B.3.2 Network-to-MS compatibility checking

When the network is providing a basic service at the called side, the MS shall check that the basic service(s) offered by the network in the Bearer Capability information element(s) match(es) the basic services that the MS is able to support. If a mismatch is detected, then the MS shall proceed as follows:

- if the SETUP message contained two bearer capability information elements for only one of which a mismatch is detected, the MS shall either:
  - under the conditions specified in 3GPP TS 07.01 (e.g. TS 61 and TS 62), accept the SETUP message with a CALL CONFIRMED message containing the, possibly negotiated, bearer capability information element for which no mismatch is detected, or
  - reject the call using cause No. 88 "incompatible destination".
- otherwise the MS shall reject the offered call using a RELEASE COMPLETE message with cause No. 88 "incompatible destination".

When interworking with existing networks, limitations in network or distant user signalling (e.g. in the case of an incoming call from a PSTN or a call from an analogue terminal) may restrict the information available to the called MS in the incoming SETUP message (e.g. missing Bearer Capability Information Element or missing High Layer Compatibility Information Element). For compatibility checking, and handling of such calls see 3GPP TS 07.01.

## B.3.3 User-to-User compatibility checking

See 3GPP TS 07.01.

## B.4 High layer compatibility checking

See 3GPP TS 07.01.

## Annex C (normative): Low layer information coding principles

This annex is normative.

## C.1 Purpose

This annex describes principles that shall be used when the calling MS specifies information during call setup regarding low layer capabilities required in the network and by the destination terminal. Refer also to 3GPP TS 07.01.

NOTE: In this context and throughout this annex the term "called user" is the end point entity which is explicitly addressed. This may also be an explicitly addressed interworking unit (IWU) (see ITU-T I.500-Series Recommendations and ITU-T Recommendation X.31 case a).

## C.2 Principles

#### C.2.1 Definition of types of information

There are three different types of information that the calling PLMN user may specify during call setup to identify low layer capabilities needed in the network and in the destination terminal:

- a) type I information is information about the calling terminal which is only used at the destination end to allow a decision regarding terminal compatibility. An example would be the user information layer 3 protocol. Type I information is encoded in octets 5 to 7 of the low layer compatibility information element;
- b) type II information is only used by the network (PLMN) to which the calling user is connected for selection of PLMN specific network resources, e.g. channel type or specific functionality within the interworking function (IWF, see TS 09.07). This type of information is always present. An example is the connection element. Type II information is coded in:
  - i) octet 3 of the bearer capability information element when the information transfer capability required by the calling user is speech;
  - ii) octets 3, 4, 5, and optionally octet 7 of the bearer capability information element when the information transfer capability required by the calling user is not speech;
- c) type III information is required for selection of a basic service from the choice of basic services offered by the network and together with type II information for selection of an appropriate interworking function (IWF, see 3GPP TS 09.07), as well as for terminal compatibility checking at the destination terminal . An example is the information transfer capability. Type III information is always present and is encoded in:
  - i) octet 3 of the bearer capability information element when the information transfer capability required by the calling user is speech ;
  - ii) octets 3, 5, 6, 6a, 6b and 6c of the bearer capability information element when the information transfer capability required by the calling user is not speech;

#### C.2.2 Examination by network

Type I information is user-to-user (i.e. at the calling side not examined by network) while type II and III information should be available for examination by the destination user and the network.

NOTE: In the case of a mobile terminated call, if the type II and type III information is not sufficient for the selection of an appropriate interworking function, the type I information will also examined by the network.

## C.2.3 Location of type I information

Type I information (i.e. terminal information only significant to the called user) shall, when used, be included in the low layer compatibility information element.

## C.2.4 Location of types II and III information

Type II information is included in the bearer capability information element. Type III information is also included in the bearer capability information element. The network may use and modify type III information (e.g. to provide interworking).

In any case a modification of the bearer capability information element has to be performed when interworking to the fixed network (e.g. ISDN) is required, where the signalling of the radio interface has to be mapped to fixed network signalling (e.g. mapping of GSM BCIE to ISDN BCIE, see 3GPP TS 09.07).

## C.2.5 Relationship between bearer capability and low layer compatibility information elements

There shall be no contradiction of information between the low layer compatibility and the bearer capability at the originating side. However, as some bearer capability code points may be modified during the transport of the call (e.g. by the interworking function), this principle implies that there should be minimal duplication of information between the bearer capability information element and the low layer compatibility information element.

NOTE: If as a result of duplication, a contradiction occurs at the terminating side between the bearer capability information element and the low layer compatibility information element at the terminating side, the receiving entity shall ignore the conflicting information in the low layer compatibility information element.


## Annex D (informative): Examples of bearer capability information element coding

This annex is informative.

This annex gives examples of the coding of bearer capability information elements for various telecommunication services. This annex is included for information purposes only. In the case of any inconsistency between this annex and 3GPP TS 07.01 then 3GPP TS 07.01 shall take precedence over this annex.

# D.1 Coding for speech for a full rate support only mobile station

#### D.1.1 Mobile station to network direction





#### D.1.2 Network to mobile station direction




Figure D.2

- D.2 An example of a coding for modem access with V22-bis, 2,4 kbit/s, 8 bit no parity
- D.2.1 Mobile station to network direction, data compression allowed




Figure D.3

#### D.2.2 Network to mobile station direction, data compression possible




Figure D.4

# D.3 An example of a coding for group 3 facsimile (9,6 kbit/s, transparent)

## D.3.1 Mobile station to network direction

	8	7	б	5	4	3	2	1		
1	0	0				1 ity IEJ		0	octet	1
1	0 Le	0 ength d				1 pility			octet	2
	1 not ext		1 rate MS	0 GSMß	0 circ. mode	fa	1 acsimi group 3	le	octet	3
-	1 not ext	0 comp- ress.	1 unst tui			0 pt to pt			octet	4
-	1 not ext	0 access	0 8 id.	no i	0 rate ption	-	0 . 440 / 4!		octet	5
1	0 ext	0 laye	-	0 de		0 layer			octet	6
	0 ext	0 (syn)	0 no neg	1 (syn)		1 9.6 }	•	1	octet	ба
-	0 ext	16 kk	1 Dit/s rate	0 no NICtx	0 no NICrx	0 (par	1 rity) 1		octet	6b
-	1 not ext	Ũ	0 parent	0	-	0 none lem typ	-	0	octet	бс

Figure D.5

## D.3.2 Network to mobile station direction

	8	7	б	5	4	3	2	1		
+	0	0	0 Bea			1 ity IEI		0	octet	1
	0 Le	0 ength d	0 of the	•	0 c capal	1 pility	1 conte	1 nts	octet	2
	1 not ext	0 spare	1 spare	0 GSMß	0 circ. mode	0 3.1	1 kHz a ex PLM		octet	3
+	1 not ext	0 comp- ress.	unst	ruc-	1 full dupl.	0 pt to pt	0 no NIRR	de-	octet	4
	1 not ext	0 access	0 s id.	0 no 1 adar	-	-	0 .440/4	_	octet	5
	0 ext	0 laye	-			0 layer		0 sync	octet	6
	0 ext	0 (syn)	0 no neg	1 (syn)	0	1 9.6 }	•	1	octet	ба
	0 ext		1 pit/s . rate	0 no NICtx	0 no NICrx		1 rity)	-	octet	6b
+	1 not ext	0 transp	0 parent	0	-	0 none dem typ	-	0	octet	бс

Figure D.6

## Annex E (informative): Comparison between call control procedures specified in 3GPP TS 04.08 and ITU-T Recommendation Q.931

This annex is informative.

This annex summarizes a comparison of the procedures for call control as specified in ITU-T Recommendation Q.931 (blue book) and 3GPP TS 04.08.

If no comment is given, it means that the procedures specified in ITU-T Recommendation Q.931 and 3GPP TS 04.08 are similar. However, it should be noted that even in such cases the procedures may be described in slightly different ways in the two documents.

#### Table E.1/3GPP TS 04.08: Circuit-switched call control procedures

+ Procedure	Q.931	GSMß04.08
Call establishment at	5.1	5.2.1
the originating interface	5.1	5.2.1
- call request	5.1.1	5.2.1.1.1 en-bloc sending only
- B-channel selection originating	5.1.2	not applicable
- overlap sending	5.1.3	not supported
- invalid call information	5.1.4	5.2.1.1.2
<ul> <li>call proceeding, en-bloc sending</li> </ul>	5.1.5.1	5.2.1.1.3
<ul> <li>call proceeding, overlap sending</li> </ul>	5.1.5.2	not supported
<ul> <li>notification of interworking at the originating interf.</li> </ul>	5.1.6	5.2.1.1.4
- call confirmation indication	5.1.7	5.2.1.1.5
- call connected	5.1.8	5.2.1.1.6
- call rejection	5.1.9	5.2.1.1.7
<ul> <li>transit network selection</li> </ul>	5.1.10	5.2.1.1.8
Call establishment at the destination interface	5.2	5.2.2
- call indication	5.2.1	5.2.2.1 procedure for multiple terminal configuration not required, i.e. delivery of SETUP messages on broadcast data links is not supported
- compatibility checking	5.2.2	5.2.2.2 equivalent, except that delivery of SETUP mes- sages on broadcast data links is not supported
- B-channel selection destination	5.2.3	not applicable
- overlap receiving	5.2.4	not supported
- call confirmation information	5.2.5	5.2.2.3 equivalent, except that delivery of SETUP mes- sages on broadcast data links is not supported
<ul> <li>notification of interworking at the terminating interf.</li> </ul>	5.2.6	5.2.2.4
- call accept indication	5.2.7	5.2.2.5
- active indication	5.2.8	5.2.2.6 equivalent, except that

#### 3GPP TS 04.08 version 7.21.0 Release 1998

592

		SETUP messages are not sent on broadcast data links
<ul> <li>non-selected user clearing</li> </ul>	5.2.9	not applicable
Call clearing	5.3	5.4
- terminology	5.3.1	5.4.1 terminology adapted to GSMBapplications
- exception conditions	5.3.2	5.4.2 only case a) of sub-clause 5.3.2 of Rec. Q.931 ap- plies. All other excep- tions apply to functions which are not relevant to GSMS
<ul> <li>clearing initiated by the user/MS</li> </ul>	5.3.3	5.4.3
<ul> <li>clearing initiated by the network</li> </ul>	5.3.4	5.4.4
<ul> <li>clearing when tones/announcements are provided</li> </ul>	5.3.4.1	5.4.4.1.1 and 5.4.4.2.1 exception: if not already connected, the traffic channel is connected in order to provide the tone/announcement
<ul> <li>clearing when tones/announcements are not provided</li> </ul>	5.3.4.2	5.4.4.1.2 and 5.4.4.2.3
- completion of clearing	5.3.4.3	5.4.4.1.3 and 5.4.4.2.5
Clear collision	5.3.5	5.4.5
In-band tones and announcements	5.4	5.5.1
Restart procedure	5.5	not supported
Call rearrangements	5.6	5.3.4 call suspension/call re- establishment not suppor- ted on the radio path. The functions, if requi- red, are to be supported locally in the MS. On the radio interface, the notification procedure of Rec. Q.931 (sub-clause 5.6.7) applies
Call collisions	5.7	5.5.2 call collisions cannot occur
Emergency call esta- blishment at the ori- ginating interface	not specified not supported	5.2.1.2
In-call modification	Annex O Rec. Q.931 is incomplete with regard to in-call modification procedures	5.3.4
DTMF protocol control	not specified	5.3.3

not supported	
not specified not supported	5.5.4
5.8.10, 5.8.11	5.5.3
7	GSMB04.10
5.9	5.3.1
	not specified not supported 5.8.10, 5.8.11 7

## Annex F (informative): GSM specific cause values for radio resource management

This annex is informative.

Cause value = 0 Normal event;

indicates that the channel is released because of a normal event or that an assignment or handover is successfully, and normally, completed.

Cause value = 1 Abnormal release, unspecified;

indicates that the channel is released because of an abnormal event without specifying further reasons.

Cause value = 2 Abnormal release, channel unacceptable;

indicates that the channel type or channel characteristics are not acceptable.

Cause value = 3 Abnormal release, timer expired;

indicates that the release is caused by a timer expiry.

Cause value = 4 Abnormal release, no activity on the radio path;

indicates that some supervisory function has detected that the channel is not active.

Cause value = 5 Pre-emptive release;

indicates that the channel is released in order to be allocated to a call with priority (e.g. an emergency call).

Cause value = 8 Handover impossible, timing advance out of range;

indicates that a handover is unsuccessful because the target BTS is beyond the normal range and the target BTS would not accept an out of range timing advance.

Cause value = 9 Channel mode unacceptable

indicates that the MS does not have the capability to handle the requested mode or type of channel.

Cause value = 10 Frequency not implemented

indicates that the MS does not have the capability to operate on (at least one of) the requested frequency(ies).

Cause value = 65 Call already cleared;

indicates that a handover is unsuccessful because the connection has been released by the network or the remote user.

Cause value = 95 Semantically incorrect message;

See annex H, sub-clause H5.10.

Cause value = 96 Invalid mandatory information;

See annex H, sub-clause H6.1.

Cause value = 97 Message type non-existent or not implemented;

See annex H, sub-clause H6.2.

Cause value = 98 Message type not compatible with protocol state;

See annex H, sub-clause H6.3

Cause value = 100 Conditional IE error;

See annex H, sub-clause H6.5

Cause value = 101 No cell allocation available;

indicates that an assignment or handover is unsuccessful because the MS has no current CA.

Cause value = 111 Protocol error unspecified;

See annex H, sub-clause H6.8.

## Annex G (informative): GSM specific cause values for mobility management

This annex describes the cause values for the mobility management procedures for non-GPRS services (MM) and GPRS services (GMM). Sub-clauses G1 to G5 are valid for both MM and GMM. However, the following codes are applicable for non-GPRS services only:

#38 Call cannot be identified

Sub-clause G.6 applies only for GMM procedures.

## G.1 Causes related to MS identification

Cause value = 2 IMSI unknown in HLR

This cause is sent to the MS if the MS is not known (registered) in the HLR. This cause code does not affect operation of the GPRS service, although is may be used by a GMM procedure.

Cause value = 3 Illegal MS

This cause is sent to the MS when the network refuses service to the MS either because an identity of the MS is not acceptable to the network or because the MS does not pass the authentication check, i.e. the SRES received from the MS is different from that generated by the network.

Cause value = 4 IMSI unknown in VLR

This cause is sent to the MS when the given IMSI is not known at the VLR.

Cause value = 5 IMEI not accepted

This cause is sent to the MS if the network does not accept emergency call establishment using an IMEI.

Cause value = 6 Illegal ME

This cause is sent to the MS if the ME used is not acceptable to the network, e.g. blacklisted.

## G.2 Cause related to subscription options

Cause value = 11 PLMN not allowed

This cause is sent to the MS if it requests location updating in a PLMN where the MS, by subscription or due to operator determined barring is not allowed to operate.

Cause value = 12 Location Area not allowed

This cause is sent to the MS if it requests location updating in a location area where the MS, by subscription, is not allowed to operate.

Cause value = 13 Roaming not allowed in this location area

This cause is sent to an MS which requests location updating in a location area of a PLMN which offers roaming to that MS in that Location Area, by subscription.

# G.3 Causes related to PLMN specific network failures and congestion

Cause value = 17 Network failure

This cause is sent to the MS if the MSC cannot service an MS generated request because of PLMN failures, e.g. problems in MAP.

Cause value = 22 Congestion

This cause is sent if the service request cannot be actioned because of congestion (e.g. no channel, facility busy/congested etc.)

## G.4 Causes related to nature of request

Cause value = 32 Service option not supported

This cause is sent when the MS requests a service/facility in the CM SERVICE REQUEST message which is not supported by the PLMN.

Cause value = 33 Requested service option not subscribed

This cause is sent when the MS requests a service option for which it has no subscription.

Cause value = 34 Service option temporarily out of order

This cause is sent when the MSC cannot service the request because of temporary outage of one or more functions required for supporting the service.

Cause value = 38 Call cannot be identified

This cause is sent when the network cannot identify the call associated with a call re-establishment request.

## G.5 Causes related to invalid messages

Cause value = 95 Semantically incorrect message.

See annex H, sub-clause H.5.10.

Cause value = 96 Invalid mandatory information.

See annex H, sub-clause H.6.1.

Cause value = 97 Message type non-existent or not implemented.

See annex H, sub-clause H.6.2.

Cause value = 98 Message not compatible with protocol state.

See annex H, sub-clause H.6.3.

Cause value = 99 Information element non-existent or not implemented

See annex H, sub-clause H.6.4.

Cause value = 100 Conditional IE error.

See annex H, sub-clause H.6.5.

Cause value = 101 Message not compatible with protocol state

See annex H, sub-clause H.6.6.

Cause value = 111 Protocol error, unspecified

See annex H, sub-clause H.6.8.

## G.6 Additional cause codes for GMM

Cause value = 7 GPRS services not allowed

This cause is sent to the MS if it requests an IMSI attach for GPRS services, but is not allowed to operate GPRS services.

Cause value = 8 GPRS services and non-GPRS services not allowed

This cause is sent to the MS if it requests a combined IMSI attach for GPRS and non-GPRS services, but is not allowed to operate either of them.

Cause value = 9 MS identity cannot be derived by the network

This cause is sent to the MS when the network cannot derive the MS's identity from the P-TMSI in case of inter-SGSN routing area update.

Cause value = 10 Implicitly detached

This cause is sent to the MS either if the network has implicitly detached the MS, e.g. some while after the Mobile reachable timer has expired, or if the GMM context data related to the subscription dose not exist in the SGSN e.g. because of a SGSN restart.

Cause value = 14 GPRS services not allowed in this PLMN

This cause is sent to the MS which requests GPRS service in a PLMN which does not offer roaming for GPRS services to that MS.

Cause value = 16 MSC temporarily not reachable

This cause is sent to the MS if it requests a combined GPRS attach or routing are updating in a PLMN where the MSC is temporarily not reachable via the GPRS part of the GSM network.

## Annex H (informative): GSM specific cause values for call control

## H.1 Normal class

#### H.1.1 Cause No. 1 "unassigned (unallocated) number"

This cause indicates that the destination requested by the mobile station cannot be reached because, although the number is in a valid format, it is not currently assigned (allocated).

#### H.1.2 Cause No. 3 "no route to destination"

This cause indicates that the called user cannot be reached because the network through which the call has been routed does not serve the destination desired.

#### H.1.3 Cause No. 6 "channel unacceptable"

This cause indicates the channel most recently identified is not acceptable to the sending entity for use in this call.

## H.1.4 Cause No. 8 "operator determined barring"

This cause indicates that the MS has tried to access a service that the MS's network operator or service provider is not prepared to allow.

## H.1.5 Cause No.16 "normal call clearing"

This cause indicates that the call is being cleared because one of the users involved in the call has requested that the call be cleared.

Under normal situations, the source of this cause is not the network.

## H.1.6 Cause No.17 "user busy"

This cause is used when the called user has indicated the inability to accept another call.

It is noted that the user equipment is compatible with the call.

## H.1.7 Cause No. 18 "no user responding"

This cause is used when a user does not respond to a call establishment message with either an alerting or connect indication within the prescribed period of time allocated (defined by the expiry of either timer T303 or T310).

## H.1.8 Cause No. 19 "user alerting, no answer"

This cause is used when a user has provided an alerting indication but has not provided a connect indication within a prescribed period of time.

#### H.1.9 Cause No. 21 "call rejected"

This cause indicates that the equipment sending this cause does not wish to accept this call, although it could have accepted the call because the equipment sending this cause is neither busy nor incompatible.

#### H.1.10 Cause No. 22 "number changed"

This cause is returned to a calling mobile station when the called party number indicated by the calling mobile station is no longer assigned. The new called party number may optionally be included in the diagnostic field. If a network does not support this capability, cause No. 1 "unassigned (unallocated) number" shall be used.

#### H.1.11 Cause No. 25 "pre-emption"

This cause is returned to the network when a mobile station clears an active call which is being pre-empted by another call with higher precedence.

#### H.1.12 Cause No. 26 "non-selected user clearing"

Not supported. Treated as cause no. 31.

#### H.1.13 Cause No. 27 "destination out of order"

This cause indicates that the destination indicated by the mobile station cannot be reached because the interface to the destination is not functioning correctly. The term "not functioning correctly" indicates that a signalling message was unable to be delivered to the remote user; e.g., a physical layer or data link layer failure at the remote user, user equipment off-line, etc.

#### H.1.14 Cause No. 28 "invalid number format (incomplete number)"

This cause indicates that the called user cannot be reached because the called party number is not a valid format or is not complete.

#### H.1.15 Cause No. 29 "facility rejected"

This cause is returned when a facility requested by user can not be provided by the network.

#### H.1.16 Cause No. 30 "response to STATUS ENQUIRY"

This cause is included in STATUS messages if the message is sent in response to a STATUS ENQUIRY message. See also sub-clause 5.5.3.

## H.1.17 Cause No. 31 "normal, unspecified"

This cause is used to report a normal event only when no other cause in the normal class applies.

## H.2 Resource unavailable class

#### H.2.1 Cause No. 34 "no circuit/channel available"

This cause indicates that there is no appropriate circuit/channel presently available to handle the call.

#### H.2.2 Cause No. 38 "network out of order"

This cause indicates that the network is not functioning correctly and that the condition is likely to last a relatively long period of time; e.g., immediately re-attempting the call is not likely to be successful.

#### H.2.3 Cause No. 41 "temporary failure"

This cause indicates that the network is not functioning correctly and that the condition is not likely to last a long period of time; e.g., the mobile station may wish to try another call attempt almost immediately.

### H.2.4 Cause No. 42 "switching equipment congestion"

This cause indicates that the switching equipment generating this cause is experiencing a period of high traffic.

#### H.2.5 Cause No. 43 "access information discarded"

This cause indicates that the network could not deliver access information to the remote user as requested; i.e., a userto-user information, low layer compatibility, high layer compatibility, or sub-address as indicated in the diagnostic.

It is noted that the particular type of access information discarded is optionally included in the diagnostic.

## H.2.6 Cause No. 44 "requested circuit/channel not available"

This cause is returned when the circuit or channel indicated by the requesting entity cannot be provided by the other side of the interface.

#### H.2.7 Cause No. 47 "resource unavailable, unspecified"

This cause is used to report a resource unavailable event only when no other cause in the resource unavailable class applies.

## H.3 Service or option not available class

#### H.3.1 Cause No. 49 "quality of service unavailable"

This cause indicates to the mobile station that the requested quality of service, as defined in ITU-T Recommendation X.213, cannot be provided.

## H.3.2 Cause No. 50 "Requested facility not subscribed"

This cause indicates that the requested supplementary service could not be provided by the network because the user has no completed the necessary administrative arrangements with its supporting networks.

## H.3.3 Cause No. 55 "Incoming calls barred within the CUG"

This cause indicates that although the called party is a member of the CUG for the incoming CUG call, incoming calls are not allowed within this CUG.

## H.3.4 Cause No. 57 "bearer capability not authorized"

This cause indicates that the mobile station has requested a bearer capability which is implemented by the equipment which generated this cause but the mobile station is not authorized to use.

## H.3.5 Cause No. 58 "bearer capability not presently available"

This cause indicates that the mobile station has requested a bearer capability which is implemented by the equipment which generated this cause but which is not available at this time.

## H.3.6 Cause No. 63 "service or option not available, unspecified"

This cause is used to report a service or option not available event only when no other cause in the service or option not available class applies.

## H.3.7 Cause No. 68 "ACM equal to or greater than ACMmax"

This cause is used by the mobile to indicate that call clearing is due to ACM being greater than or equal to ACMmax.

## H.4 Service or option not implemented class

## H.4.1 Cause No. 65 "bearer service not implemented"

This cause indicates that the equipment sending this cause does not support the bearer capability requested.

## H.4.2 Cause No. 69 "Requested facility not implemented"

This cause indicates that the equipment sending this cause does not support the requested supplementary service.

## H.4.3 Cause No. 70 "only restricted digital information bearer capability is available"

This cause indicates that one equipment has requested an unrestricted bearer service, but that the equipment sending this cause only supports the restricted version of the requested bearer capability.

## H.4.4 Cause No. 79 "service or option not implemented, unspecified"

This cause is used to report a service or option not implemented event only when no other cause in the service or option not implemented class applies.

## H.5 Invalid message (e.g., parameter out of range) class

## H.5.1 Cause No. 81 "invalid transaction identifier value"

This cause indicates that the equipment sending this cause has received a message with a transaction identifier which is not currently in use on the MS-network interface.

### H.5.2 Cause No. 87 "user not member of CUG"

This cause indicates that the called user for the incoming CUG call is not a member of the specified CUG.

#### H.5.3 Cause No. 88 "incompatible destination"

This cause indicates that the equipment sending this cause has received a request to establish a call which has low layer compatibility, high layer compatibility, or other compatibility attributes (e.g., data rate) which cannot be accommodated.

#### H.5.4 Cause No. 91 "invalid transit network selection"

For further study. Treated as cause no. 95.

#### H.5.5 Cause No. 95 "semantically incorrect message"

This cause is used to report receipt of a message with semantically incorrect contents (see sub-clause 8.8).

## H.6 Protocol error (e.g., unknown message) class

#### H.6.1 Cause No. 96 "invalid mandatory information"

This cause indicates that the equipment sending this cause has received a message with a non-semantical mandatory IE error (see sub-clause 8.5).

## H.6.2 Cause No. 97 "message type non-existent or not implemented"

This cause indicates that the equipment sending this cause has received a message with a message type it does not recognize either because this is a message not defined, or defined but not implemented by the equipment sending this cause.

## H.6.3 Cause No. 98 "message type not compatible with protocol state"

This cause indicates that the equipment sending this cause has received a message not compatible with the protocol state (sub-clause 8.4).

## H.6.4 Cause No. 99 "information element non-existent or not implemented"

This cause indicates that the equipment sending this cause has received a message which includes information elements not recognized because the information element identifier is not defined or it is defined but not implemented by the equipment sending the cause. However, the information element is not required to be present in the message in order for the equipment sending the cause to process the message.

## H.6.5 Cause No. 100 "conditional IE error"

This cause indicates that the equipment sending this cause has received a message with conditional IE errors (see subclause 8.7.2).

## H.6.6 Cause No. 101 "message not compatible with protocol state"

This cause indicates that a message has been received which is incompatible with the protocol state or that a STATUS message has been received indicating an incompatible call state.

#### H.6.7 Cause No. 102 "recovery on timer expiry"

This cause indicates that a procedure has been initiated by the expiry of a timer in association with TS 04.08 error handling procedures.

#### H.6.8 Cause No. 111 "protocol error, unspecified"

This cause is used to report a protocol error event only when no other cause in the protocol error class applies.

## H.7 Interworking class

#### H.7.1 Cause No. 127 "interworking, unspecified"

This cause indicates that there has been interworking with a network which does not provide causes for actions it takes; thus, the precise cause for a message which is being sent cannot be ascertained.

## Annex I (informative): GSM specific cause values for session management

This annex is informative.

## I.1 Causes related to nature of request

Cause value = 25 LLC or SNDCP failure

This cause code is used by the MS indicate that a PDP context is deactivated because of a LLC or SNDCP failure (e.g. if the SM receives a *SNSM-STATUS.request* message with cause "*DM received*" or "*invalid XID response*", see 04.65 [78])

Cause value = 26 Insufficient resources

This cause code is used by the MS or by the network to indicate that a PDP context activation request or PDP context modification request cannot be accepted due to insufficient resources.

Cause value = 27 Unknown or missing access point name

This cause code is used by the network to indicate that the requested service was rejected by the external packet data network because the access point name was not included although required or if the access point name could not be resolved.

Cause value = 28 Unknown PDP address or PDP type

This cause code is used by the network to indicate that the requested service was rejected by the external packet data network because the PDP address or type could not be recognised.

Cause value = 29 User authentication failed

This cause code is used by the network to indicate that the requested service was rejected by the external packet data network due to a failed user authentication.

Cause value = 30 Activation rejected by GGSN

This cause code is used by the network to indicate that the requested service was rejected by the GGSN..

Cause value = 31 Activation rejected, unspecified

This cause code is used by the network to indicate that the requested service was rejected due to unspecified reasons.

Cause value = 32 Service option not supported

This cause code is used by the network when the MS requests a service which is not supported by the PLMN.

Cause value = 33 Requested service option not subscribed

See Annex G, sub-clause 4.

Cause value = 34 Service option temporarily out of order

See Annex G, sub-clause 4.

Cause value = 35 NSAPI already used

This cause code is used by the network to indicate that the NSAPI requested by the MS in the PDP context activation is already used by another active PDP context of this MS.

Cause value = 36 Regular PDP context deactivation

This cause code is used to indicate a regular MS or network initiated PDP context deactivation.

Cause value = 37 QoS not accepted

This cause code is used by the MS if the new QoS cannot be accepted that were indicated by the network in the PDP Context Modification procedure.

Cause value = 38 Network failure

This cause code is used by the network to indicate that the PDP context deactivation is caused by an error situation in the network.

Cause value = 39 Reactivation requested

This cause code is used by the network to request a PDP context reactivation after a GGSN restart.

Cause value = 40 Feature not supported

This cause code is used by the MS to indicate that the PDP context activation initiated by the network is not supported by the MS.

## I.2 Causes related to invalid messages

Cause value = 81 Invalid transaction identifier value.

See annex H, sub-clause H.5.1.

Cause value = 95 Semantically incorrect message.

See annex H, sub-clause H.5.10.

Cause value = 96 Invalid mandatory information.

See annex H, sub-clause H.6.1.

Cause value = 97 Message type non-existent or not implemented.

See annex H, sub-clause H.6.2.

Cause value = 98 Message not compatible with protocol state.

See annex H, sub-clause H.6.3.

Cause value = 99 Information element non-existent or not implemented

See annex H, sub-clause H.6.4.

Cause value = 100 Conditional IE error.

See annex H, sub-clause H.6.5.

Cause value = 101 Message not compatible with protocol state

See annex H, sub-clause H.6.6.

Cause value = 111 Protocol error, unspecified

See annex H, sub-clause H.6.8.

## Annex J (informative): Algorithm to encode frequency list information elements

## J.1 Introduction

Some information elements encode frequency lists with a special method. The main specification specifies the meaning of the fields and hence the way to decode them, but the corresponding encoding algorithm is difficult to infer from the decoding algorithm. This annex is intended as an aid for implementers of the encoding algorithm.

It could be shown that any set of frequency with less or the same number of frequencies as the number of words can be encoded with a careful choice of F1, F2, and so on, i.e. that a set of Wi can be found so that the decoding algorithm given in the main sub-clause will give back the frequency set. The right order is not the order of the frequency values.

## J.2 General principle

The encoding algorithm is based on a recursive dichotomy of both the range (i.e. the set of values that are possible) and the subset (the values to encode).

The dichotomy is best understood if the range is seen as a circle. For instance, for the 1023 range:




Figure J.1: Circular arrangement of 0..1023

The dichotomy consists in finding a value in the subset such that the diameter determined by this value splits the subset in two equal or nearly equal subsets. In the following case, we see that value 290 is acceptable (the two subsets have 3 elements), when value 250 is not acceptable (the two subsets have 4 and 2 elements):





Figure J.2: Example of dichotomy

The pivot value is part of the information field, then the two subsets are renumbered and the same algorithm is applied again on each of them. Because the range is halved at each step, the number of bits needed to encode a pivot value is 1 bit less than the number of bits needed to encode the parent pivot value.

The convention is that if the number of values is even, the left subset (that is to say the values that can be expressed as the pivot value minus some integer between 1 and half the range) will have 1 element more than the right subset.

At each step the subset is numbered from 0 to the range minus 1. The coding in the information field of the pivot value is its value as renumbered, plus 1. Value 0 is reserved to indicate no element.

The order of appearance in the information field of the successive pivot values is particular. If we present the values as organized as a tree, with the left child being the pivot of the left subset and the right child the pivot of the right subset, the order of appearance is given by the following tree:







This order has been chosen so that:

- a) whatever the number N of elements in the set, the meaningful nodes are the first N and the value for all nodes from N+1 on are null (if sent);
- b) the tree and all subtrees are balanced.

Important properties of these trees are used in the algorithms (with generation 1 corresponding to the root):

Generation g contains  $2^{g-1}$  nodes, and their indices are  $2^{g-1}$  to  $2^{g-1}$ ;

For generation g, nodes  $2^{g-1}$  to  $2^{g-1}+2^{g-2}-1$  are left children, the others are right children;

If node k belongs to generation g, its left child is node  $k + 2^{g-1}$ , and its right child is  $k + 2^{g}$ ;

Reciprocally, if k is a left child from generation g, its parent node is node k -  $2^{g-2}$ , and if k is a right child of generation g, its parent is node k -  $2^{g-1}$ .

## J.3 Performances

The number of bits needed to encode a given set of values depends on the number of values and on the range they can span.

For the application on the BCCH and the SACCH (CA and BA information ) 16 octets are available, and the number of frequencies that can be encoded in one information element is the following:

Range	Number of frequencies
513 to 1024 257 to 512 129 to 256 113 to 128	2 to 16 (17 if frequency 0 is in) 2 to 18 2 to 22 2 to 29
up to 112	any

With two messages (for the BA) the number of frequencies that can be encoded is the following:

Range	Number of frequencies
513 to 1024	2 to 36 (note 1)
257 to 512	2 to 40 (note 2)
225 to 256	2 to 51 (note 3)
up to 224	any

- NOTE 1: A 1024 range can be split cyclically in to two 512 ranges each with less than 18 frequencies; each subset is coded in one message with 512 range format.
- NOTE 2: A 512 range can be split in to two consecutive 256 ranges. If both sub-ranges contain 22 frequencies or less, it is possible to code each of these in a messages using the 256 range format. Otherwise one of the two ranges contains 23 frequencies or more: 22 of them can be coded in one message using the 256 range format and the remaining frequencies (numbering less than or equal to 18) can be coded in the other message using the 512 range format.
- NOTE 3: The principles described in notes 1 and 2, above apply in this case.

The frequency short list information element allows the following:

Range	Number of frequencies
513 to 1024	2 to 7 (8 if frequency 0 is in)
257 to 512	2 to 8
129 to 256	2 to 9
57 to 128	2 to 12
up to 56	any

The number of frequencies as a function of the range and the length in octets of the variable length frequency list information element (including the message type and length fields) is given by the following table:

Range	513 to 1024	257 to 512	129 to 256	up to 128	variable bit map
octets					
5	1	1	1	1	8
6	2	2 3	3	3	16
7	3	3	4	4	24
8	4	4	5	6	32
9	5	6	6	8	40
10	6	7	8	10	48
11	7	8	9	12	56
12	9	9	11	14	64
13	10	11	13	16	72
14	11	12	14	18	80
15	12	13	16	21	88
16 17	13 14	15 16	18 20	24 26	96 104
18	16	18	20	20	104
19	17	19	24	32	120
20	18	21	26		128
21	20	22	28		136
22	21	24	30		144
23	22	26	32		152
24	24	27	34		160
25	25	29	37		168
26	26	30	40		176
27	28	32	42		184
28	29	34	45		192
29	30	36	48		200
30	32	38	50		208
31	33	40	53		216
32	35	42	56		224

Table J.1/3GPP TS 04.08: Performance of the variable length frequency list information e	lement

## J.4 Encoding algorithm

The choice is done recursively as given by the following programs, written in ADA:

Let us define the recursive procedure:

procedure ENCODE\_SUBTREE(in INDEX : INTEGER; in SET : SET\_OF\_VALUE; in RANGE : INTEGER);

This procedure is given a set of integer values and an index. It chooses one of those values and computes the corresponding W(INDEX) (considered as a global variable), it splits the set less the value in two equal or nearly equal subsets, and calls itself recursively for each of those subsets, with suitable INDEX.

Assumption: all values in SET lie (inclusively) between 0 and RANGE-1, and they are all distinct.

As written, the program does not assume special values for the range. With a range such as  $2^{k}$ -1, some expressions can be simplified.

```
Declarative part:
    INDEX_IN_SET : INTEGER;
    begin
First the program tests the leaf conditions :
    if SET'SIZE=0 then
        W(INDEX) := 0;
        return;
    elsif SET'SIZE=1 then
        W(INDEX) := 1 + SET(1);
```

return; end if;

The following program finds a value in the set such that exactly (SET'SIZE-1)/2 values from the set are between this value plus 1 and this value plus half the range :

```
declare
        N : INTEGER;
        J : INTEGER;
      begin
        for I in 1..SET'SIZE loop
          N := 0;
          for J in 1..SET'SIZE loop
            if (SET(J)-SET(I)) mod RANGE <= (RANGE-1)/2 then
             N := N+1;
            end if;
          end loop;
The test compares N-1 because the possible pivot value is counted.
          if N-1 = (SET'SIZE-1)/2 then
            INDEX_IN_SET := I;
            exit;
          end if;
        end loop;
      end;
```

INDEX\_IN\_SET is then the index in the list of the pivot value.

The following sets W(INDEX)

W(INDEX) := SET(INDEX\_IN\_SET) + 1;

Then the program does the same thing for the two halves of the range delimited by W(INDEX) and W(INDEX)+RANGE/2. First the left subset:

```
declare
  SUBSET : SET_OF_VALUE(1..SET'SIZE/2);
  SUBSET_INDEX : INTEGER;
 ORIGIN_VALUE : INTEGER;
begin
  ORIGIN_VALUE := (SET(INDEX_IN_SET] + (RANGE-1)/2
                 + 1) mod RANGE;
  SUBSET INDEX:=1;
  for I in 1..SET'SIZE loop
    if (SET(I)-ORIGIN_VALUE) mod RANGE) < RANGE/2 then
      SUBSET(SUBSET_INDEX) :=
        (SET(I) - ORIGIN_VALUE) mod RANGE;
      SUBSET_INDEX := SUBSET_INDEX + 1;
    end if;
  end loop;
  ENCODE_SUBTREE(
     INDEX := INDEX +
        GREATEST_POWER_OF_2_LESSER_OR_EQUAL_TO(INDEX),
      SET := SUBSET,
      RANGE := RANGE/2);
```

end;

Then the right subset:

```
declare
 SUBSET : SET_OF_VALUE(1..(SET'SIZE-1)/2);
  SUBSET_INDEX : INTEGER;
 ORIGIN_VALUE : INTEGER;
begin
  ORIGIN_VALUE := (SET(INDEX_IN_SET] + 1) mod RANGE;
  SUBSET_INDEX:=1;
  for I in 1..SET'SIZE loop
   if (SET(I)-ORIGIN_VALUE) mod RANGE) < RANGE/2 then
      SUBSET(SUBSET_INDEX) :=
        (SET(I) - ORIGIN_VALUE) mod RANGE;
      SUBSET_INDEX := SUBSET_INDEX + 1;
   end if;
  end loop;
  ENCODE_SUBTREE(
   INDEX := INDEX +
      2*GREATEST_POWER_OF_2_LESSER_OR_EQUAL_TO(INDEX),
    SET := SUBSET,
   RANGE := (RANGE-1)/2;
```

end;

end ENCODE\_SUBTREE;

The initial call of the procedure depends on the format. Given some set to encode, the first problem is to verify that it can be encoded, and by so doing to choose the format.

First the encoding process must find the minimum range of the set, that is to say the minimum value R such that there exists one frequency  $F_0$  in the set such that all frequencies in the set can be written  $(F_0 + N) \mod 1024$ , with some N,  $0 \le N \le R-1$ . The choice of the format depends on R and the number of frequencies : the 512 range format can be chosen only if R $\le$ 512, the 256 range format can be chosen only if R $\le$ 256, the 128 range format can be chosen only if R $\le$ 128.

If the chosen format is "1024 range", then the program must first check if frequency 0 is in the set. If so the F0 subfield is set to 1, and frequency 0 is removed from the set. Otherwise, the F0 subfield is set to 0. Then ENCODE\_SUBTREE is called with INDEX := 1, SET set to the set of values equal to the ARFCN of all frequencies minus 1, and RANGE := 1023.

If the chosen format is "512 range", "256 range" or "128 range",  $F_0$  is chosen as ORIG-ARFCN and ENCODE\_SUBTREE is called with INDEX := 1, SET set to the set of values equal to the ARFCN of all frequencies except  $F_0$ , minus  $F_0+1$ , and RANGE set respectively to 511, 255 or 127.

### J.5 Decoding

The decoding algorithm, as given below, is the inverse transform of the program given in the previous sub-clause, for the specific case where the original range is a power of 2 minus 1. It is given a set of integer values W(i), and an original range R, and it builds a set of values from 0...R-1.

The program is here written so that the fact that it is the inverse of the encoding program needs no more proof.

procedure DECODE(in W : array <> of INTEGER; out SET : SET\_OF\_VALUE; in ORIGINAL\_RANGE : INTEGER);

-- local variablesINDEX : 1..W'SIZE; RANGE : INTEGER;N : INTEGER;

begin for K in 1..W'SIZE loop

The next loop follows the tree from child to parent, from the node of index K to the root (index 1). For each iteration the node of index INDEX is tackled. The corresponding range is RANGE, and N is the value of the element in the range defined by the node.

The data are set to their initial values :

INDEX := K; RANGE := ORIGINAL\_RANGE / GREATEST\_POWER\_OF\_2\_LESSER\_OR\_EQUAL\_TO(INDEX); N := W(INDEX) - 1;

while INDEX>1 loop

Due to the assumption that the original range is a power of two minus one, the range for the parent node can be easily computed, and does not depend upon whether the current node is a left or right child :

RANGE := 2\*RANGE + 1;

Let us note  $J := 2^{g-1}$ , g being the generation of node INDEX. We have J =GREATEST\_POWER\_OF\_2\_LESSER\_OR\_EQUAL\_TO(INDEX). The numbering used in the tree is such that the nodes of index J to J + J/2 - 1 are left children, and the nodes of index J/2 to J+J-1 are right children. Hence an easy test to distinguish left and right children: if 2\*INDEX <

3\*GREATEST\_POWER\_OF\_2\_LESSER\_OR\_EQUAL\_TO(INDEX) -- left child

then

The next computation gives the index of the parent node of the node of index INDEX, for a left child :

INDEX := INDEX -GREATEST\_POWER\_OF\_2\_LESSER\_OR\_EQUAL\_TO(INDEX)/2;

The next formula is the inverse of the renumbering appearing in the encoding for a left child. It gives the value of the parent node in the range defined by the grand-parent node:

N := (N + W(INDEX) - 1 + (RANGE-1)/2 + 1)mod RANGE: else -- right child

The next computation gives the index of the parent node of the node of index INDEX, for a right child :

INDEX := INDEX - GREATEST\_POWER\_OF\_2\_LESSER\_OR\_EQUAL\_TO(INDEX);

The next formula is the inverse of the renumbering appearing in the encoding for a right child:

 $N := (N + W(INDEX) - 1 + 1) \mod RANGE;$ end if; end loop; F(K) := N;end loop; end;

A careful study will show that the programs given in the main part of the Technical Specification are equivalent to the one presented here. The main difference is the use of different remnant variables to remove most of the calls to the function giving the greatest power of 2 less than or equal to some integer.

The decoding must be terminated by the correction specific to the format.

#### J.6A detailed example

Let us take the following subset of 16 elements of the set [0..1023] : [13, 71, 122, 191, 251, 321, 402, 476, 521, 575, 635, 701, 765, 831, 906, 981]

Range 1024 format will be used. Frequency 0 is not in the set, thus field F0 is set to 0. The set is renumbered, so as to give a subset of 0.1022 : [12, 70, 121, 190, 250, 320, 401, 475, 520, 574, 634, 700, 764, 830, 905, 980].

For the first node (corresponding to W(1)), the value 121 satisfies the requirements. The opposite value is 121 + 511 =632. There are 8 values between 633 and 120 (namely the left-hand subset 634, 700, 764, 830, 905, 980, 12 and 70), and 7 values between 122 and 632 (namely the right-hand subset 190, 250, 320, 401, 475, 520 and 574).

The encoded value W(1) is 121 + 1, i.e. 122.

The second node (corresponding to W(2)) is the left-hand child of the first node. The corresponding subtree has to encode for the left-hand subset, renumbered beginning at 633. This gives the following 8 element subset of 0..510, ordered as resulting from the example of algorithm : [402, 460, 1, 67, 131, 197, 272, 347]. Out of these values, 1 splits the set in 4 and 3, and the encoded value W(2) is 2.

Similarly, the third node (W(3)) is the right-hand child of the first node and then the corresponding subtree encodes for the right-hand subset, renumbered starting at 122. This gives the following set of 0..510 : [68, 128, 198, 279, 353, 398, 452]. Out of these values, 68 splits the set into 3 and 3, and the encoded value W(3) is 69.

The same method is applied for all nodes, giving the following encoded values per node:

node	value	node	value
1	122	9	83
2	2	10	3
3	69	11	24
4	204	12	67
5 6	75	13	54
6	66	14	64
7	60	15	70
8	70	16	9

The encoding then consists in formatting, in that order :

122 on 10 bits, then 2 and 69 on 9 bits each, then 204, 75, 66 and 60 on 8 bits each, then 70, 83, 3, 24, 67, 54, 64 and 70 on 7 bits each, and finally 9 on 6 bits.

Conversely the decoding can be done easily. For instance for node 2, the original value is:

(122 - 512 + 2) smod 1023 = 635

For node 14, we have as original value:

(122 - 512 + (2 + (66 + 64)smod 255)smod 511)smod 1023 = 765

### Annex K (informative): Default Codings of Information Elements

The information in this annex does NOT define the value of any IEI for any particular message. This annex exists to aid the design of new messages, in particular with regard to backward compatibility with phase 1 mobile stations.

### K.1 Common information elements

For the common information elements types listed below, the default coding of information element identifier bits is summarized in table K.1/3GPP TS 04.08.

									Reference sub-clause
8	7	6	5	4	3	2	1		
1	:	:	:	-	-	-	-	Type 1 info elements	
1	1	1	1	-	-	-	-	Note 1	
0	:	:	:	:	:	:	:	Type 3 & 4 info elements	
0	0	0	1	0	0	0	1	Note 1	
0	0	0	1	0	0	1	1	Location Area	
								Identification	10.5.1.3
0							1	_	10.5.1.4
								Note 1	
0	0	0	1	1	1	1	1	Note 1	
0	0	1	0	0	0	0	0	Mobile Station classmark 3	10.5.1.7
	A	11	ot	zhe	er	va	alu	Spare Half Octet es are reserved	10.5.1.8

## Table K.1/3GPP TS 04.08: Default information element identifier coding for common information elements

NOTE 1: These values were allocated but never used in earlier phases of the protocol.

NOTE 2: For GPRS common information elements no default values are defined:

### K.2 Radio Resource management information elements

For the Radio Resource management information elements listed below, the default coding of the information element identifier bits is summarized in table K.2/3GPP TS 04.08.

			Reference sub-clause
8765	5432	1	
1 : : :	:	- Type 1 info	
		elements	
		- Cipher Mode Setting	10.5.2.9
	0 – – –		10.5.2.10
	1		
1 1 0 1	1	- Synchronization Indication	10.5.2.39
1 1 1 0	0	- Channel Needed	10.5.2.8
0 : : :	: : : :	: Type 3 & 4 info elements	
0 0 0 0	0 0 0 1	) Frequency Short List	10.5.2.14
0 0 0 0	0 0 1 0		10.5.2.13
	0 0 0 0		
0 1 1 0	0 0 0 1	) Cell Channel Description	10.5.2.1b
0 1 1 0	0001	1 Channel Mode	10.5.2.6
	0 0 1 0		10.5.2.5
0 1 1 0	0 0 1 1	) Channel Mode 2	10.5.2.7
0 1 1 0	0 1 0 0	) Note	
0 1 1 0	0 1 0 0	l Frequency Chan- nel Sequence	10.5.2.12
0 1 1 0	0101		
0 1 1 0	0 1 0 1	1 Note	
0 1 1 0	0 1 1 0	) Note	

#### Table K.2/3GPP TS 04.08 (page 1 of 2): Default information element identifier coding for Radio Resource management information elements

# Table K.2/3GPP TS 04.08 (page 2 of 2): Default information element identifier coding for Radio Resource management information elements

		Reference
		sub-clause
87654321		
0 1 1 1 0 0 0 1	Note	
0 1 1 1 0 0 1 0	Mobile Allocation	10.5.2.21
01110011	BA range	10.5.2.1
0 1 1 1 0 1 0 0	Note	10.3.2.1
0 1 1 1 0 1 0 1	Note	
0 1 1 1 0 1 1 0	Note	
0 1 1 1 0 1 1 1	Mobile Time difference	10.5.2.21a
0 1 1 1 1 0 0 0	Note	
0 1 1 1 1 0 0 1	Note	
	Note	
0 1 1 1 1 0 1 0	Time Difference	10.5.2.41
•		
0 1 1 1 1 1 0 0	Starting Time	10.5.2.38
0 1 1 1 1 1 0 1	Timing Advance	10.5.2.40
0 1 1 1 1 1 1 0	TMSI	10.5.2.42
0 1 1 1 1 1 1 1	Note	

NOTE: These values were allocated but never used in earlier phases of the protocol.

## K.3 Mobility management information elements

For the mobility management information elements listed below, the default coding of the information element identifier bits is summarized in table K.3/3GPP TS 04.08.

Table K.3/3GPP TS 04.08: Default information element identifier coding for mobility management information elements

								Reference Sub-clause
8	7	6	5	4	3	2	1	
				T	ype	1	info elements	
1			1		-		-Note	
			0	-	-	-	-Note	
1	1	1	0	-	-	-	-Note	
1	0	1	0	- 0 0		0	-Type 2 info elements 1Follow-on Proceed 0CTS Permission	10.5.3.7 10.5.3.10
				T	ype	3	& 4 info elements	
0	1	0	0	0	0	0	1Note	
0	1	0	0	0	0	1	0 Note	
0	1	0	0	0	1	0	0 Note	
Al	l o	the	r v	alu	es	are	reserved	

NOTE: These values were allocated but never used in earlier versions of the protocol

### K.4 Call control information elements.

For the call control information elements listed below, the default coding of the information element identifiers is defined in table K.4/3GPP TS 04.08.

									Reference sub-clause
<b>8</b> 1	:			<b>4</b> - -		2 - -		Type 1 info elements shift	10.5.4.2 and .3
	0 1	1 0	1 1	-	_	_	-	Note Repeat indicator	10.5.4.22
1	0	1	0	: 0 0 0	: 0 0 0 0	: 0 0 1 1		Type 2 information elements More data CLIR Suppression CLIR Invocation Reverse call setup direction	10.5.4.19 10.5.4.11a 10.5.4.11k 10.5.4.22a
0	0 0	0	: 0 0 1 1	: 0 1 0 0	: 1 0 1 1	: 0 0 0 0	: 0 0 0 1	Type 3 & 4 info elements Bearer capability Cause Note Call Control Capabilities	10.5.4.5 10.5.4.11 10.5.4.5a
	0 0 0	1 1 1	1 0 0 1	1	1 1 1 1 1 1 1 1	1	1	Facility Progress indicator Auxiliary states Note Keypad facility Signal Connected number Connected subaddress	10.5.4.15 10.5.4.21 10.5.4.4 10.5.4.17 10.5.4.23 10.5.4.13 10.5.4.14
	1 1 1	0 0 0	1	1 1 1	1	0 0 1	0 1 0	Calling party BCD number Calling party subad Called party BCD	10.5.4.9
	1 1 1	1 1 1	0 1 1	1 0 1	1 1 1	0 0 0	1 0 1	number Called party subad Redirecting Party BCD Redirecting Party	10.5.4.7 10.5.4.8 10.5.4.21a
		1	1 1	1 1	1 1 1 1	0 1	0 1 0 1	subaddress Low layer compatib. High layer compatib. User-user SS version indicator	10.5.4.21k 10.5.4.18 10.5.4.16 10.5.4.25 10.5.4.24

Table K.4/3GPP TS 04.08: Default information element identifier coding for call control information elements

NOTE: These values were allocated but never used in earlier phases of the protocol.

### Annex L (informative): Allocation of responsibilities between STCs

### Annex M (normative): Additional Requirements for backward compatibility with PCS 1900 for NA revision 0 ME

This annex is normative and provides additional requirements to support network mechanisms for backward compatibility with PCS 1900 for NA revision 0 mobile equipments (applicable until July 1, 1998).

PCS 1900 for NA revision 0 mobile equipments are defined to understand Mobile Network Codes made of up to 2 digits. However federal regulation mandates that a 3-digit MNC shall be allocated by each administration to network operators. Therefore each network operator is identified by a 3-digit Mobile Country Code and a 3-digit Mobile Network Code. An operator whose network code complies to the allocation principle specified for PCS 1900 for NA and wants to achieve for a transition period of time the backward compatibility with PCS 1900 for NA revision 0 mobile equipments shall apply the following:

- The network shall send over the air interface the 3-digit Mobile Country Code and only the two most significant digits of the Mobile Network Code (the value of the "digit" sent instead of the 3rd digit is specified in 3GPP TS 04.08, sub-clause 10.5.1.3) (see note).

When a PCS 1900 for NA (revision greater than 0) mobile equipment recognizes over the air the Mobile Country Code and the two most significant digits of the Mobile Network Code as being the HPLMN codes of the current IMSI, the mobile equipment shall take into account the value of the sixth IMSI digit read from the SIM. If this value matches to a value contained in the limited set of values for the least significant MNC digit assigned by the number administration bodies for PCS 1900 for NA then the following applies for the mobile equipment:

- The value sent over the air instead of the 3rd MNC digit in the Location Area Identification (for coding see 3GPP TS 04.08, sub-clause 10.5.1.3) shall be interpreted as the value of the sixth IMSI digit read from the SIM.
- NOTE: It is still a network operator option to apply this requirement after July 1, 1998. However, in this case the following shall be considered:
  - 1. Network selection considerations for overlapping networks:

Networks overlapping to the HPLMN, identified over the radio interface by an identical combination MCC1 MCC2 MCC3 MNC1 MNC2 (possible after July 1, 1998) may be selectable by PCS 1900 for NA mobile equipments revision 0 with the same priority as the HPLMN or presented to the user as the HPLMN

2. Roaming considerations:

Roamers (SIM) from networks identified by an identical combination MCC1 MCC2 MCC3 MNC1 MNC2 (possible after July 1, 1998) when roaming into the operator network with PCS 1900 for NA mobile equipments revision 0, may cause these equipments to exhibit an unpredictable behaviour (e.g. looping in the HPLMN selection and registration procedures).

Home subscribers (SIM) roaming with PCS 1900 for NA mobile equipments revision 0 into networks identified by an identical combination MCC1 MCC2 MCC3 MNC1 MNC2 (possible after July 1, 1998), may consider being attached to the HPLMN.

## Annex N (informative): Change Record

Creation of v 7.0.1

Based on v6.3.0 including CRs A384, A396r2, A412, A457r1, A427r2, A495, A493

Creation of v 7.1.0

A358	8	Addition of SoLSA functionality
A414	1	Addition of new functionality in the packet access procedure in order to
A419	5	Transfer of the LSA Information to the MS
A460		Cell Channel Description IE incorrectly repeated in the PDCH ASSI
A464		Channel description IE
A466		Radio link failure in dedicated mode
A468		RR-Network command cell change order procedure
A484		Clarification on the RR initialisation request
A486		Correction of message type of PDCH ASSIGNMENT COMMAND
A488		Removal of REL_OR_ABS_FN field for Starting Time encoding by a
A490		P-TMSI is introduced in the Paging request messages and in the Mobile
A494		The Pb parameter is needed in SI13/PSI13 (R98)
A496		Removal of SI15
A498		Increase of SMS_VALUE and SM_VALUE
A502	2	Correction for L2 Pseudo length SI5 & SI6 rest octets
A504	1	Addition of signalling for SoLSA enhancements
A506		Read of system information after CELL CHANGE ORDER message
A534		Correction of VGCS target mode indication IE
A540		P-TMSI is introduced in the Paging request messages and in the Mobile
A542		Clarification of Packet Page Indication
A546	2	Inclusion of SoLSA capability indication in Classmark Ies
A546	2	Inclusion of SoLSA capability indication in Classmark IEs
A548		Wrong application of approved CR on NOTIFICATION/NCH
A552	1	Correction of BTS power output
A558	2	Introduction of LCS in 3GPP TS 04.08
A578		AMR IEI
A584	3	MS radio access capability IE
A584	3	MS Radio Access Capability IE
A591		Inconsistency in definition of comprehension required
A594		Role of T3132 and T3190 timers during a TBF release procedure
A598		Alignment 04.60 on 04.08 about single block allocation for a two phase
A600		Clarification on supervision of BCCH_CHANGE_MARK in dedicated
A602		Introduction of P-TMSI in Paging request messages in the MS
A604		Correction of T3142 timeout value
A606		RR Packet Uplink Assignment align with 04.60
A701	1	GPRS Internet Hosted Octet Stream Service (IHOSS).
A751	3	Usage of the combined routing area update procedure
A753	2	Multiple ATTACH REQUEST attempts and GMM-common procedures
A755	2	Network Initiated Detach with ReAttach
A757	2	P-TMSI is introduced in the Paging request messages and in the Mobile
A759	1	Improving the user data loss less inter SGSN RA update
A761		'GPRS services not allowed' cause in the ATTACH REJECT (combined
A763	1	Clarification to CCBS T334 timer
A765	1	SM-STATUS msg. Response to unknown msg type
A767	2	Cleaning up on text in general, and especially on attempt counters, PDP
A769	4	Correction to the handling of subscribed QoS values
A771	2	Correction of the handling of the Ciphering Key Sequence Number (CKSN)
A773	3	Correction of the SM message collision with equal TI to an active PDP

A775	2	Ready Timer handling in suspend state
A777		Deactivation of READY timer
A779	1	Description of cause codes in network initiated detach
A781	1	Clarification of release procedure upon PDP context deactivation
A783	2	New DEREGISTERED 'suspended' state
A785	1	Inconsistency in definition of comprehension required IEs
A787	1	Completion of error handling for session management
A789	2	Subsequent GMM substate and attach attempt counter
A791		Usage of GMM cause codes
A793	4	Old P-TMSI/TLLI handling
A797	2	Gs interface failure
A799	1	'GPRS services and non-GPRS services not allowed': the behaviour of the
A801	1	Maximum length of Access point name and Protocol configuration
A803	1	Clash between READY time deactivation and Force to Standby Procedure
A805		GMM Mobile station identity
A807	3	Initial synchronisation after READY timer negotiation
A809	2	Usage of GMM update status U2
A811		Conditional IE GPRS CKSN in Authentication and ciphering procedure
A813		Correction of the SM message collision cases through PDP address
A815	4	Paging with IMSI
A817	2	Reactivation of PDP contexts
A819		Correcting mistakes introduced via CR's 385, 415, 425,441 in v6.3.0
A821	1	Editorials, and correcting the A&C REQUEST plus INFORMATION
A823		MS reachable timer
A825		Correction of PDP type
A827		Conditional IE Errors
A829	4	Change of network operation mode
A831		Abnormal case in the MS when changing cell while trying to attach
A833		Definition of the PDP address IE
A835		Deactivation of PDP contexts in case of GPRS detach
A837		Improved SM messages error handling for non-semantically mandatory IE
A839		Usage of cause code #10 implicitly detached
A841	1	TMSI requested by the MSC trough the Gs interface
A371	2	BCIE modifications due to EDGE

Creation of v 7.1.1 Editorial correction to remove unnecessary double 'Spare Half Octets' from sub-clause 9.4.9. Version 7.1.2 Editorial corrections of Table 10.5.144/GSM04.08 the bit-string " Receive N-PDU Number value "

Creation of v 7.2.0

A620		Correction of Mobile Station Classmark 2 in the Talker Indication message
A622	1	Clarification of MCC and MNC in SI 4/16/17 rest octets
A626	1	Alignment on 04.60 of information elements RR Packet Uplink and Downlink Assignment
A632		Length of BA List Pref IE in the Channel Release message
A636		Clarification of DRX
A640	1	Alignment of RLC_OCTET_COUNT in 04.08 with 04.60
A644		System information type 14 and 15
A648	1	Introduction of short LSA ID.
A652	1	New coding of SI 4/7/8 Rest Octets.
A658		Correction to handling of GPRS suspension cause
A662	2	Alignment between 04.08 and 04.60 on the packet access procedure attempt following T3142 or
T3172 at	ttempt	
A664		Addition of 3rd MNC digit in Routing Area Identification and correction of LAI
A666		Addition of new SI type in SI 9 Rest Octets.
A670	1	Addition of PR mode in ASSIGNMENT message in 04.08
A843		Addition of 3rd MNC digit in Routing Area Identification and correction of LAI
A847		GMM attempt counters
A851		Cell Change during GPRS Detach procedure
A855		RA change in GMM-ROUTING-AREA-UPDATE-INITIATED

A937	Non power down caused Detach during Attach/ was approve as A859-collision with other CR
A860r1	CM request and combined GMM procedures
A863	"Receive N-PDU Number list" IE padding bits
A867r1	TMSI status indication
A875	PDP context deactivation caused by LLC failure
A887	RAU Complete not returned for TMSI deallocation. Some alignments and editorials
A894	Clarification of the Detach Type "re-attach required" or "re-attach not required" in the network
initiated Detach p	procedure
A901r1	CR clash in sec. 4.7.3.2.6
A905	CR clash in sec. 4.7.3.2.3.2 and 4.7.5.2.3.2
A909r1	T3212 restart after RAU reject
A913	New State GMM-REGISTERED.IMSI-DETACH-INITIATED
A917	Deactivate AA PDP context request message
A921r2	Coding Scheme in Network Name IE
A933	T3212 restart after GPRS detach
A897r1	Addition of Access Point Name in Request PDP Context Activation message

Creation of version 7.3.0

A684	Editorial (misleading reference)
A694	Correction to Packet Access Reject procedure

Creation of version 7.4.0

A939	1	Addition of APN to REQUEST PDP CONTEXT ACTIVATION REJECT message
A676	4	Add enhancements to LCS in 3GPP TS 04.08

Creation of version 7.5.1

A version of 7.5.0 have been available in draft format, with severere corruption of tables. This version 7.5.1 replaces that version.

A612	Immediate assignment
A674	PR_MODE field in assignment message
A676	Intorduction of LCS into 3GPP TS 04.08
A688	Channel Request Description IE length and Packet
A706	Clarification of starting timer T3134
A714	Suspension Cause IE
A641r1	Earlier implementation corrected.

Creation of version 7.6.0: Approval at TSGN#7, (changes based on v.7.4.0)

- A955 Removal of APN from REQUEST PDP CONTEXT ACTIVATION REJECT message
- A951r1 Clarification of NITZ time stamp coding
- A959r1 Corrections to SN-PDU IE length in GMM messages
- A963r1 Interpretation of CM service reject in MS supporting GPRS services
- A975r1 Clarification to the MS handling when receiving detach type 'IMSI detach'
- A987 Explanation of octets in MS Classmark 1 IE
- A1005 Addition of cause value # 25 'Pre-emption'
- A1007 GPRS detach type corrections
- A1013 Moving NOTIFICATION RESPONSE from MM to GSM RR

#### Creation of version 7.7.0: Approval at SMG#31bis

A722 The break indicator in SI 4 Rest Octets is currently coded as '0 | 1'. In order to support the combination of new mobile stations and old networks, the break indicator has to be coded as 'L | H'.

A720 Moving NOTIFICATION RESPONSE from MM to GSM RR

#### Creation of version 7.8.0: Approval at SMG#32 and TSGN#8

- A726 1 Maximum size of fixed ALLOCATION\_BITMAP
- A1015 Alignment on ISDN BC Coding
- A1027 1 Clarification on local and forign TLLI management

Editorial correction in 10.5.2.16 The *IA Rest Octets* information element is a type 5 information element with 1-12 octets length, by removing a curly bracket "}" before " $\{ 0 | 1 < ALPHA : bit (4) > \}$ "

Creation of version 7.9.0: Approval at GP01/ and TSGN#9				
A738		Handling of Power-Control-Parameter alpha		
A732	1	Extended measurement report (MAFA)		
A1043		Missing P-TMSI reallocation after Attach or RAU/ CAT A/ NP-000439/ N1-000935		
A995	1	Usage of cause code IE in network initiated detach/ CAT A/ NP-000439/ N1-000933		
A1039		Deletion of references to OSP: IHOSS for R98/NP-000438/ N1-000928		
A1047	r1	Optional support of GEA/2 Encryption Algorithm in the MS/ NP-000437/ N1001029		

Creation of version 7.9.1 systematic search for "TS" and replace it with "3GPP TS" as gone wrong as much more than the TSs for Technical pecifications have been changed also

#### Creation of version 7.10.0 (7.a.0): Approval at TSGN#10

A1053 Correction of update status on Authentication Reject. NP-000670/ N1-001231/ Cat A/ WI=GPRS

#### Creation of version 7.11.0 (7.b.0): Approval at TSGN#11 on March 2001 of NP-010125 and NP-010147

A1079: Using RAU procedure for MS RAC IE update / N1-010135

A1083r2: Roaming restrictions for GPRS service / N1-010292

A1090: Alignment of MS identity IE length in ATTACH ACCEPT and RAU ACCEPT messages / N1-010355 Implemented in the same version: CR approved at GERAN #4, April 2001: A752: MEASUREMENT\_STARTING\_TIME field in RR Packet Downlink Assignment IE

Meeting	Tdoc	CR	Rev	Subject	New Version
GP-05	GP-010985	A742	2	Correction in RR Sub-layer due to Uplink Removal of Pre-emption	7.12.0
NP-12	NP-010275	A1071	1	Length of User-user IE	7.13.0
NP-12	NP-010355	A1095		Missing SM cause 40 in table 10.6.6 7.13.0	
NP-12	NP-010272	A1097	2	Modification to MS's MM states to 7.13.0 enable LCS signalling on RR layer	
NP-12	NP-010355	A10101	2	Clarification of Network Initiated GPRS 7.13.0 Detach Procedure	
GP-06	GP-011895	A762		Removal of IEI explicit value in the BA 7.14.0 List Pref information element description (R98)	
GP-06	GP-011922	A764		Clarification of "inconsistent" MultiRate 7.14.0 configuration IE (R98)	
GP-07	GP-012679	A774		Restoration of the SI 3 Rest Octets IE description	7.15.0
GP-07	GP-012717	A766	1	Alignment of ASSIGNMENT CMD, HO 7.15.0 CMD and CH MOD MOD for AMR	
NP-14	NP-010647	A1119		Handling of new/old TLLI in the network	7.16.0
GP-08	GP-020495	A778	1	Correction of CSN.1 coding for SI 6 7.17.0 Rest Octets	
NP-17	NP-020370	A1123		Support of GTT (CTM) 7.18.0	
NP-18	NP-020546	A1127		No MT calls after resumption of GPRS 7.19.0 in Network Operation Mode I	
NP-18	NP-020550	A1133		Coding of the "Multiband Supported" bit 7.19.0 field in the CM3 IE	
NP-18	NP-020547	A1137		Clarification on Revision level	7.19.0
GP-15	GP-031151	A804		Correction of erroneous mathematical 7.20.0	
September 2003	-	-	-	Correction of editorial mistake in frequency band names	7.20.1
NP-22	NP-030474	A1143		Correction of MS network capability IE	7.21.0

## History

Document history							
V7.1.2	August 1999	One step Approval Procedure	OAP 9954:	1999-08-11 to 1999-12-10			
V7.1.3	December 1999	Publication as EN 300 940					
V7.4.0	January 2000	One step Approval Procedure	OAP 200019:	2000-01-12 to 2000-05-12			
V7.6.0	May 2000	One step Approval Procedure	OAP 20000901:	20000-05-03 to 2000-09-01			
V7.7.0	May 2000	One-step Approval Procedure	OAP 20000929:	2000-05-31 to 2000-09-29			
V7.4.2	September 2000	Publication as EN 300 940					
V7.6.1	October 2000	Publication as EN 300 940					
V7.7.1	October 2000	Publication as EN 300 940					
V7.8.0	October 2000	Publication					
V7.9.1	November 2000	Publication					
V7.10.0	December 2000	Publication					
V7.11.0	April 2001	Publication					
V7.13.0	June 2001	Publication					
V7.14.0	September 2001	Publication					
V7.16.0	December 2001	Publication					
V7.17.0	February 2002	Publication					
V7.18.0	September 2002	Publication					
V7.19.0	December 2002	Publication (Withdrawn)					
V7.19.1	April 2003	Publication					
V7.20.0	July 2003	Publication (Withdrawn)					
V7.20.1	September 2003	Publication					
V7.21.0	December 2003	Publication					