

ETSI TS 100 974 V7.8.0 (2001-03)

Technical Specification

**Digital cellular telecommunications system (Phase 2+);
Mobile Application Part (MAP) specification
(3GPP TS 09.02 version 7.8.0 Release 1998)**



Reference

RTS/TSGN-040902Q7R7

Keywords

GSM

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

Important notice

Individual copies of the present document can be downloaded from:
<http://www.etsi.org>

The present document may be made available in more than one electronic version or in print. In any case of existing or perceived difference in contents between such versions, the reference version is the Portable Document Format (PDF). In case of dispute, the reference shall be the printing on ETSI printers of the PDF version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status.
Information on the current status of this and other ETSI documents is available at <http://www.etsi.org/tb/status/>

If you find errors in the present document, send your comment to:
editor@etsi.fr

Copyright Notification

No part may be reproduced except as authorized by written permission.
The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2001.

All rights reserved.

Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "*Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards*", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<http://www.etsi.org/ipr>).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Foreword

This Technical Specification (TS) has been produced by the ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under www.etsi.org/key.

Contents

Foreword.....	23
1 Scope	23
2 References	24
3 Abbreviations	29
4 Configuration of the mobile network	29
4.1 The entities of the mobile system.....	29
4.1.1 The Home Location Register (HLR)	29
4.1.2 The Visitor Location Register (VLR)	30
4.1.3 The Mobile-services Switching Centre (MSC).....	30
4.1.4 The Base Station System (BSS).....	30
4.1.5 The Gateway MSC (GMSC).....	30
4.1.6 The SMS Gateway MSC.....	31
4.1.7 The SMS Interworking MSC	31
4.1.8 The VBS/VGCS Anchor MSC	31
4.1.9 The Equipment Identity Register (EIR)	31
4.1.10 The GSM Service Control Function (gsmSCF)	31
4.1.11 The VBS/VGCS Relay MSC	31
4.1.12 The Group Call Register (GCR)	31
4.1.13 The Shared InterWorking Function Server (SIWFS).....	31
4.1.14 The Serving GPRS Support Node (SGSN).....	32
4.1.15 The Gateway GPRS Support Node (GGSN)	32
4.1.16 The Number Portability Location Register (NPLR)	32
4.1.17 The Serving Mobile Location Center (SMLC)	32
4.1.18 The Gateway Mobile Location Center (GMLC).....	33
4.1.19 The Location Measurement Unit (LMU).....	33
4.2 Void.....	35
4.3 Interconnection between PLMNs	35
4.4 The interfaces within the mobile service	35
4.4.1 Interface between the HLR and the VLR (D-interface).....	35
4.4.2 Interface between the HLR and the gsmSCF (J-interface)	35
4.4.3 Interface between the VLR and its associated MSC(s) (B-interface)	35
4.4.4 Interface between VLRs (G-interface).....	35
4.4.5 Interface between the HLR and the MSC (C-interface).....	35
4.4.6 Interface between the MSC and the gsmSCF (L-interface)	36
4.4.7 Interface between MSCs (E-interface).....	36
4.4.8 Interface between the MSC and Base Station Systems (A-interface)	36
4.4.9 Interface between MSC and EIR (F-interface)	36
4.4.10 Interface between VBS/VGCS Anchor MSC and GCR (I-interface)	36
4.4.11 Interface between the MSC and the SIWF server (K-interface)	36
4.4.12 Interface between SGSN and HLR (Gr-interface)	36
4.4.13 Interface between SGSN and SMS-GMSC or SMS-IWMSC (Gd-interface)	36
4.4.14 Interface between GGSN and HLR (Gc-interface)	36
4.4.15 Interface between SGSN and EIR (Gf-interface).....	37
4.4.16 Interface between SGSN and BSC (Gb-interface).....	37
4.4.17 Interface between SGSN and MSC/VLR (Gs-interface)	37
4.4.17A Interface between SMLC and BSC (Lb interface)	37
4.4.18 Interface between SMLC and MSC (Ls interface)	37
4.4.18A Interface between SMLC and SMLC (Lp interface).....	37
4.4.19 Void	37
4.4.20 Interface between GMLC and HLR (Lh interface).....	37
4.4.21 Interface between GMLC and MSC (Lg interface)	37
4.4.22 Interface between LCS Client and GMLC (Le interface)	37
4.5 Splitting of the data storage	37
5 Overload and compatibility overview	38

5.1	Overload control.....	38
5.1.1	Overload control for MSC (outside MAP)	38
5.1.2	Overload control for MAP entities	38
5.1.3	Congestion control for Signalling System No. 7	41
5.2	Compatibility.....	41
5.2.1	General.....	41
5.2.2	Strategy for selecting the Application Context (AC) version	42
5.2.2.1	Proposed method.....	42
5.2.2.2	Managing the version look-up table	42
5.2.2.3	Optimizing the method.....	43
6	Requirements concerning the use of SCCP and TC	44
6.1	Use of SCCP.....	44
6.1.1	SCCP Class.....	44
6.1.2	Sub-System Number (SSN)	44
6.1.3	SCCP addressing	44
6.1.3.1	Introduction	44
6.1.3.2	The Mobile-services Switching Centre (MSC)	46
6.1.3.2.1	MSC interaction during handover	46
6.1.3.2.2	MSC for short message routing	46
6.1.3.2.3	MSC for location request routing	46
6.1.3.2.4	MSC for LMU Control	47
6.1.3.3	The Home Location Register (HLR).....	47
6.1.3.3.1	During call set-up	47
6.1.3.3.2	Before location updating completion.....	47
6.1.3.3.3	After location updating completion	48
6.1.3.3.4	VLR restoration	48
6.1.3.3.5	During Network-Requested PDP Context Activation	48
6.1.3.3.6	Before GPRS location updating completion.....	48
6.1.3.3.7	After GPRS location updating completion	49
6.1.3.3.8	Query for a Location Request.....	49
6.1.3.4	The Visitor Location Register (VLR)	49
6.1.3.4.1	Inter-VLR information retrieval	49
6.1.3.4.2	HLR request	49
6.1.3.5	The Interworking MSC (IWMSC) for Short Message Service	50
6.1.3.6	The Equipment Identity Register (EIR)	50
6.1.3.7	The Shared Inter Working Function (SIWF)	50
6.1.3.8	The Serving GPRS Support Node (SGSN)	50
6.1.3.9	The Gateway GPRS Support Node (GGSN).....	50
6.1.3.10	The Gateway MSC (GMSC) for Short Message Service	50
6.1.3.10A	Void.....	51
6.1.3.10A.1	Void	51
6.1.3.10A.2	Void	51
6.1.3.10B	The Gateway Mobile Location Center (GMLC)	51
6.1.3.11	Summary table	51
6.2	Use of TC	53
7	General on MAP services.....	54
7.1	Terminology and definitions	54
7.2	Modelling principles.....	54
7.3	Common MAP services.....	55
7.3.1	MAP-OPEN service.....	56
7.3.2	MAP-CLOSE service	59
7.3.3	MAP-DELIMITER service.....	59
7.3.4	MAP-U-ABORT service	59
7.3.5	MAP-P-ABORT service	60
7.3.6	MAP-NOTICE service	61
7.4	Sequencing of services	62
7.5	General rules for mapping of services onto TC.....	63
7.5.1	Mapping of common services	63
7.5.2	Mapping of user specific services.....	64
7.6	Definition of parameters.....	65

7.6.1	Common parameters	67
7.6.1.1	Invoke Id	67
7.6.1.2	Linked Id	67
7.6.1.3	Provider error	67
7.6.1.4	User error	68
7.6.1.5	All Information Sent	71
7.6.2	Numbering and identification parameter	71
7.6.2.1	IMSI	71
7.6.2.2	TMSI	71
7.6.2.3	IMEI	71
7.6.2.4	Previous location area Id	71
7.6.2.5	Stored location area Id	71
7.6.2.6	Current location area Id	71
7.6.2.7	Target location area Id	71
7.6.2.8	Target cell Id	71
7.6.2.9	Void	71
7.6.2.10	Originating entity number	71
7.6.2.11	MSC number	71
7.6.2.12	Target MSC number	72
7.6.2.13	HLR number	72
7.6.2.14	VLR number	72
7.6.2.15	HLR Id	72
7.6.2.16	LMSI	72
7.6.2.17	MS ISDN	72
7.6.2.18	OMC Id	72
7.6.2.19	Roaming number	72
7.6.2.20	Void	72
7.6.2.21	Handover number	72
7.6.2.22	Forwarded-to number	72
7.6.2.23	Forwarded-to subaddress	72
7.6.2.24	Called number	72
7.6.2.25	Calling number	72
7.6.2.26	Originally dialled number	73
7.6.2.27	Service centre address	73
7.6.2.28	Zone Code	73
7.6.2.29	MSIsdn-Alert	73
7.6.2.30	Location Information	73
7.6.2.31	GMSC Address	73
7.6.2.32	VMSC Address	73
7.6.2.33	Group Id	73
7.6.2.34	North American Equal Access preferred Carrier Id	73
7.6.2.35	SIWFS Number	73
7.6.2.36	B-subscriber address	73
7.6.2.37	Serving cell Id	73
7.6.2.38	SGSN number	74
7.6.2.39	SGSN address	74
7.6.2.40	GGSN address	74
7.6.2.41	GGSN number	74
7.6.2.42	APN	74
7.6.2.43	Network Node number	74
7.6.2.44	PDP-Type	74
7.6.2.45	PDP-Address	74
7.6.2.46	Additional number	74
7.6.2.47	P-TMSI	74
7.6.2.48	B-subscriber number	74
7.6.2.49	B-subscriber subaddress	74
7.6.2.50	LMU Number	75
7.6.2.51	MLC Number	75
7.6.3	Subscriber management parameters	75
7.6.3.1	Category	75
7.6.3.2	Equipment status	75
7.6.3.3	Extensible Bearer service	75

7.6.3.4	Extensible Teleservice	75
7.6.3.5	Extensible Basic Service Group.....	75
7.6.3.6	GSM bearer capability	75
7.6.3.7	Subscriber Status.....	75
7.6.3.8	CUG Outgoing Access indicator.....	75
7.6.3.9	Operator Determined Barring General Data	75
7.6.3.10	ODB HPLMN Specific Data.....	76
7.6.3.11	Regional Subscription Data.....	76
7.6.3.12	Regional Subscription Response.....	76
7.6.3.13	Roaming Restriction Due To Unsupported Feature	76
7.6.3.14	Extensible SS-Info	76
7.6.3.15	Extensible Forwarding information	77
7.6.3.16	Extensible Forwarding feature	77
7.6.3.17	Extensible SS-Status	77
7.6.3.18	Extensible Forwarding Options.....	77
7.6.3.19	Extensible No reply condition timer	77
7.6.3.20	Extensible Call barring information	77
7.6.3.21	Extensible Call barring feature.....	78
7.6.3.22	CUG info.....	78
7.6.3.23	CUG subscription.....	78
7.6.3.24	CUG interlock	78
7.6.3.25	CUG index	78
7.6.3.26	CUG feature	78
7.6.3.27	Inter CUG options	79
7.6.3.28	Intra CUG restrictions	79
7.6.3.29	Extensible SS-Data.....	79
7.6.3.30	Subscriber State.....	79
7.6.3.31	Requested Info	79
7.6.3.32	Suppression of Announcement.....	79
7.6.3.33	Suppress T-CSI	79
7.6.3.34	GMSC CAMEL Subscription Info.....	79
7.6.3.35	VLR CAMEL Subscription Info	79
7.6.3.36	Supported CAMEL Phases	80
7.6.3.37	CUG Subscription Flag	80
7.6.3.38	CAMEL Subscription Info Withdraw	80
7.6.3.39	Voice Group Call Service (VGCS) Data.....	80
7.6.3.40	Voice Broadcast Service (VBS) Data	80
7.6.3.41	ISDN bearer capability.....	80
7.6.3.42	Lower layer Compatibility	80
7.6.3.43	High Layer Compatibility	80
7.6.3.44	Alerting Pattern	80
7.6.3.45	GPRS Subscription Data Withdraw	80
7.6.3.46	GPRS Subscription Data	80
7.6.3.47	QoS-Subscribed	80
7.6.3.48	VPLMN address allowed	80
7.6.3.49	Roaming Restricted In SGSN Due To Unsupported Feature	81
7.6.3.50	Network Access Mode	81
7.6.3.51	Mobile Not Reachable Reason	81
7.6.3.52	Cancellation Type	81
7.6.3.53	All GPRS Data	81
7.6.3.54	Complete Data List Included.....	81
7.6.3.55	PDP Context Identifier.....	81
7.6.3.56	LSA Information	81
7.6.3.57	SoLSA support indicator.....	81
7.6.3.58	LSA Information Withdraw	81
7.6.3.59	LMU Indicator	81
7.6.3.60	LCS Information	81
7.6.3.61	GMLC List	82
7.6.3.62	LCS Privacy Exception List	82
7.6.3.63	LCS Privacy Exception Parameters	82
7.6.3.64	External Client List	82
7.6.3.65	Internal Client List	82

7.6.3.66	MO-LR List.....	82
7.6.3.67	Privacy Notification to MS User.....	82
7.6.3.68	GMLC List Withdraw	82
7.6.4	Supplementary services parameters	83
7.6.4.1	SS-Code	83
7.6.4.2	SS-Status	83
7.6.4.3	SS-Data	83
7.6.4.4	Override Category	84
7.6.4.5	CLI Restriction Option.....	84
7.6.4.6	Forwarding Options	84
7.6.4.7	No reply condition timer	84
7.6.4.8 - 7.6.4.14	Void.....	84
7.6.4.15	Forwarding information	84
7.6.4.16	Forwarding feature	84
7.6.4.17	Void.....	85
7.6.4.18	Call barring information.....	85
7.6.4.19	Call barring feature	85
7.6.4.20	New password	85
7.6.4.21	Current password	85
7.6.4.22	Guidance information.....	85
7.6.4.23	Void.....	86
7.6.4.24	SS-Info	86
7.6.4.25-7.6.4.35	Void.....	86
7.6.4.36	USSD Data Coding Scheme.....	86
7.6.4.37	USSD String.....	86
7.6.4.38	Bearer service.....	86
7.6.4.39	Teleservice	86
7.6.4.40	Basic Service Group.....	86
7.6.4.41	eMLPP information.....	86
7.6.4.42	SS-event	87
7.6.4.43	SS-event data.....	87
7.6.4.44	LCS Privacy Exceptions	87
7.6.4.45	Mobile Originating Location Request (MO-LR)	87
7.6.5	Call parameters	87
7.6.5.1	Call reference number	87
7.6.5.2	Interrogation type	87
7.6.5.3	OR interrogation	87
7.6.5.4	OR capability	88
7.6.5.5	Forwarding reason.....	88
7.6.5.6	Forwarding interrogation required	88
7.6.5.7	O-CSI	88
7.6.5.8	Call Direction	88
7.6.5.9	Channel Type	88
7.6.5.10	Chosen Channel	88
7.6.5.11	CCBS Feature	88
7.6.5.12	UU Data	88
7.6.5.13	UUS CF Interaction	88
7.6.5.14	Number Portability Status	89
7.6.6	Radio parameters	89
7.6.6.1-7.6.6.6	Void.....	89
7.6.6.7	HO-Number Not Required	89
7.6.7	Authentication parameters	89
7.6.7.1	Authentication set list.....	89
7.6.7.2	Rand	89
7.6.7.3	Sres.....	89
7.6.7.4	Kc	89
7.6.7.5	Void.....	89
7.6.7.6	Cksn	89
7.6.7.7	Ciphering mode	89
7.6.8	Short message parameters.....	90
7.6.8.1	SM-RP-DA.....	90
7.6.8.2	SM-RP-OA.....	90

7.6.8.3	MWD status	90
7.6.8.4	SM-RP-UI	90
7.6.8.5	SM-RP-PRI	90
7.6.8.6	SM Delivery Outcome	90
7.6.8.7	More Messages To Send	90
7.6.8.8	Alert Reason	91
7.6.8.9	Absent Subscriber Diagnostic SM	91
7.6.8.10	Alert Reason Indicator	91
7.6.8.11	Additional SM Delivery Outcome	91
7.6.8.12	Additional Absent Subscriber Diagnostic SM	91
7.6.8.13	Delivery Outcome Indicator	91
7.6.8.14	GPRS Node Indicator	91
7.6.8.15	GPRS Support Indicator	91
7.6.8.16	SM-RP-MTI	91
7.6.8.17	SM-RP-SMEA	91
7.6.9	Access and signalling system related parameters	91
7.6.9.1	BSS-apdu	91
7.6.9.2	CM service type	92
7.6.9.3	Access connection status	92
7.6.9.4	External Signal Information	92
7.6.9.5	Access signalling information	92
7.6.9.6	Location update type	92
7.6.9.7	Protocol ID	92
7.6.9.8	Network signal information	92
7.6.9.9	Call Info	93
7.6.9.10	Additional signal info	93
7.6.10	System operations parameters	94
7.6.10.1	Network resources	94
7.6.10.2	Trace reference	94
7.6.10.3	Trace type	94
7.6.11	Location Service Parameters	94
7.6.11.1	Age of Location Estimate	94
7.6.11.2	Void	94
7.6.11.3	Void	94
7.6.11.4	LCS Client ID	94
7.6.11.5	LCS Event	94
7.6.11.6	LCS MLC Data	95
7.6.11.7	LCS Priority	95
7.6.11.8	LCS QoS	95
7.6.11.9	Void	95
7.6.11.10	Void	95
7.6.11.11	Location Estimate	95
7.6.11.12	Location Type	95
7.6.11.13	NA-ESRD	96
7.6.11.14	NA-ESRK	96
7.6.11.15	Void	96
7.6.11.16	Privacy Override	96
7.6.11.17	Void	96
7.6.11.18	Void	96
7.6.11.19	Void	96
7.7	Representation of a list of a basic parameter in service-primitives	96
8	Mobility services	96
8.1	Location management services	96
8.1.1	MAP_UPDATE_LOCATION_AREA service	96
8.1.1.1	Definition	96
8.1.1.2	Service primitives	97
8.1.1.3	parameter definitions and use	97
8.1.2	MAP_UPDATE_LOCATION service	98
8.1.2.1	Definition	98
8.1.2.2	Service primitives	98
8.1.2.3	Parameter definitions and use	98

8.1.3	MAP_CANCEL_LOCATION service	99
8.1.3.1	Definition	99
8.1.3.2	Service primitives	100
8.1.3.3	Parameter definitions and use	100
8.1.4	MAP_SEND_IDENTIFICATION service	100
8.1.4.1	Definition	100
8.1.4.2	Service primitives	101
8.1.4.3	Parameter definitions and use	101
8.1.5	MAP_DETACH_IMSI service	101
8.1.5.1	Definition	101
8.1.5.2	Service primitives	101
8.1.5.3	Parameter definitions and use	102
8.1.6	MAP_PURGE_MS service	102
8.1.6.1	Definition	102
8.1.6.2	Service primitives	102
8.1.6.3	Parameter definitions and use	102
8.1.7	MAP_UPDATE_GPRS_LOCATION service	103
8.1.7.1	Definition	103
8.1.7.2	Service primitives	103
8.1.7.3	Parameter definitions and use	103
8.2	Paging and search	104
8.2.1	MAP_PAGE service	104
8.2.1.1	Definition	104
8.2.1.2	Service primitives	105
8.2.1.3	Parameter definitions and use	105
8.2.2	MAP_SEARCH_FOR_MS service	105
8.2.2.1	Definition	105
8.2.2.2	Service primitives	106
8.2.2.3	Parameter definitions and use	106
8.3	Access management services	106
8.3.1	MAP_PROCESS_ACCESS_REQUEST service	106
8.3.1.1	Definition	106
8.3.1.2	Service primitives	107
8.3.1.3	Parameter definitions and use	107
8.4	Handover services	108
8.4.1	MAP_PREPARE_HANDOVER service	108
8.4.1.1	Definition	108
8.4.1.2	Service primitives	108
8.4.1.3	Parameter use	109
8.4.2	MAP_SEND_END_SIGNAL service	109
8.4.2.1	Definition	109
8.4.2.2	Service primitives	109
8.4.2.3	Parameter use	110
8.4.3	MAP_PROCESS_ACCESS_SIGNALLING service	110
8.4.3.1	Definition	110
8.4.3.2	Service primitives	110
8.4.3.3	Parameter use	110
8.4.4	MAP_FORWARD_ACCESS_SIGNALLING service	110
8.4.4.1	Definition	110
8.4.4.2	Service primitives	110
8.4.4.3	Parameter use	111
8.4.5	MAP_PREPARE_SUBSEQUENT_HANDOVER service	111
8.4.5.1	Definition	111
8.4.5.2	Service primitives	111
8.4.5.3	Parameter use	111
8.4.6	MAP_ALLOCATE_HANDOVER_NUMBER service	112
8.4.6.1	Definition	112
8.4.6.2	Service primitives	112
8.4.6.3	Parameter use	112
8.4.7	MAP_SEND_HANDOVER_REPORT service	112
8.4.7.1	Definition	112
8.4.7.2	Service primitives	112

8.4.7.3	Parameter use	113
8.5	Authentication management services	113
8.5.1	MAP_AUTHENTICATE service	113
8.5.1.1	Definition	113
8.5.1.2	Service primitives	113
8.5.1.3	Parameter use	113
8.5.2	MAP_SEND_AUTHENTICATION_INFO service	114
8.5.2.1	Definition	114
8.5.2.2	Service primitives	114
8.5.2.3	Parameter use	114
8.6	Security management services	115
8.6.1	MAP_SET_CIPHERING_MODE service	115
8.6.1.1	Definitions	115
8.6.1.2	Service primitives	115
8.6.1.3	Parameter use	115
8.7	International mobile equipment identities management services	115
8.7.1	MAP_CHECK_IMEI service	115
8.7.1.1	Definition	115
8.7.1.2	Service primitives	116
8.7.1.3	Parameter use	116
8.7.2	MAP_OBTAIN_IMEI service	116
8.7.2.1	Definition	116
8.7.2.2	Service primitives	116
8.7.2.3	Parameter use	117
8.8	Subscriber management services	117
8.8.1	MAP-INSERT-SUBSCRIBER-DATA service	117
8.8.1.1	Definition	117
8.8.1.2	Service primitives	118
8.8.1.3	Parameter use	118
8.8.1.4	Basic service information related to supplementary services	125
8.8.2	MAP-DELETE-SUBSCRIBER-DATA service	126
8.8.2.1	Definition	126
8.8.2.2	Service primitives	126
8.8.2.3	Parameter use	126
8.9	Identity management services	128
8.9.1	MAP-PROVIDE-IMSI service	128
8.9.1.1	Definition	128
8.9.1.2	Service primitives	129
8.9.1.3	Parameter use	129
8.9.2	MAP-FORWARD-NEW-TMSI service	129
8.9.2.1	Definition	129
8.9.2.2	Service primitives	129
8.9.2.3	Parameter use	129
8.10	Fault recovery services	129
8.10.1	MAP_RESET service	129
8.10.1.1	Definition	129
8.10.1.2	Service primitives	130
8.10.1.3	Parameter definition and use	130
8.10.2	MAP_FORWARD_CHECK_SS_INDICATION service	130
8.10.2.1	Definition	130
8.10.2.2	Service primitives	130
8.10.2.3	Parameter definition and use	130
8.10.3	MAP_RESTORE_DATA service	130
8.10.3.1	Definition	130
8.10.3.2	Service primitives	131
8.10.3.3	Parameter definitions and use	131
8.11	Subscriber Information services	132
8.11.1	MAP-ANY-TIME-INTERROGATION service	132
8.11.1.1	Definition	132
8.11.1.2	Service primitives	132
8.11.1.3	Parameter definition and use	132
8.11.2	MAP-PROVIDE-SUBSCRIBER-Info service	132

8.11.2.1	Definition	132
8.11.2.2	Service primitives	133
8.11.2.3	Parameter definition and use	133
9	Operation and maintenance services	133
9.1	Subscriber tracing services	133
9.1.1	MAP-ACTIVATE-TRACE-MODE service	133
9.1.1.1	Definition	133
9.1.1.2	Service primitives	133
9.1.1.3	Parameter use	134
9.1.2	MAP-DEACTIVATE-TRACE-MODE service	134
9.1.2.1	Definition	134
9.1.2.2	Service primitives	134
9.1.2.3	Parameter use	135
9.1.3	MAP-TRACE-SUBSCRIBER-ACTIVITY service	135
9.1.3.1	Definition	135
9.1.3.2	Service primitives	135
9.1.3.3	Parameter use	135
9.2	Other operation and maintenance services	136
9.2.1	MAP-SEND-IMSI service	136
9.2.1.1	Definition	136
9.2.1.2	Service primitives	136
9.2.1.3	Parameter use	136
10	Call handling services	136
10.1	MAP_SEND_ROUTING_INFORMATION service	136
10.1.1	Definition	136
10.1.2	Service primitives	137
10.1.3	Parameter use	137
10.2	MAP_PROVIDE_ROAMING_NUMBER service	141
10.2.1	Definition	141
10.2.2	Service primitives	141
10.2.3	Parameter use	141
10.3	MAP_RESUME_CALL_HANDLING service	143
10.3.1	Definition	143
10.3.2	Service primitives	143
10.3.3	Parameter use	144
10.4	MAP_PREPARE_GROUP_CALL service	145
10.4.1	Definition	145
10.4.2	Service primitives	145
10.4.3	Parameter definitions and use	145
10.5	MAP_PROCESS_GROUP_CALL_SIGNALLING service	146
10.5.1	Definitions	146
10.5.2	Service primitives	146
10.5.3	Parameter definitions and use	146
10.6	MAP_FORWARD_GROUP_CALL_SIGNALLING service	147
10.6.1	Definitions	147
10.6.2	Service primitives	147
10.6.3	Parameter definitions and use	147
10.7	MAP_SEND_GROUP_CALL_END_SIGNAL service	148
10.7.1	Definitions	148
10.7.2	Service primitives	148
10.7.3	Parameter definitions and use	148
10.8	MAP_Provide_SIWFNS_Number	148
10.8.1	Definition	148
10.8.2	Service primitive	149
10.8.3	Parameter use	149
10.9	MAP_SIWFNS_Signalling_Modify	150
10.9.1	Definition	150
10.9.2	Service primitive	150
10.9.3	Parameter use	150
10.10	MAP_SET_REPORTING_STATE service	151

10.10.1	Definition.....	151
10.10.2	Service primitives	151
10.10.3	Parameter use.....	151
10.11	MAP_STATUS_REPORT service.....	152
10.11.1	Definition.....	152
10.11.2	Service primitives	152
10.11.3	Parameter use.....	152
10.12	MAP_REMOTE_USER_FREE service.....	153
10.12.1	Definition.....	153
10.12.2	Service primitives	153
10.12.3	Parameter use.....	153
11	Supplementary services related services	154
11.1	MAP_REGISTER_SS service.....	154
11.1.1	Definition.....	154
11.1.2	Service primitives	154
11.1.3	Parameter use.....	155
11.2	MAP_ERASE_SS service	156
11.2.1	Definition.....	156
11.2.2	Service primitives	156
11.2.3	Parameter use.....	156
11.3	MAP_ACTIVATE_SS service.....	157
11.3.1	Definition.....	157
11.3.2	Service primitives	157
11.3.3	Parameter use.....	157
11.4	MAP_DEACTIVATE_SS service	158
11.4.1	Definitions	158
11.4.2	Service primitives	158
11.4.3	Parameter use.....	159
11.5	MAP_INTERROGATE_SS service.....	160
11.5.1	Definitions	160
11.5.2	Service primitives	160
11.5.3	Parameter use.....	160
11.6	MAP_INVOKE_SS service	161
11.6.1	Definitions	161
11.6.2	Service primitives	162
11.6.3	Parameter use.....	162
11.7	MAP_REGISTER_PASSWORD service	162
11.7.1	Definitions	162
11.7.2	Service primitives	163
11.7.3	Parameter use.....	163
11.8	MAP_GET_PASSWORD service	163
11.8.1	Definitions	163
11.8.2	Service primitives	164
11.8.3	Parameter use.....	164
11.9	MAP_PROCESS_UNSTRUCTURED_SS_REQUEST service.....	164
11.9.1	Definitions	164
11.9.2	Service primitives	164
11.9.3	Parameter use.....	165
11.10	MAP_UNSTRUCTURED_SS_REQUEST service	165
11.10.1	Definitions	165
11.10.2	Service primitives	166
11.10.3	Parameter use.....	166
11.11	MAP_UNSTRUCTURED_SS_NOTIFY service	167
11.11.1	Definitions	167
11.11.2	Service primitives	167
11.11.3	Parameter use.....	167
11.12	MAP_SS_INVOCATION_NOTIFY	168
11.12.1	Definition.....	168
11.12.2	Service primitives	168
11.12.3	Parameter use.....	168
11.13	MAP_REGISTER_CC_ENTRY service	168

11.13.1	Definition.....	168
11.13.2	Service primitives	169
11.13.3	Parameter use.....	169
11.14	MAP_ERASE_CC_ENTRY service.....	170
11.14.1	Definition.....	170
11.14.2	Service primitives	170
11.14.3	Parameter use.....	170
12	Short message service management services	171
12.1	MAP-SEND-ROUTING-INFO-FOR-SM service	171
12.1.1	Definition.....	171
12.1.2	Service primitives	171
12.1.3	Parameter use.....	172
12.2	MAP-MO-FORWARD-SHORT-MESSAGE service.....	173
12.2.1	Definition.....	173
12.2.2	Service primitives	173
12.2.3	Parameter use.....	173
12.3	MAP-REPORT-SM-DELIVERY-STATUS service.....	174
12.3.1	Definition.....	174
12.3.2	Service primitives	174
12.3.3	Parameter use.....	175
12.4	MAP-READY-FOR-SM service.....	176
12.4.1	Definition.....	176
12.4.2	Service primitives	176
12.4.3	Parameter use.....	176
12.5	MAP-ALERT-SERVICE-CENTRE service	177
12.5.1	Definition.....	177
12.5.2	Service primitives	177
12.5.3	Parameter use.....	177
12.6	MAP-INFORM-SERVICE-CENTRE service.....	178
12.6.1	Definition.....	178
12.6.2	Service primitives	178
12.6.3	Parameter use.....	178
12.7	MAP-SEND-INFO-FOR-MT-SMS service	179
12.7.1	Definition.....	179
12.7.2	Service primitives	179
12.7.3	Parameter use.....	179
12.8	MAP-SEND-INFO-FOR-MO-SMS service.....	180
12.8.1	Definition.....	180
12.8.2	Service primitives	180
12.8.3	Parameter use.....	180
12.9	MAP-MT-FORWARD-SHORT-MESSAGE service	180
12.9.1	Definition.....	180
12.9.2	Service primitives	181
12.9.3	Parameter use.....	181
13	Network-Requested PDP Context Activation services	182
13.1	MAP_SEND_ROUTING_INFO_FOR_GPRS service	182
13.1.1	Definition.....	182
13.1.2	Service primitives	182
13.1.3	Parameter definition and use.....	182
13.2	MAP_FAILURE_REPORT service	183
13.2.1	Definition.....	183
13.2.2	Service primitives	183
13.2.3	Parameter definition and use.....	183
13.3	MAP_NOTE_MS_PRESENT_FOR_GPRS service	184
13.3.1	Definition.....	184
13.3.2	Service primitives	184
13.3.3	Parameter definition and use.....	184
13A	Location Service Management Services	185
13A.1	MAP-SEND-ROUTING-INFO-FOR-LCS Service	185
13A.1.1	Definition.....	185

13A.1.2	Service Primitives	185
13A.1.3	Parameter Use	186
13A.2	MAP-PROVIDE-SUBSCRIBER-LOCATION Service.....	187
13A.2.1	Definition.....	187
13A.2.2	Service Primitives	187
13A.2.3	Parameter Definition and Use.....	187
13A.3	MAP-SUBSCRIBER-LOCATION-REPORT Service.....	188
13A.3.1	Definition.....	188
13A.3.2	Service Primitives	189
13A.3.3	Parameter Definition and Use	189
13A.4	Void.....	191
13A.4.1 - 13A.4.3	Void.....	191
13A.5	Void.....	191
13A.5.1 - 13A.5.3	Void.....	191
13A.6	Void.....	191
13A.6.1 - 13A.6.3	Void.....	191
13A.7	Void.....	191
13A.7.1 - 13A.7.3	Void.....	191
13A.8	Void	191
13A.8.1 - 13A.8.3	Void.....	191
13A.9	Void.....	191
13A.9.1 - 13A.9.3	Void.....	191
14	General	191
14.1	Overview	191
14.2	Underlying services	191
14.3	Model	191
14.4	Conventions.....	192
15	Elements of procedure.....	192
15.1	Dialogue establishment	192
15.1.1	Handling of unknown operations.....	192
15.1.2	Receipt of a MAP-OPEN request primitive.....	193
15.1.3	Receipt of a TC-BEGIN indication.....	194
15.1.4	Receipt of a MAP-OPEN response.....	196
15.1.5	Receipt of the first TC-CONTINUE ind.....	196
15.1.6	Receipt of a TC-END ind	196
15.1.7	Receipt of a TC-U-ABORT ind.....	197
15.1.8	Receipt of a TC-P-ABORT ind.....	197
15.2	Dialogue continuation	197
15.2.1	Sending entity	197
15.2.2	Receiving entity	197
15.3	Dialogue termination	198
15.3.1	Receipt of a MAP-CLOSE request	198
15.3.2	Receipt of a TC-END indication.....	198
15.4	User Abort	198
15.4.1	MAP-U-ABORT request	198
15.4.2	TC-U-ABORT ind	198
15.5	Provider Abort.....	198
15.5.1	MAP PM error situation	199
15.5.2	TC-P-ABORT ind.....	199
15.5.3	TC-U-ABORT ind	199
15.6	Procedures for MAP specific services	199
15.6.1	Service invocation	199
15.6.2	Service invocation receipt.....	200
15.6.3	Service response	200
15.6.4	Receipt of a response	201
15.6.4.1	Receipt of a TC-RESULT-NL indication	201
15.6.4.2	Receipt of a TC-RESULT-L indication	201
15.6.4.3	Receipt of a TC-U-ERROR indication.....	202
15.6.4.4	Receipt of a TC-INVOKE indication.....	202
15.6.4.5	Receipt of a TC-U-REJECT indication.....	202

15.6.4.6	Receipt of a TC-L-REJECT indication	202
15.6.4.7	Receipt of a TC-L-CANCEL indication	203
15.6.4.8	Receipt of a TC-NOTICE indication	203
15.6.5	Other events	203
15.6.5.1	Receipt of a TC-U-REJECT	203
15.6.5.2	Receipt of a TC-R-REJECT indication	204
15.6.5.3	Receipt of a TC-L-REJECT indication	204
15.6.6	Parameter checks	204
15.6.7	Returning state machines to idle	204
15.6.8	Load control.....	204
16	Mapping on to TC services	205
16.1	Dialogue control.....	205
16.1.1	Directly mapped parameters	205
16.1.2	Use of other parameters of dialogue handling primitives	205
16.1.2.1	Dialogue Id.....	205
16.1.2.2	Application-context-name	205
16.1.2.3	User information	205
16.1.2.4	Component present.....	205
16.1.2.5	Termination.....	205
16.1.2.6	P-Abort-Cause.....	205
16.1.2.7	Quality of service	206
16.2	Service specific procedures	206
16.2.1	Directly mapped parameters	206
16.2.2	Use of other parameters of component handling primitives	206
16.2.2.1	Dialogue Id.....	206
16.2.2.2	Class	206
16.2.2.3	Linked Id	206
16.2.2.4	Operation.....	207
16.2.2.5	Error	209
16.2.2.6	Parameters	209
16.2.2.7	Time out	209
16.2.2.8	Last component	209
16.2.2.9	Problem code.....	209
16.2.2.9.1	Mapping to MAP User Error.....	209
16.2.2.9.2	Mapping to MAP Provider Error parameter.....	209
16.2.2.9.3	Mapping to diagnostic parameter	210
16.3	SDL descriptions	210
17	Abstract syntax of the MAP protocol.....	237
17.1	General	237
17.1.1	Encoding rules	237
17.1.2	Use of TC.....	237
17.1.2.1	Use of Global Operation and Error codes defined outside MAP	238
17.1.3	Use of information elements defined outside MAP	238
17.1.4	Compatibility considerations	239
17.1.5	Structure of the Abstract Syntax of MAP	239
17.1.6	Application Contexts	241
17.2	Operation packages	242
17.2.1	General aspects	242
17.2.2	Packages specifications	243
17.2.2.1	Location updating	243
17.2.2.2	Location cancellation	243
17.2.2.3	Roaming number enquiry.....	243
17.2.2.4	Information retrieval	244
17.2.2.5	Inter-VLR information retrieval.....	244
17.2.2.6	IMSI retrieval	244
17.2.2.7	Call control transfer.....	244
17.2.2.8 - 17.2.2.9	Void.....	244
17.2.2.10	Interrogation.....	244
17.2.2.11	Void.....	245
17.2.2.12	Handover Control.....	245

17.2.2.13	Subscriber Data management stand alone.....	245
17.2.2.14	Equipment management.....	245
17.2.2.15	Subscriber data management.....	245
17.2.2.16	Location register restart.....	246
17.2.2.17	Tracing stand-alone.....	246
17.2.2.18	Functional SS handling	246
17.2.2.19	Tracing	246
17.2.2.20	Binding.....	246
17.2.2.21	Unstructured SS handling	247
17.2.2.22	MO Short message relay services	247
17.2.2.23	Short message gateway services	247
17.2.2.24	MT Short message relay services.....	248
17.2.2.25	Void.....	248
17.2.2.26	Message waiting data management.....	248
17.2.2.27	Alerting	248
17.2.2.28	Data restoration	248
17.2.2.29	Purging.....	249
17.2.2.30	Subscriber information enquiry.....	249
17.2.2.31	Any time information enquiry.....	249
17.2.2.32	Group Call Control.....	249
17.2.2.33	Provide SIWFS number	249
17.2.2.34	SIWFS Signalling Modify.....	250
17.2.2.35	Gprs location updating	250
17.2.2.36	Gprs Interrogation	250
17.2.2.37	Failure reporting.....	250
17.2.2.38	GPRS notifying	250
17.2.2.39	Supplementary Service invocation notification.....	251
17.2.2.40	Set Reporting State.....	251
17.2.2.41	Status Report	251
17.2.2.42	Remote User Free.....	251
17.2.2.43	Call Completion	251
17.2.2.44	Location service gateway services	251
17.2.2.45	Location service enquiry	252
17.2.2.45A	Location service reporting.....	252
17.2.2.46	Void.....	252
17.2.2.47	Void.....	252
17.2.2.48	Void.....	252
17.3	Application contexts.....	252
17.3.1	General aspects	252
17.3.2	Application context definitions.....	253
17.3.2.1	Void.....	253
17.3.2.2	Location Updating.....	253
17.3.2.3	Location Cancellation	254
17.3.2.4	Roaming number enquiry.....	254
17.3.2.5	Void.....	254
17.3.2.6	Location Information Retrieval.....	254
17.3.2.7	Call control transfer.....	255
17.3.2.8 - 17.3.2.10	Void.....	255
17.3.2.11	Location registers restart	255
17.3.2.12	Handover control.....	255
17.3.2.13	IMSI Retrieval.....	255
17.3.2.14	Equipment Management	255
17.3.2.15	Information retrieval	256
17.3.2.16	Inter-VLR information retrieval.....	256
17.3.2.17	Stand Alone Subscriber Data Management.....	256
17.3.2.18	Tracing	256
17.3.2.19	Network functional SS handling	257
17.3.2.20	Network unstructured SS handling	257
17.3.2.21	Short Message Gateway	257
17.3.2.22	Mobile originating Short Message Relay	258
17.3.2.23	Void.....	258
17.3.2.24	Short message alert	258

17.3.2.25	Short message waiting data management.....	258
17.3.2.26	Mobile terminating Short Message Relay	259
17.3.2.27	MS purging	259
17.3.2.28	Subscriber information enquiry.....	259
17.3.2.29	Any time information enquiry.....	259
17.3.2.30	Group Call Control.....	260
17.3.2.31	Provide SIWFS Number	260
17.3.2.32	Gprs Location Updating	260
17.3.2.33	Gprs Location Information Retrieval	260
17.3.2.34	Failure Reporting	260
17.3.2.35	GPRS Notifying	261
17.3.2.36	Supplementary Service invocation notification.....	261
17.3.2.37	Reporting.....	261
17.3.2.38	Call Completion	261
17.3.2.39	Location Service Gateway	261
17.3.2.40	Location Service Enquiry.....	262
17.3.2.41	Void.....	262
17.3.2.42	Void.....	262
17.3.2.43	Void.....	262
17.3.3	ASN.1 Module for application-context-names	262
17.4	MAP Dialogue Information.....	264
17.5	MAP operation and error codes.....	266
17.6	MAP operation and error types	271
17.6.1	Mobile Service Operations	271
17.6.2	Operation and Maintenance Operations.....	276
17.6.3	Call Handling Operations	277
17.6.4	Supplementary service operations	280
17.6.5	Short message service operations	284
17.6.6	Errors	286
17.6.7	Group Call operations	291
17.6.8	Location service operations	292
17.7	MAP constants and data types.....	294
17.7.1	Mobile Service data types.....	294
17.7.2	Operation and maintenance data types.....	308
17.7.3	Call handling data types.....	309
17.7.4	Supplementary service data types.....	315
17.7.5	Supplementary service codes.....	319
17.7.6	Short message data types	322
17.7.7	Error data types.....	325
17.7.8	Common data types	329
17.7.9	Teleservice Codes.....	335
17.7.10	Bearer Service Codes.....	336
17.7.11	Extension data types	338
17.7.12	Group Call data types	339
17.7.13	Location service data types.....	341
18	General on MAP user procedures	345
18.1	Introduction	345
18.2	Common aspects of user procedure descriptions.....	345
18.2.1	General conventions	345
18.2.2	Naming conventions	345
18.2.3	Convention on primitives parameters	347
18.2.3.1	Open service.....	347
18.2.3.2	Close service	347
18.2.4	Version handling at dialogue establishment	348
18.2.4.1	Behaviour at the initiating side.....	348
18.2.4.2	Behaviour at the responding side	348
18.2.5	Abort Handling	348
18.2.6	SDL conventions	348
18.3	Interaction between MAP Provider and MAP Users.....	349
19	Mobility procedures	349

19.1	Location management Procedures.....	349
19.1.1	Location updating	355
19.1.1.1	General	355
19.1.1.2	Detailed procedure in the MSC.....	362
19.1.1.3	Detailed procedure in the VLR	366
19.1.1.4	Detailed procedure in the HLR	385
19.1.1.5	Send Identification	391
19.1.1.5.1	General	391
19.1.1.5.2	Detailed procedure in the VLR	391
19.1.1.5.3	Detailed procedure in the PVLR	391
19.1.1.6	The Process Update Location VLR.....	393
19.1.1.7	The Process Subscriber Present HLR.....	395
19.1.1.8	Detailed procedure in the SGSN	397
19.1.2	Location Cancellation	400
19.1.2.1	General.....	400
19.1.2.2	Detailed procedure in the HLR	401
19.1.2.3	Detailed procedure in the VLR	401
19.1.2.4	Detailed procedure in the SGSN	405
19.1.3	Detach IMSI.....	408
19.1.3.1	General.....	408
19.1.3.2	Detailed procedure in the MSC.....	408
19.1.3.3	Detailed procedure in the VLR	408
19.1.4	Purge MS	411
19.1.4.1	General	411
19.1.4.2	Detailed procedure in the VLR	411
19.1.4.3	Detailed procedure in the HLR	412
19.1.4.4	Detailed procedure in the SGSN	412
19.2	Handover procedure	417
19.2.1	General.....	417
19.2.2	Handover procedure in MSC-A	420
19.2.2.1	Basic handover	420
19.2.2.2	Handling of access signalling.....	420
19.2.2.3	Other procedures in stable handover situation	420
19.2.2.4	Subsequent handover	420
19.2.2.5	SDL Diagrams.....	421
19.2.3	Handover procedure in MSC-B	434
19.2.3.1	Basic handover	434
19.2.3.2	Allocation of handover number.....	434
19.2.3.3	Handling of access signalling.....	434
19.2.3.4	Other procedures in stable handover situation	434
19.2.3.5	Subsequent handover	434
19.2.3.6	SDL Diagrams.....	434
19.2.4	Handover error handling macro	447
19.2.5	Handover procedure in VLR.....	449
19.2.5.1	Allocation of handover number.....	449
19.2.5.2	SDL Diagrams.....	449
19.3	Fault recovery procedures	452
19.3.1	VLR fault recovery procedures.....	452
19.3.2	HLR fault recovery procedures.....	454
19.3.3	VLR restoration: the restore data procedure in the HLR	462
19.4	Macro Insert_Subs_Data_Framed_HLR	464
20	Operation and maintenance procedures.....	467
20.1	General	467
20.1.1	Tracing Co-ordinator for the VLR	467
20.1.2	Subscriber Data Management Co-ordinator for the VLR	469
20.1.3	Tracing Co-ordinator for the SGSN.....	471
20.1.4	Subscriber Data Management Co-ordinator for the SGSN	473
20.2	Tracing procedures	475
20.2.1	Procedures in the HLR.....	477
20.2.1.1	Subscriber tracing activation procedure	477
20.2.1.2	Subscriber tracing deactivation procedure	482

20.2.2	Procedures in the VLR.....	487
20.2.2.1	Subscriber tracing activation procedure.....	487
20.2.2.2	Subscriber tracing deactivation procedure	489
20.2.2.3	Subscriber tracing procedure.....	491
20.2.3	Procedures in the MSC	491
20.2.3.1	Subscriber tracing procedure.....	491
20.2.4	Procedures in the SGSN	491
20.2.4.1	Subscriber tracing activation procedure	491
20.2.4.2	Subscriber tracing deactivation procedure in SGSN	491
20.3	Subscriber data management procedures	494
20.3.1	Procedures in the HLR.....	495
20.3.1.1	Subscriber deletion procedure.....	495
20.3.1.2	Subscriber data modification procedure.....	497
20.3.2	Procedures in the VLR.....	502
20.3.2.1	Subscriber deletion procedure.....	502
20.3.2.2	Subscriber data modification procedure.....	502
20.3.3	Procedures in the SGSN	505
20.3.3.1	Subscriber deletion procedure.....	505
20.3.3.2	Subscriber data modification procedure.....	505
20.4	Subscriber Identity procedure.....	508
20.4.1	Subscriber identity procedure in the HLR	508
20.4.2	Subscriber identity procedure in the VLR	510
21	Call handling procedures.....	512
21.1	General	512
21.2	Retrieval of routing information.....	513
21.2.1	General.....	513
21.2.2	Process in the GMSC.....	514
21.2.3	Procedures in the HLR.....	518
21.2.4	Process in the VLR to provide a roaming number.....	524
21.2.5	Process in the VLR to restore subscriber data	526
21.2.6	Process in the VLR to provide subscriber information.....	528
21.2.7	Process in the HLR for Any Time Interrogation.....	530
21.2.7.1	Process in the gsmSCF.....	530
21.2.3	Process in the HLR	530
21.3	Transfer of call handling	534
21.3.1	General.....	534
21.3.2	Process in the VMSC.....	534
21.3.3	Process in the GMSC.....	537
21.4	Inter MSC Group Call Procedures	538
21.4.1	General.....	538
21.4.2	Process in the Anchor MSC	539
21.4.3	Process in the Relay MSC	545
21.5	Allocation and modifications of resources in an SIWFS.....	550
21.5.1	General.....	550
21.5.2	Process in the VMSC.....	553
21.5.2.1	Allocation of SIWFS resources.....	553
21.5.2.2	Modification of SIWFS resources initiated by the user	554
21.5.2.3	Modification of SIWFS resources initiated by the SIWFS	554
21.5.3	Process in the SIWFS	562
21.5.3.1	Procedures for allocation of SIWFS resources.....	562
21.5.3.2	Process for modification of SIWFS resources initiated by the user	563
21.5.3.3	Process for modification of SIWFS resources initiated by the SIWFS	563
21.6	Setting of Reporting State	569
21.6.1	General.....	569
21.6.2	Process in the HLR for Set Reporting State stand-alone	569
21.6.3	Reporting co-ordinator process in the VLR	572
21.6.4	Process in the VLR to set the reporting state	574
21.7	Status Reporting	577
21.7.1	General.....	577
21.7.2	Process in the VLR for Status Reporting	577
21.7.3	Process in the HLR for Status Reporting	581

21.8	Remote User Free.....	586
21.8.1	General.....	586
21.8.2	Process in the HLR for Remote User Free.....	586
21.8.3	Process in the VLR for Remote User Free.....	589
22	Supplementary services procedures	592
22.1	Functional supplementary service processes	592
22.1.1	Functional supplementary service process co-ordinator for MSC	592
22.1.2	Functional supplementary service process co-ordinator for VLR.....	594
22.1.3	Functional supplementary service process co-ordinator for HLR.....	597
22.1.4	Call completion supplementary service process co-ordinator for HLR	600
22.2	Registration procedure	602
22.2.1	General.....	602
22.2.2	Procedures in the MSC	602
22.2.3	Procedures in the VLR.....	605
22.2.4	Procedures in the HLR.....	608
22.3	Erasure procedure.....	611
22.3.1	General.....	611
22.3.2	Procedures in the MSC	611
22.3.3	Procedures in the VLR.....	612
22.3.4	Procedures in the HLR.....	612
22.4	Activation procedure	612
22.4.1	General.....	612
22.4.2	Procedures in the MSC	613
22.4.3	Procedures in the VLR.....	615
22.4.4	Procedures in the HLR.....	618
22.5	Deactivation procedure.....	621
22.5.1	General.....	621
22.5.2	Procedures in the MSC	622
22.5.3	Procedures in the VLR.....	622
22.5.4	Procedures in the HLR.....	622
22.6	Interrogation procedure	622
22.6.1	General.....	622
22.6.2	Procedures in the MSC	623
22.6.3	Procedures in the VLR.....	623
22.6.4	Procedures in the HLR.....	627
22.7	Invocation procedure	629
22.7.1	General.....	629
22.7.2	Procedures in the MSC	629
22.7.3	Procedures in the VLR.....	633
22.8	Password registration procedure.....	635
22.8.1	General.....	635
22.8.2	Procedures in the MSC	636
22.8.3	Procedures in the VLR.....	636
22.8.4	Procedures in the HLR.....	636
22.9	Mobile Initiated USSD procedure	639
22.9.1	General.....	639
22.9.2	Procedures in the MSC	639
22.9.3	Procedures in the VLR.....	643
22.9.4	Procedures in the HLR.....	648
22.9.5	Procedures in the gsmSCF.....	652
	Procedures in the gsmSCF	653
22.10	Network initiated USSD procedure.....	655
22.10.1	General.....	655
22.10.2	Procedure in the MSC	655
22.10.3	Procedure in the VLR	660
22.10.4	Procedure in the HLR	667
22.11	Common macros for clause 22	673
22.11.1	SS Password handling macros	674
22.11.2	SS Error handling macros	677
22.12	Supplementary Service Invocation Notification procedure.....	683
22.12.1	General.....	683

22.12.2	Procedures in the MSC	683
22.12.3	Procedures in the gsmSCF.....	685
22.13	Activation of a CCBS request	687
22.13.1	General.....	687
22.13.2	Procedure in the VLR	687
22.13.3	Procedure in the HLR	690
22.14	Deactivation of a CCBS request.....	692
22.14.1	General.....	692
22.14.2	Procedure in the VLR	692
22.14.3	Procedure in the HLR	695
23	Short message service procedures	697
23.1	General	697
23.1.1	Mobile originated short message service Co-ordinator for the MSC.....	697
23.1.2	Short message Gateway Co-ordinator for the HLR	699
23.1.3	Mobile originated short message service Co-ordinator for the SGSN	701
23.2	The mobile originated short message transfer procedure	703
23.2.1	Procedure in the servicing MSC	703
23.2.2	Procedure in the VLR	708
23.2.3	Procedure in the interworking MSC	710
23.2.4	Procedure in the servicing SGSN	712
23.3	The mobile terminated short message transfer procedure	716
23.3.1	Procedure in the Servicing MSC.....	718
23.3.2	Procedures in the VLR.....	727
23.3.3	Procedures in the HLR.....	731
23.3.4	Procedures in the gateway MSC	740
23.3.5	Procedure in the Servicing SGSN	750
23.4	The Short Message Alert procedure	758
23.4.1	Procedures in the Servicing MSC.....	760
23.4.2	Procedures in the VLR.....	762
23.4.2.1	The Mobile Subscriber is present.....	762
23.4.2.2	The Mobile Equipment has memory available.....	762
23.4.3	Procedures in the HLR.....	764
23.4.4	Procedures in the Interworking MSC	767
23.4.5	Procedures in the Servicing SGSN	769
23.4.5.1	The Mobile Subscriber is present.....	769
23.4.5.2	The Mobile Equipment has memory available.....	769
23.5	The SM delivery status report procedure	771
23.5.1	Procedures in the HLR.....	771
23.5.2	Procedures in the gateway MSC	773
23.6	Common procedures for the short message clause.....	775
23.6.1	The macro Report_SM_Delivery_Stat_HLR.....	775
24	GPRS process description	777
24.1	General	777
24.1.1	Process in the HLR for Send Routing Information for GPRS	777
24.1.2	Process in the GGSN for Send Routing Information for GPRS.....	779
24.2.1	Process in the HLR for Failure Report.....	781
24.2.2	Process in the GGSN for Failure Report.....	783
24.3.1	Process in the GGSN for Note Ms Present For Gprs	785
24.3.2	Process in the HLR for Note Ms Present For Gprs	787
25	General macro description.....	789
25.1	MAP open macros	789
25.1.1	Macro Receive_Open_Ind	789
25.1.2	Macro Receive_Open_Cnf	789
25.2	Macros to check the content of indication and confirmation primitives.....	794
25.2.1	Macro Check_Indication.....	794
25.2.2	Macro Check_Confirmation	794
25.3	The page and search macros	797
25.3.1	Macro PAGE_MSC	797
25.3.2	Macro Search_For_MS_MSC	798
25.4	Macros for handling an Access Request.....	801

25.4.1	Macro Process_Access_Request_MSC	801
25.4.2	Macro Process_Access_Request_VLR.....	806
25.4.3	Macro Identification Procedure	808
25.5	Authentication macros and processes.....	813
25.5.1	Macro Authenticate_MSC	813
25.5.2	Macro Authenticate_VLR.....	813
25.5.3	Process Obtain_Authentication_Sets_VLR	813
25.5.4	Macro Obtain_Authent_Para_VLR	813
25.5.5	Process Obtain_Auth_Sets_HLR	814
25.5.6	Process Obtain_Authent_Para_SGSN	821
25.6	IMEI Handling Macros	825
25.6.1	Macro Check_IMEI_MSC.....	825
25.6.2	Macro Check_IMEI_VLR	825
25.6.3	Process Check_IMEI_EIR	826
25.6.4	Macro Obtain_IMEI_MSC	826
25.6.5	Macro Obtain_IMEI_VLR	826
25.6.6	Process Check_IMEI_SGSN	833
25.7	Insert Subscriber Data Macros	836
25.7.1	Macro Insert_Subs_Data_VLR.....	836
25.7.2	Process Insert_Subs_Data_Stand_Alone_HLR	838
25.7.3	Macro Wait_for_Insert_Subs_Data_Cnf	844
25.7.4	Process Send_Insert_Subs_Data.....	846
25.7.5	Macro Insert_Subs_Data_SGSN	848
25.7.6	Macro Wait_for_Insert_GPRS_Subs_Data_Cnf	850
25.8	Request IMSI Macros.....	852
25.8.1	Macro Obtain_IMSI_MSC	852
25.8.2	Macro Obtain_IMSI_VLR.....	854
25.9	Tracing macros	856
25.9.1	Macro Trace_Subscriber_Activity_MSC	856
25.9.2	Macro Trace_Subscriber_Activity_VLR	858
25.9.3	Macro Activate_Tracing_VLR	860
25.9.4	Macro Control_Tracing_HLR	862
25.9.5	Macro Trace_Subscriber_Activity_SGSN.....	865
25.9.6	Macro Activate_Tracing_SGSN.....	867
25.10	Short Message Alert procedures.....	869
25.10.1	Subscriber_Present_VLR process.....	869
25.10.2	Macro Alert_Service_Centre_HLR	871
25.10.3	The Mobile Subscriber is present	874
Annex A (informative): Cross-reference for abstract syntaxes of MAP		876
Annex B (informative): Fully expanded ASN.1 sources for abstract syntaxes of MAP		1043
B.1	Fully Expanded ASN.1 Source of MAP-Protocol/TCAPMessages	1043
B.2	Fully Expanded ASN.1 Source of MAP-DialogueInformation.....	1106
Annex C : Void.....		1110
Annex D (informative): Clause mapping table		1111
D.1	Mapping of Clause numbers.....	1111
Annex E (informative): Change History.....		1112

Foreword

This Technical Specification has been produced by the 3rd Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
 - 1 presented to TSG for information;
 - 2 presented to TSG for approval;
 - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

1 Scope

It is necessary to transfer between entities of a Public Land Mobile Network (PLMN) information specific to the PLMN in order to deal with the specific behaviour of roaming Mobile Stations (MS)s. The Signalling System No. 7 specified by CCITT is used to transfer this information.

This Technical Specification (TS) describes the requirements for the signalling system and the procedures needed at the application level in order to fulfil these signalling needs.

Clauses 1 to 6 are related to general aspects such as terminology, mobile network configuration and other protocols required by MAP.

MAP consists of a set of MAP services which are provided to MAP service-users by a MAP service-provider.




Figure 1.1/1: Modelling principles

Clauses 7 to 12 of the present document describe the MAP services.

Clauses 14 to 17 define the MAP protocol specification and the behaviour of service provider (protocol elements to be used to provide MAP services, mapping on to TC service primitives, abstract syntaxes, etc.).

Clauses 18 to 25 describe the MAP user procedures which make use of MAP services.

2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the same Release as the present document*.

- [1] GSM 01.04: "Digital cellular telecommunications system (Phase 2+); Abbreviations and acronyms".
- [2] GSM 02.01: "Digital cellular telecommunications system (Phase 2+); Principles of telecommunication services supported by a GSM Public Land Mobile Network (PLMN)".
- [3] GSM 02.02: "Digital cellular telecommunications system (Phase 2+); Bearer Services (BS) Supported by a GSM Public Land Mobile Network (PLMN)".
- [4] GSM 02.03: "Digital cellular telecommunications system (Phase 2+); Teleservices Supported by a GSM Public Land Mobile Network (PLMN)".
- [5] GSM 02.04: "Digital cellular telecommunications system (Phase 2+); General on supplementary services".
- [6] GSM 02.09: "Digital cellular telecommunications system (Phase 2+); Security aspects".
- [7] GSM 02.16: "Digital cellular telecommunications system (Phase 2+); International Mobile station Equipment Identities (IMEI)".
- [8] GSM 02.41: "Digital cellular telecommunications system (Phase 2+); Operator determined barring".
- [9] GSM 02.81: "Digital cellular telecommunications system (Phase 2+); Line identification supplementary services - Stage 1".
- [10] GSM 02.82: "Digital cellular telecommunications system (Phase 2+); Call Forwarding (CF) supplementary services - Stage 1".
- [11] GSM 02.83 : "Digital cellular telecommunications system (Phase 2+); Call Waiting (CW) and Call Hold (HOLD) supplementary services - Stage 1".
- [12] GSM 02.84: "Digital cellular telecommunications system (Phase 2+); Multi Party (MPTY) supplementary services - Stage 1".
- [13] GSM 02.85: "Digital cellular telecommunications system (Phase 2+); Closed User Group (CUG) supplementary services - Stage 1".
- [14] GSM 02.86: "Digital cellular telecommunications system (Phase 2+); Advice of charge (AoC) supplementary services - Stage 1".
- [15] GSM 02.88: "Digital cellular telecommunications system (Phase 2+); Call Barring (CB) supplementary services - Stage 1".
- [16] GSM 02.90: "Digital cellular telecommunication system (Phase 2+); Unstructured supplementary services operation - Stage 1".
- [17] GSM 03.03: "Digital cellular telecommunications system (Phase 2+); Numbering, addressing and identification".

- [18] GSM 03.04: "Digital cellular telecommunications system (Phase 2+); Signalling requirements relating to routeing of calls to mobile subscribers".
- [19] GSM 03.07: "Digital cellular telecommunications system (Phase 2+); Restoration procedures".
- [20] GSM 03.08: "Digital cellular telecommunications system (Phase 2+); Organisation of subscriber data".
- [21] GSM 03.09: "Digital cellular telecommunications system (Phase 2+; Handover procedures".
- [22] GSM 03.11: "Digital cellular telecommunications system (Phase 2+); Technical realization of supplementary services".
- [23] GSM 03.12: "Digital cellular telecommunications system (Phase 2+); Location registration procedures".
- [24] GSM 03.20: "Digital cellular telecommunications system (Phase 2+); Security related network functions".
- [25] GSM 03.38: "Digital cellular telecommunications system (Phase 2+); Alphabets and language specific information for GSM".
- [26] GSM 03.40: "Digital cellular telecommunications system (Phase 2+); Technical realization of the Short Message Service (SMS) Point to Point (PP)".
- [26a] GSM 03.71: "Digital cellular telecommunications system (Phase 2+); Location Services (LCS); Functional Description; Stage 2".
- [27] GSM 03.81: "Digital cellular telecommunications system (Phase 2+); Line identification supplementary services - Stage 2".
- [28] GSM 03.82: "Digital cellular telecommunications system (Phase 2+); Call Forwarding (CF) supplementary services - Stage 2".
- [29] GSM 03.83: "Digital cellular telecommunications system (Phase 2+); Call Waiting (CW) and Call Hold (HOLD) supplementary services - Stage 2".
- [30] GSM 03.84: "Digital cellular telecommunications system (Phase 2+); Multi Party (MPTY) supplementary services - Stage 2".
- [31] GSM 03.85: "Digital cellular telecommunications system (Phase 2+); Closed User Group (CUG) supplementary services - Stage 2".
- [32] GSM 03.86: "Digital cellular telecommunications system (Phase 2+); Advice of Charge (AoC) supplementary services - Stage 2".
- [33] GSM 03.88: "Digital cellular telecommunications system (Phase 2+); Call Barring (CB) supplementary services - Stage 2".
- [34] GSM 03.90: "Digital cellular telecommunications system (Phase 2+); Unstructured supplementary services operation - Stage 2".
- [35] GSM 04.08: "Digital cellular telecommunications system (Phase 2+); Mobile radio interface layer 3 specification".
- [36] GSM 04.10: "Digital cellular telecommunications system (Phase 2+); Mobile radio interface layer 3 Supplementary services specification General aspects".
- [37] GSM 04.11: "Digital cellular telecommunications system (Phase 2+); Point-to-Point (PP) Short Message Service (SMS) support on mobile radio interface".
- [37a] GSM 04.71: "Digital cellular telecommunications system (Phase 2+); Mobile radio interface layer 3 location services specification".
- [38] GSM 04.80: "Digital cellular telecommunications system (Phase 2+); Mobile radio interface layer 3 supplementary services specification Formats and coding".

- [39] GSM 04.81: "Digital cellular telecommunications system (Phase 2+); Line identification supplementary services - Stage 3".
- [40] GSM 04.82: "Digital cellular telecommunications system (Phase 2+); Call Forwarding (CF) supplementary services - Stage 3".
- [41] GSM 04.83: "Digital cellular telecommunications system (Phase 2+); Call Waiting (CW) and Call Hold (HOLD) supplementary services - Stage 3".
- [42] GSM 04.84: "Digital cellular telecommunications system (Phase 2+); Multi Party (MPTY) supplementary services - Stage 3".
- [43] GSM 04.85: "Digital cellular telecommunications system (Phase 2+); Closed User Group (CUG) supplementary services - Stage 3".
- [44] GSM 04.86: "Digital cellular telecommunications system (Phase 2+); Advice of Charge (AoC) supplementary services - Stage 3".
- [45] GSM 04.88: "Digital cellular telecommunications system (Phase 2+); Call Barring (CB) supplementary services - Stage 3".
- [46] GSM 04.90: "Digital cellular telecommunications system (Phase 2+); Unstructured supplementary services operation - Stage 3".
- [47] GSM 08.02: "Digital cellular telecommunications system (Phase 2+); Base Station System - Mobile-services Switching Centre (BSS - MSC) interface Interface principles".
- [48] GSM 08.06: "Digital cellular telecommunications system (Phase 2+); Signalling transport mechanism specification for the Base Station System - Mobile-services Switching Centre (BSS - MSC) interface".
- [49] GSM 08.08: "Digital cellular telecommunications system (Phase 2+); Mobile Switching Centre - Base Station System (MSC - BSS) interface Layer 3 specification".
- [49a] GSM 08.31: "Digital cellular telecommunications system (Phase 2+); Location Services (LCS); Serving Mobile Location Center (SMLC) – Serving Mobile Location Center (SMLC); SMLC Peer Protocol (SMLCPP)."
- [49b] GSM 08.71: "Digital cellular telecommunications system (Phase 2+); Location Services (LCS); Serving Mobile Location Centre - Base Station System (SMLC - BSS) interface Layer 3 specification".
- [50] GSM 09.01: "Digital cellular telecommunications system (Phase 2+); General network interworking scenarios".
- [51] GSM 09.02: "Digital cellular telecommunications system (Phase 1); Mobile Application Part (MAP) specification".
- [52] GSM 09.03: "Digital cellular telecommunications system (Phase 2+); Signalling requirements on interworking between the Integrated Services Digital Network (ISDN) or Public Switched Telephone Network (PSTN) and the Public Land Mobile Network (PLMN)".
- [53] GSM 09.04: "Digital cellular telecommunications system (Phase 2+); Interworking between the Public Land Mobile Network (PLMN) and the Circuit Switched Public Data Network (CSPDN)".
- [54] GSM 09.05: "Digital cellular telecommunications system (Phase 2+); Interworking between the Public Land Mobile Network (PLMN) and the Packet Switched Public Data Network (PSPDN) for Packet Assembly/Disassembly facility (PAD) access".
- [55] GSM 09.06: "Digital cellular telecommunications system (Phase 2+); Interworking between a Public Land Mobile Network (PLMN) and a Packet Switched Public Data Network/Integrated Services Digital Network (PSPDN/ISDN) for the support of packet switched data transmission services".

- [56] GSM 09.07: "Digital cellular telecommunications system (Phase 2+); General requirements on interworking between the Public Land Mobile Network (PLMN) and the Integrated Services Digital Network (ISDN) or Public Switched Telephone Network (PSTN)".
- [57] GSM 09.08: "Digital cellular telecommunications system (Phase 2+); Application of the Base Station System Application Part (BSSAP) on the E-interface".
- [58] GSM 09.10: "Digital cellular telecommunications system (Phase 2+); Information element mapping between Mobile Station - Base Station System and BSS - Mobile-services Switching Centre (MS - BSS - MSC) Signalling procedures and the Mobile Application Part (MAP)".
- [59] GSM 09.11: "Digital cellular telecommunications system (Phase 2+); Signalling interworking for supplementary services".
- [59a] GSM 09.31: "Digital cellular telecommunications system (Phase 2+); Location Services (LCS); Base Station System Application Part LCS Extension (BSSAP-LE)".
- [60] GSM 09.90: "Digital cellular telecommunications system (Phase 2+); Interworking between Phase 1 infrastructure and Phase 2 Mobile Stations (MS)".
- [61] GSM 12.08: "Digital cellular telecommunications system (Phase 2); Subscriber and Equipment Trace".
- [62] ETS 300 102-1 (1990): "Integrated Services Digital Network (ISDN); User-network interface layer 3 specifications for basic call control".
- [63] ETS 300 136 (1992): "Integrated Services Digital Network (ISDN); Closed User Group (CUG) supplementary service description".
- [64] ETS 300 138 (1992): "Integrated Services Digital Network (ISDN); Closed User Group (CUG) supplementary service Digital Subscriber Signalling System No.one (DSS1) protocol".
- [65] ETS 300 287: "Integrated Services Digital Network (ISDN); Signalling System No.7; Transaction Capabilities (TC) version 2".
- [66] ETR 060: "Signalling Protocols and Switching (SPS); Guide-lines for using Abstract Syntax Notation One (ASN.1) in telecommunication application protocols".
- [67] CCITT Recommendation E.164: "Numbering plan for the ISDN era".
- [68] CCITT Recommendation E.212: "Identification plan for land mobile stations".
- [69] CCITT Recommendation E.213: "Telephone and ISDN numbering plan for land mobile stations".
- [70] CCITT Recommendation E.214: "Structuring of the land mobile global title for the signalling connection control part".
- [71] CCITT Recommendation Q.669: "Interworking between the Digital Subscriber Signalling System Layer 3 protocol and the Signalling System No.7 ISDN User part".
- [72] CCITT Recommendation Q.711: "Specifications of Signalling System No.7; Functional description of the signalling connection control part".
- [73] CCITT Recommendation Q.712: "Definition and function of SCCP messages".
- [74] CCITT Recommendation Q.713: "Specifications of Signalling System No.7; SCCP formats and codes".
- [75] CCITT Recommendation Q.714: "Specifications of Signalling System No.7; Signalling connection control part procedures".
- [76] CCITT Recommendation Q.716: "Specifications of Signalling System No.7; Signalling connection control part (SCCP) performances".
- [77] CCITT Recommendation Q.721 (1988): "Specifications of Signalling System No.7; Functional description of the Signalling System No.7 Telephone user part".

- [78] CCITT Recommendation Q.722 (1988): "Specifications of Signalling System No.7; General function of Telephone messages and signals".
- [79] CCITT Recommendation Q.723 (1988): "Specifications of Signalling System No.7; Formats and codes".
- [80] CCITT Recommendation Q.724 (1988): "Specifications of Signalling System No.7; Signalling procedures".
- [81] CCITT Recommendation Q.725 (1988): "Specifications of Signalling System No.7; Signalling performance in the telephone application".
- [82] CCITT Recommendation Q.761 (1988): "Specifications of Signalling System No.7; Functional description of the ISDN user part of Signalling System No.7".
- [83] CCITT Recommendation Q.762 (1988): "Specifications of Signalling System No.7; General function of messages and signals".
- [84] CCITT Recommendation Q.763 (1988): "Specifications of Signalling System No.7; Formats and codes".
- [85] CCITT Recommendation Q.764 (1988): "Specifications of Signalling System No.7; Signalling procedures".
- [86] CCITT Recommendation Q.767: "Specifications of Signalling System No.7; Application of the ISDN user part of CCITT signalling System No.7 for international ISDN interconnections".
- [87] CCITT Recommendation Q.771: "Specifications of Signalling System No.7; Functional description of transaction capabilities".
- [88] CCITT Recommendation Q.772: "Specifications of Signalling System No.7; Transaction capabilities information element definitions".
- [89] CCITT Recommendation Q.773: "Specifications of Signalling System No.7; Transaction capabilities formats and encoding".
- [90] CCITT Recommendation Q.774: "Specifications of Signalling System No.7; Transaction capabilities procedures".
- [91] CCITT Recommendation Q.775: "Specifications of Signalling System No.7; Guide-lines for using transaction capabilities".
- [92] CCITT Recommendation X.200: "Reference Model of Open systems interconnection for CCITT Applications".
- [93] CCITT Recommendation X.208 (1988): "Specification of Abstract Syntax Notation One (ASN.1)".
- [94] CCITT Recommendation X.209 (1988): "Specification of basic encoding rules for Abstract Syntax Notation One (ASN.1)".
- [95] CCITT Recommendation X.210: "Open systems interconnection layer service definition conventions".
- [96] GSM 09.02: "Digital cellular telecommunications system (Phase 2); Mobile Application Part (MAP) specification".
- [97] GSM 03.18: "Digital cellular telecommunications system (Phase 2+); Basic Call Handling".
- [98] GSM 03.78: "Digital cellular telecommunications system (Phase 2+); Customised Applications for Mobile network Enhanced Logic (CAMEL) - Stage 2".
- [99] GSM 03.79: "Digital cellular telecommunications system (Phase 2+); Support of Optimal Routeing (SOR) - Stage 2".
- [100] GSM 03.68: "Digital cellular telecommunications system (Phase 2+); - Stage 2".

- [101] GSM 03.69: "Digital cellular telecommunications system (Phase 2+); - Stage 2".
- [102] ANSI T1.113: "Signaling System No. 7 (SS7) - ISDN User Part".
- [103] GSM 03.54 "Digital cellular telecommunications system (Phase 2+); Stage 2 Description for the use of a Shared Inter Working Function (SIWF) in a GSM PLMN".
- [104] GSM 03.60: "Digital cellular telecommunications system (Phase 2+); General Packet Radio Service (GPRS) Description; Stage 2".
- [105] GSM 09.60: "Digital cellular telecommunications system (Phase 2+), General Packet Radio Service (GPRS); GPRS Tunnelling Protocol (GTP) across the Gn and Gp Interface".
- [106] GSM 09.18: "Digital cellular telecommunications system (Phase 2+); General Packet Radio Service (GPRS); Serving GPRS Support Node (SGSN) - Visitors Location Register (VLR); Gs interface layer 3 specification".
- [107] GSM 03.93: "Digital cellular telecommunications system (Phase 2+); Technical Realization of Completion of Calls to Busy Subscriber (CCBS); Stage 2".
- [108] GSM 03.66: "Digital cellular telecommunications system (Phase 2+); Support of Mobile Number Portability (MNP); Technical Realisation Stage 2".
- [109] ANSI T1.112 (1996): "Telecommunication – Signaling No. 7 – Signaling Connection Control Part (SCCP)".

3 Abbreviations

Abbreviations used in the present document are listed in GSM 01.04.

4 Configuration of the mobile network

4.1 The entities of the mobile system

To provide the mobile service as it is defined, it is necessary to introduce some specific functions. These functional entities can be implemented in different equipments or integrated. In any case, exchanges of data occur between these entities.

4.1.1 The Home Location Register (HLR)

This functional entity is a data base in charge of the management of mobile subscribers. A PLMN may contain one or several HLRs; it depends on the number of mobile subscribers, on the capacity of the equipment and on the organization of the network. All subscription data are stored there. The main information stored there concerns the location of each MS in order to be able to route calls to the mobile subscribers managed by each HLR. All management interventions occur on this data base. The HLRs have no direct control of MSCs.

Two numbers attached to each mobile subscription are stored in the HLR:

- IMSI;
- MSISDN.

The data base contains other information such as:

- location information (VLR number);
- basic telecommunication services subscription information;
- service restrictions (e.g. roaming limitation);

- supplementary services; the tables contain the parameters attached to these services;
- GPRS subscription data and routeing information.

The organization of the subscriber data is detailed in GSM 03.08.

4.1.2 The Visitor Location Register (VLR)

An MS roaming in an MSC area is controlled by the Visitor Location Register in charge of this area. When an MS appears in a location area it starts a location updating procedure. The MSC in charge of that area notices this registration and transfers to the Visitor Location Register the identity of the location area where the MS is situated. A VLR may be in charge of one or several MSC areas.

The VLR also contains the information needed to handle the calls set up or received by the MSs registered in its data base (in some cases the VLR may have to obtain additional information from the HLR); the following elements can be found in its tables:

- the IMSI;
- the MSISDN;
- the TMSI, if applicable;
- the location area where the MS has been registered. This will be used to call the station;
- supplementary service parameters.

The information is passed between VLR and HLR by the procedures described in GSM 03.12.

The organization of the subscriber data is detailed in GSM 03.08.

4.1.3 The Mobile-services Switching Centre (MSC)

The Mobile-services Switching Centre is an exchange which performs all the switching functions for MSs located in a geographical area designated as the MSC area. The main difference between an MSC and an exchange in a fixed network is that the MSC has to take into account the impact of the allocation of radio resources and the mobile nature of the subscribers and has to perform, for example, the following procedures:

- procedures required for the location registration (see GSM 03.12);
- procedures required for hand-over (see GSM 03.09).

4.1.4 The Base Station System (BSS)

The BSS is the sub-system of Base Station equipment (transceivers, controllers, etc...) which is viewed

- by the MSC through an interface (A-interface) with the functionality described in GSM 08.02;
- by the SGSN through an interface (Gb-interface) with the functionality described in GSM 03.60.

4.1.5 The Gateway MSC (GMSC)

In the case of incoming calls to the PLMN, if the fixed network is unable to interrogate the HLR, the call is routed to an MSC. This MSC will interrogate the appropriate HLR and then route the call to the MSC where the MS is located. The MSC which then performs the routing function to the actual location of the mobile is called the Gateway MSC.

The choice of which MSCs can act as Gateway MSCs is a network operator matter (e.g. all MSCs or some designated MSCs).

If the call is a voice group/broadcast call it is routed directly from the GMSC to the VBS/VGCS Anchor MSC, based on information (VBS/VGCS call reference) contained in the dialled number. See also GTSSs 03.68 and 03.69.

See also GSM 03.04.

4.1.6 The SMS Gateway MSC

The SMS GMSC is the interface between the Mobile Network and the network which provides access to the Short Message Service Centre, for short messages to be delivered to MSs.

The choice of which MSCs can act as SMS Gateway MSCs is a network operator matter (e.g. all MSCs or some designated MSCs).

4.1.7 The SMS Interworking MSC

The SMS IWMSC is the interface between the Mobile Network and the network which provides access to the Short Message Service Centre, for short messages submitted by MSs.

The choice of which MSCs can act as SMS Interworking MSCs is a network operator matter (e.g. all MSCs or some designated MSCs).

4.1.8 The VBS/VGCS Anchor MSC

The voice broadcast/group call anchor MSC obtains from the associated GCR all relevant attributes and controls in turn all cells in its area, VBS/VGCS Relay-MSCs and dispatchers belonging to a given group call.

4.1.9 The Equipment Identity Register (EIR)

This functional unit is a data base in charge of the management of the equipment identities of the MSs; see also GSM 02.16.

4.1.10 The GSM Service Control Function (gsmSCF)

This functional entity contains the CAMEL service logic to implement OSS. It interfaces with the gsmSSF and the HLR; see also TS GSM 03.78.

4.1.11 The VBS/VGCS Relay MSC

The voice broadcast/group call relay MSC obtains from the associated anchor MSC all relevant attributes and controls in turn all cells in its area belonging to a given group call.

4.1.12 The Group Call Register (GCR)

This functional unit is a data base in charge of the management of attributes related to the establishment of Voice Broadcast Calls and Voice Group Calls

4.1.13 The Shared InterWorking Function Server (SIWFS)

A Shared Inter Working Function is a network function that may be used by any MSC in the same PLMN to provide interworking for a data/fax call. Whereas an IWF can only be used by its MSC, the SIWF can be used by several other network nodes e.g. any MSC within the same PLMN (the concept is not limited to a certain number of MSCs). SIWF is applied to data services in GSM Phase 2 and GSM Phase 2+ (as defined in GSM 02.02, GSM 02.03 and GSM 02.34).

The usage of an SIWF requires no additional manipulation at the MS.

An IWF provides specific functions associated with the visited MSC for the interworking with other networks. It comprises signalling and traffic channel related functions. The traffic channel related functions are provided by an Inter Working Unit (IWU).

The SIWF concept is that it provides specific functions for the interworking with other networks. It comprises signalling and traffic channel related functions. Whereas the signalling related functions are associated with the visited MSC, the IWU providing the traffic channel related functions has another physical location.

The entity that contains all additional functions needed in the visited MSC to provide the SIWF is called SIWF Controller (SIWFC). The entity where the IWU is located is called SIWF Server (SIWFS). The Interface between a visited MSC and a SIWFS is called the K Interface.

SIWFS can be provided by a MSC (MSC/SIWFS) or by another network entity (stand alone SIWFS).

4.1.14 The Serving GPRS Support Node (SGSN)

This functional unit keeps track of the individual MSs' location and performs security functions and access control; see also GSM 03.60.

4.1.15 The Gateway GPRS Support Node (GGSN)

This functional unit provides interworking with external packet-switched networks, network screens and routing of the Network Requested PDP-context activation; see also GSM 03.60.4.2 "Configuration of a Public Land Mobile Network (PLMN)".

The basic configuration of a Public Land Mobile Network is presented in figure 4.2/1. In this figure the most general solution is described in order to define all the possible interfaces which can be found in any PLMN. The specific implementation in each network may be different: some particular functions may be implemented in the same equipment and then some interfaces may become internal interfaces. In any case the configuration of a PLMN must have no impact on the relationship with the other PLMNs.

In this configuration, all the functions are considered implemented in different equipments. Therefore, all the interfaces are external and need the support of the Mobile Application Part of the Signalling System No. 7 to exchange the data necessary to support the mobile service. From this configuration, all the possible PLMN organizations can be deduced.

4.1.16 The Number Portability Location Register (NPLR)

This functional unit provides routing information necessary in some Mobile Number Portability environments in order to route calls for ported mobile subscribers. For details see also GSM 03.66 [108].

4.1.17 The Serving Mobile Location Center (SMLC)

An SMLC is a database and processing entity that manages the procedures for obtaining the geographic location of a target MS in the coverage area served by the SMLC. In managing the location procedures, the SMLC chooses the positioning method and provides data and instructions to the LMUs or target MS that perform the actual location measurements associated with the chosen method. The SMLC also verifies any location estimate computed by the target MS or computes a location itself from measurements provided to it by the target MS or LMUs.

An SMLC also manages a set of LMUs in its coverage area whose purpose is to provide location measurements and location assistance data to the SMLC to compute, or assist in computing, location estimates for target MSs. Management functions performed by an SMLC on behalf of its LMUs include maintaining the status and current serving MSC of each LMU and supporting O&M procedures,

The database in an SMLC contains data necessary for choosing an appropriate position method and any parameters associated with this method for a target MS in any serving cell, for computing or verifying location estimates and for managing its LMUs.

An SMLC may be either NSS based or BSS based. An NSS based SMLC supports positioning and management of its LMUs via interaction with one or more MSCs using the Ls interface. A BSS based SMLC supports positioning and management of its LMUs via interaction with one or more BSCs using the Lb interface.

4.1.18 The Gateway Mobile Location Center (GMLC)

The GMLC provides access to location services (LCS) for LCS clients external to a PLMN. A GMLC may also support access to location services from LCS clients internal to its own PLMN. The GMLC allows an LCS client to issue location requests for certain target MSs; it then conveys these requests to the VMSC currently serving each target MS and passes back the location results to the LCSclient. Any target MS whose location is requested may belong to either the GMLC's own PLMN or another PLMN and may currently be served by either the GMLC's own PLMN or another PLMN.

4.1.19 The Location Measurement Unit (LMU)

The LMU is the logical network entity that performs location measurements in the VPLMN in order to either position a target MS or provide assistance data to be used in conjunction with other location measurements. An LMU is controlled by an SMLC in the VPLMN from which location commands can be received and to which any location measurements are returned.




Figure 4.2/1: Configuration of a PLMN

4.2 Void

4.3 Interconnection between PLMNs

Since the configuration of a PLMN does not have any impact on other PLMNs, the signalling interfaces specified can be implemented both between the entities within a PLMN and between different PLMNs.

4.4 The interfaces within the mobile service

4.4.1 Interface between the HLR and the VLR (D-interface)

This interface is used to exchange the data related to the location of the MS and to the management of the subscriber. The main service provided to the mobile subscriber is the capability to set up or to receive calls within the whole service area. To support that purpose the location registers have to exchange data. The VLR informs the HLR on the registration of a MS managed by the latter and provides it with the relevant location information. The HLR sends to the VLR all the data needed to support the service to the MS. The HLR then calls the previous VLR to inform it that it can cancel the location registration of this station because of the roaming of the mobile.

Exchanges of data may also occur when the mobile subscriber requires a particular service, when he wants to change some data attached to his subscription or when some parameters of the subscription are modified by administrative means.

4.4.2 Interface between the HLR and the gsmSCF (J-interface)

This interface is used by the gsmSCF to request information from the HLR (via the Any-time Interrogation function) or to allow call independent related network- or user-initiated interaction between an MS and the gsmSCF (via the USSD function). Support of the gsmSCF-HLR interface is a network operator option. As a network operator option, the HLR may refuse to provide the information requested by the gsmSCF.

4.4.3 Interface between the VLR and its associated MSC(s) (B-interface)

The VLR is the location and management data base for the MSs roaming in the area controlled by the associated MSC(s). Whenever the MSC needs data related to a given MS currently located in its area, it interrogates the VLR. When a MS initiates a location updating procedure with an MSC, the MSC informs its VLR which stores the relevant information in its tables. This procedure occurs whenever a mobile roams to another location area. Also, for instance when a subscriber activates a specific supplementary service or modifies some data attached to a service, the MSC transfers (via the VLR) the request to the HLR, which stores these modifications and updates the VLR if required.

However, this interface is not fully operational specified. It is strongly recommended not to implement the B-interface as an external interface.

4.4.4 Interface between VLRs (G-interface)

When an MS initiates a location updating using TMSI, the VLR can fetch the IMSI and authentication set from the previous VLR.

4.4.5 Interface between the HLR and the MSC (C-interface)

When the fixed network is not able to perform the interrogation procedure needed to set up a call to a mobile subscriber, the Gateway MSC has to interrogate the HLR of the called subscriber to obtain the roaming number of the called MS (see GSM 03.04).

To forward a short message to a mobile subscriber, the SMS Gateway MSC has to interrogate the HLR to obtain the MSC number where the MS is located.

4.4.6 Interface between the MSC and the gsmSCF (L-interface)

When one of the following Supplementary Services, CD, ECT or MPTY, is invoked in the MSC a notification shall be sent towards the gsmSCF.

4.4.7 Interface between MSCs (E-interface)

When a MS moves from one MSC area to another during a call, a handover procedure has to be performed in order to continue the communication. For that purpose the MSCs involved have to exchange data to initiate and then to realize the operation.

This interface is also used to forward short messages, to perform location for a target MS for which handover has occurred on an established call and to transfer LCS messages to and from an LMU for which handover of a signalling channel has occurred.

This interface is also used to transfer information for inter-MSC VBS/VGCS calls .

4.4.8 Interface between the MSC and Base Station Systems (A-interface)

The description of this interface is contained in the GSM 08-series of MSs.

The BSS-MSC interface carries information concerning:

- BSS management;
- call handling;
- location management.

4.4.9 Interface between MSC and EIR (F-interface)

This interface is used when an MSC wants to check an IMEI.

4.4.10 Interface between VBS/VGCS Anchor MSC and GCR (I-interface)

This is an internal interface.

4.4.11 Interface between the MSC and the SIWF server (K-interface)

When a MSC detects that it can not provide the requested IW function, resources from an SIWF server can be used. This interface is used to allocate resources in that SIWF server and establish required physical connections to that server.

4.4.12 Interface between SGSN and HLR (Gr-interface)

The description of this interface is contained in the GSM 03.60.

4.4.13 Interface between SGSN and SMS-GMSC or SMS-IWMSC (Gd-interface)

The description of this interface is contained in the GSM 03.60.

4.4.14 Interface between GGSN and HLR (Gc-interface)

The description of this interface is contained in the GSM 03.60.

4.4.15 Interface between SGSN and EIR (Gf-interface)

The description of this interface is contained in the GSM 03.60.

4.4.16 Interface between SGSN and BSC (Gb-interface)

The description of this interface is contained in the GSM 03.60.

4.4.17 Interface between SGSN and MSC/VLR (Gs-interface)

The description of this interface is contained in the GSM 09.18.

4.4.17A Interface between SMLC and BSC (Lb interface)

This interface is used by a BSC when an SMLC is BSS based to request either the initiation of location procedures or the retrieval of location assistance data for a particular target MS in the coverage area served by the SMLC. The interface is also used to transfer LCS measurement and O&M information between an SMLC and LMU via the BSC. A description of this interface is contained in GSM 03.71 and GSM 09.31.

4.4.18 Interface between SMLC and MSC (Ls interface)

This interface is used by the MSC when an SMLC is NSS based to request either the initiation of location procedures or the retrieval of location assistance data for a particular target MS in the coverage area served by the SMLC. The interface is also used to transfer LCS measurement and O&M information between an SMLC and LMU or BSC via the MSC. A description of this interface is contained in GSM 03.71 and GSM 09.31.

4.4.18A Interface between SMLC and SMLC (Lp interface)

This interface is used by an SMLC to obtain LCS measurement information from an LMU controlled by another SMLC. A description of this interface is contained in GSM 03.71 and GSM 08.31.

4.4.19 Void

4.4.20 Interface between GMLC and HLR (Lh interface)

This interface is used by the GMLC to request the address of the visited MSC for a particular target MS whose location has been requested.

4.4.21 Interface between GMLC and MSC (Lg interface)

This interface is used by the GMLC to convey a location request to the MSC currently serving a particular target MS whose location was requested. The interface is used by the MSC to return location results to the GMLC.

4.4.22 Interface between LCS Client and GMLC (Le interface)

This interface is used by a client of the Location Services (LCS) to request location information from a GMLC for certain target MSs. The interface is used by the GMLC to provide location information to an LCS client. This interface is external to a PLMN and is not defined within GSM.

4.5 Splitting of the data storage

The data attached to each MS management, operation and location are stored in the Location Registers. Some data are duplicated in the HLR and in the VLR, but others may be stored only in one place.

The data associated with any client that uses a particular GMLC to access location services is stored in the GMLC.

A detailed description of the data organization can be found in GSM 03.08.

5 Overload and compatibility overview

5.1 Overload control

There is a requirement for an overload/congestion control for all entities of the Public Land Mobile Network and the underlying Signalling System No. 7.

5.1.1 Overload control for MSC (outside MAP)

For the entity MSC the following two procedures (outside MAP) may be applied to control the processor load:

- ISDN
CCITT Recommendation Q.764 (Automatic Congestion Control), applicable to reduce the mobile terminating traffic;
- BSSAP
GSM 08.08 (A-interface Flow Control), applicable to reduce the mobile originating traffic.

5.1.2 Overload control for MAP entities

For all MAP entities, especially the HLR, the following overload control method is applied:

If overload of a MAP entity is detected, requests for certain MAP operations (see tables 5.1/1, 5.1/2, 5.1/3 and 5.1/4) may be ignored by the responder. The decision as to which MAP Operations may be ignored is made by the MAP service provider and is based upon the priority of the application context.

Since most of the affected MAP operations are supervised in the originating entity by TC timers (medium) an additional delay effect is achieved for the incoming traffic.

If overload levels are applicable in the Location Registers the MAP operations should be discarded taking into account the priority of their application context (see table 5.1/1 for HLR, table 5.1/2 for MSC/VLR, table 5.1/3 for the SGSN and table 5.1/4 for the SMLC; the lowest priority is discarded first).

The ranking of priorities given in the tables 5.1/1, 5.1/2, 5.1/3 and 5.1/4 is not normative. The tables can only be seen as a proposal which might be changed due to network operator/implementation matters.

Table 5.1/1: Priorities of Application Contexts for HLR as Responder

Responder = HLR		Initiating Entity
Priority high		
	<i>Mobility Management</i>	
networkLocUp	(updateLocation), (restoreData/v2), (sendParameters/v1)	VLR
gprsLocationUpdate	(updateGPRSLocation/v3),	SGSN
infoRetrieval	(sendAuthenticationInfo/v2), (sendParameters/v1)	VLR/SGSN
msPurging	VLR (purgeMS/v2/v3)	
msPurging	SGSN (purgeMS/v3)	
	<i>Short Message Service</i>	
shortMsgGateway	(sendRoutingInfoforSM), (reportSM-DeliveryStatus)	GMSC
mwdMngt	VLR/SGSN (readyForSM/v2/v3), (noteSubscriberPresent/v1)	
	<i>Mobile Terminating Traffic</i>	
locInfoRetrieval	(sendRoutingInfo)	GMSC
anyTimeEnquiry	(anyTimeInterrogation)	gsmSCF
reporting	(statusReport)	VLR
	<i>Location Services</i>	
locationSvcGateway	(sendRoutingInfoforLCS/v3)	GMLC
	<i>Subscriber Controlled Inputs (Supplementary Services)</i>	
networkFunctionalSs	(registerSS), (eraseSS), (activateSS), (deactivateSS), (interrogateSS), (registerPassword), (processUnstructuredSS-Data/v1), (beginSubscriberActivity/v1)	VLR
callCompletion	(registerCCEntry), (eraseCCEntry)	VLR
networkUnstructuredSs	(processUnstructuredSS-Request/v2)	VLR
imsiRetrieval	(sendIMSI/v2)	VLR
gprsLocationInfoRetrieval	(sendRoutingInfoForGprs/v3)	GGSN/SGSN
failureReport	(failureReport/v3)	GGSN/SGSN
Priority low		

NOTE: The application context name is the last component but one of the object identifier.
 Operation names are given in brackets for information with "/vn" appended to vn only operations.

Table 5.1/2: Priorities of Application Contexts for MSC/VLR as Responder

Responder = MSC/VLR	Initiating Entity
<i>Priority high</i>	
<i>Handover</i>	
handoverControl (prepareHandover/v2), (performHandover/v1)	MSC
<i>Group call and Broadcast call</i>	
groupCallControl (prepareGroupCall/v3)	MSC
<i>Mobility and Location Register Management</i>	
locationCancel (cancelLocation)	HLR
reset (reset)	HLR
interVlrInfoRetrieval (sendIdentification/v2), (sendParameters/v1)	VLR
subscriberDataMngt (insertSubscriberData), (deleteSubscriberData)	HLR
tracing (activateTraceMode), (deactivateTraceMode)	HLR
<i>Short Message Service</i>	
shortMsgMO-Relay (MO-ForwardSM v3) (forwardSM v1/v2)	MSC/SGSN
shortMsgMT-Relay (MT-ForwardSM v3) (forwardSM v1/v2)	MSC
shortMsgAlert (alertServiceCentre/v2), (alertServiceCentreWithoutResult/v1)	HLR
<i>Mobile Terminating Traffic</i>	
roamingNbEnquiry (provideRoamingNumber)	HLR
callControlTransfer (resumeCallHandling)	MSC
subscriberInfoEnquiry (provideSubscriberInformation)	HLR
reporting (remoteUserFree) (SetReportingState)	HLR
<i>Location Services</i>	
locationSvcEnquiry (provideSubscriberLocation v3)	GMLC
<i>Network-Initiated USSD</i>	
networkUnstructuredSs (unstructuredSS-Request/v2), (unstructuredSS-Notify/v2)	HLR
<i>Priority low</i>	

NOTE: The application context name is the last component but one of the object identifier.

Operation names are given in brackets for information with "/vn" appended to vn only operations.

Table 5.1/3: Priorities of Application Contexts for SGSN as Responder

Responder = SGSN	Initiating Entity
Priority high	
<i>Mobility and Location Register Management</i>	
locationCancel (cancelLocation v3)	HLR
reset (reset)	HLR
subscriberDataMngt (insertSubscriberData v3), (deleteSubscriberData v3)	HLR
tracing (activateTraceMode), (deactivateTraceMode)	HLR
<i>Short Message Service</i>	
shortMsgMT-Relay (MT-ForwardSM v3) (forwardSM v1/v2)	MSC
<i>Network-Requested PDP context activation</i>	
gprsNotify HLR (noteMsPresentForGprs v3),	
Priority low	

NOTE: The application context name is the last component but one of the object identifier. Operation names are given in brackets for information with "/vn" appended to vn.

5.1.3 Congestion control for Signalling System No. 7

The requirements of SS7 Congestion control have to be taken into account as far as possible.

Means which could be applied to achieve the required traffic reductions are described in subclauses 5.1.1 and 5.1.2.

5.2 Compatibility

5.2.1 General

The present document of the Mobile Application Part is designed in such a way that an implementation which conforms to it can also conform to the Mobile Application Part operational version 1 specifications, except on the MSC-VLR interface.

A version negotiation mechanism based on the use of an application-context-name is used to negotiate the protocol version used between two entities for supporting a MAP-user signalling procedure.

When starting a signalling procedure, the MAP-user supplies an application-context-name to the MAP-provider. This name refers to the set of application layer communication capabilities required for this dialogue. This refers to the required TC facilities (e.g. version 1 or 2) and the list of operation packages (i.e. set of operations) from which operations can be invoked during the dialogue.

A version one application-context-name may only be transferred to the peer user in a MAP-U-ABORT to an entity of version two or higher (i.e. to trigger a dialogue which involves only communication capabilities defined for MAP operational version 1).

If the proposed application-context-name can be supported by the responding entity the dialogue continues on this basis otherwise the dialogue is refused and the initiating user needs to start a new dialogue, which involves another application-context-name which requires less communication capabilities but provides similar functionalities (if possible).

When a signalling procedure can be supported by several application contexts which differ by their version number, the MAP-User needs to select a name. It can either select the name which corresponds to the highest version it supports or follow a more specific strategy so that the number of protocol fallbacks due to version compatibility problems be minimized.

5.2.2 Strategy for selecting the Application Context (AC) version

A method should be used to minimize the number of protocol fall-backs which would occur sometimes if the highest supported AC-Name were always the one selected by GSM entities when initiating a dialogue. The following method is an example which can be used mainly at transitory phase stage when the network is one of mixed phase entities.

5.2.2.1 Proposed method

A table (table 1) may be set up by administrative action to define the highest application context (AC) version supported by each destination; a destination may be another node within the same or a different PLMN, or another PLMN considered as a single entity. The destination may be defined by an E.164 number or an E.214 number derived from an IMSI or in North America (World Zone 1) by an E.164 number or an IMSI (E.212 number). The table also includes the date when each destination is expected to be able to handle at least one AC of the latest version of the MAP protocol. When this date is reached, the application context supported by the node is marked as "unknown", which will trigger the use of table 2.

A second table (table 2) contains an entry for each destination which has an entry in table 1. For a given entity, the entry in table 2 may be a single application context version or a vector of different versions applying to different application contexts for that entity. Table 2 is managed as described in subclause 5.2.2.2.

The data for each destination will go through the following states:

- a) the version shown in table 1 is "version n-1", where 'n' is the highest version existing in this specification; table 2 is not used;
- b) the version shown in table 1 is "unknown"; table 2 is used, and maintained as described in subclause 5.2.2.2;
- c) when the PLMN operator declares that an entity (single node or entire PLMN) has been upgraded to support all the MAP version n ACs defined for the relevant interface, the version shown in table 1 is set to "version n" by administrative action; table 2 is no longer used, and the storage space may be recovered.

5.2.2.2 Managing the version look-up table

WHEN it receives a MAP-OPEN ind the MAP-User determines the originating entity number either using the originating address parameter or the originating reference parameter or retrieving it from the subscriber data using the IMSI or the MSISDN.

IF the entity number is known

THEN

It updates (if required) the associated list of highest supported ACs

ELSE

It creates an entry for this entity and includes the received AC-name in the list of highest supported ACs.

WHEN starting a procedure, the originating MAP-user looks up its version control table.

IF the destination address is known and not timed-out

THEN

It retrieves the appropriate AC-name and uses it

IF the dialogue is accepted by the peer

THEN

It does not modify the version control table

ELSE (this should never occur)

It starts a new dialogue with the common highest version supported (based on information implicitly or explicitly provided by the peer).

It replace the old AC-name by the new one in the list of associated highest AC supported.

ELSE

It uses the AC-name which corresponds to the highest version it supports.

IF the dialogue is accepted by the peer

THEN

It adds the destination node in its version control table and includes the AC-Name in the list of associated highest AC supported.

ELSE

It starts a new dialogue with the common highest version supported (based on information implicitly or explicitly provided by the peer).

IF the destination node was not known

THEN

It adds the destination node in its version control table and includes the new AC-Name in the list of associated highest AC supported.

ELSE

It replaces the old AC-name by the new one in the list of highest supported AC and reset the timer.

5.2.2.3 Optimizing the method

A table look-up may be avoided in some cases if both the HLR and the VLR or both the HLR and the SGSN store for each subscriber the version of the AC-name used at location updating. Then:

- for procedures which make use of the same application-context, the same AC-name (thus the same version) can be selected (without any table look-up) when the procedure is triggered;
- for procedures which make use of a different application-context but which includes one of the packages used by the location updating AC, the same version can be selected (without any table look-up) when the procedure is triggered;

for HLR:

- Subscriber data modification (stand alone);

for VLR:

- Data Restoration.

6 Requirements concerning the use of SCCP and TC

6.1 Use of SCCP

The Mobile Application Part makes use of the services offered by the Signalling Connection Control Part of signalling System No. 7. CCITT Blue Book or ITU-T (03/93) Recommendations Q.711 to Q.716 should be consulted for the full specification of SCCP. In North America (World Zone 1) the national version of SCCP is used as specified in ANSI T1.112. Interworking between a PLMN in North America and a PLMN outside North America will involve an STP to translate between ANSI SCCP and ITU-T/CCITT SCCP.

6.1.1 SCCP Class

MAP will only make use of the connectionless classes (0 or 1) of the SCCP.

6.1.2 Sub-System Number (SSN)

The Application Entities (AEs) defined for MAP consist of several Application Service Elements (ASEs) and are addressed by sub-system numbers (SSNs). The SSN for MAP are specified in GSM 03.03 [17].

When the SGSN emulates MSC behavior for processing messages (MAP-MO-FORWARD-SHORT-MESSAGE, MAP_CHECK_IMEI) towards entities which do not support interworking to SGSNs, it shall use the MSC SSN in the calling party address instead of the SGSN SSN.

6.1.3 SCCP addressing

6.1.3.1 Introduction

Within the GSM System there will be a need to communicate between entities within the same PLMN and in different PLMNs. Using the Mobile Application Part (MAP) for this function implies the use of Transaction Capabilities (TC) and the Signalling Connection Control Part (SCCP) of CCITT Signalling System No. 7.

Only the entities which should be addressed are described below. If the CCITT or ITU-T SCCP is used , the format and coding of address parameters carried by the SCCP for that purpose shall comply with CCITT Recommendation Q.713 with the following restrictions:

1) Intra-PLMN addressing

For communication between entities within the same PLMN, a MAP SSN shall always be included in the called and calling party addresses. All other aspects of SCCP addressing are network specific.

2) Inter-PLMN addressing

a) Called Party Address

- SSN indicator = 1 (MAP SSN always included);
- Global title indicator = 0100 (Global title includes translation type, numbering plan, encoding scheme and nature of address indicator);
- the translation type field will be coded "00000000" (Not used). For call related messages for non-optimal routed calls (as described in GSM 03.66) directed to another PLMN the translation type field may be coded "10000000" (CRMNP);
- Routing indicator = 0 (Routing on global title);

b) Calling Party Address

- SSN indicator = 1 (MAP SSNs always included);
- Point code indicator = 0;

- Global title indicator = 0100 (Global title includes translation type, numbering plan, encoding scheme and nature of address indicator);
- Numbering Plan = 0001 (ISDN Numbering Plan, E.164; In Case of Inter-PLMN Signalling, the dialogue initiating entity and dialogue responding entity shall always include its own E.164 Global Title as Calling Party Address);
- the translation type field will be coded "00000000" (Not used);
- Routing indicator = 0 (Routing on Global Title).

If ANSI T1.112 SCCP is used, the format and coding of address parameters carried by the SCCP for that purpose shall comply with ANSI specification T1.112 with the following restrictions:

1) Intra-PLMN addressing

For communication between entities within the same PLMN, a MAP SSN shall always be included in the called and calling party addresses. All other aspects of SCCP addressing are network specific.

2) Inter-PLMN addressing

a) Called Party Address

- SSN indicator = 1 (MAP SSN always included);
- Global title indicator = 0010 (Global title includes translation type);
- the Translation Type (TT) field will be coded as follows:

TT = 9, if IMSI is included,

TT = 14, if MSISDN is included,

Or TT = 10, if Network Element is included. (If TT=10, then Number Portability GTT is not invoked, if TT=14, then Number Portability GTT may be invoked.)

- Routing indicator = 0 (Routing on global title);

b) Calling Party Address

- SSN indicator = 1 (MAP SSNs always included);
- Point code indicator = 0;
- Global title indicator = 0010 (Global title includes translation type);

TT = 9, if IMSI is included,

TT = 14, if MSISDN is included,

Or TT = 10, if Network Element is included. (If TT=10, then Number Portability GTT is not invoked, if TT=14, then Number Portability GTT may be invoked.)

Routing indicator = 0 (Routing on Global Title).

If a Global Title translation is required for obtaining routeing information, one of the numbering plans E.164, E.212 and E.214 is applicable.

- E.212 numbering plan

When CCITT or ITU-T SCCP is used, an E.212 number must not be included as Global Title in an SCCP UNITDATA message. The translation of an E.212 number into a Mobile Global Title is applicable in a dialogue initiating VLR, SGSN or GGSN if the routeing information towards the HLR is derived from the subscriber's IMSI. In World Zone 1 when ANSI SCCP is used, the IMSI (E.212 number) is used as a Global Title to address the HLR. When an MS moves from one VLR service area to another, the new VLR may derive the address of the previous VLR from the Location Area Identification provided by the MS in the location registration request.

The PLMN where the previous VLR is located is identified by the E.212 numbering plan elements of the Location Area Identification, ie the Mobile Country Code (MCC) and the Mobile Network Code (MNC).

- E.214 and E.164 numbering plans

When CCITT or ITU-T SCCP is used, , only address information belonging to either E.214 or E.164 numbering plan is allowed to be included as Global Title in the Called and Calling Party Address. In World Zone 1 when ANSI SCCP is used, the IMSI (E.212 number) is used as a Global Title to address the HLR.

If the Calling Party Address associated with the dialogue initiating message contains a Global Title, the sending network entity shall include its E.164 entity number.

When receiving an SCCP UNITDATA message, SCCP shall accept either of the valid numbering plans in the Called Party Address and in the Calling Party Address.

When CCITT or ITU-T SCCP is used and an N-UNITDATA-REQUEST primitive from TC is received, SCCP shall accept an E.164 number or an E.214 number in the Called Address and in the Calling Address. In World Zone 1 when ANSI SCCP is used, the IMSI (E.212 number) is used instead of E.214 number.

The following subclauses describe the method of SCCP addressing appropriate for each entity both for the simple intra-PLMN case and where an inter-PLMN communication is required. The following entities are considered:

- the Mobile-services Switching Centre (MSC);
- the Home location Register (HLR);
- the Visitor Location Register (VLR);
- the Gateway Mobile-services Switching Centre (GMSC);
- the GSM Service Control Function (gsmSCF);
- the Interworking Mobile-services Switching Centre (IWMSC);
- the Shared Inter Working Function (SIWF);
- the Serving GPRS Support Node (SGSN);
- the Gateway GPRS Support Node (GGSN);
- the Gateway Mobile Location Center (GMLC).

6.1.3.2 The Mobile-services Switching Centre (MSC)

There are several cases where it is necessary to address the MSC.

6.1.3.2.1 MSC interaction during handover

The address is derived from the target Cellid.

6.1.3.2.2 MSC for short message routing

When a short message has to be routed to a MS, the GMSC addresses the VMSC by an MSC identity received from the HLR which complies with E.164 rules.

For MS originating short message, the IWMSC address is derived from the Service Centre address.

6.1.3.2.3 MSC for location request routing

When a location request for a particular MS needs to be sent to the MS's VMSC, the GMLC addresses the VMSC using an E.164 address received from the MS's HLR.

6.1.3.2.4 MSC for LMU Control

When a control message has to be routed to an LMU from an SMLC, the SMLC addresses the serving MSC for the LMU using an E.164 address.

6.1.3.3 The Home Location Register (HLR)

There are several cases where the HLR has to be addressed:

6.1.3.3.1 During call set-up

When a call is initiated the HLR of the called mobile subscriber will be interrogated to discover the whereabouts of the MS. The addressing required by the SCCP will be derived from the MSISDN dialled by the calling subscriber. The dialled number will be translated into either an SPC, in the case of communications within a PLMN, or a Global Title if other networks are involved (i.e. if the communication is across a PLMN boundary).

If the calling subscriber is a fixed network subscriber, the interrogation can be initiated from the Gateway MSC of the home PLMN in the general case. If the topology of the network allows it, the interrogation could be initiated from any Signalling Point which has MAP capabilities, e.g. local exchange, outgoing International Switching Centre (ISC), etc.

6.1.3.3.2 Before location updating completion

When a MS registers for the first time in a VLR, the VLR has to initiate the update location dialogue with the MS's HLR and a preceding dialogue for authentication information retrieval if the authentication information must be retrieved from the HLR. When initiating either of these dialogues, the only data for addressing the HLR that the VLR has available is contained in the IMSI, and addressing information for SCCP must be derived from it. When continuing the established update location dialogue (as with any other dialogue), the VLR must derive the routeing information towards the HLR from the Calling Party Address received with the first responding CONTINUE message until the dialogue terminating message is received. This means that the VLR must be able to address the HLR based:

- on an E.214 Mobile Global Title originally derived by the VLR from the IMSI (when CCITT or ITU-T SCCP is used), or an E.212 number originally derived from IMSI (when ANSI SCCP is used, an IMSI); or
- on an E.164 HLR address; or
- in the case of intra-PLMN signalling, on an SPC.

When answering with Global Title to the VLR, the HLR shall insert its E.164 address in the Calling Party Address of the SCCP message containing the first responding CONTINUE message.

If the HLR is in the same PLMN as the VLR, local translation tables may exist to derive an SPC. For authentication information retrieval and location updating via the international PSTN/ISDN signalling network that requires the use of CCITT or ITU-T SCCP, the Global title must be derived from the IMSI, using the principles contained in CCITT Recommendation E.214 and the Numbering Plan Indicator (NPI) value referenced by the SCCP Specifications. In World Zone 1 where the ANSI SCCP is used, IMSI (E.212 number) is used as Global Title. A summary of the translation from the IMSI (CCITT Recommendation E.212) to Mobile Global Title (described in CCITT Recommendation E.214) is shown below:

- E.212 Mobile Country Code translates to E.164 Country Code;
- E.212 Mobile Network Code translates to E.164 National Destination Code;
- E.212 Mobile Subscriber Identification Number (MSIN) is carried unchanged if within the E.164 number maximum length (15 digits). If the Mobile Global Title is more than 15 digits the number is truncated to 15 by deleting the least significant digits.

This translation will be done either at the application or at SCCP level in the VLR. The Mobile Global Title thus derived will be used to address the HLR.

If location updating is triggered by an MS that roams from one MSC Area into a different MSC Area served by the same VLR, the VLR shall address the HLR in the same way as if the MS registers for the first time in the VLR.

6.1.3.3.3 After location updating completion

In this case, the subscriber's basic MSISDN has been received from the HLR during the subscriber data retrieval procedure as well as the HLR number constituting a parameter of the MAP message indicating successful completion of the update location dialogue. From either of these E.164 numbers the address information for initiating dialogues with the roaming subscriber's HLR can be derived. Also the subscriber's IMSI may be used for establishing the routeing information towards the HLR. This may apply in particular if the dialogue with the HLR is triggered by subscriber controlled input.

Thus the SCCP address of the roaming subscriber's HLR may be an SPC, or it may be a Global title consisting of the E.164 MSISDN or the E.164 number allocated to the HLR or either the E.214 Mobile Global Title derived from the IMSI if CCITT or ITU-T SCCP is used, or the IMSI if ANSI SCCP is used (ANSI SCCP is used in World Zone 1).

6.1.3.3.4 VLR restoration

If a roaming number is requested by the HLR for an IMSI that has no data record in the interrogated VLR, the VLR provides the roaming number in the dialogue terminating message. Subsequently the VLR must retrieve the authentication data from the MS's HLR, if required, and must then trigger the restore data procedure. For this purpose, the VLR has to initiate in succession two independent dialogues with the MS's HLR. The MTP and SCCP address information needed for routeing towards the HLR can be derived from the IMSI received as a parameter of the MAP message requesting the roaming number. In this case, the IMSI received from the HLR in the roaming number request shall be processed in the same way as the IMSI that is received from an MS that registers for the first time within a VLR. Alternatively to the IMSI, the Calling Party Address associated with the roaming number request may be used to obtain the routeing information towards the HLR.

6.1.3.3.5 During Network-Requested PDP Context Activation

When receiving a PDP PDU the GGSN may interrogate the HLR of the MS for information retrieval. When initiating such a dialogue, the only data for addressing the HLR that the GGSN has available is contained in the IMSI, and addressing information must be derived from it. The IMSI is obtained from the IP address or the X.25 address in the incoming IP message by means of a translation table. This means that the GGSN shall be able to address the HLR based on an E.214, (if CCITT or ITU-T SCCP is used), or E.212 (if ANSI SCCP is used), Mobile Global Title originally derived by the GGSN from the IMSI in the case of inter-PLMN signalling. In the case of intra-PLMN signalling, an SPC may also be used.

If the HLR is in the same PLMN as the GGSN, local translation tables may exist to derive an SPC. For information retrieval via the international PSTN/ISDN signalling network, the Global title must be derived from the IMSI, using the principles contained in CCITT Recommendation E.214 and the Numbering Plan Indicator (NPI) value referenced by the SCCP Specifications. A summary of the translation from the IMSI (CCITT Recommendation E.212) to Mobile Global Title (described in CCITT Recommendation E.214) is shown below:

- E.212 Mobile Country Code translates to E.164 Country Code;
- E.212 Mobile Network Code translates to E.164 National Destination Code;
- E.212 Mobile Subscriber Identification Number (MSIN) is carried unchanged if within the E.164 number maximum length (15 digits). If the Mobile Global Title is more than 15 digits the number is truncated to 15 by deleting the least significant digits.

This translation will be done either at the application or at SCCP level in the GGSN. The Mobile Global Title thus derived will be used to address the HLR.

6.1.3.3.6 Before GPRS location updating completion

When a MS registers for the first time in a SGSN, the SGSN has to initiate the update location dialogue with the MS's HLR and a preceding dialogue for authentication information retrieval if the authentication information must be retrieved from the HLR. When initiating either of these dialogues, the only data for addressing the HLR that the SGSN has available is contained in the IMSI, and addressing information for SCCP must be derived from it. When continuing the established update location dialogue (as with any other dialogue), the SGSN must derive the routeing information towards the HLR from the Calling Party Address received with the first responding CONTINUE message until the dialogue terminating message is received. This means that the SGSN must be able to address the HLR based:

- on an E.214 (if CCITT or ITU-T SCCP is used) or E.212 (if ANSI SCCP is used) Mobile Global Title originally derived by the SGSN from the IMSI; or
- on an E.164 HLR address; or
- in the case of intra-PLMN signalling, on an SPC.

If the HLR is in the same PLMN as the SGSN, local translation tables may exist to derive an SPC. For authentication information retrieval and location updating via the international PSTN/ISDN signalling network, the Global title must be derived from the IMSI, using the principles contained in CCITT Recommendation E.214 and the Numbering Plan Indicator (NPI) value referenced by the SCCP Specifications. A summary of the translation from the IMSI (CCITT Recommendation E.212) to Mobile Global Title (described in CCITT Recommendation E.214) is shown below:

- E.212 Mobile Country Code translates to E.164 Country Code;
- E.212 Mobile Network Code translates to E.164 National Destination Code;
- E.212 Mobile Subscriber Identification Number (MSIN) is carried unchanged if within the E.164 number maximum length (15 digits). If the Mobile Global Title is more than 15 digits the number is truncated to 15 by deleting the least significant digits.

This translation will be done either at the application or at SCCP level in the SGSN. The Mobile Global Title thus derived will be used to address the HLR.

6.1.3.3.7 After GPRS location updating completion

In this case, the subscriber's Basic MSISDN has been received from the HLR during the subscriber data retrieval procedure as well as the HLR number constituting a parameter of the MAP message indicating successful completion of the update location dialogue. From either of these E.164 numbers the address information for initiating dialogues with the roaming subscriber's HLR can be derived. Also the subscriber's IMSI may be used for establishing the routeing information towards the HLR.

Thus the SCCP address of the roaming subscriber's HLR may be an SPC, or it may be a Global title consisting of the E.164 MSISDN or the E.164 number allocated to the HLR or the E.214 Mobile Global Title derived from the IMSI.

6.1.3.3.8 Query for a Location Request

For a location request from an external client, the GMLC needs to address the home HLR of the target MS to obtain the address of the target MS's serving MSC. The GMLC uses either the international E.164 MSISDN, the international E.214 number (if CCITT or ITU-T SCCP is used) or the international E.212 number (if ANSI SCCP is used) of the MS as means to route a query to the HLR.

6.1.3.4 The Visitor Location Register (VLR)

There are several cases when the VLR needs to be addressed.

6.1.3.4.1 Inter-VLR information retrieval

When an MS moves from one VLR service area to another, the new VLR may request the IMSI and authentication sets from the previous VLR. The new VLR derives the address of the previous VLR from the Location Area Identification provided by the MS in the location registration request.

6.1.3.4.2 HLR request

The HLR will only request information from a VLR if it is aware that one of its subscribers is in the VLR's service area. This means that a location updating dialogue initiated by the VLR has been successfully completed, i.e. the HLR has indicated successful completion of the update location procedure to the VLR.

When initiating dialogues towards the VLR after successful completion of location updating, the routeing information used by the HLR is derived from the E.164 VLR number received as a parameter of the MAP message initiating the update location dialogue. If the VLR is in the same PLMN as the HLR, the VLR may be addressed directly by an SPC derived from the E.164 VLR number. For dialogues via the international PSTN/ISDN signalling network, presence of the E.164 VLR number in the Called Party Address is required.

6.1.3.5 The Interworking MSC (IWMSC) for Short Message Service

The IWMSC is the interface between the mobile network and the network to access to the Short Message Service Centre. This exchange has an E.164 address known in the SGSN or in the MSC.

6.1.3.6 The Equipment Identity Register (EIR)

The EIR address is either unique or could be derived from the IMEI. The type of address is not defined.

6.1.3.7 The Shared Inter Working Function (SIWF)

When the Visited MSC detects a data or fax call and the IWF in the V-MSC can not handle the required service an SIWF can be invoked. The SIWF is addressed with an E.164 number.

6.1.3.8 The Serving GPRS Support Node (SGSN)

The HLR will initiate dialogues towards the SGSN if it is aware that one of its subscribers is in the SGSN's serving area. This means that a GPRS location updating has been successfully completed, i.e, the HLR has indicated successful completion of the GPRS location update to the SGSN. The routeing information used by the HLR is derived form the E.164 SGSN number received as parameter of the MAP message initiating the GPRS update location procedure. If the SGSN is in the same PLMN as the HLR, the SGSN may be addressed directly by an SPC derived from the E.164 SGSN number. For dialogues via the international PSTN/ISDN signalling network, the presence of the E.164 SGSN number in the Called Party Address is required.

When the GMSC initiates dialogues towards the SGSN the SGSN (MAP) SSN (See GSM 03.03) shall be included in the called party address. The routeing information used by the GMSC is derived from the E.164 SGSN number received as a parameter of the MAP message initiating the forward short message procedure. If the GMSC does not support the GPRS functionality the MSC (MAP) SSN value shall be included in the called party address.

NOTE: Every VMSC and SGSN shall have uniquely identifiable application using E.164 numbers, for the purpose of SMS over GPRS when the GMSC does not support the GPRS functionality.

6.1.3.9 The Gateway GPRS Support Node (GGSN)

The GGSN provides interworking with external packet-switched networks, network screens and routing of the Network-Requested PDP Context activation. If a Network-Requested PDP Context activation fails, the HLR will alert the GGSN when the subscriber becomes reachable. The HLR will use the E.164 GGSN number received as parameter of the MAP message reporting the failure.

6.1.3.10 The Gateway MSC (GMSC) for Short Message Service

The GMSC provides interworking with the network to access the Short Message Service Centre, the mobile network and routing of Send Routing Info For SM. The GMSC has on E.164 address known in the HLR, SGSN or MSC.

6.1.3.10A Void

6.1.3.10A.1 Void

6.1.3.10A.2 Void

6.1.3.10B The Gateway Mobile Location Center (GMLC)

The GMLC initiates location requests on behalf of external clients. The E.164 address of the GMLC is provided to an HLR when the GMLC requests a serving MSC address from the HLR for a target MS. The E.164 address of the GMLC is also provided to a serving MSC when the GMLC requests the location of a target MS served by this MSC.

6.1.3.11 Summary table

The following tables summarize the SCCP address used for invoke operations. As a principle, within a PLMN either an SPC or a GT may be used (network operation option), whereas when addressing an entity outside the PLMN the GT must be used. The address type mentioned in the table (e.g. MSISDN) is used as GT or to derive the SPC.

For a response, the originating address passed in the invoke is used as SCCP Called Party Address. For extra-PLMN addressing the own E.164 entity address is used as SCCP Calling Party Address; for intra-PLMN addressing an SPC derived from the entity number may be used instead. When using an SPC, the SPC may be taken directly from MTP.

Table 6.1/1

from	to	fixed net work	HLR	VLR	MSC	EIR	gsmSCF	SIWF	SGSN	GGSN
fixed network	---	E:GT T:MSISDN	---	---	---	---	---	---	---	---
home location register	---	---	I:SPC/GT E:GT T:VLR NUMBER	---	---	I:SPC/GT E:GT T:gsmSCF NUMBER	---	I:SPC/GT E:GT T:SGSN NUMBER	I:SPC/GT E:GT T:GGSN NUMBER	
visitor location register	---	I:SPC/GT E:GT T:MGT (outside World Zone 1)/MSISDN (World Zone 1)/HLR NUMBER (note)	I:SPC/GT E:GT T:VLR NUMBER	---	---	---	---	---	---	---
mobile-services switching centre	---	I:SPC/GT E:GT T:MSISDN	I:SPC/GT E:GT T:VLR NUMBER	I:SPC/GT E:GT T:MSC NUMBER	I:SPC/GT E:GT T:EIR NUMBER	I:SPC/GT E:GT T:gsmSCF NUMBER	I:SPC/GT E:GT T:SIWF NUMBER	I:SPC/GT E:GT T:SGSN NUMBER		---
gsm Service Control Function	---	I:SPC/GT E:GT T:MSISDN	---	---	---	---	---	---	---	---
Shared Inter Working Function	---	---	---	I:SPC/GT E:GT T:MSC NUMBER	---	---	---	---	---	---
Serving GPRS Support Node	---	I:SPC/GT E:GT T:MGT/ MSISDN/HL R NUMBER	---	I:SPC/GT E:GT T:MSC NUMBER	I:SPC/GT E:GT T:EIR NUMBER	---	---	---	---	---
Gateway GPRS Support Node	---	I:SPC/GT E:GT T:MGT	---	---	---	---	---	---	---	---
Gateway	---	I:SPC/GT	---	I:SPC/GT	---	---	---	---	---	---

Mobile Location Center		E:GT T:MSISDN, MGT (outside World Zone 1) or IMSI (World Zone 1) (note)		E:GT T:MSC NUMBER				
I:	Intra-PLMN							
E:	Extra(Inter)-PLMN							
T:	Address Type							
T:	Global Title							
MGT:	E.214 Mobile Global Title							
SPC:	Signalling Point Code							
NOTE:	<p>For initiating the location updating procedure and an authentication information retrieval from the HLR preceding it, the VLR has to derive the HLR address from the IMSI of the MS. The result can be an SPC or an E.214 Mobile Global Title if CCITT or ITU-T SCCP is used, or IMSI itself if ANSI SCCP is used (ANSI SCCP is used in World Zone 1).. When continuing the established update location dialogue (as with any other dialogue) the VLR must derive the routeing information towards the HLR from the Calling Party Address received with the first responding CONTINUE message until the dialogue terminating message is received.</p> <p>For transactions invoked by the VLR after update location completion, the VLR may derive the information for addressing the HLR from addresses received in the course of the update location procedure (MSISDN or HLR number) or from the IMSI.</p> <p>When invoking the Restore Data procedure and an authentication information retrieval from the HLR preceding it, the VLR must derive the information for addressing the HLR from the address information received in association with the roaming number request. This may be either the IMSI received as a parameter of the MAP message requesting the Roaming Number or the Calling Party Address associated with the MAP message requesting the Roaming Number.</p> <p>The gsmSCF shall be addressed using more than one Global Title number. The first Global Title number is used to address a gsmSCF for MAP. The second Global Title number is used to address a gsmSCF for CAP.</p> <p>For querying the HLR to obtain the VMSC address to support location services, the GMLC has to derive the HLR address from either the MSISDN or IMSI of the target MS. When using the IMSI, the result can be an SPC or an E.214 Mobile Global Title if CCITT or ITU-T SCCP is used, or IMSI itself if ANSI SCCP is used (ANSI SCCP is used in World Zone 1).</p>							

Table 6.1/2

from	to	GMLC
fixed network		---
home location register		---
visitor location register		---
mobile-services switching centre		---
gsm Service Control Function		---
Shared Inter Working Function		---
Serving GPRS Support Node		---
Gateway GPRS Support Node		---
Gateway Mobile Location Center		
I:	Intra-PLMN	
E:	Extra(Inter)-PLMN	
T:	Address Type	
T:	Global Title	
MGT:	E.214 Mobile Global Title	
SPC:	Signalling Point Code	

6.2 Use of TC

The Mobile Application part makes use of the services offered by the Transaction Capabilities (TC) of signalling system No. 7. ETS 300 287, which is based on CCITT White Book Recommendations Q.771 to Q.775, should be consulted for the full specification of TC.

The MAP uses all the services provided by TC except the ones related to the unstructured dialogue facility.

From a modelling perspective, the MAP is viewed as a single Application Service Element. Further structuring of it is for further study.

Transaction Capabilities refers to a protocol structure above the network layer interface (i.e., the SCCP service interface) up to the application layer including common application service elements but not the specific application service elements using them.

TC is structured as a Component sub-layer above a Transaction sub-layer.

The Component sub-layer provides two types of application services: services for the control of end-to-end dialogues and services for Remote Operation handling. These services are accessed using the TC-Dialogue handling primitives and TC-Component handling primitives respectively.

Services for dialogue control include the ability to exchange information related to application-context negotiation as well as initialization data.

Services for Remote Operation handling provide for the exchange of protocol data units invoking tasks (operations), and reporting their outcomes (results or errors) plus any non-application-specific protocol errors detected by the component sub-layer. The reporting of application-specific protocol errors by the TC user, as distinct from application process errors, is also provided. The Transaction sub-layer provides a simple end-to-end connection association service over which several related protocol data units (i.e. built by the Component Sub-Layer) can be exchanged. A Transaction termination can be prearranged (no indication provided to the TC user) or basic (indication provided).




Figure 6.2/1: Facilities for supporting the Mobile Application Part in Signalling System No.7

7 General on MAP services

7.1 Terminology and definitions

The term service is used in clauses 7 to 12 as defined in CCITT Recommendation X.200. The service definition conventions of CCITT Recommendation X.210 are also used.

7.2 Modelling principles

MAP provides its users with a specified set of services and can be viewed by its users as a "black box" or abstract machine representing the MAP service-provider. The service interface can then be depicted as shown in figure 7.2/1.




Figure 7.2/1: Modelling principles

The MAP service-users interact with the MAP service-provider by issuing or receiving MAP service-primitives at the service interface.

A MAP service-user may receive services from several instances of the MAP service-provider at the same time. In such cases the overall procedure is synchronised by the service-user.

The MAP service-primitives are named using the following notation:

MAP-ServicePrimitiveName **type**

where **type** can be any of: request (req), indication (ind), response (rsp) or confirm (cnf) (In the user arrow diagrams type is not indicated in the case of req/ind and indicated as "ack" in the case of rsp/cnf).

The services are further classified as unconfirmed-service, confirmed-service and provider-initiated-service where the first two categories refer to whether or not the service is confirmed by the service-provider. The confirmation may or may not correspond to a response provided by the other service-user.

MAP services are also classified as common MAP services which are available to all MAP service-users, and MAP service-user specific services which are services available to one or several, but not all, MAP service-users.

A MAP dialogue is defined as an exchange of information between two MAP users in order to perform a common task. A MAP dialogue will consist of one or several MAP services.

7.3 Common MAP services

All MAP service-users require access to services for performing basic application layer functions:

- for establishing and clearing MAP dialogues between peer MAP service-users;
- for accessing functions supported by layers below the applications layer;
- for reporting abnormal situations;
- for handling of different MAP versions;
- for testing whether or not a persistent MAP dialogue is still active at each side.

For these purposes the following common services are defined:

- MAP-OPEN service;
- MAP-CLOSE service;
- MAP-DELIMITER service;
- MAP-U-ABORT service;
- MAP-P-ABORT service;
- MAP-NOTICE service.

In defining the service-primitives the following convention is used for categorising parameters:

- M the inclusion of the parameter is mandatory. The M category can be used for any primitive type and specifies that the corresponding parameter must be present in the indicated primitive type;
- O the inclusion of the parameter is a service-provider option. The O category can be used in indication and confirm type primitives and is used for parameters that may optionally be included by the service-provider;
- U the inclusion of the parameter is a service-user option. The U category can be used in request and response type primitives. The inclusion of the corresponding parameter is the choice of the service-user;

- C the inclusion of the parameter is conditional. The C category can be used for the following purposes:
- to indicate that if the parameter is received from another entity it must be included for the service being considered;
 - to indicate that the service user must decide whether to include the parameter, based on the context on which the service is used;
 - to indicate that one of a number of mutually exclusive parameters must be included (e.g. parameters indicating a positive result versus parameters indicating a negative result);
 - to indicate that a service user optional parameter (marked "U") or a conditional parameter (marked "C") presented by the service user in a request or response type primitive is to be presented to the service user in the corresponding indication or confirm type primitive;
- (=) when appended to one of the above, this symbol means that the parameter takes the same value as the parameter appearing immediately to its left;
- blank the parameter is not present.

A primitive type may also be without parameters, i.e. no parameter is required with the primitive type; in this case the corresponding column of the table is empty.

7.3.1 MAP-OPEN service

This service is used for establishing a MAP dialogue between two MAP service-users. The service is a confirmed service with service primitives as shown in table 7.3/1.

Table 7.3/1: Service-primitives for the MAP-OPEN service

Parameters	Request	Indication	Response	Confirm
Application context name	M	M(=)	U	C(=)
Destination address	M	M(=)		
Destination reference	U	C(=)		
Originating address	U	O		
Originating reference	U	C(=)		
Specific information	U	C(=)	U	C(=)
Responding address			U	C(=)
Result			M	M(=)
Refuse-reason			C	C(=)
Provider error				O

Application context name:

This parameter identifies the type of application context being established. If the dialogue is accepted the received application context name shall be echoed. In case of refusal of dialogue this parameter shall indicate the highest version supported.

Destination address:

A valid SCCP address identifying the destination peer entity (see also clause 6). As an implementation option, this parameter may also, in the indication, be implicitly associated with the service access point at which the primitive is issued.

Destination-reference:

This parameter is a reference which refines the identification of the called process. It may be identical to Destination address but its value is to be carried at MAP level. Table 7.3/2 describes the MAP services using this parameter. Only these services are allowed to use it.

Table 7.3/2: Use of the destination reference

MAP service	Reference type	Use of the parameter
MAP-REGISTER-SS	IMSI	Subscriber identity
MAP-ERASE-SS	IMSI	Subscriber identity
MAP-ACTIVATE-SS	IMSI	Subscriber identity
MAP-DEACTIVATE-SS	IMSI	Subscriber identity
MAP-INTERROGATE-SS	IMSI	Subscriber identity
MAP-REGISTER-PASSWORD	IMSI	Subscriber identity
MAP-PROCESS-UNSTRUCTURED-SS-REQUEST	IMSI	Subscriber identity
MAP-UNSTRUCTURED-SS-REQUEST	IMSI	Subscriber identity
MAP-UNSTRUCTURED-SS-NOTIFY	IMSI	Subscriber identity
MAP-FORWARD-SHORT-MESSAGE	IMSI (note)	Subscriber identity
MAP-REGISTER-CC-ENTRY	IMSI	Subscriber identity
MAP-ERASE-CC-ENTRY	IMSI	Subscriber identity

NOTE: Only when the IMSI and the LMSI are received together from the HLR in the mobile terminated short message transfer.

Originating address:

A valid SCCP address identifying the requestor of a MAP dialogue (see also clause 6). As an implementation option, this parameter may also, in the request, be implicitly associated with the service access point at which the primitive is issued.

Originating-reference:

This parameter is a reference which refines the identification of the calling process. It may be identical to the Originating address but its value is to be carried at MAP level. Table 7.3/3 describes the MAP services using the parameter. Only these services are allowed to use it. Processing of the Originating-reference shall be performed according to the supplementary service descriptions and other service descriptions, e.g. operator determined barring.

Table 7.3/3: Use of the originating reference

MAP service	Reference type	Use of the parameter
MAP-REGISTER-SS	ISDN-Address-String	Originated entity address
MAP-ERASE-SS	ISDN-Address-String	Originated entity address
MAP-ACTIVATE-SS	ISDN-Address-String	Originated entity address
MAP-DEACTIVATE-SS	ISDN-Address-String	Originated entity address
MAP-INTERROGATE-SS	ISDN-Address-String	Originated entity address
MAP-REGISTER-PASSWORD	ISDN-Address-String	Originated entity address
MAP-PROCESS-UNSTRUCTURED-SS-REQUEST	ISDN-Address-String	Originated entity address
MAP-REGISTER-CC-ENTRY	ISDN-Address-String	Originated entity address
MAP-ERASE-CC-ENTRY	ISDN-Address-String	Originated entity address

Specific information:

This parameter may be used for passing any user specific information. Establishment and processing of the Specific information is not specified by GSM and shall be performed according to operator specific requirements.

Responding address:

An address identifying the responding entity. The responding address is included if required by the context (e.g. if it is different from the destination address).

Result:

This parameter indicates whether the dialogue is accepted by the peer.

Refuse reason:

This parameter is only present if the Result parameter indicates that the dialogue is refused. It takes one of the following values:

- Application-context-not-supported;
- Invalid-destination-reference;
- Invalid-originating-reference;
- No-reason-given;
- Remote node not reachable;
- Potential version incompatibility.

7.3.2 MAP-CLOSE service

This service is used for releasing a previously established MAP dialogue. The service may be invoked by either MAP service-user depending on rules defined within the service-user. The service is an unconfirmed service with parameters as shown in table 7.3/4.

Table 7.3/4: Service-primitives for the MAP-CLOSE service

Parameters	Request	Indication
Release method Specific Information	M U	C(=)

Release method:

This parameter can take the following two values:

- normal release; in this case the primitive is mapped onto the protocol and sent to the peer;
- prearranged end; in this case the primitive is not mapped onto the protocol. Prearranged end is managed independently by the two users, i.e. only the request type primitive is required in this case.

Specific information:

This parameter may be used for passing any user specific information. Establishment and processing of the Specific information is not specified by GSM and shall be performed according to operator specific requirements.

7.3.3 MAP-DELIMITER service

This service is used to explicitly request the transfer of the MAP protocol data units to the peer entities.

See also subclause 7.4 and 7.5 for the detailed use of the MAP-DELIMITER service.

The service is an unconfirmed service with service-primitives as shown in table 7.3/5.

Table 7.3/5: Service-primitives for the MAP-DELIMITER service

Parameters	Request	Indication

7.3.4 MAP-U-ABORT service

This service enables the service-user to request the MAP dialogue to be aborted. The service is an unconfirmed service with service-primitives as shown in table 7.3/6.

Table 7.3/6: Service-primitives for the MAP-U-ABORT service

Parameters	Request	Indication
User reason	M	M(=)
Diagnostic information	U	C(=)
Specific information	U	C(=)

User reason:

This parameter can take the following values:

- resource limitation (congestion);
the requested user resource is unavailable due to congestion;

- resource unavailable;
the requested user resource is unavailable for reasons other than congestion;
- application procedure cancellation;
the procedure is cancelled for reason detailed in the diagnostic information parameter;
- procedure error;
processing of the procedure is terminated for procedural reasons.

Diagnostic information:

This parameter may be used to give additional information for some of the values of the user-reason parameter:

Table 7.3/7: User reason and diagnostic information

User reason	Diagnostic information
Resource limitation (congestion)	-
Resource unavailable	Short term/long term problem
Application procedure cancellation	Handover cancellation/ Radio Channel release/ Network path release/ Call release/ Associated procedure failure/ Tandem dialogue released/ Remote operations failure
Procedure error	-

Specific information:

This parameter may be used for passing any user specific information. Establishment and processing of the Specific information is not specified by GSM and shall be performed according to operator specific requirements.

7.3.5 MAP-P-ABORT service

This service enables the MAP service-provider to abort a MAP dialogue. The service is a provider-initiated service with service-primitive as shown in table 7.3/8.

Table 7.3/8: Service-primitive for the MAP-P-ABORT service

Parameters	Indication
Provider reason	M
Source	M

Provider reason:

This parameter indicates the reason for aborting the MAP dialogue:

- provider malfunction;
- supporting dialogue/transaction released;
- resource limitation;
- maintenance activity;
- version incompatibility;
- abnormal MAP dialogue.

Source:

This parameter indicates the source of the abort. For Transaction Capabilities (TC) applications the parameter may take the following values:

- MAP problem;
- TC problem;
- network service problem.

Table 7.3/9: Values of provider reason and source parameters and examples of corresponding events

Provider reason	Source	Corresponding event
Provider malfunction	MAP	Malfunction at MAP level at peer entity
	TC	"Unrecognised message type" or "Badly formatted transaction portion" or "Incorrect transaction portion" received in TC-P-ABORT "Abnormal dialogue"
	Network service	Malfunction at network service level at peer entity
Supporting dialogue/ transaction released	TC	"Unrecognised transaction ID" received in TC-ABORT
Resource limitation	MAP	Congestion towards MAP peer service-user
	TC	"Resource limitation" received in TC-P-ABORT
Maintenance activity	MAP	Maintenance at MAP peer service-user
	Network service	Maintenance at network peer service level
Abnormal MAP dialogue	MAP	MAP dialogue is not in accordance with specified application context
Version incompatibility	TC	A Provider Abort indicating "No common dialogue portion" is received in the dialogue initiated state

7.3.6 MAP-NOTICE service

This service is used to notify the MAP service-user about protocol problems related to a MAP dialogue not affecting the state of the protocol machines.

The service is a provider-initiated service with service-primitive as shown in table 7.3/10.

Table 7.3/10: Service-primitive for the MAP-NOTICE service

Parameters	Indication
Problem diagnostic	M

Problem diagnostic:

This parameter can take one of the following values:

- abnormal event detected by the peer;
- response rejected by the peer;
- abnormal event received from the peer
- message cannot be delivered to the peer.

7.4 Sequencing of services

The sequencing of services is shown in figure 7.4/1 and is as follows:

Opening:

The MAP-OPEN service is invoked before any user specific service-primitive is accepted. The sequence may contain none, one or several user specific service-primitives. If no user specific service-primitive is contained between the MAP-OPEN and the MAP-DELIMITER primitives, then this will correspond to sending an empty Begin message in TC. If more than one user specific service-primitive is included, all are to be sent in the same Begin message. The sequence ends with a MAP-DELIMITER primitive.

Continuing:

This sequence may not be present in some MAP dialogues. If it is present, it ends with a MAP-DELIMITER primitive. If more than one user specific service-primitive is included, all are to be included in the same Continue message.

Closing:

The sequence can only appear after an opening sequence or a continuing sequence. The sequence may contain none, one or several user specific service-primitives if the MAP-CLOSE primitive specifies normal release. If no user specific service-primitive is included, then this will correspond to sending an empty End message in TC. If more than one user specific service-primitive is included, all are to be sent in the same End message. If prearranged end is specified, the sequence cannot contain any user specific service-primitive. The MAP-CLOSE primitive must be sent after all user specific service-primitives have been delivered to the MAP service-provider.

Aborting:

A MAP service-user can issue a MAP-U-ABORT primitive at any time after the MAP dialogue has been opened or as a response to an attempt to open a MAP dialogue.

The MAP service-provider may issue at any time a MAP-P-ABORT primitive towards a MAP service-user for which a MAP dialogue exists.

MAP-U-ABORT primitives and MAP-P-ABORT primitives terminate the MAP dialogue.




Figure 7.4/1: Sequencing of services

If the reason "resource unavailable (short term problem)" is indicated in the MAP-U-ABORT indication primitive, the MAP service-user may decide to attempt a new MAP dialogue establishment immediately.

Sequencing of user specific service-primitives is done by the MAP service-user and based on rules applicable for each MAP service-user instance.

A MAP-NOTICE indication primitive may be received at any time during the active period of a MAP dialogue.

7.5 General rules for mapping of services onto TC

7.5.1 Mapping of common services

Table 7.5/1 gives an overview of the mapping rules for mapping of common services onto TC-services. Table 7.5/2 gives the mapping rules for mapping of TC-services onto common services.

Protocol machine description is given in clauses 14 to 17.

Table 7.5/1: Mapping of common services on to TC services

MAP service-primitive	TC service-primitive
MAP-OPEN request (+ any user specific service primitives) + MAP-DELIMITER request	TC-BEGIN request (+ component handling primitives)
MAP-OPEN response (+ any user specific service primitives) + MAP-DELIMITER request	TC-CONTINUE request (note) (+ component handling primitives)
(any user specific service primitives) + MAP-DELIMITER request	TC-CONTINUE request (+ component handling primitives)
(any user specific service primitives) + MAP-CLOSE request	TC-END request (+ component handling primitives)
MAP-U-ABORT request	TC-U-ABORT request
NOTE: or TC-END if the MAP-CLOSE request has been received before the MAP-DELIMITER request.	

Table 7.5/2: Mapping of TC services on to common service

TC service-primitive	MAP service-primitive
TC-BEGIN indication (+ component handling primitives)	MAP-OPEN indication (+ user specific service primitives) + MAP-DELIMITER indication (note 1)
TC-CONTINUE indication (+ component handling primitives)	First time: MAP-OPEN confirm (+ user specific service primitives) + MAP-DELIMITER indication (note 1) Subsequent times: (user specific service primitives) + MAP-DELIMITER indication (note 1)
TC-END indication (+ component handling primitives)	MAP-OPEN confirm (note 6) (user specific service primitives) + MAP-CLOSE indication
TC-U-ABORT indication	MAP-U-ABORT indication or MAP-P-ABORT indication (note 2) MAP-OPEN confirmation (note 3)
TC-P-ABORT indication	MAP-P-ABORT indication (note 4) MAP-OPEN confirmation (note 5)
NOTE 1: It may not be necessary to present this primitive to the user for MAP version 2 applications. NOTE 2: The mapping depends on whether the TC-U-ABORT indication primitive contains a MAP-abort-PDU from the remote MAP service-provider or a MAP-user-abort-PDU from the remote MAP service-user. NOTE 3: Only if the opening sequence is pending and if the "Abort Reason" in the TC-U-ABORT indication is set to "Application Context Not Supported". NOTE 4: If the "Abort Reason" in the TC-P-ABORT indication is set to a value different from "Incorrect Transaction Portion". NOTE 5: Only if the opening sequence is pending and if the "Abort Reason" in the TC-P-ABORT indication is set to "Incorrect Transaction Portion". NOTE 6: Only if opening sequence is pending.	

7.5.2 Mapping of user specific services

Table 7.5/3 gives the general mapping rules which apply to mapping of MAP user specific services onto TC services and table 7.5/4 gives the similar rules for mapping of TC services onto MAP user specific services. Detailed mapping is given in clauses 14 to 17.

Table 7.5/3: Mapping of MAP user specific services onto TC services

MAP service-primitive	TC-service-primitive
MAP-xx request	TC-INVOKE request
MAP-xx response (note 1)	TC-RESULT-L request TC-U-ERROR request TC-U-REJECT request TC-INVOKE request (note 2)

Table 7.5/4: Mapping of TC services onto MAP user specific services

TC-service-primitive	MAP service-primitive
TC-INVOKE indication	MAP-xx indication
TC-RESULT-L indication (note 4) TC-U-ERROR indication TC-INVOKE indication (note 2) TC-L-CANCEL indication	MAP-xx confirm
TC-U-REJECT indication TC-L-REJECT indication TC-R-REJECT indication	MAP-xx confirm or MAP-NOTICE indication (note 3)

Notes to tables 7.5/3 and 7.5/4:

NOTE 1: The mapping is determined by parameters contained in the MAP-xx response primitive.

NOTE 2: This applies only to TC class 4 operations where the operation is used to pass a result of another class 2 or class 4 operation.

NOTE 3: The detailed mapping rules are given in clause 16.

NOTE 4: If RESULT-NL components are present they are mapped on to the same MAP-xx confirm.

7.6 Definition of parameters

Following is an alphabetic list of parameters used in the common MAP-services in subclause 7.3:

Application context name	7.3.1	Refuse reason	7.3.1
Destination address	7.3.1	Release method	7.3.2
Destination reference	7.3.1	Responding address	7.3.1
Diagnostic information	7.3.4	Result	7.3.1
Originating address	7.3.1	Source	7.3.5
Originating reference	7.3.1	Specific information	7.3.1/7.3.2/7.3.4
Problem diagnostic	7.3.6	User reason	7.3.4
Provider reason	7.3.5		

Following is an alphabetic list of parameters contained in this clause:

Absent Subscriber Diagnostic SM	7.6.8.9	Invoke Id	7.6.1.1
Access connection status	7.6.9.3	ISDN Bearer Capability	7.6.3.41
Access signalling information	7.6.9.5	Kc	7.6.7.4
Additional Absent Subscriber	7.6.8.12	Linked Id	7.6.1.2
Diagnostic SM			
Additional number	7.6.2.46	LMSI	7.6.2.16
Additional signal info	7.6.9.10	Location Information	7.6.2.30
Additional SM Delivery Outcome	7.6.8.11	Location update type	7.6.9.6
Alert Reason	7.6.8.8	Lower Layer Compatibility	7.6.3.42
Alert Reason Indicator	7.6.8.10	LSA Information	7.6.3.56
		LSA Information Withdraw	7.6.3.58
Alerting Pattern	7.6.3.44	Mobile Not Reachable Reason	7.6.3.51
All GPRS Data	7.6.3.53	More Messages To Send	7.6.8.7
All Information Sent	7.6.1.5	MS ISDN	7.6.2.17
APN	7.6.2.42	MSC number	7.6.2.11
Authentication set list	7.6.7.1	MSIsdn-Alert	7.6.2.29
B-subscriber Address	7.6.2.36	MWD status	7.6.8.3
B subscriber Number	7.6.2.48	Network Access Mode	7.6.3.50
B subscriber subaddress	7.6.2.49	Network node number	7.6.2.43
Basic Service Group	7.6.4.40	Network resources	7.6.10.1
Bearer service	7.6.4.38	Network signal information	7.6.9.8
BSS-apdu	7.6.9.1	New password	7.6.4.20
Call barring feature	7.6.4.19	No reply condition timer	7.6.4.7
Call barring information	7.6.4.18	North American Equal Access preferred Carrier Id	7.6.2.34
Call Direction	7.6.5.8	Number Portability Status	7.6.5.14
Call Info	7.6.9.9	ODB General Data	7.6.3.9
Call reference	7.6.5.1	ODB HPLMN Specific Data	7.6.3.10
Called number	7.6.2.24	OMC Id	7.6.2.18
Calling number	7.6.2.25	Originally dialled number	7.6.2.26
CAMEL Subscription Info Withdraw	7.6.3.38	Originating entity number	7.6.2.10
Cancellation Type	7.6.3.52	Override Category	7.6.4.4
Category	7.6.3.1	P-TMSI	7.6.2.47
CCBS Feature	7.6.5.8	PDP-Address	7.6.2.45
Channel Type	7.6.5.9	PDP-Context identifier	7.6.3.55
Chosen Channel	7.6.5.10	PDP-Type	7.6.2.44
Ciphering mode	7.6.7.7	Previous location area Id	7.6.2.4
Cksn	7.6.7.5	Protocol Id	7.6.9.7
CLI Restriction	7.6.4.5	Provider error	7.6.1.3
CM service type	7.6.9.2	QoS-Subscribed	7.6.3.47
Complete Data List Included	7.6.3.54	Rand	7.6.7.2
CUG feature	7.6.3.26	Regional Subscription Data	7.6.3.11
CUG index	7.6.3.25	Regional Subscription Response	7.6.3.12
CUG info	7.6.3.22	Requested Info	7.6.3.31
CUG interlock	7.6.3.24	Roaming number	7.6.2.19
CUG Outgoing Access indicator	7.6.3.8	Roaming Restricted In SGSN Due To Unsupported Feature	7.6.3.49
CUG subscription	7.6.3.23	Roaming Restriction Due To Unsupported Feature	7.6.3.13
CUG Subscription Flag	7.6.3.37	Service centre address	7.6.2.27
Current location area Id	7.6.2.6	Serving Cell Id	7.6.2.37
Current password	7.6.4.21	SGSN address	7.6.2.39
eMLPP Information	7.6.4.41	SGSN number	7.6.2.38
Equipment status	7.6.3.2	SIWF Number	7.6.2.35
Extensible Basic Service Group	7.6.3.5	SoLSA Support Indicator	7.6.3.57
Extensible Bearer service	7.6.3.3	SM Delivery Outcome	7.6.8.6
Extensible Call barring feature	7.6.3.21	SM-RP-DA	7.6.8.1
Extensible Call barring information	7.6.3.20	SM-RP-MTI	7.6.8.16
Extensible Forwarding feature	7.6.3.16	SM-RP-OA	7.6.8.2
Extensible Forwarding info	7.6.3.15	SM-RP-PRI	7.6.8.5
Extensible Forwarding Options	7.6.3.18	SM-RP-SMEA	7.6.8.17
Extensible No reply condition timer	7.6.3.19	SM-RP-UI	7.6.8.4
Extensible SS-Data	7.6.3.29	Sres	7.6.7.3
Extensible SS-Info	7.6.3.14	SS-Code	7.6.4.1
Extensible SS-Status	7.6.3.17		

Extensible Teleservice	7.6.3.4	SS-Data	7.6.4.3
External Signal Information	7.6.9.4	SS-Event	7.6.4.42
Forwarded-to number	7.6.2.22	SS-Event-Data	7.6.4.43
Forwarded-to subaddress	7.6.2.23	SS-Info	7.6.4.24
Forwarding feature	7.6.4.16	SS-Status	7.6.4.2
Forwarding information	7.6.4.15	Stored location area Id	7.6.2.5
Forwarding Options	7.6.4.6	Subscriber State	7.6.3.30
GGSN address	7.6.2.40	Subscriber Status	7.6.3.7
GGSN number	7.6.2.41	Supported CAMEL Phases	7.6.3.36
GMSC CAMEL Subscription Info	7.6.3.34	Suppress T-CSI	7.6.3.33
GPRS Node Indicator	7.6.8.14	Suppression of Announcement	7.6.3.32
GPRS Subscription Data	7.6.3.46	Target cell Id	7.6.2.8
GPRS Subscription Data Withdraw	7.6.3.45	Target location area Id	7.6.2.7
GPRS Support Indicator	7.6.8.15	Target MSC number	7.6.2.12
Group Id	7.6.2.33	Teleservice	7.6.4.39
GSM bearer capability	7.6.3.6	TMSI	7.6.2.2
Guidance information	7.6.4.22	Trace reference	7.6.10.2
Handover number	7.6.2.21	Trace type	7.6.10.3
High Layer Compatibility	7.6.3.43	User error	7.6.1.4
HLR Id	7.6.2.15	USSD Data Coding Scheme	7.6.4.36
HLR number	7.6.2.13	USSD String	7.6.4.37
HO-Number Not Required	7.6.6.7	UU Data	7.6.5.12
IMEI	7.6.2.3	UUS CF Interaction	7.6.5.13
IMSI	7.6.2.1	VBS Data	7.6.3.40
Inter CUG options	7.6.3.27	VGCS Data	7.6.3.39
Intra CUG restrictions	7.6.3.28	VLR CAMEL Subscription Info	7.6.3.35
		VLR number	7.6.2.14
		VPLMN address allowed	7.6.3.48
		Zone Code	7.6.2.28

7.6.1 Common parameters

The following set of parameters are used in several MAP service-primitives:

7.6.1.1 Invoke Id

This parameter identifies corresponding service primitives. The parameter is supplied by the MAP service-user and must be unique over each service-user/service-provider interface.

7.6.1.2 Linked Id

This parameter is used for linked services and it takes the value of the invoke Id of the service linked to.

7.6.1.3 Provider error

This parameter is used to indicate a protocol related type of error:

- duplicated invoke Id;
- not supported service;
- mistyped parameter;
- resource limitation;
- initiating release, i.e. the peer has already initiated release of the dialogue and the service has to be released;
- unexpected response from the peer;
- service completion failure;
- no response from the peer;
- invalid response received.

7.6.1.4 User error

This parameter can take values as follows:

NOTE: The values are grouped in order to improve readability; the grouping has no other significance.

a) Generic error:

- system failure, i.e. a task cannot be performed because of a problem in another entity. The type of entity or network resource may be indicated by use of the network resource parameter;
- data missing, i.e. an optional parameter required by the context is missing;
- unexpected data value, i.e. the data type is formally correct but its value or presence is unexpected in the current context;
- resource limitation;
- initiating release, i.e. the receiving entity has started the release procedure;
- facility not supported, i.e. the requested facility is not supported by the PLMN;
- incompatible terminal, i.e. the requested facility is not supported by the terminal.

b) Identification or numbering problem:

- unknown subscriber, i.e. no such subscription exists;
- number changed, i.e. the subscription does not exist for that number any more;
- unknown MSC;
- unidentified subscriber, i.e. if the subscriber is not contained in the database and it has not or cannot be established whether or not a subscription exists;
- unallocated roaming number;
- unknown equipment;
- unknown location area.

c) Subscription problem:

- roaming not allowed, i.e. a location updating attempt is made in an area not covered by the subscription;
- illegal subscriber, i.e. illegality of the access has been established by use of authentication procedure;
- bearer service not provisioned;
- teleservice not provisioned;
- illegal equipment, i.e. the IMEI check procedure has shown that the IMEI is blacklisted or not whitelisted.

d) Handover problem:

- no handover number available;
- subsequent handover failure, i.e. handover to a third MSC failed for some reason.

e) Operation and maintenance problem:

- tracing buffer full, i.e. tracing cannot be performed because the tracing capacity is exceeded.

f) Call set-up problem:

- no roaming number available, i.e. a roaming number cannot be allocated because all available numbers are in use;
- absent subscriber, i.e. the subscriber has activated the detach service or the system detects the absence condition. This error may be qualified to indicate whether the subscriber was IMSI detached, in a restricted area or did not respond to paging;
- busy subscriber. This error may be qualified to indicate that the subscriber was busy due to CCBS and that CCBS is possible;
- no subscriber reply;
- forwarding violation, i.e. the call has already been forwarded the maximum number of times that is allowed;
- CUG reject, i.e. the call does not pass a CUG check; additional information may also be given in order to indicate rejection due to e.g. incoming call barred or non-CUG membership.
- call barred. Optionally, additional information may be included for indicating either that the call meets a barring condition set by the subscriber or that the call is barred for operator reasons. In case of barring of Mobil Terminating Short Message, the additional information may indicate a barring condition due to « unauthorised Message Originator».
- optimal routeing not allowed, i.e. the entity which sends the error does not support optimal routeing, or the HLR will not accept an optimal routeing interrogation from the GMSC, or the call cannot be optimally routed because it would contravene optimal routeing constraints.
- forwarding failed, i.e. the GMSC interrogated the HLR for forwarding information but the HLR returned an error.

g) Supplementary services problem:

- call barred;
- illegal SS operation;
- SS error status;
- SS not available;
- SS subscription violation;
- SS incompatibility;
- negative password check;
- password registration failure;
- Number of Password Attempts;
- USSD Busy;
- Unknown Alphabet.
- short term denial;
- long term denial.

For definition of these errors see GSM 04.80.

h) Short message problem:

- SM delivery failure with detailed reason as follows:
 - memory capacity exceeded;
 - MS protocol error;
 - MS not equipped;
 - unknown service centre (SC);
 - SC congestion;
 - invalid SME address;
 - subscriber is not an SC subscriber;
- and possibly detailed diagnostic information, coded as specified in TS GSM 03.40, under SMS-SUBMIT-REPORT and SMS-DELIVERY-REPORT. If the SM entity which returns the SM Delivery Failure error includes detailed diagnostic information, it shall be forwarded in the MAP_MO_FORWARD_SHORT_MESSAGE and in the MAP_MT_FORWARD_SHORT_MESSAGE response.
- message waiting list full, i.e. no further SC address can be added to the message waiting list;
- Subscriber busy for MT SMS, i.e. the mobile terminated short message transfer cannot be completed because:
 - another mobile terminated short message transfer is going on and the delivery node does not support message buffering; or
 - another mobile terminated short message transfer is going on and it is not possible to buffer the message for later delivery; or
 - the message was buffered but it is not possible to deliver the message before the expiry of the buffering time defined in GSM 03.40;
- Absent Subscriber SM, i.e. the mobile terminated short message transfer cannot be completed because the network cannot contact the subscriber. Diagnostic information regarding the reason for the subscriber's absence may be included with this error.

i) Location services problem:

- Unauthorized Requesting Network
- Unauthorized LCS Client with detailed reason as follows
 - Unauthorized Privacy Class
 - Unauthorized Call Unrelated External Client
 - Unauthorized Call Related External Client
 - Privacy override not applicable
- Position method failure with detailed reason as follows:
 - Congestion
 - Insufficient resources
 - Insufficient Measurement Data
 - Inconsistent Measurement Data
 - Location procedure not completed

- Location procedure not supported by target MS
- QoS not attainable
- Position Method Not Available in Network
- Position Method Not Available in Location Area
- Unknown or unreachable LCS Client

7.6.1.5 All Information Sent

This parameter indicates to the receiving entity when the sending entity has sent all necessary information.

7.6.2 Numbering and identification parameter

7.6.2.1 IMSI

This parameter is the International Mobile Subscriber Identity defined in GSM 03.03.

7.6.2.2 TMSI

This parameter is the Temporary Mobile Subscriber Identity defined in GSM 03.03.

7.6.2.3 IMEI

This parameter is the International Mobile Equipment Identity defined in GSM 03.03.

7.6.2.4 Previous location area Id

This parameter refers to the identity of the location area from which the subscriber has roamed.

7.6.2.5 Stored location area Id

This parameter refers to the location area where the subscriber is assumed to be located.

7.6.2.6 Current location area Id

This parameter is used to indicate the location area in which the subscriber is currently located.

7.6.2.7 Target location area Id

This parameter refers to the location area into which the subscriber intends to roam.

7.6.2.8 Target cell Id

This parameter refers to the identity of the cell to which a call has to be handed over.

7.6.2.9 Void

7.6.2.10 Originating entity number

This parameter refers to an application layer identification of a system component in terms of its associated ISDN number.

7.6.2.11 MSC number

This parameter refers to the ISDN number of an MSC.

7.6.2.12 Target MSC number

This parameter refers to the ISDN number of an MSC to which a call has to be handed over.

7.6.2.13 HLR number

This parameter refers to the ISDN number of an HLR.

7.6.2.14 VLR number

This parameter refers to the ISDN number of a VLR.

7.6.2.15 HLR Id

This parameter refers to the identity of an HLR derived from the IMSI defined in CCITT Recommendation E.212.

7.6.2.16 LMSI

This parameter refers to a local identity allocated by the VLR to a given subscriber for internal management of data in the VLR. LMSI shall not be sent to the SGSN.

7.6.2.17 MS ISDN

This parameter refers to one of the ISDN numbers assigned to a mobile subscriber in accordance with CCITT Recommendation E.213.

7.6.2.18 OMC Id

This parameter refers to the identity of an operation and maintenance centre.

7.6.2.19 Roaming number

This parameter refers to the roaming number as defined in CCITT Recommendation E.213.

7.6.2.20 Void

7.6.2.21 Handover number

This parameter refers to the number used for routing a call between MSCs during handover.

7.6.2.22 Forwarded-to number

This parameter refers to the address to which a call is to be forwarded. This may include a subaddress. For subscribers having an originating CAMEL Phase 2 subscription this address need not be in non-E.164 international format.

7.6.2.23 Forwarded-to subaddress

This parameter refers to the sub-address attached to the address to which a call is to be forwarded.

7.6.2.24 Called number

This parameter refers to a called party number as defined in CCITT Recommendation Q.767.

7.6.2.25 Calling number

This parameter refers to a calling party number as defined in CCITT Recommendation Q.767.

7.6.2.26 Originally dialled number

This parameter refers to the number dialled by the calling party in order to reach a mobile subscriber.

7.6.2.27 Service centre address

This parameter represents the address of a Short Message Service Centre.

7.6.2.28 Zone Code

This parameter is used to define location areas into which the subscriber is allowed or not allowed to roam (regional subscription). With a complete list of Zone Codes the VLR or the SGSN is able to determine for all its location areas whether roaming is allowed or not.

7.6.2.29 MSIsdn-Alert

This parameter refers to the MSISDN stored in a Message Waiting Data File in the HLR. It is used to alert the Service Centre when the MS is again attainable.

7.6.2.30 Location Information

This parameter indicates the location of the served subscriber as defined in GSM 03.18.

7.6.2.31 GMSC Address

This parameter refers to the E.164 address of a GMSC.

7.6.2.32 VMSC Address

This parameter refers to the E.164 address of a VMSC.

7.6.2.33 Group Id

This parameter is used to describe groups a subscriber can be member of. A subscriber can partake in all group calls (VBS/VGCS) where he subscribed to the respective groups.

7.6.2.34 North American Equal Access preferred Carrier Id

This parameter refers to the carrier identity preferred by the subscriber for calls requiring routing via an interexchange carrier. This identity is used at:

- outgoing calls: when the subscriber does not specify at call setup a carrier identity;
- forwarded calls: when a call is forwarded by the subscriber;
- incoming calls: applicable to the roaming leg of the call.

7.6.2.35 SIWFS Number

This parameter refers to the number used for routing a call between the MSC and the SIWFS (used by ISUP).

7.6.2.36 B-subscriber address

This parameter refers to the address used by the SIWFS to route the outgoing call from the SIWFS to either the B-subscriber in case the non-loop method or back to the VMSC in case of the loop method.

7.6.2.37 Serving cell Id

This parameter indicates the cell currently being used by the served subscriber.

7.6.2.38 SGSN number

This parameter refers to the ISDN number of a SGSN.

7.6.2.39 SGSN address

This parameter refers to the IP-address of a SGSN. This parameter is defined in GSM 03.03.

7.6.2.40 GGSN address

This parameter refers to the IP-address of a GGSN. This parameter is defined in GSM 03.03.

7.6.2.41 GGSN number

This parameter refers to the ISDN number of a GGSN or the ISDN number of the protocol-converter if a protocol-converting GSN is used between the GGSN and the HLR..

7.6.2.42 APN

This parameter refers to the DNS name of a GGSN. This parameter is defined in GSM 03.60.

7.6.2.43 Network Node number

This parameter refers either to the ISDN number of SGSN or to the ISDN number of MSC.

7.6.2.44 PDP-Type

This parameter indicates which type of protocol is used by the MS as defined in GSM 03.60.

7.6.2.45 PDP-Address

This parameter indicates the address of the data protocol as defined in GSM 03.60.

7.6.2.46 Additional number

This parameter can refer either to the SGSN number or to the MSC number.

7.6.2.47 P-TMSI

This parameter is the Packet Temporary Mobile Subscriber Identity defined in GSM 03.03.

7.6.2.48 B-subscriber number

This parameter refers to the number of the destination B dialled by the A user. This may include a subaddress.

7.6.2.49 B-subscriber subaddress

This parameter refers to the sub-address attached to the destination B dialled by the A user.

7.6.2.50 LMU Number

This parameter refers to a local number assigned to an LMU by an SMLC.

7.6.2.51 MLC Number

This parameter refers to the ISDN (E.164) number of an MLC.

7.6.3 Subscriber management parameters

7.6.3.1 Category

This parameter refers to the calling party category as defined in CCITT Recommendation Q.767.

7.6.3.2 Equipment status

This parameter refers to the status of the mobile equipment as defined in GSM 02.16.

7.6.3.3 Extensible Bearer service

This parameter may refer to a single bearer service, a set of bearer services or to all bearer services as defined in TS GSM 02.02. This parameter is used only for subscriber profile management. Extensible Bearer service values include all values defined for a Bearer service parameter (7.6.4.38).

7.6.3.4 Extensible Teleservice

This parameter may refer to a single teleservice, a set of teleservices or to all teleservices as defined in TS GSM 02.03. This parameter is used only for subscriber profile management. Extensible Teleservice values include all values defined for a Teleservice parameter (7.6.4.39).

7.6.3.5 Extensible Basic Service Group

This parameter refers to the Basic Service Group either as an extensible bearer service (see subclause 7.6.3.3) or an extensible teleservice (see subclause 7.6.3.4). This parameter is used only for subscriber profile management. The null value (i.e. neither extensible bearer service nor extensible teleservice) is used to denote the group containing all extensible bearer services and all extensible teleservices.

7.6.3.6 GSM bearer capability

This parameter refers to the GSM bearer capability information element defined in GSM 04.08.

7.6.3.7 Subscriber Status

This parameter refers to the barring status of the subscriber:

- service granted;
- Operator Determined Barring.

7.6.3.8 CUG Outgoing Access indicator

This parameter represents the Outgoing Access as defined in ETS 300 136.

7.6.3.9 Operator Determined Barring General Data

This parameter refers to the set of subscribers features that the network operator or the service provider can regulate. This set only includes those limitations that can be controlled in the VLR or in the SGSN:

- All outgoing calls barred; (*)

- International outgoing calls barred; (*)
- International outgoing calls except those to the home PLMN country barred; (*)
- Interzonal outgoing calls barred; (*)
- Interzonal outgoing calls except those to the home PLMN country barred; (*)
- Interzonal outgoing calls AND international outgoing calls except those directed to the home PLMN country barred; (*)
- Premium rate (information) outgoing calls barred;
- Premium rate (entertainment) outgoing calls barred;
- Supplementary service access barred;
- Invocation of call transfer barred;
- Invocation of chargeable call transfer barred;
- Invocation of internationally chargeable call transfer barred;
- Invocation of interzonally chargeable call transfer barred;
- Invocation of call transfer where both legs are chargeable barred.

(*) Only these ODBs are supported by the SGSN. The SGSN applies them only for short message transfer.

7.6.3.10 ODB HPLMN Specific Data

This parameter refers to the set of subscribers features that the network operator or the service provider can regulate only when the subscriber is registered in the HPLMN. This set only includes those limitations that can be controlled in the VLR or in the SGSN:

- Operator Determined Barring Type 1;
- Operator Determined Barring Type 2;
- Operator Determined Barring Type 3;
- Operator Determined Barring Type 4.

7.6.3.11 Regional Subscription Data

This parameter defines the regional subscription area in which the subscriber is allowed to roam. It consists of a list of Zone Codes (see subclause 7.6.2.28).

7.6.3.12 Regional Subscription Response

This parameter indicates either that the regional subscription data cannot be handled or that the current MSC or SGSN area is entirely restricted because of regional subscription.

7.6.3.13 Roaming Restriction Due To Unsupported Feature

This parameter defines that a subscriber is not allowed to roam in the current MSC area. It may be used by the HLR if a feature or service is indicated as unsupported by the VLR.

7.6.3.14 Extensible SS-Info

This parameter refers to all the information related to a supplementary service and is a choice between:

- extensible forwarding information (see subclause 7.6.3.15);

- extensible call barring information (see subclause 7.6.3.20);
- CUG info (see subclause 7.6.3.22);
- extensible SS-Data (see subclause 7.6.3.29).

7.6.3.15 Extensible Forwarding information

This parameter represents the information related to each call forwarding service:

- the SS-Code of the relevant call forwarding service (see subclause 7.6.4.1);
- if required, a list of extensible forwarding feature parameters (see subclause 7.6.3.16).

The list may contain one item per Basic Service Group.

7.6.3.16 Extensible Forwarding feature

This parameter applies to each combination of call forwarding service and Basic Service Group and contains the following information, as required:

- extensible Basic Service Group (see subclause 7.6.3.5);
- extensible SS-Status (see subclause 7.6.3.17);
- forwarded-to number (see subclause 7.6.2.22);
- forwarded-to subaddress (see subclause 7.6.2.23);
- extensible forwarding options (see subclause 7.6.3.18);
- extensible no reply condition timer (see subclause 7.6.4.19).

7.6.3.17 Extensible SS-Status

This parameter refers to the state information of individual supplementary services as defined in TS GSM 03.11.

7.6.3.18 Extensible Forwarding Options

This parameter refers to a set of forwarding options attached to a supplementary service. It contains the following informations:

- notification to forwarding party (see TS GSM 02.82 for the meaning of this parameter);
- redirection notification to the forwarded-to party (see TS GSM 02.82 for the meaning of this parameter);
- notification to calling party (see TS GSM 02.82 for the meaning of this parameter);
- redirecting presentation (see TS GSM 02.82 for the meaning of this parameter);
- Forwarding reason (see TS GSM 02.82 for the meaning of this parameter).

7.6.3.19 Extensible No reply condition timer

This parameter refers to the extensible no reply condition timer for call forwarding on no reply.

7.6.3.20 Extensible Call barring information

This parameter contains for each call barring service:

- SS-Code (see subclause 7.6.4.1);
- a list of extensible call barring feature parameters (see subclause 7.6.3.21).

The list may contain one item per Basic Service Group.

7.6.3.21 Extensible Call barring feature

This parameter gives the status of call barring services as applicable to each Basic Service Group. The parameter contains the following information:

- Extensible Basic Service Group (see subclause 7.6.3.5);
- provisioned SS-Status (see subclause 7.6.3.17).

7.6.3.22 CUG info

This parameter refers to the overall information required for operation for each CUG:

- CUG subscriptionList;
- CUG featureList.

7.6.3.23 CUG subscription

This parameter refers to the set of basic information for each CUG defined in that subscription. The following information is stored:

- CUG index;
- CUG interlock;
- Intra CUG restrictions;
- Basic Service Group List.

7.6.3.24 CUG interlock

This parameter represents the CUG interlock code defined in ETS 300 138.

7.6.3.25 CUG index

This parameter represents the CUG index defined in ETS 300 138.

7.6.3.26 CUG feature

This parameter contains two parameters which are associated with the Basic Service Group. If the Basic Service Group Code is not present the feature applies to all Basic Services. The following parameters are included:

- Preferential CUG indicator:
indicates which CUG index is to be used at outgoing call set-up using the associated Basic Service Group;
- Inter CUG Option:
describes whether it for the associated Basic Service Group is allowed to make calls outside the CUG and whether incoming calls are allowed;
- Basic Service Group.

See TS GSM 02.85 for meaning of this parameter.

7.6.3.27 Inter CUG options

This parameter indicates the subscribers ability to make and receive calls outside a specific closed user group. It takes any of the following values:

- CUG only facility (only calls within CUG are allowed);
- CUG with outgoing access (calls outside CUG allowed);
- CUG with incoming access (calls from outside CUG into CUG allowed);
- CUG with both incoming and outgoing access (all calls allowed).

7.6.3.28 Intra CUG restrictions

This parameter describes whether or not the subscriber is allowed to originate calls to or to receive calls from within the CUG. It can take any of the following values:

- no CUG restrictions;
- CUG incoming calls barred;
- CUG outgoing calls barred.

7.6.3.29 Extensible SS-Data

This parameter refers to the necessary set of information required in order to characterise one supplementary service:

- SS-Code (see subclause 7.6.4.1);
- Extensible SS-Status (if applicable) (see subclause 7.6.3.17);
- Extensible Override subscription option (if applicable) (see subclause 7.6.3.30);
- Extensible CLI Restriction (if applicable) (see subclause 7.6.3.31);
- Extensible Basic Service Group Code (see subclause 7.6.3.5).

7.6.3.30 Subscriber State

This parameter indicates the state of the MS as defined in GSM 03.18.

7.6.3.31 Requested Info

This parameter indicates the subscriber information being requested as defined in GSM 03.18.

7.6.3.32 Suppression of Announcement

This parameter indicates if the announcement or tones shall be suppressed as defined in GSM 03.78.

7.6.3.33 Suppress T-CSI

This parameter is used to suppress the invocation of terminating CAMEL services.

7.6.3.34 GMSC CAMEL Subscription Info

This parameter contains CAMEL subscription information, i.e.O-CSI and/or T-CSI, which indicates to the GMSC that originating and/or terminating CAMEL services shall be invoked for the incoming call.

7.6.3.35 VLR CAMEL Subscription Info

This parameter identifies the subscriber as having CAMEL services which are invoked in the MSC.

7.6.3.36 Supported CAMEL Phases

This parameter indicates which phases of CAMEL are supported.

7.6.3.37 CUG Subscription Flag

This parameter indicates a that a subscriber with a T-CSI also has a CUG subscription. It is defined in TS GSM 03.78.

7.6.3.38 CAMEL Subscription Info Withdraw

This parameter indicates that CAMEL Subscription Info shall be deleted from the VLR.

7.6.3.39 Voice Group Call Service (VGCS) Data

This parameter refers to one or more groups a subscriber may be member of for voice group calls.

7.6.3.40 Voice Broadcast Service (VBS) Data

This parameter refers to one or more groups a subscriber may be member of for the voice broadcast service. Per group it is further indicated whether the subscriber is only allowed to listen to respective group calls or whether he is in addition entitled to initiate respective voice broadcast calls.

7.6.3.41 ISDN bearer capability

This parameter refers to the ISDN bearer capability information element defined in GSM 09.07.

7.6.3.42 Lower layer Compatibility

This parameter refers to the lower layer compatibility information element defined in GSM 04.08.

7.6.3.43 High Layer Compatibility

This parameter refers to the high layer compatibility information element defined in GSM 04.08.

7.6.3.44 Alerting Pattern

This parameter is an indication that can be used by the MS to alert the user in a specific manner in case of mobile terminating traffic (switched call or USSD). That indication can be an alerting level or an alerting category.

7.6.3.45 GPRS Subscription Data Withdraw

This parameter indicates that GPRS Subscription Data shall be deleted from the SGSN.

7.6.3.46 GPRS Subscription Data

This parameter refers to the list of PDP-Contexts that subscriber has subscribed to.

7.6.3.47 QoS-Subscribed

This parameter indicates the quality of service subscribed for a certain service. It is defined in GSM 03.60.

7.6.3.48 VPLMN address allowed

This parameter specifies whether the MS is allowed to used a dynamic address allocated in the VPLMN. It is defined in GSM 03.60.

7.6.3.49 Roaming Restricted In SGSN Due To Unsupported Feature

This parameter defines that a subscriber is not allowed to roam in the current SGSN area. It may be used by the HLR if a feature or service is indicated as unsupported by the SGSN.

7.6.3.50 Network Access Mode

This parameter is defined in GSM 03.08.

7.6.3.51 Mobile Not Reachable Reason

This parameter stores the reason for the MS being absent when an attempt to deliver a short message to an MS fails at the MSC, SGSN or both. It is defined in TS GSM 03.40.

7.6.3.52 Cancellation Type

This parameter indicates the reason of location cancellation. It is defined in TS GSM 03.60.

7.6.3.53 All GPRS Data

This parameter indicates to the SGSN that all GPRS Subscription Data shall be deleted for the subscriber.

7.6.3.54 Complete Data List Included

This parameter indicates to the SGSN that the complete GPRS Subscription Data stored for the Subscriber shall be replaced with the GPRS Subscription Data received.

7.6.3.55 PDP Context Identifier

This parameter is used to identify a PDP context for the subscriber.

7.6.3.56 LSA Information

This parameter refers to one or more localised service areas a subscriber may be a member of, together with the priority, the preferential access indicator, the active mode support indicator and active mode indication of each localised service area. The access right outside these localised service areas is also indicated.

7.6.3.57 SoLSA support indicator

This parameter indicates that the VLR or the SGSN supports SoLSA subscription.

7.6.3.58 LSA Information Withdraw

This parameter indicates that LSA information shall be deleted from the VLR or the SGSN.

7.6.3.59 LMU Indicator

This parameter indicates the presence of an LMU.

7.6.3.60 LCS Information

This parameter defines the LCS related information for an MS subscriber and contains the following components:

- GMLC List (see subclause 7.6.3.61)
- LCS Privacy Exception List (see subclause 7.6.3.62)
- MO-LR List (see subclause 7.6.3.65A)

7.6.3.61 GMLC List

This parameter contains the addresses of all GMLCs that are permitted to issue a non-call related MT-LR location request for this MS. Usage of this parameter is defined in GSM 03.71.

7.6.3.62 LCS Privacy Exception List

This parameter defines the classes of LCS Client that are allowed to locate any target MS. For each class, the following information is provided:

- SS-Code (see subclause 7.6.4.1);
- a list of LCS privacy exception parameters (see subclause 7.6.3.63).

7.6.3.63 LCS Privacy Exception Parameters

This parameter gives the status of each LCS privacy exception class and any additional parameters relevant to this class. The parameter contains the following information:

- provisioned SS-Status (see subclause 7.6.3.17);
- privacy notification to MS user (see subclause 7.6.3.65B);
- external client List (see subclause 7.6.3.64);
- internal client List (see subclause 7.6.3.65).

7.6.3.64 External Client List

This parameter is only applicable to the non-call related privacy class and gives the identities of the external clients that are allowed to locate a target MS for a non-call related MT-LR. Each identity is an international (e.g.E.164) address. For each identified external client, GMLC restrictions may be defined. It may also be indicated if the MS shall be notified of a non-restricted MT-LR from each identified LCS client and, if so, whether notification only or notification with privacy verification shall apply. Usage of this parameter is defined in GSM 03.71.

7.6.3.65 Internal Client List

This parameter is only applicable to the PLMN operator privacy class and gives the identities of the internal PLMN operator clients that are allowed to locate a target MS for an NI-LR or MT-LR. Usage of this parameter is defined in GSM 03.71.

7.6.3.66 MO-LR List

This parameter defines the classes of MO-LR for which a subscription exists for a particular MS. For each class, the following information is provided:

- SS-Code (see subclause 7.6.4.1).

7.6.3.67 Privacy Notification to MS User

This parameter is applicable to the non-call related privacy class and call related privacy class. For non-call related privacy class it indicates whether the MS user shall be notified for a non-call related MT-LR from any value added LCS client when the MT-LR is restricted and be enabled to accept or override the restriction. For call related privacy class it indicates whether the MS shall be notified of a call related MT-LR and, if so, whether notification only or notification with privacy verification shall apply. Usage of this parameter is defined in GSM 03.71.

7.6.3.68 GMLC List Withdraw

This parameter indicates whether the subscriber's LCS GMLC list shall be deleted from the VLR. The parameter does not apply to, and shall be ignored if received by, an SGSN.

7.6.4 Supplementary services parameters

7.6.4.1 SS-Code

This parameter may refer to one supplementary service or a set of supplementary services as defined in TS GSM 02.04. For MAP Release '98 this includes:

- Calling Line Identification Presentation service (CLIP);
- Calling Line Identification Restriction service (CLIR);
- Connected Line Identification Presentation service (COLP);
- Connected Line Identification Restriction service (COLR);
- Calling Name Presentation (CNAP)
- All Call Forwarding services;
- Call Waiting (CW);
- Call Hold (HOLD);
- Multi-Party service (MPTY);
- Closed User Group (CUG);
- All Charging services;
- All Call Restriction services;
- Explicit Call Transfer service (ECT);
- enhanced Multi-Level Precedence and Pre-emption service (eMLPP);
- Completion of Calls to Busy Subscriber, originating side (CCBS-A);
- Completion of Calls to Busy Subscriber, destination side (CCBS-B);
- All LCS privacy exceptions (see subclause 7.6.4.44);
- Mobile Originating Location Request (MO-LR) (see subclause 7.6.4.45).

7.6.4.2 SS-Status

This parameter refers to the state information of individual supplementary services as defined in GSM 03.11.

7.6.4.3 SS-Data

This parameter refers to the necessary set of information required in order to characterise one supplementary service:

- SS-Code (see subclause 7.6.4.1);
- SS-Status (if applicable) (see subclause 7.6.4.2);
- Override subscription option (see subclause 7.6.4.4);
- CLI Restriction (see subclause 7.6.4.5);
- Basic Service Group Code (see subclause 7.6.4.40).

7.6.4.4 Override Category

This parameter refers to the subscription option Override Category attached to a supplementary service. It can take the following two values:

- Enabled;
- Disabled.

7.6.4.5 CLI Restriction Option

This parameter refers to the subscription option Restriction mode attached to the CLIR supplementary service. It can take the following three values:

- Permanent;
- Temporary (Default Restricted);
- Temporary (Default Allowed).

7.6.4.6 Forwarding Options

This parameter refers to a forwarding option attached to a supplementary service. It can take one of the following values:

- notification to forwarding party (see GSM 02.82 for the meaning of this parameter);
- notification to calling party (see GSM 02.82 for the meaning of this parameter);
- redirecting presentation (see GSM 02.82 for the meaning of this parameter);
- Forwarding reason (see GSM 02.82 for the meaning of this parameter).

7.6.4.7 No reply condition timer

This parameter refers to the no reply condition timer for call forwarding on no reply.

7.6.4.8 - 7.6.4.14 Void

7.6.4.15 Forwarding information

This parameter represents the information related to each call forwarding service:

- the SS-Code of the relevant call forwarding service (see subclause 7.6.4.1);
- if required, a list of forwarding feature parameters (see subclause 7.6.4.16).

The list may contain one item per Basic Service Group.

7.6.4.16 Forwarding feature

This parameter applies to each combination of call forwarding service and Basic Service Group and contains the following information, as required:

- Basic Service Group (see subclause 7.6.4.40);
- SS-Status (see subclause 7.6.4.2);
- forwarded-to number (see subclause 7.6.2.22);
- forwarded-to subaddress (see subclause 7.6.2.23);
- forwarding options (see subclause 7.6.4.6);

- no reply condition timer (see subclause 7.6.4.7).

7.6.4.17 Void

7.6.4.18 Call barring information

This parameter contains for each call barring service:

- SS-Code (see subclause 7.6.4.1);
- a list of call barring feature parameters (see subclause 7.6.4.19).

The list may contain one item per Basic Service Group.

7.6.4.19 Call barring feature

This parameter gives the status of call barring services as applicable to each Basic Service Group. The parameter contains the following information:

- Basic Service Group (see subclause 7.6.4.40);
- SS-Status (see subclause 7.6.4.2).

7.6.4.20 New password

This parameter refers to the password which the subscriber just registered in the network.

This parameter refers to a password used by the subscriber for supplementary service control.

7.6.4.21 Current password

This parameter refers to a password used by the subscriber for supplementary service control.

7.6.4.22 Guidance information

This parameter refers to guidance information given to a subscriber who is requested to provide a password. One of the following information may be given:

- "enter password";

This information is used for checking of the old password.

- "enter new password";

This information is used during password registration for the request of the first new password.

- "enter new password again";

This information is used during password registration for the request of the new password again for verification.

7.6.4.23 Void

7.6.4.24 SS-Info

This parameter refers to all the information related to a supplementary service and is a choice between:

- forwarding information (see subclause 7.6.4.15);
 - call barring information (see subclause 7.6.4.18);
 - CUG info (see subclause 7.6.4.8);
 - SS-Data (see subclause 7.6.4.3);
 - eMLPP information (see subclause 7.6.4.4).

7.6.4.25-7.6.4.35 Void

7.6.4.36 USSD Data Coding Scheme

This parameter contains the information of the alphabet and the language used for the unstructured information in an Unstructured Supplementary Service Data operation. The coding of this parameter is according to the Cell Broadcast Data Coding Scheme as specified in GSM 03.38.

7.6.4.37 USSD String

This parameter contains a string of unstructured information in an Unstructured Supplementary Service Data operation. The string is sent either by the mobile user or the network. The contents of a string sent by the MS are interpreted by the network as specified in GSM 02.90.

7.6.4.38 Bearer service

This parameter may refer to a single bearer service, a set of bearer services or to all bearer services as defined in TS GSM 02.02. This parameter is used only for supplementary service management.

7.6.4.39 Teleservice

This parameter may refer to a single teleservice, a set of teleservices or to all teleservices as defined in TS GSM 02.03. This parameter is used only for supplementary service management.

7.6.4.40 Basic Service Group

This parameter refers to the Basic Service Group either as a bearer service (see subclause 7.6.4.38) or a teleservice (see subclause 7.6.4.39). This parameter is used only for supplementary service management. The null value (i.e. neither bearer service nor teleservice) is used to denote the group containing all bearer services and all teleservices.

7.6.4.41 eMLPP information

This parameter contains two parameters which are associated with the eMLPP service. The following two parameters are included:

- maximum entitled priority:
 - indicates the highest priority level the subscriber is allowed to apply for an outgoing call set-up;
 - default priority:
 - defines the priority level which shall be assigned to a call if no explicit priority is indicated during call set-up.

7.6.4.42 SS-event

This parameter indicates the Supplementary Service for which an invocation notification is sent towards the gsmSCF. It can indicate one of the following services:

- Explicit Call Transfer (ECT)
- Call Deflection (CD)
- Multi-Party call (MPTY).

7.6.4.43 SS-event data

This parameter contains additional information related to Supplementary Service invocation. Depending on the service invoked it can contain the following information:

ECT A list with all Called Party Numbers involved.

CD The called Party number involved.

7.6.4.44 LCS Privacy Exceptions

Distinct SS codes are assigned to the following classes of LCS client in a target MS subscriber's privacy exception list.

- Universal Class
- Call related value added class
- Non-Call related value added class
- PLMN operator class

7.6.4.45 Mobile Originating Location Request (MO-LR)

Distinct SS codes are assigned to the following classes of MO-LR:

- Basic Self Location
- Autonomous Self Location
- Transfer to Third Party.

7.6.5 Call parameters

7.6.5.1 Call reference number

This parameter refers to a call reference number allocated by a call control MSC.

7.6.5.2 Interrogation type

This parameter refers to the type of interrogation for routing information which is sent from a GMSC to an HLR. It can take either of two values:

- basic call (for information to route a call before the call has been extended to the VMSC of the called party);
- forwarding (for information to route the call to the forwarded-to destination after the VMSC of the forwarding party has requested the GMSC to resume handling of the call).

7.6.5.3 OR interrogation

This parameter indicates that the GMSC which interrogated the HLR for routeing information is not in the same PLMN as the HLR, and therefore that the call will potentially be optimally routed.

7.6.5.4 OR capability

This parameter indicates the phase of OR which the GMSC supports.

7.6.5.5 Forwarding reason

This parameter indicates the reason for which the call is to be forwarded. It can take one of three values:

- busy subscriber;
- mobile subscriber not reachable;
- no subscriber reply.

7.6.5.6 Forwarding interrogation required

This parameter indicates that if the VMSC of the forwarding subscriber requests the GMSC to resume handling of the call the GMSC shall interrogate the HLR for forwarding information.

7.6.5.7 O-CSI

This parameter identifies the subscriber as having originating CAMEL services as defined in TS GSM 03.78

7.6.5.8 Call Direction

This parameter is used to indicate the direction of the call.

7.6.5.9 Channel Type

This parameter is the result of a Channel Mode Modification for TS61/62. It contains the changed Air Interface User Rate. The information is sent from the SIWFS to the MSC to assign the correct radio resource. This parameter is defined in GSM 08.08.

7.6.5.10 Chosen Channel

This parameter is sent from the MSC to the SIWFS to adjust the interworking unit to the assigned radio resources. This parameter is defined in GSM 08.08.

7.6.5.11 CCBS Feature

This parameter corresponds to the 'CCBS Description' parameter in GSM 03.93. It refers to the necessary set of information required in order to characterise a certain CCBS request. The parameter may contain the following information:

- CCBS Index (see GSM 03.93 for the use of this parameter);
- B-subscriber number (see subclause 7.6.2.48);
- B-subscriber subaddress (see subclause 7.6.2.49);
- Basic Service Group Code (see subclause 7.6.4.40).

7.6.5.12 UU Data

This parameter includes User-To-User Data. It is defined in GSM 03.87.

7.6.5.13 UUS CF Interaction

This parameter indicates if the call forwarding or call deflection has been activated after UUS1 request has been accepted . It is defined in GSM 03.87.

7.6.5.14 Number Portability Status

This parameter indicates the number portability status of subscriber. See GSM 03.66.

7.6.6 Radio parameters

7.6.6.1-7.6.6.6 Void

7.6.6.7 HO-Number Not Required

This parameter indicates that no handover number allocation is necessary.

7.6.7 Authentication parameters

7.6.7.1 Authentication set list

This parameter represents a list of sets of authentication parameters for a given subscriber:

- Rand;
- Sres;
- Kc.

7.6.7.2 Rand

This parameter represents a random number used for authentication.

7.6.7.3 Sres

This parameter represents the response to an authentication request.

7.6.7.4 Kc

This parameter refers to a key used for ciphering purposes.

7.6.7.5 Void

7.6.7.6 Cksn

This parameter refers to a ciphering key sequence number.

7.6.7.7 Ciphering mode

This parameter refers to the ciphering mode which is associated with a radio channel. It may take values as follows:

- no encryption;
- identification of specific ciphering algorithm.

7.6.8 Short message parameters

7.6.8.1 SM-RP-DA

This parameter represents the destination address used by the short message service relay sub-layer protocol. It can be either of the following:

- IMSI (see subclause 7.6.2.1);
- LMSI (see subclause 7.6.2.16);
- MS-ISDN (see subclause 7.6.2.17);
- roaming number (see subclause 7.6.2.19);
- service centre address (see subclause 7.6.2.27).

7.6.8.2 SM-RP-OA

This parameter refers to the originating address used by the short message service relay sub-layer protocol. It can be either of the following:

- MS-ISDN (see subclause 7.6.2.17);
- service centre address (see subclause 7.6.2.27).

7.6.8.3 MWD status

This parameter indicates whether or not the address of the originator service centre is already contained in the Message Waiting Data file. In addition, it contains the status of the Memory Capacity Exceeded Flag (MCEF), the status of the Mobile subscriber Not Reachable Flag (MNRF) and the status of the Mobile station Not Reachable for GPRS flag (MNRG).

7.6.8.4 SM-RP-UI

This parameter represents the user data field carried by the short message service relay sub-layer protocol.

7.6.8.5 SM-RP-PRI

This parameter is used to indicate whether or not delivery of the short message shall be attempted when a service centre address is already contained in the Message Waiting Data file.

7.6.8.6 SM Delivery Outcome

This parameter indicates the cause for setting the message waiting data. It can take one of the following values:

- Absent subscriber;
- MS memory capacity exceeded;
- Successful transfer.

7.6.8.7 More Messages To Send

This parameter is used to indicate whether or not the service centre has more short messages to send.

7.6.8.8 Alert Reason

This parameter is used to indicate the reason why the service centre is alerted. It can take one of the following values:

- MS present;
- Memory Available.

7.6.8.9 Absent Subscriber Diagnostic SM

This parameter is used to indicate the reason why the subscriber is absent. For the values for this parameter see TS GSM 03.40.

7.6.8.10 Alert Reason Indicator

This parameter indicates that the alert reason is sent to the HLR due to GPRS activity.

7.6.8.11 Additional SM Delivery Outcome

This parameter is used to indicate the GPRS delivery outcome in case a combination between delivery outcome for GPRS and non-GPRS are sent to the HLR.

7.6.8.12 Additional Absent Subscriber Diagnostic SM

This parameter indicates the reason of the additional SM Delivery Outcome.

7.6.8.13 Delivery Outcome Indicator

This parameter indicates that the delivery outcome sent to the HLR is for GPRS.

7.6.8.14 GPRS Node Indicator

This parameter indicates that the Network Node Number sent by the HLR is the SGSN number.

7.6.8.15 GPRS Support Indicator

This parameter indicates that the SMS-GMSC supports GPRS specific procedure of combine delivery of Short Message via MSC and/or via the SGSN.

7.6.8.16 SM-RP-MTI

This parameter represents the RP-Message Type Indicator of the Short Message. It is used to distinguish a SM sent to the mobile station in order to acknowledge an MO-SM initiated by the mobile from a normal MT-SM. This parameter is formatted according to the formatting rules of address fields as described in GSM 03.40.

7.6.8.17 SM-RP-SMEA

This parameter represents the RP-Originating SME-address of the Short Message Entity that has originated the SM. This parameter is used by the short message service relay sub-layer protocol and is formatted according to the formatting rules of address fields as described in GSM 03.40.

7.6.9 Access and signalling system related parameters

7.6.9.1 BSS-apdu

This parameter includes one or two concatenated complete 08.06 messages, as described in GSM 03.09 and GSM 09.10. The Protocol ID indicates that the message or messages are according to GSM 08.06. For the coding of the messages see GSM 08.06 and GSM 08.08.

7.6.9.2 CM service type

This parameter identifies the service category being requested by the subscriber:

- mobile originating call;
- emergency call establishment;
- short message service;
- mobile originating call re-establishment;
- mobile terminating call;
- SS request;
- Voice group call setup;
- Voice broadcast setup.

7.6.9.3 Access connection status

This parameter represents the following access connection status information:

- RR-connection status (established/not established);
- ciphering mode (on/off);
- authentication status (authenticated/not authenticated).

7.6.9.4 External Signal Information

This parameter contains concatenated information elements (including tag and length) which are defined by a common protocol version, preceded by the associated protocol ID. It is used to transport information of the indicated protocol via MAP interfaces.

7.6.9.5 Access signalling information

This parameter refers to any set of information elements imported from GSM 04.08.

7.6.9.6 Location update type

This parameter refers to the location update type (normal, periodic or IMSI attach) contained in the GSM 04.08 LOCATION REGISTRATION REQUEST message.

7.6.9.7 Protocol ID

This parameter refers to the protocol to which the coding of the content of the associated External Signal Information conforms.

The following values are defined:

- 04.08;
- 08.06;
- ETS 300 102-1.

This value indicates the protocol defined by ETS 300 102-1 (EDSS1).

7.6.9.8 Network signal information

This parameter is transported as external signal information. The protocol ID shall be set to "ETS 300 102-1".

The network signal information may include the following information elements as defined in GSM 09.07:

- ISDN BC; the tag and length are defined by ETS 300 102-1.
For the content, see GSM 09.07.
- HLC; the tag and length are defined by ETS 300 102-1.
For the content, see GSM 09.07.
- LLC; the tag and length are defined by ETS 300 102-1.
For the content, see GSM 09.07.

They are contained in the Signal Information parameter according to figure 7.6/1 (irrespective of the order):




Figure 7.6/1: Network signal information parameter

7.6.9.9 Call Info

This parameter is transported as external signal information. The protocol ID shall be set to "GSM 04.08".

The Call Info includes the set of information elements from the original SETUP message and is imported from GSM 04.08.

7.6.9.10 Additional signal info

This parameter is transported as ext-external signal information. The protocol ID shall be set to "ETS 300 356".

The additional signal information may include the following information elements:

- Calling Party Number as defined by ETS 300 356.
- Generic Number as defined by ETS 300 356.

They are contained in the Signal Information parameter according to figure 7.6/2 (irrespective of the order):




Figure 7.6/2: Additional signal information parameter

7.6.10 System operations parameters

7.6.10.1 Network resources

This parameter refers to a class or type of network resource:

- PLMN;
- HLR;
- VLR (current or previous);
- MSC (controlling or current);
- EIR;
- radio sub-system.

7.6.10.2 Trace reference

This parameter represents a reference associated with a tracing request. The parameter is managed by OMC.

7.6.10.3 Trace type

This parameter identifies the type of trace. Trace types are fully defined in GSM 12.08.

7.6.11 Location Service Parameters

7.6.11.1 Age of Location Estimate

This parameter indicates how long ago the location estimate was obtained.

7.6.11.2 Void

7.6.11.3 Void

7.6.11.4 LCS Client ID

This parameter provides information related to the identity of an LCS client.

7.6.11.5 LCS Event

This parameter identifies an event associated with the triggering of a location estimate.

7.6.11.6 LCS MLC Data

This parameter provides the identities of any authorized GMLCs for a target MS. Only these GMLCs are allowed to send a location request for an external client when location requests are restricted to these GMLCs.

7.6.11.7 LCS Priority

This parameter gives the priority of the location request.

7.6.11.8 LCS QoS

This parameter defines the Quality of Service (QoS) for any location request. It is composed of the following elements.

1) Response Time

Indicates the category of response time – “low delay” or “delay tolerant”.

2) Horizontal Accuracy

Indicates the required horizontal accuracy of the location estimate.

3) Vertical Coordinate

Indicates if a vertical coordinate is required (in addition to horizontal coordinates).

4) Vertical Accuracy

Indicates the required vertical accuracy of the location estimate (inclusion is optional).

7.6.11.9 Void

7.6.11.10 Void

7.6.11.11 Location Estimate

This parameter gives an estimate of the location of an MS in universal coordinates and the accuracy of the estimate.

7.6.11.12 Location Type

This parameter indicates the type of location estimate required by the LCS client. Possible location estimate types include:

- current location
- current or last known location
- initial location for an emergency services call.

7.6.11.13 NA-ESRD

This parameter only applies to location for an emergency services call in North America and gives the North American Emergency Services Routing Digits.

7.6.11.14 NA-ESRK

This parameter only applies to location for an emergency services call in North America and gives the North American Emergency Services Routing Key.

7.6.11.15 Void

7.6.11.16 Privacy Override

This parameter indicates if MS privacy is overridden by the LCS client when the GMLC and VMSC for an MR-LR are in the same country.

7.6.11.17 Void

7.6.11.18 Void

7.6.11.19 Void

7.7 Representation of a list of a basic parameter in service-primitives

In some service-primitives several instances of a basic parameter of subclause 7.6 are required. In the service descriptions such cases will be represented as

ParameterNameLIST

in the tables where ParameterName refers to one of the parameters defined in subclause 7.6. This corresponds to the following construction rule:




Figure 7.7/1: Construction of Lists

8 Mobility services

8.1 Location management services

8.1.1 MAP_UPDATE_LOCATION_AREA service

8.1.1.1 Definition

This service is used between MSC and VLR to update location information in the network. It is initiated by an MS when changing the location area or at first registration. The detailed conditions are given in GSM 03.12.

The MAP_UPDATE_LOCATION_AREA service is a confirmed service using the primitives from table 8.1/1.

8.1.1.2 Service primitives

Table 8.1/1: MAP_UPDATE_LOCATION_AREA

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
Target location area Id	M	M(=)		
Serving cell Id	M	M(=)		
Location update type	M	M(=)		
IMSI	C	C(=)		
TMSI	C	C(=)		
Previous location area Id	C	C(=)		
CKSN	C	C(=)		
User error			C	C(=)
Provider error				O

8.1.1.3 parameter definitions and use

Invoke Id

See definition in subclause 7.6.1.

Target location area Id

See definition in subclause 7.6.2.

Serving cell Id

See definition in subclause 7.6.2.

Location update type

See definition in subclause 7.6.9.

IMSI

See definition in subclause 7.6.2. It is up to the MS to provide either IMSI or TMSI, but one shall be present.

TMSI

See definition in subclause 7.6.2. It is up to the MS to provide either IMSI or TMSI, but one shall be present.

Previous location area Id

See definition in subclause 7.6.2. This parameter is provided if the updating is not a first registration.

CKSN

See definition in subclause 7.6.7. The CKSN is given if TMSI is used.

User error

One of the following error causes defined in subclause 7.6.1 is sent by the user in case of location area updating failures, depending on the failure reason:

- unknown subscriber;

This cause is used if the subscriber is not known in the VLR and even a correlated request to the subscriber's HLR gives a negative result (i.e. the IMSI is not allocated to a subscriber).

- unknown location area;

This cause is used if the target location area identity given is not known in the VLR.

- roaming not allowed;

This cause is used if the MS is not allowed to roam into the target location area indicated in the MAP_UPDATE_LOCATION_AREA Req. The cause will be qualified according to the roaming restriction reason, i.e. one of "National Roaming Not Allowed", "PLMN Not Allowed", "Location Area Not Allowed", or "Operator Determined Barring".

- illegal subscriber;

This error is sent if a correlated authentication procedure has not authenticated the subscriber.

- illegal equipment;

This error is sent if an IMEI check failed, i.e. the IMEI is blacklisted or not white-listed.

- system failure;

- unexpected data value.

Provider error

For definition of provider errors see subclause 7.6.1.

8.1.2 MAP_UPDATE_LOCATION service

8.1.2.1 Definition

This service is used by the VLR to update the location information stored in the HLR.

The MAP_UPDATE_LOCATION service is a confirmed service using the service primitives given in table 6.1/2.

8.1.2.2 Service primitives

Table 8.1/2: MAP_UPDATE_LOCATION

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
MSC Address	M	M(=)		
VLR number	M	M(=)		
LMSI	U	C(=)		
Supported CAMEL Phases	C	C(=)		
SoLSA Support Indicator	C	C(=)		
HLR number			C	C(=)
User error			C	C(=)
Provider error				O

8.1.2.3 Parameter definitions and use

Invoke Id

See definition in subclause 5.6.1.

IMSI

See definition in subclause 5.6.2.

MSC Address

See definition in subclause 5.6.2. The MSC address is used for short message delivery only and for each incoming call set-up attempt the MSRN will be requested from the VLR.

VLR number

See definition in subclause 5.6.2.

LMSI

See definition in subclause 5.6.2. It is an operator option to provide the LMSI from the VLR; it is mandatory for the HLR to support the LMSI handling procedures.

Supported CAMEL Phases

This parameter indicates which phases of CAMEL are supported. Must be present if a CAMEL phase different from phase 1 is supported. Otherwise may be absent.

HLR number

See definition in subclause 5.6.2. The presence of this parameter is mandatory in case of successful HLR updating.

SoLSA Support Indicator

This parameter is used by the VLR to indicate to the HLR in the Update Location indication that SoLSA is supported. If this parameter is not included in the Update Location indication and the Subscriber is marked as only allowed to roam in Subscribed LSAs, then the HLR shall reject the roaming and indicate to the VLR that roaming is not allowed to that Subscriber in the VLR.

This SoLSA Support Indicator shall be stored by the HLR per VLR where there are Subscribers roaming. If a Subscriber is marked as only allowed to roam in Subscribed LSAs while roaming in a VLR and no SoLSA Support indicator is stored for that VLR, the location status of that Subscriber shall be set to Restricted.

User error

In case of unsuccessful updating, an error cause shall be returned by the HLR. The following error causes defined in subclause 5.6.1 may be used, depending on the nature of the fault:

- unknown subscriber;
- roaming not allowed;

This cause will be sent if the MS is not allowed to roam into the PLMN indicated by the VLR number. The cause is qualified by the roaming restriction reason "PLMN Not Allowed" or "Operator Determined Barring". If no qualification is received (HLR with MAP Version 1), "PLMN Not Allowed" is taken as default.

- system failure;
- unexpected data value.

Provider error

For definition of provider errors see subclause 5.6.1.

8.1.3 MAP_CANCEL_LOCATION service

8.1.3.1 Definition

This service is used between HLR and VLR to delete a subscriber record from the VLR. It may be invoked automatically when an MS moves from one VLR area to another, to remove the subscriber record from the old VLR, or by the HLR operator to enforce a location updating from the VLR to the HLR, e.g. on withdrawal of a subscription.

Also this service is used between HLR and SGSN to delete a subscriber record from the SGSN. It may be invoked automatically when an MS moves from one SGSN area to another, to remove the subscriber record from the old SGSN, or by the HLR operator to enforce a location updating from the SGSN to the HLR.

The MAP_CANCEL_LOCATION service is a confirmed service using the primitives defined in table 8.1/3.

8.1.3.2 Service primitives

Table 8.1/3: MAP_CANCEL_LOCATION

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
LMSI	C	C(=)		
Cancellation Type	C	C(=)		
User error			C	C(=)
Provider error				O

8.1.3.3 Parameter definitions and use

Invoke Id

See definition in subclause 7.6.1.

IMSI

See definition in subclause 7.6.2.

LMSI

See definition in subclause 7.6.2. The LMSI shall be included if it has been received from VLR. LMSI is not applicable between SGSN and HLR.

Value 0000 0000 can be used to indicate that the LMSI is not in use.

Cancellation Type

See definition in subclause 5.6.3. The presence of this parameter is mandatory when the Cancel Location is sent to the SGSN. If the VLR receives this parameter and do not understand it the VLR shall ignore it.

User error

If the cancellation fails, an error cause is to be returned by the VLR or by the SGSN. The one of the following error causes defined in subclause 5.6.1 shall be used:

- unexpected data value;
- data missing.

Provider error

For definition of provider errors see subclause 7.6.1.

8.1.4 MAP_SEND_IDENTIFICATION service

8.1.4.1 Definition

The MAP_SEND_IDENTIFICATION service is used between a VLR and a previous VLR to retrieve IMSI and authentication sets for a subscriber registering afresh in that VLR.

The MAP_SEND_IDENTIFICATION service is a confirmed service using the service primitives defined in table 8.1/4.

8.1.4.2 Service primitives

Table 8.1/4: MAP_SEND_IDENTIFICATION

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
TMSI	M	M(=)		
IMSI			C	C(=)
Authentication set			U	C(=)
User error			C	C(=)
Provider error				O

8.1.4.3 Parameter definitions and use

Invoke Id

See definition in subclause 7.6.1.

TMSI

See definition in subclause 7.6.2.

IMSI

See definition in subclause 7.6.2. The IMSI is to be returned if the service succeeds.

Authentication set

See definition in subclause 7.6.7. If the service succeeds a list of up to five authentication sets is returned, if there are any available.

User error

This parameter is mandatory if the service fails. The following error cause defined in subclause 7.6.1 may be used, depending on the nature of the fault:

- unidentified subscriber.

Provider error

For definition of provider errors see subclause 7.6.1.

8.1.5 MAP_DETACH_IMSI service

8.1.5.1 Definition

The MAP_DETACH_IMSI service is used by the MSC to indicate to the VLR that an MS is no longer reachable. The network needs this information e.g. to reject an incoming call without initiating paging on the radio path.

The MAP_DETACH_IMSI service is a non-confirmed service using the service primitives defined in table 8.1/5.

8.1.5.2 Service primitives

Table 8.1/5: MAP_DETACH_IMSI

Parameter name	Request	Indication
Invoke Id	M	M(=)
Serving cell id	M	M(=)
IMSI	C	C(=)
TMSI	C	C(=)

8.1.5.3 Parameter definitions and use

Invoke Id

See definition in subclause 7.6.1.

Serving cell id

See definition in subclause 7.6.2.

IMSI

See definition in subclause 7.6.2. It is up to the MS to provide either IMSI or TMSI as subscriber identity, but one shall be present.

TMSI

See definition in subclause 7.6.2. It is up to the MS to provide either IMSI or TMSI as subscriber identity, but one shall be present.

8.1.6 MAP_PURGE_MS service

8.1.6.1 Definition

This service is used between the VLR and the HLR to cause the HLR to mark its data for an MS so that any request for routing information for a mobile terminated call or a mobile terminated short message will be treated as if the MS is not reachable. It is invoked when the subscriber record for the MS is to be deleted in the VLR, either by MMI interaction or automatically, e.g. because the MS has been inactive for several days.

Also this service is used between the SGSN and the HLR to cause the HLR to mark its data for an MS so that any request for routing information for a mobile terminated short message or a network requested PDP-context activation will be treated as if the MS is not reachable. It is invoked when the subscriber record for the MS is to be deleted in the SGSN, either by MMI interaction or automatically, e.g. because the MS has been inactive for several days.

The MAP_PURGE_MS service is a confirmed service using the primitives defined in table 8.1/6.

8.1.6.2 Service primitives

Table 8.1/6: MAP_PURGE_MS

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
VLR number	C	C(=)		
Freeze TMSI			C	C(=)
Freeze P-TMSI			C	C(=)
SGSN number	C	C(=)		
User error			C	C(=)
Provider error				O

8.1.6.3 Parameter definitions and use

Invoke ID

See definition in subclause 7.6.1.

IMSI

See definition in subclause 7.6.2.

VLR number

Shall be present if the sender is VLR. See definition in subclause 7.6.2.

SGSN number

Shall be present if the sender is SGSN. See definition in subclause 7.6.2

Freeze TMSI

This parameter is sent to the VLR to indicate that the TMSI has to be frozen. It shall be present if the received VLR number matches the stored VLR number.

Freeze P-TMSI

This parameter is sent to the SGSN to indicate that the P-TMSI has to be frozen. It shall be present if the received SGSN number matches the stored SGSN number.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Data Missing;
- Unexpected Data Value;
- UnknownSubscriber.

Provider error

See definition of provider errors in subclause 7.6.1.

8.1.7 MAP_UPDATE_GPRS_LOCATION service

8.1.7.1 Definition

This service is used by the SGSN to update the location information stored in the HLR.

The MAP_UPDATE_GPRS_LOCATION service is a confirmed service using the service primitives given in table 8.1/7.

8.1.7.2 Service primitives

Table 8.1/7: MAP_UPDATE_GPRS_LOCATION

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
SGSN number	M	M(=)		
SGSN address	M	M(=)		
SoLSA Support Indicator	C	C(=)		
HLR number			C	C(=)
User error			C	C(=)
Provider error				O

8.1.7.3 Parameter definitions and use

Invoke Id

See definition in subclause 7.6.1.

IMSI

See definition in subclause 7.6.2.

SGSN number

See definition in subclause 7.6.2.

SGSN address

See definition in subclause 7.6.2.

SoLSA Support Indicator

This parameter is used by the SGSN to indicate to the HLR in the Update GPRS Location indication that SoLSA is supported. If this parameter is not included in the Update GPRS Location indication and the Subscriber is marked as only allowed to roam in Subscribed LSAs, then the HLR shall reject the roaming and indicate to the SGSN that roaming is not allowed to that Subscriber in the SGSN.

This SoLSA Support Indicator shall be stored by the HLR per SGSN where there are Subscribers roaming. If a Subscriber is marked as only allowed to roam in Subscribed LSAs while roaming in a SGSN and no SoLSA Support indicator is stored for that SGSN, the location status of that Subscriber has to be set to Restricted.

HLR number

See definition in subclause 7.6.2. The presence of this parameter is mandatory in case of successful HLR updating.

User error

In case of unsuccessful updating, an error cause shall be returned by the HLR. The following error causes defined in subclause 7.6.1 may be used, depending on the nature of the fault:

- unknown subscriber;
- roaming not allowed;

This cause will be sent if the MS is not allowed to roam into the PLMN indicated by the SGSN number. The cause is qualified by the roaming restriction reason "PLMN Not Allowed" or "Operator Determined Barring".

- system failure;
- unexpected data value.

The diagnostic in the Unknown Subscriber may indicate "Imsi Unknown" or "Gprs Subscription Unknown".

Provider error

For definition of provider errors see subclause 7.6.1.

8.2 Paging and search

8.2.1 MAP_PAGE service

8.2.1.1 Definition

This service is used between VLR and MSC to initiate paging of an MS for mobile terminated call set-up, mobile terminated short message or unstructured SS notification.

The MAP_PAGE service is a confirmed service using the primitives from table 8.2/1.

8.2.1.2 Service primitives

Table 8.2/1: MAP_PAGE

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
Stored location area Id	M	M(=)		
TMSI	U	C(=)		
User error			C	C(=)
Provider error				O

8.2.1.3 Parameter definitions and use

Invoke Id

See definition in subclause 7.6.1.

IMSI

See definition in subclause 7.6.2. The IMSI is used to define the paging subgroup. If the TMSI is not supplied, paging on the radio path uses the IMSI as an identifier.

Stored location area Id

See definition in subclause 7.6.2.

TMSI

See definition in subclause 7.6.2. The TMSI is included if paging on the radio channel is to use the TMSI as an identifier.

User error

The following error causes defined in subclause 7.6.1 may be sent by the user in case of a paging error, depending on the failure reason:

- absent subscriber;
- unknown location area;
- busy subscriber;
- system failure;

This corresponds to the case where there is no call associated with the MAP_PAGE service, i.e. if the call has been released but the dialogue to the VLR has not been aborted.

- unexpected data value.

Provider error

See definition in subclause 7.6.1.

8.2.2 MAP_SEARCH_FOR_MS service

8.2.2.1 Definition

This service is used between VLR and MSC to initiate paging of an MS in all location areas of that VLR. It is used if the VLR does not hold location area information confirmed by radio contact.

The MAP_SEARCH_FOR_MS service is a confirmed service using the primitives from table 8.2/2.

8.2.2.2 Service primitives

Table 8.2/2: MAP_SEARCH_FOR_MS

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
Current location area Id			C	C(=)
User error			C	C(=)
Provider error				O

8.2.2.3 Parameter definitions and use

Invoke Id

See definition in subclause 7.6.1.

IMSI

See definition in subclause 7.6.2. The IMSI is used to identify the subscriber when paging on the radio path.

Current location area Id

See definition in subclause 7.6.2. In case of successful outcome of the service, i.e. if the MS responds to paging, the Location Area Id of the area in which the MS responded is given in the response.

User error

The following error causes defined in subclause 7.6.1 shall be sent by the user if the search procedure fails, depending on the failure reason:

- absent subscriber;

This error cause is returned by the MSC if the MS does not respond to the paging request.

- system failure;

This corresponds to the case where there is no call associated with the MAP_SEARCH_FOR_MS service, i.e. if the call has been released but the dialogue to the VLR has not been aborted.

- busy subscriber;
- unexpected data value.

Provider error

See definition in subclause 7.6.1.

8.3 Access management services

8.3.1 MAP_PROCESS_ACCESS_REQUEST service

8.3.1.1 Definition

This service is used between MSC and VLR to initiate processing of an MS access to the network, e.g. in case of mobile originated call set-up or after being paged by the network.

The MAP_PROCESS_ACCESS_REQUEST service is a confirmed service using the primitives from table 8.3/1.

8.3.1.2 Service primitives

Table 8.3/1: MAP_PROCESS_ACCESS_REQUEST

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
CM service type	M	M(=)		
Access connection status	M	M(=)		
Current Location Area Id	M	M(=)		
Serving cell id	M	M(=)		
TMSI	C	C(=)		
Cksn	C	C(=)		
IMSI	C	C(=)	C	C(=)
IMEI	C	C(=)	C	C(=)
MSISDN			U	C(=)
User error			C	C(=)
Provider error				O

8.3.1.3 Parameter definitions and use

Invoke Id

See definition in subclause 7.6.1.

CM service type

See definition in subclause 7.6.9.

Access connection status

See definition in subclause 7.6.9.

Current Location Area Id

See definition in subclause 7.6.2. This parameter is used to update the VLR in case of previous VLR failure.

Serving cell id

See definition in subclause 7.6.2.

TMSI

See definition in subclause 7.6.2. Either TMSI or IMSI as received from the MS are included in the Request/Indication, but one shall be present. In case of CM Service Type "Emergency Call Establishment", the IMEI may replace IMSI/TMSI.

Cksn

See definition in subclause 7.6.7. In case of access with TMSI, the Cksn shall be present.

IMSI

See definition in subclause 7.6.2. Either TMSI or IMSI as received from the MS are included in the Request/Indication, but one shall be present. In case of CM Service Type "Emergency Call Establishment", the IMEI may replace IMSI/TMSI.

In the Response/Confirmation, the IMSI is to be sent in case of successful outcome of the service. In case of CM Service Type "Emergency Call Establishment", IMEI may replace IMSI.

IMEI

See definition in subclause 7.6.2. The IMEI may replace IMSI/TMSI in the Request/Indication and IMSI in the Response/Confirmation only in case the CM Service Type indicates "Emergency Call Establishment".

MSISDN

See definition in subclause 7.6.2. The MSISDN is included in case of successful outcome of the service as an operator option, e.g. if it is needed at the MSC for charging purposes in case of call forwarding.

User error

One of the following error causes defined in subclause 7.6.1 shall be sent by the user if the access request fails, depending on the failure reason:

- unidentified subscriber;
- illegal subscriber;

This error is sent if a correlated authentication procedure has not authenticated the subscriber.

- illegal equipment;

This error is sent if an IMEI check failed, i.e. the IMEI is blacklisted or not white-listed.

- roaming not allowed;

This cause is used after VLR restart if the subscriber has no subscription for the current location area, e.g. due to regional subscription. The cause will be qualified by "location area not allowed" or "national roaming not allowed", respectively.

- unknown location area;
- system failure;
- unexpected data value.

Provider error

For definition of provider errors see subclause 7.6.1.

8.4 Handover services

8.4.1 MAP_PREPARE_HANDOVER service

8.4.1.1 Definition

This service is used between MSC-A and MSC-B (E-interface) when a call is to be handed over from MSC-A to MSC-B.

The MAP_PREPARE_HANDOVER service is a confirmed service using the primitives from table 8.4/1.

8.4.1.2 Service primitives

Table 8.4/1: MAP_PREPARE_HANDOVER

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
Target Cell Id	C	C(=)		
HO-NumberNotRequired	C	C(=)		
BSS-APDU	C	C(=)	C	C(=)
Handover Number			C	C(=)
User error			C	C(=)
Provider error				O

8.4.1.3 Parameter use

Invoke Id

For definition of this parameter see subclause 7.6.1.

Target Cell Id

For definition of this parameter see subclause 7.6.2. This parameter is only included if the service is not in an ongoing transaction.

HO-Number Not Required

For definition of this parameter see subclause 7.6.6.

BSS-APDU

For definition of this parameter see subclause 7.6.9.

Handover Number

For definition of this parameter see subclause 7.6.2. This parameter shall be returned, unless the parameter HO-NumberNotRequired is sent.

User error

For definition of this parameter see subclause 7.6.1. The following errors defined in subclause 7.6.1 may be used, depending on the nature of the fault:

- No handover number available;
- System failure;
- Unexpected data value;
- DataMissing.

Provider error

See definition of provider errors in subclause 7.6.1.

8.4.2 MAP_SEND_END_SIGNAL service

8.4.2.1 Definition

This service is used between MSC-B and MSC-A (E-interface) indicating that the radio path has been established by MSC-B to the MS. MSC-A retains then the main control of the call until it clears.

The response is used by MSC-A to inform MSC-B that all resources for the call can be released in MSC-B, either because the call has been released in MSC-A or because the call has been successfully handed over from MSC-B to another MSC.

The MAP_SEND_END_SIGNAL service is a confirmed service using the primitives from table 8.4/2.

8.4.2.2 Service primitives

Table 8.4/2: MAP_SEND_END_SIGNAL

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
BSS-APDU	M	M(=)		
Provider error				O

8.4.2.3 Parameter use

Invoke Id

For definition of this parameter see subclause 7.6.1.

BSS-APDU

For definition of this parameter see subclause 7.6.9.

Provider error

For definition of this parameter see subclause 7.6.1.

8.4.3 MAP_PROCESS_ACCESS_SIGNALLING service

8.4.3.1 Definition

This service is used between MSC-B and MSC-A (E-interface) to pass information received on the A-interface in MSC-B to MSC-A.

The MAP_PROCESS_ACCESS_SIGNALLING service is a non-confirmed service using the primitives from table 8.4/3.

8.4.3.2 Service primitives

Table 8.4/3: MAP_PROCESS_ACCESS_SIGNALLING

Parameter name	Request	Indication
Invoke Id	M	M(=)
BSS-APDU	M	M(=)

8.4.3.3 Parameter use

Invoke Id

For definition of this parameter see subclause 7.6.1.

BSS-APDU

For definition of this parameter see subclause 7.6.9.

8.4.4 MAP_FORWARD_ACCESS_SIGNALLING service

8.4.4.1 Definition

This service is used between MSC-A and MSC-B (E-interface) to pass information to be forwarded to the A-interface of MSC-B.

The MAP_FORWARD_ACCESS_SIGNALLING service is a non-confirmed service using the primitives from table 8.4/4.

8.4.4.2 Service primitives

Table 8.4/4: MAP_FORWARD_ACCESS_SIGNALLING

Parameter name	Request	Indication
Invoke Id	M	M(=)
BSS-APDU	M	M(=)

8.4.4.3 Parameter use

For the definition and use of all parameters and errors, see subclause 7.6.1

Invoke Id

For definition of this parameter see subclause 7.6.1.

BSS-APDU

For definition of this parameter see subclause 7.6.9.

8.4.5 MAP_PREPARE_SUBSEQUENT_HANDOVER service

8.4.5.1 Definition

This service is used between MSC-B and MSC-A (E-interface) to inform MSC-A that it has been decided that a handover to either MSC-A or a third MSC (MSC-B') is required.

The MAP_PREPARE_SUBSEQUENT_HANDOVER service is a confirmed service using the primitives from table 8.4/5.

8.4.5.2 Service primitives

Table 8.4/5: MAP_PREPARE_SUBSEQUENT_HANDOVER

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
Target Cell Id	M	M(=)		
Target MSC Number	M	M(=)		
BSS-APDU	M	M(=)	C	C(=)
User error			C	C(=)
Provider error				O

8.4.5.3 Parameter use

Invoke Id

For definition of this parameter see subclause 7.6.1.

Target Cell Id

For definition of this parameter see subclause 7.6.2.

Target MSC Number

For definition of this parameter see subclause 7.6.2.

BSS-APDU

For definition of this parameter see subclause 7.6.9.

User error

For definition of this parameter see subclause 7.6.1. The following error causes defined in subclause 7.6.1 may be used, depending on the nature of the fault:

- Unknown MSC;
- Subsequent handover failure;
- Unexpected data value;

- Data Missing.

Provider error

For definition of this parameter see subclause 7.6.1.

8.4.6 MAP_ALLOCATE_HANDOVER_NUMBER service

8.4.6.1 Definition

This service is used between MSC and VLR (B-interface) to request a handover number.

The MAP_ALLOCATE_HANDOVER_NUMBER service is a confirmed service using the primitives from table 8.4/6.

8.4.6.2 Service primitives

Table 8.4/6: MAP_ALLOCATE_HANDOVER_NUMBER

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
User error			C	C(=)
Provider error			O	O

8.4.6.3 Parameter use

Invoke Id

For definition of this parameter see subclause 7.6.1.

User error

For definition of this parameter see subclause 7.6.1. The following errors defined in subclause 7.6.1 may be used, depending on the nature of the fault:

- No handover number available.

Provider error

For definition of this parameter see subclause 7.6.1.

8.4.7 MAP_SEND_HANDOVER_REPORT service

8.4.7.1 Definition

This service is used between VLR and MSC-B (B-interface) to transfer the handover number to be forwarded to and used by MSC-A.

The MAP_SEND_HANDOVER_REPORT service is a confirmed service using the primitives from table 8.4/7.

8.4.7.2 Service primitives

Table 8.4/7: MAP_SEND_HANDOVER_REPORT

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
Handover Number	M	M(=)		Linked Id
M	M(=)	O	Provider error	

8.4.7.3 Parameter use

Invoke Id

For definition of this parameter see subclause 7.6.1.

Handover Number

For definition of this parameter see subclause 7.6.2.

Linked Id

For definition of this parameter see subclause 7.6.1. This service is linked with MAP_ALLOCATE_HANDOVER_NUMBER.

Provider error

For definition of this parameter see subclause 7.6.1.

8.5 Authentication management services

8.5.1 MAP_AUTHENTICATE service

8.5.1.1 Definition

This service is used between the VLR and the MSC when the VLR receives a MAP service indication from the MSC concerning a location registration, call set-up, operation on a supplementary service or a request from the MSC to initiate authentication.

The service is a confirmed service and consists of four service primitives.

8.5.1.2 Service primitives

The service primitives are shown in table 8.5/1

Table 8.5/1: MAP_AUTHENTICATE parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
RAND	M	M(=)		
CKSN	M	M(=)		
SRES			M	M(=) O
Provider error				

8.5.1.3 Parameter use

Invoke id

See subclause 7.6.1 for the use of this parameter.

RAND

See subclause 7.6.7 for the use of this parameter.

CKSN

See subclause 7.6.7 for the use of this parameter.

SRES

See subclause 7.6.7 for the use of this parameter.

Provider error

See subclause 7.6.1 for the use of this parameter.

8.5.2 MAP_SEND_AUTHENTICATION_INFO service

8.5.2.1 Definition

This service is used between the VLR and the HLR for the VLR to retrieve authentication information from the HLR. The VLR requests some sets of RAND/SRES/Kc vectors.

Also this service is used between the SGSN and the HLR for the SGSN to retrieve authentication information from the HLR. The SGSN requests some sets of RAND/SRES/Kc vectors.

If the HLR cannot provide the VLR or the SGSN with triplets, an empty response is returned. The VLR or the SGSN may then re-use old authentication triplets, except where this is forbidden under the conditions specified in GSM 03.20 [24].

If the VLR or SGSN receives a MAP-Send_AUTHENTICATION_INFO response containing a User Error parameter as part of the handling of an authentication procedure, the authentication procedure in the VLR or SGSN shall fail.

Security related network functions are further described in GSM 03.20.

The service is a confirmed service and consists of four service primitives.

8.5.2.2 Service primitives

The service primitives are shown in table 8.5/2.

Table 8.5/2: MAP_SEND_AUTHENTICATION_PARAMETERS parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)	C	C(=)
AuthenticationSetList			C	C(=)
User error				O
Provider error				

8.5.2.3 Parameter use

Invoke id

See subclause 7.6.1 for the use of this parameter.

IMSI

See subclause 7.6.2 for the use of this parameter.

AuthenticationSetList

A set of one to five authentication vectors are transferred from the HLR to the VLR or from the HLR to the SGSN, if the outcome of the service was successful.

User error

One of the following error causes defined in subclause 7.6.1 shall be sent by the user in case of unsuccessful outcome of the service, depending on the respective failure reason:

- unknown subscriber;
- unexpected data value;
- system failure;

- data missing.

Provider error

See subclause 7.6.1 for the use of this parameter.

8.6 Security management services

8.6.1 MAP_SET_CIPHERING_MODE service

8.6.1.1 Definitions

This service is used between the VLR and the MSC to set the ciphering mode and to start ciphering if applicable. It is called when another service requires that information is to be sent on the radio path in encrypted form.

The service is a non-confirmed service and consists of two service primitives.

8.6.1.2 Service primitives

The service primitives are shown in table 8.6/1

Table 8.6/1: MAP_SET_CIPHERING_MODE parameters

Parameter name	Request	Indication
Invoke id	M	M(=)
Ciphering mode	M	M(=)
Kc	C	C(=)

8.6.1.3 Parameter use

Invoke id

See subclause 7.6.1 for the use of this parameter.

Ciphering mode

See subclause 7.6.7 for the use of this parameter.

Kc

The Kc parameter should be included when the ciphering mode parameter indicates that ciphering must be performed.

8.7 International mobile equipment identities management services

8.7.1 MAP_CHECK_IMEI service

8.7.1.1 Definition

This service is used between the VLR and the MSC and between the MSC and the EIR and between the SGSN and EIR to request check of IMEI. If the IMEI is not available in the MSC or in the SGSN, it is requested from the MS and transferred to the EIR in the service request.

The service is a confirmed service and consists of four service primitives.

8.7.1.2 Service primitives

The service primitives are shown in table 8.7/1.

Table 8.7/1: MAP_CHECK_IMEI parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMEI	C	C(=)	C	C(=)
Equipment status			C	C(=)
User error			C	C(=)
Provider error			O	

8.7.1.3 Parameter use

Invoke id

See subclause 7.6.1 for the use of this parameter.

IMEI

See subclause 7.6.2 for the use of this parameter. The parameter shall not be included in the service request between the VLR and the MSC, but is mandatory in the service request from the MSC to the EIR and from the SGSN to the EIR. It is not included in the service response from the EIR to the MSC or to the SGSN, but is mandatory in the service response from the MSC to the VLR on successful outcome.

Equipment status

See subclause 7.6.4 for the use of this parameter. This parameter is sent by the responder in case of successful outcome of the service.

User error

One of the following error causes defined in subclause 7.6.1 shall be sent by the user in case of unsuccessful outcome of the service, depending on the respective failure reason:

- unknown equipment;

This error is returned by the responder when the IMEI is not known in the EIR.

- system failure;
- unexpected data value.

Provider error

See subclause 7.6.1 for the use of this parameter.

8.7.2 MAP_OBTAIN_IMEI service

8.7.2.1 Definition

This service is used between the VLR and the MSC to request the IMEI. If the IMEI is not available in the MSC, it is requested from the MS.

The service is a confirmed service and consists of four service primitives.

8.7.2.2 Service primitives

The service primitives are shown in table 8.7/2.

Table 8.7/2: MAP_OBTAIN_IMEI parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMEI			C	C(=)
User error			C	C(=)
Provider error			O	

8.7.2.3 Parameter use

Invoke id

See subclause 7.6.1 for the use of this parameter.

IMEI

See subclause 7.6.2 for the use of this parameter. The parameter IS included in the service response from the MSC to the VLR on successful outcome of the service.

User error

If the service fails, the VLR sends the user error System Failure (see subclause 7.6.1) to the MSC.

Provider error

See subclause 7.6.1 for the use of this parameter.

8.8 Subscriber management services

8.8.1 MAP-INSERT-SUBSCRIBER-DATA service

8.8.1.1 Definition

This service is used by an HLR to update a VLR with certain subscriber data in the following occasions:

- the operator has changed the subscription of one or more supplementary services, basic services or data of a subscriber. Note that in case of withdrawal of a Basic or Supplementary service this primitive shall not be used;
- the operator has applied, changed or removed Operator Determined Barring;
- the subscriber has changed data concerning one or more supplementary services by using a subscriber procedure;
- the HLR provides the VLR with subscriber parameters at location updating of a subscriber or at restoration. In this case, this service is used to indicate explicitly that a supplementary service is not provisioned, if the supplementary service specification requires it. The only supplementary services which have this requirement are the CLIR and COLR services. Network access mode is provided only in restoration.

Also this service is used by an HLR to update a SGSN with certain subscriber data in the following occasions:

- if the GPRS subscription has changed;
- if the network access mode is changed;
- the operator has applied, changed or removed Operator Determined Barring;
- the HLR provides the SGSN with subscriber parameters at GPRS location updating of a subscriber.

It is a confirmed service and consists of the primitives shown in table 6.8/1.

8.8.1.2 Service primitives

Table 8.8/1: MAP-INSERT-SUBSCRIBER-DATA

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)		
IMSI	C	C(=)		
MSISDN	C	C(=)		
Category	C	C(=)		
Subscriber Status	C	C(=)		
Bearer service List	C	C(=)	C	C(=)
Teleservice List	C	C(=)	C	C(=)
Forwarding information List	C	C(=)		
Call barring information List	C	C(=)		
CUG information List	C	C(=)		
SS-Data List	C	C(=)		
eMLPP Subscription Data	C	C(=)		
Operator Determined Barring General data	C	C(=)	C	C(=)
Operator Determined Barring HPLMN data	C	C(=)		
Roaming Restriction Due To Unsupported Feature	C	C(=)		
Regional Subscription Data	C	C(=)		
VLR CAMEL Subscription Info	C	C(=)		
Voice Broadcast Data	C	C(=)		
Voice Group Call Data	C	C(=)		
Network access mode	C	C(=)		
GPRS Subscription Data	C	C(=)		
Roaming Restricted In SGSN Due To Unsupported Feature	C	C(=)		
North American Equal Access preferred Carrier Id List	U	C(=)		
LSA Information	C	C(=)		
SS-Code List			C	C(=)
LMU Identifier	C	C(=)		
LCS Information	C	C(=)		
Regional Subscription Response			C	C(=)
Supported CAMEL Phases			C	C(=)
User error			U	C(=)
Provider error				O

8.8.1.3 Parameter use

Network access mode

This parameter defines if the subscriber has access to MSC/VLR and/or to SGSN. This parameter is used by SGSN and MSC/VLR. In VLR, the parameter is used only as part of Restore Data Procedure and the parameter is not stored in the VLR. This parameter shall always be sent to the SGSN as part of the subscriber data at GPRS location updating. It shall be sent to the SGSN or VLR as appropriate if it is to be changed as a result of administrative action.

All parameters are described in subclause 7.6. The following clarifications are applicable:

IMSI

It is only included if the service is not used in an ongoing transaction (e.g. location updating). This parameter is used by the VLR and the SGSN.

MSISDN

It is included either at location updating or when it is changed. The MSISDN sent shall be the basic MSISDN. This parameter is used by the VLR and the SGSN.

Category

It is included either at location updating or when it is changed. This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

Subscriber Status

It is included either at location updating or when it is changed.

To apply, remove or update Operator Determined Barring Categories the Subscriber Status is set to Operator Determined Barring. In this case ODB General Data shall also be present. If the Operator Determined Barring applies and the subscriber is registered in the HPLMN and HPLMN specific Operator Determined Barring applies then ODB HPLMN Specific Data shall also be present.

To remove all Operator Determined Barring Categories the Subscriber Status shall be set to "Service Granted". This parameter is used by the VLR and the SGSN.

Bearer service List

A list of Extensible Bearer service parameters (Extensible Bearer service is defined in subclause 7.6). An Extensible Bearer service parameter must be the code for an individual Bearer service, except in the cases described below.

The codes for the Bearer service groups "allAlternateSpeech-DataCDA" and "allAlternateSpeech-DataCDS" shall, if applicable, be sent from the HLR to the VLR as a pair. The codes for the Bearer service groups "allSpeechFollowedByDataCDA" and "allSpeechFollowedByDataCDS" shall, if applicable, be sent from the HLR to the VLR as a pair.

If it is included in the Request/Indication, it includes either all Extensible Bearer services subscribed (at location updating or at restoration) or only the ones added (at subscriber data modification).

If the VLR receives an Indication containing any Extensible Bearer service parameters which it does not support/allocate it returns them in the response to the HLR and discards the unsupported Extensible Bearer services (no error is sent back), except in the cases described below.

If the VLR receives the codes for the Bearer service groups "allSpeechFollowedByDataCDA" and "allSpeechFollowedByDataCDS" and supports one or more of the circuit-switched synchronous or asynchronous data rates specified for simple data bearer services, it shall accept the bearer service codes, and not return them in the response to the HLR. If the VLR does not support any of the circuit-switched synchronous or asynchronous data rates specified for simple data bearer services, and receives the pair of codes for "allAlternateSpeech-DataCDA" and "allAlternateSpeech-DataCDS" or the pair of codes for "allSpeechFollowedByDataCDA" and "allSpeechFollowedByDataCDS", it shall reject the pair of codes by returning them in the response to the HLR. This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

Teleservice List

A list of Extensible Teleservice parameters (Extensible Teleservice is defined in subclause 7.6). An Extensible Teleservice parameter must be the code for an individual Teleservice.

If it is included in the Request/Indication, it contains either all Extensible Teleservices subscribed (at location updating or at restoration) or the ones added (at subscriber data modification). Only the Extensible Teleservices that are relevant to the node at which the message is received should be included in the Teleservice List.

If the VLR or the SGSN receives an Indication containing any Extensible Teleservice parameters which it does not support/allocate it returns them in the response to the HLR and discards the unsupported Extensible Teleservices (no error is sent back). This parameter is used by the VLR and the SGSN.

Forwarding information List

A list of Extensible Forwarding information parameters (Extensible Forwarding information is defined in subclause 7.6). It includes Call Forwarding services either at location updating or at restoration or when they are changed. Each Extensible Forwarding information parameter shall be treated independently of all other parameters in the primitive.

The Extensible Forwarding information shall include the SS-Code for an individual call forwarding supplementary service. The Extensible Forwarding information shall contain one or more Extensible Forwarding Features (Extensible Forwarding Feature is defined in subclause 7.6).

The Extensible Forwarding Feature may include an Extensible Basic Service Group. This shall be interpreted according to the rules in subclause 8.8.1.4.

The Extensible Forwarding Feature shall contain an Extensible SS-Status parameter.

If the Extensible SS-Status indicates that call forwarding is registered then (except for call forwarding unconditional) the Extensible Forwarding Feature shall contain a forwarded-to number and, if available, the forwarded-to subaddress. In other states the forwarded-to number and, if applicable, the forwarded-to subaddress shall not be included. For call forwarding unconditional the forwarded-to number and, if applicable, the forwarded-to subaddress shall not be included. If the VLR does not receive a forwarded-to subaddress then it shall assume that a forwarded-to subaddress has not been registered.

The Extensible Forwarding Feature shall contain the extensible forwarding options (except for call forwarding unconditional where the extensible forwarding options shall not be included). Bits 3 and 4 of the extensible forwarding options shall be ignored by the VLR, and may be set to any value by the HLR.

For call forwarding on no reply: If the extensible SS-Status indicates that call forwarding is registered then the Extensible Forwarding Feature shall contain an extensible no reply condition timer. In other states the no reply condition timer shall not be included.

For call forwarding services other than call forwarding on no reply: The Extensible Forwarding Feature shall not contain a no reply condition timer.

If the VLR receives an Indication containing any Call Forwarding service codes which it does not support/allocate it returns them to the HLR in the parameter SS-Code List and discards the unsupported Call Forwarding service codes (no error is sent back). This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

Call barring information List

A list of Extensible Call barring information parameters (Extensible Call barring information is defined in subclause 7.6). It includes Call Barring services either at location updating or at restoration or when they are changed. Each Extensible Call barring information parameter shall be treated independently of all other parameters in the primitive.

The Extensible Call barring information shall include the SS-Code for an individual call barring supplementary service. The Extensible Call barring information shall contain one or more Extensible Call Barring Features (Extensible Call Barring Feature is defined in subclause 7.6).

The Extensible Call Barring Feature may include an Extensible Basic Service Group. This shall be interpreted according to the rules in subclause 8.8.1.4.

The Extensible Call Barring Feature shall contain an extensible SS-Status parameter.

If the VLR receives an Indication containing any Extensible Call Barring service codes which it does not support/allocate it returns them to the HLR in the parameter SS-Code List and discards the unsupported Extensible Call Barring service codes (no error is sent back). This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

CUG information List

A list of CUG information list parameters (CUG information is defined in subclause 7.6). It includes CUG information either at location updating or at restoration or when it is changed.

At location updating, restoration or when there is a change in CUG data, the HLR shall include the complete CUG-SubscriptionList and, if there are options per basic group, it shall also include the complete CUG-FeatureList. If there are not options per extensible basic service group the CUG-FeatureList shall not be included.

In any dialogue, the first insertSubscriberData message which contains CUG information shall include a non-empty CUG-SubscriptionList.

When the VLR receives CUG data it shall replace the stored CUG data with the received data set.

If CUG-FeatureList is omitted in the Insert Subscriber Data operation VLR shall interpret that no options per extensible basic service group exist, and then it shall apply the default values i.e. no outgoing access, no incoming access, no preferential CUG exists.

If CUG-Feature is received without preferential CUG, the VLR shall interpret that no preferential CUG applies.

If the VLR detects that there is overlapping in the information received within a dialogue, it shall send the error Unexpected Data Value.

Note that data consistency between CUG subscription data and CUG feature data is the responsibility of the HLR.

If the VLR does not support the CUG service it returns its code to the HLR in the parameter SS-Code List and discards the received information (no error is sent back). This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

SS-Data List

A list of Extensible SS-Data parameters (Extensible SS-Data is defined in subclause 7.6). It is sent for any other supplementary service than Call Forwarding, Call Barring, CUG and eMLPP either at location updating or at restoration or when they are changed. Each SS-Data parameter shall be treated independently of all other parameters in the primitive.

The Extensible SS-Data shall include the SS-Code for an individual supplementary service.

The Extensible SS-Data shall contain an Extensible SS-Status parameter and any subscription options that are applicable to the service defined by the SS-Code.

The SS-Data may include a Basic Service Group List. This shall be interpreted according to the rules in subclause 8.8.1.4.

If the VLR receives an Indication containing any supplementary service codes which it does not support/allocate it returns them to the HLR in the parameter SS-Code List and therefore discards the unsupported service codes received (no error is sent back). This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

Operator Determined Barring General data

If it is included in a Request/Indication, it includes all the Operator Determined Barring categories that may be applied to a subscriber registered in any PLMN. This parameter is only included in a Request/Indication when the parameter Subscriber Status is set to the value Operator Determined Barring. Note that all General Operator Determined Barring Categories shall be set to their actual status.

If the VLR or the SGSN receives an Indication containing Operator Determined Barring General Data which shows that the subscriber is subject to barring not supported / not allocated by the VLR or by the SGSN, it returns Operator Determined Barring General Data in the response to the HLR to show the barring categories which are not supported / not allocated by the VLR or by the SGSN. This parameter is used by the VLR and the SGSN.

Operator Determined Barring HPLMN data

It includes all the Operator Determined Barring categories that may be applied only to a subscriber registered in the HPLMN. Therefore, it shall only be transferred to the VLR or to the SGSN when the subscriber is roaming into the HPLMN and when the parameter Subscriber Status is set to the value Operator Determined Barring. Note that all HPLMN Operator Determined Barring Categories shall be set to their actual status.

If Subscriber Status is set to the value Operator Determined Barring and no Operator Determined Barring HPLMN data is present then the VLR or the SGSN shall not apply any HPLMN specific ODB services to the subscriber. This parameter is used by the VLR and the SGSN.

eMLPP Subscription Data

If included in the Insert Subscriber Data request this parameter defines the priorities the subscriber might apply for a call (as defined in subclause 7.6). It contains both subparameters of eMLPP.

If the VLR does not support the eMLPP service it returns its code to the HLR in the parameter SS-Code List and therefore discards the received information (no error is sent back).

eMLPP subscription data that have been stored previously in a subscriber data record in the VLR are completely replaced by the new eMLPP subscription data received in a MAP_INSERT_SUBSCRIBER_DATA during either an Update Location or Restore Data procedure or a stand alone Insert Subscriber data procedure. This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

Roaming Restriction Due To Unsupported Feature

The HLR may decide to include this parameter in the request if certain services or features are indicated as not supported by the MSC/VLR (e.g. Advice of Charge Charging Level).

If this parameter is sent to the VLR the MSC area is restricted by the HLR and the VLR. This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

Regional Subscription Data

If included in the Insert Subscriber Data request this parameter defines the subscriber's subscription area for the addressed VLR or for the addressed SGSN (as defined in subclause 7.6). It contains the complete list of up to 10 Zone Codes that apply to a subscriber in the currently visited PLMN. The HLR shall send only those Zone Codes which are stored against the CC and NDC of the VLR or the CC and NDC of the SGSN to be updated.

NOTE: Support of this parameter is a network operator option and it will not be sent to networks which do not support Regional Subscription.

Regional subscription data that have been stored previously in a subscriber data record in the VLR or in the SGSN are completely replaced by the regional subscription data received in an Insert Subscriber Data indication during either an Update Location or Restore Data procedure or a stand alone Insert Subscriber data procedure.

After the regional subscription data are inserted the VLR or the SGSN shall derive whether its location areas are allowed or not. If the whole MSC or SGSN area is restricted it will be reported to HLR by returning the Regional Subscription Response.

The VLR or the SGSN returns a Regional Subscription Response indicating that a problem with the Zone Code has been detected in one of the following cases:

- Too Many Zone Codes: more than 10 Zone Codes are to be stored in the VLR or in the SGSN;
- Regional Subscription Not Supported by the VLR or the SGSN;
- Zone Codes Conflict: the VLR or the SGSN detects that the zone codes indicate conflicting service permission for a location area.

Zone codes which have no mapping to location areas shall be ignored.

If a sequence of MAP_INSERT_SUBSCRIBER_DATA services is used during a dialogue, Regional Subscription Data shall be accepted only in one service. Regional Subscription Data received in a subsequent service shall be rejected with the error Unexpected Data Value.

If Regional Subscription Data are not included in any MAP_INSERT_SUBSCRIBER_DATA service, there is no restriction of roaming due to Regional Subscription. This parameter is used by the VLR and the SGSN.

Voice Broadcast Data

This parameter contains a list of group id's a user might have subscribed to; (VBS-Data is defined in subclause 7.6). It includes VBS information either at location updating or at restoration or when it is changed.

At location updating, restoration or when there is a change in VBS data, the HLR shall include the complete VBS-Data.

When the VLR receives VBS-Data within a dialogue it shall replace the stored VBS-data with the received data set. All subsequent VBS-data received within this dialogue shall be interpreted as add-on data.

If VBS-data is omitted in the Insert Subscriber Data operation the VLR shall keep the previously stored VBS data.

If the VLR detects that there is overlapping in the information received within a dialogue, it shall send the error Unexpected Data Value. . This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

Voice Group Call Data

This parameter contains a list of group id's a user might have subscribed to; see subclause 7.6.

At location updating, restoration or when there is a change in VGCS data, the HLR shall include the complete VGCS-Data.

When the VLR receives VGCS-Data within a dialogue it shall replace the stored VGCS-Data with the received data set. All VGCS-Data received within this dialogue shall be interpreted as add-on data.

If VGCS-Data is omitted in the Insert Subsciber Data operation the VLR shall keep the previously stored VGCS-Data.

If the VLR detects that there is overlapping in the information received within a dialogue, it shall send the error Unexpected Data Value. This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

North American Equal Access preferred Carrier Id List

A list of the preferred carrier identity codes that are subscribed to.

When the VLR receives this parameter from the HLR, it shall replace the previously stored preferred carrier identity codes with the received ones. It is not possible to delete all the preferred carrier identity codes from the VLR using this service. To delete all the preferred carrier identity codes from the VLR, the HLR shall use the MAP_CANCEL_LOCATION service.

LSA Information

If included in the ISD request, this parameter contains a list of localised service area identities a user might have subscribed to together with the priority, the preferential access indicator, the active mode support indicator and active mode indication of each localised service area; see subclause 7.6. The access right outside these localised service areas is also indicated. In all cases mentioned below, the LSA information shall only include LSA Data applicable to the VPLMN where the Subscriber is located. The VLR number, received in the MAP-UPDATE_LOCATION primitive, or the SGSN number, received in the MAP_UPDATE_GPRS_LOCATION primitive, can be used, alongside data stored in the HLR, to determine the LSA Data applicable to the VPLMN.

At restoration, location updating or GPRS location updating the HLR shall include the complete set of applicable LSA Information.

When there is a change in LSA data the HLR shall include at least the new and/or modified LSA data.

When there is a change in the access right outside the localised service areas the HLR shall include the LSA only access indicator.

When the SGSN or the VLR receives LSA information within a dialogue it shall check if the received data has to be considered as the entire LSA information. If so, it shall replace the stored LSA information with the received data set, otherwise it shall replace the data only for the modified LSA data (if any) and/or access right, and add the new LSA data (if any) to the stored LSA Information.

If the entire LSA information is received, it shall always include the LSA only access indicator value together with the LSA data applicable for the PLMN (if any).

If LSA Information is omitted in the Insert Subscriber Data operation the SGSN or the VLR shall keep the previously stored LSA Information.

If the SGSN or the VLR detects that there is overlapping in the information received within a dialogue, it shall send the error Unexpected Data Value. This parameter is used by the VLR and the SGSN.

LMU Identifier

This parameter indicates the presence of an LMU. This parameter is used only by the VLR and shall be ignored if received by an SGSN.

LCS Information

This parameter provides the following LCS related information for an MS subscriber:

- list of GMLCs in the HPLMN
- privacy exception list
- MO-LR list

At restoration and location updating, the HLR shall include the complete LCS data of the subscriber.

When there is a change in LCS subscriber data the HLR shall include at least the new and/or modified LCS data. LCS data that is not modified need not be included.

The VLR shall keep any previously stored LCS Information that is not included in an Insert Subscriber Data operation.

If the VLR detects that there is overlapping in the LCS information received within a dialogue, it shall send the error Unexpected Data Value.

This parameter is used only by the VLR and shall be ignored if received by an SGSN.

SS-Code List

The list of SS-Code parameters that are provided to a subscriber but are not supported/allocated by the VLR (SS-Code is defined in subclause 7.6). The list can only include individual SS-Codes that were sent in the service request. This parameter is used only by the VLR.

Regional Subscription Response

If included in the response this parameter indicates one of:

- MSC Area Restricted entirely because of regional subscription;
- SGSN Area Restricted entirely because of regional subscription;
- Too Many Zone Codes to be inserted;
- Zone Codes Conflict;
- Regional Subscription not Supported by the VLR or by the SGSN.

If the VLR determines after insertion of Regional Subscription Data that the entire MSC area is restricted, the VLR shall respond with a Regional Subscription Response indicating MSC Area Restricted. Otherwise MSC Area Restricted is not sent. The HLR shall check whether the current MSC area is no longer restricted.

If the SGSN determines after insertion of Regional Subscription Data that the entire SGSN area is restricted, the SGSN shall respond with a Regional Subscription Response indicating SGSN Area Restricted. Otherwise SGSN Area Restricted is not sent. The HLR shall check whether the current SGSN area is no longer restricted. This parameter is used by the VLR and by the SGSN.

VLR CAMEL Subscription Info

This parameter is sent for subscribers who have CAMEL services which are invoked in the MSC. In CAMEL phase 1 this parameter contains only the O-CSI. If an O-CSI is contained, TDP-Criteria may also be present in CAMEL Phase 2. In CAMEL Phase 2 this parameter contains the SS-CSI and/or the O-CSI. The VLR CAMEL Subscription Info is sent at location updating or when any information in the applicable CAMEL Subscription Info in the HLR has been changed. The entire set of CAMEL Subscription Info is sent within one dialogue. If a set of CAMEL Subscription Info is already stored in the VLR, i.e received within a previous dialogue, it is replaced by the received data. If the VLR CAMEL Subscription Info is omitted in the Insert Subscriber Data operation the VLR shall keep the previously stored VLR CAMEL Subscription Info. Within one dialogue subsequent received data are interpreted as add-on data. If the VLR detects that there is overlapping in the information received within a dialogue, it shall send the error Unexpected Data Value. This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

The VLR CAMEL Subscription Info may contain the TIF-CSI (Translation Information Flag). See GSM 03.72 for the use of this parameter and the conditions for its presence.

Supported CAMEL Phases

The use of this parameter and the requirements for its presence are specified in GSM 03.78. This parameter is used only by the VLR.

A VLR not supporting any CAMEL-Phase may omit this parameter.

GPRS Subscription Data

This parameter contains a list of PDP-contexts a user has subscribed to; see subclause 7.6.

At GPRS location updating the HLR shall include the complete GPRS Subscription Data.

When there is a change in GPRS subscriber data the HLR shall include only the new and/or modified PDP contexts.

When the SGSN receives GPRS Subscription Data within a dialogue it shall check if the received data has to be considered as the entire GPRS subscription data. If so, it shall replace the stored GPRS Subscription Data with the

received data set, otherwise it shall replace the data only for the modified PDP contexts (if any) and add the new PDP contexts (if any) to the stored GPRS Subscription Data.

If GPRS Subscription Data is omitted in the Insert Subscriber Data operation the SGSN shall keep the previously stored GPRS Subscription Data.

If the SGSN detects that there is overlapping in the information received within a dialogue, it shall send the error Unexpected Data Value. This parameter is used only by the SGSN and if the VLR receives this parameter it shall ignore it.

Roaming Restricted In SGSN Due To Unsupported Feature

The HLR may decide to include this parameter in the request if certain services or features are indicated as not supported by the SGSN. This parameter is used only by the SGSN and if the VLR receives this parameter it shall ignore it.

User error

Only one of the following values is applicable:

- Unidentified subscriber;
- Data missing;
- Unexpected data value.

8.8.1.4 Basic service information related to supplementary services

A number of parameters that relate to supplementary services can be qualified by a Basic Service Group (or a Basic Service Group List). This subclause explains how this information is to be interpreted. Supplementary service parameters to which this subclause is applicable only apply to the basic service groups described in this subclause, and only those basic service groups shall be overwritten at the VLR.

The Basic Service Group (or Basic Service Group List) is optional.

If present the Basic Service Group (or the elements of the Basic Service Group List) shall be one of:

- an Elementary Basic Service Group for which the supplementary service is applicable to at least one basic service in the group; and to which the subscriber has a subscription to at least one basic service in the group;
- the group "All Teleservices" provided that the service is applicable to at least one teleservice and that the subscriber has a subscription to at least one teleservice that is in the same Elementary Basic Service Group as a teleservice to which the service is applicable;
- the group "All Bearer Services" provided that the service is applicable to at least one bearer service and that the subscriber has a subscription to at least one bearer service that is in the same Elementary Basic Service Group as a basic service to which the service is applicable.

If the Basic Service Group (or Basic Service Group List) is not present then the parameter shall apply to all Basic Service Groups.

If the basic service information is not a single Elementary Basic Service Group then the parameter shall be taken as applying individually to all the Elementary Basic Service Groups for which:

- the supplementary service is applicable to at least one basic service in the Basic Service Group; and
- the subscriber has a subscription to at least one basic service in the Basic Service Group.

The VLR is not required to store supplementary services data for Basic Service Groups that are not supported at the VLR.

8.8.2 MAP-DELETE-SUBSCRIBER-DATA service

8.8.2.1 Definition

This service is used by an HLR to remove certain subscriber data from a VLR if the subscription of one or more supplementary services or basic services is withdrawn. Note that this service is not used in case of erasure or deactivation of supplementary services.

Also this service is used by an HLR to remove GPRS subscription data from a SGSN.

It is a confirmed service and consists of the primitives shown in table 8.8/2.

8.8.2.2 Service primitives

Table 8.8/2: MAP-DELETE-SUBSCRIBER-DATA

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
Basic service List	C	C(=)		
SS-Code List	C	C(=)		
Roaming Restriction Due To Unsupported Feature	C	C(=)		
Camel Subscription Info Withdraw	C	C(=)		
Regional Subscription Data	C	C(=)		
VBS Group Indication	C	C(=)		
VGCS Group Indication	C	C(=)		
GPRS Subscription Data Withdraw	C	C(=)		
Roaming Restricted In SGSN Due To Unsupported Feature	C	C(=)		
LSA Information Withdraw	C	C(=)	C	C(=)
Regional Subscription Response	C	C(=)	C	C(=)
GMLC List Withdraw				O
User error				
Provider error				

8.8.2.3 Parameter use

All parameters are described in subclause 7.6. The following clarifications are applicable:

Basic service List

A list of Extensible Basic service parameters (Extensible Basic service is defined in subclause 7.6). It is used when one, several or all basic services are to be withdrawn from the subscriber. If the VLR or the SGSN receives a value for an Extensible Basic Service which it does not support, it shall ignore that value. This parameter is used by the VLR and by the SGSN.

SS-Code List

A list of SS-Code parameters (SS-Code is defined in subclause 7.6). It is used when several or all supplementary services are to be withdrawn from the subscriber.

There are three possible options:

- deletion of basic service(s);

The parameter Basic service List is only included.

- deletion of supplementary service(s);

The parameter SS-Code List is only included.

- deletion of basic and supplementary services;

Both Basic service List and SS-Code List are included.

This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

Roaming Restriction Due To Unsupported Feature

This parameter is used if Roaming Restriction Due To Unsupported Feature is deleted from the subscriber data. This may occur if unsupported features or services are removed from the subscriber data in the HLR.

If this parameter is sent the VLR shall check if the current Location Area is possibly allowed now. This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

CAMEL Subscription Info Withdraw

This parameter is used to indicate that CAMEL Subscription Info shall be deleted from the VLR. All CAMEL Subscription Info for the subscriber shall be deleted. This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

Regional Subscription Identifier

Contains one single Zone Code (as defined subclause 7.6) and is used if all Zone Codes shall be deleted from the subscriber data. When all the Zone Codes are deleted, the VLR or the SGSN shall check for its location areas whether they are allowed or not. If the whole MSC area is restricted, VLR will report it to HLR by returning the Regional Subscription Response "MSC Area Restricted". If the whole SGSN area is restricted, SGSN will report it to HLR by returning the Regional Subscription Response "SGSN Area Restricted".

The binary coding of the Zone Code value received in a Delete Subscriber Data request shall not be checked by the VLR or by the SGSN.

Note that support of this parameter is a network operator option and it shall not be sent to networks which do not support Regional Subscription.

If Regional Subscription is not supported by the VLR or by the SGSN, the request for deletion of Zone Codes is refused by sending the Regional Subscription Response "Regional Subscription Not Supported" to the HLR.

If no Zone Codes are stored in the respective subscriber data record, the request for deleting all Zone Code information shall be ignored and no Regional Subscription Response shall be returned. This parameter is used by the VLR and by the SGSN.

VBS Group Indication

Contains an indication (flag) which is used if all Group Id's shall be deleted from the subscriber data for the Voice Broadcast teleservice.

If VBS is not supported in the VLR or no Group Ids are stored for VBS in the respective subscriber record, the request for deletion of all Group Ids shall be ignored. This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

VGCS Group Indication

Contains an indication (flag) which is used if all Group Id's shall be deleted from the subscriber data for the Voice Group Call teleservice. This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

If VGCS is not supported in the VLR or no Group Ids are stored for VGCS in the respective subscriber record, the request for deletion of all Group Ids shall be ignored.

GPRS Subscription Data Withdraw

This parameter is used to indicate whether all GPRS Subscription Data for the subscriber shall be deleted or if only a subset of the stored GPRS Subscription Data for the subscriber shall be deleted. In the latter case only those PDP context whose identifiers are included in the subsequent identifier list will be deleted. This parameter is used only by the SGSN and if the VLR receives this parameter it shall ignore it.

Roaming Restricted In SGSN Due To Unsupported Feature

This parameter is used if Roaming Restricted In SGSN Due To Unsupported Feature is deleted from the GPRS subscriber data. This may occur if unsupported features or services are removed from the GPRS subscriber data in the HLR.

If this parameter is sent the SGSN shall check if the current Location Area is possibly allowed now. This parameter is used only by the SGSN and if the VLR receives this parameter it shall ignore it.

LSA Information Withdraw

This parameter is used to indicate whether all LSA Information for the subscriber shall be deleted or if only a subset of the stored LSA Information for the subscriber shall be deleted. In the latter case only the LSA data whose LSA identities are included in the subsequent LSA data list will be deleted. This parameter is used by the VLR and the SGSN.

Regional Subscription Response

If included in the Delete Subscriber Data response this parameter indicates one of:

- MSC Area Restricted
- SGSN Area Restricted;
- Regional Subscription Not Supported.

This parameter is used by the VLR and by the SGSN.

GMLC List Withdraw

This parameter indicates that the subscriber's LCS GMLC List shall be deleted from the VLR.

This parameter is used only by the VLR and shall be ignored if received by an SGSN.

User error

Only one of the following values is applicable:

- Unidentified subscriber;
- Data missing;
- Unexpected data value.

8.9 Identity management services

8.9.1 MAP-PROVIDE-IMSI service

8.9.1.1 Definition

This service is used by a VLR in order to get, via the MSC, the IMSI of a subscriber (e.g. when a subscriber has identified itself with a TMSI not allocated to any subscriber in the VLR).

It is a confirmed service and consists of the primitives shown in table 8.9/1.

8.9.1.2 Service primitives

Table 8.9/1: MAP-PROVIDE-IMSI

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI			C	C(=)
User error			C	C(=)
Provider error			O	O

8.9.1.3 Parameter use

All parameters are described in subclause 7.6. The following clarifications are applicable:

IMSI

This parameter is received when the request is successfully carried out. It contains the requested IMSI.

User error

Only one of the following values is applicable:

- Absent subscriber.

8.9.2 MAP-FORWARD-NEW-TMSI service

8.9.2.1 Definition

This service is used by a VLR to allocate, via MSC, a new TMSI to a subscriber during an ongoing transaction (e.g. call set-up, location updating or supplementary services operation).

It is a confirmed service and consists of the primitives shown in table 8.9/2.

8.9.2.2 Service primitives

Table 8.9/2: MAP-FORWARD-NEW-TMSI

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
TMSI	M	M(=) O	Provider error	

8.9.2.3 Parameter use

The parameter TMSI is described in subclause 7.6.

8.10 Fault recovery services

8.10.1 MAP_RESET service

8.10.1.1 Definition

This service is used by the HLR, after a restart, to indicate to a list of VLRs or SGSNs that a failure occurred.

The MAP_RESET service is a non-confirmed service using the service primitives defined in table 8.10/1

8.10.1.2 Service primitives

Table 8.10/1: MAP_RESET

Parameter name	Request	Indication
Invoke Id	M	M(=)
HLR number	M	M(=)
HLR Id LIST	U	C(=)

8.10.1.3 Parameter definition and use

Invoke Id

See definition in subclause 7.6.1.

HLR number

See definition in subclause 7.6.2.

HLR Id LIST

The HLR Id List is a list of HLR Id. If the parameter is present in the indication, the VLR or SGSN may base the retrieval of subscribers to be restored on their IMSI: the subscribers affected by the reset are those whose IMSI leading digits are equal to one of these numbers. If the parameter is absent, subscribers to be restored are those for which the OriginatingEntityNumber received at location updating time matches the equivalent parameter of the Reset Indication.

8.10.2 MAP_FORWARD_CHECK_SS_INDICATION service

8.10.2.1 Definition

This service may be used by an HLR as an implementation option, to indicate to a mobile subscriber that supplementary services parameters may have been altered, e.g. due to a restart. If received from the HLR, the VLR shall forward this indication to the MSC, which in turn forwards it to the MS. The HLR only sends this indication after successful completion of the subscriber data retrieval from HLR to VLR that ran embedded in a MAP_UPDATE_LOCATION procedure.

The MAP_FORWARD_CHECK_SS_INDICATION service is a non-confirmed service using the service primitives defined in table 8.10/2.

8.10.2.2 Service primitives

Table 8.10/2: MAP_FORWARD_CHECK_SS_INDICATION

Parameter name	Request	Indication
Invoke Id	M	M(=)

8.10.2.3 Parameter definition and use

Invoke Id

See definition in subclause 7.6.1.

8.10.3 MAP_RESTORE_DATA service

8.10.3.1 Definition

This service is invoked by the VLR on receipt of a MAP_PROVIDE_ROAMING_NUMBER indication for an unknown IMSI, or for a known IMSI with the indicator "Confirmed by HLR" set to "Not confirmed". The service is

used to update the LMSI in the HLR, if provided, and to request the HLR to send all data to the VLR that are to be stored in the subscriber's IMSI record.

The MAP_RESTORE_DATA service is a confirmed service using the service primitives defined in table 6.10/3.

8.10.3.2 Service primitives

Table 8.10/3: MAP_RESTORE_DATA

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
LMSI	U	C(=)		
Supported CAMEL phases	C	C(=)		
HLR number			C	C(=)
MS Not Reachable Flag			C	C(=)
User error			C	C(=)
Provider error				O

8.10.3.3 Parameter definitions and use

Invoke Id

See definition in subclause 5.6.1.

IMSI

See definition in subclause 5.6.2.

LMSI

See definition in subclause 5.6.2. It is an operator option to provide the LMSI from the VLR; it is mandatory for the HLR to support the LMSI handling procedures.

Supported CAMEL Phases

This parameter indicates which phases of CAMEL are supported. Must be present if a CAMEL phase different from phase 1 is supported. Otherwise may be absent.

HLR number

See definition in subclause 5.6.2. The presence of this parameter is mandatory in case of successful outcome of the service.

MS Not Reachable Flag

See definition in subclause 5.6.8. This parameter shall be present in case of successful outcome of the service, if the "MS Not Reachable flag" was set in the HLR.

User error

In case of unsuccessful outcome of the service, an error cause shall be returned by the HLR. The following error causes defined in subclause 5.6.1 may be used, depending on the nature of the fault:

- unknown subscriber;
- system failure;
- unexpected data value;
- data missing.

Provider error

For definition of provider errors see subclause 5.6.1.

8.11 Subscriber Information services

8.11.1 MAP-ANY-TIME-INTERROGATION service

8.11.1.1 Definition

This service is used by the gsmSCF, to request information (e.g. subscriber state and location) from the HLR at any time.

8.11.1.2 Service primitives

Table 8.11/1: Any_Time_Interrogation

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
Requested Info	M	M(=)		
gsmSCF-Address	M	M(=)		
IMSI	C	C(=)		
MSISDN	C	C(=)		
Location Information			C	C(=)
Subscriber State			C	C(=)
User error			C	C(=)
Provider error				O

8.11.1.3 Parameter definition and use

All parameters are described in subclause 7.6.

The HLR may be able to use the value of the parameter gsmSCF-address to screen an MAP_Any_Time_Interrogation indication.

The use of the parameters and the requirements for their presence are specified in GSM 03.78.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- System Failure;
- Any Time Interrogation Not Allowed;
- Data Missing;
- Unexpected Data Value;
- Unknown Subscriber.

Provider error

These are defined in subclause 7.6.1.

8.11.2 MAP-PROVIDE-SUBSCRIBER-Info service

8.11.2.1 Definition

This service is used to request information (e.g. subscriber state and location) from the VLR at any time.

8.11.2.2 Service primitives

Table 8.11/2: Provide_Subscriber_Information

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
Requested Info	M	M(=)		
IMSI	M	M(=)		
LMSI	U	O		
Location Information			C	C(=)
Subscriber State			C	C(=)
User error			C	C(=)
Provider error				O

8.11.2.3 Parameter definition and use

All parameters are defined in section 7.6. The use of these parameters and the requirements for their presence are specified in GSM 03.18

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Data Missing;
- Unexpected Data Value.

Provider error

These are defined in subclause 7.6.1.

9 Operation and maintenance services

9.1 Subscriber tracing services

9.1.1 MAP-ACTIVATE-TRACE-MODE service

9.1.1.1 Definition

This service is used between the HLR and the VLR to activate subscriber tracing in the VLR.

Also this service is used between the HLR and the SGSN to activate subscriber tracing in the SGSN.

The MAP-ACTIVATE-TRACE-MODE service is a confirmed service using the primitives from table 9.1/1.

9.1.1.2 Service primitives

Table 9.1/1: MAP-ACTIVATE-TRACE-MODE

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMSI	C	C(=)		
Trace reference	M	M(=)		
Trace type	M	M(=)		
OMC Id	U	C(=)		
User error			C	C(=)
Provider error				O

9.1.1.3 Parameter use

Invoke id

See definition in subclause 7.6.1.

IMSI

See definition in subclause 7.6.2. The IMSI is a mandatory parameter in a stand-alone operation.

Trace reference

See definition in subclause 7.6.10.

Trace type

See definition in subclause 7.6.10.

OMC Id

See definition in subclause 7.6.2. The use of this parameter is an operator option.

User error

The following errors defined in subclause 7.6.1 may be used, depending on the nature of the fault:

- Unidentified Subscriber;
- Facility Not Supported;
- Tracing Buffer Full;
- System Failure;
- Unexpected Data Value;
- Data missing.

Provider error

For definition of provider errors see subclause 7.6.1.

9.1.2 MAP-DEACTIVATE-TRACE-MODE service

9.1.2.1 Definition

This service is used between the VLR and the HLR for deactivating subscriber tracing in the VLR.

Also this service is used between the SGSN and the HLR for deactivating subscriber tracing in the SGSN.

The MAP-DEACTIVATE-TRACE-MODE service is a confirmed service using the primitives from table 9.1/2.

9.1.2.2 Service primitives

Table 9.1/2: MAP-DEACTIVATE-TRACE-MODE

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMSI	C	C(=)		
Trace reference	M	M(=)		
User error			C	C(=)
Provider error				O

9.1.2.3 Parameter use

Invoke id

See definition in subclause 7.6.1.

IMSI

See definition in subclause 7.6.2. The IMSI is a mandatory parameter in a stand-alone operation.

Trace reference

See definition in subclause 7.6.10.

User error

The following errors defined in subclause 7.6.1 may be used, depending on the nature of the fault:

- Unidentified Subscriber;
- Facility Not Supported;
- System Failure;
- Unexpected Data Value;
- Data missing.

Provider error

For definition of provider errors see subclause 7.6.1.

9.1.3 MAP-TRACE-SUBSCRIBER-ACTIVITY service

9.1.3.1 Definition

This service is used between the VLR and the MSC to activate the subscriber tracing in the MSC.

The MAP-TRACE-SUBSCRIBER-ACTIVITY service is a non-confirmed service using the primitives from table 9.1/3.

9.1.3.2 Service primitives

Table 9.1/3: MAP-TRACE-SUBSCRIBER-ACTIVITY

Parameter name	Request	Indication
Invoke id	M	M(=)
IMSI	C	C(=)
Trace reference	M	M(=)
Trace type	M	M(=)
OMC Id	U	C(=)

9.1.3.3 Parameter use

Invoke id

See definition in subclause 7.6.1.

IMSI

See definition in subclause 7.6.2. The controlling MSC shall provide either the IMSI or the IMEI to the servicing MSC.

Trace reference

See definition in subclause 7.6.10.

Trace type

See definition in subclause 7.6.10.

OMC Id

See definition in subclause 7.6.2. The use of this parameter is an operator option.

9.2 Other operation and maintenance services

9.2.1 MAP-SEND-IMSI service

9.2.1.1 Definition

This service is used by a VLR in order to fetch the IMSI of a subscriber in case of some Operation & Maintenance procedure where subscriber data are needed in the Visited PLMN and MSISDN is the only subscriber's identity known.

It is a confirmed service and consists of the primitive shown in figure 9.2/1.

9.2.1.2 Service primitives

Table 9.2/1: MAP-SEND-IMSI

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
MSISDN	M	M(=)		
IMSI			C	C(=)
User error			C	C(=)
Provider error				O

9.2.1.3 Parameter use

All parameters are described in subclause 7.6. The following clarifications are applicable:

User error

Only one of the following values is applicable:

- Unknown subscriber;
- Unexpected data value;
- Data missing.

10 Call handling services

10.1 MAP_SEND_ROUTING_INFORMATION service

10.1.1 Definition

This service is used between the Gateway MSC and the HLR. The service is invoked by the Gateway MSC to perform the interrogation of the HLR in order to route a call towards the called MS.

This is a confirmed service using the primitives listed in table 10.1/1.

This service is also used between the GMSC and the NPLR.

10.1.2 Service primitives

Table 10.1/1: MAP_SEND_ROUTING_INFORMATION parameters

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
Interrogation Type	M	M(=)		
GMSC Address	M	M(=)		
MSISDN	M	M(=)	C	C(=)
OR Interrogation	C	C(=)		
OR Capability	C	C(=)		
CUG Interlock	C	C(=)	C	C(=)
CUG Outgoing Access	C	C(=)	C	C(=)
Number of Forwarding	C	C(=)		
Network Signal Info	C	C(=)		
Supported CAMEL Phases	C	C(=)		
Suppress T-CSI	C	C(=)		
Suppression of Announcement	C	C(=)		
Call Reference Number	C	C(=)		
Forwarding Reason	C	C(=)		
Basic Service Group	C	C(=)		
Alerting Pattern	C	C(=)		
CCBS Call	C	C(=)		
Supported CCBS Phase	C	C(=)		
Additional Signal Info	C	C(=)		
IMSI			C	C(=)
MSRN			C	C(=)
Forwarding Data			C	C(=)
Forwarding Interrogation Required			C	C(=)
VMSC address			C	C(=)
GMSC Camel Subscription Info			C	C(=)
Location Information			C	C(=)
Subscriber State			C	C(=)
Basic Service Code			C	C(=)
CUG Subscription Flag			C	C(=)
North American Equal Access preferred			U	C(=)
Carrier Id				
User error			C	C(=)
SS-List			U	C(=)
CCBS Target			C	C(=)
Keep CCBS Call Indicator			C	C(=)
Number Portability Status			U	C(=)
Provider error				O

10.1.3 Parameter use

See subclause 7.6 for a definition of the parameters used in addition to the following. Note that:

- a conditional parameter whose use is defined only in GSM 03.78 shall be absent if the sending entity does not support CAMEL;
- a conditional parameter whose use is defined only in GSM 03.79 shall be absent if the sending entity does not support optimal routeing;
- a conditional parameter whose use is defined only in GSM 03.78 & GSM 03.79 shall be absent if the sending entity supports neither CAMEL nor optimal routeing.

Interrogation Type

See GSM 03.79 [99] for the use of this parameter.

GMSC address

The E.164 address of the GMSC.

MSISDN

This is the Mobile Subscriber ISDN number assigned to the called subscriber. In the Request & Indication it is the number received by the GMSC in the IAM. If the call is to be forwarded and the HLR supports determination of the redirecting number, the HLR inserts the basic MSISDN in the Response.

See GSM 03.66 [108] for the use of this parameter and the conditions for its presence in the response.

OR Interrogation

See GSM 03.79 [99] for the use of this parameter and the conditions for its presence.

OR Capability

See GSM 03.79 [99] for the use of this parameter and the conditions for its presence.

CUG Interlock

See GSM 03.18 [97] for the use of this parameter and the conditions for its presence.

CUG Outgoing Access

See GSM 03.18 [97] for the use of this parameter and the conditions for its presence.

Number of Forwarding

See GSM 03.18 [97] for the use of this parameter and the conditions for its presence.

Network Signal Info

See GSM 03.18 [97] for the conditions for the presence of the components of this parameter.

Supported CAMEL Phases

The use of this parameter and the requirements for its presence are specified in GSM 03.78

T-CSI Suppression

The use of this parameter and the requirements for its presence are specified in GSM 03.78

Suppression Of Announcement

The use of this parameter and the requirements for its presence are specified in GSM 03.78

Call Reference Number

The use of this parameter and the conditions for its presence are specified in GSM 03.78 [98] and GSM 03.79 [99].

Forwarding Reason

See GSM 03.79 [99] for the use of this parameter and the conditions for its presence.

Basic Service Group

See GSM 03.79 [99] for the use of this parameter and the conditions for its presence.

Alerting Pattern

See GSM 03.18 [97] for the use of this parameter and the conditions for its presence.

CCBS Call

See GSM 03.93 [107] for the use of this parameter and the conditions for its presence.

Supported CCBS Phase

This parameter indicates by its presence that CCBS is supported and the phase of CCBS which is supported.

[Additional Signal Info](#)

See GSM 03.81 [27] for the conditions for the presence of the components of this parameter.

[IMSI](#)

See GSM 03.18 [97] and GSM 03.66 [108] for the use of this parameter and the conditions for its presence.

[MSRN](#)

See GSM 03.18 [97], GSM 03.66 [108] and GSM 03.79 [99] for the use of this parameter and the conditions for its presence. If the NPLR returns only the MSISDN-number without Routeing Number to the GMSC, the MSISDN-number shall be returned as MSRN.

[Forwarding Data](#)

This parameter includes the forwarded-to number, the forwarding reason and the forwarding options Notification to calling party and Redirecting presentation , and can include the forwarded-to subaddress. See GSM 03.18 [97] and GSM 03.79 [99] for the conditions for the presence of its components.

[Forwarding Interrogation Required](#)

See GSM 03.79 [99] for the use of this parameter and the conditions for its presence.

[VMSC address](#)

See GSM 03.79 [99] for the use of this parameter and the conditions for its presence.

[GMSC CAMEL Subscription Info](#)

The use of this parameter and the requirements for its presence are specified in GSM 03.78

[Location Information](#)

The use of this parameter and the requirements for its presence are specified in GSM 03.78

[Subscriber State](#)

The use of this parameter and the requirements for its presence are specified in GSM 03.78

[CUG Subscription Flag](#)

The use of this parameter and the requirements for its presence are specified in GSM 03.78.

[North American Equal Access preferred Carrier Id](#)

This parameter is returned to indicate the preferred carrier identity to be used to setup the call (i.e. forwarding the call or establishing the roaming leg).

[SS-List](#)

This parameter includes SS-codes and will be returned as an operator option. The HLR shall not send PLMN-specific SS-codes across PLMN boundaries. However if the GMSC receives PLMN-specific SS-codes from a foreign PLMN's HLR the GMSC may ignore it. If the GMSC attempts to process the PLMN specific SS codes, this may lead to unpredictable behaviour but the GMSC shall continue call processing.

[Basic Service Code](#)

The use of this parameter and the requirements for its presence are specified in GSM 03.78.

If the CAMEL service is not involved, this parameter includes the basic service code and will be returned as an operator option. The HLR shall not send a PLMN-specific Basic Service Code across PLMN boundaries. However if the GMSC receives a PLMN-specific Basic Service Code from a foreign PLMN's HLR the GMSC may ignore it. If the GMSC attempts to process the PLMN specific Basic Service codes, this may lead to unpredictable behaviour but the GMSC shall continue call processing.

CCBS Target

See GSM 03.93 for the use of this parameter and the conditions for its presence.

Keep CCBS Call Indicator

See GSM 03.93 for the use of this parameter and the conditions for its presence.

Number Portability Status

This parameter indicates the number portability status of the subscriber. This parameter may be present if the sender of SRIack is NPLR.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Unknown Subscriber;
- Number changed;
- Call Barred;

This error will indicate that either incoming calls are barred for this MS or that calls are barred due to Operator Determined Barring (see GSM 02.41 for a definition of this network feature).

- CUG Reject;

The value of this error cause will indicate the reason for CUG Reject.

- Bearer Service Not Provisioned;
- Teleservice Not Provisioned;

A subscription check has been performed and the call has not passed the check due to incompatibility with regard to the requested service. Depending on the nature of the incompatibility, either of these messages will be returned.

- Facility Not Supported;
- Absent Subscriber;

This indicates that the location of the MS is not known (either the station is not registered and there is no location information available or the Provide Roaming Number procedure fails due to IMSI detached flag being set), or the GMSC requested forwarding information with a forwarding reason of not reachable, and the call forwarding on MS not reachable service is not active.

- Busy Subscriber;

This indicates that Call Forwarding on Busy was not active for the specified basic service group when the GMSC requested forwarding information with a forwarding reason of busy.

The error may also indicate that the subscriber is busy due to an outstanding CCBS recall. In the error data it may then be specified that CCBS is possible for the busy encountered call.

- No Subscriber Reply;

This indicates that Call Forwarding on No Reply was not active for the specified basic service group when the GMSC requested forwarding information with a forwarding reason of no reply.

- OR Not Allowed;

This indicates that the HLR is not prepared to accept an OR interrogation from the GMSC, or that calls to the specified subscriber are not allowed to be optimally routed.

- Forwarding Violation;
- System Failure;

- Data Missing;
- Unexpected Data Value.

See subclause 7.6 for a definition of these errors.

Provider error

These are defined in subclause 7.6.

10.2 MAP_PROVIDE_ROAMING_NUMBER service

10.2.1 Definition

This service is used between the HLR and VLR. The service is invoked by the HLR to request a VLR to send back a roaming number to enable the HLR to instruct the GMSC to route an incoming call to the called MS.

This is a confirmed service which uses the Primitives described in table 10.2/1.

10.2.2 Service primitives

Table 10.2/1: MAP_PROVIDE_ROAMING_NUMBER parameters

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
MSC Number	M	M(=)		
MSISDN	U	C(=)		
LMSI	C	C(=)		
GSM Bearer Capability	C	C(=)		
Network Signal Info	C	C(=)		
Suppression Of Announcement	C	C(=)		
Call Reference Number	C	C(=)		
GMSC Address	C	C(=)		
OR Interrogation	C	C(=)		
OR Not Supported in GMSC	C	C(=)		
Alerting Pattern	C	C(=)		
CCBS Call	C	C(=)		
Supported CAMEL Phases in GMSC	C	C(=)		
Additional Signal Info	C	C(=)		
Roaming Number			C	C(=)
User error			C	C(=)
Provider error				O

10.2.3 Parameter use

See subclause 7.6 for a definition of the parameters used, in addition to the following. Note that:

- a conditional parameter whose use is defined only in GSM 03.78 shall be absent if the sending entity does not support CAMEL;
- a conditional parameter whose use is defined only in GSM 03.79 shall be absent if the sending entity does not support optimal routeing;
- a conditional parameter whose use is defined only in GSM 03.78 & GSM 03.79 shall be absent if the sending entity supports neither CAMEL nor optimal routeing.

IMSI

This is the IMSI of the called Subscriber.

MSC Number

This is the ISDN number assigned to the MSC currently serving the MS. The MSC number will have been stored in the HLR as provided at location updating.

MSISDN

See GSM 03.18 [97] for the use of this parameter and the conditions for its presence.

LMSI

See GSM 03.18 [97] for the use of this parameter and the conditions for its presence.

GSM Bearer Capability

See GSM 03.18 [97] for the use of this parameter and the conditions for its presence.

This information is passed according to the rules specified in TS GSM 09.07.

There may be two GSM Bearer Capabilities supplied.

Network Signal Info

See GSM 03.18 [97] for the conditions for the presence of the components of this parameter.

Suppression Of Announcement

The use of this parameter and the requirements for its presence are specified in GSM 03.78.

Call Reference Number

The use of this parameter and the conditions for its presence are specified in GSM 03.78 [98] and GSM 03.79 [99].

GMSC Address

The use of this parameter and the conditions for its presence are specified in GSM 03.78 [98] and GSM 03.79 [99].

OR Interrogation

See GSM 03.79 [99] for the use of this parameter and the conditions for its presence.

Supported CAMEL Phases in GMSC

See GSM 03.78 [98] for the use of this parameter and the conditions for its presence.

OR Not Supported in GMSC

See GSM 03.79 [99] for the use of this parameter and the conditions for its presence.

Alerting Pattern

See GSM 03.78 [98] for the use of this parameter and the conditions for its presence.

CCBS Call

See GSM 03.93 [xx] for the use of this parameter and the conditions for its presence.

Additional Signal Info

See GSM 03.81 [xx] for the conditions for the presence of the components of this parameter.

Roaming Number

See GSM 03.18 [97] for the use of this parameter and the conditions for its presence.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Absent Subscriber;

This error will be returned if the IMSI detach flag is set.

- No Roaming Number Available;
- OR Not Allowed;

This indicates that the MAP_PROVIDE_ROAMING_NUMBER indication included the OR interrogation indicator, but the VLR does not support optimal routeing.

- Facility Not Supported;
- System Failure;
- Data Missing;
- Unexpected Data Value.

See subclause 7.6 for a definition of these reasons.

Provider error

These are defined in subclause 7.6.

10.3 MAP_RESUME_CALL_HANDLING service

10.3.1 Definition

This service is used between the terminating VMSC and the GMSC. The service is invoked by the terminating VMSC to request the GMSC to resume handling the call and forward it to the specified destination.

This is a confirmed service which uses the Primitives listed in table 10.3/1.

10.3.2 Service primitives

Table 10.3/1: MAP_RESUME_CALL_HANDLING parameters

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
Call Reference Number	C	C(=)		
Basic Service Group	C	C(=)		
IMSI	C	C(=)		
Forwarding Data	C	C(=)		
CUG Interlock	C	C(=)		
CUG Outgoing Access	C	C(=)		
O-CSI	C	C(=)		
CCBS Target	C	C(=)		
UU Data	C	C(=)		
UUS CF Interaction	C	C(=)		
All Information Sent	C	C(=)		
MSISDN	C	C(=)		
User error			C	C(=)
Provider error				O

10.3.3 Parameter use

Information received in subsequent segment of a segmented dialogue shall not overwrite information received in an earlier segment.

See subclause 7.6 for a definition of the parameters used, in addition to the following.

Call Reference Number

See GSM 03.79 [99] for the use of this parameter. This parameter shall be present in a first segment of the dialogue.

Basic Service Group

See GSM 03.79 [99] for the use of this parameter. This parameter shall be present in a first segment of the dialogue.

IMSI

This is the IMSI of the forwarding Subscriber. This parameter shall be present in a first segment of the dialogue.

Forwarding Data

This parameter includes the forwarded-to number, the forwarding reason and the forwarding options Notification to calling party and Redirecting presentation, and can include the forwarded-to subaddress. See GSM 03.79 [99] for the conditions for the presence of its components. This parameter shall be present in a first segment of the dialogue.

CUG Interlock

See GSM 03.79 [99] for the use of this parameter and the conditions for its presence.

CUG Outgoing Access

See GSM 03.79 [99] for the use of this parameter and the conditions for its presence.

O-CSI

See GSM 03.79 [99] for the use of this parameter and the conditions for its presence.

For CAMEL phases 1 & 2, the O-CSI shall contain only one set of O-BCSM TDP data.

CCBS Target

See GSM 03.93 [107] for the use of this parameter and the conditions for its presence.

UU Data

See GSM 03.87 for the use of this parameter and the conditions for its presence.

UUS CF Interaction

See GSM 03.87 for the use of this parameter and the conditions for its presence.

All Information Sent

This parameter is set when the VMSC has sent all information to GMSC.

MSISDN

This parameter is the basic MSISDN of the forwarding subscriber. It shall be present if the VMSC supports determination of the redirecting number.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Optimal Routeing not allowed;
- Forwarding failed;

- Unexpected Data Value;
- Data Missing.

Provider error

These are defined in subclause 7.6.

10.4 MAP_PREPARE_GROUP_CALL service

10.4.1 Definition

This service is used by the Anchor_MSC to inform the Relay_MSC about a group call setup.

The MAP_PREPARE_GROUP_CALL service is a confirmed service using the service primitives given in table 10.4

10.4.2 Service primitives

Table 10.4/1: MAP_PREPARE_GROUP_CALL service

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
Teleservice	M	M(=)		
ASCI Call Reference	M	M(=)		
Ciphering Algorithm	M	M(=)		
Group Key Number	C	C(=)		
Group Key	C	C(=)		
Priority	C	C(=)		
CODEC-Information	M	M(=)		
Uplink Free Indicator	M	M(=)		
Group Call Number			M	M(=)
User Error			C	C(=)
Provider Error				O

10.4.3 Parameter definitions and use

Invoke Id

See definition in section 7.6.1

Teleservice

Voice Broadcast Service or Voice Group Call Service.

ASCI Call Reference

Broadcast call reference or group call reference. This item is used to access the VBS-GCR or VGCS-GCR within the Relay_MSC.

Ciphering Algorithm

The ciphering algorithm to be used for the group call.

Group Key Number

This number has to be broadcasted and is used by the mobile station to select the chosen group key.

Shall be present if the ciphering applies.

Group Key

This key is used for ciphering on the radio interface.

Shall be present if the ciphering applies.

Priority

Default priority level related to the call if eMLPP applies.

CODEC-Information

Information on the codecs allowed for this call.

Uplink Free Indicator

A flag indicating whether the call is initiated from a dispatcher.

Group Call Number

This temporary allocated E.164 number is used for routing the call from the Anchor MSC to the Relay MSC.

User Error

For definition of this parameter see section 7.6.1 The following errors defined in section 7.6.1 may be used, depending on the nature of the fault:

- No Group Call Number available;
- System Failure;
- Unexpected Data Value.

Provider Error

See definition of provider error in section 7.6.1.

10.5 MAP_PROCESS_GROUP_CALL_SIGNALLING service

10.5.1 Definitions

This service is used between Relay MSC and Anchor MSC for transmission of Group Call notifications.

The MAP_PROCESS_GROUP_CALL_SIGNALLING service is a non-confirmed service using the service primitives given in table 10.5

10.5.2 Service primitives

Table 10.5/1: MAP_PROCESS_GROUP_CALL_SIGNALLING service

Parameter name	Request	Indication
Invoke Id	M	M(=)
Uplink Request	C	C(=)
Uplink Release Indication	C	C(=)
Release Group Call	C	C(=)

10.5.3 Parameter definitions and use

Invoke Id

See definition in section 7.6.1

Uplink Request

This information element indicates to the anchor MSC that a service subscriber roaming in the relay MSC area requests access to the uplink.

Uplink Release Indication

This information element if included by the Relay MSC indicates to the Anchor MSC that the uplink has become free.

Release Group Call

This information element if included by the Relay MSC indicates to the Anchor MSC that the service subscriber who has initiated the call and who currently has access to the uplink terminates the call.

10.6 MAP_FORWARD_GROUP_CALL_SIGNALLING service

10.6.1 Definitions

This service is used between Anchor MSC and Relay MSC for transmission of Group Call notifications.

The MAP_FORWARD_GROUP_CALL_SIGNALLING service is a non-confirmed service using the service primitives given in table 10.6

10.6.2 Service primitives

Table 10.6: MAP_FORWARD_GROUP_CALL_SIGNALLING service

Parameter name	Request	Indication
Invoke Id	M	M(=)
IMSI	C	C(=)
Uplink Request Acknowledgement	C	C(=)
Uplink Release Indication	C	C(=)
Uplink Reject Command	C	C(=)
Uplink Seized Command	C	C(=)
Uplink Release Command	C	C(=)

10.6.3 Parameter definitions and use

IMSI

Identity of the service subscriber who has established the call and who is allowed to terminate the call.

Invoke Id

See definition in section 7.6.1

Uplink Request Acknowledgement

This information element is used for positive acknowledgement of an uplink request

Uplink Release Indication

This information element if included by the Anchor MSC indicates to the Relay MSC that the uplink has become free.

Uplink Reject Command

This information element is used for negative acknowledgement of an uplink request

Uplink Seized Command

This information element if included by the Anchor MSC indicates to the Relay MSC that the uplink is no longer free.

Uplink Release Command

This information element if included by the Anchor MSC indicates to the Relay MSC that the uplink which is granted to a MS in the relay MSC area shall be released.

10.7 MAP_SEND_GROUP_CALL_END_SIGNAL service

10.7.1 Definitions

This service is used between the Relay MSC and the Anchor MSC indicating that VGCS / VBS channels have been established in the Relay MSC area. The response is used by the Anchor MSC to inform Relay MSC that all resources for the call can be released in Relay MSC because the call has been released in the Anchor MSC.

The MAP_SEND_GROUP_CALL_END_SIGNAL service is a confirmed service using the service primitives given in table 10.7

10.7.2 Service primitives

Table 10.7: MAP_SEND_GROUP_CALL_END_SIGNAL service

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	C	C(=)		
Provider Error				O

10.7.3 Parameter definitions and use

IMSI

Identity of the service subscriber who has established the call and who is allowed to terminate the call.

Shall be present if the call was established by a service subscriber roaming in the relay MSC area.

Invoke Id

See definition in section 7.6.1

Provider Error

See definition of provider error in section 7.6.1.

10.8 MAP_Provide_SIWFs_Number

10.8.1 Definition

This service is used between an MSC and SIWFS. It is invoked by an MSC receiving an incoming call (call to or from MS) to request the SIWFS to allocate IWU resources. The service is defined in GSM 03.54.

This is a confirmed service using the primitives described in table 10.8.

10.8.2 Service primitive

Table 10.8: MAP_Provide_SIWF_Number service

Parameter name	Request	Indication	Response	Confirm
Invoke ID	M	M(=)	M(=)	M(=)
GSM Bearer Capability	M	M(=)		
ISDN Bearer Capability	M	M(=)		
Call Direction	M	M(=)		
B-subscriber address	M	M(=)		
Chosen Channel	M	M(=)		
Lower Layer Compatibility	C	C(=)		
High Layer Compatibility	C	C(=)		
SIWF number			C	C(=)
User error			C	C(=)
Provider error				O

10.8.3 Parameter use

See subclause 7.6 for a definition of the parameter used, in addition to the following.

GSM Bearer Capability

This information is the result from the negotiation with the mobile station. The information is sent from the MSC to the SIWF to allocate the correct IWU.

ISDN Bearer Capability

This parameter refers to the ISDN Bearer Capability information element. For the MTC this parameter is received in the ISUP User Service Information parameter. For the MOC call this parameter is mapped from the GSM BC parameter according to GSM 09.07. The parameter is used by the SIWF to route the call and to allocate the outgoing circuit.

Call Direction

This parameter indicates the direction of the call (mobile originated or mobile terminated) at call set-up.

B-subscriber address

This parameter is sent from the MSC to the SIWF to inform the SIWF where to route the call i.e. where to send the IAM. If the loop method is used this parameter will indicate the address to the VMSC. This address is allocated by the VMSC in the same way as a MSRN and is used to correlate the incoming IAM to the corresponding MAP dialogue. If the non-loop method is used this parameter will indicate the address to the B-subscriber.

Chosen Channel

This parameter is sent from the MSC to the SIWF to adjust the interworking unit to the assigned radio resources. This parameter is defined in GSM 08.08.

Lower Layer Compatibility

This parameter is sent from the MSC to the SIWF to allow the interworking unit to perform a compatibility check. This parameter is handled as specified in GSM 09.07. This parameter is defined in GSM 04.08.

High Layer Compatibility

This parameter is sent from the MSC to the SIWF to allow the interworking unit to perform a compatibility check. This parameter is handled as specified in GSM 09.07. This parameter is defined in GSM 04.08.

SIWF number

This parameter is sent from the SIWF to the MSC. This address is used by the visited MSC to route the call, i.e. the IAM to the SIWF (similar to MSRN) and will be used by the SIWF to correlate the incoming IAM to the corresponding MAP message. This parameter must always be sent from the SIWF when a successful allocation of SIWF resources has been made.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Resource limitation;
- Facility Not Supported;
- Unexpected Data Value;
- System Failure.

See subclause 7.6 for a definition of these reasons.

Provider error

These are defined in subclause 7.6.

10.9 MAP_SIWF_Signalling_Modify

10.9.1 Definition

This service is used to transport signalling information between an MSC and an SIWFS in the case of a request to modify the configuration (e.g. HSCSD). It is invoked either by an MSC or by the SIWFS. The service is defined in GSM 03.54.

This is a confirmed service using the primitives described in table 10.9.

10.9.2 Service primitive

Table 10.9: MAP_SIWF_Signalling_Modify service

Parameter name	Request	Indication	Response	Confirm
Invoke ID	M	M(=)	M(=)	M(=)
Channel Type	C	C(=)		
Chosen Channel	C	C(=)	C(=)	C(=)
User error			C	C(=)
Provider error				O

10.9.3 Parameter use

See subclause 7.6 for a definition of the parameter used, in addition to the following.

Channel Type

This parameter is the result of a Channel Mode Modification for TS61/62. It contains the changed Air Interface User Rate. The information is sent from the SIWFS to the MSC to assign the correct radio resource. This parameter is defined in GSM 08.08.

Chosen Channel

This parameter is sent from the MSC to the SIWFS to adjust the interworking unit to the assigned radio resources. This parameter is defined in GSM 08.08.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Resource limitation;
- Facility Not Supported;

- Data Missing;
- Unexpected Data Value;
- System Failure.

See subclause 7.6 for a definition of these reasons.

Provider error

These are defined in subclause 7.6.

10.10 MAP_SET_REPORTING_STATE service

10.10.1 Definition

This service is used between the HLR and the VLR to set the reporting state for a requested service. It is a confirmed service using the service primitives shown in table 10.10/1.

10.10.2 Service primitives

The service primitives are shown in table 10.10/1.

Table 10.10/1: MAP_SET_REPORTING_STATE parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMSI	C	C(=)		
LMSI	C	C(=)		
CCBS Monitoring	C	C(=)		
CCBS Subscriber Status			C	C(=)
User error			C	C(=)
Provider error				O

10.10.3 Parameter use

See subclause 7.6 for a definition of the parameters used, in addition to the following.

IMSI

The IMSI is a mandatory parameter if the service is used as the only one in a dialogue.

CCBS Monitoring

This parameter indicates whether monitoring for CCBS shall be started or stopped. If it indicates that monitoring shall be started this service corresponds to the message 'Start Reporting' in GSM 03.93; if it indicates that monitoring shall be stopped this service corresponds to the message 'Stop Reporting' in GSM 03.93.

CCBS Subscriber Status

See GSM 03.93 for the use of this parameter and the conditions for its presence.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values defined in subclause 7.6.1:

- System Failure;
- Unidentified Subscriber;

- Unexpected Data Value;
- Data Missing;
- Resource Limitation;
- Facility Not Supported.

NOTE: This error is reserved for future use.

Provider error

These are defined in subclause 7.6.

10.11 MAP_STATUS_REPORT service

10.11.1 Definition

This service is used by the VLR to report an event or call outcome to the HLR. It is a confirmed service using the service primitives shown in table 10.11/1.

10.11.2 Service primitives

The service primitives are shown in table 10.11/1.

Table 10.11/1: MAP_STATUS_REPORT parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)		M(=)
IMSI	M	M(=)		
CCBS Subscriber Status	C	C(=)		
Monitoring Mode	C	C(=)		
Call Outcome	C	C(=)	C	C(=)
User error				O
Provider error				

10.11.3 Parameter use

See subclause 7.6 for a definition of the parameters used, in addition to the following.

CCBS Subscriber Status

If this parameter is present without Monitoring Mode and Call Outcome this service corresponds to the message 'Event Report' in GSM 03.93 [107]. See GSM 03.93 [107] for the use of this parameter and the conditions for its presence.

Monitoring Mode

If this parameter is present with CCBS Call Outcome this service corresponds to the message 'CCBS Call Report' in GSM 03.93. See GSM 03.93 for the use of this parameter and the conditions for its presence.

Call Outcome

See GSM 03.93 for the use of this parameter and the conditions for its presence.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values defined in subclause 7.6.1:

- Unknown Subscriber ;

- System Failure;
- Unexpected Data Value;
- Data Missing.

Provider error

These are defined in subclause 7.6.

10.12 MAP_REMOTE_USER_FREE service

10.12.1 Definition

This service is used between the HLR and the VLR to report that the B subscriber is now idle and that the A subscriber can be notified. It is a confirmed service using the service primitives shown in table 10.12/1.

10.12.2 Service primitives

The service primitives are shown in table 10.12/1.

Table 10.12/1: MAP_REMOTE_USER_FREE parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
Call Info	M	M(=)		
CCBS Feature	M	M(=)		
Translated B Number	M	M(=)		
Replace B Number	C	C(=)		
Alerting Pattern	C	C(=)		
RUF Outcome			C	C(=)
User error			C	C(=)
Provider error				O

10.12.3 Parameter use

See subclause 7.6 for a definition of the parameters used, in addition to the following.

Call Info

See GSM 03.93 for the use of this parameter.

CCBS Feature

See GSM 03.93 for the conditions for the presence of the parameters included in the CCBS feature.

Translated B Number

See GSM 03.93 for the use of this parameter.

Replace B Number

See GSM 03.93 for the use of this parameter and the conditions for its presence.

Alerting Pattern

See GSM 03.93 for the use of this parameter and the conditions for its presence.

RUF Outcome

See GSM 03.93 for the use of this parameter and the conditions for its presence.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values defined in subclause 7.6.1:

- Unexpected Data Value;
- Data Missing;
- Incompatible Terminal;

This error is returned by the responder when the terminal used for CCBS activation is not compatible with the terminal used for the CCBS recall. For details refer to GSM 04.08.

- Absent Subscriber (IMSI Detach; Restricted Area; No Page Response);
- System Failure;
- Busy Subscriber (CCBS Busy).

Provider error

These are defined in subclause 7.6.

11 Supplementary services related services

11.1 MAP_REGISTER_SS service

11.1.1 Definition

This service is used between the MSC and the VLR and between the VLR and the HLR to register data related to a supplementary service. The VLR will relay the message to the HLR.

The service is a confirmed service and consists of four service primitives.

11.1.2 Service primitives

The service primitives are shown in table 11.1/1.

Table 11.1/1: MAP_REGISTER_SS parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)		
SS-Code	M	M(=)		
Basic service	C	C(=)		
Forwarded-to number with subaddress	C	C(=)		
No reply condition time	C	C(=)		
EMLPP default priority	C	C(=)	C	C(=)
Forwarding information			C	C(=)
User error			C	C(=)
Provider error				O

11.1.3 Parameter use

Invoke id

See subclause 7.6.1 for the use of this parameter.

SS-Code

This parameter indicates the supplementary service which the mobile subscriber wants to register.

Basic service

This parameter indicates for which basic service group the supplementary service is to be registered. If it is not included, the registration request applies to all basic services.

Forwarded-to number with subaddress

This parameter is obligatory if the registration applies to one or more call forwarding supplementary services. It can optionally include a sub-address.

No reply condition time

This parameter is included if the registration applies to the Call Forwarding on No Reply supplementary service (or a superset of this service) and the mobile subscriber supplies a value for this time.

eMLPP default priority

This parameter is sent by the initiator to register the eMLPP default priority level and is returned by the responder at successful outcome of the service.

Forwarding information

This parameter is returned by the responder at successful outcome of the service, if the registration request concerned one or a group of Call Forwarding supplementary services.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values defined in subclause 7.6.1:

- System failure;
- Data missing;
- Unexpected data value;
- Call Barred;
- Bearer service not provisioned;

This error is returned only if not even a subset of the requested bearer service group has been subscribed to.

- Teleservice not provisioned;

This error is returned only if not even a subset of the requested teleservice group has been subscribed to.

- Illegal SS operation;
- SS error status;
- SS incompatibility.

Provider error

See subclause 7.6.1 for the use of this parameter.

11.2 MAP_ERASE_SS service

11.2.1 Definition

This service is used between the MSC and the VLR and between the VLR and the HLR to erase data related to a supplementary service. The VLR will relay the message to the HLR.

The service is a confirmed service and consists of four service primitives.

11.2.2 Service primitives

The service primitives are shown in table 11.2/1.

Table 11.2/1: MAP_ERASE_SS parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS-Code	M	M(=)		
Basic service	C	C(=)		
Forwarding information			C	C(=)
User error			C	C(=)
Provider error				O

11.2.3 Parameter use

Invoke id

See subclause 7.6.1 for the use of this parameter.

SS-Code

This parameter indicates the supplementary service which the mobile subscriber wants to erase.

Basic service

This parameter indicates for which basic service group the supplementary service should be erased. If it is not included, the erasure request applies to all basic services.

Forwarding information

This parameter is returned by the responder at successful outcome of the service, if the erasure request concerned one or a group of Call Forwarding supplementary services.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values, defined in subclause 7.6.1:

- System failure;
- Data Missing;
- Unexpected data value;
- Bearer service not provisioned;

This error is returned only if not even a subset of the requested bearer service group has been subscribed to.

- Teleservice not provisioned;

This error is returned only if not even a subset of the requested teleservice group has been subscribed to.

- Call Barred;

- Illegal SS operation;
- SS error status.

Provider error

See subclause 7.6.1 for the use of this parameter.

11.3 MAP_ACTIVATE_SS service

11.3.1 Definition

This service is used between the MSC and the VLR and between the VLR and the HLR to activate a supplementary service. The VLR will relay the message to the HLR.

The service is a confirmed service and consists of four service primitives.

11.3.2 Service primitives

The service primitives are shown in table 11.3/1.

Table 11.3/1: MAP_ACTIVATE_SS parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS-Code	M	M(=)		
Basic service	C	C(=)		
Forwarding information			C	C(=)
Call barring information			C	C(=)
SS-Data			C	C(=)
User error			C	C(=)
Provider error				O

11.3.3 Parameter use

Invoke id

See subclause 7.6.1 for the use of this parameter.

SS-Code

This parameter indicates the supplementary service which the mobile subscriber wants to activate.

Basic service

This parameter indicates for which basic service groups the requested supplementary service(s) should be activated. If it is not included, the activation request applies to all basic services.

Forwarding information

This parameter is returned by the responder at successful outcome of the service, if the activation request concerned Call Forwarding.

Call barring information

This parameter is returned by the responder at successful outcome of the service, if the activation request concerned Call Barring.

SS-Data

This parameter is returned by the responder at successful outcome of the service, if the activation request concerned for example Call Waiting.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values, defined in subclause 7.6.1:

- System failure;
- Data Missing;
- Unexpected data value;
- Bearer service not provisioned;

This error is returned only if not even a subset of the requested bearer service group has been subscribed to.

- Teleservice not provisioned;

This error is returned only if not even a subset of the requested teleservice group has been subscribed to.

- Call Barred;
- Illegal SS operation;
- SS error status;
- SS subscription violation;
- SS incompatibility;
- Negative PW check;
- Number Of PW Attempts Violation.

Provider error

See subclause 7.6.1 for the use of this parameter.

11.4 MAP_DEACTIVATE_SS service

11.4.1 Definitions

This service is used between the MSC and the VLR and between the VLR and the HLR to deactivate a supplementary service. The VLR will relay the message to the HLR.

The service is a confirmed service and consists of four service primitives.

11.4.2 Service primitives

The service primitives are shown in table 11.4/1.

Table 11.4/1: MAP_DEACTIVATE_SS parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS-Code	M	M(=)		
Basic service	C	C(=)		
Forwarding information			C	C(=)
Call barring information			C	C(=)
SS-Data			C	C(=)
User error			C	C(=)
Provider error				O

11.4.3 Parameter use

Invoke id

See subclause 7.6.1 for the use of this parameter.

SS-Code

This parameter indicates the supplementary service which the mobile subscriber wants to deactivate.

Basic service

This parameter indicates for which basic service group the requested supplementary service(s) should be deactivated. If it is not included the deactivation request applies to all basic services.

Forwarding information

This parameter is returned by the responder at successful outcome of the service, if the deactivation request concerned one or a group of Call Forwarding supplementary services.

Call barring information

This parameter is returned by the responder at successful outcome of the service, if the activation request concerned one or a group of Call Barring supplementary services.

SS-Data

This parameter is returned by the responder at successful outcome of the service, for example if the deactivation request concerned the Call Waiting supplementary service.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values, defined in subclause 7.6.1:

- System failure;
- Data Missing;
- Unexpected data value;
- Bearer service not provisioned;

This error is returned only if not even a subset of the requested bearer service group has been subscribed to.

- Teleservice not provisioned;

This error is returned only if not even a subset of the requested teleservice group has been subscribed to.

- Call Barred;
- Illegal SS operation;
- SS error status;
- SS subscription violation;
- Negative PW check;
- Number Of PW Attempts Violation.

Provider error

See subclause 7.6.1 for the use of this parameter.

11.5 MAP_INTERROGATE_SS service

11.5.1 Definitions

This service is used between the MSC and the VLR and between the VLR and the HLR to retrieve information related to a supplementary service. The VLR will relay the message to the HLR if necessary.

The service is a confirmed service and consists of four service primitives.

11.5.2 Service primitives

The service primitives are shown in table 11.5/1.

Table 11.5/1: MAP_INTERROGATE_SS parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS-Code	M	M(=)		
Basic service	C	C(=)		
SS-Status			C	C(=)
Basic service Group LIST			C	C(=)
Forwarding feature LIST			C	C(=)
CLI restriction Info			C	C(=)
EMLPP Info			C	C(=)
CCBS Feature LIST			C	C(=)
User error			C	C(=)
Provider error				O

11.5.3 Parameter use

For additional information on parameter use refer to the GSM 04.8x and 04.9x-series of technical specifications.

Invoke id

See subclause 7.6.1 for the use of this parameter.

SS-Code

The mobile subscriber can only interrogate a single supplementary service per service request.

Basic service

This parameter indicates for which basic service group the given supplementary service is interrogated. If it is not included, the interrogation request applies to all basic services.

SS-Status

This parameter is included by the responder if:

- the interrogated supplementary service can only be subscribed for all applicable basic services simultaneously; or
- the interrogated supplementary service is not active for any of the interrogated basic services, or
- the interrogation was for the CCBS supplementary service and no CCBS request is active or the service is not provisioned.

Basic service group LIST

This parameter LIST is used to include one or a series of basic service groups for which the interrogated supplementary service is active. If the interrogated supplementary service is not active for any of the interrogated (and provisioned) basic service groups, the SS-Status parameter is returned.

Forwarding feature LIST

The forwarding feature parameter is described in subclause 7.6.4. A list of one or more forwarding features is returned by the responder when the interrogation request applied to Call Forwarding supplementary service.

If no basic service code parameter is provided within this sequence, the forwarding feature parameter applies to all provisioned basic services.

CLI restriction Info

The CLI-RestrictionInfo parameter is returned by the responder when the interrogation request applies to the CLIR supplementary service.

eMLPP Info

The eMLPP info (maximum entitled priority and default priority) is returned by the responder if the interrogation request applies to the eMLPP supplementary service.

CCBS Feature LIST

The CCBS feature parameter is described in subclause 7.6. A list of one or more CCBS features is returned by the responder when the interrogation request applied to the CCBS supplementary service. See GSM 03.93 [107] for the conditions for the presence of the parameters included in the CCBS feature.

User error

This error is sent by the responder upon unsuccessful outcome of the interrogation service, and then takes one of the following values, defined in subclause 7.6.1:

- System failure;
- Data Missing;
- Unexpected data value;
- Bearer Service not provisioned;

This error is returned only if not even a subset of the interrogated bearer services are provided.

- Teleservice not provisioned;

This error is returned only if not even a subset of the interrogated teleservices are provided.

- Call Barred;
- Illegal SS operation;
- SS not available.

Provider error

See subclause 7.6.1 for the use of this parameter.

11.6 MAP_INVOKE_SS service

11.6.1 Definitions

This service is used between the MSC and the VLR to check the subscriber's subscription to a given supplementary service in the VLR, in connection with in-call invocation of that supplementary service, i.e. after the call set-up phase is finished. For supplementary service invocation during call set-up phase, please refer to the call handling descriptions.

The service is a confirmed service and consists of four service primitives.

11.6.2 Service primitives

The service primitives are shown in table 11.6/1.

Table 11.6/1: MAP_INVOKE_SS parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS-Code	M	M(=)		
Basic service	C	C(=)		
User error			C	C(=)
Provider error				O

11.6.3 Parameter use

Invoke id

See subclause 7.6.1 for the use of this parameter.

SS-Code

This SS-Code can only refer to a single supplementary service, e.g. the Call Hold or Multi Party supplementary services.

Basic service

This parameter indicates for which basic service the supplementary service invocation is required.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values:

- System Failure;
- Data Missing;
- Unexpected data value;
- Call Barred;
- Illegal SS operation;
- SS error status;
- SS not available.

Provider error

See subclause 7.6.1 for the use of this parameter.

11.7 MAP_REGISTER_PASSWORD service

11.7.1 Definitions

This service is used between the MSC and the VLR and between the VLR and the HLR if the mobile subscriber requests to register a new password. The VLR will relay the message to the HLR.

The service is a confirmed service and consists of four service primitives.

11.7.2 Service primitives

The service primitives are shown in table 11.7/1.

Table 11.7/1: MAP_REGISTER_PASSWORD parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS-Code	M	M(=)		
New password			C	C(=)
User error			C	C(=)
Provider error				O

11.7.3 Parameter use

Invoke id

See subclause 7.6.1 for the use of this parameter.

SS-Code

This parameter indicates for which supplementary service(s) the password should be registered.

New Password

See subclause 7.6.4 for the use of this parameter.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values, defined in subclause 7.6.1:

- System failure;
- Data Missing;
- Unexpected data value;
- Call Barred;
- SS subscription violation;
- Password registration failure;
- Negative PW check;
- Number Of PW Attempts Violation.

Provider error

See subclause 7.6.1 for the use of this parameter.

11.8 MAP_GET_PASSWORD service

11.8.1 Definitions

This service is used between the HLR and the VLR and between the VLR and the MSC when the HLR receives a request from the mobile subscriber for an operation on a supplementary service which requires a password from the subscriber. The VLR will relay the message to the MSC.

The service is a confirmed service and consists of four service primitives.

11.8.2 Service primitives

The service primitives are shown in table 11.8/1.

Table 11.8/1: MAP_GET_PASSWORD parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
Linked id	C	C(=)		
Guidance info	M	M(=)		
Current password			M	M(=)
Provider error				O

11.8.3 Parameter use

Invoke id

See subclause 7.6.1 for the use of this parameter.

Linked Id

See subclause 7.6.1 for the use of this parameter. If the MAP GET PASSWORD service is used in conjunction with the MAP REGISTER PASSWORD service, this parameter must be present; otherwise it must be absent.

Guidance info

See subclause 7.6.4 for the use of this parameter.

Current password

See subclause 7.6.4 for the use of this parameter.

Provider error

See subclause 7.6.1 for the use of this parameter.

11.9 MAP_PROCESS_UNSTRUCTURED_SS_REQUEST service

11.9.1 Definitions

This service is used between the MSC and the VLR, between the VLR and the HLR and between the HLR and gsmSCF to relay information in order to allow unstructured supplementary service operation.

The MAP_PROCESS_UNSTRUCTURED_SS_REQUEST service is a confirmed service using the primitives from table 11.9/1.

11.9.2 Service primitives

Table 11.9/1: MAP_PROCESS_UNSTRUCTURED_SS_REQUEST parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
USSD Data Coding Scheme	M	M(=)	C	C(=)
USSD String	M	M(=)	C	C(=)
MSISDN	U	C(=)	C	C(=)
User error			C	O
Provider error				

11.9.3 Parameter use

Invoke id

See subclause 7.6.1 for the use of this parameter.

USSD Data Coding Scheme:

See subclause 7.6.4 for the use of this parameter. The presence of the parameter in the response is dependent on the unstructured supplementary service application. If this parameter is present, then the USSD String parameter has to be present.

USSD String:

See subclause 7.6.1 for the use of this parameter. The presence of the parameter in the response is dependent on the unstructured supplementary service application. If this parameter is present, then the USSD Data Coding Scheme parameter has to be present.

MSISDN:

The subscriber's basic MSISDN.

See definition in subclause 7.6.2. The MSISDN is included as an operator option, e.g. to allow addressing the subscriber's data in the gsmSCF with the MSISDN.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values defined in subclause 7.6.1:

- System failure;
- Data missing;
- Unexpected data value;

This error is returned by the responder if it is not able to deal with the contents of the USSD string.

- Call Barred;
- Unknown Alphabet.

Provider error

See subclause 7.6.1 for the use of this parameter.

11.10 MAP_UNSTRUCTURED_SS_REQUEST service

11.10.1 Definitions

This service is used between the gsmSCF and the HLR, the HLR and the VLR and between the VLR and the MSC when the invoking entity requires information from the mobile user, in connection with unstructured supplementary service handling.

The MAP_UNSTRUCTURED_SS_REQUEST service is a confirmed service using the primitives from table 11.10/1.

11.10.2 Service primitives

The service primitives are shown in table 11.10/1.

Table 11.10/1: MAP_UNSTRUCTURED_SS_REQUEST parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
USSD Data Coding Scheme	M	M(=)	C	C(=)
USSD String	M	M(=)	C	C(=)
Alerting Pattern	C	C(=)	C	C(=)
User error				O
Provider error				

11.10.3 Parameter use

Invoke id

See subclause 7.6.1 for the use of this parameter.

USSD Data Coding Scheme:

See subclause 7.6.4 for the use of this parameter. The presence of the parameter in the response is dependent on the mobile user's MMI input. If this parameter is present, then the USSD String parameter has to be present.

USSD String:

See subclause 7.6.1 for the use of this parameter. The presence of the parameter in the response is dependent on the mobile user's MMI input. If this parameter is present, then the USSD Data Coding Scheme parameter has to be present.

Alerting Pattern

See subclause 7.6.3 for the use of this parameter.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values defined in subclause 7.6.1:

- System failure;
- Data missing;
- Unexpected data value;

This error is returned by the responder if it is not able to deal with the contents of the USSD string.

- Absent Subscriber;
- Illegal Subscriber;

This error indicates that delivery of the unstructured supplementary service data failed because the MS failed authentication.

- Illegal Equipment;
- USSD Busy;
- Unknown Alphabet.

Provider error

See subclause 7.6.1 for the use of this parameter.

11.11 MAP_UNSTRUCTURED_SS_NOTIFY service

11.11.1 Definitions

This service is used between the gsmSCF and the HLR, the HLR and the VLR and between the VLR and the MSC when the invoking entity requires a notification to be sent to the mobile user, in connection with unstructured supplementary services handling.

The MAP_UNSTRUCTURED_SS_NOTIFY service is a confirmed service using the primitives from table 11.11/1.

11.11.2 Service primitives

The service primitives are shown in table 11.11/1.

Table 11.11/1: MAP_UNSTRUCTURED_SS_NOTIFY parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
USSD Data Coding Scheme	M	M(=)		
USSD String	M	M(=)		
Alerting Pattern	C	C(=)		
User error			C	
Provider error				C(=) O

11.11.3 Parameter use

Invoke id

See subclause 7.6.1 for the use of this parameter.

USSD Data Coding Scheme:

See subclause 7.6.4 for the use of this parameter.

USSD String:

See subclause 7.6.1 for the use of this parameter.

Alerting Pattern

See subclause 7.6.3 for the use of this parameter.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values defined in subclause 7.6.1:

- System failure;
- Data missing;
- Unexpected data value;

This error is returned by the responder if it is not able to deal with the contents of the USSD string.

- Absent Subscriber;
- Illegal Subscriber;

This error indicates that delivery of the unstructured supplementary service data failed because the MS failed authentication.

- Illegal Equipment;
- USSD Busy;
- Unknown Alphabet.

Provider error

See subclause 7.6.1 for the use of this parameter.

11.12 MAP_SS_INVOCATION_NOTIFY

11.12.1 Definition

This service is used between the MSC and the gsmSCF when the subscriber invokes one of the following supplementary services; CD, ECT or MPTY.

11.12.2 Service primitives

The service primitives are shown in table 11.12/1.

Table 11.12/1: SS_INVOCATION_NOTIFY parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)		
MSISDN	M	M(=)		
IMSI	M	M(=)		
SS- event	M	M(=)		
SS- event data	C	C(=)		
User error			C	
Provider error				C(=) O

11.12.3 Parameter use

All parameters are described in subclause 7.6. The use of these parameters and the requirements for their presence are specified in GSM 03.78.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Data Missing;
- Unexpected Data Value;
- Unknown Subscriber.

Provider error

This is defined in subclause 7.6.1.

11.13 MAP_REGISTER_CC_ENTRY service

11.13.1 Definition

This service is used between the MSC and the VLR and between the VLR and the HLR to register data for a requested call completion supplementary service. The VLR will relay the message to the HLR.

The service is a confirmed service and uses the service primitives shown in table 11.13/1.

11.13.2 Service primitives

The service primitives are shown in table 11.13/1.

Table 11.13/1: MAP_REGISTER_CC_ENTRY parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS Code	M	M(=)		
CCBS Feature	C	C(=)	C	C(=)
Translated B number	C	C(=)		
Service Indicator	C	C(=)		
Call Info	C	C(=)		
Network Signal Info	C	C(=)		
User error			C	C(=)
Provider error				O

11.13.3 Parameter use

See subclause 7.6 for a definition of the parameters used, in addition to the following.

SS-Code

This parameter indicates the call completion supplementary service for which the mobile subscriber wants to register an entry.

CCBS Feature

See GSM 03.93 for the conditions for the presence of the parameters included in the CCBS feature.

Translated B Number

See GSM 03.93 for the use of this parameter and the conditions for its presence.

Service Indicator

This parameter corresponds to the parameters 'Presentation Indicator' and 'CAMEL Invoked' in GSM 03.93 [107]. It indicates which services have been invoked for the original call (e.g. CLIR, Camel). See GSM 03.93 [107] for the use of this parameter and the conditions for its presence.

Call Info

See GSM 03.93 [107] for the use of this parameter and the conditions for its presence.

Network Signal Info

See GSM 03.93 [107] for the use of this parameter and the conditions for its presence.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values, defined in subclause 7.6.1:

- System failure;
- Data missing;
- Unexpected data value;
- Call Barred;
- Illegal SS operation;
- SS error status;

- SS incompatibility;
- Short Term Denial;
- Long Term Denial;
- Facility Not Supported;

NOTE: This error is reserved for future use.

Private Extensions shall not be sent with these user errors for this operation.

Provider error

See subclause 7.6.1 for the use of this parameter.

11.14 MAP_ERASE_CC_ENTRY service

11.14.1 Definition

This service is used between the MSC and the VLR and between the VLR and the HLR to erase data related to a call completion supplementary service. The VLR will relay the message to the HLR.

The service is a confirmed service and uses the service primitives shown in table 11.14/1.

11.14.2 Service primitives

The service primitives are shown in table 11.14/1.

Table 11.14/1: MAP_ERASE_CC_ENTRY parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS-Code	M	M(=)	C(=)	C(=)
CCBS Index	C	C(=)		
SS-Status			C	C(=)
User error			C	C(=)
Provider error				O

11.14.3 Parameter use

See subclause 7.6 for a definition of the parameters used, in addition to the following.

SS-Code

This parameter indicates the call completion supplementary service for which the mobile subscriber wants to erase an entry/entries.

CCBS Index

See GSM 03.93 for the use of this parameter and the condition for its presence.

SS-Status

Depending on the outcome of the service request this parameter may indicate either provisioned and active or not provisioned.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values, defined in subclause 7.6.1:

- System failure;
- Data Missing;
- Unexpected data value;
- Call Barred;
- Illegal SS operation;
- SS error status.

Private Extensions shall not be sent with these user errors for this operation.

Provider error

See subclause 7.6.1 for the use of this parameter.

12 Short message service management services

12.1 MAP-SEND-ROUTING-INFO-FOR-SM service

12.1.1 Definition

This service is used between the gateway MSC and the HLR to retrieve the routing information needed for routing the short message to the servicing MSC.

The MAP-SEND-ROUTING-INFO-FOR-SM is a confirmed service using the primitives from table 12.1/1.

12.1.2 Service primitives

The service primitives are shown in table 12.1/1.

Table 12.1/1: MAP-SEND-ROUTING-INFO-FOR-SM

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
MSISDN	M	M(=)		
SM-RP-PRI	M	M(=)		
Service Centre Address	M	M(=)		
SM-RP-MTI	C	C(=)		
SM-RP-SMEA	C	C(=)		
GPRS Support Indicator	C	C(=)		
IMSI			C	C(=)
Network Node Number			C	C(=)
LMSI			C	C(=)
GPRS Node Indicator			C	C(=)
Additional Number			C	C(=)
User error			C	C(=)
Provider error				O

12.1.3 Parameter use

Invoke id:

See definition in subclause 7.6.1.

MSISDN:

See definition in subclause 7.6.2.

SM-RP-PRI:

See definition in subclause 7.6.8.

Service Centre Address:

See definition in subclause 7.6.2.

SM-RP-MTI:

See definition in subclause 7.6.8. This parameter shall be present when the feature « SM filtering by the HPLMN » is supported by the SMS-GMSC and when the equivalent parameter is received from the short message service relay sub-layer protocol.

SM-RP-SMEA:

See definition in subclause 7.6.8. This parameter shall be present when the feature « SM filtering by the HPLMN » is supported by the SMS-GMSC and when the equivalent parameter is received from the short message service relay sub-layer protocol.

GPRS Support Indicator:

See definition in subclause 7.6.8. The presence of this parameter is mandatory if the SMS-GMSC supports receiving of the two numbers from the HLR.

IMSI:

See definition in subclause 7.6.2. The presence of this parameter is mandatory in a successful case.

Network Node Number:

See definition in subclause 7.6.2. This parameter is provided in a successful response.

LMSI:

See definition in subclause 7.6.2. It is an operator option to provide this parameter from the VLR; it is mandatory for the HLR to include the LMSI in a successful response, if the VLR has used the LMSI.

GPRS Node Indicator:

See definition in subclause 7.6.8. The presence of this parameter is mandatory if only the SGSN number is sent in the Network Node Number.

Additional Number:

See definition in subclause 7.6.2. This parameter is provided in a successful response.

User error:

The following errors defined in subclause 7.6.1 may be used, depending on the nature of the fault:

- Unknown subscriber;
- Call Barred;
- Teleservice Not Provisioned;
- Absent Subscriber_SM;

- Facility Not Supported;
- System failure;
- Unexpected Data Value;
- Data missing.

Provider error:

For definition of provider errors see subclause 7.6.1.

12.2 MAP-MO-FORWARD-SHORT-MESSAGE service

12.2.1 Definition

This service is used between the serving MSC or the SGSN and the SMS Interworking MSC to forward mobile originated short messages.

The MAP-MO-FORWARD-SHORT-MESSAGE service is a confirmed service using the service primitives given in table 12.2/1.

12.2.2 Service primitives

The service primitives are shown in table 12.2/1.

Table 12.2/1: MAP-MO-FORWARD-SHORT-MESSAGE

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
SM RP DA	M	M(=)		
SM RP OA	M	M(=)		
SM RP UI	M	M(=)	C	C(=)
IMSI	C	C(=)	C	C(=)
User error				O
Provider error				

12.2.3 Parameter use

Invoke id:

See definition in subclause 7.6.1.

SM RP DA:

See definition in subclause 7.6.8.

In the mobile originated SM transfer this parameter contains the Service Centre address received from the mobile station.

SM RP OA:

See definition in subclause 7.6.8.

The MSISDN received from the VLR or from the SGSN is inserted in this parameter in the mobile originated SM transfer.

SM RP UI:

See definition in subclause 7.6.8. The short message transfer protocol data unit received from the Service Centre is inserted in this parameter.

IMSI:

See definition in subclause 7.6.2.1. The IMSI of the originating subscriber is inserted in this parameter in the mobile originated SM transfer.

This parameter shall be included if the sending entity, whether MSC or SGSN, supports mobile number portability.

User error:

The following errors defined in subclause 7.6.1 may be used, depending on the nature of the fault:

- Facility Not Supported;
- System Failure;
- SM Delivery Failure;
 - The reason of the SM Delivery Failure can be one of the following in the mobile originated SM:
 - unknown Service Centre address;
 - Service Centre congestion;
 - invalid Short Message Entity address;
 - subscriber not Service Centre subscriber;
 - protocol error.
- Unexpected Data Value

Provider error:

For definition of provider errors see subclause 7.6.1.

12.3 MAP-REPORT-SM-DELIVERY-STATUS service

12.3.1 Definition

This service is used between the gateway MSC and the HLR. The MAP-REPORT-SM-DELIVERY-STATUS service is used to set the Message Waiting Data into the HLR or to inform the HLR of successful SM transfer after polling. This service is invoked by the gateway MSC.

The MAP-REPORT-SM-DELIVERY-STATUS service is a confirmed service using the service primitives given in table 12.3/1.

12.3.2 Service primitives

The service primitives are shown in table 12.3/1.

Table 12.3/1: MAP-REPORT-SM-DELIVERY-STATUS

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)		
MSISDN	M	M(=)		
Service Centre Address	M	M(=)		
SM Delivery Outcome	M	M(=)		
Absent Subscriber	C	C(=)		
Diagnostic SM				
GPRS Support Indicator	C	C(=)		
Delivery Outcome Indicator	C	C(=)		
Additional SM Delivery Outcome	C	C(=)		
Additional Absent Subscriber	C	C(=)		
Diagnostic SM				
MSIsdn-Alert			C	C(=)
User error			C	C(=)
Provider error				O

12.3.3 Parameter use

Invoke id:

See definition in subclause 7.6.1.

MSISDN:

See definition in subclause 7.6.2.

Service Centre Address:

See definition in subclause 7.6.2.

SM Delivery Outcome:

See definition in subclause 7.6.8. This parameter indicates the status of the mobile terminated SM delivery.

Absent Subscriber Diagnostic SM:

See definition in subclause 7.6.8.

GPRS Support Indicator:

See definition in subclause 7.6.8. The presence of this parameter is mandatory if the SMS-GMSC supports handling of two delivery outcomes.

Delivery Outcome Indicator:

See definition in subclause 7.6.8.

Additional SM Delivery Outcome:

See definition in subclause 7.6.8.

Additional Absent Subscriber Diagnostic SM:

See definition in subclause 7.6.8.

MSIsdn-Alert:

See definition in subclause 7.6.2. This parameter shall be present in case of unsuccessful delivery, when the MSISDN received in the operation is different from the stored MSIsdn-Alert; the stored MSIsdn-Alert is the value that is returned to the gateway MSC.

User error:

The following errors defined in subclause 7.6.1 may be used, depending on the nature of the fault:

- Unknown Subscriber;
- Message Waiting List Full;
- Unexpected Data Value;
- Data missing.

Provider error:

For definition of provider errors see subclause 7.6.1.

12.4 MAP-READY-FOR-SM service

12.4.1 Definition

This service is used between the MSC and VLR and as well between the VLR and the HLR. The MSC initiates this service if a subscriber indicates memory available situation. The VLR uses the service to indicate this to the HLR.

The VLR initiates this service if a subscriber, whose message waiting flag is active in the VLR, has radio contact in the MSC.

Also this service is used between the SGSN and the HLR. The SGSN initiates this service if a subscriber indicates memory available situation. The SGSN uses the service to indicate this to the HLR.

The SGSN initiates this service if a subscriber, whose message waiting flag is active in the SGSN, has radio contact in the GPRS.

The MAP-READY-FOR-SM service is a confirmed service using the primitives from table 12.4/1.

12.4.2 Service primitives

The service primitives are shown in table 12.4/1.

Table 12.4/1: MAP-READY-FOR-SM

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	C	C(=)		
TMSI	C	C(=)		
Alert Reason	M	M(=)		
Alert Reason Indicator	C	C(=)		
User error			C	C(=)
Provider error				O

12.4.3 Parameter use

Invoke id:

See definition in subclause 7.6.1.

See definition in subclause 7.6.2. The IMSI is used always between the VLR and the HLR and between the SGSN and the HLR. Between the MSC and the VLR the identification can be either IMSI or TMSI.

TMSI:

See definition in subclause 7.6.2. The identification can be either IMSI or TMSI between MSC and VLR.

Alert Reason:

See definition in subclause 7.6.8. This parameter indicates if the mobile subscriber is present or the MS has memory available.

Alert Reason Indicator:

See definition in subclause 7.6.8.

User error:

The following errors defined in subclause 7.6.1 may be used, depending on the nature of the fault:

- Unknown Subscriber;
- Facility Not Supported;
- System Failure;
- Unexpected Data Value;
- Data missing;

Provider error:

For definition of provider errors see subclause 7.6.1.

12.5 MAP-ALERT-SERVICE-CENTRE service

12.5.1 Definition

This service is used between the HLR and the interworking MSC. The HLR initiates this service, if the HLR detects that a subscriber, whose MSISDN is in the Message Waiting Data file, is active or the MS has memory available.

The MAP-ALERT-SERVICE-CENTRE service is a confirmed service using the primitives from table 12.5/1.

12.5.2 Service primitives

The service primitives are shown in table 12.5/1.

Table 12.5/1: MAP-ALERT-SERVICE-CENTRE

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)		
MSIsdn-Alert	M	M(=)		
Service Centre Address	M	M(=)		
User error			C	
Provider error				C(=) O

12.5.3 Parameter use

Invoke id:

See definition in subclause 7.6.1.

MSIsdn-Alert:

See definition in subclause 7.6.2. The provided MSISDN shall be the one which is stored in the Message Waiting Data file.

Service Centre Address:

See definition in subclause 7.6.2.

User error:

The following errors defined in subclause 7.6.1 may be used, depending on the nature of the fault:

- System Failure;
- Unexpected Data Value;
- Data missing.

Provider error:

For definition of provider errors see subclause 7.6.1.

12.6 MAP-INFORM-SERVICE-CENTRE service

12.6.1 Definition

This service is used between the HLR and the gateway MSC to inform the Service Centre which MSISDN number is stored in the Message Waiting Data file. If the stored MSISDN number is not the same than the one received from the gateway MSC in the MAP-SEND-ROUTING-INFO-FOR-SM service primitive the stored MSISDN number is included in the message.

Additionally the status of MCEF, MNRF and MNRG flags and the inclusion of the particular Service Centre address in the Message Waiting Data list is informed to the gateway MSC when appropriate.

The MAP-INFORM-SERVICE-CENTRE service is a non-confirmed service using the primitives from table 12.6/1.

12.6.2 Service primitives

The service primitives are shown in table 12.6/1.

Table 12.6/1: MAP-INFORM-SERVICE-CENTRE

Parameter name	Request	Indication
Invoke Id	M	M(=)
MSIsdn-Alert	C	C(=)
MWD Status	C	C(=)

12.6.3 Parameter use

Invoke id:

See definition in subclause 7.6.1.

MSIsdn-Alert:

See definition in subclause 7.6.2 This parameter refers to the MSISDN stored in a Message Waiting Data file in the HLR.

MWD Status:

See definition in subclause 7.6.8. This parameter indicates the status of the MCEF, MNRF and MNRG flags and the status of the particular SC address presence in the Message Waiting Data list.

12.7 MAP-SEND-INFO-FOR-MT-SMS service

12.7.1 Definition

This service is used between the MSC and the VLR. The service is invoked by the MSC receiving an mobile terminated short message to request subscriber related information from the VLR.

The MAP-SEND-INFO-FOR-MT-SMS service is a confirmed service using the primitives from table 12.7/1.

12.7.2 Service primitives

The service primitives are shown in table 12.7/1.

Table 12.7/1: MAP-SEND-INFO-FOR-MT-SMS

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
SM RP DA	M	M(=)		
MSISDN			C	C(=)
User error			C	C(=)
Provider error			O	

12.7.3 Parameter use

Invoke id:

See definition in subclause 7.6.1.

SM RP DA:

See definition in subclause 7.6.8. This parameter shall contain either an IMSI or a LMSI.

MSISDN:

See definition in subclause 7.6.2.

User error:

The following errors defined in subclause 7.6.1 may be used, depending on the nature of the fault:

- Unknown subscriber;
- Unidentified Subscriber;
- Absent subscriber;
- Unexpected Data Value;
- Data Missing;
- Illegal subscriber;
- Illegal equipment;
- Subscriber busy for MT SMS;
- System Failure.

Provider error:

For definition of provider errors see subclause 7.6.1.

12.8 MAP-SEND-INFO-FOR-MO-SMS service

12.8.1 Definition

This service is used between the MSC and the VLR. The service is invoked by the MSC which has to handle a mobile originated short message request to request the subscriber related information from the VLR.

The MAP-SEND-INFO-FOR-MO-SMS service is a confirmed service using the primitives from table 12.8/1.

12.8.2 Service primitives

The service primitives are shown in table 12.8/1.

Table 12.8/1: MAP-SEND-INFO-FOR-MO-SMS

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
Service Centre Address	M	M(=)		
MSISDN			C	C(=)
User error			C	C(=)
Provider error			O	

12.8.3 Parameter use

Invoke id:

See definition in subclause 7.6.1.

Service Centre Address:

See definition in subclause 7.6.2.

MSISDN:

See definition in subclause 7.6.2.

User error:

The following errors defined in subclause 7.6.1 may be used, depending on the nature of the fault:

- Teleservice Not Provisioned;
- Call Barred;
- Unexpected Data Value;
- Data Missing.

Provider error:

For definition of provider errors see subclause 7.6.1.

12.9 MAP-MT-FORWARD-SHORT-MESSAGE service

12.9.1 Definition

This service is used between the gateway MSC and the servicing MSC or the SGSN to forward mobile terminated short messages.

The MAP-MT-FORWARD-SHORT-MESSAGE service is a confirmed service using the service primitives given in table 12.9/1.

12.9.2 Service primitives

The service primitives are shown in table 12.9/1.

Table 12.9/1: MAP-MT-FORWARD-SHORT-MESSAGE

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)		
SM RP DA	M	M(=)		
SM RP OA	M	M(=)		
SM RP UI	M	M(=)	C	C(=)
More Messages To Send	C	C(=)	C	C(=)
User error				O
Provider error				

12.9.3 Parameter use

Invoke id:

See definition in subclause 7.6.1.

SM RP DA:

See definition in subclause 7.6.8. This parameter can contain either an IMSI or a LMSI. The use of the LMSI is an operator option. The LMSI can be provided if it is received from the HLR. The IMSI is used if the use of the LMSI is not available.

This parameter is omitted in the mobile terminated subsequent SM transfers.

SM RP OA:

See definition in subclause 7.6.8. The Service Centre address received from the originating Service Centre is inserted in this parameter.

This parameter is omitted in the mobile terminated subsequent SM transfers.

SM RP UI:

See definition in subclause 7.6.8. The short message transfer protocol data unit received from the Service Centre is inserted in this parameter. A short message transfer protocol data unit may also be inserted in this parameter in the message delivery acknowledgement from the MSC or from the SGSN to the Service Centre.

More Messages To Send:

See definition in subclause 7.6.8. The information from the MMS indication received from the Service Centre is inserted in this parameter.

User error:

The following errors defined in subclause 7.6.1 may be used, depending on the nature of the fault:

- Unidentified subscriber;
- Absent Subscriber_SM;
- Subscriber busy for MT SMS;
- Facility Not Supported;
- Illegal Subscriber indicates that delivery of the mobile terminated short message failed because the mobile station failed authentication;
- Illegal equipment indicates that delivery of the mobile terminated short message failed because an IMEI check failed, i.e. the IMEI was blacklisted or not white-listed;

- System Failure;
- SM Delivery Failure;
 - The reason of the SM Delivery Failure can be one of the following in the mobile terminated SM:
 - memory capacity exceeded in the mobile equipment;
 - protocol error;
 - mobile equipment does not support the mobile terminated short message service.
- Unexpected Data Value;
- Data Missing.

Provider error:

For definition of provider errors see subclause 7.6.1.

13 Network-Requested PDP Context Activation services

13.1 MAP_SEND_ROUTING_INFO_FOR_GPRS service

13.1.1 Definition

This service is used by the GGSN to request GPRS routing information from the HLR.

13.1.2 Service primitives

Table 13.1/1: MAP_SEND_ROUTING_INFO_FOR_GPRS

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
GGSN address	C	C(=)	C	C(=)
GGSN number	M	M(=)		
SGSN address			C	C(=)
Mobile Not Reachable Reason			C	C(=)
User error			C	C(=)
Provider error				O

13.1.3 Parameter definition and use

Invoke Id

See definition in subclause 7.6.1.

IMSI

See definition in subclause 7.6.2.

GGSN address

This parameter shall be present if the protocol-converting GSN is used between the GGSN and the HLR.

GGSN number

See definition in subclause 7.6.2.

GGSN address

This parameter shall be present if the outcome of the Send Routing Info For GPRS request to the GPRS application process in the HLR is positive.

Mobile Not Reachable Reason

This parameter shall be present if the outcome of the Send Routing Info For GPRS request to the GPRS application process in the HLR is positive and the MNRG flag in the HLR is set. See definition in subclause 7.6.3.51.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Absent Subscriber;
- System Failure;
- Data Missing;
- Unexpected Data Value;
- UnknownSubscriber.

The diagnostic in the Unknown Subscriber may indicate “Imsi Unknown” or “Gprs Subscription Unknown”.

Provider error

These are defined in subclause 7.6.1.

13.2 MAP_FAILURE_REPORT service

13.2.1 Definition

This service is used by the GGSN to inform the HLR that network requested PDP-context activation has failed.

13.2.2 Service primitives

Table 13.2/1: MAP_FAILURE_REPORT

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
GGSN address	C	C(=)	C	C(=)
GGSN number	M	M(=)		
User error			C	C(=)
Provider error				O

13.2.3 Parameter definition and use

Invoke Id

See definition in subclause 7.6.1.

IMSI

See definition in subclause 7.6.2.

GGSN address

This parameter shall be present if the protocol-converting GSN is used between the GGSN and the HLR.

GGSN number

See definition in subclause 7.6.2.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- System Failure;
- Data Missing;
- Unexpected Data Value;
- UnknownSubscriber.

Provider error

These are defined in subclause 7.6.1.

13.3 MAP_NOTE_MS_PRESENT_FOR_GPRS service

13.3.1 Definition

This service is used by the HLR to inform the GGSN that the MS is present for GPRS again.

13.3.2 Service primitives

Table 13.3/1: MAP_NOTE_MS_PRESENT_FOR_GPRS

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
GGSN address	C	C(=)		
SGSN address	M	M(=)		
User error			C	C(=)
Provider error				O

13.3.3 Parameter definition and use

Invoke Id

See definition in subclause 7.6.1.

IMSI

See definition in subclause 7.6.2.

GGSN address

This parameter shall be present if the protocol-converting GSN is used between the GGSN and the HLR.

SGSN address

See definition in subclause 7.6.2.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- System Failure;

- Data Missing;
- Unexpected Data Value;
- UnknownSubscriber.

Provider error

These are defined in subclause 7.6.1.

13A Location Service Management Services

13A.1 MAP-SEND-ROUTING-INFO-FOR-LCS Service

13A.1.1 Definition

This service is used between the GMLC and the HLR to retrieve the routing information needed for routing a location service request to the servicing VMSC. The MAP-SEND-ROUTING-INFO-FOR-LCS is a confirmed service using the primitives from table A.1/1.

13A.1.2 Service Primitives

The service primitives are shown in table 13A.1/1.

Table 13A.1/1: MAP-SEND-ROUTING-INFO-FOR-LCS

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
MLC Number	M	M(=)		
MSISDN	C	C(=)	C	C(=)
IMSI	C	C(=)	C	C(=)
LMSI			C	C(=)
MSC Number			C	C(=)
User error			C	C(=)
Provider error				O

13A.1.3 Parameter Use

Invoke id:

See definition in subclause 7.6.1.

MLC Number:

See definition in subclause 7.6.2.

MSISDN:

See definition in subclause 7.6.2. The request shall carry either the IMSI or MSISDN. The response shall carry whichever of these was not included in the request (see GSM 03.71 for details).

IMSI:

See definition in subclause 7.6.2.

LMSI:

See definition in subclause 7.6.2. It is an operator option to provide this parameter from the VLR; it is mandatory for the HLR to include the LMSI in a successful response, if the VLR has used the LMSI.

MSC Number:

See definition in subclause 7.6.2. This parameter is provided in a successful response.

User error:

The following errors defined in subclause 7.6.1 may be used, depending on the nature of the fault:

- Unknown subscriber;
- Absent Subscriber;
- Facility Not Supported;
- System failure;
- Unexpected Data Value;
- Data missing;
- Unauthorized requesting network

Provider error:

For definition of provider errors see subclause 7.6.1.

13A.2 MAP-PROVIDE-SUBSCRIBER-LOCATION Service

13A.2.1 Definition

This service is used by a GMLC to request the location of a target MS from the visited MSC at any time. This is a confirmed service using the primitives from table 13A.2/1.

13A.2.2 Service Primitives

Table 13A.2/1: Provide_Subscriber_Location

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
Location Type	M	M(=)		
MLC Number	M	M(=)		
LCS Client ID	M	M(=)		
Privacy Override	U	C(=)		
IMSI	C	C(=)		
MSISDN	C	C(=)		
LMSI	C	C(=)		
LCS Priority	C	C(=)		
LCS QoS	C	C(=)		
IMEI	U	C(=)		
Location Estimate			M	M(=)
Age of Location Estimate			C	C(=)
User error			C	C(=)
Provider error				O

13A.2.3 Parameter Definition and Use

All parameters are defined in section 7.6. The use of these parameters and the requirements for their presence are specified in GSM 03.71.

Location Type

This parameter identifies the type of location information requested

MLC Number

This is the E.164 number of the requesting GMLC.

LCS Client ID

This parameter provides information related to the identity of an LCS client.

Privacy Override

This parameter indicates if MS privacy is overridden by the LCS client when the GMLC and VMSC for an MR-LR are in the same country.

IMSI

The IMSI is provided to identify the target MS. At least one of the IMSI or MSISDN is mandatory.

MSISDN

The MSISDN is provided to identify the target MS. At least one of the IMSI or MSISDN is mandatory.

LMSI

The LMSI shall be provided if previously supplied by the HLR

LCS Priority

This parameter indicates the priority of the location request.

LCS QoS

This parameter indicates the required quality of service in terms of response time and accuracy.

IMEI

Inclusion of the IMEI is optional.

Location Estimate

This parameter provides the location estimate.

Age of Location Estimate

This parameter indicates how long ago the location estimate was obtained.

User error

This parameter is sent by the responder when the location request has failed or cannot proceed and if present, takes one of the following values defined in section 7.6.1:

- System Failure;
- Data Missing;
- Unexpected Data Value;
- Facility Not Supported;
- Unidentified Subscriber;
- Illegal Subscriber;
- Illegal Equipment;
- Absent Subscriber (diagnostic information may also be provided);
- Unauthorized requesting network;
- Unauthorized LCS Client with detailed reason;
- Position method failure with detailed reason.

Provider error

These are defined in subclause 7.6.1.

13A.3 MAP-SUBSCRIBER-LOCATION-REPORT Service

13A.3.1 Definition

This service is used by a VMSC to provide the location of a target MS to a GMLC when a request for location is either implicitly administered or made at some earlier time. This is a confirmed service using the primitives from table 13A.3/1.

13A.3.2 Service Primitives

Table 13A.3/1: Subscriber_Location_Report

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
LCS Event	M	M(=)		
LCS Client ID	M	M(=)		
MSC Number	M	M(=)		
IMSI	C	C(=)		
MSISDN	C	C(=)		
NA-ESRD	C	C(=)		
NA-ESRK	C	C(=)		
IMEI	U	C(=)		
Location Estimate	C	C(=)		
Age of Location Estimate	C	C(=)		
LMSI	U	C(=)		
User error			C	C(=)
Provider error				O

13A.3.3 Parameter Definition and Use

All parameters are defined in section 7.6. The use of these parameters and the requirements for their presence are specified in GSM 03.71.

LCS Event

This parameter indicates the event that triggered the Subscriber Location Report.

LCS Client ID

This parameter provides information related to the identity of the recipient LCS client.

MSC Number

See definition in subclause 7.6.2. This parameter provides the address of the visited MSC for target MS.

IMSI

The IMSI shall be provided if available to the VMSC

MSISDN

The MSISDN shall be provided if available to the VMSC

NA-ESRD

If the target MS has originated an emergency service call in North America, the NA-ESRD shall be provided by the VMSC if available.

NA-ESRK

If the target MS has originated an emergency service call in North America, the NA-ESRK shall be provided by the VMSC if assigned.

IMEI

Inclusion of the IMEI is optional.

Location Estimate

This parameter provides the location estimate. The absence of this parameter implies that a location estimate was not available or could not be successfully obtained.

Age of Location Estimate

This parameter indicates how long ago the location estimate was obtained.

LMSI

The LMSI may be provided if assigned by the VLR.

User error

This parameter is sent by the responder when the received message contains an error, cannot be forwarded or stored for an LCS client or cannot be accepted for some other reason and if present, takes one of the following values defined in section 7.6.1.

- System Failure;
- Data Missing;
- Unexpected Data Value;
- Resource Limitation;
- Unknown Subscriber;
- Unauthorized requesting network;
- Unknown or unreachable LCS Client;
- Provider error

These are defined in subclause 7.6.1.

13A.4 Void

13A.4.1 - 13A.4.3 Void

13A.5 Void

13A.5.1 - 13A.5.3 Void

13A.6 Void

13A.6.1 - 13A.6.3 Void

13A.7 Void

13A.7.1 - 13A.7.3 Void

13A.8 Void

13A.8.1 - 13A.8.3 Void

13A.9 Void

13A.9.1 - 13A.9.3 Void

14 General

14.1 Overview

Clauses 14 to 17 specify the protocol elements to be used to provide the MAP services described in clause 7.

Clause 15 specifies the elements of procedures for the MAP protocol. Clause 16 specifies the mapping on to TC service primitives. Clause 17 specifies the application contexts, operation packages and abstract syntaxes for the MAP protocol as well as the encoding rules to be applied.

14.2 Underlying services

The MAP protocol relies on the services provided by the Transaction Capabilities (TC) of signalling system number 7, as referenced in clause 6.

14.3 Model

The MAP Protocol Machine (MAP PM) can be modelled as a collection of service state machines (SSMs) - one per MAP specific service invoked - coordinated by a MAP dialogue control function with its one state machine: MAP dialogue state machine (DSM). There are two types of Service State Machines: Requesting Service State Machines (RSM) and Performing Service State Machines (PSM).

A new invocation of a MAP PM is employed on the receipt of a MAP-OPEN request primitive or a TC-BEGIN indication primitive. Each invocation controls exactly one MAP dialogue. For each MAP specific service invoked during a dialogue, a MAP RSM is created at the requestor's side and a MAP PSM is created at the performer's side.

This modelling is used only to facilitate understanding and the MAP behaviour descriptions and is not intended to suggest any implementation. SDL descriptions are organized according to this model.

How the MAP-service-user and the MAP refer to a MAP dialogue (i.e. a MAP PM invocation) is a local implementation matter.

How TC dialogue identifiers are assigned to a MAP PM invocation is also a local implementation matter.

14.4 Conventions

The behaviour of the MAP PM depends on the application-context-name associated with the dialogue. One major difference is that the MAP requests the transfer of the application-context-name by TC only for those contexts which do not belong to the so-called "version one context set".

The "version one context set" is a set of application-contexts which model the behaviour of a MAP V1 implementation according to the latest phase 1 version of GSM 09.02. This set is defined in clause 15.

The procedures described in clause 15 are used when the application-context-name does not refer to a dialogue between an MSC and its VLR. When the application-context-name refers to a dialogue between an MSC and its VLR the MAP PM procedures are a local implementation matter.

15 Elements of procedure

15.1 Dialogue establishment

The establishment of a MAP dialogue involves two MAP-service-users, one that is the dialogue-initiator and one that is the dialogue-responder.

This procedure is driven by the following signals:

- a MAP-OPEN request primitive from the dialogue-initiator;
- a TC-BEGIN indication primitive occurring at the responding side;
- a MAP-OPEN response primitive from the dialogue-responder;
- the first TC-CONTINUE indication primitive occurring at the initiating side;

and under specific conditions:

- a TC-END indication primitive occurring at the initiating side;
- a TC-U-ABORT indication primitive occurring at the initiating side;
- a TC-P-ABORT indication primitive occurring at the initiating side.

15.1.1 Handling of unknown operations

Unknown operations (i.e. a standard operation introduced in a later version of GSM 09.02 or a private operation) can be introduced in MAP in a backwards compatible way. This means, that the receiver of an unknown operation shall, if the dialogue state allows it, send a TC-REJECT component to the sender of the operation indicating 'unrecognised operation' and continue with the processing of further components or messages exchanged within the dialogue as if the unknown operation had not been received.

The standardised structure of a MAP dialogue shall not be affected by the invocation of unknown operations, i.e. if a dialogue uses only a TC-BEGIN message which is acknowledged by a TC-END message, a TC-CONTINUE message

shall not be used to invoke an unknown operation. However the standardised structure of a MAP dialogue may be affected by the rejection of unknown operations, i.e. if a dialogue uses only a TC-BEGIN message which is acknowledged by a TC-END message, a TC-CONTINUE message followed by a TC-END message may be used to carry the rejection of an unknown operation and the response to the standardised operation. The entity which initiated a dialogue whose standardised structure is a TC-BEGIN message which is acknowledged by a TC-END message shall not send any messages in that dialogue after the TC-BEGIN.

Note that if the dialogue structure is affected as described in this paragraph the TC-CONTINUE shall include the dialogue portion required to confirm the acceptance of the dialogue.

Unknown operations can be invoked in the following types of messages (there is no restriction as to how many unknown operations can be invoked in a message):

- TC-BEGIN the component to invoke the unknown operation shall follow the component of the standard operation that is included in this message.
- TC-CONTINUE: the component to invoke the unknown operation may be transported as the only component in a stand-alone message or can be grouped with existing operations. In the latter case a specific sequencing of components is not required.
- TC-END: if the component to invoke the unknown operation is grouped with an existing operation a specific sequencing of components is not required.

The TC-REJECT component may be sent in the following messages:

- TC-CONTINUE or TC-END: either as the only component of the message or grouped with an existing component. The choice is up to the MAP-Service User.

If the received message contains only unknown operations the MAP-Service User shall send the TC-REJECT components in a TC-CONTINUE message to the peer entity, if the dialogue state allows it.

If the received message contains unknown operations and standard operations and the standardised structure of the dialogue requires the response to the standard operation to be sent within a TC-END message, then the MAP-Service User may send the response to the standard operations and the TC-REJECT components for the unknown operations in a TC-CONTINUE message followed by a TC-END message. A specific distribution of the components to the TC messages or a specific sequencing of components is not required.

Note that SDLs of chapters 19 - 25 do not show the report to the MAP-Service User about the reception of the unknown operation. This has been done for the sake of simplicity of description; the MAP PM may inform the MAP-Service User.

The sender of the unknown operation shall ensure that there is enough room in the used message for the unknown operation.

15.1.2 Receipt of a MAP-OPEN request primitive

On receipt of a MAP-OPEN request primitive the behaviour of the MAP PM shall be as follows:

The MAP PM shall accept zero, one or several user request primitives until a MAP-DELIMITER request primitive is received.

For each user request primitive, the MAP PM shall request the invocation of the associated operation using the TC-INVOKE service. See subclause 15.6 for a description of the associated SSMs.

On receipt of the MAP-DELIMITER request primitive the MAP PM shall issue a TC-BEGIN request primitive. The application-context-name as well as the user information parameter (if any) shall be mapped to the corresponding TC-BEGIN parameters.

The requesting MAP PM waits for a TC indication primitive and does not accept any other primitive from its user, except a MAP-U-ABORT request or a MAP-CLOSE request.

15.1.3 Receipt of a TC-BEGIN indication

On receipt of a TC-BEGIN indication primitive, the MAP PM shall:

- if no application-context-name is included in the primitive and if the "Components present" indicator indicates "no components", issue a TC-U-ABORT request primitive (note 2). The local MAP-User is not informed.
- if no application-context-name is included in the primitive and if presence of components is indicated, wait for the first TC-INVOKE primitive, and derive a version 1 application-context-name from the operation code according to table 15.1/1 (note 1).

NOTE 1: In some cases, it may be necessary to analyse the operation argument.

Then:

- a) if no application-context-name can be derived (i.e. the operation code does not exist in MAP V1 specifications), the MAP PM shall issue a TC-U-ABORT request primitive (note 2). The local MAP-User is not informed.
- b) if an application-context-name can be derived and if it is acceptable from a load control point of view, the MAP PM shall:
 - i) if this primitive requests the beginSubscriberActivity operation, the MAP PM shall check whether more components have been received associated with this operation. If more components are present, the MAP PM shall issue a MAP-OPEN indication primitive with the version 1 application-context-name "networkFunctionalSsContext-v1". The Destination-reference shall include the IMSI taken from the argument of the beginSubscriberActivity operation; the Originating-reference shall cover the originatingEntityNumber.

A beginSubscriberActivity operation that is not associated with any other Component shall be rejected by the MAP PM by issuing a TC-U-ABORT request primitive (note 2). The local MAP-User shall not be informed.

- ii) otherwise, the MAP PM shall issue a MAP-OPEN indication primitive with the version 1 application-context-name set according to table 15.1/1. DestinationReference and OriginatingReference must not be included in the MAP-OPEN indication primitive.

Then the MAP PM shall function in a way that the dialogue responding MAP behaves as specified in the GSM phase 1 protocol (latest version of TS GSM 09.02 phase 1).

NOTE 2: If no AARQ apdu was included in the BEGIN message, TC (Component Sub-layer) will not include an AARE apdu or an ABRT apdu in a TR-U-ABORT request primitive that is to be issued on receipt of a TC-U-ABORT request primitive from the local MAP service provider.

- c) if an application-context-name can be derived but if it is not acceptable from a load control point of view, the MAP PM shall ignore this dialogue request and not inform the MAP-user;
- if a version 1 application-context-name is included, the MAP PM shall issue a TC-U-ABORT request primitive with abort-reason "User-specific" and user-information "MAP-ProviderAbortInfo" indicating "abnormalDialogue". The local MAP-user shall not be informed.
- if an application-context-name different from version 1 is included in the primitive and if User-information is present, the User-information must constitute a syntactically correct MAP-OPEN dialogue PDU. Otherwise a TC-U-ABORT request primitive with abort-reason "User-specific" and user-information "MAP-ProviderAbortInfo" indicating "abnormalDialogue" shall be issued and the local MAP-user shall not be informed.
- if no User-information is present it is checked whether presence of User Information in the TC-BEGIN indication primitive is required for the received application-context-name. If User Information is required but not present, a TC-U-ABORT request primitive with abort-reason "User-specific" and user-information "MAP-ProviderAbortInfo" indicating "abnormalDialogue" shall be issued. The local MAP-user shall not be informed.

- if an application-context-name different from version 1 is received in a syntactically correct TC-BEGIN indication primitive but is not acceptable from a load control point of view, the MAP PM shall ignore this dialogue request. The MAP-user is not informed.
- if an application-context-name different from version 1 is received in a syntactically correct TC-BEGIN indication primitive and if it is acceptable from a load control point of view, the MAP PM shall check whether the application-context-name is supported.

NOTE 3: Unknown application-context-names are treated like unsupported ones.

If it is, the MAP PM shall issue a MAP-OPEN indication primitive with all parameters (application-context-name included) set according to the value of the corresponding parameter of the TC-BEGIN indication primitive.

The MAP PM shall then process any other indication primitives received from TC as described in subclause 15.6. Once all the received components have been processed, the MAP PM shall inform the local MAP service user by a MAP-DELIMITER indication primitive.

If the TC-BEGIN indication primitive is not associated with any component, the MAP PM shall inform the MAP User by a MAP-DELIMITER indication primitive.

Once all the received primitives have been processed, the MAP PM does not accept any primitive from the provider and waits for a MAP-OPEN response primitive from its user.

- if an application-context-name different from version 1 is received in a syntactically correct TC-BEGIN indication primitive and if it is acceptable from a load control point of view but the application-context-name is not supported, the MAP PM shall issue a TC-U-ABORT request primitive with abort-reason indicating "application-context-not-supported". If an alternative application-context-name cannot be offered, the received application-context-name shall be returned in the TC-U-ABORT Req primitive.

In the following cases an alternative application-context can be offered and its name included in the TC-U-ABORT Req primitive:

- a) if an application-context of version 2 or higher is requested, but only version 1 application-context supported, then the v1 application context shall be returned;
- b) if an application-context of version 3 or higher is requested, but only version 2 application-context supported, then the v2 application context shall be returned.
- c) if an application-context of version 4 or higher is requested, but only version 3 application-context supported, then the v3 application context shall be returned.

Table 15.1/1: Mapping of V1 operation codes on to application-context-names

Operation	Application-context-name (note 1)
updateLocation	networkLocUpContext-v1
cancelLocation	locationCancellationContext-v1
provideRoamingNumber	roamingNumberEnquiryContext-v1
insertSubscriberData	subscriberDataMngtContext-v1
deleteSubscriberData	subscriberDataMngtContext-v1
sendParameters	infoRetrievalContext-v1 networkLocUpContext-v1 (note 2)
beginSubscriberActivity	networkFunctionalSsContext-v1
sendRoutingInfo	locationInfoRetrievalContext-v1
performHandover	handoverControlContext-v1
reset	resetContext-v1
activateTraceMode	tracingContext-v1
deactivateTraceMode	tracingContext-v1
sendRoutingInfoForSM	shortMsgGatewayContext-v1
forwardSM	shortMsgRelayContext-v1
reportSM-deliveryStatus	shortMsgGatewayContext-v1
noteSubscriberPresent	mwdMngtContext-v1
alertServiceCentreWithoutResult	shortMsgAlertContext-v1
checkIMEI	EquipmentMngtContext-v1
NOTE 1: These symbolic names refer to the object identifier value defined in clause 17 and allocated to each application-context used for the MAP.	
NOTE 2: The choice between the application contexts is based on the parameters received in the operation.	

15.1.4 Receipt of a MAP-OPEN response

On receipt of a MAP-OPEN response primitive indicating that the dialogue is accepted, the MAP PM shall build a MAP-Accept PDU if the user-information parameter is included in the response primitive and accept any MAP specific service request or service response until a MAP-DELIMITER request or a MAP-CLOSE request is received from the MAP user. The MAP PM shall process the MAP specific primitives as described in subclause 15.6. The MAP PM shall then issue a TC-CONTINUE request primitive after it receives the MAP-DELIMITER request primitive if no MAP-CLOSE request primitive has been received, otherwise it shall issue a TC-END request primitive. In both cases the MAP-Accept PDU (if any) is included in the user-information parameter of the TC primitive.

If the dialogue is not associated with a version 1 application context, the MAP PM shall include the application-context-name in the TC primitive.

If no MAP-CLOSE request has been received, the MAP PM waits for a request primitive from its user or an indication primitive from TC.

On receipt of a MAP-OPEN response primitive indicating that the dialogue is not accepted, the MAP PM shall build a MAP-Refuse PDU and request its transfer using the TC-U-ABORT req primitive (abort reason = user specific).

15.1.5 Receipt of the first TC-CONTINUE ind

On receipt of the first TC-CONTINUE indication primitive for a dialogue, the MAP PM shall check the value of the application-context-name parameter. If this value matches the one used in the MAP-OPEN request primitive, the MAP PM shall issue a MAP-OPEN confirm primitive with the result parameter indicating "accepted", then process the following TC component handling indication primitives as described in subclause 15.6, and then waits for a request primitive from its user or an indication primitive from TC, otherwise it shall issue a TC-U-ABORT request primitive with a MAP-providerAbort PDU indicating "abnormal dialogue" and a MAP-P-ABORT indication primitive with the "provider-reason" parameter indicating "abnormal dialogue".

15.1.6 Receipt of a TC-END ind

On receipt of a TC-END indication primitive in the dialogue initiated state, the MAP PM shall check the value of the application-context-name parameter. If this value does not match the one used in the MAP-OPEN request primitive, the

MAP PM shall discard any following component handling primitive and shall issue a MAP-P-ABORT indication primitive with the "provider-reason" parameter indicating "abnormal dialogue".

Otherwise it shall issue a MAP-OPEN confirm primitive with the result parameter set to "accepted" and process the following TC component handling indication primitives as described in subclause 15.6; then it shall issue a MAP-CLOSE indication primitive and return to idle all state machines associated with the dialogue.

15.1.7 Receipt of a TC-U-ABORT ind

On receipt of a TC-U-ABORT indication primitive in the "Dialogue Initiated" state with an abort-reason parameter indicating "ApplicationContextNotSupported", the MAP PM shall issue a MAP-OPEN confirm primitive with the result parameter indicating "Dialogue Refused" and the refuse-reason parameter indicating "ApplicationContextNotSupported".

On receipt of a TC-U-ABORT indication primitive in the "Dialogue Initiated" state with an abort-reason parameter indicating "User Specific" and without user information, the MAP PM shall issue a MAP-OPEN confirm primitive with the result parameter indicating "Dialogue Refused" and the refuse-reason parameter indicating "Potential Version Incompatibility".

On receipt of a TC-U-ABORT indication primitive in the "Dialogue Initiated" state with an abort-reason parameter indicating "User Specific" and a MAP-Refuse PDU included as user information, the MAP PM shall issue a MAP-OPEN confirm primitive with the result set to refused and the refuse reason set as received in the MAP Refuse PDU.

Receipt of a TC-U-ABORT indication primitive with abort-reason "User Specific" and with user information is described as part of abnormal termination (see subclause 15.4.2).

15.1.8 Receipt of a TC-P-ABORT ind

On receipt of a TC-P-ABORT indication primitive in the "Dialogue Initiated" state with a P-abort parameter indicating "Incorrect Transaction Portion", the MAP PM shall issue a MAP-OPEN confirm primitive with the result parameter indicating "Dialogue Refused" and the refuse reason parameter indicating "Potential Version Incompatibility".

On receipt of a TC-P-ABORT indication primitive in the "Dialogue Initiated" state with a P-abort parameter indicating "No Common Dialogue Portion", the MAP PM shall issue a MAP-P-ABORT indication primitive with the provider reason parameter indicating "Version Incompatibility".

Receipt of a TC-P-ABORT indication primitive with another P-abort parameter value is described as part of abnormal termination (see subclause 15.5.2).

15.2 Dialogue continuation

Once established the dialogue is said to be in a continuation phase.

Both MAP users can request the transfer of MAP APDUs until one of them requests the termination of the dialogue.

15.2.1 Sending entity

The MAP PM shall accept any MAP specific service request or response primitives and process them as described in subclause 15.6.

On receipt of a MAP-DELIMITER request primitive, the MAP PM shall issue a TC-CONTINUE request primitive.

15.2.2 Receiving entity

On receipt of a TC-CONTINUE indication primitive the MAP PM shall accept zero, one or several TC component handling indication primitives and process them as described in subclause 15.6.

15.3 Dialogue termination

Both the dialogue-initiator and the dialogue-responder have the ability to request the termination of a dialogue after it has been established.

The dialogue termination procedure is driven by the following events:

- a MAP-CLOSE request primitive;
- a TC-END indication primitive.

15.3.1 Receipt of a MAP-CLOSE request

On receipt of a MAP-CLOSE request primitive, the MAP PM shall issue a TC-END request primitive and, if applicable, return to idle the associated active SSMs. Note that if the release method parameter of the MAP-CLOSE request indicates "normal" the TC-END request primitive will trigger the transmission of components associated with any user specific request or response primitives which may have been issued after the last MAP-DELIMITER request.

15.3.2 Receipt of a TC-END indication

On receipt of a TC-END indication primitive, the MAP shall accept any component handling indication primitives and process them as described in subclause 15.6.

Once all the received primitives have been processed, the MAP PM shall return to idle the associated SSMs and issue a MAP-CLOSE indication primitive.

15.4 User Abort

Both the dialogue-initiator and the dialogue-responder have the ability to abort a dialogue at any time.

The user abort procedure is driven by one of the following events:

- a MAP-U-ABORT request primitive;
- a TC-U-ABORT indication primitive carrying a MAP-user-abort PDU.

15.4.1 MAP-U-ABORT request

On receipt of a MAP-U-ABORT request the MAP PM shall construct a MAP-user-abort PDU from the user-reason and diagnostic parameters and issue a TC-U-ABORT request primitive. All state machines associated with the dialogue are returned to idle.

15.4.2 TC-U-ABORT ind

On receipt of a TC-U-ABORT indication carrying a MAP-user-abort PDU, the MAP PM shall issue a MAP-U-ABORT indication primitive. The user-reason and diagnostic information elements are mapped to the corresponding parameters of the MAP-U-ABORT indication primitive.

All state machines associated with the dialogue are returned to idle.

15.5 Provider Abort

The MAP has the ability to abort a dialogue at both the dialogue-initiator side and the dialogue-responder side.

The provider abort procedure is driven by one of the following events:

- a MAP PM error situation;
- a TC-P-ABORT indication primitive;

- a TC-U-ABORT indication primitive carrying a MAP-abort PDU.

15.5.1 MAP PM error situation

In the case of an abnormal situation detected at the MAP level during an established dialogue, the MAP PM shall:

- issue a MAP-P-ABORT indication primitive with the appropriate value of the provider-reason parameter;
- construct a MAP-abort PDU from the value of these parameters and request its transfer using a TC-U-ABORT request primitive.

15.5.2 TC-P-ABORT ind

On receipt of a TC-P-ABORT indication, the MAP PM shall issue a MAP-P-ABORT indication primitive.

All state machines associated with the dialogue are returned to idle.

15.5.3 TC-U-ABORT ind

On receipt of a TC-U-ABORT indication carrying a MAP-abort PDU, the MAP PM shall issue a MAP-P-ABORT indication primitive, with the appropriate value of the provider-reason parameter. The source parameter shall indicate "MAP-provider".

All state machines associated with the dialogue are returned to idle.

15.6 Procedures for MAP specific services

This subclause describes the MAP procedures for MAP specific services.

These procedures are driven by the following types of events:

- a MAP specific request or a MAP specific MAP response primitive;
- a component handling primitive from TC.

A Service State Machine is activated on receipt of one of the following signals:

- a MAP request primitive, which activates a requesting SSM;
- a TC-INVOKE indication primitive without linked identifier, which activates a responding SSM.

For component handling primitives there are two types of events:

- events which activate a Service State Machine or which can be related to an existing one;
The procedure elements driven by these events are described in subclauses 15.6.1 to 15.6.4.
- events which cannot be related to a Service State Machine.

The procedure elements driven by these events are described in subclause 15.6.5.

15.6.1 Service invocation

The MAP specific procedures are initiated by the MAP request primitives.

On receipt of a MAP request primitive, the MAP PM shall build an operation argument from the parameters received in the request primitive and request the invocation of the associated operation using the TC-INVOKE procedure. If a linked ID parameter is inserted in the primitive this indicates a child service and implies that the operation on which the service is mapped is linked to the operation on which the parent service is mapped.

The mapping of MAP specific services on to remote operations is given in table 16.2/1.

15.6.2 Service invocation receipt

On receipt of a TC-INVOKE indication primitive, the MAP PM shall:

- if the invoke ID is already in use by an active service, request the transfer of a reject component using the TC-U-REJECT request primitive with the appropriate problem code (duplicated invokeID) and issue a MAP-NOTICE indication primitive with a diagnostic parameter set to "abnormal event received from the peer";
- if the operation code does not correspond to an operation supported by the application-context, request the transfer of a reject component using the TC-U-REJECT request primitive, with the appropriate problem code (unrecognized operation), and -if the dialogue version is lower than 3- issue a MAP-NOTICE indication primitive with a diagnostic parameter set to „abnormal event received from the peer“;
- if a linked ID is included, perform the following checks: If the operation referred to by the linked ID does not allow linked operations or if the operation code does not correspond to a permitted linked operation, issue a TC-U-REJECT request primitive with the appropriate problem code (linked response unexpected or unexpected linked operation);
- if the type of the argument is not the one defined for the operation, request the transfer of a reject component using the TC-U-REJECT request primitive, with the appropriate problem code (mistyped parameter), and issue a MAP-NOTICE indication primitive with a diagnostic parameter set to "abnormal event from the peer";
- if the type of the argument is correct but the values of the information elements it contains do not permit the type of MAP service being invoked to be determined, request the transfer of an error component using the TC-U-ERROR request primitive with an error code set to "unexpected data value" and issue a MAP-NOTICE indication primitive with a diagnostic parameter set to "abnormal event from the peer";

NOTE 1: These checks are only relevant when there is not a one-to-one mapping between a service and an operation.

- if the type of the argument is correct but information elements required for the service being invoked are missing, request the transfer of an error component using the TC-U-ERROR request primitive with an error code set to "data missing" and issue a MAP-NOTICE indication primitive with a diagnostic parameter set to "abnormal event from the peer";

NOTE 2: These checks are only relevant when there is not a one-to-one mapping between a service and an operation.

- if the type of the argument is correct but contains information elements which are not relevant for the type of MAP service being invoked, request the transfer of an error component using the TC-U-ERROR request primitive with an error code set to "unexpected data value" and issue a MAP-NOTICE indication primitive with a diagnostic parameter set to "abnormal event from the peer";

NOTE 3: These checks are only relevant when there is not a one-to-one mapping between a service and an operation.

- Otherwise, issue the relevant MAP indication primitive to the MAP-service-user. If the service is to be user confirmed, the MAP PM waits for the corresponding response primitive.

15.6.3 Service response

For user confirmed services, the MAP PM shall accept a MAP response primitive and shall:

- if no error indication is included in the primitive and the service maps on to a class 1 or 3 operation, construct a result information element from the parameters received and request its transfer using the TC-RESULT-L service and optionally the TC-RESULT-NL service.

The TC-RESULT-NL services shall be used when the user specific parameters of the response primitives cannot be transferred in a single signalling frame and no segmenting mechanism is available from the underlying layers. The MAP PM shall issue one or several TC-RESULT-NL request primitives followed by a TC-RESULT-L primitive. The user parameters shall be split so that each portion contains sufficient information to construct a value compatible with the type defined for the result of the associated operation.

- if no error indication is included in the primitive and the service response maps on to a class 4 linked operation, construct an operation argument from the parameters received and request its transfer using the TC-INVOKE service for this class 4 linked operation. The operation to be invoked is deduced from the value of the result parameter of the service primitive;
- if an error indication is included in the primitive and the service maps on to a class 1 or 2 operation, either issue a TC-U-REJECT request primitive if the user error parameter indicates "resource limitation" or "initiating release", or construct an error parameter from the parameters received and request its transfer using the TC-U-ERROR request primitive. The error code should be the one associated with the value of the user error parameter of the response primitive.

NOTE: The only user errors that a MAP user can generate in addition to the list of errors attached to the operation which is associated with the service are: resource limitation and initiating release. Any other abnormal situation is detected either by the TC entity or by the MAP entity.

- if an error indication is received and the operation maps on to a class 3 operation, or if no error indication is received but the service maps on to a class 2 operation which has no class 4 linked operation, return the local service state machine to idle without requesting any service from TC.

15.6.4 Receipt of a response

A component handling indication primitive is considered as driving a response for a confirmed service if the invoke ID parameter value matches the one stored for the service, or if the linked ID parameter value matches the one stored for the service and the operation invoked is a class 4 operation. On receipt of a response (except a TC-L-CANCEL indication) for an unconfirmed service the MAP PM shall issue a MAP-NOTICE indication primitive with the appropriate provider error (return result unexpected or return error unexpected).

15.6.4.1 Receipt of a TC-RESULT-NL indication

If the type of the partial result parameter is not compatible with the one defined for the complete result of this operation, request the transfer of a reject component using the TC-U-REJECT request primitive, with the appropriate problem code (mistyped parameter) and issue a confirm primitive with the provider error parameter set to "invalid response received". The MAP PM shall also issue a TC-U-CANCEL request primitive so that all subsequent result components for this operation are discarded by TC.

Otherwise, store the value of the partial result parameter and wait for subsequent TC-RESULT-NL indication primitives until a TC-RESULT-L indication primitive is received.

15.6.4.2 Receipt of a TC-RESULT-L indication

If the type of the result parameter is not the one defined for the result of this operation, request the transfer of a reject component using the TC-U-REJECT request primitive, with the appropriate problem code (mistyped parameter), and issue a confirm primitive with the provider error parameter set to "invalid response received".

If the type of the result parameter is correct but does not contain all the information elements required by the service associated with the invocation, issue a confirm primitive with the provider error parameter set to "invalid response received".

NOTE 1: These checks are only relevant when there is not a one-to-one mapping between a service and an operation.

If the type of the result parameter is correct but contains information elements which are not relevant for the service associated with the invocation are missing, issue a confirm primitive with the provider error parameter set to "invalid response received".

NOTE 2: These checks are only relevant when there is not a one-to-one mapping between a service and an operation.

Otherwise, issue a MAP confirm primitive to the MAP-service-user mapping the result parameter of the TC-RESULT-L primitive on to the MAP specific parameters.

If partial results have been previously received, the value of the partial result parameters shall also be taken into account before performing the three previous checks.

15.6.4.3 Receipt of a TC-U-ERROR indication

If the error code is not defined for the MAP or is not one associated with the operation referred to by the invoke identifier, request the transfer of a reject component using the TC-U-REJECT request primitive, with the appropriate problem code (unrecognized error or unexpected error), and issue a confirm primitive with the provider error parameter set to "invalid response received".

If the type of the error parameter is not the one defined for this error, request the transfer of a reject component using the TC-U-REJECT request primitive, with the appropriate problem code (mistyped parameter), and issue a confirm primitive with the provider error parameter set to "invalid response received".

If the type of the error parameter is correct but does not contain all the information elements required by the service associated with the invocation, issue a confirm primitive with the provider error parameter set to "invalid response received".

NOTE 1: In some cases, it may be necessary to analyse the operation argument.

If the type of the error parameter is correct but its value includes information elements which are not relevant for the service associated with the invocation, issue a confirm primitive with the provider error parameter set to "invalid response received".

NOTE 2: In some cases, it may be necessary to analyse the operation argument.

Otherwise, issue a MAP confirm primitive to the MAP-service-user with the user error parameter set according to the received error code. If applicable the error parameter is mapped to the diagnostic parameter.

15.6.4.4 Receipt of a TC-INVOKE indication

A TC-INVOKE indication primitive is considered as carrying a possible response to a specific service if the linked ID refers to an active specific service and the associated operation is a class 4 operation. Note that the presence of a linked ID parameter in a TC-INVOKE primitive requesting a non class 4 operation indicates a child service whose procedures are the same as the procedures for the parent service.

On receipt of a TC-INVOKE indication confirming an active service, the MAP PM shall:

- if the operation code is not defined for MAP and the dialogue version is at least 3, issue a TC-U-REJECT request primitive with the appropriate problem code (unrecognized operation).
- if the operation code is not defined for MAP and the dialogue version is lower than 3, or if the operation referred to by the linked ID does not allow linked operations or if the operation code does not correspond to an allowed linked operation, issue a TC-U-REJECT request primitive with the appropriate problem code (unrecognized operation, linked response unexpected or unexpected linked operation). If the service is confirmed, the MAP shall also issue a Confirm primitive with provider error indication "unexpected response from the peer", otherwise it may issue a MAP-NOTICE indication primitive with an appropriate diagnostic "abnormal event received from the peer".
- otherwise issue a confirm primitive mapping the operation argument parameter to the user specific parameters and setting the result parameter according to the operation code of the linked operation.

15.6.4.5 Receipt of a TC-U-REJECT indication

On receipt of a TC-U-REJECT indication primitive which affects a pending service, the MAP PM shall issue a MAP confirm primitive to the MAP-service-user with the appropriate value of the provider error or user error parameter.

The mapping of TC invoke problem codes on to MAP Provider Error and MAP User Error parameter values is described in clause 16.

15.6.4.6 Receipt of a TC-L-REJECT indication

This event occurs when the local TC detects a protocol error in an incoming component which affects an active specific service.

On receipt of a TC-L-REJECT indicating "return result problem, unexpected return result", the MAP shall issue a confirm primitive with the parameter provider error indicating "unexpected response from the peer".

On receipt of a TC-L-REJECT indicating "return error problem, unexpected error result", the MAP shall issue a confirm primitive with the parameter provider error indicating "unexpected response from the peer".

Note that when the problem code indicates a general problem, it is considered that the event cannot be related to an existing SSM even if the invoke Id is provided by TC. This is because whether the invoke Id refers to a local or remote invocation is ambiguous. The behaviour of the MAP PM in such a case is described in subclause 15.6.5.3.

15.6.4.7 Receipt of a TC-L-CANCEL indication

On receipt of a TC-L-CANCEL indication, the MAP PM shall:

- if the associated operation is a class 1 operation, issue a confirm primitive with the provider error cause indicating "no response from the peer";
- if the associated operation is a class 2 operation and no linked operations are defined for this operation, issue a confirm primitive without parameter (i.e. indicating implicitly the successful completion of the service);
- if the associated operation is a class 2 operation and has linked operations but none of them has been invoked, issue a confirm primitive with the provider error parameter indicating "service completion failure";
- if the associated operation is a class 2 operation and a linked operation invocation has already been received in response to this operation, ignore the primitive;
- if the associated operation is a class 3 operation, issue a confirm primitive with the provider error cause indicating "service completion failure";
- if the associated operation is a class 4 operation, ignore the primitive.

NOTE: When a TC-L-CANCEL ind primitive is received before the dialogue has been confirmed (i.e. no backward message is received by the dialogue initiator node), the MAP PM shall first issue a MAP-OPEN Cnf primitive with the result parameter indicating "accepted" (which means that the dialogue is considered as being implicitly accepted). Then, as indicated above, the TC-L-CANCEL Indication is interpreted according to the class of the operation to which it refers.

15.6.4.8 Receipt of a TC-NOTICE indication

If a TC-NOTICE indication primitive is received before the dialogue has been confirmed (i.e. no backward message is received by the dialogue initiator node), the MAP PM shall issue a MAP-OPEN Cnf primitive with the result parameter indicating Refused and a refuse reason Remote node not reachable".

If a TC-NOTICE indication primitive is received after the dialogue has been confirmed, the MAP PM shall issue a MAP-NOTICE indication to the user, with a problem diagnostic indicating "message cannot be delivered to the peer".

15.6.5 Other events

This subclause describes the behaviour of the MAP PM on receipt of a component handling indication primitive which cannot be related to any service or which does not affect a pending one. The MAP user is only informed that an abnormal event occurred during the associated dialogue. It is up to the MAP user to abort, continue or terminate the dialogue.

15.6.5.1 Receipt of a TC-U-REJECT

On receipt of a TC-U-REJECT indication primitive which does not affect an active SSM (i.e. indicating a return result or return error problem), the MAP PM shall issue a MAP-NOTICE indication primitive with the diagnostic parameter set to "response rejected by the peer".

This is also applicable for invoke problems related to a class 4 linked operation.

15.6.5.2 Receipt of a TC-R-REJECT indication

On receipt of a TC-R-REJECT indication (i.e. when a protocol error has been detected by the peer TC entity) which does not affect an active SSM, the MAP PM shall either discard this indication or issue a MAP-NOTICE indication primitive with the provider error indicating "abnormal event detected by the peer".

In case of notification, it is up to the MAP user to continue, abort or terminate the dialogue. Note also that for MAP V1 the reject component is received in an END message and therefore the dialogue is terminated anyway.

15.6.5.3 Receipt of a TC-L-REJECT indication

On receipt of a TC-L-REJECT indication primitive (i.e. when a protocol error has been detected by the local TC entity) which cannot be related to an active SSM, the MAP PM shall either discard this indication or issue a MAP-NOTICE indication primitive with the provider error indicating "abnormal event received from the peer".

In case of notification, it is up to the MAP user to continue, or to terminate the dialogue and implicitly trigger the transmission of the reject component or to abort the dialogue.

15.6.6 Parameter checks

As described in the previous subclauses, the MAP PM performs a set of checks to ensure the correctness of the information elements received; these are:

- check if the syntax and encoding (note) of the operation argument, result or error parameter are correct.

NOTE: Depending on the implementation, encoding problems on the TC user portion may be detected at TC level or by the MAP user. In the second case the problem is reported in a similar manner to a syntactical problem.

The syntax shall be considered incorrect if a mandatory information element is missing in any constructed element or if the value of an information element is out of the range defined for the type it is supposed to belong to;

- if there is not a one-to-one mapping between a service and an operation:
 - i) check if the value of the information elements (generally a single one) permits the MAP PM to determine the service associated with the operation invocation;
 - ii) check that there are no information elements which are irrelevant for the indication or a confirm primitive to be issued;
- check if all the information elements required to build an indication or a confirm primitive are available.

However some additional checks may have to be performed by the MAP user (see clause 18).

15.6.7 Returning state machines to idle

Unlike TC invocation state machines, service state machines exist at both requestor and performer side.

A service state machine at the requestor side is returned to idle when the MAP-specific confirm primitive is issued or when the dialogue terminates.

A service state machine at the performer side is returned to idle on receipt of a MAP-specific response primitive from the MAP user, when the dialogue terminates or at expiry of an implementation dependent watch-dog timer which is started when the state machine is created.

15.6.8 Load control

As stated in the previous subclauses, before issuing a MAP-OPEN indication primitive the MAP PM performs a check to verify if there are sufficient resources to open the dialogue taking into account possible overload conditions.

The decision is based on the priority allocated to the application-context whose name is explicitly included in the TC-BEGIN indication primitive or implied by the first operation invocation when V1 contexts are in use. How a V1 application-context-name is derived from an operation code is described in table 15.1/1.

The priority level allocated to each application-context is described in clause 3 tables 5.1/1 and 5.1/2.

16 Mapping on to TC services

16.1 Dialogue control

Dialogue control services are mapped to TC dialogue handling services. The TC-UNI service is not used by the MAP PM.

16.1.1 Directly mapped parameters

The following parameters of the MAP-OPEN request and indication primitives are directly mapped on to the corresponding parameters of the TC-BEGIN primitives:

- destination address;
- originating address.

16.1.2 Use of other parameters of dialogue handling primitives

16.1.2.1 Dialogue Id

The value of this parameter is associated with the MAP PM invocation in an implementation dependent manner.

16.1.2.2 Application-context-name

The application-context-name parameter of a MAP primitive is mapped to the application-context-name parameter of TC dialogue handling primitives according to the rules described in subclause 15.1.

16.1.2.3 User information

The user information parameter of TC dialogue primitives is used to carry the MAP dialogue APDUs.

16.1.2.4 Component present

This parameter is used by the MAP PM as described in CCITT Recommendation Q.771. It is not visible to the MAP user.

16.1.2.5 Termination

The value of this parameter of the TC-END request primitive is set by the MAP PM on the basis of the release method parameter of the MAP-CLOSE request primitive, except when the dialogue state machine is in the state DIALOGUE INITIATED, in which case the Termination parameter shall always indicate "pre-arranged end".

16.1.2.6 P-Abort-Cause

Values of the P-abort-cause parameter are mapped to the values of the provider-reason parameter of the MAP-P-ABORT indication primitive according to table 16.1/1, except in the dialogue initiated phase for the "incorrectTransactionPortion" and "noCommonDialoguePortion" values which are mapped to the "potential incompatibility problem" value of the refuse-reason parameter of the MAP-OPEN cnf primitive. The source parameter in the MAP-P-ABORT ind takes the value "TC problem".

16.1.2.7 Quality of service

The quality of service of TC request primitives is set by the MAP as shown below.

- Return option: "Return message on error" or "Discard message on error" as required by the network operator;
- Sequence control: "Sequence guaranteed" or "Sequence result not guaranteed" as required by the network operator;

"Sequence guaranteed" shall be used when a segmented result is to be transferred (e.g. subscriber data in response to SendParameters). It may also be appropriate to use Sequence guaranteed when a series of InsertSubscriberData, ProcessAccessSignalling or ForwardAccessSignalling operations is used.

It is essential that the TC message which indicates acceptance of a dialogue opening request is received by the dialogue initiator before any subsequent message in that dialogue; otherwise the dialogue opening will fail. The dialogue responder shall ensure that this requirement is met by:

- Sending the dialogue acceptance message in a TC-END, if the dialogue structure requires it; or
- Using "Sequence guaranteed", if the dialogue acceptance message is sent in a TC-CONTINUE; or
- Waiting until the dialogue acceptance message has been acknowledged by the dialogue initiator before sending a subsequent message, if the dialogue acceptance message is sent in a TC-CONTINUE.

**Table 16.1/1: Mapping of P-Abort cause in TC-P-ABORT indication
on to provider-reason in MAP-P-ABORT indication**

TC P-Abort cause	MAP provider-reason
unrecognized message type	provider malfunction
unrecognized transaction Id	supporting dialogue released
badlyFormattedTransactionPortion	provider malfunction
incorrectTransactionPortion	provider malfunction (note)
resourceLimitation	resource limitation
abnormalDialogue	provider malfunction
noCommonDialoguePortion	version incompatibility
NOTE: Or version incompatibility in the dialogue initiated phase.	

16.2 Service specific procedures

Specific services are mapped to TC component handling services.

16.2.1 Directly mapped parameters

The Invoke Id parameter of the MAP request and indication primitive is directly mapped on to the Invoke Id parameter of the component handling primitives.

16.2.2 Use of other parameters of component handling primitives

16.2.2.1 Dialogue Id

The value of this parameter is associated with the MAP PM invocation in an implementation dependent manner.

16.2.2.2 Class

The value of this parameter is set by the MAP PM according to the type of the operation to be invoked.

16.2.2.3 Linked Id

When a service response is mapped to a class 4 operation, the value of this parameter is set by the MAP PM and corresponds to the value assigned by the user to the initial service request (i.e. the value of the invoke ID parameter of

the request primitive). Otherwise if such a parameter is included in MAP request/indication primitives it is directly mapped to the linked ID parameter of the associated TC-INVOKE request/indication primitives.

16.2.2.4 Operation

When mapping a request primitive on to a Remote Operations PDU (invoke), the MAP PM shall set the operation code according to the mapping described in table 16.2/1.

When mapping a response primitive on to a Remote Operations service, the MAP PM shall set the operation code of the TC-RESULT-L/NL primitive (if required) to the same value as the one received at invocation time.

Table 16.2/1: Mapping of MAP specific services on to MAP operations

MAP-SERVICE	operation
MAP-ACTIVATE-SS	activateSS
MAP-ACTIVATE-TRACE-MODE	activateTraceMode
MAP-ALERT-SERVICE-CENTRE	alertServiceCentre
MAP-ANY-TIME-INTERROGATION	anyTimeInterrogation
MAP-CANCEL-LOCATION	cancelLocation
MAP-CHECK-IMEI	checkIMEI
MAP-DEACTIVATE-SS	deactivateSS
MAP-DEACTIVATE-TRACE-MODE	deactivateTraceMode
MAP-DELETE-SUBSCRIBER-DATA	deleteSubscriberData
MAP-ERASE-CC-ENTRY	eraseCC-Entry
MAP-ERASE-SS	eraseSS
MAP-FAILURE-REPORT	failureReport
MAP-FORWARD-ACCESS-SIGNALLING	forwardAccessSignalling
MAP-FORWARD-CHECK-SS-INDICATION	forwardCheckSSIndication
MAP-FORWARD-GROUP-CALL-SIGNALLING	forwardGroupCallSignalling
MAP-MT-FORWARD-SHORT-MESSAGE	mt-forwardSM
MAP-MO-FORWARD-SHORT-MESSAGE	mo-forwardSM
MAP-GET-PASSWORD	getPassword
MAP-INFORM-SERVICE-CENTRE	informServiceCentre
MAP-INSERT-SUBSCRIBER-DATA	insertSubscriberData
MAP-INTERROGATE-SS	interrogateSS
MAP-NOTE-MS-PRESENT-FOR-GPRS	noteMsPresentForGprs
MAP-PREPARE-GROUP-CALL	prepareGroupCall
MAP-PREPARE-HANDOVER	prepareHandover
MAP-PREPARE-SUBSEQUENT-HANDOVER	prepareSubsequentHandover
MAP-PROCESS-ACCESS-SIGNALLING	processAccessSignalling
MAP-PROCESS-GROUP-CALL-SIGNALLING	processGroupCallSignalling
MAP-PROCESS-UNSTRUCTURED-SS-REQUEST	processUnstructuredSS-Request
MAP-PROVIDE-ROAMING-NUMBER	provideRoamingNumber
MAP-PROVIDE-SIWFS-NUMBER	provideSIWFSNumber
MAP-PROVIDE-SUBSCRIBER-LOCATION	provideSubscriberLocation
MAP-PROVIDE-SUBSCRIBER-INFO	provideSubscriberInfo
MAP-PURGE-MS	purgeMS
MAP-READY-FOR-SM	readyForSM
MAP-REGISTER-CC-ENTRY	registerCC-Entry
MAP-REGISTER-PASSWORD	registerPassword
MAP-REGISTER-SS	registerSS
MAP-REMOTE-USER-FREE	remoteUserFree
MAP-REPORT-SM-DELIVERY-STATUS	reportSmDeliveryStatus
MAP-RESET	reset
MAP-RESTORE-DATA	restoreData
MAP-SEND_GROUP-CALL_END_SIGNAL	sendGroupCallEndSignal
MAP-SEND-END-SIGNAL	sendEndSignal
MAP-SEND-AUTHENTICATION-INFO	sendAuthenticationInfo
MAP-SEND-IMSI	sendIMSI
MAP-SEND-IDENTIFICATION	sendIdentification
MAP-SEND-ROUTING-INFO-FOR-SM	sendRoutingInfoForSM
MAP-SEND-ROUTING-INFO-FOR-GPRS	sendRoutingInfoForGprs
MAP-SEND-ROUTING-INFO-FOR-LCS	sendRoutingInfoForLcs
MAP-SEND-ROUTING- INFORMATION	sendRoutingInfo
MAP-SET-REPORTING-STATE	setReportingState
MAP-SIWFS-SIGNALLING-MODIFY	SIWFSSignallingModify
MAP-STATUS-REPORT	statusReport
MAP-SUBSCRIBER-LOCATION-REPORT	subscriberLocationReport
MAP-SUPPLEMENTARY-SERVICE-INVOCATION-NOTIFICATION	ss-Invocation-Notification
MAP-UNSTRUCTURED-SS-NOTIFY	unstructuredSS-Notify
MAP-UNSTRUCTURED-SS-REQUEST	unstructuredSS-Request
MAP-UPDATE-GPRS-LOCATION	updateGprsLocation
MAP-UPDATE-LOCATION	updateLocation

16.2.2.5 Error

The error parameter in a TC-U-ERROR indication primitive is mapped to the user error parameter in the MAP confirm primitive of the service associated with the operation to which the error is attached.

The user error parameter in MAP response primitives is mapped to the error parameter of the TC-U-ERROR request primitive, except for "initiating-release" and "resource-limitation" which are mapped to the problem code parameter of the TC-U-REJECT request primitive.

16.2.2.6 Parameters

The parameters of MAP specific request and indication primitives are mapped to the argument parameter of TC-INVOKE primitives.

The parameters of MAP specific response and confirm primitives are mapped to the result parameter of TC-RESULT-L primitives, the parameter of TC-U-ERROR primitives or the argument of TC-INVOKE primitives when mapping on linked class 4 operations is used.

16.2.2.7 Time out

The value of this parameter is set by the MAP PM according to the type of operation invoked.

16.2.2.8 Last component

This parameter is used by the MAP PM as described in CCITT Recommendation Q.711. It is not visible from the MAP user.

16.2.2.9 Problem code

16.2.2.9.1 Mapping to MAP User Error

The following values of the user error parameter are mapped as follows to values of the TC problem code parameter. These values are generated by the MAP user. This mapping is valid from the TC-U-REJECT indication primitive to the MAP confirm service primitive and from the MAP response service primitive to the TC-U-REJECT request primitive.

Table 16.2/2: Mapping of MAP User Error parameter on to TC problem code in TC-U-REJECT primitives

MAP User Error	TC problem code
resource limitation	resource limitation
initiating release	initiating release

16.2.2.9.2 Mapping to MAP Provider Error parameter

The following values of the TC problem code parameter of the TC-U-REJECT indication primitive are mapped as follows to values of the MAP Provider Error parameter of the MAP confirm primitive.

Table 16.2/3: Mapping of TC problem code in TC-U-REJECT on to MAP Provider Error parameter

TC problem code	MAP Provider Error
duplicated invoke Id	duplicated invoke id
unrecognized operation	service not supported
mistyped parameter	mistyped parameter

The following values of the problem code parameters of the TC-L-REJECT primitive are mapped to values of the provider error parameter of the MAP confirm primitive as follows:

Table 16.2/4: Mapping of TC problem code in TC-L-REJECT on to MAP Provider Error parameter

TC problem code	MAP Provider Error
return result unexpected	unexpected response from the peer
return error unexpected	unexpected response from the peer

16.2.2.9.3 Mapping to diagnostic parameter

The following values of the problem code parameter of the TC-R-REJECT and TC-U-REJECT primitive are mapped to values of the diagnostic parameter of the MAP-NOTICE indication primitive as follows:

Table 16.2/5: Mapping of TC problem code of TC-R-REJECT and TC-U-REJECT on to diagnostic parameter

TC problem code	MAP diagnostic
General problem	
abnormal event detected by the peer	
Invoke problem	
- unrecognized linked ID	- abnormal event detected by the peer
- linked response unexpected	- response rejected by the peer
- unexpected linked operation	- response rejected by the peer
Return result problem	
- unrecognized invoke ID	- response rejected by the peer
- return result unexpected	- response rejected by the peer
- mistyped parameter	- response rejected by the peer
Return error problem	
- unrecognized invoke ID	- response rejected by the peer
- return error unexpected	- response rejected by the peer
- unrecognized error	- response rejected by the peer
- unexpected error	- response rejected by the peer
- mistyped parameter	- response rejected by the peer

The following values of the problem code parameter of the TC-L-REJECT primitive are mapped to values of the diagnostic parameter of the MAP-NOTICE indication primitive as follows:

Table 16.2/6: Mapping of TC problem code of TC-L-REJECT on to diagnostic parameter

TC problem code	MAP diagnostic
General problems:	- abnormal event received from the peer
Invoke problem:	
- unrecognized linked ID	- abnormal event received from the peer
Return result problem:	
- unrecognized invoke ID	- abnormal event received from the peer
Return error problem:	
- unrecognized invoke ID	- abnormal event received from the peer

16.3 SDL descriptions

The following SDL specification describes a system which includes three blocks: MAP-user, MAP-provider and TC.

Such a system resides in each network component supporting MAP and communicates with its peers via the lower layers of the signalling network which are part of the environment.

Only the MAP-provider is fully described in this subclause. The various type of processes which form the MAP-User block and the TC block are described respectively in clauses 18 to 25 of the present document and in CCITT Recommendation Q.774.

The MAP-Provider block communicates with the MAP_USER via two channels U1 and U2. Via U1 the MAP-provider receives the MAP request and response primitives. Via U2 it sends the MAP indication and confirm primitives.

The MAP-Provider block communicates with TC via two channels P1 and P2. Via P1 the MAP-Provider sends all the TC request primitives. Via P2 it receives all the TC indication primitives.

The MAP-Provider block is composed of the four following types of processes:

- a) MAP_DSM: This type of process handles a dialogue. There exists one process instance per MAP dialogue.
- b) LOAD_CTRL: This type of process is in charge of load control. There is only one instance of this process in each system.
- c) PERFORMING_MAP_SSM: This type of process handle a MAP service performed during a dialogue. An instance of this process is created by the instance of the MAP_DSM process for each MAP-service to be performed.
- d) REQUESTING_MAP_SSM: This type of process handle a MAP service requested during a dialogue. An instance of this process is created by the instance of the MAP_DSM process for each requested MAP-service.

A process MAP_DSM exchanges external signals with other blocks as well as internal signals with the other processes of the MAP-Provider block. The external signals are either MAP service primitives or TC service primitives.

The signal routes used by the various processes are organized as follows:

- a) A process MAP_DSM receives and sends events from/to the MAP_user via signal route User1/User2. These routes uses respectively channel U1 and U2.
- b) A process MAP_DSM receives and sends events from/to the TC via signal route Tc1/Tc2. These routes uses respectively channel P1 and P2.
- c) A process MAP_DSM receives and sends events from/to the LOAD_CTRL process via signal route Load1/Load2. These routes are internal.
- d) A process MAP_DSM sends events to the PERFORMING_MAP_SSM processes via signal route Intern1. This route is internal.
- e) A process MAP_DSM sends events to the REQUESTING_MAP_SSM processes via signal route Intern2. This route is internal.
- f) A process MAP_PERFORMING_SSM sends events to the MAP_USER via signal route User4. This route uses channel U2.
- g) A process MAP_PERFORMING_SSM sends events to TC via signal route Tc3. This route uses channel P1.
- h) A process MAP_REQUESTING_SSM sends events to the MAP_USER via signal route User5. This route uses channel U2.
- j) A process MAP_REQUESTING_SSM sends events to TC via signal route Tc4. This route uses channel P1.

09.02 version 6.6.0




Figure 16.2/1: System MAP_STACK




Figure 16.2/2: Block MAPPROVIDER

Process MAP_DSM

16.2_3.1(11)

Figure 16.2/3:

Comment 'MAP Dialoges State Maschine':
 DCL
 COMPONENTS_PRESENT, INVOKEID_ACTIVE, LAST_COMPONENT, OP_EXIST BOOLEAN,
 OP_CODE INTEGER;




Figure 16.2/3 (sheet 1 of 11): Process MAP_DSM




Figure 16.2/3 (sheet 2 of 11): Process MAP_DSM




Figure 16.2/3 (sheet 3 of 11): Process MAP_DSM




Figure 16.2/3 (sheet 4 of 11): Process MAP_DSM




Figure 16.2/3 (sheet 5 of 11): Process MAP_DSM

Process MAP_DSM

16.2_3.6(11)

Figure 16.2/3:




Figure 16.2/3 (sheet 6 of 11): Process MAP_DSM




Figure 16.2/3 (sheet 7 of 11): Process MAP_DSM

Process MAP_DSM

16.2_3.8(11)

Figure 16.2/3:




Figure 16.2/3 (sheet 8 of 11): Process MAP_DSM




Figure 16.2/3 (sheet 9 of 11): Process MAP_DSM




Figure 16.2/3 (sheet 10 of 11): Process MAP_DSM




Figure 16.2/3 (sheet 11 of 11): Process MAP_DSM

Procedure PROCESS_COMPONENTS

16.2_4.1(4)

Figure 16.2/4:

Comments: Components from TCAP:

```
DCL
  OP_CODE INTERGER,
  OP_EXIST, LAST_COMPONENT, INVOKEID_ASS, LINKEDID_PRES, LINKEDID_ASS BOOLEAN;
```




Figure 16.2/4 (sheet 1 of 4): Procedure PROCESS_COMPONENTS

Procedure PROCESS_COMPONENTS

16.2_4.2(4)

Figure 16.2/4:




Figure 16.2/4 (sheet 2 of 4): Procedure PROCESS COMPONENTS

Procedure PROCESS_COMPONENTS

16.2_4.3(4)




Figure 16.2/4 (sheet 3 of 4): Procedure PROCESS_COMPONENTS

Procedure PROCESS_COMPONENTS

16.2_4.4(4)

Figure 16.2/4:




Figure 16.2/4 (sheet 4 of 4): Procedure PROCESS_COMPONENTS

Process LOAD_CTRL

16.2_5(1)

Figure 16.2/5:

Comment 'LOAD CONTROL':
 DCL
 CONGESTION, DIALOGUE_ACCEPTABLE BOOLEAN;




Figure 16.2/5: Process LOAD_CTRL

Process PERFORMING_MAP_SSM

16.2_6.1(3)

Figure 16.2/6:

Comment 'MAP Service State Machine':
DCL
 ARGUMENT_CORRECT, USER_ERROR_PRESENT,
 SPECIFIC_ERROR_LINKED_REQUEST, CNF BOOLEAN,

 OP_CLASS INTEGER,

 TIMER GUARD_TIMER COMMENT 'expires if MAP user does not respond';




Figure 16.2/6 (sheet 1 of 3): Process PERFORMING_MAP_SSM




Figure 16.2/6 (sheet 2 of 3): Process PERFORMING_MAP_SSM




Figure 16.2/6 (sheet 3 of 3): Process PERFORMING_MAP_SSM

Process REQUESTING_MAP_SSM

16.2_7.1(4)

Figure 16.2/7:

Comment 'MAP Service State Maschine':

DCL

ARGUMENT_CORRECT, ERROR_CODE_CORRECT, LINKED_REQ_DEF, SYNTAX_CORRECT,
 MAP_INITIATED, CNF, LINKED_OPERATION_ALLOWED BOOLEAN,
 OP_CLASS INTEGER;




Figure 16.2/7 (sheet 1 of 4): Process REQUESTING_MAP_SSM

Process REQUESTING_MAP_SSM

16.2_7.2(4)

Figure 16.2/7:




Figure 16.2/7 (sheet 2 of 4): Process REQUESTING_MAP_SSM




Figure 16.2/7 (sheet 3 of 4): Process REQUESTING_MAP_SSM




Figure 16.2/7 (sheet 4 of 4): Process REQUESTING_MAP_SSM

17 Abstract syntax of the MAP protocol

17.1 General

This subclause specifies the Abstract Syntaxes for the Mobile Application Part as well as the associated set of Operations and Errors, using the Abstract Syntax Notation One (ASN.1), defined in CCITT Recommendation X.208 (1988) or X.680 (1994) with additions as defined in subclause 17.1.4 on Compatibility Considerations and the OPERATION and ERROR external MACROs, defined in CCITT Recommendation Q.773.

The Abstract Syntax is defined for all interfaces specified in subclause 4.4 except for the A- and B-interfaces.

The Mobile Application Part protocol is defined by two Abstract Syntaxes:

- one Abstract Syntax which encompass all Operations; and
- Errors identified by the various MAP subsystem numbers.

This Abstract Syntax represents the set of values each of which is a value of the ASN.1 type TCAPMessages.MessageType as defined in CCITT Recommendation Q.773 with the ANY DEFINED BY sections resolved by the operation and error codes included in the ASN.1 module MAP-Protocol. However, only the subset of this abstract syntax which is required by the procedures defined for an entity needs to be supported:

- one Abstract Syntax identified by the OBJECT IDENTIFIER value MAP-DialogueInformation.map-DialogueAS.

This Abstract Syntax represents the set of values each of which is a value of the ASN.1 type MAP-DialogueInformation.MAP-DialoguePDU. Such a value of the ASN.1 single-ASN.1-type element is contained within the user-information element of the TCAPMessages.DialoguePortion ASN.1 type. This Abstract Syntax name is to be used as a direct reference.

17.1.1 Encoding rules

The encoding rules which are applicable to the defined Abstract Syntaxes are the Basic Encoding Rules for Abstract Syntax Notation One, defined in CCITT Recommendation X.690 with the same exceptions as in CCITT Recommendation Q.773 section 4 Message Representation.

When the definite form is used for length encoding, a data value of length less than 128 octets must have the length encoded in the short form.

When the long form is employed to code a length, the minimum number of octets shall be used to code the length field.

OCTET STRING values and BIT STRING values must be encoded in a primitive form.

There is no restriction to the use of empty constructors (e.g. an empty SEQUENCE type). That is, the encoding of the content of any data value shall consist of zero, one or more octets.

17.1.2 Use of TC

The mapping of OPERATION and ERROR to TC components is defined in ETS 300 287 (version 2) which is based on CCITT Recommendation Q.773 (1992).

NOTE 1: The class of an operation is not stated explicitly but is specified as well in the ASN.1 operation type definition.

Class 1: RESULT and ERROR appear in ASN.1 operation type definition.

Class 2: only ERROR appears in ASN.1 operation type definition.

Class 3: only RESULT appears in ASN.1 operation type definition.

Class 4: both RESULT and ERROR do not appear in ASN.1 operation type definition.

The ASN.1 data type which follows the keywords "ARGUMENT", "PARAMETER" or "RESULT" (for OPERATION and ERROR) is always optional from a syntactic point of view. However, except when specifically mentioned with the ASN.1 comment «-- optional», the «parameter» part of a component has to be considered as mandatory from a semantic point of view.

When an optional element is missing in an invoke component or in an inner data structure while it is required by the context, an error component is returned if specified in the operation type; the associated type of error is DataMissing. This holds also when the entire parameter of an invoke component is missing while it is required by the context.

NOTE 2: When a mandatory element is missing in the parameter or inner data structure of any component, a reject component is returned (if the dialogue still exists). The problem code to be used is "Mistyped parameter".

The Timer Values used in the operation type definitions are indicated as ASN.1 comment. The Timer Value Ranges are:

s = from 3 seconds to 10 seconds;

m = from 15 seconds to 30 seconds;

ml = from 1 minute to 10 minutes;

l = from 28 hours to 38 hours.

17.1.2.1 Use of Global Operation and Error codes defined outside MAP

An entity supporting an application context greater than 2 shall be capable of receiving an operation or error code, within an application context defined in GSM 09.02, encoded as either an Object Identifier (as defined in CCITT Recommendation X.690 (1994)) or an integer value (as defined in section 17.5). Related restrictions regarding the use of Object Identifiers are as follows:

- The length of the Object Identifier shall not exceed 16 octets and the number of components of the Object Identifier shall not exceed 16.
- Object Identifiers shall be used only for operations or errors defined outside of GSM 09.02.
- Global error codes may be sent only in response to a global operation. If a standard operation is received then a global error code shall not be sent in response.

Handling of an unknown operation codes by the receiving entity is defined in section 15.1.1

17.1.3 Use of information elements defined outside MAP

An information element or a set of information elements (messages) transparently carried in the Mobile Application Part but defined in other recommendation/technical specifications are handled in one of the following ways:

- i) The contents of each information element (without the octets encoding the identifier and the length in the recommendation/technical specification where it is defined) is carried as the value of an ASN.1 NamedType derived from the OCTET STRING data type. Additionally, the internal structure may be explained by means of comments. In case of misalignment the referred to recommendation/technical specification takes precedence.
- ii) The complete information element (including the octets encoding the identifier and the length in the recommendation/technical specification where it is defined) or set of information elements and the identity of the associated protocol are carried as the value of the ExternalSignalInfo data type defined in the present document. Where more than one information element is carried, the information elements are sent contiguously with no filler octets between them.

17.1.4 Compatibility considerations

The following ASN.1 modules conform to CCITT Recommendation X.208 (1988) or X.680 (1994) (the only module which makes use of X.680 is MAP-ExtensionDataTypes), but in addition Ellipsis Notation ("..." - notation) is used as described in ITU-T Recommendation X.680 Amendment 1 (1995) wherever future protocol extensions are foreseen.

The "..." construct applies only to SEQUENCE and ENUMERATED data types. An entity supporting a version greater than 1 shall not reject an unsupported extension following "..." of that SEQUENCE or ENUMERATED data type. The Encoding Rules from subclause 17.1.1 apply to every element of the whole Transfer Syntax especially to the ASN.1 type EXTERNAL.

Private extensions shall:

- 1) if included in operations of an AC of V2, follow the extension marker and be tagged using PRIVATE tags up to and including 29.

NOTE: This type of extension is in most cases used only within a PLMN.

- 2) if included in operations of an AC of V3 or higher: be included only in the Private Extension Container that is defined in the specification.

NOTE: This type of extension can be used between PLMNs.

Private extensions shall not be included in v2 supplementary service operations.

Private extensions shall not be included within user error for RegisterCCEEntry and EraseCCEEntry operations.

PCS extensions shall be included in the PCS Extension Container that is defined in this specification.

In order to improve extensibility, a few error parameters have been defined as a CHOICE between the version 2 description and a SEQUENCE including the version 2 description and an extension container. Operations used in a v2-application-context must consider only the first alternative while operations used in a vn-application-context (n>2) must consider only the second alternative.

17.1.5 Structure of the Abstract Syntax of MAP

For each MAP parameter which has to be transferred by a MAP Protocol Data Unit (MAP message), there is a PDU field (an ASN.1 NamedType) whose ASN.1 identifier has the same name as the corresponding parameter, except for the differences required by the ASN.1 notation (blanks between words are removed or replaced by hyphen, the first letter of the first word is lower-case and the first letter of the following words are capitalized, e.g. "no reply condition time" is mapped to "noReplyConditionTime"). Additionally some words may be abbreviated as follows:

bs	basic service
ch	call handling
cug	closed user group
ho	handover
ic	incoming call
id	identity
info	information
lcs	location services
ms	mobile service
oc	outgoing call
om	operation & maintenance
pw	Password
sm	short message service

ss supplementary service

The MAP protocol is composed of several ASN.1 modules dealing with either operations, errors, data types, and, if applicable, split into those dealing with mobile services, call handling services, supplementary services and short message services. For operations and errors no values are assigned, but only the operation and error types in order to allow use of the defined types also by other protocols (e.g. GSM 04.80). The values (operation codes and error codes) are defined in a separate module. The ASN.1 source lines are preceded by line-numbers at the left margin in order to enable the usage of the cross-reference in annex A.

The module containing the definition of the operation packages for MAP is:

1. MAP-OperationPackages.

The module containing the definition of the application contexts for MAP is:

2. MAP-ApplicationContexts.

The module containing the data types for the Abstract Syntax to be used for TCAPMessages.DialoguePortion for MAP is:

3. MAP-DialogueInformation.

The module containing the operation codes and error codes for MAP is:

4. MAP-Protocol.

The modules containing all operation type definitions for MAP are:

5. MAP-MobileServiceOperations;
6. MAP-OperationAndMaintenanceOperations;
7. MAP-CallHandlingOperations;
8. MAP-SupplementaryServiceOperations;
9. MAP-ShortMessageServiceOperations;
10. MAP-Group-Call-Operations.
11. MAP-LocationServiceOperations

The module containing all error type definitions for MAP is:

12. MAP-Errors.

Modules containing all data type definitions for MAP are:

13. MAP-MS-DataTypes;
14. MAP-OM-DataTypes;
15. MAP-CH-DataTypes;
16. MAP-SS-DataTypes;
17. MAP-SS-Code;
18. MAP-SM-DataTypes;
19. MAP-ER-DataTypes;
20. MAP-CommonDataTypes;
21. MAP-TS-Code;
22. MAP-BS-Code;

- 23. MAP-ExtensionDataTypes;
- 24. MAP-GR-DataTypes;
- 25. MAP-LCS-DataTypes.

References are made also to modules defined outside of the present document. They are defined in the technical specification Mobile Services Domain and technical specification Transaction Capability respectively:

- MobileDomainDefinitions;
- TCAPMessages;
- DialoguePDUs.

17.1.6 Application Contexts

The following informative table lists the latest versions of the Application Contexts used in this specification, with the operations used by them and, where applicable, whether or not the operation description is exactly the same as for previous versions. Information in sections 17.6 & 17.7 relates only to the ACs in this table.

AC Name	AC Version	Operations Used	Comments
locationCancellationContext	v3	cancelLocation	
equipmentMngtContext	v2	checkIMEI	
imsiRetrievalContext	v2	sendIMSI	
infoRetrievalContext	v2	sendAuthenticationInfo	
interVlrInfoRetrievalContext	v2	sendIdentification	
handoverControlContext	v2	prepareHandover forwardAccessSignalling sendEndSignal processAccessSignalling prepareSubsequentHandover	
mwdMngtContext	v3	readyForSM	
msPurgingContext	v3	purgeMS	
shortMsgAlertContext	v2	alertServiceCentre	
resetContext	v2	reset	
networkUnstructuredSsContext	v2	processUnstructuredSS-Request unstructuredSS-Request unstructuredSS-Notify	
tracingContext	v3	activateTraceMode deactivateTraceMode	
networkFunctionalSsContext	v2	registerSS eraseSS activateSS deactivateSS registerPassword interrogateSS getPassword	
shortMsgMO-RelayContext	v3	mo-forwardSM	
shortMsgMT-RelayContext	v3	mt-forwardSM	
shortMsgGatewayContext	v3	sendRoutingInfoForSM reportSM-DeliveryStatus InformServiceCentre	the syntax of this operation has been extended in comparison with release 96 version
networkLocUpContext	v3	updateLocation forwardCheckSs-Indication restoreData insertSubscriberData activateTraceMode	the syntax is the same in v1 & v2
gprsLocationUpdateContext	v3	updateGprsLocation insertSubscriberData activateTraceMode	

subscriberDataMngtContext	v3	insertSubscriberData deleteSubscriberData	
roamingNumberEnquiryContext	v3	provideRoamingNumber	
locationInfoRetrievalContext	v3	sendRoutingInfo	
gprsNotifyContext	v3	noteMsPresentForGprs	
gprsLocationInfoRetrievalContext	v3	sendRoutingInfoForGprs	
failureReportContext	v3	failureReport	
callControlTransferContext	v4	resumeCallHandling	
subscriberInfoEnquiryContext	v3	provideSubscriberInfo	
anyTimeEnquiryContext	v3	anyTimeInterrogation	
ss-InvocationNotificationContext	v3	ss-InvocationNotification	
slWFSAlocationContext	v3	provideSIWFSNumber slWFSSignallingModify	
groupCallControlContext	v3	prepareGroupCall processGroupCallSignalling forwardGroupCallSignalling sendGroupCallEndSignal	
reportingContext	v3	setReportingState statusReport remoteUserFree	
callCompletionContext	v3	registerCC-Entry eraseCC-Entry	
locationSvcEnquiryContext	v3	provideSubscriberLocation subscriberLocationReport	
locationSvcGatewayContext	v3	sendRoutingInfoForLCS	

NOTE (*): The syntax of the operations is not the same as in previous versions unless explicitly stated

17.2 Operation packages

17.2.1 General aspects

This subclause describes the operation-packages which are used to build the application-contexts defined in subclause 17.3.

Each operation-package is a specification of the roles of a pair of communicating objects (i.e. a pair of MAP-Providers), in term of operations which they can invoke of each other.

The grouping of operations into one or several packages does not necessarily imply any grouping in term of Application Service Elements.

The following ASN.1 MACRO is used to describe operation-packages in this subclause:

```
OPERATION-PACKAGE MACRO ::=

BEGIN

TYPE NOTATION ::= Symmetric | ConsumerInvokes SupplierInvokes |
empty

VALUE NOTATION ::= value(VALUE OBJECT IDENTIFIER)
Symmetric ::= "OPERATIONS" "{" OperationList "}"
ConsumerInvokes ::= "CONSUMER INVOKES" "{" OperationList "}"
SupplierInvokes ::= "SUPPLIER INVOKES" "{" OperationList "}" | empty
OperationList ::= Operation | OperationList "," Operation
Operation ::= value(OPERATION)

END
```

Since the application-context definitions provided in subclause 17.3 use only an informal description technique, only the type notation is used in the following subclauses to define operation-packages.

The following definitions are used throughout this subclause (n>=2):

- v1-only operation: An operation which shall be used only in v1 application-contexts;
- vn-only operation: An operation which shall be used only in vn application-contexts;
- v(n-1)-operation: An operation whose specification has not been modified since the MAP v(n-1) specifications or if the modifications are considered as not affecting v(n-1) implementations;
- v(n-1)-equivalent operation: The version of an operation which excludes all the information elements and errors which have been added since the MAP v(n-1) specification;
- vn-only package: An operation package which contains only vn-only operations;
- v(n-1)-package: An operation package which contains only v(n-1)- operations.

The names of vn-packages are suffixed by "-vn" where n>=2.

For each operation package which is not vn-only (n>=2) and which does not include only v(n-1)-operations, there is a v(n-1)-equivalent package. Except when a definition is explicitly provided in the following subclauses, the v(n-1)-equivalent package includes the v(n-1)-equivalent operations of the operations which belong to this package.

17.2.2 Packages specifications

17.2.2.1 Location updating

This operation package includes the operations required for location management procedures between HLR and VLR.

```
LocationUpdatingPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is HLR if Consumer is VLR
  CONSUMER INVOKES {
    updateLocation}
  SUPPLIER INVOKES {
    forwardCheckSs-Indication}
```

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in subclause 17.2.1.

17.2.2.2 Location cancellation

This operation package includes the operations required for location cancellation and MS purging procedures between HLR and VLR and between HLR and SGSN.

```
LocationCancellationPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is VLR or SGSN if Consumer is HLR
  CONSUMER INVOKES {
    cancelLocation}
```

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in subclause 17.2.1.

17.2.2.3 Roaming number enquiry

This operation package includes the operations required for roaming number enquiry procedures between HLR and VLR.

```
RoamingNumberEnquiryPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is VLR if Consumer is HLR
  CONSUMER INVOKES {
    provideRoamingNumber}
```

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in subclause 17.2.1.

17.2.2.4 Information retrieval

This operation package includes the operation required for the authentication information retrieval procedure between HLR and VLR and between HLR and SGSN.

```
InfoRetrievalPackage-v2 ::= OPERATION-PACKAGE
  -- Supplier is HLR if Consumer is VLR
  -- Supplier is HLR if Consumer is SGSN
  CONSUMER INVOKES {
    sendAuthenticationInfo}
```

The v1-equivalent package is defined as follows:

```
InfoRetrievalPackage-v1 ::= OPERATION-PACKAGE
  -- Supplier is HLR or VLR if Consumer is VLR
  -- Supplier is HLR if Consumer is SGSN
  CONSUMER INVOKES {
    sendParameters}
```

17.2.2.5 Inter-VLR information retrieval

This operation package includes the operations required for inter VLR information retrieval procedures.

```
InterVlrInfoRetrievalPackage-v2 ::= OPERATION-PACKAGE
  -- Supplier is VLR if Consumer is VLR
  CONSUMER INVOKES {
    sendIdentification}
```

The v1-equivalent package is : InfoRetrievalPackage-v1.

17.2.2.6 IMSI retrieval

This operation package includes the operation required for the IMSI retrieval procedure between HLR and VLR.

```
IMSIRetrievalPackage-v2 ::= OPERATION-PACKAGE
  -- Supplier is HLR if Consumer is VLR
  CONSUMER INVOKES {
    sendIMSI}
```

This package is v2 only.

17.2.2.7 Call control transfer

This operation package includes the operation required for the call control transfer procedure between VMSC and GMSC.

```
CallControlTransferPackage-v4 ::= OPERATION-PACKAGE
  -- Supplier is GMSC if Consumer is VMSC
  CONSUMER INVOKES {
    resumeCallHandling}
```

The v3-equivalent package can be determined according to the rules described in subclause 17.2.1.

17.2.2.8 - 17.2.2.9 Void

17.2.2.10 Interrogation

This operation package includes the operations required for interrogation procedures between MSC and HLR or NPLR.

```
InterrogationPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is HLR or NPLR if Consumer is MSC
  CONSUMER INVOKES {
    sendRoutingInfo}
```

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in subclause 17.2.1.

17.2.2.11 Void

17.2.2.12 Handover Control

This operation package includes the operations required for handover procedures between MSCs.

```
HandoverControlPackage-v2 ::= OPERATION-PACKAGE
  -- Supplier is MSCB if Consumer is MSCA
  CONSUMER INVOKES {
    prepareHandover,
    forwardAccessSignalling}
  SUPPLIER INVOKES {
    sendEndSignal,
    processAccessSignalling,
    prepareSubsequentHandover}
```

The v1-equivalent package is defined as follows.

```
HandoverControlPackage-v1 ::= OPERATION-PACKAGE
  -- Supplier is MSCB if Consumer is MSCA
  CONSUMER INVOKES {
    performHandover,
    forwardAccessSignalling,
    traceSubscriberActivity}
  SUPPLIER INVOKES {
    sendEndSignal,
    noteInternalHandover,
    processAccessSignalling,
    performSubsequentHandover}
```

17.2.2.13 Subscriber Data management stand alone

This operation package includes the operations required for stand alone subscriber data management procedures between HLR and VLR or between HLR and SGSN.

```
SubscriberDataMngtStandAlonePackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is VLR or SGSN if Consumer is HLR
  CONSUMER INVOKES {
    insertSubscriberData,
    deleteSubscriberData}
```

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in subclause 17.2.1.

17.2.2.14 Equipment management

This operation package includes the operations required for equipment management procedures between EIR and MSC or between EIR and SGSN.

```
EquipmentMngtPackage-v2 ::= OPERATION-PACKAGE
  -- Supplier is EIR if Consumer is MSC
  -- Supplier is EIR if Consumer is SGSN
  CONSUMER INVOKES {
    checkIMEI}
```

The v1-equivalent package can be determined according to the rules described in subclause 17.2.1.

17.2.2.15 Subscriber data management

This operation package includes the operations required for subscriber data management procedures between HLR and VLR or between HLR and SGSN.

```
SubscriberDataMngtPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is VLR or SGSN if Consumer is HLR
  CONSUMER INVOKES {
    insertSubscriberData}
```

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in subclause 17.2.1.

17.2.2.16 Location register restart

This operation package includes the operations required for location register restart procedures between HLR and VLR or between HLR and SGSN.

```
ResetPackage-v2 ::= OPERATION-PACKAGE
  -- Supplier is VLR or SGSN if Consumer is HLR
  CONSUMER INVOKES {
    reset}
```

The v1-equivalent package can be determined according to the rules described in subclause 17.2.1.

17.2.2.17 Tracing stand-alone

This operation package includes the operations required for stand alone tracing procedures between HLR and VLR or between HLR and SGSN.

```
TracingStandAlonePackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is VLR or SGSN if Consumer is HLR
  CONSUMER INVOKES {
    activateTraceMode,
    deactivateTraceMode}
```

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in subclause 17.2.1.

17.2.2.18 Functional SS handling

This operation package includes the operations required for functional supplementary services procedures between VLR and HLR.

```
FunctionalSSPackage-v2 ::= OPERATION-PACKAGE
  -- Supplier is HLR if Consumer is VLR
  CONSUMER INVOKES {
    registerSS,
    erasesSS,
    activateSS,
    deactivateSS,
    registerPassword,
    interrogateSS}
  SUPPLIER INVOKES {
    getPassword}
```

The v1-equivalent package can be determined according to the rules described in subclause 17.2.1.

17.2.2.19 Tracing

This operation package includes the operations required for tracing procedures between HLR and VLR or between HLR and SGSN.

```
TracingPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is VLR or SGSN if Consumer is HLR
  CONSUMER INVOKES {
    activateTraceMode}
```

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in subclause 17.2.1.

17.2.2.20 Binding

This operation package includes the operation required to initialize a supplementary service procedure between VLR and HLR or between gsmSCF and HLR.

```
BindingPackage-v1 ::= OPERATION-PACKAGE
  -- Supplier is HLR if Consumer is VLR
  -- Supplier is gsmSCF if Consumer is HLR
  CONSUMER INVOKES {
    beginSubscriberActivity}
```

This package is v1 only.

17.2.2.21 Unstructured SS handling

This operation package includes the operations required for unstructured supplementary services procedures between VLR and HLR, and between the HLR and the gsmSCF.

```
UnstructuredSSPackage-v2 ::= OPERATION-PACKAGE
  -- Supplier is HLR if Consumer is VLR
  -- Supplier is gsmSCF if Consumer is HLR
  CONSUMER INVOKES {
    processUnstructuredSS-Request}
  SUPPLIER INVOKES {
    unstructuredSS-Request,
    unstructuredSS-Notify}
```

The v1-equivalent package is defined as follows:

```
UnstructuredSSPackage-v1 ::= OPERATION-PACKAGE
  -- Supplier is HLR if Consumer is VLR
  -- Supplier is gsmSCF if Consumer is HLR
  CONSUMER INVOKES {
    processUnstructuredSS-Data}
```

17.2.2.22 MO Short message relay services

This operation package includes the operations required for short message relay service procedures between IWMSC and VMSC or between GMSC and MSC or between SGSN and IWMSC.

```
MOShortMsgRelayPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is IWMSC if Consumer is MSC
  -- Supplier is IWMSC if Consumer is SGSN
  CONSUMER INVOKES {
    MO-forwardSM}
```

The v2-equivalent package is defined as follows:

```
ShortMsgRelayPackage-v2 ::= OPERATION-PACKAGE
  -- Supplier is IWMSC if Consumer is MSC
  -- Supplier is MSC or SGSN if Consumer is GMSC
  -- Supplier is IWMSC if Consumer is SGSN
  CONSUMER INVOKES {
    forwardSM}
```

The v1-equivalent package can be determined according to the rules described in subclause 17.2.1.

17.2.2.23 Short message gateway services

This operation package includes the operations required for short message service gateway procedures between MSC and HLR.

```
ShortMsgGatewayPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is HLR if Consumer is GMSC
  CONSUMER INVOKES {
    sendRoutingInfoForSM,
    reportSM-DeliveryStatus}
  SUPPLIER INVOKES {
    informServiceCentre}
```

The v2-equivalent package can be determined according to the rules described in subclause 17.2.1

The v1-equivalent package is defined as follows:

```
ShortMsgGatewayPackage-v1 ::= OPERATION-PACKAGE
  -- Supplier is HLR if Consumer is GMSC
  CONSUMER INVOKES {
    sendRoutingInfoForSM
    reportSMDeliveryStatus}
```

17.2.2.24 MT Short message relay services

This operation package includes the operations required for short message relay service procedures between GMSC and MSC or between GMSC and SGSN.

```
MTShortMsgRelayPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is MSC or SGSN if Consumer is GMSC
  CONSUMER INVOKES {
    MT-forwardSM}
```

The v2-equivalent package is: **ShortMsgRelayPackage-v2**

17.2.2.25 Void

17.2.2.26 Message waiting data management

This operation package includes the operations required for short message waiting data procedures between HLR and VLR, between HLR and SGSN.

```
MwdMngtPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is HLR if Consumer is SGSN
  -- Supplier is HLR if Consumer is VLR
  CONSUMER INVOKES {
    readyForSM}
```

The v2-equivalent package can be determined according to the rules described in subclause 17.2.1.

The v1-equivalent package is defined as follows:

```
MwdMngtPackage-v1 ::= OPERATION-PACKAGE
  -- Supplier is HLR if Consumer is VLR
  CONSUMER INVOKES {
    noteSubscriberPresent}
```

17.2.2.27 Alerting

This operation package includes the operations required for alerting between HLR and IWMSC.

```
AlertingPackage-v2 ::= OPERATION-PACKAGE
  -- Supplier is IWMSC if Consumer is HLR
  CONSUMER INVOKES {
    alertServiceCentre}
```

The v1-equivalent package is defined as follows.

```
AlertingPackage-v1 ::= OPERATION-PACKAGE
  -- Supplier is IWMSC if Consumer is HLR
  CONSUMER INVOKES {
    alertServiceCentreWithoutResult}
```

17.2.2.28 Data restoration

This operation package includes the operations required for VLR data restoration between HLR and VLR.

```
DataRestorationPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is HLR if Consumer is VLR
  CONSUMER INVOKES {
    restoreData}
```

The v2-equivalent package can be determined according to the rules described in subclause 17.2.1.

The v1-equivalent package is: **InfoRetrievalPackage-v1**

17.2.2.29 Purging

This operation package includes the operations required for purging between HLR and VLR or between HLR and SGSN.

```
PurgingPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is HLR if Consumer is VLR
  -- Supplier is HLR if Consumer is SGSN
  CONSUMER INVOKES {
    purgeMS}
```

The v2-equivalent package can be determined according to the rules described in subclause 17.2.1.

17.2.2.30 Subscriber information enquiry

This operation package includes the operations required for subscriber information enquiry procedures between HLR and VLR.

```
SubscriberInformationEnquiryPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is VLR if Consumer is HLR
  CONSUMER INVOKES {
    provideSubscriberInfo}
```

This package is v3 only.

17.2.2.31 Any time information enquiry

This operation package includes the operations required for any time information enquiry procedures between gsmSCF and HLR.

```
AnyTimeInformationEnquiryPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is HLR if Consumer is gsmSCF
  CONSUMER INVOKES {
    anyTimeInterrogation}
```

This package is v3 only.

17.2.2.32 Group Call Control

This operation package includes the operations required for group call and broadcast call procedures between MSCs.

```
GroupCallControlPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is relay MSC if Consumer is anchor MSC
  CONSUMER INVOKES {
    prepareGroupCall,
    forwardGroupCallSignalling}
  SUPPLIER INVOKES {
    sendGroupCallEndSignal,
    processGroupCallSignalling}
```

This package is v3 only.

17.2.2.33 Provide SIWFS number

This operation package includes the operations required between VMSC and SIWF for requesting resources from an SIWF.

```
ProvideSIWFSNumberPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is SIWF if Consumer is VMSC
  CONSUMER INVOKES {
    provideSIWFSNumber}
```

This package is v3 only.

17.2.2.34 SIWFS Signalling Modify

This operation package includes the operations required for the modification of the resources in an SIWF between the VMSC and SIWF.

```
SIWFSSignallingModifyPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is SIWF if Consumer is VMSC
  CONSUMER INVOKES {
    siWFSSignallingModify}
```

This package is v3 only.

17.2.2.35 Gprs location updating

This operation package includes the operations required for the gprs location management procedures between HLR and SGSN.

```
GprsLocationUpdatingPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is HLR if Consumer is SGSN
  CONSUMER INVOKES {
    updateGprsLocation}
```

This package is v3 only.

17.2.2.36 Gprs Interrogation

This operation package includes the operations required for interrogation procedures between HLR and GGSN.

```
GprsInterrogationPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is HLR if Consumer is GGSN
  CONSUMER INVOKES {
    sendRoutingInfoForGprs}
```

This package is v3 only.

17.2.2.37 Failure reporting

This operation package includes the operations required for failure reporting between HLR and GGSN.

```
FailureReportingPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is HLR if Consumer is GGSN
  CONSUMER INVOKES {
    failureReport}
```

This package is v3 only.

17.2.2.38 GPRS notifying

This operation package includes the operations required for notifying that GPRS subscriber is present between HLR and GGSN.

```
GprsNotifyingPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is GGSN if Consumer is HLR
  CONSUMER INVOKES {
    noteMsPresentForGprs}
```

This package is v3 only.

17.2.2.39 Supplementary Service invocation notification

This operation package includes the operations required for Supplementary Service invocation notification procedures between MSC and gsmSCF.

```
SS-InvocationNotificationPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is gsmSCF if Consumer is MSC
  CONSUMER INVOKES {
    ss-InvocationNotification}
```

This package is v3 only.

17.2.2.40 Set Reporting State

This operation package includes the operation required for procedures between HLR and VLR to set the reporting state.

```
SetReportingStatePackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is VLR if Consumer is HLR
  CONSUMER INVOKES {
    setReportingState}
```

This package is v3 only.

17.2.2.41 Status Report

This operation package includes the operation required for procedures between VLR and HLR to report call results and events.

```
StatusReportPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is HLR if Consumer is VLR
  CONSUMER INVOKES {
    statusReport}
```

This package is v3 only.

17.2.2.42 Remote User Free

This operation package includes the operation required by the HLR to indicate to the VLR that the remote user is free.

```
RemoteUserFreePackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is VLR if Consumer is HLR
  CONSUMER INVOKES {
    remoteUserFree}
```

This package is v3 only.

17.2.2.43 Call Completion

This operation package includes the operations required for procedures between VLR and HLR for subscriber control of call completion services.

```
CallCompletionPackage-v3 ::= OPERATION-PACKAGE
  -- Supplier is HLR if Consumer is VLR
  CONSUMER INVOKES {
    registerCC-Entry,
    eraseCC-Entry}
```

This package is v3 only.

17.2.2.44 Location service gateway services

This operation package includes the operations required for location service gateway procedures between GMLC and HLR.

```
LocationSvcGatewayPackage-v3 ::= OPERATION-PACKAGE
-- Supplier is HLR if Consumer is GMLC
CONSUMER INVOKES {
    sendRoutingInfoForLCS}
```

This package is v3 only.

17.2.2.45 Location service enquiry

This operation package includes the operations required for the location service enquiry procedures between GMLC and MSC.

```
LocationSvcEnquiryPackage-v3 ::= OPERATION-PACKAGE
-- Supplier is MSC if Consumer is GMLC
CONSUMER INVOKES {
    provideSubscriberLocation}
```

This package is v3 only.

17.2.2.45A Location service reporting

This operation package includes the operations required for the location service enquiry procedures between MSC and GMLC.

```
LocationSvcReportingPackage-v3 ::= OPERATION-PACKAGE
-- Supplier is GMLC if Consumer is MSC
CONSUMER INVOKES {
    subscriberLocationReport}
```

17.2.2.46 Void

17.2.2.47 Void

17.2.2.48 Void

17.3 Application contexts

17.3.1 General aspects

An application-context is assigned for each dialogue established by a MAP-user. In the present document each application-context is assigned a name which is supplied in the MAP-OPEN Req primitive by the MAP-User and transmitted to the peer under certain circumstances.

The following ASN.1 MACRO is used to describe the main aspects of application-contexts in the following subclauses:

```
APPLICATION-CONTEXT MACRO ::=

BEGIN

TYPE NOTATION ::= Symmetric | InitiatorConsumerOf
ResponderConsumerOf | empty

VALUE NOTATION ::= value(VALUE OBJECT IDENTIFIER)

Symmetric ::= "OPERATIONS OF" "{" PackageList "}"

InitiatorConsumerOf ::= "INITIATOR CONSUMER OF" "{" PackageList "}"

ResponderConsumerOf ::= "RESPONDER CONSUMER OF" "{" PackageList "}"
| empty

PackageList ::= Package | PackageList "," Package

Package ::= value(OPERATION-PACKAGE)
| type -- shall reference a package type

END
```

The following definitions are used throughout this subclause:

- v1-application-context: An application-context which contains only v1-packages and uses only TC v1 facilities;
- v1 context set: the set of v1-application-contexts defined in the present document.
- vn-application-context (n>=2): An application-context which contains only vn-packages;

The names of v1-application-contexts are suffixed by "-v1" while other names are suffixed by "-vn" where n>=2.

Application-contexts which do not belong to the v1 context set use v2 TC facilities.

The last component of each application-context-name (i.e. the last component of the object identifier value) assigned to an application-context which belongs to the v1 context set indicates explicitly "version1".

For each application-context which does not belong to the "v1 context set" there is a v1-equivalent application context. This is a v1-application-context which includes the v1-equivalents of the packages included in the original context.

Each application-context uses the abstract-syntax associated with the operation-packages it includes and uses the transfer-syntax derived from it by applying the encoding rules defined in subclause 17.1.1.

ACs which do not belong to the v1 context set require the support of the abstract-syntax identified by the object identifier value: MAP-DialogueInformation.map-Dialogue-AS defined in subclause 17.4.

17.3.2 Application context definitions

17.3.2.1 Void

17.3.2.2 Location Updating

This application context is used between HLR and VLR for location updating procedures.

```
networkLocUpContext-v3 APPLICATION-CONTEXT
-- Responder is HLR if Initiator is VLR
INITIATOR CONSUMER OF {
    LocationUpdatingPackage-v3,
    DataRestorationPackage-v3}
RESPONDER CONSUMER OF {
    SubscriberDataMngtPackage-v3
    TracingPackage-v3}
::= {map-ac networkLocUp(1) version3(3)}
```

The following application-context-name is assigned to the v2-equivalent application-context:

{map-ac networkLocUp(1) version2(2)}

The following application-context-name is assigned to the v1-equivalent application-context:

{map-ac networkLocUp(1) version1(1)}

17.3.2.3 Location Cancellation

This application context is used between HLR and VLR or between HLR and SGSN for location cancellation procedures. For the HLR - SGSN interface only version 3 of this application context is applicable.

<pre>locationCancellationContext-v3 APPLICATION-CONTEXT -- Responder is VLR or SGSN if Initiator is HLR INITIATOR CONSUMER OF { LocationCancellationPackage-v3} ::= {map-ac locationCancel(2) version3(3)}</pre>

The following application-context-name is assigned to the v2-equivalent application-context:

{map-ac locationCancel(2) version2(2)}
--

The following application-context-name is assigned to the v1-equivalent application-context:

{map-ac locationCancel(2) version1(1)}
--

17.3.2.4 Roaming number enquiry

This application context is used between HLR and VLR for roaming number enquiry procedures.

<pre>roamingNumberEnquiryContext-v3 APPLICATION-CONTEXT -- Responder is VLR if Initiator is HLR INITIATOR CONSUMER OF { RoamingNumberEnquiryPackage-v3} ::= {map-ac roamingNbEnquiry(3) version3(3)}</pre>

The following application-context-name is assigned to the v2-equivalent application-context:

{map-ac roamingNbEnquiry(3) version2(2)}
--

The following application-context-name is assigned to the v1-equivalent application-context:

{map-ac roamingNbEnquiry(3) version1(1)}
--

17.3.2.5 Void

17.3.2.6 Location Information Retrieval

This application-context is used between GMSC and HLR or between GMSC and NPLR when retrieving location information. For the GMSC - NPLR interface version 1, version 2 and version 3 of this application context are applicable.

<pre>locationInfoRetrievalContext-v3 APPLICATION-CONTEXT -- Responder is HLR or NPLR if Initiator is GMSC INITIATOR CONSUMER OF { InterrogationPackage-v3} ::= {map-ac locInfoRetrieval(5) version3(3)}</pre>
--

The following application-context-name is assigned to the v2-equivalent application-context:

{map-ac locInfoRetrieval(5) version2(2)}
--

The following application-context-name is assigned to the v1-equivalent application-context:

{map-ac locInfoRetrieval(5) version1(1)}
--

17.3.2.7 Call control transfer

This application context is used for the call control transfer procedure between the VMSC and the GMSC.

```
callControlTransferContext-v4 APPLICATION-CONTEXT
  -- Responder is GMSC if Initiator is VMSC
  INITIATOR CONSUMER OF {
    CallControlTransferPackage-v4}
  ::= {map-ac callControlTransfer(6) version4(4)}
```

The following application-context-name is assigned to the v3-equivalent application-context:

```
{map-ac callControlTransfer(6) version3(3)}
```

17.3.2.8 - 17.3.2.10 Void

17.3.2.11 Location registers restart

This application context is used between HLR and VLR or between HLR and SGSN for location register restart procedures. For the HLR - SGSN interface version 1 and version 2 of this application context are applicable.

```
resetContext-v2 APPLICATION-CONTEXT
  -- Responder is VLR or SGSN if Initiator is HLR
  INITIATOR CONSUMER OF {
    ResetPackage-v2}
  ::= {map-ac reset(10) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
{map-ac reset(10) version1(1)}
```

17.3.2.12 Handover control

This application context is used for handover procedures between MSCs.

```
handoverControlContext-v2 APPLICATION-CONTEXT
  -- Responder is MSCB if Initiator is MSCA
  INITIATOR CONSUMER OF {
    HandoverControlPackage-v2}
  ::= {map-ac handoverControl(11) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
{map-ac handoverControl(11) version1(1)}
```

17.3.2.13 IMSI Retrieval

This application context is used for IMSI retrieval between HLR and VLR.

```
imsiRetrievalContext-v2 APPLICATION-CONTEXT
  -- Responder is HLR if Initiator is VLR
  INITIATOR CONSUMER OF {
    IMSIRetrievalPackage-v2}
  ::= {map-ac imsiRetrieval(26) version2(2)}
```

This application-context is v2 only.

17.3.2.14 Equipment Management

This application context is used for equipment checking between MSC and EIR or between SGSN and EIR. For the SGSN - EIR interface version 1 and version 2 of this application context are applicable:

```
equipmentMngtContext-v2 APPLICATION-CONTEXT
  -- Responder is EIR if Initiator is MSC
  -- Responder is EIR if Initiator is SGSN
  INITIATOR CONSUMER OF {
    EquipmentMngtPackage-v2}
  ::= {map-ac equipmentMngt(13) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
{map-ac equipmentMngt(13) version1(1)}
```

17.3.2.15 Information retrieval

This application context is used for authentication information retrieval between HLR and VLR or between HLR and SGSN. For the HLR - SGSN interface version 1 and version 2 of this application context are applicable.

```
infoRetrievalContext-v2 APPLICATION-CONTEXT
  -- Responder is HLR if Initiator is VLR
  -- Responder is HLR if Initiator is SGSN
  INITIATOR CONSUMER OF {
    InfoRetrievalPackage-v2}
::= {map-ac infoRetrieval(14) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
-- Responder is HLR if Initiator is VLR
{map-ac infoRetrieval(14) version1(1)}
```

17.3.2.16 Inter-VLR information retrieval

This application context is used for information retrieval between VLRs.

```
interVlrInfoRetrievalContext-v2 APPLICATION-CONTEXT
  -- Responder is VLR if Initiator is VLR
  INITIATOR CONSUMER OF {
    InterVlrInfoRetrievalPackage-v2}
::= {map-ac interVlrInfoRetrieval(15) version2(2)}
```

The v1-equivalent application-context is:

```
-- Responder is VLR if Initiator is VLR
{map-ac infoRetrieval(14) version1(1)}
```

17.3.2.17 Stand Alone Subscriber Data Management

This application context is used for stand alone subscriber data management between HLR and VLR or between HLR and SGSN. For the HLR - SGSN interface only version 3 of this application context is applicable:

```
subscriberDataMngtContext-v3 APPLICATION-CONTEXT
  -- Responder is VLR or SGSN if Initiator is HLR
  INITIATOR CONSUMER OF {
    SubscriberDataMngtStandAlonePackage-v3}
::= {map-ac subscriberDataMngt(16) version3(3)}
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
{map-ac subscriberDataMngt(16) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
{map-ac subscriberDataMngt(16) version1(1)}
```

17.3.2.18 Tracing

This application context is used between HLR and VLR or between HLR and SGSN for stand alone tracing control procedures: For the HLR - SGSN interface version 1, version 2 and version 3 of this application context are applicable.

```
tracingContext-v3 APPLICATION-CONTEXT
  -- Responder is VLR or SGSN if Initiator is HLR
  INITIATOR CONSUMER OF {
    TracingStandalonePackage-v3}
::= {map-ac tracing(17) version3(3)}
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
{map-ac tracing(17) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
{map-ac tracing(17) version1(1)}
```

17.3.2.19 Network functional SS handling

This application context is used for functional-like SS handling procedures between VLR and HLR.

```
networkFunctionalSsContext-v2 APPLICATION-CONTEXT
  -- Responder is HLR, Initiator is VLR
  INITIATOR CONSUMER OF {
    FunctionalSsPackage-v2}
  ::= {map-ac networkFunctionalSs(18) version2(2)}
```

The v1-equivalent application-context is defined as follows:

```
networkFunctionalSsContext-v1 APPLICATION-CONTEXT
  -- Responder is HLR, Initiator is VLR
  INITIATOR CONSUMER OF {
    FunctionalSsPackage-v1,
    UnstructuredSsPackage-v1,
    BindingPackage-v1}
  ::= {map-ac networkFunctionalSs(18) version1(1)}
```

17.3.2.20 Network unstructured SS handling

This application context is used for handling stimuli-like procedures between HLR and VLR, and between the HLR and gsmSCF.

```
networkUnstructuredSsContext-v2 APPLICATION-CONTEXT
  -- Responder is HLR, Initiator is VLR
  -- Responder is VLR, Initiator is HLR
  -- Responder is gsmSCF, Initiator is HLR
  -- Responder is HLR, Initiator is gsmSCF
  OPERATIONS OF {
    UnstructuredSsPackage-v2}
  ::= {map-ac networkUnstructuredSs(19) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
{map-ac networkFunctionalSs(18) version1(1)}
```

17.3.2.21 Short Message Gateway

This application context is used for short message gateway procedures.

```
shortMsgGatewayContext-v3 APPLICATION-CONTEXT
  -- Responder is HLR if Initiator is GMSC
  INITIATOR CONSUMER OF {
    ShortMsgGatewayPackage-v3}
  ::= {map-ac shortMsgGateway(20) version3(3)}
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
{map-ac shortMsgGateway(20) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
{map-ac shortMsgGateway(20) version1(1)}
```

17.3.2.22 Mobile originating Short Message Relay

This application context is used between MSC and IWMSC or between SGSN and IWMSC for mobile originating short message relay procedures. For the SGSN - IWMSC interface version 1, version 2 and version 3 of this application context are applicable.

```
shortMsgMO-RelayContext-v3 APPLICATION-CONTEXT
  -- Responder is IWMSC if Initiator is MSC
  -- Responder is IWMSC if Initiator is SGSN
  INITIATOR CONSUMER OF {
    MOShortMsgRelayPackage-v3}
  ::= {map-ac shortMsgMO-Relay(21) version3(3)}
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
{map-ac shortMsgMO-Relay(21) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
{map-ac shortMsg-Relay(21) version1(1)}
```

17.3.2.23 Void

17.3.2.24 Short message alert

This application context is used for short message alerting procedures.

```
shortMsgAlertContext-v2 APPLICATION-CONTEXT
  -- Responder is IWMSC if Initiator is HLR
  INITIATOR CONSUMER OF {
    AlertingPackage-v2}
  ::= {map-ac shortMsgAlert(23) version2(2)}
```

The following application-context-name is symbolically assigned to the v1-equivalent application-context:

```
{map-ac shortMsgAlert(23) version1(1)}
```

17.3.2.25 Short message waiting data management

This application context is used between VLR and HLR or between SGSN and HLR for short message waiting data management procedures. For the SGSN - HLR interface only version 3 of this application context is applicable.

```
mwdMngtContext-v3 APPLICATION-CONTEXT
  -- Responder is HLR if Initiator is SGSN
  -- Responder is HLR if Initiator is VLR
  INITIATOR CONSUMER OF {
    MwdMngtPackage-v3}
  ::= {map-ac mwdMngt(24) version3(3)}
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
{map-ac mwdMngt(24) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
{map-ac mwdMngt(24) version1(1)}
```

17.3.2.26 Mobile terminating Short Message Relay

This application context is used between GMSC and MSC or between GMSC and SGSN for mobile terminating short message relay procedures. For the GMSC - SGSN interface version 2and version 3 of this application context and the equivalent version 1 application context are applicable.

```
shortMsgMT-RelayContext-v3 APPLICATION-CONTEXT
  -- Responder is MSC or SGSN if Initiator is GMSC
  INITIATOR CONSUMER OF {
    MTShortMsgRelayPackage-v3}
  ::= {map-ac shortMsgMT-Relay(25) version3(3)}
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
{map-ac shortMsgMT-Relay(25) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
{map-ac shortMsgMO-Relay(21) version1(1)}
```

17.3.2.27 MS purging

This application context is used between HLR and VLR or between HLR and SGSN for MS purging procedures. For the SGSN - HLR interface only version 3 of this application context is applicable.

```
msPurgingContext-v3 APPLICATION-CONTEXT
  -- Responder is HLR if Initiator is VLR
  -- Responder is HLR if Initiator is SGSN
  INITIATOR CONSUMER OF {
    purgingPackage-v3}
  ::= {map-ac msPurging(27) version3(3)}
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
{map-ac msPurging(27) version2(2)}
```

17.3.2.28 Subscriber information enquiry

This application context is used between HLR and VLR for subscriber information enquiry procedures.

```
subscriberInfoEnquiryContext-v3 APPLICATION-CONTEXT
  -- Responder is VLR if Initiator is HLR
  INITIATOR CONSUMER OF {
    SubscriberInformationEnquiryPackage-v3}
  ::= {map-ac subscriberInfoEnquiry(28) version3(3)}
```

This application-context is v3 only.

17.3.2.29 Any time information enquiry

This application context is used between gsmSCF and HLR for any time information enquiry procedures.

```
anyTimeInfoEnquiryContext-v3 APPLICATION-CONTEXT
  -- Responder is HLR if Initiator is gsmSCF
  INITIATOR CONSUMER OF {
    AnyTimeInformationEnquiryPackage-v3}
  ::= {map-ac anyTimeInfoEnquiry(29) version3(3)}
```

This application-context is v3 only.

17.3.2.30 Group Call Control

This application context is used between anchor MSC and relay MSC for group call and broadcast call procedures.

```
groupCallControlContext-v3 APPLICATION-CONTEXT
  -- Responder is relay MSC if Initiator is anchor MSC
  INITIATOR CONSUMER OF {
    GroupCallControlPackage-v3}
  ::= {map-ac groupCallControl(31) version3(3)}
```

This application-context is v3 only.

17.3.2.31 Provide SIWFS Number

This application context is used for activation or modification of SIWF resources.

```
siwfsAllocationContext-v3 APPLICATION-CONTEXT
  -- Responder is SIWF if Initiator is VMSC
  INITIATOR CONSUMER OF {
    ProvideSIWFSNumberPackage-v3,
    SIWFSSignallingModifyPackage-v3}
  ::= {map-ac siwfsAllocation (12) version3(3)}
```

This application-context is v3 only.

17.3.2.32 Gprs Location Updating

This application context is used between HLR and SGSN for gprs location updating procedures.

```
gprsLocationUpdateContext-v3 APPLICATION-CONTEXT
  -- Responder is HLR if Initiator is SGSN
  INITIATOR CONSUMER OF {
    GprsLocationUpdatingPackage-v3}
  RESPONDER CONSUMER OF {
    SubscriberDataMngtPackage-v3
    TracingPackage-v3}
  ::= {map-ac gprsLocationUpdate(32) version3(3)}
```

This application-context is v3 only.

17.3.2.33 Gprs Location Information Retrieval

This application context is used between HLR and GGSN when retrieving gprs location information.

```
gprsLocationInfoRetrievalContext-v3 APPLICATION-CONTEXT
  -- Responder is HLR if Initiator is GGSN
  INITIATOR CONSUMER OF {
    GprsInterrogationPackage-v3}
  ::= {map-ac gprsLocationInfoRetrieval(33) version3(3)}
```

This application-context is v3 only.

17.3.2.34 Failure Reporting

This application context is used between HLR and GGSN to inform that network requested PDP-context activation has failed.

```
failureReportContext-v3 APPLICATION-CONTEXT
  -- Responder is HLR if Initiator is GGSN
  INITIATOR CONSUMER OF {
    FailureReportingPackage-v3}
  ::= {map-ac failureReport(34) version3(3)}
```

This application-context is v3 only.

17.3.2.35 GPRS Notifying

This application context is used between HLR and GGSN for notifying that GPRS subscriber is present again.

```
gprsNotifyContext-v3 APPLICATION-CONTEXT
  -- Responder is GGSN if Initiator is HLR
  INITIATOR CONSUMER OF {
    GprsNotifyingPackage-v3}
  ::= {map-ac gprsNotify(35) version3(3)}
```

This application-context is v3 only.

17.3.2.36 Supplementary Service invocation notification

This application context is used between MSC and gsmSCF for Supplementary Service invocation notification procedures.

```
ss-InvocationNotificationContext-v3 APPLICATION-CONTEXT
  -- Responder is gsmSCF, Initiator is MSC
  INITIATOR CONSUMER OF {
    SS-InvocationNotificationPackage-v3}
  ::= {map-ac ss-InvocationNotification(36) version3(3)}
```

This application-context is v3 only.

17.3.2.37 Reporting

This application context is used between HLR and VLR for reporting procedures.

```
reportingContext-v3 APPLICATION-CONTEXT
  -- Responder is VLR if Initiator is HLR
  -- Responder is HLR if Initiator is VLR
  INITIATOR CONSUMER OF {
    SetReportingStatePackage-v3,
    StatusReportPackage-v3,
    RemoteUserFreePackage-v3}
  RESPONDER CONSUMER OF {
    SetReportingStatePackage-v3,
    StatusReportPackage-v3}
  ::= {map-ac reporting(7) version3(3)}
```

This application-context is v3 only.

17.3.2.38 Call Completion

This application context is used between VLR and the HLR for subscriber control of call completion services.

```
callCompletionContext-v3 APPLICATION-CONTEXT
  -- Responder is HLR if Initiator is VLR
  INITIATOR CONSUMER OF {
    CallCompletionPackage-v3}
  ::= {map-ac callCompletion(8) version3(3)}
```

This application-context is v3 only.

17.3.2.39 Location Service Gateway

This application context is used for location service gateway procedures.

```
locationSvcGatewayContext-v3 APPLICATION-CONTEXT
  -- Responder is HLR if Initiator is GMLC
  INITIATOR CONSUMER OF {
    locationSvcGatewayPackage-v3}
  ::= {map-ac locationSvcGateway(37) version3(3)}
```

17.3.2.40 Location Service Enquiry

This application context is used for location service enquiry procedures.

```
locationSvcEnquiryContext-v3 APPLICATION-CONTEXT
  -- Responder is MSC if Initiator is GMLC
  -- Responder is GMLC if Initiator is MSC
  INITIATOR CONSUMER OF {
    locationSvcEnquiryPackage-v3,
    locationSvcReportingPackage-v3}
 ::= {map-ac locationSvcEnquiry(38) version3 (3)}
```

17.3.2.41 Void

17.3.2.42 Void

17.3.2.43 Void

17.3.3 ASN.1 Module for application-context-names

The following ASN.1 module summarizes the application-context-name assigned to MAP application-contexts.

```
1 MAP-ApplicationContexts {
2   ccitt identified-organization (4) etsi (0) mobileDomain (0)
3   gsm-Network (1) modules (3) map-ApplicationContexts (2) version5 (5)}
4
5 DEFINITIONS
6
7 ::=-
8
9 BEGIN
10
11 -- EXPORTS everything
12
13
14 IMPORTS
15   gsm-NetworkId,
16   ac-Id
17
18 FROM MobileDomainDefinitions {
19   ccitt (0) identified-organization (4) etsi (0) mobileDomain (0)
20   mobileDomainDefinitions (0) version1 (1)}
21 ;
22
23 -- application-context-names
24
25 map-ac OBJECT IDENTIFIER ::= {gsm-NetworkId ac-Id}
26
27 networkLocUpContext-v3 OBJECT IDENTIFIER ::=
28   {map-ac networkLocUp(1) version3(3)}
29
30 locationCancellationContext-v3 OBJECT IDENTIFIER ::=
31   {map-ac locationCancel(2) version3(3)}
32
33 roamingNumberEnquiryContext-v3 OBJECT IDENTIFIER ::=
34   {map-ac roamingNbEnquiry(3) version3(3)}
35
36 locationInfoRetrievalContext-v3 OBJECT IDENTIFIER ::=
37   {map-ac locInfoRetrieval(5) version3(3)}
38
39 resetContext-v2 OBJECT IDENTIFIER ::=
40   {map-ac reset(10) version2(2)}
41
42 handoverControlContext-v2 OBJECT IDENTIFIER ::=
43   {map-ac handoverControl(11) version2(2)}
44
45 equipmentMngtContext-v2 OBJECT IDENTIFIER ::=
46   {map-ac equipmentMngt(13) version2(2)}
```

```

48 infoRetrievalContext-v2 OBJECT IDENTIFIER ::= 
49   {map-ac infoRetrieval(14) version2(2)}
50
51 interVlrInfoRetrievalContext-v2 OBJECT IDENTIFIER ::= 
52   {map-ac interVlrInfoRetrieval(15) version2(2)}
53
54 subscriberDataMngtContext-v3 OBJECT IDENTIFIER ::= 
55   {map-ac subscriberDataMngt(16) version3(3)}
56
57 tracingContext-v3 OBJECT IDENTIFIER ::= 
58   {map-ac tracing(17) version3(3)}
59
60 networkFunctionalSsContext-v2 OBJECT IDENTIFIER ::= 
61   {map-ac networkFunctionalSs(18) version2(2)}
62
63 networkUnstructuredSsContext-v2 OBJECT IDENTIFIER ::= 
64   {map-ac networkUnstructuredSs(19) version2(2)}
65
66 shortMsgGatewayContext-v3 OBJECT IDENTIFIER ::= 
67   {map-ac shortMsgGateway(20) version3(3)}
68
69 shortMsgMO-RelayContext-v3 OBJECT IDENTIFIER ::= 
70   {map-ac shortMsgMO-Relay(21) version3(3)}
71
72 shortMsgAlertContext-v2 OBJECT IDENTIFIER ::= 
73   {map-ac shortMsgAlert(23) version2(2)}
74
75 mwdMngtContext-v3 OBJECT IDENTIFIER ::= 
76   {map-ac mwdMngt(24) version3(3)}
77
78 shortMsgMT-RelayContext-v3 OBJECT IDENTIFIER ::= 
79   {map-ac shortMsgMT-Relay(25) version3(3)}
80
81 imsiRetrievalContext-v2 OBJECT IDENTIFIER ::= 
82   {map-ac imsiRetrieval(26) version2(2)}
83
84 msPurgingContext-v3 OBJECT IDENTIFIER ::= 
85   {map-ac msPurging(27) version3(3)}
86
87 subscriberInfoEnquiryContext-v3 OBJECT IDENTIFIER ::= 
88   {map-ac subscriberInfoEnquiry(28) version3(3)}
89
90 anyTimeInfoEnquiryContext-v3 OBJECT IDENTIFIER ::= 
91   {map-ac anyTimeInfoEnquiry(29) version3(3)}
92
93 callControlTransferContext-v4 OBJECT IDENTIFIER ::= 
94   {map-ac callControlTransfer(6) version4(4)}
95
96 ss-InvocationNotificationContext-v3 OBJECT IDENTIFIER ::= 
97   {map-ac ss-InvocationNotification(36) version3(3)}
98
99 sIWFSAllocationContext-v3 OBJECT IDENTIFIER ::= 
100  {map-ac sIWFSAllocation(12) version3(3)}
101
102 groupCallControlContext-v3 OBJECT IDENTIFIER ::= 
103  {map-ac groupCallControl(31) version3(3)}
104
105 gprsLocationUpdateContext-v3 OBJECT IDENTIFIER ::= 
106  {map-ac gprsLocationUpdate(32) version3(3)}
107
108 gprsLocationInfoRetrievalContext-v3 OBJECT IDENTIFIER ::= 
109  {map-ac gprsLocationInfoRetrieval(33) version3(3)}
110
111 failureReportContext-v3 OBJECT IDENTIFIER ::= 
112  {map-ac failureReport(34) version3(3)}
113
114 gprsNotifyContext-v3 OBJECT IDENTIFIER ::= 
115  {map-ac gprsNotify(35) version3(3)}
116
117 reportingContext-v3 OBJECT IDENTIFIER ::= 
118  {map-ac reporting(7) version3(3)}
119
120 callCompletionContext-v3 OBJECT IDENTIFIER ::= 
121  {map-ac callCompletion(8) version3(3)}
122

```

```

123 locationSvcGatewayContext-v3 OBJECT IDENTIFIER ::=
124   {map-ac locationSvcGateway(37) version3(3)}
125
126 locationSvcEnquiryContext-v3 OBJECT IDENTIFIER ::=
127   {map-ac locationSvcEnquiry(38) version3(3)}
128
129
130 -- The following Object Identifiers are reserved for application-
131 -- contexts existing in previous versions of the protocol
132

```

-- AC Name & Version	Object Identifier	
--		
-- networkLocUpContext-v1	map-ac networkLocUp (1)	version1 (1)
-- networkLocUpContext-v2	map-ac networkLocUp (1)	version2 (2)
-- locationCancellationContext-v1	map-ac locationCancellation (2)	version1 (1)
-- locationCancellationContext-v2	map-ac locationCancellation (2)	version2 (2)
-- roamingNumberEnquiryContext-v1	map-ac roamingNumberEnquiry (3)	version1 (1)
-- roamingNumberEnquiryContext-v2	map-ac roamingNumberEnquiry (3)	version2 (2)
-- locationInfoRetrievalContext-v1	map-ac locationInfoRetrieval (5)	version1 (1)
-- locationInfoRetrievalContext-v2	map-ac locationInfoRetrieval (5)	version2 (2)
-- resetContext-v1	map-ac reset (10)	version1 (1)
-- handoverControlContext-v1	map-ac handoverControl (11)	version1 (1)
-- equipmentMngtContext-v1	map-ac equipmentMngt (13)	version1 (1)
-- infoRetrievalContext-v1	map-ac infoRetrieval (14)	version1 (1)
-- subscriberDataMngtContext-v1	map-ac subscriberDataMngt (16)	version1 (1)
-- subscriberDataMngtContext-v2	map-ac subscriberDataMngt (16)	version2 (2)
-- tracingContext-v1	map-ac tracing (17)	version1 (1)
-- tracingContext-v2	map-ac tracing (17)	version2 (2)
-- networkFunctionalSsContext-v1	map-ac networkFunctionalSs (18)	version1 (1)
-- shortMsgGatewayContext-v1	map-ac shortMsgGateway (20)	version1 (1)
-- shortMsgGatewayContext-v2	map-ac shortMsgGateway (20)	version2 (2)
-- shortMsgRelayContext-v1	map-ac shortMsgRelay (21)	version1 (1)
-- shortMsgAlertContext-v1	map-ac shortMsgAlert (23)	version1 (1)
-- mwdlMngtContext-v1	map-ac mwdlMngt (24)	version1 (1)
-- mwdlMngtContext-v2	map-ac mwdlMngt (24)	version2 (2)
-- shortMsgMT-RelayContext-v2	map-ac shortMsgMT-Relay (25)	version2 (2)
-- msPurgingContext-v2	map-ac msPurging (27)	version2 (2)
-- callControlTransferContext-v3	map-ac callControlTransferContext (6)	version3 (3)

```

161
162
163 END

```

17.4 MAP Dialogue Information

```

1 MAP-DialogueInformation {
2   ccitt identified-organization (4) etsi (0) mobileDomain (0)
3   gsm-Network (1) modules (3) map-DialogueInformation (3) version5 (5)
4
5 DEFINITIONS
6
7 IMPLICIT TAGS
8
9 ::==
10
11 BEGIN
12
13 EXPORTS
14   map-DialogueAS,
15   MAP-DialoguePDU
16 ;
17
18 IMPORTS
19   gsm-NetworkId,
20   as-Id
21 FROM MobileDomainDefinitions {
22   ccitt (0) identified-organization (4) etsi (0) mobileDomain (0)
23   mobileDomainDefinitions (0) version1 (1)
24
25   AddressString
26 FROM MAP-CommonDataTypes {
27   ccitt identified-organization (4) etsi (0) mobileDomain (0)
28   gsm-Network(1) modules (3) map-CommonDataTypes (18) version5 (5)
29
30   ExtensionContainer
31 FROM MAP-ExtensionDataTypes {
32   ccitt identified-organization (4) etsi (0) mobileDomain (0)
33   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version5 (5)

```

```

34
35 ;
36
37
38 -- abstract syntax name for MAP-DialoguePDU
39
40 map-DialogueAS OBJECT IDENTIFIER ::= {gsm-NetworkId as-Id map-DialoguePDU (1) version1 (1)}
41
42
43 MAP-DialoguePDU ::= CHOICE {
44   map-open                               [0] MAP-OpenInfo,
45   map-accept                             [1] MAP-AcceptInfo,
46   map-close [2] MAP-CloseInfo,
47   map-refuse                            [3] MAP-RefuseInfo,
48   map-userAbort                         [4] MAP-UserAbortInfo,
49   map-providerAbort                     [5] MAP-ProviderAbortInfo}
50
51 MAP-OpenInfo ::= SEQUENCE {
52   destinationReference      [0] AddressString           OPTIONAL,
53   originationReference     [1] AddressString           OPTIONAL,
54   ...,
55   extensionContainer        ExtensionContainer         OPTIONAL
56   -- extensionContainer must not be used in version 2
57 }
58
59 MAP-AcceptInfo ::= SEQUENCE {
60   ...,
61   extensionContainer        ExtensionContainer         OPTIONAL
62   -- extensionContainer must not be used in version 2
63 }
64
65 MAP-CloseInfo ::= SEQUENCE {
66   ...,
67   extensionContainer        ExtensionContainer         OPTIONAL
68   -- extensionContainer must not be used in version 2
69 }
70
71 MAP-RefuseInfo ::= SEQUENCE {
72   reason    Reason,
73   ...,
74   extensionContainer        ExtensionContainer         OPTIONAL
75   -- extensionContainer must not be used in version 2
76 }
77
78 Reason ::= ENUMERATED {
79   noReasonGiven (0),
80   invalidDestinationReference (1),
81   invalidOriginatingReference (2)
82
83 MAP-UserAbortInfo ::= SEQUENCE {
84   map-UserAbortChoice          MAP-UserAbortChoice,
85   ...,
86   extensionContainer          ExtensionContainer         OPTIONAL
87   -- extensionContainer must not be used in version 2
88 }
89
90 MAP-UserAbortChoice ::= CHOICE {
91   userSpecificReason          [0] NULL,
92   userResourceLimitation     [1] NULL,
93   resourceUnavailable        [2] ResourceUnavailableReason,
94   applicationProcedureCancellation [3] ProcedureCancellationReason}
95
96 ResourceUnavailableReason ::= ENUMERATED {
97   shortTermResourceLimitation (0),
98   longTermResourceLimitation (1)}
99
100 ProcedureCancellationReason ::= ENUMERATED {
101   handoverCancellation (0),
102   radioChannelRelease (1),
103   networkPathRelease (2),
104   callRelease (3),
105   associatedProcedureFailure (4),
106   tandemDialogueRelease (5),
107   remoteOperationsFailure (6)}
108

```

```

109 MAP-ProviderAbortInfo ::= SEQUENCE {
110   map-ProviderAbortReason           MAP-ProviderAbortReason,
111   ...
112   extensionContainer               ExtensionContainer
113   -- extensionContainer must not be used in version 2
114 }
115
116 MAP-ProviderAbortReason ::= ENUMERATED {
117   abnormalDialogue (0),
118   invalidPDU (1)
119
120 END

```

17.5 MAP operation and error codes

```

1 MAP-Protocol {
2   ccitt identified-organization (4) etsi (0) mobileDomain (0)
3   gsm-Network (1) modules (3) map-Protocol (4) version5 (5)}
4
5 DEFINITIONS
6
7 ::=_
8
9 BEGIN
10
11 IMPORTS
12   UpdateLocation,
13   CancelLocation,
14   PurgeMS,
15   SendIdentification,
16   UpdateGprsLocation,
17   PrepareHandover,
18   SendEndSignal,
19   ProcessAccessSignalling,
20   ForwardAccessSignalling,
21   PrepareSubsequentHandover,
22   SendAuthenticationInfo,
23   CheckIMEI,
24   InsertSubscriberData,
25   DeleteSubscriberData,
26   Reset,
27   ForwardCheckSS-Indication,
28   RestoreData,
29   ProvideSubscriberInfo,
30   AnyTimeInterrogation,
31   SendRoutingInfoForGprs,
32   FailureReport,
33   NoteMsPresentForGprs
34
35
36 FROM MAP-MobileServiceOperations {
37   ccitt identified-organization (4) etsi (0) mobileDomain (0)
38   gsm-Network (1) modules (3) map-MobileServiceOperations (5)
39   version5 (5)}
40
41   ActivateTraceMode,
42   DeactivateTraceMode,
43   SendIMSI
44 FROM MAP-OperationAndMaintenanceOperations {
45   ccitt identified-organization (4) etsi (0) mobileDomain (0)
46   gsm-Network (1) modules (3) map-OperationAndMaintenanceOperations (6)
47   version5 (5)}
48
49   SendRoutingInfo,
50   ProvideRoamingNumber,
51   ResumeCallHandling,
52   ProvideSIWFSSNumber,
53   SIWFSSignallingModify,
54   SetReportingState,
55   StatusReport,
56   RemoteUserFree
57 FROM MAP-CallHandlingOperations {
58   ccitt identified-organization (4) etsi (0) mobileDomain (0)
59   gsm-Network (1) modules (3) map-CallHandlingOperations (7)
60   version5 (5)}
61
62   RegisterSS,
63   EraseSS,

```

```

64   ActivateSS,
65   DeactivateSS,
66   InterrogateSS,
67   ProcessUnstructuredSS-Request,
68   UnstructuredSS-Request,
69   UnstructuredSS-Notify,
70   RegisterPassword,
71   GetPassword,
72   SS-InvocationNotification,
73   RegisterCC-Entry,
74   EraseCC-Entry
75 FROM MAP-SupplementaryServiceOperations {
76   ccitt identified-organization (4) etsi (0) mobileDomain (0)
77   gsm-Network (1) modules (3) map-SupplementaryServiceOperations (8)
78   version5 (5)}
79
80   SendRoutingInfoForSM,
81   MO-ForwardSM,
82   MT-ForwardSM,
83   ReportSM-DeliveryStatus,
84   AlertServiceCentre,
85   InformServiceCentre,
86   ReadyForSM
87 FROM MAP-ShortMessageServiceOperations {
88   ccitt identified-organization (4) etsi (0) mobileDomain (0)
89   gsm-Network (1) modules (3) map-ShortMessageServiceOperations (9)
90   version5 (5)}
91
92   PrepareGroupCall,
93   ProcessGroupCallSignalling,
94   ForwardGroupCallSignalling,
95   SendGroupCallEndSignal
96 FROM MAP-Group-Call-Operations {
97   ccitt identified-organization (4) etsi (0) mobileDomain (0)
98   gsm-Network (1) modules (3) map-Group-Call-Operations (22)
99   version5 (5)}
100
101  ProvideSubscriberLocation,
102  SendRoutingInfoForLCS,
103  SubscriberLocationReport
104 FROM MAP-LocationServiceOperations {
105   ccitt identified-organization (4) etsi (0) mobileDomain (0)
106   gsm-Network (1) modules (3) map-LocationServiceOperations (24)
107   version5 (5)}
108
109  SystemFailure,
110  DataMissing,
111  UnexpectedDataValue,
112  FacilityNotSupported,
113  UnknownSubscriber,
114  NumberChanged,
115  UnknownMSC,
116  UnidentifiedSubscriber,
117  UnknownEquipment,
118  RoamingNotAllowed,
119  IllegalSubscriber,
120  IllegalEquipment,
121  BearerServiceNotProvisioned,
122  TeleserviceNotProvisioned,
123  NoHandoverNumberAvailable,
124  SubsequentHandoverFailure,
125  TracingBufferFull,
126  OR-NotAllowed,
127  NoRoamingNumberAvailable,
128  AbsentSubscriber,
129  BusySubscriber,
130  NoSubscriberReply,
131  CallBarred,
132  ForwardingViolation,
133  ForwardingFailed,
134  CUG-Reject,
135  ATI-NotAllowed,
136  IllegalSS-Operation,
137  SS-ErrorStatus,
138  SS-NotAvailable,
139  SS-SubscriptionViolation,
140  SS-Incompatibility,
141  UnknownAlphabet,
142  USSD-Busy,

```

```

143   PW-RegistrationFailure,
144   NegativePW-Check,
145   NumberOfPW-AttemptsViolation,
146   SubscriberBusyForMT-SMS,
147   SM-DeliveryFailure,
148   MessageWaitingListFull,
149   AbsentSubscriberSM,
150   ResourceLimitation,
151   NoGroupCallNumberAvailable,
152   ShortTermDenial,
153   LongTermDenial,
154   IncompatibleTerminal,
155   UnauthorizedRequestingNetwork,
156   UnauthorizedLCSClient,
157   PositionMethodFailure,
158   UnknownOrUnreachableLCSClient
159
160 FROM MAP-Errors {
161   ccitt identified-organization (4) etsi (0) mobileDomain (0)
162   gsm-Network (1) modules (3) map-Errors (10) version5 (5)}
163 ;
164
165
166 -- location registration operation codes
167
168 updateLocation UpdateLocation ::= localValue 2
169 cancelLocation CancelLocation ::= localValue 3
170 purgeMS PurgeMS ::= localValue 67
171 sendIdentification SendIdentification ::= localValue 55
172
173
174 -- handover operation codes
175
176 prepareHandover PrepareHandover ::= localValue 68
177 sendEndSignal SendEndSignal ::= localValue 29
178 processAccessSignalling ProcessAccessSignalling ::= localValue 33
179 forwardAccessSignalling ForwardAccessSignalling ::= localValue 34
180 prepareSubsequentHandover PrepareSubsequentHandover ::=
181   localValue 69
182
183
184 -- authentication operation codes
185
186 sendAuthenticationInfo SendAuthenticationInfo ::= localValue 56
187
188
189 -- IMEI MANAGEMENT operation codes
190
191 checkIMEI CheckIMEI ::= localValue 43
192
193
194 -- subscriber management operation codes
195
196 insertSubscriberData InsertSubscriberData ::= localValue 7
197 deleteSubscriberData DeleteSubscriberData ::= localValue 8
198
199
200 -- fault recovery operation codes
201
202 reset Reset ::= localValue 37
203 forwardCheckSS-Indication ForwardCheckSS-Indication ::=
204   localValue 38
205 restoreData RestoreData ::= localValue 57
206
207
208 -- operation and maintenance operation codes
209
210 activateTraceMode ActivateTraceMode ::= localValue 50
211 deactivateTraceMode DeactivateTraceMode ::= localValue 51
212 sendIMSI SendIMSI ::= localValue 58
213
214
215 -- call handling operation codes
216

```

```

217 sendRoutingInfo SendRoutingInfo ::= localValue 22
218 provideRoamingNumber ProvideRoamingNumber ::= localValue 4
219 resumeCallHandling ResumeCallHandling ::= localValue 6
220 providesIWFSNumber ProvideSIWFSSNumber ::= localValue 31
221 siWFSSignallingModify SIWFSSignallingModify ::= localValue 32
222 setReportingState SetReportingState ::= localValue 73
223 statusReport StatusReport ::= localValue 74
224 remoteUserFree RemoteUserFree ::= localValue 75
225
226
227 -- supplementary service handling operation codes
228
229 registerSS RegisterSS ::= localValue 10
230 erasESS ErasESS ::= localValue 11
231 activateSS ActivateSS ::= localValue 12
232 deactivateSS DeactivateSS ::= localValue 13
233 interrogateSS InterrogateSS ::= localValue 14
234 processUnstructuredSS-Request ProcessUnstructuredSS-Request ::=
235   localValue 59
236 unstructuredSS-Request UnstructuredSS-Request ::= localValue 60
237 unstructuredSS-Notify UnstructuredSS-Notify ::= localValue 61
238 registerPassword RegisterPassword ::= localValue 17
239 getPassword GetPassword ::= localValue 18
240 registerCC-Entry RegisterCC-Entry ::= localValue 76
241 eraseCC-Entry EraseCC-Entry ::= localValue 77
242
243
244 -- short message service operation codes
245
246 sendRoutingInfoForSM SendRoutingInfoForSM ::= localValue 45
247 mo-forwardSM MO-ForwardSM ::= localValue 46
248 mt-forwardSM MT-ForwardSM ::= localValue 44
249 reportSM-DeliveryStatus ReportSM-DeliveryStatus ::= localValue 47
250 informServiceCentre InformServiceCentre ::= localValue 63
251 alertServiceCentre AlertServiceCentre ::= localValue 64
252 readyForSM ReadyForSM ::= localValue 66
253
254 -- provide subscriber info operation codes
255
256 provideSubscriberInfo ProvideSubscriberInfo ::= localValue 70
257
258 -- any time interrogation operation codes
259
260 anyTimeInterrogation AnyTimeInterrogation ::= localValue 71
261
262 -- supplementary service invocation notification operation codes
263
264 ss-InvocationNotification SS-InvocationNotification ::= localValue 72
265
266
267 -- Group Call operation codes
268
269 prepareGroupCall PrepareGroupCall ::= localValue 39
270 sendGroupCallEndSignal SendGroupCallEndSignal ::= localValue 40
271 processGroupCallSignalling ProcessGroupCallSignalling ::= localValue 41
272 forwardGroupCallSignalling ForwardGroupCallSignalling ::= localValue 42
273
274
275 -- gprs location updating operation codes
276
277 updateGprsLocation UpdateGprsLocation ::= localValue 23
278
279 -- gprs location information retrieval operation codes
280
281 sendRoutingInfoForGprs SendRoutingInfoForGprs ::= localValue 24
282
283 -- failure reporting operation codes
284
285 failureReport FailureReport ::= localValue 25
286
287 -- GPRS notification operation codes
288
289 noteMsPresentForGprs NoteMsPresentForGprs ::= localValue 26
290

```

```

291 -- Location service operation codes
292
293 provideSubscriberLocation ProvideSubscriberLocation ::= localValue 83
294 sendRoutingInfoForLCS SendRoutingInfoForLCS ::= localValue 85
295 subscriberLocationReport SubscriberLocationReport ::= localValue 86
296
297
298 -- generic error codes
299
300 systemFailure SystemFailure ::= localValue 34
301 dataMissing DataMissing ::= localValue 35
302 unexpectedDataValue UnexpectedDataValue ::= localValue 36
303 facilityNotSupported FacilityNotSupported ::= localValue 21
304 incompatibleTerminal IncompatibleTerminal ::= localValue 28
305 resourceLimitation ResourceLimitation ::= localValue 51
306
307
308 -- identification and numbering error codes
309
310 unknownSubscriber UnknownSubscriber ::= localValue 1
311 numberChanged NumberChanged ::= localValue 44
312 unknownMSC UnknownMSC ::= localValue 3
313 unidentifiedSubscriber UnidentifiedSubscriber ::= localValue 5
314 unknownEquipment UnknownEquipment ::= localValue 7
315
316
317 -- subscription error codes
318
319 roamingNotAllowed RoamingNotAllowed ::= localValue 8
320 illegalSubscriber IllegalSubscriber ::= localValue 9
321 illegalEquipment IllegalEquipment ::= localValue 12
322 bearerServiceNotProvisioned BearerServiceNotProvisioned ::=
323     localValue 10
324 teleserviceNotProvisioned TeleserviceNotProvisioned ::=
325     localValue 11
326
327
328 -- handover error codes
329
330 noHandoverNumberAvailable NoHandoverNumberAvailable ::=
331     localValue 25
332 subsequentHandoverFailure SubsequentHandoverFailure ::=
333     localValue 26
334
335
336 -- operation and maintenance error codes
337
338 tracingBufferFull TracingBufferFull ::= localValue 40
339
340
341 -- call handling error codes
342
343 noRoamingNumberAvailable NoRoamingNumberAvailable ::= localValue 39
344 absentSubscriber AbsentSubscriber ::= localValue 27
345 busySubscriber BusySubscriber ::= localValue 45
346 noSubscriberReply NoSubscriberReply ::= localValue 46
347 callBarred CallBarred ::= localValue 13
348 forwardingFailed ForwardingFailed ::= localValue 47
349 or-NotAllowed OR-NotAllowed ::= localValue 48
350 forwardingViolation ForwardingViolation ::= localValue 14
351 cug-Reject CUG-Reject ::= localValue 15
352
353
354 -- any time interrogation error codes
355 ati-NotAllowed ATI-NotAllowed ::= localValue 49
356
357
358 -- Group Call error codes
359 noGroupCallNumberAvailable NoGroupCallNumberAvailable ::= localValue 50
360
361
362 -- supplementary service error codes
363

```

```

364 illegalSS-Operation IllegalSS-Operation ::= localValue 16
365 ss-ErrorStatus SS-ErrorStatus ::= localValue 17
366 ss-NotAvailable SS-NotAvailable ::= localValue 18
367 ss-SubscriptionViolation SS-SubscriptionViolation ::= localValue 19
368 ss-Incompatibility SS-Incompatibility ::= localValue 20
369 unknownAlphabet UnknownAlphabet ::= localValue 71
370 ussd-Busy USSD-Busy ::= localValue 72
371 pw-RegistrationFailure PW-RegistrationFailure ::= localValue 37
372 negativePW-Check NegativePW-Check ::= localValue 38
373 numberOfPW-AttemptsViolation NumberOfPW-AttemptsViolation ::= localValue 43
374 shortTermDenial ShortTermDenial ::= localValue 29
375 longTermDenial LongTermDenial ::= localValue 30
376
377
378 -- short message service error codes
379
380
381 subscriberBusyForMT-SMS SubscriberBusyForMT-SMS ::= localValue 31
382 sm-DeliveryFailure SM-DeliveryFailure ::= localValue 32
383 messageWaitingListFull MessageWaitingListFull ::= localValue 33
384 absentsubscriberSM AbsentSubscriberSM ::= localValue 6
385
386 -- location service error codes
387
388 unauthorizedRequestingNetwork UnauthorizedRequestingNetwork ::= localValue 52
389 unauthorizedLCSClient UnauthorizedLCSClient ::= localValue 53
390 positionMethodFailure PositionMethodFailure ::= localValue 54
391 unknownOrUnreachableLCSClient UnknownOrUnreachableLCSClient ::= localValue 58
392
393
394 -- The following operation codes are reserved for operations
395 -- existing in previous versions of the protocol
396
397 -- Operation Name          AC used           Oper. Code
398 --
399 -- sendParameters          map-ac infoRetrieval (14) version1 (1)    localValue 9
400 -- processUnstructuredSS-Data map-ac networkFunctionalSs (18) version1 (1)  localValue 19
401 -- performHandover         map-ac handoverControl (11) version1 (1)   localValue 28
402 -- performSubsequentHandover map-ac handoverControl (11) version1 (1)   localValue 30
403 -- noteInternalHandover    map-ac handoverControl (11) version1 (1)   localValue 35
404 -- noteSubscriberPresent   map-ac mwdMngt (24) version1 (1)     localValue 48
405 -- alertServiceCentreWithoutResult map-ac shortMsgAlert (23) version1 (1)  localValue 49
406 -- traceSubscriberActivity map-ac handoverControl (11) version1 (1)   localValue 52
407 -- beginSubscriberActivity map-ac networkFunctionalSs (18) version1 (1)  localValue 54
408
409 -- The following error codes are reserved for errors
410 -- existing in previous versions of the protocol
411
412 -- Error Name              AC used           Error Code
413 --
414 -- unknownBaseStation      map-ac handoverControl (11) version1 (1)   localValue 2
415 -- invalidTargetBaseStation map-ac handoverControl (11) version1 (1)   localValue 23
416 -- noRadioResourceAvailable map-ac handoverControl (11) version1 (1)   localValue 24
417
418
419 END

```

17.6 MAP operation and error types

17.6.1 Mobile Service Operations

```

1 MAP-MobileServiceOperations {
2   ccitt identified-organization (4) etsi (0) mobileDomain (0)
3   gsm-Network (1) modules (3) map-MobileServiceOperations (5)
4   version5 (5)}
5
6 DEFINITIONS
7
8 ::==
9
10 BEGIN
11
12 EXPORTS
13

```

```

14    -- location registration operations
15    UpdateLocation,
16    CancelLocation,
17    PurgeMS,
18    SendIdentification,
19
20    -- gprs location registration operations
21    UpdateGprsLocation,
22
23    -- subscriber information enquiry operations
24    ProvideSubscriberInfo,
25
26    -- any time information enquiry operations
27    AnyTimeInterrogation,
28
29    -- handover operations
30    PrepareHandover,
31    SendEndSignal,
32    ProcessAccessSignalling,
33    ForwardAccessSignalling,
34    PrepareSubsequentHandover,
35
36    -- authentication management operations
37    SendAuthenticationInfo,
38
39    -- IMEI management operations
40    CheckIMEI,
41
42    -- subscriber management operations
43    InsertSubscriberData,
44    DeleteSubscriberData,
45
46    -- fault recovery operations
47    Reset,
48    ForwardCheckSS-Indication,
49    RestoreData,
50
51    -- gprs location information retrieval operations
52    SendRoutingInfoForGprs,
53
54    -- failure reporting operations
55    FailureReport,
56
57    -- gprs notification operations
58    NoteMsPresentForGprs
59
60
61 ;
62 ;
63
64 IMPORTS
65   OPERATION
66 FROM TCAPMessages {
67   ccitt recommendation q 773 modules (2) messages (1) version2 (2)}
68
69   SystemFailure,
70   DataMissing,
71   UnexpectedDataValue,
72   UnknownSubscriber,
73   UnknownMSC,
74   UnidentifiedSubscriber,
75   UnknownEquipment,
76   RoamingNotAllowed,
77   ATI-NotAllowed,
78   NoHandoverNumberAvailable,
79   SubsequentHandoverFailure,
80   AbsentSubscriber
81
82 FROM MAP-Errors {
83   ccitt identified-organization (4) etsi (0) mobileDomain (0)
84   gsm-Network (1) modules (3) map-Errors (10) version5 (5)}
85
86   UpdateLocationArg,
87   UpdateLocationRes,
88   CancelLocationArg,
89   CancelLocationRes,
90   PurgeMS-Arg,
91   PurgeMS-Res,
92   SendIdentificationRes,

```

```

93     UpdateGprsLocationArg,
94     UpdateGprsLocationRes,
95     PrepareHO-Arg,
96     PrepareHO-Res,
97     PrepareSubsequentHO-Arg,
98     SendAuthenticationInfoArg,
99     SendAuthenticationInfoRes,
100    EquipmentStatus,
101    InsertSubscriberDataArg,
102    InsertSubscriberDataRes,
103    DeleteSubscriberDataArg,
104    DeleteSubscriberDataRes,
105    ResetArg,
106    RestoreDataArg,
107    RestoreDataRes,
108    ProvideSubscriberInfoArg,
109    ProvideSubscriberInfoRes,
110    AnyTimeInterrogationArg,
111    AnyTimeInterrogationRes,
112    SendRoutingInfoForGprsArg,
113    SendRoutingInfoForGprsRes,
114    FailureReportArg,
115    FailureReportRes,
116    NoteMsPresentForGprsArg,
117    NoteMsPresentForGprsRes
118
119 FROM MAP-MS-DataTypes {
120   ccitt identified-organization (4) etsi (0) mobileDomain (0)
121   gsm-Network (1) modules (3) map-MS-DataTypes (11) version5 (5)}
122
123   ExternalSignalInfo,
124   TMSI,
125   IMEI
126 FROM MAP-CommonDataTypes {
127   ccitt identified-organization (4) etsi (0) mobileDomain (0)
128   gsm-Network (1) modules (3) map-CommonDataTypes (18) version5 (5)}
129 ;
130
131
132 -- location registration operations
133
134 UpdateLocation ::= OPERATION                                --Timer m
135   ARGUMENT
136     updateLocationArg          UpdateLocationArg
137   RESULT
138     updateLocationRes         UpdateLocationRes
139   ERRORS {
140     SystemFailure,
141     DataMissing,
142     UnexpectedDataValue,
143     UnknownSubscriber,
144     RoamingNotAllowed}
145
146 CancelLocation ::= OPERATION                                --Timer m
147   ARGUMENT
148     cancelLocationArg        CancelLocationArg
149   RESULT
150     cancelLocationRes       CancelLocationRes
151     -- optional
152   ERRORS {
153     DataMissing,
154     UnexpectedDataValue}
155
156 PurgeMS ::= OPERATION                                     --Timer m
157   ARGUMENT
158     purgeMS-Arg              PurgeMS-Arg
159   RESULT
160     purgeMS-Res              PurgeMS-Res
161     -- optional
162   ERRORS{
163     DataMissing,
164     UnexpectedDataValue,
165     UnknownSubscriber}
166

```

```

167 SendIdentification ::= OPERATION --Timer s
168   ARGUMENT
169     tmsi
170   RESULT
171     sendIdentificationRes
172   ERRORS {
173     DataMissing,
174     UnidentifiedSubscriber}
175
176 -- gprs location registration operations
177
178 UpdateGprsLocation ::= OPERATION --Timer m
179   ARGUMENT
180     updateGprsLocationArg
181   RESULT
182     updateGprsLocationRes
183   ERRORS {
184     SystemFailure,
185     UnexpectedDataValue,
186     UnknownSubscriber,
187     RoamingNotAllowed}
188
189 -- subscriber information enquiry operations
190
191 ProvideSubscriberInfo ::= OPERATION --Timer m
192   ARGUMENT
193     provideSubscriberInfoArg
194   RESULT
195     provideSubscriberInfoRes
196   ERRORS {
197     DataMissing,
198     UnexpectedDataValue}
199
200 -- any time information enquiry operations
201
202 AnyTimeInterrogation ::= OPERATION --Timer m
203   ARGUMENT
204     anyTimeInterrogationArg
205   RESULT
206     anyTimeInterrogationRes
207   ERRORS {
208     SystemFailure,
209     ATI-NotAllowed,
210     DataMissing,
211     UnexpectedDataValue,
212     UnknownSubscriber}
213
214 -- handover operations
215
216 PrepareHandover ::= OPERATION --Timer m
217   ARGUMENT
218     prepareHO-Arg
219   RESULT
220     prepareHO-Res
221   ERRORS {
222     SystemFailure,
223     DataMissing,
224     UnexpectedDataValue,
225     NoHandoverNumberAvailable}
226
227 SendEndSignal ::= OPERATION --Timer 1
228   ARGUMENT
229     bss-APDU
230   RESULT
ExternalSignalInfo
231
232 ProcessAccessSignalling ::= OPERATION --Timer s
233   ARGUMENT
234     bss-APDU
ExternalSignalInfo
235
236 ForwardAccessSignalling ::= OPERATION --Timer s
237   ARGUMENT
238     bss-APDU
ExternalSignalInfo
239

```

```

240 PrepareSubsequentHandover ::= OPERATION --Timer m
241   ARGUMENT
242     prepareSubsequentHO-Arg      PrepareSubsequentHO-Arg
243   RESULT
244     bss-APDU                   ExternalSignalInfo
245   ERRORS {
246     UnexpectedDataValue,
247     DataMissing,
248     UnknownMSC,
249     SubsequentHandoverFailure}
250
251 -- authentication management operations
252
253 SendAuthenticationInfo ::= OPERATION --Timer m
254   ARGUMENT
255     sendAuthenticationInfoArg    SendAuthenticationInfoArg
256   RESULT
257     sendAuthenticationInfoRes   SendAuthenticationInfoRes
258     -- optional
259   ERRORS {
260     SystemFailure,
261     DataMissing,
262     UnexpectedDataValue,
263     UnknownSubscriber}
264
265 -- IMEI management operations
266
267 CheckIMEI ::= OPERATION --Timer m
268   ARGUMENT
269     imei                         IMEI
270   RESULT
271     equipmentStatus              EquipmentStatus
272   ERRORS {
273     SystemFailure,
274     DataMissing,
275     UnknownEquipment}
276
277 -- subscriber management operations
278
279 InsertSubscriberData ::= OPERATION --Timer m
280   ARGUMENT
281     insertSubscriberDataArg     InsertSubscriberDataArg
282   RESULT
283     insertSubscriberDataRes   InsertSubscriberDataRes
284     -- optional
285   ERRORS {
286     DataMissing,
287     UnexpectedDataValue,
288     UnidentifiedSubscriber}
289
290 DeleteSubscriberData ::= OPERATION --Timer m
291   ARGUMENT
292     deleteSubscriberDataArg    DeleteSubscriberDataArg
293   RESULT
294     deleteSubscriberDataRes   DeleteSubscriberDataRes
295     -- optional
296   ERRORS {
297     DataMissing,
298     UnexpectedDataValue,
299     UnidentifiedSubscriber}
300
301 -- fault recovery operations
302
303 Reset ::= OPERATION --Timer m
304   ARGUMENT
305     resetArg                    ResetArg
306
307 ForwardCheckSS-Indication ::= OPERATION --Timer s
308

```

```

309 RestoreData ::= OPERATION --Timer m
310   ARGUMENT
311     restoreDataArg           RestoreDataArg
312   RESULT
313     restoreDataRes          RestoreDataRes
314   ERRORS {
315     SystemFailure,
316     DataMissing,
317     UnexpectedDataValue,
318     UnknownSubscriber}
319
320 -- gprs location information retrieval operations
321
322 SendRoutingInfoForGprs ::= OPERATION --Timer m
323   ARGUMENT
324     sendRoutingInfoForGprsArg  SendRoutingInfoForGprsArg
325   RESULT
326     sendRoutingInfoForGprsRes SendRoutingInfoForGprsRes
327   ERRORS {
328     AbsentSubscriber,
329     SystemFailure,
330     DataMissing,
331     UnexpectedDataValue,
332     UnknownSubscriber}
333
334 -- failure reporting operations
335
336 FailureReport ::= OPERATION --Timer m
337   ARGUMENT
338     failureReportArg         FailureReportArg
339   RESULT
340     failureReportRes        FailureReportRes
341     -- optional
342   ERRORS {
343     SystemFailure,
344     DataMissing,
345     UnexpectedDataValue,
346     UnknownSubscriber}
347
348 -- gprs notification operations
349
350 NoteMsPresentForGprs ::= OPERATION --Timer m
351   ARGUMENT
352     noteMsPresentForGprsArg NoteMsPresentForGprsArg
353   RESULT
354     noteMsPresentForGprsRes NoteMsPresentForGprsRes
355     -- optional
356   ERRORS {
357     SystemFailure,
358     DataMissing,
359     UnexpectedDataValue,
360     UnknownSubscriber}
361
362
363 END

```

17.6.2 Operation and Maintenance Operations

```

1 MAP-OperationAndMaintenanceOperations {
2   ccitt identified-organization (4) etsi (0) mobileDomain (0)
3   gsm-Network (1) modules (3) map-OperationAndMaintenanceOperations (6)
4   version5 (5)}
5
6 DEFINITIONS
7
8 ::= BEGIN
9
10 EXPORTS
11   ActivateTraceMode,
12   DeactivateTraceMode,
13   SendIMSI
14 ;
15
16 IMPORTS
17   OPERATION
18   FROM TCAPMessages {
19

```

```

21     ccitt recommendation q 773 modules (2) messages (1) version2 (2)}
22
23     SystemFailure,
24     DataMissing,
25     UnexpectedDataValue,
26     FacilityNotSupported,
27     UnknownSubscriber,
28     UnidentifiedSubscriber,
29     TracingBufferFull
30   FROM MAP-Errors {
31     ccitt identified-organization (4) etsi (0) mobileDomain (0)
32     gsm-Network (1) modules (3) map-Errors (10) version5 (5)}
33
34     ActivateTraceModeArg,
35     ActivateTraceModeRes,
36     DeactivateTraceModeArg,
37     DeactivateTraceModeRes
38   FROM MAP-OM-DataTypes {
39     ccitt identified-organization (4) etsi (0) mobileDomain (0)
40     gsm-Network (1) modules (3) map-OM-DataTypes (12) version5 (5)}
41
42     ISDN-AddressString,
43     IMSI
44   FROM MAP-CommonDataTypes {
45     ccitt identified-organization (4) etsi (0) mobileDomain (0)
46     gsm-Network (1) modules (3) map-CommonDataTypes (18) version5 (5)}
47 ;
48
49
50 ActivateTraceMode ::= OPERATION                                     --Timer m
51   ARGUMENT
52     activateTraceModeArg          ActivateTraceModeArg
53   RESULT
54     activateTraceModeRes         ActivateTraceModeRes
55     -- optional
56   ERRORS {
57     SystemFailure,
58     DataMissing,
59     UnexpectedDataValue,
60     FacilityNotSupported,
61     UnidentifiedSubscriber,
62     TracingBufferFull}
63
64 DeactivateTraceMode ::= OPERATION                                     --Timer m
65   ARGUMENT
66     deactivateTraceModeArg        DeactivateTraceModeArg
67   RESULT
68     deactivateTraceModeRes       DeactivateTraceModeRes
69     -- optional
70   ERRORS {
71     SystemFailure,
72     DataMissing,
73     UnexpectedDataValue,
74     FacilityNotSupported,
75     UnidentifiedSubscriber}
76
77 SendIMSI ::= OPERATION                                         --Timer m
78   ARGUMENT
79     msisdn                      ISDN-AddressString
80   RESULT
81     imsi                        IMSI
82   ERRORS {
83     DataMissing,
84     UnexpectedDataValue,
85     UnknownSubscriber}
86
87 END

```

17.6.3 Call Handling Operations

```

1 MAP-CallHandlingOperations {
2   ccitt identified-organization (4) etsi (0) mobileDomain (0)
3   gsm-Network (1) modules (3) map-CallHandlingOperations (7)
4   version5 (5)}
5
6 DEFINITIONS
7
8 ::= 

```

```

9
10 BEGIN
11
12 EXPORTS
13   SendRoutingInfo,
14   ProvideRoamingNumber,
15   ResumeCallHandling,
16   ProvideSIWFSNNumber,
17   SIWFSSignallingModify,
18   SetReportingState,
19   StatusReport,
20   RemoteUserFree
21 ;
22
23 IMPORTS
24   OPERATION
25 FROM TCAPMessages {
26   ccitt recommendation q 773 modules (2) messages (1) version2 (2)}
27
28   SystemFailure,
29   DataMissing,
30   UnexpectedDataValue,
31   FacilityNotSupported,
32   OR-NotAllowed,
33   UnknownSubscriber,
34   NumberChanged,
35   BearerServiceNotProvisioned,
36   TeleserviceNotProvisioned,
37   NoRoamingNumberAvailable,
38   AbsentSubscriber,
39   BusySubscriber,
40   NoSubscriberReply,
41   CallBarred,
42   ForwardingViolation,
43   ForwardingFailed,
44   CUG-Reject,
45   ResourceLimitation,
46   IncompatibleTerminal,
47   UnidentifiedSubscriber
48
49 FROM MAP-Errors {
50   ccitt identified-organization (4) etsi (0) mobileDomain (0)
51   gsm-Network (1) modules (3) map-Errors (10) version5 (5)}
52   SendRoutingInfoArg,
53   SendRoutingInfoRes,
54   ProvideRoamingNumberArg,
55   ProvideRoamingNumberRes,
56   ResumeCallHandlingArg,
57   ResumeCallHandlingRes,
58   ProvideSIWFSNNumberArg,
59   ProvideSIWFSNNumberRes,
60   SIWFSSignallingModifyArg,
61   SIWFSSignallingModifyRes,
62   SetReportingStateArg,
63   SetReportingStateRes,
64   StatusReportArg,
65   StatusReportRes,
66   RemoteUserFreeArg,
67   RemoteUserFreeRes
68 FROM MAP-CH-DataTypes {
69   ccitt identified-organization (4) etsi (0) mobileDomain (0)
70   gsm-Network (1) modules (3) map-CH-DataTypes (13) version5 (5)}
71
72 ;
73

```

```

74 SendRoutingInfo ::= OPERATION --Timer m
75   ARGUMENT
76     sendRoutingInfoArg      SendRoutingInfoArg
77   RESULT
78     sendRoutingInfoRes      SendRoutingInfoRes
79   ERRORS {
80     SystemFailure,
81     DataMissing,
82     UnexpectedDataValue,
83     FacilityNotSupported,
84     OR-NotAllowed,
85     UnknownSubscriber,
86     NumberChanged,
87     BearerServiceNotProvisioned,
88     TeleserviceNotProvisioned,
89     AbsentSubscriber,
90     BusySubscriber,
91     NoSubscriberReply,
92     CallBarred,
93     CUG-Reject,
94     ForwardingViolation}
95
96 ProvideRoamingNumber ::= OPERATION --Timer m
97   ARGUMENT
98     provideRoamingNumberArg  ProvideRoamingNumberArg
99   RESULT
100    provideRoamingNumberRes  ProvideRoamingNumberRes
101  ERRORS {
102    SystemFailure,
103    DataMissing,
104    UnexpectedDataValue,
105    FacilityNotSupported,
106    OR-NotAllowed,
107    AbsentSubscriber,
108    NoRoamingNumberAvailable}
109
110 ResumeCallHandling ::= OPERATION --Timer m
111   ARGUMENT
112     resumeCallHandlingArg    ResumeCallHandlingArg
113   RESULT
114     resumeCallHandlingRes    ResumeCallHandlingRes
115     -- optional
116   ERRORS {
117     ForwardingFailed,
118     OR-NotAllowed,
119     UnexpectedDataValue,
120     DataMissing }
121
122 ProvideSIWFSNumber ::= OPERATION --Timer m
123   ARGUMENT
124     provideSIWFSNumberArg    ProvideSIWFSNumberArg
125   RESULT
126     provideSIWFSNumberRes    ProvideSIWFSNumberRes
127   ERRORS {
128     ResourceLimitation,
129     DataMissing,
130     UnexpectedDataValue,
131     SystemFailure}
132
133 SIWFSSignallingModify ::= OPERATION --Timer m
134   ARGUMENT
135     SIWFSSignallingModifyArg  SIWFSSignallingModifyArg
136   RESULT
137     SIWFSSignallingModifyRes  SIWFSSignallingModifyRes
138     -- optional
139   ERRORS {
140     ResourceLimitation,
141     DataMissing,
142     UnexpectedDataValue,
143     SystemFailure}
144

```

```

145 SetReportingState ::= OPERATION --Timer m
146   ARGUMENT
147     setReportingStateArg      SetReportingStateArg
148   RESULT
149     setReportingStateRes    SetReportingStateRes
150   -- optional
151   ERRORS {
152     SystemFailure,
153     UnidentifiedSubscriber,
154     UnexpectedDataValue,
155     DataMissing,
156     ResourceLimitation,
157     FacilityNotSupported}
158
159 StatusReport ::= OPERATION --Timer m
160   ARGUMENT
161     statusReportArg        StatusReportArg
162   RESULT
163     statusReportRes       StatusReportRes
164   -- optional
165   ERRORS {
166     UnknownSubscriber,
167     SystemFailure,
168     UnexpectedDataValue,
169     DataMissing}
170
171 RemoteUserFree ::= OPERATION --Timer ml
172   ARGUMENT
173     remoteUserFreeArg      RemoteUserFreeArg
174   RESULT
175     remoteUserFreeRes     RemoteUserFreeRes
176   ERRORS {
177     UnexpectedDataValue,
178     DataMissing,
179     IncompatibleTerminal,
180     AbsentSubscriber,
181     SystemFailure,
182     BusySubscriber}
183
184 END

```

17.6.4 Supplementary service operations

```

1 MAP-SupplementaryServiceOperations {
2   ccitt identified-organization (4) etsi (0) mobileDomain (0)
3   gsm-Network (1) modules (3) map-SupplementaryServiceOperations (8)
4   version5 (5)}
5
6 DEFINITIONS
7
8 ::=-
9
10 BEGIN
11
12 EXPORTS
13   RegisterSS,
14   EraseSS,
15   ActivateSS,
16   DeactivateSS,
17   InterrogateSS,
18   ProcessUnstructuredSS-Request,
19   UnstructuredSS-Request,
20   UnstructuredSS-Notify,
21   RegisterPassword,
22   GetPassword,
23   SS-InvocationNotification,
24   RegisterCC-Entry,
25   EraseCC-Entry
26 ;
27
28 IMPORTS
29   OPERATION
30 FROM TCAPMessages {
31   ccitt recommendation q 773 modules (2) messages (1) version2 (2)}
32
33 SystemFailure,
34 DataMissing,
35 UnexpectedDataValue,

```

```

36    UnknownSubscriber,
37    BearerServiceNotProvisioned,
38    TeleserviceNotProvisioned,
39    CallBarred,
40    IllegalSS-Operation,
41    SS-ErrorStatus,
42    SS-NotAvailable,
43    SS-SubscriptionViolation,
44    SS-Incompatibility,
45    PW-RegistrationFailure,
46    NegativePW-Check,
47    NumberOfPW-AttemptsViolation,
48    UnknownAlphabet,
49    USSD-Busy,
50    AbsentSubscriber,
51    IllegalSubscriber,
52    IllegalEquipment,
53    ShortTermDenial,
54    LongTermDenial,
55    FacilityNotSupported
56 FROM MAP-Errors {
57   ccitt identified-organization (4) etsi (0) mobileDomain (0)
58   gsm-Network (1) modules (3) map-Errors (10) version5 (5)}
59
60 RegisterSS-Arg,
61 SS-Info,
62 SS-ForBS-Code,
63 InterrogateSS-Res,
64 USSD-Arg,
65 USSD-Res,
66 Password,
67 GuidanceInfo,
68 SS-InvocationNotificationArg,
69 SS-InvocationNotificationRes,
70 RegisterCC-EntryArg,
71 RegisterCC-EntryRes,
72 EraseCC-EntryArg,
73 EraseCC-EntryRes
74 FROM MAP-SS-DataTypes {
75   ccitt identified-organization (4) etsi (0) mobileDomain (0)
76   gsm-Network (1) modules (3) map-SS-DataTypes (14) version5 (5)}
77
78 SS-Code
79 FROM MAP-SS-Code {
80   ccitt identified-organization (4) etsi (0) mobileDomain (0)
81   gsm-Network (1) modules (3) map-SS-Code (15) version5 (5)}
82 ;
83
84
85 -- supplementary service handling operations
86
87 RegisterSS ::= OPERATION
88   ARGUMENT
89     registerSS-Arg
90   RESULT
91     ss-Info
92     -- optional
93   ERRORS {
94     SystemFailure,
95     DataMissing,
96     UnexpectedDataValue,
97     BearerServiceNotProvisioned,
98     TeleserviceNotProvisioned,
99     CallBarred,
100    IllegalSS-Operation,
101    SS-ErrorStatus,
102    SS-Incompatibility}
103

```

```

104 EraseSS ::= OPERATION --Timer m
105   ARGUMENT
106     ss-ForBS           SS-ForBS-Code
107   RESULT
108     ss-Info            SS-Info
109     -- optional
110   ERRORS {
111     SystemFailure,
112     DataMissing,
113     UnexpectedDataValue,
114     BearerServiceNotProvisioned,
115     TeleserviceNotProvisioned,
116     CallBarred,
117     IllegalSS-Operation,
118     SS-ErrorStatus
119   }
120
121 ActivateSS ::= OPERATION --Timer m
122   ARGUMENT
123     ss-ForBS           SS-ForBS-Code
124   RESULT
125     ss-Info            SS-Info
126     -- optional
127   ERRORS {
128     SystemFailure,
129     DataMissing,
130     UnexpectedDataValue,
131     BearerServiceNotProvisioned,
132     TeleserviceNotProvisioned,
133     CallBarred,
134     IllegalSS-Operation,
135     SS-ErrorStatus,
136     SS-SubscriptionViolation,
137     SS-Incompatibility,
138     NegativePW-Check,
139     NumberOfPW-AttemptsViolation}
140
141 DeactivateSS ::= OPERATION --Timer m
142   ARGUMENT
143     ss-ForBS           SS-ForBS-Code
144   RESULT
145     ss-Info            SS-Info
146     -- optional
147   ERRORS {
148     SystemFailure,
149     DataMissing,
150     UnexpectedDataValue,
151     BearerServiceNotProvisioned,
152     TeleserviceNotProvisioned,
153     CallBarred,
154     IllegalSS-Operation,
155     SS-ErrorStatus,
156     SS-SubscriptionViolation,
157     NegativePW-Check,
158     NumberOfPW-AttemptsViolation}
159
160 InterrogateSS ::= OPERATION --Timer m
161   ARGUMENT
162     ss-ForBS           SS-ForBS-Code
163   RESULT
164     interrogateSS-Res InterrogateSS-Res
165   ERRORS {
166     SystemFailure,
167     DataMissing,
168     UnexpectedDataValue,
169     BearerServiceNotProvisioned,
170     TeleserviceNotProvisioned,
171     CallBarred,
172     IllegalSS-Operation,
173     SS-NotAvailable}
174

```

```

175 ProcessUnstructuredSS-Request ::= OPERATION --Timer 10 minutes
176   ARGUMENT
177     ussd-Arg          USSD-Arg
178   RESULT
179     ussd-Res          USSD-Res
180   ERRORS {
181     SystemFailure,
182     DataMissing,
183     UnexpectedDataValue,
184     UnknownAlphabet,
185     CallBarred}
186
187 UnstructuredSS-Request ::= OPERATION --Timer ml
188   ARGUMENT
189     ussd-Arg          USSD-Arg
190   RESULT
191     ussd-Res          USSD-Res
192     -- optional
193   ERRORS {
194     SystemFailure,
195     DataMissing,
196     UnexpectedDataValue,
197     AbsentSubscriber,
198     IllegalSubscriber,
199     IllegalEquipment,
200     UnknownAlphabet,
201     USSD-Busy}
202
203 UnstructuredSS-Notify ::= OPERATION --Timer ml
204   ARGUMENT
205     ussd-Arg          USSD-Arg
206   RESULT
207   ERRORS {
208     SystemFailure,
209     DataMissing,
210     UnexpectedDataValue,
211     AbsentSubscriber,
212     IllegalSubscriber,
213     IllegalEquipment,
214     UnknownAlphabet,
215     USSD-Busy}
216
217 RegisterPassword ::= OPERATION --Timer ml
218   ARGUMENT
219     ss-Code            SS-Code
220   RESULT
221     newPassword       Password
222   ERRORS {
223     SystemFailure,
224     DataMissing,
225     UnexpectedDataValue,
226     CallBarred,
227     SS-SubscriptionViolation,
228     PW-RegistrationFailure,
229     NegativePW-Check,
230     NumberOfPW-AttemptsViolation}
231   LINKED {
232     GetPassword}
233
234 GetPassword ::= OPERATION --Timer m
235   ARGUMENT
236     guidanceInfo      GuidanceInfo
237   RESULT
238     currentPassword   Password
239
240 SS-InvocationNotification ::= OPERATION --Timer m
241   ARGUMENT
242     ss-InvocationNotificationArg  SS-InvocationNotificationArg
243   RESULT
244     ss-InvocationNotificationRes SS-InvocationNotificationRes
245     -- optional
246   ERRORS {
247     DataMissing,
248     UnexpectedDataValue,
249     UnknownSubscriber}
250

```

```

251 RegisterCC-Entry ::= OPERATION --Timer m
252   ARGUMENT
253     registerCC-EntryArg      RegisterCC-EntryArg
254   RESULT
255     registerCC-EntryRes     RegisterCC-EntryRes
256   ERRORS {
257     SystemFailure,
258     DataMissing,
259     UnexpectedDataValue,
260     CallBarred,
261     IllegalSS-Operation,
262     SS-ErrorStatus,
263     SS-Incompatibility,
264     ShortTermDenial,
265     LongTermDenial,
266     FacilityNotSupported}
267
268 EraseCC-Entry ::= OPERATION --Timer m
269   ARGUMENT
270     eraseCC-EntryArg        EraseCC-EntryArg
271   RESULT
272     eraseCC-EntryRes       EraseCC-EntryRes
273   ERRORS {
274     SystemFailure,
275     DataMissing,
276     UnexpectedDataValue,
277     CallBarred,
278     IllegalSS-Operation,
279     SS-ErrorStatus}
280
281 END

```

17.6.5 Short message service operations

```

1 MAP-ShortMessageServiceOperations {
2   ccitt identified-organization (4) etsi (0) mobileDomain (0)
3   gsm-Network (1) modules (3) map-ShortMessageServiceOperations (9)
4   version5 (5)}
5
6 DEFINITIONS
7
8 ::= :
9
10 BEGIN
11
12 EXPORTS
13   SendRoutingInfoForSM,
14   MO-ForwardSM,
15   MT-ForwardSM,
16   ReportSM-DeliveryStatus,
17   AlertServiceCentre,
18   InformServiceCentre,
19   ReadyForSM
20 ;
21
22 IMPORTS
23   OPERATION
24 FROM TCAPMessages {
25   ccitt recommendation q 773 modules (2) messages (1) version2 (2)}
26
27   SystemFailure,
28   DataMissing,
29   UnexpectedDataValue,
30   FacilityNotSupported,
31   UnknownSubscriber,
32   UnidentifiedSubscriber,
33   IllegalSubscriber,
34   IllegalEquipment,
35   TeleserviceNotProvisioned,
36   AbsentSubscriber,
37   CallBarred,
38   SubscriberBusyForMT-SMS,
39   SM-DeliveryFailure,
40   MessageWaitingListFull,
41   AbsentSubscriberSM
42 FROM MAP-Errors {
43   ccitt identified-organization (4) etsi (0) mobileDomain (0)
44   gsm-Network (1) modules (3) map-Errors (10) version5 (5)}

```

```

45
46     RoutingInfoForSM-Arg,
47     RoutingInfoForSM-Res,
48     MO-ForwardSM-Arg,
49     MO-ForwardSM-Res,
50     MT-ForwardSM-Arg,
51     MT-ForwardSM-Res,
52     ReportSM-DeliveryStatusArg,
53     ReportSM-DeliveryStatusRes,
54     AlertServiceCentreArg,
55     InformServiceCentreArg,
56     ReadyForSM-Arg,
57     ReadyForSM-Res
58 FROM MAP-SM-DataTypes {
59     ccitt identified-organization (4) etsi (0) mobileDomain (0)
60     gsm-Network (1) modules (3) map-SM-DataTypes (16) version5 (5)
61
62
63
64 ;
65
66
67 SendRoutingInfoForSM ::= OPERATION --Timer m
68     ARGUMENT
69         routingInfoForSM-Arg          RoutingInfoForSM-Arg
70     RESULT
71         routingInfoForSM-Res        RoutingInfoForSM-Res
72     ERRORS {
73         SystemFailure,
74         DataMissing,
75         UnexpectedDataValue,
76         FacilityNotSupported,
77         UnknownSubscriber,
78         TeleserviceNotProvisioned,
79         CallBarred,
80         AbsentSubscriberSM}
81
82 MO-ForwardSM ::= OPERATION --Timer ml
83     ARGUMENT
84         mo-forwardSM-Arg            MO-ForwardSM-Arg
85     RESULT
86         mo-forwardSM-Res           MO-ForwardSM-Res
87         -- optional
88     ERRORS {
89         SystemFailure,
90         UnexpectedDataValue,
91         FacilityNotSupported,
92         SM-DeliveryFailure}
93
94 MT-ForwardSM ::= OPERATION --Timer ml
95     ARGUMENT
96         mt-forwardSM-Arg           MT-ForwardSM-Arg
97     RESULT
98         mt-forwardSM-Res           MT-ForwardSM-Res
99         -- optional
100    ERRORS {
101        SystemFailure,
102        DataMissing,
103        UnexpectedDataValue,
104        FacilityNotSupported,
105        UnidentifiedSubscriber,
106        IllegalSubscriber,
107        IllegalEquipment,
108        SubscriberBusyForMT-SMS,
109        SM-DeliveryFailure,
110        AbsentSubscriberSM}
111

```

```

112 ReportSM-DeliveryStatus ::= OPERATION --Timer s
113   ARGUMENT
114     reportSM-DeliveryStatusArg      ReportSM-DeliveryStatusArg
115   RESULT
116     reportSM-DeliveryStatusRes    ReportSM-DeliveryStatusRes
117     -- optional
118   ERRORS {
119     DataMissing,
120     UnexpectedDataValue,
121     UnknownSubscriber,
122     MessageWaitingListFull}
123
124 AlertServiceCentre ::= OPERATION --Timer s
125   ARGUMENT
126     alertServiceCentreArg        AlertServiceCentreArg
127   RESULT
128   ERRORS {
129     SystemFailure,
130     DataMissing,
131     UnexpectedDataValue}
132
133 InformServiceCentre ::= OPERATION --Timer s
134   ARGUMENT
135     informServiceCentreArg       InformServiceCentreArg
136
137 ReadyForSM ::= OPERATION --Timer m
138   ARGUMENT
139     readyForSM-Arg             ReadyForSM-Arg
140   RESULT
141     readyForSM-Res            ReadyForSM-Res
142     -- optional
143   ERRORS {
144     DataMissing,
145     UnexpectedDataValue,
146     FacilityNotSupported,
147     UnknownSubscriber}
148
149 END

```

17.6.6 Errors

```

1 MAP-Errors {
2   ccitt identified-organization (4) etsi (0) mobileDomain (0)
3   gsm-Network (1) modules (3) map-Errors (10) version5 (5)}
4
5 DEFINITIONS
6
7 ::= 
8
9 BEGIN
10
11 EXPORTS
12
13   -- generic errors
14   SystemFailure,
15   DataMissing,
16   UnexpectedDataValue,
17   FacilityNotSupported,
18   IncompatibleTerminal,
19   ResourceLimitation,
20
21   -- identification and numbering errors
22   UnknownSubscriber,
23   NumberChanged,
24   UnknownMSC,
25   UnidentifiedSubscriber,
26   UnknownEquipment,
27
28   -- subscription errors
29   RoamingNotAllowed,
30   IllegalSubscriber,
31   IllegalEquipment,
32   BearerServiceNotProvisioned,
33   TeleserviceNotProvisioned,
34
35   -- handover errors
36   NoHandoverNumberAvailable,
37   SubsequentHandoverFailure,

```

```

38
39    -- operation and maintenance errors
40    TracingBufferFull,
41
42    -- call handling errors
43    OR-NotAllowed,
44    NoRoamingNumberAvailable,
45    BusySubscriber,
46    NoSubscriberReply,
47    AbsentSubscriber,
48    CallBarred,
49    ForwardingViolation,
50    ForwardingFailed,
51    CUG-Reject,
52
53    -- any time interrogation errors
54    ATI-NotAllowed,
55
56    -- supplementary service errors
57    IllegalSS-Operation,
58    SS-ErrorStatus,
59    SS-NotAvailable,
60    SS-SubscriptionViolation,
61    SS-Incompatibility,
62    UnknownAlphabet,
63    USSD-Busy,
64    PW-RegistrationFailure,
65    NegativePW-Check,
66    NumberOfPW-AttemptsViolation,
67    ShortTermDenial,
68    LongTermDenial,
69
70    -- short message service errors
71    SubscriberBusyForMT-SMS,
72    SM-DeliveryFailure,
73    MessageWaitingListFull,
74    AbsentSubscriberSM,
75
76    -- Group Call errors
77    NoGroupCallNumberAvailable,
78
79    -- location service errors
80    UnauthorizedRequestingNetwork,
81    UnauthorizedLCSClient,
82    PositionMethodFailure,
83    UnknownOrUnreachableLCSClient
84
85 ;
86
87 IMPORTS
88   ERROR
89 FROM TCAPMessages {
90   ccitt recommendation q 773 modules (2) messages (1) version2 (2)}
91
92   SS-Status
93 FROM MAP-SS-DataTypes {
94   ccitt identified-organization (4) etsi (0) mobileDomain (0)
95   gsm-Network (1) modules (3) map-SS-DataTypes (14) version5 (5)}
96
97   SS-IncompatibilityCause,
98   PW-RegistrationFailureCause,
99   SM-DeliveryFailureCause,
100  SystemFailureParam,
101  DataMissingParam,
102  UnexpectedDataParam,
103  FacilityNotSupParam,
104  UnknownSubscriberParam,
105  NumberChangedParam,
106  UnidentifiedSubParam,
107  RoamingNotAllowedParam,
108  IllegalSubscriberParam,
109  IllegalEquipmentParam,
110  BearerServNotProvParam,
111  TeleservNotProvParam,
112  TracingBufferFullParam,
113  NoRoamingNbParam,
114  OR-NotAllowedParam,
115  AbsentSubscriberParam,
116  BusySubscriberParam,

```

```

117    NoSubscriberReplyParam,
118    CallBarredParam,
119    ForwardingViolationParam,
120    ForwardingFailedParam,
121    CUG-RejectParam,
122    ATI-NotAllowedParam,
123    SubBusyForMT-SMS-Param,
124    MessageWaitListFullParam,
125    AbsentSubscriberSM-Param,
126    ResourceLimitationParam,
127    NoGroupCallNbParam,
128    IncompatibleTerminalParam,
129    ShortTermDenialParam,
130    LongTermDenialParam,
131    UnauthorizedRequestingNetwork-Param,
132    UnauthorizedLCSClient-Param,
133    PositionMethodFailure-Param,
134    UnknownOrUnreachableLCSClient-Param
135
136
137 FROM MAP-ER-DataTypes {
138     ccitt identified-organization (4) etsi (0) mobileDomain (0)
139     gsm-Network (1) modules (3) map-ER-DataTypes (17) version5 (5)
140 ;
141
142 -- generic errors
143
144
145 SystemFailure ::= ERROR
146     PARAMETER
147         systemFailureParam          SystemFailureParam
148         -- optional
149
150
151 DataMissing ::= ERROR
152     PARAMETER
153         dataMissingParam           DataMissingParam
154         -- optional
155         -- dataMissingParam must not be used in version <3
156
157
158 UnexpectedDataValue ::= ERROR
159     PARAMETER
160         unexpectedDataParam       UnexpectedDataParam
161         -- optional
162         -- unexpectedDataParam must not be used in version <3
163
164
165 FacilityNotSupported ::= ERROR
166     PARAMETER
167         facilityNotSupParam      FacilityNotSupParam
168         -- optional
169         -- facilityNotSupParam must not be used in version <3
170
171
172 IncompatibleTerminal ::= ERROR
173     PARAMETER
174         incompatibleTerminalParam IncompatibleTerminalParam
175         -- optional
176
177
178 -- identification and numbering errors
179
180
181 UnknownSubscriber ::= ERROR
182     PARAMETER
183         unknownSubscriberParam   UnknownSubscriberParam
184         -- optional
185         -- unknownSubscriberParam must not be used in version <3
186
187
188 NumberChanged ::= ERROR
189     PARAMETER
190         numberChangedParam       NumberChangedParam
191         -- optional
192

```

```

193 UnidentifiedSubscriber ::= ERROR
194   PARAMETER
195     unidentifiedSubParam          UnidentifiedSubParam
196     -- optional
197     -- unidentifiedSubParam must not be used in version <3
198
199 UnknownEquipment ::= ERROR
200
201
202   -- subscription errors
203
204 RoamingNotAllowed ::= ERROR
205   PARAMETER
206     roamingNotAllowedParam       RoamingNotAllowedParam
207
208 IllegalSubscriber ::= ERROR
209   PARAMETER
210     illegalSubscriberParam      IllegalSubscriberParam
211     -- optional
212     -- illegalSubscriberParam must not be used in version <3
213
214 IllegalEquipment ::= ERROR
215   PARAMETER
216     illegalEquipmentParam      IllegalEquipmentParam
217     -- optional
218     -- illegalEquipmentParam must not be used in version <3
219
220 BearerServiceNotProvisioned ::= ERROR
221   PARAMETER
222     bearerServNotProvParam     BearerServNotProvParam
223     -- optional
224     -- bearerServNotProvParam must not be used in version <3
225
226 TeleserviceNotProvisioned ::= ERROR
227   PARAMETER
228     teleservNotProvParam      TeleservNotProvParam
229     -- optional
230     -- teleservNotProvParam must not be used in version <3
231
232
233   -- handover errors
234
235 NoHandoverNumberAvailable ::= ERROR
236
237 SubsequentHandoverFailure ::= ERROR
238
239
240   -- operation and maintenance errors
241
242 TracingBufferFull ::= ERROR
243   PARAMETER
244     tracingBufferFullParam    TracingBufferFullParam
245     -- optional
246
247
248   -- call handling errors
249
250 NoRoamingNumberAvailable ::= ERROR
251   PARAMETER
252     noRoamingNbParam         NoRoamingNbParam
253     -- optional
254
255 AbsentSubscriber ::= ERROR
256   PARAMETER
257     absentSubscriberParam    AbsentSubscriberParam
258     -- optional
259
260     -- absentSubscriberParam must not be used in version <3
261
262 BusySubscriber ::= ERROR
263   PARAMETER
264     busySubscriberParam      BusySubscriberParam
265     -- optional
266

```

```

267 NoSubscriberReply ::= ERROR
268   PARAMETER
269     noSubscriberReplyParam           NoSubscriberReplyParam
270     -- optional
271
272 CallBarred ::= ERROR
273   PARAMETER
274     callBarredParam                CallBarredParam
275     -- optional
276
277 ForwardingViolation ::= ERROR
278   PARAMETER
279     forwardingViolationParam      ForwardingViolationParam
280     -- optional
281
282 ForwardingFailed ::= ERROR
283   PARAMETER
284     forwardingFailedParam        ForwardingFailedParam
285     -- optional
286
287 CUG-Reject ::= ERROR
288   PARAMETER
289     cug-RejectParam              CUG-RejectParam
290     -- optional
291
292 OR-NotAllowed ::= ERROR
293   PARAMETER
294     or-NotAllowedParam          OR-NotAllowedParam
295     -- optional
296
297
298   -- any time interrogation errors
299 ATI-NotAllowed ::= ERROR
300   PARAMETER
301     ati-NotAllowedParam         ATI-NotAllowedParam
302     -- optional
303
304
305   -- supplementary service errors
306
307 IllegalSS-Operation ::= ERROR
308
309 SS-ErrorStatus ::= ERROR
310   PARAMETER
311     ss>Status                   SS-Status
312     -- optional
313
314 SS-NotAvailable ::= ERROR
315
316 SS-SubscriptionViolation ::= ERROR
317
318 SS-Incompatibility ::= ERROR
319   PARAMETER
320     ss>IncompatibilityCause    SS-IncompatibilityCause
321     -- optional
322
323 UnknownAlphabet ::= ERROR
324
325 USSD-Busy ::= ERROR
326
327 PW-RegistrationFailure ::= ERROR
328   PARAMETER
329     pw-RegistrationFailureCause PW-RegistrationFailureCause
330
331 NegativePW-Check ::= ERROR
332
333 NumberOfPW-AttemptsViolation ::= ERROR
334
335 ShortTermDenial ::= ERROR
336   PARAMETER
337     shortTermDenialParam       ShortTermDenialParam
338     -- optional
339

```

```

340 LongTermDenial ::= ERROR
341   PARAMETER
342     longTermDenialParam           LongTermDenialParam
343     -- optional
344
345
346   -- short message service errors
347
348 SubscriberBusyForMT-SMS ::= ERROR
349   PARAMETER
350     subBusyForMT-SMS-Param       SubBusyForMT-SMS-Param
351     -- optional
352
353 SM-DeliveryFailure ::= ERROR
354   PARAMETER
355     sm-DeliveryFailureCause    SM-DeliveryFailureCause
356
357 MessageWaitingListFull ::= ERROR
358   PARAMETER
359     messageWaitListFullParam   MessageWaitListFullParam
360     -- optional
361
362 AbsentSubscriberSM ::= ERROR
363   PARAMETER
364     absentSubscriberSM-Param  AbsentSubscriberSM-Param
365     -- optional
366
367   -- Group Call errors
368
369 NoGroupCallNumberAvailable ::= ERROR
370   PARAMETER
371     noGroupCallNbParam        NoGroupCallNbParam
372     -- optional
373
374   -- location service errors
375
376 UnauthorizedRequestingNetwork ::= ERROR
377   PARAMETER
378     unauthorizedRequestingNetwork-Param UnauthorizedRequestingNetwork-Param
379     -- optional
380
381 UnauthorizedLCSClient ::= ERROR
382   PARAMETER
383     unauthorizedLCSClient-Param  UnauthorizedLCSClient-Param
384     -- optional
385
386 PositionMethodFailure ::= ERROR
387   PARAMETER
388     positionMethodFailure-Param PositionMethodFailure-Param
389     -- optional
390
391 UnknownOrUnreachableLCSClient ::= ERROR
392   PARAMETER
393     unknownOrUnreachableLCSClient-Param UnknownOrUnreachableLCSClient-Param
394     -- optional
395
396 END

```

17.6.7 Group Call operations

```

1 MAP-Group-Call-Operations {
2   ccitt identified-organization (4) etsi (0) mobileDomain (0)
3   gsm-Network (1) modules (3) map-Group-Call-Operations (22)
4   version5 (5)}
5
6 DEFINITIONS
7
8 ::= 
9
10 BEGIN
11
12 EXPORTS
13   PrepareGroupCall,
14   SendGroupCallEndSignal,
15   ForwardGroupCallSignalling,
16   ProcessGroupCallSignalling
17 ;

```

```

18
19 IMPORTS
20   OPERATION
21 FROM TCAPMessages {
22   ccitt recommendation q 773 modules (2) messages (1) version2 (2)}
23
24   SystemFailure,
25   UnexpectedDataValue,
26   NoGroupCallNumberAvailable
27 FROM MAP-Errors {
28   ccitt identified-organization (4) etsi (0) mobileDomain (0)
29   gsm-Network (1) modules (3) map-Errors (10) version5 (5)}
30
31   PrepareGroupCallArg,
32   PrepareGroupCallRes,
33   SendGroupCallEndSignalArg,
34   SendGroupCallEndSignalRes,
35   ForwardGroupCallSignallingArg,
36   ProcessGroupCallSignallingArg
37 FROM MAP-GR-DataTypes {
38   ccitt identified-organization (4) etsi (0) mobileDomain (0)
39   gsm-Network (1) modules (3) map-GR-DataTypes (23) version5 (5)}
40
41
42 ;
43 ;
44
45
46 PrepareGroupCall ::= OPERATION --Timer m
47   ARGUMENT
48     prepareGroupCallArg      PrepareGroupCallArg
49   RESULT
50     prepareGroupCallRes      PrepareGroupCallRes
51   ERRORS {
52     SystemFailure,
53     NoGroupCallNumberAvailable,
54     UnexpectedDataValue}
55
56 SendGroupCallEndSignal ::= OPERATION --Timer 1
57   ARGUMENT
58     sendGroupCallEndSignalArg SendGroupCallEndSignalArg
59   RESULT
60     sendGroupCallEndSignalRes SendGroupCallEndSignalRes
61
62
63 ProcessGroupCallSignalling ::= OPERATION --Timer s
64   ARGUMENT
65     processGroupCallSignallingArg ProcessGroupCallSignallingArg
66
67 ForwardGroupCallSignalling ::= OPERATION --Timer s
68   ARGUMENT
69     forwardGroupCallSignallingArg ForwardGroupCallSignallingArg
70
71 END

```

17.6.8 Location service operations

```

1 MAP-LocationServiceOperations {
2   ccitt identified-organization (4) etsi (0) mobileDomain (0)
3   gsm-Network (1) modules (3) map-LocationServiceOperations (24)
4   version5 (5)}
5
6 DEFINITIONS
7
8 ::= 
9
10 BEGIN
11
12 EXPORTS
13   ProvideSubscriberLocation,
14   SendRoutingInfoForLCS,
15   SubscriberLocationReport
16 ;
17

```

```

18 IMPORTS
19   OPERATION
20 FROM TCAPMessages {
21   ccitt recommendation q 773 modules (2) messages (1) version2 (2)}
22
23   SystemFailure,
24   DataMissing,
25   UnexpectedDataValue,
26   FacilityNotSupported,
27   UnknownSubscriber,
28   AbsentSubscriber,
29   UnauthorizedRequestingNetwork,
30   UnauthorizedLCSClient,
31   PositionMethodFailure,
32   ResourceLimitation,
33   UnknownOrUnreachableLCSClient,
34   UnidentifiedSubscriber,
35   IllegalEquipment,
36   IllegalSubscriber
37 FROM MAP-Errors {
38   ccitt identified-organization (4) etsi (0) mobileDomain (0)
39   gsm-Network (1) modules (3) map-Errors (10) version5 (5)}
40
41 RoutingInfoForLCS-Arg,
42 RoutingInfoForLCS-Res,
43 ProvideSubscriberLocation-Arg,
44 ProvideSubscriberLocation-Res,
45 SubscriberLocationReport-Arg,
46 SubscriberLocationReport-Res
47 FROM MAP-LCS-DataTypes {
48   ccitt identified-organization (4) etsi (0) mobileDomain (0)
49   gsm-Network (1) modules (3) map-LCS-DataTypes (25) version5 (5)}
50 ;
51
52 SendRoutingInfoForLCS ::= OPERATION --Timer m
53   ARGUMENT
54     routingInfoForLCS-Arg      RoutingInfoForLCS-Arg
55   RESULT
56     routingInfoForLCS-Res      RoutingInfoForLCS-Res
57   ERRORS {
58     SystemFailure,
59     DataMissing,
60     UnexpectedDataValue,
61     FacilityNotSupported,
62     UnknownSubscriber,
63     AbsentSubscriber,
64     UnauthorizedRequestingNetwork }
65
66 ProvideSubscriberLocation ::= OPERATION --Timer ml
67   ARGUMENT
68     provideSubscriberLocation-Arg  ProvideSubscriberLocation-Arg
69   RESULT
70     provideSubscriberLocation-Res  ProvideSubscriberLocation-Res
71   ERRORS {
72     SystemFailure,
73     DataMissing,
74     UnexpectedDataValue,
75     FacilityNotSupported,
76     UnidentifiedSubscriber,
77     IllegalSubscriber,
78     IllegalEquipment,
79     AbsentSubscriber,
80     UnauthorizedRequestingNetwork,
81     UnauthorizedLCSClient,
82     PositionMethodFailure }
83

```

```

84 SubscriberLocationReport ::= OPERATION          --Timer m
85   ARGUMENT
86     subscriberLocationReport-Arg    SubscriberLocationReport-Arg
87   RESULT
88     subscriberLocationReport-Res    SubscriberLocationReport-Res
89   ERRORS {
90     SystemFailure,
91     DataMissing,
92     UnexpectedDataValue,
93     ResourceLimitation,
94     UnknownSubscriber,
95     UnauthorizedRequestingNetwork,
96     UnknownOrUnreachableLCSCClient}
97
98 END
99

```

17.7 MAP constants and data types

17.7.1 Mobile Service data types

```

1 MAP-MS-DataTypes {
2   ccitt identified-organization (4) etsi (0) mobileDomain (0)
3   gsm-Network (1) modules (3) map-MS-DataTypes (11) version5 (5)}
4
5 DEFINITIONS
6
7 IMPLICIT TAGS
8
9 ::==
10
11 BEGIN
12
13 EXPORTS
14
15   -- location registration types
16   UpdateLocationArg,
17   UpdateLocationRes,
18   CancelLocationArg,
19   CancelLocationRes,
20   PurgeMS-Arg,
21   PurgeMS-Res,
22   SendIdentificationRes,
23   UpdateGprsLocationArg,
24   UpdateGprsLocationRes,
25
26
27
28   -- handover types
29   PrepareHO-Arg,
30   PrepareHO-Res,
31   PrepareSubsequentHO-Arg,
32
33   -- authentication management types
34   SendAuthenticationInfoArg,
35   SendAuthenticationInfoRes,
36
37   -- security management types
38   EquipmentStatus,
39   Kc,
40
41   -- subscriber management types
42   InsertSubscriberDataArg,
43   InsertSubscriberDataRes,
44   DeleteSubscriberDataArg,
45   DeleteSubscriberDataRes,
46   SubscriberData,
47   ODB-Data,
48   SubscriberStatus,
49   ZoneCodeList,
50   maxNumOfZoneCodes,
51   O-CSI,
52   O-BcsmCamelTDPCriteriaList,
53   SS-CSI,
54   ServiceKey,
55   DefaultCallHandling,

```

```

56   CamelCapabilityHandling,
57   BasicServiceCriteria,
58   SupportedCamelPhases,
59   maxNumOfCamelTDPData,
60   CUG-Index,
61   CUG-Interlock,
62   InterCUG-Restrictions,
63   IntraCUG-Options,
64   NotificationToMSUser,
65
66   -- fault recovery types
67   ResetArg,
68   RestoreDataArg,
69   RestoreDataRes,
70
71   -- subscriber information enquiry types
72   ProvideSubscriberInfoArg,
73   ProvideSubscriberInfoRes,
74   SubscriberInfo,
75   LocationInformation,
76   SubscriberState,
77
78   -- any time information enquiry types
79   AnyTimeInterrogationArg,
80   AnyTimeInterrogationRes,
81
82   -- gprs location information retrieval types
83   SendRoutingInfoForGprsArg,
84   SendRoutingInfoForGprsRes,
85
86   -- failure reporting types
87   FailureReportArg,
88   FailureReportRes,
89
90   -- gprs notification types
91   NoteMsPresentForGprsArg,
92   NoteMsPresentForGprsRes
93
94 ;
95 ;
96
97 IMPORTS
98   maxNumOfSS,
99   SS-SubscriptionOption,
100  SS-List
101 FROM MAP-SS-DataTypes {
102   ccitt identified-organization (4) etsi (0) mobileDomain (0)
103   gsm-Network (1) modules (3) map-SS-DataTypes (14) version5 (5)}
104
105  SS-Code
106 FROM MAP-SS-Code {
107   ccitt identified-organization (4) etsi (0) mobileDomain (0)
108   gsm-Network (1) modules (3) map-SS-Code (15) version5 (5)}
109
110  Ext-BearerServiceCode
111 FROM MAP-BS-Code {
112   ccitt identified-organization (4) etsi (0) mobileDomain (0)
113   gsm-Network (1) modules (3) map-BS-Code (20) version5 (5)}
114
115  Ext-TeleserviceCode
116 FROM MAP-TS-Code {
117   ccitt identified-organization (4) etsi (0) mobileDomain (0)
118   gsm-Network (1) modules (3) map-TS-Code (19) version5 (5)}
119
120
121 ISDN-AddressString,
122 maxISDN-AddressLength,
123 ISDN-SubaddressString,
124 ExternalSignalInfo,
125 IMSI,
126 HLR-List,
127 LMSI,
128 Identity,
129 GlobalCellId,
130 CellIdOrLAI,
131 Ext-BasicServiceCode,
132 NAEA-PreferredCI,
133 EMLPP-Info,
134 SubscriberIdentity,

```

```

135     AgeOfLocationInformation,
136     LCSClientExternalID,
137     LCSClientInternalID
138
139
140
141 FROM MAP-CommonDataTypes {
142     ccitt identified-organization (4) etsi (0) mobileDomain (0)
143     gsm-Network (1) modules (3) map-CommonDataTypes (18) version5 (5)}
144
145     ExtensionContainer
146 FROM MAP-ExtensionDataTypes {
147     ccitt identified-organization (4) etsi (0) mobileDomain (0)
148     gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version5 (5)}
149
150     AbsentSubscriberDiagnosticSM
151 FROM MAP-ER-DataTypes {
152     ccitt identified-organization (4) etsi (0) mobileDomain (0)
153     gsm-Network (1) modules (3) map-ER-DataTypes (17) version5 (5)}
154
155 ;
156
157
158
159 -- location registration types
160
161 UpdateLocationArg ::= SEQUENCE {
162     imsi                               IMSI,
163
164     msc-Number                         [1] ISDN-AddressString,
165     vlr-Number                          ISDN-AddressString,
166     lmsi                                [10] LMSI OPTIONAL,
167     extensionContainer                  ExtensionContainer           OPTIONAL,
168     ... ,
169     vlr-Capability                     [6] VLR-Capability          OPTIONAL }
170
171 VLR-Capability ::= SEQUENCE{
172     supportedCamelPhases              [0] SupportedCamelPhases    OPTIONAL,
173     extensionContainer                ExtensionContainer           OPTIONAL,
174     ... ,
175     solsaSupportIndicator            [2] NULL                   OPTIONAL }
176
177
178 UpdateLocationRes ::= SEQUENCE {
179     hlr-Number                         ISDN-AddressString,
180
181     extensionContainer                 ExtensionContainer           OPTIONAL,
182     ... }
183
184 CancellingLocationArg ::= [3] SEQUENCE {
185     identity                            Identity,
186     cancellationType                  CancellationType           OPTIONAL,
187     extensionContainer                ExtensionContainer           OPTIONAL,
188     ... }
189
190
191 CancellationType ::= ENUMERATED {
192     updateProcedure                    (0),
193     subscriptionWithdraw             (1),
194     ... }
195     -- The HLR shall not send values other than listed above
196
197
198 CancellingLocationRes ::= SEQUENCE {
199     extensionContainer                 ExtensionContainer           OPTIONAL,
200     ... }
201
202 PurgeMS-Arg ::= [3] SEQUENCE {
203     imsi                               IMSI,
204     vlr-Number                         [0] ISDN-AddressString    OPTIONAL,
205     sgsn-Number                        [1] ISDN-AddressString    OPTIONAL,
206     extensionContainer                 ExtensionContainer           OPTIONAL,
207     ... }
208

```

```

209 PurgeMS-Res ::= SEQUENCE {
210   freezeTMSI                               [ 0] NULL                                OPTIONAL,
211   freezeP-TMSI                             [ 1] NULL                                OPTIONAL,
212   extensionContainer                         ExtensionContainer                         OPTIONAL,
213   ...
214 }
215 SendIdentificationRes ::= SEQUENCE {
216   imsi                                     IMSI,
217   authenticationSetList                    AuthenticationSetList                      OPTIONAL,
218   ...
219 }
220 AuthenticationSetList ::= SEQUENCE SIZE (1..5) OF
221   AuthenticationSet
222
223 AuthenticationSet ::= SEQUENCE {
224   rand                                     RAND,
225   sres                                     SRES,
226   kc                                       Kc,
227   ...
228 }
229 RAND ::= OCTET STRING (SIZE (16))
230
231 SRES ::= OCTET STRING (SIZE (4))
232
233 Kc ::= OCTET STRING (SIZE (8))
234
235 -- gprs location registration types
236
237 UpdateGprsLocationArg ::= SEQUENCE {
238   imsi                                     IMSI,
239   sgsn-Number                            ISDN-AddressString,
240   sgsn-Address                            GSN-Address,
241   extensionContainer                     ExtensionContainer                         OPTIONAL,
242   ...
243   sgsn-Capability                       [ 0] SGSN-Capability                   OPTIONAL }
244
245 SGSN-Capability ::= SEQUENCE{
246   solsaSupportIndicator                  NULL                                OPTIONAL,
247   extensionContainer                     [ 1] ExtensionContainer                OPTIONAL,
248   ...
249 }
250 GSN-Address ::= OCTET STRING (SIZE (5..17))
251 -- Octets are coded according to TS GSM 03.03
252
253 UpdateGprsLocationRes ::= SEQUENCE {
254   hlr-Number                            ISDN-AddressString,
255   extensionContainer                     ExtensionContainer                         OPTIONAL,
256   ...
257 }
258 -- handover types
259
260 PrepareHO-Ang ::= SEQUENCE {
261   targetCellId                           GlobalCellId                          OPTIONAL,
262   ho-NumberNotRequired                  NULL                                OPTIONAL,
263   bss-APDU                               ExternalSignalInfo                   OPTIONAL,
264   ...
265 }
266 PrepareHO-Res ::= SEQUENCE {
267   handoverNumber                        ISDN-AddressString                   OPTIONAL,
268   bss-APDU                             ExternalSignalInfo                   OPTIONAL,
269   ...
270 }
271 PrepareSubsequentHO-Ang ::= SEQUENCE {
272   targetCellId                           GlobalCellId,
273   targetMSC-Number                     ISDN-AddressString,
274   bss-APDU                             ExternalSignalInfo,
275   ...
276 }
277 -- authentication management types
278
279 SendAuthenticationInfoArg ::= IMSI
280
281 SendAuthenticationInfoRes ::= AuthenticationSetList
282
283

```

```

284 -- security management types
285
286 EquipmentStatus ::= ENUMERATED {
287   whiteListed (0),
288   blackListed (1),
289   greyListed (2)}
290
291
292 -- subscriber management types
293
294 InsertSubscriberDataArg ::= SEQUENCE {
295   imsi [0] IMSI OPTIONAL,
296   COMPONENTS OF SubscriberData,
297   extensionContainer [14] ExtensionContainer OPTIONAL,
298   ... ,
299   naea-PreferredCI [15] NAEA-PreferredCI OPTIONAL,
300   -- naea-PreferredCI is included at the discretion of the HLR operator.
301   gprsSubscriptionData [16] GPRSSubscriptionData OPTIONAL,
302   roamingRestrictedInSgsnDueToUnsupportedFeature [23] NULL OPTIONAL,
303
304   networkAccessMode [24] NetworkAccessMode OPTIONAL,
305   lsaInformation [25] LSAInformation OPTIONAL,
306   lmu-Indicator [21] NULL OPTIONAL,
307   lcsInformation [22] LCSInformation OPTIONAL
308 }
309 -- If the Network Access Mode parameter is sent, it shall be present only in
310 -- the first sequence if the segmentation is used
311
312 LCSInformation ::= SEQUENCE {
313   gmlc-List [0] GMLC-List OPTIONAL,
314   lcs-PrivacyExceptionList [1] LCS-PrivacyExceptionList OPTIONAL,
315   molr-List [2] MOLR-List OPTIONAL,
316 ...}
317
318 GMLC-List ::= SEQUENCE SIZE (1..maxNumOfGMLC) OF
319   ISDN-AddressString
320   -- if segmentation is used, the complete GMLC-List shall be sent in one segment
321
322 maxNumOfGMLC INTEGER ::= 5
323
324
325 NetworkAccessMode ::= ENUMERATED {
326   bothMSCAndSGSN (0),
327   onlyMSC (1),
328   onlySGSN (2),
329   ...}
330   -- if unknown values are received in NetworkAccessMode
331   -- they shall be discarded.
332
333 GPRSDataList ::= SEQUENCE SIZE (1..maxNumOfPDP-Contexts) OF
334   PDP-Context
335
336 maxNumOfPDP-Contexts INTEGER ::= 50
337
338 PDP-Context ::= SEQUENCE {
339   pdp-ContextId ContextId,
340   pdp-Type [16] PDP-Type,
341   pdp-Address [17] PDP-Address OPTIONAL,
342   qos-Subscribed [18] QoS-Subscribed,
343   vplmnAddressAllowed [19] NULL OPTIONAL,
344   apn [20] APN ,
345   extensionContainer [21] ExtensionContainer OPTIONAL,
346   ...}
347
348 ContextId ::= INTEGER (1..maxNumOfPDP-Contexts)
349
350 GPRSSubscriptionData ::= SEQUENCE {
351   completeDataListIncluded NULL OPTIONAL,
352
353   -- If segmentation is used, completeDataListIncluded may only be present in the
354   -- first segment.
355   gprsDataList [1] GPRSDataList,
356   extensionContainer [2] ExtensionContainer OPTIONAL,
357   ...}
358

```

```

359 APN ::= OCTET STRING (SIZE (2..63))
360   -- Octets are coded according to TS GSM 03.03
361
362
363 PDP-Type ::= OCTET STRING (SIZE (2))
364   -- Octets are coded according to TS GSM 09.60
365
366 PDP-Address ::= OCTET STRING (SIZE (1..16))
367   -- Octets are coded according to TS GSM 09.60
368
369   -- The possible size values are:
370   -- 1-7 octets X.25 address type
371   -- 4 octets IPv4 address type
372   -- 16 octets Ipv6 address type
373
374 QoS-Subscribed ::= OCTET STRING (SIZE (3))
375   -- Octets are coded according to TS GSM 04.08.
376
377 LSAOnlyAccessIndicator ::= ENUMERATED {
378   accessOutsideLSAsAllowed (0),
379   accessOutsideLSAsRestricted (1)}
380
381 LSADataList ::= SEQUENCE SIZE (1..maxNumOfLSAs) OF
382   LSAData
383
384 maxNumOfLSAs INTEGER ::= 20
385
386 LSAData ::= SEQUENCE {
387   lsaIdentity [0] LSAIdentity,
388   lsaAttributes [1] LSAAttributes,
389   lsaActiveModeIndicator [2] NULL,
390   extensionContainer [3] ExtensionContainer
391   ...}
392
393 LSAInformation ::= SEQUENCE {
394   completeDataListIncluded NULL
395   OPTIONAL,
396   -- If segmentation is used, completeDataListIncluded may only be present in the
397   -- first segment.
398   lsaOnlyAccessIndicator [1] LSAOnlyAccessIndicator
399   OPTIONAL,
400   lsadatelist [2] LSADataList
401   OPTIONAL,
402   extensionContainer [3] ExtensionContainer
403   OPTIONAL,
404 }
405
406 LSAIdentity ::= OCTET STRING (SIZE (3))
407   -- Octets are coded according to TS GSM 03.03
408
409
410 SubscriberData ::= SEQUENCE {
411   msisdn [1] ISDN-AddressString
412   category [2] Category
413   subscriberStatus [3] SubscriberStatus
414   bearerServiceList [4] BearerServiceList
415   -- The exception handling for reception of unsupported / not allocated
416   -- bearerServiceCodes is defined in section 6.8.1
417   teleserviceList [6] TeleserviceList
418   -- The exception handling for reception of unsupported / not allocated
419   -- teleserviceCodes is defined in section 6.8.1
420   provisionedSS [7] Ext-SS-InfoList
421   odb-Data [8] ODB-Data
422   roamingRestrictionDueToUnsupportedFeature [9] NULL
423   regionalSubscriptionData [10] ZoneCodeList
424   vbsSubscriptionData [11] VBSDataList
425   vgcsSubscriptionData [12] VGCSDataList
426   vlrCamelSubscriptionInfo [13] VlrCamelSubscriptionInfo
427 }
428
429 Category ::= OCTET STRING (SIZE (1))
430   -- The internal structure is defined in CCITT Rec Q.763.
431

```

```

432 SubscriberStatus ::= ENUMERATED {
433   serviceGranted (0),
434   operatorDeterminedBarring (1)}
435
436 BearerServiceList ::= SEQUENCE SIZE (1..maxNumOfBearerServices) OF
437   Ext-BearerServiceCode
438
439 maxNumOfBearerServices INTEGER ::= 50
440
441 TeleserviceList ::= SEQUENCE SIZE (1..maxNumOfTeleservices) OF
442   Ext-TeleserviceCode
443
444 maxNumOfTeleservices INTEGER ::= 20
445
446 ODB-Data ::= SEQUENCE {
447   odb-GeneralData
448   odb-HPLMN-Data
449   extensionContainer
450   ...}
451
452 ODB-GeneralData ::= BIT STRING {
453   allOG-CallsBarred (0),
454   internationalOGCallsBarred (1),
455   internationalOGCallsNotToHPLMN-CountryBarred (2),
456   interzonalOGCallsBarred (6),
457   interzonalOGCallsNotToHPLMN-CountryBarred (7),
458   interzonalOGCallsAndInternationalOGCallsNotToHPLMN-CountryBarred (8),
459   premiumRateInformationOGCallsBarred (3),
460   premiumRateEntertainmentOGCallsBarred (4),
461   ss-AccessBarred (5),
462   allECT-Barred (9),
463   chargeableECT-Barred (10),
464   internationalECT-Barred (11),
465   interzonalECT-Barred (12),
466   doublyChargeableECT-Barred (13),
467   multipleECT-Barred (14)} (SIZE (15..32))
468   -- exception handling: reception of unknown bit assignments in the
469   -- ODB-GeneralData type shall be treated like unsupported ODB-GeneralData
470
471 ODB-HPLMN-Data ::= BIT STRING {
472   plmn-SpecificBarringType1 (0),
473   plmn-SpecificBarringType2 (1),
474   plmn-SpecificBarringType3 (2),
475   plmn-SpecificBarringType4 (3)} (SIZE (4..32))
476   -- exception handling: reception of unknown bit assignments in the
477   -- ODB-HPLMN-Data type shall be treated like unsupported ODB-HPLMN-Data
478
479 Ext-SS-InfoList ::= SEQUENCE SIZE (1..maxNumOfSS) OF
480   Ext-SS-Info
481
482 Ext-SS-Info ::= CHOICE {
483   forwardingInfo [0] Ext-ForwInfo,
484   callBarringInfo [1] Ext-CallBarInfo,
485   cug-Info [2] CUG-Info,
486   ss-Data [3] Ext-SS-Data,
487   emlpp-Info [4] EMLPP-Info}
488
489
490 Ext-ForwInfo ::= SEQUENCE {
491   ss-Code
492   forwardingFeatureList
493   extensionContainer
494   ...}
495
496 Ext-ForwFeatureList ::= SEQUENCE SIZE (1..maxNumOfExt-BasicServiceGroups) OF
497   Ext-ForwFeature
498

```

```

499 Ext-ForwFeature ::= SEQUENCE {
500   basicService                                Ext-BasicServiceCode      OPTIONAL,
501   ss-Status [4] Ext-SS-Status,
502   forwardedToNumber                            [5] ISDN-AddressString    OPTIONAL,
503   -- When this data type is sent from an HLR which supports CAMEL Phase 2
504   -- to a VLR that supports CAMEL Phase 2 the VLR shall not check the
505   -- format of the number
506   forwardedToSubaddress                         [8] ISDN-SubaddressString  OPTIONAL,
507   forwardingOptions                           [6] Ext-ForwOptions        OPTIONAL,
508   noReplyConditionTime                      [7] Ext-NoRepCondTime     OPTIONAL,
509   extensionContainer                          [9] ExtensionContainer    OPTIONAL,
510   ...}
511

```

```

512 Ext-SS-Status ::= OCTET STRING (SIZE (1..5))
513
514   -- OCTET 1:
515   --
516   -- bits 8765: 0000 (unused)
517   -- bits 4321: Used to convey the "P bit", "R bit", "A bit" and "Q bit",
518   --             representing supplementary service state information
519   --             as defined in TS GSM 03.11
520
521   -- bit 4: "Q bit"
522
523   -- bit 3: "P bit"
524
525   -- bit 2: "R bit"
526
527   -- bit 1: "A bit"
528
529   -- OCTETS 2-5: reserved for future use. They shall be discarded if
530   -- received and not understood.
531

```

```

532 Ext-ForwOptions ::= OCTET STRING (SIZE (1..5))
533
534   -- OCTET 1:
535
536   -- bit 8: notification to forwarding party
537   -- 0 no notification
538   -- 1 notification
539
540   -- bit 7: redirecting presentation
541   -- 0 no presentation
542   -- 1 presentation
543
544   -- bit 6: notification to calling party
545   -- 0 no notification
546   -- 1 notification
547
548   -- bit 5: 0 (unused)
549
550   -- bits 43: forwarding reason
551   -- 00 ms not reachable
552   -- 01 ms busy
553   -- 10 no reply
554   -- 11 unconditional
555
556   -- bits 21: 00 (unused)
557
558   -- OCTETS 2-5: reserved for future use. They shall be discarded if
559   -- received and not understood.
560

```

```

561 Ext-NoRepCondTime ::= INTEGER (1..100)
562   -- Only values 5-30 are used.
563   -- Values in the ranges 1-4 and 31-100 are reserved for future use
564   -- If received:
565   --   values 1-4 shall be mapped on to value 5
566   --   values 31-100 shall be mapped on to value 30
567

```

```

568
569 Ext-CallBarInfo ::= SEQUENCE {
570   ss-Code                                     SS-Code,
571   callBarringFeatureList                     Ext-CallBarFeatureList,
572   extensionContainer                        ExtensionContainer
573   ...}                                         OPTIONAL,
574

```

```

575 Ext-CallBarFeatureList ::= SEQUENCE SIZE (1..maxNumOfExt-BasicServiceGroups) OF
576   Ext-CallBarringFeature
577
578 Ext-CallBarringFeature ::= SEQUENCE {
579   basicService                         Ext-BasicServiceCode           OPTIONAL,
580   ss-Status [4] Ext-SS-Status,
581   extensionContainer                   ExtensionContainer            OPTIONAL,
582   ...
583 }
584 CUG-Info ::= SEQUENCE {
585   cug-SubscriptionList                CUG-SubscriptionList,
586   cug-FeatureList                    CUG-FeatureList             OPTIONAL,
587   extensionContainer                 [0] ExtensionContainer      OPTIONAL,
588   ...
589 }
590 CUG-SubscriptionList ::= SEQUENCE SIZE (0..maxNumOfCUG) OF
591   CUG-Subscription
592
593 CUG-Subscription ::= SEQUENCE {
594   cug-Index CUG-Index,
595   cug-Interlock                      CUG-Interlock,
596   intraCUG-Options                  IntraCUG-Options,
597   basicServiceGroupList              Ext-BasicServiceGroupList   OPTIONAL,
598   extensionContainer                 [0] ExtensionContainer      OPTIONAL,
599   ...
600 }
601 CUG-Index ::= INTEGER (0..32767)
602   -- The internal structure is defined in ETS 300 138.
603
604 CUG-Interlock ::= OCTET STRING (SIZE (4))
605
606 IntraCUG-Options ::= ENUMERATED {
607   noCUG-Restrictions (0),
608   cugIC-CallBarred (1),
609   cugOG-CallBarred (2)}
610
611 maxNumOfCUG INTEGER ::= 10
612
613 CUG-FeatureList ::= SEQUENCE SIZE (1..maxNumOfExt-BasicServiceGroups) OF
614   CUG-Feature
615
616 Ext-BasicServiceGroupList ::= SEQUENCE SIZE (1..maxNumOfExt-BasicServiceGroups) OF
617   Ext-BasicServiceCode
618
619 maxNumOfExt-BasicServiceGroups INTEGER ::= 32
620
621 CUG-Feature ::= SEQUENCE {
622   basicService                       Ext-BasicServiceCode           OPTIONAL,
623   preferentialCUG-Indicator         CUG-Index OPTIONAL,
624   interCUG-Restrictions            InterCUG-Restrictions,
625   extensionContainer                ExtensionContainer            OPTIONAL,
626   ...
627 }
628 InterCUG-Restrictions ::= OCTET STRING (SIZE (1))
629   -- bits 876543: 000000 (unused)
630   -- Exception handling:
631   -- bits 876543 shall be ignored if received and not understood
632
633   -- bits 21
634   -- 00 CUG only facilities
635   -- 01 CUG with outgoing access
636   -- 10 CUG with incoming access
637   -- 11 CUG with both outgoing and incoming access
638
639

```

```

640 Ext-SS-Data ::= SEQUENCE {
641   ss-Code                               SS-Code,
642   ss-Status [4] Ext-SS-Status,           SS-SubscriptionOption
643   ss-SubscriptionOption                 Ext-BasicServiceGroupList
644   basicServiceGroupList                OPTIONAL,
645   extensionContainer                  ExtensionContainer
646   ...
647
648 LCS-PrivacyExceptionList ::= SEQUENCE SIZE (1..maxNumOfPrivacyClass) OF
649   LCS-PrivacyClass
650
651 maxNumOfPrivacyClass INTEGER ::= 4
652
653 LCS-PrivacyClass ::= SEQUENCE {
654   ss-Code                               SS-Code,
655   ss-Status                            Ext-SS-Status,
656
657   notificationToMSUser [0] NotificationToMSUser      OPTIONAL,
658   -- notificationToMSUser is expected only for SS-code = callunrelated or
659   -- SS-code = callrelated
660   externalClientList [1] ExternalClientList        OPTIONAL,
661   -- externalClientList is expected only for SS-code = callunrelated
662   plmnClientList [2] PLMNClientList            OPTIONAL,
663   -- plmnClientList is expected only for SS-code = plmnoperator
664   extensionContainer [3] ExtensionContainer      OPTIONAL,
665   ...
666   -- if segmentation is used, the complete LCS-PrivacyClass shall be sent in one segment
667
668 ExternalClientList ::= SEQUENCE SIZE (0..maxNumOfExternalClient) OF
669   ExternalClient
670
671 maxNumOfExternalClient INTEGER ::= 5
672
673 PLMNClientList ::= SEQUENCE SIZE (1..maxNumOfPLMNClient) OF
674   LCSClientInternalID
675
676 maxNumOfPLMNClient INTEGER ::= 5
677
678 ExternalClient ::= SEQUENCE {
679   clientIdentity          LCSClientExternalID,
680   gmlc-Restriction        [0] GMLC-Restriction      OPTIONAL,
681   notificationToMSUser   [1] NotificationToMSUser    OPTIONAL,
682   extensionContainer     [2] ExtensionContainer      OPTIONAL,
683   ...
684
685 GMLC-Restriction ::= ENUMERATED {
686   gmlc-List                (0),
687   home-Country             (1),
688   ...
689   }
690   -- exception handling:
691   -- At reception of any other value than the ones listed the receiver shall ignore
692   -- GMLC-Restriction.
693
693 NotificationToMSUser ::= ENUMERATED {
694   notifyLocationAllowed     (0),
695   notifyAndVerify-LocationAllowedIfNoResponse (1),
696   notifyAndVerify-LocationNotAllowedIfNoResponse(2),
697   ...
698   }
699   -- exception handling:
700   -- At reception of any other value than the ones listed the receiver shall ignore
701   -- NotificationToMSUser.
702
702 MOLR-List ::= SEQUENCE SIZE (1..maxNumOfMOLR-Class) OF
703   MOLR-Class
704
705 maxNumOfMOLR-Class INTEGER ::= 3
706
707 MOLR-Class ::= SEQUENCE {
708   ss-Code                               SS-Code,
709   ss-Status                            Ext-SS-Status,
710   extensionContainer                  ExtensionContainer
711   ...
712
713 ZoneCodeList ::= SEQUENCE SIZE (1..maxNumOfZoneCodes)
714   OF ZoneCode
715

```

```

716 ZoneCode ::= OCTET STRING (SIZE (2))
717   -- internal structure is defined in TS GSM 03.03
718
719 maxNumberOfZoneCodes  INTEGER ::= 10
720
721 InsertSubscriberDataRes ::= SEQUENCE {
722   teleserviceList [1] TeleserviceList
723   bearerServiceList [2] BearerServiceList
724   ss-List [3] SS-List
725   odb-GeneralData [4] ODB-GeneralData
726   regionalSubscriptionResponse [5]
727     RegionalSubscriptionResponse OPTIONAL,
728   supportedCamelPhases [6] SupportedCamelPhases
729   extensionContainer [7] ExtensionContainer
730   ...
731 }
732
733 RegionalSubscriptionResponse ::= ENUMERATED {
734   networkNode-AreaRestricted (0),
735   tooManyZoneCodes (1),
736   zoneCodesConflict (2),
737   regionalSubscNotSupported (3)}
738
739 DeleteSubscriberDataArg ::= SEQUENCE {
740   imsi [0] IMSI,
741   basicServiceList [1] BasicServiceList
742   -- The exception handling for reception of unsupported/not allocated
743   -- basicServiceCodes is defined in section 6.8.2
744   ss-List [2] SS-List
745   roamingRestrictionDueToUnsupportedFeature [4] NULL
746   regionalSubscriptionIdentifier [5] ZoneCode
747   vbsGroupIndication [7] NULL
748   vgcsGroupIndication [8] NULL OPTIONAL,
749   camelSubscriptionInfoWithdraw [9] NULL OPTIONAL,
750   extensionContainer [6] ExtensionContainer OPTIONAL,
751   ...
752   gprsSubscriptionDataWithdraw [10] GPRSSubscriptionDataWithdraw OPTIONAL,
753   roamingRestrictedInSgsnDueToUnsupportedFeature [11] NULL OPTIONAL,
754   lsaInformationWithdraw [12] LSAInformationWithdraw OPTIONAL,
755   gmlc-ListWithdraw [13] NULL OPTIONAL }
756
757 GPRSSubscriptionDataWithdraw ::= CHOICE {
758   allGPRSData NULL,
759   contextIdList ContextIdList}
760
761 ContextIdList ::= SEQUENCE SIZE (1..maxNumberOfPDP-Contexts) OF
762   ContextId
763
764 LSAInformationWithdraw ::= CHOICE {
765   allLSAData NULL,
766   lsaIdentityList LSAIdentityList }
767
768 LSAIdentityList ::= SEQUENCE SIZE (1..maxNumberOfLSAs) OF
769   LSAIdentity
770
771 BasicServiceList ::= SEQUENCE SIZE (1..maxNumberOfBasicServices) OF
772   Ext-BasicServiceCode
773
774 maxNumberOfBasicServices  INTEGER ::= 70
775
776 DeleteSubscriberDataRes ::= SEQUENCE {
777   regionalSubscriptionResponse [0]
778     RegionalSubscriptionResponse OPTIONAL,
779   extensionContainer [1] ExtensionContainer
780   ...
781 }
782 VlrCamelSubscriptionInfo ::= SEQUENCE {
783   o-CSI [0] O-CSI
784   extensionContainer [1] ExtensionContainer
785   ...
786   ss-CSI [2] SS-CSI
787   o-BcsmCamelTDP-CriteriaList [4] O-BcsmCamelTDPCriteriaList
788   tif-CSI [3] NULL
789 }

```

```

790 SS-CSI ::= SEQUENCE {
791   ss-CamelData                               SS-CamelData,
792   extensionContainer                         ExtensionContainer
793   ...}                                         OPTIONAL,
794
795 SS-CamelData ::= SEQUENCE {
796   ss-EventList                                SS-EventList,
797   gsmSCF-Address                             ISDN-AddressString,
798   extensionContainer                         [0] ExtensionContainer
799   ...}                                         OPTIONAL,
800
801 SS-EventList ::= SEQUENCE SIZE (1..maxNumOfCamelsSEvents) OF SS-Code
802   -- Actions for the following SS-Code values are defined in CAMEL Phase 2:
803   -- ect                                     SS-Code ::= '00110001'B
804   -- multiPTY                                SS-Code ::= '01010001'B
805   -- cd                                      SS-Code ::= '00100100'B
806   -- all other SS codes shall be ignored
807
808 maxNumOfCamelsSEvents INTEGER ::= 10
809
810 O-CSI ::= SEQUENCE {
811   o-BcsmCamelTDPDataList                    O-BcsmCamelTDPDataList,
812   extensionContainer                         ExtensionContainer
813   ...}                                         OPTIONAL,
814   camelCapabilityHandling                   [0] CamelCapabilityHandling
815   }                                         OPTIONAL
816
817 O-BcsmCamelTDPDataList ::= SEQUENCE SIZE (1..maxNumOfCamelTDPData) OF
818   O-BcsmCamelTDPData
819   --- O-BcsmCamelTDPDataList shall not contain more than one instance of
820   --- O-BcsmCamelTDPData containing the same value for o-BcsmTriggerDetectionPoint.
821   --- For CAMEL Phase 2, this means that only one instance of O-BcsmCamelTDPData is allowed
822   --- with o-BcsmTriggerDetectionPoint being equal to DP2.
823
824 maxNumOfCamelTDPData INTEGER ::= 10
825
826 O-BcsmCamelTDPData ::= SEQUENCE {
827   o-BcsmTriggerDetectionPoint                O-BcsmTriggerDetectionPoint,
828   serviceKey                                 ServiceKey,
829   gsmSCF-Address                            [0] ISDN-AddressString,
830   defaultCallHandling                      [1] DefaultCallHandling,
831   extensionContainer                        [2] ExtensionContainer
832   ...}                                         OPTIONAL,
833   }
834
835 ServiceKey ::= INTEGER (0..2147483647)
836
837 O-BcsmTriggerDetectionPoint ::= ENUMERATED {
838   collectedInfo (2),
839   ...
840   }
841   -- exception handling:
842   -- For O-BcsmCamelTDPData sequences containing this parameter with any
843   -- other value than the ones listed the receiver shall ignore the whole
844   -- O-BcsmCamelTDPData sequence.
845   -- For O-BcsmCamelTDP-Criteria sequences containing this parameter with any
846   -- other value than the ones listed the receiver shall ignore the whole
847   -- O-BcsmCamelTDP-Criteria sequence.
848
849 O-BcsmCamelTDPCriteriaList ::= SEQUENCE SIZE (1..maxNumOfCamelTDPData) OF
850   O-BcsmCamelTDP-Criteria
851
852 O-BcsmCamelTDP-Criteria ::= SEQUENCE {
853   o-BcsmTriggerDetectionPoint                O-BcsmTriggerDetectionPoint,
854   destinationNumberCriteria                 [0] DestinationNumberCriteria
855   basicServiceCriteria                     [1] BasicServiceCriteria
856   callTypeCriteria                         [2] CallTypeCriteria
857   ...}
858
859 DestinationNumberCriteria ::= SEQUENCE {
860   matchType                                [0] MatchType,
861   destinationNumberList                    [1] DestinationNumberList
862   destinationNumberLengthList            [2] DestinationNumberLengthList
863   -- one or both of destinationNumberList and destinationNumberLengthList
864   -- shall be present
865   ...}
866

```

```

867 DestinationNumberList ::= SEQUENCE SIZE (1..maxNumOfCamelDestinationNumbers) OF
868           ISDN-AddressString
869   -- The receiving entity shall not check the format of a number in
870   -- the dialled number list
871
872 DestinationNumberLengthList ::= SEQUENCE SIZE (1..maxNumOfCamelDestinationNumberLengths)
873   OF
874           INTEGER(1..maxNumOfISDN-AddressDigits)
875
876 BasicServiceCriteria ::= SEQUENCE SIZE(1..maxNumOfCamelBasicServiceCriteria) OF
877   Ext-BasicServiceCode
878
879 maxNumOfISDN-AddressDigits INTEGER ::= 15
880
881 maxNumOfCamelDestinationNumbers INTEGER ::= 10
882
883 maxNumOfCamelDestinationNumberLengths INTEGER ::= 3
884
885 maxNumOfCamelBasicServiceCriteria INTEGER ::= 5
886
887 CallTypeCriteria ::= ENUMERATED {
888   forwarded                               (0),
889   notForwarded                            (1)}
890
891 MatchType ::= ENUMERATED {
892   inhibiting                             (0),
893   enabling                                (1)}
894
895
896 DefaultCallHandling ::= ENUMERATED {
897   continueCall (0),
898   releaseCall (1),
899   ...}
900   -- exception handling:
901   -- reception of values in range 2-31 shall be treated as "continueCall"
902   -- reception of values greater than 31 shall be treated as "releaseCall"
903
904 CamelCapabilityHandling ::= INTEGER(1..16)
905   -- value 1 = CAMEL phase 1,
906   -- value 2 = CAMEL phase 2:
907   -- reception of values greater than 2 shall be treated as CAMEL phase 2
908
909 SupportedCamelPhases ::= BIT STRING {
910   phase1 (0),
911   phase2 (1) } (SIZE (1..16))
912   -- A node shall mark in the BIT STRING all CAMEL Phases which it supports.
913   -- Other values than those listed above shall be discarded.
914
915
916   -- gprs location information retrieval types
917
918 SendRoutingInfoForGprsArg ::= SEQUENCE {
919   imsi                      [0] IMSI,
920   ggsn-Address               [1] GSN-Address          OPTIONAL,
921   ggsn-Number                [2] ISDN-AddressString,
922   extensionContainer         [3] ExtensionContainer    OPTIONAL,
923   ...}
924
925 SendRoutingInfoForGprsRes ::= SEQUENCE {
926   sgsn-Address               [0] GSN-Address          OPTIONAL,
927   ggsn-Address               [1] GSN-Address          OPTIONAL,
928   mobileNotReachableReason  [2] AbsentSubscriberDiagnosticSM OPTIONAL,
929   extensionContainer         [3] ExtensionContainer    OPTIONAL,
930   ...}
931
932   -- failure report types
933
934 FailureReportArg ::= SEQUENCE {
935   imsi                      [0] IMSI,
936   ggsn-Number                [1] ISDN-AddressString ,
937   ggsn-Address               [2] GSN-Address          OPTIONAL,
938   extensionContainer         [3] ExtensionContainer    OPTIONAL,
939   ...}
940

```

```

941 FailureReportRes ::= SEQUENCE {
942   ggsn-Address                               [ 0 ] GSN-Address           OPTIONAL,
943   extensionContainer                         [ 1 ] ExtensionContainer    OPTIONAL,
944   ...}
945
946 -- gprs notification types
947
948 NoteMsPresentForGprsArg ::= SEQUENCE {
949   imsi                                         [ 0 ] IMSI,
950   sgsn-Address                                [ 1 ] GSN-Address,
951   ggsn-Address                                [ 2 ] GSN-Address           OPTIONAL,
952   extensionContainer                         [ 3 ] ExtensionContainer    OPTIONAL,
953   ...}
954
955 NoteMsPresentForGprsRes ::= SEQUENCE {
956   extensionContainer                         [ 0 ] ExtensionContainer    OPTIONAL,
957   ...}
958
959
960 -- fault recovery types
961
962 ResetArg ::= SEQUENCE {
963   hlr-Number                                 ISDN-AddressString,
964   hlr-List                                    HLR-List
965   ...}
966
967 RestoreDataArg ::= SEQUENCE {
968   imsi                                         IMSI,
969   lmsi                                         LMSI
970   extensionContainer                         ExtensionContainer
971   ...,
972   vlr-Capability                            [ 6 ] VLR-Capability        OPTIONAL }
973
974 RestoreDataRes ::= SEQUENCE {
975   hlr-Number                                 ISDN-AddressString,
976   msNotReachable                           NULL
977   extensionContainer                         ExtensionContainer
978   ...}
979
980 -- VBS/VGCS types
981 VBSDataList ::= SEQUENCE SIZE (1..maxNumOfVBSGroupIds) OF
982   VoiceBroadcastData
983
984 VGCSDataList ::= SEQUENCE SIZE (1..maxNumOfVGCSGroupIds) OF
985   VoiceGroupCallData
986
987 maxNumOfVBSGroupIds INTEGER ::= 50
988
989 maxNumOfVGCSGroupIds INTEGER ::= 50
990
991 VoiceGroupCallData ::= SEQUENCE {
992   groupId                                     GroupId,
993   extensionContainer                         ExtensionContainer
994   ...}
995
996 VoiceBroadcastData ::= SEQUENCE {
997   groupId                                     GroupId,
998   broadcastInitEntitlement                  NULL
999   extensionContainer                         ExtensionContainer
1000  ...}
1001
1002 GroupId ::= OCTET STRING (SIZE (3))
1003   -- Refers to the Group Identification as specified in GSM TS 03.03
1004   -- and 03.68/ 03.69
1005
1006 -- provide subscriber info types
1007
1008 ProvideSubscriberInfoArg ::= SEQUENCE {
1009   imsi          [ 0 ] IMSI,
1010   lmsi          [ 1 ] LMSI
1011   requestedInfo [ 2 ] RequestedInfo,
1012   extensionContainer [ 3 ] ExtensionContainer
1013   ...}
1014

```

```

1015 ProvideSubscriberInfoRes ::= SEQUENCE {
1016     subscriberInfo                               SubscriberInfo,
1017     extensionContainer                           ExtensionContainer
1018     ...}                                         OPTIONAL,
1019
1020 SubscriberInfo ::= SEQUENCE {
1021     locationInformation                         [0] LocationInformation
1022     subscriberState                            [1] SubscriberState
1023     extensionContainer                          [2] ExtensionContainer
1024     ...}                                         OPTIONAL,
1025
1026 RequestedInfo ::= SEQUENCE {
1027     locationInformation                         [0] NULL
1028     subscriberState                            [1] NULL
1029     extensionContainer                          [2] ExtensionContainer
1030     ...}                                         OPTIONAL,
1031
1032 LocationInformation ::= SEQUENCE {
1033     ageOfLocationInformation                  AgeOfLocationInformation
1034     geographicalInformation                   [0] GeographicalInformation
1035     vlr-number                                [1] ISDN-AddressString
1036     locationNumber                            [2] LocationNumber
1037     cellIdOrLAI                             [3] CellIdOrLAI
1038     extensionContainer                        [4] ExtensionContainer
1039     ...}                                         OPTIONAL,
1040
1041 GeographicalInformation ::= OCTET STRING (SIZE (8))
1042 -- Refers to geographical Information defined in GSM 03.32.
1043 -- Only the description of an ellipsoid point with uncertainty circle
1044 --as specified in GSM 03.32 is allowed to be used
1045 -- The internal structure according to GSM 03.32 is as follows:
1046 --      Type of shape (ellipsoid point with uncertainty circle)      1 octet
1047 --      Degrees of Latitude                                         3 octets
1048 --      Degrees of Longitude                                         3 octets
1049 --      Uncertainty code                                           1 octet
1050
1051 LocationNumber ::= OCTET STRING (SIZE (2..10))
1052 -- the internal structure is defined in CCITT Rec Q.763
1053
1054 SubscriberState ::= CHOICE {
1055     assumedIdle                                [0] NULL,
1056     camelBusy [1] NULL,
1057     netDetNotReachable                      NotReachableReason,
1058     notProvidedFromVLR                     [2] NULL}
1059
1060 NotReachableReason ::= ENUMERATED {
1061     msPurged (0),
1062     imsIDetached (1),
1063     restrictedArea (2),
1064     notRegistered (3)}
1065
1066 -- any time interrogation info types
1067
1068 AnyTimeInterrogationArg ::= SEQUENCE {
1069     subscriberIdentity                         [0] SubscriberIdentity,
1070     requestedInfo                            [1] RequestedInfo,
1071     gsmSCF-Address                           [3] ISDN-AddressString,
1072     extensionContainer                       [2] ExtensionContainer
1073     ...}                                         OPTIONAL,
1074
1075 AnyTimeInterrogationRes ::= SEQUENCE {
1076     subscriberInfo                            SubscriberInfo,
1077     extensionContainer                       ExtensionContainer
1078     ...}                                         OPTIONAL,
1079
1080
1081 END

```

17.7.2 Operation and maintenance data types

```

1 MAP-OM-DataTypes {
2     ccitt identified-organization (4) etsi (0) mobileDomain (0)
3     gsm-Network (1) modules (3) map-OM-DataTypes (12) version5 (5)
4
5 DEFINITIONS
6
7 IMPLICIT TAGS

```

```

8 ::= 
9 BEGIN
10
11 EXPORTS
12   ActivateTraceModeArg,
13   ActivateTraceModeRes,
14   DeactivateTraceModeArg,
15   DeactivateTraceModeRes
16 ;
17
18 IMPORTS
19   AddressString,
20   IMSI
21 FROM MAP-CommonDataTypes {
22   ccitt identified-organization (4) etsi (0) mobileDomain (0)
23   gsm-Network (1) modules (3) map-CommonDataTypes (18) version5 (5)}
24
25 ExtensionContainer
26 FROM MAP-ExtensionDataTypes {
27   ccitt identified-organization (4) etsi (0) mobileDomain (0)
28   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version5 (5)}
29
30 ;
31
32 ;
33
34 ;
35
36 ActivateTraceModeArg ::= SEQUENCE {
37   imsi                               [0] IMSI                  OPTIONAL,
38   traceReference                      [1] TraceReference,
39   traceType [2] TraceType,
40   omc-Id                             [3] AddressString        OPTIONAL,
41   extensionContainer                  [4] ExtensionContainer    OPTIONAL,
42   ...
43 }
44 TraceReference ::= OCTET STRING (SIZE (1..2))
45
46 TraceType ::= INTEGER
47   (0..255)
48   -- Trace types are fully defined in TS GSM 12.08.
49
50 ActivateTraceModeRes ::= SEQUENCE {
51   extensionContainer                 [0] ExtensionContainer    OPTIONAL,
52   ...
53 }
54 DeactivateTraceModeArg ::= SEQUENCE {
55   imsi                               [0] IMSI                  OPTIONAL,
56   traceReference                     [1] TraceReference,
57   extensionContainer                [2] ExtensionContainer    OPTIONAL,
58   ...
59 }
60 DeactivateTraceModeRes ::= SEQUENCE {
61   extensionContainer                 [0] ExtensionContainer    OPTIONAL,
62   ...
63 }
64 END

```

17.7.3 Call handling data types

```

1 MAP-CH-DataTypes {
2   ccitt identified-organization (4) etsi (0) mobileDomain (0)
3   gsm-Network (1) modules (3) map-CH-DataTypes (13) version5 (5)}
4
5 DEFINITIONS
6
7 IMPLICIT TAGS
8
9 ::= 
10 BEGIN
11
12 EXPORTS
13   SendRoutingInfoArg,
14   SendRoutingInfoRes,
15   ProvideRoamingNumberArg,
16   ProvideRoamingNumberRes,
17

```

```

18   ResumeCallHandlingArg,
19   ResumeCallHandlingRes,
20   NumberOfForwarding,
21   SuppressionOfAnnouncement,
22   CallReferenceNumber,
23   ProvideSIWFSTNumberArg,
24   ProvideSIWFSTNumberRes,
25   SIWFSSignallingModifyArg,
26   SIWFSSignallingModifyRes,
27   SetReportingStateArg,
28   SetReportingStateRes,
29   StatusReportArg,
30   StatusReportRes,
31   RemoteUserFreeArg,
32   RemoteUserFreeRes
33 ;
34
35 IMPORTS
36   maxNumOfCamelTDPData,
37   SubscriberInfo,
38   ServiceKey,
39   DefaultCallHandling,
40   SupportedCamelPhases,
41   CamelCapabilityHandling,
42   BasicServiceCriteria,
43   CUG-Interlock,
44   O-CSI,
45   O-BcsmCamelTDPCriteriaList
46
47 FROM MAP-MS-DataTypes {
48   ccitt identified-organization (4) etsi (0) mobileDomain (0)
49   gsm-Network (1) modules (3) map-MS-DataTypes (11) version5 (5)}
50
51   ForwardingOptions,
52   SS-List,
53   CCBS-Feature
54 FROM MAP-SS-DataTypes {
55   ccitt identified-organization (4) etsi (0) mobileDomain (0)
56   gsm-Network (1) modules (3) map-SS-DataTypes (14) version5 (5)}
57
58   ISDN-AddressString,
59   ISDN-SubaddressString,
60   ExternalSignalInfo,
61   Ext-ExternalSignalInfo,
62   IMSI,
63   LMSI,
64   Ext-BasicServiceCode,
65   AlertingPattern,
66   NAEA-PreferredCI
67
68
69 FROM MAP-CommonDataTypes {
70   ccitt identified-organization (4) etsi (0) mobileDomain (0)
71   gsm-Network (1) modules (3) map-CommonDataTypes (18) version5 (5)}
72
73   ExtensionContainer
74 FROM MAP-ExtensionDataTypes {
75   ccitt identified-organization (4) etsi (0) mobileDomain (0)
76   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version5 (5)}
77 ;
78
79
80 CUG-CheckInfo ::= SEQUENCE {
81   cug-Interlock                               CUG-Interlock,
82   cug-OutgoingAccess                         NULL                   OPTIONAL,
83   extensionContainer                         ExtensionContainer    OPTIONAL,
84   ...}
85
86 NumberOfForwarding ::= INTEGER (1..5)
87

```

```

88 SendRoutingInfoArg ::= SEQUENCE {
89   msisdn                               [0] ISDN-AddressString,
90   cug-CheckInfo                          [1] CUG-CheckInfo           OPTIONAL,
91   numberOfForwarding                    [2] NumberOfForwarding     OPTIONAL,
92   interrogationType                    [3] InterrogationType      ,
93   or-Interrogation                     [4] NULL                  OPTIONAL,
94   or-Capability                        [5] OR-Phase              OPTIONAL,
95   gmsc-Address                         [6] ISDN-AddressString,
96   callReferenceNumber                  [7] CallReferenceNumber    OPTIONAL,
97   forwardingReason                     [8] ForwardingReason       OPTIONAL,
98   basicServiceGroup                   [9] Ext-BasicServiceCode  OPTIONAL,
99   networkSignalInfo                   [10] ExternalSignalInfo   OPTIONAL,
100  camelInfo                            [11] CamelInfo             OPTIONAL,
101  suppressionOfAnnouncement          [12] SuppressionOfAnnouncement  OPTIONAL,
102  extensionContainer                 [13] ExtensionContainer   OPTIONAL,
103  ...
104  alertingPattern                    [14] AlertingPattern        OPTIONAL,
105  ccbs-Call                           [15] NULL                 OPTIONAL,
106  supportedCCBS-Phase               [16] SupportedCCBS-Phase   OPTIONAL,
107  additionalSignalInfo              [17] Ext-ExternalSignalInfo OPTIONAL }

108
109 SuppressionOfAnnouncement ::= NULL
110
111 InterrogationType ::= ENUMERATED {
112   basicCall    (0),
113   forwarding   (1) }

114
115 OR-Phase ::= INTEGER (1..127)
116
117 CallReferenceNumber ::= OCTET STRING (SIZE (1..8))
118
119 ForwardingReason ::= ENUMERATED {
120   notReachable (0),
121   busy         (1),
122   noReply      (2) }

123
124 SupportedCCBS-Phase ::= INTEGER (1..127)
125 -- exception handling:
126 -- Only value 1 is used.
127 -- Values in the ranges 2-127 are reserved for future use.
128 -- If received values 2-127 shall be mapped on to value 1.
129
130 SendRoutingInfoRes ::= [3] SEQUENCE {
131   imsi                                [9] IMSI                OPTIONAL,
132   -- IMSI must be present if SendRoutingInfoRes is not segmented.
133   -- If the TC-Result-NL segmentation option is taken the IMSI must be
134   -- present in one segmented transmission of SendRoutingInfoRes.
135   extendedRoutingInfo                  ExtendedRoutingInfo   OPTIONAL,
136   cug-CheckInfo                        [3] CUG-CheckInfo      OPTIONAL,
137   cugSubscriptionFlag                 [6] NULL              OPTIONAL,
138   subscriberInfo                      [7] SubscriberInfo    OPTIONAL,
139   ss-List                             [1] SS-List            OPTIONAL,
140   basicService                        [5] Ext-BasicServiceCode OPTIONAL,
141   forwardingInterrogationRequired    [4] NULL              OPTIONAL,
142   vmsc-Address                        [2] ISDN-AddressString OPTIONAL,
143   extensionContainer                 [0] ExtensionContainer OPTIONAL,
144   ...
145   naea-PreferredCI                   [10] NAEA-PreferredCI  OPTIONAL,
146   -- naea-PreferredCI is included at the discretion of the HLR operator.
147   ccbs-Indicators                     [11] CCBS-Indicators   OPTIONAL,
148   msisdn                            [12] ISDN-AddressString OPTIONAL,
149   numberPortabilityStatus            [13] NumberPortabilityStatus OPTIONAL
150 }

151
152 NumberPortabilityStatus ::= ENUMERATED {
153   notKnownToBePorted                 (0),
154   ownNumberPortedOut                (1),
155   foreignNumberPortedToForeignNetwork (2),
156   ...
157   -- exception handling:
158   -- reception of other values than the ones listed the receiver shall ignore the
159   -- whole NumberPortabilityStatus
160 }

```

```

161 CCBS-Indicators ::= SEQUENCE {
162   ccbs-Possible                               [ 0] NULL                                OPTIONAL,
163   keepCCBS-CallIndicator                      [ 1] NULL                                OPTIONAL,
164   extensionContainer                          [ 2] ExtensionContainer                   OPTIONAL,
165   ...
166 }
167 RoutingInfo ::= CHOICE {
168   roamingNumber                         ISDN-AddressString,
169   forwardingData                        ForwardingData}
170
171 ForwardingData ::= SEQUENCE {
172   forwardedToNumber                     [ 5] ISDN-AddressString      OPTIONAL,
173   -- When this datatype is sent from an HLR which supports CAMEL Phase 2
174   -- to a GMSC which supports CAMEL Phase 2 the GMSC shall not check the
175   -- format of the number
176   forwardedToSubaddress                [ 4] ISDN-SubaddressString    OPTIONAL,
177   forwardingOptions                   [ 6] ForwardingOptions        OPTIONAL,
178   extensionContainer                  [ 7] ExtensionContainer       OPTIONAL,
179   ...
180 }
181 ProvideRoamingNumberArg ::= SEQUENCE {
182   imsi                                 [ 0] IMSI,
183   msc-Number                           [ 1] ISDN-AddressString,
184   msisdn                              [ 2] ISDN-AddressString      OPTIONAL,
185   lmsi                                 [ 4] LMSI                                OPTIONAL,
186   gsm-BearerCapability                 [ 5] ExternalSignalInfo     OPTIONAL,
187   networkSignalInfo                   [ 6] ExternalSignalInfo     OPTIONAL,
188   suppressionOfAnnouncement          [ 7] SuppressionOfAnnouncement OPTIONAL,
189   gmsc-Address                         [ 8] ISDN-AddressString      OPTIONAL,
190   callReferenceNumber                 [ 9] CallReferenceNumber    OPTIONAL,
191   or-Interrogation                    [ 10] NULL                                OPTIONAL,
192   extensionContainer                  [ 11] ExtensionContainer     OPTIONAL,
193   ...
194   alertingPattern                     [ 12] AlertingPattern        OPTIONAL,
195   ccbs-Call                            [ 13] NULL                                OPTIONAL,
196   supportedCamelPhasesInGMSC         [ 15] SupportedCamelPhases   OPTIONAL,
197   additionalSignalInfo                [ 14] Ext-ExternalSignalInfo  OPTIONAL,
198   orNotSupportedInGMSC               [ 16] NULL                                OPTIONAL }
199
200 ProvideRoamingNumberRes ::= SEQUENCE {
201   roamingNumber                       ISDN-AddressString,
202   extensionContainer                  ExtensionContainer      OPTIONAL,
203   ...
204 }
205 ResumeCallHandlingArg ::= SEQUENCE {
206   callReferenceNumber                 [ 0] CallReferenceNumber    OPTIONAL,
207   basicServiceGroup                  [ 1] Ext-BasicServiceCode   OPTIONAL,
208   forwardingData                     [ 2] ForwardingData        OPTIONAL,
209   imsi                               [ 3] IMSI                                OPTIONAL,
210   cug-CheckInfo                      [ 4] CUG-CheckInfo        OPTIONAL,
211   o-CSI                             [ 5] O-CSI                                OPTIONAL,
212   extensionContainer                [ 7] ExtensionContainer     OPTIONAL,
213   ccbs-Possible                      [ 8] NULL                                OPTIONAL,
214   msisdn                            [ 9] ISDN-AddressString    OPTIONAL,
215   uu-Data                            [ 10] UU-Data      OPTIONAL,
216   allInformationSent                [ 11] NULL                                OPTIONAL,
217   ...
218 }
219 UU-Data ::= SEQUENCE {
220   uuIndicator                         [ 0] UUIIndicator        OPTIONAL,
221   uui                                [ 1] UUI                                OPTIONAL,
222   uusCFInteraction                   [ 2] NULL                                OPTIONAL,
223   extensionContainer                  [ 3] ExtensionContainer     OPTIONAL,
224   ...
225 }
226 UUIIndicator ::= OCTET STRING (SIZE (1))
227   -- Octets are coded according to ETS 300 356
228
229 UUI ::= OCTET STRING (SIZE (1..131))
230   -- Octets are coded according to ETS 300 356
231
232 ResumeCallHandlingRes ::= SEQUENCE {
233   extensionContainer                  ExtensionContainer     OPTIONAL,
234   ...
235 }

```

```

236 CamelInfo ::= SEQUENCE {
237   supportedCamelPhases           SupportedCamelPhases,
238   suppress-T-CSI                NULL
239   extensionContainer             ExtensionContainer
240   ...
241 }
242 ExtendedRoutingInfo ::= CHOICE {
243   routingInfo                   RoutingInfo,
244   camelRoutingInfo              [8] CamelRoutingInfo}
245
246 CamelRoutingInfo ::= SEQUENCE {
247   forwardingData               ForwardingData
248   gmscCamelSubscriptionInfo    [0] GmscCamelSubscriptionInfo,
249   extensionContainer            [1] ExtensionContainer
250   ...
251 }
252 GmscCamelSubscriptionInfo ::= SEQUENCE {
253   t-CSI                        [0] T-CSI OPTIONAL,
254   o-CSI                        [1] O-CSI OPTIONAL,
255   extensionContainer             [2] ExtensionContainer
256   ...
257   o-BcsmCamelTDP-CriteriaList [3] O-BcsmCamelTDPCriteriaList OPTIONAL
258 }
259
260 T-CSI ::= SEQUENCE {
261   t-BcsmCamelTDPDataList        T-BcsmCamelTDPDataList,
262   extensionContainer             ExtensionContainer
263   ...
264   camelCapabilityHandling       [0] CamelCapabilityHandling
265   }
266
267 T-BcsmCamelTDPDataList ::= SEQUENCE SIZE (1..maxNumOfCamelTDPData) OF
268   T-BcsmCamelTDPData
269 --- T-BcsmCamelTDPDataList shall not contain more than one instance of
270 --- T-BcsmCamelTDPData containing the same value for t-BcsmTriggerDetectionPoint.
271 --- For CAMEL Phase 2, this means that only one instance of T-BcsmCamelTDPData is allowed
272 --- with t-BcsmTriggerDetectionPoint being equal to DP12.
273
274 T-BcsmCamelTDPData ::= SEQUENCE {
275   t-BcsmTriggerDetectionPoint    T-BcsmTriggerDetectionPoint,
276   serviceKey                   ServiceKey,
277   gsmSCF-Address                [0] ISDN-AddressString,
278   defaultCallHandling           [1] DefaultCallHandling,
279   extensionContainer             [2] ExtensionContainer
280   ...
281 }
282 T-BcsmTriggerDetectionPoint ::= ENUMERATED {
283   termAttemptAuthorized(12),
284   ...
285 -- exception handling:
286 -- For T-BcsmCamelTDPData sequences containing this parameter with any other
287 -- value than the ones listed the receiver shall ignore the whole
288 -- T-BcsmCamelTDPData sequence.
289
290 ProvideIWFSNumberArg ::= SEQUENCE {
291   gsm-BearerCapability          [0] ExternalSignalInfo,
292   isdn-BearerCapability         [1] ExternalSignalInfo,
293   call-Direction                 [2] CallDirection,
294   b-Subscriber-Address          [3] ISDN-AddressString,
295   chosenChannel                 [4] ExternalSignalInfo,
296   lowerLayerCompatibility        [5] ExternalSignalInfo
297   highLayerCompatibility         [6] ExternalSignalInfo
298   extensionContainer             [7] ExtensionContainer
299   ...
300 }
301 CallDirection ::= OCTET STRING (SIZE (1))
302   -- OCTET 1
303
304   -- bit 1 (direction of call)
305   -- 0 Mobile Originated Call (MOC)
306   -- 1 Mobile Terminated Call (MTC)
307
308 
```

```

309 ProvideSIWFSSNumberRes ::= SEQUENCE {
310     siwfsNumber
311     extensionContainer
312     ...
313 }
314 SIWFSSignallingModifyArg ::= SEQUENCE {
315     channelType
316     chosenChannel
317     extensionContainer
318     ...
319 }
320 SIWFSSignallingModifyRes ::= SEQUENCE {
321     chosenChannel
322     extensionContainer
323     ...
324 }
325 SetReportingStateArg ::= SEQUENCE {
326     imsi
327     lmsi
328     ccbs-Monitoring
329     extensionContainer
330     ...
331 }
332 ReportingState ::= ENUMERATED {
333     stopMonitoring
334     startMonitoring
335     ...
336 }
-- exception handling:
-- reception of values 2-10 shall be mapped to 'stopMonitoring'
-- reception of values > 10 shall be mapped to 'startMonitoring'
337
338
339
340 SetReportingStateRes ::= SEQUENCE{
341     ccbs-SubscriberStatus
342     extensionContainer
343     ...
344 }
345 CCBS-SubscriberStatus ::= ENUMERATED {
346     ccbsNotIdle
347     ccbsIdle (1),
348     ccbsNotReachable
349     ...
350 }
-- exception handling:
-- reception of values 3-10 shall be mapped to 'ccbsNotIdle'
-- reception of values 11-20 shall be mapped to 'ccbsIdle'
-- reception of values > 20 shall be mapped to 'ccbsNotReachable'
351
352
353
354
355 StatusReportArg ::= SEQUENCE{
356     imsi
357     eventReportData
358     callReportdata
359     extensionContainer
360     ...
361 }
362 EventReportData ::= SEQUENCE{
363     ccbs-SubscriberStatus
364     extensionContainer
365     ...
366 }
367 CallReportData ::= SEQUENCE{
368     monitoringMode
369     callOutcome
370     extensionContainer
371     ...
372 }
373 MonitoringMode ::= ENUMERATED {
374     a-side
375     b-side
376     ...
377 }
-- exception handling:
-- reception of values 2-10 shall be mapped 'a-side'
-- reception of values > 10 shall be mapped to 'b-side'
378
379
380

```

```

381 CallOutcome ::= ENUMERATED {
382   success                               (0),
383   failure                                (1),
384   busy                                    (2),
385   ...
386 -- exception handling:
387 -- reception of values 3-10 shall be mapped to 'success'
388 -- reception of values 11-20 shall be mapped to 'failure'
389 -- reception of values > 20 shall be mapped to 'busy'
390
391 StatusReportRes ::= SEQUENCE {
392   extensionContainer          [0] ExtensionContainer      OPTIONAL,
393   ...
394
395 RemoteUserFreeArg ::= SEQUENCE {
396   imsi                      [0] IMSI,
397   callInfo                  [1] ExternalSignalInfo,
398   ccbs-Feature              [2] CCBS-Feature,
399   translatedB-Number        [3] ISDN-AddressString,
400   replaceB-Number           [4] NULL                   OPTIONAL,
401   alertingPattern          [5] AlertingPattern        OPTIONAL,
402   extensionContainer        [6] ExtensionContainer    OPTIONAL,
403   ...
404
405 RemoteUserFreeRes ::= SEQUENCE {
406   ruf-Outcome                [0] RUF-Outcome,
407   extensionContainer          [1] ExtensionContainer      OPTIONAL,
408   ...
409
410 RUF-Outcome ::= ENUMERATED{
411   accepted (0),
412   rejected (1),
413   noResponseFromFreeMS (2), -- T4 Expiry
414   noResponseFromBusyMS (3), -- T10 Expiry
415   udubFromFreeMS (4),
416   udubFromBusyMS (5),
417   ...
418 -- exception handling:
419 -- reception of values 6-20 shall be mapped to 'accepted'
420 -- reception of values 21-30 shall be mapped to 'rejected'
421 -- reception of values 31-40 shall be mapped to 'noResponseFromFreeMS'
422 -- reception of values 41-50 shall be mapped to 'noResponseFromBusyMS'
423 -- reception of values 51-60 shall be mapped to 'udubFromFreeMS'
424 -- reception of values > 60 shall be mapped to 'udubFromBusyMS'
425
426 END

```

17.7.4 Supplementary service data types

```

1 MAP-SS-DataTypes {
2   ccitt identified-organization (4) etsi (0) mobileDomain (0)
3   gsm-Network (1) modules (3) map-SS-DataTypes (14) version5 (5)
4
5 DEFINITIONS
6
7 IMPLICIT TAGS
8
9 ::= 
10 BEGIN
11
12 EXPORTS
13   RegisterSS-Arg,
14   SS-Info,
15   SS-Status,
16   SS-SubscriptionOption,
17   SS-ForBS-Code,
18   InterrogateSS-Res,
19   USSD-Arg,
20   USSD-Res,
21   USSD-DataCodingScheme,
22   USSD-String,
23   Password,
24   GuidanceInfo,
25   SS-List,
26   SS-InfoList,
27   OverrideCategory,
28   CliRestrictionOption,
29

```

```

30      NoReplyConditionTime,
31      ForwardingOptions,
32      maxNumOfSS,
33      SS-Data,
34      SS-InvocationNotificationArg,
35      SS-InvocationNotificationRes,
36      CCBs-Feature,
37      RegisterCC-EntryArg,
38      RegisterCC-EntryRes,
39      EraseCC-EntryArg,
40      EraseCC-EntryRes
41 ;
42
43 IMPORTS
44     AddressString,
45     ISDN-AddressString,
46     ISDN-SubaddressString,
47     IMSI,
48     BasicServiceCode,
49     AlertingPattern,
50     EMLPP-Priority,
51     ExternalSignalInfo
52
53 FROM MAP-CommonDataTypes {
54     ccitt identified-organization (4) etsi (0) mobileDomain (0)
55     gsm-Network (1) modules (3) map-CommonDataTypes (18) version5 (5)}
56
57     ExtensionContainer
58 FROM MAP-ExtensionDataTypes {
59     ccitt identified-organization (4) etsi (0) mobileDomain (0)
60     gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version5 (5)}
61
62     SS-Code
63 FROM MAP-SS-Code {
64     ccitt identified-organization (4) etsi (0) mobileDomain (0)
65     gsm-Network (1) modules (3) map-SS-Code (15) version5 (5)}
66 ;
67
68
69 RegisterSS-Arg ::= SEQUENCE{
70     ss-Code                               SS-Code,
71     basicService                          BasicServiceCode          OPTIONAL,
72     forwardedToNumber                     [4] AddressString        OPTIONAL,
73     forwardedToSubaddress                [6] ISDN-SubaddressString OPTIONAL,
74     noReplyConditionTime                 [5] NoReplyConditionTime OPTIONAL,
75     ...,
76     defaultPriority                      [7] EMLPP-Priority       OPTIONAL }
77
78 NoReplyConditionTime ::= INTEGER (5..30)
79
80 SS-Info ::= CHOICE {
81     forwardingInfo                      [0] ForwardingInfo,
82     callBarringInfo                     [1] CallBarringInfo,
83     ss-Data                            [3] SS-Data}
84
85 ForwardingInfo ::= SEQUENCE {
86     ss-Code                             SS-Code          OPTIONAL,
87     forwardingFeatureList               ForwardingFeatureList,
88     ...}
89
90 ForwardingFeatureList ::=
91     SEQUENCE SIZE (1..maxNumOfBasicServiceGroups) OF
92         ForwardingFeature
93
94 ForwardingFeature ::= SEQUENCE {
95     basicService                       BasicServiceCode          OPTIONAL,
96     ss-Status [4] SS-Status            OPTIONAL,
97     forwardedToNumber                  [5] ISDN-AddressString    OPTIONAL,
98     forwardedToSubaddress              [8] ISDN-SubaddressString OPTIONAL,
99     forwardingOptions                 [6] ForwardingOptions    OPTIONAL,
100    noReplyConditionTime              [7] NoReplyConditionTime  OPTIONAL,
101    ...}
102

```

```

103 ss-Status ::= OCTET STRING (SIZE (1))
104
105   -- bits 8765: 0000 (unused)
106   -- bits 4321: Used to convey the "P bit", "R bit", "A bit" and "Q bit",
107   --           representing supplementary service state information
108   --           as defined in TS GSM 03.11
109
110   -- bit 4: "Q bit"
111
112   -- bit 3: "P bit"
113
114   -- bit 2: "R bit"
115
116   -- bit 1: "A bit"
117

118 ForwardingOptions ::= OCTET STRING (SIZE (1))
119
120   -- bit 8: notification to forwarding party
121   -- 0 no notification
122   -- 1 notification
123
124   -- bit 7: redirecting presentation
125   -- 0 no presentation
126   -- 1 presentation
127
128   -- bit 6: notification to calling party
129   -- 0 no notification
130   -- 1 notification
131
132   -- bit 5: 0 (unused)
133
134   -- bits 43: forwarding reason
135   -- 00 ms not reachable
136   -- 01 ms busy
137   -- 10 no reply
138   -- 11 unconditional when used in a SRI Result,
139   -- or call deflection when used in a RCH Argument
140   -- bits 21: 00 (unused)
141

142 CallBarringInfo ::= SEQUENCE {
143   ss-Code                               SS-Code                  OPTIONAL,
144   callBarringFeatureList                CallBarringFeatureList,
145   ...
146 }

147 CallBarringFeatureList ::= SEQUENCE SIZE (1..maxNumOfBasicServiceGroups) OF
148   CallBarringFeature
149

150 CallBarringFeature ::= SEQUENCE {
151   basicService                         BasicServiceCode        OPTIONAL,
152   ss-Status [4] SS-Status              OPTIONAL,
153   ...
154 }

155 SS-Data ::= SEQUENCE {
156   ss-Code                               SS-Code                  OPTIONAL,
157   ss-Status [4] SS-Status              OPTIONAL,
158   ss-SubscriptionOption               SS-SubscriptionOption  OPTIONAL,
159   basicServiceGroupList                BasicServiceGroupList  OPTIONAL,
160   ...
161   defaultPriority                     EMLPP-Priority         OPTIONAL
162 }

163 SS-SubscriptionOption ::= CHOICE {
164   cliRestrictionOption               [2] CliRestrictionOption,
165   overrideCategory                  [1] OverrideCategory
166 }

167 CliRestrictionOption ::= ENUMERATED {
168   permanent (0),
169   temporaryDefaultRestricted (1),
170   temporaryDefaultAllowed (2)
171 }

172 OverrideCategory ::= ENUMERATED {
173   overrideEnabled (0),
174   overrideDisabled (1)
175 }

176

```

```

177 SS-ForBS-Code ::= SEQUENCE {
178   ss-Code                               SS-Code,
179   basicService                           BasicServiceCode
180   ...}                                     OPTIONAL,
181
182 GenericServiceInfo ::= SEQUENCE {
183   ss-Status SS-Status,
184   cliRestrictionOption                  CliRestrictionOption
185   ...,
186   maximumEntitledPriority              [ 0 ] EMLPP-Priority
187   defaultPriority                      [ 1 ] EMLPP-Priority
188   ccbs-FeatureList                     [ 2 ] CCBS-FeatureList
189
190 CCBS-FeatureList ::= SEQUENCE SIZE (1..maxNumOfCCBS-Requests) OF
191   CCBS-Feature
192
193 maxNumOfCCBS-Requests INTEGER ::= 5
194
195 CCBS-Feature ::= SEQUENCE {
196   ccbs-Index                            [ 0 ] CCBS-Index
197   b-subscriberNumber                    [ 1 ] ISDN-AddressString
198   b-subscriberSubaddress               [ 2 ] ISDN-SubaddressString
199   basicServiceGroup                    [ 3 ] BasicServiceCode
200   ...}                                     OPTIONAL,
201
202 CCBS-Index ::= INTEGER (1..maxNumOfCCBS-Requests)
203
204 InterrogateSS-Res ::= CHOICE {
205   ss-Status [ 0 ] SS-Status,
206   basicServiceGroupList                [ 2 ] BasicServiceGroupList,
207   forwardingFeatureList               [ 3 ] ForwardingFeatureList,
208   genericServiceInfo                 [ 4 ] GenericServiceInfo }
209
210 USSD-Arg ::= SEQUENCE {
211   ussd-DataCodingScheme             USSD-DataCodingScheme,
212   ussd-String                      USSD-String,
213   ... ,
214   alertingPattern                 AlertingPattern
215   msisdn                          [ 0 ] ISDN-AddressString
216                                         OPTIONAL,
217                                         OPTIONAL }
218
219 USSD-Res ::= SEQUENCE {
220   ussd-DataCodingScheme             USSD-DataCodingScheme,
221   ussd-String                      USSD-String,
222   ...}
223
224 USSD-DataCodingScheme ::= OCTET STRING (SIZE (1))
225   -- The structure of the USSD-DataCodingScheme is defined by
226   -- the Cell Broadcast Data Coding Scheme as described in
227   -- TS GSM 03.38
228
229 USSD-String ::= OCTET STRING (SIZE (1..maxUSSDStringLength))
230   -- The structure of the contents of the USSD-String is dependent
231   -- on the USSD-DataCodingScheme as described in TS GSM 03.38.
232
233 maxUSSDStringLength INTEGER ::= 160
234
235 Password ::= NumericString
236   (FROM ("0"|"1"|"2"|"3"|"4"|"5"|"6"|"7"|"8"|"9"))
237   (SIZE (4))
238
239 GuidanceInfo ::= ENUMERATED {
240   enterPW (0),
241   enterNewPW (1),
242   enterNewPW-Again (2)}
243   -- How this information is really delivered to the subscriber
244   -- (display, announcement, ...) is not part of this
245   -- specification.
246
247 SS-List ::= SEQUENCE SIZE (1..maxNumOfSS) OF
248   SS-Code
249
250 maxNumOfSS INTEGER ::= 30
251
252 SS-InfoList ::= SEQUENCE SIZE (1..maxNumOfSS) OF
253   SS-Info

```

```

253 BasicServiceGroupList ::= SEQUENCE SIZE (1..maxNumberOfBasicServiceGroups) OF
254     BasicServiceCode
255
256 maxNumberOfBasicServiceGroups INTEGER ::= 13
257
258 SS-InvocationNotificationArg ::= SEQUENCE {
259     imsi                               [0] IMSI,
260     msisdn                            [1] ISDN-AddressString,
261     ss-Event                           [2] SS-Code,
262     -- The following SS-Code values are allowed :
263     -- ect                                SS-Code ::= '00110001'B
264     -- multiPTY                          SS-Code ::= '01010001'B
265     -- cd                                 SS-Code ::= '00100100'B
266     ss-EventSpecification               [3] SS-EventSpecification      OPTIONAL,
267     extensionContainer                  [4] ExtensionContainer        OPTIONAL,
268     ...
269 }
270 SS-InvocationNotificationRes ::= SEQUENCE {
271     extensionContainer                  ExtensionContainer        OPTIONAL,
272     ...
273 }
274
275 SS-EventSpecification ::= SEQUENCE SIZE (1..maxEventSpecification) OF
276     AddressString
277
278 maxEventSpecification INTEGER ::= 2
279
280 RegisterCC-EntryArg ::= SEQUENCE {
281     ss-Code                             [0] SS-Code,
282     ccbs-Data [1]                         CCBS-Data OPTIONAL,
283     ...
284 }
285 CCBS-Data ::= SEQUENCE {
286     ccbs-Feature                        [0] CCBS-Feature,
287     translatedB-Number                 [1] ISDN-AddressString,
288     serviceIndicator                   [2] ServiceIndicator      OPTIONAL,
289     callInfo                            [3] ExternalSignalInfo,
290     networkSignalInfo                 [4] ExternalSignalInfo,
291     ...
292 }
293 ServiceIndicator ::= BIT STRING {
294     clir-invoked (0),
295     camel-invoked (1)} (SIZE(2..32))
296     -- exception handling:
297     -- bits 2 to 31 shall be ignored if received and not understood
298
299 RegisterCC-EntryRes ::= SEQUENCE {
300     ccbs-Feature                        [0] CCBS-Feature        OPTIONAL,
301     ...
302 }
303 EraseCC-EntryArg ::= SEQUENCE {
304     ss-Code                             [0] SS-Code,
305     ccbs-Index                          [1] CCBS-Index        OPTIONAL,
306     ...
307 }
308 EraseCC-EntryRes ::= SEQUENCE {
309     ss-Code                             [0] SS-Code,
310     ss-Status [1] SS-Status            OPTIONAL,
311     ...
312 }
313 END

```

17.7.5 Supplementary service codes

```

1 MAP-SS-Code {
2     ccitt identified-organization (4) etsi (0) mobileDomain (0)
3     gsm-Network (1) modules (3) map-SS-Code (15) version5 (5)}
4
5 DEFINITIONS
6
7 ::= BEGIN
8
9
10

```

```

11 ss-Code ::= OCTET STRING (SIZE (1))
12   -- This type is used to represent the code identifying a single
13   -- supplementary service, a group of supplementary services, or
14   -- all supplementary services. The services and abbreviations
15   -- used are defined in TS GSM 02.04. The internal structure is
16   -- defined as follows:
17   --
18   -- bits 87654321: group (bits 8765), and specific service
19   -- (bits 4321)
20
21 allSS                               SS-Code ::= '00000000'B
22   -- reserved for possible future use
23   -- all SS
24
25 allLineIdentificationSS           SS-Code ::= '00010000'B
26   -- reserved for possible future use
27   -- all line identification SS
28 clip                                SS-Code ::= '00010001'B
29   -- calling line identification presentation
30 clir                                SS-Code ::= '00010010'B
31   -- calling line identification restriction
32 colp                                SS-Code ::= '00010011'B
33   -- connected line identification presentation
34 colr                                SS-Code ::= '00010100'B
35   -- connected line identification restriction
36 mci                                 SS-Code ::= '00010101'B
37   -- reserved for possible future use
38   -- malicious call identification
39
40 allNameIdentificationSS           SS-Code ::= '00011000'B
41   -- all name identification SS
42 cnap                                SS-Code ::= '00011001'B
43   -- calling name presentation
44
45   -- SS-Codes '00011010'B to '00011111'B are reserved for future
46   -- NameIdentification Supplementary Service use.
47
48 allForwardingSS                  SS-Code ::= '00100000'B
49   -- all forwarding SS
50 cfu                                 SS-Code ::= '00100001'B
51   -- call forwarding unconditional
52 allCondForwardingSS             SS-Code ::= '00101000'B
53   -- all conditional forwarding SS
54 cfb                                 SS-Code ::= '00101001'B
55   -- call forwarding on mobile subscriber busy
56 cfnry                                SS-Code ::= '00101010'B
57   -- call forwarding on no reply
58 cfnrc                                SS-Code ::= '00101011'B
59   -- call forwarding on mobile subscriber not reachable
60 cd                                 SS-Code ::= '00100100'B
61   -- call deflection
62
63 allCallOfferingsSS                SS-Code ::= '00110000'B
64   -- reserved for possible future use
65   -- all call offering SS includes also all forwarding SS
66 ect                                 SS-Code ::= '00110001'B
67   -- explicit call transfer
68 mah                                 SS-Code ::= '00110010'B
69   -- reserved for possible future use
70   -- mobile access hunting
71
72 allCallCompletionSS              SS-Code ::= '01000000'B
73   -- reserved for possible future use
74   -- all Call completion SS
75 cw                                  SS-Code ::= '01000001'B
76   -- call waiting
77 hold                                SS-Code ::= '01000010'B
78   -- call hold
79 ccbs-A                                SS-Code ::= '01000011'B
80   -- completion of call to busy subscribers, originating side
81 ccbs-B                                SS-Code ::= '01000100'B
82   -- completion of call to busy subscribers, destination side
83   -- this SS-Code is used only in InsertSubscriberData and DeleteSubscriberData
84

```

```

85 allMultiPartySS SS-Code ::= '01010000'B
86   -- reserved for possible future use
87   -- all multiparty SS
88 multiparty SS-Code ::= '01010001'B
89   -- multiparty
90
91 allCommunityOfInterest-ss SS-Code ::= '01100000'B
92   -- reserved for possible future use
93   -- all community of interest SS
94 cug SS-Code ::= '01100001'B
95   -- closed user group
96
97 allChargingSS SS-Code ::= '01110000'B
98   -- reserved for possible future use
99   -- all charging SS
100 aoci SS-Code ::= '01110001'B
101   -- advice of charge information
102 aocc SS-Code ::= '01110010'B
103   -- advice of charge charging
104
105 allAdditionalInfoTransferSS SS-Code ::= '10000000'B
106   -- reserved for possible future use
107   -- all additional information transfer SS
108 uus1 SS-Code ::= '10000001'B
109   -- UUS1 user-to-user signalling
110 uus2 SS-Code ::= '10000010'B
111   -- UUS2 user-to-user signalling
112 uus3 SS-Code ::= '10000011'B
113   -- UUS3 user-to-user signalling
114
115 allBarringSS SS-Code ::= '10010000'B
116   -- all barring SS
117 barringOfOutgoingCalls SS-Code ::= '10010001'B
118   -- barring of outgoing calls
119 baoc SS-Code ::= '10010010'B
120   -- barring of all outgoing calls
121 boic SS-Code ::= '10010011'B
122   -- barring of outgoing international calls
123 boicExHC SS-Code ::= '10010100'B
124   -- barring of outgoing international calls except those directed
125   -- to the home PLMN
126 barringOfIncomingCalls SS-Code ::= '10011001'B
127   -- barring of incoming calls
128 baic SS-Code ::= '10011010'B
129   -- barring of all incoming calls
130 bicRoam SS-Code ::= '10011011'B
131   -- barring of incoming calls when roaming outside home PLMN
132   -- Country
133
134 allPLMN-specificSS SS-Code ::= '11110000'B
135 plmn-specificSS-1 SS-Code ::= '11110001'B
136 plmn-specificSS-2 SS-Code ::= '11110010'B
137 plmn-specificSS-3 SS-Code ::= '11110011'B
138 plmn-specificSS-4 SS-Code ::= '11110100'B
139 plmn-specificSS-5 SS-Code ::= '11110101'B
140 plmn-specificSS-6 SS-Code ::= '11110110'B
141 plmn-specificSS-7 SS-Code ::= '11110111'B
142 plmn-specificSS-8 SS-Code ::= '11111000'B
143 plmn-specificSS-9 SS-Code ::= '11111001'B
144 plmn-specificSS-A SS-Code ::= '11111010'B
145 plmn-specificSS-B SS-Code ::= '11111011'B
146 plmn-specificSS-C SS-Code ::= '11111100'B
147 plmn-specificSS-D SS-Code ::= '11111101'B
148 plmn-specificSS-E SS-Code ::= '11111110'B
149 plmn-specificSS-F SS-Code ::= '11111111'B
150
151 allCallPrioritySS SS-Code ::= '10100000'B
152   -- reserved for possible future use
153   -- all call priority SS
154 eMLPP SS-Code ::= '10100001'B
155   -- enhanced Multilevel Pre-emption (EMLPP) service
156

```

```

157 allLCSPrivacyException SS-Code ::= '10110000'B
158   -- all LCS Privacy Exception Classes
159 universal SS-Code ::= '10110001'B
160   -- allow location by any LCS client
161 callrelated SS-Code ::= '10110010'B
162   -- allow location by any value added LCS client to which a call
163   -- is established from the target MS
164 callunrelated SS-Code ::= '10110011'B
165   -- allow location by designated external value added LCS clients
166 plmnoperator SS-Code ::= '10110100'B
167   -- allow location by designated PLMN operator LCS clients
168
169
170 allMOLR-SS SS-Code ::= '11000000'B
171   -- all Mobile Originating Location Request Classes
172 basicSelfLocation SS-Code ::= '11000001'B
173   -- allow an MS to request its own location
174 autonomousSelfLocation SS-Code ::= '11000010'B
175   -- allow an MS to perform self location without interaction
176   -- with the PLMN for a predetermined period of time
177 transferToThirdParty SS-Code ::= '11000011'B
178   -- allow an MS to request transfer of its location to another LCS client
179
180 END

```

17.7.6 Short message data types

```

1 MAP-SM-DataTypes {
2   ccitt identified-organization (4) etsi (0) mobileDomain (0)
3   gsm-Network (1) modules (3) map-SM-DataTypes (16) version5 (5)
4
5 DEFINITIONS
6
7 IMPLICIT TAGS
8
9 ::=:
10
11 BEGIN
12
13 EXPORTS
14   RoutingInfoForSM-Arg,
15   RoutingInfoForSM-Res,
16   MO-ForwardSM-Arg,
17   MO-ForwardSM-Res,
18   MT-ForwardSM-Arg,
19   MT-ForwardSM-Res,
20   ReportSM-DeliveryStatusArg,
21   ReportSM-DeliveryStatusRes,
22   AlertServiceCentreArg,
23   InformServiceCentreArg,
24   ReadyForSM-Arg,
25   ReadyForSM-Res,
26   SM-DeliveryOutcome,
27   AlertReason
28 ;
29
30 IMPORTS
31   AddressString,
32   ISDN-AddressString,
33   SignalInfo,
34   IMSI,
35   LMSI
36 FROM MAP-CommonDataTypes {
37   ccitt identified-organization (4) etsi (0) mobileDomain (0)
38   gsm-Network (1) modules (3) map-CommonDataTypes (18) version5 (5)}
39
40 AbsentSubscriberDiagnosticSM
41 FROM MAP-ER-DataTypes {
42   ccitt identified-organization (4) etsi (0) mobileDomain (0)
43   gsm-Network (1) modules (3) map-ER-DataTypes (17) version5 (5)}
44
45 ExtensionContainer
46 FROM MAP-ExtensionDataTypes {
47   ccitt identified-organization (4) etsi (0) mobileDomain (0)
48   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version5 (5)}
49 ;
50
51

```

```

52 RoutingInfoForSM-Arg ::= SEQUENCE {
53   msisdn                               [0] ISDN-AddressString,
54   sm-RP-PRI [1] BOOLEAN,
55   serviceCentreAddress                 [2] AddressString,
56   extensionContainer                  [6] ExtensionContainer
57   OPTIONAL,
58   ... ,
59   gprsSupportIndicator                [7] NULL
60   -- gprsSupportIndicator is set only if the SMS-GMSC supports
61   -- receiving of two numbers from the HLR
62   sm-RP-MTI [8] SM-RP-MTI
63   OPTIONAL,
64   sm-RP-SMEA [9] SM-RP-SMEA
65   OPTIONAL }

66 SM-RP-MTI ::= INTEGER (0..10)
67   -- 0 SMS Deliver
68   -- 1 SMS Status Report
69   -- other values are reserved for future use and shall be discarded if
70   -- received

71 SM-RP-SMEA ::= OCTET STRING (SIZE (1..12))
72   -- this parameter contains an address field which is encoded
73   -- as defined in GSM 03.40. An address field contains 3 elements :
74   --   address-length
75   --   type-of-address
76   --   address-value

77 RoutingInfoForSM-Res ::= SEQUENCE {
78   imsi                                IMSI,
79   locationInfoWithLMSI                 [0] LocationInfoWithLMSI,
80   extensionContainer                  [4] ExtensionContainer
81   OPTIONAL,
82   ... }

83 LocationInfoWithLMSI ::= SEQUENCE {
84   networkNode-Number                 [1] ISDN-AddressString,
85   lmsi                                LMSI
86   OPTIONAL,
87   extensionContainer                  ExtensionContainer
88   OPTIONAL,
89   ... ,
90   gprsNodeIndicator                  [5] NULL
91   -- gprsNodeIndicator is set only if the SGSN number is sent as the
92   -- Network Node Number
93   additional-Number                  [6] Additional-Number
94   -- NetworkNode-number can be either msc-number or sgsn-number
95   }

96 Additional-Number ::= CHOICE {
97   msc-Number                          [0] ISDN-AddressString,
98   sgsn-Number                         [1] ISDN-AddressString}
99   -- additional-number can be either msc-number or sgsn-number
100  -- if received networkNode-number is msc-number then the
101  -- additional number is sgsn-number
102  -- if received networkNode-number is sgsn-number then the
103  -- additional number is msc-number
104  }

105 MO-ForwardSM-Arg ::= SEQUENCE {
106   sm-RP-DA                            SM-RP-DA,
107   sm-RP-OA                            SM-RP-OA,
108   sm-RP-UI                            SignalInfo,
109   extensionContainer                  ExtensionContainer
110   OPTIONAL,
111   ... ,
112   imsi                                IMSI
113   OPTIONAL }

114 MO-ForwardSM-Res ::= SEQUENCE {
115   sm-RP-UI                            SignalInfo
116   extensionContainer                  ExtensionContainer
117   OPTIONAL,
118   ... }

119 MT-ForwardSM-Arg ::= SEQUENCE {
120   sm-RP-DA                            SM-RP-DA,
121   sm-RP-OA                            SM-RP-OA,
122   sm-RP-UI                            SignalInfo,
123   moreMessagesToSend                 NULL
124   extensionContainer                  ExtensionContainer
125   OPTIONAL,
126   ... }

```

```

127 MT-ForwardSM-Res ::= SEQUENCE {
128   sm-RP-UI                               SignalInfo           OPTIONAL,
129   extensionContainer                     ExtensionContainer  OPTIONAL,
130   ...
131 }
132
132 SM-RP-DA ::= CHOICE {
133   imsI                                [0] IMSI,
134   lmsI                                [1] LMSI,
135   serviceCentreAddressDA               [4] AddressString,
136   noSM-RP-DA                           [5] NULL}
137
138 SM-RP-OA ::= CHOICE {
139   msisdn                             [2] ISDN-AddressString,
140   serviceCentreAddressOA              [4] AddressString,
141   noSM-RP-OA                           [5] NULL}
142
143 ReportSM-DeliveryStatusArg ::= SEQUENCE {
144   msisdn                            ISDN-AddressString,
145   serviceCentreAddress             AddressString,
146   sm-DeliveryOutcome              SM-DeliveryOutcome,
147   absentSubscriberDiagnosticSM    [0] AbsentSubscriberDiagnosticSM
148                                         OPTIONAL,
149   extensionContainer                [1] ExtensionContainer
150                                         OPTIONAL,
151   ...
151   gprsSupportIndicator            [2] NULL
152   -- gprsSupportIndicator is set only if the SMS-GMSC supports
153   -- handling of two delivery outcomes
154   deliveryOutcomeIndicator        [3] NULL
155   -- DeliveryOutcomeIndicator is set when the SM-DeliveryOutcome
156   -- is for GPRS
157   additionalSM-DeliveryOutcome    [4] SM-DeliveryOutcome
158   -- If received, additionalSM-DeliveryOutcome is for GPRS
159   -- If DeliveryOutcomeIndicator is set, then AdditionalSM-DeliveryOutcome shall be absent
160   additionalAbsentSubscriberDiagnosticSM [5] AbsentSubscriberDiagnosticSM
161   -- If received additionalAbsentSubscriberDiagnosticSM is for GPRS
162   -- If DeliveryOutcomeIndicator is set, then AdditionalAbsentSubscriberDiagnosticSM
163   -- shall be absent
164 }
165
166 SM-DeliveryOutcome ::= ENUMERATED {
167   memoryCapacityExceeded (0),
168   absentSubscriber (1),
169   successfulTransfer (2)}
170
171 ReportSM-DeliveryStatusRes ::= SEQUENCE {
172   storedMSISDN                         ISDN-AddressString
173   extensionContainer                   ExtensionContainer
174   ...
175 }
176
177 AlertServiceCentreArg ::= SEQUENCE {
178   msisdn                            ISDN-AddressString,
179   serviceCentreAddress             AddressString,
180   ...
181 }
182 InformServiceCentreArg ::= SEQUENCE {
183   storedMSISDN                         ISDN-AddressString
184   mw-Status MW-Status
185   extensionContainer                   ExtensionContainer
186   ...
187 }
188 MW-Status ::= BIT STRING {
189   sc-AddressNotIncluded (0),
190   mnrf-Set (1),
191   mcef-Set (2),
192   mnrg-Set (3) } (SIZE (6..16))
193   -- exception handling:
194   -- bits 4 to 15 shall be ignored if received and not understood
195

```

```

196 ReadyForSM-Arg ::= SEQUENCE {
197   imsi                               [ 0 ] IMSI,
198   alertReason                         AlertReason,
199   alertReasonIndicator                NULL
200   -- alertReasonIndicator is set only when the alertReason
201   -- sent to HLR is for GPRS
202   extensionContainer                  ExtensionContainer
203   ...
204 }
205 ReadyForSM-Res ::= SEQUENCE {
206   extensionContainer                  ExtensionContainer
207   ...
208 }
209
210 AlertReason ::= ENUMERATED {
211   ms-Present    (0),
212   memoryAvailable (1)
213 }
214 END

```

17.7.7 Error data types

```

1 MAP-ER-DataTypes {
2   ccitt identified-organization (4) etsi (0) mobileDomain (0)
3   gsm-Network (1) modules (3) map-ER-DataTypes (17) version5 (5)
4
5 DEFINITIONS
6
7 IMPLICIT TAGS
8
9 ::= :
10
11 BEGIN
12
13 EXPORTS
14   RoamingNotAllowedParam,
15   CallBarredParam,
16   CUG-RejectParam,
17   SS-IncompatibilityCause,
18   PW-RegistrationFailureCause,
19   SM-DeliveryFailureCause,
20   SystemFailureParam,
21   DataMissingParam,
22   UnexpectedDataParam,
23   FacilityNotSupParam,
24   OR-NotAllowedParam,
25   UnknownSubscriberParam,
26   NumberChangedParam,
27   UnidentifiedSubParam,
28   IllegalSubscriberParam,
29   IllegalEquipmentParam,
30   BearerServNotProvParam,
31   TeleservNotProvParam,
32   TracingBufferFullParam,
33   NoRoamingNbParam,
34   AbsentSubscriberParam,
35   BusySubscriberParam,
36   NoSubscriberReplyParam,
37   ForwardingViolationParam,
38   ForwardingFailedParam,
39   ATI-NotAllowedParam,
40   SubBusyForMT-SMS-Param,
41   MessageWaitListFullParam,
42   AbsentSubscriberSM-Param,
43   AbsentSubscriberDiagnosticSM,
44   ResourceLimitationParam,
45   NoGroupCallNbParam,
46   IncompatibleTerminalParam,
47   ShortTermDenialParam,
48   LongTermDenialParam,
49   UnauthorizedRequestingNetwork-Param,
50   UnauthorizedLCSClient-Param,
51   PositionMethodFailure-Param,
52   UnknownOrUnreachableLCSClient-Param
53
54 ;
55
56

```

```

57 IMPORTS
58   SS-Status
59 FROM MAP-SS-DataTypes {
60   ccitt identified-organization (4) etsi (0) mobileDomain (0)
61   gsm-Network (1) modules (3) map-SS-DataTypes (14) version5 (5)}
62
63   SignalInfo,
64   BasicServiceCode,
65   NetworkResource
66 FROM MAP-CommonDataTypes {
67   ccitt identified-organization (4) etsi (0) mobileDomain (0)
68   gsm-Network (1) modules (3) map-CommonDataTypes (18) version5 (5)}
69
70   SS-Code
71 FROM MAP-SS-Code {
72   ccitt identified-organization (4) etsi (0) mobileDomain (0)
73   gsm-Network (1) modules (3) map-SS-Code (15) version5 (5)}
74
75   ExtensionContainer
76 FROM MAP-ExtensionDataTypes {
77   ccitt identified-organization (4) etsi (0) mobileDomain (0)
78   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version5 (5)}
79 ;
80
81 RoamingNotAllowedParam ::= SEQUENCE {
82   roamingNotAllowedCause           RoamingNotAllowedCause,
83   extensionContainer               ExtensionContainer
84   ...
85 }
86
86 RoamingNotAllowedCause ::= ENUMERATED {
87   plmnRoamingNotAllowed (0),
88   operatorDeterminedBarring (3)}
89
90 CallBarredParam ::= CHOICE {
91   callBarringCause                CallBarringCause,
92   -- call BarringCause must not be used in version 3
93   extensibleCallBarredParam       ExtensibleCallBarredParam
94   -- extensibleCallBarredParam must not be used in version <3
95 }
96
97 CallBarringCause ::= ENUMERATED {
98   barringServiceActive (0),
99   operatorBarring (1)}
100
101 ExtensibleCallBarredParam ::= SEQUENCE {
102   callBarringCause                CallBarringCause
103   extensionContainer              ExtensionContainer
104   ...
105   unauthorisedMessageOriginator [1] NULL
106 }
107
107 CUG-RejectParam ::= SEQUENCE {
108   cug-RejectCause                CUG-RejectCause
109   extensionContainer              ExtensionContainer
110   ...
111 }
112
112 CUG-RejectCause ::= ENUMERATED {
113   incomingCallsBarredWithinCUG (0),
114   subscriberNotMemberOfCUG (1),
115   requestedBasicServiceViolatesCUG-Constraints (5),
116   calledPartySS-InteractionViolation (7)}
117
118 SS-IncompatibilityCause ::= SEQUENCE {
119   ss-Code                         [1] SS-Code
120   basicService                    BasicServiceCode
121   ss-Status [4] SS-Status
122   ...
123 }
124
124 PW-RegistrationFailureCause ::= ENUMERATED {
125   undetermined (0),
126   invalidFormat (1),
127   newPasswordsMismatch (2)}
128
129

```

```

130 SM-EnumeratedDeliveryFailureCause ::= ENUMERATED {
131   memoryCapacityExceeded (0),
132   equipmentProtocolError (1),
133   equipmentNotSM-Equipped (2),
134   unknownServiceCentre (3),
135   sc-Congestion (4),
136   invalidSME-Address (5),
137   subscriberNotSC-Subscriber (6)}
138
139 SM-DeliveryFailureCause ::= SEQUENCE {
140   sm-EnumeratedDeliveryFailureCause    SM-EnumeratedDeliveryFailureCause,
141   diagnosticInfo                      SignalInfo                  OPTIONAL,
142   extensionContainer                   ExtensionContainer          OPTIONAL,
143   ...}
144
145 AbsentSubscriberSM-Param ::= SEQUENCE {
146   absentSubscriberDiagnosticSM        AbsentSubscriberDiagnosticSM      OPTIONAL,
147   -- AbsentSubscriberDiagnosticSM can be either for non-GPRS
148   -- or for GPRS
149   extensionContainer                 ExtensionContainer            OPTIONAL,
150   ...,
151   additionalAbsentSubscriberDiagnosticSM [0] AbsentSubscriberDiagnosticSM OPTIONAL }
152   -- if received, additionalAbsentSubscriberDiagnosticSM
153   -- is for GPRS and absentSubscriberDiagnosticSM is
154   -- for non-GPRS
155
156 AbsentSubscriberDiagnosticSM ::= INTEGER (0..255)
157   -- AbsentSubscriberDiagnosticSM values are defined in ETS 300 536 (GSM 03.40)
158
159 SystemFailureParam ::= CHOICE {
160   networkResource                    NetworkResource,
161   -- networkResource must not be used in version 3
162   extensibleSystemFailureParam     ExtensibleSystemFailureParam
163   -- extensibleSystemFailureParam must not be used in version <3
164 }
165
166 ExtensibleSystemFailureParam ::= SEQUENCE {
167   networkResource                  NetworkResource      OPTIONAL,
168   extensionContainer               ExtensionContainer  OPTIONAL,
169   ...}
170
171 DataMissingParam ::= SEQUENCE {
172   extensionContainer               ExtensionContainer  OPTIONAL,
173   ...}
174
175 UnexpectedDataParam ::= SEQUENCE {
176   extensionContainer               ExtensionContainer  OPTIONAL,
177   ...}
178
179 FacilityNotSupParam ::= SEQUENCE {
180   extensionContainer               ExtensionContainer  OPTIONAL,
181   ...}
182
183 OR-NotAllowedParam ::= SEQUENCE {
184   extensionContainer               ExtensionContainer  OPTIONAL,
185   ...}
186
187 UnknownSubscriberParam ::= SEQUENCE {
188   extensionContainer               ExtensionContainer  OPTIONAL,
189   ...,
190   unknownSubscriberDiagnostic     UnknownSubscriberDiagnostic OPTIONAL}
191
192 UnknownSubscriberDiagnostic ::= ENUMERATED {
193   imsiUnknown (0),
194   gprsSubscriptionUnknown (1),
195   ...}
196   -- if unknown values are received in
197   -- unknownSubscriberDiagnostic they shall be discarded
198
199
200 NumberChangedParam ::= SEQUENCE {
201   extensionContainer               ExtensionContainer  OPTIONAL,
202   ...}
203

```

```

204 UnidentifiedSubParam ::= SEQUENCE {
205   extensionContainer           ExtensionContainer      OPTIONAL,
206   ...
207 }
208 IllegalSubscriberParam ::= SEQUENCE {
209   extensionContainer           ExtensionContainer      OPTIONAL,
210   ...
211 }
212 IllegalEquipmentParam ::= SEQUENCE {
213   extensionContainer           ExtensionContainer      OPTIONAL,
214   ...
215 }
216 BearerServNotProvParam ::= SEQUENCE {
217   extensionContainer           ExtensionContainer      OPTIONAL,
218   ...
219 }
220 TeleservNotProvParam ::= SEQUENCE {
221   extensionContainer           ExtensionContainer      OPTIONAL,
222   ...
223 }
224 TracingBufferFullParam ::= SEQUENCE {
225   extensionContainer           ExtensionContainer      OPTIONAL,
226   ...
227 }
228 NoRoamingNbParam ::= SEQUENCE {
229   extensionContainer           ExtensionContainer      OPTIONAL,
230   ...
231 }
232 AbsentSubscriberParam ::= SEQUENCE {
233   extensionContainer           ExtensionContainer      OPTIONAL,
234   ...
235   absentSubscriberReason      [0] AbsentSubscriberReason OPTIONAL}
236
237 AbsentSubscriberReason ::= ENUMERATED {
238   imsidiDetach (0),
239   restrictedArea (1),
240   noPageResponse (2),
241   ...
242   -- exception handling: at reception of other values than the ones listed the
243   -- AbsentSubscriberReason shall be ignored.
244 }
245 BusySubscriberParam ::= SEQUENCE {
246   extensionContainer           ExtensionContainer      OPTIONAL,
247   ...
248   ccbs-Possible               [0] NULL             OPTIONAL,
249   ccbs-Busy [1] NULL          OPTIONAL}
250
251 NoSubscriberReplyParam ::= SEQUENCE {
252   extensionContainer           ExtensionContainer      OPTIONAL,
253   ...
254 }
255 ForwardingViolationParam ::= SEQUENCE {
256   extensionContainer           ExtensionContainer      OPTIONAL,
257   ...
258 }
259 ForwardingFailedParam ::= SEQUENCE {
260   extensionContainer           ExtensionContainer      OPTIONAL,
261   ...
262 }
263 ATI-NotAllowedParam ::= SEQUENCE {
264   extensionContainer           ExtensionContainer      OPTIONAL,
265   ...
266 }
267 SubBusyForMT-SMS-Param ::= SEQUENCE {
268   extensionContainer           ExtensionContainer      OPTIONAL,
269   ...
270   gprsConnectionSuspended     NULL      OPTIONAL }
271   -- If GprsConnectionSuspended is not understood it shall
272   -- be discarded
273
274 MessageWaitListFullParam ::= SEQUENCE {
275   extensionContainer           ExtensionContainer      OPTIONAL,
276   ...
277 }

```

```

278 ResourceLimitationParam ::= SEQUENCE {
279   extensionContainer           ExtensionContainer      OPTIONAL,
280   ...
281 }
282 NoGroupCallNbParam ::= SEQUENCE {
283   extensionContainer           ExtensionContainer      OPTIONAL,
284   ...
285 }
286 IncompatibleTerminalParam ::= SEQUENCE {
287   extensionContainer           ExtensionContainer      OPTIONAL,
288   ...
289 }
290 ShortTermDenialParam ::= SEQUENCE {
291   ...
292 }
293 LongTermDenialParam ::= SEQUENCE {
294   ...
295 }
296 UnauthorizedRequestingNetwork-Param ::= SEQUENCE {
297   extensionContainer           ExtensionContainer      OPTIONAL,
298   ...
299 }
300 UnauthorizedLCSCClient-Param ::= SEQUENCE {
301   unauthorizedLCSCClient-Diagnostic [0] UnauthorizedLCSCClient-Diagnostic  OPTIONAL,
302   extensionContainer           [1] ExtensionContainer      OPTIONAL,
303   ...
304 }
305 UnauthorizedLCSCClient-Diagnostic ::= ENUMERATED {
306   noAdditionalInformation (0),
307   clientNotInMSPrivacyExceptionList (1),
308   callToClientNotSetup (2),
309   privacyOverrideNotApplicable (3),
310   disallowedByLocalRegulatoryRequirements (4),
311   ...
312 -- exception handling:
313 -- any unrecognized value shall be ignored
314 }
315 PositionMethodFailure-Param ::= SEQUENCE {
316   positionMethodFailure-Diagnostic [0] PositionMethodFailure-Diagnostic  OPTIONAL,
317   extensionContainer           [1] ExtensionContainer      OPTIONAL,
318   ...
319 }
320 PositionMethodFailure-Diagnostic ::= ENUMERATED {
321   congestion (0),
322   insufficientResources (1),
323   insufficientMeasurementData (2),
324   inconsistentMeasurementData (3),
325   locationProcedureNotCompleted (4),
326   locationProcedureNotSupportedByTargetMS (5),
327   qosNotAttainable (6),
328   positionMethodNotAvailableInNetwork (7),
329   positionMethodNotAvailableInLocationArea (8),
330   ...
331 -- exception handling:
332 -- any unrecognized value shall be ignored
333 }
334 UnknownOrUnreachableLCSCClient-Param ::= SEQUENCE {
335   extensionContainer           ExtensionContainer      OPTIONAL,
336   ...
337 }
338
339 END

```

17.7.8 Common data types

```

1 MAP-CommonDataTypes {
2   ccitt identified-organization (4) etsi (0) mobileDomain (0)
3   gsm-Network (1) modules (3) map-CommonDataTypes (18) version5 (5)
4
5 DEFINITIONS
6
7 IMPLICIT TAGS
8
9 ::= :
10
11 BEGIN
12

```

```

13 EXPORTS
14
15   -- general data types and values
16   AddressString,
17   ISDN-AddressString,
18   maxISDN-AddressLength,
19   ISDN-SubaddressString,
20   ExternalSignalInfo,
21   Ext-ExternalSignalInfo,
22   SignalInfo,
23   maxSignalInfoLength,
24   AlertingPattern,
25
26   -- data types for numbering and identification
27   IMSI,
28   TMSI,
29   Identity,
30   SubscriberId,
31   IMEI,
32   HLR-List,
33   LMSI,
34   GlobalCellId,
35   NetworkResource,
36   NAEA-PreferredCI,
37   NAEA-CIC,
38   ASCI-CallReference,
39   SubscriberIdentity,
40
41   -- data types for CAMEL
42   CellIdOrLAI,
43
44   -- data types for subscriber management
45   BasicServiceCode,
46   Ext-BasicServiceCode,
47   EMLPP-Info,
48   EMLPP-Priority,
49
50   -- data types for geographic location
51   AgeOfLocationInformation,
52   LCSClientExternalID,
53   LCSClientInternalID
54 ;
55
56 IMPORTS
57   TeleserviceCode,
58   Ext-TeleserviceCode
59 FROM MAP-TS-Code {
60   ccitt identified-organization (4) etsi (0) mobileDomain (0)
61   gsm-Network (1) modules (3) map-TS-Code (19) version5 (5)}
62
63   BearerServiceCode,
64   Ext-BearerServiceCode
65 FROM MAP-BS-Code {
66   ccitt identified-organization (4) etsi (0) mobileDomain (0)
67   gsm-Network (1) modules (3) map-BS-Code (20) version5 (5)}
68
69   ExtensionContainer
70 FROM MAP-ExtensionDataTypes {
71   ccitt identified-organization (4) etsi (0) mobileDomain (0)
72   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version5 (5)}
73 ;
74
75
76   -- general data types
77
78 TBCD-STRING ::= OCTET STRING
79   -- This type (Telephony Binary Coded Decimal String) is used to
80   -- represent several digits from 0 through 9, *, #, a, b, c, two
81   -- digits per octet, each digit encoded 0000 to 1001 (0 to 9),
82   -- 1010 (*), 1011 (#), 1100 (a), 1101 (b) or 1110 (c); 1111 used
83   -- as filler when there is an odd number of digits.
84
85   -- bits 8765 of octet n encoding digit 2n
86   -- bits 4321 of octet n encoding digit 2(n-1) +1
87

```

```

88 AddressString ::= OCTET STRING (SIZE (1..maxAddressLength))
89   -- This type is used to represent a number for addressing
90   -- purposes. It is composed of
91   --   a) one octet for nature of address, and numbering plan
92   --      indicator.
93   --   b) digits of an address encoded as TBCD-String.
94
95   -- a) The first octet includes a one bit extension indicator, a
96   --      3 bits nature of address indicator and a 4 bits numbering
97   --      plan indicator, encoded as follows:
98
99   -- bit 8: 1 (no extension)
100
101   -- bits 765: nature of address indicator
102   -- 000 unknown
103   -- 001 international number
104   -- 010 national significant number
105   -- 011 network specific number
106   -- 100 subscriber number
107   -- 101 reserved
108   -- 110 abbreviated number
109   -- 111 reserved for extension
110
111   -- bits 4321: numbering plan indicator
112   -- 0000 unknown
113   -- 0001 ISDN/Telephony Numbering Plan (Rec CCITT E.164)
114   -- 0010 spare
115   -- 0011 data numbering plan (CCITT Rec X.121)
116   -- 0100 telex numbering plan (CCITT Rec F.69)
117   -- 0101 spare
118   -- 0110 land mobile numbering plan (CCITT Rec E.212)
119   -- 0111 spare
120   -- 1000 national numbering plan
121   -- 1001 private numbering plan
122   -- 1111 reserved for extension
123
124   -- all other values are reserved.
125
126   -- b) The following octets representing digits of an address
127   --      encoded as a TBCD-STRING.
128
129 maxAddressLength INTEGER ::= 20
130
131 ISDN-AddressString ::= AddressString (SIZE (1..maxISDN-AddressLength))
132   -- This type is used to represent ISDN numbers.
133
134
135 maxISDN-AddressLength INTEGER ::= 9
136

```

```

137 ISDN-SubaddressString ::= OCTET STRING (SIZE (1..maxISDN-SubaddressLength))
138   -- This type is used to represent ISDN subaddresses.
139   -- It is composed of
140   --   a) one octet for type of subaddress and odd/even indicator.
141   --   b) 20 octets for subaddress information.
142
143   --   a) The first octet includes a one bit extension indicator, a
144   --      3 bits type of subaddress and a one bit odd/even indicator,
145   --      encoded as follows:
146
147   --     bit 8: 1 (no extension)
148
149   --     bits 765: type of subaddress
150   --       000 NSAP (X.213/ISO 8348 AD2)
151   --       010 User Specified
152   --       All other values are reserved
153
154   --     bit 4: odd/even indicator
155   --       0 even number of address signals
156   --       1 odd number of address signals
157   --       The odd/even indicator is used when the type of subaddress
158   --       is "user specified" and the coding is BCD.
159
160   --     bits 321: 000 (unused)
161
162   --   b) Subaddress information.
163   --   The NSAP X.213/ISO8348AD2 address shall be formatted as specified
164   --   by octet 4 which contains the Authority and Format Identifier
165   --   (AFI). The encoding is made according to the "preferred binary
166   --   encoding" as defined in X.213/ISO834AD2. For the definition
167   --   of this type of subaddress, see CCITT Rec I.334.
168
169   --   For User-specific subaddress, this field is encoded according
170   --   to the user specification, subject to a maximum length of 20
171   --   octets. When interworking with X.25 networks BCD coding should
172   --   be applied.
173
174
175 maxISDN-SubaddressLength INTEGER ::= 21
176
177 ExternalSignalInfo ::= SEQUENCE {
178   protocolId                               ProtocolId,
179   signalInfo                                SignalInfo,
180   -- Information about the internal structure is given in
181   -- subclause 7.6.9.
182   extensionContainer                         ExtensionContainer
183   -- extensionContainer must not be used in version 2
184   ...
185
186 SignalInfo ::= OCTET STRING (SIZE (1..maxSignalInfoLength))
187
188 maxSignalInfoLength INTEGER ::= 200
189   -- This NamedValue represents the theoretical maximum number of
190   -- octets which are available to carry a single data type,
191   -- without requiring segmentation to cope with the network layer
192   -- service. However, the actual maximum size available for a data
193   -- type may be lower, especially when other information elements
194   -- have to be included in the same component.
195
196 ProtocolId ::= ENUMERATED {
197   gsm-0408 (1),
198   gsm-0806 (2),
199   gsm-BSSMAP (3),
200   -- Value 3 is reserved and must not be used
201   ets-300102-1 (4)}
202
203 Ext-ExternalSignalInfo ::= SEQUENCE {
204   ext-ProtocolId                            Ext-ProtocolId,
205   signalInfo                                SignalInfo,
206   -- Information about the internal structure is given in
207   -- subclause 7.6.9.10
208   extensionContainer                         ExtensionContainer
209   ...
210

```

```

211 Ext-ProtocolId ::= ENUMERATED {
212   ets-300356 (1),
213   ...
214 }
215 -- exception handling:
216 -- For Ext-ExternalSignalInfo sequences containing this parameter with any
217 -- other value than the ones listed the receiver shall ignore the whole
218 -- Ext-ExternalSignalInfo sequence.
219

```

```

220 AlertingPattern ::= OCTET STRING (SIZE (1) )
221   -- This type is used to represent Alerting Pattern
222
223   -- bits 8765 : 0000 (unused)
224
225   -- bits 43 : type of Pattern
226   -- 00 level
227   -- 01 category
228   -- 10 category
229   -- all other values are reserved.
230
231   -- bits 21 : type of alerting
232
233 alertingLevel-0 AlertingPattern ::= '00000000'B
234 alertingLevel-1 AlertingPattern ::= '00000001'B
235 alertingLevel-2 AlertingPattern ::= '00000010'B
236   -- all other values of Alerting level are reserved
237   -- Alerting Levels are defined in GSM 02.07
238
239 alertingCategory-1 AlertingPattern ::= '00000100'B
240 alertingCategory-2 AlertingPattern ::= '00000101'B
241 alertingCategory-3 AlertingPattern ::= '00000110'B
242 alertingCategory-4 AlertingPattern ::= '00000111'B
243 alertingCategory-5 AlertingPattern ::= '00001000'B
244   -- all other values of Alerting Category are reserved
245   -- Alerting categories are defined in GSM 02.07
246

```

```

247 -- data types for numbering and identification
248
249

```

```

250 IMSI ::= TBCD-STRING (SIZE (3..8))
251   -- digits of MCC, MNC, MSIN are concatenated in this order.
252

```

```

253 Identity ::= CHOICE {
254   imsi                               IMSI,
255   imsi-WithLMSI                      IMSI-WithLMSI}
256

```

```

257 IMSI-WithLMSI ::= SEQUENCE {
258   imsi                               IMSI,
259   lmsi                               LMSI,
260   -- a special value 00000000 indicates that the LMSI is not in use
261   ...}
262

```

```

263 ASCI-CallReference ::= TBCD-STRING (SIZE (1..8))
264   -- digits of VGCS/VBC-area,Group-ID are concatenated in this order.
265
266

```

```

267 TMSI ::= OCTET STRING (SIZE (1..4))
268

```

```

269 SubscriberId ::= CHOICE {
270   imsi                               [0] IMSI,
271   tmsi                               [1] TMSI}
272

```

```

273 IMEI ::= TBCD-STRING (SIZE (8))
274   -- Refers to International Mobile Station Equipment Identity
275   -- and Software Version Number (SVN) defined in TS GSM 03.03.
276   -- If the SVN is not present the last octet shall contain the
277   -- digit 0 and a filler.
278   -- If present the SVN shall be included in the last octet.
279

```

```

280 HLR-Id ::= IMSI
281   -- leading digits of IMSI, i.e. (MCC, MNC, leading digits of
282   -- MSIN) forming HLR Id defined in TS GSM 03.03.
283

```

```

284 HLR-List ::= SEQUENCE SIZE (1..maxNumOfHLR-Id) OF
285   HLR-Id
286

```

```

287 maxNumOfHLR-Id INTEGER ::= 50

```

```

288
289 LMSI ::= OCTET STRING (SIZE (4))
290
291 GlobalCellId ::= OCTET STRING (SIZE (5..7))
292   -- Refers to Cell Global Identification defined in TS GSM 03.03.
293   -- The internal structure is defined as follows:
294   -- octet 1 bits 4321           Mobile Country Code 1st digit
295   --       bits 8765            Mobile Country Code 2nd digit
296   -- octet 2 bits 4321           Mobile Country Code 3rd digit
297   --       bits 8765            Mobile Network Code 3rd digit
298   --                           or filler (1111) for 2 digit MNCS
299   -- octet 3 bits 4321           Mobile Network Code 1st digit
300   --       bits 8765            Mobile Network Code 2nd digit
301   -- octets 4 and 5            Location Area Code according to TS GSM 04.08
302   -- octets 6 and 7            Cell Identity (CI) according to TS GSM 04.08
303
304 NetworkResource ::= ENUMERATED {
305   plmn (0),
306   hlr (1),
307   vlr (2),
308   pvlr (3),
309   controllingMSC (4),
310   vmsc (5),
311   eir (6),
312   rss (7)}
313
314 NAEA-PreferredCI ::= SEQUENCE {
315   naea-PreferredCIC          [0] NAEA-CIC,
316   extensionContainer         [1] ExtensionContainer      OPTIONAL,
317   ...}
318
319 NAEA-CIC ::= OCTET STRING (SIZE (3))
320   -- The internal structure is defined by the Carrier Identification
321   -- parameter in ANSI T1.113.3. Carrier codes between "000" and "999" may
322   -- be encoded as 3 digits using "000" to "999" or as 4 digits using
323   -- "0000" to "0999". Carrier codes between "1000" and "9999" are encoded
324   -- using 4 digits.
325
326 SubscriberIdentity ::= CHOICE {
327   imsi                      [0] IMSI,
328   msisdn                    [1] ISDN-AddressString
329 }
330
331 LCSClientExternalID ::= SEQUENCE {
332   externalAddress            [0] AddressString        OPTIONAL,
333   extensionContainer         [1] ExtensionContainer    OPTIONAL,
334   ...}
335
336 LCSClientInternalID ::= ENUMERATED {
337   broadcastService           (0),
338   o-andM-HPLMN              (1),
339   o-andM-VPLMN              (2),
340   anonymousLocation          (3),
341   targetMSsubscribedService (4),
342   ...}
343
344
345 -- data types for CAMEL
346
347 CellIdOrLAI ::= CHOICE {
348   cellIdFixedLength          [0] CellIdFixedLength,
349   laiFixedLength             [1] LAIFixedLength}
350
351 CellIdFixedLength ::= OCTET STRING (SIZE (7))
352   -- Refers to Cell Global Identification defined in TS GSM 03.03.
353   -- The internal structure is defined as follows:
354   -- octet 1 bits 4321           Mobile Country Code 1st digit
355   --       bits 8765            Mobile Country Code 2nd digit
356   -- octet 2 bits 4321           Mobile Country Code 3rd digit
357   --       bits 8765            Mobile Network Code 3rd digit
358   --                           or filler (1111) for 2 digit MNCS
359   -- octet 3 bits 4321           Mobile Network Code 1st digit
360   --       bits 8765            Mobile Network Code 2nd digit
361   -- octets 4 and 5            Location Area Code according to TS GSM 04.08
362   -- octets 6 and 7            Cell Identity (CI) according to TS GSM 04.08
363

```

```

364 LAIFixedLength ::= OCTET STRING (SIZE (5))
365   -- Refers to Location Area Identification defined in TS GSM 03.03.
366   -- The internal structure is defined as follows:
367   -- octet 1 bits 4321           Mobile Country Code 1st digit
368   --          bits 8765           Mobile Country Code 2nd digit
369   -- octet 2 bits 4321           Mobile Country Code 3rd digit
370   --          bits 8765           Mobile Network Code 3rd digit
371   --          or filler (1111) for 2 digit MNCs
372   -- octet 3 bits 4321           Mobile Network Code 1st digit
373   --          bits 8765           Mobile Network Code 2nd digit
374   -- octets 4 and 5            Location Area Code according to TS GSM 04.08
375
376
377 -- data types for subscriber management
378
379 BasicServiceCode ::= CHOICE {
380   bearerService                [2] BearerServiceCode,
381   teleservice                   [3] TeleserviceCode}
382
383 Ext-BasicServiceCode ::= CHOICE {
384   ext-BearerService             [2] Ext-BearerServiceCode,
385   ext-Teleservice               [3] Ext-TeleserviceCode}
386
387 EMLPP-Info ::= SEQUENCE {
388   maximumentitledPriority       EMLPP-Priority,
389   defaultPriority               EMLPP-Priority,
390   extensionContainer            ExtensionContainer
391   ...}                           OPTIONAL,
392
393 EMLPP-Priority ::= INTEGER (0..15)
394   -- The mapping from the values A,B,0,1,2,3,4 to the integer-value is
395   -- specified as follows where A is the highest and 4 is the lowest
396   -- priority level
397   -- the integer values 7-15 are spare and shall be mapped to value 4
398
399 priorityLevelA                  EMLPP-Priority ::= 6
400 priorityLevelB                  EMLPP-Priority ::= 5
401 priorityLevel0                 EMLPP-Priority ::= 0
402 priorityLevel1                 EMLPP-Priority ::= 1
403 priorityLevel2                 EMLPP-Priority ::= 2
404 priorityLevel3                 EMLPP-Priority ::= 3
405 priorityLevel4                 EMLPP-Priority ::= 4
406
407
408 -- data types for geographic location
409
410 AgeOfLocationInformation ::= INTEGER (0..32767)
411   -- the value represents the elapsed time in minutes since the last
412   -- network contact of the mobile station (i.e. the actuality of the
413   -- location information).
414   -- value "0" indicates that the MS is currently in contact with the
415   -- network
416   -- value "32767" indicates that the location information is at least
417   --      32767 minutes old
418
419 END

```

17.7.9 Teleservice Codes

```

1 MAP-TS-Code {
2   ccitt identified-organization (4) etsi (0) mobileDomain (0)
3   gsm-Network (1) modules (3) map-TS-Code (19) version5 (5)}
4
5 DEFINITIONS
6
7 ::=_
8
9 BEGIN
10
11 TeleserviceCode ::= OCTET STRING (SIZE (1))
12   -- This type is used to represent the code identifying a single
13   -- teleservice, a group of teleservices, or all teleservices. The
14   -- services are defined in TS GSM 02.03.
15   -- The internal structure is defined as follows:
16
17   -- bits 87654321: group (bits 8765) and specific service
18   -- (bits 4321)

```

```

19
20 Ext-TeleserviceCode ::= OCTET STRING (SIZE (1..5))
21   -- This type is used to represent the code identifying a single
22   -- teleservice, a group of teleservices, or all teleservices. The
23   -- services are defined in TS GSM 02.03.
24   -- The internal structure is defined as follows:
25
26   -- OCTET 1:
27   -- bits 87654321: group (bits 8765) and specific service
28   -- (bits 4321)
29
30   -- OCTETS 2-5: reserved for future use. If received the
31   -- Ext-TeleserviceCode shall be
32   -- treated according to the exception handling defined for the
33   -- operation that uses this type.
34
35   -- Ext-TeleserviceCode includes all values defined for TeleserviceCode.
36
37
38 allTeleservices           TeleserviceCode ::= '00000000'B
39
40 allSpeechTransmissionServices TeleserviceCode ::= '00010000'B
41 telephony                 TeleserviceCode ::= '00010001'B
42 emergencyCalls           TeleserviceCode ::= '00010010'B
43
44 allShortMessageServices    TeleserviceCode ::= '00100000'B
45 shortMessageMT-PP          TeleserviceCode ::= '00100001'B
46 shortMessageMO-PP          TeleserviceCode ::= '00100010'B
47
48 allFacsimileTransmissionServices TeleserviceCode ::= '01100000'B
49 facsimileGroup3AndAlterSpeech TeleserviceCode ::= '01100001'B
50 automaticFacsimileGroup3     TeleserviceCode ::= '01100010'B
51 facsimileGroup4            TeleserviceCode ::= '01100011'B
52
53   -- The following non-hierarchical Compound Teleservice Groups
54   -- are defined in TS GSM 02.30:
55 allDataTeleservices        TeleserviceCode ::= '01110000'B
56   -- covers Teleservice Groups 'allFacsimileTransmissionServices'
57   -- and 'allShortMessageServices'
58 allTeleservices-ExeptSMS   TeleserviceCode ::= '10000000'B
59   -- covers Teleservice Groups 'allSpeechTransmissionServices' and
60   -- 'allFacsimileTransmissionServices'
61
62   -- Compound Teleservice Group Codes are only used in call
63   -- independent supplementary service operations, i.e. they
64   -- are not used in InsertSubscriberData or in
65   -- DeleteSubscriberData messages.
66
67 allVoiceGroupCallServices  TeleserviceCode ::= '10010000'B
68
69 voiceGroupCall             TeleserviceCode ::= '10010001'B
70 voiceBroadcastCall         TeleserviceCode ::= '10010010'B
71
72 allPLMN-specificTS        TeleserviceCode ::= '11010000'B
73 plmn-specificTS-1         TeleserviceCode ::= '11010001'B
74 plmn-specificTS-2         TeleserviceCode ::= '11010010'B
75 plmn-specificTS-3         TeleserviceCode ::= '11010011'B
76 plmn-specificTS-4         TeleserviceCode ::= '11010100'B
77 plmn-specificTS-5         TeleserviceCode ::= '11010101'B
78 plmn-specificTS-6         TeleserviceCode ::= '11010110'B
79 plmn-specificTS-7         TeleserviceCode ::= '11010111'B
80 plmn-specificTS-8         TeleserviceCode ::= '11011000'B
81 plmn-specificTS-9         TeleserviceCode ::= '11011001'B
82 plmn-specificTS-A         TeleserviceCode ::= '11011010'B
83 plmn-specificTS-B         TeleserviceCode ::= '11011011'B
84 plmn-specificTS-C         TeleserviceCode ::= '11011100'B
85 plmn-specificTS-D         TeleserviceCode ::= '11011101'B
86 plmn-specificTS-E         TeleserviceCode ::= '11011110'B
87 plmn-specificTS-F         TeleserviceCode ::= '11011111'B
88
89 END

```

17.7.10 Bearer Service Codes

```

1 MAP-BS-Code {
2   ccitt identified-organization (4) etsi (0) mobileDomain (0)
3   gsm-Network (1) modules (3) map-BS-Code (20) version5 (5)}

```

```

4
5 DEFINITIONS
6
7 ::= BEGIN
8
9
10
11 BearerServiceCode ::= OCTET STRING (SIZE (1))
12   -- This type is used to represent the code identifying a single
13   -- bearer service, a group of bearer services, or all bearer
14   -- services. The services are defined in TS GSM 02.02.
15   -- The internal structure is defined as follows:
16   --
17   -- plmn-specific bearer services:
18   -- bits 87654321: defined by the HPLMN operator
19
20   -- rest of bearer services:
21   -- bit 8: 0 (unused)
22   -- bits 7654321: group (bits 7654), and rate, if applicable
23   -- (bits 321)
24
25 Ext-BearerServiceCode ::= OCTET STRING (SIZE (1..5))
26   -- This type is used to represent the code identifying a single
27   -- bearer service, a group of bearer services, or all bearer
28   -- services. The services are defined in TS GSM 02.02.
29   -- The internal structure is defined as follows:
30   --
31   -- OCTET 1:
32   -- plmn-specific bearer services:
33   -- bits 87654321: defined by the HPLMN operator
34   --
35   -- rest of bearer services:
36   -- bit 8: 0 (unused)
37   -- bits 7654321: group (bits 7654), and rate, if applicable
38   -- (bits 321)
39
40   -- OCTETS 2-5: reserved for future use. If received the
41   -- Ext-TeleserviceCode shall be
42   -- treated according to the exception handling defined for the
43   -- operation that uses this type.
44
45   -- Ext-BearerServiceCode includes all values defined for BearerServiceCode.
46
47
48
49 allBearerServices           BearerServiceCode ::= '00000000'B
50
51 allDataCDA-Services        BearerServiceCode ::= '00010000'B
52 dataCDA-300bps            BearerServiceCode ::= '00010001'B
53 dataCDA-1200bps           BearerServiceCode ::= '00010010'B
54 dataCDA-1200-75bps        BearerServiceCode ::= '00010011'B
55 dataCDA-2400bps           BearerServiceCode ::= '00010100'B
56 dataCDA-4800bps           BearerServiceCode ::= '00010101'B
57 dataCDA-9600bps           BearerServiceCode ::= '00010110'B
58 general-dataCDA           BearerServiceCode ::= '00010111'B
59
60 allDataCDS-Services        BearerServiceCode ::= '00011000'B
61 dataCDS-1200bps           BearerServiceCode ::= '00011010'B
62 dataCDS-2400bps           BearerServiceCode ::= '00011100'B
63 dataCDS-4800bps           BearerServiceCode ::= '00011101'B
64 dataCDS-9600bps           BearerServiceCode ::= '00011110'B
65 general-dataCDS           BearerServiceCode ::= '00011111'B
66
67 allPadAccessCA-Services    BearerServiceCode ::= '00100000'B
68 padAccessCA-300bps         BearerServiceCode ::= '00100001'B
69 padAccessCA-1200bps        BearerServiceCode ::= '00100010'B
70 padAccessCA-1200-75bps     BearerServiceCode ::= '00100011'B
71 padAccessCA-2400bps        BearerServiceCode ::= '00100100'B
72 padAccessCA-4800bps        BearerServiceCode ::= '00100101'B
73 padAccessCA-9600bps        BearerServiceCode ::= '00100110'B
74 general-padAccessCA       BearerServiceCode ::= '00100111'B
75
76 allDataPDS-Services        BearerServiceCode ::= '00101000'B
77 dataPDS-2400bps           BearerServiceCode ::= '00101100'B
78 dataPDS-4800bps           BearerServiceCode ::= '00101101'B
79 dataPDS-9600bps           BearerServiceCode ::= '00101110'B
80 general-dataPDS           BearerServiceCode ::= '00101111'B
81

```

```

82 allAlternateSpeech-DataCDA                                BearerServiceCode ::= '00110000'B
83
84 allAlternateSpeech-DataCDS                                BearerServiceCode ::= '00111000'B
85
86 allSpeechFollowedByDataCDA                                BearerServiceCode ::= '01000000'B
87
88 allSpeechFollowedByDataCDS                                BearerServiceCode ::= '01001000'B
89
90 -- The following non-hierarchical Compound Bearer Service
91 -- Groups are defined in TS GSM 02.30:
92 allDataCircuitAsynchronous                                BearerServiceCode ::= '01010000'B
93   -- covers "allDataCDA-Services", "allAlternateSpeech-DataCDA" and
94   -- "allSpeechFollowedByDataCDA"
95 allAsynchronousServices                                BearerServiceCode ::= '01100000'B
96   -- covers "allDataCDA-Services", "allAlternateSpeech-DataCDA",
97   -- "allSpeechFollowedByDataCDA" and "allPadAccessCDA-Services"
98 allDataCircuitSynchronous                                BearerServiceCode ::= '01011000'B
99   -- covers "allDataCDS-Services", "allAlternateSpeech-DataCDS" and
100  -- "allSpeechFollowedByDataCDS"
101 allSynchronousServices                                BearerServiceCode ::= '01101000'B
102   -- covers "allDataCDS-Services", "allAlternateSpeech-DataCDS",
103   -- "allSpeechFollowedByDataCDS" and "allDataPDS-Services"
104
105 -- Compound Bearer Service Group Codes are only used in call
106 -- independent supplementary service operations, i.e. they
107 -- are not used in InsertSubscriberData or in
108 -- DeleteSubscriberData messages.
109
110 allPLMN-specificBS                                BearerServiceCode ::= '11010000'B
111 plmn-specificBS-1                                BearerServiceCode ::= '11010001'B
112 plmn-specificBS-2                                BearerServiceCode ::= '11010010'B
113 plmn-specificBS-3                                BearerServiceCode ::= '11010011'B
114 plmn-specificBS-4                                BearerServiceCode ::= '11010100'B
115 plmn-specificBS-5                                BearerServiceCode ::= '11010101'B
116 plmn-specificBS-6                                BearerServiceCode ::= '11010110'B
117 plmn-specificBS-7                                BearerServiceCode ::= '11010111'B
118 plmn-specificBS-8                                BearerServiceCode ::= '11011000'B
119 plmn-specificBS-9                                BearerServiceCode ::= '11011001'B
120 plmn-specificBS-A                                BearerServiceCode ::= '11011010'B
121 plmn-specificBS-B                                BearerServiceCode ::= '11011011'B
122 plmn-specificBS-C                                BearerServiceCode ::= '11011100'B
123 plmn-specificBS-D                                BearerServiceCode ::= '11011101'B
124 plmn-specificBS-E                                BearerServiceCode ::= '11011110'B
125 plmn-specificBS-F                                BearerServiceCode ::= '11011111'B
126
127 END

```

17.7.11 Extension data types

```

1 MAP-ExtensionDataTypes {
2   ccitt identified-organization (4) etsi (0) mobileDomain (0)
3   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version5 (5)
4
5 DEFINITIONS
6
7 IMPLICIT TAGS
8
9 ::=-
10
11 BEGIN
12
13 EXPORTS
14
15   PrivateExtension,
16   ExtensionContainer;
17
18
19 -- IOC for private MAP extensions
20
21
22 MAP-EXTENSION ::= CLASS {
23   &ExtensionType
24   &extensionId
25   OBJECT IDENTIFIER } OPTIONAL,
-- The length of the Object Identifier shall not exceed 16 octets and the
-- number of components of the Object Identifier shall not exceed 16
26
27
28

```

```

29
30 -- data types
31
32 ExtensionContainer ::= SEQUENCE {
33   privateExtensionList           [0]PrivateExtensionList      OPTIONAL,
34   pcs-Extensions                [1]PCS-Extensions          OPTIONAL,
35   ...
36 }
37 PrivateExtensionList ::= SEQUENCE SIZE (1..maxNumOfPrivateExtensions) OF
38   PrivateExtension
39
40 PrivateExtension ::= SEQUENCE {
41   extId                         MAP-EXTENSION.&extensionId
42   ( {ExtensionSet} ),
43   extType                        MAP-EXTENSION.&ExtensionType
44   ( {ExtensionSet}{@extId} )      OPTIONAL
45 }
46 maxNumOfPrivateExtensions INTEGER ::= 10
47
48 ExtensionSet                  MAP-EXTENSION ::= ...
49   ...
50   -- ExtensionSet is the set of all defined private extensions
51 }
52
53 -- Unsupported private extensions shall be discarded if received.
54
55
56 PCS-Extensions ::= SEQUENCE {
57   ...
58 }
59 END
60

```

17.7.12 Group Call data types

```

1 MAP-GR-DataTypes {
2   ccitt identified-organization (4) etsi (0) mobileDomain (0)
3   gsm-Network (1) modules (3) map-GR-DataTypes (23) version5 (5)
4
5 DEFINITIONS
6
7 IMPLICIT TAGS
8
9 ::= :
10
11 BEGIN
12
13 EXPORTS
14   PrepareGroupCallArg,
15   PrepareGroupCallRes,
16   SendGroupCallEndSignalArg,
17   SendGroupCallEndSignalRes,
18   ForwardGroupCallSignallingArg,
19   ProcessGroupCallSignallingArg
20 ;
21
22 IMPORTS
23   ISDN-AddressString,
24   IMSI,
25   EMLPP-Priority,
26   ASCII-CallReference
27 FROM MAP-CommonDataTypes {
28   ccitt identified-organization (4) etsi (0) mobileDomain (0)
29   gsm-Network (1) modules (3) map-CommonDataTypes (18) version5 (5)
30
31   Ext-TeleserviceCode
32 FROM MAP-TS-Code {
33   ccitt identified-organization (4) etsi (0) mobileDomain (0)
34   gsm-Network (1) modules (3) map-TS-Code (19) version5 (5)
35
36   Kc
37 FROM MAP-MS-DataTypes {
38   ccitt identified-organization (4) etsi (0) mobileDomain (0)
39   gsm-Network (1) modules (3) map-MS-DataTypes (11) version5 (5)
40
41 ExtensionContainer
42

```

```

43 FROM MAP-ExtensionDataTypes {
44   ccitt identified-organization (4) etsi (0) mobileDomain (0)
45   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version5 (5)}
46 ;
47
48
49 PrepareGroupCallArg ::= SEQUENCE {
50   teleservice                      Ext-TeleserviceCode,
51   asciiCallReference                ASCII-CallReference,
52   codec-Info                       CODEC-Info,
53   cipheringAlgorithm               CipheringAlgorithm,
54   groupKeyNumber                  [0] GroupKeyNumber           OPTIONAL,
55   groupKey                         [1] Kc                      OPTIONAL,
56   priority                          [2] EMLPP-Priority          OPTIONAL,
57   uplinkFree                       [3] NULL                    OPTIONAL,
58   extensionContainer               [4] ExtensionContainer        OPTIONAL,
59   ...
60 }
61
62 PrepareGroupCallRes ::= SEQUENCE {
63   groupCallNumber                 ISDN-AddressString,
64   extensionContainer              ExtensionContainer           OPTIONAL,
65   ...
66 }
67 SendGroupCallEndSignalArg ::= SEQUENCE {
68   imsi                            IMSI                      OPTIONAL,
69   extensionContainer              ExtensionContainer           OPTIONAL,
70   ...
71 }
72 SendGroupCallEndSignalRes ::= SEQUENCE {
73   extensionContainer              ExtensionContainer           OPTIONAL,
74   ...
75 }
76 ForwardGroupCallSignallingArg ::= SEQUENCE {
77   imsi                            IMSI                      OPTIONAL,
78   uplinkRequestAck                [0] NULL                 OPTIONAL,
79   uplinkReleaseIndication         [1] NULL                 OPTIONAL,
80   uplinkRejectCommand             [2] NULL                 OPTIONAL,
81   uplinkSeizedCommand            [3] NULL                 OPTIONAL,
82   uplinkReleaseCommand            [4] NULL                 OPTIONAL,
83   extensionContainer              ExtensionContainer        OPTIONAL,
84   ...
85 }
86 ProcessGroupCallSignallingArg ::= SEQUENCE {
87   uplinkRequest                   [0] NULL                 OPTIONAL,
88   uplinkReleaseIndication         [1] NULL                 OPTIONAL,
89   releaseGroupCall                [2] NULL                 OPTIONAL,
90   extensionContainer              ExtensionContainer        OPTIONAL,
91   ...
92 }
93
94 GroupKeyNumber ::= INTEGER (0..15)
95
96 CODEC-Info ::= OCTET STRING (SIZE (5..10))
97   -- Refers to channel type
98   -- coded according to GSM 08.08
99
100 CipheringAlgorithm ::= OCTET STRING (SIZE (1))
101   -- Refers to 'permitted algorithms' in 'encryption information'
102   -- coded according to GSM 08.08:
103
104   -- Bits 8-1
105   -- 8765 4321
106   -- 0000 0001      No encryption
107   -- 0000 0010      GSM A5/1
108   -- 0000 0100      GSM A5/2
109   -- 0000 1000      GSM A5/3
110   -- 0001 0000      GSM A5/4
111   -- 0010 0000      GSM A5/5
112   -- 0100 0000      GSM A5/6
113   -- 1000 0000      GSM A5/7
114
115
116
117
118
119 END

```

17.7.13 Location service data types

```

1 MAP-LCS-DataTypes {
2   ccitt identified-organization (4) etsi (0) mobileDomain (0)
3   gsm-Network (1) modules (3) map-LCS-DataTypes (25) version5 (5)}
4
5 DEFINITIONS
6 IMPLICIT TAGS
7 ::==
8 BEGIN
9
10 EXPORTS
11   RoutingInfoForLCS-Arg,
12   RoutingInfoForLCS-Res,
13   ProvideSubscriberLocation-Arg,
14   ProvideSubscriberLocation-Res,
15   SubscriberLocationReport-Arg,
16   SubscriberLocationReport-Res,
17   LocationType,
18   LCSClientName,
19   LCS-QoS,
20   Horizontal-Accuracy,
21   ResponseTime,
22   Ext-GeographicalInformation
23 ;
24
25 IMPORTS
26   AddressString,
27   ISDN-AddressString,
28   IMEI,
29   IMSI,
30   LMSI,
31   SubscriberIdentity,
32   AgeOfLocationInformation,
33   LCSClientExternalID,
34   LCSClientInternalID
35 FROM MAP-CommonDataTypes {
36   ccitt identified-organization (4) etsi (0) mobileDomain (0)
37   gsm-Network (1) modules (3) map-CommonDataTypes (18) version5 (5)}
38
39   ExtensionContainer
40 FROM MAP-ExtensionDataTypes {
41   ccitt identified-organization (4) etsi (0) mobileDomain (0)
42   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version5 (5)}
43
44   USSD-DataCodingScheme,
45   USSD-String
46 FROM MAP-SS-DataTypes {
47   ccitt identified-organization (4) etsi (0) mobileDomain (0) gsm-Network (1) modules (3)
48   map-SS-DataTypes (14) version5 (5)}
49 ;
50
51
52 RoutingInfoForLCS-Arg ::= SEQUENCE {
53   mlcNumber                               [0] ISDN-AddressString,
54   targetMS                                 [1] SubscriberIdentity,
55   extensionContainer                      [2] ExtensionContainer
56   ...}                                     OPTIONAL,
57
58 RoutingInfoForLCS-Res ::= SEQUENCE {
59   targetMS                                 [0] SubscriberIdentity,
60   lcsLocationInfo                         [1] LCSLocationInfo,
61   extensionContainer                      [2] ExtensionContainer
62   ...}                                     OPTIONAL,
63
64 LCSLocationInfo ::= SEQUENCE {
65   msc-Number                             ISDN-AddressString,
66   lmsi                                    [0] LMSI
67   extensionContainer                     [1] ExtensionContainer
68   ...}                                     OPTIONAL,
69

```

```

70 ProvideSubscriberLocation-Arg ::= SEQUENCE {
71   locationType                  LocationType,
72   mlc-Number                   ISDN-AddressString,
73   lcs-ClientID                [0] LCS-ClientID           OPTIONAL,
74   privacyOverride              [1] NULL                  OPTIONAL,
75   imsi                        [2] IMSI                 OPTIONAL,
76   msisdn                      [3] ISDN-AddressString    OPTIONAL,
77   lmsi                         [4] LMSI                 OPTIONAL,
78   imei                         [5] IMEI                 OPTIONAL,
79   lcs-Priority                [6] LCS-Priority          OPTIONAL,
80   lcs-QoS                      [7] LCS-QoS               OPTIONAL,
81   extensionContainer          [8] ExtensionContainer    OPTIONAL,
82   ...
83
84 -- one of imsi or msisdn is mandatory
85
86 LocationType ::= SEQUENCE {
87   locationEstimateType        [0] LocationEstimateType,
88   ...
89
90 LocationEstimateType ::= ENUMERATED {
91   currentLocation             (0),
92   currentOrLastKnownLocation (1),
93   initialLocation            (2),
94   ...
95 -- exception handling:
96 -- a ProvideSubscriberLocation-Arg containing an unrecognized LocationEstimateType
97 -- shall be rejected by the receiver with a return error cause of unexpected data value
98
99 LCS-ClientID ::= SEQUENCE {
100  lcsClientType               [0] LCSClientType,
101  lcsClientExternalID         [1] LCSClientExternalID    OPTIONAL,
102  lcsClientDialedByMS         [2] AddressString          OPTIONAL,
103  lcsClientInternalID         [3] LCSClientInternalID    OPTIONAL,
104  lcsClientName               [4] LCSClientName          OPTIONAL,
105  ...
106
107 LCSClientType ::= ENUMERATED {
108   emergencyServices          (0),
109   valueAddedServices          (1),
110   plmnOperatorServices       (2),
111   lawfulInterceptServices    (3),
112   ...
113 -- exception handling:
114 -- unrecognized values may be ignored if the LCS client uses the privacy override
115 -- otherwise, an unrecognized value shall be treated as unexpected data by a receiver
116 -- a return error shall then be returned if received in a MAP invoke
117
118 LCSClientName ::= SEQUENCE {
119   dataCodingScheme            [0] USSD-DataCodingScheme,
120   nameString                  [2] NameString,
121   ...
122
123 -- The USSD-DataCodingScheme shall indicate use of the default alphabet through the
124 -- following encoding
125 -- bit 7 6 5 4 3 2 1 0
126 --      0 0 0 0 1 1 1 1
127
128 NameString ::= USSD-String (SIZE (1..maxNameStringLength))
129
130 maxNameStringLength INTEGER ::= 63
131
132 LCS-Priority ::= OCTET STRING (SIZE (1))
133   -- 0 = highest priority
134   -- 1 = normal priority
135   -- all other values treated as 1
136
137 LCS-QoS ::= SEQUENCE {
138   horizontal-accuracy        [0] Horizontal-Accuracy    OPTIONAL,
139   verticalCoordinateRequest  [1] NULL                  OPTIONAL,
140   vertical-accuracy          [2] Vertical-Accuracy    OPTIONAL,
141   responseTime               [3] ResponseTime          OPTIONAL,
142   extensionContainer          [4] ExtensionContainer    OPTIONAL,
143   ...
144

```

```

145 Horizontal-Accuracy ::= OCTET STRING (SIZE (1))
146   -- bit 8 = 0
147   -- bits 7-1 = 7 bit Uncertainty Code defined in GSM 03.32. The horizontal location
148   -- error should be less than the error indicated by the uncertainty code with 67%
149   -- confidence.
150
151 Vertical-Accuracy ::= OCTET STRING (SIZE (1))
152   -- bit 8 = 0
153   -- bits 7-1 = 7 bit Vertical Uncertainty Code defined in GSM 03.32. The vertical location
154   -- error should be less than the error indicated by the uncertainty code with 67 %
155   -- confidence.
156
157 ResponseTime ::= SEQUENCE {
158   responseTimeCategory           ResponseTimeCategory,
159   ...
160   -- note: an expandable SEQUENCE simplifies later addition of a numeric response time.
161
162 ResponseTimeCategory ::= ENUMERATED {
163   lowdelay (0),
164   delaytolerant (1),
165   ...
166   -- exception handling:
167   -- an unrecognized value shall be treated the same as value 1 (delaytolerant)
168
169 ProvideSubscriberLocation-Res ::= SEQUENCE {
170   locationEstimate             Ext-GeographicalInformation,
171   ageOfLocationEstimate        [0] AgeOfLocationInformation      OPTIONAL,
172   extensionContainer           [1] ExtensionContainer          OPTIONAL,
173   ...
174
175 Ext-GeographicalInformation ::= OCTET STRING (SIZE (1..maxExt-GeographicalInformation))
176   -- Refers to geographical Information defined in GSM 03.32.
177   -- This is composed of 1 or more octets with an internal structure according to GSM 03.32
178   -- Octet 1: Type of shape, only the following shapes in GSM 03.32 are allowed:
179   --   (a) Ellipsoid point with uncertainty circle
180   --   (b) Ellipsoid point with uncertainty ellipse
181   --   (c) Ellipsoid point with altitude and uncertainty ellipsoid
182   --   (d) Ellipsoid Arc
183   -- Any other value in octet 1 shall be treated as invalid
184   -- Octets 2 to 8 for case (a) - Ellipsoid point with uncertainty circle
185   --   Degrees of Latitude                      3 octets
186   --   Degrees of Longitude                     3 octets
187   --   Uncertainty code                         1 octet
188   -- Octets 2 to 11 for case (b) - Ellipsoid point with uncertainty ellipse:
189   --   Degrees of Latitude                      3 octets
190   --   Degrees of Longitude                     3 octets
191   --   Uncertainty semi-major axis            1 octet
192   --   Uncertainty semi-minor axis            1 octet
193   --   Angle of major axis                  1 octet
194   --   Confidence                           1 octet
195   -- Octets 2 to 14 for case (c) - Ellipsoid point with altitude and uncertainty ellipsoid
196   --   Degrees of Latitude                      3 octets
197   --   Degrees of Longitude                     3 octets
198   --   Altitude                            2 octets
199   --   Uncertainty semi-major axis            1 octet
200   --   Uncertainty semi-minor axis            1 octet
201   --   Angle of major axis                  1 octet
202   --   Uncertainty altitude                1 octet
203   --   Confidence                           1 octet
204   -- Octets 2 to 13 for case (d) - Ellipsoid Arc
205   --   Degrees of Latitude                      3 octets
206   --   Degrees of Longitude                     3 octets
207   --   Inner radius                         2 octets
208   --   Uncertainty radius                   1 octet
209   --   Offset angle                          1 octet
210   --   Included angle                       1 octet
211   --   Confidence                           1 octet
212
213   -- An Ext-GeographicalInformation parameter containing any other shape or an incorrect number
214   -- of octets or coding according to GSM 03.32 shall be treated as invalid data by a receiver
215
216 maxExt-GeographicalInformation INTEGER ::= 20
217   -- the maximum length allows for further shapes in GSM 03.32 to be included in later versions
218   -- of GSM 09.02
219

```

```

220 SubscriberLocationReport-Arg ::= SEQUENCE {
221   lcs-Event                         LCS-Event,
222   lcs-ClientID                      LCS-ClientID,
223   lcsLocationInfo                   LCSLocationInfo,
224   msisdn                           [ 0 ] ISDN-AddressString      OPTIONAL,
225   imsi                            [ 1 ] IMSI                     OPTIONAL,
226   imei                            [ 2 ] IMEI                     OPTIONAL,
227   na-ESRD                          [ 3 ] ISDN-AddressString      OPTIONAL,
228   na-ESRK                          [ 4 ] ISDN-AddressString      OPTIONAL,
229   locationEstimate                 [ 5 ] Ext-GeographicalInformation OPTIONAL,
230   ageOfLocationEstimate            [ 6 ] AgeOfLocationInformation OPTIONAL,
231   extensionContainer               [ 7 ] ExtensionContainer       OPTIONAL,
232   ...
233
234 -- one of msisdn or, imsi is mandatory
235
236 LCS-Event ::= ENUMERATED {
237   emergencyCallOrigination (0),
238   emergencyCallRelease  (1),
239   mo-lr (2),
240   ...
241 -- exception handling:
242 -- a SubscriberLocationReport-Arg containing an unrecognized LCS-Event
243 -- shall be rejected by a receiver with a return error cause of unexpected data value
244
245 SubscriberLocationReport-Res ::= SEQUENCE {
246   extensionContainer             ExtensionContainer      OPTIONAL,
247   ...
248
249
250
251 END
252

```

18 General on MAP user procedures

18.1 Introduction

Clauses 18 to 25 describe the use of MAP services for GSM signalling procedures. GSM signalling procedures may involve one or several interfaces running one or several application protocols. The present document addresses only the signalling procedures which require at least the use of one MAP service.

When a signalling procedure takes place in the network, an application process invocation is created in each system component involved. Part of the application process invocation acts as a MAP user and handles one or several MAP dialogues. For each dialogue it employs an instance of the MAP service provider. It may also use other communication services to exchange information on other interfaces, but detailed description of these aspects is outside the scope of the present document.

18.2 Common aspects of user procedure descriptions

18.2.1 General conventions

For each signalling procedure the present document provides a brief textual overview accompanied by a flow diagram which represent the functional interactions between system components. Functional interactions are labelled using the MAP service name when the interaction results from a service request or by this service name followed by the symbol "ack" when this interaction results from a service response.

For each of the system components involved, the present document also provides a detailed textual description of the application process behaviour as well as an SDL diagram. SDL diagrams describe the sequence of events, as seen by the MAP-User, which occurs at MAP service provider boundaries as well as external events which occur at other interfaces and which impact on the previous sequence.

External events do not necessarily correspond to the messages of other protocols used in the system component. The MAP-user procedures are described as if a set of interworking functions (IWF) between the MAP-user and the other protocol entities was implemented (see figure 18.2/1). Such interworking functions are assumed to perform either an identity mapping or some processing or translation as required to eliminate information irrelevant to the MAP-user.

The mapping of service primitives on to protocol elements is described in clauses 14 to 17.

GSM signalling procedures are built from one or more sub-procedures (e.g. authentication, ciphering,). Sub-procedures from which signalling procedures are built are represented using SDL MACRO descriptions.

In case of any discrepancy between the textual descriptions and the SDL descriptions, the latter take precedence.

18.2.2 Naming conventions

Events related to MAP are represented by MAP service primitives. The signal names used in the SDL diagrams are derived from the service primitive names defined in clauses 7 to 12, with some lexical transformations for readability and parsability purposes (blanks between words are replaced by underscores, the first letter of each word is capitalized).

Events received and sent on other interfaces are named by appending the message or signal name to a symbol representing the interface type, with some lexical transformations for readability and parsability purposes (blanks between words are replaced by underscores, the first letter of each word is capitalized).

The following symbols are used to represent the interface types:

- "I": For interfaces to the fixed network. "I" stands for ISUP interface.
- "A": For interfaces to BSS (i.e. A-interfaces);
- "OM": For network management interfaces (communication with OMC, MML interface, ...);
- "SC": For interfaces to a Service Centre;
- "HO_CA": For internal interfaces to the Handover Control Application.
- "US": For a local USSD application.

These naming conventions can be summarized by the following BNF description:

```

<Event_Name> ::= <MAP_Primitive> | <External_Event>
<MAP_Primitive> ::= <MAP_Open> | <MAP_Close> | <MAP_U_Abort> | <MAP_P_Abort> |
                     <MAP_Specific> | <MAP_Notify>
<MAP_Open> ::= MAP_Open_Req | MAP_Open_Ind | MAP_Open_Rsp | MAP_Open_Cnf
<MAP_Close> ::= MAP_Close_Req | MAP_Close_Ind
<MAP_U_Abort> ::= MAP_U_Abort_Req | MAP_U_Abort_Ind
<MAP_P_Abort> ::= MAP_P_Abort_Ind
<MAP_Notify> ::= MAP_Notify_Ind
<MAP_Specific> ::= <MAP_Req> | <MAP_Ind> | <MAP_Rsp> | <MAP_Cnf>
<MAP_Req> ::= MAP_<Service_Name>_Req
<MAP_Ind> ::= MAP_<Service_Name>_Ind
<MAP_Rsp> ::= MAP_<Service_Name>_Rsp
<MAP_Cnf> ::= MAP_<Service_Name>_Cnf
<External_Event> ::= <Interface_Type>_<External_Signal>
<Interface_Type> ::= I | A | OM | SC | HO AC | US
<External_Signal> ::= <Lexical_Unit>
<Service_Name> ::= <Lexical_Unit>
<Lexical_Unit> ::= <Lexical_Component> | <Lexical_Unit>_<Lexical_Component>
<Lexical_Component> ::= <Upper_Case_Letter><Letter_Or_Digit_List>
<Letter_Or_Digit_List> ::= <Letter_Or_Digit> | <Letter_Or_Digit_List><Letter_Or_Digit>
<Letter_Or_Digit> ::= <Letter> | <Digit>
<Letter> ::= <Lower_Case_Letter> | <Upper_Case_Letter>
<Upper_Case_Letter> ::= A|B|C|D|E|F|G|H|I|J|K|L|M|N|O|P|Q|R|S|T|U|V|W|X|Y|Z
<Lower_Case_Letter> ::= a|b|c|d|e|f|g|h|i|j|k|l|m|n|o|p|q|r|s|t|u|v|w|x|y|z
<Digit> ::= 1|2|3|4|5|6|7|8|9|0

```

Figure 18.2/1: Interfaces applicable to the MAP-User

18.2.3 Convention on primitives parameters

18.2.3.1 Open service

When the originating and destination reference parameters shall be included in the MAP-OPEN request primitive, their value are indicated as a comment to the signal which represents this primitive.

18.2.3.2 Close service

When a pre-arranged released is requested, a comment is attached to the signal which represents the MAP-CLOSE request primitive. In the absence of comment, a normal release is assumed.

18.2.4 Version handling at dialogue establishment

Unless explicitly indicated in subsequent subclauses, the following principles regarding version handling procedures at dialogue establishment are applied by the MAP-user:

18.2.4.1 Behaviour at the initiating side

When a MAP user signalling procedure has to be executed, the MAP-user issues a MAP-OPEN request primitive with an appropriate application-context-name. If several names are supported (i.e. several versions) a suitable one is selected using the procedures described in clause 5.

If version 2 is selected and a MAP-OPEN Confirm primitive in response to the MAP-OPEN request is received with a result parameter set to "refused" and a diagnostic parameter indicating "application-context-not-supported" or "potential incompatibility problem", the MAP-User issues a new MAP-OPEN request primitive with the equivalent version one context. This is informally represented in the SDL diagrams by a task symbol indicating "Perform Vr procedure".

If version 3 is selected and a MAP-OPEN Confirm primitive in response to the MAP-OPEN request is received with a result parameter set to "refused" and a diagnostic parameter indicating "application-context-not-supported" or "potential incompatibility problem", the MAP-User issues a new MAP-OPEN request primitive with the equivalent version one or version two context. This is informally represented in the SDL diagrams by task symbols indicating "Perform Vr procedure".

If version 4 is selected and a MAP-OPEN Confirm primitive in response to the MAP-OPEN request is received with a result parameter set to "refused" and a diagnostic parameter indicating "application-context-not-supported" or "potential incompatibility problem", the MAP-User issues a new MAP-OPEN request primitive with the equivalent version one, version two or version three context. This is informally represented in the SDL diagrams by task symbols indicating "Perform Vr procedure".

18.2.4.2 Behaviour at the responding side

On receipt of a MAP-OPEN indication primitive, the MAP-User analyses the application-context-name.

If it refers to a version one context, the associated V1 procedure is executed; if it refers to a version two context, the associated V2 procedure is executed; if it refers to a version three context, the associated V3 procedure is executed, otherwise the associated V4 procedure is executed.

18.2.5 Abort Handling

Unless explicitly indicated in subsequent subclauses, the following principles are applied by the MAP-user regarding abort handling procedures:

On receipt of a MAP-P-ABORT indication or MAP-U-ABORT Indication primitive from any MAP-provider invocation, the MAP-User issues a MAP-U-ABORT Request primitive to each MAP-provider invocation associated with the same user procedure.

If applicable a decision is made to decide if the affected user procedure has to be retried or not.

18.2.6 SDL conventions

The MAP SDLs make use of a number of SDL concepts and conventions, where not all of them may be widely known. Therefore, this subclause outlines the use of a few concepts and conventions to improve understanding of the MAP SDLs.

The MAP User SDLs make use of SDL Processes, Procedures and Macros. Processes are independent from each other even if one process starts another one: The actions of both of them have no ordering in time. SDL Procedures and Macros are just used to ease writing of the specification: They contain parts of a behaviour used in several places, and the corresponding Procedure/Macro definition has to be expanded at the position of the Procedure/Macro call.

All Processes are started at system initialization and live forever, unless process creation/termination is indicated explicitly (i.e. a process is created by some other process).

The direction of Input/Output Signals in the SDL graphs is used to indicate the entity to which/from which communication is directed. If a process A communicates in parallel with processes B and C, all Inputs/Outputs to/from B are directed to one side, whereas communication with C is directed to the other side. However, there has been no formal convention used that communication to a certain entity (e.g. a HLR) will always be directed to a certain side (e.g. right).

In each state all those Input Signals are listed, which result in an action and/or state change. If an Input Signal is not listed in a state, receipt of this input should lead to an implicit consumption without any action or state change (according to the SDL rules). This implicit consumption is mainly used for receipt of the MAP DELIMITER indication and for receipt of a MAP CLOSE indication, except for a premature MAP CLOSE.

18.3 Interaction between MAP Provider and MAP Users

Each MAP User is defined by at least one SDL process. On the dialogue initiating side the MAP User will create a new instance of a MAP Provider implicit by issuing a MAP-OPEN request. This instance corresponds to a TC Dialogue and lives as long as the dialogue exists (see also subclause 14.3). There is a fix relation between MAP User and this Provider instance, i.e. all MAP service primitives from the MAP User for this dialogue are sent to this instance and all TC components received by this MAP Provider are mapped onto service primitives sent to this MAP User.

On the receiving side a MAP Provider instance is created implicit by receipt of a TC BEGIN indication. The corresponding MAP User is determined by the Application Context name included in this primitive, i.e. each Application Context is associated with one and only one MAP User. An instance of this User will be created implicit by receiving a MAP-OPEN indication. Note that in some cases there exist several SDL Processes for one MAP User (Application Context), e.g. the processes Register_SS_HLR, Erase_SS_HLR, Activate_SS_HLR, Deactivate_SS_HLR, Interrogate_SS_HLR, and Register_Password for the AC Network_Functional_SS_Handling. In these cases, a coordinator process is introduced acting as a MAP User, which in turn starts a sub-process depending on the first MAP service primitive received.

19 Mobility procedures

19.1 Location management Procedures

For non-GPRS subscribers, this subclause comprises a number of processes to handle the mobile nature of the subscriber. The processes will be addressed by SCCP Sub-System Number (MSC, VLR or HLR) and the Application Context. The following processes are defined in this subclause:

Process Update Location Area:

- Initiator: Update_Location_Area_MSC, subclause 19.1.1.2;
- Responder: Update_Location_Area_VLR, subclause 19.1.1.3;

Process Update Location:

- Initiator: Update_Location_Area_VLR, subclause 19.1.1.3, or
Update_Location_VLR, subclause 19.1.1.6;
- Responder: Update_Location_HLR, subclause 19.1.1.4;

Process Send Identification:

- Initiator: Update_Location_Area_VLR, subclause 19.1.1.3;
- Responder: Send_Identification_VLR, subclause 19.1.1.5;

Process Subscriber Present HLR:

- Initiator: Subscriber_Present_HLR, subclause 19.1.1.7;
- Responder: Short_Message_Alert_IWMSC, subclause 23.4.3;

Process Cancel Location:

- Initiator: Cancel_Location_HLR, subclause 19.1.2.2;
- Responder: Cancel_Location_VLR, subclause 19.1.2.3;

Process Detach IMSI:

- Initiator: Detach_IMSI_MSC, subclause 19.1.3.2;
- Responder: Detach_IMSI_VLR, subclause 19.1.3.3.

Process Purge MS:

- Initiator: Purge_MS_VLR, subclause 19.1.4.2;
- Responder: Purge_MS_HLR, subclause 19.1.4.3.

As both the Update Location Area and the Detach IMSI processes use the same application context name, the MAP Provider cannot distinguish between them. Therefore, a Location Management Coordinator Process will act as one user for this application context. This process (one in MSC, one in VLR) will create the Update Location Area or the Detach IMSI process, depending on the first service primitive received in the respective dialogue.

Additionally, a Location Management Coordinator process in the HLR coordinates the two application processes "Update Location HLR" (subclause 19.1.1.4) and "RESTORE_DATA_HLR" (subclause 19.3.3) that are addressed by the same application context.

Location Management Coordinator MSC

On receipt of a request for location updating from the A-interface, the Location Management Coordinator in the MSC will:

- create the process Update_Location_Area_MSC in case the updating type indicated in the A-interface primitive indicates normal updating, periodic updating or IMSI Attach;
- create the process Detach_IMSI_MSC in case the updating type indicated in the A-interface primitive indicates IMSI Detach.

The respective primitive is then forwarded to the created process. Henceforth, the coordinator will relay all service primitives from provider to the user and vice versa, until a request or indication for dialogue termination is received. This last primitive will be relayed, too, before the Coordinator process returns to idle state.

Location Management Coordinator VLR

On receipt of a dialogue request for the Location Management Application Context (see Receive_Open_Ind macro in subclause 25.1), the Location_Management_Coordinator will:

- terminate the procedure in case of parameter problems or if the MSC indicated version Vr protocol; or
- continue as below, if the dialogue is accepted.

Depending on the first service primitive received from the MAP Provider in this dialogue, the user process is created:

- Update_Location_Area_VLR in case the primitive is a MAP_UPDATE_LOCATION_AREA indication;
- Detach_IMSI_VLR in case the primitive is a MAP_DETACH_IMSI indication.

In case a MAP_U_ABORT, MAP_P_ABORT or a premature MAP_CLOSE indication is received instead, the process returns to idle state. If a MAP_NOTICE indication is received, the dialogue towards the MSC is aborted and the process returns to idle state.

After creation of the user process the service primitive received from the provider is passed to the user process. Henceforth, the coordinator will relay all service primitives from provider to the user and vice versa, until a request or indication for dialogue termination is received. This last primitive will be relayed, too, before the Coordinator process returns to idle state.

Location Management Coordinator HLR

On receipt of a dialogue request for the Location Management Application Context (see Receive_Open_Ind macro in subclause 25.1), the Location_Management_Coordinator will:

- terminate the process in case of parameter problems; or
- revert to MAP version Vr protocol if the VLR requests version Vr protocol; or
- continue as described in the following, if the dialogue is accepted.

The user process is created depending on the first service primitive received from the MAP service provider within this dialogue:

- Update_Location_HLR if the primitive is a MAP_UPDATE_LOCATION indication;
- RESTORE_DATA_HLR if the primitive is a MAP_RESTORE_DATA indication.

If a MAP_NOTICE indication is received instead, the dialogue towards the MSC is terminated and the process returns to idle state.

After creation of the user process the service primitive received from the MAP service-provider is passed to the user process. Henceforth, the coordinator will relay all service primitives from MAP service-provider to the MAP service-user and vice versa, until a request or indication for dialogue termination is received. This last primitive will be relayed, too, before the Coordinator process returns to idle state.

For GPRS subscribers, this subclause comprises a number of other processes to handle the mobile nature of the subscriber. The processes will be addressed by SCCP Sub-System Number (SGSN or HLR) and the Application Context. The following processes are defined in this subclause:

Process GPRS Update Location:

- Initiator: GPRS_Update_Location_Area_VLR, subclause 19.1.1.3, or
 SGSN_Update_HLR, subclause 19.1.1.8,
 Responder: Update_GPRS_Location_HLR, subclause 19.1.1.4;

Process Cancel Location:

- Initiator: Cancel_GPRS_Location_HLR, subclause 19.1.2.2;
 Responder: Cancel_Location_SGSN, subclause 19.1.2.4;

Process Purge MS:

- Initiator: Purge_MS_SGSN, subclause 19.1.4.4;
 Responder: Purge_MS_HLR, subclause 19.1.4.3.

The following existing process is also used for GPRS subscribers :

Process Subscriber Present HLR:

- Initiator: Subscriber_Present_HLR, subclause 19.1.1.7;
 Responder: Short_Message_Alert_IWMSC, subclause 23.4.3;




Figure 19.1/1: Process Location_Management_Coordinator_MSC




Figure 19.1/2: Process Location_Management_Coordinator_VLR




Figure 19.1/3: Process Location_Management_Coordinator_HLR

19.1.1 Location updating

19.1.1.1 General

The location updating procedure is used to update the location information held in the network. For GPRS subscribers, this procedure describes also updating of the SGSN and, if Gs interface is installed, updating of the VLR in combination with an attach/routing area updating in the SGSN. This location information is used to route incoming calls, packet data, short messages and unstructured supplementary service data to the roaming subscriber. Additionally, this procedure is used to provide the VLR and/or the SGSN with the information that a subscriber already registered, but being detached, is reachable again (IMSI Attach and/or GPRS Attach, see GSM 03.12 and GSM 03.60). The use of the IMSI Detach / Attach feature is optional for the network operator.

To minimize the updates of the subscriber's HLR, the HLR holds only information about the VLR and MSC the subscriber is attached to and, for GPRS subscribers, the SGSN the subscriber is attached to. The VLR and the SGSN contain more detailed location information, i.e. the location area the subscriber is actually roaming in (for the VLR) and the routing area (RA) where the GPRS subscriber is located (for SGSN). Therefore, the VLR needs to be updated at each location area change (see figure 19.1.1/1 for this procedure) and the SGSN needs to be updated at each routing area change. The HLR needs updating only in the following cases:

- when the subscriber registers in a new VLR or SGSN, i.e. the VLR or SGSN has no data for that subscriber;
- when the subscriber registers in a new location area of the same VLR and new routing information is to be provided to the HLR (change of MSC area);
- if the indicator "Confirmed by HLR" or the indicator "Location Information Confirmed in HLR" is set to "Not Confirmed" because of HLR, VLR or SGSN restoration, and the VLR or SGSN receives an indication that the subscriber is present.

If a mobile subscriber registers in a visitor location register (VLR) not holding any information about this subscriber and is identified by a temporary mobile subscriber identity (TMSI) allocated by a previous visitor location register (PVLR), if the PVLR identity can be derived from LAI the new VLR must obtain the IMSI from PVLR to identify the HLR to be updated (see figure 19.1.1/2). If the IMSI cannot be retrieved from PVLR, it is requested from the MS (see figure 19.1.1/3).

The stage 2 specification for GPRS is in GSM 03.60. The interworking between the MAP signalling procedures and the GPRS procedures in the SGSN is shown by the transfer of signals between these procedures (see subclause 19.1.1.8).

The message flow for successful GPRS Attach/ RA update procedure (with Gs interface not installed) is shown in figure 19.1.1/4.


The message flow for successful GPRS Attach/ RA update procedure combined with a successful VLR location updating (Gs interface installed) is shown in figure 19.1.1/5.

The following MAP services are invoked by the location update procedure:

MAP_UPDATE_LOCATION_AREA (see subclause 8.1);(**)
MAP_UPDATE_LOCATION (see subclause 8.1);(**)
MAP_UPDATE_GPRS_LOCATION (see subclause 8.1) (*);
MAP_CANCEL_LOCATION (see subclause 8.1);
MAP_INSERT_SUBSCRIBER_DATA (see subclause 8.8);
MAP_SEND_IDENTIFICATION (see subclause 8.1) (**);
MAP_PROVIDE_IMSI (see subclause 8.9) (**);
MAP_AUTHENTICATE (see subclause 8.5) (**);
MAP_SET_CIPHERING_MODE (see subclause 8.6) (**);
MAP_FORWARD_NEW_TMSI (see subclause 8.9) (**);
MAP_CHECK_IMEI (see subclause 8.7) (**);
MAP_ACTIVATE_TRACE_MODE (see subclause 9.2);
MAP_TRACE_SUBSCRIBER_ACTIVITY (see subclause 9.2) (**).

(*): only used in SGSN and HLR for GPRS


(**): not used in SGSN



NOTE 1: For details of the procedure on the radio path, see GSM 04.08. The services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.


NOTE 2: Optional services are printed in *italics*.

Figure 19.1.1/1: Interface and services for location updating when roaming within an visitor location registers area (without need to update HLR)




NOTE: The optional procedures in figure 19.1.1/1 apply here respectively.

Figure 19.1.1/2: Interface and services for location updating when changing the VLR area



NOTE: The optional procedures in figure 19.1.1/1 apply here respectively.


Figure 19.1.1/3: Interface and services for location updating involving both a VLR and an HLR, when IMSI can not be retrieved from the previous VLR



PSGSN = Previous SGSN

- NOTE 1: For details of the procedure on the radio path, see GSM 08.18. The services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.
- NOTE 2: For security functions (authentication, ciphering, IMEI check) triggering refer to GSM 03.60. MAP processes invoked for those procedures are described in section 25.
- NOTE 3: Optional services are printed in *italics*.
- NOTE 4: Refer to GSM 03.60 for termination of the procedure and triggering of the signalling on the Gb interface.

Figure 19.1.1/14: Interface and services for GPRS location updating (Gs-interface not installed)



NOTE 0: The optional procedures in figure 19.1.1/14 apply here respectively. For details of the procedure on the Gs-interface, see GSM 09.18.

NOTE 1: Location Cancellation procedure toward the old VLR and optional tracing activation toward the new VLR are not represented on this figure.

Figure 19.1.1/15: Interface and services for GPRS location updating (Gs-interface installed)

19.1.1.2 Detailed procedure in the MSC

Figure 19.1.1/4 shows the MSC process for location register updating, containing macro calls for:

Receive_Open_Cnf	subclause 25.1;
Authenticate_MSC	subclause 25.5;
Check_IMEI_MSC	subclause 25.6;
Obtain_IMSI_MSC	subclause 25.8;
Trace_Subscriber_Activity_MSC	subclause 25.9.

For structuring purposes, the second part of the process is placed into the macro Update Location Completion MSC, which is specific to this process (see figure 19.1.1/5).

When the MSC receives an A_LU_REQUEST (normal location updating, periodic location updating or IMSI attach) for a subscriber via the radio path, the MSC opens a dialogue to the VLR (MAP_OPEN request without any user specific parameters) and sends a MAP_UPDATE_LOCATION_AREA request, containing the parameters provided in the A_LU_REQUEST by the MS or BSS (for the parameter mapping see GSM 09.10).

If the dialogue is rejected or the VLR indicates a fallback to the version Vr procedure (see Receive_Open_Cnf macro in subclause 25.1), the MSC will send an A_LU_Rej towards the MS and terminate the procedure.

If the dialogue is accepted, the VLR will process this updating request, invoking optionally the MAP_PROVIDE_IMSI, MAP_TRACE_SUBSCRIBER_ACTIVITY, MAP_CHECK_IMEI or the MAP_AUTHENTICATE services first (see subclause 19.1.1.3 for initiation conditions, clause 25 for macros defining the handling of services in the MSC). For these macros there are two possible outcomes:

- a positive outcome, in which case the process continues waiting for the MAP_UPDATE_LOCATION_AREA confirmation; or
- an error is reported, in which case the process terminates (not applicable for Trace_Subscriber_Activity_MSC, which has only a positive outcome).

After receiving the MAP_UPDATE_LOCATION_AREA indication and handling these optional services, the VLR will decide whether a new TMSI need to be allocated to the subscriber or not.

Updating without TMSI reallocation

If the VLR does not reallocate the TMSI, the MSC will receive a MAP_UPDATE_LOCATION_AREA confirmation next (figure 19.1.1/4).

- if there are no parameters with this primitive, updating was successful and a confirmation will be sent to the MS;
- if there is an error cause contained in the received primitive, this cause will be mapped to the corresponding cause in the confirmation sent to the MS (see GSM 09.10 for the mapping of messages and causes).

Updating including TMSI reallocation

This case is covered by the macro Update Location Completion MSC given in figure 19.1.1/5. The MSC will upon receipt of a MAP_SET_CIPHERING_MODE request send a ciphering command towards BSS/MS. Thereafter, the MAP_FORWARD_NEW_TMSI indication and the MAP_UPDATE_LOCATION_AREA confirmation are received in arbitrary order, causing a confirmation on the radio path containing both new LAI and new TMSI. If the MAP_UPDATE_LOCATION_AREA confirmation contains any error, the updating request is rejected towards the MS:

- the MS will confirm receipt of the new TMSI, resulting in an empty MAP_FORWARD_NEW_TMSI response terminating the dialogue;
- if there is no confirmation received from the A-interface, the dialogue is terminated locally.

Before receiving a MAP_UPDATE_LOCATION_AREA confirmation, the MSC may receive a MAP_CHECK_IMEI indication. Handling of this indication, comprising IMEI request towards the MS and IMEI checking request towards the EIR, is given in the macro description in subclause 25.6. The result may either be to return to the state Wait for TMSI or to return to terminate.

Forwarding the Check SS Indication


When the VLR receives a MAP_FORWARD_CHECK_SS_INDICATION_Ind during the Update LOCATION Area process, this indication is relayed to the MS (see GSM 09.11 for detailed interworking) and the MSC remains in the current state.

Abort handling

If the VLR receives a MAP_U_ABORT, a MAP_P_ABORT or a premature MAP_CLOSE indication from the VLR during the location update process, the MSC terminates the process by sending an A_LU_CONFIRM containing the error cause Updating Failure to the MS. If the MSC had already confirmed the location update towards the MS, the process terminates without notification towards the A-interface.

If the MSC receives a MAP_NOTICE indication, it issues a MAP_CLOSE and terminates the A-interface dialogue, and the process terminates.

When the procedure is terminated abnormally on the radio path, the dialogue towards the VLR is aborted with the appropriate diagnostic information, and the procedure terminates.

**Figure 19.1.1/4: Process Update_Location_Area_MSC**




Figure 19.1.1/5: Macro Update_Location_Completion_MSC

19.1.1.3 Detailed procedure in the VLR

Figure 19.1.1/6 shows the process for location updating in the VLR. The following general macros are used:

Receive_Open_Ind	subclause 25.1;
Receive_Open_Cnf	subclause 25.1;
Authenticate_VLR	subclause 25.5;
Check_IMEI_VLR	subclause 25.6;
Insert_Subscriber_Data_VLR	subclause 25.7;
Obtain_IMSI_VLR to request the IMSI for the subscriber	subclause 25.8;
Activate_Tracing_VLR and Trace_Subscriber_Activity_VLR	subclause 25.9,
Subscriber_Present_VLR	subclause 25.10.

Additionally, the process specific macro

Location_Update_Completion_VLR, for optional initiation of Ciphering and TMSI reallocation as for acknowledgement of the MAP_UPDATE_LOCATION_AREA service, see figure 19.1.1/7,

and the optional process specific macro

VLR_Update_HLR to update the HLR and download subscriber data from there, see figure 19.1.1/8,

are invoked by this process.

Process Initiation

The location area updating process will be activated by receiving a MAP_UPDATE_LOCATION_AREA indication from the MSC. If there are parameter errors in the indication, the process is terminated with the appropriate error sent in the MAP_UPDATE_LOCATION_AREA response to the MSC. Else, The behaviour will depend on the subscriber identity received, either an IMSI or an TMSI.

Updating using IMSI

If the subscriber identity is an IMSI, the VLR checks whether the subscriber is unknown (i.e. no IMSI record). If so, the indicator "Location Information Confirmed in HLR" is set to "Not Confirmed" to initiate HLR updating later on. If the IMSI is known, the VLR checks whether the previous location area identification (LAI) provided in the primitive received from the MSC belongs to this VLR. If it does not, the indicator "Location Information Confirmed in HLR" is set to "Not Confirmed" to initiate HLR updating later on. The process may continue in both cases with the authentication check (see below).

Updating using TMSI

If the subscriber identity is a TMSI, the VLR checks whether the previous location area identification (LAI) provided in the primitive received from MSC belongs to an area of this VLR:

- if so, the TMSI will be checked. In case of location area change within a VLR, the TMSI should be known and the process may continue with the authentication check. Additionally, the indicator "Location Information Confirmed in HLR" is set to "Not confirmed" and the trace activity status is checked in case the target Location Area Id belongs to a new MSC.
- if the TMSI is not known or the subscriber data stored are incomplete, e.g. because the new LA belongs to a different VLR or due to VLR restoration, the indicator "Confirmed by VLR" is set to "Not Confirmed" to initiate HLR updating later on.

If the subscriber has not already been registered in the VLR, i.e. the previous LAI belongs to a different VLR, the indicators "Confirmed by HLR" and "Location Information Confirmed in HLR" are set to "Not Confirmed" and the VLR checks whether the identity of the Previous VLR (PVLR) is derivable from the previous LAI:

- if so, the IMSI and authentication parameters are requested from that VLR using the MAP_SEND_IDENTIFICATION service (see sheet 3 of figure 19.1.1/6), containing the subscriber's TMSI.

- if the dialogue is rejected by the PVLR, the process continues requesting the IMSI from the MS. In case the PVLR reverts to the MAP version Vr dialogue, the VLR will perform the respective procedure of version Vr, too, with outcomes as for the current MAP version dialogue. Else, the process waits for the respective MAP_SEND_IDENTIFICATION response from the PVLR:
 - if the IMSI is received in that primitive, the process continues with the authentication check;
 - if the IMSI is not received from the previous VLR for any reason, the dialogue to the PVLR is terminated and the IMSI will be requested from the MS;
 - if a MAP_NOTICE indication is received from the PVLR, the dialogue will be terminated by sending a MAP_CLOSE indication, and the process continues requesting the IMSI from the MS;
 - if a MAP_P_ABORT or MAP_U_ABORT indication is received from the MSC while waiting for the MAP_SEND_IDENTIFICATION response, the process is terminated;
 - if a MAP_NOTICE indication is received from the MSC while waiting for the MAP_SEND_IDENTIFICATION response, the dialogue with the PVLR will be aborted by sending a MAP_U_ABORT indication (Remote Operations Failure), the dialogue with the MSC will be terminated by sending a MAP_CLOSE and the process terminates;
- if the identity of the previous VLR cannot be derived, the process continues by requesting the IMSI from the MS.

Requesting IMSI from the MS

For requesting the IMSI from the MS, the macro Obtain_IMSI_VLR described in subclause 25.8 is invoked (see figure 19.1.1/6 sheet 3). The outcome will be:

- OK, i.e. receipt of IMSI, in which case the process continues with the authentication check described below; or
- receipt of an Absent Subscriber error, indicating that the MS did not respond. In this case the System Failure error is reported in the MAP_UPDATE_LOCATION_AREA response towards the MSC and the updating process is terminated;
- aborted, i.e. the MSC dialogue has been released while waiting for the IMSI. In this case the updating process is terminated, too.

Authentication check

After a subscriber identity has been received, either in the service indication or by an explicit request procedure, the VLR checks whether authentication of this identity is required (see figure 19.1.1/6 sheet 2). If so, the authentication macro described in subclause 25.5 is invoked. The outcome of this macro can be:

- OK, i.e. the subscriber has been authenticated successfully, in which case the process is continued by setting the indicator "Confirmed by Radio Contact" to "Confirmed" and updating the location information held in the register. Thereafter,
 - if one or both of the indicators "Confirmed by HLR" and "Location Information Confirmed in HLR" is set to "Not Confirmed", HLR updating is invoked first;
 - otherwise the process continues with the Location Update Completion VLR macro described below, and the register is updated after successful completion of this macro.
- Illegal subscriber, i.e. there was a mismatch between expected and received SRES. The VLR checks whether authentication had been performed using the TMSI, in which case a new authentication attempt with IMSI may be started (VLR operator option).
 - if so, the process continues by requesting the IMSI from the MS;
 - else, the Illegal Subscriber error is reported in the MAP_UPDATE_LOCATION_AREA response.
- Unknown Subscriber, i.e. the IMSI given is unknown in the HLR. In this case, the subscriber data are deleted in the VLR and the same error is returned in the MAP_UPDATE_LOCATION_AREA response.

- Procedure error, i.e. the authentication process was unsuccessful for some other reason, e.g. because of a failure while requesting authentication information from the HLR. In this case the System Failure error is reported in the MAP_UPDATE_LOCATION_AREA response.
- Null, indicating impossible dialogue continuation (e.g. termination of the radio path), and leading to procedure termination without any further action.

Updating the HLR

If the HLR is to be updated, the VLR_Update_HLR macro described below is performed, with one of the following results (see sheet 4 of figure 19.1.1/6):

- OK, if HLR updating has been completed successfully. The response will contain the HLR number as parameter. Next, the Location_Update_Completion VLR macro is invoked (checking amongst others the roaming restrictions and regional subscription data), and upon successful outcome of this macro the register is updated and the process terminates.
- Roaming Not Allowed, qualified by PLMN Roaming Not Allowed if the location information indicates a PLMN for which the subscriber has no subscription or if the subscribers HLR cannot be reached (e.g. SS7 links to the subscribers HPLMN do not yet exist). In this case, the error Roaming Not Allowed qualified by PLMN Roaming Not Allowed is sent in the MAP_UPDATE_LOCATION_AREA response. The Subscriber Data are deleted in the VLR.
- if Roaming Not Allowed was qualified by the parameter Operator Determined Barring, the same value is sent in the MAP_UPDATE_LOCATION_AREA response to the MSC. The subscriber data are deleted in the VLR.
- Unknown Subscriber, if the subscriber is not known in the HLR. In this case, the subscriber data are deleted in the VLR, and the same error is sent in the MAP_UPDATE_LOCATION_AREA response.
- Procedure error, if there occurs some other error during HLR updating (e.g. abort of the connection to HLR):
 - if the VLR can proceed in stand alone mode (VLR operator option), the Location Update Completion VLR macro is invoked to complete the VLR updating, and the indicator "Confirmed by HLR" remains unchanged;
 - otherwise, the System Failure error is sent in the MAP_UPDATE_LOCATION_AREA response.
- Aborted, indicating that during HLR updating the MSC dialogue has been terminated. In this case, the updating process terminates without any further action.

The macro Location Update Completion VLR

This macro completes the VLR updating process. First, the VLR checks whether there is a roaming restriction for the subscriber (see figure 19.1.1/7):

- if the target LA is not allowed for the subscriber due to national roaming restrictions, the error Roaming Not Allowed with cause National Roaming Not Allowed is returned in the MAP_UPDATE_LOCATION_AREA response towards the MSC.

The subscriber data are not deleted from VLR, to avoid unnecessary HLR updating when roaming into other LAs of the same MSC. An indication that the subscriber is not allowed to roam is set in the VLR (LA Not Allowed Flag set to not allowed). As a consequence the subscriber is not reachable (checked for MTC, SMS and MT USSD) and cannot perform outgoing actions (checked in Access Management).

- if the target LA is not allowed for the subscriber because of Roaming Restriction Due To Unsupported Feature stored in the VLR, the error Roaming Not Allowed with cause National Roaming Not Allowed is returned towards the MSC in the MAP_UPDATE_LOCATION_AREA response.

Also in this case the subscriber data are not deleted from VLR, to avoid unnecessary HLR updating when roaming into other LAs of the same MSC. The LA Not Allowed Flag is set to not allowed in the VLR.

- if the target LA is not allowed for the subscriber because of regional subscription data (Zone Code List) stored in the VLR, the error Roaming Not Allowed with cause Location Area Not Allowed is returned towards the MSC in the MAP_UPDATE_LOCATION_AREA response.

Also in this case the subscriber data are not deleted from VLR, to avoid unnecessary HLR updating when roaming into other LAs of the same MSC. The LA Not Allowed Flag is set to not allowed in the VLR.

- if, after check of possible roaming restrictions, the subscriber is allowed to roam in the target LA, the LA Not Allowed Flag is set to allowed (if necessary), the IMSI Detached Flag is set to attached and the process SUBSCRIBER_PRESENT_VLR is started; this may inform the HLR that the subscriber is present again to retry an SMS delivery (see subclause 19.1.1.7). Thereafter, the VLR checks whether TMSI reallocation is required.
- if so, the VLR sends a MAP_SET_CIPHERING_MODE request containing:
 - Ciphering Mode (version 1 GSM); and
 - Kc, the cipher key to be used.
- if IMEI checking is required by the operator, the VLR will invoke the CHECK_IMEI_VLR macro (see subclause 25.6) to initiate both requesting IMEI from the MS and checking of this IMEI towards the EIR. As result either the service is granted, with process continuation as given below, or the service is rejected, in which case the VLR marks the subscriber as detached and returns an Illegal Equipment error in the MAP_UPDATE_LOCATION_AREA response before the process terminates.
- the VLR then sends a MAP_FORWARD_NEW_TMSI request containing the new TMSI, and the MAP_UPDATE_LOCATION_AREA response containing no parameters. The process will thereafter wait for the MAP_FORWARD_NEW_TMSI confirm. If this indicates a negative outcome, or if a MAP_P_ABORT or a MAP_U_ABORT primitive is received, the old TMSI is frozen. Subsequent accesses of the MS shall be accepted with both old or new TMSI.
- if TMSI reallocation is not required, the VLR invokes the CHECK_IMEI_VLR macro (see subclause 25.6) to initiate both requesting IMEI from the MS and checking of this IMEI towards the EIR, if IMEI Checking is required by the operator. As a result, either the service is granted, in which case the MAP_UPDATE_LOCATION_AREA response is sent without any parameters, or the service is rejected, in which case an Illegal Equipment error is returned in the MAP_UPDATE_LOCATION_AREA response, before the process terminates.

In all cases where the VLR sends a MAP_UPDATE_LOCATION_AREA response to the MSC, the dialogue towards the MSC is terminated by a MAP_CLOSE request with parameter Release Method indicating Normal Release.

The macro VLR Update HLR

This macro is invoked by the VLR process for location updating or by some other process handling the first subscriber access to the network after a register failure in order to perform HLR updating. If the VLR does not know the subscribers HLR (e.g. no IMSI translation exists as there are not yet any SS7 links to the subscribers HPLMN), the error Roaming Not Allowed with cause PLMN Roaming Not Allowed is returned.

If the subscribers HLR can be reached, the VLR opens a dialogue towards the HLR (see figure 19.1.1/8) by sending a MAP_OPEN request without any user specific parameters, together with a MAP_UPDATE_LOCATION request containing the parameters

- IMSI, identifying the subscriber;
- Location Info, containing the MSC number;
- VLR Number, the E.164 address of the VLR, to be used by the HLR when addressing the VLR henceforth (e.g. when requesting an MSRN);
- the LMSI as an VLR operator option; this is a subscriber identification local to the VLR, used for fast data base access.

In case the HLR rejects dialogue opening (see subclause 25.1), the VLR will terminate the procedure indicating procedure error. If the HLR indicates version Vr protocol to be used, the VLR will revert to the version Vr procedure concerning the dialogue with the HLR, with outcomes as for the current MAP version procedure.

If the HLR accepts the dialogue, the HLR will respond with:

- a MAP_INSERT_SUBSCRIBER_DATA indication, handled by the macro Insert_Subs_Data_VLR defined in subclause 25.7;

NOTE: The HLR may repeat this service several times depending on the amount of data to be transferred to the VLR and to replace subscription data in case they are not supported by the VLR.

- a MAP_ACTIVATE_TRACE_MODE indication, handled by the macro Activate_Tracing_VLR defined in subclause 25.9;
- a MAP_FORWARD_CHECK_SS_INDICATION_ind. This indication will be relayed to the MSC without any change of the current state.
- the MAP_UPDATE_LOCATION confirmation:
 - if this confirmation contains the HLR Number, this indicates that the HLR has passed all information and that updating has been successfully completed. The VLR is updated using the parameters provided in the service and needed by the VLR. If certain parameters are not needed in the VLR, e.g. because some service is not supported, the corresponding data may be discarded. The VLR sets the "Confirmed by HLR" and "Location information confirmed in HLR" indicators to "Confirmed" to indicate successful subscriber data updating;
 - if the confirmation contains an User error cause (Unknown Subscriber, Roaming Not Allowed or some other), the process calling the macro continues accordingly. In the last case, the subscriber data are marked as incomplete by setting the indicators "Confirmed by HLR" and "Location information confirmed in HLR" to "Not Confirmed". The same holds if there is a Provider error or a Data error in the confirmation;
- a MAP_P_ABORT, MAP_U_ABORT, or MAP_CLOSE indication. In these cases, the subscriber data are marked to be incomplete and the process continues as in the case of an error reported by the HLR;
- a MAP_NOTICE indication. Then, the dialogue towards the HLR is terminated, the subscriber data are marked to be incomplete and the process continues as in the case of an error reported by the HLR;
- if during HLR updating the VLR receives a MAP_P_ABORT, MAP_U_ABORT or a MAP_CLOSE indication concerning the MSC dialogue, the process is terminated by sending a MAP_U_ABORT request towards the HLR, and subscriber data are marked to be incomplete;
- if during HLR updating the VLR receives a MAP_NOTICE indication concerning the MSC dialogue, the dialogue with the MSC is terminated by sending a MAP_CLOSE, the dialogue with the HLR is terminated by sending a MAP_U_ABORT, subscriber data are marked to be incomplete and the process is terminated.

Abort Handling

If the VLR receives a MAP_NOTICE indication from the MSC while waiting for a MAP service primitive, the VLR will terminate the MSC dialogue by sending a MAP_CLOSE and any pending HLR dialogue by sending a MAP_U_ABORT (Remote Operations Failure), and the process is terminated.

Updating request via the Gs interface (optional for GPRS)

If Gs-interface is installed, the VLR may receive the Gs_GPRS_LOCATION_UPDATING_Request message from the SGSN for triggering an IMSI Attach or Location Updating procedure (see GSM 03.60 and 09.18).

Figure 19.1.1/16 shows the process for handling this Gs interface message.

The process specific macro

« GPRS_Location_Update_Completion_VLR » for optional initiation of TMSI reallocation as for acknowledgement of the Gs_GPRS_LOCATION_UPDATING_Request message (see figure 19.1.1/17),

and the optional process specific macro

« VLR_Update_GPRS_HLR » to update the HLR and download subscriber data from there (see figure 19.1.1/18), are invoked by this process.

On receipt of the Gs_GPRS_LOCATION_UPDATING_Request message, the VLR checks whether the subscriber is unknown (i.e. no IMSI record). If so, the indicator "Location Information Confirmed in HLR" is set to "Not Confirmed" to initiate HLR updating later on. The indicator "Confirmed by Radio Contact" is set to "Confirmed" and the location information held in the register is updated. If no VLR/SGSN association exists it is created (storage of SGSN address received) otherwise it is updated.

If the HLR is to be updated, the VLR_Update_GPRS_HLR macro described below is performed, with one of the following results (see sheet 2 of figure 19.1.1/18):

- OK, if HLR updating has been completed successfully. The response will contain the HLR number as parameter. Next, the GPRS_Location_Update_Completion VLR macro is invoked (checking amongst others the roaming restrictions and regional subscription data), and upon successful outcome of this macro the register is updated and the process terminates.
- Roaming Not Allowed, qualified by PLMN Roaming Not Allowed if the location information indicates a PLMN for which the subscriber has no subscription or if the subscribers HLR cannot be reached (e.g. SS7 links to the subscribers HPLMN do not yet exist). In this case, the appropriate error (see GSM 09.18) is sent to the SGSN in the Gs_GPRS_LOCATION_UPDATING Reject. The Subscriber Data are deleted in the VLR.
- if Roaming Not Allowed was qualified by the parameter Operator Determined Barring, the appropriate error (see GSM 09.18) is sent in the Gs_GPRS_LOCATION_UPDATING Reject to the SGSN. The subscriber data are deleted in the VLR.
- Unknown Subscriber, if the subscriber is not known in the HLR. In this case, the subscriber data are deleted in the VLR, and the appropriate error (see GSM 09.18) is sent in the Gs_GPRS_LOCATION_UPDATING Reject.
- Procedure error, if there occurs some other error during HLR updating (e.g. abort of the connection to HLR). In this case the appropriate error (see GSM 09.18) is sent in the Gs_GPRS_LOCATION_UPDATING Reject.

The macro GPRS Location Update Completion VLR

This macro completes the VLR updating process. First, the VLR checks whether there is a roaming restriction for the subscriber (see figure 19.1.1/17):

- if the target LA is not allowed for the subscriber due to national roaming restrictions, the appropriate error (see GSM 09.18) is sent in the Gs_GPRS_LOCATION_UPDATING Reject towards the SGSN.

The subscriber data are not deleted from VLR, to avoid unnecessary HLR updating when roaming into other LAs of the same MSC/VLR. An indication that the subscriber is not allowed to roam is set in the VLR (LA Not Allowed Flag set to not allowed). As a consequence the subscriber is not reachable (checked for MTC, SMS and MT USSD) and cannot perform outgoing actions (checked in Access Management).

- if the target LA is not allowed for the subscriber because of regional subscription data (Zone Code List) or Roaming Restriction Due To Unsupported Feature stored in the VLR, the appropriate error (see GSM 09.18) is returned to the SGSN in the Gs_GPRS_LOCATION_UPDATING Reject.

Also in this case the subscriber data are not deleted from VLR, to avoid unnecessary HLR updating when roaming into other LAs of the same MSC. The LA Not Allowed Flag is set to not allowed in the VLR.

- if, after check of possible roaming restrictions, the subscriber is allowed to roam in the target LA, the LA Not Allowed Flag is set to allowed (if necessary), the IMSI Detached Flag is set to attached and the process SUBSCRIBER_PRESENT_VLR is started; this may inform the HLR that the subscriber is present again to retry an SMS delivery (see subclause 19.1.1.7). Thereafter, the VLR checks whether TMSI reallocation is required.
 - if so, the VLR sends the TMSI within the Gs_GPRS_LOCATION_UPDATING Accept message and Gs_GPRS_TMSI_REALLOCATION_Complete is expected.
- if TMSI reallocation is not required, the VLR sends the Gs_GPRS_LOCATION_UPDATING Accept message to the SGSN.

The macro VLR Update GPRS HLR

This macro is invoked by the VLR process for location updating (see GSM 03.60). If the VLR does not know the subscribers HLR (e.g. no IMSI translation exists as there are not yet any SS7 links to the subscribers HPLMN), the error Roaming Not Allowed with cause PLMN Roaming Not Allowed is returned.

If the subscribers HLR can be reached, the VLR opens a dialogue towards the HLR (see figure 19.1.1/18) by sending a MAP_OPEN request without any user specific parameters, together with a MAP_UPDATE_LOCATION request containing the parameters

- IMSI, identifying the subscriber;
- Location Info, containing the MSC number;
- VLR Number, the E.164 address of the VLR, to be used by the HLR when addressing the VLR henceforth (e.g. when requesting an MSRN);
- the LMSI as an VLR operator option; this is a subscriber identification local to the VLR, used for fast data base access.


In case the HLR rejects dialogue opening (see subclause 25.1), the VLR will terminate the procedure indicating procedure error. If the HLR indicates version Vr protocol to be used, the VLR will revert to the version Vr procedure concerning the dialogue with the HLR, with outcomes as for the current MAP version procedure.

If the HLR accepts the dialogue, the HLR will respond with:

- a MAP_INSERT_SUBSCRIBER_DATA indication, handled by the macro Insert_Subs_Data_VLR defined in subclause 25.7;

NOTE: The HLR may repeat this service several times depending on the amount of data to be transferred to the VLR and to replace subscription data in case they are not supported by the VLR.

- a MAP_ACTIVATE_TRACE_MODE indication, handled by the macro Activate_Tracing_VLR defined in subclause 25.9;
- a MAP_FORWARD_CHECK_SS_INDICATION_ind. This indication will not be relayed to the SGSN.
- the MAP_UPDATE_LOCATION confirmation:
 - if this confirmation contains the HLR Number, this indicates that the HLR has passed all information and that updating has been successfully completed. The VLR is updated using the parameters provided in the service and needed by the VLR. If certain parameters are not needed in the VLR, e.g. because some service is not supported, the corresponding data may be discarded. The VLR sets the "Confirmed by HLR" and "Location information confirmed in HLR" indicators to "Confirmed" to indicate successful subscriber data updating;
 - if the confirmation contains an User error cause (Unknown Subscriber, Roaming Not Allowed or some other), the process calling the macro continues accordingly. In the last case, the subscriber data are marked as incomplete by setting the indicators "Confirmed by HLR" and "Location information confirmed in HLR" to "Not Confirmed". The same holds if there is a Provider error or a Data error in the confirmation;
- a MAP_P_ABORT, MAP_U_ABORT, or MAP_CLOSE indication. In these cases, the subscriber data are marked to be incomplete and the process continues as in the case of an error reported by the HLR;
- a MAP_NOTICE indication. Then, the dialogue towards the HLR is terminated, the subscriber data are marked to be incomplete and the process continues as in the case of an error reported by the HLR.

**Figure 19.1.1/6 (sheet 1 of 4): Process Update_Location_Area_VLR**




Figure 19.1.1/6 (sheet 2 of 4): Process Update_Location_Area_VLR




Figure 19.1.1/6 (sheet 3 of 4): Process Update_Location_Area_VLR




Figure 19.1.1/6 (sheet 4 of 4): Process Update_Location_Area_VLR




Figure 19.1.1/7: Macro Location_Update_Completion_VLR




Figure 19.1.1/8 (sheet 1 of 2): Macro VLR_Update_HLR




Figure 19.1.1/8 (sheet 2 of 2): Macro VLR_Update_HLR




Figure 19.1.1/16 (sheet 1 of 2): Process GPRS_Update_Location_Area_VLR





Figure 19.1.1/16 (sheet 2 of 2): Process GPRS_Update_Location_Area_VLR

**Figure 19.1.1/17: Macro GPRS_Location_Update_Completion_VLR**




Figure 19.1.1/18 (sheet 1 of 2): Macro VLR_Update_GPRS_HLR




Figure 19.1.1/18 (sheet 2 of 2): Macro VLR_Update_GPRS_HLR

19.1.1.4 Detailed procedure in the HLR

When addressed by the VLR, the following macros are used by the process Update_Location_HLR:

- Receive_Open_Ind, defined in subclause 25.1;
- Check_indication, defined in subclause 25.2;
- Insert_Subs_Data_Framed_HLR, described in subclause 19.4.1;
- Control_Tracing_HLR, described in subclause 25.9;

and the processes Cancel_Location_HLR (see subclause 19.1.2) and Subscriber_Present_HLR (see subclause 19.1.1.7) are invoked.

The location updating process in the HLR is activated by receipt of a MAP_UPDATE_LOCATION indication (see figure 19.1.1/9):

- if there is a parameter problem in the indication, the error Unexpected Data Value is returned in the MAP_UPDATE_LOCATION response (see Check_indication macro defined in subclause 25.2); if the subscriber is not known in the HLR, the error Unknown Subscriber is returned in the response. In either case the process terminates;
- if Network Access Mode is set to "GPRS only" the error Unknown Subscriber is returned in the response. The process terminates;
- tracing shall be set to deactivate in the VLR
- if the VLR address received in the MAP_UPDATE_LOCATION indication differs from the one actually stored against the subscriber, the Cancel_Location_HLR process is started to cancel the subscriber data in the stored VLR (see subclause 19.1.2).

The next action will be to check whether the subscriber is allowed to roam into the PLMN indicated by the VLR Number given in the MAP_UPDATE_LOCATION indication:

- if the subscriber is not allowed to roam into the PLMN, the error Roaming not Allowed with cause PLMN Roaming Not Allowed is returned in the MAP_UPDATE_LOCATION response, and the routing information stored (VLR number, MSC Number, LMSI) is deleted (deregistration);
- otherwise the HLR database will be updated with information received in the indication. The HLR sets the "MS purged for non-GPRS" flag to False and checks whether tracing is required for that subscriber. This is handled by the macro Control_Tracing_HLR described in subclause 25.9.

Thereafter, the macro Insert_Subs_Data_Framed_HLR described in subclause 19.4.1 is invoked. The outcome of this macro may be:

- aborted, in which case the process terminates;
- error, in which case the error System Failure is returned in the MAP_UPDATE_LOCATION response and the process terminates;
- OK, indicating successful outcome of downloading the subscriber data to the VLR.

The SUBSCRIBER_PRESENT_HLR process is then started to alert the Short Message Service Centre, if required (see subclause 19.1.7). Additionally, the MAP_FORWARD_CHECK_SS_INDICATION request is sent to inform the subscriber about an uncertain state of his SS-Data if this is needed due to previous HLR restoration (use of this service may be omitted as an HLR operator option).

The HLR number is then returned in the MAP_UPDATE_LOCATION response.

In all cases where the HLR sends a MAP_UPDATE_LOCATION response to the VLR, the dialogue towards the VLR is terminated by a MAP_CLOSE request with parameter Release Method indicating Normal Release.

Finally the process Update_Location_HLR sends a "Location updating complete" message to the process CCBS_Coordinator_HLR (specified in GSM 03.93 [107]) and the process terminates.

When addressed by the SGSN, the following macros are used by the process Update_GPRS_Location_HLR:

- Receive_Open_indication, defined in subclause 25.1;
- Check_indication, defined in subclause 25.2;
- Insert_Subs_Data_In_SGSN_Framed_HLR, described in subclause 19.4.x;
- Control_Tracing_HLR_with_SGSN, described in subclause 25.9;

and the processes Cancel_Location_HLR (see subclause 19.1.2) and Subscriber_Present_HLR (see subclause 19.1.1.7) are invoked.

The location updating process in the HLR is activated by receipt of a MAP_UPDATE_GPRS_LOCATION indication (see figure 19.1.1/19):

- if there is a parameter problem in the indication, the error Unexpected Data Value is returned in the MAP_UPDATE_LOCATION response (see Check_indication macro defined in subclause 25.2); if the subscriber is not known in the HLR, the error Unknown Subscriber (with diagnostic value set to "Imsi Unknown") is returned in the response. In either case the process terminates;
- if Network Access Mode is set to "non-GPRS only" the error Unknown Subscriber (with diagnostic value set to "Gprs Subscription Unknown") is returned in the response. The process terminates;
- tracing shall be set to deactivate in the SGSN.
- if the SGSN number received in the MAP_UPDATE_GPRS_LOCATION indication differs from the one actually stored against the subscriber, the Cancel_Location_HLR process is started to cancel the subscriber data in the stored SGSN (see subclause 19.1.2).

The next action will be to check whether the subscriber is allowed to roam into the PLMN indicated by the SGSN Number given in the MAP_UPDATE_GPRS_LOCATION indication:

- if the subscriber is not allowed to roam into the PLMN, the error Roaming not Allowed with cause PLMN Roaming Not Allowed or 'Operator determined Barring', depending on the case, is returned in the MAP_UPDATE_GPRS_LOCATION response, and the routing information stored (SGSN number) is deleted (deregistration);
- otherwise the HLR database will be updated with information received in the indication. The HLR sets the "MS purged for GPRS" flag to False and checks whether tracing is required for that subscriber. This is handled by the macro Control_Tracing_HLR-with_SGSN described in subclause 25.9.

Thereafter, the macro Insert_Subs_Data_In_SGSN_Framed_HLR described in subclause 19.4.x is invoked. The outcome of this macro may be:

- aborted, in which case the process terminates;
- error, in which case the error System Failure is returned in the MAP_UPDATE_GPRS_LOCATION response and the process terminates;
- OK, indicating successful outcome of downloading the subscriber data to the SGSN.

The SUBSCRIBER_PRESENT_HLR process is then started to alert the Short Message Service Centre, if required (see subclause 19.1.7).

Finally the HLR number is returned in the MAP_UPDATE_GPRS_LOCATION response.

In all cases where the HLR sends a MAP_UPDATE_GPRS_LOCATION response to the SGSN, the dialogue towards the SGSN is terminated by a MAP_CLOSE request with parameter Release Method indicating Normal Release.




Figure 19.1.1/9 (sheet 1 of 2): Process Update_Location_HLR




Figure 19.1.1/9 (sheet 2 of 2): Process Update_Location_HLR




Figure 19.1.1/19 (sheet 1 of 2): Process Update_GPRS_Location_HLR

Process Update_GPRS_Location_HLR

19.1.1_19.2(2)

Figure 19.1.1/19: GPRS Location Updating in the HLR




Signals to/from the left
are to/from the HLR

Figure 19.1.1/19 (sheet 2 of 2): Process Update_GPRS_Location_HLR

19.1.1.5 Send Identification

19.1.1.5.1 General

This service is invoked by a VLR when it receives a MAP_UPDATE_LOCATION_AREA indication containing a LAI indicating that the subscriber was registered in a different VLR (henceforth called the Previous VLR, PVLR). If the identity of the PVLR is derivable for the VLR (usually if both are within the same network), the IMSI and authentication sets are requested from the PVLR (see subclause 19.1.1.3), using the service described in subclause 8.1.4.



NOTE: The service shown in dotted lines indicates the trigger provided by other MAP signalling.

Figure 19.1.1/10: Interface and services for Send Identification

19.1.1.5.2 Detailed procedure in the VLR

The VLR procedure is part of the location area updating process described in subclause 19.1.1.3, see also figure 19.1.1/6 sheet 3.

19.1.1.5.3 Detailed procedure in the PVLR

On receipt of a dialogue request for the Send Identification procedure, (see Receive_Open_Ind macro in subclause 25.1), the PVLR will:

- terminate the procedure in case of parameter problems;
- revert to the MAP version Vr procedure in case the VLR indicated version Vr protocol; or
- continue as below, if the dialogue is accepted.

If the PVLR process receives a MAP_NOTICE indication, it terminates the dialogue by sending a MAP_CLOSE request.

If the PVLR process receives a MAP_SEND_IDENTIFICATION indication from the VLR (see figure 19.1.1/11), it checks whether the subscriber identity provided is known:

- if so, the IMSI and - if available - authentication parameters for the subscriber are returned in the MAP_SEND_IDENTIFICATION response;
- if not, the error Unidentified Subscriber is returned in the MAP_SEND_IDENTIFICATION response.

In all cases where the PVLR sends a MAP_SEND_IDENTIFICATION response to the VLR, the dialogue towards the VLR is terminated by a MAP_CLOSE request with parameter Release Method indicating Normal Release.




Figure 19.1.1/11: Process Send_Identification_PVLR

19.1.1.6 The Process Update Location VLR

This process is started by some other MAP user process in case the HLR need to be updated due to previous network failure. It is invoked when the subscriber accesses the network, e.g. for mobile originated call set-up, response to paging or supplementary services handling. Here, location updating consists only of invoking the macro VLR_Update_HLR described above (see subclause 19.1.1.3), which performs HLR updating and downloading of subscriber data.

If updating is successful (OK) the HLR Number is received in the MAP_UPDATE_LOCATION confirm primitive and the process terminates.

If one of the errors Roaming not Allowed or Unknown Subscriber is received instead, all subscriber data are deleted from the VLR before the process terminates.

In case some other error occurs during HLR updating, the process simply terminates. Note, in all error cases the initiating restoration flags in VLR remain false, therefore a new HLR updating attempt will be started later on.

NOTE: This process will be performed independent from the calling process, no coordination is required.




Figure 19.1.1/12: Process UL_VLR

19.1.1.7 The Process Subscriber Present HLR

The process Subscriber Present HLR is started by the location updating process in HLR to perform actions required for short message alerting. The process checks the Message Waiting Data flag, and if this is set, the macro Alert_Service_Centre_HLR defined in subclause 25.10 is invoked. This macro will alert all service centres from which there are short messages waiting for this subscriber.

Process Subscriber_Present_HLR

19.1.1_13(1)

Figure 19.1.1/13: Process Subscriber_Present_HLR




Figure 19.1.1/13: Process Subscriber_Present_HLR

19.1.1.8 Detailed procedure in the SGSN

Figure 19.1.1/20 shows the MAP process for updating of the SGSN. The following general macros are used:

Receive_Open_Cnf	subclause 25.1;
Insert_Subscriber_Data_SGSN	subclause 25.7;
Activate_Tracing_SGSN	subclause 25.9;

The location updating process

The MAP process receives an « Update HLR request » from the relevant process in the SGSN (see GSM 03.60) to perform HLR updating. If the SGSN does not know the subscribers HLR (e.g. no IMSI translation exists as there are not yet any SS7 links to the subscribers HPLMN), the « Update HLR negative response » with error Unknown HLR is returned to the requesting process.

If the subscribers HLR can be reached, the SGSN opens a dialogue towards the HLR by sending a MAP_OPEN request without any user specific parameters, together with a MAP_UPDATE_GPRS_LOCATION request containing the parameters

- IMSI, identifying the subscriber;
- SGSN Address and SGSN number;

In case the HLR rejects dialogue opening (see subclause 25.1) or indicates version Vr protocol to be used, the SGSN will terminate the process indicating « Update HLR negative response » to the requesting process.

If the HLR accepts the dialogue, the HLR will respond with:

- a MAP_INSERT_SUBSCRIBER_DATA indication, handled by the macro Insert_Subs_Data_SGSN defined in subclause 25.7;

NOTE: The HLR may repeat this service several times depending on the amount of data to be transferred to the SGSN and to replace subscription data in case they are not supported by the SGSN.

- a MAP_ACTIVATE_TRACE_MODE indication, handled by the macro Activate_Tracing_SGSN defined in subclause 25.9;
- the MAP_UPDATE_GPRS_LOCATION confirmation:
 - if this confirmation contains the HLR Number, this indicates that the HLR has passed all information and that updating has been successfully completed. The « Update HLR response » message is returned to the requesting process for completion of the SGSN updating (see GSM 03.60).
 - if the confirmation contains an User error cause (Unknown Subscriber, Roaming Not Allowed or some other), the corresponding error is returned to the requesting process in the « Update HLR negative response ».
- a MAP_P_ABORT, MAP_U_ABORT, or MAP_CLOSE indication. In these cases, the corresponding error is returned to the requesting process in the « Update HLR negative response ».
- a MAP_NOTICE indication. Then, the dialogue towards the HLR is terminated, and the « HLR Update negative response » with the appropriate error is returned to the requesting process.




Figure 19.1.1/20 (sheet 1 of 2): Process SGSN_Update_HLR




Figure 19.1.1/20 (sheet 2 of 2): Process SGSN_Update_HLR


19.1.2 Location Cancellation

19.1.2.1 General

The purpose of this process is to delete a subscriber's record from a previous visitor location register after she has registered with a new visitor location register. Also this process is used to delete a subscriber's record from a old SGSN after she has registered with a SGSN. The procedure may also be used if the subscriber's record is to be deleted for other operator determined purposes, e.g. withdrawal of subscription, imposition of roaming restrictions or modifications to the subscription which result in roaming restrictions. Location cancellation can be used to enforce location updating including updating of subscriber data in the VLR or in the SGSN at the next subscriber access.


In all cases, the process is performed independently of the invoking process (e.g. Location Updating).

The service as described in subclause 8.1.3 is invoked when an HLR receives a MAP_UPDATE_LOCATION indication from a VLR other than that stored in its table for this subscriber. Also the MAP_CANCEL_LOCATION service is invoked when the HLR receives a MAP_UPDATE_GPRS_LOCATION indication from a SGSN other than stored in its table for this subscriber. Additionally the service may be invoked by operator intervention. The MAP_CANCEL_LOCATION service is in any case invoked towards the VLR or the SGSN whose identity is contained in the HLR table.



NOTE: The service shown in dotted lines indicates the trigger provided by other MAP signalling.

Figure 19.1.2/1: Interface and services for Location Cancellation



NOTE: The service shown in dotted lines indicates the trigger provided by other MAP signalling.

Figure 19.1.2/6: Interface and services for Location Cancellation in GPRS

19.1.2.2 Detailed procedure in the HLR

The location cancellation process is started by an external process as stated above. The HLR opens a dialogue with the VLR or with the SGSN whose identity is contained in the HLR table (MAP_OPEN request without any user specific parameters), sending the MAP_CANCEL_LOCATION request primitive (see figures 16.1.2/2 and 16.1.2/4), containing the parameters:

- IMSI, to identify the subscriber to be deleted from that VLR or SGSN;
- LMSI, which is included if available in the HLR. LMSI is not applicable between HLR and SGSN;
- Cancellation Type if the Cancel Location is sent to SGSN. Cancellation Type is not applicable between HLR and VLR. If the VLR receives this parameter and do not understand it this parameter shall be ignored.

The HLR then waits for the MAP_OPEN confirmation (see macro Receive_Open_Cnf, subclause 21.1), indicating either:

- reject of the dialogue (process terminates);
- reversion to version Vr when the operation is sent to SGSN (process terminates);
- reversion to version Vr when the operation is sent to VLR (process will be performed according to MAP version Vr); or
- dialogue acceptance.

When the VLR or the SGSN accepts the dialogue, it will return a MAP_CANCEL_LOCATION confirmation, containing:

- no parameter, indicating successful outcome of the procedure;
- a user error, provider error or a data error indicating unsuccessful outcome of the procedure.

In case of unsuccessful outcome or if a MAP_P_ABORT indication has been received, the HLR may repeat the MAP_CANCEL_LOCATION request later, where the number of repeat attempts and time in between are HLR operator options, depending on the error returned by the VLR or the SGSN.

19.1.2.3 Detailed procedure in the VLR

Opening of the dialogue is described in the macro Receive_Open_Ind in subclause 25.1, with outcomes:

- reversion to version Vr procedure;
- procedure termination; or
- dialogue acceptance, with processing as below.

If the VLR process receives a MAP_NOTICE indication, it terminates the dialogue by sending a MAP_CLOSE request.

If the VLR process receives a MAP_CANCEL_LOCATION indication from the HLR (see figure 19.1.2/3), the parameters are checked first (macro Check_Indication, see subclause 25.2). In case of parameter problems the appropriate error is sent in the MAP_CANCEL_LOCATION response.

If the MAP_CANCEL_LOCATION indication contains both the IMSI and the LMSI, the VLR checks whether the stored IMSI matches the received IMSI. If it does not, the VLR attempts to process the request using the IMSI received from the HLR to define the subscriber record to be deleted.

Thereafter the VLR checks whether the subscriber identity provided is known in the VLR:

- if so, the data of the subscriber are deleted from VLR table and a MAP_CANCEL_LOCATION response is returned without any parameters;
- if not, location cancellation is regarded as being successful, too, and the MAP_CANCEL_LOCATION response is returned without any parameters.

In either case, after sending the MAP_CANCEL_LOCATION response the VLR process releases any TMSI which may be associated with the IMSI of the subscriber, terminates the dialogue (MAP_CLOSE with Release Method Normal Release) and returns to the idle state.




Figure 19.1.2/2: Process Cancel_Location_HLR




Figure 19.1.2/3: Process Cancel_Location_VLR

19.1.2.4 Detailed procedure in the SGSN

Opening of the dialogue is described in the macro Receive_Open_Ind in subclause 25.1, with outcomes:

- procedure termination; or
- dialogue acceptance, with processing as below.

If the SGSN process receives a MAP_NOTICE indication, it terminates the dialogue by sending a MAP_CLOSE request.

If the SGSN process receives a MAP_CANCEL_LOCATION indication from the HLR (see figure 19.1.2/4), the parameters are checked first (macro Check_Indication, see subclause 25.2). In case of parameter problems the appropriate error is sent in the MAP_CANCEL_LOCATION response.

Thereafter the SGSN checks whether the subscriber identity provided is known in the SGSN:

- if so, the data of the subscriber are deleted from SGSN table and a MAP_CANCEL_LOCATION response is returned without any parameters;
- if not, location cancellation is regarded as being successful, too, and the MAP_CANCEL_LOCATION response is returned without any parameters.

In either case, after sending the MAP_CANCEL_LOCATION response the SGSN process releases any P-TMSI which may be associated with the IMSI of the subscriber, terminates the dialogue (MAP_CLOSE with Release Method Normal Release) and returns to the idle state.





Figure 19.1.2/4: Process Cancel_GPRS_Location_HLR


**Figure 19.1.2/5: Process Cancel_Location_SGSN**

19.1.3 Detach IMSI

19.1.3.1 General

On receipt of an A_LU_REQUEST (DETACH IMSI) indication from the radio interface this procedure invokes the MAP_DETACH_IMSI service described in subclause 8.1.5 in order to inform the visitor location register that a subscriber is no longer reachable (see figure 19.1.3/1), e.g. due to switched off station. This information is used by the VLR to reject mobile terminating calls or short messages without sending page messages on the radio path. The service is unconfirmed as it is likely that the MS is switched off before receiving a confirmation.

The detach IMSI feature is optional for the network operator. The MS is informed by the network whether detach IMSI is to be used or not.



NOTE: The service shown in dotted lines indicates the trigger provided by the radio interface (see GSM 09.10).

Figure 19.1.3/1: Interface and services for MAP_DETACH_IMSI

If the Gs interface is installed, the procedures to handle an IMSI Detach or a GPRS Detach request from the SGSN via the Gs interface do not require any signalling over the MAP interface. These procedures are specified in GSM 03.60 and 09.18.

19.1.3.2 Detailed procedure in the MSC

The MAP_DETACH_IMSI service is invoked by the MSC when receiving an A_LU_Request (DETACH IMSI) for a subscriber (see figure 19.1.3/2).

The MSC will open the dialogue to the VLR with a MAP_OPEN request containing no user specific parameters. The MAP_DETACH_IMSI request will contain the following parameter received from the radio side (for the mapping see GSM 09.10):

- Subscriber Id, being either a TMSI or an IMSI.

The MSC then waits for the MAP_OPEN confirmation (see macro Receive_Open_Cnf, subclause 25.1), indicating either:

- reject of dialogue (process terminates);
- reversion to version Vr(process terminates); or
- dialogue acceptance.

Thereafter, the dialogue is terminated locally by the MSC (MAP_CLOSE request with Release Method Prearranged End).

19.1.3.3 Detailed procedure in the VLR

When the VLR receives a MAP_DETACH_IMSI indication (see figure 19.1.3/3), it first checks the indication data (macro Check_Indication, see subclause 25.2). Thereafter it is checked whether the subscriber is known:

- if the subscriber is unknown the VLR ignores the indication;
- if the subscriber is known in the VLR, the IMSI detached flag is set.

The VLR process will terminate the dialogue locally (MAP_CLOSE request with Release Method Prearranged End).




Figure 19.1.3/2: Process Detach_IMSI_MSC




Figure 19.1.3/3: Process Detach_IMSI_VLR

19.1.4 Purge MS

19.1.4.1 General

When the VLR or the SGSN receives an indication on the O&M interface that the MS record is to be purged (either because of administrative action or because the MS has been inactive for an extended period), this procedure invokes the MAP_PURGE_MS service described in subclause 8.1.6 to request the HLR to set the "MS purged for non-GPRS" or the "MS purged for GPRS" flag for the MS so that any request for routing information for a mobile terminated call or a mobile terminated short message will be treated as if the MS is not reachable. The message flows are shown in figures 19.1.4/1 and 19.1.4/5.

It is optional for the network operator to delete MS records from the VLR or from the SGSN, but if the option is used the VLR or the SGSN shall notify the HLR when a record has been deleted.

The O&M process in the VLR or in the SGSN must ensure that during the MS purging procedure any other attempt to access the MS record is blocked, to maintain consistency of data.




Figure 19.1.4/1: MAP-D Interface and services for MAP_PURGE_MS




Figure 19.1.4/5: Gr Interface and services for MAP_PURGE_MS

19.1.4.2 Detailed procedure in the VLR

When the VLR receives an indication from O&M that an MS record is to be purged, it invokes the MAP_PURGE_MS service (see figure 19.1.4/2).

The VLR opens the dialogue to the HLR with a MAP_OPEN request containing no user specific parameters. The MAP_PURGE_MS request contains the IMSI of the MS which is to be purged and the VLR number.

The VLR then waits for the MAP_OPEN confirmation (see macro Receive_Open_Cnf, subclause 25.1), indicating one of:

- rejection of the dialogue (process terminates);
- reversion to version one (process terminates);
- dialogue acceptance.

If the HLR accepts the dialogue it returns a MAP_PURGE_MS confirmation, containing no parameter, indicating successful outcome of the procedure.

If a MAP_PURGE_MS confirmation containing a provider error, data error or user error, or a MAP_P_ABORT, MAP_NOTICE or premature MAP_CLOSE indication, has been received, the failure is reported to the O&M interface.

Successful outcome of the procedure leads to deletion of the subscriber data and freezing of the TMSI if so requested by the HLR, and is reported to the O&M interface.

19.1.4.3 Detailed procedure in the HLR

Opening of the dialogue is described in the macro Receive_Open_Ind in subclause 25.1. The possible outcomes are:

- termination of the procedure if the AC indicates a version 1 dialogue, as this procedure is not defined for version 1;
- termination of the procedure if there is an error;
- dialogue acceptance, in which case the procedure is as described below.

If the HLR receives a MAP_NOTICE indication, it terminates the dialogue by sending a MAP_CLOSE request.

If the HLR receives a MAP_PURGE_MS indication (see figure 19.1.4/3), it first checks the indication data (macro Check_Indication, see subclause 25.2). If there is a parameter error the HLR terminates the dialogue by sending an appropriate error in the MAP_PURGE_MS response in a MAP_CLOSE request. If there is no parameter error the HLR then checks whether the subscriber is known.

- if the subscriber is unknown, the HLR reports an error to the O&M interface, the error Unknown Subscriber is returned in the MAP_PURGE_MS response and the dialogue is terminated by sending a MAP_CLOSE request ;
- if the subscriber is known, the HLR checks whether the purging notification came from the VLR or SGSN where the MS was last registered:
 - if the received VLR number and the stored VLR number match, the HLR sets the "MS purged for non-GPRS" flag for the subscriber and sends a MAP_PURGE_MS response containing a freeze TMSI indicator to indicate successful outcome;
 - if the received VLR number and the stored VLR number do not match, the HLR sends a MAP_PURGE_MS response containing an empty result to indicate successful outcome. Since the MS is known by the HLR to be in a different VLR area, it is not appropriate to block mobile terminated calls or short messages to the MS, but the VLR which initiated the purging procedure can safely purge its record for the MS without freezing the TMSI.
 - if the received SGSN number and the stored SGSN number match, the HLR sets the "MS purged for GPRS" flag for the subscriber and sends a MAP_PURGE_MS response containing a freeze P-TMSI indicator to indicate successful outcome;
 - if the received SGSN number and the stored SGSN number do not match, the HLR sends a MAP_PURGE_MS response containing an empty result to indicate successful outcome. Since the MS is known by the HLR to be in a different SGSN area, it is not appropriate to block short messages to the MS, but the SGSN which initiated the purging procedure can safely purge its record for the MS without freezing the P-TMSI.

In either cases of successful termination the HLR terminates the dialogue by sending a MAP_CLOSE request.

19.1.4.4 Detailed procedure in the SGSN

When the SGSN receives an indication from O&M that an MS record is to be purged, it invokes the MAP_PURGE_MS service (see figure 19.1.4/4).

The SGSN opens the dialogue to the HLR with a MAP_OPEN request containing no user specific parameters. The MAP_PURGE_MS request contains the IMSI of the MS which is to be purged and the SGSN number.

The SGSN then waits for the MAP_OPEN confirmation (see macro Receive_Open_Cnf, subclause 25.1), indicating one of:

- rejection of the dialogue (process terminates);
- reversion to Vr (process terminates);
- dialogue acceptance.

If the HLR accepts the dialogue it returns a MAP_PURGE_MS confirmation, containing no parameter, indicating successful outcome of the procedure.

If a MAP_PURGE_MS confirmation containing a provider error, data error or user error, or a MAP_P_ABORT, MAP_NOTICE or premature MAP_CLOSE indication, has been received, the failure is reported to the O&M interface. Successful outcome of the procedure leads to deletion of the subscriber data and freezing of the P-TMSI if so requested by the HLR, and is reported to the O&M interface.




Figure 19.1.4/2: Process Purge_MS_VLR




Figure 19.1.4/3: Process Purge_MS_HLR




Figure 19.1.4/4: Process Purge_MS_SGSN

19.2 Handover procedure

19.2.1 General

The handover between different MSCs is called Inter-MSC handover. The interfaces involved for Inter-MSC handover are shown in figure 19.2/1. Following two Inter-MSC handover procedures apply:

1) Basic Inter-MSC handover:

The call is handed over from the controlling MSC, called MSC-A to another MSC, called MSC-B (figure 19.2/1a).

Figure 19.2/2 shows a successful handover between MSC-A and MSC-B including a request for handover number allocation by MSC-B to VLR-B.


2) Subsequent Inter-MSC handover:

After the call has been handed over from MSC-A to MSC-B, a handover to either MSC-A (figure 19.2/1a) or to a third MSC (MSC-B') (figure 19.2/1b) is necessary in order to continue the connection.

Figure 19.2/3 shows a successful subsequent handover.



a) Basic handover procedure MSC-A to MSC-B and subsequent handover procedure MSC-B to MSC-A.




b) Subsequent handover procedure MSC-B to MSC-B'.

Figure 19.2/1: Interface structure for handover

The MAP handover procedures achieve the functionality required to set up an MSC-MSC dialogue, to optionally allocate a handover number and to transport BSSAP messages.


The transported BSSAP messages are controlled and handled by the Handover Control Application in the MSCs. This information will be transparent to the MAP protocol. If the MSC receives via the MAP protocol BSSAP messages, this information will be forwarded to the Handover Control Application (shown in the handover SDL diagrams with the internal HO_CA signalling, it is an internal process in the MSC) and vice versa if the Handover Control Application requires the sending of BSSAP messages via the MAP protocol.

For detailed interworking between the A-interface and MAP procedures, see GSM 03.09 and GSM 09.10.



NOTE: This can be sent at any time after the connection between MSC-A and MSC-B is established.

Figure 19.2/2: Example of a successful basic handover procedure to MSC-B



NOTE: This can be sent at any time after the connection between MSC-A and MSC-B is established.

Figure 19.2/3: Example of a handover towards a third MSC

19.2.2 Handover procedure in MSC-A

This subclause describes the handover procedure in MSC-A, including the request for a basic handover to another MSC (MSC-B), subsequent handover to a third MSC (MSC-B') or back to the controlling MSC (MSC-A).

19.2.2.1 Basic handover

When MSC-A has decided that a call has to be handed over to MSC-B, the Handover Control Application in MSC-A requests the MAP application to initiate the MAP_PREPARE_HANDOVER request to MSC-B.

MSC-A opens the dialogue to MSC-B with a MAP_OPEN request containing no user specific parameters and sends a MAP_PREPARE_HANDOVER request. This request may optionally contain an indication that a handover number allocation is not required, targetCellId, for compatibility reasons, and all information required by MSC-B to allocate the necessary radio resources.

If MSC-B accepts the dialogue, it returns a MAP_PREPARE_HANDOVER confirmation containing a handover number, unless the request has included the HO-NumberNotRequired parameter, and BSSAP information which is forwarded to and handled by the Handover Control Application in MSC-A.

Optionally MSC-A can receive, after a MAP_PREPARE_HANDOVER confirmation, a MAP_PROCESS_ACCESS_SIGNALLING indication containing BSSAP information.

When the connection has been established between the MS and MSC-B, MSC-A will be informed by a MAP_SEND_END_SIGNAL indication.

When MSC-A wants to clear the connection with BSS-B, an indication from the Handover Control Application is received in the Map Application to send the MAP_SEND_END-SIGNAL response to MSC-B to close the MAP dialogue.

MSC-A may abort the handover procedure at any time (e.g. if the call is cleared).

19.2.2.2 Handling of access signalling

If required, the Handover Control Application in MSC-A requests the MAP application to invoke the MAP_FORWARD_ACCESS_SIGNALLING request containing the information to be transferred to the A-interface of MSC-B (e.g. call control information).

MAP_FORWARD_ACCESS_SIGNALLING is a non-confirmed service.

MSC-B will then forward the required information to the Handover Control Application. The MAP_FORWARD_ACCESS_SIGNALLING is composed in such a way that the information can be passed transparently to the A-interface for call control and mobility management information. Any response received in MSC-B from the A-interface that should be brought to MSC-A will require a new independent request from the Handover Control Application in MSC-B to MSC-A by invoking a MAP_PROCESS_ACCESS_SIGNALLING request.

19.2.2.3 Other procedures in stable handover situation

During a call and after handover, a number of procedures between MSC-A and BSS-B controlled by or reported to MSC-A may be initiated in both directions by invoking a MAP_FORWARD_ACCESS_SIGNALLING request and reception of a MAP_PROCESS_ACCESS_SIGNALLING indication.

19.2.2.4 Subsequent handover

When MSC-A receives a MAP_PREPARE_SUBSEQUENT_HANDOVER request, it will start the procedure of handing the call over to a third MSC (MSC-B'), or back to the controlling MSC (MSC-A). If the new handover procedure towards MSC-B' or MSC-A is successful, the handover control application in MSC-A will request the release of the dialogue towards MSC-B by sending the MAP_SEND_END_SIGNAL confirmation.

19.2.2.5 SDL Diagrams

The SDL diagrams on the following pages describe the user processes in MSC-A for the procedures described in this subclause.

The services used are defined in subclause 8.4.

NOTE: The message primitives HO_CA_MESSAGE used in the SDL-Diagrams are used to show the internal co-ordination between the MAP application and the Handover Control Application. For a detailed description of the co-ordination between the applications for the handover procedure, see GSM 03.09.

Note that in case of reception of errors from the MSCs (see the Handover error handling macro), the MAP user reports them to the Handover Control Application and does not take any action except in cases explicitly mentioned in the SDL diagrams.




Figure 19.2.2/1 (sheet 1 of 12): Process MSC_A_HO




Figure 19.2.2/1 (sheet 2 of 12): Process MSC_A_HO




Figure 19.2.2/1 (sheet 3 of 12): Process MSC_A_HO




Figure 19.2.2/1 (sheet 4 of 12): Process MSC_A_HO




Figure 19.2.2/1 (sheet 5 of 12): Process MSC_A_HO





Figure 19.2.2/1 (sheet 6 of 12): Process MSC_A_HO

**Figure 19.2.2/1 (sheet 7 of 12): Process MSC_A_HO**




Figure 19.2.2/1 (sheet 8 of 12): Process MSC_A_HO




Figure 19.2.2/1 (sheet 9 of 12): Process MSC_A_HO




Figure 19.2.2/1 (sheet 10 of 12): Process MSC_A_HO




Figure 19.2.2/1 (sheet 11 of 12): Process MSC_A_HO




Figure 19.2.2/1 (sheet 12 of 12): Process MSC_A_HO

19.2.3 Handover procedure in MSC-B

This subclause describes the handover procedure in MSC-B, including the request for a handover from another MSC (MSC-A), subsequent handover to a third MSC (MSC-B') or back to the controlling MSC (MSC-A).

19.2.3.1 Basic handover

Opening of the dialogue is described in the macro Receive_Open_Ind in subclause 25.1.

When MSC-B process receives a MAP_PREPARE_HANDOVER indication from MSC-A, MSC-B requests its associated VLR to provide a handover number, unless the parameter HO-NumberNotRequired is received in the indication.

When the connection between the MS and MSC-B is established on MSC-B, the Handover Control Application will request the MAP application to indicate this event to MSC-A by invoking the MAP_SEND_END_SIGNAL request. When a call is released, MSC-A will inform MSC-B by MAP_SEND_END_SIGNAL response and the MAP dialogue between MSC-A and MSC-B is closed.

19.2.3.2 Allocation of handover number

When a handover number is required, a MAP_ALLOCATE_HANDOVER_NUMBER request will be sent to the VLR. The handover number is received in the MAP_SEND_HANDOVER_REPORT request, and will be included in the MAP_PREPARE_HANDOVER response to MSC-A.

As soon as the call from MSC-A using the handover number arrives in MSC-B, MSC-B shall release the handover number in the VLR using the MAP_SEND_HANDOVER_REPORT response.

19.2.3.3 Handling of access signalling

If required by the Handover Control Application, MSC-B invokes the MAP_PROCESS_ACCESS_SIGNALLING request containing the information received on the A-interface that should be transferred to MSC-A (e.g. call control information).

MAP_PROCESS_ACCESS_SIGNALLING is a non-confirmed service and any response from MSC-A will require a MAP_FORWARD_ACCESS_SIGNALLING request.

19.2.3.4 Other procedures in stable handover situation

During a call and after handover, a number of procedures between MSC-A and BSS-B controlled by or reported to MSC-A may be initiated by involving access signalling transfer in both directions.

19.2.3.5 Subsequent handover

The procedure is used when the Handover Control Application in MSC-B has decided that a call is to be handed over to another MSC (either back to the controlling MSC (MSC-A) or to a third MSC (MSC-B')).

After the MAP_PREPARE_SUBSEQUENT_HANDOVER response is received from MSC-A, MSC-B will await the disconnection of the call. Once the disconnect is complete, MSC-B will inform its VLR by invoking the MAP_SEND_HANDOVER_REPORT confirmation. VLR-B will then release the allocated handover number.

The subsequent handover procedure is shown in figure 19.2/3.

19.2.3.6 SDL Diagrams

The SDL diagrams on the following pages describe the user process in MSC-B for the procedures described in this subclause.

The services used are defined in subclause 8.4.

NOTE 1: The message primitives HO_CA_MESSAGE in the SDL-diagrams are used to show the internal co-ordination between the MAP application and the Handover Control Application. For a detailed description of the co-ordination between the applications for the handover procedure, see GSM 03.09.

NOTE 2: The order in the SDL diagrams to allocate first the handover number and then the radio resources is not binding.




Figure 19.2.3/1 (sheet 1 of 11): Process MSC_B_HO




Figure 19.2.3/1 (sheet 2 of 11): Process MSC_B_HO




Figure 19.2.3/1 (sheet 3 of 11): Process MSC_B_HO




Figure 19.2.3/1 (sheet 4 of 11): Process MSC_B_HO




Figure 19.2.3/1 (sheet 5 of 11): Process MSC_B_HO





Figure 19.2.3/1 (sheet 6 of 11): Process MSC_B_HO

**Figure 19.2.3/1 (sheet 7 of 11): Process MSC_B_HO**




Figure 19.2.3/1 (sheet 8 of 11): Process MSC_B_HO




Figure 19.2.3/1 (sheet 9 of 11): Process MSC_B_HO




Figure 19.2.3/1 (sheet 10 of 11): Process MSC_B_HO




Figure 19.2.3/1 (sheet 11 of 11): Process MSC_B_HO

19.2.4 Handover error handling macro

This macro is used for the handover procedures to receive errors from the MSCs and from the Handover Control Application at any state of a handover process.

If a MAP_NOTICE indication is received, the Handover Control Application is informed and the actual situation is kept and the Handover Control Application decides how the handover process should continue. In all other cases the MSC is returned to a "NULL" state.




Figure 19.2.4/1: Macro Receive_error_from_HO_CA_or_MSC

19.2.5 Handover procedure in VLR

19.2.5.1 Allocation of handover number

When receiving the MAP_ALLOCATE_HANDOVER_NUMBER indication, the VLR will determine whether a handover number is available. If no handover number is available, this will be indicated by a MAP_ALLOCATE_HANDOVER_NUMBER response with the appropriate error.


The handover number allocated will otherwise be returned to MSC-B in the MAP_SEND_HANDOVER_REPORT request.

The handover number will be reserved until a MAP_SEND_HANDOVER_REPORT confirmation is received from MSC-B.

19.2.5.2 SDL Diagrams

The SDL diagrams on the following pages describe the user processes in VLR for the procedures described in this subclause.

The services used are defined in subclause 8.4.

**Figure 19.2.5/1 (sheet 1 of 2): Process VLR_B_HO**




Figure 19.2.5/1 (sheet 2 of 2): Process VLR_B_HO

19.3 Fault recovery procedures

After a fault of a location register, the fault recovery procedures ensure that the subscriber data in the VLR or in the SGSN become consistent with the subscriber data that are stored in the HLR for the MS concerned and that the location information in HLR , VLR and SGSN reflect accurately the current location of the MS.

The detailed specification of fault recovery procedures of location registers is given in GSM 03.07.

19.3.1 VLR fault recovery procedures

The following processes are involved with the restoration of one IMSI record in the VLR:

- In case of a location registration request from the MS:

Update_Location_Area_VLR	subclause 19.1.1.3;
Update_Location_HLR	subclause 19.1.1.4.
- In case of a mobile terminated call:

PRN_VLR	subclause 21.2.4;
RESTORE_DATA_VLR	subclause 21.2.4;
RESTORE_DATA_HLR	subclause 19.3.3;
ICS_VLR	subclause 21.3.3.

After a restart, the VLR shall erase all IMSI records affected by the failure and shall cause all affected TMSIs and all affected LMSIs to become invalid. There will be no subscriber data or location information stored for an affected MS until after the VLR has received either a MAP_PROVIDE_ROAMING_NUMBER indication or a MAP_UPDATE_LOCATION_AREA indication for that MS. Restoration of subscriber data in the VLR is triggered individually for each IMSI record by receipt of either of these indications.

Reception of either a MAP_UPDATE_LOCATION_AREA indication or a MAP_PROVIDE_ROAMING_NUMBER indication with an IMSI that is unknown in the VLR causes creation of a skeleton IMSI record that is marked as:

- not confirmed by radio contact by the indicator "Confirmed by Radio Contact" (The function of this indicator is described in GSM 03.07), and
- not confirmed by HLR by the indicator "Confirmed by HLR" (The function of this indicator is described in GSM 03.07).

A third indicator "Location Information Confirmed in HLR" is allocated to each IMSI record in the VLR (The function of this indicator is described in GSM 03.07).

The indicator "Location Information Confirmed in HLR" shall be checked whenever authenticated radio contact with an MS has been established. The status "Not Confirmed" of this indicator shall force the VLR to invoke the MAP_UPDATE_LOCATION service but it shall never cause rejection of a mobile originated request. The status is changed from "Not Confirmed" to "Confirmed" only after successful completion of a MAP_UPDATE_LOCATION procedure for the MS concerned.

If the VLR serves only one MSC, the indicator "Location Information Confirmed in HLR" is only relevant to the HLR restoration procedure and an initial value must be assigned when an IMSI record is created in the VLR:

- if the IMSI record was created due to a roaming number request, the initial value must be set to "Confirmed";
- if reception of a MAP_UPDATE_LOCATION_AREA indication causes creation of the IMSI record, the initial value must be "Not Confirmed".

If the VLR serves more than one MSC, the indicator "Location Information Confirmed in HLR" is used in the VLR restoration procedure as well as in the HLR restoration procedure. When an IMSI record is created in the VLR, the indicator must be set to "Not Confirmed".

VLR restoration triggered by a location registration request

Upon receipt of a MAP_UPDATE_LOCATION_AREA indication, the VLR retrieves authentication data from the HLR by using the MAP_SEND_AUTHENTICATION_INFO service if authentication is required and if no authentication data are available in the VLR for the IMSI concerned (see figure 19.1.1/6).

Receipt of a MAP_UPDATE_LOCATION_AREA indication for an MS whose IMSI is unknown in the VLR or whose data stored in the VLR are marked as "Not Confirmed" by the indicator "Confirmed by HLR" and/or by the indicator "Location Information Confirmed in HLR" forces the VLR to invoke the MAP_UPDATE_LOCATION service after successful authentication, if required. The location updating procedure is performed as described in subclause 19.1.

Any other mobile originated request from an MS whose IMSI is unknown in the VLR or whose subscriber data stored in the VLR are marked as "Not Confirmed" by the indicator "Confirmed by HLR" shall be rejected with error cause "Unidentified Subscriber". This causes the MS to trigger the location registration procedure.

After successful completion of the MAP_UPDATE_LOCATION procedure, the indicators "Confirmed by HLR" and "Location Information Confirmed in HLR" are set to "Confirmed".

The indicator "Confirmed by Radio Contact" is set to "Confirmed" when the radio contact with the MS is authenticated.

VLR restoration triggered by a roaming number request

Figure 19.3/1 illustrates the signalling sequence for restoration of an IMSI record in the VLR triggered by a mobile terminating call set-up.

Upon receipt of a MAP_PROVIDE_ROAMING_NUMBER indication for an IMSI that is unknown in the VLR and for which authentication is required, the VLR retrieves authentication data from the HLR by using the MAP_SEND_AUTHENTICATION_INFO service after an MSRN has been sent to the HLR in the MAP_PROVIDE_ROAMING_NUMBER response.

Receipt of a MAP_PROVIDE_ROAMING_NUMBER indication for an MS whose IMSI is unknown in the VLR or whose data record in the VLR is marked as "Not Confirmed" by the indicator "Confirmed by HLR" forces the VLR to request subscriber data from the HLR by sending a MAP_RESTORE_DATA request which triggers one or more INSERT_SUBSCRIBER_DATA operations from the HLR. The MAP_RESTORE_DATA request may also be used to send the LMSI to the HLR.

The MAP_RESTORE_DATA process in the VLR is described in subclause 21.2.4.


The MAP_RESTORE_DATA process in the HLR is described in subclause 19.3.3.

After successful completion of the MAP_RESTORE_DATA procedure, the indicator "Confirmed by HLR" is set to "Confirmed".

If restoration of an IMSI record was triggered by a MAP_PROVIDE_ROAMING_NUMBER indication (i.e. by a mobile terminating call), the VLR has no valid Location Area Identity information for the MS concerned before successful establishment of the first authenticated radio contact. Upon receipt of a MAP_SEND_INFO_FOR_INCOMING_CALL indication from the MSC (see 5 in figure 19.3/1) for an MS whose subscriber data are marked as "Confirmed" by the indicator "Confirmed by HLR" but not confirmed by radio contact, the VLR shall invoke a "MAP_SEARCH_FOR_MS" instead of a "MAP_PAGE".

A MAP_SEARCH_FOR_MS shall also be performed if the VLR receives a MAP_SEND_INFO_FOR_MT_SMS indication from the MSC for an MS whose IMSI record is marked as "Confirmed" by the indicator "Confirmed by HLR" but not confirmed by radio contact.

The indicator "Confirmed by Radio Contact" is set to "Confirmed" when authenticated radio contact caused by a mobile originated or a mobile terminated activity is established.



NOTE 1: If authentication required.

NOTE 2: If subscriber tracing active in HLR.

Figure 19.3/1: Procedures related to restoration of VLR in case of mobile terminated call set-up

19.3.2 HLR fault recovery procedures

The following processes are involved with the restart of the HLR:

- HLR_RESTART subclause 19.3.2;
- REC_RESET_IN_VLR subclause 19.3.2;
- REC_RESET_IN_SGSN subclause 19.3.2.

In the case of a location registration request from the MS, the following processes are involved with the HLR restoration procedure:

- Update_Location_Area_VLR subclause 19.1.1.3;
- Update_Location_HLR subclause 19.1.1.4;
- Update_GPRS_Location_HLR subclause 19.1.1.4;
- GPRS_Update_Location_Area_VLR subclause 19.1.1.3;

- SGSN_Update_HLR subclause 19.1.1.8.

In the case of a mobile originated service request, the

- Macro Process_Access_Request_VLR subclause 25.4.2; and the
- Process Update_Location_HLR subclause 19.1.1.4,

are involved with the HLR restoration procedure.

For the HLR, periodic back-up of data to non-volatile memory is mandatory.

Data that have been changed in the period of time after the last back-up storage and before the restart of the HLR cannot be recovered by reload from the non-volatile memory. Therefore, a restoration procedure is triggered individually for each IMSI record that has been affected by the HLR fault at the first authenticated radio contact that is established with the MS concerned.

The HLR restoration procedure forces updating of MSC number, VLR number, SGSN number and, if provided by the VLR, LMSI in the HLR. Consistency of subscriber data that are stored in the VLR or in the SGSN for an MS that has been affected by a HLR fault with the subscriber data stored in the HLR for this MS will be achieved.

As an implementation option, a notification can be forwarded to the MS to alert the subscriber to check the parameters for supplementary services that allow subscriber controlled input (MAP_FORWARD_CHECK_SS_INDICATION service). If the VLR receives this notification from the HLR it shall forward the notification to the MS. If the Gs-interface is present the VLR shall not forward this notification.

Figures 19.3/2 and 19.3/9 illustrates the signalling sequence for HLR restoration.

After a restart, the home location register performs the following actions for the subscriber data records that have been affected by the HLR fault (see figure 19.3/3):

- reload all data from the non-volatile back-up;
- if the MAP_FORWARD_CHECK_SS_INDICATION service is implemented, mark each subscriber record "SS Check Required" by setting the "Check SS" indicator;
- set subscriber tracing deactive in the VLR for each of its MSS;
- reset the "MS Purged" flag for each of its MSS;
- send a MAP_RESET request to the VLRs where its MSSs are located (see figure 19.3/4).
- send a MAP_RESET request to the SGSNs where its MSSs are located (see figure 19.3/7).

The MAP_RESET request contains the HLR number and optionally the HLR Identity List.

When receiving a MAP_RESET indication, the VLR or the SGSN will derive all involved MSSs of that HLR either from the HLR Identity List (if present), or from the HLR number. The VLR or the SGSN will then mark these MSSs with the indicator "Location Information Confirmed in HLR" set to "Not Confirmed" and will deactivate all subscriber tracings for these MSS (see figures 19.3/5 and 19.3/8).

The status "Not Confirmed" of the indicator "Location Information Confirmed in HLR" forces the VLR to invoke the MAP_UPDATE_LOCATION service after establishment of authenticated radio contact with the MS concerned.

Also the status "Not Confirmed" of the indicator "Location Information Confirmed in HLR" forces the SGSN to invoke the MAP_UPDATE_GPRS_LOCATION service after establishment of authenticated radio contact with the MS concerned.

The MAP_UPDATE_LOCATION procedure is performed as described in subclause 19.1.

After receipt of the MAP_UPDATE_LOCATION or the MAP_UPDATE_GPRS_LOCATION acknowledge containing the HLR number, the status of the indicator "Location Information Confirmed in HLR" is changed to "Confirmed".

If the MAP_UPDATE_LOCATION procedure is unsuccessful for any reason, the status of the indicator "Location Information Confirmed in HLR" remains unchanged except for the case that the IMSI record in the VLR is deleted because either of the errors "Unknown Subscriber" or "Roaming Not Allowed" has been received from the HLR in response to a MAP_UPDATE_LOCATION request.

If the MAP_UPDATE_GPRS_LOCATION procedure is unsuccessful for any reason, the status of the indicator "Location Information Confirmed in HLR" remains unchanged except for the case that the IMSI record in the SGSN is deleted because either of the errors "Unknown Subscriber" or "Roaming Not Allowed" has been received from the HLR in response to a MAP_UPDATE_GPRS_LOCATION request.




Figure 19.3/2: Procedures related to restoration of HLR





Figure 19.3/9: Procedures related to restoration of HLR for GPRS






Figure 19.3/4: Process SEND_RESET_TO_VLR

Process REC_RESET_IN_VLR

19.3_5(1)

'Figure 19.3/5 Restoration of the HLR - Application process in the VLR for reception of the RESET message from HLR'




Figure 19.3/5: Process REC_RESET_IN_VLR

Process SEND_RESET_TO_SGSN 19.3_7(1)

Figure 19.3/7: Restoration of the HLR
Process for sending the RESET message
from HLR to SGSN




Figure 19.3/7: Process SEND_RESET_TO_SGSN

Process REC_RESET_IN_SGSN

19.3_8(1)

Figure 19.3/8: Restoration of the HLR - Application process in the SGSN
for reception of the RESET message from HLR




Figure 19.3/8: Process REC_RESET_IN_SGSN

19.3.3 VLR restoration: the restore data procedure in the HLR

The MAP_RESTORE_DATA procedure in the HLR (Process RESTORE_DATA_HLR) is described in this subclause; the corresponding procedure in the VLR (RESTORE_DATA_VLR) is described in subclause 21.2.4.

The process RESTORE_DATA_HLR makes use of the following macros:

- Receive_Open_Ind subclause 25.1.1;
- Check_Indication subclause 25.2.1;
- Insert_Subs_Data_Framed_HLR subclause 19.4.1.

The MAP_RESTORE_DATA service is invoked by the VLR after provision of a roaming number in response to a MAP_PROVIDE_ROAMING_NUMBER indication for an unidentified MS (i.e. IMSI unknown in VLR), or for a known MS whose IMSI record is marked as "Not Confirmed" by the indicator "Confirmed by HLR" (see 4 in figure 19.3/1). The process RESTORE_DATA_VLR is shown in figure 21.2/6.

The restore data process in the HLR is activated by receipt of a MAP_RESTORE_DATA indication from the VLR (see figure 19.3/6). If there is a parameter problem in the indication, either of the errors "Unexpected Data Value" or "Data Missing" is returned in the MAP_RESTORE_DATA response; if the subscriber is not known in the HLR, the error "Unknown Subscriber" is returned in the MAP_RESTORE_DATA response. In all of these cases the process in the HLR terminates.

If the MAP_RESTORE_DATA indication is accepted and if the LMSI is received, the HLR updates the LMSI for the IMSI received in the MAP_RESTORE_DATA indication. For this IMSI the HLR sets "subscriber-tracing-not-active-in-VLR" and checks whether tracing is required. This check is handled by the macro "Control_Tracing_HLR" that is described in subclause 25.9. Thereafter, the macro "Insert_Subs_Data_Framed_HLR" that is described in subclause 19.4.1 is invoked. The outcome of the macro Insert_Subs_Data_Framed_HLR is one of:

- abort, in which case the process terminates;
- error, in which case the HLR returns the error "System Failure" in the MAP_RESTORE_DATA response, and the process terminates;
- OK, indicating successful outcome of downloading the subscriber data to the VLR.

After successful completion of the framed MAP_INSERT_SUBSCRIBER_DATA procedure, the HLR Number and, if applicable, the "MS Not Reachable Flag" which is used for SMS, are provided in the MAP_RESTORE_DATA response.

Upon receipt of the MAP_RESTORE_DATA confirmation, the VLR behaves as described in subclause 21.2.4, figure 21.2/6.




Figure 19.3/6: Process RESTORE_DATA_HLR

19.4 Macro Insert_Subs_Data_Framed_HLR

This macro is used by any procedure invoked in HLR which requires the transfer of subscriber data by means of the InsertSubscriberData operation (e.g. Update Location or Restore Data).

The invocation of the operation is done in a dialogue already opened by the framing procedure. Therefore the latter is the one that handles the reception of the open indication and sends the dialogue close request.

The macro calls the process "Send_Insert_Subs_Data" (see subclause 25.7.4) as many times as it is needed for transferring all subscriber data. This process call is meant to describe two possible behaviours of HLR to handle service requests and confirmations:

- either the HLR handles requests and confirmations in parallel; or
- the HLR sends the next request only after receiving the confirmation to the previous one.

Another call is done to the macro "Wait_for_Insert_Subscriber_Data" (see subclause 25.7.3). There the reception and handling of the service confirmations is described.

If certain services required for a subscriber are not supported by the VLR or by the SGSN (e.g. Advice of Charge Charging Level), this may result in one of the following outcomes:

- The HLR stores and sends "Roaming Restriction Due To Unsupported Feature" in a subsequent MAP_INSERT_SUBSCRIBER_DATA service. If "Roaming Restriction Due To Unsupported Feature" is stored in the HLR, the "MSC Area Restricted Flag" shall be set to "restricted". This will prevent MT calls, MT SM and MT USSD from being forwarded to the MSC/VLR;
- The HLR stores and sends other induced subscriber data (e.g. a specific barring program) in a subsequent MAP_INSERT_SUBSCRIBER_DATA service. This will cause rejection of mobile originated service requests, except emergency calls.
- The HLR stores and sends "Roaming Restricted in the SGSN Due To Unsupported Feature" in a subsequent MAP_INSERT_SUBSCRIBER_DATA service. If "Roaming Restricted In SGSN Due To Unsupported Feature" is stored in the HLR, the "SGSN Area Restricted Flag" shall be set to "restricted". This will prevent MT SM from being forwarded to the SGSN and Network Requested PDP-Context Activation;

When the VLR receives regional subscription data (Zone Code List) it may respond with "MSC Area Restricted" in the MAP_INSERT_SUBSCRIBER_DATA response. In this case the "MSC Area Restricted Flag" shall be set to "restricted" in the HLR. This will prevent MT calls, MT SM and MT USSD from being forwarded to the MSC/VLR.

If the HLR neither stores "Roaming Restriction Due To Unsupported Feature" nor receives "MSC Area Restricted" in the MAP_INSERT_SUBSCRIBER_DATA response, the "MSC Area Restricted Flag" in the HLR shall be set to "not restricted".

If subscriber data for CAMEL Phase 2 services are sent to a VLR which does not support CAMEL Phase 2, the service behaviour may be unpredictable or incorrect. The HLR therefore needs to ensure that at the conclusion of a location updating dialogue the data in the VLR do not require a capability that the VLR does not have. Possible mechanisms to ensure this are described in GSM 03.78.

The HLR should send a Forwarded-to number which is not in E.164 international format to the VLR only when the HLR has ascertained that the VLR supports CAMEL Phase 2. Thus, the ISD message containing the Forwarded-to number which is not in E.164 international format shall be sent to the VLR only after the HLR receives confirmation in the first ISD message result that CAMEL Phase 2 is supported.

A Forwarded-to number non-international E.164 format shall only be sent from an HLR to a VLR if the VLR supports CAMEL Phase 2, or a subsequent phase of CAMEL.

When the SGSN receives regional subscription data (Zone Code List) it may respond with "SGSN Area Restricted" in the MAP_INSERT_SUBSCRIBER_DATA response. In this case the "SGSN Area Restricted Flag" shall be set to "restricted" in the HLR. This will prevent MT SM from being forwarded to the SGSN and Network Requested PDP-Context Activation.

If the HLR neither stores "Roaming Restricted In SGSN Due To Unsupported Feature" nor receives "SGSN Area Restricted" in the MAP_INSERT_SUBSCRIBER_DATA response, the "SGSN Area Restricted Flag" in the HLR shall be set to "not restricted".

The SDL diagrams are shown in figures 19.4/1 and 19.4/2.




Figure 19.4/1: Macro Insert_Subs_Data_Framed_HLR




Figure 19.4/2: Macro Insert_Subs_Data_In_SGSN_Framed_HLR

20 Operation and maintenance procedures

20.1 General

The Operation and Maintenance procedures are needed for operating and maintaining the GSM PLMN network.

The following procedures exist for operation and maintenance purposes:

- i) Tracing procedures;
- ii) Subscriber Data Management procedures;
- iii) Subscriber Identity procedures.

The following application contexts refer to complex MAP Users consisting of several processes:

- subscriberDataManagementContext;
- tracingContext.

These two application contexts need a co-ordinating process in the VLR or in the SGSN as described in the following subclauses.

20.1.1 Tracing Co-ordinator for the VLR

The MAP_OPEN indication opens the dialogue for the stand-alone tracing procedure when the application context tracingContext is received. If that service is successful, the Co-ordinator can receive the first service primitive from the MAP_PM. Depending on the received primitive, the user process is created as follows:

- if the MAP_ACTIVATE_TRACE_MODE indication is received, the process ATM_VLR_Standalone is created;
- if the MAP_DEACTIVATE_TRACE_MODE indication is received, the process DTM_VLR_Standalone is created.

After creation of the user process the Co-ordinator relays the messages between the MAP_PM and the invoked process until a request or an indication for dialogue termination is received.

The Tracing Co-ordinator is shown in the figure 20.1/1.




Figure 20.1/1: Process Co_Tracing_VLR

20.1.2 Subscriber Data Management Co-ordinator for the VLR

The MAP_OPEN indication opens the dialogue for the stand-alone subscriber data management procedure when the application context subscriberDataManagementContex is received. If that service is successful, the Co-ordinator can receive the first service primitive from the MAP_PM. Depending on the received primitive, the user process is created as follows:

- if the MAP_INSERT_SUBSCRIBER_DATA indication is received, the process INS_SUBS_DATA_VLR is created;
- if the MAP_DELETE_SUBSCRIBER_DATA indication is received, the process Delete_Subscriber_Data_VLR is created.

After creation of the user process the Co-ordinator relays the messages between the MAP_PM and the invoked process until a request or an indication for dialogue termination is received.

The Subscriber_Data_Management Co-ordinator is shown in the figure 20.1/2.




Figure 20.1/2: Process Co_Data_Management_VLR

20.1.3 Tracing Co-ordinator for the SGSN

The MAP_OPEN indication opens the dialogue for the stand-alone tracing procedure when the application context tracingContext is received. If that service is successful, the Co-ordinator can receive the first service primitive from the MAP_PM. Depending on the received primitive, the user process is created as follows:

- if the MAP_ACTIVATE_TRACE_MODE indication is received, the process ATM_SGSN_Standalone is created;
- if the MAP_DEACTIVATE_TRACE_MODE indication is received, the process DTM_SGSN_Standalone is created.

After creation of the user process the Co-ordinator relays the messages between the MAP_PM and the invoked process until a request or an indication for dialogue termination is received.

The Tracing Co-ordinator for the SGSN is shown in the figure 20.1/3.




Figure 20.1/3: Process Co_Tracing_SGSN

20.1.4 Subscriber Data Management Co-ordinator for the SGSN

The MAP_OPEN indication opens the dialogue for the stand-alone subscriber data management procedure when the application context subscriberDataManagementContext is received. If that service is successful, the Co-ordinator can receive the first service primitive from the MAP_PM. Depending on the received primitive, the user process is created as follows:

- if the MAP_INSERT_SUBSCRIBER_DATA indication is received, the process INS_SUBS_DATA_SGSN is created;
- if the MAP_DELETE_SUBSCRIBER_DATA indication is received, the process Delete_Subscriber_Data_SGSN is created.

After creation of the user process the Co-ordinator relays the messages between the MAP_PM and the invoked process until a request or an indication for dialogue termination is received.

The Subscriber_Data_Management Co-ordinator is shown in the figure 20.1/4.





Figure 20.1/4: Process Co_Data_Management_SGSN

20.2 Tracing procedures

Three type of tracing procedures exist:


- i) Subscriber tracing management procedures;
- ii) Subscriber tracing procedures;
- iii) Event tracing procedures.

The subscriber tracing management procedures are used for management of the status and the type of the tracing. The subscriber tracing activation procedure is used at location updating or data restoration when the trace mode of a subscriber is set active in the HLR or, as a stand alone procedure, when the subscriber is already registered and the trace mode becomes active in the HLR. The procedures for providing a trace request to the VLR are shown in figures 20.2/1 and 20.2/2. The procedures for providing a trace request to the SGSN are shown in figures 20.2/11 and 20.2/12.




- 1) Subscriber Tracing Activation.
- 2) MAP_ACTIVATE_TRACE_MODE.
- 3) MAP_ACTIVATE_TRACE_MODE_ACK.
- 4) Subscriber Tracing Activation Accepted.

Figure 20.2/1: Stand alone subscriber tracing activation procedure




- 1) Subscriber Tracing Activation.
- 2) MAP_ACTIVATE_TRACE_MODE.
- 3) MAP_ACTIVATE_TRACE_MODE_ACK.
- 4) Subscriber Tracing Activation Accepted.

Figure 20.2/11: Stand alone subscriber tracing activation procedure for GPRS



- 1) MAP_UPDATE_LOCATION or MAP_RESTORE_DATA.
- 2) MAP_ACTIVATE_TRACE_MODE.
- 3) MAP_ACTIVATE_TRACE_MODE_ACK.
- 4) MAP_UPDATE_LOCATION_ACK or MAP_RESTORE_DATA_ACK.

Figure 20.2/2: Subscriber tracing activation procedure at location updating or data restoration




- 1) MAP_UPDATE_GPRS_LOCATION.
- 2) MAP_ACTIVATE_TRACE_MODE.
- 3) MAP_ACTIVATE_TRACE_MODE_ACK.
- 4) MAP_UPDATE_GPRS_LOCATION_ACK.

Figure 20.2/12: Subscriber tracing activation procedure at GPRS location updating


The HLR sends the trace request (IMSI, trace reference, trace type and identity of the OMC) to the VLR or to the SGSN in a MAP_ACTIVATE_TRACE_MODE request. The receipt of this primitive is acknowledged. The acknowledgement primitive will indicate that the trace request is accepted by the VLR or by the SGSN. If the request is not accepted, the reason will be reported to the HLR.

The subscriber tracing deactivation procedure is used when the trace request of a subscriber is to be cancelled in the VLR or in the SGSN. The procedures are shown in figures 20.2/3 and 20.2/13.




- 1) Subscriber Tracing Deactivation.
- 2) MAP_DEACTIVATE_TRACE_MODE.
- 3) MAP_DEACTIVATE_TRACE_MODE_ACK.
- 4) Subscriber Tracing Deactivation Accepted.

Figure 20.2/3: Subscriber tracing deactivation procedure

**Figure 20.2/13: Subscriber tracing deactivation procedure for GPRS**

The HLR sends a MAP_DEACTIVATE_TRACE_MODE request to the VLR or to the SGSN. The VLR or the SGSN will acknowledge the deactivation. The acknowledge primitive will indicate that the trace request has been deleted by the VLR or by the SGSN. If the deactivation is not accepted, the reason will be reported to the HLR.

The subscriber tracing procedures are used when the VLR detects any subscriber related activity for which the trace mode is activated, e.g. receives the MAP_PROCESS_ACCESS_REQUEST indication. The procedure is shown in figure 20.2/4.

**Figure 20.2/4: Subscriber tracing procedure in the servicing MSC**

The VLR will generate the MAP_TRACE_SUBSCRIBER_ACTIVITY indication. The receiving MSC will send the trace record to the OMC.

[Figure numbers 20.2/5 and 20.2/6 are spare.]

20.2.1 Procedures in the HLR

20.2.1.1 Subscriber tracing activation procedure

When receiving the subscriber tracing mode activation command for a subscriber from the OMC, the HLR will activate tracing, if the subscriber is known and registered in the HLR and the subscriber is roaming in the home PLMN area. The MAP_ACTIVATE_TRACE_MODE request is sent to the VLR or to the SGSN where the subscriber is registered.

If the MAP_ACTIVATE_TRACE_MODE confirmation is received indicating an error situation, the errors are mapped to the OMC interface. The activation request may also be repeated; the number of repeat attempts and the time in between are HLR operator options, depending on the error returned by the VLR or the SGSN.

If the subscriber is known in the HLR, but is deregistered or roaming outside the home PLMN area, the subscriber tracing status is activated in the HLR, but the VLR or the SGSN is not updated.

When receiving a request for location updating or data restoration while the subscriber trace mode is active, the macro Control_Tracing_HLR (see figure 25.9/4) shall be initiated by the location updating process in the HLR.

The subscriber tracing activation process in the HLR with VLR is shown in figure 20.2/7.

The subscriber tracing activation process in the HLR with SGSN is shown in figure 20.2/14.




Figure 20.2/7 (sheet 1 of 2): Process ATM_HLR_with_VLR

Process ATM_HLR_with_VLR

20.2_7.2(2)

Figure 20.2/7: The subscriber tracing activation process in the HLR




Figure 20.2/7 (sheet 2 of 2): Process ATM_HLR_with_VLR




Figure 20.2/14 (sheet 1 of 2): Process ATM_HLR_with_SGSN

Process ATM_HLR_with_SGSN

20.2_14.2(2)

Figure 20.2/14: The subscriber tracing activation process in the HLR with SGSN




Figure 20.2/14 (sheet 2 of 2): Process ATM_HLR_with_SGSN

20.2.1.2 Subscriber tracing deactivation procedure

When receiving the subscriber trace mode deactivation command for a subscriber from the OMC, the HLR will send the MAP_DEACTIVATE_TRACE_MODE request to the VLR or to the SGSN where the subscriber is registered, if the trace mode activation has been carried out. The subscriber tracing in HLR is set to a deactivate state.

If the operation is successful, the HLR will set the subscriber tracing in VLR or in SGSN to a deactivate state.

If the MAP_DEACTIVATE_TRACE_MODE confirmation is received indicating an error situation, the errors are mapped to the OMC interface. The deactivation request may be also repeated; the number of repeat attempts and the time in between are HLR operator options, depending on the error returned by the VLR or by the SGSN.

The subscriber tracing deactivation procedure with VLR is shown in figure 20.2/8.

The subscriber tracing deactivation procedure with SGSN is shown in figure 20.2/15.

Process DTM_HLR_with_VLR

20.2_8.1(2)

Figure 20.2/8: The subscriber tracing deactivation process in the HLR




Figure 20.2/8 (sheet 1 of 2): Process DTM_HLR_with_VLR

Process DTM_HLR_with_VLR

20.2_8.2(2)

Figure 20.2/8: The subscriber tracing deactivation process in the HLR




Figure 20.2/8 (sheet 2 of 2): Process DTM_HLR_with_VLR




Figure 20.2/15 (sheet 1 of 2): Process DTM_HLR_with_SGSN

Process DTM_HLR_with_SGSN

20.2_15.2(2)

Figure 20.2/15: The subscriber tracing deactivation process in the HLR with SGSN




Figure 20.2/15 (sheet 2 of 2): Process DTM_HLR_with_SGSN

20.2.2 Procedures in the VLR

The VLR is involved in the following tracing procedures:

- i) Subscriber tracing activation procedure;
- ii) Subscriber tracing deactivation procedure;
- iii) Subscriber tracing procedure.


20.2.2.1 Subscriber tracing activation procedure

When receiving a MAP_ACTIVATE_TRACE_MODE indication, the VLR will check the parameters and data in the primitive. Data errors are reported as an unexpected data value error or as a data missing error depending on the nature of the error.

If the subscriber is known, the tracing facility is supported and the tracing capacity is not exceeded, the successful report is sent in the MAP_ACTIVATE_TRACE_MODE response primitive.

The MAP_ACTIVATE_TRACE_MODE indication primitive may be received during a location updating or data restoration procedure, so the location updating or restore data process shall use the macro Activate_Tracing_VLR (see figure 25.9/3).

The subscriber tracing activation process in the VLR is shown in figure 20.2/9.

**Figure 20.2/9: Process ATM_VLR_Standalone**

20.2.2.2 Subscriber tracing deactivation procedure

When receiving a MAP_DEACTIVATE_TRACE_MODE indication, the VLR will check the parameters and data in the primitive. Data errors are reported as an unexpected data value error or as a data missing error depending on the nature of the error.

If the subscriber is known and the tracing facility is supported, the successful report is sent in the MAP_DEACTIVATE_TRACE_MODE response primitive.

The subscriber tracing deactivation procedure in the VLR is shown in figure 20.2/10.

Process DTM_VLR_Standalone

20.2_10(1)

Figure 20.2/10: The subscriber tracing deactivation process in the VLR




Figure 20.2/10: Process DTM_VLR_Standalone

20.2.2.3 Subscriber tracing procedure

When the VLR receives a MAP_PROCESS_ACCESS_REQUEST or MAP_UPDATE_LOCATION_AREA indication related to any subscriber activity from the MSC, the subscriber tracing procedure may be carried out. The macro Trace_Subscriber_Activity_VLR is shown in figure 25.9/2.

20.2.3 Procedures in the MSC

The MSC is involved in the following tracing procedure:

- i) Subscriber tracing procedure.

20.2.3.1 Subscriber tracing procedure

When receiving the MAP_TRACE_SUBSCRIBER_ACTIVITY indication from the VLR, the MSC stores trace reference, trace type and the identity of the OMC in charge of the trace, and the MSC starts to collect the trace information. The MSC will send the trace record to the OMC.

The macro Trace_Subscriber_Activity_MSC is shown in figure 25.9/1.

20.2.4 Procedures in the SGSN

The SGSN is involved in the following tracing procedures:

- i) Subscriber tracing activation procedure;
- ii) Subscriber tracing deactivation procedure;

20.2.4.1 Subscriber tracing activation procedure

When receiving a MAP_ACTIVATE_TRACE_MODE indication, the SGSN will check the parameters and data in the primitive. Data errors are reported as an unexpected data value error or as a data missing error depending on the nature of the error.

If the subscriber is known, the tracing facility is supported and the tracing capacity is not exceeded, the successful report is sent in the MAP_ACTIVATE_TRACE_MODE response primitive.

The MAP_ACTIVATE_TRACE_MODE indication primitive may be received during a location updating or data restoration procedure, so the location updating or restore data process shall use the macro Activate_Tracing_SGSN (see figure 25.9/7).

The subscriber tracing activation process in the SGSN is shown in figure 20.2/16.

20.2.4.2 Subscriber tracing deactivation procedure in SGSN

When receiving a MAP_DEACTIVATE_TRACE_MODE indication, the SGSN will check the parameters and data in the primitive. Data errors are reported as an unexpected data value error or as a data missing error depending on the nature of the error.

If the subscriber is known and the tracing facility is supported, the successful report is sent in the MAP_DEACTIVATE_TRACE_MODE response primitive.

The subscriber tracing deactivation procedure in the SGSN is shown in figure 20.2/17.




Figure 20.2/16: Process ATM_SGSN_Standalone




Figure 20.2/17: Process DTM_SGSN_Standalone

20.3 Subscriber data management procedures

Two types of subscriber data management procedures exist in the Mobile Application Part

- i) Subscriber Deletion;
- ii) Subscriber Data Modification.

No requirements have been identified for the Subscriber creation and subscriber data interrogation procedures.

The subscriber deletion and subscriber data modification procedures are initiated by the OMC (see figures 20.3/1 , 20.3/2, 20.3/8 and 20.3/9).




Figure 20.3/1: Subscriber deletion procedure

In the subscriber deletion procedure the subscriber data should be removed from the VLR and from the HLR. The HLR uses the MAP_CANCEL_LOCATION service.




Figure 20.3/8: Subscriber deletion procedure for GPRS

In the subscriber deletion procedure the subscriber data should be removed from the SGSN and from the HLR. The HLR uses the MAP_CANCEL_LOCATION service.





Figure 20.3/2: Subscriber data modification procedure



- 1) Modify Subscriber Data.
- 2) MAP_CANCEL_LOCATION, MAP_INSERT_SUBSCRIBER_DATA or
MAP_DELETE_SUBSCRIBER_DATA.
- 3) MAP_CANCEL_LOCATION_ACK, MAP_INSERT_SUBSCRIBER_DATA_ACK or
MAP_DELETE_SUBSCRIBER_DATA_ACK.
- 4) Subscriber Data Modified.

Figure 20.3/9: Subscriber data modification procedure for GPRS

In the subscriber data modification procedure the subscriber data is modified in the HLR and when necessary also in the VLR or in the SGSN. The HLR initiates either the MAP_INSERT_SUBSCRIBER_DATA, MAP_DELETE_SUBSCRIBER_DATA or MAP_CANCEL_LOCATION service depending on the modified data.

20.3.1 Procedures in the HLR

20.3.1.1 Subscriber deletion procedure

When the subscriber deletion request is received from the OMC, the HLR shall delete the subscriber data from the HLR and initiate the MAP_CANCEL_LOCATION request to the VLR or to the SGSN where the subscriber is registered.

The subscriber deletion procedure in the HLR is shown in the figure 20.3/3.




Figure 20.3/3: Process Delete_Subscriber_HLR

20.3.1.2 Subscriber data modification procedure

The OMC can modify the subscriber data in several different ways. The modifications can be categorized in following groups:

- a) no effect in the VLR;
- b) data shall be modified in both the HLR and the VLR;
- c) withdrawal of a basic service or a supplementary service requiring change to VLR data;
- d) modification affects on the roaming of the subscriber and the subscriber shall be removed from the VLR data base;
- e) authentication algorithm or authentication key of the subscriber is modified;
- f) no effect in the SGSN;
- g) data shall be modified in both the HLR and the SGSN;
- h) withdrawal of a GPRS subscription data or a basic service or both requiring change to SGSN data;
- i) modification affects on the roaming of the subscriber and the subscriber shall be removed from the SGSN data base;
- j) withdrawal of GPRS Subscription related to Network Access Mode;
- k) withdrawal of non-GPRS Subscription related to Network Access Mode;

In case "b" and "g" the MAP_INSERT_SUBSCRIBER_DATA service is initiated in the HLR.

In case "c" and "h" the MAP_DELETE_SUBSCRIBER_DATA service is initiated in the HLR.

In cases "d", "e", "i", "j" and "k" the MAP_CANCEL_LOCATION service is initiated in the HLR.

If the result of a primitive received from the VLR or from the SGSN is unsuccessful, the HLR may initiate re-attempts; the number of repeat attempts and the time in between are HLR operator options, depending on the error returned by the VLR or by the SGSN.

The subscriber data modification procedure in the HLR is shown in the figures 20.3/4, 20.3/5 and 25.7/2.




Figure 20.3/4 (sheet 1 of 2): Process Modify_Data_HLR

Process Modify_Data_HLR 20.3_4.2(2)

Figure 20.3/4: The subscriber data modification process in the HLR




Figure 20.3/4 (sheet 2 of 2): Process Modify_Data_HLR




Figure 20.3/10: Macro Delete_GPRS_Subscriber_Data_HLR




Figure 20.3/5: Macro Delete_Subscriber_Data_HLR

20.3.2 Procedures in the VLR

20.3.2.1 Subscriber deletion procedure

The subscriber deletion procedure in the VLR is described in the subclause 19.1.

20.3.2.2 Subscriber data modification procedure

When receiving either the MAP_INSERT_SUBSCRIBER_DATA indication or the MAP_DELETE_SUBSCRIBER_DATA indication, the VLR check the parameters and data in the primitive. Data errors are reported as an unexpected data value error or a data missing error depending on the nature of the error.

After receiving the first MAP_INSERT_SUBSCRIBER_DATA indication, the VLR will check the IMSI that is included in the primitive. If the IMSI is unknown, the error "Unidentified subscriber" is returned.

If the VLR does not support received basic or supplementary services or the network feature Operator Determined Barring, or there is a problem with Regional Subscription Data then it reports it to the HLR.

If the entire MSC area is restricted due to regional subscription, this is reported to the HLR.

If the updating of the subscriber data is not possible, the VLR will initiate the MAP_U_ABORT request primitive. If the updating is successful, the MAP_CLOSE indication is received from the HLR.

The subscriber data modification procedure in the VLR is shown in the figures 20.3/6, 20.3/7 and 25.7/1.




Figure 20.3/6: Process INS_SUBS_DATA_VLR

Process Delete_Subscriber_Data_VLR

20.3_7(1)

Figure 20.3/7: The delete subscriber data process in the VLR




Figure 20.3/7: Process Delete_Subscriber_Data_VLR

20.3.3 Procedures in the SGSN

20.3.3.1 Subscriber deletion procedure

The subscriber deletion procedure in the SGSN is described in the subclause 19.1.

20.3.3.2 Subscriber data modification procedure

When receiving either the MAP_INSERT_SUBSCRIBER_DATA indication or the MAP_DELETE_SUBSCRIBER_DATA indication, the SGSN check the parameters and data in the primitive. Data errors are reported as an unexpected data value error or a data missing error depending on the nature of the error.

After receiving the first MAP_INSERT_SUBSCRIBER_DATA indication, the SGSN will check the IMSI that is included in the primitive. If the IMSI is unknown, the error "Unidentified subscriber" is returned.

If the SGSN does not support received basic services or the network feature Operator Determined Barring, or there is a problem with Regional Subscription Data then it reports it to the HLR.

If the entire SGSN area is restricted due to regional subscription, this is reported to the HLR.

If the updating of the subscriber data is not possible, the SGSN will initiate the MAP_U_ABORT request primitive. If the updating is successful, the MAP_CLOSE indication is received from the HLR.

The subscriber data modification procedure in the SGSN is shown in the figures 20.3/11, 20.3/12 and 25.7/5.




Figure 20.3/11: Process INS_SUBS_DATA_SGSN




Figure 20.3/12: Process Delete_Subscriber_Data_SGSN

20.4 Subscriber Identity procedure

In the subscriber identity procedure the IMSI of the subscriber is retrieved from the HLR. The procedure is shown in figure 20.4/1.




Figure 20.4/1: The subscriber identity procedure

20.4.1 Subscriber identity procedure in the HLR


Opening of the dialogue is described in the macro Receive_Open_Ind in subclause 25.1, with outcomes:

- procedure termination; or
- dialogue acceptance, with proceeding as below.

When receiving the MAP_SEND_IMSI indication, the HLR will check the parameters and data in the primitive. Data errors are reported as an unexpected data value error or a data missing error depending on the nature of the error.

If the subscriber is known in the HLR, the IMSI is fetched from the database and sent to the VLR. If the MSISDN cannot be identified, unknown subscriber indication is passed to the VLR.

The subscriber identity procedure in the HLR is shown in figure 20.4/2.

**Figure 20.4/2: Process Send_IMSI_HLR**

20.4.2 Subscriber identity procedure in the VLR

When the IMSI request is received from the OMC, the VLR will send the MAP_SEND_IMSI request to the HLR. The contents of the response is sent to the OMC.

The subscriber identity procedure in the VLR is shown in figure 20.4/3.




Figure 20.4/3: Process Send_IMSI_VLR

21 Call handling procedures

21.1 General

The MAP call handling procedures are used:

- to retrieve routeing information to handle a mobile terminating call;
- to transfer control of a call back to the GMSC if the call is to be forwarded;
- to retrieve and transfer information between anchor MSC and relay MSC for inter MSC group calls / broadcast calls;
- to allocate resources in an SIWFS;
- to handle the reporting of MS status for call completion services;
- to handle the notification of remote user free for CCBS.

The procedures to handle a mobile originating call and a mobile terminating call after the call has arrived at the destination MSC do not require any signalling over a MAP interface. These procedures are specified in GSM 03.18 [97].

The stage 2 specification for the retrieval of routeing information to handle a mobile terminating call is in GSM 03.18 [97]; modifications to this procedure for CAMEL are specified in GSM 03.78 [98], for optimal routeing of a basic mobile-to-mobile call in GSM 03.79 [99] and for CCBS in GSM 03.93. The interworking between the MAP signalling procedures and the call handling procedures for each entity (GMSC, HLR and VLR) is shown by the transfer of signals between these procedures.

The stage 2 specification for the transfer of control of a call back to the GMSC if the call is to be forwarded is in GSM 03.79 [99]. The interworking between the MAP signalling procedures and the call handling procedures for each entity (VMSC and GMSC) is shown by the transfer of signals between these procedures.

The stage 2 specifications for inter MSC group calls / broadcast calls are in GSM 03.68 and GSM 03.69. The interworking between the MAP signalling procedures and the group call /broadcast call procedures for each entity (Anchor MSC and Relay MSC) is shown by the transfer of signals between these procedures.

The stage 2 specification for the allocation of resources in an SIWFS is in GSM 03.54. The interworking between the MAP signalling procedures and the call handling procedures for each entity (VMSC and SIWFS) is shown by the transfer of signals between these procedures.


The interworking between the call handling procedures and signalling protocols other than MAP is shown in GSM 03.18, GSM 03.78 and GSM 03.79.

The stage 2 specification for the handling of reporting of MS status for call completion services and notification of remote user free for CCBS is in GSM 03.93.

21.2 Retrieval of routing information

21.2.1 General

The message flows for successful retrieval of routeing information for a mobile terminating call are shown in figure 21.2/1 (mobile terminating call which has not been optimally routed) and 21.2/2 (mobile-to-mobile call which has been optimally routed).




Notes:

xxx = Optional Procedure

- NOTE 1: This service may also be used by an ISDN exchange for obtaining routing information from the HLR.
- NOTE 2: TUP or ISUP may be used in signalling between MSCs, depending on the network type between the MSCs. For further details on the TUP and ISUP procedures refer to the following ITU-T Recommendations and ETSI specification:
 - Q.721-725 - Telephone User Part (TUP);
 - ETS 300 356-1 - Integrated Services Digital Network (ISDN); Signalling System No.7; ISDN User Part (ISUP) version 2 for the international interface; Part 1: Basic services.
- NOTE 3: As a network operator option, the HLR sends MAP_PROVIDE_SUBSCRIBER_INFORMATION to the VLR. For further details on the CAMEL procedures refer to GSM TS 03.78.

Figure 21.2/1: Message flow for retrieval of routeing information (non-optimally routed call)



Notes:

xxx = Optional Procedure

- NOTE 1: For Optimal Routeing phase 1, only one of the information flows for Provide Subscriber Info and Provide Roaming Number is used. For later phases of Optimal Routeing, the HLR may return a MAP_SEND_ROUTEING_INFORMATION ack after the Provide Subscriber Info information flow, and the GMSC may send a second MAP_SEND_ROUTEING_INFORMATION, which will trigger the Provide Roaming Number information flow.
- NOTE 2: TUP or ISUP may be used in signalling between MSCs, depending on the network type between the MSCs. For further details on the TUP and ISUP procedures refer to the following CCITT Recommendations & ETSI specification:
 - Q.721-725 - Telephone User Part (TUP);
 - ETS 300 356-1 - Integrated Services Digital Network (ISDN); Signalling System No.7; ISDN User Part (ISUP) version 2 for the international interface; Part 1: Basic services.

Figure 21.2/2: Message flow for retrieval of routeing information (optimally routed call)

The following MAP services are used to retrieve routing information:

MAP_SEND_ROUTING_INFORMATION	see subclause 10.1;
MAP_PROVIDE_ROAMING_NUMBER	see subclause 10.2;
MAP_PROVIDE_SUBSCRIBER_INFO	see subclause 8.11.2;
MAP_RESTORE_DATA	see subclause 8.10.3.

21.2.2 Process in the GMSC

The MAP process in the GMSC to retrieve routeing information for a mobile terminating call is shown in figure 21.2/3. The MAP process invokes macros not defined in this subclause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2.

Successful Outcome

When the MAP process receives a Send Routeing Info request from the call handling process in the GMSC, it requests a dialogue with the HLR whose identity is contained in the Send Routeing Info request by sending a MAP_OPEN service request, requests routeing information using a MAP_SEND_ROUTING_INFORMATION service request and invokes the macro Receive_Open_Cnf to wait for the response to the dialogue opening request. If the dialogue opening is successful, the MAP process waits for a response from the HLR.

If the MAP process receives a MAP_SEND_ROUTING_INFORMATION service confirm from the HLR, the MAP process invokes the macro Check_Confirmation to check the content of the confirm. If the MAP_SEND_ROUTING_INFORMATION confirm from the HLR cannot be carried in a single TC-Result component, it is carried in one or more TC-Result-NL components (each sent in a TC-CONTINUE), followed by a TC-Result-L component in a TC-END message.

If the macro Check_Confirmation takes the OK exit, the MAP process sends a Send Routeing Info ack containing the routeing information received from the HLR to the call handling process in the GMSC and returns to the idle state.

Earlier version MAP dialogue with the HLR

If the macro Receive_Open_Cnf takes the Vr exit, the MAP process checks whether this is an OR interrogation (indicated by the inclusion of the OR interrogation parameter in the MAP_SEND_ROUTING_INFORMATION service request).

If this is not an OR interrogation, the GMSC performs the earlier version MAP dialogue as specified in [51] or [96] and the process returns to the idle state.

If this is an OR interrogation, the MAP process sends a Send Routeing Info negative response indicating OR not allowed to the call handling process in the GMSC and returns to the idle state.

Dialogue opening failure

If the macro Receive_Open_Cnf indicates that the dialogue with the HLR could not be opened, the MAP process sends an Abort to the call handling process in the GMSC and returns to the idle state.

Error in MAP_SEND_ROUTING_INFORMATION confirm

If the MAP_SEND_ROUTING_INFORMATION service confirm contains a user error or a provider error, or the macro Check_Confirmation indicates that there is a data error, the MAP process sends a Send Routeing Info negative response to the call handling process in the GMSC and returns to the idle state.

Call release

If the call handling process in the GMSC indicates that the call has been aborted (i.e. prematurely released by the calling subscriber), the MAP process returns to the idle state. Any response from the HLR will be discarded.

Abort of HLR dialogue

After the dialogue with the HLR has been established, the MAP service provider may abort the dialogue by issuing a MAP_P_ABORT indication, or the HLR may send a MAP_U_ABORT indication or a MAP_CLOSE indication. In any of these cases, the MAP process sends a Send Routeing Info negative response to the call handling process in the GMSC and returns to the idle state.

If the MAP provider indicates a protocol problem by sending a MAP_NOTICE indication, the MAP process closes the dialogue with the HLR, sends a Send Routeing Info negative response indicating system failure to the call handling process in the GMSC and returns to the idle state.




Figure 21.2/3 (sheet 1 of 2): Process SRI_GMSC




Figure 21.2/3 (sheet 2 of 2): Process SRI_GMSC

21.2.3 Procedures in the HLR

The MAP process in the HLR to retrieve routeing information for a mobile terminating call is shown in figure 21.2/4. The MAP process invokes macros not defined in this subclause; the definitions of these macros can be found as follows:

Receive_Open_Ind	see subclause 25.1.1;
Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2.

Successful outcome

When the MAP process receives a MAP_OPEN indication with the application context locInfoRetrieval, it checks it by invoking the macro Receive_Open_Ind.

If the macro takes the OK exit, the MAP process waits for a service indication.

If a MAP_SEND_ROUTING_INFORMATION service indication is received, the MAP process sends a Send Routeing Info request to the call handling process in the HLR, and waits for a response. The Send Routeing Info request contains the parameters received in the MAP_SEND_ROUTING_INFORMATION service indication.

If the call handling process in the HLR returns a Send Routeing Info ack, the MAP process constructs a MAP_SEND_ROUTING_INFORMATION service response containing the routeing information contained in the Send Routeing Info ack, constructs a MAP_CLOSE service request, sends them to the GMSC and returns to the idle state. If the MAP_SEND_ROUTING_INFORMATION response cannot be carried in a single TC-Result component, it is carried in one or more TC-Result-NL components (each sent in a TC-CONTINUE), followed by a TC-Result-L component in a TC-END message.

If the call handling process in the HLR returns a Provide Subscriber Info request, the MAP process requests a dialogue with the VLR whose identity is contained in the Provide Subscriber Info request by sending a MAP_OPEN service request, requests the subscriber status using a MAP_PROVIDE_SUBSCRIBER_INFO service request, and invokes the macro Receive_Open_Cnf to wait for the response to the dialogue opening request.

If the macro takes the OK exit, the MAP process waits for the response from the VLR.

If the MAP process receives a MAP_PROVIDE_SUBSCRIBER_INFO service confirm, it invokes the macro Check_Confirmation to check the content of the confirm.

If the Check_Confirmation macro takes the OK exit, the MAP process sends a Provide Subscriber Info ack containing the information received in the MAP_PROVIDE_SUBSCRIBER_INFO service confirm to the call handling process in the HLR, and waits for a response. The handling of the response from the call handling process in the HLR is described above.

If the MAP_PROVIDE_SUBSCRIBER_INFO service confirm contains a provider error or a data error, the MAP process sends a Provide Subscriber Info negative response indicating the type of error to the call handling process in the HLR, and waits for a response. The handling of the response from the call handling process in the HLR is described above.

NOTE: The 'User Error' exit from the macro Check_Confirmation is shown for formal completeness; the MAP_PROVIDE_SUBSCRIBER_INFO_cnf primitive cannot contain a user error.

If the call handling process in the HLR returns a Provide Roaming Number request, the MAP process requests a dialogue with the VLR whose identity is contained in the Provide Roaming Number request by sending a MAP_OPEN service request, requests a roaming number using a MAP_PROVIDE_ROAMING_NUMBER service request, and invokes the macro Receive_Open_Cnf to wait for the response to the dialogue opening request.

If the macro takes the OK exit, the MAP process waits for the response from the VLR.

If the MAP process receives a MAP_PROVIDE_ROAMING_NUMBER service confirm, it invokes the macro Check_Confirmation to check the content of the confirm.

If the Check_Confirmation macro takes the OK exit, the MAP process sends a Provide Roaming Number ack containing the MSRN received in the MAP_PROVIDE_ROAMING_NUMBER service confirm to the call handling process in the HLR, and waits for a response. The handling of the response from the call handling process in the HLR is described above.

If the MAP_PROVIDE_ROAMING_NUMBER service confirm contains a user error or a provider error, or the macro Check_Confirmation indicates that there is a data error, the MAP process sends a Provide Roaming Number negative response indicating the type of error to the call handling process in the HLR, and waits for a response. The handling of the response from the call handling process in the HLR is described above.

Negative response from HLR call handling process

If the call handling process in the HLR returns a negative response, either before or after a dialogue with the VLR to obtain a roaming number, the MAP process constructs a MAP_SEND_ROUTING_INFORMATION service response containing the appropriate error, constructs a MAP_CLOSE service request, sends them to the GMSC and returns to the idle state.

Earlier version MAP Provide Roaming Number dialogue with the VLR

If the macro Receive_Open_Cnf takes the Vr exit after the MAP process has requested opening of a Provide Roaming Number dialogue with the VLR, the MAP process checks whether this is an OR interrogation (indicated by the inclusion of the OR interrogation parameter in the MAP_PROVIDE_ROAMING_NUMBER service request).

If this is not an OR interrogation, the HLR performs the earlier version MAP dialogue as specified in [51] or [96], relays the result of the dialogue to the HLR call handling process, and waits for a response. The handling of the response from the call handling process in the HLR is described above.

If this is an OR interrogation, the MAP process sends a Provide Roaming Number negative response indicating OR not allowed to the call handling process in the HLR and waits for a response. The handling of the response from the call handling process in the HLR is described above.

Failure of Provide Subscriber Info dialogue with the VLR

If the Receive_Open_Cnf macro takes the Vr exit or the Error exit after the MAP process has requested opening of a Provide Subscriber Info dialogue with the VLR, the MAP process sends a Provide Subscriber Info negative response indicating system failure to the call handling process in the HLR, and waits for a response. The handling of the response from the call handling process in the HLR is described above.

Failure of Provide Roaming Number dialogue with the VLR

If the Receive_Open_Cnf macro takes the Error exit after the MAP process has requested opening of a Provide Roaming Number dialogue with the VLR, the MAP process sends a Provide Roaming Number negative response indicating system failure to the call handling process in the HLR, and waits for a response. The handling of the response from the call handling process in the HLR is described above.

If the MAP process receives a MAP_U_ABORT, a MAP_P_ABORT or a premature MAP_CLOSE from the MAP provider, it sends a Provide Roaming Number negative response indicating system failure to the call handling process in the HLR, and waits for a response. The handling of the response from the call handling process in the HLR is described above.

If the MAP process receives a MAP_NOTICE from the MAP provider, it returns a MAP_CLOSE request to the MAP provider, sends a Provide Roaming Number negative response indicating system failure to the call handling process in the HLR, and waits for a response. The handling of the response from the call handling process in the HLR is described above.

Earlier version MAP dialogue with the GMSC

If the macro Receive_Open_Ind takes the Vr exit, the the HLR performs the earlier version MAP dialogue as specified in [51] or [96] and the process returns to the idle state.

Failure of dialogue opening with the GMSC

If the macro Receive_Open_Ind takes the Error exit, the MAP process returns to the idle state.

If the MAP provider sends a MAP_P_ABORT while the MAP process is waiting for a service indication, the MAP process returns to the idle state.

If the MAP provider sends a MAP_NOTICE while the MAP process is waiting for a service indication, the MAP process sends a MAP_CLOSE request to terminate the dialogue and returns to the idle state.




Figure 21.2/4 (sheet 1 of 3): Process SRI_HLR




Figure 21.2/4 (sheet 2 of 3): Process SRI_HLR




Figure 21.2/4 (sheet 3 of 3): Process SRI_HLR

21.2.4 Process in the VLR to provide a roaming number

The MAP process in the VLR to provide a roaming number for a mobile terminating call is shown in figure 21.2/5. The MAP process invokes a macro not defined in this subclause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Successful outcome

When the MAP process receives a MAP_OPEN indication with the application context roamingNbEnquiry, it checks it by invoking the macro Receive_Open_Ind.

If the macro takes the OK exit, the MAP process waits for a service indication.

If a MAP_PROVIDE_ROAMING_NUMBER service indication is received, the MAP process sends a Provide Roaming Number request to the call handling process in the VLR, and waits for a response. The Provide Roaming Number request contains the parameters received in the MAP_PROVIDE_ROAMING_NUMBER service indication.

If the call handling process in the VLR returns a Provide Roaming Number ack, the MAP process constructs a MAP_PROVIDE_ROAMING_NUMBER service response containing the roaming number contained in the Send Routeing Info ack, constructs a MAP_CLOSE service request, sends them to the HLR and returns to the idle state.

Earlier version MAP dialogue with the HLR

If the macro Receive_Open_Ind takes the Vr exit, the the VLR performs the earlier version MAP dialogue as specified in [51] or [96] and the process returns to the idle state.

Failure of dialogue opening with the HLR

If the macro Receive_Open_Ind takes the Error exit, the MAP process returns to the idle state.

If the MAP provider sends a MAP_P_ABORT while the MAP process is waiting for a service indication, the MAP process returns to the idle state.

If the MAP provider sends a MAP_NOTICE while the MAP process is waiting for a service indication, the MAP process sends a MAP_CLOSE request to terminate the dialogue and returns to the idle state.

Negative response from VLR call handling process

If the call handling process in the HLR returns a negative response, the MAP process constructs a MAP_PROVIDE_ROAMING_NUMBER service response containing the appropriate error, constructs a MAP_CLOSE service request, sends them to the HLR and returns to the idle state.




Figure 21.2/5: Process PRN_VLR

21.2.5 Process in the VLR to restore subscriber data

The MAP process in the HLR to restore subscriber data is shown in figure 21.2/6. The MAP process invokes macros not defined in this subclause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2;
Insert_Subs_Data_VLR	see subclause 25.7.1;
Activate_Tracing_VLR	see subclause 25.9.3.

Successful outcome

When the MAP process receives a Restore Data request from the data restoration process in the VLR, it requests a dialogue with the HLR whose identity is contained in the Restore Data request by sending a MAP_OPEN service request, requests data restoration using a MAP_RESTORE_DATA service request and invokes the macro Receive_Open_Cnf to wait for the response to the dialogue opening request. If the dialogue opening is successful, the MAP process waits for a response from the HLR.

The VLR may receive a MAP_INSERT_SUBSCRIBER_DATA service indication from the HLR; this is handled by the macro Insert_Subs_Data_VLR as described in subclause 25.7.1, and the MAP process waits for a further response from the HLR.

The VLR may receive a MAP_ACTIVATE_TRACE_MODE service indication from the HLR; this is handled by the macro Activate_Tracing_VLR as described in subclause 25.9.3, and the MAP process waits for a further response from the HLR.

If the MAP process receives a MAP_RESTORE_DATA service confirm, it invokes the macro Check_Confirmation to check the content of the confirm.

If the Check_Confirmation macro takes the OK exit, the MAP process sends a Restore Data ack containing the information received from the HLR to the data restoration process in the VLR and returns to the idle state.

Error in MAP_RESTORE_DATA confirm

If the MAP_RESTORE_DATA service confirm contains a user error or a provider error, or the macro Check_Confirmation indicates that there is a data error, the MAP process sends a Restore Data negative response indicating the type of error to the call handling process in the HLR, and returns to the idle state.

Earlier version MAP dialogue with the HLR

If the macro Receive_Open_Cnf takes the Vr exit, the VLR performs the earlier MAP version dialogue as specified in [51] or [96] and the process terminates.

Dialogue opening failure

If the macro Receive_Open_Cnf indicates that the dialogue with the HLR could not be opened, the MAP process sends a negative response indicating system failure to the data restoration process in the GMSC and returns to the idle state.




Figure 21.2/6: Process Restore_Data_VLR

21.2.6 Process in the VLR to provide subscriber information

The MAP process in the VLR to provide subscriber information for a mobile terminating call subject to CAMEL invocation is shown in figure 21.2/6. The MAP process invokes a macro not defined in this subclause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Successful outcome

When the MAP process receives a MAP_OPEN indication with the application context subscriberInfoEnquiry, it checks it by invoking the macro Receive_Open_Ind.

If the macro takes the OK exit, the MAP process waits for a service indication.

If a MAP_PROVIDE_SUBSCRIBER_INFO service indication is received, the MAP process sends a Provide Subscriber Info request to the subscriber information request process in the VLR, and waits for a response. The Provide Subscriber Info request contains the parameters received in the MAP_PROVIDE_SUBSCRIBER_INFO service indication.


If the subscriber information request process in the VLR returns a Provide Subscriber Info ack, the MAP process constructs a MAP_PROVIDE_SUBSCRIBER_INFO service response containing the information contained in the Provide Subscriber Info ack, constructs a MAP_CLOSE service request, sends them to the HLR and returns to the idle state.

Failure of dialogue opening with the HLR

If the macro Receive_Open_Ind takes the Vr exit or the Error exit, the MAP process returns to the idle state.

If the MAP provider sends a MAP_P_ABORT while the MAP process is waiting for a service indication, the MAP process returns to the idle state.

If the MAP provider sends a MAP_NOTICE while the MAP process is waiting for a service indication, the MAP process sends a MAP_CLOSE request to terminate the dialogue and returns to the idle state.

**Figure 21.2/7: Process PSI_VLR**

21.2.7 Process in the HLR for Any Time Interrogation

The message flows for successful retrieval of subscriber information related to an any time interrogation from the CAMEL server are shown in figure 21.2/8.




Figure 21.2/8: Message flow for any time interrogation

The following MAP services are used to retrieve routing information:

- MAP_ANY_TIME_INTERROGATION see subclause 8.11.1;
- MAP_PROVIDE_SUBSCRIBER_INFO see subclause 8.11.2;

21.2.7.1 Process in the gsmSCF

Out of the scope of the MAP specification.

21.2.3 Process in the HLR

The MAP process in the HLR to provide subscriber information in response to an interrogation from the CAMEL server is shown in figure 21.2/8. The MAP process invokes macros not defined in this subclause; the definitions of these macros can be found as follows:

- | | |
|--------------------|-----------------------|
| Receive_Open_Ind | see subclause 25.1.1; |
| Receive_Open_Cnf | see subclause 25.1.2; |
| Check_Confirmation | see subclause 25.2.2. |

Successful outcome

When the MAP process receives a MAP_OPEN indication with the application context anyTimeInterrogationEnquiry, it checks it by invoking the macro Receive_Open_Ind.

If the macro takes the OK exit, the MAP process waits for a service indication.

If a MAP_ANY_TIME_INTERROGATION service indication is received, the MAP process sends an Any Time Interrogation request to the call handling process in the HLR (described in GSM 03.78), and waits for a response. The Any Time Interrogation request contains the parameters received in the MAP_ANY_TIME_INTERROGATION service indication.

If the call handling process in the HLR returns an Any Time Interrogation response, the MAP process constructs a MAP_ANY_TIME_INTERROGATION service response containing the subscriber information contained in the Any Time Interrogation response, constructs a MAP_CLOSE service request, sends them to the CAMEL server and returns to the idle state.

If the call handling process in the HLR returns a Provide Subscriber Info request, the MAP process requests a dialogue with the VLR whose identity is contained in the Provide Subscriber Info request by sending a MAP_OPEN service request, requests the subscriber status using a MAP_PROVIDE_SUBSCRIBER_INFO service request, and invokes the macro Receive_Open_Cnf to wait for the response to the dialogue opening request.

If the macro takes the OK exit, the MAP process waits for the response from the VLR.

If the MAP process receives a MAP_PROVIDE_SUBSCRIBER_INFO service confirm, it invokes the macro Check_Confirmation to check the content of the confirm.

If the Check_Confirmation macro takes the OK exit, the MAP process sends a Provide Subscriber Info ack containing the information received in the MAP_PROVIDE_SUBSCRIBER_INFO service confirm to the call handling process in the HLR, and waits for a response. The handling of the response from the call handling process in the HLR is described above.

If the MAP_PROVIDE_SUBSCRIBER_INFO service confirm contains a provider error or a data error, the MAP process sends a Provide Subscriber Info negative response indicating the type of error to the call handling process in the HLR, and waits for a response. The handling of the response from the call handling process in the HLR is described above.

NOTE: The 'User Error' exit from the macro Check_Confirmation is shown for formal completeness; the MAP_PROVIDE_SUBSCRIBER_INFO_cnf primitive cannot contain a user error.

Negative response from HLR call handling process

If the call handling process in the HLR returns a negative response, either before or after a dialogue with the VLR to obtain subscriber information, the MAP process constructs a MAP_ANY_TIME_INTERROGATION service response containing the appropriate error, constructs a MAP_CLOSE service request, sends them to the CAMEL server and returns to the idle state.

Failure of Provide Subscriber Info dialogue with the VLR

If the Receive_Open_Cnf macro takes the Vr exit or the Error exit after the MAP process has requested opening of a Provide Subscriber Info dialogue with the VLR, the MAP process sends a Provide Subscriber Info negative response indicating system failure to the call handling process in the HLR, and waits for a response. The handling of the response from the call handling process in the HLR is described above.

Failure of dialogue opening with the CAMEL server

If the macro Receive_Open_Ind takes the Vr or Error exit, the MAP process returns to the idle state.

If the MAP provider sends a MAP_P_ABORT while the MAP process is waiting for a service indication, the MAP process returns to the idle state.

If the MAP provider sends a MAP_NOTICE while the MAP process is waiting for a service indication, the MAP process sends a MAP_CLOSE request to terminate the dialogue and returns to the idle state.




Figure 21.2/9 (sheet 1 of 2): Process ATI_HLR (New)





Figure 21.2/9 (sheet 2 of 2): Process ATI_HLR (New)

21.3 Transfer of call handling

21.3.1 General

The message flow for successful transfer of call handling to forward a call is shown in figure 21.3/1.



NOTES:

xxx = Optional Procedure

TUP or ISUP may be used in signalling between MSCs, depending on the network type between the MSCs. For further details on the TUP and ISUP procedures refer to the following CCITT Recommendations & ETSI specification:

- Q.721-725 - Telephone User Part (TUP);
- ETS 300 356-1 - Integrated Services Digital Network (ISDN); Signalling System No.7; ISDN User Part (ISUP) version 2 for the international interface; Part 1: Basic services.

Figure 21.3/1: Message flow for transfer of call handling

If the HLR indicated in the response to the original request for routeing information that forwarding interrogation is required, the GMSC executes the Send Routeing Information procedure with the HLR to obtain forwarding information; otherwise the GMSC uses the forwarding data which were sent in the MAP_RESUME_CALL_HANDLING req/ind.

21.3.2 Process in the VMSC

The MAP process in the VMSC to retrieve routeing information for a mobile terminating call is shown in figure 21.3/2. The MAP process invokes macros not defined in this subclause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2.

Successful Outcome

When the MAP process receives a Resume Call Handling request from the call handling process in the VMSC, it requests a dialogue with the GMSC whose identity is contained in the Resume Call Handling request by sending a MAP_OPEN service request, requests routeing information using a MAP_RESUME_CALL_HANDLING service request and invokes the macro Receive_Open_Cnf to wait for the response to the dialogue opening request. If the dialogue opening is successful, the MAP process waits for a response from the GMSC. VMSC shall not send any duplicate data to the GMSC.

If the VMSC notices after receiving a Resume Call Handling request that the segmentation is needed the VMSC does not set the “All Information Sent” indicator. Otherwise the indicator is set and the process returns to the Wait For GMSC Response state.

If the MAP process receives a MAP_RESUME_CALL_HANDLING service confirm from the GMSC, the MAP process invokes the macro Check_Confirmation to check the content of the confirm.

If the macro Check_Confirmation takes the OK exit, the MAP process checks if the “All Information Sent” indicator is set. If it is set the MAP process sends a Resume Call Handling ack to the call handling process in the VMSC and returns to the idle state. If the “All Information Sent” indicator is not set the MAP process checks if the further segmentation is needed. If segmentation is needed the VMSC does not set the indicator and sends MAP_RESUME_CALL_HANDLING service request to the GMSC. Otherwise the indicator is set and the MAP_RESUME_CALL_HANDLING service request is sent to the GMSC.

Dialogue opening failure

If the macro Receive_Open_Cnf indicates that the dialogue with the GMSC could not be opened or that the dialogue can be opened only at an earlier version, the MAP process sends an Resume Call Handling negative response indicating system failure to the call handling process in the VMSC and returns to the idle state.

Error in MAP_RESUME_CALL_HANDLING confirm

If the MAP_RESUME_CALL_HANDLING service confirm contains a user error or a provider error, the MAP process sends a Resume Call Handling negative response to the call handling process in the VMSC and returns to the idle state.

NOTE: the 'Data Error' exit from the macro Check_Confirmation is shown for formal completeness; the result is empty, so the MAP_PROVIDE_SUBSCRIBER_INFO_cnf primitive cannot contain a data error.]

Abort of GMSC dialogue

After the dialogue with the GMSC has been established, the MAP service provider may abort the dialogue by issuing a MAP_P_ABORT indication, or the GMSC may send a MAP_CLOSE indication. In either of these cases, the MAP process sends a Resume Call Handling negative response to the call handling process in the GMSC and returns to the idle state.

If the MAP provider indicates a protocol problem by sending a MAP_NOTICE indication, the MAP process closes the dialogue with the GMSC, sends a Resume Call Handling negative response indicating system failure to the call handling process in the VMSC and returns to the idle state.




Figure 21.3/2: Process RCH_VMSC

21.3.3 Process in the GMSC

The MAP process in the GMSC to handle a request for the GMSC to resume call handling is shown in figure 21.3/3. The MAP process invokes a macro not defined in this subclause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Successful outcome

When the MAP process receives a MAP_OPEN indication with the application context callControlTransfer, it checks it by invoking the macro Receive_Open_Ind.

If the macro takes the OK exit, the MAP process waits for a service indication.

If a MAP_RESUME_CALL_HANDLING service indication is received, the MAP process checks if the “All Information Sent” indicator is set and if so it sends a Resume Call Handling request including all the stored data to the call handling process in the GMSC, and waits for a response. The Resume Call Handling request contains the parameters received in the MAP_RESUME_CALL_HANDLING service indication. If the “All Information Sent” indicator is not set, the received data is stored and the MAP process constructs an empty MAP_RESUME_CALL_HANDLING service response, sends it to the VMSC and returns to the Wait For Service Indication state.

If the call handling process in the GMSC returns a Resume Call Handling ack, the MAP process constructs a MAP_RESUME_CALL_HANDLING service response, constructs a MAP_CLOSE service request, sends them to the VMSC and returns to the idle state.

Failure of dialogue opening with the VMSC

If the macro Receive_Open_Ind takes the Vr exit or the Error exit, the MAP process returns to the idle state.

If the MAP provider sends a MAP_P_ABORT while the MAP process is waiting for a service indication, the MAP process returns to the idle state.

If the MAP provider sends a MAP_NOTICE while the MAP process is waiting for a service indication, the MAP process sends a MAP_CLOSE request to terminate the dialogue and returns to the idle state.





Figure 21.3/3: Process RCH_GMSC

21.4 Inter MSC Group Call Procedures

21.4.1 General

The message flows for successful inter MSC group call / broadcast call setup is shown in figure 21.4/1.



NOTE 1: TUP or ISUP may be used in signalling between MSCs, depending on the network type between the MSCs. For further details on the TUP and ISUP procedures refer to the following ITU-T Recommendations and ETSI specification:

- Q.721-725 - Telephone User Part (TUP);
- ETS 300 356-1 - Integrated Services Digital Network (ISDN); Signalling System No.7; ISDN User Part (ISUP) version 2 for the international interface; Part 1: Basic services.

NOTE 2: The MAP_FORWARD_GROUP_CALL_SIGNALLING and MAP_PROCESS_GROUP_CALL_SIGNALLING services are not applicable for voice broadcast calls.

Figure 21.4/1: Message flow for inter MSC group call / broadcast call

21.4.2 Process in the Anchor MSC

The MAP process in the Anchor MSC to retrieve and transfer information from / to the Relay MSC for VBS and VGCS calls is shown in figure 21.4/2. The MAP process invokes macros not defined in this subclause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Indication	see subclause 25.2.1;
Check_Confirmation	see subclause 25.2.2.

Successful Outcome

When the MAP process receives a Prepare Group Call request from the ASCI handling process in the anchor MSC, it requests a dialogue with the relay MSC whose identity is contained in the Prepare Group Call request by sending a MAP_OPEN service request, requests an Group Call number by using a MAP_PREPARE_GROUP_CALL service request and invokes the macro Receive_Open_Cnf to wait for the response to the dialogue opening request. If the dialogue opening is successful, the MAP process waits for a response from the relay MSC.

If the MAP process receives a MAP_PREPARE_GROUP_CALL service confirm from the relay MSC, the MAP process invokes the macro Check_Confirmation to check the content of the confirm.

If the macro Check_Confirmation takes the OK exit, the MAP process sends a Prepare Group Call ack containing the Group Call number received from the relay MSC to the ASCI handling process in the anchor MSC and waits for completion of call setup in the relay MSC.

On receipt of a MAP_SEND_GROUP_CALL_END_SIGNAL service indication from the relay MSC the MAP process invokes the macro Check_Indication to check the content of the indication.

If the macro Check_Indication takes the OK exit, the MAP process sends a Send Group Call End Signal to the ASCI handling process in the anchor MSC and waits for uplink management signals. In this state the following events are processed:

- Reception of a Send Group Call End Signal ack from the ASCI handling process in the anchor MSC;
- Reception of a Forward Group Call Signalling request from the ASCI handling process in the anchor MSC;
- Reception of a MAP_PROCESS_GROUP_CALL_SIGNALLING service indication from the relay MSC.

On reception of a Send Group Call End Signal ack from the ASCI handling process in the anchor MSC, the MAP process constructs a MAP_SEND_GROUP_CALL_END_SIGNAL service response, constructs a MAP_CLOSE service request, sends them to the relay MSC and returns to the idle state.

On reception of a Forward Group Call Signalling request from the ASCI handling process in the anchor MSC, the MAP process constructs a MAP_FORWARD_GROUP_CALL_SIGNALLING service request, sends it to the relay MSC and returns to the uplink management state.

On reception of a MAP_PROCESS_GROUP_CALL_SIGNALLING service indication from the relay MSC, the MAP process invokes the macro Check_Indication to check the content of the indication.

If the macro Check_Indication takes the OK exit, the MAP process sends a Process Group Call Signalling to the ASCI handling process in the anchor MSC and returns to the uplink management state.

Dialogue opening failure

If the macro Receive_Open_Cnf indicates that the dialogue with the relay MSC could not be opened, the MAP process sends an Abort to the ASCI handling process and returns to the idle state.


Error in MAP_PREPARE_GROUP_CALL confirm

If the MAP_PREPARE_GROUP_CALL service confirm contains a user error or a provider error, or the macro Check_Confirmation indicates that there is a data error, the MAP process sends a Prepare Group Call negative response to the ASCI handling process in the anchor MSC, sends a MAP_U_ABORT request to the relay MSC and returns to the idle state.

Abort of MAP dialogue

After the dialogue with the relay MSC has been established, the MAP service provider may abort the dialogue by issuing a MAP_P_ABORT indication, or the relay MSC may send a MAP_U_ABORT indication or a MAP_CLOSE indication. In any of these cases, the MAP process sends an Abort to the ASCI handling process in the anchor MSC and returns to the idle state.

If the MAP provider indicates a protocol problem by sending a MAP_NOTICE indication, the MAP process closes the dialogue with the relay MSC, sends an Abort to the ASCI handling process in the anchor MSC and returns to the idle state.

**Figure 21.4/2 (sheet 1 of 4): Process ASCI_Anchor_MSC**




Figure 21.4/2 (sheet 2 of 4): Process ASCI_Anchor_MSC

Process ASCI_Anchor_MSC

21.4_2.3(4)

Figure 21.4/2: Process in the
Anchor MSC for ASCI call
handling

Signals to/from the left are
to/from the A-MSC ASCI process;
signals to/from the right are to/from
the R-MSC




Figure 21.4/2 (sheet 3 of 4): Process ASCI_Anchor_MSC

Process ASCI_Anchor_MSC

21.4_2.4(4)

Figure 21.4/2: Process in the
Anchor MSC for ASCI call
handling

Signals to/from the left are
to/from the A-MSC ASCI process;
signals to/from the right are to/from
the R-MSC




Figure 21.4/2 (sheet 4 of 4): Process ASCI_Anchor_MSC

21.4.3 Process in the Relay MSC

The MAP process in the Relay MSC to receive and transfer information from / to the Anchor MSC for VBS and VGCS calls is shown in figure 21.4/3. The MAP process invokes macros not defined in this subclause; the definitions of these macros can be found as follows:

Receive_Open_Ind see subclause 25.1.2;

Check_Indication see subclause 25.2.1.

Successful Outcome

When the MAP process receives a MAP_OPEN indication with the application context groupCallControl, it checks it by invoking the macro Receive_Open_Ind.

If the macro takes the OK exit, the MAP process waits for a service indication.

If a MAP_PREPARE_GROUP_CALL service indication is received, the MAP process invokes the macro Check_Indication.

If the macro takes the OK exit, the MAP process sends a Prepare Group Call request to the ASCI handling process in the relay MSC and waits for a response. The Prepare Group Call request contains the parameters received in the MAP_PREPARE_GROUP_CALL service indication.

If the ASCI handling process in the relay MSC returns a Prepare Group Call ack, the MAP process constructs a MAP_PREPARE_GROUP_CALL service response containing the information contained in the Prepare Group Call ack, constructs a MAP_DELIMITER service request, sends them to the anchor MSC and waits for the GROUP CALL END SIGNAL.

If the ASCI handling process in the relay MSC sends a Send Group Call End Signal request to the MAP process, the MAP process constructs a MAP_SEND_GROUP_CALL_END_SIGNAL service request containing the information contained in the SEND GROUP CALL End Signal request, constructs a MAP_DELIMITER service request, sends them to the anchor MSC and waits for uplink management signals. In this state the following events are processed:

- Reception of a MAP_SEND_GROUP_CALL_END_SIGNAL service confirmation from the anchor MSC;
- Reception of a MAP_FORWARD_GROUP_CALL_SIGNALLING service indication from the anchor MSC;
- Reception of a Process Group Call Signalling request from the ASCI handling process in the relay MSC.

On reception of a MAP_SEND_GROUP_CALL_END_SIGNAL service confirmation from the anchor MSC, the MAP process returns to the idle state.

On reception of a MAP_FORWARD_GROUP_CALL_SIGNALLING service indication from the anchor MSC, the MAP process invokes the macro Check Indication. If the macro takes the OK exit, the MAP process sends a Forward Group Call Signalling request to the ASCI handling process in the relay MSC and waits for further uplink management signals.

On reception of a Process Group Call Signalling request from the ASCI handling process in the relay MSC, the MAP process constructs a MAP_PROCESS_GROUP_CALL_SIGNALLING service request containing the information received in the Process Group Call Signalling request, constructs a MAP_DELIMITER service request, sends them to the anchor MSC and waits for further uplink management signals.

Failure of dialogue opening with the anchor MSC

If the macro Receive_Open_Ind takes the Error exit, the MAP process returns to the idle state.

If the MAP provider sends a MAP_P_ABORT while the MAP process is waiting for a service indication, the MAP process returns to the idle state.

If the MAP provider sends a MAP_NOTICE while the MAP process is waiting for a service indication, the MAP process sends a MAP_CLOSE request to terminate the dialogue and returns to the idle state.

Error in MAP_PREPARE_GROUP_CALL indication

If the macro Check Indication takes the Error exit, the MAP process sends a MAP_U_ABORT request to the anchor MSC and returns to the idle state.

Negative response received from the ASCI handling process

If the ASCI handling process in the relay MSC returns a negative response to the Prepare Group Call request, the MAP process constructs a MAP_PREPARE_GROUP_CALL service response containing the appropriate error, constructs a MAP_CLOSE service request, sends them to the anchor MSC and returns to the idle state.

Error in MAP_FORWARD_GROUP_CALL_SIGNALLING indication

If the macro Check Indication takes the Error exit, the MAP process sends a MAP_U_ABORT request to the anchor MSC, sends an Abort to the ASCI handling process in the relay MSC and returns to the idle state.

Abort of MAP dialogue

After the dialogue with the anchor MSC has been established, the MAP service provider may abort the dialogue by issuing a MAP_P_ABORT indication, or the anchor MSC may send a MAP_U_ABORT indication or a MAP_CLOSE indication. In any of these cases, the MAP process sends an Abort to the ASCI handling process in the relay MSC and returns to the idle state.

If the MAP provider indicates a protocol problem by sending a MAP_NOTICE indication, the MAP process closes the dialogue with the anchor MSC, sends an Abort to the ASCI handling process in the anchor MSC and returns to the idle state.




Figure 21.4/3 (sheet 1 of 3): Process ASCI_Relay_MSC

Process ASCI_Relay_MSC

21.4_3.2(3)

Figure 21.4/3: Process in the Relay MSC for ASCI call handling

Signals to/from the left are
to/from the A-MSC;
Signals to/from the right are
to/from the R-MSC ASCI process





Figure 21.4/3 (sheet 2 of 3): Process ASCI_Relay_MSC

Process ASCI_Relay_MSC

21.4_3.3(3)

Figure 21.4/3: Process in the Relay MSC for ASCI call handling

Signals to/from the left are to/from the A-MSC;
 Signals to/from the right are to/from the R-MSC ASCI process





Figure 21.4/3 (sheet 3 of 3): Process ASCI_Relay_MSC

21.5 Allocation and modifications of resources in an SIWFS

21.5.1 General

The message flow for successful allocation and modification of resources in an SIWFS is shown in figure 21.5/1 (mobile originating call non-loop method), 21.5/2 (mobile originating call loop method) and 21.5/3 (mobile terminating call loop method).



Notes: xxx = Optional Procedure


NOTE 1: TUP or ISUP may be used in signalling between MSCs, depending on the network type between the MSCs. The Release message can be initiated either by the calling or called subscriber. For further details on the TUP and ISUP procedures refer to the following CCITT Recommendations & ETSI specification:

- Q.721-725 - Telephone User Part (TUP);
- ETS 300 356-1 - Integrated Services Digital Network (ISDN); Signalling System No.7; ISDN User Part (ISUP) version 2 for the international interface; Part 1: Basic services.

NOTE 2: The number on the ISUP messages have been added to link the messages to respective signalling sequence.

NOTE 3: The modification of SIWF resources could be initiated any time during the call either by the VMSC or the SIWFS.

Figure 21.5/1: Message flow for mobile originating call non-loop method




Notes: xxx = Optional Procedure

NOTE 1: TUP or ISUP may be used in signalling between MSCs, depending on the network type between the MSCs. The Release message can be initiated either by calling or called subscriber. For further details on the TUP and ISUP procedures refer to the following CCITT Recommendations & ETSI specification:

- Q.721-725 - Telephone User Part (TUP);
- ETS 300 356-1 - Integrated Services Digital Network (ISDN); Signalling System No.7; ISDN User Part (ISUP) version 2 for the international interface; Part 1: Basic services.

NOTE 2: The number on the ISUP messages have been added to link the messages to respective signalling sequence.

NOTE 3: The modification of SIWF resources could be initiated any time during the call either by the VMSC or the SIWFS.

Figure 21.5/2: Message flow for mobile originating call loop method

Notes: *xxx = Optional Procedure*

NOTE 1: TUP or ISUP may be used in signalling between MSCs, depending on the network type between the MSCs. The Release message can be initiated either by calling or called subscriber. For further details on the TUP and ISUP procedures refer to the following CCITT Recommendations & ETSI specification:

- Q.721-725 - Telephone User Part (TUP);
- ETS 300 356-1 - Integrated Services Digital Network (ISDN); Signalling System No.7; ISDN User Part (ISUP) version 2 for the international interface; Part 1: Basic services.

NOTE 2: The number on the ISUP messages have been added to link the messages to respective signalling sequence.

NOTE 3: The modification of SIWFS resources could be initiated any time during the call either by the VMSC or the SIWFS.

Figure 21.5/3: Message flow for mobile terminating call loop method

The following MAP services are used to allocate resources in an SIWFS:

MAP_PROVIDE_SIWF_NUMBER see subclause 10.4.

The following MAP services are used to modify resources in an SIWFS:

MAP_SIWF_SIGNALLING MODIFY see subclause 10.5.

21.5.2 Process in the VMSC

The MAP process in the VMSC to allocate and modify resources in an SIWFS for a mobile call is shown in figure 21.5/4. The MAP process invokes macros not defined in this subclause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

21.5.2.1 Allocation of SIWFS resources

Successful Outcome

When the MAP process receives a Provide SIWFS Number request from the call handling process in the VMSC, it requests a dialogue with the SIWFS whose identity is contained in the Provide SIWFS Number request by sending a MAP_OPEN service request, requests resources in the SIWFS using a MAP_PROVIDE_SIWF_NUMBER service request and invokes the macro Receive_Open_Cnf to wait for the response to the dialogue opening request. If the dialogue opening is successful, the MAP process waits for a response from the SIWFS.

If the MAP process receives a MAP_PROVIDE_SIWF_NUMBER service confirm from the SIWFS, the MAP process invokes the macro Check_Confirmation to check the content of the confirm.

If the macro Check_Confirmation takes the OK exit, the MAP process sends a Provide SIWFS Number ack containing the SIWFS Number received from the SIWFS to the call handling process in the VMSC and go to Wait_Modification state.

Earlier version MAP dialogue with the SIWFS

If the macro Receive_Open_Cnf takes the Vr exit, the MAP process sends an Abort to the call handling process in the VMSC and returns to the idle state.

Dialogue opening failure

If the macro Receive_Open_Cnf indicates that the dialogue with the SIWFS could not be opened, the MAP process sends an Abort to the call handling process in the VMSC and returns to the idle state.

Error in MAP_PROVIDE_SIWF_NUMBER confirm

If the MAP_PROVIDE_SIWF_NUMBER service confirm contains a user error or a provider error, or the macro Check_Confirmation indicates that there is a data error, the MAP process sends a Provide SIWFS number negative response to the call handling process in the VMSC and returns to the idle state.

Call release

If the call handling process in the VMSC indicates that the call has been aborted, the MAP process returns to the idle state. Any response from the SIWFS will be discarded.

If the call handling process in the VMSC indicates that the traffic channel has been released (i.e. call released by a user) a MAP_CLOSE_req is sent and the process is returned to the idle state.

Abort of SIWFS dialogue

During the time an answer is expected from the SIWFS, the MAP service provider may abort the dialogue by issuing a MAP_P_ABORT indication, or the SIWFS may send a MAP_U_ABORT indication or a MAP_CLOSE indication. In any of these cases, the MAP process sends a Provide SIWFS number negative response to the call handling process in the VMSC and returns to the idle state.

If the MAP provider indicates a protocol problem by sending a MAP_NOTICE indication, the MAP process closes the dialogue with the SIWFS, sends a Provide SIWFS number negative response indicating system failure to the call handling process in the VMSC and returns to the idle state.

After the dialogue with the SIWFS has been established, the MAP service provider may abort the dialogue by issuing a MAP_P_ABORT indication, or the SIWFS may send a MAP_U_ABORT indication or a MAP_CLOSE indication. In any of these cases, the MAP process returns to the idle state.

If the MAP provider indicates a protocol problem by sending a MAP_NOTICE indication, the MAP process closes the dialogue with the SIWFS, and returns to the idle state.

21.5.2.2 Modification of SIWFS resources initiated by the user

Successful Outcome

When the MAP process receives an SIWFS Signalling Modify request from the call handling process in the VMSC, it requests a dialogue with the SIWFS whose identity is contained in the SIWFS Signalling Modify request by sending a MAP_SIWFSSIGNALLING_MODIFY service request and waits for a response from the SIWFS.

If the MAP process receives a MAP_SIWFSSIGNALLING_MODIFY service confirm from the SIWFS, the MAP process invokes the macro Check_Confirmation to check the content of the confirm.

If the macro Check_Confirmation takes the OK exit, the MAP process sends an SIWFS Signalling Modify ack containing the response received from the SIWFS to the call handling process in the VMSC and go to Wait_For_Modification state.

Error in MAP_SIWFSSIGNALLING_MODIFY confirm

If the MAP_SIWFSSIGNALLING_MODIFY service confirm contains a user error or a provider error, or the macro Check_Confirmation indicates that there is a data error, the MAP process sends an SIWFS Signalling Modify negative response to the call handling process in the VMSC and go to Wait_For_Modification state.

Abort of SIWFS dialogue

During the time an answer is expected from the SIWFS, the MAP service provider may abort the dialogue by issuing a MAP_P_ABORT indication, or the SIWFS may send a MAP_U_ABORT indication or a MAP_CLOSE indication. In any of these cases, the MAP process sends an SIWFS Signalling Modify negative response to the call handling process in the VMSC and returns to the idle state.

If the MAP provider indicates a protocol problem by sending a MAP_NOTICE indication, the MAP process closes the dialogue with the SIWFS, sends an SIWFS Signalling Modify negative response indicating system failure to the call handling process in the VMSC and returns to the idle state.

21.5.2.3 Modification of SIWFS resources initiated by the SIWFS

Successful outcome

If a MAP_SIWFSSIGNALLING_MODIFY service indication is received, the MAP process sends an SIWFS signalling modify Info request to the call handling process in the VMSC, and waits for a response. The SIWFS

signalling modify request contains the parameters received in the MAP_SIWF_Signalling MODIFY service indication.

If the call handling process in the VMSC returns an SIWFS signalling modify ack, the MAP process constructs a MAP_SIWF_Signalling MODIFY service response contained in the Provide SIWFS Number ack, send it to the SIWFS and go to Wait_For_Modification state.

Negative response from VMSC call handling process

If the call handling process in the VMSC returns a negative response the MAP process constructs a MAP_SIWF_Signalling MODIFY service response containing the appropriate error, send it to the SIWFS and go to Wait_For_Modification state.




Figure 21.5/4 (sheet 1 of 6): Process SRA (SIWFS_RESOURCE_ADMINISTRATION)_VMSC




Figure 21.5/4 (sheet 2 of 6): Process SRA_VMSC




Figure 21.5/4 (sheet 3 of 6): Process SRA_VMSC




Figure 21.5/4 (sheet 4 of 6): Process SRA_VMSC




Figure 21.5/4 (sheet 5 of 6): Process SRA_VMSC




Figure 21.5/4 (sheet 6 of 6): Process SRA_VMSC

21.5.3 Process in the SIWFS

The MAP process in the SIWFS to allocate and modify SIWFS resources for a mobile call is shown in figure 21.5/5. The MAP process invokes macros not defined in this subclause; the definitions of these macros can be found as follows:

Receive_Open_Ind see subclause 25.1.1.

Check_Confirmation see subclause 25.2.2.

21.5.3.1 Procedures for allocation of SIWFS resources

Successful outcome

When the MAP process receives a MAP_OPEN indication with the application context locInfoRetrieval, it checks it by invoking the macro Receive_Open_Ind.

If the macro takes the OK exit, the MAP process waits for a service indication.

If a MAP_PROVIDE_SIWFNS_NUMBER service indication is received, the MAP process sends a Provide SIWFS number Info request to the call handling process in the SIWFS, and waits for a response. The Provide SIWFS number request contains the parameters received in the MAP_PROVIDE_SIWFNS_NUMBER service indication.

If the call handling process in the SIWFS returns a Provide SIWFS number ack, the MAP process constructs a MAP_PROVIDE_SIWFNS_NUMBER service response containing the routing information contained in the Provide SIWFS Number ack, constructs a MAP_DELIMITER service request, sends them to the VMSC and go to Wait_For_Modification state.

Earlier version MAP dialogue with the VMSC

If the macro Receive_Open_Ind takes the Vr exit, the MAP process returns to the idle state.

Dialogue opening failure

If the macro Receive_Open_Ind takes the Error exit, the MAP process returns to the idle state.

If the MAP provider sends a MAP_P_ABORT while the MAP process is waiting for a service indication, the MAP process returns to the idle state.

If the MAP provider sends a MAP_NOTICE while the MAP process is waiting for a service indication, the MAP process sends a MAP_CLOSE request to terminate the dialogue and returns to the idle state.

Negative response from SIWFS call handling process

If the call handling process in the SIWFS returns a negative response the MAP process constructs a MAP_PROVIDE_SIWFNS_NUMBER service response containing the appropriate error, constructs a MAP_CLOSE service request, sends them to the VMSC and returns to the idle state.

Call release

If the call handling process in the SIWFS indicates that the call has been aborted, the MAP process returns to the idle state. Any response from the VMSC will be discarded.

If the call handling process in the SIWFS indicates that the traffic channel has been released (i.e. call released by a user) a MAP_CLOSE_req is sent and the process is returned to the idle state.

Abort of VMSC dialogue

After the dialogue with the VMSC has been established, the MAP service provider may abort the dialogue by issuing a MAP_P_ABORT indication, or the VMSC may send a MAP_U_ABORT indication or a MAP_CLOSE indication. In any of these cases, the MAP process returns to the idle state.

If the MAP provider indicates a protocol problem by sending a MAP_NOTICE indication, the MAP process closes the dialogue with the VMSC, and returns to the idle state.

21.5.3.2 Process for modification of SIWFS resources initiated by the user

Successful outcome

If a MAP_SIWFSSIGNALLING_MODIFY service indication is received, the MAP process sends an SIWFS signalling modify Info request to the call handling process in the SIWFS, and waits for a response. The SIWFS signalling modify request contains the parameters received in the MAP_SIWFSSIGNALLING_MODIFY service indication.

If the call handling process in the SIWFS returns an SIWFS signalling modify ack, the MAP process constructs a MAP_SIWFSSIGNALLING_MODIFY service response contained in the Provide SIWFS Number ack, send it to the VMSC and go to Wait_For_Modification state.

Negative response from SIWFS call handling process

If the call handling process in the SIWFS returns a negative response the MAP process constructs a MAP_SIWFSSIGNALLING_MODIFY service response containing the appropriate error, send it to the VMSC and go to Wait_For_Modification state.

21.5.3.3 Process for modification of SIWFS resources initiated by the SIWFS

Successful Outcome

When the MAP process receives an SIWFS Signalling Modify request from the call handling process in the SIWF, it requests a dialogue with the VMSC whose identity is contained in the VMSC Signalling Modify request by sending a MAP_DELIMITER service request, requests resources in the VMSC using a MAP_SIWFSSIGNALLING_MODIFY service request, the MAP process waits for a response from the VMSC.

If the MAP process receives a MAP_SIWFSSIGNALLING_MODIFY service confirm from the VMSC, the MAP process invokes the macro Check_Confirmation to check the content of the confirm.

If the macro Check_Confirmation takes the OK exit, the MAP process sends an SIWFS Signalling Modify ack containing the response received from the VMSC to the call handling process in the SIWF and go to Wait_For_Modification state.

Error in MAP_SIWFSSIGNALLING_MODIFY confirm

If the MAP_SIWFSSIGNALLING_MODIFY service confirm contains a user error or a provider error, or the macro Check_Confirmation indicates that there is a data error, the MAP process sends an SIWFS Signalling Modify negative response to the call handling process in the SIWFS and go to Wait_For_Modification state.

Abort of SIWFS dialogue

During the time an answer is expected from the VMSC, the MAP service provider may abort the dialogue by issuing a MAP_P_ABORT indication, or the VMSC may send a MAP_U_ABORT indication or a MAP_CLOSE indication. In any of these cases, the MAP process sends an SIWFS Signalling Modify negative response to the call handling process in the SIWFS and returns to the idle state.

If the MAP provider indicates a protocol problem by sending a MAP_NOTICE indication, the MAP process closes the dialogue with the VMSC, sends an SIWFS Signalling Modify negative response indicating system failure to the call handling process in the SIWFS and returns to the idle state.




Figure 21.5/5 (sheet 1 of 5): Process SRA_SIWFs




Figure 21.5/5 (sheet 2 of 5): Process SRA_SIWFs

Process SRA_SIWFs

21.5_5.3(5)

Figure 21.5/5: Process in the SIWFS for administration of SIWFS resources

Signals to/from the left are to/from the SIWFS call handling process; signals to/from the right are to/from the VMSC




Figure 21.5/5 (sheet 3 of 5): Process SRA_SIWFs

Process SRA_SIWFs

21.5_5.4(5)




Figure 21.5/5 (sheet 4 of 5): Process SRA_SIWFs




Figure 21.5/5 (sheet 5 of 5): Process SRA_SIWFs

21.6 Setting of Reporting State

21.6.1 General

The message flow for setting the reporting state in a stand-alone dialogue is shown in figure 21.6.1/1.




Figure 21.6/1: Message Flow for Setting the Reporting State

In Set Reporting State, the HLR can request a start or a stop of monitoring in the VLR.

21.6.2 Process in the HLR for Set Reporting State stand-alone

The MAP process in the HLR to set the reporting state in the VLR in a separate stand-alone dialogue is shown in figure 21.6/2. The MAP process invokes macros not defined in this subclause; the definitions of these macros can be found as follows:

- | | |
|--------------------|-----------------------|
| Receive_Open_Cnf | see subclause 25.1.2; |
| Check_Confirmation | see subclause 25.2.2. |

Successful Outcome

When the MAP process receives a Start Reporting or Stop Reporting request from the CCBS application process in the HLR, it requests a dialogue with the VLR whose identity is contained in the request by sending a MAP_OPEN service request and sending the necessary information using a MAP_SET_REPORTING_STATE service request. The HLR then invokes the macro Receive_Open_Cnf to wait for the response to the dialogue opening request. If the dialogue opening is successful, the MAP process waits for a response from the VLR.

If the MAP process receives a MAP_SET_REPORTING_STATE service confirm from the VLR, the MAP process invokes the macro Check_Confirmation to check the content of the confirm.

If the macro Check_Confirmation takes the OK exit and the request was for Start Reporting, the MAP process sends a positive acknowledgement containing the information received from the VLR to the CCBS application process in the HLR and returns to the idle state. In the case of Stop Reporting the CCBS application process returns to the idle state.

Failure of dialogue opening with the VLR

If the macro Receive_Open_Cnf takes the Vr exit or the Error exit, the MAP process sends (in the case of Start Reporting) a negative response to the CCBS application process in the HLR and returns to the idle state. In the case of Stop Reporting the process returns to the idle state.

Error in MAP_SET_REPORTING_STATE confirm

If the MAP_SET_REPORTING_STATE service confirm contains a user error or a provider error, or the macro Check_Confirmation indicates that there is a data error, the MAP process sends a negative response (in the case of Start Reporting) to the CCBS application process in the HLR and returns to the idle state. In the case of Stop Reporting the CCBS application process returns to the idle state.

Abort of VLR dialogue

After the dialogue with the VLR has been established, the MAP service provider may abort the dialogue by issuing a MAP_P_ABORT or a MAP_U_ABORT indication. If the request was for the Start Reporting, the MAP process sends a Start Reporting negative response to the CCBS application process in the HLR and returns to the idle state.

If the MAP provider indicates a protocol problem by sending a MAP_NOTICE indication, the MAP process closes the dialogue with the VLR, sends a negative response (in the case of the Start Reporting) indicating system failure to the CCBS application process in the HLR and returns to the idle state. In the case of Stop Reporting the CCBS application process returns to the idle state.




Figure 21.6/2: Process Set_Reported_State_HLR

21.6.3 Reporting co-ordinator process in the VLR

The MAP co-ordinating process in the VLR to handle a dialogue opened with the reporting application context is shown in figure 21.6/3. The MAP process invokes a macro not defined in this subclause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1.

Any reporting process in the VLR starts by the VLR receiving a MAP-OPEN service indication. If that service is successful, the VLR can handle reporting indications from the HLR. Table 21.6/1 shows the co-ordinating process' reaction on receipt of specific reporting indications from the HLR. After the relevant process is invoked, the received service indication is sent to that process.

Table 21.6/1: Relationship between received service indication and invoked process in the VLR

Service indication received	Process invoked
MAP_REMOTE_USER_FREE_ind	REMOTE_USER_FREE_VLR
MAP_SET_REPORTING_STATE_ind	SET_REPORTING_STATE_VLR

After creation of the user process the co-ordinator relays the messages between the MAP protocol machine and the invoked process until a request or an indication for dialogue termination is received.




Figure 21.6/3: Process Reporting_Coord_VLR

21.6.4 Process in the VLR to set the reporting state

The MAP process in the VLR to set the reporting state is shown in figure 21.6/4.

The co-ordinator opens the process. The macro Receive_Set_Reportin g_State_VLR handles the receipt of the request from the HLR, and the possible response from the CCBS application process in the VLR. When the macro exits, a MAP CLOSE is sent to the HLR and the process terminates.

The macro Set_Reportin g_State_VLR is defined in figure 21.6/5.

When the VLR receives a MAP_SET_REPORTING_STATE service indication, it checks whether the required monitoring state is stopped.

If the required monitoring state is stopped, the MAP process sends a Stop Reporting message to the CCBS application in the VLR, sends a MAP_SET_REPORTING_STATE response to the HLR and exits from the macro.

If the required monitoring state is started, the MAP process sends a Start Reporting message to the CCBS application in the VLR and waits for a response.

If the CCBS application sends a Start Reporting ack, the MAP process sends a MAP_SET_REPORTING_STATE response to the HLR and exits from the macro.

If the CCBS application sends a Start Reporting negative response, the MAP process translates the negative response into a MAP user error, sends a MAP_SET_REPORTING_STATE response to the HLR and exits from the macro.




Figure 21.6/4: Process Set_Reported_State_VLR

Macrodefinition Receive_Set_Reportin g_ State_VLR

21.6_5(1)

Figure 21.6/5: Macro in the VLR
to handle a Set Reporting
State instruction from
the HLR

Signals to/from the left
are to/from the CCBS
application process
in the VLR;
signals to/from the right
are to/from the HLR




Figure 21.6/5: Macro Receive_Set_Reportin g_ State_VLR

21.7 Status Reporting

21.7.1 General

The message flows for reporting the status of a subscriber are shown in figures 21.7/1 and 21.7/2.




Figure 21.7/1: Status reporting, when monitoring continues in the VLR




Figure 21.7/2: Status reporting, when monitoring stops

When the HLR sends a `MAP_SET_REPORTING_STATE`, it requests the stop of monitoring in the VLR.

21.7.2 Process in the VLR for Status Reporting

The MAP process in the VLR to send a status report to the HLR is shown in figure 21.7/3. The MAP process invokes macros not defined in this subclause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2.

Successful Outcome

When the MAP process receives a Event Report or CCBS Call Report from the CCBS application process in the VLR, it requests a dialogue with the HLR whose identity is contained in the request by sending a MAP_OPEN service request, and requests status report using a MAP_STATUS_REPORT service request. The VLR then invokes the macro Receive_Open_Cnf to wait for the response to the dialogue opening request. If the dialogue opening is successful, the MAP process waits for a response from the HLR.

If the MAP process receives a MAP_STATUS_REPORT service confirm from the HLR, the MAP process invokes the macro Check_Confirmation to check the content of the confirm.

If the macro Check_Confirmation takes the OK exit, the MAP process sends an Event Report ack or a CCBS Call Report ack containing the information received from the HLR to the CCBS application process in the VLR and waits for a possible instruction from the HLR to set the reporting state.

If the HLR requests the VLR to set a reporting state (in the macro Receive_Set_Reporting_State_VLR), the VLR closes the dialogue with the HLR by sending a MAP CLOSE to the HLR.

If the HLR requires monitoring in the VLR to continue, it closes the dialogue by sending a MAP_CLOSE, and the MAP process in the VLR sends Continue Monitoring message to the CCBS application process in the VLR and returns to the idle state.

Failure of dialogue opening with the HLR

If the macro Receive_Open_Cnf takes the Vr exit or the Error exit, the MAP process sends a Event Report negative response or CCBS Call Report negative response to the CCBS application process in the VLR and returns to the idle state.

Error in MAP_STATUS_REPORT confirm

If the MAP_STATUS_REPORT service confirm contains a user error or a provider error, or the macro Check_Confirmation indicates that there is a data error, the MAP process sends an Event Report negative response or CCBS Call Report negative response to the CCBS application process in the VLR and returns to the idle state.

Abort of HLR dialogue in State Wait_For_HLR_Response

After the dialogue with the HLR has been established, the MAP service provider may abort the dialogue by issuing a MAP_P_ABORT or a MAP_U_ABORT indication. In this case, the MAP process sends a Event Report or CCBS Call Report negative response to the CCBS application process in the VLR and returns to the idle state.

If the MAP provider indicates a protocol problem by sending a MAP_NOTICE indication, the MAP process closes the dialogue with the HLR. The VLR sends an Event Report negative response or CCBS Call Report negative response indicating system failure to the CCBS application process in the VLR and returns to the idle state.

Abort of HLR dialogue in State Wait_For_Set_Reporting

After the dialogue with the HLR has been established, the MAP service provider may abort the dialogue by issuing a MAP_P_ABORT or a MAP_U_ABORT indication. In this case, the VLR returns to the idle state

If the MAP provider indicates a protocol problem by sending a MAP_NOTICE indication, the MAP process closes the dialogue with the HLR and returns to the idle state.




Figure 21.7/3 (sheet 1 of 2): Process Send_Status_Report_VLR




Figure 21.7/3 (sheet 2 of 2): Process Send_Status_Report_VLR

21.7.3 Process in the HLR for Status Reporting

The MAP process in the HLR to handle a status report is shown in figure 21.7/4. The MAP process invokes macros not defined in this subclause; the definitions of these macros can be found as follows:

- | | |
|--------------------|-----------------------|
| Receive_Open_Ind | see subclause 25.1.1; |
| Check_Confirmation | see subclause 25.2.2; |

Successful outcome

When the MAP process receives a MAP_OPEN indication with the application context reporting, it checks it by invoking the macro Receive_Open_Ind.

If the macro takes the OK exit, the MAP process waits for a service indication.

The MAP process invokes the macro Receive_Status_Report_HLR to handle a MAP_STATUS_REPORT service indication; this macro is defined in figure 21.7/5. The MAP process then waits for a response from the CCBS application in the HLR.

If the MAP process receives a Stop Reporting message from the CCBS process, it sets the required monitoring state to stop, and may send a MAP_DELIMITER service request to the VLR. The HLR then invokes the macro Set_Reported_State_HLR. After exiting the macro, the MAP process returns to the idle state.

If the MAP process receives a Continue Reporting from the CCBS process, it sends a MAP CLOSE Request to VLR and returns to the idle state.

Failure of dialogue opening with the VLR

If the macro Receive_Open_Ind takes the Vr exit or the Error exit, the MAP process returns to the idle state.

Abort of VLR dialogue in State Wait_For_Service_Indication

After the dialogue with the HLR has been established, the MAP service provider may abort the dialogue by issuing a MAP_P_ABORT indication. In this case, the MAP process returns to the idle state.

If the MAP provider indicates a protocol problem by sending a MAP_NOTICE indication, the MAP process closes the dialogue with the VLR and returns to the idle state.

Macro Receive_Status_Report_HLR

The macro Receive_Status_Report_HLR is shown in figure 21.7/5.

When a MAP_STATUS_REPORT service indication is received, the HLR checks whether call report data are present.

If call report data are present, the MAP process sends a CCBS Call Report message to the CCBS application process in the HLR and waits for a response; otherwise it sends an Event Report message to the CCBS application process in the HLR and waits for a response.

If the MAP process receives a CCBS Call Report ack or Event Report ack from the CCBS application process in the HLR, it sends a MAP_STATUS_REPORT service confirm to the VLR and exits from the macro.

If the MAP process receives a CCBS Call Report negative response or Event Report negative response from the CCBS application process in the HLR, it sets the User Error according to the negative response, sends a MAP_STATUS_REPORT service confirm to the VLR and exits from the macro.

Macro Set_Reported_State_HLR

The macro Set_Reported_State_HLR is shown in figure 21.7/6.

The MAP process in the HLR sends a MAP_SET_REPORTING_STATE service request to the VLR and waits for a response.

If the MAP process receives a MAP_SET_REPORTING_STATE service confirm from the VLR, it invokes the macro Check_Confirmation to check the content of the confirm.

If the macro Check_Confirmation takes the OK exit, the macro Set_Reportng_State_HLR takes the OK exit.

If the macro Check_Confirmation takes the Data error, Provider error or User error exit, the macro Set_Reportng_State_HLR takes the Error exit.

While the MAP process is waiting for a response from the VLR, the MAP provider may terminate the dialogue by sending a MAP_CLOSE, MAP_P_ABORT or MAP_U_ABORT. In this case the macro takes the Aborted exit.

If the MAP provider indicates a protocol problem by sending a MAP_NOTICE indication, the MAP process closes the dialogue with the VLR and the macro takes the Aborted exit.




Figure 21.7/4: Process Status Report_HLR




Figure 21.7/5: Macro Receive_Status_Report_HLR

Macrodefinition Set_Reportng_State_HLR

21.7_6(1)

Figure 21.7/6: Macro in the HLR to instruct the VLR to set the reporting state for a subscriber

Signals to/from the left are to/from the VLR




Figure 21.7/6: Macro Set_Reportng_State_HLR

21.8 Remote User Free

21.8.1 General

The message flows for handling remote user free are shown in figures 21.8/1 and 21.8/2.




Figure 21.8/1: Remote User Free: recall not accepted




Figure 21.8/2: Remote User Free: recall accepted

21.8.2 Process in the HLR for Remote User Free

The MAP process in the HLR to handle Remote User Free is shown in figure 21.8/3. The MAP process invokes macros not defined in this subclause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2;

Successful Outcome

When the MAP process receives a CCBS RUF request from the CCBS application process in the HLR, it requests a dialogue with the VLR whose identity is contained in the request by sending a MAP_OPEN service request and sending the necessary information using a MAP_REMOTE_USER_FREE service request. The HLR then invokes the macro Receive_Open_Cnf to wait for the response to the dialogue opening request. If the dialogue opening is successful, the MAP process waits for a response from the VLR.

If the MAP process receives a MAP_REMOTE_USER_FREE service confirm from the VLR, the MAP process invokes the macro Check_Confirmation to check the content of the confirm.

If the macro Check_Confirmation takes the OK exit, the MAP process sends a CCBS RUF ack containing the information received from the VLR to the CCBS application process in the HLR and waits for a MAP_STATUS_REPORT service indication from the VLR. If in this state a MAP_CLOSE service indication is received, the MAP process returns to the idle state. If in this state a MAP_STATUS_REPORT service indication is received, further processing is described by the macro Receive_Status_Report_HLR (described in subclause 21.7.3). When the macro exits, the MAP process constructs a MAP_CLOSE service request, sends it to the VLR and returns to the idle state.

Failure of dialogue opening with the VLR

If the macro Receive_Open_Cnf takes the Vr exit or the Error exit, the MAP process sends a negative response to the CCBS application process in the HLR and returns to the idle state.

Error in MAP_REMOTE_USER_FREE confirm

If the MAP_REMOTE_USER_FREE service confirm contains a user error or a provider error, or the macro Check_Confirmation indicates that there is a data error, the MAP process sends a CCBS RUF negative response to the CCBS application process in the HLR and returns to the idle state.

Abort of VLR dialogue

When the MAP process is waiting for a VLR response to the MAP_REMOTE_USER_FREE, the MAP service provider may abort the dialogue by issuing a MAP_CLOSE, a MAP_P_ABORT or a MAP_U_ABORT indication. In this case, the MAP process sends a CCBS RUF negative response to the CCBS application process in the HLR and returns to the idle state.

If the MAP provider indicates a protocol problem by sending a MAP_NOTICE indication when the MAP process is waiting for a VLR response to the MAP_REMOTE_USER_FREE, the MAP process closes the dialogue with the VLR, sends a CCBS RUF negative response indicating system failure to the CCBS application process in the HLR and returns to the idle state.

When the MAP process is waiting for a possible MAP_STATUS_REPORT from the VLR, the MAP service provider may abort the dialogue by issuing a MAP_P_ABORT or a MAP_U_ABORT indication. In this case, the MAP process returns to the idle state.

If the MAP provider indicates a protocol problem by sending a MAP_NOTICE indication when the MAP process is waiting for a possible MAP_STATUS_REPORT from the VLR, the MAP process closes the dialogue with the VLR and returns to the idle state.

If the CCBS application in the HLR decides to abort the dialogue, it sends an Abort message to the MAP process, which closes the dialogue with the VLR and returns to the idle state.




Figure 21.8/3: Process Remote_User_Free_HLR

21.8.3 Process in the VLR for Remote User Free

The MAP process in the VLR to handle Remote User Free is shown in figure 21.8/4. The MAP process invokes a macro not defined in this subclause; the definitions of this macro can be found as follows:

Check_Confirmation see subclause 25.2.2;

Successful outcome (Recall accepted)

When the MAP process receives a MAP_REMOTE_USER_FREE service indication, the VLR sends a CCBS RUF request to the CCBS application process in the VLR, and waits for a response. The request contains the parameters received in the MAP_REMOTE_USER_FREE service indication.

If the CCBS application process in the VLR returns a positive response indicating "recall accepted", the MAP process constructs a MAP_REMOTE_USER_FREE service response and a MAP_DELIMITER service request, sends them to the VLR and waits for a CCBS Call Report message from the CCBS application process in the VLR. When the MAP process receives the CCBS Call Report from the CCBS application process in the VLR, it constructs a MAP_STATUS_REPORT service request and a MAP_DELIMITER service request, sends them to the HLR and waits for a response. If the MAP process receives a MAP_STATUS_REPORT service confirm, the VLR calls the macro Check_Confirmation. If this macro takes the OK exit, the MAP process sends a CCBS Call Report ack to the CCBS application process in the VLR and the MAP process terminates.

Successful outcome (Recall not accepted)

If the CCBS application process in the VLR returns a positive response indicating "recall not accepted", the MAP process constructs a MAP_REMOTE_USER_FREE service response and a MAP_CLOSE service request, sends them to the HLR and terminates.

Negative response from VLR CCBS application process

If the CCBS application process in the VLR returns a negative response, the MAP process constructs a MAP_REMOTE_USER_FREE service response containing the appropriate error and a MAP_CLOSE service request, sends them to the HLR and terminates.

Failure of dialogue with the HLR

When waiting for a response or a call result from the CCBS application process in the VLR, the MAP process may receive a MAP_CLOSE service indication, a MAP_U_ABORT service indication or a MAP_P_ABORT service indication from the co-ordinating process, in which case the MAP process terminates.

When waiting for a call result from the CCBS application process in the VLR, the MAP process may receive a MAP_NOTICE indication from the co-ordinating process, in which case the MAP process constructs a MAP_CLOSE service request, sends it to the co-ordinating process and terminates.

When waiting for a response from the HLR, the MAP process may receive a MAP_CLOSE indication, a MAP_U_ABORT indication or a MAP_P_ABORT indication from the co-ordinating process, in which case the MAP process sends a CCBS Call Report negative response to the CCBS application process in the VLR and terminates.

When waiting for a response from the HLR, the MAP process may receive a MAP_NOTICE indication from the co-ordinating process, in which case the MAP process constructs a MAP_CLOSE service request, sends it to the co-ordinating process, sends a CCBS Call Report negative response to the CCBS application process in the VLR and terminates.

Error in MAP_STATUS_REPORT confirm

If the MAP_STATUS_REPORT service confirm contains a user error or a provider error, the MAP process sends a CCBS Call Report negative response to the CCBS application process in the VLR and terminates.




Figure 21.8/4 (sheet 1 of 2): Process Remote_User_Free_VLR




Figure 21.8/4 (sheet 2 of 2): Process Remote_User_Free_VLR

22 Supplementary services procedures

The following application contexts exist for handling of supplementary services:

- accessUnstructuredSsContext;
- accessFunctionalSsContext.

The accessUnstructuredSsContext refers to a simple MAP users, for which the corresponding MAP process can be identified by the MAP-Provider directly.

However, the accessFunctionalSsContext refers to a complex MAP-User consisting of several processes. For this user, a process co-ordinator is defined for each network entity, in order to identify the correct process to invoke. These processes open and validate the dialogue, then invoke the necessary operation-specific process. These processes are described below.

22.1 Functional supplementary service processes

22.1.1 Functional supplementary service process co-ordinator for MSC

Upon receipt of a CM-Service request with CM-service type = SS, the MSC initiates the process access request procedure towards the VLR as described in clause 25 of the present document.

Once a CM connection is established, the MSC can handle supplementary service indications from the MS. Table 22.1/1 shows the co-ordinating process' reaction on receipt of specific SS service indications on the air interface. After the relevant process is invoked, the received air interface service indication is sent to that process. The creation of service requests on the basis of air interface messages is described in GSM 09.11.

Table 22.1/1: Relationship between received service indication and invoked process in the MSC

Service indication received	Process invoked
A_REGISTER_SS_ind	REGISTER_SS_MSC
A_ERASE_SS_ind	ERASE_SS_MSC
A_ACTIVATE_SS_ind	ACTIVATE_SS_MSC
A_DEACTIVATE_SS_ind	DEACTIVATE_SS_MSC
A_INTERROGATE_SS_ind	INTERROGATE_SS_MSC
A_REGISTER_PASSWORD	REGISTER_PASSWORD_MSC

Figure 22.1/1 shows the co-ordinating process in the MSC.




Figure 22.1/1: Process SS_Coordinator_MSC

22.1.2 Functional supplementary service process co-ordinator for VLR

Any functional SS process in the VLR starts by the VLR receiving the MAP_PROCESS_ACCESS_REQUEST indication. The VLR then acts as described in clause 25 of the present document.

If the Process Access Request was successful, the VLR can handle supplementary service indications from the MSC. Table 22.1/2 shows the co-ordinating process' reaction on receipt of specific SS service indications from the MSC. After the relevant process is invoked, the received service indication is sent to that process, and the co-ordinating process terminates.

Table 22.1/2: Relationship between received service indication and invoked process in the VLR

Service indication received	Process invoked
MAP_REGISTER_SS_ind	REGISTER_SS_VLR
MAP_ERASE_SS_ind	ERASE_SS_VLR
MAP_ACTIVATE_SS_ind	ACTIVATE_SS_VLR
MAP_DEACTIVATE_SS_ind	DEACTIVATE_SS_VLR
MAP_INTERROGATE_SS_ind	INTERROGATE_SS_VLR
MAP_REGISTER_PASSWORD	REGISTER_PASSWORD_VLR

Figure 22.1/2 shows the co-ordinating process in the VLR.

Process SS_Coordinator_VLR

22.1_2.1(2)

Figure 22.1/2: Supplementary Service Coordination process in the VLR, to open and process the access request from the MSC, and then identify which functional supplementary service process shall be invoked.




Figure 22.1/2 (sheet 1 of 2): Process SS_Coordinator_VLR

Process SS_Coordinator_VLR

22.1_2.2(2)

Figure 22.1/2: Supplementary Service Coordination process in the VLR, to open and process the access request from the MSC, and then identify which functional supplementary service process shall be invoked.




Figure 22.1/2 (sheet 2 of 2): Process SS_Coordinator_VLR

22.1.3 Functional supplementary service process co-ordinator for HLR

Any functional SS process in the HLR starts by the HLR receiving a MAP-OPEN service indication. If that service is successful, the HLR can handle supplementary service indications from the VLR. Table 22.1/3 shows the co-ordinating process' reaction on receipt of specific SS service indications from the VLR. After the relevant process is invoked, the received service indication is sent to that process, and the co-ordinating process terminates.

Table 22.1/3: Relationship between received service indication and invoked process in the HLR.

Service indication received	Process invoked
MAP_REGISTER_SS_ind	REGISTER_SS_HLR
MAP_ERASE_SS_ind	ERASE_SS_HLR
MAP_ACTIVATE_SS_ind	ACTIVATE_SS_HLR
MAP_DEACTIVATE_SS_ind	DEACTIVATE_SS_HLR
MAP_INTERROGATE_SS_ind	INTERROGATE_SS_HLR
MAP_REGISTER_PASSWORD	REGISTER_PASSWORD_HLR

Figure 22.1/3 shows the co-ordinating process in the HLR.

Process SS_Coordinator_HLR

22.1_3.1(2)

Figure 22.1/3: Supplementary Service Coordination process in the HLR, to identify which functional supplementary service process shall be invoked.




Figure 22.1/3 (sheet 1 of 2): Process SS_Coordinator_HLR

Process SS_Coordinator_HLR

22.1_3.2(2)

Figure 22.1/3: Supplementary Service Coordination process in the HLR, to identify which functional supplementary service process shall be invoked.




Figure 22.1/3 (sheet 2 of 2): Process SS_Coordinator_HLR

22.1.4 Call completion supplementary service process co-ordinator for HLR

The MAP co-ordinating process in the HLR to handle a dialogue opened with the callCompletion application context is shown in figure 22.1/4. The MAP process invokes a macro not defined in this subclause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1.

Any call completion SS process in the HLR starts by the HLR receiving a MAP-OPEN service indication. If that service is successful, the HLR can handle call completion supplementary service indications from the VLR.

Table 22.1/4 shows the co-ordinating process' reaction on receipt of specific call completion SS service indications from the VLR. After the relevant process is invoked, the received service indication is sent to that process.

Table 22.1/4: Relationship between received service indication and invoked process in the HLR.

Service indication received	Process invoked
MAP_REGISTER_CC_ENTRY_ind	REGISTER_CC_ENTRY_HLR
MAP_ERASE_CC_ENTRY_ind	ERASE_CC_ENTRY_HLR

After creation of the user process the Co-ordinator relays the messages between the MAP_PM and the invoked process until a request or an indication for dialogue termination is received.

The Call_Completion Co-ordinator is shown in figure 22.1/4.




Figure 22.1/4: Process_CC_Coord_HLR

22.2 Registration procedure


22.2.1 General

The registration procedure is used to register data related to a supplementary service in the HLR. The registration procedure is a fully transparent communication between the MS and the HLR, except that some services may be invoked as a result of the procedure, as described in the subclauses below.

The registration procedure is shown in figure 22.2.1/1.

The following services may be used:

MAP_PROCESS_ACCESS_REQUEST	(defined in clauses 8 and 25);
MAP_TRACE_SUBSCRIBER_ACTIVITY	(defined in clauses 9 and 25);
MAP_PROVIDE_IMSI	(defined in clauses 8 and 25);
MAP_FORWARD_NEW_TMSI	(defined in clauses 8 and 25);
MAP_AUTHENTICATE	(defined in clauses 8 and 25);
MAP_SET_CIPHERING_MODE	(defined in clauses 8 and 25);
MAP_CHECK_IMEI	(defined in clauses 8 and 25);
MAP_READY_FOR_SM	(defined in clauses 12 and 25);
MAP_INSERT_SUBSCRIBER_DATA	(defined in clauses 8 and 25);
MAP_REGISTER_SS	(defined in clause 11).



NOTE 1: For details of the procedure on the radio path, see GSM 04.08, 04.10, 04.8x and 04.9x. Services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.

NOTE 2: For details on the Process Access Request procedure, please refer to clause 25 in the present document.
NOTE 3: Services printed in *italics* are optional.

Figure 22.2.1/1: Interfaces and services for supplementary service registration

22.2.2 Procedures in the MSC

Supplementary service registration

The A_REGISTER_SS service indication received by the MAP user in the MSC contains the SS-Code and any parameters that are related to the supplementary service.

The MAP user transfers the received information to the VLR in the MAP_REGISTER_SS request without checking the contents of the service indication. Rules for the mapping are described in GSM 09.11.

The MSC then awaits the receipt of the MAP_REGISTER_SS confirm from the VLR. The outcome of the procedure is reported to the MS in the A_REGISTER_SS response message as described in GSM 04.8x, 04.9x and 09.11. Finally the SS-connection is released.

For call independent SS operations, each message shall only contain a single component. Messages which contain more than one component will be stopped at the air interface (as specified in GSM 09.11).

Error handling

If at any time during the supplementary service part of this procedure a MAP_P_ABORT, MAP_U_ABORT, MAP_NOTICE or unexpected MAP_CLOSE indication is received from the VLR concerning the process, a CM_RELEASE_COMPLETE indication is sent to the MS (as specified in GSM 09.11). Upon receipt of a MAP_NOTICE indication from the VLR, the MSC must close the VLR dialogue by sending a MAP_CLOSE request. The process is then terminated.

If an A_CM_RELEASE indication is received from the MS, all open transactions shall be released using the MAP_U_ABORT request indicating application procedure cancellation, and the process is terminated.

The registration procedure in the MSC is shown in figure 22.2.2/1.

Process SS_REGISTER_MSC

22.2.2_1(1)

Figure 22.2.2/1 :Mobile initiated registration of supplementary service in the MSC




Figure 22.2.2/1: Procedure SS_Register_MSC

22.2.3 Procedures in the VLR

Supplementary service registration

When receiving the MAP_REGISTER_SS indication, the MAP user in the VLR transfers the information to the HLR in the MAP_REGISTER_SS request without checking the contents of the service indication.

The VLR then awaits the receipt of the MAP_REGISTER_SS confirm from the HLR. The MAP user in the VLR shall transfer the information contained in this primitive to the MSC in the MAP_REGISTER_SS response without checking its contents.

For call independent SS operations, each message shall only contain a single component. Messages which contain more than one component will be stopped at the air interface (as specified in GSM 09.11).

Error handling

If at any time during this procedure a MAP_P_ABORT, MAP_U_ABORT, MAP_NOTICE or unexpected MAP_CLOSE indication is received from the MSC concerning the process, a MAP_U_ABORT request indicating application procedure cancellation is sent to the HLR (if a connection exists). If a MAP_NOTICE indication was received from the MSC, that dialogue must be closed by sending a MAP_CLOSE request towards the MSC. The process is terminated.

If a MAP_P_ABORT, MAP_U_ABORT or MAP_CLOSE indication is received from the HLR, a MAP_U_ABORT request shall be sent to the MSC terminating the process. If a MAP_NOTICE indication was received from the HLR, that dialogue must be closed by sending a MAP_CLOSE request towards the HLR. The process terminates.

The registration procedure in the VLR is shown in figure 22.2.3/1.

Process SS_REGISTER_VLR

22.2.3_1.1(2)

Figure 22.2.3/1: Mobile initiated registration of supplementary services in the VLR




Figure 22.2.3/1 (sheet 1 of 2): Procedure SS_Register_VLR




Figure 22.2.3/1 (sheet 2 of 2): Procedure SS_Register_VLR

22.2.4 Procedures in the HLR

The procedure in the HLR is initiated when it receives a MAP_REGISTER_SS indication.

The HLR acts as follows:

- if the operator has barred the subscriber from access to supplementary services, the Call Barred error should be returned to the VLR. The parameter "operatorBarring" shall be included with the error.

The supplementary service request shall then be processed according to GSM 03.11 and the 03.8x and 03.9x-series of technical specifications. This handling may lead to either a successful result, a partially successful result, or an error being returned.

For call independent SS operations, each message shall only contain a single component. Messages which contain more than one component will be stopped at the air interface (as specified in GSM 09.11):

- if the VLR is to be updated after the supplementary service registration, the MAP_INSERT_SUBS_DATA_HLR process shall be initiated;
- if at any time during this procedure a MAP_P_ABORT, MAP_U_ABORT or MAP_CLOSE indication concerning the process is received from the VLR, the process is terminated. If a MAP_NOTICE indication is received, a MAP_CLOSE request indicating sent towards the VLR.

The registration procedure in the HLR is shown in figure 22.2.4/1.

Process SS_REGISTER_HLR

22.2.4_1.1(2)

Figure 22.2.4/1: Registration of supplementary services procedure in HLR




Figure 22.2.4/1 (sheet 1 of 2): Procedure SS_Register_HLR

Process SS_REGISTER_HLR

22.2.4_1.2(2)

Figure 22.2.4/1: Registration of supplementary services procedure in HLR




Figure 22.2.4/1 (sheet 2 of 2): Procedure SS_Register_HLR

22.3 Erasure procedure


22.3.1 General

The erasure procedure is used to erase data related to a supplementary service in the HLR. The erasure procedure is a fully transparent communication between the MS and the HLR, except that some services may be invoked as a result of the procedure, as described in the subclauses below.

The erasure procedure is shown in figure 22.3.1/1.

The following services may be used:

MAP_PROCESS_ACCESS_REQUEST	(defined in subclauses 8 and 25);
MAP_TRACE_SUBSCRIBER_ACTIVITY	(defined in clauses 9 and 25);
MAP_PROVIDE_IMSI	(defined in clauses 8 and 25);
MAP_FORWARD_NEW_TMSI	(defined in clauses 8 and 25);
MAP_AUTHENTICATE	(defined in clauses 8 and 25);
MAP_SET_CIPHERING_MODE	(defined in clauses 8 and 25);
MAP_CHECK_IMEI	(defined in clauses 8 and 25);
MAP_READY_FOR_SM	(defined in clauses 12 and 25);
MAP_INSERT_SUBSCRIBER_DATA	(defined in clauses 8 and 25);
MAP_ERASE_SS	(defined in clause 11).



NOTE 1: For details of the procedure on the radio path, see GSM 04.08, 04.10, 04.8x and 04.9x. Services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.

NOTE 2: For details on the Process Access Request procedure, please refer to clause 25 in the present document.
 NOTE 3: Services printed in *italics* are optional.

Figure 22.3.1/1: Interfaces and services for supplementary service erasure

22.3.2 Procedures in the MSC

The MSC procedures for erasure are identical to those specified for registration in subclause 22.2.2. The text and diagrams in subclause 22.2.2 apply with all references to registration changed to erasure.

22.3.3 Procedures in the VLR

The VLR procedures for erasure are identical to those specified for registration in subclause 22.2.3. The text and diagrams in subclause 22.2.3 apply with all references to registration changed to erasure.

22.3.4 Procedures in the HLR

The HLR procedure for erasure is identical to those specified for registration in subclause 22.2.4. The text and diagrams in subclause 22.2.4 apply with all references to registration changed to erasure.

22.4 Activation procedure


22.4.1 General

The activation procedure is used to activate a supplementary service in the HLR. The activation procedure is a fully transparent communication between the MS and the HLR, except that some services may be invoked as a result of the procedure, as described in the subclauses below.

The activation procedure is shown in figure 22.4.1/1.

The following services may be used:

MAP_PROCESS_ACCESS_REQUEST	(defined in clauses 8 and 25);
MAP_TRACE_SUBSCRIBER_ACTIVITY	(defined in clauses 9 and 25);
MAP_PROVIDE_IMSI	(defined in clauses 8 and 25);
MAP_FORWARD_NEW_TMSI	(defined in clauses 8 and 25);
MAP_AUTHENTICATE	(defined in clauses 8 and 25);
MAP_SET_CIPHERING_MODE	(defined in clauses 8 and 25);
MAP_CHECK_IMEI	(defined in clauses 8 and 25);
MAP_READY_FOR_SM	(defined in clauses 12 and 25);
MAP_GET_PASSWORD	(defined in clause 11);
MAP_INSERT_SUBSCRIBER_DATA	(defined in clauses 8 and 25);
MAP_ACTIVATE_SS	(defined in clause 11).



NOTE 1: For details of the procedure on the radio path, see GSM 04.08, 04.10, 04.8x and 04.9x. Services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.

NOTE 2: For details on the Process Access Request procedure, please refer to clause 25 of this document.

NOTE 3: Services printed in italics are optional.

Figure 22.4.1/1: Interfaces and services for supplementary service activation

22.4.2 Procedures in the MSC

The A_ACTIVATE_SS service indication received by the MAP user in the MSC contains the SS-Code and any parameters related to the supplementary service.

The MSC transfers the received information to the VLR in the MAP_ACTIVATE_SS request without checking the contents of the service indication. Rules for the mapping are described in GSM 09.11.

The MAP user may subsequently receive the MAP_GET_PASSWORD indication from the VLR. Upon receipt of this indication, the MSC sends the A_GET_PASSWORD message towards the MS and then awaits the response from the MS. When an A_GET_PASSWORD confirm message is received from the MS, the MSC initiates the MAP_GET_PASSWORD response towards the VLR without checking further the contents of the indication. Also see GSM 09.11.

The MSC will receive a MAP_ACTIVATE_SS confirm from the VLR. The outcome of the procedure is reported to the MS in the A_ACTIVATE_SS response message, see GSM 04.8x, 04.9x and 09.11. Finally the SS connection is released.

For call independent SS operations, each message shall only contain a single component. Messages which contain more than one component will be stopped at the air interface (as specified in GSM 09.11).

The handling of MAP_P_ABORT, MAP_U_ABORT, MAP_NOTICE and unexpected MAP_CLOSE or A_CM_RELEASE in this procedure is identical to the handling in the Registration procedure in the MSC, see subclause 22.2.2 of the present document.

The activation procedure in the MSC is shown in figure 22.4.2/1.

Process ACTIVATE_SS_MSC

22.4.2_1(1)

Figure 22.4.2/1: Mobile initiated activation of supplementary service in the MSC




Figure 22.4.2/1: Procedure Activate_SS_MSC

22.4.3 Procedures in the VLR

Supplementary service activation

When receiving the MAP_ACTIVATE_SS indication, the MAP user in the VLR transfers the information to the HLR in the MAP_ACTIVATE_SS request without checking the contents of the service indication.

The VLR may then receive the MAP_GET_PASSWORD indication. This information is transferred to the MSC in the MAP_GET_PASSWORD request. If a MAP_GET_PASSWORD confirm primitive is received from the MSC, the VLR initiates the MAP_GET_PASSWORD response towards the HLR.

The VLR will receive the MAP_ACTIVATE_SS confirm from the HLR. The MAP user in the VLR shall transfer the information contained in this primitive to the MSC in the MAP_ACTIVATE_SS response without checking its contents.

For call independent SS operations, each message shall only contain a single component. Messages which contain more than one component will be stopped at the air interface (as specified in GSM 09.11).

Error handling

The handling of MAP_P_ABORT, MAP_U_ABORT, MAP_NOTICE and unexpected MAP_CLOSE in this procedure is identical to the handling in the Registration procedure in the VLR, see subclause 22.2.3 of the present document.

The activation procedure in the VLR is shown in figure 22.4.3/1.

Process ACTIVATE_SS_VLR

22.4.3_1.1(2)

Figure 22.4.3/1: Activation of supplementary service procedure in the VLR




Figure 22.4.3/1 (sheet 1 of 2): Procedure Activate_SS_VLR

Process ACTIVATE_SS_VLR

22.4.3_1.2(2)

Figure 22.4.3/1: Activation of supplementary service procedure in the VLR




Figure 22.4.3/1 (sheet 2 of 2): Procedure SS_Activate_VLR

22.4.4 Procedures in the HLR

The procedure in the HLR is initiated when it receives a MAP_ACTIVATE_SS indication.

The HLR acts as follows:

- if the operator has barred the subscriber from access to supplementary services, the Call Barred error should be returned to the VLR. The parameter "operatorBarring" shall be included with the error.

The supplementary service request shall then be processed according to GSM 03.11 and the 03.8x and 03.9x-series of technical specifications. This handling may lead to either a successful result, a partially successful result, or an error being returned.

During the handling of activation, the get password procedure may be initiated (as specified in GSM 03.11). This will involve the sending of a MAP_GET_PASSWORD request to the VLR.

For call independent SS operations, each message shall only contain a single component. Messages which contain more than one component will be stopped at the air interface (as specified in GSM 09.11):

- if the VLR is to be updated after the supplementary service activation, the MAP_INSERT_SUBS_DATA_HLR process is initiated;
- handling of receipt of MAP_P_ABORT, MAP_U_ABORT or MAP_CLOSE indications from the VLR is identical to their handling in the registration procedure, see subclause 22.2.4 above.

The activation procedure in the HLR is shown in figure 22.4.4/1.

Process ACTIVATE_SS_HLR

22.4.4_1.1(2)

Figure 22.4.4/1: Activation of supplementary services procedure in HLR.




Figure 22.4.4/1 (sheet 1 of 2): Procedure Activate_SS_HLR

Process ACTIVATE_SS_HLR

22.4.4_1.2(2)

Figure 22.4.4/1: Activation of supplementary services procedure in HLR.




Figure 22.4.4/1 (sheet 2 of 2): Procedure Activate_SS_HLR

22.5 Deactivation procedure


22.5.1 General

The deactivation procedure is used to deactivate a supplementary service in the HLR. The deactivation procedure is a fully transparent communication between the MS and the HLR, except that some services may be invoked as a result of the procedure, as described in the subclauses below.

The deactivation procedure is shown in figure 22.5.1/1.

The following services may be used:

MAP_PROCESS_ACCESS_REQUEST	(defined in clauses 8 and 25);
MAP_TRACE_SUBSCRIBER_ACTIVITY	(defined in clauses 9 and 25);
MAP_PROVIDE_IMSI	(defined in clauses 8 and 25);
MAP_FORWARD_NEW_TMSI	(defined in clauses 8 and 25);
MAP_AUTHENTICATE	(defined in clauses 8 and 25);
MAP_SET_CIPHERING_MODE	(defined in clauses 8 and 25);
MAP_CHECK_IMEI	(defined in clauses 8 and 25);
MAP_READY_FOR_SM	(defined in clauses 12 and 25);
MAP_GET_PASSWORD	(defined in clause 11);
MAP_INSERT_SUBSCRIBER_DATA	(defined in clauses 8 and 25);
MAP_DEACTIVATE_SS	(defined in clause 11).



NOTE 1: For details of the procedure on the radio path, see GSM 04.08, 04.10, 04.8x and 04.9x. Services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.

NOTE 2: For details on the Process Access Request procedure, please refer to clause 25 in the present document.
NOTE 3: Services printed in *italics* are optional.

Figure 22.5.1/1: Interfaces and services for supplementary service deactivation

22.5.2 Procedures in the MSC

The MSC procedures for deactivation are identical to those specified for activation in subclause 22.4.2. The text and diagrams in subclause 22.4.2 apply with all references to activation changed to deactivation.

22.5.3 Procedures in the VLR

The VLR procedures for deactivation are identical to those specified for activation in subclause 22.4.3. The text and diagrams in subclause 22.4.3 apply with all references to activation changed to deactivation.

22.5.4 Procedures in the HLR

The HLR procedures for deactivation are identical to those specified for activation in subclause 22.4.4. The text and diagrams in subclause 22.4.4 apply with all references to activation changed to deactivation.

22.6 Interrogation procedure


22.6.1 General

The interrogation procedure is used to retrieve information related to a supplementary service from the VLR or the HLR. It is the VLR which decides whether an interrogation request should be forwarded to the HLR or not. Some non-supplementary service related services may be invoked as a result of the procedure, as described in the subclauses below.

The interrogation procedure is shown in figure 22.6.1/1.

The following services may be used:

MAP_PROCESS_ACCESS_REQUEST	(defined in clauses 8 and 25);
MAP_TRACE_SUBSCRIBER_ACTIVITY	(defined in clauses 9 and 25);
MAP_PROVIDE_IMSI	(defined in clauses 8 and 25);
MAP_FORWARD_NEW_TMSI	(defined in clauses 8 and 25);
MAP_AUTHENTICATE	(defined in clauses 8 and 25);
MAP_SET_CIPHERING_MODE	(defined in clauses 8 and 25);
MAP_CHECK_IMEI	(defined in clauses 8 and 25);
MAP_READY_FOR_SM	(defined in clauses 12 and 25);
MAP_INTERROGATE_SS	(defined in clause 11).



NOTE 1: For details of the procedure on the radio path, see GSM 04.08, 04.10, 04.8x and 04.9x. Services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.

NOTE 2: For details on the Process Access Request procedure, please refer to clause 25 in the present document.

NOTE 3: Services printed in italics are optional.

Figure 22.6.1/1: Interfaces and services for supplementary service interrogation

22.6.2 Procedures in the MSC

The MSC procedures for interrogation are identical to those specified for registration in subclause 22.2.2. The text and diagrams in subclause 22.2.2 apply with all references to registration changed to interrogation.

22.6.3 Procedures in the VLR

Supplementary service interrogation

When receiving the MAP_INTERROGATE_SS indication, the MAP user acts as follows:

- if the operator has barred the subscriber from access to supplementary services, the error Call Barred is returned to the MSC. The parameter "operatorBarring" shall be included with the error.

The interrogation is either answered by the VLR or by the HLR, depending on the service interrogated.

a) Interrogation to be handled by the VLR

The supplementary service request shall then be processed according to GSM 03.11 and the 03.8x and 03.9x-series of technical specifications. This handling may lead to either a successful result, a partially successful result, or an error being returned.

For call independent SS operations, each message shall only contain a single component. Messages which contain more than one component will be stopped at the air interface (as specified in GSM 09.11).

b) Interrogation to be handled by HLR

If the interrogation is to be handled by the HLR, on receiving the MAP_INTERROGATE_SS indication, the MAP user in the VLR transfers the information to the HLR in the MAP_INTERROGATE_SS request without further checking the contents of the service indication.

The VLR will receive the MAP_INTERROGATE_SS confirm from the HLR. The MAP user in the VLR shall transfer the information contained in this primitive to the MSC in the MAP_INTERROGATE_SS response without checking its contents.

For call independent SS operations, each message shall only contain a single component. Messages which contain more than one component will be stopped at the air interface (as specified in GSM 09.11).

Error handling

Handling of MAP_P_ABORT, MAP_U_ABORT, MAP_NOTICE and unexpected MAP_CLOSE in this procedure is identical to the handling in the Registration procedure in the VLR, subclause 22.2.3. The Interrogation procedure is described in figure 22.6.3/1.




Figure 22.6.3/1 (sheet 1 of 3): Procedure Interrogate_SS_VLR

Process INTERROGATE_SS_VLR

22.6.3_1.2(3)

Figure 22.6.3/1: Interrogation of supplementary service procedure in VLR




Figure 22.6.3/1 (sheet 2 of 3): Procedure Interrogate_SS_VLR

Process INTERROGATE_SS_VLR

22.6.3_1.3(3)

Figure 22.6.3/1: Interrogation of supplementary service procedure in VLR




Figure 22.6.3/1 (sheet 3 of 3): Procedure Interrogate_SS_VLR

22.6.4 Procedures in the HLR

When receiving the MAP_INTERROGATE_SS indication, the MAP user acts as follows:

- if the operator has barred the subscriber from access to supplementary services, the error Call Barred is returned to the MSC. The parameter "operatorBarring" shall be included with the error;
- if the supplementary service is not supported in HLR the error Unexpected Data Value is returned to the VLR.

The interrogation is either answered by the VLR or by the HLR, depending on the service interrogated.

a) Interrogation to be handled by the VLR

If the interrogation procedure should have been answered by the VLR, then the HLR assumes that the VLR does not support the interrogated supplementary service, and returns the SS Not Available error to the VLR.

b) Interrogation to be handled by HLR

The supplementary service request shall be processed according to GSM 03.11 and the 03.8x and 03.9x-series of technical specifications. This handling may lead to either a successful result or an error being returned.

For call independent SS operations, each message shall only contain a single component.

Error handling

Handling of MAP_P_ABORT, MAP_U_ABORT, MAP_NOTICE and unexpected MAP_CLOSE in this procedure is identical to the handling in the Registration procedure in the VLR, subclause 22.2.3. The Interrogation procedure is described in figure 22.6.4/1.

Process INTERROGATE_SS_HLR

22.6.4_1(1)

Figure 22.6.4/1: Interrogation of supplementary services procedure in HLR




Figure 22.6.4/1: Procedure Interrogate_SS_HLR

22.7 Invocation procedure


22.7.1 General

The invocation procedure is used to check subscription data in the VLR for certain supplementary services which are invoked after the call set-up phase is finished. For invocation of supplementary services which are invoked during the call set-up phase, please refer to the Call Handling procedure descriptions.

The invocation procedure is shown in figure 22.7.1/1. Note that some optional services may be invoked in connection with this procedure, as described in the subclause below.

The following services are used:

MAP_PROCESS_ACCESS_REQUEST	(defined in clauses 8 and 25);
MAP_TRACE_SUBSCRIBER_ACTIVITY	(defined in clauses 9 and 25);
MAP_PROVIDE_IMSI	(defined in clauses 8 and 25);
MAP_FORWARD_NEW_TMSI	(defined in clauses 8 and 25);
MAP_AUTHENTICATE	(defined in clauses 8 and 25);
MAP_SET_CIPHERING_MODE	(defined in clauses 8 and 25);
MAP_CHECK_IMEI	(defined in clauses 8 and 25);
MAP_READY_FOR_SM	(defined in clauses 12 and 25);
MAP_INVOKE_SS	(defined in clause 11).



NOTE 1: For details of the procedure on the radio path, see GSM 04.08, 04.10, 04.8x and 04.9x. Services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.

NOTE 2: For details on the Process Access Request procedure, please refer to clause 25 in the present document.

NOTE 3: A_INVOKE_SS is a generic message to illustrate any supplementary service invocation request message on the air interface, e.g. BuildMPTY, see GSM 04.80.

Figure 22.7.1/1: Interfaces and services for supplementary service invocation

22.7.2 Procedures in the MSC

Process access request

Before the Call Hold or Multi-Party supplementary services can be invoked, a CC connection must be established between the MS and the MSC as described in GSM 04.08 and the Call Handling procedure descriptions within the present document.

When an A_INVOKE_SS request message arrives at the MSC during a call (as described in GSM 04.10, 04.8x and 04.9x-series of technical specifications), then if control of subscription to the invoked supplementary service is required, the MSC initiates the process access request procedure towards the VLR as described in clause 25 of the present document.

Supplementary service invocation

If the Process Access Request procedure towards the VLR is successful, the MSC shall forward a MAP_INVOKE_SS service request towards the VLR. This request shall contain the SS-Code of the supplementary service to be invoked, and possibly the Basic service code. Mapping from the A_INVOKE_SS to this service request is described in GSM 09.11.

The MSC will receive a MAP_INVOKE_SS confirm from the VLR. If the outcome of the service is successful (i.e. the service confirm is empty), the MSC will invoke the requested supplementary service as described in GSM 02.8x-series, 03.8x and 03.9x-series of technical specifications. If the outcome of the service is unsuccessful, the MSC shall send an appropriate A_INVOKE_SS response towards the MS. The structure of this message is described in GSM 09.11 and 04.8x and 04.9x-series of technical specifications.

Error handling

If at any time during this procedure a MAP_P_ABORT, MAP_U_ABORT, MAP_NOTICE or MAP_CLOSE indication concerning the process is received from the VLR, the process is terminated. If a MAP_NOTICE indication was received from the VLR, the VLR dialogue must also be aborted by sending a MAP_U_ABORT request indicating Procedure error towards the VLR. Possible signalling to the MS is described in GSM 04.10.


If an A_CM_RELEASE indication is received from the MS, all open transactions are released using the MAP_U_ABORT request indicating application procedure cancellation; the process terminates.

The invocation procedure in the MSC is shown in figure 22.7.2/1.

Process INVOKE_SS_MSC

22.7.2_1.1(2)

Figure 22.7.2/1: Mobile initiated invocation of supplementary service procedure in the MSC




Note 1: Fictitious signal to indicate receipt/sending of SS invocation invoke component on the air interface (eg. BuildMPTY).
 Described in GSM 04.8X and 09.11.

Figure 22.7.2/1 (sheet 1 of 2): Procedure INVOKE_SS_MSC

Process INVOKE_SS_MSC

22.7.2_1.2(2)

Figure 22.7.2/1: Mobile initiated invocation of supplementary service procedure in the MSC



Note 1: Fictitious signal to indicate receipt/ sending of SS invocation invoke component on the air interface, (eg. BuildMPTY).
Described in GSM 04.8X and 09.11.

Figure 22.7.2/1 (sheet 2 of 2): Procedure INVOKE_SS_MSC

22.7.3 Procedures in the VLR

Process Access Request

When receiving the MAP_PROCESS_ACCESS_REQUEST indication, the VLR acts as described in clause 25 of the present document.

Supplementary service invocation

When receiving the MAP_INVOKE_SS indication, the MAP user acts as follows:

- if the operator has barred the subscriber from access to supplementary services, the error "Call Barred" is returned to the MSC. The parameter "operatorBarring" shall be included with the error;
- if any irrelevant information elements (according to the service description) or invalid information element values are present in the service request, then the unexpected data value error is returned to the MSC in the MAP_INVOKE_SS response;
- if the VLR does not support the invoked supplementary service then the VLR shall respond with the SS Not Available error;
- if the requested supplementary service cannot be invoked by subscriber actions, then the VLR shall respond with the Illegal SS Operation error;
- if the subscriber is not provided with (i.e. subscribed to) the requested supplementary service, then the SS error status error (possibly including the SS-Status as parameter) is returned to the MSC in the MAP_INVOKE_SS response.

If all checks are passed the VLR returns an empty MAP_INVOKE_SS response to the MSC, thus indicating that the invocation request was accepted.

If at any time during this procedure a MAP_P_ABORT, MAP_U_ABORT, MAP_NOTICE or unexpected MAP_CLOSE indication concerning the process is received from the MSC, the process terminates. If a MAP_NOTICE indication was received from the MSC, that dialogue must be aborted by sending a MAP_U_ABORT request indicating Procedure error towards the MSC. The process terminates.

The invocation procedure in the VLR is shown in figure 22.7.3/1.




Figure 22.7.3/1: Procedure Invoke_SS_VLR

22.8 Password registration procedure


22.8.1 General

The password registration procedure is used to register a password in the HLR. The password registration procedure is a fully transparent communication between the MS and the HLR, except that some services may be invoked as a result of the procedure, as described below.

The password registration procedure is shown in figure 22.8.1/1.

The following services may be used:

MAP_PROCESS_ACCESS_REQUEST	(defined in clauses 8 and 25);
MAP_TRACE_SUBSCRIBER_ACTIVITY	(defined in clauses 9 and 25);
MAP_PROVIDE_IMSI	(defined in clauses 8 and 25);
MAP_FORWARD_NEW_TMSI	(defined in clauses 8 and 25);
MAP_AUTHENTICATE	(defined in clauses 8 and 25);
MAP_SET_CIPHERING_MODE	(defined in clauses 8 and 25);
MAP_CHECK_IMEI	(defined in clauses 8 and 25);
MAP_READY_FOR_SM	(defined in clauses 12 and 25);
MAP_GET_PASSWORD	(defined in clause 11).



NOTE 1: For details of the procedure on the radio path, see GSM 04.08, 04.10, 04.8x and 04.9x. Services shown in dotted lines are triggers/ triggered signalling on the radio path.

NOTE 2: For details on the Process Access Request procedure, please refer to clause 25 in the present document.

NOTE 3: Use of each of the three MAP_GET_PASSWORD operations is described in subclause 22.8.4.

Figure 22.8.1/1: Interfaces and services for supplementary service password registration

22.8.2 Procedures in the MSC

The password registration procedure in the MSC is identical to that for activation specified in subclause 22.4.2. All the text and diagrams in subclause 22.4.2 apply with all references to activation changed to password registration.

22.8.3 Procedures in the VLR

The password registration procedure in the VLR is identical to that for activation specified in subclause 22.4.3. All the text and diagrams in subclause 22.4.3 apply with all references to activation changed to password registration.

22.8.4 Procedures in the HLR

The procedure in the HLR is initiated when it receives a MAP_REGISTER_PASSWORD indication.

The HLR acts as follows:

- if the operator has barred the subscriber for access to supplementary services, the Call Barred error is returned to the VLR. The parameter "operatorBarring" shall be included with the error;
- if any irrelevant information elements (according to the service description) or invalid information element values are present, then the unexpected data value error is returned to the VLR in the response. This error should thus be returned if the SS-Code provided by the mobile subscriber is not allocated.

The HLR shall then process the MAP_REGISTER_PASSWORD indication as specified in GSM 03.11. During the handling of password registration, the password procedure will be initiated (as specified in GSM 03.11) This will involve the sending of MAP_GET_PASSWORD requests to the VLR.

- Handling of receipt of MAP_P_ABORT, MAP_U_ABORT or MAP_CLOSE indications from the VLR is identical to their handling in the registration procedure, see subclause 22.2.4 above.

The password registration procedure in the HLR is shown in figure 22.8.4/1.

Process REGISTER_PASSWORD_HLR

22.8.4_1.1(2)

Figure 22.8.4/1: Registration of supplementary service password procedure in HLR




Figure 22.8.4/1 (sheet 1 of 2): Procedure Register_PW_HLR

Process REGISTER_PASSWORD_HLR

22.8.4_1.2(2)

Figure 22.8.4/1: Registration of supplementary service password procedure in HLR




Figure 22.8.4/1 (sheet 2 of 2): Procedure Register_PW_HLR

22.9 Mobile Initiated USSD procedure

22.9.1 General

The procedure supports supplementary service signalling procedures which can allow PLMN specific services to be introduced.

The message flow for the procedure can be found in GSM 03.90.

The following services may be used:

MAP_PROCESS_ACCESS_REQUEST	(defined in clauses 8 and 25);
MAP_TRACE_SUBSCRIBER_ACTIVITY	(defined in clauses 9 and 25);
MAP_PROVIDE_IMSI	(defined in clauses 8 and 25);
MAP_FORWARD_NEW_TMSI	(defined in clauses 8 and 25);
MAP_AUTHENTICATE	(defined in clauses 8 and 25);
MAP_SET_CIPHERING_MODE	(defined in clauses 8 and 25);
MAP_CHECK_IMEI	(defined in clauses 8 and 25);
MAP_READY_FOR_SM	(defined in clauses 12 and 25);
MAP_UNSTRUCTURED_SS_REQUEST	(defined in clause 11);
MAP_UNSTRUCTURED_SS_NOTIFY	(defined in clause 11).

The following service is certainly used:

MAP_PROCESS_UNSTRUCTURED_SS_REQUEST	(defined in clause 11).
-------------------------------------	-------------------------

22.9.2 Procedures in the MSC

Before the Process Unstructured SS Request service can be invoked, a call independent CM connection must be created between the MS and the MSC.

Once a CM-connection is established, the MSC may handle the A_PROCESS_UNSTRUCTURED_SS_REQUEST from the MS. This message contains information input by the user, the message may be fed to an application contained locally in the MSC or to the VLR. The rules for determining this are specified in GSM 03.90.

1) Message Destined for VLR

If the message is destined for the VLR then the MSC shall transfer the message to the VLR using the mapping specified in detail in GSM 09.11.

The MSC may subsequently receive one or more MAP_UNSTRUCTURED_SS_REQUEST or MAP_UNSTRUCTURED_SS_NOTIFY indications from the VLR. These shall be sent transparently to the MS. When a confirmation is received from the MS this shall be returned to the VLR.

When the MSC receives a MAP_PROCESS_UNSTRUCTURED_SS_REQUEST confirmation from the VLR then it shall pass this to the MS and initiate release of the CM connection.

2) Message Destined for Local Application

If the message is destined for the local USSD application then the MSC shall transfer the message to the application.

The MSC may subsequently receive one or more requests from the application which correspond to the MAP_UNSTRUCTURED_SS_REQUEST or MAP_UNSTRUCTURED_SS_NOTIFY indications. These shall be sent transparently to the MS. When a confirmation is received from the MS this shall be returned to the application.

When the MSC receives the result of the original operation from the application then it shall pass this to the MS and initiate release of the CM connection.

Error Handling

Both the MS and the VLR or USSD Application may initiate release of the CM-connection at any time. This is handled as shown in the diagrams.

The procedure in the MSC is shown in figure 22.9.2/1.




Figure 22.9.2/1 (sheet 1 of 2): Procedure MI_USSD_MSC




Figure 22.9.2/1 (sheet 2 of 2): Procedure MI_USSD_MSC

22.9.3 Procedures in the VLR

The initiation of the process is shown in subclause 22.1.2.

Once a MAP dialogue is established, the VLR may handle the MAP_PROCESS_UNSTRUCTURED_SS_REQUEST from the MSC. This message contains information input by the user, the message may be fed to an application contained locally in the VLR or to the HLR. The rules for determining this are specified in GSM 03.90.

Message Destined for HLR

If the message is destined for the HLR then the VLR shall transfer the message transparently to the HLR.

The VLR may subsequently receive one or more MAP_UNSTRUCTURED_SS_REQUEST or MAP_UNSTRUCTURED_SS_NOTIFY indications from the HLR. These shall be sent transparently to the MSC. When a confirmation is received from the MSC this shall be returned to the HLR.

When the VLR receives a MAP_PROCESS_UNSTRUCTURED_SS_REQUEST confirmation from the HLR then it shall pass this to the MS and close the MAP provider service.

Message Destined for Local Application

If the message is destined for the local USSD application then the VLR shall transfer the message to the application.

The VLR may subsequently receive one or more requests from the application which correspond to the MAP_UNSTRUCTURED_SS_REQUEST or MAP_UNSTRUCTURED_SS_NOTIFY indications. These shall be sent transparently to the MSC. When a confirmation is received from the MSC this shall be returned to the application.

When the VLR receives the result of the original operation from the application then it shall pass this to the MSC and initiate release of the CM connection.

Error Handling

Both the MSC and the HLR or USSD Application may initiate release of the MAP service at any time. This is handled as shown in the diagrams.

The procedure in the VLR is shown in figures 22.9.3/1 and 22.9.3/2.




Figure 22.9.3/1 (sheet 1 of 3): Procedure MI_USSD_VLR

Process MS_INIT_USSD_VLR

22.9.3_1.2(3)

Figure 22.9.3/1: Handling for mobile initiated USSD at VLR

Arrows to left are to MSC,
arrows to right are to HLR
unless otherwise stated.




Figure 22.9.3/1 (sheet 2 of 3): Procedure MI_USSD_VLR




Figure 22.9.3/1 (sheet 3 of 3) : Procedure MI USSD VLR

Macrodefinition Receive_Error_at_VLR

22.9.3_2(1)




Figure 22.9.3/2: Macro Receive_Error_at_VLR

22.9.4 Procedures in the HLR

The Mobile initiated USSD Procedure in the HLR starts by the HLR receiving a MAP-OPEN service indication from the VLR.

Once a MAP dialogue is established, the HLR may handle the MAP_PROCESS_UNSTRUCTURED_SS_REQUEST from the VLR. This message contains information input by the user. If the alphabet used for the message is understood then the message shall either be fed to an application contained locally in the HLR or to the gsmSCF. If the alphabet is not understood then the error "UnknownAlphabet" shall be returned.

Message Destined for Local Application

If the message is destined for the local USSD application then the HLR shall transfer the message to the local application.

The HLR may subsequently receive one or more requests from the application which correspond to the MAP_UNSTRUCTURED_SS_REQUEST or MAP_UNSTRUCTURED_SS_NOTIFY indications. These shall be sent transparently to the VLR. When a confirmation is received from the VLR this shall be returned to the application.

When the HLR receives the result of the original operation from the application then it shall pass this to the VLR and initiate release of the CM connection.

Message Destined for gsmSCF

If the message is destined for the gsmSCF then the HLR shall transfer the message transparently to the gsmSCF.

The HLR may subsequently receive one or more MAP_UNSTRUCTURED_SS_REQUEST or MAP_UNSTRUCTURED_SS_NOTIFY indications from the gsmSCF. These shall be sent transparently to the VLR. When a confirmation is received from the VLR this shall be returned to the gsmSCF.

When the HLR receives a MAP_PROCESS_UNSTRUCTURED_SS_REQUEST confirmation from the gsmSCF then it shall pass this to the VLR and closes the MAP provider service.

Error Handling

Both the VLR, the USSD Application and the gsmSCF may initiate release of the MAP service at any time. This is handled as shown in the diagrams.

The procedure in the HLR is shown in figure 22.9.4/1.




Figure 22.9.4/1 (sheet 1 of 4): Procedure MI_USSD_HLR

Process MS_INIT_USSD_HLR

22.9.4_1.2(4)

Figure 22.9.4/1: Handling of mobile initiated USSD at HLR.

Arrows to left are to VLR,
arrows to right are to USSD application
unless otherwise stated.




Figure 22.9.4/1 (sheet 2 of 4): Procedure MI_USSD_HLR




Figure 22.9.4/1 (sheet 3 of 4): Procedure MI_USSD_HLR




Figure 22.9.4/1 (sheet 4 of 4): Procedure MI_USSD_HLR

22.9.5 Procedures in the gsmSCF

The Mobile initiated USSD Procedure in the gsmSCF starts by the gsmSCF receiving a MAP-OPEN service indication from the HLR.

Once a MAP dialogue is established, the gsmSCF may handle the MAP_PROCESS_UNSTRUCTURED_SS_REQUEST from the HLR.

The gsmSCF shall transfer the message to the local application.

The gsmSCF may subsequently receive one or more requests from the application which correspond to the MAP_UNSTRUCTURED_SS_REQUEST or MAP_UNSTRUCTURED_SS_NOTIFY indications. These shall be sent transparently to the HLR. When a confirmation is received from the HLR this shall be returned to the application.

When the gsmSCF receives the result of the original operation from the application then it shall pass this to the HLR and initiate release of the CM connection.

Error Handling

Both the HLR and the USSD Application may initiate release of the MAP service at any time. This is handled as shown in the diagrams.

The procedure in the gsmSCF is shown in figure 22.9.5/1.




Figure 22.9.5/1 Process MS INIT USSD qsmSCF

22.10 Network initiated USSD procedure

22.10.1 General

The procedure supports supplementary service signalling procedures which can allow PLMN specific services to be introduced.

The message flow for the procedure can be found in GSM 03.90.

The following services may be used:

MAP_PAGE	(defined in clauses 8 and 25);
MAP_SEARCH_FOR_MOBILE_SUBSCRIBER	(defined in clauses 8 and 25);
MAP_PROCESS_ACCESS_REQUEST	(defined in clauses 8 and 25);
MAP_AUTHENTICATE	(defined in clauses 8 and 25);
MAP_SET_CIPHERING_MODE	(defined in clauses 8 and 25);
MAP_FORWARD_NEW_TMSI	(defined in clauses 8 and 25);
MAP_READY_FOR_SM	(defined in clauses 12 and 25).

At least one of the following services will certainly be used, and both may be used:

MAP_UNSTRUCTURED_SS_REQUEST	(defined in clause 11);
MAP_UNSTRUCTURED_SS_NOTIFY	(defined in clause 11).

22.10.2 Procedure in the MSC

The procedure may be invoked either by the VLR or by a USSD application local to the MSC. They may start by using either the MAP_UNSTRUCTURED_SS_REQUEST or MAP_UNSTRUCTURED_SS_NOTIFY service. If the request is initiated by a local USSD application then the MSC will open a dialogue with the VLR.

In both cases the MSC will initiate a CM connection to the MS (using the page or search macros defined in subclause 25.3). Once the connection is successfully established the message received from the VLR or USSD application will be sent to the MS using the mapping specified in GSM 09.11.

Following transfer of the message the MSC will wait for a confirmation from the MS. This will be sent to the VLR or USSD application as appropriate.

Following this, the MSC may receive further uses of the MAP_UNSTRUCTURED_SS_REQUEST or MAP_UNSTRUCTURED_SS_NOTIFY services, or may receive an indication to release the connection to the MS.

In the event of an error, the connection to the MS shall be released, and the MAP process with the VLR shall be aborted as shown in the diagram.

The procedure in the MSC is shown in figure 22.10.2/1.




Figure 22.10.2/1 (sheet 1 of 4): Procedure NI_USSD_MSC

Process NW_INIT_USSD_MSC

22.10.2_1.2(4)

Figure 22.10.2/1: Handling of network initiated USSD in MSC




Figure 22.10.2/1 (sheet 2 of 4): Procedure NI_USSD_MSC

Process NW_INIT_USSD_MSC

22.10.2_1.3(4)

Figure 22.10.2/1: Handling of network initiated USSD in MSC




Figure 22.10.2/1 (sheet 3 of 4): Procedure NI_USSD_MSC

Process NW_INIT_USSD_MSC

22.10.2_1.4(4)

Figure 22.10.2/1: Handling of network initiated USSD in MSC

Arrows to left are to MS,
arrows to right are to USSD application
unless otherwise stated.




Figure 22.10.2/1 (sheet 4 of 4): Procedure NI_USSD_MSC

22.10.3 Procedure in the VLR

The procedure may be invoked either by the HLR or by a USSD application local to the VLR. They may start by using either the MAP_UNSTRUCTURED_SS_REQUEST or MAP_UNSTRUCTURED_SS_NOTIFY service.

In both cases the VLR will first initiate a MAP dialogue with the MSC. When the indication for the unstructured SS request or notify is received then the macro Start_USSD_VLR will be used to page the MS and open a CM connection. Once the CM connection is successfully established the indication received from the HLR or USSD application will be sent to the MSC.

Following transfer of the message the VLR will wait for a confirmation from the MSC. This will be sent to the HLR or USSD application as appropriate.

Following this, the VLR may receive further uses of the MAP_UNSTRUCTURED_SS_REQUEST or MAP_UNSTRUCTURED_SS_NOTIFY services, or may receive a MAP_CLOSE_ind.

In the event of an error, the MAP process with the MSC shall be released, and if necessary the MAP process with the HLR shall be aborted as shown in the diagram.

The procedure in the VLR is shown in figure 22.10.3/1.

MSC Initiated USSD

If a USSD application in the MSC wishes to use the network initiated USSD procedure, and a connection to the MS does not exist then it shall open a dialogue to the VLR. This dialogue will automatically lead to the VLR performing page and search using the macro Start_USSD_VLR.

Macro Start_USSD_VLR

This macro is used to initiate a CM connection with the MS for transfer of network initiated unstructured SS data.

It first checks for correct data in the VLR. If a problem is found then "Err" is returned.

A page or search procedure (as appropriate) will then be used to contact the MS. Following successful page or search the macro Process_Access_Request_VLR specified in subclause 25.4 will be used to handle the CM connection establishment.

The macro is shown in figure 22.10.3/2.




Figure 22.10.3/1 (sheet 1 of 4): Procedure NI_USSD_VLR

Process NW_INIT_USSD_VLR

22.10.3_1.2(4)

Figure 22.10.3/1: Handling of network initiated USSD at VLR


Arrows to left are to MSC,
arrows to right are to HLR
unless otherwise stated.

Figure 22.10.3/1 (sheet 2 of 4): Procedure NI_USSD_VLR




Figure 22.10.3/1 (sheet 3 of 4): Procedure NI_USSD_VLR

Process NW_INIT_USSD_VLR

22.10.3_1.4(4)

Figure 22.10.3/1: Handling of network initiated USSD at VLR

Arrows to left are to MSC,
arrows to right are to USSD application
unless otherwise stated.




Figure 22.10.3/1 (sheet 4 of 4): Procedure NI_USSD_VLR

Macrodefinition Start_USSD_VLR

22.10.3_2.1(2)

Figure 22.10.3/2: Macro to establish a connection to the MS for a network initiated USSD operation.




Figure 22.10.3/2 (sheet 1 of 2): Macro Start_USSD_VLR




Figure 22.10.3/2 (sheet 2 of 2): Macro Start_USSD_VLR

22.10.4 Procedure in the HLR

The procedure may be invoked either by the gsmSCF or by a USSD application local to the HLR. It may start by using either the MAP_UNSTRUCTURED_SS_REQUEST or MAP_UNSTRUCTURED_SS_NOTIFY service.

In both cases the HLR will first check whether the MS is reachable.

If the MS is reachable, the HLR will initiate a MAP dialogue with the VLR and send the message received from the gsmSCF or USSD application to the VLR.

Following transfer of the message the HLR will wait for a confirmation from the VLR. This will be sent to the gsmSCF or USSD application as appropriate.

Following this, the HLR may receive further uses of the MAP_UNSTRUCTURED_SS_REQUEST or MAP_UNSTRUCTURED_SS_NOTIFY services, or may receive a MAP_CLOSE_ind.

In the event of an error, the MAP process with the VLR shall be released and if necessary the MAP process with the gsmSCF shall be aborted, as shown in the diagram.

Message Originated by gsmSCF

If the message is originated by the gsmSCF then the HLR shall transfer the message transparently to the VLR.

The HLR may subsequently receive one or more MAP_UNSTRUCTURED_SS_REQUEST_ind or MAP_UNSTRUCTURED_SS_NOTIFY_ind indications from the gsmSCF. These shall be sent transparently to the VLR. When a confirmation is received from the VLR this shall be returned to the gsmSCF.

When the HLR receives a MAP_CLOSE_ind from the gsmSCF then it shall pass this to the VLR and close the MAP dialogue.

The procedure in the HLR is shown in figure 22.10.4/1 and 22.10.4/2.




Figure 22.10.4/1 (sheet 1 of 5): Procedure NI_USSD_HLR




Figure 22.10.4/1 (sheet 2 of 5): Procedure NI_USSD_HLR




Figure 22.10.4/1 (sheet 3 of 5): Procedure NI_USSD_HLR




Figure 22.10.4/1 (sheet 4 of 5): Procedure NI_USSD_HLR




Figure 22.10.4/1 (sheet 5 of 5): Procedure NI_USSD_HLR




Figure 22.10.4/2: Macro Start_USSD_HLR

22.11 Common macros for clause 22

The following macros are used for the description of more than one of the supplementary service processes described in clause 22.

22.11.1 SS Password handling macros

Macro Get_Password_MSC

This macro is used by the MSC to relay a request for password from the VLR to the MS, and to relay a response from the MS back to the VLR. The macro is described in figure 22.11.1/1.

Macro Get_Password_VLR

This macro is used by the VLR to relay a request for password from the HLR to the MSC, and to relay a response from the MSC back to the HLR. The macro is described in figure 22.11.1/2.

Macrodefinition GET_PASSWORD_MSC

22.11.1_1(1)

'Figure 22.11.1/1: Macro which relays a GetPassword request from the VLR to the MS
and relays the GetPassword response from the MS to the VLR




Figure 22.11.1/1: Macro Get_PW_MSC

Macrodefinition GET_PASSWORD_VLR

22.11.1_2(1)

'Figure 22.11.1/2: Macro which relay a GetPassword request from the HLR to the VLR
and relays the GetPassword response from the VLR to the HLR




Figure 22.11.1/2: Macro Get_PW_VLR

22.11.2 SS Error handling macros

Macro Receive_errors_MSC

This macro is used by the MSC to receive signals which should lead to failure if received in any state of a supplementary service process. If the air interface connection is released by the MS, the communication towards the VLR is aborted, and the MSC should return to a stable "NULL" state. If a MAP_NOTICE indication is received from the VLR, or the VLR aborts or unexpectedly closes the connection, then the air interface connection shall be released. The macro is described in figure 22.11.2/1.

Macro Receive_error_from_MSC

This macro is used by the VLR to receive signals from the MSC which should lead to failure if received in any state of a supplementary service process. If a MAP_NOTICE indication is received from the MSC, that connection is closed before the only outcome of the macro, "err" is reported back to the calling process. The macro is described in figure 22.11.2/2.

Macro Receive_error_from_HLR

This macro is used by the VLR to receive signals from the HLR which should lead to failure if received in any state of a supplementary service process. If a MAP_NOTICE indication is received from the HLR, that connection is closed. The macro is described in figure 22.11.2/3.

Macro Receive_error_from_VLR

This macro is used by the HLR to receive signals from the VLR that should lead to failure if received in any state of a supplementary service process. If a MAP_NOTICE indication is received from the VLR, that connection is closed before the only outcome of the macro, "err" is reported back to the calling process. The macro is described in figure 22.11.2/4.

Macro Receive_error_from_gsmSCF

This macro is used by the HLR to receive signals from the gsmSCF that should lead to failure if received in any state of a supplementary service process. If a MAP_NOTICE indication is received from the gsmSCF, that connection is closed. The macro is described in figure 22.11.2/5.

Macrodefinition Receive_errors_MSC

22.11.2_1(1)

Figure 22.11.2/1: Macro which handles possible error situations while the MSC is waiting for a confirmation of a supplementary service request to the VLR




Figure 22.11.2/1: Macro Receive_Errors_MSC

Macrodefinition Receive_error_from_MSC

22.11.2_2(1)

Figure 22.11.2/2: Macro to receive errors from the MSC during supplementary services procedures in the VLR




Figure 22.11.2/2: Macro Receive_Error_from_MSC

Macrodefinition Receive_error_from_HLR

22.11.2_3(1)

Figure 22.11.2/3: Macro to receive errors from the HLR while the VLR is waiting for a confirmation of a supplementary service request sent to the HLR




Figure 22.11.2/3: Macro Receive_Error_HLR

Macrodefinition Receive_error_from_VLR

22.11.2_4(1)

Figure 22.11.2/4: Macro to receive errors from the VLR during supplementary services procedures in the HLR




Figure 22.11.2/4: Macro Receive_error_from_VLR

Macrodefinition Receive_error_from_gsmSCF

22.11.2_5(1)

Figure 22.11.2/5: Macro to receive errors from the gsmSCF while the HLR is waiting for a confirmation of a supplementary service request sent to the gsmSCF




Figure 22.11.2/5: Macro Receive_error_from_gsmSCF

22.12 Supplementary Service Invocation Notification procedure

22.12.1 General

The Supplementary Service Invocation Notification procedure is used to notify a gsmSCF about the invocation of a GSM Supplementary Service.

The password registration procedure is shown in figure 22.12.1/1.

The following services may be used.



- (1) MAP-SUPPLEMENTARY-SERVICE-INVOCATION-NOTIFICATION (MSC to gsmSCF).
- (2) MAP-SUPPLEMENTARY-SERVICE-INVOCATION-NOTIFICATION-ACK (gsmSCF to MSC).
- MAP-SUPPLEMENTARY-SERVICE-INVOCATION-NOTIFICATION (defined in clauses 8 and 25).

Figure 22.12.1/1: Interfaces and services for supplementary service invocation notification

22.12.2 Procedures in the MSC

The supplementary service invocation notification procedure in the MSC is triggered when the requested supplementary service is invoked at the MSC. The MSC notifies the gsmSCF of a supplementary service invocation the MAP-SUPPLEMENTARY-SERVICE-INVOCATION-NOTIFICATION service. This is sent in a TCAP TC-BEGIN primitive. The MSC then awaits a positive or negative acknowledgement from the gsmSCF to the MAP-SUPPLEMENTARY-SERVICE-INVOCATION-NOTIFICATION. This is received in a TCAP TC-END primitive, and upon receipt the relationship between the MSC and the gsmSCF is terminated. Similarly, the relationship is terminated at the MSC by the sending from or receipt of a TCAP P-ABORT primitive. This is illustrated in figure 22.12.2.




Figure 22.12.2 Process SS_Invocation_Notify_MSC (sheet 1 of 1)

22.12.3 Procedures in the gsmSCF

Upon receiving notification of the supplementary service invocation via the MAP-SUPPLEMENTARY-SERVICE-INVOCATION-NOTIFICATION service, the gsmSCF analyses the received information. If the gsmSCF understands the information sent via the MAP-SUPPLEMENTARY-SERVICE-INVOCATION-NOTIFICATION service then it returns a positive acknowledgement to the MAP-SUPPLEMENTARY-SERVICE-INVOCATION-NOTIFICATION, indicating the success of the service. This is returned in a TCAP TC-END primitive, using the basic end procedure.

Otherwise, a negative acknowledgement to the MAP-SUPPLEMENTARY-SERVICE-INVOCATION-NOTIFICATION is returned. This is also returned in a TCAP TC-END primitive, again using the basic end procedure. The gsmSCF TCAP service may also choose to abort the relationship to the MSC by sending a TCAP P-ABORT primitive. It will immediately terminate processing of a MAP-SUPPLEMENTARY-SERVICE-INVOCATION-NOTIFICATION should a TCAP P-ABORT primitive be received from the MSC. This is illustrated in figure 22.12.3.




Figure 22.12.3 Process SS_Invocation_Notify_gsmSCF (sheet 1 of 1)

22.13 Activation of a CCBS request

22.13.1 General

The message flow to activate a CCBS request is shown in figure 22.13.1/1.




Figure 22.13.1/1: Message flow to activate a CCBS request

22.13.2 Procedure in the VLR

The MAP process in the VLR to activate a CCBS request is shown in figure 22.13.2/1. The MAP process invokes macros not defined in this subclause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2;

Successful Outcome

When the MAP process receives a CCBS Request message from the CCBS application process in the VLR, it requests a dialogue with the HLR whose identity is contained in the request by sending a MAP_OPEN service request and the necessary information in a MAP_REGISTER_CC_ENTRY service request. The VLR then invokes the macro Receive_Open_Cnf to wait for the response to the dialogue opening request. If the dialogue opening is successful, the MAP process waits for a response from the HLR.

If the MAP process receives a MAP_REGISTER_CC_ENTRY service confirm from the HLR, the MAP process invokes the macro Check_Confirmation to check the content of the confirm.

If the macro Check_Confirmation takes the OK exit, the MAP process sends a CCBS Request Ack message containing the information received from the HLR to the CCBS application process in the VLR and returns to the idle state.

Failure of dialogue opening with the HLR

If the macro Receive_Open_Cnf takes the Vr exit or the Error exit, the MAP process sends a CCBS Request Negative response message to the CCBS application process in the VLR and returns to the idle state.

Error in MAP_REGISTER_CC_ENTRY confirm

If the MAP_REGISTER_CC_ENTRY service confirm contains a user error or a provider error, or the macro Check_Confirmation indicates that there is a data error, the MAP process sends a CCBS Request Negative response message to the CCBS application process in the VLR and returns to the idle state.

Abort of HLR dialogue

After the dialogue with the HLR has been established, the MAP service provider may abort the dialogue by issuing a MAP_P_ABORT indication. In this case, the MAP process sends a CCBS Request negative response to the CCBS application process in the VLR and returns to the idle state.

If the MAP provider indicates a protocol problem by sending a MAP_NOTICE indication, the MAP process closes the dialogue with the HLR, sends a CCBS Request negative response indicating system failure to the CCBS application process in the VLR and returns to the idle state.




Figure 22.13.2/1: Process Register_CC_Entry_VLR

22.13.3 Procedure in the HLR

Successful outcome

When the MAP process receives a MAP_REGISTER_CC_ENTRY_indication from the co-ordinating process, it sends a CCBS Request message to the CCBS application process in the HLR, and waits for a response. The request contains the parameters received in the MAP_REGISTER_CC_ENTRY service indication.

If the CCBS application process in the HLR returns a positive response, the MAP process constructs a MAP_REGISTER_CC_ENTRY service response, constructs a MAP_CLOSE service request, sends them to the co-ordinating process and terminates.

Negative response from HLR CCBS application process

If the CCBS application process in the HLR returns a negative response, the MAP process constructs a MAP_REGISTER_CC_ENTRY service response containing the appropriate error, constructs a MAP_CLOSE service request, sends them to the co-ordinating process and terminates.

Process Register_CC_Entry_HLR

22.13.3_1(1)

Figure 22.13.3/1: Process in the HLR
to handle a request to
register a CC entry

Signals to/from the left
are to/from the VLR
via the coordinating process;
signals to/from the right
are to/from the CCBS
application process in the HLR




Figure 22.13.3/1: Process Register_CC_Entry_HLR

22.14 Deactivation of a CCBS request

22.14.1 General

The message flow to deactivate a CCBS request is shown in figure 22.14.1/1.




Figure 22.14.1/1: Message flow to deactivate a CCBS request

22.14.2 Procedure in the VLR

The MAP process in the VLR to deactivate a CCBS request is shown in figure 22.14.2/1. The MAP process invokes macros not defined in this subclause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2;

Successful Outcome

When the MAP process receives a Deactivate CCBS message from the CCBS application process in the VLR, it requests a dialogue with the HLR whose identity is contained in the request by sending a MAP_OPEN service request and the necessary information in a MAP_ERASE_CC_ENTRY service request. The VLR then invokes the macro Receive_Open_Cnf to wait for the response to the dialogue opening request. If the dialogue opening is successful, the MAP process waits for a response from the HLR.

If the MAP process receives a MAP_ERASE_CC_ENTRY service confirm from the HLR, the MAP process invokes the macro Check_Confirmation to check the content of the confirm.

If the macro Check_Confirmation takes the OK exit, the MAP process sends a Deactivate CCBS Ack message containing the information received from the HLR to the CCBS application process in the VLR and returns to the idle state.

Failure of dialogue opening with the HLR

If the macro Receive_Open_Cnf takes the Vr exit or the Error exit, the MAP process sends a Deactivate CCBS Negative response message to the CCBS application process in the VLR and returns to the idle state.

Error in MAP_ERASE_CC_ENTRY confirm

If the MAP_ERASE_CC_ENTRY service confirm contains a user error or a provider error, or the macro Check_Confirmation indicates that there is a data error, the MAP process sends a Deactivate CCBS Negative response message to the CCBS application process in the VLR and returns to the idle state.

Abort of HLR dialogue

After the dialogue with the HLR has been established, the MAP service provider may abort the dialogue by issuing a MAP_P_ABORT indication. In this case, the MAP process sends a Deactivate CCBS negative response to the CCBS application process in the VLR and returns to the idle state.

If the MAP provider indicates a protocol problem by sending a MAP_NOTICE indication, the MAP process closes the dialogue with the HLR, sends a Deactivate CCBS negative response indicating system failure to the CCBS application process in the VLR and returns to the idle state.




Figure 22.14.2/1: Process Erase_CC_Entry_VLR

22.14.3 Procedure in the HLR

Successful outcome

When the MAP process receives a MAP_ERASE_CC_ENTRY_indication from the co-ordinating process, it sends a Deactivate CCBS message to the CCBS application process in the HLR, and waits for a response. The message contains the parameters received in the MAP_ERASE_CC_ENTRY service indication.

If the CCBS application process in the HLR returns a positive response, the MAP process constructs a MAP_ERASE_CC_ENTRY service response, constructs a MAP_CLOSE service request, sends them to the co-ordinating process and terminates.

Negative response from HLR CCBS application process

If the CCBS application process in the HLR returns a negative response, the MAP process constructs a MAP_ERASE_CC_ENTRY service response containing the appropriate error, constructs a MAP_CLOSE service request, sends them to the co-ordinating process and terminates.

Process Erase_CC_Entry_HLR

22.14.3_1(1)

Figure 22.14.3/1: Process in the HLR
to handle a request to
erase a CC entry

Signals to/from the left
are to/from the VLR
via the coordinating process;
signals to/from the right
are to/from the CCBS
application process in the HLR




Figure 22.14.3/1: Process Erase_CC_Entry_HLR

23 Short message service procedures

23.1 General

The short message service procedures are used to control both mobile originated and mobile terminated short message transfer.

Four procedures exist for short message services:

- mobile originated short message service transfer;
- mobile terminated short message service transfer;
- short message alert procedure;
- short message waiting data set procedure.

The following application context refers to a complex MAP user consisting of several processes:

- shortMessageGatewayContext.

This application context needs a co-ordinating process in the HLR. Additionally a Co-ordinator has to be defined for the mobile originated situation in the MSC, because the A_CM_SERV_REQ message does not distinguish between mobile originated short message transfer and the short message alert procedures.

NOTE: A_CM_SERV_REQ message is not used for SMS over GPRS.

23.1.1 Mobile originated short message service Co-ordinator for the MSC

The A_CM_SERV_REQ message (GSM 04.08) is received from the A-interface containing the CM service type. This parameter indicates mobile originated short message service. The service MAP_PROCESS_ACCESS_REQUEST is started.

If the MAP_PROCESS_ACCESS_REQUEST service ends successfully, the MS initiates mobile originated short message transfer or alerting indication. Depending on the situation, the appropriate process is initiated as follows:

- if the A_RP_MO_DATA indication is received, the process MOSM_MSC is initiated (see subclause 23.2.1);
- if the A_RP_SM_MEMORY_AVAILABLE indication is received, the process SC_Alert_MSC is initiated (see subclause 23.4.1).

After creation of the user process the Co-ordinator relays the messages between the A-interface and the invoked process until a request or an indication for dialogue termination is received.

The SMS process Co-ordinator is shown in the figure 23.1/1.




Figure 23.1/1: Process Co_SMS_MSC

23.1.2 Short message Gateway Co-ordinator for the HLR

The MAP_OPEN indication opens a dialogue for the short message procedure between the gateway MSC and the HLR when the application context shortMessageGatewayContext is received. If that service is successful, the Co-ordinator can receive the first service primitive from the MAP_PM. Depending on the received primitive, the user process is created as follows:

- if the MAP_SEND_ROUTING_INFO_FOR_SM indication is received, the process Mobile_Terminated_MS_HLR is created;
- if the MAP_REPORT_SM_DELIVERY_STATUS indication is received, the process Report_SM_delivery_stat_HLR is created.

After creation of the user processs the Co-ordinator relays the messages between the MAP_PM and the invoked process until a request or an indication for dialogue termination is received.

The SM Gateway Co-ordinator is shown in the figure 23.1/2.

If the Receive_Open_Ind macro takes the Vr exit then HLR shall perform the MAP Vr dialogue. But based on the subscriber data, handling at the MAP user application level may be performed as described in release 97 :

- If the subscriber is not a GPRS subscriber then the behaviour of the HLR shall be the same as described in the corresponding MAP Vr release.
- If the subscriber is a GPRS subscriber and a non-GPRS subscriber with the option « transfer of SM via the MSC when GPRS is not supported in the GMSC » then the behaviour of the HLR shall be the same as described in the corresponding MAP Vr release.
- If the subscriber is a GPRS subscriber and a non-GPRS subscriber with the option « transfer of SM via the SGSN when GPRS is not supported in the GMSC » or if the subscriber is a GPRS subscriber only then the behaviour of the HLR shall be the same as for the case transfer over GPRS described in MAP release 97, with the following precision : because GMSC does not support MAP release 97, the previous MAP protocol release is used. When the HLR sends the MAP_SEND_ROUTING_INFO_FOR_SM_Resp, the SGSN number is mapped to the MAP parameter « MSC number ». When the HLR sends the MAP_INFORM_SERVICE_CENTRE_resp, the MNRG status shall be mapped to the MAP parameter « mnrf-set ». When the HLR receives the MAP_REPORT_SM_DELIVERY_STATUS_Ind, it shall interpret the delivery outcome as a GPRS delivery outcome.




Figure 23.1/2: Process Co_SMS_Gateway_HLR

23.1.3 Mobile originated short message service Co-ordinator for the SGSN

The MS initiates mobile originated short message transfer or alerting indication. Depending on the situation, the appropriate process is initiated as follows:

- if the A_RP_MO_DATA indication is received, the process MOSM_SGSN is initiated (see subclause 23.2.4);
- if the A_RP_SM_MEMORY_AVAILABLE indication is received, the process SC_Alert_SGSN is initiated (see subclause 23.4.5).

After creation of the user process the Co-ordinator relays the messages between the SGSN and the MS, and the invoked process until a request or an indication for dialogue termination is received.

The SMS process Co-ordinator is shown in the figure 23.1/3.

Process Co_SMS_SGSN

23.1_3(1)

Figure 23.1/3: The SMS co-ordinating process in the SGSN




Figure 23.1/3: Process Co_SMS_SGSN

23.2 The mobile originated short message transfer procedure

The mobile originated short message service procedure is used to forward short message from a mobile subscriber to a Service Centre. The mobile originated short message service procedure is shown in figure 23.2/1.




Figure 23.2/1: Mobile originated short message transfer

In addition the following MAP services are used:

MAP_PROCESS_ACCESS_REQUEST	(see subclause 8.3); (*)
MAP_AUTHENTICATE	(see subclause 8.5); (*)
MAP_SET_CIPHERING_MODE	(see subclause 8.6); (*)
MAP_PROVIDE_IMSI	(see subclause 8.9); (*)
MAP_CHECK_IMEI	(see subclause 8.7);
MAP_FORWARD_NEW_TMSI	(see subclause 8.9); (*)
MAP_TRACE_SUBSCRIBER_ACTIVITY	(see subclause 9.1); (*)
MAP_READY_FOR_SM	(see subclause 12.4).

(*) Those messages are not used by SGSN.

23.2.1 Procedure in the servicing MSC

The activation of the MAP_PROCESS_ACCESS_REQUEST service is described in the subclause 25.4.1.

When receiving the short message from the A-interface, the MSC sends the MAP_SEND_INFO_FOR_MO_SMS request to the VLR. As a response the MSC will receive the MAP_SEND_INFO_FOR_MO_SMS confirmation from VLR indicating that:

- the service ends successfully. If the MSC is not itself the IWMSC, the short message transmission towards the IWMSC is initiated using the MAP_MO_FORWARD_SHORT_MESSAGE request;
- the service ends unsuccessfully. The error cause in the MAP_SEND_INFO_FOR_MO_SMS confirmation indicates the reason for the unsuccessful end. The mapping between MAP error causes and RP_ERROR causes is described in TS GSM 03.40.

If there are data errors in the MAP_SEND_INFO_FOR_MO_SMS confirmation, or there is an operation failure in MAP, the RP_ERROR cause network out of order is forwarded to the mobile station.

If the service MAP_MO_FORWARD_SHORT_MESSAGE is started, the MSC will check whether the grouping of MAP_OPEN request and MAP_MO_FORWARD_SHORT_MESSAGE request needs segmentation. If this is the case then the MAP_OPEN request primitive shall be sent first without any associated MAP service request primitive and the dialogue confirmation must be received before the MAP_MO_FORWARD_SHORT_MESSAGE request is sent. As a response to the procedure, the servicing MSC will receive the MAP_MO_FORWARD_SHORT_MESSAGE confirmation from the IWMSM indicating that:

- the short message has been successfully delivered to the Service Centre. The acknowledgement is sent to the mobile station;
- one of several error cases has occurred. The mapping between MAP error causes and RP_ERROR causes is described in TS GSM 03.40. The appropriate indication is provided to the mobile station.

If the procedure failed, a provider error or an abort indication is received. The RP_ERROR cause network out of order is provided to the mobile station.

If the MSC itself is the interworking MSC, the short message is forwarded to the Service Centre. In that case the service MAP_MO_FORWARD_SHORT_MESSAGE is not initiated. The acknowledge message from the Service Centre is forwarded to the mobile station (TS GSM 03.40, TS GSM 04.11).

The mobile originated short message service procedure is shown in figure 23.2/2.

Process MOSM_MSC

23.2_2.1(3)

Figure 23.2/2: The mobile originated short message service process in the MSC.




Figure 23.2/2 (sheet 1 of 3): Process MOSM_MSC

Process MOSM_MSC

23.2_2.2(3)

Figure 23.2/2: The mobile originated short message service process in the MSC.




Figure 23.2/2 (sheet 2 of 3): Process MOSM_MSC

Process MOSM_MSC 23.2_2.3(3)




Figure 23.2/2 (sheet 3 of 3): Process MOSM_MSC

23.2.2 Procedure in the VLR

The MAP_PROCESS_ACCESS_REQUEST indication starts the MAP_PROCESS_ACCESS_REQUEST service in the VLR. The application context in the MAP_OPEN indication is mobile originated short message transfer.

If the service MAP_PROCESS_ACCESS_REQUEST is successful, the VLR waits for the next message from the MSC. When receiving the MAP_SEND_INFO_FOR_MO_SMS indication, the VLR acts as follows:

- if there is incompatibility in the subscription check, the error teleservice not provisioned is returned to the MSC;
- if the short message transfer would contravene operator determined barring, the call barred error with cause operator barring is returned;
- if the short message transfer would contravene the supplementary service call barring conditions in the VLR, the call barred error with cause barring service active is returned.

When the mobile subscriber has passed all checks, the MAP_SEND_INFO_FOR_MO_SMS response is initiated and the procedure is terminated in the VLR. The mobile originated short message transfer procedure in the VLR is shown in figure 23.2/3.




Figure 23.2/3: Process MOSM_VLR

23.2.3 Procedure in the interworking MSC

This procedure applies only when the IWMSC is not the servicing MSC or SGSN.

When receiving a MAP_OPEN indication primitive that is not associated with any MAP service indication primitive and if the dialogue is accepted, the MAP service-user in the interworking MSC issues a MAP_DELIMITER request primitive in order to trigger the local MAP service-provider to confirm the dialogue. Then a MAP_MO_FORWARD_SHORT_MESSAGE indication shall be received.

When a MAP_MO_FORWARD_SHORT_MESSAGE indication is correctly received, the Interworking MSC invokes forwarding of the short message to the Service Centre. If invalid data content is detected, an unexpected data value error or a data missing error is returned to the servicing MSC or SGSN.

The outcome of the procedure with the Service Centre is awaited before a MAP_MO_FORWARD_SHORT_MESSAGE response is given back to the servicing MSC or SGSN:

- if a short message is accepted by the Service Centre, an acknowledgement is sent back to the servicing MSC or SGSN;
- if the Service Centre is not identified, the SM Delivery Failure error is returned to the servicing MSC or SGSN;
- if the Service Centre returns an error indication, the SM Delivery Failure error is returned to the servicing MSC with the error cause and any diagnostic information received from the Service Centre;
- if the short message cannot be forwarded to the Service Centre or the procedure towards the Service Centre fails for some reason, a system failure error is sent to the servicing MSC or SGSN.

The mobile originated short message service transfer in the IWMSC is shown in figure 23.2/4.




Figure 23.2/4: Process MOSM_IWMSC

23.2.4 Procedure in the servicing SGSN

When receiving the short message from the MS, the SGSN acts as follows:

- if there is incompatibility in the subscription check, the RP_ERROR cause requested facility not subscribed is provided to the mobile station;
- if the short message transfer would contravene operator determined barring, the RP_ERROR cause operator determined barring is provided to the mobile station;

NOTE: The RP_ERROR causes are described in TS GSM 04.11

- if no error is detected, the short message transmission towards the IWMSC is initiated using the MAP_MO_FORWARD_SHORT_MESSAGE request.

If the service MAP_MO_FORWARD_SHORT_MESSAGE is started, the SGSN will check whether the grouping of MAP_OPEN request and MAP_MO_FORWARD_SHORT_MESSAGE request needs segmentation.

If this is the case then the MAP_OPEN request primitive shall be sent first without any associated MAP service request primitive and the dialogue confirmation must be received before the MAP_MO_FORWARD_SHORT_MESSAGE request is sent. As a response to the procedure, the servicing SGSN will receive the MAP_MO_FORWARD_SHORT_MESSAGE confirmation from the IWMSC indicating that:

- the short message has been successfully delivered to the Service Centre. The acknowledgement is sent to the mobile station;
- one of several error cases has occurred. The mapping between MAP error causes and RP_ERROR causes is described in TS GSM 03.40. The appropriate indication is provided to the mobile station.

If the procedure failed, a provider error or an abort indication is received. The RP_ERROR cause network out of order is provided to the mobile station.

The mobile originated short message service procedure is shown in figure 23.2/5

Process MOSM_SGSN 23.2_5.1(3)

Figure 23.2/5: The mobile originated short message service process in the SGSN.




Figure 23.2/5 (sheet 1 of 3): Process MOSM_SGSN

Process MOSM_SGSN

23.2_5.2(3)

Figure 23.2/5: The mobile originated short message service process in the SGSN.




Figure 23.2/5 (sheet 2 of 3): Process MOSM_SGSN

Process MOSM_SGSN 23.2_5.3(3)

Figure 23.2/5: The mobile originated short message service process in the SGSN.





Figure 23.2/5 (sheet 3 of 3): Process MOSM_SGSN

23.3 The mobile terminated short message transfer procedure


The mobile terminated short message transfer procedure is used for forwarding a short message or several short messages from a Service Centre to a mobile subscriber. The mobile terminated short message procedure for a single short message transfer is shown in figure 23.3/1.



- 1) Short Message (GSM 03.40).
 - 2) MAP_SEND_ROUTING_INFO_FOR_SM.
 - 3) MAP_SEND_ROUTING_INFO_FOR_SM_ACK.
 - 4) MAP_MT_FORWARD_SHORT_MESSAGE.
 - 5) MAP_SEND_INFO_FOR_MT_SMS (*).
 - 6) MAP_PAGE/MAP_SEARCH_FOR_MOBILE_SUBSCRIBER (*).
 - 7) Page (GSM 04.08).
 - 8) Page response (GSM 04.08).
 - 9) MAP_PROCESS_ACCESS_REQUEST_ACK and
MAP_SEARCH_FOR_MOBILE_SUBSCRIBER_ACK (*).
 - 10) MAP_SEND_INFO_FOR_MT_SMS_ACK (*).
 - 11) Short Message (GSM 04.11).
 - 12) Short Message Acknowledgement (GSM 04.11).
 - 13) MAP_MT_FORWARD_SHORT_MESSAGE_ACK.
 - 14) Short Message Acknowledgment (GSM 03.40).
- (*) Messages 5), 6), 9), and 10) are not used by SGSN.

Figure 23.3/1: Mobile terminated short message service procedures

The mobile terminated short message procedure for multiple short message transfer is shown in figure 23.3/2.



- 1) Short Message (GSM 03.40).
 - 2) MAP_SEND_ROUTING_INFO_FOR_SM.
 - 3) MAP_SEND_ROUTING_INFO_FOR_SM_ACK.
 - 4) MAP_MT_FORWARD_SHORT_MESSAGE (note 1).
 - 5) MAP_SEND_INFO_FOR_MT_SMS (*).
 - 6) MAP_PAGE/MAP_SEARCH_FOR_MOBILE_SUBSCRIBER (*).
 - 7) Page (GSM 08.08).
 - 8) Page response (GSM 04.08).
 - 9) MAP_PROCESS_ACCESS_REQUEST_ACK and
MAP_SEARCH_FOR_MOBILE_SUBSCRIBER_ACK (*).
 - 10) MAP_SEND_INFO_FOR_MT_SMS_ACK (*).
 - 11) Short Message (GSM 04.11).
 - 12) Short Message Acknowledgement (GSM 04.11).
 - 13) MAP_MT_FORWARD_SHORT_MESSAGE_ACK.
 - 14) Short Message Acknowledgment (GSM 03.40).
 - 15) Short Message (GSM 03.40).
 - 16) MAP_MT_FORWARD_SHORT_MESSAGE (note 2).
 - 17) Short Message (GSM 04.11).
 - 18) Short Message Acknowledgement (GSM 04.11).
 - 19) MAP_MT_FORWARD_SHORT_MESSAGE_ACK.
 - 20) Short Message Acknowledgement (GSM 03.40).

(*) Messages 5), 6), 9), and 10) are not used by SGSN.

NOTE 1: The More Messages To Send flag is TRUE.
NOTE 2: The More Messages To Send flag is FALSE.

Figure 23.3/2: Mobile terminated short message procedure for multiple short message transfer

In the multiple short message transfer the service MAP_MT_FORWARD_SHORT_MESSAGE can be used several times. However, the short message transfer is always acknowledged to the Service Centre before the next short message is sent.

In addition the following MAP services are used:

MAP_PROCESS_ACCESS_REQUEST	(see subclause 8.3); (*)
MAP_PAGE	(see subclause 8.2); (*)
MAP_SEARCH_FOR_MS	(see subclause 8.2); (*)
MAP_AUTHENTICATE	(see subclause 8.5); (*)
MAP_SET_CIPHERING_MODE	(see subclause 8.6); (*)
MAP_CHECK_IMEI	(see subclause 8.7);

MAP_FORWARD_NEW_TMSI	(see subclause 8.9); (*)
MAP_REPORT_SM_DELIVERY_STATUS	(see subclause 12.3);
MAP_INFORM_SERVICE_CENTRE	see subclause 12.6);
MAP_TRACE_SUBSCRIBER_ACTIVITY	(see subclause 9.1); (*)
MAP_READY_FOR_SM	(see subclause 12.4).

(*) Those messages are not used by SGSN.

23.3.1 Procedure in the Servicing MSC

When initiating the dialogue with the servicing MSC, the SMS Gateway MSC must provide the IMSI of the subscriber to whom the short message is directed.

The IMSI can be included either in the Destination Reference of the MAP_OPEN indication received from the SMS Gateway MSC or in the sm-RP-DA information field of the MAP_MT_FORWARD_SHORT_MESSAGE indication.

When receiving a MAP_OPEN indication primitive that is not associated with any MAP service indication primitive and if the dialogue is accepted, the MAP service-user in the servicing MSC issues a MAP_DELIMITER request primitive in order to trigger the local MAP service-provider to confirm the dialogue.

When receiving the first MAP_MT_FORWARD_SHORT_MESSAGE indication from the gateway MSC, the servicing MSC sends the MAP_SEND_INFO_FOR_MT_SMS request primitive to the VLR, if the MAP service primitive is accepted and if short message service is supported in the servicing MSC.

The MAP_MT_FORWARD_SHORT_MESSAGE indication primitive is checked by the macro "Check_Indication". If the received MAP service primitive contains errors, the service is aborted and an unexpected data value error or data missing error is returned to the GMSC.

If the MSC does not support the short message service, the service is aborted in the servicing MSC and the error "Facility Not Supported" is returned to the GMSC.

The subscriber identity information that may be included in the MAP_OPEN indication primitive and in the MAP service indication primitive is checked by the macro "Check_Subscr_Identity_For_MT_SMS" as follows.

If a Destination Reference has been received in the MAP_OPEN indication, an LMSI must be present in the sm-RP-DA information field of the MAP_MT_FORWARD_SHORT_MESSAGE indication. The LMSI shall be included in the sm-RP-DA information field of the MAP_SEND_INFO_FOR_MT_SMS request sent to the VLR; the associated MAP_OPEN request must contain a Destination Reference that carries an IMSI.

Otherwise, if the IMSI is included in the sm-RP-DA information field of the MAP_MT_FORWARD_SHORT_MESSAGE indication, it is mapped into the sm-RP-DA information field of the MAP_SEND_INFO_FOR_MT_SMS request that is sent to the VLR. In this case, the IMSI is not accompanied by an LMSI and neither the MAP_OPEN indication received from the gateway MSC nor the MAP_OPEN request sent to the VLR shall include a Destination Reference.

If a Destination Reference has been received in the servicing MSC and the sm-RP-DA information field of the MAP_MT_FORWARD_SHORT_MESSAGE indication does not include an LMSI or if no Destination Reference has been received and the sm-RP-DA information field does not cover an IMSI the service is aborted in the servicing MSC and the error "Unexpected Data Value" is returned to the SMS GMSC.

The following responses to the MAP_SEND_INFO_FOR_MT_SMS request may be received from the VLR:

- unidentified subscriber or system failure error. The error code is forwarded to the GMSC;
- absent subscriber error. The absent subscriber_SM error is forwarded to the GMSC with the absent subscriber diagnostic indication set to 'IMSI Detached';
- unknown subscriber error. The system failure indication is provided to the GMSC;
- data missing or unexpected data value error. The system failure indication is provided to the GMSC;

- a provider error or an abort indication. The system failure indication is provided to the GMSC;
- subscriber busy for MT SMS. The error code is forwarded to the GMSC;
- paging procedure invocation (see subclause 25.3) reporting the successful outcome of the procedure;
- search procedure invocation (see subclause 25.3) reporting the successful outcome of the procedure.

The result of the paging or the search procedure is processed as follows:

- if the procedure is completed successfully, the MSC will send the MAP_PROCESS_ACCESS_REQUEST request to the VLR (see subclause 25.4);
- if the procedure is completed successfully, but the MS has no mobile terminated short message transfer capability, the procedure is terminated and SM delivery failure indication with cause "equipment not SM equipped" is provided to the GMSC;
- if the procedure ends unsuccessfully, the termination of the procedure is awaited from the VLR. The absent subscriber_SM error is forwarded to the GMSC with the absent subscriber diagnostic indication set to 'No Paging Response', but the other error causes are reported as a system failure indication.

If the short message transfer is aborted for any reason, the dialogue with the VLR is aborted. If the procedure with the VLR is aborted by the VLR or by the provider, a system failure indication is provided to the GMSC.

The unsuccessful outcome of the MAP_PROCESS_ACCESS_REQUEST service is reported by using the system failure error to the GMSC.

When the service MAP_PROCESS_ACCESS_REQUEST is carried out, the MSC will receive the MAP_SEND_INFO_FOR_MT_SMS confirmation indicating:

- the unsuccessful outcome of the procedure. The error indication received from the VLR is forwarded to the GMSC;
- the successful outcome of the procedure. The MSC initiates forwarding of the short message to the MS.

If the primitive itself is badly formatted or data is missing, the system failure error is sent to the GMSC.

If forwarding of the short message is initiated, the MSC awaits the result before one of the following responses is sent back to the GMSC:

- an acknowledge if the short message has been successfully delivered to the mobile subscriber;
- an SM delivery failure error containing a parameter indicating either of the following: there is a MS protocol error or the MS memory capacity is exceeded; detailed diagnostic information (see subclause 7.6.1.4) may also be carried;
- a system failure error if the delivery procedure is aborted.

If the More Messages To Send flag was FALSE or the service MAP_MT_FORWARD_SHORT_MESSAGE ends unsuccessfully, the transaction to the gateway MSC is terminated. Otherwise, the servicing MSC waits for the next short message from the Service Centre.

When receiving the next MAP_MT_FORWARD_SHORT_MESSAGE indication from the gateway MSC the servicing MSC will act as follows:

- if the received primitive contains errors, the unexpected data value error or data missing error is provided to the gateway MSC;
- if the More Messages To Send flag is FALSE, the servicing MSC will start the short message transfer procedure to the mobile subscriber. The successful or unsuccessful outcome of this procedure is reported to the gateway MSC and the transaction is terminated.
- if the More Messages To Send flag is TRUE, the servicing MSC will start the short message transfer to the mobile subscriber. If the outcome of this procedure is unsuccessful, the reason is reported to the gateway MSC and the procedure is terminated. If the procedure is successful, it is acknowledged to the gateway MSC and more short messages can be received.

The tracing procedure may be activated. It is described in detail in the clause 20.

The mobile terminated short message transfer procedure in the servicing MSC is shown in figures 23.3/3 and 23.3/4. The page and search procedures are shown in figure 25.3/1 and 25.3/2.




Figure 23.3/3 (sheet 1 of 3): Procedure MTSM_VMSC

Process MTSM_VMSC

23.3_3.2(3)

Figure 23.3/3: The mobile terminated short message service process in the MSC




Figure 23.3/3 (sheet 2 of 3): Procedure MTSM_VMSC

Process MTSM_VMSC

23.3_3.3(3)

Figure 23.3/3: The mobile terminated short message service process in the MSC




Figure 23.3/3 (sheet 3 of 3): Procedure MTSM_VMSC




Figure 23.3/4 (sheet 1 of 3): Macro MT_SM_Transfer_MSC

Macrodefinition MT_SM_Transfer_MSC 23.3_4.2(3)




Figure 23.3/4 (sheet 2 of 3): Macro MT_SM_Transfer_MSC

Macrodefinition MT_SM_Transfer_MSC

23.3_4.3(3)

Figure 23.3/4: The mobile terminated short message transfer macro in the MSC




Figure 23.3/4 (sheet 3 of 3): Macro MT_SM_Transfer_MSC

23.3.2 Procedures in the VLR

When receiving the MAP_SEND_INFO_FOR_MT_SMS indication, the VLR will act as follows:

- the parameters and data in the primitive are checked by the macro "Check_Indication". A data failure is reported as an unexpected data value error or a data missing error depending on the nature of the failure;
- for mobile terminated short message the mobile subscriber is identified either by the IMSI only or by the IMSI accompanied by the LMSI. The subscriber identity information that may be included in the MAP_OPEN indication primitive and in the MAP service indication primitive is checked by the macro "Check_Subscr_Identity_For_MT_SMS". In the first case, the IMSI is included in the sm-RP-DA information field and the Destination Reference must not be present in the MAP_OPEN primitive. In the latter case the IMSI must be obtained from the Destination Reference of the MAP_OPEN indication primitive and an LMSI must be present in the sm-RP-DA information field of the MAP_SEND_INFO_FOR_MT_SMS indication. If the mobile subscriber is unknown, the unidentified subscriber error is returned;
- if the "Confirmed by HLR" indicator is set to "Not Confirmed", the unidentified subscriber error is returned;
- if the IMSI Detached Flag is set to detached or the LA Not Allowed Flag is set to not allowed in the VLR, an absent subscriber error with the diagnostic indication set to 'IMSI Detached' is returned and the MS not reachable flag (MNRF) is set;
- if the MAP_SEND_INFO_FOR_MT_SMS indication has passed all the tests, the VLR will initiate the paging procedure. If the location area identification is known and the "Confirmed by Radio Contact" indicator is set to "Confirmed", the MAP_PAGE service is used. Otherwise the MAP_SEARCH_FOR_MOBILE_SUBSCRIBER service is started.

The following responses to the paging procedure may be received from the MSC:

- the MAP_SEARCH_FOR_MOBILE_SUBSCRIBER confirmation indicating a successful outcome, if the search procedure is used. After that the VLR awaits the MAP_PROCESS_ACCESS_REQUEST indication from the MSC;
- the MAP_PAGE confirmation or MAP_SEARCH_FOR_MOBILE_SUBSCRIBER confirmation indicating unsuccessful outcome. If an absent subscriber error is received, the MS not reachable flag (MNRF) is set in the VLR. The errors are forwarded to the MSC in the MAP_SEND_INFO_FOR_MT_SMS response, the absent subscriber error is forwarded with the diagnostic indication set to 'No Paging Response for non GPRS'. If the unexpected data value, or unknown location area error is received, the system failure indication is given to the MSC; if subscriber busy for MT SMS is received, this cause is given to the MSC.
- the MAP_PROCESS_ACCESS_REQUEST indication telling that the outcome of the service MAP_PAGE is successful.

If the paging procedure or process access request procedure or any other procedure invoked fails, the appropriate error is reported to the MSC.

If the process access request procedure is successful, the VLR will send the MAP_SEND_INFO_FOR_MT_SMS response to the MSC and the transaction is terminated in the VLR.

The mobile terminated short message transfer procedure in the VLR is shown in figure 23.3/5.




Figure 23.3/5 (sheet 1 of 3): Process MT_SM_VLR

Process MT_SM_VLR

23.3_5.2(3)

Figure 23.3/5: The mobile terminated short message service process in the VLR




Figure 23.3/5 (sheet 2 of 3): Process MT_SM_VLR




Figure 23.3/5 (sheet 3 to 3): Process MT_SM_VLR

23.3.3 Procedures in the HLR

The MAP_SEND_ROUTING_INFO_FOR_SM indication is received from the GMSC. The following error cases are reported to the GMSC in the MAP_SEND_ROUTING_INFO_FOR_SM response as an unsuccessful outcome of the procedure:

- if the necessary parameters and data are not present in the primitive or they are badly formatted, the data missing or unexpected data value error is returned;
- if the mobile subscriber is unknown, i.e. it cannot be identified from the MSISDN given, an unknown subscriber error is returned;
- if the short message transfer would contravene operator determined barring, the call barred error with cause operator barring is returned;
- if the short message transfer would contravene the « SM filtering by the HPLMN » function criteria, the call barred error with cause unauthorised Message Originator is returned (the definition of the filtering function is out of the scope of GSM specification. Filtering may be based on SM-RP-SMEA information element if received from the GMSC) ;
- if the mobile subscription identified by the given MSISDN number does not include the short message service, the teleservice not provisioned error is returned;
- if the GMSC does not support the GPRS functionality, the behaviour of the HLR depends on the following conditions:
 - If the subscriber is not a GPRS subscriber then the behaviour of the HLR shall be the same as for a subscriber only registered as non GPRS and for SMS delivery.
 - If the subscriber is a GPRS subscriber and a non-GPRS subscriber with the option « transfer of SM via the MSC when GPRS is not supported in the GMSC » then the behaviour of the HLR shall be the same as for a subscriber only registered as non GPRS and for SMS delivery.
 - If the subscriber is a GPRS subscriber and a non-GPRS subscriber with the option « transfer of SM via the SGSN when GPRS is not supported in the GMSC » or if the subscriber is a GPRS subscriber only then the behaviour of the HLR shall be the same as for the case transfer over GPRS described in MAP release 97, with the following precision : because GMSC does not support MAP release 97, the previous MAP protocol release is used. When the HLR sends the MAP_SEND_ROUTING_INFO_FOR_SM_Resp, the SGSN number is mapped to the MAP parameter « MSC number ». When the HLR sends the MAP_INFORM_SERVICE_CENTRE_resp, the MNRG status shall be mapped to the MAP parameter « mnrf-set ».

The HLR may send the MSC, SGSN or both numbers as routing information to SMS-GMSC based on the following:

- A) The subscriber may only be registered as non GPRS and for SMS delivery:

- if the short message transfer would contravene the supplementary service barring, the call barred error with cause barring service active is returned;
- if the location registration of the mobile subscriber shows that the VLR in the visited PLMN does not support the MT short message service, the facility not supported error is returned;
- if no MSC identity is stored for the mobile subscriber or the "MSC Area Restricted Flag" is set or the "MS purged for non GPRS" flag is set, i.e. the MS is not reachable, the MSISDN-Alert and the SC address are included in the MWD (if possible), the flag MNRF is set and the "Absent Subscriber_SM" error is returned with the appropriate absent subscriber diagnostic indication, i.e. 'Deregistered in HLR for non GPRS ', 'Roaming Restricted' or 'MS-Purged for non GPRS '.

The priority parameter (SM_RP_PRI) is processed as follows:

- if the priority is low (SM_RP_PRI = False) and the mobile station not reachable flag (MNRF) is set, an absent subscriber_SM error is returned. If a reason for the subscriber's absence for non GPRS is stored in the mobile not reachable reason (MNRR) in the subscriber data, then this is returned with the absent subscriber_SM error. The SC-address given in the request will be included in the MWD if possible. The service MAP_INFORM_SERVICE_CENTRE including the parameter MW Status is invoked to indicate whether or not the SC address has been included in the MWD list.
- if the priority is low (SM_RP_PRI = False), and the MNRF is clear, the routing information with MSC number is retrieved as described below;
- if the priority is high (SM_RP_PRI = True) and the MNRF is set, the HLR will send the acknowledge primitive containing the routing information with MSC number to the gateway MSC. In addition the service MAP_INFORM_SERVICE_CENTRE including the parameter MW Status is invoked to indicate whether or not the SC address is already included in the MWD list.

B) The subscriber may only be registered as GPRS and for SMS delivery:

- if the location registration of the mobile subscriber shows that the SGSN in the visited PLMN does not support the MT short message service, the facility not supported error is returned;
- if no SGSN identity is stored for the mobile subscriber or the "SGSN Area Restricted Flag" is set or the "MS purged for GPRS" flag is set, i.e. the MS is not reachable, the MSISDN-Alert and the SC address are included in the MWD (if possible), the flag MNRG is set and the "Absent Subscriber_SM" error is returned with the appropriate absent subscriber diagnostic indication, i.e. 'Deregistered in HLR for GPRS', 'Roaming Restricted' or 'MS-Purged for GPRS' .

The priority parameter (SM_RP_PRI) is processed as follows:

- if the priority is low (SM_RP_PRI = False) and the mobile station not reachable for GPRS (MNRG) flag is set, an absent subscriber_SM error is returned. If a reason for the subscriber's absence for GPRS is stored in the mobile not reachable reason (MNRR) in the subscriber data, then this is returned with the absent subscriber_SM error. The SC-address given in the request will be included in the MWD if possible. The service MAP_INFORM_SERVICE_CENTRE including the parameter MW Status is invoked to indicate whether or not the SC address has been included in the MWD list.
- if the priority is low (SM_RP_PRI = False), and the MNRG is clear, the routing information with SGSN number is retrieved as described below;
- if the priority is high (SM_RP_PRI = True) and the MNRG is set, the HLR will send the acknowledge primitive containing the routing information with SGSN number to the gateway MSC. In addition the service MAP_INFORM_SERVICE_CENTRE including the parameter MW Status is invoked to indicate whether or not the SC address is already included in the MWD list.

C) The subscriber may be registered as non GPRS and GPRS and for SMS Delivery:

- if the short message transfer would contravene the supplementary service barring, the behaviour is the same as for a subscriber only registered for GPRS and SMS delivery.
- if the location registration of the mobile subscriber shows that the VLR in the visited PLMN does not support the MT short message service, the behaviour is the same as for a subscriber only registered for GPRS and SMS delivery;
- if the location registration of the mobile subscriber shows that the SGSN in the visited PLMN does not support the MT short message service, the behaviour is the same as for a subscriber only registered for non GPRS and SMS delivery;
- if no MSC and SGSN identities are stored for the mobile subscriber or the "MSC and SGSN Area Restricted Flags" are set or the "MS purged for non GPRS and GPRS" flags are set or a combination of these errors for non GPRS and GPRS are used, i.e. the MS is not reachable, the MSISDN-Alert and the SC address are included in the MWD (if possible), the flags MNRF and MNRG are set and the "Absent Subscriber_SM" error is returned with the appropriate absent subscriber diagnostic indication, i.e. 'Deregistered in HLR for non GPRS or GPRS', 'Roaming Restricted', 'MS-Purged for non GPRS or GPRS' or both.

The priority parameter (SM_RP_PRI) is processed as follows:

- if the priority is low (SM_RP_PRI = False), the MNRF and MNRG are set, an absent subscriber_SM error is returned. If reasons for the subscriber's absence for non GPRS and GPRS are stored in MNRR in the subscriber data, then this is returned with the absent subscriber_SM error. The SC-address given in the request will be included in the MWD if possible. The service MAP_INFORM_SERVICE_CENTRE including the parameter MW Status is invoked to indicate whether or not the SC address has been included in the MWD list.
- if the priority is low (SM_RP_PRI = False), and the MNRF is clear and MNRG is set, the routing information with MSC number is retrieved as described below;
- if the priority is low (SM_RP_PRI = False), and the MNRF is set and MNRG is clear, the routing information with SGSN number is retrieved as described below
- if the priority is low (SM_RP_PRI = False), and the MNRF and MNRG are clear, the routing information with MSC and SGSN numbers is retrieved as described below;
- if the priority is high (SM_RP_PRI = True) and the MNRF, the MNRG or both are set, the HLR will send the acknowledge primitive containing the routing information with both MSC and SGSN numbers to the gateway MSC. In addition the service MAP_INFORM_SERVICE_CENTRE including the parameter MW Status is invoked to indicate whether or not the SC address is already included in the MWD list.

If the MSISDN-Alert number of the mobile subscriber stored in the MWD is not the same as that received in the MAP_SEND_ROUTING_INFO_FOR_SM indication, the HLR will include in the MAP_INFORM_SERVICE_CENTRE request to the GMSC the MSISDN-Alert number stored.

The MAP_INFORM_SERVICE_CENTRE request is sent also when the MCEF, MNRF, MNRG or both are set but the routing information is still sent to the GMSC. The status of the flags is indicated in the parameter MW Status.

The routing information is included in a MAP_SEND_ROUTING_INFO_FOR_SM response as follows:

- the IMSI will be returned to the GMSC together with the MSC, SGSN or both numbers and may be optionally accompanied by the LMSI.
- an indication specifying which number belongs the MSC and the SGSN will be returned to the GMSC.

LMSI shall not be used in case only the SGSN number is sent by HLR.

The mobile terminated short message transfer procedure in the HLR is shown in figure 23.3/6.




Figure 23.3/6 (sheet 1 of 5): Process Mobile_terminated_SM_HLR




Figure 23.3/6 (sheet 2 of 5): Process Mobile_terminated_SM_HLR




Figure 23.3/6 (sheet 3 of 5): Process Mobile_terminated_SM_HLR





Figure 23.3/6 (sheet 4 of 5): Process Mobile_terminated_SM_HLR

**Figure 23.3/6 (sheet 5 of 5): Process Mobile_terminated_SM_HLR**




Figure 23.3/11: Procedure Select_Transfer_Nodes

23.3.4 Procedures in the gateway MSC

The short message handling function of the GMSC will request routing information when a mobile terminated short message is received from a Service Centre. The GMSC sends the MAP_SEND_ROUTING_INFO_FOR_SM request to the HLR containing the subscriber data of the mobile subscriber and the indication that the SMS-GMSC supports the GPRS functionality.

As an outcome of the procedure the MAP_SEND_ROUTING_INFO_FOR_SM confirmation is received indicating:

- an unsuccessful event indication containing an error;

The mapping between the MAP error causes and the RP_ERROR causes is explained in TS GSM 03.40.

- a successful event indication containing following parameters:
 - an IMSI optionally accompanied by an LMSI; and
 - routing addresses (servicing MSC, SGSN or both numbers).

The LMSI shall not be used in case the short message is routed towards the SGSN.

The GMSC may also receive a MAP_INFORM_SERVICE_CENTRE indication after the MAP_SEND_ROUTING_INFO_FOR_SM confirmation. The parameter MW Status in the message indicates whether or not the Service Centre address is stored in the Message Waiting Data. It also indicates the status of the MCEF, MNRF and MNRG flags in the HLR.

If the MSISDN-Alert stored in the MWD data is not the same as the one sent to the HLR, the MSISDN-Alert is received in the MAP_INFORM_SERVICE_CENTRE indication. This MSISDN number shall be transferred in a delivery failure report to the SC.

In the abnormal end or in the provider error case the system failure error is provided to the SC.

The forward short message procedure is initiated when the GMSC has obtained the routing information needed to forward a mobile terminated short message to the servicing MSC or SGSN.

If both numbers MSC and SGSN are received from HLR as routing information, the SMS-GMSC may choose which path (SGSN or MSC) first the SMS is to be transferred.

If an LMSI has been provided in the MAP_SEND_ROUTING_INFO_FOR_SM confirmation, it can be included in the sm-RP-DA information field of the first MAP_MT_FORWARD_SHORT_MESSAGE request sent to the servicing MSC. In this case, the IMSI must be included in the Destination Reference of the MAP_OPEN request. If the LMSI is not sent by the SMS Gateway MSC, the sm-RP-DA information field in the first MAP_MT_FORWARD_SHORT_MESSAGE request sent to the servicing MSC or SGSN shall contain the IMSI and the Destination Reference in the MAP_OPEN request shall not be present. The Service Centre address is sent in the parameter SM_RP_OA. The More Messages To Send flag is set to TRUE or FALSE depending on the information received from the Service Centre.

If the GMSC is the servicing MSC then the MAP service is not initiated. The procedure in the Servicing MSC is described in subclause 23.3.1 and in the figure 23.3/4.

If the grouping of MAP_OPEN request and MAP_MT_FORWARD_SHORT_MESSAGE request together would need segmenting, these primitives must not be grouped together. The MAP_OPEN request primitive is sent first without any associated MAP service request primitive and the dialogue confirmation must be received before the MAP_MT_FORWARD_SHORT_MESSAGE request is sent.

As a response to the procedure, the GMSC will receive the MAP_MT_FORWARD_SHORT_MESSAGE confirmation indicating:

- a successful forwarding of the short message. This indication is passed to the SC;
- unsuccessful forwarding of the short message;

In case only one number (MSC or SGSN) was received from HLR as routing information, the mapping of the MAP error causes and the RP_ERROR causes is explained in TS GSM 03.40. The appropriate error indication is sent to the SC.

In case both numbers (MSC and SGSN) were received from HLR as routing information, the transfer of SMS is re-attempted towards the second path only when one of the following errors is received from the unsuccessful transfer over the first path:

Facility Not Supported

Unidentified Subscriber

Absent Subscriber with indication: GPRS or IMSI Detach

Unexpected Data Value

System failure

Data Missing

Subscriber Busy for MT SMS: GPRS Connection Suspended,

otherwise, the mapping of the MAP error causes and the RP_ERROR causes is performed (see TS GSM 03.40) and the appropriate error indication is sent to the SC.

If second forwarding of short message is unsuccessful, the mapping of the MAP error causes and the RP_ERROR causes is explained in TS GSM 03.40. The appropriate error indications are sent to the SC.

If second forwarding of short message is successful, the successful indication is passed to the SC.

A provider error is indicated as a system failure error to the SC.

The GMSC invokes the procedure MAP_REPORT_SM_DELIVERY_STATUS, if an absent subscriber_SM, an unidentified subscriber or SM delivery failure with error cause MS memory capacity exceeded indication is received from the servicing MSC, SGSN or both, and the corresponding flags received in the MAP_INFORM_SC are not already set or the SC address is not yet included in the MWD set.

If absent subscriber diagnostic information (see GSM 03.40) is included with the absent subscriber_SM error indication then this information is relayed to the HLR using the procedure MAP_REPORT_SM_DELIVERY_STATUS.

In case the SMS was attempted to be delivered towards the MSC and the SGSN, and both delivery failed with causes described above, the two unsuccessful SMS delivery outcomes for GPRS and non GPRS are sent to the HLR.

In case the SMS was attempted to be delivered towards the MSC and the SGSN, and the first delivery failed with causes described above and the second delivery succeeded, the unsuccessful and successful SMS delivery outcomes for GPRS and non GPRS are sent to HLR.

The gateway MSC may also invoke the procedure when the first SMS delivery was successful towards MSC, if the MNRF, MCEF flags or both were set in the HLR.

The gateway MSC may also invoke the procedure when the first SMS delivery was successful towards SGSN, if the MNRG, MCEF flags or both were set in the HLR.

This procedure is described in detail in subclause 23.5.

Unexpected data value, system failure errors are indicated as a system failure to the SC. Other errors are indicated using appropriate cause values and diagnostic information between the GMSC and the SC as described in TS GSM 03.40 and GSM 04.11.

The unidentified subscriber error is indicated to the SC as absent subscriber with diagnostic information set to 'Unidentified subscriber' as described in TS GSM 03.40.

Note that the indication, on which number belongs the SGSN and MSC, received from the HLR at routing information result (see subclause 23.3.3) will enable the GMSC to map the causes received from the SGSN, MSC or both into the appropriate causes for non GPRS, GPRS or both, and send them to the SC and HLR.

If there are more short messages to send in the Service Centre and the previous short message transfer succeeded, then the gateway MSC awaits the next short message.

When receiving the next short message from the SC, the gateway MSC sets the More Messages To Send flag according to the information received and starts the service MAP_MT_FORWARD_SHORT_MESSAGE again.

If the gateway MSC is the servicing MSC, then the short message transfer to mobile subscriber is started as described in the subclause 23.3.1.

The mobile terminated short message transfer procedure in the gateway MSC is shown in figure 23.3/7.




Figure 23.3/7 (sheet 1 of 6): Procedure MT_SM_GMSC





Figure 23.3/7 (sheet 2 to 6): Procedure MT_SM_GMSC

**Figure 23.3/7 (sheet 3 of 6): Procedure MT_SM_GMSC**




Figure 23.3/7 (sheet 4 of 6): Procedure_MT_SM_GMSC




Figure 23.3/7 (sheet 5 to 6): Procedure MT_SM_GMSC




Figure 23.3/7 (sheet 6 of 6): Procedure MT_SM_GMSC

Macrodefinition Check_Subscr_Identity_For_MT_SMS

23.3_8(1)

Figure 23.3/8: Check of the subscriber identity for a mobile terminated short message in the servicing MSC and in the VLR




Figure 23.3/8: Macro Check_Subscr_Identity_For_MT_SMS

23.3.5 Procedure in the Servicing SGSN

When initiating the dialogue with the servicing SGSN, the SMS Gateway MSC must provide the IMSI of the subscriber to whom the short message is directed.

The IMSI is included in the sm-RP-DA information field of the MAP_MT_FORWARD_SHORT_MESSAGE indication.

When receiving a MAP_OPEN indication primitive that is not associated with any MAP service indication primitive and if the dialogue is accepted, the MAP service-user in the servicing SGSN issues a MAP_DELIMITER request primitive in order to trigger the local MAP service-provider to confirm the dialogue.

When receiving the first MAP_MT_FORWARD_SHORT_MESSAGE indication from the gateway MSC, the servicing SGSN performs some subscriber data checks, if the MAP service primitive is accepted and if short message service is supported in the servicing SGSN.

The MAP_MT_FORWARD_SHORT_MESSAGE indication primitive is checked by the macro "Check_Indication". If the received MAP service primitive contains errors, the service is aborted and an unexpected data value error or data missing error is returned to the GMSC.

If the SGSN does not support the short message service, the service is aborted in the servicing SGSN and the error "Facility Not Supported" is returned to the GMSC.

If the connection is GPRS suspended, the SGSN sends to the GMSC an error specifying that the GPRS connection is suspended.

The subscriber identity information that are included in the MAP service indication primitive is checked by the macro "Check_Subscr_Identity_For_MT_SMS" as follows:

If the IMSI is included in the sm-RP-DA information field of the MAP_MT_FORWARD_SHORT_MESSAGE indication, the MAP_OPEN indication received from the gateway MSC shall not include a Destination Reference.

If no Destination Reference has been received and the sm-RP-DA information field does not cover an IMSI the service is aborted in the servicing SGSN and the error "Unexpected Data Value" is returned to the GMSC.

The following outcomes from the subscriber data checks can occur in SGSN:

- if the mobile subscriber is unknown, the unidentified subscriber error is forwarded to the GMSC;
- if the "Confirmed by HLR" indicator is set to "Not Confirmed", the unidentified subscriber error is forwarded to the GMSC.
- if the GPRS Detached Flag is set to detached or the LA Not Allowed Flag is set to not allowed in the SGSN, an absent subscriber error with the diagnostic indication set to 'GPRS Detached' is forwarded to the GMSC and the MS not reachable for GPRS (MNRG) flag is set;
- If the location area identification is known and the "Confirmed by Radio Contact" indicator is set to "Confirmed", the paging procedure is invoked (see subclause 25.3).Otherwise the search procedure is invoked (see subclause 25.3).

The result of the paging or the search procedure is processed as follows:

- if the procedure is completed successfully, the SGSN may trigger the Authentication, Ciphering and IMEI check procedures (see subclauses 25.4 and 25.5). Then, if the procedure are completed successfully, the SGSN will send the short message to the MS;
- if the procedure is completed successfully, but the MS has no mobile terminated short message transfer capability, the SM delivery failure indication with cause "equipment not SM equipped" is provided to the GMSC;
- if the procedure is ended unsuccessfully because of subscriber already busy for SMS, another paging, emergency call, location updating, inter SGSN routing area update or a call set-up, the subscriber busy for MT SMS is provided to the GMSC.

- if the procedure is ended unsuccessfully, the absent subscriber_SM error is forwarded to the GMSC with the absent subscriber diagnostic indication set to 'No Paging Response for GPRS', but if the location area is unknown, the system failure indication is provided to the GMSC.

If forwarding of the short message is initiated, the SGSN awaits the result before one of the following responses is sent back to the GMSC:

- an acknowledge if the short message has been successfully delivered to the mobile subscriber;
- an SM delivery failure error containing a parameter indicating either of the following: there is a MS protocol error or the MS memory capacity is exceeded; detailed diagnostic information (see subclause 7.6.1.4) may also be carried;
- a system failure error if the delivery procedure is aborted.

If the More Messages To Send flag was FALSE or the service MAP_MT_FORWARD_SHORT_MESSAGE ends unsuccessfully, the transaction to the gateway MSC is terminated. Otherwise, the servicing SGSN waits for the next short message from the Service Centre.

When receiving the next MAP_MT_FORWARD_SHORT_MESSAGE indication from the gateway MSC the servicing MSC will act as follows:

- if the received primitive contains errors, the unexpected data value error or data missing error is provided to the gateway MSC;
- if the More Messages To Send flag is FALSE, the servicing SGSN will start the short message transfer procedure to the mobile subscriber. The successful or unsuccessful outcome of this procedure is reported to the gateway MSC and the transaction is terminated.
- if the More Messages To Send flag is TRUE, the servicing SGSN will start the short message transfer to the mobile subscriber. If the outcome of this procedure is unsuccessful, the reason is reported to the gateway MSC and the procedure is terminated. If the procedure is successful, it is acknowledged to the gateway MSC and more short messages can be received.

The mobile terminated short message transfer procedure in the servicing SGSN is shown in figures 23.3/9 and 23.3/10. The page and search procedures are shown in figure 25.3/1 and 25.3/2.




Figure 23.3/9 (sheet 1 of 3): Procedure MT_SM_Transfer_SGSN

Process MT_SM_Transfer_SGSN

23.3_9.2(3)

Figure 23.3/9: The mobile terminated short message service process in the SGSN




Figure 23.3/9 (sheet 2 of 3): Procedure MT_SM_Transfer_SGSN

Process MT_SM_Transfer_SGSN

23.3_9.3(3)

Figure 23.3/9: The mobile terminated short message service process in the SGSN




Figure 23.3/9 (sheet 3 of 3): Procedure MT_SM_Transfer_SGSN




Figure 23.3/10 (sheet 1 of 3): Macro MT_SM_SGSN

Macrodefinition MT_SM_SGSN

23.3_10.2(3)

Figure 23.3/10: The mobile terminated short message transfer macro in the SGSN




Figure 23.3/10 (sheet 2 of 3): Macro MT_SM_SGSN

Macrodefinition MT_SM_SGSN

23.3_10.3(3)

Figure 23.3/10: The mobile terminated short message transfer macro in the SGSN





Figure 23.3/10 (sheet 3 of 3): Macro MT_SM_SGSN

23.4 The Short Message Alert procedure

The Short Message Alert procedure is used for alerting the Service Centre when the mobile subscriber is active after a short message transfer has failed because the mobile subscriber is not reachable or when the MS has indicated that it has memory capacity to accept a short message.

The Short Message Alert procedure for the case when the mobile subscriber was not reachable is shown in figure 23.4/1.



- NOTE 1: To all Service Centres in the Message Waiting List.
 NOTE 2: The HLR initiates the MAP_ALERT_SERVICE_CENTRE service only if the MS Memory Capacity Exceeded flag is clear.
 (*) In case of GPRS, messages 3) and 4) are sent/received by SGSN.
 (**) Those messages are not used by SGSN.

Figure 23.4/1: Short message alert procedure (Mobile is present)

The Short Message Alert procedure for the case where the MS indicates that it has memory capacity to accept one or more short messages is shown in figure 23.4/2.





Figure 23.4/2: Short message alert procedure (MS memory capacity available)

In addition the following MAP services are used in the MS memory available case:

MAP_PROCESS_ACCESS_REQUEST	(see subclause 8.3); (*)
MAP_AUTHENTICATE	(see subclause 8.5); (*)
MAP_SET_CIPHERING_MODE	(see subclause 8.6); (*)
MAP_PROVIDE_IMSI	(see subclause 8.9); (*)
MAP_CHECK_IMEI	(see subclause 8.7);
MAP_FORWARD_NEW_TMSI	(see subclause 8.9); (*)
MAP_TRACE_SUBSCRIBER_ACTIVITY	(see subclause 9.1). (*)

(*) Those messages are not used by SGSN.

The Short Message Alert procedure when the MS indicates successful transfer after polling is shown in figure 23.4/3.



- 1) MAP_REPORT_SM_DELIVERY_STATUS (Successful Transfer).
- 2) MAP_REPORT_SM_DELIVERY_STATUS_ACK.
- 3) MAP_ALERT_SERVICE_CENTRE (note).
- 4) Alert Service Centre (GSM 03.40).
- 5) MAP_ALERT_SERVICE_CENTRE_ACK.

NOTE: To all Service Centres in the Message Waiting List.

Figure 23.4/3: Short message alert procedure (Successful transfer after polling)

23.4.1 Procedures in the Servicing MSC

The activation of the MAP_PROCESS_ACCESS_REQUEST service is described in the subclause 23.6.2.

After receiving the SM memory capacity available indication, the servicing MSC sends the MAP_READY_FOR_SM request to the VLR indicating memory available. The outcome of that procedure is one of the following:

- successful acknowledgment. The MSC sends the corresponding message to the MS;
- negative acknowledgment, where the error causes are treated as follows:
 - unexpected data value, data missing and system failure errors are reported as network out of order error to the MS;
 - facility not supported is reported as requested facility not implemented error to the MS;
- procedure failure, which is reported as network out of order error to the MS if a connection to the MS still exists.

The short message alert procedure in the MSC for the MS memory capacity available case is shown in figure 23.4/4.




Figure 23.4/4: Procedure SM_Alert_MSC

23.4.2 Procedures in the VLR

23.4.2.1 The Mobile Subscriber is present

When receiving the MAP_PROCESS_ACCESS_REQUEST indication, MAP_UPDATE_LOCATION_AREA indication while the MS not reachable flag (MNRF) is set, the VLR will send the MAP_READY_FOR_SM request towards the HLR. The Alert Reason is set to indicate that the mobile subscriber is present for non GPRS. If the authentication procedure is initiated and it fails, the VLR will not initiate the service. The process in VLR is described in detail in the subclause 25.10.

23.4.2.2 The Mobile Equipment has memory available

The MAP_PROCESS_ACCESS_REQUEST indication starts the MAP_PROCESS_ACCESS_REQUEST service in the VLR. The application context in the MAP_OPEN indication refers to the short message alerting procedure.

If the service MAP_PROCESS_ACCESS_REQUEST is successful, the VLR waits for the next message from the MSC. When receiving the MAP_READY_FOR_SM indication from the MSC, the VLR will check the contents. Data errors are reported to the MSC as an unexpected data value or data missing error, depending on the error. If the primitive passes the data check, the VLR forwards it to the HLR and awaits an acknowledgment.

When receiving the MAP_READY_FOR_SM confirmation from the HLR and the Alert Reason is MS memory available, the VLR will act as follows:

- the MAP_READY_FOR_SM response is sent to the MSC as follows:
 - an acknowledge in the positive case;
 - system failure error, if unexpected data value, data missing, or unknown subscriber errors are received, otherwise the error cause received from the HLR;
 - a facility not supported error, if the HLR supports MAP Vr only;
 - procedure failure is reported as a system failure error.

The short message alert procedure in the VLR is shown in figures 23.4/5.




Figure 23.4/5: Procedure SM_Alert_VLR

23.4.3 Procedures in the HLR

When receiving the MAP_READY_FOR_SM indication, the HLR will check the contents. Data errors are reported to the VLR as an unexpected data value or a data missing error depending on the error. If the HLR does not support the MNRF or MNRG, MCEF, and MWD a facility not supported error is reported to the VLR or SGSN. If the IMSI is unknown an unknown subscriber error is reported to the VLR or SGSN. Otherwise an acknowledgement is returned to the VLR or SGSN.

If neither the MS not reachable flag (MNRF) or the MS not reachable for GPRS (MNRG) flag, nor the memory capacity exceeded flag (MCEF) are set, and MAP_READY_FOR_SM is received from the VLR or SGSN, the HLR sets a timer and waits for it to expire. This ensures that in the race situation the MAP_REPORT_SM_DELIVERY_STATUS service (as described in the subclause 23.6) for the same subscriber can be carried out when delayed in the GMSC.

If the Alert Reason indicates the mobile present for non GPRS situation, or when the update location procedure has been successfully completed or Supplementary Service Control request is received, the MS not reachable flag (MNRF) is cleared and the service centre alert procedure is initiated. If the memory capacity exceeded flag is set, the MS not reachable flag is cleared and stored reason for absence for non GPRS are cleared but the alert procedure is not started.

If the Alert Reason indicates the mobile present for GPRS situation, or when the Update GPRSlocation procedure has been successfully completed, the MS not reachable for GPRS (MNRG) flag is cleared and the service centre alert procedure is initiated. If the memory capacity exceeded flag is set, the MS detach for GPRS flag is cleared and stored reason for absence for GPRS are cleared but the alert procedure is not started.

If the Alert Reason indicates the memory available for non GPRS situation, the HLR initiates the alert procedure. The MS not reachable and memory capacity available flags are cleared.

If the Alert Reason indicates the memory available for GPRS situation, the HLR initiates the alert procedure. The MS detach for GPRS and memory capacity available flags are cleared.

If the MAP_REPORT_SM_DELIVERY_STATUS indication is received and it indicates the successful transfer of the mobile terminated short message for non GPRS, the HLR initiates the alert procedure described in the subclause 25.10 and clears MCEF and MNRF flags and stored reason for absence for non GPRS are cleared.

If the MAP_REPORT_SM_DELIVERY_STATUS indication is received and it indicates the successful transfer of the mobile terminated short message for GPRS, the HLR initiates the alert procedure described in the subclause 25.10 and clears MCEF and MNRG flags and stored reason for absence for GPRS are cleared.

The short message alert procedure in the HLR is shown in figures 23.4/6 and 25.10/2.




Figure 23.4/6 (sheet 1 of 2): Process SM_Alert_HLR

Process SM_Alert_HLR

23.4_6.2(2)

Figure 23.4/6:
The short
message alert
process in the HLR




Figure 23.4/6 (sheet 2 of 2): Process SM_Alert_HLR

23.4.4 Procedures in the Interworking MSC

When a MAP_ALERT_SERVICE_CENTRE indication is correctly received by the IWMSC, the IWMSC will forward the alerting to the given Service Centre if possible.

Data errors are reported to the HLR as an unexpected data value or a data missing error depending on the error.

The short message alert procedure is shown in figure 23.4/7.

Process Alert_SC_IWMSC

23.4_7(1)

Figure 23.4/7: The short message alert message in the IWMSC




Figure 23.4/7: Process Alert_SC_IWMSC

23.4.5 Procedures in the Servicing SGSN

23.4.5.1 The Mobile Subscriber is present

When receiving Page response, Attach request or Routing area update request messages (TS GSM 04.08), while the MS not reachable for GPRS (MNRG) flag is set, the SGSN will send the MAP_READY_FOR_SM request towards the HLR. The Alert Reason is set to indicate that the mobile subscriber is present for GPRS.

When receiving the answer, the SGSN will act as follows:

- MNRG is cleared if the procedure is successful
- MNRG is not cleared if the procedure is not successful

The process in SGSN is described in detail in the subclause 25.10/3.

23.4.5.2 The Mobile Equipment has memory available

After receiving the SM memory capacity available indication, the servicing SGSN sends the MAP_READY_FOR_SM request to the HLR indicating memory available for GPRS. The outcome of that procedure is one of the following:

- successful acknowledgment. The SGSN sends the corresponding message to the MS;
- negative acknowledgment, where the error causes are treated as follows:
 - unexpected data value, data missing and system failure errors are reported as network out of order error to the MS;
 - facility not supported is reported as requested facility not implemented error to the MS;
- procedure failure, which is reported as network out of order error to the MS if a connection to the MS still exists.

The short message alert procedure in the SGSN for the MS memory capacity available case is shown in figure 23.4/8.




Figure 23.4/8: Process Subscriber_Present_SGSN

23.5 The SM delivery status report procedure

The SM delivery status report procedure is used to set the Service Centre address into the message waiting list in the HLR because the subscriber is absent or unidentified or the memory capacity is exceeded. The procedure sets

- the memory capacity exceeded flag in the HLR if the MS memory does not have room for more messages
- and/or the MS not reachable flag for non GPRS in the case of unidentified or absent subscriber
- and/or the MS not reachable for GPRS flag in the case of unidentified or absent subscriber for GPRS

Additionally the procedure is used to report the HLR about the successful transfer for GPRS or non GPRS after the Service Centre has polled the subscriber. This procedure is described also in the subclause 23.4.

The SM delivery status report procedure is shown in figure 23.5/1.




Figure 23.5/1: Short message delivery status report procedure

23.5.1 Procedures in the HLR

When the HLR receives a MAP_REPORT_SM_DELIVERY_STATUS indication, it acts as described in the subclause 23.6, macro Report_SM_Delivery_Stat_HLR.

The short message delivery status report process in the HLR is shown in figure 23.5/2.

Process SM_Delivery_Status_Report_HLR

23.5_2(1)

Figure 23.5/2: The report SM delivery process in the HLR




Fig. 23.6/1

Figure 23.5/2: Process SM_Delivery_Status_Report_HLR

23.5.2 Procedures in the gateway MSC

The GMSC invokes the short message delivery status report procedure if an absent subscriber_SM indication, unidentified subscriber indication, SM delivery failure error indicating MS memory capacity exceeded or both are received from the servicing MSC, SGSN or both during a mobile terminated short message transfer, and the HLR has not indicated that the SC address is included in the MWD. The unidentified subscriber indication is however processed as the absent subscriber_SM indication

In case of successful SMS delivery on the second path, the successful SMS Delivery outcome is sent in combination with the unsuccessful SMS Delivery outcome to the HLR.

The service is invoked also when the HLR has indicated that either of the flags MCEF, MNRF or both are set and the first SM delivery was successful from the servicing MSC or, in case of subsequent SM, the last SM delivery was successful from the servicing MSC.

The service is invoked also when the HLR has indicated that either of the flags MCEF, MNRF or both are set and the SM delivery was successful from the servicing SGSN or, in case of subsequent SM, the last SM delivery was successful from the servicing SGSN.

The reason for unsuccessful, successful for GPRS, non GPRS or both deliveries of the short message are included in the SM Delivery Outcome in the MAP_REPORT_SM_DELIVERY_STATUS request. In the case of an unsuccessful delivery due to the subscriber being absent the absent subscriber diagnostic indication (if available) is also included in the MAP_REPORT_SM_DELIVERY_STATUS request.

If the reason for unsuccessful delivery is absent subscriber with diagnostic 'Paging failure' for GPRS or non GPRS, the two SM Delivery Outcomes absent subscriber with both diagnostics 'Paging failure' for GPRS and non GPRS is included in the MAP_REPORT_SM_DELIVERY_STATUS request.

The GMSC sends the MAP_REPORT_SM_DELIVERY_STATUS request to the HLR. As a response the GMSC will receive the MAP_REPORT_SM_DELIVERY_STATUS confirmation reporting:

- successful outcome of the procedure. The acknowledge primitive may contain the MSISDN-Alert number which is stored in the MWD List in the HLR;
- unsuccessful outcome of the procedure. The system failure indication is forwarded to the SC. In that case, if the SM Delivery Outcome was successful SMS delivery for GPRS or non GPRS (combined or not with another unsuccessful reason), a successful report is forwarded to the SC.

A provider error is indicated as a system failure to the SC.

Note that the indication, on which number belongs the SGSN and MSC, received from the HLR at routing information result (see subclause 23.3.3) will enable the GMSC to map the causes received from the SGSN, MSC or both into the appropriate causes for GPRS, non GPRS or both, and send them to the SC and HLR.

The procedure towards the Service Centre may also be aborted. If so the operation towards the HLR is also aborted.

The short message delivery status report procedure in the GMSC is shown in figure 23.5/3.




Figure 23.5/3: Macro Report_SM_Delivery_Stat_GMSC

23.6 Common procedures for the short message clause

23.6.1 The macro Report_SM_Delivery_Stat_HLR

This macro is used when the HLR receives a MAP_REPORT_SM_DELIVERY_STATUS indication from the GMSC. The HLR responses to the indication as follows:

- if the flag « GPRS Support Indicator » is absent then if the subscriber is a GPRS subscriber and a non-GPRS subscriber with the option « transfer of SM via the SGSN when GPRS is not supported in the GMSC » or if the subscriber is a GPRS subscriber only, the HLR shall interpret the delivery outcome as a GPRS delivery outcome.
- if invalid data content is detected, an unexpected data value error or a data missing error is returned to the GMSC;
- if the MSISDN number provided is not recognized by the HLR, an unknown subscriber error is returned to the GMSC;
- if the MAP_REPORT_SM_DELIVERY_STATUS indication reports a successful SM delivery, the Service Centres in the Message Waiting list are alerted as described in the subclause 25.10;
- if the SM Delivery Outcome reports unsuccessful delivery and the inclusion of the SC address in the MWD is not possible, a message waiting list full error is returned to the GMSC;
- if the SM Delivery Outcome reports unsuccessful delivery and the message waiting list is not full, the given Service Centre address is inserted and an acknowledgement is sent to the GMSC. If the MSISDN-Alert stored in the subscriber data is not the same as that received in the MAP_REPORT_SM_DELIVERY_STATUS indication, the MSISDN-Alert is sent in a response primitive to the GMSC;

The SC address is only stored in the MWD if the unsuccessful SM Delivery Outcome is not received in combination with another successful SM Delivery Outcome

- if the SM Delivery Outcome is MS memory capacity exceeded for non GPRS, the HLR sets the memory capacity exceeded flag in the subscriber data and resets the MNRF;
- if the SM Delivery Outcome is MS memory capacity exceeded for GPRS the HLR sets the memory capacity exceeded flag in the subscriber data and resets the MNRG;
- if the SM Delivery Outcome is absent subscriber for non GPRS, the HLR sets the mobile station not reachable flag in the subscriber data. If a reason for absence is provided by the GMSC then this is stored in the mobile station not reachable reason (MNRR) in the subscriber data.
- if the SM Delivery Outcome is absent subscriber for GPRS, the HLR sets the mobile station not reachable for GPRS flag in the subscriber data. If a reason for absence is provided by the GMSC then this is stored in the mobile station not reachable reason (MNRR) in the subscriber data.

Note that a combination of all the SM Delivery Outcome specified above may be provided to the HLR from the SMS-GMSC.

The short message delivery status report macro in the HLR is shown in figure 23.6/1.




Figure 23.6/1: Macro Report_SM_Delivery_Stat_HLR

24 GPRS process description

24.1 General

The MAP GPRS procedures are used for the Network Requested PDP-Context Activation procedures.

The stage 2 specification for General Packet Radio Service (GPRS) is in GSM 03.60 [100].

24.1.1 Process in the HLR for Send Routing Information for GPRS

The MAP process in the HLR to provide routing information for a network-requested PDP context activation is shown in figure 24.1/1. The MAP process invokes a macro not defined in this subclause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Check_Indication see subclause 25.2.1.

Successful outcome

When the MAP process receives a MAP_OPEN indication with the application context gprsLocationInfoRetrieval, it checks it by invoking the macro Receive_Open_Ind.

If the macro takes the OK exit, the MAP process waits for a service indication.

If a MAP_SEND_ROUTING_INFO_FOR_GPRS service indication is received, the HLR sends a Send Routing Info For Gprs request to the GPRS application process in the HLR, and wait for a response. The Send Routing Info For Gprs request contains the parameter received in the MAP_SEND_ROUTING_INFO_FOR_GPRS service indication

If the GPRS application process in the HLR returns a positive response containing the routing information, the MAP process constructs a MAP_SEND_ROUTING_INFO_FOR_GPRS service response containing the routing info, constructs a MAP_CLOSE service request, sends them to the GGSN and returns to the idle state.

Negative response from HLR GPRS application process

If the GPRS application process in the HLR returns a negative response, the MAP process constructs a MAP_SEND_ROUTING_INFO_FOR_GPRS service response containing the appropriate error, constructs a MAP_CLOSE service request, sends them to the GGSN and returns to the idle state.

Failure of dialogue opening with the GGSN

If the macro Receive_Open_Ind takes the Vr exit or the Error exit, the MAP process returns to the idle state.

If the MAP provider sends a MAP_P_ABORT while the MAP process is waiting for a service indication, the MAP process returns to the idle state.

If the MAP provider sends a MAP_NOTICE while the MAP process is waiting for a service indication, the MAP process sends a MAP_CLOSE request to terminate the dialogue and returns to the idle state.




Figure 24.1/1: Process Send Routing Info For Gprs_HLR

24.1.2 Process in the GGSN for Send Routing Information for GPRS

Successful Outcome

When the MAP process receives a Send Routing Info For Gprs request from the GPRS application process in the GGSN, it requests a dialogue with the HLR whose identity is contained in the Send Routing Info For Gprs request by sending a MAP_OPEN service request, requests routeing information using a MAP_SEND_ROUTING_INFO_FOR_GPRS service request and invokes the macro Receive_Open_Cnf to wait for the response to the dialogue opening request. If the dialogue opening is successful, the MAP process waits for a response from the HLR.

If the MAP process receives a MAP_SEND_ROUTING_INFO_FOR_GPRS service confirm from the HLR, the MAP process invokes the macro Check_Confirmation to check the content of the confirm.

If the macro Check_Confirmation takes the OK exit, the MAP process sends a Send Routing Info For Gprs ack containing the routing information received from the HLR to the GPRS application process in the GGSN and returns to the idle state.

Failure of dialogue opening with the HLR

If the macro Receive_Open_Cnf takes the Vr exit or the Error exit, the MAP process sends a negative response to the GPRS application process in the GGSN and returns to the idle state.

Error in MAP_SEND_ROUTING_INFO_FOR_GPRS confirm

If the MAP_SEND_ROUTING_INFO_FOR_GPRS service confirm contains a user error or a provider error, or the macro Check_Confirmation indicates that there is a data error, the MAP process sends a Send Routing Info For Gprs negative response to the GPRS application process in the GGSN and returns to the idle state.

Abort of HLR dialogue

After the dialogue with the HLR has been established, the MAP service provider may abort the dialogue by issuing a MAP_P_ABORT or a MAP_U_ABORT indication. In this case, the MAP process sends a Send Routing Info For Gprs negative response to the GPRS application process in the GGSN and returns to the idle state.

If the MAP provider indicates a protocol problem by sending a MAP_NOTICE indication, the MAP process closes the dialogue with the HLR, sends a Send Routing Info For Gprs negative response indicating system failure to the GPRS application process in the GGSN and returns to the idle state.

Process Send_Routing_Info_For_Gprs_GGSN 24.1_2(1)




Figure 24.1/2: Process Send_Routing_Info_For_Gprs_GGSN

24.2.1 Process in the HLR for Failure Report

The MAP process in the HLR to set the MNRG (Mobile station Not Reachable for GPRS) flag for the subscriber is shown in figure 24.2/1. The MAP process invokes a macro not defined in this subclause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Check Indication see subclause 25.2.1.

Successful outcome

When the MAP process receives a MAP_OPEN indication with the application context failureReport, it checks it by invoking the macro Receive_Open_Ind.

If the macro takes the OK exit, the MAP process waits for a service indication.

If a MAP_FAILURE_REPORT service indication is received, the HLR sends a Failure Report request to the GPRS application process in the HLR, and wait for a response. The Failure Report request contains the parameter received in the MAP_FAILURE_REPORT service indication.

If a positive response is received, the MAP process constructs a MAP_FAILURE_REPORT service response, constructs a MAP_CLOSE service request, sends them to the GGSN and returns to the idle state.

Negative response from HLR GPRS application process

If the GPRS application process in the HLR returns a negative response, the MAP process constructs a MAP_FAILURE_REPORT service response containing the appropriate error, constructs a MAP_CLOSE service request, sends them to the GGSN and returns to the idle state.

Failure of dialogue opening with the GGSN

If the macro Receive_Open_Ind takes the Vr exit or the Error exit, the MAP process returns to the idle state.

If the MAP provider sends a MAP_P_ABORT while the MAP process is waiting for a service indication, the MAP process returns to the idle state.

If the MAP provider sends a MAP_NOTICE while the MAP process is waiting for a service indication, the MAP process sends a MAP_CLOSE request to terminate the dialogue and returns to the idle state.




Figure 24.2/1: Process Failure_Report_HLR

24.2.2 Process in the GGSN for Failure Report

Successful Outcome

When the MAP process receives a Failure Report request from the GPRS application process in the GGSN, it requests a dialogue with the HLR whose identity is contained in the Failure Report request by sending a MAP_OPEN service request, sending failure information using a MAP_FAILURE_REPORT service request and invokes the macro Receive_Open_Cnf to wait for the response to the dialogue opening request. If the dialogue opening is successful, the MAP process waits for a response from the HLR.

If the MAP process receives a MAP_FAILURE_REPORT service confirm from the HLR, the MAP process invokes the macro Check_Confirmation to check the content of the confirm.

If the macro Check_Confirmation takes the OK exit, the MAP process sends a Failure Report ack containing the information received from the HLR to the GPRS application process in the GGSN and returns to the idle state.

Failure of dialogue opening with the HLR

If the macro Receive_Open_Cnf takes the Vr exit or the Error exit, the MAP process sends a negative response to the GPRS application process in the GGSN and returns to the idle state.

Error in MAP_FAILURE_REPORT confirm

If the MAP_FAILURE_REPORT service confirm contains a user error or a provider error, or the macro Check_Confirmation indicates that there is a data error, the MAP process sends a Failure Report negative response to the GPRS application process in the GGSN and returns to the idle state.

Abort of HLR dialogue

After the dialogue with the HLR has been established, the MAP service provider may abort the dialogue by issuing a MAP_P_ABORT or a MAP_U_ABORT indication. In this case, the MAP process sends a Failure Report negative response to the GPRS application process in the GGSN and returns to the idle state.

If the MAP provider indicates a protocol problem by sending a MAP_NOTICE indication, the MAP process closes the dialogue with the HLR, sends a Failure Report negative response indicating system failure to the GPRS application process in the GGSN and returns to the idle state.

Process Failure_Report_GGSN

24.2_2(1)

Figure 24.2/2: Failure Report process in the GGSN

Signals to/from the right
are to/from the GPRS
application process




Figure 24.2/2: Process Failure_Report_GGSN

24.3.1 Process in the GGSN for Note Ms Present For Gprs

The MAP process in the GGSN to inform that the subscriber is present for GPRS again is shown in figure 24.3/1. The MAP process invokes a macro not defined in this subclause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Check_Indication see subclause 25.2.1.

Successful outcome

When the MAP process receives a MAP_OPEN indication with the application context gprsNotify, it checks it by invoking the macro Receive_Open_Ind.

If the macro takes the OK exit, the MAP process waits for a service indication.

If a MAP_NOTE_MS_PRESENT_FOR_GPRS service indication is received, the GGSN sends a Note Ms Present For Gprs request to the GPRS application process in the GGSN, and wait for a response. The Note Ms Present For Gprs request contains the parameter received in the MAP_NOTE_MS_PRESENT_FOR_GPRS service indication.

If the GPRS application process in the GGSN returns a positive response, the MAP process constructs a MAP_NOTE_MS_PRESENT_FOR_GPRS service response, constructs a MAP_CLOSE service request, sends them to the HLR and returns to the idle state.

Negative response from GGSN GPRS application process

If the GPRS application process in the GGSN returns a negative response, the MAP process constructs a MAP_NOTE_MS_PRESENT_FOR_GPRS service response containing the appropriate error, constructs a MAP_CLOSE service request, sends them to the HLR and returns to the idle state.

Failure of dialogue opening with the HLR

If the macro Receive_Open_Ind takes the Vr exit or the Error exit, the MAP process returns to the idle state.

If the MAP provider sends a MAP_P_ABORT while the MAP process is waiting for a service indication, the MAP process returns to the idle state.

If the MAP provider sends a MAP_NOTICE while the MAP process is waiting for a service indication, the MAP process sends a MAP_CLOSE request to terminate the dialogue and returns to the idle state.




Figure 24.3/1: Process Note_Ms_Present_For_Gprs_GGSN

24.3.2 Process in the HLR for Note Ms Present For Gprs

Successful Outcome

When the MAP process receives a Note Ms Present For Gprs request from the GPRS application process in the HLR, it requests a dialogue with the GGSN whose identity is contained in the Note Ms Present For Gprs request by sending a MAP_OPEN service request, sending necessary information using a MAP_NOTE_MS_PRESENT_FOR_GPRS service request and invokes the macro Receive_Open_Cnf to wait for the response to the dialogue opening request. If the dialogue opening is successful, the MAP process waits for a response from the GGSN.

If the MAP process receives a MAP_NOTE_MS_PRESENT_FOR_GPRS service confirm from the GGSN, the MAP process invokes the macro Check_Confirmation to check the content of the confirm.

If the macro Check_Confirmation takes the OK exit, the MAP process sends a Note Ms Present For Gprs ack containing the information received from the GGSN to the GPRS application process in the HLR and returns to the idle state.

Failure of dialogue opening with the GGSN

If the macro Receive_Open_Cnf takes the Vr exit or the Error exit, the MAP process sends a negative response to the GPRS application process in the HLR and returns to the idle state.

Error in MAP_NOTE_MS_PRESENT_FOR_GPRS confirm

If the MAP_NOTE_MS_PRESENT_FOR_GPRS service confirm contains a user error or a provider error, or the macro Check_Confirmation indicates that there is a data error, the MAP process sends a Note Ms Present For Gprs negative response to the GPRS application process in the HLR and returns to the idle state.

Abort of GGSN dialogue

After the dialogue with the GGSN has been established, the MAP service provider may abort the dialogue by issuing a MAP_P_ABORT or a MAP_U_ABORT indication. In this case, the MAP process sends a Note Ms Present For Gprs negative response to the GPRS application process in the HLR and returns to the idle state.

If the MAP provider indicates a protocol problem by sending a MAP_NOTICE indication, the MAP process closes the dialogue with the GGSN, sends a Failure Report negative response indicating system failure to the GPRS application process in the HLR and returns to the idle state.




Figure 24.3/2: Process Note_MS_Present_For_Gprs_HLR

25 General macro description

25.1 MAP open macros

25.1.1 Macro Receive_Open_Ind

This macro is used by a MAP service-user procedure when a peer entity requests opening of a dialogue.

If the application context received in the MAP-OPEN indication primitive indicates a context name of the MAP version one context set, the macro takes the Vr exit..

If an application-context different from version 1 is received, the presence of MAP_OPEN information is checked. If no MAP_OPEN information has been received, the MAP_OPEN response with:

- Result set to Dialogue Accepted; and
- Application Context Name set to the received value,

is returned

If the received version (Vr) is the one described in this version of MAP, the macro takes the OK exit, otherwise it takes the Vr exit..

If MAP_OPEN information is received, the macro "CHECK_REFERENCE" is called in order to check whether the received values for Destination Reference and Originating Reference correspond with the requirements of the received application-context-name. The outcome of this check is an error, the MAP_OPEN response with:

- Result set to Dialogue Refused;
- Refuse Reason set to Invalid Destination Reference or Invalid Originating Reference;
- Application Context Name set to the highest version supported,

is returned and the macro takes the error exit.

If the data values received for Destination Reference and Originating Reference are accepted for the associated application-context-name it is checked whether the Destination Reference is known if this check is required by the process that calls the macro.

If the Destination Reference (e.g. a subscribers IMSI) is unknown, the MAP_OPEN response with

- Result set to Dialogue Refused;
- Refuse Reason set to Invalid Destination Reference;
- Application Context Name set to the highest version supported,

is returned and the macro takes the error exit.

Else, if the Destination Reference is accepted or if no check is required, the MAP_OPEN response with

- Result set to Dialogue Accepted; and
- Application Context Name set to the received value,

is returned and

If the received version (Vr) is the one described in this version of MAP, the macro takes the OK exit, otherwise it takes the Vr exit..

25.1.2 Macro Receive_Open_Cnf

This macro is used by a user procedure after it requested opening of a dialogue towards a peer entity.

On receipt of a MAP_OPEN Confirmation with a "Result" parameter indicating "Dialogue Accepted", the macro takes the OK exit.

If the "Result" parameter indicates "Dialogue Refused", the "Refuse-reason" parameter is examined. If the "Refuse-reason" parameter indicates "Potential Version Incompatibility", the macro terminates in a way that causes restart of the dialogue by using the version 1 protocol.

If the "Refuse-reason" parameter indicates "Application Context Not Supported" and if the received Application Context Name indicates "Version Vr" ($Vr < Vn$), the macro terminates in a way that causes restart of the dialogue by using the version Vr protocol. Otherwise, the macro takes the Error exit.

If the "Refuse-reason" parameter indicates neither "Potential Version Incompatibility" nor "Application Context Not Supported", the macro takes the Error exit.

If a MAP_U_ABORT, a MAP_P_ABORT or a MAP_NOTICE Indication is received, the macro takes the Error exit.





Figure 25.1/1: Macro Receive_Open_Ind

**Figure 25.1/2: Macro Receive_Open_Cnf**

Macrodefinition CHECK_REFERENCE

25.1_3(1)

Figure 25.1/3: Check of Destination Reference and Originating Reference received in a MAP-OPEN indication primitive




Figure 25.1/3: Macro CHECK_REFERENCE

25.2 Macros to check the content of indication and confirmation primitives

25.2.1 Macro Check_Indication

If a parameter required by the application is missing from the indication, the macro takes the error exit, with a user error of "Data Missing".

If a parameter not expected by the application is present in the indication, or an expected parameter has a value not in the set of values permitted by the application, the macro takes the error exit, with a user error of "Unexpected Data Value".

Otherwise the macro takes the "OK" exit.

The macro is shown in figure 25.2/1.

25.2.2 Macro Check_Confirmation

If the confirmation contains a provider error the macro issues a MAP CLOSE request and takes the provider error exit.

Otherwise, if the confirmation contains a user error the macro takes the user error exit.

Otherwise, if a parameter required by the application is missing from the confirmation, or a parameter not expected by the application is present in the confirmation, or an expected parameter has a value not in the set of values permitted by the application, the macro takes the data error exit.

Otherwise the macro takes the "OK" exit.

The macro is shown in figure 25.2/2.

Macrodefinition Check_Indication

25.2_1(1)

Figure 25.2/1: Macro to check the parameters of an indication primitive




Figure 25.2/1: Macro Check_Indication

Macrodefinition Check_Confirmation

25.2_2(1)

Figure 25.2/2: Macro to check the parameters of a confirmation primitive




Figure 25.2/2: Macro Check_Confirmation

25.3 The page and search macros

25.3.1 Macro PAGE_MSC

This macro (see figure 25.3/1) is called if a mobile terminating call set-up, an unstructured SS notification, a network-initiated unstructured SS request or a mobile terminating short message is to be delivered to the MS and the current location area identity of the MS is known in the VLR.

When the MSC receives a MAP_PAGE indication, parameter checks are performed first (macro Check_Indication, see subclause 25.2). If parameter errors are detected, the MSC returns a MAP_PAGE response containing the appropriate error cause and the macro terminates with unsuccessful outcome.

Thereafter, several checks on the indication content are performed. The macro terminates by returning the MAP_PAGE response with error:

Unknown Location Area if the LAI is not known in the MSC;

System Failure if the call has been released by the calling subscriber or the SMS or SS transaction for this subscriber has been released by the originating entity in the meantime.

Next, the MSC checks if an MM-connection over the radio link already exists for the given IMSI. If so,

- in the case of mobile terminating call set-up the MSC determines whether the busy condition can be established (see GSM 02.01 for a definition of busy states). If the MSC determines that the MS is busy, it returns a MAP_PAGE response with error Busy Subscriber, qualified by either More Calls Allowed or No More Calls Allowed. The macro then terminates with unsuccessful outcome.
- if the service requested is short message service or an unstructured SS notification or network-initiated unstructured SS request, or if the service is mobile terminating call set-up, but the existing connection is for signalling purposes only (i.e. a service different from call set-up), the access connection status is set according to the characteristics of the existing connection (i.e. RR-connection established, ciphering mode on/off, MM-connection existing and authenticated or not), and the macro terminates with successful outcome.

If no MM-connection for the given IMSI exists, paging is initiated at the radio interface within all cells of the location area indicated by the VLR. If the VLR provided the TMSI, the MSC uses it to identify the MS at the radio interface; otherwise the MSC uses the IMSI. The IMSI will also be used to determine the page group (see GSM 04.08). There are several possible outcomes of paging:

- the MS responds to paging, causing the access connection status to be set accordingly (i.e. no RR-connection, in which case other values are not significant), and the macro terminates with successful outcome;
- the MS responds with a channel request containing an establishment cause which is not "answer to paging". The MSC sends a MAP_PAGE response primitive with user error Busy Subscriber before the macro terminates with unsuccessful outcome. This will give priority to the mobile originating request. Alternatively, as an implementation option, the MSC may treat this as a response to paging, which will give priority to the mobile terminating request.
- there is no response from the MS. The MSC sends a MAP_PAGE response primitive with user error Absent Subscriber before the macro terminates with unsuccessful outcome;
- the call handling connection or MAP transaction on which the call, SMS or unstructured SS transaction is waiting for delivery, is released before a response is received from the MS (indicated in the SDL by the input signal I-REL). The MAP transaction with the VLR will be released in this case by a MAP_U_ABORT request, and the unsuccessful macro termination will indicate transaction termination.
- the MAP transaction with the VLR may be released by receiving a MAP_U_ABORT or MAP_P_ABORT indication. The call handling connection or MAP transaction on which the call, SMS or unstructured SS transaction is waiting for delivery, is released (indicated in the SDL by the output signal I-REL), and the unsuccessful macro termination will indicate transaction termination.

25.3.2 Macro Search_For_MS_MSC

This macro (see figure 25.3/2) is called if a mobile terminating call set-up, an unstructured SS notification, a network-initiated unstructured SS request or a mobile terminating short message is to be delivered to the MS and the current location area identity of the MS is not known in VLR.

When the MSC receives a MAP_SEARCH_FOR_MS Indication, parameter checks are performed first (macro Check_indication, see subclause 25.2). If parameter errors are detected, the MSC returns a MAP_SEARCH_FOR_MS response containing the appropriate error cause and the macro terminates with unsuccessful outcome.

Thereafter, the MSC checks whether the call or the SMS or SS transaction still exists in the MSC. If the call or the SMS or SS transaction has been released, the MSC returns a MAP_SEARCH_FOR_MS response with error System Failure and the macro terminates with unsuccessful outcome.

Next, the MSC checks if an MM-connection over the radio link already exists for the given IMSI. If so,

- in the case of mobile terminating call set-up the MSC determines whether the busy condition can be established (see GSM 02.01 for a definition of busy states). If the MSC determines that the MS is busy, it returns a MAP_SEARCH_FOR_MS response with error Busy Subscriber, qualified by either More Calls Allowed or No More Calls Allowed. The macro then terminates with unsuccessful outcome.
- if the service requested is short message service or an unstructured SS notification or network-initiated unstructured SS request, or if the service is mobile terminating call set-up, but the existing connection is for signalling purposes only (i.e. a service different from call set-up), a MAP_SEARCH_FOR_MS response containing the IMSI and current location area identification of the called MS is returned to the VLR. The access connection status is set according to the characteristics of the existing connection (i.e. RR-connection established, ciphering mode on/off, MM-connection existing and authenticated or not), and the macro terminates with successful outcome.

If no MM-connection for the given IMSI exists, paging is initiated at the radio interface within all cells of all location areas of the VLR, using the IMSI to identify the subscriber and the page group (see GSM 04.08). There are several possible outcomes of paging:

- the MS responds to paging, causing a MAP_SEARCH_FOR_MS response containing the IMSI and current location area identification of the called MS to be returned to the VLR. The access connection status will be set accordingly (i.e. no RR-connection, in which case other values are not significant), and the macro terminates with successful outcome.
- the MS responds with a channel request containing an establishment cause which is not "answer to paging". The MSC sends a MAP_SEARCH_FOR_MS response primitive with user error "Busy Subscriber" before the macro terminates with unsuccessful outcome. This will give priority to the mobile originating request. Alternatively, as an implementation option, the MSC may treat this as a response to paging, which will give priority to the mobile terminating request.
- there is no response from the MS. The MSC sends a MAP_SEARCH_FOR_MS response primitive with user error "Absent Subscriber" before the macro terminates with unsuccessful outcome.
- the call handling connection or MAP transaction on which the call, SMS or unstructured SS transaction is waiting for delivery, is released before a response is received from the MS (indicated in the SDL by the input signal I-REL). The MAP transaction with the VLR will be released in this case by a MAP_U_ABORT request, and the unsuccessful macro termination will indicate transaction termination.
- the MAP transaction with the VLR may be released by receiving a MAP_U_ABORT or MAP_P_ABORT indication. The call handling connection or MAP transaction on which the call, SMS or unstructured SS transaction is waiting for delivery, is released (indicated in the SDL by the output signal I-REL), and the unsuccessful macro termination will indicate transaction termination.





Figure 25.3/1: Macro Page_MSC

**Figure 25.3/2: Macro Search_for_MS_MSC**

25.4 Macros for handling an Access Request

These macros are invoked when a MS accesses the network, e.g. to set up an outgoing call or when responding to paging. The macro handles identification and authentication of the mobile subscriber as well as invocation of security related features (see GSM 02.09).

25.4.1 Macro Process_Access_Request_MSC

This macro is invoked by any procedure receiving an access request from the MS, e.g. the page response at mobile terminating call set-up or the request for outgoing call set-up.

If no dialogue with the VLR exists (e.g. within the procedure for outgoing call set-up), the MSC will open a dialogue towards the VLR by sending a MAP_OPEN request without any user specific parameters.

In any case, the parameters received from the MS are mapped to a MAP_PROCESS_ACCESS_REQUEST request primitive, containing:

- the received subscriber identification (IMSI, TMSI) or - in case of emergency call set-up - an IMEI;
- the CM service type, indicating the type of request;
- the status of the access connection, i.e. whether a connection to this MS already exists and if so, whether it is already authenticated and ciphered;
- the current location area id of the MS; and
- the CKSN received from the MS.

If opening of the dialogue was required, the MSC will wait for the dialogue confirmation (see macro Receive_Open_Confirmation, subclause 25.1), leading either to:

- immediate unsuccessful exit from the macro, in case no dialogue is possible;
- reversion to MAP version one dialogue if indicated by the VLR. The macro terminates with unsuccessful outcome, as the complete dialogue will be covered by the version one procedure, so that no further action from the calling process is required;
- continuation as given below, if the dialogue is accepted by the VLR.

The MSC waits then for the MAP_PROCESS_ACCESS_REQUEST confirmation. In between, several other indications may be received from the VLR:

- the MSC may receive a MAP_PROVIDE_IMSI indication, handled by the macro Obtain_IMSI_MSC defined in subclause 25.8. In case of positive outcome, the procedure continues waiting for the MAP_PROCESS_ACCESS_REQUEST confirmation, else the macro terminates with unsuccessful outcome;
- the MSC may receive a MAP_AUTHENTICATE indication, handled by the macro Authenticate_MSC defined in subclause 25.5. In case of positive outcome, the procedure continues waiting for the MAP_PROCESS_ACCESS_REQUEST confirmation, else the macro terminates with unsuccessful outcome;
- the MSC may receive a MAP_TRACE_SUBSCRIBER_ACTIVITY indication, handled by the macro Trace_Subscriber_Activity_MSC defined in subclause 25.9;
- the MSC may receive a MAP_SET_CIPHERING_MODE indication, which will be stored for initiating ciphering later on;
- the MSC may receive a MAP_CHECK_IMEI indication, handled by the macro Check_IMEI_MSC defined in subclause 25.6. In case of positive outcome, the procedure continues waiting for the MAP_PROCESS_ACCESS_REQUEST confirmation, else the macro terminates with unsuccessful outcome;
- the MSC may receive a MAP_OBTAIN_IMEI indication, handled by the macro Obtain_IMEI_MSC defined in subclause 25.6. In case of positive outcome, the procedure continues waiting for the MAP_PROCESS_ACCESS_REQUEST confirmation, else the macro terminates with unsuccessful outcome;

- the MSC may receive a MAP_U_ABORT or MAP_P_ABORT indication, or a premature MAP_CLOSE indication from the VLR. In all these cases, the macro terminates with unsuccessful outcome, after sending the appropriate reject towards the MS (see GSM 09.10);
- the MSC may receive a MAP_NOTICE indication from the VLR. In this case, the dialogue towards the VLR is terminated by a MAP_CLOSE primitive, the appropriate reject is sent towards the MS (see GSM 09.10), and the macro terminates with unsuccessful outcome;
- the MSC may receive an indication for release of the radio path, in which case the dialogue towards the VLR will be terminated by a MAP_U_ABORT primitive, containing the diagnostic information Radio Channel Release.

When the MAP_PROCESS_ACCESS_REQUEST confirmation is received, the parameters of this primitive are checked first. In case of unsuccessful outcome of the service, the MAP User Error received is mapped onto the appropriate radio interface message (see GSM 09.10), before the macro terminates with unsuccessful outcome.

In case of positive outcome of the service, ciphering is initiated on the radio path, if this had been requested by the VLR (see above). Otherwise, if the access request was not triggered by a page response from the MS, the access request is accepted explicitly by sending a CM_Service_Accept message to the MS. If the access request was triggered by a page response from the MS then no CM Service Accept message is sent.

After ciphering has been initiated, the MSC will wait for the MAP_FORWARD_NEW_TMSI indication from the VLR. While waiting, the MSC may receive:

- a MAP_U_ABORT or MAP_P_ABORT indication, or a premature MAP_CLOSE indication from the VLR. In these cases, the macro terminates with unsuccessful outcome, after sending a release request towards the MS (see GSM 09.10);
- a MAP_NOTICE indication from the VLR. In this case, the dialogue towards the VLR is terminated by a MAP_CLOSE primitive, the appropriate reject is sent towards the MS (see GSM 09.10), and the macro terminates with unsuccessful outcome;
- an indication for release of the radio path, in which case the dialogue towards the VLR will be terminated by a MAP_U_ABORT primitive, containing the diagnostic information Radio Channel Release;
- a MAP_DELIMITER request from the VLR. This will be taken as a successful outcome of the macro (i.e. the VLR did not require TMSI reallocation), and it terminates successfully;
- an A_SETUP request from the MS. This will be saved for handling by the procedure which invoked the macro Process_Access_Request_MSC after the macro has terminated.

When the MAP_FORWARD_NEW_TMSI indication is received in the MSC, the TMSI Reallocation Command is sent to the MS, and the MSC waits for an acknowledgement from the MS. In case a positive acknowledgement is received, the MSC sends an empty MAP_FORWARD_NEW_TMSI response primitive to the VLR and terminates successfully. Else, the dialogue is terminated locally (MAP_CLOSE_Req with Release method Prearranged End) without any further action.

If the MSC receives an A_SETUP request while it is waiting for the TMSI acknowledgement from the MS, the A_SETUP is saved for handling by the procedure which invoked the macro Process_Access_Request_MSC after the macro has terminated.

If the dialogue is aborted by the VLR while waiting for the TMSI acknowledgement from the MS, the MSC regards the access request to be failed and terminates with unsuccessful outcome, after sending a release request towards the MS (see GSM 09.10).




Figure 25.4/1 (sheet 1 of 3): Macro Process_Access_Request_MSC

Macrodefinition Process_Access_Request_MSC

25.4_1.2(3)

Figure 25.4/1: Macro for processing the access request in MSC




Figure 25.4/1 (sheet 2 of 3): Macro Process_Access_Request_MSC

Macrodefinition Process_Access_Request_MSC

25.4_1.3(3)




Figure 25.4/1 (sheet 3 of 3): Macro Process_Access_Request_MSC

25.4.2 Macro Process_Access_Request_VLR

When the VLR receives a MAP_PROCESS_ACCESS_REQUEST indication, the VLR will check this indication first (macro Check_Indication, see subclause 25.2). In case of negative outcome, the macro will proceed with the error handling described below.

If the indication data are correct, it is checked first whether the subscriber identification (IMSI or TMSI) is known if included:

- if the identification is not known, the IMSI may be requested from the MS, described in the macro Identification_Procedure (see below) with outcome:
 - OK, if a IMSI known in the VLR has been received;
 - Error, if the VLR did not recognize the subscriber's identity. The macro will proceed with the error handling described below;
 - Aborted, if the transaction to the MSC is released. The macro will terminate immediately with unsuccessful.

In case the identity received is an IMEI, the error System Failure is set and the macro proceeds with the error handling described below.

NOTE: Emergency Call with IMEI may be accepted within the error handling phase.

For a known subscriber the authentication check is performed next (see macro Authenticate_VLR, subclause 25.5), if required. If a negative result is received, the VLR proceeds on receipt of user error:

- illegal subscriber depending on the identity used for authentication;

In case IMSI is already used or no new authentication attempt with IMSI shall not be performed (operator option), the error Illegal Subscriber is set and the macro proceeds with the error handling described below.

If a new authentication attempt with IMSI shall be performed, the IMSI is requested from the MS (macro Obtain_IMSI_VLR, see subclause 25.8):

- the authentication will be performed again if a IMSI known in the VLR is received;
- the error Unidentified Subscriber is set and the macro proceeds with the error handling described below, if the IMSI received is unknown in VLR;
- if the IMSI request procedure fails for any other reason, the error System Failure is set and the macro proceeds with the error handling described below;
- if the dialogue has been aborted during the IMSI request, the macro terminates immediately with unsuccessful outcome;
- unknown subscriber by setting the error Unidentified Subscriber and proceeding with the error handling described below.

NOTE: This can occur only in case of data inconsistency between HLR and VLR;

- procedure error by setting the error System Failure and proceeding with the error handling described below;
- null (i.e. the dialogue towards the MSC is terminated) by terminating immediately with unsuccessful outcome.

The MS access is accepted if no authentication is required or after successful authentication. Then, the indicator "Confirmed by Radio Contact" is set to "Confirmed". If the indicator "Location Information Confirmed in HLR" is set to "Not Confirmed", HLR updating will be started as an independent process (Update_Location_VLR, see subclause 19.1.1.6).

If the indicator "Confirmed by HLR" is set to "Not Confirmed", the error Unidentified Subscriber is set and the macro proceeds with the error handling described below.

If roaming is not allowed in the location area indicated in the Current Location Area Id parameter, the error Roaming Not Allowed qualified by the roaming restriction reason is set and the macro proceeds with the error handling described below.

In case roaming is allowed, the IMSI is set to attached and the process for notifying the HLR that the subscriber is present is started if required (Subscriber Present VLR, see subclause 25.10).

At next, tracing is invoked if required by the operator (macro Trace_Subscriber_Activity_VLR, see subclause 25.9). Thereafter,

if ciphering is not required, IMEI checking is invoked if required by the operator (see macro Check_IMEI_VLR defined in subclause 25.6).

The error Illegal Equipment is set in case of unsuccessful outcome of the IMEI check, the subscriber is marked as detached and the macro proceeds with the error handling described below.

The macro terminates immediately with unsuccessful outcome if the MSC dialogue has been released during the IMEI check.

Else, the macro terminates successfully by returning the MAP_PROCESS_ACCESS_REQUEST response containing the IMSI to indicate acceptance of the MS access.

if ciphering is required, the MAP_SET_CIPHERING_MODE request containing:

- the cipher mode indicating the cipher algorithm required; and
- the cipher key to be used;

is sent to the MSC.

As a further operator option, IMEI checking may be performed next.

The error Illegal Equipment is set in case of unsuccessful outcome of the IMEI check, the subscriber is marked as detached and the macro proceeds with the error handling described below.

The macro terminates immediately with unsuccessful outcome if the MSC dialogue has been released during the IMEI check.

Else, the macro terminates successfully by returning the MAP_PROCESS_ACCESS_REQUEST response containing the IMSI to indicate acceptance of the MS access.

IF no TMSI reallocation is required (again an operator option), the macro terminates thereafter. Else, TMSI reallocation is performed by sending a MAP_FORWARD_NEW_TMSI request, containing the new TMSI as parameter. The old TMSI will be frozen until an acknowledgement from the MS has been received. Before the macro terminates, the VLR will wait for the MAP_FORWARD_NEW_TMSI response, containing no parameters if reallocation has been confirmed by the MS, or a Provider Error, otherwise, in which case the old TMSI is kept frozen to avoid double allocation. In this case, both the old as the new TMSI are subsequently regarded valid when used by the MS.

Error handling

In case some error is detected during handling the access request, a respective error has been set. Before returning this error cause to the MSC in a MAP_PROCESS_ACCESS_REQUEST response, it need to be checked whether this access is for emergency call set-up, as this will require extra treatment.

If the CM Service type given in the MAP_PROCESS_ACCESS_REQUEST indication is emergency call set-up, it is checked whether EC set-up in the particular error situation is permitted (operator option). If so, it is checked whether the IMEI is required, and if so the IMEI is requested from the MS (macro Obtain_IMEI_VLR, see subclause 25.6).

The macro will terminate immediately with unsuccessful outcome if the MSC transaction has been aborted during the IMEI retrieval.

In case of an error reported back from IMEI retrieval, MAP_PROCESS_ACCESS_REQUEST response containing the error cause set previously is returned to the MSC, the dialogue is closed (MAP_CLOSE request indicating normal release) and the macro terminates with unsuccessful outcome.

When a subscriber identity required by the operator (IMSI or IMEI) is available, the user error set previously is deleted, the respective identity is returned in the MAP_PROCESS_ACCESS_REQUEST response to indicate acceptance of emergency call, and the macro terminates with successful outcome.

In all other cases, the MAP_PROCESS_ACCESS_REQUEST response containing the error cause set previously is returned to the MSC, the dialogue is closed (MAP_CLOSE request indicating normal release) and the macro terminates with unsuccessful outcome.

25.4.3 Macro Identification Procedure

This macro is invoked by the macro Process_Access_Request_VLR in case the subscribers identity is not known in the VLR.

If the identity received from the MS is an IMSI, the error Unidentified Subscriber will be set and reported back to the calling macro (to be sent in the MAP_PROCESS_ACCESS_REQUEST response). The same error is used in case a TMSI was received from the MS, but the operator does not allow open identification of the MS.

If open identification of the MS is allowed, the macro Obtain_IMSI_VLR is invoked, requesting the subscribers IMSI from the MS (see subclause 25.8), with outcome

OK, in which case it is checked whether for the IMSI received there exists a subscriber record in the VLR. If so, the macro terminates successfully, else the error Unidentified Subscriber will be set and reported back to the calling macro.

Error, in which case the error System Failure will be set and reported back to the calling macro.

Aborted, i.e. the MSC transaction is released, in which the macro terminates accordingly.

Macrodefinition Process_Access_Request_VLR

25.4_2.1(3)




Figure 25.4/2 (sheet 1 of 3): Macro Process Access Request_VLR

Macrodefinition Process_Access_Request_VLR^P

25.4_2.2(3)





Figure 25.4/2 (sheet 2 of 3): Macro Process_Access_Request_VLR

**Figure 25.4/2 (sheet 3 of 3): Macro Process_Access_Request_VLR**




Figure 25.4/3: Macro ID_Proc_VLR

25.5 Authentication macros and processes

The following macros are used in the GSM network in order to enable authentication of a mobile subscriber.

25.5.1 Macro Authenticate_MSC

This macro is used by the MSC to relay a request for authentication transparently from the VLR to the MS, wait for a response from the MS and to relay the response from the MS back to the VLR. If, while the MSC is waiting for the authentication response, the air interface connection is released or a MAP_U_ABORT, MAP_P_ABORT or MAP_CLOSE indication is received from the VLR, then necessary connections are released and the "Error" exit is used. The macro is described in figure 25.5/1.

25.5.2 Macro Authenticate_VLR

This macro is used by the VLR to control the authentication of a subscriber. The macro proceeds as follows:

- if there are not enough authentication triplets in the VLR to perform the authentication, then the macro "Obtain_Authent_Para_VLR" described below is invoked. If this macro fails, then the corresponding error (Unknown Subscriber or Procedure Error) is returned to the calling process;
- if there are enough authentication triplets in the VLR, or the Obtain_Authent_Para_VLR macro was successful, then a MAP_AUTHENTICATE request is sent to the MSC. This request contains the RAND and CKSN parameters as indicated in the service description;
- the VLR then waits for a response from the MSC;
- if a MAP_U_ABORT, MAP_P_ABORT or MAP_CLOSE indication is received from the MSC in this wait state, the VLR checks whether authentication sets are available. If no sets are available the process Obtain_Authent_Sets_VLR is invoked to fetch authentication sets from the HLR. The "Null" exit is then used;
- if a MAP_NOTICE indication is received from the MSC in this wait state, the VLR closes the dialogue with the MSC, then checks whether authentication sets are available. If no sets are available the process Obtain_Authent_Sets_VLR is invoked to fetch authentication sets from the HLR. The "Null" exit is then used;
- if a MAP_AUTHENTICATE confirmation is received by the VLR, it checks whether the received Signed Result (SRES) is identical to the stored one (see GSM 03.20). If this is not the case, the "Illegal Subscriber" exit is used. If the SRES values are identical, then the "OK" exit is used;
- before exit, the VLR may fetch a new set of triplets from the HLR. This is done by initiating a separate Obtain_Authent_Sets_VLR process described below.

The macro is described in figure 25.5/2.

25.5.3 Process Obtain_Authentication_Sets_VLR

This process is initiated by the VLR to fetch triplets from a subscriber's HLR in a stand-alone, independent manner. The Obtain_Authent_Para_VLR macro described below is simply called; the process is described in figure 25.5/3.

25.5.4 Macro Obtain_Authent_Para_VLR

This macro is used by the VLR to request authentication triplets from the HLR. The macro proceeds as follows:

- a connection is opened, and a MAP_SEND_AUTHENTICATION_INFO request sent to the HLR;
- if the HLR indicates that a MAP version 1 dialogue is to be used, the VLR performs the equivalent MAP version 1 dialogue, which can return a positive result containing authentication sets, an empty positive result, or an error;
- if the dialogue opening fails, the "Procedure Error" exit is used. Otherwise, the VLR waits for the response from the HLR;
- if a MAP_SEND_AUTHENTICATION_INFO confirmation is received from the HLR, the VLR checks the received data.

One of the following positive responses may be received from a MAP version 1 or MAP version 2 dialogue with the HLR:

- Authentication triplets, in which case the outcome is successful;
- Empty response, in which case the VLR may re-use old triplets, if allowed by the PLMN operator.

If the VLR cannot re-use old triplets (or no such triplets are available) then the "Procedure Error" exit is used.

If the outcome was successful or re-use of old parameters in the VLR is allowed, then the "OK" exit is used.

If an "Unknown Subscriber" error is included in the MAP_SEND_AUTHENTICATION_INFO confirm or is returned by the MAP version 1 dialogue, then the "Unknown Subscriber" exit is used.

- if a MAP_U_ABORT, MAP_P_ABORT, MAP_NOTICE or unexpected MAP_CLOSE service indication is received from the MSC, then open connections are terminated, and the macro takes the "Null" exit;
- if a MAP_U_ABORT, MAP_P_ABORT or unexpected MAP_CLOSE service indication is received from the HLR, then the VLR checks whether old authentication parameters can be re-used. If old parameters cannot be re-used the macro takes the "Procedure Error" exit; otherwise it takes the "OK" exit;
- if a MAP_NOTICE service indication is received from the HLR, then the dialogue with the HLR is closed. The VLR then checks whether old authentication parameters can be re-used. If old parameters cannot be re-used the macro takes the "Procedure Error" exit; otherwise it takes the "OK" exit.

The macro is described in figure 25.5/4.

25.5.5 Process Obtain_Auth_Sets_HLR

Opening of the dialogue is described in the macro Receive_Open_Ind in subclause 25.1, with outcomes:

- reversion to version one procedure;
- procedure termination; or
- dialogue acceptance, with proceeding as below.

This process is used by the HLR to obtain authentication triplets from the AuC, upon request from the VLR or from the SGSN. The process acts as follows:

- a MAP_SEND_AUTHENTICATION_INFO indication is received by the HLR;
- the HLR checks the service indication for errors. If any, they are reported to the VLR or to the SGSN in the MAP_SEND_AUTHENTICATION_INFO response. If no errors are detected, authentication triplets are fetched from the AuC. Further details are found in GSM 03.20;
- if errors are detected they are reported to the VLR or to the SGSN in the MAP_SEND_AUTHENTICATION_INFO response. Otherwise the authentication triplets are returned.

The process is described in figure 25.5/5.

Macrodefinition Authenticate_MSC

25.5_1(1)

Figure 25.5/1: Authentication macro in the MSC, relaying authentication indication from the VLR to the MS, and relaying the confirmation from the MSC to the VLR





Figure 25.5/1: Macro Authenticate_MSC

**Figure 25.5/2: Macro Authenticate_VLR**

Process Obtain_Authent_Sets_VLR 25.5_3(1)

Figure 25.5/3: Process to obtain authentication sets from the HLR to the VLR




Figure 25.5/3: Process Obtain_Authentication_Sets_VLR




Figure 25.5/4 (sheet 1 of 2): Macro Obtain_Authent_Para_VLR

Macrodefinition Obtain_Authent_Para_VLR

25.5_4.2(2)

Figure 25.5/4: Macro to obtain authentication parameters from the HLR to the VLR




Figure 25.5/4 (sheet 2 of 2): Macro Obtain_Authent_Para_VLR

Process Obtain_Auth_Sets_HLR 25.5_5(1)

Figure 25.5/5: Process in the HLR to obtain authentication sets from the AuC and relay them to the VLR




Figure 25.5/5: Process Obtain_Auth_Sets_HLR

25.5.6 Process Obtain_Authent_Para_SGSN

For authentication procedure description see GSM 03.60 and GSM 04.08.

This Process is used by the SGSN to request authentication triplets from the HLR.

If the SGSN does not know the subscriber's HLR address (e.g. no IMSI translation exists), the Authentication Parameter negative response with error "Unknown HLR" is returned to the requesting process.

Otherwise, the Process proceeds as follows:

- a connection is opened, and a MAP_SEND_AUTHENTICATION_INFO request sent to the HLR;
- if the HLR indicates that a MAP version 1 dialogue is to be used, the SGSN performs the equivalent MAP version 1 dialogue, which can return a positive result containing authentication sets, an empty positive result, or an error;
- if the dialogue opening fails, the Authentication Parameters negative response with appropriate error is sent to the requesting process. Otherwise, the SGSN waits for the response from the HLR;
- if a MAP_SEND_AUTHENTICATION_INFO confirmation is received from the HLR, the SGSN checks the received data.

One of the following positive responses may be received from a MAP version 1 or MAP version 2 dialogue with the HLR:

- Authentication triplets, in which case the outcome is successful;
- Empty response, in which case the SGSN may re-use old triplets, if allowed by the PLMN operator.

If the SGSN cannot re-use old triplets (or no such triplets are available) then the the Authentication Parameters negative response with appropriate error is sent to the requesting process.

If the outcome was successful or re-use of old parameters in the SGSN is allowed, then the Authentication Parameters response is sent to the requesting process

If an "Unknown Subscriber" error is included in the MAP_SEND_AUTHENTICATION_INFO confirm or is returned by the MAP version 1 dialogue, then the appropriate error is sent to the requesting process in the Authentication Parameters negative response

- if a MAP-U-ABORT, MAP-P-ABORT or unexpected MAP_CLOSE service indication is received from the HLR, then the SGSN checks whether old authentication parameters can be re-used. If old parameters cannot be re-used the Authentication Parameters negative response with appropriate error is sent to the requesting process.
- if a MAP_NOTICE service indication is received from the HLR, then the dialogue with the HLR is closed. The SGSN then checks whether old authentication parameters can be re-used. If old parameters cannot be re-used the process terminates and the Authentication Parameters negative response with appropriate error is sent to the requesting process; Otherwise the Authentication Parameters response is sent to requesting process.

The process is described in figure 25.5/6.

Process Obtain_Authent_Para_SGSN

25.5_6.1(2)

Figure 25.5/6: Process to obtain authentication parameters from the HLR to the SGSN




Figure 25.5/6 (sheet 1 of 3): Macro Obtain_Authen_Para_SGSN

Process Obtain_Authent_Para_SGSN

25.5_6.1(2)

Figure 25.5/6: Process to obtain authentication parameters from the HLR to the SGSN




Figure 25.5/6 (sheet 2 of 3): Macro Obtain_Authen_Para_SGSN

Process Obtain_Authent_Para_SGSN

25.5_6.2(2)

Figure 25.5/6: Process to obtain authentication parameters from the HLR to the SGSN




Figure 25.5/6 (sheet 3 of 3): Macro Obtain_Authen_Para_SGSN

25.6 IMEI Handling Macros

The following macros are used in the GSM network in order to enable handling and checking of the mobile equipment identity.

25.6.1 Macro Check_IMEI_MSC

This macro is used by the MSC to receive a request from the VLR, relay it to the EIR, and pass the result from the EIR back to the VLR. The macro proceeds as follows:

- a MAP_CHECK_IMEI service indication containing only the Invoke Id is received from the VLR;
- if the IMEI is not available in the MSC, it is requested from the MS using the IDENTITY REQUEST message;
- if the MS releases the radio resources, a MAP_U_ABORT request indicating "Application procedure Cancellation" is sent to the VLR, and the "Error" exit of the macro is used;
- when the IMEI is known, a connection is set up towards the EIR, and a MAP_CHECK_IMEI service request is sent including the IMEI;
- if the opening of the dialogue fails, a System Failure is reported to the VLR. Otherwise, the MSC waits for a response from the EIR;
- when the MAP_CHECK_IMEI service confirm is received, it is checked for errors. Any errors discovered in the MSC lead to the System Failure error to be reported to the VLR in the MAP_CHECK_IMEI response. Any errors reported from the EIR are sent directly to the VLR in the MAP_CHECK_IMEI service response. If no errors are detected by or reported to the MSC, the IMEI is added to the MAP_CHECK_IMEI service response returned to the VLR. The "OK" exit is used in all cases;
- if a MAP_P_ABORT, MAP_U_ABORT, MAP_CLOSE or MAP_NOTICE service indication is received from the EIR, the MSC closes the transaction with the EIR (if necessary), reports a System Failure error back to the VLR in the MAP_CHECK_IMEI response, and uses the macro's "OK" exit;
- if a MAP_P_ABORT, MAP_U_ABORT, MAP_CLOSE or MAP_NOTICE indication is received from the VLR, the MSC closes the transaction with the VLR (if necessary) and aborts the connections towards the EIR and the MS; the macro takes the "Error" exit.

If the dialogue with the EIR drops back to version 1, the result or error returned by the EIR is checked. The use of the "Check_Confirmation" macro in the SDL diagram indicates that the checks carried out on the result returned by the EIR in a MAP v1 dialogue are functionally equivalent to those carried out on the parameters of the MAP_CHECK_IMEI confirm received from the EIR in a MAP v2 dialogue.

The macro is described in figure 25.6/1.

25.6.2 Macro Check_IMEI_VLR

This macro is used by the VLR to control the check of a mobile equipment's IMEI. The macro proceeds as follows:

- a MAP_CHECK_IMEI service request is sent to the MSC, including only the Invoke Id;
- the VLR then waits for the response from the MSC;
- if a MAP_CHECK_IMEI service confirm including either:
 - the IMEI and the Equipment Status; or
 - an error;

is received, the VLR checks whether the response requires that an alarm be generated on the Operation and Maintenance interface. The criteria for such alarms are PLMN operator dependent;

- the VLR then checks whether the response from the MSC means that service is granted to the MS. The criteria for granting service depending on the equipment status or errors received in the MAP_CHECK_IMEI service response are also PLMN operator dependent;

- if a MAP_P_ABORT, MAP_U_ABORT, MAP_CLOSE or MAP_NOTICE indication is received from the MSC, then the MSC connection is closed (if necessary) and the macro takes the "Aborted" exit.

The macro is described in figure 25.6/2.

25.6.3 Process Check_IMEI_EIR

This process is used by the EIR to obtain the status of a piece of mobile equipment, upon request from the MSC or from the SGSN. The process acts as follows:

- a MAP_OPEN service indication is received (macro Receive_Open_Ind, subclause 25.1.1). If the dialogue opening fails, the process terminates;
- otherwise, a MAP_CHECK_IMEI indication is received by the EIR, containing the IMEI to be checked;
- the EIR checks the service indication for errors. If there are any, they are reported to the MSC or to the SGSN in the MAP-CHECK_IMEI response. If no errors are detected, the EIR data base function is interrogated for the status of the given equipment. Further details are found in GSM 02.16;
- the status of the equipment (white-listed, grey-listed, black-listed or unknown) is returned to the MSC or to the SGSN in the MAP_CHECK_IMEI service response;
- if a MAP_U_ABORT, MAP_P_ABORT, MAP_NOTICE or MAP_CLOSE indication is received from the MSC or from the SGSN at any time during this process, the process in the EIR terminates.

The process is described in figure 25.6/3.

25.6.4 Macro Obtain_IMEI_MSC

This macro is used by the MSC to respond to a request from the VLR to provide the IMEI. The macro proceeds as follows:

- a MAP_OBTAIN_IMEI service indication containing only the Invoke Id is received from the VLR;
- if the IMEI is not available in the MSC, it is requested from the MS using the IDENTITY REQUEST message;
- when the IMEI is known, it is returned to the VLR in the MAP_OBTAIN_IMEI service response. The macro terminates at the "OK" exit;
- if the IMEI cannot be obtained by the MSC, the System Failure error is reported back to the VLR in the MAP_OBTAIN_IMEI service response. The macro terminates at the "OK" exit;
- if a MAP_P_ABORT, MAP_U_ABORT or MAP_CLOSE indication is received from the VLR, the macro terminates at the "Error" exit.

The macro is described in figure 25.6/4.

25.6.5 Macro Obtain_IMEI_VLR

This macro is used by the VLR to obtain the IMEI from the MSC, e.g. to enable handling of emergency calls in case of authentication failure (in which case the IMEI may be used by some operators as an alternative to the IMSI). It proceeds as follows:

- the MAP_OBTAIN_IMEI service request is sent to the MSC, including only the Invoke Id;
- the VLR then waits for the response from the MSC;
- if the IMEI is received in the MAP_OBTAIN_IMEI service response, the macro terminates at the "OK" exit;
- if the System Failure error is reported in the MAP_OBTAIN_IMEI service response, the "Error" exit is used;
- if the MSC terminates the dialogue using a MAP_P_ABORT, MAP_U_ABORT, MAP_CLOSE or MAP_NOTICE service indication, the necessary connections are released, and the "Aborted" exit is used for termination of the macro.

The macro is shown in figure 25.6/5.




Figure 25.6/1 (sheet 1 of 2): Macro Check_IMEI_MSC

Macrodefinition Check_IMEI_MSC

25.6_1.2(2)

Figure 25.6/1: Check IMEI macro in the MSC, relaying the IMEI check indication from the VLR to the MSC and relaying the confirmation from the EIR to the VLR




Figure 25.6/1 (sheet 2 of 2): Macro Check_IMEI_MSC

Macrodefinition Check_IMEI_VLR

25.6_2(1)

Figure 25.6/2: Check IMEI macro in the VLR, containing the request towards the MSC/EIR




Figure 25.6/2: Macro Check_IMEI_VLR




Figure 25.6/3: Process Check_IMEI_EIR

Macrodefinition Obtain_IMEI_MSC

25.6_4(1)

Figure 25.6/4: Obtain IMEI macro in the MSC, receiving the Obtain_IMEI indication from the VLR to the MSC and returning the confirmation to the VLR




Figure 25.6/4: Macro Obtain_IMEI_MSC

Macrodefinition Obtain_IMEI_VLR

25.6_5(1)

Figure 25.6/5: Obtain IMEI macro in the VLR, controlling the request towards the MSC




Figure 25.6/5: Macro Obtain_IMEI_VLR

25.6.6 Process Check_IMEI_SGSN

This process is used by the SGSN to control the check of a mobile equipment's IMEI. The process proceeds as follows:

- if the MS does not complete successfully the procedure, the "Error" exit of the macro is used;
- when the IMEI is known, a connection is set up towards the EIR, and a MAP_CHECK_IMEI service request is sent including the IMEI;
- if the opening of the dialogue fails, a System Failure is set. Otherwise, the SGSN waits for a response from the EIR;
- if a MAP_CHECK_IMEI service confirm including either:
 - the IMEI and the Equipment Status; or
 - an error;

is received, the SGSN checks whether the response requires that an alarm be generated on the Operation and Maintenance interface. The criteria for such alarms are PLMN operator dependent;

- the SGSN then checks whether the response from the EIR means that service is granted to the MS. The criteria for granting service depending on the equipment status or errors received in the MAP_CHECK_IMEI service response are also PLMN operator dependent;

If the dialogue with the EIR drops back to version 1, the result or error returned by the EIR is checked. The use of the "Check_Confirmation" macro in the SDL diagram indicates that the checks carried out on the result returned by the EIR in a MAP v1 dialogue are functionally equivalent to those carried out on the parameters of the MAP_CHECK_IMEI confirm received from the EIR in a MAP v2 dialogue.

The process is described in figure 25.6/6.




Figure 25.6/6 (sheet 1 of 2): Process Check_IMEI_SGSN




Figure 25.6/6 (sheet 2 of 2): Process Check_IMEI_SGSN

25.7 Insert Subscriber Data Macros


25.7.1 Macro Insert_Subs_Data_VLR

This macro describes the reception of the InsertSubscriberData service indication. This macro is used by any procedure that triggers the reception of subscriber data (e.g. Update Location or Restore Data).

If the VLR does not support any basic or supplementary service or the network feature Operator Determined Barring, or there is a problem with Regional Subscription Data then it reports it to the HLR.

If the entire MSC area is restricted due to regional subscription this is reported to the HLR.

The SDL diagram is shown in figure 25.7/1.

**Figure 25.7/1: Macro Insert_Subs_Data_VLR**

25.7.2 Process Insert_Subs_Data_Stand_Alone_HLR

This process is used by HLR to transfer subscriber data to VLR or to SGSN in a stand alone mode, i.e. in its own dialogue. this is done whenever a change of subscriber data is performed either by the operator or by the subscriber and this change has to be reported to VLR or to SGSN.

The process, after opening the dialogue with VLR or with SGSN, sends as many requests of the InsertSubscriberData service as necessary to transfer the subscriber data. The call to the process "Send_Insert_Subs_Data" (see subclause 25.7.4) is meant to describe two possible behaviours of the HLR when more than one service request has to be sent:

- either the HLR handles the requests and the confirmations in parallel; or
- the HLR sends every request after receiving the confirmation to the previous one.

The macros "Wait_for_Insert_Subs_Data_Cnf" and "Wait_for_Insert_GPRS_Subs_Data_Cnf" (see subclauses 25.7.3 and 25.7.6) are also called in order to handle every single confirmation.

If the result of a primitive received from the VLR or from the SGSN is unsuccessful, the HLR may initiate re-attempts; the number of repeat attempts and the time in between are HLR operator options, depending on the error returned by the VLR or by the SGSN.

If certain services required for a subscriber are not supported by the VLR or by the SGSN (e.g. Advice of Charge Charging Level), this may result in one of the following outcomes:

- the HLR stores and sends "Roaming Restriction Due To Unsupported Feature" in a subsequent MAP_INSERT_SUBSCRIBER_DATA service. If "Roaming Restriction Due To Unsupported Feature" is stored in the HLR, the "MSC Area Restricted Flag" shall be set to "restricted". This will prevent MT calls, MT SM and MT USSD from being forwarded to the MSC/VLR.
- the HLR stores and sends other induced subscriber data (e.g. a specific barring program) in a subsequent MAP_INSERT_SUBSCRIBER_DATA service. This will cause rejection of mobile originated service requests, except emergency calls.
- the HLR stores and sends "Roaming Restricted In SGSN Due To Unsupported Feature" in a subsequent MAP_INSERT_SUBSCRIBER_DATA service. If "Roaming Restricted In SGSN Due To Unsupported Feature" is stored in the HLR, the "SGSN Area Restricted Flag" shall be set to "restricted". This will prevent MT SM from being forwarded to the SGSN and Network Requested PDP-Context activation.

When the VLR receives regional subscription data (Zone Code List) it may respond with "MSC Area Restricted" in the MAP_INSERT_SUBSCRIBER_DATA response. In this case the "MSC Area Restricted Flag" shall be set to "restricted" in the HLR. This will prevent MT calls, MT SM and MT USSD from being forwarded to the MSC/VLR.

When the SGSN receives regional subscription data (Zone Code List) it may respond with "SGSN Area Restricted" in the MAP_INSERT_SUBSCRIBER_DATA response. In this case the "SGSN Area Restricted Flag" shall be set to "restricted" in the HLR. This will prevent MT SM from being forwarded to the SGSN and Network Requested PDP-Context activation.

If subscriber data for CAMEL Phase 2 services are sent to a VLR which does not support CAMEL Phase 2, the service behaviour may be unpredictable or incorrect. The HLR therefore needs to ensure that at the conclusion of a stand alone Insert Subscriber data procedure that the data in the VLR do not require a capability that the VLR does not have. Possible mechanisms to ensure this are described in GSM 03.78.

The HLR should send a Forwarded-to number which is not in E.164 international format to the VLR only when the HLR has ascertained that the VLR supports CAMEL Phase 2. Thus, the ISD message containing the Forwarded-to number which is not in E.164 international format shall be sent to the VLR only if the HLR previously received confirmation from the VLR at Location Update that CAMEL Phase 2 is supported.


A Forwarded-to number in non-international E.164 format shall only be sent from an HLR to a VLR if the VLR supports CAMEL Phase 2, or a subsequent version of CAMEL.

If the HLR does not store "Roaming Restriction Due To Unsupported Feature" as a consequence of the stand alone Insert Subscriber Data procedure and the HLR does not receive "MSC Area Restricted" in the MAP_INSERT_SUBSCRIBER_DATA response and "Roaming Restriction Due To Unsupported Feature" has not been stored in the HLR in the course of a previous subscriber data retrieval procedure, the "MSC Area Restricted Flag" in the HLR shall be set to "not restricted".

If the HLR does not store "Roaming Restricted In SGSN Due To Unsupported Feature" as a consequence of the stand alone Insert Subscriber Data procedure and the HLR does not receive "SGSN Area Restricted" in the MAP_INSERT_SUBSCRIBER_DATA response and "Roaming Restricted In SGSN Due To Unsupported Feature" has not been stored in the HLR in the course of a previous subscriber data retrieval procedure, the "SGSN Area Restricted Flag" in the HLR shall be set to "not restricted".

The SDL diagram of process between HLR and VLR is shown in figure 25.7/2;

The SDL diagram of process between HLR and SGSN is shown in figure 25.7/5.

**Figure 25.7/2 (sheet 1 of 2): Process Insert_Subs_Data_Stand_Alone_HLR**

Process Insert_Subs_Data_Stand_Alone_HLR

25.7_2.2(2)

Figure 25.7/2: Independent process to open a new dialogue and transfer subscriber data from HLR to VLR




Figure 25.7/2 (sheet 2 of 2): Process Insert_Subs_Data_Stand_Alone_HLR




Figure 25.7/5 (sheet 1 of 2): Process Insert_GPRS_Subs_Data_Stand_Alone_HLR

Process Insert_GPRS_Subs_Data_Stand_Alone_HLR

25.7_5.2(2)

Figure 25.7/5: Independent process to open a new dialogue and transfer GPRS subscriber data from HLR to SGSN




Figure 25.7/7




Figure 25.7/5 (sheet 2 of 2): Process Insert_GPRS_Subs_Data_Stand_Alone_HLR

25.7.3 Macro Wait_for_Insert_Subs_Data_Cnf

This macro is used by any process or macro that describes the handling of the reception of the Insert_Subscriber_Data service in HLR that is coming from VLR (e.g. Update Location or Restore Data).

If the VLR reports the non-support of some basic or supplementary service or the network feature Operator Determined Barring then three actions are possible:

- to ignore the information received;
- to replace the not supported service;
- or to perform any other internal action.

The SDL diagram is shown in figure 25.7/3.




Figure 25.7/3: Macro Wait_for_Insert_Subs_Data_Cnf

25.7.4 Process Send_Insert_Subs_Data

This process is used by any process or macro where the Insert_Subscriber_Data request is sent to VLR or to SGSN.

The SDL diagram is shown in figure 25.7/4.

Process Send_Insert_Subs_Data

25.7_4(1)

Figure 25.7/4: Independent process to send
a component of subscriber data from HLR to VLR




Figure 25.7/4: Process Send_Insert_Subs_Data


25.7.5 Macro Insert_Subs_Data_SGSN

This macro describes the reception of the InsertSubscriberData service indication. This macro is used by any procedure that triggers the reception of subscriber data (e.g. Update GPRS Location).

If the SGSN does not support any basic or the network feature Operator Determined Barring, or there is a problem with Regional Subscription Data then it reports it to the HLR.

If the entire SGSN area is restricted due to regional subscription this is reported to the HLR.

The SDL diagram is shown in figure 25.7/6.

**Figure 25.7/6: Macro Insert_Subs_Data_SGSN**

25.7.6 Macro Wait_for_Insert_GPRS_Subs_Data_Cnf

This macro is used by any process or macro that describes the handling of the reception of the Insert_Subscriber_Data service in HLR that is coming from SGSN (e.g. Update GPRS Location).

If the SGSN reports the non-support of some basic or the network feature Operator Determined Barring then three actions are possible:

- to ignore the information received;
- to replace the not supported service;
- or to perform any other internal action.

The SDL diagram is shown in figure 25.7/7.




Figure 25.7/7: Macro Wait_for_Insert_GPRS_Subs_Data_Cnf

25.8 Request IMSI Macros

25.8.1 Macro Obtain_IMSI_MSC

This macro describes the handling of the request received from the VLR to provide the IMSI of a subscriber (e.g. at Location Updating).

The SDL diagram is shown in figure 25.8/1.




Figure 25.8/1: Macro Obtain_IMSI_MSC

25.8.2 Macro Obtain_IMSI_VLR

This macro describes the way VLR requests the MSC the IMSI of a subscriber (e.g. at Location Updating).

The SDL diagram is shown in figure 25.8/2.

Macrodefinition Obtain_IMSI_VLR

25.8_2(1)

Figure 25.8/2: Macro to obtain the IMSI from the MS via the MSC




Figure 25.8/2: Macro Obtain_IMSI_VLR

25.9 Tracing macros

25.9.1 Macro Trace_Subscriber_Activity_MSC

The Trace_Subscriber_Activity_MSC is invoked in the MSC, when the MSC receives the MAP_TRACE_SUBSCRIBER_ACTIVITY indication from the VLR. The data of the primitive is checked and the tracing in the MSC is started if the content includes no errors. No response is returned to the VLR.

The Trace_Subscriber_Activity_MSC macro is described in the figure 25.9/1.




Figure 25.9/1: Macro Trace_Subscriber_Activity_MSC

25.9.2 Macro Trace_Subscriber_Activity_VLR

The macro Trace_Subscriber_Activity_VLR is invoked, if the subscriber activity is detected by the VLR and the tracing is active. The VLR sends MAP_TRACE_SUBSCRIBER_ACTIVITY request to the MSC. No answer is awaited from the MSC.

The Trace_Subscriber_Activity_VLR macro is shown in the figure 25.9/2.

Macrodefinition Trace_Subscriber_Activity_VLR

25.9_2(1)

Figure 25.9/2: The subscriber tracing macro in the VLR




Figure 25.9/2: Macro Trace_Subscriber_Activity_VLR

25.9.3 Macro Activate_Tracing_VLR

The Activate_Tracing_VLR macro is invoked, when the MAP_ACTIVATE_TRACE_MODE indication is received from the HLR. The primitive is processed in the VLR as follows:

- if the data contains errors, a data missing or unexpected data value indication is returned to the HLR;
- if the tracing is not supported, a facility not supported indication is returned to the HLR;
- if the tracing buffer does not have any space left for the data, a tracing buffer full indication is returned to the HLR;
- if no errors is detected, the tracing is set active and a positive acknowledge is returned to the HLR.

The Activate_Tracing_VLR macro is described in the figure 25.9/3.

Macrodefinition Activate_Tracing_VLR

25.9_3(1)

Figure 25.9/3: The activate trace mode macro in the VLR




Figure 25.9/3: Macro Activate_Tracing_VLR

25.9.4 Macro Control_Tracing_HLR

The Control_Tracing_HLR macro may be invoked in the HLR, if subscriber related activity is detected. If the tracing is active in the HLR and not active in the VLR or in the SGSN, the MAP_ACTIVATE_TRACE_MODE request is sent to the VLR or to the SGSN.

The MAP_ACTIVATE_TRACE_MODE confirmation from the VLR or from the SGSN is processed as follows:

- if the primitive contains a successful acknowledge, the tracing in VLR or in the SGSN is set active;
- if the primitive contains errors, the tracing in VLR or in SGSN is set deactive.

The Control_Tracing_HLR macro between HLR and VLR is shown in the figure 25.9/4

The Control_Tracing_HLR_with_SGSN macro between HLR and SGSN is shown in the figure 25.9/5





Figure 25.9/4: Macro Control_Tracing_HLR

**Figure 25.9/5: Macro Control_Tracing_HLR_with_SGSN**

25.9.5 Macro Trace_Subscriber_Activity_SGSN

The macro Trace_Subscriber_Activity_SGSN is invoked, if the subscriber activity is detected by the SGSN and the tracing is active.

The Trace_Subscriber_Activity_SGSN macro is shown in the figure 25.9/6.

Macrodefinition Trace_Subscriber_Activity_SGSN

25.9_6(1)

Figure 25.9/6: The subscriber tracing macro in the SGSN




Figure 25.9/6: Macro Trace_Subscriber_Activity_SGSN

25.9.6 Macro Activate_Tracing_SGSN

The Activate_Tracing_SGSN macro is invoked, when the MAP_ACTIVATE_TRACE_MODE indication is received from the HLR. The primitive is processed in the SGSN as follows:

- if the data contains errors, a data missing or unexpected data value indication is returned to the HLR;
- if the tracing is not supported, a facility not supported indication is returned to the HLR;
- if the tracing buffer does not have any space left for the data, a tracing buffer full indication is returned to the HLR;
- if no errors is detected, the tracing is set active and a positive acknowledge is returned to the HLR.

The Activate_Tracing_SGSN macro is described in the figure 25.9/7.

Macrodefinition Activate_Tracing_SGSN

25.9_7(1)

Figure 25.9/7: The activate trace mode macro in the SGSN




Figure 25.9/7: Macro Activate_Tracing_SGSN

25.10 Short Message Alert procedures

25.10.1 Subscriber_Present_VLR process

The Subscriber_Present_VLR process is invoked by the VLR, when the mobile subscriber becomes active and the MNRF flag is set. The general description of the short message alert procedures is in the subclause 23.4.

The VLR sends the MAP_READY_FOR_SM request to the HLR and waits for the HLR to answer. When receiving the answer, the VLR will act as follows:

- the MNRF flag is cleared if the procedure is successful;
- the MNRF flag is not cleared if the procedure is not successful.

The Subscriber_Present_VLR process is shown in the figure 25.10/1.

Process Subscriber_Present_VLR

25.10_1(1)

Figure 25.10/1: The short message alert process in the VLR for mobile present situation




Figure 25.10/1: Process Subscriber_Present_VLR

25.10.2 Macro Alert_Service_Centre_HLR

The Alert_Service_Centre_HLR macro is initiated when the HLR notices that the Service Centre(s) shall be alerted. The macro starts process Alert_Service_Centre_HLR for every SC address in the MWD list.

In the process Alert_Service_Centre_HLR the HLR sends MAP_ALERT_SERVICE_CENTRE request to the appropriate IWMSC. The MWD entry is deleted when the positive acknowledge is received from the IWMSC. The unsuccessful alert may be repeated. The MWD entry should be purged in the unsuccessful case, at least when a suitable time period has expired.

The Alert_Service_Centre_HLR macro is shown in the figure 25.10/2 and the Alert_Service_Centre_HLR process is shown in the figure 25.10/3.

Macrodefinition Alert_Service_Centre_HLR

25.10_2(1)

Figure 25.10/2: The short message alert macro in the HLR




Figure 25.10/2: Macro Alert_Service_Centre_HLR

Process Alert_Service_Centre_HLR

22.10_3(1)

Figure 25.10/3: The short message alert process in the HLR




Figure 25.10/3: Process Alert_Service_Centre_HLR

25.10.3 The Mobile Subscriber is present

When receiving Page response, Attach request or Routing area update request messages (TS GSM 04.08), while the MS not reachable for GPRS (MNRG) flag is set, the SGSN will send the MAP_READY_FOR_SM request towards the HLR. The Alert Reason is set to indicate that the mobile subscriber is present for GPRS.

When receiving the answer, the SGSN will act as follows:

- MNRG is cleared if the procedure is successful
- MNRG is not cleared if the procedure is not successful

The Subscriber_Present_SGSN process is shown in the figure 25.10/4.

Process Subscriber_Present_SGSN 25.10_4(1)

Figure 25.10/4: The short message alert process in the SGSN for mobile present situation




Figure 25.10/4: Process Subscriber_Present_SGSN

Annex A (informative): Cross-reference for abstract syntaxes of MAP

Annex A is not part of the standard, it is included for information purposes only.

For every ASN.1 item such as identifier, type-reference or value-reference the cross-reference allows to locate all occurrences by means of module-name and line numbers. For that purpose line numbers are printed at the left margin in front of each ASN.1 source line starting with 1 for every module.

The items are sorted alphabetically in the cross-reference in a case-insensitive manner. Occurrences of an item are its definition and all its usages such as in exports, imports or within a type or value assignment.

For every item additional information is provided such as kind of item (identifier, value reference, type reference), and tag, associated type and value if applicable.

The cross-reference for a root module includes all modules referred to directly or indirectly via imports. The cross-references for the root modules MAP-Protocol/TCAPMessages and MAP-DialoguePDU are included.

TAG R4.81 Cross Reference Listing for MAP-Protocol 2000-07-19 08:07:06 PAGE 1

```
&extensionId.....identifier of Fieldspec
  DEFINED in MAP-ExtensionDataTypes : 24
  USED in MAP-ExtensionDataTypes : 41

&ExtensionType.....identifier of Fieldspec
  DEFINED in MAP-ExtensionDataTypes : 23
  USED in MAP-ExtensionDataTypes : 43

abort.....identifier of [APPLICATION 7] IMPLICIT Abort
  DEFINED in TCAPMessages : 56

Abort.....type reference SEQUENCE
  DEFINED in TCAPMessages : 74
  USED in TCAPMessages : 56

absentSubscriber.....value reference AbsentSubscriber, CHOICE VALUE
  DEFINED in MAP-Protocol : 344

AbsentSubscriber.....type reference ERROR
  DEFINED in MAP-Errors : 255
  USED in MAP-Protocol : 128 344
  USED in MAP-MobileServiceOpera : 80 328
  USED in MAP-CallHandlingOperat : 38 89 107 180
  USED in MAP-SupplementaryServi : 50 197 211
  USED in MAP-ShortMessageServic : 36
  USED in MAP-LocationServiceOpe : 28 63 79
  USED in MAP-Errors : 47

absentSubscriber.....identifier of Named Number, 1
  DEFINED in MAP-SM-DataTypes : 168

absentSubscriberDiagnosticSM.....identifier of [0] AbsentSubscriberDiagnosticSM
  DEFINED in MAP-SM-DataTypes : 147

absentSubscriberDiagnosticSM.....identifier of AbsentSubscriberDiagnosticSM
  DEFINED in MAP-ER-DataTypes : 146

AbsentSubscriberDiagnosticSM.....type reference INTEGER
  DEFINED in MAP-ER-DataTypes : 156
  USED in MAP-MS-DataTypes : 150 925
  USED in MAP-SM-DataTypes : 40 147 160
  USED in MAP-ER-DataTypes : 43 146 151

absentSubscriberParam.....identifier of AbsentSubscriberParam
  DEFINED in MAP-Errors : 257

AbsentSubscriberParam.....type reference SEQUENCE
  DEFINED in MAP-ER-DataTypes : 232
  USED in MAP-Errors : 115 257
  USED in MAP-ER-DataTypes : 34
```

absentSubscriberReason.....identifier of [0] AbsentSubscriberReason
DEFINED in MAP-ER-DataTypes : 235

AbsentSubscriberReason.....type reference ENUMERATED
DEFINED in MAP-ER-DataTypes : 237
USED in MAP-ER-DataTypes : 235

absentSubscriberSM.....value reference AbsentSubscriberSM, CHOICE VALUE
DEFINED in MAP-Protocol : 384

AbsentSubscriberSM.....type reference ERROR
DEFINED in MAP-Errors : 362
USED in MAP-Protocol : 149 384
USED in MAP-ShortMessageService : 41 80 110
USED in MAP-Errors : 74

absentSubscriberSM-Param.....identifier of AbsentSubscriberSM-Param
DEFINED in MAP-Errors : 364

AbsentSubscriberSM-Param.....type reference SEQUENCE
DEFINED in MAP-ER-DataTypes : 145
USED in MAP-Errors : 125 364
USED in MAP-ER-DataTypes : 42

accepted.....identifier of Named Number, 0
DEFINED in MAP-CH-DataTypes : 411

accessOutsideLSAsAllowed.....identifier of Named Number, 0
DEFINED in MAP-MS-DataTypes : 378

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 2

2000-07-19 08:07:06

```

accessOutsideLSAsRestricted.....identifier of Named Number, 1
  DEFINED in MAP-MS-DataTypes : 379

activateSS.....value reference ActivateSS, CHOICE VALUE
  DEFINED in MAP-Protocol : 231

ActivateSS.....type reference OPERATION
  DEFINED in MAP-SupplementaryServi : 121
    USED in MAP-Protocol : 64 231
    USED in MAP-SupplementaryServi : 15

activateTraceMode.....value reference ActivateTraceMode, CHOICE VALUE
  DEFINED in MAP-Protocol : 210

ActivateTraceMode.....type reference OPERATION
  DEFINED in MAP-OperationAndMainte : 50
    USED in MAP-Protocol : 41 210
    USED in MAP-OperationAndMainte : 13

activateTraceModeArg.....identifier of ActivateTraceModeArg
  DEFINED in MAP-OperationAndMainte : 52

ActivateTraceModeArg.....type reference SEQUENCE
  DEFINED in MAP-OM-DataTypes : 36
    USED in MAP-OperationAndMainte : 34 52
    USED in MAP-OM-DataTypes : 14

activateTraceModeRes.....identifier of ActivateTraceModeRes
  DEFINED in MAP-OperationAndMainte : 54

ActivateTraceModeRes.....type reference SEQUENCE
  DEFINED in MAP-OM-DataTypes : 50
    USED in MAP-OperationAndMainte : 35 54
    USED in MAP-OM-DataTypes : 15

additionalAbsentSubscriberDiagnosticSM..identifier of [5] AbsentSubscriberDiagnosticSM
  DEFINED in MAP-SM-DataTypes : 160

additionalAbsentSubscriberDiagnosticSM..identifier of [0] AbsentSubscriberDiagnosticSM
  DEFINED in MAP-ER-DataTypes : 151

additionalSignalInfo.....identifier of [17] Ext-ExternalSignalInfo
  DEFINED in MAP-CH-DataTypes : 107

additionalSignalInfo.....identifier of [14] Ext-ExternalSignalInfo
  DEFINED in MAP-CH-DataTypes : 197

additionalSM-DeliveryOutcome.....identifier of [4] SM-DeliveryOutcome
  DEFINED in MAP-SM-DataTypes : 157

additional-Number.....identifier of [6] Additional-Number
  DEFINED in MAP-SM-DataTypes : 93

Additional-Number.....type reference CHOICE
  DEFINED in MAP-SM-DataTypes : 97
  USED in MAP-SM-DataTypes : 93

AddressString.....type reference OCTET STRING
  DEFINED in MAP-CommonDataTypes : 88
    USED in MAP-CommonDataTypes : 16 132 332
    USED in MAP-OM-DataTypes : 21 40
    USED in MAP-SS-DataTypes : 44 72 276
    USED in MAP-SM-DataTypes : 31 55 135 140 145 179
    USED in MAP-LCS-DataTypes : 26 102

ageOfLocationEstimate.....identifier of [0] AgeOfLocationInformation
  DEFINED in MAP-LCS-DataTypes : 167

ageOfLocationEstimate.....identifier of [6] AgeOfLocationInformation
  DEFINED in MAP-LCS-DataTypes : 226

ageOfLocationInformation.....identifier of AgeOfLocationInformation
  DEFINED in MAP-MS-DataTypes : 1031

```

```
AgeOfLocationInformation.....type reference INTEGER
  DEFINED in MAP-CommonDataTypes   :    410
  USED in MAP-MS-DataTypes        :    135  1031
  USED in MAP-CommonDataTypes    :      51
  USED in MAP-LCS-DataTypes      :     32    167   226

alertingCategory-1.....value reference AlertingPattern, '00000100'B
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 3

2000-07-19 08:07:06

```

DEFINED in MAP-CommonDataTypes : 239

alertingCategory-2.....value reference AlertingPattern, '00000101'B
  DEFINED in MAP-CommonDataTypes : 240

alertingCategory-3.....value reference AlertingPattern, '00000110'B
  DEFINED in MAP-CommonDataTypes : 241

alertingCategory-4.....value reference AlertingPattern, '00000111'B
  DEFINED in MAP-CommonDataTypes : 242

alertingCategory-5.....value reference AlertingPattern, '00001000'B
  DEFINED in MAP-CommonDataTypes : 243

alertingLevel-0.....value reference AlertingPattern, '00000000'B
  DEFINED in MAP-CommonDataTypes : 233

alertingLevel-1.....value reference AlertingPattern, '00000001'B
  DEFINED in MAP-CommonDataTypes : 234

alertingLevel-2.....value reference AlertingPattern, '00000010'B
  DEFINED in MAP-CommonDataTypes : 235

AlertingPattern.....type reference OCTET STRING
  DEFINED in MAP-CommonDataTypes : 220
    USED in MAP-CommonDataTypes : 24 233 234 235 239 240 241 242 243
      USED in MAP-CH-DataTypes : 65 104 194 401
        USED in MAP-SS-DataTypes : 49 214

alertingPattern.....identifier of [14] AlertingPattern
  DEFINED in MAP-CH-DataTypes : 104

alertingPattern.....identifier of [12] AlertingPattern
  DEFINED in MAP-CH-DataTypes : 194

alertingPattern.....identifier of [5] AlertingPattern
  DEFINED in MAP-CH-DataTypes : 401

alertingPattern.....identifier of AlertingPattern
  DEFINED in MAP-SS-DataTypes : 214

alertReason.....identifier of AlertReason
  DEFINED in MAP-SM-DataTypes : 198

AlertReason.....type reference ENUMERATED
  DEFINED in MAP-SM-DataTypes : 210
    USED in MAP-SM-DataTypes : 27 198

alertReasonIndicator.....identifier of NULL
  DEFINED in MAP-SM-DataTypes : 199

alertServiceCentre.....value reference AlertServiceCentre, CHOICE VALUE
  DEFINED in MAP-Protocol : 251

AlertServiceCentre.....type reference OPERATION
  DEFINED in MAP-ShortMessageServic : 124
    USED in MAP-Protocol : 84 251
      USED in MAP-ShortMessageServic : 17

alertServiceCentreArg.....identifier of AlertServiceCentreArg
  DEFINED in MAP-ShortMessageServic : 126

AlertServiceCentreArg.....type reference SEQUENCE
  DEFINED in MAP-SM-DataTypes : 177
    USED in MAP-ShortMessageServic : 54 126
      USED in MAP-SM-DataTypes : 22

allAdditionalInfoTransferSS.....value reference SS-Code, '10000000'B
  DEFINED in MAP-SS-Code : 105

allAlternateSpeech-DataCDA.....value reference BearerServiceCode, '00110000'B
  DEFINED in MAP-BS-Code : 82

allAlternateSpeech-DataCDS.....value reference BearerServiceCode, '00111000'B
  DEFINED in MAP-BS-Code : 84

```

```
allAsynchronousServices.....value reference BearerServiceCode, '01100000'B  
DEFINED in MAP-BS-Code : 95  
  
allBarringSS.....value reference SS-Code, '10010000'B  
DEFINED in MAP-SS-Code : 115
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 4

allBearerServices.....	value reference BearerServiceCode, '00000000'B
DEFINED in MAP-BS-Code	: 49
allCallCompletionSS.....	value reference SS-Code, '01000000'B
DEFINED in MAP-SS-Code	: 72
allCallOfferingSS.....	value reference SS-Code, '00110000'B
DEFINED in MAP-SS-Code	: 63
allCallPrioritySS.....	value reference SS-Code, '10100000'B
DEFINED in MAP-SS-Code	: 151
allChargingSS.....	value reference SS-Code, '01110000'B
DEFINED in MAP-SS-Code	: 97
allCommunityOfInterest-SS.....	value reference SS-Code, '01100000'B
DEFINED in MAP-SS-Code	: 91
allCondForwardingSS.....	value reference SS-Code, '00101000'B
DEFINED in MAP-SS-Code	: 52
allDataCDA-Services.....	value reference BearerServiceCode, '00010000'B
DEFINED in MAP-BS-Code	: 51
allDataCDS-Services.....	value reference BearerServiceCode, '00011000'B
DEFINED in MAP-BS-Code	: 60
allDataCircuitAsynchronous.....	value reference BearerServiceCode, '01010000'B
DEFINED in MAP-BS-Code	: 92
allDataCircuitSynchronous.....	value reference BearerServiceCode, '01011000'B
DEFINED in MAP-BS-Code	: 98
allDataPDS-Services.....	value reference BearerServiceCode, '00101000'B
DEFINED in MAP-BS-Code	: 76
allDataTeleservices.....	value reference TeleserviceCode, '01110000'B
DEFINED in MAP-TS-Code	: 55
allECT-Barred.....	identifier of Named Number, 9
DEFINED in MAP-MS-DataTypes	: 462
allFacsimileTransmissionServices.....	value reference TeleserviceCode, '01100000'B
DEFINED in MAP-TS-Code	: 48
allForwardingSS.....	value reference SS-Code, '00100000'B
DEFINED in MAP-SS-Code	: 48
allGPRSData.....	identifier of NULL
DEFINED in MAP-MS-DataTypes	: 757
allInformationSent.....	identifier of [11] NULL
DEFINED in MAP-CH-DataTypes	: 216
allLCSPrivacyException.....	value reference SS-Code, '10110000'B
DEFINED in MAP-SS-Code	: 157
allLineIdentificationSS.....	value reference SS-Code, '00010000'B
DEFINED in MAP-SS-Code	: 25
allLSAData.....	identifier of NULL
DEFINED in MAP-MS-DataTypes	: 764
allMOLR-SS.....	value reference SS-Code, '11000000'B
DEFINED in MAP-SS-Code	: 170
allMultiPartySS.....	value reference SS-Code, '01010000'B
DEFINED in MAP-SS-Code	: 85
allNameIdentificationSS.....	value reference SS-Code, '00011000'B
DEFINED in MAP-SS-Code	: 40
allOG-CallsBarred.....	identifier of Named Number, 0
DEFINED in MAP-MS-DataTypes	: 453

```
allPadAccessCA-Services.....value reference BearerServiceCode, '00100000'B  
      DEFINED in MAP-BS-Code           :      67  
  
allPLMN-specificBS.....value reference BearerServiceCode, '11010000'B  
      DEFINED in MAP-BS-Code           :     110  
  
allPLMN-specificSS.....value reference SS-Code, '11110000'B
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 5

DEFINED in MAP-SS-Code	:	134
allPLMN-specificTS	value reference TeleserviceCode, '11010000'B
DEFINED in MAP-TS-Code	:	72
allShortMessageServices	value reference TeleserviceCode, '00100000'B
DEFINED in MAP-TS-Code	:	44
allSpeechFollowedByDataCDA	value reference BearerServiceCode, '01000000'B
DEFINED in MAP-BS-Code	:	86
allSpeechFollowedByDataCDS	value reference BearerServiceCode, '01001000'B
DEFINED in MAP-BS-Code	:	88
allSpeechTransmissionServices	value reference TeleserviceCode, '00010000'B
DEFINED in MAP-TS-Code	:	40
allSS	value reference SS-Code, '00000000'B
DEFINED in MAP-SS-Code	:	21
allSynchronousServices	value reference BearerServiceCode, '01101000'B
DEFINED in MAP-BS-Code	:	101
allTeleservices	value reference TeleserviceCode, '00000000'B
DEFINED in MAP-TS-Code	:	38
allTeleservices-ExptSMS	value reference TeleserviceCode, '10000000'B
DEFINED in MAP-TS-Code	:	58
allVoiceGroupCallServices	value reference TeleserviceCode, '10010000'B
DEFINED in MAP-TS-Code	:	67
anonymousLocation	identifier of Named Number, 3
DEFINED in MAP-CommonDataTypes	:	340
anyTimeInterrogation	value reference AnyTimeInterrogation, CHOICE VALUE
DEFINED in MAP-Protocol	:	260
AnyTimeInterrogation	type reference OPERATION
DEFINED in MAP-MobileServiceOpera	:	202
USED in MAP-Protocol	:	30 260
USED in MAP-MobileServiceOpera	:	27
anyTimeInterrogationArg	identifier of AnyTimeInterrogationArg
DEFINED in MAP-MobileServiceOpera	:	204
AnyTimeInterrogationArg	type reference SEQUENCE
DEFINED in MAP-MS-DataTypes	:	1066
USED in MAP-MobileServiceOpera	:	110 204
USED in MAP-MS-DataTypes	:	79
anyTimeInterrogationRes	identifier of AnyTimeInterrogationRes
DEFINED in MAP-MobileServiceOpera	:	206
AnyTimeInterrogationRes	type reference SEQUENCE
DEFINED in MAP-MS-DataTypes	:	1073
USED in MAP-MobileServiceOpera	:	111 206
USED in MAP-MS-DataTypes	:	80
aocc	value reference SS-Code, '01110010'B
DEFINED in MAP-SS-Code	:	102
aoci	value reference SS-Code, '01110001'B
DEFINED in MAP-SS-Code	:	100
apn	identifier of [20] APN
DEFINED in MAP-MS-DataTypes	:	344
APN	type reference OCTET STRING
DEFINED in MAP-MS-DataTypes	:	359
USED in MAP-MS-DataTypes	:	344
asciCallReference	identifier of ASCII-CallReference
DEFINED in MAP-GR-DataTypes	:	51

```
ASCI-CallReference.....type reference TBCD-STRING
  DEFINED in MAP-CommonDataTypes   :    263
  USED in MAP-CommonDataTypes     :     38
  USED in MAP-GR-DataTypes        :    26      51

assumedIdle.....identifier of [0] NULL
  DEFINED in MAP-MS-DataTypes     : 1053
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 6

```

ati-NotAllowed.....value reference ATI-NotAllowed, CHOICE VALUE
  DEFINED in MAP-Protocol : 355

ATI-NotAllowed.....type reference ERROR
  DEFINED in MAP-Errors : 299
  USED in MAP-Protocol : 135 355
  USED in MAP-MobileServiceOpera : 77 209
  USED in MAP-Errors : 54

ati-NotAllowedParam.....identifier of ATI-NotAllowedParam
  DEFINED in MAP-Errors : 301

ATI-NotAllowedParam.....type reference SEQUENCE
  DEFINED in MAP-ER-DataTypes : 263
  USED in MAP-Errors : 122 301
  USED in MAP-ER-DataTypes : 39

AuthenticationSet.....type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes : 223
  USED in MAP-MS-DataTypes : 221

authenticationSetList.....identifier of AuthenticationSetList
  DEFINED in MAP-MS-DataTypes : 217

AuthenticationSetList.....type reference SEQUENCE OF
  DEFINED in MAP-MS-DataTypes : 220
  USED in MAP-MS-DataTypes : 217 281

automaticFacsimileGroup3.....value reference TeleserviceCode, '01100010'B
  DEFINED in MAP-TS-Code : 50

autonomousSelfLocation.....value reference SS-Code, '11000010'B
  DEFINED in MAP-SS-Code : 174

a-side.....identifier of Named Number, 0
  DEFINED in MAP-CH-DataTypes : 374

badlyFormattedTransactionPortion.....identifier of Named Number, 2
  DEFINED in TCAPMessages : 105

badlyStructuredComponent.....identifier of Named Number, 2
  DEFINED in TCAPMessages : 181

baic.....value reference SS-Code, '10011010'B
  DEFINED in MAP-SS-Code : 128

baoc.....value reference SS-Code, '10010010'B
  DEFINED in MAP-SS-Code : 119

barringOfIncomingCalls.....value reference SS-Code, '10011001'B
  DEFINED in MAP-SS-Code : 126

barringOfOutgoingCalls.....value reference SS-Code, '10010001'B
  DEFINED in MAP-SS-Code : 117

barringServiceActive.....identifier of Named Number, 0
  DEFINED in MAP-ER-DataTypes : 98

basicCall.....identifier of Named Number, 0
  DEFINED in MAP-CH-DataTypes : 112

basicSelfLocation.....value reference SS-Code, '11000001'B
  DEFINED in MAP-SS-Code : 172

basicService.....identifier of Ext-BasicServiceCode
  DEFINED in MAP-MS-DataTypes : 500

basicService.....identifier of Ext-BasicServiceCode
  DEFINED in MAP-MS-DataTypes : 579

basicService.....identifier of Ext-BasicServiceCode
  DEFINED in MAP-MS-DataTypes : 622

basicService.....identifier of [5] Ext-BasicServiceCode

```

DEFINED in MAP-CH-DataTypes : 140
basicService..... identifier of BasicServiceCode
DEFINED in MAP-SS-DataTypes : 71
basicService..... identifier of BasicServiceCode
DEFINED in MAP-SS-DataTypes : 95

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 7 2000-07-19 08:07:06

```

basicService..... identifier of BasicServiceCode
  DEFINED in MAP-SS-DataTypes : 151

basicService..... identifier of BasicServiceCode
  DEFINED in MAP-SS-DataTypes : 179

basicService..... identifier of BasicServiceCode
  DEFINED in MAP-ER-DataTypes : 120

BasicServiceCode..... type reference CHOICE
  DEFINED in MAP-CommonDataTypes : 379
    USED in MAP-CommonDataTypes : 45
    USED in MAP-SS-DataTypes : 48 71 95 151 179 199 254
    USED in MAP-ER-DataTypes : 64 120

basicServiceCriteria..... identifier of [1] BasicServiceCriteria
  DEFINED in MAP-MS-DataTypes : 855

BasicServiceCriteria..... type reference SEQUENCE OF
  DEFINED in MAP-MS-DataTypes : 875
    USED in MAP-MS-DataTypes : 57 855
    USED in MAP-CH-DataTypes : 42

basicServiceGroup..... identifier of [9] Ext-BasicServiceCode
  DEFINED in MAP-CH-DataTypes : 98

basicServiceGroup..... identifier of [1] Ext-BasicServiceCode
  DEFINED in MAP-CH-DataTypes : 207

basicServiceGroup..... identifier of [3] BasicServiceCode
  DEFINED in MAP-SS-DataTypes : 199

basicServiceGroupList..... identifier of Ext-BasicServiceGroupList
  DEFINED in MAP-MS-DataTypes : 597

basicServiceGroupList..... identifier of Ext-BasicServiceGroupList
  DEFINED in MAP-MS-DataTypes : 644

basicServiceGroupList..... identifier of BasicServiceGroupList
  DEFINED in MAP-SS-DataTypes : 159

basicServiceGroupList..... identifier of [2] BasicServiceGroupList
  DEFINED in MAP-SS-DataTypes : 206

BasicServiceGroupList..... type reference SEQUENCE OF
  DEFINED in MAP-SS-DataTypes : 253
    USED in MAP-SS-DataTypes : 159 206

basicServiceList..... identifier of [1] BasicServiceList
  DEFINED in MAP-MS-DataTypes : 740

BasicServiceList..... type reference SEQUENCE OF
  DEFINED in MAP-MS-DataTypes : 770
    USED in MAP-MS-DataTypes : 740

bearerService..... identifier of [2] BearerServiceCode
  DEFINED in MAP-CommonDataTypes : 380

BearerServiceCode..... type reference OCTET STRING
  DEFINED in MAP-BS-Code : 11
    USED in MAP-CommonDataTypes : 63 380
      USED in MAP-BS-Code : 49 51 52 53 54 55 56 57 58
        60 61 62 63 64 65 67 68 69
        70 71 72 73 74 76 77 78 79
        80 82 84 86 88 92 95 98 101
        110 111 112 113 114 115 116 117 118
        119 120 121 122 123 124 125

bearerServiceList..... identifier of [4] BearerServiceList
  DEFINED in MAP-MS-DataTypes : 414

BearerServiceList..... type reference SEQUENCE OF
  DEFINED in MAP-MS-DataTypes : 436
    USED in MAP-MS-DataTypes : 414 723

```

bearerServiceList.....identifier of [2] BearerServiceList
DEFINED in MAP-MS-DataTypes : 723

bearerServiceNotProvisioned.....value reference BearerServiceNotProvisioned, CHOICE
VALUE
DEFINED in MAP-Protocol : 322

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 8

BearerServiceNotProvisioned.....	type reference	ERROR		2000-07-19 08:07:06
DEFINED in MAP-Errors	:	220		
USED in MAP-Protocol	:	121 322		
USED in MAP-CallHandlingOperat	:	35 87		
USED in MAP-SupplementaryServ	:	37 97 114 131 151 169		
USED in MAP-Errors	:	32		
bearerServNotProvParam.....	identifier of	BearerServNotProvParam		
DEFINED in MAP-Errors	:	222		
BearerServNotProvParam.....	type reference	SEQUENCE		
DEFINED in MAP-ER-DataTypes	:	216		
USED in MAP-Errors	:	110 222		
USED in MAP-ER-DataTypes	:	30		
begin.....	identifier of	[APPLICATION 2] IMPLICIT Begin		
DEFINED in TCAPMessages	:	53		
Begin.....	type reference	SEQUENCE		
DEFINED in TCAPMessages	:	61		
USED in TCAPMessages	:	53		
bicRoam.....	value reference	SS-Code, '10011011'B		
DEFINED in MAP-SS-Code	:	130		
blackListed.....	identifier of	Named Number, 1		
DEFINED in MAP-MS-DataTypes	:	288		
boic.....	value reference	SS-Code, '10010011'B		
DEFINED in MAP-SS-Code	:	121		
boicExHC.....	value reference	SS-Code, '10010100'B		
DEFINED in MAP-SS-Code	:	123		
bothMSCAndSGSN.....	identifier of	Named Number, 0		
DEFINED in MAP-MS-DataTypes	:	326		
broadcastInitEntitlement.....	identifier of	NULL		
DEFINED in MAP-MS-DataTypes	:	996		
broadcastService.....	identifier of	Named Number, 0		
DEFINED in MAP-CommonDataTypes	:	337		
bss-APDU.....	identifier of	ExternalSignalInfo		
DEFINED in MAP-MobileServiceOpera	:	229		
bss-APDU.....	identifier of	ExternalSignalInfo		
DEFINED in MAP-MobileServiceOpera	:	234		
bss-APDU.....	identifier of	ExternalSignalInfo		
DEFINED in MAP-MobileServiceOpera	:	238		
bss-APDU.....	identifier of	ExternalSignalInfo		
DEFINED in MAP-MobileServiceOpera	:	244		
bss-APDU.....	identifier of	ExternalSignalInfo		
DEFINED in MAP-MS-DataTypes	:	263		
bss-APDU.....	identifier of	ExternalSignalInfo		
DEFINED in MAP-MS-DataTypes	:	268		
bss-APDU.....	identifier of	ExternalSignalInfo		
DEFINED in MAP-MS-DataTypes	:	274		
busy.....	identifier of	Named Number, 1		
DEFINED in MAP-CH-DataTypes	:	121		
busy.....	identifier of	Named Number, 2		
DEFINED in MAP-CH-DataTypes	:	384		
busySubscriber.....	value reference	BusySubscriber, CHOICE VALUE		
DEFINED in MAP-Protocol	:	345		
BusySubscriber.....	type reference	ERROR		
DEFINED in MAP-Errors	:	262		

USED in MAP-Protocol	:	129	345	
USED in MAP-CallHandlingOperat	:	39	90	182
USED in MAP-Errors	:	45		
busySubscriberParam.....	identifier of BusySubscriberParam		
DEFINED in MAP-Errors	:	264		

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 9

BusySubscriberParam.....	type reference SEQUENCE		2000-07-19 08:07:06
DEFINED in MAP-ER-DataTypes	: 245		
USED in MAP-Errors	: 116 264		
USED in MAP-ER-DataTypes	: 35		
b-side.....	identifier of Named Number, 1		
DEFINED in MAP-CH-DataTypes	: 375		
b-subscriberNumber.....	identifier of [1] ISDN-AddressString		
DEFINED in MAP-SS-DataTypes	: 197		
b-subscriberSubaddress.....	identifier of [2] ISDN-SubaddressString		
DEFINED in MAP-SS-DataTypes	: 198		
b-Subscriber-Address.....	identifier of [3] ISDN-AddressString		
DEFINED in MAP-CH-DataTypes	: 294		
callBarred.....	value reference CallBarred, CHOICE VALUE		
DEFINED in MAP-Protocol	: 347		
CallBarred.....	type reference ERROR		
DEFINED in MAP-Errors	: 272		
USED in MAP-Protocol	: 131 347		
USED in MAP-CallHandlingOperat	: 41 92		
USED in MAP-SupplementaryServi	: 39 99 116 133 153 171 185 226 260		
277			
USED in MAP-ShortMessageServic	: 37 79		
USED in MAP-Errors	: 48		
callBarredParam.....	identifier of CallBarredParam		
DEFINED in MAP-Errors	: 274		
CallBarredParam.....	type reference CHOICE		
DEFINED in MAP-ER-DataTypes	: 90		
USED in MAP-Errors	: 118 274		
USED in MAP-ER-DataTypes	: 15		
callBarringCause.....	identifier of CallBarringCause		
DEFINED in MAP-ER-DataTypes	: 91		
CallBarringCause.....	type reference ENUMERATED		
DEFINED in MAP-ER-DataTypes	: 97		
USED in MAP-ER-DataTypes	: 91 102		
callBarringCause.....	identifier of CallBarringCause		
DEFINED in MAP-ER-DataTypes	: 102		
CallBarringFeature.....	type reference SEQUENCE		
DEFINED in MAP-SS-DataTypes	: 150		
USED in MAP-SS-DataTypes	: 148		
callBarringFeatureList.....	identifier of Ext-CallBarFeatureList		
DEFINED in MAP-MS-DataTypes	: 571		
callBarringFeatureList.....	identifier of CallBarringFeatureList		
DEFINED in MAP-SS-DataTypes	: 144		
CallBarringFeatureList.....	type reference SEQUENCE OF		
DEFINED in MAP-SS-DataTypes	: 147		
USED in MAP-SS-DataTypes	: 144		
callBarringInfo.....	identifier of [1] Ext-CallBarInfo		
DEFINED in MAP-MS-DataTypes	: 484		
callBarringInfo.....	identifier of [1] CallBarringInfo		
DEFINED in MAP-SS-DataTypes	: 82		
CallBarringInfo.....	type reference SEQUENCE		
DEFINED in MAP-SS-DataTypes	: 142		
USED in MAP-SS-DataTypes	: 82		
CallDirection.....	type reference OCTET STRING		
DEFINED in MAP-CH-DataTypes	: 301		
USED in MAP-CH-DataTypes	: 293		

```
calledPartySS-InteractionViolation.....identifier of Named Number, 7
    DEFINED in MAP-ER-DataTypes      :     116

callInfo.....identifier of [1] ExternalSignalInfo
    DEFINED in MAP-CH-DataTypes      :     397

callInfo.....identifier of [3] ExternalSignalInfo
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 10

DEFINED in MAP-SS-DataTypes	:	289
callOutcome.....	identifier of [1] CallOutcome
DEFINED in MAP-CH-DataTypes	:	369
CallOutcome.....	type reference ENUMERATED
DEFINED in MAP-CH-DataTypes	:	381
USED in MAP-CH-DataTypes	:	369
callReferenceNumber.....	identifier of [7] CallReferenceNumber
DEFINED in MAP-CH-DataTypes	:	96
CallReferenceNumber.....	type reference OCTET STRING
DEFINED in MAP-CH-DataTypes	:	117
USED in MAP-CH-DataTypes	:	22 96 190 206
callReferenceNumber.....	identifier of [9] CallReferenceNumber
DEFINED in MAP-CH-DataTypes	:	190
callReferenceNumber.....	identifier of [0] CallReferenceNumber
DEFINED in MAP-CH-DataTypes	:	206
callrelated.....	value reference SS-Code, '10110010'B
DEFINED in MAP-SS-Code	:	161
callReportdata.....	identifier of [2] CallReportData
DEFINED in MAP-CH-DataTypes	:	358
CallReportData.....	type reference SEQUENCE
DEFINED in MAP-CH-DataTypes	:	367
USED in MAP-CH-DataTypes	:	358
callToClientNotSetup.....	identifier of Named Number, 2
DEFINED in MAP-ER-DataTypes	:	308
callTypeCriteria.....	identifier of [2] CallTypeCriteria
DEFINED in MAP-MS-DataTypes	:	856
CallTypeCriteria.....	type reference ENUMERATED
DEFINED in MAP-MS-DataTypes	:	886
USED in MAP-MS-DataTypes	:	856
callunrelated.....	value reference SS-Code, '10110011'B
DEFINED in MAP-SS-Code	:	164
call-Direction.....	identifier of [2] CallDirection
DEFINED in MAP-CH-DataTypes	:	293
camelBusy.....	identifier of [1] NULL
DEFINED in MAP-MS-DataTypes	:	1054
camelCapabilityHandling.....	identifier of [0] CamelCapabilityHandling
DEFINED in MAP-MS-DataTypes	:	815
CamelCapabilityHandling.....	type reference INTEGER
DEFINED in MAP-MS-DataTypes	:	903
USED in MAP-MS-DataTypes	:	56 815
USED in MAP-CH-DataTypes	:	41 264
camelCapabilityHandling.....	identifier of [0] CamelCapabilityHandling
DEFINED in MAP-CH-DataTypes	:	264
camelInfo.....	identifier of [11] CamelInfo
DEFINED in MAP-CH-DataTypes	:	100
CamelInfo.....	type reference SEQUENCE
DEFINED in MAP-CH-DataTypes	:	236
USED in MAP-CH-DataTypes	:	100
camelRoutingInfo.....	identifier of [8] CamelRoutingInfo
DEFINED in MAP-CH-DataTypes	:	244
CamelRoutingInfo.....	type reference SEQUENCE
DEFINED in MAP-CH-DataTypes	:	246
USED in MAP-CH-DataTypes	:	244

camelSubscriptionInfoWithdraw.....identifier of [9] NULL
DEFINED in MAP-MS-DataTypes : 748

camel-invoked.....identifier of Named Number, 1
DEFINED in MAP-SS-DataTypes : 295

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 11

cancellationType.....	identifier of CancellationType	
DEFINED in MAP-MS-DataTypes	:	186
CancellationType.....	type reference ENUMERATED	
DEFINED in MAP-MS-DataTypes	:	191
USED in MAP-MS-DataTypes	:	186
cancelLocation.....	value reference CancelLocation, CHOICE VALUE	
DEFINED in MAP-Protocol	:	169
CancelLocation.....	type reference OPERATION	
DEFINED in MAP-MobileServiceOpera	:	146
USED in MAP-Protocol	:	13 169
USED in MAP-MobileServiceOpera	:	16
cancelLocationArg.....	identifier of CancelLocationArg	
DEFINED in MAP-MobileServiceOpera	:	148
CancelLocationArg.....	type reference [3] SEQUENCE	
DEFINED in MAP-MS-DataTypes	:	184
USED in MAP-MobileServiceOpera	:	88 148
USED in MAP-MS-DataTypes	:	18
cancelLocationRes.....	identifier of CancelLocationRes	
DEFINED in MAP-MobileServiceOpera	:	150
CancelLocationRes.....	type reference SEQUENCE	
DEFINED in MAP-MS-DataTypes	:	198
USED in MAP-MobileServiceOpera	:	89 150
USED in MAP-MS-DataTypes	:	19
category.....	identifier of [2] Category	
DEFINED in MAP-MS-DataTypes	:	412
Category.....	type reference OCTET STRING	
DEFINED in MAP-MS-DataTypes	:	429
USED in MAP-MS-DataTypes	:	412
ccbsIdle.....	identifier of Named Number, 1	
DEFINED in MAP-CH-DataTypes	:	347
ccbsNotIdle.....	identifier of Named Number, 0	
DEFINED in MAP-CH-DataTypes	:	346
ccbsNotReachable.....	identifier of Named Number, 2	
DEFINED in MAP-CH-DataTypes	:	348
ccbs-A.....	value reference SS-Code, '01000011'B	
DEFINED in MAP-SS-Code	:	79
ccbs-B.....	value reference SS-Code, '01000100'B	
DEFINED in MAP-SS-Code	:	81
ccbs-Busy.....	identifier of [1] NULL	
DEFINED in MAP-ER-DataTypes	:	249
ccbs-Call.....	identifier of [15] NULL	
DEFINED in MAP-CH-DataTypes	:	105
ccbs-Call.....	identifier of [13] NULL	
DEFINED in MAP-CH-DataTypes	:	195
ccbs-Data.....	identifier of [1] CCBS-Data	
DEFINED in MAP-SS-DataTypes	:	282
CCBS-Data.....	type reference SEQUENCE	
DEFINED in MAP-SS-DataTypes	:	285
USED in MAP-SS-DataTypes	:	282
ccbs-Feature.....	identifier of [2] CCBS-Feature	
DEFINED in MAP-CH-DataTypes	:	398
CCBS-Feature.....	type reference SEQUENCE	
DEFINED in MAP-SS-DataTypes	:	195
USED in MAP-CH-DataTypes	:	53 398

USED in MAP-SS-DataTypes	:	36	191	286	300
ccbs-Feature.....	identifier of [0]	CCBS-Feature		
DEFINED in MAP-SS-DataTypes	:	286			
ccbs-Feature.....	identifier of [0]	CCBS-Feature		
DEFINED in MAP-SS-DataTypes	:	300			

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 12 2000-07-19 08:07:06

```

ccbs-FeatureList..... identifier of [2] CCBS-FeatureList
  DEFINED in MAP-SS-DataTypes : 188

CCBS-FeatureList..... type reference SEQUENCE OF
  DEFINED in MAP-SS-DataTypes : 190
  USED in MAP-SS-DataTypes : 188

ccbs-Index..... identifier of [0] CCBS-Index
  DEFINED in MAP-SS-DataTypes : 196

CCBS-Index..... type reference INTEGER
  DEFINED in MAP-SS-DataTypes : 202
  USED in MAP-SS-DataTypes : 196 305

ccbs-Index..... identifier of [1] CCBS-Index
  DEFINED in MAP-SS-DataTypes : 305

ccbs-Indicators..... identifier of [11] CCBS-Indicators
  DEFINED in MAP-CH-DataTypes : 147

CCBS-Indicators..... type reference SEQUENCE
  DEFINED in MAP-CH-DataTypes : 161
  USED in MAP-CH-DataTypes : 147

ccbs-Monitoring..... identifier of [2] ReportingState
  DEFINED in MAP-CH-DataTypes : 328

ccbs-Possible..... identifier of [0] NULL
  DEFINED in MAP-CH-DataTypes : 162

ccbs-Possible..... identifier of [8] NULL
  DEFINED in MAP-CH-DataTypes : 213

ccbs-Possible..... identifier of [0] NULL
  DEFINED in MAP-ER-DataTypes : 248

ccbs-SubscriberStatus..... identifier of [0] CCBS-SubscriberStatus
  DEFINED in MAP-CH-DataTypes : 341

CCBS-SubscriberStatus..... type reference ENUMERATED
  DEFINED in MAP-CH-DataTypes : 345
  USED in MAP-CH-DataTypes : 341 363

ccbs-SubscriberStatus..... identifier of [0] CCBS-SubscriberStatus
  DEFINED in MAP-CH-DataTypes : 363

cd..... value reference SS-Code, '00100100'B
  DEFINED in MAP-SS-Code : 60

cellIdFixedLength..... identifier of [0] CellIdFixedLength
  DEFINED in MAP-CommonDataTypes : 348

CellIdFixedLength..... type reference OCTET STRING
  DEFINED in MAP-CommonDataTypes : 351
  USED in MAP-CommonDataTypes : 348

cellIdOrLAI..... identifier of [3] CellIdOrLAI
  DEFINED in MAP-MS-DataTypes : 1035

CellIdOrLAI..... type reference CHOICE
  DEFINED in MAP-CommonDataTypes : 347
  USED in MAP-MS-DataTypes : 130 1035
  USED in MAP-CommonDataTypes : 42

cfb..... value reference SS-Code, '00101001'B
  DEFINED in MAP-SS-Code : 54

cfnrc..... value reference SS-Code, '00101011'B
  DEFINED in MAP-SS-Code : 58

cfnry..... value reference SS-Code, '00101010'B
  DEFINED in MAP-SS-Code : 56

cfu..... value reference SS-Code, '00100001'B

```

DEFINED in MAP-SS-Code : 50
channelType.....identifier of [0] ExternalSignalInfo
 DEFINED in MAP-CH-DataTypes : 315
chargeableECT-Barred.....identifier of Named Number, 10
 DEFINED in MAP-MS-DataTypes : 463

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 13 2000-07-19 08:07:06

```

checkIMEI.....value reference CheckIMEI, CHOICE VALUE
  DEFINED in MAP-Protocol : 191

CheckIMEI.....type reference OPERATION
  DEFINED in MAP-MobileServiceOpera : 267
    USED in MAP-Protocol : 23 191
    USED in MAP-MobileServiceOpera : 40

chosenChannel.....identifier of [4] ExternalSignalInfo
  DEFINED in MAP-CH-DataTypes : 295

chosenChannel.....identifier of [1] ExternalSignalInfo
  DEFINED in MAP-CH-DataTypes : 316

chosenChannel.....identifier of [0] ExternalSignalInfo
  DEFINED in MAP-CH-DataTypes : 321

cipheringAlgorithm.....identifier of CipheringAlgorithm
  DEFINED in MAP-GR-DataTypes : 53

CipheringAlgorithm.....type reference OCTET STRING
  DEFINED in MAP-GR-DataTypes : 99
    USED in MAP-GR-DataTypes : 53

clientIdentity.....identifier of LCSClientExternalID
  DEFINED in MAP-MS-DataTypes : 679

clientNotInMSPrivacyExceptionList.....identifier of Named Number, 1
  DEFINED in MAP-ER-DataTypes : 307

clip.....value reference SS-Code, '00010001'B
  DEFINED in MAP-SS-Code : 28

clir.....value reference SS-Code, '00010010'B
  DEFINED in MAP-SS-Code : 30

cliRestrictionOption.....identifier of [2] CliRestrictionOption
  DEFINED in MAP-SS-DataTypes : 165

CliRestrictionOption.....type reference ENUMERATED
  DEFINED in MAP-SS-DataTypes : 168
    USED in MAP-SS-DataTypes : 29 165 184

cliRestrictionOption.....identifier of CliRestrictionOption
  DEFINED in MAP-SS-DataTypes : 184

clir-invoked.....identifier of Named Number, 0
  DEFINED in MAP-SS-DataTypes : 294

cnap.....value reference SS-Code, '00011001'B
  DEFINED in MAP-SS-Code : 42

codec-Info.....identifier of CODEC-Info
  DEFINED in MAP-GR-DataTypes : 52

CODEC-Info.....type reference OCTET STRING
  DEFINED in MAP-GR-DataTypes : 94
    USED in MAP-GR-DataTypes : 52

collectedInfo.....identifier of Named Number, 2
  DEFINED in MAP-MS-DataTypes : 839

colp.....value reference SS-Code, '00010011'B
  DEFINED in MAP-SS-Code : 32

colr.....value reference SS-Code, '00010100'B
  DEFINED in MAP-SS-Code : 34

completeDataListIncluded.....identifier of NULL
  DEFINED in MAP-MS-DataTypes : 351

completeDataListIncluded.....identifier of NULL
  DEFINED in MAP-MS-DataTypes : 394

```

Component.....	type reference CHOICE
DEFINED in TCAPMessages	: 124
USED in TCAPMessages	: 47 115
ComponentPortion.....	type reference [APPLICATION 12] IMPLICIT SEQUENCE OF
DEFINED in TCAPMessages	: 115
USED in TCAPMessages	: 59 63 67 72

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 14 2000-07-19 08:07:06

```

components.....identifier of ComponentPortion
  DEFINED in TCAPMessages : 59

components.....identifier of ComponentPortion
  DEFINED in TCAPMessages : 63

components.....identifier of ComponentPortion
  DEFINED in TCAPMessages : 67

components.....identifier of ComponentPortion
  DEFINED in TCAPMessages : 72

congestion.....identifier of Named Number, 0
  DEFINED in MAP-ER-DataTypes : 321

ContextId.....type reference INTEGER
  DEFINED in MAP-MS-DataTypes : 348
  USED in MAP-MS-DataTypes : 339 761

contextIdList.....identifier of ContextIdList
  DEFINED in MAP-MS-DataTypes : 758

ContextIdList.....type reference SEQUENCE OF
  DEFINED in MAP-MS-DataTypes : 760
  USED in MAP-MS-DataTypes : 758

Continue.....type reference SEQUENCE
  DEFINED in TCAPMessages : 69
  USED in TCAPMessages : 55

continueCall.....identifier of Named Number, 0
  DEFINED in MAP-MS-DataTypes : 896

continue-ME.....identifier of [APPLICATION 5] IMPLICIT Continue
  DEFINED in TCAPMessages : 55

controllingMSC.....identifier of Named Number, 4
  DEFINED in MAP-CommonDataTypes : 309

cug.....value reference SS-Code, '01100001'B
  DEFINED in MAP-SS-Code : 94

cugIC-CallBarred.....identifier of Named Number, 1
  DEFINED in MAP-MS-DataTypes : 608

cugOG-CallBarred.....identifier of Named Number, 2
  DEFINED in MAP-MS-DataTypes : 609

cugSubscriptionFlag.....identifier of [6] NULL
  DEFINED in MAP-CH-DataTypes : 137

CUG-CheckInfo.....type reference SEQUENCE
  DEFINED in MAP-CH-DataTypes : 80
  USED in MAP-CH-DataTypes : 90 136 210

cug-CheckInfo.....identifier of [1] CUG-CheckInfo
  DEFINED in MAP-CH-DataTypes : 90

cug-CheckInfo.....identifier of [3] CUG-CheckInfo
  DEFINED in MAP-CH-DataTypes : 136

cug-CheckInfo.....identifier of [4] CUG-CheckInfo
  DEFINED in MAP-CH-DataTypes : 210

CUG-Feature.....type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes : 621
  USED in MAP-MS-DataTypes : 614

cug-FeatureList.....identifier of CUG-FeatureList
  DEFINED in MAP-MS-DataTypes : 586

CUG-FeatureList.....type reference SEQUENCE OF
  DEFINED in MAP-MS-DataTypes : 613
  USED in MAP-MS-DataTypes : 586

```

cug-Index.....identifier of CUG-Index
DEFINED in MAP-MS-DataTypes : 594

CUG-Index.....type reference INTEGER
DEFINED in MAP-MS-DataTypes : 601
USED in MAP-MS-DataTypes : 60 594 623

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 15 2000-07-19 08:07:06

```

cug-Info..... identifier of [2] CUG-Info
  DEFINED in MAP-MS-DataTypes : 485

CUG-Info..... type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes : 584
  USED in MAP-MS-DataTypes : 485

cug-Interlock..... identifier of CUG-Interlock
  DEFINED in MAP-MS-DataTypes : 595

CUG-Interlock..... type reference OCTET STRING
  DEFINED in MAP-MS-DataTypes : 604
  USED in MAP-MS-DataTypes : 61 595
  USED in MAP-CH-DataTypes : 43 81

cug-Interlock..... identifier of CUG-Interlock
  DEFINED in MAP-CH-DataTypes : 81

cug-OutgoingAccess..... identifier of NULL
  DEFINED in MAP-CH-DataTypes : 82

cug-Reject..... value reference CUG-Reject, CHOICE VALUE
  DEFINED in MAP-Protocol : 351

CUG-Reject..... type reference ERROR
  DEFINED in MAP-Errors : 287
  USED in MAP-Protocol : 134 351
  USED in MAP-CallHandlingOperat : 44 93
  USED in MAP-Errors : 51

cug-RejectCause..... identifier of CUG-RejectCause
  DEFINED in MAP-ER-DataTypes : 108

CUG-RejectCause..... type reference ENUMERATED
  DEFINED in MAP-ER-DataTypes : 112
  USED in MAP-ER-DataTypes : 108

cug-RejectParam..... identifier of CUG-RejectParam
  DEFINED in MAP-Errors : 289

CUG-RejectParam..... type reference SEQUENCE
  DEFINED in MAP-ER-DataTypes : 107
  USED in MAP-Errors : 121 289
  USED in MAP-ER-DataTypes : 16

CUG-Subscription..... type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes : 593
  USED in MAP-MS-DataTypes : 591

cug-SubscriptionList..... identifier of CUG-SubscriptionList
  DEFINED in MAP-MS-DataTypes : 585

CUG-SubscriptionList..... type reference SEQUENCE OF
  DEFINED in MAP-MS-DataTypes : 590
  USED in MAP-MS-DataTypes : 585

currentLocation..... identifier of Named Number, 0
  DEFINED in MAP-LCS-DataTypes : 91

currentOrLastKnownLocation..... identifier of Named Number, 1
  DEFINED in MAP-LCS-DataTypes : 92

currentPassword..... identifier of Password
  DEFINED in MAP-SupplementaryServ : 238

cw..... value reference SS-Code, '01000001'B
  DEFINED in MAP-SS-Code : 75

dataCDA-1200bps..... value reference BearerServiceCode, '00010010'B
  DEFINED in MAP-BS-Code : 53

dataCDA-1200-75bps..... value reference BearerServiceCode, '00010011'B
  DEFINED in MAP-BS-Code : 54

```

```
dataCDA-2400bps.....value reference BearerServiceCode, '00010100'B  
DEFINED in MAP-BS-Code : 55  
  
dataCDA-300bps.....value reference BearerServiceCode, '00010001'B  
DEFINED in MAP-BS-Code : 52  
  
dataCDA-4800bps.....value reference BearerServiceCode, '00010101'B
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 16

DEFINED in MAP-BS-Code	:	56
dataCDA-9600bps.....	value reference BearerServiceCode, '00010110'B	
DEFINED in MAP-BS-Code	:	57
dataCDS-1200bps.....	value reference BearerServiceCode, '00011010'B	
DEFINED in MAP-BS-Code	:	61
dataCDS-2400bps.....	value reference BearerServiceCode, '00011100'B	
DEFINED in MAP-BS-Code	:	62
dataCDS-4800bps.....	value reference BearerServiceCode, '00011101'B	
DEFINED in MAP-BS-Code	:	63
dataCDS-9600bps.....	value reference BearerServiceCode, '00011110'B	
DEFINED in MAP-BS-Code	:	64
dataCodingScheme.....	identifier of [0] USSD-DataCodingScheme	
DEFINED in MAP-LCS-DataTypes	:	119
dataMissing.....	value reference DataMissing, CHOICE VALUE	
DEFINED in MAP-Protocol	:	301
DataMissing.....	type reference ERROR	
DEFINED in MAP-Errors	:	150
USED in MAP-Protocol	:	110 301
USED in MAP-MobileServiceOpera	:	70 141 153 163 173 197 210 223 247
261 274 286 297 316 330 344 358		
USED in MAP-OperationAndMainte	:	24 58 72 83
USED in MAP-CallHandlingOperat	:	29 81 103 120 129 141 155 169 178
USED in MAP-SupplementaryServ	:	34 95 112 129 149 167 182 195 209
224 247 258 275		
USED in MAP-ShortMessageServic	:	28 74 102 119 130 144
USED in MAP-LocationServiceOpe	:	24 59 73 91
USED in MAP-Errors	:	15
dataMissingParam.....	identifier of DataMissingParam	
DEFINED in MAP-Errors	:	152
DataMissingParam.....	type reference SEQUENCE	
DEFINED in MAP-ER-DataTypes	:	171
USED in MAP-Errors	:	101 152
USED in MAP-ER-DataTypes	:	21
dataPDS-2400bps.....	value reference BearerServiceCode, '00101100'B	
DEFINED in MAP-BS-Code	:	77
dataPDS-4800bps.....	value reference BearerServiceCode, '00101101'B	
DEFINED in MAP-BS-Code	:	78
dataPDS-9600bps.....	value reference BearerServiceCode, '00101110'B	
DEFINED in MAP-BS-Code	:	79
deactivateSS.....	value reference DeactivateSS, CHOICE VALUE	
DEFINED in MAP-Protocol	:	232
DeactivateSS.....	type reference OPERATION	
DEFINED in MAP-SupplementaryServ	:	141
USED in MAP-Protocol	:	65 232
USED in MAP-SupplementaryServ	:	16
deactivateTraceMode.....	value reference DeactivateTraceMode, CHOICE VALUE	
DEFINED in MAP-Protocol	:	211
DeactivateTraceMode.....	type reference OPERATION	
DEFINED in MAP-OperationAndMainte	:	64
USED in MAP-Protocol	:	42 211
USED in MAP-OperationAndMainte	:	14
deactivateTraceModeArg.....	identifier of DeactivateTraceModeArg	
DEFINED in MAP-OperationAndMainte	:	66
DeactivateTraceModeArg.....	type reference SEQUENCE	
DEFINED in MAP-OM-DataTypes	:	54
USED in MAP-OperationAndMainte	:	36 66

USED in MAP-OM-DataTypes : 16
deactivateTraceModeRes.....identifier of DeactivateTraceModeRes
DEFINED in MAP-OperationAndMainte : 68
DeactivateTraceModeRes.....type reference SEQUENCE
DEFINED in MAP-OM-DataTypes : 60

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 17

USED in MAP-OperationAndMainte :	37	68
USED in MAP-OM-DataTypes :	17	
 defaultCallHandling.....identifier of [1] DefaultCallHandling		
DEFINED in MAP-MS-DataTypes :	831	
 DefaultCallHandling.....type reference ENUMERATED		
DEFINED in MAP-MS-DataTypes :	895	
USED in MAP-MS-DataTypes :	55	831
USED in MAP-CH-DataTypes :	39	278
 defaultCallHandling.....identifier of [1] DefaultCallHandling		
DEFINED in MAP-CH-DataTypes :	278	
 defaultPriority.....identifier of EMLPP-Priority		
DEFINED in MAP-CommonDataTypes :	389	
 defaultPriority.....identifier of [7] EMLPP-Priority		
DEFINED in MAP-SS-DataTypes :	76	
 defaultPriority.....identifier of EMLPP-Priority		
DEFINED in MAP-SS-DataTypes :	161	
 defaultPriority.....identifier of [1] EMLPP-Priority		
DEFINED in MAP-SS-DataTypes :	187	
 delaytolerant.....identifier of Named Number, 1		
DEFINED in MAP-LCS-DataTypes :	160	
 deleteSubscriberData.....value reference DeleteSubscriberData, CHOICE VALUE		
DEFINED in MAP-Protocol :	197	
 DeleteSubscriberData.....type reference OPERATION		
DEFINED in MAP-MobileServiceOpera :	290	
USED in MAP-Protocol :	25	197
USED in MAP-MobileServiceOpera :	44	
 deleteSubscriberDataArg.....identifier of DeleteSubscriberDataArg		
DEFINED in MAP-MobileServiceOpera :	292	
 DeleteSubscriberDataArg.....type reference SEQUENCE		
DEFINED in MAP-MS-DataTypes :	738	
USED in MAP-MobileServiceOpera :	103	292
USED in MAP-MS-DataTypes :	44	
 deleteSubscriberDataRes.....identifier of DeleteSubscriberDataRes		
DEFINED in MAP-MobileServiceOpera :	294	
 DeleteSubscriberDataRes.....type reference SEQUENCE		
DEFINED in MAP-MS-DataTypes :	775	
USED in MAP-MobileServiceOpera :	104	294
USED in MAP-MS-DataTypes :	45	
 deliveryOutcomeIndicator.....identifier of [3] NULL		
DEFINED in MAP-SM-DataTypes :	154	
 derivable.....identifier of InvokeIdType		
DEFINED in TCAPMessages :	167	
 destinationNumberCriteria.....identifier of [0] DestinationNumberCriteria		
DEFINED in MAP-MS-DataTypes :	854	
 DestinationNumberCriteria.....type reference SEQUENCE		
DEFINED in MAP-MS-DataTypes :	859	
USED in MAP-MS-DataTypes :	854	
 destinationNumberLengthList.....identifier of [2] DestinationNumberLengthList		
DEFINED in MAP-MS-DataTypes :	862	
 DestinationNumberLengthList.....type reference SEQUENCE OF		
DEFINED in MAP-MS-DataTypes :	872	
USED in MAP-MS-DataTypes :	862	
 destinationNumberList.....identifier of [1] DestinationNumberList		
DEFINED in MAP-MS-DataTypes :	861	

DestinationNumberList.....type reference SEQUENCE OF
 DEFINED in MAP-MS-DataTypes : 867
 USED in MAP-MS-DataTypes : 861

DestTransactionID.....type reference [APPLICATION 9] IMPLICIT
 TransactionID
 DEFINED in TCAPMessages : 98

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 18 2000-07-19 08:07:06

USED in TCAPMessages	:	65	70	74
diagnosticInfo.....	identifier of SignalInfo		
DEFINED in MAP-ER-DataTypes	:	141		
dialoguePortion.....	identifier of DialoguePortion		
DEFINED in TCAPMessages	:	58		
dialoguePortion.....	identifier of DialoguePortion		
DEFINED in TCAPMessages	:	62		
dialoguePortion.....	identifier of DialoguePortion		
DEFINED in TCAPMessages	:	66		
dialoguePortion.....	identifier of DialoguePortion		
DEFINED in TCAPMessages	:	71		
dialoguePortion.....	identifier of DialoguePortion		
DEFINED in TCAPMessages	:	77		
DialoguePortion.....	type reference [APPLICATION 11] EXTERNAL		
DEFINED in TCAPMessages	:	82		
USED in TCAPMessages	:	58	62	66
USED in TCAPMessages	:	71	77	
disallowedByLocalRegulatoryRequirements.identifier of Named Number	,	4		
DEFINED in MAP-ER-DataTypes	:	310		
doublyChargeableECT-Barred.....	identifier of Named Number	,	13
DEFINED in MAP-MS-DataTypes	:	466		
dtid.....	identifier of DestTransactionID		
DEFINED in TCAPMessages	:	65		
dtid.....	identifier of DestTransactionID		
DEFINED in TCAPMessages	:	70		
dtid.....	identifier of DestTransactionID		
DEFINED in TCAPMessages	:	74		
duplicateInvokeID.....	identifier of Named Number	,	0
DEFINED in TCAPMessages	:	183		
ect.....	value reference SS-Code, '00110001'B		
DEFINED in MAP-SS-Code	:	66		
eir.....	identifier of Named Number	,	6
DEFINED in MAP-CommonDataTypes	:	311		
emergencyCallOrigination.....	identifier of Named Number	,	0
DEFINED in MAP-LCS-DataTypes	:	233		
emergencyCallRelease.....	identifier of Named Number	,	1
DEFINED in MAP-LCS-DataTypes	:	234		
emergencyCalls.....	value reference TeleserviceCode, '00010010'B		
DEFINED in MAP-TS-Code	:	42		
emergencyServices.....	identifier of Named Number	,	0
DEFINED in MAP-LCS-DataTypes	:	108		
emlpp.....	value reference SS-Code, '10100001'B		
DEFINED in MAP-SS-Code	:	154		
emlpp-Info.....	identifier of [4] EMLPP-Info		
DEFINED in MAP-MS-DataTypes	:	487		
EMLPP-Info.....	type reference SEQUENCE		
DEFINED in MAP-CommonDataTypes	:	387		
USED in MAP-MS-DataTypes	:	133	487	
USED in MAP-CommonDataTypes	:	47		
EMLPP-Priority.....	type reference INTEGER		
DEFINED in MAP-CommonDataTypes	:	393		
USED in MAP-CommonDataTypes	:	48	388	389
USED in MAP-CommonDataTypes	:	399	400	401
USED in MAP-CommonDataTypes	:	402	403	404
USED in MAP-CommonDataTypes	:	405		

USED in MAP-SS-DataTypes	:	50	76	161	186	187
USED in MAP-GR-DataTypes	:	25	56			
enabling.....	identifier of Named Number, 1				
DEFINED in MAP-MS-DataTypes	:	892				
End.....	type reference SEQUENCE				

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 19

DEFINED in TCAPMessages	:	65
USED in TCAPMessages	:	54
end-ME.....	identifier of [APPLICATION 4] IMPLICIT End
DEFINED in TCAPMessages	:	54
enterNewPW.....	identifier of Named Number, 1
DEFINED in MAP-SS-DataTypes	:	239
enterNewPW-Again.....	identifier of Named Number, 2
DEFINED in MAP-SS-DataTypes	:	240
enterPW.....	identifier of Named Number, 0
DEFINED in MAP-SS-DataTypes	:	238
equipmentNotSM-Equipped.....	identifier of Named Number, 2
DEFINED in MAP-ER-DataTypes	:	133
equipmentProtocolError.....	identifier of Named Number, 1
DEFINED in MAP-ER-DataTypes	:	132
equipmentStatus.....	identifier of EquipmentStatus
DEFINED in MAP-MobileServiceOpera	:	271
EquipmentStatus.....	type reference ENUMERATED
DEFINED in MAP-MS-DataTypes	:	286
USED in MAP-MobileServiceOpera	:	100 271
USED in MAP-MS-DataTypes	:	38
eraseCC-Entry.....	value reference EraseCC-Entry, CHOICE VALUE
DEFINED in MAP-Protocol	:	241
EraseCC-Entry.....	type reference OPERATION
DEFINED in MAP-SupplementaryServi	:	268
USED in MAP-Protocol	:	74 241
USED in MAP-SupplementaryServi	:	25
eraseCC-EntryArg.....	identifier of EraseCC-EntryArg
DEFINED in MAP-SupplementaryServi	:	270
EraseCC-EntryArg.....	type reference SEQUENCE
DEFINED in MAP-SS-DataTypes	:	303
USED in MAP-SupplementaryServi	:	72 270
USED in MAP-SS-DataTypes	:	39
eraseCC-EntryRes.....	identifier of EraseCC-EntryRes
DEFINED in MAP-SupplementaryServi	:	272
EraseCC-EntryRes.....	type reference SEQUENCE
DEFINED in MAP-SS-DataTypes	:	308
USED in MAP-SupplementaryServi	:	73 272
USED in MAP-SS-DataTypes	:	40
eraseSS.....	value reference EraseSS, CHOICE VALUE
DEFINED in MAP-Protocol	:	230
EraseSS.....	type reference OPERATION
DEFINED in MAP-SupplementaryServi	:	104
USED in MAP-Protocol	:	63 230
USED in MAP-SupplementaryServi	:	14
errorCode.....	identifier of ERROR
DEFINED in TCAPMessages	:	158
USED in TCAPMessages	:	159
ets-300102-1.....	identifier of Named Number, 4
DEFINED in MAP-CommonDataTypes	:	201
ets-300356.....	identifier of Named Number, 1
DEFINED in MAP-CommonDataTypes	:	212
eventReportData.....	identifier of [1] EventReportData
DEFINED in MAP-CH-DataTypes	:	357
EventReportData.....	type reference SEQUENCE

DEFINED in MAP-CH-DataTypes : 362
USED in MAP-CH-DataTypes : 357

extendedRoutingInfo.....identifier of ExtendedRoutingInfo
DEFINED in MAP-CH-DataTypes : 135

ExtendedRoutingInfo.....type reference CHOICE

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 20 2000-07-19 08:07:06

DEFINED in MAP-CH-DataTypes	:	242
USED in MAP-CH-DataTypes	:	135
extensibleCallBarredParam.....identifier of ExtensibleCallBarredParam		
DEFINED in MAP-ER-DataTypes	:	93
ExtensibleCallBarredParam.....type reference SEQUENCE		
DEFINED in MAP-ER-DataTypes	:	101
USED in MAP-ER-DataTypes	:	93
extensibleSystemFailureParam.....identifier of ExtensibleSystemFailureParam		
DEFINED in MAP-ER-DataTypes	:	162
ExtensibleSystemFailureParam.....type reference SEQUENCE		
DEFINED in MAP-ER-DataTypes	:	166
USED in MAP-ER-DataTypes	:	162
extensionContainer.....identifier of ExtensionContainer		
DEFINED in MAP-MS-DataTypes	:	167
extensionContainer.....identifier of ExtensionContainer		
DEFINED in MAP-MS-DataTypes	:	173
extensionContainer.....identifier of ExtensionContainer		
DEFINED in MAP-MS-DataTypes	:	181
extensionContainer.....identifier of ExtensionContainer		
DEFINED in MAP-MS-DataTypes	:	187
extensionContainer.....identifier of ExtensionContainer		
DEFINED in MAP-MS-DataTypes	:	199
extensionContainer.....identifier of ExtensionContainer		
DEFINED in MAP-MS-DataTypes	:	206
extensionContainer.....identifier of ExtensionContainer		
DEFINED in MAP-MS-DataTypes	:	212
extensionContainer.....identifier of ExtensionContainer		
DEFINED in MAP-MS-DataTypes	:	241
extensionContainer.....identifier of [1] ExtensionContainer		
DEFINED in MAP-MS-DataTypes	:	247
extensionContainer.....identifier of ExtensionContainer		
DEFINED in MAP-MS-DataTypes	:	255
extensionContainer.....identifier of [14] ExtensionContainer		
DEFINED in MAP-MS-DataTypes	:	297
extensionContainer.....identifier of [21] ExtensionContainer		
DEFINED in MAP-MS-DataTypes	:	345
extensionContainer.....identifier of [2] ExtensionContainer		
DEFINED in MAP-MS-DataTypes	:	356
extensionContainer.....identifier of [3] ExtensionContainer		
DEFINED in MAP-MS-DataTypes	:	390
extensionContainer.....identifier of [3] ExtensionContainer		
DEFINED in MAP-MS-DataTypes	:	400
extensionContainer.....identifier of ExtensionContainer		
DEFINED in MAP-MS-DataTypes	:	449
extensionContainer.....identifier of [0] ExtensionContainer		
DEFINED in MAP-MS-DataTypes	:	493
extensionContainer.....identifier of [9] ExtensionContainer		
DEFINED in MAP-MS-DataTypes	:	509
extensionContainer.....identifier of ExtensionContainer		
DEFINED in MAP-MS-DataTypes	:	572
extensionContainer.....identifier of ExtensionContainer		

```
DEFINED in MAP-MS-DataTypes      :      581
extensionContainer.....identifier of [0] ExtensionContainer
    DEFINED in MAP-MS-DataTypes   :      587
extensionContainer.....identifier of [0] ExtensionContainer
    DEFINED in MAP-MS-DataTypes   :      598
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
PAGE 21 2000-07-19 08:07:06

```
extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 625

extensionContainer..... identifier of [5] ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 645

extensionContainer..... identifier of [3] ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 664

extensionContainer..... identifier of [2] ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 682

extensionContainer..... identifier of [0] ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 710

extensionContainer..... identifier of [7] ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 729

extensionContainer..... identifier of [6] ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 749

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 778

extensionContainer..... identifier of [1] ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 783

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 792

extensionContainer..... identifier of [0] ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 798

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 813

extensionContainer..... identifier of [2] ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 832

extensionContainer..... identifier of [3] ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 919

extensionContainer..... identifier of [3] ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 926

extensionContainer..... identifier of [3] ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 935

extensionContainer..... identifier of [1] ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 940

extensionContainer..... identifier of [3] ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 949

extensionContainer..... identifier of [0] ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 953

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 967

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 974

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 991

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 997

extensionContainer..... identifier of [3] ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 1010

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-MS-DataTypes : 1015
```

extensionContainer.....identifier of [2] ExtensionContainer
DEFINED in MAP-MS-DataTypes : 1021

extensionContainer.....identifier of [2] ExtensionContainer
DEFINED in MAP-MS-DataTypes : 1027

TAG R4.81 Cross Reference Listing for MAP-Protocol
PAGE 22

extensionContainer..... identifier of [4] ExtensionContainer
DEFINED in MAP-MS-DataTypes : 1036

extensionContainer..... identifier of [2] ExtensionContainer
DEFINED in MAP-MS-DataTypes : 1070

extensionContainer..... identifier of ExtensionContainer
DEFINED in MAP-MS-DataTypes : 1075

extensionContainer..... identifier of ExtensionContainer
DEFINED in MAP-CommonDataTypes : 182

extensionContainer..... identifier of ExtensionContainer
DEFINED in MAP-CommonDataTypes : 208

extensionContainer..... identifier of [1] ExtensionContainer
DEFINED in MAP-CommonDataTypes : 316

extensionContainer..... identifier of [1] ExtensionContainer
DEFINED in MAP-CommonDataTypes : 333

extensionContainer..... identifier of ExtensionContainer
DEFINED in MAP-CommonDataTypes : 390

extensionContainer..... identifier of [4] ExtensionContainer
DEFINED in MAP-OM-DataTypes : 41

extensionContainer..... identifier of [0] ExtensionContainer
DEFINED in MAP-OM-DataTypes : 51

extensionContainer..... identifier of [2] ExtensionContainer
DEFINED in MAP-OM-DataTypes : 57

extensionContainer..... identifier of [0] ExtensionContainer
DEFINED in MAP-OM-DataTypes : 61

extensionContainer..... identifier of ExtensionContainer
DEFINED in MAP-CH-DataTypes : 83

extensionContainer..... identifier of [13] ExtensionContainer
DEFINED in MAP-CH-DataTypes : 102

extensionContainer..... identifier of [0] ExtensionContainer
DEFINED in MAP-CH-DataTypes : 143

extensionContainer..... identifier of [2] ExtensionContainer
DEFINED in MAP-CH-DataTypes : 164

extensionContainer..... identifier of [7] ExtensionContainer
DEFINED in MAP-CH-DataTypes : 178

extensionContainer..... identifier of [11] ExtensionContainer
DEFINED in MAP-CH-DataTypes : 192

extensionContainer..... identifier of ExtensionContainer
DEFINED in MAP-CH-DataTypes : 202

extensionContainer..... identifier of [7] ExtensionContainer
DEFINED in MAP-CH-DataTypes : 212

extensionContainer..... identifier of [3] ExtensionContainer
DEFINED in MAP-CH-DataTypes : 223

extensionContainer..... identifier of ExtensionContainer
DEFINED in MAP-CH-DataTypes : 233

extensionContainer..... identifier of ExtensionContainer
DEFINED in MAP-CH-DataTypes : 239

extensionContainer..... identifier of [1] ExtensionContainer
DEFINED in MAP-CH-DataTypes : 249

extensionContainer..... identifier of [2] ExtensionContainer
DEFINED in MAP-CH-DataTypes : 255

```
extensionContainer.....identifier of ExtensionContainer
    DEFINED in MAP-CH-DataTypes      : 262

extensionContainer.....identifier of [2] ExtensionContainer
    DEFINED in MAP-CH-DataTypes      : 279

extensionContainer.....identifier of [7] ExtensionContainer
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 23 2000-07-19 08:07:06

```

  DEFINED in MAP-CH-DataTypes      :     298

extensionContainer.....identifier of [1] ExtensionContainer
  DEFINED in MAP-CH-DataTypes      :     311

extensionContainer.....identifier of [2] ExtensionContainer
  DEFINED in MAP-CH-DataTypes      :     317

extensionContainer.....identifier of [1] ExtensionContainer
  DEFINED in MAP-CH-DataTypes      :     322

extensionContainer.....identifier of [3] ExtensionContainer
  DEFINED in MAP-CH-DataTypes      :     329

extensionContainer.....identifier of [1] ExtensionContainer
  DEFINED in MAP-CH-DataTypes      :     342

extensionContainer.....identifier of [3] ExtensionContainer
  DEFINED in MAP-CH-DataTypes      :     359

extensionContainer.....identifier of [1] ExtensionContainer
  DEFINED in MAP-CH-DataTypes      :     364

extensionContainer.....identifier of [2] ExtensionContainer
  DEFINED in MAP-CH-DataTypes      :     370

extensionContainer.....identifier of [0] ExtensionContainer
  DEFINED in MAP-CH-DataTypes      :     392

extensionContainer.....identifier of [6] ExtensionContainer
  DEFINED in MAP-CH-DataTypes      :     402

extensionContainer.....identifier of [1] ExtensionContainer
  DEFINED in MAP-CH-DataTypes      :     407

extensionContainer.....identifier of [4] ExtensionContainer
  DEFINED in MAP-SS-DataTypes      :     267

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-SS-DataTypes      :     271

extensionContainer.....identifier of [6] ExtensionContainer
  DEFINED in MAP-SM-DataTypes      :     56

extensionContainer.....identifier of [4] ExtensionContainer
  DEFINED in MAP-SM-DataTypes      :     82

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-SM-DataTypes      :     88

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-SM-DataTypes      :    110

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-SM-DataTypes      :    116

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-SM-DataTypes      :    124

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-SM-DataTypes      :    129

extensionContainer.....identifier of [1] ExtensionContainer
  DEFINED in MAP-SM-DataTypes      :    149

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-SM-DataTypes      :    173

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-SM-DataTypes      :    185

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-SM-DataTypes      :    202

extensionContainer.....identifier of ExtensionContainer

```

DEFINED in MAP-SM-DataTypes : 206
extensionContainer.....identifier of [4] ExtensionContainer
 DEFINED in MAP-GR-DataTypes : 58
extensionContainer.....identifier of ExtensionContainer
 DEFINED in MAP-GR-DataTypes : 63

TAG R4.81 Cross Reference Listing for MAP-Protocol
PAGE 24 2000-07-19 08:07:06

```
extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-GR-DataTypes : 68

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-GR-DataTypes : 72

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-GR-DataTypes : 82

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-GR-DataTypes : 89

extensionContainer..... identifier of [2] ExtensionContainer
    DEFINED in MAP-LCS-DataTypes : 55

extensionContainer..... identifier of [2] ExtensionContainer
    DEFINED in MAP-LCS-DataTypes : 61

extensionContainer..... identifier of [1] ExtensionContainer
    DEFINED in MAP-LCS-DataTypes : 67

extensionContainer..... identifier of [8] ExtensionContainer
    DEFINED in MAP-LCS-DataTypes : 81

extensionContainer..... identifier of [4] ExtensionContainer
    DEFINED in MAP-LCS-DataTypes : 142

extensionContainer..... identifier of [1] ExtensionContainer
    DEFINED in MAP-LCS-DataTypes : 168

extensionContainer..... identifier of [7] ExtensionContainer
    DEFINED in MAP-LCS-DataTypes : 227

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-LCS-DataTypes : 242

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-ER-DataTypes : 83

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-ER-DataTypes : 103

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-ER-DataTypes : 109

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-ER-DataTypes : 142

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-ER-DataTypes : 149

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-ER-DataTypes : 168

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-ER-DataTypes : 172

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-ER-DataTypes : 176

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-ER-DataTypes : 180

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-ER-DataTypes : 184

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-ER-DataTypes : 188

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-ER-DataTypes : 201

extensionContainer..... identifier of ExtensionContainer
    DEFINED in MAP-ER-DataTypes : 205
```

```
extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-ER-DataTypes : 209

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-ER-DataTypes : 213
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 25 2000-07-19 08:07:06

```

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-ER-DataTypes : 217

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-ER-DataTypes : 221

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-ER-DataTypes : 225

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-ER-DataTypes : 229

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-ER-DataTypes : 233

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-ER-DataTypes : 246

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-ER-DataTypes : 252

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-ER-DataTypes : 256

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-ER-DataTypes : 260

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-ER-DataTypes : 264

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-ER-DataTypes : 268

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-ER-DataTypes : 275

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-ER-DataTypes : 279

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-ER-DataTypes : 283

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-ER-DataTypes : 287

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-ER-DataTypes : 297

extensionContainer.....identifier of [1] ExtensionContainer
  DEFINED in MAP-ER-DataTypes : 302

extensionContainer.....identifier of [1] ExtensionContainer
  DEFINED in MAP-ER-DataTypes : 317

extensionContainer.....identifier of ExtensionContainer
  DEFINED in MAP-ER-DataTypes : 335

ExtensionContainer.....type reference SEQUENCE
  DEFINED in MAP-ExtensionDataTypes : 32
    USED in MAP-MS-DataTypes : 145 167 173 181 187 199 206 212 241
                                247 255 297 345 356 390 400 449 493
                                509 572 581 587 598 625 645 664 682
                                710 729 749 778 783 792 798 813 832
                                919 926 935 940 949 953 967 974 991
                                997 1010 1015 1021 1027 1036 1070 1075
    USED in MAP-CommonDataTypes : 69 182 208 316 333 390
    USED in MAP-OM-DataTypes : 27 41 51 57 61
    USED in MAP-CH-DataTypes : 73 83 102 143 164 178 192 202 212
                                223 233 239 249 255 262 279 298 311
                                317 322 329 342 359 364 370 392 402
                                407
    USED in MAP-SS-DataTypes : 57 267 271
    USED in MAP-SM-DataTypes : 45 56 82 88 110 116 124 129 149
                                173 185 202 206
    USED in MAP-GR-DataTypes : 42 58 63 68 72 82 89
  
```

USED in MAP-LCS-DataTypes :	39	55	61	67	81	142	168	227	242
USED in MAP-ER-DataTypes :	75	83	103	109	142	149	168	172	176
	180	184	188	201	205	209	213	217	221
	225	229	233	246	252	256	260	264	268
USED in MAP-ExtensionDataTypes :	275	279	283	287	297	302	317	335	
									16

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 26 2000-07-19 08:07:06

```

ExtensionSet.....information object set reference MAP-EXTENSION, Information Object
Set
  DEFINED in MAP-ExtensionDataTypes : 48
  USED in MAP-ExtensionDataTypes : 42 44

  externalAddress.....identifier of [0] AddressString
    DEFINED in MAP-CommonDataTypes : 332

  ExternalClient.....type reference SEQUENCE
    DEFINED in MAP-MS-DataTypes : 678
    USED in MAP-MS-DataTypes : 669

  externalClientList.....identifier of [1] ExternalClientList
    DEFINED in MAP-MS-DataTypes : 660

  ExternalClientList.....type reference SEQUENCE OF
    DEFINED in MAP-MS-DataTypes : 668
    USED in MAP-MS-DataTypes : 660

  ExternalSignalInfo.....type reference SEQUENCE
    DEFINED in MAP-CommonDataTypes : 177
    USED in MAP-MobileServiceOpera : 123 229 234 238 244
    USED in MAP-MS-DataTypes : 124 263 268 274
    USED in MAP-CommonDataTypes : 20
    USED in MAP-CH-DataTypes : 60 99 186 187 291 292 295 296 297
    USED in MAP-SS-DataTypes : 315 316 321 397
    USED in MAP-SS-DataTypes : 51 289 290

  extId.....identifier of InformationObjectClassFieldType
    DEFINED in MAP-ExtensionDataTypes : 41

  extType.....identifier of InformationObjectClassFieldType
    DEFINED in MAP-ExtensionDataTypes : 43

  Ext-BasicServiceCode.....type reference CHOICE
    DEFINED in MAP-CommonDataTypes : 383
    USED in MAP-MS-DataTypes : 131 500 579 617 622 771 876
    USED in MAP-CommonDataTypes : 46
    USED in MAP-CH-DataTypes : 64 98 140 207

  Ext-BasicServiceGroupList.....type reference SEQUENCE OF
    DEFINED in MAP-MS-DataTypes : 616
    USED in MAP-MS-DataTypes : 597 644

  ext-BearerService.....identifier of [2] Ext-BearerServiceCode
    DEFINED in MAP-CommonDataTypes : 384

  Ext-BearerServiceCode.....type reference OCTET STRING
    DEFINED in MAP-BS-Code : 25
    USED in MAP-MS-DataTypes : 110 437
    USED in MAP-CommonDataTypes : 64 384

  Ext-CallBarFeatureList.....type reference SEQUENCE OF
    DEFINED in MAP-MS-DataTypes : 575
    USED in MAP-MS-DataTypes : 571

  Ext-CallBarInfo.....type reference SEQUENCE
    DEFINED in MAP-MS-DataTypes : 569
    USED in MAP-MS-DataTypes : 484

  Ext-CallBarringFeature.....type reference SEQUENCE
    DEFINED in MAP-MS-DataTypes : 578
    USED in MAP-MS-DataTypes : 576

  Ext-ExternalSignalInfo.....type reference SEQUENCE
    DEFINED in MAP-CommonDataTypes : 203
    USED in MAP-CommonDataTypes : 21
    USED in MAP-CH-DataTypes : 61 107 197

  Ext-ForwFeature.....type reference SEQUENCE
    DEFINED in MAP-MS-DataTypes : 499
    USED in MAP-MS-DataTypes : 497

  Ext-ForwFeatureList.....type reference SEQUENCE OF
    DEFINED in MAP-MS-DataTypes : 496
  
```

USED in MAP-MS-DataTypes	:	492
Ext-ForwInfo.....	type reference	SEQUENCE
DEFINED in MAP-MS-DataTypes	:	490
USED in MAP-MS-DataTypes	:	483
Ext-ForwOptions.....	type reference	OCTET STRING
DEFINED in MAP-MS-DataTypes	:	533

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 27

USED in MAP-MS-DataTypes	:	507
Ext-GeographicalInformation	type reference OCTET STRING
DEFINED in MAP-LCS-DataTypes	:	171
USED in MAP-LCS-DataTypes	:	22 166 225
Ext-NoRepCondTime	type reference INTEGER
DEFINED in MAP-MS-DataTypes	:	562
USED in MAP-MS-DataTypes	:	508
ext-ProtocolId	identifier of Ext-ProtocolId
DEFINED in MAP-CommonDataTypes	:	204
Ext-ProtocolId	type reference ENUMERATED
DEFINED in MAP-CommonDataTypes	:	211
USED in MAP-CommonDataTypes	:	204
Ext-SS-Data	type reference SEQUENCE
DEFINED in MAP-MS-DataTypes	:	640
USED in MAP-MS-DataTypes	:	486
Ext-SS-Info	type reference CHOICE
DEFINED in MAP-MS-DataTypes	:	482
USED in MAP-MS-DataTypes	:	480
Ext-SS-InfoList	type reference SEQUENCE OF
DEFINED in MAP-MS-DataTypes	:	479
USED in MAP-MS-DataTypes	:	420
Ext-SS-Status	type reference OCTET STRING
DEFINED in MAP-MS-DataTypes	:	512
USED in MAP-MS-DataTypes	:	501 580 642 655 709
ext-Teleservice	identifier of [3] Ext-TeleserviceCode
DEFINED in MAP-CommonDataTypes	:	385
Ext-TeleserviceCode	type reference OCTET STRING
DEFINED in MAP-TS-Code	:	20
USED in MAP-MS-DataTypes	:	115 442
USED in MAP-CommonDataTypes	:	58 385
USED in MAP-GR-DataTypes	:	31 50
facilityNotSupParam	identifier of FacilityNotSupParam
DEFINED in MAP-Errors	:	164
FacilityNotSupParam	type reference SEQUENCE
DEFINED in MAP-ER-DataTypes	:	179
USED in MAP-Errors	:	103 164
USED in MAP-ER-DataTypes	:	23
facilityNotSupported	value reference FacilityNotSupported, CHOICE VALUE
DEFINED in MAP-Protocol	:	303
FacilityNotSupported	type reference ERROR
DEFINED in MAP-Errors	:	162
USED in MAP-Protocol	:	112 303
USED in MAP-OperationAndMainte	:	26 60 74
USED in MAP-CallHandlingOperat	:	31 83 105 157
USED in MAP-SupplementaryServ	:	55 266
USED in MAP-ShortMessageServic	:	30 76 91 104 146
USED in MAP-LocationServiceOpe	:	26 61 75
USED in MAP-Errors	:	17
facsimileGroup3AndAlterSpeech	value reference TeleserviceCode, '01100001'B
DEFINED in MAP-TS-Code	:	49
facsimileGroup4	value reference TeleserviceCode, '01100011'B
DEFINED in MAP-TS-Code	:	51
failure	identifier of Named Number, 1
DEFINED in MAP-CH-DataTypes	:	383
failureReport	value reference FailureReport, CHOICE VALUE
DEFINED in MAP-Protocol	:	285

```
FailureReport.....type reference OPERATION
  DEFINED in MAP-MobileServiceOpera :    336
    USED in MAP-Protocol          :    32    285
    USED in MAP-MobileServiceOpera :      55

failureReportArg.....identifier of FailureReportArg
  DEFINED in MAP-MobileServiceOpera :    338
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 28 2000-07-19 08:07:06

```

FailureReportArg.....type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes : 931
  USED in MAP-MobileServiceOpera : 114 338
  USED in MAP-MS-DataTypes : 87

failureReportRes.....identifier of FailureReportRes
  DEFINED in MAP-MobileServiceOpera : 340

FailureReportRes.....type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes : 938
  USED in MAP-MobileServiceOpera : 115 340
  USED in MAP-MS-DataTypes : 88

foreignNumberPortedToForeignNetwork....identifier of Named Number, 2
  DEFINED in MAP-CH-DataTypes : 155

forwardAccessSignalling.....value reference ForwardAccessSignalling, CHOICE VALUE
  DEFINED in MAP-Protocol : 179

ForwardAccessSignalling.....type reference OPERATION
  DEFINED in MAP-MobileServiceOpera : 236
  USED in MAP-Protocol : 20 179
  USED in MAP-MobileServiceOpera : 33

forwardCheckSS-Indication.....value reference ForwardCheckSS-Indication, CHOICE
  DEFINED in MAP-Protocol : 203

ForwardCheckSS-Indication.....type reference OPERATION
  DEFINED in MAP-MobileServiceOpera : 307
  USED in MAP-Protocol : 27 203
  USED in MAP-MobileServiceOpera : 48

forwarded.....identifier of Named Number, 0
  DEFINED in MAP-MS-DataTypes : 887

forwardedToNumber.....identifier of [5] ISDN-AddressString
  DEFINED in MAP-MS-DataTypes : 502

forwardedToNumber.....identifier of [5] ISDN-AddressString
  DEFINED in MAP-CH-DataTypes : 172

forwardedToNumber.....identifier of [4] AddressString
  DEFINED in MAP-SS-DataTypes : 72

forwardedToNumber.....identifier of [5] ISDN-AddressString
  DEFINED in MAP-SS-DataTypes : 97

forwardedToSubaddress.....identifier of [8] ISDN-SubaddressString
  DEFINED in MAP-MS-DataTypes : 506

forwardedToSubaddress.....identifier of [4] ISDN-SubaddressString
  DEFINED in MAP-CH-DataTypes : 176

forwardedToSubaddress.....identifier of [6] ISDN-SubaddressString
  DEFINED in MAP-SS-DataTypes : 73

forwardedToSubaddress.....identifier of [8] ISDN-SubaddressString
  DEFINED in MAP-SS-DataTypes : 98

forwardGroupCallSignalling.....value reference ForwardGroupCallSignalling, CHOICE
  DEFINED in MAP-Protocol : 272

ForwardGroupCallSignalling.....type reference OPERATION
  DEFINED in MAP-Group-Call-Operati : 67
  USED in MAP-Protocol : 94 272
  USED in MAP-Group-Call-Operati : 15

forwardGroupCallSignallingArg.....identifier of ForwardGroupCallSignallingArg
  DEFINED in MAP-Group-Call-Operati : 69

ForwardGroupCallSignallingArg.....type reference SEQUENCE
  DEFINED in MAP-GR-DataTypes : 75

```

USED in MAP-Group-Call-Operati	:	35	69
USED in MAP-GR-DataTypes	:	18	
forwarding.....	identifier of Named Number,	1
DEFINED in MAP-CH-DataTypes	:	113	
forwardingData.....	identifier of ForwardingData	
DEFINED in MAP-CH-DataTypes	:	169	

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 29

ForwardingData.....	type reference SEQUENCE	
DEFINED in MAP-CH-DataTypes	: 171	
USED in MAP-CH-DataTypes	: 169 208 247	
forwardingData.....	identifier of [2] ForwardingData	
DEFINED in MAP-CH-DataTypes	: 208	
forwardingData.....	identifier of ForwardingData	
DEFINED in MAP-CH-DataTypes	: 247	
forwardingFailed.....	value reference ForwardingFailed, CHOICE VALUE	
DEFINED in MAP-Protocol	: 348	
ForwardingFailed.....	type reference ERROR	
DEFINED in MAP-Errors	: 282	
USED in MAP-Protocol	: 133 348	
USED in MAP-CallHandlingOperat	: 43 117	
USED in MAP-Errors	: 50	
forwardingFailedParam.....	identifier of ForwardingFailedParam	
DEFINED in MAP-Errors	: 284	
ForwardingFailedParam.....	type reference SEQUENCE	
DEFINED in MAP-ER-DataTypes	: 259	
USED in MAP-Errors	: 120 284	
USED in MAP-ER-DataTypes	: 38	
ForwardingFeature.....	type reference SEQUENCE	
DEFINED in MAP-SS-DataTypes	: 94	
USED in MAP-SS-DataTypes	: 92	
forwardingFeatureList.....	identifier of Ext-ForwFeatureList	
DEFINED in MAP-MS-DataTypes	: 492	
forwardingFeatureList.....	identifier of ForwardingFeatureList	
DEFINED in MAP-SS-DataTypes	: 87	
ForwardingFeatureList.....	type reference SEQUENCE OF	
DEFINED in MAP-SS-DataTypes	: 90	
USED in MAP-SS-DataTypes	: 87 207	
forwardingFeatureList.....	identifier of [3] ForwardingFeatureList	
DEFINED in MAP-SS-DataTypes	: 207	
forwardingInfo.....	identifier of [0] Ext-ForwInfo	
DEFINED in MAP-MS-DataTypes	: 483	
forwardingInfo.....	identifier of [0] ForwardingInfo	
DEFINED in MAP-SS-DataTypes	: 81	
ForwardingInfo.....	type reference SEQUENCE	
DEFINED in MAP-SS-DataTypes	: 85	
USED in MAP-SS-DataTypes	: 81	
forwardingInterrogationRequired.....	identifier of [4] NULL	
DEFINED in MAP-CH-DataTypes	: 141	
forwardingOptions.....	identifier of [6] Ext-ForwOptions	
DEFINED in MAP-MS-DataTypes	: 507	
forwardingOptions.....	identifier of [6] ForwardingOptions	
DEFINED in MAP-CH-DataTypes	: 177	
forwardingOptions.....	identifier of [6] ForwardingOptions	
DEFINED in MAP-SS-DataTypes	: 99	
ForwardingOptions.....	type reference OCTET STRING	
DEFINED in MAP-SS-DataTypes	: 118	
USED in MAP-CH-DataTypes	: 51 177	
USED in MAP-SS-DataTypes	: 31 99	
forwardingReason.....	identifier of [8] ForwardingReason	
DEFINED in MAP-CH-DataTypes	: 97	
ForwardingReason.....	type reference ENUMERATED	

DEFINED in MAP-CH-DataTypes : 119
USED in MAP-CH-DataTypes : 97

forwardingViolation.....value reference ForwardingViolation, CHOICE VALUE
DEFINED in MAP-Protocol : 350

ForwardingViolation.....type reference ERROR

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 30

DEFINED in MAP-Errors	:	277
USED in MAP-Protocol	:	132 350
USED in MAP-CallHandlingOperat	:	42 94
USED in MAP-Errors	:	49
forwardingViolationParam.....	identifier of ForwardingViolationParam	
DEFINED in MAP-Errors	:	279
ForwardingViolationParam.....	type reference SEQUENCE	
DEFINED in MAP-ER-DataTypes	:	255
USED in MAP-Errors	:	119 279
USED in MAP-ER-DataTypes	:	37
freezeP-TMSI.....	identifier of [1] NULL	
DEFINED in MAP-MS-DataTypes	:	211
freezeTMSI.....	identifier of [0] NULL	
DEFINED in MAP-MS-DataTypes	:	210
generalProblem.....	identifier of [0] IMPLICIT GeneralProblem	
DEFINED in TCAPMessages	:	170
GeneralProblem.....	type reference INTEGER	
DEFINED in TCAPMessages	:	179
USED in TCAPMessages	:	170
general-dataCDA.....	value reference BearerServiceCode, '00010111'B	
DEFINED in MAP-BS-Code	:	58
general-dataCDS.....	value reference BearerServiceCode, '00011111'B	
DEFINED in MAP-BS-Code	:	65
general-dataPDS.....	value reference BearerServiceCode, '00101111'B	
DEFINED in MAP-BS-Code	:	80
general-padAccessCA.....	value reference BearerServiceCode, '00100111'B	
DEFINED in MAP-BS-Code	:	74
GenericServiceInfo.....	type reference SEQUENCE	
DEFINED in MAP-SS-DataTypes	:	182
USED in MAP-SS-DataTypes	:	208
genericServiceInfo.....	identifier of [4] GenericServiceInfo	
DEFINED in MAP-SS-DataTypes	:	208
geographicalInformation.....	identifier of [0] GeographicalInformation	
DEFINED in MAP-MS-DataTypes	:	1032
GeographicalInformation.....	type reference OCTET STRING	
DEFINED in MAP-MS-DataTypes	:	1039
USED in MAP-MS-DataTypes	:	1032
getPassword.....	value reference GetPassword, CHOICE VALUE	
DEFINED in MAP-Protocol	:	239
GetPassword.....	type reference OPERATION	
DEFINED in MAP-SupplementaryServi	:	234
USED in MAP-Protocol	:	71 239
USED in MAP-SupplementaryServi	:	22 232
ggsn-Address.....	identifier of [1] GSN-Address	
DEFINED in MAP-MS-DataTypes	:	917
ggsn-Address.....	identifier of [1] GSN-Address	
DEFINED in MAP-MS-DataTypes	:	924
ggsn-Address.....	identifier of [2] GSN-Address	
DEFINED in MAP-MS-DataTypes	:	934
ggsn-Address.....	identifier of [0] GSN-Address	
DEFINED in MAP-MS-DataTypes	:	939
ggsn-Address.....	identifier of [2] GSN-Address	
DEFINED in MAP-MS-DataTypes	:	948

ggsn-Number.....identifier of [2] ISDN-AddressString
DEFINED in MAP-MS-DataTypes : 918

ggsn-Number.....identifier of [1] ISDN-AddressString
DEFINED in MAP-MS-DataTypes : 933

GlobalCellId.....type reference OCTET STRING

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 31

DEFINED in MAP-CommonDataTypes	:	291
USED in MAP-MS-DataTypes	:	129 261 272
USED in MAP-CommonDataTypes	:	34
 gmlc-List..... identifier of [0] GMLC-List		
DEFINED in MAP-MS-DataTypes	:	313
 GMLC-List..... type reference SEQUENCE OF		
DEFINED in MAP-MS-DataTypes	:	318
USED in MAP-MS-DataTypes	:	313
 gmlc-List..... identifier of Named Number, 0		
DEFINED in MAP-MS-DataTypes	:	686
 gmlc-ListWithdraw..... identifier of [13] NULL		
DEFINED in MAP-MS-DataTypes	:	754
 gmlc-Restriction..... identifier of [0] GMLC-Restriction		
DEFINED in MAP-MS-DataTypes	:	680
 GMLC-Restriction..... type reference ENUMERATED		
DEFINED in MAP-MS-DataTypes	:	685
USED in MAP-MS-DataTypes	:	680
 gmscCamelSubscriptionInfo..... identifier of [0] GmscCamelSubscriptionInfo		
DEFINED in MAP-CH-DataTypes	:	248
 GmscCamelSubscriptionInfo..... type reference SEQUENCE		
DEFINED in MAP-CH-DataTypes	:	252
USED in MAP-CH-DataTypes	:	248
 gmsc-Address..... identifier of [6] ISDN-AddressString		
DEFINED in MAP-CH-DataTypes	:	95
 gmsc-Address..... identifier of [8] ISDN-AddressString		
DEFINED in MAP-CH-DataTypes	:	189
 gprsConnectionSuspended..... identifier of NULL		
DEFINED in MAP-ER-DataTypes	:	270
 GPRSDataList..... type reference SEQUENCE OF		
DEFINED in MAP-MS-DataTypes	:	333
USED in MAP-MS-DataTypes	:	355
 gprsDataList..... identifier of [1] GPRSDataList		
DEFINED in MAP-MS-DataTypes	:	355
 gprsNodeIndicator..... identifier of [5] NULL		
DEFINED in MAP-SM-DataTypes	:	90
 gprsSubscriptionData..... identifier of [16] GPRSSubscriptionData		
DEFINED in MAP-MS-DataTypes	:	301
 GPRSSubscriptionData..... type reference SEQUENCE		
DEFINED in MAP-MS-DataTypes	:	350
USED in MAP-MS-DataTypes	:	301
 gprsSubscriptionDataWithdraw..... identifier of [10] GPRSSubscriptionDataWithdraw		
DEFINED in MAP-MS-DataTypes	:	751
 GPRSSubscriptionDataWithdraw..... type reference CHOICE		
DEFINED in MAP-MS-DataTypes	:	756
USED in MAP-MS-DataTypes	:	751
 gprsSubscriptionUnknown..... identifier of Named Number, 1		
DEFINED in MAP-ER-DataTypes	:	194
 gprsSupportIndicator..... identifier of [7] NULL		
DEFINED in MAP-SM-DataTypes	:	58
 gprsSupportIndicator..... identifier of [2] NULL		
DEFINED in MAP-SM-DataTypes	:	151
 greyListed..... identifier of Named Number, 2		
DEFINED in MAP-MS-DataTypes	:	289

```
groupCallNumber.....identifier of ISDN-AddressString
  DEFINED in MAP-GR-DataTypes : 62

groupId.....identifier of GroupId
  DEFINED in MAP-MS-DataTypes : 990
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 32

groupid.....	identifier of GroupId
DEFINED in MAP-MS-DataTypes	: 995
GroupId.....	type reference OCTET STRING
DEFINED in MAP-MS-DataTypes	: 1000
USED in MAP-MS-DataTypes	: 990 995
groupKey.....	identifier of [1] Kc
DEFINED in MAP-GR-DataTypes	: 55
groupKeyNumber.....	identifier of [0] GroupKeyNumber
DEFINED in MAP-GR-DataTypes	: 54
GroupKeyNumber.....	type reference INTEGER
DEFINED in MAP-GR-DataTypes	: 92
USED in MAP-GR-DataTypes	: 54
gsmSCF-Address.....	identifier of ISDN-AddressString
DEFINED in MAP-MS-DataTypes	: 797
gsmSCF-Address.....	identifier of [0] ISDN-AddressString
DEFINED in MAP-MS-DataTypes	: 830
gsmSCF-Address.....	identifier of [3] ISDN-AddressString
DEFINED in MAP-MS-DataTypes	: 1069
gsmSCF-Address.....	identifier of [0] ISDN-AddressString
DEFINED in MAP-CH-DataTypes	: 277
gsm-0408.....	identifier of Named Number, 1
DEFINED in MAP-CommonDataTypes	: 197
gsm-0806.....	identifier of Named Number, 2
DEFINED in MAP-CommonDataTypes	: 198
gsm-BearerCapability.....	identifier of [5] ExternalSignalInfo
DEFINED in MAP-CH-DataTypes	: 186
gsm-BearerCapability.....	identifier of [0] ExternalSignalInfo
DEFINED in MAP-CH-DataTypes	: 291
gsm-BSSMAP.....	identifier of Named Number, 3
DEFINED in MAP-CommonDataTypes	: 199
GSN-Address.....	type reference OCTET STRING
DEFINED in MAP-MS-DataTypes	: 250
USED in MAP-MS-DataTypes	: 240 917 923 924 934 939 947 948
guidanceInfo.....	identifier of GuidanceInfo
DEFINED in MAP-SupplementaryServi	: 236
GuidanceInfo.....	type reference ENUMERATED
DEFINED in MAP-SS-DataTypes	: 237
USED in MAP-SupplementaryServi	: 67 236
USED in MAP-SS-DataTypes	: 25
handoverNumber.....	identifier of ISDN-AddressString
DEFINED in MAP-MS-DataTypes	: 267
highLayerCompatibility.....	identifier of [6] ExternalSignalInfo
DEFINED in MAP-CH-DataTypes	: 297
hlr.....	identifier of Named Number, 1
DEFINED in MAP-CommonDataTypes	: 306
HLR-Id.....	type reference IMSI
DEFINED in MAP-CommonDataTypes	: 280
USED in MAP-CommonDataTypes	: 285
hlr-List.....	identifier of HLR-List
DEFINED in MAP-MS-DataTypes	: 961
HLR-List.....	type reference SEQUENCE OF
DEFINED in MAP-CommonDataTypes	: 284
USED in MAP-MS-DataTypes	: 126 961

USED in MAP-CommonDataTypes : 32
hlr-Number.....identifier of ISDN-AddressString
DEFINED in MAP-MS-DataTypes : 179
hlr-Number.....identifier of ISDN-AddressString
DEFINED in MAP-MS-DataTypes : 254

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 33 2000-07-19 08:07:06

```

hlr-Number..... identifier of ISDN-AddressString
  DEFINED in MAP-MS-DataTypes : 960

hlr-Number..... identifier of ISDN-AddressString
  DEFINED in MAP-MS-DataTypes : 972

hold..... value reference SS-Code, '01000010'B
  DEFINED in MAP-SS-Code : 77

home-Country..... identifier of Named Number, 1
  DEFINED in MAP-MS-DataTypes : 687

horizontal-accuracy..... identifier of [0] Horizontal-Accuracy
  DEFINED in MAP-LCS-DataTypes : 138

Horizontal-Accuracy..... type reference OCTET STRING
  DEFINED in MAP-LCS-DataTypes : 145
  USED in MAP-LCS-DataTypes : 20 138

ho-NumberNotRequired..... identifier of NULL
  DEFINED in MAP-MS-DataTypes : 262

identity..... identifier of Identity
  DEFINED in MAP-MS-DataTypes : 185

Identity..... type reference CHOICE
  DEFINED in MAP-CommonDataTypes : 253
  USED in MAP-MS-DataTypes : 128 185
  USED in MAP-CommonDataTypes : 29

illegalEquipment..... value reference IllegalEquipment, CHOICE VALUE
  DEFINED in MAP-Protocol : 321

IllegalEquipment..... type reference ERROR
  DEFINED in MAP-Errors : 214
  USED in MAP-Protocol : 120 321
  USED in MAP-SupplementaryServi : 52 199 213
  USED in MAP-ShortMessageServic : 34 107
  USED in MAP-LocationServiceOpe : 35 78
  USED in MAP-Errors : 31

illegalEquipmentParam..... identifier of IllegalEquipmentParam
  DEFINED in MAP-Errors : 216

IllegalEquipmentParam..... type reference SEQUENCE
  DEFINED in MAP-ER-DataTypes : 212
  USED in MAP-Errors : 109 216
  USED in MAP-ER-DataTypes : 29

illegalSS-Operation..... value reference IllegalSS-Operation, CHOICE VALUE
  DEFINED in MAP-Protocol : 364

IllegalSS-Operation..... type reference ERROR
  DEFINED in MAP-Errors : 307
  USED in MAP-Protocol : 136 364
  USED in MAP-SupplementaryServi : 40 100 117 134 154 172 261 278
  USED in MAP-Errors : 57

illegalSubscriber..... value reference IllegalSubscriber, CHOICE VALUE
  DEFINED in MAP-Protocol : 320

IllegalSubscriber..... type reference ERROR
  DEFINED in MAP-Errors : 208
  USED in MAP-Protocol : 119 320
  USED in MAP-SupplementaryServi : 51 198 212
  USED in MAP-ShortMessageServic : 33 106
  USED in MAP-LocationServiceOpe : 36 77
  USED in MAP-Errors : 30

illegalSubscriberParam..... identifier of IllegalSubscriberParam
  DEFINED in MAP-Errors : 210

IllegalSubscriberParam..... type reference SEQUENCE
  DEFINED in MAP-ER-DataTypes : 208

```

USED in MAP-Errors : 108 210
USED in MAP-ER-DataTypes : 28

imei.....identifier of IMEI
DEFINED in MAP-MobileServiceOpera : 269

IMEI.....type reference TBCD-STRING

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 34 2000-07-19 08:07:06

DEFINED in MAP-CommonDataTypes	:	273
USED in MAP-MobileServiceOpera	:	125 269
USED in MAP-CommonDataTypes	:	31
USED in MAP-LCS-DataTypes	:	28 78 222
 imei..... identifier of [5] IMEI		
DEFINED in MAP-LCS-DataTypes	:	78
 imei..... identifier of [2] IMEI		
DEFINED in MAP-LCS-DataTypes	:	222
 imsi..... identifier of IMSI		
DEFINED in MAP-OperationAndMainte	:	81
 imsi..... identifier of IMSI		
DEFINED in MAP-MS-DataTypes	:	162
 imsi..... identifier of IMSI		
DEFINED in MAP-MS-DataTypes	:	203
 imsi..... identifier of IMSI		
DEFINED in MAP-MS-DataTypes	:	216
 imsi..... identifier of IMSI		
DEFINED in MAP-MS-DataTypes	:	238
 imsi..... identifier of [0] IMSI		
DEFINED in MAP-MS-DataTypes	:	295
 imsi..... identifier of [0] IMSI		
DEFINED in MAP-MS-DataTypes	:	739
 imsi..... identifier of [0] IMSI		
DEFINED in MAP-MS-DataTypes	:	916
 imsi..... identifier of [0] IMSI		
DEFINED in MAP-MS-DataTypes	:	932
 imsi..... identifier of [0] IMSI		
DEFINED in MAP-MS-DataTypes	:	946
 imsi..... identifier of IMSI		
DEFINED in MAP-MS-DataTypes	:	965
 imsi..... identifier of [0] IMSI		
DEFINED in MAP-MS-DataTypes	:	1007
 IMSI..... type reference TBCD-STRING		
DEFINED in MAP-CommonDataTypes	:	250
USED in MAP-OperationAndMainte	:	43 81
USED in MAP-MS-DataTypes	:	125 162 203 216 238 279 295 739 916
932 946 965 1007		
USED in MAP-CommonDataTypes	:	27 254 258 270 280 327
USED in MAP-OM-DataTypes	:	22 37 55
USED in MAP-CH-DataTypes	:	62 131 182 209 326 356 396
USED in MAP-SS-DataTypes	:	47 259
USED in MAP-SM-DataTypes	:	34 80 112 133 197
USED in MAP-GR-DataTypes	:	24 67 76
USED in MAP-LCS-DataTypes	:	29 75 221
 imsi..... identifier of IMSI		
DEFINED in MAP-CommonDataTypes	:	254
 imsi..... identifier of IMSI		
DEFINED in MAP-CommonDataTypes	:	258
 imsi..... identifier of [0] IMSI		
DEFINED in MAP-CommonDataTypes	:	270
 imsi..... identifier of [0] IMSI		
DEFINED in MAP-CommonDataTypes	:	327
 imsi..... identifier of [0] IMSI		
DEFINED in MAP-OM-DataTypes	:	37

```
imsi.....identifier of [0] IMSI
      DEFINED in MAP-OM-DataTypes      :      55

imsi.....identifier of [9] IMSI
      DEFINED in MAP-CH-DataTypes      :      131

imsi.....identifier of [0] IMSI
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 35

DEFINED in MAP-CH-DataTypes	:	182
imsi.....	identifier of [3] IMSI
DEFINED in MAP-CH-DataTypes	:	209
imsi.....	identifier of [0] IMSI
DEFINED in MAP-CH-DataTypes	:	326
imsi.....	identifier of [0] IMSI
DEFINED in MAP-CH-DataTypes	:	356
imsi.....	identifier of [0] IMSI
DEFINED in MAP-CH-DataTypes	:	396
imsi.....	identifier of [0] IMSI
DEFINED in MAP-SS-DataTypes	:	259
imsi.....	identifier of IMSI
DEFINED in MAP-SM-DataTypes	:	80
imsi.....	identifier of IMSI
DEFINED in MAP-SM-DataTypes	:	112
imsi.....	identifier of [0] IMSI
DEFINED in MAP-SM-DataTypes	:	133
imsi.....	identifier of [0] IMSI
DEFINED in MAP-SM-DataTypes	:	197
imsi.....	identifier of IMSI
DEFINED in MAP-GR-DataTypes	:	67
imsi.....	identifier of IMSI
DEFINED in MAP-GR-DataTypes	:	76
imsi.....	identifier of [2] IMSI
DEFINED in MAP-LCS-DataTypes	:	75
imsi.....	identifier of [1] IMSI
DEFINED in MAP-LCS-DataTypes	:	221
imsiDetach.....	identifier of Named Number, 0
DEFINED in MAP-ER-DataTypes	:	238
imsiDetached.....	identifier of Named Number, 1
DEFINED in MAP-MS-DataTypes	:	1060
imsiUnknown.....	identifier of Named Number, 0
DEFINED in MAP-ER-DataTypes	:	193
imsi-WithLMSI.....	identifier of IMSI-WithLMSI
DEFINED in MAP-CommonDataTypes	:	255
IMSI-WithLMSI.....	type reference SEQUENCE
DEFINED in MAP-CommonDataTypes	:	257
USED in MAP-CommonDataTypes	:	255
incomingCallsBarredWithinCUG.....	identifier of Named Number, 0
DEFINED in MAP-ER-DataTypes	:	113
incompatibleTerminal.....	value reference IncompatibleTerminal, CHOICE VALUE
DEFINED in MAP-Protocol	:	304
IncompatibleTerminal.....	type reference ERROR
DEFINED in MAP-Errors	:	168
USED in MAP-Protocol	:	154 304
USED in MAP-CallHandlingOperat	:	46 179
USED in MAP-Errors	:	18
incompatibleTerminalParam.....	identifier of IncompatibleTerminalParam
DEFINED in MAP-Errors	:	170
IncompatibleTerminalParam.....	type reference SEQUENCE
DEFINED in MAP-ER-DataTypes	:	286
USED in MAP-Errors	:	128 170

USED in MAP-ER-DataTypes : 46
inconsistentMeasurementData.....identifier of Named Number, 3
DEFINED in MAP-ER-DataTypes : 324
incorrectTransactionPortion.....identifier of Named Number, 3
DEFINED in TCAPMessages : 106

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 36 2000-07-19 08:07:06

```

informServiceCentre.....value reference InformServiceCentre, CHOICE VALUE
  DEFINED in MAP-Protocol : 250

InformServiceCentre.....type reference OPERATION
  DEFINED in MAP-ShortMessageServic : 133
    USED in MAP-Protocol : 85 250
    USED in MAP-ShortMessageServic : 18

informServiceCentreArg.....identifier of InformServiceCentreArg
  DEFINED in MAP-ShortMessageServic : 135

InformServiceCentreArg.....type reference SEQUENCE
  DEFINED in MAP-SM-DataTypes : 182
    USED in MAP-ShortMessageServic : 55 135
    USED in MAP-SM-DataTypes : 23

inhibiting.....identifier of Named Number, 0
  DEFINED in MAP-MS-DataTypes : 891

initialLocation.....identifier of Named Number, 2
  DEFINED in MAP-LCS-DataTypes : 93

initiatingRelease.....identifier of Named Number, 4
  DEFINED in TCAPMessages : 187

insertSubscriberData.....value reference InsertSubscriberData, CHOICE VALUE
  DEFINED in MAP-Protocol : 196

InsertSubscriberData.....type reference OPERATION
  DEFINED in MAP-MobileServiceOpera : 279
    USED in MAP-Protocol : 24 196
    USED in MAP-MobileServiceOpera : 43

insertSubscriberDataArg.....identifier of InsertSubscriberDataArg
  DEFINED in MAP-MobileServiceOpera : 281

InsertSubscriberDataArg.....type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes : 294
    USED in MAP-MobileServiceOpera : 101 281
    USED in MAP-MS-DataTypes : 42

insertSubscriberDataRes.....identifier of InsertSubscriberDataRes
  DEFINED in MAP-MobileServiceOpera : 283

InsertSubscriberDataRes.....type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes : 721
    USED in MAP-MobileServiceOpera : 102 283
    USED in MAP-MS-DataTypes : 43

insufficientMeasurementData.....identifier of Named Number, 2
  DEFINED in MAP-ER-DataTypes : 323

insufficientResources.....identifier of Named Number, 1
  DEFINED in MAP-ER-DataTypes : 322

interCUG-Restrictions.....identifier of InterCUG-Restrictions
  DEFINED in MAP-MS-DataTypes : 624

InterCUG-Restrictions.....type reference OCTET STRING
  DEFINED in MAP-MS-DataTypes : 628
    USED in MAP-MS-DataTypes : 62 624

internationalECT-Barred.....identifier of Named Number, 11
  DEFINED in MAP-MS-DataTypes : 464

internationalOGCallsBarred.....identifier of Named Number, 1
  DEFINED in MAP-MS-DataTypes : 454

internationalOGCallsNotToHPLMN-CountryBaidentifier of Named Number, 2
  DEFINED in MAP-MS-DataTypes : 455

interrogateSS.....value reference InterrogateSS, CHOICE VALUE
  DEFINED in MAP-Protocol : 233

```

```
InterrogateSS.....type reference OPERATION
  DEFINED in MAP-SupplementaryServi :   160
    USED in MAP-Protocol      :     66   233
    USED in MAP-SupplementaryServi :     17

interrogateSS-Res.....identifier of InterrogateSS-Res
  DEFINED in MAP-SupplementaryServi :   164
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 37 2000-07-19 08:07:06

```

InterrogateSS-Res.....type reference CHOICE
  DEFINED in MAP-SS-DataTypes : 204
  USED in MAP-SupplementaryServi : 63 164
  USED in MAP-SS-DataTypes : 19

interrogationType.....identifier of [3] InterrogationType
  DEFINED in MAP-CH-DataTypes : 92

InterrogationType.....type reference ENUMERATED
  DEFINED in MAP-CH-DataTypes : 111
  USED in MAP-CH-DataTypes : 92

interzonalECT-Barred.....identifier of Named Number, 12
  DEFINED in MAP-MS-DataTypes : 465

interzonalOGCallsAndInternationalOGCalls.....identifier of Named Number, 8
  DEFINED in MAP-MS-DataTypes : 458

interzonalOGCallsBarred.....identifier of Named Number, 6
  DEFINED in MAP-MS-DataTypes : 456

interzonalOGCallsNotToHPLMN-CountryBarre.....identifier of Named Number, 7
  DEFINED in MAP-MS-DataTypes : 457

intraCUG-Options.....identifier of IntraCUG-Options
  DEFINED in MAP-MS-DataTypes : 596

IntraCUG-Options.....type reference ENUMERATED
  DEFINED in MAP-MS-DataTypes : 606
  USED in MAP-MS-DataTypes : 63 596

invalidFormat.....identifier of Named Number, 1
  DEFINED in MAP-ER-DataTypes : 126

invalidSME-Address.....identifier of Named Number, 5
  DEFINED in MAP-ER-DataTypes : 136

invoke.....identifier of [1] IMPLICIT Invoke
  DEFINED in TCAPMessages : 125

Invoke.....type reference SEQUENCE
  DEFINED in TCAPMessages : 133
  USED in TCAPMessages : 125

invokeID.....identifier of InvokeIdType
  DEFINED in TCAPMessages : 134

invokeID.....identifier of InvokeIdType
  DEFINED in TCAPMessages : 145

invokeID.....identifier of InvokeIdType
  DEFINED in TCAPMessages : 157

invokeID.....identifier of CHOICE
  DEFINED in TCAPMessages : 166

InvokeIdType.....type reference INTEGER
  DEFINED in TCAPMessages : 175
  USED in TCAPMessages : 47 134 135 145 157 167

invokeProblem.....identifier of [1] IMPLICIT InvokeProblem
  DEFINED in TCAPMessages : 171

InvokeProblem.....type reference INTEGER
  DEFINED in TCAPMessages : 183
  USED in TCAPMessages : 171

ISDN-AddressString.....type reference AddressString
  DEFINED in MAP-CommonDataTypes : 131
  USED in MAP-OperationAndMainte : 42 79
  USED in MAP-MS-DataTypes : 121 164 165 179 204 205 239 254 267
  USED in MAP-MS-DataTypes : 273 319 411 502 797 830 868 918 933
  USED in MAP-MS-DataTypes : 960 972 1033 1069
  USED in MAP-CommonDataTypes : 17 328

```

USED in MAP-CH-DataTypes	:	58	89	95	142	148	168	172	183	184
		189	201	214	277	294	310	399		
USED in MAP-SS-DataTypes	:	45	97	197	215	260	287			
USED in MAP-SM-DataTypes	:	32	53	86	98	99	139	144	172	178
				183						
USED in MAP-GR-DataTypes	:	23	62							
USED in MAP-LCS-DataTypes	:	27	53	65	72	76	220	223	224	

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 38 2000-07-19 08:07:06

```

isdn-BearerCapability.....identifier of [1] ExternalSignalInfo
  DEFINED in MAP-CH-DataTypes : 292

ISDN-SubaddressString.....type reference OCTET STRING
  DEFINED in MAP-CommonDataTypes : 137
    USED in MAP-MS-DataTypes : 123 506
    USED in MAP-CommonDataTypes : 19
    USED in MAP-CH-DataTypes : 59 176
    USED in MAP-SS-DataTypes : 46 73 98 198

kc.....identifier of Kc
  DEFINED in MAP-MS-DataTypes : 226

Kc.....type reference OCTET STRING
  DEFINED in MAP-MS-DataTypes : 233
    USED in MAP-MS-DataTypes : 39 226
    USED in MAP-GR-DataTypes : 36 55

keepCCBS-CallIndicator.....identifier of [1] NULL
  DEFINED in MAP-CH-DataTypes : 163

laiFixedLength.....identifier of [1] LAIFixedLength
  DEFINED in MAP-CommonDataTypes : 349

LAIFixedLength.....type reference OCTET STRING
  DEFINED in MAP-CommonDataTypes : 364
    USED in MAP-CommonDataTypes : 349

lawfulInterceptServices.....identifier of Named Number, 3
  DEFINED in MAP-LCS-DataTypes : 111

lcsClientDialedByMS.....identifier of [2] AddressString
  DEFINED in MAP-LCS-DataTypes : 102

LCSCClientExternalID.....type reference SEQUENCE
  DEFINED in MAP-CommonDataTypes : 331
    USED in MAP-MS-DataTypes : 136 679
    USED in MAP-CommonDataTypes : 52
    USED in MAP-LCS-DataTypes : 33 101

lcsClientExternalID.....identifier of [1] LCSCClientExternalID
  DEFINED in MAP-LCS-DataTypes : 101

LCSCClientInternalID.....type reference ENUMERATED
  DEFINED in MAP-CommonDataTypes : 336
    USED in MAP-MS-DataTypes : 137 674
    USED in MAP-CommonDataTypes : 53
    USED in MAP-LCS-DataTypes : 34 103

lcsClientInternalID.....identifier of [3] LCSCClientInternalID
  DEFINED in MAP-LCS-DataTypes : 103

lcsClientName.....identifier of [4] LCSCClientName
  DEFINED in MAP-LCS-DataTypes : 104

LCSCClientName.....type reference SEQUENCE
  DEFINED in MAP-LCS-DataTypes : 118
    USED in MAP-LCS-DataTypes : 18 104

lcsClientType.....identifier of [0] LCSCClientType
  DEFINED in MAP-LCS-DataTypes : 100

LCSCClientType.....type reference ENUMERATED
  DEFINED in MAP-LCS-DataTypes : 107
    USED in MAP-LCS-DataTypes : 100

lcsInformation.....identifier of [22] LCSCInformation
  DEFINED in MAP-MS-DataTypes : 307

LCSCInformation.....type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes : 312
    USED in MAP-MS-DataTypes : 307

lcsLocationInfo.....identifier of [1] LCSCLocationInfo

```

DEFINED in MAP-LCS-DataTypes : 60
LCSLocationInfo..... type reference SEQUENCE
 DEFINED in MAP-LCS-DataTypes : 64
 USED in MAP-LCS-DataTypes : 60 219
lcsLocationInfo..... identifier of LCSLocationInfo

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 39 2000-07-19 08:07:06

```

DEFINED in MAP-LCS-DataTypes : 219

lcs-ClientID..... identifier of [0] LCS-ClientID
DEFINED in MAP-LCS-DataTypes : 73

LCS-ClientID..... type reference SEQUENCE
DEFINED in MAP-LCS-DataTypes : 99
USED in MAP-LCS-DataTypes : 73 218

lcs-ClientID..... identifier of LCS-ClientID
DEFINED in MAP-LCS-DataTypes : 218

lcs-Event..... identifier of LCS-Event
DEFINED in MAP-LCS-DataTypes : 217

LCS-Event..... type reference ENUMERATED
DEFINED in MAP-LCS-DataTypes : 232
USED in MAP-LCS-DataTypes : 217

lcs-Priority..... identifier of [6] LCS-Priority
DEFINED in MAP-LCS-DataTypes : 79

LCS-Priority..... type reference OCTET STRING
DEFINED in MAP-LCS-DataTypes : 132
USED in MAP-LCS-DataTypes : 79

LCS-PrivacyClass..... type reference SEQUENCE
DEFINED in MAP-MS-DataTypes : 653
USED in MAP-MS-DataTypes : 649

lcs-PrivacyExceptionList..... identifier of [1] LCS-PrivacyExceptionList
DEFINED in MAP-MS-DataTypes : 314

LCS-PrivacyExceptionList..... type reference SEQUENCE OF
DEFINED in MAP-MS-DataTypes : 648
USED in MAP-MS-DataTypes : 314

lcs-QoS..... identifier of [7] LCS-QoS
DEFINED in MAP-LCS-DataTypes : 80

LCS-QoS..... type reference SEQUENCE
DEFINED in MAP-LCS-DataTypes : 137
USED in MAP-LCS-DataTypes : 19 80

linkedID..... identifier of [0] IMPLICIT InvokeIdType
DEFINED in TCAPMessages : 135

linkedResponseUnexpected..... identifier of Named Number, 6
DEFINED in TCAPMessages : 189

lmsi..... identifier of [10] LMSI
DEFINED in MAP-MS-DataTypes : 166

lmsi..... identifier of LMSI
DEFINED in MAP-MS-DataTypes : 966

lmsi..... identifier of [1] LMSI
DEFINED in MAP-MS-DataTypes : 1008

lmsi..... identifier of LMSI
DEFINED in MAP-CommonDataTypes : 259

LMSI..... type reference OCTET STRING
DEFINED in MAP-CommonDataTypes : 289
USED in MAP-MS-DataTypes : 127 166 966 1008
USED in MAP-CommonDataTypes : 33 259
USED in MAP-CH-DataTypes : 63 185 327
USED in MAP-SM-DataTypes : 35 87 134
USED in MAP-LCS-DataTypes : 30 66 77

lmsi..... identifier of [4] LMSI
DEFINED in MAP-CH-DataTypes : 185

lmsi..... identifier of [1] LMSI
DEFINED in MAP-CH-DataTypes : 327

```

```
lmsi.....identifier of LMSI
      DEFINED in MAP-SM-DataTypes : 87

lmsi.....identifier of [1] LMSI
      DEFINED in MAP-SM-DataTypes : 134
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 40

```

lmsi..... identifier of [0] LMSI
  DEFINED in MAP-LCS-DataTypes : 66

lmsi..... identifier of [4] LMSI
  DEFINED in MAP-LCS-DataTypes : 77

lmu-Indicator..... identifier of [21] NULL
  DEFINED in MAP-MS-DataTypes : 306

locationEstimate..... identifier of Ext-GeographicalInformation
  DEFINED in MAP-LCS-DataTypes : 166

locationEstimate..... identifier of [5] Ext-GeographicalInformation
  DEFINED in MAP-LCS-DataTypes : 225

locationEstimateType..... identifier of [0] LocationEstimateType
  DEFINED in MAP-LCS-DataTypes : 87

LocationEstimateType..... type reference ENUMERATED
  DEFINED in MAP-LCS-DataTypes : 90
  USED in MAP-LCS-DataTypes : 87

locationInformation..... identifier of [0] LocationInformation
  DEFINED in MAP-MS-DataTypes : 1019

locationInformation..... identifier of [0] NULL
  DEFINED in MAP-MS-DataTypes : 1025

LocationInformation..... type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes : 1030
  USED in MAP-MS-DataTypes : 75 1019

locationInfoWithLMSI..... identifier of [0] LocationInfoWithLMSI
  DEFINED in MAP-SM-DataTypes : 81

LocationInfoWithLMSI..... type reference SEQUENCE
  DEFINED in MAP-SM-DataTypes : 85
  USED in MAP-SM-DataTypes : 81

locationNumber..... identifier of [2] LocationNumber
  DEFINED in MAP-MS-DataTypes : 1034

LocationNumber..... type reference OCTET STRING
  DEFINED in MAP-MS-DataTypes : 1049
  USED in MAP-MS-DataTypes : 1034

locationProcedureNotCompleted..... identifier of Named Number, 4
  DEFINED in MAP-ER-DataTypes : 325

locationProcedureNotSupportedByTargetMS.identifier of Named Number, 5
  DEFINED in MAP-ER-DataTypes : 326

locationType..... identifier of LocationType
  DEFINED in MAP-LCS-DataTypes : 71

LocationType..... type reference SEQUENCE
  DEFINED in MAP-LCS-DataTypes : 86
  USED in MAP-LCS-DataTypes : 17 71

longTermDenial..... value reference LongTermDenial, CHOICE VALUE
  DEFINED in MAP-Protocol : 376

LongTermDenial..... type reference ERROR
  DEFINED in MAP-Errors : 340
  USED in MAP-Protocol : 153 376
  USED in MAP-SupplementaryServ : 54 265
  USED in MAP-Errors : 68

longTermDenialParam..... identifier of LongTermDenialParam
  DEFINED in MAP-Errors : 342

LongTermDenialParam..... type reference SEQUENCE
  DEFINED in MAP-ER-DataTypes : 293
  USED in MAP-Errors : 130 342
  USED in MAP-ER-DataTypes : 48

```

lowdelay.....identifier of Named Number, 0
DEFINED in MAP-LCS-DataTypes : 159

lowerLayerCompatibility.....identifier of [5] ExternalSignalInfo
DEFINED in MAP-CH-DataTypes : 296

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 41

lsaActiveModeIndicator.....	identifier of [2] NULL	
DEFINED in MAP-MS-DataTypes	:	389
lsaAttributes.....	identifier of [1] LSAAttributes	
DEFINED in MAP-MS-DataTypes	:	388
LSAAttributes.....	type reference OCTET STRING	
DEFINED in MAP-MS-DataTypes	:	406
USED in MAP-MS-DataTypes	:	388
LSAData.....	type reference SEQUENCE	
DEFINED in MAP-MS-DataTypes	:	386
USED in MAP-MS-DataTypes	:	382
LSADataList.....	type reference SEQUENCE OF	
DEFINED in MAP-MS-DataTypes	:	381
USED in MAP-MS-DataTypes	:	399
lsaDataList.....	identifier of [2] LSADataList	
DEFINED in MAP-MS-DataTypes	:	399
lsaIdentity.....	identifier of [0] LSAIdentity	
DEFINED in MAP-MS-DataTypes	:	387
LSAIdentity.....	type reference OCTET STRING	
DEFINED in MAP-MS-DataTypes	:	403
USED in MAP-MS-DataTypes	:	387 768
lsaIdentityList.....	identifier of LSAIdentityList	
DEFINED in MAP-MS-DataTypes	:	765
LSAIdentityList.....	type reference SEQUENCE OF	
DEFINED in MAP-MS-DataTypes	:	767
USED in MAP-MS-DataTypes	:	765
lsaInformation.....	identifier of [25] LSAInformation	
DEFINED in MAP-MS-DataTypes	:	305
LSAInformation.....	type reference SEQUENCE	
DEFINED in MAP-MS-DataTypes	:	393
USED in MAP-MS-DataTypes	:	305
lsaInformationWithdraw.....	identifier of [12] LSAInformationWithdraw	
DEFINED in MAP-MS-DataTypes	:	753
LSAInformationWithdraw.....	type reference CHOICE	
DEFINED in MAP-MS-DataTypes	:	763
USED in MAP-MS-DataTypes	:	753
LSAOnlyAccessIndicator.....	type reference ENUMERATED	
DEFINED in MAP-MS-DataTypes	:	377
USED in MAP-MS-DataTypes	:	398
lsaOnlyAccessIndicator.....	identifier of [1] LSAOnlyAccessIndicator	
DEFINED in MAP-MS-DataTypes	:	398
mah.....	value reference SS-Code, '00110010'B	
DEFINED in MAP-SS-Code	:	68
MAP-BS-Code.....	module reference	
DEFINED in MAP-BS-Code	:	1
USED in MAP-MS-DataTypes	:	111
USED in MAP-CommonDataTypes	:	65
MAP-CallHandlingOperations.....	module reference	
DEFINED in MAP-CallHandlingOperat	:	1
USED in MAP-Protocol	:	57
MAP-CH-DataTypes.....	module reference	
DEFINED in MAP-CH-DataTypes	:	1
USED in MAP-CallHandlingOperat	:	68
MAP-CommonDataTypes.....	module reference	
DEFINED in MAP-CommonDataTypes	:	1
USED in MAP-MobileServiceOpera	:	126

USED in MAP-OperationAndMainte :	44
USED in MAP-MS-DataTypes :	141
USED in MAP-OM-DataTypes :	23
USED in MAP-CH-DataTypes :	69
USED in MAP-SS-DataTypes :	53
USED in MAP-SM-DataTypes :	36
USED in MAP-GR-DataTypes :	27

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 42

USED in MAP-LCS-DataTypes	:	35	2000-07-19 08:07:06
USED in MAP-ER-DataTypes	:	66	
MAP-Errors.....module reference			
DEFINED in MAP-Errors	:	1	
USED in MAP-Protocol	:	160	
USED in MAP-MobileServiceOpera	:	82	
USED in MAP-OperationAndMainte	:	30	
USED in MAP-CallHandlingOperat	:	49	
USED in MAP-SupplementaryServi	:	56	
USED in MAP-ShortMessageServic	:	42	
USED in MAP-Group-Call-Operati	:	27	
USED in MAP-LocationServiceOpe	:	37	
MAP-ER-DataTypes.....module reference			
DEFINED in MAP-ER-DataTypes	:	1	
USED in MAP-Errors	:	137	
USED in MAP-MS-DataTypes	:	151	
USED in MAP-SM-DataTypes	:	41	
MAP-EXTENSION.....information object class reference CLASS			
DEFINED in MAP-ExtensionDataTypes	:	22	
USED in MAP-ExtensionDataTypes	:	41 43 48	
MAP-ExtensionDataTypes.....module reference			
DEFINED in MAP-ExtensionDataTypes	:	1	
USED in MAP-MS-DataTypes	:	146	
USED in MAP-CommonDataTypes	:	70	
USED in MAP-OM-DataTypes	:	28	
USED in MAP-CH-DataTypes	:	74	
USED in MAP-SS-DataTypes	:	58	
USED in MAP-SM-DataTypes	:	46	
USED in MAP-GR-DataTypes	:	43	
USED in MAP-LCS-DataTypes	:	40	
USED in MAP-ER-DataTypes	:	76	
MAP-Group-Call-Operations.....module reference			
DEFINED in MAP-Group-Call-Operati	:	1	
USED in MAP-Protocol	:	96	
MAP-GR-DataTypes.....module reference			
DEFINED in MAP-GR-DataTypes	:	1	
USED in MAP-Group-Call-Operati	:	37	
MAP-LCS-DataTypes.....module reference			
DEFINED in MAP-LCS-DataTypes	:	1	
USED in MAP-LocationServiceOpe	:	47	
MAP-LocationServiceOperations.....module reference			
DEFINED in MAP-LocationServiceOpe	:	1	
USED in MAP-Protocol	:	104	
MAP-MobileServiceOperations.....module reference			
DEFINED in MAP-MobileServiceOpera	:	1	
USED in MAP-Protocol	:	36	
MAP-MS-DataTypes.....module reference			
DEFINED in MAP-MS-DataTypes	:	1	
USED in MAP-MobileServiceOpera	:	119	
USED in MAP-CH-DataTypes	:	47	
USED in MAP-GR-DataTypes	:	37	
MAP-OM-DataTypes.....module reference			
DEFINED in MAP-OM-DataTypes	:	1	
USED in MAP-OperationAndMainte	:	38	
MAP-OperationAndMaintenanceOperations...module reference			
DEFINED in MAP-OperationAndMainte	:	1	
USED in MAP-Protocol	:	44	
MAP-Protocol.....module reference			
DEFINED in MAP-Protocol	:	1	
MAP-ShortMessageServiceOperations.....module reference			
DEFINED in MAP-ShortMessageServic	:	1	

USED in MAP-Protocol	:	87
MAP-SM-DataTypes.....	module reference	
DEFINED in MAP-SM-DataTypes	:	1
USED in MAP-ShortMessageServic	:	58
MAP-SS-Code.....	module reference	

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 43

DEFINED in MAP-SS-Code	:	1
USED in MAP-SupplementaryServi	:	79
USED in MAP-MS-DataTypes	:	106
USED in MAP-SS-DataTypes	:	63
USED in MAP-ER-DataTypes	:	71
 MAP-SS-DataTypes.....module reference		
DEFINED in MAP-SS-DataTypes	:	1
USED in MAP-SupplementaryServi	:	74
USED in MAP-Errors	:	93
USED in MAP-MS-DataTypes	:	101
USED in MAP-CH-DataTypes	:	54
USED in MAP-LCS-DataTypes	:	46
USED in MAP-ER-DataTypes	:	59
 MAP-SupplementaryServiceOperations.....module reference		
DEFINED in MAP-SupplementaryServi	:	1
USED in MAP-Protocol	:	75
 MAP-TS-Code.....module reference		
DEFINED in MAP-TS-Code	:	1
USED in MAP-MS-DataTypes	:	116
USED in MAP-CommonDataTypes	:	59
USED in MAP-GR-DataTypes	:	32
 matchType.....identifier of [0] MatchType		
DEFINED in MAP-MS-DataTypes	:	860
 MatchType.....type reference ENUMERATED		
DEFINED in MAP-MS-DataTypes	:	890
USED in MAP-MS-DataTypes	:	860
 maxAddressLength.....value reference INTEGER, 20		
DEFINED in MAP-CommonDataTypes	:	129
USED in MAP-CommonDataTypes	:	88
 maxEventSpecification.....value reference INTEGER, 2		
DEFINED in MAP-SS-DataTypes	:	278
USED in MAP-SS-DataTypes	:	275
 maxExt-GeographicalInformation.....value reference INTEGER, 20		
DEFINED in MAP-LCS-DataTypes	:	212
USED in MAP-LCS-DataTypes	:	171
 maximumEntitledPriority.....identifier of EMLPP-Priority		
DEFINED in MAP-CommonDataTypes	:	388
 maximumEntitledPriority.....identifier of [0] EMLPP-Priority		
DEFINED in MAP-SS-DataTypes	:	186
 maxISDN-AddressLength.....value reference INTEGER, 9		
DEFINED in MAP-CommonDataTypes	:	135
USED in MAP-MS-DataTypes	:	122
USED in MAP-CommonDataTypes	:	18 132
 maxISDN-SubaddressLength.....value reference INTEGER, 21		
DEFINED in MAP-CommonDataTypes	:	175
USED in MAP-CommonDataTypes	:	138
 maxNameStringLength.....value reference INTEGER, 63		
DEFINED in MAP-LCS-DataTypes	:	130
USED in MAP-LCS-DataTypes	:	128
 maxNumOfBasicServiceGroups.....value reference INTEGER, 13		
DEFINED in MAP-SS-DataTypes	:	256
USED in MAP-SS-DataTypes	:	91 147 253
 maxNumOfBasicServices.....value reference INTEGER, 70		
DEFINED in MAP-MS-DataTypes	:	773
USED in MAP-MS-DataTypes	:	770
 maxNumOfBearerServices.....value reference INTEGER, 50		
DEFINED in MAP-MS-DataTypes	:	439
USED in MAP-MS-DataTypes	:	436

```
maxNumOfCamelBasicServiceCriteria.....value reference INTEGER, 5
  DEFINED in MAP-MS-DataTypes      :    884
  USED in MAP-MS-DataTypes        :    875

maxNumOfCamelDestinationNumberLengths...value reference INTEGER, 3
  DEFINED in MAP-MS-DataTypes      :    882
  USED in MAP-MS-DataTypes        :    872
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 44 2000-07-19 08:07:06

```

maxNumOfCamelDestinationNumbers.....value reference INTEGER, 10
  DEFINED in MAP-MS-DataTypes      : 880
  USED in MAP-MS-DataTypes        : 867

maxNumOfCamelSSEvents.....value reference INTEGER, 10
  DEFINED in MAP-MS-DataTypes      : 809
  USED in MAP-MS-DataTypes        : 802

maxNumOfCamelTDPData.....value reference INTEGER, 10
  DEFINED in MAP-MS-DataTypes      : 825
  USED in MAP-MS-DataTypes        : 59   818   849
  USED in MAP-CH-DataTypes        : 36   267

maxNumOfCCBS-Requests.....value reference INTEGER, 5
  DEFINED in MAP-SS-DataTypes      : 193
  USED in MAP-SS-DataTypes        : 190   202

maxNumOfCUG.....value reference INTEGER, 10
  DEFINED in MAP-MS-DataTypes      : 611
  USED in MAP-MS-DataTypes        : 590

maxNumOfExternalClient.....value reference INTEGER, 5
  DEFINED in MAP-MS-DataTypes      : 671
  USED in MAP-MS-DataTypes        : 668

maxNumOfExt-BasicServiceGroups.....value reference INTEGER, 32
  DEFINED in MAP-MS-DataTypes      : 619
  USED in MAP-MS-DataTypes        : 496   575   613   616

maxNumOfGMLC.....value reference INTEGER, 5
  DEFINED in MAP-MS-DataTypes      : 322
  USED in MAP-MS-DataTypes        : 318

maxNumOfHLR-Id.....value reference INTEGER, 50
  DEFINED in MAP-CommonDataTypes   : 287
  USED in MAP-CommonDataTypes     : 284

maxNumOfISDN-AddressDigits.....value reference INTEGER, 15
  DEFINED in MAP-MS-DataTypes      : 878
  USED in MAP-MS-DataTypes        : 873

maxNumOfLSAs.....value reference INTEGER, 20
  DEFINED in MAP-MS-DataTypes      : 384
  USED in MAP-MS-DataTypes        : 381   767

maxNumOfMOLR-Class.....value reference INTEGER, 3
  DEFINED in MAP-MS-DataTypes      : 705
  USED in MAP-MS-DataTypes        : 702

maxNumOfPDP-Contexts.....value reference INTEGER, 50
  DEFINED in MAP-MS-DataTypes      : 336
  USED in MAP-MS-DataTypes        : 333   348   760

maxNumOfPLMNclient.....value reference INTEGER, 5
  DEFINED in MAP-MS-DataTypes      : 676
  USED in MAP-MS-DataTypes        : 673

maxNumOfPrivacyClass.....value reference INTEGER, 4
  DEFINED in MAP-MS-DataTypes      : 651
  USED in MAP-MS-DataTypes        : 648

maxNumOfPrivateExtensions.....value reference INTEGER, 10
  DEFINED in MAP-ExtensionDataTypes : 46
  USED in MAP-ExtensionDataTypes   : 37

maxNumOfSS.....value reference INTEGER, 30
  DEFINED in MAP-SS-DataTypes      : 248
  USED in MAP-MS-DataTypes        : 98    479
  USED in MAP-SS-DataTypes        : 32    245   250

maxNumOfTeleservices.....value reference INTEGER, 20
  DEFINED in MAP-MS-DataTypes      : 444
  USED in MAP-MS-DataTypes        : 441

```

```
maxNumOfVBSGroupIds.....value reference INTEGER, 50
  DEFINED in MAP-MS-DataTypes      : 985
  USED in MAP-MS-DataTypes        : 979

maxNumOfVGCSGroupIds.....value reference INTEGER, 50
  DEFINED in MAP-MS-DataTypes      : 987
  USED in MAP-MS-DataTypes        : 982
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 45 2000-07-19 08:07:06

```

maxNumOfZoneCodes.....value reference INTEGER, 10
  DEFINED in MAP-MS-DataTypes : 719
  USED in MAP-MS-DataTypes : 50 713

maxSignalInfoLength.....value reference INTEGER, 200
  DEFINED in MAP-CommonDataTypes : 188
  USED in MAP-CommonDataTypes : 23 186

maxUSSD-StringLength.....value reference INTEGER, 160
  DEFINED in MAP-SS-DataTypes : 231
  USED in MAP-SS-DataTypes : 227

mcef-Set.....identifier of Named Number, 2
  DEFINED in MAP-SM-DataTypes : 191

mci.....value reference SS-Code, '00010101'B
  DEFINED in MAP-SS-Code : 36

memoryAvailable.....identifier of Named Number, 1
  DEFINED in MAP-SM-DataTypes : 212

memoryCapacityExceeded.....identifier of Named Number, 0
  DEFINED in MAP-SM-DataTypes : 167

memoryCapacityExceeded.....identifier of Named Number, 0
  DEFINED in MAP-ER-DataTypes : 131

MessageType.....type reference CHOICE
  DEFINED in TCAPMessages : 51
  USED in TCAPMessages : 47

messageWaitingListFull.....value reference MessageWaitingListFull, CHOICE VALUE
  DEFINED in MAP-Protocol : 383

MessageWaitingListFull.....type reference ERROR
  DEFINED in MAP-Errors : 357
  USED in MAP-Protocol : 148 383
  USED in MAP-ShortMessageService : 40 122
  USED in MAP-Errors : 73

messageWaitListFullParam.....identifier of MessageWaitListFullParam
  DEFINED in MAP-Errors : 359

MessageWaitListFullParam.....type reference SEQUENCE
  DEFINED in MAP-ER-DataTypes : 274
  USED in MAP-Errors : 124 359
  USED in MAP-ER-DataTypes : 41

mistypedComponent.....identifier of Named Number, 1
  DEFINED in TCAPMessages : 180

mistypedParameter.....identifier of Named Number, 2
  DEFINED in TCAPMessages : 185

mistypedParameter.....identifier of Named Number, 2
  DEFINED in TCAPMessages : 194

mistypedParameter.....identifier of Named Number, 4
  DEFINED in TCAPMessages : 200

mlcNumber.....identifier of [0] ISDN-AddressString
  DEFINED in MAP-LCS-DataTypes : 53

mlc-Number.....identifier of ISDN-AddressString
  DEFINED in MAP-LCS-DataTypes : 72

mnrf-Set.....identifier of Named Number, 1
  DEFINED in MAP-SM-DataTypes : 190

mnrg-Set.....identifier of Named Number, 3
  DEFINED in MAP-SM-DataTypes : 192

mobileNotReachableReason.....identifier of [2] AbsentSubscriberDiagnosticSM
  DEFINED in MAP-MS-DataTypes : 925

```

MOLR-Class.....type reference SEQUENCE
 DEFINED in MAP-MS-DataTypes : 707
 USED in MAP-MS-DataTypes : 703

molr-List.....identifier of [2] MOLR-List
 DEFINED in MAP-MS-DataTypes : 315

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 46 2000-07-19 08:07:06

```

MOLR-List.....type reference SEQUENCE OF
  DEFINED in MAP-MS-DataTypes : 702
  USED in MAP-MS-DataTypes : 315

monitoringMode.....identifier of [0] MonitoringMode
  DEFINED in MAP-CH-DataTypes : 368

MonitoringMode.....type reference ENUMERATED
  DEFINED in MAP-CH-DataTypes : 373
  USED in MAP-CH-DataTypes : 368

moreMessagesToSend.....identifier of NULL
  DEFINED in MAP-SM-DataTypes : 123

mo-forwardSM.....value reference MO-ForwardSM, CHOICE VALUE
  DEFINED in MAP-Protocol : 247

MO-ForwardSM.....type reference OPERATION
  DEFINED in MAP-ShortMessageServic : 82
  USED in MAP-Protocol : 81 247
  USED in MAP-ShortMessageServic : 14

mo-forwardSM-Arg.....identifier of MO-ForwardSM-Arg
  DEFINED in MAP-ShortMessageServic : 84

MO-ForwardSM-Arg.....type reference SEQUENCE
  DEFINED in MAP-SM-DataTypes : 106
  USED in MAP-ShortMessageServic : 48 84
  USED in MAP-SM-DataTypes : 16

mo-forwardSM-Res.....identifier of MO-ForwardSM-Res
  DEFINED in MAP-ShortMessageServic : 86

MO-ForwardSM-Res.....type reference SEQUENCE
  DEFINED in MAP-SM-DataTypes : 114
  USED in MAP-ShortMessageServic : 49 86
  USED in MAP-SM-DataTypes : 17

mo-lr.....identifier of Named Number, 2
  DEFINED in MAP-LCS-DataTypes : 235

msc-Number.....identifier of [1] ISDN-AddressString
  DEFINED in MAP-MS-DataTypes : 164

msc-Number.....identifier of [1] ISDN-AddressString
  DEFINED in MAP-CH-DataTypes : 183

msc-Number.....identifier of [0] ISDN-AddressString
  DEFINED in MAP-SM-DataTypes : 98

msc-Number.....identifier of ISDN-AddressString
  DEFINED in MAP-LCS-DataTypes : 65

msisdn.....identifier of ISDN-AddressString
  DEFINED in MAP-OperationAndMainte : 79

msisdn.....identifier of [1] ISDN-AddressString
  DEFINED in MAP-MS-DataTypes : 411

msisdn.....identifier of [1] ISDN-AddressString
  DEFINED in MAP-CommonDataTypes : 328

msisdn.....identifier of [0] ISDN-AddressString
  DEFINED in MAP-CH-DataTypes : 89

msisdn.....identifier of [12] ISDN-AddressString
  DEFINED in MAP-CH-DataTypes : 148

msisdn.....identifier of [2] ISDN-AddressString
  DEFINED in MAP-CH-DataTypes : 184

msisdn.....identifier of [9] ISDN-AddressString
  DEFINED in MAP-CH-DataTypes : 214

```

```
msisdn.....identifier of [0] ISDN-AddressString
    DEFINED in MAP-SS-DataTypes      :   215

msisdn.....identifier of [1] ISDN-AddressString
    DEFINED in MAP-SS-DataTypes      :   260

msisdn.....identifier of [0] ISDN-AddressString
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 47

msisdn.....	identifier of [2] ISDN-AddressString	
DEFINED in MAP-SM-DataTypes	:	139
msisdn.....	identifier of ISDN-AddressString	
DEFINED in MAP-SM-DataTypes	:	144
msisdn.....	identifier of ISDN-AddressString	
DEFINED in MAP-SM-DataTypes	:	178
msisdn.....	identifier of [3] ISDN-AddressString	
DEFINED in MAP-LCS-DataTypes	:	76
msisdn.....	identifier of [0] ISDN-AddressString	
DEFINED in MAP-LCS-DataTypes	:	220
msNotReachable.....	identifier of NULL	
DEFINED in MAP-MS-DataTypes	:	973
msPurged.....	identifier of Named Number, 0	
DEFINED in MAP-MS-DataTypes	:	1059
ms-Present.....	identifier of Named Number, 0	
DEFINED in MAP-SM-DataTypes	:	211
mt-forwardSM.....	value reference MT-ForwardSM, CHOICE VALUE	
DEFINED in MAP-Protocol	:	248
MT-ForwardSM.....	type reference OPERATION	
DEFINED in MAP-ShortMessageServic	:	94
USED in MAP-Protocol	:	82 248
USED in MAP-ShortMessageServic	:	15
mt-forwardSM-Arg.....	identifier of MT-ForwardSM-Arg	
DEFINED in MAP-ShortMessageServic	:	96
MT-ForwardSM-Arg.....	type reference SEQUENCE	
DEFINED in MAP-SM-DataTypes	:	119
USED in MAP-ShortMessageServic	:	50 96
USED in MAP-SM-DataTypes	:	18
mt-forwardSM-Res.....	identifier of MT-ForwardSM-Res	
DEFINED in MAP-ShortMessageServic	:	98
MT-ForwardSM-Res.....	type reference SEQUENCE	
DEFINED in MAP-SM-DataTypes	:	127
USED in MAP-ShortMessageServic	:	51 98
USED in MAP-SM-DataTypes	:	19
multipleECT-Barred.....	identifier of Named Number, 14	
DEFINED in MAP-MS-DataTypes	:	467
multiPTY.....	value reference SS-Code, '01010001'B	
DEFINED in MAP-SS-Code	:	88
mw-Status.....	identifier of MW-Status	
DEFINED in MAP-SM-DataTypes	:	184
MW-Status.....	type reference BIT STRING	
DEFINED in MAP-SM-DataTypes	:	188
USED in MAP-SM-DataTypes	:	184
NAEA-CIC.....	type reference OCTET STRING	
DEFINED in MAP-CommonDataTypes	:	319
USED in MAP-CommonDataTypes	:	37 315
naea-PreferredCI.....	identifier of [15] NAEA-PreferredCI	
DEFINED in MAP-MS-DataTypes	:	299
NAEA-PreferredCI.....	type reference SEQUENCE	
DEFINED in MAP-CommonDataTypes	:	314
USED in MAP-MS-DataTypes	:	132 299
USED in MAP-CommonDataTypes	:	36
USED in MAP-CH-DataTypes	:	66 145

naea-PreferredCI.....identifier of [10] NAEA-PreferredCI
DEFINED in MAP-CH-DataTypes : 145

naea-PreferredCIC.....identifier of [0] NAEA-CIC
DEFINED in MAP-CommonDataTypes : 315

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 48

nameString.....	identifier of [2] NameString
DEFINED in MAP-LCS-DataTypes	: 120
NameString.....	type reference USSD-String
DEFINED in MAP-LCS-DataTypes	: 128
USED in MAP-LCS-DataTypes	: 120
na-ESRD.....	identifier of [3] ISDN-AddressString
DEFINED in MAP-LCS-DataTypes	: 223
na-ESRK.....	identifier of [4] ISDN-AddressString
DEFINED in MAP-LCS-DataTypes	: 224
negativePW-Check.....	value reference NegativePW-Check, CHOICE VALUE
DEFINED in MAP-Protocol	: 372
NegativePW-Check.....	type reference ERROR
DEFINED in MAP-Errors	: 331
USED in MAP-Protocol	: 144 372
USED in MAP-SupplementaryServi	: 46 138 157 229
USED in MAP-Errors	: 65
netDetNotReachable.....	identifier of NotReachableReason
DEFINED in MAP-MS-DataTypes	: 1055
networkAccessMode.....	identifier of [24] NetworkAccessMode
DEFINED in MAP-MS-DataTypes	: 304
NetworkAccessMode.....	type reference ENUMERATED
DEFINED in MAP-MS-DataTypes	: 325
USED in MAP-MS-DataTypes	: 304
networkNode-AreaRestricted.....	identifier of Named Number, 0
DEFINED in MAP-MS-DataTypes	: 733
networkNode-Number.....	identifier of [1] ISDN-AddressString
DEFINED in MAP-SM-DataTypes	: 86
NetworkResource.....	type reference ENUMERATED
DEFINED in MAP-CommonDataTypes	: 304
USED in MAP-CommonDataTypes	: 35
USED in MAP-ER-DataTypes	: 65 160 167
networkResource.....	identifier of NetworkResource
DEFINED in MAP-ER-DataTypes	: 160
networkResource.....	identifier of NetworkResource
DEFINED in MAP-ER-DataTypes	: 167
networkSignalInfo.....	identifier of [10] ExternalSignalInfo
DEFINED in MAP-CH-DataTypes	: 99
networkSignalInfo.....	identifier of [6] ExternalSignalInfo
DEFINED in MAP-CH-DataTypes	: 187
networkSignalInfo.....	identifier of [4] ExternalSignalInfo
DEFINED in MAP-SS-DataTypes	: 290
newPassword.....	identifier of Password
DEFINED in MAP-SupplementaryServi	: 221
newPasswordsMismatch.....	identifier of Named Number, 2
DEFINED in MAP-ER-DataTypes	: 127
noAdditionalInformation.....	identifier of Named Number, 0
DEFINED in MAP-ER-DataTypes	: 306
noCUG-Restrictions.....	identifier of Named Number, 0
DEFINED in MAP-MS-DataTypes	: 607
noGroupCallNbParam.....	identifier of NoGroupCallNbParam
DEFINED in MAP-Errors	: 371
NoGroupCallNbParam.....	type reference SEQUENCE
DEFINED in MAP-ER-DataTypes	: 282

USED in MAP-Errors : 127 371
USED in MAP-ER-DataTypes : 45

noGroupCallNumberAvailable.....value reference NoGroupCallNumberAvailable, CHOICE
VALUE

DEFINED in MAP-Protocol : 359

NoGroupCallNumberAvailable.....type reference ERROR

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 49

DEFINED in MAP-Errors	:	369		2000-07-19 08:07:06
USED in MAP-Protocol	:	151	359	
USED in MAP-Group-Call-Operati	:	26	53	
USED in MAP-Errors	:	77		
 noHandoverNumberAvailable.....value reference NoHandoverNumberAvailable, CHOICE				
VALUE				
DEFINED in MAP-Protocol	:	330		
NoHandoverNumberAvailable.....type reference ERROR				
DEFINED in MAP-Errors	:	235		
USED in MAP-Protocol	:	123	330	
USED in MAP-MobileServiceOpera	:	78	225	
USED in MAP-Errors	:	36		
noPageResponse.....identifier of Named Number, 2				
DEFINED in MAP-ER-DataTypes	:	240		
noReply.....identifier of Named Number, 2				
DEFINED in MAP-CH-DataTypes	:	122		
noReplyConditionTime.....identifier of [7] Ext-NoRepCondTime				
DEFINED in MAP-MS-DataTypes	:	508		
noReplyConditionTime.....identifier of [5] NoReplyConditionTime				
DEFINED in MAP-SS-DataTypes	:	74		
NoReplyConditionTime.....type reference INTEGER				
DEFINED in MAP-SS-DataTypes	:	78		
USED in MAP-SS-DataTypes	:	30	74	100
noReplyConditionTime.....identifier of [7] NoReplyConditionTime				
DEFINED in MAP-SS-DataTypes	:	100		
noResponseFromBusyMS.....identifier of Named Number, 3				
DEFINED in MAP-CH-DataTypes	:	414		
noResponseFromFreeMS.....identifier of Named Number, 2				
DEFINED in MAP-CH-DataTypes	:	413		
noRoamingNbParam.....identifier of NoRoamingNbParam				
DEFINED in MAP-Errors	:	252		
NoRoamingNbParam.....type reference SEQUENCE				
DEFINED in MAP-ER-DataTypes	:	228		
USED in MAP-Errors	:	113	252	
USED in MAP-ER-DataTypes	:	33		
 noRoamingNumberAvailable.....value reference NoRoamingNumberAvailable, CHOICE				
VALUE				
DEFINED in MAP-Protocol	:	343		
NoRoamingNumberAvailable.....type reference ERROR				
DEFINED in MAP-Errors	:	250		
USED in MAP-Protocol	:	127	343	
USED in MAP-CallHandlingOperat	:	37	108	
USED in MAP-Errors	:	44		
noSM-RP-DA.....identifier of [5] NULL				
DEFINED in MAP-SM-DataTypes	:	136		
noSM-RP-OA.....identifier of [5] NULL				
DEFINED in MAP-SM-DataTypes	:	141		
noSubscriberReply.....value reference NoSubscriberReply, CHOICE VALUE				
DEFINED in MAP-Protocol	:	346		
NoSubscriberReply.....type reference ERROR				
DEFINED in MAP-Errors	:	267		
USED in MAP-Protocol	:	130	346	
USED in MAP-CallHandlingOperat	:	40	91	
USED in MAP-Errors	:	46		
noSubscriberReplyParam.....identifier of NoSubscriberReplyParam				
DEFINED in MAP-Errors	:	269		

```
NoSubscriberReplyParam.....type reference SEQUENCE
  DEFINED in MAP-ER-DataTypes      :   251
  USED in MAP-Errors              :   117   269
  USED in MAP-ER-DataTypes      :     36

noteMsPresentForGprs.....value reference NoteMsPresentForGprs, CHOICE VALUE
  DEFINED in MAP-Protocol        :   289
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 50

```

NoteMsPresentForGprs.....type reference OPERATION
  DEFINED in MAP-MobileServiceOpera : 350
  USED in MAP-Protocol : 33 289
  USED in MAP-MobileServiceOpera : 58

noteMsPresentForGprsArg.....identifier of NoteMsPresentForGprsArg
  DEFINED in MAP-MobileServiceOpera : 352

NoteMsPresentForGprsArg.....type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes : 945
  USED in MAP-MobileServiceOpera : 116 352
  USED in MAP-MS-DataTypes : 91

noteMsPresentForGprsRes.....identifier of NoteMsPresentForGprsRes
  DEFINED in MAP-MobileServiceOpera : 354

NoteMsPresentForGprsRes.....type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes : 952
  USED in MAP-MobileServiceOpera : 117 354
  USED in MAP-MS-DataTypes : 92

notForwarded.....identifier of Named Number, 1
  DEFINED in MAP-MS-DataTypes : 888

notificationToMSUser.....identifier of [0] NotificationToMSUser
  DEFINED in MAP-MS-DataTypes : 657

notificationToMSUser.....identifier of [1] NotificationToMSUser
  DEFINED in MAP-MS-DataTypes : 681

NotificationToMSUser.....type reference ENUMERATED
  DEFINED in MAP-MS-DataTypes : 693
  USED in MAP-MS-DataTypes : 64 657 681

notifyAndVerify-LocationAllowedIfNoReIdentifier of Named Number, 1
  DEFINED in MAP-MS-DataTypes : 695

notifyAndVerify-LocationNotAllowedIfNoReIdentifier of Named Number, 2
  DEFINED in MAP-MS-DataTypes : 696

notifyLocationAllowed.....identifier of Named Number, 0
  DEFINED in MAP-MS-DataTypes : 694

notKnownToBePorted.....identifier of Named Number, 0
  DEFINED in MAP-CH-DataTypes : 153

notProvidedFromVLR.....identifier of [2] NULL
  DEFINED in MAP-MS-DataTypes : 1056

notReachable.....identifier of Named Number, 0
  DEFINED in MAP-CH-DataTypes : 120

NotReachableReason.....type reference ENUMERATED
  DEFINED in MAP-MS-DataTypes : 1058
  USED in MAP-MS-DataTypes : 1055

notRegistered.....identifier of Named Number, 3
  DEFINED in MAP-MS-DataTypes : 1062

not-derivable.....identifier of NULL
  DEFINED in TCAPMessages : 168

numberChanged.....value reference NumberChanged, CHOICE VALUE
  DEFINED in MAP-Protocol : 311

NumberChanged.....type reference ERROR
  DEFINED in MAP-Errors : 186
  USED in MAP-Protocol : 114 311
  USED in MAP-CallHandlingOperat : 34 86
  USED in MAP-Errors : 23

numberChangedParam.....identifier of NumberChangedParam
  DEFINED in MAP-Errors : 188

NumberChangedParam.....type reference SEQUENCE

```

DEFINED in MAP-ER-DataTypes	:	200
USED in MAP-Errors	:	105 188
USED in MAP-ER-DataTypes	:	26
NumberOfForwarding.....	type reference	INTEGER
DEFINED in MAP-CH-DataTypes	:	86
USED in MAP-CH-DataTypes	:	20 91

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 51 2000-07-19 08:07:06

numberOfForwarding.....	identifier of [2] NumberOfForwarding
DEFINED in MAP-CH-DataTypes	: 91
value reference NumberOfPW-AttemptsViolation, CHOICE	
DEFINED in MAP-Protocol	: 373
NUMBEROFPW-AttemptsViolation.....	type reference ERROR
DEFINED in MAP-Errors	: 333
USED in MAP-Protocol	: 145 373
USED in MAP-SupplementaryServic	: 47 139 158 230
USED in MAP-Errors	: 66
numberPortabilityStatus.....	identifier of [13] NumberPortabilityStatus
DEFINED in MAP-CH-DataTypes	: 149
NumberPortabilityStatus.....	type reference ENUMERATED
DEFINED in MAP-CH-DataTypes	: 152
USED in MAP-CH-DataTypes	: 149
odb-Data.....	identifier of [8] ODB-Data
DEFINED in MAP-MS-DataTypes	: 421
ODB-Data.....	type reference SEQUENCE
DEFINED in MAP-MS-DataTypes	: 446
USED in MAP-MS-DataTypes	: 47 421
odb-GeneralData.....	identifier of ODB-GeneralData
DEFINED in MAP-MS-DataTypes	: 447
ODB-GeneralData.....	type reference BIT STRING
DEFINED in MAP-MS-DataTypes	: 452
USED in MAP-MS-DataTypes	: 447 725
odb-GeneralData.....	identifier of [4] ODB-GeneralData
DEFINED in MAP-MS-DataTypes	: 725
odb-HPLMN-Data.....	identifier of ODB-HPLMN-Data
DEFINED in MAP-MS-DataTypes	: 448
ODB-HPLMN-Data.....	type reference BIT STRING
DEFINED in MAP-MS-DataTypes	: 471
USED in MAP-MS-DataTypes	: 448
omc-Id.....	identifier of [3] AddressString
DEFINED in MAP-OM-DataTypes	: 40
onlyMSC.....	identifier of Named Number, 1
DEFINED in MAP-MS-DataTypes	: 327
onlySGSN.....	identifier of Named Number, 2
DEFINED in MAP-MS-DataTypes	: 328
operationCode.....	identifier of OPERATION
DEFINED in TCAPMessages	: 136
USED in TCAPMessages	: 137
operationCode.....	identifier of OPERATION
DEFINED in TCAPMessages	: 147
USED in TCAPMessages	: 148
operatorBarring.....	identifier of Named Number, 1
DEFINED in MAP-ER-DataTypes	: 99
operatorDeterminedBarring.....	identifier of Named Number, 1
DEFINED in MAP-MS-DataTypes	: 434
operatorDeterminedBarring.....	identifier of Named Number, 3
DEFINED in MAP-ER-DataTypes	: 88
OrigTransactionID.....	type reference [APPLICATION 8] IMPLICIT
TRANSACTIONID	
DEFINED in TCAPMessages	: 97
USED in TCAPMessages	: 61 69

```
orNotSupportedInGMSC.....identifier of [16] NULL
    DEFINED in MAP-CH-DataTypes      :   198

or-Capability.....identifier of [5] OR-Phase
    DEFINED in MAP-CH-DataTypes      :   94

or-Interrogation.....identifier of [4] NULL
    DEFINED in MAP-CH-DataTypes      :   93
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 52 2000-07-19 08:07:06

```

or-Interrogation..... identifier of [10] NULL
  DEFINED in MAP-CH-DataTypes : 191

or-NotAllowed..... value reference OR-NotAllowed, CHOICE VALUE
  DEFINED in MAP-Protocol : 349

OR-NotAllowed..... type reference ERROR
  DEFINED in MAP-Errors : 292
    USED in MAP-Protocol : 126 349
    USED in MAP-CallHandlingOperat : 32 84 106 118
    USED in MAP-Errors : 43

or-NotAllowedParam..... identifier of OR-NotAllowedParam
  DEFINED in MAP-Errors : 294

OR-NotAllowedParam..... type reference SEQUENCE
  DEFINED in MAP-ER-DataTypes : 183
    USED in MAP-Errors : 114 294
    USED in MAP-ER-DataTypes : 24

OR-Phase..... type reference INTEGER
  DEFINED in MAP-CH-DataTypes : 115
    USED in MAP-CH-DataTypes : 94

otid..... identifier of OrigTransactionID
  DEFINED in TCAPMessages : 61

otid..... identifier of OrigTransactionID
  DEFINED in TCAPMessages : 69

overrideCategory..... identifier of [1] OverrideCategory
  DEFINED in MAP-SS-DataTypes : 166

OverrideCategory..... type reference ENUMERATED
  DEFINED in MAP-SS-DataTypes : 173
    USED in MAP-SS-DataTypes : 28 166

overrideDisabled..... identifier of Named Number, 1
  DEFINED in MAP-SS-DataTypes : 175

overrideEnabled..... identifier of Named Number, 0
  DEFINED in MAP-SS-DataTypes : 174

ownNumberPortedOut..... identifier of Named Number, 1
  DEFINED in MAP-CH-DataTypes : 154

o-andM-HPLMN..... identifier of Named Number, 1
  DEFINED in MAP-CommonDataTypes : 338

o-andM-VPLMN..... identifier of Named Number, 2
  DEFINED in MAP-CommonDataTypes : 339

O-BcsmCamelTDPCriteriaList..... type reference SEQUENCE OF
  DEFINED in MAP-MS-DataTypes : 849
    USED in MAP-MS-DataTypes : 52 786
    USED in MAP-CH-DataTypes : 45 257

O-BcsmCamelTDPData..... type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes : 827
    USED in MAP-MS-DataTypes : 819

O-BcsmCamelTDPDataList..... identifier of O-BcsmCamelTDPDataList
  DEFINED in MAP-MS-DataTypes : 812

O-BcsmCamelTDPDataList..... type reference SEQUENCE OF
  DEFINED in MAP-MS-DataTypes : 818
    USED in MAP-MS-DataTypes : 812

O-BcsmCamelTDP-Criteria..... type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes : 852
    USED in MAP-MS-DataTypes : 850

O-BcsmCamelTDP-CriteriaList..... identifier of [4] O-BcsmCamelTDPCriteriaList
  DEFINED in MAP-MS-DataTypes : 786

```

o-BcsmCamelTDP-CriteriaList.....identifier of [3] O-BcsmCamelTDPCriteriaList
DEFINED in MAP-CH-DataTypes : 257

o-BcsmTriggerDetectionPoint.....identifier of O-BcsmTriggerDetectionPoint
DEFINED in MAP-MS-DataTypes : 828

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 53

O-BcsmTriggerDetectionPoint.....	type reference ENUMERATED
DEFINED in MAP-MS-DataTypes :	838
USED in MAP-MS-DataTypes :	828 853
o-BcsmTriggerDetectionPoint.....	identifier of O-BcsmTriggerDetectionPoint
DEFINED in MAP-MS-DataTypes :	853
o-CSI.....	identifier of [0] O-CSI
DEFINED in MAP-MS-DataTypes :	782
O-CSI.....	type reference SEQUENCE
DEFINED in MAP-MS-DataTypes :	811
USED in MAP-MS-DataTypes :	51 782
USED in MAP-CH-DataTypes :	44 211 254
o-CSI.....	identifier of [5] O-CSI
DEFINED in MAP-CH-DataTypes :	211
o-CSI.....	identifier of [1] O-CSI
DEFINED in MAP-CH-DataTypes :	254
padAccessCA-1200bps.....	value reference BearerServiceCode, '00100010'B
DEFINED in MAP-BS-Code :	69
padAccessCA-1200-75bps.....	value reference BearerServiceCode, '00100011'B
DEFINED in MAP-BS-Code :	70
padAccessCA-2400bps.....	value reference BearerServiceCode, '00100100'B
DEFINED in MAP-BS-Code :	71
padAccessCA-300bps.....	value reference BearerServiceCode, '00100001'B
DEFINED in MAP-BS-Code :	68
padAccessCA-4800bps.....	value reference BearerServiceCode, '00100101'B
DEFINED in MAP-BS-Code :	72
padAccessCA-9600bps.....	value reference BearerServiceCode, '00100110'B
DEFINED in MAP-BS-Code :	73
parameter.....	identifier of ANY DEFINED BY operationCode
DEFINED in TCAPMessages :	137
parameter.....	identifier of ANY DEFINED BY operationCode
DEFINED in TCAPMessages :	148
parameter.....	identifier of ANY DEFINED BY errorCode
DEFINED in TCAPMessages :	159
Password.....	type reference NumericString
DEFINED in MAP-SS-DataTypes :	233
USED in MAP-SupplementaryServi :	66 221 238
USED in MAP-SS-DataTypes :	24
pcs-Extensions.....	identifier of [1] PCS-Extensions
DEFINED in MAP-ExtensionDataTypes :	34
PCS-Extensions.....	type reference SEQUENCE
DEFINED in MAP-ExtensionDataTypes :	56
USED in MAP-ExtensionDataTypes :	34
pdp-Address.....	identifier of [17] PDP-Address
DEFINED in MAP-MS-DataTypes :	341
PDP-Address.....	type reference OCTET STRING
DEFINED in MAP-MS-DataTypes :	366
USED in MAP-MS-DataTypes :	341
PDP-Context.....	type reference SEQUENCE
DEFINED in MAP-MS-DataTypes :	338
USED in MAP-MS-DataTypes :	334
pdp-ContextId.....	identifier of ContextId
DEFINED in MAP-MS-DataTypes :	339
pdp-Type.....	identifier of [16] PDP-Type

DEFINED in MAP-MS-DataTypes : 340
PDP-Type.....type reference OCTET STRING
 DEFINED in MAP-MS-DataTypes : 363
 USED in MAP-MS-DataTypes : 340
permanent.....identifier of Named Number, 0

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 54 2000-07-19 08:07:06

```

DEFINED in MAP-SS-DataTypes : 169

phase1..... identifier of Named Number, 0
DEFINED in MAP-MS-DataTypes : 909

phase2..... identifier of Named Number, 1
DEFINED in MAP-MS-DataTypes : 910

plmn..... identifier of Named Number, 0
DEFINED in MAP-CommonDataTypes : 305

plmnClientList..... identifier of [2] PLMNClientList
DEFINED in MAP-MS-DataTypes : 662

PLMNClientList..... type reference SEQUENCE OF
DEFINED in MAP-MS-DataTypes : 673
USED in MAP-MS-DataTypes : 662

plmnoperator..... value reference SS-Code, '10110100'B
DEFINED in MAP-SS-Code : 166

plmnOperatorServices..... identifier of Named Number, 2
DEFINED in MAP-LCS-DataTypes : 110

plmnRoamingNotAllowed..... identifier of Named Number, 0
DEFINED in MAP-ER-DataTypes : 87

plmn-SpecificBarringType1..... identifier of Named Number, 0
DEFINED in MAP-MS-DataTypes : 472

plmn-SpecificBarringType2..... identifier of Named Number, 1
DEFINED in MAP-MS-DataTypes : 473

plmn-SpecificBarringType3..... identifier of Named Number, 2
DEFINED in MAP-MS-DataTypes : 474

plmn-SpecificBarringType4..... identifier of Named Number, 3
DEFINED in MAP-MS-DataTypes : 475

plmn-specificBS-1..... value reference BearerServiceCode, '11010001'B
DEFINED in MAP-BS-Code : 111

plmn-specificBS-2..... value reference BearerServiceCode, '11010010'B
DEFINED in MAP-BS-Code : 112

plmn-specificBS-3..... value reference BearerServiceCode, '11010011'B
DEFINED in MAP-BS-Code : 113

plmn-specificBS-4..... value reference BearerServiceCode, '11010100'B
DEFINED in MAP-BS-Code : 114

plmn-specificBS-5..... value reference BearerServiceCode, '11010101'B
DEFINED in MAP-BS-Code : 115

plmn-specificBS-6..... value reference BearerServiceCode, '11010110'B
DEFINED in MAP-BS-Code : 116

plmn-specificBS-7..... value reference BearerServiceCode, '11010111'B
DEFINED in MAP-BS-Code : 117

plmn-specificBS-8..... value reference BearerServiceCode, '11011000'B
DEFINED in MAP-BS-Code : 118

plmn-specificBS-9..... value reference BearerServiceCode, '11011001'B
DEFINED in MAP-BS-Code : 119

plmn-specificBS-A..... value reference BearerServiceCode, '11011010'B
DEFINED in MAP-BS-Code : 120

plmn-specificBS-B..... value reference BearerServiceCode, '11011011'B
DEFINED in MAP-BS-Code : 121

plmn-specificBS-C..... value reference BearerServiceCode, '11011100'B
DEFINED in MAP-BS-Code : 122

```

```
plmn-specificBS-D.....value reference BearerServiceCode, '11011101'B  
      DEFINED in MAP-BS-Code           :    123  
  
plmn-specificBS-E.....value reference BearerServiceCode, '11011110'B  
      DEFINED in MAP-BS-Code           :    124  
  
plmn-specificBS-F.....value reference BearerServiceCode, '11011111'B
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 55

DEFINED in MAP-BS-Code	:	125
plmn-specificSS-1.....	value reference SS-Code, '11110001'B	
DEFINED in MAP-SS-Code	:	135
plmn-specificSS-2.....	value reference SS-Code, '11110010'B	
DEFINED in MAP-SS-Code	:	136
plmn-specificSS-3.....	value reference SS-Code, '11110011'B	
DEFINED in MAP-SS-Code	:	137
plmn-specificSS-4.....	value reference SS-Code, '11110100'B	
DEFINED in MAP-SS-Code	:	138
plmn-specificSS-5.....	value reference SS-Code, '11110101'B	
DEFINED in MAP-SS-Code	:	139
plmn-specificSS-6.....	value reference SS-Code, '11110110'B	
DEFINED in MAP-SS-Code	:	140
plmn-specificSS-7.....	value reference SS-Code, '11110111'B	
DEFINED in MAP-SS-Code	:	141
plmn-specificSS-8.....	value reference SS-Code, '11111000'B	
DEFINED in MAP-SS-Code	:	142
plmn-specificSS-9.....	value reference SS-Code, '11111001'B	
DEFINED in MAP-SS-Code	:	143
plmn-specificSS-A.....	value reference SS-Code, '11111010'B	
DEFINED in MAP-SS-Code	:	144
plmn-specificSS-B.....	value reference SS-Code, '11111011'B	
DEFINED in MAP-SS-Code	:	145
plmn-specificSS-C.....	value reference SS-Code, '11111100'B	
DEFINED in MAP-SS-Code	:	146
plmn-specificSS-D.....	value reference SS-Code, '11111101'B	
DEFINED in MAP-SS-Code	:	147
plmn-specificSS-E.....	value reference SS-Code, '11111110'B	
DEFINED in MAP-SS-Code	:	148
plmn-specificSS-F.....	value reference SS-Code, '11111111'B	
DEFINED in MAP-SS-Code	:	149
plmn-specificTS-1.....	value reference TeleserviceCode, '11010001'B	
DEFINED in MAP-TS-Code	:	73
plmn-specificTS-2.....	value reference TeleserviceCode, '11010010'B	
DEFINED in MAP-TS-Code	:	74
plmn-specificTS-3.....	value reference TeleserviceCode, '11010011'B	
DEFINED in MAP-TS-Code	:	75
plmn-specificTS-4.....	value reference TeleserviceCode, '11010100'B	
DEFINED in MAP-TS-Code	:	76
plmn-specificTS-5.....	value reference TeleserviceCode, '11010101'B	
DEFINED in MAP-TS-Code	:	77
plmn-specificTS-6.....	value reference TeleserviceCode, '11010110'B	
DEFINED in MAP-TS-Code	:	78
plmn-specificTS-7.....	value reference TeleserviceCode, '11010111'B	
DEFINED in MAP-TS-Code	:	79
plmn-specificTS-8.....	value reference TeleserviceCode, '11011000'B	
DEFINED in MAP-TS-Code	:	80
plmn-specificTS-9.....	value reference TeleserviceCode, '11011001'B	
DEFINED in MAP-TS-Code	:	81
plmn-specificTS-A.....	value reference TeleserviceCode, '11011010'B	

DEFINED in MAP-TS-Code	:	82
plmn-specificTS-B.....	value reference TeleserviceCode, '11011011'B	
DEFINED in MAP-TS-Code	:	83
plmn-specificTS-C.....	value reference TeleserviceCode, '11011100'B	
DEFINED in MAP-TS-Code	:	84

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 56

```

plmn-specificTS-D.....value reference TeleserviceCode, '11011101'B
  DEFINED in MAP-TS-Code : 85

plmn-specificTS-E.....value reference TeleserviceCode, '11011110'B
  DEFINED in MAP-TS-Code : 86

plmn-specificTS-F.....value reference TeleserviceCode, '11011111'B
  DEFINED in MAP-TS-Code : 87

positionMethodFailure.....value reference PositionMethodFailure, CHOICE VALUE
  DEFINED in MAP-Protocol : 390

PositionMethodFailure.....type reference ERROR
  DEFINED in MAP-Errors : 386
  USED in MAP-Protocol : 157 390
  USED in MAP-LocationServiceOpe : 31 82
  USED in MAP-Errors : 82

positionMethodFailure-Diagnostic.....identifier of [0] PositionMethodFailure-Diagnostic
  DEFINED in MAP-ER-DataTypes : 316

PositionMethodFailure-Diagnostic.....type reference ENUMERATED
  DEFINED in MAP-ER-DataTypes : 320
  USED in MAP-ER-DataTypes : 316

positionMethodFailure-Param.....identifier of PositionMethodFailure-Param
  DEFINED in MAP-Errors : 388

PositionMethodFailure-Param.....type reference SEQUENCE
  DEFINED in MAP-ER-DataTypes : 315
  USED in MAP-Errors : 133 388
  USED in MAP-ER-DataTypes : 51

positionMethodNotAvailableInLocationArea.....identifier of Named Number, 8
  DEFINED in MAP-ER-DataTypes : 329

positionMethodNotAvailableInNetwork.....identifier of Named Number, 7
  DEFINED in MAP-ER-DataTypes : 328

preferentialCUG-Indicator.....identifier of CUG-Index
  DEFINED in MAP-MS-DataTypes : 623

premiumRateEntertainmentOGCallsBarred..identifier of Named Number, 4
  DEFINED in MAP-MS-DataTypes : 460

premiumRateInformationOGCallsBarred....identifier of Named Number, 3
  DEFINED in MAP-MS-DataTypes : 459

prepareGroupCall.....value reference PrepareGroupCall, CHOICE VALUE
  DEFINED in MAP-Protocol : 269

PrepareGroupCall.....type reference OPERATION
  DEFINED in MAP-Group-Call-Operati : 46
  USED in MAP-Protocol : 92 269
  USED in MAP-Group-Call-Operati : 13

prepareGroupCallArg.....identifier of PrepareGroupCallArg
  DEFINED in MAP-Group-Call-Operati : 48

PrepareGroupCallArg.....type reference SEQUENCE
  DEFINED in MAP-GR-DataTypes : 49
  USED in MAP-Group-Call-Operati : 31 48
  USED in MAP-GR-DataTypes : 14

prepareGroupCallRes.....identifier of PrepareGroupCallRes
  DEFINED in MAP-Group-Call-Operati : 50

PrepareGroupCallRes.....type reference SEQUENCE
  DEFINED in MAP-GR-DataTypes : 61
  USED in MAP-Group-Call-Operati : 32 50
  USED in MAP-GR-DataTypes : 15

prepareHandover.....value reference PrepareHandover, CHOICE VALUE
  DEFINED in MAP-Protocol : 176

```

```
PrepareHandover.....type reference OPERATION
  DEFINED in MAP-MobileServiceOpera : 216
  USED in MAP-Protocol      : 17   176
  USED in MAP-MobileServiceOpera : 30

  prepareHO-Arg.....identifier of PrepareHO-Arg
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 57

2000-07-19 08:07:06

```

DEFINED in MAP-MobileServiceOpera : 218

PrepareHO-Arg.....type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes : 260
    USED in MAP-MobileServiceOpera : 95 218
    USED in MAP-MS-DataTypes : 29

prepareHO-Res.....identifier of PrepareHO-Res
  DEFINED in MAP-MobileServiceOpera : 220

PrepareHO-Res.....type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes : 266
    USED in MAP-MobileServiceOpera : 96 220
    USED in MAP-MS-DataTypes : 30

prepareSubsequentHandover.....value reference PrepareSubsequentHandover, CHOICE
VALUE
  DEFINED in MAP-Protocol : 180

PrepareSubsequentHandover.....type reference OPERATION
  DEFINED in MAP-MobileServiceOpera : 240
    USED in MAP-Protocol : 21 180
    USED in MAP-MobileServiceOpera : 34

prepareSubsequentHO-Arg.....identifier of PrepareSubsequentHO-Arg
  DEFINED in MAP-MobileServiceOpera : 242

PrepareSubsequentHO-Arg.....type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes : 271
    USED in MAP-MobileServiceOpera : 97 242
    USED in MAP-MS-DataTypes : 31

priority.....identifier of [2] EMLPP-Priority
  DEFINED in MAP-GR-DataTypes : 56

priorityLevel0.....value reference EMLPP-Priority, 0
  DEFINED in MAP-CommonDataTypes : 401

priorityLevel1.....value reference EMLPP-Priority, 1
  DEFINED in MAP-CommonDataTypes : 402

priorityLevel2.....value reference EMLPP-Priority, 2
  DEFINED in MAP-CommonDataTypes : 403

priorityLevel3.....value reference EMLPP-Priority, 3
  DEFINED in MAP-CommonDataTypes : 404

priorityLevel4.....value reference EMLPP-Priority, 4
  DEFINED in MAP-CommonDataTypes : 405

priorityLevelA.....value reference EMLPP-Priority, 6
  DEFINED in MAP-CommonDataTypes : 399

priorityLevelB.....value reference EMLPP-Priority, 5
  DEFINED in MAP-CommonDataTypes : 400

privacyOverride.....identifier of [1] NULL
  DEFINED in MAP-LCS-DataTypes : 74

privacyOverrideNotApplicable.....identifier of Named Number, 3
  DEFINED in MAP-ER-DataTypes : 309

PrivateExtension.....type reference SEQUENCE
  DEFINED in MAP-ExtensionDataTypes : 40
    USED in MAP-ExtensionDataTypes : 15 38

privateExtensionList.....identifier of [0] PrivateExtensionList
  DEFINED in MAP-ExtensionDataTypes : 33

PrivateExtensionList.....type reference SEQUENCE OF
  DEFINED in MAP-ExtensionDataTypes : 37
    USED in MAP-ExtensionDataTypes : 33

problem.....identifier of CHOICE
  DEFINED in TCAPMessages : 169

```

```
processAccessSignalling.....value reference ProcessAccessSignalling, CHOICE VALUE
    DEFINED in MAP-Protocol : 178

ProcessAccessSignalling.....type reference OPERATION
    DEFINED in MAP-MobileServiceOpera : 232
    USED in MAP-Protocol : 19   178
    USED in MAP-MobileServiceOpera : 32
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 58

2000-07-19 08:07:06

processGroupCallSignalling.....value reference ProcessGroupCallSignalling, CHOICE
 VALUE
 DEFINED in MAP-Protocol : 271

ProcessGroupCallSignalling.....type reference OPERATION
 DEFINED in MAP-Group-Call-Operati : 63
 USED in MAP-Protocol : 93 271
 USED in MAP-Group-Call-Operati : 16

processGroupCallSignallingArg.....identifier of ProcessGroupCallSignallingArg
 DEFINED in MAP-Group-Call-Operati : 65

ProcessGroupCallSignallingArg.....type reference SEQUENCE
 DEFINED in MAP-GR-DataTypes : 85
 USED in MAP-Group-Call-Operati : 36 65
 USED in MAP-GR-DataTypes : 19

processUnstructuredSS-Request.....value reference ProcessUnstructuredSS-Request, CHOICE
 VALUE
 DEFINED in MAP-Protocol : 234

ProcessUnstructuredSS-Request.....type reference OPERATION
 DEFINED in MAP-SupplementaryServi : 175
 USED in MAP-Protocol : 67 234
 USED in MAP-SupplementaryServi : 18

protocolId.....identifier of ProtocolId
 DEFINED in MAP-CommonDataTypes : 178

ProtocolId.....type reference ENUMERATED
 DEFINED in MAP-CommonDataTypes : 196
 USED in MAP-CommonDataTypes : 178

provideRoamingNumber.....value reference ProvideRoamingNumber, CHOICE VALUE
 DEFINED in MAP-Protocol : 218

ProvideRoamingNumber.....type reference OPERATION
 DEFINED in MAP-CallHandlingOperat : 96
 USED in MAP-Protocol : 50 218
 USED in MAP-CallHandlingOperat : 14

provideRoamingNumberArg.....identifier of ProvideRoamingNumberArg
 DEFINED in MAP-CallHandlingOperat : 98

ProvideRoamingNumberArg.....type reference SEQUENCE
 DEFINED in MAP-CH-DataTypes : 181
 USED in MAP-CallHandlingOperat : 54 98
 USED in MAP-CH-DataTypes : 16

provideRoamingNumberRes.....identifier of ProvideRoamingNumberRes
 DEFINED in MAP-CallHandlingOperat : 100

ProvideRoamingNumberRes.....type reference SEQUENCE
 DEFINED in MAP-CH-DataTypes : 200
 USED in MAP-CallHandlingOperat : 55 100
 USED in MAP-CH-DataTypes : 17

provideSIWFSNumber.....value reference ProvideSIWFSNumber, CHOICE VALUE
 DEFINED in MAP-Protocol : 220

ProvideSIWFSNumber.....type reference OPERATION
 DEFINED in MAP-CallHandlingOperat : 122
 USED in MAP-Protocol : 52 220
 USED in MAP-CallHandlingOperat : 16

provideSIWFSNumberArg.....identifier of ProvideSIWFSNumberArg
 DEFINED in MAP-CallHandlingOperat : 124

ProvideSIWFSNumberArg.....type reference SEQUENCE
 DEFINED in MAP-CH-DataTypes : 290
 USED in MAP-CallHandlingOperat : 58 124
 USED in MAP-CH-DataTypes : 23

provideSIWFSNumberRes.....identifier of ProvideSIWFSNumberRes

```
DEFINED in MAP-CallHandlingOperat : 126
ProvideSIWFSNumberRes.....type reference SEQUENCE
  DEFINED in MAP-CH-DataTypes : 309
    USED in MAP-CallHandlingOperat : 59 126
    USED in MAP-CH-DataTypes : 24
provideSubscriberInfo.....value reference ProvideSubscriberInfo, CHOICE VALUE
  DEFINED in MAP-Protocol : 256
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 59 2000-07-19 08:07:06

```

ProvideSubscriberInfo.....type reference OPERATION
  DEFINED in MAP-MobileServiceOpera : 191
  USED in MAP-Protocol : 29 256
  USED in MAP-MobileServiceOpera : 24

provideSubscriberInfoArg.....identifier of ProvideSubscriberInfoArg
  DEFINED in MAP-MobileServiceOpera : 193

ProvideSubscriberInfoArg.....type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes : 1006
  USED in MAP-MobileServiceOpera : 108 193
  USED in MAP-MS-DataTypes : 72

provideSubscriberInfoRes.....identifier of ProvideSubscriberInfoRes
  DEFINED in MAP-MobileServiceOpera : 195

ProvideSubscriberInfoRes.....type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes : 1013
  USED in MAP-MobileServiceOpera : 109 195
  USED in MAP-MS-DataTypes : 73

provideSubscriberLocation.....value reference ProvideSubscriberLocation, CHOICE
VALUE
  DEFINED in MAP-Protocol : 293

ProvideSubscriberLocation.....type reference OPERATION
  DEFINED in MAP-LocationServiceOpe : 66
  USED in MAP-Protocol : 101 293
  USED in MAP-LocationServiceOpe : 13

provideSubscriberLocation-Arg.....identifier of ProvideSubscriberLocation-Arg
  DEFINED in MAP-LocationServiceOpe : 68

ProvideSubscriberLocation-Arg.....type reference SEQUENCE
  DEFINED in MAP-LCS-DataTypes : 70
  USED in MAP-LocationServiceOpe : 43 68
  USED in MAP-LCS-DataTypes : 13

provideSubscriberLocation-Res.....identifier of ProvideSubscriberLocation-Res
  DEFINED in MAP-LocationServiceOpe : 70

ProvideSubscriberLocation-Res.....type reference SEQUENCE
  DEFINED in MAP-LCS-DataTypes : 165
  USED in MAP-LocationServiceOpe : 44 70
  USED in MAP-LCS-DataTypes : 14

provisionedSS.....identifier of [7] Ext-SS-InfoList
  DEFINED in MAP-MS-DataTypes : 420

purgeMS.....value reference PurgeMS, CHOICE VALUE
  DEFINED in MAP-Protocol : 170

PurgeMS.....type reference OPERATION
  DEFINED in MAP-MobileServiceOpera : 156
  USED in MAP-Protocol : 14 170
  USED in MAP-MobileServiceOpera : 17

purgeMS-Arg.....identifier of PurgeMS-Arg
  DEFINED in MAP-MobileServiceOpera : 158

PurgeMS-Arg.....type reference [3] SEQUENCE
  DEFINED in MAP-MS-DataTypes : 202
  USED in MAP-MobileServiceOpera : 90 158
  USED in MAP-MS-DataTypes : 20

purgeMS-Res.....identifier of PurgeMS-Res
  DEFINED in MAP-MobileServiceOpera : 160

PurgeMS-Res.....type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes : 209
  USED in MAP-MobileServiceOpera : 91 160
  USED in MAP-MS-DataTypes : 21

pvlr.....identifier of Named Number, 3

```

DEFINED in MAP-CommonDataTypes : 308
pw-RegistrationFailure.....value reference PW-RegistrationFailure, CHOICE VALUE
 DEFINED in MAP-Protocol : 371

PW-RegistrationFailure.....type reference ERROR
 DEFINED in MAP-Errors : 327
 USED in MAP-Protocol : 143 371

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 60

USED in MAP-SupplementaryServi :	45	228
USED in MAP-Errors :	64	
pw-RegistrationFailureCause..... identifier of PW-RegistrationFailureCause		
DEFINED in MAP-Errors :	329	
PW-RegistrationFailureCause..... type reference ENUMERATED		
DEFINED in MAP-ER-DataTypes :	124	
USED in MAP-Errors :	98	329
USED in MAP-ER-DataTypes :	18	
p-abortCause..... identifier of P-AbortCause		
DEFINED in TCAPMessages :	76	
P-AbortCause..... type reference [APPLICATION 10] IMPLICIT INTEGER		
DEFINED in TCAPMessages :	102	
USED in TCAPMessages :	76	
qoSNotAttainable..... identifier of Named Number, 6		
DEFINED in MAP-ER-DataTypes :	327	
qos-Subscribed..... identifier of [18] QoS-Subscribed		
DEFINED in MAP-MS-DataTypes :	342	
QoS-Subscribed..... type reference OCTET STRING		
DEFINED in MAP-MS-DataTypes :	374	
USED in MAP-MS-DataTypes :	342	
rand..... identifier of RAND		
DEFINED in MAP-MS-DataTypes :	224	
RAND..... type reference OCTET STRING		
DEFINED in MAP-MS-DataTypes :	229	
USED in MAP-MS-DataTypes :	224	
readyForSM..... value reference ReadyForSM, CHOICE VALUE		
DEFINED in MAP-Protocol :	252	
ReadyForSM..... type reference OPERATION		
DEFINED in MAP-ShortMessageServic :	137	
USED in MAP-Protocol :	86	252
USED in MAP-ShortMessageServic :	19	
readyForSM-Arg..... identifier of ReadyForSM-Arg		
DEFINED in MAP-ShortMessageServic :	139	
ReadyForSM-Arg..... type reference SEQUENCE		
DEFINED in MAP-SM-DataTypes :	196	
USED in MAP-ShortMessageServic :	56	139
USED in MAP-SM-DataTypes :	24	
readyForSM-Res..... identifier of ReadyForSM-Res		
DEFINED in MAP-ShortMessageServic :	141	
ReadyForSM-Res..... type reference SEQUENCE		
DEFINED in MAP-SM-DataTypes :	205	
USED in MAP-ShortMessageServic :	57	141
USED in MAP-SM-DataTypes :	25	
reason..... identifier of CHOICE		
DEFINED in TCAPMessages :	75	
regionalSubscNotSupported..... identifier of Named Number, 3		
DEFINED in MAP-MS-DataTypes :	736	
regionalSubscriptionData..... identifier of [10] ZoneCodeList		
DEFINED in MAP-MS-DataTypes :	423	
regionalSubscriptionIdentifier..... identifier of [5] ZoneCode		
DEFINED in MAP-MS-DataTypes :	745	
regionalSubscriptionResponse..... identifier of [5] RegionalSubscriptionResponse		
DEFINED in MAP-MS-DataTypes :	726	
RegionalSubscriptionResponse..... type reference ENUMERATED		

DEFINED in MAP-MS-DataTypes : 732
USED in MAP-MS-DataTypes : 727 777

regionalSubscriptionResponse.....identifier of [0] RegionalSubscriptionResponse
DEFINED in MAP-MS-DataTypes : 776

registerCC-Entry.....value reference RegisterCC-Entry, CHOICE VALUE

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 61

DEFINED in MAP-Protocol	:	240
RegisterCC-Entry	type reference OPERATION
DEFINED in MAP-SupplementaryServi	:	251
USED in MAP-Protocol	:	73 240
USED in MAP-SupplementaryServi	:	24
registerCC-EntryArg	identifier of RegisterCC-EntryArg
DEFINED in MAP-SupplementaryServi	:	253
RegisterCC-EntryArg	type reference SEQUENCE
DEFINED in MAP-SS-DataTypes	:	280
USED in MAP-SupplementaryServi	:	70 253
USED in MAP-SS-DataTypes	:	37
registerCC-EntryRes	identifier of RegisterCC-EntryRes
DEFINED in MAP-SupplementaryServi	:	255
RegisterCC-EntryRes	type reference SEQUENCE
DEFINED in MAP-SS-DataTypes	:	299
USED in MAP-SupplementaryServi	:	71 255
USED in MAP-SS-DataTypes	:	38
registerPassword	value reference RegisterPassword, CHOICE VALUE
DEFINED in MAP-Protocol	:	238
RegisterPassword	type reference OPERATION
DEFINED in MAP-SupplementaryServi	:	217
USED in MAP-Protocol	:	70 238
USED in MAP-SupplementaryServi	:	21
registerSS	value reference RegisterSS, CHOICE VALUE
DEFINED in MAP-Protocol	:	229
RegisterSS	type reference OPERATION
DEFINED in MAP-SupplementaryServi	:	87
USED in MAP-Protocol	:	62 229
USED in MAP-SupplementaryServi	:	13
registerSS-Arg	identifier of RegisterSS-Arg
DEFINED in MAP-SupplementaryServi	:	89
RegisterSS-Arg	type reference SEQUENCE
DEFINED in MAP-SS-DataTypes	:	69
USED in MAP-SupplementaryServi	:	60 89
USED in MAP-SS-DataTypes	:	14
reject	identifier of [4] IMPLICIT Reject
DEFINED in TCAPMessages	:	128
Reject	type reference SEQUENCE
DEFINED in TCAPMessages	:	165
USED in TCAPMessages	:	128
rejected	identifier of Named Number, 1
DEFINED in MAP-CH-DataTypes	:	412
releaseCall	identifier of Named Number, 1
DEFINED in MAP-MS-DataTypes	:	897
releaseGroupCall	identifier of [2] NULL
DEFINED in MAP-GR-DataTypes	:	88
remoteUserFree	value reference RemoteUserFree, CHOICE VALUE
DEFINED in MAP-Protocol	:	224
RemoteUserFree	type reference OPERATION
DEFINED in MAP-CallHandlingOperat	:	171
USED in MAP-Protocol	:	56 224
USED in MAP-CallHandlingOperat	:	20
remoteUserFreeArg	identifier of RemoteUserFreeArg
DEFINED in MAP-CallHandlingOperat	:	173
RemoteUserFreeArg	type reference SEQUENCE

DEFINED in MAP-CH-DataTypes	:	395
USED in MAP-CallHandlingOperat	:	66 173
USED in MAP-CH-DataTypes	:	31
remoteUserFreeRes.....	identifier of RemoteUserFreeRes
DEFINED in MAP-CallHandlingOperat	:	175

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 62 2000-07-19 08:07:06

```

RemoteUserFreeRes.....type reference SEQUENCE
  DEFINED in MAP-CH-DataTypes : 405
  USED in MAP-CallHandlingOperat : 67 175
  USED in MAP-CH-DataTypes : 32

replaceB-Number.....identifier of [4] NULL
  DEFINED in MAP-CH-DataTypes : 400

ReportingState.....type reference ENUMERATED
  DEFINED in MAP-CH-DataTypes : 332
  USED in MAP-CH-DataTypes : 328

reportSM-DeliveryStatus.....value reference ReportSM-DeliveryStatus, CHOICE VALUE
  DEFINED in MAP-Protocol : 249

ReportSM-DeliveryStatus.....type reference OPERATION
  DEFINED in MAP-ShortMessageServic : 112
  USED in MAP-Protocol : 83 249
  USED in MAP-ShortMessageServic : 16

reportSM-DeliveryStatusArg.....identifier of ReportSM-DeliveryStatusArg
  DEFINED in MAP-ShortMessageServic : 114

ReportSM-DeliveryStatusArg.....type reference SEQUENCE
  DEFINED in MAP-SM-DataTypes : 143
  USED in MAP-ShortMessageServic : 52 114
  USED in MAP-SM-DataTypes : 20

reportSM-DeliveryStatusRes.....identifier of ReportSM-DeliveryStatusRes
  DEFINED in MAP-ShortMessageServic : 116

ReportSM-DeliveryStatusRes.....type reference SEQUENCE
  DEFINED in MAP-SM-DataTypes : 171
  USED in MAP-ShortMessageServic : 53 116
  USED in MAP-SM-DataTypes : 21

requestedBasicServiceViolatesCUG-Constraidentifier of Named Number, 5
  DEFINED in MAP-ER-DataTypes : 115

requestedInfo.....identifier of [2] RequestedInfo
  DEFINED in MAP-MS-DataTypes : 1009

RequestedInfo.....type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes : 1024
  USED in MAP-MS-DataTypes : 1009 1068

requestedInfo.....identifier of [1] RequestedInfo
  DEFINED in MAP-MS-DataTypes : 1068

reset.....value reference Reset, CHOICE VALUE
  DEFINED in MAP-Protocol : 202

Reset.....type reference OPERATION
  DEFINED in MAP-MobileServiceOpera : 303
  USED in MAP-Protocol : 26 202
  USED in MAP-MobileServiceOpera : 47

resetArg.....identifier of ResetArg
  DEFINED in MAP-MobileServiceOpera : 305

ResetArg.....type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes : 959
  USED in MAP-MobileServiceOpera : 105 305
  USED in MAP-MS-DataTypes : 67

resourceLimitation.....value reference ResourceLimitation, CHOICE VALUE
  DEFINED in MAP-Protocol : 305

ResourceLimitation.....type reference ERROR
  DEFINED in MAP-Errors : 173
  USED in MAP-Protocol : 150 305
  USED in MAP-CallHandlingOperat : 45 128 140 156
  USED in MAP-LocationServiceOpe : 32 93
  USED in MAP-Errors : 19

```

```
resourceLimitation.....identifier of Named Number, 4
    DEFINED in TCAPMessages      : 107

resourceLimitation.....identifier of Named Number, 3
    DEFINED in TCAPMessages      : 186

resourceLimitationParam.....identifier of ResourceLimitationParam
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 63

DEFINED in MAP-Errors	:	175
ResourceLimitationParam	type reference SEQUENCE
DEFINED in MAP-ER-DataTypes	:	278
USED in MAP-Errors	:	126 175
USED in MAP-ER-DataTypes	:	44
responseTime	identifier of [3] ResponseTime
DEFINED in MAP-LCS-DataTypes	:	141
ResponseTime	type reference SEQUENCE
DEFINED in MAP-LCS-DataTypes	:	153
USED in MAP-LCS-DataTypes	:	21 141
responseTimeCategory	identifier of ResponseTimeCategory
DEFINED in MAP-LCS-DataTypes	:	154
ResponseTimeCategory	type reference ENUMERATED
DEFINED in MAP-LCS-DataTypes	:	158
USED in MAP-LCS-DataTypes	:	154
restoreData	value reference RestoreData, CHOICE VALUE
DEFINED in MAP-Protocol	:	205
RestoreData	type reference OPERATION
DEFINED in MAP-MobileServiceOpera	:	309
USED in MAP-Protocol	:	28 205
USED in MAP-MobileServiceOpera	:	49
restoreDataArg	identifier of RestoreDataArg
DEFINED in MAP-MobileServiceOpera	:	311
RestoreDataArg	type reference SEQUENCE
DEFINED in MAP-MS-DataTypes	:	964
USED in MAP-MobileServiceOpera	:	106 311
USED in MAP-MS-DataTypes	:	68
restoreDataRes	identifier of RestoreDataRes
DEFINED in MAP-MobileServiceOpera	:	313
RestoreDataRes	type reference SEQUENCE
DEFINED in MAP-MS-DataTypes	:	971
USED in MAP-MobileServiceOpera	:	107 313
USED in MAP-MS-DataTypes	:	69
restrictedArea	identifier of Named Number, 2
DEFINED in MAP-MS-DataTypes	:	1061
restrictedArea	identifier of Named Number, 1
DEFINED in MAP-ER-DataTypes	:	239
result-RR	identifier of SEQUENCE
DEFINED in TCAPMessages	:	146
resumeCallHandling	value reference ResumeCallHandling, CHOICE VALUE
DEFINED in MAP-Protocol	:	219
ResumeCallHandling	type reference OPERATION
DEFINED in MAP-CallHandlingOperat	:	110
USED in MAP-Protocol	:	51 219
USED in MAP-CallHandlingOperat	:	15
resumeCallHandlingArg	identifier of ResumeCallHandlingArg
DEFINED in MAP-CallHandlingOperat	:	112
ResumeCallHandlingArg	type reference SEQUENCE
DEFINED in MAP-CH-DataTypes	:	205
USED in MAP-CallHandlingOperat	:	56 112
USED in MAP-CH-DataTypes	:	18
resumeCallHandlingRes	identifier of ResumeCallHandlingRes
DEFINED in MAP-CallHandlingOperat	:	114
ResumeCallHandlingRes	type reference SEQUENCE
DEFINED in MAP-CH-DataTypes	:	232

USED in MAP-CallHandlingOperat : 57 114
USED in MAP-CH-DataTypes : 19

returnError.....identifier of [3] IMPLICIT ReturnError
DEFINED in TCAPMessages : 127

ReturnError.....type reference SEQUENCE

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 64

DEFINED in TCAPMessages	:	156
USED in TCAPMessages	:	127
returnErrorProblem..... identifier of [3] IMPLICIT ReturnErrorProblem		
DEFINED in TCAPMessages	:	173
ReturnErrorProblem..... type reference INTEGER		
DEFINED in TCAPMessages	:	196
USED in TCAPMessages	:	173
returnErrorUnexpected..... identifier of Named Number, 1		
DEFINED in TCAPMessages	:	197
ReturnResult..... type reference SEQUENCE		
DEFINED in TCAPMessages	:	144
USED in TCAPMessages	:	126 129
returnResultLast..... identifier of [2] IMPLICIT ReturnResult		
DEFINED in TCAPMessages	:	126
returnResultNotLast..... identifier of [7] IMPLICIT ReturnResult		
DEFINED in TCAPMessages	:	129
returnResultProblem..... identifier of [2] IMPLICIT ReturnResultProblem		
DEFINED in TCAPMessages	:	172
ReturnResultProblem..... type reference INTEGER		
DEFINED in TCAPMessages	:	192
USED in TCAPMessages	:	172
returnResultUnexpected..... identifier of Named Number, 1		
DEFINED in TCAPMessages	:	193
roamingNotAllowed..... value reference RoamingNotAllowed, CHOICE VALUE		
DEFINED in MAP-Protocol	:	319
RoamingNotAllowed..... type reference ERROR		
DEFINED in MAP-Errors	:	204
USED in MAP-Protocol	:	118 319
USED in MAP-MobileServiceOpera	:	76 144 187
USED in MAP-Errors	:	29
roamingNotAllowedCause..... identifier of RoamingNotAllowedCause		
DEFINED in MAP-ER-DataTypes	:	82
RoamingNotAllowedCause..... type reference ENUMERATED		
DEFINED in MAP-ER-DataTypes	:	86
USED in MAP-ER-DataTypes	:	82
roamingNotAllowedParam..... identifier of RoamingNotAllowedParam		
DEFINED in MAP-Errors	:	206
RoamingNotAllowedParam..... type reference SEQUENCE		
DEFINED in MAP-ER-DataTypes	:	81
USED in MAP-Errors	:	107 206
USED in MAP-ER-DataTypes	:	14
roamingNumber..... identifier of ISDN-AddressString		
DEFINED in MAP-CH-DataTypes	:	168
roamingNumber..... identifier of ISDN-AddressString		
DEFINED in MAP-CH-DataTypes	:	201
roamingRestrictedInSgsnDueToUnsupportedFIdentifier of [23] NULL		
DEFINED in MAP-MS-DataTypes	:	302
roamingRestrictedInSgsnDueToUnsuppportedIdentifier of [11] NULL		
DEFINED in MAP-MS-DataTypes	:	752
roamingRestrictionDueToUnsupportedFeaturIdentifier of [9] NULL		
DEFINED in MAP-MS-DataTypes	:	422
roamingRestrictionDueToUnsupportedFeaturIdentifier of [4] NULL		
DEFINED in MAP-MS-DataTypes	:	744

```
RoutingInfo.....type reference CHOICE
  DEFINED in MAP-CH-DataTypes   :
    USED in MAP-CH-DataTypes   : 167
                                : 243

routingInfo.....identifier of RoutingInfo
  DEFINED in MAP-CH-DataTypes   :
                                : 243
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 65

2000-07-19 08:07:06

```

routingInfoForLCS-Arg.....identifier of RoutingInfoForLCS-Arg
  DEFINED in MAP-LocationServiceOpe : 54

RoutingInfoForLCS-Arg.....type reference SEQUENCE
  DEFINED in MAP-LCS-DataTypes : 52
    USED in MAP-LocationServiceOpe : 41 54
    USED in MAP-LCS-DataTypes : 11

routingInfoForLCS-Res.....identifier of RoutingInfoForLCS-Res
  DEFINED in MAP-LocationServiceOpe : 56

RoutingInfoForLCS-Res.....type reference SEQUENCE
  DEFINED in MAP-LCS-DataTypes : 58
    USED in MAP-LocationServiceOpe : 42 56
    USED in MAP-LCS-DataTypes : 12

routingInfoForSM-Arg.....identifier of RoutingInfoForSM-Arg
  DEFINED in MAP-ShortMessageServic : 69

RoutingInfoForSM-Arg.....type reference SEQUENCE
  DEFINED in MAP-SM-DataTypes : 52
    USED in MAP-ShortMessageServic : 46 69
    USED in MAP-SM-DataTypes : 14

routingInfoForSM-Res.....identifier of RoutingInfoForSM-Res
  DEFINED in MAP-ShortMessageServic : 71

RoutingInfoForSM-Res.....type reference SEQUENCE
  DEFINED in MAP-SM-DataTypes : 79
    USED in MAP-ShortMessageServic : 47 71
    USED in MAP-SM-DataTypes : 15

rss.....identifier of Named Number, 7
  DEFINED in MAP-CommonDataTypes : 312

ruf-Outcome.....identifier of [0] RUF-Outcome
  DEFINED in MAP-CH-DataTypes : 406

RUF-Outcome.....type reference ENUMERATED
  DEFINED in MAP-CH-DataTypes : 410
    USED in MAP-CH-DataTypes : 406

sc-AddressNotIncluded.....identifier of Named Number, 0
  DEFINED in MAP-SM-DataTypes : 189

sc-Congestion.....identifier of Named Number, 4
  DEFINED in MAP-ER-DataTypes : 135

sendAuthenticationInfo.....value reference SendAuthenticationInfo, CHOICE VALUE
  DEFINED in MAP-Protocol : 186

SendAuthenticationInfo.....type reference OPERATION
  DEFINED in MAP-MobileServiceOpera : 253
    USED in MAP-Protocol : 22 186
    USED in MAP-MobileServiceOpera : 37

sendAuthenticationInfoArg.....identifier of SendAuthenticationInfoArg
  DEFINED in MAP-MobileServiceOpera : 255

SendAuthenticationInfoArg.....type reference IMSI
  DEFINED in MAP-MS-DataTypes : 279
    USED in MAP-MobileServiceOpera : 98 255
    USED in MAP-MS-DataTypes : 34

sendAuthenticationInfoRes.....identifier of SendAuthenticationInfoRes
  DEFINED in MAP-MobileServiceOpera : 257

SendAuthenticationInfoRes.....type reference AuthenticationSetList
  DEFINED in MAP-MS-DataTypes : 281
    USED in MAP-MobileServiceOpera : 99 257
    USED in MAP-MS-DataTypes : 35

sendEndSignal.....value reference SendEndSignal, CHOICE VALUE
  DEFINED in MAP-Protocol : 177

```

```
SendEndSignal.....type reference OPERATION
  DEFINED in MAP-MobileServiceOpera : 227
    USED in MAP-Protocol : 18   177
    USED in MAP-MobileServiceOpera : 31

sendGroupCallEndSignal.....value reference SendGroupCallEndSignal, CHOICE VALUE
  DEFINED in MAP-Protocol : 270
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 66 2000-07-19 08:07:06

```

SendGroupCallEndSignal.....type reference OPERATION
  DEFINED in MAP-Group-Call-Operati :      56
  USED in MAP-Protocol           :     95    270
  USED in MAP-Group-Call-Operati :      14

sendGroupCallEndSignalArg.....identifier of SendGroupCallEndSignalArg
  DEFINED in MAP-Group-Call-Operati :      58

SendGroupCallEndSignalArg.....type reference SEQUENCE
  DEFINED in MAP-GR-DataTypes   :      66
  USED in MAP-Group-Call-Operati :     33    58
  USED in MAP-GR-DataTypes   :      16

sendGroupCallEndSignalRes.....identifier of SendGroupCallEndSignalRes
  DEFINED in MAP-Group-Call-Operati :      60

SendGroupCallEndSignalRes.....type reference SEQUENCE
  DEFINED in MAP-GR-DataTypes   :      71
  USED in MAP-Group-Call-Operati :     34    60
  USED in MAP-GR-DataTypes   :      17

sendIdentification.....value reference SendIdentification, CHOICE VALUE
  DEFINED in MAP-Protocol       :     171

SendIdentification.....type reference OPERATION
  DEFINED in MAP-MobileServiceOpera :     167
  USED in MAP-Protocol          :     15    171
  USED in MAP-MobileServiceOpera :     18

sendIdentificationRes.....identifier of SendIdentificationRes
  DEFINED in MAP-MobileServiceOpera :     171

SendIdentificationRes.....type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes   :     215
  USED in MAP-MobileServiceOpera :     92    171
  USED in MAP-MS-DataTypes   :     22

sendIMSI.....value reference SendIMSI, CHOICE VALUE
  DEFINED in MAP-Protocol       :     212

SendIMSI.....type reference OPERATION
  DEFINED in MAP-OperationAndMainte :     77
  USED in MAP-Protocol          :     43    212
  USED in MAP-OperationAndMainte :     15

sendRoutingInfo.....value reference SendRoutingInfo, CHOICE VALUE
  DEFINED in MAP-Protocol       :     217

SendRoutingInfo.....type reference OPERATION
  DEFINED in MAP-CallHandlingOperat :     74
  USED in MAP-Protocol          :     49    217
  USED in MAP-CallHandlingOperat :     13

sendRoutingInfoArg.....identifier of SendRoutingInfoArg
  DEFINED in MAP-CallHandlingOperat :     76

SendRoutingInfoArg.....type reference SEQUENCE
  DEFINED in MAP-CH-DataTypes   :     88
  USED in MAP-CallHandlingOperat :     52    76
  USED in MAP-CH-DataTypes   :     14

sendRoutingInfoForGprs.....value reference SendRoutingInfoForGprs, CHOICE VALUE
  DEFINED in MAP-Protocol       :     281

SendRoutingInfoForGprs.....type reference OPERATION
  DEFINED in MAP-MobileServiceOpera :     322
  USED in MAP-Protocol          :     31    281
  USED in MAP-MobileServiceOpera :     52

sendRoutingInfoForGprsArg.....identifier of SendRoutingInfoForGprsArg
  DEFINED in MAP-MobileServiceOpera :     324

SendRoutingInfoForGprsArg.....type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes   :     915

```

USED in MAP-MobileServiceOpera : 112 324
USED in MAP-MS-DataTypes : 83

sendRoutingInfoForGprsRes.....identifier of SendRoutingInfoForGprsRes
DEFINED in MAP-MobileServiceOpera : 326

SendRoutingInfoForGprsRes.....type reference SEQUENCE

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 67

sendRoutingInfoForLCS.....	value reference	SendRoutingInfoForLCS, CHOICE VALUE
DEFINED in MAP-Protocol	:	294
SendRoutingInfoForLCS.....	type reference	OPERATION
DEFINED in MAP-LocationServiceOpe	:	52
USED in MAP-Protocol	:	102 294
USED in MAP-LocationServiceOpe	:	14
sendRoutingInfoForSM.....	value reference	SendRoutingInfoForSM, CHOICE VALUE
DEFINED in MAP-Protocol	:	246
SendRoutingInfoForSM.....	type reference	OPERATION
DEFINED in MAP-ShortMessageServic	:	67
USED in MAP-Protocol	:	80 246
USED in MAP-ShortMessageServic	:	13
sendRoutingInfoRes.....	identifier of	SendRoutingInfoRes
DEFINED in MAP-CallHandlingOperat	:	78
SendRoutingInfoRes.....	type reference	[3] SEQUENCE
DEFINED in MAP-CH-DataTypes	:	130
USED in MAP-CallHandlingOperat	:	53 78
USED in MAP-CH-DataTypes	:	15
serviceCentreAddress.....	identifier of	[2] AddressString
DEFINED in MAP-SM-DataTypes	:	55
serviceCentreAddress.....	identifier of	AddressString
DEFINED in MAP-SM-DataTypes	:	145
serviceCentreAddress.....	identifier of	AddressString
DEFINED in MAP-SM-DataTypes	:	179
serviceCentreAddressDA.....	identifier of	[4] AddressString
DEFINED in MAP-SM-DataTypes	:	135
serviceCentreAddressOA.....	identifier of	[4] AddressString
DEFINED in MAP-SM-DataTypes	:	140
serviceGranted.....	identifier of	Named Number, 0
DEFINED in MAP-MS-DataTypes	:	433
serviceIndicator.....	identifier of	[2] ServiceIndicator
DEFINED in MAP-SS-DataTypes	:	288
ServiceIndicator.....	type reference	BIT STRING
DEFINED in MAP-SS-DataTypes	:	293
USED in MAP-SS-DataTypes	:	288
serviceKey.....	identifier of	ServiceKey
DEFINED in MAP-MS-DataTypes	:	829
ServiceKey.....	type reference	INTEGER
DEFINED in MAP-MS-DataTypes	:	836
USED in MAP-MS-DataTypes	:	54 829
USED in MAP-CH-DataTypes	:	38 276
serviceKey.....	identifier of	ServiceKey
DEFINED in MAP-CH-DataTypes	:	276
setReportingState.....	value reference	SetReportingState, CHOICE VALUE
DEFINED in MAP-Protocol	:	222
SetReportingState.....	type reference	OPERATION
DEFINED in MAP-CallHandlingOperat	:	145
USED in MAP-Protocol	:	54 222
USED in MAP-CallHandlingOperat	:	18
setReportingStateArg.....	identifier of	SetReportingStateArg
DEFINED in MAP-CallHandlingOperat	:	147

```
SetReportingStateArg.....type reference SEQUENCE
  DEFINED in MAP-CH-DataTypes      :    325
    USED in MAP-CallHandlingOperat :    62    147
    USED in MAP-CH-DataTypes      :    27

setReportingStateRes.....identifier of SetReportingStateRes
  DEFINED in MAP-CallHandlingOperat :    149
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 68 2000-07-19 08:07:06

```

SetReportingStateRes.....type reference SEQUENCE
  DEFINED in MAP-CH-DataTypes : 340
  USED in MAP-CallHandlingOperat : 63 149
  USED in MAP-CH-DataTypes : 28

sgsn-Address.....identifier of GSN-Address
  DEFINED in MAP-MS-DataTypes : 240

sgsn-Address.....identifier of [0] GSN-Address
  DEFINED in MAP-MS-DataTypes : 923

sgsn-Address.....identifier of [1] GSN-Address
  DEFINED in MAP-MS-DataTypes : 947

sgsn-Capability.....identifier of [0] SGSN-Capability
  DEFINED in MAP-MS-DataTypes : 243

SGSN-Capability.....type reference SEQUENCE
  DEFINED in MAP-MS-DataTypes : 245
  USED in MAP-MS-DataTypes : 243

sgsn-Number.....identifier of [1] ISDN-AddressString
  DEFINED in MAP-MS-DataTypes : 205

sgsn-Number.....identifier of ISDN-AddressString
  DEFINED in MAP-MS-DataTypes : 239

sgsn-Number.....identifier of [1] ISDN-AddressString
  DEFINED in MAP-SM-DataTypes : 99

shortMessageMO-PP.....value reference TeleserviceCode, '00100010'B
  DEFINED in MAP-TS-Code : 46

shortMessageMT-PP.....value reference TeleserviceCode, '00100001'B
  DEFINED in MAP-TS-Code : 45

shortTermDenial.....value reference ShortTermDenial, CHOICE VALUE
  DEFINED in MAP-Protocol : 375

ShortTermDenial.....type reference ERROR
  DEFINED in MAP-Errors : 335
  USED in MAP-Protocol : 152 375
  USED in MAP-SupplementaryServ : 53 264
  USED in MAP-Errors : 67

shortTermDenialParam.....identifier of ShortTermDenialParam
  DEFINED in MAP-Errors : 337

ShortTermDenialParam.....type reference SEQUENCE
  DEFINED in MAP-ER-DataTypes : 290
  USED in MAP-Errors : 129 337
  USED in MAP-ER-DataTypes : 47

signalInfo.....identifier of SignalInfo
  DEFINED in MAP-CommonDataTypes : 179

SignalInfo.....type reference OCTET STRING
  DEFINED in MAP-CommonDataTypes : 186
  USED in MAP-CommonDataTypes : 22 179 205
  USED in MAP-SM-DataTypes : 33 109 115 122 128
  USED in MAP-ER-DataTypes : 63 141

signalInfo.....identifier of SignalInfo
  DEFINED in MAP-CommonDataTypes : 205

sIWFSNumber.....identifier of [0] ISDN-AddressString
  DEFINED in MAP-CH-DataTypes : 310

sIWFSSignallingModify.....value reference SIWFSSignallingModify, CHOICE VALUE
  DEFINED in MAP-Protocol : 221

SIWFSSignallingModify.....type reference OPERATION
  DEFINED in MAP-CallHandlingOperat : 133
  USED in MAP-Protocol : 53 221

```

USED in MAP-CallHandlingOperat : 17
SIWFSSignallingModifyArg.....identifier of SIWFSSignallingModifyArg
DEFINED in MAP-CallHandlingOperat : 135
SIWFSSignallingModifyArg.....type reference SEQUENCE
DEFINED in MAP-CH-DataTypes : 314

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 69

USED in MAP-CallHandlingOperat :	60	135	2000-07-19 08:07:06
USED in MAP-CH-DataTypes :	25		
SIWFSSignallingModifyRes.....	identifier of SIWFSSignallingModifyRes		
DEFINED in MAP-CallHandlingOperat :	137		
SIWFSSignallingModifyRes.....	type reference SEQUENCE		
DEFINED in MAP-CH-DataTypes :	320		
USED in MAP-CallHandlingOperat :	61	137	
USED in MAP-CH-DataTypes :	26		
sm-DeliveryFailure.....	value reference SM-DeliveryFailure, CHOICE VALUE		
DEFINED in MAP-Protocol :	382		
SM-DeliveryFailure.....	type reference ERROR		
DEFINED in MAP-Errors :	353		
USED in MAP-Protocol :	147	382	
USED in MAP-ShortMessageServic :	39	92	109
USED in MAP-Errors :	72		
sm-DeliveryFailureCause.....	identifier of SM-DeliveryFailureCause		
DEFINED in MAP-Errors :	355		
SM-DeliveryFailureCause.....	type reference SEQUENCE		
DEFINED in MAP-ER-DataTypes :	139		
USED in MAP-Errors :	99	355	
USED in MAP-ER-DataTypes :	19		
sm-DeliveryOutcome.....	identifier of SM-DeliveryOutcome		
DEFINED in MAP-SM-DataTypes :	146		
SM-DeliveryOutcome.....	type reference ENUMERATED		
DEFINED in MAP-SM-DataTypes :	166		
USED in MAP-SM-DataTypes :	26	146	157
SM-EnumeratedDeliveryFailureCause.....	type reference ENUMERATED		
DEFINED in MAP-ER-DataTypes :	130		
USED in MAP-ER-DataTypes :	140		
sm-EnumeratedDeliveryFailureCause.....	identifier of SM-EnumeratedDeliveryFailureCause		
DEFINED in MAP-ER-DataTypes :	140		
sm-RP-DA.....	identifier of SM-RP-DA		
DEFINED in MAP-SM-DataTypes :	107		
sm-RP-DA.....	identifier of SM-RP-DA		
DEFINED in MAP-SM-DataTypes :	120		
SM-RP-DA.....	type reference CHOICE		
DEFINED in MAP-SM-DataTypes :	132		
USED in MAP-SM-DataTypes :	107	120	
sm-RP-MTI.....	identifier of [8] SM-RP-MTI		
DEFINED in MAP-SM-DataTypes :	61		
SM-RP-MTI.....	type reference INTEGER		
DEFINED in MAP-SM-DataTypes :	64		
USED in MAP-SM-DataTypes :	61		
sm-RP-OA.....	identifier of SM-RP-OA		
DEFINED in MAP-SM-DataTypes :	108		
sm-RP-OA.....	identifier of SM-RP-OA		
DEFINED in MAP-SM-DataTypes :	121		
SM-RP-OA.....	type reference CHOICE		
DEFINED in MAP-SM-DataTypes :	138		
USED in MAP-SM-DataTypes :	108	121	
sm-RP-PRI.....	identifier of [1] BOOLEAN		
DEFINED in MAP-SM-DataTypes :	54		
sm-RP-SMEA.....	identifier of [9] SM-RP-SMEA		
DEFINED in MAP-SM-DataTypes :	62		

```
SM-RP-SMEA.....type reference OCTET STRING
  DEFINED in MAP-SM-DataTypes   :
    USED in MAP-SM-DataTypes   :      71
                                :      62

sm-RP-UI.....identifier of SignalInfo
  DEFINED in MAP-SM-DataTypes   :
                                :      109
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 70

sm-RP-UI.....	identifier of SignalInfo
DEFINED in MAP-SM-DataTypes	: 115
sm-RP-UI.....	identifier of SignalInfo
DEFINED in MAP-SM-DataTypes	: 122
sm-RP-UI.....	identifier of SignalInfo
DEFINED in MAP-SM-DataTypes	: 128
solsaSupportIndicator.....	identifier of [2] NULL
DEFINED in MAP-MS-DataTypes	: 175
solsaSupportIndicator.....	identifier of NULL
DEFINED in MAP-MS-DataTypes	: 246
sres.....	identifier of SRES
DEFINED in MAP-MS-DataTypes	: 225
SRES.....	type reference OCTET STRING
DEFINED in MAP-MS-DataTypes	: 231
USED in MAP-MS-DataTypes	: 225
ss-AccessBarred.....	identifier of Named Number, 5
DEFINED in MAP-MS-DataTypes	: 461
ss-CamelData.....	identifier of SS-CamelData
DEFINED in MAP-MS-DataTypes	: 791
SS-CamelData.....	type reference SEQUENCE
DEFINED in MAP-MS-DataTypes	: 795
USED in MAP-MS-DataTypes	: 791
ss-Code.....	identifier of SS-Code
DEFINED in MAP-SupplementaryServi	: 219
ss-Code.....	identifier of SS-Code
DEFINED in MAP-MS-DataTypes	: 491
ss-Code.....	identifier of SS-Code
DEFINED in MAP-MS-DataTypes	: 570
ss-Code.....	identifier of SS-Code
DEFINED in MAP-MS-DataTypes	: 641
ss-Code.....	identifier of SS-Code
DEFINED in MAP-MS-DataTypes	: 654
ss-Code.....	identifier of SS-Code
DEFINED in MAP-MS-DataTypes	: 708
ss-Code.....	identifier of SS-Code
DEFINED in MAP-SS-DataTypes	: 70
ss-Code.....	identifier of SS-Code
DEFINED in MAP-SS-DataTypes	: 86
ss-Code.....	identifier of SS-Code
DEFINED in MAP-SS-DataTypes	: 143
ss-Code.....	identifier of SS-Code
DEFINED in MAP-SS-DataTypes	: 156
ss-Code.....	identifier of SS-Code
DEFINED in MAP-SS-DataTypes	: 178
ss-Code.....	identifier of [0] SS-Code
DEFINED in MAP-SS-DataTypes	: 281
ss-Code.....	identifier of [0] SS-Code
DEFINED in MAP-SS-DataTypes	: 304
ss-Code.....	identifier of [0] SS-Code
DEFINED in MAP-SS-DataTypes	: 309
SS-Code.....	type reference OCTET STRING

DEFINED in MAP-SS-Code	:	11									
USED in MAP-SupplementaryServi	:	78	219								
USED in MAP-MS-DataTypes	:	105	491	570	641	654	708	802			
USED in MAP-SS-DataTypes	:	62	70	86	143	156	178	246	261	281	
		304	309								
USED in MAP-SS-Code	:	21	25	28	30	32	34	36	40	42	
		48	50	52	54	56	58	60	63	66	

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 71 2000-07-19 08:07:06

	68	72	75	77	79	81	85	88	91
	94	97	100	102	105	108	110	112	115
	117	119	121	123	126	128	130	134	135
	136	137	138	139	140	141	142	143	144
	145	146	147	148	149	151	154	157	159
	161	164	166	170	172	174	177		
USED in MAP-ER-DataTypes	:	70	119						
ss-Code.....	identifier of [1] SS-Code								
DEFINED in MAP-ER-DataTypes	:	119							
ss-CSI.....	identifier of [2] SS-CSI								
DEFINED in MAP-MS-DataTypes	:	785							
SS-CSI.....	type reference SEQUENCE								
DEFINED in MAP-MS-DataTypes	:	790							
USED in MAP-MS-DataTypes	:	53	785						
ss-Data.....	identifier of [3] Ext-SS-Data								
DEFINED in MAP-MS-DataTypes	:	486							
ss-Data.....	identifier of [3] SS-Data								
DEFINED in MAP-SS-DataTypes	:	83							
SS-Data.....	type reference SEQUENCE								
DEFINED in MAP-SS-DataTypes	:	155							
USED in MAP-SS-DataTypes	:	33	83						
ss-ErrorStatus.....	value reference SS-ErrorStatus, CHOICE VALUE								
DEFINED in MAP-Protocol	:	365							
SS-ErrorStatus.....	type reference ERROR								
DEFINED in MAP-Errors	:	309							
USED in MAP-Protocol	:	137	365						
USED in MAP-SupplementaryServi	:	41	101	118	135	155	262	279	
USED in MAP-Errors	:	58							
ss-Event.....	identifier of [2] SS-Code								
DEFINED in MAP-SS-DataTypes	:	261							
ss-EventList.....	identifier of SS-EventList								
DEFINED in MAP-MS-DataTypes	:	796							
SS-EventList.....	type reference SEQUENCE OF								
DEFINED in MAP-MS-DataTypes	:	802							
USED in MAP-MS-DataTypes	:	796							
ss-EventSpecification.....	identifier of [3] SS-EventSpecification								
DEFINED in MAP-SS-DataTypes	:	266							
SS-EventSpecification.....	type reference SEQUENCE OF								
DEFINED in MAP-SS-DataTypes	:	275							
USED in MAP-SS-DataTypes	:	266							
ss-ForBS.....	identifier of SS-ForBS-Code								
DEFINED in MAP-SupplementaryServi	:	106							
ss-ForBS.....	identifier of SS-ForBS-Code								
DEFINED in MAP-SupplementaryServi	:	123							
ss-ForBS.....	identifier of SS-ForBS-Code								
DEFINED in MAP-SupplementaryServi	:	143							
ss-ForBS.....	identifier of SS-ForBS-Code								
DEFINED in MAP-SupplementaryServi	:	162							
SS-ForBS-Code.....	type reference SEQUENCE								
DEFINED in MAP-SS-DataTypes	:	177							
USED in MAP-SupplementaryServi	:	62	106	123	143	162			
USED in MAP-SS-DataTypes	:	18							
ss-Incompatibility.....	value reference SS-Incompatibility, CHOICE VALUE								
DEFINED in MAP-Protocol	:	368							
SS-Incompatibility.....	type reference ERROR								

DEFINED in MAP-Errors	:	318			
USED in MAP-Protocol	:	140	368		
USED in MAP-SupplementaryServi	:	44	102	137	263
USED in MAP-Errors	:	61			

ss-IncompatibilityCause.....identifier of SS-IncompatibilityCause
DEFINED in MAP-Errors : 320

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 72 2000-07-19 08:07:06

SS-IncompatibilityCause.....	type reference SEQUENCE
DEFINED in MAP-ER-DataTypes	: 118
USED in MAP-Errors	: 97 320
USED in MAP-ER-DataTypes	: 17
ss-Info.....	identifier of SS-Info
DEFINED in MAP-SupplementaryServi	: 91
ss-Info.....	identifier of SS-Info
DEFINED in MAP-SupplementaryServi	: 108
ss-Info.....	identifier of SS-Info
DEFINED in MAP-SupplementaryServi	: 125
ss-Info.....	identifier of SS-Info
DEFINED in MAP-SupplementaryServi	: 145
SS-Info.....	type reference CHOICE
DEFINED in MAP-SS-DataTypes	: 80
USED in MAP-SupplementaryServi	: 61 91 108 125 145
USED in MAP-SS-DataTypes	: 15 251
SS-InfoList.....	type reference SEQUENCE OF
DEFINED in MAP-SS-DataTypes	: 250
USED in MAP-SS-DataTypes	: 27
ss-InvocationNotification.....	value reference SS-InvocationNotification, CHOICE
VALUE	
DEFINED in MAP-Protocol	: 264
SS-InvocationNotification.....	type reference OPERATION
DEFINED in MAP-SupplementaryServi	: 240
USED in MAP-Protocol	: 72 264
USED in MAP-SupplementaryServi	: 23
ss-InvocationNotificationArg.....	identifier of SS-InvocationNotificationArg
DEFINED in MAP-SupplementaryServi	: 242
SS-InvocationNotificationArg.....	type reference SEQUENCE
DEFINED in MAP-SS-DataTypes	: 258
USED in MAP-SupplementaryServi	: 68 242
USED in MAP-SS-DataTypes	: 34
ss-InvocationNotificationRes.....	identifier of SS-InvocationNotificationRes
DEFINED in MAP-SupplementaryServi	: 244
SS-InvocationNotificationRes.....	type reference SEQUENCE
DEFINED in MAP-SS-DataTypes	: 270
USED in MAP-SupplementaryServi	: 69 244
USED in MAP-SS-DataTypes	: 35
ss-List.....	identifier of [3] SS-List
DEFINED in MAP-MS-DataTypes	: 724
ss-List.....	identifier of [2] SS-List
DEFINED in MAP-MS-DataTypes	: 743
ss-List.....	identifier of [1] SS-List
DEFINED in MAP-CH-DataTypes	: 139
SS-List.....	type reference SEQUENCE OF
DEFINED in MAP-SS-DataTypes	: 245
USED in MAP-MS-DataTypes	: 100 724 743
USED in MAP-CH-DataTypes	: 52 139
USED in MAP-SS-DataTypes	: 26
ss-NotAvailable.....	value reference SS-NotAvailable, CHOICE VALUE
DEFINED in MAP-Protocol	: 366
SS-NotAvailable.....	type reference ERROR
DEFINED in MAP-Errors	: 314
USED in MAP-Protocol	: 138 366
USED in MAP-SupplementaryServi	: 42 173
USED in MAP-Errors	: 59

ss-Status.....identifier of SS-Status
DEFINED in MAP-Errors : 311

ss-Status.....identifier of [4] Ext-SS-Status
DEFINED in MAP-MS-DataTypes : 501

ss-Status.....identifier of [4] Ext-SS-Status

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 73

DEFINED in MAP-MS-DataTypes	:	580
ss-Status.....	identifier of [4] Ext-SS-Status	
DEFINED in MAP-MS-DataTypes	:	642
ss-Status.....	identifier of Ext-SS-Status	
DEFINED in MAP-MS-DataTypes	:	655
ss-Status.....	identifier of Ext-SS-Status	
DEFINED in MAP-MS-DataTypes	:	709
ss-Status.....	identifier of [4] SS-Status	
DEFINED in MAP-SS-DataTypes	:	96
SS-Status.....	type reference OCTET STRING	
DEFINED in MAP-SS-DataTypes	:	103
USED in MAP-Errors	:	92 311
USED in MAP-SS-DataTypes	:	16 96 152 157 183 205 310
USED in MAP-ER-DataTypes	:	58 121
ss-Status.....	identifier of [4] SS-Status	
DEFINED in MAP-SS-DataTypes	:	152
ss-Status.....	identifier of [4] SS-Status	
DEFINED in MAP-SS-DataTypes	:	157
ss-Status.....	identifier of SS-Status	
DEFINED in MAP-SS-DataTypes	:	183
ss-Status.....	identifier of [0] SS-Status	
DEFINED in MAP-SS-DataTypes	:	205
ss-Status.....	identifier of [1] SS-Status	
DEFINED in MAP-SS-DataTypes	:	310
ss-Status.....	identifier of [4] SS-Status	
DEFINED in MAP-ER-DataTypes	:	121
ss-SubscriptionOption.....	identifier of SS-SubscriptionOption	
DEFINED in MAP-MS-DataTypes	:	643
ss-SubscriptionOption.....	identifier of SS-SubscriptionOption	
DEFINED in MAP-SS-DataTypes	:	158
SS-SubscriptionOption.....	type reference CHOICE	
DEFINED in MAP-SS-DataTypes	:	164
USED in MAP-MS-DataTypes	:	99 643
USED in MAP-SS-DataTypes	:	17 158
ss-SubscriptionViolation.....	value reference SS-SubscriptionViolation, CHOICE	
DEFINED in MAP-Protocol	:	367
SS-SubscriptionViolation.....	type reference ERROR	
DEFINED in MAP-Errors	:	316
USED in MAP-Protocol	:	139 367
USED in MAP-SupplementaryServi	:	43 136 156 227
USED in MAP-Errors	:	60
startMonitoring.....	identifier of Named Number, 1	
DEFINED in MAP-CH-DataTypes	:	334
statusReport.....	value reference StatusReport, CHOICE VALUE	
DEFINED in MAP-Protocol	:	223
StatusReport.....	type reference OPERATION	
DEFINED in MAP-CallHandlingOperat	:	159
USED in MAP-Protocol	:	55 223
USED in MAP-CallHandlingOperat	:	19
statusReportArg.....	identifier of StatusReportArg	
DEFINED in MAP-CallHandlingOperat	:	161
StatusReportArg.....	type reference SEQUENCE	
DEFINED in MAP-CH-DataTypes	:	355

USED in MAP-CallHandlingOperat : 64 161
USED in MAP-CH-DataTypes : 29

statusReportRes.....identifier of StatusReportRes
DEFINED in MAP-CallHandlingOperat : 163

StatusReportRes.....type reference SEQUENCE
DEFINED in MAP-CH-DataTypes : 391

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 74

USED in MAP-CallHandlingOperat :	65	163
USED in MAP-CH-DataTypes :	30	
stopMonitoring.....	identifier of Named Number, 0	
DEFINED in MAP-CH-DataTypes :	333	
storedMSISDN.....	identifier of ISDN-AddressString	
DEFINED in MAP-SM-DataTypes :	172	
storedMSISDN.....	identifier of ISDN-AddressString	
DEFINED in MAP-SM-DataTypes :	183	
subBusyForMT-SMS-Param.....	identifier of SubBusyForMT-SMS-Param	
DEFINED in MAP-Errors :	350	
SubBusyForMT-SMS-Param.....	type reference SEQUENCE	
DEFINED in MAP-ER-DataTypes :	267	
USED in MAP-Errors :	123	350
USED in MAP-ER-DataTypes :	40	
subscriberBusyForMT-SMS.....	value reference SubscriberBusyForMT-SMS, CHOICE VALUE	
DEFINED in MAP-Protocol :	381	
SubscriberBusyForMT-SMS.....	type reference ERROR	
DEFINED in MAP-Errors :	348	
USED in MAP-Protocol :	146	381
USED in MAP-ShortMessageServic :	38	108
USED in MAP-Errors :	71	
SubscriberData.....	type reference SEQUENCE	
DEFINED in MAP-MS-DataTypes :	410	
USED in MAP-MS-DataTypes :	46	296
SubscriberId.....	type reference CHOICE	
DEFINED in MAP-CommonDataTypes :	269	
USED in MAP-CommonDataTypes :	30	
subscriberIdentity.....	identifier of [0] SubscriberIdentity	
DEFINED in MAP-MS-DataTypes :	1067	
SubscriberIdentity.....	type reference CHOICE	
DEFINED in MAP-CommonDataTypes :	326	
USED in MAP-MS-DataTypes :	134	1067
USED in MAP-CommonDataTypes :	39	
USED in MAP-LCS-DataTypes :	31	54
59		
subscriberInfo.....	identifier of SubscriberInfo	
DEFINED in MAP-MS-DataTypes :	1014	
SubscriberInfo.....	type reference SEQUENCE	
DEFINED in MAP-MS-DataTypes :	1018	
USED in MAP-MS-DataTypes :	74	1014
USED in MAP-CH-DataTypes :	37	1074
USED in MAP-CH-DataTypes :	138	
subscriberInfo.....	identifier of SubscriberInfo	
DEFINED in MAP-MS-DataTypes :	1074	
subscriberInfo.....	identifier of [7] SubscriberInfo	
DEFINED in MAP-CH-DataTypes :	138	
subscriberLocationReport.....	value reference SubscriberLocationReport, CHOICE	
DEFINED in MAP-Protocol :	295	
SubscriberLocationReport.....	type reference OPERATION	
DEFINED in MAP-LocationServiceOpe :	84	
USED in MAP-Protocol :	103	295
USED in MAP-LocationServiceOpe :	15	
subscriberLocationReport-Arg.....	identifier of SubscriberLocationReport-Arg	
DEFINED in MAP-LocationServiceOpe :	86	
SubscriberLocationReport-Arg.....	type reference SEQUENCE	
DEFINED in MAP-LCS-DataTypes :	216	
USED in MAP-LocationServiceOpe :	45	86

USED in MAP-LCS-DataTypes : 15
subscriberLocationReport-Res.....identifier of SubscriberLocationReport-Res
DEFINED in MAP-LocationServiceOpe : 88
SubscriberLocationReport-Res.....type reference SEQUENCE
DEFINED in MAP-LCS-DataTypes : 241
USED in MAP-LocationServiceOpe : 46 88

TAG R4.81 Cross Reference Listing for MAP-Protocol 2000-07-19 08:07:06
 PAGE 75

USED in MAP-LCS-DataTypes	:	16
subscriberNotMemberOfCUG.....	identifier of Named Number,	1
DEFINED in MAP-ER-DataTypes	:	114
subscriberNotSC-Subscriber.....	identifier of Named Number,	6
DEFINED in MAP-ER-DataTypes	:	137
subscriberState.....	identifier of [1] SubscriberState	
DEFINED in MAP-MS-DataTypes	:	1020
subscriberState.....	identifier of [1] NULL	
DEFINED in MAP-MS-DataTypes	:	1026
SubscriberState.....	type reference CHOICE	
DEFINED in MAP-MS-DataTypes	:	1052
USED in MAP-MS-DataTypes	:	76 1020
subscriberStatus.....	identifier of [3] SubscriberStatus	
DEFINED in MAP-MS-DataTypes	:	413
SubscriberStatus.....	type reference ENUMERATED	
DEFINED in MAP-MS-DataTypes	:	432
USED in MAP-MS-DataTypes	:	48 413
subscriptionWithdraw.....	identifier of Named Number,	1
DEFINED in MAP-MS-DataTypes	:	193
subsequentHandoverFailure.....	value reference SubsequentHandoverFailure, CHOICE	
DEFINED in MAP-Protocol	:	332
SubsequentHandoverFailure.....	type reference ERROR	
DEFINED in MAP-Errors	:	237
USED in MAP-Protocol	:	124 332
USED in MAP-MobileServiceOpera	:	79 249
USED in MAP-Errors	:	37
success.....	identifier of Named Number,	0
DEFINED in MAP-CH-DataTypes	:	382
successfulTransfer.....	identifier of Named Number,	2
DEFINED in MAP-SM-DataTypes	:	169
supportedCamelPhases.....	identifier of [0] SupportedCamelPhases	
DEFINED in MAP-MS-DataTypes	:	172
supportedCamelPhases.....	identifier of [6] SupportedCamelPhases	
DEFINED in MAP-MS-DataTypes	:	728
SupportedCamelPhases.....	type reference BIT STRING	
DEFINED in MAP-MS-DataTypes	:	908
USED in MAP-MS-DataTypes	:	58 172 728
USED in MAP-CH-DataTypes	:	40 196 237
supportedCamelPhases.....	identifier of SupportedCamelPhases	
DEFINED in MAP-CH-DataTypes	:	237
supportedCamelPhasesInGMSC.....	identifier of [15] SupportedCamelPhases	
DEFINED in MAP-CH-DataTypes	:	196
supportedCCBS-Phase.....	identifier of [16] SupportedCCBS-Phase	
DEFINED in MAP-CH-DataTypes	:	106
SupportedCCBS-Phase.....	type reference INTEGER	
DEFINED in MAP-CH-DataTypes	:	124
USED in MAP-CH-DataTypes	:	106
suppressionOfAnnouncement.....	identifier of [12] SuppressionOfAnnouncement	
DEFINED in MAP-CH-DataTypes	:	101
SuppressionOfAnnouncement.....	type reference NULL	
DEFINED in MAP-CH-DataTypes	:	109
USED in MAP-CH-DataTypes	:	21 101 188

```
suppressionOfAnnouncement.....identifier of [7] SuppressionOfAnnouncement
    DEFINED in MAP-CH-DataTypes      :     188

suppress-T-CSI.....identifier of NULL
    DEFINED in MAP-CH-DataTypes      :     238

systemFailure.....value reference SystemFailure, CHOICE VALUE
    DEFINED in MAP-Protocol        :     300
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 76 2000-07-19 08:07:06

```

SystemFailure.....type reference ERROR
  DEFINED in MAP-Errors : 145
  USED in MAP-Protocol : 109   300
  USED in MAP-MobileServiceOpera : 69   140   184   208   222   260   273   315   329
                                         343   357
  USED in MAP-OperationAndMainte : 23    57    71
  USED in MAP-CallHandlingOperat : 28    80   102   131   143   152   167   181
  USED in MAP-SupplementaryServi : 33    94   111   128   148   166   181   194   208
                                         223   257   274
  USED in MAP-ShortMessageServic : 27    73    89   101   129
  USED in MAP-Group-Call-Operati : 24    52
  USED in MAP-LocationServiceOpe : 23    58    72    90
  USED in MAP-Errors : 14

systemFailureParam.....identifier of SystemFailureParam
  DEFINED in MAP-Errors : 147

SystemFailureParam.....type reference CHOICE
  DEFINED in MAP-ER-DataTypes : 159
  USED in MAP-Errors : 100   147
  USED in MAP-ER-DataTypes : 20

targetCellId.....identifier of GlobalCellId
  DEFINED in MAP-MS-DataTypes : 261

targetCellId.....identifier of GlobalCellId
  DEFINED in MAP-MS-DataTypes : 272

targetMS.....identifier of [1] SubscriberIdentity
  DEFINED in MAP-LCS-DataTypes : 54

targetMS.....identifier of [0] SubscriberIdentity
  DEFINED in MAP-LCS-DataTypes : 59

targetMSC-Number.....identifier of ISDN-AddressString
  DEFINED in MAP-MS-DataTypes : 273

targetMSsubscribedService.....identifier of Named Number, 4
  DEFINED in MAP-CommonDataTypes : 341

TBCD-STRING.....type reference OCTET STRING
  DEFINED in MAP-CommonDataTypes : 78
  USED in MAP-CommonDataTypes : 250   263   273

TCAPMessages.....module reference
  DEFINED in TCAPMessages : 1
  USED in MAP-MobileServiceOpera : 66
  USED in MAP-OperationAndMainte : 20
  USED in MAP-CallHandlingOperat : 25
  USED in MAP-SupplementaryServi : 30
  USED in MAP-ShortMessageServic : 24
  USED in MAP-Group-Call-Operati : 21
  USED in MAP-LocationServiceOpe : 20
  USED in MAP-Errors : 89

telephony.....value reference TeleserviceCode, '00010001'B
  DEFINED in MAP-TS-Code : 41

teleservice.....identifier of [3] TeleserviceCode
  DEFINED in MAP-CommonDataTypes : 381

teleservice.....identifier of Ext-TeleserviceCode
  DEFINED in MAP-GR-DataTypes : 50

TeleserviceCode.....type reference OCTET STRING
  DEFINED in MAP-TS-Code : 11
  USED in MAP-CommonDataTypes : 57   381
  USED in MAP-TS-Code : 38    40    41    42    44    45    46    48    49
                                         50    51    55    58    67    69    70    72    73
                                         74    75    76    77    78    79    80    81    82
                                         83    84    85    86    87

teleserviceList.....identifier of [6] TeleserviceList
  DEFINED in MAP-MS-DataTypes : 417

```

```
TeleserviceList.....type reference SEQUENCE OF
  DEFINED in MAP-MS-DataTypes   :    441
  USED in MAP-MS-DataTypes     : 417    722

teleserviceList.....identifier of [1] TeleserviceList
  DEFINED in MAP-MS-DataTypes   :    722
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 77 2000-07-19 08:07:06

VALUE	teleserviceNotProvisioned.....value reference TeleserviceNotProvisioned, CHOICE DEFINED in MAP-Protocol : 324
	TeleserviceNotProvisioned.....type reference ERROR DEFINED in MAP-Errors : 226 USED in MAP-Protocol : 122 324 USED in MAP-CallHandlingOperat : 36 88 USED in MAP-SupplementaryServi : 38 98 115 132 152 170 USED in MAP-ShortMessageServic : 35 78 USED in MAP-Errors : 33
	teleservNotProvParam.....identifier of TeleservNotProvParam DEFINED in MAP-Errors : 228
	TeleservNotProvParam.....type reference SEQUENCE DEFINED in MAP-ER-DataTypes : 220 USED in MAP-Errors : 111 228 USED in MAP-ER-DataTypes : 31
	temporaryDefaultAllowed.....identifier of Named Number, 2 DEFINED in MAP-SS-DataTypes : 171
	temporaryDefaultRestricted.....identifier of Named Number, 1 DEFINED in MAP-SS-DataTypes : 170
	termAttemptAuthorized.....identifier of Named Number, 12 DEFINED in MAP-CH-DataTypes : 283
	tif-CSI.....identifier of [3] NULL DEFINED in MAP-MS-DataTypes : 787
	tmsi.....identifier of TMSI DEFINED in MAP-MobileServiceOpera : 169
	TMSI.....type reference OCTET STRING DEFINED in MAP-CommonDataTypes : 267 USED in MAP-MobileServiceOpera : 124 169 USED in MAP-CommonDataTypes : 28 271
	tmsi.....identifier of [1] TMSI DEFINED in MAP-CommonDataTypes : 271
	tooManyZoneCodes.....identifier of Named Number, 1 DEFINED in MAP-MS-DataTypes : 734
	traceReference.....identifier of [1] TraceReference DEFINED in MAP-OM-DataTypes : 38
	TraceReference.....type reference OCTET STRING DEFINED in MAP-OM-DataTypes : 44 USED in MAP-OM-DataTypes : 38 56
	traceReference.....identifier of [1] TraceReference DEFINED in MAP-OM-DataTypes : 56
	traceType.....identifier of [2] TraceType DEFINED in MAP-OM-DataTypes : 39
	TraceType.....type reference INTEGER DEFINED in MAP-OM-DataTypes : 46 USED in MAP-OM-DataTypes : 39
	tracingBufferFull.....value reference TracingBufferFull, CHOICE VALUE DEFINED in MAP-Protocol : 338
	TracingBufferFull.....type reference ERROR DEFINED in MAP-Errors : 242 USED in MAP-Protocol : 125 338 USED in MAP-OperationAndMainte : 29 62 USED in MAP-Errors : 40
	tracingBufferFullParam.....identifier of TracingBufferFullParam DEFINED in MAP-Errors : 244

TracingBufferFullParam.....type reference SEQUENCE
 DEFINED in MAP-ER-DataTypes : 224
 USED in MAP-Errors : 112 244
 USED in MAP-ER-DataTypes : 32

TransactionID.....type reference OCTET STRING
 DEFINED in TCAPMessages : 100

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 78

USED in TCAPMessages	:	47	97	98
transferToThirdParty.....	value reference SS-Code, '11000011'B			
DEFINED in MAP-SS-Code	:	177		
translatedB-Number.....	identifier of [3] ISDN-AddressString			
DEFINED in MAP-CH-DataTypes	:	399		
translatedB-Number.....	identifier of [1] ISDN-AddressString			
DEFINED in MAP-SS-DataTypes	:	287		
T-BcsmCamelTDPData.....	type reference SEQUENCE			
DEFINED in MAP-CH-DataTypes	:	274		
USED in MAP-CH-DataTypes	:	268		
t-BcsmCamelTDPDataList.....	identifier of T-BcsmCamelTDPDataList			
DEFINED in MAP-CH-DataTypes	:	261		
T-BcsmCamelTDPDataList.....	type reference SEQUENCE OF			
DEFINED in MAP-CH-DataTypes	:	267		
USED in MAP-CH-DataTypes	:	261		
t-BcsmTriggerDetectionPoint.....	identifier of T-BcsmTriggerDetectionPoint			
DEFINED in MAP-CH-DataTypes	:	275		
T-BcsmTriggerDetectionPoint.....	type reference ENUMERATED			
DEFINED in MAP-CH-DataTypes	:	282		
USED in MAP-CH-DataTypes	:	275		
t-CSI.....	identifier of [0] T-CSI			
DEFINED in MAP-CH-DataTypes	:	253		
T-CSI.....	type reference SEQUENCE			
DEFINED in MAP-CH-DataTypes	:	260		
USED in MAP-CH-DataTypes	:	253		
udubFromBusyMS.....	identifier of Named Number, 5			
DEFINED in MAP-CH-DataTypes	:	416		
udubFromFreeMS.....	identifier of Named Number, 4			
DEFINED in MAP-CH-DataTypes	:	415		
unauthorisedMessageOriginator.....	identifier of [1] NULL			
DEFINED in MAP-ER-DataTypes	:	105		
unauthorizedLCSClient.....	value reference UnauthorizedLCSClient, CHOICE VALUE			
DEFINED in MAP-Protocol	:	389		
UnauthorizedLCSClient.....	type reference ERROR			
DEFINED in MAP-Errors	:	381		
USED in MAP-Protocol	:	156	389	
USED in MAP-LocationServiceOpe	:	30	81	
USED in MAP-Errors	:	81		
unauthorizedLCSClient-Diagnostic.....	identifier of [0] UnauthorizedLCSClient-Diagnostic			
DEFINED in MAP-ER-DataTypes	:	301		
UnauthorizedLCSClient-Diagnostic.....	type reference ENUMERATED			
DEFINED in MAP-ER-DataTypes	:	305		
USED in MAP-ER-DataTypes	:	301		
unauthorizedLCSClient-Param.....	identifier of UnauthorizedLCSClient-Param			
DEFINED in MAP-Errors	:	383		
UnauthorizedLCSClient-Param.....	type reference SEQUENCE			
DEFINED in MAP-ER-DataTypes	:	300		
USED in MAP-Errors	:	132	383	
USED in MAP-ER-DataTypes	:	50		
unauthorizedRequestingNetwork.....	value reference UnauthorizedRequestingNetwork, CHOICE VALUE			
DEFINED in MAP-Protocol	:	388		
UnauthorizedRequestingNetwork.....	type reference ERROR			
DEFINED in MAP-Errors	:	376		

USED in MAP-Protocol	:	155	388		
USED in MAP-LocationServiceOpe	:	29	64	80	95
USED in MAP-Errors	:	80			

unauthorizedRequestingNetwork-Param.....identifier of UnauthorizedRequestingNetwork-Param
DEFINED in MAP-Errors : 378

UnauthorizedRequestingNetwork-Param.....type reference SEQUENCE

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 79 2000-07-19 08:07:06

DEFINED in MAP-ER-DataTypes	:	296									
USED in MAP-Errors	:	131	378								
USED in MAP-ER-DataTypes	:	49									
undetermined.....	identifier of Named Number, 0									
DEFINED in MAP-ER-DataTypes	:	125									
unexpectedDataParam.....	identifier of UnexpectedDataParam									
DEFINED in MAP-Errors	:	158									
UnexpectedDataParam.....	type reference SEQUENCE									
DEFINED in MAP-ER-DataTypes	:	175									
USED in MAP-Errors	:	102	158								
USED in MAP-ER-DataTypes	:	22									
unexpectedDataValue.....	value reference UnexpectedDataValue, CHOICE VALUE									
DEFINED in MAP-Protocol	:	302									
UnexpectedDataValue.....	type reference ERROR									
DEFINED in MAP-Errors	:	156									
USED in MAP-Protocol	:	111	302								
USED in MAP-MobileServiceOpera	:	71	142	154	164	185	198	211	224	246	
		262	287	298	317	331	345	359			
USED in MAP-OperationAndMainte	:	25	59	73	84						
USED in MAP-CallHandlingOperat	:	30	82	104	119	130	142	154	168	177	
USED in MAP-SupplementaryServ	:	35	96	113	130	150	168	183	196	210	
		225	248	259	276						
USED in MAP-ShortMessageServic	:	29	75	90	103	120	131	145			
USED in MAP-Group-Call-Operati	:	25	54								
USED in MAP-LocationServiceOpe	:	25	60	74	92						
USED in MAP-Errors	:	16									
unexpectedError.....	identifier of Named Number, 3									
DEFINED in TCAPMessages	:	199									
unexpectedLinkedOperation.....	identifier of Named Number, 7									
DEFINED in TCAPMessages	:	190									
unidentifiedSubParam.....	identifier of UnidentifiedSubParam									
DEFINED in MAP-Errors	:	195									
UnidentifiedSubParam.....	type reference SEQUENCE									
DEFINED in MAP-ER-DataTypes	:	204									
USED in MAP-Errors	:	106	195								
USED in MAP-ER-DataTypes	:	27									
unidentifiedSubscriber.....	value reference UnidentifiedSubscriber, CHOICE VALUE									
DEFINED in MAP-Protocol	:	313									
UnidentifiedSubscriber.....	type reference ERROR									
DEFINED in MAP-Errors	:	193									
USED in MAP-Protocol	:	116	313								
USED in MAP-MobileServiceOpera	:	74	174	288	299						
USED in MAP-OperationAndMainte	:	28	61	75							
USED in MAP-CallHandlingOperat	:	47	153								
USED in MAP-ShortMessageServic	:	32	105								
USED in MAP-LocationServiceOpe	:	34	76								
USED in MAP-Errors	:	25									
unidirectional.....	identifier of [APPLICATION 1] IMPLICIT Unidirectional									
DEFINED in TCAPMessages	:	52									
Unidirectional.....	type reference SEQUENCE									
DEFINED in TCAPMessages	:	58									
USED in TCAPMessages	:	52									
universal.....	value reference SS-Code, '10110001'B									
DEFINED in MAP-SS-Code	:	159									
unknownAlphabet.....	value reference UnknownAlphabet, CHOICE VALUE									
DEFINED in MAP-Protocol	:	369									
UnknownAlphabet.....	type reference ERROR									
DEFINED in MAP-Errors	:	323									
USED in MAP-Protocol	:	141	369								

USED in MAP-SupplementaryServi : 48 184 200 214
USED in MAP-Errors : 62

unknownEquipment.....value reference UnknownEquipment, CHOICE VALUE
DEFINED in MAP-Protocol : 314

UnknownEquipment.....type reference ERROR

PAGE TAG R4.81 Cross Reference Listing for MAP-Protocol 2000-07-19 08:07:06
80

DEFINED in MAP-Errors	:	199	
USED in MAP-Protocol	:	117	314
USED in MAP-MobileServiceOpera	:	75	275
USED in MAP-Errors	:	26	

unknownMSC..... value reference UnknownMSC, CHOICE VALUE
DEFINED in MAP-Protocol : 312

```

UnknownMSC..... type reference ERROR
  DEFINED in MAP-Errors : 191
  USED in MAP-Protocol : 115 312
  USED in MAP-MobileServiceOpera : 73 248
  USED in MAP-Errors : 24

```

unknownOrUnreachableLCSClient.....value reference UnknownOrUnreachableLCSClient, CHOICE
VALUE DEFINED in MAP-Protocol : 391

```

UnknownOrUnreachableLCSClient.....type reference ERROR
    DEFINED in MAP-Errors          :      391
    USED in MAP-Protocol          :      158      391
    USED in MAP-LocationServiceOpe :       33      96
    USED in MAP-Errors            :       83

```

unknownOrUnreachableLCSClient-Param.....identifier of UnknownOrUnreachableLCSClient-Param
DEFINED in MAP-Errors : 393

```

UnknownOrUnreachableLCSClient-Param.....type reference SEQUENCE
    DEFINED in MAP-ER-DataTypes      :      334
        USED in MAP-Errors          :      134      393
        USED in MAP-ER-DataTypes    :       52

```

unknownServiceCentre..... identifier of Named Number, 3
 DEFINED in MAP-ER-DataTypes : 134

unknownSubscriber..... value reference UnknownSubscriber, CHOICE VALUE
DEFINED in MAP-Protocol : 310

```

UnknownSubscriber.....type reference ERROR
  DEFINED in MAP-Errors          :    180
  USED   in MAP-Protocol         :    113    310
  USED   in MAP-MobileServiceOpera :     72    143    165
                                         360
  USED   in MAP-OperationAndMainte :     27      85
  USED   in MAP-CallHandlingOperat :     33      85    166
  USED   in MAP-SupplementaryServi :     36    249
  USED   in MAP-ShortMessageServic :     31      77    121
  USED   in MAP-LocationServiceOpe :     27      62     94
  USED   in MAP-Errors           :     22

```

unknownSubscriberDiagnostic..... identifier of UnknownSubscriberDiagnostic
DEFINED in MAP-ER-DataTypes : 190

UnknownSubscriberDiagnostic..... type reference ENUMERATED
 DEFINED in MAP-ER-DataTypes : 192
 USED in MAP-ER-DataTypes : 190

unknownSubscriberParam..... identifier of UnknownSubscriberParam
DEFINED in MAP-Errors : 182

UnknownSubscriberParam..... type reference SEQUENCE
 DEFINED in MAP-ER-DataTypes : 187
 USED in MAP-Errors : 104 182
 USED in MAP-ER-DataTypes : 25

unrecognizedComponent..... identifier of Named Number, 0
 DEFINED in TCAPMessages : 179

unrecognizedError..... identifier of Named Number, 2
DEFINED in TCAPMessages : 198

unrecognizedInvokeID..... identifier of Named Number, 0
 DEFINED in TCAPMessages : 192

unrecognizedInvokeID..... identifier of Named Number, 0

DEFINED in TCAPMessages : 196
unrecognizedLinkedID.....identifier of Named Number, 5
DEFINED in TCAPMessages : 188
unrecognizedMessageType.....identifier of Named Number, 0
DEFINED in TCAPMessages : 103

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 81

unrecognizedOperation.....	identifier of Named Number, 1	2000-07-19 08:07:06
DEFINED in TCAPMessages	: 184	
unrecognizedTransactionID.....	identifier of Named Number, 1	
DEFINED in TCAPMessages	: 104	
unstructuredSS-Notify.....	value reference UnstructuredSS-Notify, CHOICE VALUE	
DEFINED in MAP-Protocol	: 237	
UnstructuredSS-Notify.....	type reference OPERATION	
DEFINED in MAP-SupplementaryServi	: 203	
USED in MAP-Protocol	: 69 237	
USED in MAP-SupplementaryServi	: 20	
unstructuredSS-Request.....	value reference UnstructuredSS-Request, CHOICE VALUE	
DEFINED in MAP-Protocol	: 236	
UnstructuredSS-Request.....	type reference OPERATION	
DEFINED in MAP-SupplementaryServi	: 187	
USED in MAP-Protocol	: 68 236	
USED in MAP-SupplementaryServi	: 19	
updateGprsLocation.....	value reference UpdateGprsLocation, CHOICE VALUE	
DEFINED in MAP-Protocol	: 277	
UpdateGprsLocation.....	type reference OPERATION	
DEFINED in MAP-MobileServiceOpera	: 178	
USED in MAP-Protocol	: 16 277	
USED in MAP-MobileServiceOpera	: 21	
updateGprsLocationArg.....	identifier of UpdateGprsLocationArg	
DEFINED in MAP-MobileServiceOpera	: 180	
UpdateGprsLocationArg.....	type reference SEQUENCE	
DEFINED in MAP-MS-DataTypes	: 237	
USED in MAP-MobileServiceOpera	: 93 180	
USED in MAP-MS-DataTypes	: 23	
updateGprsLocationRes.....	identifier of UpdateGprsLocationRes	
DEFINED in MAP-MobileServiceOpera	: 182	
UpdateGprsLocationRes.....	type reference SEQUENCE	
DEFINED in MAP-MS-DataTypes	: 253	
USED in MAP-MobileServiceOpera	: 94 182	
USED in MAP-MS-DataTypes	: 24	
updateLocation.....	value reference UpdateLocation, CHOICE VALUE	
DEFINED in MAP-Protocol	: 168	
UpdateLocation.....	type reference OPERATION	
DEFINED in MAP-MobileServiceOpera	: 134	
USED in MAP-Protocol	: 12 168	
USED in MAP-MobileServiceOpera	: 15	
updateLocationArg.....	identifier of UpdateLocationArg	
DEFINED in MAP-MobileServiceOpera	: 136	
UpdateLocationArg.....	type reference SEQUENCE	
DEFINED in MAP-MS-DataTypes	: 161	
USED in MAP-MobileServiceOpera	: 86 136	
USED in MAP-MS-DataTypes	: 16	
updateLocationRes.....	identifier of UpdateLocationRes	
DEFINED in MAP-MobileServiceOpera	: 138	
UpdateLocationRes.....	type reference SEQUENCE	
DEFINED in MAP-MS-DataTypes	: 178	
USED in MAP-MobileServiceOpera	: 87 138	
USED in MAP-MS-DataTypes	: 17	
updateProcedure.....	identifier of Named Number, 0	
DEFINED in MAP-MS-DataTypes	: 192	
uplinkFree.....	identifier of [3] NULL	
DEFINED in MAP-GR-DataTypes	: 57	

uplinkRejectCommand.....identifier of [2] NULL
DEFINED in MAP-GR-DataTypes : 79

uplinkReleaseCommand.....identifier of [4] NULL
DEFINED in MAP-GR-DataTypes : 81

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 82

uplinkReleaseIndication.....	identifier of [1] NULL DEFINED in MAP-GR-DataTypes	: 78	2000-07-19 08:07:06
uplinkReleaseIndication.....	identifier of [1] NULL DEFINED in MAP-GR-DataTypes	: 87	
uplinkRequest.....	identifier of [0] NULL DEFINED in MAP-GR-DataTypes	: 86	
uplinkRequestAck.....	identifier of [0] NULL DEFINED in MAP-GR-DataTypes	: 77	
uplinkSeizedCommand.....	identifier of [3] NULL DEFINED in MAP-GR-DataTypes	: 80	
ussd-Arg.....	identifier of USSD-Arg DEFINED in MAP-SupplementaryServi	: 177	
ussd-Arg.....	identifier of USSD-Arg DEFINED in MAP-SupplementaryServi	: 189	
ussd-Arg.....	identifier of USSD-Arg DEFINED in MAP-SupplementaryServi	: 205	
USSD-Arg.....	type reference SEQUENCE DEFINED in MAP-SS-DataTypes	: 210	
	USED in MAP-SupplementaryServi	: 64 177 189 205	
	USED in MAP-SS-DataTypes	: 20	
ussd-Busy.....	value reference USSD-Busy, CHOICE VALUE DEFINED in MAP-Protocol	: 370	
USSD-Busy.....	type reference ERROR DEFINED in MAP-Errors	: 325	
	USED in MAP-Protocol	: 142 370	
	USED in MAP-SupplementaryServi	: 49 201 215	
	USED in MAP-Errors	: 63	
ussd-DataCodingScheme.....	identifier of USSD-DataCodingScheme DEFINED in MAP-SS-DataTypes	: 211	
ussd-DataCodingScheme.....	identifier of USSD-DataCodingScheme DEFINED in MAP-SS-DataTypes	: 218	
USSD-DataCodingScheme.....	type reference OCTET STRING DEFINED in MAP-SS-DataTypes	: 222	
	USED in MAP-SS-DataTypes	: 22 211 218	
	USED in MAP-LCS-DataTypes	: 44 119	
ussd-Res.....	identifier of USSD-Res DEFINED in MAP-SupplementaryServi	: 179	
ussd-Res.....	identifier of USSD-Res DEFINED in MAP-SupplementaryServi	: 191	
USSD-Res.....	type reference SEQUENCE DEFINED in MAP-SS-DataTypes	: 217	
	USED in MAP-SupplementaryServi	: 65 179 191	
	USED in MAP-SS-DataTypes	: 21	
ussd-String.....	identifier of USSD-String DEFINED in MAP-SS-DataTypes	: 212	
ussd-String.....	identifier of USSD-String DEFINED in MAP-SS-DataTypes	: 219	
USSD-String.....	type reference OCTET STRING DEFINED in MAP-SS-DataTypes	: 227	
	USED in MAP-SS-DataTypes	: 23 212 219	
	USED in MAP-LCS-DataTypes	: 45 128	
uui.....	identifier of [1] UUI DEFINED in MAP-CH-DataTypes	: 221	
UUI.....	type reference OCTET STRING		

DEFINED in MAP-CH-DataTypes : 229
USED in MAP-CH-DataTypes : 221

uuIndicator.....identifier of [0] UUIndicator
DEFINED in MAP-CH-DataTypes : 220

UUIndicator.....type reference OCTET STRING

TAG R4.81 Cross Reference Listing for MAP-Protocol
 PAGE 83

DEFINED in MAP-CH-DataTypes	:	226
USED in MAP-CH-DataTypes	:	220
uus1.....	value reference SS-Code, '10000001'B
DEFINED in MAP-SS-Code	:	108
uus2.....	value reference SS-Code, '10000010'B
DEFINED in MAP-SS-Code	:	110
uus3.....	value reference SS-Code, '10000011'B
DEFINED in MAP-SS-Code	:	112
uusCFInteraction.....	identifier of [2] NULL
DEFINED in MAP-CH-DataTypes	:	222
uu-Data.....	identifier of [10] UU-Data
DEFINED in MAP-CH-DataTypes	:	215
UU-Data.....	type reference SEQUENCE
DEFINED in MAP-CH-DataTypes	:	219
USED in MAP-CH-DataTypes	:	215
valueAddedServices.....	identifier of Named Number, 1
DEFINED in MAP-LCS-DataTypes	:	109
VBSDataList.....	type reference SEQUENCE OF
DEFINED in MAP-MS-DataTypes	:	979
USED in MAP-MS-DataTypes	:	424
vbsGroupIndication.....	identifier of [7] NULL
DEFINED in MAP-MS-DataTypes	:	746
vbsSubscriptionData.....	identifier of [11] VBSDataList
DEFINED in MAP-MS-DataTypes	:	424
verticalCoordinateRequest.....	identifier of [1] NULL
DEFINED in MAP-LCS-DataTypes	:	139
vertical-accuracy.....	identifier of [2] Vertical-Accuracy
DEFINED in MAP-LCS-DataTypes	:	140
Vertical-Accuracy.....	type reference OCTET STRING
DEFINED in MAP-LCS-DataTypes	:	149
USED in MAP-LCS-DataTypes	:	140
VGCSDataList.....	type reference SEQUENCE OF
DEFINED in MAP-MS-DataTypes	:	982
USED in MAP-MS-DataTypes	:	425
vgcsGroupIndication.....	identifier of [8] NULL
DEFINED in MAP-MS-DataTypes	:	747
vgcsSubscriptionData.....	identifier of [12] VGCSDataList
DEFINED in MAP-MS-DataTypes	:	425
vlr.....	identifier of Named Number, 2
DEFINED in MAP-CommonDataTypes	:	307
vlrCamelSubscriptionInfo.....	identifier of [13] VlrCamelSubscriptionInfo
DEFINED in MAP-MS-DataTypes	:	426
VlrCamelSubscriptionInfo.....	type reference SEQUENCE
DEFINED in MAP-MS-DataTypes	:	781
USED in MAP-MS-DataTypes	:	426
vlr-Capability.....	identifier of [6] VLR-Capability
DEFINED in MAP-MS-DataTypes	:	169
VLR-Capability.....	type reference SEQUENCE
DEFINED in MAP-MS-DataTypes	:	171
USED in MAP-MS-DataTypes	:	169 969
vlr-Capability.....	identifier of [6] VLR-Capability
DEFINED in MAP-MS-DataTypes	:	969

```
vlr-Number.....identifier of ISDN-AddressString
  DEFINED in MAP-MS-DataTypes      :    165

vlr-Number.....identifier of [0] ISDN-AddressString
  DEFINED in MAP-MS-DataTypes      :    204

vlr-number.....identifier of [1] ISDN-AddressString
```

TAG R4.81 Cross Reference Listing for MAP-Protocol
PAGE 84

2000-07-19 08:07:06

DEFINED in MAP-MS-DataTypes : 1033

vmsc..... identifier of Named Number, 5
DEFINED in MAP-CommonDataTypes : 310

vmsc-Address..... identifier of [2] ISDN-AddressString
DEFINED in MAP-CH-DataTypes : 142

voiceBroadcastCall..... value reference TeleserviceCode, '10010010'B
DEFINED in MAP-TS-Code : 70

VoiceBroadcastData..... type reference SEQUENCE
DEFINED in MAP-MS-DataTypes : 994
USED in MAP-MS-DataTypes : 980

voiceGroupCall..... value reference TeleserviceCode, '10010001'B
DEFINED in MAP-TS-Code : 69

VoiceGroupCallData..... type reference SEQUENCE
DEFINED in MAP-MS-DataTypes : 989
USED in MAP-MS-DataTypes : 983

vplmnAddressAllowed..... identifier of [19] NULL
DEFINED in MAP-MS-DataTypes : 343

whiteListed..... identifier of Named Number, 0
DEFINED in MAP-MS-DataTypes : 287

ZoneCode..... type reference OCTET STRING
DEFINED in MAP-MS-DataTypes : 716
USED in MAP-MS-DataTypes : 714 745

ZoneCodeList..... type reference SEQUENCE OF
DEFINED in MAP-MS-DataTypes : 713
USED in MAP-MS-DataTypes : 49 423

zoneCodesConflict..... identifier of Named Number, 2
DEFINED in MAP-MS-DataTypes : 735

Annex B (informative): Fully expanded ASN.1 sources for abstract syntaxes of MAP

Annex B is not part of the standard, it is included for information purposes only.

For every (Value)Assignment in the root ASN.1 module all the used defined types and defined values, which are defined within the ASN.1 module or imported from ASN.1 modules, are replaced by the constructs this type or value is composed of.

The fully expanded ASN.1 root module is itself a correct and equivalent representation of the MAP-Protocol.

It allows to see at all the parameters, including all nested ones for a specific operationcode or errorcode at once.

Note that for those operations which use a result without parameters the keyword RESULT is not shown. Empty results are only defined in the ASN.1 description in clause 17.

B.1 Fully Expanded ASN.1 Source of MAP-Protocol/TCAPMessages

```
--          Expanded ASN1 Module 'MAP-Protocol'
--SIEMENS ASN.1 Compiler      R4.81 (48-00-02)
--          Date: 2000-07-19 Time: 08:07:06

MAP-Protocol{ 0 identified-organization (4) etsi (0) mobileDomain (0) gsm-Network (1) modules (3)
map-Protocol (4) version5 (5) }

DEFINITIONS

:=

BEGIN

updateLocation OPERATION
  ARGUMENT
    updateLocationArg SEQUENCE {
      imsi          OCTET STRING ( SIZE (3 .. 8 ) ),
      msc-Number    [1] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 .. 9 ) ),
      vlr-Number    OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 .. 9 ) ),
      lmsi          [10] IMPLICIT OCTET STRING ( SIZE (4 ) ) OPTIONAL,
      extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
          SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
              '
              ...
            } ),
            extType     MAP-EXTENSION .&ExtensionType ( {
              ...
            } { @extId } ) OPTIONAL} OPTIONAL,
        pcs-Extensions [1] IMPLICIT SEQUENCE {
          ...
        } OPTIONAL,
        ...
      },
      vlr-Capability [6] IMPLICIT SEQUENCE {
        supportedCamelPhases [0] IMPLICIT BIT STRING {
          phase1 (0),
          phase2 (1) } ( SIZE (1 .. 16 ) ) OPTIONAL,
        extensionContainer SEQUENCE {
          privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
              extId      MAP-EXTENSION .&extensionId ( {
                ...
              } ),
              extType     MAP-EXTENSION .&ExtensionType ( {
                ...
              } )
            }
        }
      }
    }
  }
```

```

        ... } { @extId } ) OPTIONAL} OPTIONAL,
    pcs-Extensions [1] IMPLICIT SEQUENCE {
        ... } OPTIONAL,
        ... } OPTIONAL,
        ...
        solsaSupportIndicator [2] IMPLICIT NULL OPTIONAL} OPTIONAL}
RESULT
updateLocationRes SEQUENCE {
    hlr-Number OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) ),
    extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
            SEQUENCE {
                extId MAP-EXTENSION .&extensionId ( {
                    ...
                    ...
                ) ,
                extType MAP-EXTENSION .&ExtensionType ( {
                    ...
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ...
                    ...
                } OPTIONAL,
                ...
            }
        }
    }
ERRORS {
    -- systemFailure -- localValue : 34,
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- unknownSubscriber -- localValue : 1,
    -- roamingNotAllowed -- localValue : 8}
::= localValue : 2

cancelLocation OPERATION
ARGUMENT
cancelLocationArg [3] IMPLICIT SEQUENCE {
    identity CHOICE {
        imsi OCTET STRING ( SIZE (3 .. 8) ),
        imsi-WithLMSI SEQUENCE {
            imsi OCTET STRING ( SIZE (3 .. 8) ),
            lmsi OCTET STRING ( SIZE (4) ),
            ...
        },
        cancellationType ENUMERATED {
            updateProcedure (0),
            subscriptionWithdraw (1),
            ...
        } OPTIONAL,
        extensionContainer SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                SEQUENCE {
                    extId MAP-EXTENSION .&extensionId ( {
                        ...
                        ...
                    ) ,
                    extType MAP-EXTENSION .&ExtensionType ( {
                        ...
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
                    pcs-Extensions [1] IMPLICIT SEQUENCE {
                        ...
                        ...
                    } OPTIONAL,
                    ...
                }
            }
        }
    }
RESULT
cancelLocationRes SEQUENCE {
    extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
            SEQUENCE {
                extId MAP-EXTENSION .&extensionId ( {
                    ...
                    ...
                ) ,
                extType MAP-EXTENSION .&ExtensionType ( {
                    ...
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ...
                    ...
                } OPTIONAL,
                ...
            }
        }
    }
ERRORS {
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36}
::= localValue : 3

purgeMS OPERATION
ARGUMENT

```

```

purgeMS-Arg [3] IMPLICIT SEQUENCE {
    imsi          OCTET STRING ( SIZE (3 .. 8) ),
    vlr-Number    [0] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) )
OPTIONAL,
    sgsn-Number   [1] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) )
OPTIONAL,
    extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    '...'},
                    ...),
                extType     MAP-EXTENSION .&ExtensionType ( {
                    '...} { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ...} OPTIONAL,
                    ...} OPTIONAL,
                    ...
                }
RESULT
purgeMS-Res SEQUENCE {
    freezeTMSI      [0] IMPLICIT NULL OPTIONAL,
    freezeP-TMSI    [1] IMPLICIT NULL OPTIONAL,
    extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    '...'),
                    ...),
                extType     MAP-EXTENSION .&ExtensionType ( {
                    '...} { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ...} OPTIONAL,
                    ...} OPTIONAL,
                    ...
                }
ERRORS {
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- unknownSubscriber -- localValue : 1}
::= localValue : 67

sendIdentification OPERATION
ARGUMENT
    tmsi      OCTET STRING ( SIZE (1 .. 4) )
RESULT
sendIdentificationRes SEQUENCE {
    imsi          OCTET STRING ( SIZE (3 .. 8) ),
    authenticationSetList SEQUENCE ( SIZE (1 .. 5) ) OF
        SEQUENCE {
            rand      OCTET STRING ( SIZE (16) ),
            sres      OCTET STRING ( SIZE (4) ),
            kc       OCTET STRING ( SIZE (8) ),
            ...
        } OPTIONAL,
        ...
    }
ERRORS {
    -- dataMissing -- localValue : 35,
    -- unidentifiedSubscriber -- localValue : 5}
::= localValue : 55

prepareHandover OPERATION
ARGUMENT
    prepareHO-Arg SEQUENCE {
        targetCellId    OCTET STRING ( SIZE (5 .. 7) ) OPTIONAL,
        ho-NumberNotRequired NULL OPTIONAL,
        bss-APDU        SEQUENCE {
            protocolId  ENUMERATED {
                gsm-0408    (1),
                gsm-0806    (2),
                gsm-BSSMAP  (3),
                ets-300102-1 (4)},
                signalInfo   OCTET STRING ( SIZE (1 .. 200) ),
                extensionContainer SEQUENCE {
                    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                        SEQUENCE {
                            extId      MAP-EXTENSION .&extensionId ( {
                                '...}),
                                ...
                            })
                }
            }
        }
    }

```

```

        extType      MAP-EXTENSION .&ExtensionType  ( {
            ...
            ...} { @extId    } )  OPTIONAL} OPTIONAL,
        pcs-Extensions [1] IMPLICIT SEQUENCE {
            ...
            ...} OPTIONAL,
            ...
            ...} OPTIONAL,
            ...
            ...
        }
    RESULT
    prepareHO-Res SEQUENCE {
        handoverNumber OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) ) OPTIONAL,
        bss-APDU       SEQUENCE {
            protocolId      ENUMERATED {
                gsm-0408      (1 ),
                gsm-0806      (2 ),
                gsm-BSSMAP     (3 ),
                ets-300102-1   (4 )},
            signalInfo      OCTET STRING ( SIZE (1 .. 200) ),
            extensionContainer SEQUENCE {
                privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                    SEQUENCE {
                        extId      MAP-EXTENSION .&extensionId  ( {
                            ...
                            ...} ),
                            extType      MAP-EXTENSION .&ExtensionType  ( {
                                ...
                                ...} { @extId    } )  OPTIONAL} OPTIONAL,
                                pcs-Extensions [1] IMPLICIT SEQUENCE {
                                    ...
                                    ...} OPTIONAL,
                                    ...
                                    ...} OPTIONAL,
                                    ...
                                    ...
                                }
                            }
                        }
                    }
                }
            }
        }
    }
    ERRORS {
        -- systemFailure -- localValue : 34,
        -- dataMissing -- localValue : 35,
        -- unexpectedDataValue -- localValue : 36,
        -- noHandoverNumberAvailable -- localValue : 25}
    ::= localValue : 68

sendEndSignal OPERATION
ARGUMENT
bss-APDU   SEQUENCE {
    protocolId      ENUMERATED {
        gsm-0408      (1 ),
        gsm-0806      (2 ),
        gsm-BSSMAP     (3 ),
        ets-300102-1   (4 )},
    signalInfo      OCTET STRING ( SIZE (1 .. 200) ),
    extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId  ( {
                    ...
                    ...} ),
                    extType      MAP-EXTENSION .&ExtensionType  ( {
                        ...
                        ...} { @extId    } )  OPTIONAL} OPTIONAL,
                        pcs-Extensions [1] IMPLICIT SEQUENCE {
                            ...
                            ...} OPTIONAL,
                            ...
                            ...
                        }
                    }
                }
            }
        }
    }
    ::= localValue : 29

processAccessSignalling OPERATION
ARGUMENT
bss-APDU   SEQUENCE {
    protocolId      ENUMERATED {
        gsm-0408      (1 ),
        gsm-0806      (2 ),
        gsm-BSSMAP     (3 ),
        ets-300102-1   (4 )},
    signalInfo      OCTET STRING ( SIZE (1 .. 200) ),
    extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId  ( {
                    ...
                    ...} ),
                    ...
                    ...
                }
            }
        }
    }

```

```

        extType      MAP-EXTENSION .&ExtensionType  ( {
          ...
        } { @extId   } ) OPTIONAL} OPTIONAL,
      pcs-Extensions [1] IMPLICIT SEQUENCE {
        ...
      } OPTIONAL,
      ...
    }
  ::= localValue : 33

forwardAccessSignalling OPERATION
ARGUMENT
bss-APDU   SEQUENCE {
  protocolId      ENUMERATED {
    gsm-0408      (1 ),
    gsm-0806      (2 ),
    gsm-BSSMAP     (3 ),
    ets-300102-1  (4 )},
  signalInfo       OCTET STRING ( SIZE (1 .. 200 ) ),
  extensionContainer SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
    SEQUENCE {
      extId      MAP-EXTENSION .&extensionId  ( {
        ...
      } ),
      extType     MAP-EXTENSION .&ExtensionType  ( {
        ...
      } { @extId   } ) OPTIONAL} OPTIONAL,
      pcs-Extensions [1] IMPLICIT SEQUENCE {
        ...
      } OPTIONAL,
      ...
    }
  ::= localValue : 34

prepareSubsequentHandover OPERATION
ARGUMENT
prepareSubsequentHO-Arg SEQUENCE {
  targetCellId     OCTET STRING ( SIZE (5 .. 7 ) ),
  targetMSC-Number OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 .. 9 ) ),
  bss-APDU         SEQUENCE {
    protocolId      ENUMERATED {
      gsm-0408      (1 ),
      gsm-0806      (2 ),
      gsm-BSSMAP     (3 ),
      ets-300102-1  (4 )},
    signalInfo       OCTET STRING ( SIZE (1 .. 200 ) ),
    extensionContainer SEQUENCE {
      privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
      SEQUENCE {
        extId      MAP-EXTENSION .&extensionId  ( {
          ...
        } ),
        extType     MAP-EXTENSION .&ExtensionType  ( {
          ...
        } { @extId   } ) OPTIONAL} OPTIONAL,
        pcs-Extensions [1] IMPLICIT SEQUENCE {
          ...
        } OPTIONAL,
        ...
      },
      ...
    }
  }
RESULT
bss-APDU   SEQUENCE {
  protocolId      ENUMERATED {
    gsm-0408      (1 ),
    gsm-0806      (2 ),
    gsm-BSSMAP     (3 ),
    ets-300102-1  (4 )},
  signalInfo       OCTET STRING ( SIZE (1 .. 200 ) ),
  extensionContainer SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
    SEQUENCE {
      extId      MAP-EXTENSION .&extensionId  ( {
        ...
      } ),
      extType     MAP-EXTENSION .&ExtensionType  ( {
        ...
      } { @extId   } ) OPTIONAL} OPTIONAL,
      pcs-Extensions [1] IMPLICIT SEQUENCE {
        ...
      } OPTIONAL,
    }
  }

```

```

        ... } OPTIONAL,
    ...
}
ERRORS {
-- unexpectedDataValue -- localValue : 36,
-- dataMissing -- localValue : 35,
-- unknownMSC -- localValue : 3,
-- subsequentHandoverFailure -- localValue : 26}
 ::= localValue : 69

sendAuthenticationInfo OPERATION
ARGUMENT
    sendAuthenticationInfoArg OCTET STRING ( SIZE (3 .. 8) )
RESULT
    sendAuthenticationInfoRes SEQUENCE ( SIZE (1 .. 5) ) OF
        SEQUENCE {
            rand      OCTET STRING ( SIZE (16) ),
            sres      OCTET STRING ( SIZE (4) ),
            kc       OCTET STRING ( SIZE (8) ),
            ...
        }
    ERRORS {
-- systemFailure -- localValue : 34,
-- dataMissing -- localValue : 35,
-- unexpectedDataValue -- localValue : 36,
-- unknownSubscriber -- localValue : 1}
 ::= localValue : 56

checkIMEI OPERATION
ARGUMENT
    imei      OCTET STRING ( SIZE (8) )
RESULT
    equipmentStatus ENUMERATED {
        whiteListed   (0),
        blackListed   (1),
        greyListed    (2)}
    ERRORS {
-- systemFailure -- localValue : 34,
-- dataMissing -- localValue : 35,
-- unknownEquipment -- localValue : 7}
 ::= localValue : 43

insertSubscriberData OPERATION
ARGUMENT
    insertSubscriberDataArg SEQUENCE {
        imsi                      [0] IMPLICIT OCTET STRING ( SIZE (3 .. 8 )
    ) OPTIONAL,
        msisdn                    [1] IMPLICIT OCTET STRING ( SIZE (1 .. 20) )
    ( SIZE (1 .. 9) ) OPTIONAL,
        category                  [2] IMPLICIT OCTET STRING ( SIZE (1) )
    OPTIONAL,
        subscriberStatus          [3] IMPLICIT ENUMERATED {
            serviceGranted        (0),
            operatorDeterminedBarring (1) } OPTIONAL,
        bearerServiceList          [4] IMPLICIT SEQUENCE ( SIZE (1 .. 50) ) OF
            OCTET STRING ( SIZE (1 .. 5) ) OPTIONAL,
        teleserviceList            [6] IMPLICIT SEQUENCE ( SIZE (1 .. 20) ) OF
            OCTET STRING ( SIZE (1 .. 5) ) OPTIONAL,
        provisionedSS              [7] IMPLICIT SEQUENCE ( SIZE (1 .. 30) ) OF
        CHOICE {
            forwardingInfo          [0] IMPLICIT SEQUENCE {
                ss-Code           OCTET STRING ( SIZE (1) ),
                forwardingFeatureList SEQUENCE ( SIZE (1 .. 32) ) OF
                    SEQUENCE {
                        basicService      CHOICE {
                            ext-BearerService [2] IMPLICIT OCTET STRING ( SIZE (1 .. 5) ),
                            ext-Teleservice   [3] IMPLICIT OCTET STRING ( SIZE (1 .. 5) ) }
            OPTIONAL,
                ss>Status           [4] IMPLICIT OCTET STRING ( SIZE (1 .. 5) ),
                forwardedToNumber     [5] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) (
        SIZE (1 .. 9) ) OPTIONAL,
                forwardedToSubaddress [8] IMPLICIT OCTET STRING ( SIZE (1 .. 21) )
        OPTIONAL,
                forwardingOptions     [6] IMPLICIT OCTET STRING ( SIZE (1 .. 5) )
        OPTIONAL,
                noReplyConditionTime  [7] IMPLICIT INTEGER ( 1 .. 100 ) OPTIONAL,
                extensionContainer    [9] IMPLICIT SEQUENCE {
                    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                        SEQUENCE {
                            extId       MAP-EXTENSION .&extensionId ( {

```

```

        '...} ) ,
extType      MAP-EXTENSION .&ExtensionType  ( {
        '...} { @extId   }  ) OPTIONAL} OPTIONAL,
pcs-Extensions [1] IMPLICIT SEQUENCE {
        ... } OPTIONAL,
        ... } OPTIONAL,
        ... },
extensionContainer [0] IMPLICIT SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
        extId      MAP-EXTENSION .&extensionId  ( {
        '...} ) ,
        extType      MAP-EXTENSION .&ExtensionType  ( {
        '...} { @extId   }  ) OPTIONAL} OPTIONAL,
        pcs-Extensions [1] IMPLICIT SEQUENCE {
        ... } OPTIONAL,
        ... } OPTIONAL,
        ... },
callBarringInfo [1] IMPLICIT SEQUENCE {
        ss-Code          OCTET STRING ( SIZE (1 ) ),
        callBarringFeatureList SEQUENCE ( SIZE (1 .. 32 ) ) OF
SEQUENCE {
        basicService    CHOICE {
            ext-BearerService [2] IMPLICIT OCTET STRING ( SIZE (1 .. 5 ) ),
            ext-Teleservice  [3] IMPLICIT OCTET STRING ( SIZE (1 .. 5 ) ) }
OPTIONAL,
        ss-Status         [4] IMPLICIT OCTET STRING ( SIZE (1 .. 5 ) ),
        extensionContainer SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
                extId      MAP-EXTENSION .&extensionId  ( {
                '...} ) ,
                extType      MAP-EXTENSION .&ExtensionType  ( {
                '...} { @extId   }  ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                ... } OPTIONAL,
                ... } OPTIONAL,
                ... },
        extensionContainer SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
                extId      MAP-EXTENSION .&extensionId  ( {
                '...} ) ,
                extType      MAP-EXTENSION .&ExtensionType  ( {
                '...} { @extId   }  ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                ... } OPTIONAL,
                ... } OPTIONAL,
                ... },
cug-Info           [2] IMPLICIT SEQUENCE {
        cug-SubscriptionList SEQUENCE ( SIZE (0 .. 10 ) ) OF
SEQUENCE {
            cug-Index          INTEGER ( 0 .. 32767 ),
            cug-Interlock        OCTET STRING ( SIZE (4 ) ),
            intraCUG-Options    ENUMERATED {
                noCUG-Restrictions (0 ),
                cugIC-CallBarred   (1 ),
                cugOG-CallBarred   (2 )},
            basicServiceGroupList SEQUENCE ( SIZE (1 .. 32 ) ) OF
CHOICE {
                ext-BearerService [2] IMPLICIT OCTET STRING ( SIZE (1 .. 5 ) ),
                ext-Teleservice   [3] IMPLICIT OCTET STRING ( SIZE (1 .. 5 ) ) }
OPTIONAL,
        extensionContainer [0] IMPLICIT SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
                extId      MAP-EXTENSION .&extensionId  ( {
                '...} ) ,
                extType      MAP-EXTENSION .&ExtensionType  ( {

```

```

        '...} { @extId   } ) OPTIONAL} OPTIONAL,
    pcs-Extensions      [1] IMPLICIT SEQUENCE {
        ... } OPTIONAL,
        ... } OPTIONAL,
        ... },
cug-FeatureList      SEQUENCE ( SIZE (1 .. 32 ) ) OF
SEQUENCE {
    basicService      CHOICE {
        ext-BearerService [2] IMPLICIT OCTET STRING ( SIZE (1 .. 5 ) ),
        ext-Teleservice  [3] IMPLICIT OCTET STRING ( SIZE (1 .. 5 ) )}
OPTIONAL,
    preferentialCUG-Indicator  INTEGER ( 0 .. 32767 ) OPTIONAL,
    interCUG-Restrictions     OCTET STRING ( SIZE (1 ) ),
    extensionContainer        SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                '...} ) ,
            extType    MAP-EXTENSION .&ExtensionType ( {
                '...} { @extId   } ) OPTIONAL} OPTIONAL,
        pcs-Extensions      [1] IMPLICIT SEQUENCE {
            ... } OPTIONAL,
            ... } OPTIONAL,
            ... } OPTIONAL,
extensionContainer    [0] IMPLICIT SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
        extId      MAP-EXTENSION .&extensionId ( {
            '...} ) ,
        extType    MAP-EXTENSION .&ExtensionType ( {
            '...} { @extId   } ) OPTIONAL} OPTIONAL,
    pcs-Extensions      [1] IMPLICIT SEQUENCE {
        ... } OPTIONAL,
        ... } OPTIONAL,
        ... },
ss-Data              [3] IMPLICIT SEQUENCE {
    ss-Code          OCTET STRING ( SIZE (1 ) ),
    ss-Status         [4] IMPLICIT OCTET STRING ( SIZE (1 .. 5 ) ),
    ss-SubscriptionOption CHOICE {
        cliRestrictionOption [2] IMPLICIT ENUMERATED {
            permanent           (0 ),
            temporaryDefaultRestricted (1 ),
            temporaryDefaultAllowed (2 ),
        overrideCategory       [1] IMPLICIT ENUMERATED {
            overrideEnabled     (0 ),
            overrideDisabled    (1 )}} OPTIONAL,
    basicServiceGroupList SEQUENCE ( SIZE (1 .. 32 ) ) OF
CHOICE {
        ext-BearerService [2] IMPLICIT OCTET STRING ( SIZE (1 .. 5 ) ),
        ext-Teleservice  [3] IMPLICIT OCTET STRING ( SIZE (1 .. 5 ) )}
OPTIONAL,
    extensionContainer [5] IMPLICIT SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                '...} ) ,
            extType    MAP-EXTENSION .&ExtensionType ( {
                '...} { @extId   } ) OPTIONAL} OPTIONAL,
        pcs-Extensions      [1] IMPLICIT SEQUENCE {
            ... } OPTIONAL,
            ... } OPTIONAL,
            ... },
    emlpp-Info          [4] IMPLICIT SEQUENCE {
        maximumumentitledPriority  INTEGER ( 0 .. 15 ),
        defaultPriority           INTEGER ( 0 .. 15 ),
        extensionContainer        SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    '...} ) ,

```

```

extType      MAP-EXTENSION .&ExtensionType  ( {
    '...} { @extId   } ) OPTIONAL} OPTIONAL,
    pcs-Extensions [1] IMPLICIT SEQUENCE {
        ... } OPTIONAL,
        ... } OPTIONAL,
        ... } } OPTIONAL,
    odb-Data [8] IMPLICIT SEQUENCE {
        odb-GeneralData BIT STRING {
            alLOG-CallsBarred (0),
            internationalOGCallsBarred (1),
            internationalOGCallsNotToHPLMN-CountryBarred (2),
            interzonalOGCallsBarred (6),
            interzonalOGCallsNotToHPLMN-CountryBarred (7),
            interzonalOGCallsAndInternationalOGCallsNotToHPLMN-CountryBarred (8),
            premiumRateInformationOGCallsBarred (3),
            premiumRateEntertainmentOGCallsBarred (4),
            ss-AccessBarred (5),
            allECT-Barred (9),
            chargeableECT-Barred (10),
            internationalECT-Barred (11),
            interzonalECT-Barred (12),
            doublyChargeableECT-Barred (13),
            multipleECT-Barred (14) } ( SIZE (15 .. 32) ),
        odb-HPLMN-Data BIT STRING {
            plmn-SpecificBarringType1 (0),
            plmn-SpecificBarringType2 (1),
            plmn-SpecificBarringType3 (2),
            plmn-SpecificBarringType4 (3) } ( SIZE (4 .. 32) ) OPTIONAL,
        extensionContainer SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        '...} ),
                    extType      MAP-EXTENSION .&ExtensionType  ( {
                        '...} { @extId   } ) OPTIONAL} OPTIONAL,
                        pcs-Extensions [1] IMPLICIT SEQUENCE {
                            ... } OPTIONAL,
                            ... } OPTIONAL,
                            ... } } OPTIONAL,
                roamingRestrictionDueToUnsupportedFeature [9] IMPLICIT NULL OPTIONAL,
                regionalSubscriptionData [10] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                    OCTET STRING ( SIZE (2) ) OPTIONAL,
                vbsSubscriptionData [11] IMPLICIT SEQUENCE ( SIZE (1 .. 50) ) OF
                    SEQUENCE {
                        groupId          OCTET STRING ( SIZE (3) ),
                        broadcastInitEntitlement NULL OPTIONAL,
                        extensionContainer SEQUENCE {
                            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                                SEQUENCE {
                                    extId      MAP-EXTENSION .&extensionId ( {
                                        '...} ),
                                    extType      MAP-EXTENSION .&ExtensionType  ( {
                                        '...} { @extId   } ) OPTIONAL} OPTIONAL,
                                        pcs-Extensions [1] IMPLICIT SEQUENCE {
                                            ... } OPTIONAL,
                                            ... } OPTIONAL,
                                            ... } } OPTIONAL,
                        vgcsSubscriptionData [12] IMPLICIT SEQUENCE ( SIZE (1 .. 50) ) OF
                            SEQUENCE {
                                groupId          OCTET STRING ( SIZE (3) ),
                                extensionContainer SEQUENCE {
                                    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                                        SEQUENCE {
                                            extId      MAP-EXTENSION .&extensionId ( {
                                                '...} ),
                                                extType      MAP-EXTENSION .&ExtensionType  ( {
                                                    '...} { @extId   } ) OPTIONAL} OPTIONAL,
                                                    pcs-Extensions [1] IMPLICIT SEQUENCE {
                                                        ... } OPTIONAL,
                                                        ... } OPTIONAL,
                                                        ... } } OPTIONAL,

```

```

vlrCamelSubscriptionInfo           [13] IMPLICIT SEQUENCE {
  o-CSI                         [0] IMPLICIT SEQUENCE {
    o-BcsmCamelTDPDataList      SEQUENCE ( SIZE (1 .. 10 ) ) OF
      SEQUENCE {
        o-BcsmTriggerDetectionPoint ENUMERATED {
          collectedInfo      (2 ),
          ...
        },
        serviceKey            INTEGER ( 0 .. 2147483647 ),
        gsmSCF-Address        [0] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) (
          SIZE (1 .. 9 ) ),
        defaultCallHandling    [1] IMPLICIT ENUMERATED {
          continueCall       (0 ),
          releaseCall        (1 ),
          ...
        },
        extensionContainer     [2] IMPLICIT SEQUENCE {
          privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
              extId          MAP-EXTENSION .&extensionId ( {
                ,
                ...
              } ),
              extType         MAP-EXTENSION .&ExtensionType ( {
                ,
                ...
              } { @extId } ) OPTIONAL} OPTIONAL,
              pcs-Extensions   [1] IMPLICIT SEQUENCE {
                ...
              } OPTIONAL,
              ...
            } OPTIONAL,
            ...
          },
          extensionContainer    SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
              SEQUENCE {
                extId          MAP-EXTENSION .&extensionId ( {
                  ,
                  ...
                } ),
                extType         MAP-EXTENSION .&ExtensionType ( {
                  ,
                  ...
                } { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions   [1] IMPLICIT SEQUENCE {
                  ...
                } OPTIONAL,
                ...
              } OPTIONAL,
              ...
            },
            camelCapabilityHandling [0] IMPLICIT INTEGER ( 1 .. 16 ) OPTIONAL} OPTIONAL,
            extensionContainer     [1] IMPLICIT SEQUENCE {
              privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                SEQUENCE {
                  extId          MAP-EXTENSION .&extensionId ( {
                    ,
                    ...
                  } ),
                  extType         MAP-EXTENSION .&ExtensionType ( {
                    ,
                    ...
                  } { @extId } ) OPTIONAL} OPTIONAL,
                  pcs-Extensions   [1] IMPLICIT SEQUENCE {
                    ...
                  } OPTIONAL,
                  ...
                } OPTIONAL,
                ...
              },
              ss-CSI             [2] IMPLICIT SEQUENCE {
                ss-CamelData      SEQUENCE {
                  ss-EventList      SEQUENCE ( SIZE (1 .. 10 ) ) OF
                    OCTET STRING ( SIZE (1 ) ),
                    gsmSCF-Address    OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 .. 9 ) ),
                    extensionContainer [0] IMPLICIT SEQUENCE {
                      privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                        SEQUENCE {
                          extId          MAP-EXTENSION .&extensionId ( {
                            ,
                            ...
                          } ),
                          extType         MAP-EXTENSION .&ExtensionType ( {
                            ,
                            ...
                          } { @extId } ) OPTIONAL} OPTIONAL,
                          pcs-Extensions   [1] IMPLICIT SEQUENCE {
                            ...
                          } OPTIONAL,
                          ...
                        },
                        extensionContainer SEQUENCE {
                          privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                            SEQUENCE {
                              extId          MAP-EXTENSION .&extensionId ( {
                                ,
                                ...
                              } ),
                              ...
                            }
                          }
                        }
                      }
                    }
                  }
                }
              }
            }
          }
        }
      }
    }
  }
}

```



```

    pcs-Extensions          [1] IMPLICIT SEQUENCE {
        ...
    },
extensionContainer      [2] IMPLICIT SEQUENCE {
privateExtensionList   [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
    extId      MAP-EXTENSION .&extensionId ( {
        ...
    },
    extType     MAP-EXTENSION .&ExtensionType ( {
        ...
    } { @extId } ) OPTIONAL} OPTIONAL,
    pcs-Extensions [1] IMPLICIT SEQUENCE {
        ...
    } OPTIONAL,
    ...
} OPTIONAL,
roamingRestrictedInSgsnDueToUnsupportedFeature [23] IMPLICIT NULL OPTIONAL,
networkAccessMode       [24] IMPLICIT ENUMERATED {
    bothMSCAndSGSN   (0 ),
    onlyMSC          (1 ),
    onlySGSN         (2 ),
    ...
} OPTIONAL,
lsaInformation          [25] IMPLICIT SEQUENCE {
    completeDataListIncluded NULL OPTIONAL,
    lsaOnlyAccessIndicator [1] IMPLICIT ENUMERATED {
        accessOutsideLSAsAllowed (0 ),
        accessOutsideLSAsRestricted (1 ) } OPTIONAL,
    lsaDataList        [2] IMPLICIT SEQUENCE ( SIZE (1 .. 20 ) ) OF
SEQUENCE {
        lsaIdentity      [0] IMPLICIT OCTET STRING ( SIZE (3 ) ),
        lsaAttributes     [1] IMPLICIT OCTET STRING ( SIZE (1 ) ),
        lsaActiveModeIndicator [2] IMPLICIT NULL OPTIONAL,
        extensionContainer [3] IMPLICIT SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                },
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        } OPTIONAL,
        ...
    },
    extensionContainer [3] IMPLICIT SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ...
            },
            extType     MAP-EXTENSION .&ExtensionType ( {
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
        pcs-Extensions [1] IMPLICIT SEQUENCE {
            ...
        } OPTIONAL,
        ...
    } OPTIONAL,
    ...
},
lmu-Indicator           [21] IMPLICIT NULL OPTIONAL,
lcsInformation          [22] IMPLICIT SEQUENCE {
    gmlc-List        [0] IMPLICIT SEQUENCE ( SIZE (1 .. 5 ) ) OF
OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 .. 9 ) ) OPTIONAL,
    lcs-PrivacyExceptionList [1] IMPLICIT SEQUENCE ( SIZE (1 .. 4 ) ) OF
SEQUENCE {
        ss-Code          OCTET STRING ( SIZE (1 ) ),
        ss-Status        OCTET STRING ( SIZE (1 .. 5 ) ),
        notificationToMSUser [0] IMPLICIT ENUMERATED {
            notifyLocationAllowed (0 ),
            notifyAndVerify-LocationAllowedIfNoResponse (1 ),
            notifyAndVerify-LocationNotAllowedIfNoResponse (2 ),
            ...
        } OPTIONAL,
        externalClientList [1] IMPLICIT SEQUENCE ( SIZE (0 .. 5 ) ) OF
SEQUENCE {
            clientIdentity SEQUENCE {
                externalAddress [0] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) )
OPTIONAL,
            extensionContainer [1] IMPLICIT SEQUENCE {

```

```

privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
    extId      MAP-EXTENSION .&extensionId ( {
        ...
        ...
    } ),
    extType     MAP-EXTENSION .&ExtensionType ( {
        ...
        ...
    } { @extId } ) OPTIONAL} OPTIONAL,
    pcs-Extensions [1] IMPLICIT SEQUENCE {
        ...
        ...
    } OPTIONAL,
    ...
},
gmlc-Restriction [0] IMPLICIT ENUMERATED {
    gmlc-List (0),
    home-Country (1),
    ...
} OPTIONAL,
notificationToMSUser [1] IMPLICIT ENUMERATED {
    notifyLocationAllowed (0),
    notifyAndVerify-LocationAllowedIfNoResponse (1),
    notifyAndVerify-LocationNotAllowedIfNoResponse (2),
    ...
} OPTIONAL,
extensionContainer [2] IMPLICIT SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
        extId      MAP-EXTENSION .&extensionId ( {
            ...
            ...
        } ),
        extType     MAP-EXTENSION .&ExtensionType ( {
            ...
            ...
        } { @extId } ) OPTIONAL} OPTIONAL,
        pcs-Extensions [1] IMPLICIT SEQUENCE {
            ...
            ...
        } OPTIONAL,
        ...
    } OPTIONAL,
    ...
},
plmnClientList [2] IMPLICIT SEQUENCE ( SIZE (1 .. 5 ) ) OF
ENUMERATED {
    broadcastService (0),
    o-andM-HPLMN (1),
    o-andM-VPLMN (2),
    anonymousLocation (3),
    targetMSSubscribedService (4),
    ...
} OPTIONAL,
extensionContainer [3] IMPLICIT SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
        extId      MAP-EXTENSION .&extensionId ( {
            ...
            ...
        } ),
        extType     MAP-EXTENSION .&ExtensionType ( {
            ...
            ...
        } { @extId } ) OPTIONAL} OPTIONAL,
        pcs-Extensions [1] IMPLICIT SEQUENCE {
            ...
            ...
        } OPTIONAL,
        ...
    } OPTIONAL,
    ...
},
m0lr-List [2] IMPLICIT SEQUENCE ( SIZE (1 .. 3 ) ) OF
SEQUENCE {
    ss-Code          OCTET STRING ( SIZE (1 ) ),
    ss-Status        OCTET STRING ( SIZE (1 .. 5 ) ),
    extensionContainer [0] IMPLICIT SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ...
                ...
            } ),
            extType     MAP-EXTENSION .&ExtensionType ( {
                ...
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ...
                ...
            } OPTIONAL,
            ...
        } OPTIONAL,
        ...
    } OPTIONAL,
    ...
},
RESULT
insertSubscriberDataRes SEQUENCE {
    teleserviceList [1] IMPLICIT SEQUENCE ( SIZE (1 .. 20 ) ) OF
    OCTET STRING ( SIZE (1 .. 5 ) ) OPTIONAL,
    bearerServiceList [2] IMPLICIT SEQUENCE ( SIZE (1 .. 50 ) ) OF
}

```

```

    OCTET STRING ( SIZE (1 .. 5 ) ) OPTIONAL,
ss-List [3] IMPLICIT SEQUENCE ( SIZE (1 .. 30 ) ) OF
    OCTET STRING ( SIZE (1 ) ) OPTIONAL,
    odb-GeneralData [4] IMPLICIT BIT STRING {
        allOG-CallsBarred (0),
        internationalOGCallsBarred (1),
        internationalOGCallsNotToHPLMN-CountryBarred (2),
        interzonalOGCallsBarred (6),
        interzonalOGCallsNotToHPLMN-CountryBarred (7),
        interzonalOGCallsAndInternationalOGCallsNotToHPLMN-CountryBarred (8),
        premiumRateInformationOGCallsBarred (3),
        premiumRateEntertainementOGCallsBarred (4),
        ss-AccessBarred (5),
        allECT-Barred (9),
        chargeableECT-Barred (10),
        internationaleCT-Barred (11),
        interzonalECT-Barred (12),
        doublyChargeableECT-Barred (13),
        multipleECT-Barred (14)} ( SIZE (15 .. 32 ) ) OPTIONAL,
    regionalSubscriptionResponse [5] IMPLICIT ENUMERATED {
        networkNode-AreaRestricted (0),
        tooManyZoneCodes (1),
        zoneCodesConflict (2),
        regionalSubscNotSupported (3)} OPTIONAL,
    supportedCamelPhases [6] IMPLICIT BIT STRING {
        phase1 (0),
        phase2 (1)} ( SIZE (1 .. 16 ) ) OPTIONAL,
extensionContainer [7] IMPLICIT SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
        SEQUENCE {
            extId MAP-EXTENSION .&extensionId ( {
                ...
            } ),
            extType MAP-EXTENSION .&ExtensionType ( {
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        }
    ...
}
ERRORS {
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- unidentifiedSubscriber -- localValue : 5}
::= localValue : 7

deleteSubscriberData OPERATION
    ARGUMENT
        deleteSubscriberDataArg SEQUENCE {
            imsi [0] IMPLICIT OCTET STRING ( SIZE (3 .. 8
) ),
            basicServiceList [1] IMPLICIT SEQUENCE ( SIZE (1 .. 70 )
) OF
                CHOICE {
                    ext-BearerService [2] IMPLICIT OCTET STRING ( SIZE (1 .. 5 ) ),
                    ext-Teleservice [3] IMPLICIT OCTET STRING ( SIZE (1 .. 5 ) ) } OPTIONAL,
            ss-List [2] IMPLICIT SEQUENCE ( SIZE (1 .. 30 )
) OF
                OCTET STRING ( SIZE (1 ) ) OPTIONAL,
                roamingRestrictionDueToUnsupportedFeature [4] IMPLICIT NULL OPTIONAL,
                regionalSubscriptionIdentifier [5] IMPLICIT OCTET STRING ( SIZE (2 ) )
OPTIONAL,
                vbsGroupIndication [7] IMPLICIT NULL OPTIONAL,
                vgcsGroupIndication [8] IMPLICIT NULL OPTIONAL,
                camelSubscriptionInfoWithdraw [9] IMPLICIT NULL OPTIONAL,
                extensionContainer [6] IMPLICIT SEQUENCE {
                    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                        SEQUENCE {
                            extId MAP-EXTENSION .&extensionId ( {
                                ...
                            } ),
                            extType MAP-EXTENSION .&ExtensionType ( {
                                ...
                            } { @extId } ) OPTIONAL} OPTIONAL,
                            pcs-Extensions [1] IMPLICIT SEQUENCE {
                                ...
                            } OPTIONAL,
                            ...
                        }
                    ...
                }
            }
        }
    }

```

```

gprsSubscriptionDataWithdraw [10] CHOICE {
    allGPRSData      NULL,
    contextIdList    SEQUENCE ( SIZE (1 .. 50) ) OF
        INTEGER ( 1 .. 50 ) } OPTIONAL,
    roamingRestrictedInSgsnDueToUnsuppportedFeature [11] IMPLICIT NULL OPTIONAL,
    lsaInformationWithdraw [12] CHOICE {
        allLSAData      NULL,
        lsaIdentityList SEQUENCE ( SIZE (1 .. 20) ) OF
            OCTET STRING ( SIZE (3) ) } OPTIONAL,
        gmlc-ListWithdraw [13] IMPLICIT NULL OPTIONAL}
RESULT
deleteSubscriberDataRes SEQUENCE {
    regionalSubscriptionResponse [0] IMPLICIT ENUMERATED {
        networkNode-AreaRestricted (0),
        tooManyZoneCodes (1),
        zoneCodesConflict (2),
        regionalSubscNotSupported (3) } OPTIONAL,
    extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ,
                    ...
                } ),
                extType    MAP-EXTENSION .&ExtensionType ( {
                    ,
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
        pcs-Extensions [1] IMPLICIT SEQUENCE {
            ...
        } OPTIONAL,
        ...
    }
ERRORS {
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- unidentifiedSubscriber -- localValue : 5}
::= localValue : 8

reset      OPERATION
ARGUMENT
resetArg   SEQUENCE {
    hlr-Number  OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) ),
    hlr-List    SEQUENCE ( SIZE (1 .. 50) ) OF
        OCTET STRING ( SIZE (3 .. 8) ) OPTIONAL,
        ...
}
::= localValue : 37

forwardCheckSS-Indication OPERATION
::= localValue : 38

restoreData OPERATION
ARGUMENT
restoreDataArg SEQUENCE {
    imsi          OCTET STRING ( SIZE (3 .. 8) ),
    lmsi          OCTET STRING ( SIZE (4) ) OPTIONAL,
    extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ,
                    ...
                } ),
                extType    MAP-EXTENSION .&ExtensionType ( {
                    ,
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
        pcs-Extensions [1] IMPLICIT SEQUENCE {
            ...
        } OPTIONAL,
        ...
    }
    ...
    vlr-Capability [6] IMPLICIT SEQUENCE {
        supportedCamelPhases [0] IMPLICIT BIT STRING {
            phase1 (0),
            phase2 (1) } ( SIZE (1 .. 16) ) OPTIONAL,
        extensionContainer SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ,
                        ...
                    } ),
                    extType    MAP-EXTENSION .&ExtensionType ( {
                        ,
                        ...
                    } )
                }
            }
        }
    }
}

```

```

        ...} { @extId } ) OPTIONAL} OPTIONAL,
    pcs-Extensions [1] IMPLICIT SEQUENCE {
        ... } OPTIONAL,
        ... } OPTIONAL,
        ...
        solsaSupportIndicator [2] IMPLICIT NULL OPTIONAL} OPTIONAL}
RESULT
restoreDataRes SEQUENCE {
    hlr-Number          OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) ),
    msNotReachable     NULL OPTIONAL,
    extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ,
                ...
            } ),
            extType     MAP-EXTENSION .&ExtensionType ( {
                ,
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
        pcs-Extensions [1] IMPLICIT SEQUENCE {
            ... } OPTIONAL,
            ... } OPTIONAL,
            ...
        }
    }
ERRORS {
    -- systemFailure -- localValue : 34,
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- unknownSubscriber -- localValue : 1}
::= localValue : 57

activateTraceMode OPERATION
ARGUMENT
activateTraceModeArg SEQUENCE {
    imsi           [0] IMPLICIT OCTET STRING ( SIZE (3 .. 8) ) OPTIONAL,
    traceReference [1] IMPLICIT OCTET STRING ( SIZE (1 .. 2) ),
    traceType      [2] IMPLICIT INTEGER ( 0 .. 255 ),
    omc-Id         [3] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) OPTIONAL,
    extensionContainer [4] IMPLICIT SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ,
                ...
            } ),
            extType     MAP-EXTENSION .&ExtensionType ( {
                ,
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
        pcs-Extensions [1] IMPLICIT SEQUENCE {
            ... } OPTIONAL,
            ... } OPTIONAL,
            ...
        }
    }
RESULT
activateTraceModeRes SEQUENCE {
    extensionContainer [0] IMPLICIT SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ,
                ...
            } ),
            extType     MAP-EXTENSION .&ExtensionType ( {
                ,
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
        pcs-Extensions [1] IMPLICIT SEQUENCE {
            ... } OPTIONAL,
            ... } OPTIONAL,
            ...
        }
    }
ERRORS {
    -- systemFailure -- localValue : 34,
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- facilityNotSupported -- localValue : 21,
    -- unidentifiedSubscriber -- localValue : 5,
    -- tracingBufferFull -- localValue : 40}
::= localValue : 50

deactivateTraceMode OPERATION
ARGUMENT
deactivateTraceModeArg SEQUENCE {
    imsi           [0] IMPLICIT OCTET STRING ( SIZE (3 .. 8) ) OPTIONAL,

```

```

traceReference      [1] IMPLICIT OCTET STRING ( SIZE (1 .. 2) ),
extensionContainer [2] IMPLICIT SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ...
            } ),
            extType     MAP-EXTENSION .&ExtensionType ( {
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
    pcs-Extensions   [1] IMPLICIT SEQUENCE {
        ...
    } OPTIONAL,
    ...
}
RESULT
deactivateTraceModeRes SEQUENCE {
    extensionContainer [0] IMPLICIT SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                } ),
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        }
    }
ERRORS {
    -- systemFailure -- localValue : 34,
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- facilityNotSupported -- localValue : 21,
    -- unidentifiedSubscriber -- localValue : 5}
 ::= localValue : 51

sendIMSI    OPERATION
ARGUMENT
    msisdn    OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) )
RESULT
    imsi      OCTET STRING ( SIZE (3 .. 8) )
ERRORS {
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- unknownSubscriber -- localValue : 1}
 ::= localValue : 58

sendRoutingInfo OPERATION
ARGUMENT
    sendRoutingInfoArg SEQUENCE {
        msisdn          [0] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9)
    ),
        cug-CheckInfo    [1] IMPLICIT SEQUENCE {
            cug-Interlock    OCTET STRING ( SIZE (4) ),
            cug-OutgoingAccess NULL OPTIONAL,
            extensionContainer SEQUENCE {
                privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                    SEQUENCE {
                        extId      MAP-EXTENSION .&extensionId ( {
                            ...
                        } ),
                        extType     MAP-EXTENSION .&ExtensionType ( {
                            ...
                        } { @extId } ) OPTIONAL} OPTIONAL,
                    pcs-Extensions   [1] IMPLICIT SEQUENCE {
                        ...
                    } OPTIONAL,
                    ...
                } OPTIONAL,
                ...
            }
            numberOfForwarding [2] IMPLICIT INTEGER ( 1 .. 5 ) OPTIONAL,
            interrogationType [3] IMPLICIT ENUMERATED {
                basicCall      (0),
                forwarding     (1),
            }
            or-Interrogation [4] IMPLICIT NULL OPTIONAL,
            or-Capability   [5] IMPLICIT INTEGER ( 1 .. 127 ) OPTIONAL,
            gmsc-Address    [6] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9
    ),
            callReferenceNumber [7] IMPLICIT OCTET STRING ( SIZE (1 .. 8) ) OPTIONAL,
}

```

```

forwardingReason           [8] IMPLICIT ENUMERATED {
    notReachable      (0),
    busy              (1),
    noReply           (2)} OPTIONAL,
basicServiceGroup          [9] CHOICE {
    ext-BearerService [2] IMPLICIT OCTET STRING ( SIZE (1 .. 5) ),
    ext-Teleservice   [3] IMPLICIT OCTET STRING ( SIZE (1 .. 5) )} OPTIONAL,
networkSignalInfo          [10] IMPLICIT SEQUENCE {
    protocolId        ENUMERATED {
        gsm-0408       (1),
        gsm-0806       (2),
        gsm-BSSMAP     (3),
        ets-300102-1   (4)},
    signalInfo         OCTET STRING ( SIZE (1 .. 200) ),
    extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ,
                    ...
                } ),
                extType    MAP-EXTENSION .&ExtensionType ( {
                    ,
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
        pcs-Extensions   [1] IMPLICIT SEQUENCE {
            ...
        } OPTIONAL,
        ...
    } OPTIONAL,
    ...
},
camelInfo                  [11] IMPLICIT SEQUENCE {
    supportedCamelPhases BIT STRING {
        phase1 (0),
        phase2 (1)} ( SIZE (1 .. 16) ),
    suppress-T-CSI      NULL OPTIONAL,
    extensionContainer   SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ,
                    ...
                } ),
                extType    MAP-EXTENSION .&ExtensionType ( {
                    ,
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
        pcs-Extensions   [1] IMPLICIT SEQUENCE {
            ...
        } OPTIONAL,
        ...
    } OPTIONAL,
    ...
},
suppressionOfAnnouncement  [12] IMPLICIT NULL OPTIONAL,
extensionContainer          [13] IMPLICIT SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ,
                ...
            } ),
            extType    MAP-EXTENSION .&ExtensionType ( {
                ,
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
        pcs-Extensions   [1] IMPLICIT SEQUENCE {
            ...
        } OPTIONAL,
        ...
    } OPTIONAL,
    ...
},
alertingPattern             [14] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
ccbs-Call                   [15] IMPLICIT NULL OPTIONAL,
supportedCCBS-Phase         [16] IMPLICIT INTEGER ( 1 .. 127 ) OPTIONAL,
additionalSignalInfo         [17] IMPLICIT SEQUENCE {
    ext-ProtocolId     ENUMERATED {
        ets-300356     (1),
        ...
    },
    signalInfo         OCTET STRING ( SIZE (1 .. 200) ),
    extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ,
                    ...
                } ),
                extType    MAP-EXTENSION .&ExtensionType ( {
                    ,
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
        pcs-Extensions   [1] IMPLICIT SEQUENCE {
            ...
        } OPTIONAL,
        ...
    } OPTIONAL,
}

```

```

    ... } OPTIONAL,
    ... } OPTIONAL}
RESULT
sendRoutingInfoRes [3] IMPLICIT SEQUENCE {
    imsi                               [9] IMPLICIT OCTET STRING ( SIZE (3 .. 8 ) ) OPTIONAL,
    extendedRoutingInfo               CHOICE {
        routingInfo             CHOICE {
            roamingNumber      OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 .. 9 ) ),
            forwardingData     SEQUENCE {
                forwardedToNumber   [5] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1
.. 9 ) ) OPTIONAL,
                forwardedToSubaddress [4] IMPLICIT OCTET STRING ( SIZE (1 .. 21 ) ) OPTIONAL,
                forwardingOptions   [6] IMPLICIT OCTET STRING ( SIZE (1 ) ) OPTIONAL,
                extensionContainer  [7] IMPLICIT SEQUENCE {
                    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                        SEQUENCE {
                            extId       MAP-EXTENSION .&extensionId ( {
                                ...
                            } ),
                            extType     MAP-EXTENSION .&ExtensionType ( {
                                ...
                            } { @extId } ) OPTIONAL} OPTIONAL,
                    pcs-Extensions [1] IMPLICIT SEQUENCE {
                        ...
                    } OPTIONAL,
                    ...
                },
                camelRoutingInfo    [8] IMPLICIT SEQUENCE {
                    forwardingData   SEQUENCE {
                        forwardedToNumber   [5] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1
.. 9 ) ) OPTIONAL,
                        forwardedToSubaddress [4] IMPLICIT OCTET STRING ( SIZE (1 .. 21 ) ) OPTIONAL,
                        forwardingOptions   [6] IMPLICIT OCTET STRING ( SIZE (1 ) ) OPTIONAL,
                        extensionContainer  [7] IMPLICIT SEQUENCE {
                            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                                SEQUENCE {
                                    extId       MAP-EXTENSION .&extensionId ( {
                                        ...
                                    } ),
                                    extType     MAP-EXTENSION .&ExtensionType ( {
                                        ...
                                    } { @extId } ) OPTIONAL} OPTIONAL,
                                pcs-Extensions [1] IMPLICIT SEQUENCE {
                                    ...
                                } OPTIONAL,
                                ...
                            },
                            gmscCamelSubscriptionInfo [0] IMPLICIT SEQUENCE {
                                t-CSI           [0] IMPLICIT SEQUENCE {
                                    t-BcsmCamelTDPDataList SEQUENCE ( SIZE (1 .. 10 ) ) OF
                                        SEQUENCE {
                                            t-BcsmTriggerDetectionPoint ENUMERATED {
                                                termAttemptAuthorized (12 ),
                                                ...
                                            },
                                            serviceKey          INTEGER ( 0 .. 2147483647 ),
                                            gsmSCF-Address      [0] IMPLICIT OCTET STRING ( SIZE (1 .. 20
) ) ( SIZE (1 .. 9 ) ),
                                            defaultCallHandling [1] IMPLICIT ENUMERATED {
                                                continueCall      (0 ),
                                                releaseCall       (1 ),
                                                ...
                                            },
                                            extensionContainer  [2] IMPLICIT SEQUENCE {
                                                privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                                                    SEQUENCE {
                                                        extId       MAP-EXTENSION .&extensionId ( {
                                                            ...
                                                        } ),
                                                        extType     MAP-EXTENSION .&ExtensionType ( {
                                                            ...
                                                        } { @extId } ) OPTIONAL} OPTIONAL,
                                                    pcs-Extensions [1] IMPLICIT SEQUENCE {
                                                        ...
                                                    } OPTIONAL,
                                                    ...
                                                },
                                                extensionContainer  SEQUENCE {
                                                    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                                                        SEQUENCE {
                                                            extId       MAP-EXTENSION .&extensionId ( {
                                                                ...
                                                            } ),
                                                        }
                                                    }
                                                }
                                            }
                                        }
                                    }
                                }
                            }
                        }
                    }
                }
            }
        }
    }
}

```

```

        extType      MAP-EXTENSION .&ExtensionType  ( {
          ...
          ... } { @extId   } ) OPTIONAL} OPTIONAL,
        pcs-Extensions [1] IMPLICIT SEQUENCE {
          ...
          ... } OPTIONAL,
          ...
          camelCapabilityHandling [0] IMPLICIT INTEGER ( 1 .. 16 ) OPTIONAL} OPTIONAL,
o-CSI           [1] IMPLICIT SEQUENCE {
        o-BcsmCamelTDPDataList    SEQUENCE ( SIZE (1 .. 10 ) ) OF
          ...
          o-BcsmTriggerDetectionPoint ENUMERATED {
            collectedInfo (2),
            ...
            },
            serviceKey             INTEGER ( 0 .. 2147483647 ),
            gsmSCF-Address         [0] IMPLICIT OCTET STRING ( SIZE (1 .. 20
) ) ( SIZE (1 .. 9 ) ),
            defaultCallHandling     [1] IMPLICIT ENUMERATED {
              continueCall (0),
              releaseCall (1),
              ...
              },
            extensionContainer      [2] IMPLICIT SEQUENCE {
              privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                ...
                extId      MAP-EXTENSION .&extensionId ( {
                  ...
                  ...
                  } ),
                  extType      MAP-EXTENSION .&ExtensionType  ( {
                    ...
                    ... } { @extId   } ) OPTIONAL} OPTIONAL,
                    pcs-Extensions [1] IMPLICIT SEQUENCE {
                      ...
                      ... } OPTIONAL,
                      ...
                      },
                      extensionContainer    SEQUENCE {
                        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                          ...
                          extId      MAP-EXTENSION .&extensionId ( {
                            ...
                            ...
                            } ),
                            extType      MAP-EXTENSION .&ExtensionType  ( {
                              ...
                              ... } { @extId   } ) OPTIONAL} OPTIONAL,
                                pcs-Extensions [1] IMPLICIT SEQUENCE {
                                  ...
                                  ... } OPTIONAL,
                                  ...
                                  },
                                  camelCapabilityHandling [0] IMPLICIT INTEGER ( 1 .. 16 ) OPTIONAL} OPTIONAL,
extensionContainer [2] IMPLICIT SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
          ...
          extId      MAP-EXTENSION .&extensionId ( {
            ...
            ...
            } ),
            extType      MAP-EXTENSION .&ExtensionType  ( {
              ...
              ... } { @extId   } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                  ...
                  ... } OPTIONAL,
                  ...
                  },
                  ...
                  destinationNumberCriteria [0] IMPLICIT SEQUENCE {
                    matchType
                      inhibiting (0),
                      enabling (1)},
                    destinationNumberList [1] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) )
OF
                      OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 .. 9 ) ) OPTIONAL,
destinationNumberLengthList [2] IMPLICIT SEQUENCE ( SIZE (1 .. 3 ) )
OF
                      INTEGER ( 1 .. 15 ) OPTIONAL,
                      ...
                      } OPTIONAL,
basicServiceCriteria [1] IMPLICIT SEQUENCE ( SIZE (1 .. 5 ) ) OF

```

```

        CHOICE {
            ext-BearerService      [2] IMPLICIT OCTET STRING ( SIZE (1 .. 5) ),
            ext-Teleservice       [3] IMPLICIT OCTET STRING ( SIZE (1 .. 5) )}
OPTIONAL,
callTypeCriteria                               [2] IMPLICIT ENUMERATED {
    forwarded          (0),
    notForwarded      (1)} OPTIONAL,
... } OPTIONAL},
extensionContainer      [1] IMPLICIT SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ...
            },
            extType    MAP-EXTENSION .&ExtensionType ( {
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        } } OPTIONAL,
cug-CheckInfo                                     [3] IMPLICIT SEQUENCE {
    cug-Interlock      OCTET STRING ( SIZE (4) ),
    cug-OutgoingAccess NULL OPTIONAL,
    extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                },
                extType    MAP-EXTENSION .&ExtensionType ( {
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ...
                } OPTIONAL,
                ...
            } } OPTIONAL,
            cugSubscriptionFlag [6] IMPLICIT NULL OPTIONAL,
            subscriberInfo   [7] IMPLICIT SEQUENCE {
                locationInformation [0] IMPLICIT SEQUENCE {
                    ageOfLocationInformation INTEGER ( 0 .. 32767 ) OPTIONAL,
                    geographicalInformation [0] IMPLICIT OCTET STRING ( SIZE (8) ) OPTIONAL,
                    vlr-number           [1] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) ) OPTIONAL,
                    locationNumber       [2] IMPLICIT OCTET STRING ( SIZE (2 .. 10) ) OPTIONAL,
                    cellIdOrLAI          [3] CHOICE {
                        cellIdFixedLength [0] IMPLICIT OCTET STRING ( SIZE (7) ),
                        laiFixedLength     [1] IMPLICIT OCTET STRING ( SIZE (5) ) } OPTIONAL,
                    extensionContainer    [4] IMPLICIT SEQUENCE {
                        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                            SEQUENCE {
                                extId      MAP-EXTENSION .&extensionId ( {
                                    ...
                                },
                                extType    MAP-EXTENSION .&ExtensionType ( {
                                    ...
                                } { @extId } ) OPTIONAL} OPTIONAL,
                                pcs-Extensions [1] IMPLICIT SEQUENCE {
                                    ...
                                } OPTIONAL,
                                ...
                            } } OPTIONAL,
                            subscriberState [1] CHOICE {
                                assumedIdle      [0] IMPLICIT NULL,
                                camelBusy        [1] IMPLICIT NULL,
                                netDetNotReachable ENUMERATED {
                                    msPurged        (0),
                                    imsiDetached    (1),
                                    restrictedArea  (2),
                                    notRegistered   (3) },
                                notProvidedFromVLR [2] IMPLICIT NULL } OPTIONAL,
                                extensionContainer [2] IMPLICIT SEQUENCE {
                                    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                                        SEQUENCE {
                                            extId      MAP-EXTENSION .&extensionId ( {
                                                ...
                                            },
                                            extType    MAP-EXTENSION .&ExtensionType ( {
                                                ...
                                            },
                                            ...
                                        ) }
                                }
                            }
                        }
                    }
                }
            }
        }
    }
}

```

```

        ...} { @extId } ) OPTIONAL} OPTIONAL,
    pcs-Extensions [1] IMPLICIT SEQUENCE {
        ... } OPTIONAL,
        ... } OPTIONAL,
        ... } OPTIONAL,
ss-List [1] IMPLICIT SEQUENCE ( SIZE (1 .. 30 ) ) OF
    OCTET STRING ( SIZE (1 ) ) OPTIONAL,
basicService [5] CHOICE {
    ext-BearerService [2] IMPLICIT OCTET STRING ( SIZE (1 .. 5 ) ),
    ext-Teleservice [3] IMPLICIT OCTET STRING ( SIZE (1 .. 5 ) ) } OPTIONAL,
forwardingInterrogationRequired [4] IMPLICIT NULL OPTIONAL,
vmsc-Address [2] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1
.. 9 ) ) OPTIONAL,
extensionContainer [0] IMPLICIT SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
        SEQUENCE {
            extId MAP-EXTENSION .&extensionId ( {
                ,
                ...
            ) ,
            extType MAP-EXTENSION .&ExtensionType ( {
                ,
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ... } OPTIONAL,
                ... } OPTIONAL,
                ...
naea-PreferredCI [10] IMPLICIT SEQUENCE {
    naea-PreferredCIC [0] IMPLICIT OCTET STRING ( SIZE (3 ) ),
    extensionContainer [1] IMPLICIT SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId MAP-EXTENSION .&extensionId ( {
                    ,
                    ...
                ) ,
                extType MAP-EXTENSION .&ExtensionType ( {
                    ,
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ... } OPTIONAL,
                    ... } OPTIONAL,
                    ...
ccbs-Indicators [11] IMPLICIT SEQUENCE {
    ccbs-Possible [0] IMPLICIT NULL OPTIONAL,
    keepCCBS-CallIndicator [1] IMPLICIT NULL OPTIONAL,
    extensionContainer [2] IMPLICIT SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId MAP-EXTENSION .&extensionId ( {
                    ,
                    ...
                ) ,
                extType MAP-EXTENSION .&ExtensionType ( {
                    ,
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ... } OPTIONAL,
                    ... } OPTIONAL,
                    ...
msisdn [12] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE
(1 .. 9 ) ) OPTIONAL,
numberPortabilityStatus [13] IMPLICIT ENUMERATED {
    notKnownToBePorted (0 ),
    ownNumberPortedOut (1 ),
    foreignNumberPortedToForeignNetwork (2 ),
    ...
}
ERRORS {
    -- systemFailure -- localValue : 34,
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- facilityNotSupported -- localValue : 21,
    -- or-NotAllowed -- localValue : 48,
    -- unknownSubscriber -- localValue : 1,
    -- numberChanged -- localValue : 44,
    -- bearerServiceNotProvisioned -- localValue : 10,
    -- teleserviceNotProvisioned -- localValue : 11,
    -- absentSubscriber -- localValue : 27,
    -- busySubscriber -- localValue : 45,
    -- noSubscriberReply -- localValue : 46,
    -- callBarred -- localValue : 13,
}

```

```

-- cug-Reject -- localValue : 15,
-- forwardingViolation -- localValue : 14}
 ::= localValue : 22

provideRoamingNumber OPERATION
ARGUMENT
provideRoamingNumberArg SEQUENCE {
    imsi [0] IMPLICIT OCTET STRING ( SIZE (3 .. 8 ) ),
    msc-Number [1] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 .. 9
) ),
    msisdn [2] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 .. 9
) ) OPTIONAL,
    lmsi [4] IMPLICIT OCTET STRING ( SIZE (4 ) ) OPTIONAL,
    gsm-BearerCapability [5] IMPLICIT SEQUENCE {
        protocolId ENUMERATED {
            gsm-0408 (1 ),
            gsm-0806 (2 ),
            gsm-BSSMAP (3 ),
            ets-300102-1 (4 )},
        signalInfo OCTET STRING ( SIZE (1 .. 200 ) ),
        extensionContainer SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                SEQUENCE {
                    extId MAP-EXTENSION .&extensionId ( {
                        ,
                        ...
                    } ),
                    extType MAP-EXTENSION .&ExtensionType ( {
                        ,
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        } OPTIONAL,
        ...
    } OPTIONAL,
    networkSignalInfo [6] IMPLICIT SEQUENCE {
        protocolId ENUMERATED {
            gsm-0408 (1 ),
            gsm-0806 (2 ),
            gsm-BSSMAP (3 ),
            ets-300102-1 (4 )},
        signalInfo OCTET STRING ( SIZE (1 .. 200 ) ),
        extensionContainer SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                SEQUENCE {
                    extId MAP-EXTENSION .&extensionId ( {
                        ,
                        ...
                    } ),
                    extType MAP-EXTENSION .&ExtensionType ( {
                        ,
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        } OPTIONAL,
        suppressionOfAnnouncement [7] IMPLICIT NULL OPTIONAL,
        gmsc-Address [8] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 .. 9
) ) OPTIONAL,
        callReferenceNumber [9] IMPLICIT OCTET STRING ( SIZE (1 .. 8 ) ) OPTIONAL,
        or-Interrogation [10] IMPLICIT NULL OPTIONAL,
        extensionContainer [11] IMPLICIT SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                SEQUENCE {
                    extId MAP-EXTENSION .&extensionId ( {
                        ,
                        ...
                    } ),
                    extType MAP-EXTENSION .&ExtensionType ( {
                        ,
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        } OPTIONAL,
        ...
    } OPTIONAL,
    alertingPattern [12] IMPLICIT OCTET STRING ( SIZE (1 ) ) OPTIONAL,
    ccbs-Call [13] IMPLICIT NULL OPTIONAL,
    supportedCamelPhasesInGMSC [15] IMPLICIT BIT STRING {
        phase1 (0 ),
        phase2 (1 )} ( SIZE (1 .. 16 ) ) OPTIONAL,
    additionalSignalInfo [14] IMPLICIT SEQUENCE {
        ext-ProtocolId ENUMERATED {
            ...
        }
    }
}

```

```

        ets-300356      (1),
        ...
    signalInfo          OCTET STRING ( SIZE (1 .. 200) ),
extensionContainer   SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
SEQUENCE {
        extId      MAP-EXTENSION .&extensionId ( {
        ...
        ...
    },
    extType      MAP-EXTENSION .&ExtensionType ( {
        ...
        ...
    } { @extId } ) OPTIONAL} OPTIONAL,
    pcs-Extensions [1] IMPLICIT SEQUENCE {
        ...
    } OPTIONAL,
    ...
    ...
} OPTIONAL,
orNotSupportedInGMSC [16] IMPLICIT NULL OPTIONAL}
RESULT
provideRoamingNumberRes SEQUENCE {
    roamingNumber      OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) ),
extensionContainer   SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
SEQUENCE {
        extId      MAP-EXTENSION .&extensionId ( {
        ...
        ...
    },
    extType      MAP-EXTENSION .&ExtensionType ( {
        ...
        ...
    } { @extId } ) OPTIONAL} OPTIONAL,
    pcs-Extensions [1] IMPLICIT SEQUENCE {
        ...
    } OPTIONAL,
    ...
    ...
}
ERRORS {
-- systemFailure -- localValue : 34,
-- dataMissing -- localValue : 35,
-- unexpectedDataValue -- localValue : 36,
-- facilityNotSupported -- localValue : 21,
-- or-NotAllowed -- localValue : 48,
-- absentSubscriber -- localValue : 27,
-- noRoamingNumberAvailable -- localValue : 39}
::= localValue : 4

resumeCallHandling OPERATION
ARGUMENT
resumeCallHandlingArg SEQUENCE {
    callReferenceNumber [0] IMPLICIT OCTET STRING ( SIZE (1 .. 8) ) OPTIONAL,
    basicServiceGroup  [1] CHOICE {
        ext-BearerService [2] IMPLICIT OCTET STRING ( SIZE (1 .. 5) ),
        ext-Teleservice   [3] IMPLICIT OCTET STRING ( SIZE (1 .. 5) ) } OPTIONAL,
    forwardingData     [2] IMPLICIT SEQUENCE {
        forwardedToNumber [5] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9)
) OPTIONAL,
        forwardedToSubaddress [4] IMPLICIT OCTET STRING ( SIZE (1 .. 21) ) OPTIONAL,
        forwardingOptions [6] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
        extensionContainer [7] IMPLICIT SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                ...
                ...
            },
            extType      MAP-EXTENSION .&ExtensionType ( {
                ...
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
            ...
        } OPTIONAL,
        ...
    },
    imsi           [3] IMPLICIT OCTET STRING ( SIZE (3 .. 8) ) OPTIONAL,
    cug-CheckInfo [4] IMPLICIT SEQUENCE {
        cug-Interlock   OCTET STRING ( SIZE (4) ),
        cug-OutgoingAccess NULL OPTIONAL,
        extensionContainer SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                ...
                ...
            },
            ...
        },
        ...
    }
}

```

```

extType      MAP-EXTENSION .&ExtensionType  ( {
    '... } { @extId   } ) OPTIONAL} OPTIONAL,
pcs-Extensions          [1] IMPLICIT SEQUENCE {
    ... } OPTIONAL,
... } OPTIONAL,
... } OPTIONAL,
o-CSI                  [5] IMPLICIT SEQUENCE {
o-BcsmCamelTDPDataList   SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
    o-BcsmTriggerDetectionPoint   ENUMERATED {
        collectedInfo      (2 ),
        ...
    },
    serviceKey           INTEGER ( 0 .. 2147483647 ),
    gsmSCF-Address       [0] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) (
SIZE (1 .. 9 ) ),
    defaultCallHandling   [1] IMPLICIT ENUMERATED {
        continueCall      (0 ),
        releaseCall       (1 ),
        ...
    },
    extensionContainer    [2] IMPLICIT SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
            extId        MAP-EXTENSION .&extensionId  ( {
                '... } ,
            extType      MAP-EXTENSION .&ExtensionType  ( {
                '... } { @extId   } ) OPTIONAL} OPTIONAL,
            pcs-Extensions          [1] IMPLICIT SEQUENCE {
                ... } OPTIONAL,
                ... } OPTIONAL,
            ...
        },
        extensionContainer   SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
                extId        MAP-EXTENSION .&extensionId  ( {
                    '... } ,
                extType      MAP-EXTENSION .&ExtensionType  ( {
                    '... } { @extId   } ) OPTIONAL} OPTIONAL,
                pcs-Extensions          [1] IMPLICIT SEQUENCE {
                    ... } OPTIONAL,
                    ... } OPTIONAL,
                    ...
                },
                camelCapabilityHandling [0] IMPLICIT INTEGER ( 1 .. 16 ) OPTIONAL} OPTIONAL,
extensionContainer     [7] IMPLICIT SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
        extId        MAP-EXTENSION .&extensionId  ( {
            '... } ,
        extType      MAP-EXTENSION .&ExtensionType  ( {
            '... } { @extId   } ) OPTIONAL} OPTIONAL,
            pcs-Extensions          [1] IMPLICIT SEQUENCE {
                ... } OPTIONAL,
                ... } OPTIONAL,
                ...
            },
            ccbs-Possible        [8] IMPLICIT NULL OPTIONAL,
            msisdn             [9] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 .. 9 ) )
OPTIONAL,
            uu-Data             [10] IMPLICIT SEQUENCE {
                uuIndicator      [0] IMPLICIT OCTET STRING ( SIZE (1 ) ) OPTIONAL,
                uui              [1] IMPLICIT OCTET STRING ( SIZE (1 .. 131 ) ) OPTIONAL,
                uusCFInteraction  [2] IMPLICIT NULL OPTIONAL,
                extensionContainer [3] IMPLICIT SEQUENCE {
                    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
                        extId        MAP-EXTENSION .&extensionId  ( {
                            '... } ,
                        extType      MAP-EXTENSION .&ExtensionType  ( {
                            '... } { @extId   } ) OPTIONAL} OPTIONAL,
                            pcs-Extensions          [1] IMPLICIT SEQUENCE {
                                ... } OPTIONAL,
                                ... } OPTIONAL,
                                ...
                            }
                }
            }
        }
    }
}

```

```

        ... } OPTIONAL,
    allInformationSent      [11] IMPLICIT NULL OPTIONAL,
    ...
}

RESULT
resumeCallHandlingRes SEQUENCE {
    extensionContainer   SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                } ),
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
        pcs-Extensions      [1] IMPLICIT SEQUENCE {
            ...
        } OPTIONAL,
        ...
    }
}

ERRORS {
    -- forwardingFailed -- localValue : 47,
    -- or-NotAllowed -- localValue : 48,
    -- unexpectedDataValue -- localValue : 36,
    -- dataMissing -- localValue : 35}
::= localValue : 6

provideSIWFNumber OPERATION
ARGUMENT
provideSIWFNumberArg SEQUENCE {
    gsm-BearerCapability      [0] IMPLICIT SEQUENCE {
        protocolId          ENUMERATED {
            gsm-0408          (1),
            gsm-0806          (2),
            gsm-BSSMAP         (3),
            ets-300102-1       (4)},
        signalInfo           OCTET STRING ( SIZE (1 .. 200) ),
        extensionContainer  SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ...
                    } ),
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions      [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        },
        isdn-BearerCapability [1] IMPLICIT SEQUENCE {
            protocolId          ENUMERATED {
                gsm-0408          (1),
                gsm-0806          (2),
                gsm-BSSMAP         (3),
                ets-300102-1       (4)},
            signalInfo           OCTET STRING ( SIZE (1 .. 200) ),
            extensionContainer  SEQUENCE {
                privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                    SEQUENCE {
                        extId      MAP-EXTENSION .&extensionId ( {
                            ...
                        } ),
                        extType     MAP-EXTENSION .&ExtensionType ( {
                            ...
                        } { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions      [1] IMPLICIT SEQUENCE {
                    ...
                } OPTIONAL,
                ...
            },
            call-Direction        [2] IMPLICIT OCTET STRING ( SIZE (1) ),
            b-Subscriber-Address [3] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9)
        },
        chosenChannel          [4] IMPLICIT SEQUENCE {
            protocolId          ENUMERATED {
                gsm-0408          (1),
                gsm-0806          (2),
                gsm-BSSMAP         (3),
                ets-300102-1       (4)},
            signalInfo           OCTET STRING ( SIZE (1 .. 200) ),
        }
    }
}

```

```

extensionContainer SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ...
            } ),
            extType     MAP-EXTENSION .&ExtensionType ( {
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        },
        ...
    lowerLayerCompatibility [5] IMPLICIT SEQUENCE {
        protocolId      ENUMERATED {
            gsm-0408      (1),
            gsm-0806      (2),
            gsm-BSSMAP     (3),
            ets-300102-1   (4)},
        signalInfo       OCTET STRING ( SIZE (1 .. 200) ),
        extensionContainer SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ...
                    } ),
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
                    pcs-Extensions [1] IMPLICIT SEQUENCE {
                        ...
                    } OPTIONAL,
                    ...
                } OPTIONAL,
                ...
            },
            highLayerCompatibility [6] IMPLICIT SEQUENCE {
                protocolId      ENUMERATED {
                    gsm-0408      (1),
                    gsm-0806      (2),
                    gsm-BSSMAP     (3),
                    ets-300102-1   (4)},
                signalInfo       OCTET STRING ( SIZE (1 .. 200) ),
                extensionContainer SEQUENCE {
                    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                        SEQUENCE {
                            extId      MAP-EXTENSION .&extensionId ( {
                                ...
                            } ),
                            extType     MAP-EXTENSION .&ExtensionType ( {
                                ...
                            } { @extId } ) OPTIONAL} OPTIONAL,
                            pcs-Extensions [1] IMPLICIT SEQUENCE {
                                ...
                            } OPTIONAL,
                            ...
                        } OPTIONAL,
                    extensionContainer [7] IMPLICIT SEQUENCE {
                        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                            SEQUENCE {
                                extId      MAP-EXTENSION .&extensionId ( {
                                    ...
                                } ),
                                extType     MAP-EXTENSION .&ExtensionType ( {
                                    ...
                                } { @extId } ) OPTIONAL} OPTIONAL,
                                pcs-Extensions [1] IMPLICIT SEQUENCE {
                                    ...
                                } OPTIONAL,
                                ...
                            } OPTIONAL,
                            ...
                        }
                },
                RESULT
                provideSIWFNumberRes SEQUENCE {
                    SIWFNumber      [0] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) ),
                    extensionContainer [1] IMPLICIT SEQUENCE {
                        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                            SEQUENCE {
                                extId      MAP-EXTENSION .&extensionId ( {
                                    ...
                                } ),
                                extType     MAP-EXTENSION .&ExtensionType ( {
                                    ...
                                } { @extId } ) OPTIONAL} OPTIONAL,
                                ...
                            }
                }
            }
        }
    }
}

```

```

    pcs-Extensions      [1] IMPLICIT SEQUENCE {
        ...
    }
    ...
}
ERRORS {
    -- resourceLimitation -- localValue : 51,
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- systemFailure -- localValue : 34}
 ::= localValue : 31

sIWFSSignallingModify OPERATION
ARGUMENT
    sIWFSSignallingModifyArg SEQUENCE {
        channelType          [0] IMPLICIT SEQUENCE {
            protocolId       ENUMERATED {
                gsm-0408      (1 ),
                gsm-0806      (2 ),
                gsm-BSSMAP     (3 ),
                ets-300102-1   (4 )},
                signalInfo      OCTET STRING ( SIZE (1 .. 200 ) ),
                extensionContainer SEQUENCE {
                    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                        SEQUENCE {
                            extId      MAP-EXTENSION .&extensionId ( {
                                ...
                            },
                            ...
                        },
                        extType     MAP-EXTENSION .&ExtensionType ( {
                            ...
                        } { @extId } ) OPTIONAL} OPTIONAL,
                    pcs-Extensions      [1] IMPLICIT SEQUENCE {
                        ...
                    } OPTIONAL,
                    ...
                } OPTIONAL,
                ...
            }
            chosenChannel      [1] IMPLICIT SEQUENCE {
                protocolId       ENUMERATED {
                    gsm-0408      (1 ),
                    gsm-0806      (2 ),
                    gsm-BSSMAP     (3 ),
                    ets-300102-1   (4 )},
                    signalInfo      OCTET STRING ( SIZE (1 .. 200 ) ),
                    extensionContainer SEQUENCE {
                        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                            SEQUENCE {
                                extId      MAP-EXTENSION .&extensionId ( {
                                    ...
                                },
                                ...
                            },
                            extType     MAP-EXTENSION .&ExtensionType ( {
                                ...
                            } { @extId } ) OPTIONAL} OPTIONAL,
                        pcs-Extensions      [1] IMPLICIT SEQUENCE {
                            ...
                        } OPTIONAL,
                        ...
                    } OPTIONAL,
                    ...
                }
                extensionContainer [2] IMPLICIT SEQUENCE {
                    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                        SEQUENCE {
                            extId      MAP-EXTENSION .&extensionId ( {
                                ...
                            },
                            ...
                        },
                        extType     MAP-EXTENSION .&ExtensionType ( {
                            ...
                        } { @extId } ) OPTIONAL} OPTIONAL,
                    pcs-Extensions      [1] IMPLICIT SEQUENCE {
                        ...
                    } OPTIONAL,
                    ...
                }
            }
        }
    }
RESULT
    sIWFSSignallingModifyRes SEQUENCE {
        chosenChannel      [0] IMPLICIT SEQUENCE {
            protocolId       ENUMERATED {
                gsm-0408      (1 ),
                gsm-0806      (2 ),
                gsm-BSSMAP     (3 ),
                ets-300102-1   (4 )},
                signalInfo      OCTET STRING ( SIZE (1 .. 200 ) ),
                extensionContainer SEQUENCE {
                    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF

```

```

SEQUENCE {
    extId      MAP-EXTENSION .&extensionId  ( {
        ,
        ...
    } ) ,
    extType     MAP-EXTENSION .&ExtensionType ( {
        ,
        ...
    } { @extId } ) OPTIONAL} OPTIONAL,
    pcs-Extensions [1] IMPLICIT SEQUENCE {
        ...
    } OPTIONAL,
    ...
    ...
}
extensionContainer [1] IMPLICIT SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId  ( {
                ,
                ...
            } ) ,
            extType     MAP-EXTENSION .&ExtensionType ( {
                ,
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
            ...
        }
}
ERRORS {
    -- resourceLimitation -- localValue : 51,
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- systemFailure -- localValue : 34}
::= localValue : 32

setReportingState OPERATION
ARGUMENT
setReportingStateArg SEQUENCE {
    imsi          [0] IMPLICIT OCTET STRING ( SIZE (3 .. 8) ) OPTIONAL,
    lmsi          [1] IMPLICIT OCTET STRING ( SIZE (4) ) OPTIONAL,
    ccbs-Monitoring [2] IMPLICIT ENUMERATED {
        stopMonitoring (0),
        startMonitoring (1),
        ...
    } OPTIONAL,
}
extensionContainer [3] IMPLICIT SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId  ( {
                ,
                ...
            } ) ,
            extType     MAP-EXTENSION .&ExtensionType ( {
                ,
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
            ...
        }
}
RESULT
setReportingStateRes SEQUENCE {
    ccbs-SubscriberStatus [0] IMPLICIT ENUMERATED {
        ccbsNotIdle (0),
        ccbsIdle (1),
        ccbsNotReachable (2),
        ...
    } OPTIONAL,
}
extensionContainer [1] IMPLICIT SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId  ( {
                ,
                ...
            } ) ,
            extType     MAP-EXTENSION .&ExtensionType ( {
                ,
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
            ...
        }
}
ERRORS {
    -- systemFailure -- localValue : 34,
    -- unidentifiedSubscriber -- localValue : 5,
    -- unexpectedDataValue -- localValue : 36,
    -- dataMissing -- localValue : 35,
}

```

```

-- resourceLimitation -- localValue : 51,
-- facilityNotSupported -- localValue : 21}
 ::= localValue : 73

statusReport OPERATION
ARGUMENT
statusReportArg SEQUENCE {
    imsi          [0] IMPLICIT OCTET STRING ( SIZE (3 .. 8) ),
    eventReportData [1] IMPLICIT SEQUENCE {
        ccbs-SubscriberStatus [0] IMPLICIT ENUMERATED {
            ccbsNotIdle      (0),
            ccbsIdle         (1),
            ccbsNotReachable (2),
            ... } OPTIONAL,
        extensionContainer [1] IMPLICIT SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ,
                        ... } ) ,
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        ,
                        ... } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ... } OPTIONAL,
                ... } OPTIONAL,
                ... } OPTIONAL,
        callReportdata [2] IMPLICIT SEQUENCE {
            monitoringMode [0] IMPLICIT ENUMERATED {
                a-side       (0),
                b-side       (1),
                ... } OPTIONAL,
            callOutcome   [1] IMPLICIT ENUMERATED {
                success      (0),
                failure      (1),
                busy         (2),
                ... } OPTIONAL,
            extensionContainer [2] IMPLICIT SEQUENCE {
                privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                    SEQUENCE {
                        extId      MAP-EXTENSION .&extensionId ( {
                            ,
                            ... } ) ,
                        extType     MAP-EXTENSION .&ExtensionType ( {
                            ,
                            ... } { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ... } OPTIONAL,
                    ... } OPTIONAL,
                    ... } OPTIONAL,
            extensionContainer [3] IMPLICIT SEQUENCE {
                privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                    SEQUENCE {
                        extId      MAP-EXTENSION .&extensionId ( {
                            ,
                            ... } ) ,
                        extType     MAP-EXTENSION .&ExtensionType ( {
                            ,
                            ... } { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ... } OPTIONAL,
                    ... } OPTIONAL,
                    ... }
    }
RESULT
statusReportRes SEQUENCE {
    extensionContainer [0] IMPLICIT SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ,
                    ... } ) ,
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ,
                    ... } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ... } OPTIONAL,
                ... } OPTIONAL,
                ... }
}
```

```

ERRORS {
  -- unknownSubscriber -- localValue : 1,
  -- systemFailure -- localValue : 34,
  -- unexpectedDataValue -- localValue : 36,
  -- dataMissing -- localValue : 35}
 ::= localValue : 74

remoteUserFree OPERATION
ARGUMENT
remoteUserFreeArg SEQUENCE {
  imsi          [0] IMPLICIT OCTET STRING ( SIZE (3 .. 8) ),
  callInfo      [1] IMPLICIT SEQUENCE {
    protocolId   ENUMERATED {
      gsm-0408     (1),
      gsm-0806     (2),
      gsm-BSSMAP   (3),
      ets-300102-1 (4)},
    signalInfo    OCTET STRING ( SIZE (1 .. 200) ),
    extensionContainer SEQUENCE {
      privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
        SEQUENCE {
          extId       MAP-EXTENSION .&extensionId ( {
            ,
            ...
          } ),
          extType     MAP-EXTENSION .&ExtensionType ( {
            ,
            ...
          } { @extId } ) OPTIONAL} OPTIONAL,
      pcs-Extensions [1] IMPLICIT SEQUENCE {
        ...
      } OPTIONAL,
      ...
    } OPTIONAL,
    ...
  },
  ccbs-Feature    [2] IMPLICIT SEQUENCE {
    ccbs-Index      [0] IMPLICIT INTEGER ( 1 .. 5 ) OPTIONAL,
    b-subscriberNumber [1] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9
) ) OPTIONAL,
    b-subscriberSubaddress [2] IMPLICIT OCTET STRING ( SIZE (1 .. 21) ) OPTIONAL,
    basicServiceGroup CHOICE {
      bearerService  [2] IMPLICIT OCTET STRING ( SIZE (1) ),
      teleservice    [3] IMPLICIT OCTET STRING ( SIZE (1) )} OPTIONAL,
      ...
    },
    translatedB-Number [3] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9
) ),
    replaceB-Number [4] IMPLICIT NULL OPTIONAL,
    alertingPattern [5] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
    extensionContainer [6] IMPLICIT SEQUENCE {
      privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
        SEQUENCE {
          extId       MAP-EXTENSION .&extensionId ( {
            ,
            ...
          } ),
          extType     MAP-EXTENSION .&ExtensionType ( {
            ,
            ...
          } { @extId } ) OPTIONAL} OPTIONAL,
      pcs-Extensions [1] IMPLICIT SEQUENCE {
        ...
      } OPTIONAL,
      ...
    }
  }
RESULT
remoteUserFreeRes SEQUENCE {
  ruf-Outcome      [0] IMPLICIT ENUMERATED {
    accepted        (0),
    rejected        (1),
    noResponseFromFreeMS (2),
    noResponseFromBusyMS (3),
    udubFromFreeMS (4),
    udubFromBusyMS (5),
    ...
  },
  extensionContainer [1] IMPLICIT SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
      SEQUENCE {
        extId       MAP-EXTENSION .&extensionId ( {
          ,
          ...
        } ),
        extType     MAP-EXTENSION .&ExtensionType ( {
          ,
          ...
        } { @extId } ) OPTIONAL} OPTIONAL,
      pcs-Extensions [1] IMPLICIT SEQUENCE {
        ...
      } OPTIONAL,
      ...
    }
  }
}

```

```

    ...
}
ERRORS {
-- unexpectedDataValue -- localValue : 36,
-- dataMissing -- localValue : 35,
-- incompatibleTerminal -- localValue : 28,
-- absentSubscriber -- localValue : 27,
-- systemFailure -- localValue : 34,
-- busySubscriber -- localValue : 45}
 ::= localValue : 75

registerSS OPERATION
ARGUMENT
registerSS-Arg SEQUENCE {
    ss-Code          OCTET STRING ( SIZE (1) ),
    basicService    CHOICE {
        bearerService [2] IMPLICIT OCTET STRING ( SIZE (1) ),
        teleservice   [3] IMPLICIT OCTET STRING ( SIZE (1) ) } OPTIONAL,
    forwardedToNumber [4] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) OPTIONAL,
    forwardedToSubaddress [6] IMPLICIT OCTET STRING ( SIZE (1 .. 21) ) OPTIONAL,
    noReplyConditionTime [5] IMPLICIT INTEGER ( 5 .. 30 ) OPTIONAL,
    ...
    defaultPriority [7] IMPLICIT INTEGER ( 0 .. 15 ) OPTIONAL}
RESULT
ss-Info CHOICE {
    forwardingInfo [0] IMPLICIT SEQUENCE {
        ss-Code          OCTET STRING ( SIZE (1) ) OPTIONAL,
        forwardingFeatureList SEQUENCE ( SIZE (1 .. 13) ) OF
            SEQUENCE {
                basicService CHOICE {
                    bearerService [2] IMPLICIT OCTET STRING ( SIZE (1) ),
                    teleservice   [3] IMPLICIT OCTET STRING ( SIZE (1) ) } OPTIONAL,
                    ss-Status      [4] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
                    forwardedToNumber [5] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) ) OPTIONAL,
                    forwardedToSubaddress [8] IMPLICIT OCTET STRING ( SIZE (1 .. 21) ) OPTIONAL,
                    forwardingOptions [6] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
                    noReplyConditionTime [7] IMPLICIT INTEGER ( 5 .. 30 ) OPTIONAL,
                    ...
                },
                ...
            },
    callBarringInfo [1] IMPLICIT SEQUENCE {
        ss-Code          OCTET STRING ( SIZE (1) ) OPTIONAL,
        callBarringFeatureList SEQUENCE ( SIZE (1 .. 13) ) OF
            SEQUENCE {
                basicService CHOICE {
                    bearerService [2] IMPLICIT OCTET STRING ( SIZE (1) ),
                    teleservice   [3] IMPLICIT OCTET STRING ( SIZE (1) ) } OPTIONAL,
                    ss-Status      [4] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
                    ...
                },
                ...
            },
    ss-Data          [3] IMPLICIT SEQUENCE {
        ss-Code          OCTET STRING ( SIZE (1) ) OPTIONAL,
        ss-Status        [4] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
        ss-SubscriptionOption CHOICE {
            cliRestrictionOption [2] IMPLICIT ENUMERATED {
                permanent           (0),
                temporaryDefaultRestricted (1),
                temporaryDefaultAllowed (2),
                overrideCategory     [1] IMPLICIT ENUMERATED {
                    overrideEnabled (0),
                    overrideDisabled (1) } OPTIONAL,
            basicServiceGroupList SEQUENCE ( SIZE (1 .. 13) ) OF
                CHOICE {
                    bearerService [2] IMPLICIT OCTET STRING ( SIZE (1) ),
                    teleservice   [3] IMPLICIT OCTET STRING ( SIZE (1) ) } OPTIONAL,
                ...
                defaultPriority    INTEGER ( 0 .. 15 ) OPTIONAL}}
    }
ERRORS {
-- systemFailure -- localValue : 34,
-- dataMissing -- localValue : 35,
-- unexpectedDataValue -- localValue : 36,
-- bearerServiceNotProvisioned -- localValue : 10,
-- teleserviceNotProvisioned -- localValue : 11,
-- callBarred -- localValue : 13,
-- illegalSS-Operation -- localValue : 16,
-- ss-ErrorStatus -- localValue : 17,
-- ss-Incompatibility -- localValue : 20}
 ::= localValue : 10

```

```

eraseSS      OPERATION
ARGUMENT
  ss-ForBS    SEQUENCE {
    ss-Code        OCTET STRING ( SIZE (1) ),
    basicService   CHOICE {
      bearerService [2] IMPLICIT OCTET STRING ( SIZE (1) ),
      teleservice   [3] IMPLICIT OCTET STRING ( SIZE (1) ) } OPTIONAL,
    ...
  }
RESULT
  ss-Info     CHOICE {
    forwardingInfo [0] IMPLICIT SEQUENCE {
      ss-Code          OCTET STRING ( SIZE (1) ) OPTIONAL,
      forwardingFeatureList SEQUENCE ( SIZE (1 .. 13) ) OF
        SEQUENCE {
          basicService   CHOICE {
            bearerService [2] IMPLICIT OCTET STRING ( SIZE (1) ),
            teleservice   [3] IMPLICIT OCTET STRING ( SIZE (1) ) } OPTIONAL,
            ss-Status       [4] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
            forwardedToNumber [5] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1
... 9) ) OPTIONAL,
            forwardedToSubaddress [8] IMPLICIT OCTET STRING ( SIZE (1 .. 21) ) OPTIONAL,
            forwardingOptions [6] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
            noReplyConditionTime [7] IMPLICIT INTEGER ( 5 .. 30 ) OPTIONAL,
            ...
          },
        ...
      },
      callBarringInfo [1] IMPLICIT SEQUENCE {
        ss-Code          OCTET STRING ( SIZE (1) ) OPTIONAL,
        callBarringFeatureList SEQUENCE ( SIZE (1 .. 13) ) OF
          SEQUENCE {
            basicService   CHOICE {
              bearerService [2] IMPLICIT OCTET STRING ( SIZE (1) ),
              teleservice   [3] IMPLICIT OCTET STRING ( SIZE (1) ) } OPTIONAL,
              ss-Status       [4] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
              ...
            },
          ...
        },
        ss-Data         [3] IMPLICIT SEQUENCE {
          ss-Code          OCTET STRING ( SIZE (1) ) OPTIONAL,
          ss-Status       [4] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
          ss-SubscriptionOption CHOICE {
            cliRestrictionOption [2] IMPLICIT ENUMERATED {
              permanent        (0),
              temporaryDefaultRestricted (1),
              temporaryDefaultAllowed (2)},
            overrideCategory [1] IMPLICIT ENUMERATED {
              overrideEnabled (0),
              overrideDisabled (1)} OPTIONAL,
            basicServiceGroupList SEQUENCE ( SIZE (1 .. 13) ) OF
              CHOICE {
                bearerService [2] IMPLICIT OCTET STRING ( SIZE (1) ),
                teleservice   [3] IMPLICIT OCTET STRING ( SIZE (1) ) } OPTIONAL,
              ...
            defaultPriority   INTEGER ( 0 .. 15 ) OPTIONAL}
          }
        }
      }
    }
  }
ERRORS {
  -- systemFailure -- localValue : 34,
  -- dataMissing -- localValue : 35,
  -- unexpectedDataValue -- localValue : 36,
  -- bearerServiceNotProvisioned -- localValue : 10,
  -- teleserviceNotProvisioned -- localValue : 11,
  -- callBarred -- localValue : 13,
  -- illegalSS-Operation -- localValue : 16,
  -- ss-ErrorStatus -- localValue : 17}
 ::= localValue : 11

activateSS OPERATION
ARGUMENT
  ss-ForBS    SEQUENCE {
    ss-Code        OCTET STRING ( SIZE (1) ),
    basicService   CHOICE {
      bearerService [2] IMPLICIT OCTET STRING ( SIZE (1) ),
      teleservice   [3] IMPLICIT OCTET STRING ( SIZE (1) ) } OPTIONAL,
    ...
  }
RESULT
  ss-Info     CHOICE {
    forwardingInfo [0] IMPLICIT SEQUENCE {
      ss-Code          OCTET STRING ( SIZE (1) ) OPTIONAL,
      forwardingFeatureList SEQUENCE ( SIZE (1 .. 13) ) OF
        SEQUENCE {
          basicService   CHOICE {

```

```

        bearerService      [2] IMPLICIT OCTET STRING ( SIZE (1) ),
        teleservice       [3] IMPLICIT OCTET STRING ( SIZE (1) ) } OPTIONAL,
        ss-Status         [4] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
        forwardedToNumber [5] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1
.. 9) ) OPTIONAL,
        forwardedToSubaddress [8] IMPLICIT OCTET STRING ( SIZE (1 .. 21) ) OPTIONAL,
        forwardingOptions [6] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
        noReplyConditionTime [7] IMPLICIT INTEGER ( 5 .. 30 ) OPTIONAL,
        ... },
        ... },
callBarringInfo      [1] IMPLICIT SEQUENCE {
    ss-Code          OCTET STRING ( SIZE (1) ) OPTIONAL,
    callBarringFeatureList SEQUENCE ( SIZE (1 .. 13) ) OF
        SEQUENCE {
            basicService CHOICE {
                bearerService      [2] IMPLICIT OCTET STRING ( SIZE (1) ),
                teleservice       [3] IMPLICIT OCTET STRING ( SIZE (1) ) } OPTIONAL,
                ss-Status         [4] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
                ... },
            ... },
    ss-Data           [3] IMPLICIT SEQUENCE {
        ss-Code          OCTET STRING ( SIZE (1) ) OPTIONAL,
        ss-Status         [4] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
        ss-SubscriptionOption CHOICE {
            cliRestrictionOption [2] IMPLICIT ENUMERATED {
                permanent          (0),
                temporaryDefaultRestricted (1),
                temporaryDefaultAllowed (2)},
            overrideCategory      [1] IMPLICIT ENUMERATED {
                overrideEnabled     (0),
                overrideDisabled   (1) } } OPTIONAL,
        basicServiceGroupList SEQUENCE ( SIZE (1 .. 13) ) OF
            CHOICE {
                bearerService      [2] IMPLICIT OCTET STRING ( SIZE (1) ),
                teleservice       [3] IMPLICIT OCTET STRING ( SIZE (1) ) } OPTIONAL,
            ... ,
            defaultPriority     INTEGER ( 0 .. 15 ) OPTIONAL}}}
ERRORS {
-- systemFailure -- localValue : 34,
-- dataMissing -- localValue : 35,
-- unexpectedDataValue -- localValue : 36,
-- bearerServiceNotProvisioned -- localValue : 10,
-- teleserviceNotProvisioned -- localValue : 11,
-- callBarred -- localValue : 13,
-- illegalSS-Operation -- localValue : 16,
-- ss-ErrorStatus -- localValue : 17,
-- ss-SubscriptionViolation -- localValue : 19,
-- ss-Incompatibility -- localValue : 20,
-- negativePW-Check -- localValue : 38,
-- numberOfWorkAttemptsViolation -- localValue : 43}
 ::= localValue : 12

deactivateSS OPERATION
ARGUMENT
ss-ForBS SEQUENCE {
    ss-Code          OCTET STRING ( SIZE (1) ),
    basicService CHOICE {
        bearerService      [2] IMPLICIT OCTET STRING ( SIZE (1) ),
        teleservice       [3] IMPLICIT OCTET STRING ( SIZE (1) ) } OPTIONAL,
    ... }
RESULT
ss-Info CHOICE {
    forwardingInfo      [0] IMPLICIT SEQUENCE {
        ss-Code          OCTET STRING ( SIZE (1) ) OPTIONAL,
        forwardingFeatureList SEQUENCE ( SIZE (1 .. 13) ) OF
            SEQUENCE {
                basicService CHOICE {
                    bearerService      [2] IMPLICIT OCTET STRING ( SIZE (1) ),
                    teleservice       [3] IMPLICIT OCTET STRING ( SIZE (1) ) } OPTIONAL,
                    ss-Status         [4] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
                    forwardedToNumber [5] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1
.. 9) ) OPTIONAL,
                    forwardedToSubaddress [8] IMPLICIT OCTET STRING ( SIZE (1 .. 21) ) OPTIONAL,
                    forwardingOptions [6] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
                    noReplyConditionTime [7] IMPLICIT INTEGER ( 5 .. 30 ) OPTIONAL,
                    ... },
                ... },
    callBarringInfo      [1] IMPLICIT SEQUENCE {
```

```

ss-Code          OCTET STRING ( SIZE (1) ) OPTIONAL,
callBarringFeatureList SEQUENCE ( SIZE (1 .. 13) ) OF
SEQUENCE {
    basicService CHOICE {
        bearerService [2] IMPLICIT OCTET STRING ( SIZE (1) ),
        teleservice   [3] IMPLICIT OCTET STRING ( SIZE (1) ) } OPTIONAL,
        ss-Status     [4] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
        ... },
    ... },
ss-Data          [3] IMPLICIT SEQUENCE {
    ss-Code          OCTET STRING ( SIZE (1) ) OPTIONAL,
    ss-Status        [4] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
    ss-SubscriptionOption CHOICE {
        cliRestrictionOption [2] IMPLICIT ENUMERATED {
            permanent           (0),
            temporaryDefaultRestricted (1),
            temporaryDefaultAllowed (2)},
        overrideCategory      [1] IMPLICIT ENUMERATED {
            overrideEnabled     (0),
            overrideDisabled    (1)} } OPTIONAL,
    basicServiceGroupList SEQUENCE ( SIZE (1 .. 13) ) OF
    CHOICE {
        bearerService      [2] IMPLICIT OCTET STRING ( SIZE (1) ),
        teleservice        [3] IMPLICIT OCTET STRING ( SIZE (1) ) } OPTIONAL,
    ... ,
    defaultPriority     INTEGER ( 0 .. 15 ) OPTIONAL} }

ERRORS {
-- systemFailure -- localValue : 34,
-- dataMissing -- localValue : 35,
-- unexpectedDataValue -- localValue : 36,
-- bearerServiceNotProvisioned -- localValue : 10,
-- teleserviceNotProvisioned -- localValue : 11,
-- callBarred -- localValue : 13,
-- illegalSS-Operation -- localValue : 16,
-- ss-ErrorStatus -- localValue : 17,
-- ss-SubscriptionViolation -- localValue : 19,
-- negativePW-Check -- localValue : 38,
-- numberOfWorkAttemptsViolation -- localValue : 43}
 ::= localValue : 13

interrogateSS OPERATION
ARGUMENT
ss-ForBS SEQUENCE {
    ss-Code          OCTET STRING ( SIZE (1) ),
    basicService CHOICE {
        bearerService [2] IMPLICIT OCTET STRING ( SIZE (1) ),
        teleservice   [3] IMPLICIT OCTET STRING ( SIZE (1) ) } OPTIONAL,
    ... }
RESULT
interrogateSS-Res CHOICE {
    ss-Status        [0] IMPLICIT OCTET STRING ( SIZE (1) ),
    basicServiceGroupList [2] IMPLICIT SEQUENCE ( SIZE (1 .. 13) ) OF
    CHOICE {
        bearerService [2] IMPLICIT OCTET STRING ( SIZE (1) ),
        teleservice   [3] IMPLICIT OCTET STRING ( SIZE (1) ) },
    forwardingFeatureList [3] IMPLICIT SEQUENCE ( SIZE (1 .. 13) ) OF
    SEQUENCE {
        basicService CHOICE {
            bearerService [2] IMPLICIT OCTET STRING ( SIZE (1) ),
            teleservice   [3] IMPLICIT OCTET STRING ( SIZE (1) ) } OPTIONAL,
            ss-Status       [4] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
            forwardedToNumber [5] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 ..
9) ) OPTIONAL,
            forwardedToSubaddress [8] IMPLICIT OCTET STRING ( SIZE (1 .. 21) ) OPTIONAL,
            forwardingOptions [6] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
            noReplyConditionTime [7] IMPLICIT INTEGER ( 5 .. 30 ) OPTIONAL,
            ... },
        genericServiceInfo [4] IMPLICIT SEQUENCE {
            ss-Status          OCTET STRING ( SIZE (1) ),
            cliRestrictionOption ENUMERATED {
                permanent           (0),
                temporaryDefaultRestricted (1),
                temporaryDefaultAllowed (2)} } OPTIONAL,
            ... ,
            maximumEntitledPriority [0] IMPLICIT INTEGER ( 0 .. 15 ) OPTIONAL,
            defaultPriority     [1] IMPLICIT INTEGER ( 0 .. 15 ) OPTIONAL,
            ccbs-FeatureList   [2] IMPLICIT SEQUENCE ( SIZE (1 .. 5) ) OF
            SEQUENCE {
```

```

ccbs-Index [0] IMPLICIT INTEGER ( 1 .. 5 ) OPTIONAL,
b-subscriberNumber [1] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1
.. 9) ) OPTIONAL,
b-subscriberSubaddress [2] IMPLICIT OCTET STRING ( SIZE (1 .. 21) ) OPTIONAL,
basicServiceGroup [3] CHOICE {
    bearerService [2] IMPLICIT OCTET STRING ( SIZE (1) ),
    teleservice [3] IMPLICIT OCTET STRING ( SIZE (1) ) } OPTIONAL,
    ... } OPTIONAL} }

ERRORS {
    -- systemFailure -- localValue : 34,
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- bearerServiceNotProvisioned -- localValue : 10,
    -- teleserviceNotProvisioned -- localValue : 11,
    -- callBarred -- localValue : 13,
    -- illegalSS-Operation -- localValue : 16,
    -- ss-NotAvailable -- localValue : 18}
    ::= localValue : 14

processUnstructuredSS-Request OPERATION
ARGUMENT
    ussd-Arg SEQUENCE {
        ussd-DataCodingScheme OCTET STRING ( SIZE (1) ),
        ussd-String OCTET STRING ( SIZE (1 .. 160) ),
        ...
        alertingPattern OCTET STRING ( SIZE (1) ) OPTIONAL,
        msisdn [0] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) )
    OPTIONAL}
RESULT
    ussd-Res SEQUENCE {
        ussd-DataCodingScheme OCTET STRING ( SIZE (1) ),
        ussd-String OCTET STRING ( SIZE (1 .. 160) ),
        ...
    }
ERRORS {
    -- systemFailure -- localValue : 34,
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- unknownAlphabet -- localValue : 71,
    -- callBarred -- localValue : 13}
    ::= localValue : 59

unstructuredSS-Request OPERATION
ARGUMENT
    ussd-Arg SEQUENCE {
        ussd-DataCodingScheme OCTET STRING ( SIZE (1) ),
        ussd-String OCTET STRING ( SIZE (1 .. 160) ),
        ...
        alertingPattern OCTET STRING ( SIZE (1) ) OPTIONAL,
        msisdn [0] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) )
    OPTIONAL}
RESULT
    ussd-Res SEQUENCE {
        ussd-DataCodingScheme OCTET STRING ( SIZE (1) ),
        ussd-String OCTET STRING ( SIZE (1 .. 160) ),
        ...
    }
ERRORS {
    -- systemFailure -- localValue : 34,
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- absentSubscriber -- localValue : 27,
    -- illegalSubscriber -- localValue : 9,
    -- illegalEquipment -- localValue : 12,
    -- unknownAlphabet -- localValue : 71,
    -- ussd-Busy -- localValue : 72}
    ::= localValue : 60

unstructuredSS-Notify OPERATION
ARGUMENT
    ussd-Arg SEQUENCE {
        ussd-DataCodingScheme OCTET STRING ( SIZE (1) ),
        ussd-String OCTET STRING ( SIZE (1 .. 160) ),
        ...
        alertingPattern OCTET STRING ( SIZE (1) ) OPTIONAL,
        msisdn [0] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) )
    OPTIONAL}
ERRORS {
    -- systemFailure -- localValue : 34,
    -- dataMissing -- localValue : 35,

```

```

-- unexpectedDataValue -- localValue : 36,
-- absentSubscriber -- localValue : 27,
-- illegalSubscriber -- localValue : 9,
-- illegalEquipment -- localValue : 12,
-- unknownAlphabet -- localValue : 71,
-- ussd-Busy -- localValue : 72}
 ::= localValue : 61

registerPassword OPERATION
ARGUMENT
  ss-Code OCTET STRING ( SIZE (1) )
RESULT
  newPassword NumericString ( FROM ("0"|"1"|"2"|"3"|"4"|"5"|"6"|"7"|"8"|"9") | SIZE (4) )
ERRORS {
  -- systemFailure -- localValue : 34,
  -- dataMissing -- localValue : 35,
  -- unexpectedDataValue -- localValue : 36,
  -- callBarred -- localValue : 13,
  -- ss-SubscriptionViolation -- localValue : 19,
  -- pw-RegistrationFailure -- localValue : 37,
  -- negativePW-Check -- localValue : 38,
  -- numberOfPW-AttemptsViolation -- localValue : 43}
LINKED {
  -- getPassword -- localValue : 18}
 ::= localValue : 17

getPassword OPERATION
ARGUMENT
  guidanceInfo ENUMERATED {
    enterPW          (0),
    enterNewPW       (1),
    enterNewPW-Again (2)}
RESULT
  currentPassword NumericString ( FROM ("0"|"1"|"2"|"3"|"4"|"5"|"6"|"7"|"8"|"9") | SIZE (4) )
 ::= localValue : 18

registerCC-Entry OPERATION
ARGUMENT
  registerCC-EntryArg SEQUENCE {
    ss-Code      [0] IMPLICIT OCTET STRING ( SIZE (1) ),
    ccbs-Data    [1] IMPLICIT SEQUENCE {
      ccbs-Feature [0] IMPLICIT SEQUENCE {
        ccbs-Index   [0] IMPLICIT INTEGER ( 1 .. 5 ) OPTIONAL,
        b-subscriberNumber [1] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 ..
9) ) OPTIONAL,
        b-subscriberSubaddress [2] IMPLICIT OCTET STRING ( SIZE (1 .. 21) ) OPTIONAL,
        basicServiceGroup [3] CHOICE {
          bearerService [2] IMPLICIT OCTET STRING ( SIZE (1) ),
          teleservice   [3] IMPLICIT OCTET STRING ( SIZE (1) )} OPTIONAL,
        ... },
      translatedB-Number [1] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) ),
      serviceIndicator [2] IMPLICIT BIT STRING {
        clir-invoked (0),
        camel-invoked (1)} ( SIZE (2 .. 32) ) OPTIONAL,
      callInfo       [3] IMPLICIT SEQUENCE {
        protocolId   ENUMERATED {
          gsm-0408     (1),
          gsm-0806     (2),
          gsm-BSSMAP   (3),
          ets-300102-1 (4)},
        signalInfo    OCTET STRING ( SIZE (1 .. 200) ),
        extensionContainer SEQUENCE {
          privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
            SEQUENCE {
              extId      MAP-EXTENSION .&extensionId ( {
                ,
                ...
              } ),
              extType    MAP-EXTENSION .&ExtensionType ( {
                ,
                ...
              } { @extId } ) OPTIONAL} OPTIONAL,
          pcs-Extensions [1] IMPLICIT SEQUENCE {
            ...
          } OPTIONAL,
          ...
        },
        networkSignalInfo [4] IMPLICIT SEQUENCE {
          protocolId   ENUMERATED {
            gsm-0408     (1),
            gsm-0806     (2),
            ...
          }
        }
      }
    }
  }
}

```

```

        gsm-BSSMAP      ( 3 ),
        ets-300102-1    ( 4 )},
        signalInfo      OCTET STRING ( SIZE (1 .. 200) ),
        extensionContainer SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        '...'},
                        ... } ),
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        '...'} { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ... } OPTIONAL,
                ... } OPTIONAL,
                ... },
                ... } OPTIONAL,
                ... }
        RESULT
        registerCC-EntryRes SEQUENCE {
            ccbs-Feature [0] IMPLICIT SEQUENCE {
                ccbs-Index      [0] IMPLICIT INTEGER ( 1 .. 5 ) OPTIONAL,
                b-subscriberNumber [1] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9 )
            ) ) OPTIONAL,
                b-subscriberSubaddress [2] IMPLICIT OCTET STRING ( SIZE (1 .. 21) ) OPTIONAL,
                basicServiceGroup [3] CHOICE {
                    bearerService   [2] IMPLICIT OCTET STRING ( SIZE (1 ) ),
                    teleservice     [3] IMPLICIT OCTET STRING ( SIZE (1 ) )} OPTIONAL,
                    ... } OPTIONAL,
                ... }
        ERRORS {
            -- systemFailure -- localValue : 34,
            -- dataMissing -- localValue : 35,
            -- unexpectedDataValue -- localValue : 36,
            -- callBarred -- localValue : 13,
            -- illegalSS-Operation -- localValue : 16,
            -- ss-ErrorStatus -- localValue : 17,
            -- ss-Incompatibility -- localValue : 20,
            -- shortTermDenial -- localValue : 29,
            -- longTermDenial -- localValue : 30,
            -- facilityNotSupported -- localValue : 21}
        ::= localValue : 76

eraseCC-Entry OPERATION
ARGUMENT
    eraseCC-EntryArg SEQUENCE {
        ss-Code      [0] IMPLICIT OCTET STRING ( SIZE (1 ) ),
        ccbs-Index   [1] IMPLICIT INTEGER ( 1 .. 5 ) OPTIONAL,
        ... }
RESULT
    eraseCC-EntryRes SEQUENCE {
        ss-Code      [0] IMPLICIT OCTET STRING ( SIZE (1 ) ),
        ss>Status    [1] IMPLICIT OCTET STRING ( SIZE (1 ) ) OPTIONAL,
        ... }
ERRORS {
    -- systemFailure -- localValue : 34,
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- callBarred -- localValue : 13,
    -- illegalSS-Operation -- localValue : 16,
    -- ss-ErrorStatus -- localValue : 17}
 ::= localValue : 77

sendRoutingInfoForSM OPERATION
ARGUMENT
    routingInfoForSM-Arg SEQUENCE {
        msisdn          [0] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9 ) ),
        sm-RP-PRI       [1] IMPLICIT BOOLEAN,
        serviceCentreAddress [2] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ),
        extensionContainer [6] IMPLICIT SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        '...'},
                        ... } ),
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        '...'} { @extId } ) OPTIONAL} OPTIONAL,
                ... }
        }

```

```

    pcs-Extensions      [1] IMPLICIT SEQUENCE {
        ...
    } OPTIONAL,
    ...
    gprsSupportIndicator [7] IMPLICIT NULL OPTIONAL,
    sm-RP-MTI          [8] IMPLICIT INTEGER ( 0 .. 10 ) OPTIONAL,
    sm-RP-SMEA          [9] IMPLICIT OCTET STRING (  SIZE (1 .. 12 ) ) OPTIONAL}
RESULT
routingInfoForSM-Res SEQUENCE {
    imsi          OCTET STRING (  SIZE (3 .. 8 ) ),
    locationInfoWithLMSI [0] IMPLICIT SEQUENCE {
        networkNode-Number [1] IMPLICIT OCTET STRING (  SIZE (1 .. 20 ) ) (  SIZE (1 .. 9 ) ),
        lmsi            OCTET STRING (  SIZE (4 ) ) OPTIONAL,
        extensionContainer SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE (  SIZE (1 .. 10 ) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ...
                    } ),
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        }
        ...
        gprsNodeIndicator [5] IMPLICIT NULL OPTIONAL,
        additional-Number [6] CHOICE {
            msc-Number   [0] IMPLICIT OCTET STRING (  SIZE (1 .. 20 ) ) (  SIZE (1 .. 9 ) ),
            sgsn-Number  [1] IMPLICIT OCTET STRING (  SIZE (1 .. 20 ) ) (  SIZE (1 .. 9 ) )
        }
    OPTIONAL},
    extensionContainer [4] IMPLICIT SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE (  SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                } ),
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
        pcs-Extensions [1] IMPLICIT SEQUENCE {
            ...
        } OPTIONAL,
        ...
    }
}
ERRORS {
    -- systemFailure -- localValue : 34,
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- facilityNotSupported -- localValue : 21,
    -- unknownSubscriber -- localValue : 1,
    -- teleserviceNotProvisioned -- localValue : 11,
    -- callBarred -- localValue : 13,
    -- absentsubscriberSM -- localValue : 6}
::= localValue : 45

mo-forwardSM OPERATION
ARGUMENT
mo-forwardSM-Arg SEQUENCE {
    sm-RP-DA           CHOICE {
        imsi          [0] IMPLICIT OCTET STRING (  SIZE (3 .. 8 ) ),
        lmsi          [1] IMPLICIT OCTET STRING (  SIZE (4 ) ),
        serviceCentreAddressDA [4] IMPLICIT OCTET STRING (  SIZE (1 .. 20 ) ),
        nosM-RP-DA    [5] IMPLICIT NULL },
    sm-RP-OA           CHOICE {
        msisdn        [2] IMPLICIT OCTET STRING (  SIZE (1 .. 20 ) ) (  SIZE (1 ..
9 ) ),
        serviceCentreAddressOA [4] IMPLICIT OCTET STRING (  SIZE (1 .. 20 ) ),
        nosM-RP-OA    [5] IMPLICIT NULL },
    sm-RP-UI           OCTET STRING (  SIZE (1 .. 200 ) ),
    extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE (  SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                } ),
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
            ...
        }
    }
}

```

```

    pcs-Extensions      [1] IMPLICIT SEQUENCE {
        ... } OPTIONAL,
        ... } OPTIONAL,
    ...
    imsi          OCTET STRING ( SIZE (3 .. 8 ) ) OPTIONAL}
RESULT
mo-forwardSM-Res SEQUENCE {
    sm-RP-UI          OCTET STRING ( SIZE (1 .. 200 ) ) OPTIONAL,
    extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ...
            },
            extType     MAP-EXTENSION .&ExtensionType ( {
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ... } OPTIONAL,
                ... } OPTIONAL,
            ...
        }
    }
ERRORS {
    -- systemFailure -- localValue : 34,
    -- unexpectedDataValue -- localValue : 36,
    -- facilityNotSupported -- localValue : 21,
    -- sm-DeliveryFailure -- localValue : 32}
::= localValue : 46

mt-forwardSM OPERATION
ARGUMENT
    mt-forwardSM-Arg SEQUENCE {
        sm-RP-DA           CHOICE {
            imsi          [0] IMPLICIT OCTET STRING ( SIZE (3 .. 8 ) ),
            lmsi          [1] IMPLICIT OCTET STRING ( SIZE (4 ) ),
            serviceCentreAddressDA [4] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ),
            nosM-RP-DA      [5] IMPLICIT NULL},
            sm-RP-OA           CHOICE {
                msisdn       [2] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 ..
9 ) ),
                serviceCentreAddressOA [4] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ),
                nosM-RP-OA      [5] IMPLICIT NULL},
            sm-RP-UI           OCTET STRING ( SIZE (1 .. 200 ) ),
            moreMessagesToSend NULL OPTIONAL,
            extensionContainer SEQUENCE {
                privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ...
                    },
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
                    pcs-Extensions [1] IMPLICIT SEQUENCE {
                        ... } OPTIONAL,
                        ... } OPTIONAL,
                    ...
                }
            }
        }
    }
RESULT
    mt-forwardSM-Res SEQUENCE {
        sm-RP-UI          OCTET STRING ( SIZE (1 .. 200 ) ) OPTIONAL,
        extensionContainer SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                },
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ... } OPTIONAL,
                    ... } OPTIONAL,
                ...
            }
        }
    }
ERRORS {
    -- systemFailure -- localValue : 34,
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- facilityNotSupported -- localValue : 21,
    -- unidentifiedSubscriber -- localValue : 5,
    ...
}
```

```

-- illegalSubscriber -- localValue : 9,
-- illegalEquipment -- localValue : 12,
-- subscriberBusyForMT-SMS -- localValue : 31,
-- sm-DeliveryFailure -- localValue : 32,
-- absentsubscriberSM -- localValue : 6}
::= localValue : 44

reportSM-DeliveryStatus OPERATION
ARGUMENT
  reportSM-DeliveryStatusArg SEQUENCE {
    msisdn                               OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9)
) ),
    serviceCentreAddress                 OCTET STRING ( SIZE (1 .. 20) ),
    sm-DeliveryOutcome                  ENUMERATED {
      memoryCapacityExceeded      (0),
      absentSubscriber            (1),
      successfulTransfer         (2)},
    absentSubscriberDiagnosticSM       [0] IMPLICIT INTEGER (0 .. 255) OPTIONAL,
    extensionContainer                [1] IMPLICIT SEQUENCE {
      privateExtensionList        [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
        SEQUENCE {
          extId      MAP-EXTENSION .&extensionId ( {
            ,
            ...
          },
          extType     MAP-EXTENSION .&ExtensionType ( {
            ,
            ...
          } { @extId } ) OPTIONAL} OPTIONAL,
          pcs-Extensions          [1] IMPLICIT SEQUENCE {
            ...
          } OPTIONAL,
          ...
        } OPTIONAL,
        ...
      gprsSupportIndicator          [2] IMPLICIT NULL OPTIONAL,
      deliveryOutcomeIndicator     [3] IMPLICIT NULL OPTIONAL,
      additionalSM-DeliveryOutcome [4] IMPLICIT ENUMERATED {
        memoryCapacityExceeded      (0),
        absentSubscriber            (1),
        successfulTransfer         (2)} OPTIONAL,
      additionalAbsentSubscriberDiagnosticSM [5] IMPLICIT INTEGER (0 .. 255) OPTIONAL
    }
RESULT
  reportSM-DeliveryStatusRes SEQUENCE {
    storedMSISDN           OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) ) OPTIONAL,
    extensionContainer      SEQUENCE {
      privateExtensionList    [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
        SEQUENCE {
          extId      MAP-EXTENSION .&extensionId ( {
            ,
            ...
          },
          extType     MAP-EXTENSION .&ExtensionType ( {
            ,
            ...
          } { @extId } ) OPTIONAL} OPTIONAL,
          pcs-Extensions          [1] IMPLICIT SEQUENCE {
            ...
          } OPTIONAL,
          ...
        } ...
    }
  }
ERRORS {
  -- dataMissing -- localValue : 35,
  -- unexpectedDataValue -- localValue : 36,
  -- unknownSubscriber -- localValue : 1,
  -- messageWaitingListFull -- localValue : 33}
::= localValue : 47

informServiceCentre OPERATION
ARGUMENT
  informServiceCentreArg SEQUENCE {
    storedMSISDN           OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) ) OPTIONAL,
    mw-Status               BIT STRING {
      sc-AddressNotIncluded (0),
      mnrf-Set             (1),
      mcef-Set              (2),
      mnrg-Set              (3)} ( SIZE (6 .. 16) ) OPTIONAL,
    extensionContainer      SEQUENCE {
      privateExtensionList    [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
        SEQUENCE {
          extId      MAP-EXTENSION .&extensionId ( {
            ,
            ...
          },
          extType     MAP-EXTENSION .&ExtensionType ( {
            ,
            ...
          } ,
          ...
        })
      }
    }
  }

```

```

        ...} { @extId   } ) OPTIONAL} OPTIONAL,
    pcs-Extensions      [1] IMPLICIT SEQUENCE {
        ... } OPTIONAL,
        ... } OPTIONAL,
        ...
    }
 ::= localValue : 63

alertServiceCentre OPERATION
ARGUMENT
    alertServiceCentreArg SEQUENCE {
        msisdn          OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) ),
        serviceCentreAddress OCTET STRING ( SIZE (1 .. 20) ),
        ...
    }
ERRORS {
    -- systemFailure -- localValue : 34,
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36}
 ::= localValue : 64

readyForSM OPERATION
ARGUMENT
    readyForSM-Arg SEQUENCE {
        imsi           IMPLICIT OCTET STRING ( SIZE (3 .. 8) ),
        alertReason    ENUMERATED {
            ms-Present    (0),
            memoryAvailable (1) },
        alertReasonIndicator NULL OPTIONAL,
        extensionContainer SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                SEQUENCE {
                    extId       MAP-EXTENSION .&extensionId ( {
                        ...
                    } ),
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        ...
                    } { @extId   } ) OPTIONAL} OPTIONAL,
                }
            pcs-Extensions      [1] IMPLICIT SEQUENCE {
                ... } OPTIONAL,
                ... } OPTIONAL,
                ...
            }
        }
RESULT
    readyForSM-Res SEQUENCE {
        extensionContainer SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                SEQUENCE {
                    extId       MAP-EXTENSION .&extensionId ( {
                        ...
                    } ),
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        ...
                    } { @extId   } ) OPTIONAL} OPTIONAL,
                }
            pcs-Extensions      [1] IMPLICIT SEQUENCE {
                ... } OPTIONAL,
                ... } OPTIONAL,
                ...
            }
        }
ERRORS {
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- facilityNotSupported -- localValue : 21,
    -- unknownSubscriber -- localValue : 1}
 ::= localValue : 66

provideSubscriberInfo OPERATION
ARGUMENT
    provideSubscriberInfoArg SEQUENCE {
        imsi           [0] IMPLICIT OCTET STRING ( SIZE (3 .. 8) ),
        lmsi           [1] IMPLICIT OCTET STRING ( SIZE (4) ) OPTIONAL,
        requestedInfo  [2] IMPLICIT SEQUENCE {
            locationInformation [0] IMPLICIT NULL OPTIONAL,
            subscriberState     [1] IMPLICIT NULL OPTIONAL,
            extensionContainer  [2] IMPLICIT SEQUENCE {
                privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                    SEQUENCE {
                        extId       MAP-EXTENSION .&extensionId ( {
                            ...
                        } ),
                        extType     MAP-EXTENSION .&ExtensionType ( {
                            ...
                        } ,
                        ...
                    }
                }
            }
        }
    }

```

```

        ...} { @extId } ) OPTIONAL} OPTIONAL,
    pcs-Extensions [1] IMPLICIT SEQUENCE {
        ... } OPTIONAL,
        ... } OPTIONAL,
        ... },
extensionContainer [3] IMPLICIT SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ...
            } ),
            extType     MAP-EXTENSION .&ExtensionType ( {
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
        pcs-Extensions [1] IMPLICIT SEQUENCE {
            ... } OPTIONAL,
            ... } OPTIONAL,
            ...
        }
RESULT
provideSubscriberInfoRes SEQUENCE {
    subscriberInfo   SEQUENCE {
        locationInformation [0] IMPLICIT SEQUENCE {
            ageOfLocationInformation INTEGER ( 0 .. 32767 ) OPTIONAL,
            geographicalInformation [0] IMPLICIT OCTET STRING ( SIZE (8) ) OPTIONAL,
            vlr-number          [1] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1
.. 9) ) OPTIONAL,
            locationNumber       [2] IMPLICIT OCTET STRING ( SIZE (2 .. 10) ) OPTIONAL,
            cellIdOrLAI         [3] CHOICE {
                cellidFixedLength [0] IMPLICIT OCTET STRING ( SIZE (7) ),
                laiFixedLength    [1] IMPLICIT OCTET STRING ( SIZE (5) ) } OPTIONAL,
            extensionContainer   [4] IMPLICIT SEQUENCE {
                privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                    SEQUENCE {
                        extId      MAP-EXTENSION .&extensionId ( {
                            ...
                        } ),
                        extType     MAP-EXTENSION .&ExtensionType ( {
                            ...
                        } { @extId } ) OPTIONAL} OPTIONAL,
                    pcs-Extensions [1] IMPLICIT SEQUENCE {
                        ... } OPTIONAL,
                        ... } OPTIONAL,
                        ...
                    }
                subscriberState      [1] CHOICE {
                    assumedIdle        [0] IMPLICIT NULL,
                    camelBusy          [1] IMPLICIT NULL,
                    netDetNotReachable ENUMERATED {
                        msPurged           (0),
                        imsiDetached        (1),
                        restrictedArea       (2),
                        notRegistered        (3) },
                    notProvidedFromVLR   [2] IMPLICIT NULL } OPTIONAL,
                extensionContainer   [2] IMPLICIT SEQUENCE {
                    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                        SEQUENCE {
                            extId      MAP-EXTENSION .&extensionId ( {
                                ...
                            } ),
                            extType     MAP-EXTENSION .&ExtensionType ( {
                                ...
                            } { @extId } ) OPTIONAL} OPTIONAL,
                        pcs-Extensions [1] IMPLICIT SEQUENCE {
                            ... } OPTIONAL,
                            ... } OPTIONAL,
                            ...
                        },
                extensionContainer   SEQUENCE {
                    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                        SEQUENCE {
                            extId      MAP-EXTENSION .&extensionId ( {
                                ...
                            } ),
                            extType     MAP-EXTENSION .&ExtensionType ( {
                                ...
                            } { @extId } ) OPTIONAL} OPTIONAL,
                        pcs-Extensions [1] IMPLICIT SEQUENCE {
                            ... } OPTIONAL,
                            ... } OPTIONAL,
                            ...
                        }
                }
}

```

```

    ERRORS {
        -- dataMissing -- localValue : 35,
        -- unexpectedDataValue -- localValue : 36}
    ::= localValue : 70

anyTimeInterrogation OPERATION
ARGUMENT
anyTimeInterrogationArg SEQUENCE {
    subscriberIdentity [0] CHOICE {
        imsi      [0] IMPLICIT OCTET STRING ( SIZE (3 .. 8 ) ),
        msisdn    [1] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 .. 9 ) ),
    requestedInfo [1] IMPLICIT SEQUENCE {
        locationInformation [0] IMPLICIT NULL OPTIONAL,
        subscriberState     [1] IMPLICIT NULL OPTIONAL,
        extensionContainer  [2] IMPLICIT SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ...
                    } ),
                    extType    MAP-EXTENSION .&ExtensionType ( {
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        },
        gsmSCF-Address [3] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 .. 9 ) ),
        extensionContainer [2] IMPLICIT SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ...
                    } ),
                    extType    MAP-EXTENSION .&ExtensionType ( {
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        }
    }
RESULT
anyTimeInterrogationRes SEQUENCE {
    subscriberInfo SEQUENCE {
        locationInformation [0] IMPLICIT SEQUENCE {
            ageOfLocationInformation INTEGER ( 0 .. 32767 ) OPTIONAL,
            geographicalInformation [0] IMPLICIT OCTET STRING ( SIZE (8 ) ) OPTIONAL,
            vlr-number          [1] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 .. 9 ) ) OPTIONAL,
            ...
            locationNumber       [2] IMPLICIT OCTET STRING ( SIZE (2 .. 10 ) ) OPTIONAL,
            cellIdOrLAI          [3] CHOICE {
                cellIdFixedLength [0] IMPLICIT OCTET STRING ( SIZE (7 ) ),
                laiFixedLength    [1] IMPLICIT OCTET STRING ( SIZE (5 ) ) } OPTIONAL,
            extensionContainer   [4] IMPLICIT SEQUENCE {
                privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                    SEQUENCE {
                        extId      MAP-EXTENSION .&extensionId ( {
                            ...
                        } ),
                        extType    MAP-EXTENSION .&ExtensionType ( {
                            ...
                        } { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ...
                } OPTIONAL,
                ...
            } OPTIONAL,
            ...
        },
        subscriberState [1] CHOICE {
            assumedIdle      [0] IMPLICIT NULL,
            camelBusy        [1] IMPLICIT NULL,
            netDetNotReachable ENUMERATED {
                msPurged      (0 ),
                imsiDetached   (1 ),
                restrictedArea (2 ),
                notRegistered  (3 ),
            },
            notProvidedFromVLR [2] IMPLICIT NULL } OPTIONAL,
        extensionContainer [2] IMPLICIT SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                SEQUENCE {

```

```

        extId      MAP-EXTENSION .&extensionId  ( {
          ,
          ...
        ) ,
        extType    MAP-EXTENSION .&ExtensionType ( {
          ,
          ...
        } { @extId   } ) OPTIONAL} OPTIONAL,
      pcs-Extensions [1] IMPLICIT SEQUENCE {
        ...
      } OPTIONAL,
      ...
    },
    extensionContainer SEQUENCE {
      privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
      SEQUENCE {
        extId      MAP-EXTENSION .&extensionId  ( {
          ,
          ...
        ) ,
        extType    MAP-EXTENSION .&ExtensionType ( {
          ,
          ...
        } { @extId   } ) OPTIONAL} OPTIONAL,
      pcs-Extensions [1] IMPLICIT SEQUENCE {
        ...
      } OPTIONAL,
      ...
    }
  }
  ERRORS {
    -- systemFailure -- localValue : 34,
    -- ati-NotAllowed -- localValue : 49,
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- unknownSubscriber -- localValue : 1}
  ::= localValue : 71

ss-InvocationNotification OPERATION
  ARGUMENT
    ss-InvocationNotificationArg SEQUENCE {
      imsi           [0] IMPLICIT OCTET STRING ( SIZE (3 .. 8) ),
      msisdn         [1] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) ),
      ss-Event        [2] IMPLICIT OCTET STRING ( SIZE (1) ),
      ss-EventSpecification [3] IMPLICIT SEQUENCE ( SIZE (1 .. 2) ) OF
        OCTET STRING ( SIZE (1 .. 20) ) OPTIONAL,
      extensionContainer [4] IMPLICIT SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
        SEQUENCE {
          extId      MAP-EXTENSION .&extensionId  ( {
            ,
            ...
          ) ,
          extType    MAP-EXTENSION .&ExtensionType ( {
            ,
            ...
          } { @extId   } ) OPTIONAL} OPTIONAL,
        pcs-Extensions [1] IMPLICIT SEQUENCE {
          ...
        } OPTIONAL,
        ...
      }
    }
    RESULT
      ss-InvocationNotificationRes SEQUENCE {
        extensionContainer SEQUENCE {
          privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
          SEQUENCE {
            extId      MAP-EXTENSION .&extensionId  ( {
              ,
              ...
            ) ,
            extType    MAP-EXTENSION .&ExtensionType ( {
              ,
              ...
            } { @extId   } ) OPTIONAL} OPTIONAL,
          pcs-Extensions [1] IMPLICIT SEQUENCE {
            ...
          } OPTIONAL,
          ...
        }
      }
      ERRORS {
        -- dataMissing -- localValue : 35,
        -- unexpectedDataValue -- localValue : 36,
        -- unknownSubscriber -- localValue : 1}
      ::= localValue : 72

prepareGroupCall OPERATION
  ARGUMENT
    prepareGroupCallArg SEQUENCE {
      teleservice     OCTET STRING ( SIZE (1 .. 5) ),
      asciCallReference OCTET STRING ( SIZE (1 .. 8) ),

```

```

codec-Info          OCTET STRING ( SIZE (5 .. 10 ) ),
cipheringAlgorithm OCTET STRING ( SIZE (1 ) ),
groupKeyNumber     [0] IMPLICIT INTEGER ( 0 .. 15 ) OPTIONAL,
groupKey          [1] IMPLICIT OCTET STRING ( SIZE (8 ) ) OPTIONAL,
priority          [2] IMPLICIT INTEGER ( 0 .. 15 ) OPTIONAL,
uplinkFree        [3] IMPLICIT NULL OPTIONAL,
extensionContainer [4] IMPLICIT SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                '...'},
                ...),
            extType     MAP-EXTENSION .&ExtensionType ( {
                '...} { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ...} OPTIONAL,
                ...} OPTIONAL,
            ...
        }
    }
RESULT
prepareGroupCallRes SEQUENCE {
    groupCallNumber      OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 .. 9 ) ),
    extensionContainer   SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    '...'},
                    ...),
                extType     MAP-EXTENSION .&ExtensionType ( {
                    '...} { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ...} OPTIONAL,
                    ...} OPTIONAL,
                    ...
    }
}
ERRORS {
    -- systemFailure -- localValue : 34,
    -- noGroupCallNumberAvailable -- localValue : 50,
    -- unexpectedDataValue -- localValue : 36}
::= localValue : 39

sendGroupCallEndSignal OPERATION
ARGUMENT
sendGroupCallEndSignalArg SEQUENCE {
    imsi                  OCTET STRING ( SIZE (3 .. 8 ) ) OPTIONAL,
    extensionContainer    SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    '...'},
                    ...),
                extType     MAP-EXTENSION .&ExtensionType ( {
                    '...} { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ...} OPTIONAL,
                    ...} OPTIONAL,
                    ...
    }
}
RESULT
sendGroupCallEndSignalRes SEQUENCE {
    extensionContainer   SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    '...'},
                    ...),
                extType     MAP-EXTENSION .&ExtensionType ( {
                    '...} { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ...} OPTIONAL,
                    ...} OPTIONAL,
                    ...
    }
}
::= localValue : 40

processGroupCallSignalling OPERATION
ARGUMENT
processGroupCallSignallingArg SEQUENCE {

```

```

uplinkRequest      [0] IMPLICIT NULL OPTIONAL,
uplinkReleaseIndication [1] IMPLICIT NULL OPTIONAL,
releaseGroupCall    [2] IMPLICIT NULL OPTIONAL,
extensionContainer   SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ' ...
            } ),
            extType     MAP-EXTENSION .&ExtensionType ( {
                ' ...
            } { @extId } ) OPTIONAL} OPTIONAL,
        pcs-Extensions [1] IMPLICIT SEQUENCE {
            ... } OPTIONAL,
            ... } OPTIONAL,
            ...
        }
::= localValue : 41

forwardGroupCallSignalling OPERATION
ARGUMENT
forwardGroupCallSignallingArg SEQUENCE {
    imsi          OCTET STRING ( SIZE (3 .. 8 ) ) OPTIONAL,
    uplinkRequestAck [0] IMPLICIT NULL OPTIONAL,
    uplinkReleaseIndication [1] IMPLICIT NULL OPTIONAL,
    uplinkRejectCommand [2] IMPLICIT NULL OPTIONAL,
    uplinkSeizedCommand [3] IMPLICIT NULL OPTIONAL,
    uplinkReleaseCommand [4] IMPLICIT NULL OPTIONAL,
    extensionContainer   SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ' ...
                } ),
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ' ...
                } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ... } OPTIONAL,
                ... } OPTIONAL,
                ...
            }
::= localValue : 42

updateGprsLocation OPERATION
ARGUMENT
updateGprsLocationArg SEQUENCE {
    imsi          OCTET STRING ( SIZE (3 .. 8 ) ),
    sgsn-Number    OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 .. 9 ) ),
    sgsn-Address   OCTET STRING ( SIZE (5 .. 17 ) ),
    extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ' ...
                } ),
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ' ...
                } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ... } OPTIONAL,
                ... } OPTIONAL,
                ...
            },
            sgsn-Capability [0] IMPLICIT SEQUENCE {
                solsaSupportIndicator NULL OPTIONAL,
                extensionContainer   [1] IMPLICIT SEQUENCE {
                    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                        SEQUENCE {
                            extId      MAP-EXTENSION .&extensionId ( {
                                ' ...
                            } ),
                            extType     MAP-EXTENSION .&ExtensionType ( {
                                ' ...
                            } { @extId } ) OPTIONAL} OPTIONAL,
                        pcs-Extensions [1] IMPLICIT SEQUENCE {
                            ... } OPTIONAL,
                            ... } OPTIONAL,
                            ... } OPTIONAL}
RESULT
updateGprsLocationRes SEQUENCE {

```

```

    hlr-Number          OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 .. 9 ) ),
extensionContainer   SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
    SEQUENCE {
        extId      MAP-EXTENSION .&extensionId ( {
            ...
        } ),
        extType     MAP-EXTENSION .&ExtensionType ( {
            ...
        } { @extId } ) OPTIONAL} OPTIONAL,
    pcs-Extensions     [1] IMPLICIT SEQUENCE {
        ...
    } OPTIONAL,
    ...
}
ERRORS {
    -- systemFailure -- localValue : 34,
    -- unexpectedDataValue -- localValue : 36,
    -- unknownSubscriber -- localValue : 1,
    -- roamingNotAllowed -- localValue : 8}
::= localValue : 23

sendRoutingInfoForGprs OPERATION
ARGUMENT
    sendRoutingInfoForGprsArg SEQUENCE {
        imsi           [0] IMPLICIT OCTET STRING ( SIZE (3 .. 8 ) ),
        ggsn-Address   [1] IMPLICIT OCTET STRING ( SIZE (5 .. 17 ) ) OPTIONAL,
        ggsn-Number    [2] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 .. 9 ) ),
        extensionContainer [3] IMPLICIT SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                } ),
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions     [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        }
    }
RESULT
    sendRoutingInfoForGprsRes SEQUENCE {
        sgsn-Address     [0] IMPLICIT OCTET STRING ( SIZE (5 .. 17 ) ),
        ggsn-Address     [1] IMPLICIT OCTET STRING ( SIZE (5 .. 17 ) ) OPTIONAL,
        mobileNotReachableReason [2] IMPLICIT INTEGER ( 0 .. 255 ) OPTIONAL,
        extensionContainer [3] IMPLICIT SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                } ),
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions     [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        }
    }
ERRORS {
    -- absentSubscriber -- localValue : 27,
    -- systemFailure -- localValue : 34,
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- unknownSubscriber -- localValue : 1}
::= localValue : 24

failureReport OPERATION
ARGUMENT
    failureReportArg SEQUENCE {
        imsi           [0] IMPLICIT OCTET STRING ( SIZE (3 .. 8 ) ),
        ggsn-Number    [1] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 .. 9 ) ),
        ggsn-Address   [2] IMPLICIT OCTET STRING ( SIZE (5 .. 17 ) ) OPTIONAL,
        extensionContainer [3] IMPLICIT SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                } ),
                ...
            }
        }
    }

```

```

        extType      MAP-EXTENSION .&ExtensionType  ( {
            ...
            ... } { @extId   } ) OPTIONAL} OPTIONAL,
    pcs-Extensions [1] IMPLICIT SEQUENCE {
        ...
        ... } OPTIONAL,
        ...
    }

RESULT
failureReportRes SEQUENCE {
    ggsn-Address [0] IMPLICIT OCTET STRING ( SIZE (5 .. 17) ) OPTIONAL,
    extensionContainer [1] IMPLICIT SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId  ( {
                ...
                ... } ),
            extType      MAP-EXTENSION .&ExtensionType  ( {
                ...
                ... } { @extId   } ) OPTIONAL} OPTIONAL,
        pcs-Extensions [1] IMPLICIT SEQUENCE {
            ...
            ... } OPTIONAL,
            ...
        }
    }

ERRORS {
    -- systemFailure -- localValue : 34,
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- unknownSubscriber -- localValue : 1}
::= localValue : 25

noteMsPresentForGprs OPERATION
ARGUMENT
noteMsPresentForGprsArg SEQUENCE {
    imsi          [0] IMPLICIT OCTET STRING ( SIZE (3 .. 8) ),
    sgsn-Address [1] IMPLICIT OCTET STRING ( SIZE (5 .. 17) ),
    ggsn-Address [2] IMPLICIT OCTET STRING ( SIZE (5 .. 17) ) OPTIONAL,
    extensionContainer [3] IMPLICIT SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId  ( {
                ...
                ... } ),
            extType      MAP-EXTENSION .&ExtensionType  ( {
                ...
                ... } { @extId   } ) OPTIONAL} OPTIONAL,
        pcs-Extensions [1] IMPLICIT SEQUENCE {
            ...
            ... } OPTIONAL,
            ...
        }
    }

RESULT
noteMsPresentForGprsRes SEQUENCE {
    extensionContainer [0] IMPLICIT SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId  ( {
                ...
                ... } ),
            extType      MAP-EXTENSION .&ExtensionType  ( {
                ...
                ... } { @extId   } ) OPTIONAL} OPTIONAL,
        pcs-Extensions [1] IMPLICIT SEQUENCE {
            ...
            ... } OPTIONAL,
            ...
        }
    }

ERRORS {
    -- systemFailure -- localValue : 34,
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- unknownSubscriber -- localValue : 1}
::= localValue : 26

provideSubscriberLocation OPERATION
ARGUMENT
provideSubscriberLocation-Arg SEQUENCE {
    locationType      SEQUENCE {
        locationEstimateType [0] IMPLICIT ENUMERATED {
            currentLocation      (0),
            currentOrLastKnownLocation (1),

```

```

        initialLocation          (2),
        ... },
      . . . },
  mlc-Number          OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) ),
  lcs-ClientID        [0] IMPLICIT SEQUENCE {
    lcsClientType       [0] IMPLICIT ENUMERATED {
      emergencyServices (0),
      valueAddedServices (1),
      plmnOperatorServices (2),
      lawfulInterceptServices (3),
      ... },
    lcsClientExternalID [1] IMPLICIT SEQUENCE {
      externalAddress   [0] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) OPTIONAL,
      extensionContainer [1] IMPLICIT SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
          SEQUENCE {
            extId        MAP-EXTENSION .&extensionId ( {
              ' . . .
              ... } ) ,
            extType      MAP-EXTENSION .&ExtensionType ( {
              ' . . .
              ... } { @extId } ) OPTIONAL} OPTIONAL,
          pcs-Extensions [1] IMPLICIT SEQUENCE {
            ... } OPTIONAL,
            ... } OPTIONAL,
            ... } OPTIONAL,
            ... } OPTIONAL,
      lcsClientDialedByMS [2] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) OPTIONAL,
      lcsClientInternalID [3] IMPLICIT ENUMERATED {
        broadcastService (0),
        o-andM-HPLMN     (1),
        o-andM-VPLMN     (2),
        anonymousLocation (3),
        targetMSSubscribedService (4),
        ... } OPTIONAL,
        lcsClientName     [4] IMPLICIT SEQUENCE {
          dataCodingScheme [0] IMPLICIT OCTET STRING ( SIZE (1) ),
          nameString       [2] IMPLICIT OCTET STRING ( SIZE (1 .. 160) ) ( SIZE (1 .. 63)
        ),
        ... } OPTIONAL,
        ... } OPTIONAL,
      privacyOverride     [1] IMPLICIT NULL OPTIONAL,
      imsi                [2] IMPLICIT OCTET STRING ( SIZE (3 .. 8) ) OPTIONAL,
      msisdn             [3] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) )
OPTIONAL,
      lmsi                [4] IMPLICIT OCTET STRING ( SIZE (4) ) OPTIONAL,
      imei                [5] IMPLICIT OCTET STRING ( SIZE (8) ) OPTIONAL,
      lcs-Priority        [6] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
      lcs-QoS             [7] IMPLICIT SEQUENCE {
        horizontal-accuracy [0] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
        verticalCoordinateRequest [1] IMPLICIT NULL OPTIONAL,
        vertical-accuracy     [2] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
        responseTime         [3] IMPLICIT SEQUENCE {
          responseTimeCategory ENUMERATED {
            lowdelay        (0),
            delaytolerant   (1),
            ... },
            ... } OPTIONAL,
          extensionContainer [4] IMPLICIT SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
              SEQUENCE {
                extId        MAP-EXTENSION .&extensionId ( {
                  ' . . .
                  ... } ) ,
                extType      MAP-EXTENSION .&ExtensionType ( {
                  ' . . .
                  ... } { @extId } ) OPTIONAL} OPTIONAL,
              pcs-Extensions [1] IMPLICIT SEQUENCE {
                ... } OPTIONAL,
                ... } OPTIONAL,
                ... } OPTIONAL,
            extensionContainer [8] IMPLICIT SEQUENCE {
              privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                SEQUENCE {
                  extId        MAP-EXTENSION .&extensionId ( {
                    ' . . .
                    ... } ) ,
                  extType      MAP-EXTENSION .&ExtensionType ( {
                    ' . . .
                    ...
                  }
                }
              }
            }
          }
        }
      }
    }
  }
}

```

```

        ...} { @extId   } ) OPTIONAL} OPTIONAL,
    pcs-Extensions          [1] IMPLICIT SEQUENCE {
        ... } OPTIONAL,
        ... } OPTIONAL,
    ...
}

RESULT
provideSubscriberLocation-Res SEQUENCE {
    locationEstimate      OCTET STRING ( SIZE (1 .. 20) ),
    ageOfLocationEstimate [0] IMPLICIT INTEGER ( 0 .. 32767 ) OPTIONAL,
    extensionContainer     [1] IMPLICIT SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                    ...
                ) ,
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ...
                    ...} { @extId   } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ... } OPTIONAL,
                    ... } OPTIONAL,
                ...
            }
    }
ERRORS {
    -- systemFailure -- localValue : 34,
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- facilityNotSupported -- localValue : 21,
    -- unidentifiedSubscriber -- localValue : 5,
    -- illegalSubscriber -- localValue : 9,
    -- illegalEquipment -- localValue : 12,
    -- absentSubscriber -- localValue : 27,
    -- unauthorizedRequestingNetwork -- localValue : 52,
    -- unauthorizedLCSClient -- localValue : 53,
    -- positionMethodFailure -- localValue : 54}
::= localValue : 83

sendRoutingInfoForLCS OPERATION
ARGUMENT
routingInfoForLCS-Arg SEQUENCE {
    mlcNumber        [0] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) ),
    targetMS         [1] CHOICE {
        imsi           [0] IMPLICIT OCTET STRING ( SIZE (3 .. 8) ),
        msisdn         [1] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) )},
    extensionContainer [2] IMPLICIT SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                    ...
                ) ,
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ...
                    ...} { @extId   } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ... } OPTIONAL,
                    ... } OPTIONAL,
                ...
            }
    }
RESULT
routingInfoForLCS-Res SEQUENCE {
    targetMS         [0] CHOICE {
        imsi           [0] IMPLICIT OCTET STRING ( SIZE (3 .. 8) ),
        msisdn         [1] IMPLICIT OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) )},
    lcsLocationInfo  [1] IMPLICIT SEQUENCE {
        msc-Number      OCTET STRING ( SIZE (1 .. 20) ) ( SIZE (1 .. 9) ),
        lmsi             [0] IMPLICIT OCTET STRING ( SIZE (4) ) OPTIONAL,
        extensionContainer [1] IMPLICIT SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ...
                        ...
                    ) ,
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        ...
                        ...} { @extId   } ) OPTIONAL} OPTIONAL,
                    pcs-Extensions [1] IMPLICIT SEQUENCE {
                        ... } OPTIONAL,
                        ... } OPTIONAL,
                        ...
                    },
        extensionContainer [2] IMPLICIT SEQUENCE {
}

```

```

privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
    extId      MAP-EXTENSION .&extensionId ( {
        ,
        ...
    } ),
    extType     MAP-EXTENSION .&ExtensionType ( {
        ,
        ...
    } { @extId } ) OPTIONAL} OPTIONAL,
pcs-Extensions [1] IMPLICIT SEQUENCE {
    ...
} OPTIONAL,
...
}
... }

ERRORS {
-- systemFailure -- localValue : 34,
-- dataMissing -- localValue : 35,
-- unexpectedDataValue -- localValue : 36,
-- facilityNotSupported -- localValue : 21,
-- unknownSubscriber -- localValue : 1,
-- absentSubscriber -- localValue : 27,
-- unauthorizedRequestingNetwork -- localValue : 52}
::= localValue : 85

subscriberLocationReport OPERATION
ARGUMENT
subscriberLocationReport-Arg SEQUENCE {
    lcs-Event          ENUMERATED {
        emergencyCallOrigination (0),
        emergencyCallRelease (1),
        mo-lr (2),
        ...
    },
    lcs-ClientID       SEQUENCE {
        lcsClientType [0] IMPLICIT ENUMERATED {
            emergencyServices (0),
            valueAddedServices (1),
            plmnOperatorServices (2),
            lawfulInterceptServices (3),
            ...
        },
        lcsClientExternalID [1] IMPLICIT SEQUENCE {
            externalAddress [0] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) OPTIONAL,
            extensionContainer [1] IMPLICIT SEQUENCE {
                privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ,
                        ...
                    } ),
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        ,
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ...
} OPTIONAL,
                    ...
} OPTIONAL,
                    ...
} OPTIONAL,
            lcsClientDialedByMS [2] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) OPTIONAL,
            lcsClientInternalID [3] IMPLICIT ENUMERATED {
                broadcastService (0),
                o-andM-HPLMN (1),
                o-andM-VPLMN (2),
                anonymousLocation (3),
                targetMSSubscribedService (4),
                ...
} OPTIONAL,
            lcsClientName [4] IMPLICIT SEQUENCE {
                dataCodingScheme [0] IMPLICIT OCTET STRING ( SIZE (1 ) ),
                nameString [2] IMPLICIT OCTET STRING ( SIZE (1 .. 160 ) ) ( SIZE (1 .. 63 ) ),
                ...
} OPTIONAL,
            ...
},
            lcsLocationInfo SEQUENCE {
                msc-Number OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 .. 9 ) ),
                lmsi [0] IMPLICIT OCTET STRING ( SIZE (4 ) ) OPTIONAL,
                extensionContainer [1] IMPLICIT SEQUENCE {
                    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ,
                        ...
                    } ),
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        ,
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
                }
            }
        }
    }
}

```

```

        pcs-Extensions      [1] IMPLICIT SEQUENCE {
            ... } OPTIONAL,
            ... } OPTIONAL,
            ... },
        msisdn           [0] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 .. 9 ) )
OPTIONAL,
        imsi             [1] IMPLICIT OCTET STRING ( SIZE (3 .. 8 ) ) OPTIONAL,
        imei             [2] IMPLICIT OCTET STRING ( SIZE (8 ) ) OPTIONAL,
        na-ESRD          [3] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 .. 9 ) )
OPTIONAL,
        na-ESRK          [4] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) ( SIZE (1 .. 9 ) )
OPTIONAL,
        locationEstimate [5] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) OPTIONAL,
        ageOfLocationEstimate [6] IMPLICIT INTEGER ( 0 .. 32767 ) OPTIONAL,
        extensionContainer [7] IMPLICIT SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ,
                        ...
                    } ),
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        ,
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ... } OPTIONAL,
                ... } OPTIONAL,
            ...
        }
RESULT
    subscriberLocationReport-Res SEQUENCE {
        extensionContainer SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ,
                        ...
                    } ),
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        ,
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ... } OPTIONAL,
                ... } OPTIONAL,
            ...
        }
    }
ERRORS {
    -- systemFailure -- localValue : 34,
    -- dataMissing -- localValue : 35,
    -- unexpectedDataValue -- localValue : 36,
    -- resourceLimitation -- localValue : 51,
    -- unknownSubscriber -- localValue : 1,
    -- unauthorizedRequestingNetwork -- localValue : 52,
    -- unknownOrUnreachableLCSClient -- localValue : 58}
::= localValue : 86

systemFailure ERROR
PARAMETER
    systemFailureParam CHOICE {
        networkResource          ENUMERATED {
            plmn              (0 ),
            hlr               (1 ),
            vlr               (2 ),
            pvlr              (3 ),
            controllingMSC   (4 ),
            vmsc              (5 ),
            eir               (6 ),
            rss               (7 )},
        extensibleSystemFailureParam SEQUENCE {
            networkResource    ENUMERATED {
                plmn          (0 ),
                hlr           (1 ),
                vlr           (2 ),
                pvlr          (3 ),
                controllingMSC (4 ),
                vmsc          (5 ),
                eir           (6 ),
                rss            (7 )} OPTIONAL,
            extensionContainer SEQUENCE {
                privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                    SEQUENCE {
                        extId      MAP-EXTENSION .&extensionId ( {
                            ,
                            ...
                        } ),
                        extType     MAP-EXTENSION .&ExtensionType ( {
                            ,
                            ...
                        } { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ... } OPTIONAL,
                    ... } OPTIONAL,
                ...
            }
        }
    }

```

```

        ...
    extType      MAP-EXTENSION .&ExtensionType  ( {
        ...
        ... } { @extId   } )  OPTIONAL} OPTIONAL,
    pcs-Extensions          [1] IMPLICIT SEQUENCE {
        ...
        ... } OPTIONAL,
        ...
    ...
}
::= localValue : 34

dataMissing ERROR
PARAMETER
dataMissingParam SEQUENCE {
    extensionContainer  SEQUENCE {
        privateExtensionList  [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId  ( {
                    ...
                    ... } ) ,
                extType      MAP-EXTENSION .&ExtensionType  ( {
                    ...
                    ... } { @extId   } )  OPTIONAL} OPTIONAL,
                ...
            pcs-Extensions          [1] IMPLICIT SEQUENCE {
                ...
                ... } OPTIONAL,
                ...
            ...
}
::= localValue : 35

unexpectedDataValue ERROR
PARAMETER
unexpectedDataParam SEQUENCE {
    extensionContainer  SEQUENCE {
        privateExtensionList  [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId  ( {
                    ...
                    ... } ) ,
                extType      MAP-EXTENSION .&ExtensionType  ( {
                    ...
                    ... } { @extId   } )  OPTIONAL} OPTIONAL,
                ...
            pcs-Extensions          [1] IMPLICIT SEQUENCE {
                ...
                ... } OPTIONAL,
                ...
            ...
}
::= localValue : 36

facilityNotSupported ERROR
PARAMETER
facilityNotSupParam SEQUENCE {
    extensionContainer  SEQUENCE {
        privateExtensionList  [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId  ( {
                    ...
                    ... } ) ,
                extType      MAP-EXTENSION .&ExtensionType  ( {
                    ...
                    ... } { @extId   } )  OPTIONAL} OPTIONAL,
                ...
            pcs-Extensions          [1] IMPLICIT SEQUENCE {
                ...
                ... } OPTIONAL,
                ...
            ...
}
::= localValue : 21

incompatibleTerminal ERROR
PARAMETER
incompatibleTerminalParam SEQUENCE {
    extensionContainer  SEQUENCE {
        privateExtensionList  [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId  ( {
                    ...
                    ... } ) ,
                extType      MAP-EXTENSION .&ExtensionType  ( {
                    ...
                    ... } { @extId   } )  OPTIONAL} OPTIONAL,
                ...
            pcs-Extensions          [1] IMPLICIT SEQUENCE {
                ...
                ...
            ...
}

```

```

        ... } OPTIONAL,
        ... } OPTIONAL,
    ...
 ::= localValue : 28

resourceLimitation ERROR
PARAMETER
resourceLimitationParam SEQUENCE {
    extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                },
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ...
                } OPTIONAL,
                ...
            }
        ...
    }
 ::= localValue : 51

unknownSubscriber ERROR
PARAMETER
unknownSubscriberParam SEQUENCE {
    extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                },
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ...
                } OPTIONAL,
                ...
            }
        ...
        unknownSubscriberDiagnostic ENUMERATED {
            imsiUnknown      (0),
            gprsSubscriptionUnknown (1),
            ...
        } OPTIONAL}
    ...
}
 ::= localValue : 1

numberChanged ERROR
PARAMETER
numberChangedParam SEQUENCE {
    extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                },
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ...
                } OPTIONAL,
                ...
            }
        ...
}
 ::= localValue : 44

unknownMSC ERROR
 ::= localValue : 3

unidentifiedSubscriber ERROR
PARAMETER
unidentifiedSubParam SEQUENCE {
    extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                },
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
                ...
            }
        ...
}

```

```

    pcs-Extensions      [1] IMPLICIT SEQUENCE {
        ...
    } OPTIONAL,
    ...
}
 ::= localValue : 5

unknownEquipment ERROR
 ::= localValue : 7

roamingNotAllowed ERROR
PARAMETER
roamingNotAllowedParam SEQUENCE {
    roamingNotAllowedCause ENUMERATED {
        plmnRoamingNotAllowed      (0),
        operatorDeterminedBarring (3)},
    extensionContainer   SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ...
            },
            extType     MAP-EXTENSION .&ExtensionType ( {
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
        pcs-Extensions [1] IMPLICIT SEQUENCE {
            ...
        } OPTIONAL,
        ...
    }
}
 ::= localValue : 8

illegalSubscriber ERROR
PARAMETER
illegalSubscriberParam SEQUENCE {
    extensionContainer   SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ...
            },
            extType     MAP-EXTENSION .&ExtensionType ( {
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
        pcs-Extensions [1] IMPLICIT SEQUENCE {
            ...
        } OPTIONAL,
        ...
    }
}
 ::= localValue : 9

illegalEquipment ERROR
PARAMETER
illegalEquipmentParam SEQUENCE {
    extensionContainer   SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ...
            },
            extType     MAP-EXTENSION .&ExtensionType ( {
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
        pcs-Extensions [1] IMPLICIT SEQUENCE {
            ...
        } OPTIONAL,
        ...
    }
}
 ::= localValue : 12

bearerServiceNotProvisioned ERROR
PARAMETER
bearerServNotProvParam SEQUENCE {
    extensionContainer   SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ...
            },
            extType     MAP-EXTENSION .&ExtensionType ( {
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
        ...
    }
}

```

```

    pcs-Extensions      [1] IMPLICIT SEQUENCE {
        ... } OPTIONAL,
        ... } OPTIONAL,
        ...
    ::= localValue : 10

teleserviceNotProvisioned ERROR
PARAMETER
    teleservNotProvParam SEQUENCE {
        extensionContainer   SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ...
                    } ),
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions      [1] IMPLICIT SEQUENCE {
                ... } OPTIONAL,
                ... } OPTIONAL,
                ...
        }
    ::= localValue : 11

noHandoverNumberAvailable ERROR
 ::= localValue : 25

subsequentHandoverFailure ERROR
 ::= localValue : 26

tracingBufferFull ERROR
PARAMETER
    tracingBufferFullParam SEQUENCE {
        extensionContainer   SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ...
                    } ),
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions      [1] IMPLICIT SEQUENCE {
                ... } OPTIONAL,
                ... } OPTIONAL,
                ...
        }
    ::= localValue : 40

noRoamingNumberAvailable ERROR
PARAMETER
    noRoamingNbParam SEQUENCE {
        extensionContainer   SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ...
                    } ),
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions      [1] IMPLICIT SEQUENCE {
                ... } OPTIONAL,
                ... } OPTIONAL,
                ...
        }
    ::= localValue : 39

absentSubscriber ERROR
PARAMETER
    absentSubscriberParam SEQUENCE {
        extensionContainer   SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ...
                    } ),
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
                    ...
                }
            }
        }
    }

```

```

    pcs-Extensions      [1] IMPLICIT SEQUENCE {
        ...
    } OPTIONAL,
    ...
}

absentSubscriberReason [0] IMPLICIT ENUMERATED {
    imsiDetach          (0),
    restrictedArea       (1),
    noPageResponse      (2),
    ...
} OPTIONAL
 ::= localValue : 27

busySubscriber ERROR
PARAMETER
busySubscriberParam SEQUENCE {
    extensionContainer   SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                },
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        }
    ...
    ccbs-Possible      [0] IMPLICIT NULL OPTIONAL,
    ccbs-Busy         [1] IMPLICIT NULL OPTIONAL}
 ::= localValue : 45

noSubscriberReply ERROR
PARAMETER
noSubscriberReplyParam SEQUENCE {
    extensionContainer   SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                },
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        }
    ...
}
 ::= localValue : 46

callBarred ERROR
PARAMETER
callBarredParam CHOICE {
    callBarringCause           ENUMERATED {
        barringServiceActive (0),
        operatorBarring        (1)},
    extensibleCallBarredParam SEQUENCE {
        callBarringCause           ENUMERATED {
            barringServiceActive (0),
            operatorBarring        (1)} OPTIONAL,
        extensionContainer        SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ...
                    },
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        }
    ...
    unauthorisedMessageOriginator [1] IMPLICIT NULL OPTIONAL}}
 ::= localValue : 13

forwardingFailed ERROR
PARAMETER
forwardingFailedParam SEQUENCE {

```

```

extensionContainer SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ...
            } ),
            extType     MAP-EXTENSION .&ExtensionType ( {
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        }
    ...
}
 ::= localValue : 47

or-NotAllowed ERROR
PARAMETER
or-NotAllowedParam SEQUENCE {
    extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                } ),
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ...
                } OPTIONAL,
                ...
            }
        ...
}
 ::= localValue : 48

forwardingViolation ERROR
PARAMETER
forwardingViolationParam SEQUENCE {
    extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                } ),
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ...
                } OPTIONAL,
                ...
            }
        ...
}
 ::= localValue : 14

cug-Reject ERROR
PARAMETER
cug-RejectParam SEQUENCE {
    cug-RejectCause ENUMERATED {
        incomingCallsBarredWithinCUG (0),
        subscriberNotMemberOfCUG (1),
        requestedBasicServiceViolatesCUG-Constraints (5),
        calledPartySS-InteractionViolation (7) } OPTIONAL,
    extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                } ),
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ...
                } OPTIONAL,
                ...
            }
        ...
}
 ::= localValue : 15

ati-NotAllowed ERROR
PARAMETER
ati-NotAllowedParam SEQUENCE {
    extensionContainer SEQUENCE {

```

```

privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
    extId      MAP-EXTENSION .&extensionId ( {
        ...
    } ),
    extType     MAP-EXTENSION .&ExtensionType ( {
        ...
    } { @extId } ) OPTIONAL} OPTIONAL,
    pcs-Extensions [1] IMPLICIT SEQUENCE {
        ...
    } OPTIONAL,
    ...
}
...
}
::= localValue : 49

noGroupCallNumberAvailable ERROR
PARAMETER
noGroupCallNbParam SEQUENCE {
    extensionContainer SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ...
            } ),
            extType     MAP-EXTENSION .&ExtensionType ( {
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        }
    }
}
::= localValue : 50

illegalSS-Operation ERROR
::= localValue : 16

ss-ErrorStatus ERROR
PARAMETER
ss-Status OCTET STRING ( SIZE (1) )
::= localValue : 17

ss-NotAvailable ERROR
::= localValue : 18

ss-SubscriptionViolation ERROR
::= localValue : 19

ss-Incompatibility ERROR
PARAMETER
ss-IncompatibilityCause SEQUENCE {
    ss-Code      [1] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
    basicService CHOICE {
        bearerService [2] IMPLICIT OCTET STRING ( SIZE (1) ),
        teleservice  [3] IMPLICIT OCTET STRING ( SIZE (1) ) } OPTIONAL,
        ss-Status    [4] IMPLICIT OCTET STRING ( SIZE (1) ) OPTIONAL,
        ...
    }
}
::= localValue : 20

unknownAlphabet ERROR
::= localValue : 71

ussd-Busy ERROR
::= localValue : 72

pw-RegistrationFailure ERROR
PARAMETER
pw-RegistrationFailureCause ENUMERATED {
    undetermined (0),
    invalidFormat (1),
    newPasswordsMismatch (2)
}
::= localValue : 37

negativePW-Check ERROR
::= localValue : 38

numberOfPW-AttemptsViolation ERROR
::= localValue : 43

shortTermDenial ERROR

```

```

PARAMETER
    shortTermDenialParam SEQUENCE {
        ...
    }
::= localValue : 29

longTermDenial ERROR
PARAMETER
    longTermDenialParam SEQUENCE {
        ...
    }
::= localValue : 30

subscriberBusyForMT-SMS ERROR
PARAMETER
    subBusyForMT-SMS-Param SEQUENCE {
        extensionContainer      SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ,
                        ...
                    } ,
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        ,
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
                    pcs-Extensions [1] IMPLICIT SEQUENCE {
                        ...
                    } OPTIONAL,
                    ...
                } OPTIONAL,
                ...
            gprsConnectionSuspended NULL OPTIONAL}
::= localValue : 31

sm-DeliveryFailure ERROR
PARAMETER
    sm-DeliveryFailureCause SEQUENCE {
        sm-EnumeratedDeliveryFailureCause ENUMERATED {
            memoryCapacityExceeded (0),
            equipmentProtocolError (1),
            equipmentNotSM-Equipped (2),
            unknownServiceCentre (3),
            sc-Congestion (4),
            invalidSME-Address (5),
            subscriberNotSC-Subscriber (6)},
        diagnosticInfo          OCTET STRING ( SIZE (1 .. 200) ) OPTIONAL,
        extensionContainer      SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ,
                        ...
                    } ,
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        ,
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
                    pcs-Extensions [1] IMPLICIT SEQUENCE {
                        ...
                    } OPTIONAL,
                    ...
                } OPTIONAL,
                ...
            } }
::= localValue : 32

messageWaitingListFull ERROR
PARAMETER
    messageWaitListFullParam SEQUENCE {
        extensionContainer SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ,
                        ...
                    } ,
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        ,
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
                    pcs-Extensions [1] IMPLICIT SEQUENCE {
                        ...
                    } OPTIONAL,
                    ...
                } }
::= localValue : 33

absentSubscriberSM ERROR
PARAMETER
    absentSubscriberSM-Param SEQUENCE {

```

```

absentSubscriberDiagnosticSM           INTEGER ( 0 .. 255 ) OPTIONAL,
extensionContainer                   SEQUENCE {
    privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ...
            } ),
            extType     MAP-EXTENSION .&ExtensionType ( {
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
    pcs-Extensions [1] IMPLICIT SEQUENCE {
        ...
    } OPTIONAL,
    ...
}
...
additionalAbsentSubscriberDiagnosticSM [0] IMPLICIT INTEGER ( 0 .. 255 ) OPTIONAL}
 ::= localValue : 6

unauthorizedRequestingNetwork ERROR
PARAMETER
    unauthorizedRequestingNetwork-Param SEQUENCE {
        extensionContainer SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ...
                    } ),
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ...
                } OPTIONAL,
                ...
            }
}
 ::= localValue : 52

unauthorizedLCSCClient ERROR
PARAMETER
    unauthorizedLCSCClient-Param SEQUENCE {
        unauthorizedLCSCClient-Diagnostic [0] IMPLICIT ENUMERATED {
            noAdditionalInformation          (0),
            clientNotInMSPrivacyExceptionList (1),
            callToClientNotSetup             (2),
            privacyOverrideNotApplicable     (3),
            disallowedByLocalRegulatoryRequirements (4),
            ...
        } OPTIONAL,
        extensionContainer [1] IMPLICIT SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ...
                    } ),
                    extType     MAP-EXTENSION .&ExtensionType ( {
                        ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ...
                } OPTIONAL,
                ...
            }
}
 ::= localValue : 53

positionMethodFailure ERROR
PARAMETER
    positionMethodFailure-Param SEQUENCE {
        positionMethodFailure-Diagnostic [0] IMPLICIT ENUMERATED {
            congestion                      (0),
            insufficientResources            (1),
            insufficientMeasurementData     (2),
            inconsistentMeasurementData    (3),
            locationProcedureNotCompleted   (4),
            locationProcedureNotSupportedByTargetMS (5),
            qosNotAttainable               (6),
            positionMethodNotAvailableInNetwork (7),
            positionMethodNotAvailableInLocationArea (8),
            ...
        } OPTIONAL,
        extensionContainer [1] IMPLICIT SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
                SEQUENCE {
                    extId      MAP-EXTENSION .&extensionId ( {
                        ...
                    } ),
                    ...
                }
}

```

```
'  
...} ) ,  
extType    MAP-EXTENSION .&ExtensionType  ( {  
'...} { @extId   } ) OPTIONAL} OPTIONAL,  
pcs-Extensions [1] IMPLICIT SEQUENCE {  
... } OPTIONAL,  
... } OPTIONAL,  
... }  
 ::= localValue : 54  
  
unknownOrUnreachableLCSClient ERROR  
PARAMETER  
unknownOrUnreachableLCSClient-Param SEQUENCE {  
extensionContainer  SEQUENCE {  
privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF  
SEQUENCE {  
extId    MAP-EXTENSION .&extensionId  ( {  
'...} ) ,  
extType    MAP-EXTENSION .&ExtensionType  ( {  
'...} { @extId   } ) OPTIONAL} OPTIONAL,  
pcs-Extensions [1] IMPLICIT SEQUENCE {  
... } OPTIONAL,  
... } OPTIONAL,  
... }  
 ::= localValue : 58  
  
END
```

B.2 Fully Expanded ASN.1 Source of MAP-DialogueInformation

```
-- Expanded ASN1 Module 'MAP-DialogueInformation'
--SIEMENS ASN.1 Compiler      R4.81 (48-00-02)
-- Date: 2000-07-19 Time: 08:07:28

MAP-DialogueInformation{ 0 identified-organization (4) etsi (0) mobileDomain (0) gsm-Network (1)
modules (3) map-DialogueInformation (3) version5 (5) }

DEFINITIONS ::=

BEGIN

EXPORTS
map-DialogueAS,
MAP-DialoguePDU;

map-DialogueAS OBJECT IDENTIFIER ::= { ccitt (0) identified-organization (4) etsi (0) mobileDomain
(0) gsm-Network (1) 1 map-DialoguePDU (1) version1 (1) }

MAP-DialoguePDU ::= CHOICE {
map-open          [0] IMPLICIT SEQUENCE {
    destinationReference [0] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) OPTIONAL,
    originationReference [1] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) OPTIONAL,
    ... ,
    extensionContainer   SEQUENCE {
        privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ...
                ...
            } ),
            extType     MAP-EXTENSION .&ExtensionType ( {
                ...
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        } OPTIONAL},
    map-accept       [1] IMPLICIT SEQUENCE {
        ...
        extensionContainer SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                    ...
                } ),
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ...
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ...
                } OPTIONAL,
                ...
            } OPTIONAL},
    map-close        [2] IMPLICIT SEQUENCE {
        ...
        extensionContainer SEQUENCE {
            privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                    ...
                } ),
                extType     MAP-EXTENSION .&ExtensionType ( {
                    ...
                    ...
                } { @extId } ) OPTIONAL} OPTIONAL,
                pcs-Extensions [1] IMPLICIT SEQUENCE {
                    ...
                } OPTIONAL,
                ...
            } OPTIONAL},
    map-refuse       [3] IMPLICIT SEQUENCE {
        reason      ENUMERATED {
            noReasonGiven           (0 ),
            invalidDestinationReference (1 ),
            ...
        }
    }
}
```

```

    invalidOriginatingReference      (2 )},
...
extensionContainer      SEQUENCE {
    privateExtensionList      [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ...
            } ),
            extType     MAP-EXTENSION .&ExtensionType ( {
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions      [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        } OPTIONAL},
map-userAbort          [4] IMPLICIT SEQUENCE {
    map-UserAbortChoice   CHOICE {
        userSpecificReason           [0] IMPLICIT NULL,
        userResourceLimitation       [1] IMPLICIT NULL,
        resourceUnavailable         [2] IMPLICIT ENUMERATED {
            shortTermResourceLimitation (0 ),
            longTermResourceLimitation (1 )},
        applicationProcedureCancellation [3] IMPLICIT ENUMERATED {
            handoverCancellation      (0 ),
            radioChannelRelease        (1 ),
            networkPathRelease         (2 ),
            callRelease                (3 ),
            associatedProcedureFailure (4 ),
            tandemDialogueRelease      (5 ),
            remoteOperationsFailure    (6 )}},
...
extensionContainer      SEQUENCE {
    privateExtensionList      [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ...
            } ),
            extType     MAP-EXTENSION .&ExtensionType ( {
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions      [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        } OPTIONAL},
map-providerAbort       [5] IMPLICIT SEQUENCE {
    map-ProviderAbortReason  ENUMERATED {
        abnormalDialogue      (0 ),
        invalidPDU              (1 )},
...
extensionContainer      SEQUENCE {
    privateExtensionList      [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ...
            } ),
            extType     MAP-EXTENSION .&ExtensionType ( {
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions      [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        } OPTIONAL}}}

MAP-OpenInfo ::= SEQUENCE {
    destinationReference  [0] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) OPTIONAL,
    originationReference [1] IMPLICIT OCTET STRING ( SIZE (1 .. 20 ) ) OPTIONAL,
...
extensionContainer      SEQUENCE {
    privateExtensionList      [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
        SEQUENCE {
            extId      MAP-EXTENSION .&extensionId ( {
                ...
            } ),
            extType     MAP-EXTENSION .&ExtensionType ( {
                ...
            } { @extId } ) OPTIONAL} OPTIONAL,
            pcs-Extensions      [1] IMPLICIT SEQUENCE {
                ...
            } OPTIONAL,
            ...
        } OPTIONAL}}}

MAP-AcceptInfo ::= SEQUENCE {

```

```

    ...
extensionContainer SEQUENCE {
  privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
    SEQUENCE {
      extId      MAP-EXTENSION .&extensionId ( {
        ...
      } ),
      extType     MAP-EXTENSION .&ExtensionType ( {
        ...
      } { @extId } ) OPTIONAL} OPTIONAL,
  pcs-Extensions [1] IMPLICIT SEQUENCE {
    ...
  } OPTIONAL,
  ...
} OPTIONAL

MAP-CloseInfo ::= SEQUENCE {
  ...
extensionContainer SEQUENCE {
  privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
    SEQUENCE {
      extId      MAP-EXTENSION .&extensionId ( {
        ...
      } ),
      extType     MAP-EXTENSION .&ExtensionType ( {
        ...
      } { @extId } ) OPTIONAL} OPTIONAL,
  pcs-Extensions [1] IMPLICIT SEQUENCE {
    ...
  } OPTIONAL,
  ...
} OPTIONAL

MAP-RefuseInfo ::= SEQUENCE {
  reason          ENUMERATED {
    noReasonGiven      (0),
    invalidDestinationReference (1),
    invalidOriginatingReference (2)},
  ...
extensionContainer SEQUENCE {
  privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
    SEQUENCE {
      extId      MAP-EXTENSION .&extensionId ( {
        ...
      } ),
      extType     MAP-EXTENSION .&ExtensionType ( {
        ...
      } { @extId } ) OPTIONAL} OPTIONAL,
  pcs-Extensions [1] IMPLICIT SEQUENCE {
    ...
  } OPTIONAL,
  ...
} OPTIONAL

Reason ::= ENUMERATED {
  noReasonGiven      (0),
  invalidDestinationReference (1),
  invalidOriginatingReference (2)}

MAP-UserAbortInfo ::= SEQUENCE {
  map-UserAbortChoice CHOICE {
    userSpecificReason           [0] IMPLICIT NULL,
    userResourceLimitation       [1] IMPLICIT NULL,
    resourceUnavailable          [2] IMPLICIT ENUMERATED {
      shortTermResourceLimitation (0),
      longTermResourceLimitation (1)},
    applicationProcedureCancellation [3] IMPLICIT ENUMERATED {
      handoverCancellation (0),
      radioChannelRelease (1),
      networkPathRelease (2),
      callRelease (3),
      associatedProcedureFailure (4),
      tandemDialogueRelease (5),
      remoteOperationsFailure (6)}},
  ...
extensionContainer SEQUENCE {
  privateExtensionList [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
    SEQUENCE {
      extId      MAP-EXTENSION .&extensionId ( {
        ...
      } ),
      extType     MAP-EXTENSION .&ExtensionType ( {
        ...
      } { @extId } ) OPTIONAL} OPTIONAL,
}

```

```

    pcs-Extensions      [1] IMPLICIT SEQUENCE {
        ... } OPTIONAL,
        ... } OPTIONAL}

MAP-UserAbortChoice ::= CHOICE {
    userSpecificReason          [0] IMPLICIT NULL,
    userResourceLimitation      [1] IMPLICIT NULL,
    resourceUnavailable         [2] IMPLICIT ENUMERATED {
        shortTermResourceLimitation (0 ),
        longTermResourceLimitation (1 )},
    applicationProcedureCancellation [3] IMPLICIT ENUMERATED {
        handoverCancellation      (0 ),
        radioChannelRelease        (1 ),
        networkPathRelease         (2 ),
        callRelease                (3 ),
        associatedProcedureFailure (4 ),
        tandemDialogueRelease     (5 ),
        remoteOperationsFailure   (6 )} }

ResourceUnavailableReason ::= ENUMERATED {
    shortTermResourceLimitation (0 ),
    longTermResourceLimitation (1 ) }

ProcedureCancellationReason ::= ENUMERATED {
    handoverCancellation      (0 ),
    radioChannelRelease        (1 ),
    networkPathRelease         (2 ),
    callRelease                (3 ),
    associatedProcedureFailure (4 ),
    tandemDialogueRelease     (5 ),
    remoteOperationsFailure   (6 ) }

MAP-ProviderAbortInfo ::= SEQUENCE {
    map-ProviderAbortReason   ENUMERATED {
        abnormalDialogue      (0 ),
        invalidPDU             (1 )},
    ...
    extensionContainer        SEQUENCE {
        privateExtensionList  [0] IMPLICIT SEQUENCE ( SIZE (1 .. 10 ) ) OF
            SEQUENCE {
                extId      MAP-EXTENSION .&extensionId ( {
                    ...
                    } ),
                extType    MAP-EXTENSION .&ExtensionType ( {
                    ...
                    } { @extId } ) OPTIONAL} OPTIONAL,
        pcs-Extensions        [1] IMPLICIT SEQUENCE {
            ... } OPTIONAL,
            ... } OPTIONAL}

MAP-ProviderAbortReason ::= ENUMERATED {
    abnormalDialogue      (0 ),
    invalidPDU             (1 )}

END

```

Annex C :
Void

Annex D (informative): Clause mapping table

D.1 Mapping of Clause numbers

The clause numbers have been modified according to table D.1.

Table D.1: Clause mapping from Version 5.9.0 to Version 6.0.0

Old Clause No (V5.9.0)	New Clause No (V6.0.0)	Old Clause No (V5.9.0)	New Clause No (V6.0.0)
1.1	2	17.*	20.*
1.2	3	18.*	21.*
2.*	4.*	19.*	22.*
3.*	5.*	19.0.*	22.1.*
4.*	6.*	19.1.*	22.2.*
5.*	7.*	19.2.*	22.3.*
6.*	8.*	19.3.*	22.4.*
7.*	9.*	19.4.*	22.5.*
8.*	10.*	19.5.*	22.6.*
9.*	11.*	19.6.*	22.7.*
10.*	12.*	19.7.*	22.8.*
new11.*	13.*	19.8.*	22.9.*
old11.*	14.*	19.9.*	22.10.*
12.*	15.*	19.10.*	22.11.*
13.*	16.*	19.11.*	22.12.*
14.*	17.*	20.*	23.*
15.*	18.*	new22.*	24.*
16.*	19.*	old21.*	25.*

Annex E (informative): Change History

SMG#	TDoc	SPEC	VERS	CR	R E V	PHASE	C A T	SUBJECT	NEW_ VERS	WORKITEM
s22	372/97	09.02	5.9.0	A087		R97	B	Allocation of an SS-code for the Calling Name Presentation SS. {based on 5.5.0}	6.0.0d1 .0	CNAP R97
s23	97-689	09.02	5.9.0	A095	1	R97	B	Support of NAEA {based on 5.6.0}	6.0.0d1 .0	NAEA
s24	97-971	09.02	5.9.0	A084	3	R97	B	Network's indication of alerting {based on 5.7.0}	6.0.0d1 .0	NIAlerting in MS
s24	97-989	09.02	5.9.0	A094	2	R97	B	Modifications due to ASCI phase 2 {based on 5.7.0}	6.0.0d1 .0	ASCI R97
s24	97-912	09.02	5.9.0	A103	6	R97	B	Introduction of SIWFS {based on 5.7.0}	6.0.0d1 .0	SIWF
s25	98-0093	09.02	5.9.0	A105	9	R97	B	MAP changes for GPRS	6.0.0	GPRS
s25	98-0152	09.02	5.9.0	A109		R97	B	SMS Screening	6.0.0	SMS Enh.: Filtering
s25	98-0083	09.02	5.9.0	A111	4	R97	B	CAMEL phase 2	6.0.0	CAMEL R97
s25	98-0088	09.02	5.9.0	A114		R97	B	Introduction of description of VBS/VGSC Relay MSC in ASCI R97	6.0.0	ASCI R97
s25	98-0085	09.02	5.9.0	A115	1	R97	C	Introduction of Alerting categories	6.0.0	CAMEL R97, NetworkIA
s26	98-0413	09.02	6.0.0	A104	1	R97	F	SMS interworking with GPRS	6.1.0	
s26	98-0413	09.02	6.0.0	A123	2	R97	C	Subscription withdrawn from SGSN	6.1.0	
s26	98-0413	09.02	6.0.0	A124		R97	F	SMS interworking with GPRS	6.1.0	
s26	98-0413	09.02	6.0.0	A124	2	R97	C	Modification of Insert Subscriber Data and Delete Subscriber Data Procedures for GPRS	6.1.0	
s26	98-0413	09.02	6.0.0	A130	1	R97	C	Network access mode in the Insert-Subscriber-data to SGSN and VLR	6.1.0	
s26	98-0408	09.02	6.0.0	A120		R97	C	Modification of CUG-Info	6.1.0	
s26	98-0411	09.02	6.0.0	A113	2	R97	C	Support of CAMEL Phase 2	6.1.0	
s26	98-0407	09.02	6.0.0	A127	2	R97	A	Queuing of short messages at the VMSC and SGSN	6.1.0	
s26	98-0355	09.02	6.0.0	A097	8	R97	B	MAP impacts for CCBS	6.1.0	
s27		09.02	6.1.1	A136		R97	F	Correction to the Status Reporting procedure	6.2.0	
s27		09.02	6.1.1	A138		R97	F	Extending the applicability of GMSC Address in ProvideRoamingNumber	6.2.0	
s27		09.02	6.1.1	A140		R97	F	Minor corrections to SMS over GPRS	6.2.0	
s27		09.02	6.1.1	A129	1	R97	A	E.214 addressing of the HLR	6.2.0	
s27		09.02	6.1.1	A132	1	R97	F	09.02 Corrections	6.2.0	
s27		09.02	6.1.1	A133	1	R97	F	Clarification on applicability of application contexts	6.2.0	
s27		09.02	6.1.1	A139	2	R97	D	Clarification of GSM 09.02 when the SMS over GPRS functionality is not supported by SMS-GMSC.	6.2.0	
s27		09.02	6.1.1	A147	1	R97	F	Correction to the Status Reporting process in the VLR	6.2.0	
s27		09.02	6.1.1	A149		R97	F	Clarification of limit on length of O-CSI in MAP_RESUME_CALL-HANDLING	6.2.0	
s27		09.02	6.1.1	A152	1	R97	C	Support of CAMEL Phase 2	6.2.0	
s27		09.02	6.1.1	A151		R97	F	Removal of CCBS-feature from SS-Data	6.2.0	
s27		09.02	6.1.1	A158	1	R97	F	Restricting the use of extension containers in RegisterCCEEntry and Erase CCEEntry user errors	6.2.0	
s27		09.02	6.1.1	A153	1	R97	F	Correction in overload control tables for GPRS operations applicability	6.2.0	
s27		09.02	6.1.1	A154		R97	F	Usage of ShortMsgRelayPackage-v2 in GPRS	6.2.0	
s27		09.02	6.1.1	A150	1	R97	F	ASN.1 corrections	6.2.0	
s28		09.02	6.2.0	A159		R97	F	ASN.1 corrections	6.3.0	
s28		09.02	6.2.0	A161	1	R97	C	Clarification on the use of SCCP addresses in response	6.3.0	
s28		09.02	6.2.0	A162		R97	C	Removal of unused ST parameters	6.3.0	
s28		09.02	6.2.0	A164	1	R97	A	Use of SCCP Class 1	6.3.0	
s28		09.02	6.2.0	A167	1	R97	A	Corrections and updating of the 09.02	6.3.0	
s28		09.02	6.2.0	A170		R97	A	Optionality of sm-RP-UI in MO-ForwardSM-Res	6.3.0	

SMG#	TDoc	SPEC	VERS	CR	R E V	PHASE	C A T	SUBJECT	NEW_ VERS	WORKITEM
s28		09.02	6.2.0	A171	2	R97	F	Inclusion of "Check Indication" macro in GPRS SDLs	6.3.0	
s28		09.02	6.2.0	A172		R97	D	Editorial corrections of the GPRS enhancement of MAP	6.3.0	
s28		09.02	6.2.0	A173	1	R97	F	Alignment of the Failure Report-Arg message with GS	6.3.0	
s28		09.02	6.2.0	A174		R97	F	Correction on ODB applicability for GPRS ph 1	6.3.0	
s28		09.02	6.2.0	A179	1	R97	F	Alignment of the GSN-Address GSM 09.02 ASN.1 def	6.3.0	
s28		09.02	6.2.0	A180		R97	F	Applicability of SS Binding package	6.3.0	
s28		09.02	6.2.0	A181		R97	F	Definition of DestinationNumberLength	6.3.0	
s28		09.02	6.2.0	A185		R97	F	Clarification for MNRR	6.3.0	
s28		09.02	6.2.0	A188	1	R97	F	Correction of ASN.1 definition of PDP address	6.3.0	
s28		09.02	6.2.0	A192		R97	A	Re-use of security related information	6.3.0	
s28		09.02	6.2.0	A195		R97	F	ASN.1 coding for Access Point name	6.3.0	
s28		09.02	6.3.0	A165	4	R98	B	Addition of SoLSA functionality	7.0.0	
s28		09.02	6.3.0	A168		R98	B	Introduction of UUS service	7.0.0	
s28		09.02	6.3.0	A175	4	R98	C	Addition of Originating IMSI to MO-ForwardSM-Arg	7.0.0	
s28		09.02	6.3.0	A176	1	R98	B	Translation Type for MNP	7.0.0	
s28		09.02	6.3.0	A187		R98	B	Introduction of Call Deflection	7.0.0	
s28		09.02	6.3.0	A190		R98	B	Introduction of new subscription option for Call Forwarding supplementary service	7.0.0	
s28		09.02	6.3.0	A193	2	R98	B	Mobile Number Portability	7.0.0	
S28		09.02	6.3.0	A194	1	R98	B	Introduction of new subscription option	7.0.0	
s28		09.02	6.3.0	A197		R98	B	Introduction of WI CLI Enhancement	7.0.0	
s28		09.02	6.3.0	A198		R98	B	Adding the support of ANSI SCCP which is required in North America (World Zone 1)	7.0.0	
s28		09.02	6.3.0	A199		R98	D	Deletion of preferred carrier identities from the VLR	7.0.0	
s29	3C99-206	09.02	7.0.0	A186	3	R98	B	Introduction of UUS service to Resume Call Handling	7.1.0	UUS
s29	P99-475	09.02	7.0.0	A238		R98	B	MAP Impacts for Location Services (LCS)	7.1.0	Location Services (LCS)
s29	N2-99650	09.02	7.0.0	A237	1	R98	A	Modification of the O-CSI ASN1 structure	7.1.0	CAMEL phase 2
s29	N2-99676	09.02	7.0.0	A234		R98	A	Correction of mapping from MAP service to TC service	7.1.0	TEI
s29	N2-99628	09.02	7.0.0	A231		R98	F	Correction to the Purge MS "Detailed procedure in the HLR"	7.1.0	GPRS
s29	N2-99578	09.02	7.0.0	A228		R98	B	Introduction of TIF-CSI for Call Deflection	7.1.0	Call Deflection
s29	N2-99548	09.02	7.0.0	A227		R98	D	Clarification to text to identify how the LSA data relevant in the current VPLMN can be determined	7.1.0	SoLSA
s29	N2b99461	09.02	7.0.0	A224	1	R98	F	Introduction of Data Missing error in Resume Call Handling	7.1.0	TEI
s29	N2b99520	09.02	7.0.0	A223		R98	F	Export of NAEA-CIC	7.1.0	PCS-1900 Harmonisation
s29	N2b99519	09.02	7.0.0	A222		R98	A	VBS data	7.1.0	TEI

SMG#	TDoc	SPEC	VERS	CR	R E V	PHASE	C A T	SUBJECT	NEW VERS	WORKITEM
s29	N2-99585	09.02	7.0.0	A216	1	R98	C	Adding the support of ANSI SCCP which is required in North America (World Zone 1)	7.1.0	PCS 1900 Harmonisation
s29	N2-99269	09.02	7.0.0	A215		R98	C	Introduction of MSISDN in USSD operation	7.1.0	CAMEL phase 2
s29	N2-99250	09.02	7.0.0	A212		R98	A	Adding of MAP_DELIMITER_req to the Status Report operation	7.1.0	CCBS
s29	N2-99233	09.02	7.0.0	A211		R98	D	Clarificationin ASN.1 encoding of O-CSI aud T-CSI	7.1.0	CAMEL Phase 2
s29	N2-99228	09.02	7.0.0	A210		R98	F	New subscription option for Call Forwarding	7.1.0	PCS 1900 Harmonisation
s29	N2-99227	09.02	7.0.0	A209		R98	A	Use of E interface	7.1.0	ASCI phase 2
s29	N2b99677	09.02	7.0.0	A204	3	R98	A	Adding of MNP indicator to the SRI ack	7.1.0	MNP
s29	N2b99515	09.02	7.0.0	A218		R98	A	Introduction of 3-digit MNCs correction	7.1.0	PCS 1900 Harmonisation
CN#5	N2-99758	09.02	7.1.0	A242		R98	A	Clarification on VLR CAMEL Subscription Info	7.2.0	CAMEL Phase 2
CN#5	N2-99916	09.02	7.1.0	A244	1	R98	D	Clarification on DestinationNumberCriteria	7.2.0	CAMEL Phase 2
CN#5	N2-99962	09.02	7.1.0	A245	2	R98	A	GMSC-CAMEL phase 2 support IE in PRN	7.2.0	CAMEL Phase 2
CN#5	N2-99954	09.02	7.1.0	A246	1	R98	C	OR capability IE in PRN	7.2.0	TEI
CN#5	N2-99764	09.02	7.1.0	A248		R98	A	Removal of TDP-Criteria from RCH	7.2.0	CAMEL Phase 2
CN#5	N2-99774	09.02	7.1.0	A252		R98	A	Update Location handling for GPRS-only subscription	7.2.0	GPRS Phase 1
CN#5	N2-99775	09.02	7.1.0	A253		R98	A	Correction of OP & AC definitions for NoteMS-PresentForGPRS	7.2.0	GPRS phase 1
CN#5	N2-99860	09.02	7.1.0	A259		R98	F	Removal of redundant information from RCH	7.2.0	UUS
CN#5	N2-99932	09.02	7.1.0	A261		R98	A	Corrections related to GGSN-HLR Interface	7.2.0	GPRS phase 1
CN#5	N2-99A18	09.02	7.1.0	A263		R98	A	Alignment of 09.02 with 02.67	7.2.0	eMLPP
CN#05	N2-99A70	09.02	7.1.0	A264		R98	F	Clarification of returning the MSISDN in SRIack	7.2.0	MNP
CN#5	N2-99B79	09.02	7.1.0	A265		R98	F	Clarification of LR-REJECT cause corresponding to RoamingRestriction DueToUnsupportedFeature	7.2.0	TEI
CN#5	N2-99C26	09.02	7.1.0	A268		R98	A	Clarification on 'Supported CAMEL Phases' in ISD ack	7.2.0	CAMEL Phase 2
CN#5	N2-99D04	09.02	7.1.0	A270	1	R98	A	Addition of exception handling to the CancellationType	7.2.0	GPRS
CN#5	N2-99C76	09.02	7.1.0	A271		R98	F	Editing error correction on VLR capabilities	7.2.0	SoLSA
CN#6	N2-99G49	09.02	7.2.0	A279		R98	A	Addition of GGSN number for the SRIforGPRS	7.3.0	GPRS
CN#6	N2-99K10	09.02	7.2.0	A280		R98	A	Use of SSN for GPRS	7.3.0	GPRS
CN#6	N2-99K22	09.02	7.2.0	A277		R98	A	Correction of the USSD procedure in the HLR	7.3.0	USSD
CN#6	P-99-702	09.02	7.2.0	A273	1	R98	C	MAP Impacts for Location Services (LCS)	7.3.0	Location Services
CN#7	N2B000088	09.02	7.3.0	A281		R98	F	Correction of LSA information.	7.4.0	SoLSA
CN#7	N2B000097	09.02	7.3.0	A282		R98	F	Correction of SS-Codes for LCS	7.4.0	LCS
CN#7	N2B000147	09.02	7.3.0	A284		R98	F	Priorisation of MAP application context related to VGCS/VBS	7.4.0	ASCI Phase 2
CN#7	N2B000047	09.02	7.3.0	A285		R98	F	Privacy notification/verification for call related privacy class	7.4.0	LCS

SMG#	TDoc	SPEC	VERS	CR	R E V	PHASE	C A T	SUBJECT	NEW_ VERS	WORKITEM
CN#08	N4-000093	09.02	7.4.0	A287	1	R98	A	Using DSD to delete CCBS-B from the subscriber	7.5.0	CCBS
CN#08	N4-000215	09.02	7.4.0	A291		R98	A	Correction of version handling at dialogue establishment	7.5.0	TEI
CN#08	N4-000219	09.02	7.4.0	A293		R98	A	Correction of errors in Figure 25.1/1: Macro Receive_Open_Ind	7.5.0	TEI
CN#08	N4-000391	09.02	7.4.0	A295	1	R98	F	Indication of unsupported position method	7.5.0	LCS
CN#08	N4-000275	09.02	7.4.0	A297		R98	A	Clarification for ReportSM-DeliveryStatus operation	7.5.0	GPRS
CN#08	N4-000377	09.02	7.4.0	A299	1	R98	A	Use of NAM parameter with MAP-INSERT-SUBSCRIBER-DATA service between HLR and SGSN	7.5.0	GPRS
CN#08	N4-000373	09.02	7.4.0	A303		R98	A	Correction to the description of MAP-MO-Forward-Short-Message service	7.5.0	TEI
CN#08		09.02	7.5.0			R98		V 7.5.1 created to allow automatic update of Annexes A and B	7.5.1	
CN#9	N4-000489	09.02	7.5.1	A306		R98	A	Deletion of informative Annex C	7.6.0	TEI
CN#9	N4-000786	09.02	7.5.1	A310	1	R98	F	Correction to QoS indication	7.6.0	LCS
			7.5.1					Conversion to 3GPP layout	7.6.0	
CN#10	N4-000910	09.02	7.6.0	A308	2	R98	A	Corrections and clarifications for USSD procedures on the HLR - gsmSCF interface	7.7.0	CAMEL PHASE 2
CN#10	N4-001061	09.02	7.6.0	A314		R98	A	Clarification in SupportedCamelPhases	7.7.0	CAMEL PHASE 2
CN#11	N4-010034	09.02	7.7.0	A312	1	R98	F	Correction to LCS application context	7.8.0	LCS
CN#11	N4-010056	09.02	7.7.0	A316		R98	A	Failure of Update GPRS Location when HLR is not reachable	7.8.0	GPRS R97
CN#11	N4-010444	09.02	7.7.0	A318		R98	A	Failure of Authentication Parameter when HLR is not reachable	7.8.0	GPRS R97

NOTE: CR 09.02 A109r3 was not completely implemented in v6.0.0 and v6.1.1 so is introduced in v6.2.0. SDL changes to figure 23.3/6 (sheet 1 of 5) "Process Mobile_terminated_SM_HLR".

History

Document history		
V7.1.0	August 1999	Publication
V7.3.0	February 2000	Publication
V7.5.0	July 2000	Publication
V7.5.1	September 2000	Publication
V7.6.0	September 2000	Publication
V7.7.0	December 2000	Publication
V7.8.0	March 2001	Publication