ETSI TS 137 480 V17.2.0 (2024-02)



5G; E1 general aspects and principles (3GPP TS 37.480 version 17.2.0 Release 17)



Reference RTS/TSGR-0337480vh20 Keywords 5G

ETSI

650 Route des Lucioles F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B Association à but non lucratif enregistrée à la Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from: https://www.etsi.org/standards-search

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at www.etsi.org/deliver.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx

If you find errors in the present document, please send your comment to one of the following services: https://portal.etsi.org/People/CommiteeSupportStaff.aspx

If you find a security vulnerability in the present document, please report it through our Coordinated Vulnerability Disclosure Program:

https://www.etsi.org/standards/coordinated-vulnerability-disclosure

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2024. All rights reserved.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (https://ipr.etsi.org/).

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

DECTTM, **PLUGTESTS**TM, **UMTS**TM and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP**TM and **LTE**TM are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2M**TM logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM**[®] and the GSM logo are trademarks registered and owned by the GSM Association.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found under https://webapp.etsi.org/key/queryform.asp.

Modal verbs terminology

In the present document "shall", "shall not", "should", "should not", "may", "need not", "will", "will not", "can" and "cannot" are to be interpreted as described in clause 3.2 of the <u>ETSI Drafting Rules</u> (Verbal forms for the expression of provisions).

"must" and "must not" are NOT allowed in ETSI deliverables except when used in direct citation.

Contents

Intell	Intellectual Property Rights						
Legal	l Notice	2					
Moda	al verbs terminology	2					
Forev	word						
1	Scope						
	References						
2							
3	Definitions and abbreviations						
3.1	Definitions						
	Abbreviations						
4	General aspects						
4.1	E1 interface general principles						
4.2	E1 interface specification objectives						
5	Functions of the E1 interface.						
5.1	General						
5.1.1 5.1.2	E1 interface management function						
5.1.3	Trace function						
5.1.4	Load management function						
5.1.5	Measurement results transfer function						
5.1.6	Support for IAB						
5.1.7 5.2	E1 bearer context management function for NR MBS						
6	Procedures of the E1 interface						
6.1	Interface Management procedures						
6.2	Bearer Context Management procedures						
6.3	UE Tracing procedures	10					
6.4	Load management procedures						
6.5 6.6	Measurement results transfer procedures						
6.7	NR MBS procedures						
7	E1 interface protocol structure						
8	Other E1 interface specifications	11					
8.1	E1 interface: layer 1 (3GPP TS 37.481)						
8.2	E1 interface: signalling transport (3GPP TS 37.482)	11					
8.3	E1 interface: E1AP specification (3GPP TS 37.483)	12					
Anne	ex A (informative): Change history	13					
Uicto	NPT7	1/					

Foreword

This Technical Specification has been produced by the 3rd Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
 - 1 presented to TSG for information;
 - 2 presented to TSG for approval;
 - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

1 Scope

The present document is an introduction to the 3GPP TS 37.48x series of technical specifications that define the E1 interface. The E1 interface provides means for interconnecting a gNB-CU-CP and a gNB-CU-UP of a gNB-CU within an NG-RAN, or for interconnecting a gNB-CU-CP and a gNB-CU-UP of an en-gNB within an E-UTRAN, or for interconnecting an eNB-CP and an eNB-UP of an eNB within an E-UTRAN, or for interconnecting an ng-eNB-CU-CP and an ng-eNB-CU-UP of an ng-eNB-CU within an NG-RAN.

2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the same Release as the present document*.

```
[1]
                 3GPP TR 21.905: "Vocabulary for 3GPP Specifications".
                 3GPP TS 38.401: "NG-RAN; Architecture Description".
[2]
[3]
                 3GPP TS 37.481: "E1 layer 1".
[4]
                 3GPP TS 37.482: "E1 signalling transport".
                 3GPP TS 37.483: "E1 Application Protocol (E1AP)".
[5]
                 3GPP TS 38.300: "NR; Overall description; Stage-2".
[6]
[7]
                 3GPP TS 37.340: "NR; Multi-connectivity; Overall description; Stage-2".
                 3GPP TS 37.470: "W1 interface; General aspects and principles".
[8]
[9]
                 3GPP TS 36.401: "Evolved Universal Terrestrial Radio Access Network (E-UTRAN);
                 Architecture description".
[10]
                 3GPP TS 23.247: "5G multicast-broadcast services; Stage 2".
```

3 Definitions and abbreviations

3.1 Definitions

For the purposes of the present document, the terms and definitions given in 3GPP TR 21.905 [1] and the following apply. A term defined in the present document takes precedence over the definition of the same term, if any, in 3GPP TR 21.905 [1].

```
eNB-CP: as defined in TS 36.401 [9].
eNB-UP: as defined in TS 36.401 [9].
en-gNB: as defined in TS 37.340 [7].
gNB-CU: as defined in TS 38.401 [2].
gNB-CU-CP: as defined in TS 38.401 [2].
```

gNB-CU-UP: as defined in TS 38.401 [2].
gNB-DU: as defined in TS 38.401 [2].
gNB: as defined in TS 38.300 [6].
IAB: as defined in TS 38.300 [6].
ng-eNB-CU: as defined in TS 37.470 [8].
ng-eNB-CU-CP: as defined in TS 38.401 [2].
ng-eNB-CU-UP: as defined in TS 38.401 [2].
ng-eNB-DU: as defined in TS 37.470 [8].

3.2 Abbreviations

For the purposes of the present document, the abbreviations given in 3GPP TR 21.905 [1] and the following apply. An abbreviation defined in the present document takes precedence over the definition of the same abbreviation, if any, in 3GPP TR 21.905 [1].

DL Downlink
DRB Data Radio Bearer
E1AP E1 Application Protocol
IP Internet Protocol
MBS Multicast/Broadcast Service

PTP Point to Point PTM Point to Multipoint

SCTP Stream Control Transmission Protocol

TNL Transport Network Layer

4 General aspects

This clause captures the E1 interface principles and characteristics.

Note:

The principles, functions and procedures specified in this specification also apply to the case where E1AP is used between an ng-eNB-CU-CP and an ng-eNB-CU-UP or between an eNB-CP and an eNB-UP, unless stated otherwise.

4.1 E1 interface general principles

The general principles for the specification of the E1 interface are as follows:

- the E1 interface is open;
- the E1 interface supports the exchange of signalling information between the endpoints;
- from a logical standpoint, the E1 is a point-to-point interface between a gNB-CU-CP and a gNB-CU-UP, or between an ng-eNB-CU-CP and an ng-eNB-CU-UP, or between an eNB-CP and an eNB-UP.

NOTE 1: A point-to-point logical interface should be feasible even in the absence of a physical direct connection between the endpoints.

- the E1 interface separates Radio Network Layer and Transport Network Layer;
- the E1 interface enables exchange of UE associated information and non-UE associated information;
- the E1 interface is future proof to fulfil different new requirements, support of new services and new functions.

4.2 E1 interface specification objectives

The E1 interface specifications facilitate the following:

- inter-connection of a gNB-CU-CP and a gNB-CU-UP supplied by different manufacturers.
- inter-connection of an ng-eNB-CU-CP and an ng-eNB-CU-UP supplied by different manufacturers.
- inter-connection of an eNB-CP and an eNB-UP supplied by different manufacturers.

5 Functions of the E1 interface

5.1 General

The following clauses describe the functions supported over E1.

5.1.1 E1 interface management function

The error indication function is used by the gNB-CU-UP or gNB-CU-CP to indicate to the gNB-CU-CP or gNB-CU-UP that an error has occurred.

The reset function is used to initialize the peer entity after node setup and after a failure event occurred. This procedure can be used by both the gNB-CU-UP and the gNB-CU-CP.

The E1 setup function allows to exchange application level data needed for the gNB-CU-UP and gNB-CU-CP to interoperate correctly on the E1 interface. The E1 setup is initiated by both the gNB-CU-UP and gNB-CU-CP.

The gNB-CU-UP Configuration Update and gNB-CU-CP Configuration Update functions allow to update application level configuration data needed between the gNB-CU-CP and the gNB-CU-UP to interoperate correctly over the E1 interface.

The E1 setup and gNB-CU-UP Configuration Update functions allow to inform NR CGI(s), ECGI(s), S-NSSAI(s), PLMN-ID(s), QoS information and NID(s) supported by the gNB-CU-UP.

The E1 setup and gNB-CU-UP Configuration Update functions allow the gNB-CU-UP to signal its capacity information to the gNB-CU-CP.

The E1 gNB-CU-UP Status Indication function allows to inform the overloaded or non-overloaded status over the E1 interface.

5.1.2 E1 bearer context management function

The establishment of the E1 bearer context is initiated by the gNB-CU-CP and accepted or rejected by the gNB-CU-UP based on admission control criteria (e.g., resource not available).

The modification of the E1 bearer context can be initiated by either gNB-CU-CP or gNB-CU-UP. The receiving node can accept or indicate failure to carry out the modification request. The E1 bearer context management function also supports the release of the bearer context previously established in the gNB-CU-UP. The release of the bearer context is triggered by the gNB-CU-CP either directly or following a request received from the gNB-CU-UP.

This function is used to setup and modify the QoS-flow to DRB mapping configuration. The gNB-CU-CP decides flow-to-DRB mapping and provides the generated SDAP and PDCP configuration to the gNB-CU-UP. The gNB-CU-CP also decides the Reflective QoS flow to DRB mapping. The function is also used to send to the gNB-CU-UP the alternative QoS Parameters Sets when available for a QoS flow. For each PDU Session Resource to be setup or modified, the S-NSSAI, shall be provided in the E1 bearer context setup procedure and may be provided in the E1 bearer context modification procedure by gNB-CU-CP to the gNB-CU-UP.

This function is also used to setup and modify the EPS bearer/E-RAB to DRB mapping configuration for the case of eNB-CP and eNB-UP separation. The eNB-CP decides EPS bearer/E-RAB-to-DRB mapping and provides the E-UTRAN/NR PDCP configuration to the eNB-UP.

This function is used for the gNB-CU-CP to send the security information to the gNB-CU-UP.

This function is used for the gNB-CU-CP to send to the gNB-CU-UP transport layer information to be used for data forwarding e.g., during handovers.

This function is used for the gNB-CU-CP to send the parameters for header compression for certain traffic types e.g., IP, Ethernet to the gNB-CU-UP.

This function is used for the gNB-CU-CP to send the uplink data compression parameters to the gNB-CU-UP for certain data radio bearer(s).

This function is used for the gNB-CU-UP to notify the event of DL data arrival detection to the gNB-CU-CP. With this function, the gNB-CU-UP requests gNB-CU-CP to trigger paging procedure over F1 or Xn to support RRC Inactive state. RRC Inactive state is not supported when this function is used between an eNB-CP and an eNB-UP.

This function is used for the gNB-CU-UP to notify the gNB-CU-CP that a DL packet including a QFI value not configured by the gNB-CU-CP or an UL packet including a QFI value in the SDAP header of the default DRB not configured by the gNB-CU-CP is received for the first time. The gNB-CU-CP can take further action if needed.

This function is used for the gNB-CU-UP to notify the event of user inactivity to the gNB-CU-CP. With this function, the gNB-CU-UP indicates that the inactivity timer associated with a bearer, a PDU session or a UE expires, or that user data is received for the bearer, the PDU session or the UE whose inactivity timer has expired. The gNB-CU-CP consolidates all the serving gNB-CU-UPs for the UE and takes further action.

This function is used for the gNB-CU-UP to report data volume to the gNB-CU-CP.

This function is used for the gNB-CU-CP to notify the suspension and resumption of bearer contexts to the gNB-CU-UP. Suspension and resumption of bearer contexts are not applicable to eNB-CP/eNB-UP and ng-eNB-CU-CP/ng-eNB-CU-UP.

This function also allows to support CA based packet duplication as described in TS 38.300 [6], i.e. one data radio bearer should be configured with at least two GTP-U tunnels between gNB-CU-UP and a gNB-DU.

This function is used to support the enhanced mobility operations as described in TS 38.300 [6] in the gNB-CU-UP.

5.1.3 Trace function

The Trace function provides means to control trace sessions for a UE over E1 interface.

5.1.4 Load management function

The load management function allows an gNB-CU-CP to request the reporting of load measurements to gNB-DU and is used by gNB-CU-UP to report the result of measurements admitted by gNB-CU-UP.

5.1.5 Measurement results transfer function

The measurement results transfer is used by the gNB-CU-CP to transfer UE associated measurement results to the gNB-CU-UP.

5.1.6 Support for IAB

Note: IAB is an NR feature, and this function is not applicable to eNB CP-UP separation and ng-eNB CP-UP separation.

This function is used to update the DL/UL F1-U GTP-U tunnels for an IAB network, and allow the gNB-CU-CP to send the security key info to the gNB-CU-UP for the protection of the F1-U interface with IAB-DU.

5.1.7 E1 bearer context management function for NR MBS

The E1 bearer context management function for NR MBS consists of two sub-sets for functions, one for NR MBS broadcast, one for NR MBS multicast.

Both sets follow the principles of the E1 bearer context management functions, with the following differences.

- E1 NR MBS procedure concerns a single MBS Session Resource only.
- E1 NR MBS procedures concern the control of MRB resources in gNB-CU-UP.
- E1 NR MBS procedures do not control security information, as for NR MBS, PDCP does not apply security as specified in TS 38.300 [6].
- QoS flow to MRB mapping is determined by the gNB-CU-CP or, in case of shared NR-U terminations, the gNB-CU-UP may be notified about the QoS flow to MRB mapping already determined in the bearer context for the shared NR-U termination. The gNB-CU-CP may inform the gNB-CU-UP whether it is contended with the already determined mapping decision.

NOTE: Not all QoS flow parameters are applicable for NR MBS, as specified in TS 23.247 [10].

- Data volume reporting is not applicable for NR MBS.
- CA based packet duplication is not applicable for NR MBS.

5.2 TEIDs allocation

The gNB-CU-UP is responsible for the allocation of the F1-U UL GTP TEID for each data radio bearer.

The gNB-CU-UP is responsible for the allocation of the S1-U DL GTP TEID for each E-RAB and the NG-U DL GTP TEID for each PDU Session.

The gNB-CU-UP is responsible for the allocation of the X2-U DL/UL GTP TEID or the Xn-U DL/UL GTP TEID for each data radio bearer.

6 Procedures of the E1 interface

6.1 Interface Management procedures

The E1 interface management procedures are listed below:

- Reset procedure
- Error Indication procedure
- gNB-CU-UP E1 Setup procedure
- gNB-CU-CP E1 Setup procedure
- gNB-CU-UP Configuration Update procedure
- gNB-CU-CP Configuration Update procedure
- E1 Release procedure
- gNB-CU-UP Status Indication procedure

6.2 Bearer Context Management procedures

The E1 bearer management procedures are listed below:

- Bearer Context Setup procedure
- Bearer Context Release Request (gNB-CU-UP initiated) procedure
- Bearer Context Release (gNB-CU-CP initiated) procedure
- Bearer Context Modification (gNB-CU-CP initiated) procedure
- Bearer Context Modification Required (gNB-CU-UP initiated) procedure
- DL Data Notification procedure
- Bearer Context Inactivity Notification procedure
- Data Usage Report procedure
- MR-DC Data Usage Report procedure

6.3 UE Tracing procedures

The following procedures are used to trace the UE:

- Trace Start procedure
- Deactivate Trace procedure
- Cell Traffic Trace procedure

6.4 Load management procedures

The load management procedures are listed as below:

- Resource Status Reporting Initiation procedure
- Resource Status Reporting procedure

6.5 Measurement results transfer procedures

The measurement results transfer procedures are listed as below:

- GNB-CU-CP Measurement Results Information

6.6 IAB procedures

Note: IAB is an NR feature, and this procedure is not applicable to eNB CP-UP separation and ng-eNB CP-UP separation.

The IAB procedures are listed as below:

- IAB UP TNL Address Update procedure
- IAB PSK Notification procedure

6.7 NR MBS procedures

The E1 MBS procedures are listed below:

- Broadcast E1AP MBS procedures
 - BC Bearer Context Setup

- BC Bearer Context Modification (gNB-CU-CP inititated)
- BC Bearer Context Modification (gNB-CU-UP inititated)
- BC Bearer Context Release (gNB-CU-CP inititated)
- BC Bearer Context Release (gNB-CU-UP inititated)
- Multicast E1AP MBS procedures
 - MC Bearer Context Setup
 - MC Bearer Context Modification (gNB-CU-CP inititated)
 - MC Bearer Context Modification (gNB-CU-UP inititated)
 - MC Bearer Context Release (gNB-CU-CP inititated)
 - MC Bearer Context Release (gNB-CU-UP inititated)
 - MC Bearer Notification

7 E1 interface protocol structure

Figure 7.1-1 shows the protocol structure for E1. The TNL is based on IP transport, comprising the SCTP on top of IP. The application layer signalling protocol is referred to as E1AP (E1 Application Protocol).




Figure 7.1-1: Interface protocol structure for E1

8 Other E1 interface specifications

This clause contains the description of the other related 3GPP specifications.

8.1 E1 interface: layer 1 (3GPP TS 37.481)

3GPP TS 37.481 [3] specifies the physical layer technologies that may be used to support the E1 interface.

8.2 E1 interface: signalling transport (3GPP TS 37.482)

3GPP TS 37.482 [4] specifies the signalling bearers for the E1AP for the E1 interface.

8.3 E1 interface: E1AP specification (3GPP TS 37.483)

3GPP TS 37.483 [5] specifies the E1AP protocol for radio network control plane signalling over the E1 interface.

Annex A (informative): Change history

	Change history									
Date	Meeting	TDoc	CR	Rev	Cat	Subject/Comment	New version			
2022-01	R3#114bis -e	R3-220846				Text transferred from TS 38.460 v16.4.0 and references updated to 37.48x series	0.0.1			
2022-02	R3#115-e	R3-221646				Changes from Rel-17 WI "LTE_NR_arch_evo_enh-Core" incorporated and change history updated.	0.1.0			
2022-03	R3#115-e	R3-222579				Agreements from Rel-17 WI "LTE_NR_arch_evo_enh-Core" at RAN3#115-e incorporated.	0.1.1			
2022-03	R3#115-e	R3-222973				Change history updated	0.2.0			
2022-03	RAN#95-e	RP-220795				Version submitted for approval in RAN#95-e	1.0.0			
2022-03	RAN#95-e	R3-220848				Agreed Rel-16/17 CRs from other WIs are merged. Including REL-16 38.460 changes of R3-221224 of RP-220276, and REL-17 38.460 changes of R3-222614 of RP-220234, R3-222929 of RP-220224.	1.1.0			
2022-03	SA#95- e					Promotion to Release 17 without technical change	17.0.0			
2022-06	RAN#96	RP-221145	0001	-	D	E1 TS 37.480 Editorial corrections	17.1.0			
2022-06	RAN#96	RP-221134	0002	-	F	Corrections on E1 bearer context management function for NR MBS	17.1.0			
2023-12	RAN#102	RP-233849	0005	2	F	Correction on Temp no data and DL data arrival for Activate Multicast Session	17.2.0			

History

Document history								
V17.0.0	April 2022	Publication						
V17.1.0	July 2022	Publication						
V17.2.0	February 2024	Publication						