
ETSITS 125 331 V5.9.0 (2004-06)

Technical Specification

Universal Mobile Telecommunications System (UMTS); Radio Resource Control (RRC) protocol specification (3GPP TS 25.331 version 5.9.0 Release 5)



Reference RTS/TSGR-0225331v590 Keywords UMTS

ETSI

650 Route des Lucioles F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C Association à but non lucratif enregistrée à la Sous-Préfecture de Grasse (06) N° 7803/88

Important notice

Individual copies of the present document can be downloaded from: <u>http://www.etsi.org</u>

The present document may be made available in more than one electronic version or in print. In any case of existing or perceived difference in contents between such versions, the reference version is the Portable Document Format (PDF). In case of dispute, the reference shall be the printing on ETSI printers of the PDF version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

http://portal.etsi.org/tb/status/status.asp

If you find errors in the present document, send your comment to: editor@etsi.org

Copyright Notification

No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2004.
All rights reserved.

DECTTM, **PLUGTESTS**TM and **UMTS**TM are Trade Marks of ETSI registered for the benefit of its Members. **TIPHON**TM and the **TIPHON logo** are Trade Marks currently being registered by ETSI for the benefit of its Members. **3GPP**TM is a Trade Mark of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (http://webapp.etsi.org/IPR/home.asp).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Foreword

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under http://webapp.etsi.org/key/queryform.asp.

Contents

Intelle	Intellectual Property Rights	
Forew	/ord	2
Forew	vord	26
1	Scope	27
2	References	27
3	Definitions and abbreviations.	29
3.1	Definitions	
3.2	Abbreviations	
4	General	31
4.1	Overview of the specification	31
4.2	RRC Layer Model	32
4.3	Protocol specification principles	35
5	RRC Functions and Services provided to upper layers	
5.1	RRC Functions	
5.2	RRC Services provided to upper layers	
5.3	Primitives between RRC and upper layers	36
6	Services expected from lower layers	
6.1	Services expected from Layer 2	
6.2	Services expected from Layer 1	
6.3	Signalling Radio Bearers	
7	Protocol states	
7.1	Overview of RRC States and State Transitions including GSM	
7.2	Processes in UE modes/states	
7.2.1	UE Idle mode	
7.2.2	UTRA RRC Connected mode	
7.2.2.1		
7.2.2.2 7.2.2.3		
8	RRC procedures	
8.1	RRC Connection Management Procedures	
8.1.1	Broadcast of system information	
8.1.1.1	· · · · · · · · · · · · · · · · · · ·	
8.1.1.1		
8.1.1.1		
8.1.1.1	·	
8.1.1.1	.4 Re-assembly of segments	47
8.1.1.1	5 Scheduling of system information	48
8.1.1.2		
8.1.1.3		
8.1.1.4		
8.1.1.5		
8.1.1.6		
8.1.1.6	J	
8.1.1.6	V VI	
8.1.1.6	7	
8.1.1.6	7	
8.1.1.6	7	
8.1.1.6 8.1.1.6	7	
8.1.1.6		
8.1.1.6	7	

		_
8.1.1.6.10	System Information Block type 10	
8.1.1.6.11	System Information Block type 11	
8.1.1.6.12	System Information Block type 12	
8.1.1.6.13	System Information Block type 13	
8.1.1.6.14	System Information Block type 14	
8.1.1.6.15	System Information Block type 15	
8.1.1.6.16	System Information Block type 16	
8.1.1.6.17 8.1.1.6.18	System Information Block type 17	
8.1.1.7	System Information Block type 18	
8.1.1.7.1	Modification of system information blocks using a value tag	
8.1.1.7.1	Synchronised modification of system information blocks	
8.1.1.7.3	Actions upon system information change	
8.1.1.7.4	Actions upon system information enauge	
8.1.2	Paging	
8.1.2.1	General	
8.1.2.2	Initiation	
8.1.2.3	Reception of a PAGING TYPE 1 message by the UE	
8.1.3	RRC connection establishment	
8.1.3.1	General	67
8.1.3.2	Initiation	67
8.1.3.3	RRC CONNECTION REQUEST message contents to set	
8.1.3.4	Reception of an RRC CONNECTION REQUEST message by the UTRAN	
8.1.3.5	Cell re-selection or T300 timeout.	
8.1.3.5a	Abortion of RRC connection establishment	
8.1.3.6	Reception of an RRC CONNECTION SETUP message by the UE	
8.1.3.7	Physical channel failure or cell re-selection	71
8.1.3.8	Invalid RRC CONNECTION SETUP message, unsupported configuration or invalid	
0.1.2.0	configuration	
8.1.3.9	Reception of an RRC CONNECTION REJECT message by the UE	
8.1.3.10	Invalid RRC CONNECTION REJECT message	
8.1.4 8.1.4.1	General	
8.1.4.1	Initiation	
8.1.4.3	Reception of an RRC CONNECTION RELEASE message by the UE	
8.1.4.4	Invalid RRC CONNECTION RELEASE message	
8.1.4.5	Cell re-selection or radio link failure	
8.1.4.6	Expiry of timer T308, unacknowledged mode transmission	
8.1.4.7	Void	
8.1.4.8	Reception of an RRC CONNECTION RELEASE COMPLETE message by UTRAN	
8.1.4.9	Unsuccessful transmission of the RRC CONNECTION RELEASE COMPLETE message,	
	acknowledged mode transmission	80
8.1.4.10	Detection of loss of dedicated physical channel by UTRAN in CELL_DCH state	80
8.1.4.11	Failure to receive RRC CONNECTION RELEASE COMPLETE message by UTRAN	80
8.1.4a	RRC connection release requested by upper layers	80
8.1.4a.1	General	
8.1.4a.2	Initiation	
8.1.5	Void	
8.1.6	Transmission of UE capability information	
8.1.6.1	General	
8.1.6.2	Initiation	
8.1.6.3	Reception of a UE CAPABILITY INFORMATION message by the UTRAN	
8.1.6.4 8.1.6.5	Reception of the UE CAPABILITY INFORMATION CONFIRM message by the UE	
8.1.6.6	T304 timeout	
8.1.7	UE capability enquiry	
8.1.7.1	General	
8.1.7.2	Initiation	
8.1.7.3	Reception of a UE CAPABILITY ENQUIRY message by the UE	
8.1.7.4	Invalid UE CAPABILITY ENQUIRY message	
8.1.8	Initial Direct transfer	
8181	General	8/

8.1.8.2	Initiation of Initial direct transfer procedure in the UE	84
8.1.8.2a	RLC re-establishment or inter-RAT change	
8.1.8.2ab	Inter-RAT handover from UTRAN to GERAN Iu mode	
8.1.8.2b	Abortion of signalling connection establishment	86
8.1.8.3	Reception of INITIAL DIRECT TRANSFER message by the UTRAN	86
8.1.9	Downlink Direct transfer	87
8.1.9.1	General	
8.1.9.2	Initiation of downlink direct transfer procedure in the UTRAN	
8.1.9.3	Reception of a DOWNLINK DIRECT TRANSFER message by the UE	
8.1.9.3a	No signalling connection exists	
8.1.9.4	Invalid DOWNLINK DIRECT TRANSFER message	
8.1.10	Uplink Direct transfer	
8.1.10.1	General	
8.1.10.2	Initiation of uplink direct transfer procedure in the UE	
8.1.10.2a	RLC re-establishment or inter-RAT change	
8.1.10.2b	Inter-RAT handover from UTRAN to GERAN <i>Iu mode</i>	
8.1.10.3	Reception of UPLINK DIRECT TRANSFER message by the UTRAN	
8.1.11	UE dedicated paging	
8.1.11.1	General	
8.1.11.2	Initiation	
8.1.11.3	Reception of a PAGING TYPE 2 message by the UE	
8.1.11.4	Invalid PAGING TYPE 2 message	
8.1.12	Security mode control	
8.1.12.1	General	
8.1.12.1	Initiation	
8.1.12.2.1	Ciphering configuration change	
8.1.12.2.2		
8.1.12.2.2	Reception of SECURITY MODE COMMAND message by the UE	
8.1.12.3 8.1.12.3.1	New ciphering and integrity protection keys	
8.1.12.3.1 8.1.12.4	VoidVoid	
8.1.12.4 8.1.12.4a	Incompatible simultaneous security reconfiguration	
8.1.12.4a	Cell update procedure during security reconfiguration	
8.1.12.4c	Invalid configuration	
8.1.12.40	Reception of SECURITY MODE COMPLETE message by the UTRAN	
8.1.12.5	Invalid SECURITY MODE COMMAND message	
8.1.13	Signalling connection release procedure	
8.1.13.1	General	
8.1.13.1	Initiation of SIGNALLING CONNECTION RELEASE by the UTRAN	
	Reception of SIGNALLING CONNECTION RELEASE by the UE	
8.1.13.3 8.1.13.4		
	Invalid SIGNALLING CONNECTION RELEASE message	
8.1.13.5	Invalid configuration	
8.1.14	Signalling connection release indication procedure	
8.1.14.1	General	
8.1.14.2	Initiation	
8.1.14.2a	RLC re-establishment or inter-RAT change	
8.1.14.3	Reception of SIGNALLING CONNECTION RELEASE INDICATION by the UTRAN	
8.1.15	Counter check procedure	
8.1.15.1	General	
8.1.15.2	Initiation	
8.1.15.3	Reception of a COUNTER CHECK message by the UE	
8.1.15.4	Reception of the COUNTER CHECK RESPONSE message by UTRAN	
8.1.15.5	Cell re-selection	
8.1.15.6	Invalid COUNTER CHECK message	
8.1.16	Inter RAT handover information transfer	
8.1.16.1	General	
8.1.16.2	Initiation	
8.1.16.3	INTER RAT HANDOVER INFO message contents to set	
8.2	Radio Bearer control procedures	
8.2.1	Radio bearer establishment	
8.2.2	Reconfiguration procedures	
8.2.2.1	General	
8222	Initiation	113

8.2.2.2a	Initiation of handover from GERAN Iu mode	115
8.2.2.3	Reception of RADIO BEARER SETUP or RADIO BEARER RECONFIGURATION or RADIO BEARER RELEASE or TRANSPORT CHANNEL RECONFIGURATION or	
	PHYSICAL CHANNEL RECONFIGURATION message by the UE	115
8.2.2.3a	Reception of RADIO BEARER RECONFIGURATION message by the UE performing	10
0224	handover from GERAN <i>Iu mode</i>	
8.2.2.4 8.2.2.5	Reception of a response message by the UTRAN, normal case	
8.2.2.6	Unsupported configuration in the UE	
8.2.2.7	Physical channel failure	
8.2.2.8	Cell re-selection	
8.2.2.9	Transmission of a response message by the UE, failure case	
8.2.2.10	Reception of a response message by the UTRAN, failure case	
8.2.2.11	Invalid configuration	
8.2.2.12	Incompatible simultaneous reconfiguration	
8.2.2.12a	Incompatible simultaneous security reconfiguration	
8.2.2.12b	Cell update procedure during security reconfiguration	
8.2.2.13	Invalid received message	
8.2.2.14	Radio link failure	133
8.2.3	Radio bearer release	134
8.2.4	Transport channel reconfiguration	134
8.2.5	Transport format combination control	
8.2.5.1	General	134
8.2.5.2	Initiation	
8.2.5.3	Reception of a TRANSPORT FORMAT COMBINATION CONTROL message by the UE	
8.2.5.4	Invalid configuration	
8.2.5.5	Invalid TRANSPORT FORMAT COMBINATION CONTROL message	
8.2.6	Physical channel reconfiguration	
8.2.7	Physical Shared Channel Allocation [TDD only]	
8.2.7.1	General	
8.2.7.2	Initiation	
8.2.7.3	Reception of a PHYSICAL SHARED CHANNEL ALLOCATION message by the UE	
8.2.7.4	Invalid PHYSICAL SHARED CHANNEL ALLOCATION message	
8.2.8	PUSCH capacity request [TDD only]	
8.2.8.1	General	
8.2.8.2	Initiation	
8.2.8.3	PUSCH CAPACITY REQUEST message contents to set	
8.2.8.4	Reception of a PUSCH CAPACITY REQUEST message by the UTRAN	
8.2.8.5	T310 expiry	
8.2.9	Void	
8.2.10	Uplink Physical Channel Control [TDD only]	
8.2.10.1	General Initiation	
8.2.10.2 8.2.10.3	Reception of UPLINK PHYSICAL CHANNEL CONTROL message by the UE	
8.2.10.3	Invalid UPLINK PHYSICAL CHANNEL CONTROL message by the UE	
8.2.10.4	Physical channel reconfiguration failure	
8.2.11.1	General	
8.2.11.1	Runtime error due to overlapping compressed mode configurations	
8.2.11.3	Runtime error due to overlapping compressed mode configuration and PDSCH reception	
8.3	RRC connection mobility procedures	
8.3.1	Cell and URA update procedures	
8.3.1.1	General	
8.3.1.2	Initiation	
8.3.1.3	CELL UPDATE / URA UPDATE message contents to set	
8.3.1.4	T305 expiry and the UE detects "out of service area"	
8.3.1.4.1	Re-entering "in service area"	
8.3.1.4.2	Expiry of timer T307	
8.3.1.5	Reception of an CELL UPDATE/URA UPDATE message by the UTRAN	
8.3.1.6	Reception of the CELL UPDATE CONFIRM/URA UPDATE CONFIRM message by the UE	
8.3.1.7	Transmission of a response message to UTRAN	
8.3.1.7a	Physical channel failure	
8.3.1.8	Unsupported configuration by the UE	

8.3.1.9	Invalid configuration	
8.3.1.9a	Incompatible simultaneous reconfiguration	
8.3.1.9b	Security reconfiguration during Cell update procedure	
8.3.1.10	Confirmation error of URA ID list	
8.3.1.11	Invalid CELL UPDATE CONFIRM/URA UPDATE CONFIRM message	170
8.3.1.12	T302 expiry or cell reselection	171
8.3.1.13	T314 expiry	173
8.3.1.14	T315 expiry	
8.3.1.15	Reception of the UTRAN MOBILITY INFORMATION CONFIRM message by the UTRAN	175
8.3.2	URA update	175
8.3.3	UTRAN mobility information	175
8.3.3.1	General	175
8.3.3.2	Initiation	
8.3.3.3	Reception of UTRAN MOBILITY INFORMATION message by the UE	
8.3.3.4	Reception of an UTRAN MOBILITY INFORMATION CONFIRM message by the UTRAN	178
8.3.3.5	Cell re-selection	
8.3.3.5a	Incompatible simultaneous security reconfiguration	
8.3.3.6	Invalid UTRAN MOBILITY INFORMATION message	180
8.3.4	Active set update	180
8.3.4.1	General	
8.3.4.2	Initiation	
8.3.4.3	Reception of an ACTIVE SET UPDATE message by the UE	
8.3.4.4	Unsupported configuration in the UE	
8.3.4.5	Invalid configuration	
8.3.4.5a	Void	
8.3.4.5b	Incompatible simultaneous reconfiguration	
8.3.4.6	Reception of the ACTIVE SET UPDATE COMPLETE message by the UTRAN	
8.3.4.7	Reception of the ACTIVE SET UPDATE FAILURE message by the UTRAN	
8.3.4.8	Invalid ACTIVE SET UPDATE message	
8.3.4.9	Reception of an ACTIVE SET UPDATE message in wrong state	
8.3.5	Hard handover	
8.3.5.1	Timing re-initialised hard handover	
8.3.5.1.1	General	
8.3.5.1.2	Initiation	
8.3.5.2	Timing-maintained hard handover	
8.3.5.2.1	General	
8.3.5.2.2	Initiation	
8.3.6	Inter-RAT handover to UTRAN	
8.3.6.1	General	
8.3.6.2	Initiation	
8.3.6.3	Reception of HANDOVER TO UTRAN COMMAND message by the UE	
8.3.6.4	Invalid Handover to UTRAN command message	190
8.3.6.4a	Unsupported configuration in HANDOVER TO UTRAN COMMAND message	
8.3.6.5	UE fails to perform handover	190
8.3.6.6	Reception of message HANDOVER TO UTRAN COMPLETE by the UTRAN	
8.3.7	Inter-RAT handover from UTRAN	
8.3.7.1	General	
8.3.7.2	Initiation	
8.3.7.3	Reception of a HANDOVER FROM UTRAN COMMAND message by the UE	
8.3.7.4	Successful completion of the inter-RAT handover	
8.3.7.5	UE fails to complete requested handover	
8.3.7.6	Invalid HANDOVER FROM UTRAN COMMAND message	
8.3.7.7	Reception of an HANDOVER FROM UTRAN FAILURE message by UTRAN	
8.3.7.8	Unsupported configuration in HANDOVER FROM UTRAN COMMAND message	
8.3.7.8a	Reception of HANDOVER FROM UTRAN COMMAND message by UE in CELL_FACH	
8.3.8	Inter-RAT cell reselection to UTRAN	
8.3.8.1	General	
8.3.8.2	Initiation	
8.3.8.2a	Initiation of inter-RAT cell reselection from GERAN <i>Iu mode</i>	
8.3.8.3 8.3.8.3a	UE fails to complete an inter-RAT cell reselection.	
8.3.8.3a 8.3.9	UE fails to complete an inter-RAT cell reselection from GERAN <i>Iu mode</i>	
U.J.7	III.UI-IXAT UUII IUSEIUUII IIUIII U TKAIN	19/

8.3.9.1	General	197
8.3.9.2	Initiation	
8.3.9.2a	Initiation of inter-RAT cell reselection to GERAN Iu mode	
8.3.9.3	Successful cell reselection.	
8.3.9.4	UE fails to complete an inter-RAT cell reselection.	
8.3.10	Inter-RAT cell change order to UTRAN	
8.3.10.1	General	
8.3.10.2	Initiation	
8.3.10.2	UE fails to complete an inter-RAT cell change order	
8.3.11	Inter-RAT cell change order from UTRAN	
8.3.11.1	General	
8.3.11.1	Initiation	
8.3.11.2	Reception of an CELL CHANGE ORDER FROM UTRAN message by the UE	
8.3.11.3	Successful completion of the cell change order	
8.3.11.5		
	Expiry of timer T309 or UE fails to complete requested cell change order	
8.3.11.6	Unsupported configuration in CELL CHANGE ORDER FROM UTRAN message	
8.3.11.7	Invalid CELL CHANGE ORDER FROM UTRAN message	
8.4	Measurement procedures	
8.4.0	Measurement related definitions	
8.4.1	Measurement control	
8.4.1.1	General	
8.4.1.2	Initiation	
8.4.1.3	Reception of MEASUREMENT CONTROL by the UE	
8.4.1.4	Unsupported measurement in the UE	
8.4.1.4a	Configuration Incomplete	
8.4.1.5	Invalid MEASUREMENT CONTROL message	
8.4.1.6	Measurements after transition from CELL_DCH to CELL_FACH/CELL_PCH/URA_PCH s	
8.4.1.6.1	Intra-frequency measurement	211
8.4.1.6.2	Inter-frequency measurement	211
8.4.1.6.3	Inter-RAT measurement	211
8.4.1.6.4	Quality measurement	212
8.4.1.6.5	UE internal measurement	212
8.4.1.6.6	Traffic volume measurement	212
8.4.1.6.7	UE positioning measurement	213
8.4.1.6a	Actions in CELL_FACH/CELL_PCH/URA/PCH state upon cell re-selection	
8.4.1.7	Measurements after transition from CELL_FACH to CELL_DCH state	
8.4.1.7.1	Intra-frequency measurement	
8.4.1.7.2	Inter-frequency measurement	
8.4.1.7.3	Inter-RAT measurement	
8.4.1.7.4	Traffic volume measurement	
8.4.1.7.5	UE positioning measurement	
8.4.1.8	Measurements after transition from idle mode to CELL_DCH state	
8.4.1.8.1	Intra-frequency measurement	
8.4.1.8.2	Inter-frequency measurement	
8.4.1.8.3	Inter-RAT measurement	
8.4.1.8.4	Traffic volume measurement	
8.4.1.8.5	UE positioning measurement	
8.4.1.9	Measurements after transition from idle mode to CELL_FACH state	
8.4.1.9.1		
8.4.1.9.2	Intra-frequency measurement	
	Inter-frequency measurement	
8.4.1.9.3	Inter-RAT measurement	
8.4.1.9.4	Traffic volume measurement	
8.4.1.9.5	UE positioning measurement.	
8.4.1.9a	Measurements after transition from connected mode to idle mode	
8.4.1.9a.1	Intra-frequency measurement	
8.4.1.9a.2	· •	
8.4.1.9a.3	Inter-RAT measurement	
8.4.1.9a.4		
8.4.1.9b	Measurements after transition from CELL_FACH to CELL_PCH/URA_PCH	
8.4.1.9b.1	Traffic volume measurement	
8.4.1.9c	Measurements after transition from CELL_PCH/URA_PCH to CELL_FACH	
8 / 1 9c 1	Traffic volume measurement	219

8.4.1.10	Changes in measurement objects	219
8.4.1.10.1	Traffic volume measurement	
8.4.1.10.2	Quality measurement	220
8.4.1.10.3	Intra-frequency, Inter-frequency and Inter-RAT measurements	220
8.4.2	Measurement report	220
8.4.2.1	General	220
8.4.2.2	Initiation	220
8.4.3	Assistance Data Delivery	222
8.4.3.1	General	
8.4.3.2	Initiation	
8.4.3.3	Reception of ASSISTANCE DATA DELIVERY message by the UE	
8.4.3.4	Invalid ASSISTANCE DATA DELIVERY message	
8.5	General procedures	
8.5.1	Selection of initial UE identity	
8.5.2	Actions when entering idle mode from connected mode	
8.5.3	Open loop power control upon establishment of DPCCH	
8.5.4	Physical channel establishment criteria	225
8.5.5	Actions in "out of service area" and "in service area"	
8.5.5.1	Detection of "out of service" area	
8.5.5.1.1	Actions following detection of "out of service" area in URA_PCH or CELL_PCH state	
8.5.5.1.2	Actions following detection of "out of service" area in CELL_FACH state	225
8.5.5.1.3	Actions following detection of "out of service" area on transition from CELL_DCH to	22.5
8.5.5.1.4	URA_PCH or CELL_PCH	223
8.3.3.1.4	CELL_FACH	226
8.5.5.2	Detection of "in service" area	
8.5.5.2.1	Actions following Re-entry into "in service area" in URA_PCH or CELL_PCH state	
8.5.5.2.2	Actions following re-entry into "in service area" in CELL_FACH state	
8.5.5.3	T316 expiry	
8.5.5.4	T317 expiry	
8.5.6	Radio link failure criteria and actions upon radio link failure	
8.5.7	Open loop power control	
8.5.8	Maintenance of Hyper Frame Numbers	
8.5.9	START value calculation	
8.5.10	Integrity protection	
8.5.10.1	Integrity protection in downlink	
8.5.10.2	Integrity protection in uplink	
8.5.10.3	Calculation of message authentication code	
8.5.11	FACH measurement occasion calculation	
8.5.12	Establishment of Access Service Classes	236
8.5.13	Mapping of Access Classes to Access Service Classes	237
8.5.14	PLMN Type Selection	
8.5.14a	Neighbour cells list narrowing for cell reselection	237
8.5.15	CFN calculation	
8.5.15.1	Initialisation for CELL_DCH state after state transition	
8.5.15.2	Initialisation in CELL_DCH state at hard handover	
8.5.15.3	Initialisation for CELL_FACH	
8.5.15.4	Initialisation after intersystem handover to UTRAN	
8.5.16	Configuration of CTCH occasions	
8.5.17	PRACH selection	
8.5.18	Selection of RACH TTI	
8.5.18.1	FDD	
8.5.18.2	1.28 Mcps TDD.	
8.5.19	Secondary CCPCH selection	
8.5.20	Unsupported configuration	
8.5.21 8.5.22	Actions related to Radio Bearer mapping	
8.5.22 8.5.23	Actions when entering another RAT from connected mode	
8.5.23 8.5.24	Change of PLMN while in RRC connected mode	
8.6	Generic actions on receipt and absence of an information element	
8.6.1	CN information elements	
8611	Void	247 247

8.6.1.2	CN information info	247
8.6.1.3	Signalling connection release indication	247
8.6.2	UTRAN mobility information elements	247
8.6.2.1	URA identity	247
8.6.2.2	Mapping info	248
8.6.3	UE information elements	248
8.6.3.1	Activation time	248
8.6.3.1a	CN domain specific DRX cycle length coefficient	249
8.6.3.1b	H-RNTI	249
8.6.3.2	UTRAN DRX Cycle length coefficient	250
8.6.3.3	Generic state transition rules depending on received information elements	250
8.6.3.4	Ciphering mode info	251
8.6.3.5	Integrity protection mode info	253
8.6.3.5.1	Initialisation of Integrity Protection	254
8.6.3.5.2	Integrity Protection Re-configuration for SRNS Relocation and handover from GERAN Iu	
	mode	255
8.6.3.5.3	Integrity Protection modification in case of new keys or initialisation of signalling connecti	on256
8.6.3.6	Void	257
8.6.3.7	Void	257
8.6.3.8	Integrity check info	257
8.6.3.9	New C-RNTI	257
8.6.3.9a	New DSCH-RNTI	257
8.6.3.10	New U-RNTI	257
8.6.3.11	RRC transaction identifier	258
8.6.3.12	Capability Update Requirement	261
8.6.3.13	Group release information	262
8.6.4	Radio bearer information elements	263
8.6.4.1	Signalling RB information to setup list	
8.6.4.2	RAB information for setup	264
8.6.4.2a	RAB information to reconfigure	
8.6.4.3	RB information to setup	
8.6.4.4	RB information to be affected	
8.6.4.5	RB information to reconfigure	
8.6.4.6	RB information to release	
8.6.4.7	RB with PDCP information	
8.6.4.8	RB mapping info	
8.6.4.9	RLC Info	
8.6.4.10	PDCP Info	
8.6.4.11	PDCP SN Info	
8.6.4.12	NAS Synchronisation Indicator	
8.6.4.13	PDCP context relocation info	
8.6.5	Transport channel information elements	
8.6.5.1	Transport Format Set	
8.6.5.2	Transport format combination set	
8.6.5.3	Transport format combination subset	
8.6.5.4	DCH quality target	
8.6.5.5	Added or Reconfigured UL TrCH information	
8.6.5.5a	Added or reconfigured MAC-d flow	
8.6.5.6	Added or Reconfigured DL TrCH information	
8.6.5.6a	Void	
8.6.5.6b	HARQ Info	
8.6.5.7	Deleted UL TrCH information	
8.6.5.8	Deleted DL TrCH information	
8.6.5.9	UL Transport channel information common for all transport channels	
8.6.5.10	DL Transport channel information common for all transport channels	
8.6.5.11	DRAC static information	
8.6.5.12 8.6.5.13	TFCS Reconfiguration/Addition Information	
8.6.5.13 8.6.5.14	TFCS Removal Information	
8.6.5.14 8.6.5.15	TFCI Field 2 Information	
	· · · · · · · · · · · · · · · · · · ·	
8.6.6 8.6.6 1	Physical channel information elements.	283 283

8.6.6.2	Void	283
8.6.6.2a	PNBSCH allocation	283
8.6.6.3	Void	283
8.6.6.3a	Downlink information per radio link list	283
8.6.6.4	Downlink information for each radio link	
8.6.6.5	Void	
8.6.6.6	Uplink DPCH info	
8.6.6.7	Void	
8.6.6.8	Maximum allowed UL TX power	
8.6.6.9	PDSCH with SHO DCH Info (FDD only)	
8.6.6.10	PDSCH code mapping (FDD only)	
8.6.6.11	Uplink DPCH power control info	
8.6.6.12	Secondary CPICH info	
8.6.6.13	Primary CPICH usage for channel estimation	
8.6.6.14	DPCH frame offset.	
8.6.6.15	DPCH Compressed mode info	
8.6.6.16	Repetition period, Repetition length, Offset (TDD only)	
8.6.6.17	Primary CCPCH info	
8.6.6.18	Primary CPICH info	
8.6.6.19	CPCH SET Info (FDD only)	
8.6.6.20	CPCH set ID (FDD only)	
8.6.6.21	Default DPCH Offset Value	
8.6.6.22	Secondary Scrambling Code, Code Number	
8.6.6.23	PDSCH Power Control info	
8.6.6.24	Tx Diversity Mode	
8.6.6.25	SSDT Information.	
8.6.6.26	UL Timing Advance Control (TDD only)	
8.6.6.26a	Uplink synchronisation parameters (TDD only)	
8.6.6.27	Downlink information common for all radio links	
8.6.6.28	Downlink DPCH info common for all radio links	
8.6.6.29	ASC setting	
8.6.6.30	SRB delay, PC preamble (FDD only)	
8.6.6.31	FPACH/PRACH Selection (1.28 Mcps TDD only)	
8.6.6.32	Downlink HS-PDSCH Information	
8.6.6.33	HS-SCCH Info	
8.6.6.34	Measurement Feedback Info	
8.6.6.35	DPC Mode	
8.6.7	Measurement information elements	
8.6.7.1	Measurement validity	
8.6.7.2	Filter coefficient	
8.6.7.3	Intra-frequency/Inter-frequency/Inter-RAT cell info list	
8.6.7.4	Intra-frequency measurement quantity	
8.6.7.5	Inter-RAT measurement quantity	
8.6.7.6	Inter-RAT reporting quantity	
8.6.7.7	Cell Reporting Quantities	
8.6.7.8	Periodical Reporting Criteria	
8.6.7.9	Reporting Cell Status	
8.6.7.10	Traffic Volume Measurement	
8.6.7.11	Traffic Volume Measurement Reporting Criteria	
8.6.7.12	FACH measurement occasion info	
8.6.7.13	Measurement Reporting Mode	
8.6.7.14	Inter-frequency measurement	
8.6.7.15	Inter-RAT measurement	
8.6.7.16	Intra-frequency measurement	
8.6.7.17	Quality measurement	
8.6.7.18	UE internal measurement	
8.6.7.18a	Void	
8.6.7.19a	UE positioning	
8.6.7.19 8.6.7.19.0	•	
8.6.7.19.0 8.6.7.19.1	UE positioning reporting quantity	
	UE positioning reporting quantity	
8.6.7.19.1a		
8.6.7.19.1b	UE positioning reporting for UE based methods	321

8.6.7.19.2		
8.6.7.19.2	2a UE positioning OTDOA assistance data for UE-based	323
8.6.7.19.3	3 UE positioning GPS assistance data	325
8.6.7.19.4		
8.6.7.19.5		
8.6.7.19.6		
8.6.7.20	Void	
8.6.7.21	Intra-frequency reporting quantity for RACH reporting	
8.6.7.22	Additional Measurement List	330
8.6.8	Void	331
9 H	andling of unknown, unforeseen and erroneous protocol data	331
9.1	General	
9.2	ASN.1 violation or encoding error	
9.3	Unknown or unforeseen message type	
9.3a	Unsolicited received message	
9.3b	Unexpected critical message extension	
9.4	Unknown or unforeseen information element value, mandatory information element	
9.5	Conditional information element error	
9.6	Unknown or unforeseen information element value, conditional information element	
9.7	Unknown or unforeseen information element value, optional information element	
9.8	Unexpected non-critical message extension	
9.9	Handling of errors in nested information elements	
	•	
	lessage and information element functional definition and content	
10.1	General	
10.1.1	Protocol extensions	
10.1.1.1	Non-critical extensions	
10.1.1.1.1		
10.1.1.1.2	$\boldsymbol{\varepsilon}$	
10.1.1.2	Critical extensions	
10.1.1.2.1 10.1.1.2.2		
10.1.1.2.2	Radio Resource Control messages	
10.2.1	ACTIVE SET UPDATE	
10.2.1	ACTIVE SET UPDATE COMPLETE	
10.2.2	ACTIVE SET UPDATE FAILURE	
10.2.4	ASSISTANCE DATA DELIVERY	
10.2.5	CELL CHANGE ORDER FROM UTRAN	
10.2.6	CELL CHANGE ORDER FROM UTRAN FAILURE	
10.2.7	CELL UPDATE	
10.2.8	CELL UPDATE CONFIRM.	
10.2.9	COUNTER CHECK	
10.2.10	COUNTER CHECK RESPONSE	
10.2.11	DOWNLINK DIRECT TRANSFER	
10.2.12	Void	350
10.2.13	Void	350
10.2.14	Void	351
10.2.15	HANDOVER FROM UTRAN COMMAND	351
10.2.16	HANDOVER FROM UTRAN FAILURE	353
10.2.16a	HANDOVER TO UTRAN COMMAND	354
10.2.16b	HANDOVER TO UTRAN COMPLETE	356
10.2.16c	INITIAL DIRECT TRANSFER	
10.2.16d	INTER RAT HANDOVER INFO	
10.2.17	MEASUREMENT CONTROL	
10.2.18	MEASUREMENT CONTROL FAILURE	
10.2.19	MEASUREMENT REPORT	
10.2.20	PAGING TYPE 1	
10.2.21	PAGING TYPE 2	
10.2.22	PHYSICAL CHANNEL RECONFIGURATION	
10.2.23	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	
10 2 24	PHYSICAL CHANNEL RECONEIGURATION FAILURE	364

10.2.25	PHYSICAL SHARED CHANNEL ALLOCATION	
10.2.26	PUSCH CAPACITY REQUEST	
10.2.27	RADIO BEARER RECONFIGURATION	
10.2.28	RADIO BEARER RECONFIGURATION COMPLETE	371
10.2.29	RADIO BEARER RECONFIGURATION FAILURE	372
10.2.30	RADIO BEARER RELEASE	372
10.2.31	RADIO BEARER RELEASE COMPLETE	375
10.2.32	RADIO BEARER RELEASE FAILURE	376
10.2.33	RADIO BEARER SETUP	377
10.2.34	RADIO BEARER SETUP COMPLETE	380
10.2.35	RADIO BEARER SETUP FAILURE	
10.2.36	RRC CONNECTION REJECT	
10.2.37	RRC CONNECTION RELEASE	
10.2.38	RRC CONNECTION RELEASE COMPLETE	
10.2.39	RRC CONNECTION REQUEST	
10.2.40	RRC CONNECTION SETUP	
10.2.41	RRC CONNECTION SETUP COMPLETE	
10.2.41a	RRC FAILURE INFO	
10.2.42	RRC STATUS	
10.2.43	SECURITY MODE COMMAND	
10.2.44	SECURITY MODE COMPLETE	
10.2.45	SECURITY MODE FAILURE	
10.2.46	SIGNALLING CONNECTION RELEASE	
10.2.47	SIGNALLING CONNECTION RELEASE INDICATION	
10.2.48	SYSTEM INFORMATION	
10.2.48.1	First Segment	
10.2.48.2	First Segment (short)	
10.2.48.3	Subsequent Segment	
10.2.48.4	Last Segment	
10.2.48.5	Last Segment (short)	
10.2.48.6	Complete SIB	
10.2.48.7	Complete SIB (short)	
10.2.48.7	System Information Blocks	
10.2.48.8.1	Master Information Block	
10.2.48.8.2	Scheduling Block 1	
10.2.48.8.3	Scheduling Block 2	
10.2.48.8.4	System Information Block type 1	
10.2.48.8.5	System Information Block type 2	
10.2.48.8.6	System Information Block type 3	
10.2.48.8.7	System Information Block type 4	
10.2.48.8.8	System Information Block type 5	
10.2.48.8.9	System Information Block type 6	
10.2.48.8.10	System Information Block type 7	
10.2.48.8.11	System Information Block type 8	
10.2.48.8.12	System Information Block type 9	
10.2.48.8.13	System Information Block type 10	
10.2.48.8.14	System Information Block type 11	
10.2.48.8.15	System Information Block type 12	
10.2.48.8.16	System Information Block type 13	
10.2.48.8.16.1	*	
10.2.48.8.16.2	J 11	
10.2.48.8.16.3	, , , , , , , , , , , , , , , , , , ,	
10.2.48.8.16.4	31	
10.2.48.8.17	System Information Block type 14	
10.2.48.8.18	System Information Block type 15	
10.2.48.8.18.1	*	
10.2.48.8.18.2	•	
10.2.48.8.18.3	*	
10.2.48.8.18.4	•	
10.2.48.8.19	System Information Block type 16	
10.2.48.8.20	System Information Block type 17	
10.2.48.8.21	System Information Block type 18	408

10.2.49	SYSTEM INFORMATION CHANGE INDICATION	
10.2.50	TRANSPORT CHANNEL RECONFIGURATION	
10.2.51	TRANSPORT CHANNEL RECONFIGURATION COMPLETE	
10.2.52	TRANSPORT CHANNEL RECONFIGURATION FAILURE	
10.2.53	TRANSPORT FORMAT COMBINATION CONTROL	
10.2.54	TRANSPORT FORMAT COMBINATION CONTROL FAILURE	
10.2.55	UE CAPABILITY ENQUIRY	414
10.2.56	UE CAPABILITY INFORMATION	414
10.2.57	UE CAPABILITY INFORMATION CONFIRM	415
10.2.58	UPLINK DIRECT TRANSFER	415
10.2.59	UPLINK PHYSICAL CHANNEL CONTROL	
10.2.60	URA UPDATE	
10.2.61	URA UPDATE CONFIRM	
10.2.62	UTRAN MOBILITY INFORMATION	
10.2.63	UTRAN MOBILITY INFORMATION CONFIRM	
10.2.64	UTRAN MOBILITY INFORMATION CONTINU	
	Information element functional definitions	
10.3 10.3.1	CN Information elements	
10.3.1.1	CN domain identity	
10.3.1.2	CN Domain System Information	
10.3.1.3	CN Information info	
10.3.1.3a	CN Information info full	
10.3.1.4	IMEI	
10.3.1.5	IMSI (GSM-MAP)	
10.3.1.6	Intra Domain NAS Node Selector	
10.3.1.7	Location Area Identification	425
10.3.1.8	NAS message	426
10.3.1.9	NAS system information (GSM-MAP)	426
10.3.1.10	Paging record type identifier	426
10.3.1.11	PLMN identity	426
10.3.1.12	PLMN Type	427
10.3.1.13	P-TMSI (GSM-MAP)	427
10.3.1.14	RAB identity	427
10.3.1.15	Routing Area Code	427
10.3.1.16	Routing Area Identification	428
10.3.1.17	TMSI (GSM-MAP)	
10.3.2	UTRAN mobility Information elements	
10.3.2.1	Cell Access Restriction	
10.3.2.2	Cell identity	
10.3.2.3	Cell selection and re-selection info for SIB3/4	
10.3.2.4	Cell selection and re-selection info for SIB11/12	
10.3.2.5	Mapping Info.	
10.3.2.6	URA identity	
10.3.2.0	UE Information elements	
10.3.3.1	Activation time	
10.3.3.1	Capability Update Requirement	
10.3.3.2	Cell update cause	
10.3.3.4	1	
	Ciphering Algorithm	
10.3.3.5	Ciphering mode info	
10.3.3.6	CN domain specific DRX cycle length coefficient	
10.3.3.7	CPCH Parameters	
10.3.3.8	C-RNTI	
10.3.3.9	DRAC system information	
10.3.3.9a	DSCH-RNTI	
10.3.3.10	Void	
10.3.3.11	Establishment cause	
10.3.3.12	Expiration Time Factor	
10.3.3.13	Failure cause	
10.3.3.14	Failure cause and error information	
10.3.3.14	Group release information	440
10.3.3.14	H-RNTI	440
10 3 3 15	Initial IIE identity	440

10.3.3.16	Integrity check info	441
10.3.3.17	Integrity protection activation info	441
10.3.3.18	Integrity protection Algorithm	442
10.3.3.19	Integrity protection mode info	442
10.3.3.19a	Void	442
10.3.3.20	Maximum bit rate	442
10.3.3.21	Measurement capability	443
10.3.3.21a	Measurement capability extension	445
10.3.3.22	Paging cause	447
10.3.3.23	Paging record	447
10.3.3.24	PDCP capability	449
10.3.3.25	Physical channel capability	449
10.3.3.26	Protocol error cause	452
10.3.3.27	Protocol error indicator	453
10.3.3.28	RB timer indicator	453
10.3.3.29	Redirection info	453
10.3.3.30	Re-establishment timer	453
10.3.3.31	Rejection cause	454
10.3.3.32	Release cause	
10.3.3.32a	RF Capability Compressed	454
10.3.3.33	RF capability FDD	455
10.3.3.33a	RF capability FDD extension	455
10.3.3.33b	RF capability TDD	455
10.3.3.33c	RF capability TDD 1.28 Mcps	
10.3.3.34	RLC capability	
10.3.3.35	RLC re-establish indicator	
10.3.3.35o	RRC connection release information	456
10.3.3.35a	RRC State Indicator	
10.3.3.36	RRC transaction identifier	457
10.3.3.37	Security capability	457
10.3.3.38	START	
10.3.3.39	Transmission probability	
10.3.3.40	Transport channel capability	
10.3.3.41	UE multi-mode/multi-RAT capability	
10.3.3.42	UE radio access capability	
10.3.3.42o	UE radio access capability compressed	
10.3.3.42a	UE radio access capability extension	
10.3.3.42b	UE security information	
10.3.3.43	UE Timers and Constants in connected mode	
10.3.3.44	UE Timers and Constants in idle mode	
10.3.3.45	UE positioning capability	
10.3.3.46	URA update cause	
10.3.3.47	U-RNTI	
10.3.3.47a	U-RNTI group	
10.3.3.48	U-RNTI Short	
10.3.3.49	UTRAN DRX cycle length coefficient	
10.3.3.50	Wait time	
10.3.3.51	UE Specific Behaviour Information 1 idle	
10.3.3.52	UE Specific Behaviour Information 1 interRAT	
10.3.4	Radio Bearer Information elements	
10.3.4.0	Default configuration identity	
10.3.4.1	Downlink RLC STATUS info.	
10.3.4.1a	PDCP context relocation info	
10.3.4.2	PDCP SN info	
10.3.4.3	PDCP SN info	
10.3.4.4	Productional configuration identity	
10.3.4.5	Predefined configuration identity	
10.3.4.5a	Predefined configuration status information	
10.3.4.5b	Predefined configuration status information compressed	
10.3.4.6	Predefined Configuration value tag	
10.3.4.7	Predefined RB configuration	4/3 //73

10.3.4.9	RAB info Post	474
10.3.4.10	RAB information for setup	474
10.3.4.11	RAB information to reconfigure	
10.3.4.12	NAS Synchronization indicator	474
10.3.4.13	RB activation time info	
10.3.4.14	RB COUNT-C MSB information	
10.3.4.15	RB COUNT-C information	
10.3.4.16	RB identity	
10.3.4.17	RB information to be affected	
10.3.4.18	RB information to reconfigure	
10.3.4.19	RB information to release	
10.3.4.20	RB information to setup	
10.3.4.21	RB mapping info	
10.3.4.22	RB with PDCP information	
10.3.4.23	RLC info	
10.3.4.24	Signalling RB information to setup	
10.3.4.25	Transmission RLC Discard	481
10.3.5	Transport CH Information elements	
10.3.5.1	Added or Reconfigured DL TrCH information	
10.3.5.1a	Added or reconfigured MAC-d flow	
10.3.5.2	Added or Reconfigured UL TrCH information	
10.3.5.3	CPCH set ID.	
10.3.5.4	Deleted DL TrCH information	
10.3.5.5	Deleted UL TrCH information	
10.3.5.6	DL Transport channel information common for all transport channels	
10.3.5.7	DRAC Static Information	
10.3.5.7a	HARQ Info	
10.3.5.7b	Void	
10.3.5.7c	MAC-d Flow Identity	
10.3.5.8	Power Offset Information	
10.3.5.9	Predefined TrCH configuration	
10.3.5.10	Quality Target	
10.3.5.11	Semi-static Transport Format Information	
10.3.5.12	TFCI Field 2 Information	
10.3.5.13	TFCS Explicit Configuration	
10.3.5.14	TFCS Information for DSCH (TFCI range method)	
10.3.5.15	TFCS Reconfiguration/Addition Information	
10.3.5.16	TFCS Removal Information	493
10.3.5.17	Void	
10.3.5.18	Transport channel identity	
10.3.5.19	Transport Format Combination (TFC)	493
10.3.5.20	Transport Format Combination Set	
10.3.5.21	Transport Format Combination Set Identity	
10.3.5.22	Transport Format Combination Subset	
10.3.5.23	Transport Format Set	495
10.3.5.24	UL Transport channel information common for all transport channels	497
10.3.6	Physical CH Information elements	
10.3.6.1	AC-to-ASC mapping	
10.3.6.2	AICH Info	499
10.3.6.3	AICH Power offset	499
10.3.6.4	Allocation period info	499
10.3.6.5	Alpha	
10.3.6.6	ASC setting	
10.3.6.7	Void	
10.3.6.8	CCTrCH power control info	
10.3.6.8a	Cell and Channel Identity info	
10.3.6.9	Cell parameters Id	
10.3.6.10	Common timeslot info	
10.3.6.11	Constant value	
10.3.6.11a	Constant value TDD	503
10.3.6.12	CPCH persistence levels	503
10 3 6 13	CPCH set info	503

10.3.6.14	CPCH Status Indication mode	505
10.3.6.15	CSICH Power offset	506
10.3.6.16	Default DPCH Offset Value	506
10.3.6.17	Downlink channelisation codes	506
10.3.6.18	Downlink DPCH info common for all RL	507
10.3.6.19	Downlink DPCH info common for all RL Post	
10.3.6.20	Downlink DPCH info common for all RL Pre	508
10.3.6.21	Downlink DPCH info for each RL	509
10.3.6.22	Downlink DPCH info for each RL Post	511
10.3.6.23	Downlink DPCH power control information	512
10.3.6.23a	Downlink HS-PDSCH Information	
10.3.6.24	Downlink information common for all radio links	512
10.3.6.25	Downlink information common for all radio links Post	513
10.3.6.26	Downlink information common for all radio links Pre	513
10.3.6.27	Downlink information for each radio link	513
10.3.6.28	Downlink information for each radio link Post	514
10.3.6.29	Void	515
10.3.6.30	Downlink PDSCH information	515
10.3.6.31	Downlink rate matching restriction information	515
10.3.6.32	Downlink Timeslots and Codes	515
10.3.6.33	DPCH compressed mode info	516
10.3.6.34	DPCH Compressed Mode Status Info	519
10.3.6.35	Dynamic persistence level	520
10.3.6.35a	FPACH info	520
10.3.6.36	Frequency info	520
10.3.6.3600	HS-PDSCH Midamble Configuration	520
10.3.6.36o	HS-PDSCH Timeslot Configuration	
10.3.6.36a	HS-SCCH Info	523
10.3.6.36b	HS-SICH Power Control Info	
10.3.6.37	Individual timeslot info	
10.3.6.38	Individual Timeslot interference	
10.3.6.39	Maximum allowed UL TX power	
10.3.6.40	Void	
10.3.6.40a	Measurement Feedback Info	
10.3.6.41	Midamble shift and burst type	
10.3.6.42	PDSCH Capacity Allocation info	
10.3.6.43	PDSCH code mapping	
10.3.6.44	PDSCH info	
10.3.6.45	PDSCH Power Control info	
10.3.6.46	PDSCH system information	
10.3.6.47	PDSCH with SHO DCH Info	
10.3.6.48	Persistence scaling factors	
10.3.6.49	PICH Info	
10.3.6.50	PICH Power offset	
10.3.6.51	PRACH Channelisation Code List	
10.3.6.51a	PRACH Channelisation Code 1.28 Mcps TDD	
10.3.6.52	PRACH info (for RACH)	
10.3.6.53	PRACH partitioning	
10.3.6.54	PRACH power offset	
10.3.6.55	PRACH system information list	
10.3.6.56	Predefined PhyCH configuration	
10.3.6.57	Primary CCPCH info	
10.3.6.58	Primary CCPCH TV Payer	
10.3.6.59	Primary CPICH info	
10.3.6.60	Primary CPICH Ty power	
10.3.6.61	Primary CPICH years for shapped setimation	
10.3.6.62	Primary CPICH usage for channel estimation	
10.3.6.63	PUSCH infoPUSCH Capacity Allocation info	
10.3.6.64	± •	
10.3.6.65	PUSCH system information	
10.3.6.66	PUSCH system information	540 5/1

10.3.6.68	Radio link addition information	541
10.3.6.69	Radio link removal information	
10.3.6.70	SCCPCH Information for FACH	
10.3.6.70a	SCTD indicator	
10.3.6.71	Secondary CCPCH info	
10.3.6.72	Secondary CCPCH system information	
10.3.6.73	Secondary CPICH info	
10.3.6.74	Secondary scrambling code	
10.3.6.75	SFN Time info	
10.3.6.75a	Special Burst Scheduling	
10.3.6.76	SSDT cell identity	
10.3.6.77	SSDT information	
10.3.6.78	STTD indicator	
10.3.6.78a	SYNC_UL info	
10.3.6.79 10.3.6.80	TDD open loop power control	
10.3.6.81	TFC Combining Indicator	
10.3.6.82	TGPSI	
10.3.6.83	Time info	
10.3.6.84	Time life	
10.3.6.85	TPC combination index.	
10.3.6.85a	TSTD indicator	
10.3.6.86	TX Diversity Mode	
10.3.6.87	UL interference	
10.3.6.87a	UL interference TDD	
10.3.6.88	Uplink DPCH info	
10.3.6.89	Uplink DPCH info Post	
10.3.6.90	Uplink DPCH info Pre	
10.3.6.91	Uplink DPCH power control info	
10.3.6.92	Uplink DPCH power control info Post	
10.3.6.93	Uplink DPCH power control info Pre	
10.3.6.94	Uplink Timeslots and Codes	554
10.3.6.95	Uplink Timing Advance	
10.3.6.96	Uplink Timing Advance Control	
10.3.7	Measurement Information elements	
10.3.7.1	Additional measurements list	
10.3.7.2	Cell info	
10.3.7.3	Cell measured results	
10.3.7.4	Cell measurement event results	
10.3.7.5	Cell reporting quantities	
10.3.7.6	Cell synchronisation information	
10.3.7.7	Event results	
10.3.7.8	FACH measurement occasion info	
10.3.7.9 10.3.7.10	Filter coefficient	
10.3.7.11 10.3.7.12	HCS neighbouring cell information	
10.3.7.12	Inter-frequency cell info list	
10.3.7.13	Inter-frequency event identity	
10.3.7.14	Inter-frequency measured results list	
10.3.7.16	Inter-frequency measurement	
10.3.7.17	Inter-frequency measurement event results	
10.3.7.17	Inter-frequency measurement quantity	
10.3.7.19	Inter-frequency measurement reporting criteria	
10.3.7.20	Inter-frequency measurement system information	
10.3.7.21	Inter-frequency reporting quantity	
10.3.7.22	Inter-frequency SET UPDATE	
10.3.7.23	Inter-RAT cell info list	
10.3.7.24	Inter-RAT event identity	
10.3.7.25	Inter-RAT info	
10.3.7.26	Inter-RAT measured results list	
10.3.7.27	Inter-RAT measurement	571

10.3.7.28	Inter-RAT measurement event results	
10.3.7.29	Inter-RAT measurement quantity	
10.3.7.30	Inter-RAT measurement reporting criteria	
10.3.7.31	Inter-RAT measurement system information	573
10.3.7.32	Inter-RAT reporting quantity	573
10.3.7.33	Intra-frequency cell info list	574
10.3.7.34	Intra-frequency event identity	574
10.3.7.35	Intra-frequency measured results list	575
10.3.7.36	Intra-frequency measurement	575
10.3.7.37	Intra-frequency measurement event results	575
10.3.7.38	Intra-frequency measurement quantity	
10.3.7.39	Intra-frequency measurement reporting criteria	576
10.3.7.40	Intra-frequency measurement system information	
10.3.7.41	Intra-frequency reporting quantity	580
10.3.7.42	Intra-frequency reporting quantity for RACH reporting	
10.3.7.43	Maximum number of reported cells on RACH	581
10.3.7.44	Measured results	581
10.3.7.45	Measured results on RACH	582
10.3.7.46	Measurement Command	
10.3.7.47	Measurement control system information	584
10.3.7.48	Measurement Identity	584
10.3.7.49	Measurement reporting mode	585
10.3.7.50	Measurement Type	585
10.3.7.51	Measurement validity	585
10.3.7.52	Observed time difference to GSM cell	585
10.3.7.53	Periodical reporting criteria	586
10.3.7.53aa	Periodical reporting info-1b	586
10.3.7.53a	PLMN identities of neighbour cells	586
10.3.7.54	Primary CCPCH RSCP info	587
10.3.7.54a	Qhcs	587
10.3.7.55	Quality measured results list	589
10.3.7.56	Quality measurement	590
10.3.7.57	Quality measurement event results	590
10.3.7.58	Quality measurement reporting criteria	590
10.3.7.59	Quality reporting quantity	591
10.3.7.60	Reference time difference to cell	591
10.3.7.61	Reporting Cell Status	
10.3.7.62	Reporting information for state CELL_DCH	
10.3.7.63	SFN-SFN observed time difference	
10.3.7.64	Time to trigger	594
10.3.7.65	Timeslot ISCP info	594
10.3.7.66	Traffic volume event identity	595
10.3.7.67	Traffic volume measured results list	595
10.3.7.68	Traffic volume measurement	
10.3.7.69	Traffic volume measurement event results	596
10.3.7.70	Traffic volume measurement object	597
10.3.7.71	Traffic volume measurement quantity	597
10.3.7.72	Traffic volume measurement reporting criteria	598
10.3.7.73	Traffic volume measurement system information	599
10.3.7.74	Traffic volume reporting quantity	599
10.3.7.75	UE internal event identity	599
10.3.7.76	UE internal measured results	600
10.3.7.77	UE internal measurement	601
10.3.7.78	UE internal measurement event results	601
10.3.7.79	UE internal measurement quantity	
10.3.7.80	UE internal measurement reporting criteria	602
10.3.7.81	Void	
10.3.7.82	UE Internal reporting quantity	
10.3.7.83	UE Rx-Tx time difference type 1	
10.3.7.84	UE Rx-Tx time difference type 2	
10.3.7.85	UE Transmitted Power info	
10.3.7.86	UE positioning Ciphering info	604

10.3.7.87	UE positioning Error	605
10.3.7.88	UE positioning GPS acquisition assistance	
10.3.7.88a	UE positioning GPS Additional Assistance Data Request	
10.3.7.89	UE positioning GPS almanac	608
10.3.7.90	UE positioning GPS assistance data	
10.3.7.90a	Void	
10.3.7.91	UE positioning GPS DGPS corrections	
10.3.7.91a	UE positioning GPS Ephemeris and Clock Correction parameters	
10.3.7.92	UE positioning GPS ionospheric model	
10.3.7.93	UE positioning GPS measured results	
10.3.7.94	UE positioning GPS navigation model	
10.3.7.95	UE positioning GPS real-time integrity	
10.3.7.95a	Void	
10.3.7.96	UE positioning GPS reference time	
10.3.7.97	UE positioning GPS UTC model	
10.3.7.98	UE positioning IPDL parameters	
10.3.7.99	UE positioning measured results	
10.3.7.100	UE positioning measurement	
10.3.7.101	UE positioning measurement event results	
10.3.7.102	Void	
10.3.7.103	UE positioning OTDOA assistance data for UE-assisted	
10.3.7.103a	UE positioning OTDOA assistance data for UE-based	
10.3.7.104	Void	
10.3.7.105	UE positioning OTDOA measured results	
10.3.7.106	UE positioning OTDOA neighbour cell info	
10.3.7.106a	UE positioning OTDOA neighbour cell info for UE-based	
10.3.7.107	UE positioning OTDOA quality	
10.3.7.108	UE positioning OTDOA reference cell info	
10.3.7.108a	UE positioning OTDOA reference cell info for UE-based	
10.3.7.109	UE positioning position estimate info	
10.3.7.109a	UE positioning Relative Time Difference quality	
10.3.7.110	UE positioning reporting criteria.	
10.3.7.111 10.3.7.112	UE positioning reporting quantity	
10.3.8	Other Information elements	
10.3.8.1	BCCH modification info	
10.3.8.2	BSIC	
10.3.8.3	CBS DRX Level 1 information	
10.3.8.4	Cell Value tag	
10.3.8.4a	Ellipsoid point	
10.3.8.4b	Ellipsoid point with Altitude	
10.3.8.4c	Ellipsoid point with Altitude and uncertainty ellipsoid	
10.3.8.4d	Ellipsoid point with uncertainty Circle	
10.3.8.4e 10.3.8.4f	Ellipsoid point with uncertainty Ellipse	
10.3.8.5	GERAN system information	
10.3.8.6	Inter-RAT change failure Inter-RAT handover failure	
10.3.8.7	Inter-RAT Handover failure Inter-RAT UE radio access capability	
10.3.8.7		
10.3.8.8a	Void Inter-RAT UE security capability	
10.3.8.9	MIB Value tag	
10.3.8.10	PLMN Value tag	
10.3.8.10 10.3.8.10a	PNBSCH allocation	
10.3.8.10a	Predefined configuration identity and value tag	
10.3.8.11	Protocol error information	
10.3.8.12	References to other system information blocks	
10.3.8.13	References to other system information blocks and scheduling blocks	
10.3.8.14	Rplmn information	
10.3.8.16	Scheduling information	
10.3.8.17	SEG COUNT	
10.3.8.17	Segment index	638

10.3.8.18	a SIB and SB type	638
10.3.8.19	SIB data fixed	639
10.3.8.20	SIB data variable	639
10.3.8.20	a SIB occurrence identity	640
10.3.8.20	b SIB occurrence identity and value tag	640
10.3.8.20	SIB occurrence value tag	640
10.3.8.21	SIB type	640
10.3.8.22	SIB type SIBs only	641
10.3.9	ANSI-41 Information elements	
10.3.9.1	ANSI 41 Core Network Information	
10.3.9.2	ANSI-41 Global Service Redirection information	642
10.3.9.3	ANSI-41 NAS parameter	643
10.3.9.4	ANSI-41 NAS system information	643
10.3.9.5	ANSI-41 Private Neighbour List information	643
10.3.9.6	ANSI-41 RAND information	643
10.3.9.7	ANSI-41 User Zone Identification information	643
10.3.9.8	MIN_P_REV	644
10.3.9.9	NID	644
10.3.9.10	P_REV	644
10.3.9.11	SID	
10.3.10	Multiplicity values and type constraint values	
11.0	General	
11.1	General message structure	
11.2	PDU definitions	
11.3	Information element definitions	
11.4	Constant definitions.	
11.5	RRC information between network nodes.	
	essage transfer syntax	
12.1	Structure of encoded RRC messages	
12.1.1	Basic production	
12.1.2	Extension	
12.1.3	Padding	
12.2	ECN link module for RRC	
12.3	ECN modules for RRC	
12.4	RRC messages encoded otherwise	
12.4.1	Messages using tabular encoding specification	
12.4.1.1	TRANSPORT FORMAT COMBINATION CONTROL using transparent DCCH	
12.4.1.1.1		856
12.4.1.1.2		
12.4.1.1.3	TRANSPORT FORMAT COMBINATION CONTROL, 10 bit format	856
13 Pr	otocol timers, counters, other parameters and default configurations	857
13.1	Timers for UE	857 857
13.1	Counters for UE	
13.2	UE constants and parameters.	
13.4	UE variables	
13.4.0	CELL INFO LIST	
13.4.00	Void	
13.4.00 13.4.0a	CELL_UPDATE_STARTED	
	CIPHERING STATUS	
13.4.1 13.4.2		
	Void CONFIGURATION_INCOMPLETE	
13.4.2a 13.4.3		
	C_RNTI DSCH RNTI	
13.4.3a	-	
13.4.4	Void	
13.4.5	ESTABLISHED_RABSESTABLISHED_SIGNALLING_CONNECTIONS	86]
13.4.5a 13.4.6	ESTABLISHED_SIGNALLING_CONNECTIONS ESTABLISHMENT_CAUSE	
13.4.6	FAILURE CAUSEFAILURE CAUSE	
13.4.7	FAILURE_CAUSEFAILURE INDICATOR	
13.4.8	H RNTI	802 863

13.4.800	HS_DSCH_RECEPTION	
13.4.8a	INCOMPATIBLE_SECURITY_RECONFIGURATION	863
13.4.9	INITIAL_UE_IDENTITY	
13.4.9a	INTEGRITY_PROTECTION_ACTIVATION_INFO	864
13.4.10	INTEGRITY_PROTECTION_INFO	864
13.4.10a	INTER_RAT_HANDOVER_INFO_TRANSFERRED	864
13.4.11	INVALID_CONFIGURATION	866
13.4.11a	LATEST_CONFIGURED_CN_DOMAIN	866
13.4.11b	LATEST_CONFIGURED_SRB_DELAY_AND_PC_PREAMBLE	866
13.4.12	MEASUREMENT_IDENTITY	866
13.4.13	Void	867
13.4.14	ORDERED_RECONFIGURATION	
13.4.15	PDCP_SN_INFO	
13.4.15a	PHYSICAL_SHARED_CHANNEL_CONFIGURATION	
13.4.16	PROTOCOL_ERROR_INDICATOR	
13.4.17	PROTOCOL_ERROR_INFORMATION	
13.4.18	PROTOCOL_ERROR_REJECT	
13.4.19	RB_TIMER_INDICATOR	
13.4.20	RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO	
13.4.20a	SECURITY_MODIFICATION	
13.4.21	SELECTED_PLMN	
13.4.22	START_THRESHOLD	
13.4.23	START_VALUE_TO_TRANSMIT	
13.4.24	TFC_SUBSET	
13.4.25	TGPS_IDENTITY	
13.4.26	TGSN_REPORTED	
13.4.26a	TIMERS_AND_CONSTANTS	
13.4.27	TRANSACTIONS	
13.4.27a	TRIGGERED_1A_EVENT	
13.4.27b	TRIGGERED_1G_EVENT	
13.4.27c 13.4.27d	TRIGGERED_1C_EVENT BEST CELL 1D EVENT	
13.4.27u 13.4.27e	TRIGGERED 1E EVENT	
13.4.27f	TRIGGERED 1F EVENT	
13.4.27f1	TRIGGERED_1G_EVENT	
13.4.27f2	TRIGGERED 1H EVENT	
13.4.27f3	TRIGGERED 11 EVENT	
13.4.27f4	BEST_FREQUENCY_2A_EVENT	
13.4.27f5	TRIGGERED_2B_EVENT	
13.4.27f6	TRIGGERED_2C_EVENT	
13.4.27f7	TRIGGERED_2D_EVENT	
13.4.27f8	TRIGGERED_2E_EVENT	
13.4.27f9	TRIGGERED_2F_EVENT	
13.4.27f10	TRIGGERED_3A_EVENT	878
13.4.27f11	TRIGGERED_3B_EVENT	879
13.4.27f12	TRIGGERED_3C_EVENT	879
13.4.27f13	BEST_CELL_3D_EVENT	879
13.4.27f14	TRIGGERED_6A_EVENT	880
13.4.27f15	TRIGGERED_6B_EVENT	
13.4.27f16	TRIGGERED_6C_EVENT	
13.4.27f17	TRIGGERED_6D_EVENT	
13.4.27f18	TRIGGERED_6E_EVENT	
13.4.27f19	TRIGGERED_6F_EVENT	
13.4.27f20	TRIGGERED_6G_EVENT	
13.4.27g	UE_CAPABILITY_REQUESTED	
13.4.28	UE_CAPABILITY_TRANSFERRED	
13.4.28a	UE_POSITIONING_GPS_DATA_UE_AGGISTED	
13.4.28b	UE_POSITIONING_OTDOA_DATA_UE_ASSISTED	
13.4.28c	UE_POSITIONING_OTDOA_DATA_UE_BASED	
13.4.29 13.4.30	UNSUPPORTED_CONFIGURATIONURA IDENTITY	
13.4.30	U RNTI	
10.7.01	V 111111	

13.4.32	VALUE_TAG	885
13.5	UE RRC Procedure Performance	886
13.5.1	Definitions	
13.5.2	RRC procedure performance values	887
13.6	RB information parameters for signalling radio bearer RB 0	892
13.6a	RB information parameters for SHCCH	892
13.6b	RB information parameters for BCCH mapped to FACH	892
13.6c	RB information parameters for PCCH mapped to PCH	893
13.6d	Parameters for BCCH mapped to BCH	893
13.7	Parameter values for default radio configurations	893
14 C.	pecific functions	024
14 S ₁ 14.1	Intra-frequency measurements	
14.1 14.1.1	1 7	
14.1.1	Intra-frequency measurement quantities	
14.1.2.1	Intra-frequency reporting events for FDD	
14.1.2.1		
	Reporting event 1B: A primary CPICH leaves the reporting range	
14.1.2.3	Reporting event 1C: A non-active primary CPICH becomes better than an active primary CPICH	
14.1.2.4 14.1.2.5	Reporting event 1D: Change of best cell	
14.1.2.5	Reporting event 1E: A Primary CPICH becomes better than an absolute threshold	
	•	
14.1.3	Intra-frequency reporting events for TDD	
14.1.3.1	Reporting event 1G: Change of best cell (TDD)	
14.1.3.2	Reporting event 1H: Timeslot ISCP below a certain threshold (TDD)	
14.1.3.3	Reporting event 1I: Timeslot ISCP above a certain threshold (TDD)	
14.1.4	Event-triggered periodic intra-frequency measurement reports (informative)	
14.1.4.1	Cell addition failure (FDD only)	
14.1.4.1a 14.1.4.2		
14.1.4.2	Cell replacement failure (FDD only)	943
14.1.3	Mechanisms available for modifying intra-frequency measurement reporting behaviour (informative)	042
14.1.5.1	Hysteresis	
14.1.5.1	Time-to-trigger	
	Cell individual offsets	
14.1.5.3 14.1.5.4	Forbid a Primary CPICH to affect the reporting range (FDD only)	
14.1.5.4	Report quantities in intra-frequency measurements	
14.1.0	Inter-frequency measurements	
14.2.0a	Inter-frequency measurement quantities	
14.2.0b	Frequency quality estimate	
14.2.0b.1		
14.2.0b.1 14.2.0b.2		
14.2.0c.2 14.2.0c	Inter-frequency reporting quantities	
14.2.1	Inter-frequency reporting quantities Inter-frequency reporting events	
14.2.1.1	Event 2a: Change of best frequency.	
14.2.1.2	Event 2b: The estimated quality of the currently used frequency is below a certain threshold and	950
17.2.1.2	the estimated quality of a non-used frequency is above a certain threshold	951
14.2.1.3	Event 2c: The estimated quality of a non-used frequency is above a certain threshold	
14.2.1.4	Event 2d: The estimated quality of the currently used frequency is below a certain threshold	
14.2.1.5	Event 2e: The estimated quality of the currently used frequency is below a certain threshold	
14.2.1.6	Event 2 f: The estimated quality of the currently used frequency is above a certain threshold	
14.3	Inter-RAT measurements	
14.3.0a	Inter-RAT measurement quantities	
14.3.0b	Frequency quality estimate of the UTRAN frequency	
14.3.0c	Inter-RAT reporting quantities	
14.3.1	Inter-RAT reporting quantities Inter-RAT reporting events	
14.3.1.1	Event 3a: The estimated quality of the currently used UTRAN frequency is below a certain	,51
1	threshold and the estimated quality of the other system is above a certain threshold	958
14.3.1.2	Event 3b: The estimated quality of other system is below a certain threshold	
14.3.1.3	Event 3c: The estimated quality of other system is above a certain threshold	
14.3.1.4	Event 3d: Change of best cell in other system	
14.3.2	GSM measurements in compressed mode	
14 3 2 1	GSM RSSI measurements	964

14.3.2.2	Initial BSIC identification	
14.3.2.3	BSIC re-confirmation	964
14.4	Traffic Volume Measurements	
14.4.1	Traffic Volume Measurement Quantity	964
14.4.2	Traffic Volume reporting triggers	965
14.4.2.1	Reporting event 4 A: Transport Channel Traffic Volume becomes larger than an absolute threshold	969
14.4.2.2	Reporting event 4 B: Transport Channel Traffic Volume becomes smaller than an absolute threshold	
14.4.3	Traffic volume reporting mechanisms	
14.4.3.1	Pending time after trigger	
14.4.3.2	Time-to-trigger	
14.4.4	Interruption of user data transmission	
14.5	Quality Measurements	
14.5.1	Quality reporting measurement quantities	
14.5.2	Quality reporting events	
14.5.2.1	Reporting event 5A: A predefined number of bad CRCs is exceeded	
14.6	UE internal measurements.	
14.6.1	UE internal measurement quantities	
14.6.2	UE internal measurement reporting events	
14.6.2.1	Reporting event 6A: The UE Tx power becomes larger than an absolute threshold	
14.6.2.2	Reporting event 6B: The UE Tx power becomes less than an absolute threshold	
14.6.2.3	Reporting event 6C: The UE Tx power reaches its minimum value	
14.6.2.4	Reporting event 6D: The UE Tx power reaches its maximum value	
14.6.2.5	Reporting event 6E: The UE RSSI reaches the UE's dynamic receiver range	
14.6.2.6	Reporting event 6F (FDD): The UE Rx-Tx time difference for a RL included in the active set	970
14.0.2.0	becomes larger than an absolute threshold	076
14.6.2.6a	Reporting event 6F (1.28 Mcps TDD): The time difference indicated by T_{ADV} becomes larger	970
14.0.2.0a	than an absolute threshold	077
14.6.2.7	Reporting event 6G: The UE Rx-Tx time difference for a RL included in the active set becomes	711
14.0.2.7	less than an absolute threshold	077
14.7	UE positioning measurements	
14.7.1	UE positioning measurement quantities	
14.7.1	Void	
14.7.3	UE positioning reporting events	
14.7.3.1	Reporting Event 7a: The UE position changes more than an absolute threshold	
14.7.3.1	Reporting Event 7a. The OE position changes more than an absolute threshold	
14.7.3.2	Reporting Event 7c: GPS time and SFN time have drifted apart more than an absolute threshold.	
14.7.3.3	Dynamic Resource Allocation Control of Uplink DCH (FDD only)	
	Downlink power control	
14.9.1	Generalities	
14.9.1	Downlink power control in compressed mode	
14.9.2		
	Calculated Transport Format Combination	
14.11 14.11.1	Initial virtual active set	
14.11.2	Virtual active set update during an inter-frequency measurement	
14.12 14.12.0	Provision and reception of RRC information between network nodes	
	General	
14.12.0a	General error handling for RRC messages exchanged between network nodes	
14.12.1	RRC Information to target RNC	
14.12.2	RRC information, target RNC to source RNC	
14.12.3	Void	
14.12.4	RRC messages exchanged between network nodes	
14.12.4.0	HANDOVER TO UTRAN COMMAND	
14.12.4.0a		
14.12.4.1	INTER RAT HANDOVER INFO WITH INTER RAT CAPABILITIES	
14.12.4.2	SRNS RELOCATION INFO	
14.12.4.3	Void	
14.12.4.4	RFC 3095 CONTEXT INFO	
14.13	Void	
14.14	Versatile Channel Assignment Mode (VCAM) mapping rule (FDD only)	.1001

Annex A	A (informative):	USIM parameters	1003
A.1	Introduction	-	1003
A.2	Ciphering information	on	1003
A.3	Frequency informati	on	1003
A.4	Multiplicity values a	nd type constraint values	1004
Annex I	3 (informative):	Description of RRC state transitions	1005
B.1		transitions including GSM	
B.2		Mode to UTRA RRC Connected Mode	
B.2.1		mergency Calls	
B.3		ted Mode States and Transitions	
B.3.1		<u>a</u>	
B.3.1.1		om CELL_DCH to Idle Mode	
B.3.1.2		om CELL_DCH to CELL_FACH state	
B.3.1.3		om CELL_DCH to CELL_PCH state	
B.3.1.4		om CELL_DCH to URA_PCH state	
B.3.1.5		ce Allocation tasks (CELL_DCH)	
B.3.1.6		tion mobility tasks (CELL_DCH)	
B.3.1.7		nents (CELL_DCH)	
B.3.1.8		f system information (CELL_DCH)	
B.3.2	CELL FACH sta	ite	1007
B.3.2.1		om CELL FACH to CELL DCH state	
B.3.2.2		om CELL_FACH to CELL_PCH state	
B.3.2.3		om CELL_FACH to Idle Mode	
B.3.2.4		om CELL_FACH to URA_PCH State	
B.3.2.5		ce Allocation Tasks (CELL_FACH)	
B.3.2.6		tion mobility tasks (CELL_FACH)	
B.3.2.7		nents (CELL_FACH)	
B.3.2.8		update of system information (CELL_FACH)	
B.3.3)	
B.3.3.1		om CELL_PCH to CELL_FACH state	
B.3.3.2		ce Allocation Tasks (CELL_PCH)	
B.3.3.3		tion mobility tasks (CELL_PCH)	
B.3.3.4		nents (CELL_PCH)	
B.3.3.5		update of system information (CELL_PCH)	
B.3.4		update of System information (CBBE_1 C11)	
B.3.4.1		om URA_PCH State to CELL_FACH State (URA_PCH)	
B.3.4.2		ce Allocation Tasks (URA_PCH)	
B.3.4.3		tion mobility tasks (URA_PCH)	
B.3.4.4		nents (URA_PCH)	
B.3.4.5		update of system information (URA_PCH)	
B.3.5		tions for Cell Reselection in URA_PCH, CELL_PCH, and CELL_FACH	
B.4		with CS domain services	
B.5		with PS domain services	
B.6		with 1 S dollarin services	
B.6.1		ver UTRAN to GSM / BSS	
B.6.2		ver GSM / BSS to UTRAN	
D.0.2	mici-ixa nango		
	C (informative):	Change history	
History.			1035

Foreword

This Technical Specification has been produced by the 3rd Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
- 1 presented to TSG for information;
- 2 presented to TSG for approval;
- 3 or greater indicates TSG approved document under change control.
 - y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
 - z the third digit is incremented when editorial only changes have been incorporated in the document.

1 Scope

The present document specifies the Radio Resource Control protocol for the UE-UTRAN radio interface.

The scope of the present document also includes:

- the information to be transported in a transparent container between source RNC and target RNC in connection with SRNC relocation;
- the information to be transported in a transparent container between a target RNC and another system.

2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the same Release as the present document*.

[1]	3GPP TR 21.905: "Vocabulary for 3GPP Specifications".
[2]	3GPP TS 25.301: "Radio Interface Protocol Architecture".
[3]	3GPP TS 25.303: "Interlayer Procedures in Connected Mode".
[4]	3GPP TS 25.304: "UE Procedures in Idle Mode and Procedures for Cell Reselection in Connected Mode".
[5]	3GPP TS 24.008: "Mobile radio interface layer 3 specification; Core Network Protocols; Stage 3".
[6]	3GPP TS 25.103: "RF parameters in support of RRM".
[7]	3GPP TS 25.215: "Physical layer – Measurements (FDD)".
[8]	3GPP TS 25.225: "Physical layer – Measurements (TDD)".
[9]	3GPP TS 25.401: "UTRAN overall description".
[10]	3GPP TS 25.402: "Synchronization in UTRAN; Stage 2".
[11]	3GPP TS 23.003: "Numbering, addressing and identification".
[12]	ICD-GPS-200: "Navstar GPS Space Segment/Navigation User Interface".
[13]	RTCM-SC104: "RTCM Recommended Standards for Differential GNSS Service (v.2.2)".
[14]	3GPP TR 25.921: "Guidelines and principles for protocol description and error handling".
[15]	3GPP TS 25.321: "Medium Access Control (MAC) protocol specification".
[16]	3GPP TS 25.322: "Radio Link Control (RLC) protocol specification".
[17]	3GPP TS 24.007: "Mobile radio interface signalling layer 3; General aspects".
[18]	3GPP TS 25.305: "Stage 2 Functional Specification of UE Positioning in UTRAN".
[19]	3GPP TS 25.133: "Requirements for Support of Radio Resource Management (FDD)".

[20]	3GPP TS 25.123: "Requirements for Support of Radio Resource Management (TDD)".
[21]	3GPP TS 25.101: "UE Radio Transmission and Reception (FDD)".
[22]	3GPP TS 25.102: "UE Radio Transmission and Reception (TDD)".
[23]	3GPP TS 23.060: "General Packet Radio Service (GPRS); Service description; Stage 2".
[24]	3GPP TS 23.032: "Universal Geographical Area Description (GAD)".
[25]	3GPP TS 23.122: "Non-Access-Stratum functions related to Mobile Station (MS) in idle mode".
[26]	3GPP TS 25.211: "Physical channels and mapping of transport channels onto physical channels (FDD)".
[27]	3GPP TS 25.212: "Multiplexing and channel coding (FDD)".
[28]	3GPP TS 25.213: "Spreading and modulation (FDD)".
[29]	3GPP TS 25.214: "Physical layer procedures (FDD)".
[30]	3GPP TS 25.221: "Physical channels and mapping of transport channels onto physical channels (TDD)".
[31]	3GPP TS 25.222: "Multiplexing and channel coding (TDD)".
[32]	3GPP TS 25.223: "Spreading and modulation (TDD)".
[33]	3GPP TS 25.224: "Physical Layer Procedures (TDD)".
[34]	3GPP TS 25.302: "Services provided by the physical layer ".
[35]	3GPP TS 25.306 "UE Radio Access Capabilities".
[36]	3GPP TS 25.323: "Packet Data Convergence Protocol (PDCP) Specification".
[37]	3GPP TS 25.324: "Broadcast/Multicast Control BMC".
[38]	3GPP TR 25.922: "Radio resource management strategies".
[39]	3GPP TR 25.925: "Radio interface for broadcast/multicast services".
[40]	3GPP TS 33.102: "3G Security; Security Architecture".
[41]	3GPP TS 34.108: "Common Test Environments for User Equipment (UE) Conformance Testing".
[42]	3GPP TS 34.123-2: "User Equipment (UE) conformance specification; Part 2: Implementation Conformance Statement (ICS) proforma specification".
[43]	3GPP TS 44.018: "Mobile radio interface layer 3 specification; Radio Resource Control Protocol".
[44]	3GPP TS 44.060: "General Packet Radio Service (GPRS); Mobile Station (MS) - Base Station System (BSS) interface; Radio Link Control/Medium Access Control (RLC/MAC) protocol".
[45]	3GPP TS 45.005: "Radio transmission and reception".
[46]	3GPP TS 45.008: "Radio subsystem link control".
[47]	ITU-T Recommendation X.680 (12/97) "Information Technology - Abstract Syntax Notation One (ASN.1): Specification of basic notation".
[48]	ITU-T Recommendation X.681 (12/97) "Information Technology - Abstract Syntax Notation One (ASN.1): Information object specification".
[49]	ITU-T Recommendation X.691 (12/97) "Information technology - ASN.1 encoding rules: Specification of Packed Encoding Rules (PER)".
[50]	3GPP TS 31.102: "Characteristics of the USIM Application".

- [51] 3GPP TS 25.308: "High Speed Downlink Packet Access (HSDPA): Overall Description; Stage 2".
- [52] IANA ROHC profile identifier definition (http://www.iana.org/assignments/rohc-pro-ids).
- [53] 3GPP TS 44.118: "Mobile radio interface layer 3 specification; Radio Resource Control Protocol,

Iu Mode".

3 Definitions and abbreviations

3.1 Definitions

For the purposes of the present document, the terms and definitions given in [1] apply.

3.2 Abbreviations

For the purposes of the present document, the following abbreviations apply:

ACK Acknowledgement

AICH Acquisition Indicator CHannel

AM Acknowledged Mode
AS Access Stratum
ASC Access Service Class
ASN.1 Abstract Syntax Notation.1
BCCH Broadcast Control Channel

BCFE Broadcast Control Functional Entity

BER Bit Error Rate
BLER BLock Error Rate
BSS Base Station Sub-system
CCCH Common Control Channel

CCPCH Common Control Physical CHannel

CH Conditional on history
CM Connection Management

CN Core Network

CPCH Common Packet CHannel

C-RNTI Cell RNTI

CTCH Common Traffic CHannel

CTFC Calculated Transport Format Combination

CV Conditional on value
DCA Dynamic Channel Allocation
DCCH Dedicated Control Channel

DCFE Dedicated Control Functional Entity

DCH Dedicated Channel
DC-SAP Dedicated Control SAP

DGPS Differential Global Positioning System

DL Downlink

DRAC Dynamic Resource Allocation Control

DSCH Downlink Shared Channel
DTCH Dedicated Traffic Channel
FACH Forward Access Channel
FDD Frequency Division Duplex
GC-SAP General Control SAP

GERAN GSM/EDGE Radio Access Network

GRA GERAN Registration Area

G-RNTI GERAN Radio Network Temporary Identity

HCS Hierarchical Cell Structure
HFN Hyper Frame Number
H-RNTI HS-DSCH RNTI

HS-DSCH High Speed Downlink Shared Channel

ID Identifier

IDNNS Intra Domain NAS Node Selector

IE Information element

IETF Internet Engineering Task Force

IMEI International Mobile Equipment Identity
IMSI International Mobile Subscriber Identity

IP Internet Protocol

ISCP Interference on Signal Code Power

L1 Layer 1 L2 Layer 2 L3 Layer 3

LAI Location Area Identity
MAC Media Access Control
MCC Mobile Country Code
MD Mandatory default
MM Mobility Management
MNC Mobile Network Code
MP Mandatory present

NACC Network Assisted Cell Change

NAS Non Access Stratum Nt-SAP Notification SAP

NW Network OP Optional

PCCH Paging Control Channel

PCH Paging Channel

PDCP Packet Data Convergence Protocol PDSCH Physical Downlink Shared Channel

PDU Protocol Data Unit

PLMN Public Land Mobile Network

PNFE Paging and Notification Control Functional Entity

PRACH Physical Random Access CHannel

PSI Packet System Information

P-TMSI Packet Temporary Mobile Subscriber Identity

PUSCH Physical Uplink Shared Channel

QoS Quality of Service
RAB Radio access bearer
RACH Random Access CHannel
RAI Routing Area Identity
RAT Radio Access Technology

RB Radio Bearer

RFE Routing Functional Entity

RL Radio Link
RLC Radio Link Control
RNC Radio Network Controller

RNTI Radio Network Temporary Identifier

RRC Radio Resource Control
RSCP Received Signal Code Power
RSSI Received Signal Strength Indicator

SAP Service Access Point

SCFE Shared Control Function Entity SCTD Space Code Transmit Diversity

SF Spreading Factor
SHCCH Shared Control Channel
SI System Information
SIR Signal to Interference Ratio

S-RNTI SRNC - RNTI

SSDT Site Selection Diversity Transmission

TDD Time Division Duplex TF Transport Format

TFCS Transport Format Combination Set

TFS Transport Format Set
TM Transparent Mode

TME Transfer Mode Entity

TMSI Temporary Mobile Subscriber Identity

Tr Transparent
Tx Transmission
UE User Equipment

UL Uplink

UM Unacknowledged Mode
URA UTRAN Registration Area

U-RNTI UTRAN-RNTI

USCH Uplink Shared Channel

UTRAN Universal Terrestrial Radio Access Network

4 General

If not specified differently, descriptions are relevant for both FDD and TDD. Descriptions for TDD only are relevant for both 1.28 Mcps TDD and 3.84 Mcps TDD if not specified differently.

4.1 Overview of the specification

This specification is organised as follows:

- subclause 4.2 contains the description of the model of the RRC protocol layer;
- clause 5 lists the RRC functions and the services provided to upper layers;
- clause 6 lists the services expected from the lower layers and specifies the radio bearers available for usage by the RRC messages;
- clause 7 specifies the UE states for the Access Stratum, and also specifies the processes running in the UE in the respective states;
- clause 8 specifies RRC procedures, including UE state transitions;
- clause 9 specifies the procedures for the handling of unknown, unforeseen, and erroneous protocol data by the receiving entity;
- clause 10 describes the message in a Tabular format; these messages descriptions are referenced in clause 8;
- clause 11 specifies the encoding of the messages of the RRC protocol. This is based on the Tabular description in clause 10.
- clause 12 specifies the transfer syntax for RRC PDUs derived from the encoding definition;
- clause 13 lists the protocol timers, counters, constants and variables to be used by the UE;
- clause 14 specifies some of the processes applicable in UTRA RRC connected mode e.g. measurement
 processes, and also the RRC information to be transferred between network nodes. Note that not all the processes
 applicable in UTRA RRC connected mode are specified here i.e. some UTRA RRC connected mode processes
 are described in [4] e.g. cell re-selection;
- Annex A contains recommendations about the network parameters to be stored on the USIM;
- Annex B contains informative Stage 2 description of the RRC protocol states and state transitions.

The following figure summarises the mapping of UE states, including states in GSM, to the appropriate UTRA and GSM specifications that specify the UE behaviour.




Figure 4.1-1: Mapping of UE state to 3GPP Specifications

4.2 RRC Layer Model

The functional entities of the RRC layer are described below:

- Routing of higher layer messages to different MM/CM entities (UE side) or different core network domains (UTRAN side) is handled by the Routing Function Entity (RFE).
- Broadcast functions are handled in the broadcast control function entity (**BCFE**). The BCFE is used to deliver the RRC services, which are required at the GC-SAP. The BCFE can use the lower layer services provided by the Tr-SAP and UM-SAP.
- Paging of UEs that do not have an RRC connection is controlled by the paging and notification control function entity (**PNFE**). The PNFE is used to deliver the RRC services that are required at the Nt-SAP. The PNFE can use the lower layer services provided by the Tr-SAP and UM-SAP.
- The Dedicated Control Function Entity (**DCFE**) handles all functions specific to one UE. The DCFE is used to deliver the RRC services that are required at the DC-SAP and can use lower layer services of UM/AM-SAP and Tr-SAP depending on the message to be sent and on the current UE service state.
- In TDD mode, the DCFE is assisted by the Shared Control Function Entity (SCFE) location in the C-RNC, which controls the allocation of the PDSCH and PUSCH using lower layers services of UM-SAP and Tr-SAP.
- The Transfer Mode Entity (TME) handles the mapping between the different entities inside the RRC layer and the SAPs provided by RLC.
- NOTE 1: Logical information exchange is necessary also between the RRC sublayer functional entities. Most of that is implementation dependent and not necessary to present in detail in a specification.
- Figure 4.2-1 shows the RRC model for the UE and Figure 4.2-2 and Figure 4.2-3 show the RRC model for the UTRAN.
 - NOTE 2: The figure shows only the types of SAPs that are used. Multiple instances of Tr-SAP, UM-SAP and AM-SAP are possible. Especially, different functional entities usually use different instances of SAP types.




Figure 4.2-1: UE side model of RRC




Figure 4.2-2: UTRAN side RRC model (DS-MAP system)




Figure 4.2-3: UTRAN side RRC model (DS-41 System)

4.3 Protocol specification principles

This protocol specification is based on the applicable general guidelines given in [14].

In this specification, a notation of variables is used. The variables are defined in subclause 13.4. Variables are typically used to represent a status or a result of an action, such as reception of an information element in a message, which is used to specify a behaviour somewhere else in the specification, such as when setting the value of an information element in a transmitted message. The variables only serve the purpose of specifying the protocol, and do not therefore impose any particular implementation.

When specifying the UE behaviour at reception of messages, the behaviour that is tied to reception or non-reception of individual information elements, and in some cases combinations of information elements, is specified in one location (subclause 8.6).

5 RRC Functions and Services provided to upper layers

5.1 RRC Functions

The RRC performs the functions listed below. A more detailed description of these functions is provided in [2]:

- Broadcast of information related to the non-access stratum (Core Network);
- Broadcast of information related to the access stratum;
- Establishment, maintenance and release of an RRC connection between the UE and UTRAN;
- Establishment, reconfiguration and release of Radio Bearers;
- Assignment, reconfiguration and release of radio resources for the RRC connection;
- RRC connection mobility functions;
- Control of requested QoS;
- UE measurement reporting and control of the reporting;
- Outer loop power control;
- Control of ciphering;
- Slow DCA (TDD mode);
- Paging;
- Initial cell selection and cell re-selection;
- Arbitration of radio resources on uplink DCH;
- RRC message integrity protection;
- Timing advance (TDD mode);
- CBS control.

5.2 RRC Services provided to upper layers

The RRC offers the following services to upper layers, a description and primitives of these services are provided in [2] and [17].

- General Control;
- Notification;
- Dedicated control.

The RRC layer provides the UE-UTRAN portion of signalling connections to the upper layers to support the exchange of upper layer's information flow. The signalling connection is used between the user equipment and the core network to transfer upper layer information. For each core network domain, at most one signalling connection may exist at the same time. The RRC layer maps the signalling connections for one UE on a single RRC connection. For the upper layer data transfer on signalling connections, the RRC layer supports the discrimination between two different classes, named "High priority" (corresponding to "SAPI 0" for a GSM-MAP based core network) and "Low priority" (corresponding to "SAPI 3" for a GSM-MAP based core network).

5.3 Primitives between RRC and upper layers

The primitives between RRC and the upper layers are described in [17].

6 Services expected from lower layers

6.1 Services expected from Layer 2

The services provided by layer 2 are described in [2], [15] and [16].

6.2 Services expected from Layer 1

The services provided by layer 1 are described in [2].

6.3 Signalling Radio Bearers

The Radio Bearers (RB) available for transmission of RRC messages are defined as "signalling radio bearers" and are specified in the following. The UE and UTRAN shall select the signalling radio bearers for RRC messages using RLC-TM, RLC-UM or RLC-AM on the DCCH and CCCH, according to the following:

- Signalling radio bearer RB0 shall be used for all messages sent on the CCCH (UL: RLC-TM, DL: RLC-UM).
- Signalling radio bearer RB1 shall be used for all messages sent on the DCCH, when using RLC unacknowledged mode (RLC-UM).
- Signalling radio bearer RB2 shall be used for all messages sent on the DCCH, when using RLC acknowledged mode (RLC-AM), except for the RRC messages carrying higher layer (NAS) signalling.
- Signalling radio bearer RB3 and optionally Signalling radio bearer RB4 shall be used for the RRC messages carrying higher layer (NAS) signalling and sent on the DCCH in RLC acknowledged mode (RLC-AM), as specified in subclauses 8.1.8., 8.1.9 and 8.1.10.
- Additionally, RBs whose identities shall be set between 5 and 32 may be used as signalling radio bearer for the RRC messages on the DCCH sent in RLC transparent mode (RLC-TM).
- RRC messages on the SHCCH are mapped either on RACH or on the USCH in the uplink using TM and either on FACH or on the DSCH using RLC-UM. These messages are only specified for TDD mode.


The Radio Bearer configuration for signalling radio bearer RB0, SHCCH, BCCH on FACH and PCCH on PCH are specified in subclauses 13.6, 13.6a, 13.6b and 13.6c.

Ciphering is never applied to signalling radio bearer RB0 or signalling radio bearers using RLC TM.

7 Protocol states

7.1 Overview of RRC States and State Transitions including GSM

Figure 7.1-1 shows the RRC states in UTRA RRC Connected Mode, including transitions between UTRA RRC connected mode and GSM connected mode for CS domain services, and between UTRA RRC connected mode and GSM/GPRS packet modes for PS domain services. It also shows the transitions between Idle Mode and UTRA RRC Connected Mode and furthermore the transitions within UTRA RRC connected mode.



NOTE: 1: The indicated division within Idle Mode is only included for clarification and shall not be interpreted as states.

Figure 7.1-1: RRC States and State Transitions including GSM

The RRC connection is defined as a point-to-point bi-directional connection between RRC peer entities in the UE and the UTRAN characterised by the allocation of a U-RNTI. A UE has either zero or one RRC connection.

NOTE: The state transitions are specified in clause 8.

7.2 Processes in UE modes/states

NOTE: This subclause specifies what processes shall be active in the UE in the different RRC modes/states. The related procedures and the conditions on which they are triggered are specified either in clause 8 or elsewhere in the relevant process definition.

7.2.1 UE Idle mode

UE processes that are active in UE Idle mode are specified in [4].

The UE shall perform a periodic search for higher priority PLMNs as specified in [25].

7.2.2 UTRA RRC Connected mode

In this specification unless otherwise mentioned "connected mode" shall refer to "UTRA RRC connected mode".

7.2.2.1 URA_PCH or CELL_PCH state

In the URA_PCH or CELL_PCH state the UE shall perform the following actions:

NOTE: Neither DCCH nor DTCH are available in these states.

- 1> if the UE is "in service area":
 - 2> maintain up-to-date system information as broadcast by the serving cell as specified in the subclause 8.1.1;
 - 2> perform cell reselection process as specified in [4];
 - 2> perform a periodic search for higher priority PLMNs as specified in [25];
- NOTE: If the DRX cycle length is 80ms, then a search for higher priority PLMNs may not identify all the available PLMNs due to the paging occasion on the current serving cell coinciding with the MIB of the cell of interest.
 - 2> monitor the paging occasions and PICH monitoring occasions determined according to subclauses 8.6.3.1a and 8.6.3.2 and receive paging information on the PCH mapped on the S-CCPCH selected by the UE according to the procedure in subclause 8.5.19;
 - 2> act on RRC messages received on PCCH and BCCH;
 - 2> perform measurements process according to measurement control information as specified in subclause 8.4 and in subclause 14.4;
 - 2> maintain up-to-date BMC data if it supports Cell Broadcast Service (CBS) as specified in [37];
 - 2> run timer T305 for periodical URA update if the UE is in URA_PCH or for periodical cell update if the UE is in CELL_PCH.
- 1> if the UE is "out of service area":
 - 2> perform cell selection process as specified in [4];
 - 2> run timer T316;
 - 2> run timer T305;
 - 2> if the cell selection process fails to find a suitable cell after a complete scan of all RATs and all frequency bands supported by the UE, the UE shall after a minimum of TimerOutOfService time (default value 30 s) of being "out of service area":
- 3> indicate all available PLMNs to NAS to enable the selection of a new PLMN. If the NAS indicates the selection of a new PLMN the UE shall store information for the new PLMN within the variable SELECTED_PLMN and perform actions according to subclause 8.5.24;
- 3> if an acceptable cell is found then the UE shall camp on that cell to obtain limited service as defined in [4] and, perform actions according to subclause 8.5.24. If the RRC connection is released due to camping on an acceptable cell, indicate this to upper layers;
- 3> else if no acceptable cell is found, the UE shall continue looking for an acceptable cell as defined in [4].

7.2.2.2 CELL_FACH state

In the CELL_FACH state the UE shall perform the following actions:

NOTE: DCCH and, if configured, DTCH are available in this state.

- 1> if the UE is "in service area":
 - 2> maintain up-to-date system information as broadcast by the serving cell as specified in subclause 8.1.1;
 - 2> perform cell reselection process as specified in [4];
 - 2> perform measurements process according to measurement control information as specified in subclause 8.4 and in subclause 14.4;
 - 2> run timer T305 (periodical cell update);
 - 2> select and configure the RB multiplexing options applicable for the transport channels to be used in this RRC state:
 - 2> listen to all FACH transport channels mapped on the S-CCPCH selected by the UE according to the procedure in subclause 8.5.19;
 - 2> act on RRC messages received on BCCH, CCCH and DCCH;
 - 2> act on RRC messages received on, if available, SHCCH (TDD only).
- 1> if the UE is "out of service area":
 - 2> perform cell selection process as specified in [4];
 - 2> run timers T305 (periodical cell update), and T317 (cell update when re-entering "in service") or T307 (transition to Idle mode), if started;
 - 2> run timers T314 and/or T315, if started;
 - 2> if the cell selection process fails to find a suitable cell after a complete scan of all RATs and all frequency bands supported by the UE, the UE shall after a minimum of TimerOutOfService time (default value 30 seconds) of being "out of service area":
- 3> indicate all available PLMNs to NAS to enable the selection of a new PLMN. If the NAS indicates the selection of a new PLMN the UE shall store information for the new PLMN within the variable SELECTED_PLMN and perform actions according to subclause 8.5.24;
- 3> if an acceptable cell is found then the UE shall camp on that cell to obtain limited service as defined in [4] and perform actions according to subclause 8.5.24. If the RRC connection is released due to camping on an acceptable cell, indicate this to upper layers;

3> else if no acceptable cell is found, the UE shall continue looking for an acceptable cell as defined in [4].

7.2.2.3 CELL DCH state

In the CELL_DCH state the UE shall perform the following actions:

NOTE: DCCH and, if configured, DTCH are available in this state.

- 1> read system information broadcast on FACH as specified in subclause 8.1.1.3 (applicable only to UEs with certain capabilities and in FDD mode);
- 1> read the system information as specified in subclause 8.1.1 (for UEs in TDD mode);
- 1> perform measurements process according to measurement control information as specified in subclause 8.4 and in clause 14;
- 1> select and configure the RB multiplexing options applicable for the transport channels to be used in this RRC state:

- 1> act on RRC messages received on DCCH;
- 1> act on RRC messages received on BCCH (applicable only to UEs with certain capabilities and in FDD mode);
- 1> act on RRC messages received on BCCH (TDD only) and, if available, SHCCH (TDD only).

8 RRC procedures

The UE shall be able to process several simultaneous RRC procedures. After the reception of a message which invoked a procedure, the UE shall be prepared to receive and act on another message which may invoke a second procedure. Whether this second invocation of a procedure (transaction) is accepted or rejected by the UE is specified in the subclauses of this clause, and in particular in subclause 8.6.3.11 (RRC transaction identifier).

On receiving a message the UE shall:

- 1> check that the message is addressed to the UE (e.g. by checking the IE "Initial UE identity" or the IE "U-RNTI" for messages on CCCH);
- 1> discard the messages addressed to other UEs.

and then the UE shall:

- 1> apply integrity check as appropriate;
- 1> proceed with error handling as specified in clause 9;
- 1> act upon the IE "RRC transaction identifier";
- 1> continue with the procedure as specified in the relevant subclause.

NOTE: Due to an error in the Release '99 ASN.1, a Release '99 UE is unable to determine which UE is addressed by a downlink CCCH message corresponding to a protocol version later than Release '99. As a result, the Release '99 UE will not be able to return a protocol error according to subclause 9.3a. Therefore, the UTRAN should only send a Release '99 message version towards UEs that have indicated conformance to Release '99 in the IE "Access stratum release indicator".

The RRC entity in the UE shall consider PDUs to have been transmitted when they are submitted to the lower layers. If the RRC entity in the UE submits a message for transmission using AM RLC, it shall consider the message successfully transmitted when UTRAN reception of all relevant PDUs is acknowledged by RLC. In the UE, timers are started when the PDUs are sent on the radio interface in the case of the transmission using the CCCH.

8.1 RRC Connection Management Procedures

8.1.1 Broadcast of system information



Figure 8.1.1-1: Broadcast of system information




Figure 8.1.1-2: Notification of system information modification for UEs in idle mode, CELL_PCH state and URA_PCH state



Figure 8.1.1-3: Notification of system information modification for UEs in CELL_FACH and CELL_DCH(TDD only) state

8.1.1.1 General

The purpose of this procedure is to broadcast system information from the UTRAN to UEs in a cell.

8.1.1.1.1 System information structure

The system information elements are broadcast in *system information blocks*. A system information block groups together system information elements of the same nature. Different system information blocks may have different characteristics, e.g. regarding their repetition rate and the requirements on UEs to re-read the system information blocks.

The system information is organised as a tree. A *master information block* gives references and scheduling information to a number of system information blocks in a cell. The system information blocks contain the actual system information. The master information block may optionally also contain reference and scheduling information to one or two *scheduling blocks*, which give references and scheduling information for additional system information blocks. Scheduling information for a system information block may only be included in either the master information block or one of the scheduling blocks.

For all system information blocks except System Information Block types 15.2, 15.3 and 16, the content is the same in each occurrence for system information blocks using value tag. System Information Block types 15.2, 15.3 and 16 may occur more than once with different content. In this case scheduling information is provided for each such occurrence of the system information block. System information blocks that do not use value tag may have different content for each occurrence.

8.1.1.1.2 System information blocks

Table 8.1.1 specifies all system information blocks and their characteristics.

The *area scope column* in table 8.1.1 specifies the area where a system information block's value tag is valid. If the area scope is *cell*, the UE shall consider the system information block to be valid only in the cell in which it was read. If system information blocks have been previously stored for this cell, the UE shall check whether the value tag for the system information block in the entered cell is different compared to the stored value tag. If the area scope is *PLMN* or *Equivalent PLMN*, the UE shall check the value tag for the system information block when a new cell is selected. If the value tag for the system information block in the new cell is different compared to the value tag for the system information block stored in the UE, the UE shall re-read the system information block. If the area scope is *PLMN*, the

UE shall consider the system information block to be valid only within the PLMN in which it was read. If the area scope is *Equivalent PLMN*, the UE shall consider the system information block to be valid within the PLMN in which it was received and all PLMNs which are indicated by higher layers to be equivalent.

For System information block types 15.2, 15.3 and 16, which may have multiple occurrences, each occurrence has its own independent value tag. The UE- shall re-read a particular occurrence if the value tag of this occurrence has changed compared to that stored in the UE.

The *UE mode/state column when block is valid* in Table 8.1.1 specifies in which UE mode or UE state the IEs in a system information block shall be regarded as valid by the UE. In other words, the indicated system information block becomes invalid upon change to a mode/state that is not included in this column. System Information Block Type 16 remains also valid upon transition to or from GSM/GPRS. In some cases, the states are inserted in brackets to indicate that the validity is dependent on the broadcast of the associated System Information Blocks by the network as explained in the relevant procedure subclause.

The *UE mode/state column when block is read* in Table 8.1.1 specifies in which UE mode or UE state the IEs in a system information block may be read by the UE. The UE shall have the necessary information prior to execution of any procedure requiring information to be obtained from the appropriate system information block. The requirements on the UE in terms of when to read the system information may therefore be derived from the procedure specifications that specify which IEs are required in the different UE modes/states in conjunction with the different performance requirements that are specified.

System Information Block type 10 shall only be read by the UE while in CELL_DCH.

The UE shall:

- 1> if System Information Block type 11 is referenced in the master information block or in the scheduling blocks:
 - 2> if System Information Block type 12 is not referenced in the master information block or in the scheduling blocks, or broadcast of System Information Block type 12 is not indicated in System Information Block type 11.
 - 3> have read and acted upon System Information Block type 11 in a cell when the UE transmits an RRC message on RACH.

2> else:

- 3> have read and acted upon System Information Block type 11 in a cell before the UE transmits the RRC CONNECTION REQUEST message.
- 3> have read and acted upon both System Information Block type 11 and System Information Block type 12 in a cell when:
 - 4> the UE transmits an RRC message on RACH in RRC connected mode; or
 - 4> the UE receives a message commanding to enter Cell_DCH state.
 - NOTE 1: There are a number of system information blocks that include the same IEs while the UE mode/state in which the information is valid differs. This approach is intended to allows the use of different IE values in different UE mode/states.
 - NOTE 2: System Information Block Type 16 is also obtained by a UE while in GSM/GPRS. The details of this are not within the scope of this specification.

The *Scheduling information* column in table 8.1.1 specifies the position and repetition period for the System Information Block.

The *modification of system information* column in table 8.1.1 specifies the update mechanisms applicable for a certain system information block. For system information blocks with a value tag, the UE shall update the information according to subclause 8.1.1.7.1 or 8.1.1.7.2. For system information blocks with an expiration timer, the UE shall, when the timer expires, perform an update of the information according to subclause 8.1.1.7.4.

Table 8.1.1: Specification of system information block characteristics

System information block	Area scope	UE mode/state when block is valid	UE mode/state when block is read	Scheduling information	Modification of system information	Additional comment
Master information block	Cell	Idle mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only)	Idle mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only)	SIB_POS = 0 SIB_REP = 8 (FDD) SIB_REP = 8, 16, 32 (TDD) SIB_OFF=2	Value tag	
Scheduling block 1	Cell	Idle mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only)	Idle mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only)	Specified by the IE "Scheduling information" in MIB	Value tag	
Scheduling block 2	Cell	Idle mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only)	Idle mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only)	Specified by the IE "Scheduling information" in MIB	Value tag	
System information block type 1	PLMN	Idle mode CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH	Idle, CELL_FACH, CELL_PCH, URA_PCH	Specified by the IE "Scheduling information"	Value tag	
System information block type 2	Cell	URA_PCH	URA_PCH	Specified by the IE "Scheduling information"	Value tag	
System information block type 3	Cell	Idle mode, (CELL_FACH, CELL_PCH, URA_PCH)	Idle mode, (CELL_FACH, CELL_PCH, URA_PCH)	Specified by the IE "Scheduling information"	Value tag	
System information block type 4	Cell	CELL_FACH, CELL_PCH, URA_PCH	CELL_FACH, CELL_PCH, URA_PCH	Specified by the IE "Scheduling information"	Value tag	If System information block type 4 is not broadcast in a cell, the connected mode UE shall apply information in System information block type 3 in connected mode.
System information block type 5	Cell	Idle mode, (CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only))	Idle mode, (CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only))	Specified by the IE "Scheduling information"	Value tag	

System	Area	UE	UE	Scheduling	Modification	Additional comment
information block	scope	mode/state when block is valid	mode/state when block is read	information	of system information	
System information block type 6	Cell	CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only)	CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only)	Specified by the IE "Scheduling information"	Value tag	If system information block type 6 is not broadcast in a cell, the connected mode UE shall read System information block type 5.
						If some of the optional IEs are not included in System information block type 6, the UE shall read the corresponding IEs in System information block type 5
						In TDD mode system information block 6 shall only be read in CELL_DCH if required for open loop power control as specified in subclause 8.5.7 and/or if shared transport channels are assigned to the UE. If in these cases system information block type 6 is not broadcast the UE shall read system information block type 5.
System information block type 7	Cell	Idle mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only)	Idle mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only)	Specified by the IE "Scheduling information"	Expiration timer = MAX(32, SIB_REP* ExpirationTi meFactor)	In TDD mode system information block type 7 shall only be read in CELL_DCH if shared transport channels are assigned to the UE.
System information block type 8	Cell	CELL_FACH, CELL_PCH, URA_PCH	CELL_FACH, CELL_PCH, URA_PCH	Specified by the IE "Scheduling information"	Value tag	
System information block type 9	Cell	CELL_FACH, CELL_PCH, URA_PCH	CELL_FACH, CELL_PCH, URA_PCH	Specified by the IE "Scheduling information"	Expiration timer = SIB_REP	
System information block type 10	Cell	CELL_DCH	CELL_DCH	Specified by the IE "Scheduling information"	Expiration timer = SIB_REP	
System information block type 11	Cell	Idle mode (CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH)	Idle mode (CELL_FACH, CELL_PCH, URA_PCH)	Specified by the IE "Scheduling information"	Value tag	

System information block	Area scope	UE mode/state when block is valid	UE mode/state when block is read	Scheduling information	Modification of system information	Additional comment
System information block type 12	Cell	CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH	Idle mode, CELL_FACH, CELL_PCH, URA_PCH	Specified by the IE "Scheduling information"	Value tag	If system information block type 12 is not broadcast in a cell, the connected mode UE shall read System information block type 11. If some of the optional IEs are not included in System information block type 12, the UE shall read the corresponding IEs in System information block type 11.
System information block type 13	Cell	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH	Specified by the IE "Scheduling information"	Value tag	
System information block type 13.1	Cell	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH	Specified by the IE "Scheduling information"	Value tag	
System information block type 13.2	Cell	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH	Specified by the IE "Scheduling information"	Value tag	
System information block type 13.3	Cell	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH	Specified by the IE "Scheduling information"	Value tag	
System information block type 13.4	Cell	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH	Specified by the IE "Scheduling information"	Value tag	
System information block type 14	Cell	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH	Specified by the IE "Scheduling information"	Expiration timer = MAX(32, SIB_REP * ExpirationTi meFactor)	This system information block is used in 3.84 Mcps TDD mode only. System information block type 14 shall only be read in CELL_DCH if required for open loop power control as specified in subclause 8.5.7.
System information block type 15	Cell	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH	Specified by the IE "Scheduling information"	Value tag	
System information block type 15.1	Cell	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH	Specified by the IE "Scheduling information"	Value tag	
System information block type 15.2	Cell	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH	Specified by the IE "Scheduling information"	Value tag	For this system information block there may be multiple occurrences
System information block type 15.3	PLMN	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH	Specified by the IE "Scheduling information"	Value tag	For this system information block there may be multiple occurrences

46

System information block	Area scope	UE mode/state when block is valid	UE mode/state when block is read	Scheduling information	Modification of system information	Additional comment
System information block type 15.4	Cell	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH	Specified by the IE "Scheduling information"	Value tag	
System information block type 15.5	Cell	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH	Specified by the IE "Scheduling information"	Value tag	
System information block type 16	Equival ent PLMN	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH	Idle Mode, CELL_FACH, CELL_PCH, URA_PCH	Specified by the IE "Scheduling information"	Value tag	For this system information block there may be multiple occurrences. This system information block is also valid while in GSM/GPRS.
System information block type 17	Cell	CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH	CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH	Specified by the IE "Scheduling information"	Expiration timer = SIB_REP	This system information block is used in TDD mode only. System information block type 17 shall only be read if shared transport channels are assigned to the UE.
System Information Block type 18	Cell	Idle mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH	Idle mode, CELL_FACH, CELL_PCH, URA_PCH	Specified by the IE "Scheduling information"	Value tag	

The UE shall acquire all system information blocks except system information block type 10 on BCH. System Information Block type 10 shall be acquired on the FACH and only by UEs with support for simultaneous reception of one SCCPCH and one DPCH. If System Information Block type 10 is not broadcast in a cell, the DRAC procedures do not apply in this cell. System Information Block type 10 is used in FDD mode only.

8.1.1.1.3 Segmentation and concatenation of system information blocks

A generic SYSTEM INFORMATION message is used to convey the system information blocks on the BCCH. A given BCCH may be mapped onto either a BCH or a FACH transport channel according to subclause 8.1.1.1.2. The size of the SYSTEM INFORMATION message shall fit the size of a BCH or a FACH transport block.

The RRC layer in UTRAN performs segmentation and concatenation of encoded system information blocks. If the encoded system information block is larger than the size of a SYSTEM INFORMATION message, it will be segmented and transmitted in several messages. If the encoded system information block is smaller than a SYSTEM INFORMATION message, UTRAN may concatenate several system information blocks, or the first segment or the last segment into the same message as specified in the remainder of this clause.

Four different segment types are defined:

- First segment;
- Subsequent segment;
- Last segment;
- Complete.

Each of the types - *First*, *Subsequent* and *Last segment* - is used to transfer segments of a master information block, scheduling block or a system information block. The segment type, *Complete*, is used to transfer a complete master information block, complete scheduling block or a complete system information block.

Each segment consists of a header and a data field. The data field carries the encoded system information elements. The header contains the following parameters:

- The number of segments in the system information block (SEG_COUNT). This parameter is only included in the header if the segment type is "First segment".
- SIB type. The SIB type uniquely identifies the master information block, scheduling block or a system information block.
- Segment index. This parameter is only included in the header if the segment type is "Subsequent segment" or "Last segment".

UTRAN may combine one or several segments of variable length in the same SYSTEM INFORMATION message. The following combinations are allowed:

- 1. No segment;
- 2. First segment;
- 3. Subsequent segment;
- 4. Last segment;
- 5. Last segment + First segment;
- 6. Last segment + one or several Complete;
- 7. Last segment + one or several Complete + First segment;
- 8. One or several Complete;
- 9. One or several Complete + First segment;
- 10. One Complete of size 215 to 226;
- 11. Last segment of size 215 to 222.

The "No segment" combination is used when there is no master information block, scheduling block or system information block scheduled for a specific BCH transport block.

UEs are not required to support the reception of multiple occurrences of the same system information block type within one SYSTEM INFORMATION message.

NOTE: Since the SIB type is the same for each occurrence of the system information block, the UE does not know the order in which the occurrences, scheduled for this SYSTEM INFORMATION message, appear. Therefore, the UE is unable to determine which scheduling information, e.g., value tag relates to which occurrence of the system information block.

8.1.1.1.4 Re-assembly of segments

The RRC layer in the UE shall perform re-assembly of segments. All segments belonging to the same master information block, scheduling block or system information block shall be assembled in ascending order with respect to the segment index. When all segments of the master information block, scheduling block or a system information block have been received, the UE shall perform decoding of the complete master information block, scheduling block or system information block. For System Information Block types 15.2, 15.3 and 16, which may have multiple occurrences, each occurrence shall be re-assembled independently.

The UE shall discard system information blocks of which segments were missing, of which segments were received out of sequence and/or for which duplicate segments were received. The only valid sequence is an ascending one with the sequence starting with the First Segment of the associated System Information Block.

If the UE receives a Subsequent segment or Last segment where the index in IE "Segment index" is equal to or larger than the number of segments stated in IE "SEG_COUNT" in the scheduling information for that scheduling block or system information block:

- 1> the UE may:
 - 2> read all the segments to create a system information block as defined by the scheduling information read by the UE:
 - 2> store the content of the system information block with a value tag set to the value NULL; and
 - 2> consider the content of the scheduling block or system information block as valid:

3> until it receives the same type of scheduling block or system information block in a position according to its scheduling information; or

- 3> at most for 6 hours after reception.
 - 1> and the UE shall:
 - 2> re-read scheduling information for that scheduling block or system information block.

If the UE receives a Subsequent segment or Last segment where the index in IE "Segment index" is equal to or larger than the number of segments stated in IE "SEG_COUNT" in the First segment, the UE shall

- 1> discard all segments for that master information block, scheduling block or system information block; and
- 1> re-read the scheduling information for that system information block;
- 1> then re-read all segments for that system information block.

8.1.1.1.5 Scheduling of system information

Scheduling of system information blocks is performed by the RRC layer in UTRAN. If segmentation is used, it should be possible to schedule each segment separately.

To allow the mixing of system information blocks with short repetition period and system information blocks with segmentation over many frames, UTRAN may multiplex segments from different system information blocks. Multiplexing and de-multiplexing is performed by the RRC layer.

The scheduling of each system information block broadcast on a BCH transport channel is defined by the following parameters:

- the number of segments (SEG_COUNT);
- the repetition period (SIB REP). The same value applies to all segments;
- the position (phase) of the first segment within one cycle of the Cell System Frame Number (SIB_POS(0)). Since system information blocks are repeated with period SIB_REP, the value of SIB_POS(i), i = 0, 1, 2, ... SEG_COUNT-1 must be less than SIB_REP for all segments;
- the offset of the subsequent segments in ascending index order (SIB_OFF(i), i = 1, 2, ... SEG_COUNT-1) The position of the subsequent segments is calculated using the following: SIB_POS(i) = SIB_POS(i-1) + SIB_OFF(i).

The scheduling is based on the Cell System Frame Number (SFN). The SFN of a frame at which a particular segment, i, with i = 0, 1, 2, ... SEG COUNT-1 of a system information block occurs, fulfills the following relation:

In FDD and TDD the scheduling of the master information block is fixed as defined in table 8.1.1. For TDD, UTRAN may apply one of the values allowed for the master information block's repetition period. The value that UTRAN is using in TDD is not signalled; UEs have to determine it by trial and error.

8.1.1.2 Initiation

The system information is continuously broadcast on a regular basis in accordance with the scheduling defined for each system information block.

8.1.1.3 Reception of SYSTEM INFORMATION messages by the UE

The UE shall read SYSTEM INFORMATION messages broadcast on a BCH transport channel in idle mode and in the connected mode in states CELL_FACH, CELL_PCH, URA_PCH and CELL_DCH (TDD only). In addition, UEs in FDD mode which support simultaneous reception of one SCCPCH and one DPCH shall read system information on a FACH transport channel when in CELL_DCH state.

In idle mode and connected mode different combinations of system information blocks are valid. The UE shall acquire the system information blocks that are needed according to table 8.1.1.

The UE may store system information blocks with *cell*, *PLMN* or *Equivalent PLMN* area scope (including their value tag if applicable) for different cells and different PLMNs, to be used if the UE returns to these cells.

The UE shall consider all stored system information blocks as invalid after it has been switched off. Some information obtained from system information may be stored by the UE or in the USIM for use in a stored information cell selection.

When selecting a new cell within the currently used PLMN, the UE shall consider all current system information blocks with area scope cell to be invalid. If the UE has stored valid system information blocks for the newly selected cell, the UE may set those as current system information blocks.

After selecting a new PLMN, the UE shall consider all current system information blocks with area scope *cell* and *PLMN* to be invalid. If the UE has previously stored valid system information blocks for the selected cell of the new PLMN, the UE may set those as current system information blocks. Upon selection of a new PLMN the UE shall store all information elements specified within variable SELECTED_PLMN for the new PLMN within this variable.

After selecting a new PLMN which is not indicated by higher layers to be equivalent to the identity of the previously selected PLMN, the UE shall consider all system information blocks with area scope *Equivalent PLMN* to be invalid.

8.1.1.4 Reception of SYSTEM INFORMATION messages broadcast on a FACH transport channel

System information block type 10 may be broadcast on FACH, as specified in subclause 8.1.1.1.2.

When reading system information blocks on FACH, the UE shall perform the actions as defined in subclause 8.1.1.6.

8.1.1.5 Actions upon reception of the Master Information Block and Scheduling Block(s)

When selecting a new cell, the UE shall read the master information block. The UE may use the pre-defined scheduling information to locate the master information block in the cell.

Upon reception of the master information block, the UE shall:

- 1> if the "PLMN type" in the variable SELECTED_PLMN has the value "ANSI-41" and the IE "PLMN Type" has the value "ANSI-41" or "GSM-MAP and ANSI-41":
 - 2> store the ANSI-41 Information elements contained in the master information block and perform initial process for ANSI-41.
- 1> compare the value tag in the master information block with the value tag stored for this cell and this PLMN in the variable VALUE TAG;
- 1> if the value tags differ, or if no IEs for the master information block are stored:
 - 2> store the value tag into the variable VALUE_TAG for the master information block;
 - 2> read and store scheduling information included in the master information block.

1> if the value tags are the same the UE may use stored system information blocks and scheduling blocks using value tag that were stored for this cell and this PLMN as valid system information.

For all system information blocks or scheduling blocks that are supported by the UE referenced in the master information block or the scheduling blocks, the UE shall perform the following actions:

- 1> for all system information blocks with area scope "PLMN" or "Equivalent PLMN" that use value tags:
 - 2> compare the value tag read in scheduling information for that system information block with the value stored within the variable VALUE_TAG for that system information block;
 - 2> if the value tags differ, or if no IEs for the corresponding system information block are stored:
- 3> store the value tag read in scheduling information for that system information block into the variable VALUE_TAG;
- 3> read and store the IEs of that system information block.
 - 2> if the value tags are the same the UE may use stored system information blocks using value tag that were stored in this PLMN as valid system information.
 - 1> for all system information blocks or scheduling blocks with area scope cell that use value tags:
 - 2> compare the value tag read in scheduling information for that system information block or scheduling block with the value stored within the variable VALUE_TAG for that system information block or scheduling block;
 - 2> if the value tags differ, or if no IEs for the corresponding system information block or scheduling block are stored:
- 3> store the value tag read in scheduling information for that system information block or scheduling block into the variable VALUE TAG;
- 3> read and store the IEs of that system information block or scheduling block.
 - 2> if the value tags are the same the UE may use stored system information blocks using value tags that were stored for this cell and this PLMN as valid system information.
 - 1> for system information blocks which may have multiple occurrences:
 - 2> compare the value tag and the configuration or multiple occurrence identity for the occurrence of the system information blocks read in scheduling information with the value tag and configuration or multiple occurrence identity stored within the variable VALUE_TAG:
- 3> if the value tags differ, or if no IEs from the occurrence with that configuration or multiple occurrence identity of the system information block are stored:
 - 4> store the value tag read in scheduling information for that system information block and the occurrence with that configuration or multiple occurrence identity into the variable VALUE_TAG;
 - 4> read and store the IEs of that system information block.
- 3> if the value tags and the configuration or multiple occurrence identity are identical to those stored, the UE may use stored occurrences of system information blocks that were stored for this cell and this PLMN as valid system information.

For system information blocks, not supported by the UE, but referenced either in the master information block or in the scheduling blocks, the UE may:

- 1> skip reading this system information block;
- 1> skip monitoring changes to this system information block.

If the UE:

1> receives a scheduling block at a position different from its position according to the scheduling information for the scheduling block; or

1> receives a scheduling block for which scheduling information has not been received:

the UE may:

- 1> store the content of the scheduling block with a value tag set to the value NULL; and
- 1> consider the content of the scheduling block as valid until it receives the same type of scheduling block in a position according to its scheduling information or at most for 6 hours after reception.

If the UE does not find a scheduling block in a position where it should be according to its scheduling information, but a transport block with correct CRC was found at that position, the UE shall:

1> read the scheduling information for this scheduling block.

If the UE does not find the master information block in a position fulfilling:

SFN mod 32 = 0

but a transport block with correct CRC was found at that position), the UE shall:

- 1> consider the master information block as not found; and
- 1> consider the cell to be barred according to [4]; and
- 1> consider the barred cell as using the value "allowed" in the IE "Intra-frequency cell re-selection indicator", and the maximum value in the IE "T_{barred}".

NOTE: This permits a different repetition for the MIB in later versions for FDD. In TDD it allows for a variable SIB REP in this and future releases.

If system information block type 1 is not scheduled on BCH, and system information block type 13 is not scheduled on BCH, the UE shall:

- 1> consider the cell to be barred according to [4]; and
- 1> consider the barred cell as using the value "allowed" in the IE "Intra-frequency cell re-selection indicator", and the maximum value in the IE "T_{barred}".

If the UE only supports GSM-MAP but finds a cell that broadcasts System Information Block type 13 but not System Information Block type 1, the UE shall:

1> consider the cell barred.

If:

- system information block type 1 is not scheduled on BCH; and
- the "PLMN Type" in the variable SELECTED PLMN has the value "GSM-MAP"; and
- the IE "PLMN type" in the Master Information Block has the value "GSM-MAP" or "GSM-MAP and ANSI-41":

the UE shall:

1> indicate to upper layers that no CN system information is available.

If in idle mode and System Information Block type 3 is not scheduled on BCH, the UE shall:

- 1> consider the cell to be barred according to [4]; and
- 1> consider the barred cell as using the value "allowed" in the IE "Intra-frequency cell re-selection indicator", and the maximum value in the IE " T_{barred} ".

If in connected mode and System Information Block type 3 is not scheduled on BCH, and System Information Block type 4 is not scheduled on BCH, the UE shall:

1> consider the cell to be barred according to [4]; and

1> consider the barred cell as using the value "allowed" in the IE "Intra-frequency cell re-selection indicator", and the maximum value in the IE "T_{barred}".

If in idle mode and System Information Block type 5 is not scheduled on BCH or System Information Block type 5 is scheduled but IE "AICH info" (FDD) or IE "PICH info" is not present, the UE shall:

- 1> consider the cell to be barred according to [4]; and
- 1> consider the barred cell as using the value "allowed" in the IE "Intra-frequency cell re-selection indicator", and the maximum value in the IE "T_{barred}".

If in connected mode and System Information Block type 5 is not scheduled on BCH, and System Information Block type 6 is not scheduled on BCH, or any of System Information Block type 5 or type 6 is scheduled but IE "AICH info" (FDD) or IE "PICH info" is not present, the UE shall:

- 1> consider the cell to be barred according to [4]; and
- 1> consider the barred cell as using the value "allowed" in the IE "Intra-frequency cell re-selection indicator", and the maximum value in the IE "T_{barred}".

If System Information Block type 7 is not scheduled on BCH, the UE shall:

- 1> consider the cell to be barred according to [4]; and
- 1> consider the barred cell as using the value "allowed" in the IE "Intra-frequency cell re-selection indicator", and the maximum value in the IE "T_{barred}".

In 3.84 Mcps TDD, if System Information Block type 14 is not scheduled on BCH, the UE shall:

- 1> consider the cell to be barred according to [4]; and
- 1> consider the barred cell as using the value "allowed" in the IE "Intra-frequency cell re-selection indicator", and the maximum value in the IE " T_{barred} ".

8.1.1.6 Actions upon reception of system information blocks

The UE may use the scheduling information included within the master information block and the scheduling blocks to locate each system information block to be acquired.

The UE should only expect one occurrence of the scheduling information for a system information block in the master information block and any of the scheduling blocks except for System Information Block type 16, System Information Block type 15.2 and System Information Block type 15.3, which may have multiple occurrences. However, to enable future introduction of new system information blocks, the UE shall also be able to receive system information blocks other than the ones indicated within the scheduling information. The UE may ignore contents of such system information block.

If the UE:

- 1> receives a system information block in a position according to the scheduling information for the system information block; and
- 1> this system information block uses a value tag; or
- 1> this system information block uses a value tag and configuration or multiple occurrence identity:

the UE shall:

- 1> store the content of the system information block together with the value of its value tag or the values of configuration and multiple occurrence identity and the associated value tag in the scheduling information for the system information block; and
- 1> consider the content of the system information block valid until, if used, the value tag in the scheduling information for the system information block is changed or at most for 6 hours after reception.

If the UE:

- 1> receives a system information block in a position according to the scheduling information for the system information block; and
- 1> this system information block does not use a value tag according to the system information block type:

the UE shall:

- 1> store the content of the system information block; and
- 1> start an expiration timer using a value as defined in Table 8.1.1 for that system information block type; and
- 1> consider the content of the system information block valid until, the expiration timer expires.

If the UE:

- 1> receives a system information block at a position different from its position according to the scheduling information for the system information block; or
- 1> receives a system information block for which scheduling information has not been received; and
- 1> this system information block uses a value tag:

the UE may:

- 1> store the content of the system information block with a value tag set to the value NULL; and
- 1> consider the content of the system information block as valid until it receives the same type of system information block in a position according to its scheduling information or at most for 6 hours after reception.

If the UE:

- 1> receives a system information block with multiple occurrences at a position different from its position according to the scheduling information for the system information block; or
- 1> receives a system information block with multiple occurrences for which scheduling information has not been received; and
- 1> this system information block uses a value tag and configuration or multiple occurrence identity:

the UE shall:

1> ignore this information.

If the UE does not find a system information block in a position where it should be according to its scheduling information, but a transport block with correct CRC was found at that position, the UE shall read the scheduling information for this system information block.

The UE shall act upon all received information elements as specified in subclause 8.6 unless specified otherwise in the following subclauses.

8.1.1.6.1 System Information Block type 1

The UE should store all relevant IEs included in this system information block if the "PLMN Type" in the variable SELECTED_PLMN has the value "GSM-MAP" and the IE "PLMN type" in the Master Information Block has the value "GSM-MAP" or "GSM-MAP and ANSI-41". The UE shall also:

- 1> check that the cell, according to information included in IE "CN common GSM-MAP NAS system information", is suitable [4];
- 1> if in connected mode:
 - 2> not forward the content of the IE "CN common GSM-MAP NAS system information" to upper layers.

- 1> if in idle mode:
 - 2> forward the content of the IE "CN common GSM-MAP NAS system information" to upper layers.
- 1> for the IE "CN domain system information list":
 - 2> for each IE "CN domain system information" that is present:
- 3> check that the cell, according to information included in IE "CN domain specific NAS system information", is suitable [4];
- 3> if in connected mode:
 - 4> not forward the content of the IE "CN domain specific NAS system information" to upper layers.
- 3> if in idle mode:
 - 4> forward the content of the IE "CN domain specific NAS system information" and the IE "CN domain identity" to upper layers;
 - 4> use the IE "CN domain specific DRX cycle length coefficient" to calculate frame number for the Paging Occasions as specified in [4];
 - 4> store the value of the IE "CN domain specific DRX cycle length coefficient" for use in connected mode.
 - 2> if an IE "CN domain system information" is not present for a particular CN domain:
- 3> if in idle mode:
 - 4> indicate to upper layers that no CN system information is available for that CN domain.
 - 1> if the UE has not yet entered UTRA RRC connected mode:
 - 2> store the values of the IE "UE Timers and constants in connected mode" in the variable TIMERS_AND_CONSTANTS.
 - 1> use the values stored in the variable TIMERS_AND_CONSTANTS for the relevant timers and constants.

8.1.1.6.2 System Information Block type 2

If in connected mode the UE should store all relevant IEs included in this system information block. The UE shall:

1> if in state URA_PCH, start to perform URA updates using the information in the IE "URA identity".

If in idle mode, the UE shall not use the values of the IEs in this system information block.

8.1.1.6.3 System Information Block type 3

The UE should store all relevant IEs included in this system information block. The UE shall:

- 1> if in connected mode, and System Information Block 4 is indicated as used in the cell:
 - 2> read and act on information sent in that block.

8.1.1.6.4 System Information Block type 4

If in connected mode, the UE should store all relevant IEs included in this system information block.

If in idle mode, the UE shall not use the values of the IEs included in this system information block.

8.1.1.6.5 System Information Block type 5

The UE should store all relevant IEs included in this system information block. The UE shall:

1> if in connected mode, and System Information Block type 6 is indicated as used in the cell:

- 2> read and act on information sent in System Information Block type 6.
- 1> replace the TFS of the RACH with the one stored in the UE if any;
- 1> let the physical channel(s) of type PRACH given by the IE(s) "PRACH info" be the default in uplink for the PRACH if UE is in CELL_FACH state;
- 1> start to receive the physical channel of type AICH using the parameters given by the IE "AICH info" (FDD only) when given allocated PRACH is used;
- 1> use the first instance of the list of transport formats as in the IE "RACH TFS" for the used RACH received in the IE "PRACH system information list" when using the CCCH;
- 1> replace the TFS of the FACH/PCH with the one stored in the UE if any;
- 1> select a Secondary CCPCH as specified in [4] and in subclause 8.5.19, and start to receive the physical channel of type PICH associated with the PCH carried by the selected Secondary CCPCH using the parameters given by the IE "PICH info" if UE is in Idle mode or in CELL_PCH or URA_PCH state;
- 1> start to monitor its paging occasions on the selected PICH if UE is in Idle mode or in CELL_PCH or URA_PCH state;
- 1> start to receive the selected physical channel of type Secondary CCPCH using the parameters given by the IE(s) "Secondary CCPCH info" if UE is in CELL_FACH state;
- 1> in 3.84 Mcps TDD:
 - 2> use the IE "TDD open loop power control" as defined in subclause 8.5.7 when allocated PRACH is used.
- 1> in TDD:
 - 2> if the IE "PDSCH system information" and/or the IE "PUSCH system information" is included:

3> store each of the configurations given there with the associated identity given in the IE "PDSCH Identity" and/or "PUSCH Identity" respectively. For every configuration, for which the IE "SFN Time info" is included, the information shall be stored for the duration given there.

If a UE is a 12 kbps class UE according to [35] and the UE has a lower capability than required to support all transport channel configurations mapped on a specific Secondary CCPCH, the UE shall at a certain time instant still be able to decode those transport channels mapped on this Secondary CCPCH that do match the capability supported by the UE. The UE shall use the TFCI bits for that Secondary CCPCH, to distinguish a transport channel configuration that is supported by the UE from a transport channel configuration that is not supported by the UE.

In particular if the UE is a 12 kbps class UE according to [35] and it does not support the processing requirement at a given point in time for a Secondary CCPCH, it shall still be able to decode the same Secondary CCPCH when the processing requirement is consistent with the UE capability. Or if the UE does not support the number of TFs or the coding of a certain transport channel on a Secondary CCPCH, it shall still be able to decode other transport channels mapped on the same Secondary CCPCH that is consistent with what is supported by the UE.

8.1.1.6.6 System Information Block type 6

If in connected mode, the UE should store all relevant IEs included in this system information block. The UE shall:

- 1> replace the TFS of the RACH with the one stored in the UE if any;
- 1> let the physical channel(s) of type PRACH given by the IE(s) "PRACH info" be the default in uplink if UE is in CELL_FACH state. If the IE "PRACH info" is not included, the UE shall read the corresponding IE(s) in System Information Block type 5 and use that information to configure the PRACH;
- 1> start to receive the physical channel of type AICH using the parameters given by the IE "AICH info" when associated PRACH is used. If the IE "AICH info" is not included, the UE shall read the corresponding IE in System Information Block type 5 and use that information (FDD only);
- 1> replace the TFS of the FACH/PCH with the one stored in the UE if any;

- 1> select a Secondary CCPCH as specified in [4] and in subclause 8.5.19, and start to receive the physical channel of type PICH associated with the PCH carried by the selected Secondary CCPCH using the parameters given by the IE "PICH info" if the UE is in CELL_PCH or URA_PCH state. If the IE "PICH info" is not included, the UE shall read the corresponding IE in System Information Block type 5 and use that information;
- 1> start to monitor its paging occasions on the selected PICH if the UE is in CELL_PCH or URA_PCH state;
- 1> start to receive the selected physical channel of type Secondary CCPCH using the parameters given by the IE(s) "Secondary CCPCH info" if the UE is in CELL_FACH state. If the IE "Secondary CCPCH info" is not included, the UE shall read the corresponding IE(s) in System Information Block type 5 and use that information;
- 1> in 3.84 Mcps TDD: use the IE "TDD open loop power control" as defined in subclause 8.5.7;
- 1> in TDD: if the IE "PDSCH system information" and/or the IE "PUSCH system information" is included, store each of the configurations given there with the associated identity given in the IE "PDSCH Identity" and/or "PUSCH Identity" respectively. For every configuration, for which the IE "SFN Time info" is included, the information shall be stored for the duration given there.

If in idle mode, the UE shall not use the values of the IEs in this system information block.

If a UE is a 12 kbps class UE according to [35] and the UE has a lower capability than required to support all transport channel configurations mapped on a specific Secondary CCPCH, the UE shall at a certain time instant still be able to decode those transport channels mapped on this Secondary CCPCH that do match the capability supported by the UE. The UE shall use the TFCI bits for that Secondary CCPCH, to distinguish a transport channel configuration that is supported by the UE from a transport channel configuration that is not supported by the UE.

In particular if the UE is a 12 kbps class UE according to [35] and it does not support the processing requirement at a given point in time for a Secondary CCPCH, it shall still be able to decode the same Secondary CCPCH when the processing requirement is consistent with the UE capability. Or if the UE does not support the number of TFs or the coding of a certain transport channel on a Secondary CCPCH, it shall still be able to decode other transport channels mapped on the same Secondary CCPCH that is consistent with what is supported by the UE.

8.1.1.6.7 System Information Block type 7

The UE should store all relevant IEs included in this system information block.

8.1.1.6.8 System Information Block type 8

This system information block type is used only in FDD.

If in connected mode, the UE should store all relevant IEs included in this system information block.

If in idle mode, the UE shall not use the values of the IEs in this system information block.

8.1.1.6.9 System Information Block type 9

This system information block type is used only in FDD.

If in connected mode, the UE should store all relevant IEs included in the system information block. The UE shall:

1> start a timer set to the value given by the repetition period (SIB_REP) for that system information block.

If in idle mode, the UE shall not use the values of the IEs in this system information block.

8.1.1.6.10 System Information Block type 10

This system information block type is used only in FDD.

If in state CELL_DCH, the UE should store all relevant IEs included in this system information block. The UE shall:

1> start a timer set to the value given by the repetition period (SIB_REP) for that system information block;

1> perform actions defined in subclause 14.8.

If in idle mode, state CELL_FACH, state CELL_PCH or state URA_PCH, the UE shall not use the values of the IEs in this system information block.

8.1.1.6.11 System Information Block type 11

The UE should store all relevant IEs included in this system information block. The UE shall:

- 1> if in idle mode:
 - 2> clear the variable MEASUREMENT IDENTITY.
- 1> if IE "FACH measurement occasion info" is included:
 - 2> act as specified in subclause 8.6.7.
- 1> else
 - 2> may perform inter-frequency/inter-RAT measurements or inter-frequency/inter-RAT cell re-selection evaluation, if the UE capabilities permit such measurements while simultaneously receiving the S-CCPCH of the serving cell.
- 1> clear the variable CELL_INFO_LIST;
- 1> act upon the received IE "Intra-frequency cell info list"/"Inter-frequency cell info list"/"Inter-RAT cell info list" as described in subclause 8.6.7.3;
- 1> if in idle mode; or
- 1> if in connected mode and if System Information Block type 12 is not broadcast in the cell:
 - 2> if no intra-frequency measurement was set up or modified through a MEASUREMENT CONTROL message:
- 3> if included, store the IE "Intra-frequency reporting quantity" and the IE "Intra-frequency measurement reporting criteria" or "Periodical reporting criteria" in order to activate reporting when state CELL_DCH is entered in the variable MEASUREMENT_IDENTITY. The IE "Cells for measurement" is absent for this measurement. The IE "Measurement Validity" is absent for this measurement after a state transition to CELL_DCH;
 - 1> if in connected mode and if System Information Block type 12 is not broadcast in the cell:
 - 2> read the IE "Traffic volume measurement information";
 - 2> if no traffic volume measurement with the measurement identity indicated in the IE "Traffic volume measurement system information" was set up or modified through a MEASUREMENT CONTROL message:
- 3> update the variable MEASUREMENT IDENTITY with the measurement information received in that IE.
 - 1> if the IE "Cell selection and reselection info" is not included for a new neighbouring cell in the IE "intrafrequency cell info list", the IE "inter-frequency cell info list" or the IE "inter-RAT cell info list" in System Information Block type 11:
 - 2> use the default values specified for the IE "Cell selection and reselection info" for that cell except for the IE "HCS neighbouring cell information".
 - 1> if the IE "Use of HCS" is set to "used", indicating that HCS is used, do the following:
 - 2> if IE "HCS neighbouring cell information" is not included for the first new cell in the IE "Intra-frequency cell info list", the IE "Inter-frequency cell info list" or the IE "Inter-RAT cell info list" in System Information Block type 11:
- 3> use the default values specified for the IE "HCS neighbouring cell information" for that cell.
 - 2> if IE "HCS neighbouring cell information" is not included for any other new cell in the IE "Intra-frequency cell info list", the IE "Inter-frequency cell info list" or the IE "Inter-RAT cell info list" in System Information Block type 11:

- 3> for that cell use the same parameter values as used for the preceding cell in the same cell info list in System Information Block type 11.
 - 1> if the value of the IE "Cell selection and reselection quality measure" is different from the value of the IE "Cell selection and reselection quality measure" obtained from System Information Block type 3 or System Information Block type 4:
 - 2> use the value of the IE from this System Information Block and ignore the value obtained from System Information Block type 3 or System Information Block type 4.
 - 1> if in connected mode, and System Information Block type 12 is indicated as used in the cell:
 - 2> read and act on information sent in System Information Block type 12 as indicated in subclause 8.1.1.6.12.

8.1.1.6.12 System Information Block type 12

If in connected mode, the UE should store all relevant IEs included in this system information block. The UE shall:

- 1> after reception of System Information Block type 11:
 - 2> update the variable MEASUREMENT_IDENTITY with the measurement information in the received IEs unless specified otherwise.
- 1> if IE "FACH measurement occasion info" is included:
 - 2> act as specified in subclause 8.6.7.
- 1> else:
 - 2> may perform inter-frequency/inter-RAT measurements or inter-frequency/inter-RAT cell re-selection evaluation, if the UE capabilities permit such measurements while simultaneously receiving the S-CCPCH of the serving cell.
- 1> act upon the received IE "Intra-frequency cell info list"/"Inter-frequency cell info list"/"Inter-RAT cell info list" as described in subclause 8.6.7.3;
- 1> if any of the IEs "Intra-frequency measurement quantity", "Intra-frequency reporting quantity for RACH reporting", "Maximum number of reported cells on RACH" or "Reporting information for state CELL_DCH" are not included in the system information block:
 - 2> read the corresponding IE(s) in system information block type 11 and use that information for the intrafrequency measurement.
- 1> if included in this system information block or in System Information Block type 11:
 - 2> if no intra-frequency measurement in the variable MEASUREMENT_IDENTITY was set up or modified through a MEASUREMENT CONTROL message:

3> store the IE "Intra-frequency reporting quantity" and the IE "Intra-frequency measurement reporting criteria" or "Periodical reporting criteria" in order to activate reporting when state CELL_DCH is entered in the variable MEASUREMENT_IDENTITY. The IE "Cells for measurement" is absent for this measurement. The IE "Measurement Validity" is absent for this measurement after a state transition to CELL_DCH;

- 1> if the IE "Traffic volume measurement system information" is not included in this system information block:
 - 2> read the corresponding IE in System Information Block type 11.
- 1> if the IE "Traffic volume measurement system information" was received either in this system information block or in System Information Block type 11:
 - 2> if no traffic volume measurement with the measurement identity indicated in the IE "Traffic volume measurement system information" was set up or modified through a MEASUREMENT CONTROL message:
- 3> update the variable MEASUREMENT_IDENTITY with the measurement information received in that IE.
 - 1> if in CELL_FACH state:

- 2> start or continue the traffic volume measurements stored in the variable MEASUREMENT_IDENTITY that are valid in CELL FACH state.
- 1> if the IE "Cell selection and reselection info" is not included for a new neighbouring cell in the IE "Intrafrequency cell info list", the IE "Inter-frequency cell info list" or the IE "Inter-RAT cell info list" in System Information Block type 12:
 - 2> use the default values specified for the IE "Cell selection and reselection info" for that cell except for the IE "HCS neighbouring cell information".
- 1> if the IE "Use of HCS" is set to "used", indicating that HCS is used, do the following:
 - 2> if IE "HCS neighbouring cell information" is not included for the first new cell in the IE "Intra-frequency cell info list", the IE "Inter-frequency cell info list" or the IE "Inter-RAT cell info list" in System Information Block type 12:
- 3> use the default values specified for the IE "HCS neighbouring cell information" for that cell.
 - 2> if IE "HCS neighbouring cell information" is not included for any other new cell in the IE "Intra-frequency cell info list", the IE "Inter-frequency cell info list" or the IE "Inter-RAT cell info list" in System Information Block type 12:
- 3> for that cell use the same parameter values as used for the preceding cell in the same cell info list in System Information Block type 12.
 - 1> if the value of the IE "Cell selection and reselection quality measure" is different from the value of the IE "Cell selection and reselection quality measure" obtained from System Information Block type 3 or System Information Block type 4:
 - 2> use the value of the IE from this System Information Block and ignore the value obtained from System Information Block type 3 or System Information Block type 4.

If in idle mode, the UE shall not use the values of the IEs in this system information block.

8.1.1.6.13 System Information Block type 13

If in idle or connected mode, the UE should store all relevant IEs included in this system information block except for the IEs "CN domain specific DRX cycle length coefficient", "UE timers and constants in idle mode" and "Capability update requirement" which shall be stored only in the idle mode case. The UE shall read System Information Block type 13 and the associated System Information Block types 13.1, 13.2, 13.3 and 13.4 only when the "PLMN Type" in the variable SELECTED_PLMN has the value "ANSI-41" and the IE "PLMN type" in the Master Information Block has the value "ANSI-41" or "GSM-MAP and ANSI-41". The UE shall also:

- 1> forward the content of the IE "CN domain specific NAS system information" to the non-access stratum entity indicated by the IE "CN domain identity";
- 1> use the IE "CN domain specific DRX cycle length coefficient" to calculate frame number for the Paging Occasions and Page indicator as specified in [4].

Refer to TIA/EIA/IS-2000.5-A for actions on information contained in System Information Block types 13.1, 13.2, 13.3 and 13.4.

8.1.1.6.14 System Information Block type 14

This system information block type is used only in 3.84 Mcps TDD.

The UE should store all relevant IEs included in this system information block. The UE shall:

1> use the IE "UL Timeslot Interference" to calculate PRACH, DPCH and PUSCH transmit power for TDD uplink open loop power control as defined in subclause 8.5.7.

8.1.1.6.15 System Information Block type 15

If the UE is in idle or connected mode, and supports GPS location services it should store all relevant IEs included in this system information block. The UE shall:

- 1> if the IE "GPS Data ciphering info" is included:
- 1> act as specified in the subclause 8.6.7.19.4.- act upon the received IE "Reference position" as specified in subclause 8.6.7.19.3.8;
- 1> act upon the received IE "GPS reference time" as specified in subclause 8.6.7.19.3.7;
- 1> if IE "Satellite information" is included:
 - 2> act upon this list of bad satellites as specified in subclause 8.6.7.19.3.6.
- NOTE: For efficiency purposes, the UTRAN should broadcast System Information Block type 15 if it is broadcasting System Information Block type 15.2.

8.1.1.6.15.1 System Information Block type 15.1

The UE should store all the relevant IEs included in this system information block in variable UE_POSITIONING_GPS_DATA. The UE shall:

- 1> act on "DGPS information" in the IE "DGPS Corrections" in a similar manner as specified in [13] except that the scale factors for PRC and RRC are different;
- 1> act upon the received IE " UE Positioning GPS DGPS corrections" as specified in subclause 8.6.7.19.3.3.

In this version of the specification, the UE shall:

1> ignore the following IEs: "Delta PRC2", "Delta RRC2", "Delta PRC3" and "Delta RRC3".

8.1.1.6.15.2 System Information Block type 15.2

For System Information Block type 15.2 multiple occurrences may be used; one occurrence for one satellite. To identify the different occurrences, the scheduling information for System Information Block type 15.2 includes IE "SIB occurrence identity and value tag". The UE should store all the relevant IEs included in this system information block in variable UE_POSITIONING_GPS_DATA. The UE shall:

- 1> compare for each occurrence the value tag of the stored occurrence, if any, with the occurrence value tag included in the IE "SIB occurrence identity and value tag" for the occurrence of the System Information Block with the same occurrence identity;
- 1> in case the UE has no SIB occurrence stored with the same identity or in case the occurrence value tag is different:
 - 2> store the occurrence information together with its identity and value tag for later use.
- 1> in case an occurrence with the same identity but different value tag was stored:
 - 2> overwrite this one with the new occurrence read via system information for later use.
- 1> interpret IE "Transmission TOW" as a very coarse estimate of the current time, i.e., the approximate GPS time-of-week when the message is broadcast;
- 1> interpret IE "SatID" as the satellite ID of the data from which this message was obtained;
- 1> act upon the received IEs "Sat ID" and "GPS Ephemeris and Clock Corrections Parameter" as specified in subclause 8.6.7.19.3.4.

The IE "Transmission TOW" may be different each time a particular SIB occurrence is transmitted. The UTRAN should not increment the value tag of the SIB occurrence if the IE "Transmission TOW" is the only IE that is changed.

The UE may not need to receive all occurrences before it can use the information from any one occurrence.

8.1.1.6.15.3 System Information Block type 15.3

For System Information Block type 15.3 multiple occurrences may be used; one occurrence for each set of satellite data. To identify the different occurrences, the scheduling information for System Information Block type 15.3 includes IE "SIB occurrence identity and value tag". The UE should store all the relevant IEs included in this system information block in variable UE_POSITIONING_GPS_DATA. The UE shall:

- 1> compare for each occurrence the value tag of the stored occurrence, if any, with the occurrence value tag included in the IE "SIB occurrence identity and value tag" for the occurrence of the System Information Block with the same occurrence identity;
- 1> in case the UE has no SIB occurrence stored with the same identity or in case the occurrence value tag is different:
 - 2> store the occurrence information together with its identity and value tag for later use.
- 1> in case an occurrence with the same identity but different value tag was stored:
 - 2> overwrite this one with the new occurrence read via system information for later use.
- 1> interpret IE "Transmission TOW" as a very coarse estimate of the current time, i.e., the approximate GPS time-of-week when the message is broadcast;
- 1> if the IE "GPS Almanac and Satellite Health" is included:
 - 2> interpret IE "SatMask" as the satellites that contain the pages being broadcast in this message;
 - 2> interpret IE "LSB TOW" as the least significant 8 bits of the TOW ([12]);
 - 2> act upon the received IE "GPS Almanac and Satellite Health" as specified in subclause 8.6.7.19.3.2.
- 1> if the IE "GPS ionospheric model" is included:
 - 2> act upon the received IE "GPS ionospheric model" as specified in subclause 8.6.7.19.3.5.
- 1> if the IE "GPS UTC model" is included:
 - 2> act upon the received IE "GPS UTC model" as specified in subclause 8.6.7.19.3.9.

The IE "Transmission TOW" may be different each time a particular SIB occurrence is transmitted. The UTRAN should not increment the value tag of the SIB occurrence if the IE "Transmission TOW" is the only IE that is changed. One SIB occurrence value tag is assigned to the table of subclause 10.2.48.8.18.3.

The UE may not need to receive all occurrences before it can use the information for any one occurrence.

8.1.1.6.15.4 System Information Block type 15.4

If the UE is in idle mode or connected mode, the UE shall:

- 1> if the IE "OTDOA Data ciphering info" is included:
 - 2> act as specified in subclause 8.6.7.19.4.

If the UE is in connected mode, the UE shall:

1> act as specified in subclause 8.6.7.19.2.

8.1.1.6.15.5 System Information Block type 15.5

If the UE is in idle or connected mode, the UE shall:

- 1> if the UE supports UE-based OTDOA positioning:
 - 2> act as specified in subclause 8.6.7.19.2a.

8.1.1.6.16 System Information Block type 16

For System Information Block type 16 multiple occurrences may be used; one occurrence for each predefined configuration. To identify the different predefined configurations, the scheduling information for System Information Block type 16 includes IE "Predefined configuration identity and value tag".

The UE should store all relevant IEs included in this system information block. The UE shall:

- 1> compare for each predefined configuration the value tag of the stored predefined configuration with the preconfiguration value tag included in the IE "Predefined configuration identity and value tag" for the occurrence of the System Information Block with the same predefined configuration identity;
- 1> in case the UE has no predefined configuration stored with the same identity:
 - 2> store the predefined configuration information together with its identity and value tag for later use e.g. during handover to UTRAN.
- 1> in case a predefined configuration with the same identity but different value tag was stored:
 - 2> overwrite this one with the new configuration read via system information for later use e.g. during handover to UTRAN.

The above handling applies regardless of whether the previously stored predefined configuration information has been obtained via UTRA or via another RAT.

The UE is not required to complete reading of all occurrences of System Information Block type 16 before initiating RRC connection establishment.

The UE is not required to store more than maxPredefConfig preconfigurations even in the case of multiple equivalent PLMNs.

8.1.1.6.17 System Information Block type 17

This system information block type is used only for TDD.

If in connected mode, the UE should store all relevant IEs included in this system information block. The UE shall:

1> if the IE "PDSCH system information" and/or the IE "PUSCH system information" is included, store each of the configurations given there with the associated identity given in the IE "PDSCH Identity" and/or "PUSCH Identity" respectively. This information shall become invalid after the time specified by the repetition period (SIB_REP) for this system information block.

If in idle mode, the UE shall not use the values of the IEs in this system information block.

8.1.1.6.18 System Information Block type 18

If the System Information Block type 18 is present, a UE shall obtain knowledge of the PLMN identity of the neighbour cells to be considered for cell reselection, and shall behave as specified in this subclause and in subclause 8.5.14a.

The UE should store all the relevant IEs included in this system information block.

A UE in idle mode shall act according to the following rules:

- 1> any PLMN list of a given type (IEs "PLMNs of intra-frequency cells list", "PLMNs of inter-frequency cells list", "PLMNs of inter-RAT cell lists") included in the IE "Idle mode PLMN identities" is paired with the list of cells of the same type derived from System Information Block type 11;
- 1> the PLMN identity located at a given rank in the PLMN list is that of the cell with the same ranking in the paired list of cells, the cells being considered in the increasing order of their associated identities ("Intra-frequency cell id", "Inter-frequency cell id", "Inter-RAT cell id");
- 1> if the number of identities in a PLMN list exceeds the number of neighbour cells in the paired list (if any), the extra PLMN identities are considered as unnecessary and ignored;

1> if the number of identities in a PLMN list (if any) is lower than the number of neighbour cells in the paired list, the missing PLMN identities are replaced by the last PLMN identity in the list if present, otherwise by the identity of the selected PLMN.

A UE in connected mode shall act in the same manner as a UE in idle mode with the following modifications:

- 1> the PLMN lists to be considered are the ones included, when present, in the IE "Connected mode PLMN identities"; otherwise, the UE shall use, in place of any missing list, the corresponding one in the IE "Idle mode PLMN identities";
- 1> the paired lists of cells are the ones derived from System Information Block type 11, and System Information Block type 12 if present.

8.1.1.7 Modification of system information

For System Information Block type 15.2, 15.3 and 16 that may have multiple occurrences, the UE shall handle each occurrence independently as specified in the previous; that is each occurrence is handled as a separate system information block.

NOTE: It should be noted that for the proper operation of the BCCH Modification Information sent on a PCH, the System Information should not be changed more frequently than can be accommodated by mobile stations operating at the maximum DRX cycle length supported by the UTRAN.

8.1.1.7.1 Modification of system information blocks using a value tag

Upon modifications of system information blocks using value tags, UTRAN should notify the new value tag for the master information block in the IE "BCCH modification info", transmitted in the following way:

- 1> to reach UEs in idle mode, CELL_PCH state and URA_PCH state, the IE "BCCH modification info" is contained in a PAGING TYPE 1 message transmitted on the PCCH in all paging occasions in the cell;
- 1> to reach UEs in CELL_FACH state or TDD UEs in CELL_DCH with S-CCPCH assigned, the IE "BCCH modification info" is contained in a SYSTEM INFORMATION CHANGE INDICATION message transmitted on the BCCH mapped on at least one FACH on every Secondary CCPCH in the cell.

Upon reception of a PAGING TYPE 1 message or a SYSTEM INFORMATION CHANGE INDICATION message containing the IE "BCCH modification info" containing the IE "MIB value tag" but not containing the IE "BCCH modification time", the UE shall perform actions as specified in subclause 8.1.1.7.3.

If the IE "BCCH modification time" is included the UE shall perform actions as specified in subclause 8.1.1.7.2.

8.1.1.7.2 Synchronised modification of system information blocks

For modification of some system information elements, e.g. reconfiguration of the channels, it is important for the UE to know exactly when a change occurs. In such cases, the UTRAN should notify the SFN when the change will occur as well as the new value tag for the master information block in the IE "BCCH modification info" transmitted in the following way:

- 1> To reach UEs in idle mode, CELL_PCH state and URA_PCH state, the IE "BCCH modification info" is contained in a PAGING TYPE 1 message transmitted on the PCCH in all paging occasions in the cell;
- 1> To reach UEs in CELL_FACH state, the IE "BCCH modification info" is contained in a SYSTEM INFORMATION CHANGE INDICATION message transmitted on the BCCH mapped on at least one FACH on every Secondary CCPCH in the cell.

Upon reception of a PAGING TYPE 1 message or a SYSTEM INFORMATION CHANGE INDICATION message containing the IE "BCCH modification info" containing the IE "MIB value tag" and containing the IE "BCCH modification time", the UE shall:

1> perform the actions as specified in subclause 8.1.1.7.3 at the time, indicated in the IE "BCCH Modification Info".

8.1.1.7.3 Actions upon system information change

The UE shall:

- 1> compare the value of IE "MIB value tag" in the IE "BCCH modification info" with the value tag stored for the master information block in variable VALUE_TAG.
- 1> if the value tags differ:
 - 2> read the master information block on BCH;
 - 2> if the value tag of the master information block in the system information is the same as the value in IE "MIB value tag" in "BCCH modification info" but different from the value tag stored in the variable VALUE TAG:
- 3> perform actions as specified in subclause 8.1.1.5.
 - 2> if the value tag of the master information block in the system information is the same as the value tag stored in the variable VALUE_TAG:
- 3> for the next occurrence of the master information block:
 - 4> perform actions as specified in subclause 8.1.1.7.3 again.
 - 2> if the value tag of the master information block in the system information is different from the value tag stored in the variable VALUE_TAG, and is different from the value in IE "MIB value tag" in "BCCH modification info":
- 3> perform actions as specified in subclause 8.1.1.5;
- 3> if (VTCI-VTMIB) mod 8 < 4, where VTCI is the value tag in the IE "MIB value tag" in "BCCH modification info" and VTMIB is the value tag of the master information block in the system information:
 - 4> for the next occurrence of the master information block:
 - 5> perform actions as specified in subclause 8.1.1.7.3 again.

8.1.1.7.4 Actions upon expiry of a system information expiry timer

When the expiry timer of a system information block not using a value tag expires

the UE shall:

- 1> consider the content of the system information block invalid;
- 1> re-acquire the system information block again before the content can be used;

In FDD for system information blocks other than System Information Block type 7, or in states other than CELL_FACH, or in TDD for system information blocks other than System Information Block type 14, or in states other than CELL_FACH or CELL_DCH the UE may:

1> postpone reading the system information block until the content is needed.

In FDD for System Information Block type 7, while in state CELL_FACH, and in TDD for System Information Block type 14, while in state CELL_FACH or CELL DCH the UE shall always keep an up to date version of the relevant IEs, unless this is not possible because system information can not be received due to bad radio conditions.

8.1.2 Paging




Figure 8.1.2-1: Paging

8.1.2.1 General

This procedure is used to transmit paging information to selected UEs in idle mode, CELL_PCH or URA_PCH state using the paging control channel (PCCH). Upper layers in the network may request paging, to e.g. establish a signalling connection. UTRAN may initiate paging for UEs in CELL_PCH or URA_PCH state to trigger a cell update procedure. In addition, UTRAN may initiate paging for UEs in idle mode, CELL_PCH and URA_PCH state to trigger reading of updated system information. UTRAN may also initiate paging for UEs in CELL_PCH and URA_PCH state to release the RRC connection.

8.1.2.2 Initiation

UTRAN initiates the paging procedure by transmitting a PAGING TYPE 1 message on an appropriate paging occasion on the PCCH.

UTRAN may repeat transmission of a PAGING TYPE 1 message to a UE in several paging occasions to increase the probability of proper reception of a page.

UTRAN may page several UEs in the same paging occasion by including one IE "Paging record" for each UE in the PAGING TYPE 1 message.

For CN originated paging, UTRAN should set the IE "Paging cause" to the cause for paging received from upper layers. If no cause for paging is received from upper layers, UTRAN should set the value "Terminating – cause unknown".

UTRAN may also indicate that system information has been updated, by including the value tag of the master information block in the IE "BCCH modification info" in the PAGING TYPE 1 message. In this case, UTRAN may omit the IEs "Paging record".

8.1.2.3 Reception of a PAGING TYPE 1 message by the UE

A UE in idle mode, CELL_PCH state or URA_PCH state shall receive the paging information for all its monitored paging occasions. For a UE in idle mode, the paging occasions are specified in [4] and depend on the IE "CN domain specific DRX cycle length coefficient", as specified in subclause 8.6.3.1a. For a UE in CELL_PCH state or URA_PCH state, the paging occasions depend also on the IE "UTRAN DRX cycle length coefficient" and the IE "RRC State Indicator", as specified in subclauses 8.6.3.2 and 8.6.3.3 respectively.

When the UE receives a PAGING TYPE 1 message, it shall perform the actions as specified below.

If the UE is in idle mode, for each occurrence of the IE "Paging record" included in the message the UE shall:

- 1> if the IE "Used paging identity" is a CN identity:
 - 2> compare the IE "UE identity" with all of its allocated CN UE identities:
 - 2> if one match is found:
- 3> indicate reception of paging; and
- 3> forward the IE "CN domain identity", the IE "UE identity" and the IE "Paging cause" to the upper layers.

- 1> otherwise:
 - 2> ignore that paging record.
- If the UE is in connected mode, for each occurrence of the IE "Paging record" included in the message the UE shall:
 - 1> if the IE "Used paging identity" is a UTRAN single UE identity and if this U-RNTI is the same as the U-RNTI allocated to the UE stored in the UE variable U_RNTI:
 - 2> if the optional IE "CN originated page to connected mode UE" is included:
- 3> indicate reception of paging; and
- 3> forward the IE "CN domain identity", the IE "Paging cause" and the IE "Paging record type identifier" to the upper layers.
 - 2> if the IE "Release indicator" in the IE "RRC connection release information" has the value "Release":
- 3> release all its radio resources;
- 3> indicate the release of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to the upper layers;
- 3> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
- 3> clear the variable ESTABLISHED RABS;
- 3> pass the value of the IE "Release cause" received in the IE 'Release information' to upper layers;
- 3> enter idle mode;
- 3> perform the actions specified in subclause 8.5.2 when entering idle mode;
- 3> and the procedure ends.
 - 2> otherwise:
- 3> perform a cell update procedure with cause "paging response" as specified in subclause 8.3.1.2.
 - 2> ignore any other remaining IE "Paging record" that may be present in the message.
 - 1> if the IE "Used paging identity" is a UTRAN group identity and there is a group identity match according to subclause 8.6.3.13:
 - 2> if the IE "Release indicator" in the IE "RRC connection release information" has the value "Release":
- 3> release all its radio resources;
- 3> indicate the release of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to the upper layers;
- 3> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
- 3> clear the variable ESTABLISHED_RABS;
- 3> pass the value of the IE "Release cause" received in the IE 'Release information' to upper layers;
- 3> enter idle mode;
- 3> perform the actions specified in subclause 8.5.2 when entering idle mode;
- 3> and the procedure ends.
 - 2> otherwise:
- 3> perform a cell update procedure with cause "paging response" as specified in subclause 8.3.1.2.

2> ignore any other remaining IE "Paging record" that may be present in the message.

1> otherwise:

2> ignore that paging record.

If the IE "BCCH modification info" is included, any UE in idle mode, CELL_PCH or URA_PCH state shall perform the actions as specified in subclause 8.1.1 in addition to any actions caused by the IE "Paging record" occurrences in the message as specified above.

8.1.3 RRC connection establishment




Figure 8.1.3-1: RRC Connection Establishment, network accepts RRC connection




Figure 8.1.3-2: RRC Connection Establishment, network rejects RRC connection

8.1.3.1 General

The purpose of this procedure is to establish an RRC connection.

8.1.3.2 Initiation

The UE shall initiate the procedure when upper layers in the UE requests the establishment of a signalling connection and the UE is in idle mode (no RRC connection exists), as specified in subclause 8.1.8.

Upon initiation of the procedure, the UE shall:

1> set the variable PROTOCOL_ERROR_INDICATOR to FALSE;

1> if the USIM is present:

2> set the value of "THRESHOLD" in the variable "START_THRESHOLD" to the 20 MSBs of the value stored in the USIM [50] for the maximum value of START for each CN Domain.

1> if the SIM is present:

2> set the value of "THRESHOLD" in the variable "START_THRESHOLD" to the default value in [40] for each CN Domain.

- 1> set the IE "Initial UE identity" in the variable INITIAL_UE_IDENTITY according to subclause 8.5.1;
- 1> set the contents of the RRC CONNECTION REQUEST message according to subclause 8.1.3.3;
- 1> set CFN in relation to SFN of current cell according to subclause 8.5.15;
- 1> perform the mapping of the Access Class to an Access Service Class as specified in subclause 8.5.13, and apply the given Access Service Class when accessing the RACH;
- 1> submit the RRC CONNECTION REQUEST message for transmission on the uplink CCCH;
- 1> set counter V300 to 1; and
- 1> start timer T300 when the MAC layer indicates success or failure to transmit the message;
- 1> select a Secondary CCPCH according to [4];
- 1> start receiving all FACH transport channels mapped on the selected Secondary CCPCH.

8.1.3.3 RRC CONNECTION REQUEST message contents to set

The UE shall, in the transmitted RRC CONNECTION REQUEST message:

- 1> set the IE "Establishment cause" to the value of the variable ESTABLISHMENT_CAUSE;
- 1> set the IE "Initial UE identity" to the value of the variable INITIAL_UE_IDENTITY;
- 1> set the IE "Protocol error indicator" to the value of the variable PROTOCOL_ERROR_INDICATOR; and
- 1> include a measurement report in the IE "Measured results on RACH", as specified in the IE "Intra-frequency reporting quantity for RACH reporting" and the IE "Maximum number of reported cells on RACH" in System Information Block type 11.

The UE shall not include the IE "UE Specific Behaviour Information 1 idle".

8.1.3.4 Reception of an RRC CONNECTION REQUEST message by the UTRAN

Upon receiving an RRC CONNECTION REQUEST message, UTRAN should either:

- 1> accept the request and use a predefined or default radio configuration, in which case it should:
 - 2> include the following information in the RRC CONNECTION SETUP message:
- 3> the IE "Predefined configuration identity", to indicate which pre-defined configuration of RB and, transport channel parameters shall be used; or
- 3> the IE "Default configuration mode" and IE "Default configuration identity", to indicate which default configuration of RB and transport channel parameters shall be used;
- 3> PhyCH information elements.
 - 2> submit the RRC CONNECTION SETUP message to the lower layers for transmission on the downlink CCCH.
 - NOTE 1: UTRAN should only apply a predefined radio configuration in case it orders the UE to enter CELL_DCH. This is because the predefined configuration information included in System Information Block 16 mandatorily includes information only required in CELL_DCH state.
 - 1> accept the request without using a predefined or default radio configuration, in which case it should:
 - 2> include in the RRC CONNECTION SETUP message the complete set of RB, TrCH and PhyCH information elements to be used;
 - 2> submit the RRC CONNECTION SETUP message to the lower layers for transmission on the downlink CCCH:

- NOTE 2: In R'99, the RRC CONNECTION SETUP message always includes the IEs "Added or Reconfigured TrCH information list", both for uplink and downlink transport channels, even if UTRAN orders the UE to move to CELL_FACH and hence need not configure any transport channels. In these cases, UTRAN may include a configuration that adds little to the encoded message size e.g. a DCH with a single zero size transport format. At a later stage, UTRAN may either remove or reconfigure this configuration.
- 1> submit an RRC CONNECTION REJECT message on the downlink CCCH. In the RRC CONNECTION REJECT message, the UTRAN may direct the UE to another UTRA carrier or to another system. After the RRC CONNECTION REJECT message has been sent, all context information for the UE may be deleted in UTRAN.

8.1.3.5 Cell re-selection or T300 timeout

- 1> if the UE has not yet received an RRC CONNECTION SETUP message with the value of the IE "Initial UE identity" equal to the value of the variable INITIAL_UE_IDENTITY; and
- 1> if cell re-selection or expiry of timer T300 occurs:

the UE shall:

- 1> check the value of V300; and
 - 2> if V300 is equal to or smaller than N300:
- 3> if cell re-selection occurred:
 - 4> set CFN in relation to SFN of current cell according to subclause 8.5.15.
- 3> set the IEs in the RRC CONNECTION REQUEST message according to subclause 8.1.3.3;
- 3> perform the mapping of the Access Class to an Access Service Class as specified in subclause 8.5.13; and
- 3> apply the given Access Service Class when accessing the RACH;
- 3> submit a new RRC CONNECTION REQUEST message to lower layers for transmission on the uplink CCCH;
- 3> increment counter V300;
- 3> restart timer T300 when the MAC layer indicates success or failure to transmit the message.
 - 2> if V300 is greater than N300:
- 3> enter idle mode.
- 3> consider the procedure to be unsuccessful;
- 3> Other actions the UE shall perform when entering idle mode from connected mode are specified in subclause 8.5.2;
- 3> the procedure ends.

8.1.3.5a Abortion of RRC connection establishment

If the UE has not yet entered UTRA RRC Connected mode and the RRC connection establishment is to be aborted as specified in subclause 8.1.8, the UE shall:

- 1> consider the procedure to be unsuccessful;
- 1> perform the actions when entering idle mode as specified in subclause 8.5.2.

The procedure ends.

8.1.3.6 Reception of an RRC CONNECTION SETUP message by the UE

The UE shall compare the value of the IE "Initial UE identity" in the received RRC CONNECTION SETUP message with the value of the variable INITIAL_UE_IDENTITY.

If the values are different, the UE shall:

1> ignore the rest of the message.

If the values are identical, the UE shall:

- 2> if IE "Specification mode" is set to "Preconfiguration" and IE "Preconfiguration mode" is set to "Predefined configuration":
- 3> initiate the radio bearer and transport channel configuration in accordance with the predefined parameters identified by the IE "Predefined configuration identity" with the following exception;
 - 4> ignore the IE "RB to setup list" and the IE "Re- establishment timer".
 - NOTE: IE above IEs are mandatory to include in IE 'Predefined RB configuration' that is included in System Information Block 16 but should be ignored since it is not possible to establish a RAB during RRC connection establishment.
- 3> initiate the physical channels in accordance with the received physical channel information elements;
 - 2> if IE "Specification mode" is set to "Preconfiguration" and IE "Preconfiguration mode" is set to "Default configuration":
- 3> initiate the radio bearer and transport channel configuration in accordance with the default parameters identified by the IE "Default configuration mode" and IE "Default configuration identity";
- 3> initiate the physical channels in accordance with the received physical channel information elements.
 - NOTE: IE "Default configuration mode" specifies whether the FDD or TDD version of the default configuration shall be used.
 - 2> if IE "Specification mode" is set to "Complete specification":
- 3> initiate the radio bearer, transport channel and physical channel configuration in accordance with the received radio bearer, transport channel and physical channel information elements.
 - 1> clear the variable ESTABLISHMENT CAUSE;
 - 1> stop timer T300, and act upon all received information elements as specified in subclause 8.6, unless specified otherwise in the following:
 - 2> if the UE, according to subclause 8.6.3.3, will be in the CELL_FACH state at the conclusion of this procedure:
- 3> if the IE "Frequency info" is included:
 - 4> select a suitable UTRA cell according to [4] on that frequency.
- 3> enter UTRA RRC connected mode;
- 3> select PRACH according to subclause 8.5.17;
- 3> select Secondary CCPCH according to subclause 8.5.19;
- 3> ignore the IE "UTRAN DRX cycle length coefficient" and stop using DRX.
 - 1> if the UE, according to subclause 8.6.3.3, will be in the CELL_DCH state at the conclusion of this procedure:
 - 2> perform the physical layer synchronisation procedure A as specified in [29] (FDD only);
 - 2> enter UTRA RRC connected mode.
 - 1> submit an RRC CONNECTION SETUP COMPLETE message to the lower layers on the uplink DCCH after successful state transition per subclause 8.6.3.3, with the contents set as specified below:
 - 2> set the IE "RRC transaction identifier" to:

- 3> the value of "RRC transaction identifier" in the entry for the RRC CONNECTION SETUP message in the table "Accepted transactions" in the variable TRANSACTIONS; and
- 3> clear that entry.
 - 2> if the USIM or SIM is present:
- 3> set the "START" for each CN domain in the IE "START list" in the RRC CONNECTION SETUP COMPLETE message with the corresponding START value that is stored in the USIM [50] if present, or as stored in the UE if the SIM is present; and then
- 3> set the START value stored in the USIM [50] if present, and as stored in the UE if the SIM is present for any CN domain to the value "THRESHOLD" of the variable START_THRESHOLD.
 - 2> if neither the USIM nor SIM is present:
- 3> set the "START" for each CN domain in the IE "START list" in the RRC CONNECTION SETUP COMPLETE message to zero;
- 3> set the value of "THRESHOLD" in the variable "START_THRESHOLD" to the default value [40].
 - 2> retrieve its UTRA UE radio access capability information elements from variable UE_CAPABILITY_REQUESTED; and then
 - 2> include this in IE "UE radio access capability" and IE "UE radio access capability extension", provided this IE is included in variable UE_CAPABILITY_REQUESTED;
 - 2> retrieve its inter-RAT-specific UE radio access capability information elements from variable UE_CAPABILITY_REQUESTED; and then
 - 2> include this in IE "UE system specific capability".

When the RRC CONNECTION SETUP COMPLETE message has been submitted to lower layers for transmission the UE shall:

- 1> if the UE has entered CELL_FACH state:
 - 2> start timer T305 using its initial value if periodical update has been configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity" in the variable TIMERS_AND_CONSTANTS.
- 1> store the contents of the variable UE_CAPABILITY_REQUESTED in the variable UE_CAPABILITY_TRANSFERRED;
- 1> initialise variables upon entering UTRA RRC connected mode as specified in subclause 13.4;
- 1> consider the procedure to be successful;

And the procedure ends.

8.1.3.7 Physical channel failure or cell re-selection

- 1> If the UE failed to establish, per subclause 8.5.4, the physical channel(s) indicated in the RRC CONNECTION SETUP message; or
- 1> if the UE performs cell re-selection; or
- 1> if the UE will be in the CELL_FACH state at the conclusion of this procedure; and
- 1> if the received RRC CONNECTION SETUP message included the IE "Frequency info" and the UE could not find a suitable UTRA cell on that frequency but it could find a suitable UTRA cell on another frequency; or
- 1> if the received RRC CONNECTION SETUP message included the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD), and the UE selected another cell than indicated by this IE; or
- 1> if the contents of the variable C_RNTI is empty;

- 1> after having received an RRC CONNECTION SETUP message with the value of the IE "Initial UE identity" equal to the value of the variable INITIAL_UE_IDENTITY; and
- 1> before the RRC CONNECTION SETUP COMPLETE message is delivered to lower layers for transmission:

the UE shall:

- 1> clear the entry for the RRC CONNECTION SETUP message in the table "Accepted transactions" in the variable TRANSACTIONS;
- 1> check the value of V300, and:
 - 2> if V300 is equal to or smaller than N300:
- 3> set CFN in relation to SFN of current cell according to subclause 8.5.15;
- 3> set the IEs in the RRC CONNECTION REQUEST message according to subclause 8.1.3.3;
- 3> perform the mapping of the Access Class to an Access Service Class as specified in subclause 8.5.13, and apply the given Access Service Class when accessing the RACH;
- 3> submit a new RRC CONNECTION REQUEST message to the lower layers for transmission on the uplink CCCH;
- 3> increment counter V300; and
- 3> restart timer T300 when the MAC layer indicates success or failure in transmitting the message.
 - 2> if V300 is greater than N300:
- 3> enter idle mode;
- 3> perform the actions specified in subclause 8.5.2 when entering idle mode from connected mode;
- 3> consider the RRC establishment procedure to be unsuccessful;
- 3> the procedure ends.

8.1.3.8 Invalid RRC CONNECTION SETUP message, unsupported configuration or invalid configuration

If the UTRAN instructs the UE to use a configuration, which it does not support e.g., the message includes a predefined configuration that the UE has not stored and/or if the received message causes the variable UNSUPPORTED_CONFIGURATION or the variable INVALID_CONFIGURATION to be set to TRUE the UE shall perform procedure specific error handling as specified in this subclause.

If the UE receives an RRC CONNECTION SETUP message which contains an IE "Initial UE identity" with a value which is identical to the value of the variable INITIAL_UE_IDENTITY, but the RRC CONNECTION SETUP message contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

1> clear the entry for the RRC CONNECTION SETUP message in the table "Rejected transactions" in the variable TRANSACTIONS and proceed as below.

If the UE receives an RRC CONNECTION SETUP message which contains an IE "Initial UE identity" with a value which is identical to the value of the variable INITIAL_UE_IDENTITY:

- 1> if the RRC CONNECTION SETUP message contained a configuration the UE does not support; and/or
- 1> if the variable UNSUPPORTED_CONFIGURATION becomes set to TRUE due to the received RRC CONNECTION SETUP message; and/or
- 1> if the variable INVALID_CONFIGURATION becomes set to TRUE due to the received RRC CONNECTION SETUP message:

the UE shall:

1> clear the entry for the RRC CONNECTION SETUP message in the table "Accepted transactions" in the variable TRANSACTIONS and proceed as below.

If V300 is equal to or smaller than N300, the UE shall:

- 1> set the variable PROTOCOL ERROR INDICATOR to TRUE;
- 1> set the IEs in the RRC CONNECTION REQUEST message according to subclause 8.1.3.3;
- 1> perform the mapping of the Access Class to an Access Service Class as specified in subclause 8.5.13; and
- 1> apply the given Access Service Class when accessing the RACH;
- 1> submit a new RRC CONNECTION REQUEST message to the lower layers for transmission on the uplink CCCH;
- 1> increment counter V300; and
- 1> restart timer T300 when the MAC layer indicates success or failure in transmitting the message.

If V300 is greater than N300, the UE shall:

- 1> enter idle mode;
- 1> perform the actions specified in subclause 8.5.2 when entering idle mode from connected mode;
- 1> consider the RRC establishment procedure to be unsuccessful;
- 1> the procedure ends.

8.1.3.9 Reception of an RRC CONNECTION REJECT message by the UE

When the UE receives an RRC CONNECTION REJECT message on the downlink CCCH, it shall compare the value of the IE "Initial UE identity" in the received RRC CONNECTION REJECT message with the value of the variable INITIAL_UE_IDENTITY:

If the values are different, the UE shall ignore the rest of the message;

If the values are identical, the UE shall:

- 1> stop timer T300; and
- 1> clear the entry for the RRC CONNECTION REJECT message in the table "Accepted transactions" in the variable TRANSACTIONS;
- 1> if the UE has disabled cell reselection to a UTRA carrier due to an earlier RRC CONNECTION REJECT message, the UE shall resume cell reselection to that UTRA carrier;
- 1> if the IE "wait time" <> '0'; and
- 1> if the IE "frequency info" is present and:
 - 2> if V300 is equal to or smaller than N300:
- 3> select a suitable UTRA cell according to [4] on that frequency;
- 3> after having selected and camped on a suitable cell on the designated UTRA carrier:
 - 4> set CFN in relation to SFN of current cell according to subclause 8.5.15;
 - 4> set the contents of the RRC CONNECTION REQUEST message according to subclause 8.1.3.3;
 - 4> perform the mapping of the Access Class to an Access Service Class as specified in subclause 8.5.13, and apply the given Access Service Class when accessing the RACH;

- 4> transmit an RRC CONNECTION REQUEST message on the uplink CCCH;
- 4> reset counter V300;
- 4> start timer T300 when the MAC layer indicates success or failure in transmitting the message;
- 4> disable cell reselection to original UTRA carrier until the time stated in the IE "wait time" has elapsed or until the RRC connection establishment procedure ends, whichever occurs first;
- 3> if no suitable cell on the designated UTRA carrier is found:
 - 4> wait for at least the time stated in the IE "wait time";
 - 4> set CFN in relation to SFN of current cell according to subclause 8.5.15;
 - 4> set the IEs in the RRC CONNECTION REQUEST message according to subclause 8.1.3.3;
 - 4> perform the mapping of the Access Class to an Access Service Class as specified in subclause 8.5.13, and apply the given Access Service Class when accessing the RACH;
 - 4> then submit a new RRC CONNECTION REQUEST message to the lower layers for transmission on the uplink CCCH of the original serving cell;
 - 4> increment counter V300;
 - 4> restart timer T300 when the MAC layer indicates success or failure to transmit the message;
 - 2> if V300 is greater than N300:
- 3> enter idle mode;
- 3> perform the actions specified in subclause 8.5.2 when entering idle mode from connected mode;
- 3> consider the RRC establishment procedure to be unsuccessful;
- 3> the procedure ends.
 - 1> if the IE "inter-RAT info" is present and:
 - 2> if V300 is equal to or smaller than N300:
- 3> select a suitable cell belonging to the selected PLMN or any PLMN indicated to be equivalent to that PLMN in the designated RAT;
- 3> after having selected and camped on a suitable cell on the designated RAT:
 - 4> disable cell reselection to the original RAT until the time stated in the IE " wait time" has elapsed or until the UE successfully establishes a connection on the designated RAT, whichever occurs first.
- 3> if no suitable cell in the designated RAT is found:
 - 4> wait at least the time stated in the IE "wait time";
 - 4> set CFN in relation to SFN of current cell according to subclause 8.5.15;
 - 4> set the IEs in the RRC CONNECTION REQUEST message according to subclause 8.1.3.2.
 - 4> perform the mapping of the Access Class to an Access Service Class as specified in subclause 8.5.13, and apply the given Access Service Class when accessing the RACH;
 - 4> then submit a new RRC CONNECTION REQUEST message to the lower layers for transmission on the uplink CCCH;
 - 4> increment counter V300;
 - 4> restart timer T300 when the MAC layer indicates success or failure to transmit the message;
 - 2> if V300 is greater than N300:

- 3> enter idle mode;
- 3> perform the actions specified in subclause 8.5.2 when entering idle mode from connected mode;
- 3> consider the RRC establishment procedure to be unsuccessful;
- 3> the procedure ends.
 - 1> If neither the IEs "frequency info" nor "inter-RAT info" are present and:
 - 2> if V300 is equal to or smaller than N300:
- 3> wait at least the time stated in the IE "wait time";
- 3> set the IEs in the RRC CONNECTION REQUEST message according to subclause 8.1.3.2;
- 3> perform the mapping of the Access Class to an Access Service Class as specified in subclause 8.5.13, and apply the given Access Service Class when accessing the RACH;
- 3> submit a new RRC CONNECTION REQUEST message to the lower layers for transmission on the uplink CCCH;
- 3> increment counter V300;
- 3> restart timer T300 when the MAC layer indicates success or failure to transmit the message;
 - 2> if V300 is greater than N300:
- 3> enter idle mode;
- 3> perform the actions specified in subclause 8.5.2 when entering idle mode from connected mode;
- 3> consider the RRC establishment procedure to be unsuccessful;
- 3> the procedure ends.
 - 1> if the IE "wait time" = '0':
 - 2> enter idle mode;
 - 2> perform the actions specified in subclause 8.5.2 when entering idle mode from connected mode;
 - 2> consider the RRC establishment procedure to be unsuccessful;
 - 2> the procedure ends.

8.1.3.10 Invalid RRC CONNECTION REJECT message

If the UE receives an RRC CONNECTION REJECT message which contains an IE "Initial UE identity" with a value which is identical to the value of the IE "Initial UE identity" in the most recent RRC CONNECTION REQUEST message sent by the UE; but the RRC CONNECTION REJECT message contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows:

The UE shall:

- 1> clear the entry for the RRC CONNECTION REJECT message in the table "Rejected transactions" in the variable TRANSACTIONS;
- 1> if V300 is equal to or smaller than N300:
 - 2> set the variable PROTOCOL ERROR INDICATOR to TRUE;
 - 2> set the IEs in the RRC CONNECTION REQUEST message according to subclause 8.1.3.3;
 - 2> perform the mapping of the Access Class to an Access Service Class as specified in subclause 8.5.13, and apply the given Access Service Class when accessing the RACH;

- 2> submit a new RRC CONNECTION REQUEST message to the lower layers for transmission on the uplink CCCH;
- 2> increment counter V300;
- 2> restart timer T300 when the MAC layer indicates success or failure to transmit the message.
- 1> if V300 is greater than N300:
 - 2> enter idle mode;
 - 2> perform the actions specified in subclause 8.5.2 when entering idle mode from connected mode;
 - 2> consider the procedure to be successful;
 - 2> the procedure ends.

8.1.4 RRC connection release




Figure 8.1.4-1: RRC Connection Release procedure on the DCCH



Figure 8.1.4-2: RRC Connection Release procedure on the CCCH

8.1.4.1 General

The purpose of this procedure is to release the RRC connection including all radio bearers and all signalling radio bearers between the UE and the UTRAN. By doing so, all established signalling connections will be released.

8.1.4.2 Initiation

When the UE is in state CELL_DCH or CELL_FACH, the UTRAN may at anytime initiate an RRC connection release by transmitting an RRC CONNECTION RELEASE message using UM RLC.

When UTRAN transmits an RRC CONNECTION RELEASE message the downlink DCCH should be used, if available. If the downlink DCCH is not available in UTRAN and the UE is in CELL_FACH state, the downlink CCCH may be used.

UTRAN may transmit several RRC CONNECTION RELEASE messages to increase the probability of proper reception of the message by the UE. In such a case, the RRC SN for these repeated messages should be the same. The number of repeated messages and the interval between the messages is a network option.

8.1.4.3 Reception of an RRC CONNECTION RELEASE message by the UE

The UE shall receive and act on an RRC CONNECTION RELEASE message in states CELL_DCH and CELL_FACH. Furthermore this procedure can interrupt any ongoing procedures with the UE in the above listed states.

When the UE receives the first RRC CONNECTION RELEASE message; and

- 1> if the message is received on the CCCH, and IE "U-RNTI" is present and has the same value as the variable U_RNTI; or
- 1> if the message is received on DCCH:

the UE shall perform the RRC connection release procedure as specified below.

When the UE receives the first RRC CONNECTION RELEASE message; and

1> if the message is received on the CCCH, the IE "UTRAN group identity" is present and there is a group identity match according to subclause 8.6.3.13:

the UE shall perform the RRC connection release procedure as specified below.

The UE shall:

- 1> in state CELL_DCH:
 - 2> initialise the counter V308 to zero;
 - 2> set the IE "RRC transaction identifier" in the RRC CONNECTION RELEASE COMPLETE message to the value of "RRC transaction identifier" in the entry for the RRC CONNECTION RELEASE message in the table "Accepted transactions" in the variable TRANSACTIONS;
 - 2> submit an RRC CONNECTION RELEASE COMPLETE message to the lower layers for transmission using UM RLC on the DCCH to the UTRAN;
 - 2> if the IE "Rplmn information" is present:
- 3> the UE may:
 - 4> store the IE on the ME together with the PLMN id for which it applies;
- 3> the UE may then:
 - 4> utilise this information, typically indicating where a number of BCCH frequency ranges of a RAT may be expected to be found, during subsequent Rplmn selections of the indicated PLMN.
 - 2> start timer T308 when the RRC CONNECTION RELEASE COMPLETE message is sent on the radio interface.
 - 1> in state CELL_FACH:
 - 2> if the RRC CONNECTION RELEASE message was received on the DCCH:
- 3> set the IE "RRC transaction identifier" in the RRC CONNECTION RELEASE COMPLETE message to the value of "RRC transaction identifier" in the entry for the RRC CONNECTION RELEASE message in the table "Accepted transactions" in the variable TRANSACTIONS;
- 3> submit an RRC CONNECTION RELEASE COMPLETE message to the lower layers for transmission using AM RLC on the DCCH to the UTRAN.
- 3> when the successful transmission of the RRC CONNECTION RELEASE COMPLETE message has been confirmed by the lower layers:
 - 4> release all its radio resources; and
 - 4> indicate the release of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers; and

- 4> clear any entry for the RRC CONNECTION RELEASE message in the tables "Accepted transactions" and "Rejected transactions" in the variable TRANSACTIONS;
- 4> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
- 4> clear the variable ESTABLISHED_RABS;
- 4> pass the value of the IE "Release cause" received in the RRC CONNECTION RELEASE message to upper layers;
- 4> enter idle mode;
- 4> perform the actions specified in subclause 8.5.2 when entering idle mode.
- 3> and the procedure ends.
 - 2> if the RRC CONNECTION RELEASE message was received on the CCCH:
- 3> release all its radio resources;
- 3> indicate the release of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to the upper layers;
- 3> clear any entry for the RRC CONNECTION RELEASE message in the tables "Accepted transactions" and "Rejected transactions" in the variable TRANSACTIONS;
- 3> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
- 3> clear the variable ESTABLISHED_RABS;
- 3> pass the value of the IE "Release cause" received in the RRC CONNECTION RELEASE message to upper layers;
- 3> enter idle mode;
- 3> perform the actions specified in subclause 8.5.2 when entering idle mode;
- 3> and the procedure ends.

8.1.4.4 Invalid RRC CONNECTION RELEASE message

If the RRC CONNECTION RELEASE message contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, and if the "protocol error cause" in PROTOCOL_ERROR_INFORMATION is set to any cause value except "ASN.1 violation or encoding error", the UE shall perform procedure specific error handling as follows:

The UE shall:

- 1> ignore any IE(s) causing the error but treat the rest of the RRC CONNECTION RELEASE message as normal according to subclause 8.1.4.3, with an addition of the following actions:
 - 2> if the RRC CONNECTION RELEASE message was received on the DCCH:
- 3> set the IE "RRC transaction identifier" in the RRC CONNECTION RELEASE COMPLETE message to the value of "RRC transaction identifier" in the entry for the RRC CONNECTION RELEASE message in the table "Rejected transactions" in the variable TRANSACTIONS;
- 3> include the IE "Error indication" in the RRC CONNECTION RELEASE COMPLETE message with:
 - 4> the IE "Failure cause" set to the cause value "Protocol error"; and
 - 4> the IE "Protocol error information" set to the value of the variable PROTOCOL_ERROR_INFORMATION.

8.1.4.5 Cell re-selection or radio link failure

If the UE performs cell re-selection or the radio link failure criteria in subclause 8.5.6 are met at any time during the RRC connection release procedure and the UE has not yet entered idle mode, the UE shall:

- 1> if cell re-selection occurred (CELL_FACH state):
 - 2> perform a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection".
- 1> if radio link failure occurred (CELL_DCH state):
 - 2> release all its radio resources;
 - 2> indicate the release of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;
 - 2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
 - 2> clear the variable ESTABLISHED_RABS;
 - 2> enter idle mode;
 - 2> perform the actions specified in subclause 8.5.2 when entering idle mode;
 - 2> and the procedure ends.

8.1.4.6 Expiry of timer T308, unacknowledged mode transmission

When in state CELL_DCH and the timer T308 expires, the UE shall:

- 1> increment V308 by one;
- 1> if V308 is equal to or smaller than N308:
 - 2> prior to retransmitting the RRC CONNECTION RELEASE COMPLETE message:
- 3> if the IE "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Started":
 - 4> include the same IEs as in the last unsuccessful attempt of this message, except for the IE "Integrity check info", which is set as specified in subclause 8.5.10.

- 4> include the same IEs as in the last unsuccessful attempt of this message.
- 2> set the IE "RRC transaction identifier" in the RRC CONNECTION RELEASE COMPLETE message retransmitted below to the value of "RRC transaction identifier" in the entry for the RRC CONNECTION RELEASE message in the table "Accepted transactions" in the variable TRANSACTIONS;
- 2> send the RRC CONNECTION RELEASE COMPLETE message on signalling radio bearer RB1;
- 2> start timer T308 when the RRC CONNECTION RELEASE COMPLETE message is sent on the radio interface.
- 1> if V308 is greater than N308:
 - 2> release all its radio resources;
 - 2> indicate the release of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;
 - 2> clear any entry for the RRC CONNECTION RELEASE message in the tables "Accepted transactions" and "Rejected transactions" in the variable TRANSACTIONS;
 - 2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

- 2> clear the variable ESTABLISHED_RABS;
- 2> enter idle mode;
- 2> perform the actions specified in subclause 8.5.2 when entering idle mode;
- 2> and the procedure ends.

8.1.4.7 Void

8.1.4.8 Reception of an RRC CONNECTION RELEASE COMPLETE message by UTRAN

When UTRAN receives an RRC CONNECTION RELEASE COMPLETE message from the UE, it should:

1> release all UE dedicated resources and the procedure ends on the UTRAN side.

8.1.4.9 Unsuccessful transmission of the RRC CONNECTION RELEASE COMPLETE message, acknowledged mode transmission

When acknowledged mode was used and RLC does not succeed in transmitting the RRC CONNECTION RELEASE COMPLETE message, the UE shall:

- 1> release all its radio resources;
- 1> indicate the release of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;
- 1> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
- 1> clear the variable ESTABLISHED_RABS;
- 1> enter idle mode;
- 1> perform the actions specified in subclause 8.5.2 when entering idle mode;
- 1> and the procedure ends.

8.1.4.10 Detection of loss of dedicated physical channel by UTRAN in CELL_DCH state

If the release is performed from the state CELL_DCH, and UTRAN detects loss of the dedicated physical channel according to subclause 8.5.6, UTRAN may release all UE dedicated resources, even if no RRC CONNECTION RELEASE COMPLETE message has been received.

8.1.4.11 Failure to receive RRC CONNECTION RELEASE COMPLETE message by UTRAN

If UTRAN does not receive any RRC CONNECTION RELEASE COMPLETE message, it should release all UE dedicated resources.

8.1.4a RRC connection release requested by upper layers

8.1.4a.1 General

The purpose of this procedure is to release the RRC connection and bar the current cell or cells. The procedure is requested by upper layers when they determine that the network has failed an authentication check [5].

8.1.4a.2 Initiation

If the upper layers request the release of the RRC connection, the UE shall:

- 1> release all its radio resources;
- 1> enter idle mode;
- 1> perform other actions when entering idle mode from connected mode as specified in subclause 8.5.2;
- 1> if the UE was in CELL_DCH state prior to entering idle mode:
 - 2> consider all cells that were in the active set prior to entering idle mode to be barred according to [4]; and
 - 2> consider the barred cells as using the value "allowed" in the IE "Intra-frequency cell re-selection indicator", and the maximum value in the IE " T_{barred} ".
- 1> if the UE was in CELL_FACH or CELL_PCH or URA_PCH state prior to entering idle mode:
 - 2> consider the cell on which the UE was camped prior to entering idle mode to be barred according to [4]; and
 - 2> consider the barred cell as using the value "allowed" in the IE "Intra-frequency cell re-selection indicator", and the maximum value in the IE " T_{barred} ".

8.1.5 Void

8.1.6 Transmission of UE capability information




Figure 8.1.6-1: Transmission of UE capability information, normal flow

8.1.6.1 General

The UE capability update procedure is used by the UE to convey UE specific capability information to the UTRAN.

8.1.6.2 Initiation

The UE shall initiate the UE capability update procedure in the following situations:

- 1> the UE receives a UE CAPABILITY ENQUIRY message from the UTRAN;
- 1> while in connected mode the UE capabilities change compared to those stored in the variable UE_CAPABILITY_TRANSFERRED.

If the UE CAPABILITY INFORMATION message is sent in response to a UE CAPABILITY ENQUIRY message, the UE shall:

- 1> include the IE "RRC transaction identifier"; and
- 1> set it to the value of "RRC transaction identifier" in the entry for the UE CAPABILITY ENQUIRY message in the table "Accepted transactions" in the variable TRANSACTIONS;

- 1> retrieve its UTRA UE radio access capability information elements from variable UE_CAPABILITY_REQUESTED; and
- 1> include this in IE "UE radio access capability" and in IE "UE radio access capability extension", provided this IE is included in variable UE_CAPABILITY_REQUESTED;
- 1> retrieve its inter-RAT-specific UE radio access capability information elements from variable UE_CAPABILITY_REQUESTED; and
- 1> include this in IE "UE system specific capability".

If the UE CAPABILITY INFORMATION message is sent because one or more of the UE capabilities change compared to those stored in the variable UE_CAPABILITY_TRANSFERRED while in connected state, the UE shall include the information elements associated with the capabilities that have changed in the UE CAPABILITY INFORMATION message.

If the UE is in CELL_PCH or URA_PCH state, it shall first perform a cell update procedure using the cause "uplink data transmission", see subclause 8.3.1.

The UE RRC shall submit the UE CAPABILITY INFORMATION message to the lower layers for transmission on the uplink DCCH using AM RLC. When the message has been delivered to lower layers for transmission the UE RRC shall start timer T304 and set counter V304 to 1.

8.1.6.3 Reception of a UE CAPABILITY INFORMATION message by the UTRAN

Upon reception of a UE CAPABILITY INFORMATION message, the UTRAN should transmit a UE CAPABILITY INFORMATION CONFIRM message on the downlink DCCH using UM or AM RLC. After the UE CAPABILITY INFORMATION CONFIRM message has been submitted to the lower layers for transmission, the procedure is complete.

8.1.6.4 Reception of the UE CAPABILITY INFORMATION CONFIRM message by the UE

Upon reception of a UE CAPABILITY INFORMATION CONFIRM message, the UE shall:

- 1> stop timer T304;
- 1> if there is an entry for the UE CAPABILITY ENQUIRY message is present in the table "Accepted transactions" in the variable TRANSACTIONS:
 - 2> clear that entry.
- 1> update its variable UE_CAPABILITY_TRANSFERRED with the UE capabilities it has last transmitted to the UTRAN during the current RRC connection;
- 1> clear the variable UE_CAPABILITY_REQUESTED;
- 1> and the procedure ends.

8.1.6.5 Invalid UE CAPABILITY INFORMATION CONFIRM message

If the UE receives a UE CAPABILITY INFORMATION CONFIRM message, which contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows:

- 1> stop timer T304;
- 1> transmit an RRC STATUS message on the uplink DCCH using AM RLC;
- 1> include the IE "Identification of received message"; and
- 1> set the IE "Received message type" to UE CAPABILITY INFORMATION CONFIRM; and

- 1> set the IE "RRC transaction identifier" to the value of "RRC transaction identifier" in the entry for the UE CAPABILITY INFORMATION CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS; and
- 1> clear that entry;
- 1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION;
- 1> when the RRC STATUS message has been submitted to lower layers for transmission:
 - 2> restart timer T304 and continue with any ongoing procedures or processes as if the invalid UE CAPABILITY INFORMATION CONFIRM message has not been received.

8.1.6.6 T304 timeout

Upon expiry of timer T304, the UE shall check the value of V304 and:

- 1> if V304 is smaller than or equal to N304:
 - 2> prior to retransmitting the UE CAPABILITY INFORMATION message:
- 3> if the IE "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Started":
 - 4> include the same IEs as in the last unsuccessful attempt of this message, except for the IE "Integrity check info", which is set as specified in subclause 8.5.10.
- 3> else:
- 4> include the same IEs as in the last unsuccessful attempt of this message.
- 2> send the UE CAPABILITY INFORMATION message on signalling radio bearer RB2;
- 2> restart timer T304;
- 2> increment counter V304.
- 1> if V304 is greater than N304:
 - 2> initiate the Cell update procedure as specified in subclause 8.3.1, using the cause "Radio link failure".

8.1.7 UE capability enquiry




Figure 8.1.7-1: UE capability enquiry procedure, normal flow

8.1.7.1 General

The UE capability enquiry can be used to request the UE to transmit its capability information related to any radio access network that is supported by the UE.

8.1.7.2 Initiation

The UE capability enquiry procedure is initiated by the UTRAN by transmitting a UE CAPABILITY ENQUIRY message on the DCCH using UM or AM RLC.

8.1.7.3 Reception of a UE CAPABILITY ENQUIRY message by the UE

Upon reception of a UE CAPABILITY ENQUIRY message, the UE shall act on the received information elements as specified in subclause 8.6 and initiate the transmission of UE capability information procedure, which is specified in subclause 8.1.6.

8.1.7.4 Invalid UE CAPABILITY ENQUIRY message

If the UE receives a UE CAPABILITY ENQUIRY message, which contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows:

- 1> transmit an RRC STATUS message on the uplink DCCH using AM RLC;
- 1> include the IE "Identification of received message"; and
- 1> set the IE "Received message type" to UE CAPABILITY ENQUIRY; and
- 1> set the IE "RRC transaction identifier" to the value of "RRC transaction identifier" in the entry for the UE CAPABILITY ENQUIRY message in the table "Rejected transactions" in the variable TRANSACTIONS; and
- 1> clear that entry;
- 1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL ERROR INFORMATION;
- 1> when the RRC STATUS message has been submitted to lower layers for transmission:
 - 2> continue with the ongoing processes and procedures as if the invalid UE CAPABILITY ENQUIRY message has not been received.

8.1.8 Initial Direct transfer



Figure 8.1.8-1: Initial Direct transfer in the uplink, normal flow

8.1.8.1 General

The initial direct transfer procedure is used in the uplink to establish a signalling connection. It is also used to carry an initial upper layer (NAS) message over the radio interface.

8.1.8.2 Initiation of Initial direct transfer procedure in the UE

In the UE, the initial direct transfer procedure shall be initiated, when the upper layers request establishment of a signalling connection. This request also includes a request for the transfer of a NAS message.

Upon initiation of the initial direct transfer procedure the UE shall:

1> set the variable ESTABLISHMENT_CAUSE to the cause for establishment indicated by upper layers.

Upon initiation of the initial direct transfer procedure when the UE is in idle mode, the UE shall:

- 1> perform an RRC connection establishment procedure, according to subclause 8.1.3;
- 1> if the RRC connection establishment procedure was not successful:
 - 2> indicate failure to establish the signalling connection to upper layers and end the procedure.
- 1> when the RRC connection establishment procedure is completed successfully:
 - 2> continue with the initial direct transfer procedure as below.

Upon initiation of the initial direct transfer procedure when the UE is in CELL_PCH or URA_PCH state, the UE shall:

- 1> perform a cell update procedure, according to subclause 8.3.1, using the cause "uplink data transmission";
- 1> when the cell update procedure completed successfully:
 - 2> continue with the initial direct transfer procedure as below.

The UE shall, in the INITIAL DIRECT TRANSFER message:

- 1> set the IE "NAS message" as received from upper layers; and
- 1> set the IE "CN domain identity" as indicated by the upper layers; and
- 1> set the IE "Intra Domain NAS Node Selector" as follows:
 - 2> derive the IE "Intra Domain NAS Node Selector" from TMSI/PMTSI, IMSI, or IMEI; and
 - 2> provide the coding of the IE "Intra Domain NAS Node Selector" according to the following priorities:
- 1. derive the routing parameter for IDNNS from TMSI (CS domain) or PTMSI (PS domain) whenever a valid TMSI/PTMSI is available;
- 2. base the routing parameter for IDNNS on IMSI when no valid TMSI/PTMSI is available;
- 3. base the routing parameter for IDNNS on IMEI only if no (U)SIM is inserted in the UE.
 - 1> if the variable ESTABLISHMENT_CAUSE_ is initialised:
 - 2> set the IE "Establishment cause" to the value of the variable ESTABLISHMENT_CAUSE;
 - 2> clear the variable ESTABLISHMENT_CAUSE.
 - 1> calculate the START according to subclause 8.5.9 for the CN domain as set in the IE "CN Domain Identity"; and
 - 1> include the calculated START value for that CN domain in the IE "START".

The UE shall:

- 1> transmit the INITIAL DIRECT TRANSFER message on the uplink DCCH using AM RLC on signalling radio bearer RB3;
- 1> when the INITIAL DIRECT TRANSFER message has been submitted to lower layers for transmission:
 - 2> confirm the establishment of a signalling connection to upper layers; and
 - 2> add the signalling connection with the identity indicated by the IE "CN domain identity" in the variable ESTABLISHED_SIGNALLING_CONNECTIONS.
- 1> when the successful delivery of the INITIAL DIRECT TRANSFER message has been confirmed by RLC:
 - 2> the procedure ends.

When not stated otherwise elsewhere, the UE may also initiate the initial direct transfer procedure when another procedure is ongoing, and in that case the state of the latter procedure shall not be affected.

A new signalling connection request may be received from upper layers during transition to idle mode. In those cases, from the time of the indication of release to upper layers until the UE has entered idle mode, any such upper layer request to establish a new signalling connection shall be queued. This request shall be processed after the UE has entered idle mode.

8.1.8.2a RLC re-establishment or inter-RAT change

If a re-establishment of the transmitting side of the RLC entity on signalling radio bearer RB3 occurs before the successful delivery of the INITIAL DIRECT TRANSFER message has been confirmed by RLC, the UE shall:

1> retransmit the INITIAL DIRECT TRANSFER message on the uplink DCCH using AM RLC on signalling radio bearer RB3.

If an Inter-RAT handover from UTRAN procedure occurs before the successful delivery of the INITIAL DIRECT TRANSFER message has been confirmed by RLC, for messages with the IE "CN domain identity" set to "CS domain", the UE shall:

1> retransmit the NAS message as specified in subclause 8.3.7.4.

8.1.8.2ab Inter-RAT handover from UTRAN to GERAN *Iu mode*

If an Inter-RAT handover from UTRAN to GERAN *Iu mode* occurs before the successful delivery of the INITIAL DIRECT TRANSFER message has been confirmed by RLC, for messages for all CN domains, the UE shall:

1> retransmit the NAS message as specified in subclause 8.3.7.4.

8.1.8.2b Abortion of signalling connection establishment

If the UE receives a request from upper layers to release (abort) the signalling connection for the CN domain for which the initial direct transfer procedure is ongoing, the UE shall:

- 1> if the UE has not yet entered UTRA RRC connected mode:
 - 2> abort the RRC connection establishment procedure as specified in subclause 8.1.3;

the procedure ends.

8.1.8.3 Reception of INITIAL DIRECT TRANSFER message by the UTRAN

On reception of the INITIAL DIRECT TRANSFER message the NAS message should be routed using the IE "CN Domain Identity". UTRAN may also use the IE "Intra Domain NAS Node Selector" for routing among the CN nodes for the addressed CN domain.

If no signalling connection exists towards the chosen node, then a signalling connection is established.

When the UTRAN receives an INITIAL DIRECT TRANSFER message, it shall not affect the state of any other ongoing RRC procedures, when not stated otherwise elsewhere.

The UTRAN should:

1> set the START value for the CN domain indicated in the IE "CN domain identity" to the value of the IE "START".

8.1.9 Downlink Direct transfer



Figure 8.1.9-1: Downlink Direct transfer, normal flow

8.1.9.1 General

The downlink direct transfer procedure is used in the downlink direction to carry upper layer (NAS) messages over the radio interface.

8.1.9.2 Initiation of downlink direct transfer procedure in the UTRAN

In the UTRAN, the direct transfer procedure is initiated when the upper layers request the transfer of a NAS message after the initial signalling connection is established. The UTRAN may also initiate the downlink direct transfer procedure when another RRC procedure is ongoing, and in that case the state of the latter procedure shall not be affected. The UTRAN shall transmit the DOWNLINK DIRECT TRANSFER message on the downlink DCCH using AM RLC on signalling radio bearer RB3 or signalling radio bearer RB4. The UTRAN should:

- 1> if upper layers indicate "low priority" for this message:
 - 2> select signalling radio bearer RB4, if available. Specifically, for a GSM-MAP based CN, signalling radio bearer RB4 should, if available, be selected when "SAPI 3" is requested;
 - 2> select signalling radio bearer RB3 when signalling radio bearer RB4 is not available.
- 1> if upper layers indicate "high priority" for this message:
 - 2> select signalling radio bearer RB3. Specifically, for a GSM-MAP based CN, signalling radio bearer RB3 should be selected when "SAPI 0" is requested.

The UTRAN sets the IE "CN Domain Identity" to indicate, which CN domain the NAS message is originated from.

8.1.9.3 Reception of a DOWNLINK DIRECT TRANSFER message by the UE

Upon reception of the DOWNLINK DIRECT TRANSFER message, the UE RRC shall, using the IE "CN Domain Identity", route the contents of the IE "NAS message" and the value of the IE "CN Domain Identity" to upper layers.

The UE shall clear the entry for the DOWNLINK DIRECT TRANSFER message in the table "Accepted transactions" in the variable TRANSACTIONS.

When the UE receives a DOWNLINK DIRECT TRANSFER message, it shall not affect the state of any other ongoing RRC procedures when not stated otherwise elsewhere.

8.1.9.3a No signalling connection exists

If the UE receives a DOWNLINK DIRECT TRANSFER message, and the signalling connection identified with the IE "CN domain identity" does not exist according to the variable ESTABLISHED_SIGNALLING_CONNECTIONS, the UE shall:

- 1> ignore the content of the DOWNLINK DIRECT TRANSFER message;
- 1> transmit an RRC STATUS message on the uplink DCCH using AM RLC;

- 1> include the IE "Identification of received message"; and
- 1> set the IE "Received message type" to DOWNLINK DIRECT TRANSFER; and
- 1> set the IE "RRC transaction identifier" to the value of "RRC transaction identifier" in the entry for the DOWNLINK DIRECT TRANSFER message in the table "Accepted transactions" in the variable TRANSACTIONS; and
- 1> clear that entry;
- 1> include the IE "Protocol error information" with the IE "Protocol error cause" set to "Message not compatible with receiver state".

When the RRC STATUS message has been submitted to lower layers for transmission, the UE shall:

1> continue with any ongoing processes and procedures as if the DOWNLINK DIRECT TRANSFER message has not been received.

8.1.9.4 Invalid DOWNLINK DIRECT TRANSFER message

If the UE receives a DOWNLINK DIRECT TRANSFER message, which contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows:

- 1> transmit an RRC STATUS message on the uplink DCCH using AM RLC;
- 1> include the IE "Identification of received message"; and
- 1> set the IE "Received message type" to DOWNLINK DIRECT TRANSFER; and
- 1> set the IE "RRC transaction identifier" to the value of "RRC transaction identifier" in the entry for the DOWNLINK DIRECT TRANSFER message in the table "Rejected transactions" in the variable TRANSACTIONS; and
- 1> clear that entry;
- 1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION.

When the RRC STATUS message has been submitted to lower layers for transmission, the UE shall:

1> continue with any ongoing processes and procedures as if the invalid DOWNLINK DIRECT TRANSFER message has not been received.

8.1.10 Uplink Direct transfer




Figure 8.1.10-1: Uplink Direct transfer, normal flow

8.1.10.1 General

The uplink direct transfer procedure is used in the uplink direction to carry all subsequent upper layer (NAS) messages over the radio interface belonging to a signalling connection.

8.1.10.2 Initiation of uplink direct transfer procedure in the UE

In the UE, the uplink direct transfer procedure shall be initiated when the upper layers request a transfer of a NAS message on an existing signalling connection. When not stated otherwise elsewhere, the UE may initiate the uplink direct transfer procedure when another procedure is ongoing, and in that case the state of the latter procedure shall not be affected.

Upon initiation of the uplink direct transfer procedure in CELL_PCH or URA_PCH state, the UE shall:

- 1> perform a cell update procedure, according to subclause 8.3.1, using the cause "uplink data transmission";
- 1> when the cell update procedure has been completed successfully:
 - 2> continue with the uplink direct transfer procedure as below.

The UE shall transmit the UPLINK DIRECT TRANSFER message on the uplink DCCH using AM RLC on signalling radio bearer RB3 or signalling radio bearer RB4. The UE shall:

- 1> if upper layers indicate "low priority" for this message:
 - 2> select signalling radio bearer RB4, if available. Specifically, for a GSM-MAP based CN, signalling radio bearer RB4 shall, if available, be selected when "SAPI 3" is requested;
 - 2> select signalling radio bearer RB3 when signalling radio bearer RB4 is not available;
- 1> if upper layers indicate "high priority" for this message:
 - 2> select signalling radio bearer RB3. Specifically, for a GSM-MAP based CN, signalling radio bearer RB3 shall be selected when "SAPI 0" is requested.

The UE shall set the IE "NAS message" as received from upper layers and set the IE "CN domain identity" as indicated by the upper layers.

When the successful delivery of the UPLINK DIRECT TRANSFER message has been confirmed by RLC the procedure ends.

8.1.10.2a RLC re-establishment or inter-RAT change

If signalling radio bearer RB n (where n equals to 3 or 4) was used when transmitting the UPLINK DIRECT TRANSFER message and a re-establishment of the transmitting side of the RLC entity on the same signalling radio bearer RB n occurs before the successful delivery of the UPLINK DIRECT TRANSFER message has been confirmed by RLC, the UE shall:

1> retransmit the UPLINK DIRECT TRANSFER message on the uplink DCCH using AM RLC on signalling radio bearer RB n.

If an Inter-RAT handover from UTRAN procedure occurs before the successful delivery of the UPLINK DIRECT TRANSFER message has been confirmed by RLC, for messages with the IE "CN domain identity" set to "CS domain", the UE shall:

1> retransmit the NAS message as specified in subclause 8.3.7.4.

8.1.10.2b Inter-RAT handover from UTRAN to GERAN *lu mode*

If an Inter-RAT handover from UTRAN to GERAN *Iu mode* occurs before the successful delivery of the UPLINK DIRECT TRANSFER message has been confirmed by RLC, for messages for all CN domains, the UE shall:

1> retransmit the NAS message as specified in subclause 8.3.7.4.

8.1.10.3 Reception of UPLINK DIRECT TRANSFER message by the UTRAN

On reception of the UPLINK DIRECT TRANSFER message the NAS message should be routed using the value indicated in the IE "CN domain identity".

When the UTRAN receives an UPLINK DIRECT TRANSFER message, it shall not affect the state of any other ongoing RRC procedures, when not stated otherwise elsewhere.

8.1.11 UE dedicated paging




Figure 8.1.11-1: UE dedicated paging

8.1.11.1 General

This procedure is used to transmit dedicated paging information to one UE in connected mode in CELL_DCH or CELL_FACH state. Upper layers in the network may request initiation of paging.

8.1.11.2 Initiation

For a UE in CELL_DCH or CELL_FACH state, UTRAN initiates the procedure by transmitting a PAGING TYPE 2 message on the DCCH using AM RLC. When not stated otherwise elsewhere, the UTRAN may initiate the UE dedicated paging procedure also when another RRC procedure is ongoing, and in that case the state of the latter procedure shall not be affected.

UTRAN should set the IE "Paging cause" to the cause for paging received from upper layers. If no cause for paging is received from upper layers, UTRAN should set the value "Terminating – cause unknown".

8.1.11.3 Reception of a PAGING TYPE 2 message by the UE

When the UE receives a PAGING TYPE 2 message, it shall not affect the state of any other ongoing RRC procedures, when not stated otherwise elsewhere.

The UE shall:

- 1> indicate reception of paging; and
- 1> forward the IE "Paging cause" and the IE "Paging record type identifier" to upper layers.

The UE shall:

1> clear the entry for the PAGING TYPE 2 message in the table "Accepted transactions" in the variable TRANSACTIONS.

8.1.11.4 Invalid PAGING TYPE 2 message

If the UE receives a PAGING TYPE 2 message, which contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows:

- 1> transmit an RRC STATUS message on the uplink DCCH using AM RLC;
- 1> include the IE "Identification of received message"; and
- 1> set the IE "Received message type" to PAGING TYPE 2; and
- 1> set the IE "RRC transaction identifier" to the value of "RRC transaction identifier" in the entry for the PAGING TYPE 2 message in the table "Rejected transactions" in the variable TRANSACTIONS; and

- 1> clear that entry;
- 1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL ERROR INFORMATION;
- 1> when the RRC STATUS message has been submitted to lower layers for transmission:
 - 2> continue with any ongoing processes and procedures as if the invalid PAGING TYPE 2 message has not been received.

8.1.12 Security mode control




Figure 8.1.12-1: Security mode control procedure

8.1.12.1 General

The purpose of this procedure is to trigger the start of ciphering or to command the restart of the ciphering with a new ciphering configuration, for the radio bearers of one CN domain and for all signalling radio bearers.

It is also used to start integrity protection or to modify the integrity protection configuration for all signalling radio bearers.

8.1.12.2 Initiation

8.1.12.2.1 Ciphering configuration change

To start/restart ciphering, UTRAN sends a SECURITY MODE COMMAND message on the downlink DCCH in AM RLC using the most recent ciphering configuration. If no such ciphering configuration exists then the SECURITY MODE COMMAND is not ciphered. UTRAN should not transmit a SECURITY MODE COMMAND to signal a change in ciphering algorithm.

When configuring ciphering, UTRAN should ensure that the UE needs to store at most two different ciphering configurations (keyset and algorithm) per CN domain, in total over all radio bearers at any given time. For signalling radio bearers the total number of ciphering configurations that need to be stored is at most three. Prior to sending the SECURITY MODE COMMAND, for the CN domain indicated in the IE "CN domain identity" in the SECURITY MODE COMMAND, UTRAN should:

- 1> suspend all radio bearers using RLC-AM or RLC-UM and all signalling radio bearers using RLC-AM or RLC-UM, except the signalling radio bearer used to send the SECURITY MODE COMMAND message on the downlink DCCH in RLC-AM, and except signalling radio bearer RB0, according to the following:
 - 2> not transmit RLC PDUs with sequence number greater than or equal to the number in IE "Radio bearer downlink ciphering activation time info" on all suspended radio bearers and all suspended signalling radio bearers.

- 1> set, for the signalling radio bearer used to send the SECURITY MODE COMMAND, the "RLC sequence number" in IE "Radio bearer downlink ciphering activation time info" in the IE "Ciphering mode info", at which time the new ciphering configuration shall be applied;
- 1> if a transparent mode radio bearer for this CN domain exists:
 - 2> include the IE "Ciphering activation time for DPCH" in IE "Ciphering mode info", at which time the new ciphering configuration shall be applied and specify a CFN value for this IE that is a multiple of 8 frames (CFN mod 8 = 0).
- NOTE: UTRAN should chose the value for the IE "Ciphering activation time for DPCH" such that the new ciphering configuration will occur after all the pending ciphering activation times have been reached for the transparent mode radio bearers of this CN domain.
- 1> consider a ciphering activation time in downlink to be pending until the RLC sequence number of the next RLC PDU to be transmitted for the first time is equal to or larger than the selected activation time;
- 1> set, for each suspended radio bearer and signalling radio bearer that has no pending ciphering activation time set by a previous security mode control procedure, an "RLC sequence number" in IE "Radio bearer downlink ciphering activation time info" in the IE "Ciphering mode info", at which time the new ciphering configuration shall be applied;
- 1> set, for each suspended radio bearer and signalling radio bearer that has a pending ciphering activation time set by a previous security mode control procedure, the "RLC sequence number" in IE "Radio bearer downlink ciphering activation time info" in the IE "Ciphering mode info" to the value used in the previous security mode control procedure, at which time the latest ciphering configuration shall be applied;
- 1> if Integrity protection has already been started for the UE:
 - 2> if for the CN domain indicated in the IE "CN domain identity" in the SECURITY MODE COMMAND, a new security key set (new ciphering and integrity protection keys) has been received from upper layers since the transmission of the last SECURITY MODE COMMAND message for that CN domain:
- 3> include the IE "Integrity protection mode info" in the SECURITY MODE COMMAND.
 - 2> if the IE "CN domain identity" in the SECURITY MODE COMMAND is different from the IE "CN domain identity" that was sent in the previous SECURITY MODE COMMAND message to the UE:
- 3> include the IE "Integrity protection mode info" in the SECURITY MODE COMMAND.
 - 1> transmit the SECURITY MODE COMMAND message on RB2.

8.1.12.2.2 Integrity protection configuration change

To start or modify integrity protection, UTRAN sends a SECURITY MODE COMMAND message on the downlink DCCH in AM RLC using the new integrity protection configuration. UTRAN should not "modify" integrity protection for a CN domain to which a SECURITY MODE COMMAND configuring integrity protection has been previously sent for an ongoing signalling connection unless the application of new integrity keys needs to be signalled to the UE. UTRAN should not transmit a SECURITY MODE COMMAND to signal a change in integrity protection algorithm.

When configuring Integrity protection, UTRAN should:

- 1> ensure that the UE needs to store at most three different Integrity protection configurations (keysets) at any given time. This includes the total number of Integrity protection configurations for all signalling radio bearers;
- 1> if Ciphering has already been started for the UE for the CN domain to be set in the IE "CN domain identity" in the SECURITY MODE COMMAND:
 - 2> if for the CN domain indicated in the IE "CN domain identity" in the SECURITY MODE COMMAND, a new security key set (new ciphering and integrity protection keys) has been received from upper layers since the transmission of the last SECURITY MODE COMMAND message for that CN domain:
- 3> include the IE "Ciphering mode info" in the SECURITY MODE COMMAND.

- 1> if Ciphering has already been configured for the UE for a CN domain different from the CN domain to be set in the IE "CN domain identity" in the SECURITY MODE COMMAND:
 - 2> include the IE "Ciphering mode info" in the SECURITY MODE COMMAND.

Prior to sending the SECURITY MODE COMMAND, for the CN domain indicated in the IE "CN domain identity" in the SECURITY MODE COMMAND, UTRAN should:

- 1> if this is the first SECURITY MODE COMMAND sent for this RRC connection:
 - 2> if new keys have been received:
- 3> initialise the hyper frame numbers as follows:
 - 4> set all bits of the hyper frame numbers of the COUNT-I values for all signalling radio bearers to zero.
 - 2> else (if new keys have not been received):

3> use the value "START" in the most recently received IE "START list" or IE "START" that belongs to the CN domain indicated in the IE "CN domain identity" to initialise all hyper frame numbers of COUNT-I for all the signalling radio bearers by:

- 4> setting the 20 most significant bits of the hyper frame numbers for all signalling radio bearers to the value "START" in the most recently received IE "START list" or IE "START" for that CN domain;
- 4> setting the remaining bits of the hyper frame numbers equal to zero.
- 1> else (this is not the first SECURITY MODE COMMAND sent for this RRC connection):
 - 2> if new keys have been received:
- 3> initialise the hyper frame number for COUNT-I for RB2 as follows:
 - 4> set all bits of the HFN of the COUNT-I value for RB2 to zero.
 - 2> if new keys have not been received:
- 3> initialise the hyper frame number for COUNT-I for RB2 as follows:
 - 4> set the 20 most significant bits of the HFN of the downlink and uplink COUNT-I to the value of the most recently received IE "START" or IE "START list" for the CN domain to be set in the IE "CN Domain Identity";
 - 4> set the remaining bits of the HFN of the downlink and uplink COUNT-I to zero.
 - $1\!\!>$ if the IE "Integrity protection mode command" has the value "Start":
 - 2> prohibit the transmission of signalling messages with any RRC SN on all signalling radio bearers, except RB2:
 - 2> set the FRESH value in the IE "Integrity protection initialisation number", included in the IE "Integrity protection mode info".
 - 1> if the IE "Integrity protection mode command" has the value "Modify":
 - 2> for each signalling radio bearer RBn, except RB2:
- 3> prohibit the transmission of signalling messages with RRC SN greater or equal to the RRC sequence number in entry for signalling radio bearer n in the "RRC message sequence number list" in the IE "Downlink integrity protection activation info", included in the IE "Integrity protection mode info".
 - 2> consider an integrity protection activation time in downlink to be pending until the selected activation time is equal to the next RRC sequence number to be used, which means that the last RRC message using the old integrity protection configuration has been submitted to lower layers;
 - 2> set, for each signalling radio bearer RBn, that has no pending integrity protection activation time set by a previous security mode control procedure, an RRC sequence number in entry for signalling radio bearer n in

- the "RRC message sequence number list" in the IE "Downlink integrity protection activation info", included in the IE "Integrity protection mode info", at which time the new integrity protection configuration shall be applied;
- 2> set, for each signalling radio bearer RBn, that has a pending integrity protection activation time set by a previous security mode control procedure, the RRC sequence number in entry for signalling radio bearer n in the "RRC message sequence number list" in the IE "Downlink integrity protection activation info", included in the IE "Integrity protection mode info", to the value used in the previous security mode control procedure, at which time the latest integrity protection configuration shall be applied.
- 1> transmit the SECURITY MODE COMMAND message on RB2 using the new integrity protection configuration.
- NOTE1: In the case of re-initialisation of Integrity Protection at HFN wrap around, the network should take into account the UE actions as described in subclauses 8.5.10.1 and 8.5.10.2.
- NOTE2: After the SECURITY MODE COMMAND message is transmitted, the network should ensure that it can revert back to old integrity protection until it receives the SECURITY MODE COMPLETE message, to take into account the UE actions when security mode control procedure is unsuccessful. The network should also be aware that the UE may revert to old configuration when waiting for the acknowledgement from L2 for the SECURITY MODE COMPLETE message, and act accordingly.

8.1.12.3 Reception of SECURITY MODE COMMAND message by the UE

Upon reception of the SECURITY MODE COMMAND message, the UE shall:

- 1> if neither IE "Ciphering mode info" nor IE "Integrity protection mode info" is included in the SECURITY MODE COMMAND:
 - 2> set the variable INVALID_CONFIGURATION to TRUE.
- 1> if the IE "Security capability" is the same as indicated by variable UE_CAPABILITY_TRANSFERRED, and the IE "GSM security capability" (if included in the SECURITY MODE COMMAND) is the same as indicated by the variable UE_CAPABILITY_TRANSFERRED:
 - 2> set the variable LATEST_CONFIGURED_CN_DOMAIN equal to the IE "CN domain identity";
 - 2> set the IE "Status" in the variable SECURITY_MODIFICATION for the CN domain indicated in the IE "CN domain identity" in the received SECURITY MODE COMMAND to the value "Affected";
 - 2> set the IE "Status" in the variable SECURITY_MODIFICATION for all CN domains other than the CN domain indicated in the IE "CN domain identity" to "Not affected";
 - 2> set the IE "RRC transaction identifier" in the SECURITY MODE COMPLETE message to the value of "RRC transaction identifier" in the entry for the SECURITY MODE COMMAND message in the table "Accepted transactions" in the variable TRANSACTIONS; and
 - 2> clear that entry;
 - 2> if the SECURITY MODE COMMAND message contained the IE "Ciphering mode info":
- 3> perform the actions as specified in subclause 8.6.3.4.
 - 2> if the SECURITY MODE COMMAND message contained the IE "Integrity protection mode info":
- 3> perform the actions as specified in subclause 8.6.3.5.
 - 1> prior to sending the SECURITY MODE COMPLETE message:
 - 2> use the old ciphering configuration for this message;
 - 2> if the SECURITY MODE COMMAND message contained the IE "Ciphering mode info":
- 3> include and set the IE "Radio bearer uplink ciphering activation time info" to the value of the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;

- 3> for each radio bearer and signalling radio bearer that belongs to the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN:
 - 4> start or continue incrementing the COUNT-C values for all RLC-AM and RLC-UM signalling radio bearers at the ciphering activation time as specified in the procedure;
 - 4> start or continue incrementing the COUNT-C values common for all transparent mode radio bearers for this CN domain at the ciphering activation time as specified in the procedure;
 - 4> continue incrementing the COUNT-C values for all RLC-AM and RLC-UM radio bearers.
- 3> if no new security key set (new ciphering and integrity protection keys) has been received from the upper layers [40] for the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN:
 - 4> for ciphering on signalling radio bearers using RLC-AM and RLC-UM in the downlink, at the RLC sequence number indicated in IE "Radio bearer downlink ciphering activation time info" in the IE "Ciphering mode info" included in the SECURITY MODE COMMAND, for each signalling radio bearer:
 - 5> set the 20 most significant bits of the HFN component of the downlink COUNT-C to the value "START" in the most recently transmitted IE "START list" or IE "START", at the reception of the SECURITY MODE COMMAND, that belongs to the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN;
 - 5> set the remaining bits of the hyper frame numbers to zero.
- 3> if new keys have been received:
 - 4> perform the actions in subclause 8.1.12.3.1.
 - 2> if the SECURITY MODE COMMAND message contained the IE "Integrity protection mode info":
- 3> include and set the IE "Uplink integrity protection activation info" to the value of the variable INTEGRITY_PROTECTION_ACTIVATION_INFO for each signalling radio bearer;
- 3> if no new security key set (new ciphering and integrity protection keys) has been received from the upper layers [40] for the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN, for RB2:
 - 4> in the downlink, for the received SECURITY MODE COMMAND message:
 - 5> set the 20 most significant bits of the IE "Downlink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the downlink COUNT-I to the value "START" in the most recently transmitted IE "START list" or IE "START", at the reception of the SECURITY MODE COMMAND, that belongs to the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN;
 - 5> set the remaining bits of the IE "Downlink RRC HFN" to zero.
 - 4> in the uplink, for the transmitted response message, SECURITY MODE COMPLETE:
 - 5> set the 20 most significant bits of the IE "Uplink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the uplink COUNT-I to the value "START" in the most recently transmitted IE "START list" or IE "START", at the reception of the SECURITY MODE COMMAND, that belongs to the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN;
 - 5> set the remaining bits of the IE "Uplink RRC HFN" to zero.
- 3> if no new security key set (new ciphering and integrity protection keys) has been received from the upper layers [40] for the CN domain indicated in the variable LATEST_CONFIGURED_CN_DOMAIN, for each signalling radio bearer other than RB2:
 - 4> if the IE "Integrity protection mode command" has the value "start":
 - 5> in the downlink, for this signalling radio bearer:

- 6> set the 20 most significant bits of IE "Downlink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the downlink COUNT-I to the value START transmitted in the most recently transmitted IE "START list" or IE "START", at the reception of the SECURITY MODE COMMAND, that belongs to the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN;
- 6> set the remaining bits of the IE "Downlink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the downlink COUNT-I to zero;

- 5> in the downlink, for the first message for which the RRC sequence number in a received RRC message for this signalling radio bearer is equal to or greater than the activation time as indicated in IE "Downlink integrity protection activation info" as included in the IE "Integrity protection mode info", for this signalling radio bearer:
 - 6> set the 20 most significant bits of the IE "Downlink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the downlink COUNT-I to the value "START" in the most recently transmitted IE "START list" or IE "START", at the reception of the SECURITY MODE COMMAND, that belongs to the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN;
 - 6> set the remaining bits of the IE "Downlink RRC HFN" to zero.
- 3> if new keys have been received:
 - 4> perform the actions in subclause 8.1.12.3.1.
 - 2> start applying the new integrity protection configuration in the uplink for signalling radio bearer RB2 from and including the transmitted SECURITY MODE COMPLETE message;
 - 2> transmit the SECURITY MODE COMPLETE message on the uplink DCCH in AM RLC;
 - NOTE: After submission of the SECURITY MODE COMPLETE message to the lower layers, the UE should accept messages received in the DL which require the new security configuration to be applied on them. If the received message is successfully integrity checked, the UE should not discard the message due to lack of completion of the security procedure, caused by the successful delivery of the SECURITY MODE COMPLETE not having yet been confirmed by lower layers, unless the security configuration to be applied has been aborted and the message received requires integrity protection [5].
 - 1> when the successful delivery of the SECURITY MODE COMPLETE message has been confirmed by RLC:
 - 2> if the SECURITY MODE COMMAND message contained the IE "Ciphering mode info":
- 3> if no new security key set (new ciphering and integrity protection keys) has been received from the upper layers [40] for the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN:
 - 4> for ciphering on signalling radio bearers using RLC-AM and RLC-UM in the uplink, at the RLC sequence number indicated in IE "Radio bearer uplink ciphering activation time info" included in the SECURITY MODE COMPLETE, for each signalling radio bearer:
 - 5> set the HFN component of the uplink COUNT-C to the value "START" in the most recently transmitted IE "START list" or IE "START", at the reception of the SECURITY MODE COMMAND, that belongs to the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN;
 - 5> set the remaining bits of the hyper frame numbers to zero.
- 3> if new keys have been received:
 - 4> perform the actions in subclause 8.1.12.3.1.
- 3> resume data transmission on any suspended radio bearer and signalling radio bearer mapped on RLC-AM or RLC-UM:
- 3> set the IE "Reconfiguration" in the variable CIPHERING STATUS to FALSE; and

- 3> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO.
 - 2> if the SECURITY MODE COMMAND message contained the IE "Integrity protection mode info":
- 3> if no new security key set (new ciphering and integrity protection keys) has been received from the upper layers [40] for the CN domain indicated in the variable LATEST_CONFIGURED_CN_DOMAIN, for each signalling radio bearer other than RB2:
 - 4> if the IE "Integrity protection mode command" has the value "start":
 - 5> in the uplink, for this signalling radio bearer:
 - 6> set the 20 most significant bits of IE "Uplink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the uplink COUNT-I to the value START transmitted in the most recently transmitted IE "START list" or IE "START", at the reception of the SECURITY MODE COMMAND, that belongs to the CN domain as indicated in the variable LATEST CONFIGURED CN DOMAIN;
 - 6> set the remaining bits of the IE "Uplink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the uplink COUNT-I to zero.

- 5> in the uplink, for the first transmitted RRC message for this signalling radio bearer with RRC sequence number equal to the activation time as indicated in IE "Uplink integrity protection activation info" included in the transmitted SECURITY MODE COMPLETE, for this signalling radio bearer:
 - 6> set the 20 most significant bits of the IE "Uplink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the uplink COUNT-I to the value "START" in the most recently transmitted IE "START list" or IE "START", at the reception of the SECURITY MODE COMMAND, that belongs to the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN;
 - 6> set the remaining bits of the IE "Uplink RRC HFN" to zero.
- 3> if new keys have been received:
 - 4> perform the actions in subclause 8.1.12.3.1.
- 3> allow the transmission of RRC messages on all signalling radio bearers with any RRC SN;
- 3> set "Uplink RRC Message sequence number" for signalling radio bearer RB0 in the variable INTEGRITY_PROTECTION_INFO to a value such that next RRC message to be sent on uplink RB0 will use the new integrity protection configuration;
- 3> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to FALSE; and
- 3> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.
 - 2> clear the variable SECURITY MODIFICATION;
 - 2> notify upper layers upon change of the security configuration;
 - 2> and the procedure ends.
 - 1> if the IE "Security capability" is not the same as indicated by the variable UE_CAPABILITY_TRANSFERRED, or the IE "GSM security capability" (if included in the SECURITY MODE COMMAND) is not the same as indicated by the variable UE_CAPABILITY_TRANSFERRED, or if the IE "GSM security capability" is not included in the SECURITY MODE COMMAND and is included in the variable UE_CAPABILITY_TRANSFERRED:
 - 2> release all its radio resources;

- 2> indicate the release of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;
- 2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
- 2> clear the variable ESTABLISHED_RABS;
- 2> clear the variable SECURITY_MODIFICATION;
- 2> enter idle mode;
- 2> perform actions when entering idle mode as specified in subclause 8.5.2;
- 2> and the procedure ends.

8.1.12.3.1 New ciphering and integrity protection keys

NOTE: The actions in this subclause are to be performed only if the new keys were received for an ongoing signalling connection while in UTRA.

If a new security key set (new ciphering and integrity protection keys) has been received from the upper layers [40] for the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN, the UE shall:

- 1> set the START value for the CN domain indicated in the variable LATEST_CONFIGURED_CN_DOMAIN to zero;
- 1> if the SECURITY MODE COMMAND message contained the IE "Integrity protection mode info":
 - 2> for integrity protection in the downlink on each signalling radio bearer except RB2:
- 3> if IE "Integrity protection mode command" has the value "start":
 - 4> for the first received message on this signalling radio bearer:
 - 5> start using the new integrity key;
 - 5> for this signalling radio bearer:
 - 6> set the IE "Downlink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the downlink COUNT-I to zero.

- 4> for the first message for which the RRC sequence number in a received RRC message for this signalling radio bearer is equal to or greater than the activation time as indicated in IE "Downlink integrity protection activation info" as included in the IE "Integrity protection mode info":
 - 5> start using the new integrity key;
 - 5> for this signalling radio bearer:
 - 6> set the IE "Downlink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the downlink COUNT-I to zero.
- 2> for integrity protection in the uplink on each signalling radio bearer except RB2:
- 3> for the first message for which the RRC sequence number in a to be transmitted RRC message for this signalling radio bearer is equal to the activation time as indicated in IE "Uplink integrity protection activation info" included in the transmitted SECURITY MODE COMPLETE message:
 - 4> start using the new integrity key;
 - 4> for this signalling radio bearer:
 - 5> set the IE "Uplink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the uplink COUNT-I to zero.

- 2> for integrity protection in the downlink on signalling radio bearer RB2:
- 3> at the received SECURITY MODECOMMAND:
 - 4> start using the new integrity key;
 - 4> set the IE "Downlink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the downlink COUNT-I to zero.
 - 2> for integrity protection in the uplink on signalling radio bearer RB2:
- 3> at the transmitted SECURITY MODE COMPLETE:
 - 4> start using the new integrity key;
 - 4> set the IE "Uplink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the uplink COUNT-I to zero.
 - 1> if the SECURITY MODE COMMAND message contained the IE "Ciphering mode info":
 - 2> for each signalling radio bearer and for each radio bearer for the CN domain indicated in the variable LATEST_CONFIGURED_CN_DOMAIN:
- 3> if the IE "Status" in the variable CIPHERING_STATUS has the value "Started" for this CN domain, then for ciphering on radio bearers using RLC-TM:
 - 4> at the CFN as indicated in the IE "Ciphering activation time for DPCH" in the IE "Ciphering mode info":
 - 5> start using the new key in uplink and downlink;
 - 5> set the HFN component of the COUNT-C to zero.
- 3> if the IE "Status" in the variable CIPHERING_STATUS has the value "Started" for this CN domain, then for ciphering on radio bearers and signalling radio bearers using RLC-AM and RLC-UM:
 - 4> in the downlink, at the RLC sequence number indicated in IE "Radio bearer downlink ciphering activation time info" in the IE "Ciphering mode info":
 - 5> start using the new key;
 - 5> set the HFN component of the downlink COUNT-C to zero.
 - 4> in the uplink, at the RLC sequence number indicated in IE "Radio bearer uplink ciphering activation time info":
 - 5> start using the new key;
 - 5> set the HFN component of the uplink COUNT-C to zero.
 - 1> consider the value of the latest transmitted START value to be zero.

8.1.12.4 Void

8.1.12.4a Incompatible simultaneous security reconfiguration

If the variable INCOMPATIBLE_SECURITY_RECONFIGURATION becomes set to TRUE of the received SECURITY MODE COMMAND message, the UE shall:

1> transmit a SECURITY MODE FAILURE message on the uplink DCCH using AM RLC, using the ciphering and integrity protection configurations prior to the reception of this SECURITY MODE COMMAND;

- 1> set the IE "RRC transaction identifier" in the SECURITY MODE FAILURE message to the value of "RRC transaction identifier" in the entry for the SECURITY MODE COMMAND message in the table "Accepted transactions" in the variable TRANSACTIONS; and
- 1> clear that entry;
- 1> set the IE "failure cause" to the cause value "incompatible simultaneous reconfiguration";
- 1> when the response message has been submitted to lower layers for transmission:
 - 2> set the variable INCOMPATIBLE_SECURITY_RECONFIGURATION to FALSE;
 - 2> continue with any ongoing processes and procedures as if the invalid SECURITY MODE COMMAND message has not been received;
 - 2> only accept a message on SRB 2, with a COUNT-I that:
- 3> is higher than the COUNT-I used prior to receiving the SECURITY MODE COMMAND message incremented by one; and
- 3> does not take into account the HFN from the received SECURITY MODE COMMAND message.
 - 2> and the procedure ends.

8.1.12.4b Cell update procedure during security reconfiguration

If:

- a cell update procedure according to subclause 8.3.1 is initiated; and
- the received SECURITY MODE COMMAND message causes either,
 - the IE "Reconfiguration" in the variable CIPHERING_STATUS to be set to TRUE; and/or
 - the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to be set to TRUE:

the UE shall:

- 1> abort the ongoing integrity and/or ciphering reconfiguration;
- 1> resume data transmission on any suspended radio bearer and signalling radio bearer mapped on RLC-AM or RLC-UM;
- 1> allow the transmission of RRC messages on all signalling radio bearers with any RRC SN;
- 1> when the CELL UPDATE message has been submitted to lower layers for transmission:
 - 2> if the SECURITY MODE COMMAND message contained the IE "Ciphering mode info":
- $3\!\!>\!\!$ set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE; and
- 3> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;
 - 2> if the SECURITY MODE COMMAND message contained the IE "Integrity protection mode info":
- 3> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to FALSE; and
- 3> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.
 - 2> continue with any ongoing processes and procedures as if the SECURITY MODE COMMAND message has not been received:
 - 2> only accept a message on SRB 2, with a COUNT-I that:
- 3> is higher than the COUNT-I used prior to receiving the SECURITY MODE COMMAND message incremented by one; and

- 3> does not take into account the HFN from the received SECURITY MODE COMMAND message.
 - 2> if the UE has already submitted the SECURITY MODE COMPLETE message, use a COUNT-I value for transmission of the next message on SRB2 as stated below:
- 3> take the COUNT-I used prior to the transmission of the SECURITY MODE COMPLETE message;
- 3> increment that COUNT-I with 2;
- 3> apply that COUNT-I on the next message to transmit.
 - 2> clear the variable SECURITY_MODIFICATION;
 - 2> the procedure ends.

8.1.12.4c Invalid configuration

If the variable INVALID_CONFIGURATION is set to TRUE due to the received SECURITY MODE COMMAND message, the UE shall:

- 1> transmit a SECURITY MODE FAILURE message on the DCCH using AM RLC after setting the IEs as specified below:
 - 2> set the IE "RRC transaction identifier" in the SECURITY MODE FAILURE message to the value of "RRC transaction identifier" in the entry for the SECURITY MODE COMMAND message in the table "Accepted transactions" in the variable TRANSACTIONS; and
 - 2> clear that entry;
 - 2> set the IE "failure cause" to the cause value "invalid configuration".
- 1> when the response message has been submitted to lower layers for transmission:
 - 2> set the variable INVALID_CONFIGURATION to FALSE;
 - 2> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE;
 - 2> continue with any ongoing processes and procedures as if the invalid SECURITY MODE COMMAND message has not been received;
 - 2> only accept a message on SRB 2, with a COUNT-I that:
- 3> is higher than the COUNT-I used prior to receiving the SECURITY MODE COMMAND message incremented by one; and
- 3> does not take into account the HFN from the received SECURITY MODE COMMAND message.
 - 2> and the procedure ends.

8.1.12.5 Reception of SECURITY MODE COMPLETE message by the UTRAN

UTRAN should apply integrity protection on the received SECURITY MODE COMPLETE message and all subsequent messages with the new integrity protection configuration, if changed. When UTRAN has received a SECURITY MODE COMPLETE message and the integrity protection has successfully been applied, UTRAN should:

- 1> if the IE "Ciphering mode info" was included in the SECURITY MODE COMMAND message:
 - 2> if new keys were received for the CN domain set in the IE "CN Domain Identity" in the SECURITY MODE COMMAND:
- 3> set, at the downlink and uplink activation time, all the bits of the hyper frame numbers of the downlink and uplink COUNT-C values respectively for all radio bearers for this CN domain and all signalling radio bearers to zero.
 - 2> else (if new keys were not received):

- 3> use, at the downlink and uplink activation time, the value "START" in the most recently received IE "START list" or IE "START" that belongs to the CN domain as indicated in the IE "CN domain identity" to initialise all hyper frame numbers of the downlink and uplink COUNT-C values respectively for all the signalling radio bearers as follows:
 - 4> set the 20 most significant bits of the hyper frame numbers of the COUNT-C for all signalling radio bearers to the value "START" in the most recently received IE "START list" or IE "START" for that CN domain;
 - 4> set the remaining bits of the hyper frame numbers equal to zero.
 - 1> if the IE "Integrity protection mode info" was included in the SECURITY MODE COMMAND message:
 - 2> if this was not the first SECURITY MODE COMMAND message for this RRC connection:
- 3> if new keys have been received for the CN domain set in the IE "CN Domain Identity" included in the transmitted SECURITY MODE COMMAND message:
 - 4> initialise, at the downlink and uplink activation time, all hyper frame numbers of the downlink and uplink COUNT-I values respectively for all the signalling radio bearers other than RB2 as follows:
 - 5> set all bits of the hyper frame numbers of the uplink and downlink COUNT-I to zero.
- 3> if no new keys have been received for the CN domain set in the IE "CN Domain Identity" included in the transmitted SECURITY MODE COMMAND message:
 - 4> use, at the downlink and uplink activation time, the value "START" in the most recently received IE "START list" or IE "START" that belongs to the CN domain as indicated in the IE "CN domain identity" to initialise all hyper frame numbers of the downlink and uplink COUNT-I values respectively for all the signalling radio bearers other than RB2 as follows:
 - 5> set the 20 most significant bits of the hyper frame numbers of the downlink and uplink COUNT-I respectively for all signalling radio bearers to the value "START" in the most recently received IE "START list" or IE "START" for that CN domain;
 - 5> set the remaining bits of the hyper frame numbers equal to zero.
 - 1> send an indication to upper layers that the new security configuration has been activated;
 - 1> resume, in the downlink, all suspended radio bearers and all signalling radio bearers;
 - 1> allow the transmission of RRC messages on all signalling radio bearers with any RRC SN;
 - 1> if the IE "Integrity protection mode command" included in the SECURITY MODE COMMAND had the value "Start":
 - 2> start applying integrity protection in the downlink for all signalling radio bearers.
 - 1> if the IE "Integrity protection mode command" included in the SECURITY MODE COMMAND had the value "Modify":
 - 2> start applying the new integrity protection configuration in the downlink at the RRC sequence number, for each signalling radio bearer RBn, except for signalling radio bearer RB2, indicated by the entry for signalling radio bearer n in the "RRC message sequence number list" in the IE "Downlink integrity protection activation info";
 - 2> continue applying the new integrity configuration for signalling radio bearer RB2;
 - 2> apply the new integrity protection configuration on the received signalling messages with RRC SN greater than or equal to the number associated with the signalling radio bearer in IE "Uplink integrity protection activation info".
 - 1> apply the old ciphering configuration for the transmission of RLC PDUs with RLC sequence number less than the number indicated in the IE "Radio bearer downlink ciphering activation time info" included in the IE "Ciphering mode info";

- 1> apply the new ciphering configuration for the transmission of RLC PDUs with RLC sequence number greater than or equal to the number indicated in IE "Radio bearer downlink ciphering activation time info" included in the IE "Ciphering mode info";
- 1> apply the old integrity protection configuration on the received signalling messages with RRC SN smaller than the number associated with the signalling radio bearer in IE "Uplink integrity protection activation info";
- 1> for radio bearers using RLC-AM or RLC-UM:
 - 2> use the old ciphering configuration for received RLC PDUs with RLC sequence number less than the RLC sequence number indicated in the IE "Radio bearer uplink ciphering activation time info" sent by the UE;
 - 2> use the new ciphering configuration for received RLC PDUs with RLC sequence number greater than or equal to the RLC sequence number indicated in the IE "Radio bearer uplink ciphering activation time info" sent by the UE;
 - 2> if an RLC reset or re-establishment of the transmitting side of an RLC entity occurs after the SECURITY MODE COMPLETE message has been received by UTRAN before the downlink activation time for the new ciphering configuration has been reached, ignore the activation time and apply the new ciphering configuration in downlink immediately after the RLC reset or RLC re-establishment;
 - 2> if an RLC reset or re-establishment of the receiving side of an RLC entity occurs after the SECURITY MODE COMPLETE message has been received by UTRAN before the uplink activation time for the new ciphering configuration has been reached, ignore the activation time and apply the new ciphering configuration in uplink immediately after the RLC reset or RLC re-establishment.
- 1> for radio bearers using RLC-TM:
 - 2> use the old ciphering configuration for the received RLC PDUs before the CFN as indicated in the IE "Ciphering activation time for DPCH" in the IE "Ciphering mode info" as included in the SECURITY MODE COMMAND:
 - 2> use the new ciphering configuration for the received RLC PDUs at the CFN as indicated in the IE "Ciphering activation time for DPCH" in the IE "Ciphering mode info" as included in the SECURITY MODE COMMAND.
- 1> and the procedure ends.

8.1.12.6 Invalid SECURITY MODE COMMAND message

If the SECURITY MODE COMMAND message contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows:

- 1> transmit a SECURITY MODE FAILURE message on the uplink DCCH using AM RLC;
- 1> set the IE "RRC transaction identifier" in the SECURITY MODE FAILURE message to the value of "RRC transaction identifier" in the entry for the SECURITY MODE COMMAND message in the table "Rejected transactions" in the variable TRANSACTIONS; and
- 1> clear that entry;
- 1> set the IE "failure cause" to the cause value "protocol error";
- 1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION;
- 1> when the response message has been submitted to lower layers for transmission:
 - 2> continue with any ongoing processes and procedures as if the invalid SECURITY MODE COMMAND message has not been received;
 - 2> only accept a message on SRB 2, with a COUNT-I that:

3> is higher than the COUNT-I used prior to receiving the SECURITY MODE COMMAND message incremented by one; and

3> does not take into account the HFN from the received SECURITY MODE COMMAND message.

2> and the procedure ends.

8.1.13 Signalling connection release procedure




Figure 8.1.13-1: Signalling connection release procedure, normal case

8.1.13.1 General

The signalling connection release procedure is used to notify to the UE that one of its ongoing signalling connections has been released. The procedure does not initiate the release of the RRC connection.

8.1.13.2 Initiation of SIGNALLING CONNECTION RELEASE by the UTRAN

To initiate the procedure, the UTRAN transmits a SIGNALLING CONNECTION RELEASE message on DCCH using AM RLC.

8.1.13.3 Reception of SIGNALLING CONNECTION RELEASE by the UE

Upon reception of a SIGNALLING CONNECTION RELEASE message, the UE shall:

- 1> indicate the release of the signalling connection and pass the value of the IE "CN domain identity" to upper layers;
- 1> remove the signalling connection with the identity indicated by the IE "CN domain identity" from the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
- 1> clear the entry for the SIGNALLING CONNECTION RELEASE message in the table "Accepted transactions" in the variable TRANSACTIONS;
- 1> the procedure ends.

8.1.13.4 Invalid SIGNALLING CONNECTION RELEASE message

If the UE receives a SIGNALLING CONNECTION RELEASE message, which contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows:

- 1> include the IE "Identification of received message"; and
 - 2> set the IE "Received message type" to SIGNALLING CONNECTION RELEASE;
 - 2> set the IE "RRC transaction identifier" to the value of "RRC transaction identifier" in the entry for the SIGNALLING CONNECTION RELEASE message in the table "Rejected transactions" in the variable TRANSACTIONS; and
 - 2> clear that entry.

- 1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION;
- 1> transmit an RRC STATUS message on the uplink DCCH using AM RLC
- 1> when the RRC STATUS message has been submitted to lower layers for transmission:
 - 2> continue with any ongoing processes and procedures as if the invalid SIGNALLING CONNECTION RELEASE message has not been received.

8.1.13.5 Invalid configuration

If radio access bearers for the CN domain indicated by the IE "CN domain identity" exist in the variable ESTABLISHED_RABS, the UE shall:

- 1> transmit an RRC STATUS message on the uplink DCCH using AM RLC;
- 1> include the IE "Identification of received message"; and
- 1> set the IE "Received message type" to SIGNALLING CONNECTION RELEASE; and
- 1> set the IE "RRC transaction identifier" to the value of "RRC transaction identifier" in the entry for the SIGNALLING CONNECTION RELEASE message in the table "Accepted transactions" in the variable TRANSACTIONS and clear that entry;
- 1> include the IE "Protocol error information" with contents set to the value "Message not compatible with receiver state";
- 1> when the RRC STATUS message has been submitted to lower layers for transmission:
 - 2> continue with any ongoing processes and procedures as if the invalid SIGNALLING CONNECTION RELEASE message has not been received.

8.1.14 Signalling connection release indication procedure




Figure 8.1.14-1: Signalling connection release indication procedure, normal case

8.1.14.1 General

The signalling connection release indication procedure is used by the UE to indicate to the UTRAN that one of its signalling connections has been released. The procedure may in turn initiate the RRC connection release procedure.

8.1.14.2 Initiation

The UE shall, on receiving a request to release (abort) the signalling connection from upper layers for a specific CN domain:

- 1> if a signalling connection in the variable ESTABLISHED_SIGNALLING_CONNECTIONS for the specific CN domain identified with the IE "CN domain identity" exists:
 - 2> initiate the signalling connection release indication procedure.

1> otherwise:

2> abort any ongoing establishment of signalling connection for that specific CN domain as specified in 8.1.3.5a.

Upon initiation of the signalling connection release indication procedure in CELL_PCH or URA_PCH state, the UE shall:

- 1> perform a cell update procedure, according to subclause 8.3.1, using the cause "uplink data transmission";
- 1> when the cell update procedure completed successfully:
 - 2> continue with the signalling connection release indication procedure as below.

The UE shall:

- 1> set the IE "CN Domain Identity" to the value indicated by the upper layers. The value of the IE indicates the CN domain whose associated signalling connection the upper layers are indicating to be released;
- 1> remove the signalling connection with the identity indicated by upper layers from the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
- 1> transmit a SIGNALLING CONNECTION RELEASE INDICATION message on DCCH using AM RLC.

When the successful delivery of the SIGNALLING CONNECTION RELEASE INDICATION message has been confirmed by RLC the procedure ends.

8.1.14.2a RLC re-establishment or inter-RAT change

If a re-establishment of the transmitting side of the RLC entity on signalling radio bearer RB2 occurs before the successful delivery of the SIGNALLING CONNECTION RELEASE INDICATION message has been confirmed by RLC, the UE shall:

1> retransmit the SIGNALLING CONNECTION RELEASE INDICATION message on the uplink DCCH using AM RLC on signalling radio bearer RB2.

If an Inter-RAT handover from UTRAN procedure occurs before the successful delivery of the SIGNALLING CONNECTION RELEASE INDICATION message has been confirmed by RLC, the UE shall:

1> abort the signalling connection while in the new RAT.

8.1.14.3 Reception of SIGNALLING CONNECTION RELEASE INDICATION by the UTRAN

Upon reception of a SIGNALLING CONNECTION RELEASE INDICATION message, the UTRAN requests the release of the signalling connection from upper layers. Upper layers may then initiate the release of the signalling connection.

8.1.15 Counter check procedure




Figure 8.1.15-1: Counter check procedure

8.1.15.1 General

The counter check procedure is used by the UTRAN to perform a local authentication. The purpose of the procedure is to check that the amount of data sent in both directions (uplink and downlink) over the duration of the RRC connection is identical at the UTRAN and at the UE (to detect a possible intruder – a 'man-in-the-middle' – from operating).

This procedure is only applicable to radio bearers, and only to radio bearers using RLC-AM or RLC-UM. It should be noted that this requires that the COUNT-C values for each UL and DL radio bearers using RLC-AM or RLC-UM continue to be incremented even if ciphering is not used. This procedure is not applicable to signalling radio bearers.

8.1.15.2 Initiation

The UTRAN monitors the COUNT-C value associated with each radio bearer using UM or AM RLC. The procedure is triggered whenever any of these values reaches a critical checking value. The granularity of these checking values and the values themselves are defined to the UTRAN by the visited network. The UTRAN initiates the procedure by sending a COUNTER CHECK message on the downlink DCCH.

8.1.15.3 Reception of a COUNTER CHECK message by the UE

When the UE receives a COUNTER CHECK message it shall compare the COUNT-C MSB values received in the IE "RB COUNT-C MSB information" in the COUNTER CHECK message to the COUNT-C MSB values of the corresponding radio bearers.

The UE shall:

- 1> set the IE "RRC transaction identifier" in the COUNTER CHECK RESPONSE message to the value of "RRC transaction identifier" in the entry for the COUNTER CHECK message in the table "Accepted transactions" in the variable TRANSACTIONS; and
- 1> clear that entry.

If:

- there is one or more radio bearer(s) using UM or AM RLC mode stored in the variable ESTABLISHED_RABS, which is (are) not included in the IE "RB COUNT-C MSB information"; or
- there is one or more radio bearer(s) included in the IE "RB COUNT-C MSB information", which is (are) not stored in the variable ESTABLISHED RABS; or
- for any radio bearer (excluding signalling radio bearers) using UM or AM RLC mode stored in the variable ESTABLISHED_RABS and included in the IE "RB COUNT-C MSB information" with COUNT-C MSB values different from the MSB part of the COUNT-C values in the UE:

the UE shall:

1> include these radio bearers in the IE "RB COUNT-C information" in the COUNTER CHECK RESPONSE message. For any RB which is included in the IE "RB COUNT-C MSB information" in the COUNTER CHECK message but not stored in the variable ESTABLISHED_RABS in the UE, the MSB part of COUNT-C values in the COUNTER CHECK RESPONSE message shall be set identical to COUNT-C-MSB values in the COUNTER CHECK message. The LSB part shall be filled with zeroes.

The UE shall:

- 1> if no COUNT-C exists for a radio bearer for a given direction (uplink or downlink) because:
 - 2> it is a uni-directional radio bearer configured only for the other direction (downlink or uplink respectively); or
 - 2> it has been configured to RLC-TM mode in one direction (uplink or downlink) and RLC-UM in the other (downlink or uplink respectively):

3> set the COUNT-C in the IE "RB COUNT-C information" in the COUNTER CHECK RESPONSE message, to any value.

1> submit a COUNTER CHECK RESPONSE message to lower layers for transmission on the uplink DCCH using AM RLC.

When the COUNTER CHECK RESPONSE message has been submitted to lower layers for transmission the procedure ends

8.1.15.4 Reception of the COUNTER CHECK RESPONSE message by UTRAN

If the UTRAN receives a COUNTER CHECK RESPONSE message that does not contain any COUNT-C values, the procedure ends.

If the UTRAN receives a COUNTER CHECK RESPONSE message that contains one or several COUNT-C values the UTRAN may release the RRC connection.

8.1.15.5 Cell re-selection

If the UE performs cell re-selection anytime during this procedure it shall, without interrupting the procedure:

1> initiate the cell update procedure according to subclause 8.3.1.

8.1.15.6 Invalid COUNTER CHECK message

If the UE receives a COUNTER CHECK message, which contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

- 1> transmit an RRC STATUS message on the uplink DCCH using AM RLC;
- 1> include the IE "Identification of received message"; and
- 1> set the IE "Received message type" to COUNTER CHECK; and
- 1> set the IE "RRC transaction identifier" to the value of "RRC transaction identifier" in the entry for the UE COUNTER CHECK message in the table "Rejected transactions" in the variable TRANSACTIONS; and
- 1> clear that entry;
- 1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION;
- 1> when the RRC STATUS message has been submitted to lower layers for transmission:
 - 2> continue with any ongoing processes and procedures as if the invalid COUNTER CHECK message has not been received.

8.1.16 Inter RAT handover information transfer



Figure 8.1.16-1: Inter RAT handover information transfer, normal flow

8.1.16.1 General

The inter RAT handover information transfer procedure is used by the UE to convey RRC information needed for inter RAT handover to UTRAN.

8.1.16.2 Initiation

If:

- a radio access technology other than UTRA, e.g. GSM, using radio access technology-specific procedures, orders the UE to provide the INTER RAT HANDOVER INFO message; or
- a radio access technology other than UTRA, e.g. GSM, using radio access technology-specific procedures, configures the UE to send the INTER RAT HANDOVER INFO message upon system specific conditions not involving an explicit order e.g. early classmark sending upon entering connected mode; or
- while in connected mode using another radio access technology, the inter RAT handover info changes compared to what has previously been sent via the other radio access technology:

the UE shall:

1> initiate the inter RAT handover information transfer procedure.

To determine if the inter RAT handover info has changed compared to what has previously been sent, the UE shall:

- 1> store the information last sent in the variable INTER_RAT_HANDOVER_INFO_TRANSFERRED;
- 1> if this variable has not yet been set:
 - 2> not initiate the inter RAT handover information transfer procedure due to change of inter RAT handover info.

NOTE: Currently neither the UE security information nor the predefined configuration status information change while in connected mode using GSM radio access technology.

8.1.16.3 INTER RAT HANDOVER INFO message contents to set

The UE shall:

- 1> include the IE "UE security information"; and
- 1> not include the IE "UE Specific Behaviour Information 1 interRAT".
- 1> in case support for the compressed version of the inter RAT handover info is indicated via the other radio access technology:
 - 2> include of the following IEs the IE that after encoding has the smallest size: IE "Predefined configuration status information compressed" or the IE "Predefined configuration status information";
 - 2> include the IE "UE radio access capability compressed".

1> else:

- 2> include the IE "Predefined configuration status information";
- 2> include the IE "UE capability container", containing the IE "UE radio access capability" and the IE "UE radio access capability extension", in accordance with the following:
- 3> if the UE supports multiple UTRA FDD Frequency Bands; or
- 3> if the UE supports a single UTRA FDD Frequency Band different from Band I [21]:
 - 4> include the IE "UE radio access capability", excluding IEs "RF capability FDD" and "Measurement capability";

4> include the IE "UE radio access capability extension", including the IEs "RF capability FDD extension" and the "Measurement capability extension" associated with each supported UTRA FDD frequency band indicated in the IE "Frequency band".

3> else:

- 4> include the IE "UE radio access capability", including the IEs "RF capability FDD" and "Measurement capability" associated with the Band I [21];
- 4> include the IE "UE radio access capability extension", including the IEs "RF capability FDD extension" and the "Measurement capability extension" associated with each supported UTRA FDD frequency band indicated in the IE "Frequency band".
- 1> initiate the transfer of the INTER RAT HANDOVER INFO message via the other radio access technology, using radio access technology-specific procedures;
- 1> store the following in the variable INTER_RAT_HANDOVER_INFO_TRANSFERRED if they were included in the INTER RAT HANDOVER INFO message:
 - 2> the IE "Predefined configuration status information";
 - 2> the IE "Predefined configuration status information compressed";
 - 2> the IE "UE security information";
 - 2> the IE "UE radio access capability";
 - 2> the IE "UE radio access capability extension"; and
 - 2> the IE "UE radio access capability compressed".
- 1> and the procedure ends.

8.2 Radio Bearer control procedures

8.2.1 Radio bearer establishment

See subclause 8.2.2 Reconfiguration procedures.

8.2.2 Reconfiguration procedures




Figure 8.2.2-1: Radio Bearer Establishment, normal case




Figure 8.2.2-2: Radio Bearer Establishment, failure case




Figure 8.2.2-3: Radio bearer reconfiguration, normal flow




Figure 8.2.2-4: Radio bearer reconfiguration, failure case




Figure 8.2.2-5: Radio Bearer Release, normal case




Figure 8.2.2-6: Radio Bearer Release, failure case




Figure 8.2.2-7: Transport channel reconfiguration, normal flow




Figure 8.2.2-8: Transport channel reconfiguration, failure case




Figure 8.2.2-9: Physical channel reconfiguration, normal flow




Figure 8.2.2-10: Physical channel reconfiguration, failure case

8.2.2.1 General

Reconfiguration procedures include the following procedures:

- the radio bearer establishment procedure;
- radio bearer reconfiguration procedure;
- the radio bearer release procedure;
- the transport channel reconfiguration procedure; and
- the physical channel reconfiguration procedure.

The radio bearer establishment procedure is used to establish new radio bearer(s).

The radio bearer reconfiguration procedure is used to reconfigure parameters for a radio bearer.

The radio bearer release procedure is used to release radio bearer(s).

The transport channel reconfiguration procedure is used to reconfigure transport channel parameters.

The physical channel reconfiguration procedure is used to establish, reconfigure and release physical channels.

While performing any of the above procedures, these procedures may perform a hard handover (subclause 8.3.5) and/or an HS-DSCH cell change. The reconfiguration procedures are also used to change the feedback configuration for HS-DSCH.

8.2.2.2 Initiation

To initiate any one of the reconfiguration procedures, UTRAN should:

- 1> configure new radio links in any new physical channel configuration;
- 1> start transmission and reception on the new radio links;
- 1> for a radio bearer establishment procedure:
 - 2> transmit a RADIO BEARER SETUP message on the downlink DCCH using AM or UM RLC;
 - 2> if signalling radio bearer RB4 is setup with this procedure and signalling radio bearers RB1-RB3 were already established prior to the procedure:
- 3> if the variable "LATEST_CONFIGURED_CN_DOMAIN" has been initialised:
 - 4> connect any radio bearers setup by the same message as signalling radio bearer RB4 to the CN domain indicated in the variable "LATEST CONFIGURED CN DOMAIN".
 - 1> for a radio bearer reconfiguration procedure:
 - 2> transmit a RADIO BEARER RECONFIGURATION message on the downlink DCCH using AM or UM RLC.

- 1> for a radio bearer release procedure:
 - 2> transmit a RADIO BEARER RELEASE message on the downlink DCCH using AM or UM RLC.
- 1> for a transport channel reconfiguration procedure:
 - 2> transmit a TRANSPORT CHANNEL RECONFIGURATION message on the downlink DCCH using AM or UM RLC.
- 1> for a physical channel reconfiguration procedure:
 - 2> transmit a PHYSICAL CHANNEL RECONFIGURATION message on the downlink DCCH using AM or UM RLC.
- 1> if the reconfiguration procedure is simultaneous with SRNS relocation procedure:
 - 2> if the transmitted message is a RADIO BEARER RECONFIGURATION:
- 3> include the IE "New U-RNTI".
 - 2> else:
- 3> include the IE "Downlink counter synchronisation info".
 - 2> if ciphering and/or integrity protection are activated:
- 3> include new ciphering and/or integrity protection configuration information to be used after reconfiguration.
 - 2> use the downlink DCCH using AM RLC.
 - 1> if transport channels are added, reconfigured or deleted in uplink and/or downlink:
 - 2> set TFCS according to the new transport channel(s).
 - 1> if transport channels are added or deleted in uplink and/or downlink, and RB Mapping Info applicable to the new configuration has not been previously provided to the UE, the UTRAN should:
 - 2> send the RB Mapping Info for the new configuration.

In the Radio Bearer Reconfiguration procedure UTRAN may indicate that uplink transmission shall be stopped or continued on certain radio bearers. Uplink transmission on a signalling radio bearer used by the RRC signalling (signalling radio bearer RB1) or signalling radio bearer RB2) should not be stopped.

- NOTE 1: The Release '99 RADIO BEARER RECONFIGURATION message always includes the IE "RB information to reconfigure", even if UTRAN does not require the reconfiguration of any RB. In these cases, UTRAN may include only the IE "RB identity" within the IE "RB information to reconfigure".
- NOTE 2: The Release '99 RADIO BEARER RECONFIGURATION message always includes the IE "Downlink information per radio link list", even if UTRAN does not require the reconfiguration of any RL. In these cases, UTRAN may re-send the currently assigned values for the mandatory IEs included within the IE "Downlink information per radio link list".
- NOTE 3: The Release '99 RADIO BEARER RECONFIGURATION message always includes the IE "Primary CPICH Info" (FDD) or IE "Primary CCPCH Info" (TDD) within IE "Downlink information per radio link list". This implies that in case UTRAN applies the RADIO BEARER RECONFIGURATION message to move the UE to CELL_FACH state, it has to indicate a cell. However, UTRAN may indicate any cell; the UE anyhow performs cell selection and notifies UTRAN if it selects another cell than indicated by UTRAN.

If the IE "Activation Time" is included, UTRAN should set it to a value taking the UE performance requirements into account.

UTRAN should take the UE capabilities into account when setting the new configuration.

If the message is used to initiate a transition from CELL_DCH to CELL_FACH state, the UTRAN may assign a CPCH configuration to be used in that cell by the UE. UTRAN may also assign a C-RNTI to be used in that cell by the UE.

8.2.2.2a Initiation of handover from GERAN *Iu mode*

To initiate the handover from GERAN Iu mode, UTRAN should:

- 1> provide a RADIO BEARER RECONFIGURATION message to be encapsulated in INTERSYSTEM HANDOVER TO UTRAN COMMAND message, sent on the downlink SRB2 in GERAN *Iu mode*, as specified in [53].
- 1> in case UTRAN decides to use a predefined or default radio configuration that is stored in the UE, it should include the following information in the RADIO BEARER RECONFIGURATION message:
 - PhyCH information elements; and
 - either:
- the IE "Predefined configuration identity", to indicate which pre-defined configuration of RB, transport channel and physical channel parameters shall be used; or
- the IE "Default configuration mode" and IE "Default configuration identity", to indicate which default configuration of RB, transport channel and physical channel parameters shall be used.

8.2.2.3 Reception of RADIO BEARER SETUP or RADIO BEARER RECONFIGURATION or RADIO BEARER RELEASE or TRANSPORT CHANNEL RECONFIGURATION or PHYSICAL CHANNEL RECONFIGURATION message by the UE

The UE shall:

- 1> be able to receive any of the following messages:
 - 2> RADIO BEARER SETUP message; or
 - 2> RADIO BEARER RECONFIGURATION message; or
 - 2> RADIO BEARER RELEASE message; or
 - 2> TRANSPORT CHANNEL RECONFIGURATION message; or
 - 2> PHYSICAL CHANNEL RECONFIGURATION message;
- 1> be able to perform a hard handover and apply physical layer synchronisation procedure A as specified in [29], even if no prior UE measurements have been performed on the target cell and/or frequency.

In case the reconfiguration procedure is used to remove all existing RL(s) in the active set while new RL(s) are established the UE shall:

- 1> if the UE has a pending "TGPS reconfiguration CFN" at the activation time received in the reconfiguration message and the reconfiguration requests a timing re-initialised hard handover (see subclause 8.3.5.1), the UE may:
 - 2> abort the pending CM activation;
 - 2> set the CM PATTERN ACTIVATION ABORTED to TRUE.
- 1> otherwise:
 - 2> set the CM_PATTERN_ACTIVATION_ABORTED to FALSE.

If the UE receives:

- a RADIO BEARER SETUP message; or
- a RADIO BEARER RECONFIGURATION message; or
- a RADIO BEARER RELEASE message; or

- a TRANSPORT CHANNEL RECONFIGURATION message; or
- a PHYSICAL CHANNEL RECONFIGURATION message:

it shall:

- 1> set the variable ORDERED_RECONFIGURATION to TRUE;
- 1> if the UE will enter the CELL_DCH state from any state other than CELL_DCH state at the conclusion of this procedure:
 - 2> perform the physical layer synchronisation procedure A as specified in [29] (FDD only).
- 1> act upon all received information elements as specified in subclause 8.6, unless specified in the following and perform the actions below.

The UE may:

1> maintain a list of the set of cells to which the UE has Radio Links if the IE "Cell ID" is present.

The UE may first release the physical channel configuration used at reception of the reconfiguration message. The UE shall then:

- 1> in FDD, if the IE "PDSCH code mapping" is included but the IE "PDSCH with SHO DCH Info" is not included and if the DCH has only one link in its active set:
 - 2> act upon the IE "PDSCH code mapping" as specified in subclause 8.6; and
 - 2> infer that the PDSCH will be transmitted from the cell from which the downlink DPCH is transmitted.
- 1> enter a state according to subclause 8.6.3.3.

In case the UE receives a RADIO BEARER RECONFIGURATION message including the IE "RB information to reconfigure" that only includes the IE "RB identity", the UE shall:

- 1> handle the message as if IE "RB information to reconfigure" was absent.
- NOTE: The RADIO BEARER RECONFIGURATION message always includes the IE "RB information to reconfigure". UTRAN has to include it even if it does not require the reconfiguration of any RB.

If after state transition the UE enters CELL_DCH state, the UE shall, after the state transition:

- 1> in FDD; or
- 1> in TDD when "Primary CCPCH Info" is included indicating a new target cell and "New C-RNTI" is not specified:
 - 2> remove any C-RNTI from MAC;
 - 2> clear the variable C_RNTI.

If after state transition the UE leaves CELL_DCH state, the UE shall, after the state transition:

- 1> stop any HS-DSCH reception procedures;
- 1> clear any stored HS-PDSCH configuration;
- 1> act as if the IE "MAC-hs reset indicator" is received and set to TRUE;
- 1> release all HARQ resources;
- 1> remove any H-RNTI stored;
- 1> clear the variable H_RNTI;
- 1> set the variable HS_DSCH_RECEPTION to FALSE.

- NOTE: If configured for HS-DSCH, the UE will have still stored the IEs "Added or Reconfigured MAC-d flow" and "RB mapping Info".
- In FDD, if after state transition the UE leaves CELL_DCH state, the UE shall, after the state transition:
 - 1> remove any DSCH-RNTI from MAC;
 - 1> clear the variable DSCH RNTI.
- If the UE was in CELL_DCH state upon reception of the reconfiguration message and remains in CELL_DCH state, the UE shall:
 - 1> if the IE "Uplink DPCH Info" is absent, not change its current UL Physical channel configuration;
 - 1> in TDD:
 - 2> if "Primary CCPCH Info" is included indicating a new target cell and "New C-RNTI" is not specified:
- 3> remove any C-RNTI from MAC;
 - 3> clear the variable C RNTI.
 - 1> if "DPCH frame offset" is included for one or more RLs in the active set:
 - 2> use its value to determine the beginning of the DPCH frame in accordance with the following:
- 3> if the received IE "DPCH frame offset" is across the value range border compared to the DPCH frame offset currently used by the UE:
 - 4> consider it to be a request to adjust the timing with 256 chips across the frame border (e.g. if the UE receives value 0 while the value currently used is 38144 consider this as a request to adjust the timing with +256 chips).
- 3> if after taking into account value range borders, the received IE "DPCH frame offset" corresponds to a request to adjust the timing with a step exceeding 256 chips:
 - 4> set the variable INVALID_CONFIGURATION to TRUE.
- 3> and the procedure ends.
 - 2> adjust the radio link timing accordingly.
- If after state transition the UE enters CELL_FACH state, the UE shall, after the state transition:
 - 1> if the IE "Frequency info" is included in the received reconfiguration message:
 - 2> select a suitable UTRA cell according to [4] on that frequency;
 - 2> if the UE finds a suitable UTRA cell on that frequency:
- 3> if the received reconfiguration message included the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD), and the UE selects another cell than indicated by this IE or the received reconfiguration message did not include the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD):
 - 4> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";
 - 4> when the cell update procedure completed successfully:
 - 5> if the UE is in CELL_PCH or URA_PCH state, initiate a cell update procedure according to subclause 8.3.1 using the cause "Uplink data transmission" and proceed as below.
 - 2> else, if the UE can not find a suitable UTRA cell on that frequency but it finds a suitable UTRA cell on another frequency:
- 3> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";
- 3> when the cell update procedure completed successfully:

- 4> if the UE is in CELL_PCH or URA_PCH state, initiate a cell update procedure according to subclause 8.3.1 using the cause "Uplink data transmission" and proceed as below.
- 1> if the IE "Frequency info" is not included in the received reconfiguration message:
 - 2> select a suitable UTRA cell according to [4];
 - 2> if the UE finds a suitable UTRA cell on the current frequency:
- 3> if the received reconfiguration message included the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD), and the UE selects another cell than indicated by this IE or the received reconfiguration message did not include the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD):
 - 4> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";
 - 4> when the cell update procedure completed successfully:
 - 5> if the UE is in CELL_PCH or URA_PCH state, initiate a cell update procedure according to subclause 8.3.1 using the cause "Uplink data transmission" and proceed as below.
 - 2> else, if the UE can not find a suitable UTRA cell on the current frequency but it finds a suitable UTRA cell on another frequency:
- 3> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";
- 3> when the cell update procedure completed successfully:
 - 4> if the UE is in CELL_PCH or URA_PCH state, initiate a cell update procedure according to subclause 8.3.1 using the cause "Uplink data transmission" and proceed as below.
 - 1> start timer T305 using its initial value if timer T305 is not running and if periodical update has been configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity" in the variable TIMERS_AND_CONSTANTS;
 - 1> select PRACH according to subclause 8.5.17;
 - 1> select Secondary CCPCH according to subclause 8.5.19;
 - 1> use the transport format set given in system information;
 - 1> if the IE "UTRAN DRX cycle length coefficient" is included in the same message:
 - 2> ignore that IE and stop using DRX.
 - 1> if the contents of the variable C_RNTI is empty:
 - 2> perform a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";
 - 2> when the cell update procedure completed successfully:
- 3> if the UE is in CELL_PCH or URA_PCH state:
 - 4> initiate a cell update procedure according to subclause 8.3.1 using the cause "Uplink data transmission":
 - 4> proceed as below.

If the UE was in CELL_FACH state upon reception of the reconfiguration message and remains in CELL_FACH state, the UE shall:

- 1> if the IE "Frequency info" is included in the received reconfiguration message:
 - 2> select a suitable UTRA cell according to [4] on that frequency;
 - 2> if the UE finds a suitable UTRA cell on that frequency:

- 3> if the received reconfiguration message included the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD), and the UE selected another cell than indicated by this IE or the received reconfiguration message did not include the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD):
 - 4> initiate a cell update procedure according to subclause 8.3.1 using the cause "cell reselection";
 - 4> when the cell update procedure completed successfully:
 - 5> if the UE is in CELL_PCH or URA_PCH state, initiate a cell update procedure according to subclause 8.3.1 using the cause "Uplink data transmission" and proceed as below.
 - 2> else, if the UE can not find a suitable UTRA cell on that frequency but it finds a suitable UTRA cell on another frequency:
- 3> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";
- 3> when the cell update procedure completed successfully:
 - 4> if the UE is in CELL_PCH or URA_PCH state, initiate a cell update procedure according to subclause 8.3.1 using the cause "Uplink data transmission" and proceed as below.
 - 1> if the IE "Frequency info" is not included in the received reconfiguration message:
 - 2> if the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD) is included the UE shall either:
- 3> ignore the content of the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD) and proceed as below;

2> or:

- 3> if the received reconfiguration message included the IE "Primary CPICH info" (for FDD) or "Primary CPCH info" (for TDD), and it is different from the current cell:
 - 4> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";
 - 4> when the cell update procedure completed successfully:
 - 5> if the UE is in CELL_PCH or URA_PCH state, initiate a cell update procedure according to subclause 8.3.1 using the cause "Uplink data transmission" and proceed as below.

If after state transition the UE enters CELL_PCH or URA_PCH state, the UE shall:

- 1> if the IE "UTRAN DRX cycle length coefficient" is not included in the same message:
 - 2> set the variable INVALID_CONFIGURATION to TRUE.

The UE shall transmit a response message as specified in subclause 8.2.2.4, setting the information elements as specified below. The UE shall:

- 1> if the received reconfiguration message included the IE "Downlink counter synchronisation info"; or
- 1> if the received reconfiguration message is a RADIO BEARER RECONFIGURATION and the IE "New U-RNTI" is included:
 - 2> if the variable PDCP_SN_INFO is empty:
- 3> configure the corresponding RLC entity for all AM and UM radio bearers and AM and UM signalling radio bearers except RB2 to "stop".

2> else:

- 3> configure the RLC entity for signalling radio bearers RB1, RB3 and RB4 to "stop";
- 3> configure the RLC entity for UM and AM radio bearers for which the IE "PDCP SN Info" is not included to "stop".
 - 2> re-establish the RLC entity for RB2;

- 2> for the downlink and the uplink, apply the ciphering configuration as follows:
- 3> if the received re-configuation message included the IE "Ciphering Mode Info":
 - 4> use the ciphering configuration in the received message when transmitting the response message.
- 3> if the ciphering configuration for RB2 from a previously received SECURITY MODE COMMAND has not yet been applied because the activation times not having been reached:
 - 4> if the previous SECURITY MODE COMMAND was received due to new keys being received:
 - 5> consider the new ciphering configuration to include the received new keys;
 - 5> initialise the HFN component of the uplink COUNT-C and downlink COUNT-C of SRB2 as indicated in subclause 8.1.12.3.1.
 - 4> if the ciphering configuration for RB2 from a previously received SECURITY MODE COMMAND has not yet been applied because of the corresponding activation times not having been reached and the previous SECURITY MODE COMMAND caused a change in LATEST_CONFIGURED_CN_DOMAIN:
 - 5> consider the new ciphering configuration to include the keys associated with the LATEST_CONFIGURED_CN_DOMAIN;
 - 5> initialise the HFN component of the uplink COUNT-C and downlink COUNT-C of SRB2 to the most recently transmitted IE "START list" or IE "START" for the LATEST_CONFIGURED_CN_DOMAIN at the reception of the previous SECURITY MODE COMMAND.
 - 4> apply the new ciphering configuration immediately following RLC re-establishment.

3> else:

- 4> continue using the current ciphering configuration.
- 2> set the new uplink and downlink HFN component of COUNT-C of RB2 to MAX(uplink HFN component of COUNT-C of RB2);
- 2> increment by one the downlink and uplink values of the HFN of COUNT-C for RB2;
- 2> calculate the START value according to subclause 8.5.9;
- 2> include the calculated START values for each CN domain in the IE "START list" in the IE "Uplink counter synchronisation info".
- 1> if the received reconfiguration message did not include the IE "Downlink counter synchronisation info":
 - 2> if the variable START_VALUE_TO_TRANSMIT is set:
- 3> include and set the IE "START" to the value of that variable.
 - 2> if the variable START_VALUE_TO_TRANSMIT is not set and the IE "New U-RNTI" is included:
- 3> calculate the START value according to subclause 8.5.9;
- 3> include the calculated START values for each CN domain in the IE "START list" in the IE "Uplink counter synchronisation info".
 - 2> if the received reconfiguration message caused a change in the RLC size for any RB using RLC-AM:
- 3> calculate the START value according to subclause 8.5.9;
- 3> include the calculated START values for the CN domain associated with the corresponding RB identity in the IE "START list" in the IE "Uplink counter synchronisation info".
 - 1> if the received reconfiguration message contained the IE "Ciphering mode info" or contained the IE "Integrity protection mode info":

- 2> set the IE "Status" in the variable SECURITY_MODIFICATION for all the CN domains in the variable SECURITY_MODIFICATION to "Affected".
- 1> if the received reconfiguration message contained the IE "Ciphering mode info":
 - 2> if the reconfiguration message is not used to perform SRNS relocation with change of ciphering algorithm:
- 3> the UE behaviour is not specified.
 - 2> if the message is used to perform a timing re-initialised hard handover:
- 3> if IE "Ciphering activation time for DPCH" is included:
 - 4> the UE behaviour is not specified.
 - 2> else:
 - 3> if the reconfiguration message is used to setup radio bearer(s) using RLC-TM; or
 - 3> if radio bearer(s) using RLC-TM already exist:
 - 4> if IE "Ciphering activation time for DPCH" is not included:
 - 5> the UE behaviour is not specified.
 - 2> include and set the IE "Radio bearer uplink ciphering activation time info" to the value of the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO.
 - 1> if the received reconfiguration message did not contain the IE "Ciphering activation time for DPCH" in IE "Ciphering mode info":
 - 2> if prior to this procedure there exist no transparent mode RLC radio bearers:
- 3> if, at the conclusion of this procedure, the UE will be in CELL_DCH state; and
- 3> if, at the conclusion of this procedure, at least one transparent mode RLC radio bearer exists:
 - 4> include the IE "COUNT-C activation time" and specify a CFN value for this IE that is a multiple of 8 frames (CFN mod 8 = 0) and lies at least 200 frames ahead of the CFN in which the response message is first transmitted.
 - NOTE: UTRAN should not include the IE "Ciphering mode info" in any reconfiguration message unless it is also used to perform an SRNS relocation with change of ciphering algorithm.
 - 1> set the IE "RRC transaction identifier" to the value of "RRC transaction identifier" in the entry for the received message in the table "Accepted transactions" in the variable TRANSACTIONS; and
 - 1> clear that entry;
 - 1> if the variable PDCP_SN_INFO is not empty:
 - 2> include the IE "RB with PDCP information list" and set it to the value of the variable PDCP_SN_INFO.
 - 1> in TDD, if the procedure is used to perform a handover to a cell where timing advance is enabled, and the UE can calculate the timing advance value in the new cell (i.e. in a synchronous TDD network):
 - 2> set the IE "Uplink Timing Advance" according to subclause 8.6.6.26.
 - 1> if the IE "Integrity protection mode info" was present in the received reconfiguration message:
 - 2> start applying the new integrity protection configuration in the uplink for signalling radio bearer RB2 from and including the transmitted response message.

If after state transition the UE enters URA_PCH state, the UE shall, after the state transition and transmission of the response message:

- 1> if the IE "Frequency info" is included in the received reconfiguration message:
 - 2> select a suitable UTRA cell according to [4] on that frequency.
 - 2> if the UE can not find a suitable UTRA cell on that frequency but it finds a suitable UTRA cell on another frequency:
- 3> proceed as below.
 - 1> if the IE "Frequency info" is not included in the received reconfiguration message:
 - 2> select a suitable UTRA cell according to [4].
 - 1> prohibit periodical status transmission in RLC;
 - 1> remove any C-RNTI from MAC;
 - 1> clear the variable C RNTI;
 - 1> start timer T305 using its initial value if timer T305 is not running and if periodical update has been configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity" in the variable TIMERS_AND_CONSTANTS;
 - 1> select Secondary CCPCH according to subclause 8.5.19;
 - 1> if the IE "UTRAN DRX cycle length coefficient" is included in the same message:
 - 2> use the value in the IE "UTRAN DRX Cycle length coefficient" for calculating Paging occasion and PICH Monitoring Occasion as specified in subclause 8.6.3.2.
 - 1> if the criteria for URA update caused by "URA reselection" according to subclause 8.3.1 are fulfilled after cell selection:
 - 2> initiate a URA update procedure according to subclause 8.3.1 using the cause "URA reselection";
 - 2> when the URA update procedure is successfully completed:
- 3> the procedure ends.

If after state transition the UE enters CELL_PCH state from CELL_DCH state, the UE shall, after the state transition and transmission of the response message:

- 1> if the IE "Frequency info" is included in the received reconfiguration message:
 - 2> select a suitable UTRA cell according to [4] on that frequency.
 - 2> if the UE finds a suitable UTRA cell on that frequency:
- 3> if the received reconfiguration message included the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD), and the UE selects another cell than indicated by this IE or the received reconfiguration message did not include the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD):
 - 4> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";
 - 4> proceed as below.
 - 2> else, if the UE can not find a suitable UTRA cell on that frequency but it finds a suitable UTRA cell on another frequency:
- 3> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";
- 3> proceed as below.
 - 1> if the IE "Frequency info" is not included in the received reconfiguration message:

- 2> select a suitable UTRA cell according to [4].
- 2> if the UE finds a suitable UTRA cell on the current frequency:
- 3> if the received reconfiguration message included the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD), and the UE selects another cell than indicated by this IE or the received reconfiguration message did not include the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD):
 - 4> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";
 - 4> proceed as below.
 - 2> else, if the UE can not find a suitable UTRA cell on the current frequency but it finds a suitable UTRA cell on another frequency:
- 3> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";
- 3> proceed as below.
 - 1> prohibit periodical status transmission in RLC;
 - 1> remove any C-RNTI from MAC;
 - 1> clear the variable C_RNTI;
 - 1> start timer T305 using its initial value if timer T305 is not running and if periodical update has been configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity" in the variable TIMERS_AND_CONSTANTS;
 - 1> select Secondary CCPCH according to subclause 8.5.19;
 - 1> if the IE "UTRAN DRX cycle length coefficient" is included in the same message:
 - 2> use the value in the IE "UTRAN DRX Cycle length coefficient" for calculating Paging occasion and PICH Monitoring Occasion as specified in subclause 8.6.3.2.
 - 1> the procedure ends.

If after state transition the UE enters CELL_PCH state from CELL_FACH state, the UE shall, after the state transition and transmission of the response message:

- 1> if the IE "Frequency info" is included in the received reconfiguration message:
 - 2> select a suitable UTRA cell according to [4] on that frequency.
 - 2> if the UE finds a suitable UTRA cell on that frequency:
- 3> if the received reconfiguration message included the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD), and the UE selected another cell than indicated by this IE or the received reconfiguration message did not include the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD):
 - 4> initiate a cell update procedure according to subclause 8.3.1 using the cause "cell reselection";
 - 4> proceed as below.
 - 2> else, if the UE can not find a suitable UTRA cell on that frequency but it finds a suitable UTRA cell on another frequency:
- 3> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";
- 3> proceed as below.
 - 1> if the IE "Frequency info" is not included in the received reconfiguration message:
 - 2> if the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD) is included the UE shall either:

3> ignore the content of the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD) and proceed as below:

2> or:

- 3> if the received reconfiguration message included the IE "Primary CPICH info" (for FDD) or "Primary CPCH info" (for TDD), and it is different from the current cell:
 - 4> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";
 - 4> proceed as below.
 - 1> prohibit periodical status transmission in RLC;
 - 1> remove any C-RNTI from MAC;
 - 1> clear the variable C_RNTI;
 - 1> start timer T305 using its initial value if timer T305 is not running and if periodical update has been configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity" in the variable TIMERS_AND_CONSTANTS;
 - 1> select Secondary CCPCH according to subclause 8.5.19;
 - 1> if the IE "UTRAN DRX cycle length coefficient" is included in the same message:
 - 2> use the value in the IE "UTRAN DRX Cycle length coefficient" for calculating Paging occasion and PICH Monitoring Occasion as specified in subclause 8.6.3.2.
 - 1> the procedure ends.

8.2.2.3a Reception of RADIO BEARER RECONFIGURATION message by the UE performing handover from GERAN *lu mode*

If the UE is performing handover from GERAN Iu mode, the UE shall, in addition to the actions in 8.2.2.3:

- 1> if the IE "Specification mode" is set to "Preconfiguration" and the IE "Preconfiguration mode" is set to "Predefined configuration":
 - 2> initiate the radio bearer and transport channel configuration in accordance with the predefined parameters identified by the IE "Predefined configuration identity";
 - 2> initiate the physical channels in accordance with the predefined parameters identified by the IE "Predefined radio configuration identity" and the received physical channel information elements;
 - 2> store information about the established radio access bearers and radio bearers according to the IE "Predefined configuration identity"; and
- 1> if the IE "Specification mode" is set to "Preconfiguration" and the IE "Preconfiguration mode" is set to "Default configuration":
 - 2> initiate the radio bearer and transport channel configuration in accordance with the default parameters identified by the IE "Default configuration mode" and the IE "Default configuration identity";
 - 2> initiate the physical channels in accordance with the default parameters identified by the IE "Default configuration mode" and IE "Default configuration identity" and the received physical channel information elements;
- NOTE: The IE "Default configuration mode" specifies whether the FDD or TDD version of the default configuration shall be used.
- 1> if IE "Specification mode" is set to "Complete specification":
 - 2> initiate the radio bearer, transport channel and physical channel configuration in accordance with the received radio bearer, transport channel and physical channel information elements.

- 1> perform an open loop estimation to determine the UL transmission power according to subclause 8.5.3;
- 1> set the following variables equal to the corresponding variables in GERAN *Iu mode*:

CIPHERING STATUS

ESTABLISHED_RABS

ESTABLISHED_SIGNALLING_CONNECTIONS

INTEGRITY_PROTECTION_INFO

INTER_RAT_HANDOVER_INFO_TRANSFERRED

LATEST_CONFIGURED_CN_DOMAIN

START_THRESHOLD

UE_CAPABILITY_TRANSFERRED.

1> set the new uplink and downlink HFN of RB2 to MSB₂₀(MAX(uplink HFN of RB2, downlink HFN of RB2));

NOTE: MSB₂₀() operation provides the HFN mapping from GERAN *Iu mode* to UTRAN. In GERAN *Iu mode* the length of HFN component of the COUNT-C of RB2 is longer than 20 bits.

1> initialise the variable TIMERS_AND_CONSTANTS to the default values and start to use those timer and constants values.

8.2.2.4 Transmission of a response message by the UE, normal case

In case the procedure was triggered by reception of a RADIO BEARER SETUP message, the UE shall:

1> transmit a RADIO BEARER SETUP COMPLETE as response message on the uplink DCCH using AM RLC.

In case the procedure was triggered by reception of a RADIO BEARER RECONFIGURATION message, the UE shall:

1> transmit a RADIO BEARER RECONFIGURATION COMPLETE as response message on the uplink DCCH using AM RLC.

In case the procedure was triggered by reception of a RADIO BEARER RELEASE message, the UE shall:

1> transmit a RADIO BEARER RELEASE COMPLETE as response message on the uplink DCCH using AM RLC.

In case the procedure was triggered by reception of a TRANSPORT CHANNEL RECONFIGURATION message, the UE shall:

1> transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE as response message on the uplink DCCH using AM RLC.

In case the procedure was triggered by reception of a PHYSICAL CHANNEL RECONFIGURATION message, the UE shall:

1> transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE as response message on the uplink DCCH using AM RLC.

If the new state is CELL_DCH or CELL_FACH, the response message shall be transmitted using the new configuration after the state transition, and the UE shall:

- 1> if the IE "Downlink counter synchronisation info" was included in the reconfiguration message; or
- 1> if the received reconfiguration message is a RADIO BEARER RECONFIGURATION and the IE "New U-RNTI" is included:
 - 2> when RLC has confirmed the successful transmission of the response message:
- 3> if the variable PDCP_SN_INFO is empty:

4> configure the RLC entity for all AM and UM radio bearers and AM and UM signalling radio bearers except RB2 to "continue".

3> else:

- 4> configure the RLC entity for signalling radio bearers RB1, RB3 and RB4 to "continue";
- 4> configure the RLC entity for UM and AM radio bearers for which the IE "PDCP SN Info" is not included to "continue".
- 3> re-establish all AM and UM RLC entities with RB identities larger than 4 and set the first 20 bits of all the HFN component of the respective COUNT-C values to the START value included in the response message for the corresponding CN domain;
- 3> re-establish the RLC entities with RB identities 1, 3 and 4 and set the first 20 bits of all the HFN component of the respective COUNT-C values to the START value included in the response message for the CN domain stored in the variable LATEST CONFIGURED CN DOMAIN;
- 3> set the remaining bits of the HFN component of COUNT-C values of all UM RLC entities to zero;
- 3> if the IE "PDCP context relocation info" is not present:
 - 4> re-initialise the PDCP header compression entities of each radio bearer in the variable ESTABLISHED_RABS as specified in [36].
- 3> if the IE "PDCP context relocation info" is present:
 - 4> perform the actions as specified in subclause 8.6.4.13.
 - 1> if the variable PDCP_SN_INFO is empty:
 - 2> if the received reconfiguration message contained the IE "Ciphering mode info":
- 3> when RLC has confirmed the successful transmission of the response message:
 - 4> notify upper layers upon change of the security configuration;
 - 4> perform the actions below.
 - 2> if the received reconfiguration message did not contain the IE "Ciphering mode info":
- 3> when RLC has been requested to transmit the response message:
 - 4> perform the actions below.
 - 1> if the variable PDCP_SN_INFO is non-empty:
 - 2> when RLC has confirmed the successful transmission of the response message:
- 3> for each radio bearer in the variable PDCP_SN_INFO:
 - 4> if the IE "RB started" in the variable ESTABLISHED_RABS is set to "started":
 - 5> configure the RLC entity for that radio bearer to "continue".
- 3> perform the actions below.

If the new state is CELL_PCH or URA_PCH, the response message shall be transmitted using the old configuration before the state transition, but the new C-RNTI shall be used if the IE "New C-RNTI" was included in the received reconfiguration message, and the UE shall:

- 1> when RLC has confirmed the successful transmission of the response message:
 - 2> for each radio bearer in the variable PDCP_SN_INFO:
- 3> if the IE "RB started" in the variable ESTABLISHED RABS is set to "started":
 - 4> configure the RLC entity for that radio bearer to "continue".

- 2> enter the new state (CELL_PCH or URA_PCH, respectively);
- 2> perform the actions below.

The UE shall:

- 1> set the variable ORDERED_RECONFIGURATION to FALSE;
- 1> if the received reconfiguration message contained the IE "Ciphering mode info":
 - 2> resume data transmission on any suspended radio bearer and signalling radio bearer mapped on RLC-AM or RLC-UM;
 - 2> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE; and
 - 2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO.
- 1> if the received reconfiguration message contained the IE "Integrity protection mode info":
 - 2> allow the transmission of RRC messages on all signalling radio bearers with any RRC SN;
 - 2> set "Uplink RRC Message sequence number" for signalling radio bearer RB0 in the variable INTEGRITY_PROTECTION_INFO to a value such that next RRC message to be sent on uplink RB0 will use the new integrity protection configuration;
 - 2> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to FALSE; and
 - 2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.
- 1> clear the variable PDCP_SN_INFO;
- 1> clear the variable START_VALUE_TO_TRANSMIT;
- 1> clear the variable SECURITY MODIFICATION.

8.2.2.5 Reception of a response message by the UTRAN, normal case

When UTRAN has received

- the RADIO BEARER SETUP COMPLETE message; or
- the RADIO BEARER RECONFIGURATION COMPLETE message; or
- the RADIO BEARER RELEASE COMPLETE message; or
- the TRANSPORT CHANNEL RECONFIGURATION COMPLETE message; or
- the PHYSICAL CHANNEL RECONFIGURATION COMPLETE message.

UTRAN may:

1> delete the old configuration.

If the procedure caused the UE to leave the CELL FACH state, UTRAN may:

1> delete the C-RNTI of the UE.

If the IE "UL Timing Advance" is included in TDD, UTRAN should:

1> evaluate the timing advance value that the UE has to use in the new cell after handover.

If the IE "START" or the IE "START list" is included, UTRAN should:

- 1> set the START value for each CN domain with the corresponding values as received in this response message;
- 1> consequently, then use the START values to initialise the hyper frame numbers, in the same way as specified for the UE in subclause 8.2.2.3, for any new radio bearers that are established.

If UTRAN has ordered a ciphering reconfiguration by including the IE "Ciphering mode info", UTRAN should:

- 1> for radio bearers using RLC-AM or RLC-UM:
 - 2> use the old ciphering configuration for received RLC PDUs with RLC sequence number less than the RLC sequence number indicated in the IE "Radio bearer uplink ciphering activation time info" sent by the UE;
 - 2> use the new ciphering configuration for received RLC PDUs with RLC sequence number greater than or equal to the RLC sequence number indicated in the IE "Radio bearer uplink ciphering activation time info" sent by the UE;
 - 2> if an RLC reset or re-establishment of the receiving side of an RLC entity occurs after this response message has been received by UTRAN before the uplink activation time for the new ciphering configuration has been reached, ignore the activation time and apply the new ciphering configuration in uplink immediately after the RLC reset or RLC re-establishment:
 - 2> if an RLC reset or re-establishment of the transmitting side of an RLC entity occurs after this response message has been received by UTRAN before the downlink activation time for the new ciphering configuration has been reached, ignore the activation time and apply the new ciphering configuration in downlink immediately after the RLC reset or RLC re-establishment.
- 1> for radio bearers using RLC-TM:
 - 2> begin incrementing the COUNT-C at the CFN only as indicated in:
- 3> the IE "Ciphering activation time for DPCH" in the IE "Ciphering mode info", if included in the message that triggered the radio bearer control procedure; or
- 3> the IE "COUNT-C activation time", if included in the response message for this procedure.
 - 1> and the procedure ends on the UTRAN side.

8.2.2.6 Unsupported configuration in the UE

If the UTRAN instructs the UE to use a configuration, which it does not support and/or if the received message causes the variable UNSUPPORTED_CONFIGURATION to be set to TRUE, the UE shall:

- 1> transmit a failure response as specified in subclause 8.2.2.9, setting the information elements as specified below:
 - 2> include the IE "RRC transaction identifier"; and
 - 2> set it to the value of "RRC transaction identifier" in the entry for the received message in the table "Accepted transactions" in the variable TRANSACTIONS; and
 - 2> clear that entry;
 - 2> set the IE "failure cause" to "configuration unsupported".
- 1> set the variable UNSUPPORTED_CONFIGURATION to FALSE;
- 1> continue with any ongoing processes and procedures as if the reconfiguration message was not received.

The procedure ends.

8.2.2.7 Physical channel failure

If the received message caused the UE to be in CELL_DCH state and the UE according to subclause 8.5.4 failed to establish the dedicated physical channel(s) indicated in the received message the UE shall:

- 1> if HS-DSCH is configured:
 - 2> stop any HS-DSCH reception procedures;
 - 2> clear any stored HS-PDSCH configuration;
 - 2> act as if the IE 'MAC-hs reset indicator' is received and set to TRUE;

- 2> release all HARQ resources;
- 2> remove any H-RNTI stored;
- 2> clear the variable H RNTI;
- 2> set the variable HS_DSCH_RECEPTION to FALSE.
- 1> if the CM_PATTERN_ACTIVATION_ABORTED flag is not set to TRUE:
 - 2> revert to the configuration prior to the reception of the message (old configuration);
 - 2> if the UE was in Cell DCH state prior to the reconfiguration:
- 3> perform the physical layer synchronisation procedure A as specified in [29] (FDD only);
- 3> after the establishment of the uplink physical channel, send DPCCH and no DPDCH according to [26] during the number of frames indicated in the IE "PC preamble" in the variable LATEST_CONFIGURED_SRB_DELAY_AND_PC_PREAMBLE; and
- 3> then not send any data on signalling radio bearers RB0 to RB4 during the number of frames indicated in the IE "SRB delay" in the variable LATEST_CONFIGURED_SRB_DELAY_AND_PC_PREAMBLE.
 - 1> if the CM_PATTERN_ACTIVATION_ABORTED flag is set to TRUE or if the old configuration includes dedicated physical channels (CELL_DCH state) and the UE is unable to revert to the old configuration:
 - 2> initiate a cell update procedure according to subclause 8.3.1, using the cause "radio link failure";
 - 2> after the cell update procedure has completed successfully:
- 3> proceed as below.
 - 1> if the old configuration does not include dedicated physical channels (CELL_FACH state):
 - 2> select a suitable UTRA cell according to [4];
 - 2> if the UE selects another cell than the cell the UE camped on upon reception of the reconfiguration message:
- 3> initiate a cell update procedure according to subclause 8.3.1, using the cause "Cell reselection";
- 3> after the cell update procedure has completed successfully:
 - 4> proceed as below.
 - 1> transmit a failure response message as specified in subclause 8.2.2.9, setting the information elements as specified below:
 - 2> include the IE "RRC transaction identifier"; and
 - 2> set it to the value of "RRC transaction identifier" in the entry for the received message in the table "Accepted transactions" in the variable TRANSACTIONS; and
 - 2> clear that entry;
 - 2> set the IE "failure cause" to "physical channel failure".
 - 1> set the variable ORDERED_RECONFIGURATION to FALSE;
 - 1> continue with any ongoing processes and procedures as if the reconfiguration message was not received.

The procedure ends.

8.2.2.8 Cell re-selection

If the UE performs cell re-selection during the reconfiguration procedure, the UE shall:

1> initiate a cell update procedure, as specified in subclause 8.3.1;

1> continue with the reconfiguration procedure.

8.2.2.9 Transmission of a response message by the UE, failure case

The UE shall:

- 1> in case of reception of a RADIO BEARER SETUP message:
 - 2> if the radio bearer establishment procedure affects several radio bearers:
- 3> (may) include the identities of the radio bearers for which the procedure would have been successful into the RADIO BEARER SETUP FAILURE message.
 - 2> transmit a RADIO BEARER SETUP FAILURE as response message on the DCCH using AM RLC.
 - 1> in case of reception of a RADIO BEARER RECONFIGURATION message:
 - 2> if the radio bearer reconfiguration procedure affects several radio bearers:
- 3> (may) include the identities of the radio bearers for which the procedure would have been successful into the RADIO BEARER RECONFIGURATION FAILURE message.
 - 2> transmit a RADIO BEARER RECONFIGURATION FAILURE as response message on the DCCH using AM RLC.
 - 1> in case of reception of a RADIO BEARER RECONFIGURATION message encapsulated in INTERSYSTEM HANDOVER TO UTRAN COMMAND message in GERAN *Iu mode*:
 - 2> perform the actions as specified in [53].
 - 1> in case of reception of a RADIO BEARER RELEASE message:
 - 2> if the radio bearer release procedure affects several radio bearers:
- 3> (may) include the identities of the radio bearers for which the procedure would have been successful into the RADIO BEARER RELEASE FAILURE message.
 - 2> transmit a RADIO BEARER RELEASE FAILURE as response message on the DCCH using AM RLC.
 - 1> in case of reception of a TRANSPORT CHANNEL RECONFIGURATION message:
 - 2> transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE as response message on the DCCH using AM RLC.
 - 1> in case of reception of a PHYSICAL CHANNEL RECONFIGURATION message:
 - 2> transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE as response message on the DCCH using AM RLC.
 - 1> when the response message has been submitted to lower layers for transmission:
 - 2> continue with any ongoing processes and procedures as if no reconfiguration attempt had occurred.

8.2.2.10 Reception of a response message by the UTRAN, failure case

When the UTRAN has received:

- the RADIO BEARER SETUP FAILURE message; or
- the RADIO BEARER RECONFIGURATION FAILURE message; or
- the RADIO BEARER RELEASE FAILURE message; or
- the TRANSPORT CHANNEL RECONFIGURATION FAILURE message; or
- the PHYSICAL CHANNEL RECONFIGURATION FAILURE message:

the UTRAN may restore the old and delete the new configuration. Upper layers should be notified of the failure.

The procedure ends on the UTRAN side.

8.2.2.11 Invalid configuration

If the variable INVALID_CONFIGURATION is set to TRUE the UE shall:

- 1> keep the configuration existing before the reception of the message;
- 1> transmit a failure response message as specified in subclause 8.2.2.9, setting the information elements as specified below:
 - 2> include the IE "RRC transaction identifier"; and

3> set it to the value of "RRC transaction identifier" in the entry for the received message in the table "Accepted transactions" in the variable TRANSACTIONS; and

- 3> clear that entry.
 - 2> set the IE "failure cause" to "invalid configuration".
 - 1> set the variable INVALID_CONFIGURATION to FALSE;
 - 1> continue with any ongoing processes and procedures as if the reconfiguration message was not received.

The procedure ends.

8.2.2.12 Incompatible simultaneous reconfiguration

If the table "Rejected transactions" in the variable TRANSACTIONS is set due to the received message and the variable PROTOCOL_ERROR_REJECT is set to FALSE, the UE shall:

- 1> not apply the configuration contained in the received reconfiguration message;
- 1> transmit a failure response message as specified in subclause 8.2.2.9, setting the information elements as specified below:
 - 2> include the IE "RRC transaction identifier"; and
 - 2> set it to the value of "RRC transaction identifier" in the entry for the received message in the table "Rejected transactions" in the variable TRANSACTIONS; and
 - 2> clear that entry;
 - 2> set the IE "failure cause" to "incompatible simultaneous reconfiguration".
- 1> continue with any ongoing processes and procedures as if the reconfiguration message was not received.

The procedure ends.

8.2.2.12a Incompatible simultaneous security reconfiguration

If the variable INCOMPATIBLE_SECURITY_RECONFIGURATION is set to TRUE due to the received reconfiguration message, the UE shall:

- 1> transmit a failure response message as specified in subclause 8.2.2.9, setting the information elements as specified below:
 - 2> include the IE "RRC transaction identifier"; and
 - 2> set it to the value of "RRC transaction identifier" in the entry for the received message in the table "Accepted transactions" in the variable TRANSACTIONS; and
 - 2> clear that entry;

- 2> set the IE "failure cause" to the cause value "incompatible simultaneous reconfiguration".
- 1> set the variable INCOMPATIBLE_SECURITY_RECONFIGURATION to FALSE;
- 1> continue with any ongoing processes and procedures as if the reconfiguration message was not received.

The procedure ends.

8.2.2.12b Cell update procedure during security reconfiguration

If:

- a cell update procedure according to subclause 8.3.1 is initiated; and
- the received reconfiguration message causes either:
 - the IE "Reconfiguration" in the variable CIPHERING_STATUS to be set to TRUE; and/or
 - the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to be set to TRUE:

the UE shall:

- 1> release all radio resources;
- 1> indicate the release of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers; and
- 1> clear any entry for the RRC CONNECTION RELEASE message in the tables "Accepted transactions" and "Rejected transactions" in the variable TRANSACTIONS;
- 1> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
- 1> clear the variable ESTABLISHED_RABS;
- 1> if the received reconfiguration message contained the IE "Ciphering mode info":
 - $2\!\!>\!\!$ set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE; and
 - 2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;
 - 2> clear the variable SECURITY_MODIFICATION.
- 1> if the received reconfiguration message contained the IE "Integrity protection mode info":
 - 2> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to FALSE; and
 - 2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.
- 1> enter idle mode;
- 1> perform the actions specified in subclause 8.5.2 when entering idle mode;
- 1> and the procedure ends.

NOTE: UTRAN should use RB Control messages to perform an SRNS relocation only in case of state transitions from CELL_DCH to CELL_DCH.

8.2.2.13 Invalid received message

If the received reconfiguration message contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

1> transmit a failure response message as specified in subclause 8.2.2.9, setting the information elements as specified below:

- 2> include the IE "RRC transaction identifier"; and
- 2> set it to the value of "RRC transaction identifier" in the entry for the received message in the table "Rejected transactions" in the variable TRANSACTIONS; and
- 2> clear that entry;
- 2> set the IE "failure cause" to the cause value "protocol error";
- 2> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION.

The procedure ends.

8.2.2.14 Radio link failure

If the criteria for radio link failure are met in the old configuration during the reconfiguration procedure as specified in subclause 8.5.6, the UE shall:

- 1> if UE would have entered CELL_PCH or URA_PCH as a result of this reconfiguration procedure and UE has already submitted a response message to lower layers:
 - 2> act as if the reconfiguration message was not received;
 - 2> initiate a cell update procedure according to subclause 8.3.1, using the cause "radio link failure";
 - 2> the procedure ends.
- NOTE: UTRAN should consider the reconfiguration procedure as unsuccessful in this case even if a success response message had been received.
- 1> if the UE would have remained in CELL_DCH state as a result of this reconfiguration procedure:
 - 2> initiate a cell update procedure according to subclause 8.3.1, using the cause "radio link failure";
 - 2> after the cell update procedure has completed successfully:
- 3> transmit a failure response message as specified in subclause 8.2.2.9, setting the information elements as specified below:
 - 4> include the IE "RRC transaction identifier"; and
 - 4> set it to the value of "RRC transaction identifier" in the entry for the received message in the table "Accepted transactions" in the variable TRANSACTIONS; and
 - 4> clear that entry;
 - 4> set the IE "failure cause" to "physical channel failure".
- 3> act as if the reconfiguration message was not received;
- 3> the procedure ends.

If the criteria for radio link failure are met in the new configuration during the reconfiguration procedure (i.e. while UE is waiting for RLC acknowledgement for a response message.) as specified in subclause 8.5.6, the UE shall:

- 1> if the received reconfiguration causes either:
 - the IE "Reconfiguration" in the variable CIPHERING_STATUS to be set to TRUE; and/or
 - the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to be set to TRUE:
 - 2> perform the actions specified in subclause 8.2.2.12b.
- 1> else, the UE should:
 - 2> release all its radio resources;

- 2> indicate the release of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;
- 2> clear any entry for the RRC CONNECTION RELEASE message in the tables "Accepted transactions" and "Rejected transactions" in the variable TRANSACTIONS;
- 2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
- 2> clear the variable ESTABLISHED_RABS;
- 2> enter idle mode;
- 2> perform the actions specified in subclause 8.5.2 when entering idle mode; and
- 2> the procedure ends.

8.2.3 Radio bearer release

See subclause 8.2.2 (Reconfiguration procedures).

8.2.4 Transport channel reconfiguration

See subclause 8.2.2 (Reconfiguration procedures).

8.2.5 Transport format combination control




Figure 8.2.5-1: Transport format combination control, normal flow




Figure 8.2.5-2: Transport format combination control, failure case

8.2.5.1 General

The transport format combination control procedure is used to control the allowed uplink transport format combinations within the transport format combination set.

8.2.5.2 Initiation

To initiate the transport format combination control procedure, the UTRAN transmits the TRANSPORT FORMAT COMBINATION CONTROL message on the downlink DCCH using AM, UM or TM RLC. When not stated otherwise elsewhere, the UTRAN may initiate the transport format combination control procedure also when another procedure is ongoing, and in that case the state of the latter procedure shall not be affected.

To change the sub-set of allowed transport format combinations, the UTRAN should:

1> set the allowed TFCs in the IE "TFC subset". The UTRAN may specify the duration for which a new TFC subset applies by using the IE "TFC Control duration" and independently may specify the time at which a new TFC sub-set shall be applied using the IE "Activation Time".

To remove completely the previous restrictions of allowed transport format combinations, the UTRAN should:

1> set the "full transport format combination" in the IE "TFC subset".

8.2.5.3 Reception of a TRANSPORT FORMAT COMBINATION CONTROL message by the UE

If the TRANSPORT FORMAT COMBINATION CONTROL message was received on AM RLC or UM RLC, the UE shall:

- 1> act upon all received information elements as specified in 8.6, unless specified otherwise in the following;
- 1> perform the actions for the transport format combination subset specified in the IE "DPCH/PUSCH TFCS in uplink" according to subclause 8.6.5.3;
- 1> if the variable INVALID_CONFIGURATION is set to FALSE:
 - 2> if the IE "TFC Control duration" is included in the message:
- 3> store the value of the IE "TFC Control duration" in the IE "Duration" in the variable TFC_SUBSET;
- 3> set the IE "Current TFC subset" (for the CCTrCH indicated by the IE "TFCS Id" in case of TDD) in the variable TFC_SUBSET to the value of the IE "Transport format combination subset";
- 3> apply the transport format combination subset in the IE "Current TFC subset" stored in the variable TFC_SUBSET for the number of (10 ms) frames specified in the IE "TFC Control duration";
- 3> at the end of the time period defined by the IE "TFC control duration":
 - 4> if the variable TFC_SUBSET has not subsequently been changed by another message:
 - 5> go back to any previous restriction of the transport format combination set defined by the content of the IE "Default TFC subset" in the variable TFC_SUBSET;
 - 5> set the value of the IE "Current TFC subset" in the variable TFC_SUBSET to the value of the IE "Default TFC subset" in the variable TFC_SUBSET;
 - 5> clear the IE "Duration" in the variable TFC_SUBSET.
 - 2> if the IE "TFC Control duration" is not included in the message:
- 3> set both the IE "Current TFC subset" and the IE "Default TFC subset" (for the CCTrCH indicated by the IE "TFCS Id" in case of TDD) in the variable TFC_SUBSET to the value of the IE "Transport format combination subset".
 - 1> if the UE is unable to comply with the reconfiguration due to an invalid activation time:
 - 2> set the variable INVALID_CONFIGURATION to TRUE.

If the TRANSPORT FORMAT COMBINATION CONTROL message was received on TM RLC, the UE shall:

1> consider the size of the transport block of the downlink transport channel where this message was received to select the format for the transparent format combination control mode as specified in subclause 12.4.1.1;

- 1> if the IE "TFC subset identity" identifies one of the TFC subsets stored in the IE "TFC subset list" in the variable TFC SUBSET:
 - 2> perform the actions as specified in subclause 8.6.5.3;
 - 2> if the variable INVALID CONFIGURATION is set to FALSE:
- 3> in the variable TFC_SUBSET, set the IE "Current TFC subset" to the value of the IE "TFC subset" in "TFC subset list" which is identified by the IE "TFC subset identity".
 - 1> if the IE "TFC subset identity" is greater than the maximum number of TFC subsets stored in the IE "TFC subset list" in the variable TFC_SUBSET:
 - 2> set the variable INVALID_CONFIGURATION to TRUE.

The UE shall:

- 1> clear the entry for the TRANSPORT FORMAT COMBINATION CONTROL message in the table "Accepted transactions" in the variable TRANSACTIONS;
- 1> and the procedure ends.

8.2.5.4 Invalid configuration

If the variable INVALID_CONFIGURATION is set to TRUE due to the received TRANSPORT FORMAT COMBINATION CONTROL message the UE shall:

- 1> if the TRANSPORT FORMAT COMBINATION CONTROL message was received on AM RLC:
 - 2> keep the TFC subset existing before the TRANSPORT FORMAT COMBINATION CONTROL message was received;
 - 2> transmit a TRANSPORT FORMAT COMBINATION CONTROL FAILURE message on the DCCH using AM RLC;
 - 2> set the IE "RRC transaction identifier" in the TRANSPORT FORMAT COMBINATION CONTROL FAILURE message to the value of "RRC transaction identifier" in the entry for the TRANSPORT FORMAT COMBINATION CONTROL message in the table "Accepted transactions" in the variable TRANSACTIONS; and
 - 2> clear that entry;
 - 2> set the IE "failure cause" to "invalid configuration";
 - 2> when the TRANSPORT FORMAT COMBINATION CONTROL FAILURE message has been submitted to lower layers for transmission the procedure ends.
- 1> if the TRANSPORT FORMAT COMBINATION CONTROL message was received on UM RLC or TM RLC:
 - 2> ignore the TRANSPORT FORMAT COMBINATION CONTROL message;
 - 2> clear the entry for the TRANSPORT FORMAT COMBINATION CONTROL message in the table "Accepted transactions" in the variable TRANSACTIONS.

8.2.5.5 Invalid TRANSPORT FORMAT COMBINATION CONTROL message

If the TRANSPORT FORMAT COMBINATION CONTROL message was received on AM RLC or UM RLC and contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

- 1> transmit a TRANSPORT FORMAT COMBINATION CONTROL FAILURE message on the uplink DCCH using AM RLC setting the information elements as specified below:
 - 2> set the IE "RRC transaction identifier" in the TRANSPORT FORMAT COMBINATION CONTROL FAILURE message to the value of "RRC transaction identifier" in the entry for the TRANSPORT FORMAT

COMBINATION CONTROL message in the table "Rejected transactions" in the variable TRANSACTIONS; and

- 2> clear that entry;
- 2> set the IE "failure cause" to the cause value "protocol error";
- 2> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION.
- 1> when the TRANSPORT FORMAT COMBINATION CONTROL FAILURE message has been submitted to lower layers for transmission:
 - 2> continue with any ongoing processes and procedures as if the invalid TRANSPORT FORMAT COMBINATION CONTROL message has not been received;
 - 2> and the procedure ends.

If the TRANSPORT FORMAT COMBINATION CONTROL message was received on TM RLC and contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

- 1> ignore the invalid TRANSPORT FORMAT COMBINATION CONTROL message as if it has not been received:
- 1> the procedure ends.

8.2.6 Physical channel reconfiguration

See subclause 8.2.2 Reconfiguration procedures.

8.2.7 Physical Shared Channel Allocation [TDD only]



Figure 8.2.7-1: Physical Shared Channel Allocation

8.2.7.1 General

The purpose of this procedure is to allocate radio resources to USCH and/or DSCH transport channels in TDD mode, for use by a UE. This procedure can also be used to indicate to the UE, that a PUSCH allocation is pending, in order to prevent further capacity requests from the UE.

UEs are not required to receive FACH and DSCH simultaneously, i.e. if resources are allocated to DSCH the FACH reception may be suspended.

8.2.7.2 Initiation

To initiate the Physical Shared Channel Allocation procedure, the UTRAN sends the "PHYSICAL SHARED CHANNEL ALLOCATION" message on the downlink SHCCH or on the downlink DCCH using UM RLC. The DSCH-RNTI shall be included for UE identification, if the message is sent on the SHCCH.

8.2.7.3 Reception of a PHYSICAL SHARED CHANNEL ALLOCATION message by the UE

Upon reception of a "PHYSICAL SHARED CHANNEL ALLOCATION" message, if the message is received on the downlink SHCCH the UE shall:

- 1> check the DSCH-RNTI to see if the UE is addressed by the message;
- 1> if the UE is addressed by the message, or if the message is received on the downlink DCCH:
 - 2> perform the following actions.
- 1> otherwise:
 - 2> ignore the message.
- 1> act upon all received information elements as specified in subclause 8.6, unless specified otherwise in the following:
- 1> if the IE "ISCP Timeslot list" is included:
 - 2> store the timeslot numbers given there for future Timeslot ISCP measurements and reports in the variable PHYSICAL_SHARED_CHANNEL_CONFIGURATION.
- 1> if the IE "PDSCH capacity allocation info" is included:
 - 2> configure the physical resources used for the downlink CCTrCH given by the IE "TFCS ID" according to the following:
- 3> if the CHOICE "Configuration" has the value "Old configuration":
 - 4> if the UE has stored a PDSCH configuration in the variable PHYSICAL_SHARED_CHANNEL_CONFIGURATION with the identity given by the IE "PDSCH Identity":
 - 5> configure the physical resources according to that configuration.
 - 4> otherwise:
 - 5> ignore the IE "PDSCH capacity allocation info".
- 3> if the CHOICE "Configuration" has the value "New configuration":
 - 4> configure the physical resources according to the information given in IE "PDSCH Info". If IE "Common timeslot info" or IE "PDSCH timeslots and codes" IE are not present in IE "PDSCH Info":
 - 5> reuse the configuration stored in the variable PHYSICAL_SHARED_CHANNEL_CONFIGURATION for this CCTrCH.
 - 4> if the IE "PDSCH Identity" is included:
 - 5> store the new configuration in the variable PHYSICAL_SHARED_CHANNEL_CONFIGURATION using that identity.
 - 2> start using the new configuration at the CFN specified by the IE "Allocation activation time", and use that for the duration given by the IE "Allocation duration";
 - 2> if the IE "Confirm request" has the value "Confirm PDSCH" and IE "PDSCH Identity" is included in IE "PDSCH capacity allocation info":
- 3> initiate the PUSCH CAPACITY REQUEST procedure as described in subclause 8.2.8.
 - 1> if the IE "PUSCH capacity allocation info" is included:
 - 2> stop the timer T310, if running;
 - 2> if the CHOICE "PUSCH allocation" has the value "PUSCH allocation pending":

- 3> start the timer T311.
 - 2> if the CHOICE "PUSCH allocation" has the value "PUSCH allocation assignment":
- 3> stop the timer T311, if running;
- 3> configure the physical resources used for the uplink CCTrCH given by the IE "TFCS ID" according to the following:
 - 4> if the CHOICE "Configuration" has the value "Old configuration":
 - 5> if the UE has stored a PUSCH configuration with the identity given by the IE "PUSCH Identity" in the variable PHYSICAL_SHARED_CHANNEL_CONFIGURATION:
 - 6> configure the physical resources according to that configuration.
 - 5> otherwise:
 - 6> ignore the IE "PUSCH capacity allocation info".
 - 4> if the CHOICE "Configuration" has the value "New configuration", the UE shall:
 - 5> configure the physical resources according to the information given in IE "PUSCH Info". If IE "Common timeslot info" or IE "PUSCH timeslots and codes" is not present in IE "PUSCH Info":
 - 6> reuse the configuration stored in the variable PHYSICAL_SHARED_CHANNEL_CONFIGURATION for this CCTrCH.
 - 5> if the IE "PUSCH Identity" is included:
 - 6> store the new configuration in the variable PHYSICAL_SHARED_CHANNEL_CONFIGURATION using that identity.
- 3> if the IE "PUSCH power control info" is present in this message and includes the parameter "UL target SIR" for 3.84 Mcps TDD, or the parameters "PRX_{PUSCHdes}" and "TPC Step Size" for 1.28 Mcps TDD, or the parameters are stored in the variable PHYSICAL SHARED CHANNEL CONFIGURATION for this CCTrCH:
 - 4> start using the new configuration at the CFN specified by the IE "Allocation activation time", and use that for the duration given by the IE "Allocation duration".

3> otherwise:

- 4> ignore the IE "PUSCH capacity allocation info".
- 3> if the IE "PUSCH power control info" is present in this message and includes the parameter "UL target SIR" for 3.84 Mcps TDD, or the parameters "PRX_{PUSCHdes}" and/or "TPC Step Size" for 1.28 Mcps TDD:
 - 4> replace the parameters "UL target SIR" or "PRX_{PUSCHdes}" or "TPC Step Size" stored in the variable PHYSICAL SHARED CHANNEL CONFIGURATION for this CCTrCH with the signalled values.
- 3> if the IE "Traffic volume report request " is included:
 - 4> initiate the PUSCH CAPACITY REQUEST procedure as described in subclause 8.2.8 at the time indicated by the IE "Traffic volume report request".
- 3> if the IE "Confirm request" has the value "Confirm PUSCH" and IE "PUSCH Identity" is included in IE "PUSCH capacity allocation info":
 - 4> initiate the PUSCH CAPACITY REQUEST procedure as described in subclause 8.2.8.
- 3> determine the TFCS subset and hence the TFCI values which are possible given the PUSCH allocation for that CCTrCH;
- 3> configure the MAC-c/sh in the UE with this TFCS restriction if necessary;
- 3> transmit USCH Transport Block Sets as required, within the TFCS limits given by the PUSCH allocation.

NOTE: If the UE has just entered a new cell and System Information Block Type 6 has not yet been scheduled, PUSCH/PDSCH information should be specified in the allocation message.

The UE shall:

- 1> clear the entry for the PHYSICAL SHARED CHANNEL ALLOCATION message in the table "Accepted transactions" in the variable TRANSACTIONS:
- 1> and the procedure ends.

8.2.7.4 Invalid PHYSICAL SHARED CHANNEL ALLOCATION message

If the UE receives a PHYSICAL SHARED CHANNEL ALLOCATION message, which contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

- 1> ignore the invalid PHYSICAL SHARED CHANNEL ALLOCATION message;
- 1> submit the PUSCH CAPACITY REQUEST message for transmission on the uplink SHCCH, setting the information elements in the message as specified in subclause 8.2.8.3;
- 1> reset counter V310:
- 1> start timer T310;
- 1> proceed as described in subclause 8.2.8.

8.2.8 PUSCH capacity request [TDD only]




Figure 8.2.8-1: PUSCH Capacity request procedure

8.2.8.1 General

With this procedure, the UE transmits its request for PUSCH resources to the UTRAN. In the normal case, the UTRAN responds with a PHYSICAL SHARED CHANNEL ALLOCATION message, which either allocates the requested PUSCH resources, and/or allocates a PDSCH resource, or may just serve as an acknowledgement, indicating that PUSCH allocation is pending.

This procedure can also be used to acknowledge the reception of a PHYSICAL SHARED CHANNEL ALLOCATION message, or to indicate a protocol error in that message.

With the PUSCH CAPACITY REQUEST message, the UE can request capacity for one or more USCH.

8.2.8.2 Initiation

This procedure is initiated:

1> in the CELL FACH or CELL DCH state;

1> and when at least one RB using USCH has been established;

1> and when the UE sees the requirement to request physical resources (PUSCH) for an USCH channel or there is the need to reply to a PHYSICAL SHARED CHANNEL ALLOCATION message as described in clause 8.2.7 (i.e. to confirm the reception of a message, if requested to do so, or to indicate a protocol error).

The procedure can be initiated if:

- Timer T311 is not running.
- The timer T310 (capacity request repetition timer) is not running.

The UE shall:

- 1> set the IEs in the PUSCH CAPACITY REQUEST message according to subclause 8.2.8.3;
- 1> if the procedure is triggered to reply to a previous PHYSICAL SHARED CHANNEL ALLOCATION message by the IE "Confirm request" set to "Confirm PUSCH" and the IE "PUSCH capacity allocation info" is not present:
 - 2> transmit the PUSCH CAPACITY REQUEST message on RACH.
- 1> else:
 - 2> transmit the PUSCH CAPACITY REQUEST message on the uplink SHCCH.
- 1> set counter V310 to 1;
- 1> start timer T310.

8.2.8.3 PUSCH CAPACITY REQUEST message contents to set

With one PUSCH CAPACITY REQUEST message, capacity for one or more USCH can be requested. It shall include these information elements:

- 1> DSCH-RNTI to be used as UE identity if the message is sent on RACH;
- 1> Traffic volume measured results for each radio bearer satisfying the reporting criteria as specified in the MEASUREMENT CONTROL procedure (if no radio bearer satisfies the reporting criteria, traffic volume measured results shall not be included). These results shall include:
 - 2> Radio Bearer ID of the Radio Bearer being reported;
 - 2> RLC buffer payload for these radio bearers, as specified by the MEASUREMENT CONTROL procedure.

The UE shall:

- 1> if the initiation of the procedure is triggered by the IE "Traffic volume report request" in a previously received PHYSICAL SHARED CHANNEL ALLOCATION message:
 - 2> report the traffic volume measurement result for the radio bearer mapped on USCH transport channel specified in the received message. These results shall include:
- 3> Radio Bearer ID of the Radio Bearer being reported;
- 3> RLC buffer payload for this radio bearer.
 - 1> if the initiation of the procedure is triggered by the IE "Confirm request" set to "Confirm PDSCH" in a previously received PHYSICAL SHARED CHANNEL ALLOCATION message and the IE "PUSCH capacity allocation info" is present in this message:
 - 2> set the CHOICE "Allocation confirmation" to "PDSCH Confirmation" with the value given in the IE "PDSCH Identity" stored in the variable PHYSICAL_SHARED_CHANNEL_CONFIGURATION.
 - 1> if the initiation of the procedure is triggered by the IE "Confirm request" set to "Confirm PUSCH" in a previously received PHYSICAL SHARED CHANNEL ALLOCATION message:
 - 2> set the CHOICE "Allocation confirmation" to "PUSCH Confirmation" with the value given in the IE "PUSCH Identity" stored in the variable PHYSICAL_SHARED_CHANNEL_CONFIGURATION.

- 1> if the variable PROTOCOL_ERROR_REJECT is set to TRUE:
 - 2> include the IE "RRC transaction identifier" in the response message transmitted below; and
 - 2> set it to the value of "RRC transaction identifier" in the entry for the PHYSICAL SHARED CHANNEL ALLOCATION message in the table "Rejected transactions" in the variable TRANSACTIONS; and
 - 2> clear that entry;
 - 2> set the IE "protocol error indicator" to TRUE;
 - 2> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION.
- 1> if the value of the variable PROTOCOL_ERROR_ REJECT is FALSE:
 - 2> set the IE "Protocol error indicator" to FALSE.

As an option, the message may include IE "Timeslot ISCP" and IE "Primary CCPCH RSCP".

The timeslots for which "Timeslot ISCP" may be reported shall have been configured with a previous PHYSICAL SHARED CHANNEL ALLOCATION message and stored in the variable PHYSICAL_SHARED_CHANNEL_CONFIGURATION.

"Primary CCPCH RSCP" is reported when requested with a previous PHYSICAL SHARED CHANNEL ALLOCATION message.

8.2.8.4 Reception of a PUSCH CAPACITY REQUEST message by the UTRAN

Upon receiving a PUSCH CAPACITY REQUEST message with traffic volume measurement included for at least one radio bearer, the UTRAN should initiate the PHYSICAL SHARED CHANNEL ALLOCATION procedure, either for allocating PUSCH or PDSCH resources as required, or just as an acknowledgement, indicating a pending PUSCH allocation, as described in subclause 8.2.7.

8.2.8.5 T310 expiry

Upon expiry of timer T310, the UE shall:

- 1> if V310 is smaller than N310:
 - 2> transmit a new PUSCH CAPACITY REQUEST message on the Uplink SHCCH;
 - 2> restart timer T310;
 - 2> increment counter V310;
 - 2> set the IEs in the PUSCH CAPACITY REQUEST message as specified in subclause 8.2.8.3.
- 1> if V310 is greater than or equal to N310:
 - 2> the procedure ends.

8.2.9 Void

8.2.10 Uplink Physical Channel Control [TDD only]




Figure 8.2.10-1: Uplink Physical Channel Control

8.2.10.1 General

The uplink physical channel control procedure is used in TDD to control the uplink outer loop power control and timing advance running in the UE.

8.2.10.2 Initiation

The UTRAN initiates the procedure by transmitting the UPLINK PHYSICAL CHANNEL CONTROL message on the downlink DCCH using AM or UM RLC in order to update parameters for uplink open loop power control in the UE for one CCTrCH or to inform the UE about a new timing advance value to be applied. Especially, uplink interference information measured by the UTRAN can be included for the uplink timeslots used for the CCTrCH.

8.2.10.3 Reception of UPLINK PHYSICAL CHANNEL CONTROL message by the UE

Upon reception of the UPLINK PHYSICAL CHANNEL CONTROL message, the UE shall:

1> act upon all received information elements as specified in subclause 8.6.

In 1.28 Mcps TDD, if the IE "Uplink DPCH Power Control Info" is transmitted, this information shall be taken into account by the UE for uplink open loop power control and for uplink closed loop power control as described in subclause 8.6.6.11.

In 3.84 Mcps TDD, if the IEs "Uplink DPCH Power Control Info", "PRACH Constant Value", "PUSCH Constant Value", "HS-SICH Power Control Info", "Alpha" or IE group "list of UL Timeslot Interference" are transmitted, this information shall be taken into account by the UE for uplink open loop power control as specified in subclause 8.5.7. If the UE is capable of using IPDLs for UE positioning, the IE "IPDL-Alpha" shall be used instead of the IE "Alpha". If the IE "IPDL-Alpha" parameter is not present, the UE shall use IE "Alpha".

If the IE Special Burst Scheduling is transmitted the UE shall:

1> use the new value for the "Special Burst Generation Period".

The UE shall:

- 1> clear the entry for the UPLINK PHYSICAL CHANNEL CONTROL message in the table "Accepted transactions" in the variable TRANSACTIONS;
- 1> and the procedure ends.

8.2.10.4 Invalid UPLINK PHYSICAL CHANNEL CONTROL message

If the UE receives a UPLINK PHYSICAL CHANNEL CONTROL message, which contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

1> transmit an RRC STATUS message on the uplink DCCH using AM RLC, setting the information elements as specified below:

- 2> include the IE "Identification of received message"; and
- 2> set the IE "Received message type" to UPLINK PHYSICAL CHANNEL CONTROL; and
- 2> set the IE "RRC transaction identifier" to the value of "RRC transaction identifier" in the entry for the UPLINK PHYSICAL CHANNEL CONTROL message in the table "Rejected transactions" in the variable TRANSACTIONS; and
- 2> clear that entry;
- 2> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL ERROR INFORMATION.
- 1> when the RRC STATUS message has been submitted to lower layers for transmission:
 - 2> continue with any ongoing processes and procedures as if the invalid UPLINK PHYSICAL CHANNEL CONTROL message has not been received.

8.2.11 Physical channel reconfiguration failure




Figure 8.2.11-1: Physical channel reconfiguration failure in case of runtime configuration error

8.2.11.1 General

The physical channel reconfiguration failure procedure is used to indicate to the network a runtime configuration error in the UE.

8.2.11.2 Runtime error due to overlapping compressed mode configurations

When the UE has received from the UTRAN the configurations of several compressed mode transmission gap pattern sequences, and if several of these patterns are to be simultaneously active, the UE shall check to see if these simultaneously active transmission gap pattern sequences create transmission gaps in the same frame. An illegal overlap is created if two or more transmission gap pattern sequences create transmission gaps in the same frame, irrespective of the gaps are created in uplink or downlink.

If the parallel transmission gap pattern sequences create an illegal overlap, the UE shall:

- 1> delete the overlapping transmission gap pattern sequence configuration stored in the variable TGPS_IDENTITY, which is associated with the highest value of IE "TGPSI";
- 1> transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting the information elements as specified below:
 - 2> not include the IE "RRC transaction identifier";
 - 2> set the cause value in IE "failure cause" to value "compressed mode runtime error".
- 1> terminate the inter-frequency and/or inter-RAT measurements corresponding to the deleted transmission gap pattern sequence;
- 1> when the PHYSICAL CHANNEL RECONFIGURATION FAILURE message has been submitted to lower layers for transmission:

2> the procedure ends.

8.2.11.3 Runtime error due to overlapping compressed mode configuration and PDSCH reception

If UE is scheduled to receive a PDSCH frame at the same time instant as a compressed mode gap, UE shall perform the measurements according to the measurement purpose of the pattern sequence.

8.3 RRC connection mobility procedures

8.3.1 Cell and URA update procedures




Figure 8.3.1-1: Cell update procedure, basic flow




Figure 8.3.1-2: Cell update procedure with update of UTRAN mobility information




Figure 8.3.1-3: Cell update procedure with physical channel reconfiguration




Figure 8.3.1-4: Cell update procedure with transport channel reconfiguration




Figure 8.3.1-5: Cell update procedure with radio bearer release




Figure 8.3.1-6: Cell update procedure with radio bearer reconfiguration




Figure 8.3.1-7: Cell update procedure, failure case



Figure 8.3.1-8: URA update procedure, basic flow




Figure 8.3.1-9: URA update procedure with update of UTRAN mobility information




Figure 8.3.1-10: URA update procedure, failure case

8.3.1.1 General

The URA update and cell update procedures serve several main purposes:

- to notify UTRAN after re-entering service area in the URA_PCH or CELL_PCH state;
- to notify UTRAN of an RLC unrecoverable error [16] on an AM RLC entity;
- to be used as a supervision mechanism in the CELL_FACH, CELL_PCH, or URA_PCH state by means of periodical update.

In addition, the URA update procedure also serves the following purpose:

- to retrieve a new URA identity after cell re-selection to a cell not belonging to the current URA assigned to the UE in URA_PCH state.

In addition, the cell update procedure also serves the following purposes:

- to update UTRAN with the current cell the UE is camping on after cell reselection;
- to act on a radio link failure in the CELL_DCH state;
- to act on the transmission failure of the UE CAPABILITY INFORMATION message;

- when triggered in the URA_PCH or CELL_PCH state, to notify UTRAN of a transition to the CELL_FACH state due to the reception of UTRAN originated paging or due to a request to transmit uplink data.

The URA update and cell update procedures may:

- 1> include an update of mobility related information in the UE;
- 1> cause a state transition from the CELL_FACH state to the CELL_DCH, CELL_PCH or URA_PCH states or idle mode.

The cell update procedure may also include:

- a re-establish of AM RLC entities;
- a radio bearer release, radio bearer reconfiguration, transport channel reconfiguration or physical channel reconfiguration.

8.3.1.2 Initiation

A UE shall initiate the cell update procedure in the following cases:

- 1> Uplink data transmission:
 - 2> if the UE is in URA PCH or CELL PCH state; and
 - 2> if the UE has uplink RLC data PDU or uplink RLC control PDU on RB1 or upwards to transmit:
- 3> perform cell update using the cause "uplink data transmission".
 - 1> Paging response:
 - 2> if the criteria for performing cell update with the cause specified above in the current subclause are not met;
 - 2> if the UE in URA_PCH or CELL_PCH state, receives a PAGING TYPE 1 message fulfilling the conditions for initiating a cell update procedure specified in subclause 8.1.2.3:
- 3> perform cell update using the cause "paging response".
 - 1> Radio link failure:
 - 2> if none of the criteria for performing cell update with the causes specified above in the current subclause is met:
- 3> if the UE is in CELL_DCH state and the criteria for radio link failure are met as specified in subclause 8.5.6; or
- 3> if the transmission of the UE CAPABILITY INFORMATION message fails as specified in subclause 8.1.6.6:
 - 4> perform cell update using the cause "radio link failure".
 - 1> Re-entering service area:
 - 2> if none of the criteria for performing cell update with the causes specified above in the current subclause is met; and
 - 2> if the UE is in CELL_FACH or CELL_PCH state; and
 - 2> if the UE has been out of service area and re-enters service area before T307 or T317 expires:
- 3> perform cell update using the cause "re-entering service area".
 - 1> RLC unrecoverable error:
 - 2> if none of the criteria for performing cell update with the causes specified above in the current subclause is met: and
 - 2> if the UE detects RLC unrecoverable error [16] in an AM RLC entity:

- 3> perform cell update using the cause "RLC unrecoverable error".
 - 1> Cell reselection:
 - 2> if none of the criteria for performing cell update with the causes specified above in the current subclause is met:
- 3> if the UE is in CELL_FACH or CELL_PCH state and the UE performs cell re-selection; or
- 3> if the UE is in CELL_FACH state and the variable C_RNTI is empty:
 - 4> perform cell update using the cause "cell reselection".
 - 1> Periodical cell update:
 - 2> if none of the criteria for performing cell update with the causes specified above in the current subclause is met; and
 - 2> if the UE is in CELL FACH or CELL PCH state; and
 - 2> if the timer T305 expires; and
 - 2> if the criteria for "in service area" as specified in subclause 8.5.5.2 are fulfilled; and
 - 2> if periodic updating has been configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity":
- 3> perform cell update using the cause "periodical cell update".
- A UE in URA_PCH state shall initiate the URA update procedure in the following cases:
 - 1> URA reselection:
 - 2> if the UE detects that the current URA assigned to the UE, stored in the variable URA_IDENTITY, is not present in the list of URA identities in system information block type 2; or
 - 2> if the list of URA identities in system information block type 2 is empty; or
 - 2> if the system information block type 2 can not be found:
- 3> perform URA update using the cause "change of URA".
 - 1> Periodic URA update:
 - 2> if the criteria for performing URA update with the causes as specified above in the current subclause are not met; and
 - 2> if the timer T305 expires while the UE is in the service area; and
 - 2> if periodic updating has been configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity":
- 3> perform URA update using the cause "periodic URA update".
- When initiating the URA update or cell update procedure, the UE shall:
 - 1> stop timer T305;
 - 1> if the UE is in CELL_DCH state:
 - 2> in the variable RB_TIMER_INDICATOR, set the IE "T314 expired" and the IE "T315 expired" to FALSE;
 - 2> if the stored values of the timer T314 and timer T315 are both equal to zero; or
 - 2> if the stored value of the timer T314 is equal to zero and there are no radio bearers associated with any radio access bearers for which in the variable ESTABLISHED_RABS the value of the IE "Re-establishment timer" is set to "useT315":

- 3> release all its radio resources;
- 3> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;
- 3> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
- 3> clear the variable ESTABLISHED_RABS;
- 3> enter idle mode;
- 3> perform other actions when entering idle mode from connected mode as specified in subclause 8.5.2;
- 3> and the procedure ends.
 - 2> if the stored value of the timer T314 is equal to zero:
- 3> release all radio bearers, associated with any radio access bearers for which in the variable ESTABLISHED_RABS the value of the IE "Re-establishment timer" is set to "useT314";
- 3> in the variable RB_TIMER_INDICATOR set the IE "T314 expired" to TRUE.
 - 2> if the stored value of the timer T315 is equal to zero:
- 3> release all radio bearers associated with any radio access bearers for which in the variable ESTABLISHED_RABS the value of the IE "Re-establishment timer" is set to "useT315";
- 3> in the variable RB_TIMER_INDICATOR set the IE "T315 expired" to TRUE.
 - 2> if the stored value of the timer T314 is greater than zero:
- 3> if there are radio bearers associated with any radio access bearers for which in the variable ESTABLISHED_RABS the value of the IE "Re-establishment timer" is set to "useT314":
 - 4> start timer T314.
- 3> if there are no radio bearers associated with any radio access bearers for which in the variable ESTABLISHED_RABS the value of the IE "Re-establishment timer" is set to "useT314" or "useT315":
 - 4> start timer T314.
 - 2> if the stored value of the timer T315 is greater than zero:
- 3> if there are radio bearers associated with any radio access bearers for which in the variable ESTABLISHED_RABS the value of the IE "Re-establishment timer" is set to "useT315":
 - 4> start timer T315.
 - 2> for the released radio bearer(s):
- 3> delete the information about the radio bearer from the variable ESTABLISHED_RABS;
- 3> when all radio bearers belonging to the same radio access bearer have been released:
 - 4> indicate local end release of the radio access bearer to upper layers using the CN domain identity together with the RAB identity stored in the variable ESTABLISHED_RABS;
 - 4> delete all information about the radio access bearer from the variable ESTABLISHED_RABS.
 - 2> select a suitable UTRA cell on the current frequency according to [4];
 - 2> set the variable ORDERED_RECONFIGURATION to FALSE.
 - 1> set the variables PROTOCOL_ERROR_INDICATOR, FAILURE_INDICATOR, UNSUPPORTED_CONFIGURATION and INVALID_CONFIGURATION to FALSE;
 - 1> set the variable CELL_UPDATE_STARTED to TRUE;

- 1> if HS-DSCH is configured:
 - 2> stop any HS-DSCH reception procedures;
 - 2> clear any stored HS-PDSCH configuration;
 - 2> act as if the IE "MAC-hs reset indicator" is received and set to TRUE;
 - 2> release all HARQ resources;
 - 2> remove any H-RNTI stored;
 - 2> clear the variable H_RNTI;
 - 2> set the variable HS_DSCH_RECEPTION to FALSE.
- 1> if the UE is not already in CELL_FACH state:
 - 2> move to CELL_FACH state;
 - 2> select PRACH according to subclause 8.5.17;
 - 2> select Secondary CCPCH according to subclause 8.5.19;
 - 2> use the transport format set given in system information as specified in subclause 8.6.5.1.
- 1> if the UE performs cell re-selection:
 - 2> clear the variable C_RNTI; and
 - 2> stop using that C_RNTI just cleared from the variable C_RNTI in MAC.
- 1> set CFN in relation to SFN of current cell according to subclause 8.5.15;
- 1> in case of a cell update procedure:
 - 2> set the contents of the CELL UPDATE message according to subclause 8.3.1.3;
 - 2> submit the CELL UPDATE message for transmission on the uplink CCCH.
- 1> in case of a URA update procedure:
 - 2> set the contents of the URA UPDATE message according to subclause 8.3.1.3;
 - 2> submit the URA UPDATE message for transmission on the uplink CCCH.
- 1> set counter V302 to 1;
- 1> start timer T302 when the MAC layer indicates success or failure in transmitting the message.

8.3.1.3 CELL UPDATE / URA UPDATE message contents to set

In case of cell update procedure the UE shall transmit a CELL UPDATE message.

In case of URA update procedure the UE shall transmit a URA UPDATE message.

The UE shall set the IEs in the CELL UPDATE message as follows:

- 1> set the IE "Cell update cause" corresponding to the cause specified in subclause 8.3.1.2 that is valid when the CELL UPDATE message is submitted to lower layers for transmission;
- NOTE: During the time period starting from when a cell update procedure is initiated by the UE until when the procedure ends, additional CELL UPDATE messages may be transmitted by the UE with different causes.
- 1> set the IE "U-RNTI" to the value of the variable U RNTI;
- 1> if the value of the variable PROTOCOL_ERROR_INDICATOR is TRUE:

- 2> include the IE "RRC transaction identifier"; and
- 3> set it to the value of "RRC transaction identifier" in the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.
 - 2> include and set the IE "failure cause" to the cause value "protocol error";
 - 2> set the IE "Protocol error information" set to the value of the variable PROTOCOL_ERROR_INFORMATION.
 - 1> if the value of the variable FAILURE_INDICATOR is TRUE:
 - 2> include the IE "RRC transaction identifier"; and
- 3> set it to the value of "RRC transaction identifier" in the entry for the CELL UPDATE CONFIRM message in the table "Accepted transactions" in the variable TRANSACTIONS.
 - 2> include and set the IE "failure cause" to the value of the variable FAILURE_CAUSE.
 - 1> include the START values for each CN domain, calculated according to subclause 8.5.9;
 - 1> if an unrecoverable error [16] in any of the AM RLC entities for the signalling radio bearers RB2, RB3 or RB4 is detected:
 - 2> set the IE "AM_RLC error indication (RB2, RB3 or RB4)" to TRUE.
 - 1> otherwise:
 - 2> set the IE "AM RLC error indication (RB2, RB3 or RB4)" to FALSE.
 - 1> if an unrecoverable error [16] in any of the AM RLC entities for the RB5 or upward is detected:
 - 2> set the IE "AM_RLC error indication (RB>4)" to TRUE.
 - 1> otherwise:
 - 2> set the IE "AM_RLC error indication (RB>4)" to FALSE.
 - 1> set the IE "RB Timer indicator" to the value of the variable RB_TIMER_INDICATOR;
 - 1> if the variable ESTABLISHMENT_CAUSE is initialised:
 - 2> include the IE "Establishment cause" and set it to the value of the variable ESTABLISHMENT_CAUSE.

The UE shall set the IEs in the URA UPDATE message as follows:

- 1> set the IE "U-RNTI" to the value of the variable U RNTI;
- 1> set the IE "URA update cause" corresponding to which cause as specified in subclause 8.3.1.2 that is valid when the URA UPDATE message is submitted to lower layers for transmission;
- NOTE: During the time period starting from when a URA update procedure is initiated by the UE until when the procedure ends, additional URA UPDATE messages may be transmitted by the UE with different causes, depending on which causes are valid for the respective URA UPDATE message.
 - 2> if the value of the variable PROTOCOL_ERROR_INDICATOR is TRUE:
- 3> include the IE "RRC transaction identifier"; and
 - 4> set it to the value of "RRC transaction identifier" in the entry for the URA UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS;
- 3> set the IE "Protocol error indicator" to TRUE;
- 3> include the IE "Protocol error information" set to the value of the variable PROTOCOL_ERROR_INFORMATION.
 - 2> if the value of the variable PROTOCOL_ERROR_INDICATOR is FALSE:

- 3> if the value of the variable INVALID_CONFIGURATION is TRUE:
 - 4> include the IE "RRC transaction identifier"; and
 - 4> set it to the value of "RRC transaction identifier" in the entry for the URA UPDATE CONFIRM message in the table "Accepted transactions" in the variable TRANSACTIONS;
 - 4> set the IE "Protocol error indicator" to TRUE;
 - 4> include the IE "Protocol error information" set to "Information element value not comprehended";
- 3> if the value of the variable INVALID_CONFIGURATION is FALSE:
 - 4> set the IE "Protocol error indicator" to FALSE.

8.3.1.4 T305 expiry and the UE detects "out of service area"

When the T305 expires and the UE detects that it is "out of service area" as specified in subclause 8.5.5.1, the UE shall

- 1> start timer T307;
- 1> act according to subclause 7.2.2.

8.3.1.4.1 Re-entering "in service area"

If the UE detects "in service area" according to subclause 8.5.5.2 and timer T307 or T317 is running, the UE shall:

- 1> check the value of V302; and
- 1> if V302 is equal to or smaller than N302:
 - 2> in case of a cell update procedure:
- 3> set the contents of the CELL UPDATE message according to subclause 8.3.1.3;
- 3> submit the CELL UPDATE message for transmission on the uplink CCCH.
 - 2> in case of a URA update procedure:
- 3> set the contents of the URA UPDATE message according to subclause 8.3.1.3;
- 3> submit the URA UPDATE message for transmission on the uplink CCCH.
 - 2> increment counter V302;
 - 2> restart timer T302 when the MAC layer indicates success or failure to transmit the message.
 - 1> if V302 is greater than N302:
 - 2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;

 - 2> in case of a cell update procedure:
- 3> clear the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.
 - 2> in case of a URA update procedure:
- 3> clear the entry for the URA UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.
 - 2> release all its radio resources;

- 2> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;
- 2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
- 2> clear the variable ESTABLISHED_RABS;
- 2> enter idle mode;
- 2> perform other actions when entering idle mode from connected mode as specified in subclause 8.5.2;
- 2> and the procedure ends.

8.3.1.4.2 Expiry of timer T307

When the T307 expires, the UE shall:

- 1> move to idle mode;
- 1> release all dedicated resources;
- 1> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;
- 1> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
- 1> clear the variable ESTABLISHED_RABS;
- 1> perform other actions when entering idle mode from connected mode as specified in subclause 8.5.2;
- 1> and the procedure ends.

8.3.1.5 Reception of an CELL UPDATE/URA UPDATE message by the UTRAN

When the UTRAN receives a CELL UPDATE/URA UPDATE message, the UTRAN should:

- 1> in case the procedure was triggered by reception of a CELL UPDATE:
 - 2> if SRNS relocation was performed:
- 3> transmit a CELL UPDATE CONFIRM message on the downlink DCCH.
 - 2> otherwise:
- 3> update the START value for each CN domain as maintained in UTRAN (refer to subclause 8.5.9) with "START" in the IE "START list" for the CN domain as indicated by "CN domain identity" in the IE "START list";
- 3> transmit a CELL UPDATE CONFIRM message on the downlink DCCH or optionally on the CCCH but only if ciphering is not required; and
- 3> optionally set the IE "RLC re-establish indicator (RB2, RB3 and RB4)" and/or the IE "RLC re-establish indicator (RB5 and upwards)" to TRUE to request a RLC re-establishment in the UE, in which case the corresponding RLC entities should also be re-established in UTRAN; or
 - 1> in case the procedure was triggered by reception of a URA UPDATE:
 - 2> if SRNS relocation was performed:
- 3> transmit a URA UPDATE CONFIRM message on the downlink DCCH.
 - 2> otherwise:
- 3> transmit a URA UPDATE CONFIRM message on the downlink CCCH or DCCH.

- 2> include the IE "URA identity" in the URA UPDATE CONFIRM message in a cell where multiple URA identifiers are broadcast; or
- 1> initiate an RRC connection release procedure (see subclause 8.1.4) by transmitting an RRC CONNECTION RELEASE message on the downlink CCCH. In particular UTRAN should:
 - 2> if the CELL UPDATE message was sent because of an unrecoverable error in RB2, RB3 or RB4:
- 3> initiate an RRC connection release procedure (subclause 8.1.4) by transmitting an RRC CONNECTION RELEASE message on the downlink CCCH.

UTRAN may transmit several CELL UPDATE CONFIRM/URA UPDATE CONFIRM messages to increase the probability of proper reception of the message by the UE. In such a case, the RRC SN for these repeated messages should be the same.

8.3.1.6 Reception of the CELL UPDATE CONFIRM/URA UPDATE CONFIRM message by the UE

When the UE receives a CELL UPDATE CONFIRM/URA UPDATE CONFIRM message; and

- if the message is received on the CCCH, and IE "U-RNTI" is present and has the same value as the variable U_RNTI; or
- if the message is received on DCCH:

the UE may:

1> maintain a list of the set of cells to which the UE has Radio Links if the IE "Cell ID" is present.

the UE shall:

- 1> stop timer T302;
- 1> in case of a cell update procedure and the CELL UPDATE CONFIRM message:
 - 2> includes "RB information elements"; and/or
 - 2> includes "Transport channel information elements"; and/or
 - 2> includes "Physical channel information elements"; and
 - 2> if the variable ORDERED_RECONFIGURATION is set to FALSE:
- 3> set the variable ORDERED_RECONFIGURATION to TRUE.
 - 1> act upon all received information elements as specified in subclause 8.6, unless specified otherwise in the following:
 - 2> if the IE "Frequency info" is included in the message:
- 3> if the IE "RRC State Indicator" is set to the value "CELL_FACH" or "CELL_PCH" or URA_PCH":
 - 4> select a suitable UTRA cell according to [4] on that frequency;
 - 4> act as specified in subclause 8.3.1.12.
- 3> if the IE "RRC State Indicator" is set to the value "CELL_DCH":
 - 4> act on the IE "Frequency info" as specified in subclause 8.6.6.1.
 - 2> use the transport channel(s) applicable for the physical channel types that is used; and
 - 2> if the IE "TFS" is neither included nor previously stored in the UE for that transport channel(s):
- 3> use the TFS given in system information.
 - 2> if none of the TFS stored is compatible with the physical channel:

- 3> delete the stored TFS;
- 3> use the TFS given in system information.
 - 2> if the IE "RLC re-establish indicator (RB2, RB3 and RB4)" in the CELL UPDATE CONFIRM message is set to TRUE:
- 3> re-establish the RLC entities for signalling radio bearer RB2, signalling radio bearer RB3 and signalling radio bearer RB4 (if established);
- 3> if the value of the IE "Status" in the variable CIPHERING_STATUS of the CN domain stored in the variable LATEST_CONFIGURED_CN_DOMAIN is set to "Started":
 - 4> set the HFN component of the respective COUNT-C values for AM RLC entities with RB identity 2,RB identity 3 and RB identity 4 (if established) equal to the START value included in the latest transmitted CELL UPDATE message for the CN domain stored in the variable LATEST CONFIGURED CN DOMAIN.
 - 2> if the IE "RLC re-establish indicator (RB5 and upwards)" in the CELL UPDATE CONFIRM message is set to TRUE:
- 3> for radio bearers with RB identity 5 and upwards:
 - 4> re-establish the AM RLC entities;
 - 4> if the value of the IE "Status" in the variable CIPHERING_STATUS of the CN domain as indicated in the IE "CN domain identity" in the IE "RAB info" in the variable ESTABLISHED_RABS is set to "Started":
 - 5> set the HFN component of the respective COUNT-C values for AM RLC entities equal to the START value included in this CELL UPDATE message for the CN domain as indicated in the IE "CN domain identity" in the IE "RAB info" in the variable ESTABLISHED_RABS.
 - NOTE: UE actions, in case IE "Downlink counter synchronisation info" is included and either IE "RLC reestablish indicator (RB2, RB3 and RB4)" or IE "RLC re-establish indicator (RB5 and upwards)" are set to TRUE, are not defined.
 - 1> if the CELL UPDATE CONFIRM / URA UPDATE CONFIRM message contained the IE "Ciphering mode info" or contained the IE "Integrity protection mode info":
 - 2> set the IE "Status" in the variable SECURITY_MODIFICATION for all the CN domains in the variable SECURITY_MODIFICATION to "Affected".
 - 1> if the variable ESTABLISHMENT_CAUSE is set:
 - 2> clear the variable ESTABLISHMENT_CAUSE.
 - 1> enter a state according to subclause 8.6.3.3 applied on the CELL UPDATE CONFIRM / URA UPDATE CONFIRM message.
- If the UE after state transition enters CELL_DCH state, it shall:
 - 1> perform the physical layer synchronisation procedure A as specified in [29] (FDD only);
 - 1> not prohibit periodical status transmission in RLC.
- If the UE after state transition remains in CELL_FACH state, it shall
 - 1> start the timer T305 using its initial value if timer T305 is not running and periodical cell update has been configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity";
 - 1> select PRACH according to subclause 8.5.17;
 - 1> select Secondary CCPCH according to subclause 8.5.19;
 - 1> not prohibit periodical status transmission in RLC;

- 1> if the IE "UTRAN DRX cycle length coefficient" is included in the same message:
 - 2> ignore that IE and stop using DRX.
- If the UE after state transition enters URA PCH or CELL PCH state, it shall:
 - 1> prohibit periodical status transmission in RLC;
 - 1> clear the variable C_RNTI;
 - 1> stop using that C_RNTI just cleared from the variable C_RNTI in MAC;
 - 1> start the timer T305 using its initial value if timer T305 is not running and periodical update has been configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity";
 - 1> select Secondary CCPCH according to subclause 8.5.19;
 - 1> if the IE "UTRAN DRX cycle length coefficient" is included in the same message:
 - 2> use the value in the IE "UTRAN DRX Cycle length coefficient" for calculating Paging Occasion and PICH Monitoring Occasion as specified in subclause 8.6.3.2.
 - 1> if the IE "UTRAN DRX cycle length coefficient" is not included in the same message:
 - 2> set the variable INVALID_CONFIGURATION to TRUE.
- If the UE after the state transition remains in CELL FACH state; and
 - 1> the contents of the variable C_RNTI are empty:
- it shall check the value of V302; and:
 - 1> if V302 is equal to or smaller than N302:
 - 2> if, caused by the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message:
- 3> the IE "Reconfiguration" in the variable CIPHERING_STATUS is set to TRUE; and/or
- 3> the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO is set to TRUE:
 - 4> abort the ongoing integrity and/or ciphering reconfiguration;
 - 4> if the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message contained the IE "Ciphering mode info":
 - 5> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE; and
 - 5> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO.
 - 4> if the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message contained the IE "Integrity protection mode info":
 - 5> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to FALSE; and
 - 5> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.
 - 2> in case of a URA update procedure:
- 3> stop the URA update procedure;
- 3> clear any entry for the URA UPDATE CONFIRM message in the table "Accepted transactions" in the variable TRANSACTIONS; and
- 3> continue with a cell update procedure.
 - 2> set the contents of the CELL UPDATE message according to subclause 8.3.1.3, except for the IE "Cell update cause" which shall be set to "cell reselection";

- 2> submit the CELL UPDATE message for transmission on the uplink CCCH;
- 2> increment counter V302;
- 2> restart timer T302 when the MAC layer indicates success or failure to transmit the message.
- 1> if V302 is greater than N302:
 - 2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;
 - 2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO;
 - 2> in case of a cell update procedure:
- 3> clear the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.
 - 2> in case of a URA update procedure:
- 3> clear the entry for the URA UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.
 - 2> release all its radio resources;
 - 2> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;
 - 2> clear the variable ESTABLISHED SIGNALLING CONNECTIONS;
 - 2> clear the variable ESTABLISHED_RABS;
 - 2> enter idle mode;
 - 2> other actions the UE shall perform when entering idle mode from connected mode are specified in subclause 8.5.2;
 - 2> and the procedure ends.

If the UE after the state transition remains in CELL_FACH state; and

- a C-RNTI is stored in the variable C_RNTI;

or

- the UE after the state transition moves to another state than the CELL FACH state:

the UE shall:

- 1> if the CELL UPDATE CONFIRM / URA UPDATE CONFIRM message contained the IE "Ciphering mode info":
 - 2> include and set the IE "Radio bearer uplink ciphering activation time info" in any response message transmitted below to the value of the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO.
- 1> in case cell reselection interrupted an ongoing cell update procedure and a CELL UPDATE CONFIRM/URA UPDATE CONFIRM was received with the IE "Downlink counter synchronisation info" present and the response to which was not submitted to the lower layers due to the cell re-selection:
 - 2> include the IE "START list" in the response message transmitted according to subclause 8.3.1.7;
 - 2> if the CELL UPDATE CONFIRM/URA UPDATE CONFIRM, the response to which was not delivered to the lower layers, due to the cell re-selection, included the IE "RB with PDCP information list":
- 3> include the IE "RB with PDCP information list" in the response message transmitted according to subclause 8.3.1.7.
 - 1> in case of a cell update procedure:

- 2> set the IE "RRC transaction identifier" in any response message transmitted below to the value of "RRC transaction identifier" in the entry for the CELL UPDATE CONFIRM message in the table "Accepted transactions" in the variable TRANSACTIONS; and
- 2> clear that entry.
- 1> in case of a URA update procedure:
 - 2> set the IE "RRC transaction identifier" in any response message transmitted below to the value of "RRC transaction identifier" in the entry for the URA UPDATE CONFIRM message in the table "Accepted transactions" in the variable TRANSACTIONS; and
 - 2> clear that entry;
- 1> if the variable PDCP_SN_INFO is non-empty:
 - 2> include the IE "RB with PDCP information list" in any response message transmitted below and set it to the value of the variable PDCP_SN_INFO.
- 1> if the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message included the IE "Downlink counter synchronisation info":
 - 2> if the variable PDCP_SN_INFO is empty:
- 3> configure the corresponding RLC entity for all AM and UM radio bearers and AM and UM signalling radio bearers except RB2 to "stop".
 - 2> else:
- 3> configure the RLC entity for signalling radio bearers RB1, RB3 and RB4 to "stop";
- 3> configure the RLC entity for UM and AM radio bearers for which the IE "PDCP SN Info" is not included to "stop".
 - 2> re-establish the RLC entity for RB2;
 - 2> for the downlink and the uplink, apply the ciphering configuration as follows:
- 3> if the received re-configuation message included the IE "Ciphering Mode Info":
 - 4> use the ciphering configuration in the received message when transmitting the response message.
- 3> if the ciphering configuration for RB2 from a previously received SECURITY MODE COMMAND has not yet been applied because the activation times not having been reached:
 - 4> if the previous SECURITY MODE COMMAND was received due to new keys being received:
 - 5> consider the new ciphering configuration to include the received new keys;
 - 5> initialise the HFN component of the uplink COUNT-C and downlink COUNT-C of SRB2 as indicated in subclause 8.1.12.3.1.
 - 4> if the ciphering configuration for RB2 from a previously received SECURITY MODE COMMAND has not yet been applied because of the corresponding activation times not having been reached and the previous SECURITY MODE COMMAND caused a change in LATEST_CONFIGURED_CN_DOMAIN:
 - 5> consider the new ciphering configuration to include the keys associated with the LATEST_CONFIGURED_CN_DOMAIN;
 - 5> initialise the HFN component of the uplink COUNT-C and downlink COUNT-C of SRB2 to the most recently transmitted IE "START list" or IE "START" for the LATEST_CONFIGURED_CN_DOMAIN at the reception of the previous SECURITY MODE COMMAND.
 - 4> apply the new ciphering configuration immediately following RLC re-establishment.

3> else:

- 4> continue using the current ciphering configuration.
- 2> set the new uplink and downlink HFN component of the COUNT-C of RB2 to MAX(uplink HFN component of the COUNT-C of RB2, downlink HFN component of the COUNT-C of RB2);
- 2> increment by one the downlink and uplink values of the HFN component of the COUNT-C for RB2;
- 2> calculate the START value according to subclause 8.5.9;
- 2> include the calculated START values for each CN domain in the IE "START list" in the IE "Uplink counter synchronisation info" in any response message transmitted below.
- 1> transmit a response message as specified in subclause 8.3.1.7;
- 1> if the IE "Integrity protection mode info" was present in the CELL UPDATE CONFIRM or URA UPDATE CONFIRM message:
 - 2> start applying the new integrity protection configuration in the uplink for signalling radio bearer RB2 from and including the transmitted response message.
- 1> if the variable ORDERED_RECONFIGURATION is set to TRUE caused by the received CELL UPDATE CONFIRM message in case of a cell update procedure:
 - 2> set the variable ORDERED_RECONFIGURATION to FALSE.
- 1> clear the variable PDCP_SN_INFO;
- 1> when the response message transmitted per subclause 8.3.1.7 to the UTRAN has been confirmed by RLC:
 - 2> if the CELL UPDATE CONFIRM / URA UPDATE CONFIRM message contained the IE "Ciphering mode info":
- 3> resume data transmission on any suspended radio bearer and signalling radio bearer mapped on RLC-AM or RLC-UM;
- 3> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE; and
- 3> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO.
 - 2> if the CELL UPDATE CONFIRM / URA UPDATE CONFIRM message contained the IE "Integrity protection mode info":
- 3> set "Uplink RRC Message sequence number" for signalling radio bearer RB0 in the variable INTEGRITY_PROTECTION_INFO to a value such that next RRC message to be sent on uplink RB0 will use the new integrity protection configuration;
- 3> allow the transmission of RRC messages on all signalling radio bearers with any RRC SN;
- 3> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to FALSE.
 - 2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.
 - 1> in case of a cell update procedure:
 - 2> clear the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.
 - 1> in case of a URA update procedure:
 - 2> clear the entry for the URA UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.
 - 1> set the variable CELL_UPDATE_STARTED to FALSE;
 - 1> clear the variable SECURITY_MODIFICATION.

The procedure ends.

8.3.1.7 Transmission of a response message to UTRAN

If the CELL UPDATE CONFIRM message:

- includes the IE "RB information to release list":

the UE shall:

1> transmit a RADIO BEARER RELEASE COMPLETE as response message using AM RLC.

If the CELL UPDATE CONFIRM message:

- does not include the IE "RB information to release list"; and
- includes the IE "RB information to reconfigure list"; or
- includes the IE "RB information to be affected list":

the UE shall:

1> transmit a RADIO BEARER RECONFIGURATION COMPLETE as response message using AM RLC.

If the CELL UPDATE CONFIRM message:

- does not include the IE "RB information to release list", nor the IE "RB information to reconfigure list", nor the IE "RB information to be affected list"; and
- includes "Transport channel information elements":

the UE shall:

1> transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE as response message using AM RLC.

If the CELL UPDATE CONFIRM message:

- does not include the IE "RB information to release list", nor the IE "RB information to reconfigure list", nor the IE "RB information to be affected list"; and
- does not include "Transport channel information elements"; and
- includes "Physical channel information elements":

the UE shall:

1> transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE as response message using AM RLC.

If the CELL UPDATE CONFIRM message:

- does not include the IE "RB information to release list", nor the IE "RB information to reconfigure list", nor the IE "RB information to be affected list"; and
- does not include "Transport channel information elements"; and
- does not include "Physical channel information elements"; and
- includes "CN information elements"; or
- includes the IE "Ciphering mode info"; or
- includes the IE "Integrity protection mode info"; or
- includes the IE "New C-RNTI"; or
- includes the IE "New U-RNTI"; or
- includes the IE "Downlink counter synchronisation info" and the IE "New U-RNTI":

the UE shall:

1> transmit a UTRAN MOBILITY INFORMATION CONFIRM as response message using AM RLC.

If the CELL UPDATE CONFIRM message:

- does not include "RB information elements"; and
- does not include "Transport channel information elements"; and
- does not include "Physical channel information elements"; and
- does not include "CN information elements"; and
- does not include the IE "Ciphering mode info"; and
- does not include the IE "Integrity protection mode info"; and
- does not include the IE "New C-RNTI"; and
- does not include the IE "New U-RNTI":

the UE shall:

1> transmit no response message.

If the URA UPDATE CONFIRM message:

- includes "CN information elements"; or
- includes the IE "Ciphering mode info"; or
- includes the IE "Integrity protection mode info"; or
- includes any one or both of the IEs "New C-RNTI" and "New U-RNTI"; or
- includes the IE "Downlink counter synchronisation info" and the IE "New U-RNTI":

the UE shall:

1> transmit a UTRAN MOBILITY INFORMATION CONFIRM as response message using AM RLC.

If the URA UPDATE CONFIRM message:

- does not include "CN information elements"; and
- does not include the IE "Ciphering mode info"; and
- does not include the IE "Integrity protection mode info"; and
- does not include the IE "New U-RNTI"; and
- does not include the IE "New C-RNTI":

the UE shall:

1> transmit no response message.

If the new state is CELL_DCH or CELL_FACH, the response message shall be transmitted using the new configuration after the state transition., and the UE shall:

- 1> if the IE "Downlink counter synchronisation info" was included in the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message:
 - 2> when RLC has confirmed the successful transmission of the response message:
- 3> if the variable PDCP_SN_INFO is empty:

4> configure the RLC entity for all AM and UM radio bearers and AM and UM signalling radio bearers except RB2 to "continue".

3> else:

- 4> configure the RLC entity for signalling radio bearers RB1, RB3 and RB4 to "continue";
- 4> configure the RLC entity for UM and AM radio bearers for which the IE " PDCP SN Info" is not included to "continue".
- 3> re-establish all AM and UM RLC entities with RB identities larger than 4 and set the first 20 bits of all the HFN component of the respective COUNT-C values to the START value included in the response message for the corresponding CN domain;
- 3> re-establish the RLC entities with RB identities 1, 3 and 4 and set the first 20 bits of all the HFN component of the respective COUNT-C values to the START value included in the response message for the CN domain stored in the variable LATEST_CONFIGURED_CN_DOMAIN;
- 3> set the remaining bits of the HFN component of the COUNT-C values of all UM RLC entities to zero;
- 3> if the IE "PDCP context relocation info" is not present:
 - > re-initialise the PDCP header compression entities of each radio bearer in the variable ESTABLISHED_RABS as specified in [36].
- 3> if the IE "PDCP context relocation info" is present:
 - 4> perform the actions as specified in subclause 8.6.4.13.
 - 1> if the variable PDCP_SN_INFO is empty:
 - 2> if the CELL UPDATE CONFIRM or URA UPDATE CONFIRM message contained the IE "Ciphering mode info":
- 3> when RLC has confirmed the successful transmission of the response message:
 - 4> continue with the remainder of the procedure.
 - 2> if the CELL UPDATE CONFIRM or URA UPDATE CONFIRM message did not contain the IE "Ciphering mode info":
- 3> when RLC has been requested to transmit the response message,
 - 4> continue with the remainder of the procedure.
 - 1> if the variable PDCP_SN_INFO is non-empty:
 - 2> when RLC has confirmed the successful transmission of the response message:
- 3> for each radio bearer in the variable PDCP_SN_INFO:
 - 4> if the IE "RB started" in the variable ESTABLISHED_RABS is set to "started":
 - 5> configure the RLC entity for that radio bearer to "continue".
- 3> continue with the remainder of the procedure.

If the new state is CELL_PCH or URA_PCH, the response message shall be transmitted in CELL_FACH state, and the UE shall:

- 1> when RLC has confirmed the successful transmission of the response message:
 - 2> if the IE "Downlink counter synchronisation info" was included in the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message:

- 3> re-establish all AM and UM RLC entities with RB identities larger than 4 and set the first 20 bits of all the HFN component of the respective COUNT-C values to the START value included in the response message for the corresponding CN domain;
- 3> re-establish the RLC entities with RB identities 1, 3 and 4 and set the first 20 bits of all the HFN component of the respective COUNT-C values to the START value included in the response message for the CN domain stored in the variable LATEST_CONFIGURED_CN_DOMAIN;
- 3> set the remaining bits of the HFN component of the COUNT-C values of all UM RLC entities to zero;
- 3> re-initialise the PDCP header compression entities of each radio bearer in the variable ESTABLISHED_RABS as specified in [36].
 - 2> for each radio bearer in the variable PDCP_SN_INFO:
- 3> if the IE "RB started" in the variable ESTABLISHED RABS is set to "started":
 - 4> configure the RLC entity for that radio bearer to "continue".
 - 2> enter the new state (CELL_PCH or URA_PCH, respectively).
 - 1> continue with the remainder of the procedure.

8.3.1.7a Physical channel failure

If the received CELL UPDATE CONFIRM message would cause the UE to transit to CELL_DCH state:

- 1> if the UE failed to establish the physical channel(s) indicated in the received CELL UPDATE CONFIRM message according to the criteria defined in subclause 8.5.4 are not fulfilled; or
- 1> the received CELL UPDATE CONFIRM message does not contain dedicated physical channels:

the UE shall:

- 1> if, caused by the received CELL UPDATE CONFIRM message
 - 2> the IE "Reconfiguration" in the variable CIPHERING_STATUS is set to TRUE; and/or
 - 2> the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO is set to TRUE:
- 3> abort the ongoing integrity and/or ciphering reconfiguration;
- 3> if the received CELL UPDATE CONFIRM message contained the IE "Ciphering mode info":
 - 4> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE; and
 - 4> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO.
- 3> if the received CELL UPDATE CONFIRM message contained the IE "Integrity protection mode info":
 - 4> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to FALSE; and
 - 4> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.
 - 1> if the variable ORDERED_RECONFIGURATION is set to TRUE caused by the received CELL UPDATE CONFIRM message:
 - 2> set the variable ORDERED_RECONFIGURATION to FALSE.
 - 1> if V302 is equal to or smaller than N302:
 - 2> select a suitable UTRA cell according to [4];
 - 2> set the contents of the CELL UPDATE message according to subclause 8.3.1.3, except for the IE "Cell update cause" which shall be set to "Radio link failure";
 - 2> submit the CELL UPDATE message for transmission on the uplink CCCH;

- 2> increment counter V302;
- 2> restart timer T302 when the MAC layer indicates success or failure to transmit the message.
- 1> if V302 is greater than N302:
 - 2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;
 - 2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO;
 - 2> in case of a cell update procedure:
- 3> clear the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.
 - 2> release all its radio resources;
 - 2> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;
 - 2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
 - 2> clear the variable ESTABLISHED_RABS;
 - 2> set the variable CELL_UPDATE_STARTED to FALSE;
 - 2> enter idle mode.

8.3.1.8 Unsupported configuration by the UE

If the UE does not support the configuration in the CELL UPDATE CONFIRM message and/or the variable UNSUPPORTED_CONFIGURATION is set to TRUE, the UE shall:

- 1> if V302 is equal to or smaller than N302, the UE shall:
 - 2> if, caused by the received CELL UPDATE CONFIRM message
- 3> the IE "Reconfiguration" in the variable CIPHERING_STATUS is set to TRUE; and/or
- 3> the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO is set to TRUE:
 - 4> abort the ongoing integrity and/or ciphering reconfiguration;
 - 4> if the received CELL UPDATE CONFIRM message contained the IE "Ciphering mode info":
 - 5> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE; and
 - 5> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO.
 - 4> if the received CELL UPDATE CONFIRM message contained the IE "Integrity protection mode info":
 - 5> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to FALSE; and
 - 5> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.
 - 2> if the variable ORDERED_RECONFIGURATION is set to TRUE due to the received CELL UPDATE CONFIRM message in case of a cell update procedure:
- 3> set the variable ORDERED RECONFIGURATION to FALSE.
 - 2> set the variable FAILURE_INDICATOR to TRUE;
 - 2> set the variable FAILURE_CAUSE to "Unsupported configuration";
 - 2> set the content of the CELL UPDATE message according to subclause 8.3.1.3;

- 2> submit the CELL UPDATE message for transmission on the uplink CCCH;
- 2> increment counter V302;
- 2> restart timer T302 when the MAC layer indicates success or failure to transmit the message.
- 1> if V302 is greater than N302, the UE shall:
 - 2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;
 - 2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO;
 - 2> clear the variable PDCP_SN_INFO;
 - 2> clear the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS;
 - 2> release all its radio resources;
 - 2> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;
 - 2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
 - 2> clear the variable ESTABLISHED RABS;
 - 2> set the variable CELL_UPDATE_STARTED to FALSE;
 - 2> enter idle mode;
 - 2> Other actions the UE shall perform when entering idle mode from connected mode are specified in subclause 8.5.2;
 - 2> and the procedure ends.

8.3.1.9 Invalid configuration

If the variable INVALID_CONFIGURATION is set to TRUE, the UE shall:

- 1> if V302 is equal to or smaller than N302:
 - 2> if, caused by the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message
- 3> the IE "Reconfiguration" in the variable CIPHERING_STATUS is set to TRUE; and/or
- 3> the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO is set to TRUE:
 - 4> abort the ongoing integrity and/or ciphering reconfiguration;
 - 4> if the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message contained the IE "Ciphering mode info":
 - 5> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE; and
 - 5> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO.
 - 4> if the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message contained the IE "Integrity protection mode info";
 - 5> set the IE "Reconfiguration" in the variable INTEGRITY PROTECTION INFO to FALSE; and
 - 5> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.
 - 2> if the variable ORDERED_RECONFIGURATION is set to TRUE caused by the received CELL UPDATE CONFIRM message in case of a cell update procedure:

- 3> set the variable ORDERED_RECONFIGURATION to FALSE.
 - 2> in case of a cell update procedure:
- 3> set the variable FAILURE INDICATOR to TRUE;
- 3> set the variable FAILURE_CAUSE to "Invalid configuration";
- 3> set the contents of the CELL UPDATE message according to subclause 8.3.1.3;
- 3> submit the CELL UPDATE message for transmission on the uplink CCCH.
 - 2> in case of a URA update procedure:
- 3> set the contents of the URA UPDATE message according to subclause 8.3.1.3;
- 3> submit the URA UPDATE message for transmission on the uplink CCCH.
 - 2> increment counter V302;
 - 2> restart timer T302 when the MAC layer indicates success or failure to transmit the message.
 - 1> if V302 is greater than N302:
 - 2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;
 - 2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO;
 - 2> clear the variable PDCP_SN_INFO;
 - 2> clear the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS;
 - 2> release all its radio resources;
 - 2> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;
 - 2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
 - 2> clear the variable ESTABLISHED_RABS;
 - 2> set the variable CELL_UPDATE_STARTED to FALSE;
 - 2> enter idle mode;
 - 2> Other actions the UE shall perform when entering idle mode from connected mode are specified in subclause 8.5.2;
 - 2> the procedure ends.

8.3.1.9a Incompatible simultaneous reconfiguration

In case of a cell update procedure and if the received CELL UPDATE CONFIRM message

- includes "RB information elements"; and/or
- includes "Transport channel information elements"; and/or
- includes "Physical channel information elements"; and
- the variable ORDERED_RECONFIGURATION is set to TRUE because of an ongoing Reconfiguration procedure;

or

If the variable INCOMPATIBLE_SECURITY_RECONFIGURATION is set to TRUE due to the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message:

the UE shall:

- 1> if V302 is equal to or smaller than N302:
 - 2> if, caused by the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message
- 3> the IE "Reconfiguration" in the variable CIPHERING_STATUS is set to TRUE; and/or
- 3> the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO is set to TRUE:
 - 4> abort the ongoing integrity and/or ciphering reconfiguration;
 - 4> if the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message contained the IE "Ciphering mode info":
 - 5> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE; and
 - 5> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO.
 - 4> if the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message contained the IE "Integrity protection mode info":
 - 5> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to FALSE; and
 - 5> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.
 - 2> if the variable ORDERED_RECONFIGURATION is set to TRUE due to the received CELL UPDATE CONFIRM message in case of a cell update procedure:
- 3> set the variable ORDERED_RECONFIGURATION to FALSE.
 - 2> set the variable FAILURE_INDICATOR to TRUE;
 - 2> set the variable FAILURE_CAUSE to "Incompatible simultaneous reconfiguration";
 - 2> set the content of the CELL UPDATE message according to subclause 8.3.1.3;
 - 2> submit the CELL UPDATE message for transmission on the uplink CCCH;
 - 2> increment counter V302;
 - 2> restart timer T302 when the MAC layer indicates success or failure to transmit the message.
 - 1> if V302 is greater than N302:
 - 2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;
 - 2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO;
 - 2> clear the variable PDCP_SN_INFO;
 - 2> set the variable INCOMPATIBLE_SECURITY_RECONFIGURATION to FALSE;
 - 2> clear the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS;
 - 2> release all its radio resources;
 - 2> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;
 - 2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
 - 2> clear the variable ESTABLISHED_RABS;

- 2> set the variable CELL_UPDATE_STARTED to FALSE;
- 2> enter idle mode;
- 2> Other actions the UE shall perform when entering idle mode from connected mode are specified in subclause 8.5.2;
- 2> the procedure ends.

8.3.1.9b Security reconfiguration during Cell update procedure

If:

- the variable CELL_UPDATE_STARTED is set to TRUE; and
- the UE receives a SECURITY MODE COMMAND message:

the UE shall

1> ignore the received SECURITY MODE COMMAND and continue with any ongoing processes and procedures as if the SECURITY MODE COMMAND message has not been received.

8.3.1.10 Confirmation error of URA ID list

If the URA UPDATE CONFIRM message causes a confirmation error of URA identity list as specified in subclause 8.6.2.1 the UE shall:

- 1> check the value of V302; and
- 1> if V302 is smaller or equal than N302:
 - 2> if, caused by the received URA UPDATE CONFIRM message
- 3> the IE "Reconfiguration" in the variable CIPHERING_STATUS is set to TRUE; and/or
- 3> the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO is set to TRUE:
 - 4> abort the ongoing integrity and/or ciphering reconfiguration;
 - 4> if the received URA UPDATE CONFIRM message contained the IE "Ciphering mode info":
 - 5> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE; and
 - 5> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO.
 - 4> if the received URA UPDATE CONFIRM message contained the IE "Integrity protection mode info"
 - 5> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to FALSE; and
 - 5> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.
 - 2> set the IEs in the URA UPDATE message according to subclause 8.3.1.3;
 - 2> submit the URA UPDATE message for transmission on the uplink CCCH;
 - 2> increment counter V302;
 - 2> restart timer T302 when the MAC layer indicates success or failure to transmit the message.
 - 1> if V302 is greater than N302:
 - 2> release all its radio resources;
 - 2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;
 - 2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO;

- 2> clear the variable PDCP_SN_INFO;
- 2> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;
- 2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
- 2> clear the variable ESTABLISHED_RABS;
- 2> set the variable CELL_UPDATE_STARTED to FALSE;
- 2> enter idle mode;
- 2> perform the actions specified in subclause 8.5.2 when entering idle mode from connected mode;
- 2> the procedure ends.

8.3.1.11 Invalid CELL UPDATE CONFIRM/URA UPDATE CONFIRM message

If the UE receives an CELL UPDATE CONFIRM/URA UPDATE CONFIRM message, which contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows:

- 1> If V302 is equal to or smaller than N302, the UE shall:
 - 2> set the variable PROTOCOL_ERROR_INDICATOR to TRUE;
 - 2> in case of a cell update procedure:
- 3> set the contents of the CELL UPDATE message according to subclause 8.3.1.3;
- 3> submit the CELL UPDATE message for transmission on the uplink CCCH.
 - 2> in case of a URA update procedure:
- 3> set the contents of the URA UPDATE message according to subclause 8.3.1.3;
- 3> submit the URA UPDATE message for transmission on the uplink CCCH.
 - 2> increment counter V302;
 - 2> restart timer T302 when the MAC layer indicates success or failure to transmit the message.
 - 1> if V302 is greater than N302, the UE shall:
 - 2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;
 - 2> in case of a cell update procedure:
- 3> clear the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.
 - 2> in case of a URA update procedure:
- 3> clear the entry for the URA UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.
 - 2> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;
 - 2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
 - 2> clear the variable ESTABLISHED RABS;
 - 2> set the variable CELL_UPDATE_STARTED to FALSE;

- 2> release all its radio resources;
- 2> enter idle mode;
- 2> Other actions the UE shall perform when entering idle mode from connected mode are specified in subclause 8.5.2;
- 2> the procedure ends.

8.3.1.12 T302 expiry or cell reselection

If any or several of the following conditions are true:

- expiry of timer T302;
- reselection to another UTRA cell (including the previously serving cell) before completion of the cell update or URA update procedure;

the UE shall:

- 1> stop T302 if it is running;
- 1> if the UE was in CELL_DCH state prior to the initiation of the procedure; and
 - 2> if timers T314 and T315 have elapsed while T302 was running:
- 3> enter idle mode.
- 3> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers. Other actions the UE shall perform when entering idle mode from connected mode are specified in subclause 8.5.2.
- 3> and the procedure ends.
 - 2> if timer T314 has elapsed while T302 was running and,
- 3> if "T314 expired" in the variable RB_TIMER_INDICATOR is set to FALSE and
- 3> if T315 is still running:
 - 4> release locally all radio bearers which are associated with any radio access bearers for which in the variable ESTABLISHED_RABS the value of the IE "Re-establishment timer" is set to "useT314";
 - 4> indicate release of those radio access bearers to upper layers;
 - 4> delete all information about those radio access bearers from the variable ESTABLISHED_RABS;
 - 4> set "T314 expired" in the variable RB_TIMER_INDICATOR to TRUE.
 - 2> if timer T315 has elapsed while T302 was running and,
- 3> if "T315 expired" in the variable RB_TIMER_INDICATOR is set to FALSE and,
- 3> if T314 is still running:
 - 4> release locally all radio bearers which are associated with any radio access bearers for which in the variable ESTABLISHED_RABS the value of the IE "Re-establishment timer" is set to "useT315";
 - 4> indicate release of those radio access bearers to upper layers;
 - 4> delete all information about those radio access bearers from the variable ESTABLISHED RABS;
 - 4> set "T315 expired" in the variable RB_TIMER_INDICATOR to TRUE.
 - 1> check whether it is still in "in service area" (see subclause 8.5.5.2);

- 1> if the variable ORDERED_RECONFIGURATION is set to TRUE caused by the received CELL UPDATE CONFIRM message in case of a cell update procedure:
 - 2> set the variable ORDERED_RECONFIGURATION to FALSE.
- 1> in case of a cell update procedure:
 - 2> clear any entry for the CELL UPDATE CONFIRM message in the table "Accepted transactions" in the variable TRANSACTIONS.
- 1> in case of a URA update procedure:
 - 2> clear any entry for the URA UPDATE CONFIRM message in the table "Accepted transactions" in the variable TRANSACTIONS.

If the UE detects "in service area" if it has not entered idle mode, and:

- 1> if V302 is equal to or smaller than N302, the UE shall:
 - 2> if the UE performed cell re-selection:
- 3> delete its C-RNTI.
 - 2> in case of a cell update procedure:
- 3> set the contents of the CELL UPDATE message according to subclauses 8.3.1.3 and 8.5.10;
- 3> if a CELL UPDATE CONFIRM message was received and caused the IE "Reconfiguration" in the variable CIPHERING_STATUS to be set to TRUE and/or the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to be set to TRUE:
 - 4> if the IE "Downlink counter synchronisation info" was included in the received CELL UPDATE CONFIRM message:
 - 5> apply the new security (integrity protection) configuration received in the CELL UPDATE CONFIRM on the CELL UPDATE message.
- 3> submit the CELL UPDATE message for transmission on the uplink CCCH.
 - 2> in case of a URA update procedure:
- 3> set the contents of the URA UPDATE message according to subclauses 8.3.1.3 and 8.5.10;
- 3> if a URA UPDATE CONFIRM message was received and caused the IE "Reconfiguration" in the variable CIPHERING_STATUS to be set to TRUE and/or the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO is set to TRUE:
 - 4> if the IE "Downlink counter synchronisation info" was included in the received URA UPDATE CONFIRM message:
 - 5> apply the new security (integrity protection) configuration received in the URA UPDATE CONFIRM on the URA UPDATE message.
- 3> submit the URA UPDATE message for transmission on the uplink CCCH.
 - 2> increment counter V302;
 - 2> restart timer T302 when the MAC layer indicates success or failure to transmit the message.
 - 1> if V302 is greater than N302, the UE shall:
 - 2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;
 - 2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO;
 - 2> clear the variable PDCP_SN_INFO;

- 2> in case of a cell update procedure:
- 3> clear the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.
 - 2> in case of a URA update procedure:
- 3> clear the entry for the URA UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.
 - 2> release all its radio resources;
 - 2> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;
 - 2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
 - 2> clear the variable ESTABLISHED_RABS;
 - 2> set the variable CELL_UPDATE_STARTED to FALSE;
 - 2> enter idle mode;
 - 2> other actions the UE shall perform when entering idle mode from connected mode are specified in subclause 8.5.2;
 - 2> and the procedure ends.

If the UE detects "out of service area", it shall:

1> act according to subclause 7.2.2.

8.3.1.13 T314 expiry

Upon expiry of timer T314 the UE shall:

- 1> if timer T302 is running:
 - 2> continue awaiting response message from UTRAN.
- 1> if timer T302 is not running and timer T315 is running:
 - 2> set IE "T314 expired" in variable RB_TIMER_INDICATOR to TRUE;
 - 2> release locally all radio bearers which are associated with any radio access bearers for which in the variable ESTABLISHED_RABS the value of the IE "Re-establishment timer" is set to "useT314";
 - 2> indicate release of those radio access bearers to upper layers;
 - 2> delete all information about those radio access bearers from the variable ESTABLISHED_RABS.
- 1> if timers T302 and T315 are not running:
 - 2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;
 - 2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO;
 - 2> clear the variable PDCP_SN_INFO;
 - 2> clear the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS;
 - 2> release all its radio resources;

- 2> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;
- 2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
- 2> clear the variable ESTABLISHED_RABS;
- 2> set the variable CELL_UPDATE_STARTED to FALSE;
- 2> enter idle mode;
- 2> other actions the UE shall perform when entering idle mode from connected mode are specified in subclause 8.5.2;
- 2> and the procedure ends.

8.3.1.14 T315 expiry

Upon expiry of timer T315 the UE shall:

- 1> if timer T302 is running:
 - 2> continue awaiting response message from UTRAN.
- 1> if timer T302 is not running and timer T314 is running:
 - 2> set IE "T315 expired" in variable RB_TIMER_INDICATOR to TRUE;
 - 2> release locally all radio bearers which are associated with any radio access bearers for which in the variable ESTABLISHED_RABS the value of the IE "Re-establishment timer" is set to "use T315";
 - 2> indicate release of those radio access bearers to upper layers;
 - 2> delete all information about those radio access bearers from the variable ESTABLISHED_RABS.
- 1> if timers T302 and T314 are not running:
 - 2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;
 - 2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO;
 - 2> clear the variable PDCP_SN_INFO;
 - 2> clear the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS;
 - 2> release all its radio resources;
 - 2> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;
 - 2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
 - 2> clear the variable ESTABLISHED_RABS;
 - 2> set the variable CELL_UPDATE_STARTED to FALSE;
 - 2> enter idle mode;
 - 2> other actions the UE shall perform when entering idle mode from connected mode are specified in subclause 8.5.2;
 - 2> and the procedure ends.

8.3.1.15 Reception of the UTRAN MOBILITY INFORMATION CONFIRM message by the UTRAN

See subclause 8.3.3.4.

8.3.2 URA update

See subclause 8.3.1.

8.3.3 UTRAN mobility information




Figure 8.3.3-1: UTRAN mobility information procedure, normal flow




Figure 8.3.3-2: UTRAN mobility information procedure, failure case

8.3.3.1 General

The purpose of this procedure is to allocate any one or a combination of the following to a UE in connected mode:

- a new C-RNTI;
- a new U-RNTI;
- other mobility related information.

8.3.3.2 Initiation

To initiate the procedure UTRAN transmits a UTRAN MOBILITY INFORMATION message to the UE on the downlink DCCH using AM or UM RLC. In case of SRNS relocation, the message is sent using UM RLC only.

8.3.3.3 Reception of UTRAN MOBILITY INFORMATION message by the UE

When the UE receives a UTRAN MOBILITY INFORMATION message, it shall:

- 1> act on received information elements as specified in subclause 8.6;
- 1> if the IE "UE Timers and constants in connected mode" is present:
 - 2> store the values of the IE "UE Timers and constants in connected mode" in the variable TIMERS_AND_CONSTANTS, replacing any previously stored value for each timer and constant; and

- 2> for each updated timer value:
- 3> start using the new value next time the timer is started;
 - NOTE: If a new value of timer T305 is included in the IE "UE Timers and constants in connected mode", and the old value of timer T305 is "infinity", the UE will not use the new value of the timer T305 until the next cell reselection.
 - 2> for each updated constant value:
- 3> start using the new value directly;
 - 1> if the IE "CN domain specific DRX cycle length coefficient" is present:
 - 2> store the value of the IE "CN domain specific DRX cycle length coefficient" for that CN domain, replacing any previously stored value; and
 - 2> use the value to determine the connected mode paging occasions according to [4].
 - 1> set the IE "RRC transaction identifier" in the UTRAN MOBILITY INFORMATION CONFIRM message to the value of "RRC transaction identifier" in the entry for the UTRAN MOBILITY INFORMATION message in the table "Accepted transactions" in the variable TRANSACTIONS; and
 - 1> clear that entry;
 - 1> if the UTRAN MOBILITY INFORMATION message contained the IE "Ciphering mode info" or contained the IE "Integrity protection mode info":
 - 2> set the IE "Status" in the variable SECURITY_MODIFICATION for all the CN domains in the variable SECURITY_MODIFICATION to "Affected";
 - 1> if the UTRAN MOBILITY INFORMATION message contained the IE "Ciphering mode info":
 - 2> include and set the IE "Radio bearer uplink ciphering activation time info" to the value of the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO.
 - 1> if the variable PDCP_SN_INFO is non-empty:
 - 2> include the IE "RB with PDCP information list" in the UTRAN MOBILITY INFORMATION CONFIRM message and set it to the value of the variable PDCP_SN_INFO.
 - 1> if the received UTRAN MOBILITY INFORMATION message included the IE "Downlink counter synchronisation info":
 - 2> if the variable PDCP_SN_INFO is empty:
- 3> configure the corresponding RLC entity for all AM and UM radio bearers and AM and UM signalling radio bearers except RB2 to "stop".
 - 2> else:
- 3> configure the RLC entity for signalling radio bearers RB1, RB3 and RB4 to "stop";
- 3> configure the RLC entity for UM and AM radio bearers for which the IE "PDCP SN Info" is not included to "stop".
 - 2> re-establish the RLC entity for RB2;
 - 2> for the downlink and the uplink, apply the ciphering configuration as follows:
- 3> if the received re-configuation message included the IE "Ciphering Mode Info":
 - 4> use the ciphering configuration in the received message when transmitting the response message.
- 3> if the ciphering configuration for RB2 from a previously received SECURITY MODE COMMAND has not yet been applied because the activation times not having been reached:
 - 4> if the previous SECURITY MODE COMMAND was received due to new keys being received:

- 5> consider the new ciphering configuration to include the received new keys;
- 5> initialise the HFN component of the uplink COUNT-C and downlink COUNT-C of SRB2 as indicated in subclause 8.1.12.3.1.
- 4> if the ciphering configuration for RB2 from a previously received SECURITY MODE COMMAND has not yet been applied because of the corresponding activation times not having been reached and the previous SECURITY MODE COMMAND caused a change in LATEST_CONFIGURED_CN_DOMAIN:
 - 5> consider the new ciphering configuration to include the keys associated with the LATEST CONFIGURED CN DOMAIN;
 - 5> initialise the HFN component of the uplink COUNT-C and downlink COUNT-C of SRB2 to the most recently transmitted IE "START list" or IE "START" for the LATEST_CONFIGURED_CN_DOMAIN at the reception of the previous SECURITY MODE COMMAND.
- 4> apply the new ciphering configuration immediately following RLC re-establishment.

3> else:

- 4> continue using the current ciphering configuration.
- 2> set the new uplink and downlink HFN component of COUNT-C of RB2 to MAX(uplink HFN component of COUNT-C of RB2);
- 2> increment by one the downlink and uplink values of the HFN component of COUNT-C for RB2;
- 2> calculate the START value according to subclause 8.5.9;
- 2> include the calculated START values for each CN domain in the IE "START list" in the IE "Uplink counter synchronisation info" in the UTRAN MOBILITY INFORMATION CONFIRM message.
- 1> transmit a UTRAN MOBILITY INFORMATION CONFIRM message on the uplink DCCH using AM RLC;
- 1> if the IE "Integrity protection mode info" was present in the UTRAN MOBILITY INFORMATION message:
 - 2> start applying the new integrity protection configuration in the uplink for signalling radio bearer RB2 from and including the transmitted UTRAN MOBILITY INFORMATION CONFIRM message.
- 1> if the IE "Downlink counter synchronisation info" was included in the received UTRAN MOBILITY INFORMATION message:
 - 2> when RLC has confirmed the successful transmission of the response message:
- 3> if the variable PDCP_SN_INFO is empty:
 - 4> configure the RLC entity for all AM and UM radio bearers and AM and UM signalling radio bearers except RB2 to "continue".

3> else:

- 4> configure the RLC entity for signalling radio bearers RB1, RB3 and RB4 to "continue";
- 4> configure the RLC entity for UM and AM radio bearers for which the IE "PDCP SN Info" is not included to "continue".
- 3> re-establish all AM and UM RLC entities with RB identities larger than 4 and set the first 20 bits of all the HFN component of the respective COUNT-C values to the START value included in the response message for the corresponding CN domain;
- 3> re-establish the RLC entities with RB identities 1, 3 and 4 and set the first 20 bits of all the HFN component of the respective COUNT-C values to the START value included in the response message for the CN domain stored in the variable LATEST_CONFIGURED_CN_DOMAIN;
- 3> set the remaining bits of the HFN component of the COUNT-C values of all UM RLC entities to zero;

- 3> if the IE "PDCP context relocation info" is not present:
 - 4> re-initialise the PDCP header compression entities of each radio bearer in the variable ESTABLISHED_RABS as specified in [36].
- 3> if the IE "PDCP context relocation info" is present:
 - 4> perform the actions as specified in subclause 8.6.4.13.
 - 1> if the variable PDCP_SN_INFO is empty; and
 - 2> if the UTRAN MOBILITY INFORMATION message contained the IE "Ciphering mode info":
- 3> when RLC has confirmed the successful transmission of the UTRAN MOBILITY INFORMATION CONFIRM message:
 - 4> perform the actions below:
 - 2> if the UTRAN MOBILITY INFORMATION message did not contain the IE "Ciphering mode info":
- 3> when RLC has been requested to transmit the UTRAN MOBILITY INFORMATION CONFIRM message:
 - 4> perform the actions below.
 - 1> if the variable PDCP_SN_INFO is non-empty:
 - 2> when RLC has confirmed the successful transmission of the UTRAN MOBILITY INFORMATION CONFIRM message:
- 3> for each radio bearer in the variable PDCP_SN_INFO:
 - 4> if the IE "RB started" in the variable ESTABLISHED_RABS is set to "started":
 - 5> configure the RLC entity for that radio bearer to "continue".
- 3> clear the variable PDCP_SN_INFO; and
- 3> perform the actions below.

The UE shall:

- 1> if the UTRAN MOBILITY INFORMATION message contained the IE "Ciphering mode info":
 - 2> resume data transmission on any suspended radio bearer and signalling radio bearer mapped on RLC-AM or RLC-UM;
 - 2> set the IE "Reconfiguration" in the variable CIPHERING STATUS to FALSE; and
 - 2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO.
- 1> if the UTRAN MOBILITY INFORMATION message contained the IE "Integrity protection mode info":
 - 2> allow the transmission of RRC messages on all signalling radio bearers with any RRC SN;
 - 2> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to FALSE; and
 - 2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.
- 1> clear the variable SECURITY_MODIFICATION.

The procedure ends.

8.3.3.4 Reception of an UTRAN MOBILITY INFORMATION CONFIRM message by the UTRAN

When the network receives UTRAN MOBILITY INFORMATION CONFIRM message, UTRAN may delete any old U-RNTI. The procedure ends.

8.3.3.5 Cell re-selection

If the UE performs cell re-selection, the UE shall:

- 1> initiate a cell update procedure according to subclause 8.3.1;
- 1> if the UTRAN MOBILITY INFORMATION message contains the IE "New C-RNTI"; and
- 1> if the UE has not yet submitted the UTRAN MOBILITY INFORMATION CONFIRM message to lower layers for transmission; and
- 1> if the IE "Downlink counter synchronisation info" was not included in the received UTRAN MOBILITY INFORMATION message:
 - 2> transmit a UTRAN MOBILITY INFORMATION FAILURE message on the uplink DCCH using AM RLC;
 - 2> set the IE "RRC transaction identifier" in the UTRAN MOBILITY INFORMATION FAILURE message to the value of "RRC transaction identifier" in the entry for the UTRAN MOBILITY INFORMATION message in the table "Accepted transactions" in the variable TRANSACTIONS; and
 - 2> clear that entry.
 - 2> set the IE "failure cause" to the cause value "cell update occurred";
 - 2> when the UTRAN MOBILITY INFORMATION FAILURE message has been submitted to lower layers for transmission:

3> continue with any ongoing processes and procedures as if the invalid UTRAN MOBILITY INFORMATION message has not been received and the procedure ends.

- 1> otherwise:
 - 2> if a UTRAN MOBILITY INFORMATION message was received and caused the IE "Reconfiguration" in the variable CIPHERING_STATUS to be set to TRUE and/or the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to be set to TRUE; and
 - 2> if the IE "Downlink counter synchronisation info" was included in the received UTRAN MOBILITY INFORMATION message:

3> apply the new security (integrity protection) configuration received in the UTRAN MOBILITY INFORMATION message on the CELL UPDATE message to be transmitted.

2> continue the procedure normally.

8.3.3.5a Incompatible simultaneous security reconfiguration

If the variable INCOMPATIBLE_SECURITY_RECONFIGURATION becomes set to TRUE of the received UTRAN MOBILITY INFORMATION message, the UE shall:

- 1> transmit a UTRAN MOBILITY INFORMATION FAILURE message on the uplink DCCH using AM RLC;
- 1> set the IE "RRC transaction identifier" in the UTRAN MOBILITY INFORMATION FAILURE message to the value of "RRC transaction identifier" in the entry for the UTRAN MOBILITY INFORMATION message in the table "Accepted transactions" in the variable TRANSACTIONS; and
- 1> clear that entry;
- 1> set the IE "failure cause" to the cause value "incompatible simultaneous reconfiguration";
- 1> when the UTRAN MOBILITY INFORMATION FAILURE message has been delivered to lower layers for transmission:
 - 2> set the variable INCOMPATIBLE_SECURITY_RECONFIGURATION to FALSE;
 - 2> continue with any ongoing processes and procedures as if the UTRAN MOBILITY INFORMATION message has not been received;

2> and the procedure ends.

8.3.3.6 Invalid UTRAN MOBILITY INFORMATION message

If the UTRAN MOBILITY INFORMATION message contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

- 1> transmit a UTRAN MOBILITY INFORMATION FAILURE message on the uplink DCCH using AM RLC;
- 1> set the IE "RRC transaction identifier" in the UTRAN MOBILITY INFORMATION FAILURE message to the value of "RRC transaction identifier" in the entry for the UTRAN MOBILITY INFORMATION message in the table "Rejected transactions" in the variable TRANSACTIONS, and;
- 1> clear that entry.
- 1> set the IE "failure cause" to the cause value "protocol error";
- 1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION;
- 1> when the UTRAN MOBILITY INFORMATION FAILURE message has been submitted to lower layers for transmission:
 - 2> continue with any ongoing processes and procedures as if the invalid UTRAN MOBILITY INFORMATION message has not been received;
 - 2> and the procedure ends.

8.3.4 Active set update




Figure 8.3.4-1: Active Set Update procedure, successful case




Figure 8.3.4-2: Active Set Update procedure, failure case

8.3.4.1 General

The purpose of the active set update procedure is to update the active set of the connection between the UE and UTRAN. This procedure shall be used in CELL_DCH state. The UE should keep on using the old RLs while configuring the new RLs. Also the UE should keep the transmitter turned on during the procedure. This procedure is only used in FDD mode.

8.3.4.2 Initiation

The procedure is initiated when UTRAN orders a UE in CELL_DCH state, to make the following modifications of the active set of the connection:

- a) Radio link addition;
- b) Radio link removal:
- c) Combined radio link addition and removal.

In case a) and c), UTRAN should:

1> prepare new additional radio link(s) in the UTRAN prior to the command to the UE.

In all cases, UTRAN should:

- 1> send an ACTIVE SET UPDATE message on downlink DCCH using AM or UM RLC;
- 1> create active sets that contain at least one common radio link across a DPCH frame boundary as the result of one or multiple (parallel) active set update procedures.

UTRAN should include the following information:

- 1> IE "Radio Link Addition Information": Downlink DPCH information and other optional parameters relevant for the radio links to be added along with the IE "Primary CPICH info" used for the reference ID to indicate which radio link to add. This IE is needed in cases a) and c) listed above;
- 1> IE "Radio Link Removal Information": IE "Primary CPICH info" used for the reference ID to indicate which radio link to remove. This IE is needed in cases b) and c) listed above.

8.3.4.3 Reception of an ACTIVE SET UPDATE message by the UE

Upon reception of an ACTIVE SET UPDATE message the UE shall act upon all received information elements as specified in 8.6, unless specified otherwise in the following.

The UE may:

1> maintain a list of the set of cells to which the UE has Radio Links if the IE "Cell ID" is present.

The UE shall:

- 1> first add the RLs indicated in the IE "Radio Link Addition Information";
- 1> remove the RLs indicated in the IE "Radio Link Removal Information". If the UE active set is full or becomes full, an RL, which is included in the IE "Radio Link Removal Information" for removal, shall be removed before adding RL, which is included in the IE "Radio Link Addition Information" for addition;
- 1> perform the physical layer synchronisation procedure B as specified in [29];
- 1> if the IE "TFCI combining indicator" associated with a radio link to be added is set to TRUE:
 - 2> if a DSCH transport channel is assigned and there is a 'hard' split in the TFCI field:
- 3> configure Layer 1 to soft-combine TFCI (field 2) of this new link with those links already in the TFCI (field 2) combining set.
 - 1> set the IE "RRC transaction identifier" in the ACTIVE SET UPDATE COMPLETE message to the value of "RRC transaction identifier" in the entry for the ACTIVE SET UPDATE message in the table "Accepted transactions" in the variable TRANSACTIONS; and
 - 1> clear that entry;
 - 1> transmit an ACTIVE SET UPDATE COMPLETE message on the uplink DCCH using AM RLC without waiting for the completion of the Physical Layer synchronisation B, as specified in [29];
 - 1> the procedure ends on the UE side.

8.3.4.4 Unsupported configuration in the UE

If UTRAN instructs the UE to use a configuration that it does not support, the UE shall:

- 1> keep the active set as it was before the ACTIVE SET UPDATE message was received;
- 1> transmit an ACTIVE SET UPDATE FAILURE message on the DCCH using AM RLC;
- 1> set the IE "RRC transaction identifier" in the ACTIVE SET UPDATE FAILURE message to the value of "RRC transaction identifier" in the entry for the ACTIVE SET UPDATE message in the table "Accepted transactions" in the variable TRANSACTIONS; and
- 1> clear that entry;
- 1> set the IE "failure cause" to "configuration unsupported";
- 1> when the ACTIVE SET UPDATE FAILURE message has been submitted to lower layers for transmission:
 - 2> the procedure ends on the UE side.

8.3.4.5 Invalid configuration

If any of the following conditions are valid:

- a radio link indicated by the IE "Downlink DPCH info for each RL" in the IE "Radio link addition information" has a different spreading factor than the spreading factor for the radio links in the active set that will be established at the time indicated by the IE "Activation time"; and/or
- a radio link in the IE "Radio link addition information" is also present in the IE "Radio Link Removal Information"; and/or
- the IE "Radio Link Removal Information" contains all the radio links which are part of or will be part of the active set at the time indicated by the IE "Activation time"; and/or
- the IE "TX Diversity Mode" is not set to "none" and it indicates a diversity mode that is different from the one currently used (<STTD>, <closed loop mode1>, or <closed loop mode2>) in all or part of the active set; and/or
- a radio link indicated by the IE "Radio Link Removal Information" does not exist in the active set; and/or
- after the removal of all radio links indicated by the IE "Radio Link Removal Information" and the addition of all radio links indicated by the IE "Radio Link Addition Information" the active set would contain more than the maximum allowed number of radio links; and/or
- the variable INVALID_CONFIGURATION is set to TRUE:

the UE shall:

- 1> keep the active set as it was before the ACTIVE SET UPDATE message was received;
- 1> transmit an ACTIVE SET UPDATE FAILURE message on the DCCH using AM RLC;
- 1> set the IE "RRC transaction identifier" in the ACTIVE SET UPDATE FAILURE message to the value of "RRC transaction identifier" in the entry for the ACTIVE SET UPDATE message in the table "Accepted transactions" in the variable TRANSACTIONS; and
- 1> clear that entry;
- 1> set the IE "failure cause" to "Invalid configuration";
- 1> When the ACTIVE SET UPDATE FAILURE message has been submitted to lower layers for transmission:
 - 2> the procedure ends on the UE side.

If the following condition is valid:

- the active set update procedure results in active sets that do not contain at least one common radio link before and after a DPCH frame boundary:

the UE behaviour is not specified.

8.3.4.5a Void

8.3.4.5b Incompatible simultaneous reconfiguration

If the variable ORDERED_RECONFIGURATION is set to TRUE, the UE may:

- 1> if the activation time for the procedure that has set variable ORDERED_RECONFIGURATION and the activation time for the Active Set Update procedure are within a time window of 5 frames:
 - 2> transmit an ACTIVE SET UPDATE FAILURE message on the uplink DCCH using AM RLC;
 - 2> set the IE "RRC transaction identifier" in the ACTIVE SET UPDATE FAILURE message to the value of "RRC transaction identifier" in the entry for the ACTIVE SET UPDATE message in the table "Accepted transactions" in the variable TRANSACTIONS; and
 - 2> clear that entry;
 - 2> set the IE "failure cause" to the cause value "incompatible simultaneous reconfiguration";
 - 2> when the ACTIVE SET UPDATE FAILURE message has been delivered to lower layers for transmission:

3> continue with any ongoing processes and procedures as if the ACTIVE SET UPDATE message has not been received.

3> and the procedure ends.

8.3.4.6 Reception of the ACTIVE SET UPDATE COMPLETE message by the UTRAN

When the UTRAN has received the ACTIVE SET UPDATE COMPLETE message,

- 1> the UTRAN may remove radio link(s) that are indicated to remove to the UE in case b) and c); and
- 1> the procedure ends on the UTRAN side.

8.3.4.7 Reception of the ACTIVE SET UPDATE FAILURE message by the UTRAN

When the UTRAN has received the ACTIVE SET UPDATE FAILURE message, the UTRAN may delete radio links that were included in the IE "Radio Link Addition Information" for addition. The procedure ends on the UTRAN side.

8.3.4.8 Invalid ACTIVE SET UPDATE message

If the ACTIVE SET UPDATE message contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

- 1> transmit a ACTIVE SET UPDATE FAILURE message on the uplink DCCH using AM RLC;
- 1> set the IE "RRC transaction identifier" in the ACTIVE SET UPDATE FAILURE message to the value of "RRC transaction identifier" in the entry for the ACTIVE SET UPDATE message in the table "Rejected transactions" in the variable TRANSACTIONS; and
- 1> clear that entry;
- 1> set the IE "failure cause" to the cause value "protocol error";
- 1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION;

- 1> when the ACTIVE SET UPDATE FAILURE message has been delivered to lower layers for transmission:
 - 2> continue with any ongoing processes and procedures as if the invalid ACTIVE SET UPDATE message has not been received;
 - 2> and the procedure ends.

8.3.4.9 Reception of an ACTIVE SET UPDATE message in wrong state

If the UE is in another state than CELL_DCH state upon reception of the ACTIVE SET UPDATE message, the UE shall perform procedure specific error handling as follows. The UE shall:

- 1> transmit a ACTIVE SET UPDATE FAILURE message on the uplink DCCH using AM RLC;
- 1> set the IE "RRC transaction identifier" in the ACTIVE SET UPDATE FAILURE message to the value of "RRC transaction identifier" in the entry for the ACTIVE SET UPDATE message in the table "Accepted transactions" in the variable TRANSACTIONS; and
- 1> clear that entry;
- 1> set the IE "failure cause" to the cause value "protocol error";
- 1> include the IE "Protocol error information" with the IE "Protocol error cause" set to "Message not compatible with receiver state";
- 1> when the ACTIVE SET UPDATE FAILURE message has been delivered to lower layers for transmission:
 - 2> continue with any ongoing processes and procedures as if the ACTIVE SET UPDATE message has not been received:
 - 2> and the procedure ends.

8.3.5 Hard handover

When performing hard handover with change of frequency, the UE shall:

1> stop all intra-frequency and inter-frequency measurement reporting on the cells listed in the variable CELL_INFO_LIST. Each stopped measurement is restarted when a MEASUREMENT CONTROL message is received with the corresponding measurement identity.

8.3.5.1 Timing re-initialised hard handover

8.3.5.1.1 General

The purpose of the timing re-initialised hard handover procedure is to remove all the RL(s) in the active set and establish new RL(s) along with a change in the CFN in the UE according to the SFN of the target cell.(see subclause 8.5.15).

NOTE: During the hard-handover procedure, the UE will align the timing of the uplink transmission as specified in [26].

This procedure is initiated when UTRAN does not know the target SFN timing before hard handover.

8.3.5.1.2 Initiation

Timing re-initialised hard handover initiated by the UTRAN is normally performed by using the procedure "Physical channel reconfiguration" (subclause 8.2.6), but may also be performed by using either one of the following procedures:

- "radio bearer establishment" (subclause 8.2.1);
- "Radio bearer reconfiguration" (subclause 8.2.2);
- "Radio bearer release" (subclause 8.2.3); or

- "Transport channel reconfiguration" (subclause 8.2.4).

If IE "Timing indication" has the value "initialise", UE shall:

1> execute the Timing Re-initialised hard handover procedure by following the procedure indicated in the subclause relevant to the procedure chosen by the UTRAN.

In this case of a timing re-initialised hard handover, UTRAN should include the IE "Default DPCH Offset Value" and:

1> in FDD mode:

2> set "Default DPCH Offset Value" and "DPCH frame offset" respecting the following relation

(Default DPCH Offset Value) mod 38400 = DPCH frame offset_i

3> where *j* indicates the first radio link listed in the message and the IE values used are the Actual Values of the IEs as defined in clause 11.

If the IE "Default DPCH Offset Value" is included, the UE shall:

1> in FDD mode:

2> if the above relation between "Default DPCH Offset Value" and "DPCH frame offset" is not respected:

3> set the variable INVALID_CONFIGURATION to true.

If the IE "Default DPCH Offset Value" is not included, the UE shall:

1> set the variable INVALID_CONFIGURATION to true.

8.3.5.2 Timing-maintained hard handover

8.3.5.2.1 General

The purpose of the Timing-maintained hard handover procedure is to remove all the RL(s) in the active set and establish new RL(s) while maintaining the CFN in the UE.

NOTE: During the hard-handover procedure, the UE will align the timing of the uplink transmission as specified in [26].

This procedure can be initiated only if UTRAN knows the target SFN timing before hard handover. The target SFN timing can be known by UTRAN in the following 2 cases:

- UE reads SFN when measuring "Cell synchronisation information" and sends it to the UTRAN in MEASUREMENT REPORT message.
- UTRAN internally knows the time difference between the cells.

8.3.5.2.2 Initiation

Timing-maintained hard handover initiated by the network is normally performed by using the procedure "Physical channel reconfiguration" (subclause 8.2.6), but may also be performed by using either one of the following procedures:

- "radio bearer establishment" (subclause 8.2.1);
- "Radio bearer reconfiguration" (subclause 8.2.2);
- "Radio bearer release" (subclause 8.2.3); or
- "Transport channel reconfiguration" (subclause 8.2.4).

If IE "Timing indication" has the value "maintain", UE shall initiate the Timing-maintained hard handover procedure by following the procedure indicated in the subclause relevant to the procedure chosen by the UTRAN. In this case UTRAN should not include the IE "Default DPCH Offset Value".

If the IE "Default DPCH Offset Value" is included, the UE shall:

1> ignore the IE "Default DPCH Offset Value".

8.3.6 Inter-RAT handover to UTRAN




Figure 8.3.6-1: Inter-RAT handover to UTRAN, successful case

8.3.6.1 General

The purpose of the inter-RAT handover procedure is to, under the control of the network, transfer a connection between the UE and another radio access technology (e.g. GSM) to UTRAN.

8.3.6.2 Initiation

The procedure is initiated when a radio access technology other than UTRAN, e.g. GSM, using radio access technology-specific procedures, orders the UE to make a handover to UTRAN.

A HANDOVER TO UTRAN COMMAND message is sent to the UE via the radio access technology from which inter-RAT handover is performed.

In case UTRAN decides to uses a predefined or default radio configuration that is stored in the UE, it should include the following information in the HANDOVER TO UTRAN COMMAND message.

- the IE "New U-RNTI" to be assigned;
- the IE "Predefined configuration identity", to indicate which pre-defined configuration of RB, transport channel and physical channel parameters shall be used; or
- the IE "Default configuration mode" and IE "Default configuration identity", to indicate which default configuration of RB, transport channel and physical channel parameters shall be used;
- PhyCH information elements.
- NOTE 1: When using a predefined or default configuration during handover to UTRAN, UTRAN can only assign values of IEs "New U-RNTI" and "scrambling code" that are within the special subranges defined exclusively for this procedure. UTRAN may re- assign other values after completion of the handover procedure.
- NOTE 2: When using a predefined or default configuration during handover to UTRAN, fewer IEs are signalled; when using this signalling option some parameters e.g. concerning compressed mode, DSCH, SSDT can not be configured. In this case, the corresponding functionality can not be activated immediately.
- NOTE 3: When using a predefined or default configuration, the HANDOVER TO UTRAN COMMAND should not include more than one radio link. If UTRAN includes more than one radio link in the HANDOVER TO UTRAN COMMAND using a predefined or default configuration, the UE behaviour is unspecified.

In case UTRAN does not use a predefined radio configuration that is stored in the UE, it should include the following information in the HANDOVER TO UTRAN COMMAND message.

- the IE "New U-RNTI" to be assigned;

- the complete set of RB, TrCH and PhyCH information elements to be used.

8.3.6.3 Reception of HANDOVER TO UTRAN COMMAND message by the UE

The UE shall be able to receive a HANDOVER TO UTRAN COMMAND message and perform an inter-RAT handover, even if no prior UE measurements have been performed on the target UTRAN cell and/or frequency.

The UE shall act upon all received information elements as specified in subclause 8.6, unless specified otherwise in the following.

The UE may:

1> maintain a list of the set of cells to which the UE has Radio Links if the IE "Cell ID" is present.

The UE shall:

- 1> store a U-RNTI value (32 bits), which is derived by the IEs "SRNC identity" (12 bits) and "S-RNTI 2" (10 bits) included in IE "U-RNTI-short". In order to produce a full size U-RNTI value, a full size "S-RNTI" (20 bits) shall be derived by padding the IE "S-RNTI 2" with 10 zero bits in the most significant positions; and
- 1> initialise the variable ESTABLISHED_SIGNALLING_CONNECTIONS with the signalling connections that remains after the handover according to the specifications of the source RAT;
- 1> initialise the variable UE_CAPABILITIES_TRANSFERRED with the UE capabilities that have been transferred to the network up to the point prior to the handover, if any;
- 1> initialise the variable TIMERS_AND_CONSTANTS to the default values and start to use those timer and constants values:
- 1> if IE "Specification mode" is set to "Preconfiguration" and IE "Preconfiguration mode" is set to "Predefined configuration":
 - 2> initiate the radio bearer and transport channel configuration in accordance with the predefined parameters identified by the IE "Predefined configuration identity";
 - 2> initiate the physical channels in accordance with the predefined parameters identified by the IE "Predefined radio configuration identity" and the received physical channel information elements;
 - 2> store information about the established radio access bearers and radio bearers according to the IE "Predefined configuration identity"; and
 - 2> set the IE "RAB Info Post" in the variable ESTABLISHED_RABS and the IE "Re-establishment timer" in the IE "RAB Info" in the variable ESTABLISHED_RABS to "useT314".
- 1> if IE "Specification mode" is set to "Preconfiguration" and IE "Preconfiguration mode" is set to "Default configuration":
 - 2> initiate the radio bearer and transport channel configuration in accordance with the default parameters identified by the IE "Default configuration mode" and IE "Default configuration identity";
 - 2> initiate the physical channels in accordance with the default parameters identified by the IE "Default configuration mode" and IE "Default configuration identity" and the received physical channel information elements;
- NOTE: IE "Default configuration mode" specifies whether the FDD or TDD version of the default configuration shall be used.
 - 2> set the IE "RAB Info Post" in the variable ESTABLISHED_RABS and the IE "Re-establishment timer" in the IE "RAB Info" in the variable ESTABLISHED_RABS to "useT314".
- 1> if IE "Specification mode" is set to "Preconfiguration":
 - 2> use the following values for parameters that are neither signalled within the HANDOVER TO UTRAN COMMAND message nor included within pre-defined or default configuration:
- 3> 0 dB for the power offset P Pilot-DPDCH bearer in FDD;

3> calculate the Default DPCH Offset Value using the following formula:

3> in FDD:

Default DPCH Offset Value = (SRNTI 2 mod 600) * 512

3> in TDD:

Default DPCH Offset Value = (SRNTI 2 mod 7)

- 3> handle the above Default DPCH Offset Value as if an IE with that value was included in the message, as specified in subclause 8.6.6.21.
 - 1> if IE "Specification mode" is set to "Complete specification":
 - 2> initiate the radio bearer, transport channel and physical channel configuration in accordance with the received radio bearer, transport channel and physical channel information elements.
 - 1> perform an open loop estimation to determine the UL transmission power according to subclause 8.5.3;
 - 1> set the IE "START" for each CN domain, in the IE "START list" in the HANDOVER TO UTRAN COMPLETE message equal to the START value for each CN domain stored in the USIM if the USIM is present, or as stored in the UE for each CN domain if the SIM is present;
 - NOTE: Keys received while in another RAT are not regarded as "new" (i.e.do not trigger the actions in subclause 8.1.12.3.1) in a subsequent security control procedure in UTRAN, irrespective of whether the keys are already being used in the other RAT or not. If the UE has received new keys in the other RAT before handover, then the START values in the USIM (sent in the HANDOVER TO UTRAN COMPLETE message and in the INTER_RAT_HANDOVER_INFO sent to the BSS while in the other RAT) will not reflect the receipt of these new keys. At a subsequent security mode control procedure in UTRA, UE activates ciphering and/or integrity protection using the key set stored in the USIM/SIM.
 - 1> set the value of "THRESHOLD" in the variable "START_THRESHOLD" to the 20 MSBs of the value stored in the USIM [50] for the maximum value of START for each CN Domain, or to the default value in [40] if the SIM is present;
 - 1> if ciphering has been activated and ongoing in the radio access technology from which inter- RAT handover is performed:
 - 2> for the CN domain included in the IE "CN domain identity" which is included in the IE "RAB info" of the IE "RAB information to setup", or the CS domain when these IEs are not present:
- 3> set the variable LATEST_CONFIGURED_CN_DOMAIN to the value indicated in the IE "CN domain identity", or to the CS domain when this IE is not present;
- 3> set the 20 MSB of the HFN component of the COUNT-C variable for all radio bearers using RLC-TM and all signalling radio bearers to the "START" value included in the IE "UE security information" in the variable "INTER_RAT_HANDOVER_INFO_TRANSFERRED";
- 3> set the remaining LSBs of the HFN component of COUNT-C for all radio bearers using RLC-TM and all signalling radio bearers to zero;
- 3> not increment the HFN component of COUNT-C for radio bearers using RLC-TM, i.e. keep the HFN value fixed without incrementing every CFN cycle;
- 3> set the CFN component of the COUNT-C variable to the value of the CFN as calculated in subclause 8.5.15;
- 3> set the IE "Status" in the variable CIPHERING STATUS to "Started";
- 3> apply the algorithm according to IE "Ciphering Algorithm" with the ciphering key set stored in the USIM/SIM and apply ciphering immediately upon reception of the HANDOVER TO UTRAN COMMAND.
 - NOTE: If ciphering has been activated and ongoing in the radio access technology from which inter RAT handover is performed, UTRAN should not include the IE "Ciphering mode info" in the SECURITY MODE COMMAND message that starts Integrity protection.

- 1> if ciphering has not been activated and ongoing in the radio access technology from which inter-RAT handover is performed:
 - 2> for the CN domain included in the IE "CN domain identity" which is included in the IE "RAB info" of the IE "RAB information to setup", or the CS domain when these IEs are not present:
- 3> set the IE "Status" in the variable CIPHERING_STATUS to "Not Started".
- If the UE succeeds in establishing the connection to UTRAN, it shall:
 - 1> indicate to upper layers that no CN system information is available for any domain other then the CS domain;
 - 1> if the USIM or SIM is present:
 - 2> set the START value stored in the USIM [50] if present, and as stored in the UE if the SIM is present for any CN domain to the value "THRESHOLD" of the variable START_THRESHOLD.
 - 1> if the IE "Status" in the variable CIPHERING_STATUS of a CN domain is set to "Started" and transparent mode radio bearers have been established by this procedure for that CN domain:
 - 2> include the IE "COUNT-C activation time" in the response message and specify a CFN value for this IE other than the default, "Now", that is a multiple of 8 frames (CFN mod 8 =0) and lies at least 200 frames ahead of the CFN in which the response message is first transmitted;
 - 2> at the CFN value as indicated in the response message in the IE "COUNT-C activation time" for radio bearers using RLC-TM:
- 3> set the 20 MSB of the HFN component of the COUNT-C variable common for all transparent mode radio bearers of this CN domain to the START value as indicated in the IE "START list" of the response message for the relevant CN domain; and
- 3> set the remaining LSBs of the HFN component of COUNT-C to zero;
- 3> increment the HFN component of the COUNT-C variable by one even if the "COUNT-C activation time" is equal to zero:
- 3> set the CFN component of the COUNT-C to the value of the IE "COUNT-C activation time" of the response message. The HFN component and the CFN component completely initialise the COUNT-C variable;
- 3> step the COUNT-C variable, as normal, at each CFN value. The HFN component is no longer fixed in value but incremented at each CFN cycle.
 - 1> if the IE "Status" in the variable CIPHERING_STATUS of a CN domain is set to "Not Started" and transparent mode radio bearers have been established by this procedure for that CN domain:
 - 2> initialise the 20 MSB of the HFN component of COUNT-C common for all transparent mode radio bearers of this CN domain with the START value as indicated in the IE "START list" of the response message for the relevant CN domain;
 - 2> set the remaining LSBs of the HFN component of COUNT-C to zero;
 - 2> do not increment the COUNT-C value common for all transparent mode radio bearers for this CN domain.
 - 1> transmit a HANDOVER TO UTRAN COMPLETE message on the uplink DCCH, using, if ciphering has been started, the new ciphering configuration;
 - 1> when the HANDOVER TO UTRAN COMPLETE message has been submitted to lower layers for transmission:
 - 2> enter UTRA RRC connected mode in state CELL_DCH;
 - 2> initialise variables upon entering UTRA RRC connected mode as specified in subclause 13.4;
 - 2> update the variable UE_CAPABILITY_TRANSFERRED with the UE capabilities stored in the variable INTER RAT HANDOVER INFO TRANSFERRED;
 - 2> for all radio bearers using RLC-AM or RLC-UM:

- 3> set the 20 MSB of the HFN component of the uplink and downlink COUNT-C variable to the START value indicated in the IE "START list" of the response message for the relevant CN domain; and
- 3> set the remaining LSBs of the HFN component of COUNT-C to zero;
- 3> increment the HFN component of the COUNT-C variable by one;
- 3> start incrementing the COUNT-C values.
 - 1> and the procedure ends.

8.3.6.4 Invalid Handover to UTRAN command message

If the UE receives a HANDOVER TO UTRAN COMMAND message, which contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling according to the source radio access technology. The UE shall:

- 1> if allowed by the source RAT:
 - 2> transmit an RRC FAILURE INFO message to the source radio access technology; and
 - 2> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION;
- 1> Other details may be provided in the specifications related to the source radio access technology.

NOTE: The other RAT may include the above diagnostics information in a subsequent handover request towards the same RNC.

8.3.6.4a Unsupported configuration in HANDOVER TO UTRAN COMMAND message

If the UE does not support the configuration included in the HANDOVER TO UTRAN COMMAND message, e.g., the message includes a pre-defined configuration that the UE has not stored, the UE shall:

- 1> continue the connection using the other radio access technology; and
- 1> indicate the failure to the other radio access technology.

8.3.6.5 UE fails to perform handover

If the UE does not succeed in establishing the connection to UTRAN, it shall:

- 1> terminate the procedure including release of the associated resources;
- 1> resume the connection used before the handover; and
- 1> indicate the failure to the other radio access technology.

Upon receiving an indication about the failure from the other radio access technology, UTRAN should release the associated resources and the context information concerning this UE.

8.3.6.6 Reception of message HANDOVER TO UTRAN COMPLETE by the UTRAN

Upon receiving a HANDOVER TO UTRAN COMPLETE message, UTRAN should consider the inter-RAT handover procedure as having been completed successfully and indicate this to the Core Network.

8.3.7 Inter-RAT handover from UTRAN



Figure 8.3.7-1: Inter-RAT handover from UTRAN, successful case




Figure 8.3.7-2: Inter-RAT handover from UTRAN, failure case

8.3.7.1 General

The purpose of the inter-RAT handover procedure is to, under the control of the network, transfer a connection between the UE and UTRAN to another radio access technology (e.g. GSM). This procedure may be used in CELL_DCH state. This procedure may be used when no RABs are established or when the established RABs are only in the CS domain or when the established RABs are in both CS and PS domains.

8.3.7.2 Initiation

The procedure is initiated when UTRAN orders a UE in CELL_DCH state, to make a handover to a radio access technology other than UTRAN, e.g. GSM.

To initiate the procedure, UTRAN sends a HANDOVER FROM UTRAN COMMAND message.

8.3.7.3 Reception of a HANDOVER FROM UTRAN COMMAND message by the UE

The UE shall be able to receive a HANDOVER FROM UTRAN COMMAND message and perform an inter-RAT handover, even if no prior UE measurements have been performed on the target cell.

The UE shall:

- 1> if HS-DSCH is configured for UTRA:
 - 2> stop any HS-DSCH reception procedures;
 - 2> clear any stored HS-PDSCH configuration;
 - 2> act as if the IE "MAC-hs reset indicator" is received and set to TRUE;
 - 2> release all HARQ resources;
 - 2> remove any H-RNTI stored;
 - 2> clear the variable H_RNTI;

- 2> set the variable HS_DSCH_RECEPTION to FALSE.
- 1> if the UE has a pending "TGPS reconfiguration CFN" at the activation time received in the HANDOVER FROM UTRAN COMMAND the UE may:
 - 2> abort the pending CM activation;
 - 2> set the CM_PATTERN_ACTIVATION_ABORTED to TRUE.
- 1> otherwise:
 - 2> set the CM_PATTERN_ACTIVATION_ABORTED to FALSE.
- 1> establish the connection to the target radio access technology, by using the contents of the IE "Inter-RAT message". This IE contains a message specified in another standard, as indicated by the IE "System type", and carries information about the candidate/ target cell identifier(s) and radio parameters relevant for the target radio access technology. The correspondence between the value of the IE "System type", the standard to apply and the message contained within IE "Inter RAT message" is shown in the following:

Value of the IE "System type"	Standard to apply	Inter RAT Message
GSM	GSM TS 04.18, version 8.5.0 or later, or 3GPP TS 44.018	HANDOVER COMMAND
GERAN lu	3GPP TS 44.118	RADIO BEARER RECONFIGURATION
cdma2000	TIA/EIA/IS-2000 or later, TIA/EIA/IS-833 or later, TIA/EIQ/IS-834 or later	

- 1> if the IE "System type" has the value "GSM" or "GERAN Iu":
 - 2> if the IE "Frequency band" has the value "GSM /DCS 1800 band used":
- 3> set the BAND_INDICATOR [45] to "ARFCN indicates 1800 band".
 - 2> if the IE "Frequency band" has the value " GSM /PCS 1900 band used":
- 3> set the BAND_INDICATOR [45] to "ARFCN indicates 1900 band".
 - 1> apply the "Inter RAT Message" according to the "standard to apply" in the table above.
 - 1> if the IE "RAB information List" is included in the HANDOVER FROM UTRAN COMMAND message:
 - 2> if the IE "RAB information List" includes one IE "RAB Info" with the IE "CN domain Identity" set to "CS domain":
- 3> connect upper layer entities corresponding to the indicated CS domain RAB to the radio resources indicated in the inter-RAT message.
 - NOTE1: In this version of the specification the maximum number of CS domain RABs which may be included in the IE "RAB information List" is limited to 1.
 - NOTE2: In handover to GERAN *Iu mode*, the RAB information is included in the RADIO BEARER RECONFIGURATION message specified in [53].
 - NOTE3: Requirements concerning the establishment of the radio connection towards the other radio access technology and the signalling procedure are outside the scope of this specification.
 - NOTE4: The UE may ignore the IE "NAS synchronisation indicator" if included in the HANDOVER FROM UTRAN COMMAND message;
 - NOTE5: The UE behaviour is undefined if the IE "Re-establishment timer" in the IE "RAB info" indicates a timer different from the timer currently configured for this RAB.

8.3.7.4 Successful completion of the inter-RAT handover

Upon successfully completing the handover, UTRAN should:

- 1> release the radio connection; and
- 1> remove all context information for the concerned UE.

Upon successfully completing the handover, the UE shall:

- 1> if inter-RAT handover to GERAN *Iu mode* is performed:
 - 2> perform the actions on reception of the RADIO BEARER RECONFIGURATION message as specified in [53].
- 1> if inter-RAT handover to GERAN *Iu mode* is performed and if there are any NAS messages for which the successful delivery of the INITIAL DIRECT TRANSFER message or UPLINK DIRECT TRANSFER message on signalling radio bearer RB3 or signalling radio bearer RB4 has not yet been confirmed by RLC; or
- 1> if inter-RAT handover to other RAT than GERAN *Iu mode* is performed and if there are any NAS messages with the IE "CN domain identity" set to "CS domain" for which the successful delivery of the INITIAL DIRECT TRANSFER message or UPLINK DIRECT TRANSFER message on signalling radio bearer RB3 or signalling radio bearer RB4 that have not yet been confirmed by RLC:
 - 2> retransmit those NAS messages to the network on the newly established radio connection to the target radio access technology.
- 1> clear or set variables upon leaving UTRA RRC connected mode as specified in subclause 13.4.

NOTE: The release of the UMTS radio resources is initiated from the target RAT.

8.3.7.5 UE fails to complete requested handover

If the UE does not succeed in establishing the connection to the target radio access technology, it shall:

1> revert back to the UTRA configuration;

NOTE: If configured for HS-DSCH while in UTRA, the UE will have still stored the IEs "Added or Reconfigured MAC-d flow" and "RB mapping Info".

- 1> if the CM_PATTERN_ACTIVATION_ABORTED flag is not set to TRUE:
 - 2> establish the UTRA physical channel(s) used at the time for reception of HANDOVER FROM UTRAN COMMAND;
 - 2> perform the physical layer synchronisation procedure A as specified in [29] (FDD only);
 - 2> after the establishment of the uplink physical channel, send DPCCH and no DPDCH according to [26] during the number of frames indicated in the IE "PC preamble" in the variable LATEST_CONFIGURED_SRB_DELAY_AND_PC_PREAMBLE; and
 - 2> then not send any data on signalling radio bearers RB0 to RB4 during the number of frames indicated in the IE "SRB delay" in the variable LATEST_CONFIGURED_SRB_DELAY_AND_PC_PREAMBLE.
- 1> if the CM_PATTERN_ACTIVATION_ABORTED flag is set to TRUE or if the UE does not succeed to establish the UTRA physical channel(s):
 - 2> perform a cell update procedure according to subclause 8.3.1 with cause "Radio link failure";
 - 2> when the cell update procedure has completed successfully:
- 3> proceed as below.
 - 1> transmit the HANDOVER FROM UTRAN FAILURE message setting the information elements as specified below:

- 2> include the IE "RRC transaction identifier"; and
- 2> set it to the value of "RRC transaction identifier" in the entry for the HANDOVER FROM UTRAN COMMAND message in the table "Accepted transactions" in the variable TRANSACTIONS; and
- 2> clear that entry;
- 2> set the IE "Inter-RAT handover failure" to "physical channel failure".
- 1> When the HANDOVER FROM UTRAN FAILURE message has been submitted to lower layer for transmission:
 - 2> the procedure ends.

8.3.7.6 Invalid HANDOVER FROM UTRAN COMMAND message

If the IE "Inter-RAT message" received within the HANDOVER FROM UTRAN COMMAND message does not include a valid inter RAT handover message in accordance with the protocol specifications for the target RAT, the UE shall perform procedure specific error handling as follows. The UE shall:

- 1> set the IE "failure cause" to the cause value "Inter-RAT protocol error";
- 1> include the IE "Inter-RAT message" in accordance with the specifications applicable to the other RAT;
- 1> transmit a HANDOVER FROM UTRAN FAILURE message on the uplink DCCH using AM RLC;
- 1> when the transmission of the HANDOVER FROM UTRAN FAILURE message has been confirmed by RLC:
 - 2> continue with any ongoing processes and procedures as if the invalid HANDOVER FROM UTRAN COMMAND message has not been received;
 - 2> and the procedure ends.

If the HANDOVER FROM UTRAN COMMAND message contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

- 1> set the IE "RRC transaction identifier" in the HANDOVER FROM UTRAN FAILURE message to the value of "RRC transaction identifier" in the entry for the HANDOVER FROM UTRAN COMMAND message in the table "Rejected transactions" in the variable TRANSACTIONS; and
- 1> clear that entry;
- 1> set the IE "failure cause" to the cause value "protocol error";
- 1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION;
- 1> transmit a HANDOVER FROM UTRAN FAILURE message on the uplink DCCH using AM RLC;
- 1> when the HANDOVER FROM UTRAN FAILURE message has been submitted to lower layers for transmission:
 - 2> continue with any ongoing processes and procedures as if the invalid HANDOVER FROM UTRAN COMMAND message has not been received;
 - 2> and the procedure ends.

8.3.7.7 Reception of an HANDOVER FROM UTRAN FAILURE message by UTRAN

Upon receiving an HANDOVER FROM UTRAN FAILURE message, UTRAN may initiate the release the resources in the target radio access technology.

8.3.7.8 Unsupported configuration in HANDOVER FROM UTRAN COMMAND message

If:

- the UTRAN instructs the UE to perform a non-supported handover scenario; or
- the UTRAN instructs the UE to use a non-supported configuration; or
- inter-RAT handover to other RAT than GERAN *Iu mode* is performed and the IE "RAB information List" is included in the HANDOVER FROM UTRAN COMMAND message and this IE does not include any IE "RAB Info" with the IE "CN domain Identity" set to "CS domain":

the UE shall:

- 1> transmit a HANDOVER FROM UTRAN FAILURE message, setting the information elements as specified below:
 - 2> include the IE "RRC transaction identifier"; and
 - 2> set it to the value of "RRC transaction identifier" in the entry for the HANDOVER FROM UTRAN COMMAND message in the table "Accepted transactions" in the variable TRANSACTIONS; and
 - 2> clear that entry;
 - 2> set the IE "Inter-RAT handover failure" to "configuration unacceptable";
 - 2> when the HANDOVER FROM UTRAN FAILURE message has been submitted to lower layers for transmission:
- 3> resume normal operation as if the invalid HANDOVER FROM UTRAN COMMAND message has not been received:
- 3> and the procedure ends.

8.3.7.8a Reception of HANDOVER FROM UTRAN COMMAND message by UE in CELL FACH

If the UE receives HANDOVER FROM UTRAN COMMAND while in CELL_FACH, the UE shall:

- 1> transmit a HANDOVER FROM UTRAN FAILURE message, setting the information elements as specified below:
 - 2> include the IE "RRC transaction identifier"; and
 - 2> set it to the value of "RRC transaction identifier" in the entry for the HANDOVER FROM UTRAN COMMAND message in the table "Accepted transactions" in the variable TRANSACTIONS; and
 - 2> clear that entry;
 - 2> set the IE "Inter-RAT handover failure" to "protocol error", include IE "Protocol error information"; and
 - 2> set the value of IE "Protocol error cause" to "Message not compatible with receiver state";
 - 2> when the HANDOVER FROM UTRAN FAILURE message has been submitted to lower layers for transmission:
- 3> resume normal operation as if the invalid HANDOVER FROM UTRAN COMMAND message has not been received;
- 3> and the procedure ends.

8.3.8 Inter-RAT cell reselection to UTRAN

8.3.8.1 General

The purpose of the inter-RAT cell reselection procedure to UTRAN is to transfer, under the control of the UE and to some extent the source radio access technology, a connection between the UE and another radio access technology (e.g. GSM/GPRS, but not UTRAN) to UTRAN.

8.3.8.2 Initiation

When the UE makes an inter-RAT cell reselection to UTRAN according to the criteria specified in [4], it shall initiate this procedure. The inter-RAT cell reselection made by the UE may use system information broadcast from the source radio access technology or UE dedicated information.

If the NAS procedures associated with inter-system change specified in [5] require the establishment of an RRC connection, the UE shall:

1> set the variable ESTABLISHMENT_CAUSE to "Inter-RAT cell reselection";

NOTE: This value of ESTABLISHMENT_CAUSE has priority over the cause requested by upper layers.

- 1> initiate an RRC connection establishment procedure as specified in subclause 8.1.3;
- 1> after initiating an RRC connection establishment:
 - 2> release all resources specific to the other radio access technology.

If the NAS procedures associated with inter-system change specified in [5] do not require the establishment of an RRC connection, the UE shall:

- 1> enter idle mode in the target cell without accessing the cell; and
- 1> release all resources specific to the other radio access technology.

8.3.8.2a Initiation of inter-RAT cell reselection from GERAN *lu mode*

When the UE performs an inter-RAT cell reselection from GERAN *Iu mode* Cell_Shared state, the UE shall:

1> initiate the cell update procedure as specified for the cell reselection case in CELL_FACH and CELL_PCH states, using the cause "cell reselection" and setting the G-RNTI in the IE "U-RNTI".

When the UE performs an inter-RAT cell reselection from GERAN Iu mode GRA_PCH state, the UE shall:

- 1> compare the GRA identity which the MS had been assigned to in GERAN against the URA identities which are broadcast in the UTRAN cell.
- 1> If the assigned GRA identity is not present in the list of URA identities that are broadcast in the UTRAN cell:
 - 2> initiate the URA update procedure as specified for the URA reselection case in URA_PCH state, using the cause "change of URA" and setting the G-RNTI in the IE "U-RNTI".

The UE shall:

1> set the following variables equal to the corresponding variables in GERAN *Iu mode*:

CIPHERING_STATUS

ESTABLISHED RABS

ESTABLISHED_SIGNALLING_CONNECTIONS

INTEGRITY_PROTECTION_INFO

INTER_RAT_HANDOVER_INFO_TRANSFERRED

LATEST_CONFIGURED_CN_DOMAIN

START THRESHOLD

UE_CAPABILITY_TRANSFERRED.

1> set the new uplink and downlink HFN of RB2 to MSB₂₀(MAX(uplink HFN of RB2, downlink HFN of RB2)).

NOTE: MSB₂₀() operation provides the HFN mapping from GERAN *Iu mode* to UTRAN. In GERAN *Iu mode* the length of HFN component of the COUNT-C of RB2 is longer than 20 bits.

1> initialise the variable TIMERS_AND_CONSTANTS to the default values and start to use those timer and constants values.

8.3.8.3 UE fails to complete an inter-RAT cell reselection

If the inter-RAT cell reselection fails before the UE has initiated the RRC connection establishment the UE may return back to the other radio access technology.

If the RRC connection establishment fails, the UE shall enter idle mode.

8.3.8.3a UE fails to complete an inter-RAT cell reselection from GERAN *lu mode*

When the UE performs an inter-RAT cell reselection from GERAN Iu mode to UTRAN, and the cell reselection fails:

1> the UE may return back to the GERAN *Iu mode* state from which it initiated the inter-RAT cell reselection.

8.3.9 Inter-RAT cell reselection from UTRAN

8.3.9.1 General

The purpose of the inter-RAT cell reselection procedure from UTRAN is to transfer, under the control of the UE and to some extent the UTRAN, a connection between the UE and UTRAN to another radio access technology (e.g. GSM/GPRS).

8.3.9.2 Initiation

This procedure is applicable in states CELL_FACH, CELL_PCH or URA_PCH.

When the UE based on received system information makes a cell reselection to a radio access technology other than UTRAN, e.g. GSM/GPRS, according to the criteria specified in [4], the UE shall:

- 1> If the NAS procedures associated with inter-system change specified in [5] require the establishment of a connection:
 - 2> initiate the establishment of a connection to the target radio access technology according to its specifications.

8.3.9.2a Initiation of inter-RAT cell reselection to GERAN *lu mode*

When the UE in CELL_PCH or CELL_FACH state performs an inter-RAT cell reselection to GERAN *Iu mode*, according to the criteria specified in [4], the UE shall:

1> initiate the cell update procedure according to 3GPP TS 44.118 [53], setting the U-RNTI in the IE "G-RNTI".

When the UE in URA_PCH state performs an inter-RAT cell reselection to GERAN *Iu mode*, according to the criteria specified in [4], the UE shall:

- 1> compare the URA identity which the UE had been assigned to in UTRAN against the GRA identities which are broadcast in the GERAN cell;
- 1> If the assigned URA identity is not present in the list of GRA identities that are broadcast in the GERAN cell:

2> initiate the GRA update procedure as specified in 3GPP TS 44.118 [53], setting the U-RNTI in the IE "G-RNTI".

8.3.9.3 Successful cell reselection

When the UE has succeeded in reselecting a cell in the target radio access technology, the UE shall:

1> release all UTRAN specific resources.

UTRAN should:

1> release all UE dedicated resources upon indication that the UE has completed a connection establishment to the other radio access technology.

8.3.9.4 UE fails to complete an inter-RAT cell reselection

If the inter-RAT cell reselection fails, the UE shall:

1> resume the connection to UTRAN using the resources used before initiating the inter-RAT cell reselection procedure.

8.3.10 Inter-RAT cell change order to UTRAN

8.3.10.1 General

The purpose of the inter-RAT cell change order to UTRAN procedure is to transfer, under the control of the source radio access technology, a connection between the UE and another radio access technology (e.g. GSM/GPRS) to UTRAN.

8.3.10.2 Initiation

The procedure is initiated when a radio access technology other than UTRAN, e.g. GSM/GPRS, using procedures specific for that RAT, orders the UE to change to a UTRAN cell.

NOTE: Within the message used to order the UE to change to a UTRAN cell, the source RAT should specify the identity of the target UTRAN cell as specified in the specifications for that RAT.

The UE shall:

1> set the variable ESTABLISHMENT_CAUSE to "Inter-RAT cell change order";

NOTE: This value of ESTABLISHMENT_CAUSE has priority over the cause requested by upper layers.

1> initiate an RRC connection establishment procedure as specified in subclause 8.1.3.

8.3.10.3 UE fails to complete an inter-RAT cell change order

If the inter-RAT cell reselection fails the UE shall return to the other radio access technology and proceed as specified in the appropriate specifications for that RAT.

NOTE 3: The cell change was network ordered. Therefore, failure to change to the target cell should not cause the UE to move to UE- controlled cell selection.

8.3.11 Inter-RAT cell change order from UTRAN



Figure 8.3.11-1: Inter-RAT cell change order from UTRAN




Figure 8.3.11-2: Inter-RAT cell change order from UTRAN, failure case

8.3.11.1 General

The purpose of the inter-RAT cell change order procedure is to transfer, under the control of the network, a connection between the UE and UTRAN to another radio access technology (e.g. GSM). This procedure may be used in CELL_DCH and CELL_FACH state. This procedure may be used when no RABs are established or when the established RABs are only from PS domain. This procedure may not be used when there is no PS signalling connection.

8.3.11.2 Initiation

The procedure is initiated when UTRAN orders a UE in CELL_DCH or CELL_FACH state, to make a cell change to a radio access technology other than UTRAN, e.g. GSM.

To initiate the procedure, UTRAN sends a CELL CHANGE ORDER FROM UTRAN message.

8.3.11.3 Reception of an CELL CHANGE ORDER FROM UTRAN message by the UE

The UE shall be able to receive a CELL CHANGE ORDER FROM UTRAN message and perform a cell change order to another RAT, even if no prior UE measurements have been performed on the target cell.

If the variable ESTABLISHED_SIGNALLING_CONNECTIONS does not include the CN domain identity "PS domain", or if the variable ESTABLISHED_SIGNALLING_CONNECTIONS includes the CN domain identity "CS domain":

1> the UE shall act as if the message was never received.

The UE shall:

- 1> if HS-DSCH is configured for UTRA:
 - 2> stop any HS-DSCH reception procedures;
 - 2> clear any stored HS-PDSCH configuration;
 - 2> act as if the IE "MAC-hs reset indicator" is received and set to TRUE;

- 2> release all HARQ resources;
- 2> remove any H-RNTI stored;
- 2> clear the variable H RNTI;
- 2> set the variable HS_DSCH_RECEPTION to FALSE.
- 1> if the UE has a pending "TGPS reconfiguration CFN" at the activation time received in the CELL CHANGE ORDER FROM UTRAN message the UE may:
 - 2> abort the pending CM activation;
 - 2> set the CM_PATTERN_ACTIVATION_ABORTED to TRUE.
- 1> otherwise:
 - 2> set the CM_PATTERN_ACTIVATION_ABORTED to FALSE.
- 1> start timer T309; and
- 1> establish the connection to the other radio access technology, as specified within IE "Target cell description". This IE specifies the target cell identity, in accordance with the specifications for that other RAT. In case the target cell is a GSM/ GPRS cell, IE "Target cell description" may also include IE "NC mode", which specifies the cell selection mode to be applied in the target cell; and
- 1> if IE "NC mode" is not included in the CELL CHANGE ORDER FROM UTRAN:
 - 2> retrieve it from the target cell as specified in [43];
 - 2> act upon IE "NC mode" as specified in [43].
- 1> if the IE "RAB Information List" is included in the CELL CHANGE ORDER FROM UTRAN message:
 - 2> ignore the contents of the IE "RAB Information List".
- NOTE: Requirements concerning the establishment of the radio connection towards the other radio access technology and the signalling procedure are outside the scope of this specification. In case of GSM/GPRS proceed according to the procedure Network control cell reselection procedure as specified in [44].
- 1> if the UE supports UTRAN to GERAN Network Assisted Cell Change, the IE "Geran-System Information" is present and the UE is in CELL_DCH state:
 - 2> if according to [44] the IE "GERAN System Information" includes a correct and consistent set of SI or PSI messages:
- 3> use this information as the system information to begin access on the target GERAN cell.
 - 2> otherwise:
- 3> ignore the IE "GERAN System Information" and continue the Cell Change Order procedure.

8.3.11.4 Successful completion of the cell change order

The UE regards the procedure as completed when it has received a successful response from the target RAT, e.g. in case of GSM when it received the response to a (PACKET) CHANNEL REQUEST in the new cell.

Upon successful completion of the cell change order, the UE shall:

- 1> stop timer T309;
- 1> clear or set variables upon leaving UTRA RRC connected mode as specified in subclause 13.4.

Upon indication of the UE having successfully completed the cell change order, UTRAN should:

1> release the radio connection; and

1> remove all context information for the concerned UE.

NOTE: The release of the UMTS radio resources is initiated from another RAT.

8.3.11.5 Expiry of timer T309 or UE fails to complete requested cell change order

If:

- timer T309 expires prior to the successful establishment of a connection to the target RAT; or
- if the establishment of the connection to the other RAT failed due to other reasons e.g. (random) access failure, rejection due to lack of resources:

the UE shall:

- 1> if it received the CELL CHANGE ORDER FROM UTRAN message in state CELL_DCH:
 - 2> if the CM_PATTERN_ACTIVATION_ABORTED flag is not set to TRUE:
- 3> revert back to the UTRA configuration;
 - NOTE: If configured for HS-DSCH while in UTRA, the UE will have still stored the IEs "Added or Reconfigured MAC-d flow" and "RB mapping Info".
- 3> establish the UTRA physical channel(s) used at the time for reception of CELL CHANGE ORDER FROM UTRAN.
 - 2> perform the physical layer synchronisation procedure A as specified in [29] (FDD only);
 - 2> after the establishment of the uplink physical channel, send DPCCH and no DPDCH according to [26] during the number of frames indicated in the IE "PC preamble" in the variable LATEST_CONFIGURED_SRB_DELAY_AND_PC_PREAMBLE; and
 - 2> then not send any data on signalling radio bearers RB0 to RB4 during the number of frames indicated in the IE "SRB delay" in the variable LATEST_CONFIGURED_SRB_DELAY_AND_PC_PREAMBLE;
 - 2> if the CM_PATTERN_ACTIVATION_ABORTED flag is set to TRUE or if the UE does not succeed in establishing the UTRA physical channel(s):
- 3> perform a cell update procedure according to subclause 8.3.1 with cause "Radio link failure";
- 3> when the cell update procedure has completed successfully:
 - 4> proceed as below.
 - 2> transmit the CELL CHANGE ORDER FROM UTRAN FAILURE message setting the information elements as specified below:
- 3> include the IE "RRC transaction identifier"; and
- 3> set it to the value of "RRC transaction identifier" in the entry for the received message in the table "Accepted transactions" in the variable TRANSACTIONS; and
- 3> clear that entry;
- 3> set the IE "Inter-RAT change failure" to "physical channel failure".
 - 2> When the CELL CHANGE ORDER FROM UTRAN FAILURE message has been submitted to lower layer for transmission, the procedure ends.
 - 1> if the UE receives the CELL CHANGE ORDER FROM UTRAN message in CELL_FACH state:
 - 2> revert to the cell it was camped on at the reception of the CELL CHANGE ORDER FROM UTRAN message;
 - 2> if the UE is unable to return to this cell:

- 3> select a suitable UTRA cell according to [4];
- 3> initiate the cell update procedure according to subclause 8.3.1 using the cause "cell re-selection";
- 3> when the cell update procedure completed successfully:
 - 4> proceed as below.
 - 2> transmit the CELL CHANGE ORDER FROM UTRAN FAILURE message setting the information elements as specified below:
- 3> include the IE "RRC transaction identifier"; and
- 3> set it to the value of "RRC transaction identifier" in the entry for the CELL CHANGE ORDER FROM UTRAN message in the table "Accepted transactions" in the variable TRANSACTIONS; and
- 3> clear that entry;
- 3> set the IE "Inter-RAT change failure" to "physical channel failure".
 - 2> When the CELL CHANGE ORDER FROM UTRAN FAILURE message has been submitted to lower layer for transmission:
- 3> the procedure ends.

8.3.11.6 Unsupported configuration in CELL CHANGE ORDER FROM UTRAN message

If the UTRAN instructs the UE to perform a non-supported cell change order scenario or to use a non-supported configuration, the UE shall:

- 1> transmit a CELL CHANGE ORDER FROM UTRAN FAILURE message, setting the information elements as specified below:
 - 2> include the IE "RRC transaction identifier"; and
 - 2> set it to the value of "RRC transaction identifier" in the entry for the received message in the table "Accepted transactions" in the variable TRANSACTIONS; and
 - 2> clear that entry;
 - 2> set the IE "Inter-RAT change failure" to "configuration unacceptable";
 - 2> when the CELL CHANGE ORDER FROM UTRAN FAILURE message has been submitted to lower layers for transmission:
- 3> resume normal operation as if the CELL CHANGE ORDER FROM UTRAN message has not been received;
- 3> and the procedure ends.

8.3.11.7 Invalid CELL CHANGE ORDER FROM UTRAN message

If the CELL CHANGE ORDER FROM UTRAN message contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

- 1> set the IE "RRC transaction identifier" in the CELL CHANGE ORDER FROM UTRAN FAILURE message to the value of "RRC transaction identifier" in the entry for the CELL CHANGE ORDER FROM UTRAN message in the table "Rejected transactions" in the variable TRANSACTIONS; and
- 1> clear that entry;
- 1> set the IE "Inter-RAT change failure" to the cause value "protocol error";
- 1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION;

- 1> transmit a CELL CHANGE ORDER FROM UTRAN FAILURE message on the uplink DCCH using AM RLC;
- 1> when the CELL CHANGE ORDER FROM UTRAN FAILURE message has been submitted to lower layers for transmission:
 - 2> resume normal operation as if the invalid CELL CHANGE ORDER FROM UTRAN message has not been received:
 - 2> and the procedure ends.

8.4 Measurement procedures

8.4.0 Measurement related definitions

UTRAN may control a measurement in the UE either by broadcast of SYSTEM INFORMATION and/or by transmitting a MEASUREMENT CONTROL message.

The following information is used to control the UE measurements and the measurement results reporting:

- 1. **Measurement identity**: A reference number that should be used by the UTRAN when setting up, modifying or releasing the measurement and by the UE in the measurement report.
- 2. **Measurement command**: One out of three different measurement commands.
 - Setup: Setup a new measurement.
 - Modify: Modify a previously defined measurement, e.g. to change the reporting criteria.
 - Release: Stop a measurement and clear all information in the UE that are related to that measurement.
- 3. **Measurement type**: One of the types listed below describing what the UE shall measure.

Presence or absence of the following control information depends on the measurement type

- 4. **Measurement objects:** The objects on which the UE shall measure measurement quantities, and corresponding object information.
- 5. **Measurement quantity:** The quantity the UE shall measure on the measurement object. This also includes the filtering of the measurements.
- 6. **Reporting quantities:** The quantities the UE shall include in the report in addition to the quantities that are mandatory to report for the specific event.
- 7. **Measurement reporting criteria**: The triggering of the measurement report, e.g. periodical or event-triggered reporting.
- 8. **Measurement Validity**: Defines in which UE states the measurement is valid.
- Measurement reporting mode: This specifies whether the UE shall transmit the measurement report using AM or UM RLC.
- 10. **Additional measurement identities**: A list of references to other measurements. When this measurement triggers a measurement report, the UE shall also include the reporting quantities for the measurements referenced by the additional measurement identities.

All these measurement parameters depend on the measurement type and are described in more detail in clause 14.

The different types of measurements are:

- **Intra-frequency measurements**: measurements on downlink physical channels at the same frequency as the active set. A measurement object corresponds to one cell. Detailed description is found in subclause 14.1.
- **Inter-frequency measurements**: measurements on downlink physical channels at frequencies that differ from the frequency of the active set and on downlink physical channels in the active set. A measurement object corresponds to one cell. Detailed description is found in subclause 14.2.

- **Inter-RAT measurements**: measurements on downlink physical channels belonging to another radio access technology than UTRAN, e.g. GSM. A measurement object corresponds to one cell. Detailed description is found in subclause 14.3.
- **Traffic volume measurements**: measurements on uplink traffic volume. A measurement object corresponds to one cell. Detailed description is found in subclause 14.4.
- Quality measurements: Measurements of downlink quality parameters, e.g. downlink transport block error rate. A measurement object corresponds to one transport channel in case of BLER. A measurement object corresponds to one timeslot in case of SIR (TDD only). Detailed description is found in subclause 14.5.
- **UE-internal measurements**: Measurements of UE transmission power and UE received signal level. Detailed description is found in subclause 14.6.
- **UE positioning measurements:** Measurements of UE position. Detailed description is found in subclause 14.7.

The UE shall support a number of measurements running in parallel as specified in [19] and [20]. The UE shall also support that each measurement is controlled and reported independently of every other measurement.

Cells that the UE is monitoring are grouped in the UE into three mutually exclusive categories:

- 1. Cells, which belong to the **active set.** User information is sent from all these cells. In FDD, the cells in the active set are involved in soft handover. In TDD the active set always comprises one cell only. The UE shall only consider active set cells included in the variable CELL_INFO_LIST for measurement; i.e. active set cells not included in the CELL_INFO_LIST shall not be considered in any event evaluation and measurement reporting.
- 2. Cells, which are not included in the active set, but are included in the CELL_INFO_LIST belong to the **monitored set.**
- 3. Cells detected by the UE, which are neither in the CELL_INFO_LIST nor in the active set belong to the **detected set.** Reporting of measurements of the detected set is only applicable to intra-frequency measurements made by UEs in CELL_DCH state.

If the IE "Cells for measurement" has been included in a MEASUREMENT CONTROL message, only monitored set cells explicitly indicated for a given intra-frequency (resp. inter-frequency, interRAT) measurement by the IE "Cells for measurement" shall be considered for measurement. If the IE "Cells for measurement" has not been included in a MEASUREMENT CONTROL message, all of the intra-frequency (resp. inter-frequency, inter RAT) cells stored in the variable CELL_INFO_LIST shall be considered for measurement. The IE "Cells for measurement" is not applicable to active set cells or virtual active set cells e.g. when the triggering condition refers to active set cells, the UE shall consider all active set cells in the CELL_INFO_LIST for measurement irrespective if these cells are explicitly indicated by the IE "Cells for measurement".

8.4.1 Measurement control



Figure 8.4.1-1: Measurement Control, normal case




Figure 8.4.1-2: Measurement Control, failure case

8.4.1.1 General

The purpose of the measurement control procedure is to setup, modify or release a measurement in the UE.

8.4.1.2 Initiation

The UTRAN may request a measurement by the UE to be setup, modified or released with a MEASUREMENT CONTROL message, which is transmitted on the downlink DCCH using AM RLC.

The UTRAN should take the UE capabilities into account when a measurement is requested from the UE.

When a new measurement is created, UTRAN should set the IE "Measurement identity" to a value, which is not used for other measurements. UTRAN may use several "Measurement identity" for the same "Measurement type". In case of setting several "Measurement identity" within a same "Measurement type", the measurement object or the list of measurement objects can be set differently for each measurement with different "Measurement identity".

When a current measurement is modified or released, UTRAN should set the IE "Measurement identity" to the value, which is used for the measurement being modified or released. In case of modifying IEs within a "Measurement identity", it is not needed for UTRAN to indicate the IEs other than modified IEs, and the UE continues to use the current values of the IEs that are not modified. UTRAN should not use "modify" to change the type of measurement stored in the variable MEASUREMENT_IDENTITY for a given measurement identity.

8.4.1.3 Reception of MEASUREMENT CONTROL by the UE

Upon reception of a MEASUREMENT CONTROL message the UE shall perform actions specified in subclause 8.6 unless otherwise specified below.

The UE shall:

- 1> read the IE "Measurement command";
- 1> if the IE "Measurement command" has the value "setup":
 - 2> store this measurement in the variable MEASUREMENT_IDENTITY according to the IE "measurement identity", first releasing any previously stored measurement with that identity if that exists;
 - 2> if the measurement type is quality, UE internal, intra-frequency, inter-frequency or inter-RAT:
- 3> if the UE is in CELL_FACH state:
 - 4> the UE behaviour is not specified.
 - 2> for measurement types "inter-RAT measurement" or "inter-frequency measurement" that require measurements on a frequency other than the actually used frequency:
- 3> if, according to its measurement capabilities, the UE requires compressed mode to perform that measurement type and after reception of this message a compressed mode pattern sequence with an appropriate measurement purpose is active according to the IE "Current TGPS Status Flag" in UE variable TGPS_IDENTITY; or

- 3> if, according to its measurement capabilities, the UE does not require compressed mode to perform the measurements on at least one supported band of that measurement type:
 - 4> if the measurement is valid in the current RRC state of the UE:
 - 5> begin measurements according to the stored control information for this measurement identity.
 - NOTE: The UE is not required to perform measurements on cells for which it needs compressed mode but a suitable compressed mode pattern is not activated.
 - 2> for measurement type "inter-frequency measurement" that requires measurements only on the same frequency as the actually used frequency:
- 3> if the measurement is valid in the current RRC state of the UE:
 - 4> begin measurements according to the stored control information for this measurement identity.
 - 2> for measurement type "UE positioning measurement":
- 3> if the UE is in CELL FACH state:
 - 4> if IE "Positioning Method" is set to "OTDOA":
 - 5> if IE "Method Type" is set to "UE assisted":
 - 6> if IE "UE positioning OTDOA assistance data for UE assisted" is not included:
 - 7> if System Information Block type 15.4 is broadcast:
 - 8> read System Information Block type 15.4.
 - 7> act as specified in subclause 8.6.7.19.2.
 - 5> if IE "Method Type" is set to "UE based":
 - 6> if IE "UE positioning OTDOA assistance data for UE based" is not included:
 - 7> if System Information Block type 15.5 is broadcast:
 - 8> read System Information Block type 15.5.
 - 7> act as specified in subclause 8.6.7.19.2a.
 - 2> for any other measurement type:
- 3> if the measurement is valid in the current RRC state of the UE:
 - 4> begin measurements according to the stored control information for this measurement identity.
 - 1> if the IE "Measurement command" has the value "modify":
 - 2> for all IEs present in the MEASUREMENT CONTROL message:
- 3> if a measurement was stored in the variable MEASUREMENT_IDENTITY associated to the identity by the IE "measurement identity":
 - 4> if the measurement type is quality, UE internal, intra-frequency, inter-frequency or inter-RAT:
 - 5> if the UE is in CELL_FACH state:
 - 6> the UE behaviour is not specified.
 - 4> if measurement type is set to "intra-frequency measurement", for any of the optional IEs "Intra-frequency measurement objects list", "Intra-frequency measurement quantity", "Intra-frequency reporting quantity", "Measurement Validity", "report criteria" and "parameters required for each event" (given "report criteria" is set to "intra-frequency measurement reporting criteria") that are present in the MEASUREMENT CONTROL message:

- 4> if measurement type is set to "inter-frequency measurement", for any of the optional IEs "Inter-frequency measurement quantity", "Inter-frequency reporting quantity", "Measurement Validity", "Inter-frequency set update" and "parameters required for each event" (given "report criteria" is set to either "inter-frequency measurement reporting criteria" or "intra-frequency measurement reporting criteria") that are present in the MEASUREMENT CONTROL message:
- 4> if measurement type is set to "inter-RAT measurement", for any of the optional IEs "Inter-RAT measurement objects list", "Inter-RAT measurement quantity", "Inter-RAT reporting quantity" and "parameters required for each event" (given "report criteria" is set to "inter-RAT measurement reporting criteria") that are present in the MEASUREMENT CONTROL message:
- 4> if measurement type is set to "UE positioning measurement" and the IE "UE positioning OTDOA assistance data" is present, for any of the optional IEs "UE positioning OTDOA neighbour cell info for UE-assisted", "UE positioning OTDOA reference cell info for UE-assisted", "UE positioning OTDOA neighbour cell info for UE-based" and "UE positioning" that are present in the MEASUREMENT CONTROL message:
- 4> if measurement type is set to "UE positioning measurement" and the IE "UE positioning GPS assistance data" is present, for any of the optional IEs "UE positioning GPS reference time", "UE positioning GPS reference UE position", "UE positioning GPS DGPS corrections", "UE positioning GPS ionospheric model", "UE positioning GPS UTC model", "UE positioning GPS acquisition assistance", "UE positioning GPS real-time integrity" that are present in the MEASUREMENT CONTROL message:
- 4> if measurement type is set to "traffic volume measurement", for any of the optional IEs "Traffic volume measurement Object", "Traffic volume measurement quantity", "Traffic volume reporting quantity", "Measurement Validity" and "parameters required for each event" (given "report criteria" is set to "traffic volume measurement reporting criteria") that are present in the MEASUREMENT CONTROL message:
- 4> if measurement type is set to "quality measurement", for any of the optional IE "Quality reporting quantity" that is present in the MEASUREMENT CONTROL message:
- 4> if measurement type is set to "UE internal measurement", for any of the optional IEs "UE internal measurement quantity", "UE internal reporting quantity" and "parameters required for each event" (given "report criteria" is set to "UE internal measurement reporting criteria") that are present in the MEASUREMENT CONTROL message:
 - 5> replace all instances of the IEs listed above (and all their children) stored in variable MEASUREMENT_IDENTITY associated to the identity indicated by the IE "measurement identity" with the IEs received in the MEASUREMENT CONTROL message;
 - 5> leave all other stored information elements unchanged in the variable MEASUREMENT_IDENTITY.

3> otherwise:

- 4> set the variable CONFIGURATION_INCOMPLETE to TRUE.
- 2> if measurement type is set to "inter-frequency measurement":
- 3> if "report criteria" is set to "intra-frequency measurement reporting criteria" and "reporting criteria" in "inter-frequency measurement quantity" is set to "intra-frequency reporting criteria":
 - 4> leave the currently stored "inter-frequency measurement reporting criteria" within "report criteria" and "inter-frequency reporting criteria" within "inter-frequency measurement quantity" unchanged, and continue to act on the information stored in these variables.
 - NOTE: If the UTRAN wants to modify the inter-frequency cell info list for an inter-frequency measurement configured with event based reporting without repeating any IEs related to the configured events, one possibility is to set the IE "report criteria" to "intra-frequency measurement reporting criteria", not include the IE "parameters required for each event", and set the IE "reporting criteria" in the IE "inter-frequency measurement quantity" to "intra-frequency reporting criteria".

- 2> for measurement types "inter-frequency measurement" that require measurements on a frequency other than the actually used frequency, or that require measurements on another RAT:
- 3> if, according to its measurement capabilities, the UE requires compressed mode to perform that measurement type and after reception of this message a compressed mode pattern sequence with an appropriate measurement purpose is active according to the IE "Current TGPS Status Flag" in UE variable TGPS_IDENTITY; or
- 3> if, according to its measurement capabilities, the UE does not require compressed mode, on at least one supported band of that measurement type, to perform the measurements:
 - 4> resume the measurements according to the new stored measurement control information.
 - 2> for measurement type "inter-frequency measurement" that requires measurements only on the same frequency as the actually used frequency:
- 3> if the measurement is valid in the current RRC state of the UE:
 - 4> resume measurements according to the new stored control information for this measurement identity.
 - 2> for any other measurement type:
- 3> resume the measurements according to the new stored measurement control information.
 - 1> if the IE "measurement command" has the value "release":
 - 2> terminate the measurement associated with the identity given in the IE "measurement identity";
 - 2> clear all stored measurement control information related associated to this measurement identity in variable MEASUREMENT_IDENTITY.
 - 1> if the IE "DPCH Compressed Mode Status Info" is present:
 - 2> if, as the result of this message, UE will have more than one transmission gap pattern sequence with the same measurement purpose active (according to IEs "TGMP" and "Current TGPS Status Flag" in variable TGPS_IDENTITY):
- 3> set the variable CONFIGURATION_INCOMPLETE to TRUE.
 - 2> if there is any pending "TGPS reconfiguration CFN" or any pending "TGCFN":
- 3> the UE behaviour is unspecified.
 - 2> if there is a pending "activation time" for a reconfiguration procedure that included the IE "DPCH Compressed mode info":
- 3> the UE behaviour is unspecified.
 - 2> if pattern sequence corresponding to IE "TGPSI" is already active (according to "Current TGPS Status Flag") in the variable TGPS_IDENTITY):
- 3> if the "TGPS Status Flag" in this message is set to "deactivate" for the corresponding pattern sequence:
 - 4> deactivate this pattern sequence at the beginning of the frame indicated by IE "TGPS reconfiguration CFN" received in the message;
 - 4> set the "Current TGPS Status Flag" for this pattern sequence in the variable TGPS_IDENTITY to "inactive" at the frame indicated by IE "TGPS reconfiguration CFN" received in the message.
- 3> if the "TGPS Status Flag" in this message is set to "activate" for the corresponding pattern sequence:
 - 4> deactivate this pattern sequence at the beginning of the frame indicated by IE "TGPS reconfiguration CFN" received in the message.
 - NOTE1: The temporary deactivation of pattern sequences for which the status flag is set to "activate" can be used by the network to align the timing of already active patterns with newly activated patterns.

- NOTE2: The deactivation of pattern sequences only occurs as a result of RRC messages received by the UE, i.e. the UE does not set the "Current TGPS Status Flag" to "inactive" after the final gap of a finite length pattern sequence.
 - 2> after the time indicated by IE "TGPS reconfiguration CFN" has elapsed:
- 3> activate the pattern sequence corresponding to each IE "TGPSI" for which the "TGPS status flag" in this message is set to "activate" at the time indicated by IE "TGCFN"; and
- 3> set the corresponding "Current TGPS status flag" for this pattern sequence in the variable TGPS_IDENTITY to "active"; and
- 3> begin the inter-frequency and/or inter-RAT measurements corresponding to the pattern sequence measurement purpose of each activated pattern sequence;
- 3> if the values of IE "TGPS reconfiguration CFN" and IE "TGCFN" are equal:
 - 4> start the concerned pattern sequence immediately at that CFN.
 - 2> not alter pattern sequences stored in variable TGPS_IDENTITY, if the pattern sequence is not identitifed in IE "TGPSI" in the received message.
 - 1> if the UE in CELL_FACH state receives a MEASUREMENT CONTROL message, which indicates the same measurement identity as that stored in the variable MEASUREMENT_IDENTITY:
 - 2> update the stored information with the traffic volume measurement control information in variable MEASUREMENT_IDENTITY; and
 - 2> refrain from updating the traffic volume measurement control information associated with this measurement identity in the variable MEASUREMENT_IDENTITY with the information received in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11) until this measurement is explicitly released with another MEASUREMENT CONTROL message.
 - 1> if the IE "Read SFN indicator" included in the IE "Cell info" of an inter-frequency cell is set to TRUE and the variable UE_CAPABILITY_TRANSFERRED has the DL "Measurement capability" for "FDD measurements" set to TRUE (the UE requires DL compressed mode in order to perform measurements on FDD):
 - 2> set the variable CONFIGURATION_INCOMPLETE to TRUE.
 - 1> clear the entry for the MEASUREMENT CONTROL message in the table "Accepted transactions" in the variable TRANSACTIONS.

The UE may:

- 1> if the IE "Measurement command" has the value "setup":
 - 2> for measurement type "UE positioning measurement":
- 3> if the UE is CELL FACH state:
 - 4> if IE "Positioning Method" is set to "GPS":
 - 5> if IE "UE positioning GPS assistance data" is not included and variable UE_POSITIONING_GPS_DATA is empty:
 - 6> if System Information Block types 15, 15.1, 15.2 and 15.3 are broadcast:
 - 7> read System Information Block types 15, 15.1, 15.2 and 15.3.
 - 6> act as specified in subclause 8.6.7.19.3.
 - 1> and the procedure ends.

8.4.1.4 Unsupported measurement in the UE

If UTRAN instructs the UE to perform a measurement that is not supported by the UE, the UE shall:

- 1> retain the measurement configuration that was valid before the MEASUREMENT CONTROL message was received:
- 1> set the IE "RRC transaction identifier" in the MEASUREMENT CONTROL FAILURE message to the value of "RRC transaction identifier" in the entry for the MEASUREMENT CONTROL message in the table "Accepted transactions" in the variable TRANSACTIONS; and
- 1> clear that entry.
- 1> set the cause value in IE "failure cause" to "unsupported measurement";
- 1> submit the MEASUREMENT CONTROL FAILURE message to lower layers for transmission on the DCCH using AM RLC;
- 1> continue with any ongoing processes and procedures as if the invalid MEASUREMENT CONTROL message has not been received:
- 1> and the procedure ends.

8.4.1.4a Configuration Incomplete

If the variable CONFIGURATION INCOMPLETE is set to TRUE, the UE shall:

- 1> retain the measurement configuration that was valid before the MEASUREMENT CONTROL message was received;
- 1> set the IE "RRC transaction identifier" in the MEASUREMENT CONTROL FAILURE message to the value of "RRC transaction identifier" in the entry for the MEASUREMENT CONTROL message in the table "Accepted transactions" in the variable TRANSACTIONS and clear that entry;
- 1> clear the variable CONFIGURATION_INCOMPLETE;
- 1> set the cause value in IE "failure cause" to "Configuration incomplete";
- 1> submit the MEASUREMENT CONTROL FAILURE message to lower layers for transmission on the DCCH using AM RLC;
- 1> continue with any ongoing processes and procedures as if the invalid MEASUREMENT CONTROL message has not been received;
- 1> and the procedure ends.

8.4.1.5 Invalid MEASUREMENT CONTROL message

If the MEASUREMENT CONTROL message contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

- 1> set the IE "RRC transaction identifier" in the MEASUREMENT CONTROL FAILURE message to the value of "RRC transaction identifier" in the entry for the MEASUREMENT CONTROL message in the table "Rejected transactions" in the variable TRANSACTIONS; and
- 1> clear that entry.
- 1> set the IE "failure cause" to the cause value "protocol error";
- 1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION;
- 1> submit the MEASUREMENT CONTROL FAILURE message to lower layers for transmission on the DCCH using AM RLC;
- 1> continue with any ongoing processes and procedures as if the invalid MEASUREMENT CONTROL message has not been received;

1> and the procedure ends.

8.4.1.6 Measurements after transition from CELL_DCH to CELL FACH/CELL PCH/URA PCH state

The UE shall apply the following rules for different measurement types after transiting from CELL_DCH to CELL FACH/CELL PCH/URA PCH state:

8.4.1.6.1 Intra-frequency measurement

Upon transition from CELL_DCH to CELL_FACH/CELL_PCH/URA_PCH state, the UE shall:

- 1> stop intra-frequency type measurement reporting;
- 1> if the transition is due to a reconfiguration message which included the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD), and the UE selects a cell other than that indicated by this IE on the current frequency (in case the IE "Frequency info" is not received) or other than that indicated by this IE on the frequency indicated by the IE "Frequency info" (when the IE "Frequency info" is included); or
- 1> if the transition is due to a reconfiguration message which does not include the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD); or
- 1> if the transition is not due to a reconfiguration message:
 - 2> delete the measurements of type intra-frequency associated with the variable MEASUREMENT_IDENTITY.
- 1> begin monitoring cells listed in the IE "intra-frequency cell info list" received in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11).

8.4.1.6.2 Inter-frequency measurement

Upon transition from CELL_DCH to CELL_FACH/ CELL_PCH/URA_PCH state, the UE shall:

- 1> stop the inter-frequency type measurement reporting assigned in a MEASUREMENT CONTROL message;
- 1> if the transition is due to a reconfiguration message which included the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD), and the UE selects a cell other than that indicated by this IE on the current frequency (in case the IE "Frequency info" is not received) or other than that indicated by this IE on the frequency indicated by the IE "Frequency info" (when the IE "Frequency info" is included); or
- 1> if the transition is due to a reconfiguration message which does not include the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD); or
- 1> if the transition is not due to a reconfiguration message:
 - 2> delete the measurements of type inter-frequency associated with the variable MEASUREMENT_IDENTITY and delete the corresponding compressed mode pattern.
- 1> for remaining compressed mode patterns, set the IE "TGPS Status Flag" to "deactivate" and the IE "Current TGPS Status Flag" to "inactive" in the variable TGPS_IDENTITY.
- 1> begin monitoring cells listed in the IE "inter-frequency cell info list" received in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11);
- 1> in CELL_FACH state:
 - 2> perform measurements on other frequencies according to the IE "FACH measurement occasion info".

8.4.1.6.3 Inter-RAT measurement

Upon transition from CELL DCH to CELL FACH/CELL PCH/URA PCH state, the UE shall:

1> stop the inter-RAT type measurement reporting assigned in a MEASUREMENT CONTROL message;

- 1> delete the measurements of type inter-RAT associated with the variable MEASUREMENT_IDENTITY and delete the corresponding compressed mode pattern;
- 1> begin monitoring cells listed in the IE "inter-RAT cell info list" received in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11);
- 1> in CELL FACH state:
 - 2> perform measurements on other systems according to the IE "FACH measurement occasion info".

8.4.1.6.4 Quality measurement

Upon transition from CELL_DCH to CELL_FACH/CELL_PCH/URA_PCH state, the UE shall:

- 1> stop quality type measurement reporting;
- 1> delete all measurement control information of measurement type "quality" stored in the variable MEASUREMENT_IDENTITY.

8.4.1.6.5 UE internal measurement

Upon transition from CELL_DCH to CELL_FACH/CELL_PCH/URA_PCH state, the UE shall:

- 1> stop UE internal measurement type measurement reporting;
- 1> delete all measurement control information of measurement type "UE internal" stored in the variable MEASUREMENT_IDENTITY.

8.4.1.6.6 Traffic volume measurement

Upon transition from CELL_DCH to CELL_FACH or CELL_PCH or URA_PCH state, the UE shall:

- 1> retrieve each set of measurement control information of measurement type "traffic volume" stored in the variable MEASUREMENT_IDENTITY; and
 - 2> if the optional IE "measurement validity" for this measurement has not been included:
- 3> delete the measurement associated with the variable MEASUREMENT_IDENTITY.
 - 2> if the IE "measurement validity" for the measurement has been included, and the IE "UE state" has been assigned to value "CELL_DCH":
- 3> stop measurement reporting;
- 3> store the measurement associated with the variable MEASUREMENT_IDENTITY to be used after the next transition to CELL_DCH state.
 - 2> if the IE "measurement validity" for the measurement has been included, and the IE "UE state" has been assigned to value "all states":
- 3> continue measurement reporting.
 - 2> if the IE "measurement validity" has been included and the IE "UE state" has been assigned to value "all states except CELL_DCH":
- 3> resume this measurement and associated reporting.
 - 1> if no traffic volume type measurement has been assigned to the UE with a MEASUREMENT CONTROL message that is valid in CELL_FACH or CELL_PCH or URA_PCH states (stored in the variable MEASUREMENT_IDENTITY), which has the same identity as the one indicated in the IE "Traffic volume measurement system information":
 - 2> store the measurement control information from the IE "Traffic volume measurement system information" received in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11) in the variable MEASUREMENT_IDENTITY;

2> begin traffic volume measurement reporting according to the assigned information.

8.4.1.6.7 UE positioning measurement

Upon transition from CELL_DCH to CELL_FACH and upon transition from CELL_DCH to CELL_PCH or URA_PCH for UE assisted GPS measurements, the UE shall:

- 1> retrieve each set of measurement control information of measurement type "UE positioning" stored in the variable MEASUREMENT_IDENTITY; and
 - 2> if the optional IE "measurement validity" for this measurement has not been included:
- 3> delete the measurement associated with the variable MEASUREMENT_IDENTITY.
 - 2> if the IE "measurement validity" for the measurement has been included, and the IE "UE state" has been assigned to value "CELL_DCH":
- 3> stop measurement reporting;
- 3> store the measurement associated with the variable MEASUREMENT_IDENTITY to be used after the next transition to CELL_DCH state.
 - 2> if the IE "measurement validity" for the measurement has been included, and the IE "UE state" has been assigned to value "all states":
- 3> upon transition from CELL DCH to CELL PCH or URA PCH:
 - 4> if the choice in the IE "Reporting Criteria" included the IE "UE Positioning measurement" stored in the variable MEASUREMENT_IDENTITY is set to "UE positioning reporting criteria" and the value of the IE "Measurement interval" included in this IE is less than 64 seconds:
 - 5> consider the value of the IE "Measurement interval" as being 64 seconds;
 - 4> if the choice in the IE "Reporting Criteria" included the IE "UE Positioning measurement" stored in the variable MEASUREMENT_IDENTITY is set to "Periodical Reporting Criteria" and the value of the IE "Reporting interval" included in this IE is less than 64 seconds:
 - 5> consider the value of the IE "Reporting Interval" as being 64 seconds
- 3> continue measurement reporting according to its UE positioning measurement reporting capability.
 - 2> if the IE "measurement validity" has been included and the IE "UE state" has been assigned to value "all states except CELL_DCH":
- 3> upon transition from CELL_DCH to CELL_PCH or URA_PCH:
 - 4> if the choice in the IE "Reporting Criteria" included the IE "UE Positioning measurement" stored in the variable MEASUREMENT_IDENTITY is set to "UE positioning reporting criteria" and the value of the IE "Measurement interval" included in this IE is less than 64 seconds:
 - 5> consider the value of the IE "Measurement interval" as being 64 seconds.
 - 4> if the choice in the IE "Reporting Criteria" included the IE "UE Positioning measurement" stored in the variable MEASUREMENT_IDENTITY is set to "Periodical Reporting Criteria" and the value of the IE "Reporting interval" included in this IE is less than 64 seconds:
 - 5> consider the value of the IE "Reporting Interval" as being 64 seconds.
- 3> resume this measurement and associated reporting according to its UE Positioning measurement reporting capability.
 - 1> if the transition is due to a reconfiguration message which included the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD), and the UE selects a cell other than that indicated by this IE; or
 - 1> if the transition is due to a reconfiguration message which does not include the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD); or

- 1> if the transition is due to a reconfiguration message which included the IE "Frequency info", and the UE selects a cell on another frequency than that indicated by this IE; or
- 1> if the transition is due to a reconfiguration message which does not include the IE "Frequency info", and the UE can not find a cell on the current frequency, but it selects a cell on another frequency; or
- 1> if the transition is not due to a reconfiguration message:
 - 2> delete the assistance data included in the variable UE_POSITIONING_OTDOA_DATA_UE_BASED and UE_POSITIONING_OTDOA_DATA_UE_ASSISTED.
- 1> if the IE "Positioning Methods" stored in the variable MEASUREMENT_IDENTITY is set to "OTDOA" or "OTDOA or GPS":
 - 2> if the IE "Method type" stored in the variable MEASUREMENT_IDENTITY is set to "UE-based" or "UE assisted preferred but UE-based allowed" or "UE-based preferred but UE-assisted allowed":
- 3> begin monitoring assistance data received in System Information Block type 15.4 and System Information Block type 15.5 according to subclause 8.1.1.6.15.
 - 2> if the IE "Method type" stored in the variable MEASUREMENT_IDENTITY is set to "UE-assisted":
- 3> begin monitoring assistance data received in System Information Block type 15.4 according to subclause 8.1.1.6.15.
 - 1> if the UE is in CELL_FACH state:
 - 2> if the IE "UE positioning OTDOA neighbour cell list for UE assisted" stored in the variable UE_POSITIONING_OTDOA_DATA_UE_ASSISTED or UE_POSITIONING_OTDOA_DATA_UE_BASED contains neighbour cells on other frequencies than the current frequency:
- 3> perform measurements on other frequencies according to the IE "FACH measurement occasion info".

The UE may:

- 1> if the IE "Positioning Methods" stored in the variable MEASUREMENT_IDENTITY is set to "GPS" or "OTDOA or GPS":
 - 2> begin monitoring assistance data received in System Information Block type 15 and/or System Information Block type 15.1 and/or System Information Block type 15.2 and/or System Information Block type 15.3 according to subclause 8.1.1.6.15.

8.4.1.6a Actions in CELL_FACH/CELL_PCH/URA/PCH state upon cell re-selection

Upon cell reselection while in CELL_FACH/CELL_PCH/URA/PCH state and the cell reselection has occurred after the measurement control information was stored, the UE shall:

- 1> delete all measurements of type intra-frequency, inter-frequency, and inter-RAT associated with the variable MEASUREMENT_IDENTITY;
- 1> delete all compressed mode patterns associated with inter-frequency and inter-RAT measurements;
- 1> delete the traffic volume measurements that have not been set up or modified through a MEASUREMENT CONTROL message.

8.4.1.7 Measurements after transition from CELL FACH to CELL DCH state

The UE shall apply the following rules for different measurement types after transiting from CELL_FACH to CELL_DCH state:

8.4.1.7.1 Intra-frequency measurement

Upon transition from CELL_FACH to CELL_DCH state:

- 1> if intra-frequency measurements applicable to CELL_DCH state are stored in the variable MEASUREMENT_IDENTITY:
 - 2> if the cell in which the UE transited from CELL_FACH state is included in the active set for the CELL_DCH state, the UE shall:
- 3> resume the measurement reporting.
 - 2> otherwise, the UE shall:

3> not resume the measurement reporting. The measurement shall be restarted when a MEASUREMENT CONTROL message is received with the corresponding measurement identity.

8.4.1.7.2 Inter-frequency measurement

Upon transition from CELL_FACH to CELL_DCH state:

- 1> if inter-frequency measurements applicable to CELL_DCH state are stored in the variable MEASUREMENT_IDENTITY:
 - 2> if the cell in which the UE transited from CELL_FACH state is included in the active set for the CELL_DCH state, the UE shall:
- 3> resume the measurement reporting.
 - 2> otherwise, the UE shall:
- 3> not resume the measurement reporting. The measurement shall be restarted when a MEASUREMENT CONTROL message is received with the corresponding measurement identity.

8.4.1.7.3 Inter-RAT measurement

Upon transition from CELL_FACH to CELL_DCH state, the UE shall:

1> stop monitoring the list of cells assigned in the IE "inter-RAT cell info list" in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11).

8.4.1.7.4 Traffic volume measurement

Upon transition from CELL_FACH to CELL_DCH state, the UE shall:

- 1> retrieve each set of measurement control information of measurement type "traffic volume" stored in the variable MEASUREMENT_IDENTITY;
 - 2> if the optional IE "measurement validity" for this measurement has not been included:
- 3> delete the measurement associated with the variable MEASUREMENT_IDENTITY.
 - 2> if the IE "measurement validity" for the measurement has been included, and the IE "UE state" has been assigned to value "all states except CELL DCH":
- 3> stop measurement reporting; and
- 3> save the measurement associated with the variable MEASUREMENT_IDENTITY to be used after the next transition to CELL FACH/CELL PCH/URA PCH state.
 - 2> if the IE "measurement validity" for the measurement has been included, and the IE "UE state" has been assigned to value "all states":
- 3> continue measurement reporting.
 - 2> if the IE "measurement validity" has been included and the IE "UE state" has been assigned to value "CELL_DCH":
- 3> resume this measurement and associated reporting.

- 1> if no traffic volume type measurement has been assigned to the UE with a MEASUREMENT CONTROL message that is valid in CELL_DCH and has the same identity as the one indicated in the IE "Traffic volume measurement system information":
 - 2> store the measurement control information from the IE "Traffic volume measurement system information" received in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11) in the variable MEASUREMENT_IDENTITY;
 - 2> begin traffic volume measurement reporting according to the assigned information.

8.4.1.7.5 UE positioning measurement

Upon transition from CELL_FACH to CELL_DCH state, the UE shall:

- 1> retrieve each set of measurement control information of measurement type "UE positioning" stored in the variable MEASUREMENT_IDENTITY; and
 - 2> if the optional IE "Measurement validity" for this measurement has not been included:
- 3> delete the measurement associated with the variable MEASUREMENT_IDENTITY.
 - 2> if the IE "measurement validity" for the measurement has been included, and the IE "UE state" has been assigned to value "all states except CELL_DCH":
- 3> stop measurement reporting; and
- 3> save the measurement associated with the variable MEASUREMENT_IDENTITY to be used after the next transition to CELL FACH/CELL PCH/URA PCH state.
 - 2> if the IE "measurement validity" for the measurement has been included, and the IE "UE state" has been assigned to value "all states":
- 3> continue measurement reporting.
 - 2> if the IE "measurement validity" has been included and the IE "UE state" has been assigned to value "CELL_DCH":
- 3> resume this measurement and associated reporting.
 - 1> stop monitoring assistance data received in System Information Block type 15 or System Information Block type 15.1 or System Information Block type 15.2 or System Information Block type 15.3 or System Information Block type 15.4 or System Information Block 15.5.

8.4.1.8 Measurements after transition from idle mode to CELL DCH state

The UE shall obey the following rules for different measurement types after transiting from idle mode to CELL_DCH state:

8.4.1.8.1 Intra-frequency measurement

Upon transition from idle mode to CELL_DCH state:

- 1> if intra-frequency measurements applicable to CELL_DCH state are stored in the variable MEASUREMENT_IDENTITY:
 - 2> if the cell in which the UE transited from idle mode is included in the active set for the CELL_DCH state, the UE shall:
- 3> begin measurement reporting.
 - 2> otherwise, the UE shall:
- 3> not begin the measurement reporting. The measurement shall be restarted when a MEASUREMENT CONTROL message is received with the corresponding measurement identity.

8.4.1.8.2 Inter-frequency measurement

Upon transition from idle mode to CELL_DCH state, the UE shall:

1> stop monitoring the list of cells assigned in the IE "inter-frequency cell info list" in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11).

8.4.1.8.3 Inter-RAT measurement

Upon transition from idle mode to CELL_DCH state, the UE shall:

1> stop monitoring the list of cells assigned in the IE "inter-RAT cell info list" in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11).

8.4.1.8.4 Traffic volume measurement

Upon transition from idle mode to CELL DCH state, the UE shall:

1> begin a traffic volume type measurement, assigned in System Information Block type 11 (or System Information Block type 12, according to subclause 8.1.1.6.11).

8.4.1.8.5 UE positioning measurement

Upon transition from idle mode to CELL_DCH state, the UE shall:

1> stop monitoring assistance data received in System Information Block type 15 or System Information Block type 15.1 or System Information Block type 15.2 or System Information Block type 15.3 or System Information Block type 15.4 or System Information Block type 15.5.

8.4.1.9 Measurements after transition from idle mode to CELL_FACH state

The UE shall obey the follow rules for different measurement types after transiting from idle mode to CELL_FACH state:

8.4.1.9.1 Intra-frequency measurement

Upon transition from idle mode to CELL_FACH state, the UE shall:

1> begin or continue monitoring cells listed in the IE "intra-frequency cell info list" received in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11).

8.4.1.9.2 Inter-frequency measurement

Upon transition from idle mode to CELL_FACH state, the UE shall:

- 1> begin or continue monitoring cells listed in the IE "inter-frequency cell info list" received in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11);
- 1> perform measurements on other frequencies according to the IE "FACH measurement occasion info".

8.4.1.9.3 Inter-RAT measurement

Upon transition from idle mode to CELL_FACH state, the UE shall:

- 1> begin or continue monitoring cells listed in the IE "inter-RAT cell info list" received in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11);
- 1> perform measurements on other systems according to the IE "FACH measurement occasion info".

8.4.1.9.4 Traffic volume measurement

Upon transition from idle mode to CELL_FACH state, the UE shall:

- 1> store the measurement control information from the IE "Traffic volume measurement system information" received in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11) in the variable MEASUREMENT_IDENTITY;
- 1> begin traffic volume measurement reporting according to the assigned information.

8.4.1.9.5 UE positioning measurement

Upon transition from idle mode to CELL_FACH state, the UE may:

- 1> begin or continue monitoring assistance data received in System Information Block type 15 or System Information Block type 15.1 or System Information Block type 15.2 or System Information Block type 15.3 or System Information Block type 15.4 or System Information Block type 15.5 according to subclause 8.1.1.6.15;
- 1> if the IE "UE positioning OTDOA neighbour cell list for UE assisted" stored in the variable UE_POSITIONING_OTDOA_DATA_UE_ASSISTED; or
- 1> if the IE "UE positioning OTDOA neighbour cell list for UE based" stored in the variable UE_POSITIONING_OTDOA_DATA_UE_BASED contains neighbour cells on other frequencies than the current frequency:
 - 2> perform measurements on other frequencies according to the IE "FACH measurement occasion info".

8.4.1.9a Measurements after transition from connected mode to idle mode

Upon transition from connected mode to idle mode the UE shall:

- 1> stop measurement reporting for all measurements stored in the variable MEASUREMENT_IDENTITY;
- 1> clear the variable MEASUREMENT_IDENTITY;
- 1> apply the following rules for different measurement types.

8.4.1.9a.1 Intra-frequency measurement

Upon transition from connected mode to idle mode, the UE shall:

- 1> stop monitoring intra-frequency cells listed in the IE "intra-frequency cell info list" received in System Information Block type 12 (if System Information Block type 12 is transmitted in the cell, according to subclause 8.1.1.6.11);
- 1> begin monitoring intra-frequency cells listed in the IE "intra-frequency cell info list" received in System Information Block type 11.

8.4.1.9a.2 Inter-frequency measurement

Upon transition from connected mode to idle mode, the UE shall:

- 1> stop monitoring inter-frequency cells listed in the IE "inter-frequency cell info list" received in System Information Block type 12 (if System Information Block type 12 is transmitted in the cell, according to subclause 8.1.1.6.11);
- 1> begin monitoring inter-frequency cells listed in the IE "inter-frequency cell info list" received in System Information Block type 11.

8.4.1.9a.3 Inter-RAT measurement

Upon transition from connected mode to idle mode, the UE shall:

- 1> stop monitoring inter-RAT cells listed in the IE "inter-RAT cell info list" received in System Information Block type 12 (if System Information Block type 12 is transmitted in the cell, according to 8.1.1.6.11);
- 1> begin monitoring inter-RAT cells listed in the IE "inter-RAT cell info list" received in System Information Block type 11.

8.4.1.9a.4 UE positioning measurement

Upon transition from connected mode to idle mode, the UE may:

1> begin or continue monitoring assistance data received in System Information Block type 15 or System Information Block type 15.1 or System Information Block type 15.2 or System Information Block type 15.3 or System Information Block type 15.4 or System Information Block type 15.5.

8.4.1.9b Measurements after transition from CELL_FACH to CELL_PCH/URA_PCH

8.4.1.9b.1 Traffic volume measurement

Upon transition from CELL_FACH to CELL_PCH, the UE shall stop any ongoing traffic volume measurement, and associated traffic volume measurement reporting.

8.4.1.9c Measurements after transition from CELL_PCH/URA_PCH to CELL_FACH

8.4.1.9c.1 Traffic volume measurement

Upon transition from CELL_PCH to CELL_FACH, the UE shall resume any traffic volume measurement stored in the variable MEASUREMENT_IDENTITY with measurement validity "all states" or "all states except CELL_DCH", and start the associated traffic volume measurement reporting.

8.4.1.10 Changes in measurement objects

8.4.1.10.1 Traffic volume measurement

When performing traffic volume event evaluation or reporting related to a certain transport channel, the UE shall consider all RBs which are mapped to the concerning transport channel e.g. if an additional RB is established on a transport channel used for event triggering or reporting, the new RB shall be taken into account.

NOTE: In this subclause, an "existing" uplink transport channel refers to a configured uplink transport channel applicable in the current RRC state.

The UE shall:

- 1> if the IE "Traffic volume measurement object" is included for this measurement:
 - 2> while a transport channel that is referenced in the IE "Traffic volume measurement object" does not exist:
- 3> not perform any reporting related to this transport channel.
 - 1> else:
 - 2> report on all existing uplink transport channels; e.g. if an additional transport channel is established while the measurement is ongoing, this new transport channel shall be taken into account in the traffic volume measurement reporting.

For every traffic volume event, the UE shall:

- 1> if the IE "Uplink transport channel type" is not included in the IE "Traffic volume measurement reporting criteria", or the "Uplink transport channel type" has the value "DCH" or "USCH" and the IE "UL transport channel id" is not included in the IE "Traffic volume measurement reporting criteria":
 - 2> if the IE "Traffic volume measurement object" is not included:
- 3> take all existing UL transport channels into account for event triggering; e.g. if an additional transport channel is established while the measurement is ongoing, this new transport channel shall be taken into account in the traffic volume event triggering.

2> else:

3> while a transport channel that is referenced in the IE "Traffic Volume Measurement object" does not exist:

4> not take this transport channel identity into account in the traffic volume measurement triggering.

1> else:

2> while a transport channel that is referenced in the IE "Traffic Volume Measurement Reporting Criteria" does not exist:

3> not take this transport channel identity into account in the traffic volume event triggering.

8.4.1.10.2 Quality measurement

While a transport channel that is explicitly referenced with a transport channel identity in the IE "Quality Reporting Quantity" does not exist, the UE shall:

1> not perform any reporting related to this transport channel identity.

If the IE "Quality Reporting Quantity" does not contain any explicit transport channel identities, the UE shall:

- 1> report the quality of all existing downlink dedicated transport channels;
- 1> if an additional transport channel is established while the measurement is ongoing:
 - 2> take into account this new transport channel in the quality measurement reporting.

While a transport channel that is explicitly referenced with a transport channel id in the IE "Quality Measurement Reporting Criteria" does not exist, the UE shall:

1> not take this transport channel identity into account in the quality measurement event triggering.

8.4.1.10.3 Intra-frequency, Inter-frequency and Inter-RAT measurements

For measurements which include the IE "Cells for measurement" the UE shall:

- 1> while an IE "Intra-frequency cell id" or IE "Inter-frequency cell id" or IE "Inter-RAT cell id" in the IE "Cells for measurement" points to a position in the variable CELL INFO LIST which is marked as "vacant":
 - 2> not take this position into account for event triggering and reporting.

8.4.2 Measurement report



Figure 8.4.2-1: Measurement report, normal case

8.4.2.1 General

The purpose of the measurement reporting procedure is to transfer measurement results from the UE to UTRAN.

8.4.2.2 Initiation

In CELL_DCH state, the UE shall:

1> transmit a MEASUREMENT REPORT message on the uplink DCCH when the reporting criteria stored in variable MEASUREMENT_IDENTITY are met for any ongoing measurements that are being performed in the UE.

In CELL FACH state, the UE shall:

1> transmit a MEASUREMENT REPORT message on the uplink DCCH when the reporting criteria stored in variable MEASUREMENT_IDENTITY are met for any ongoing traffic volume measurement or UE positioning measurement that is being performed in the UE.

In TDD, if the Radio Bearer associated with the MEASUREMENT_IDENTITY fulfilling the reporting criteria for an ongoing traffic volume measurement is mapped on transport channel of type USCH, the UE shall:

1> initiate the "PUSCH CAPACITY REQUEST" procedure instead of transmitting a MEASUREMENT REPORT (TDD Only).

In CELL_PCH or URA_PCH state, the UE shall:

- 1> first perform the cell update procedure according to subclause 8.3.1, using the cause "uplink data transmission", in order to transit to CELL FACH state; and then
- 1> transmit a MEASUREMENT REPORT message on the uplink DCCH when the reporting criteria stored in variable MEASUREMENT_IDENTITY are fulfilled for any ongoing UE positioning measurement which is being performed in the UE.

The reporting criteria are fulfilled if either:

- a periodic MEASUREMENT REPORT message shall be sent according to the IE "Periodical Reporting Criteria"; or
- an event in stored IE "Measurement reporting criteria" was triggered. Events and triggering of reports for different measurement types are described in detail in clause 14.

For the measurement, which triggered the MEASUREMENT REPORT message, the UE shall:

- 1> set the IE "measurement identity" to the measurement identity, which is associated with that measurement in variable MEASUREMENT_IDENTITY;
- 1> set the IE "measured results" to include measurements according to the IE "reporting quantity" of that measurement stored in variable MEASUREMENT_IDENTITY; and
 - 2> if all the reporting quantities are set to "false":
- 3> not set the IE "measured results".
 - 1> set the IE "Measured results" in the IE "Additional measured results" according to the IE "reporting quantity" for all measurements associated with the measurement identities included in the "Additional measurements list" stored in variable MEASUREMENT_IDENTITY of the measurement that triggered the measurement report; and
 - 2> if one or more additional measured results are to be included:
- 3> include only the available additional measured results, and sort them in ascending order according to their IE "measurement identity" in the MEASUREMENT REPORT message.
 - 1> if the MEASUREMENT REPORT message was triggered by an event (i.e. not a periodical report):
 - 2> set the IE "Event results" according to the event that triggered the report.
 - 1> if the observed time difference for one or more GSM cells is included in the MEASUREMENT REPORT message:
 - 2> set the IE "GSM OTD reference cell" to the primary CPICH info of the active set cell that was used as reference for the measurement.

The UE shall:

1> transmit the MEASUREMENT REPORT message on the uplink DCCH using either AM or UM RLC according to the stored IE "measurement reporting mode" associated with the measurement identity that triggered the report.

When the MEASUREMENT REPORT message has been submitted to lower layers for transmission:

1> the procedure ends.

8.4.3 Assistance Data Delivery



Figure 8.4.3-1 Assistance Data Delivery

8.4.3.1 General

The purpose of the assistance data delivery procedure is to transfer UE positioning related assistance data from the UTRAN to the UE.

8.4.3.2 Initiation

When requested by the Core Network, the UTRAN may deliver UE positioning related assistance data with a ASSISTANCE DATA DELIVERY message, which is transmitted on the downlink DCCH using AM RLC

8.4.3.3 Reception of ASSISTANCE DATA DELIVERY message by the UE

Upon reception of a ASSISTANCE DATA DELIVERY message the UE shall:

- 1> if IE "UE positioning OTDOA assistance data for UE-based" is included:
 - 2> act as specified in subclause 8.6.7.19.2a.
- 1> if IE "UE positioning GPS assistance data" is included:
 - 2> act as specified in subclause 8.6.7.19.3.

8.4.3.4 Invalid ASSISTANCE DATA DELIVERY message

If the UE receives a ASSISTANCE DATA DELIVERY message, which contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

- 1> transmit an RRC STATUS message on the uplink DCCH using AM RLC;
- 1> include the IE "Identification of received message"; and
- 1> set the IE "Received message type" to ASSISTANCE DATA DELIVERY; and
- 1> set the IE "RRC transaction identifier" to the value of "RRC transaction identifier" in the entry for the ASSISTANCE DATA DELIVERY message in the table "Rejected transactions" in the variable TRANSACTIONS; and
- 1> clear that entry;
- 1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION.
- 1> when the RRC STATUS message has been submitted to lower layers for transmission:

2> continue with any ongoing processes and procedures as if the invalid ASSISTANCE DATA DELIVERY message has not been received.

8.5 General procedures

8.5.1 Selection of initial UE identity

The purpose of the IE "Initial UE identity" is to provide a unique UE identification at the establishment of an RRC connection. The type of identity shall be selected by the UE according to the following.

Upper layers shall set the variable SELECTED_PLMN. If the variable SELECTED_PLMN in the UE indicates "GSM-MAP", the UE shall choose "UE id type" in the IE "Initial UE identity" with the following priority:

- 1. TMSI (GSM-MAP): The TMSI (GSM-MAP) shall be chosen if available. The IE "LAI" in the IE "Initial UE identity" shall also be present when TMSI (GSM-MAP) is used, for making it unique.
- 2. P-TMSI (GSM-MAP): The P-TMSI (GSM-MAP) shall be chosen if available and no TMSI (GSM-MAP) is available. The IE "RAI" in the IE "Initial UE identity" shall in this case also be present when P-TMSI (GSM-MAP) is used, for making it unique.
- 3. IMSI (GSM-MAP): The IMSI (GSM-MAP) shall be chosen if available and no TMSI (GSM-MAP) or P-TMSI is available.
- 4. IMEI: The IMEI shall be chosen when none of the above three conditions are fulfilled.

When being used, the IEs "TMSI (GSM-MAP)," "P-TMSI (GSM-MAP)", "IMSI (GSM-MAP)", "LAI" and "RAI" shall be set equal to the values of the corresponding identities stored in the USIM or SIM.

If the variable SELECTED_PLMN in the UE indicates "ANSI-41", the UE shall choose "UE id type" in the IE "Initial UE identity" according to the procedure specified in the 3GPP2 document "3GPP2 C.P0004-A".

8.5.2 Actions when entering idle mode from connected mode

When entering idle mode from connected mode, the UE shall:

- 1> clear or set variables upon leaving UTRA RRC connected mode as specified in subclause 13.4;
- 1> attempt to select a suitable cell to camp on.

When leaving connected mode according to [4], the UE shall:

1> perform cell selection.

While camping on a cell, the UE shall:

- 1> acquire system information according to the system information procedure in subclause 8.1;
- 1> perform measurements according to the measurement control procedure specified in subclause 8.4; and
- 1> if the UE is registered:
 - 2> be prepared to receive paging messages according to the paging procedure in subclause 8.2.

If IE "PLMN identity" within variable SELECTED_PLMN has the value "GSM-MAP", the UE shall:

- 1> delete any NAS system information received in connected mode;
- 1> acquire the NAS system information in system information block type 1; and
- 1> proceed according to subclause 8.6.1.2.

When entering idle mode, the UE shall:

1> if the USIM is present, for each CN domain:

- 2> if a new security key set was received for this CN domain but was not used either for integrity protection or ciphering during this RRC connection:
- 3> set the START value for this domain to zero; and
- 3> store this START value for this domain in the USIM.
 - 2> else:
- 3> if the current "START" value, according to subclause 8.5.9 for a CN domain, is greater than or equal to the value "THRESHOLD" of the variable START_THRESHOLD:
 - 4> delete the ciphering and integrity keys that are stored in the USIM for that CN domain;
 - 4> inform the deletion of these keys to upper layers.
- 3> else:
- 4> store the current "START" value for this CN domain on the USIM.
- NOTE: Prior to storing the "START" value, the UE should calculate this "START" value according to subclause 8.5.9.
- 1> else:
 - 2> if the SIM is present, for each CN domain:
- 3> if a new security key set was received for this CN domain but was not used either for integrity protection or ciphering during this RRC connection:
 - 4> set the START value for this domain to zero; and
 - 4> store this START value for this domain in the UE
- 3> else:
- 4> if the current "START" value, according to subclause 8.5.9 for this CN domain, is greater than or equal to the value "THRESHOLD" of the variable START_THRESHOLD:
 - 5> delete the Kc key for this CN domain;
 - 5> delete the ciphering and integrity keys that are stored in the UE for that CN domain;
 - 5> set the "START" values for this CN domain to zero and store it the UE;
 - 5> inform the deletion of the key to upper layers.
- 4> else:
 - 5> store the current "START" value for this CN domain in the UE.
- NOTE: Prior to storing the "START" value, the UE should calculate this "START" value according to subclause 8.5.9.

8.5.3 Open loop power control upon establishment of DPCCH

This procedure is used in FDD mode only.

When establishing the first DPCCH the UE shall start the UL inner loop power control at a power level according to:

1> DPCCH_Initial_power = DPCCH_Power_offset - CPICH_RSCP

Where

DPCCH_Power_offset shall have the value of IE "DPCCH Power offset" in IE "Uplink DPCH power control info"

The value for the CPICH_RSCP shall be measured by the UE.

8.5.4 Physical channel establishment criteria

When a physical dedicated channel establishment is initiated by the UE, the UE shall start a timer T312 and wait for layer 1 to indicate N312 "in sync" indications. On receiving N312 "in sync" indications, the physical channel is considered established and the timer T312 is stopped and reset.

If the timer T312 expires before the physical channel is established, the UE shall consider this as a "physical channel failure".

NOTE: The criteria defined in this subclause only apply in case the UE performs synchronisation procedure A (FDD only).

8.5.5 Actions in "out of service area" and "in service area"

This subclause specifies the general actions the UE shall perform when it detects "out of service" or "in service" area. The specific UE behaviour when it detects "out of service" or "in service area" and periodical update has been configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity" is specified in subclause 8.3.1.

8.5.5.1 Detection of "out of service" area

The UE shall detect "out of service" area as defined in [19].

8.5.5.1.1 Actions following detection of "out of service" area in URA_PCH or CELL PCH state

If the UE detects the "out of service area" and the UE is in URA_PCH or CELL_PCH state it shall perform the following actions:

1> start timer T316;

1> perform processes described in subclause 7.2.2.

8.5.5.1.2 Actions following detection of "out of service" area in CELL_FACH state

If the UE detects the "out of service area" and the UE is in CELL_FACH state it shall perform the following actions. The UE shall:

1> start timer T317 if not already running;

1> perform processes described in subclause 7.2.2.

8.5.5.1.3 Actions following detection of "out of service" area on transition from CELL_DCH to URA_PCH or CELL_PCH

If the UE detects the "out of service area" on transition from CELL_DCH to URA_PCH or CELL_PCH, it shall perform the following actions:

1> start timer T316;

1> start the timer T305 using its initial value if timer T305 is not running and periodical cell update has been configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity";

1> perform processes described in subclause 7.2.2.

8.5.5.1.4 Actions following detection of "out of service" area on transition from CELL_DCH to CELL_FACH

If the UE detects the "out of service area" on transition from CELL_DCH to CELL_FACH, it shall perform the following actions:

- 1> if the transition is triggered by a reconfiguration procedure:
 - 2> start timer T317;
 - 2> start the timer T305 using its initial value if timer T305 is not running and periodical cell update has been configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity";
 - 2> perform processes described in subclause 7.2.2.
- 1> otherwise:
 - 2> perform processes described in subclause 7.2.2.

8.5.5.2 Detection of "in service" area

When a suitable cell is found based on the description in [4], the UE considers it as having detected "in service area".

8.5.5.2.1 Actions following Re-entry into "in service area" in URA_PCH or CELL_PCH state

If the UE re-enters "in service area" before T316 expiry the UE shall perform the following actions. The UE shall:

- 1> stop T316;
- 1> if T307 is active:
 - 2> stop T307.
- 1> perform processes described in subclause 7.2.2.

8.5.5.2.2 Actions following re-entry into "in service area" in CELL_FACH state

If the UE detects "in service area" before T317 expiry the UE shall perform the following actions. If no cell update procedure or URA update procedure is ongoing, the UE shall:

- 1> stop T317;
- 1> if T307 is active:
 - 2> stop T307.
- 1> initiate the cell update procedure using as cause "Re-entering service area" as specified in subclause 8.3.1;
- 1> perform processes described in subclause 7.2.2.

If a cell update procedure or URA update procedure is ongoing, the UE shall:

- 1> stop T317;
- 1> perform the actions as specified in 8.3.1.

8.5.5.3 T316 expiry

On T316 expiry the UE shall perform the following actions. The UE shall:

1> if "out of service area" is detected:

- 2> start timer T317;
- 2> move to CELL FACH state;
- 2> perform processes described in subclause 7.2.2.
- 1> if "in service area" is detected:
 - 2> initiate the cell update procedure using as cause "Re-entering service area" as specified in subclause 8.3.1;
 - 2> perform processes described in subclause 7.2.2.

8.5.5.4 T317 expiry

T317 shall never expire, i.e. all its values shall be assumed to be "infinity".

If T317 is running:

1> the UE behaviour shall be as specified in subclause 7.2.2.2.

8.5.6 Radio link failure criteria and actions upon radio link failure

In CELL_DCH State, after receiving N313 consecutive "out of sync" indications from layer 1 for the established DPCCH physical channel in FDD, and the DPCH associated with mapped DCCHs in TDD, the UE shall:

- 1> start timer T313;
- 1> upon receiving N315 successive "in sync" indications from layer 1 and upon change of UE state:
 - 2> stop and reset timer T313.
- 1> if T313 expires:
 - 2> consider it as a "Radio link failure".

Periods in time where neither "in sync" nor "out of sync" is reported by layer 1 do not affect the evaluation of the number of consecutive (resp. successive) "in sync" or "out of sync" indications.

When a radio link failure occurs, the UE shall:

- 1> clear the dedicated physical channel configuration;
- 1> perform actions as specified for the ongoing procedure;
- 1> if no procedure is ongoing or no actions are specified for the ongoing procedure:
 - 2> perform a cell update procedure according to subclause 8.3.1 using the cause "radio link failure".

8.5.7 Open loop power control

For FDD and prior to PRACH or PCPCH transmission the UE shall:

- 1> acquire valid versions of the necessary System Information IEs as follows:
 - 2> if the UE has stored valid versions of the IEs "Primary CPICH Tx power" and "Constant value":
- 3> use the stored content of the IEs.
 - 2> otherwise:
- 3> read and store the IE "Primary CPICH Tx power" and "Constant value" in System Information Block type 6 (or System Information Block type 5, if System Information Block type 6 is not being broadcast).
 - 2> if the UE has a valid version of the IE "UL interference" stored:
- 3> use the stored content of the IE "UL interference".

- 2> otherwise:
- 3> read and store the IE "UL interference" in System Information Block type 7;
- 3> if the UE fails to read the IE "UL interference" in System Information Block type 7 due to bad radio conditions, the UE shall use the last stored IE "UL interference".
 - 1> measure the value for the CPICH RSCP;
 - 1> calculate the power for the first preamble as:

Preamble_Initial_Power = Primary CPICH TX power - CPICH_RSCP + UL interference + Constant Value

Where.

Primary CPICH TX power shall have the value of IE "Primary CPICH Tx power",

UL interference shall have the value of IE "UL interference"; and

Constant Value shall have the value of IE "Constant value".

- 1> as long as the physical layer is configured for PRACH or PCPCH transmission:
 - 2> continuously recalculate the Preamble_Initial_Power when any of the broadcast parameters used in the above formula changes; and
 - 2> resubmit to the physical layer the new calculated Preamble_Initial_Power.

For 3.84 Mcps TDD the UE shall:

- 1> if in the IE "Uplink DPCH Power Control info" the "CHOICE UL OL PC info" has the value "Broadcast UL OL PC info":
 - 2> prior to DPCH transmission the UE shall:
 - 3> acquire valid versions of the necessary System Information IEs as follows:
 - 4> if the UE has stored valid versions of the IEs "Primary CCPCH Tx power" and "DPCH Constant value":
 - 5> use the stored content of the IEs.
 - 4> otherwise:
 - 5> read and store the IE "Primary CCPCH Tx power" and "DPCH Constant value" in System Information Block type 6 (or System Information Block type 5, if System Information Block type 6 is not being broadcast).
- 3> if the UE has a valid version of the IE "UL interference" for each active UL timeslot stored:
 - 4> use the stored content of the IE "UL interference" for each active UL timeslot.
- 3> otherwise:
 - 4> read and store the IE "UL Timeslot Interference" for each active UL timeslot in System Information Block type 14;
 - 4> if the UE fails to read the IE "UL Timeslot Interference" for each active UL time slot in System Information Block type 14 due to bad radio conditions, the UE shall use the last stored IE "UL Timeslot interference" for each active UL timeslot.
 - 1> otherwise:
 - 2> acquire Reference Power, Constant Values and I_{BTS} for all active UL timeslots from the IE "Uplink DPCH Power Control info".
 - 1> for PUSCH, PRACH and HS-SICH power control:

- 2> prior to PUSCH or PRACH transmission the UE shall:
- 3> acquire valid versions of the necessary System Information IEs as follows:
 - 4> if the UE has stored valid versions of the IEs "Primary CCPCH Tx power" and "PUSCH Constant value" for PUSCH transmissions or "PRACH Constant value" for PRACH transmissions:
 - 5> use the stored content of the IEs.
 - 4> otherwise:
 - 5> read and store the IE "Primary CCPCH Tx power" and "PUSCH Constant value" for PUSCH transmissions or "PRACH Constant value" for PRACH transmissions in System Information Block type 6 (or System Information Block type 5, if System Information Block type 6 is not being broadcast).
- 3> if the UE has a valid version of the IE "UL interference" for each active UL timeslot stored:
 - 4> use the stored content of the IE "UL interference" for each active UL timeslot.
- 3> otherwise:
 - 4> read and store the IE "UL Timeslot Interference" for each active UL timeslot in System Information Block type 14;
 - 4> if the UE fails to read the IE "UL Timeslot Interference" for each active UL time slot in System Information Block type 14 due to bad radio conditions, the UE shall use the last stored IE "UL Timeslot interference" for each active UL timeslot.

calculate the UL transmit power according to the following formula for the PRACH continuously while the physical channel is active:

$$P_{PRACH} = L_{PCCPCH} + I_{BTS} + PRACH Constant value,$$

- 2> 3dB shall be added to RACH Constant Value in the above equation for the case where RACH Spreading Factor = 8.
- 1> calculate the UL transmit power according to the following formula for the DPCH continuously while the physical channel is active:

$$P_{DPCH} = \alpha L_{PCCPCH} + (1-\alpha)L_0 + I_{BTS} + SIR_{TARGET} + DPCH$$
 Constant value

1> calculate the UL transmit power according to the following formula for the PUSCH continuously while the physical channel is active:

$$P_{PUSCH} = \alpha L_{PCCPCH} + (1-\alpha)L_0 + I_{BTS} + SIR_{TARGET} + PUSCH$$
 Constant value

- 1> calculate the initial UL transmit power for HS-SICH according to the following formulae:
 - 2> when transmitting a Negative Acknowledgement:

$$P_{\text{HS-SICH}} = \alpha L_{PCCPCH} + (1-\alpha)L_0 + I_{BTS} + SIR_{TARGET} + HS-SICH Constant value$$

2> when transmitting an Acknowledgement:

$$P_{HS-SICH} = \alpha L_{PCCPCH} + (1-\alpha)L_0 + I_{BTS} + SIR_{TARGET} + HS-SICH \ Constant \ value + Ack_Nack \ power \ offset$$

Where, for all the above equations for 3.84 Mcps TDD the following apply:

- P_{PRACH}, P_{DPCH}, P_{PUSCH} and P_{HS-SICH}: Transmitter power level in dBm;
- Pathloss values:
- L_{PCCPCH}: Measurement representing path loss in dB based on beacon channels (the reference transmit power is signalled as the value of the IE "Primary CCPCH Tx Power" on BCH in System Information Block type 6 (or System Information Block type 5, according to subclause 8.1.1.6.5), or individually signalled in the IE" Uplink DPCH Power Control info").

- L₀: Long term average of path loss in dB;
- If the midamble is used in the evaluation of L_{PCCPCH} and L_0 , and the Tx diversity scheme used for the P-CCPCH involves the transmission of different midambles from the diversity antennas, the received power of the different midambles from the different antennas shall be combined prior to evaluation of the variables.
 - I_{BTS}: Interference signal power level at cell's receiver in dBm. I_{BTS} shall have the value of the IE "UL Timeslot Interference" (IE "UL Timeslot Interference" is broadcast on BCH in System Information Block type 14 or individually signalled to each UE in the IE "Uplink DPCH Power Control info" for each active uplink timeslot).
 - α : α is a weighting parameter, which represents the quality of path loss measurements. α may be a function of the time delay between the uplink time slot and the most recent down link PCCPCH time slot. α is calculated at the UE. α shall be smaller or equal to the value of the IE "Alpha". If the IE "Alpha" is not explicitly signalled to the UE α shall be set to 1. If UE is capable of estimating its position by using the OTDOA IPDL method, the UE shall use the IPDL- α parameter.
 - SIR_{TARGET}: Target SNR in dB. This value is individually signalled to UEs in IE "UL target SIR" in IE "Uplink DPCH Power Control Info" or in IE "PUSCH Power Control Info" respectively.
 - PRACH Constant value: PRACH Constant value shall have the value of the IE "PRACH Constant value".
 - DPCH Constant value: DPCH Constant value shall have the value of the IE "DPCH Constant value".
 - PUSCH Constant value: PUSCH Constant value shall have the value of the IE "PUSCH Constant value".
 - HS-SICH Constant value: HS-SICH Constant value shall have the value of the IE "HS-SICH Constant value".
 - Values received by dedicated signalling shall take precedence over broadcast values.
 - If IPDLs are applied, the UE may increase UL Tx power by the value given in the IE "Max power increase". This power increase is only allowed in the slots between an idle slot and the next beacon slot.
 - Ack-Nack Power Offset: Difference in the desired RX power between HS-SICH transmissions conveying an acknowledgement and transmissions conveying a negative acknowledgement signalled to the UE in IE "HS-SCCH Info".

For 1.28 Mcps TDD the UE shall:

1> acquire valid versions of the necessary System Information IEs as follows:

2> if the UE has stored a valid version of the IE "Primary CCPCH Tx Power":

3> use the stored content of the IE.

2> otherwise:

3> read and store the IE "Primary CCPCH Tx Power" from System Information Block type 6 (or System Information Block type 5, if System Information Block type 6 is not being broadcast).

1> calculate the UL transmit power according to the following formula for each UpPCH code transmission:

$$P_{UpPCH} = L_{PCCPCH} + PRX_{UpPCHdes} + (i-1)* Pwr_{ramp}$$

NOTE: When i equals 1, the initial signature power "Signature_Initial_Power" defined in [33] corresponds to P_{UpPCH} with i set to 1.

1> calculate the UL transmit power according to the following formula for each PRACH transmission:

$$P_{PRACH} = L_{PCCPCH} + PRX_{PRACHdes} + (i_{UpPCH}-1) * Pwr_{ramp}$$

1> calculate the initial UL transmit power according to the following formula for the PUSCH. Once the UE receives TPC bits relating to the PUSCH then it transitions to closed loop power control. If successive PUSCH resource allocations are contiguous then no return is made to open loop power control at the beginning of the succeeding resource allocation.

$$P_{USCH} = PRX_{PUSCHdes} + L_{PCCPCH}$$

- 1> calculate the initial UL transmit power for HS-SICH according to the following formulae:
 - 2> when transmitting a Negative Acknowledgement;

$$P_{HS-SICH} = PRX_{HS-SICH} + L_{PCCPCH}$$

2> when transmitting an Acknowledgement

$$P_{HS-SICH} = PRX_{HS-SICH} + L_{PCCPCH} + Ack-Nack Power Offset$$

- 2> Once the UE receives TPC bits relating to the HS-SICH, it transitions to closed loop power control. If no TPC command for the HS-SICH is detected between successive HS-SICH transmissions, the UE should revert to open loop power control until the next TPC command is detected.
- 1> calculate the initial UL transmit power according to the following formula for the DPCH. Once the UE receives TPC bits relating to the uplink DPCH then it transitions to closed loop power control.

$$P_{DPCH} = PRX_{DPCHdes} + L_{PCCPCH}$$

Where:

- P_{UpPCH}, P_{PRACH}, P_{DPCH}, P_{HS-SICH} & P_{USCH}: Transmitter power level in dBm.
- L_{PCCPCH}: Measurement representing path loss in dB (reference transmit power "Primary CCPCH Tx Power" is broadcast on BCH in System Information Block type 5 and System Information Block type 6, or individually signalled to each UE in the IE" Uplink DPCH Power Control info").
- i is the number of transmission attempts on UpPCH, i=1...Max SYNC_UL Transmissions.
- i_{UpPCH} is the final value of i.
- PRX_{PRACHdes}: Desired PRACH RX power at the cell's receiver in dBm signalled to the UE by the network in the FPACH response to the UE's successful SYNC_UL transmission.
- PRX_{UpPCHdes}: Desired UpPCH RX power at the cell's receiver in dBm. The value is broadcast in "PRX_{UpPCHdes}" in IE "SYNC_UL info" on BCH and shall be read on System Information Block type 5 and System Information Block type 6. It can also be signalled directly to the UE in IE "Uplink Timing Advance Control" contained in a protocol message triggering a hard handover or a transition from cell FACH to cell DCH state.
- PRX_{PUSCHdes}: Desired PUSCH RX power at the cell's receiver in dBm signalled to the UE in IE "PUSCH Power Control Info".
- PRX_{DPCHdes}: Desired DPCH RX power at the cell's receiver in dBm signalled to the UE in IE "Uplink DPCH Info" and IE "Uplink DPCH Power Control Info".
- Pwr_{ramp}: The UE shall increase its transmission power by the value of the IE "Power Ramp step" by every UpPCH transmission. Its value is signalled in the IE "SYNC UL info" in System Information Block type 5 and System Information Block type 6 or is signalled to the UE in the IE "Uplink Timing Advance Control" contained in a protocol message triggering a hard handover or a transition from cell FACH state to cell DCH state.
- PRX_{HS-SICH}: Desired HS-SICH RX power at the cell's receiver in dBm signalled to the UE in IE "Downlink HS-PDSCH Information".
- Ack-Nack Power Offset: Difference in the desired RX power between HS-SICH transmissions conveying an
 acknowledgement and transmissions conveying a negative acknowledgement signalled to the UE in IE "HSSCCH Info".

8.5.8 Maintenance of Hyper Frame Numbers

The MSBs of both the ciphering sequence numbers (COUNT-C) and integrity sequence numbers (COUNT-I), for the ciphering and integrity protection algorithms, respectively [40], are called the Hyper Frame Numbers (HFN).

For integrity protection, the UE shall:

1> maintain COUNT-I as specified in subclause 8.5.10.

The following hyper frame numbers types are defined:

MAC-d HFN:

24 MSB of COUNT-C for data sent over RLC TM

RLC UM HFN:

25 MSB of COUNT-C for data sent over RLC UM

RLC AM HFN:

20 MSB of COUNT-C for data sent over RLC AM

RRC HFN:

28 MSB of COUNT-I

For non-transparent mode RLC signalling radio bearers and radio bearers, the UE shall:

- 1> maintain one uplink and one downlink COUNT-C per signalling radio bearer and per radio bearer and one uplink and one downlink COUNT-I per signalling radio bearer;
- 1> increment the RLC UM HFN and RLC AM HFN in uplink and downlink by one each time the RLC sequence number wraps around in uplink and downlink respectively;
- 1> if the activation time for a new ciphering configuration set by an RRC procedure is equal to zero:
 - 2> apply the configured RLC UM HFN or RLC AM HFN at this activation time, i.e. the configured HFN is not incremented.

NOTE: On the receiver side it may happen that the RLC PDU with sequence number equal to the activation time is lost and the first received PDU after the activation time implies a wrap around of the sequence number compared to the activation time. In this case the configured HFN is incremented by one. This action is taken only when the activation time is set to a RLC PDU sequence number value other than zero.

For all transparent mode RLC signalling radio bearers and radio bearers of each CN domain, the UE shall:

- 1> maintain one COUNT-C, common for all radio bearers in uplink and downlink;
- 1> increment the MAC-d HFN by one each time the CFN wraps around;
- 1> if the activation time for a new ciphering configuration set by an RRC procedure is equal to zero:
 - 2> apply the configured MAC-d HFN at this activation time, i.e. the configured HFN is not incremented.
- 1> maintain one uplink and one downlink COUNT-I per signalling radio bearer.

NOTE: In this release of the specification there is only an uplink transparent mode COUNT-I, which is used for signalling radio bearer RB0.

COUNT-C and COUNT-I are defined in [40], with the following supplement for COUNT-C: for transparent mode RLC radio bearers with a transmission time interval of x radio frames (x = 2, 4, 8), the MAC PDU is carried by L1 in x consecutive radio frames due to radio frame segmentation. In this case, the CFN of the first radio frame in the TTI shall be used as the CFN component of COUNT-C for ciphering of all data in the TTI [15].

8.5.9 START value calculation

In connected mode, if a security mode command procedure has been successfully completed for a CN domain during the current RRC connection, the START value for that CN domain is calculated as:

Let $START_X$ = the START value for CN domain 'X' prior to the calculation below:

 $START_{X}' = MSB_{20} \ (\ MAX \ \{COUNT-I \ | \ radio \ bearers \ and \ signalling \ radio \ bearers \ using \ the \ most \ recently \ configured \ CK_{X} \ and \ IK_{X}\}) + 2.$

- if $START_X$ '= the maximum value = 1048575 then $START_X$ = $START_X$ ';
- if the current $START_X < START_X'$ then $START_X = START_X'$, otherwise $START_X$ is unchanged.

NOTE: Here, "most recently configured" means that if there is more than one key in use for a CN domain, due to non-expiry of the ciphering and/or integrity protection activation time for any signalling radio bearers and/or radio bearers, do not include the COUNT-I/COUNT-C for these signalling radio bearers and/or radio bearers in the calculation of the START x'.

COUNT-C corresponding to non-ciphered radio bearers (i.e. RBs with ciphering status set to "not started") shall not be included in the calculation of the $START_{X}$ '. If a radio bearer is released and the radio bearer was ciphered, the values of the COUNT-C at the time the radio bearer is released shall be taken into account in the calculation of the $START_{X}$ '.

If a security mode command procedure has not been successfully completed for a CN domain during the current RRC connection, the UE shall use the latest transmitted START value for this CN domain.

8.5.10 Integrity protection

If the "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Started" then the UE shall:

1> perform integrity protection (and integrity checking) on all RRC messages, with the following exceptions:

HANDOVER TO UTRAN COMPLETE

PAGING TYPE 1

PUSCH CAPACITY REQUEST

PHYSICAL SHARED CHANNEL ALLOCATION

RRC CONNECTION REQUEST

RRC CONNECTION SETUP

RRC CONNECTION SETUP COMPLETE

RRC CONNECTION REJECT

RRC CONNECTION RELEASE (CCCH only)

SYSTEM INFORMATION

SYSTEM INFORMATION CHANGE INDICATION

TRANSPORT FORMAT COMBINATION CONTROL (TM DCCH only)

If the "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Not started" then integrity protection (and integrity checking) shall not be performed on any RRC message.

For each signalling radio bearer, the UE shall use two RRC hyper frame numbers:

- "Uplink RRC HFN";
- "Downlink RRC HFN".

and two message sequence numbers:

- "Uplink RRC Message sequence number";
- "Downlink RRC Message sequence number".

The above information is stored in the variable INTEGRITY_PROTECTION_INFO per signalling radio bearer (RB0-RB4).

Upon the first activation of integrity protection for an RRC connection, UE and UTRAN initialise the "Uplink RRC Message sequence number" and "Downlink RRC Message sequence number" for all signalling radio bearers as specified in subclauses 8.6.3.5 and 8.5.10.1.

The RRC message sequence number (RRC SN) is incremented for every integrity protected RRC message.

If the IE "Integrity Protection Mode Info" is present in a received message, the UE shall:

1> perform the actions in subclause 8.6.3.5 before proceeding with the integrity check of the received message.

8.5.10.1 Integrity protection in downlink

If the UE receives an RRC message on signalling radio bearer with RB identity n, the "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Started" and the IE 'Integrity check info' is present the UE shall:

- 1> check the value of the IE "RRC message sequence number" included in the IE "Integrity check info";
 - 2> if the "Downlink RRC Message sequence number" is not present in the variable INTEGRITY_PROTECTION_INFO:

3> initialise the "Downlink RRC Message sequence number" for signalling radio bearer RBn in the variable INTEGRITY_PROTECTION_INFO with the value of the IE "RRC message sequence number" included in the IE "Integrity check info" of the received message.

2> if the "Downlink RRC Message sequence number" is present in the variable INTEGRITY_PROTECTION_INFO:

3> if the RRC message sequence number is lower than the "Downlink RRC Message sequence number" for signalling radio bearer RBn in the variable INTEGRITY_PROTECTION_INFO:

4> increment "Downlink RRC HFN" for signalling radio bearer RBn in the variable INTEGRITY_PROTECTION_INFO with one.

NOTE: The actions above imply that also for the case the "Downlink RRC HFN" is re-initialised by a security mode control procedure, this "Downlink RRC HFN" value is incremented by one before it is applied for the integrity protection of any received message if the conditions above are fulfilled.

3> if the RRC message sequence number is equal to the "Downlink RRC Message sequence number" for signalling radio bearer RBn in the variable INTEGRITY_PROTECTION_INFO:

- 4> discard the message.
- 1> calculate an expected message authentication code in accordance with subclause 8.5.10.3;
- 1> compare the expected message authentication code with the value of the received IE "message authentication code" contained in the IE "Integrity check info";
 - 2> if the expected message authentication code and the received message authentication code are the same, the integrity check is successful:

3> update the "Downlink RRC Message sequence number" for signalling radio bearer RBn in the variable INTEGRITY_PROTECTION_INFO with the value of the IE "RRC message sequence number" included in the IE "Integrity check info" of the received RRC message.

2> if the calculated expected message authentication code and the received message authentication code differ:

3> act as if the message was not received.

If the UE receives an RRC message on signalling radio bearer with identity n, the "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Started" and the IE 'Integrity check info' is not present the UE shall:

1> discard the message.

UTRAN may transmit several copies of the same message in the downlink to increase the probability of proper reception of the message by the UE. In such a case, the RRC SN for these repeated messages should be the same.

8.5.10.2 Integrity protection in uplink

Prior to sending an RRC message using the signalling radio bearer with radio bearer identity n, and the "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Started" the UE shall:

- 1> increment "Uplink RRC Message sequence number" for signalling radio bearer RBn in the variable INTEGRITY_PROTECTION_INFO with 1, even if the message is a retransmission of a previously transmitted message.
- 1> if the "Uplink RRC Message sequence number" for signalling radio bearer RBn in the variable INTEGRITY_PROTECTION_INFO equals zero:
 - 2> increment "Uplink RRC HFN" for signalling radio bearer RBn in the variable INTEGRITY_PROTECTION_INFO by one.
- NOTE 1: The actions above imply that also for the case the "Uplink RRC HFN" is re-initialised by a security mode control procedure, this "Uplink RRC HFN" is incremented before it is applied in the integrity protection of any transmitted message if the conditions above are fulfilled.
- NOTE 2: For SRB0, this is also valid in case the Message Sequence Number has been increased by N302 +2 resulting in an MSN which equals 0 (i.e.: SRB0 UL activation time equals 0). Then the uplink RRC HFN is incremented by 1 after it is re-initialized and before it is applied in the integrity protection of any transmitted message.
- 1> calculate the message authentication code in accordance with subclause 8.5.10.3;
- 1> replace the "Message authentication code" in the IE "Integrity check info" in the message with the calculated message authentication code;
- 1> replace the "RRC Message sequence number" in the IE "Integrity check info" in the message with contents set to the new value of the "Uplink RRC Message sequence number" for signalling radio bearer RBn in the variable INTEGRITY_PROTECTION_INFO.

In the response message for the procedure ordering the security reconfiguration, the UE indicates the activation time, for each signalling radio bearer. When the new integrity configuration is to be applied in uplink, UTRAN should start to apply the new integrity protection configuration according to the activation time for each signalling radio bearer (except for the signalling radio bearer which is used to send the message that is reconfiguring the security configuration where the new configuration is to be applied starting from and including reception of the response message).

8.5.10.3 Calculation of message authentication code

The UE shall calculate the message authentication code in accordance with [40]. The input parameter MESSAGE [40] for the integrity algorithm shall be constructed by:

- 1> setting the "Message authentication code" in the IE "Integrity check info" in the message to the value of the IE "RB identity" for the signalling radio bearer;
- 1> setting the "RRC Message sequence number" in the IE "Integrity check info" in the message to zero;
- 1> encoding the message;
- 1> appending RRC padding (if any) as a bit string to the encoded bit string as the least significant bits.

For usage on an RRC message transmitted or received on the radio bearer with identity n, the UE shall:

- 1> construct the input parameter COUNT-I [40] by appending the following IEs from the IE "Signalling radio bearer specific integrity protection information" for radio bearer n in the variable INTEGRITY PROTECTION INFO:
 - 2> for uplink:
- 3> "Uplink RRC HFN", as the MSB, and "Uplink RRC Message sequence number", as LSB.
 - 2> for downlink:

3> "Downlink RRC HFN", as the MSB, and the IE "RRC message sequence number" included in the IE "Integrity check info", as LSB.

8.5.11 FACH measurement occasion calculation

When in CELL_FACH state and when the variable C_RNTI is non-empty the UE in FDD mode shall perform measurements as specified in subclauses 8.4.1.6 and 8.4.1.8 during the frame(s) with the SFN value fulfilling the following equation:

SFN div
$$N = C_RNTI \mod M_REP + n * M_REP$$

where

- N is the TTI (in number of 10ms frames) of the FACH having the largest TTI on the SCCPCH monitored by UE
- C_RNTI is the C-RNTI value of the UE stored in the variable C_RNTI
- M_REP is the Measurement Occasion cycle length. According to the equation above, a FACH Measurement Occasion of N frames will be repeated every N * M_REP frame, and M_REP = 2^k.

where,

- k is the FACH Measurement occasion cycle length coefficient.
 The value of the FACH Measurement occasion cycle length coefficient is read in system information in "System Information Block type 11" or "System Information Block type 12" in the IE "FACH measurement occasion info".
- n = 0,1,2... as long as SFN is below its maximum value

The UE is allowed to measure on other occasions in case the UE moves "out of service" area or in case it can simultaneously perform the ordered measurements.

A UE in TDD mode shall use the frame(s) with the SFN value fulfilling the above equation for neighbour cells measurements.

8.5.12 Establishment of Access Service Classes

The PRACH resources (i.e. access slots and preamble signatures for FDD), timeslot (with specific frame allocation and channelisation code for 3.84 Mcps TDD and SYNC_UL codes (with specific frame allocation) for 1.28 Mcps TDD) may be divided between different Access Service Classes in order to provide different priorities of RACH usage. It is possible for more than one ASC or for all ASCs to be assigned to the same access slot/signature space in FDD or frame allocation/channelisation codes in 3.84 Mcps TDD or frame allocation/SYNC_UL codes in 1.28 Mcps TDD.

Access Service Classes shall be numbered in the range $0 \le i \le \text{NumASC} \le 7$ (i.e. the maximum number of ASCs is 8). An ASC is defined by an identifier, i, that defines a certain partition of the PRACH resources (SYNC_UL resources in 1.28 Mcps TDD) and an associated persistence value P_i . A set of ASC parameters consists of "NumASC+1" such parameters (i, P_i) , i = 0, ..., NumASC.

PRACH partitions shall be established using the information element "PRACH partitioning". The persistence values P_i to be associated with each ASC shall be derived from the dynamic persistence level N = 1,..., 8 which is broadcast in System Information Block 7, and the persistence scaling factors s_i , broadcast in System Information Block Type 5 and possibly also in System Information Block Type 6, as follows:

$$P(N) = 2^{-(N-1)}$$

ASC # i	0	1	2	3	4	5	6	7
Pi	1	P(N)	s ₂ P(N)	s ₃ P(N)	s ₄ P(N)	s ₅ P(N)	s ₆ P(N)	s ₇ P(N)

Scaling factors s_i are provided optionally for i = 2,..., NumASC, where NumASC+1 is the number of ASCs as defined by PRACH partitioning. If no scaling factors are broadcast, default value 1 shall be used if NumASC ≥ 2 .

If $k \ge 1$ scaling factors are broadcast and NumASC $\ge k+2$ then the last scaling factor s_{k+1} shall be used as default for the ASCs where i > k+1.

The set of ASC parameters is provided to MAC with the CMAC-Config-REQ primitive (see [15]), the PRACH partitioning is provided to PHY using the CPHY-RL-Setup-REQ primitive (see [34]).

The ASC enumeration shall be such that it corresponds to the order of priority (ASC 0 = highest priority, ASC 7 = lowest priority). ASC 0 shall be used in case of Emergency Call or for reasons with equivalent priority.

ASCs are numbered according to the order in which the IEs "ASC Setting" appear in the IE "PRACH partitioning", where the first IE "ASC Setting" describes ASC 0, the second IE "ASC Setting" describes ASC 1, etc.

At radio bearer setup/reconfiguration each involved logical channel is assigned a MAC Logical channel Priority (MLP) in the range 1,...,8. When the MAC sublayer is configured for RACH transmission in the UE, these MLP levels shall be employed for ASC selection on MAC.

8.5.13 Mapping of Access Classes to Access Service Classes

Access Classes shall only be applied at initial access, i.e. when sending an RRC CONNECTION REQUEST message. A mapping between Access Class (AC) and Access Service Class (ASC) shall be indicated by the information element "AC-to-ASC mapping" in System Information Block type 5. The correspondence between AC and ASC shall be indicated as follows.

AC	0 - 9	10	11	12	13	14	15
ASC	1 st IE	2 nd IE	3 ^{ra} IE	4 th IE	5 th IE	6 th IE	7 th IE

In the table, " n^{th} IE" designates an ASC number i in the range 0 - 7 to AC. If the ASC indicated by the " n^{th} IE" is undefined, the UE behaviour is unspecified.

For the random access, the parameters implied by the respective ASC shall be employed. In case the UE is member of several ACs it shall select the ASC for the highest AC number. In connected mode, AC shall not be applied.

8.5.14 PLMN Type Selection

The UE shall perform PLMN selection and reselection as stated in [4] and store the identifier of the chosen PLMN in the variable SELECTED_PLMN as follows. The UE shall:

- 1> if a GSM-MAP type of PLMN is selected:
 - 2> set the "PLMN Type" in the variable SELECTED_PLMN to "GSM-MAP";
 - 2> and store the PLMN identity of that PLMN.
- 1> if an ANSI-41 type of PLMN is selected:
 - 2> set the "PLMN Type" in the variable SELECTED_PLMN to "ANSI-41";
 - 2> and store the System identification (SID) of that PLMN.

8.5.14a Neighbour cells list narrowing for cell reselection

A UE having performed the PLMN identification of the neighbour cells as specified in 8.1.1.6.18 shall narrow the cell list to be used for cell reselection ([4]) to those cells that do satisfy one of the following criteria:

- 1> the PLMN identity of the neighbour cell is the identity of the selected PLMN;
- 1> the PLMN identity of the neighbour cell is indicated by higher layers to be equivalent to the identity of the selected PLMN.

8.5.15 CFN calculation

The DOFF used in the formulas in this clause concerns the value of IE "Default DPCH Offset Value" received in the message that instructs the UE to enter CELL_DCH state or to perform timing re-initialised hard handover.

8.5.15.1 Initialisation for CELL_DCH state after state transition

When the UE receives any of the messages causing the UE to perform a state transition to CELL_DCH, the UE shall set the CFN in relation to the SFN of the first radio link listed in the IE "Downlink information per radio link list" included in that message according to the following formula:

- for FDD:

$$CFN = (SFN - (DOFF \text{ div } 38400)) \mod 256$$

where the formula gives the CFN of the downlink DPCH frame which starts at the same time as or which starts during the PCCPCH frame with the given SFN.

for TDD:

$$CFN = (SFN - DOFF) \mod 256$$
.

8.5.15.2 Initialisation in CELL_DCH state at hard handover

When the UE is in CELL_DCH state and receives any of the messages causing the UE to perform a hard handover, the UE shall check the IE "Timing indication" in that message and:

- 1> if IE "Timing indication" has the value "initialise" (i.e. timing re-initialised hard handover):
 - 2> read SFN on target cell identified by the first radio link listed in the IE "Downlink information per radio link list" included in that message;
 - 2> set the CFN according to the following formula:

3> for FDD:

$$CFN = (SFN - (DOFF div 38400)) \mod 256$$

where the formula gives the CFN of the downlink DPCH frame which starts at the same time as or which starts during the PCCPCH frame with the given SFN.

3> for TDD:

$$CFN = (SFN - DOFF) \mod 256$$
.

1> if IE "Timing indication" has the value "maintain" (i.e. timing-maintained hard handover), the UE shall keep CFN with no change due to the hard handover, and only increase CFN (mod 256) by 1 every frame.

8.5.15.3 Initialisation for CELL FACH

When the UE performs cell selection, re-selection or changes to CELL_FACH state the UE shall set CFN for all common or shared channels according to:

$$CFN = SFN \mod 256$$

where the formula gives the CFN of the downlink common or shared channel frame which starts at the same time as or which starts during the PCCPCH frame with the given SFN.

After the initialisation, the CFN in the UE is increased (mod 256) by 1 every frame.

8.5.15.4 Initialisation after intersystem handover to UTRAN

Upon inter RAT handover to UTRAN the UE shall, regardless of the value received within IE "Timing indication" (if received):

1> read SFN on target cell and set the CFN according to the following formula:

2> for FDD:

$$CFN = (SFN - (DOFF div 38400)) \mod 256$$

where the formula gives the CFN of the downlink DPCH frame which starts at the same time as or which starts during the PCCPCH frame with the given SFN.

2> for TDD:

 $CFN = (SFN - DOFF) \mod 256$.

8.5.16 Configuration of CTCH occasions

The CTCH, carrying CBS data is mapped onto only one S-CCPCH. If more than one CTCH is defined, the first CTCH that is configured in the list of S-CCPCHs is the one that is used for CBS data.

The CTCH occasions are identified by the first radio frame of the TTI that can contain CTCH data. The CTCH occasions are fixed on the system frame number cycle 0 .. 4095 (i.e. no modulo calculation) and thus repeated cyclically.

The CTCH occasions are determined by a set of parameters.

M_{TTI}: number of radio frames within the TTI of the FACH used for CTCH

N: period of CTCH allocation on S-CCPCH, integer number of radio frames, $M_{TTI} \le N \le MaxSFN - K$, where N is a multiple of M_{TTI} (see [27] and [31]).

MaxSFN: maximum system frame number = 4095 (see [10]).

K: CBS frame offset, integer number of radio frames $0 \le K \le N-1$ where K is a multiple of M_{TTI} .

The CTCH occasions are calculated as follows:

SFN = (K + m N), m = 0, 1,..., M, with M chosen that $K+MN \le MaxSFN$.

The parameters N and K are broadcast as system information.

8.5.17 PRACH selection

For this version of the specification, when a UE selects a cell, the uplink frequency to be used for the initial PRACH transmission shall have a default duplex frequency spacing offset from the downlink frequency that the cell was selected on. The default duplex frequency separation to be used by the UE is specified in [35] (for FDD only).

NOTE: The PRACH selection scheme assumes that all PRACHs configured in System Information Block type 5 and System Information Block type 6 support all (implicitly or explicitly) configurable RLC sizes of the cell, i.e. at least the transport formats corresponding to a single transport block of each applicable RLC size of the cell must be defined for each PRACH.

The UE shall select a "PRACH system information" according to the following rule. The UE shall:

- 1> select a "PRACH system information" from the ones indicated in the IE "PRACH system information list" in System Information Block type 5 (applicable in Idle Mode and Connected Mode) or System Information Block type 6 (applicable in Connected Mode only), as follows:
 - 2> if in connected mode and System Information Block type 6 is defined and includes PRACH info:

3> compile a list of candidate PRACHs that consists of the PRACH system information listed in System Information Block 6, in the order of appearance as in System Information Block 6.

2>otherwise

3> compile a list of candidate PRACHs that consists of the PRACH system information listed in System Information Block 5, in the order of appearance as in System Information Block 5.

2> in FDD:

3> perform RACH TTI selection as specified in subclause 8.5.18.1.

2> in 1.28 Mcps TDD:

- 3> perform RACH TTI selection according to subclause 8.5.18.2.
 - 2> remove from the list of candidate PRACHs those PRACHs that have a TTI length different from the selected value:
 - 2> select a PRACH randomly from the list of candidate PRACHs as follows:

"Index of selected PRACH" = floor (rand * K)

where K is equal to the number of candidate PRACH system informations, "rand" is a random number uniformly distributed in the range $0 \le \text{rand} < 1$ and "floor" refers to rounding down to nearest integer. The candidate PRACH system informations shall be indexed from 0 to K-1. The random number generator is left to implementation. The scheme shall be implemented such that one of the available PRACH system informations is randomly selected with uniform probability. At start-up of the random number generator in the UE the seed shall be dependent on the IMSI of the UE or time, thereby avoiding that all UEs select the same RACH;

- 2> use the TFCS of the selected PRACH when performing TFC selection (see [15]);
- 2> reselect the PRACH system information when a new cell is selected. RACH reselection may also be performed after each transmission of a Transport Block Set on RACH.
- 1> for emergency call, the UE is allowed to select any of the available PRACH system informations.

After selecting a PRACH system information, the RRC in the UE shall configure the MAC and the physical layer for the RACH access according to the parameters included in the selected "PRACH system information" IE.

8.5.18 Selection of RACH TTI

8.5.18.1 FDD

In FDD mode, a RACH may employ either 10 or 20 ms TTI. The supported TTI is indicated as a semi-static parameter of the RACH Transport Format in system information. The UE shall select an appropriate TTI length from the RACHs included in the list of candidate PRACH(s) according to the following rule.

The UE shall:

- 1> if only RACHs with one particular TTI length are included in the list of candidate PRACH(s):
 - 2> select this TTI length and proceed as specified in subclause 8.5.17.
- 1> if both PRACHs with 10ms and 20ms TTI lengths are included in the list of candidate PRACH(s):
 - 2> perform TTI selection as follows:

3> when the UE calculates the initial preamble transmit power ("Preamble_Initial_Power") as specified in subclause 8.5.7:

- 4> select a TF to be employed for calculation of a transmit power margin as follows:
 - 5> from the TFs supported by all candidate PRACHs keep those which correspond to a single transport block of all configured RLC sizes (i.e., in idle mode, the RLC size applicable for RB0, in connected mode, the RLC sizes configured with explicit "RB mapping info"). If more than a single TF remain applicable, the UE may select any of these. Preferably the UE should select the TF which is intended to be used at the next transmission or, if such information is not available, the TF corresponding to the largest configured RLC size.
- 4> calculate a transmit power margin,

 $\begin{aligned} & \text{Margin} = \{ \text{min}(\text{Maximum allowed UL tx power, P_MAX}) - \text{max}(\text{Preamble_Initial_Power, P-mAX}) -$

where "Maximum allowed UL tx power" is the maximum allowed uplink transmit power indicated in system information (in dBm), and P_MAX is the maximum RF output power of the UE (dBm). The

margin shall be calculated for the gain factors β_d and β_c of the TF selected in the step above, using 10ms TTI length.

NOTE: the expression Preamble_Initial_Power + Δ Pp-m + $10*\log_{10}(1 + (\beta_d/\beta_c)^2)$ represents the total RACH message power if the message would be sent after the initial preamble.

3> if the resulting "Margin" value is less than 6 dB:

4> select RACH with 20 ms TTI, and proceed as specified in subclause 8.5.17.

3> otherwise, if the last L1 message transmission on PRACH failed (see [15]):

4> the UE may select RACH with 20ms TTI length and proceed as specified in subclause 8.5.17.

3> otherwise:

4> select RACH with 10ms TTI length and proceed as specified in subclause 8.5.17.

8.5.18.2 1.28 Mcps TDD

In 1.28 Mcps TDD, a RACH may be assigned a 5, 10 or 20 ms TTI. If, in one cell, more than one RACH is defined a UE shall select the RACH that is to be used for each transmission according to the following rule:

- 1> if only RACHs with one particular TTI length are assigned a transport format that is suitable for the transmission of the transport block set:
 - 2> select this RACH's TTI length.
- 1> if more than one RACHs are assigned a transport format that is suitable for the transmission of the transport block set:
 - 2> select the longest of the TTI lengths of these RACHs.

8.5.19 Secondary CCPCH selection

In UTRAN Connected mode, the UE shall select the Secondary CCPCH according to the following rules:

- 1> in Cell_DCH state:
 - 2> select Secondary CCPCH according to subclause 8.6.6.4.
- 1> in Cell_FACH state:
 - 2> if System Information Block type 6 is defined and includes one or more SCCPCH that carry a FACH, compile a list of candidate SCCPCH that consists of these SCCPCH, in the order of appearance in System Information Block type 6.
- NOTE 1: An SCCPCH carries a FACH if the size of the "FACH/PCH information" list within the IE "Secondary CCPCH system information" exceeds 1 or if the size of this list equals 1 while IE "Secondary CCPCH system information" does not contain an IE "PICH info".
 - 2> otherwise:

3> compile a list of candidate SCCPCH that consists of the SCCPCH(s) included in System Information Block type 5 that carry a FACH, in the order of appearance in System Information Block type 5.

2> select an SCCPCH from the list of candidate SCCPCHs based on U-RNTI as follows:

"Index of selected SCCPCH" = U-RNTI mod K,

where K is equal to the number of candidate SCCPCHs.

1> in Cell_PCH and URA_PCH states:

- 2> if System Information Block type 6 is defined and includes one or more SCCPCH that carry a PCH, compile a list of candidate SCCPCH that consists of these SCCPCH, in the order of appearance in System Information Block type 6
- NOTE 2: An SCCPCH carries a PCH if the IE "Secondary CCPCH system information" contains IE "PICH info"
 - 2> otherwise compile a list of candidate SCCPCH that consists of the SCCPCH(s) included in System Information Block type 5 that that carry a PCH, in the order of appearance in System Information Block type
 - 2> select an SCCPCH from the list of candidate SCCPCHs based on U-RNTI as follows:

"Index of selected SCCPCH" = U-RNTI mod K,

where K is equal to the number of candidate SCCPCHs.

The UE shall set the CFN in relation to the SFN of the current cell according to subclause 8.5.15.

The UE shall decode all transport formats on all FACHs multiplexed on the selected S-CCPCH according to its UE capability, as defined in subclauses 8.1.1.6.5 and 8.1.1.6.6, to find blocks adressed to the UE.

8.5.20 Unsupported configuration

The UE should set the variable UNSUPPORTED_CONFIGURATION to TRUE if the received message is not according to the UE capabilities.

8.5.21 Actions related to Radio Bearer mapping

When the UE receives the IE "RB mapping info" and/or the IE "Transport format set", when the UE performs a cell reselection or a state transition, or when the UE releases a RB, the UE shall for each of the configured Radio Bearers:

- 1> upon moving to CELL_FACH after detecting a radio link failure (see subclause 8.5.6) and upon subsequent cell reselections until the first successfully completed cell update procedure, perform the actions defined in the remainder of this subclause only for signalling radio bearers;
- 1> for FDD, select the multiplexing option according to the following:
 - 2> if the UE is in CELL_FACH state:
- 3> if the RB has a multiplexing option with transport channel type "FACH" for the DL and transport channel type "RACH" for the UL:
 - 4> select this multiplexing option.
 - 2> if the UE is in CELL_DCH state:
- 3> if the RB has a multiplexing option with transport channel type "DCH + HS-DSCH" for the DL, and both the corresponding DCH transport channel and MAC-d flow are configured, and with transport channel type "DCH" for the UL, and the corresponding DCH transport channel is configured:
 - 4> select this multiplexing option; else
- 3> if the RB has a multiplexing option with transport channel type "DCH + DSCH" for the DL, and both the corresponding DCH and DSCH transport channels are configured, and with transport channel type "DCH" for the UL, and the corresponding DCH transport channel is configured:
 - 4> select this multiplexing option; else
- 3> if the RB has a multiplexing option with transport channel type "HS-DSCH" for the DL, and the corresponding MAC-d flow is configured, and with transport channel type "DCH" for the UL, and the corresponding DCH transport channel is configured:
 - 4> select this multiplexing option; else

- 3> if the RB has a multiplexing option with transport channel type "DSCH" for the DL, and the corresponding DSCH transport channel is configured, and with transport channel type 'DCH' for the UL, and the corresponding DCH transport channel is configured:
 - 4> select this multiplexing option; else
- 3> if the RB has a multiplexing option with transport channel type "DCH" for the DL, and the corresponding DCH transport channel is configured, and with transport channel type "DCH" for the UL, and the corresponding DCH transport channel is configured:
 - 4> select this multiplexing option.
 - 1> configure the MAC with the appropriate transport format set (with computed transport block sizes) for the transport channel used by that RB;
 - 1> determine the sets of RLC sizes that apply to the logical channels used by that RB, based on the IEs "RLC size list" and/or the IEs "Logical Channel List" included in the applicable "Transport format set" (either the ones received in the same message or the ones stored if none were received);
 - 1> in case the selected multiplexing option is a multiplexing option on RACH:
 - 2> ignore the RLC size indexes that do not correspond to any RLC size within the Transport Format Set stored for RACH.
 - 2> if there is no remaining RLC size index corresponding to an RLC size within the Transport Format Set stored for RACH:
- 3> set the variable INVALID_CONFIGURATION to TRUE.
 - 1> if RACH is the transport channel to be used on the uplink, if that RB has a multiplexing option on RACH and if it is using AM:
 - 2> apply the largest size amongst the ones derived according to the previous bullet for the RLC size (or RLC sizes in case the RB is realised using two logical channels) for the corresponding RLC entity.
 - NOTE: The IE "RB mapping info" is only included in the IE "Predefined RB configurations" in system information when used for Inter-RAT handover to UTRAN and there is no AM RLC size change involved in this case.
 - 1> if that RB is using AM and the RLC size applicable to the uplink logical channel transporting data PDUs is different from the one derived from the previously stored configuration:
 - 2> if the RLC size change is caused by a reconfiguration message or a CELL UPDATE CONFIRM; and
 - 2> the IE "one sided RLC re-establishment" is included in that message and is set to TRUE:
- 3> re-establish the transmitting side of the corresponding RLC entity.
 - 2> else:
- 3> re-establish the corresponding RLC entity.
 - 2> configure the corresponding RLC entity with the new uplink RLC size;
 - 2> for each AM RLC radio bearer in the CN domain as indicated in the IE "CN domain identity" in the IE "RAB info" in the variable ESTABLISHED_RABS whose RLC size is changed; and
 - 2> for each AM RLC signalling radio bearer in the CN domain as indicated in the IE "CN domain identity" in the variable LATEST_CONFIGURED_CN_DOMAIN whose RLC size is changed:
- 3> if the IE "Status" in the variable CIPHERING_STATUS of this CN domain is set to "Started":
 - 4> if the information causing the RLC re-establishment was included in system information:
 - 5> set the HFN values for the corresponding RLC entity equal to the value of the IE "START" for this CN domain that will be included in the CELL UPDATE message following cell reselection.

- NOTE: Since the UE cannot predict the START value at the time of the next CELL UPDATE transmission in the future, UTRAN should desist from changing the RLC size for a signalling radio bearer within a cell. Other than this case the change in RLC size for a signalling radio bearer is known to the UE when reading system information following cell reselection.
 - 4> if the RLC re-establishment is caused by a CELL UPDATE CONFIRM:
 - 5> if the whole RLC entity was re-established:
 - 6> set the HFN values for the corresponding RLC entity in uplink and downlink equal to the value of the IE "START" included in the latest transmitted CELL UPDATE message for this CN domain.
 - 5> if only the transmitting side of the RLC entity was re-established:
 - 6> set the HFN value for the corresponding RLC entity in the uplink equal to the value of the IE "START" included in the latest transmitted CELL UPDATE message for this CN domain.
 - 4> if the RLC re-establishment is caused by a reconfiguration message:
 - 5> if the whole RLC entity was re-established:
 - 6> set the HFN values for the corresponding RLC entity in uplink and downlink equal to the value of the IE "START" that will be included in the reconfiguration complete message for this CN domain.
 - 5> if only the transmitting side of the RLC entity was re-established:
 - 6> set the HFN value for the corresponding RLC entity in the direction uplink equal to the value of the IE "START" that will be included in the reconfiguration complete message for this CN domain
- NOTE1: If the UTRAN modifies the RLC size for RB2 on any reconfiguration message or Cell Update Confirm message, the UE behaviour is unspecified in this version of the specification.
- NOTE2: The UE cannot rely on the configured Transport Formats to determine the RLC sizes to be used in downlink for a particular logical channel. This size can be signalled explicitly in the RLC Info IE.
- 1> if that RB is using UM:
 - 2> indicate the largest RLC size applicable for uplink to the corresponding RLC entity.
- 1> configure MAC multiplexing according to the selected multiplexing option (MAC multiplexing shall only be configured for a logical channel if the transport channel it is mapped on according to the selected multiplexing option is the same as the transport channel another logical channel is mapped on according to the multiplexing option selected for it);
- 1> configure the MAC with the logical channel priorities according to selected multiplexing option;
- 1> configure the MAC with the set of applicable RLC Sizes for each of the logical channels used for that RB;
- 1> if there is no multiplexing option applicable for the transport channels to be used:
 - 2> set the variable INVALID_CONFIGURATION to TRUE.
- 1> if there is more than one multiplexing option applicable for the transport channels to be used:
 - 2> set the variable INVALID_CONFIGURATION to TRUE.

If upon cell re-selection or upon moving to CELL_FACH after detecting a radio link failure the UE sets variable INVALID_CONFIGURATION to TRUE as a result of the actions defined in this subclause, the UE should:

1> move to idle mode;

- 1> release (locally) the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and the established radio access bearers (as stored in the variable ESTABLISHED_RABS) and indicate this to upper layers;
- 1> perform other actions when entering idle mode from connected mode as specified in subclause 8.5.2.

8.5.22 Actions when entering another RAT from connected mode

NOTE: This section does not apply when entering GERAN Iu mode from UTRAN connected mode.

When entering another RAT from connected mode (due to Inter-RAT handover from UTRAN, Inter-RAT cell change order from UTRAN or Inter-RAT cell reselection from UTRAN), after successful completion of the procedure causing the transition to the other RAT, the UE shall:

- 1> if the USIM is present, for each CN domain:
 - 2> if a new security key set was received for this CN domain but was not used either for integrity protection or ciphering during this RRC connection:
- 3> set the START value for this domain to zero and;
- 3> store this START value for this domain in the USIM;
 - 2> else:
- 3> store the current START value for every CN domain in the USIM [50].
 - NOTE: Prior to storing the START value, the UE should calculate this START value according to subclause 8.5.9.
 - 1> if the SIM is present, for each CN domain:
 - 2> if a new security key was received for this CN domain but was not used either for integrity protection or ciphering during this RRC connection:
- 3> set the START value for this domain to zero and;
- 3> store this START value for this domain in the UE.
 - 2> else:
- 3> store the current START value for this CN domain in the UE.
 - NOTE: Prior to storing the START value, the UE should calculate this START value according to subclause

8.5.23 Measured results on RACH

When transmitting an uplink RRC message, the UE shall:

- 1> if the uplink RRC message is an RRC CONNECTION REQUEST message:
 - 2> if the IE "Intra-frequency reporting quantity for RACH reporting" and the IE "Maximum number of reported cells on RACH" are included in System Information Block type 1:
- 3> include a measurement report in the IE "Measured results on RACH", as specified in the IE "Intra-frequency reporting quantity for RACH reporting" and the IE "Maximum number of reported cells on RACH" in System Information Block type 11.
 - 1> for any other uplink RRC message which optionally includes the IE "Measured results on RACH":
 - 2> if the IE "Intra-frequency reporting quantity for RACH reporting" and the IE "Maximum number of reported cells on RACH" in System Information Block type 12 (or "System Information Block Type 11" if "System Information Block Type 12" is not being broadcast).

3> include a measurement report in the IE "Measured results on RACH", as specified in the IE "Intra-frequency reporting quantity for RACH reporting" and the IE "Maximum number of reported cells on RACH" in System Information Block type 12 (or "System Information Block Type 11" if "System Information Block Type 12" is not being broadcast).

- 1> include in the IE "Measured results on RACH" all requested reporting quantities for cells for which measurements are reported.
 - NOTE: The UE only includes measurement results for neighbour cells for which valid measurements are available at the time the message is sent. At cell access following selection or reselection to a cell, the UE may not have had sufficient time to obtain valid measurement results for neighbour cells.
- 1> for messages transmitted on CCCH, take care that the maximum allowed message size is not exceeded when forming the IE "Measured results on RACH", i.e. limit the number of included neighbour cells or if required omit the IE "Measured results on RACH" altogether.

If the IE "Measured results on RACH" is present in the message, the UTRAN should extract the contents to be used for radio resource control.

8.5.24 Change of PLMN while in RRC connected mode

If the UE camps on an acceptable cell to obtain limited service while in RRC connected mode the UE shall either:

- 1> move to idle mode;
- 1> release all dedicated resources;
- 1> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;
- 1> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
- 1> clear the variable ESTABLISHED_RABS; and
- 1> perform actions specified in subclause 8.5.2 when entering idle mode from connected mode.

or

- 1> keep the RRC connection of the selected PLMN and its behaviour while camping on the cell of the other PLMN shall be as if in Idle mode in that PLMN;
- 1> if the UE re-enters "in service area" on the selected PLMN or cannot maintain limited service (i.e. cannot find any acceptable cell of any PLMN), the UE shall resume its RRC Connected mode behaviour as if it had not camped on any cell whilst being in "out of service area".

If the NAS indicates the selection of a new PLMN while the UE is in RRC connected mode in the selected PLMN or if the UE attempts transmission on a cell of another PLMN (i.e. to initiate emergency call), the UE shall for the selected PLMN:

- 1> move to idle mode:
- 1> release all dedicated resources;
- 1> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;
- 1> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;
- 1> clear the variable ESTABLISHED RABS; and
- 1> perform actions specified in subclause 8.5.2 when entering idle mode from connected mode.

8.6 Generic actions on receipt and absence of an information element

8.6.1 CN information elements

8.6.1.1 Void

8.6.1.2 CN information info

If the IE "CN information info" is present in a message, the UE shall:

- 1> if present, forward the content of the IE "PLMN identity" to upper layers;
- 1> if present, forward the content of the IE "CN common GSM-MAP NAS system information" to upper layers;
- 1> if the IE "CN domain related information" is present:
 - 2> forward each occurrence of the IE "CN domain specific GSM-MAP NAS system info" together with the IE "CN domain identity" to upper layers.
 - 2> if an IE "CN domain specific GSM-MAP NAS system info" is not present for a particular CN domain:

3> indicate to upper layers that no CN system information is available for that CN domain.

If the "PLMN identity" is present, the UE shall consider this PLMN to be the selected PLMN (see [4]).

8.6.1.3 Signalling connection release indication

If the IE "Signalling Connection release indication" is present in a message, the UE shall:

- 1> if all radio access bearers for the CN domain identified with the value of the IE "Signalling Connection release indication" would have been released in the variable ESTABLISHED_RABS after processing of the received message:
 - 2> indicate release of the signalling connection identified with the value of the IE "Signalling Connection release indication" to the upper layers;
 - 2> remove the signalling connection identified with the value of the IE "Signalling Connection release indication" from the variable ESTABLISHED_SIGNALLING_CONNECTIONS.
- 1> if radio access bearers for the CN domain identified with the value of the IE "Signalling Connection release indication" would remain in the variable ESTABLISHED RABS after processing of the received message:
 - 2> set the variable INVALID_CONFIGURATION to TRUE.

8.6.2 UTRAN mobility information elements

8.6.2.1 URA identity

The UE shall:

- 1> if the IE "URA identity" is included in a received message:
 - 2> if the IE "RRC State Indicator" is included and set to "URA PCH":
- 3> store this URA identity in the variable URA_IDENTITY;
- 3> after sending a possible message to UTRAN and entering URA_PCH state as specified elsewhere, read system information block type 2 in the selected cell;

- 3> if the stored URA identity in the variable URA_IDENTITY is not included in the list of URA identities in System Information Block type 2 in the selected cell, the list of URA identities in system information block type 2 is empty or if the system information block type 2 can not be found, a confirmation error of URA identity list has occurred:
 - 4> if no URA update procedure is ongoing:
 - 5> initiate a URA update procedure after entering URA_PCH state; see subclause 8.3.1.2.
 - 4> if a URA update procedure is ongoing:
 - 5> take actions as specified in subclause 8.3.1.10.
 - 1> if the IE "URA identity" is not included in a received message:
 - 2> if the IE "RRC State Indicator" is included and set to " URA_PCH":
- 3> after sending a possible message to UTRAN and entering URA_PCH state as specified elsewhere, read System Information Block type 2 in the selected cell;
- 3> if System Information Block type 2 in the selected cell contains a single URA identity:
 - 4> store this URA identity in the variable URA_IDENTITY.
- 3> if System Information Block type 2 of the selected cell contains more than one URA identity, the list of URA identities in system information block type 2 is empty or if the system information block type 2 can not be found, a confirmation error of URA identity list has occurred:
 - 4> if no URA update procedure is ongoing:
 - 5> initiate a URA update procedure after entering URA_PCH state, see subclause 8.3.1.2.
 - 4> if a URA update procedure is ongoing:
 - 5> take actions as specified in subclause 8.3.1.10.

8.6.2.2 Mapping info

If the IE "Mapping info" is received, the UE shall in this version of the specification:

1> ignore the contents of this IE.

8.6.3 UE information elements

8.6.3.1 Activation time

If the UE receives a message in which presence is needed for the IE "Activation time", and the value is other than the default value "Now", the UE shall:

- 1> let the "reference CCTrCH" be defined as the CCTrCh that includes any transport channel or is associated with any physical channel which is being added, re-configured or removed, or, in the case of DSCH (FDD only) or HS-DSCH, the CCTrCh including the associated DCH;
- 1> if the frame boundary immediately before the frame with the CFN (Connection Frame Number) value indicated by the IE "Activation Time" is at the TTI boundary common to all the transport channels that are multiplexed onto the reference CCTrCh:
 - 2> select that frame boundary as the activation time T.
- 1> else:
 - 2> select the next TTI boundary, which is common to all the transport channels that are multiplexed onto the reference CCTrCh, after the frame with the CFN (Connection Frame Number) value indicated by the IE "Activation Time", as the activation time T.
- 1> at the activation time T:

- 2> for a physical channel reconfiguration other than an HS-DSCH related reconfiguration, caused by the received message:
- 3> release the physical channel configuration, which was present before T;
- 3> initiate the establishment of the physical channel configuration as specified for the physical channel information elements in the received message as specified elsewhere.
 - 2> for an HS-DSCH related reconfiguration in FDD or 1.28 Mcps TDD caused by the received message:
- 3> select the HS-SCCH subframe boundary immediately before the first HS-SCCH subframe, which entirely falls within the 10 ms frame following T;
- 3> start using, at that HS-SCCH subframe boundary, the new HS-DSCH configuration in the received message, replacing any old HS-DSCH configuration.
 - 2> for an HS-DSCH related reconfiguration in 3.84 Mcps TDD caused by the received message:
- 3> start using, at activation time T, the new HS-DSCH configuration in the received message, replacing any old HS-DSCH configuration.
 - 2> for actions, other than a physical channel reconfiguration, caused by the received message:
- 3> perform the actions for the information elements in the received message as specified elsewhere.
 - NOTE: In FDD an "HS-DSCH related reconfiguration" includes, in particular, reconfigurations that need to be time-aligned with the 2ms subframe of the HS-SCCH, HS-PDSCH and/or HS-DPCCH. For example, start and stop of HS-SCCH reception and serving HS-DSCH cell change.

If the UE receives a message in which presence is needed for the IE "Activation time", and the value is the default value "Now", the UE shall:

- 1> choose an activation time T as soon as possible after the reception of the message, respecting the performance requirements in subclause 13.5;
- 1> at the activation time T:
 - 2> perform the actions for the information elements in the received message as specified elsewhere.
- NOTE: In FDD, if the UE was in idle mode or CELL_FACH state upon reception of the message, regardless of the state the UE enters after reception of the message, and the value of the IE "Activation time" in the received message is different from "Now", the UE behaviour is unspecified. In TDD, if the UE was in idle mode or CELL_FACH state upon reception of the message, the value of the IE "Activation time" in the received message is relative to the CFN associated with the cell from which the message was received.

8.6.3.1a CN domain specific DRX cycle length coefficient

The UE updates CN domain specific DRX cycle length coefficient as specified in [4]. The UE shall use it to calculate the CN domain specific DRX cycle length, according to the following:

- 1> set k to the value of the IE "CN domain specific DRX cycle length coefficient".
- 1> store the result of MAX(2^k, PBP), where PBP is the Paging Block Periodicity, as the CN domain specific DRX cycle length for the CN domain indicated by the IE "CN domain identity". For FDD PBP=1.

The UE shall determine its idle mode paging occasions and PICH monitoring occasions for that CN domain, according to [4], based on the stored CN domain specific DRX cycle length, when using DRX in idle mode.

8.6.3.1b H-RNTI

If the IE "New H-RNTI" is included, the UE shall:

1> if the IE "Downlink HS-PDSCH Information" is also included and the UE would enter CELL_DCH state according to subclause 8.6.3.3 applied on the received message:

2> store the value in the variable H_RNTI.

When the variable HS_DSCH_RECEPTION is set to TRUE the UE shall:

1> use the value of the variable H_RNTI as UE identity in the HS-SCCH reception procedure in the physical layer.

8.6.3.2 UTRAN DRX Cycle length coefficient

If the IE "UTRAN DRX cycle length coefficient" is present, the UE shall use it to calculate the UTRAN DRX cycle length, according to the following:

1> set k to the value of the IE "UTRAN DRX cycle length coefficient";

1> store the result of MAX(2^kPBP), where PBP is the Paging Block Periodicity, as the DRX cycle length.

The UE shall determine its connected mode paging occasions and PICH monitoring occasions in the same way as for idle mode, according to [4].

The DRX cycle length to use in connected mode is defined in [4].

8.6.3.3 Generic state transition rules depending on received information elements

The IE "RRC State Indicator" indicates the state the UE shall enter. The UE shall enter the state indicated by the IE "RRC State Indicator" even if the received message includes other IEs relevant only for states other than indicated by the IE "RRC State Indicator". E.g. if the RRC state indicator is set to CELL_FACH while other IEs provide information about a configuration including dedicated channels, the UE shall enter CELL_FACH state. If however the UE has no information about the configuration corresponding to the state indicated by the IE "RRC State Indicator", it shall consider the requested configuration as invalid.

The UE shall, if the IE "RRC State Indicator" in the received message has the value:

- 1> "CELL_FACH":
 - 2> enter CELL_FACH state as dictated by the procedure governing the message received.
- 1> "CELL DCH":
 - 2> if neither DPCH is assigned in the message nor is the UE in CELL_DCH:
- 3> set the variable INVALID_CONFIGURATION to TRUE.
 - 2> else:
- 3> enter CELL_DCH state as dictated by the procedure governing the message received.
 - 1> "CELL_PCH":
 - 2> if the received message is RRC CONNECTION SETUP and IE "RRC State Indicator" is set to CELL_PCH:
- 3> set the variable INVALID_CONFIGURATION to TRUE.
 - 2> else:
- 3> enter CELL_PCH state as dictated by the procedure governing the message received.
 - 1> "URA PCH":
 - 2> if the received message is RRC CONNECTION SETUP and IE "RRC State Indicator" is set to URA_PCH:
- 3> set the variable INVALID_CONFIGURATION to TRUE.
 - 2> else:
- 3> enter URA_PCH state as dictated by the procedure governing the message received.

8.6.3.4 Ciphering mode info

The IE "Ciphering mode info" defines the new ciphering configuration. At any given time, the UE needs to store at most two different ciphering configurations (keyset and algorithm) per CN domain at any given time in total for all radio bearers and three configurations in total for all signalling radio bearers.

If the IE "Ciphering mode info" is present and if the IE "Reconfiguration" in the variable CIPHERING_STATUS is set to TRUE, the UE shall:

- 1> ignore this second attempt to change the ciphering configuration; and
- 1> set the variable INCOMPATIBLE SECURITY RECONFIGURATION to TRUE.

If the IE "Ciphering mode info" is present and if the IE "Reconfiguration" in the variable CIPHERING_STATUS is set to FALSE, the UE shall:

- 1> if none of the IE "Status" in the variable CIPHERING STATUS has the value "Started", and this IE "Ciphering mode info" was included in a message that is not the message SECURITY MODE COMMAND; or
- 1> if the IE "Ciphering Mode Info" was received in the message SECURITY MODE COMMAND and there does not exist exactly one ciphering activation time in the IE "Radio bearer downlink ciphering activation time info" for each established RLC-AM and RLC-UM radio bearers included in the IE "RB information" in the IE "ESTABLISHED_RABS" for the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN; or
- 1> if the IE "Ciphering Mode Info" was received in the message SECURITY MODE COMMAND and the IE "Ciphering activation time for DPCH" is not included in the message, and there exist radio bearers using RLC-TM according to the IE "RB information" in the IE "ESTABLISHED_RABS" for the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN; or
- 1> if the IE "Ciphering Mode Info" was received in the message SECURITY MODE COMMAND and there does not exist exactly one ciphering activation time in the IE "Radio bearer downlink ciphering activation time info" for each established signalling radio bearer included in the IE "Signalling radio bearer information" in the IE "ESTABLISHED_RABS":
 - 2> ignore this attempt to change the ciphering configuration;
 - 2> set the variable INVALID_CONFIGURATION to TRUE;
 - 2> perform the actions as specified in subclause 8.1.12.4c.
- 1> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to TRUE;
- 1> set the IE "Status" in the variable CIPHERING_STATUS of the CN domains for which the IE "Status" of the variable SECURITY_MODIFICATION is set to "Affected" to "Started";
- 1> apply the new ciphering configuration in the lower layers for all RBs that belong to a CN domain for which the IE "Status" of the variable SECURITY_MODIFICATION is set to "Affected" and all signalling radio bearers:
 - 2> using the ciphering algorithm (UEA [40]) indicated by the IE "Ciphering algorithm" as part of the new ciphering configuration;
 - 2> for each radio bearer that belongs to a CN domain for which the IE "Status" of the variable SECURITY_MODIFICATION is set to "Affected" and all signalling radio bearers:

3> using the value of the IE "RB identity" in the variable ESTABLISHED_RABS minus one as the value of BEARER [40] in the ciphering algorithm.

- 1> for the downlink and the uplink, apply the new ciphering configuration as follows:
 - 2> if the ciphering configuration for a AM or UM radio bearer or signalling radio bearer from a previously received SECURITY MODE COMMAND has not yet been applied because of the corresponding activation times not having been reached and the current received message includes the IE "DL Counter Synch Info" or the current received message is a RADIO BEARER RECONFIGURATION message and includes the IE "New U-RNTI":

- 3> if the previous SECURITY MODE COMMAND was received due to new keys being received:
 - 4> consider the new ciphering configuration to include the received new keys.
- 3> else if the previous SECURITY MODE COMMAND caused a change in LATEST_CONFIGURED_CN_DOMAIN:
 - 4> consider the new ciphering configuration to include the keys associated with the LATEST_CONFIGURED_CN_DOMAIN.
 - 3> apply the new ciphering configuration in uplink and downlink immediately following RLC re-establishment.
 - 2> if the IE "Ciphering activation time for DPCH" is present in the IE "Ciphering mode info" and the UE was in CELL_DCH state prior to this procedure:
- 3> for radio bearers using RLC-TM:
 - 4> apply the old ciphering configuration for CFN less than the number indicated in the IE "Ciphering activation time for DPCH";
 - 4> apply the new ciphering configuration for CFN greater than or equal to the number indicated in IE "Ciphering activation time for DPCH".
 - 2> if the IE "Radio bearer downlink ciphering activation time info" is present:
- 3> apply the following procedure for each radio bearer and signalling radio bearers using RLC-AM or RLC-UM indicated by the IE "RB identity":
 - 4> suspend uplink transmission on the radio bearer or the signalling radio bearer (except for the SRB where the response message is transmitted) according to the following:
 - 5> do not transmit RLC PDUs with sequence number greater than or equal to the uplink activation time, where the uplink activation time is selected according to the rules below.
 - 4> select an "RLC sequence number" at which (activation) time the new ciphering configuration shall be applied in uplink for that radio bearer according to the following:
 - 5> consider a ciphering activation time in uplink to be pending until the RLC sequence number of the next RLC PDU to be transmitted for the first time is equal to or larger than the selected activation time:
 - 5> for each radio bearer and signalling radio bearer that has no pending ciphering activation time in uplink as set by a previous procedure changing the security configuration:
 - 6> set a suitable value that would ensure a minimised delay in the change to the latest ciphering configuration.
 - 5> for each radio bearer and signalling radio bearer that has a pending ciphering activation time in uplink as set by a previous procedure changing the security configuration:
 - 6> for radio bearers and signalling radio bearers except SRB2:
 - 7> set the same value as the pending ciphering activation time.
 - 6> for signalling radio bearer SRB2:
 - 7> set a suitable value that would ensure a minimised delay in the change to the latest ciphering configuration.
 - 4> store the selected "RLC sequence number" for that radio bearer in the entry for the radio bearer in the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;
 - 4> switch to the new ciphering configuration according to the following:
 - 5> use the old ciphering configuration for the transmitted and received RLC PDUs with RLC sequence numbers smaller than the corresponding RLC sequence numbers indicated in the IE

- "Radio bearer uplink ciphering activation time info" sent to UTRAN and in the received IE "Radio bearer downlink ciphering activation time info" received from UTRAN, respectively;
- 5> use the new ciphering configuration for the transmitted and received RLC PDUs with RLC sequence numbers greater than or equal to the corresponding RLC sequence numbers indicated in the IE "Radio bearer uplink ciphering activation time info" sent to UTRAN and in the received IE "Radio bearer downlink ciphering activation time info" received from UTRAN, respectively;
- 5> for a radio bearer using RLC-AM, when the RLC sequence number indicated in the IE "Radio bearer downlink ciphering activation time info" falls below the RLC receiving window and the RLC sequence number indicated in the IE "Radio bearer uplink ciphering activation time info" falls below the RLC transmission window, the UE may release the old ciphering configuration for that radio bearer;
- 5> if an RLC reset or re-establishment of the transmitting side of an RLC entity occurs before the activation time for the new ciphering configuration has been reached in uplink, ignore the activation time and apply the new ciphering configuration in uplink immediately after the RLC reset or RLC re-establishment;
- 5> if an RLC reset or re-establishment of the receiving side of an RLC entity occurs before the activation time for the new ciphering configuration has been reached in downlink, ignore the activation time and apply the new ciphering configuration in downlink immediately after the RLC reset or RLC re-establishment.

If the IE "Ciphering mode info" is not present, the UE shall:

- 1> for the downlink and the uplink, apply the ciphering configuration as follows:
 - 2> if the ciphering configuration for a AM or UM radio bearer or signalling radio bearer from a previously received SECURITY MODE COMMAND has not yet been applied because of the corresponding activation times not having been reached and the current received message includes the IE "DL Counter Synch Info" or the current received message is a RADIO BEARER RECONFIGURATION message and includes the IE "New U-RNTI":
- 3> if the previous SECURITY MODE COMMAND was received due to new keys being received:
 - 4> consider the ciphering configuration to include the received new keys.

3> else if the previous SECURITY MODE COMMAND caused a change in LATEST_CONFIGURED_CN_DOMAIN:

- 4> consider the ciphering configuration to include the keys associated with the LATEST_CONFIGURED_CN_DOMAIN.
- 3> apply the ciphering configuration in uplink and downlink immediately following RLC re-establishment.

2> else:

3> not change the ciphering configuration.

8.6.3.5 Integrity protection mode info

The IE "Integrity protection mode info" defines the new integrity protection configuration. At any given time, the UE needs to store at most three different integrity protection configurations (keysets) in total for all signalling radio bearers for all CN domains.

If the IE "Integrity protection mode info" is present and if the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO is set to TRUE, the UE shall:

- 1> ignore this second attempt to change the integrity protection configuration; and
- 1> set the variable INCOMPATIBLE_SECURITY_RECONFIGURATION to TRUE.

If the IE "Integrity protection mode command" has the value "Start", the IE "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Not started" and the IE "Integrity protection mode info" was not included in the message SECURITY MODE COMMAND; or

If the IE "Integrity protection mode command" has the value "Start", the IE "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Not started", the IE "Integrity protection mode info" was included in the message SECURITY MODE COMMAND and the IE "Integrity protection algorithm" is not included; or

If the IE "Integrity protection mode command" has the value "Modify" and the IE "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Not Started"; or

If the IE "Integrity protection mode command" has the value "Start", the IE "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Started" and the IE "Integrity protection mode command info" was included in the message SECURITY MODE COMMAND; or

If the IE "Integrity protection mode command" has the value "Modify" and there does not exist exactly one integrity protection activation time in the IE "Downlink integrity protection activation info" for each established signalling radio bearer included in the IE "Signalling radio bearer information" in the IE "ESTABLISHED RABS"; or

If the IE "Integrity protection mode command" has the value "Modify", the IE "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Started" and the IE "Integrity protection mode info" was not included in the message SECURITY MODE COMMAND:

the UE shall:

- 1> ignore this attempt to change the integrity protection configuration; and
- 1> set the variable INVALID CONFIGURATION to TRUE.

If the IE "Integrity protection mode info" is not present, the UE shall:

1> not change the integrity protection configuration.

If the IE "Integrity protection mode info" is present and if the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO is set to FALSE, the UE shall:

1> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to TRUE;

1> perform the actions in accordance with subclauses 8.6.3.5.1, 8.6.3.5.2 and 8.6.3.5.3.

8.6.3.5.1 Initialisation of Integrity Protection

The UE shall:

- 1> if the IE "Integrity protection mode command" has the value "start" and the IE "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Not started", and this IE was included in the message SECURITY MODE COMMAND:
 - 2> initialise the information for all signalling radio bearers in the variable INTEGRITY_PROTECTION_INFO according to the following:
- 3> set the IE "Uplink RRC Message sequence number" in the variable INTEGRITY_PROTECTION_INFO to zero;
- 3> do not set the IE "Downlink RRC Message sequence number" in the variable INTEGRITY_PROTECTION_INFO;
- 3> set the variable INTEGRITY_PROTECTION_ACTIVATION_INFO to zero for each signalling radio bearer in the IE "ESTABLISHED_RABS".
 - NOTE: The IEs "Integrity protection activation info" and "RRC Message sequence number"included in the IE "Integrity Check Info" in the transmitted message do not have identical values, but integrity protection is applied from the first transmitted message.
 - 2> set the IE "Status" in the variable INTEGRITY_PROTECTION_INFO to the value "Started";
 - 2> perform integrity protection on the received message, applying the new integrity protection configuration, as described in subclause 8.5.10.1 by:

3> using the algorithm (UIA [40]) indicated by the IE "Integrity protection algorithm" contained in the IE "Integrity protection mode info";

3> using the IE "Integrity protection initialisation number", contained in the IE "Integrity protection mode info" as the value of FRESH [40].

- 2> start applying the new integrity protection configuration in the downlink for each signalling radio bearer in the IE "ESTABLISHED_RABS" except RB2 at the next received RRC message;
- 2> start applying the new integrity protection configuration in the downlink for signalling radio bearer RB2 from and including the received SECURITY MODE COMMAND message;
- 2> start applying the new integrity protection configuration in the uplink for signalling radio bearer RB2 from and including the transmitted SECURITY MODE COMPLETE message;
- 2> start applying the new integrity protection configuration in the uplink for signalling radio bearers other than RB2 at the uplink activation time included in the IE "Uplink integrity protection activation info".

8.6.3.5.2 Integrity Protection Re-configuration for SRNS Relocation and handover from GERAN lu mode

The UE shall:

1> if IE "Integrity protection mode command" has the value "start" and the IE "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Started" and this IE was not included SECURITY MODE COMMAND:

NOTE: This case is used in SRNS relocation and in handover from GERAN *Iu mode*.

2> perform integrity protection on the received message, applying the new integrity protection configuration, as described in subclause 8.5.10.1 by:

3> using the algorithm (UIA [40]) indicated by the IE "Integrity protection algorithm" contained in the IE "Integrity protection mode info";

3> using the IE "Integrity protection initialisation number", contained in the IE "Integrity protection mode info" as the value of FRESH [40].

- 2> let RBm be the signalling radio bearer where the reconfiguration message was received and let RBn be the signalling radio bearer where the response message is transmitted;
- 2> prohibit transmission of RRC messages on all signalling radio bearers in the IE "ESTABLISHED_RABS" except on RBO and the radio bearer where the response message is transmitted;
- 2> for the downlink, for each signalling radio bearer, if for the signalling radio bearer, a security configuration triggered by a previous SECURITY MODE COMMAND has not yet been applied, due to the activation time for the signalling radio bearer not having been reached:

3> set "Down link RRC Message sequence number" for this signalling radio bearer in the variable INTEGRITY_PROTECTION_INFO to (activation time -1), where the activation time is the corresponding activation time for this signalling radio bearer;

- 3> if the previous SECURITY MODE COMMAND was received due to new keys being received:
 - 4> consider the new integrity protection configuration to include the received new keys.

3> else if the previous SECURITY MODE COMMAND caused a change in LATEST_CONFIGURED_CN_DOMAIN:

4> consider the new Integrity Protection configuration to include the keys associated with the LATEST_CONFIGURED_CN_DOMAIN associated with the previously received SECURITY MODE COMMAND.

- 2> start applying the new integrity protection configuration in the downlink for each signalling radio bearer in the IE "ESTABLISHED_RABS" except RBm at the next received RRC message for the corresponding signalling radio bearer;
- 2> start applying the new integrity protection configuration in the downlink for signalling radio bearer RBm from and including the received configuration message;
- 2> start applying the new integrity protection configuration in the uplink for signalling radio bearer RBn from and including the transmitted response message;
- 2> start applying the new integrity protection configuration in the uplink for signalling radio bearers other than RBn from the first message onwards.

8.6.3.5.3 Integrity Protection modification in case of new keys or initialisation of signalling connection

The UE shall:

- 1> if the IE "Integrity protection mode command" has the value "modify" and the IE "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Started" and this IE was included in SECURITY MODE COMMAND:
 - 2> store the (oldest currently used) integrity protection configuration until activation times have elapsed for the new integrity protection configuration to be applied on all signalling radio bearers;
 - 2> start applying the new integrity protection configuration in the downlink for each signalling radio bearer n, at the first received message with RRC Sequence number greater than or equal to the RRC sequence number indicated by the entry for signalling radio bearer n in the "RRC message sequence number list" in the IE "Downlink integrity protection activation info", included in the IE "Integrity protection mode info";
 - 2> perform integrity protection on the received message, applying the new integrity protection configuration, as described in subclause 8.5.10.1;
- 3> if present, use the algorithm indicated by the IE "Integrity protection algorithm" (UIA [40]);
 - 2> set the content of the variable INTEGRITY_PROTECTION_ACTIVATION_INFO according to the following:
- 3> for each established signalling radio bearer, stored in the variable ESTABLISHED_RABS:
 - 4> select a value of the RRC sequence number at which (activation) time the new integrity protection configuration shall be applied in uplink for that signalling radio bearer according to the following:
 - 5> for each signalling radio bearer except RB0:
 - 6> set the activation time for the new integrity protection configuration to the next RRC SN.
 - 4> for signalling radio bearer RB0:
 - 5> set the value of the included RRC sequence number to greater than or equal to the current value of the RRC sequence number for signalling radio bearer RB0 in the variable INTEGRITY_PROTECTION_INFO, plus the value of the constant N302 plus two.
 - 4> prohibit the transmission of RRC messages on all signalling radio bearers, except for RB2, with RRC SN greater than or equal to the value in the "RRC message sequence number list" for the signalling radio bearer in the IE "Uplink integrity protection activation info" of the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.
 - 2> start applying the new integrity protection configuration in the uplink at the RRC sequence number, for each RBn, except for signalling radio bearer RB2, indicated by the entry for signalling radio bearer n in the "RRC message sequence number list" in the IE "Uplink integrity protection activation info", included in the variable INTEGRITY_PROTECTION_ACTIVATION_INFO;
 - 2> start applying the new integrity protection configuration in the uplink at the RRC sequence number for signalling radio bearer RB2, as specified for the procedure initiating the integrity protection reconfiguration;

- 2> start applying the new integrity protection configuration in the downlink at the RRC sequence number, for each RBn, except for signalling radio bearer RB2, indicated by the entry for signalling radio bearer n in the "RRC message sequence number list" in the IE "Downlink integrity protection activation info";
- NOTE: For signalling radio bearers that have a pending activation time as set for integrity protection by a previous procedure changing the integrity protection configuration, UTRAN should set this value in IE "Downlink integrity protection activation info".
 - 2> start applying the new integrity protection configuration in the downlink at the RRC sequence number for signalling radio bearer RB2, as specified for the procedure initiating the integrity protection reconfiguration.

8.6.3.6 Void

8.6.3.7 Void

8.6.3.8 Integrity check info

If the IE "Integrity check info" is present the UE shall:

1> act as described in subclause 8.5.10.1.

8.6.3.9 New C-RNTI

If the IE "New C-RNTI" is included, the UE shall:

1> store the value in the variable C_RNTI, replacing any old stored value;

1> use that C-RNTI when using common transport channels of type RACH, FACH and CPCH in the current cell.

8.6.3.9a New DSCH-RNTI

If the IE "New DSCH-RNTI" is included, the UE shall:

1> in FDD:

- 2> if the UE will be in CELL_DCH at the end of the procedure where the received message included this IE:
- 3> if the UE supports DSCH as indicated in the IE "Physical Channel Capability" included in the IE "UE Radio Access Capability":
 - 4> store the value in the variable DSCH_RNTI, replacing any old stored value;
 - 4> use that DSCH-RNTI when using common transport channels of type DSCH in the current cell.

1> in TDD:

- 2> if the UE will be in CELL_DCH or CELL_FACH at the end of the procedure where the received message included this IE:
- 3> if the UE supports DSCH or USCH as indicated in the IE "Physical Channel Capability" included in the IE "UE Radio Access Capability":
 - 4> store the value in the variable DSCH_RNTI, replacing any old stored value;
 - 4> use that DSCH-RNTI when using SHCCH signalling in the current cell.

8.6.3.10 New U-RNTI

If the IE "New U-RNTI" is included in a received message, the UE shall:

1> store the value in the variable U_RNTI, replacing any old stored value.

8.6.3.11 RRC transaction identifier

The IE "RRC transaction identifier" may be used, together with the message type, for identification of an invocation of a downlink procedure (transaction). The UE behaviour for accepting or rejecting transactions based on the message type and the IE "RRC transaction identifier" is specified below.

If the IE "RRC transaction identifier" is included in a received message, the UE shall perform the actions below. The UE shall:

If the received message is any of the messages:

- RADIO BEARER SETUP; or
- RADIO BEARER RECONFIGURATION; or
- RADIO BEARER RELEASE; or
- TRANSPORT CHANNEL RECONFIGURATION; or
- PHYSICAL CHANNEL RECONFIGURATION:

the UE shall:

- 1> if the variable ORDERED_RECONFIGURATION is set to FALSE; and
- 1> if the variable CELL_UPDATE_STARTED is set to FALSE; and
- 1> if the received message does not contain a protocol error according to clause 9 and the variable PROTOCOL_ERROR_REJECT is set to FALSE; and
- 1> if the table "Accepted transactions" in the variable TRANSACTIONS does not contain an entry with an IE "Message Type" set to ACTIVE SET UPDATE:
 - 2> accept the transaction; and
 - 2> store the IE "Message type" and the IE "RRC transaction identifier" of the received message in the table "Accepted transactions" in the variable TRANSACTIONS.

1> else:

- 2> if the variable ORDERED_RECONFIGURATION is set to TRUE; or
- 2> if the variable CELL UPDATE STARTED is set to TRUE; or
- 2> if the table "Accepted transactions" in the variable TRANSACTIONS contains an entry with an IE "Message Type" set to ACTIVE SET UPDATE; or
- 2> if the received message contains a protocol error according to clause 9 causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE:
- 3> if the IE "RRC transaction identifier" of the received message is identical to the "RRC transaction identifier" stored for the same "Message Type" as the received message in the table "Accepted transactions" in the variable TRANSACTIONS:
 - 4> ignore the transaction; and
 - 4> continue with any ongoing processes and procedures as the message was not received;
 - 4> and end the procedure.

3> else:

4> reject the transaction; and

- 4> if the IE "Message Type" of the received message is not present in the table "Rejected transactions" in the variable TRANSACTIONS:
 - 5> store the IE "Message type" and the IE "RRC transaction identifier" of the received message in the table "Rejected transactions" in the variable TRANSACTIONS.

Else:

If the received message is any of the messages:

- RRC CONNECTION SETUP; or
- CELL UPDATE CONFIRM; or
- URA UPDATE CONFIRM; or
- UE CAPABILITY ENQUIRY:

the UE shall:

- 1> if the IE "Message Type" of the received message is not present in the table "Accepted transactions" in the variable TRANSACTIONS:
 - 2> if the received message does not contain a protocol error according to clause 9 and the variable PROTOCOL_ERROR_REJECT is set to FALSE:
- 3> accept the transaction; and
- 3> store the IE "Message type" and the IE "RRC transaction identifier" of the received message in the table "Accepted transactions" in the variable TRANSACTIONS.
 - 2> else:
 - 2> if the received message contains a protocol error according to clause 9 causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE:
- 3> reject the transaction; and
- 3> if the IE "Message Type" of the received message is not present in the table "Rejected transactions" in the variable TRANSACTIONS:
 - 4> store the IE "Message type" and the IE "RRC transaction identifier" of the received message in the table "Rejected transactions" in the variable TRANSACTIONS.
 - 1> else:
 - 1> if the IE "Message Type" of the received message is present in the table "Accepted transactions" in the variable TRANSACTIONS:
 - 2> if the IE "RRC transaction identifier" of the received message is identical to the "RRC transaction identifier" stored for the "Message Type" in the table "Accepted transactions" in the variable TRANSACTIONS:
- 3> ignore the transaction; and
- 3> continue with any ongoing processes and procedures as the message was not received; and
- 3> end the procedure.
 - 2> else:
 - 2> if the IE "RRC transaction identifier" of the received message is different from the "RRC transaction identifier" stored for the "Message Type" in the table "Accepted transactions" in the variable TRANSACTIONS:
- 3> if the received message does not contain a protocol error according to clause 9 and the variable PROTOCOL_ERROR_REJECT is set to FALSE:

- 4> ignore the once accepted transaction and instead accept the new transaction; and
- 4> store the IE "Message type" and the IE "RRC transaction identifier" of the received message in the table "Accepted transactions" in the variable TRANSACTIONS, replacing the previous entry.
- NOTE 1: The UE is expected to process the first RRC CONNECTION SETUP/CELL UPDATE CONFIRM/URA UPDATE COMFIRM message that it receives after transmitting an RRC CONNECTION REQUEST/CELL_UPDATE/URA_UPDATE message. If the UE receives further RRC CONNECTION SETUP/CELL UPDATE CONFIRM/URA UPDATE COMFIRM messages without having transmitted another RRC CONNECTION REQUEST/CELL_UPDATE/URA_UPDATE message, the UE is not required to process these messages.
- NOTE 2: If the previously accepted transaction was a CELL UPDATE CONFIRM/URA UPDATE CONFIRM that included the IE "Dowlink counter synchronisation info", rather than ignore the first accepted transaction the UE may continue with the first transaction in the case where a cell re-selection interrupted the ongoing procedure causing a cell update procedure to be triggered. In this case the response message acts as an explicit acknowledgement of both the CELL UPDATE CONFIRM/URA UPDATE CONFIRM message signalling an SRNS relocation and the subsequent CELL UPDATE CONFIRM/URA UPDATE CONFIRM.

3> else:

3> if the received message contains a protocol error according to clause 9 causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE:

- 4> reject the transaction; and
- 4> if the IE "Message Type" of the received message is not present in the table "Rejected transactions" in the variable TRANSACTIONS:
 - 5> store the IE "Message type" and the IE "RRC transaction identifier" of the received message in the table "Rejected transactions" in the variable TRANSACTIONS.

Else:

If the received message is any of the messages:

- HANDOVER FROM UTRAN COMMAND; or
- CELL CHANGE ORDER FROM UTRAN:

the UE shall:

- 1> if the variable ORDERED_RECONFIGURATION is set to TRUE;
 - 2> reject the transaction; and
 - 2> if the IE "Message Type" of the received message is not present in the table "Rejected transactions" in the variable TRANSACTIONS:
 - 3> store the IE "Message type" and the IE "RRC transaction identifier" of the received message in the table "Rejected transactions" in the variable TRANSACTIONS.

Else:

If the received message is any other message, the UE shall:

- 1> if the IE "Message Type" of the received message is not present in the table "Accepted transactions" in the variable TRANSACTIONS:
 - 2> if the received message does not contain a protocol error according to clause 9 and the variable PROTOCOL_ERROR_REJECT is set to FALSE:

3> accept the transaction; and

3> store the IE "Message type" and the IE "RRC transaction identifier" of the received message in the table "Accepted transactions" in the variable TRANSACTIONS.

- 2> else:
- 2> if the received message contains a protocol error according to clause 9 causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE:
- 3> reject the transaction; and
- 3> store the IE "Message type" and the IE "RRC transaction identifier" of the received message in the table "Rejected transactions" in the variable TRANSACTIONS.
 - 1> else:
 - 1> if the IE "Message Type" of the received message is present in the table "Accepted transactions" in the variable TRANSACTIONS:
 - 2> if the IE "RRC transaction identifier" of the received message is identical to the "RRC transaction identifier" stored in any entry for the "Message Type" in the table "Accepted transactions" in the variable TRANSACTIONS:
- 3> ignore the transaction; and
- 3> continue with any ongoing processes and procedures as the message was not received; and
- 3> end the procedure.
 - 2> else:
 - 2> if the IE "RRC transaction identifier" of the received message is different from the "RRC transaction identifier" stored in all entries for the "Message Type" in the table "Accepted transactions" in the variable TRANSACTIONS:
- 3> if the received message does not contain a protocol error according to clause 9 and the variable PROTOCOL_ERROR_REJECT is set to FALSE:
 - 4> accept the additional transaction; and
 - 4> store the IE "Message type" and the IE "RRC transaction identifier" of the received message in the table "Accepted transactions" in the variable TRANSACTIONS, in addition to the already existing entries.
- 3> else:
- 3> if the received message contains a protocol error according to clause 9 causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE:
 - 4> reject the transaction; and
 - 4> store the IE "Message type" and the IE "RRC transaction identifier" of the received message in the table "Rejected transactions" in the variable TRANSACTIONS.

8.6.3.12 Capability Update Requirement

If the IE "Capability Update Requirement" is included the UE shall:

- 1> if the IE "UE radio access FDD capability update requirement" has the value TRUE:
 - 2> if the UE supports FDD mode:
- 3> store its UTRA FDD capabilities and its UTRA capabilities common to FDD and TDD in the IE "UE radio access capability" and the IE "UE radio access capability extension" in variable UE_CAPABILITY_REQUESTED as specified below:
 - 4> if the UE supports multiple UTRA FDD Frequency Bands; or
 - 4> if the UE supports a single UTRA FDD Frequency Band different from Band I [21]:

- 5> store the IE "UE radio access capability", excluding IEs "RF capability FDD" and "Measurement capability";
- 5> store the IE "UE radio access capability extension", including the IEs "RF capability FDD extension" and the "Measurement capability extension" associated with each supported UTRA FDD frequency band indicated in the IE "Frequency band".
- 4> else:
 - 5> store the IE "UE radio access capability", including the IEs "RF capability FDD" and "Measurement capability" associated with the Band I [21].
- 1> if the IE "UE radio access 3.84 Mcps TDD capability update requirement" has the value TRUE:
 - 2> if the UE supports 3.84 Mcps TDD mode:
- 3> store its UTRAN-specific 3.84 Mcps TDD capabilities and its UTRAN-specific capabilities common to FDD and TDD in the variable UE_CAPABILITY_REQUESTED.
 - 1> if the IE "UE radio access 1.28 Mcps TDD capability update requirement" has the value TRUE:
 - 2> if the UE supports 1.28 Mcps TDD mode:
- 3> store its UTRAN-specific 1.28 Mcps TDD capabilities and its UTRAN-specific capabilities common to FDD and TDD in the variable UE_CAPABILITY_REQUESTED.
 - 1> if the IE "System specific capability update requirement list" is present:
 - 2> for each of the RAT requested in the IE "UE system specific capability"
- 3> if the UE supports the listed RAT:
 - 4> include its inter-RAT radio access capabilities for the listed RAT in the IE "UE system specific capability" from the variable UE_CAPABILITY_REQUESTED.

If the IE " Capability update requirement " is not present, the UE shall:

1> assume the default values as specified in subclause 10.3.3.2 and act in accordance with the above.

8.6.3.13 Group release information

The UE shall apply the following procedure to compare the IE "U-RNTI group" with the U-RNTI allocated to the UE stored in the variable U_RNTI.

If the IE "group discriminator" is equal to "All":

1> consider this as a group identity match.

If the IE "group discriminator" is equal to "U-RNTI mask":

- 1> let N be the value of the IE "U-RNTI bit mask index";
- 1> if N is equal to b20, b21, ... or b31:
 - 2> compare pairs of bits, starting from bit b31 downto, and including, bit N of the "SRNC identity" of the IE "U-RNTI" with the corresponding bits stored in the variable U_RNTI;
 - 2> if all pairs of bits are equal:
- 3> consider this as a group identity match.
 - 1> if N is equal to b1, b2, ... or b19:
 - 2> compare pairs of bits, starting from bit b31 downto, and including, bit b20 of the "SRNC identity" in the IE "U-RNTI" with the corresponding bits of the "SRNC identity" stored in the variable U_RNTI;
 - 2> if all pairs of bits are equal:

- 3> then compare pairs of bits, starting from bit b19 downto, and including, bit N of the "S-RNTI" in the IE "U-RNTI" with the corresponding bits of the "S-RNTI" stored in the variable U_RNTI;
- 3> if all pairs of bits are equal:
 - 4> consider this as a group identity match.

8.6.4 Radio bearer information elements

8.6.4.1 Signalling RB information to setup list

If the IE "Signalling RB information to setup list" is included the UE shall:

- 1> use the same START value to initialise the COUNT-C and COUNT-I variables for all the signalling radio bearers in the list;
- 1> if the IE "Signalling RB information to setup list" was included in the RADIO BEARER SETUP message:
 - 2> if the variable LATEST_CONFIGURED_CN_DOMAIN has been initialised:
- 3> calculate the START value only once during this procedure according to subclause 8.5.9 for the CN domain indicated in the variable LATEST_CONFIGURED_CN_DOMAIN;
- 3> store the calculated START value in the variable START_VALUE_TO_TRANSMIT.
 - 1> for each occurrence of the IE "Signalling RB information to setup":
 - 2> use the value of the IE "RB identity" as the identity of the signalling radio bearer to setup;
 - 2> if the signalling radio bearer identified with the IE "RB identity" does not exist in the variable ESTABLISHED_RABS:
- 3> create a new entry for the signalling radio bearer in the variable ESTABLISHED_RABS.
 - 2> if the IE "Signalling RB information to setup list" was received in a message other than HANDOVER TO UTRAN COMMAND; and
 - 2> if the variable LATEST_CONFIGURED_CN_DOMAIN has been initialised and the value "STATUS" of the variable CIPHERING_STATUS of the CN domain stored in this variable is "Started":
- 3> if the IE "Uplink RLC mode" or the IE "Downlink RLC mode" either in the IE "RLC info" or referenced by the RB identity in the IE "Same as RB" is set to "AM RLC" or "UM RLC":
 - 4> initialise the 20 MSB of the hyper frame number component of COUNT-C for this signalling radio bearer with the START value in the variable START_VALUE_TO_TRANSMIT;
 - 4> set the remaining LSB of the hyper frame number component of COUNT-C for this signalling radio bearer to zero;
 - 4> start to perform ciphering on this signalling radio bearer, using the value of the IE "RB identity" minus one as the value of BEARER in the ciphering algorithm.
 - 2> if the IE "Signalling RB information to setup list" was received in a message other than HANDOVER TO UTRAN COMMAND; and
 - 2> if the variable LATEST_CONFIGURED_CN_DOMAIN has been initialised and the value "Status" of the variable "INTEGRITY PROTECTION INFO" of the CN domain stored in this variable is "Started":
- 3> initialise the 20 MSB of the hyper frame number component of COUNT-I for this signalling radio bearer with the START value in the variable START_VALUE_TO_TRANSMIT;
- 3> set the remaining LSB of the hyper frame number component of COUNT-I for this signalling radio bearer to zero;
- 3> for this signalling radio bearer, set the IE "Uplink RRC Message sequence number" in the variable INTEGRITY_PROTECTION_INFO to zero;

- 3> start performing integrity protection according to subclauses 8.5.10.1 and 8.5.10.2.
 - 2> perform the actions for the IE "RLC info" as specified in subclause 8.6.4.9, applied for that signalling radio bearer:
 - 2> perform the actions for the IE "RB mapping info" as specified in subclause 8.6.4.8, applied for that signalling radio bearer.
 - 1> apply a default value of the IE "RB identity" equal to 1 for the first IE "Signalling RB information to setup"; and
 - 1> increase the default value by 1 for each occurrence.

8.6.4.2 RAB information for setup

If the IE "RAB information for setup" is included, the procedure is used to establish radio bearers belonging to a radio access bearer, and the UE shall:

- 1> if several IEs "RAB information for setup" are included and the included IEs "CN domain identity" in the IE "RAB info" does not all have the same value:
 - 2> set the variable INVALID_CONFIGURATION to TRUE.
- 1> if the radio access bearer identified with the IE "RAB info" does not exist in the variable ESTABLISHED_RABS:
 - 2> create a new entry for the radio access bearer in the variable ESTABLISHED_RABS;
 - 2> store the content of the IE "RAB info" in the entry for the radio access bearer in the variable ESTABLISHED_RABS;
 - 2> indicate the establishment of the radio access bearer to the upper layer entity using the IE "CN domain identity", forwarding the content of the IE "RAB identity";
 - 2> if prior to this procedure there exists no transparent mode radio bearer for the CN domain included in the IE "CN domain identity" and at least one transparent mode radio bearer is included in the IE "RB information to setup"; or
 - 2> if at least one RLC-AM or RLC-UM radio bearer is included in the IE "RB information to setup":
- 3> calculate the START value only once during this procedure (the same START value shall be used on all new radio bearers created for this radio access bearer) according to subclause 8.5.9 for the CN domain as indicated in the IE "CN domain identity" in the IE "RAB info" part of the IE "RAB information to setup";
- 3> store the calculated START value in the variable START_VALUE_TO_TRANSMIT.
 - 1> for each radio bearer in the IE "RB information to setup":
 - 2> if the radio bearer identified with the IE "RB identity" does not exist in the variable ESTABLISHED_RABS:
- 3> perform the actions specified in subclause 8.6.4.3;
- 3> store information about the new radio bearer in the entry for the radio access bearer identified by "RAB info" in the variable ESTABLISHED_RABS;
- 3> create a new RAB subflow for the radio access bearer:
- 3> number the RAB subflow in ascending order, assigning the smallest number to the RAB subflow corresponding to the first radio bearer in the list;
- 3> if the IE "CN domain identity" in the IE "RAB info" is set to "PS domain" and the number of RAB subflows for the radio access bearer is greater than 1:
 - 4> set the variable INVALID_CONFIGURATION to TRUE.
 - 2> if the radio bearer identified with the IE "RB identity" already exists in the variable ESTABLISHED_RABS:
- 3> set the variable INVALID_CONFIGURATION to TRUE.

8.6.4.2a RAB information to reconfigure

If the IE "RAB information to reconfigure" is included then the UE shall:

- 1> if the entry for the radio access bearer identified by the IE "CN domain identity" together with the IE "RAB Identity" in the variable ESTABLISHED_RABS already exists:
 - 2> perform the action for the IE "NAS Synchronization Indicator", according to subclause 8.6.4.12.
- 1> else:
 - 2> set the variable INVALID_CONFIGURATION to TRUE.

8.6.4.3 RB information to setup

If the IE "RB information to setup" is included, the UE shall apply the following actions on the radio bearer identified with the value of the IE "RB identity". The UE shall:

- 1> use the same START value to initialise the hyper frame number components of COUNT-C variables for all the new radio bearers to setup;
- 1> perform the actions for the IE "PDCP info", if present, according to subclause 8.6.4.10, applied for the radio bearer;
- 1> perform the actions for the IE "RLC info", according to subclause 8.6.4.9, applied for the radio bearer;
- 1> perform the actions for the IE "RB mapping info", according to subclause 8.6.4.8, applied for the radio bearer;
- 1> if the IE "Downlink RLC mode" either in the IE "RLC info" or referenced by the RB identity in the IE "Same as RB" is set to "TM RLC":
 - 2> configure delivery of erroneous SDUs in lower layers according to indication from upper layer [5].
- 1> if the IE "RB information to setup" was received in a message other than HANDOVER TO UTRAN COMMAND; and
- 1> if the IE "Uplink RLC mode" or the IE "Downlink RLC mode" either in the IE "RLC info" or referenced by the RB identity in the IE "Same as RB" is set to "AM RLC" or "UM RLC":
 - 2> initialise the 20 MSB of the hyper frame number component of COUNT-C for this radio bearer with the START value in the variable START_VALUE_TO_TRANSMIT;
 - 2> set the remaining LSB of the hyper frame number component of COUNT-C for this radio bearer to zero;
 - 2> start incrementing the COUNT-C values.
- 1> if the IE "RB information to setup" was received in a message other than HANDOVER TO UTRAN COMMAND; and
- 1> if the IE "Uplink RLC mode" and the IE "Downlink RLC mode" either in the IE "RLC info" or referenced by the RB identity in the IE "Same as RB" is set to "TM RLC":
 - 2> if prior to this procedure there exists no transparent mode radio bearer for the CN domain included in the IE "CN domain identity" in the IE "RAB info" in the variable ESTABLISHED_RABS and at least one transparent mode radio bearer is included in the IE "RB information to setup":
- 3> if the IE "Status" in the variable CIPHERING_STATUS of the CN domain as indicated in the IE "CN domain identity" in the IE "RAB info" in the variable ESTABLISHED_RABS is set to "Not Started":
 - 4> at the activation time as specified in the IE "Ciphering activation time for DPCH" if included in the IE "Ciphering mode info" in the command message or, if this IE is not included, as specified in the IE "COUNT-C activation time" included in the response message:
 - 5> initialise the 20 most significant bits of the hyper frame number component of COUNT-C common for all transparent mode radio bearers of this CN domain with the START value in the variable START_VALUE_TO_TRANSMIT;

- 5> set the remaining LSB of the hyper frame number component of COUNT-C to zero;
- 5> do not increment the COUNT-C value common for all transparent mode radio bearers for this CN domain.
- 3> if the IE "Status" in the variable CIPHERING_STATUS of the CN domain as indicated in the IE "CN domain identity" in the IE "RAB info" in the variable ESTABLISHED_RABS is set to "Started":
 - 4> at the activation time as specified in the IE "Activation Time" in the RADIO BEARER SETUP message:
 - 5> initialise the 20 most significant bits of the HFN component of COUNT-C common for all transparent mode RLC radio bearer to the value of the latest transmitted START for this CN domain, while not incrementing the value of the HFN component of COUNT-C at each CFN cycle; and
 - 5> set the remaining LSB of the HFN component of COUNT-C to zero;
 - 5> start to perform ciphering on the radio bearer in lower layers while not incrementing the HFN.
 - 4> at the activation time as specified in the IE "Ciphering activation time for DPCH" if included in the IE "Ciphering mode info" in the command message or, if this IE is not included, as specified in the IE "COUNT-C activation time" included in the response message:
 - 5> initialise the 20 most significant bits of the HFN component of COUNT-C common for all transparent mode radio bearers of this CN domain with the START value in the variable START_VALUE_TO_TRANSMIT;
 - 5> set the remaining LSB of the HFN component of COUNT-C to zero;
 - 5> if the received message is used to perform a Timing re-initialised hard handover:
 - 6> increment the HFN component of the COUNT-C variable by one even if the "COUNT-C activation time" is set to zero.
 - 5> start incrementing the COUNT-C value common for all transparent mode radio bearers of this CN domain as normal, at each CFN value, i.e. the HFN component is no longer fixed in value but incremented at each CFN cycle.
 - 2> if prior to this procedure there exists at least one transparent mode radio bearer for the CN domain included in the IE "CN domain identity" in the IE "RAB info" in the variable ESTABLISHED_RABS:
- 3> if the IE "Status" in the variable CIPHERING_STATUS of the CN domain as indicated in the IE "CN domain identity" in the IE "RAB info" in the variable ESTABLISHED_RABS is set to "Not Started":
 - 4> do not increment the COUNT-C value common for all transparent mode radio bearers for this CN domain.
- 3> if the IE "Status" in the variable CIPHERING_STATUS of the CN domain as indicated in the IE "CN domain identity" in the IE "RAB info" in the variable ESTABLISHED_RABS is set to "Started":
 - 4> use the COUNT-C value common for all transparent mode radio bearers of this CN domain.
 - 1> if the IE "Status" in the variable CIPHERING_STATUS of the CN domain as indicated in the IE "CN domain identity" in the IE "RAB info" in the variable ESTABLISHED_RABS is set to "Started":
 - 2> start to perform ciphering on the radio bearer in lower layers, using the value of the IE "RB identity" minus one as the value of BEARER in the ciphering algorithm.
 - NOTE: UTRAN should not use the IE "RB information to setup" to setup radio bearers with RB identity in the range 1-4.

8.6.4.4 RB information to be affected

If the IE "RB information to be affected" is included, the UE shall apply the following actions on the radio bearer identified with the value of the IE "RB identity". The UE shall:

1> perform the actions for the IE "RB mapping info", according to subclause 8.6.4.8, applied for the radio bearer.

8.6.4.5 RB information to reconfigure

If the IE "RB information to reconfigure" is included, the UE shall apply the following actions on the radio bearer identified with the value of the IE "RB identity". The UE shall:

- 1> perform the actions for the IE "PDCP info", if present, according to subclause 8.6.4.10, applied for the radio bearer:
- 1> if the IE "RLC info" is present:
 - 2> perform the actions for the IE "RLC info", according to subclause 8.6.4.9, applied for the radio bearer.
- 1> else:
 - 2> continue using the current RLC configuration for the radio bearer.
- 1> perform the actions for the IE "RB mapping info", according to subclause 8.6.4.8, applied for the radio bearer;
- 1> if the IE "Downlink RLC mode" in the IE "RLC info" is set to "TM RLC":
 - 2> configure delivery of erroneous SDUs in lower layers according to indication from upper layer [5].
- 1> if the IE "PDCP SN info" is included:
 - 2> perform the actions as specified in subclause 8.6.4.11 applied for the radio bearer.
- 1> if the IE "RB stop/continue" is included; and
 - 2> if the "RB identity" has a value greater than 2; and
- 3> if the value of the IE "RB stop/continue" is "stop":
 - 4> configure the RLC entity for the radio bearer to stop;
 - 4> set the IE "RB started" in the variable ESTABLISHED RABS to "stopped" for that radio bearer.
- 3> if the value of the IE "RB stop/continue" is "continue":
 - 4> configure the RLC entity for the radio bearer to continue;
 - 4> set the IE "RB started" in the variable ESTABLISHED_RABS to "started" for that radio bearer.
 - 2> if the IE "RB identity" is set to a value less than or equal to 2:
- 3> set the variable INVALID_CONFIGURATION to TRUE.

8.6.4.6 RB information to release

If the IE "RB information to release" is included, the UE shall apply the following actions on the radio bearer identified with the value of the IE "RB identity". The UE shall:

- 1> if the IE "RB identity" is set to a value less than 4:
 - 2> set the variable INVALID_CONFIGURATION to TRUE.
- 1> if the IE "RB identity" refers to a signalling radio bearer:
 - 2> release the RLC entity for the signalling radio bearer;
 - 2> delete the information about the signalling radio bearer from the variable ESTABLISHED_RABS.

- 1> if the IE "RB identity" refers to a radio bearer:
 - 2> release the PDCP and RLC entities for that radio bearer;
 - 2> indicate release of the RAB subflow associated with the radio bearer to upper layers;
 - 2> delete the information about the radio bearer from the variable ESTABLISHED RABS;
 - 2> when all radio bearers belonging to the same radio access bearer have been released:
- 3> indicate release of the radio access bearer to upper layers providing the "CN domain identity" together with the "RAB identity" stored in the variable ESTABLISHED_RABS;
- 3> delete all information about the radio access bearer from the variable ESTABLISHED RABS.

8.6.4.7 RB with PDCP information

If the IE "RB with PDCP information" is included, the UE shall apply the following actions on the radio bearer identified with the value of the IE "RB identity". The UE shall:

- 1> for the IE "PDCP SN info":
 - 2> perform the actions as specified in subclause 8.6.4.11.

8.6.4.8 RB mapping info

If the IE "RB mapping info" is included, the UE shall:

- 1> for each multiplexing option of the RB:
 - 2> if a multiplexing option that maps a logical channel corresponding to a TM-RLC entity onto RACH, CPCH, FACH or DSCH or HS-DSCH is included:
- 3> set the variable INVALID CONFIGURATION to TRUE.
 - 2> if the multiplexing option realises the radio bearer on the uplink (resp. on the downlink) using two logical channels with different values of the IE "Uplink transport channel type" (resp. of the IE "Downlink transport channel type"):
- 3> set the variable INVALID_CONFIGURATION to TRUE.
 - 2> if that RB is using TM and the IE "Segmentation indication" is set to TRUE and, based on the multiplexing configuration resulting from this message, the logical channel corresponding to it is mapped onto the same transport channel as another logical channel:
- 3> set the variable INVALID_CONFIGURATION to TRUE.
 - 2> if the transport channel considered in that multiplexing option is different from RACH and if that RB is using AM and the set of RLC sizes applicable to the uplink logical channel transferring data PDUs has more than one element not equal to zero:
- 3> set the variable INVALID_CONFIGURATION to TRUE.
 - 2> if that RB is using UM or TM and the multiplexing option realises it using two logical channels:
- 3> set the variable INVALID_CONFIGURATION to TRUE.
 - 2> for each logical channel in that multiplexing option:
- 3> if the value of the IE "RLC size list" is set to "Explicit list":
 - 4> if a "Transport format set" for the transport channel this logical channel is mapped on in this multiplexing option is included in the same message, and the value (index) of any IE "RLC size index" in the IE "Explicit list" does not correspond to an "RLC size" in the IE transport format set of that transport channel given in the message; or

- 4> if the transport channel this logical channel is mapped on in this multiplexing option is different from RACH, and if a "Transport format set" for that transport channel is not included in the same message, and the value (index) of any IE "RLC size index" in the IE "Explicit list" does not correspond to an "RLC size" in the stored transport format set of that transport channel; or
- 4> if a "Transport format set" for the transport channel this logical channel is mapped on in this multiplexing option is included in the same message, and the value of any IE "Logical channel list" in the transport format set is not set to "Configured"; or
- 4> if a "Transport format set" for the transport channel this logical channel is mapped on in this multiplexing option is not included in the same message, and the value of any IE "Logical channel list" in the stored transport format set of that transport channel is not set to "Configured":
 - 5> set the variable INVALID CONFIGURATION to TRUE.
- 3> if the value of the IE "RLC size list" is set to "All":
 - 4> if the transport channel this logical channel is mapped on is RACH; or
 - 4> if a "Transport format set" for the transport channel this logical channel is mapped on in this multiplexing option is included in the same message, and the value of any IE "Logical channel list" in the transport format set is not set to "Configured"; or
 - 4> if a "Transport format set" for the transport channel this logical channel is mapped on in this multiplexing option is not included in the same message, and the value of any IE "Logical channel list" in the stored transport format set of that transport channel is not set to "Configured":
 - 5> set the variable INVALID CONFIGURATION to TRUE.
- 3> if the value of the IE "RLC size list" is set to "Configured":
 - 4> if the transport channel this logical channel is mapped on is RACH; or
 - 4> if a "Transport format set" for the transport channel this logical channel is mapped on in this multiplexing option is included in the same message, and for none of the RLC sizes defined for that transport channel in the "Transport format set", the "Logical Channel List" is set to "All" or given as an "Explicit List" which contains this logical channel; or
 - 4> if a "Transport format set" for the transport channel this logical channel is mapped on in this multiplexing option is not included in the same message, and for none of the RLC sizes defined in the transport format set stored for that transport channel, the "Logical Channel List" is set to "All" or given as an "Explicit List" which contains this logical channel:
 - 5> set the variable INVALID_CONFIGURATION to TRUE.
 - 1> if, as a result of the message this IE is included in, several radio bearers can be mapped onto the same transport channel, and the IE "Logical Channel Identity" was not included in the RB mapping info of any of those radio bearers for a multiplexing option on that transport channel or the same "Logical Channel Identity" was used more than once in the RB mapping info of those radio bearers for the multiplexing options on that transport channel:
 - 2> set the variable INVALID_CONFIGURATION to TRUE.
 - 1> if the "RB mapping info" is considered as valid according to the rules above:
 - 2> delete all previously stored multiplexing options for that radio bearer;
 - 2> store each new multiplexing option for that radio bearer;
 - 2> perform the actions as specified in subclause 8.5.21.
 - 1> if the IE "Uplink transport channel type" is set to the value "RACH":
 - 2> in FDD:

3> refer the IE "RLC size index" to the RACH Transport Format Set of the first PRACH received in the IE "PRACH system information list" received in System Information Block 5 or System Information Block 6.

2> in TDD:

3> use the first Transport Format of the PRACH of the IE "PRACH system information list" at the position equal to the value in the IE "RLC size index".

In case IE "RLC info" includes IE "Downlink RLC mode" ("DL RLC logical channel info" is mandatory present) but IE "Number of downlink RLC logical channels" is absent in the corresponding IE "RB mapping info", the parameter values are exactly the same as for the corresponding UL logical channels. In case two multiplexing options are specified for the UL, the first options shall be used as default for the DL. As regards the IE "Channel type", the following rule should be applied to derive the DL channel type from the UL channel included in the IE:

Channel used in UL	DL channel type implied by "same as"
DCH	DCH
RACH	FACH
CPCH	FACH
USCH	DSCH

If ciphering is applied, UTRAN should not map Transparent Mode RBs of different CN domains on the same transport channel and it should not map transparent mode SRBs and RBs onto the same transport channel. In such cases the UE behaviour is not specified.

8.6.4.9 RLC Info

Upon reception of the IE "RLC Info", the UE shall:

- 1> configure the transmitting and receiving RLC entities in the UE for that radio bearer accordingly;
- 1> if the IE "Polling info" is present in the IE "RLC info":
 - 2> for each present IE in the IE "Polling info":
- 3> configure RLC to use the corresponding function according to the value of the IE.
 - 2> for each absent IE in the IE "Polling info":
- 3> configure RLC to not use the corresponding function.
 - 1> if the IE "Polling info" is absent:
 - 2> configure RLC to not use the polling functionality.
 - 1> if the IE "Downlink RLC STATUS info" is present in the IE "RLC info" (this IE is present for AM RLC):
 - 2> for each present IE in the IE "Downlink RLC STATUS info":
- 3> configure RLC to use the corresponding function according to value of the IE.
 - 2> for each absent IE in the IE "Downlink RLC STATUS info":
- 3> configure RLC to not use the corresponding function.
 - 1> if the IE "Transmission RLC discard" is present:
 - 2> configure the discard procedure in RLC according to the IE "Transmission RLC discard"
 - 1> if the IE "Transmission RLC discard" is absent (only possible for TM RLC and UM RLC):
 - 2> do not configure SDU discard in RLC.
 - 1> if the IE "Downlink RLC mode" is present and is set to "AM RLC":
 - 2> if IE "DL RLC PDU size" is not present:

- 3> determining the downlink RLC PDU size will be handled at RLC level as described in [16], without any configuration from RRC.
 - NOTE: The case where this mandatory IE is not present is meant to handle the interaction with a network using an earlier release of the specification.
 - 2> else, if the IE "DL RLC PDU size" is present and no downlink RLC PDU size is currently set in the RLC entity:
- 3> configure the corresponding RLC entity with the downlink RLC PDU size.
 - 2> else, if the IE "DL RLC PDU size" is present and its value is different from the one currently set in the RLC entity:
 - NOTE: The downlink RLC PDU size set in the RLC entity can either be explicitly configured or, in case no explicit configuration is provided, derived by the first received RLC PDU [16].
- 3> if the IE "one sided RLC re-establishment" is set to TRUE:
 - 4> re-establish the receiving side of the corresponding RLC entity.
- 3> else:
- 4> re-establish the corresponding RLC entity.
- 3> configure the corresponding RLC entity with the new downlink RLC PDU size;
- 3> if the IE "Status" in the variable CIPHERING_STATUS of the CN domain as indicated in the IE "CN domain identity" in the IE "RAB info" for this radio bearer is set to "Started":
 - 4> if the RLC re-establishment is caused by a CELL UPDATE CONFIRM:
 - 5> if only the receiving side of the RLC entity was re-established:
 - 6> set the HFN values for the corresponding RLC entity in downlink equal to the value of the IE "START" included in the latest transmitted CELL UPDATE message for this CN domain.
 - 5> if the whole RLC entity was re-established:
 - 6> set the HFN values for the corresponding RLC entity in uplink and downlink equal to the value of the IE "START" included in the latest transmitted CELL UPDATE message for this CN domain.
 - 4> if the RLC re-establishment is caused by a reconfiguration message:
 - 5> if only the receiving side of the RLC entity was re-established:
 - 6> set the HFN values for the corresponding RLC entity in downlink equal to the value of the IE "START" that will be included in the reconfiguration complete message for this CN domain.
 - 5> if the whole RLC entity was re-established:
 - 6> set the HFN values for the corresponding RLC entity in uplink and downlink equal to the value of the IE "START" that will be included in the reconfiguration complete message for this CN domain.
 - $1\!\!>$ if the IE "Downlink RLC mode" is present and is set to "UM RLC":
 - 2> if the IE "DL UM RLC LI size" is not present:
- 3> configure the corresponding RLC entity with an LI size of 7 bits;
 - NOTE: The case where this mandatory IE is not present is meant to handle the interaction with a network using an earlier release of the specification.

2> else:

3> configure the corresponding RLC entity with the LI size indicated in the IE "DL UM RLC LI size".

8.6.4.10 PDCP Info

For RFC 3095:

- 1> the chosen MAX_CID shall not be greater than the value "Maximum number of ROHC context sessions" as indicated in the IE "PDCP Capability";
- 1> the configuration for the PACKET_SIZES_ALLOWED is FFS.

If IE "PDCP info" is included, the UE shall:

- 1> if the radio bearer is connected to a CS domain radio access bearer:
 - 2> set the variable INVALID_CONFIGURATION to TRUE.
- 1> if the IE "PDCP PDU header" is set to the value "absent":
 - 2> if the IE "Support for lossless SRNS relocation" is true:
- 3> set the variable INVALID_CONFIGURATION to TRUE.
 - 1> if the IE "PDCP PDU header" is set to the value "present":
 - 2> if the IE "Support for lossless SRNS relocation" is false:
- 3> if the IE "Header compression information" is absent:
 - 4> set the variable INVALID CONFIGURATION to TRUE.
 - 1> if the IE "Header compression information" is absent:
 - 2> not use Header compression after the successful completion of this procedure;
 - 2> remove any stored configuration for the IE "Header compression information".
 - 1> if the IE "Header compression information" is present:
 - 2> if the IE "Algorithm Type" is set to "RFC 2507":
- 3> if the UE capability "Maximum header compression context space", as specified in [35], is exceeded with this configuration:
 - 4> set the variable INVALID_CONFIGURATION to TRUE.
 - 1> configure the PDCP entity for that radio bearer accordingly;
 - 1> configure the RLC entity for that radio bearer according to the value of the IE "Support for lossless SRNS relocation";
 - 1> set the PROFILES parameter, used by inband ROHC profile negotiation, for this PDCP entity for both UL and DL equal to the list of ROHC profiles received in the IE "PDCP info". A UE complying to this version of the protocol shall support ROHC profiles 0x0000 (ROHC uncompressed), 0x0001 (ROHC RTP), 0x0002 (ROHC UDP) and 0x0003 (ROHC ESP) (see [52]).

8.6.4.11 PDCP SN Info

If the IE "PDCP SN Info" is included, the UE shall:

- 1> transfer the sequence number to the PDCP entity for the radio bearer;
- 1> configure the RLC entity for the radio bearer to stop;

1> include the current PDCP receive sequence number and the radio bearer identity for the radio bearer in the variable PDCP_SN_INFO.

8.6.4.12 NAS Synchronisation Indicator

If the IE "NAS Synchronisation Indicator" is present in a message, the UE shall:

1> forward the content to upper layers along with the IE "CN domain identity" of the associated RAB stored in the variable ESTABLISHED_RABS at the CFN indicated in the IE "Activation time" in order to synchronise actions in NAS and AS.

8.6.4.13 PDCP context relocation info

If the IE "PDCP context relocation info" is included, the UE shall, for each radio bearer included in this IE:

- 1> If the IE "Downlink RFC 3095 context relocation indication" is set to TRUE:
 - 2> perform the actions as specified in [36] for all RFC 3095 contexts associated with that radio bearer in the downlink.
- 1> If the IE "Uplink RFC 3095 context relocation indication" is set to TRUE:
 - 2> perform the actions as specified in [36] for all RFC 3095 contexts associated with that radio bearer in the uplink.

8.6.5 Transport channel information elements

8.6.5.1 Transport Format Set

If the IE "Transport format set" is included, the UE shall:

- 1> if the transport format set is a RACH TFS received in System Information Block type 5 or 6, and CHOICE "Logical Channel List" has a value different from "Configured":
 - 2> ignore that System Information Block.
- 1> if the transport format set for a downlink transport channel is received in a System Information Block, and CHOICE "Logical Channel List" has a value different from 'ALL':
 - 2> ignore that System Information Block.
- 1> if the transport format set for a downlink transport channel is received in a message on a DCCH, and CHOICE "Logical Channel List" has a value different from 'ALL':
 - 2> keep the transport format set if this exists for that transport channel;
 - 2> set the variable INVALID_CONFIGURATION to TRUE.
- 1> if the value of any IE "RB identity" (and "Logical Channel" for RBs using two UL logical channels) in the IE "Logical channel list" does not correspond to a logical channel indicated to be mapped onto this transport channel in any RB multiplexing option (either included in the same message or previously stored and not changed by this message); or
- 1> if the "Logical Channel List" for any of the RLC sizes defined for that transport channel is set to "Configured" while it is set to "All" or given as an "Explicit List" for any other RLC size; or
- 1> if the "Logical Channel List" for any of the RLC sizes defined for that transport channel is set to "All" and for any logical channel mapped to this transport channel, the value of the "RLC size list" (either provided in the IE "RB mapping info" if included in the same message, or stored) is not set to "Configured"; or
- 1> if the "Logical Channel List" for any of the RLC sizes defined for that transport channel is given as an "Explicit List" that contains a logical channel for which the value of the "RLC size list" (either provided in the IE "RB mapping info" if included in the same message, or stored) is not set to "Configured"; or

- 1> if the "Logical Channel List" for all the RLC sizes defined for that transport channel are given as "Explicit List" and if one of the logical channels mapped onto this transport channel is not included in any of those lists; or
- 1> if the "Logical Channel List" for the RLC sizes defined for that transport channel is set to "Configured" and for any logical channel mapped onto that transport channel, the value of the "RLC size list" (either provided in the IE "RB mapping info" if included in the same message, or stored) is also set to "Configured"; or
- 1> if the IE "Transport Format Set" was not received within the IE "PRACH system information list" and if the "Logical Channel List" for the RLC sizes defined for that transport channel is set to "Configured" and for any logical channel mapped onto that transport channel, the "RLC size list" (either provided in the IE "RB mapping info" if included in the same message, or stored) is given as an "Explicit List" that includes an "RLC size index" that does not correspond to any RLC size in this "Transport Format Set"; or
- 1> if the IE "Transport Format Set" was not received within the IE "PRACH system information list", and if that RB is using AM and the set of RLC sizes applicable to the logical channel transferring data PDUs has more than one element not equal to zero:
 - 2> keep the transport format set if this exists for that transport channel;
 - 2> set the variable INVALID_CONFIGURATION to TRUE.
- 1> if the total number of configured transport formats for the transport channel exceeds maxTF:
 - 2> keep the transport format set if this exists for that transport channel;
 - 2> set the variable INVALID_CONFIGURATION to TRUE.
- 1> if the IE "Transport format set" is considered as valid according to the rules above:
 - 2> remove a previously stored transport format set if this exists for that transport channel;
 - 2> store the transport format set for that transport channel;
 - 2> consider the first instance of the parameter *Number of TBs and TTI List* within the *Dynamic transport format information* to correspond to transport format 0 for this transport channel, the second to transport format 1 and so on;
 - 2> if the IE "Transport format Set" has the choice "Transport channel type" set to "Dedicated transport channel":
- 3> calculate the transport block size for all transport formats in the TFS using the following

TB size = RLC size + MAC header size if "RLC size"
$$<> 0$$
,
TB size = 0 if "RLC size" = 0,

where:

- MAC header size is calculated according to [15] if MAC multiplexing is used. Otherwise it is 0 bits;
- 'RLC size' reflects the RLC PDU size.
- 2> if the IE "Transport format Set" has the choice "Transport channel type" set to "Common transport channel":

3> in FDD:

4> for transport channels other than DSCH calculate the transport block size for all transport formats in the TFS using the following:

TB size =
$$RLC$$
 size.

4> for DSCH transport channels calculate the transport block size for all transport formats in the TFS using the following:

```
TB size = RLC size + MAC header size if "RLC size" \Leftrightarrow 0,
TB size = 0 if "RLC size" = 0,
```

where:

- MAC header size is calculated according to [15];
- 'RLC size' reflects the RLC PDU size.
- 3> for TDD calculate the transport block size for all transport formats in the TFS using the following:

TB size = RLC size.

- 2> if the IE "Number of Transport blocks" <> 0 and IE "RLC size" = 0, no RLC PDU data exists but only parity bits exist for that transport format;
- 2> if the IE "Number of Transport blocks" = 0, neither RLC PDU neither data nor parity bits exist for that transport format;
- 2> perform the actions as specified in subclause 8.5.21.

For configuration restrictions on Blind Transport Format Detection, see [27].

8.6.5.2 Transport format combination set

If the IE "Transport format combination set" is included for the uplink, the UE shall for that direction:

- 1> store the new transport format combination set, or (if this exists) modify a previously stored transport format combination set according to IEs included in IE "Transport format combination set";
- 1> start to respect those transport format combinations;
- 1> if IE "Transport format combination subset" is received in this message:
 - 2> perform the actions as specified in subclause 8.6.5.3.
- 1> if IE "Transport format combination subset" is not received in this message:
 - 2> clear the IE "Duration" in the variable TFC_SUBSET;
 - 2> set both the IE "Current TFC subset" and the IE "Default TFC subset" in the variable TFC_SUBSET to the value indicating "full transport format combination set".

If the IE "Transport format combination set" is included for the downlink, the UE shall for that direction:

- 1> store the new transport format combination set, or (if this exists) modify a previously stored transport format combination set according to IEs included in IE "Transport format combination set";
- 1> start to respect those transport format combinations;
- 1> if IE "Transport format combination subset" is received in this message:
 - 2> perform the actions as specified in subclause 8.6.5.3.

If the IE "Transport format combination set" is not included for the uplink and if there is no addition, removal or reconfiguration of transport channels, the UE shall for that direction:

1> use a previously stored transport format combination set if this exists.

If the IE "Transport format combination set" is not included for the downlink and if there is no addition, removal or reconfiguration of transport channels, the UE shall for that direction:

1> use a previously stored transport format combination set if this exists.

If the IE "Transport format combination set" is not included; and

- 1> if no transport format combination set is stored in the UE; or
- 1> if transport channels are added or removed in the message; or
- 1> if any transport channel is reconfigured in the message such that the size of the transport format set is changed:

the UE shall:

1> set the variable INVALID_CONFIGURATION to TRUE.

In the uplink TFCS the minimum set of TFCs is the set of TFCs that is needed for the TFC selection algorithm defined in [15] to give a predictable result. This set should always be included in the TFCS, and its use should never be restricted using the IE "TFC Subset". In the definition of the minimum set of TFCs below, only logical channels for which the TFCS or the TFC subset include at least one TFC with non-empty TF for the corresponding transport channel should be considered.

The minimum set of TFCs consists of the following:

- 1> for each UM logical channel:
 - 2> a TFC with one transport block for this transport channel and empty TFs (see [34]) for all the others. If more than one TFC fulfils these criteria, only the TFC with the lowest number of bits should be included in the minimum set of TFCs.
- 1> for each AM logical channel:
 - 2> a TFC with a non-empty TF for the corresponding transport channel and empty TFs for all other transport channels, where the non-empty TF includes one transport block with "Configured RLC Size" equal to the RLC PDU size.
- 1> for each set of "synchronous" TM logical channels (see the definition below) and for each set of SDU sizes associated with it:
 - 2> a TFC with TFs corresponding to any combination of SDU sizes that can be received in a TTI from higher layers on the corresponding transport channels and empty TFs for all other transport channels.
- 1> for each TM logical channel that is not part of a set of "synchronous" TM logical channels (see the definition below):
 - 2> a TFC with non-empty TFs for the corresponding transport channel, and empty TFs for all other transport channels, where
- 3> for non-segmented mode TM-RLC logical channels the non-empty TFs include, for the smallest SDU size that can be received in a single TTI from higher layer:
 - 4> a TF with non-zero number of transport blocks with "Configured RLC Size" equal to the corresponding SDU size. If more than one TFC fulfils these criteria, only the TFC with the lowest number of bits in the TFC is included in the minimum set of TFCs.
- 3> for segmented mode TM-RLC, the non-empty TFs include any TF such that the number of transport blocks multiplied by the "Configured RLC Size" is equal to the smallest SDU size that can be received in a single TTI from higher layer.
 - 1> an "empty" TFC (see [34]).

Furthermore, the UTRAN should ensure that the uplink TFCS and any configured TFC Subset satisfies the following rules:

- 1> for each TTI length with which at least one transport channel is configured:
 - 2> for each combination of TFs for the transport channels configured with this TTI length included in the TFCS:
- 3> a TFC with these TFs for the transport channels configured with this TTI length and empty TFs on all transport channels configured with shorter TTI lengths is also included in the TFCS.

For TDD, the TFCS of a CCTrCH should include those of the above combinations, which include a TF with one transport block for a transport channel used in that CCTrCH, and the "empty" TFC should be included in the TFCS of every CCTrCH.

Synchronous TM logical channels are logical channels on which higher layer traffic is generated in a perfectly correlated fashion (e.g. AMR RAB).

NOTE: The "Configured RLC Size" is defined as the transport block size minus the MAC header size.

8.6.5.3 Transport format combination subset

When configuring a TFC Subset, the UTRAN should follow the guidelines defined in subclause 8.6.5.2.

- If the IE "Transport format combination subset" ("TFC subset") is included, the UE shall:
 - 1> if the IE "Minimum allowed Transport format combination index" is included; and
 - 2> if the value of the IE "Minimum allowed Transport format combination index" is greater than the highest TFCI value in the current transport format combination set:
- 3> consider the TFC subset to be incompatible with the current transport format combination set.
 - 1> if the IE "Allowed transport format combination list" is included; and
 - 2> if the value of any of the IEs "Allowed transport format combination" included in the IE "Allowed transport format combination list" does not match a TFCI value in the current transport format combination set:
- 3> consider the TFC subset to be incompatible with the current transport format combination set.
 - 1> if the IE "Non-allowed transport format combination list" is included; and
 - 2> if the value of any of the IEs "Non-allowed transport format combination" included in the IE "Non-allowed transport format combination list" does not match a TFCI value in the current transport format combination set:
- 3> consider the TFC subset to be incompatible with the current transport format combination set.
 - 1> if the IE "Restricted TrCH information" is included:
 - 2> if the value of any of the IEs "Uplink transport channel type" and "Restricted UL TrCH identity" included in the IE "Restricted TrCH information" do not correspond to any of the transport channels for which the current transport format combination set is valid:
- 3> consider the TFC subset to be incompatible with the current transport format combination set.
 - 2> if the IE "Allowed TFIs" is included; and
- 3> if the value of each of the IEs "Allowed TFI" included in the IE "Allowed TFIs" corresponds to a transport format for that transport channel within the current transport format combination set:
 - 4> allow all transport format combinations that include these transport formats for the transport channel;
 - 4> restrict all other transport format combinations.
- 3> else:
- 4> consider the TFC subset to be incompatible with the current transport format combination set.
- 2> if the IE "Allowed TFIs" is not included:
- 3> restrict all transport format combinations where the transport channel has a transport format of non-zero rate.
 - 1> if the UE considers the TFC subset to be incompatible with the current Transport format combination set according to the above:
 - 2> keep any previous restriction of the transport format combination set;
 - 2> set the variable INVALID_CONFIGURATION to TRUE.
 - 1> if the UE does not consider the TFC subset to be incompatible with the current Transport format combination set according to the above:
 - 2> restrict the transport format combination set in the uplink to the value of the IE "Transport format combination subset" (in case of TDD for the uplink CCTrCH specified by the IE "TFCS Id");

- 2> clear the IE "Duration" in the variable TFC_SUBSET.
- 1> if the transport format combination subset indicates the "full transport format combination set":
 - 2> any restriction on transport format combination set is released and the UE may use the full transport format combination set.

8.6.5.4 DCH quality target

If the IE "DCH quality target" is included, the UE shall:

- 1> set, at physical channel establishment, an initial downlink target SIR value based on the received IE "DCH quality target";
- 1> adjust the target SIR for the downlink power control to meet the quality target received in the IE "DCH quality target".
- NOTE 1: Adjusting the target SIR is possible to do continuously by the UE if a CRC exists in all transport formats in the downlink TFS for a DCH. If a CRC does not exist in all transport formats, the UE can only adjust the target SIR when receiving transport formats containing a CRC and the UE has knowledge about the transport format according to [27].
- NOTE 2: If the UTRAN configures a UE to use blind transport format detection and configures a transport channel such that single transport format detection [27] must be used to detect the TF, then it is not possible for the UE to maintain a quality target for that transport channel.

8.6.5.5 Added or Reconfigured UL TrCH information

If the IE "Added or Reconfigured UL TrCH information" is included then the UE shall:

- 1> for the transport channel identified by the IE "UL Transport Channel Identity" and IE "Uplink transport channel type":
 - 2> perform the actions for the IE "Transport Format Set" as specified in subclause 8.6.5.1.
- NOTE: The UE stores the UL transport channel configuration until it is explicitly deleted by a message containing the IE "Deleted UL TrCH information" or the UE leaves RRC Connected mode.

8.6.5.5a Added or reconfigured MAC-d flow

If the IE "Added or reconfigured MAC-d flow" is included, the UE shall:

- 1> if a MAC-hs queue (identified by the IE "MAC-hs queue Id") is included in both the IE "MAC-hs queue to add or reconfigure list" and the IE "MAC-hs queue to delete list":
 - 2> set the variable INVALID CONFIGURATION to TRUE.
- 1> for each MAC-hs queue included in the IE "MAC-hs queue to add or reconfigure" list:
 - 2> if the UE has previously stored a mapping between this MAC-hs queue and a MAC-d flow:
- 3> delete the old mapping.
 - 2> map the MAC-d flow indicated in the current message to this MAC-hs queue;
 - 2> set the release timer for each of the MAC-hs queues in the MAC-hs entity to the value in the corresponding IE "T1":
 - 2> set the MAC-hs receiver window size for each of the MAC-hs queues in the MAC-hs entity to the value in the corresponding IE "MAC-hs window size"; and
 - 2> configure MAC-hs with the mapping between MAC-d PDU sizes index and allowed MAC-d PDU sizes as follows:

3> if a MAC-d PDU size has been stored for a MAC-d PDU size index for the corresponding MAC-hs queue and no mapping is provided in the current message for this MAC-d PDU index:

4> continue to use this mapping.

3> if a MAC-d PDU size has been stored for a MAC-d PDU size index for the corresponding MAC-hs queue and a mapping is provided in the current message for this MAC-d PDU index:

- 4> configure the MAC-hs entity with the mapping indicated in the current message.
- 1> for each MAC-hs queue included in the IE "MAC-hs queue to delete" list:
 - 2> delete any information about the MAC-hs queue identified by the IE "MAC-hs queue Id".

8.6.5.6 Added or Reconfigured DL TrCH information

If the IE "Added or Reconfigured DL TrCH information" is included then for the transport channel identified by the IE "DL Transport Channel Identity" the UE shall:

- 1> if the choice "DL parameters" is set to 'explicit':
 - 2> perform the actions for the IE "Transport Format Set" as specified in subclause 8.6.5.1.
- 1> if the choice "DL parameters" is set to 'same as uplink':
 - 2> if the IE "UL Transport Channel Identity" indicates an existing or a new UL Transport Channel:

3> store as transport format for this transport channel the transport format associated with the transport channel identified by the IE "UL Transport Channel Identity".

2> else:

- 3> set the variable INVALID_CONFIGURATION to TRUE.
 - 1> if the choice "DL parameters" is set to 'HSDSCH':
- 2> if the IE "HARQ Info" is included:
- 3> perform the actions specified in subclause 8.6.5.6b.
 - 1> if the IE "DCH quality target" is included:
 - 2> perform the actions specified in subclause 8.6.5.4.

NOTE: The UE stores the DL transport channel configuration until it is explicitly deleted by a message containing the IE "Deleted DL TrCH information" or the UE leaves RRC connected mode.

8.6.5.6a Void

8.6.5.6b HARQ Info

If the IE "HARQ Info" is included, the UE shall:

- 1> configure the MAC-hs entity with the number of HARQ processes indicated in IE "Number of Processes";
- 1> assign to each of these HARQ processes IDs going from 0 to "Number of Processes" 1;
- 1> if the IE "Memory Partitioning" is set to 'Implicit':
 - 2> partition the soft memory buffer in the MAC-hs entity equally among the processes configured above. In the event that the division of the soft memory buffer results in a non-Integer value the partition memory size is rounded down to the nearerst Integer value.
- 1> if the IE "Memory Partitioning" is set to 'Explicit':

- 2> if the UE capability "Total number of soft channel bits in HS-DSCH", as specified in [35], is exceeded with this configuration:
- 3> set the variable INVALID_CONFIGURATION to TRUE.
 - 2> else

3> partition the soft memory buffer in the MAC-hs entity according to the IE "Process memory size" assuming that the order in the list follows the order in the HARQ process IDs.

8.6.5.7 Deleted UL TrCH information

If the IE "Deleted UL TrCH information" is included the UE shall:

1> delete any information about the transport channel identified by the IE "UL TrCH identity" and IE "Uplink transport channel type".

8.6.5.8 Deleted DL TrCH information

If the IE "Deleted DL TrCH information" is included the UE shall:

- 1> if a Downlink transport channel is requested to be deleted:
 - 2> delete any information about the transport channel identified by the IE "DL TrCH identity".
- 1> if a DL MAC-d flow is requested to be deleted:
 - 2> delete any information about the DL HS-DSCH MAC-d flow identified by the IE "MAC-d Flow Identity", i.e. delete any information about MAC-hs queue(s) mapped onto this MAC-d flow.

8.6.5.9 UL Transport channel information common for all transport channels

If the IE "UL Transport channel information common for all transport channels" is included the UE shall:

- 1> perform actions for the IE "TFC subset" as specified in subclause 8.6.5.3;
- 1> if the IE "PRACH TFCS" is included:
 - 2> set the variable INVALID_CONFIGURATION to TRUE.
- 1> if the IE has the choice "mode" set to FDD:
 - 2> perform actions for the IE "UL DCH TFCS" as specified in subclause 8.6.5.2.
- 1> if the IE has the choice "mode" set to TDD:
 - 2> if the IE "Individual UL CCTrCH information" is included:
- 3> for each TFCS identified by IE "UL TFCS id":
 - 4> perform actions for the IE "UL TFCS" as specified in subclause 8.6.5.2.
 - 1> if the IE "TFC subset list" is included:
 - 2> remove a previously stored TFC subset list if this exists in the variable TFC_SUBSET;
 - 2> store the IE "TFC subset list" in the IE "TFC subset list" in the variable TFC_SUBSET;
 - 2> consider the first instance of the IE "TFC subset" in the IE "TFC subset list" as Transport Format Combination Subset 0 (TFC subset identity = 0), the second instance as Transport Format Combination Subset 1 (TFC subset identity = 1) and so on.

8.6.5.10 DL Transport channel information common for all transport channels

If the IE "DL Transport channel information common for all transport channels" is included the UE shall:

- 1> if the IE "SCCPCH TFCS" is included:
 - 2> set the variable INVALID_CONFIGURATION to TRUE.
- 1> if the IE choice "mode" is set to FDD:
 - 2> if the choice "DL parameters" is set to 'explicit':
- 3> if the IE "DL DCH TFCS" is included:
 - 4> if the IE "SCCPCH TFCS" is included and the state the UE enters after handling the received information is other than CELL_DCH:
 - 5> ignore the received IE "DL DCH TFCS".
 - NOTE: the IE "DL Transport channel information common for all transport channels" always includes a DL DCH TFCS configuration, either by including the IE "DL DCH TFCS" or by specifying that the TFCS is the same as in UL. If UTRAN does not require the reconfiguration of the concerned parameters, UTRAN may replace one TFC with the value that is already assigned for this IE.
 - 4> else:
 - 5> perform actions as specified in subclause 8.6.5.2.
 - 1> if the IE choice "mode" is set to TDD:
 - 2> if the IE "Individual DL CCTRCH information" is included:
- 3> for each DL TFCS identified by the IE "DL TFCS identity":
 - 4> if the IE choice "DL parameters" is set to 'independent':
 - 5> perform actions for the IE "DL TFCS" as specified in subclause 8.6.5.2.
 - 4> if the IE choice "DL parameters" is set to 'same as UL':
 - 5> if the IE "UL DCH TFCS identity" indicates an existing or a new UL TFCS:
 - 6> store for that DL TFCS the TFCS identified by the IE "UL DCH TFCS identity".
 - 5> else:
 - 6> set the variable INVALID_CONFIGURATION to TRUE.

8.6.5.11 DRAC static information

If the IE "DRAC static information" is included the UE shall:

- 1> store the content of the IE "Transmission Time Validity";
- 1> store the content of the IE "Time duration before retry";
- 1> store the content of the IE "DRAC Class identity".

8.6.5.12 TFCS Reconfiguration/Addition Information

If the IE "TFCS Reconfiguration/Addition Information" is included the UE shall:

- 1> store the TFCs to be reconfigured/added indicated in the IE "CTFC information" as specified below;
- 1> if the IE "Power offset information" is included:
 - 2> perform actions as specified in [29].

In order to identify the TFCs included in this IE the UE shall calculate the CTFC as specified in subclause 14.10 and

1> if the IE "TFCS Reconfiguration/Addition Information" was included in the IE "TFCI Field 1 Information":

- 2> ignore for the CTFC calculation any DSCH transport channel that may be assigned.
- 1> if the IE "TFCS Reconfiguration/Addition Information" was included in the IE "TFCI Field 2 Information":
 - 2> ignore for the CTFC calculation any DCH transport channel that may be assigned.

If the IE "TFCS Reconfiguration/Addition Information" is used in case of TFCS "Complete reconfiguration" the UE shall:

- 1> remove a previously stored transport format combination set if this exists;
- 1> consider the first instance of the IE "CTFC information" as Transport Format Combination 0 in FDD (TFCI=0) and 1 in TDD (TFCI=1), the second instance as Transport Format Combination 1 in FDD (TFCI=1) and 2 in TDD (TFCI=2) and so on. In TDD the TFCI value = 0 is reserved for physical layer use.

If the IE "TFCS Reconfiguration/Addition Information" is used in case of TFCS "Addition" the UE shall insert the new additional(s) TFC into the first available position(s) in ascending TFCI order in the TFCS.

8.6.5.13 TFCS Removal Information

If the IE "TFCS Removal Information" is included the UE shall:

1> remove the TFC indicated by the IE "TFCI" from the current TFCS, and regard this position (TFCI) in the TFCS as vacant.

8.6.5.14 TFCI Field 2 Information

If the IE "TFCI Field 2 Information" is included the UE shall:

- 1> if the IE choice "Signalling method" is set to 'TFCI range':
 - 2> for the first group in the IE "TFCI(field 2) range":

3> apply the Transport Format Combination indicated by the value of the IE "TFCS Information for DSCH (TFCI range method)" to the group of values of TFCI(field 2) between 0 and the IE "Max TFCI(field2) value".

2> for the following groups in the IE "TFCI(field 2) range":

3> apply the Transport Format Combination indicated by the value of the IE "TFCS Information for DSCH (TFCI range method)" to the group of values of TFCI(field 2) between the largest value reached in the previous group plus one and the IE "Max TFCI(field2) value".

- 1> if the IE choice "Signalling method" is set to 'Explicit':
 - 2> perform actions for the IE "TFCS explicit configuration" as specified in subclause 8.6.5.15.

8.6.5.15 TFCS Explicit Configuration

If the IE "TFCS Explicit Configuration" is included the UE shall:

- 1> if the IE choice "TFCS representation" is set to 'complete reconfiguration':
 - 2> perform the actions for the IE "TFCS Reconfiguration/Addition Information" as specified in subclause 8.6.5.12.
- 1> if the IE choice "TFCS representation" is set to 'addition':
 - 2> perform the actions for the IE "TFCS Reconfiguration/Addition Information" as specified in subclause 8.6.5.12.
- 1> if the IE choice "TFCS representation" is set to 'removal':
 - 2> perform the actions for the IE "TFCS Removal Information" as specified in subclause 8.6.5.13.
- 1> if the IE choice "TFCS representation" is set to 'replace':

- 2> perform first the actions for the IE "TFCS Removal Information" as specified in subclause 8.6.5.13; and then
- 2> perform the actions for the IE "TFCS Reconfiguration/Addition Information" as specified in subclause 8.6.5.12.

8.6.6 Physical channel information elements

This subclause specifies the actions upon reception and/or non-reception of the physical channel information elements. The combination of the values of those information elements included in a given message shall follow the compatibility rules that are specified in the physical layer specifications. In case those rules are not followed, the UE shall set the variable INVALID CONFIGURATION to TRUE.

8.6.6.1 Frequency info

If, after completion of the procedure, the UE will be in CELL_DCH state, the UE shall:

- 1> if the IE "Frequency info" is included:
 - 2> if the frequency is different from the currently used frequency:
- 3> store and use the frequency indicated by the IE "Frequency Info"; and
- 3> perform the physical layer synchronisation procedure A as specified in [29] (FDD only).
 - 2> if the frequency is the same as the currently used frequency:
- 3> continue to use the currently used frequency;
- 3> perform the physical layer synchronisation procedure A as specified in [29] (FDD only).
 - 1> if the IE "Frequency info" is not included and the UE has a currently used frequency:
 - 2> continue to use the currently used frequency.

8.6.6.2 Void

8.6.6.2a PNBSCH allocation

The UE shall consider the frame numbers fulfilling the following equation as "PRACH blocked frames" as specified in [33].

$$SFN = \lfloor k * Repetition period \rfloor$$

for an integer k with k {0, 1, 2, 3, 4, ..., value of IE "Number of repetitions per SFN period" - 1}, where:

Repetition period is: 4096 / value of IE "Number of repetitions per SFN period".

The UE shall configure the physical layer for the physical random access procedure accordingly.

8.6.6.3 Void

8.6.6.3a Downlink information per radio link list

If the IE "Downlink information per radio link list" is included in a received message, the UE shall:

1> if the message was received in CELL_DCH state and the UE remains in CELL_DCH state according to subclause 8.6.3.3 applied on the received message:

- 2> if all radio links included in the IE "Downlink information per radio link list" are part of the current active set:
- 3> for radio links part of the current active set, and present in the IE "Downlink information per radio link list":
 - 4> update the downlink physical channel configuration according to the IE "Downlink information for each radio link" as specified in subclause 8.6.6.4.
- 3> for radio links part of the current active set, and absent in the IE "Downlink information per radio link list":
 - 4> not change its current downlink physical channel configuration.
 - 2> if all radio links included in the IE "Downlink information per radio link list" are not part of the current active set:
- 3> replace all the radio links in the current active set with the radio links in the IE "Downlink information per radio link list", each with a downlink physical channel configuration according to the IE "Downlink information for each radio link" as specified in subclause 8.6.6.4.
 - NOTE: UTRAN should not mix radio links which are part of the current active set and radio links which are not part of the current active set in the same IE "Downlink information per radio link list". In such cases the UE behaviour is unspecified.
 - 1> otherwise:
 - 2> if the message was received in CELL_FACH state and the UE would transit to CELL_DCH state according to subclause 8.6.3.3 applied on the received message:
- 3> establish a downlink physical channel configuration for each of the included radio links according to the IE "Downlink information for each radio link" as specified in subclause 8.6.6.4.

8.6.6.4 Downlink information for each radio link

If the IE "Downlink information for each radio link" is included in a received message, the UE shall:

- 1> if the UE would enter CELL DCH state according to subclause 8.6.3.3 applied on the received message:
 - 2> if the IE "SCCPCH Information for FACH" is included; and
 - 2> if the UE is in FDD mode and is not capable of simultaneous reception of DPCH and Secondary CCPCH:
- 3> set the variable UNSUPPORTED_CONFIGURATION to TRUE;
 - 2> if the UE is in FDD mode and is capable of simultaneous reception of DPCH and SCCPCH:
- 3> start to receive the indicated Secondary CCPCH.
 - 2> if the UE is in TDD mode and shared transport channels are assigned to the UE:
- 3> start to receive the indicated Secondary CCPCH.
 - 2> if the UE is in TDD mode and no shared transport channels are assigned to the UE:
- 3> set the variable UNSUPPORTED_CONFIGURATION to TRUE.
 - 2> if the IE "Serving HS-DSCH radio link indicator" is set to 'TRUE':
- 3> consider this radio link as the serving HS-DSCH radio link;
- 3> if the serving HS-DSCH radio link was another radio link than this radio link prior to reception of the message and the IE "H-RNTI" is not included:
 - 4> set the variable INVALID_CONFIGURATION to TRUE.
 - 2> act on the other IEs contained in the IE "Downlink information for each radio link" as specified in subclause 8.6 applied on this radio link.

- 1> in addition, if the message was received in CELL_DCH state and the UE remains in CELL_DCH state according to subclause 8.6.3.3 applied on the received message:
 - 2> for each optional IE part of the IE "Downlink information for each radio link" that is not present:
- 3> do not change its current downlink physical channel configuration corresponding to the IE, which is absent, if not stated otherwise elsewhere.
 - NOTE: The Release '99 RADIO BEARER RECONFIGURATION message always includes at least one IE "Downlink information for each radio link" containing the mandatory IEs, even if UTRAN does not require the reconfiguration of any radio link.
 - 1> if the UE would enter either the CELL_FACH, CELL_PCH or URA_PCH state according to subclause 8.6.3.3 applied on the received message:
 - 2> if the received message is CELL UPDATE CONFIRM:
- 3> ignore the IE "Downlink information for each radio link".
 - 2> if the received message is any other message than CELL UPDATE CONFIRM; and
 - 2> if IEs other than the IE "Primary CPICH info" (for FDD) or the IE "Primary CCPCH info" (for TDD) are included in the IE "Downlink information for each radio link":
- 3> ignore these IEs.
 - 2> act on the other IEs contained in the IE "Downlink information for each radio link" as specified in subclause 8.6 applied on this radio link.

8.6.6.5 Void

8.6.6.6 Uplink DPCH info

If the IE "Uplink DPCH info" is included, the UE shall:

For FDD:

- 1> release any active uplink physical channels and activate the given physical channels;
- 1> if the IE "Number of FBI bits" is not included:
 - 2> use 0 FBI bits in the Uplink DPCH.
- 1> use an SF equal to or greater than the minimum SF indicated in the IE "Spreading Factor" during uncompressed frames or compressed frames by HL scheduling;
- 1> use an SF equal to or greater than the minimum SF divided by 2 during compressed frames by SF reduction.

For TDD:

- 1> release the uplink physical channels associated with any CCTrCH that is removed or reconfigured and activate the physical channels assigned to any CCTrCH that is added or reconfigured;
- 1> for 3.84 Mcps TDD use the IE "UL target SIR" specified for each added or reconfigured CCTrCH as described in subclause 8.5.7. For 1.28 Mcps TDD use the value of IE 'UL target SIR' specified for each added or reconfigured CCTrCH for parameter PRX_{DPCHdes} as described in subclause 8.5.7;
- 1> use the parameters of the IE "Time info" for each added or reconfigured CCTrCH;
- 1> if present, use the IE "Uplink Timing Advance Control" as specified in subclause 8.6.6.26.

8.6.6.7 Void

8.6.6.8 Maximum allowed UL TX power

If the IE "Maximum allowed UL TX power" is included in the Handover to UTRAN Command, in any other dedicated message or in System Information Block type 3 or in System Information Block 4, the UE shall:

1> store and use the value until it is updated.

If the IE "Maximum allowed UL TX power" was not included in any dedicated message, the UE shall:

1> use the value previously stored, when received in an earlier dedicated message, Handover to UTRAN Command message or received in System Information Block type 3 or in System Information Block 4.

For all cases, the UE shall:

- 1> keep the UE uplink transmit power at or below the indicated power value;
- 1> if the current UE uplink transmit power is above the indicated power value:
 - 2> decrease the power to a level at or below the power value.

The maximum UE TX power is defined as the lower of the maximum output power of the UE power class and the maximum allowed UL TX power indicated in this IE. The maximum UE TX power shall not be exceeded.

8.6.6.9 PDSCH with SHO DCH Info (FDD only)

If the IE "PDSCH with SHO DCH Info" is included, the UE shall:

- 1> if the variable DSCH_RNTI is empty:
 - 2> set the variable INVALID_CONFIGURATION to TRUE.
- 1> configure itself to receive the PDSCH from the specified radio link within the active set identified by the IE "DSCH radio link identifier";
- 1> if the TFCI has a 'hard' split:
 - 2> if the IE "TFCI(field2) combining set" is included:

3> configure the Layer 1 to combine soft only the DPCCH TFCI(field 2) of the radio links within the active set which are identified by the IE "Radio link identifier" in the IE "TFCI(field2) Combining set".

2> if the IE "TFCI(field2) combining set" is not included:

3> configure the L1 to combine soft the DPCCH TFCI(field 2) of all radio links within the active set.

8.6.6.10 PDSCH code mapping (FDD only)

If the IE "PDSCH code mapping" is included, the UE shall:

- 1> if the variable DSCH_RNTI is empty:
 - 2> set the variable INVALID_CONFIGURATION to TRUE.
- 1> use the scrambling code defined by the IE "DL Scrambling Code" to receive the PDSCH;
- 1> if the IE choice "signalling method" is set to 'code range':
 - 2> map the TFCI(field2) values to PDSCH codes in the following way:
 - 2> for the first group of the IE "PDSCH code mapping":
- 3> if the value of the IE "multi-code info" equals 1:

- 4> map the TFCI(field 2) = 0 to the PDSCH code specified by the IE "Spreading factor" and the code number given by the IE "Code number (for PDSCH code) start";
- 4> map TFCI(field 2) = 1 to the PDSCH code specified by the IE "Spreading factor" and the code number given by the IE "Code number (for PDSCH code) start"+1;
- 4> continue this process with unit increments in the value of TFCI(field 2) mapped to unit increments in code number until the code number equals the value of the IE "Code number (for PDSCH code) stop".
- 3> if the value of the IE "multi-code info" is greater than 1:
 - 4> if the value of the difference between the IE "Code number (for PDSCH code) start" and the IE "Code number (for PDSCH code) stop" + 1 is not a multiple of the value of the IE "multi-code info":
 - 5> set the variable INVALID_CONFIGURATION to TRUE.
 - 4> map TFCI (field 2)=0 to a set of PDSCH contiguous codes. This code set is specified by the IE "Spreading factor" and code numbers between 'code number start' denoted by the IE "Code number (for PDSCH code) start" and 'code number stop' given by IE "Code number (for PDSCH code) start" 1 + the value of the IE "multi-code info";
 - 4> continue this process with unit increments in the value of TFCI(field 2) mapped to a set of contiguous codes. This code set is specified by the IE "Spreading factor" and code numbers between 'code number start' = 'code number stop' +1 of the previous TFCI(field2) and 'code number stop'='code number start' 1 + the value of the IE "multi-code info";
 - 4> stop this process when the 'code number stop' associated to the last TFCI(field2) equals the value of the IE "Code number (for PDSCH code) stop".
 - 2> for each of the next groups included in the IE "PDSCH code mapping":
- 3> continue the process in the same way as for the first group with the TFCI(field 2) value used by the UE to construct its mapping table starting at the largest TFCI(field 2) value reached in the previous group plus one.
 - 2> if the value of the IE "Code number (for PDSCH code) start" equals the value of the IE "Code number (for PDSCH code) stop" (as may occur when mapping the PDSCH root code to a TFCI (field 2) value):
- 3> consider this as defining the mapping between the channelisation code and a single TFCI (i.e., TFCI(field 2) shall not be incremented twice).
 - 1> if the IE choice "signalling method" is set to 'TFCI range':
 - 2> map the TFCI(field2) values to PDSCH codes in the following way:
 - 2> for the first group of the IE "DSCH mapping":
- 3> map each of the TFCI(field 2) between 0 and the value of the IE "Max TFCI(field2)" to the PDSCH code specified by the IE "Spreading factor (for PDSCH code)" and the code number given by the IE "Code number (for PDSCH code)".
 - 2> for each of the next groups included in the IE "DSCH mapping":
- 3> map each of the TFCI(field 2) between the IE "Max TFCI(field2) value" specified in the last group plus one and the specified IE "Max TFCI(field2)" in the current group to the PDSCH code specified by the IE "Spreading factor (for PDSCH code)" and the code number given by the IE "Code number (for PDSCH code)".
 - 2> if the value of the IE "multi-code info" is greater than 1:
- 3> map each value of TFCI (field 2) to a set of PDSCH contiguous codes starting at the channelisation code denoted by the 'code number' parameter and including all codes with code numbers up to and including 'code number' 1 + the value of the IE "multi-code info".
 - 1> if the IE choice "signalling method" is set to 'Explicit'
 - 2> map the TFCI(field2) values to PDSCH codes in the following way:
 - 2> for the first instance on the IE "PDSCH code info":

- 3> apply the PDSCH code specified by the IE "Spreading factor (for PDSCH code)" and the code number given by the IE "Code number (for PDSCH code)" for TFCI(field2)=0.
 - 2> for the second instance of the IE "PDSCH code info":
- 3> apply the PDSCH code specified by the IE "Spreading factor (for PDSCH code)" and the code number given by the IE "Code number (for PDSCH code)" for TFCI(field2)=1.
 - 2> continue in a similar way for each next instance of the IE "PDSCH code info";
 - 2> if the value of the IE "multi-code info" is greater than 1, then
- 3> map each value of TFCI (field 2) to a set of PDSCH contiguous codes starting at the channelisation code denoted by the 'code number' parameter and including all codes with code numbers up to and including 'code number' 1 + the value of the IE "multi-code info".
 - 1> if the IE choice "signalling method" is set to 'Replace':
 - 2> map the TFCI(field2) values to PDSCH codes in the following way:
 - 2> for each instance of the IE "Replaced PDSCH code":
- 3> replace the corresponding PDSCH code for the TFCI(field2) identified by the IE "TFCI(field2)" with the new code specified by the IE "Spreading factor (for PDSCH code)" and the code number given by the IE "Code number (for PDSCH code)".
 - 2> if the value of the IE "multi-code info" is greater than 1:
- 3> map each value of TFCI (field 2) to a set of PDSCH contiguous codes starting at the channelisation code denoted by the 'code number' parameter and including all codes with code numbers up to and including 'code number' 1 + the value of the IE "multi-code info".

8.6.6.11 Uplink DPCH power control info

- 1> in FDD:
 - 2> if the IE "Uplink DPCH power control info" is included:
- 3> if a synchronisation procedure A is performed according to [29]:
 - 4> calculate and set an initial uplink transmission power;
 - 4> start inner loop power control as specified in subclause 8.5.3;
 - 4> for the UL inner loop power control:
 - 5> use the parameters specified in the IE.
- 3> else:
- 4> act on the IE "Power control algorithm" and the IE "TPC step size" if included and ignore any other IEs that are included.
- 1> in 3.84 Mcps TDD:
 - 2> if the IE "Uplink DPCH power control info" is included:
- 3> use the parameters specified in the IE for open loop power control as defined in subclause 8.5.7.
 - 2> else:
- 3> use the current uplink transmission power.
 - 1> in 1.28 Mcps TDD:

- 2> if the CHOICE UL OL PC info is set to 'Broadcast UL OL PC info':
- 3> set the variable INVALID_CONFIGURATION to true.
 - 2> if the IE "Uplink DPCH power control info" is included in the UPLINK PHYSICAL CHANNEL CONTROL message:

3> use the TPC step size for the closed loop power control of the CCTrCH identified in the message, replacing the existing value used for the CCTrCH.

- 3> if the IE " UL target SIR " is included:
 - 4> use this value for parameter PRX_{DPCHdes} for open loop power control of the CCTrCH identified in the message in the case of a transition from closed loop to open loop power control as specified in [33].
 - 2> if the IE "Uplink DPCH power control info" is included in the IE "Uplink DPCH info":

3> use the TPC step size for the closed loop power control of all CCTrCH added or reconfigured by the IE replacing any existing values used for the CCTrCHs;

- 3> if the IE " UL target SIR " is included ignore the parameter.
 - 1> both in FDD and TDD;
 - 2> if the IE "Uplink DPCH power control info" is not included in a message used to enter CELL_DCH:
- 3> set the variable INVALID_CONFIGURATION to true.

8.6.6.12 Secondary CPICH info

If the IE Secondary CPICH info is included, the UE may:

- 1> use the channelisation code according to IE "channelisation code", with scrambling code according to IE "DL scrambling code" in the IE "Secondary CPICH info", for channel estimation of that radio link;
- 1> use the pilot bits on DPCCH for channel estimation.

If the IE Secondary CPICH info is not included, the UE shall:

1> not use any previously stored configuration corresponding to the usage of the Secondary CPICH info.

8.6.6.13 Primary CPICH usage for channel estimation

If the IE "Primary CPICH usage for channel estimation" is included and has the value "Primary CPICH may be used" the UE:

- 1> may use the Primary CPICH for channel estimation;
- 1> may use the pilot bits on DPCCH for channel estimation.

If the IE "Primary CPICH usage for channel estimation" is included and has the value "Primary CPICH shall not be used" the UE:

- 1> shall not use the Primary CPICH for channel estimation;
- 1> may use the Secondary CPICH for channel estimation;
- 1> may use the pilot bits on DPCCH for channel estimation.

8.6.6.14 DPCH frame offset

If "DPCH frame offset" is included in a message that instructs the UE to enter CELL_DCH state:

- 1> UTRAN should:
 - 2> if only one Radio Link is included in the message:

3> set "Default DPCH Offset Value" and "DPCH frame offset" respecting the following relation:

(Default DPCH Offset Value) mod 38400 = DPCH frame offset

- where the IE values used are the Actual Values of the IEs as defined in clause 11.
- 2> if more than one Radio Link are included in the message:
- 3> set "Default DPCH Offset Value" and "DPCH frame offset" respecting the following relation:

(Default DPCH Offset Value) mod 38400 = DPCH frame offset_i

- where *j* indicates the first radio link listed in the message and the IE values used are the Actual Values of the IEs as defined in clause 11.
- 1> The UE shall:
 - 2> on reception of a message where the above relation between "Default DPCH Offset Value" and "DPCH frame offset" is not respected:

3> set the variable INVALID_CONFIGURATION to true.

If the IE "DPCH frame offset" is included the UE shall:

1> use its value to determine the beginning of the DPCH frame.

8.6.6.15 DPCH Compressed mode info

If the IE "DPCH compressed mode info" is included, and if the IE group "transmission gap pattern sequence configuration parameters" is included, the UE shall for each transmission gap pattern sequence perform the following consistency checks:

- 1> if the UE, according to its measurement capabilities, and for all supported bands of the UTRA mode or RAT associated with the measurement purpose indicated by IE "TGMP", requires UL compressed mode, and CHOICE 'UL/DL mode' indicates 'DL only':
 - 2> set the variable INVALID_CONFIGURATION to TRUE.
- 1> if the UE, according to its measurement capabilities, and for all supported bands of the UTRA mode or RAT associated with the measurement purpose indicated by IE "TGMP", requires DL compressed mode, and CHOICE 'UL/DL mode' indicates 'UL only':
 - 2> set the variable INVALID_CONFIGURATION to TRUE.
- 1> if the UE, according to its measurement capabilities, does not require UL compressed mode for any of supported band of the UTRA mode or RAT associated with the measurement purpose indicated by the IE "TGMP", and CHOICE 'UL/DL mode' indicates 'UL only' or 'UL and DL':
 - 2> set the variable INVALID CONFIGURATION to TRUE.
- 1> if the UE, according to its measurement capabilities, does not require DL compressed mode for any supported band of the UTRA mode or RAT associated with the measurement purpose indicated by the IE "TGMP", and CHOICE 'UL/DL mode' indicates 'DL only' or 'UL and DL':
 - 2> set the variable INVALID_CONFIGURATION to TRUE.
- 1> if UE already has an active transmission gap pattern sequence that, according to IE "TGMP", has the same measurement purpose, and both patterns will be active (according to the IE "Current TGPS Status Flag" in variable TGPS IDENTITY) after the new configuration has been taken into use:
 - 2> set the variable INVALID CONFIGURATION to TRUE.
- 1> if there is any pending "TGPS reconfiguration CFN" or any pending "TGCFN":
 - 2> the UE behaviour is unspecified.

If variable INVALID_CONFIGURATION has value FALSE after UE has performed the checks above, the UE shall:

- 1> if pattern sequence corresponding to IE "TGPSI" is already active (according to "Current TGPS Status Flag") in the variable TGPS_IDENTITY):
 - 2> if the "TGPS Status Flag" in this message is set to "deactivate" for the corresponding pattern sequence:
- 3> deactivate this pattern sequence at the beginning of the frame, indicated by IE "Activation time" (see subclause 8.6.3.1) received in this message, when the new configuration received in this message is taken into use.
- 3> set the "Current TGPS Status Flag" for this pattern sequence in the variable TGPS_IDENTITY to "inactive" at the frame, indicated by IE "Activation time" (see subclause 8.6.3.1) received in this message, when the new configuration received in this message is taken into use.
 - 2> if the "TGPS Status Flag" in this message is set to "activate" for the corresponding pattern sequence:
- 3> deactivate this pattern sequence at the beginning of the frame, indicated by IE "Activation time" (see subclause 8.6.3.1) received in this message, when the new configuration received in this message is taken into use.
 - NOTE1: The temporary deactivation of pattern sequences for which the status flag is set to "activate" can be used by the network to align the timing of already active patterns with newly activated patterns.
 - NOTE2: The deactivation of pattern sequences only occurs as a result of RRC messages received by the UE, i.e. the UE does not set the "Current TGPS Status Flag" to "inactive" after the final gap of a finite length pattern sequence.
 - 1> update each pattern sequence to the variable TGPS_IDENTITY according to the IE "TGPSI";
 - 1> update into the variable TGPS_IDENTITY the configuration information defined by IE group" transmission gap pattern sequence configuration parameters ";
 - 1> after the instant in which the message is to be executed, as specified in subclause 8.6.3.1:
 - 2> activate the stored pattern sequence corresponding to each IE "TGPSI" for which the "TGPS status flag" in the variable TGPS_IDENTITY is set to "activate" at the time indicated by IE "TGCFN"; and
 - 2> set the "Current TGPS Status Flag" for this pattern sequence in the variable TGPS_IDENTITY to "active".
 - NOTE1: If the pattern is activated with a message that includes the IE "Activation time", and if the CFN value indicated by the IE "Activation Time" and the CFN value indicated by the TGCFN are included in the same TTI (but not at the TTI boundary) common to all the transport channels that are multiplexed onto the reference CCTrCh (as defined in subclause 8.6.3.1), and if the CFN value indicated by the TGCFN is equal or higher than the CFN value indicated by the IE "Activation Time" (as defined in subclause 8.6.3.1) value, the UE behaviour is not specified.
 - NOTE2: If the pattern is activated with a message used to perform timing re-initialised hard handover, the UE can start evaluating the activation of the pattern (i.e. compare the value of the CFN in the new configuration with the value of the TGCFN) at any time between the message activation time and the completion of the synchronisation procedure A.
 - 2> if the IE "DPCH compressed mode info" is included in a message used to perform a Hard Handover with change of frequency (see subclause 8.3.5); or
 - 2> if the IE "DPCH compressed mode info" is included in a message used to transfer the UE from Cell_FACH to Cell_DCH, and the cell in which the UE transited from CELL_FACH state is not included in the active set for the CELL_DCH state (see subclause 8.4.1.7.2):
 - 3> not begin the inter-frequency measurement reporting corresponding to the pattern sequence measurement purpose of each activated pattern sequence.
 - 2> else:
- 3> begin the inter-frequency measurement reporting corresponding to the pattern sequence measurement purpose of each activated pattern sequence.
 - 2> begin the inter-RAT measurement reporting corresponding to the pattern sequence measurement purpose of each activated pattern sequence;

- 2> if the new configuration is taken into use at the same CFN as indicated by IE "TGCFN":
- 3> start the concerned pattern sequence immediately at that CFN.
 - 1> monitor if the parallel transmission gap pattern sequences create an illegal overlap, and in case of overlap, take actions as specified in subclause 8.2.11.2.

If the IE "DPCH compressed mode info" is included, and if the IE group "transmission gap pattern sequence configuration parameters" is not included, the UE shall:

- 1> if, as the result of this message, UE will have more than one transmission gap pattern sequence with the same measurement purpose active (according to IEs "TGMP" and "Current TGPS Status Flag" in variable TGPS_IDENTITY):
 - 1> set the variable CONFIGURATION_INCOMPLETE to TRUE.
- 1> if there is any pending "TGPS reconfiguration CFN" or any pending "TGCFN":
 - 2> the UE behaviour is unspecified.
- 1> if pattern sequence corresponding to IE "TGPSI" is already active (according to "Current TGPS Status Flag" in the variable TGPS_IDENTITY):
 - 2> if the "TGPS Status Flag" in this message is set to "deactivate" for the corresponding pattern sequence:
- 3> deactivate this pattern sequence at the beginning of the frame, indicated by IE "Activation time" (see subclause 8.6.3.1) received in this message, when the new configuration received in this message is taken into use;
- 3> set the "Current TGPS Status Flag" for this pattern sequence in the variable TGPS_IDENTITY to "inactive" at the frame, indicated by IE "Activation time" (see subclause 8.6.3.1) received in this message, when the new configuration received in this message is taken into use.
 - 2> if the "TGPS Status Flag" in this message is set to "activate" for the corresponding pattern sequence:
- 3> deactivate this pattern sequence at the beginning of the frame, indicated by IE "Activation time" (see subclause 8.6.3.1) received in this message, when the new configuration received in this message is taken into use.
 - NOTE1: The temporary deactivation of pattern sequences for which the status flag is set to "activate" can be used by the network to align the timing of already active patterns with newly activated patterns.
 - NOTE2: The deactivation of pattern sequences only occurs as a result of RRC messages received by the UE, i.e. the UE does not set the "Current TGPS Status Flag" to "inactive" after the final gap of a finite length pattern sequence.
 - 1> after the instant in which the message is to be executed, as specified in subclause 8.6.3.1:
 - 2> activate the stored pattern sequence corresponding to each IE "TGPSI" for which the "TGPS status flag" is set to "activate" at the time indicated by IE "TGCFN"; and
 - NOTE1: If the pattern is activated with a message that includes the IE "Activation time", and if the CFN value indicated by the IE "Activation Time" and the CFN value indicated by the TGCFN are included in the same TTI (but not at the TTI boundary) common to all the transport channels that are multiplexed onto the reference CCTrCh (as defined in subclause 8.6.3.1), and if the CFN value indicated by the TGCFN is equal or higher than the CFN value indicated by the IE "Activation Time" (as defined in subclause 8.6.3.1) value, the UE behaviour is not specified.
 - NOTE2: If the pattern is activated with a message used to perform timing re-initialised hard handover, the UE can start evaluating the activation of the pattern (i.e. compare the value of the CFN in the new configuration with the value of the TGCFN) at any time between the message activation time and the completion of the synchronisation procedure A.
 - 2> set the "Current TGPS Status Flag" for this pattern sequence in the variable TGPS_IDENTITY to "active";
 - 2> if the IE "DPCH compressed mode info" is included in a message used to perform a Hard Handover with change of frequency (see subclause 8.3.5); or

2> if the IE "DPCH compressed mode info" is included in a message used to transfer the UE from Cell_FACH to Cell_DCH, and the cell in which the UE transited from CELL_FACH state is not included in the active set for the CELL_DCH state (see subclause 8.4.1.7.2):

3> not begin the inter-frequency measurement reporting corresponding to the pattern sequence measurement purpose of each activated pattern sequence.

2> else:

- 3> begin the inter-frequency measurement reporting corresponding to the pattern sequence measurement purpose of each activated pattern sequence.
 - 2> begin the inter-RAT measurement reporting corresponding to the pattern sequence measurement purpose of each activated pattern sequence;
 - 2> if the new configuration is taken into use at the same CFN as indicated by IE "TGCFN":
- 3> start the concerned pattern sequence immediately at that CFN.

For transmission gap pattern sequences stored in variable TGPS_IDENTITY, but not identified in IE "TGPSI" (either due to the absence of the IE "DPCH compressed mode info" in the received message or due to not receiving the corresponding TGPSI value in the IE "DPCH compressed mode info"), the UE shall:

- 1> if the received message implies a timing re-initialised hard handover (see subclause 8.3.5.1):
 - 2> deactivate such transmission gap pattern sequences at the beginning of the frame, indicated by IE "Activation time" (see subclause 8.6.3.1) received in this message; and
 - 2> set IE "Current TGPS Status Flag" in corresponding UE variable TGPS_IDENTITY to 'inactive'.
- 1> if the received message not implies a timing re-initialised hard handover (see subclause 8.3.5.1):
 - 2> continue such transmission gap pattern sequence according to IE "Current TGPS Status Flag" in the corresponding UE variable TGPS_IDENTITY.

Uplink and downlink compressed mode methods are described in [27]. For UL "higher layer scheduling" compressed mode method and transport format combination selection, see [15].

8.6.6.16 Repetition period, Repetition length, Offset (TDD only)

In case the physical allocations of different channels overlap the following priority rules shall apply for common channels and shall be taken into account by the UE:

- 1> PICH takes precedence over Primary CCPCH;
- 1> PICH takes precedence over Secondary CCPCH;
- 1> Secondary CCPCH takes precedence over Primary CCPCH.

The frame allocation can be derived by following rules:

If no IE "Offset" is explicitly given, the parameter "Offset" to be used is calculated by the following equation:

Activation time mod Repetition period = Offset.


Frames from CFN CFN $_{\rm off}$ to CFN $_{\rm off}$ + Repetition length - 1 belong to the allocation with CFN $_{\rm off}$ fulfilling the following equation:

 CFN_{off} mod Repetition period = Offset.

Repetition length is always a multiple of the largest TTI within the CCTrCH fulfilling the following equation:

(largest TTI within CCTrCH) * X = Repetition Length

Example of usage:



- \blacktriangle physic. channel (Code 7; Repetition period=8; Repetition length=5; Activation time = $4 \Rightarrow$ Offset = $4 \Rightarrow$ CFN_{off} = 4, 12, 20, 28, 36, 44, 52, 60)
- physic. channel (Code 5; Repetition Period=1 => Repetition length=0; Offset = 0 => $CFN_{off} = 0, 1, 2, 3, 4, ...$ (continuous allocation))
- physic. channel (Code 3; Repetition period=16; Repetition length=3; Activation time
 = 23 =>Offset = 7 => CFN_{off} = 7, 23, 39, 55)

Figure 8.6.6.16-1: Examples for frame allocations in TDD

8.6.6.17 Primary CCPCH info

If the IE "Primary CCPCH info" is included, the UE shall:

1> use the information elements in this IE.

8.6.6.18 Primary CPICH info

If the IE "Primary CPICH info" in FDD is included, the UE shall:

1> use the value of this IE as the primary scrambling code for the downlink radio link.

8.6.6.19 CPCH SET Info (FDD only)

If the UE has the capability to use CPCH, the UE shall use the following general procedures:

- 1> if an IE "CPCH SET Info" is included in a dedicated message:
 - 2> read the "CPCH set ID" included in the IE;
 - 2> store the IE using the "CPCH set ID" as an address tag;
 - 2> release any active dedicated physical channels in the uplink;
 - 2> let the PCPCHs listed in the CPCH set be the default in the uplink for CPCH.
- 1> if an IE "CPCH SET Info" is included in a System Information message:
 - 2> read the "CPCH set ID" included in the IE;
 - 2> store the IE using the "CPCH set ID" as an address tag.

8.6.6.20 CPCH set ID (FDD only)

If the UE has the capability to use CPCH, the UE shall use the following general procedures. The UE shall:

- 1> if an IE "CPCH set ID" is included in a dedicated message and not as part of IE "CPCH SET Info":
 - 2> use the IE as an address tag to retrieve the corresponding stored "CPCH SET Info";
 - 2> release any active dedicated physical channels in the uplink;
 - 2> let the PCPCHs listed in the CPCH set be the default in the uplink for CPCH.

- 1> if an IE "CPCH set ID" is included in a dedicated message and not as part of IE "CPCH SET Info", and if there is no corresponding stored "CPCH SET Info":
 - 2> release any active dedicated physical channels in the uplink;
 - 2> let the last assigned PRACH be the default in the uplink for RACH;
 - 2> obtain current System Information on SCCPCH to obtain and store the "CPCH SET info" IE(s);
 - 2> upon receipt of a "CPCH SET Info" which corresponds to the "CPCH set ID" IE:
- 3> let the PCPCHs listed in that CPCH set be the default in the uplink for CPCH.
 - 1> if an IE "CPCH set ID" is not included in a dedicated message and the UE prior to the receipt of this message had configured the PCPCH as the default in the uplink:
 - 2> stop using the PCPCH;
 - 2> let the last assigned PRACH be the default in the uplink for RACH.

8.6.6.21 Default DPCH Offset Value

The UE shall:

- 1> if the IE "Default DPCH Offset Value" is included:
 - 2> use its value to determine Frame Offset and Chip Offset from the SFN timing in a cell.

8.6.6.22 Secondary Scrambling Code, Code Number

The following description applies to FDD.

Code Number can be assigned by following rules:

1> When more than one DL DPDCH is assigned per RL, the segmented physical channel shall be mapped on to DL DPDCHs according to [27]. When *p* number of DL DPDCHs are assigned to each RL, the first pair of Secondary Scrambling Code and Code Number corresponds to "*PhCH number 1*", the second to "*PhCH number 2*", and so on until the *p*th to "*PhCH number p*".

8.6.6.23 PDSCH Power Control info

The UE shall:

- 1> if the IE "PDSCH Power Control info" is included:
 - 2> configure PDSCH power control with the received values.
- 1> if the IE "PDSCH Power Control info" is not included:
 - 2> continue to use the stored values.

8.6.6.24 Tx Diversity Mode

If the IE "Tx Diversity Mode" is included the UE shall:

- 1> if the value of the IE "Tx Diversity Mode" is STTD:
 - 2> configure the Layer 1 to use the Tx diversity mode indicated in the IE "Tx Diversity Mode" for the radio links for which the IE "Closed loop timing adjustment mode" is included, ignoring the actual value of IE "Closed loop timing adjustment mode".
- 1> if the value of the IE "Tx Diversity Mode" is closed loop mode 1 or closed loop mode 2:

- 2> configure the Layer 1 to use the Tx diversity mode indicated in the IE "Tx Diversity Mode" for the radio links for which the IE "Closed loop timing adjustment mode" is included, using the actual value of the IE "Closed loop timing adjustment mode".
- 1> if the value of the IE "Tx Diversity Mode" is "none":
 - 2> configure the Layer 1 not to use Tx diversity for all radio links in the active set.
- If the IE "Tx Diversity Mode" is not included, the UE shall:
 - 1> continue to use the already configured Tx diversity mode;
 - 1> in case no Tx diversity mode has been configured:
 - 2> do not apply Tx diversity.

For HS-SCCH, the UE shall:

- 1> if the DPCH associated with a HS-SCCH is using either open or closed loop transmit diversity on the radio link transmitted from the HS-DSCH serving cell:
 - 2> use STTD for this HS-SCCH:
- 1> otherwise:
 - 2> not use Tx diversity for this HS-SCCH.

8.6.6.25 SSDT Information

- If the IE "SSDT Information" is included the UE shall:
 - 1> configure the size of the S-field in the FBI field on the uplink DPCCH to the value indicated in the IE "S-field";
 - 1> if the IE "Code Word Set" has the value "long", "medium" or "short":
 - 2> use the length of the temporary cell ID code for SSDT indicated in the IE "Code Word Set".
 - 1> if the IE "Code Word Set" has the value "SSDT off":
 - 2> terminate SSDT.

8.6.6.26 UL Timing Advance Control (TDD only)

- If the IE "UL Timing Advance Control" is present, the UE shall:
 - 1> if the IE "Uplink Timing Advance Control" has the value "disabled":
 - 2> reset timing advance to 0;
 - 2> disable calculated timing advance following handover;
 - 2> in case of handover:
- 3> start uplink transmissions in the target cell without applying timing advance.
 - 1> if the IE "Uplink Timing Advance Control" has the value "enabled":
 - 2> in 3.84 Mcps TDD:
- 3> in case of no cell change:
 - 4> evaluate and apply the timing advance value for uplink transmission as indicated in the IE "Uplink Timing Advance" at the CFN indicated in the IE "Activation Time".
- 3> in case of cell change:

- 4> use the IE "Uplink Timing Advance" as TA_{old} and apply TA_{new} for uplink transmission in the target cell at the CFN indicated in the IE "Activation Time" as specified in [33];
- 4> include the value of the applied timing advance in the IE "Timing Advance" in the COMPLETE message.
- 2> in 1.28 Mcps TDD:
- 3> if the IE "Synchronisation parameters" is included:
 - 4> initiate a sequence of UpPCH SYNC_UL code transmissions using a code selected from the set specified and continue until a timing correction is received in the specified FPACH (received for WT sub-frames following the sub-frame in which the transmission was made) or until Max SYNC_UL transmissions have been completed. The power used for each SYNC_UL transmission is as specified in subclause 8.5.7. Each transmission is made in the first sub-frame possible following the end of each FPACH reception interval using the timing specified in [33]. A new code is selected for each transmission. The detection that the FPACH relates to the transmitted SYNC_UL code is described in [33];
 - 4> if a timing correction is received within Max SYNC_UL transmissions the procedure is completed. The assigned uplink resources may then be used, commencing at the first possible TTI boundary or the SFN in which the assignment commences, whichever is the later. The timing of the uplink transmission is described in [33];
 - 4> if no timing correction has been received within Max SYNC_UL transmissions, the synchronisation procedure has failed. If the assigned resources are DCH, the UE should not transmit using these resources and should respond as if a physical channel failure has occurred as specified in subclauses 8.1.3.7 or 8.2.2.7 or 8.3.1.7, or 8.3.6.5. If the assigned resources are USCH then the UE should ignore the USCH allocation.
- 3> if the IE "Synchronisation parameters" is not included:
 - 4> in case of no cell change:
 - 5> continue to use the current uplink timing.
 - 4> in case of cell change:
 - 5> evaluate and apply the timing correction TA_{new} for uplink transmissions using the procedure as specified in [33].

8.6.6.26a Uplink synchronisation parameters (TDD only)

The UE shall apply uplink synchronisation using the values of the IEs "Uplink synchronisation step size" and "Uplink synchronisation frequency" as specified in [33].

8.6.6.27 Downlink information common for all radio links

If the IE "Downlink information common for all radio links" is included the UE shall:

- 1> if the IE "Downlink DPCH info common for all RL" is included:
 - 2> perform actions as specified in subclause 8.6.6.28.
- 1> if the IE choice "mode" is set to 'FDD':
 - 2> perform actions for the IE "DPCH compressed mode info" as specified in subclause 8.6.6.15;
 - 2> perform actions for the IE "Tx Diversity mode" as specified in subclause 8.6.6.24;
 - 2> if the IE "SSDT information" is included:
- 3> perform actions as specified in subclause 8.6.6.25.
 - 1> if the IE "Default DPCH Offset value" is included:

- 2> perform actions as specified in the subclause 8.6.6.21.
- 1> if the IE "MAC-hs reset indicator" is included:
 - 2> reset the MAC-hs entity [15].

8.6.6.28 Downlink DPCH info common for all radio links

If the IE "Downlink DPCH info common for all RL" is included the UE shall:

- 1> if the IE "Downlink DPCH info common for all RL" is included in a message used to perform a hard handover:
 - 2> perform actions for the IE "Timing indication" as specified in subclause 8.5.15.2, and subclause 8.3.5.1 or 8 3 5 2
- 1> ignore the value received in IE "CFN-targetSFN frame offset";
- 1> if the IE "Downlink DPCH power control information" is included:
 - 2> in the case of FDD:
- 3> perform actions for the IE "DPC Mode" according to [29].
 - 2> in the case of TDD:
- 3> perform actions for the IE "TPC Step Size" according to [33].
 - 1> if the IE choice "mode" is set to 'FDD':
 - 2> if the IE "Downlink rate matching restriction information" is included:
- 3> set the variable INVALID_CONFIGURATION to TRUE.
 - 2> perform actions for the IE "spreading factor";
 - 2> perform actions for the IE "Fixed or Flexible position";
 - 2> perform actions for the IE "TFCI existence";
 - 2> if the IE choice "SF" is set to 256:
- 3> store the value of the IE "Number of bits for pilot bits".
 - 2> if the IE choice "SF" is set to 128:
- 3> store the value of the IE "Number of bits for pilot bits".

If the IE "Downlink DPCH info common for all RL" is included in a message used to perform a Timing re-initialised hard handover or the IE "Downlink DPCH info common for all RL" is included in a message other than RB SETUP used to transfer the UE from a state different from Cell_DCH to Cell_DCH, and ciphering is active for any radio bearer using RLC-TM, the UE shall, after having activated the dedicated physical channels indicated by that IE:

- 1> if any ciphering configuration for a radio bearer using RLC-TM has not been applied, due to that the activation time from a previous procedure has not elapsed:
 - 2> apply the ciphering configuration immediately and consider the activation time from the previous procedure to be elapsed;
- 1> if the IE "MAC-d HFN initial value" is included in the IE "Downlink DPCH info common for all RL":
 - 2> set the HFN component of COUNT-C for TM-RLC to the value of the IE "MAC-d HFN initial value", while not incrementing the value of the HFN component of COUNT-C at each CFN cycle.
- NOTE: The UTRAN should choose a value for the IE "MAC-d HFN initial value" using the COUNT-C value of the RBs using RLC-TM indicated by the Source RNC to the Target RNC in the IE "SRNS Relocation Info" and include some margin in such a way that no values of COUNT-C are repeated after the handover.

1> else:

- 2> set the 20 MSB of the HFN component of COUNT-C for TM-RLC to the value of the latest transmitted IE "START" or "START List" for this CN domain, while not incrementing the value of the HFN component of COUNT-C at each CFN cycle; and
- 2> set the remaining LSBs of the HFN component of COUNT-C to zero.
- 1> start to perform ciphering on the radio bearer in lower layers while not incrementing the HFN;
- 1> include the IE "COUNT-C activation time" in the response message and specify a CFN value for this IE other than the default, "Now", that is a multiple of 8 frames (CFN mod 8 =0) and lies at least 200 frames ahead of the CFN in which the response message is first transmitted;
- 1> calculate the START value according to subclause 8.5.9;
- 1> include the calculated START values for each CN domain in the IE "START list" in the IE "Uplink counter synchronisation info" in the response message;
- 1> at the CFN value as indicated in the response message in the IE "COUNT-C activation time":
 - 2> set the 20 MSB of the HFN component of the COUNT-C variable common for all transparent mode radio bearers of this CN domain to the START value as indicated in the IE "START list" of the response message for the relevant CN domain; and
 - 2> set the remaining LSBs of the HFN component of COUNT-C to zero;
 - 2> increment the HFN component of the COUNT-C variable by one even if the "COUNT-C activation time" is equal to zero;
 - 2> set the CFN component of the COUNT-C to the value of the IE "COUNT-C activation time" of the response message. The HFN component and the CFN component completely initialise the COUNT-C variable;
 - 2> step the COUNT-C variable, as normal, at each CFN value, i.e. the HFN component is no longer fixed in value but incremented at each CFN cycle.

8.6.6.29 ASC setting

If the IE "ASC setting" is included, the UE shall:

- 1> establish the available signatures for this ASC as specified in the following:
 - 2> renumber the list of available signatures specified in the IE "Available signature" included in the IE "PRACH info" from signature index 0 to signature index N-1, where N is the number of available signatures, starting with the lowest available signature number and continuing in sequence, in the order of increasing signature numbers;
 - 2> consider as available signatures for this ASC the signatures included in this renumbered list from the index specified by the IE "Available signature Start Index" to the index specified by the IE "Available signature End Index".
- 1> establish the available access slot sub-channels for this ASC as specified in the following:
 - 2> if the IE "AICH transmission timing" included in the IE "AICH Info" is set to '0';
- 3> ignore the leftmost (most significant) bit (bit b3) of the bit string specified by the IE "Assigned Sub-Channel Number";
- 3> repeat 4 times the 3 rightmost (least significant) bits (bits b2-b0) of the bit string specified by the IE "Assigned Sub-Channel Number" to form a resulting bit string 'b2 b1 b0 b2 b1 b0 b2 b1 b0 b2 b1 b0' of length 12 bits, where the leftmost bit is the most significant.
 - 2> if the IE "AICH transmission timing" included in the IE "AICH Info" is set to '1':
- 3> repeat 3 times the bit string (bits b3-b0) specified by the IE "Assigned Sub-Channel Number" to form a bit string 'b3 b2 b1 b0 b3 b2 b1 b0 b3 b2 b1 b0' of length 12 bits, where the leftmost bit is the most significant.

- 2> perform in both cases, for the resulting bit string (that includes the repetitions) bit-wise logical AND operation with the IE "Available Sub Channel number" included in IE "PRACH info (for RACH)";
- 2> consider as available sub-channels for this ASC the available sub-channels indicated in the resulting bit string, after logical AND operation i.e. each bit set to 1 or 0 indicates availability or non-availability, respectively, of sub-channel number x, with x from 0 to 11, for the respective ASC.
- NOTE 1: In FDD, the list of available signatures is renumbered from signature index 0 to signature index N-1, where N is the number of available signatures, starting with the lowest available signature number and continuing in sequence, in the order of increasing signature numbers.
 - List of available signatures: 16 or fewer signatures are available.
 - Example: only signatures 0, 5, 10 and 15 are available, then:
 - Signature 0 is: available signature index 0
 - Signature 5 is: available signature index 1
 - Signature 10 is: available signature index 2
 - Signature 15 is: available signature index 3
- NOTE 2: In 3.84 Mcps TDD, the list of available channelisation codes (defined in PRACH info) is renumbered from channelisation code index 0 to channelisation code index N-1, where N is the number of available channelisation codes, starting with the lowest available channelisation code number and continuing in sequence, in the order of increasing channelisation code numbers

List of available channelisation codes: 8 or less channelisation codes are available.

The i-th bit of the bitmap defined in the IE "Available Channelisation Code indices" defines whether the channelisation code with the available channelisation code index i is to be used for this ASC (bit set means used, bit unset means not used). Only the low N bits shall be used in the bitmap, where N is the number of available channelisation codes defined in PRACH info.

Ex: spreading factor 16, channelisation codes 16/1, 16/2, 16/5, 16/8 are available:

Channelisation code 16/1 is: available channelisation code index 0

Channelisation code 16/2 is: available channelisation code index 1

Channelisation code 16/5 is: available channelisation code index 2

Channelisation code 16/8 is: available channelisation code index 3

Available Channelisation Code indices has the value '00001100' means: Channelisation Codes 16/5 and 16/8 are available for this ASC.

- NOTE 3: In TDD, the subchannel description is found in [33].
- NOTE 4: In 1.28 Mcps TDD, the list of available SYNC_UL codes (defined in PRACH info) is numbered from SYNC_UL code index 0 to SYNC_UL code index N-1, where N is the number of available SYNC_UL codes, starting with the lowest available SYNC_UL code number and continuing in sequence, in the order of increasing SYNC_UL code numbers

The i-th bit of the bitmap defined in the IE "Available SYNC_UL codes indices" defines whether the SYNC_UL code with the available SYNC_UL code index i is to be used for this ASC (bit set means used, bit unset means not used). Only the low N bits shall be used in the bitmap, where N is the number of available SYNC_UL codes defined in PRACH info.

- List of available SYNC_UL codes: 8 or fewer SYNC_UL codes are available.

Example: only signatures 0, 5, 6 and 7 are available, then:

- SYNC_UL codes 0 is: available SYNC_UL codes index 0
- SYNC_UL codes 5 is: available SYNC_UL codes index 1
- SYNC_UL codes 6 is: available SYNC_UL codes index 2
- SYNC_UL codes 7 is: available SYNC_UL codes index 3

Available SYNC_UL codes indices has the value '00001100' means: SYNC_UL codes 6 and 7 are available for this ASC.

8.6.6.30 SRB delay, PC preamble (FDD only)

When the IE "SRB delay" and IE "PC preamble" is received in a message that results in a configuration of uplink DPCH, the UE shall:

- 1> store the received IE "SRB delay" and IE "PC preamble" in the variable LATEST_CONFIGURED_SRB_DELAY_AND_PC_PREAMBLE;
- 1> after the establishment of the uplink physical channel, send DPCCH and no DPDCH according to [26] during the number of frames indicated in the IE "PC preamble"; and
- 1> then not send any data on signalling radio bearers RB0 to RB4 during the number of frames indicated in the IE "SRB delay".

8.6.6.31 FPACH/PRACH Selection (1.28 Mcps TDD only)

Where more than one FPACH is defined, the FPACH that a UE should receive following a UpPCH transmission is defined by the UpPCH signature (SYNC_UL) code that the UE used. The FPACH/PRACH number = N mod M where N denotes the signature number (0..7) and M denotes the number of FPACH/PRACH combinations that have been defined. The FPACH/PRACH number indicates the position of the FPACH/PRACH description in the IE "PRACH info".

The PRACH that should be used is selected out of the ones associated with the FPACH in the IE "PRACH info" according to [33].

8.6.6.32 Downlink HS-PDSCH Information

If the IE "Downlink HS-PDSCH Information" is included and the UE would enter CELL_DCH state according to subclause 8.6.3.3 applied on the received message, the UE shall:

- 1> if the IE "New H-RNTI" is included:
 - 2> perform the actions as specified in subclause 8.6.3.1b.
- 1> if the IE "HS-SCCH Info" is included:
 - 2> act as specified in subclause 8.6.6.33.
- 1> if the IE "Measurement Feedback Info" is included:
 - 2> act as specified in subclause 8.6.6.34.
- 1> if the IE "HS-DSCH Timeslot Configuration" or "HS-PDSCH Midamble Configuration" is included:
 - 2> store the received configuration.
- 1> For FDD, if, as a result of the received message, the variable H_RNTI is set and the UE has a stored IE "HS-SCCH Info" and a stored IE "Measurement Feedback Info"; and
- 1> For FDD, if the UE has received IE "Uplink DPCH Power Control Info" and stored Δ_{ACK} , Δ_{NACK} and Ack-NACK Repetition factor; and
- 1> For FDD, if the UE has stored IEs "MAC-hs queue to add or reconfigure list", "MAC-d PDU size Info" and "RB Mapping Info" corresponding to the HS-PDSCH configuration;
- 1> for 3.84 Mcps TDD, if, as a result of the received message, the variable H_RNTI is set and the UE has a stored IE "HS-SCCH Info" and a stored IE "HS-PDSCH Timeslot Configuration"; or
- 1> for 1.28 Mcps TDD, if, as a result of the received message, the variable H_RNTI is set and the UE has a stored IE "HS-SCCH Info" and a stored IE "HS-PDSCH Midamble Configuration":
 - 2> set the variable HS_DSCH_RECEPTION to TRUE;
 - 2> start HS-DSCH reception procedures according to the stored HS-PDSCH configuration:

- 3> as stated in subclause 8.6.3.1b for the IE "H-RNTI";
- 3> in subclause 8.6.6.33 for the IE "HS-SCCH Info"; and
- 3> in subclause 8.6.6.34 for the IE "Measurement Feedback Info".

If the IE "Downlink HS-PDSCH Information" is not included, the UE shall:

- 1> set the variable HS_DSCH_RECEPTION to FALSE;
- 1> stop HS-DSCH reception procedures according to the stored HS-PDSCH configuration.

8.6.6.33 HS-SCCH Info

If the IE "HS-SCCH Info" is included, the UE shall:

1> store the received configuration.

When the variable HS_DSCH_RECEPTION is set to TRUE the UE shall:

- 1> in the case of FDD:
 - 2> receive the HS-SCCH(s) according to the IE "HS-SCCH channelisation code" on the serving HS-DSCH radio link applying the scrambling code as received in the IE "DL Scrambling code".
- 1> in the case of TDD:
 - 2> receive the HS-SCCH(s) according to the IEs "Timeslot Number", "Channelisation Code" and Midamble configuration IEs.
 - 2> transmit the HS-SICH according to the IEs "Timeslot Number", "Channelisation Code" and Midamble configuration IEs.
 - 2> in 3.84 Mcps TDD:
 - 3> use the parameters specified in the IE "HS-SICH power control info" and "ACK-NAK power offset" for open loop power control as defined in subclause 8.5.7.
 - 2> in 1.28 Mcps TDD:
- 3> use the IE " PRX_{HS-SICH} " and "ACK-NAK power offset" to calculate and set an initial uplink transmission power;
- 3> use the IE "TPC step size" upon reception of TPC commands for closed loop power control.

8.6.6.34 Measurement Feedback Info

If the IE "Measurement Feedback Info" is included, the UE shall:

1> store the received configuration.

When the variable HS_DSCH_RECEPTION is set to TRUE the UE shall:

1> use the information for the channel quality indication (CQI) procedure in the physical layer on the serving HS-DSCH radio link.

8.6.6.35 DPC Mode

If the IE "DPC Mode" is included, the UE shall:

1> apply the indicated DPC mode according to [29].

If the IE "DPC Mode" is not included, the UE shall:

1> continue with the currently used DPC mode.

8.6.7 Measurement information elements

On reception of measurement information elements the UE shall:

- 1> store the received information in the variable MEASUREMENT_IDENTITY and CELL_INFO_LIST as specified;
- 1> perform further actions as specified in subclause 8.6.7 and subclause 8.4, based on the content of the variable MEASUREMENT_IDENTITY.

If a configuration is considered to be invalid the UE may:

1> set the variable CONFIGURATION_INCOMPLETE to TRUE.

8.6.7.1 Measurement validity

If the IE "measurement validity" for a given measurement has not been included in measurement control information, the UE shall delete the measurement associated with the variable MEASUREMENT_IDENTITY after the UE makes a transition to a new state.

If the IE "measurement validity" for this measurement has been included in measurement control information, the UE shall save the measurement associated with the variable MEASUREMENT_IDENTITY. The IE "UE state" defines the scope of resuming the measurement.

If the "UE state" is defined as "all states", the UE shall continue the measurement after making a transition to a new state. This scope is assigned for traffic volume measurement type and UE positioning measurement type. For traffic volume measurement type this scope can only be applied by the UE if the IE " traffic volume measurement object" has been included in measurement control information. If the IE " traffic volume measurement object" has not been included in measurement control information, the UE shall not save the measurement control information in variable MEASUREMENT_IDENTITY, but shall send a MEASUREMENT CONTROL FAILURE message to the UTRAN with failure cause "Configuration incomplete".

If the "UE state" is defined as "all states except CELL_DCH", the UE shall store the measurement to be resumed after a subsequent transition from CELL_DCH state to any of the other states in connected mode. This scope is assigned for traffic volume measurement type or UE positioning measurement type.

If the "UE state" is defined as "CELL_DCH", the UE shall store the measurement to be resumed after a subsequent transition to CELL_DCH state.

If the IE "measurement type" received in a MEASUREMENT CONTROL message is set to "inter-frequency measurement" or "intra-frequency measurement" and the IE "measurement validity" is present and is set to a value other than "CELL_DCH", the UE behaviour is unspecified.

If the IE "Measurement type" received in a MEASUREMENT CONTROL message is set to "UE positioning measurement", the IE "Measurement validity" is present and the value of the IE "Support for UP assisted GPS measurement validity in CELL_PCH and URA_PCH states" in the variable UE_CAPABILITY_TRANSFERRED is set to "FALSE", the UE shall:

- 1> if the IE "Measurement validity" is set to "All states":
 - 2> consider the UE positioning measurement to have the scope CELL_DCH and CELL_FACH.
- 1> if the IE "Measurement validity" is set to "All states except CELL_DCH":
 - 2> consider the UE positioning measurement to have the scope CELL_FACH.

8.6.7.2 Filter coefficient

If the IE "Filter coefficient" is received the UE shall, depending on the measurement quantity (see Table 8.6.7.2), apply filtering of the measurements for that measurement quantity according to the formula below. This filtering shall be performed by the UE before UE event evaluation. The UE shall depending on the reporting quantity (see Table 8.6.7.2), also filter the measurements reported in the IE "Measured results". The filtering shall not be performed for the measurements reported in the IE "Measured results on RACH" and for cell-reselection in connected or idle mode.

The filtering shall be performed according to the following formula.

$$F_n = (1 - a) \cdot F_{n-1} + a \cdot M_n$$

The variables in the formula are defined as follows:

 F_n is the updated filtered measurement result

 F_{n-1} is the old filtered measurement result

 M_n is the latest received measurement result from physical layer measurements, the unit used for M_n is the same unit as the reported unit in the MEASUREMENT REPORT message or the unit used in the event evaluation.

 $a = 1/2^{(k/2)}$, where k is the parameter received in the IE "Filter coefficient".

NOTE: if *k* is set to 0 that will mean no layer 3 filtering.

In order to initialise the averaging filter, F_{θ} is set to M_{I} when the first measurement result from the physical layer measurement is received.

The physical layer measurement results are sampled once every measurement period. The measurement period and the accuracy for a certain measurement is defined in [19] and [20].

Table 8.6.7.2 lists for all measurement quantities and reporting quantities if L3-filtering is applicable or not and used L3-filtering type for each measurement quantity.

Table 8.6.7.2: L3 filtering applicable for each measurement quantity and reporting quantity

Measurement- / Reporting quantity	L3-filtering applicable	Linear or logarithmic filtering	Comment
Pathloss	Yes	Log	
Cell synchronisation information	No	-	
Cell Identity	No	_	
Frequency quality estimate	No	-	Although the frequency quality estimate itself is not filtered, the inputs to the frequency quality estimate calculation (CPICH Ec/N0 or CPICH RSCP) are filtered
UTRA carrier RSSI	Yes	Log	
GSM carrier RSSI	Yes	Log	
Observed time difference to GSM cell	No	-	
UE transmitted power	Yes	Log	
FDD			
> UE Rx-Tx time difference	No	-	
> CPICH Ec/N0	Yes	Log	
> CPICH RSCP	Yes	Log	
TDD			
> Primary CCPCH RSCP	Yes	Log	
> Proposed TGSN	No	-	
> Timeslot ISCP	Yes	Log	
> TADV (1.28 Mcps TDD)	No	-	
> Applied TA (3.84 Mcps TDD)	No	-	

The UE shall support 2 different layer 3 filters per measurement type defined in subclause 8.4.0 (i.e. the UE shall be capable to apply at least 2 different L3 filters to intra-frequency measurement results, at least 2 different L3 filters to inter-frequency measurement results, etc.). If a MEASUREMENT CONTROL message is received that would require the UE to configure more than 2 different layer 3 filters, the UE may:

1> set the variable CONFIGURATION INCOMPLETE to TRUE.

8.6.7.3 Intra-frequency/Inter-frequency/Inter-RAT cell info list

If the IE "Intra-frequency cell info list" is received in System Information Block Type 11, the UE shall update the variable CELL_INFO_LIST accordingly and in the following order. The UE shall:

- 1> if the IE "Intra-frequency cell removal" is received:
 - 2> ignore the IE.
- 1> if the IE "New Intra-frequency cells" is received, for each cell, and in the same order as the cells appear in the IE:
 - 2> update the variable CELL INFO LIST as follows:
- 3> if the IE "Intra-frequency cell id" is received:
 - 4> store received cell information at this position in the Intra-frequency cell info list in the variable CELL_INFO_LIST, possibly overwriting any existing information in this position; and
 - 4> mark the position "occupied".
- 3> if the IE "Intra-frequency cell id" is not received:
 - 4> store the received cell information at the first vacant position in ascending order in the Intra-frequency cell info list in the variable CELL_INFO_LIST; and
 - 4> mark the position as "occupied".

If the IE "Intra-frequency cell info list" is received in System Information Block Type 12, the UE shall update the variable CELL_INFO_LIST accordingly and in the following order. The UE shall:

- 1> if the IE "Intra-frequency cell removal" is received:
 - 2> if it has the value "Remove some intra-frequency cells", at the position indicated by the IE "Intra-frequency cell id":
- 3> clear the cell information stored in the variable CELL_INFO_LIST; and
- 3> mark the position "vacant".
 - 2> if it has the value "Remove all intra-frequency cells":
- 3> for each position referring to an intra-frequency cell in the variable CELL_INFO_LIST:
 - 4> clear the cell information stored in the variable CELL_INFO_LIST; and
 - 4> mark the position "vacant".
 - 2> if it has the value "Remove no intra-frequency cells":
- 3> leave the variable CELL_INFO_LIST unchanged.
 - 1> if the IE "New Intra-frequency cells" is received, for each cell, and in the same order as the cells appear in the IE:
 - 2> update the variable CELL_INFO_LIST as follows:
- $3\!\!>$ if the IE "Intra-frequency cell id" is received:
 - 4> store received cell information at this position in the Intra-frequency cell info list in the variable CELL_INFO_LIST, possibly overwriting any existing information in this position; and
 - 4> mark the position "occupied".
- 3> if the IE "Intra-frequency cell id" is not received:
 - 4> store the received cell information at the first vacant position in ascending order in the Intra-frequency cell info list in the variable CELL_INFO_LIST; and

4> mark the position as "occupied".

If the IE "Intra-frequency cell info list" is received in a MEASUREMENT CONTROL message, the UE shall update the variable CELL_INFO_LIST accordingly and in the following order. The UE shall:

- 1> if the CHOICE "Intra-frequency cell removal" is received:
 - 2> if it has the value "Remove some intra-frequency cells", at the position indicated by the IE "Intra-frequency cell id":
- 3> clear the cell information stored in the variable CELL_INFO_LIST; and
- 3> mark the position "vacant".
 - 2> if it has the value "Remove all intra-frequency cells":
- 3> for each position referring to an intra-frequency cell in the variable CELL_INFO_LIST:
 - 4> clear the cell information stored in the variable CELL INFO LIST; and
 - 4> mark the position "vacant".
 - 2> if it has the value "Remove no intra-frequency cells":
- 3> leave the variable CELL_INFO_LIST unchanged.
 - 1> if the IE "New Intra-frequency cells" is received, for each cell, and in the same order as the cells appear in the IE:
 - 2> update the variable CELL_INFO_LIST as follows:
- 3> if the IE "Intra-frequency cell id" is received:
 - 4> store received cell information at this position in the Intra-frequency cell info list in the variable CELL_INFO_LIST, possibly overwriting any existing information in this position; and
 - 4> mark the position "occupied".
- 3> if the IE "Intra-frequency cell id" is not received:
 - 4> store the received cell information at the first vacant position in ascending order in the Intra-frequency cell info list in the variable CELL_INFO_LIST; and
 - 4> mark the position as "occupied".
 - 1> if the IE "Cells for measurement" is received, in the measurement configured by this message only:
 - 2> consider Intra-frequency cells whose cell information is stored at the position indicated by the IE "Intra-frequency cell id" in the variable CELL_INFO_LIST.
 - 1> if the IE "Cells for measurement" is not received, in the measurement configured by this message:
 - 2> consider all Intra-frequency cells whose cell information is stored in CELL_INFO_LIST.

If the IE "Inter-frequency cell info list" is received in System Information Block Type 11 update the variable CELL_INFO_LIST accordingly and in the following order. The UE shall:

- 1> if the IE "Inter-frequency cell removal" is received:
 - 2> ignore the IE.
- 1> if the IE "New Inter-frequency cells" is received, for each cell, and in the same order as the cells appear in the IE:
 - 2> update the variable CELL_INFO_LIST as follows:
- 3> if the IE "Inter-frequency cell id" is received:

- 4> store received cell information at this position in the Inter-frequency cell info list in the variable CELL_INFO_LIST, possibly overwriting any existing information in this position; and
- 4> mark the position "occupied".
- 3> if the IE "Inter-frequency cell id" is not received:
 - 4> store the received cell information at the first vacant position in ascending order in the Inter-frequency cell info list in the variable CELL_INFO_LIST; and
 - 4> mark the position as "occupied".

If the IE "Inter-frequency cell info list" is received in System Information Block Type 12, the UE shall update the variable CELL_INFO_LIST accordingly and in the following order. The UE shall:

- 1> if the CHOICE "Inter-frequency cell removal" is received:
 - 2> if it has the value "Remove some inter-frequency cells", at the position indicated by the IE "Inter-frequency cell id":
- 3> clear the cell information stored in the variable CELL_INFO_LIST; and
- 3> mark the position "vacant".
 - 2> if it has the value "Remove all inter-frequency cells":
- 3> for each position referring to an inter-frequency cell in the variable CELL_INFO_LIST:
 - 4> clear the cell information stored in the variable CELL_INFO_LIST; and
 - 4> mark the position "vacant".
 - 2> if it has the value "Remove no inter-frequency cells":
- 3> leave the variable CELL_INFO_LIST unchanged.
 - 1> if the IE "New Inter-frequency cells" is received, for each cell, and in the same order as the cells appear in the IE:
 - 2> update the variable CELL_INFO_LIST as follows:
- 3> if the IE "Inter-frequency cell id" is received:
 - 4> store received cell information at this position in the Inter-frequency cell info list in the variable CELL_INFO_LIST, possibly overwriting any existing information in this position; and
 - 4> mark the position "occupied".
- 3> if the IE "Inter-frequency cell id" is not received:
 - 4> store the received cell information at the first vacant position in ascending order in the Inter-frequency cell info list in the variable CELL_INFO_LIST; and
 - 4> mark the position as "occupied".

If the IE "Inter-frequency cell info list" is received in a MEASUREMENT CONTROL message, the UE shall update the variable CELL_INFO_LIST accordingly and in the following order:

- 1> if the CHOICE "Inter-frequency cell removal" is received:
 - 2> if it has the value "Remove some inter-frequency cells", at the position indicated by the IE "Inter-frequency cell id":
- 3> clear the cell information stored in the variable CELL_INFO_LIST; and
- 3> mark the position "vacant".
 - 2> if it has the value "Remove all inter-frequency cells":

- 3> for each position referring to an inter-frequency cell in the variable CELL_INFO_LIST:
 - 4> clear the cell information stored in the variable CELL_INFO_LIST; and
 - 4> mark the position "vacant".
 - 2> if it has the value "Remove no inter-frequency cells":
- 3> leave the variable CELL_INFO_LIST unchanged.
 - 1> if the IE "New Inter-frequency cells" is received, for each cell, and in the same order as the cells appear in the IE:
 - 2> update the variable CELL_INFO_LIST as follows:
- 3> if the IE "Inter-frequency cell id" is received:
 - 4> store received cell information at this position in the Inter-frequency cell info list in the variable CELL_INFO_LIST, possibly overwriting any existing information in this position; and
 - 4> mark the position "occupied".
- 3> if the IE "Inter-frequency cell id" is not received:
 - 4> store the received cell information at the first vacant position in ascending order in the Inter-frequency cell info list in the variable CELL_INFO_LIST; and
 - 4> mark the position as "occupied".
 - 1> if the IE "Cells for measurement" is received, in the measurement configured by this message only:
 - 2> consider Inter-frequency cells whose cell information is stored at the position indicated by the IE "Inter-frequency cell id" in the variable CELL_INFO_LIST.
 - 1> if the IE "Cells for measurement" is not received, in the measurement configured by this message:
 - 2> consider all Inter-frequency cells whose cell information is stored in CELL_INFO_LIST.

If the IE "Inter-RAT cell info list" is received in System Information Block Type 11, the UE shall update the variable CELL_INFO_LIST accordingly and in the following order. The UE shall:

- 1> ignore the IE "Inter-RAT cell removal".
- 1> if the IE "New Inter-RAT cells" is received, for each cell, and in the same order as the cells appear in the IE:
 - 2> if the IE "Radio Access Technology" is set to "None":
- 3> ignore the cell.
 - 2> otherwise:
- 3> update the variable CELL_INFO_LIST as follows:
 - 4> if the IE "Inter-RAT cell id" is received:
 - 5> store received cell information at this position in the Inter-RAT cell info list in the variable CELL_INFO_LIST, possibly overwriting any existing information in this position; and
 - 5> mark the position "occupied".
 - 4> if the IE "Inter-RAT cell id" is not received:
 - 5> store the received cell information at the first vacant position in ascending order in the Inter-RAT cell info list in the variable CELL_INFO_LIST; and
 - 5> mark the position as "occupied".
 - 1> if the IE "Cells for measurement" is received:

2> ignore the IE.

If the IE "Inter-RAT cell info list" is received in System Information Block Type 12, the UE shall update the variable CELL_INFO_LIST accordingly and in the following order. The UE shall:

- 1> if the IE "Inter-RAT cell removal" is received:
 - 2> if it has the value "Remove some inter-RAT cells", at the position indicated by the IE "Inter-RAT cell id":
- 3> clear the cell information stored in the variable CELL_INFO_LIST; and
- 3> mark the position "vacant".
 - 2> if it has the value "Remove all inter-RAT cells":
- 3> for each position referring to an inter-RAT cell in the variable CELL_INFO_LIST:
 - 4> clear the cell information stored in the variable CELL_INFO_LIST; and
 - 4> mark the position "vacant".
 - 2> if it has the value "Remove no inter-RAT cells":
- 3> leave the variable CELL_INFO_LIST unchanged.
 - 1> if the IE "New Inter-RAT cells" is received, for each cell, and in the same order as the cells appear in the IE:
 - 2> if the IE "Radio Access Technology" is set to "None":
- 3> ignore the cell.
 - 2> otherwise:
- 3> update the variable CELL_INFO_LIST as follows:
 - 4> if the IE "Inter-RAT cell id" is received:
 - 5> store received cell information at this position in the Inter-RAT cell info list in the variable CELL_INFO_LIST, possibly overwriting any existing information in this position; and
 - 5> mark the position "occupied".
 - 4> if the IE "Inter-RAT cell id" is not received:
 - 5> store the received cell information at the first vacant position in ascending order in the Inter-RAT cell info list in the variable CELL_INFO_LIST; and
 - 5> mark the position as "occupied".
 - 1> if the IE "Cells for measurement" is received:
 - 2> ignore the IE.

If the IE "Inter-RAT cell info list" is received in a MEASUREMENT CONTROL message, the UE shall update the variable CELL_INFO_LIST accordingly and in the following order. The UE shall:

- 1> if the IE "Inter-RAT cell removal" is received:
 - 2> if it has the value "Remove some inter-RAT cells", at the position indicated by the IE "Inter-RAT cell id":
- 3> clear the cell information stored in the variable CELL_INFO_LIST; and
- 3> mark the position "vacant".
 - 2> if it has the value "Remove all inter-RAT cells":
- 3> for each position referring to an inter RAT cell in the variable CELL_INFO_LIST:
 - 4> clear the cell information stored in the variable CELL_INFO_LIST; and

- 4> mark the position "vacant".
- 2> if it has the value "Remove no inter-RAT cells":
- 3> leave the variable CELL_INFO_LIST unchanged.
 - 1> if the IE "New Inter-RAT cells" is received, for each cell, and in the same order as the cells appear in the IE:
 - 2> if the IE "Radio Access Technology" is set to "None":
- 3> ignore the cell.
 - 2> otherwise:
- 3> update the variable CELL_INFO_LIST as follows:
 - 4> if the IE "Inter-RAT cell id" is received:
 - 5> store received cell information at this position in the Inter-RAT cell info list in the variable CELL_INFO_LIST, possibly overwriting any existing information in this position; and
 - 5> mark the position "occupied".
 - 4> if the IE "Inter-RAT cell id" is not received:
 - 5> store the received cell information at the first vacant position in ascending order in the Inter-RAT cell info list in the variable CELL_INFO_LIST; and
 - 5> mark the position as "occupied".
 - 1> if the IE "Cells for measurement" is received, in the measurement configured by this message only:
 - 2> consider Inter-RAT cells whose cell information is stored at the position indicated by the IE "Inter-RAT cell id" in the variable CELL_INFO_LIST.
 - 1> if the IE "Cells for measurement" is not received, in the measurement configured by this message:
 - 2> consider all Inter-RAT cells whose cell information is stored in CELL_INFO_LIST.
 - 1> if the IE "Cell selection and re-selection info for SIB11/12" is present:
 - 2> ignore the IE.

8.6.7.4 Intra-frequency measurement quantity

If the IE "Intra-frequency measurement quantity" is received in a MEASUREMENT CONTROL message, the UE shall:

- 1> if the IE "Measurement quantity" is set to "pathloss"; and
- 1> for any intra-frequency cell indicated by the IE "Cells for measurement", the IE "Primary CPICH Tx power" in FDD or the IE "Primary CCPCH TX Power" in TDD in the intra frequency cell info list in the variable CELL_INFO_LIST is not present:
 - 2> set the variable CONFIGURATION_INCOMPLETE to TRUE.
- 1> else:
 - 2> configure the measurement quantity accordingly.

8.6.7.5 Inter-RAT measurement quantity

If the IE "Inter-RAT measurement quantity" is received in a MEASUREMENT CONTROL message and CHOICE system is GSM, the UE shall:

- 1> if IE "BSIC verification required" is set to "required", for cells that match any of the BCCH ARFCN and BSIC combinations in the list of inter-RAT cells that the UE has received in IE "Inter-RAT cell info list", and that has a "verified" BSIC:
 - 2> report measurement quantities according to IE "inter-RAT reporting quantity" taking into account the restrictions defined in subclause 8.6.7.6;
 - 2> trigger inter-RAT events according to IE "inter-RAT measurement reporting criteria"; and
 - 2> perform event evaluation for event-triggered reporting after BSIC has been verified for a GSM cell as defined in [19]; and
 - 2> trigger periodical reports according to the given "Reporting interval"; and
 - 2> when a periodical measurement report is triggered, include only BSIC verified GSM cells in the IE "Inter-RAT measured results list"; and
- 3> indicate verified BSIC for a GSM cell in the IE "Inter-RAT measured results list" as defined in subclause 8.6.7.6.
 - 2> when an event triggered measurement report is triggered, include only BSIC verified GSM cells in the IE "Inter-RAT measured results list"; and
- 3> indicate verified BSIC for a GSM cell in the IE "Inter-RAT measured results list" as defined in subclause 8.6.7.6.
 - 1> if IE "BSIC verification required" is set to "not required", for cells that match any of the BCCH ARFCN in the list of inter-RAT cells that the UE has received in IE "Inter-RAT cell info list", regardless if the BSIC is "verified" or "non-verified":
 - 2> report measurement quantities according to IE "inter-RAT reporting quantity";
 - 2> trigger inter-RAT events according to IE "inter-RAT measurement reporting criteria";
 - 2> when an event triggered or periodical measurement report is triggered, include GSM cells in the IE "Inter-RAT measured results list" regardless of whether the BSIC of the GSM cell has been verified or not; and
- 3> for any GSM cell that has not been verified, indicate non-verified BSIC for a GSM cell in the "Inter-RAT measured results list" IE as defined in subclause 8.6.7.6.
- 3> for any GSM cell that has been verified, indicate verified BSIC for a GSM cell in the "Inter-RAT measured results list" IE as defined in subclause 8.6.7.6.
 - 1> if the IE "Measurement quantity" is set to "pathloss":
 - 2> set the variable CONFIGURATION_INCOMPLETE to TRUE.
 - NOTE: The requirements for a cell to be considered "verified" or "non-verified" can be found in [19].

8.6.7.6 Inter-RAT reporting quantity

If the IE "Inter-RAT reporting quantity" is received by the UE, the UE shall:

1> store the content of the IE to the variable MEASUREMENT_IDENTITY.

If the IE "Inter-RAT measurement quantity" is received and CHOICE system is GSM, the UE shall check each quantity in the GSM choice. The UE shall include measured results in MEASUREMENT REPORT as specified in the IE "Inter-RAT reporting quantity" with the following restrictions:

- 1> if the UE has not confirmed the BSIC of the measured cell:
 - 2> if no compressed mode pattern sequence specified with measurement purpose "Initial BSIC identification" is active and according to its capabilities the UE requires compressed mode to measure this, the UE is not required to include the "inter-RAT cell id" nor "Observed time difference to GSM cell" in the IE "Inter-RAT measured results list", when a MEASUREMENT REPORT is triggered.
- 1> if the UE has confirmed the BSIC of the measured cell, then:

- 2> if no compressed mode pattern sequence specified with measurement purpose "Initial BSIC identification" nor "BSIC re-confirmation" is active and according to its capabilities the UE requires compressed mode to measure this, the UE is not required to include the "inter-RAT cell id" nor "Observed time difference to GSM cell" in the IE "Inter-RAT measured results", when a MEASUREMENT REPORT is triggered. If no compressed mode pattern sequence with measurement purpose "GSM carrier RSSI measurements" is active and according to its capabilities the UE requires compressed mode to measure this, the UE may include "inter-RAT cell id" or "Observed time difference to GSM cell" in MEASUMENT REPORT without "GSM carrier RSSI" even if it is defined in the IE "Inter-RAT reporting quantity".
- 1> if the IE "UTRAN estimated quality" is set to "TRUE":
 - 2> ignore that IE.
- 1> if IE "Observed time difference to GSM cell Reporting indicator " is set to "TRUE":
 - 2> include optional IE "Observed time difference to GSM cell" with the value set to the time difference to that GSM cell for the GSM cells that have a BSIC that is "verified", and that match any of the BCCH ARFCN and BSIC combinations in the list of inter-RAT cells that the UE has received in IE "Inter-RAT cell info list". Observed time difference to GSM cells with "non-verified" BSIC shall not be included.
- 1> if IE "GSM Carrier RSSI" is set to "TRUE":
 - 2> include optional IE "GSM Carrier RSSI" with a value set to the measured RXLEV to that GSM cell in IE "Inter-RAT measured results list". If no compressed mode pattern sequence specified with measurement purpose "GSM carrier RSSI measurements" is active and according to its capabilities the UE requires compressed mode to measure this, the UE is not required to include the "GSM carrier RSSI" in the IE " Inter-RAT measured results list ", when a MEASUREMENT REPORT is triggered.
- 1> if the BSIC of reported GSM cell is "verified":
 - 2> set the CHOICE BSIC to "Verified BSIC" and IE "inter-RAT cell id" to the value that GSM cell had in the IE "Inter-RAT cell info list".
- 1> if the BSIC of reported GSM cell is "non-verified":
 - 2> set the CHOICE BSIC to "Non verified BSIC" and the IE "BCCH ARFCN" to the value of that GSM cells ARFCN.

The requirements for a cell to be considered "verified" or "non-verified" can be found in [19].

8.6.7.7 Cell Reporting Quantities

If the IE "Cell Reporting Quantities" is received by the UE, the UE shall store the content of the IE "Cell Reporting Quantities" to the variable MEASUREMENT_IDENTITY.

The UE shall include measured results in MEASUREMENT REPORT as specified in the IE "Cell Reporting Quantities", except for the following cases:

If the IE "Cell Identity" is set to TRUE, the UE shall in this version of the specification:

1> treat the IE as if the IE "Cell Identity" is set to FALSE.

If the IE "Cell synchronisation information reporting indicator" is set to TRUE, the UE shall:

- 1> include the IE "Cell synchronisation information" in MEASUREMENT REPORT as specified in the IE "Cell Reporting Quantities":
 - 2> if the measurement is performed on another frequency; or
 - 2> if the IE "Read SFN indicator" included in the IE "Cell info" of the measured cell is set to FALSE:
- 3> the UE may omit the information group "COUNT-C-SFN frame difference" in the IE "Cell synchronisation information".
 - 2> if the measurement is performed on the same frequency and no RLC Transparent Mode COUNT-C exists in the UE:

- 3> set the IE "COUNT-C-SFN high" to 0.
 - 2> otherwise:
- 3> include the information group "COUNT-C-SFN frame difference" with IE "COUNT-C-SFN high" set to:

COUNT-C-SFN high = (((SFN - (COUNT-C mod 4096)) mod 4096) div 256) * 256;

- 3> if RLC Transparent Mode COUNT-Cs exist in both CN domains:
 - 4> use the COUNT-C of CS domain in this measurement.

If the IE "Proposed TGSN Reporting required" is set to TRUE, the UE shall:

- 1> if compressed mode was used to monitor a TDD cell and the variable TGSN_REPORTED is set to FALSE:
 - 2> report the IE "Proposed TGSN" indicating the TGSN that suits best to the measured cell;
 - 2> set the variable TGSN REPORTED to TRUE.
- 1> otherwise
 - 2> omit the IE "Proposed TGSN".

8.6.7.8 Periodical Reporting Criteria

If the IE "Periodical Reporting Criteria" is received by the UE, the UE shall:

1> store the contents of the IE "Amount of Reporting" and IE "Reporting interval" in the variable MEASUREMENT_IDENTITY.

For the first MEASUREMENT REPORT message, the UE shall:

1> send the MEASUREMENT REPORT as soon as all requested reporting quantities are available according to the requirements and the measurement capabilities set in [19] and [20] for at least one measurement object stored in the variable MEASUREMENT_IDENTITY, but never later than one reporting interval after measurement initiation.

Following the first MEASUREMENT REPORT message, the UE shall:

1> send a MEASUREMENT REPORT message one reporting interval after the previous MEASUREMENT REPORT message;

The first and subsequent periodic MEASUREMENT REPORT messages shall only include measured results for reporting quantities that are available according to the requirements and the measurement capabilities set in [19] and [20] i.e. if no measured results are available and the measurement type is not UE positioning, the IE "Measured Results" shall not be included in the MEASUREMENT REPORT message. If no measured results are available and the measurement type is UE positioning, the UE shall include the IE "Measured Results" in the MEASUREMENT REPORT message in order to include the IE "UE positioning error" as specified in 8.6.7.19a and 8.6.7.19b.

After the UE has sent a total number of MEASUREMENT REPORT messages, which equal the value indicated in the IE "Amount of reporting", the UE shall:

- 1> terminate measurement reporting; and
- 1> delete all measurement information linked with the "Measurement identity" of the ongoing measurement from the variable MEASUREMENT IDENTITY.

If according to subclause 8.6.7.19.1a or 8.6.7.19.1b, a UE configured with a UE positioning measurement is unable to report the requested measurement results due to missing GPS assistance data and sends a MEASUREMENT REPORT containing the IE "UE positioning error" and the IE "Error reason" is set to "Assistance Data Missing", then this is not counted in the total number of MEASUREMENT REPORT messages sent.

8.6.7.9 Reporting Cell Status

If the IE "Reporting Cell Status" is received, the UE shall set the IE "Measured Results" in MEASUREMENT REPORT as follows. The UE shall:

- 1> for intra-frequency measurement and inter-frequency measurement:
 - 2> include the IE "Cell Measured Results" for cells (excluding cells of another RAT) that satisfy the condition (such as "Report cells within active set") specified in the IE "Reporting Cell Status", in descending order by the measurement quantity.
 - 2> the maximum number of the IE "Cell Measured Results" to be included in the IE "Measured Results" per reported frequency is the number specified in the IE "Reporting Cell Status".
- 1> for periodic inter-frequency measurement:
 - 2> include in the IE "Inter-frequency measured results list" the measured results for all non-used frequencies.
- 1> for inter-RAT measurement:
 - 2> include the measurement results for cells of other RAT (e.g., GSM) that satisfy the condition specified in the IE "Reporting Cell Status", in descending order by the measurement quantity.
 - 2> the maximum number of the IE "Measured GSM Cells" to be included in the IE "Measured Results" is the number specified in the IE "Reporting Cell Status".

If the IE "Reporting Cell Status" is not received for intra-frequency, inter-frequency measurement, or inter-RAT measurement, the UE shall:

- 1> for intra-frequency measurement, inter-frequency measurement and inter-RAT measurement:
 - 2> exclude the IE "Measured Results" in MEASUREMENT REPORT.

NOTE: The IE "Reporting Cell Status" within "Event Criteria List" defines whether "Cell Measured Results" is present for event-based reporting.

The IE "Reporting Cell Status" is not included in System Information Block 11/12 for periodic intra-frequency measurements. In this case the UE shall assume the default values "Report cells within active set and/or monitored set on used frequency" and "6".

8.6.7.10 Traffic Volume Measurement

If the IE "Traffic Volume Measurement" is received by the UE, the UE shall:

1> store the content of the IE to the variable MEASUREMENT_IDENTITY.

If IE "Traffic volume measurement" is received by the UE in a MEASUREMENT CONTROL message, where IE "measurement command" has the value "setup", and if the IE "traffic volume reporting quantity" is included, the UE shall:

- 1> if the parameter "Average of RLC Buffer Payload for each RB" or the parameter "Variance of RLC Buffer payload for each RB" is set to "TRUE":
 - 2> if the IE "Traffic volume measurement quantity" is not included:
- 3> set the variable CONFIGURATION_INCOMPLETE to TRUE.
 - 2> if the IE "Traffic volume measurement quantity" is included:
- 3> if the parameter "time interval to take an average or a variance" is not included:
 - 4> set the variable CONFIGURATION INCOMPLETE to TRUE.

If IE "Traffic volume measurement" is received by the UE in a MEASUREMENT CONTROL message, where IE "measurement command" has the value "setup", but IE "Traffic volume reporting quantity" or is not received, the UE shall:

1> set the variable CONFIGURATION_INCOMPLETE to TRUE.

8.6.7.11 Traffic Volume Measurement Reporting Criteria

If the IE "Traffic Volume Measurement Reporting Criteria" is received by the UE, the UE shall:

- 1> if the IE "Parameters sent for each transport channel" is absent:
 - 2> set the variable PROTOCOL_ERROR_REJECT to TRUE;
 - 2> set the IE "Protocol error cause" in the variable PROTOCOL_ERROR_INFORMATION to "Information element missing".
- 1> for each IE "Parameters sent for each transport channel":
 - 2> if the IE "Parameters required for each Event" is absent:
- 3> set the variable CONFIGURATION_INCOMPLETE to TRUE.

8.6.7.12 FACH measurement occasion info

IE "FACH measurement occasion info" is used to control UE measurement activities in inter-frequency and inter-RAT cells in CELL_FACH state.

If IE "FACH measurement occasion info" is received, UE shall, when in CELL_FACH state:

- 1> if IE "FACH Measurement occasion cycle length coefficient" is included:
 - 2> if, according to its measurement capabilities, UE is not able to perform some of the indicated measurements in this IE simultaneously as receiving the SCCPCH of serving cell:
- 3> perform those measurements during FACH measurement occasions, see subclause 8.5.11.
 - 2> if, according to its measurement capabilities, UE is able to perform some of the indicated measurements in this IE simultaneously as receiving the SCCPCH of serving cell:
- 3> UE may perform measurements also on other occasions.
 - 2> if, according to its measurement capabilities, UE is able to perform the measurements and indicated in this IE simultaneously as receiving the SCCPCH of serving cell:
- 3> perform the measurements simultaneously as receiving the SCCPCH of serving cell.
 - 1> if IE "FACH Measurement occasion cycle length coefficient" is not included:
 - 2> perform those indicated measurements indicated in this IE that UE, according to its measurement capabilities, is able to perform simultaneously as receiving the SCCPCH of serving cell.
 - 1> if IE "Inter-frequency FDD measurement indicator" is set to TRUE:
 - 2> perform measurements and evaluate cell re-selection criteria according to [4] on inter-frequency FDD cells listed in IE "Measurement control system information" in "System Information Block type 11" or "System Information Block type 12".
 - 1> if IE "Inter-frequency FDD measurement indicator" is set to FALSE:
 - 2> neither perform measurements nor evaluate cell re-selection criteria on inter-frequency FDD cells.
 - 1> if IE "Inter-frequency TDD measurement indicator" is set to TRUE:
 - 2> perform measurements and evaluate cell re-selection criteria according to [4] on inter-frequency TDD cells listed in IE "Measurement control system information" in "System Information Block type 11" or "System Information Block type 12".
 - 1> if IE "Inter-frequency TDD measurement indicator" is set to FALSE:

- 2> neither perform measurements nor evaluate cell re-selection criteria on inter-frequency TDD cells.
- 1> if IE "Inter-RAT measurement indicators" is included:
 - 2> perform measurements and evaluate cell re-selection criteria according to [4] on those cells of listed Inter-RAT types that are present in IE "Measurement control system information" in "System Information Block type 11" or "System Information Block type 12".

8.6.7.13 Measurement Reporting Mode

If IE "Measurement Reporting Mode" is received by the UE, the UE shall:

- 1> store the contents of the IE "Measurement Report Transfer Mode" in the variable MEASUREMENT_IDENTITY;
- 1> use the indicated RLC mode when sending MEASUREMENT REPORT message(s) related to this measurement;
- 1> ignore IE "Periodical Reporting / Event Trigger Reporting Mode".
- If IE "Measurement Reporting Mode" is not received by the UE in MEASUREMENT CONTROL message, where IE "measurement command" has the value "setup", the UE shall:
 - 1> clear all stored measurement control information related associated to this measurement identity in variable MEASUREMENT_IDENTITY;
 - 1> set the variable CONFIGURATION_INCOMPLETE to TRUE.

8.6.7.14 Inter-frequency measurement

If the Inter-frequency cell info list, included in the variable CELL_INFO_LIST, includes a number (M) of frequencies that is larger than the number (N) considered in a UE performance requirement defined in [19] and [20]:

- 1> the UE shall:
 - 2> meet this performance requirement on the first relevant (N) frequencies, according to the order defined by the position of the frequencies in the Inter-frequency cell info list, included in the variable CELL INFO LIST.
- 1> the UE may:
 - 2> ignore the remaining (M-N) frequencies.
- If IE "Inter-frequency measurement" is received by the UE in a MEASUREMENT CONTROL message, where IE "measurement command" has the value "setup", but IE "Inter-frequency measurement quantity", IE "Inter-frequency reporting quantity" or IE "parameters required for each event" (given "CHOICE Report criteria" is set to "inter-frequency measurement reporting criteria") is not received, the UE shall:
 - 1> clear all stored measurement control information related associated to this measurement identity in variable MEASUREMENT_IDENTITY;
 - 1> set the variable CONFIGURATION INCOMPLETE to TRUE.
- If IE "Inter-frequency measurement" is received by the UE in a MEASUREMENT CONTROL message, where IE "measurement command" has the value "modify":
 - 1> if CHOICE "Report criteria" in IE "Inter-frequency measurement" is set to "intra-frequency reporting criteria" and IE "parameters required for each event" is present:
 - 2> the UE behaviour is unspecified.
- If IE "Inter-frequency measurement" is received by the UE in a MEASUREMENT CONTROL message, where IE "measurement command" has the value "setup" and CHOICE "Report criteria" is set to "intra-frequency reporting criteria" in IE "Inter-frequency measurement":
 - 1> the UE behaviour is unspecified.

In the case of an inter-frequency measurement for FDD, the UE shall:

- 1> if IE "Inter-frequency measurement" is received by the UE in a MEASUREMENT CONTROL message, where IE "measurement command" has the value "setup", if an inter-frequency event is configured that is different from event 2d or 2f, and if the IE "Inter-frequency SET UPDATE" is not received in that same message:
 - 2> set the variable CONFIGURATION_INCOMPLETE to TRUE.

If IE "Inter-frequency measurement" is received by the UE in a MEASUREMENT CONTROL message:

- 1> if CHOICE "Report criteria" is set to "inter-frequency measurement reporting criteria" and CHOICE "reporting criteria" in "inter-frequency measurement quantity" is not set to "inter-frequency reporting criteria"; or
- 1> if CHOICE "Report criteria" is set to "intra-frequency measurement reporting criteria" and CHOICE "reporting criteria" in "inter-frequency measurement quantity" is not set to "intra-frequency reporting criteria":
 - 2> the UE behaviour is not specified.

If the variable CONFIGURATION_INCOMPLETE is set to TRUE, the UE shall:

1> act as described in subclause 8.4.1.4a.

8.6.7.15 Inter-RAT measurement

If the Inter-RAT cell info list, included in the variable CELL_INFO_LIST, includes a number (M) of frequencies that is larger than the number (N) considered in a UE performance requirement defined in [19] and [20]:

- 1> the UE shall:
 - 2> meet this performance requirement on the first relevant (N) frequencies, according to the order defined by the position of the frequencies in the Inter-RAT cell info list, included in the variable CELL_INFO_LIST.
- 1> the UE may:
 - 2> ignore the remaining (M-N) frequencies.

If IE "Inter-RAT measurement" is received by the UE in a MEASUREMENT CONTROL message, where IE "measurement command" has the value "setup", but IE "Inter-RAT measurement quantity", IE "Inter-RAT reporting quantity" or "parameters required for each event" (given "CHOICE Report criteria" is set to "inter-RAT measurement reporting criteria") is not received, the UE shall:

- 1> clear all stored measurement control information related associated to this measurement identity in variable MEASUREMENT IDENTITY;
- 1> set the variable CONFIGURATION_INCOMPLETE to TRUE.

8.6.7.16 Intra-frequency measurement

If IE "Intra-frequency measurement" is received by the UE in a MEASUREMENT CONTROL message, where IE "measurement command" has the value "setup", but IE "Intra-frequency measurement quantity", IE "Intra-frequency reporting quantity", "CHOICE Report criteria" or "parameters required for each event" (given "CHOICE report criteria" is set to "intra-frequency measurement reporting criteria") is not received, the UE shall:

- 1> clear all stored measurement control information related associated to this measurement identity in variable MEASUREMENT IDENTITY;
- 1> set the variable CONFIGURATION_INCOMPLETE to TRUE.

In case of 1a or 1e event-triggered reporting:

- 1> if the IE "Intra-frequency measurement quantity" is set to "pathloss", the UE shall:
 - 2> if detected set cells are indicated as possibly triggering the event within the IEs "Triggering condition 2":
- 3> set the variable CONFIGURATION_INCOMPLETE to TRUE.

8.6.7.17 Quality measurement

If IE "Quality measurement" is received by the UE in a MEASUREMENT CONTROL message, where IE "measurement command" has the value "setup", but IE "Quality reporting quantity" is not received, the UE shall:

- 1> clear all stored measurement control information related associated to this measurement identity in variable MEASUREMENT IDENTITY;
- 1> set the variable CONFIGURATION_INCOMPLETE to TRUE.

8.6.7.18 UE internal measurement

If IE "UE internal measurement" is received by the UE in a MEASUREMENT CONTROL message, where IE "measurement command" has the value "setup", but IE "UE internal measurement quantity", IE "UE internal reporting quantity" or "parameters sent for each UE internal measurement event" (given "CHOICE report criteria" is set to "UE internal measurement reporting criteria") is not received, the UE shall:

- 1> clear all stored measurement control information related associated to this measurement identity in variable MEASUREMENT_IDENTITY;
- 1> set the variable CONFIGURATION_INCOMPLETE to TRUE.

8.6.7.18a Void

8.6.7.19 UE positioning

8.6.7.19.0 UE positioning reporting criteria

If IE "UE positioning reporting criteria" is included, the UE shall:

- 1> perform the necessary measurements and evaluate the event in the interval indicated in IE "Measurement Interval":
- 1> if IE "Event ID" is set to "7a" and if IE "Report first fix" is set to TRUE:
 - 2> if the IE "Method Type" included in the variable MEASUREMENT_IDENTITY is set to "UE based":

3> act as specified in subclause 8.6.7.19.1b.

8.6.7.19.1 UE positioning reporting quantity

- 1> ignore IE "Multiple Sets";
- 1> ignore IE "Response Time";
- 1> if IE "Horizontal Accuracy" and/or IE "Vertical Accuracy" is included:
 - 2> should try to achieve the requested level(s) of positioning accuracy with 67% confidence.
- 1> if IE "Positioning Methods" is set to "Cell ID":
 - 2> act as specified in subclause 8.6.7.19.1a.
- 1> if the IE "Method Type" is set to "UE based":
 - 2> act as specified in subclause 8.6.7.19.1b.
- 1> if the IE "Method Type" is set to "UE assisted":
 - 2> act as specified in subclause 8.6.7.19.1a.

- 1> if the IE "Method Type" is set to "UE-assisted preferred but UE-based allowed" or "UE-based preferred but UE-assisted allowed":
 - 2> act either according to subclause 8.6.7.19.1a or 8.6.7.19.1b depending on the method type chosen by the UE.

If UE according to its capabilities supports Rx-Tx time difference type 2 measurement and if IE "Positioning Methods" is set to "Cell ID" and the IE "Measurement validity" stored in the variable MEASUREMENT_IDENTITY is other than "CELL_DCH", the UE shall:

- 1> set the variable CONFIGURATION_INCOMPLETE to TRUE, and
- 1> act as specified in subclause 8.4.1.4b.

The UE shall perform the following consistency check:

- 1> if UE, according to its capabilities, does not support UE-based OTDOA and if IE "Positioning Methods" is set to "OTDOA" and if IE "Method Type" is set to "UE-based":
 - 2> set the variable CONFIGURATION_INCOMPLETE to TRUE.
- 1> if UE, according to its capabilities, does not support UE-based GPS and if IE "Positioning Methods" is set to "GPS" and if IE "Method Type" is set to "UE-based":
 - 2> set the variable CONFIGURATION_INCOMPLETE to TRUE.
- 1> if UE, according to its capabilities, does not support UE-assisted GPS and if IE "Positioning Methods" is set to "GPS" and if IE "Method Type" is set to "UE-assisted":
 - 2> set the variable CONFIGURATION INCOMPLETE to TRUE.
- 1> if UE, according to its capabilities, does not support UE-based positioning and if IE "Positioning Methods" is set to "OTDOAorGPS" and if IE "Method Type" is set to "UE-based":
 - 2> set the variable CONFIGURATION_INCOMPLETE to TRUE.
- 1> if UE, according to its capabilities, does not support Rx-Tx time difference type 2 measurement and if IE "Positioning Methods" is set to "Cell ID":
 - 2> set the variable CONFIGURATION_INCOMPLETE to TRUE.
- 1> if UE, according to its capabilities, does not support UE GPS timing of cell frames measurement and if IE "GPS timing of Cell wanted" is set to TRUE:
 - 2> set the variable CONFIGURATION_INCOMPLETE to TRUE.

8.6.7.19.1a UE positioning reporting for UE assisted methods

- 1> when a measurement report is triggered:
 - 2> if the UE was able to perform measurements on at least one neighbour cell included in the variable UE_POSITIONING_OTDOA_DATA_UE_ASSISTED in case of OTDOA or one satellite included in the variable UE_POSITIONING_GPS_DATA in case of GPS positioning or one cell from the active set in case of CELL ID:
- 3> if the IE "Vertical Accuracy" is included:
 - 4> interpret the presence of this IE to indicate that the UTRAN desires to compute a 3-dimensional position estimate.
- 3> if the IE "Positioning Methods" is set to "GPS":
 - 4> include the IE "UE positioning GPS measured results" in the measurement report and set the contents of the IE as follows:
 - 5> if the UE supports the capability to provide the GPS timing of the cell frames measurement:

- 6> if the IE "GPS timing of Cell wanted" is set to TRUE:
 - 7> perform the UE GPS timing of cell frames measurement on the serving cell or on one cell of the active set.
 - 7> include the IE "Primary CPICH Info" for FDD or the IE "cell parameters id" for TDD; and
 - 7> include the IE "Reference SFN" and the IE "UE GPS timing of cell frames".
- 6> if the IE "GPS timing of Cell wanted" is set to FALSE:
 - 7> include the IE "GPS TOW msec".
- 5> if the UE does not support the capability to provide the GPS timing of the cell:
 - 6> include the IE "GPS TOW msec".
- 3> if the IE "Positioning Methods" is set to "OTDOA":
 - 4> include the IE "UE positioning OTDOA measured results" in the measurement report and set the contents of the IE as follows:
 - 5> set IE "SFN" to the SFN when the last measurement was performed;
 - 5> if the UE supports the capability to perform the Rx-Tx time difference type 2 measurement:
 - 6> if the UE is in CELL_DCH state:
 - 7> if the measured value is equal to "1279.9375":
 - 8> set the IE "Rx-Tx time difference type 2" in IE "UE positioning OTDOA measured results" for the reference cell to "1279.8750".
 - 7> otherwise:
 - 8> set the IE "Rx-Tx time difference type 2" in IE "UE positioning OTDOA measured results" for the reference cell to the measured value.
 - 7> include the IE group "Rx-Tx time difference type 2 info" for the reference cell and for each neighbour cell listed in variable UE_POSITIONING_OTDOA_DATA_UE_ASSISTED that belongs to the active set.
 - 5> if the UE does not support the capability to perform the Rx-Tx time difference type 2 measurement:
 - 6> set the IE "Rx-Tx time difference type 2" in IE "UE positioning OTDOA measured results" for the reference cell to value "1279.9375" to indicate that the measurement is not supported.
 - 4> include IE group "Neighbour" for all neighbour cells listed in variable UE_POSITIONING_OTDOA_DATA_UE_ASSISTED on which the SFN-SFN observed time difference type 2 measurement could be performed.
- 3> if IE "Positioning Methods" in the MEASUREMENT CONTROL message has been assigned to value "OTDOA or GPS":
 - 4> the UE may choose to either act as if IE "Positioning Methods" is set to "GPS" or "OTDOA" depending on the method chosen by the UE.
- 3> if the IE "Positioning Methods" is set to "CELL ID":
 - 4> if the UE supports the capability to perform the Rx-Tx time difference type 2 measurement; and
 - 4> if the UE is in CELL_DCH state:
 - 5> perform the Rx-Tx time difference type 2 measurement on the cells in the active set; and

- 5> report the measurement results back to the network in the MEASUREMENT REPORT by using IE "UE positioning OTDOA measured results" including measurements on the cells in the active set; and
- 5> report Rx-Tx time difference type 2 measurement of the reference cell (as designated by the UE); and
- 5> for all reported neighbour cells:
 - 6> report Rx-Tx time difference type 2 measurement; and
 - 6> set the IE "SFN-SFN observed time difference type 2" and all IEs within the corresponding IE "UE positioning OTDOA quality" in IE "UE positioning OTDOA measured results" to value "0".
- 2> if the UE is not able to report the requested measurement results:
- 3> include IE "UE positioning error" in the MEASUREMENT REPORT and set the contents of this IE as specified in subclause 8.6.7.19.5.
 - 1> if the UE is unable to report the requested measurement results due to missing GPS assistance data:
 - 2> the UE may at anytime send a measurement report containing the IE "UE positioning error" and set the contents of this IE as specified in subclause 8.6.7.19.5.
 - 2> after sending the measurement report, the UE shall not send another measurement report to request the same GPS assistance data for at least 20s. This requirement does not apply after release of the current RRC connection.

8.6.7.19.1b UE positioning reporting for UE based methods

- 1> when a measurement report is triggered:
 - 2> if the UE has been able to calculate a position after performing measurements on the cells included in the variable UE_POSITIONING_OTDOA_DATA_UE_BASED in case of OTDOA or the UE has been able to calculate a position in case of GPS positioning:
- 3> include IE "UE positioning Position Estimate Info" in the MEASUREMENT REPORT and set the contents of the IE as follows:
 - 4> if the UE supports the capability to perform the UE GPS timing of cell frames measurement:
 - 5> if the IE "GPS timing of Cell wanted" is set to TRUE:
- 6> perform the UE GPS timing of cell frames measurement on the serving cell or on one cell of the active set.
 - 6> include the IE "Primary CPICH Info" for FDD or the IE "cell parameters id" for TDD;
 - 6> include the SFN when the position was determined;
 - 6> include the IE "UE GPS timing of cell frames".
 - 5> if the IE "GPS timing of Cell wanted" is set to FALSE:
 - 6> include the IE "GPS TOW msec".
 - 4> if the UE does not support the capability to provide the GPS timing of the cell:
 - 5> include the IE "GPS TOW msec".
 - 4> if IE "Vertical Accuracy" has been included in IE "UE positioning reporting quantity":
 - 5> if the IE "Vertical Accuracy" has been assigned to value "0":

- 6> if the IE "Horizontal Accuracy" has been assigned a value "0":
 - 7> may include IE "Ellipsoid point with altitude".
- 6> if the IE "Horizontal Accuracy" has been assigned a value unequal to "0"; and
- 6> if the UE has been able to calculate a 3-dimensional position
 - 7> include IE "Ellipsoid point with altitude" or IE "Ellipsoid point with altitude and uncertainty ellipsoid" as the position estimate.
- 6> if the UE has not been able to calculate a 3-dimensional position:
 - 7> may act as if IE "Vertical Accuracy" was not included in IE "UE positioning reporting quantity".
- 5> if the IE "Vertical Accuracy" has been assigned to a value unequal to "0":
 - 6> if the UE has been able to calculate a 3-dimensional position:
 - 7> include IE "Ellipsoid point with altitude and uncertainty ellipsoid" as the position estimate.
 - 6> if the UE has not been able to calculate a 3-dimensional position:
 - 7> act as if IE "Vertical Accuracy" has not been included in IE "UE positioning reporting quantity".
- 4> if IE "Vertical Accuracy" has not been included in IE "UE positioning reporting quantity":
 - 5> if IE "Horizontal Accuracy" in IE "UE positioning reporting quantity" has been assigned to value "0":
 - 6> may include IE "Ellipsoid point".
 - 5> if IE "Horizontal Accuracy" in IE "UE positioning reporting quantity" has been assigned to a value unequal to 0:
 - 6> include either IE "Ellipsoid point with uncertainty circle" or IE "Ellipsoid point with uncertainty ellipse" or IE "Ellipsoid point with altitude and uncertainty ellipsoid" as the position estimate.
- 2> if the UE was not able to calculate a position:
- 3> include IE "UE positioning error" in the MEASUREMENT REPORT and set the contents of this IE as specified in subclause 8.6.7.19.5.
 - 1> if the UE is unable to calculate a position due to missing GPS assistance data:
- 2> the UE may at any time send a measurement report containing the IE "UE positioning error" and set the contents of this IE as specified in subclause 8.6.7.19.5;
- 2> after sending the measurement report, the UE shall not send another measurement report to request the same GPS assistance data for at least 20s. This requirement does not apply after release of the current RRC connection.

8.6.7.19.2 UE positioning OTDOA assistance data for UE-assisted

If IE "UE positioning OTDOA reference cell info for UE-assisted" is received in System Information Block type 15.4 or in the MEASUREMENT CONTROL message, the UE shall update the variable UE_POSITIONING_OTDOA_DATA_UE_ASSISTED accordingly. The UE shall:

1> store received cell information in the UE positioning reference cell info in the variable UE_POSITIONING_OTDOA_DATA_UE_ASSISTED, overwriting any existing information.

If IE "UE positioning OTDOA neighbour cell list for UE-assisted" is received in System Information Block type 15.4 or in the MEASUREMENT CONTROL message, the UE shall update the variable UE_POSITIONING_OTDOA_DATA_UE_ASSISTED accordingly. The UE shall:

1> store received cell information in the neighbour cell info list in the variable UE_POSITIONING_OTDOA_DATA_UE_ASSISTED, overwriting any existing information.

If, according to its capabilities, UE does not support IPDLs and if IE "IPDL parameters" is received for the reference or any of the neighbour cells, the UE shall:

- 1> ignore this IE.
- In 1.28 Mcps TDD, if the IE "IPDL parameters" is received and the UE supports IPDLs, the UE shall:
 - 1> ignore the IE IP_Slot;
 - 1> if the IE "IP_PCCPCH" is set to FALSE:
 - 2> configure the physical layer with IP_Sub to be first subframe according to [33].
 - 1> if the IE "IP_PCCPCH" is set to TRUE:
 - 2> configure the physical layer with IP_Sub to be second subframe according to [33].
 - 1> if the IE "IP_PCCPCH" is absent:
 - 2> configure the physical layer with IP_Sub to use both subframes according to [33].
- If IE "SFN offset validity" is set to FALSE, the UE shall:
 - 1> ignore the IE "SFN offset".

If IE "UE positioning measurement" is received in the MEASUREMENT CONTROL message, the UE shall also perform the following consistency checks:

- 1> if IE "Positioning Methods" is set to "OTDOA":
 - 2> if IE "UE positioning OTDOA reference cell info for UE-assisted" is not included and if UE positioning OTDOA reference cell info for UE-assisted in variable UE_POSITIONING_OTDOA_DATA_UE_ASSISTED is empty:
- 3> set the variable CONFIGURATION_INCOMPLETE to TRUE.
 - 1> if IE "Positioning Methods" is set to "OTDOA":
 - 2> if IE "UE positioning OTDOA neighbour cell list for UE-assisted" is not included and if less than two neighbour cells are stored in UE positioning OTDOA neighbour cell info list for UE-assisted in variable UE_POSITIONING_OTDOA_DATA_UE_ASSISTED:
- 3> set the variable CONFIGURATION_INCOMPLETE to TRUE.

8.6.7.19.2a UE positioning OTDOA assistance data for UE-based

- 1> if IE "UE positioning OTDOA reference cell info for UE-based" is received in System Information Block type 15.5 or in the MEASUREMENT CONTROL message or in the ASSISTANCE DATA DELIVERY:
 - 2> update the variable UE_POSITIONING_OTDOA_DATA_UE_BASED accordingly;
 - 2> store received cell information in the UE positioning reference cell info for UE-based in the variable UE_POSITIONING_OTDOA_DATA_UE_BASED, overwriting any existing information.
- 1> if IE "UE positioning OTDOA neighbour cell list for UE-based" is received in System Information Block type 15.5 or in the MEASUREMENT CONTROL message or in the ASSISTANCE DATA DELIVERY:
 - 2> update the variable UE_POSITIONING_OTDOA_DATA_UE_BASED accordingly;
 - 2> store received cell information in the neighbour cell info list for UE-based in the variable UE_POSITIONING_OTDOA_DATA_UE_BASED, overwriting any existing information.

- 1> if, according to its capabilities, UE does not support IPDLs and if IE "IPDL parameters" is received for the reference or any of the neighbour cells:
 - 2> ignore this IE.
- 1> in 1.28 Mcps TDD:
 - 2> if the IE "IPDL parameters" is received and the UE supports IPDLs:
- 3> ignore the IE IP_Slot;
- 3> if the IE "IP_PCCPCH" is set to FALSE:
 - 4> configure the physical layer with IP_Sub to be first subframe according to [33].
- 3> if the IE "IP_PCCPCH" is set to TRUE:
 - 4> configure the physical layer with IP_Sub to be second subframe according to [33].
- 3> if the IE "IP_PCCPCH" is absent:
 - 4> configure the physical layer with IP Sub to use both subframes according to [33].
 - 1> if IE "SFN offset validity" is set to FALSE:
 - 2> ignore the IE "SFN offset".
 - 1> if IE "UE positioning measurement" is received in the MEASUREMENT CONTROL message:
 - 2> also perform the following consistency checks:
- 3> if IE "Positioning Methods" is set to "OTDOA":
 - 4> if IE "UE positioning OTDOA reference cell info for UE-based" is not included and if UE positioning OTDOA reference cell info for UE-based in variable UE_POSITIONING_OTDOA_DATA_UE_BASED is empty:
 - 5> set the variable CONFIGURATION_INCOMPLETE to TRUE.
- 3> if IE "Positioning Methods" is set to "OTDOA":
 - 4> if IE "UE positioning OTDOA neighbour cell list for UE-based" is not included and if less than two neighbour cells are stored in UE positioning OTDOA neighbour cell info list for UE-based in variable UE_POSITIONING_OTDOA_DATA_UE_BASED:
 - 5> set the variable CONFIGURATION INCOMPLETE to TRUE.
 - 4> if IE "Method Type" is set to "UE based":
 - 5> if IE "UE positioning OTDOA reference cell info for UE-based" is included and if IE "Cell Position" for the reference cell is not included:
 - 6> set the variable CONFIGURATION_INCOMPLETE to TRUE.
 - 5> if the IE "UE positioning OTDOA neighbour cell list for UE-based" is included and if cell position of less than two neighbour cells of the cells included in this IE and stored in variable UE_POSITIONING_OTDOA_DATA_UE_BASED are different and if those cell positions are not different to the one of the reference cell stored in variable UE_POSITIONING_OTDOA_DATA_UE_BASED:
 - 6> set the variable CONFIGURATION_INCOMPLETE to TRUE.
 - 5> if the IE "UE positioning OTDOA neighbouring cell list for UE-based" is included and only two neighbour cells are included or stored in variable UE_POSITIONING_OTDOA_DATA_UE_BASED and if the IE "Round Trip Time" is neither included for the neighbour cells nor for the reference cell info:
 - 6> set the variable CONFIGURATION_INCOMPLETE to TRUE.

8.6.7.19.3 UE positioning GPS assistance data

The UE may receive GPS assistance data in System Information Block types 15, 15.1, 15.2, or 15.3, or in the ASSISTANCE DATA DELIVERY message, or in the MEASUREMENT CONTROL message.

8.6.7.19.3.1 UE positioning GPS acquisition assistance

If the IE "UE positioning GPS acquisition assistance" is included, the UE shall:

- 1> update the variable UE_POSITIONING_GPS_DATA as follows:
 - 2> delete all information currently stored in the IE "UE positioning GPS acquisition assistance" in the variable UE_POSITIONING_GPS_DATA;
 - 2> store the received acquisition assistance information in the IE "UE positioning GPS acquisition assistance" in the variable UE POSITIONING GPS DATA;
 - 2> store the IE "GPS TOW msec" in the IE "UE positioning GPS acquisition assistance" in variable UE_POSITIONING_GPS_DATA and use it as an estimate of the GPS Time-of-Week at the time of reception of the complete message containing the IE "GPS TOW msec";

NOTE: The UE does not need to apply any compensation on the GPS Time-of-Week.

- 1> if the IEs "SFN" and "UTRAN GPS timing of cell frames" are included:
 - 2> if the UE is able to utilise these IEs:
- 3> store these IEs in the IE "UE positioning GPS acquisition assistance" in variable UE_POSITIONING_GPS_DATA;
- 3> if the IE "Primary CPICH Info" for FDD or IE "cell parameters id" for TDD is not included:
 - 4> if the UE is not in CELL_DCH state:
 - 5> use IEs "SFN" and "UTRAN GPS timing of cell frames" to estimate the relationship between GPS time and radio interface timing of the NODE B transmission in the serving cell.
 - 4> if the UE is in CELL_DCH state:
 - 5> ignore IEs "SFN" and "UTRAN GPS timing of cell frames".
- 3> if the IE "Primary CPICH Info" for FDD or IE "cell parameters id" for TDD is also included:
 - 4> store this IE in the IE "UE positioning acquisition assistance" in variable UE_POSITIONING_GPS_DATA;
 - 4> use IEs "SFN" and "UTRAN GPS timing of cell frames" to estimate the relationship between GPS time and air-interface timing of the NODE B transmission in the cell indicated by "Primary CPICH info" or "cell parameters id".

8.6.7.19.3.2 UE positioning GPS Almanac

If the IE "UE positioning GPS Almanac" is included, the UE shall:

- 1> if the IE "SV Global Health" is included:
 - 1> store this IE in the IE "SV Global Health" in the IE "UE positioning GPS Almanac" in variable UE_POSITIONING_GPS_DATA.
- 1> for each satellite:
 - 2> store received GPS almanac information at the position indicated by the IE "Sat ID" in the IE "UE positioning GPS Almanac" in the variable UE_POSITIONING_GPS_DATA, possibly overwriting any existing information in this position.
 - 2> interpret IE "Data ID" as the Data ID field contained in the indicated subframe, word 3, most significant 2 bits, as defined by [12];

2> act on the rest of the IEs in a similar manner as specified in [12].

8.6.7.19.3.3 UE positioning D-GPS Corrections

If the IE "UE positioning GPS DGPS corrections" is included, the UE shall:

- 1> update the variable UE_POSITIONING_GPS_DATA as follows:
 - 2> delete all information currently stored in the IE "UE positioning GPS DGPS corrections" in the variable UE_POSITIONING_GPS_DATA;
 - 2> store the received DGPS corrections in the IE "UE positioning GPS DGPS corrections" in the variable UE_POSITIONING_GPS_DATA.
- 1> use IE "GPS TOW sec" to determine when the differential corrections were calculated;
- 1> use IE "Status/Health" to determine the status of the differential corrections.

8.6.7.19.3.3a UE positioning GPS Navigation Model

If the IE "UE positioning GPS Navigation Model" is included, for each satellite, the UE shall:

- 1> use IE "Satellite Status" to determine if an update of IE "UE positioning GPS Ephemeris and Clock Correction parameters" has been provided for the satellite indicated by the IE "SatID";
- 1> if an update has been provided for this satellite:
 - 2> act as specified in subclause 8.6.7.19.3.4.

8.6.7.19.3.4 UE positioning GPS Ephemeris and Clock Correction Parameters

If the IE "UE positioning GPS Ephemeris and Clock Correction parameters" is included, for each satellite, the UE shall:

- 1> update the variable UE_POSITIONING_GPS_DATA as follows:
 - 2> store this IE at the position indicated by the IE "Sat ID" in the IE "UE positioning GPS Navigation Model" in the variable UE_POSITIONING_GPS_DATA, possibly overwriting any existing information in this position.
- 1> act on these GPS ephemeris and clock correction parameters in a manner similar to that specified in [12].

8.6.7.19.3.5 UE positioning GPS ionospheric model

If IE "UE positioning GPS ionospheric model" is included, the UE shall:

- 1> store this IE in the IE "UE positioning GPS ionospheric model" in variable UE_POSITIONING_GPS_DATA;
- 1> act on these GPS ionospheric model parameters in a manner similar to that specified in [12].

8.6.7.19.3.6 UE positioning GPS real-time integrity

If this list of bad satellites is included, the UE shall:

- 1> update the variable UE_POSITIONING_GPS_DATA as follows:
 - 2> add the Sat IDs that are not yet included in the list of satellites in the IE "UE positioning GPS real time integrity" in the variable UE_POSITIONING_GPS_DATA;
 - 2> remove all Sat IDs in the list of satellites in the IE "UE positioning GPS real time integrity" in the variable UE POSITIONING GPS DATA that are not included in IE UE positioning GPS real time integrity.
- 1> consider the data associated with the satellites identified in the variable UE_POSITIONING_GPS_DATA as invalid.

8.6.7.19.3.7 UE positioning GPS reference time

If the IE "UE positioning GPS reference time" is included, the UE shall:

- 1> store the IE "GPS Week" in "UE positioning GPS reference time" in variable UE_POSITIONING_GPS_DATA and use it as the current GPS week;
- 1> store the IE "GPS TOW msec" in the IE "UE positioning GPS reference time" in variable UE_POSITIONING_GPS_DATA and use it as an estimate of the GPS Time-of-Week at the time of reception of the complete message containing the IE "GPS TOW msec";

NOTE: The UE does not need to apply any compensation on the GPS Time-of-Week.

- 1> if the IE "SFN" and IE "UTRAN GPS timing of cell frames" are included:
 - 2> if the UE is able to utilise the IEs:
- 3> store these IEs in the IE "UE positioning GPS reference time" in variable UE_POSITIONING_GPS_DATA;
- 3> if the IE "Primary CPICH Info" for FDD or IE "cell parameters id" for TDD is not included:
 - 4> if the UE is not in CELL_DCH state:
 - 5> use IEs "SFN" and "UTRAN GPS timing of cell frames" to estimate the relationship between GPS time and air-interface timing of the NODE B transmission in the serving cell.
 - 4> if the UE is in CELL_DCH state:
 - 5> ignore IEs "SFN" and "UTRAN GPS timing of cell frames".
- 3> if the IE "Primary CPICH Info" for FDD or IE "cell parameters id" for TDD is also included:
 - 4> store this IE in the IE "UE positioning GPS reference time" in variable UE_POSITIONING_GPS_DATA;
 - 4> use IEs "SFN" and "UTRAN GPS timing of cell frames" to estimate the relationship between GPS time and air-interface timing of the NODE B transmission in the cell indicated by "Primary CPICH info" or "cell parameters id".
 - 1> if the IE "SFN-TOW Uncertainty" is included:
 - 2> store this IE in the IE "UE positioning GPS reference time" in variable UE_POSITIONING_GPS_DATA and use it to determine if the relationship between GPS time and air-interface timing of the NODE B transmission is known to within at least 10ms.
 - 1> if the IE "T_{UTRAN-GPS} drift rate" is included:
 - 2> store this IE in the IE "UE positioning GPS reference time" in variable UE_POSITIONING_GPS_DATA; and
 - 2> may use it as an estimate of the drift rate of the NODE B clock relative to GPS time.
 - 1> if the IE "GPS TOW Assist" is included:
 - 2> for each satellite:
- 3> delete all information currently stored in the IE "GPS TOW Assist" in the IE "UE positioning GPS reference time" in the variable UE_POSITIONING_GPS_DATA;
- 3> store the received GPS TOW Assist information in the IE "UE positioning GPS reference time" in the variable UE_POSITIONING_GPS_DATA.

8.6.7.19.3.8 UE positioning GPS reference UE position

If the IE "UE positioning GPS reference UE position" is included, the UE shall:

- 1> store this IE in the IE "UE positioning GPS reference UE position" in variable UE_POSITIONING_GPS_DATA; and
- 1> use it as a priori knowledge of the approximate location of the UE.

8.6.7.19.3.9 UE positioning UTC model

If the IE "UE positioning GPS UTC model" is included, the UE shall:

1> store this IE in the IE "UE positioning GPS UTC model" in variable UE_POSITIONING_GPS_DATA.

8.6.7.19.4 UE positioning Ciphering info

The UE shall:

- 1> if deciphering information is received from higher layers for deciphering of GPS assistance data broadcast on system information:
 - 2> store the current key in IE "Current deciphering key" in variable UE_POSITIONING_GPS_DATA;
 - 2> store the next key in IE "Next deciphering key" in variable UE_POSITIONING_GPS_DATA;
 - 2> store the ciphering key flag in UE_POSITIONING_GPS_DATA.
- 1> if deciphering information is received from higher layers for deciphering of OTDOA assistance data broadcast on system information:
 - 2> store the current key in IE "Current deciphering key" in variable UE_POSITIONING_OTDOA_DATA_UE_BASED;
 - 2> store the next key in IE "Next deciphering key" in variable UE_POSITIONING_OTDOA_DATA_UE_BASED;
 - 2> store the ciphering key flag in UE_POSITIONING_OTDOA_DATA_UE_BASED.
- 1> if the IE "GPS Data ciphering info" is included in System Information Block type 15:
 - 2> select one of the two deciphering keys received and stored it in UE_POSITIONING_GPS_DATA according to the following:
- 3> if the value of the received IE "Ciphering Key Flag" is the same as the value of the IE "Ciphering Key Flag" stored in the variable UE_POSITIONING_GPS_DATA:
 - 4> select the current deciphering key.
- 3> if the value of the received IE "Ciphering Key Flag" is different from the value of the IE "Ciphering Key Flag" stored in the variable UE_POSITIONING_GPS_DATA:
 - 4> select the next deciphering key.
 - 2> store the received IE in the variable UE_POSITIONING_GPS_DATA;
 - 2> use the selected deciphering key to decipher the broadcast UE positioning GPS information contained within the System Information Block types 15.1, 15.2 and 15.3.
 - 1> if the IE "OTDOA positioning ciphering info" is included in System Information Block type 15.4:
 - 2> select one of the two deciphering keys and stored it in UE_POSITIONING_OTDOA_DATA_UE_BASED according to the following:
- 3> if the value of the received IE "Ciphering Key Flag" is the same as the value of the IE "Ciphering Key Flag" stored in the variable UE_POSITIONING_OTDOA_DATA_UE_BASED:
 - 4> select the current deciphering key.

- 3> if the value of the received IE "Ciphering Key Flag" is different from the value of the IE "Ciphering Key Flag" stored in the variable UE_POSITIONING_OTDOA_DATA_UE_BASED:
 - 4> select the next deciphering key.
 - 2> store the received IE in the variable UE_POSITIONING_OTDOA_DATA_UE_BASED;
 - 2> use the selected deciphering key to decipher the IE "OTDOA assistance data" included in the System Information Block types 15.4.

8.6.7.19.5 UE positioning Error

The UE shall set the contents of the IE "UE positioning Error" as follows:

- 1> if the IE "Positioning Methods" in IE "UE positioning reporting quantity" has been assigned to value "OTDOA" and no neighbour cells could be received,
 - 2> set IE "Error reason" to "Not Enough OTDOA Cells";
- 1> if the IE "Positioning Methods" in IE "UE positioning reporting quantity" has been assigned to value "GPS":
 - 2> if there were not enough GPS satellites to be received:
- 3> set IE "Error reason" to "Not Enough GPS Satellites".
 - 2> if some GPS assistance data was missing:
- 3> set IE "Error reason" to "Assistance Data Missing"; and
- 3> if the IE ""Additional Assistance Data Request" included in the IE "UE positioning reporting quantity" stored in the variable MEASUREMENT_IDENTITY is set to TRUE:
 - 4> include the IE "GPS Additional Assistance Data Request".
- 3> if the IE "Additional Assistance Data Request" included in the IE "UE positioning reporting quantity" stored in the variable MEASUREMENT_IDENTITY is set to FALSE:
 - 4> not include the IE "GPS Additional Assistance Data Request", and use the assistance data available for doing a positioning estimate.
 - 2> if the UE was not able to read the SFN of the reference cell included in the IE "UE positioning GPS reference time" or in the IE "UE positioning acquisition assistance":
- 3> set IE "Error reason" to "Reference Cell Not Serving Cell".
 - 2> if the UE was not able to measure the requested GPS timing of cell frames measurement:
- 3> set IE "Error reason" to "Not Accomplished GPS Timing Of Cell Frames".
 - 1> if none of the conditions above are fulfilled:
 - 2> set IE "Error reason" to "Undefined Error".

The UE shall not set the IE "Error reason" to "Request Denied By User" or "Not Processed and Timeout".

8.6.7.19.6 Void

8.6.7.20 Void

8.6.7.21 Intra-frequency reporting quantity for RACH reporting

If the IE "Intra-frequency reporting quantity for RACH reporting" is included, the UE shall:

- 1> if the IE "SFN-SFN observed time difference reporting indicator" has the value "type 2":
 - 2> act as if the value of the IE "SFN-SFN observed time difference reporting indicator" is "no reporting".
- 1> if the IE "Reporting quantity" (FDD) or all IEs "Reporting quantity" (TDD) have the value "no report":
 - 2> the UE behaviour is unspecified.

8.6.7.22 Additional Measurement List

If the IE "Additional Measurement List" is received in a MEASUREMENT CONTROL message, the UE shall:

- 1> if the received measurement configuration in this MEASUREMENT CONTROL message, or any measurement referenced in the "Additional Measurement List" do not all have the same validity (for this consistency check the UE shall assume "CELL_DCH" as the measurement validity for measurements of type "inter-RAT", "UE internal", and "quality"):
 - 2> set the variable CONFIGURATION_INCOMPLETE to TRUE.
- 1> if any of the measurements referenced in the "Additional Measurement List" is an intra-frequency, interfrequency or inter-RAT measurement, and this measurement is configured with event based reporting:
 - 2> the UE behaviour is not specified.
- 1> if any of the "intra-frequency", "inter-frequency", "traffic volume" or "UE positioning" measurements referenced in the "Additional Measurement List" has been setup without including the IE "measurement validity":
 - 2> the UE behaviour is not specified.
- 1> if the result of this MEASUREMENT CONTROL message is such that more than one additional measurement of the same type will be referenced in the IE "Additional Measurement List" in the MEASUREMENT_IDENTITY variable:
 - 2> the UE behaviour is not specified.
- 1> if the UE has no IE "Additional Measurement List" stored the in variable MEASUREMENT_IDENTITY associated with the identity indicated by the IE "measurement identity":
 - 2> store the received IE "Additional Measurement List" in the variable MEASUREMENT_IDENTITY.

If the IE "Additional Measurement List" is received in a MEASUREMENT CONTROL message with the IE "Measurement command" value set to "modify", and the UE has an IE "Additional Measurement List" stored in the variable MEASUREMENT_IDENTITY associated with the identity indicated by the IE "measurement identity", the UE shall:

1> replace the information stored in "Additional Measurement List" in variable MEASUREMENT_IDENTITY associated to the identity indicated by the IE "measurement identity" with the one received in the MEASUREMENT CONTROL message.

If the IE "Additional Measurement List" is not received in a MEASUREMENT CONTROL message and the IE "Measurement command" has the value "modify" and the UE has an IE "Additional Measurement List" stored in the variable MEASUREMENT_IDENTITY associated with the identity indicated by the IE "measurement identity", the UE shall:

1> leave the IE "Additional Measurement List" stored in the variable MEASUREMENT_IDENTITY associated with the identity indicated by the IE "measurement identity" unchanged.

If, at any time during the life-time of a measurement, any measurement referenced in the Additional Measurement List does not exist, the UE shall:

1> remove this measurement identity from the Additional Measurement List.

NOTE: A measurement referenced in the Additional Measurement List which is updated with a measurement command set to "modify", or replaced with a measurement command set to "setup", continues to exist.

If the measurement configured with the MEASUREMENT CONTROL message triggers a measurement report, the UE shall:

1> also include the reporting quantities for the measurements referenced by the additional measurement identities. The contents of the IE "Additional Measured results" are completely determined by the measurement configuration of the referenced additional measurement.

8.6.8 Void

9 Handling of unknown, unforeseen and erroneous protocol data

9.1 General

This subclause specifies procedures for the handling of unknown, unforeseen, and erroneous protocol data by the receiving entity. These procedures are called "error handling procedures", but in addition to provide recovery mechanisms for error situations they define a compatibility mechanism for future extensions of the protocol.

The error handling procedures specified in this subclause shall apply to all RRC messages. When there is a specific handling for messages received on different logical channels this is specified.

For system information received on the BCCH, the error handling procedures are applied on the BCCH message SYSTEM INFORMATION, the re-assembled system information segments as well as the system information blocks (including the master information block and the scheduling blocks), with specific error handling as specified below.

When the UE receives an RRC message, it shall set the variable PROTOCOL_ERROR_REJECT to FALSE and then perform the checks in the order as defined below.

The error cases specified in the following include the handling upon reception of spare values. This behaviour also applies in case the actual value of the IE results from mapping the originally sent IE value. Moreover, in certain error cases, as specified in the following, default values apply. In this case, the default values specified within the ASN.1, the tabular and the procedure specifications apply.

9.2 ASN.1 violation or encoding error

If the UE receives an RRC message on the DCCH for which the encoded message does not result in any valid abstract syntax value [49] (or "encoding error"), it shall perform the following. The UE shall:

- 1> set the variable PROTOCOL_ERROR_REJECT to TRUE;
- 1> transmit an RRC STATUS message on the uplink DCCH. The IE "Protocol error information" shall contain an IE "Protocol error cause" set to "ASN.1 violation or encoding error";
- 1> when RRC STATUS message has been submitted to lower layers for transmission:
 - 2> continue with any ongoing processes and procedures as if the invalid message had not been received.

If the UE receives an RRC message sent via a radio access technology other than UTRAN, for which the encoded message does not result in any valid abstract syntax, the UE shall:

- 1> set the variable PROTOCOL_ERROR_REJECT to TRUE;
- 1> set the IE "Protocol error cause" in the variable PROTOCOL_ERROR_INFORMATION to "ASN.1 violation or encoding error";
- 1> perform procedure specific error handling according to clause 8.

If a reassembled set of system information segments received in messages on the BCCH does not result in any valid abstract syntax value, the UE shall:

- 1> ignore the reassembled set of system information segments;
- 1> treat the rest of each message containing the ignored system information segments as if those segments were not present.

If the UE receives an RRC message on the BCCH, PCCH, CCCH or SHCCH for which the encoded message does not result in any valid abstract syntax value, it shall ignore the message.

9.3 Unknown or unforeseen message type

If a UE receives an RRC message on the DCCH with a message type not defined for the DCCH it shall:

- 1> set the variable PROTOCOL_ERROR_REJECT to TRUE;
- 1> transmit an RRC STATUS message on the uplink DCCH. The IE "Protocol error information" shall contain an IE "Protocol error cause" set to "Message type non-existent or not implemented";
- 1> when the RRC STATUS message has been submitted to lower layers for transmission:
 - 2> continue with any ongoing processes and procedures as if the invalid message had not been received.

If the UE receives an RRC message on the BCCH, PCCH, CCCH or SHCCH with a message type not defined for the logical channel type the message was received on, it shall ignore the message.

9.3a Unsolicited received message

If the UE receives any of the following messages:

- an RRC CONNECTION SETUP message addressed to the UE on the CCCH; or
- an RRC CONNECTION REJECT message addressed to the UE on the CCCH; or
- a UE CAPABILITY INFORMATION CONFIRM message on the DCCH; or
- a CELL UPDATE CONFIRM message addressed to the UE on the CCCH or on the DCCH; or
- a URA UPDATE CONFIRM message addressed to the UE on the CCCH or on the DCCH

and no procedure is ongoing according to clause 8 which expects the message to be received:

the UE shall:

1> ignore the received message.

9.3b Unexpected critical message extension

If the UE receives an RRC message on the DCCH, or addressed to the UE on the CCCH or on the SHCCH, or sent via a radio access technology other than UTRAN, containing an undefined critical message extension, the UE shall:

- 1> set the variable PROTOCOL ERROR REJECT to TRUE;
- 1> set the IE "Protocol error cause" in the variable PROTOCOL_ERROR_INFORMATION to "Message extension not comprehended";
- 1> if the IE "Message Type" of the received message is not present in the table "Rejected transactions" in the variable TRANSACTIONS:
 - 2> store the IE "Message type" of the received message in the table "Rejected transactions" in the variable TRANSACTIONS; and

- 2> set the IE "RRC transaction identifier" to zero in that table entry.
- 1> perform procedure specific error handling according to clause 8.

If the UE receives an RRC message on the BCCH or PCCH, containing an undefined critical message extension, the UE shall:

1> ignore the message.

9.4 Unknown or unforeseen information element value, mandatory information element

If the UE receives an RRC message on the DCCH, or addressed to the UE on the CCCH or on the SHCCH, or sent via a radio access technology other than UTRAN, with a mandatory IE having a value, including choice, reserved for future extension (spare) or a value not used in this version of the specification (e.g. a dummy value), the UE shall:

- 1> if a default value of the IE is defined:
 - 2> treat the rest of the message using the default value of the IE.
- 1> if no default value of the IE is defined:
 - 2> set the variable PROTOCOL_ERROR_REJECT to TRUE;
 - 2> set the IE "Protocol error cause" in the variable PROTOCOL_ERROR_INFORMATION to "Information element value not comprehended";
 - 2> perform procedure specific error handling according to clause 8.

If the UE receives a system information block on the BCCH with a mandatory IE having a value reserved for future extension (spare) or a value not used in this version of the specification (e.g. a dummy value), the UE shall:

- 1> if a default value of the IE is defined:
 - 2> treat the rest of the system information block using the default value of the IE.
- 1> if no default value of the IE is defined:
 - 2> ignore the system information block.

If the UE receives an RRC message on the BCCH or PCCH with a mandatory IE having a value reserved for future extension (spare) or a value not used in this version of the specification (e.g. a dummy value), the UE shall:

- 1> if a default value of the IE is defined:
 - 2> treat the rest of the message using the default value of the IE.
- 1> if no default value of the IE is defined:
 - 2> ignore the message.

9.5 Conditional information element error

If the UE receives an RRC message on the DCCH, BCCH, PCCH, or addressed to the UE on the CCCH or on the SHCCH, or sent via a radio access technology other than UTRAN, for which the specified conditions for absence of a conditional IE are met and that IE is present, the UE shall:

- 1> ignore the IE;
- 1> treat the rest of the message as if the IE was not present.

If the UE receives an RRC message on the DCCH, or addressed to the UE on the CCCH or on the SHCCH, or sent via a radio access technology other than UTRAN, for which the specified conditions for presence of a conditional IE are met and that IE is absent, the UE shall:

- 1> set the variable PROTOCOL_ERROR_REJECT to TRUE;
- 1> set the IE "Protocol error cause" in the variable PROTOCOL_ERROR_INFORMATION to "Information element missing";
- 1> perform procedure specific error handling according to clause 8.

If the UE receives a system information block on the BCCH for which the specified conditions for presence of a conditional IE are met and that IE is absent, the UE shall:

1> ignore the system information block.

If the UE receives an RRC message on the BCCH or PCCH for which the specified conditions for presence of a conditional IE are met and that IE is absent, the UE shall:

1> ignore the message.

9.6 Unknown or unforeseen information element value, conditional information element

If the UE receives an RRC message on the DCCH, or addressed to the UE on the CCCH or on the SHCCH, or sent via a radio access technology other than UTRAN, for which the specified conditions for presence of a conditional IE are met, that IE is present, and that IE has a value, including choice, reserved for future extension (spare) or a value not used in this version of the specification (e.g. a dummy value), the UE shall:

- 1> if a default value of the IE is defined:
 - 2> treat the rest of the message using the default value of the IE.
- 1> if no default value of the IE is defined:
 - 2> set the variable PROTOCOL_ERROR_REJECT to TRUE;
 - 2> set the IE "Protocol error cause" in the variable PROTOCOL_ERROR_INFORMATION to "Information element value not comprehended";
 - 2> perform procedure specific error handling according to clause 8.

If the UE receives a system information block on the BCCH for which the specified conditions for presence of a conditional IE are met, that IE is present, and that IE has a value, including choice, reserved for future extension (spare) or a value not used in this version of the specification (e.g. a dummy value), the UE shall:

- 1> if a default value of the IE is defined:
 - 2> treat the rest of the system information block using the default value of the IE.
- 1> if no default value of the IE is defined:
 - 2> ignore the system information block.

If the UE receives an RRC message on the BCCH or PCCH for which the specified conditions for presence of a conditional IE are met, that IE is present, and that IE has a value, including choice, reserved for future extension (spare) or a value not used in this version of the specification (e.g. a dummy value), the UE shall:

- 1> if a default value of the IE is defined:
 - 2> treat the rest of the message using the default value of the IE.
- 1> if no default value of the IE is defined:
 - 2> ignore the message.

9.7 Unknown or unforeseen information element value, optional information element

If the UE receives an RRC message on the DCCH, or addressed to the UE on the CCCH or on the SHCCH, or sent via a radio access technology other than UTRAN, with an optional IE having a value, including choice, reserved for future extension (spare) or a value not used in this version of the specification (e.g. a dummy value), it shall:

- 1> ignore the value of the IE;
- 1> treat the rest of the message as if the IE was not present.

If the UE receives a system information block on the BCCH with an optional IE having a value, including choice, reserved for future extension (spare) or a value not used in this version of the specification (e.g. a dummy value), it shall:

- 1> ignore the value of the IE;
- 1> treat the rest of the system information block as if the IE was not present.

If the UE receives an RRC message on the BCCH or PCCH with an optional IE having a value, including choice, reserved for future extension (spare) or a value not used in this version of the specification (e.g. a dummy value), it shall:

- 1> ignore the value of the IE;
- 1> treat the rest of the message as if the IE was not present.

9.8 Unexpected non-critical message extension

If the UE receives an RRC message on the DCCH, or addressed to the UE on the CCCH or on the SHCCH, or sent via a radio access technology other than UTRAN, containing an undefined non-critical message extension, the UE shall:

- 1> if the non critical extension is included in the "Variable Length Extension Container":
 - 2> ignore the content of the extension and the contents of this container after the not comprehended extension, and continue decoding the rest of the message.
- 1> otherwise:
 - 2> ignore the content of the extension and the message contents after the extension, but treat the parts of the message up to the extension normally.

If the UE receives a system information block on the BCCH containing an undefined non-critical message extension, the UE shall:

1> ignore the content of the extension and the system information block contents after the extension, but treat the parts of the system information block up to the extension normally.

If the UE receives an RRC message on the BCCH or PCCH, containing an undefined non-critical message extension, the UE shall:

1> ignore the content of the extension and the message contents after the extension, but treat the parts of the message up to the extension normally.

9.9 Handling of errors in nested information elements

An erroneous IE may be included in another IE, which may be included in another IE and so on. This subclause specifies the handling of errors in mandatory IEs as well as for conditional IEs for which the specified conditions for presence are met, that are nested in another IE.

In case the UE receives an IE (IE1) that includes a mandatory IE (IE1-1) having a value, including choice, reserved for future extension (spare) or a value not used in this version of the specification (e.g. a dummy value), the UE shall:

- 1> consider IE1 to have an undefined value; and
- 1> apply the corresponding generic error handling to IE1.

In case there are many IE nesting levels, in all of which the IE is mandatory while no default value is defined, this treatment may need to be repeated several times. The following example illustrates the general principle.

```
ExampleMessage ::= SEQUENCE {
   iel iel IEI OPTIONAL,
   ie2 IE2
}

IE1 ::= SEQUENCE {
   iel-1 INTEGER (1..16),
   -- iel-1 values 13..16 are spare and should not be used in this version of the protocol iel-2 IE1-2 OPTIONAL,
   iel-3
}
```

If in the above example, UTRAN would include ie1 and set ie1-1 to value 13, the UE experiences an error in a mandatory IE. The guideline outlined in the previous then means that the UE shall not discard the entire message but instead consider "ie1" to have an unknown value. Since IE1 is optional, the generic error handling would be to ignore "ie1".

In case the UE receives an IE (IE1) that includes a list of another IE (IE1-1) for which one or more entries in the list have a value, including choice, reserved for future extension (spare) or a value not used in this version of the specification (e.g. a dummy value), the UE shall:

1> consider the list as if these entries were not included.

NOTE: In case the above generic error handling procedures do not result in the desired behaviour, the introduction of spares may need to be reconsidered.

Message and information element functional definition and content

10.1 General

The function of each Radio Resource Control message together with message contents in the form of a list of information elements is defined in subclause 10.2.

Functional definitions of the information elements are then described in subclause 10.3.

Information elements are marked as either MP - Mandatory present, MD - Mandatory with default value, OP - Optional, CV - Conditional on value or CH - Conditional on history (see Table 10.1 with information extracted from [14]).

Table 10.1: Meaning of abbreviations used in RRC messages and information elements

Abbreviation	Meaning
MP	Mandatory present
	A value for that information is always needed, and no
	information is provided about a particular default value. If
	ever the transfer syntax allows absence (e.g., due to
	extension), then absence leads to an error diagnosis.
MD	Mandatory with default value
	A value for that information is always needed, and a
	particular default value is mentioned (in the 'Semantical
	information' column). This opens the possibility for the
	transfer syntax to use absence or a special pattern to
	encode the default value.

Abbreviation	Meaning
CV	Conditional on value The need for a value for that information depends on the value of some other IE or IEs, and/or on the message flow (e.g., channel, SAP). The need is specified by means of a condition, the result of which may be that the information is mandatory present, mandatory with default value, not needed or optional. If one of the results of the condition is that the information is mandatory present, the transfer syntax must allow for the presence of the information. If in this case the information is absent an error is diagnosed. If one of the results of the condition is that the information is mandatory with default value, and a particular default value is mentioned (in the 'Semantical information' column), the transfer syntax may use absence or a special pattern to encode the default value. If one of the results of the condition is that the information is not needed, the transfer syntax must allow encoding the absence. If in this case the information is present, it will be ignored. In specific cases however, an error may be diagnosed instead. If one of the results of the condition is that the information is optional, the transfer syntax must allow for the presence of the information. In this case, neither absence nor presence of the information leads to an error diagnosis.
СН	Conditional on history The need for a value for that information depends on information obtained in the past (e.g., from messages received in the past from the peer). The need is specified by means of a condition, the result of which may be that the information is mandatory present, mandatory with default value, not needed or optional. The handling of the conditions is the same as described for CV.
OP	Optional The presence or absence is significant and modifies the behaviour of the receiver. However whether the information is present or not does not lead to an error diagnosis.

10.1.1 Protocol extensions

RRC messages may be extended in future versions of this protocol, either by adding values for choices, enumerated and size constrained types or by adding information elements. An important aspect concerns the behaviour of a UE, conforming to this revision of the standard, upon receiving a not comprehended future extension. The details of this error handling behaviour are provided in clause 9.

NOTE 1: By avoiding the need for partial decoding (skipping uncomprehended IEs to continue decoding the remainder of the message), the RRC protocol extension mechanism also avoids the overhead of length determinants for extensions. "Variable length extension containers" (i.e. non critical extension containers that have their abstract syntax defined using the ASN.1 type "BIT STRING") have been defined to support the introduction of extensions to a release after the subsequent release is frozen (and UEs based on that subsequent release may appear). For this container a length determinant is used, which facilitates partial decoding of the container as well as the decoding of the extensions included after the container.

Two kinds of protocol extensions are distinguished: non-critical and critical extensions. In general, a receiver shall process a message including not comprehended non-critical extensions as if the extensions were absent. However, a receiver shall entirely reject a message including not comprehended critical extensions (there is no partial rejection) and notify the sender, as specified in clause 9.

The general mechanism for adding critical extensions is by defining a new version of the message, which is indicated at the beginning of the message.

The UE shall always comprehend the complete transfer syntax specified for the protocol version it supports; if the UE comprehends the transfer syntax defined within protocol version A for message 1, it shall also comprehend the transfer syntax defined within protocol version A for message 2.

The following table shows for which messages only non-critical extensions may be added while for others both critical and non-critical extensions may be added.

NOTE 2: Critical extensions can only be added to certain downlink messages.

Extensions	Message
Critical and non-critical	ACTIVE SET UPDATE 10.2.1
extensions	ASSISTANCE DATA DELIVERY 10.2.4
	CELL CHANGE ORDER FROM UTRAN 10.2.5
	CELL UPDATE CONFIRM 10.2.8
	COUNTER CHECK 10.2.9
	DOWNLINK DIRECT TRANSFER 10.2.11
	HANDOVER TO UTRAN COMMAND 10.2.16a
	HANDOVER FROM UTRAN COMMAND 10.2.15
	MEASUREMENT CONTROL 10.2.17
	PHYSICAL CHANNEL RECONFIGURATION 10.2.22
	PHYSICAL SHARED CHANNEL ALLOCATION 10.2.25
	RADIO BEARER RECONFIGURATION 10.2.27
	RADIO BEARER RELEASE 10.2.30
	RADIO BEARER SETUP 10.2.33
	RRC CONNECTION REJECT 10.2.36
	RRC CONNECTION RELEASE 10.2.37
	RRC CONNECTION SETUP 10.2.40
	SECURITY MODE COMMAND 10.2.43
	SIGNALLING CONNECTION RELEASE 10.2.46
	TRANSPORT CHANNEL RECONFIGURATION 10.2.50
	UE CAPABILITY ENQUIRY 10.2.55
	UE CAPABILITY INFORMATION CONFIRM 10.2.57
	UPLINK PHYSICAL CHANNEL CONTROL 10.2.59
	URA UPDATE CONFIRM 10.2.61
	UTRAN MOBILITY INFORMATION 10.2.62
Non-critical extensions	ACTIVE SET UPDATE COMPLETE 10.2.2
only	ACTIVE SET UPDATE FAILURE 10.2.3
	CELL CHANGE ORDER FROM UTRAN FAILURE 10.2.6
	CELL UPDATE 10.2.7
	COUNTER CHECK RESPONSE 10.2.10
	HANDOVER TO UTRAN COMPLETE 10.2.16b
	INITIAL DIRECT TRANSFER 10.2.16c
	HANDOVER FROM UTRAN FAILURE 10.2.16
	MEASUREMENT CONTROL FAILURE 10.2.18
	MEASUREMENT REPORT 10.2.19
	PAGING TYPE 1 10.2.20
	PAGING TYPE 2 10.2.21
	PHYSICAL CHANNEL RECONFIGURATION COMPLETE 10.2.23
	PHYSICAL CHANNEL RECONFIGURATION FAILURE 10.2.24
	PUSCH CAPACITY REQUEST 10.2.26
	RADIO BEARER RECONFIGURATION COMPLETE 10.2.28
	RADIO BEARER RECONFIGURATION FAILURE 10.2.29
	RADIO BEARER RELEASE COMPLETE 10.2.31
	RADIO BEARER RELEASE FAILURE 10.2.32
	RADIO BEARER SETUP COMPLETE 10.2.34
	RADIO BEARER SETUP FAILURE 10.2.35
	RRC CONNECTION RELEASE COMPLETE 10.2.38
	RRC CONNECTION REQUEST 10.2.39
	RRC CONNECTION SETUP COMPLETE 10.2.41
	RRC STATUS 10.2.42
	SECURITY MODE COMPLETE 10.2.44
	SECURITY MODE FAILURE 10.2.45
	SIGNALLING CONNECTION RELEASE INDICATION 10.2.47
	Master Information Block 10.2.48.8.1
	System Information Block type 1 to
	System Information Block type 17 10.2.48.8.2 to 10.2.48.8.19
	SYSTEM INFORMATION CHANGE INDICATION 10.2.49
	TRANSPORT CHANNEL RECONFIGURATION COMPLETE 10.2.51

Extensions	Message
	TRANSPORT CHANNEL RECONFIGURATION FAILURE 10.2.52
	TRANSPORT FORMAT COMBINATION CONTROL 10.2.53
	TRANSPORT FORMAT COMBINATION CONTROL FAILURE 10.2.54
	UE CAPABILITY INFORMATION 10.2.56
	UPLINK DIRECT TRANSFER 10.2.58
	URA UPDATE 10.2.60
	UTRAN MOBILITY INFORMATION CONFIRM 10.2.63
	UTRAN MOBILITY INFORMATION FAILURE 10.2.64
No extensions	SYSTEM INFORMATION 10.2.48
	First Segment 10.2.48.1
	Subsequent or last Segment 10.2.48.3
	Complete SIB 10.2.48.5
	SIB content 10.2.48.8.1

NOTE 3: For the SYSTEM INFORMATION message protocol extensions are only possible at the level of system information blocks.

10.1.1.1 Non-critical extensions

10.1.1.1.1 Extension of an information element with additional values or choices

In future versions of this protocol, non-critical values may be added to choices, enumerated and size constrained types.

For choices, enumerated and size constrained types it is possible to indicate how many non-critical spare values need to be reserved for future extension. In this case, the tabular format should indicate the number of spare values that are needed. The value range defined in ASN.1 for the extensible IE should include the number of spares that are needed, since a value outside the range defined for this IE will result in a general ASN.1 violation error.

For downlink messages, spare values may be defined for non-critical information elements for which the need is specified to be MD or OP (or CV case leading to MD or OP). In this case, a receiver not comprehending the received spare value shall consider the information element to have the default value or consider it to be absent respectively.

For uplink messages spare values may be defined for all information elements, including those for which the need is specified to be MP (or CV case leading to MP).

In all cases at most one spare should be defined for choices. In this case, information elements applicable to the spare choices shall be added to the end of the message.

10.1.1.1.2 Extension of a message with additional information elements

In future versions of this protocol, non-critical information elements may be added to RRC messages. These additional information elements shall be normally appended at the end of the message; the transfer syntax specified in this revision of the standard facilitates this. A receiver conformant to this revision of the standard shall accept such extension, and proceed as if it was not included.

A transmitter conformant to this version of the standard shall not include an extension reserved for introducing non critical extensions in later versions of the standard; i.e. the corresponding parameter defined in the ASN.1 shall be absent.

NOTE: If an extension, reserved for future non-critical extensions, is included (even if it is empty), this may result in transfer syntax errors when received by an implementation conforming to a later version of the standard.

Extensions to a release that are introduced after the subsequent release is frozen may however be inserted prior to the end of the message. To facilitate this, "variable length extension containers" have been introduced in most messages.

10.1.1.2 Critical extensions

10.1.1.2.1 Extension of an information element with additional values or choices

In versions of this protocol, choices, enumerated and size constrained types may be extended with critical values. For extension with critical values the general critical extension mechanism is used, i.e. for this no spare values are reserved since backward compatibility is not required.

10.1.1.2.2 Extension of a message with additional information elements

In future versions of this protocol, RRC messages may be extended with new information elements. Since messages including critical extensions are rejected by receivers not comprehending them, these messages may be modified completely, e.g. IEs may be inserted at any place and IEs may be removed or redefined.

10.2 Radio Resource Control messages

10.2.1 ACTIVE SET UPDATE

NOTE: Only for FDD.

This message is used by UTRAN to add, replace or delete radio links in the active set of the UE.

RLC-SAP: AM or UM

Logical channel: DCCH

Direction: UTRAN \rightarrow UE

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Message Type	MP		Message		
Wicodago Typo	'*''		Type		
UE information			71 -		
elements					
RRC transaction	MP		RRC		
identifier			transactio		
			n		
			identifier		
			10.3.3.36		
Integrity check info	CH		Integrity		
			check info		
			10.3.3.16		
Activation time	MD		Activation	Default value is "now".	
			time		
			10.3.3.1		
New U-RNTI	OP		U-RNTI		
			10.3.3.47		
CN information					
elements					
CN Information info	OP		CN		
			Informatio		
			n info		
			10.3.1.3		
Phy CH information					
elements					
Uplink radio resources					
Maximum allowed UL TX	MD		Maximum	Default value is the	<u></u>
power			allowed	existing "maximum UL	
			UL TX	TX power.	
			power		
			10.3.6.39		
Downlink radio					<u></u>
resources					

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Radio link addition information	OP	1 to <maxrl -1></maxrl 		Radio link addition information required for each RL to add	
>Radio link addition information	MP		Radio link addition informatio n 10.3.6.68		
Radio link removal information	OP	1 to <maxrl ></maxrl 		Radio link removal information required for each RL to remove	
>Radio link removal information	MP		Radio link removal informatio n 10.3.6.69		
TX Diversity Mode	MD		TX Diversity Mode 10.3.6.86	Default value is the TX diversity mode currently used in all or part of the active set.	
SSDT information	OP		SSDT informatio n 10.3.6.77		
DPC Mode	OP		Enumerat ed (Single TPC, TPC triplet in soft)	"Single TPC" is DPC_Mode=0 and "TPC triplet in soft" is DPC_mode=1 in [29].	REL-5

10.2.2 ACTIVE SET UPDATE COMPLETE

NOTE: For FDD only.

This message is sent by UE when active set update has been completed.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message Type	
UE information elements				
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36	
Integrity check info	СН		Integrity check info 10.3.3.16	

10.2.3 ACTIVE SET UPDATE FAILURE

NOTE: Only for FDD.

This message is sent by UE if the update of the active set has failed, e.g. because the radio link is not a part of the active set

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message Type	
UE information elements				
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36	
Integrity check info	СН		Integrity check info 10.3.3.16	
Failure cause	MP		Failure cause and error information 10.3.3.14	

10.2.4 ASSISTANCE DATA DELIVERY

This message is sent by UTRAN to convey UE positioning assistance data to the UE.

RLC-SAP: AM

Logical channel: DCCH

Direction: UTRAN \rightarrow UE

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message Type	
UE information elements				
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36	
Integrity check info	СН		Integrity check info 10.3.3.16	
Measurement Information elements				
UE positioning OTDOA assistance data for UE-based	OP		UE positioning OTDOA assistance data for UE- based 10.3.7.103a	
UE positioning GPS assistance data	OP		UE positioning GPS assistance data 10.3.7.90	

10.2.5 CELL CHANGE ORDER FROM UTRAN

This message is used to order a cell change from UTRA to another radio access technology, e.g., GSM.

RLC-SAP: AM

Logical channel: DCCH

Direction: UTRAN→UE

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Message Type	MP		Message Type		
UE information					
elements					
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36		
Integrity check info	CH		Integrity check info 10.3.3.16		
Activation time	MD		Activation time 10.3.3.1	Default value is "now"	
RB Information elements					
RAB information list	OP	1 to <maxra Bsetup></maxra 		This IE should not be included in this version of the protocol.	
>RAB info	MP		RAB info 10.3.4.8		
Other information elements					
Target cell description	MP				
>CHOICE Radio Access	MP			Two spare values are	
Technology				needed.	
>>GSM					
>>>BSIC	MP		BSIC 10.3.8.2		
>>>Band Indicator	MP		Enumerated (DCS 1800 band used, PCS 1900 band used)	Indicates how to interpret the BCCH ARFCN	
>>>BCCH ARFCN	MP		Integer (01023)	[45]	
>>>NC mode	OP		Bit string(3)	Includes bits b1-b3 of the NC mode IE specified in [43]. b1 is the least significant bit. NOTE: The Bit string should be extended to 4 bits in a later version of the message.	
>>>CHOICE GERAN	OP			3	REL-5
System Info type >>>> SI			GERAN system information 10.3.8.4f	SI3, SI13, SI1 [44]	REL-5
>>>>PSI			GERAN system information 10.3.8.4f	PSI1, PSI2, PSI4 [44]	REL-5
>>IS-2000					

10.2.6 CELL CHANGE ORDER FROM UTRAN FAILURE

This message is sent on the RRC connection used before the Cell change order from UTRAN was executed. The message indicates that the UE has failed to seize the new channel in the other radio access technology.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message	
			Туре	
UE information elements				
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36	
Integrity check info	СН		Integrity check info 10.3.3.16	
Other information elements				
Inter-RAT change failure	MP		Inter-RAT change failure 10.3.8.5	

10.2.7 CELL UPDATE

This message is used by the UE to initiate a cell update procedure.

RLC-SAP: TM

Logical channel: CCCH

Direction: UE→UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Message Type	MP		Message Type		
UE information elements					
U-RNTI	MP		U-RNTI 10.3.3.47		
RRC transaction identifier	CV- Failure		RRC transactio n identifier 10.3.3.36		
Integrity check info	СН		Integrity check info 10.3.3.16		
START list	MP	1 to <maxcn domains ></maxcn 		START [40] values for all CN domains.	
>CN domain identity	MP		CN domain identity 10.3.1.1		

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
>START	MP		START	START value to be	
			10.3.3.38	used in this CN domain.	
AM_RLC error indication(RB2, RB3 or RB4)	MP		Boolean	TRUE indicates AM_RLC unrecoverable error [16] occurred on RB2, RB3 or RB4 in the UE	
AM_RLC error indication(RB>4)	MP		Boolean	TRUE indicates AM_RLC unrecoverable error [16] occurred on RB>4 in the UE	
Cell update cause	MP		Cell update cause 10.3.3.3		
Failure cause	OP		Failure cause and error informatio n 10.3.3.14		
RB timer indicator	MP		RB timer indicator 10.3.3.28		
Establishment cause	OP		Establish ment cause 10.3.3.11		Rel-5
Measurement information elements					
Measured results on RACH	OP		Measured results on RACH 10.3.7.45		

Condition	Explanation
Failure	This IE is mandatory present if the IE "Failure cause"
	is present and not needed otherwise.

10.2.8 CELL UPDATE CONFIRM

This message confirms the cell update procedure and can be used to reallocate new RNTI information for the UE valid in the new cell.

RLC-SAP: UM

Logical channel: CCCH or DCCH

Direction: UTRAN \rightarrow UE

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Message Type	MP		Message Type		
UE Information Elements					
U-RNTI	CV-CCCH		U-RNTI 10.3.3.47		
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36		
Integrity check info	CH		Integrity		

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
			check info 10.3.3.16		
Integrity protection mode info	OP		Integrity protection mode info 10.3.3.19	The UTRAN should not include this IE unless it is performing an SRNS relocation or a cell reselection from GERAN <i>Iu mode</i>	
Ciphering mode info	OP		Ciphering mode info 10.3.3.5	The UTRAN should not include this IE unless it is performing either an SRNS relocation or a cell reselection from GERAN <i>Iu mode</i> , and a change in ciphering algorithm.	
Activation time	MD		Activation time 10.3.3.1	Default value is "now"	
New U-RNTI	OP		U-RNTI 10.3.3.47		
New C-RNTI	OP		C-RNTI 10.3.3.8		
New DSCH-RNTI	OP		DSCH-RNTI 10.3.3.9a		
New H-RNTI	OP		H-RNTI 10.3.3.14a		REL-5
RRC State Indicator	MP		RRC State Indicator 10.3.3.35a		
UTRAN DRX cycle length coefficient	OP		UTRAN DRX cycle length coefficient 10.3.3.49		
RLC re-establish indicator (RB2, RB3 and RB4)	MP		RLC re- establish indicator 10.3.3.35	Should not be set to TRUE if IE "Downlink counter synchronisation info" is included in message.	
RLC re-establish indicator (RB5 and upwards)	MP		RLC re- establish indicator 10.3.3.35	Should not be set to TRUE if IE "Downlink counter synchronisation info" is included in message.	
CN Information Elements					
CN Information info	OP		CN Information info 10.3.1.3		
UTRAN Information Elements					
URA identity	OP		URA identity 10.3.2.6		
RB information elements					
RB information to release list	OP	1 to <maxrb></maxrb>			
>RB information to release	MP		RB information to release 10.3.4.19		

Information Element/Group name	Need	Multi <maxrb></maxrb>	Type and reference	Semantics description	Version
>RB information to reconfigure	MP	<iiiaxrb></iiiaxrb>	RB		
The monitor to receiving and			information to reconfigure 10.3.4.18		
RB information to be affected list	OP	1 to <maxrb></maxrb>	10.3.4.16		
>RB information to be affected	MP		RB information to be affected 10.3.4.17		
Downlink counter	OP				
synchronisation info	OD	4.4-			
>RB with PDCP information list	OP	1 to <maxrball RABs></maxrball 			
>>RB with PDCP information	MP		RB with PDCP information 10.3.4.22	This IE is needed for each RB having PDCP in the case of lossless SRNS relocation	
	OP				REL-5
>>PDCP context relocation info	OP		PDCP context relocation info 10.3.4.1a	This IE is needed for each RB having PDCP and performing PDCP context relocation	REL-5
TrCH Information Elements					
Uplink transport channels			<u>-</u>		
UL Transport channel information common for all transport channels	OP		UL Transport channel information common for all transport channels 10.3.5.24		
Deleted TrCH information list	OP	1 to <maxtrch ></maxtrch 			
>Deleted UL TrCH information	MP		Deleted UL TrCH information 10.3.5.5		
Added or Reconfigured TrCH information list	OP	1 to <maxtrch ></maxtrch 			
>Added or Reconfigured UL TrCH information	MP		Added or Reconfigure d UL TrCH information 10.3.5.2		
CHOICE mode	MP				
>FDD				_	
>>CPCH set ID	OP		CPCH set ID 10.3.5.3		
>>Added or Reconfigured TrCH information for DRAC list	OP	1 to <maxtrch ></maxtrch 			
>>>DRAC static information	MP		DRAC static information 10.3.5.7		
>TDD				(no data)	

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Downlink transport channels					
DL Transport channel information common for all transport channels	OP		DL Transport channel information common for all transport channels 10.3.5.6		
Deleted TrCH information list	OP	1 to <maxtrch ></maxtrch 			
>Deleted DL TrCH information	MP		Deleted DL TrCH information 10.3.5.4		
Added or Reconfigured TrCH information list	OP	1 to <maxtrch ></maxtrch 			
>Added or Reconfigured DL TrCH information	MP		Added or Reconfigure d DL TrCH information 10.3.5.1		
PhyCH information elements					1
Frequency info	OP		Frequency info 10.3.6.36		
Uplink radio resources					
Maximum allowed UL TX power	MD		Maximum allowed UL TX power 10.3.6.39	Default value is the existing maximum UL TX power	
CHOICE channel requirement	OP				
>Uplink DPCH info			Uplink DPCH info 10.3.6.88.		
>CPCH SET Info			CPCH SET Info 10.3.6.13		
Downlink radio resources	140				-
CHOICE mode	MP				1
>>FDD >>Downlink PDSCH information	OP		Downlink PDSCH information 10.3.6.30		
>TDD				(no data)	
Downlink HS-PDSCH Information	OP		Downlink HS_PDSCH Information 10.3.6.23a		REL-5
Downlink information common for all radio links	OP		Downlink information common for all radio links 10.3.6.24		
Downlink information per radio link list	OP	1 to <maxrl></maxrl>		Send downlink information for each radio link to be set-up	
>Downlink information for each radio link	MP		Downlink information for each radio link 10.3.6.27		

Condition	Explanation
CCCH	This IE is mandatory present when CCCH is used and
	ciphering is not required and not needed otherwise.

10.2.9 COUNTER CHECK

This message is used by the UTRAN to indicate the current COUNT-C MSB values associated to each radio bearer utilising UM or AM RLC mode and to request the UE to compare these to its COUNT-C MSB values and to report the comparison results to UTRAN.

RLC-SAP: AM

Logical channel: DCCH

Direction: UTRAN→UE

Information Element/Group name	Presence	Multi	IE type and reference	Semantics description
Message Type	MP			
UE information elements				
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36	
Integrity check info	СН		Integrity check info 10.3.3.16	
RB information elements				
RB COUNT-C MSB information	MP	1 to < maxRBallR ABs >		For each RB (excluding signalling radio bearers) using UM or AM RLC.
>RB COUNT-C MSB information	MP		RB COUNT- C MSB information 10.3.4.14	

10.2.10 COUNTER CHECK RESPONSE

This message is used by the UE to respond to a COUNTER CHECK message.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

Information Element/Group name	Presence	Multi	IE type and reference	Semantics description
	MD		reference	
Message Type	MP			
UE information elements				
RRC transaction identifier	MP		RRC	
			transaction	
			identifier	
			10.3.3.36	
Integrity check info	CH		Integrity	
			check info	
			10.3.3.16	
RB information elements				
RB COUNT-C information	OP	1 to <		
		maxRBallR		
		ABs >		
>RB COUNT-C information	MP	71007	RB COUNT-	
>KD COUNT-C Information	IVIP			
			С	
			information	
			10.3.4.15	

10.2.11 DOWNLINK DIRECT TRANSFER

This message is sent by UTRAN to transfer higher layer messages.

RLC-SAP: AM

Logical channel: DCCH

Direction: UTRAN -> UE

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message Type	
UE information elements				
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36	
Integrity check info	CH		Integrity check info 10.3.3.16	
CN information elements				
CN Domain Identity	MP		Core Network Domain Identity 10.3.1.1	
NAS message	MP		NAS message 10.3.1.8	

10.2.12 Void

10.2.13 Void

10.2.14 Void

10.2.15 HANDOVER FROM UTRAN COMMAND

This message is used for handover from UMTS to another system e.g. GSM. One or several messages from the other system can be included in the Inter-RAT message information element in this message. These messages are structured and coded according to that systems specification.

RLC-SAP: AM

Logical channel: DCCH

Direction: UTRAN→UE

Information	Need	Multi	Type and	Semantics description	Version
Element/Group name			reference		
Message Type	MP		Message Type		
UE information			71 -		
elements					
RRC transaction	MP		RRC		
identifier			transactio		
			n		
			identifier		
			10.3.3.36		
Integrity check info	CH		Integrity		
			check info		
A stirestion times	MD		10.3.3.16	Defections in the coult	
Activation time	MD		Activation time	Default value is "now"	
			10.3.3.1		
RB information			10.3.3.1		
elements					
RAB information list	OP	1 to		For each RAB to be	
		<maxra< td=""><td></td><td>handed over. In this</td><td></td></maxra<>		handed over. In this	
		Bsetup>		version, the maximum	
				size of the list of 1 shall	
				be applied for all	
				system types. In	
				handover to GERAN Iu	
				mode the RAB	
				information is included	
				in the GERAN lu	
>RAB info	MP		RAB info	message below.	
>RAD IIIIU	IVIF		10.3.4.8		
Other information					
elements	MP			This IE indicates which	
CHOICE System type	IVIP			specification to apply, to	
				decode the transported	
				messages	
>GSM				meedagee	
>>Frequency band	MP		Enumerat		
			ed		
			(GSM/DC		
			S 1800		
			band		
			used),		
			GSM/PC		
	1	1	S 1900		
			hand	l l	
			band used)		

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
>>>Single GSM message	MP		Bit string (no explicit size constraint	Formatted and coded according to GSM specifications The first/leftmost/most significant bit of the bit string contains bit 8 of the first octet of the GSM message.	
>>>GSM message List	MP	1.to. <ma xInterSy sMessa ges></ma 	Bit string (1512)	Formatted and coded according to GSM specifications. The first/leftmost/most significant bit of the bit string contains bit 8 of the first octet of the GSM message.	
>GERAN lu	MD				REL-5
>>Frequency band >>GERAN lu message	MP		Enumerat ed (GSM/DC S 1800 band used), GSM/PC S 1900 band used)		REL-5
>>Single GERAN lu message	MP		Bit string (no explicit size constraint	Formatted and coded according to [53]. The first/leftmost/most significant bit of the bit string contains bit 8 of the first octet of the message.	REL-5
>>>GERAN lu message List	MP	1 to <maxint erSysMe ssages></maxint 	Bit string (132768)	Formatted and coded according to [53]. The first/leftmost/most significant bit of the bit string contains bit 8 of the first octet of the message.	REL-5
>cdma2000 >>cdma2000MessageLis	MP	1.to. <ma< td=""><td></td><td></td><td></td></ma<>			
t		xInterSy sMessa ges>			
>>>MSG_TYPE(s)	MP		Bit string (8)	Formatted and coded according to cdma2000 specifications. The MSG_TYPE bits are numbered b0 to b7. The first/leftmost/most significant bit of the bit string contains bit 7 of the MSG_TYPE.	
>>>cdma2000Messagep ayload(s)	MP		Bit string (1512)	Formatted and coded according to cdma2000 specifications. The first/leftmost/most significant bit of the bit string contains the bit 7 of the first octet of the cdma2000 message.	

10.2.16 HANDOVER FROM UTRAN FAILURE

This message is sent on the RRC connection used before the Inter-RAT Handover was executed. The message indicates that the UE has failed to seize the new channel in the other system.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

Information Element/Group name Message Type MP Message Type UE information elements RRC transaction identifier Integrity check info Other information Element/Group name MP Message Type MP Message Type MR MR MR RRC transactio n identifier 10.3.3.36 Integrity check info 10.3.3.16	Version
UE information elements RRC transaction identifier Integrity check info CH Type Type	
UE information elements RRC transaction identifier MP RRC transactio transactio n identifier 10.3.3.36 Integrity check info CH Integrity check info 10.3.3.16	
elements RRC transaction identifier MP RRC transactio transactio n identifier 10.3.3.36 Integrity check info CH Integrity check info 10.3.3.16	
identifier transactio n identifier 10.3.3.36 Integrity check info CH Integrity check info 10.3.3.16	
Integrity check info CH Integrity check info 10.3.3.36 Integrity check info 10.3.3.16	
Integrity check info CH Integrity check info 10.3.3.36 Integrity check info 10.3.3.16	
Integrity check info CH Integrity check info 10.3.3.36 Integrity check info 10.3.3.16	
Integrity check info CH Integrity check info 10.3.3.16	
check info 10.3.3.16	
Other information	
elements	
Inter-RAT handover OP Inter-RAT	
failure handover failure	
10.3.8.6	
CHOICE System type OP This IE indicates which	1
specification to apply to	
decode the transported	
messages	_
>GSM >>GSM Bit string Formatted and coded	
xInterSy (1512) according to GSM	
sMessa specifications. The	
ges> first/leftmost/most	
significant bit of the bit	
string contains bit 8 of	
the first octet of the GSM message.	
>GERAN lu	REL-5
>>GERAN lu message MP 1 to Bit string Formatted and coded	REL-5
List <maxint (132768)="" [53].="" according="" td="" the<="" to=""><td></td></maxint>	
erSysMe first/leftmost/most	
ssages> significant bit of the bit	
string contains bit 8 of the first octet of the	
message.	
>cdma2000	+
>>cdma2000MessageLis MP 1.to. <ma< td=""><td>1</td></ma<>	1
t xInterSy	
sMessa	
ges>	+
Silving Formatied and coded (8) according to cdma2000	
specifications. The	
MSG_TYPE bits are	
numbered b0 to b7. The	
first/leftmost/most	
significant bit of the bit string contains bit 7 of	
the MSG_TYPE.	
>>>cdma2000Messagep MP Bit string Formatted and coded	1

Information	Need	Multi	Type and	Semantics description	Version
Element/Group name			reference		
ayload(s)			(1512)	according to cdma2000 specifications. The first/leftmost/most significant bit of the bit string contains bit 7 of the first octet of the cdma2000 message.	

10.2.16a HANDOVER TO UTRAN COMMAND

This message is sent to the UE via other system to make a handover to UTRAN.

RLC-SAP: N/A (Sent through a different RAT)

Logical channel: N/A (Sent through a different RAT)

Direction: UTRAN \rightarrow UE

Information Floresut/Cusus	Need	Multi	Tyme and	Computing description
Information Element/Group name	Need	Williti	Type and reference	Semantics description
New U-RNTI	MP		U-RNTI	
New U-RIVII	IVIE		Short	
			10.3.3.48	
Ciphering algorithm	OP		Ciphering	
Cipileting algorithm	OF .		algorithm	
			10.3.3.4	
CHOICE specification mode	MP		10.5.5.4	
>Complete specification	1011			
RB information elements				
>>Signalling RB information to	MP	1 to		For each signalling radio
setup list	IVIE	<maxsrbs< td=""><td></td><td>bearer established</td></maxsrbs<>		bearer established
setup list		etup>		bearer established
>>>Signalling RB information to	MP	Glup/	Signalling	
setup	1411		RB	
ootap			information	
			to setup	
			10.3.4.24	
>>RAB information to setup list	OP	1 to	10.0.1.21	For each RAB established
The second secon		<maxrabs< td=""><td></td><td></td></maxrabs<>		
		etup>		
>>>RAB information for setup	MP		RAB	
			information	
			for setup	
			10.3.4.10	
Uplink transport channels				
>>UL Transport channel	MP		UL Transport	
information common for all			channel	
transport channels			information	
			common for	
			all transport	
			channels	
			10.3.5.24	
>>Added or Reconfigured TrCH	MP	1 to		
information		<maxtrch< td=""><td></td><td></td></maxtrch<>		
		>		
>>>Added or Reconfigured UL	MP		Added or	
TrCH information			Reconfigure	
			d UL TrCH	
			information	
Daniel to a series also a la			10.3.5.2	
Downlink transport channels	L L		DI T	
>>DL Transport channel	MP		DL Transport	
information common for all			channel	
transport channels			information	

Information Element/Group name	Need	Multi	Type and reference	Semantics description
			common for all transport channels 10.3.5.6	
>>Added or Reconfigured TrCH information	MP	1 to <maxtrch ></maxtrch 		
>>>Added or Reconfigured DL TrCH information	MP		Added or Reconfigure d DL TrCH information 10.3.5.1	
Uplink radio resources				
>>Uplink DPCH info	MP		Uplink DPCH info 10.3.6.88	
>>CHOICE mode	MP			
>>>FDD				
>>>>CPCH SET Info	OP		CPCH SET Info 10.3.6.13	
Downlink radio resources	0.0			
>>>Downlink PDSCH information	OP		Downlink PDSCH information 10.3.6.30	
>>>TDD				(no data)
>>Downlink information common for all radio links	MP		Downlink information common for all radio links 10.3.6.24	
>>Downlink information per radio link	MP	1 to <maxrl></maxrl>		
>>>Downlink information for each radio link	MP		Downlink information for each radio link 10.3.6.27	
>Preconfiguration				
>>CHOICE Preconfiguration mode	MP			
>>>Predefined configuration	MP		Predefined configuration identity 10.3.4.5	
>>>Default configuration >>>Default configuration mode	MP		Enumerated (FDD, TDD)	Indicates whether the FDD or TDD version of the default configuration shall be used
>>>>Default configuration identity	MP		Default configuration identity 10.3.4.0	
>>RAB info	OP		RAB info Post 10.3.4.9	One RAB is established
>>Uplink DPCH info	MP		Uplink DPCH info Post 10.3.6.89	
Downlink radio resources				
>>Downlink information common for all radio links	MP		Downlink information common for	

Information Element/Group name	Need	Multi	Type and reference	Semantics description
			all radio links Post 10.3.6.25	
>>Downlink information per radio link	MP	1 to <maxrl></maxrl>		Send downlink information for each radio link to be set-up. In TDD MaxRL is 1.
>>>Downlink information for each radio link	MP		Downlink information for each radio link Post 10.3.6.28	
>>CHOICE mode	MP			
>>>FDD				(no data)
>>>TDD				
>>>Primary CCPCH Tx Power	MP		Primary CCPCH Tx Power 10.3.6.59	
Frequency info	MP		Frequency info 10.3.6.36	
Maximum allowed UL TX power	MP		Maximum allowed UL TX power 10.3.6.39	

10.2.16b HANDOVER TO UTRAN COMPLETE

This message is sent by the UE when a handover to UTRAN has been completed.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE \rightarrow UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message	
			Туре	
UE Information elements				
START list	CH	1 to		START [40] values for all CN
		<maxcndo< td=""><td></td><td>domains.</td></maxcndo<>		domains.
		mains>		
>CN domain identity	MP		CN domain	
			identity	
			10.3.1.1	
>START	MP		START	
			10.3.3.38	
RB Information elements				
COUNT-C activation time	OP		Activation	Used for radio bearers
			time	mapped on RLC-TM.
			10.3.3.1	

10.2.16c INITIAL DIRECT TRANSFER

This message is used to initiate a signalling connection based on indication from the upper layers, and to transfer a NAS message.

RLC-SAP: AM

Logical channel: DCCH
Direction: UE -> UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Message Type	MP		Message Type		
UE information elements					
Integrity check info	СН		Integrity check info 10.3.3.16		
CN information elements					
CN domain identity	MP		CN domain identity 10.3.1.1		
Intra Domain NAS Node Selector	MP		Intra Domain NAS Node Selector 10.3.1.6		
NAS message	MP		NAS message 10.3.1.8		
START	OP		START 10.3.3.38	START value to be used in the CN domain as indicated in the IE "CN domain identity". This IE shall always be present in this version of the protocol.	
Establishment cause	OP		Establish ment cause 10.3.3.11		Rel-5
Measurement information elements					
Measured results on RACH	OP		Measured results on RACH 10.3.7.45		

10.2.16d INTER RAT HANDOVER INFO

This message is sent by the UE via another radio access technology to provide information to the target RNC when preparing for a handover to UTRAN.

RLC-SAP: N/A (Sent through a different RAT)

Logical channel: N/A (Sent through a different RAT)

Direction: UE → UTRAN

Information Element/Group Name	Need	Multi	Type and reference	Semantics description	Version
Radio Bearer IEs					
Predefined configuration status information	OP		Predefined configuration status information 10.3.4.5a		
Predefined configuration status information compressed	OP		Predefined configuration status information compressed 10.3.4.5b		REL-5
UE Information elements					
UE security information	ОР		UE security information 10.3.3.42b		
>UE Specific Behaviour Information 1 interRAT	OP		UE Specific Behaviour Information 1 interRAT 10.3.3.52	This IE shall not be included in this version of the protocol	
UE capability container	OP				
>UE radio access capability	MP		UE radio access capability 10.3.3.42		
>UE radio access capability extension	MP		UE radio access capability extension 10.3.3.42a	Although this IE is not always required, the need has been set to MP to align with the ASN.1	
UE radio access capability compressed	OP		UE radio access capability compressed 10.3.3.420		REL-5

10.2.17 MEASUREMENT CONTROL

This message is sent by UTRAN to setup, modify or release a measurement in the UE.

RLC-SAP: AM

Logical channel: DCCH

Direction: UTRAN→UE

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message	
			Type	
UE information elements				
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36	
Integrity check info	СН		Integrity check info 10.3.3.16	
Measurement Information elements				
Measurement Identity	MP		Measuremen t Identity	

Information Element/Group name	Need	Multi	Type and reference	Semantics description
			10.3.7.48	
Measurement Command	MP		Measuremen	
			t Command	
			10.3.7.46	
Measurement Reporting Mode	OP		Measuremen	
1 3			t Reporting	
			Mode	
			10.3.7.49	
Additional measurements list	OP		Additional	
			measuremen	
			ts list	
			10.3.7.1	
CHOICE Measurement type	CV-			
, , , , , , , , , , , , , , , , , , ,	command			
>Intra-frequency measurement			Intra-	
, ,			frequency	
			measuremen	
			t 10.3.7.36	
>Inter-frequency measurement			Inter-	
			frequency	
			measuremen	
			t 10.3.7.16	
>Inter-RAT measurement			Inter-RAT	
			measuremen	
			t 10.3.7.27	
>UE positioning measurement			UE	
			positioning	
			measuremen	
			t 10.3.7.100	
>Traffic Volume measurement			Traffic	
			Volume	
			measuremen	
			t 10.3.7.68	
>Quality measurement			Quality	
			measuremen	
			t 10.3.7.56	
>UE internal measurement			UE internal	
			measuremen	
			t 10.3.7.77	
Physical channel information elements				
DPCH compressed mode status	OP		DPCH	
info			compressed	
			mode status	
			info	
			10.3.6.34	

Condition	Explanation
Command	The IE is mandatory present if the IE "Measurement
	command" is set to "Setup", optional if the IE
	"Measurement command" is set to "modify", otherwise
	the IE is not needed.

10.2.18 MEASUREMENT CONTROL FAILURE

This message is sent by UE, if it cannot initiate a measurement as instructed by UTRAN.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Message Type	MP		Message	
			Type	
UE information elements				
RRC transaction identifier	MP		RRC	
			transaction	
			identifier	
			10.3.3.36	
Integrity check info	CH		Integrity	
			check info	
			10.3.3.16	
Failure cause	MP		Failure	
			cause and	
			error	
			information	
			10.3.3.14	

10.2.19 MEASUREMENT REPORT

This message is used by UE to transfer measurement results to the UTRAN.

RLC-SAP: AM or UM

Logical channel: DCCH

Direction: UE→UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Message Type	MP		Message Type		
UE information elements					
Integrity check info	СН		Integrity check info 10.3.3.16		
Measurement Information Elements					
Measurement identity	MP		Measure ment identity 10.3.7.48		
Measured Results	OP		Measured Results 10.3.7.44		
Measured Results on RACH	OP		Measured Results on RACH 10.3.7.45		
Additional Measured results	OP	1 to <maxad ditional Meas></maxad 			
>Measured Results	MP		Measured Results 10.3.7.44		
Event results	OP		Event results 10.3.7.7		
GSM OTD reference cell	OP		Primary CPICH info 10.3.6.60		REL-4

10.2.20 PAGING TYPE 1

This message is used to send information on the paging channel. One or several UEs, in idle or connected mode, can be paged in one message, which also can contain other information.

RLC-SAP: TM

Logical channel: PCCH Direction: UTRAN \rightarrow UE

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message Type	
UE Information elements				
Paging record list	OP	1 to <maxpage 1></maxpage 		
>Paging record	MP		Paging record 10.3.3.23	
Other information elements				
BCCH modification info	ОР		BCCH modification info 10.3.8.1	

If the encoded message does not fill a transport block, the RRC layer shall add padding according to subclause 12.1.

10.2.21 PAGING TYPE 2

This message is used to page a UE in connected mode, when using the DCCH for CN originated paging.

RLC-SAP: AM

Logical channel: DCCH

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message Type	
UE information elements				
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36	
Integrity check info	СН		Integrity check info 10.3.3.16	
Paging cause	MP		Paging cause 10.3.3.22	
CN Information elements				
CN domain identity	MP		CN domain identity 10.3.1.1	
Paging Record Type Identifier	MP		Paging Record Type Identifier 10.3.1.10	

10.2.22 PHYSICAL CHANNEL RECONFIGURATION

This message is used by UTRAN to assign, replace or release a set of physical channels used by a UE.

RLC-SAP: AM or UM Logical channel: DCCH Direction: UTRAN \rightarrow UE

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Message Type	MP		Message	_	
HELD STATE OF THE			Туре		
UE Information Elements RRC transaction identifier	MP		RRC		
RRC transaction identifier	IMP		transaction		
			identifier		
			10.3.3.36		
Integrity check info	CH		Integrity		
3 7			check info		
			10.3.3.16		
Integrity protection mode info	OP		Integrity	The UTRAN	
			protection	should not include	
			mode info	this IE unless it is	
			10.3.3.19	performing an	
Cinharing made info	OB		Ciphoring	SRNS relocation The UTRAN	
Ciphering mode info	OP		Ciphering mode info	should not include	
			10.3.3.5	this IE unless it is	
			10.0.0.0	performing an	
				SRNS relocation	
				and a change in	
				ciphering	
				algorithm	
Activation time	MD		Activation	Default value is	
Name II DAITI	OD		time 10.3.3.1	"now"	
New U-RNTI	OP		U-RNTI		
New C-RNTI	OP		10.3.3.47 C-RNTI		
New C-KINTI			10.3.3.8		
New DSCH-RNTI	OP		DSCH-RNTI		
			10.3.3.9a		
New H-RNTI	OP		H-RNTI		REL-5
			10.3.3.14a		
RRC State Indicator	MP		RRC State		
			Indicator		
LITE AND DOWN	0.5		10.3.3.35a		
UTRAN DRX cycle length coefficient	OP		UTRAN DRX		
coemcient			cycle length coefficient		
			10.3.3.49		
CN Information Elements	1				
CN Information info	OP		CN		
			Information		
			info 10.3.1.3		
UTRAN mobility information					
URA identity	OP		LIDA idaatitu		
ONA Identity			URA identity 10.3.2.6		
RB information elements			10.0.2.0		
Downlink counter	OP				
synchronisation info					
>RB with PDCP information list	OP	1 to			
		<maxrball< td=""><td></td><td></td><td></td></maxrball<>			
		RABs>			

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
>>RB with PDCP information	MP		RB with PDCP information 10.3.4.22	This IE is needed for each RB having PDCP in the case of lossless SRNS relocation	
	OP				REL-5
>>PDCP context relocation info	OP		PDCP context relocation info 10.3.4.1a	This IE is needed for each RB having PDCP and performing PDCP context relocation	REL-5
PhyCH information elements					
Frequency info	OP		Frequency info 10.3.6.36		
Uplink radio resources					
Maximum allowed UL TX power	MD		Maximum allowed UL TX power 10.3.6.39	Default value is the existing value of the maximum allowed UL TX power	
CHOICE channel requirement	OP				
>Uplink DPCH info			Uplink DPCH info 10.3.6.88		
>CPCH SET Info			CPCH SET Info 10.3.6.13		
>CPCH set ID			CPCH set ID 10.3.5.3		
Downlink radio resources					
CHOICE mode	MP				
>FDD					
>>Downlink PDSCH information	OP		Downlink PDSCH information 10.3.6.30		
>TDD				(no data)	
Downlink HS-PDSCH Information	OP		Downlink HS_PDSCH Information 10.3.6.23a		REL-5
Downlink information common for all radio links	OP		Downlink information common for all radio links 10.3.6.24		
Downlink information per radio link list	OP	1 to <maxrl></maxrl>		Send downlink information for each radio link	
>Downlink information for each radio link	MP		Downlink information for each radio link 10.3.6.27		

10.2.23 PHYSICAL CHANNEL RECONFIGURATION COMPLETE

This message is sent from the UE when a physical channel reconfiguration has been done.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE \rightarrow UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Message Type	MP		Message Type		
UE information elements			1900		
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36		
Integrity check info	СН		Integrity check info 10.3.3.16		
Uplink integrity protection activation info	ОР		Integrity protection activation info 10.3.3.17		
CHOICE mode	MP				
>FDD				(no data)	
>TDD					
>>CHOICE TDD option	MP				REL-4
>>>3.84 Mcps TDD	MP				REL-4
>>>>Uplink Timing Advance	OP		Uplink Timing Advance 10.3.6.95		
>>>1.28 Mcps TDD				(no data)	REL-4
RB Information elements					
COUNT-C activation time	OP		Activation time 10.3.3.1	Used for radio bearers mapped on RLC-TM.	
Radio bearer uplink ciphering activation time info	OP		RB activation time info 10.3.4.13		
Uplink counter synchronisation info	OP				
>RB with PDCP information list	OP	1 to <maxrball RABs></maxrball 			
>>RB with PDCP information	MP		RB with PDCP information 10.3.4.22		
>START list	MP	1 to <maxcndo mains></maxcndo 		START [40] values for all CN domains.	
>>CN domain identity	MP		CN domain identity 10.3.1.1		
>>START	MP		START 10.3.3.38	START value to be used in this CN domain.	

10.2.24 PHYSICAL CHANNEL RECONFIGURATION FAILURE

This message is sent by UE if the configuration given by UTRAN is unacceptable or if the UE failed to assign, replace or release a set of physical channel(s).

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message type	MP		Message	
UE information elements			type	
RRC transaction identifier	OP		RRC transaction identifier 10.3.3.36	
Integrity check info	CH		Integrity check info 10.3.3.16	
Failure cause	MP		Failure cause and error information 10.3.3.14	

10.2.25 PHYSICAL SHARED CHANNEL ALLOCATION

NOTE: Only for TDD.

This message is used by UTRAN to assign physical resources to USCH/DSCH transport channels in TDD, for temporary usage by the UE.

RLC-SAP: UM on SHCCH, UM on DCCH

Logical channel: SHCCH or DCCH

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message	
			type	
DSCH-RNTI	OP		DSCH-RNTI	
			10.3.3.9a	
RRC transaction identifier	MP		RRC	
			transaction	
			identifier	
			10.3.3.36	
Uplink timing advance Control	MD		Uplink	Default value is the existing
			Timing	value for uplink timing advance
			Advance	
			Control	
			10.3.6.96	
PUSCH capacity allocation info	OP		PUSCH	
			Capacity	
			Allocation	
			info	
			10.3.6.64	
PDSCH capacity allocation info	OP		PDSCH	
			Capacity	
			Allocation	
			info	
			10.3.6.42	
Confirm request	MD		Enumerated(Default value is No Confirm
			No Confirm,	
			Confirm	
			PDSCH,	
			Confirm	
			PUSCH)	

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Traffic volume report request	OP		Integer (0 255)	Indicates the number of frames between start of the allocation period and sending measurement report. The value should be less than the value for Allocation Duration.
ISCP Timeslot list	OP	1 to maxTS		
>Timeslot number	MP		Timeslot number 10.3.6.84	Timeslot numbers, for which the UE shall report the timeslot ISCP in PUSCH CAPACITY REQUEST message.
Request P-CCPCH RSCP	MP		Boolean	TRUE indicates that a Primary CCPCH RSCP measurement shall be reported by the UE in PUSCH CAPACITY REQUEST message.

10.2.26 PUSCH CAPACITY REQUEST

NOTE: Only for TDD.

This message is used by the UE for request of PUSCH resources to the UTRAN.

RLC-SAP: TM

Logical channel: SHCCH

Direction: UE \rightarrow UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message	
DSCH-RNTI	OP		Type DSCH-RNTI 10.3.3.9a	
RRC transaction identifier	CV-ProtErr		RRC transaction identifier 10.3.3.36	
Traffic Volume	OP		Traffic Volume, measured results list 10.3.7.67	
Timeslot list	OP	1 to maxTS		
>Timeslot number	MP		Timeslot number 10.3.6.84	
>Timeslot ISCP	MP		Timeslot ISCP info 10.3.7.65	
Primary CCPCH RSCP	OP		Primary CCPCH RSCP info 10.3.7.54	
CHOICE Allocation confirmation	OP			
>PDSCH Confirmation			Integer(1hi PDSCHident ities)	
>PUSCH Confirmation			Integer(1hi PUSCHident ities)	

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Protocol error indicator	MD		Protocol	Default value is FALSE
			error	
			indicator	
			10.3.3.27	
Protocol error information	CV-ProtErr		Protocol	
			error	
			information	
			10.3.8.12	

Condition	Explanation		
ProtErr	This IE is mandatory present if the IE "Protocol error indicator" has the value "TRUE". Otherwise it is not		
	needed.		

10.2.27 RADIO BEARER RECONFIGURATION

This message is sent from UTRAN to reconfigure parameters related to a change of QoS. This procedure can also change the multiplexing of MAC, reconfigure transport channels and physical channels. This message is also used to perform a handover from GERAN *Iu mode* to UTRAN.

RLC-SAP: AM or UM or sent through GERAN Iu mode

Logical channel: DCCH or sent through GERAN Iu mode

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			reference	description	
Message Type	MP		Message		
			Туре		
UE Information elements					
RRC transaction identifier	MP		RRC		
			transaction		
			identifier		
			10.3.3.36		
Integrity check info	CH		Integrity		
			check info		
			10.3.3.16		
Integrity protection mode info	OP		Integrity	The UTRAN	
			protection	should not include	
			mode info	this IE unless it is	
			10.3.3.19	performing an	
				SRNS relocation	
				or a handover	
				from GERAN Iu	
0:1:	0.0		0.1.	mode	
Ciphering mode info	OP		Ciphering	The UTRAN	
			mode info	should not include	
			10.3.3.5	this IE unless it is	
				performing either	
				an SRNS	
				relocation or a	
				handover from	
				GERAN lu mode	
				and a change in	
				ciphering	
Activation time	MD		Activation	algorithm Default value is	
Activation time	IVID			Default value is "now"	
New U-RNTI	OP		time 10.3.3.1 U-RNTI	HOW	
New U-KNII	UP		10.3.3.47		
New C DNTI	OB				
New C-RNTI	OP		C-RNTI		

Information Element/Group Nee name		Multi	Type and reference	Semantics description	Version
N. BOOLL BAIT!	0.0		10.3.3.8		
New DSCH-RNTI	OP		DSCH-RNTI		
New H-RNTI	OP		10.3.3.9a H-RNTI		REL-5
New H-RIVII	OP		10.3.3.14a		KEL-3
RRC State Indicator	MP		RRC State		
Tive State Indicator	IVII		Indicator		
			10.3.3.35a		
UTRAN DRX cycle length	OP		UTRAN DRX		
coefficient	01		cycle length		
			coefficient		
			10.3.3.49		
CN information elements					
CN Information info	OP		CN		
Or mornador mo			Information		
			info 10.3.1.3		
UTRAN mobility information			1110 10.0.1.0		
elements					
URA identity	OP		URA identity		1
5.0 (lashing	.		10.3.2.6		
CHOICE specification mode	MP		10.0.2.0		REL-5
>Complete specification	1				1 3
RB information elements					1
>>RAB information to	OP	1 to <			
reconfigure list	01	maxRABse			
Toodingure list		tup >			
>>>RAB information to	MP	tup /	RAB		
reconfigure	'''		information		
1 Toodinigato			to		
			reconfigure		
			10.3.4.11		
>>RB information to reconfigure	MP	1to		Although this IE is	
list		<maxrb></maxrb>		not always	
				required, need is	
				MP to align with	
				ASN.1	
	OP				REL-4
>>>RB information to	MP		RB		
reconfigure			information		
<u> </u>			to		
			reconfigure		
			10.3.4.18		
>>RB information to be affected	OP	1 to			
list		<maxrb></maxrb>			
>>>RB information to be	MP		RB		
affected			information		
			to be		
			affected		
			10.3.4.17		
>>RB with PDCP context	OP	1 to		This IE is needed	REL-5
relocation info list		<maxrball< td=""><td></td><td>for each RB</td><td></td></maxrball<>		for each RB	
		RABs>		having PDCP and	
				performing PDCP	
				context relocation	ļ
>>>PDCP context relocation info	MP		PDCP		REL-5
			context		
			relocation		
			info		
	<u> </u>	1	10.3.4.1a		ļ
TrCH Information Elements	<u> </u>	1			ļ
Uplink transport channels					
>>UL Transport channel	OP		UL Transport		
information common for all			channel		
transport channels			information		
			common for		

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
			all transport channels 10.3.5.24		
>>Deleted TrCH information list	OP	1 to <maxtrch></maxtrch>			
>>>Deleted UL TrCH information	MP		Deleted UL TrCH information 10.3.5.5		
>>Added or Reconfigured TrCH information list	OP	1 to <maxtrch ></maxtrch 			
>>>Added or Reconfigured UL TrCH information	MP		Added or Reconfigure d UL TrCH information 10.3.5.2		
>>CHOICE mode	OP				
>>>FDD	OB		ODOLL 125		
>>>>CPCH set ID	OP		CPCH set ID 10.3.5.3		
>>>>Added or Reconfigured TrCH information for DRAC list	OP	1 to <maxtrch ></maxtrch 			
>>>>DRAC static information	MP		DRAC static information 10.3.5.7		
>>>TDD				(no data)	
Downlink transport channels					
>>DL Transport channel information common for all transport channels	OP		DL Transport channel information common for all transport channels 10.3.5.6		
>>Deleted TrCH information list	OP	1 to <maxtrch ></maxtrch 			
>>>Deleted DL TrCH information	MP		Deleted DL TrCH information 10.3.5.4		
>>Added or Reconfigured TrCH information list	OP	1 to <maxtrch ></maxtrch 			
>>>Added or Reconfigured DL TrCH information	MP		Added or Reconfigure d DL TrCH information 10.3.5.1		

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
>Preconfiguration			1010101100		REL-5
>>CHOICE Preconfiguration mode	MP				
>>>Predefined configuration identity	MP		Predefined configuration identity 10.3.4.5		
>>>Default configuration >>>>Default configuration mode	MP			Indicates whether	
>>>Default configuration mode	IVIP		Enumerated (FDD, TDD)	the FDD or TDD version of the default configuration shall be used	
>>>Default configuration identity	MP		Default configuration identity 10.3.4.0		
PhyCH information elements					
Frequency info	OP		Frequency info 10.3.6.36		
Uplink radio resources					
Maximum allowed UL TX power	MD		Maximum allowed UL TX power 10.3.6.39	Default value is the existing maximum UL TX power	
CHOICE channel requirement	OP				
>Uplink DPCH info			Uplink DPCH info 10.3.6.88		
>CPCH SET Info			CPCH SET Info 10.3.6.13		
Downlink radio resources					
CHOICE mode	MP				
>FDD					
>>Downlink PDSCH information	OP		Downlink PDSCH information 10.3.6.30		
>TDD				(no data)	
Downlink HS-PDSCH Information	OP		Downlink HS-PDSCH Information 10.3.6.23a		REL-5
Downlink information common for all radio links	OP		Downlink information common for all radio links 10.3.6.24		
Downlink information per radio link list	MP	1 to <maxrl></maxrl>		Although this IE is not always required, need is MP to align with ASN.1	
	OP				REL-4
>Downlink information for each radio link	MP		Downlink information for each radio link 10.3.6.27		

10.2.28 RADIO BEARER RECONFIGURATION COMPLETE

This message is sent from the UE when a RB and signalling link reconfiguration has been done.

RLC-SAP: AM

Logical channel: DCCH $\label{eq:DCCH} \mbox{Direction: UE} \rightarrow \mbox{UTRAN}$

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Message Type	MP		Message Type		
UE information elements			Туре		
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36		
Integrity check info	СН		Integrity check info 10.3.3.16		
Uplink integrity protection activation info	ОР		Integrity protection activation info 10.3.3.17		
CHOICE mode	MP				
>FDD				(no data)	
>TDD					
>>CHOICE TDD option	MP				REL-4
>>>3.84 Mcps TDD					REL-4
>>>>Uplink Timing Advance	OP		Uplink Timing Advance 10.3.6.95		
>>>1.28 Mcps TDD				(no data)	REL-4
RB Information elements					
COUNT-C activation time	OP		Activation time 10.3.3.1	Used for radio bearers mapped on RLC-TM.	
Radio bearer uplink ciphering activation time info	OP		RB activation time info 10.3.4.13		
Uplink counter synchronisation info	OP				
>RB with PDCP information list	OP	1 to <maxrball RABs></maxrball 			
>>RB with PDCP information	MP		RB with PDCP information 10.3.4.22		
>START list	MP	1 to <maxcndo mains></maxcndo 		START [40] values for all CN domains.	
>>CN domain identity	MP		CN domain identity 10.3.1.1		
>>START	MP		START 10.3.3.38	START value to be used in this CN domain.	

10.2.29 RADIO BEARER RECONFIGURATION FAILURE

This message is sent by UE if the configuration given by UTRAN is unacceptable or if the UE failed to establish the physical channel(s).

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message Type	
UE information elements				
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36	
Integrity check info	СН		Integrity check info 10.3.3.16	
Failure cause	MP		Failure cause and error information 10.3.3.14	
RB information elements				
Radio bearers for which reconfiguration would have succeeded List	OP	1 to <maxrb></maxrb>		
>Radio bearer for which reconfiguration would have succeeded	MP		RB identity, 10.3.4.16	

10.2.30 RADIO BEARER RELEASE

This message is used by UTRAN to release a radio bearer. It can also include modifications to the configurations of transport channels and/or physical channels. It can simultaneously indicate release of a signalling connection when UE is connected to more than one CN domain.

RLC-SAP: AM or UM

Logical channel: DCCH

Information Element/Group	Need	Multi	Type and	Semantics description	Version
name			reference		
Message Type	MP		Message		
			Type		
UE Information Elements					
RRC transaction identifier	MP		RRC		
			transaction		
			identifier		
			10.3.3.36		
Integrity check info	CH		Integrity		
			check info		
			10.3.3.16		
Integrity protection mode info	OP		Integrity	The UTRAN should not	
			protection	include this IE unless it is	
			mode info	performing an SRNS	
			10.3.3.19	relocation.	
Ciphering mode info	OP		Ciphering	The UTRAN should not	

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
			mode info 10.3.3.5	include this IE unless it is performing an SRNS relocation and a change in ciphering algorithm.	
Activation time	MD		Activation time 10.3.3.1	Default value is "now"	
New U-RNTI	OP		U-RNTI 10.3.3.47		
New C-RNTI	OP		C-RNTI 10.3.3.8		
New DSCH-RNTI	OP		DSCH-RNTI 10.3.3.9a		
New H-RNTI	OP		H-RNTI 10.3.3.14a		REL-5
RRC State Indicator	MP		RRC State Indicator 10.3.3.35a		
UTRAN DRX cycle length coefficient	OP		UTRAN DRX cycle length coefficient 10.3.3.49		
CN Information Elements					
CN Information info	OP		CN Information info 10.3.1.3		
Signalling Connection release indication	OP		CN domain identity 10.3.1.1		
UTRAN mobility information elements					
URA identity	OP		URA identity 10.3.2.6		
RB Information Elements			10.0.2.0		
RAB information to reconfigure list	ОР	1 to < maxRABse tup >			
>RAB information to reconfigure	MP		RAB information to reconfigure 10.3.4.11		
RB information to release list	MP	1 to <maxrb></maxrb>	10.0.4.11		
>RB information to release	MP	anioxi (S)	RB information to release 10.3.4.19		
RB information to be affected list	OP	1 to <maxrb></maxrb>			
>RB information to be affected	MP		RB information to be affected 10.3.4.17		
Downlink counter synchronisation info	OP		10.0.1.17		
>RB with PDCP information list	OP	1 to <maxrball RABs></maxrball 			
>>RB with PDCP information	MP		RB with PDCP information 10.3.4.22	This IE is needed for each RB having PDCP in the case of lossless SRNS relocation	
	OP				REL-5
>RB with PDCP context	OP	1 to			REL-5

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
relocation info list		<maxrball RABs></maxrball 			
>>PDCP context relocation info	MP		PDCP context relocation info 10.3.4.1a	This IE is needed for each RB having PDCP and performing PDCP context relocation	REL-5
TrCH Information Elements					
Uplink transport channels					
UL Transport channel information common for all transport channels	OP		UL Transport channel information common for all transport channels 10.3.5.24		
Deleted TrCH information list	OP	1 to <maxtrch ></maxtrch 			
>Deleted UL TrCH information	MP		Deleted UL TrCH information 10.3.5.5		
Added or Reconfigured TrCH information list	OP	1 to <maxtrch ></maxtrch 			
>Added or Reconfigured UL TrCH information	MP		Added or Reconfigure d UL TrCH information 10.3.5.2		
CHOICE mode	OP				
>FDD					
>>CPCH set ID	OP		CPCH set ID 10.3.5.3		
>>Added or Reconfigured TrCH information for DRAC list	OP	1 to <maxtrch ></maxtrch 			
>>>DRAC static information	MP		DRAC static information 10.3.5.7		
>TDD				(no data)	
Downlink transport channels					
DL Transport channel information common for all transport channels	OP		DL Transport channel information common for all transport channels 10.3.5.6		
Deleted TrCH information list	OP	1 to <maxtrch< td=""><td>10.0.0.0</td><td></td><td></td></maxtrch<>	10.0.0.0		
>Deleted DL TrCH information	MP	>	Deleted DL TrCH information 10.3.5.4		
Added or Reconfigured TrCH information list	OP	1 to <maxtrch< td=""><td></td><td></td><td></td></maxtrch<>			
>Added or Reconfigured DL TrCH information	MP		Added or Reconfigure d DL TrCH information 10.3.5.1		

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
PhyCH information elements					
Frequency info	OP		Frequency info 10.3.6.36		
Uplink radio resources					
Maximum allowed UL TX power	MD		Maximum allowed UL TX power 10.3.6.39	Default value is the existing maximum UL TX power	
CHOICE channel requirement	OP				
>Uplink DPCH info			Uplink DPCH info 10.3.6.88		
>CPCH SET Info			CPCH SET Info 10.3.6.13		
Downlink radio resources					
CHOICE mode	MP				
>FDD					
>>Downlink PDSCH information	OP		Downlink PDSCH information 10.3.6.30		
>TDD				(no data)	
Downlink HS-PDSCH Information	OP		Downlink HS-PDSCH Information 10.3.6.23a		REL-5
Downlink information common for all radio links	OP		Downlink information common for all radio links 10.3.6.24		
Downlink information per radio link list	OP	1 to <maxrl></maxrl>		Send downlink information for each radio link to be set-up	
>Downlink information for each radio link	MP		Downlink information for each radio link 10.3.6.27		

10.2.31 RADIO BEARER RELEASE COMPLETE

This message is sent from the UE when radio bearer release has been completed.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE \rightarrow UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Message Type	MP		Message		
UE information elements			Type		
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36		
Integrity check info	СН		Integrity check info 10.3.3.16	Integrity check info is included if integrity protection	

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
				is applied	
Uplink integrity protection activation info	OP		Integrity protection activation info 10.3.3.17		
CHOICE mode	MP				
>FDD	1			(no data)	
>TDD					
>>CHOICE TDD option	MP				REL-4
>>>3.84 Mcps TDD					REL-4
>>>Uplink Timing Advance	OP		Uplink Timing Advance 10.3.6.95	This information element shall be present in case of handover procedure if timing advance is enabled. Calculated timing advance value for the new cell after handover in a synchronous TDD network	
>>>1.28 Mcps TDD				(no data)	REL-4
RB Information elements					
COUNT-C activation time	OP		Activation time 10.3.3.1	Used for radio bearers mapped on RLC-TM.	
Radio bearer uplink ciphering activation time info	OP		RB activation time info 10.3.4.13		
Uplink counter synchronisation info	OP				
>RB with PDCP information list	OP	1 to <maxrball RABs></maxrball 		This IE is needed for each RB having PDCP in the case of lossless SRNS relocation	
>>RB with PDCP information	MP		RB with PDCP information 10.3.4.22		
>START list	MP	1 to <maxcndo mains></maxcndo 		START [40] values for all CN domains.	
>>CN domain identity	MP		CN domain identity 10.3.1.1		
>>START	MP		START 10.3.3.38	START value to be used in this CN domain.	

10.2.32 RADIO BEARER RELEASE FAILURE

This message is sent by UE if the configuration given by UTRAN is unacceptable or if radio bearer cannot be released.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message Type	
UE information elements				
RRC transaction identifier	MP		RRC	
			transaction identifier 10.3.3.36	
Integrity check info	СН		Integrity check info 10.3.3.16	
Failure cause	MP		Failure cause and error information 10.3.3.14	
RB information elements				
Radio bearers for which reconfiguration would have succeeded	OP	1 to <maxrb></maxrb>		
>Radio bearer for which reconfiguration would have been succeeded	MP		RB identity, 10.3.4.16	

10.2.33 RADIO BEARER SETUP

This message is sent by UTRAN to the UE to establish new radio bearer(s). It can also include modifications to the configurations of transport channels and/or physical channels.

RLC-SAP: AM or UM

Logical channel: DCCH

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Message Type	MP		Message Type		
UE Information Elements			. , , , ,		
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36		
Integrity check info	СН		Integrity check info 10.3.3.16		
Integrity protection mode info	OP		Integrity protection mode info 10.3.3.19	The UTRAN should not include this IE unless it is performing an SRNS relocation	
Ciphering mode info	OP		Ciphering mode info 10.3.3.5	The UTRAN should not include this IE unless it is performing an SRNS relocation and a change in ciphering algorithm	
Activation time	MD		Activation time 10.3.3.1	Default value is "now"	

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
New U-RNTI	OP		U-RNTI 10.3.3.47		
New C-RNTI	OP		C-RNTI 10.3.3.8		
New DSCH-RNTI	OP		DSCH-RNTI 10.3.3.9a		
New H-RNTI	OP		H-RNTI 10.3.3.14a		REL-5
RRC State Indicator	MP		RRC State Indicator 10.3.3.35a		
UTRAN DRX cycle length coefficient	OP		UTRAN DRX cycle length coefficient 10.3.3.49		
CN Information Elements					
CN Information info	OP		CN Information info 10.3.1.3		
UTRAN mobility information elements					
URA identity	OP		URA identity 10.3.2.6		
RB Information Elements					
Signalling RB information to setup list	OP	1 to <maxsrbs etup></maxsrbs 		For each signalling radio bearer established	
>Signalling RB information to setup	MP		Signalling RB information to setup 10.3.4.24		
RAB information to setup list	OP	1 to <maxrabs etup></maxrabs 		For each RAB established	
>RAB information for setup	MP		RAB information for setup 10.3.4.10		
RB information to be affected list	OP	1 to <maxrb></maxrb>			
>RB information to be affected	MP		RB information to be affected 10.3.4.17		
Downlink counter synchronisation info	OP				
>RB with PDCP information list	ОР	1 to <maxrball RABs></maxrball 			
>>RB with PDCP information	MP		RB with PDCP information 10.3.4.22	This IE is needed for each RB having PDCP in the case of lossless SRNS relocation	
	OP				REL-5
>>PDCP context relocation info	OP		PDCP context relocation info 10.3.4.1a	This IE is needed for each RB having PDCP and performing PDCP context relocation	REL-5
TrCH Information Elements					
Uplink transport channels					

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
UL Transport channel information common for all transport channels	OP		UL Transport channel information common for all transport channels 10.3.5.24		
Deleted TrCH information list	OP	1 to <maxtrch< td=""><td></td><td></td><td></td></maxtrch<>			
>Deleted UL TrCH information	MP		Deleted UL TrCH information 10.3.5.5		
Added or Reconfigured TrCH information list	OP	1 to <maxtrch></maxtrch>			
>Added or Reconfigured UL TrCH information	MP		Added or Reconfigure d UL TrCH information 10.3.5.2		
CHOICE mode	OP				
>FDD >>CPCH set ID	OP		CPCH set ID 10.3.5.3		
>>Added or Reconfigured TrCH information for DRAC list	OP	1 to <maxtrch ></maxtrch 			
>>>DRAC static information	MP		DRAC static information 10.3.5.7		
>TDD				(no data)	
Downlink transport channels DL Transport channel information common for all transport channels	OP		DL Transport channel information common for all transport channels10. 3.5.6		
Deleted TrCH information list	OP	1 to <maxtrch< td=""><td></td><td></td><td></td></maxtrch<>			
>Deleted DL TrCH information	MP		Deleted DL TrCH information 10.3.5.4		
Added or Reconfigured TrCH information list	OP	1 to <maxtrch ></maxtrch 			
>Added or Reconfigured DL TrCH information	MP		Added or Reconfigure d DL TrCH information 10.3.5.1		
PhyCH information elements					
Frequency info	OP		Frequency info 10.3.6.36		
Uplink radio resources					
Maximum allowed UL TX power	MD		Maximum allowed UL TX power 10.3.6.39	Default value is the existing maximum UL TX power	

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
CHOICE channel requirement	OP				
>Uplink DPCH info			Uplink DPCH info 10.3.6.88		
>CPCH SET Info			CPCH SET Info 10.3.6.13		
Downlink radio resources					
CHOICE mode	MP				
>FDD					
>>Downlink PDSCH information	OP		Downlink PDSCH information 10.3.6.30		
>TDD				(no data)	
Downlink HS-PDSCH Information	OP		Downlink HS-PDSCH Information 10.3.6.23a		REL-5
Downlink information common for all radio links	OP		Downlink information common for all radio links 10.3.6.24		
Downlink information per radio link list	OP	1 to <maxrl></maxrl>		Send downlink information for each radio link	
>Downlink information for each radio link	MP		Downlink information for each radio link 10.3.6.27		

10.2.34 RADIO BEARER SETUP COMPLETE

This message is sent by the UE to confirm the establishment of the radio bearer.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE \rightarrow UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Message Type	MP		Message Type		
UE information elements					
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36		
Integrity check info	СН		Integrity check info 10.3.3.16		
Uplink integrity protection activation info	OP		Integrity protection activation info 10.3.3.17		
CHOICE mode	OP				
>FDD				(no data)	
>TDD					

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
>>CHOICE TDD option	MP			•	REL-4
>>>3.84 Mcps TDD					REL-4
>>>>Uplink Timing Advance	OP		Uplink Timing Advance 10.3.6.95	This information element shall be present in case of handover procedure if timing advance is enabled. Calculated timing advance value for the new cell after handover in a synchronous TDD network	
>>>1.28 Mcps TDD	1			(No data)	REL-4
START	OP		START 10.3.3.38	This information element is not needed for transparent mode RBs if prior to this procedure there exists one RB using RLC-TM.	
RB Information elements					
COUNT-C activation time	OP		Activation time 10.3.3.1	Used for radio bearers mapped on RLC-TM.	
Radio bearer uplink ciphering activation time info	OP		RB activation time info 10.3.4.13		
Uplink counter synchronisation info	OP				
>RB with PDCP information list	OP	1 to <maxrball RABs></maxrball 		This IE is needed for each RB having PDCP in the case of lossless SRNS relocation	
>>RB with PDCP information	MP		RB with PDCP information 10.3.4.22		
>START list	MP	1 to <maxcndo mains></maxcndo 		START [40] values for all CN domains.	
>>CN domain identity	MP		CN domain identity 10.3.1.1		
>>START	MP		START 10.3.3.38	START value to be used in this CN domain.	

10.2.35 RADIO BEARER SETUP FAILURE

This message is sent by UE, if it does not support the configuration given by UTRAN.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message Type	
UE information elements				
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36	
Integrity check info	CH		Integrity check info 10.3.3.16	
Failure cause	MP		Failure cause and error information 10.3.3.14	
RB information elements				
Radio bearers for which reconfiguration would have succeeded	OP	1 to <maxrb></maxrb>		
>Radio bearer for which reconfiguration would have succeeded	MP		RB identity, 10.3.4.16	

10.2.36 RRC CONNECTION REJECT

The network transmits this message when the requested RRC connection cannot be accepted.

RLC-SAP: UM

Logical channel: CCCH

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message Type	
UE information elements				
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36	
Initial UE identity	MP		Initial UE identity 10.3.3.15	
Rejection cause	MP		Rejection cause 10.3.3.31	
Wait time	MP		Wait time 10.3.3.50	
Redirection info	OP		Redirection info 10.3.3.29	

10.2.37 RRC CONNECTION RELEASE

This message is sent by UTRAN to release the RRC connection. The message also releases the signalling connection and all radio bearers between the UE and UTRAN.

RLC-SAP: UM

Logical channel: CCCH or DCCH

Direction: UTRAN→UE

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Message Type	MP		Message Type		
UE information elements					
CHOICE identity type	CV- CCCH				REL-5
>U-RNTI			U-RNTI 10.3.3.47		
> Group identity		1 to <maxur NTIgrou p></maxur 			REL-5
>>Group release information	MP		Group release informatio n 10.3.3.14		REL-5
RRC transaction identifier	MP		RRC transactio n identifier 10.3.3.36		
Integrity check info	CV- DCCH		Integrity check info 10.3.3.16	Integrity check info is included if integrity protection is applied	
N308	CH- Cell_DC H		Integer(1 8)		
Release cause	MP		Release cause 10.3.3.32		
Other information elements					
Rplmn information	OP		Rplmn informatio n 10.3.8.15		

Condition	Explanation
CCCH	This IE is mandatory present when CCCH is used and
	not needed otherwise.
DCCH	This IE is mandatory present when DCCH is used and
	not needed otherwise.
Cell_DCH	This IE is mandatory present when UE is in
	CELL_DCH state and not needed otherwise.

10.2.38 RRC CONNECTION RELEASE COMPLETE

This message is sent by UE to confirm that the RRC connection has been released.

RLC-SAP: AM or UM Logical channel: DCCH Direction: UE \rightarrow UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message	
			Type	
UE information elements				
RRC transaction identifier	MP		RRC	
			transaction	
			identifier	
			10.3.3.36	
Integrity check info	CH		Integrity	
			check info	
			10.3.3.16	
Error indication	OP		Failure	
			cause and	
			error	
			information	
			10.3.3.14	

10.2.39 RRC CONNECTION REQUEST

RRC Connection Request is the first message transmitted by the UE when setting up an RRC Connection to the network.

RLC-SAP: TM

Logical channel: CCCH

Direction: UE → UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Message Type	MP		Message Type		
Radio Bearer IEs					
Predefined configuration status information	MP		Boolean	True indicates the UE has all preconfigurations stored with the same value tag as broadcast in the cell in which the RRC connection establishment is initiated	REL-5
UE information elements					
Initial UE identity	MP		Initial UE identity 10.3.3.15		
Establishment cause	MP		Establishme nt cause 10.3.3.11		
Protocol error indicator	MD		Protocol error indicator 10.3.3.27	Default value is FALSE	
>UE Specific Behaviour Information 1 idle	OP		UE Specific Behaviour Information 1 idle 10.3.3.51	This IE shall not be included in this version of the protocol	
Measurement information elements					
Measured results on RACH	OP		Measured results on RACH 10.3.7.45		
Access stratum release indicator	MP		Enumerated(REL-4,	Absence of the IE implies R99. The IE also indicates the release of the RRC transfer syntax supported by the UE 14 spare values are needed	REL-4

If the encoded message does not fill a transport block, the RRC layer shall insert padding according to subclause 12.1.

10.2.40 RRC CONNECTION SETUP

This message is used by the network to accept the establishment of an RRC connection for a UE, including assignment of signalling link information, transport channel information and optionally physical channel information.

RLC-SAP: UM

Logical channel: CCCH

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Message Type	MP		Message Type		

386

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
UE Information Elements					
Initial UE identity	MP		Initial UE		
			identity		
			10.3.3.15		
RRC transaction identifier	MP		RRC		
			transaction		
			identifier		
			10.3.3.36		
Activation time	MD		Activation	Default value is	
			time 10.3.3.1	"now"	
New U-RNTI	MP		U-RNTI		
			10.3.3.47		
New C-RNTI	OP		C-RNTI		
			10.3.3.8		
RRC State Indicator	MP		RRC State		
			Indicator		
			10.3.3.35a		
UTRAN DRX cycle length	MP		UTRAN DRX		
coefficient			cycle length		
			coefficient		
			10.3.3.49		
Capability update requirement	MD	1	Capability	Default value is	
Capability apadio requirement	IVID		update	defined in	
			requirement	subclause	
			10.3.3.2	10.3.3.2	
CHOICE specification mode	MP		10.0.0.2	10.0.0.2	REL-5
>Complete specification	IVIF				NEL-3
RB Information Elements					
	MD	0.45.4			
>>Signalling RB information to setup list	MP	3 to 4			
>>>Signalling RB information to	MP		Signalling		
setup			RB		
			information		
			to setup		
			10.3.4.24		
TrCH Information Elements					
Uplink transport channels					
>>UL Transport channel	OP		UL Transport		
information common for all			channel		
transport channels			information		
·			common for		
			all transport		
			channels		
			10.3.5.24		
>>Added or Reconfigured TrCH	MP	1 to		Although this IE is	
information list		<maxtrch< td=""><td></td><td>not required when</td><td></td></maxtrch<>		not required when	
in omidion not		> <		the IE "RRC state	
				indicator" is set to	
				"CELL_FACH",	
				need is MP to	
<u> </u>	00		1	align with ASN.1	חבי נ
	OP	1			REL-4
>>>Added or Reconfigured UL	MP		Added or		
TrCH information			Reconfigure		
			d UL TrCH		
			information		
			10.3.5.2		
Downlink transport channels					
>>DL Transport channel	OP		DL Transport		
information common for all			channel		
transport channels			information		
			common for		
				i	i .
			all transport		
			all transport channels		

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
>>Added or Reconfigured TrCH information list	MP	1 to <maxtrch ></maxtrch 	15.5.01100	Although this IE is not required when the IE "RRC state indicator" is set to "CELL_FACH", need is MP to align with ASN.1	
	OP				REL-4
>>>Added or Reconfigured DL TrCH information	MP		Added or Reconfigure d DL TrCH information 10.3.5.1		
>Preconfiguration					REL-5
>>CHOICE Preconfiguration mode	MP				REL-5
>>>Predefined configuration identity	MP		Predefined configuration identity 10.3.4.5		REL-5
>>>Default configuration					REL-5
>>>Default configuration mode	MP		Enumerated (FDD, TDD)	Indicates whether the FDD or TDD version of the default configuration shall be used	REL-5
>>>Default configuration identity	MP		Default configuration identity 10.3.4.0		REL-5
PhyCH information elements					
Frequency info	OP		Frequency info 10.3.6.36		
Uplink radio resources	145			5 (); .	
Maximum allowed UL TX power	MD		Maximum allowed UL TX power 10.3.6.39	Default value is the existing maximum UL TX power	
CHOICE channel requirement	OP				
>Uplink DPCH info			Uplink DPCH info 10.3.6.88		
>CPCH SET Info			CPCH SET Info 10.3.6.13		
Downlink radio resources					
Downlink information common for all radio links	OP		Downlink information common for all radio links 10.3.6.24		
Downlink information per radio link list	OP	1 to <maxrl></maxrl>		Send downlink information for each radio link to be set-up	
>Downlink information for each radio link	MP		Downlink information for each radio link 10.3.6.27		

10.2.41 RRC CONNECTION SETUP COMPLETE

This message confirms the establishment of the RRC Connection by the UE.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE → UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message Type	
UE Information Elements				
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36	
START list	MP	1 to <maxcndo mains></maxcndo 		START [40] values for all CN domains.
>CN domain identity	MP		CN domain identity 10.3.1.1	
>START	MP		START 10.3.3.38	START value to be used in this CN domain.
UE radio access capability	OP		UE radio access capability 10.3.3.42	
UE radio access capability extension	OP		UE radio access capability extension 10.3.3.42a	
Other information elements				
UE system specific capability	OP	1 to <maxinter SysMessa ges></maxinter 		
>Inter-RAT UE radio access capability	MP		Inter-RAT UE radio access capability 10.3.8.7	

10.2.41a RRC FAILURE INFO

This message is sent by the UE via another radio access technology to provide information about the cause for failure to perform the requested operation.

RLC-SAP: N/A (Sent through a different RAT)

Logical channel: N/A (Sent through a different RAT)

Direction: UE \rightarrow UTRAN

Information Element/Group	Need	Multi	Type and	Semantics description
Name			reference	
Other Information elements				
Failure cause	MP		Failure	
			cause	
			10.3.3.13	
Protocol error information	CV-ProtErr		Protocol	
			error	
			information	
			10.3.8.12	

Condition	Explanation
ProtErr ProtErr	Presence is mandatory if the IE "Failure cause" has
	the value "Protocol error"; otherwise the element is
	not needed in the message.

10.2.42 RRC STATUS

This message is sent to indicate a protocol error.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message Type	
UE information elements				
Integrity check info	CH		Integrity check info 10.3.3.16	Integrity check info is included if integrity protection is applied
Identification of received message	CV- Message identified			
>Received message type	MP		Message Type	
>RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36	
Other information elements				
Protocol error information	MP		Protocol error information 10.3.8.12	

Condition	Explanation
Message identified	This IE is mandatory present if the IE "Protocol error cause" in the
	IE "Protocol error information" has any other value than "ASN.1
	violation or encoding error" or "Message type non-existent or not
	implemented" and not needed otherwise.

10.2.43 SECURITY MODE COMMAND

This message is sent by UTRAN to start or reconfigure ciphering and/or integrity protection parameters.

RLC-SAP: AM

Logical channel: DCCH

Direction: UTRAN to UE

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message	
			Туре	
UE information elements				
RRC transaction identifier	MP		RRC transaction	
			identifier	
			10.3.3.36	
Integrity check info	MP		Integrity	
3 7			check info	
			10.3.3.16	
Security capability	MP		Security	
			capability	
			10.3.3.37	
Ciphering mode info	OP		Ciphering	Only present if ciphering shall
			mode info	be controlled
	0.0		10.3.3.5	
Integrity protection mode info	OP		Integrity	Only present if integrity
			protection mode info	protection shall be controlled
			10.3.3.19	
CN Information elements			10.3.3.19	
CN domain identity	MP		CN domain	Indicates which cipher and
,			identity	integrity protection keys are
			10.3.1.1	applicable
Other information elements				
UE system specific security	CH	1 to		This IE is included if the IE
capability		<maxinter< td=""><td></td><td>"Inter-RAT UE radio access</td></maxinter<>		"Inter-RAT UE radio access
		SysMessa		capability" was included in
		ges>		RRC CONNECTION SETUP
	1			COMPLETE message
>Inter-RAT UE security	MP		Inter-RAT	
capability			UE security	
			capability	
			10.3.8.8a	

10.2.44 SECURITY MODE COMPLETE

This message is sent by UE to confirm the reconfiguration of ciphering and/or integrity protection.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE to UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message Type	
UE information elements				
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36	
Integrity check info	MP		Integrity check info 10.3.3.16	
Uplink integrity protection activation info	OP		Integrity protection activation info 10.3.3.17	
RB Information elements				
Radio bearer uplink ciphering activation time info	OP		RB activation time info 10.3.4.13	

10.2.45 SECURITY MODE FAILURE

This message is sent to indicate a failure to act on a received SECURITY MODE COMMAND message.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message Type	
UE information elements				
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36	
Integrity check info	CH		Integrity check info 10.3.3.16	
Failure cause	MP		Failure cause and error information 10.3.3.14	

10.2.46 SIGNALLING CONNECTION RELEASE

This message is used to notify the UE that its ongoing signalling connection to a CN domain has been released.

RLC-SAP: AM

Logical channel: DCCH

Direction: UTRAN→UE

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Message Type	MP		Message	
			Type	
UE information elements				
RRC transaction identifier	MP		RRC	
			transaction	
			identifier	
			10.3.3.36	
Integrity check info	CH		Integrity	Integrity check info is included
			check info	if integrity protection is applied
			10.3.3.16	
CN information elements				
CN domain identity	MP		CN domain	
			identity	
			10.3.1.1	

10.2.47 SIGNALLING CONNECTION RELEASE INDICATION

This message is used by the UE to indicate to UTRAN the release of an existing signalling connection.

RLC-SAP: AM

Logical channel: DCCH
Direction: UE→UTRAN

Information Element/Group name	Need	Multi	IE type and reference	Semantics description
Message Type	MP		Message type	
UE Information Elements				
Integrity check info	СН		Integrity check info 10.3.3.16	
CN information elements				
CN domain identity	MP		CN domain identity	

10.2.48 SYSTEM INFORMATION

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message type	CV- channel1		Message type	
SFNprime	CV- channel2		Integer(040 94 by step of 2)	SFN=SFNprime (for first 10ms frame of 20ms TTI), SFN=SFNprime+1 (for last 10ms frame of 20ms TTI)
CHOICE Segment combination	MP			Five spares are needed
>Combination 1				(no data)
>Combination 2				
>>First Segment	MP		First Segment, 10.2.48.1	
>Combination 3				
>>Subsequent Segment	MP		Subsequent Segment, 10.2.48.3	
>Combination 4				
>>Last segment	MP		Last segment	

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference (short),10.2.	
			48.5	
>Combination 5				
>>Last segment	MP		Last Segment (short)10.2.4 8.5	
>>First Segment	MP		First Segment (short), 10.2.48.2	
>Combination 6				
>>Last Segment	MP		Last Segment (short), 10.2.48.5	
>>Complete list	MP	1 to maxSIBper Msg		Note 1
>>>Complete	MP		Complete SIB (short),10.2. 48.7	
>Combination 7				
>>Last Segment	MP		Last Segment (short), 10.2.48.5	
>>Complete list	MP	1< maxSIBper Msg>		Note 1
>>>Complete	MP		Complete SIB (short),10.2. 48.7	
>>First Segment	MP		First Segment (short), 10.2.48.2	
>Combination 8				
>>Complete list	MP	1 to maxSIBper Msg		Note 1
>>>Complete	MP		Complete SIB (short),10.2. 48.7	
>Combination 9				
>>Complete list	MP	1MaxSIB perMsg		Note 1
>>>Complete	MP		Complete SIB (short),10.2. 48.7	
>>First Segment	MP		First Segment (short), 10.2.48.2	
>Combination 10				
>>>Complete SIB of size 215 to 226	MP		Complete SIB,10.2.48.	
>Combination 11 >>Last segment of size 215 to	MP	1	Last	
>>Last segment of size 215 to 222	IVIE		segment,10.	

Information Element/Group name	Need	Multi	Type and reference	Semantics description
			2.48.4	

Condition	Explanation
channel1	The IE is mandatory present if the message is sent on the FACH and not needed otherwise.
channel2	This IE is mandatory present if the channel is BCH, otherwise it is not needed.

If the encoded message does not fill a transport block, the RRC layer shall insert padding according to subclause 12.1. Padding is needed e.g. if the remaining space is insufficient to start a new First Segment (which requires several bits for SIB type, SEG_COUNT and SIB data).

NOTE 1: If Combination 6 - 9 contains a Master information block Master information shall be located as the first IE in the list.

10.2.48.1 First Segment

This segment type is used to transfer the first segment of a segmented system information block. The IE is used when the first segment fills the entire transport block (Combination 2).

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Other information elements				
SIB type	MP		SIB Type,	
			10.3.8.21	
SEG_COUNT	MP		SEG	
			COUNT,	
			10.3.8.17	
SIB data fixed	MP		SIB data	
			fixed,	
			10.3.8.19	

10.2.48.2 First Segment (short)

This segment type is used to transfer the first segment of a segmented system information block. The IE is used when the first segment is concatenated after other segments in a transport block (Combination 5, 7 and 9).

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Other information elements				
SIB type	MP		SIB Type,	
			10.3.8.21	
SEG_COUNT	MP		SEG	
			COUNT,	
			10.3.8.17	
SIB data variable	MP		SIB data	
			variable,	
			10.3.8.20	

10.2.48.3 Subsequent Segment

This segment type is used to transfer a subsequent segment of a segmented system information block.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Other information elements				
SIB type	MP		SIB Type,	
			10.3.8.21	
Segment index	MP		Segment	
			Index,	
			10.3.8.18	
SIB data fixed	MP		SIB data	
			fixed,	
			10.3.8.19	

10.2.48.4 Last Segment

This segment type is used to transfer the last segment of a segmented system information block. The IE is used when the last segment has a length, excluding length denominator, from 215 through 222 (Combination 11).

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Other information elements				
SIB type	MP		SIB Type, 10.3.8.21	
Segment index	MP		Segment Index, 10.3.8.18	
SIB data fixed	MP		SIB data fixed, 10.3.8.19	In case the SIB data is less than 222 bits, padding shall be used. The same padding bits shall be used as defined in clause 12.1

10.2.48.5 Last Segment (short)

This segment type is used to transfer the last segment of a segmented system information block. The IE is used when the last segment has a length, excluding length denominator, of upto 214 bits (Combination 4, 5, 6 and 7).

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Other information elements				
SIB type	MP		SIB Type, 10.3.8.21	
Segment index	MP		Segment Index, 10.3.8.18	
SIB data variable	MP		SIB data variable, 10.3.8.20	

10.2.48.6 Complete SIB

This segment type is used to transfer a non-segmented system information block. The IE is used when the complete SIB has a length, excluding length denominator, from 215 through 226 (Combination 10).

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Other information elements			reference	
SIB type	MP		SIB Type, 10.3.8.21	
SIB data fixed	MP		Bit string (226)	The first/leftmost/most significant bit of the bit string contains the first bit of the segment. In case the SIB data is less than 226 bits, padding shall be used. The same padding bits shall be used as defined in clause 12.1

10.2.48.7 Complete SIB (short)

This segment type is used to transfer a non-segmented system information block. The IE is used when the complete SIB has a length, excluding length denominator, of upto 214 bits (Combination 6, 7, 8 and 9).

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Other information elements				
SIB type	MP		SIB Type, 10.3.8.21	
SIB data variable	MP		SIB data variable, 10.3.8.20	

10.2.48.8 System Information Blocks

The IE "SIB data" within the IEs, "First Segment", "Subsequent or last Segment" and "Complete SIB" contains either complete system information block or a segment of a system information block. The actual system information blocks are defined in the following clauses.

10.2.48.8.1 Master Information Block

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Other information elements				
MIB Value tag	MP		MIB Value	
-			tag 10.3.8.9	
CN information elements				
Supported PLMN types	MP		PLMN Type	
, .			10.3.1.12	
PLMN Identity	CV-GSM		PLMN	
			Identity	
			10.3.1.11	
ANSI-41 information elements				
ANSI-41 Core Network	CV-ANSI-		ANSI-41	
Information	41		Core	
			Network	
			Information	
			10.3.9.1	
References to other system	MP		References	
information blocks and			to other	
scheduling blocks			system	
			information	
			blocks and	
			scheduling	
			blocks	
			10.3.8.14	

Condition	Explanation
GSM	The IE is mandatory present if the IE "Supported PLMN Types" is set to 'GSM-MAP' or 'GSM-MAP
	AND ANSI-41', and not needed otherwise
ANSI-41	The IE is mandatory present if the IE "Supported PLMN Types" is set to 'ANSI-41' or 'GSM-MAP AND ANSI-41', and not needed otherwise

10.2.48.8.2 Scheduling Block 1

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
References to other system	MP		References	
information blocks			to other	
			system	
			information	
			blocks	
			10.3.8.13	

10.2.48.8.3 Scheduling Block 2

Information Element/Group name	Need	Multi	Type and reference	Semantics description
References to other system	MP		References	
information blocks			to other	
			system	
			information	
			blocks	
			10.3.8.13	

10.2.48.8.4 System Information Block type 1

The system information block type 1 contains NAS system information as well as UE timers and counters to be used in idle mode and in connected mode.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CN information elements				
CN common GSM-MAP NAS system information	MP		NAS system information (GSM-MAP) 10.3.1.9	
CN domain system information list	MP	1 to <maxcndo mains></maxcndo 		Send CN information for each CN domain.
>CN domain system information	MP		CN domain system information 10.3.1.2	
UE information				
UE Timers and constants in idle mode	MD		UE Timers and constants in idle mode 10.3.3.44	Default value means that for all timers and constants - For parameters with need MD, the defaults specified in 10.3.3.44 apply and - For parameters with need OP, the parameters are absent
UE Timers and constants in connected mode	MD		UE Timers and constants in connected mode 10.3.3.43	Default value means that for all timers and constants - For parameters with need MD, the defaults specified in 10.3.3.43 apply and - For parameters with need OP, the parameters are absent

10.2.48.8.5 System Information Block type 2

The system information block type 2 contains the URA identity.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
UTRAN mobility information				
elements				
URA identity list	MP	1		
		<maxur< td=""><td></td><td></td></maxur<>		
		A>		
>URA identity	MP		URA identity	
-			10.3.2.6	

10.2.48.8.6 System Information Block type 3

The system information block type 3 contains parameters for cell selection and re-selection.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
SIB4 Indicator	MP		Boolean	TRUE indicates that SIB4 is broadcast in the cell.
UTRAN mobility information elements				
Cell identity	MP		Cell identity 10.3.2.2	
Cell selection and re-selection info	MP		Cell selection and re- selection info for SIB3/4 10.3.2.3	
Cell Access Restriction	MP		Cell Access Restriction 10.3.2.1	

10.2.48.8.7 System Information Block type 4

The system information block type 4 contains parameters for cell selection and re-selection to be used in connected mode.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
UTRAN mobility information elements				
Cell identity	MP		Cell identity 10.3.2.2	
Cell selection and re-selection info	MP		Cell selection and re- selection info for SIB3/4 10.3.2.3	
Cell Access Restriction	MP		Cell Access Restriction 10.3.2.1	

10.2.48.8.8 System Information Block type 5

The system information block type 5 contains parameters for the configuration of the common physical channels in the cell.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
SIB6 Indicator	MP		Boolean	TRUE indicates that SIB6 is broadcast in the cell.
PhyCH information elements				
PICH Power offset	MP		PICH Power offset 10.3.6.50	
CHOICE mode	MP			
>FDD				
>>AICH Power offset	MP		AICH Power offset 10.3.6.3	This AICH Power offset also indicates the power offset for AP-AICH and for CD/CA-ICH.
>TDD				
>>PUSCH system information	OP		PUSCH system information 10.3.6.66	
>>PDSCH system information	OP		PDSCH system	

Information Element/Group name	Need	Multi	Type and reference	Semantics description
			information 10.3.6.46	
>>TDD open loop power control	MP		TDD open loop power control 10.3.6.79	
Primary CCPCH info	OP		Primary CCPCH info 10.3.6.57	Note 1
PRACH system information list	MP		PRACH system information list 10.3.6.55	
Secondary CCPCH system information	MP		Secondary CCPCH system information 10.3.6.72	
CBS DRX Level 1 information	CV-CTCH		CBS DRX Level 1 information 10.3.8.3	

NOTE 1: DL scrambling code of the Primary CCPCH is the same as the one for Primary CPICH (FDD only).

Explanation
The IE is mandatory present if the IE "CTCH
indicator" is equal to TRUE for at least one FACH, otherwise the IE is not needed in the message

10.2.48.8.9 System Information Block type 6

The system information block type 6 contains parameters for the configuration of the common and shared physical channels to be used in connected mode.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
PhyCH information elements				
PICH Power offset	MP		PICH Power offset 10.3.6.50	
CHOICE mode	MP			
>FDD				
>>AICH Power offset	MP		AICH Power offset 10.3.6.3	This AICH Power offset also indicates the power offset for AP-AICH and for CD/CA-ICH.
>TDD				
>>PUSCH system information	OP		PUSCH system information 10.3.6.66	
>>PDSCH system information	OP		PDSCH system information 10.3.6.46	
>>TDD open loop power control	MP		TDD open loop power control 10.3.6.79	
Primary CCPCH info	OP		Primary CCPCH info 10.3.6.57	Note 1
PRACH system information list	OP		PRACH	

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
			system	
			information	
			list 10.3.6.55	
Secondary CCPCH system	OP		Secondary	
information			CCPCH	
			system	
			information	
			10.3.6.72	
CBS DRX Level 1 information	CV-CTCH		CBS DRX	
			Level 1	
			information	
			10.3.8.3	

NOTE 1: DL scrambling code of the Primary CCPCH is the same as the one for Primary CPICH (FDD only).

Condition	Explanation
СТСН	The IE is mandatory present if the IE "CTCH indicator" is equal to TRUE for at least one FACH.
	otherwise the IE is not needed

10.2.48.8.10 System Information Block type 7

The system information block type 7 contains the fast changing parameters UL interference and Dynamic persistence level.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
CHOICE mode	MP			
>FDD				
>>UL interference	MP		UL interference 10.3.6.87	
>TDD				(no data)
PhyCH information elements				
PRACHs listed in system information block type 5	MP	1 to <maxpr ACH></maxpr 		The order of the PRACHs is the same as in system information block type 5.
>Dynamic persistence level	MP		Dynamic persistence level 10.3.6.35	
PRACHs listed in system information block type 6	OP	1 to <maxpra CH></maxpra 		The order of the PRACHs is the same as in system information block type 6.
>Dynamic persistence level	MP		Dynamic persistence level 10.3.6.35	
Expiration Time Factor	MD		Expiration Time Factor 10.3.3.12	Default is 1.

10.2.48.8.11 System Information Block type 8

NOTE: Only for FDD.

The system information block type 8 contains static CPCH information to be used in the cell.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
UE information				
CPCH parameters	MP		CPCH	
			parameters	
			10.3.3.7	
PhyCH information elements				
CPCH set info list	MP	1 to		
		<maxcpc< td=""><td></td><td></td></maxcpc<>		
		Hsets>		
>CPCH set info	MP		CPCH set	
			info	
			10.3.6.13	
CSICH Power offset	MP		CSICH	
			Power offset	
			10.3.6.15	

10.2.48.8.12 System Information Block type 9

NOTE: Only for FDD.

The system information block type 9 contains CPCH information to be used in the cell.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
PhyCH information elements				
CPCH set persistence levels list	MP	1 to <maxcpc Hsets></maxcpc 		
>CPCH set persistence levels	MP		CPCH persistence levels 10.3.6.12	

10.2.48.8.13 System Information Block type 10

NOTE: Only for FDD.

The system information block type 10 contains information to be used by UEs having their DCH controlled by a DRAC procedure.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
UE information				
DRAC system information	MP		DRAC system information 10.3.3.9	DRAC information is sent for each class of terminal

10.2.48.8.14 System Information Block type 11

The system information block type 11 contains measurement control information to be used in the cell.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
SIB12 Indicator	MP		Boolean	TRUE indicates that SIB12 is broadcast in the cell.
Measurement information elements				
FACH measurement occasion	OP		FACH	
info			measuremen	
			t occasion	

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
			info 10.3.7.8	
Measurement control system information	MP		Measuremen t control system	
			information 10.3.7.47	

10.2.48.8.15 System Information Block type 12

The system information block type 12 contains measurement control information to be used in connected mode.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Measurement information elements				
FACH measurement occasion info	OP		FACH measuremen t occasion info 10.3.7.8	
Measurement control system information	MP		Measuremen t control system information 10.3.7.47	

10.2.48.8.16 System Information Block type 13

The system information block type 13 contains ANSI-41 system information.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Other information elements				
CN Information Elements				
CN Domain system information list	MP	1 to <maxcndo mains></maxcndo 		Send CN information for each CN domain.
>CN Domain system information	MP		CN Domain system information 10.3.1.2	
UE Information				
UE timers and constants in idle mode	MD		UE timers and constants in idle mode 10.3.3.44	Default value means that for all timers and constants - for parameters with need MD, the defaults specified in 10.3.3.44 apply; and - for parameters with need OP, the parameters are absent.
Capability update requirement	MD		Capability update requirement 10.3.3.2	Default value is defined in subclause 10.3.3.2

10.2.48.8.16.1 System Information Block type 13.1

The system information block type 13.1 contains the ANSI-41 RAND information.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
ANSI-41 information elements				
ANSI-41 RAND information	MP		ANSI-41	
			RAND	
			information	
			10.3.9.6	

10.2.48.8.16.2 System Information Block type 13.2

The system information block type 13.2 contains the ANSI-41 User Zone Identification information.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
ANSI-41 information elements				
ANSI-41 User Zone	MP		ANSI-41	
Identification information			User Zone	
			Identification	
			information	
			10.3.9.7	

10.2.48.8.16.3 System Information Block type 13.3

The system information block type 13.3 contains the ANSI-41 Private Neighbour List information.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
ANSI-41 information elements				
ANSI-41 Private Neighbour List	MP		ANSI-41	
information			Private	
			Neighbour	
			List	
			information	
			10.3.9.5	

10.2.48.8.16.4 System Information Block type 13.4

The system information block type 13.4 contains the ANSI-41 Global Service Redirection information.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
ANSI-41 information elements				
ANSI-41 Global Service	MP		ANSI-41	
Redirection information			Global	
			Service	
			Redirection	
			information	
			10.3.9.2	

10.2.48.8.17 System Information Block type 14

NOTE: Only for 3.84 Mcps TDD.

The system information block type 14 contains parameters for common and dedicated physical channel uplink outer loop power control information to be used in both idle and connected mode.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
PhyCH information elements				
Individual Timeslot interference	MP	1 to		
list		<maxts></maxts>		

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
>Individual Timeslot interference	MP		Individual	
			Timeslot	
			interference	
			10.3.6.38	
Expiration Time Factor	MD		Expiration	Default is 1.
			Time Factor	
			10.3.3.12	

10.2.48.8.18 System Information Block type 15

The system information block type 15 contains information useful for UE-based or UE-assisted positioning methods.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
GPS Data ciphering info	OP		UE positioning Cipher info 10.3.7.86	If this IE is present then the SIB types 15.1, 15.2 & 15.3 are ciphered in accordance with the Data Assistance Ciphering Algorithm specified in [18]
Reference position	MP		Ellipsoid point with altitude and uncertainty ellipsoid 10.3.8.4c	approximate position where the UE is located
GPS reference time	MP		UE positioning GPS reference time 10.3.7.96	
Satellite information	OP	1 to <maxsat></maxsat>		This IE is present whenever bad (failed/failing) satellites are detected by UTRAN [18].
>BadSatID	MP		Enumerated(063)	

10.2.48.8.18.1 System Information Block type 15.1

The system information block type 15.1 contains information useful for UE positioning DGPS Corrections. The DGPS Corrections message contents are based on a Type-1 message of DGPS specified in [13].

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
DGPS corrections	MP		UE positioning GPS DGPS corrections 10.3.7.91	

10.2.48.8.18.2 System Information Block type 15.2

The system information block type 15.2 contains information useful for GPS Navigation Model. These IE fields are based on information extracted from the subframes 1 to 3 of the GPS navigation message [12].

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
Transmission TOW	MP		Integer (0604799)	The approximate GPS time-of- week when the message is broadcast.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
				in seconds
SatID	MP		Enumerated(063)	Satellite ID
GPS Ephemeris and Clock Correction Parameters	MP		UE positioning GPS Ephemeris and Clock Correction parameters 10.3.7.91a	

10.2.48.8.18.3 System Information Block type 15.3

The system information block type 15.3 contains information useful for ionospheric delay, UTC offset, and Almanac. These IEs contain information extracted from the subframes 4 and 5 of the GPS navigation message, [12].

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
Transmission TOW	MP		Integer (0604799)	The approximate GPS time-of- week when the message is broadcast. in seconds
GPS Almanac and Satellite Health	OP		UE positioning GPS almanac 10.3.7.89	
GPS ionospheric model	OP		UE positioning GPS ionospheric model 10.3.7.92	
GPS UTC model	OP		UE positioning GPS UTC model 10.3.7.97	
SatMask	CV- Almanac		Bit string(132)	indicates the satellites that contain the pages being broadcast in this data set
LSB TOW	CV- Almanac		Bit string(8)	

Condition	Explanation
Almanac	This IE is mandatory present if the IE "GPS Almanac and Satellite Health" is present

10.2.48.8.18.4 System Information Block type 15.4

The system information block type 15.4 contains ciphering information for System Information Block type 15.5 and information useful for OTDOA UE-assisted Positioning method.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
OTDOA Data ciphering info	OP		UE positioning Ciphering info 10.3.7.86	If this IE is present then the for UE-based the System Information Block type 15.5 is ciphered in accordance with the Data Assistance Ciphering Algorithm specified in [18]
OTDOA assistance data for UE-assisted	MP		UE positioning OTDOA assistance data for UE- assisted 10.3.7.103	

10.2.48.8.18.4a System Information Block type 15.5

The system information block type 15.5 contains information useful for OTDOA UE-based Positioning method.

Information Element/Group	Need	Multi	Type and	Semantics description
name			Reference	
OTDOA assistance data for UE-	MP		UE	
based			positioning	
			OTDOA	
			assistance	
			data for UE-	
			based	
			10.3.7.103a	

10.2.48.8.19 System Information Block type 16

The system information block type 16 contains radio bearer, transport channel and physical channel parameters to be stored by UE in idle and connected mode for use during handover to UTRAN.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
RB information elements				
Predefined RB configuration	MP		Predefined RB configuration 10.3.4.7	
TrCH Information Elements				
Predefined TrCH configuration	MP		Predefined TrCH configuration 10.3.5.9	
PhyCH Information Elements				
Predefined PhyCH configuration	MP		Predefined PhyCH configuration 10.3.6.56	

10.2.48.8.20 System Information Block type 17

NOTE: Only for TDD.

The system information block type 17 contains fast changing parameters for the configuration of the shared physical channels to be used in connected mode.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
PhyCH information elements				
PUSCH system information	OP		PUSCH	
			system	
			information	
			10.3.6.66	
PDSCH system information	OP		PDSCH	
			system	
			information	
			10.3.6.46	

10.2.48.8.21 System Information Block type 18

The System Information Block type 18 contains PLMN identities of neighbouring cells to be considered in idle mode as well as in connected mode.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Idle mode PLMN identities	OP		PLMN identities of neighbour cells 10.3.7.53a	
Connected mode PLMN identities	OP		PLMN identities of neighbour cells 10.3.7.53a	

10.2.49 SYSTEM INFORMATION CHANGE INDICATION

This message is used to send information on FACH to the UEs in state CELL_FACH or CELL_DCH(TDD only) about coming modification of the system information.

RLC-SAP: TM

Logical channel: BCCH

Direction: UTRAN \rightarrow UE

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message Type	
Other information elements				
BCCH modification info	MP		BCCH modification info 10.3.8.1	

If the encoded message does not fill a transport block, the RRC layer shall insert padding according to subclause 12.1.

10.2.50 TRANSPORT CHANNEL RECONFIGURATION

This message is used by UTRAN to configure the transport channel of a UE. This also includes a possible reconfiguration of physical channels. The message can also be used to assign a TFC subset and reconfigure physical channel.

RLC-SAP: AM or UM

Logical channel: DCCH

Direction: UTRAN \rightarrow UE

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Message Type	MP		Message Type		
UE Information Elements			туре		
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36		
Integrity check info	CH		Integrity check info 10.3.3.16		
Integrity protection mode info	OP		Integrity protection mode info 10.3.3.19	The UTRAN should not include this IE unless it is performing an SRNS relocation	
Ciphering mode info	OP		Ciphering mode info 10.3.3.5	The UTRAN should not include this IE unless it is performing an SRNS relocation and a change in ciphering algorithm	
Activation time	MD		Activation time 10.3.3.1	Default value is "now"	
New U-RNTI	OP		U-RNTI 10.3.3.47		
New C-RNTI	OP		C-RNTI 10.3.3.8		
New DSCH-RNTI	OP		DSCH-RNTI 10.3.3.9a		
New H-RNTI	OP		H-RNTI 10.3.3.14a		REL-5
RRC State Indicator	MP		RRC State Indicator 10.3.3.35a		
UTRAN DRX cycle length coefficient	OP		UTRAN DRX cycle length coefficient 10.3.3.49		
CN Information Elements					
CN Information info	OP		CN Information info 10.3.1.3		
UTRAN mobility information elements					
URA identity	OP		URA identity 10.3.2.6		
RB information elements					
Downlink counter synchronisation info	OP				
>RB with PDCP information list	OP	1 to <maxrball RABs></maxrball 			
>>RB with PDCP information	MP		RB with PDCP information 10.3.4.22	This IE is needed for each RB having PDCP in the case of lossless SRNS relocation	
>>PDCP context relocation info	OP OP		PDCP	This IE is needed	REL-5 REL-5
->FDGF COINEXLIERCEALION INTO	UF		context	for each RB	NEL-3

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
name			relocation	having PDCP and	
			info	performing PDCP	
			10.3.4.1a	context relocation	
TrCH Information Elements					
Uplink transport channels					
UL Transport channel information common for all transport channels	OP		UL Transport channel information common for		
			all transport channels 10.3.5.24		
Added or Reconfigured TrCH information list	OP	1 to <maxtrch ></maxtrch 			
>Added or Reconfigured UL TrCH information	MP		Added or Reconfigure d UL TrCH information 10.3.5.2		
CHOICE mode	OP				
>FDD					
>>CPCH set ID	OP		CPCH set ID 10.3.5.3		
>>Added or Reconfigured TrCH information for DRAC list	OP	1 to <maxtrch ></maxtrch 			
>>>DRAC static information	MP		DRAC static information 10.3.5.7		
>TDD				(no data)	
Downlink transport channels					
DL Transport channel information common for all transport channels	OP		DL Transport channel information common for all transport channels 10.3.5.6		
Added or Reconfigured TrCH information list	OP	1 to <maxtrch ></maxtrch 			
>Added or Reconfigured DL TrCH information	MP		Added or Reconfigure d DL TrCH information 10.3.5.1		
PhyCH information elements					
Frequency info	OP		Frequency info 10.3.6.36		
Uplink radio resources					
Maximum allowed UL TX power	MD		Maximum allowed UL TX power 10.3.6.39	Default value is the existing maximum UL TX power	
CHOICE channel requirement	OP				
>Uplink DPCH info			Uplink DPCH info 10.3.6.88		
>CPCH SET Info			CPCH SET Info 10.3.6.13		
Downlink radio resources CHOICE mode	MP				

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
>FDD				•	
>>Downlink PDSCH information	OP		Downlink PDSCH information 10.3.6.30		
>TDD				(no data)	
Downlink HS-PDSCH Information	OP		Downlink HS-PDSCH Information 10.3.6.23a		REL-5
Downlink information common for all radio links	OP		Downlink information common for all radio links 10.3.6.24		
Downlink information per radio link list	OP	1 to <maxrl></maxrl>		Send downlink information for each radio link	
>Downlink information for each radio link	MP		Downlink information for each radio link 10.3.6.27		

10.2.51 TRANSPORT CHANNEL RECONFIGURATION COMPLETE

This message is sent from the UE when a transport channel reconfiguration has been done.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE \rightarrow UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Message Type	MP		Message Type		
UE information elements					
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36		
Integrity check info	СН		Integrity check info 10.3.3.16		
Uplink integrity protection activation info	OP		Integrity protection activation info 10.3.3.17		
CHOICE mode	OP				
>FDD				(no data)	
>TDD					
>>CHOICE TDD option	MP				REL-4
>>>3.84 Mcps TDD					REL-4
>>>>Uplink Timing Advance	OP		Uplink Timing Advance 10.3.6.95		
>>>1.28 Mcps TDD				(no data)	REL-4
RB Information elements				·	
COUNT-C activation time	OP		Activation	Used for radio	

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
			time 10.3.3.1	bearers mapped on RLC-TM. Only applicable if the UE is moving to CELL_DCH state due to this procedure	
Radio bearer uplink ciphering activation time info	OP		RB activation time info 10.3.4.13		
Uplink counter synchronisation info	OP				
>RB with PDCP information list	OP	1 to <maxrball RABs></maxrball 			
>>RB with PDCP information	MP		RB with PDCP information 10.3.4.22		
>START list	MP	1 to <maxcndo mains></maxcndo 		START [40] values for all CN domains.	
>>CN domain identity	MP		CN domain identity 10.3.1.1		
>>START	MP		START 10.3.3.38	START value to be used in this CN domain.	

10.2.52 TRANSPORT CHANNEL RECONFIGURATION FAILURE

This message is sent by UE if the configuration given by UTRAN is unacceptable or if the UE failed to establish the physical channel(s).

RLC-SAP: AM

Logical channel: DCCH

Direction: UE \rightarrow UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message Type	
UE information elements				
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36	
Integrity check info	CH		Integrity check info 10.3.3.16	
Failure cause	MP		Failure cause and error information 10.3.3.14	

10.2.53 TRANSPORT FORMAT COMBINATION CONTROL

This message is sent by UTRAN to control the uplink transport format combination within the allowed transport format combination set. This message has different structures depending if the message is sent on transparent (TM) or non-transparent mode (AM or UM).

RLC-SAP: AM or UM
Logical channel: DCCH
Direction: UTRAN→UE

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message	
UE information elements			Туре	
	MD		DDO	
RRC transaction identifier	MP		RRC	
			transaction	
			identifier	
			10.3.3.36	
Integrity check info	CH		Integrity	
			check info	
			10.3.3.16	
TrCH information elements				
CHOICE mode	MP			
>FDD				(no data)
>TDD				
>>TFCS Id	OP		Transport	
			Format	
			Combination	
			Set Identity	
			10.3.5.21	
DPCH/PUSCH TFCS in uplink	MP		Transport	
·			Format	
			Combination	
			subset	
			10.3.5.22	
Activation time for TFC subset	MD		Activation	Default value is "now"
			time	
			10.3.3.1	
TFC Control duration	OP		TFC Control	
			duration	
			10.3.6.80	

In case of transparent mode signalling the following message structure shall be used:

RLC-SAP: TM

Logical channel: DCCH

Direction: UTRAN→UE

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
CHOICE TFCsubsetListSize	MP			
>Three bits list size				
>>TFC subset identity	MP		INTEGER	
			(07)	
>Five bits list size				
>>TFC subset identity	MP		INTEGER	
			(031)	
>Ten bits list size				
>>TFC subset identity	MP		INTEGER	
			(01023)	

The encoding of this message is specified in subclause 12.4.1.1.

10.2.54 TRANSPORT FORMAT COMBINATION CONTROL FAILURE

This message is sent to indicate that a received TRANSPORT FORMAT COMBINATION CONTROL message could not be handled by the UE.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message Type	
UE information elements				
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36	
Integrity check info	CH		Integrity check info 10.3.3.16	
Failure cause	MP		Failure cause and error information 10.3.3.14	

10.2.55 UE CAPABILITY ENQUIRY

The UE CAPABILITY ENQUIRY is used by the UTRAN to enquire inter-RAT classmarks from the UE.

RLC-SAP: AM or UM

Logical channel: DCCH

Direction: UTRAN \rightarrow UE

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message	
			Туре	
UE information elements				
RRC transaction identifier	MP		RRC	
			transaction	
			identifier	
			10.3.3.36	
Integrity check info	CH		Integrity	Integrity check info is included
			check info	if integrity protection is applied
			10.3.3.16	
Capability update requirement	MP		Capability	
			update	
			requirement	
			10.3.3.2	

10.2.56 UE CAPABILITY INFORMATION

This message is sent by UE to convey UE specific capability information to the UTRAN.

RLC-SAP: AM

Integrity check info is included

if integrity protection is applied

Logical channel: DCCH Direction: $UE \rightarrow UTRAN$

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message	
UE information elements			Туре	
RRC transaction identifier	OP		RRC	
RRC transaction identifier	OP		transaction	
			identifier	
late with the all info	011		10.3.3.36	late with a least infector in the least
Integrity check info	СН		Integrity	Integrity check info is included
			check info	if integrity protection is applied
LIE P. LYG	0.0		10.3.3.16	
UE radio access capability	OP		UE radio	
			access	
			capability	
LIE P. LOS	0.0		10.3.3.42	
UE radio access capability	OP		UE radio	
extension			access	
			capability	
			extension	
			10.3.3.42a	
Other information elements				
UE system specific capability	OP	1 to		
		<maxinter< td=""><td></td><td></td></maxinter<>		
		SysMessa		
		ges>		
>Inter-RAT UE radio access	MP		Inter-RAT	
capability			UE radio	
			access	
			capability10.	
			3.8.7	

10.2.57 UE CAPABILITY INFORMATION CONFIRM

This message is sent by UTRAN to confirm that UE capability information has been received.

RLC-SAP: AM or UM Logical channel: DCCH Direction: UTRAN \rightarrow UE

Multi Information Element/Group Need Type and **Semantics description** name reference MP Message Type Message Type **UE information elements** MP RRC RRC transaction identifier transaction identifier 10.3.3.36

Integrity check info

10.3.3.16

10.2.58 UPLINK DIRECT TRANSFER

This message is used to transfer NAS messages for an existing signalling connection.

СН

RLC-SAP: AM

Integrity check info

Logical channel: DCCH
Direction: UE ->UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message Type	
UE information elements				
Integrity check info	СН		Integrity check info 10.3.3.16	Integrity check info is included if integrity protection is applied
CN information elements				
CN domain identity	MP		CN domain identity 10.3.1.1	
NAS message	MP		NAS message 10.3.1.8	
Measurement information elements				
Measured results on RACH	OP		Measured results on RACH 10.3.7.45	

10.2.59 UPLINK PHYSICAL CHANNEL CONTROL

NOTE: Only for TDD.

This message is used to transfer uplink physical channel parameters to the UE.

RLC-SAP: AM or UM

Logical channel: DCCH

Direction: UTRAN→UE

Information Element/Group name	Need	Multi	Type and Reference	Semantics description	Version
Message Type	MP		Message Type		
UE information elements					
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36		
Integrity check info	OP		Integrity check info 10.3.3.16		
PhyCH information elements					
CCTrCH power control info	OP		CCTrCH power control info 10.3.6.8	Power control information for one CCTrCH	
Special Burst Scheduling	OP		Special Burst Scheduling 10.3.6.75a	UL Special Burst generation period in radio frames	
CHOICE TDD option	MP				REL-4
>3.84 Mcps TDD					REL-4
>>Alpha	OP		Alpha 10.3.6.5		
>>Timing Advance Control	OP		UL Timing Advance Control		

Information Element/Group name	Need	Multi	Type and Reference	Semantics description	Version
			10.3.6.96		
>>PRACH Constant Value	OP		Constant value TDD 10.3.6.11a	Operator controlled PRACH Margin	
>>PUSCH Constant Value	OP		Constant value TDD 10.3.6.11a	Operator controlled PUSCH Margin	
>>UE positioning related parameters	CV-IPDLs			3	REL-4
>>>IPDL-Alpha	MP		Alpha 10.3.6.5		REL-4
>>>Max power increase	MP		Integer (03)	In dB	REL-4
>> HS-SICH power control info	OP		HS-SICH Power Control Info 10.3.6.36b	Only applies to TDD 3.84 Mcps	REL-5
>1.28 Mcps TDD					REL-4
>>Uplink synchronisation parameters	MD			Default: Uplink synchronisation step size 1. Uplink synchronisation frequency 1.	REL-4
>>>Uplink synchronisation step size	MP		Integer(18)	This parameter specifies the step size to be used for the adjustment of the uplink transmission timing	REL-4
>>>Uplink synchronisation frequency	MP		Integer(18)	This parameter specifies the frequency of the adjustment of the uplink transmission timing	REL-4

Condition	Explanation
IPDLs	This IE is present only if idle periods are applied

10.2.60 URA UPDATE

This message is used by the UE to initiate a URA update procedure.

RLC-SAP: TM

Logical channel: CCCH

Direction: UE→UTRAN

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message Type	MP		Message Type	
UE information elements				
U-RNTI	MP		U-RNTI 10.3.3.47	

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
RRC transaction identifier	CV-		RRC	
	ProtErr		transaction	
			identifier	
			10.3.3.36	
Integrity check info	CH		Integrity	
			check info	
			10.3.3.16	
URA update cause	MP		URA update	
			cause	
			10.3.3.46	
Protocol error indicator	MD		Protocol	Default value is FALSE
			error	
			indicator	
			10.3.3.27	
Other information elements				
Protocol error information	CV-ProtErr		Protocol	
			error	
			information	
			10.3.8.12	

Condition	Explanation
ProtErr	The IE is mandatory present if the IE "Protocol error indicator" has the value "TRUE" and not needed
	otherwise.

10.2.61 URA UPDATE CONFIRM

This message confirms the URA update procedure and can be used to reallocate new RNTI information for the UE valid after the URA update.

RLC-SAP: UM

Logical channel: CCCH or DCCH

Direction: UTRAN \rightarrow UE

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Message Type	MP		Message		
			Туре		
UE information elements					
U-RNTI	CV-CCCH		U-RNTI		
550			10.3.3.47		
RRC transaction identifier	MP		RRC		
			transaction		
			identifier		
			10.3.3.36		
Integrity check info	CH		Integrity	Integrity check	
			check info	info is included if	
			10.3.3.16	integrity protection	
				is applied	
Integrity protection mode info	OP		Integrity	The UTRAN	
			protection	should not include	
			mode info	this IE unless it is	
			10.3.3.19	performing an	
				SRNS relocation	
Ciphering mode info	OP		Ciphering	The UTRAN	
			mode info	should not include	
			10.3.3.5	this IE unless it is	
				performing an	
				SRNS relocation	
				and a change in	

Information Element/Group	Need	Multi	Type and reference	Semantics	Version
name			reference	description ciphering	
				algorithm	
New U-RNTI	OP		U-RNTI	algontiliii	
Now & MATH			10.3.3.47		
New C-RNTI	OP		C-RNTI		
			10.3.3.8		
RRC State Indicator	MP		RRC State		
			Indicator		
			10.3.3.35a		
UTRAN DRX cycle length	OP		UTRAN DRX		
coefficient			cycle length		
			coefficient		
			10.3.3.49		
CN Information Elements	1				
CN Information info	OP		CN		
			Information		
			info 10.3.1.3		
UTRAN mobility information					
elements	0.0		LIDA: L		
URA identity	OP		URA identity		
DD information alamanta			10.3.2.6		
RB information elements Downlink counter	OP				
synchronisation info					
>RB with PDCP information list	OP	1 to			
		<maxrball< td=""><td></td><td></td><td></td></maxrball<>			
		RABs>			
>>RB with PDCP information	MP		RB with	This IE is needed	
			PDCP	for each RB	
			information	having PDCP in	
			10.3.4.22	the case of	
				lossless SRNS	
				relocation	
	OP				REL-5
>>PDCP context relocation info	OP		PDCP	This IE is needed	REL-5
			context	for each RB	
			relocation	having PDCP and	
			info	performing PDCP	
			10.3.4.1a	context relocation	

Condition	Explanation
CCCH	This IE is mandatory present when CCCH is used and
	not needed otherwise.

10.2.62 UTRAN MOBILITY INFORMATION

This message is used by UTRAN to allocate a new RNTI and to convey other UTRAN mobility related information to a UE.

RLC-SAP: AM or UM
Logical channel: DCCH

Direction: UTRAN→UE

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Message Type	MP		Message Type		
UE Information Elements					
Integrity check info	СН		Integrity check info 10.3.3.16		
RRC transaction identifier	MP		RRC		

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
			transaction identifier 10.3.3.36	•	
Integrity protection mode info	OP		Integrity protection mode info 10.3.3.19	The UTRAN should not include this IE unless it is performing an SRNS relocation	
Ciphering mode info	OP		Ciphering mode info 10.3.3.5	The UTRAN should not include this IE unless it is performing an SRNS relocation and a change in ciphering algorithm	
New U-RNTI	OP		U-RNTI 10.3.3.47		
New C-RNTI	OP		C-RNTI 10.3.3.8		
UE Timers and constants in connected mode	OP		UE Timers and constants in connected mode 10.3.3.43		
CN Information Elements					
CN Information info	OP		CN Information info full 10.3.1.3a		
UTRAN Information Elements					
URA identity	OP		URA identity 10.3.2.6		
RB Information elements					
Downlink counter synchronisation info	OP				
>RB with PDCP information list	OP	1 to <maxrball RABs></maxrball 			
>>RB with PDCP information	MP		RB with PDCP information 10.3.4.22	This IE is needed for each RB having PDCP in the case of lossless SRNS relocation	
	OP				REL-5
>>PDCP context relocation info	OP		PDCP context relocation info 10.3.4.1a	This IE is needed for each RB having PDCP and performing PDCP context relocation	REL-5

10.2.63 UTRAN MOBILITY INFORMATION CONFIRM

This message is used to confirm the new UTRAN mobility information for the UE.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Message Type	MP		Message	

Information Element/Group name	Need	Multi	Type and reference	Semantics description
			Туре	
UE information elements				
RRC transaction identifier	MP		RRC transaction identifier 10.3.3.36	
Integrity check info	СН		Integrity check info 10.3.3.16	
Uplink integrity protection activation info	OP		Integrity protection activation info 10.3.3.17	
RB Information elements				
COUNT-C activation time	OP		Activation time 10.3.3.1	Used for radio bearers mapped on RLC-TM. Only applicable if the UE is moving to CELL_DCH state due to this procedure
Radio bearer uplink ciphering activation time info	OP		RB activation time info 10.3.4.13	
Uplink counter synchronisation info	OP			
>RB with PDCP information list	OP	1 to <maxrball RABs></maxrball 		This IE is needed for each RB having PDCP in the case of lossless SRNS relocation
>>RB with PDCP information	MP		RB with PDCP information 10.3.4.22	
>START list	MP	1 to <maxcndo mains></maxcndo 		START [40] values for all CN domains.
>>CN domain identity	MP		CN domain identity 10.3.1.1	
>>START	MP		START 10.3.3.38	START value to be used in this CN domain.

10.2.64 UTRAN MOBILITY INFORMATION FAILURE

This message is sent to indicate a failure to act on a received UTRAN MOBILITY INFORMATION message.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Message Type	MP		Message	
			Туре	
UE information elements				
RRC transaction identifier	MP		RRC	
			transaction	
			identifier	
			10.3.3.36	
Integrity check info	CH		Integrity	
			check info	
			10.3.3.16	
Failure cause	MP		Failure	
			cause and	
			error	
			information	
			10.3.3.14	

10.3 Information element functional definitions

10.3.1 CN Information elements

10.3.1.1 CN domain identity

Identifies the type of core network domain.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CN domain identity	MP		Enumerated	
^			(CS domain,	
			PS domain)	

10.3.1.2 CN Domain System Information

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CN domain identity	MP		CN domain identity 10.3.1.1	
CHOICE CN Type	MP			
>GSM-MAP				
>>CN domain specific NAS system information	MP		NAS system information (GSM-MAP) 10.3.1.9	
>ANSI-41				
>>CN domain specific NAS system information	MP		ANSI-41 NAS system information, 10.3.9.4	
CN domain specific DRX cycle length coefficient	MP		CN domain specific DRX cycle length coefficient, 10.3.3.6	

10.3.1.3 CN Information info

Information Element/Group name	Need	Multi	Type and reference	Semantics description
PLMN identity	OP		PLMN identity 10.3.1.11	
CN common GSM-MAP NAS system information	OP		NAS system information (GSM-MAP) 10.3.1.9	
CN domain related information	OP	1 to <maxcndo mains></maxcndo 		
>CN domain identity	MP		CN domain identity 10.3.1.1	
>CN domain specific GSM-MAP NAS system info	MP		NAS system information (GSM-MAP) 10.3.1.9	

10.3.1.3a CN Information info full

Information Element/Group name	Need	Multi	Type and reference	Semantics description
PLMN identity	OP		PLMN identity 10.3.1.11	
CN common GSM-MAP NAS system information	OP		NAS system information (GSM-MAP) 10.3.1.9	
CN domain related information	OP	1 to <maxcndo mains></maxcndo 		
>CN domain identity	MP		CN domain identity 10.3.1.1	
>CN domain specific GSM-MAP NAS system info	MP		NAS system information (GSM-MAP) 10.3.1.9	
>CN domain specific DRX cycle length coefficient	MP		CN domain specific DRX cycle length coefficient, 10.3.3.6	

10.3.1.4 IMEI

This IE contains an International Mobile Equipment Identity. Setting specified in [11].

Information Element/Group name	Need	Multi	Type and reference	Semantics description
IMEI	MP	15		The first element contains the first IMEI digit, the second element the second IMEI digit and so on.
>IMEI digit	MP		INTEGER(015)	

424

10.3.1.5 IMSI (GSM-MAP)

This IE contains an International Mobile Subscriber Identity, used towards a GSM-MAP type of PLMN. Setting specified in [11].

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
IMSI	MP	6 to 21		The first element contains the first IMSI digit, the second element the second IMSI digit and so on. Although normally upto 15 digits are used for this IE, a bigger length is used to support future extension.
>IMSI digit	MP		INTEGER(0.	
			.9)	

10.3.1.6 Intra Domain NAS Node Selector

This IE carries information to be used to route the establishment of a signalling connection to a CN node within a CN domain.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE version	MP			
>R99				This choice shall also be used by mobiles that are compliant to this version of the protocol
>>CHOICE CN type	MP			·
>>>GSM-MAP				
>>>>CHOICE Routing basis	MP			
>>>>local (P)TMSI				TMSI allocated in the current LA or PTMSI allocated in the current RA
>>>>Routing parameter	MP		Bit string (10)	The TMSI/ PTMSI consists of 4 octets (32bits). This can be represented by a string of bits numbered from b0 to b31, with bit b0 being the least significant The "Routing parameter" bit string consists of bits b14 through b23 of the TMSI/ PTMSI. The first/leftmost/most significant bit of the bit string contains bit b23 of the TMSI/PTMSI.
>>>>(P)TMSI of same PLMN, different (RA)LA				TMSI allocated in another LA of this PLMN or PTMSI allocated in another RA this PLMN
>>>>Routing parameter	MP		Bit string (10)	The TMSI/ PTMSI consists of 4 octets (32bits). This can be represented by a string of bits numbered from b0 to b31, with bit b0 being the least significant The "Routing parameter" bit string consists of bits b14 through b23 of the TMSI/ PTMSI. The first/leftmost/most significant bit of the bit string contains bit b23 of the TMSI/ PTMSI.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	TMCL or a DTMCL allocated in
>>>>(P)TMSI of different PLMN				TMSI or a PTMSI allocated in another PLMN
>>>>>Routing parameter	MP		Bit string (10)	The TMSI/ PTMSI consists of 4 octets (32bits). This can be represented by a string of bits numbered from b0 to b31, with bit b0 being the least significant. The "Routing parameter" bit string consists of bits b14 through b23 of the TMSI/ PTMSI. The first/leftmost/most significant bit of the bit string contains bit b23 of the TMSI/ PTMSI.
>>>>IMSI(response to IMSI paging)				NAS identity is IMSI
>>>>>Routing parameter	MP		Bit string (10)	The "Routing parameter" bit string consists of DecimalToBinary [(IMSI div 10) mod 1000]. The first/leftmost bit of the bit string contains the most significant bit of the result.
>>>>IMSI(cause UE initiated event)				NAS identity is IMSI
>>>>>Routing parameter	MP		Bit string (10)	The "Routing parameter" bit string consists of DecimalToBinary [(IMSI div 10) mod 1000]. The first/leftmost bit of the bit string contains the most significant bit of the result.
>>>>IMEI				NAS parameter is IMEI
>>>>>Routing parameter	MP		Bit string (10)	The "Routing parameter" bit string consists of DecimalToBinary [(IMEI div 10) mod 1000]. The first/leftmost bit of the bit string contains the most significant bit of the result.
>>>>Spare 1			Bit string (10)	This choice shall not be used in this version
>>>>Spare 2			Bit string (10)	This choice shall not be used in this version
>>>ANSI-41			Bit string (14)	All bits shall be set to 0
>Later			Bit string(15)	This bit string shall not be sent by mobiles that are compliant to this version of the protocol.

10.3.1.7 Location Area Identification

Identifies uniquely a location area for a GSM-MAP type of PLMN. Setting specified in [5].

Information Element/Group name	Need	Multi	Type and reference	Semantics description
PLMN identity	MP		PLMN identity 10.3.1.11	
LAC	MP		Bit string(16)	The first/leftmost bit of the bit string contains the most significant bit of the LAC

10.3.1.8 NAS message

A non-access stratum message to be transferred transparently through UTRAN.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
NAS message	MP		Octet string (14095)	The first octet contains octet 1 [17] of the NAS message, the second octet contains octet 2 of the NAS message and so on.

10.3.1.9 NAS system information (GSM-MAP)

This information element contains system information that belongs to the non-access stratum for a GSM-MAP type of PLMN. This information is transparent to RRC. It may contain either information specific to one CN domain (CS or PS) or information common for both CN domains.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
GSM-MAP NAS system	MP		Octet	The first octet contains octet 1
information			string(18)	[5] of the NAS system
				information element, the
				second octet contains octet 2
				of the NAS system information
				element and so on.

10.3.1.10 Paging record type identifier

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Paging record type identifier	MP		Enumerated (IMSI (GSM- MAP), TMSI (GSM-MAP)/ P-TMSI, IMSI (DS- 41), TMSI (DS-41))	

10.3.1.11 PLMN identity

This information element identifies a Public Land Mobile Network for a GSM-MAP type of PLMN. Setting of digits is defined in [11].

Information Element/Group name	Need	Multi	Type and reference	Semantics description
MCC	MP	3		The first element contains the first MCC digit, the second element the second MCC digit and so on.
>MCC digit	MP		INTEGER(09)	
MNC	MP	2 to 3		The first element contains the first MNC digit, the second element the second MNC digit and so on.
>MNC digit	MP		INTEGER(0.	

10.3.1.12 PLMN Type

Identifies the type of Public Land Mobile Network (PLMN). This IE shall be used to control the interpretation of network dependent messages and information elements in the RRC protocol.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
PLMN Type	MP		Enumerated (GSM-MAP, ANSI-41, GSM-MAP and ANSI- 41)	One spare value is needed.

10.3.1.13 P-TMSI (GSM-MAP)

This IE contains a Packet Temporary Mobile Subscriber Identity, used towards a GSM-MAP type of PLMN.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
P-TMSI	MP		Bit string (32)	Setting specified in [11]. The first/leftmost bit of the bit string contains the most significant bit of the P-TMSI.

10.3.1.14 RAB identity

This information element uniquely identifies a radio access bearer within a CN domain.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
CHOICE RAB identity type	MP			
>RAB identity (GSM-MAP)			Bit string (8)	Formatted according to [5]. The first/leftmost bit of the bit string contains the most significant bit of the RAB identity.
>RAB identity (ANSI-41)			Bit string (8)	The first/leftmost bit of the bit string contains the most significant bit of the RAB identity.

CHOICE NAS binding info type	Condition under which the given RAB identity type is chosen
RAB identity (GSM-MAP)	PLMN is of type GSM-MAP
RAB identity (ANSI-41)	PLMN is of type ANSI-41

10.3.1.15 Routing Area Code

Identifies a routing area within a location area for a GSM-MAP type of PLMN.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Routing Area Code	MP		Bit string(8)	Setting specified in [11]. The first/leftmost bit of the bit string contains the most significant bit of the Routing Area Code.

10.3.1.16 Routing Area Identification

Identifies uniquely a routing area for a GSM-MAP type of PLMN. Setting specified in [11].

Information Element/Group name	Need	Multi	Type and reference	Semantics description
LAI	MP		Location area identification 10.3.1.7	
RAC	MP		Routing area code 10.3.1.15	

10.3.1.17 TMSI (GSM-MAP)

This IE contains a Temporary Mobile Subscriber Identity, used towards a GSM-MAP type of PLMN.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
TMSI (GSM-MAP)	MP		Bit string (32)	Setting specified in [11]. The first/leftmost bit of the bit string contains the most significant bit of the TMSI.

10.3.2 UTRAN mobility Information elements

10.3.2.1 Cell Access Restriction

Indicates the restrictions to cell access.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Cell Barred	MP		Enumerated(not barred, barred)	
Intra-frequency cell re-selection indicator	CV-Barred		Enumerated(not allowed, allowed)	
T _{barred}	CV-Barred		Integer (10,20,40,80 ,160,320,640 ,1280)	[4] [s]
Cell Reserved for operator use	MP		Enumerated(reserved, not reserved)	
Cell Reservation Extension	MP		Enumerated(reserved, not reserved)	
Access Class Barred list	CV-SIB3- MD	maxAC		Default is no access class barred is applied. The first instance of the parameter corresponds to Access Class 0, the second to Access Class 1 and so on up to Access Class 15. UE reads this IE of its access class stored in SIM.
>Access Class Barred	MP		Enumerated(not barred, barred)	-

Condition	Explanation		
Barred	The IE is mandatory present if the IE "Cell Barred"		
	has the value "Barred"; otherwise the element is not		
	needed in the message.		
SIB3-MD	The IE is mandatory and has a default value if the IE		
	"Cell Access Restriction" is included in SIB 3.		
	Otherwise the IE is not needed.		

10.3.2.2 Cell identity

This information element identifies a cell unambiguously within a PLMN.

NOTE: This information element may carry any implementation dependent identity that unambiguously identifies a cell within a PLMN.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Cell identity	MP		bit string(28)	

10.3.2.3 Cell selection and re-selection info for SIB3/4

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Mapping Info	OP		Mapping info 10.3.2.5	This IE should not be sent.	
Cell selection and reselection quality measure	MP		Enumerat ed (CPICH Ec/N0, CPICH RSCP)	Choice of measurement (CPICH Ec/N0 or CPICH RSCP) to use as quality measure Q for FDD cells. This IE is also sent to the UE in SIB11/12. Both occurrences of the IE should be set to the same value.	
CHOICE mode	MP				
>FDD					
>>S _{intrasearch}	OP		Integer (- 3220 by step of 2)	If a negative value is received the UE shall consider the value to be 0. [4] [dB]	
>>Sintersearch	OP		Integer (- 3220 by step of 2)	If a negative value is received the UE shall consider the value to be 0. [4] [dB]	
>>S _{searchHCS}	OP		Integer (- 10591 by step of 2)	If a negative value is received the UE shall consider the value to be 0. [4] [dB]	
>>RAT List	OP	1 to <maxot herRAT ></maxot 			
>>>RAT identifier	MP		Enumerat ed (GSM, cdma200 0)		

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
>>>S _{search,RAT}	MP		Integer (-	In case the value 20 is	
			3220 by	received the UE shall	
			step of 2)	consider this IE as if it	
				was absent according to [4]	
				If a negative value is	
				received the UE shall	
				consider the value to be	
				0.	
_				[dB]	
>>SHCS,RAT	OP		Integer (-	If a negative value is	
			10591 by step of	received the UE shall consider the value to be	
			2)	0.	
			-/	[4]	
				[dB]	
>>>Slimit,SearchRAT	MP		Integer (-	If a negative value is	
			3220 by	received the UE shall	
			step of 2)	consider the value to be	
				0. [4]	
				[dB]	
>>Qqualmin	MP		Integer (-	Ec/N0, [dB]	
			240)		
>>Qrxlevmin	MP		Integer (-	RSCP, [dBm]	
			11525 by step of		
			2)		
>> Delta _{Qrxlevmin}	CV-		Integer(-	If present, the actual	REL-5
Q.A.eviiiii	Delta		42 by	value of Qrxlevmin =	
			step of 2)	Qrxlevmin +	
				Delta _{Qrxlevmin}	
>TDD	OP		Intogor (If a negative value is	
>>S _{intrasearch}	OF		Integer (- 10591	received the UE shall	
			by step of	consider the value to be	
			2)	0.	
				[4]	
	0.0			[dB]	
>>Sintersearch	OP		Integer (- 10591	If a negative value is received the UE shall	
			by step of	consider the value to be	
			2)	0.	
			,	[4]	
				[dB]	
>>S _{searchHCS}	OP		Integer (-	If a negative value is	
			10591 by step of	received the UE shall consider the value to be	
			2)	0.	
			-,	[4]	
				[dB]	
>>RAT List	OP	1 to			
		<maxot< td=""><td></td><td></td><td></td></maxot<>			
		herRAT >			
>>>RAT identifier	MP		Enumerat		
			ed (GSM,		
			cdma200		
	NAD.		0)	1 0 1 01	
>>>S _{search,RAT}	MP		Integer (- 10591	In case the value 91 is received the UE shall	
			by step of	consider this IE as if it	
			2)	was absent according	
			´	to [4]	
				If a negative value is	
				received the UE shall	

Information	Need	Multi	Type and	Semantics description	Version
Element/Group name			reference		
				consider the value to be 0.	
				[dB]	
>>>S _{HCS.RAT}	OP		Integer (-	If a negative value is	
OHCS,RAT	01		10591	received the UE shall	
			by step of	consider the value to be	
			2)	0.	
			,	[4]	
				[dB]	
>>>Slimit,SearchRAT	MP		Integer (-	If a negative value is	
			10591	received the UE shall	
			by step of	consider the value to be	
			2)	0.	
				[4] [dB]	
>>Qrxlevmin	MP		Integer (-	RSCP, [dBm]	
>>QIXIEVIIIII	IVII		11525	Noci , [abiii]	
			by step of		
			2)		
>>Delta _{Qrxlevmin}	CV-		Integer(-	If present, the actual	REL-5
	Delta		42 by	value of Qrxlevmin =	
			step of 2)	Qrxlevmin +	
				Delta _{Qrxlevmin}	
Qhyst1 _s	MP		Integer	[4]	
			(040 by	[dB]	
Qhyst2 _s	CV-		step of 2) Integer	Default value is Qhyst1s	
Qiiystz _s	FDD-		(040 by	[4]	
	Quality-		step of 2)	[dB]	
	Measure		0.000 0.2)	[05]	
Treselections	MP		Integer	[s]	
-			(031)	= =	
HCS Serving cell	OP		HCS		
Information			Serving		
			cell		
			informatio		
			n 10.3.7.12		
Maximum allowed UL TX	MP		Maximum	[dBm]	
power			allowed	UE_TXPWR_MAX_RA	
			UL TX	CH in [4].	
			power		
			10.3.6.39		

Condition	Explanation
FDD-Quality-Measure	The IE is not needed if the IE "Cell selection and reselection quality measure" has the value CPICH RSCP, otherwise the IE is mandatory and has a default value.
Delta	This IE is optional if the value of Qrxlevmin is below – 115dBm. It is not needed otherwise.

10.3.2.4 Cell selection and re-selection info for SIB11/12

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Qoffset1 _{s,n}	MD		Integer(- 5050)	Default value is 0. [dB]	
Qoffset2 _{s,n}	CV- FDD- Quality- Measure		Integer(- 5050)	Default value is 0. [dB]	
Maximum allowed UL TX	MD		Maximum	According to	

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
power			allowed UL TX power 10.3.6.39	UE_TXPWR_MAX_RA CH in [4], [dBm]. If applied to FDD or TDD cells, the default is the Maximum allowed UL TX power for the serving cell. If applied to a GSM cell, the default is the UE maximum output power applicable for this GSM cell, according to the UE's radio access capability.	
HCS neighbouring cell information	OP		HCS Neighbou ring cell informatio n 10.3.7.11	- September 1	
CHOICE mode	MP				
>FDD					
>>Qqualmin	CV- FDD- Serving- Cell		Integer (- 240)	Ec/N0, [dB] Default value is Qqualmin for the serving cell	
>>Qrxlevmin	MD		Integer (- 11525 by step of 2)	RSCP, [dBm] Default value is Qrxlevmin for the serving cell	
>>Delta _{Qrxlevmin}	CV- Delta		Integer(- 42 by step of 2)	If present, the actual value of Qrxlevmin = Qrxlevmin + Delta _{Qrxlevmin}	REL-5
>TDD					
>>Qrxlevmin	MD		Integer (- 11525 by step of 2)	RSCP, [dBm] Default value is Qrxlevmin for the serving cell	
>> Delta _{Qrxlevmin}	CV- Delta		Integer(- 42 by step of 2)	If present, the actual value of Qrxlevmin = Qrxlevmin + Delta _{Qrxlevmin}	REL-5
>GSM					
>>Qrxlevmin	MD		Integer (- 11525 by step of 2)	GSM RSSI, [dBm] Default value is Qrxlevmin for the serving cell	

Condition	Explanation
FDD-Quality-Measure	This IE is mandatory and has a default value for Intra/Inter Frequency Cells if the IE "Cell selection and reselection quality measure" has the value CPICH Ec/No. Otherwise the IE is absent.
FDD-Serving-Cell	This IE is mandatory and has a default value if the serving cell is an FDD cell. Otherwise the IE is mandatory present.
Delta	This IE is optional if Qrxlevmin is present and the value of Qrxlevmin is below –115dBm. It is not needed otherwise.

10.3.2.5 Mapping Info

Information Element/Group name	Need	Multi	Type and Reference	Semantics description	Version
Mapping List	MP	1 to <maxrat></maxrat>			
>RAT	MP	WdXRAT	Enumerated (UTRA FDD, UTRA TDD 3.84 Mcps, UTRA TDD 1.28 Mcps, GSM, cdma2000)		UTRA TDD 1.28 Mcps is included for REL- 4.
>Mapping Function Parameter List	MP	1 to <maxmeas Intervals></maxmeas 	,		
>>Function type	MP		Enumerated (linear, function type 2, function type 3, function type 4)	Type of the function within the interval.	
>>Map_parameter_1	MD		Integer (099)	Parameter describing the mapping function between the quality measurement and the representing quality value, see [4]. Default value is zero for the first interval or otherwise the value of Map_parameter_2 of the interval before.	
>>Map_parameter_2	MP		Integer (099)	Parameter describing the mapping function between the quality measurement and the representing quality value, see [4].	
>>Upper_limit	CV-MaxInt		Integer (1MaxMeas)	Upper limit of interval for which the Map_parameter_1 and Map_parameter_2 are valid. MaxMeas = 25 if RAT = UTRA FDD / CPICH Ec/N0, MaxMeas = 91 if RAT = UTRA TDD 3.84 Mcps or if RAT = UTRA TDD 1.28 Mcps or if RAT = UTRA	UTRA TDD 1.28 Mcps is included for REL- 4.

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			Reference	description	
				FDD/ CPICH	
				RSCP,	
				MaxMeas = 63 if	
				RAT = GSM.	

Condition	Explanation		
MaxInt	This IE is mandatory present if Mapping Function		
	Parameter List has not reached maxMeasIntervals		
	and is not needed otherwise.		

10.3.2.6 URA identity

Gives the identity of the UTRAN Registration Area. It can be used to indicate to the UE which URA it shall use in case of overlapping URAs.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
URA identity	MP		bit string(16)	

10.3.3 UE Information elements

10.3.3.1 Activation time

Activation Time defines the frame number/time at which the operation/changes caused by the related message shall take effect. Values between 0 and 255 indicate the absolute value of CFN (Connection Frame Number) of that frame number/time.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Activation time	MP		Integer(0 255)	CFN [10]

10.3.3.2 Capability Update Requirement

This IE indicates to the UE which specific capabilities to transfer to the network.

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			reference	description	
UE radio access FDD capability	MP		Boolean	TRUE indicates	
update requirement				update required	
UE radio access 3.84 Mcps TDD	MP		Boolean	TRUE indicates	Name
capability update requirement				update required	changed
					in REL-4
UE radio access 1.28 Mcps TDD	MP		Boolean	TRUE indicates	REL-4
capability update requirement				update required	
System specific capability	OP	1 to		In this version, a	
update requirement list		<maxsyste< td=""><td></td><td>maximum size of</td><td></td></maxsyste<>		maximum size of	
		mCapabilit		4 of the list shall	
		y>		be applied and	
				any items after the	
				4 th item in the list	
				shall be ignored.	
>System specific capability	MP		Enumerated		
update requirement			(GSM		
			, GERAN lu)		REL-5

Default value is:

"UE radio capability FDD update requirement" = false

"UE radio capability 3.84 Mcps TDD update requirement" = false

"UE radio capability 1.28 Mcps TDD update requirement" = false

"System specific capability update requirement" not present.

10.3.3.3 Cell update cause

Indicates the cause for cell update.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Cell update cause	MP		Enumerated (cell reselection, periodical cell update, uplink data transmission , paging response, re-entered service area, radio link failure, RLC unrecoverabl e error)	One spare value is needed.

10.3.3.4 Ciphering Algorithm

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Ciphering algorithm	MP		Enumerated	
			(UEA0,	
			UEA1)	

10.3.3.5 Ciphering mode info

This information element contains the ciphering specific security mode control information.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Ciphering mode command	MP		Enumerated (start/restart)	
Ciphering algorithm	MP		Ciphering algorithm 10.3.3.4	
Ciphering activation time for DPCH	OP		Activation time 10.3.3.1	Used for radio bearers mapped on RLC-TM. Only applicable if the UE is already in CELL_DCH state
Radio bearer downlink ciphering activation time info	OP		RB activation time info, 10.3.4.13	Used for radio bearers mapped on RLC-AM or RLC- UM

10.3.3.6 CN domain specific DRX cycle length coefficient

A coefficient in the formula to count the paging occasions to be used by a specific UE (specified in [4]).

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
CN domain specific DRX cycle length coefficient	MP		Integer(69)	Refers to 'k' in the formula as specified in [4], Discontinuous reception

10.3.3.7 CPCH Parameters

NOTE: Only for FDD.

These parameters are used by any UE using any CPCH set allocated to the cell that is broadcasting this system information.

Information Element/Group	Need	Multi	Type and	Semantics description	
name			reference		
Initial Priority Delay	OP	1 to maxASC		Initial delays for ASC priority.	
>NS_IP	MP		Integer (028)	Number of slots for initial fixed delay for each ASC priority level	
Backoff control parameters	MP				
>N_ap_retrans_max	MP		Integer (164)	Max number of AP transmissions without AP-AICH response, a PHY parameter.	
>N_access_fails	MP		Integer (164)	Max number of preamble ramping cycles when NAK response received, a MAC parameter.	
>NF_bo_no aich	MP		Integer (031)	Number of frames for UE backoff after Nap_retrans_max unsuccessful AP access attempts, a MAC parameter.	
>NS_bo_busy	MP		Integer (063)	Number of slots for UE fixed backoff after access attempt to busy CPCH, a MAC parameter.	
>NF_bo_all_busy	MP		Integer (031)	Max number of frames for UE backoff after access attempt to last busy CPCH, a MAC parameter. UE randomly selects backoff value from range (0NF_bo_all_busy)	
>NF_bo_mismatch	MP		Integer (0127)	Max number of frames for the UE backoff after received mismatch on CD/CA-ICH, a MAC parameter. UE randomly selects backoff value from range (0NF_bo_mismatch)	
>T_CPCH	MP		Enumerated (0, 1)	CPCH channel timing used to determine Tau, a PHY parameter	
Power Control Algorithm	MP		Enumerated (algorithm 1, algorithm 2)	Specifies algorithm to be used by UE to interpret TPC commands	
TPC step size	CV-algo		Integer (1, 2)	In dB	
DL DPCCH BER	MP		Integer (063)	The BER quality value shall be set in the range 0 ≤ DPCCH BER ≤ 1 in the unit BER_dB where: BER_dB_0: DPCCH BER = 0	

Information Element/Group name	Need	Multi	Type and reference	Semantics description
				BER_dB_1: -∞ < Log10(DPCCH BER) < -4.03 BER_dB_2: -4.03 ≤
				Log10(DPCCH BER) < -3.965 BER_dB_3: -3.965 ≤ Log10(DPCCH BER) < -3.9
				BER_dB_61: -0.195 ≤ Log10(DPCCH BER) < -0.13
				BER_dB_62: -0.13 ≤ Log10(DPCCH BER) < -0.065
				BER_dB_63: -0.065 ≤ Log10(DPCCH BER) ≤ 0

Condition	Explanation		
algo	The IE is mandatory present if "Power Control		
	Algorithm" is set to "algorithm 1", otherwise the IE is		
	not needed		

10.3.3.8 C-RNTI

The cell RNTI (C-RNTI) identifies a UE having a RRC connection within a cell.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
C-RNTI	MP		bit string(16)	

10.3.3.9 DRAC system information

Information element	Need	Multi	Type and reference	Semantics description
DRAC system information	MP	1 to <maxdra Cclasses></maxdra 		DRAC information is sent for each class of terminal
>Transmission probability	MP		Transmissio n probability 10.3.3.39	
>Maximum bit rate	MP		Maximum bit rate 10.3.3.20	

10.3.3.9a DSCH-RNTI

In FDD, the DSCH-RNTI identifies a UE in CELL_DCH using a DSCH within a cell. In TDD, the DSCH-RNTI identifies a UE in CELL_DCH or CELL_FACH using a DSCH or USCH within the cell.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
DSCH-RNTI	MP		bit string(16)	

10.3.3.10 Void

10.3.3.11 Establishment cause

Cause for an RRC connection establishment request.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Establishment cause	MP		Enumerated(Originating Conversatio nal Call, Originating Streaming Call, Originating Interactive Call, Originating Background Call, Originating Subscribed traffic Call, Terminating Conversatio nal Call, Terminating Streaming Call, Terminating Interactive Call, Terminating Background Call, Terminating Interactive Call, Terminating Background Call, Terminating High Priority Signalling, Originating Low Priority Signalling, Terminating High Priority Signalling, Terminating Low Priority Signalling, Terminating	Twelve spare values are needed.

10.3.3.12 Expiration Time Factor

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Expiration Time Factor	MP		Enumerated(
			2times,	
			4times,	
			8times,	
			16times,	
			32times,	
			64times,	
			128times,	
			256times)	

10.3.3.13 Failure cause

Cause for failure to perform the requested procedure.

Failure cause MP Enumerated (configuratio n unsupported, physical channel failure, incompatible simultaneou s reconfigurati on, protocol error, compressed mode runtime error, cell update occurred, invalid configuration	Information Element/Group name	Need	Multi	Type and reference	Semantics description
configuration incomplete, unsupported measuremen t)		MP		Enumerated (configuratio n unsupported, physical channel failure, incompatible simultaneou s reconfigurati on, protocol error, compressed mode runtime error, cell update occurred, invalid configuration , configuration incomplete, unsupported measuremen	

10.3.3.14 Failure cause and error information

Cause for failure to perform the requested procedure.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Failure cause	MP		Failure	
			cause	
			10.3.3.13	
Protocol error information	CV-ProtErr		Protocol	
			error	
			information	
			10.3.8.12	
Deleted TGPSI	CV-		TGPSI	
	CompMod		10.3.6.82	
	eErr			

Condition	Explanation
ProtErr	The IE is mandatory present if the IE "Failure cause" has the value "Protocol error"; otherwise it is not
	needed in the message.
CompModeErr	The IE is mandatory present if the IE "Failure cause" has the value " Compressed mode runtime error";
	otherwise it is not needed in the message

10.3.3.140 Group release information

Contains addressing information to perform a release of a group of RRC connections.

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			reference	description	
U-RNTI group	MP		U-RNTI		REL-5
			group		
			10.3.3.47a		

10.3.3.14a H-RNTI

The H-RNTI identifies an UE having a HS-PDSCH assignment within a cell.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
H-RNTI	MP		bit string(16)		REL-5

10.3.3.15 Initial UE identity

This information element identifies the UE at a request of an RRC connection.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE UE id type	MP			
>IMSI (GSM-MAP)			IMSI (GSM- MAP) 10.3.1.5	
>TMSI and LAI (GSM-MAP)				
>>TMSI (GSM-MAP)	MP		TMSI (GSM- MAP) 10.3.1.17	
>>LAI (GSM-MAP)	MP		Location Area Identification 10.3.1.7	
>P-TMSI and RAI (GSM-MAP)				
>>P-TMSI (GSM-MAP)	MP		P-TMSI (GSM-MAP) 10.3.1.13	
>>RAI (GSM-MAP)	MP		Routing Area Identification 10.3.1.16	
>IMEI			IMEI 10.3.1.4	
>ESN (DS-41)			Bit string (SIZE (32))	TIA/EIA/IS-2000-4
>IMSI (DS-41)			Octet string (SIZE (57))	TIA/EIA/IS-2000-4
>IMSI and ESN (DS-41)				TIA/EIA/IS-2000-4
>>IMSI (DS-41)	MP		Octet string (SIZE (57))	TIA/EIA/IS-2000-4

>>ESN (DS-41)	MP	Bit string (SIZE (32))	TIA/EIA/IS-2000-4
>TMSI (DS-41)		Octet string (SIZE (217))	TIA/EIA/IS-2000-4 Although normally upto 12 digits are used for this IE, a bigger length is used to support future extension.

10.3.3.16 Integrity check info

The Integrity check info contains the RRC message sequence number needed in the calculation of XMAC-I [40] and the calculated MAC-I.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Message authentication code	MP		bit string(32)	MAC-I [40]. The first/leftmost bit of the bit string contains the most significant bit of the MAC-I. The 27 MSB of the IE shall be set to zero and the 5 LSB of the IE shall be set to the value of the IE "RB identity" for the used signalling radio bearer when the encoded RRC message is used as the MESSAGE parameter in the integrity protection algorithm.
RRC Message sequence number	MP		Integer (015)	The local RRC hyper frame number (RRC HFN) is concatenated with the RRC message sequence number to form the input parameter COUNT-I for the integrity protection algorithm. The IE value shall be set to zero when the encoded RRC message is used as the MESSAGE parameter in the integrity protection algorithm.

10.3.3.17 Integrity protection activation info

This IE contains the time, in terms of RRC sequence numbers, when a new integrity protection configuration shall be activated for the signalling radio bearers.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
RRC message sequence number list	MP	4 to 5		The RRC sequence number when a new integrity protection configuration shall be applied, for signalling radio bearers in the order RB0, RB1, RB2, RB3, RB4. The value for RB1 shall be ignored if this IE was included in a RRC message sent on RB1. The value for RB2 shall be ignored if this IE was included in a RRC message sent on RB1.
>RRC message sequence number	MP		Integer (0 15)	

10.3.3.18 Integrity protection Algorithm

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Integrity protection algorithm	MP		Enumerated (UIA1)	

10.3.3.19 Integrity protection mode info

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Integrity protection mode command	MP		Enumerated(start, modify)	
Downlink integrity protection activation info	CV-modify		Integrity protection activation info 10.3.3.17	
Integrity protection algorithm	OP		Integrity protection algorithm 10.3.3.18	
Integrity protection initialisation number	CV-start		Bit string(32)	FRESH [40]. The first/leftmost bit of the bit string contains the most significant bit of the FRESH.

Condition	Explanation
Start	The IE is mandatory present if the IE "Integrity
	protection mode command" has the value "start ",
	otherwise it is not needed in the message.
Modify	The IE is mandatory present if the IE "Integrity
	protection mode command" has the value "modify" and
	not needed otherwise.

10.3.3.19a Void

10.3.3.20 Maximum bit rate

NOTE: Only for FDD.

Indicates the maximum user bit rate allowed on a DCH controlled by DRAC procedure for the transmission period (Transmission time validity).

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Maximum bit rate	MP		integer(051 2 by step of	=kbit/s
			16)	

10.3.3.21 Measurement capability

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Need for downlink compressed mode					
FDD measurements	MP		Boolean	TRUE means that the UE requires DL compressed mode in order to perform measurements on FDD	
3.84 Mcps TDD measurements	CV- 3.84_Mcps _tdd_sup		Boolean	TRUE means that the UE requires DL compressed mode in order to perform measurements on 3.84 Mcps TDD	Name changed in REL-4
1.28 Mcps TDD measurements	CV- 1.28_Mcps _tdd_sup		Boolean	TRUE means that the UE requires DL compressed mode in order to perform measurements on 1.28 Mcps TDD	REL-4
GSM measurements	CV- gsm_sup				
>GSM 900	MP		Boolean	TRUE means that the UE requires DL compressed mode in order to perform measurements on GSM 900	
>DCS 1800	MP		Boolean	TRUE means that the UE requires DL compressed mode in order to perform measurements on DCS 1800	
>GSM 1900	MP		Boolean	TRUE means that the UE requires DL compressed mode in order to perform measurements on GSM 1900	
Multi-carrier measurement	CV- mc_sup		Boolean	TRUE means that the UE requires DL compressed mode in order to perform measurements on multi-carrier	

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Need for uplink compressed mode					
FDD measurements	MP		Boolean	TRUE means that the UE requires UL compressed mode in order to perform measurements on FDD	
3.84 Mcps TDD measurements	CV- 3.84_Mcps _tdd_sup		Boolean	TRUE means that the UE requires UL compressed mode in order to perform measurements on 3.84 Mcps TDD	Name changed in REL-4
1.28 Mcps TDD measurements	CV- 1.28_Mcps _tdd_sup		Boolean	TRUE means that the UE requires DL compressed mode in order to perform measurements on 1.28 Mcps TDD	REL-4
GSM measurements	CV- gsm_sup				
>GSM 900	MP		Boolean	TRUE means that the UE requires UL compressed mode in order to perform measurements on GSM 900	
>DCS 1800	MP		Boolean	TRUE means that the UE requires UL compressed mode in order to perform measurements on DCS 1800	
>GSM 1900	MP		Boolean	TRUE means that the UE requires UL compressed mode in order to perform measurements on GSM 1900	
Multi-carrier measurement	CV- mc_sup		Boolean	TRUE means that the UE requires UL compressed mode in order to perform measurements on multi-carrier	

Condition	Explanation
3.84_Mcps_tdd_sup	The IE is mandatory present if an IE "TDD RF capability" is present with the IE "Chip rate capability" set to "3.84 Mcps". Otherwise this field is not needed in the message.
1.28_Mcps_tdd_sup	The IE is mandatory present if an IE "TDD RF capability" is present with the IE "Chip rate capability" set to "1.28 Mcps". Otherwise this field is not needed in the message.
gsm_sup	The IE is mandatory present if the IE "Inter-RAT UE radio access capability" indicates support for GSM900, GSM1800 and/or GSM1900. Otherwise this field is not needed in the message.
mc_sup	The IE is mandatory present if the IE "Support of multi-carrier" has the value TRUE. Otherwise this field is not needed in the message.

10.3.3.21a Measurement capability extension

This IE may be used to replace the measurement capability information provided within IE "Measurement capability".

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
FDD measurements	MP	1 to <maxfre qBands FDD></maxfre 			
>FDD Frequency band	MD		Enumerat ed(Band I, Band II,	The default value is the same as indicated in the IE "Frequency band" included in the IE " UE radio access capability extension". Band numbering is defined in [21]. Five spare values are needed	
			Band III)		REL-5
>Need for DL compressed mode	MP		Boolean	TRUE means that the UE requires DL compressed mode in order to perform measurements on the FDD frequency band indicated by the IE "FDD Frequency band"	
>Need for UL compressed mode	MP		Boolean	TRUE means that the UE requires UL compressed mode in order to perform measurements on the FDD frequency band indicated by the IE "FDD Frequency band"	
TDD measurements	CV- tdd_sup	1 to <maxfre qBands TDD></maxfre 			
>TDD Frequency band	MP		Enumerat ed(a, b, c)		

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
>Need for DL compressed mode	MP		Boolean	TRUE means that the UE requires DL compressed mode in order to perform measurements on TDD frequency band indicated by the IE "TDD Frequency band"	
>Need for UL compressed mode	MP		Boolean	TRUE means that the UE requires UL compressed mode in order to perform measurements on TDD frequency band indicated by the IE "TDD Frequency band"	
GSM measurements	CV- gsm_su p	1 to <maxfre qBands GSM></maxfre 			
>GSM Frequency band	MP		Enumerat ed(GSM4 50, GSM480, GSM850, GSM900 P, GSM900 E, GSM1800 ,	as defined in [45]. Nine spare values are needed.	
>Need for DL compressed mode	MP		Boolean	TRUE means that the UE requires DL compressed mode in order to perform measurements on GSM frequency band indicated by the IE "GSM Frequency band"	
>Need for UL compressed mode	MP		Boolean	TRUE means that the UE requires UL compressed mode in order to perform measurements on GSM frequency band indicated by the IE "GSM Frequency band"	
Multi-carrier	CV-				
measurement >Need for DL compressed mode	mc_sup MP		Boolean	TRUE means that the UE requires DL compressed mode in order to perform measurements on multicarrier	
>Need for UL compressed mode	MP		Boolean	TRUE means that the UE requires UL compressed mode in order to perform measurements on multicarrier	

Condition	Explanation
tdd_sup	The IE is mandatory present if the IE "Multi-mode capability" has the value "TDD" or "FDD/TDD".
	Otherwise this field is not needed in the message.
gsm_sup	The IE is mandatory present if the IE "Support of GSM" has the value TRUE. Otherwise this field is not needed in the message.
mc_sup	The IE is mandatory present if the IE "Support of multi-carrier" has the value TRUE. Otherwise this field is not needed in the message.

10.3.3.22 Paging cause

Cause for a CN originated page.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Paging cause	MP		Enumerated(Terminating Conversatio nal Call, Terminating Streaming Call, Terminating Interactive Call, Terminating Background Call, Terminating High Priority Signalling, Terminating Low Priority Signalling, Terminating	One spare value is needed.

10.3.3.23 Paging record

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
CHOICE Used paging identity	MP				
>CN identity					
>>Paging cause	MP		Paging cause 10.3.3.22		
>>CN domain identity	MP		CN domain identity 10.3.1.1		
>>CHOICE UE Identity	MP			Three spare values are needed.	
>>>IMSI (GSM-MAP)			IMSI (GSM- MAP) 10.3.1.5		
>>>TMSI (GSM-MAP)			TMSI (GSM- MAP)		

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
•			10.3.1.17		
>>>P-TMSI (GSM-MAP)			P-TMSI		
,			(GSM-		
			MAP)		
			10.3.1.13		
>>>IMSI (DS-41)			TIA/EIA/I		
			S-2000-4		
>>>TMSI (DS-41)			TIA/EIA/I		
			S-2000-4		
>UTRAN single UE					
identity					
>>U-RNTI	MP		U-RNTI		
			10.3.3.47		
>>CN originated page to connected mode UE	OP				
>>>Paging cause	MP		Paging		
a a a a a a a a a a a a a a a a a a a			cause		
			10.3.3.22		
>>>CN domain identity	MP		CN		
222 Ort domain idomity			domain		
			identity		
			10.3.1.1		
>>>Paging record type	MP		Paging		
identifier	14		record		
identino			type		
			identifier		
			10.3.1.10		
>>RRC connection	MP		RRC		REL-5
release information			connectio		1122 0
Tologoo imorriadion			n release		
			informatio		
			n		
			10.3.3.35		
			0		
>UTRAN group identity		1 to	-		REL-5
2 group identity		<maxur< td=""><td></td><td></td><td></td></maxur<>			
		NTIgrou			
		p>			
>>RRC connection	MP	F	RRC		REL-5
release information			connectio		0
			n release		
			informatio		
			n		
			10.3.3.35		
			0		
>>Group release	MP		Group		REL-5
information			release		0
			informatio		
			n		
			10.3.3.14		
	1		0		

Condition	Explanation		
CHOICE Used paging identity	Condition under which the given used paging		
	identity is chosen		
CN identity	For CN originating pages (for idle mode UEs)		
UTRAN single UE identity	For UTRAN originating pages (for connected mode		
	UEs), addressing a single UE		
UTRAN group identity	For UTRAN originating pages (for connected mode		
	UEs), addressing a group of UEs		

10.3.3.24 PDCP capability

Indicates which algorithms and which value range of their parameters are supported by the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Support for lossless SRNS relocation	MP		Boolean	TRUE means supported	
Support for RFC2507	MP		Boolean	TRUE means supported	
>Max HC context space	MP		Integer(512, 1024, 2048, 4096, 8192,		
			16384, 32768, 65536, 131072)	Note 1	REL-5
Support for RFC 3095	CV- not_iRAT_ HoInfo		Boolean	TRUE means supported	REL-4
>Maximum number of ROHC context sessions	MD		Integer(2, 4, 8, 12, 16, 24, 32, 48, 64, 128, 256, 512, 1024, 16384)	Default value is 16.	REL-4
>Reverse decompression depth	MD		Integer (065535)	Default value is 0 (reverse decompression is not supported).	REL-4
>Support for RFC 3095 context relocation	MP		Boolean	TRUE means supported	REL-5

Note 1: The IE "Max HC context space" values 16384, 32768, 65536 and 131072 are not used in the INTER RAT HANDOVER INFO message.

Condition	Explanation
not_iRAT_HoInfo	The IE is not needed in the INTER RAT HANDOVER
	INFO message. Otherwise, it is mandatory present.

10.3.3.25 Physical channel capability

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			Reference	description	
Downlink physical channel capability information elements					
FDD downlink physical channel capability	CH- fdd_req_su p				
>Max no DPCH/PDSCH codes	MP		Integer (18)	Maximum number of DPCH/PDSCH codes to be simultaneously received	
>Max no physical channel bits received	MP		Integer (1200, 2400, 3600, 4800, 7200, 9600, 14400, 19200, 28800, 38400, 48000, 57600, 67200, 76800)	Maximum number of physical channel bits received in any 10 ms interval (DPCH, PDSCH, S-CCPCH)	

Information Element/Group name	Need	Multi	Type and Reference	Semantics description	Version
>Support for SF 512	MP		Boolean	TRUE means supported	
>Support of PDSCH	MP		Boolean	TRUE means supported	
>CHOICE Support of HS- PDSCH	CV- not_iRAT_ HoInfo			сирропои	REL-5
>>Supported					REL-5
>>>HS-DSCH physical layer category	MP		Integer (164)		REL-5
>>>Support of dedicated pilots for channel estimation of HS- DSCH	MP		Boolean	TRUE means supported	REL-5
>>>Simultaneous reception of SCCPCH, DPCH and HS-PDSCH	MP		Boolean	TRUE means supported. This IE shall only be set to TRUE in the case the IE 'Simultaneous reception of SCCPCH and DPCH' is set to TRUE	REL-5
>>Unsupported				(no data)	REL-5
>Simultaneous reception of SCCPCH and DPCH	MP		Boolean	TRUE means supported	
>Simultaneous reception of SCCPCH, DPCH and PDSCH	CV- if_sim_rec _pdsch _sup		Boolean	TRUE means supported	
>Max no of S-CCPCH RL	CV- if_sim_rec		Integer(1)	Maximum number of simultaneous S-CCPCH radio links	
>Support of dedicated pilots for channel estimation	MD		Enumerated (true)	Presence of this element means supported and absence not supported. This IE shall be set to TRUE in this version of the protocol.	
3.84 Mcps TDD downlink physical channel capability	CH- 3.84_Mcps _tdd_req_s up				Name changed in REL-4
>Maximum number of timeslots per frame	MP		Integer (114)		
>Maximum number of physical channels per frame	MP		Integer (5224)		
>Minimum SF	MP		Integer (1, 16)		
>Support of PDSCH	MP		Boolean	TRUE means supported	
>CHOICE Support of HS- PDSCH	CV- not_iRAT_ HoInfo				REL-5
>>Supported					REL-5
>>>HS-DSCH physical layer category	MP		Integer (164)		REL-5
>>Unsupported				(no data)	REL-5
>Maximum number of physical channels per timeslot	MP		Integer (516)		

Information Element/Group name	Need	Multi	Type and Reference	Semantics description	Version
1.28 Mcps TDD downlink	CH-				REL-4
physical channel capability	1.28_Mcps _tdd_req_s up				
>Maximum number of timeslots per subframe	MP		Integer (16)		REL-4
>Maximum number of physical channels per subframe	MP		Integer (196)		REL-4
>Minimum SF	MP		Integer (1, 16)		REL-4
>Support of PDSCH	MP		Boolean	TRUE means supported	REL-4
>CHOICE Support of HS- PDSCH	CV- not_iRAT_ HoInfo				REL-5
>>Supported					REL-5
>>>HS-DSCH physical layer category	MP		Integer (164)		REL-5
>>Unsupported				(no data)	REL-5
>Maximum number of physical channels per timeslot	MP		Integer (116)		REL-4
>Support of 8PSK	MP		Boolean	TRUE means supported	REL-4
Uplink physical channel capability information elements					
FDD uplink physical channel capability	CH- fdd_req_su p				
>Maximum number of DPDCH bits transmitted per 10 ms	MP		Integer (600, 1200, 2400, 4800. 9600, 19200. 28800, 38400, 48000, 57600)		
>Support of PCPCH	MP		Boolean	TRUE means supported	
3.84 Mcps TDD uplink physical channel capability	CH- 3.84_Mcps _tdd_req_s up				Name changed in REL-4
>Maximum Number of timeslots per frame	MP		Integer (114)		
>Maximum number of physical channels per timeslot	MP		Integer (1, 2)		
>Minimum SF	MP		Integer (1, 2, 4, 8)		
>Support of PUSCH	MP		Boolean	TRUE means supported	
1.28 Mcps TDD uplink physical channel capability	CH- 1.28_Mcps _tdd_req_s up				REL-4
>Maximum Number of timeslots per subframe	MP		Integer (16)		REL-4
>Maximum number of physical channels per timeslot	MP		Integer (1, 2)		REL-4
>Minimum SF	MP		Integer (1, 2, 4, 8, 16)		REL-4
>Support of PUSCH	MP		Boolean	TRUE means supported	REL-4
>Support of 8PSK	MP		Boolean	TRUE means	REL-4

Information Element/Group name	Need	Multi	Type and Reference	Semantics description	Version
				supported	

Condition	Explanation
if_sim_rec_pdsch_sup	The IE is mandatory present if the IE "Simultaneous reception of SCCPCH and DPCH" = True and IE Support of PDSCH = True. Otherwise this field is not needed in the message.
if_sim_rec	The IE is mandatory present if the IE "capability Simultaneous reception of SCCPCH and DPCH" = True. Otherwise this field is not needed in the message.
3.84_Mcps_tdd_req_sup	The IE is mandatory present if the IE "TDD RF capability" is present with the IE "Chip rate capability" set to "3.84 Mcps" and a 3.84 Mcps TDD capability update has been requested in a previous message. Otherwise this field is not needed in the message.
1.28_Mcps_tdd_req_sup	The IE is mandatory present if the IE "TDD RF capability" is present with the IE "Chip rate capability" set to "1.28 Mcps" and a 1.28 Mcps TDD capability update has been requested in a previous message. Otherwise this field is not needed in the message.
fdd_req_sup	The IE is mandatory present if the IE "Multi-mode capability" has the value "FDD" or "FDD/TDD" and a FDD capability update has been requested in a previous message. Otherwise this field is not needed in the message.
not_iRAT_HoInfo	The CHOICE Support of HS-PDSCH is not needed in the INTER RAT HANDOVER INFO message. Otherwise, it is mandatory present.

10.3.3.26 Protocol error cause

This IE indicates the cause for a message or information that was not comprehended.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Protocol error cause	MP		Enumerated (ASN.1 violation or encoding error, Message type non- existent or not implemented , Message not compatible with receiver state, Information element value not comprehend ed, Information element missing, Message extension not comprehend ed)	Two spare values are needed.

453

10.3.3.27 Protocol error indicator

This IE indicates whether a message was transmitted due to a protocol error or not.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
Protocol error indicator	MP		Boolean	TRUE means a protocol error occurred. FALSE means a protocol error did not occur.

10.3.3.28 RB timer indicator

This IE is used to indicate to UTRAN if the timers T314 or T315 has expired in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
T314 expired	MP		Boolean	TRUE means that the timer has expired or the stored value is zero. FALSE means that the timer has not expired.
T315 expired	MP		Boolean	TRUE means that the timer has expired or the stored value is zero. FALSE means that the timer has not expired.

10.3.3.29 Redirection info

This IE is used to redirect the UE to another frequency or other system.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE Redirection Information	MP			
>Frequency info			Frequency info 10.3.6.36	
>Inter-RAT info			Inter-RAT info 10.3.7.25	

10.3.3.30 Re-establishment timer

This information element indicates which timer to associate with RAB.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Re-establishment timer	MP		Enumerated(
			useT314,	
			useT315)	

10.3.3.31 Rejection cause

Cause for rejection of RRC connection establishment request.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Rejection cause	MP		Enumerated(
			congestion,	
			unspecified)	

10.3.3.32 Release cause

Cause for release of RRC connection.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Release cause	MP		Enumerated (normal event, unspecified, pre-emptive release, congestion, re-establishme nt reject, user inactivity), directed signalling connection re-establishme nt)	One spare value is needed.

10.3.3.32a RF Capability Compressed

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
CHOICE FDD	MP				REL-5
>Supported					REL-5
>>RF capability band FDD list Compressed	MP	1 <maxf reqband sFDD></maxf 			REL-5
>>>RF Capability Band FDD Compressed	MP		Enumerated (not supported, 190, 174.8-205.2, 134.8-245.2)	In MHz adefined in [21]. NOTE: Not applicable if UE is not operating in frequency band I (as defined in [21]).	REL-5
>Not supported			NULL		REL-5
CHOICE TDD-3.84Mcps	MP				REL-5
>Supported					REL-5
>>Radio Frequency Band TDD List	MP		Enumerated (a, b, c, a+b, a+c, b+c, a+b+c)	As defined in [22]. One spare value needed	REL-5
>Not supported			NULL		REL-5
CHOICE TDD-1.28Mcps	MP				REL-5
>Supported					REL-5
>>Radio Frequency Band TDD List	MP		Enumerated (a, b, c, a+b, a+c, b+c, a+b+c)	As defined in [22]. One spare value needed	REL-5
>Not supported			NULL		REL-5

10.3.3.33 RF capability FDD

Information Element/Group name	Need	Multi	Type and Reference	Semantics description	Version
UE power class	MP		Enumerated(14)	as defined in [21]	
Tx/Rx frequency separation	MP		Enumerated(190, 174.8- 205.2, 134.8-245.2)	In MHz as defined in [21]. NOTE: Not applica ble if UE is not operati ng in frequen cy band I (as defined in [21]).	

10.3.3.33a RF capability FDD extension

Information Element/Group	Need	Multi	Type and	Semantics description
name			Reference	
UE power class extension	MP		Enumerated(as defined in [21]. Four spare
			14)	values are needed
Tx/Rx frequency separation	MP		Enumerated(In MHz
			190, 174.8-	as defined in [21].
			205.2,	NOTE: Not applicable if UE
			134.8-245.2)	is not operating in
				frequency band I
				(as defined in [21]).

10.3.3.33b RF capability TDD

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
UE power class	MP		Enumerated (14)	as defined in [22]
Radio frequency bands	MP		Enumerated(a, b, c, a+b, a+c, b+c, a+b+c)	as defined in [22]. One spare value needed.
Chip rate capability	MP		Enumerated(3.84Mcps,1. 28Mcps)	as defined in [22]

10.3.3.33c RF capability TDD 1.28 Mcps

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
Radio frequency bands	MP		Enumerated(a, b, c, a+b, a+c, b+c, a+b+c)	as defined in [22]. One spare value needed.

10.3.3.34 RLC capability

Information Element/Group name	Need	Multi	Type and Referenc	Semantics description	Version	
Total RLC AM buffer size	MP		e Integer (10, 50, 100, 150, 500, 1000, 200, 300, 400, 750)	Total receiving and transmitting RLC AM buffer and MAC-hs reordering buffer capability in kBytes. Note 1.	REL-5	
Maximum RLC AM Window Size	MP		Integer(20 47,4095)	Maximum supported RLC TX and RX window in UE		
Maximum number of AM entities	MP		Integer (4,5,6,8,1 6,30)			
Note 1: The IE "Total RLC AM buffer size" values 200, 300, 400 and 750 are not used in the INTER RAT HANDOVER INFO message.						

10.3.3.35 RLC re-establish indicator

This IE is used to re-configure AM RLC on c-plane and u-plane.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
RLC re-establish indicator	MP		Boolean	TRUE means re-establish required FALSE means re-establish not required

10.3.3.350 RRC connection release information

Indicates whether the UE shall perform a release of the RRC connection.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
CHOICE Release indicator	MD			Default value is 'No release'	REL-5
>No release					REL-5
>Release					REL-5
>>Release cause	MP		Release cause 10.3.3.32		REL-5

10.3.3.35a RRC State Indicator

Indicates to a UE the RRC state to be entered.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
RRC State indicator	MP		Enumerated(
			CELL_DCH,	
			CELL_FACH	
			,	
			CELL_PCH,	
			URA_PCH)	

10.3.3.36 RRC transaction identifier

This IE contains an identification of the RRC procedure transaction local for the type of the message this IE was included within.

Information	Need	Multi	Type and	Semantics description	Version
Element/Group name			reference		
RRC transaction	MP		Integer		
identifier			(03)		
	CV-		Integer		REL-5
	Measure		(015)		
	ment		,		

Condition	Explanation
Measurement	This IE is mandatory present if used in MEASUREMENT_CONTROL or MEASUREMENT_CONTROL_FAILURE message otherwise it is absent

10.3.3.37 Security capability

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Ciphering algorithm capability	MP			
>UEA0	MP		Boolean	
>UEA1	MP		Boolean	
>Spare	MP	14	Boolean	Shall be set to FALSE by UEs complying with this version of the protocol.
Integrity protection algorithm capability	MP			
>UIA1	MP		Boolean	The value TRUE means that UIA1, Kasumi, is supported
>Spare	MP	15	Boolean	Shall be set to FALSE by UEs complying with this version of the protocol.

10.3.3.38 START

There is a START value per CN domain. The START is used to initialise the 20 MSBs of all hyper frame numbers (MAC-d HFN, RLC UM HFN, RLC AM HFN, RRC HFN) for a CN domain.

Information Element/Group	Need	Multi	Type and	Semantics description
name			Reference	
START	MP		Bit string (20)	START [40]. The first/leftmost bit of the bit string contains the most significant bit of the START.

10.3.3.39 Transmission probability

NOTE: Only for FDD.

Indicates the probability for a mobile to be allowed to transmit on a DCH controlled by DRAC procedure.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Transmission probability	MP		Real(0.125	probability
			1.0 by step	
			of 0.125)	

10.3.3.40 Transport channel capability

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
Downlink transport channel capability information elements				
Max no of bits received	MP		Integer(640, 1280, 2560, 3840, 5120, 6400, 7680, 8960, 10240, 20480, 40960, 81920, 163840)	Maximum sum of number of bits of all transport blocks received at an arbitrary time instant
Max convolutionally coded bits received	MP		Integer(640, 1280, 2560, 3840, 5120, 6400, 7680, 8960, 10240, 20480, 40960, 81920, 163840)	Maximum sum of number of bits of all convolutionally coded transport blocks received at an arbitrary time instant
Max turbo coded bits received	CV- turbo_dec_ sup		Integer(640, 1280, 2560, 3840, 5120, 6400, 7680, 8960, 10240, 20480, 40960, 81920, 163840)	Maximum sum of number of bits of all turbo coded transport blocks received at an arbitrary time instant
Maximum number of simultaneous transport channels	MP		Integer(4, 8, 16, 32)	
Maximum number of simultaneous CCTrCH	MP		Integer (18)	
Max no of received transport blocks	MP		Integer(4, 8, 16, 32, 48, 64, 96, 128, 256, 512)	Maximum total number of transport blocks received within TTIs that end at within the same 10ms interval
Maximum number of TFC	MP		Integer(16, 32, 48, 64, 96, 128, 256, 512, 1024)	
Maximum number of TF	MP		Integer(32, 64, 128, 256, 512, 1024)	
Support for turbo decoding	MP		Boolean	TRUE means supported
Uplink transport channel capability information elements				
Max no of bits transmitted	MP		Integer(640, 1280, 2560, 3840, 5120, 6400, 7680, 8960, 10240, 20480, 40960, 81920, 163840)	Maximum sum of number of bits of all transport blocks transmitted at an arbitrary time instant

Information Element/Group	Need	Multi	Type and	Semantics description
name			Reference	
Max convolutionally coded bits transmitted	MP		Integer(640, 1280, 2560, 3840, 5120, 6400, 7680, 8960, 10240, 20480, 40960, 81920, 163840)	Maximum sum of number of bits of all convolutionally coded transport blocks transmitted at an arbitrary time instant
Max turbo coded bits transmitted	CV- turbo_enc_ sup		Integer(640, 1280, 2560, 3840, 5120, 6400, 7680, 8960, 10240, 20480, 40960, 81920, 163840)	Maximum sum of number of bits of all turbo coded transport blocks transmitted at an arbitrary time instant
Maximum number of	MP		Integer(4, 8,	
simultaneous transport channels			16, 32)	
Maximum number of simultaneous CCTrCH of DCH type	CH- tdd_req_su p		Integer (18)	
Max no of transmitted transport blocks	MP		Integer(4, 8, 16, 32, 48, 64, 96, 128, 256, 512)	Maximum total number of transport blocks transmitted within TTIs that start at the same time
Maximum number of TFC	MP		Integer(16, 32, 48, 64, 96, 128, 256, 512, 1024)	
Maximum number of TF	MP		Integer(32, 64, 128, 256, 512, 1024)	
Support for turbo encoding	MP		Boolean	TRUE means supported

Condition	Explanation
turbo_dec_sup	The IE is mandatory present if the IE "Support of
	turbo decoding" = True. Otherwise this field is not
	needed in the message.
turbo_enc_sup	The IE is mandatory present if the IE "Support of
	turbo encoding" = True. Otherwise this field is not
	needed in the message.
tdd_req_sup	The IE is mandatory present if the IE "Multi-mode
	capability" has the value "TDD" or "FDD/TDD" and a
	TDD capability update has been requested in a
	previous message. Otherwise this field is not needed
	in the message.

10.3.3.41 UE multi-mode/multi-RAT capability

Information Element/Group name	Need	Multi	Type and Referenc e	Semantics description	Version
Multi-RAT capability			•		
Support of GSM	MP		Boolean		
Support of multi-carrier	MP		Boolean		
Multi-mode capability	MP		Enumerat ed (TDD, FDD, FDD/TDD		
Support of UTRAN to GERAN NACC	CV- not_iRA T_HoInf o		Boolean		REL-5

Condition	Explanation
not_iRAT_HoInfo	The IE is not needed in the INTER RAT HANDOVER
	INFO message. Otherwise, it is mandatory present.

10.3.3.42 UE radio access capability

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Access stratum release indicator	MP		Enumerated(R99)	Indicates the release of the UE according to [35]. The IE also indicates the release of the RRC transfer syntax supported by the UE	
	CV- not_rrc_co nnectionSe		Enumerated(REL-4,	14 spare values are needed.	REL-4
	tupComple te		REL-5)		REL-5
DL capability with simultaneous HS-DSCH configuration	CV- not_iRAT_ HoInfo		Enumerated(32kbps, 64kbps, 128kbps, 384kbps)		REL-5
PDCP capability	MP		PDCP capability 10.3.3.24		
RLC capability	MP		RLC capability 10.3.3.34		
Transport channel capability	MP		Transport channel capability 10.3.3.40		
RF capability FDD	OP		RF capability FDD 10.3.3.33		
RF capability TDD	OP		RF capability TDD 10.3.3.33b	One "TDD RF capability" entity shall be included for every Chip rate capability supported.	

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			reference	description	
		1 to 2		Note 1	REL-4
RF capability TDD 1.28 Mcps	CV- iRAT_HoIn fo		RF capability TDD 1.28 Mcps 10.3.3.33c	Note 1	REL-4
Physical channel capability	MP		Physical channel capability 10.3.3.25		
UE multi-mode/multi-RAT capability	MP		UE multi- mode/multi- RAT capability 10.3.3.41	The TDD Modes supported by the UE are indicated by the RF Capability TDD IE	
Security capability	MP		Security capability 10.3.3.37		
UE positioning capability	MP		UE positioning capability 10.3.3.45		
Measurement capability	CH- fdd_req_su p		Measuremen t capability 10.3.3.21		

Note 1: The second entity of the "RF capability TDD" is not needed in the INTER RAT HANDOVER INFO message: if both TDD 3.84 Mcps and TDD 1.28 Mcps are supported, the "RF capability TDD 1.28 Mcps" entity shall be used for TDD 1.28 Mcps; the "UE power class" in the "RF capability TDD" entity shall apply for both chip rates.

Condition	Explanation
fdd_req_sup	The IE is mandatory present if the IE "Multi-mode capability" has the value "FDD" or "FDD/TDD" and a FDD capability update has been requested in a previous message. Otherwise this field is not needed in the message.
not_rrc_connectionSetupComplete	The IE is not needed in the RRC CONNECTION SETUP COMPLETE message. Otherwise the IE is mandatory present.
not_iRAT_HoInfo	The IE is not needed in the INTER RAT HANDOVER INFO message. Otherwise, it is optional.
iRAT_HoInfo	The IE is optional in the INTER RAT HANDOVER INFO message. Otherwise, the IE is not needed.

10.3.3.420 UE radio access capability compressed

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Access stratum release indicator	MP		Enumerated(R99, REL-4, REL-5)	14 spare values are needed	REL-5
Total AM RLC buffer size exceeds 10 kByte	MP		BOOLEAN		REL-5
RF capability compressed	MP		RF capability compressed 10.3.3.32a		REL-5

10.3.3.42a UE radio access capability extension

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Frequency band specific capability list	MP	1 to <maxfre qbandsF DD></maxfre 	reference		
>Frequency band	MP		Enumerat ed(Band I, Band II,	Band numbering is defined in [21] Five spare values are needed	
			Band III)		REL-5
>RF capability FDD extension	MD		RF capability FDD extension 10.3.3.33 a	the default values are the same values as in the immediately preceding IE "RF capability FDD extension"; the first occurrence is MP	
>Measurement capability extension	MP		Measure ment capability extension 10.3.3.21 a		

10.3.3.42b UE security information

Upon receiving a UE information request from another system, the UE shall indicate the requested security information. The UE security information includes the following RRC information.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
UE information elements				
START-CS	MP		START 10.3.3.38	START values to be used in this CN domain.

10.3.3.43 UE Timers and Constants in connected mode

This information element specifies timer- and constants values used by the UE in connected mode.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
T301	MD		Integer(10 0, 200 2000 by step of 200, 3000, 4000, 6000, 8000)	Value in milliseconds. Default value is 2000. This IE should not be used by the UE in this release of the protocol. One spare value is needed.	
N301	MD		Integer(0 7)	Default value is 2. This IE should not be used by the UE in this release of the protocol.	
T302	MD		Integer(10 0, 200 2000 by step of 200, 3000, 4000,	Value in milliseconds. Default value is 4000. One spare value is needed.	

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
			6000, 8000)		
N302	MD		Integer(0	Default value is 3.	
T304	MD		Integer(10 0, 200, 400, 1000, 2000)	Value in milliseconds. Default value is 2000. Three spare values are needed.	
N304	MD		Integer(0	Default value is 2	
T305	MD		Integer(5, 10, 30, 60, 120, 360, 720, infinity)	Value in minutes. Default value is 30. Infinity means no update	
T307	MD		Integer(5, 10, 15, 20, 30, 40, 50)	Value in seconds. Default value is 30. One spare value is needed.	
T308	MD		Integer(40 , 80, 160, 320)	Value in milliseconds. Default value is 160.	
T309	MD		Integer(18)	Value in seconds. Default value is 5.	
T310	MD		Integer(40 320 by step of 40)	Value in milliseconds. Default value is 160.	
N310	MD		Integer(0	Default value is 4.	
T311	MD		Integer(25 0 2000 by step of 250)	Value in milliseconds. Default value is 2000.	
T312	MD		Integer (015)	Value in seconds. Default value is 1. The value 0 is not used in this version of the specification.	
N312	MD		Integer (1, 2, 4, 10, 20, 50, 100, 200, 400, 600, 800, 1000)	Default value is 1.	
T313	MD		Integer (015)	Value in seconds. Default value is 3.	
N313	MD		Integer (1, 2, 4, 10, 20, 50, 100, 200)	Default value is 20.	
T314	MD		Integer(0, 2, 4, 6, 8, 12, 16, 20)	Value in seconds. Default value is 12.	
T315	MD		Integer (0,10, 30, 60, 180, 600, 1200, 1800)	Value in seconds. Default value is 180.	
N315	MD		Integer (1, 2, 4, 10, 20, 50,	Default value is 1.	

Information	Need	Multi	Type and	Semantics description	Version
Element/Group name			reference		
			100, 200,		
			400, 600,		
			800,		
			1000)		
T316	MD		Integer(0,	Value in seconds.	
			10, 20,	Default value is 30.	
			30, 40,	One spare value is	
			50,	needed.	
			infinity)		
T317	MD				
				Default value is infinity.	
			Enumerat	All the values are	REL-5
			ed	changed to "infinity" in	
			(infinity,	the Rel-5.	
			infinity,		
			infinity)		

10.3.3.44 UE Timers and Constants in idle mode

This information element specifies timer- and constant values used by the UE in idle mode.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
T300	MP		Integer(100, 200 2000 by step of 200, 3000, 4000, 6000, 8000)	Value in milliseconds. Default value is 1000. Use of Default is described in 10.2.48.8.4 and in 10.2.48.8.16.
N300	MP		Integer(07)	Default value is 3. Use of Default is described in 10.2.48.8.4 and in 10.2.48.8.16.
T312	MP		Integer(0 15)	Value in seconds. Default value is 1. Use of Default is described in 10.2.48.8.4 and in 10.2.48.8.16. The value 0 is not used in this version of the specification.
N312	MP		Integer (1, 2, 4, 10, 20, 50, 100, 200, 400, 600, 800, 1000)	Default value is 1. Use of Default is described in 10.2.48.8.4 and in 10.2.48.8.16.

10.3.3.45 UE positioning capability

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Standalone location method(s) supported	MP		Boolean	Defines if a UE can measure its location by some means unrelated to UTRAN TRUE means supported
UE based OTDOA supported	MP		Boolean	TRUE means supported
Network Assisted GPS support	MP		Enumerated ('Network based', 'UE based', 'Both', 'None')	Defines if the UE supports network based or UE based GPS methods.
Support for GPS timing of cell frames measurement	MP		Boolean	Defines if a UE has the capability to perform the UE GPS timing of cell frames measurement [7]. TRUE means capable
Support for IPDL	MP		Boolean	Defines if a UE has the capability to use IPDL to enhance its 'SFN-SFN observed time difference –type 2' measurement. TRUE means supported
Support for Rx-Tx time difference type2 measurement	MP		Boolean	TRUE means supported
Support for UP assisted GPS measurement validity in CELL_PCH and URA_PCH states	OP		Enumerated (true)	Absence of this element means not supported and presence means supported. This IE shall be set to TRUE in this version of the protocol.
Support for SFN-SFN observed time difference type 2 measurement	OP		Enumerated (true)	Absence of this element means not supported and presence means supported.

10.3.3.46 URA update cause

Indicates the cause for s URA update.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
URA update cause	MP		Enumerated(change of URA, periodic URA update)	One spare value is needed.

10.3.3.47 U-RNTI

The U-RNTI (UTRAN Radio Network Temporary Identity) is allocated to a UE having a RRC connection and identifies the UE within UTRAN.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
SRNC identity	MP		bit string(12)	The SRNC identity bits are numbered b20 to b31, where b20 is the least significant bit.
S-RNTI	MP		bit string(20)	The S-RNTI bits are numbered b0 to b19, where b0 is the least significant bit.

10.3.3.47a U-RNTI group

The U-RNTI group is used to identify a group of UEs having an RRC connection.

Information Element/Group	Need	Multi	Type and reference	Semantics	Version
name	145		reference	description	55. 5
CHOICE group discrimimator	MP				REL-5
>AII				(no data)	REL-5
>U-RNTI mask					REL-5
>>U-RNTI	MP		U-RNTI 10.3.3.47	The bits that are less significant than the bit position indicated by the U-RNTI bit mask index shall be ignored.	REL-5
>>U-RNTI bit mask index	MP		Enumerated(b1, b2,b31)	Values b1 to b19 indicate bit positions in the S-RNTI. Values b20 to b31 indicate bit positions in the SRNC identity.	REL-5

10.3.3.48 U-RNTI Short

The U-RNTI (UTRAN Radio Network Temporary Identity) is allocated to a UE having a RRC connection and identifies the UE within UTRAN.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
SRNC identity	MP		bit string(12)	The SRNC identity bits are numbered b20 to b31, where b20 is the least significant bit.
S-RNTI 2	MP		bit string(10)	The S-RNTI 2 bits are numbered b0 to b9, where b0 is the least significant bit.

10.3.3.49 UTRAN DRX cycle length coefficient

A coefficient in the formula to count the paging occasions to be used by a specific UE (specified in [4]).

Information Element/Group name	Need	Multi	Type and reference	Semantics description
DRX cycle length coefficient	MP		Integer(39)	Refers to 'k' in the formula as specified in [4], Discontinuous reception

10.3.3.50 Wait time

Wait time defines the time period the UE has to wait before repeating the rejected procedure.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Wait time	MP		Integer(0 15)	Wait time in seconds The value 0 indicates that
				repetition is not allowed.

10.3.3.51 UE Specific Behaviour Information 1 idle

This IE indicates the UE conformance typically for RRC connection establishment from idle mode.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
UE Specific Behaviour Information 1 idle	MP		bit string(4)	

10.3.3.52 UE Specific Behaviour Information 1 interRAT

This IE indicates the UE conformance typically for RRC connection establishment from another RAT.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
UE Specific Behaviour Information 1 interRAT	MP		bit string(8)	

10.3.4 Radio Bearer Information elements

10.3.4.0 Default configuration identity

This information element identifies a default radio parameter configuration.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Default configuration identity	MP		Integer (010	The corresponding default configurations are specified in 13.7	
			11, 12		REL-4
			13)		REL-5

10.3.4.1 Downlink RLC STATUS info

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Timer_Status_Prohibit	OP		Integer(105 50 by step of 10, 5501000 by step of 50)	Minimum time in ms between STATUS reports
Missing PDU Indicator	MP		Boolean	Value true indicates that UE should send a STATUS report for each missing PDU that is detected
Timer_STATUS_periodic	OP		Integer(100, 200, 300, 400, 500, 750, 1000, 2000)	Time in milliseconds

10.3.4.1a PDCP context relocation info

This information element indicates that the header compression context relocation is to be performed during SRNS relocation for the given radio bearer.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
RB identity	MP		RB identity 10.3.4.16		REL-5
Downlink RFC 3095 context relocation indication	MP		Boolean	TRUE means RFC 3095 context relocation is performed in downlink	REL-5
Uplink RFC 3095 context relocation indication	MP		Boolean	TRUE means RFC 3095 context relocation is performed in uplink	REL-5

10.3.4.2 PDCP info

The purpose of the PDCP info IE is to indicate which algorithms shall be established and to configure the parameters of each of the algorithms.

Information Element/Group	Need	Multi	Type and	Semantics	Version
name	Neca	Widiti	reference	description	Version
Support for lossless SRNS	CV-		Boolean	TRUE means	
relocation	LosslessCr			support	
	iteria				
Max PDCP SN window size	CV-		Enumerated(Maximum PDCP	
	Lossless		sn255,	sequence number	
			sn65535)	window size. The handling of	
				sequence number	
				when the Max	
				PDCP SN window	
				size is 255 is	
				specified in [23].	
PDCP PDU header	MD		Enumerated	Whether a PDCP	
			(present,	PDU header is	
			absent)	existent or not.	
				Default value is "present"	
Header compression information	OP	1 to		present	
Treader compression information		<maxpdc< td=""><td></td><td></td><td></td></maxpdc<>			
		PAlgoType			
		>			
>CHOICE algorithm type	MP				
>>RFC 2507				Header .	
				compression according to IETF	
				standard RFC	
				2507	
>>>F_MAX_PERIOD	MD		Integer	Largest number of	
			(165535)	compressed non-	
				TCP headers that	
				may be sent	
				without sending a	
				full header. Default value is	
				256.	
>>>F_MAX_TIME	MD		Integer	Compressed	
· · · · · <u>-</u> · · · · · · · · · · · · · · · · · · ·			(1255)	headers may not	
			, ,	be sent more than	
				F_MAX_TIME	
				seconds after	
				sending last full	
				header. Default value is 5.	
>>>MAX_HEADER	MD		Integer	The largest	
WAY_HEADEN	טואו ן	l	micycl	The largest	

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
			(6065535)	header size in octets that may be compressed. Default value is 168.	
>>>TCP_SPACE	MD		Integer (3255)	Maximum CID value for TCP connections. Default value is 15.	
>>>NON_TCP_SPACE	MD		Integer (365535)	Maximum CID value for non-TCP connections. Default value is 15.	
>>>EXPECT_REORDERING	MD		Enumerated (reordering not expected, reordering expected)	Whether the algorithm shall reorder PDCP SDUs or not. Default value is "reordering not expected".	
>>RFC 3095				Header compression according to IETF standard RFC 3095	REL-4
>>>Profiles	MP	1 to <maxroh C- Profiles></maxroh 		Profiles supported by both compressor and decompressor in both UE and UTRAN. Profile 0 shall always be supported.	REL-4
>>>>Profile instance	MP		Integer(1 3)	1 = 0x0001, 2 = 0x0002, 3 = 0x0003 (see [52])	REL-4
>>>Uplink	OP			Indicates the necessary information elements for Uplink.	REL-4
>>>>CID inclusion info	MP		Enumerated (PDCP header, RFC3095 packet format)	Configures which method shall be used to carry RFC3095 CID values.	REL-4
>>>>Max_CID	MD		Integer (1 16383)	Highest context ID number to be used by the UE compressor. Default value is 15.	REL-4
>>>>Packet_Sizes_Allowed	OP	1 to <maxroh C- PacketSize s></maxroh 		List of packet sizes that are allowed to be produced by the UE compressor.	REL-4
>>>>Packet size	MP		Integer (2 1500)	Packet size as defined in RFC 3095.	REL-4

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
>>>Downlink	OP			Indicates the necessary information elements for Downlink.	REL-4
>>>>CID inclusion info	MP		Enumerated (PDCP header, RFC3095 packet format)	Configures which method shall be used to carry RFC3095 CID values.	REL-4
>>>>Max_CID	MD		Integer (1 16383)	Highest context ID number to be used by the UE decompressor. Default value is 15.	REL-4
>>>>Reverse_Decompression_ Depth	MD		Integer (065535)	Determines whether reverse decompression should be used or not and the maximum number of packets that can be reverse decompressed by the UE decompressor. Default value is 0 (reverse decompression shall not be used).	REL-4

Condition	Explanation
LosslessCriteria	This IE is mandatory present if the IE "RLC mode" is "Acknowledged", the IE "In-sequence delivery " is "True" and the IE "SDU Discard Mode" is "No discard" and not needed otherwise.
Lossless	This IE is mandatory present if the IE "Support for lossless SRNS relocation" Is TRUE, otherwise it is not needed.

10.3.4.3 PDCP SN info

Information Element/Group	Need	Multi	Type and	Semantics description
name			Reference	
Receive PDCP sequence number	MP		Integer(065 535)	The PDCP sequence number, which the sender of the message is expecting next to be received.

10.3.4.4 Polling info

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Timer_poll_prohibit	OP		Integer(105 50 by step of 10, 6001000 by step of 50)	Minimum time between polls in ms
Timer_poll	OP		Integer(105 50 by step of 10, 6001000 by step of 50)	Time in ms.
Poll_PDU	OP		Integer(1,2,4 ,8,16,32,64,1 28)	Number of PDUs, interval between pollings
Poll_SDU	OP		Integer(1,4,1 6,64)	Number of SDUs, interval between pollings
Last transmission PDU poll	MP		Boolean	TRUE indicates that poll is made at last PDU in transmission buffer
Last retransmission PDU poll	MP		Boolean	TRUE indicates that poll is made at last PDU in retransmission buffer
Poll_Window	OP		Integer(50,6 0,70,80,85,9 0,95,99)	Percentage of transmission window, threshold for polling
Timer_poll_periodic	OP		Integer(100, 200, 300, 400, 500, 750, 1000, 2000)	Time in milliseconds Timer for periodic polling.

10.3.4.5 Predefined configuration identity

This information element identifies a pre- defined radio parameter configuration.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Predefined radio configuration	MP		Integer	
identity			(015)	

10.3.4.5a Predefined configuration status information

Another system may provide the UE with one or more predefined UTRAN configurations, comprising of radio bearer, transport channel and physical channel parameters. If requested, the UE shall indicate the configurations it has stored. The predefined configuration status information should include the following RRC information.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
RB information elements				
Predefined configurations		maxPredef ConfigCou nt		The list is in order of preconfiguration identity
>Predefined configuration value tag	OP		Predefined configuration value tag 10.3.4.6	The UE shall include the value tag if it has stored the concerned configuration

Multi Bound	Explanation
MaxPredefConfigCount	Maximum number of predefined configurations

10.3.4.5b Predefined configuration status information compressed

Another system may provide the UE with one or more predefined UTRAN configurations, comprising of radio bearer, transport channel and physical channel parameters. If requested, the UE shall indicate the configurations it has stored. The compressed predefined configuration status information should include the following RRC information.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Sets with different value tags	MP		1010101100		REL-5
>Pre-defined configuration set with different value tags	MP	12			REL-5
>>Start position	MD		INTEGER (010)	Default value is 0, corresponding with the first predefined configuration. The pre-defined configuration where the consecutive sequence of pre-defined configurations begins.	REL-5
>>Pre-defined configuration value tag list	MP	6 <max PredefC onfig></max 	Pre-defined configuration value tag 10.3.4.6	Value Tags for each pre-defined configuration starting from the lowest.	REL-5
Other Entries	OP				REL-5
>Pre-defined configuration list with variable size	MP	1 <max PredefC onfig></max 		List of other pre-defined configurations not included within the Sets with different value tags, in consecutive order starting with the lowest. If there are stored pre-defined configurations positioned after a pre-defined configuration that is not stored, the UE shall indicate the not-stored pre-defined configuration by explicitly indicating it to be absent. If there are no stored pre-defined configurations positioned after a pre-defined configurations prositioned after a pre-defined configuration that is not stored, then the UE may totally omit these pre-defined configurations from the IE, i.e. reduce the size of the list to correspond to the last position that contained a stored pre-defined configuration.	REL-5
>>Predefined configuration value tag	OP		Predefined configuration value tag 10.3.4.6	The UE shall include the value tag if it has stored the concerned configuration	REL-5

10.3.4.6 Predefined configuration value tag

This information element is used to identify different versions of a radio bearer configuration as may be used within one PLMN e.g. to support different UTRAN implementations.

Information Element/Group	Need	Multi	Type and	Semantics description
name			Reference	
Predefined configuration value	MP		Integer(015	
tag)	

10.3.4.7 Predefined RB configuration

This information element concerns a pre- defined configuration of radio bearer parameters

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
UE information elements				
Re-establishment timer	MP		Re- establishme nt timer 10.3.3.30	Only one RAB supported
Signalling radio bearer information				
Signalling RB information to setup List	MP	1 to <maxsrbs etup></maxsrbs 		For each signalling radio bearer
>Signalling RB information to setup	MP		Signalling RB information to setup 10.3.4.24	
RB information				Only one RAB supported
RB information to setup list	MP	1 to <maxrbpe rRAB></maxrbpe 		
>RB information to setup	MP		RB information to setup 10.3.4.20	

10.3.4.8 RAB info

This IE contains information used to uniquely identify a radio access bearer.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
RAB identity	MP		RAB identity 10.3.1.14	
CN domain identity	MP		CN domain identity 10.3.1.1	
NAS Synchronization Indicator	OP		NAS Synchronizat ion indicator 10.3.4.12	
Re-establishment timer	MP		Re- establishme nt timer 10.3.3.30	

10.3.4.9 RAB info Post

This IE contains information used to uniquely identify a radio access bearer.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
RAB identity	MP		RAB identity 10.3.1.14	
CN domain identity	MP		CN domain identity 10.3.1.1	
NAS Synchronization Indicator	OP		NAS Synchronizat ion indicator 10.3.4.12	

10.3.4.10 RAB information for setup

Information Element/Group name	Need	Multi	Type and reference	Semantics description
RAB info	MP		RAB info 10.3.4.8	
RB information to setup list	MP	1 to <maxrbpe rRAB></maxrbpe 		
>RB information to setup	MP		RB information to setup 10.3.4.20	

10.3.4.11 RAB information to reconfigure

Information Element/Group name	Need	Multi	Type and reference	Semantics description
RAB identity	MP		RAB Identity 10.3.1.14	
CN domain identity	MP		CN domain identity 10.3.1.1	
NAS synchronization indicator	MP		NAS Synchronizat ion info 10.3.4.12	

10.3.4.12 NAS Synchronization indicator

A container for non-access stratum information to be transferred transparently through UTRAN.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
NAS Synchronization indicator	MP		Bit string(4)	The first/leftmost bit of the bit string contains the most significant bit of the NAS Synchronization indicator.

475

10.3.4.13 RB activation time info

This IE contains the time, in terms of RLC sequence numbers, when a certain configuration shall be activated, for a number of radio bearers.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Radio bearer activation time	MP	1 to		
		<maxrb></maxrb>		
>RB identity	MP		RB identity	
			10.3.4.16	
>RLC sequence number	MP		Integer (0	RLC SN [16] .
			4095)	Used for radio bearers
				mapped on RLC AM and UM

10.3.4.14 RB COUNT-C MSB information

The MSB of the COUNT-C values of the radio bearer.

Information Element/Group name	Needed	Multi	Type and reference	Semantics description
RB identity	MP		RB identity 10.3.4.16	
COUNT-C-MSB-uplink	MP		Integer (0 2^25-1)	25 MSBs from COUNT-C associated to this RB
COUNT-C-MSB-downlink	MP		Integer (0 2^25-1)	25 MSBs from COUNT-C associated to this RB

10.3.4.15 RB COUNT-C information

The COUNT-C values of the radio bearer.

Information Element/Group name	Needed	Multi	Type and reference	Semantics description
RB identity	MP		RB identity 10.3.4.16	
COUNT-C-uplink	MP		Integer (0 2^32-1)	
COUNT-C-downlink	MP		Integer (0 2^32-1)	

10.3.4.16 RB identity

An identification number for the radio bearer affected by a certain message.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
RB identity	MP		Integer(132	Values 1-4 shall only be used for signalling radio bearers. The IE value minus one shall be used as BEARER in the ciphering algorithm.

10.3.4.17 RB information to be affected

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
RB identity	MP		RB identity	
			10.3.4.16	
RB mapping info	MP		RB mapping	
			info	
			10.3.4.21	

10.3.4.18 RB information to reconfigure

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
RB identity	MP		RB identity	
			10.3.4.16	
PDCP info	OP		PDCP info	
			10.3.4.2	
PDCP SN info	OP		PDCP SN	PDCP sequence number info
			info	from the network. Present only
			10.3.4.3	in case of lossless SRNS
				relocation.
RLC info	OP		RLC info	
			10.3.4.23	
RB mapping info	OP		RB mapping	
			info	
			10.3.4.21	
RB stop/continue	OP		Enumerated(
			stop,	
			continue)	

10.3.4.19 RB information to release

Information Element/Group name	Need	Multi	Type and reference	Semantics description
RB identity	MP		RB identity	
			10.3.4.16	

10.3.4.20 RB information to setup

Information Element/Group name	Need	Multi	Type and reference	Semantics description
RB identity	MP		RB identity 10.3.4.16	
PDCP info	OP		PDCP info 10.3.4.2	
CHOICE RLC info type	MP			
>RLC info			RLC info 10.3.4.23	
>Same as RB			RB identity 10.3.4.16	Identity of RB with exactly the same RLC info IE values
RB mapping info	MP		RB mapping info 10.3.4.21	

NOTE: This information element is included within IE "Predefined RB configuration".

10.3.4.21 RB mapping info

A multiplexing option for each possible transport channel or MAC-d flow this RB can be multiplexed on.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Information for each multiplexing option	MP	1 to <maxrbm uxOptions></maxrbm 			
>RLC logical channel mapping indicator	CV-UL- RLCLogica IChannels		Boolean	TRUE indicates that the first logical channel shall be used for data PDUs and the second logical channel shall be used for control PDUs. FALSE indicates that control and data PDUs can be sent on either of the two logical channels. This parameter is not used in this release and shall be set to TRUE.	
>Number of uplink RLC logical channels	CV-UL- RLC info	1 to MaxLoCHp erRLC		1 or 2 logical channels per RLC entity or radio bearer RLC [16]	
>>Uplink transport channel type	MP		Enumerated(DCH,RACH, CPCH,USC H)	CPCH is FDD only USCH is TDD only	
>>ULTransport channel identity	CV-UL- DCH/USC H		Transport channel identity 10.3.5.18	This is the ID of a DCH or USCH (TDD only) that this RB could be mapped onto.	
>>Logical channel identity	ОР		Integer(115	This parameter is used to distinguish logical channels multiplexed by MAC on a transport channel.	
>>CHOICE RLC size list	MP			The RLC sizes that are allowed for this logical channel.	
>>>All			Null	All RLC sizes listed in the Transport Format Set. 10.3.5.23	
>>>Configured			Null	The RLC sizes configured for this logical channel in the <i>Transport Format Set</i> . 10.3.5.23 if present in this message or in the previously stored configuration otherwise	

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
>>>Explicit List		1 to <maxtf></maxtf>		Lists the RLC sizes that are valid for the logical channel.	
>>>RLC size index	MP		Integer(1m axTF)	The integer number is a reference to the <i>RLC size</i> which arrived at that position in the <i>Transport Format Set</i> 10.3.5.23	
>>MAC logical channel priority	MP		Integer(18)	This is priority between a user's different RBs (or logical channels). [15]	
>Downlink RLC logical channel info	CV-DL- RLC info				
>>Number of downlink RLC logical channels	MD	1 to MaxLoCHp erRLC		1 or 2 logical channels per RLC entity or radio bearer RLC [16] Default value is that parameter values for DL are exactly the same as for corresponding UL logical channel. In case two multiplexing options are specified for the UL, the first options shall be used as default for the DL. As regards to the IE "Channel type", rule is specified in 8.6.4.8.	
>>>Downlink transport channel type	MP		Enumerated(DCH,FACH, DSCH,DCH+ DSCH , HS-DSCH, DCH + HS-	Note 1	REL-5
			DSCH)		
>>>DL DCH Transport channel identity	CV-DL- DCH		Transport channel identity 10.3.5.18		
>>>DL DSCH Transport channel identity	CV-DL- DSCH		Transport channel identity 10.3.5.18		
>>>DL HS-DSCH MAC-d flow identity	CV-DL-HS- DSCH		MAC-d flow identity 10.3.5.7c	40:	REL-5
>>>Logical channel identity	OP		Integer(115	16 is reserved	

Note 1: The IE "Downlink transport channel type" values "HS-DSCH" and "DCH + HS-DSCH" are not used in the RRC CONNECTION SETUP message.

Condition	Explanation
UL-RLC info	If "CHOICE Uplink RLC mode" in the IE "RLC info"
	that applies for that RB (i.e. either the one stored or
	received in the same message for the RB for which
	the "RB mapping info" was received, or the one stored
	or received in the same message for the RB pointed
	at in the IE "Same as RB" in the IE "RB information to
	setup" stored or received in the same message) is
	present this IE is mandatory present. Otherwise the IE
DI DIO inte	is not needed.
DL-RLC info	If "CHOICE Downlink RLC mode" in the IE "RLC info"
	that applies for that RB (i.e. either the one stored or received in the same message for the RB for which
	the "RB mapping info" was received, or the one stored
	or received in the same message for the RB pointed
	at in the IE "Same as RB" in the IE "RB information to
	setup" stored or received in the same message) is
	present this IE is mandatory present. Otherwise the IE
	is not needed.
UL-RLCLogicalChannels	If "Number of uplink RLC logical channels" in IE "RB
	mapping info" is 2, then this IE is mandatory present.
	Otherwise this IE is not needed.
UL-DCH/USCH	If IE "Uplink transport channel type" is equal to "DCH"
	or "USCH" (TDD only) this IE is mandatory present.
	Otherwise the IE is not needed.
DL-DCH	If IE "Downlink transport channel type" is equal to
	"DCH", "DCH+DSCH" or 'DCH + HS-DSCH' this IE is
DI DOCI	mandatory present. Otherwise the IE is not needed.
DL-DSCH	If IE "Downlink transport channel type" is equal to
	"DSCH" or "DCH+DSCH" this IE is mandatory
DL-HS-DSCH	present. Otherwise the IE is not needed.
<i>DL-</i> П3- <i>D</i> 3CП	If IE "Downlink transport channel type" is equal to "HSDSCH" or 'DCH + HS-DSCH' this IE is mandatory
	present. Otherwise the IE is not needed.
	present. Otherwise the IE is not needed.

10.3.4.22 RB with PDCP information

Information Element/Group name	Need	Multi	Type and reference	Semantics description
RB identity	MP		RB identity 10.3.4.16	
PDCP SN info	MP		PDCP SN info 10.3.4.3	PDCP sequence number info from the sender of the message for lossless SRNS relocation.

10.3.4.23 RLC info

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
CHOICE Uplink RLC mode	OP			Indicates if Acknowledged, Unacknowledged or Transparent mode RLC shall be used.	
>AM RLC					
>>Transmission RLC discard	MP		Transmissio n RLC discard 10.3.4.25		
>>Transmission window size	MP		Integer(1,8,1 6,32,64,128, 256,512,768, 1024,1536,2 047,2560,30	Maximum number of RLC PUs sent without getting them acknowledged. This parameter is needed if acknowledged mode is used. UE shall also	

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
			72,3584,409	assume that the UTRAN	
			5)	receiver window is equal to this value.	
>>Timer_RST	MP		Integer(50, 100, 150, 200, 250, 300, 350, 400, 450, 500, 550, 600, 700,	Elapsed time in milliseconds. It is used to trigger the retransmission of RESET PDU.	
			800, 900, 1000)		
>>Max_RST	MP		Integer(1, 4, 6, 8, 12 16, 24, 32)	Defined in [16]	
>>Polling info	OP		Polling info 10.3.4.4		
>UM RLC					
>>Transmission RLC discard	OP		Transmissio n RLC discard 10.3.4.25		
>TM RLC					
>>Transmission RLC discard	OP		Transmissio n RLC discard 10.3.4.25		
>>Segmentation indication	MP		Boolean	TRUE indicates that segmentation is performed.	
CHOICE Downlink RLC mode	OP			Indicates if Acknowledged, Unacknowledged or Transparent mode RLC shall be used	
>AM RLC					
>>DL RLC PDU size	MP		Integer(049 92)	Unit is bits	REL-5
>>In-sequence delivery	MP		Boolean	TRUE indicates that RLC shall preserve the order of higher layer PDUs when these are delivered. FALSE indicates that receiving RLC entity could allow SDUs to be delivered to the higher layer in different order than submitted to RLC sublayer at the transmitting side.	
>>Receiving window size	MP		Integer(1,8,1 6,32,64,128, 256,512,768, 1024,1536,2 047,2560,30 72,3584,409 5)	Maximum number of RLC PUs allowed to be received. This parameter is needed if acknowledged mode is used. UE shall also assume that the UTRAN transmitter window is equal to this value	
>>Downlink RLC status Info	MP		Downlink RLC status info		
>UM RLC			10.3.4.1	(No data)	
>>DL UM RLC LI size	MP		Integer(7, 15)	Size in bits to use for the downlink RLC UM LI.	REL-5
>TM RLC			,		
>>Segmentation indication	MP		Boolean	TRUE indicates that segmentation is performed.	
One sided RLC re-establishment	MP		Boolean	TRUE indicates that only one side of the AM RLC entity is	REL-5

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
				re-established.	

NOTE: This information element is included within IE "Predefined RB configuration".

10.3.4.24 Signalling RB information to setup

Information Element/Group name	Need	Multi	Type and reference	Semantics description
RB identity	MD		RB identity 10.3.4.16	Default value is specified in subclause 8.6.4.1
CHOICE RLC info type	MP			
>RLC info			RLC info 10.3.4.23	
>Same as RB			RB identity 10.3.4.16	Identity of RB with exactly the same RLC info IE values
RB mapping info	MP		RB mapping info 10.3.4.21	

NOTE: This information element is included within IE "Predefined RB configuration".

10.3.4.25 Transmission RLC Discard

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE SDU Discard Mode	MP			Different modes for discharge the RLC buffer on the transmitter side; "Timer based with explicit signalling", "Timer based without explicit signalling", "Discard after Max_DAT retransmissions" or "No_discard". For unacknowledged mode and transparent mode, only Timer based without explicit signalling is applicable. If "No_discard" is used, reset procedure shall be done after Max_DAT retransmissions
>Timer based explicit				
>>Timer_MRW	MP		Integer(50,6 0, 70, 80, 90, 100, 120, 140, 160, 180, 200, 300, 400, 500, 700, 900)	Elapsed time in milliseconds. It is used to trigger the retransmission of a STATUS PDU containing an MRW SUFI field
>>Timer_discard	MP		Integer(100, 250, 500, 750, 1000, 1250, 1500, 1750, 2000, 2500, 3000, 3500, 4000, 4500, 5000, 7500)	Elapsed time in milliseconds before a SDU is discarded.
>>MaxMRW	MP		Integer(1, 4, 6, 8, 12 16, 24, 32)	Defined in [16]

Information Element/Group name	Need	Multi	Type and reference	Semantics description
>Timer based no explicit				
>>Timer_discard	MP		Integer(10,2 0,30,40,50,6 0,70,80,90,1 00)	Elapsed time in milliseconds before a SDU is discarded.
>Max DAT retransmissions				
>>Max_DAT	MP		Integer(1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 15, 20, 25, 30, 35, 40)	Defined in [16]
>>Timer_MRW	MP		Integer(50, 60, 70, 80, 90, 100, 120, 140, 160, 180, 200, 300, 400, 500, 700, 900)	Elapsed time in milliseconds. It is used to trigger the retransmission of a STATUS PDU containing an MRW SUFI field
>>MaxMRW	MP		Integer(1, 4, 6, 8, 12 16, 24, 32)	Defined in [16]
>No discard				
>>Max_DAT	MP		Integer(1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 15, 20, 25, 30, 35, 40)	Defined in [16]

CHOICE SDU Discard Mode	Condition under which the given SDU Discard
	Mode is chosen
Timer based explicit	If the modes for discharge of the RLC buffer on the transmitter side is "Timer based with explicit signalling"
Timer based no explicit	If the modes for discharge of the RLC buffer on the transmitter side is "Timer based without explicit signalling" For unacknowledged mode, only Timer based without explicit signalling is applicable.
Max DAT retransmissions	If the modes for discharge of the RLC buffer on the transmitter side is "Discard after Max_DAT retransmissions"
No discard	If the modes for discharge the of RLC buffer on the transmitter side is "Reset procedure shall be done after Max_DAT retransmissions"

10.3.5 Transport CH Information elements

10.3.5.1 Added or Reconfigured DL TrCH information

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			reference	description	
Downlink transport channel type	MP		Enumerated(
			DCH,DSCH		
			,HS-DSCH)	Note 1	REL-5
DL Transport channel identity	MP		Transport		
			channel		
			identity		
			10.3.5.18		
	CV-not				REL-5
	HS-DSCH				
CHOICE DL parameters					

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
>Explicit					
>>TFS	MP		Transport Format Set 10.3.5.23		
>SameAsUL					
>>Uplink transport channel type	MP		Enumerated(DCH,USCH)	USCH is TDD only	
>>UL TrCH identity	MP		Transport channel identity 10.3.5.18	Same TFS applies as specified for indicated UL TrCH	
>HS-DSCH				Note 1	REL-5
>>HARQ Info	OP		HARQ info 10.3.5.7a		REL-5
>>Added or reconfigured MAC-d flow	OP		Added or reconfigured MAC-d flow 10.3.5.1a		REL-5
DCH quality target	OP		Quality target 10.3.5.10		

Note 1: The IE "Downlink transport channel type" value "HS-DSCH" is not used in the RRC CONNECTION SETUP message, nor is the CHOICE *DL parameters* = "HS-DSCH".

Condition	Explanation		
NotHS-DSCH	If the downlink transport channel type is DCH or DSCH then this IE is mandatory otherwise it is not		
	needed.		

10.3.5.1a Added or reconfigured MAC-d flow

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
MAC-hs queue to add or reconfigure list	OP	<1 to maxQueue ID>		•	REL-5
>MAC-hs queue Id	MP		Integer(07)	The MAC-hs queue ID is unique across all MAC-d flows.	REL-5
>MAC-d Flow Identity	MP		MAC-d Flow Identity 10.3.5.7c		REL-5
>T1	MP		Integer(10, 20, 30, 40, 50, 60, 70, 80, 90, 100, 120, 140, 160, 200, 300, 400)	Timer (in milliseconds) when PDUs are released to the upper layers even though there are outstanding PDUs with lower TSN values.	REL-5
>MAC-hs window size	MP		Integer(4, 6, 8, 12, 16, 24, 32)		REL-5
>MAC-d PDU size Info	OP	<1 to max MACdPDU sizes>		Mapping of the different MAC-d PDU sizes configured for the HS-DSCH to the MAC-d PDU size index in the MAC-hs header.	REL-5
>>MAC-d PDU size	MP		Integer (15000)		REL-5
>>MAC-d PDU size index	MP		Integer(07)		REL-5
MAC-hs queue to delete list	OP	<1 to maxQueue ID>			REL-5
>MAC-hs queue Id	MP		Integer(07)	The MAC-hs queue ID is unique across all MAC-d flows.	REL-5

10.3.5.2 Added or Reconfigured UL TrCH information

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Uplink transport channel type	MP		Enumerated(DCH,USCH)	USCH is TDD only
UL Transport channel identity	MP		Transport channel identity 10.3.5.18	
TFS	MP		Transport Format Set 10.3.5.23	

NOTE: This information element is included within IE "Predefined RB configuration".

10.3.5.3 CPCH set ID

NOTE: Only for FDD.

This information element indicates that this transport channel may use any of the Physical CPCH channels defined in the CPCH set info, which contains the same CPCH set ID. The CPCH set ID associates the transport channel with a set of PCPCH channels defined in a CPCH set info IE and a set of CPCH persistency values. The CPCH set info IE(s) and the CPCH persistency values IE(s) each include the CPCH set ID and are part of the SYSTEM INFORMATION message.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CPCH set ID	MP		Integer(1m axCPCHsets	Identifier for CPCH set info and CPCH persistency value
)	messages

10.3.5.4 Deleted DL TrCH information

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Downlink transport channel type	MP		Enumerated(DCH,DSCH		
			,HS-DSCH)		REL-5
DL Transport channel identity	MP		Transport channel identity 10.3.5.18		
	CV-notHS- DSCH				REL-5
DL HS-DSCH MAC-d flow identity	CV-HS- DSCH		MAC-d flow identity 10.3.5.7c		REL-5

Condition	Explanation
NotHS-DSCH	If the downlink transport channel type is DCH or
	DSCH then this IE is mandatory otherwise it is not needed.
HS-DSCH	If the downlink transport channel type is HSDSCH
	then this IE is mandatory otherwise it is not needed.

10.3.5.5 Deleted UL TrCH information

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Uplink transport channel type	MP		Enumerated(USCH is TDD only
			DCH,USCH)	·
UL Transport channel identity	MP		Transport	
			channel	
			identity	
			10.3.5.18	

10.3.5.6 DL Transport channel information common for all transport channels

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
SCCPCH TFCS	OP		Transport Format Combination Set 10.3.5.20	This IE should not be included in this version of the protocol.	
CHOICE mode	MP			Although this IE is not always required, need is MP to align with ASN.1	

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
	OP				REL-4
>FDD					
>>CHOICE DL parameters	OP				
>>>Explicit					
>>>DL DCH TFCS	MP		Transport Format Combination Set 10.3.5.20	Although this IE is not always required, need is MP to align with ASN.1	
	OP				REL-4
>>>SameAsUL				(no data)	
>TDD					
>>Individual DL CCTrCH information	OP	1 to <maxcctr CH></maxcctr 			
>>>DL TFCS Identity	MP		Transport format combination set identity 10.3.5.21	Identifies a special CCTrCH for shared or dedicated channels.	
>>>CHOICE DL parameters	MP				
>>>Independent					
>>>>DL TFCS	MP		Transport format combination set 10.3.5.20		
>>>SameAsUL					
>>>>UL DCH TFCS Identity	MP		Transport format combination set identity 10.3.5.21	Same TFCS applies as specified for the indicated UL DCH TFCS identity except for information applicable for UL only	

NOTE: This information element is included within IE "Predefined TrCh configuration".

10.3.5.7 DRAC Static Information

NOTE: Only for FDD.

Contains static parameters used by the DRAC procedure. Meaning and use is described in subclause 14.8.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Transmission Time Validity	MP		Integer(125	number of frames
			6)	
Time duration before retry	MP		Integer(125	number of frames
-			6)	
DRAC Class Identity	MP		Integer(1	Indicates the class of DRAC
			maxDRACcl	parameters to use in SIB10
			asses)	message

10.3.5.7a HARQ Info

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Number of Processes	MP		Integer (18)		REL-5
CHOICE Memory Partitioning	MP				REL-5
>Implicit				UE shall apply memory partitioning of equal size across all HARQ processes	REL-5
>Explicit					REL-5
>>Memory size	MP	<1 to MaxHProc esses>			REL-5
>>>Process Memory size	MP		Integer(800 16000 by step of 800, 17600 32000 by step of 1600, 36000 80000 by step of 4000, 88000 160000 by step of 8000, 176000 304000 by step of	Maximum number of soft channel bits available in the virtual IR buffer [27]	REL-5

10.3.5.7b Void

10.3.5.7c MAC-d Flow Identity

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
MAC-d flow identity	MP		Integer (07)		REL-5

10.3.5.8 Power Offset Information

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
CHOICE Gain Factors	MP			
>Signalled Gain Factors				
>>CHOICE mode				
>>>FDD				
>>> Gain Factor β_c	MP		Integer	For UL DPCCH or control part
•			(0 15)	of PRACH or PCPCH
>>>TDD				(no data)
>>Gain Factor β_d	MP		Integer	For UL DPDCH or data part of
			(015)	PRACH or PCPCH in FDD
				and all uplink channels in TDD
>>Reference TFC ID	OP		Integer (03)	If this TFC is a reference TFC,
				indicates the reference ID.
>Computed Gain Factors				
>>Reference TFC ID	MP		Integer	Indicates the reference TFC Id
			(0 3)	of the TFC to be used to
				calculate the gain factors for

Information Element/Group name	Need	Multi	Type and reference	Semantics description
				this TFC. In case of using computed gain factors, at least one signalled gain factor is necessary for reference.
CHOICE mode	MP			
>FDD				
>>Power offset P p-m	OP		Integer(- 510)	In dB. Power offset between the last transmitted preamble and the control part of the message (added to the preamble power to receive the power of the message control part) Needed only for PRACH
>TDD				(no data)

CHOICE Gain Factors	Condition under which the way to signal the <i>Gain</i> Factors is chosen
Signalled Gain Factors	The values for gain factors β_c (only in FDD mode) and β_d are signalled directly for a TFC.
Computed Gain Factors	The gain factors β_c (only in FDD mode) and β_d are computed for a TFC, based on the signalled settings for the associated reference TFC.

10.3.5.9 Predefined TrCH configuration

This information element concerns a pre-defined configuration of transport channel parameters.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
UL Transport channel information common for all transport channels	MP		UL Transport channel information common for all transport channels 10.3.5.24	
Added or Reconfigured TrCH information				
Added or Reconfigured UL TrCH information	MP	1 to <maxtrch preconf></maxtrch 		
>Added or Reconfigured UL TrCH information	MP		Added or Reconfigure d UL TrCH information 10.3.5.2	
DL Transport channel information common for all transport channels	MP		DL Transport channel information common for all transport channels 10.3.5.6	
Downlink transport channels				
Added or Reconfigured DL TrCH information	MP	1 to <maxtrch preconf></maxtrch 		
>Added or Reconfigured DL TrCH information	MP		Added or Reconfigure d DL TrCH information 10.3.5.1	

10.3.5.10 Quality Target

Information Element/Group name	Need	Multi	Type and reference	Semantics description
BLER Quality value	MP		Real(-6.3 0 by step of 0.1)	Signalled value is Log10(Transport channel BLER quality target)

10.3.5.11 Semi-static Transport Format Information

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Transmission time interval	MP		Integer(10, 20, 40, 80, dynamic	In ms. The value dynamic is only used in TDD mode.	
			5)	5 is only applicable for the RACH in 1.28 Mcps TDD	REL-4
Type of channel coding	MP		Enumerated(No coding, Convolutiona	The option "No coding" is only valid for TDD.	

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
			I, Turbo)	•	
Coding Rate	CV-Coding		Enumerated(1/2, 1/3)		
Rate matching attribute	MP		Integer(1hi RM)		
CRC size	MP		Integer(0, 8, 12, 16, 24)	in bits	

Condition	Explanation
Coding	This IE is mandatory present if IE "Type of channel
	coding" is "Convolutional" and not needed otherwise.

10.3.5.12 TFCI Field 2 Information

This IE is used for signalling the mapping between TFCI (field 2) values and the corresponding TFC.

Information Element/Group name	Need	Multi	IE type and reference	Semantics description
CHOICE Signalling method	MP			
>TFCI range				
>>TFCI(field 2) range	MP	1 to <maxpds CH- TFClgroup s></maxpds 		
>>>Max TFCI(field2) value	MP		Integer(110 23)	This is the Maximum value in the range of TFCI(field2) values for which the specified CTFC(field2) applies
>>>TFCS Information for DSCH (TFCI range method)	MP		TFCS Information for DSCH (TFCI range method) 10.3.5.14	
>Explicit				
>>TFCS explicit configuration	MP		TFCS explicit configuration 10.3.5.13	

10.3.5.13 TFCS Explicit Configuration

Information Element/Group name	Need	Multi	IE type and reference	Semantics description
CHOICE TFCS representation	MP		reference	
>Complete reconfiguration	IVII			
>>TFCS complete	MP		TFCS	
reconfiguration information	IVII		Reconfigurat	
recorniguration information			ion/Addition	
			information	
			10.3.5.15	
>Addition			101010110	
>>TFCS addition information	MP		TFCS	
			Reconfigurat	
			ion/Addition	
			information	
			10.3.5.15	
>Removal				
>>TFCS removal information	MP		TFCS	
			Removal	
			Information	
			10.3.5.16	
>Replace	MD		TEOO	
>>TFCS removal information	MP		TFCS Removal	
			Information	
			10.3.5.16	
>>TFCS addition information	MP		TFCS	
2211 33 addition information	1411		Reconfigurat	
			ion/Addition	
			information	
			10.3.5.15	

10.3.5.14 TFCS Information for DSCH (TFCI range method)

Information Element/Group	Need	Multi	IE type and	Semantics description
name			reference	
CHOICE CTFC Size	MP			
>2 bit CTFC				
>>2bit CTFC	MP		Integer(03)	
>4 bit CTFC				
>>4bit CTFC	MP		Integer(015	
)	
>6 bit CTFC				
>>6 bit CTFC	MP		Integer(063	
)	
>8 bit CTFC				
>>8 bit CTFC	MP		Integer(025	
			5)	
>12 bit CTFC				
>>12 bit CTFC	MP		Integer(040	
			95)	
>16 bit CTFC				
>>16 bit CTFC	MP		Integer(065	
			535)	
>24 bit CTFC				
>>24 bit CTFC	MP		Integer(016	
			777215)	

10.3.5.15 TFCS Reconfiguration/Addition Information

Information Element/Group name	Need	Multi	IE type and reference	Semantics description
CHOICE CTFC Size	MP			
>2 bit CTFC				
>>CTFC information	MP	1 to <maxtfc></maxtfc>		
>>>2bit CTFC	MP		Integer(03)	
>>>Power offset Information	OP		Power Offset Information 10.3.5.8	Needed only for uplink physical channels.
>4 bit CTFC				
>>CTFC information	MP	1 to <maxtfc></maxtfc>		
>>>4bit CTFC	MP		Integer(015	
>>>Power offset Information	OP		Power Offset Information 10.3.5.8	Needed only for uplink physical channels.
>6 bit CTFC				
>>CTFC information	MP	1 to <maxtfc></maxtfc>		
>>>6 bit CTFC	MP		Integer(063	
>>>Power offset Information	OP		Power Offset Information 10.3.5.8	Needed only for uplink physical channels.
>8 bit CTFC				
>>CTFC information	MP	1 to <maxtfc></maxtfc>		
>>>8 bit CTFC	MP		Integer(025 5)	
>>>Power offset Information	OP		Power Offset Information 10.3.5.8	Needed only for uplink physical channels.
>12 bit CTFC				
>>CTFC information	MP	1 to <maxtfc></maxtfc>		
>>>12 bit CTFC	MP		Integer(040 95)	
>>>Power offset Information	OP		Power Offset Information 10.3.5.8	Needed only for uplink physical channels.
>16 bit CTFC				
>>CTFC information	MP	1 to <maxtfc></maxtfc>		
>>>16 bit CTFC	MP		Integer(065 535)	
>>>Power offset Information	OP		Power Offset Information 10.3.5.8	Needed only for uplink physical channels.
>24 bit CTFC				
>>CTFC information	MP	1 to <maxtfc></maxtfc>		
>>>24 bit CTFC	MP		Integer(016 777215)	
>>>Power offset Information	OP		Power Offset Information 10.3.5.8	Needed only for uplink physical channels.

10.3.5.16 TFCS Removal Information

Information Element/Group	Need	Multi	IE type and	Semantics description
name			reference	
Removal TFCI information	MP	1 to		
		<maxtfc></maxtfc>		
>TFCI	MP		Transport	In TDD 0 is a reserved value
			Format	
			Combination	
			(TFC)	
			10.3.5.19	

10.3.5.17 Void

10.3.5.18 Transport channel identity

This information element is used to distinguish transport channels. Transport channels of different type (RACH, CPCH, USCH, FACH/PCH, DSCH or DCH) have separate series of identities. This also holds for uplink and downlink transport channel identities (i.e. for DCH). Depending on in which context a transport channel identity n that is sent, it will have different meaning

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Transport channel identity	MP		Integer(132	

10.3.5.19 Transport Format Combination (TFC)

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Transport format combination	MP		Integer (0 1023)	

10.3.5.20 Transport Format Combination Set

Indicates the allowed combinations of already defined Transport formats and the mapping between these allowed TFCs and the corresponding TFCI values.

For TDD, different coded composite transport channels have independent transport format combination sets and thus independent TFCI values.

For FDD, Where the UE is assigned access to one or more DSCH transport channels, a TFCI(field2) is used to signal the transport format combination for the DSCH. The following two cases exist:

- Case 1

Using one TFCI-word on the physical layer. A logical split determines the available number of transport format combinations for DCH and DSCH.

- Case 2:

Using split TFCI on the physical layer. Two TFCI-words, TFCI (field1) and TFCI (field2), are used and they are block coded separately.

Information Element/Group name	Need	Multi	IE type and reference	Semantics description
CHOICE TFCI signalling	MP			'Normal': meaning no split in the TFCI field (either 'Logical' or 'Hard') 'Split': meaning there is a split in the TFCI field (either 'Logical' or 'Hard'). This value is only valid for FDD downlink when using DSCH.
>Normal				
>>TFCI Field 1 Information	MP		TFCS explicit Configuratio n 10.3.5.13	
>Split				
>>Split type	OP		Enumerated ('Hard', 'Logical')	'Hard': meaning that TFCI (field 1) and TFCI (field 2) are block coded separately. 'Logical': meaning that on the physical layer TFCI (field 1) and TFCI (field 2) are concatenated, field 1 taking the most significant bits and field 2 taking the least significant bits). The whole is then encoded with a single block code.
>>Length of TFCI(field2)	OP		Integer (110)	This IE indicates the length measured in number of bits of TFCI(field2)
>>TFCI Field 1 Information	OP		TFCS explicit Configuratio n 10.3.5.13	
>>TFCI Field 2 Information	OP		TFCI field 2 information 10.3.5.12	

CHOICE TFCI signalling	Condition under which TFCI signalling type is chosen
Normal	It is chosen when no split in the TFCI field.
Split	It is chosen when split in the TFCI field. This value is only valid for FDD downlink when using DSCH.

10.3.5.21 Transport Format Combination Set Identity

NOTE: Only for TDD.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
TFCS ID	MD		Integer (18)	Indicates the identity of every TFCS within a UE. Default value is 1.
Shared Channel Indicator	MP		Boolean	TRUE indicates the use of shared channels. Default is false.

10.3.5.22 Transport Format Combination Subset

Indicates which Transport format combinations in the already defined Transport format combination set are allowed.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE Subset representation	MP			
>Minimum allowed Transport			Transport	
format combination index			format	
			combination	
			10.3.5.19	
>Allowed transport format		1 to		
combination list		<maxtfc></maxtfc>		
>>Allowed transport format	MP		Transport	
combination			format	
			combination	
			10.3.5.19	
>Non-allowed transport format		1 to		
combination list		<maxtfc></maxtfc>		
>>Non-allowed transport format	MP		Transport	
combination			format	
			combination	
D tit IT OIL (4.	10.3.5.19	
>Restricted TrCH information		1 to		
		<maxtrch< td=""><td></td><td></td></maxtrch<>		
I latint transport shows at two	MP	>	Cross cross of	LICCILIA TDD ank
>>Uplink transport channel type	IMP		Enumerated(USCH is TDD only
. Dootsisted III. TrOI lide with	MD	+	DCH, USCH)	
>>Restricted UL TrCH identity	MP		Transport channel	
			identity	
>>Allowed TFIs	OP	1 to	10.3.5.18	
>>Allowed Tris	UP	<maxtf></maxtf>		
>>>Allowed TFI	MP	<iiiax1r></iiiax1r>	Integer(0, 24	
>>>Allowed TFI	IVIP		Integer(031	
>Full transport format				(No data)
combination set				·

10.3.5.23 Transport Format Set

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE Transport channel type	MP			
>Dedicated transport channels				The transport channel that is configured with this TFS is of type DCH
>>Dynamic Transport Format Information	MP	1 to <maxtf></maxtf>		
>>>RLC Size	MP		Integer(049 92)	Unit is bits
>>>Number of TBs and TTI List	MP	1 to <maxtf></maxtf>		Present for every valid number of TB's (and TTI) for this RLC Size.
>>>Transmission Time Interval	CV- dynamicTT I		Integer(10,2 0,40,80)	Unit is ms.
>>>Number of Transport blocks	MP		Integer(051 2)	
>>>CHOICE Logical Channel List	MP			The logical channels that are allowed to use this RLC Size
>>>ALL			Null	All logical channels mapped to this transport channel.
>>>Configured			Null	The logical channels configured to use this RLC size in the <i>RB mapping info.</i> 10.3.4.21 if present in this

Information Element/Group name	Need	Multi	Type and reference	Semantics description
				message or in the previously stored configuration otherwise
>>>>Explicit List		1 to 15		Lists the logical channels that are allowed to use this RLC size.
>>>>RB Identity	MP		RB identity 10.3.4.16	
>>>>LogicalChannel	CH-UL- RLCLogica IChannels		Integer(01)	Indicates the relevant UL logical channel for this RB. "0" corresponds to the first, "1" corresponds to the second UL logical channel configured for this RB in the IE "RB mapping info".
>>Semi-static Transport Format Information	MP		Semi-static Transport Format Information 10.3.5.11	
>Common transport channels				The transport channel that is configured with this TFS is of a type not equal to DCH
>>Dynamic Transport Format Information	MP	1 to <maxtf></maxtf>		Note
>>>RLC Size	MP		Integer(049 92)	Unit is bits
>>>Number of TBs and TTI List	MP	1 to <maxtf></maxtf>		Present for every valid number of TB's (and TTI) for this RLC Size.
>>>Number of Transport blocks	MP		Integer(051 2)	
>>>>CHOICE mode	MP			
>>>>FDD				(no data)
>>>>TDD	0) (1	11.77
>>>>>Transmission Time Interval	CV- dynamicTT I		Integer(10,2 0,40,80)	Unit is ms.
>>>CHOICE Logical Channel List	MP			The logical channels that are allowed to use this RLC Size.
>>>ALL			Null	All logical channels mapped to this transport channel.
>>>>Configured			Null	The logical channels configured to use this RLC size in the <i>RB mapping info</i> . 10.3.4.21 if present in this message or in the previously stored configuration otherwise
>>>Explicit List		1 to 15		Lists the logical channels that are allowed to use this RLC size.
>>>>RB Identity	MP		RB identity 10.3.4.16	
>>>>LogicalChannel	CV-UL- RLCLogica IChannels		Integer(01)	Indicates the relevant UL logical channel for this RB. "0" corresponds to the first, "1" corresponds to the second UL logical channel configured for this RB in the IE "RB mapping info".
>>Semi-static Transport Format Information	MP		Semi-static Transport Format Information 10.3.5.11	

Condition	Explanation
dynamicTTI	This IE is mandatory present if dynamic TTI usage is indicated in IE Transmission Time Interval in Semistatic Transport Format Information. Otherwise it is not needed.
UL-RLCLogicalChannels	If "Number of uplink RLC logical channels" in IE "RB mapping info" in this message is 2 or the IE "RB mapping info" is not present in this message and 2 UL logical channels are configured for this RB, then this IE is mandatory present. Otherwise this IE is not needed.

10.3.5.24 UL Transport channel information common for all transport channels

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			reference	description	
PRACH TFCS	OP		Transport	This IE should not	
			format	be included in this	
			combination	version of the	
			set 10.3.5.20	protocol.	
CHOICE mode	OP				
>FDD					

		1		1	Г
>>TFC subset	MD		Transport	Default value is	
			Format	the complete	
			Combination	existing set of	
			Subset	transport format	
			10.3.5.22	combinations	
>>UL DCH TFCS	MP		Transport	COMBINATION	
>>0E BOTT 11 00	I WII		formation		
			combination		
			set 10.3.5.20		
>TDD					
>>Individual UL CCTrCH	OP	1 to			
information		<maxcctr< td=""><td></td><td></td><td></td></maxcctr<>			
		CH>			
>>>UL TFCS Identity	MP		Transport	Identifies a special	
			format	CCTrCH for	
			combination	shared or	
			set identity	dedicated	
LII TEOO	MD		10.3.5.21	channels.	
>>>UL TFCS	MP		Transport		
			format		
			combination		
			set 10.3.5.20		
>>>TFC subset	MD		Transport	Default value is	
			Format	the complete	
			Combination	existing set of	
			Subset	transport format	
			10.3.5.22	combinations	
TFC subset list	OP	1 to	10.3.3.22	COMBINATIONS	REL-4
TPC Subset list	UP				REL-4
		<maxtfcs< td=""><td></td><td></td><td></td></maxtfcs<>			
		ub>			
>CHOICE mode	MP				REL-4
>>FDD				(no data)	REL-4
>>TDD					REL-4
>>>TFCS Id	OP		Transport		REL-4
			Format		
			Combination		
			Set Identity		
			10.3.5.21		
>TFC subset	MD				REL-4
>IFC SUDSET	MP		Transport		KEL-4
			Format		
			Combination		
			Subset		
			10.3.5.22		

NOTE: This information element is included within IE "Predefined TrCh configuration".

10.3.6 Physical CH Information elements

10.3.6.1 AC-to-ASC mapping

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
AC-to-ASC mapping table	MP	maxASCm		
		ар		
>AC-to-ASC mapping	MP		Integer(07	Mapping of Access Classes to
)	Access Service Classes (see
				subclause 8.5.13.)

10.3.6.2 AICH Info

NOTE: Only for FDD.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Channelisation code	MP		Integer(025 5)	SF is fixed and equal to 256
STTD indicator	MP		STTD Indicator 10.3.6.78	
AICH transmission timing	MP		Enumerated (0, 1)	See parameter AICH_Transmission_Timing in [26]

10.3.6.3 AICH Power offset

NOTE: Only for FDD.

This parameter is used to indicate the power level of AICH, AP-AICH and CD/CA-ICH channels. This is the power per transmitted Acquisition Indicator, AP Acquisition Indicator or CD/CA Indicator minus power of the Primary CPICH.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
AICH Power offset	MP		Integer(- 22+5)	Offset in dB

10.3.6.4 Allocation period info

NOTE: Only for TDD.

Parameters used by UE to determine period of shared channel allocation.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Allocation Activation Time	MP		Integer (0255)	Start the allocation period at the given CFN.
Allocation Duration	MP		Integer (1256)	Total number of frames for the allocation period.

10.3.6.5 Alpha

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Alpha Value	MP		Enumerated(
			0, 1/8, 2/8,	
			3/8, 4/8, 5/8,	
			6/8, 7/8, 1)	

10.3.6.6 ASC setting

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			reference	description	
CHOICE mode	MP				
>FDD					
>>Available signature Start	MP		Integer(015		
Index)		
>>Available signature End Index	MP		Integer(015		
-)		
>>Assigned Sub-Channel	MP		Bit string(4)	This IE defines	

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			reference	description	
Number				the subchannel	
				assignment as	
				specified in	
				8.6.6.29.	
				The first/leftmost	
				bit of the bit string	
				contains the most	
				significant bit of	
				the Assigned Sub-	
T00				Channel Number	
>TDD	MD				DEL 4
>>CHOICE TDD option	MP				REL-4
>>>3.84 Mcps TDD	MD		D:((°)	F 1 1 2 2 2 4	REL-4
>>>>Available Channelisation	MD		Bit string(8)	Each bit indicates	
codes indices				availability of a	
				channelisation	
				code index, where	
				the channelisation	
				code indices are	
				numbered	
				"channelisation	
				code index 0" to	
				"channelisation	
				code index 7".	
				The value 1 of a	
				bit indicates that	
				the channelisation	
				code index is	
				available for the	
				ASC this IE is	
				associated to. The	
				value 0 of a bit	
				indicates that the	
				channelisation	
				code index is not	
				available for the	
				ASC this IE is	
				associated to.	
				Default is that all	
				channelisation	
				codes defined in	
				PRACH Info are	
10011 TDD				available.	55. 4
>>>1.28 Mcps TDD	MD		Dit atri(0)	Fach hit is disease.	REL-4
>>>Available SYNC_UL codes	MD		Bit string(8)	Each bit indicates	REL-4
indices				availability of a	
				SYNC_UL code	
				index, where the	
				SYNC_UL code	
				indices are	
				numbered	
				"SYNC_UL code	
				index 0" to	
				"SYNC_UL code	
				index 7". The	
				value 1 of a bit	
				indicates that the	
				SYNC_UL code	
				index is available	
				for the ASC this IE	
				is associated to.	
				The value 0 of a	
				bit indicates that	
				the SYNC_UL	
				code index is not	
				available for the	

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			reference	description	
				ASC this IE is	
				associated to.	
				Default is that all	
				SYNC_UL codes	
				defined in	
				SYNC_UL Info	
				are available.	
>>CHOICE subchannel size	MP				
>>>Size1					
>>>Available Subchannels	MP		null	Indicates that all	
				Subchannels are	
				available	
>>>Size2					
>>>>Available Subchannels	MD		Bit string (2)	NOTE	
>>>Size4					
>>>>Available Subchannels	MD		Bit string (4)	NOTE	
>>>Size8					
>>>Available Subchannels	MD		Bit string (8)	NOTE	

NOTE: Each bit indicates availability of a subchannel, where the subchannels are numbered subchannel 0, subchannel 1 etc. The value 1 of a bit indicates that the subchannel is available for the ASC this IE is associated with. The value 0 of a bit indicates that the subchannel is not available for the ASC this IE is associated with. Default value of the IE is that all subchannels within the size are available for the ASC this IE is associated with.

10.3.6.7 Void

10.3.6.8 CCTrCH power control info

Parameters used by UE to set the SIR target value for uplink open loop power control in TDD.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
TFCS Identity	OP		Transport Format Combination Set Identity 10.3.5.21	TFCS Identity of this CCTrCH. Default value is 1.
Uplink DPCH power control info	MP		Uplink DPCH power control info 10.3.6.91	

10.3.6.8a Cell and Channel Identity info

NOTE: Only for TDD.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
Burst type	MP		Enumerated (Type1, Type2)	Identifies the channel in combination with the Midamble shift and slot number
Midamble Shift	MP		Integer (015)	
Time Slot	OP		Timeslot number 10.3.6.84	This IE is present only if no IPDL scheme is configured in the reference cell. Otherwise the slot is defined by the IPDL configuration.
Cell parameters ID	MP		Cell parameters ID 10.3.6.9	Identifies the cell

10.3.6.9 Cell parameters Id

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
Cell parameter Id	MP		Integer(012 7)	

10.3.6.10 Common timeslot info

Information Element/Group name	Need	Multi	Type and reference	Semantics description
2 nd interleaving mode	MD		Enumerated(Frame, Timeslot)	Frame timeslot related interleaving. Default value is "Frame"
TFCI coding	MD		Integer(4,8,1 6,32)	Describes the amount of bits for the TFCI bits code word as described in [31]. Defaults is no TFCI bit: In case of 8 PSK in 1.28Mcps TDD: 4 corresponds to 6 TFCI code word bits. 8 corresponds to 12 TFCI code word bits. 16 corresponds to 24 TFCI code word bits. 32 corresponds to 48 TFCI code word bits.
Puncturing limit	MP		Real(0.401. 0 by step of 0.04)	
Repetition period	MD		Integer(1, 2,4,8,16,32,6 4)	Default is continuous allocation. Value 1 indicate continuous
Repetition length	MP		Integer(1 Repetition period –1)	NOTE: This is empty if repetition period is set to 1.

10.3.6.11 Constant value

NOTE: Only for FDD.

This constant value is used by the UE to calculate the initial output power on PRACH according to the Open loop power control procedure.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Constant value	MP		Integer (- 3510)	In dB

10.3.6.11a Constant value TDD

NOTE: Only for 3.84 Mcps TDD.

3.84 Mcps TDD constant values are used for open loop power control of PRACH, USCH, HS-SICH and UL DPCH as defined in subclause 8.5.7.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
TDD Constant value	MP		Integer (- 35+10)	In dB

10.3.6.12 CPCH persistence levels

NOTE: Only for FDD.

This IE is dynamic and is used by RNC for load balancing and congestion control. This is broadcast often in the system information message.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CPCH set ID	MP		Integer (1 <maxcpchs ets>)</maxcpchs 	Identifier for CPCH set info.
Dynamic persistence level	MP	1 to <maxtf- CPCH></maxtf- 		
>Dynamic persistence level	MP		Dynamic persistence level 10.3.6.35	Persistence level for transport format.

10.3.6.13 CPCH set info

NOTE: Only for FDD.

This IE may be broadcast in the System Information message or assigned by SRNC. It is pseudo-static in a cell.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CPCH set ID	MP		CPCH set ID 10.3.5.3	Indicates the ID number for a particular CPCH set allocated to a cell.
TFS	MP		Transport Format Set 10.3.5.23	Transport Format Set Information allocated to this CPCH set.
TFCS	MP		Transport Format Combination Set 10.3.5.20	Transport Format Set Information allocated to this CPCH set
AP preamble scrambling code	MP		Integer (079)	Preamble scrambling code for AP in UL
AP-AICH channelisation code	MP		Integer(025 5)	Channelisation code for AP- AICH in DL
CD preamble scrambling code	MP		Integer (079)	Preamble scrambling code for CD in UL

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CD/CA-ICH channelisation code	MP		Integer (0255)	Channelisation code for CD/CA-ICH in DL
Available CD access slot subchannel	CV- CDSigPres ent	1 to <maxpcp CH- CDsubCh></maxpcp 		Lists the set of subchannels to be used for CD access preambles. NOTE: If not present, all subchannels are to be used without access delays.
>CD access slot subchannel	MP		Integer (011)	
Available CD signatures	OP	1 to <maxpcp CH-CDsig></maxpcp 		Signatures for CD preamble in UL. NOTE: If not present, all signatures are available for use.
>CD signatures	MP		Integer (015)	
DeltaPp-m	MP		Integer (- 1010)	In dB. Power offset between the transmitted CD preamble and UL DPCCH of the power control preamble or message part (added to the preamble power to calculate the power of the UL DPCCH)
UL DPCCH Slot Format	MP		Enumerated (0,1,2)	Slot format for UL DPCCH in power control preamble and in message part
N_start_message	MP		Integer (18)	Number of Frames for start of message indication
N_EOT	MP		Integer(07)	Actual number of appended EOT indicators is T_EOT = N_TTI * ceil(N_EOT/N_TTI), where N_TTI is the number of frames per TTI and "ceil" refers to rounding up to nearest integer.
Channel Assignment Active	OP		Boolean	When present, indicates that Node B send a CA message and VCAM mapping rule (14.11) shall be used.
CPCH status indication mode	MP		CPCH status indication mode 10.3.6.14	
PCPCH Channel Info.	MP	1 to <maxpcp CHs></maxpcp 		
>UL scrambling code	MP		Integer (079)	For PCPCH message part
>DL channelisation code	MP		Integer (0511)	For DL DPCCH for PCPCH message part
>DL scrambling code	MD		Secondary Scrambling Code 10.3.6.74	Default is the same scrambling code as for the primary CPICH.
>PCP length	MP		Enumerated (0, 8)	Indicates length of power control preamble, 0slots (no preamble used) or 8 slots
>UCSM Info	CV-NCAA		Intogor	The HE may use this DODOLL
>>Minimum Spreading Factor	MP		Integer (4,8,16,32,6 4,128,256)	The UE may use this PCPCH at any Spreading Factor equal to or greater than the indicated minimum Spreading Factor. The Spreading Factor for initial access is the minimum

Information Element/Group name	Need	Multi	Type and reference	Semantics description
				Spreading Factor.
>>NF_max	MP		Integer (164)	Maximum number of frames for PCPCH message part
>>Channel request parameters for UCSM	MP			Required in UE channel selection mode.
>>>Available AP signature	MP	1 to <maxpcp CH-APsig></maxpcp 		AP preamble signature codes for selection of this PCPCH channel.
>>>AP signature	MP		Integer (015)	
>>>Available AP access slot subchannel	OP	1 to <maxpcp CH- APsubCh></maxpcp 		Lists the set of subchannels to be used for AP access preambles in combination with the above AP signature(s). NOTE: If not present, all subchannels are to be used without access delays.
>>>AP access slot subchannel	MP		Integer (011)	
VCAM info	CV-CAA			
>Available Minimum Spreading Factor	MP	1 to <maxpcp CH-SF></maxpcp 		
>>Minimum Spreading Factor	MP		Enumerated (4,8,16,32,6 4,128,256)	
>>NF_max	MP		Integer (164)	Maximum number of frames for PCPCH message part
>>Maximum available number of PCPCH	MP		Integer (164)	Maximum available number of PCPCH for the indicated Spreading Factor.
>>Available AP signatures	MP	1 to <maxpcp CH-APsig></maxpcp 		Signatures for AP preamble in UL.
>>>AP signature			Integer (015)	
>>Available AP sub-channel	OP	1 to <maxpcp CH- APsubCh></maxpcp 		AP sub-channels for the given AP signature in UL. NOTE: If not present, all subchannels are to be used without access delays.
>>>AP sub-channel	MP		Integer (011)	

Condition	Explanation
CDSigPresent	This IE is optional if IE "Available CD signatures" is
	present and not needed otherwise.
NCAA	This IE is mandatory present if IE "Channel
	Assignment Active" is not present and not needed
	otherwise.
CAA	This IE is mandatory present if IE ""Channel
	Assignment Active" is present and not needed
	otherwise.

10.3.6.14 CPCH Status Indication mode

NOTE: Only for FDD.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
CPCH Status Indication mode	MP		Enumerated (PA mode, PAMSF mode)	Defines the status information type broadcast on the CPCH Status Indication Channel (CSICH)

CPCH Status Indication mode defines the structure of the CSICH information that is broadcast by Node B on the CSICH channel. CSICH mode can take 2 values: PCPCH Availability (PA) mode and PCPCH Availability with Minimum Available Spreading Factor (PAMASF) mode. PAMASF mode is used when Channel Assignment is active. PA mode is used when Channel Assignment is not active (UE Channel Selection is active). [26] defines the structure of the CSICH information for both CSICH modes.

10.3.6.15 CSICH Power offset

NOTE: Only for FDD.

This is the power per transmitted CSICH Indicator minus power of the Primary CPICH.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CSICH Power offset	MP		Integer(- 10+5)	Offset in dB, granularity of 1

10.3.6.16 Default DPCH Offset Value

Indicates the default offset value within interleaving size at a resolution of 512chip (1/5 slot) in FDD and a resolution of one frame in TDD to offset CFN in the UE. This is used to distribute discontinuous transmission periods in time and also to distribute NodeB-RNC transmission traffics in time. Even though the CFN is offset by DOFF, the start timing of the interleaving will be the timing that "CFN mod (interleaving size)"=0 (e.g. interleaving size: 2,4,8) in both UE and SRNC.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE mode				
>FDD				
>>Default DPCH Offset Value (DOFF)	MP		Integer (0306688 by step of 512)	Number of chips=. 0 to 599 time 512 chips, see [10].
>TDD				
>>Default DPCH Offset Value (DOFF)	MP		Integer(07)	Number of frames; See [10]

10.3.6.17 Downlink channelisation codes

NOTE: Only for TDD

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
CHOICE codes representation	MP			
>Consecutive codes				
>>First channelisation code	MP		Enumerated ((16/1)(16/1 6))	If a TFCI exists in this timeslot, it is mapped to the channelisation code as defined in [30].
>>Last channelisation code	MP		Enumerated ((16/1)(16/1 6))	If this is the same as First channelisation code, only one code is used by the physical layer.
>Bitmap				
>>Channelisation codes bitmap	MP		Bit string(16)	Each bit indicates the availability of a channelisation code for SF16, where the channelisation codes are numbered as channelisation code 1 (SF16) to channelisation code 16 (SF16). (For SF 16, a 1 in the bitmap means that the corresponding code is used, a 0 means that the corresponding code is not used.) If all bits are set to zero, SF 1 shall be used.

10.3.6.18 Downlink DPCH info common for all RL

Information	Need	Multi	Type and	Semantics description	Version
Element/Group name			reference		
Timing Indication	MP		Enumerat	NOTE	
			ed(Initialis		
			e,		
			Maintain)		
CFN-targetSFN frame	CV-		Integer(0	In frame	
offset	TimInd		255)		
Downlink DPCH power	OP		Downlink		
control information			DPCH		
			power		
			control		
			informatio		
			n		
			10.3.6.23		
MAC-d HFN initial value	CV-		Bit		REL-4
	Messag		string(24)		
	е				
CHOICE mode	MP				
>FDD					
>>Power offset P Pilot-	MP		Integer(0	Power offset equals	
DPDCH			24)	P _{Pilot} - P _{DPDCH} , range	
				06 dB, in steps of 0.25	
				dB	
>>Downlink rate	OP		Downlink	If this IE is set to	
matching restriction			rate	"absent", no Transport	
information			matching	CH is restricted in TFI.	
			restriction		
			informatio		
			n		
			10.3.6.31		
>>Spreading factor	MP		Integer(4,		
			8, 16, 32,		
			64, 128,		
			256, 512)		

Information	Need	Multi	Type and	Semantics description	Version
Element/Group name			reference	-	
>>Fixed or Flexible	MP		Enumerat		
Position			ed (Fixed,		
			Flexible)		
>>TFCI existence	MP		Boolean	TRUE indicates that	
				TFCI is used. When	
				spreading factor is less	
				than or equal to 64,	
				FALSE indicates that	
				TFCI is not used and	
				therefore DTX is used	
0.10.05.05				in the TFCI field.	
>>CHOICE SF	MP				
>>>SF = 256					
>>>>Number of bits for	MP		Integer	In bits	
Pilot bits			(2,4,8)		
>>>SF = 128					
>>>>Number of bits for	MP		Integer(4,	In bits	
Pilot bits			8)		
>>>Otherwise				(no data). In ASN.1	
				choice "Otherwise" is	
				not explicitly available	
				as all values are	
				available, it is implied	
				by the use of any value	
TDD				other than 128 or 256.	
>TDD				(no data)	

CHOICE SF	Condition under which the given SF is chosen
SF=128	"Spreading factor" is set to 128
SF=256	"Spreading factor" is set to 256
Otherwise	"Spreading factor" is set to a value distinct from 128
	and 256

Condition	Explanation
TimInd	This IE is optional if the IE "Timing Indication" is set to
	"Initialise". Otherwise it is not needed.
Message	This IE is not needed if the IE "Downlink DPCH info common for all RL" is included in RRC CONNECTION SETUP or HANDOVER TO UTRAN COMMAND messages. Otherwise it is optional.

NOTE: Within the HANDOVER TO UTRAN COMMAND message, only value "initialise" is applicable.

10.3.6.19 Downlink DPCH info common for all RL Post

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Downlink DPCH power control information	OP		Downlink DPCH power control information 10.3.6.23	

10.3.6.20 Downlink DPCH info common for all RL Pre

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
CHOICE mode	MP			
>FDD				
>>Spreading factor	MP		Integer(4, 8,	Defined in CHOICE SF512-

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE mode	MP		reference	
>FDD	1011			
7100			16, 32, 64, 128, 256, 512)	Andpilot with "number of its for pilot bits" in ASN.1
>>Fixed or Flexible Position	MP		Enumerated (Fixed, Flexible)	
>>TFCI existence	MP		Boolean	TRUE indicates that TFCI is used. When spreading factor is less than or equal to 64, FALSE indicates that TFCI is not used and therefore DTX is used in the TFCI field.
>>CHOICE SF	MP			
>>>SF = 256				
>>>Number of bits for Pilot bits	MP		Integer (2,4,8)	In bits
>>>SF = 128				
>>>Number of bits for Pilot bits	MP		Integer(4,8)	In bits
>>>Otherwise				(no data)
>TDD				
>>Common timeslot info	MP		Common Timeslot Info 10.3.6.10	

CHOICE SF	Condition under which the given SF is chosen		
SF=128	"Spreading factor" is set to 128		
SF=256	"Spreading factor" is set to 256		
Otherwise	"Spreading factor" is set to a value distinct from 128		
	and 256		

10.3.6.21 Downlink DPCH info for each RL

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
CHOICE mode	MP		reference		
>FDD	1011				
>>Primary CPICH usage for channel estimation	MP		Primary CPICH usage for channel estimation 10.3.6.62		
>>DPCH frame offset	MP		Integer(0 38144 by step of 256)	Offset (in number of chips) between the beginning of the P-CCPCH frame and the beginning of the DPCH frame This is called $\tau_{DPCH,n}$ in [26]	
>>Secondary CPICH info	OP		Secondar y CPICH info 10.3.6.73		
>>DL channelisation code	MP	1 to <maxdp CH- DLchan ></maxdp 		For the purpose of physical channel mapping [27] the DPCHs are numbered, starting from DPCH	

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
				number 1, according to	
				the order that they are contained in this IE.	
>>>Secondary	MD		Secondar	Default is the same	
scrambling code	"""		у	scrambling code as for	
S .			scramblin	the Primary CPICH	
			g code		
	140		10.3.6.74	D () 011010E	
>>>Spreading factor	MP		Integer(4, 8, 16, 32,	Defined in CHOICE SF512-	
			64, 128,	AndCodenumber with	
			256, 512)	"code number" in	
			,	ASN.1	
>>>Code number	MP		Integer(0		
			Spreading		
0 11:	011.05%		factor - 1)		
>>>Scrambling code	CH-SF/2		Enumerat	Indicates whether the alternative scrambling	
change			ed (code change,	code is used for	
			no code	compressed mode	
			change)	method 'SF/2'.	
>>TPC combination	MP		TPC		
index			combinati		
			on index		
>>Power offset P _{TPC} -	OP		10.3.6.85	Dower offeet equals	REL-5
	UP		Integer (024)	Power offset equals PTPC- PDPDCH, range 06	KEL-3
DPDCH			(024)	dB, in steps of 0.25 dB	
>>SSDT Cell Identity	OP		SSDT		
			Cell		
			Identity		
01 11 11	011		10.3.6.76	10 ° C T	
>>Closed loop timing	CH- TxDivers		Integer(1,	It is present if Tx	
adjustment mode	ity Mode		2)	Diversity is used in the radio link.	
>TDD	ny mode			radio iirik.	
>>DL CCTrCh List	OP	1 <max< td=""><td></td><td>DL physical channels to</td><td></td></max<>		DL physical channels to	
		CCTrCH		establish or reconfigure	
		>		list.	
>>>TFCS ID	MD		Integer(1	Identity of this CCTrCh.	
>>>Time info	MP		8) Time Info	Default value is 1	
	IVII		10.3.6.83		
>>>Common timeslot	MD		Common	Default is the current	
info			Timeslot	Common timeslot info	
			Info		
D. II I DDOLL	MD		10.3.6.10	D ()(: () ()	
>>>Downlink DPCH timeslots and codes	MD		Downlink Timeslots	Default is to use the old timeslots and codes.	
timesiots and codes			and	timesions and codes.	
			Codes		
			10.3.6.32		
>>>UL CCTrCH TPC List	MD	0 <max< td=""><td></td><td>UL CCTrCH identities</td><td></td></max<>		UL CCTrCH identities	
		CCTrCH		for TPC commands	
		>		associated with this DL	
				CCTrCH. Default is	
				previous list or all defined UL CCTrCHs.	
				This list is not required	
				for 1.28 Mcps TDD and	
				is to be ignored by the	
== -				UE.	
>>>>UL TPC TFCS	MP		Transport		
Identity			Format Combinati		
			on Set		
	1	l	J.: 00t	1	

Information	Need	Multi	Type and	Semantics description	Version
Element/Group name			reference		
			Identity		
			10.3.5.21		
>>DL CCTrCH List to Remove	OP	1 <max CCTrCH</max 		DL physical channels to remove list.	
>>>TFCS ID	MP		Integer(1		
			8)		

Condition	Explanation
SF/2	The information element is mandatory present if the UE has a compressed mode pattern sequence configured in variable TGPS_IDENTITY or included in the message including IE "Downlink DPCH info for each RL", which is using compressed mode method "SF/2". Otherwise the IE is not needed.
TxDiversity Mode	This IE is mandatory present if any TX Diversity Mode is used on the radio link, i.e. if STTD, "closed loop mode 1" or "closed loop mode 2" is used on the radio link. Otherwise the IE is not needed.

10.3.6.22 Downlink DPCH info for each RL Post

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE mode	MP		10.0.0.0	
>FDD				
>>Primary CPICH usage for channel estimation	MP		Primary CPICH usage for channel estimation 10.3.6.62	
>>Secondary scrambling code	MD		Secondary scrambling code 10.3.6.74	Default is the same scrambling code as for the Primary CPICH
>>CHOICE Spreading factor	MP		Integer(4, 8, 16, 32, 64, 128, 256, 512)	Defined in CHOICE SF512- AndCodenumber with "code number" in ASN.1
>>Code number	MP		Integer(0 Spreading factor - 1)	
>>Scrambling code change	CH-SF/2		Enumerated (code change, no code change)	Indicates whether the alternative scrambling code is used for compressed mode method 'SF/2'.
>>TPC combination index	MP		TPC combination index 10.3.6.85	
>TDD				
>>Downlink DPCH timeslots and codes	MP		Downlink Timeslots and Codes 10.3.6.32	

Condition	Explanation		
SF/2	The information element is mandatory present if the		
	UE has a compressed mode pattern sequence		
	configured in variable TGPS_IDENTITY or included in		
	the message including IE "Downlink DPCH info for		
	each RL Post", which is using compressed mode		
	method "SF/2". Otherwise the IE is not needed.		

10.3.6.23 Downlink DPCH power control information

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE mode	MP			
>FDD				
>>DPC Mode	MP		Enumerated (Single TPC, TPC triplet in soft)	"Single TPC" is DPC_Mode=0 and "TPC triplet in soft" is DPC_mode=1 in [29].
>TDD				
>>TPC Step Size	OP		Integer (1, 2, 3)	In dB

10.3.6.23a Downlink HS-PDSCH Information

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
HS-SCCH Info	OP		HS-SCCH Info 10.3.6.36a		REL-5
Measurement Feedback Info	OP		Measuremen t Feedback Info 10.3.6.40a		REL-5
CHOICE mode	MP				REL-5
>TDD					
>>CHOICE TDD option	MP				REL-5
>>>3.84 Mcps					
>>>HS-PDSCH Timeslot Configuration	OP		HS-PDSCH Timeslot Configuratio n 10.3.6.360		REL-5
>>> 1.28 Mcps					
>>>> HS-PDSCH Midamble Configuration	OP		HS-PDSCH Midamble Configuratio n 10.3.6.3600		REL-5
>FDD				(No data)	

10.3.6.24 Downlink information common for all radio links

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Downlink DPCH info common for all RL	OP		Downlink DPCH info common for all RL 10.3.6.18	·	
CHOICE mode	MP				
>FDD					
>>DPCH compressed mode info	OP		DPCH compressed		

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Than 10			mode info 10.3.6.33	uooop.iio.ii	
>>TX Diversity Mode	MD		TX Diversity Mode 10.3.6.86	Default value is the existing value of TX Diversity mode	
>>SSDT information	OP		SSDT information 10.3.6.77		
>TDD				(no data)	
>>CHOICE TDD option	MP				REL-4
>>>3.84 Mcps TDD				(no data)	REL-4
>>>1.28 Mcps TDD					REL-4
>>>>TSTD indicator	MP		TSTD indicator 10.3.6.85a		REL-4
Default DPCH Offset Value	OP		Default DPCH Offset Value, 10.3.6.16		
MAC-hs reset indicator	CV- messageT ype		Enumerated (true)	TRUE Indicates the MAC-hs entity needs to be reset.	REL-5

Condition	Explanation
MessageType	The IE is not needed in the HANDOVER TO UTRAN COMMAND and the RRC CONNECTION SETUP messages. Otherwise, it is optional.

10.3.6.25 Downlink information common for all radio links Post

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Downlink DPCH info common for all RL	MP		Downlink DPCH info common for all RL Post 10.3.6.19	

10.3.6.26 Downlink information common for all radio links Pre

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Downlink DPCH info common	MP		Downlink	
for all RL			DPCH info	
			common for	
			all RL Pre	
			10.3.6.20	

10.3.6.27 Downlink information for each radio link

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Choice mode	MP		TOTOTOTOC	description	
Choice mode	IVIE				
>FDD					
>>Primary CPICH info	MP		Primary		
,			CPICH info		
			10.3.6.60		
>>Cell ID	OP		Cell ID		REL-4

		10.3.2.2		
>>PDSCH with SHO DCH Info	OP	PDSCH with SHO DCH Info 10.3.6.47		
>>PDSCH code mapping	OP	PDSCH code mapping 10.3.6.43		
>>Serving HS-DSCH radio link indicator	CV- not_rrcCon nectionSet up	Boolean	The value "TRUE" indicates that this radio link is the serving HS-DSCH radio link	REL-5
>TDD				
>>Primary CCPCH info	MP	Primary CCPCH info 10.3.6.57		
Downlink DPCH info for each RL	OP	Downlink DPCH info for each RL 10.3.6.21		
SCCPCH Information for FACH	OP	SCCPCH Information for FACH 10.3.6.70		

Condition	Explanation
not_rrcConnectionSetup	This IE is not needed in the RRC CONNECTION
	SETUP message. Otherwise it is mandatory present.

10.3.6.28 Downlink information for each radio link Post

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Choice mode	MP				
>FDD					
>>Primary CPICH info	MP		Primary CPICH info 10.3.6.60		
>>Cell ID	OP		Cell ID 10.3.2.2		REL-4
>TDD					
>>Primary CCPCH info	MP		Primary CCPCH info post 10.3.6.58		
Downlink DPCH info for each RL	MP		Downlink DPCH info for each RL Post 10.3.6.22		

10.3.6.29 Void

10.3.6.30 Downlink PDSCH information

NOTE: Only for FDD.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
PDSCH with SHO DCH Info	OP		PDSCH with	
			SHO DCH	
			Info	
			10.3.6.47	
PDSCH code mapping	OP		PDSCH	
			code	
			mapping	
			10.3.6.43	

10.3.6.31 Downlink rate matching restriction information

This IE indicates which TrCH is restricted in TFI.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Restricted TrCH information	OP	1 to <maxtrch ></maxtrch 		
>Downlink transport channel type	MP		Enumerated(DCH,DSCH)	
>Restricted DL TrCH identity	MP		Transport channel identity 10.3.5.18	
>Allowed TFIs	MP	1 to <maxtf></maxtf>		
>>Allowed TFI	MP		Integer(031	

10.3.6.32 Downlink Timeslots and Codes

NOTE: Only for TDD

Information Element/Group name	Need	Multi	Type and reference	Semantics description
First Individual timeslot info	MP		Individual timeslot info 10.3.6.37	Individual timeslot info for the first timeslot used by the physical layer.
First timeslot channelisation codes	MP		Downlink channelisatio n codes 10.3.6.17	These codes shall be used by the physical layer in the timeslot given in First Individual timeslot info.
CHOICE more timeslots	MP			
>No more timeslots				(no data)
>Consecutive timeslots				

Information Element/Group name	Need	Multi	Type and reference	Semantics description
>>Number of additional timeslots	MP		Integer(1m axTS-1)	The timeslots used by the physical layer shall be timeslots: N mod maxTS (N+1) mod maxTS (N+k) mod maxTS in that order, where N is the timeslot number in the First individual timeslot info and k the Number of additional timeslots. The additional timeslots shall use the same parameters (e.g. channelisation codes, midamble shifts etc.) as the first timeslot.
>Timeslot list				
>>Additional timeslot list	MP	1 to <maxts- 1></maxts- 		The first instance of this parameter corresponds to the timeslot that shall be used second by the physical layer, the second to the timeslot that shall be used third and so on.
>>>CHOICE parameters	MP			
>>>Same as last				
>>>>Timeslot number	MP		Timeslot Number 10.3.6.84	The physical layer shall use the same parameters (e.g. channelisation codes, midamble shifts etc.) for this timeslot as for the last one.
>>>>New parameters				
>>>>Individual timeslot info	MP		Individual timeslot info 10.3.6.37	
>>>>Channelisation codes	MP		Downlink channelisatio n codes 10.3.6.17	

10.3.6.33 DPCH compressed mode info

NOTE: Only for FDD.

This information element indicates the parameters of the compressed mode to be used by the UE in order to perform inter-frequency and inter-RAT measurements.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Transmission gap pattern sequence	MP	1 to <maxtgp S></maxtgp 		
>TGPSI	MP		TGPSI 10.3.6.82	
>TGPS Status Flag	MP		Enumerated(activate, deactivate)	This flag indicates whether the Transmission Gap Pattern Sequence shall be activated or deactivated.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
>TGCFN	CV-Active		Integer (0255)	Connection Frame Number of the first frame of the first pattern within the Transmission Gap Pattern Sequence.
>Transmission gap pattern sequence configuration parameters	OP			
>>TGMP	MP		Enumerated(TDD measuremen t, FDD measuremen t, GSM carrier RSSI measuremen t, GSM Initial BSIC identification, GSM BSIC re- confirmation, Multi-carrier measuremen t)	Transmission Gap pattern sequence Measurement Purpose.
>>TGPRC	MP		Integer (1511, Infinity)	The number of transmission gap patterns within the Transmission Gap Pattern Sequence.
>>TGSN	MP		Integer (014)	Transmission Gap Starting Slot Number The slot number of the first transmission gap slot within the TGCFN.
>>TGL1	MP		Integer(114)	The length of the first Transmission Gap within the transmission gap pattern expressed in number of slots
>>TGL2	MD		Integer (114)	The length of the second Transmission Gap within the transmission gap pattern. If omitted, then TGL2=TGL1. The value of TGL2 shall be ignored if TGD is set to "undefined"
>>TGD	MP		Integer(152 69, undefined)	Transmission gap distance indicates the number of slots between starting slots of two consecutive transmission gaps within a transmission gap pattern. If there is only one transmission gap in the transmission gap pattern, this parameter shall be set to undefined.
>>TGPL1	MP		Integer (1144)	The duration of transmission gap pattern 1.
>>TGPL2	MD		Integer (1144)	The duration of transmission gap pattern 2. If omitted, then TGPL2=TGPL1.
>>RPP	MP		Enumerated (mode 0, mode 1).	Recovery Period Power control mode during the frame after the transmission gap within the compressed frame. Indicates whether normal PC

Information Element/Group name	Need	Multi	Type and reference	Semantics description
				mode or compressed PC mode is applied
>>ITP	MP		Enumerated (mode 0, mode 1).	Initial Transmit Power is the uplink power control method to be used to compute the initial transmit power after the compressed mode gap.
>>CHOICE <i>UL/DL mode</i> >>>DL only	MP			Compressed made used in DI
>>>DL Offly				Compressed mode used in DL only
>>>Downlink compressed mode method	MP		Enumerated (puncturing, SF/2, higher layer scheduling)	Method for generating downlink compressed mode gap
>>>UL only			3/	Compressed mode used in UL only
>>>Uplink compressed mode method	MP		Enumerated (SF/2, higher layer scheduling)	Method for generating uplink compressed mode gap
>>>UL and DL			3,	Compressed mode used in UL and DL
>>>Downlink compressed mode method	MP		Enumerated (puncturing, SF/2, higher layer scheduling)	Method for generating downlink compressed mode gap
>>>>Uplink compressed mode method	MP		Enumerated (SF/2, higher layer scheduling)	Method for generating uplink compressed mode gap
>>Downlink frame type	MP		Enumerated (A, B)	
>>DeltaSIR1	MP		Real(03 by step of 0.1)	Delta in DL SIR target value to be set in the UE during the frame containing the start of the first transmission gap in the transmission gap pattern (without including the effect of the bit-rate increase)
>>DeltaSIRafter1	MP		Real(03 by step of 0.1)	Delta in DL SIR target value to be set in the UE one frame after the frame containing the start of the first transmission gap in the transmission gap pattern.
>>DeltaSIR2	OP		Real(03 by step of 0.1)	Delta in DL SIR target value to be set in the UE during the frame containing the start of the second transmission gap in the transmission gap pattern (without including the effect of the bit-rate increase) When omitted, DeltaSIR2 = DeltaSIR1.
>>DeltaSIRafter2	OP		Real(03 by step of 0.1)	Delta in DL SIR target value to be set in the UE one frame after the frame containing the start of the second transmission gap in the transmission gap pattern. When omitted, DeltaSIRafter2 = DeltaSIRafter1.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
>>N Identify abort	CV-Initial BSIC		Integer(112 8)	Indicates the maximum number of repeats of patterns that the UE shall use to attempt to decode the unknown BSIC of the GSM cell in the initial BSIC identification procedure
>>T Reconfirm abort	CV-Re- confirm BSIC		Real(0.510. 0 by step of 0.5)	Indicates the maximum time allowed for the re-confirmation of the BSIC of one GSM cell in the BSIC re-confirmation procedure. The time is given in steps of 0.5 seconds.

Condition	Explanation
Active	This IE is mandatory present when the value of the IE "TGPS Status Flag" is "Activate" and not needed otherwise.
Initial BSIC	This IE is mandatory present when the value of the IE "TGMP" is set to "GSM Initial BSIC identification" and not needed otherwise.
Re-confirm BSIC	This IE is mandatory present when the value of the IE "TGMP" is set to "GSM BSIC re-confirmation" and not needed otherwise.

10.3.6.34 DPCH Compressed Mode Status Info

This information element indicates status information of the compressed mode used by the UE in order to perform interfrequency and inter-RAT measurements.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
TGPS reconfiguration CFN	MP		Integer (0255)	
Transmission gap pattern sequence	MP	1 to <maxtgp S></maxtgp 		
>TGPSI	MP		TGPSI 10.3.6.82	Transmission Gap Pattern Sequence Identifier
>TGPS Status Flag	MP		Enumerated(activate, deactivate)	This flag indicates whether the Transmission Gap Pattern Sequence it shall be activated or deactivated.
>TGCFN	CV-Active		Integer (0255)	Connection Frame Number of the first frame of the first pattern within the Transmission Gap Pattern Sequence.

Condition	Explanation
Active	This IE is mandatory present when the value of the IE "TGPS Status Flag" is "Activate" and not needed
	otherwise.

10.3.6.35 Dynamic persistence level

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Dynamic persistence level	MP		Integer(18)	Level shall be mapped to a dynamic persistence value in the range 0 1. The mapping is described in subclause 8.5.12.

10.3.6.35a FPACH info

NOTE: Only for 1.28 Mcps TDD.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Timeslot number	MP		Integer(06)		REL-4
Channelisation code	MP		Enumerated((16/1)(16/1 6)		REL-4
Midamble Shift and burst type	MP		Midamble shift and burst type 10.3.6.41		REL-4
WT	MP		Integer(14)	The number of sub-frames, following the sub-frame in which the SYNC UL is transmitted, in which the FPACH can be transmitted.	REL-4

10.3.6.36 Frequency info

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE mode	MP			
>FDD				
>>UARFCN uplink (Nu)	OP		Integer(016 383)	If this IE is not present, the default duplex distance defined for the operating frequency band shall be used [21]
>>UARFCN downlink (Nd)	MP		Integer(0 16383)	[21]
>TDD				
>>UARFCN (Nt)	MP		Integer(0 16383)	[22]

10.3.6.3600 HS-PDSCH Midamble Configuration

NOTE: Only for TDD 1.28 Mcps.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Midamble Allocation Mode	МР		Enumerated(Default midamble, Common midamble, UE specific midamble)	This midamble allocation mode applies to all HS-PDSCH resources assigned to the UE.	REL-5
Midamble Configuration	MP		Integer(2, 4, 6, 8, 10, 12, 14, 16)	This configuration applies to all HS-PDSCH resources assigned to the UE.	REL-5
Midamble Shift	CV-UE		Integer(015	This shift, when present, applies to all HS-PDSCH resources assigned to the UE.	REL-5

Condition	Explanation
UE	This IE is mandatory present when the value of the IE
	"Midamble Allocation Mode" is "UE specific midamble"
	and not needed otherwise.

10.3.6.360 HS-PDSCH Timeslot Configuration

NOTE: Only for TDD 3.84 Mcps.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
HS-PDSCH Timeslot Configuration List	MP	1 to <maxts- 2></maxts- 			REL-5
>Timeslot Number	MP		Integer (014)		REL-5
>CHOICE Burst Type	MP				REL-5
>>Type 1					REL-5
>>>Midamble Allocation Mode	MP		Enumerated (Default midamble, Common midamble, UE specific midamble)		REL-5
>>>Midamble configuration burst type 1 and 3	MP		Integer (4, 8, 16)	As defined in [30]	REL-5
>>>Midamble Shift	CV-UE		Integer (015)		REL-5
>>Type 2					REL-5
>>>Midamble Allocation Mode	MP		Enumerated (Default midamble, Common midamble, UE specific midamble)		REL-5
>>>Midamble configuration burst type 2	MP		Integer (3, 6)	As defined in [30]	REL-5
>>>Midamble Shift	CV-UE		Integer (05)		REL-5

Condition	Explanation
UE	This IE is mandatory present when the value of the IE "Midamble Allocation Mode" is "UE specific midamble" and not needed otherwise.

10.3.6.36a HS-SCCH Info

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
CHOICE mode	MP				REL-5
>FDD					REL-5
>>DL Scrambling Code	MD		Secondary scrambling code 10.3.6.74	DL Scrambling code to be applied for HS-DSCH and HS-SCCH. Default is same scrambling code as for the primary CPICH.	REL-5
>>HS-SCCH Channelisation Code Information	MP	1 to <maxhss CCHcodes</maxhss 			REL-5
		>			
>>>HS-SCCH Channelisation Code	MP		Integer (0127)		REL-5
>TDD					REL-5
>>CHOICE TDD option	MP				REL-5
>>>3.84 Mcps					REL-5
>>> Ack-Nack Power Offset	MP		Integer (-78 by step of 1)	dB	REL-5
>>>> HS-SICH Power Control Info	MP		HS-SICH Power Control Info 10.3.6.36b		REL-5
>>>HS-SCCH Set Configuration	MP	1 to <maxhs- SCCHs></maxhs- 			REL-5
>>>>Timeslot number	MP		Integer (014)		REL-5
>>>>Channelisation code	MP		Enumerated ((16/1) (16/16))		REL-5
>>>>Midamble Allocation mode	MP		Enumerated (Default midamble, Common midamble, UE specific midamble)	HS-SCCH always uses burst type 1.	REL-5
>>>>Midamble configuration	MP		Integer (4, 8, 16)		REL-5
>>>>Midamble Shift	CV-UE		Integer(015		REL-5
>>>>BLER target	MP		Real (-3.150 by step of 0.05)	Signalled value is Log10(HS- SCCH BLER quality target)	REL-5
>>>>HS-SICH configuration				, , , , , , , , , , , , , , , , , , ,	REL-5
>>>>>Timeslot number	MP		Integer (014)		REL-5
>>>>>Channelisation code	MP		Enumerated ((16/1)(16/16))		REL-5
>>>>>Midamble Allocation mode	MP		Enumerated (Default midamble, UE specific midamble)	HS-SICH always uses burst type 1.	REL-5
>>>>>Midamble configuration	MP		Integer		REL-5

			(4, 8, 16)		
>>>>Midamble Shift	CV-UE		Integer (015)		REL-5
>>>1.28 Mcps					REL-5
>>>HS-SCCH Set	MP	1 to			REL-5
Configuration		<maxhs- SCCHs></maxhs- 			
>>>>Timeslot number	MP		Integer (06)		REL-5
>>>>First Channelisation code	MP		Enumerated ((16/1)(16/16))		REL-5
>>>>Second Channelisation code	MP		Enumerated ((16/1)(16/16))		REL-5
>>>>Midamble Allocation mode	MP		Enumerated (Default midamble, Common midamble, UE specific midamble)		REL-5
>>>> Midamble Shift	CV-UE		Integer (015)		REL-5
>>>>Midamble configuration	MP		Integer (2, 4, 6, 8, 10, 12, 14, 16)		REL-5
>>>>BLER target	MP		Real (-3.150 by step of 0.05)	Signalled value is Log10(HS-SCCH BLER quality target)	REL-5
>>>>HS-SICH configuration				,	REL-5
>>>>Timeslot number	MP		Integer (06)		REL-5
>>>> Channelisation code	MP		Enumerated ((16/1)(16/16))		REL-5
>>>>Midamble Allocation mode	MP		Enumerated (Default midamble, UE specific midamble)		REL-5
>>>>>Midamble configuration	MP		Integer (2, 4, 6, 8, 10, 12, 14, 16)		REL-5
>>>>Midamble Shift	CV-UE		Integer (015)		REL-5
>>>>Ack-Nack Power Offset	MP		Integer (-78 by step of 1)	dB.	REL-5
>>>>PRX _{HS-SICH}	MP		Integer (-12058 by step of 1)	dBm. Desired power level for HS-SICH.	REL-5
>>>>TPC step size	MP		Integer (1, 2, 3)	dB.	REL-5

Condition		Explanation
U	E	This IE is mandatory present when the value of the IE
		"Midamble Allocation Mode" is "UE specific midamble"
		and not needed otherwise.

10.3.6.36b HS-SICH Power Control Info

This IE is used to transfer HS-SICH power control info to the UE and only applies to TDD 3.84 Mcps.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
UL target SIR	MP		Real (-1120 by step of 0.5)	dB	REL-5
HS-SICH Constant value	MP		Constant value TDD 10.3.6.11a		REL-5

10.3.6.37 Individual timeslot info

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Timeslot number	MP		Timeslot number 10.3.6.84	Timeslot within a frame	
TFCI existence	MP		Boolean	TRUE indicates that the TFCI exists. It shall be coded in the physical channel defined in [30] of this timeslot.	
Midamble Shift and burst type	MP		Midamble shift and burst type 10.3.6.41		
CHOICE TDD option	MP				REL-4
>3.84 Mcps TDD				(no data)	REL-4
>1.28 Mcps TDD					REL-4
>>Modulation	MP		Enumerated(QPSK, 8PSK)		REL-4
>>SS-TPC Symbols	MP		Enumerated(0, 1, 16/SF)	Denotes amount of SS and TPC bits send in this timeslot	REL-4
>>Additional TPC-SS Symbols	OP		Integer(115	Specifies the number of additional codes in this timeslot that carry TPC and SS symbols as specified in [33]	REL-4

10.3.6.38 Individual Timeslot interference

Parameters used by the UE for uplink open loop power control in TDD.

Information element	Need	Multi	Type and reference	Semantics description
Timeslot number	MP		Timeslot	
			number	
			10.3.6.84	
UL Timeslot Interference	MP		UL	
			Interference	
			TDD	
			10.3.6.87a	

10.3.6.39 Maximum allowed UL TX power

This information element indicates the maximum allowed uplink transmit power.

Information Element	Need	Multi	Type and reference	Semantics description
Maximum allowed UL TX power	MP		Integer(- 5033)	In dBm

10.3.6.40 Void

10.3.6.40a Measurement Feedback Info

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			reference	description	
CHOICE mode	MP				REL-5
>FDD					REL-5
>>Measurement Power Offset	MP		Real (-6 13 by step of 0.5)	The measurement power offset, Γ , in dB, as described in [29].	REL-5
>>CQI Feedback cycle, k	MP		Integer (0, 2, 4, 8, 10, 20, 40, 80, 160)	In milliseconds.	REL-5
>>CQI repetition factor	MP		Integer (14)		REL-5
>>Δ _{CQI}	MP		Integer (08)	Refer to quantization of the power offset in [28]	REL-5
>TDD				(no data)	REL-5

10.3.6.41 Midamble shift and burst type

NOTE: Only for TDD.

This information element indicates burst type and midamble allocation. Three different midamble allocation schemes exist:

- Default midamble: the midamble shift is selected by layer 1 depending on the associated channelisation code (DL and UL)
- Common midamble: the midamble shift is chosen by layer 1 depending on the number of channelisation codes (possible in DL only)
- UE specific midamble: a UE specific midamble is explicitly assigned (DL and UL).

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
CHOICE TDD option	MP				REL-4
>3.84 Mcps TDD					REL-4
>>CHOICE Burst Type	MP				
>>>Type 1					
>>>Midamble Allocation Mode	MP		Enumerated (Default midamble, Common midamble, UE specific		

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
			midamble)		
>>>Midamble configuration burst type 1 and 3	MP		Integer(4, 8, 16)	As defined in [30]	
>>>>Midamble Shift	CV-UE		Integer(015		
>>>Type 2			,		
>>>Midamble Allocation Mode	MP		Enumerated (Default midamble, Common midamble, UE specific midamble)		
>>>Midamble configuration burst type 2	MP		Integer(3, 6)	As defined in [30]	
>>>Midamble Shift	CV-UE		Integer(05)		
>>>Type 3			9 \ /		
>>>>Midamble Allocation Mode	MP		Enumerated (Default midamble, UE specific midamble)		
>>>>Midamble configuration burst type 1 and 3	MP		Integer(4, 8, 16)	As defined in [30]	
>>>>Midamble Shift	CV-UE		Integer (015)	NOTE: Burst Type 3 is only used in uplink.	
>1.28 Mcps TDD					REL-4
>>Midamble Allocation Mode	MP		Enumerated (Default midamble, Common midamble, UE specific midamble)		REL-4
>>Midamble configuration	MP		Integer(2, 4, 6, 8, 10, 12, 14, 16)	As defined in [30]	REL-4
>>Midamble Shift	CV-UE		Integer (015)		REL-4

Condition	Explanation		
UE	This IE is mandatory present when the value of the IE		
	"Midamble Allocation Mode" is "UE-specific		
	midamble" and not needed otherwise.		

10.3.6.42 PDSCH Capacity Allocation info

NOTE: Only for TDD.

Information Element/Group	Need	Multi	Type and reference	Semantics description
PDSCH allocation period info	MP		Allocation	
FD3CIT allocation period into	IVIE		Period Info	
			10.3.6.4	
CHOICE Configuration	MP		10.0.0.1	
>Old configuration				
>>TFCS ID	MD		Integer(18)	Default is 1.
>>PDSCH Identity	MP		Integer(1hi	
			PDSCHident	
			ities)	
>New configuration				
>>PDSCH Info	MP		PDSCH Info	
			10.3.6.44	
>>PDSCH Identity	OP		Integer(1hi	
			PDSCHident	
			ities)	
>>PDSCH power control info	OP		PDSCH	
			power	
			control info	
			10.3.6.45	

10.3.6.43 PDSCH code mapping

NOTE: Only for FDD.

This IE indicates the association between each possible value of TFCI(field 2) and the corresponding PDSCH channelisation code(s). The following signalling methods are specified:

- 'code range': the mapping is described in terms of a number of groups, each group associated with a given spreading factor;
- 'TFCI range': the mapping is described in terms of a number of groups, each group corresponding to a given PDSCH channelisation code;
- 'Explicit': the mapping between TFCI(field 2) value and PDSCH channelisation code is spelt out explicitly for each value of TFCI (field2);
- 'Removal': replace individual entries in the TFCI(field 2) to PDSCH code mapping table with new PDSCH code values.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
DL Scrambling Code	MD		Secondary scrambling code 10.3.6.74	Scrambling code on which PDSCH is transmitted. Default is the same scrambling code as for the Primary CPICH
Choice signalling method	MP			
>code range				
>>PDSCH code mapping	MP	1 to < maxPDSC H- TFCIgroup s >		
>>>Spreading factor	MP		Integer(4, 8, 16, 32, 64, 128, 256)	
>>>multi-code info	MP		Integer(116	
>>>Code number (for PDSCH code) start	MP		Integer(0Sp reading factor-1)	
>>>Code number (for PDSCH code) stop	MP		Integer(0Sp reading	

Information Element/Group name	Need	Multi	Type and reference	Semantics description
			factor-1)	
>TFCI range				
>>DSCH mapping	MP	1 to < maxPDSC H- TFCIgroup s >		
>>>Max TFCI(field2) value	MP		Integer(110 23)	This is the maximum value in the range of TFCI(field 2) values for which the specified PDSCH code applies
>>>Spreading factor (for PDSCH code)	MP		Integer(4, 8, 16, 32, 64, 128, 256)	
>>>Code number (for PDSCH code)	MP		Integer(0Sp reading factor-1)	
>>>multi-code info	MP		Integer(116	
>Explicit				
>>PDSCH code info	MP	1 to < maxTFCI- 2-Combs >		The first instance of the parameter <i>PDSCH code</i> corresponds to TFCI (field2) = 0, the second to TFCI(field 2) = 1 and so on.
>>>Spreading factor (for PDSCH code)	MP		Integer(4, 8, 16, 32, 64, 128, 256)	
>>>Code number (for PDSCH code)	MP		Integer(0Sp reading factor-1)	
>>>multi-code info	MP		Integer(116	
>Replace				This choice is made if the PDSCH code(s) associated with a given value of TFCI(field 2) is to be replaced.
>>Replaced PDSCH code	MP	1 to < maxTFCI- 2-Combs >		Identity of the PDSCH code(s) to be used for the specified value of TFCI(field 2). These code identity(s) replace any that had been specified before
>>>TFCI (field 2)	MP		Integer (01023)	Value of TFCI(field 2) for which PDSCH code mapping will be changed
>>>Spreading factor (for PDSCH code)	MP		Integer(4, 8, 16, 32, 64, 128, 256)	
>>>Code number (for PDSCH code)	MP		Integer(0Sp reading factor-1)	
>>>multi-code info	MP		Integer(116	

10.3.6.44 PDSCH info

NOTE: Only for TDD.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
TFCS ID	MD		Integer(18)	TFCS to be used. Default value is 1.
Common timeslot info	OP		Common timeslot info 10.3.6.10	
PDSCH timeslots and codes	OP		Downlink Timeslots and Codes 10.3.6.32	Default is to use the old timeslots and codes.

10.3.6.45 PDSCH Power Control info

NOTE: Only for TDD.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
TPC Step Size	OP		Integer (1, 2, 3)	In dB
UL CCTrCH TPC List	OP	1 <maxcc TrCH></maxcc 		UL CCTrCH identities for TPC commands associated with this DL CCTrCH. This list is not used in 1.28 Mcps TDD.
>UL TPC TFCS Identity	MP		Transport Format Combination Set Identity 10.3.5.21	

10.3.6.46 PDSCH system information

NOTE: Only for TDD.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
PDSCH information	MP	1 to <maxpd SCH></maxpd 	reference		
>PDSCH Identity	MP		Integer(1 hiPDSCHi dentities)		
>PDSCH info	MP		PDSCH info 10.3.6.44		
>SFN Time Info	CH- Block17		SFN Time Info 10.3.6.75		
>DSCH TFS	OP		Transport format set 10.3.5.23		
>DSCH Transport Channels	OP	1 to <maxtr CH></maxtr 		If PDSCH is configured for 3.84Mcps TDD in Rel-5 this IE may be included.	REL-5
>> DSCH Transport channel identity	MP		Transport channel identity 10.3.5.18		REL-5
>>DSCH TFS	MP		Transport format set 10.3.5.23		REL-5
>DSCH TFCS	OP		Transport Format Combinati on Set 10.3.5.20		

Condition	Explanation		
Block17	This IE is not needed in System Information Block 17.		
	Otherwise it is optional.		

10.3.6.47 PDSCH with SHO DCH Info

NOTE: Only for FDD

Information Element/Group name	Need	Multi	Type and reference	Semantics description
DSCH radio link identifier	MP		Primary CPICH info 10.3.6.60	This parameter indicates on which radio link the user will be allocated resource on the DSCH.
TFCI(field2) Combining set	ОР	1 to <maxrl></maxrl>		This is used to indicate which of the downlink TFCI(field 2) transmissions made on the DPCCHs within the active set should be soft combined on the physical layer. This parameter may only be sent if there is a 'hard' split of the TFCI field and in this case the sending of the parameter is optional.
>Radio link identifier	MP		Primary CPICH info 10.3.6.60	

10.3.6.48 Persistence scaling factors

This IE defines scaling factors associated with ASC 2 – ASC 7 to be applied to the dynamic persistence value.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Access Service Class	MP	1 to maxASCpe rsist		multiplicity corresponds to the number of PRACH partitions minus 2
>Persistence scaling factor	MP		Real(0.90.2 , by step of 0.1)	Scaling factors in the range 0,,1

10.3.6.49 PICH Info

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
CHOICE mode	MP			•	
>FDD					
>>Channelisation code	MP		Integer(025 5)	SF is fixed and equal to 256	
>>Number of PI per frame	MP		Integer (18, 36, 72, 144)		
>>STTD indicator	MP		STTD Indicator 10.3.6.78		
>TDD					
>>Timeslot number	MD		Timeslot number 10.3.6.84	Default value is the timeslot used by the SCCPCH carrying the associated PCH.	
>>Midamble shift and burst type	MP		Midamble shift and burst type 10.3.6.41		
>>CHOICE TDD option	MP				REL-4
>>>3.84 Mcps TDD					REL-4
>>>>Channelisation code	MD		Enumerated ((16/1)(16/1 6))	Default value is the channelisation code used by the SCCPCH carrying the associated PCH.	
>>>1.28 Mcps TDD					REL-4
>>>Codes list	MP	12			REL-4
>>>>Channelisation code	MP		Enumerated ((16/1)(16/1 6))		REL-4
>>Repetition period/length	MD		Enumerated((4/2),(8/2), (8/4),(16/2), (16/4), (32/2),(32/4), (64/2),(64/4))	Default value is "(64/2)".	
>>Offset	MP		Integer (0Repetitio n period -1)	SFN mod Repetitionperiod = Offset.	
>>Paging indicator length	MD		Integer (4, 8, 16)	Indicates the length of one paging indicator in Bits. Default value is 4.	
>>N _{GAP}	MD		Integer(2, 4,	Number of frames	

N.	MD	8)	between the last frame carrying PICH for this Paging Occasion and the first frame carrying paging messages for this Paging Occasion. Default value is 4.	
>>N _{PCH}	MD	Integer(1 8)	Number of paging groups. Default value is 2.	

10.3.6.50 PICH Power offset

This is the power transmitted on the PICH minus power of the Primary CPICH in FDD and Primary CCPCH Tx Power in TDD.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
PICH Power offset	MP		Integer(-10	Offset in dB
			+5)	

10.3.6.51 PRACH Channelisation Code List

NOTE: Only for 3.84 Mcps TDD.

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			reference	description	
CHOICE SF	MP				
>SF16					
>>Channelisation Code List	MP	1 to 8			
>>>Channelisation code	MP		Enumerated ((16/1)(16/16))	There is a 1:1 mapping between spreading code and midamble shift defined in [30] for channelisation codes (16/1) to (16/8). NOTE: channelisation codes (16/9) to (16/16) are not to be used.	
>SF8					
>>Channelisation Code List	MP	1 to 8			
>>>Channelisation Code	MP		Enumerated((8/1)(8/8))		

10.3.6.51a PRACH Channelisation Code 1.28 Mcps TDD

NOTE: Only for 1.28 Mcps TDD.

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			reference	description	
Channelisation Code List	MP	1 to 4			REL-4

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
>Channelisation Code	MP		Enumerated((4/1)(4/4),(8		REL-4
			/1)(8/8),(16/ 1)(16/16))		

10.3.6.52 PRACH info (for RACH)

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
CHOICE mode	MP				
>FDD					
>>Available Signature	MP		Bit string(16)	Each bit indicates availability for a signature, where the signatures are numbered "signature 0" up to "signature 15". The value 1 of a bit indicates that the corresponding signature is available and the value 0 that it is not available.	
>>Available SF	MP		Integer (32,64,128,2 56)	In chips per symbol Defines the minimum allowed SF (i.e. the maximum rate)	
>>Preamble scrambling code number	MP		Integer (0 15)	Identification of scrambling code see [28]	
>>Puncturing Limit	MP		Real(0.401. 00 by step of 0.04)		
>>Available Sub Channel Number	MP		Bit string(12)	Each bit indicates availability for a subchannel, where the subchannels are numbered "subchannel 0" to "subchannel 11". The value 1 of a bit indicates that the corresponding subchannel is available and the value 0 indicates that it is not available.	
>TDD	MD				DEL 4
>>CHOICE TDD option	MP				REL-4
>>>3.84 Mcps TDD >>>>Timeslot number	MP		Timeslot number 10.3.6.84		REL-4
>>>PRACH Channelisation Code List	MP		PRACH Channelisati on Code List 10.3.6.51		
>>>>PRACH Midamble	MP		Enumerated	Direct or direct	

			(Direct, Direct/Invert ed)	and inverted midamble are used for PRACH	
>>>PNBSCH allocation	OP		PNBSCH allocation 10.3.8.10a	Identifies frames used for cell synchronisation purposes	REL-4
>>>1.28 Mcps TDD					REL-4
>>>SYNC_UL info	MP		SYNC_UL info 10.3.6.78a		REL-4
>>>PRACH Definition	MP	1 <maxpr ACH_FPA CH></maxpr 			REL-4
>>>>Timeslot number	MP		Timeslot number 10.3.6.84		REL-4
>>>>PRACH Channelisation Code	MP		PRACH Channelisati on Code 1.28 Mcps TDD 10.3.6.51a		REL-4
>>>>Midamble Shift and burst type	MP		Midamble shift and burst type 10.3.6.41		REL-4
>>>>FPACH info	MP		FPACH info 10.3.6.35a		REL-4

10.3.6.53 PRACH partitioning

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Access Service class	MP	1 to maxASC		If only "NumASC+1" (with, NumASC+1 < maxASC) ASCs are listed, the remaining (NumASC+2 through maxASC) ASCs are unspecified.
>ASC Setting	MD		ASC setting 10.3.6.6	The default values are same as the previous ASC. If the "default" is used for the first ASC, the default values are all available signatures and "all available subchannels" for FDD and "all available channelisation codes" and "all available subchannels" with "subchannel size=Size 1" in TDD.

10.3.6.54 PRACH power offset

NOTE: Only for FDD.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Power Ramp Step	MP		Integer (18)	Power step when no acquisition indicator is received in dB
Preamble Retrans Max	MP		Integer (164)	Maximum number of preambles in one preamble ramping cycle

10.3.6.55 PRACH system information list

Information element	Need	Multi	Type and reference	Semantics description
PRACH system information	MP	1 <maxpra CH></maxpra 		
>PRACH info	MP		PRACH info (for RACH) 10.3.6.52	
>Transport channel identity	MP		Transport channel identity 10.3.5.18	
>RACH TFS	MD		Transport format set 10.3.5.23	Default value is the value of "RACH TFS" for the previous PRACH in the list NOTE: The first occurrence is then MP). NOTE: For TDD in this release there is a single TF within the RACH TFS.
>RACH TFCS	MD		Transport Format Combination Set 10.3.5.20	Default value is the value of "RACH TFCS" for the previous PRACH in the list. NOTE: The first occurrence is then MP). NOTE: For TDD in this release there is no TFCS required.
>PRACH partitioning	MD		PRACH partitioning 10.3.6.53	Default value is the value of "PRACH partitioning" for the previous PRACH in the list (note: the first occurrence is then MP)
>Persistence scaling factors	OP		Persistence scaling factors 10.3.6.48	This IE shall not be present if only ASC 0 and ASC 1 are defined. If this IE is absent, value is the value of "Persistence scaling factors" for the previous PRACH in the list if value exists
>AC-to-ASC mapping	CV-SIB5- MD		AC-to-ASC mapping 10.3.6.1	Only present in SIB 5. Default value is the value of "AC-to-ASC mapping" for the previous PRACH in the list. NOTE: The first occurrence is then MP in SIB5.
>CHOICE mode	MP			
>>FDD >>>Primary CPICH TX power	MD		Primary CPICH TX power 10.3.6.61	Default value is the value of "Primary CPICH TX power" for the previous PRACH in the list. NOTE: The first occurrence is then MP.
>>>Constant value	MD	1	Constant	Default value is the value of

Information element	Need	Multi	Type and reference	Semantics description
			value 10.3.6.11	"Constant value" for the previous PRACH in the list. NOTE: The first occurrence is then MP.
>>>PRACH power offset	MD		PRACH power offset 10.3.6.54	Default value is the value of "PRACH power offset" for the previous PRACH in the list. NOTE: The first occurrence is then MP.
>>>RACH transmission parameters	MD		RACH transmission parameters 10.3.6.67	Default value is the value of "RACH transmission parameters" for the previous PRACH in the list. NOTE: The first occurrence is then MP.
>>>AICH info	MD		AICH info 10.3.6.2	Default value is the value of "AICH info" for the previous PRACH in the list. NOTE: The first occurrence is then MP.
>>TDD				(no data)

Condition	Explanation
SIB5-MD	The information element is present only in SIB 5 and in
	SIB 5 it is mandatory with default.

NOTE: If the setting of the PRACH information results in that a combination of a signature, preamble scrambling code and subchannel corresponds to a RACH with different TFS and/or TFCS, then for that combination only the TFS/TFCS of the PRACH listed first is valid, where PRACHs listed in System Information Block type 5 shall be counted first.

10.3.6.56 Predefined PhyCH configuration

This information element concerns a pre-defined configuration of physical channel parameters.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
Uplink radio resources				
Uplink DPCH info	MP		Uplink DPCH info Pre 10.3.6.90	
Downlink radio resources				
Downlink information common for all radio links	OP		Downlink information common for all radio links Pre 10.3.6.26	

10.3.6.57 Primary CCPCH info

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			reference	description	
CHOICE mode	MP				
>FDD					
>>TX Diversity indicator	MP		Boolean	TRUE indicates that transmit diversity is used.	
>TDD					
>>CHOICE TDD option	MP				REL-4

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			reference	description	
>>>3.84 Mcps TDD					REL-4
>>>>CHOICE SyncCase	OP				
>>>>Sync Case 1					
>>>>Timeslot	MP		Integer (014)	PCCPCH timeslot	
>>>>Sync Case 2					
>>>>Timeslot	MP		Integer(06)		
>>>1.28 Mcps TDD			-		REL-4
>>>TSTD indicator	MP		TSTD indicator 10.3.6.85a		REL-4
>>Cell parameters ID	ОР		Cell parameters Id 10.3.6.9	The Cell parameters ID is described in [32].	
>>SCTD indicator	MP		SCTD indicator 10.3.6.70a		

10.3.6.58 Primary CCPCH info post

NOTE: Only for TDD

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
CHOICE TDD option	MP			•	REL-4
>3.84 Mcps TDD					REL-4
>>CHOICE SyncCase	MP				
>>>Sync Case 1					
>>>>Timeslot	MP		Integer (014)	PCCPCH timeslot	
>>>Sync Case 2					
>>>>Timeslot	MP		Integer(06)		
>1.28 Mcps TDD					REL-4
>>TSTD indicator	MP		TSTD		REL-4
			indicator 10.3.6.85a		
Cell parameters ID	MP		Cell	The Cell	
·			parameters	parameters ID is	
			ld 10.3.6.9	described in [32].	
SCTD indicator	MP		SCTD		
			indicator		
			10.3.6.70a		

10.3.6.59 Primary CCPCH TX Power

NOTE: Only for TDD.

Information Element/group	Need	Multi	Type and	Semantics description
name			reference	
Primary CCPCH Tx Power	MP		Integer(643	In dBm
)	

10.3.6.60 Primary CPICH info

NOTE: Only for FDD.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Primary scrambling code	MP		Integer(051	
			1)	

10.3.6.61 Primary CPICH Tx power

NOTE: Only for FDD.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Primary CPICH Tx Power	MP		Integer(- 1050)	Power in dBm.

10.3.6.62 Primary CPICH usage for channel estimation

NOTE: Only for FDD.

Information Element/Group	Need	Multi	Type and	Semantics description
name			Reference	
Primary CPICH usage for	MP		Enumerated(
channel estimation			Primary	
			CPICH may	
			be used,	
			Primary	
			CPICH shall	
			not be used)	

10.3.6.63 PUSCH info

NOTE: Only for TDD.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
TFCS ID	MD		Integer(18)	Default value is 1
Common timeslot info	OP		Common	
			timeslot info	
			10.3.6.10	
PUSCH timeslots and codes	OP		Uplink	
			Timeslots	
			and Codes	
			10.3.6.94	

10.3.6.64 PUSCH Capacity Allocation info

NOTE: Only for TDD.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE PUSCH allocation	MP			
>PUSCH allocation pending				(no data)
>PUSCH allocation assignment				
>>PUSCH allocation period info	MP		Allocation Period Info 10.3.6.4	
>>PUSCH power control info	OP		PUSCH power control info 10.3.6.65	
>>CHOICE Configuration	MP			
>>>Old configuration				
>>>>TFCS ID	MD		Integer(18)	Default is 1.
>>>PUSCH Identity	MP		Integer(1hi PUSCHident ities)	
>>>New configuration				
>>>PUSCH info	MP		PUSCH info 10.3.6.63	
>>>PUSCH Identity	OP		Integer(1 hiPUSCHide ntities)	

10.3.6.65 PUSCH power control info

NOTE: Only for TDD.

Interference level measured for a frequency at the UTRAN access point used by UE to set PUSCH output power.

Information Element/Group	Need	Multi	Type and reference	Semantics	Version
name				description	
UL target SIR	MP		Real (-11		
			20 by step of	For 1.28 Mcps	REL-4
			0.5 dB)	TDD this	
				parameter	
				represents	
				PRXPUSCHdes	
				with range	
				Integer(-12058	
				by step of 1) dBm	
OLIGIOE TDD - mti- m	MD			by step or 1) dBill	DEL 4
CHOICE TDD option	MP				REL-4
>3.84 Mcps TDD				(no data)	REL-4
>1.28 Mcps TDD					REL-4
>>TPC Step Size	OP		Integer	In dB	REL-4
			(1, 2, 3)		

10.3.6.66 PUSCH system information

NOTE: Only for TDD.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
PUSCH information	MP	1 to <maxpu SCH></maxpu 			
>PUSCH Identity	MP		Integer(1 hiPUSCHi		

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Liement of our name			dentities)		
>PUSCH info	MP		PUSCH		
7 0301111110	IVII		info		
			10.3.6.63		
>SFN Time Info	CH-		SFN Time		
	Block17		Info		
	BIOCKTI		10.3.6.75		
>USCH TFS	OP		Transport		
			format set		
			10.3.5.23		
>USCH Transport Channels	OP	1 to <maxtr CH></maxtr 		If PUSCH is configured for 3.84 Mcps TDD in Rel-5 this IE may be included.	REL-5
>> USCH Transport channel identity	MP		Transport channel identity 10.3.5.18		REL-5
>>USCH TFS	MP		Transport format set 10.3.5.23		REL-5
>USCH TFCS	OP		Transport Format Combinati on Set 10.3.5.20		

Condition	Explanation		
Block17	This IE is not needed in System Information Block 17.		
	Otherwise it is optional.		

10.3.6.67 RACH transmission parameters

NOTE: Only for FDD.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Mmax	MP		Integer(132	Maximum number of preamble cycles
NB01min	MP		Integer(050	Sets lower bound for random back-off
NB01max	MP		Integer(050	Sets upper bound for random back-off

10.3.6.68 Radio link addition information

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			reference	description	
Primary CPICH info	MP		Primary		
			CPICH info		
			10.3.6.60		
Cell ID	OP		Cell ID		REL-4
			10.3.2.2		
Downlink DPCH info for each RL	MP		Downlink		
			DPCH info		
			for each RL		
			10.3.6.21		
TFCI combining indicator	MP		TFCI		
			combining		
			indicator		
			10.3.6.81		

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			reference	description	
SCCPCH Information for FACH	OP		SCCPCH	Note 1	
			Information		
			for FACH		
			10.3.6.70		

NOTE 1: These IEs are present when the UE needs to listen to system information on FACH in CELL_DCH state.

10.3.6.69 Radio link removal information

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Primary CPICH info	MP		Primary	
			CPICH info	
			10.3.6.60	

10.3.6.70 SCCPCH Information for FACH

Information Element/Group	Need	Multi	Type and reference	Semantics description
name	MP			
Secondary CCPCH info	IVIP		Secondary CCPCH info	
TEOO	MD		10.3.6.71	F FAOU
TFCS	MP		Transport	For FACHs and PCH
			format	
			combination	
EAGU/DOLL: (145		set 10.3.5.20	
FACH/PCH information	MP	1 to		
		<maxfac< td=""><td></td><td></td></maxfac<>		
		HPCH>		
>TFS	MP		Transport	For each FACHs and PCH
			format set	
			10.3.5.23	
>Transport channel identity	MP		Transport	
			channel	
			identity	
			10.3.5.18	
>CTCH indicator	MP		Boolean	The value "TRUE" indicates
				that a CTCH is mapped on the
				FACH, and "FALSE" that no
				CTCH is mapped.
CHOICE mode				
>FDD				
>>References to system	MP	1 to		
information blocks		<maxsib-< td=""><td></td><td></td></maxsib-<>		
		FACH>		
>>>Scheduling information	MP		Scheduling	
			information	
			10.3.8.16	
>>>SIB type SIBs only	MP		SIB Type	
] ,			SIBs only,	
			10.3.8.22	
>TDD				(No data)

NOTE: TFS for PCH shall be the first "FACH/PCH information" in the list if a PCH exists for the respective secondary CCPCH.

10.3.6.70a SCTD indicator

NOTE: Only for TDD

Information Element/Group name	Need	Multi	Type and reference	Semantics description
SCTD indicator	MP		Boolean	TRUE indicates that SCTD is
				used

10.3.6.71 Secondary CCPCH info

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE mode	MP		101010100	
>FDD				
>>Secondary scrambling code	OP		Secondary scrambling code 10.3.6.74	May only be sent for SCCPCH channels not carrying the PCH.
>>STTD indicator	MD		STTD Indicator 10.3.6.78	Default value is "TRUE"
>>Spreading factor	MP		Integer(4, 8, 16, 32, 64, 128, 256)	
>>Code number	MP		Integer(0Sp reading factor - 1)	
>>Pilot symbol existence	MD		Boolean	TRUE means the existence. Default value is "TRUE"
>>TFCI existence	MD		Boolean	TRUE indicates that TFCI is used. When spreading factor is less than or equal to 64, FALSE indicates that TFCI is not used and therefore DTX is used in the TFCI field. Default value is "TRUE"
>>Fixed or Flexible Position	MD		Enumerated (Fixed, Flexible)	Default value is "Flexible"
>>Timing Offset	MD		Integer(038 144 by step of 256)	Chip Delay of the Secondary CCPCH relative to the Primary CCPCH. Default value is 0.
>TDD				
>>Offset	MP		Integer (0Repetitio n Period -1)	SFN modulo Repetition period = offset. Repetition period is the one indicated in the accompanying Common timeslot info IE
>>Common timeslot info	MP		Common timeslot info 10.3.6.10	
>>Individual timeslot info	MP		Individual timeslot info 10.3.6.37	
>>Code List	MP	1 to 16		
>>>Channelisation Code	MP		Enumerated((16/1)(16/1 6))	

10.3.6.72 Secondary CCPCH system information

Information element	Need	Multi	Type and reference	Semantics description	
Secondary CCPCH system information	MP	1 to <maxscc PCH></maxscc 			
>Secondary CCPCH info	MP		Secondary CCPCH info 10.3.6.71	Note 1	
>TFCS	MD		Transport format combination set 10.3.5.20	For FACHs and PCH Default value is the value of "TFCS" for the previous SCCPCH in the list. NOTE: The first occurrence is then MP.	
>FACH/PCH information	MD	1 to <maxfac HPCH></maxfac 		Default value is the value of "FACH/PCH" for the previous SCCPCH in the list. NOTE: The first occurrence is then MP.	
>>TFS	MP		Transport format set 10.3.5.23	For each FACH and PCH Note 2	
>>Transport channel identity	MP		Transport channel identity 10.3.5.18		
>>CTCH indicator	MP		Boolean	The value "TRUE" indicates that a CTCH is mapped on the FACH, and "FALSE" that no CTCH is mapped.	
>PICH info	OP		PICH info 10.3.6.49	PICH info is present only when PCH is multiplexed on Secondary CCPCH	

NOTE 1: The secondary CCPCHs carrying a PCH shall be listed first.

NOTE 2: TFS for PCH shall be the first "FACH/PCH information" in the list if a PCH exists for the respective secondary CCPCH.

10.3.6.73 Secondary CPICH info

NOTE: Only for FDD.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Secondary scrambling code	MD		Secondary scrambling code 10.3.6.74	Default is the same scrambling code as for the Primary CPICH
Channelisation code	MP		Integer(025 5)	SF=256

10.3.6.74 Secondary scrambling code

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Secondary scrambling code	MP		Integer(115	
)	

10.3.6.75 SFN Time info

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Activation time SFN	MP		Integer	System frame number start of
			(04095)	the physical channel
				existence.
Duration	MP		Integer(140	Total number of frames the
			96)	physical channel will exist.

10.3.6.75a Special Burst Scheduling

NOTE: Only for TDD.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Special Burst Generation Period	MP		Integer (2, 4, 8, 16, 32, 64,	Value in radio frames
			128, 256)	

10.3.6.76 SSDT cell identity

NOTE: Only for FDD.

This IE is used to associate a cell identity with a given radio link.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
SSDT cell id	MP		Enumerated	
			(a, b, c, d, e,	
			f, g, h)	

10.3.6.77 SSDT information

NOTE: Only for FDD.

This information element indicates the status (e.g. initiated/terminated) of the Site Selection.

Diversity Transmit power control (SSDT). It is used to change the SSDT status. The parameter 'code word set' indicates how cell identities are coded (using many bits or few, values are long, medium, or short).

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
S field	MP		Integer (1, 2)	In bits	
Code Word Set	MP		Enumerated (long, medium, shortSSDT off)		
SSDT UL	OP		Enumerated (UL, ULandDL)		REL-4

NOTE: These parameters shall be set optionally associated with DL DPCH info but not for each RL.

10.3.6.78 STTD indicator

NOTE: Only for FDD

Indicates whether STTD is used or not.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
STTD Indicator	MP		Boolean	TRUE means that STTD is
				used

10.3.6.78a SYNC_UL info

NOTE: Only for 1.28 Mcps TDD.

Information Element/ Group name	Need	Multi	Type and reference	Semantics description	Version
SYNC_UL codes bitmap	MP		Bitstring(8)	Each bit indicates availability of a SYNC_UL code, where the SYNC_UL codes are numbered "code 0" to "code 7". The value 1 of a bit indicates that the corresponding SYNC_UL code can be used. The value 0 of a bit indicates that the corresponding SYNC_UL code can be used.	REL-4
PRX _{UpPCHdes}	MP		Integer(- 12058 by step of 1)	In dBm	REL-4
Power Ramp Step	MP		Integer(0,1,2 ,3)	In dB	REL-4
Max SYNC_UL Transmissions	MP		Integer(1,2,4 ,8)	Maximum numbers of SYNC_UL transmissions in a power ramping sequence.	REL-4
Mmax	MP		Integer(132	Maximum number of synchronisation attempts.	REL-4

10.3.6.79 TDD open loop power control

This information element contains parameters for open loop power control setting for TDD.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Primary CCPCH Tx Power	MP		Primary CCPCH Tx Power 10.3.6.59	For path loss calculation	
CHOICE TDD option	MP				REL-4
>3.84 Mcps TDD					REL-4
>>Alpha	OP		Alpha 10.3.6.5		
>>PRACH Constant Value	MP		Constant Value TDD 10.3.6.11a	Operator controlled PRACH Margin	
>>DPCH Constant Value	MP		Constant	Operator	

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			reference	description	
			Value TDD	controlled UL	
			10.3.6.11a	DPCH Margin	
>>PUSCH Constant Value	OP		Constant Value TDD 10.3.6.11a	Operator controlled PUSCH Margin	
>>UE positioning related parameters	CV-IPDLs				REL-4
>>>IPDL-Alpha	MP		Alpha 10.3.6.5		REL-4
>>>Max power increase	MP		Integer (03)	In db	REL-4
>1.28 Mcps TDD				(no data)	REL-4

Condition	Explanation
IPDLs	This IE is present only if idle periods are applied

10.3.6.80 TFC Control duration

Information Element/Group name	Need	Multi	Type and reference	Semantics description
TFC Control duration	MP		Integer (1, 2, 4, 8, 16, 24, 32, 48, 64, 128, 192, 256, 512)	Defines the period in multiples of 10 ms frames for which the defined TFC sub-set is to be applied.

10.3.6.81 TFCI Combining Indicator

NOTE: Only for FDD.

This IE indicates whether the TFCI (field 2), which will be transmitted on the DPCCH of a newly added radio link, should be soft-combined with the others in the TFCI (field 2) combining set. This IE is relevant only when the UE is in CELL_DCH state with a DSCH transport channel assigned and when there is a 'hard' split in the TFCI field (such that TFCI1 and TFCI2 have their own separate block coding).

Information Element/Group name	Need	Multi	Type and reference	Semantics description
TFCI combining indicator	MP		Boolean	TRUE means that TFCI is combined, FALSE means that TFCI is not combined or that this IE is not applicable to the added radio link.

10.3.6.82 TGPSI

Information Element/Group name	Need	Multi	Type and reference	Semantics description
TGPSI	MP		Integer(1M axTGPS)	Transmission Gap Pattern Sequence Identifier Establish a reference to the compressed mode pattern sequence. Up to <maxtgps> simultaneous compressed mode pattern sequences can be used.</maxtgps>

10.3.6.83 Time info

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Activation time	MD		Activation	Frame number start of the
			time 10.3.3.1	physical channel existence.
				Default value is "Now"
Duration	MD		Integer(140	Total number of frames the
			96, infinite)	physical channel will exist.
			<u> </u>	Default value is "infinite".

10.3.6.84 Timeslot number

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
CHOICE TDD option	MP				REL-4
>3.84 Mcps TDD					REL-4
>>Timeslot number	MP		Integer(014	Timeslot within a frame	
>1.28 Mcps TDD					REL-4
>>Timeslot number	MP		Integer(06)	Timeslot within a subframe	REL-4

10.3.6.85 TPC combination index

NOTE: Only for FDD.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
TPC combination index	MP		Integer(05)	Radio links with the same index have TPC bits, which for the UE are known to be the same.

10.3.6.85a TSTD indicator

NOTE: Only for 1.28 Mcps TDD.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
TSTD indicator	MD		Boolean	Default value is "TRUE"	REL-4

10.3.6.86 TX Diversity Mode

NOTE: Only for FDD.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Tx diversity Mode	MP		Enumerated	
·			(none,	
			STTD,	
			closed loop	
			mode1,	
			closed loop	
			mode2)	

10.3.6.87 UL interference

Information Element/Group name	Need	Multi	Type and reference	Semantics description
UL interference	MP		Integer (- 11070)	In dBm

NOTE: In TDD, this IE is a timeslot specific value.

10.3.6.87a UL interference TDD

NOTE: Only for TDD.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
TDD UL interference	MP		Integer (- 11052)	In dBm

NOTE: This IE is a timeslot specific value.

10.3.6.88 Uplink DPCH info

Information	Need	Multi	Type and	Semantics description	Version
Element/Group name Uplink DPCH power	OP		reference Uplink		
control info			DPCH		
			power		
			control		
			info		
0110105	145		10.3.6.91		
CHOICE mode >FDD	MP				
>>Scrambling code type	MP		Enumerat		
			ed(short,		
			long)		
>>Scrambling code	MP		Integer(0		
number			16777215)		
>>Number of DPDCH	MD		Ínteger(1	Default value is 1.	
			maxDPD	Number of DPDCH is 1	
			CH)	in HANDOVER TO	
				UTRAN COMMAND	
>>Spreading factor	MP		Integer(4,	Minimum allowed SF of	
			8, 16, 32,	the channelisation code	
			64, 128, 256)	for data part	
>>TFCI existence	MP		Boolean	TRUE means	
				existence.	
>>Number of FBI bits	OP		Integer (1, 2)	In bits.	
>>Puncturing Limit	MP		Real(0.40		
			1 by		
			step of		
, TDD		1	0.04)		
>TDD >>Uplink Timing	OP		Uplink		
Advance Control	01		Timing		
			Advance		
			Control		
			10.3.6.96		
>>UL CCTrCH List	OP	1 to		UL physical channels to	
		<maxcc< td=""><td></td><td>establish or reconfigure</td><td></td></maxcc<>		establish or reconfigure	
>>>TFCS ID	MD	TrCH>	Integer(1	list. Default value is 1.	
			8)		
>>>UL target SIR	MP		Real (-11	In dB	
			20 by	For 1.28 Mcps TDD this	REL-4
			step of 0.5dB)	parameter represents	
			0.5db)	PRX _{DPCHdes} with	
				range Integer(-120	
>>>Time info	MP		Time info	58 by step of 1) dBm	
>> Common timestat	MD		10.3.6.83	Default in the current	
>>>Common timeslot info	MD		Common timeslot	Default is the current Common timeslot info	
			info	COMMON MINESION MINO	
			10.3.6.10		
>>>Uplink DPCH	MD		Uplink	Default is to use the old	
timeslots and codes			Timeslots	timeslots and codes.	
			and		
			Codes		
SUIL COT*OUT :-++-	OB	1	10.3.6.94	III physical sharpels (-	
>>UL CCTrCH List to Remove	OP	1 <max CCTrCH</max 		UL physical channels to remove list	
IZEIIIOVE		> CCTICH		I LEILIONE IIST	
>>>TFCS ID	MP		Integer(1		
			8)		

10.3.6.89 Uplink DPCH info Post

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Uplink DPCH power control info	MP		Uplink DPCH power control info Post 10.3.6.92	
CHOICE mode	MP			
>FDD				
>>Scrambling code type	MP		Enumerated(short, long)	
>>Reduced scrambling code number	MP		Integer(081 91)	Sub-range of values for initial use upon handover to UTRAN.
>>Spreading factor	MP		Integer(4, 8, 16, 32, 64, 128, 256)	SF of the channelisation code for data part There is only one DPDCH for this case
>TDD				
>>Uplink Timing Advance Control	OP		Uplink Timing Advance Control 10.3.6.96	
>>Uplink DPCH timeslots and codes	MP		Uplink Timeslots and Codes 10.3.6.94	

10.3.6.90 Uplink DPCH info Pre

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Uplink DPCH power control info	OP		Uplink DPCH power control info Pre 10.3.6.93	
CHOICE mode	MP			
>FDD				
>>TFCI existence	MP		Boolean	TRUE means existence. Default value is "TRUE"
>>Puncturing Limit	MP		Real(0.401 by step of 0.04)	
>TDD				
>>Common timeslot info	MP		Common Timeslot Info 10.3.6.10	

Condition	Explanation
Single	This IE is mandatory present if the IE "Number of
	DPDCH" is "1" and not needed otherwise.

10.3.6.91 Uplink DPCH power control info

Parameters used by UE to set DPCH initial output power and to use for closed-loop power control in FDD and 1.28 Mcps TDD and parameters for uplink open loop power control in 3.84 Mcps TDD.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
CHOICE mode	MP		1010101100	uocompaion	
>FDD	1				
>>DPCCH Power offset	MP		Integer(- 164,6 by step of 2)	In dB	
>>PC Preamble	MP		Integer (07)	In number of frames	
>>SRB delay	MP		Integer(07)	In number of frames	
>>Power Control Algorithm	MP		Enumerated (algorithm 1, algorithm 2)	Specifies algorithm to be used by UE to interpret TPC commands	
>>TPC step size	CV-algo		Integer (1, 2)	In dB	
>>Δ _{ACK}	ОР		Integer (08)	Refer to quantization of the power offset in [28]	REL-5
>>∆nack	OP		Integer (08)	refer to quantization of the power offset in [28]	REL-5
>>Ack-Nack repetition factor	OP		Integer(14)		REL-5
>TDD					
>>>>UL target SIR	OP		Real (-11 20 by step of 0.5dB)	In dB For 1.28 Mcps TDD this parameter represents PRX _{DPCHdes} with range Integer(- 12058 by step of 1) dBm	REL-4
>>CHOICE UL OL PC info	MP				
>>>Broadcast UL OL PC info			Null	No data	
>>>Individually Signalled	OP				
>>>>CHOICE TDD option	MP				REL-4
>>>>3.84 Mcps TDD					REL-4
>>>>Individual timeslot interference info	MP	1 to <maxts></maxts>			
>>>>>Individual timeslot interference	MP		Individual timeslot interference 10.3.6.38		
>>>>DPCH Constant Value	OP		Constant Value TDD 10.3.6.11a	Quality Margin	
>>>>1.28 Mcps TDD					REL-4
>>>>TPC step size	MP		Integer(1,2,3		REL-4
>>>Primary CCPCH Tx Power	ОР		Primary CCPCH Tx Power 10.3.6.59	For Pathloss Calculation	

Condition	Explanation		
algo	The IE is mandatory present if the IE "Power Control		
	Algorithm" is set to "algorithm 1", otherwise the IE is		
	not needed		

10.3.6.92 Uplink DPCH power control info Post

Parameters used by UE to set DPCH initial output power and to use for closed-loop power control.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
CHOICE mode	MP				
>FDD					
>>DPCCH Power offset	MP		Integer(- 11050 by step of 4)	In dB	
>>PC Preamble	MP		Integer (07)	in number of frames	
>>SRB delay	MP		Integer (07)	In number of frames	
>TDD					
>>UL target SIR	MP		Real (-11	In dB	
			20 by step of 0.5dB)	For 1.28 Mcps TDD this parameter represents PRXDPCHdes with range Integer(- 12058 by step of 1) dBm	REL-4
>>CHOICE TDD option	MP				REL-4
>>>3.84 Mcps TDD					REL-4
>>>>UL Timeslot Interference	MP		UL Interference TDD 10.3.6.87a		
>>>1.28 Mcps TDD				(no data)	REL-4

Condition	Explanation
algo	The IE is mandatory present if the IE "Power Control
	Algorithm" is set to "algorithm 1", otherwise the IE is
	not needed

10.3.6.93 Uplink DPCH power control info Pre

Parameters used by UE to set DPCH initial output power and to use for closed-loop power control in FDD and parameters for uplink open loop power control in 3.84 Mcps TDD.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
CHOICE mode	MP			-	
>FDD					
>>Power Control Algorithm	MP		Enumerated (algorithm 1, algorithm 2)	Specifies algorithm to be used by UE to interpret TPC commands	
>>TPC step size	CV-algo		Integer (1, 2)	In dB	
>TDD				(No data)	
>>CHOICE TDD option	MP				REL-4
>>>3.84 Mcps TDD					REL-4
>>DPCH Constant Value	MP		Constant Value TDD 10.3.6.11a	Quality Margin	
>>>1.28 Mcps TDD				(no data)	REL-4

Condition	Explanation		
algo	The IE is mandatory present if the IE "Power Control		
	Algorithm" is set to "algorithm 1", otherwise the IE is not needed		

10.3.6.94 Uplink Timeslots and Codes

NOTE: Only for TDD

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Dynamic SF usage	MP		Boolean	
First Individual timeslot info	MP		Individual	Individual timeslot info for the
First marvidual timesiot imo	IVIE		timeslot info	first timeslot used by the
			10.3.6.37	physical layer.
First timeslot Code List	MP	12	10.0.0.07	Code list used in the timeslot.
That timeslot dode List	IVII	12		given in First individual timeslot info.
>Channelisation Code	MP		Enumerated((1/1),)(2/1),(2/2),(4/1)(4/ 4),(8/1)(8/8) ,(16/1)(16/1 6))	
CHOICE more timeslots	MP			
>No more timeslots				(no data)
>Consecutive timeslots				
>>Number of additional timeslots	MP		Integer(1m axTS-1)	The timeslots used by the physical layer shall be timeslots: N mod maxTS (N+1) mod maxTS (N+k) mod maxTS in that order, where N is the timeslot number in the First individual timeslot info and k the Number of additional timeslots. The additional timeslots shall use the same parameters (e.g. channelisation codes, midamble shifts etc.) as the first timeslot.
>>Additional timeslot list	MP	1 to <maxts- 1></maxts- 		The first instance of this parameter corresponds to the timeslot that shall be used second by the physical layer, the second to the timeslot that shall be used third and so on.
>>>CHOICE parameters	MP			
>>>Same as last				
>>>>Timeslot number	MP		Timeslot Number 10.3.6.84	This physical layer shall use the same parameters (e.g. channelisation codes, midamble shifts etc.) for this timeslot as for the last one.
>>>New parameters				
>>>>Individual timeslot info	MP		Individual timeslot info 10.3.6.37	
>>>>Code List	MP	12		
>>>>Channelisation Code	MP		Enumerated((1/1),)(2/1),(2/2),(4/1)(4/	

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
			4),(8/1)(8/8)	
			,(16/1)(16/1	
			6))	

10.3.6.95 Uplink Timing Advance

NOTE: Only for 3.84 Mcps TDD.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
UL Timing Advance	MP		Integer (063)	Absolute timing advance value to be used to avoid large delay spread at the NodeB	

10.3.6.96 Uplink Timing Advance Control

NOTE: Only for TDD

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
CHOICE Timing Advance	MP			·	
>Disabled			Null	Indicates that no timing advance is applied	
>Enabled					
>>CHOICE TDD option	MP				REL-4
>>>3.84 Mcps TDD					REL-4
>>>UL Timing Advance	MD		Uplink Timing Advance 10.3.6.95	Absolute timing advance value to be used to avoid large delay spread at the NodeB. Default value is the existing value for uplink timing advance.	
>>>Activation Time	OP		Activation Time 10.3.3.1	Frame number timing advance is to be applied. This IE is required when a new UL Timing Advance adjustment is specified and Activation Time is not otherwise specified in the RRC message.	
>>1.28 Mcps TDD				(no data)	REL-4
>>>Uplink synchronisation parameters	MD			Default: Uplink synchronisation step size is 1. Uplink synchronisation frequency is 1.	REL-4
>>>>Uplink synchronisation step size	MP		Integer(18)	This parameter specifies the step size to be used for the adjustment of the uplink	REL-4

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
				transmission timing	
>>>>Uplink synchronisation frequency	MP		Integer(18)	This parameter specifies the frequency of the adjustment of the uplink transmission timing	REL-4
>>>Synchronisation parameters	OP				
>>>SYNC_UL codes bitmap	MP		Bitstring(8)	Each bit indicates availability of a SYNC_UL code, where the SYNC_UL codes are numbered "code 0" to "code 7". The value 1 of a bit indicates that the corresponding SYNC_UL code can be used. The value 0 of a bit indicates that the corresponding SYNC_UL code can be used.	REL-4
>>>FPACH info	MP		FPACH info 10.3.6.35a	carriot be asea.	REL-4
>>>PRX _{UpPCHdes}	MP		Integer(- 12058 by step of 1)	In dBm	REL-4
>>>SYNC_UL procedure	MD			Default is: Max SYNC_UL Transmission is 2. Power Ramp Step is 2.	REL-4
>>>>Max SYNC_UL Transmissions	MP		Integer(1,2,4 ,8)	Maximum numbers of SYNC_UL transmissions in a power ramping sequence.	REL-4
>>>>Power Ramp Step	MP		Integer(0,1,2 ,3)	In dB	REL-4

10.3.7 Measurement Information elements

10.3.7.1 Additional measurements list

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Additional measurements	MP	1 to <maxadditi onalMeas></maxadditi 		
>Additional measurement identity	MP		Measuremen t identity 10.3.7.48	

10.3.7.2 Cell info

Includes non-frequency related cell info used in the IE "inter-frequency cell info list" and "intra frequency cell info list".

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Cell individual offset	MD		Real(-1010 by step of 0.5)	In dB Default value is 0 dB Used to offset measured quantity value	
Reference time difference to cell	OP		Reference time difference to cell 10.3.7.60	In chips. This IE is absent for serving cell.	
Read SFN indicator	MP		Boolean	TRUE indicates that read of SFN is requested for the target cell	
CHOICE mode	MP				
>FDD >>Primary CPICH info	OP		Primary CPICH info 10.3.6.60	This IE is absent only if measuring RSSI only (broadband measurement.)	
>>Primary CPICH Tx power	OP		Primary CPICH Tx power 10.3.6.61	Required if calculating pathloss.	
>>TX Diversity Indicator	MP		Boolean	TRUE indicates that transmit diversity is used.	
>TDD					
>>Primary CCPCH info	MP		Primary CCPCH info 10.3.6.57		
>>Primary CCPCH TX power	OP		Primary CCPCH TX power 10.3.6.59		
>>Timeslot list	OP	1 to <maxts></maxts>		The UE shall report Timeslot ISCP values according the order of the listed Timeslot numbers	
>>>CHOICE TDD option	MP				REL-4
>>>3.84 Mcps TDD >>>>Timeslot number	MP		Integer (014)	Timeslot numbers, for which the UE shall report Timeslot ISCP	REL-4
>>>>Burst Type	MD		Enumerated (Type1, Type2)	Use for Timeslot ISCP measurements only. Default value is "Type1"	
>>>>1.28 Mcps TDD	MD		Intoger	Timoolot	REL-4
>>>>Timeslot number	MP		Integer (06)	Timeslot numbers, for which the UE shall report Timeslot ISCP	REL-4

Cell Selection and Re-selection	CV-	Cell	This IE is absent	
Info	BCHopt	Selection	for the serving	
		and Re-	cell.	
		selection for		
		SIB11/12Info		
		10.3.2.4		

Condition	Explanation
BCHopt	This IE is Optional when sent in SYSTEM
	INFORMATION, Otherwise, the IE is not needed

10.3.7.3 Cell measured results

Includes non-frequency related measured results for a cell.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Cell Identity	OP		Cell Identity 10.3.2.2		
Cell synchronisation information	OP		Cell synchroni sation informatio n 10.3.7.6		
CHOICE mode	MP				
>FDD >>Primary CPICH info	MP		Drimon		
>>Fillilary CFICH IIII0	IVIF		Primary CPICH info 10.3.6.60		
>>CPICH Ec/N0	OP		Integer(0 49)	According to CPICH_Ec/No in [19] and [20]. Fourteen spare values are needed.	
>>CPICH RSCP	OP		Integer(0 91)	According to CPICH_RSCP in [19] and [20]. Thirty-six spare values are needed.	
>>Deltacpich RSCP	CV- RSCP		Integer(- 51)	If present, the actual value of CPICH RSCP = CPICH RSCP+ Delta _{CPICH RSCP}	REL-5
>>Pathloss	OP		Integer(46 158)	In dB. Fifteen spare values are needed.	
>>TDD >>Cell parameters Id	MP		Cell parameter s Id 10.3.6.9		
>>Proposed TGSN	OP		Integer (014)	Proposal for the next TGSN	
>>Primary CCPCH RSCP	OP		Primary CCPCH RSCP info 10.3.7.54	-	
>>Pathloss	OP		Integer(46158)	In dB. Fifteen spare values are needed.	
>>Timeslot list	OP	1 to < maxTS>			

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
>>>Timeslot ISCP	MP		Timeslot	The UE shall report the	
			ISCP Info	Timeslot ISCP in the	
			10.3.7.65	same order as indicated	
				in the cell info	

Condition	Explanation
RSCP	This IE is mandatory if CPICH RSCP is present and if
	the value of the CPICH RSCP is below 0. It is not
	needed otherwise.

10.3.7.4 Cell measurement event results

Includes non-frequency related cell reporting quantities.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE mode	MP			
>FDD				
>>Primary CPICH info	MP	1 to <maxcellm eas></maxcellm 	Primary CPICH info 10.3.6.60	
>TDD				
>>Primary CCPCH info	MP	1 to <maxcellm eas></maxcellm 	Primary CCPCH info 10.3.6.57	

10.3.7.5 Cell reporting quantities

Includes non-frequency related cell reporting quantities.

For all boolean types TRUE means inclusion in the report is requested.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Cell synchronisation information reporting indicator	MP		Boolean	
Cell Identity reporting indicator	MP		Boolean	
CHOICE mode	MP			
>FDD				
>>CPICH Ec/N0 reporting indicator	MP		Boolean	
>>CPICH RSCP reporting indicator	MP		Boolean	
>>Pathloss reporting indicator	MP		Boolean	
>TDD				
>>Timeslot ISCP reporting indicator	MP		Boolean	
>>Proposed TGSN Reporting required	MP		Boolean	
>>Primary CCPCH RSCP reporting indicator	MP		Boolean	
>>Pathloss reporting indicator	MP		Boolean	

10.3.7.6 Cell synchronisation information

The IE "Cell synchronisation information" contains the OFF and Tm as defined in [7] and [8] and the four most significant bits of the difference between the 12 least significant bits of the RLC Transparent Mode COUNT-C in the UE and the SFN of the measured cell. It is notified to SRNC by Measurement Report message or Measurement Information Element in other RRC messages

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE mode	MP			
>FDD				
>>COUNT-C-SFN frame difference	OP			
>>>COUNT-C-SFN high	MP		Integer(038 40 by step of 256)	in frames
>>>OFF	MP		Integer(025 5)	in frames
>>Tm	MP		Integer(038 399)	in chips
>TDD				
>>COUNT-C-SFN frame difference	OP			
>>>COUNT-C-SFN high	MP		Integer(038 40 by step of 256)	in frames
>>>OFF	MP		Integer(025 5)	in frames

10.3.7.7 Event results

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE event result	MP			One spare value is needed.
>Intra-frequency			Intra-	
measurement event results			frequency	
			measuremen	
			t event	
			results	
			10.3.7.37	
>Inter-frequency			Inter-	
measurement event results			frequency	
			measuremen	
			t event	
			results	
1.4. 547			10.3.7.17	5 10 0000 H : 1 1
>Inter-RAT measurement			Inter-RAT	For IS-2000 results, include
event results			measuremen	fields of the Pilot Strength
			t event	Measurement Message from
			results	subclause 2.7.2.3.2.5 of
T#:			10.3.7.28	TIA/EIA/IS-2000.5
>Traffic volume measurement			Traffic	
event results			volume	
			measuremen	
			t event results	
			10.3.7.69	
>Quality measurement event			Quality	
results			measuremen	
results			t event	
			results	
			10.3.7.57	
>UE internal measurement			UE internal	
event results			measuremen	
			t event	
			results	
			10.3.7.78	
>UE positioning measurement			UE	
event results			positioning	
			measuremen	
			t event	
			results	

Information Element/Group name	Need	Multi	Type and reference	Semantics description
			10.3.7.101	

CHOICE event result	Condition under which the given event result is
	chosen
Intra-frequency measurement event results	If measurement type = intra-frequency measurement
Inter-frequency measurement event results	If measurement type = inter-frequency measurement
Inter-RAT measurement event results	If measurement type = inter-RAT measurement
Traffic volume measurement event results	If measurement type = traffic volume measurement
Quality measurement event results	If measurement type = Quality measurement
UE internal measurement event results	If measurement type = UE internal measurement
UE positioning measurement event results	If measurement type = UE positioning measurement

10.3.7.8 FACH measurement occasion info

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
FACH Measurement occasion cycle length coefficient	OP		Integer(112		
Inter-frequency FDD measurement indicator	MP		Boolean	TRUE means that measurements are required	
Inter-frequency TDD 3.84 Mcps measurement indicator	MP		Boolean	TRUE means that measurements are required	REL-4
Inter-frequency TDD 1.28 Mcps measurement indicator	MP		Boolean	TRUE means that measurements are required	REL-4
Inter-RAT measurement indicators	OP	1 to <maxother RAT></maxother 			
>RAT type	MP		Enumerated(GSM, IS2000)		

10.3.7.9 Filter coefficient

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Filter coefficient	MD		Integer(0, 1,	Default value is 0
			2, 3, 4, 5, 6, 7, 8, 9, 11,	
			13, 15, 17,	
			19)	

10.3.7.10 HCS Cell re-selection information

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Penalty_time	MD		Integer(0, 10, 20, 30,	Default value is 0 which means = not used
Temporary_offsets	CV-Penalty used		40, 50, 60)	In seconds
>Temporary_offset1	MP		Integer(3, 6, 9, 12, 15, 18, 21, inf)	[dB]
>Temporary_offset2	CV-FDD- Quality- Measure		Integer(2, 3, 4, 6, 8, 10, 12, inf)	[dB]

Condition	Explanation		
Penalty used	This IE is not needed if the IE "Penalty time" equals		
	"not used", else it is mandatory present.		
FDD-Quality-Measure	This IE is not needed if the IE "Cell selection and reselection quality measure" has the value CPICH RSCP, otherwise the IE is mandatory present. This conditional presence is implemented in ASN.1 by the use of a specific RSCP and EcN0 variant of 10.3.7.10.		

10.3.7.11 HCS neighbouring cell information

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
HCS_PRIO	MD		Integer (07)	Default value = 0
Qhcs	MD		Qhcs	Default value = 0
			10.3.7.54a	
HCS Cell Re-selection	MP		HCS Cell	
Information			Re-selection	
			Information	
			10.3.7.10	

10.3.7.12 HCS Serving cell information

Information Element/Group	Need	Multi	Type and	Semantics description
name			Reference	
HCS_PRIO	MD		Integer (07)	Default value = 0
Qhcs	MD		Qhcs	Default value = 0
			10.3.7.54a	
T _{CRmax}	MD		Enumerated([s]
			not used, 30,	Default value is not used
			60, 120, 180,	
			240)	
N _{CR}	CV-UE		Integer(116	Default value = 8
	speed)	
	detector			
T _{CrmaxHyst}	CV-UE		Enumerated([s]
	speed		not used, 10,	
	detector		20, 30, 40,	
			50, 60, 70)	

Condition	Explanation
UE Speed detector	This IE is not needed if T _{Crmax} equals 'not used', else it
	is mandatory present.

10.3.7.13 Inter-frequency cell info list

Contains the information for the list of measurement objects for an inter-frequency measurement.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE Inter-frequency cell removal	OP			
>Remove all inter-frequency cells				No data
>Remove some inter-frequency cells				
>>Removed inter-frequency cells	MP	1 <maxcellm eas></maxcellm 		
>>>Inter-frequency cell id	MP		Integer(0 <maxcellme as>-1)</maxcellme 	
>No inter-frequency cells removed				No data
New inter-frequency cells	OP	1 to <maxcellm eas></maxcellm 		
>Inter-frequency cell id	MD		Integer(0 <maxcellme as>-1)</maxcellme 	
>Frequency info	MD		Frequency info 10.3.6.36	Default value is the value of the previous "frequency info" in the list. NOTE: The first occurrence is then MP.
>Cell info	MP		Cell info 10.3.7.2	
Cells for measurement	CV- BCHopt	1 to <maxcellm eas></maxcellm 		
>Inter-frequency cell id	MP		Integer(0 <maxcellme as>-1)</maxcellme 	

Condition	Explanation			
BCHopt	This IE is not needed when sent in SYSTEM			
	INFORMATION. Otherwise, the IE is Optional			

10.3.7.14 Inter-frequency event identity

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Inter-frequency event identity	MP		Enumerated(Two spare values are needed.
			2a, 2b, 2c,	
			2d, 2e, 2f)	

10.3.7.15 Inter-frequency measured results list

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Inter-frequency measurement	OP	1 to		
results		<maxfreq></maxfreq>		
>Frequency info	MD		Frequency	Default value is the value of
			info	the previous "frequency info"
			10.3.6.36	in the list.
				NOTE: The first occurrence
				is then MP.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
>UTRA carrier RSSI	OP		Integer(076	According to UTRA_carrier_RSSI_LEV in [19] and [20]. Fifty-one spare values are needed.
>Inter-frequency cell measurement results	OP	1 to <maxcellm eas></maxcellm 		Only cells for which all reporting quantities are available should be included.
>>Cell measured results	MP		Cell measured results 10.3.7.3	

10.3.7.16 Inter-frequency measurement

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Inter-frequency measurement objects list	MP		Inter- frequency cell info list 10.3.7.13	
Inter-frequency measurement quantity	OP		Inter- frequency measuremen t quantity 10.3.7.18	
Inter-frequency reporting quantity	OP		Inter- frequency reporting quantity 10.3.7.21	
Reporting cell status	CV- reporting		Reporting cell status 10.3.7.61	
Measurement validity	OP		Measuremen t validity 10.3.7.51	
Inter-frequency set update	OP		Inter- frequency set update 10.3.7.22	
CHOICE report criteria	MP			
>Intra-frequency measurement reporting criteria			Intra- frequency measuremen t reporting criteria 10.3.7.39	
>Inter-frequency measurement reporting criteria			Inter- frequency measuremen t reporting criteria 10.3.7.19	
>Periodical reporting criteria			Periodical reporting criteria 10.3.7.53	
>No reporting				(no data) Chosen when this measurement only is used as additional measurement to another measurement

Condition	Explanation
reporting	This IE is optional if the CHOICE "report criteria" is
	equal to "periodical reporting criteria" or "No
	reporting", otherwise the IE is not needed

10.3.7.17 Inter-frequency measurement event results

This IE contains the measurement event results that are reported to UTRAN for inter-frequency measurements.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Inter-frequency event identity	MP		Inter- frequency event identity 10.3.7.14	
Inter-frequency cells	OP	1 to <maxfreq></maxfreq>		
>Frequency info	MP		Frequency info 10.3.6.36	
>Non frequency related measurement event results	MP		Cell measureme nt event results 10.3.7.4	

10.3.7.18 Inter-frequency measurement quantity

The quantity the UE shall measure in case of inter-frequency measurement. It also includes the filtering of the measurements.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE reporting criteria	MP			
>Intra-frequency reporting criteria				
>>Intra-frequency measurement quantity	MP		Intra- frequency measuremen t quantity 10.3.7.38	
>Inter-frequency reporting criteria				
>>Filter coefficient	MP		Filter coefficient 10.3.7.9	
>>CHOICE mode	MP			
>>>FDD				
>>>Measurement quantity for frequency quality estimate	MP		Enumerated(CPICH Ec/N0, CPICH RSCP)	
>>>TDD				
>>>Measurement quantity for frequency quality estimate	MP		Enumerated(Primary CCPCH RSCP)	

10.3.7.19 Inter-frequency measurement reporting criteria

The triggering of the event-triggered reporting for an inter-frequency measurements. All events concerning inter-frequency measurements are labelled 2x where x is a,b,c,...

Event 2a: Change of best frequency.

Event 2b: The estimated quality of the currently used frequency is below a certain threshold **and** the estimated quality of a non-used frequency is above a certain threshold.

Event 2c: The estimated quality of a non-used frequency is above a certain threshold.

Event 2d: The estimated quality of the currently used frequency is below a certain threshold.

Event 2e: The estimated quality of a non-used frequency is below a certain threshold.

Event 2f: The estimated quality of the currently used frequency is above a certain threshold.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Parameters required for each event	OP	1 to <maxme asEvent</maxme 			
>Inter-frequency event identity	MP		Inter- frequency event identity 10.3.7.14		
>Threshold used frequency	CV- clause 0		Integer(- 1150)	Ranges used depend on measurement quantity. CPICH Ec/No -240dB CPICH/Primary CCPCH RSCP -11525dBm	
>Delta _{Threshold} used frequency	CV- clause 3		Integer(- 51)	If present, the actual value of Threshold used frequency = Threshold used frequency + DeltaThreshold used frequency	REL-5
>W used frequency	CV– clause 2		Real(0, 0.12.0 by step of 0.1)		
>Hysteresis	MP		Real(0, 0.514.5 by step of 0.5)	In event 2a, 2b, 2c, 2d, 2e, 2f	
>Time to trigger	MP		Time to trigger 10.3.7.64	Indicates the period of time during which the event condition has to be satisfied, before sending a Measurement Report. Time in ms.	
>Reporting cell status	OP		Reporting cell status 10.3.7.61		
>Parameters required for each non-used frequency	OP	1 to <maxfre q></maxfre 		In this release, the first listed threshold and W parameter shall apply to all non-used frequencies.	

Information	Need	Multi	Type and	Semantics description	Version
Element/Group name			reference		
>>Threshold non used	CV-		Integer(-	Ranges used depend	
frequency	clause 1		1150)	on measurement	
				quantity.	
				CPICH Ec/No -240dB	
				CPICH/Primary CCPCH	
				RSCP -11525dBm.	
				This IE is not needed if	
				the IE "Inter-frequency	
				event identity" is set to	
				2a. However, it is	
				specified to be	
				mandatory to align with	
				the ASN.1.	
>> Delta _{Threshold} non used	CV-		Integer(-	If present, the actual	REL-5
frequency	clause 4		51)	value of Threshold non	
				used frequency =	
				Threshold non used	
				frequency +	
				DeltaThreshold non used	
				frequency	
>>W non-used frequency	CV-		Real(0,		
	clause 1		0.12.0		
			by step of		
			0.1)		

Condition	Explanation
Clause 0	This IE is mandatory present if the IE "Inter frequency event identity" is set to 2b, 2d, or 2f, otherwise the IE is not needed.
Clause 1	This IE is mandatory present if the IE "Inter frequency event identity" is set to 2a, 2b, 2c or 2e, otherwise the IE is not needed
Clause 2	This IE is mandatory present if the IE "Inter-frequency event identity" is set to 2a, 2b, 2d or 2f, otherwise the IE is not needed.
Clause 3	This IE is optional if the IE "Inter frequency event identity" is set to 2b, 2d, or 2f, and the threshold is below –115dBm. Otherwise the IE is not needed.
Clause 4	This IE is optional if the IE "Inter frequency event identity" is set to 2a, 2b, 2c or 2e, and the threshold is below –115dBm. Otherwise the IE is not needed

10.3.7.20 Inter-frequency measurement system information

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Inter-frequency cell info list	OP		Inter-	
			frequency	
			cell info list	
			10.3.7.13	

10.3.7.21 Inter-frequency reporting quantity

Information Element/Group name	Need	Multi	Type and reference	Semantics description
UTRA Carrier RSSI	MP		Boolean	TRUE means report is requested.
Frequency quality estimate	MP		Boolean	TRUE means that report is requested. This parameter is not used in this release and should be set to FALSE. It shall be ignored by the UE.
Non frequency related cell reporting quantities	MP		Cell reporting quantities 10.3.7.5	

10.3.7.22 Inter-frequency SET UPDATE

NOTE 1: Only for FDD.

This information makes it possible to use events defined for Intra-frequency measurement within the same non-used frequency for Inter-frequency measurement reporting criteria.

Information Element/group name	Need	Multi	Type and reference	Semantics description
UE autonomous update mode	MP		Enumerated (On with no reporting)	Required for backwards compatibility with a UE not supporting this revision of the standard

10.3.7.23 Inter-RAT cell info list

Contains the information for the list of measurement objects for an inter-RAT measurement.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
CHOICE Inter-RAT cell removal	MP				
>Remove all inter-RAT cells				No data	
>Remove some inter-RAT cells					
>>Removed inter-RAT cells	MP	1 to <maxcellm eas></maxcellm 			
>>>Inter-RAT cell id	MP		Integer(0 <maxcellme as> - 1)</maxcellme 		
>Remove no inter-RAT cells					
New inter-RAT cells	MP	1 to <maxcellm eas></maxcellm 		Although this IE is not always required, need is MP to align with ASN.1	
	OP				REL-4
>Inter-RAT cell id	OP		Integer(0 <maxcellme as> - 1)</maxcellme 		
>CHOICE Radio Access Technology	MP				
>>GSM					
>>>Cell individual offset	MP		Integer (- 5050)	In dB Used to offset measured quantity value	
>>>Cell selection and re-	OP		Cell	See subclause	

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
selection info			selection	8.6.7.3	
			and re-		
			selection info		
			for SIB11/12		
>>>BSIC	MP		10.3.2.4 BSIC		
>>>BSIC	IVIP		10.3.8.2		
>>>Band indicator	MP		Enumerated	Indicates how to	
			(DCS 1800	interpret the	
			band used,	BCCH ARFCN	
			PCS 1900		
DOOLL ADEON	MD		band used)	[45]	
>>>BCCH ARFCN	MP		Integer (01023)	[45]	
>>IS-2000					
>>>System specific	MP		enumerated	For IS-2000, use	
measurement info			(frequency,	fields from	
			timeslot,	TIA/EIA/IS-	
			colour code,	2000.5,	
			output	subclause 3.	
			power, PN offset)	7.3.3.2.27, Candidate	
			onset)	Frequency	
				Neighbour List	
				Message	
>>None			(no data)	This value has	
				been introduced	
				to handle the case	
				when IE "New	
				inter-RAT cells" is	
				not required	
Cell for measurement	OP	1 to			
		<maxcellm< td=""><td></td><td></td><td></td></maxcellm<>			
Later DAT cell id	MD	eas>	lata ====(0		
>Inter-RAT cell id	MP		Integer(0 <maxcellme< td=""><td></td><td></td></maxcellme<>		
	1		as>-1)		

10.3.7.24 Inter-RAT event identity

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Inter-RAT event identity	MP		Enumerated	
			(3a, 3b, 3c,	
			3d)	

10.3.7.25 Inter-RAT info

Inter-RAT info defines the target system for redirected cell selection.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Inter-RAT info	MP		Enumerated	
			(GSM)	

10.3.7.26 Inter-RAT measured results list

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Inter-RAT measurement results	OP	1 to <maxother RAT-16></maxother 		
>CHOICE system	MP			One spare value is needed.
>>GSM				
>>>Measured GSM cells	MP	1 to <maxrepo rtedGSMC ells></maxrepo 		
>>>GSM carrier RSSI	OP		bit string(6)	RXLEV is mapped to a value between 0 and 63, [46]. When mapping the RXLEV value to the RSSI bit string, the first/leftmost bit of the bit string contains the most significant bit.
>>>>CHOICE BSIC	MP			
>>>>Verified BSIC				
>>>>>inter-RAT cell id	MP		Integer(0< maxCellMea s>-1)	
>>>>Non verified BSIC				
>>>>BCCH ARFCN	MP		Integer (01023)	[45]
>>>>Observed time difference to GSM cell	OP		Observed time difference to GSM cell 10.3.7.52	

10.3.7.27 Inter-RAT measurement

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Inter-RAT measurement objects	OP		Inter-RAT	
list			cell info list	
			10.3.7.23	
Inter-RAT measurement	OP		Inter-RAT	
quantity			measuremen	
			t quantity	
			10.3.7.29	
Inter-RAT reporting quantity	OP		Inter-RAT	
			reporting	
			quantity	
			10.3.7.32	
Reporting cell status	CV-		Reporting	
	reporting		cell status	
			10.3.7.61	
CHOICE report criteria	MP			
>Inter-RAT measurement			Inter-RAT	
reporting criteria			measuremen	
			t reporting	
			criteria	
			10.3.7.30	
>Periodical reporting criteria			Periodical	
			reporting	
			criteria	
			10.3.7.53	
>No reporting				(no data)
				Chosen when this
				measurement only is used as
				additional measurement to
				another measurement

Condition	Explanation		
reporting	This IE is optional if the CHOICE "report criteria" is		
	equal to "periodical reporting criteria" or "No		
	reporting", otherwise the IE is not needed		

10.3.7.28 Inter-RAT measurement event results

This IE contains the measurement event results that are reported to UTRAN for inter-RAT measurements.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Inter-RAT event identity	MP		Inter-RAT	
			event	
			identity	
			10.3.7.24	
Cells to report	MP	1 to		
		<maxcellm< td=""><td></td><td></td></maxcellm<>		
		eas>		
>CHOICE BSIC	MP			
>>Verified BSIC				
>>>inter-RAT cell id	MP		Integer(0<	
			maxCellMea	
			s>-1)	
>>Non verified BSIC				
>>>BCCH ARFCN	MP		Integer	[45]
			(01023)	

10.3.7.29 Inter-RAT measurement quantity

The quantity the UE shall measure in case of inter-RAT measurement. It also includes the filtering of the measurements.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Measurement quantity for UTRAN quality estimate	OP		Intra- frequency measuremen t quantity 10.3.7.38	
CHOICE system	MP			
>GSM				
>>Measurement quantity	MP		Enumerated(GSM Carrier RSSI)	
>>Filter coefficient	MP		Filter coefficient 10.3.7.9	
>>BSIC verification required	MP		Enumerated(required, not required)	
>IS2000				
>>TADD E ₀ /I ₀	MP		Integer(063	Admission criteria for neighbours, see subclause 2.6.6.2.6 of TIA/EIA/IS-2000.5
>>TCOMP E ₀ /I ₀	MP		Integer(015	Admission criteria for neighbours, see subclause 2.6.6.2.5.2 of TIA/EIA/IS- 2000.5
>>SOFT SLOPE	OP		Integer(063	Admission criteria for neighbours, see subclause 2.6.6.2.3 and 2.6.6.2.5.2 of TIA/EIA/IS-2000.5
>>ADD_INTERCEPT	OP		Integer(063	Admission criteria for neighbours, see subclause 2.6.6.2.5.2 of TIA/EIA/IS- 2000.5

The IE "BSIC verification required" must be set to "required" if IE "Observed time difference to GSM cell Reporting indicator" in IE "Inter-RAT reporting quantity "is set to "true".

10.3.7.30 Inter-RAT measurement reporting criteria

The triggering of the event-triggered reporting for an inter-RAT measurement. All events concerning inter-RAT measurements are labelled 3x where x is a,b,c, ...

Event 3a: The estimated quality of the currently used UTRAN frequency is below a certain threshold **and** the estimated quality of the other system is above a certain threshold.

Event 3b: The estimated quality of other system is below a certain threshold.

Event 3c: The estimated quality of other system is above a certain threshold.

Event 3d: Change of best cell in other system.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Parameters required for each event	OP	1 to <maxmeas< td=""><td></td><td></td></maxmeas<>		
		Event>		
>Inter-RAT event identity	MP		Inter-RAT	
			event	
			identity 10.3.7.24	
>Threshold own system	CV-clause		Integer (-	
,	0		1150)	
>W	CV-clause		Real(0,	In event 3a
	0		0.12.0 by	
			step of 0.1)	
>Threshold other system	CV-clause		Integer (-	In event 3a, 3b, 3c
	1		1150)	
>Hysteresis	MP		Real(07.5	
			by step of 0.5)	
>Time to trigger	MP		Time to	Indicates the period of time
			trigger	during which the event
			10.3.7.64	condition has to be satisfied,
				before sending a
Donastia a sellatatus	OD		D	Measurement Report.
>Reporting cell status	OP		Reporting	
			cell status 10.3.7.61	
			10.3.7.01	

Condition	Explanation
Clause 0	The IE is mandatory present if the IE "Inter-RAT event
	identity" is set to "3a", otherwise the IE is not needed
Clause 1	The IE is mandatory present if the IE "Inter-RAT event
	identity" is set to 3a, 3b or 3c, otherwise the IE is not
	needed

10.3.7.31 Inter-RAT measurement system information

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Inter-RAT cell info list	OP		Inter-RAT	
			cell info list	
			10.3.7.23	

10.3.7.32 Inter-RAT reporting quantity

For all boolean types TRUE means inclusion in the report is requested.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
UTRAN estimated quality	MP		Boolean	This parameter is not used in this release and should be set to FALSE.
CHOICE system	MP			
>GSM				
>>Observed time difference to GSM cell Reporting indicator	MP		Boolean	
>>GSM Carrier RSSI Reporting indicator	MP		Boolean	

10.3.7.33 Intra-frequency cell info list

Contains the information for the list of measurement objects for an intra-frequency measurement.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE Intra-frequency cell removal	OP			Absence of this IE is equivalent to choice "Remove no intra-frequency cells".
>Remove all intra-frequency cells				No data
>Remove some intra-frequency cells				
>>Removed intra-frequency cells	MP	1 to <maxcell Meas></maxcell 		
>>>Intra-frequency cell id	MP		Integer(0 <maxcellmea s> - 1)</maxcellmea 	
>Remove no intra-frequency cells				
New intra-frequency cells	OP	1 to <maxcell Meas></maxcell 		This information element must be present when "Intra- frequency cell info list" is included in the system information
>Intra-frequency cell id	OP		Integer(0 <maxcellmea s> - 1)</maxcellmea 	
>Cell info	MP		Cell info 10.3.7.2	This IE must be included for the serving cell when the IE "Intra frequency cell info list" is included in System Information Block type 11.
Cells for measurement	CV- BCHopt	1 to <maxcell Meas></maxcell 		
>Intra-frequency cell id	MP		Integer(0 <maxcellmea s>-1)</maxcellmea 	

Condition	Explanation
BCHopt	This IE is not needed when sent in SYSTEM
	INFORMATION. Otherwise, the IE is Optional

10.3.7.34 Intra-frequency event identity

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Intra-frequency event identity	MP		Enumerated (1a,1b,1c,1d, 1e,1f,1g,1h,1	Seven spare values are needed.

10.3.7.35 Intra-frequency measured results list

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Intra-frequency measurement results	OP	1 to <maxcellm eas></maxcellm 		
>Cell measured results	MP		Cell measured results 10.3.7.3	Only cells for which all reporting quantities are available should be included.

10.3.7.36 Intra-frequency measurement

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Intra-frequency measurement objects list	OP		Intra- frequency cell info list 10.3.7.33	
Intra-frequency measurement quantity	OP		Intra- frequency measuremen t quantity 10.3.7.38	
Intra-frequency reporting quantity	OP		Intra- frequency reporting quantity 10.3.7.41	
Reporting cell status	CV- reporting		Reporting cell status 10.3.7.61	
Measurement validity	ОР		Measuremen t validity 10.3.7.51	
CHOICE report criteria	OP			
>Intra-frequency measurement reporting criteria			Intra- frequency measuremen t reporting criteria 10.3.7.39	
>Periodical reporting criteria			Periodical reporting criteria 10.3.7.53	
>No reporting				(no data) Chosen when this measurement only is used as additional measurement to another measurement

Condition	Explanation
reporting	This IE is optional if the CHOICE "report criteria" is
	equal to "periodical reporting criteria" or "No
	reporting", otherwise the IE is not needed

10.3.7.37 Intra-frequency measurement event results

This IE contains the measurement event results that are reported to UTRAN for intra-frequency measurements.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Intra-frequency event identity	MP		Intra-	
			frequency	
			event	
			identity	
			10.3.7.34	
Cell measurement event results	MP		Cell	
			measureme	
			nt event	
			results	
			10.3.7.4	

10.3.7.38 Intra-frequency measurement quantity

The quantity the UE shall measure in case of intra-frequency measurement. It also includes the filtering of the measurements.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Filter coefficient	MP		Filter coefficient 10.3.7.9	
CHOICE mode	MP			
>FDD				
>>Measurement quantity	MP		Enumerated(CPICH Ec/N0, CPICH RSCP, Pathloss)	
>TDD				
>>Measurement quantity list	MP	1 to 4		
>>>Measurement quantity	MP		Enumerated(Primary CCPCH RSCP, Pathloss, Timeslot ISCP)	

10.3.7.39 Intra-frequency measurement reporting criteria

The triggering of the event-triggered reporting for an intra-frequency measurement. All events concerning intra-frequency measurements are labelled 1x where x is a, b, c....

- Event 1a: A Primary CPICH enters the Reporting Range (FDD only).
- Event 1b: A Primary CPICH leaves the Reporting Range (FDD only).
- Event 1c: A Non-active Primary CPICH becomes better than an active Primary CPICH (FDD only).
- Event 1d: Change of best cell (FDD only).
- Event 1e: A Primary CPICH becomes better than an absolute threshold (FDD only).
- Event 1f: A Primary CPICH becomes worse than an absolute threshold (FDD only).
- Event 1g: Change of best cell in TDD.
- Event 1h: Timeslot ISCP below a certain threshold (TDD only).
- Event 1i: Timeslot ISCP above a certain threshold (TDD only).

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Parameters required for each event	OP	1 to <maxme asEvent ></maxme 			
>Intra-frequency event identity	MP		Intra- frequency event identity 10.3.7.34		
>Triggering condition 1	CV– clause 0		Enumerat ed(Active set cells, Monitored set cells, Active set cells and monitored set cells)	Indicates which cells can trigger the event	
>Triggering condition 2	CV- clause 6 CV- clause 10		Enumerat ed(Active set cells, Monitored set cells, Active set cells and monitored set cells, Detected set cells, Detected set cells and monitored set cells and set cells and monitored set cells	Indicates which cells can trigger the event	REL-5
>Reporting Range Constant	CV– clause 2		Real(01 4.5 by step of 0.5)	In dB. In event 1a,1b.	
>Cells forbidden to affect Reporting range	CV- clause 1	1 to <maxcel IMeas></maxcel 		In event 1a,1b	
>>CHOICE mode >>>FDD	MP				
>>>Primary CPICH info	MP		Primary CPICH info 10.3.6.60		
>>>TDD	MD		Drives e.v.		
>>>>Primary CCPCH info	MP		Primary CCPCH info 10.3.6.57		
>W	CV– clause 2		Real(0.0 2.0 by step of 0.1)		
>Hysteresis	MP		Real(07. 5 by step of 0.5)	In dB.	
>Threshold used frequency	CV- clause 3		Integer (- 115165)	Range used depend on measurement quantity. CPICH RSCP -11525 dBm CPICH Ec/No -240 dB Pathloss 30165dB ISCP -11525 dBm	

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
>Delta _{Threshold} used frequency	CV- clause 8		Integer(- 51)	If present, the actual value of Threshold used frequency = Threshold used frequency + DeltaThreshold used frequency	REL-5
>Reporting deactivation threshold	CV- clause 4		Integer(0, 1, 2, 3, 4, 5, 6, 7)	In event 1a Indicates the maximum number of cells allowed in the active set in order for event 1a to occur. 0 means not applicable	
>Replacement activation threshold	CV- clause 5		Integer(0, 1, 2, 3, 4, 5, 6, 7)	In event 1c Indicates the minimum number of cells allowed in the active set in order for event 1c to occur. 0 means not applicable	
>Time to trigger	MP		Time to trigger 10.3.7.64	Indicates the period of time during which the event condition has to be satisfied, before sending a Measurement Report. Time in ms	
>Amount of reporting	CV– clause 7		Integer(1, 2, 4, 8, 16, 32, 64, Infinity)	In case the IE "Intra- frequency reporting criteria" is included in the IE "Inter-frequency measurement", this IE is not needed.	
>Reporting interval	CV– clause 7		Integer(0, 250, 500, 1000, 2000, 4000, 8000, 16000)	Indicates the interval of periodical reporting when such reporting is triggered by an event. Interval in milliseconds. 0 means no periodical reporting. In case the IE "Intra-frequency reporting criteria" is included in the IE "Interfrequency measurement", this IE is not needed.	
>Reporting cell status	OP		Reporting cell status 10.3.7.61		
>Periodical reporting information-1b	CV– clause 9		Periodical reporting info-1b 10.3.7.53 aa	In case the IE "Intra- frequency reporting criteria" is included in the IE "Inter-frequency measurement", this IE is not needed.	REL-5
>Use CIO	CV- clause 10		Boolean	TRUE indicates that the cell individual offset shall be used for event evaluation	REL-5

Condition	Explanation
Clause 0	The IE is mandatory present if the IE "Intra-frequency event identity" is set to "1b" or "1f", otherwise the IE is not needed.
Clause 1	The IE is optional if the IE "Intra-frequency event identity" is set to "1a" or "1b", otherwise the IE is not needed.
Clause 2	The IE is mandatory present if the IE "Intra-frequency event identity" is set to "1a" or "1b", otherwise the IE is not needed.
Clause 3	The IE is mandatory present if the IE "Intra-frequency event identity" is set to , "1e", "1f", "1h" or "1i", otherwise the IE is not needed.
Clause 4	The IE is mandatory present if the IE "Intra-frequency event identity" is set to "1a", otherwise the IE is not needed.
Clause 5	The IE is mandatory present if the IE "Intra-frequency event identity" is set to "1c", otherwise the IE is not needed.
Clause 6	The IE is mandatory present if the IE "Intra-frequency event identity" is set to "1a" or "1e", otherwise the IE is not needed.
Clause 7	The IE is mandatory present if the IE "Intra-frequency event identity" is set to "1a" or "1c", otherwise the IE is not needed.
Clause 8	The IE is optional if the IE "Intra-frequency event identity" is set to "1e", "1f", "1h" or "1i", and the threshold is below –115dBm. Otherwise the IE is not needed.
Clause 9	The IE is optional if the IE "Intra-frequency event identity" is set to "1b", otherwise the IE is not needed.
Clause 10	The IE is optional if the IE "Intra-frequency event identity" is set to "1d", otherwise the IE is not needed.

10.3.7.40 Intra-frequency measurement system information

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Intra-frequency measurement identity	MD		Measuremen t identity	The intra-frequency measurement identity has
lacinary			10.3.7.48	default value 1.
Intra-frequency cell info list	OP		Intra-	
			frequency	
			cell info list 10.3.7.33	
Intra-frequency	OP		Intra-	
measurement quantity			frequency	
			measuremen	
			t quantity	
Intra-frequency reporting	OP		10.3.7.38 Intra-	
quantity for RACH			frequency	
Reporting			reporting	
			quantity for	
			RACH	
			Reporting 10.3.7.42	
Maximum number of	OP		Maximum	
reported cells on RACH			number of	
			reported	
			cells on	
			RACH 10.3.7.43	
Reporting information for state	OP		Reporting	Note 1
CELL_DČH			information	
			for state	

Information Element/Group name	Need	Multi	Type and reference	Semantics description
			CELL_DCH 10.3.7.62	

NOTE 1: The reporting of intra-frequency measurements is activated when state CELL_DCH is entered.

10.3.7.41 Intra-frequency reporting quantity

Contains the reporting quantity information for an intra-frequency measurement.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Reporting quantities for active set cells	MP		Cell reporting quantities 10.3.7.5	
Reporting quantities for monitored set cells	MP		Cell reporting quantities 10.3.7.5	
Reporting quantities for detected set cells	OP		Cell reporting quantities 10.3.7.5	

10.3.7.42 Intra-frequency reporting quantity for RACH reporting

Contains the reporting quantity information for an intra-frequency measurement report, which is sent on the RACH.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
SFN-SFN observed time difference reporting indicator	MP		Enumerated(No report, type 1, type 2)	
CHOICE mode	MP			
>FDD				
>>Reporting quantity	MP		Enumerated(CPICH Ec/N0, CPICH RSCP, Pathloss, No report)	
>TDD				
>>Reporting quantity list	MP	1 to 2		
>>>Reporting quantity	MP		Enumerated(Timeslot ISCP, Primary CCPCH RSCP, No report)	

10.3.7.43 Maximum number of reported cells on RACH

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Maximum number of reported	MP		Enumerated	
cells			(no report,	
			current cell,	
			current cell +	
			best	
			neighbour,	
			current	
			cell+2 best	
			neighbours,	
			, current	
			cell+6 best	
			neighbours)	

10.3.7.44 Measured results

Contains the measured results of the quantity indicated optionally by Reporting Quantity in Measurement Control. "Measured results" can be used for both event trigger mode and periodical reporting mode. For intra-frequency and inter-frequency measurements the list shall be in the order of the value of the measurement quantity (the first cell shall be the best cell). The "best" FDD cell has the largest value when the measurement quantity is "Ec/No" or "RSCP". On the other hand, the "best" cell has the smallest value when the measurement quantity is "Pathloss". The "best" TDD cell has the largest value when measurement quantity is "Primary CCPCH RSCP". For intra-frequency measurements, the ordering shall be applied to all cells included in the IE "Measured results". For other measurements, the order of reported measurement objects is not specified.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE Measurement	MP			One spare value is needed.
>Intra-frequency measured			Intra-	
results list			frequency	
			measured	
			results list	
			10.3.7.35	
>Inter-frequency measured			Inter-	
results list			frequency	
			measured	
			results list	
			10.3.7.15	
>Inter-RAT measured results list			Inter-RAT	
			measured	
			results list	
			10.3.7.26	
>Traffic volume measured			Traffic	
results list			volume	
			measured	
			results list	
			10.3.7.67	
>Quality measured results list			Quality	
			measured	
			results list	
			10.3.7.55	
>UE Internal measured results			UE Internal	
			measured	
			results	
			10.3.7.76	
>UE positioning measured			UE	
results			positioning	
			measured	
			results	
			10.3.7.99	

10.3.7.45 Measured results on RACH

Contains the measured results on RACH of the quantity indicated by Reporting quantity in the IE "Intra-frequency reporting quantity for RACH Reporting" in system information broadcast on BCH. The list, measurement results for monitored cells (not including the current cell) shall be in the order of the value of the measurement quantity as indicated by Reporting Quantity in the IE "Intra-frequency reporting quantity for RACH Reporting" (the first cell shall be the best cell). The "best" FDD cell has the largest value when the measurement quantity is "Ec/No" or "RSCP". On the other hand, the "best" cell has the smallest value when the measurement quantity is "Pathloss". The "best" TDD cell has the largest value when measurement quantity is "Primary CCPCH RSCP".

Information Element/group name	Need	Multi	Type and reference	Semantics description	Version
Measurement result for current cell					
CHOICE mode	MP				
>FDD					
>>CHOICE measurement quantity	MP			One spare value is needed.	
>>>CPICH Ec/N0			Integer(049	In dB. According to CPICH_Ec/No in [19]. Fourteen spare values are needed.	
>>>CPICH RSCP			Integer(091	In dBm. According to CPICH_RSCP_LE V in [19]. Thirty-six spare values are needed.	
>>>Pathloss			Integer(461 58)	In dB. Fifteen spare values are needed.	
>TDD					
>>CHOICE TDD option	MP				REL-4
>>>3.84 Mcps TDD					REL-4
>>>>Timeslot List	OP	1 to 14			
>>>>Timeslot ISCP	MP		Timeslot ISCP info 10.3.7.65	The UE shall report the Timeslot ISCP in the same order as indicated in the cell info	
>>>1.28 Mcps TDD					REL-4
>>>>Timeslot List	OP	1 to 6			REL-4
>>>>Timeslot ISCP	MP		Timeslot ISCP info 10.3.7.65	The UE shall report the Timeslot ISCP in the same order as indicated in the cell info	REL-4
>>Primary CCPCH RSCP	OP		Primary CCPCH RSCP info 10.3.7.54		
Measurement results for monitored cells	OP	1 to 8			
>SFN-SFN observed time difference	OP		SFN-SFN observed time difference 10.3.7.63		
>CHOICE mode	MP				
>>FDD					
>>>Primary CPICH info	MP		Primary		

Information Element/group name	Need	Multi	Type and reference	Semantics description	Version
			CPICH info 10.3.6.60		
>>>CHOICE measurement quantity	OP			One spare value is needed.	
>>>>CPICH Ec/N0			Integer(049	In dB. According to CPICH_Ec/No in [19]. Fourteen spare values are needed.	
>>>>CPICH RSCP			Integer(091	In dBm. According to CPICH_RSCP_LE V in [19]. Thirty-six spare values are needed.	
>>>Pathloss			Integer(461 58)	In dB. Fifteen spare values are needed.	
>>TDD >>>Cell parameters Id	MP		Cell parameters Id 10.3.6.9		
>>>Primary CCPCH RSCP	MP		Primary CCPCH RSCP info 10.3.7.54		

NOTE: Monitored cells consist of neighbouring cells.

10.3.7.46 Measurement Command

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Measurement command	MP		Enumerated(
			Setup,	
			Modify,	
			Release)	

10.3.7.47 Measurement control system information

Information element/Group name	Need	Multi	Type and reference	Semantics description
Use of HCS	MP		Enumerated (Not used, used)	Indicates if the serving cell belongs to a HCS structure
Cell selection and reselection quality measure	MP		Enumerated (CPICH Ec/N0, CPICH RSCP)	Choice of measurement (CPICH Ec/N0 or CPICH RSCP) to use as quality measure Q. NOTE: For TDD,each choice of this parameter represents PCCPCH RSCP.
Intra-frequency measurement system information	OP		Intra- frequency measuremen t system information 10.3.7.40	
Inter-frequency measurement system information	OP		Inter- frequency measuremen t system information 10.3.7.20	
Inter-RAT measurement system information	OP		Inter-RAT measuremen t system information 10.3.7.31	
Traffic volume measurement system information	OP		Traffic volume measuremen t system information 10.3.7.73	

10.3.7.48 Measurement Identity

A reference number that is used by the UTRAN at modification and release of the measurement, and by the UE in the measurement report.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Measurement identity	MP		Integer(116	
)	

10.3.7.49 Measurement reporting mode

Contains the type of Measurement Report transfer mode and the indication of periodical/event trigger.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Measurement Report Transfer Mode	MP		enumerated (Acknowledg ed mode RLC, Unacknowle dged mode RLC)	
Periodical Reporting / Event Trigger Reporting Mode	MP		Enumerated (Periodical reporting, Event trigger)	

10.3.7.50 Measurement Type

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Measurement Type	MP		Enumerated(Intra- frequency, Inter- frequency, Inter-RAT, Traffic volume, Quality, UE internal, UE positioning)	

10.3.7.51 Measurement validity

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
UE state	MP		Enumerated(
			CELL_DCH,	
			all states	
			except	
			CELL_DCH,	
			all states)	

10.3.7.52 Observed time difference to GSM cell

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Observed time difference to	OP		Integer(0,,40	According to GSM_TIME in
GSM cell			95)	[19] and [20]

10.3.7.53 Periodical reporting criteria

Contains the periodical reporting criteria information. It is necessary only in the periodical reporting mode.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Amount of reporting	MD		Integer(1, 2, 4, 8, 16, 32, 64, Infinity)	The default value is infinity.
Reporting interval	MP		Integer(250, 500, 1000, 2000, 3000, 4000, 6000, 8000, 12000, 24000, 28000, 32000, 64000)	Indicates the interval of periodical report. Interval in milliseconds

10.3.7.53aa Periodical reporting info-1b

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Amount of reporting	MP		Integer(1, 2, 4, 8, 16, 32, 64, Infinity)		REL-5
Reporting interval	MP		Integer(0, 250, 500, 1000, 2000, 4000, 8000, 16000)	Indicates the interval of periodical reporting when such reporting is triggered by an event. Interval in milliseconds. 0 means no periodical reporting.	REL-5

10.3.7.53a PLMN identities of neighbour cells

This IE contains the PLMN identities of neighbour cells.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
PLMNs of intra-frequency cells list	OP	1 to <maxcellm eas></maxcellm 		
>PLMN identity	MD		PLMN identity 10.3.1.11	Default value is the previous "PLMN identity" in the list. The default value for the first PLMN in the list is the identity of the selected PLMN if the "PLMN type" in the variable SELECTED_PLMN has the value "GSM-MAP"; otherwise, the first occurrence is MP.
PLMNs of inter-frequency cells list	OP	1 to <maxcellm eas></maxcellm 		

Information Element/Group name	Need	Multi	Type and reference	Semantics description
>PLMN identity	MD		PLMN identity 10.3.1.11	Default value is the previous "PLMN identity" in the list. The default value for the first PLMN in the list is the identity of the selected PLMN if the "PLMN type" in the variable SELECTED_PLMN has the value "GSM-MAP"; otherwise, the first occurrence is MP.
PLMNs of inter-RAT cells list	OP	1 to <maxcellm eas></maxcellm 		
>PLMN identity	MD		PLMN identity 10.3.1.11	Default value is the previous "PLMN identity" in the list. The default value for the first PLMN in the list is the identity of the selected PLMN if the "PLMN type" in the variable SELECTED_PLMN has the value "GSM-MAP"; otherwise, the first occurrence is MP.

10.3.7.54 Primary CCPCH RSCP info

NOTE: Only for TDD

Information Element/Group name	Need	Multi	IE type and reference	Semantics description	Version
Primary CCPCH RSCP	MP		Integer(0 91)	According to P- CCPCH_RSCP_LEV in [19] and [20]. Thirty-six spare values are needed.	
Delta _{Primary} CCPCH RSCP	CV-Rel5		Integer(- 51)	If present, the actual value of Primary CCPCH RSCP = Primary CCPCH RSCP+ Delta _{Primary} CCPCH RSCP	REL-5

Condition	Explanation
Rel5	This IE is mandatory if the value of Primary CCPCH
	RSCP is below 0. Othewise the IE is not needed.

10.3.7.54a Qhcs

Information Element/Group name	Need	Multi	Type and Referenc	Semantics description	Version
			е		

Information Element/Group name	Need	Multi	Type and Referenc e	Semantics description	Version
Qhcs	MP		Integer(099)	Qhcs, mapped from CPICH Ec/No (FDD), see [4] [dB] 0: -24 1: -23.5 2: -23 3: -22.5 45: -1.5 46: -1 47: -0.5 48: 0 49: (spare) 98: (spare) 99: (spare) Qhcs, mapped from CPICH RSCP (FDD), see [4] [dBm] 0: -115 1: -114 2: -113 : 88: -27 89: -26 90: -(spare) 91: -(spare) : 98: -(spare) 99: -(spare) 99: -(spare)	
				Qhcs, mapped from PCCPCH RSCP (TDD), see [4] [dBm] 0: -115 1: -114 2: -113 : 88: -27 89: -26 90: -(spare) 91: -(spare) : 98: -(spare) 99: -(spare)	

Information Element/Group name	Need	Multi	Type and Referenc e	Semantics description	Version
				Qhcs level, mapped from Averaged received signal level RSSI (GSM), see [4] [dBm] 0: -110 1: -109 2: -108 : 61: -49 62: -48 63: -47 64: -46 65: -45 66: -44 67: -43 68: -42 69: -41 70: -40 71: -39 72: -38 73: -37 74: -(spare) 99: -(spare)	
Delta _{Qhcs-RSCP}	CV- RSCP		Integer(- 51)	If present, the actual value of Qhcs = Qhcs + Delta _{Qhcs-RSCP}	REL-5

Condition	Explanation
	This IE is optional if Qhcs is mapped from CPICH RSCP or PCCPCH RSCP, and if the value of the RSCP is below 0 (-115dBm). It is not needed otherwise.

10.3.7.55 Quality measured results list

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
BLER measurement results	OP	1 to		
		<maxtrch< td=""><td></td><td></td></maxtrch<>		
		>		
>DL Transport channel identity	MP		Transport	transport channel type = DCH
			channel	
			identity	
			10.3.5.18	
>DL Transport Channel BLER	OP		Integer	According to BLER_LOG in
			(063)	[19] and [20]
CHOICE mode	MP			
>FDD				No data
>TDD				
>>SIR measurement results	OP	1 to		SIR measurements for DL
		<maxcctr< td=""><td></td><td>CCTrCH</td></maxcctr<>		CCTrCH
		CH>		
>>>TFCS ID	MP		Integer(18)	
>>>Timeslot list	MP	1 to		for all timeslot on which the
		<maxts></maxts>		CCTrCH is mapped on
>>>SIR	MP		Integer(063	According to UE_SIR in [20]
)	

10.3.7.56 Quality measurement

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Quality reporting quantity	OP		Quality reporting quantity 10.3.7.59	
CHOICE report criteria	MP			
>Quality measurement reporting criteria >Periodical reporting criteria			Quality measuremen t reporting criteria 10.3.7.58 Periodical reporting criteria 10.3.7.53	Note Given this choice, the IE "DL Transport Channel BLER" shall be set to "False" (see subclause 10.3.7.59) Note
>No reporting			13.3.1.33	Note (no data) Chosen when this measurement only is used as additional measurement to another measurement

NOTE: In this version of the specification, BLER as additional measurement is not supported.

10.3.7.57 Quality measurement event results

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Transport channels causing the event	OP	1 to <maxtrch ></maxtrch 		
>DL Transport channel identity	MP		Transport channel identity 10.3.5.18	transport channel type = DCH

10.3.7.58 Quality measurement reporting criteria

Event 5a: Number of bad CRCs on a certain transport channel exceeds a threshold.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Parameters sent for each transport channel	MP	1 to <maxtrch< td=""><td></td><td></td></maxtrch<>		
>DL Transport channel identity	MP		Transport channel identity 10.3.5.18	transport channel type = DCH
>Total CRC	MP		Integer(151 2)	Number of CRCs
>Bad CRC	MP		Integer(151 2)	Number of CRCs
>Pending after trigger	MP		Integer(151 2)	Number of CRCs

10.3.7.59 Quality reporting quantity

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
DL Transport Channel BLER	MP		Boolean	TRUE means report requested
Transport channels for BLER reporting	CV-BLER reporting	1 to <maxtrch ></maxtrch 		The default, if no transport channel identities are present, is that the BLER is reported for all downlink transport channels
>DL Transport channel identity	MP		Transport channel identity 10.3.5.18	transport channel type = DCH
CHOICE mode	MP			
>FDD				No data
>TDD				
>>SIR measurement list	OP	1 to <maxcctr CH></maxcctr 		SIR measurements shall be reported for all listed TFCS IDs
>>>TFCS ID	MP		Integer(18)	

Condition	Explanation
BLER reporting	This IE is not needed if the IE "DL Transport Channel BLER" is "False" and optional if the IE "DL Transport
	Channel BLER" is "True"

10.3.7.60 Reference time difference to cell

In the System Information message, the reference time difference to cell indicates the timing difference between the primary CCPCH of the current cell and the primary CCPCH of a neighbouring cell..

In the Measurement Control message, the reference time difference to cell indicates the timing difference between UE uplink transmission timing and the primary CCPCH of a neighbouring cell.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
CHOICE accuracy	MP			
>40 chips				
>>Reference time difference	MP		Integer(038 400 by step of 40)	In chips
>256 chips				
>>Reference time difference	MP		Integer(0 38400 by step of 256)	In chips
>2560 chips				
>>Reference time difference	MP		Integer(0 38400 by step of 2560)	In chips

10.3.7.61 Reporting Cell Status

Indicates maximum allowed number of cells to report and whether active set cells and/or virtual active set cells and/or monitored set cells on and/or detected set cells used frequency and/or monitored set cells on non used frequency should/should not be included in the IE "Measured results".

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE reported cell	MP			
>Report cells within active set				This choice is not valid for inter-RAT measurements. For inter-frequency measurements

Information Element/Group name	Need	Multi	Type and reference	Semantics description
				it is only valid for reporting events 2D and 2F. See NOTE 1.
>>Maximum number of reported cells	MP		Integer(16)	
>Report cells within monitored set cells on used frequency				This choice is not valid for inter-RAT or inter-frequency measurements
>>Maximum number of reported cells	MP		Integer(16)	
>Report cells within active set and/or monitored set cells on used frequency				This choice is not valid for inter-RAT or inter-frequency measurements
>>Maximum number of reported cells	MP		Integer(16)	
>Report cells within detected set on used frequency				This choice is not valid for inter-RAT or inter-frequency measurements
>>Maximum number of reported cells	MP		Integer(16)	
>Report cells within monitored set and/or detected set on used frequency				This choice is not valid for inter-RAT or inter-frequency measurements
>>Maximum number of reported cells	MP		Integer(16)	
>Report all active set cells + cells within monitored set on used frequency				This choice is not valid for inter-RAT or inter-frequency measurements
>>Maximum number of reported cells	MP		Enumerated (virtual/activ e set cells+1, virtual/active set cells+2,, virtual/active set cells+6)	
>Report all active set cells + cells within detected set on used frequency				This choice is not valid for inter-RAT or inter-frequency measurements
>>Maximum number of reported cells	MP		Enumerated (virtual/activ e set cells+1, virtual/active set cells+2,, virtual/active set cells+6)	
>Report all active set cells + cells within monitored set and/or detected set on used frequency				This choice is not valid for inter-RAT or inter-frequency measurements
>>Maximum number of reported cells	MP		Enumerated (virtual/active set cells+1, virtual/active set cells+2,, virtual/active set cells+6)	
>Report cells within virtual active set				This choice is not valid for intra-frequency or inter-RAT measurements
>>Maximum number of reported cells per reported non-used frequency	MP		Integer(16)	
>Report cells within monitored set on non-used frequency				This choice is not valid for intra-frequency or inter-RAT

Information Element/Group name	Need	Multi	Type and reference	Semantics description
				measurements
>>Maximum number of reported cells per reported non-used frequency	MP		Integer(16)	
>Report cells within monitored and/or virtual active set on non-used frequency				This choice is not valid for intra-frequency or inter-RAT measurements
>>Maximum number of reported cells per reported non-used frequency	MP		Integer(16)	
>Report all virtual active set cells + cells within monitored set on non-used frequency				This choice is not valid for intra-frequency or inter-RAT measurements
>>Maximum number of reported cells per reported non-used frequency	MP		Enumerated (virtual/activ e set cells+1, virtual/active set cells+2,, virtual/active set cells+6)	
>Report cells within active set or within virtual active set or of the other RAT				If this choice is selected for inter-RAT measurements, the UE shall report only cells of the other RAT. If this choice is selected for intra-frequency measurements, the UE shall report cells within the active set. If this choice is selected for inter-frequency measurements, the UE shall report cells within the virtual active set.
>>Maximum number of reported cells	MP		Integer (112)	
>Report cells within active and/or monitored set on used frequency or within virtual active and/or monitored set on non-used frequency				This choice is not valid for inter-RAT measurements. If this choice is selected for intra-frequency measurements, the UE shall report cells within the active and/or monitored set. If this choice is selected for inter-frequency measurements, the UE shall report cells within the virtual active set and/or monitored set on non-used frequency.
>>Maximum number of reported cells	MP		Integer(112	

NOTE 1: For Inter-frequency reporting events 2D and 2F, only CHOICE "Report cells within active set" is valid.

10.3.7.62 Reporting information for state CELL_DCH

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Intra-frequency reporting quantity	MP		Intra- frequency reporting quantity	
Measurement Reporting Mode	MP		10.3.7.41 Measuremen t Reporting Mode 10.3.7.49	
CHOICE report criteria	MP			
>Intra-frequency measurement reporting criteria			Intra- frequency measuremen t reporting criteria 10.3.7.39	
>Periodical reporting criteria			Periodical reporting criteria 10.3.7.53	

10.3.7.63 SFN-SFN observed time difference

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
CHOICE type	MP				
>Type 1			Integer(0 9830399)	According to T1_SFN-SFN_TIME in [19] and [20]. For FDD and 3.84 Mcps TDD: 6946816 spare values are needed.	
			Integer(0 3276799)	For 1.28 Mcps TDD: 13500416 spare values are needed.	Rel-4
>Type 2			Integer(0 40961)	According to T2_SFN-SFN_TIME in [19] and [20]. 24574 spare values are needed.	
			Integer(0 27649)	For 1.28 Mcps TDD: 37886 spare values are needed.	Rel-4

10.3.7.64 Time to trigger

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Time to trigger	MP		Integer(0,	Time in ms
			10, 20, 40,	
			60, 80, 100,	
			120, 160,	
			200, 240,	
			320, 640,	
			1280, 2560,	
			5000)	

10.3.7.65 Timeslot ISCP info

NOTE: Only for TDD

Information Element/Group	Need	Multi	IE type and	Semantics description
name			reference	
Timeslot ISCP	MP		Integer	According to
			(091)	UE_TS_ISCP_LEV in [20].
				Thirty-six spare values are
				needed.

10.3.7.66 Traffic volume event identity

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Traffic volume event identity	MP		Enumerated(4a, 4b)	

10.3.7.67 Traffic volume measured results list

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Traffic volume measurement	OP	1 to		
results		<maxrb></maxrb>		
>RB Identity	MP		RB Identity	
			10.3.4.16	
>RLC Buffers Payload	OP		Enumerated(In bytes
			0, 4, 8, 16,	And N Kbytes = N*1024 bytes.
			32, 64, 128,	Twelve spare values are
			256, 512,	needed.
			1024, 2K,	
			4K, 8K, 16K,	
			32K, 64K,	
			128K, 256K,	
			512K,	
			1024K)	
>Average of RLC Buffer Payload	OP		Enumerated(In bytes
			0, 4, 8, 16,	And N Kbytes = N*1024 bytes.
			32, 64, 128,	Twelve spare values are
			256, 512,	needed.
			1024, 2K,	
			4K, 8K, 16K,	
			32K, 64K,	
			128K, 256K,	
			512K,	
			1024K)	
>Variance of RLC Buffer	OP		Enumerated(In bytes
Payload			0, 4, 8, 16,	And N Kbytes = N*1024 bytes.
			32, 64, 128,	Two spare values are needed.
			256, 512,	,
			1024, 2K,	
			4K, 8K, 16K)	

10.3.7.68 Traffic volume measurement

Information Element/Group name	Need	Multi	Type and reference	Semantics description
	OD			
Traffic volume measurement	OP		Traffic	
Object			volume	
			measuremen	
			t Object	
			10.3.7.70	
Traffic volume measurement	OP		Traffic	
quantity			volume	
			measuremen	
			t quantity	
			10.3.7.71	
Traffic volume reporting quantity	OP		Traffic	
a commence of the commence of			volume	
			reporting	
			quantity	
			10.3.7.74	
Measurement validity	OP		Measuremen	
Weasurement validity	Oi		t validity	
			10.3.7.51	
CHOICE was not a mita mia	MD		10.3.7.51	
CHOICE report criteria	MP		T ("	
>Traffic volume measurement			Traffic	
reporting criteria			volume	
			measuremen	
			t reporting	
			criteria	
			10.3.7.72	
>Periodical reporting criteria			Periodical	
			reporting	
			criteria	
			10.3.7.53	
>No reporting				(no data)
1 3				Chosen when this
				measurement only is used as
				additional measurement to
				another measurement
			1	another measurement

10.3.7.69 Traffic volume measurement event results

Contains the event result for a traffic volume measurement.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Uplink transport channel type causing the event	MP		Enumerated(DCH,RACHo rCPCH,USC H)	USCH is TDD only. CPCH is FDD only. RACHorCPCH is the currently configured default in the uplink.
UL Transport Channel identity	CV-UL- DCH/USC H		Transport channel identity 10.3.5.18	
Traffic volume event identity	MP		Traffic volume event identity 10.3.7.66	

Condition	Explanation
UL-DCH/USCH	If IE "Uplink transport channel type" is equal to "DCH" or "USCH" (TDD only) this IE is mandatory present.
	Otherwise the IE is not needed.

10.3.7.70 Traffic volume measurement object

Contains the measurement object information for a traffic volume measurement.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Traffic volume measurement objects	MP	1 to <maxtrch ></maxtrch 		
>Uplink transport channel type	MP		Enumerated(DCH,RACHo rCPCH,USC H)	USCH is TDD only. CPCH is FDD only. RACHorCPCH is the currently configured default in the uplink.
>UL Target Transport Channel ID	CV-UL- DCH/USC H		Transport channel identity 10.3.5.18	

Condition	Explanation
UL-DCH/USCH	If IE "Uplink transport channel type" is equal to "DCH" or "USCH" (TDD only) this IE is mandatory present.
	Otherwise the IE is not needed.

10.3.7.71 Traffic volume measurement quantity

Contains the measurement quantity information for a traffic volume measurement.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Measurement quantity	MP		Enumerated(RLC buffer payload, Average RLC buffer payload, Variance of RLC buffer payload)	This parameter should be ignored.
Time Interval to take an average or a variance	CV-A/V		Integer(20, 40,260, by steps of 20)	In ms

Condition	Explanation
A/V	This IE is mandatory present when "Average RLC
	buffer" or "Variance of RLC buffer payload" is chosen
	and not needed otherwise.

10.3.7.72 Traffic volume measurement reporting criteria

Contains the measurement reporting criteria information for a traffic volume measurement.

Event 4a: Transport Channel Traffic Volume [15] exceeds an absolute threshold.

Event 4b: Transport Channel Traffic Volume [15] becomes smaller than an absolute threshold.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Parameters sent for each transport channel	OP	1 to <maxtrch ></maxtrch 		This IE is always required, need is OP to align with ASN.1
>Uplink transport channel type	OP		Enumerated(DCH,RACHo rCPCH,USC H)	USCH is TDD only. CPCH is FDD only. RACHorCPCH is the currently configured default in the uplink.
>UL Transport Channel ID	CV-UL- DCH/USC H		Transport channel identity 10.3.5.18	
>Parameters required for each Event	OP	1 to <maxmeas parEvent></maxmeas 		
>>Traffic volume event identity	MP		Traffic volume event identity 10.3.7.66	
>>Reporting Threshold	MP		Enumerated(8,16,32,64,1 28,256,512,1 024,2K,3K,4 K,6K,8K,12K ,16K,24K,32 K,48K,64K,9 6K,128K,192 K,256K,384 K,512K,768 K)	Threshold in bytes And N Kbytes = N*1024 bytes
>>Time to trigger	OP		Time to trigger 10.3.7.64	Indicates the period of time during which the event condition has to be satisfied, before sending a Measurement Report. Time in ms
>>Pending time after trigger	OP		Integer(250, 500, 1000, 2000, 4000, 8000, 16000)	Indicates the period of time during which it is forbidden to send any new measurement reports with the same Traffic volume event identity even if the triggering condition is fulfilled. Time in milliseconds
>>Tx interruption after trigger	OP		Integer (250, 500, 1000, 2000, 4000, 8000, 16000)	Time in milliseconds. Indicates how long the UE shall block DTCH transmissions on the RACH after a measurement report is triggered.

Condition	Explanation
UL-DCH/USCH	If IE "Uplink transport channel type" is equal to "DCH" or "USCH" (TDD only) this IE is optional. Otherwise
	the IE is not needed.

10.3.7.73 Traffic volume measurement system information

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Traffic volume measurement identity	MD		Measuremen t identity 10.3.7.48	The traffic volume measurement identity has default value 4.
Traffic volume measurement object	OP		Traffic volume measuremen t object 10.3.7.70	
Traffic volume measurement quantity	OP		Traffic volume measuremen t quantity 10.3.7.71	
Traffic volume reporting quantity	OP		Traffic volume reporting quantity 10.3.7.74	
Measurement validity	OP		Measuremen t validity 10.3.7.51	
Measurement Reporting Mode	MP		Measuremen t Reporting Mode 10.3.7.49	
CHOICE reporting criteria	MP			
>Traffic volume measurement reporting criteria			Traffic volume measuremen t reporting criteria 10.3.7.72	
>Periodical reporting criteria			Periodical reporting criteria 10.3.7.53	

10.3.7.74 Traffic volume reporting quantity

Contains the reporting quantity information for a traffic volume measurement.

For all boolean types TRUE means inclusion in the report is requested.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
RLC Buffer Payload for each RB	MP		Boolean	
Average of RLC Buffer Payload for each RB	MP		Boolean	
Variance of RLC Buffer Payload for each RB	MP		Boolean	

10.3.7.75 UE internal event identity

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
UE internal event identity	MP		Enumerated(
			6a,6b,6c,6d,	
			6e, 6f, 6g)	

10.3.7.76 UE internal measured results

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			reference	description	
CHOICE mode	MP				
>FDD					
>>UE Transmitted Power	ОР		UE Transmitted Power info 10.3.7.85		
>>UE Rx-Tx report entries	OP	1 to <maxrl></maxrl>			
>>>Primary CPICH info	MP		Primary CPICH info 10.3.6.60	Primary CPICH info for each cell included in the active set	
>>>UE Rx-Tx time difference type 1	MP		UE Rx-Tx time difference type 1 10.3.7.83	UE Rx-Tx time difference in chip for each RL included in the active set	
>TDD					
>>UE Transmitted Power list	OP	1 to <maxts></maxts>		UE Transmitted Power for each used uplink timeslot in ascending timeslot number order	
>>>UE Transmitted Power	MP		UE Transmitted Power info 10.3.7.85		
>>CHOICE TDD option	MP				REL-4
>>>3.84 Mcps TDD					REL-4
>>>Applied TA	ОР		Uplink Timing Advance 10.3.6.95	Uplink timing advance applied by the UE	
>>>1.28 Mcps TDD					REL-4
>>>>T _{ADV}	OP		T _{ADV} info 10.3.7.112		REL-4

10.3.7.77 UE internal measurement

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
UE internal measurement	OP		UE internal	
quantity			measuremen	
			t quantity	
			10.3.7.79	
UE internal reporting quantity	OP		UE internal	
			reporting	
			quantity	
			10.3.7.82	
CHOICE report criteria	MP			
>UE internal measurement			UE internal	
reporting criteria			measuremen	
			t reporting	
			criteria	
B 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1			10.3.7.80	
>Periodical reporting criteria			Periodical	
			reporting	
			criteria	
No servention			10.3.7.53	/\\\\\\\\\\-
>No reporting				(no data) Chosen when this
				measurement only is used as additional measurement to
				another measurement
		l	1	anomer measurement

CHOICE report criteria	Condition under which the given report criteria is chosen
UE internal measurement reporting criteria	Chosen when UE internal measurement event triggering is required
Periodical reporting criteria	Chosen when periodical reporting is required
No reporting	Chosen when this measurement only is used as additional measurement to another measurement

10.3.7.78 UE internal measurement event results

This IE contains the measurement event results that are reported to UTRAN for UE internal measurements.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
UE internal event identity	MP		UE internal event identity 10.3.7.75	
CHOICE mode	MP			
>FDD				
>Primary CPICH info	CV-clause 1		Primary CPICH info 10.3.6.60	
>TDD				(no data)

Condition	Explanation
Clause 1	This IE is mandatory present if the IE "UE internal
	event identity" is set to "6f" or "6g", otherwise the IE is not needed.
	Hot needed.

10.3.7.79 UE internal measurement quantity

The quantity the UE shall measure in case of UE internal measurement.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
CHOICE mode	MP				
>FDD					
>>Measurement quantity	MP		Enumerated(UE Transmitted Power, UTRA Carrier RSSI, UE Rx-Tx time difference)		
>TDD					
>>Measurement quantity	MP		Enumerated(UE Transmitted Power, UTRA Carrier RSSI, TADV)	Measurement on Timing Advance is for 1.28 Mcps	REL-4
Filter coefficient	OP		Filter coefficient 10.3.7.9	If the IE "Measurement quantity" is set to "Rx-Tx time difference" and this IE is present, the UE behaviour is unspecified.	

10.3.7.80 UE internal measurement reporting criteria

The triggering of the event-triggered reporting for a UE internal measurement. All events concerning UE internal measurements are labelled 6x where x is a, b, c.... In TDD, the events 6a - 6d are measured and reported on timeslot basis.

Event 6a: The UE Transmitted Power becomes larger than an absolute threshold

Event 6b: The UE Transmitted Power becomes less than an absolute threshold

Event 6c: The UE Transmitted Power reaches its minimum value

Event 6d: The UE Transmitted Power reaches its maximum value

Event 6e: The UE RSSI reaches the UEs dynamic receiver range

Event 6f (FDD): The UE Rx-Tx time difference for a RL included in the active set becomes larger than an absolute threshold

Event 6f (1.28 Mcps TDD): The time difference indicated by T_{ADV} becomes larger than an absolute threshold

Event 6g: The UE Rx-Tx time difference for a RL included in the active set becomes less than an absolute threshold

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Parameters sent for each UE	OP	1 to			
internal measurement event		<maxmeas< td=""><td></td><td></td><td></td></maxmeas<>			
		Event>			
>UE internal event identity	MP		UE internal		
			event		
			identity		
			10.3.7.75		

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			reference	description	
>Time-to-trigger	MP		Integer(0, 10, 20, 40, 60, 80, 100, 120, 160, 200, 240, 320, 640, 1280, 2560, 5000)	Time in ms. Indicates the period of time between the timing of event detection and the timing of sending Measurement Report.	
>UE Transmitted Power Tx power threshold	CV-clause 1		Integer(- 5033)	Power in dBm. In event 6a, 6b.	
>UE Rx-Tx time difference threshold	CV-clause 2		Integer(768 1280)	Time difference in chip. In event 6f, 6g.	
>T _{ADV} threshold	CV-clause 3		Real (063 step 0.125)	Time difference in chip. In event 6f	REL-4

Condition	Explanation
Clause 1	The IE is mandatory present if the IE "UE internal event identity" is set to "6a" or "6b", otherwise the IE is not needed.
Clause 2	In FDD, the IE is mandatory present if the IE "UE internal event identity" is set to "6f" or "6g", otherwise the IE is not needed.
Clause 3	In 1.28 Mcps TDD the IE is mandatory present if the IE "UE internal event identity" is set to "6f", otherwise the IE is not needed.

10.3.7.81 Void

10.3.7.82 UE Internal reporting quantity

For all boolean types TRUE means inclusion in the report is requested.

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			reference	description	
UE Transmitted Power	MP		Boolean		
CHOICE mode	MP				
>FDD					
>>UE Rx-Tx time difference	MP		Boolean		
>TDD					
>>CHOICE TDD option					REL-4
>>>3.84 Mcps TDD				(no data)	REL-4
>>Applied TA	MP		Boolean		
>>>1.28 Mcps TDD					REL-4
>>>>T _{ADV} info	MP		Boolean		REL-4

10.3.7.83 UE Rx-Tx time difference type 1

The difference in time between the UE uplink DPCCH/DPDCH frame transmission and the first detected path (in time), of the downlink DPCH frame from the measured radio link, as defined in [7]. This measurement is for FDD only.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
UE Rx-Tx time difference type 1	MP		Integer(768	In chips.
			1280)	511 spare values are needed.

10.3.7.84 UE Rx-Tx time difference type 2

The difference in time between the UE uplink DPCCH/DPDCH frame transmission and the first detected path (in time), of the downlink DPCH frame from the measured radio link, as defined in [7].

Information Element/Group name	Need	Multi	Type and reference	Semantics description
UE Rx-Tx time difference type 2	MP		Integer (08191)	According to [19].

10.3.7.85 UE Transmitted Power info

Information Element/Group name	Need	Multi	IE type and reference	Semantics description
UE Transmitted Power	MP		Integer (0104)	According to UE_TX_POWER in [19] and [20]

10.3.7.86 UE positioning Ciphering info

This IE contains information for the ciphering of UE positioning assistance data broadcast in System Information.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
Ciphering Key Flag	MP		Bit string(1)	
Ciphering Serial Number	MP		Integer(065 535)	The serial number used in the DES ciphering algorithm

10.3.7.87 UE positioning Error

Information Element/Group	Need	Multi	Type and Reference	Semantics description
name Error reason	MP		Enumerated(Not Enough OTDOA Cells, Not Enough GPS Satellites, Assistance Data Missing, Not Accomplishe d GPS Timing Of Cell Frames, Undefined Error, Request Denied By User, Not Processed And Timeout, Reference Cell Not	Note 1
GPS Additional Assistance Data Request	CV- GPSdataM issing		Serving Cell) UE positioning GPS Additional Assistance Data Request 10.3.7.88a	

NOTE 1: The following table describes each value of the IE "Error reason".

Value	Indication
Not Enough OTDOA Cells	There were not enough cells to be received.
Not Enough GPS Satellites	There were not enough GPS satellites to be received.
Assistance Data Missing	UE positioning GPS assistance data missing.
Not Accomplished GPS	UE was not able to accomplish the GPS timing of cell frames measurement.
Timing Of Cell Frames	
Undefined Error	Undefined error.
Request Denied By User	UE positioning request denied by upper layers.
Not Processed And	UE positioning request not processed by upper layers and timeout.
Timeout	
Reference Cell Not Serving	UE was not able to read the SFN of the reference cell.
Cell	

Condition	Explanation
GPSdataMissing	The IE is optional if the IE "Error reason" is "
	Assistance Data Missing " and not needed otherwise.

10.3.7.88 UE positioning GPS acquisition assistance

This IE contains parameters that enable fast acquisition of the GPS signals in UE-assisted GPS positioning.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
GPS TOW msec	MP		Integer(06.	GPS Time of Week in

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
			048*10 ⁸ -1)	milliseconds rounded down to the nearest millisecond unit. It is also the time when satellite information is valid.
UTRAN GPS reference time	OP			
>UTRAN GPS timing of cell frames	MP		Integer(0 2322431999 999)	GPS timing of cell frames in steps of 1 chip.
>CHOICE mode	OP			
>>FDD				
>>>Primary CPICH Info	MP		Primary CPICH Info 10.3.6.60	Identifies the reference cell for the GPS TOW-SFN relationship
>>TDD				
>>>cell parameters id	MP		Cell parameters id 10.3.6.9	Identifies the reference cell for the GPS TOW-SFN relationship
>SFN	MP		Integer(040 95)	The SFN which the UTRAN GPS timing of cell frames time stamps.
Satellite information	MP	1 to <maxsat></maxsat>		
>SatID	MP		Integer (063)	Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [12].
>Doppler (0 th order term)	MP		Real(- 51205117.5 by step of 2.5)	Hz
>Extra Doppler	OP			
>>Doppler (1 st order term)	MP		Real (- 0.9660.483 by step of 0.023)	Scaling factor 1/42
>>Doppler Uncertainty	MP		Enumerated (12.5,25,50, 100,200)	Hz. Three spare values are needed.
>Code Phase	MP		Integer(010 22)	Chips, specifies the centre of the search window
>Integer Code Phase	MP		Integer(019	1023 chip segments
>GPS Bit number	MP		Integer(03)	Specifies GPS bit number (20 1023 chip segments)
>Code Phase Search Window	MP		Integer(1023 ,1,2,3,4,6,8,1 2,16,24,32,4 8,64,96,128, 192)	Specifies the width of the search window.
>Azimuth and Elevation	OP			
>>Azimuth	MP		Real(0348. 75 by step of 11.25)	Degrees
>>Elevation	MP		Real(078.7 5 by step of 11.25)	Degrees

10.3.7.88a UE positioning GPS Additional Assistance Data Request

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
Almanac	MP		Boolean	TRUE means requested
UTC Model	MP		Boolean	TRUE means requested
Ionospheric model	MP		Boolean	TRUE means requested

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
Navigation Model	MP		Boolean	TRUE means requested
DGPS Corrections	MP		Boolean	TRUE means requested
Reference Location	MP		Boolean	TRUE means requested
Reference Time	MP		Boolean	TRUE means requested
Acquisition Assistance	MP		Boolean	TRUE means requested
Real-Time Integrity	MP		Boolean	TRUE means requested
Navigation Model Additional data	CV- Navigation Model			this IE is present only if "Navigation Model" is set to TRUE otherwise it is absent
>GPS Week	MP		Integer (01023)	THOSE SHIP MICE IN IS ABSOLU
>GPS_Toe	MP		Integer (0167)	GPS time of ephemeris in hours of the latest ephemeris set contained by the UE. Eighty-eight spare values needed.
>T-Toe limit	MP		Integer (010)	ephemeris age tolerance of the UE to UTRAN in hours. Five spare values needed.
>Satellites list related data	MP	0 to <maxsat></maxsat>		
>>SatID	MP		Integer (063)	Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [12].
>>IODE	MP		Integer (0255)	Issue of Data Ephemeris for SatID

10.3.7.89 UE positioning GPS almanac

This IE contains a reduced-precision subset of the ephemeris and clock correction parameters.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
WNa	MP		Bit string(8)	Almanac Reference Week [12]
Satellite information	MP	1 to		
		<maxsat></maxsat>		
>DataID	MP		Integer(03)	See [12]
>SatID	MP		Enumerated(Identifies the satellite and is
			063)	equal to (SV ID No - 1) where
				SV ID No is defined in [12].
>e	MP		Bit string(16)	Eccentricity [12]
>t _{oa}	MP		Bit string(8)	Reference Time of Almanac [12]
>δi	MP		Bit string(16)	
>OMEGADOT	MP		Bit string(16)	Longitude of Ascending Node of Orbit Plane at Weekly Epoch (semi-circles/sec) [12]
>SV Health	MP		Bit string(8)	, <u> </u>
>A ^{1/2}	MP		Bit string(24)	Semi-Major Axis (meters) ^{1/2} [12]
>OMEGA ₀	MP		Bit string(24)	Longitude of Ascending Node of Orbit Plane at Weekly Epoch (semi-circles) [12]
>M ₀	MP		Bit string(24)	Mean Anomaly at Reference Time (semi-circles) [12]
>ω	MP		Bit string(24)	Argument of Perigee (semicircles) [12]
>af ₀	MP		Bit string(11)	apparent clock correction [12]
>af ₁	MP		Bit string(11)	apparent clock correction [12]
SV Global Health	OP		Bit	This enables GPS time
			string(364)	recovery and possibly
				extended GPS correlation
				intervals. It is specified in page 25 of subframes 4 and 5 [12]

10.3.7.90 UE positioning GPS assistance data

This IE contains GPS assistance data.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
UE positioning GPS reference time	OP		UE positioning GPS reference time 10.3.7.96	
UE positioning GPS reference UE position	OP		Ellipsoid point with altitude and uncertainty ellipsoid 10.3.8.4c	A priori knowledge of UE 3-D position.
UE positioning GPS DGPS corrections	OP		UE positioning GPS DGPS corrections 10.3.7.91	

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
UE positioning GPS navigation model	OP		UE positioning GPS navigation model	
UE positioning GPS ionospheric model	OP		10.3.7.94 UE positioning GPS ionospheric model 10.3.7.92	
UE positioning GPS UTC model	OP		UE positioning GPS UTC model 10.3.7.97	
UE positioning GPS almanac	OP		UE positioning GPS almanac 10.3.7.89	
UE positioning GPS acquisition assistance	OP		UE positioning GPS acquisition assistance 10.3.7.88	
UE positioning GPS real-time integrity	OP		UE positioning GPS real- time integrity 10.3.7.95	

10.3.7.90a Void

10.3.7.91 UE positioning GPS DGPS corrections

This IE contains DGPS corrections to be used by the UE.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
GPS TOW sec	MP		Integer(060 4799)	seconds GPS time-of-week when the DGPS corrections were calculated
Status/Health	MP		Enumerated(UDRE scale 1.0, UDRE scale 0.75, UDRE scale 0.5, UDRE scale 0.3, UDRE scale 0.2, UDRE scale 0.1, no data, invalid data)	
DGPS information	CV- Status/Hea Ith	1 to <maxsat></maxsat>	·	If the Cipher information is included these fields are ciphered.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
>SatID	MP		Enumerated (063)	Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [12].
>IODE	MP		Integer(025 5)	
>UDRE	MP		Enumerated(UDRE \leq 1.0 m, 1.0m < UDRE \leq 4.0m, 4.0m < UDRE \leq 8.0m, 8.0m < UDRE)	The value in this field shall be multiplied by the UDRE Scale Factor in the IE Status/Health to determine the final UDRE estimate for the particular satellite.
>PRC	MP		Real(- 655.04655. 04 by step of 0.32)	meters (different from [13])
>RRC	MP		Real(- 4.0644.064 by step of 0.032)	meters/sec (different from [13])
>Delta PRC2	MP		Integer(- 127127)	In this version of the protocol this IE should be set to zero and the UE shall ignore it
>Delta RRC2	MP		Real(- 0.2240.224 by step of 0.032)	In this version of the protocol this IE should be set to zero and the UE shall ignore it
>Delta PRC3	OP		Integer(- 127127)	This IE should not be included in this version of the protocol and if received the UE shall ignore it
>Delta RRC3	OP		Real(- 0.2240.224 by step of 0.032)	This IE should not be included in this version of the protocol and if received the UE shall ignore it

Condition	Explanation
Status/Health	This IE is mandatory present if "status" is not equal to
	"no data" or "invalid data", otherwise the IE is not
	needed.

10.3.7.91a UE positioning GPS Ephemeris and Clock Correction parameters

This IE contains information for GPS ephemeris and clock correction.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
C/A or P on L2	MP		Bit string(2)	Code(s) on L2 Channel [12]
URA Index	MP		Bit string(4)	User Range Accuracy [12]
SV Health	MP		Bit string(6)	[12]
IODC	MP		Bit string(10)	Issue of Data, Clock [12]
L2 P Data Flag	MP		Bit string(1)	[12]
SF 1 Reserved	MP		Bit string(87)	[12]
T _{GD}	MP		Bit string(8)	Estimated group delay differential [12]
toc	MP		Bit string(16)	apparent clock correction [12]
af ₂	MP		Bit string(8)	apparent clock correction [12]

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
af ₁	MP		Bit string(16)	apparent clock correction [12]
af ₀	MP		Bit string(22)	apparent clock correction [12]
C _{rs}	MP		Bit string(16)	Amplitude of the Sine Harmonic Correction Term to the Orbit Radius (meters) [12]
Δη	MP		Bit string(16)	Mean Motion Difference From Computed Value (semi- circles/sec) [12]
M ₀	MP		Bit string(32)	Mean Anomaly at Reference Time (semi-circles) [12]
Cuc	MP		Bit string(16)	Amplitude of the Cosine Harmonic Correction Term To The Argument Of Latitude (radians) [12]
е	MP		Bit string(32)	С
Cus	MP		Bit string(16)	Amplitude of the Sine Harmonic Correction Term To The Argument Of Latitude (radians) [12]
(A) ^{1/2}	MP		Bit string(32)	Semi-Major Axis (meters) ^{1/2} [12]
toe	MP		Bit string(16)	Reference Time Ephemeris [12]
Fit Interval Flag	MP		Bit string(1)	[12]
AODO	MP		Bit string(5)	Age Of Data Offset [12]
C _{ic}	MP		Bit string(16)	Amplitude of the Cosine Harmonic Correction Term To The Angle Of Inclination (radians) [12]
OMEGA ₀	MP		Bit string(32)	Longitude of Ascending Node of Orbit Plane at Weekly Epoch (semi-circles) [12]
C _{is}	MP		Bit string(16)	Amplitude of the Sine Harmonic Correction Term To The Angle Of Inclination (radians) [12]
i ₀	MP		Bit string(32)	Inclination Angle at Reference Time (semi-circles) [12]
C _{rc}	MP		Bit string(16)	Amplitude of the Cosine Harmonic Correction Term to the Orbit Radius (meters) [12]
ω	MP		Bit string(32)	Argument of Perigee (semi- circles) [12]
OMEGAdot	MP		Bit string(24)	Longitude of Ascending Node of Orbit Plane at Weekly Epoch (semi-circles/sec) [12]
Idot	MP		Bit string(14)	Rate of Inclination Angle (semi-circles/sec) [12]

10.3.7.92 UE positioning GPS ionospheric model

The IE contains fields needed to model the propagation delays of the GPS signals through the ionosphere.

Information Element/Group	Need	Multi	Type and	Semantics description
name			Reference	
α_0	MP		Bit string(8)	Note 1
α_1	MP		Bit string(8)	Note 1
α_2	MP		Bit string(8)	Note 1
α ₃	MP		Bit string(8)	Note 1
β_0	MP		Bit string(8)	Note 2
β ₁	MP		Bit string(8)	Note 2
β_2	MP		Bit string(8)	Note 2
β ₃	MP		Bit string(8)	Note 2

NOTE 1: The parameters αn are the coefficients of a cubic equation representing the amplitude of the vertical delay [12].

NOTE 2: The parameters β n are the coefficients of a cubic equation representing the period of the ionospheric model [12].

10.3.7.93 UE positioning GPS measured results

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
CHOICE Reference Time	MP			
>UTRAN reference time				
>>UE GPS timing of cell frames	MP		Integer(0 3715891199 9999	GPS Time of Week in units of 1/16 th UMTS chips according to [19]. 33209832177664 spare values are needed.
>>CHOICE mode	MP			
>>>FDD				
>>>>Primary CPICH Info	MP		Primary CPICH Info 10.3.6.60	Identifies the reference cell for the GPS TOW-SFN relationship.
>>>TDD				
>>>cell parameters id	MP		Cell parameters id 10.3.6.9	Identifies the reference cell for the GPS TOW-SFN relationship.
>>Reference SFN	MP		Integer(040 95)	The SFN for which the location is valid. This IE indicates the SFN at which the UE timing of cell frames is captured.
>GPS reference time only				
>>GPS TOW msec	MP		Integer(06. 048*10 ⁸ -1)	GPS Time of Week in milliseconds (rounded down to the nearest millisecond unit). This time is the GPS TOW measured by the UE.
Measurement Parameters	MP	1 to <maxsat></maxsat>		
>Satellite ID	MP		Enumerated(063)	
>C/N _o	MP		Integer(063	the estimate of the carrier-to- noise ratio of the received signal from the particular satellite used in the measurement. It is given in units of dB-Hz (typical levels will be in the range of 20 – 50 dB-Hz).

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
>Doppler	MP		Integer(- 327683276 8)	Hz, scale factor 0.2.
>Whole GPS Chips	MP		Integer(010 22)	Unit in GPS chips.
>Fractional GPS Chips	MP		Integer(0(2 ¹ 0-1))	Scale factor 2 ⁻¹⁰
>Multipath Indicator	MP		Enumerated(NM, low, medium, high)	Note 1.
>Pseudorange RMS Error	MP		Enumerated(range index 0range index 63)	Note 2.

NOTE 1: The following table gives the mapping of the multipath indicator field.

Value	Multipath Indication
NM	Not measured
Low	MP error < 5m
Medium	5m < MP error < 43m
High	MP error > 43m

NOTE 2: The following table gives the bitmapping of the Pseudorange RMS Error field.

Range Index	Mantissa	Exponent	Floating-Point value, x _i	Pseudorange value, P
0	000	000	0.5	P < 0.5
1	001	000	0.5625	0.5 <= P < 0.5625
I	X	Y	0.5 * (1 + x/8) * 2 ^y	$X_{i-1} \leq P \leq X_i$
62	110	111	112	104 <= P < 112
63	111	111		112 <= P

10.3.7.94 UE positioning GPS navigation model

This IE contain information required to manage the transfer of precise navigation data to the GPS-capable UE.

Information Element/Group	Need	Multi	Type and	Semantics description
name			Reference	
Satellite information	MP	1 to		
		<maxsat></maxsat>		
>SatID	MP		Enumerated(Identifies the satellite and is
			063)	equal to (SV ID No - 1) where
				SV ID No is defined in [12].
>Satellite Status	MP		Enumerated(NOTE
			NS_NN,	
			ES_SN,	
			ES_NN,	
			REVD)	
>GPS Ephemeris and Clock	CV-		UE	
Correction parameters	Satellite		positioning	
	status		GPS	
			Ephemeris	
			and Clock	
			Correction	
			parameters	

Information Element name	/Group	Need	Multi	Type and Reference	Semantics description
				10.3.7.91a	

NOTE: The UE shall interpret enumerated symbols as follows.

Value	Indication
NS_NN	New satellite, new Navigation Model
ES_SN	Existing satellite, same Navigation Model
ES_NN	Existing satellite, new Navigation Model
REVD	Reserved

Condition	Explanation
Satellite status	The IE is not needed if the IE "Satellite status" is
	ES_SN and mandatory present otherwise.

10.3.7.95 UE positioning GPS real-time integrity

This IE contains parameters that describe the real-time status of the GPS constellation.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
Satellite information	MP	1 to <maxsat></maxsat>		
>BadSatID	MP		Enumerated(063)	Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [12].

10.3.7.95a Void

10.3.7.96 UE positioning GPS reference time

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
GPS Week	MP		Integer(010 23)	
GPS TOW msec	MP		Integer(06. 048*10 ⁸ -1)	GPS Time of Week in milliseconds (rounded down to the nearest millisecond unit).
UTRAN GPS reference time	OP			
>UTRAN GPS timing of cell frames	MP		Integer(0 2322431999 999)	UTRAN GPS timing of cell frames in steps of 1 chip
>CHOICE mode	OP			
>>FDD				
>>>Primary CPICH Info	MP		Primary CPICH Info 10.3.6.60	Identifies the reference cell for the GPS TOW-SFN relationship
>>TDD				
>>>cell parameters id	MP		Cell parameters id 10.3.6.9	Identifies the reference cell for the GPS TOW-SFN relationship
>SFN	MP		Integer(040 95)	The SFN which the UTRAN GPS timing of cell frames time stamps.
SFN-TOW Uncertainty	OP		Enumerated (lessThan10, moreThan10	This field indicates the uncertainty of the relation GPS TOW/SFN. lessThan10 means the relation is accurate to at

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
				least 10 ms.
Tutran-gps drift rate	OP		Integer (0, 1, 2, 5, 10, 15, 25, 50, -1, - 2, -5, -10, - 15, -25, -50)	in 1/256 chips per sec.
GPS TOW Assist	OP	1 to <maxsat></maxsat>		
>SatID	MP		Enumerated(063)	Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [12].
>TLM Message	MP		Bit string(14)	
>TLM Reserved	MP		Bit string(2)	
>Alert	MP		Boolean	
>Anti-Spoof	MP		Boolean	

10.3.7.97 UE positioning GPS UTC model

The UTC Model field contains a set of parameters needed to relate GPS time to Universal Time Coordinate (UTC).

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
A ₁	MP		Bit string(24)	sec/sec [12]
A ₀	MP		Bit string(32)	seconds [12]
t _{ot}	MP		Bit string(8)	seconds [12]
WN _t	MP		Bit string(8)	weeks [12]
Δt_{LS}	MP		Bit string(8)	seconds [12]
WN _{LSF}	MP		Bit string(8)	weeks [12]
DN	MP		Bit string(8)	days [12]
Δt_{LSF}	MP		Bit string(8)	seconds [12]

10.3.7.98 UE positioning IPDL parameters

This IE contains parameters for the IPDL mode. The use of this parameters is described in [29].

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			Reference	description	
CHOICE mode					REL-4
>FDD					REL-4
>>IP spacing	MP		Integer(5,7,1 0,15,20,30,4 0,50)	See [29]	
>>IP length	MP		Integer(5,10)	See [29]	
>>IP offset	MP		Integer(09)	See [29]	
>>Seed	MP		Integer(063	See [29]	
>TDD					REL-4
>>IP spacing	MP		Integer(30,4 0,50,70,100)	See [33]	REL-4
>>IP_Start	MP		Integer(040 95)	See [33]	REL-4
>>IP_Slot	MP		Integer(014	See [33]	REL-4
>>IP_PCCPCH	CV- channel		Boolean	See [33]	REL-4
Burst mode parameters	OP				
>Burst Start	MP		Integer(015	See [29] and [33]	
>Burst Length	MP		Integer(102 5)	See [29] and [33]	

Information Element/Group name	Need	Multi	Type and Reference	Semantics description	Version
>Burst freq	MP		Integer(116	See [29] and [33]	

Condition	Explanation			
channel	This IE is present only if the idle slot carries the PCCPCH			

10.3.7.99 UE positioning measured results

Information Element/Group name	Need	Multi	Type and reference	Semantics description
UE positioning OTDOA measured results	OP		UE positioning OTDOA measured results 10.3.7.105	
UE positioning Position estimate info	OP		UE positioning Position estimate info 10.3.7.109	
UE positioning GPS measured results	OP		UE positioning GPS measured results 10.3.7.93	
UE positioning error	OP		UE positioning error 10.3.7.87	Included if UE positioning error occurred

10.3.7.100 UE positioning measurement

Information Element/Group name	Need	Multi	Type and reference	Semantics description
UE positioning reporting quantity	MP		UE positioning reporting quantity 10.3.7.111	
Measurement validity	OP		Measuremen t validity 10.3.7.51	
CHOICE reporting criteria	MP			
>UE positioning reporting criteria			UE positioning reporting criteria 10.3.7.110	
>Periodical reporting criteria			Periodical reporting criteria 10.3.7.53	
>No reporting				(no data)
UE positioning OTDOA assistance data for UE-assisted	OP		UE positioning OTDOA assistance	

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
			data for UE-	
			assisted	
			10.3.7.103	
UE positioning OTDOA	OP		UE	
assistance data for UE-based			positioning	
			OTDOA	
			assistance	
			data for UE-	
			based	
			10.3.7.103a	
UE positioning GPS assistance	OP		UE	
data			positioning	
			GPS	
			assistance	
			data	
			10.3.7.90	

10.3.7.101 UE positioning measurement event results

This IE contains the measurement event results that are reported to UTRAN for UE positioning measurements.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
CHOICE Event ID	MP			One spare value is needed.
>7a				
>>UE positioning Position estimate info	MP		UE positioning Position estimate info 10.3.7.109	
>7b				
>>UE positioning OTDOA measured results	MP		UE positioning OTDOA measured results 10.3.7.105	
>7c				
>>UE positioning GPS measurement	MP		UE positioning GPS measured results 10.3.7.93	

10.3.7.102 Void

10.3.7.103 UE positioning OTDOA assistance data for UE-assisted

Information Element/Group	Need	Multi	Type and	Semantics description
name			Reference	
UE positioning OTDOA	OP		UE	
reference cell info for UE-			positioning	
assisted			OTDOA	
			reference	
			cell info	
			10.3.7.108	

Information Element/Group	Need	Multi	Type and	Semantics description
name			Reference	
UE positioning OTDOA neighbour cell list for UE-	OP	1 to <maxcellm< td=""><td></td><td></td></maxcellm<>		
assisted		eas>		
>UE positioning OTDOA neighbour cell info for UE- assisted	MP		UE positioning OTDOA neighbour cell info 10.3.7.106	

10.3.7.103a UE positioning OTDOA assistance data for UE-based

Information Element/Group	Need	Multi	Type and	Semantics description
name			Reference	
UE positioning OTDOA	OP		UE	
reference cell info for UE-based			positioning	
			OTDOA	
			reference	
			cell info for	
			UE-based	
			10.3.7.108a	
UE positioning OTDOA	OP	1 to		
neighbour cell list for UE-based		<maxcellm< td=""><td></td><td></td></maxcellm<>		
		eas>		
>UE positioning OTDOA	MP		UE	
neighbour cell info for UE-based			positioning	
			OTDOA	
			neighbour	
			cell info for	
			UE-based	
			10.3.7.106a	

10.3.7.104 Void

10.3.7.105 UE positioning OTDOA measured results

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
SFN	MP		Integer(040 95)	SFN during which the last measurement was performed
CHOICE mode				
>FDD				
>>Reference cell id	MP		Primary CPICH info 10.3.6.60	
>>UE Rx-Tx time difference type 2 info	MP			
>>>UE Rx-Tx time difference type 2	MP		UE Rx-Tx time difference type 2 10.3.7.84	
>>>UE positioning OTDOA quality	MP		UE positioning OTDOA quality 10.3.7.107	Quality of the UE Rx-Tx time difference type 2 measurement from the reference cell.
>TDD				(no data)

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
>>Reference cell id	MP		Cell parameters ID 10.3.6.9	
Neighbours	MP	0 to <maxcellm eas></maxcellm 		
>CHOICE mode	MP			
>>FDD				
>>>Neighbour Identity	MD		Primary CPICH info 10.3.6.60	Default value is the same as in the first set of multiple sets.
>>>Frequency info	MD		Frequency info 10.3.6.36	Default value is the existing value of frequency information
>>>UE Rx-Tx time difference type 2 info	OP			Included for cell in the active set excluding the reference cell.
>>>UE Rx-Tx time difference type 2	MP		UE Rx-Tx time difference type 2 10.3.7.84	
>>>UE positioning OTDOA quality	MP		UE positioning OTDOA quality 10.3.7.107	Quality of the UE Rx-Tx time difference type 2 measurement from the neighbour cell.
>>TDD >>>Cell and Channel ID	MD		Cell and Channel Identity info 10.3.6.8a	Default value is the same as in the first set of multiple sets.
>UE positioning OTDOA quality	MP		UE positioning OTDOA quality 10.3.7.107	Quality of the SFN-SFN observed time difference type 2 measurement from the neighbour cell.
>SFN-SFN observed time difference type 2	MP		SFN-SFN observed time difference 10.3.7.63	Gives the timing relative to the reference cell. Only type 2 is allowed.

10.3.7.106 UE positioning OTDOA neighbour cell info

This IE gives approximate cell timing in order to decrease the search window.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
CHOICE mode	MP			
>FDD				
>>Primary CPICH info	MP		Primary CPICH info 10.3.6.60	
>TDD				
>>cell and channel ID	MP		Cell and Channel Identity info 10.3.6.8a	Identifies the channel to be measured on.
Frequency info	MD		Frequency info 10.3.6.36	Default value is the existing value of frequency information

Image: CV-IPDLs UE positioning IPDL parameters 10.3.7.98 Integer (0 Although this IE is not always required, need is MP to align with ASN.1. Define Tref as the time of beginning of system frame number SFNerf of the reference cell. Define Tnc as the beginning of a system frame number SFNerf of the reference cell. Define Tnc as the beginning of a system frame number be SFNnc. Then SFNnc SFNnc SFN offset is modulo 4096. Absence of this element means SFN offset is valid. False means SFN offset is not valid. False means SFN offset is not valid.	Information Element/Group name	Need	Multi	Type and Reference	Semantics description
A095) required, need is MP to align with ASM 1. Define Tref as the time of beginning of system frame number SFNref of the reference cell. Define Tref as the beginning of a frame from the neighbour cell occurring immediately after the time Tref. Let the corresponding system frame number be SFNnc. Then SFNnc = SFNref-SFN offset modulo 4096. SFN offset validity	IPDL parameters	CV-IPDLs		positioning IPDL parameters	
SFN offset validity MD Enumerated (false) SFN-SFN relative time difference MP Integer(0 38399) Integer(0 38399) Integer(0 38399) Integer(0 38399) Integer(0 38399) Integer(0 38399) SFN-SFN diff or reference cell. Equal to \(\(\text{Tref} \) (7.84 \(\text{10} \) \(\text{Jwree} \) \(\(\text{U} \) \) denotes rounding to the nearest lower integer. In chips. Tnc = the time of beginning of a system frame from the neighbour cell. Tref = the time of beginning of a system frame from the reference cell. SFN-SFN drift OP Integer (0 1, -2, -3, -4, -5, -8, -10, -15, -25, -35, -50, -65, -80, -100, -1, 2, 3, 4, 5, 8, 10, 15, 25, 35, 50, 65, 80, 100) Search Window Size MP Integer(20, 40, 80, 160, 320, 640, 1280, infinity) In chips. If the value is X then the expected SFN-SFN where RTD is the value of the field SFN-SFN relative time difference. Infinity means that the uncertainty is larger than 1280 chips. CHOICE Positioning/Mode NP SUE based MP Integer(20, 40, 80, 160, 320, 640, 1280, infinity) In chips. If the value is X then the expected SFN-SFN where RTD is the value of the field SFN-SFN relative time difference. Infinity means that the uncertainty is larger than 1280 chips.	SFN offset	MP			required, need is MP to align with ASN.1. Define Tref as the time of beginning of system frame number SFNref of the reference cell. Define Tnc as the beginning of a frame from the neighbour cell occurring immediately after the time Tref. Let the corresponding system frame number be SFNnc. Then SFNnc = SFNref-SFN offset modulo
difference 38399 Compared to the reference cell. Equal to [(Tnc-Tref)*(3.84*10 ⁶)] where [()] denotes rounding to the nearest lower integer. In chips, Tnc = the time of beginning of a system frame from the neighbour cell, Tref = the time of beginning of a system frame from the neighbour cell, Tref = the time of beginning of a system frame from the reference cell. SFN-SFN drift	SFN offset validity	MD			Absence of this element means SFN offset is valid. False means SFN offset is not
1, -2, -3, -4, -5, -8, -10, -15, -25, -35, -50, -65, -80, -100,		MP			compared to the reference cell. Equal to \(\text{(Tnc-Tref)*}(3.84*10^6) \) where \(\text{()} \) denotes rounding to the nearest lower integer. In chips, Tnc = the time of beginning of a system frame from the neighbour cell, Tref = the time of beginning of a system frame from the
40, 80, 160, 320, 640, observed time difference is in the range [RTD-X, RTD+X] where RTD is the value of the field SFN-SFN relative time difference. Infinity means that the uncertainty is larger than 1280 chips. CHOICE PositioningMode MP >UE based Me the expected SFN-SFN observed time difference is in the range [RTD-X, RTD+X] where RTD is the value of the field SFN-SFN relative time difference. Infinity means that the uncertainty is larger than 1280 chips.	SFN-SFN drift	OP		1, -2, -3, -4, - 5, -8, -10, - 15, -25, -35, -50, -65, -80, -100, 1, 2, 3, 4, 5, 8, 10, 15, 25, 35, 50, 65,	in 1/256 chips per second
>UE based (no data)				40, 80, 160, 320, 640, 1280,	the expected SFN-SFN observed time difference is in the range [RTD-X, RTD+X] where RTD is the value of the field SFN-SFN relative time difference. Infinity means that the uncertainty is larger than 1280
		MP			
	>UE based >UE assisted				(no data) (no data)

Condition	Explanation
IPDLs	This IE is mandatory present if IPDLs are applied and
	not needed otherwise.

10.3.7.106a UE positioning OTDOA neighbour cell info for UE-based

This IE gives approximate cell timing in order to decrease the search window, as well as the cell locations and fine cell timing for UE based OTDOA.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
UE positioning OTDOA neighbour cell info	MP		UE positioning OTDOA neighbour cell info 10.3.7.106	
Cell Position	MD			Default is the same as previous cell
>Relative North	OP		Integer(- 200002000 0)	Seconds of angle, scale factor 0.03. Relative position compared to reference cell.
>Relative East	OP		Integer(- 200002000 0)	Seconds of angle, scale factor 0.03. Relative position compared to reference cell.
>Relative Altitude	OP		Integer(- 40004000)	Relative altitude in meters compared to ref. cell.
Fine SFN-SFN	MP		Real(00.93 75 in steps of 0.0625)	Gives finer resolution
UE positioning Relative Time Difference Quality	MP		UE positioning OTDOA quality 10.3.7.109a	Quality of the relative time difference between neighbour and reference cell.
Round Trip Time	OP		Real(876.00 2923.875) in steps of 0.0625	In chips. Included if cell is in active set.

10.3.7.107 UE positioning OTDOA quality

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
Std Resolution	MP		Bit string(2)	Std Resolution field includes the resolution used in Std of OTDOA Measurements field. Encoding on two bits as follows: '00' 10 meters '01' 20 meters '10' 30 meters '11' Reserved
Number of OTDOA Measurements	MP		Bit string(3)	The 'Number of OTDOA measurements' field indicates how many OTDOA measurements have been used in the UE to determine the sample standard deviation of the measurements. Following 3 bit encoding is used: '001' 5-9 '010' 10-14 '011' 15-24 '100' 25-34 '101' 35-44 '110' 45-54 '111' 55 or more Special case:

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
				'O00':In this case the field 'Std of OTDOA measurements' contains the std of the reported SFN-SFN otd value = $\sqrt{E[(x-\mu)^2]}$, where x is the reported value and $\mu = E[x]$ is the expectation value (i.e. the true value) of x. This std can be used irrespective of the number of measurements and reporting of the number of measurements is not needed. Also other measurements such as Ec/No or Rx levels can be utilised in this case to evaluate the 'Std of OTDOA measurements' reported in this IE.
Std of OTDOA Measurements	MP		Bit string(5)	Std of OTDOA Measurements field includes sample standard deviation of OTDOA measurements (when number of measurements (when number of measurements is reported in 'Number of OTDOA measurements field') or standard deviation of the reported SFN-SFN otd value = $\sqrt{E[(x-\mu)^2]}$, where x is the reported value and $\mu = E[x]$ is the expectation value (i.e. the true value) of x (when '000' is given in 'Number of OTDOA measurements' field). Following linear 5 bit encoding is used: '00000' 0 - (R*1-1) meters '00001' R*1 - (R*2-1) meters '00010' R*2 - (R*3-1) meters '11111' R*31 meters or more where R is the resolution defined by Std Resolution field. E.g. R=20 m corresponds to 0-19 m, 20-39 m,,620+ m.

10.3.7.108 UE positioning OTDOA reference cell info

This IE defines the cell used for time references in all OTDOA measurements.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
SFN	OP		Integer (04095)	Time stamp (SFN of Reference Cell) of the SFN- SFN relative time differences and SFN-SFN drift rates. Included if any SFN-SFN drift value is included in IE UE positioning OTDOA neighbour cell info.
CHOICE mode	MP			
>FDD				
>>Primary CPICH info	MP		Primary CPICH info	

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
			10.3.6.60	
>TDD				
>>cell and channel ID	MP		Cell and Channel Identity info 10.3.6.8a	Identifies the channel to be measured on.
Frequency info	MD		Frequency info 10.3.6.36	Default value is the existing value of frequency information. This IE shall always be set to default value
CHOICE PositioningMode	MP			
>UE based				
>UE assisted				(no data)
IPDL parameters	OP		UE positioning IPDL parameters 10.3.7.98	If this element is not included there are no idle periods present

10.3.7.108a UE positioning OTDOA reference cell info for UE-based

This IE defines the cell used for time references in all OTDOA measurements for UE-based methods.

Information Element/Group	Need	Multi	Type and	Semantics description
name			Reference	
UE positioning OTDOA	MP		UE	
reference cell info			positioning	
			OTDOA	
			reference	
			cell info	
			10.3.7.108	
CHOICE Cell Position	OP			The position of the antenna
				that defines the cell. Used for
				the UE based method.
>Ellipsoid				
>>Ellipsoid point	MP		Ellipsoid	
			point	
			10.3.8.4a	
>Ellipsoid with altitude				
>>Ellipsoid point with altitude	MP		Ellipsoid	
			point with	
			altitude	
			10.3.8.4b	
Round Trip Time	OP		Real(876.00	In chips.
·			2923.875)	·
			in steps of	
			0.0625	

10.3.7.109 UE positioning position estimate info

The purpose of this IE is to provide the position estimate from the UE to the network, if the UE is capable of determining its own position.

Information Element/Group	Need	Multi	Type and	Semantics description
name			Reference	
CHOICE Reference Time	MP			
>UTRAN GPS reference time				
>>UE GPS timing of cell frames	MP		Integer(0 3715891199 9999)	GPS Time of Week in units of 1/16 th UMTS chips according to [19]. 33209832177664 spare values

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
				are needed.
>>CHOICE mode	MP			
>>>FDD				
>>>>Primary CPICH Info	MP		Primary CPICH Info 10.3.6.60	Identifies the reference cell for the GPS TOW-SFN relationship
>>>TDD				
>>cell parameters id	MP		Cell parameters id 10.3.6.9	Identifies the reference cell for the GPS TOW-SFN relationship.
>>Reference SFN	MP		Integer(040 95)	The SFN for which the location is valid. This IE indicates the SFN at which the UE timing of cell frame is captured.
>GPS reference time only				000 000
>>GPS TOW msec	MP		Integer(06. 048*10 ⁸ -1)	GPS Time of Week in milliseconds (rounded down to the nearest millisecond unit).
>Cell timing				
>>SFN	MP		Integer(040 95)	SFN during which the position was calculated.
>>CHOICE mode	MP			
>>>FDD				
>>>>Primary CPICH Info	MP		Primary CPICH Info 10.3.6.60	Identifies the reference cell for SFN
>>>TDD				
>>cell parameters id	MP		Cell parameters id 10.3.6.9	Identifies reference cell for SFN
CHOICE Position estimate	MP			
>Ellipsoid Point			Ellipsoid Point; 10.3.8.4a	
>Ellipsoid point with uncertainty circle			Ellipsoid point with uncertainty circle 10.3.8.4d	
>Ellipsoid point with uncertainty ellipse			Ellipsoid point with uncertainty ellipse 10.3.8.4e	
>Ellipsoid point with altitude			Ellipsoid point with altitude 10.3.8.4b	
>Ellipsoid point with altitude and uncertainty ellipsoid			Ellipsoid point with altitude and uncertainty ellipsoid 10.3.8.4c	

10.3.7.109a UE positioning Relative Time Difference quality

Information Element/Group	Need	Multi	Type and	Semantics description
name			Reference	
Relative Time Difference Std	MP		Bit string(2)	Std Resolution field includes
Resolution				the resolution used in Std of
				Relative Time Difference field.
				Encoding on two bits as
				follows:
				'00' 10 meters
				'01' 20 meters
				'10' 30 meters
				'11' Reserved
Std of Relative Time Difference	MP		Bit string(5)	Std of Relative Time difference
				field includes standard
				deviation of (SFN-SFN relative
				time difference + Fine SFN-
				SFN). Following linear 5 bit
				encoding is used:
				'00000' 0 - (R*1-1) meters
				'00001' R*1 – (R*2-1) meters
				'00010' R*2 – (R*3-1) meters
				'11111' R*31 meters or more
				where R is the resolution
				defined by Std Resolution
				field. E.g. R=20 m corresponds
				to 0-19 m, 20-39 m,,620+ m.

10.3.7.110 UE positioning reporting criteria

The triggering of the event-triggered reporting for a UE positioning measurement.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
Parameters required for each event	OP	1 to <maxmeas Event></maxmeas 	Kererence	
>Amount of reporting	MP		Integer(1, 2, 4, 8, 16, 32, 64,infinite)	
>Report first fix	MP		Boolean	If true the UE reports the position once the measurement control is received, and then each time an event is triggered.
>Measurement interval	MP		Integer(5,15, 60,300,900,1 800,3600,72 00)	Indicates how often the UE should make the measurement In seconds
>CHOICE Event ID	MP			
>>7a				
>>>Threshold Position Change	MP		Integer(10,2 0,30,40,50,1 00,200,300,5 00,1000,200 0,5000,1000 0,20000,500 00,100000)	Meters. Indicated how much the position should change compared to last reported position fix in order to trigger the event.
>>7b				
>>>Threshold SFN-SFN change	MP		Real(0.25,0. 5,1,2,3,4,5,1 0,20,50,100, 200,500,100 0,2000,5000)	Chips. Indicates how much the SFN-SFN measurement of ANY measured cell is allowed to change before the event is triggered.
>>7c				
>>>Threshold SFN-GPS TOW	MP		Integer(1,2,3 ,5,10,20,50,1 00)	Time in ms. When the GPS TOW and SFN timer has drifted apart more than the specified value the event is triggered.

10.3.7.111 UE positioning reporting quantity

The purpose of the element is to express the allowed/required location method(s), and to provide information desired QoS.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
Method Type	MP		Enumerated(UE assisted, UE based, UE based is preferred but UE assisted is allowed, UE assisted is preferred but UE based is allowed)	
Positioning Methods	MP		Enumerated(OTDOA, GPS, OTDOA or GPS, Cell ID)	
Response Time	MP		Integer(1,2,4	This IE shall be ignored.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
			, 8, 16, 32, 64, 128)	
Horizontal Accuracy	CV- MethodTyp e		Bit string(7)	The uncertainty is derived from the "uncertainty code" k by $r = 10*(1.1^k-1)$ in meters.
Vertical Accuracy	CV- MethodTyp e		Bit string(7)	The uncertainty is derived from the "uncertainty code" k by $r = 45*(1.025^k-1)$ in meters.
GPS timing of Cell wanted	MP		Boolean	If true the SRNC wants the UE to report the SFN-GPS timing of the reference cell. This is however optional in the UE.
Multiple Sets	MP		Boolean	This IE shall be ignored.
Additional Assistance Data Request	MP		Boolean	TRUE indicates that the UE is requested to send the IE "Additional assistance Data Request" when the IE "UE positioning Error" is present in the UE positioning measured results. FALSE indicates that the UE shall use the assistance data available.
Environment Characterisation	OP		Enumerated(possibly heavy multipath and NLOS conditions, no or light multipath and usually LOS conditions, not defined or mixed environment)	One spare value is needed.

Condition	Explanation
Method Type	The IE is optional if the IE "Method Type" is "UE
	assisted"; otherwise it is mandatory present.

10.3.7.112 T_{ADV} info

NOTE: Only for 1.28 Mcps TDD.

 $T_{\mbox{\scriptsize ADV}}$ indicates the difference between the Rx timing and Tx timing of a UE.

Information Element/group name	Need	Multi	Type and reference	Semantics description	Version
T _{ADV}	MP		Integer (02047)	As defined in [20].	REL-4
SFN	MP		Integer(040 95)	SFN during which the T _{ADV} measurement was performed.	REL-4

10.3.8 Other Information elements

10.3.8.1 BCCH modification info

Indicates modification of the System Information on BCCH.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
MIB Value tag	MP		MIB Value	
, and the second			tag 10.3.8.9	
BCCH modification time	OP		Integer (0	All SFN values in which MIB
			4088 in step	may be mapped are allowed.
			of 8)	

10.3.8.2 BSIC

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Base transceiver Station Identity Code (BSIC)	MP			[11]
>Network Colour Code (NCC)	MP		bit string(3)	The first/leftmost bit of the bit string contains the most significant bit of the NCC.
>Base Station Colour Code (BCC)	MP		bit string(3)	The first/leftmost bit of the bit string contains the most significant bit of the BCC.

10.3.8.3 CBS DRX Level 1 information

This information element contains the CBS discontinuous reception information to be broadcast for CBS DRX Level 1 calculations in the UE.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Period of CTCH allocation (N)	MP		Integer	$M_{TTI} \le N \le 4096 - K$
			(1256)	N multiple of M _{TTI}
CBS frame offset (K)	MP		Integer	$0 \le K \le N-1$,
			(0255)	K multiple of M _{TTI}

10.3.8.4 Cell Value tag

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Cell Value tag	MP		Integer (14)	

10.3.8.4a Ellipsoid point

This IE contains the description of an ellipsoid point as in [24].

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
Latitude sign	MP		Enumerated (North, South)	
Degrees Of Latitude	MP		Integer (02 ²³ -1)	The IE value (N) is derived by this formula: $N \le 2^{23} X/90 < N+1$ X being the latitude in degree (0° 90°)
Degrees Of Longitude	MP		Integer (- 2 ²³ 2 ²³ -1)	The IE value (<i>N</i>) is derived by this formula: <i>N</i> ≤2 ²⁴ <i>X</i> /360 < <i>N</i> +1 <i>X</i> being the longitude in degree (-180°+180°)

10.3.8.4b Ellipsoid point with Altitude

This IE contains the description of an ellipsoid point with altitude as in [24].

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
Latitude sign	MP		Enumerated (North, South)	
Degrees Of Latitude	MP		Integer (02 ²³ -1)	The IE value (N) is derived by this formula: $N \le 2^{23} X/90 < N+1$ X being the latitude in degree (0° 90°)
Degrees Of Longitude	MP		Integer (- 2 ²³ 2 ²³ -1)	The IE value (<i>N</i>) is derived by this formula: <i>N</i> ≤2 ²⁴ <i>X</i> /360 < <i>N</i> +1 <i>X</i> being the longitude in degree (-180°+180°)
Altitude Direction	MP		Enumerated (Height, Depth)	
Altitude	MP		Integer (02 ¹⁵ -1)	The IE value (<i>N</i>) is derived by this formula: <i>N</i> ≤ <i>a</i> < <i>N</i> +1 <i>a</i> being the altitude in metres

10.3.8.4c Ellipsoid point with Altitude and uncertainty ellipsoid

This IE contains the description of an ellipsoid point with altitude and uncertainty ellipsoid as in [24].

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
Latitude sign	MP		Enumerated (North, South)	
Degrees Of Latitude	MP		Integer (02 ²³ -1)	The IE value (N) is derived by this formula: $N \le 2^{23} X/90 < N+1$ X being the latitude in degree (0° 90°)

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
Degrees Of Longitude	MP		Integer (- 2 ²³ 2 ²³ -1)	The IE value (<i>N</i>) is derived by this formula: <i>N</i> ≤2 ²⁴ <i>X</i> /360 < <i>N</i> +1 <i>X</i> being the longitude in degree (-180°+180°)
Altitude Direction	MP		Enumerated (Height, Depth)	
Altitude	MP		Integer (02 ¹⁵ -1)	The IE value (N) is derived by this formula: N≤a < N+1 a being the altitude in metres
Uncertainty semi-major	MP		Integer (0127)	The uncertainty r is derived from the "uncertainty code" k by $r = 10x(1.1^k-1)$
Uncertainty semi-minor	MP		Integer (0127)	The uncertainty r is derived from the "uncertainty code" k by $r = 10x(1.1^k-1)$
Orientation of major axis	MP		Integer (089)	The IE value (N) is derived by this formula: $2N \le a < 2(N+1)$ a being the orientation in degree (0° 179°)
Uncertainty Altitude	MP		Integer(012 7)	The uncertainty in altitude, h, expressed in metres is mapped from the IE value (K), with the following formula: $h = C((1+x)^{K} - 1)$ with $C = 45$ and $x = 0.025$.
Confidence	MP		Integer (0100)	in percentage

10.3.8.4d Ellipsoid point with uncertainty Circle

This IE contains the description of an ellipsoid point with an uncertainty circle as in [24].

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
Latitude sign	MP		Enumerated (North, South)	
Degrees Of Latitude	MP		Integer (02 ²³ -1)	The IE value (N) is derived by this formula: $N \le 2^{23} X/90 < N+1 X$ being the latitude in degree $(0^{\circ}90^{\circ})$
Degrees Of Longitude	MP		Integer (- 2 ²³ 2 ²³ -1)	The IE value (N) is derived by this formula: $N \le 2^{24} X/360 < N+1$ X being the longitude in degree (-180°+180°)
Uncertainty Code	MP		Integer (0127)	The uncertainty r is derived from the "uncertainty code" k by $r = 10x(1.1^k-1)$

10.3.8.4e Ellipsoid point with uncertainty Ellipse

This IE contains the description of an ellipsoid point with an uncertainty ellipse as in [24].

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
Latitude sign	MP		Enumerated (North, South)	
Degrees Of Latitude	MP		Integer (02 ²³ -1)	The IE value (N) is derived by this formula: N≤2 ²³ X/90 < N+1 X being the latitude in degree (0° 90°)
Degrees Of Longitude	MP		Integer (- 2 ²³ 2 ²³ -1)	The IE value (N) is derived by this formula: N≤2 ²⁴ X/360 < N+1 X being the longitude in degree (-180°+180°)
Uncertainty semi-major	MP		Integer (0127)	The uncertainty r is derived from the "uncertainty code" k by $r = 10x(1.1^k-1)$
Uncertainty semi-minor	MP		Integer (0127)	The uncertainty r is derived from the "uncertainty code" k by $r = 10x(1.1^k-1)$
Orientation of major axis	MP		Integer (089)	The IE value (N) is derived by this formula: $2N \le a < 2(N+1)$ a being the orientation in degree (0° 179°)
Confidence	MP		Integer (0100)	in percentage

10.3.8.4f GERAN system information

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
>>> GERAN System Info	MP	1 to <maxgeran SI></maxgeran 			REL-5
>>>> GERAN system info block	MP		Octet string(123)	The first octet contains octet 1 of the GERAN system information block, the second octet contains octet 2 of the GERAN system information block and so on.	REL-5

10.3.8.5 Inter-RAT change failure

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Inter-RAT change failure cause	MP		Enumerated(Configuratio n unacceptabl e, physical channel	Four spare values are needed.

		failure, protocol error, unspecified)	
Protocol error information	CV-ProtErr	Protocol error information 10.3.8.12	

Condition	Explanation		
ProtErr	The IE is mandatory present if the IE "Inter-RAT		
	change failure cause" has the value "Protocol error"		
	and not needed otherwise.		

10.3.8.6 Inter-RAT handover failure

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Inter-RAT handover failure cause	MD		Enumerated(Configuratio n unacceptabl e, physical channel failure, protocol error, inter-RAT protocol error, unspecified)	Default value is "unspecified". Eleven spare values are needed.
Protocol error information	CV-ProtErr		Protocol error information 10.3.8.12	

Condition	Explanation
ProtErr	The IE is mandatory present if the IE "Inter-RAT handover failure cause" has the value "Protocol error"
	and not needed otherwise.

10.3.8.7 Inter-RAT UE radio access capability

This Information Element contains the inter-RAT UE radio access capability that is structured and coded according to the specification used for the corresponding system type.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
CHOICE system	MP				
>GSM					
>>Mobile Station Classmark 2	MP		Octet string (5)	This IE is formatted as 'TLV' and is coded in the same way as the Mobile Station Classmark 2 information element in [5]. The first octet is the Mobile station classmark 2 IEI and its value shall be set to 33H. The second octet is the Length of mobile	

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Element/Group name			reference	station classmark 2 and its value shall be set to 3. The octet 3 contains the first octet of the value part of the Mobile Station Classmark 2 information element, the octet 4 contains the second octet of the value part of the Mobile Station Classmark 2 information element and so on. For each of these octets, the first/leftmost/ most significant bit of the octet contains b8 of the corresponding octet of the Mobile Station Classmark 2. In this version of the protocol the first two octets of the Mobile Station Classmark 2 IE containing the Mobile Station classmark 2 IEI and the Length of mobile station classmark 2 contents should be ignored by the receiver.	
>>Mobile Station Classmark 3	MP		Octet string (132)	This IE is formatted as 'V' and is coded in the same way as the value part in the Mobile station classmark 3 information element in [5]. The first octet contains octet 1 of the value part of Mobile station classmark 3, the second octet contains octet 2 of the value part of Mobile station classmark 3 and so on. See NOTE 1.	
>GERAN lu				SECTION I.	REL-5
>>MS GERAN Iu mode Radio Access Capability	MP		Bit string (1170)	Formatted and coded according to [53]. The first/leftmost/most significant bit of the bit string contains bit 8 of the first octet of the IE.	REL-5
>cdma2000					
>>cdma2000Message	MP	1.to. <ma xInterSy sMessa ges></ma 			
>>>MSG_TYPE(s)	MP		Bit string (8)	Formatted and coded according to cdma2000 specifications. The first/leftmost/most significant bit of the bit string contains bit 7 of	

Information	Need	Multi	Type and	Semantics description	Version
Element/Group name			reference		
				the MSG_TYPE.	
>>>cdma2000Messagep	MP		Bit string	Formatted and coded	
ayload(s)			(1512)	according to cdma2000	
				specifications. The	
				first/leftmost/most	
				significant bit of the bit	
				string contains bit 7 of	
				the first octet of the	
				cdma2000 message.	

NOTE 1: The value part is specified by means of CSN.1, which encoding results in a bit string, to which final padding may be appended upto the next octet boundary [5]. The first/ leftmost bit of the CSN.1 bit string is placed in the first/ leftmost/ most significant bit of the first octet. This continues until the last bit of the CSN.1 bit string, which is placed in the last/ rightmost/ least significant bit of the last octet.

10.3.8.8 Void

10.3.8.8a Inter-RAT UE security capability

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE system	MP			
>GSM				
>>GSM security capability	MP			The value TRUE means that the indicated ciphering algorithm is supported.
>>>A5/7 supported	MP		Boolean	
>>>A5/6 supported	MP		Boolean	
>>>A5/5 supported	MP		Boolean	
>>>A5/4 supported	MP		Boolean	
>>>A5/3 supported	MP		Boolean	
>>>A5/2 supported	MP		Boolean	
>>>A5/1 supported	MP		Boolean	

10.3.8.9 MIB Value tag

Information Element/Group name	Need	Multi	Type and reference	Semantics description
MIB Value tag	MP		Integer (18)	

10.3.8.10 PLMN Value tag

Information Element/Group name	Need	Multi	Type and reference	Semantics description
PLMN Value tag	MP		Integer (1256)	

10.3.8.10a PNBSCH allocation

UTRAN may use this IE to provide silent periods in the cell that may be used for cell synchronisation purposes.

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			reference	description	
Number of repetitions per SFN	MP		Integer(2, 3,		REL-4
period			4, 5, 6, 7, 8,		
			9, 10, 12, 14,		
			16, 18, 20,		
			24, 28, 32,		
			36, 40, 48,		
			56, 64, 72,		
			80)		

10.3.8.11 Predefined configuration identity and value tag

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Predefined configuration identity	MP		Predefined configuration identity 10.3.4.5	
Predefined configuration value tag	MP		Predefined configuration value tag 10.3.4.6	

10.3.8.12 Protocol error information

This information element contains diagnostics information returned by the receiver of a message that was not completely understood.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
CHOICE diagnostics type	MP			One spare value is needed.
>Protocol error cause			Protocol	
			error cause	
			10.3.3.26	

10.3.8.13 References to other system information blocks

Information element/Group name	Need	Multi	Type and reference	Semantics description
References to other system information blocks	MP	1 to <maxsib></maxsib>		System information blocks for which multiple occurrences are used, may appear more than once in this list
>Scheduling information	MP		Scheduling information, 10.3.8.16	
>SIB type SIBs only	MP		SIB Type SIBs only, 10.3.8.22	

10.3.8.14 References to other system information blocks and scheduling blocks

Information element/Group name	Need	Multi	Type and reference	Semantics description
References to other system information blocks	MP	1 to <maxsib></maxsib>		System information blocks for which multiple occurrences are used, may appear more than once in this list
>Scheduling information	MP		Scheduling information, 10.3.8.16	
>SIB and SB type	MP		SIB and SB Type, 10.3.8.18a	

10.3.8.15 Rplmn information

Contains information to provide faster RPLMN selection in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
GSM BA Range	OP	1 to maxNumG SMFreqRa nges		GSM BA Range	
>GSM Lower Range (UARFCN)	MP		Integer(016 383)	Lower bound for range of GSM BA freqs	
>GSM Upper Range (UARFCN)	MP		Integer(016 383)	Upper bound for range of GSM BA freqs	
FDD UMTS Frequency list	OP	1 to maxNumF DDFreqs			
>UARFCN (Nlow)	MP		Integer(016 383)	[21]	
>UARFCN (Nupper)	OP		Integer(016 383)	[21] This IE is only needed when the FDD frequency list is specifying a range.	
3.84 Mcps TDD UMTS Frequency list	OP	1 to maxNumT DDFreqs			
>UARFCN	MP		Integer(016 383)	[22]	
1.28 Mcps TDD UMTS Frequency list	OP	1 to maxNumT DDFreqs	,		REL-4
>UARFCN	MP	•	Integer(016 383)	[22]	REL-4
CDMA2000 UMTS Frequency list	OP	1 to maxNumC DMA200Fr eqs	,		
>BAND_CLASS	MP		Bit string(5 bits)	TIA/EIA/IS-2000 When mapping the BAND_CLASS to the bit string, the first/leftmost bit of the bit string contains the most significant bit.	
>CDMA_FREQ	MP		Bit string (11	TIA/EIA/IS-2000	

Information Element/Group	Need	Multi	Type and	Semantics	Version
name			reference	description	
			bits)	When mapping	
				the CDMA_FREQ	
				to the bit string,	
				the first/leftmost	
				bit of the bit string	
				contains the most	
				significant bit	

10.3.8.16 Scheduling information

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE Value tag	OP		10.0.0.00	
>PLMN Value tag			PLMN Value tag 10.3.8.10	This IE is included if the following conditions are fulfilled: the SIB type equals system information block type 1
>Predefined configuration identity and value tag			Predefined configuration identity and value tag 10.3.8.11	This IE is included if the following conditions are fulfilled: the SIB type equals system information block type 16
>Cell Value tag			Cell Value tag 10.3.8.4	This IE is included if the following conditions are fulfilled: the area scope for the system information block is set to "cell" in table 8.1.1. a value tag is used to indicate changes in the system information block.
>SIB occurrence identity and value tag			SIB occurrence identity and value tag 10.3.8.20b	This IE is included if the following conditions are fulfilled: the SIB type equals system information block types 15.2 and 15.3
Scheduling	MP			
>SEG_COUNT	MD		SEG COUNT 10.3.8.17	Default value is 1
>SIB_REP	MP		Integer (4, 8, 16, 32, 64, 128, 256, 512, 1024, 2048, 4096)	Repetition period for the SIB in frames
>SIB_POS	MP		Integer (0 Rep-2 by step of 2)	Position of the first segment Rep is the value of the SIB_REP IE
>SIB_POS offset info	MD	115		see below for default value
>>SIB_OFF	MP		Integer(232 by step of 2)	Offset of subsequent segments

Field	Default value
SIB_POS offset info	The default value is that all segments are
	consecutive, i.e., that the SIB_OFF = 2 for all
	segments except when MIB segment/complete MIB is
	scheduled to be transmitted in between segments
	from same SIB. In that case, SIB_OFF=4 in between
	segments which are scheduled to be transmitted at
	SFNprime = 8 *n-2 and 8*n + 2, and SIB_OFF=2 for
	the rest of the segments.

10.3.8.17 SEG COUNT

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
SEG_COUNT	MP		Integer	Number of segments in the
			(116)	system information block

10.3.8.18 Segment index

Each system information segment has an individual segment index.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Segment index	MP		Integer (115)	Segments of a system information block are numbered starting with 0 for the first segment and 1 for the next segment, which can be the first subsequent segment or a last segment.

10.3.8.18a SIB and SB type

The SIB type identifies a specific system information block.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
SIB and SB type	MP		Enumerated, see below	

The list of values to encode is:

System Information Type 1,

System Information Type 2,

System Information Type 3,

System Information Type 4,

System Information Type 5,

System Information Type 6,

System Information Type 7,

System Information Type 8,

System Information Type 9,

System Information Type 10,

System Information Type 11,

System Information Type 12,

System Information Type 13,

System Information Type 13.1,

System Information Type 13.2,

System Information Type 13.3,

System Information Type 13.4,

System Information Type 14,

System Information Type 15,

System Information Type 15.1,

System Information Type 15.2,

System Information Type 15.3,

System Information Type 15.4,

System Information Type 15.5,

System Information Type 16,

System Information Type 17,

System Information Type 18,

Scheduling Block 1,

Scheduling Block 2.

In addition, three spare values are needed.

10.3.8.19 SIB data fixed

Contains the result of a master information block or a system information block after encoding and segmentation. The IE is used for segments with fixed length (segments filling an entire transport block).

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
SIB data fixed	MP		Bit string (The first bit contains the first
			222)	bit of the segment.

10.3.8.20 SIB data variable

Contains either a complete system information block or a segment of a system information block. Contains the result of a master information block or a system information block after encoding and segmentation. The IE is used for segments with variable length. The system information blocks are defined in clauses 10.2.48.8.1 to 10.2.48.8.18.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
SIB data variable	MP		Bit string (The first bit contains the first
			1214)	bit of the segment.

10.3.8.20a SIB occurrence identity

This information element identifies a SIB occurrence for System Information Block types 15.2 and 15.3. For System Information Block type 15.2, this identity is assigned to the visible satellite only. Unused identities are claimed by newly rising satellites.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
SIB occurrence identity	MP		Integer (015)	

10.3.8.20b SIB occurrence identity and value tag

Information Element/Group name	Need	Multi	Type and reference	Semantics description
SIB occurrence identity	MP		SIB occurrence identity 10.3.8.20a	
SIB occurrence value tag	MP		SIB occurrence value tag 10.3.8.20c	

10.3.8.20c SIB occurrence value tag

This information element is used to identify different versions of SIB occurrence for System Information Block types 15.2 and 15.3.

Information Element/Group name	Need	Multi	Type and Reference	Semantics description
SIB occurrence value tag	MP		Integer(015	

10.3.8.21 SIB type

The SIB type identifies a specific system information block.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
SIB type	MP		Enumerated, see below	

The list of values to encode is:

Master information block,

System Information Type 1,

System Information Type 2,

System Information Type 3,

System Information Type 4,

System Information Type 5,

System Information Type 6,

System Information Type 7,

System Information Type 8,

System Information Type 9,

System Information Type 10,

System Information Type 11,

System Information Type 12,

System Information Type 13,

System Information Type 13.1,

System Information Type 13.2,

System Information Type 13.3,

System Information Type 13.4,

System Information Type 14,

System Information Type 15,

System Information Type 15.1,

System Information Type 15.2,

System Information Type 15.3,

System Information Type 15.4,

System Information Type 15.5,

System Information Type 16,

System Information Type 17,

System Information Type 18,

Scheduling Block 1,

Scheduling Block 2.

In addition, two spare values are needed.

10.3.8.22 SIB type SIBs only

The SIB type identifies a specific system information block.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
SIB type SIBs only	MP		Enumerated,	
			see below	

The list of values to encode is:

System Information Type 1,

System Information Type 2,

System Information Type 3,

System Information Type 4,

System Information Type 5,

System Information Type 6,

System Information Type 7,

System Information Type 8,

System Information Type 9,

System Information Type 10,

System Information Type 11,

System Information Type 12,

System Information Type 13,

System Information Type 13.1,

System Information Type 13.2,

System Information Type 13.3,

System Information Type 13.4,

System Information Type 14,

System Information Type 15,

System Information Type 15.1,

System Information Type 15.2,

System Information Type 15.3,

System Information Type 15.4,

System Information Type 15.5,

System Information Type 16,

System Information Type 17,

System Information Type 18.

In addition, five spare values are needed.

10.3.9 ANSI-41 Information elements

10.3.9.1 ANSI 41 Core Network Information

Information element/Group name	Need	Multi	Type and reference	Semantics description
P_REV	MP		P_REV	
			10.3.9.10	
MIN_P_REV	MP		MIN_P_REV	
			10.3.9.8	
SID	MP		SID	
			10.3.9.11	
NID	MP		NID 10.3.9.9	

10.3.9.2 ANSI-41 Global Service Redirection information

This Information Element contains ANSI-41 Global Service Redirection information.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
ANSI-41 Global Service	MP		ANSI-41	Formatted and coded
Redirection information			NAS	according to the 3GPP2
			parameter,	document "G3G CDMA DS on
			10.3.9.3	ANSI-41"

10.3.9.3 ANSI-41 NAS parameter

This Information Element contains ANSI-41 User Zone Identification information.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
ANSI-41 NAS parameter	MP		Bit string (size (12048))	The first bit contains the first bit of the ANSI-41 information.

10.3.9.4 ANSI-41 NAS system information

This Information Element contains ANSI-41 system information.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
NAS (ANSI-41) system information	MP		ANSI-41 NAS parameter, 10.3.9.3	Formatted and coded according to the 3GPP2 document "G3G CDMA DS on ANSI-41"

10.3.9.5 ANSI-41 Private Neighbour List information

This Information Element contains ANSI-41 Private Neighbour List information.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
ANSI-41 Private Neighbour List information	MP		ANSI-41 NAS parameter, 10.3.9.3	Formatted and coded according to the 3GPP2 document "G3G CDMA DS on ANSI-41"

10.3.9.6 ANSI-41 RAND information

This Information Element contains ANSI-41 RAND information.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
ANSI-41 RAND information	MP		ANSI-41 NAS parameter, 10.3.9.3	Formatted and coded according to the 3GPP2 document "G3G CDMA DS on ANSI-41"

10.3.9.7 ANSI-41 User Zone Identification information

This Information Element contains ANSI-41 User Zone Identification information.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
ANSI-41 User Zone	MP		ANSI-41	Formatted and coded
Identification information			NAS	according to the 3GPP2
			parameter,	document "G3G CDMA DS on
			10.3.9.3	ANSI-41"

10.3.9.8 MIN_P_REV

This Information Element contains minimum protocol revision level.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
MIN_P_REV	MP		Bit string (8)	Minimum protocol revision level. The first/leftmost bit of the bit string contains the most significant bit of the MIN_P_REV.

10.3.9.9 NID

This Information Element contains Network identification.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
NID	MP		Bit string (16)	Network identification. The first/leftmost bit of the bit string contains the most significant bit of the NID.

10.3.9.10 P REV

This Information Element contains protocol revision level.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
P_REV	MP		Bit string (8)	Protocol revision level. The first/leftmost bit of the bit string contains the most significant bit of the P. REV.

10.3.9.11 SID

This Information Element contains System identification.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
SID	MP		Bit string (15)	System identification. The first/leftmost bit of the bit string contains the most significant bit of the SID.

10.3.10 Multiplicity values and type constraint values

The following table includes constants that are either used as multi bounds (name starting with "max") or as high or low value in a type specification (name starting with "lo" or "hi"). Constants are specified only for values appearing more than once in the RRC specification. In case a constant is related to one or more other constants, an expression is included in the "value" column instead of the actual value.

Constant	Explanation	Value	Version
CN information			
maxCNdomains	Maximum number of CN domains	4	
UTRAN mobility information			
maxRAT	Maximum number or Radio Access Technologies	maxOtherRAT + 1	
maxOtherRAT	Maximum number or other Radio Access Technologies	15	
maxURA	Maximum number of URAs in a cell	8	
maxInterSysMessages	Maximum number of Inter System Messages	4	
maxRABsetup	Maximum number of RABs to be established	16	
UE information			
maxtransactions	Maximum number of parallel RRC transactions in downlink	25	
maxPDCPalgoType	Maximum number of PDCP algorithm types	8	
maxDRACclasses	Maximum number of UE classes which would require different DRAC parameters	8	
maxFreqBandsFDD	Maximum number of frequency bands supported	8	
maxFreqBandsTDD	by the UE as defined in [21] Maximum number of frequency bands supported	4	
·	by the UE as defined in [22]		
maxFreqBandsGSM	Maximum number of frequency bands supported by the UE as defined in [45]	16	
maxPage1	Number of UEs paged in the Paging Type 1 message	8	
maxSystemCapability	Maximum number of system specific capabilities that can be requested in one message.	16	
MaxURNTIgroup	Maximum number of U-RNTI groups in one message	8	REL-5
RB information	, and the second		
maxPredefConfig	Maximum number of predefined configurations	16	
maxRB	Maximum number of RBs	32	
maxSRBsetup	Maximum number of signalling RBs to be established	8	
maxRBperRAB	Maximum number of RBs per RAB	8	
maxRBallRABs	Maximum number of non signalling RBs	27	
maxRBMuxOptions	Maximum number of RB multiplexing options	8	
maxLoCHperRLC	Maximum number of logical channels per RLC entity	2	
MaxROHC-PacketSizes	Maximum number of packet sizes that are allowed to be produced by ROHC.	16	
MaxROHC-Profiles	Maximum number of profiles supported by ROHC on a given RB.	8	
maxRFC 3095-CID	Maximum number of available CID values per radio bearer	16384	REL-5
TrCH information			
MaxHProcesses	Maximum number of H-ARQ processes	8	REL-5
MaxHSDSCH_TB_index	Maximum number of TB set size configurations for the HS-DSCH.	64 (FDD and 1.28 MCPS TDD); 512 (3.84 Mcps TDD)	REL-5
maxMACdPDUSizes	Maximum number of MAC-d PDU sizes per queue permitted for MAC-hs	8	REL-5
maxTrCH	Maximum number of transport channels used in one direction (UL or DL)	32	
maxTrCHpreconf	Maximum number of preconfigured Transport channels, per direction	16	
maxCCTrCH	Maximum number of CCTrCHs	8	
maxQueueID	Maximum number of Mac-hs queues	8	REL-5
MaxTF	Maximum number of different transport formats that can be included in the Transport format set for one transport channel	32	
maxTF-CPCH	Maximum number of TFs in a CPCH set	16	
maxTFC	Maximum number of Transport Format	1024	
	Combinations		

Constant	Explanation	Value	Version
maxTFCsub	Maximum number of Transport Format	1024	70101011
	Combinations Subset		
maxTFCI-1-Combs	Maximum number of TFCI (field 1) combinations	512	
maxTFCI-2-Combs	Maximum number of TFCI (field 2) combinations	512	
maxCPCHsets	Maximum number of CPCH sets per cell	16	
maxSIBperMsg	Maximum number of complete system information blocks per SYSTEM INFORMATION message	16	
maxSIB	Maximum number of references to other system information blocks.	32	
maxSIB-FACH	Maximum number of references to system information blocks on the FACH	8	
PhyCH information			
maxHSSCCHcodes	Maximum number of HSSCCH codes that can be assigned to a UE	4	REL-5
maxPCPCH-APsubCH	Maximum number of available sub-channels for AP signature on PCPCH	12	
maxPCPCH-CDsubCH	Maximum number of available sub-channels for CD signature on PCPCH	12	
maxPCPCH-APsig	Maximum number of available signatures for AP on PCPCH	16	
maxPCPCH-CDsig	Maximum number of available signatures for CD on PCPCH	16	
maxAC	Maximum number of access classes	16	
maxASC	Maximum number of access service classes	8	
maxASCmap	Maximum number of access class to access service classes mappings	7	
maxASCpersist	Maximum number of access service classes for which persistence scaling factors are specified	6	
maxPRACH	Maximum number of PRACHs in a cell	16	
MaxPRACH_FPACH	Maximum number of PRACH / FPACH pairs in a cell (1.28 Mcps TDD)	8	REL-4
maxFACHPCH	Maximum number of FACHs and PCHs mapped onto one secondary CCPCHs	8	
maxRL	Maximum number of radio links	8	
maxSCCPCH	Maximum number of secondary CCPCHs per cell	16	
maxDPDCH-UL	Maximum number of DPDCHs per cell	6	
maxDPCH-DLchan	Maximum number of channelisation codes used for DL DPCH	8	
maxPUSCH	Maximum number of PUSCHs	(8)	
maxPDSCH	Maximum number of PDSCHs	8	
maxPDSCHcodes	Maximum number of codes for PDSCH	16	
maxPDSCH-TFCIgroups	Maximum number of TFCI groups for PDSCH	256	
maxPDSCHcodeGroups	Maximum number of code groups for PDSCH	256	
maxPCPCHs	Maximum number of PCPCH channels in a CPCH Set	64	
maxPCPCH-SF	Maximum number of available SFs on PCPCH	7	
maxTS	Maximum number of timeslots used in one direction (UL or DL)	14 (3.84 Mcps TDD)	
		6 (1.28 Mcps TDD)	REL-4
hiPUSCHidentities	Maximum number of PUSCH Identities	64	
hiPDSCHidentities	Maximum number of PDSCH Identities	64	
Measurement information	Maximum number of transmission was a sur-	6	
maxTGPS	Maximum number of transmission gap pattern sequences	6	
maxAdditionalMeas	Maximum number of additional measurements for a given measurement identity	4	
maxMeasEvent	Maximum number of events that can be listed in measurement reporting criteria	8	
maxMeasParEvent	Maximum number of measurement parameters (e.g. thresholds) per event	2	
maxMeasIntervals	Maximum number of intervals that define the mapping function between the measurements for	1	

Constant	Explanation	Value	Version
	the cell quality Q of a cell and the representing		
	quality value		
maxCellMeas	Maximum number of cells to measure	32	
maxReportedGSMCells	Maximum number of GSM cells to be reported	8	
maxFreq	Maximum number of frequencies to measure	8	
maxSat	Maximum number of satellites to measure	16	
maxSatAlmanacStorage	Maximum number of satellites for which to store GPS Almanac information	32	
HiRM	Maximum number that could be set as rate matching attribute for a transport channel	256	
Frequency information			
MaxFDDFreqList	Maximum number of FDD carrier frequencies to be stored in USIM	4	
MaxTDDFreqList	Maximum number of TDD carrier frequencies to be stored in USIM	4	
MaxFDDFreqCellList	Maximum number of neighbouring FDD cells to be stored in USIM	32	
MaxTDDFreqCellList	Maximum number of neighbouring TDD cells to be stored in USIM	32	
MaxGSMCellList	Maximum number of GSM cells to be stored in USIM	32	
Other information			
MaxGERANSI	Maximum number of GERAN SI blocks that can be provided as part of NACC information	8	REL-5
maxNumGSMFreqRanges	Maximum number of GSM Frequency Ranges to store	32	
MaxNumFDDFreqs	Maximum number of FDD centre frequencies to store	8	
MaxNumTDDFreqs	Maximum number of TDD centre frequencies to store	8	
maxNumCDMA200Freqs	Maximum number of CDMA2000 centre frequencies to store	8	

11 Message and Information element abstract syntax (with ASN.1)

This clause contains definitions for RRC PDUs and IEs using a subset of ASN.1 as specified in [14]. PDU and IE definitions are grouped into separate ASN.1 modules.

11.0 General

Some messages and/or IEs may include one or more IEs with name "dummy" that are included only in the ASN.1. The UE should avoid sending information elements that are named "dummy" to UTRAN. Likewise, UTRAN should avoid sending IEs with name "dummy" to the UE. If the UE anyhow receives an information element named "dummy", it shall ignore the IE and process the rest of the message as if the IE was not included.

NOTE: An IE with name "dummy" concerns an information element that was (erroneously) included in a previous version of the specification and has been removed by replacing it with a dummy with same type.

The UE shall only include the "variable length extension container" when it sends a non critical extension that according to this specification shall be transferred within this container.

If the abstract syntax of an IE is defined using the ASN.1 type "BIT STRING", and this IE corresponds to a functional IE definition in tabular format, in which the significance of bits is semantically defined, the following general rule shall be applied:

The bits in the ASN.1 bit string shall represent the semantics of the functional IE definition in decreasing order of bit significance;

- with the first (or leftmost) bit in the bit string representing the most significant bit; and
- with the last (or rightmost) bit in the bit string representing the least significant bit.

11.1 General message structure

Class-definitions DEFINITIONS AUTOMATIC TAGS ::= BEGIN IMPORTS ActiveSetUpdate, ActiveSetUpdateComplete, ActiveSetUpdateFailure, AssistanceDataDelivery, CellChangeOrderFromUTRAN, CellChangeOrderFromUTRANFailure, CellUpdate, CellUpdateConfirm-CCCH, CellUpdateConfirm, CounterCheck, CounterCheckResponse, DownlinkDirectTransfer, HandoverToUTRANComplete, InitialDirectTransfer, HandoverFromUTRANCommand-GERANIu, HandoverFromUTRANCommand-GSM, ${\tt HandoverFromUTRANCommand-CDMA2000,}$ HandoverFromUTRANFailure, MeasurementControl, MeasurementControlFailure, MeasurementReport, PagingType1, PagingType2, PhysicalChannelReconfiguration, PhysicalChannelReconfigurationComplete, PhysicalChannelReconfigurationFailure, PhysicalSharedChannelAllocation, PUSCHCapacityRequest, RadioBearerReconfiguration, RadioBearerReconfigurationComplete, RadioBearerReconfigurationFailure, RadioBearerRelease RadioBearerReleaseComplete, RadioBearerReleaseFailure, RadioBearerSetup, RadioBearerSetupComplete, RadioBearerSetupFailure, RRCConnectionReject, RRCConnectionRelease, RRCConnectionRelease-CCCH, RRCConnectionReleaseComplete, RRCConnectionRequest, RRCConnectionSetup, RRCConnectionSetupComplete, RRCStatus, SecurityModeCommand, SecurityModeComplete, SecurityModeFailure, SignallingConnectionRelease, SignallingConnectionReleaseIndication, SystemInformation-BCH, SystemInformation-FACH, SystemInformationChangeIndication, TransportChannelReconfiguration, TransportChannelReconfigurationComplete, TransportChannelReconfigurationFailure, TransportFormatCombinationControl, ${\tt TransportFormatCombinationControlFailure,}$ UECapabilityEnquiry, UECapabilityInformation, UECapabilityInformationConfirm, UplinkDirectTransfer, UplinkPhysicalChannelControl, URAUpdate,

```
URAUpdateConfirm,
   URAUpdateConfirm-CCCH,
   UTRANMobilityInformation,
   {\tt UTRANMobilityInformationConfirm,}\\
   UTRANMobilityInformationFailure
FROM PDU-definitions
-- User Equipment IEs :
   IntegrityCheckInfo
FROM InformationElements;
__*********************
-- Downlink DCCH messages
__********************
DL-DCCH-Message ::= SEQUENCE {
   integrityCheckInfo IntegrityCheckInfo
                                                  OPTIONAL.
                          DL-DCCH-MessageType
   message
}
DL-DCCH-MessageType ::= CHOICE {
   activeSetUpdate
                                      ActiveSetUpdate,
   assistanceDataDeliverv
                                      AssistanceDataDelivery.
   cellChangeOrderFromUTRAN
                                      CellChangeOrderFromUTRAN,
   {\tt cellUpdateConfirm}
                                      CellUpdateConfirm,
   counterCheck
                                      CounterCheck,
   downlinkDirectTransfer
                                      DownlinkDirectTransfer,
   handoverFromUTRANCommand-GSM
                                      HandoverFromUTRANCommand-GSM,
   handoverFromUTRANCommand-CDMA2000
                                      HandoverFromUTRANCommand-CDMA2000,
   {\tt measurementControl}
                                      MeasurementControl,
   pagingType2
                                      PagingType2,
   physicalChannelReconfiguration
                                      PhysicalChannelReconfiguration,
   physicalSharedChannelAllocation
                                      PhysicalSharedChannelAllocation,
   radioBearerReconfiguration
                                      RadioBearerReconfiguration,
   radioBearerRelease
                                      RadioBearerRelease,
   radioBearerSetup
                                      RadioBearerSetup,
   rrcConnectionRelease
                                      RRCConnectionRelease,
   securityModeCommand
                                      SecurityModeCommand,
   \verb|signallingConnectionRelease|\\
                                      SignallingConnectionRelease,
   transportChannelReconfiguration
                                      TransportChannelReconfiguration,
   transportFormatCombinationControl
                                      TransportFormatCombinationControl,
   ueCapabilityEnquiry
                                      UECapabilityEnquiry,
   {\tt ueCapabilityInformationConfirm}
                                      UECapabilityInformationConfirm,
   uplinkPhysicalChannelControl
                                      UplinkPhysicalChannelControl,
                                      URAUpdateConfirm,
   uraUpdateConfirm
   utranMobilityInformation
                                      UTRANMobilityInformation,
   handoverFromUTRANCommand-GERANIu
                                      HandoverFromUTRANCommand-GERANIu,
   spare6
                                      NULL,
   spare5
                                      NULL,
   spare4
                                      NULT.
   spare3
                                      NULL,
   spare2
                                      NULL.
   spare1
                                      NULL
}
__**********************************
-- Uplink DCCH messages
__*********************
UL-DCCH-Message ::= SEQUENCE {
                                                OPTIONAL,
   integrityCheckInfo
                        IntegrityCheckInfo
                          UL-DCCH-MessageType
UL-DCCH-MessageType ::= CHOICE {
   \verb"activeSetUpdateComplete"
                                      ActiveSetUpdateComplete,
   activeSetUpdateFailure
                                     ActiveSetUpdateFailure,
   cellChangeOrderFromUTRANFailure
                                      CellChangeOrderFromUTRANFailure,
   counterCheckResponse
                                      CounterCheckResponse,
   handoverToUTRANComplete
                                      HandoverToUTRANComplete,
   initialDirectTransfer
                                      InitialDirectTransfer,
   handoverFromUTRANFailure
                                     HandoverFromUTRANFailure,
   measurementControlFailure
                                      MeasurementControlFailure.
   measurementReport
                                      MeasurementReport,
```

```
\verb|physicalChannelReconfigurationComplete| \\
                                     PhysicalChannelReconfigurationComplete,
   physicalChannelReconfigurationFailure
                                     PhysicalChannelReconfigurationFailure,
   radio Bearer Reconfiguration Complete \quad Radio Bearer Reconfiguration Complete \,, \\
   radioBearerReconfigurationFailure RadioBearerReconfigurationFailure,
   radioBearerReleaseComplete
                                     RadioBearerReleaseComplete,
   radioBearerReleaseFailure
                                     RadioBearerReleaseFailure,
   radioBearerSetupComplete
                                     RadioBearerSetupComplete,
   radioBearerSetupFailure
                                     RadioBearerSetupFailure,
   rrcConnectionReleaseComplete
                                     RRCConnectionReleaseComplete,
   rrcConnectionSetupComplete
                                     RRCConnectionSetupComplete,
   rrcStatus
                                     RRCStatus,
   securityModeComplete
                                     SecurityModeComplete,
   securityModeFailure
                                     SecurityModeFailure,
   \verb|signallingConnectionReleaseIndication|\\
                                     SignallingConnectionReleaseIndication,
   transport {\tt Channel Reconfiguration Complete}
                                     TransportChannelReconfigurationComplete,
   transportChannelReconfigurationFailure
                                     TransportChannelReconfigurationFailure,
   transport {\tt FormatCombinationControlFailure}
                                     {\tt TransportFormatCombinationControlFailure,}
                                     UECapabilityInformation,
   ueCapabilityInformation
   uplinkDirectTransfer
                                     UplinkDirectTransfer,
   utranMobilityInformationConfirm
                                     UTRANMobilityInformationConfirm,
   utranMobilityInformationFailure
                                     UTRANMobilityInformationFailure,
   spare2
                                     NULL,
   spare1
                                     NULL
}
__*********************
-- Downlink CCCH messages
__*****************
DL-CCCH-Message ::= SEQUENCE {
   {\tt integrityCheckInfo} \qquad {\tt IntegrityCheckInfo}
                                                OPTIONAL,
                          DL-CCCH-MessageType
   message
}
DL-CCCH-MessageType ::= CHOICE {
   cellUpdateConfirm
                                     CellUpdateConfirm-CCCH,
   rrcConnectionReject
                                     RRCConnectionReject,
   rrcConnectionRelease
                                     RRCConnectionRelease-CCCH,
                                     RRCConnectionSetup,
   rrcConnectionSetup
                                     URAUpdateConfirm-CCCH,
   uraUpdateConfirm
   spare3
                                     NULL,
   spare2
                                     NULL,
   spare1
                                     NULL
}
__**********************
-- Uplink CCCH messages
__*********************
UL-CCCH-Message ::= SEQUENCE {
                          IntegrityCheckInfo
   integrityCheckInfo
                                                OPTIONAL,
   message
                          UL-CCCH-MessageType
}
UL-CCCH-MessageType ::= CHOICE {
   cellUpdate
                                     CellUpdate,
   rrcConnectionRequest
                                     RRCConnectionRequest,
   uraUpdate
                                     URAUpdate,
   spare
                                     NULL
}
__*********************
-- PCCH messages
__*********************
PCCH-Message ::= SEQUENCE {
```

```
PCCH-MessageType
}
PCCH-MessageType ::= CHOICE {
  pagingTypel
                             PagingType1,
   spare
}
__********************
-- Downlink SHCCH messages
__*****************
DL-SHCCH-Message ::= SEQUENCE {
                 DL-SHCCH-MessageType
  message
DL-SHCCH-MessageType ::= CHOICE {
  physicalSharedChannelAllocation PhysicalSharedChannelAllocation,
   spare
                             NULL
}
__*********************
-- Uplink SHCCH messages
__*********************
UL-SHCCH-Message ::= SEQUENCE {
                    UL-SHCCH-MessageType
UL-SHCCH-MessageType ::= CHOICE {
  puschCapacityRequest
                             PUSCHCapacityRequest,
}
__**********************
-- BCCH messages sent on FACH
__********************
BCCH-FACH-Message ::= SEQUENCE {
                BCCH-FACH-MessageType
  message
BCCH-FACH-MessageType ::= CHOICE {
                             SystemInformation-FACH,
  systemInformation
   systemInformationChangeIndication SystemInformationChangeIndication,
                             NULL,
  spare1
}
__**********************
-- BCCH messages sent on BCH
__********************
BCCH-BCH-Message ::= SEQUENCE {
                SystemInformation-BCH
  message
END
```

11.2 PDU definitions

```
__*********************
PDU-definitions DEFINITIONS AUTOMATIC TAGS ::=
BEGIN
__*********************
-- IE parameter types from other modules
__**********************************
TMPORTS
-- Core Network IEs :
   CN-DomainIdentity,
   CN-InformationInfo,
   CN-InformationInfoFull,
   NAS-Message,
   PagingRecordTypeID,
-- UTRAN Mobility IEs :
   CellIdentity,
   CellIdentity-PerRL-List,
   URA-Identity,
-- User Equipment IEs :
   AccessStratumReleaseIndicator,
   ActivationTime,
   C-RNTI,
   CapabilityUpdateRequirement,
   CapabilityUpdateRequirement-r4,
   CapabilityUpdateRequirement-r4-ext,
   CapabilityUpdateRequirement-r5,
   CellUpdateCause,
   CipheringAlgorithm,
   CipheringModeInfo,
   DSCH-RNTI,
   EstablishmentCause,
   FailureCauseWithProtErr,
   FailureCauseWithProtErrTrId,
   GroupReleaseInformation,
   UESpecificBehaviourInformationlidle,
   UESpecificBehaviourInformationlinterRAT,
   InitialUE-Identity,
   IntegrityProtActivationInfo,
   IntegrityProtectionModeInfo,
   N - 308.
   PagingCause,
   PagingRecordList,
   PagingRecord2List-r5,
   ProtocolErrorIndicator.
   ProtocolErrorIndicatorWithMoreInfo,
   RadioFrequencyBandTDDList,
   Rb-timer-indicator,
   RedirectionInfo,
   RejectionCause,
   ReleaseCause,
   RF-CapabilityComp,
   RRC-StateIndicator,
   RRC-TransactionIdentifier.
   SecurityCapability,
   START-Value,
   STARTList,
   SystemSpecificCapUpdateReq-v590ext,
   U-RNTI,
   U-RNTI-Short,
   UE-RadioAccessCapability,
   UE-RadioAccessCapability-v370ext,
   UE-RadioAccessCapability-v380ext,
   UE-RadioAccessCapability-v3a0ext,
   UE-RadioAccessCapability-v3g0ext,
   UE-RadioAccessCapability-v4b0ext,
   UE-RadioAccessCapability-v590ext,
   UE-RadioAccessCapabilityComp,
   DL-PhysChCapabilityFDD-v380ext,
   UE-ConnTimersAndConstants,
   UE-ConnTimersAndConstants-v3a0ext,
   UE-ConnTimersAndConstants-r5,
```

```
UE-SecurityInformation,
   URA-UpdateCause,
   UTRAN-DRX-CycleLengthCoefficient,
   WaitTime,
-- Radio Bearer IEs :
   DefaultConfigIdentity,
   DefaultConfigIdentity-r4,
   DefaultConfigIdentity-r5,
   DefaultConfigMode,
   DL-CounterSynchronisationInfo,
   DL-CounterSynchronisationInfo-r5,
   PredefinedConfigIdentity,
   PredefinedConfigStatusList
   PredefinedConfigStatusListComp,
   PredefinedConfigSetWithDifferentValueTag,
   RAB-Info,
   RAB-Info-Post,
   RAB-InformationList,
   RAB-InformationReconfigList,
   RAB-InformationSetupList,
   RAB-InformationSetupList-r4,
   RAB-InformationSetupList-r5,
   RB-ActivationTimeInfoList,
   RB-COUNT-C-InformationList,
   RB-COUNT-C-MSB-InformationList,
   RB-IdentityList,
   RB-InformationAffectedList,
   RB-InformationAffectedList-r5,
   RB-InformationReconfigList,
   RB-InformationReconfigList-r4,
   RB-InformationReconfigList-r5,
   RB-InformationReleaseList,
   RB-PDCPContextRelocationList,
   SRB-InformationSetupList,
   SRB-InformationSetupList-r5,
   SRB-InformationSetupList2,
   UL-CounterSynchronisationInfo,
-- Transport Channel IEs:
   CPCH-SetID,
   DL-AddReconfTransChInfo2List,
   DL-AddReconfTransChInfoList,
   DL-AddReconfTransChInfoList-r4,
   DL-AddReconfTransChInfoList-r5,
   DL-CommonTransChInfo,
   DL-CommonTransChInfo-r4,
   DL-DeletedTransChInfoList,
   DL-DeletedTransChInfoList-r5.
   DRAC-StaticInformationList,
   TFC-Subset,
   TFCS-Identity,
   UL-AddReconfTransChInfoList,
   UL-CommonTransChInfo,
   UL-CommonTransChInfo-r4,
   UL-DeletedTransChInfoList,
-- Physical Channel IEs :
   Alpha,
   CCTrCH-PowerControlInfo,
   CCTrCH-PowerControlInfo-r4,
   CCTrCH-PowerControlInfo-r5,
   ConstantValue.
   ConstantValueTdd,
   CPCH-SetInfo,
   DL-CommonInformation,
   DL-CommonInformation-r4,
   DL-CommonInformation-r5,
   DL-CommonInformationPost,
   DL-HSPDSCH-Information,
   DL-InformationPerRL-List,
   DL-InformationPerRL-List-r4,
   DL-InformationPerRL-List-r5
   DL-InformationPerRL-List-r5bis,
   DL-InformationPerRL-ListPostFDD,
   DL-InformationPerRL-PostTDD,
   DL-InformationPerRL-PostTDD-LCR-r4,
   DL-PDSCH-Information,
   DL-TPC-PowerOffsetPerRL-List,
   DPC-Mode.
   DPCH-CompressedModeStatusInfo,
```

```
FrequencyInfo,
   FrequencyInfoFDD,
   FrequencyInfoTDD,
   HS-SICH-Power-Control-Info-TDD384,
   MaxAllowedUL-TX-Power,
   OpenLoopPowerControl-IPDL-TDD-r4,
   PDSCH-CapacityAllocationInfo,
   PDSCH-CapacityAllocationInfo-r4,
   PDSCH-Identity,
   PrimaryCPICH-Info,
   PrimaryCCPCH-TX-Power,
   PUSCH-CapacityAllocationInfo,
   PUSCH-CapacityAllocationInfo-r4,
   PUSCH-Identity,
   PUSCH-SysInfoList-HCR-r5,
   PDSCH-SysInfoList-HCR-r5,
   RL-AdditionInformationList,
   RL-RemovalInformationList,
   SpecialBurstScheduling,
   SSDT-Information,
   TFC-ControlDuration,
   SSDT-UL,
   TimeslotList,
   TimeslotList-r4,
   TX-DiversityMode,
   UL-ChannelRequirement,
   UL-ChannelRequirement-r4,
   UL-ChannelRequirement-r5,
   UL-ChannelRequirementWithCPCH-SetID,
   UL-ChannelRequirementWithCPCH-SetID-r4,
   UL-ChannelRequirementWithCPCH-SetID-r5,
   UL-DPCH-Info,
   UL-DPCH-Info-r4,
   UL-DPCH-Info-r5,
   UL-DPCH-InfoPostFDD,
   UL-DPCH-InfoPostTDD,
   UL-DPCH-InfoPostTDD-LCR-r4,
   UL-SynchronisationParameters-r4,
   UL-TimingAdvance,
   UL-TimingAdvanceControl,
   UL-TimingAdvanceControl-r4,
-- Measurement IEs :
   AdditionalMeasurementID-List,
   DeltaRSCP,
   Frequency-Band,
   EventResults,
   Inter-FreqEventCriteriaList-v590ext,
   Intra-FreqEventCriteriaList-v590ext,
   IntraFreqReportingCriteria-1b-r5,
   IntraFreqEvent-1d-r5,
   InterFreqEventResults-LCR-r4-ext,
   InterRAT-TargetCellDescription,
   MeasuredResults,
   MeasuredResults-v390ext,
   MeasuredResults-v590ext,
   MeasuredResultsList,
   MeasuredResultsList-LCR-r4-ext,
   MeasuredResultsOnRACH,
   MeasurementCommand,
   MeasurementCommand-r4,
   MeasurementIdentity,
   MeasurementReportingMode,
   PrimaryCCPCH-RSCP,
   SFN-Offset-Validity
   TimeslotListWithISCP.
   TrafficVolumeMeasuredResultsList,
   UE-Positioning-GPS-AssistanceData,
   UE-Positioning-Measurement-v390ext,
   UE-Positioning-OTDOA-AssistanceData,
   UE-Positioning-OTDOA-AssistanceData-r4ext,
   UE-Positioning-OTDOA-AssistanceData-UEB,
-- Other IEs :
   BCCH-ModificationInfo,
   CDMA2000-MessageList,
   GERANIu-MessageList,
   GERAN-SystemInformation,
   GSM-MessageList,
   InterRAT-ChangeFailureCause,
   InterRAT-HO-FailureCause,
```

```
InterRAT-UE-RadioAccessCapabilityList,
    InterRAT-UE-RadioAccessCapability-v590ext,
    InterRAT-UE-SecurityCapList,
    IntraDomainNasNodeSelector,
    ProtocolErrorMoreInformation,
    Rplmn-Information,
    Rplmn-Information-r4,
    SegCount,
    SegmentIndex,
    SFN-Prime,
    SIB-Data-fixed,
    SIB-Data-variable,
    SIB-Type
FROM InformationElements
    maxSIBperMsg,
    maxURNTI-Group
FROM Constant-definitions;
__ ****************
-- ACTIVE SET UPDATE (FDD only)
__ ***************
ActiveSetUpdate ::= CHOICE {
                                      SEQUENCE {
        ActiveSetUpdate-r3-IEs, laterNonCriticalExtensions

-- Control

-- Control
            -- Container for additional R99 extensions
activeSetUpdate-r3-add-ext BIT STRING OPTIONAL,
v4b0NonCriticalExtensions SEQUENCE {
   activeSetUpdate-v4b0ext v590NonCriticalExtensions activeSetUpdate-v590ext nonCriticalExtensions SEQUENCE {
        ActiveSetUpdate-v590ext nonCriticalExtensions SEQUENCE {} OPTIONAL
             -- Container for additional R99 extensions
                     OPTIONAL
             } OPTIONAL
         } OPTIONAL
                                       SEQUENCE {
    later-than-r3
        rrc-TransactionIdentifier RRC-TransactionIdentifier,
        criticalExtensions
                                            SEQUENCE {}
}
ActiveSetUpdate-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier
                                          RRC-TransactionIdentifier,
         -- dummy and dummy2 are not used in this version of the specification, they should
         -- not be sent and if received they should be ignored.
        dummy
                                       IntegrityProtectionModeInfo
                                                                               OPTIONAL,
        dummy2
                                       CipheringModeInfo
                                                                               OPTIONAL.
        activationTime
                                            ActivationTime
                                                                                    OPTIONAL,
        newU-RNTI
                                            U-RNTI
                                                                                    OPTIONAL,
    -- Core network IEs
         cn-InformationInfo
                                           CN-InformationInfo
                                                                                    OPTIONAL,
    -- Radio bearer IEs
        -- dummy3 is not used in this version of the specification, it should
         -- not be sent and if received it should be ignored.
        dummy3
                                  DL-CounterSynchronisationInfo
                                                                             OPTIONAL,
    -- Physical channel IEs
        maxAllowedUL-TX-Power
                                           MaxAllowedUL-TX-Power
                                                                                   OPTIONAL,
        rl-AdditionInformationList RL-AdditionInformationList rl-RemovalInformationList RL-DiversityMode TX-DiversityMode
                                           RL-AdditionInformationList
                                                                                   OPTIONAL.
                                                                                 OPTIONAL,
                                            TX-DiversityMode
         tx-DiversityMode
                                                                                   OPTIONAL,
        ssdt-Information
                                           SSDT-Information
                                                                                   OPTIONAL
}
ActiveSetUpdate-v4b0ext-IEs ::= SEQUENCE {
    -- Physical channel IEs
        -- ssdt-UL extends SSDT-Information. FDD only.
         ssdt-UL-r4
                                                SSDT-UL
                                                                                        OPTIONAL,
         -- The order of the RLs in IE cell-id-PerRL-List is the same as
         -- in IE RL-AdditionInformationList included in this message
        cell-id-PerRL-List
                                                CellIdentity-PerRL-List
                                                                                        OPTIONAL
ActiveSetUpdate-v590ext-IEs ::= SEQUENCE {
```

```
-- Physical channel IEs
      dpc-Mode
                                    DPC-Mode,
                                 DL-TPC-PowerOffsetPerRL-List OPTIONAL
      dl-TPC-PowerOffsetPerRL-List
}
 *************
-- ACTIVE SET UPDATE COMPLETE (FDD only)
__ ******************
ActiveSetUpdateComplete ::= SEQUENCE {
   -- User equipment IEs
                              RRC-TransactionIdentifier,
      rrc-TransactionIdentifier
       -- dummy is not used in this version of the specification, it should
       -- not be sent and if received it should be ignored.
      dummy
                             IntegrityProtActivationInfo
                                                           OPTIONAL,
   -- Radio bearer IEs
      -- dummy2 and dummy3 are not used in this version of the specification, they should
       -- not be sent and if received they should be ignored.
                        RB-ActivationTimeInfoList
                                                            OPTIONAL.
      dummy2
      OPTIONAL,
         -- Container for additional R99 extensions
          activeSetUpdateComplete-r3-add-ext BIT STRING
                                                        OPTIONAL,
                              SEQUENCE {} OPTIONAL
         nonCriticalExtensions
      } OPTIONAL
}
__ ***************
-- ACTIVE SET UPDATE FAILURE (FDD only)
__ ***************
ActiveSetUpdateFailure ::= SEQUENCE {
   -- User equipment IEs
      User equipment IEs
rrc-TransactionIdentifier RRC-TransactionIdentifier,
failureCause FailureCauseWithProtErr,
laterNonCriticalExtensions SEQUENCE {
          -- Container for additional R99 extensions
         activeSetUpdateFailure-r3-add-ext BIT STRING
                                                        OPTIONAL.
         nonCriticalExtensions SEQUENCE {} OPTIONAL
     OPTIONAL
}
 ************
-- Assistance Data Delivery
__ ***************
AssistanceDataDelivery ::= CHOICE {
                              SEQUENCE {
      assistanceDataDelivery-r3 AssistanceDataDelivery-r3-IEs, v3a0NonCriticalExtensions SEQUENCE {
         -- Container for additional R99 extensions
             {\tt assistanceDataDelivery-r3-add-ext} \qquad {\tt BIT\ STRING} \qquad {\tt OPTIONAL},
             v4b0NonCriticalExtensions SEQUENCE {
                assistanceDataDelivery-v4b0ext
                                           AssistanceDataDelivery-v4b0ext-IEs,
                nonCriticalExtensions
                                           SEQUENCE {}
                                                                      OPTIONAL
               OPTIONAL
          OPTIONAL
      } OPTIONAL
                             SEQUENCE {
   later-than-r3
      }
}
AssistanceDataDelivery-r3-IEs ::= SEQUENCE {
  -- User equipment IEs
   rrc-TransactionIdentifier
                          RRC-TransactionIdentifier,
   -- Measurement Information Elements
```

```
ue-positioning-GPS-AssistanceData
                                          UE-Positioning-GPS-AssistanceData
   OPTIONAL,
   ue-positioning-OTDOA-AssistanceData-UEB
                                          UE-Positioning-OTDOA-AssistanceData-UEB
   OPTIONAL
}
AssistanceDataDelivery-v3a0ext ::= SEQUENCE \{
                                   SFN-Offset-Validity OPTIONAL
   sfn-Offset-Validity
AssistanceDataDelivery-v4b0ext-IEs ::= SEQUENCE {
   ue-Positioning-OTDOA-AssistanceData-r4ext UE-Positioning-OTDOA-AssistanceData-r4ext OPTIONAL
 __ *************
-- CELL CHANGE ORDER FROM UTRAN
__ ****************
CellChangeOrderFromUTRAN ::= CHOICE {
                                SEQUENCE {
       cellChangeOrderFromUTRAN-IES CellChangeOrderFromUTRAN-r3-IEs, laterNonCriticalExtensions SEQUENCE {
           -- Container for additional R99 extensions
           cellChangeOrderFromUTRAN-r3-add-ext BIT STRING
                                                            OPTIONAL,
           v590NonCriticalExtensions
                                          SEQUENCE {
              \verb|cellChangeOrderFromUTRAN-v590ext| CellChangeOrderFromUTRAN-v590ext-IEs, \\
              OPTIONAL
         OPTIONAL
      er-than-r3 SEQUENCE {
    rrc-TransactionIdentifier RRC-TransactionIdentifier,
    criticalExtensions SEQUENCE {}
   later-than-r3
}
CellChangeOrderFromUTRAN-r3-IEs ::= SEQUENCE {
   -- User equipment IEs
      -- dummy is not used in this version of the specification, it should
       -- not be sent and if received it should be ignored.
                                   IntegrityProtectionModeInfo
ActivationTime
                                                                     OPTIONAL,
       activationTime
       -- the IE rab-InformationList is not used in this version of the specification, it should
       -- not be sent and if received it should be ignored. The IE may be used in a later
       -- version of the protocol and hence it is not changed into a dummy
       rab-InformationList
                                   RAB-InformationList
                                                                     OPTIONAL,
       interRAT-TargetCellDescription InterRAT-TargetCellDescription
}
CellChangeOrderFromUTRAN-v590ext-IEs ::= SEQUENCE {
       geran-SystemInfoType CHOICE
                                           GERAN-SystemInformation,
          sI
          pSI
                                           {\tt GERAN-SystemInformation}
              OPTIONAL
}
  ************
-- CELL CHANGE ORDER FROM UTRAN FAILURE
  CellChangeOrderFromUTRANFailure ::= CHOICE {
                                SEQUENCE {
       cellChangeOrderFromUTRANFailure-r3
       CellChangeOrderFromUTRANFailure-r3-IEs, laterNonCriticalExtensions SEQUENCE {
           -- Container for additional R99 extensions
           cellChangeOrderFromUTRANFailure-r3-add-ext
                                                    BIT STRING OPTIONAL,
                                       SEQUENCE {} OPTIONAL
          nonCriticalExtensions
       } OPTIONAL
    -- dummy is not used in this version of the specification and it
    -- should be ignored.
                                SEQUENCE {
   dummy
```

```
{\tt rrc-TransactionIdentifier} \qquad {\tt RRC-TransactionIdentifier},
       criticalExtensions
                                     SEQUENCE {}
   }
}
CellChangeOrderFromUTRANFailure-r3-IEs ::= SEQUENCE {
   -- User equipment IEs
       rrc-TransactionIdentifier
                                  RRC-TransactionIdentifier,
       -- dummy is not used in this version of the specification, it should
       -- not be sent and if received it should be ignored.
       dummy
                                   IntegrityProtectionModeInfo
                                                                      OPTIONAL,
                                     InterRAT-ChangeFailureCause
       interRAT-ChangeFailureCause
__ **************
-- CELL UPDATE
__ *******************************
CellUpdate ::= SEQUENCE {
    -- User equipment IEs
       u-RNTI
                                     U-RNTI,
                  STARTList,
       startList
       am-klC-ErrorIndicationRb2-3or4 BOOLEAN, am-RLC-ErrorIndicationRb5orAbove BOOLEAN, cellIndateCours
       cellUpdateCause
                                   CellUpdateCause,
        -- TABULAR: RRC transaction identifier is nested in FailureCauseWithProtErrTrId
                          FailureCauseWithProtErrTrId OPTIONAL,
       failureCause
       rb-timer-indicator
                                    Rb-timer-indicator,
   -- Measurement IEs
       Measurement IEs
measuredResultsOnRACH
laterNonCriticalExtensions
MeasuredResultsOnRACH
SEQUENCE {
           -- Container for additional R99 extensions
           cellUpdate-v590ext CellUpdate-v590ext,
               nonCriticalExtensions
                                      SEQUENCE {} OPTIONAL
                  OPTIONAL
           OPTIONAL
}
CellUpdate-v590ext ::= SEQUENCE {
   {\tt establishmentCause}
                                 EstablishmentCause OPTIONAL
__ **************************
-- CELL UPDATE CONFIRM
__ ***************
CellUpdateConfirm ::= CHOICE {
       v3a0NonCriticalExtensions

cellUpdateConfirm-r3-IEs,

SECULEMOR (
                                SEQUENCE {
           DNonCriticalExtensions SEQUENCE {
    cellUpdateConfirm-v3a0ext, laterNonCriticalExtensions SEQUENCE {
               -- Container for additional R99 extensions
              SEQUENCE {
                                                   CellUpdateConfirm-v590ext-IEs,
                      cellUpdateConfirm-v590ext
                      nonCriticalExtensions
                                                       SEQUENCE {} OPTIONAL
                         OPTIONAL
                      OPTIONAL
                  OPTIONAL
           }
       }
               OPTIONAL
                                 SEQUENCE {
       rrc-TransactionIdentifier RRC-TransactionIdentifier, criticalExtensions CHOICE {
               cellUpdateConfirm-r4
           r4
               v4d0NonCriticalExtensions

-- Container C
                   -- Container for adding non critical extensions after freezing REL-5
                  cellUpdateConfirm-r4-add-ext BIT STRING v590NonCriticalExtenstions SEQUENCE {
                                                                  OPTIONAL,
```

```
cellUpdateConfirm-v590ext
                                                             CellUpdateConfirm-v590ext-IEs,
                        nonCriticalExtensions
                                                         SEQUENCE {}
                                                                      OPTIONAL
                        OPTIONAL
                }
                    OPTIONAL.
            },
            criticalExtensions
                                             CHOICE {
                                               SEQUENCE {
                r5
                    cellUpdateConfirm-r5
                                                    CellUpdateConfirm-r5-IEs,
                     -- Container for adding non critical extensions after freezing REL-6
                    cellUpdateConfirm-r5-add-ext
                                                         BIT STRING
                                                                         OPTIONAL,
                    nonCriticalExtensions
                                                     SEQUENCE {}
                                                                     OPTIONAL
                criticalExtensions
                                        SEQUENCE {}
            }
        }
    }
}
CellUpdateConfirm-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier
                                        RRC-TransactionIdentifier,
        integrityProtectionModeInfo
                                         IntegrityProtectionModeInfo
                                                                              OPTIONAL,
        cipheringModeInfo
                                        CipheringModeInfo
                                                                              OPTIONAL,
        activationTime
                                         ActivationTime
                                                                              OPTIONAL,
        new-U-RNTI
                                        U-RNTI
                                                                              OPTIONAL.
        new-C-RNTI
                                         C-RNTI
                                                                              OPTIONAL.
        rrc-StateIndicator
                                        RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff
                                       UTRAN-DRX-CycleLengthCoefficient
                                                                              OPTIONAL,
        rlc-Re-establishIndicatorRb2-3or4
                                                 BOOLEAN,
        rlc-Re-establishIndicatorRb5orAbove
                                                BOOLEAN.
    -- CN information elements
        cn-InformationInfo
                                        CN-InformationInfo
                                                                              OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity
                                        URA-Identity
                                                                              OPTIONAL,
    -- Radio bearer IEs
        rb-InformationReleaseList RB-InformationReleaseList rb-InformationAffectedList RB-InformationAffectedList
                                                                              OPTIONAL.
                                                                              OPTIONAL,
        dl-CounterSynchronisationInfo DL-CounterSynchronisationInfo
                                                                             OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo
                                        UL-CommonTransChInfo
                                                                              OPTIONAL,
        ul-deletedTransChInfoList
                                         UL-DeletedTransChInfoList
                                                                              OPTIONAL,
        ul-AddReconfTransChInfoList
                                        UL-AddReconfTransChInfoList
                                                                              OPTIONAL,
        modeSpecificTransChInfo
                                        CHOICE {
            fdd
                                             SEQUENCE {
                cpch-SetID
                                                 CPCH-SetID
                                                                              OPTIONAL,
                addReconfTransChDRAC-Info
                                                 DRAC-StaticInformationList OPTIONAL
            },
            tdd
                                             NITIT.T.
        DL-CommonTransChInfo
dl-DeletedTransChInfoList
dl-AddReconfTransChInfoList
Physical channel TEC
DL-AddReconfTransChInfoList
                                                                              OPTIONAL,
                                        DL-DeletedTransChInfoList
                                                                              OPTIONAL,
                                        DL-AddReconfTransChInfoList
                                                                              OPTIONAL.
    -- Physical channel IEs
        frequencyInfo
                                         FrequencyInfo
                                                                              OPTIONAL,
        maxAllowedUL-TX-Power
                                        MaxAllowedUL-TX-Power
                                                                              OPTIONAL,
        ul-ChannelRequirement
                                        UL-ChannelRequirement
                                                                              OPTIONAL,
        modeSpecificPhysChInfo
                                         CHOICE {
            fdd
                                             SEOUENCE {
                                                 DL-PDSCH-Information
                dl-PDSCH-Information
                                                                              OPTIONAL
            },
            tdd
                                             NULL
        dl-CommonInformation
                                       DL-CommonInformation
                                                                              OPTIONAL,
        dl-InformationPerRL-List
                                        DL-InformationPerRL-List
                                                                              OPTIONAL
}
CellUpdateConfirm-v3a0ext ::= SEQUENCE {
    new-DSCH-RNTI
                               DSCH-RNTI
                                                                          OPTIONAL
CellUpdateConfirm-v4b0ext-IEs ::= SEQUENCE {
     - Physical channel IEs
        -- ssdt-UL extends SSDT-Information, which is included in
        -- DL-CommonInformation. FDD only.
        ssdt-UL-r4
                                             SSDT-UL
                                                                                  OPTIONAL,
        -- The order of the RLs in IE cell-id-PerRL-List is the same as
        -- in IE DL-InformationPerRL-List included in this message
```

```
cell-id-PerRL-List
                                                                              CellIdentity-PerRL-List
                                                                                                                                                    OPTIONAL
}
CellUpdateConfirm-v590ext-IEs ::= SEQUENCE {
        -- Physical channel IEs
              dl-TPC-PowerOffsetPerRL-List DL-TPC-PowerOffsetPerRL-List
                                                                                                                                          OPTIONAL
}
CellUpdateConfirm-r4-IEs ::= SEQUENCE {
       -- User equipment IEs
             integrityProtectionModeInfo
                                                                        IntegrityProtectionModeInfo
                                                                                                                                            OPTIONAL.
              cipheringModeInfo
                                                                         CipheringModeInfo
                                                                                                                                            OPTIONAL.
                                                                         ActivationTime
              activationTime
                                                                                                                                            OPTIONAL.
                                                                        U-RNTI
              new-U-RNTI
                                                                                                                                            OPTIONAL,
              new-C-RNTI
                                                                         C-RNTI
                                                                                                                                            OPTIONAL,
              new-DSCH-RNTI
                                                                         DSCH-RNTI
                                                                                                                                            OPTIONAL,
              rrc-StateIndicator RRC-StateIndicator, utran-DRX-CycleLengthCoeff UTRAN-DRX-CycleLengthCoefficient
                                                                                                                                        OPTIONAL,
              rlc-Re-establishIndicatorRb2-3or4
                                                                                      BOOLEAN.
              rlc-Re-establishIndicatorRb5orAbove BOOLEAN,
       -- CN information elements
              cn-InformationInfo
                                                                         CN-InformationInfo
                                                                                                                                            OPTIONAL,
       -- UTRAN mobility IEs
              ura-Identity
                                                                         URA-Identity
                                                                                                                                            OPTIONAL,
       -- Radio bearer IEs
              rb-InformationReleaseList
                                                                      RB-InformationReleaseList
                                                                                                                                            OPTIONAL,
              rb-InformationReconfigList RB-InformationAffectedList RB-InformationAffectedList
                                                                                                                                            OPTIONAL,
                                                                                                                                            OPTIONAL,
              dl-CounterSynchronisationInfo DL-CounterSynchronisationInfo
                                                                                                                                           OPTIONAL,
       -- Transport channel IEs
               ul-CommonTransChInfo
                                                                         UL-CommonTransChInfo-r4
                                                                                                                                            OPTIONAL.
              ul-deletedTransChInfoList
                                                                     UL-DeletedTransChInfoList
              ul-AddReconfTransChInfoList
modeSpecificTransChInfo
fdd
                                                                         UL-AddReconfTransChInfoList
                                                                                                                                           OPTIONAL,
                                                                        CHOICE {
                                                                                 SEQUENCE {
                             cpch-SetID
                                                                                        CPCH-SetID
                                                                                                                                            OPTIONAL,
                             addReconfTransChDRAC-Info
                                                                                        DRAC-StaticInformationList OPTIONAL
                      tdd
                                                                                 NULL
              dl-CommonTransChInfo DL-CommonTransChInfo-r4
dl-DeletedTransChInfoList DL-DeletedTransChInfoList
dl-AddReconfTransChInfoList DL-AddReconfTransChInfoList-r4
                                                                                                                                            OPTIONAL,
                                                                                                                                            OPTIONAL,
                                                                                                                                           OPTIONAL.
       -- Physical channel IEs
              frequencyInfo
                                                                         FrequencyInfo
                                                                                                                                            OPTIONAL.
              maxAllowedUL-TX-Power
ul-ChannelRequirement
modeSpecificPhysChInfo
                                                                     MaxAllowedUL-TX-Power
                                                                                                                                            OPTIONAL,
                                                                         UL-ChannelRequirement-r4
                                                                                                                                            OPTIONAL,
                                                                        CHOICE {
                                                                                 SECTIENCE {
                      fdd
                             dl-PDSCH-Information
                                                                                        DL-PDSCH-Information
                                                                                                                                         OPTIONAL
                      },
                      tdd
                                                                                 NULL
              dl-CommonInformation DL-CommonInformation-r4 dl-InformationPerRL-List DL-InformationPerRL-List-r4
                                                                                                                                            OPTIONAL,
                                                                                                                                            OPTIONAL
}
CellUpdateConfirm-r5-IEs ::= SEQUENCE {
        -- User equipment IEs
               integrityProtectionModeInfo
                                                                         IntegrityProtectionModeInfo
                                                                                                                                            OPTIONAL.
               cipheringModeInfo
                                                                         CipheringModeInfo
                                                                                                                                            OPTIONAL.
               activationTime
                                                                         ActivationTime
                                                                                                                                             OPTIONAL,
               new-U-RNTI
                                                                         U-RNTI
                                                                                                                                             OPTIONAL,
              new-C-RNTI
                                                                         C-RNTI
                                                                                                                                            OPTIONAL,
              new-DSCH-RNTI
                                                                         DSCH-RNTT
                                                                                                                                            OPTIONAL,
              The state of the s
              new-H-RNTI
                                                                         H-RNTT
                                                                                                                                            OPTIONAL,
                                                                         UTRAN-DRX-CycleLengthCoefficient
                                                                                                                                            OPTIONAL,
              rlc-Re-establishIndicatorRb2-3or4
               rlc-Re-establishIndicatorRb5orAbove BOOLEAN,
       -- CN information elements
              cn-InformationInfo
                                                                        CN-InformationInfo
                                                                                                                                            OPTIONAL,
       -- UTRAN mobility IEs
                                                                        URA-Identity
              ura-Identity
                                                                                                                                            OPTIONAL,
       -- Radio bearer IEs
              rb-InformationReleaseList RB-InformationReleaseList rb-InformationReconfigList RB-InformationReconfigList-r5
                                                                                                                                            OPTIONAL,
                                                                                                                                            OPTIONAL,
               rb-InformationAffectedList
                                                                         RB-InformationAffectedList-r5
                                                                                                                                            OPTIONAL,
```

```
{\tt dl-CounterSynchronisationInfo-DL-CounterSynchronisationInfo-r5} \qquad {\tt OPTIONAL}\,,
       -- Transport channel IEs
              ul-CommonTransChInfo
                                                                    UL-CommonTransChInfo-r4
                                                                                                                                      OPTIONAL,
             ul-deletedTransChInfoListUL-DeletedTransChInfoListul-AddReconfTransChInfoListUL-AddReconfTransChInfoListmodeSpecificTransChInfoCHOICE {
                                                                                                                                       OPTIONAL,
                                                                      UL-AddReconfTransChInfoList
                                                                                                                                       OPTIONAL,
              modeSpecificTransChInfo
                                                                              SEOUENCE {
                     fdd
                            cpch-SetID
                                                                                     CPCH-Set.ID
                                                                                                                                       OPTIONAL.
                            addReconfTransChDRAC-Info
                                                                                     DRAC-StaticInformationList OPTIONAL
                     },
                     t.dd
                                                                              NULL
             dl-CommonTransChInfo DL-CommonTransChInfo-r4
dl-DeletedTransChInfoList DL-DeletedTransChInfoList-r5
dl-AddReconfTransChInfoList DL-AddReconfTransChInfoList-r5
                                                                                                                                       OPTIONAL,
                                                                                                                                       OPTIONAL.
                                                                                                                                     OPTIONAL,
       -- Physical channel IEs
              frequencyInfo
                                                                      FrequencyInfo
             maxAllowedUL-TX-Power MaxAllowedUL-TX-Power ul-ChannelRequirement UL-ChannelRequirement-r5 modeSpecificPhysChInfo CHOICE {
fdd SEQUENCE {
                                                                                                                                       OPTIONAL.
                                                                                                                                       OPTIONAL.
                                                                      SEQUENCE {
                     fdd
                            dl-PDSCH-Information
                                                                                    DL-PDSCH-Information
                                                                                                                                     OPTIONAL
                     },
                     tdd
                                                                              NULL
             dl-HSPDSCH-Information DL-HSPDSCH-Information dl-CommonInformation DL-CommonInformation-r5 dl-InformationPerRL-List DL-InformationPerRL-Lis
                                                                                                                                       OPTIONAL.
                                                                      DL-CommonInformation-r5
                                                                                                                                       OPTIONAL,
                                                                    DL-InformationPerRL-List-r5
                                                                                                                                      OPTIONAL
}
__ ****************
-- CELL UPDATE CONFIRM for CCCH
__ ****************
CellUpdateConfirm-CCCH ::= CHOICE {
                                                                SEQUENCE {
              -- User equipment IEs
                   u-RNTI
                                                                      U-RNTI,
              -- The rest of the message is identical to the one sent on DCCH.
                    -- Container for additional R99 extensions
                            cellUpdateConfirm-CCCH-r3-add-ext
                                                                                                           BIT STRING OPTIONAL,
                            ONOnCriticalExtensions SEQUENCE {
cellUpdateConfirm-v590ext
nonCriticalExtensions SEQUENCE {\ \choose \ \c
                                         OPTIONAL
                                  OPTIONAL
                            OPTIONAL
       later-than-r3
                                                               SECUENCE {
             u-RNTI U-RNTI, rrc-TransactionIdentifier RRC-TransactionIdentifier,
             criticalExtensions CHOICE {
                                                                      SEOUENCE {
                    r4
                            -- The rest of the message is identical to the one sent on DCCH.
                            -- Container for adding non critical extensions after freezing REL-5
                                    \verb|cellUpdateConfirm-CCCH-r4-add-ext| & \verb|BIT STRING| & OPTIONAL|, \\
                                   OPTIONAL
                            }
                                  OPTIONAL
                     },
                     cellUpdateConfirm-CCCH-r5-add-ext BIT STRING OPTIONAL,
                                   criticalExtensions
                                                                                  SEQUENCE {}
                     }
```

```
}
   }
}
__ ****************************
-- COUNTER CHECK
__ **************
CounterCheck ::= CHOICE {
                         SEQUENCE {
       counterCheck-r3
laterNonCriticalExtensions
CounterCheck-r3-IEs,
SEQUENCE {
           -- Container for additional R99 extensions
          counterCheck-r3-add-ext BIT STRING OPTIONAL, nonCriticalExtensions SEQUENCE {} OPTIONAL
       } OPTIONAL
       er-than-r3 SEQUENCE {
    rrc-TransactionIdentifier RRC-TransactionIdentifier,
    criticalExtensions SEQUENCE {}
   later-than-r3
}
CounterCheck-r3-IEs ::= SEQUENCE {
  -- User equipment IEs
       rrc-TransactionIdentifier RRC-TransactionIdentifier,
   -- Radio bearer IEs
       rb-COUNT-C-MSB-InformationList RB-COUNT-C-MSB-InformationList
}
__ ***************
-- COUNTER CHECK RESPONSE
__ *******************
CounterCheckResponse ::= SEQUENCE {
   -- User equipment IEs
       rrc-TransactionIdentifier
                                    RRC-TransactionIdentifier,
    -- Radio bearer IEs
       rb-COUNT-C-InformationList RB-COUNT-C-InformationList laterNonCriticalExtensions SEQUENCE {
                                                                      OPTIONAL,
          -- Container for additional R99 extensions
           counterCheckResponse-r3-add-ext BIT STRING OPTIONAL,
                                             SEQUENCE {} OPTIONAL
          nonCriticalExtensions
       } OPTIONAL
__ ****************************
-- DOWNLINK DIRECT TRANSFER
__ ***************
DownlinkDirectTransfer ::= CHOICE {
                                SEQUENCE {
       downlinkDirectTransfer-r3
laterNonCriticalExtensions
DownlinkDirectTransfer-r3-IEs,
SEQUENCE {
           -- Container for additional R99 extensions
           downlinkDirectTransfer-r3-add-ext BIT STRING OPTIONAL,
                                        SEQUENCE {} OPTIONAL
           nonCriticalExtensions
       } OPTIONAL
   later-than-r3
                                SEQUENCE {
       rrc-TransactionIdentifier RRC-TransactionIdentifier,
       criticalExtensions
                                     SEQUENCE {}
}
DownlinkDirectTransfer-r3-IEs ::= SEQUENCE {
   -- User equipment IEs
       rrc-TransactionIdentifier
                                    RRC-TransactionIdentifier,
    -- Core network IEs
                              CN-DomainIdentity,
      cn-DomainIdentity
       nas-Message
                                     NAS-Message
}
```

```
__ ***************
-- HANDOVER TO UTRAN COMMAND
__ ******************
HandoverToUTRANCommand ::= CHOICE {
                                        SEQUENCE {
                                        HandoverToUTRANCommand-r3-IEs,
         handoverToUTRANCommand-r3
        nonCriticalExtensions
                                            SEQUENCE {} OPTIONAL
                                    CHOICE {
    criticalExtensions
                                          SEQUENCE {
                                            HandoverToUTRANCommand-r4-IEs,
             handoverToUTRANCommand-r4
             nonCriticalExtensions
                                                SEQUENCE {} OPTIONAL
        criticalExtensions
                                           CHOICE {
                                               SEQUENCE {
             r5
                                                 HandoverToUTRANCommand-r5-IEs,
                 handoverToUTRANCommand-r5
                 nonCriticalExtensions
                                                     SEQUENCE {}
                                                                   OPTIONAL
                                                 SEQUENCE {}
             criticalExtensions
         }
    }
}
HandoverToUTRANCommand-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        new-U-RNTI
                                          U-RNTI-Short,
         -- dummy is not used in this version of specification, it should
         -- not be sent and if received it should be ignored.
                                           ActivationTime
                                                                                   OPTIONAL.
        dummy
        cipheringAlgorithm
                                            CipheringAlgorithm
                                                                                    OPTIONAL,
    -- Radio bearer IEs
    -- Specification mode information
                 CHOICE {
plete SEQUENCE {
  srb-InformationSetupList SRB-InformationSetupList,
  rab-InformationSetupList RAB-InformationSetupList
  ul-CommonTransChInfo UL-CommonTransChInfo,
  ul-AddReconfTransChInfoList UL-AddReconfTransChInfoList,
  dl-CommonTransChInfo DL-CommonTransChInfo,
  dl-AddReconfTransChInfoList UL-AddReconfTransChInfo,
  dl-AddReconfTransChInfoList,
  ul-DPCH-Info UL-DPCH-Info,
  modeSpecificInfo CHOICE {
                               CHOICE {
        specificationMode
             complete
                                                                                             OPTIONAL,
                          SEQUENCE {
dl-PDSCH-Information DI._DDC.
cpch-SetTrf-
                      fdd
                                                         DL-PDSCH-Information OPTIONAL,
                          cpch-SetInfo
                                                              CPCH-SetInfo
                      },
                      tdd.
                                                        NULL
                 },
             preconfiguration
                                               SEQUENCE {
-- All IEs that include an FDD/TDD choice are split in two IEs for this message,
-- one for the FDD only elements and one for the TDD only elements, so that one
-- FDD/TDD choice in this level is sufficient.
                 preConfigMode
                                                     CHOICE {
                                                     PredefinedConfigIdentity,
                      predefinedConfigIdentity
                      defaultConfig
                                                         SEQUENCE {
                          defaultConfigMode
                                                        DefaultConfigMode,
                          defaultConfigIdentity
                                                             DefaultConfigIdentity
                      }
                  },
                                                                         OPTIONAL,
                  rab-Info
                                                     RAB-Info-Post
                  modeSpecificInfo
                                                     CHOICE {
                      fdd
                                                     SEQUENCE {
                          ul-DPCH-Info
UL-DPCH-InfoPostFDD,
dl-CommonInformationPost
dl-InformationPerRL-List
pt-InformationPerRL-List
DL-InformationPerRL-ListPostFDD,
frequencyInfo
                          frequencyInfo
                                                              FrequencyInfoFDD
                      t.dd
                                                              SEQUENCE {
                          ul-DPCH-Info
                                                              UL-DPCH-InfoPostTDD,
```

```
dl-CommonInformationPost
                                                          DL-CommonInformationPost,
                         dl-InformationPerRL
                                                            DL-InformationPerRL-PostTDD,
                         frequencyInfo
                                                           FrequencyInfoTDD,
                         primaryCCPCH-TX-Power
                                                           PrimaryCCPCH-TX-Power
                 }
            }
    -- Physical channel IEs
        maxAllowedUL-TX-Power
                                        MaxAllowedUL-TX-Power
}
HandoverToUTRANCommand-r4-IEs ::= SEQUENCE {
    -- User equipment IEs
       new-U-RNTI
                                           U-RNTI-Short,
        cipheringAlgorithm
                                          CipheringAlgorithm
                                                                                OPTIONAL.
    -- Radio bearer IEs
    -- Specification mode information
        specificationMode
                                          CHOICE {
                                            SEQUENCE {
            complete
                 srb-InformationSetupList SRB-InformationSetupList,
rab-InformationSetupList RAB-InformationSetupList-r4
ul-CommonTransChInfo UL-CommonTransChInfo-r4,
ul-AddReconfTransChInfoList UL-AddReconfTransChInfoList,
dl-CommonTransChInfo DL-CommonTransChInfo-r4,
                                                                                         OPTIONAL,
                 dl-AddReconfTransChInfoList DL-AddReconfTransChInfoList-r4,
                 ul-DPCH-Info
                                                   UL-DPCH-Info-r4,
                 modeSpecificInfo
                                                   CHOICE {
                     fdd
                                                      SEQUENCE {
                         dl-PDSCH-Information
                                                           DL-PDSCH-Information OPTIONAL,
                                                            CPCH-SetInfo OPTIONAL
                         cpch-SetInfo
                     },
                     tdd
                                                       NULL
                 dl-CommonInformation DL-CommonInformation-r4, dl-InformationPerRL-List DL-InformationPerRL-List frequencyInfo FrequencyInfo
                                                   DL-InformationPerRL-List-r4,
            preconfiguration
                                             SEQUENCE {
-- All IEs that include an FDD/TDD choice are split in two IEs for this message,
-- one for the FDD only elements and one for the TDD only elements, so that one
-- FDD/TDD choice in this level is sufficient.
                 preConfigMode
                                                   CHOICE {
                                                   {\tt PredefinedConfigIdentity},
                     predefinedConfigIdentity
                     defaultConfig
                                                       SEQUENCE {
                         defaultConfigMode
                                                           DefaultConfigMode,
                         defaultConfigIdentity
                                                            DefaultConfigIdentity-r4
                     }
                 },
                 rab-Info
                                                   RAB-Info-Post
                                                                       OPTIONAL,
                 modeSpecificInfo
                                                   CHOICE {
                                                   SEQUENCE {
                     fdd
                         ul-DPCH-Info
                                                           UL-DPCH-InfoPostFDD,
                         dl-CommonInformationPost
                                                           DL-CommonInformationPost,
                         dl-InformationPerRL-List
                                                          DL-InformationPerRL-ListPostFDD,
                         frequencyInfo
                                                           FrequencyInfoFDD
                     tdd
                                                        CHOICE {
                                                        SEQUENCE {
                         tdd384
                                                                UL-DPCH-InfoPostTDD,
                              ul-DPCH-Info
                              dl-InformationPerRL
                                                                DL-InformationPerRL-PostTDD,
                              frequencyInfo
                                                                FrequencyInfoTDD,
                             primaryCCPCH-TX-Power
                                                               PrimaryCCPCH-TX-Power
                          t.dd128
                                                           SEQUENCE {
                                                            UL-DPCH-InfoPostTDD-LCR-r4,
                              ul-DPCH-Info
                              dl-InformationPerRL
                                                                DL-InformationPerRL-PostTDD-LCR-r4,
                              frequencyInfo
                                                               FrequencyInfoTDD,
                                                            primaryCCPCH-TX-Power
                         }
                    }
                }
            }
        },
    -- Physical channel IEs
                                        MaxAllowedUL-TX-Power
        maxAllowedUL-TX-Power
}
```

```
HandoverToUTRANCommand-r5-IEs ::= SEQUENCE {
    -- User equipment IEs
                                  U-RNTI-Short,
CipheringAlgo
        new-U-RNTI
        cipheringAlgorithm
                                           CipheringAlgorithm
                                                                                  OPTIONAL,
    -- Radio bearer IEs
    -- Specification mode information specificationMode CHOICE {
                 complete
                                                                                           OPTIONAL,
                         dl-PDSCH-Information DL-PDSC cpch-SetInfo
                                                        DL-PDSCH-Information OPTIONAL,
                                                             CPCH-SetInfo OPTIONAL
                      },
                     tdd
                                                       NULL
                 dl-CommonInformation DL-CommonInformation-r4, DL-InformationPerRL-List DL-InformationPerRL-List-r5, frequencyInfo FrequencyInfo
                                 SEQUENCE {
             },
             preconfiguration
-- All IEs that include an FDD/TDD choice are split in two IEs for this message,
-- one for the FDD only elements and one for the TDD only elements, so that one
-- FDD/TDD choice in this level is sufficient.
                                                    CHOICE {
                 preConfiqMode
                     predefinedConfigIdentity
defaultConfig
defaultConfigMode
defaultConfigIdentity
DefaultConfigMode,
DefaultConfigIdentity
                                                            DefaultConfigIdentity-r5
                      }
                 rab-Info
                                                   RAB-Info-Post
                                                                     OPTIONAL,
                 modeSpecificInfo
fdd
                                                    CHOICE {
                                                    SEQUENCE {
                          ul-DPCH-Info
dl-CommonInformationPost
dl-InformationPerRL-List
frequencyInfo

UL-DPCH-InfoPostFDD,
DL-CommonInformationPost,
DL-InformationPerRL-ListPostFDD,
FrequencyInfo

FrequencyInfoFDD
                      tdd.
                                                       CHOICE {
                                                       SEQUENCE {
                          tdd384
                              ul-DPCH-Info UL-DPCH-InfoPostTDD,
dl-InformationPerRL DL-InformationPerRL-PostTDD,
frequencyInfo FrequencyInfo
                              ul-DPCH-Info
                              frequencyInfo
                              primaryCCPCH-TX-Power
                                                                PrimaryCCPCH-TX-Power
                                                           SEQUENCE {
                          t.dd128
                              ul-DPCH-Info
UL-DPCH-InfoPostTDD-LCR-r4,
dl-InformationPerRL
frequencyInfo

DL-InformationPerRL-PostTDD-LCR-r4,
frequencyInfo
                                                                FrequencyInfoTDD,
                              primaryCCPCH-TX-Power
                                                                 PrimaryCCPCH-TX-Power
                          }
                     }
                 }
            }
    -- Physical channel IEs
        maxAllowedUL-TX-Power
                                         MaxAllowedUL-TX-Power
}
__ ****************
-- HANDOVER TO UTRAN COMPLETE
************
HandoverToUTRANComplete ::= SEQUENCE {
    --TABULAR: Integrity protection shall not be performed on this message.
    -- User equipment IEs
    -- TABULAR: startList is conditional on history.
        startList
                                           STARTList
                                                                                   OPTIONAL,
```

```
-- Radio bearer IEs
       OPTIONAL,
           -- Container for additional R99 extensions
          handoverToUTRANComplete-r3-add-ext BIT STRING OPTIONAL,
                                   SEQUENCE {} OPTIONAL
          nonCriticalExtensions
       } OPTIONAL
}
__ ****************************
-- INITIAL DIRECT TRANSFER
__ ******************************
InitialDirectTransfer ::= SEQUENCE {
   -- Core network IEs
       NAS-Message,
       nas-Message
   -- Measurement IEs
       measuredResultsOnRACH
v3a0NonCriticalExtensions
laterNonCriticalExtensions
-- Container for additional R99 extensions

MeasuredResultsOnRACH
SEQUENCE {
InitialDirectTransfer-v3a0ext,
SEQUENCE {
-- Container for additional R99 extensions
                                                                   OPTIONAL,
          initialDirectTransfer-v590ext InitialDirectTransfer-v590ext,
                                             SEQUENCE {}
                 nonCriticalExtensions
                                                            OPTIONAL
                     OPTIONAL
                 OPTIONAL
          OPTIONAL
}
InitialDirectTransfer-v3a0ext ::= SEQUENCE {
   -- start-value shall always be included in this version of the protocol
                                START-Value
   start-Value
                                                                 OPTIONAL
}
InitialDirectTransfer-v590ext ::= SEQUENCE {
   establishmentCause EstablishmentCause OPTIONAL
__ ***************
-- HANDOVER FROM UTRAN COMMAND
__ ****************
HandoverFromUTRANCommand-GSM ::= CHOICE {
                                SEQUENCE {
       handoverFromUTRANCommand-GSM-r3
                                   HandoverFromUTRANCommand-GSM-r3-IEs,
       -- UTRAN should not include the IE laterNonCriticalExtensions when it sets the IE
       -- gsm-message included in handoverFromUTRANCommand-GSM-r3 to single-GSM-Message. The UE
       -- behaviour upon receiving a message with this combination of IE values is unspecified.
       -- Container for additional R99 extensions
          handoverFromUTRANCommand-GSM-r3-add-ext BIT STRING OPTIONAL,
                                       SEQUENCE {} OPTIONAL
          nonCriticalExtensions
       } OPTIONAL
   later-than-r3
                               SEQUENCE {
      rrc-TransactionIdentifier RRC-TransactionIdentifier,
       criticalExtensions
                                    SEOUENCE {}
}
HandoverFromUTRANCommand-GSM-r3-IEs ::= SEQUENCE {
   -- User equipment IEs
      User equipment les
rrc-TransactionIdentifier RRC-TransactionIdentifier,
       activationTime
                                   ActivationTime
                                                                     OPTIONAL,
   -- Radio bearer IEs
       toHandoverRAB-Info
                                  RAB-Info
                                                                     OPTIONAL,
   -- Measurement IEs
      frequency-band
                                  Frequency-Band,
   -- Other IEs
```

```
CHOICE {
        qsm-message
            -- In the single-GSM-Message case the following rules apply:
            -- 1> the GSM message directly follows the basic production; the final padding that
            -- results when PER encoding the abstract syntax value is removed prior to appending
                 the GSM message.
            -- 2> the RRC message excluding the GSM part, does not contain a length determinant;
                 there is no explicit parameter indicating the size of the included GSM message.
            -- 3> depending on need, final padding (all '0's) is added to ensure the final result
                comprises a full number of octets
            single-GSM-Message
                                           SEQUENCE {},
            gsm-MessageList
                                           SEQUENCE {
               gsm-Messages
                                               GSM-MessageList
        }
}
HandoverFromUTRANCommand-GERANIu ::= SEQUENCE {
    rrc-TransactionIdentifier RRC-TransactionIdentifier,
    handoverFromUTRANCommand-GERANIu CHOICE {
                                           SEQUENCE {
            handoverFromUTRANCommand-GERANIu-r5
                                           HandoverFromUTRANCommand-GERANIu-r5-IEs,
            -- UTRAN should not include the IE nonCriticalExtensions when it sets
            -- the IE geranIu-message included in handoverFromUTRANCommand-GERANIu-r5 to
            -- single-GERANTu-Message
            -- The UE behaviour upon receiving a message including this combination of IE values is
            -- not specified
                                          SEQUENCE {} OPTIONAL
           nonCriticalExtensions
        },
                                       SEQUENCE {
        later-than-r5
           criticalExtensions
                                           SEQUENCE {}
    }
}
HandoverFromUTRANCommand-GERANIu-r5-IEs ::= SEQUENCE {
    -- User equipment IEs
       activationTime
                                       ActivationTime
                                                                          OPTIONAL,
    -- Measurement IEs
       frequency-Band
                                       Frequency-Band,
    -- Other IEs
                                           CHOICE {
       geranIu-Message
            -- In the single-GERANIu-Message case the following rules apply:
            -- 1> the GERAN Iu message directly follows the basic production; the final padding that
            -- results when PER encoding the abstract syntax value is removed prior to appending
                 the GERAN Iu message.
            -- 2> the RRC message excluding the GERAN Iu part does not contain a length determinant;
                 there is no explicit parameter indicating the size of the included GERAN Iu
            -- 3> depending on need, final padding (all '0's) is added to ensure the final result
                comprises a full number of octets.
           single-GERANIu-Message SEQUENCE {},
geranIu-MessageList SEQUENCE {
               geranIu-Messages
                                               GERANIu-MessageList
        }
}
HandoverFromUTRANCommand-CDMA2000 ::= CHOICE {
                                  SEQUENCE {
       handoverFromUTRANCommand-CDMA2000-r3
                                   HandoverFromUTRANCommand-CDMA2000-r3-IEs,
        laterNonCriticalExtensions
                                          SEQUENCE {
            -- Container for additional R99 extensions
            handoverFromUTRANCommand-CDMA2000-r3-add-ext
                                                             OPTIONAL,
                                               BIT STRING
                                                SEQUENCE {}
           nonCriticalExtensions
                                                               OPTIONAL
        } OPTIONAL
    later-than-r3
                                   SEQUENCE {
                                    RRC-TransactionIdentifier,
       rrc-TransactionIdentifier
       criticalExtensions
                                       SEQUENCE {}
}
HandoverFromUTRANCommand-CDMA2000-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
       rrc-TransactionIdentifier
                                     RRC-TransactionIdentifier,
```

```
activationTime
                              ActivationTime
                                                             OPTIONAL,
   -- Radio bearer IEs
     toHandoverRAB-Info
                              RAB-Info
                                                             OPTIONAL,
   -- Other IEs
      cdma2000-MessageList
                               CDMA2000-MessageList
}
__ ****************
-- HANDOVER FROM UTRAN FAILURE
__ ***************
HandoverFromUTRANFailure ::= SEQUENCE {
   -- User equipment IEs
     rrc-TransactionIdentifier
                              RRC-TransactionIdentifier,
   -- Other IEs
      interRAT-HO-FailureCause InterRAT-HO-FailureCause
                                                            OPTIONAL,
      -- In case the interRATMessage to be transferred is for GERAN Iu mode, the
      -- message should be placed in the HandoverFromUtranFailure-v590ext-IEs
      -- non-critical extension container.
                             CHOICE {
      interRATMessage
                                SEQUENCE {
         qsm
            gsm-MessageList
                                        GSM-MessageList
         },
         cdma2000
                                      SEQUENCE {
           ma2000
cdma2000-MessageList
                                        CDMA2000-MessageList
                   OPTIONAL,
      laterNonCriticalExtensions
                             SEQUENCE {
         -- Container for additional R99 extensions
         handoverFromUTRANFailure-v590ext HandoverFromUtranFailure-v590ext-IEs,
                                     SEQUENCE {}
            nonCriticalExtensions
                                                   OPTIONAL
            OPTIONAL
      } OPTIONAL
}
HandoverFromUtranFailure-v590ext-IEs ::= SEQUENCE {
                                  GERANIu-MessageList
  geranIu-MessageList
                                                        OPTIONAL
__ ***************
-- INTER RAT HANDOVER INFO
__ ****************************
InterRATHandoverInfo ::= SEQUENCE {
   -- This structure is defined for historical reasons, backward compatibility with 04.18
   PredefinedConfigStatusList
      present
   \verb"uE-SecurityInformation" CHOICE \{
      absent
                               NULL,
                               UE-SecurityInformation
   ue-CapabilityContainer CHOICE {
      absent
                               NULL,
      -- present is an octet aligned string containing IE UE-RadioAccessCapabilityInfo
                               OCTET STRING (SIZE (0..63))
   -- Non critical extensions
   v390NonCriticalExtensions CHOICE {
   absent NULL,
                               SEQUENCE {
      present
         interRATHandoverInfo-v3d0ext InterRATHandoverInfo-v3d0ext-IEs,
                -- Container for additional R99 extensions
                interRATHandoverInfo-v3g0ext InterRATHandoverInfo-v3g0ext-IEs, v4b0NonCriticalExtensions SEQUENCE {
```

```
\verb|interRATH| and over \verb|Info-v4b0| ext- \verb|IEs|,
                            v4d0NonCriticalExtensions
                                                           SEQUENCE {
                               interRATHandoverInfo-v4d0ext
                                                               InterRATHandoverInfo-v4d0ext-IEs,
                                -- Reserved for future non critical extension
                                v590NonCriticalExtensions
                                                               SEQUENCE {
                                    \verb|interRATH| and over Info-v590ext|
                                                               InterRATHandoverInfo-v590ext-IEs,
                                                                    SEQUENCE {} OPTIONAL
                                    nonCriticalExtensions
                                   OPTIONAL
                                OPTIONAL
                            OPTIONAL
                        OPTIONAL
                   ODTTONAT.
           } OPTIONAL
    }
}
InterRATHandoverInfo-v390ext-IEs ::= SEQUENCE {
    -- User equipment IEs
       ue-RadioAccessCapability-v380ext
                                            UE-RadioAccessCapability-v380ext
                                                                                   OPTIONAL.
                                         DL-PhysChCapabilityFDD-v380ext
        dl-PhysChCapabilityFDD-v380ext
InterRATHandoverInfo-v3a0ext-IEs ::= SEQUENCE {
    -- User equipment IEs
       ue-RadioAccessCapability-v3a0ext UE-RadioAccessCapability-v3a0ext
                                                                                   OPTIONAL
}
InterRATHandoverInfo-v3d0ext-IEs ::= SEQUENCE {
    -- User equipment IEs
       uESpecificBehaviourInformationlinterRAT
                                                  UESpecificBehaviourInformationlinterRAT
   OPTIONAL
}
InterRATHandoverInfo-v3q0ext-IEs ::= SEQUENCE {
   -- User equipment IEs
       ue-RadioAccessCapability-v3g0ext UE-RadioAccessCapability-v3g0ext OPTIONAL
InterRATHandoverInfo-v4b0ext-IEs ::= SEQUENCE {
   -- User equipment IEs
       accessStratumReleaseIndicator
                                           AccessStratumReleaseIndicator
}
InterRATHandoverInfo-v4d0ext-IEs ::= SEQUENCE {
    -- User equipment IEs
    tdd128-RF-Capability
                                       RadioFrequencyBandTDDList
                                                                      OPTIONAL
InterRATHandoverInfo-v590ext-IEs ::= SEQUENCE {
    -- User equipment IEs
       predefinedConfigStatusListComp
                                           PredefinedConfigStatusListComp
                                                                                    OPTIONAL.
       ue-RadioAccessCapabilityComp
                                           UE-RadioAccessCapabilityComp
                                                                                    OPTIONAL
}
__ ***************
-- MEASUREMENT CONTROL
__ **************************
MeasurementControl ::= CHOICE {
                                    SEQUENCE {
        v390nonCriticalExtensions
                                       MeasurementControl-r3-IEs,
                                       SEQUENCE {
           measurementControl-v390ext MeasurementControl-v390ext, v3a0NonCriticalExtensions SEQUENCE {
                                            SEQUENCE {
                NonCriticalExtensions

measurementControl-v3a0ext

MeasurementControl-v3a0ext

SEQUENCE {
                                                    MeasurementControl-v3a0ext,
                    -- Container for additional R99 extensions
                   measurementControl-r3-add-ext BIT STRING OPTIONAL, v4b0NonCriticalExtensions SEQUENCE { v590NonCriticalExtensions SEQUENCE {
                            {\tt measurementControl-v590ext-IEs,}
                            nonCriticalExtensions
                                                               SEQUENCE { } OPTIONAL
                        }
                                               OPTIONAL
                    }
                                            OPTIONAL
```

```
}
                                        OPTIONAL
            }
                                    OPTIONAL
       }
                                OPTIONAL
    later-than-r3
                                    SEQUENCE {
                                   RRC-TransactionIdentifier,
       rrc-TransactionIdentifier
        criticalExtensions
                                        CHOICE {
                measurementControl-r4 SEQUENCE {

Measure
y4d0NonControl-r4
                weasurementControl-r4-IEs, v4d0NonCriticalExtensions SECTIFICE (
            r4
                    -- Container for adding non critical extensions after freezing REL-5 \,
                    measurementControl-r4-add-ext BIT STRING
                                                                       OPTIONAL.
                    v590NonCriticalExtensions
                                                     SEQUENCE {
                        measurementControl-v590ext MeasurementControl-v590ext-IEs,
                        nonCriticalExtensions
                                                        SEQUENCE {}
                                                                      OPTIONAL
                        OPTIONAL
                    OPTIONAL
            criticalExtensions
                                            SEQUENCE {}
        }
    }
}
{\tt MeasurementControl-r3-IEs} \ ::= \ {\tt SEQUENCE} \ \{
    -- User equipment IEs
       rrc-TransactionIdentifier
                                        RRC-TransactionIdentifier,
    -- Measurement IEs
       measurementIdentity MeasurementIdentity,
        -- TABULAR: The measurement type is included in MeasurementCommand.
       measurementCommand MeasurementCommand, measurementReportingMode additionalMeasurementList AdditionalMeasurementID-List
                                                                             OPTIONAL.
                                                                             OPTIONAL,
    -- Physical channel IEs
       dpch-CompressedModeStatusInfo DPCH-CompressedModeStatusInfo
                                                                            OPTIONAL
}
MeasurementControl-v4b0ext-IEs ::= SEOUENCE {
    ue-Positioning-OTDOA-AssistanceData-r4ext UE-Positioning-OTDOA-AssistanceData-r4ext OPTIONAL
MeasurementControl-v390ext ::= SEQUENCE {
                                               UE-Positioning-Measurement-v390ext OPTIONAL
       ue-Positioning-Measurement-v390ext
MeasurementControl-v3a0ext ::= SEQUENCE {
                                    SFN-Offset-Validity OPTIONAL
   sfn-Offset-Validity
MeasurementControl-r4-IEs ::= SEQUENCE {
    -- Measurement IEs
        measurementIdentity MeasurementIdentity,
        -- TABULAR: The measurement type is included in measurementCommand.
       measurementCommand MeasurementCommand-r4,
measurementReportingMode
additionalMeasurementList MeasurementID-List
                                                                            OPTIONAL,
                                                                             OPTIONAL,
    -- Physical channel IEs
        dpch-CompressedModeStatusInfo DPCH-CompressedModeStatusInfo
}
MeasurementControl-v590ext-IEs ::= SEQUENCE {
                                       CHOICE {
   measurementCommand-v590ext
        -- the choice 'intra-frequency' shall be used for the case of intra-frequency measurement,
        -- as well as when intra-frequency events are configured for inter-frequency measurement
        intra-frequency
                                            Intra-FreqEventCriteriaList-v590ext,
        inter-frequency
                                            Inter-FreqEventCriteriaList-v590ext
           OPTIONAL,
    intraFreqReportingCriteria-1b-r5
                                            IntraFreqReportingCriteria-1b-r5
                                                                                     OPTIONAL,
    intraFreqEvent-1d-r5
                                            IntraFreqEvent-1d-r5
                                                                                     OPTIONAL,
    -- most significant part of "RRC transaction identifier" (MSP),
    -- "RRC transaction identifier" = rrc-TransactionIdentifier-MSP-v590ext * 4 +
    -- rrc-TransactionIdentifier
    rrc-TransactionIdentifier-MSP-v590ext RRC-TransactionIdentifier
}
__ ***************
-- MEASUREMENT CONTROL FAILURE
```

```
__ ****************
MeasurementControlFailure ::= SEQUENCE {
   -- User equipment IEs
                                   RRC-TransactionIdentifier,
       rrc-TransactionIdentifier
       failureCause FailureCauseWithProtErr, laterNonCriticalExtensions SEQUENCE {
           -- Container for additional R99 extensions
           OPTIONAL
          OPTIONAL
}
MeasurementControlFailure-v590ext-IEs ::= SEQUENCE {
   -- most significant part of "RRC transaction identifier" (MSP),
   -- "RRC transaction identifier" = rrc-TransactionIdentifier-MSP-v590ext * 4 +
   -- rrc-TransactionIdentifier
   -- If the rrc-TransactionIdentifier-MSP-v590ext was not received in the MEASUREMENT CONTROL
   -- message, then the rrc-TransactionIdentifier-MSP-v590ext shall be set to zero
   rrc-TransactionIdentifier-MSP-v590ext RRC-TransactionIdentifier
-- MEASUREMENT REPORT
__ ***************
MeasurementReport ::= SEQUENCE {
   -- Measurement IEs
      measurementIdentity MeasurementIdentity,
       measurementIdentity MeasuredResults
measuredResults MeasuredResultsOnRACH
measuredResultsOnRACH
MeasuredResultsList
                                                                     OPTIONAL,
                                                                     OPTIONAL,
       additionalMeasuredResults MeasuredResults EventResults
                                    MeasuredResultsList
                                                                      OPTIONAL,
                                                                     OPTIONAL,
   -- Non-critical extensions
       v390nonCriticalExtensions
           OnonCriticalExtensions SEQUENCE {
measurementReport-v390ext MeasurementReport-v390ext,
laterNonCriticalExtensions SEQUENCE {
              -- Container for additional R99 extensions
              measurementReport-r3-add-ext
v4b0NonCriticalExtensions
measurementReport-v4b0ext
BIT STRING OPTIONAL,
SEQUENCE {
MeasurementReport-v4b0ext-IEs,
                  -- Extension mechanism for non-Rel4 information
                  v590NonCriticalExtensions SEQUENCE {
                      OPTIONAL
                                           OPTIONAL
                  }
                                        OPTIONAL
              }
          }
                                OPTIONAL
                                 OPTIONAL
{\tt MeasurementReport-v390ext ::= SEQUENCE } \{
       measuredResults-v390ext MeasuredResults-v390ext
                                                                     OPTIONAL
MeasurementReport-v4b0ext-IEs ::= SEQUENCE {
                                                                    OPTIONAL,
   interFreqEventResults-LCR InterFreqEventResults-LCR-r4-ext additionalMeasuredResults-LCR MeasuredResultsList-LCR-r4-ext
                                                                      OPTIONAL,
   gsmOTDreferenceCell
                                PrimaryCPICH-Info
                                                                      OPTIONAL
}
MeasurementReport-v590ext-IEs ::= SEQUENCE {
                                                                     OPTIONAL
   measuredResults-v590ext MeasuredResults-v590ext
__ ***************************
-- PAGING TYPE 1
__ ***************
PagingType1 ::= SEQUENCE {
   -- User equipment IEs
                                   PagingRecordList
      pagingRecordList
                                                                      OPTIONAL,
```

```
-- Other IEs
        bcch-ModificationInfo BCCH-ModificationInfo laterNonCriticalExtensions SEQUENCE {
        bcch-ModificationInfo
                                                                             OPTIONAL,
            -- Container for additional R99 extensions
            pagingTypel-r3-add-ext BIT STRING OPTIONAL,
v590NonCriticalExtensions SEQUENCE {
 pagingTypel-v590ext PagingTypel-v590ext-IEs,
 nonCriticalExtensions SEQUENCE {} OPTIONAL
               OPTIONAL
            OPTIONAL
}
PagingType1-v590ext-IEs ::= SEQUENCE {
   -- User equipment IEs
       pagingRecord2List
                                         PagingRecord2List-r5
                                                                             OPTIONAL
}
__ ****************************
-- PAGING TYPE 2
__ ****************
PagingType2 ::= SEQUENCE {
    -- User equipment IEs
       User equipment IEs
rrc-TransactionIdentifier RRC-TransactionIdentifier,
pagingCause PagingCause,
    -- Core network IEs
        cn-DomainIdentity CN-DomainIdentity, pagingRecordTypeID PagingRecordTypeID, laterNonCriticalExtensions SEQUENCE {
       cn-DomainIdentity
           -- Container for additional R99 extensions
            pagingType2-r3-add-ext BIT STRING OPTIONAL,
nonCriticalExtensions SEQUENCE {}
        } OPTIONAL
}
  ************
-- PHYSICAL CHANNEL RECONFIGURATION
__ ******************************
PhysicalChannelReconfiguration ::= CHOICE {
                                    SEQUENCE {
        physicalChannelReconfiguration-r3
                                   PhysicalChannelReconfiguration-r3-IEs,
SEQUENCE {
        v3a0NonCriticalExtensions
            physicalChannelReconfiguration-v3a0ext
                                                         PhysicalChannelReconfiguration-v3a0ext,
            laterNonCriticalExtensions SEQUENCE {
                -- Container for additional R99 extensions
                                                                    BIT STRING
                physicalChannelReconfiguration-r3-add-ext
                                                                                      OPTTONAL.
                v4b0NonCriticalExtenstions SEQUENCE {
                    physicalChannelReconfiguration-v4b0ext
                                               PhysicalChannelReconfiguration-v4b0ext-IEs,
                    v590NonCriticalExtenstions
                                                         SEQUENCE {
                        physicalChannelReconfiguration-v590ext
                                                PhysicalChannelReconfiguration-v590ext-IEs,
                        nonCriticalExtensions
                                                                  SEQUENCE {} OPTIONAL
                       OPTIONAL
                    OPTIONAL
                OPTIONAL
        } OPTIONAL
    later-than-r3
                                    SEQUENCE {
        rrc-TransactionIdentifier RRC-TransactionIdentifier, criticalExtensions CHOICE {
                                             SEQUENCE {
            r4
                physicalChannelReconfiguration-r4
                                             PhysicalChannelReconfiguration-r4-IEs,
                v4d0NonCriticalExtensions
                                                 SEQUENCE {
                     -- Container for adding non critical extensions after freezing REL-5
                    physicalChannelReconfiguration-r4-add-ext
                                                                     BIT STRING OPTIONAL,
                    v590NonCriticalExtenstions
                                                        SEQUENCE {
                        physicalChannelReconfiguration-v590ext
                                            PhysicalChannelReconfiguration-v590ext-IEs,
                                                         SEQUENCE { } OPTIONAL
                        nonCriticalExtensions
                      OPTIONAL
```

```
} OPTIONAL
            },
            criticalExtensions
                                            CHOICE {
                                                SEQUENCE {
                r5
                    physicalChannelReconfiguration-r5
                                                    PhysicalChannelReconfiguration-r5-IEs,
                    -- Container for adding non critical extensions after freezing REL-6
                    physicalChannelReconfiguration-r5-add-ext BIT STRING nonCriticalExtensions SEQUENCE {} OPTIONAL
                                                                                     OPTIONAL.
                                              SEQUENCE {}
                criticalExtensions
           }
       }
   }
}
PhysicalChannelReconfiguration-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
       Jser equipment iss
rrc-TransactionIdentifier RRC-TransactionIdentifier,
        integrityProtectionModeInfo
cipheringModeInfo
CipheringModeInfo
CipheringModeInfo
                                                                            OPTIONAL,
                                                                             OPTIONAL,
        activationTime
                                       ActivationTime
                                                                             OPTIONAL,
        new-U-RNTI
                                        U-RNTI
                                                                             OPTIONAL,
       new-C-RNTI
                                       C-RNTI
                                                                             OPTIONAL,
       utran-DRX-CycleLengthCoeff
Core network IFS
       rrc-StateIndicator
                                       RRC-StateIndicator.
                                       UTRAN-DRX-CycleLengthCoefficient OPTIONAL,
    -- Core network IEs
                                       CN-InformationInfo
       cn-InformationInfo
                                                                             OPTIONAL,
    -- UTRAN mobility IEs
       ura-Identity
                                      URA-Identity
                                                                             OPTIONAL.
    -- Radio bearer IEs
       dl-CounterSynchronisationInfo DL-CounterSynchronisationInfo
    -- Physical channel IEs
       frequencyInfo
                                       FrequencyInfo
                                                                            OPTIONAL.
       requencyInfo FrequencyInfo maxAllowedUL-TX-Power MaxAllowedUL-TX-Power
        -- TABULAR: UL-ChannelRequirementWithCPCH-SetID contains the choice
        -- between UL DPCH info, CPCH SET info and CPCH set ID.
       ul-ChannelRequirement UL-ChannelRequirementWithCPCH-SetID OPTIONAL, modeSpecificInfo CHOICE {
           fdd
                                            SEQUENCE {
               dl-PDSCH-Information
                                                DL-PDSCH-Information
                                                                           OPTIONAL
           tdd
                                            NULL
       dl-CommonInformation
dl-InformationPerRL-List
                                      DL-CommonInformation
                                                                            OPTIONAL,
                                       DL-InformationPerRL-List
                                                                            OPTIONAL
}
PhysicalChannelReconfiguration-v3a0ext ::= SEQUENCE {
   new-DSCH-RNTI
                                   DSCH-RNTI
                                                                       OPTIONAL
}
PhysicalChannelReconfiguration-v4b0ext-IEs ::= SEQUENCE {
     -- Physical channel IEs
        -- ssdt-UL extends SSDT-Information, which is included in
        -- DL-CommonInformation. FDD only.
        ssdt-UL-r4
                                            SSDT-UL
                                                                                OPTIONAL,
        -- The order of the RLs in IE cell-id-PerRL-List is the same as
        -- in IE DL-InformationPerRL-List included in this message
                                            CellIdentity-PerRL-List
        cell-id-PerRL-List
                                                                               OPTIONAL
}
PhysicalChannelReconfiguration-v590ext-IEs ::= SEQUENCE {
    -- Physical channel IEs
       dl-TPC-PowerOffsetPerRL-List DL-TPC-PowerOffsetPerRL-List OPTIONAL
PhysicalChannelReconfiguration-r4-IEs ::= SEQUENCE {
    -- User equipment IEs
                                      IntegrityProtectionModeInfo
        integrityProtectionModeInfo
                                                                            OPTIONAL,
        cipheringModeInfo
                                       CipheringModeInfo
                                                                             OPTIONAL,
        activationTime
                                        ActivationTime
                                                                             OPTIONAL,
       new-U-RNTI
                                       U-RNTI
                                                                            OPTIONAL,
       new-C-RNTI
                                       C-RNTI
                                                                            OPTIONAL,
       new-DSCH-RNTI
                                       DSCH-RNTI
                                                                            OPTIONAL,
                                      RRC-StateIndicator,
        rrc-StateIndicator
       utran-DRX-CycleLengthCoeff UTRAN-DRX-CycleLengthCoefficient OPTIONAL,
    -- Core network IEs
```

```
cn-InformationInfo
                                        CN-InformationInfo
                                                                             OPTIONAL,
    -- UTRAN mobility IEs
       ura-Identity
                                        URA-Identity
                                                                             OPTIONAL,
    -- Radio bearer IEs
        dl-CounterSynchronisationInfo DL-CounterSynchronisationInfo
                                                                             OPTIONAL,
    -- Physical channel IEs
        frequencyInfo
                                        FrequencyInfo
                                                                             OPTIONAL.
                                      MaxAllowedUL-TX-Power
        maxAllowedUL-TX-Power
                                                                             OPTIONAL,
        -- TABULAR: UL-ChannelRequirementWithCPCH-SetID-r4 contains the choice
        -- between UL DPCH info, CPCH SET info and CPCH set ID.
        ul-ChannelRequirement UL-ChannelRequirementWithCPCH-SetID-r4 OPTIONAL,
                                        CHOICE {
        modeSpecificInfo
                                            SEQUENCE {
            fdd
                dl-PDSCH-Information
                                                DL-PDSCH-Information
                                                                            OPTIONAL
            },
            tdd
                                            NULL
        dl-CommonInformation DL-CommonInformation-r4
dl-InformationPerRL-List DL-InformationPerRL-List-r4
                                                                             OPTIONAL.
}
PhysicalChannelReconfiguration-r5-IEs ::= SEQUENCE {
    -- User equipment IEs
        OPTIONAL.
        cipheringModeInfo
                                        CipheringModeInfo
                                                                             OPTIONAL.
                                        ActivationTime
        activationTime
                                                                             OPTIONAL,
        new-U-RNTI
                                        U-RNTI
                                                                             OPTIONAL,
        new-C-RNTI
                                        C-RNTI
                                                                             OPTIONAL,
        new-DSCH-RNTI
                                        DSCH-RNTI
                                                                             OPTIONAL,
                                       H-RNTI
        new-H-RNTI
                                                                             OPTIONAL.
        rrc-StateIndicator
                                        RRC-StateIndicator,
        rrc-StateIndicator RRC-StateIndicator, utran-DRX-CycleLengthCoeff UTRAN-DRX-CycleLengthCoefficient
    -- Core network IEs
                                      CN-InformationInfo
        cn-InformationInfo
                                                                             OPTIONAL.
    -- UTRAN mobility IEs
        ura-Identity
                                       URA-Identity
                                                                             OPTIONAL,
    -- Radio bearer IEs
        dl-CounterSynchronisationInfo DL-CounterSynchronisationInfo-r5
                                                                             OPTIONAL,
    -- Physical channel IEs
        -- TABULAR: III - C'-
                                        FrequencyInfo
                                                                             OPTIONAL,
                                        MaxAllowedUL-TX-Power
                                                                              OPTIONAL,
        -- TABULAR: UL-ChannelRequirementWithCPCH-SetID-r5 contains the choice
        -- between UL DPCH info, CPCH SET info and CPCH set ID.
        ul-ChannelRequirement UL-ChannelRequirementWithCPCH-SetID-r5 OPTIONAL, modeSpecificInfo CHOICE {
                                        CHOICE {
        modeSpecificInfo
                                            SEQUENCE {
            fdd
                dl-PDSCH-Information
                                                DL-PDSCH-Information
                                                                            OPTIONAL
            tdd
                                            NULL
        dl-HSPDSCH-Information
dl-CommonInformation
dl-InformationPerRL-List
                                        DL-HSPDSCH-Information
                                                                             OPTIONAL,
                                        DL-CommonInformation-r5
                                                                             OPTIONAL.
                                       DL-InformationPerRL-List-r5
                                                                             OPTIONAL
}
__ ****************
-- PHYSICAL CHANNEL RECONFIGURATION COMPLETE
__ ****************
PhysicalChannelReconfigurationComplete ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier RRC-TransactionIdentifier, ul-IntegProtActivationInfo IntegrityProtActivationInfo
                                                                             OPTIONAL.
        -- TABULAR: UL-TimingAdvance is applicable for TDD mode only.
        ul-TimingAdvance
                                        UL-TimingAdvance
                                                                             OPTIONAL,
    -- Radio bearer IEs
        count-C-ActivationTime ActivationTime
rb-UL-CiphActivationTimeInfo RB-ActivationTimeInfoList
ul-CounterSynchronisationInfo
laterNonCriticalExtensions SEQUENCE {
                                                                             OPTIONAL.
                                                                             OPTIONAL,
            -- Container for additional R99 extensions
            physicalChannelReconfigurationComplete-r3-add-ext BIT STRING OPTIONAL,
            nonCriticalExtensions
                                            SEQUENCE {} OPTIONAL
        } OPTIONAL
}
```

```
__ ****************************
-- PHYSICAL CHANNEL RECONFIGURATION FAILURE
PhysicalChannelReconfigurationFailure ::= SEQUENCE {
   -- User equipment IEs
       rrc-TransactionIdentifier RRC-TransactionIdentifier failureCause FailureCauseWithProtErr, laterNonCriticalExtensions SEQUENCE {
                                                                        OPTIONAL,
            -- Container for additional R99 extensions
           physicalChannelReconfigurationFailure-r3-add-ext BIT STRING OPTIONAL,
           {\tt nonCriticalExtensions} \qquad \qquad {\tt SEQUENCE} \ \{\} \qquad {\tt OPTIONAL}
       } OPTIONAL
}
************
-- PHYSICAL SHARED CHANNEL ALLOCATION (TDD only)
__ ****************
PhysicalSharedChannelAllocation ::= CHOICE {
                                   SEQUENCE {
       physicalSharedChannelAllocation-r3
       PhysicalSharedChannelAllocation-r3-IEs, laterNonCriticalExtensions SEQUENCE {
           -- Container for additional R99 extensions
                                                       BIT STRING
           physicalSharedChannelAllocation-r3-add-ext
                                                                        OPTIONAL,
           } OPTIONAL
   },
                          SEQUENCE {
   later-than-r3
       rrc-TransactionIdentifier RRC-Transa CHOICE {
 r4
                                                                        OPTIONAL,
                                      RRC-TransactionIdentifier,
                                        SEQUENCE {
               physicalSharedChannelAllocation-r4
                                        PhysicalSharedChannelAllocation-r4-IEs,
                                                  SEQUENCE {
               v4d0NonCriticalExtensions
                   -- Container for adding non critical extensions after freezing REL-5
                   OPTIONAL
                                         SEQUENCE {}
           criticalExtensions
       }
   }
}
PhysicalSharedChannelAllocation-r3-IEs ::= SEQUENCE {
   -- TABULAR: Integrity protection shall not be performed on this message.
   -- User equipment IEs
                                     DSCH-RNTI
       dsch-RNTI
                                                                        OPTIONAL,
   rrc-TransactionIdentifier RRC-TransactionIdentifier,
-- Physical channel IEs
                                     UL-TimingAdvanceControl
       ul-TimingAdvance
       pusch-CapacityAllocationInfo PUSCH-CapacityAllocationInfo OPTIONAL, pdsch-CapacityAllocationInfo PDSCH-CapacityAllocationInfo OPTIONAL,
        -- TABULAR: If confirmRequest is not present, the default value "No Confirm"
        -- shall be used as specified in 10.2.25.
                             ENUMERATED {
       confirmRequest
                                         confirmPDSCH, confirmPUSCH } OPTIONAL,
       trafficVolumeReportRequest INTEGER (0..255)
                                                                         OPTIONAL,
                                       TimeslotList
       iscpTimeslotList
                                                                             OPTIONAL,
       requestPCCPCHRSCP
                                          BOOLEAN
}
PhysicalSharedChannelAllocation-r4-IEs ::= SEQUENCE {
    -- TABULAR: Integrity protection shall not be performed on this message.
   -- Physical channel IEs
       ul-TimingAdvance
                                      UL-TimingAdvanceControl-r4
                                                                         OPTIONAL,
       pusch-CapacityAllocationInfo PUSCH-CapacityAllocationInfo-r4 OPTIONAL, pdsch-CapacityAllocationInfo PDSCH-CapacityAllocationInfo-r4 OPTIONAL,
       -- TABULAR: If confirmRequest is not present, the default value "No Confirm"
        -- shall be used as specified in 10.2.25.
                                      ENUMERATED {
       confirmRequest
```

```
confirmPDSCH, confirmPUSCH }
                                                                       OPTIONAL,
                                   INTEGER (0..255)
TimeslotList-r4
       trafficVolumeReportRequest
                                                                       OPTIONAL,
       iscpTimeslotList
                                                                       OPTIONAL,
       requestPCCPCHRSCP
                                     BOOLEAN
  *************
-- PUSCH CAPACITY REQUEST (TDD only)
__ ******************
PUSCHCapacityRequest ::= SEQUENCE {
   -- User equipment IEs
       dsch-RNTI
                                     DSCH-RNTI
                                                                       OPTIONAL,
   -- Measurement IEs
       trafficVolume TrafficVolumeMeasuredResultsList timeslotListWithISCP TimeslotListWithISCP primaryCCPCH-RSCP PrimaryCCPCH-RSCP
                                                                      OPTIONAL.
                                                                       OPTIONAL,
       allocationConfirmation CHOICE {
   pdschConfirmation PDSCH
   puschConfirmation PUSCH
                                    PDSCH-Identity,
PUSCH-Identity
          pdschConfirmation
puschConfirmation
                                                                       OPTIONAL,
       protocolErrorIndicator ProtocolErrorIndicatorWithMoreInfo, laterNonCriticalExtensions SEQUENCE {
       protocolErrorIndicator
           -- Container for additional R99 extensions
           puschCapacityRequest-r3-add-ext BIT STRING
                                                          OPTIONAL,
           v590NonCriticalExtensions SEQUENCE {
              puschCapacityRequest-v590ext
PUSCHCapacityRequest-v590ext,
              nonCriticalExtensions
                                            SEQUENCE {} OPTIONAL
                  OPTIONAL
           OPTIONAL
}
PUSCHCapacityRequest-v590ext ::= SEQUENCE {
   primaryCCPCH-RSCP-delta
                              DeltaRSCP
                                                       OPTIONAL
-- RADIO BEARER RECONFIGURATION
__ ****************************
RadioBearerReconfiguration ::= CHOICE {
                               SEQUENCE {
       radioBearerReconfiguration-r3 RadioBearerReconfiguration-r3-IEs,
       -- Prefix "v3ao" is used (in one instance) to keep alignment with R99
       radioBearer Reconfiguration-v3a0ext \quad RadioBearer Reconfiguration-v3a0ext \,, \\
           -- Container for additional R99 extensions
              radioBearerReconfiguration-r3-add-ext BIT STRING
                                                                     OPTIONAL.
                                               SEQUENCE {
               v4b0NonCriticalExtensions
                  radioBearerReconfiguration-v4b0ext
                                                RadioBearerReconfiguration-v4b0ext-IEs,
                                                   SEQUENCE {
                  v590NonCriticalExtensions
                      radioBearerReconfiguration-v590ext
                                             RadioBearerReconfiguration-v590ext-IEs,
                      nonCriticalExtensions
                                                        SEQUENCE {} OPTIONAL
                     OPTIONAL
                  OPTIONAL
               OPTIONAL
           OPTIONAL
                                 SEQUENCE {
   later-than-r3
                                RRC-TransactionIdentifier,
       rrc-TransactionIdentifier
       criticalExtensions
                                    CHOICE {
                                      SEQUENCE {
           r4
               radioBearerReconfiguration-r4 RadioBearerReconfiguration-r4-IEs,
               v4d0NonCriticalExtensions
                                                SEQUENCE {
                   -- Container for adding non critical extensions after freezing REL-5
                  radioBearerReconfiguration-r4-add-ext BIT STRING OPTIONAL,
                                                   SEQUENCE {
                  v590NonCriticalExtensions
                      radioBearerReconfiguration-v590ext
                                             RadioBearerReconfiguration-v590ext-IEs,
                      nonCriticalExtensions
                                                   SEQUENCE {}
                      OPTIONAL
                  OPTIONAL
```

```
},
                                            CHOICE {
            criticalExtensions
                                                     SEQUENCE {
                r5
                    radioBearerReconfiguration-r5
                                                       RadioBearerReconfiguration-r5-IEs,
                    -- Container for adding non critical extensions after freezing REL-6
                    radioBearerReconfiguration-r5-add-ext BIT STRING OPTIONAL,
                                                        SEQUENCE {}
                                                                       OPTIONAL
                    nonCriticalExtensions
                criticalExtensions
                                                SEQUENCE {}
           }
       }
    }
}
RadioBearerReconfiguration-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
       rrc-TransactionIdentifier
                                        RRC-TransactionIdentifier,
        integrityProtectionModeInfo
                                       IntegrityProtectionModeInfo
                                                                             OPTIONAL.
        cipheringModeInfo
                                        CipheringModeInfo
                                                                             OPTIONAL.
        activationTime
                                        ActivationTime
                                                                             OPTIONAL.
        new-U-RNTI
                                        U-RNTI
                                                                             OPTIONAL,
       new-C-RNTI
                                        C-RNTI
                                                                             OPTIONAL,
        rrc-StateIndicator
       rrc-StateIndicator RRC-StateIndicator, utran-DRX-CycleLengthCoeff UTRAN-DRX-CycleLengthCoefficient
    -- Core network IEs
       cn-InformationInfo
                                        CN-InformationInfo
                                                                             OPTIONAL.
    -- UTRAN mobility IEs
       ura-Identity
                                       URA-Identity
                                                                             OPTIONAL,
    -- Radio bearer IEs
       rab-InformationReconfigList
                                      RAB-InformationReconfigList
                                                                             OPTIONAL.
        -- NOTE: IE rb-InformationReconfigList should be optional in later versions
        -- of this message
        rb-InformationReconfigList
                                        RB-InformationReconfigList,
       rb-InformationAffectedList
                                      RB-InformationAffectedList
                                                                            OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo
                                        UL-CommonTransChInfo
                                                                            OPTIONAL,
        ul-deletedTransChInfoList
                                        UL-DeletedTransChInfoList
                                                                             OPTIONAL,
        ul-AddReconfTransChInfoList UL-AddReconfTransChInfoList
       modeSpecificTransChInfo CHOICE {
            fdd
                                            SEOUENCE {
                cpch-SetID
                                                CPCH-SetID
                                                                             OPTIONAL,
                addReconfTransChDRAC-Info
                                                DRAC-StaticInformationList OPTIONAL
            }.
            tdd
                                            NULL
       DL-CommonTransChInfo
dl-DeletedTransChInfoList
dl-AddReconfTransChInfoList
Physical channel TEC
DL-CommonTransChInfo
DL-CommonTransChInfo
DL-AddReconfTransChInfo
                                                                             OPTIONAL,
                                                                             OPTIONAL,
                                        DL-DeletedTransChInfoList
                                                                             OPTIONAL,
                                       DL-AddReconfTransChInfo2List
                                                                             OPTIONAL,
    -- Physical channel IEs
        frequencyInfo
                                        FrequencyInfo
                                                                             OPTIONAL,
        maxAllowedUL-TX-Power
                                      MaxAllowedUL-TX-Power
        ul-ChannelRequirement
                                        UL-ChannelRequirement
                                                                             OPTIONAL,
        modeSpecificPhysChInfo
                                        CHOICE {
                                            SEQUENCE {
                dl-PDSCH-Information
                                                DL-PDSCH-Information
            },
            tdd
                                            NULL
        dl-CommonInformation
                                        DL-CommonInformation
        -- NOTE: IE dl-InformationPerRL-List should be optional in later versions
        -- of this message
                                      DL-InformationPerRL-List
        dl-InformationPerRL-List
}
RadioBearerReconfiguration-v3a0ext ::= SEQUENCE {
    new-DSCH-RNTI
                                    DSCH-RNTT
                                                                         OPTIONAL.
}
RadioBearerReconfiguration-v4b0ext-IEs ::= SEQUENCE {
    -- Physical channel IEs
        -- ssdt-UL extends SSDT-Information, which is included in
        -- DL-CommonInformation. FDD only.
        ssdt-UL-r4
                                            SSDT-UL
                                                                                 OPTIONAL,
        -- The order of the RLs in IE cell-id-PerRL-List is the same as
        -- in IE DL-InformationPerRL-List included in this message
        cell-id-PerRL-List
                                            CellIdentity-PerRL-List
                                                                                OPTIONAL
}
```

```
RadioBearerReconfiguration-v590ext-IEs ::= SEQUENCE {
    -- Physical channel IEs
       dl-TPC-PowerOffsetPerRL-List DL-TPC-PowerOffsetPerRL-List
                                                                           OPTIONAL
}
RadioBearerReconfiguration-r4-IEs ::= SEQUENCE {
    -- User equipment IEs
                                                                            OPTIONAL.
        integrityProtectionModeInfo
                                        IntegrityProtectionModeInfo
        cipheringModeInfo
                                        CipheringModeInfo
                                                                             OPTIONAL,
        activationTime
                                        ActivationTime
                                                                             OPTIONAL,
        new-U-RNTI
                                        U-RNTI
                                                                            OPTIONAL,
        new-C-RNTI
                                        C-RNTI
                                                                            OPTIONAL,
       new-DSCH-RNTT
                                       DSCH-RNTT
                                                                            OPTIONAL,
        rrc-StateIndicator
                                       RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff
                                        UTRAN-DRX-CycleLengthCoefficient
                                                                            OPTIONAL,
    -- Core network IEs
        cn-InformationInfo
                                        CN-InformationInfo
                                                                            OPTIONAL.
    -- UTRAN mobility IEs
       ura-Identity
                                        URA-Identity
                                                                             OPTIONAL.
    -- Radio bearer IEs
       Radio bearer LES
rab-InformationReconfigList
rb-InformationReconfigList
RB-InformationReconfigList-r4
RB-InformationAffectedList
                                                                            OPTIONAL,
                                                                            OPTIONAL,
                                                                            OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo
                                        III.-CommonTransChInfo-r4
                                                                            OPTIONAL.
        ul-deletedTransChInfoList
                                        UL-DeletedTransChInfoList
                                                                            OPTIONAL,
        ul-AddReconfTransChInfoList
                                        UL-AddReconfTransChInfoList
                                                                            OPTIONAL,
        modeSpecificTransChInfo
                                        CHOICE {
                                            SEQUENCE {
            fdd
                cpch-SetID
                                                CPCH-Set ID
                                                                            OPTIONAL.
                addReconfTransChDRAC-Info
                                                DRAC-StaticInformationList OPTIONAL
            },
            tdd
                                            NULL
                                                                            OPTIONAL.
        dl-CommonTransChInfo
        dl-DeletedTransChInfoList
                                       DL-CommonTransChInfo-r4
                                                                            OPTIONAL,
                                        DL-DeletedTransChInfoList
                                                                             OPTIONAL,
        dl-AddReconfTransChInfoList DL-AddReconfTransChInfoList-r4
                                                                            OPTIONAL,
    -- Physical channel IEs
        frequencyInfo
                                       FrequencyInfo
                                                                            OPTIONAL,
        maxAllowedUL-TX-Power
                                        MaxAllowedUL-TX-Power
                                                                            OPTIONAL,
        ul-ChannelRequirement
                                        UL-ChannelRequirement-r4
                                                                            OPTIONAL,
        modeSpecificPhysChInfo
                                       CHOICE {
                                            SEQUENCE {
            fdd
                dl-PDSCH-Information
                                                DL-PDSCH-Information
                                                                            OPTIONAL
            },
            tdd
                                            NULL
        dl-CommonInformation
                                       DL-CommonInformation-r4
                                                                            OPTIONAL.
        dl-InformationPerRL-List
                                       DL-InformationPerRL-List-r4
                                                                            OPTIONAL
}
RadioBearerReconfiguration-r5-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo
                                        IntegrityProtectionModeInfo
                                                                            OPTIONAL,
        cipheringModeInfo
                                        CipheringModeInfo
                                                                             OPTIONAL,
        activationTime
                                       ActivationTime
                                                                            OPTIONAL,
        new-U-RNTI
                                        U-RNTI
                                                                             OPTIONAL,
       new-C-RNTT
                                        C-RNTT
                                                                            OPTIONAL,
        new-DSCH-RNTI
                                       DSCH-RNTI
                                                                            OPTIONAL,
        new-H-RNTI
                                        H-RNTI
                                                                            OPTIONAL.
        rrc-StateIndicator
                                       RRC-StateIndicator,
       utran-DRX-CycleLengthCoeff
                                       UTRAN-DRX-CycleLengthCoefficient
                                                                            OPTIONAL.
    -- Core network IEs
        cn-InformationInfo
                                        CN-InformationInfo
                                                                            OPTIONAL,
    -- UTRAN mobility IEs
       ura-Identity
                                        URA-Identity
                                                                            OPTIONAL.
    -- Specification mode information
        specificationMode
                                        CHOICE {
            complete
                                          SEQUENCE {
            -- Radio bearer IEs
                rab-InformationReconfigList
                                                RAB-InformationReconfigList
                                                                                     OPTIONAL.
                rb-InformationReconfigList
                                                                                     OPTIONAL,
                                                RB-InformationReconfigList-r5
                                                RB-InformationAffectedList-r5
                rb-InformationAffectedList
                                                                                     OPTIONAL,
                rb-PDCPContextRelocationList
                                               RB-PDCPContextRelocationList
                                                                                    OPTIONAL,
            -- Transport channel IEs
                ul-CommonTransChInfo
                                                UL-CommonTransChInfo-r4
                                                                                    OPTIONAL,
                ul-deletedTransChInfoList
                                                UL-DeletedTransChInfoList
                                                                                    OPTIONAL,
                ul-AddReconfTransChInfoList
                                                UL-AddReconfTransChInfoList
                                                                                    OPTIONAL,
```

```
SEQUENCE {
                                                                                                         CPCH-SetID OPTIONAL DRAC-StaticInformationList OPTIONAL
                                               cpch-SetID
                                                addReconfTransChDRAC-Info
                                        tdd
                                                                                                     NULL
                                                                                                                                                                        OPTIONAL.
                               dl-CommonTransChInfo DL-CommonTransChInfo-r4
dl-DeletedTransChInfoList DL-DeletedTransChInfoList-r5
dl-AddReconfTransChInfoList DL-AddReconfTransChInfoList-r5
                                                                                                                                                                       OPTIONAL,
                                                                                                                                                                      OPTIONAL,
                                                                                                                                                                        OPTIONAL
                       },
                                                                                      SEQUENCE {
                        preconfiguration
                        -- All IEs that include an FDD/TDD choice are split in two IEs for this message,
                        -- one for the FDD only elements and one for the TDD only elements, so that one
                        -- FDD/TDD choice in this level is sufficient.
                                                                                            CHOICE {
                               preConfigMode
                                       predefinedConfigIdentity PredefinedConfigIdentity,
defaultConfig SEQUENCE {
    defaultConfigMode DefaultConfigMode,
    defaultConfigIdentity DefaultConfigIdentity-r5
                                        }
                                }
                       }
               ### Interpretation of the interpretation of 
        -- Physical channel IEs
                                                                                                                                                      OPTIONAL,
                                                                                                                                                      OPTIONAL,
                           dl-PDSCH-Information
                                                                                                                                                     OPTIONAL
                                                                                             DL-PDSCH-Information
                      tdd
                                                                                       NULL
               dl-HSPDSCH-Information DL-HSPDSCH-Information dl-CommonInformation DL-CommonInformation-r5 dl-InformationPerRL-List DL-InformationPerRL-List-r5
                                                                                                                                                    OPTIONAL,
                                                                                                                                                       OPTIONAL,
                                                                              DL-InformationPerRL-List-r5
                                                                                                                                                       OPTIONAL
}
__ ****************
-- RADIO BEARER RECONFIGURATION COMPLETE
__ ***************
RadioBearerReconfigurationComplete ::= SEQUENCE {
        -- User equipment IEs
              User equipment IEs
rrc-TransactionIdentifier RRC-TransactionIdentifier,
ul-IntegProtActivationInfo IntegrityProtActivationInfo
                                                                                                                                                    OPTIONAL,
                -- TABULAR: UL-TimingAdvance is applicable for TDD mode only.
                                                           UL-TimingAdvance
               ul-TimingAdvance
                                                                                                                                                     OPTIONAL,
        -- Radio bearer IEs
               count-C-ActivationTime
               count-C-ActivationTime ActivationTime OPTIONAL, rb-UL-CiphActivationTimeInfo RB-ActivationTimeInfoList OPTIONAL, ul-CounterSynchronisationInfo UL-CounterSynchronisationInfo OPTIONAL, laterNonCriticalExtensions SEQUENCE {
                       -- Container for additional R99 extensions
                       radioBearerReconfigurationComplete-r3-add-ext BIT STRING
                                                                                                                                                             OPTIONAL,
                       nonCriticalExtensions
                                                                                      SEQUENCE {} OPTIONAL
                } OPTIONAL
}
__ *******************
-- RADIO BEARER RECONFIGURATION FAILURE
__ ***************
RadioBearerReconfigurationFailure ::= SEQUENCE {
        -- User equipment IEs
               rrc-TransactionIdentifier RRC-TransactionIdentifier, failureCause FailureCauseWithProtErr,
        -- Radio bearer IEs
               potentiallySuccesfulBearerList RB-IdentityList
                                                                                                                                                      OPTIONAL,
                -- Container for additional R99 extensions
                       radioBearerReconfigurationFailure-r3-add-ext BIT STRING OPTIONAL,
                       nonCriticalExtensions
                                                                                       SEQUENCE {} OPTIONAL
```

```
} OPTIONAL
}
__ ****************************
-- RADIO BEARER RELEASE
__ ****************
RadioBearerRelease ::= CHOICE {
                                                                  SEQUENCE {
      r3
              radioBearerRelease-r3 RadioBearerRelease-r3-IEs,
v3a0NonCriticalExtensions SEQUENCE {
    radioBearerRelease-v3a0ext RadioBearerRelease-v3a0ext,
laterNonCriticalExtensions SEQUENCE {
                      -- Container for additional R99 extensions
                      OPTIONAL.
                                                                                          SEQUENCE {
                                     radioBearerRelease-v4b0ext RadioBearerRelease-v4b0ext-IEs, v590NonCriticalExtensions SEQUENCE {
                                                                                                 SEQUENCE {
                                             radioBearerRelease-v590ext RadioBearerRelease-v590ext-IEs, nonCriticalExtensions SEQUENCE {} OPTIONAL
                                             OPTIONAL
                                    OPTIONAL
                              OPTIONAL
               } OPTIONAL
                                                                   SEQUENCE {
        later-than-r3
                                                                 RRC-TransactionIdentifier,
CHOICE {
              rrc-TransactionIdentifier
               criticalExtensions
                                                                          CHOICE {
                              radioBearerRelease-r4 SEQUENCE {
                              v4d0NonCriticalExtensions SECTION (SECTION OF SECTION O
                                      -- Container for adding non critical extensions after freezing REL-5
                                      radioBearerRelease-r4-add-ext BIT STRING OPTIONAL,
                                      v590NonCriticalExtensions
                                                                                                 SEQUENCE {
                                             radioBearerRelease-v590ext RadioBearerRelease-v590ext-IEs, nonCriticalExtensions SEOUENCE {} OPTIONAL
                                                                                                       SEQUENCE {}
                                             nonCriticalExtensions
                                                                                                                                  OPTIONAL
                                           OPTIONAL
                                      OPTIONAL
                                                                                  CHOICE {
                       criticalExtensions
                                     radioBearerRelease-r5
-- Contain --
                             r5
                                                                                           RadioBearerRelease-r5-IEs,
                                      -- Container for adding non critical extensions after freezing REL-6 \,
                                      radioBearerRelease-r5-add-ext BIT STRING OPTIONAL,
                                      nonCriticalExtensions
                                                                                                 SEQUENCE { } OPTIONAL
                              criticalExtensions
                                                                                       SEQUENCE {}
                      }
             }
       }
}
RadioBearerRelease-r3-IEs ::= SEQUENCE {
        -- User equipment IEs
               rrc-TransactionIdentifier
                                                                       RRC-TransactionIdentifier,
               rrc-Transactioniuencii---
integrityProtectionModeInfo
                                                                           IntegrityProtectionModeInfo
                                                                                                                                                OPTIONAL,
              cipheringModeInfo
                                                                          CipheringModeInfo
                                                                                                                                                OPTIONAL,
               activationTime
                                                                           ActivationTime
                                                                                                                                                OPTIONAL.
               new-II-RNTT
                                                                           II-RNTT
                                                                                                                                                OPTIONAL.
               new-C-RNTI
                                                                          C-RNTI
                                                                                                                                                OPTIONAL,
               rrc-StateIndicator
                                                                          RRC-StateIndicator,
              rrc-StateIndicator RRC-StateIndicator, utran-DRX-CycleLengthCoeff UTRAN-DRX-CycleLengthCoefficient OPTIONAL,
        -- Core network IEs
               cn-InformationInfo
                                                                          CN-InformationInfo
                                                                                                                                                OPTIONAL,
               signallingConnectionRelIndication CN-DomainIdentity
                                                                                                                                                OPTIONAL,
        -- UTRAN mobility IEs
              ura-Identity
                                                                           URA-Identity
                                                                                                                                                OPTIONAL,
        -- Radio bearer IEs
              rab-InformationReconfigList
rb-InformationReleaseList
rb-InformationAffectedList
RB-InformationReleaseList,
RB-InformationAffectedList
                                                                                                                                                OPTIONAL,
                                                                                                                                                OPTIONAL.
               dl-CounterSynchronisationInfo DL-CounterSynchronisationInfo
                                                                                                                                                OPTIONAL,
        -- Transport channel IEs
               ul-CommonTransChInfo
                                                                           UL-CommonTransChInfo
                                                                                                                                                OPTIONAL,
              ul-deletedTransChInfoList
ul-AddReconfTransChInfoList
                                                                          UL-DeletedTransChInfoList
                                                                                                                                                OPTIONAL.
                                                                          UL-AddReconfTransChInfoList
                                                                                                                                                OPTIONAL,
```

```
modeSpecificTransChInfo
                                           CHOICE {
                                               SEQUENCE {
             fdd
                 cpch-SetID
                                                    CPCH-SetID
                                                                                   OPTIONAL.
                 addReconfTransChDRAC-Info
                                                    DRAC-StaticInformationList OPTIONAL
             tdd
                                                NULL
        dl-DeletedTransChInfo
dl-DeletedTransChInfoList
dl-AddReconfTransChInfoList
DL-AddReconfTransChInfoList
DL-AddReconfTransChInfoList
                                                                                   OPTIONAL.
                                                                                   OPTIONAL,
                                                                                   OPTIONAL,
                                           DL-AddReconfTransChInfo2List
                                                                                   OPTIONAL,
    -- Physical channel IEs
        frequencyInfo
                                           FrequencyInfo
                                                                                   OPTIONAL.
        maxAllowedUL-TX-Power
                                           MaxAllowedIII.-TX-Power
                                                                                   OPTIONAL.
        ul-ChannelRequirement
                                           UL-ChannelRequirement
                                                                                   OPTIONAL,
        modeSpecificPhysChInfo
                                           CHOICE {
                                             SEQUENCE {
             fdd
                 dl-PDSCH-Information
                                                    DL-PDSCH-Information
                                                                                  OPTIONAL
             },
             t.dd
                                           NULL
        dl-CommonInformation
                                           DL-CommonInformation
                                                                                   OPTIONAL.
        dl-InformationPerRL-List
                                           DL-InformationPerRL-List
                                                                                   OPTIONAL
}
RadioBearerRelease-v3aOext ::= SEOUENCE {
    new-DSCH-RNTI
                                       DSCH-RNTI
                                                                              OPTIONAL
RadioBearerRelease-v4b0ext-IEs ::= SEQUENCE {
    -- Physical channel IEs
        -- IE ssdt-UL extends SSDT-Information, which is included in
        -- DL-CommonInformation. FDD only.
        ssdt-UL-r4
                                                SSDT-UL
                                                                                       OPTIONAL,
        -- The order of the RLs in IE cell-id-PerRL-List is the same as
        -- in IE DL-InformationPerRL-List included in this message
        cell-id-PerRL-List
                                                CellIdentity-PerRL-List
                                                                                       OPTIONAL
}
RadioBearerRelease-v590ext-IEs ::= SEQUENCE {
    -- Physical channel IEs
        dl-TPC-PowerOffsetPerRL-List
                                         DL-TPC-PowerOffsetPerRL-List
                                                                                  OPTIONAL
}
RadioBearerRelease-r4-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo
                                           IntegrityProtectionModeInfo
                                                                                   OPTIONAL,
        cipheringModeInfo
                                           CipheringModeInfo
                                                                                   OPTIONAL.
        activationTime
                                           ActivationTime
                                                                                   OPTIONAL.
        new-U-RNTI
                                           U-RNTI
                                                                                   OPTIONAL,
        new-C-RNTI
                                           C-RNTI
        new-DSCH-RNTI
                                           DSCH-RNTI
                                                                                   OPTIONAL,
        rrc-StateIndicator
                                           RRC-StateIndicator,
        rrc-StateIndicator RRC-StateIndicator, utran-DRX-CycleLengthCoeff UTRAN-DRX-CycleLengthCoefficient OPTIONAL,
    -- Core network IEs
                                                                                   OPTIONAL,
        cn-InformationInfo
                                           CN-InformationInfo
        {\tt signallingConnectionRelIndication} \quad {\tt CN-DomainIdentity}
                                                                                   OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity
                                           URA-Identity
                                                                                   OPTIONAL,
    -- Radio bearer IEs
        rab-InformationReconfigList rb-InformationReleaseList rb-InformationAffectedList RB-InformationAffectedList RB-InformationAffectedList
                                                                                   OPTIONAL.
                                                                                   OPTIONAL,
        dl-CounterSynchronisationInfo DL-CounterSynchronisationInfo
                                                                                   OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo
                                           UL-CommonTransChInfo-r4
                                                                                   OPTIONAL.
        ul-deletedTransChInfoList
        ul-deletedTransChInfoList
ul-AddReconfTransChInfoList
modeSpecificTransChInfo
                                                                                   OPTIONAL,
                                           UL-DeletedTransChInfoList
                                           UL-AddReconfTransChInfoList
                                                                                   OPTIONAL,
        modeSpecificTransChInfo
                                           CHOICE {
                                                SEQUENCE {
             fdd
                 cpch-SetID
                                                    CPCH-Set.ID
                                                                                   OPTIONAL.
                 addReconfTransChDRAC-Info
                                                    DRAC-StaticInformationList OPTIONAL
             },
             tdd
                                                NULL
                                                                                   OPTIONAL,
        dl-CommonTransChInfo DL-CommonTransChInfo-r4
dl-DeletedTransChInfoList DL-DeletedTransChInfoList
dl-AddReconfTransChInfoList DL-AddReconfTransChInfoList-r4
        dl-CommonTransChInfo
                                                                                   OPTIONAL,
                                                                                  OPTIONAL,
                                                                                 OPTIONAL,
    -- Physical channel IEs
```

```
frequencyInfo
                                        FrequencyInfo
                                                                             OPTIONAL,
        maxAllowedUL-TX-Power
                                        MaxAllowedUL-TX-Power
                                                                             OPTIONAL,
        ul-ChannelRequirement
                                        UL-ChannelRequirement-r4
                                                                             OPTIONAL,
        modeSpecificPhysChInfo
                                        CHOICE {
            fdd
                                             SEOUENCE {
                dl-PDSCH-Information
                                                 DL-PDSCH-Information
                                                                             OPTIONAL
            },
            tdd
                                        NULL
        dl-CommonInformation
                                        DL-CommonInformation-r4
                                                                             OPTIONAL.
        dl-InformationPerRL-List
                                        DL-InformationPerRL-List-r4
                                                                             OPTIONAL
}
RadioBearerRelease-r5-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo
                                         IntegrityProtectionModeInfo
                                                                              OPTIONAL,
        cipheringModeInfo
                                        CipheringModeInfo
                                                                             OPTIONAL,
        activationTime
                                        ActivationTime
                                                                             OPTIONAL.
        new-II-RNTT
                                        II-RNTT
                                                                             OPTIONAL,
        new-C-RNTI
                                        C-RNTI
                                                                              OPTIONAL,
        new-DSCH-RNTI
                                        DSCH-RNTI
                                                                             OPTIONAL,
        new-H-RNTI
                                        H-RNTI
                                                                             OPTIONAL,
        rrc-StateIndicator
                                        RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff
Core network JEs
                                        UTRAN-DRX-CycleLengthCoefficient
                                                                             OPTIONAL,
    -- Core network IEs
        cn-InformationInfo
                                        CN-InformationInfo
                                                                              OPTIONAL.
        signallingConnectionRelIndication CN-DomainIdentity
                                                                             OPTIONAL.
    -- UTRAN mobility IEs
        ura-Identity
                                        URA-Identity
                                                                             OPTIONAL,
    -- Radio bearer IEs
        rab-InformationReconfigList
rb-InformationReleaseList
rb-InformationAffectedList
RB-InformationReleaseList,
RB-InformationAffectedList-r5
                                                                             OPTIONAL.
                                                                             OPTIONAL,
        dl-CounterSynchronisationInfo DL-CounterSynchronisationInfo-r5
                                                                             OPTIONAL,
    -- Transport channel IEs
                                        UL-CommonTransChInfo-r4
        ul-CommonTransChInfo
                                                                             OPTIONAL.
                                                                             OPTIONAL,
        ul-deletedTransChInfoList
                                        UL-DeletedTransChInfoList
        ul-AddReconfTransChInfoList UL-AddReconfTransChInfoList
                                                                             OPTIONAL,
        modeSpecificTransChInfo
                                        CHOICE {
            fdd
                                             SEQUENCE {
                cpch-SetID
                                                 CPCH-SetID
                                                                             OPTIONAL.
                addReconfTransChDRAC-Info
                                                 DRAC-StaticInformationList OPTIONAL
            },
            tdd
                                            NULL
        dl-DeletedTransChInfo DL-CommonTransChInfo-r4
dl-DeletedTransChInfoList DL-DeletedTransChInfoList DL-AddReconfTransChInfoList
                                                                             OPTIONAL,
                                        DL-DeletedTransChInfoList-r5
                                                                             OPTIONAL.
                                        DL-AddReconfTransChInfoList-r5
                                                                             OPTIONAL,
    -- Physical channel IEs
        frequencyInfo
                                        FrequencyInfo
                                                                             OPTIONAL,
        maxAllowedUL-TX-Power
                                        MaxAllowedUL-TX-Power
                                                                             OPTIONAL,
        ul-ChannelRequirement
                                        UL-ChannelRequirement-r5
                                                                             OPTIONAL,
        modeSpecificPhysChInfo
                                        CHOICE {
                                            SEQUENCE {
                                                 DL-PDSCH-Information
                dl-PDSCH-Information
                                                                             OPTIONAL
            },
            tdd
                                        NULL
        dl-HSPDSCH-Information
                                        DL-HSPDSCH-Information
                                                                             OPTIONAL,
        dl-CommonInformation
                                        DL-CommonInformation-r5
                                                                             OPTIONAL,
        dl-InformationPerRL-List
                                        DL-InformationPerRL-List-r5
                                                                             OPTIONAL
}
  ***************
-- RADIO BEARER RELEASE COMPLETE
__ **************
RadioBearerReleaseComplete ::= SEQUENCE {
    -- User equipment IEs
                                      RRC-TransactionIdentifier,
        rrc-TransactionIdentifier
        ul-IntegProtActivationInfo
                                        IntegrityProtActivationInfo
                                                                             OPTIONAL.
        -- TABULAR: UL-TimingAdvance is applicable for TDD mode only.
        ul-TimingAdvance
                                        UL-TimingAdvance
                                                                             OPTIONAL,
    -- Radio bearer IEs
        count-C-ActivationTime
                                        ActivationTime
                                                                              OPTIONAL,
```

```
rb-UL-CiphActivationTimeInfo ul-CounterSynchronisationInfo uL-CounterSynchronisationInfo laterNonCriticalExtensions SEQUENCE {
                                                                                                                                                         OPTIONAL.
                                                                                                                                                          OPTIONAL,
                        -- Container for additional R99 extensions
                        radioBearerReleaseComplete-r3-add-ext
                                                                                                                 BIT STRING
                                                                                                                                                 OPTIONAL,
                                                                                       SEQUENCE {} OPTIONAL
                        nonCriticalExtensions
                     OPTIONAL
}
__ *********************
-- RADIO BEARER RELEASE FAILURE
__ ******************************
RadioBearerReleaseFailure ::= SEQUENCE {
        -- User equipment IEs
                                                                         RRC-TransactionIdentifier, FailureCauseWithProtErr,
                rrc-TransactionIdentifier
                failureCause
        -- Radio bearer IEs
                {\tt potentiallySuccesfulBearerList} \quad {\tt RB-IdentityList}
                                                                                                                                                          OPTIONAL.
                laterNonCriticalExtensions SEQUENCE {
                         -- Container for additional R99 extensions
                        radioBearerReleaseFailure-r3-add-ext
                                                                                                                 BIT STRING
                                                                                                                                                OPTIONAL.
                        nonCriticalExtensions
                                                                                         SEQUENCE {}
                                                                                                                       OPTIONAL
                      OPTIONAL
    ***********
-- RADIO BEARER SETUP
__ ******************
RadioBearerSetup ::= CHOICE {
                v3a0NonCriticalExtensions RadioBearerSetup-r3-IEs,
                                                                        SEQUENCE {
                        ONOnCriticalExtensions SEQUENCE {
radioBearerSetup-v3a0ext RadioBearerSetup-v3a0ext,
laterNonCriticalExtensions SEQUENCE {
                                 -- Container for additional R99 extensions
                                radioBearerSetup-v4b0ext RadioBearerSetup-v4b0ext-IEs,
v590NonCriticalExtensions SEQUENCE {
    radioBearerSetup-v4b0ext RadioBearerSetup-v4b0ext-IEs,
    v590NonCriticalExtensions SEQUENCE {
                                                radioBearerSetup-v590ext RadioBearerSetup-v590ext-IEs, nonCriticalExtensions SEQUENCE {} OPTIONAL
                                              OPTIONAL
                                        OPTIONAL
                                OPTIONAL
                ) OPTIONAL
        later-than-r3
                                                                        SEQUENCE {
                                                                       RRC-TransactionIdentifier,
                rrc-TransactionIdentifier
                criticalExtensions
                                                                                 CHOICE {
                                 radioBearerSetup-r4 SEQUENCE {
                                v4d0NonCriticalExtensions SEGUENCE (

Contribution SEGUENCE (

SEG
                        r4
                                         -- Container for adding non critical extensions after freezing REL-5
                                        radioBearerSetup-r4-add-ext BIT STRING OPTIONAL, v590NonCriticalExtensions SEQUENCE {
                                                radioBearerSetup-v590ext RadioBearerSetup-v590ext-IEs, nonCriticalExtensions SEQUENCE {} OPTIONAL
                                                 nonCriticalExtensions
                                                OPTIONAL
                                        OPTIONAL
                                                                                         CHOICE {
                        criticalExtensions
                                                                                   SEQUENCE {
                               r5
                                        radioBearerSetup-r5
                                                                                                   RadioBearerSetup-r5-IEs,
                                         -- Container for adding non critical extensions after freezing REL-6
                                         radioBearerSetup-r5-add-ext BIT STRING OPTIONAL,
                                         nonCriticalExtensions
                                                                                                        SEQUENCE {}
                                criticalExtensions
                                                                                              SEQUENCE {}
                      }
             }
       }
}
```

```
RadioBearerSetup-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
                                       RRC-TransactionIdentifier,
        rrc-TransactionIdentifier
        rrc-TransactionIdentificationModeInfo
                                         IntegrityProtectionModeInfo
                                                                              OPTIONAL,
                                        CipheringModeInfo
        cipheringModeInfo
                                                                              OPTIONAL,
        activationTime
                                         ActivationTime
                                                                              OPTIONAL,
                                         U-RNTI
        new-U-RNTI
                                                                              OPTIONAL,
        new-C-RNTI
                                         C-RNTI
                                                                              OPTIONAL,
        rrc-StateIndicator
                                         RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff
                                        UTRAN-DRX-CycleLengthCoefficient
                                                                              OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity
                                        URA-Identity
                                                                              OPTIONAL,
    -- Core network IEs
        cn-InformationInfo
                                        CN-InformationInfo
                                                                              OPTIONAL,
    -- Radio bearer IEs
        rab-InformationSetupList SRB-InformationSetupList RAB-InformationSetupList rb-InformationAffectedList RB-InformationAffectedList
                                                                              OPTIONAL,
                                                                              OPTIONAL,
                                                                              OPTIONAL.
        dl-CounterSynchronisationInfo DL-CounterSynchronisationInfo
                                                                              OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo
                                        UL-CommonTransChInfo
                                                                              OPTIONAL,
        ul-deletedTransChInfoList UL-DeletedTransChInfoList ul-AddReconfTransChInfoList UL-AddReconfTransChInfoList
                                                                              OPTIONAL,
                                                                              OPTIONAL.
        modeSpecificTransChInfo
                                        CHOICE {
                                        SEQUENCE {
                cpch-SetID
                                               CPCH-SetID
                                                                              OPTIONAL,
                addReconfTransChDRAC-Info
                                                 DRAC-StaticInformationList OPTIONAL
            },
            tdd
                                             NULL
                                                                              OPTIONAL.
        dl-CommonTransChInfo
dl-DeletedTransChInfoList
dl-AddReconfTransChInfoList
DL-AddReconfTransChInfoList
                                                                              OPTIONAL,
                                                                              OPTIONAL,
    -- Physical channel IEs
        frequencyInfo
                                        FrequencyInfo
                                                                              OPTIONAL,
        maxAllowedUL-TX-Power
                                      MaxAllowedUL-TX-Power
                                                                              OPTIONAL,
                                        UL-ChannelRequirement
        ul-ChannelRequirement
                                                                              OPTIONAL,
        modeSpecificPhysChInfo
                                        CHOICE {
            fdd
                                             SEOUENCE {
                dl-PDSCH-Information
                                                 DL-PDSCH-Information
                                                                             OPTIONAL
            }.
            tdd
                                             NULL
        dl-InformationPerRL-List
        dl-CommonInformation
                                      DL-CommonInformation
                                                                              OPTIONAL,
                                        DL-InformationPerRL-List
                                                                              OPTIONAL
}
RadioBearerSetup-v3a0ext ::= SEQUENCE {
                                                                        OPTIONAL
   new-DSCH-RNTI
                                    DSCH-RNTI
}
RadioBearerSetup-v4b0ext-IEs ::= SEQUENCE {
     - Physical channel IEs
        -- ssdt-UL extends SSDT-Information, which is included in
        -- DL-CommonInformation. FDD only.
        ssdt-UL-r4
                                             SSDT-UL
                                                                                  OPTIONAL,
        -- The order of the RLs in IE cell-id-PerRL-List is the same as
        -- in IE DL-InformationPerRL-List included in this message
                                             CellIdentity-PerRL-List
        cell-id-PerRL-List
                                                                                 OPTIONAL
}
RadioBearerSetup-v590ext-IEs ::= SEQUENCE {
    -- Physical channel IEs
        dl-TPC-PowerOffsetPerRL-List DL-TPC-PowerOffsetPerRL-List
                                                                            OPTIONAL
}
RadioBearerSetup-r4-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo
                                        IntegrityProtectionModeInfo
                                                                              OPTIONAL.
        cipheringModeInfo
                                         CipheringModeInfo
                                                                              OPTIONAL,
        activationTime
                                         ActivationTime
                                                                              OPTIONAL,
        new-U-RNTI
                                        U-RNTI
                                                                              OPTIONAL,
        new-C-RNTI
                                        C-RNTT
                                                                              OPTIONAL,
        new-DSCH-RNTI
                                        DSCH-RNTI
                                                                              OPTIONAL,
        rrc-StateIndicator
                                        RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff
                                        UTRAN-DRX-CycleLengthCoefficient OPTIONAL,
    -- UTRAN mobility IEs
```

```
ura-Identity
                                         URA-Identity
                                                                              OPTIONAL.
     - Core network IEs
        cn-InformationInfo
                                         CN-InformationInfo
                                                                              OPTIONAL,
    -- Radio bearer IEs
        srb-InformationSetupList
                                         SRB-InformationSetupList
                                                                              OPTIONAL,
        rab-InformationSetupList
                                         RAB-InformationSetupList-r4
                                                                              OPTIONAL,
        rb-InformationAffectedList
                                         RB-InformationAffectedList
                                                                              OPTIONAL,
        dl-CounterSynchronisationInfo
                                        DL-CounterSynchronisationInfo
                                                                              OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo
                                         UL-CommonTransChInfo-r4
                                                                              OPTIONAL,
        ul-deletedTransChInfoList
                                         UL-DeletedTransChInfoList
                                                                              OPTIONAL,
        ul-AddReconfTransChInfoList
                                         UL-AddReconfTransChInfoList
                                                                              OPTIONAL.
        modeSpecificTransChInfo
                                         CHOICE {
            fdd
                                             SEQUENCE {
                cpch-SetID
                                                 CPCH-SetID
                addReconfTransChDRAC-Info
                                                 DRAC-StaticInformationList OPTIONAL
            },
            tdd
                                             NULT.
                                                                              OPTIONAL,
        dl-CommonTransChInfo
                                         DL-CommonTransChInfo-r4
                                                                              OPTIONAL,
        dl-DeletedTransChInfoList
                                         DL-DeletedTransChInfoList
                                                                              OPTIONAL.
        dl-AddReconfTransChInfoList
                                         DL-AddReconfTransChInfoList-r4
                                                                              OPTIONAL,
    -- Physical channel IEs
        frequencyInfo
                                         FrequencyInfo
                                                                              OPTIONAL.
        maxAllowedUL-TX-Power
                                         MaxAllowedUL-TX-Power
                                                                              OPTIONAL.
        ul-ChannelRequirement
                                         UL-ChannelRequirement-r4
                                                                              OPTIONAL,
        modeSpecificPhysChInfo
                                         CHOICE {
            fdd
                                             SEOUENCE {
                dl-PDSCH-Information
                                                 DL-PDSCH-Information
                                                                              OPTIONAL
            },
            tdd
                                             NULL
        dl-CommonInformation
                                         DL-CommonInformation-r4
                                                                              OPTIONAL,
        dl-InformationPerRL-List
                                         DL-InformationPerRL-List-r4
                                                                              OPTIONAL
}
RadioBearerSetup-r5-IEs ::= SEQUENCE {
    -- User equipment IEs
        \verb|integrity| Protection ModeInfo|\\
                                         {\tt IntegrityProtectionModeInfo}
                                                                              OPTIONAL,
        cipheringModeInfo
                                         CipheringModeInfo
                                                                              OPTIONAL,
        activationTime
                                         ActivationTime
                                                                              OPTIONAL.
        new-U-RNTI
                                         U-RNTI
                                                                              OPTIONAL.
        new-C-RNTI
                                         C-RNTI
                                                                              OPTIONAL,
        new-DSCH-RNTI
                                         DSCH-RNTI
                                                                              OPTIONAL,
        new-H-RNTI
                                         H-RNTI
                                                                              OPTIONAL,
        rrc-StateIndicator
                                         RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff
                                         UTRAN-DRX-CycleLengthCoefficient
                                                                              OPTIONAL.
    -- UTRAN mobility IEs
        ura-Identity
                                         URA-Identity
                                                                              OPTIONAL,
    -- Core network IEs
        cn-InformationInfo
                                         CN-InformationInfo
                                                                              OPTIONAL.
    -- Radio bearer IEs
        srb-InformationSetupList
                                         SRB-InformationSetupList-r5
                                                                              OPTIONAL,
        rab-InformationSetupList
                                         RAB-InformationSetupList-r5
                                                                              OPTIONAL.
        rb-InformationAffectedList
                                         RB-InformationAffectedList-r5
                                                                              OPTIONAL,
        dl-CounterSynchronisationInfo
                                        DL-CounterSynchronisationInfo-r5
                                                                              OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo
                                         UL-CommonTransChInfo-r4
                                                                              OPTIONAL,
                                                                              OPTIONAL,
        ul-deletedTransChInfoList
                                         UL-DeletedTransChInfoList
        ul-AddReconfTransChInfoList
                                         III.-AddReconfTransChInfoList
                                                                              OPTIONAL.
        modeSpecificTransChInfo
                                         CHOICE {
            fdd
                                             SEQUENCE {
                cpch-SetID
                                                 CPCH-SetID
                                                                              OPTIONAL.
                addReconfTransChDRAC-Info
                                                 DRAC-StaticInformationList OPTIONAL
            },
            tdd
                                             NULL
                                                                              OPTIONAL,
        dl-CommonTransChInfo
                                         DL-CommonTransChInfo-r4
                                                                              OPTIONAL,
                                         DL-DeletedTransChInfoList-r5
        dl-DeletedTransChInfoList
                                                                              OPTIONAL,
        dl-AddReconfTransChInfoList
                                         DL-AddReconfTransChInfoList-r5
                                                                              OPTIONAL,
    -- Physical channel IEs
        frequencyInfo
                                         FrequencyInfo
                                                                              OPTIONAL,
                                         MaxAllowedUL-TX-Power
        maxAllowedUL-TX-Power
                                                                              OPTIONAL,
        ul-ChannelRequirement
                                         UL-ChannelRequirement-r5
                                                                              OPTIONAL,
        modeSpecificPhysChInfo
                                         CHOICE {
                                             SEQUENCE {
            fdd
                dl-PDSCH-Information
                                                 DL-PDSCH-Information
                                                                              OPTIONAL
            },
```

```
tdd
                                            NULL
        dl-HSPDSCH-Information DL-HSPDSCH-Information dl-CommonInformation DL-CommonInformation-r5 dl-InformationPerRL-List DL-InformationPerRL-List-r5
                                                                               OPTIONAL,
                                                                               OPTIONAL,
                                                                               OPTIONAL
}
__ ****************
-- RADIO BEARER SETUP COMPLETE
__ ***************
RadioBearerSetupComplete ::= SEQUENCE {
    -- User equipment IEs
       rrc-TransactionIdentifier RRC-TransactionIdentifier, ul-IntegProtActivationInfo IntegrityProtActivationInfo
                                                                               OPTIONAL,
        -- TABULAR: UL-TimingAdvance is applicable for TDD mode only.
    ul-TimingAdvance UL-TimingAdvance start-Value START-Value
                                                                                OPTIONAL,
        count-C-ActivationTime
        count-C-ActivationTime ActivationTime OPTIONAL, rb-UL-CiphActivationTimeInfo RB-ActivationTimeInfoList OPTIONAL, ul-CounterSynchronisationInfo UL-CounterSynchronisationInfo OPTIONAL, laterNonCriticalExtensions SEQUENCE {
            -- Container for additional R99 extensions
            radioBearerSetupComplete-r3-add-ext BIT STRING OPTIONAL,
            nonCriticalExtensions SEQUENCE {} OPTIONAL
        } OPTIONAL
}
__ ****************
-- RADIO BEARER SETUP FAILURE
__ *******************
RadioBearerSetupFailure ::= SEQUENCE {
    -- User equipment IEs
       rrc-TransactionIdentifier RRC-TransactionIdentifier, failureCause FailureCauseWithProtErr,
    -- Radio bearer IEs
        potentiallySuccesfulBearerList RB-IdentityList
                                                                               OPTIONAL,
        -- Container for additional R99 extensions
            radioBearerSetupFailure-r3-add-ext BIT STRING OPTIONAL,
            nonCriticalExtensions
                                            SEQUENCE { } OPTIONAL
        } OPTIONAL
__ ***************************
-- RRC CONNECTION REJECT
__ ***************
RRCConnectionReject ::= CHOICE {
        -- Container for additional R99 extensions
            rrcConnectionReject-r3-add-ext BIT STRING OPTIONAL, nonCriticalExtensions SEQUENCE {} OPTIONAL
        } OPTIONAL
       er-than-r3 SEQUENCE {
initialUE-Identity Initial
    later-than-r3
       initialUE-Identity InitialUE-Identity,
rrc-TransactionIdentifier RRC-TransactionIdentifier,
criticalExtensions SEQUENCE {}
}
RRCConnectionReject-r3-IEs ::= SEQUENCE {
    \mbox{--}\mbox{ TABULAR:} Integrity protection shall not be performed on this message.
    -- User equipment IEs
        initialUE-Identity InitialUE-Identity, rrc-TransactionIdentifier RRC-TransactionIdentifier, rejectionCause RejectionCause,
       initialUE-Identity
        rejectionCause
                                         RejectionCause,
```

```
waitTime
                                    WaitTime,
       redirectionInfo
                                                                     OPTIONAL
                                    RedirectionInfo
}
__ ******************
-- RRC CONNECTION RELEASE
__ ***************
RRCConnectionRelease ::= CHOICE {
       -- Container for additional R99 extensions
          rrcConnectionRelease-r3-add-ext BIT STRING OPTIONAL,
          nonCriticalExtensions SEQUENCE {} OPTIONAL
       } OPTIONAL
      later-than-r3
                  -- Container for adding non critical extensions after freezing REL-6
                 rrcConnectionRelease-r4-add-ext BIT STRING OPTIONAL, nonCriticalExtensions SEQUENCE {} OPTIONAL
                    OPTIONAL
          criticalExtensions
                                      SEQUENCE {}
       }
}
{\tt RRCConnectionRelease-r3-IEs} \; ::= \; {\tt SEQUENCE} \; \left\{ \right.
   -- User equipment IEs
      rrc-TransactionIdentifier RRC-TransactionIdentifier,
       -- n-308 is conditional on the UE state
      n-308
                                    N - 308
                                                                     OPTIONAL,
       releaseCause
                                    ReleaseCause,
       rplmn-information
                                    Rplmn-Information
                                                                     OPTIONAL
}
RRCConnectionRelease-r4-IEs ::= SEQUENCE {
    -- User equipment IEs
      -- n-308 is conditional on the UE state.
                      N-308
      n-308
                                                                     OPTIONAL.
      releaseCause
                                    ReleaseCause.
      rplmn-information
                                    Rplmn-Information-r4
                                                                    OPTIONAL
}
__ ****************
-- RRC CONNECTION RELEASE for CCCH
__ ***************
RRCConnectionRelease-CCCH ::= CHOICE {
                                SEQUENCE {
       rrcConnectionRelease-CCCH-r3 RRCConnectionRelease-CCCH-r3-IEs, laterNonCriticalExtensions SEQUENCE {
          -- Container for additional R99 extensions rrcConnectionRelease-CCCH-r3-add-ext BIT STRING OPTIONAL,
       } OPTIONAL
   later-than-r3
                               SEOUENCE {
       u-RNTI U-RNTI,
rrc-TransactionIdentifier RRC-TransactionIdentifier,
criticalExtensions CHOICE {
    r4 SEQUENCE {
              rrcConnectionRelease-CCCH-r4 RRCConnectionRelease-CCCH-r4-IEs, v4d0NonCriticalExtensions SEQUENCE {
                  -- Container for adding non critical extensions after freezing REL-5
                  rrcConnectionRelease-CCCH-r4-add-ext BIT STRING OPTIONAL, nonCriticalExtensions SEQUENCE {} OPTIONAL
              }
                     OPTIONAL
```

```
criticalExtensions
                                             SEQUENCE {
                -- TABULAR: CHOICE IdentityType (U-RNTI, GroupIdentity) is replaced with the
                -- optional element groupIdentity, since the U-RNTI is mandatory in ASN.1.
                -- In case CHOICE IdentityType is equal to GroupIdentity the value of the U-RNTI
                -- shall be ignored by a UE complying with this version of the message.
                groupIdentity SEQUENCE ( SIZE (1 .. maxURNTI-Group) ) OF
                                            GroupReleaseInformation OPTIONAL,
                criticalExtensions
                                                CHOICE {
                                                     SEQUENCE {
                        rrcConnectionRelease-CCCH-r5 RRCConnectionRelease-CCCH-r5-IEs,
                        -- Container for adding non critical extensions after freezing REL-6 rrcConnectionRelease-CCCH-r5-add-ext BIT STRING OPTIONAL
                                                        SEQUENCE {} OPTIONAL
                        nonCriticalExtensions
                    criticalExtensions
                                                    SEQUENCE {}
               }
           }
      }
   }
}
RRCConnectionRelease-CCCH-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
       11-RNTT
                                        U-RNTI,
    -- The rest of the message is identical to the one sent on DCCH.
       rrcConnectionRelease
                                        RRCConnectionRelease-r3-IEs
}
RRCConnectionRelease-CCCH-r4-IEs ::= SEQUENCE {
    -- The rest of the message is identical to the one sent on DCCH.
       rrcConnectionRelease
                                       RRCConnectionRelease-r4-IEs
}
-- The R5 and R4 sequence of IEs are identical in this message \,
RRCConnectionRelease-CCCH-r5-IEs ::= RRCConnectionRelease-CCCH-r4-IEs
__ ***************
-- RRC CONNECTION RELEASE COMPLETE
__ ****************
RRCConnectionReleaseComplete ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier RRC-TransactionIdentifier, errorIndication FailureCauseWithProtErr laterNonCriticalExtensions SEQUENCE {
       rrc-TransactionIdentifier
                                                                             OPTIONAL.
            -- Container for additional R99 extensions
            rrcConnectionReleaseComplete-r3-add-ext BIT STRING
                                           SEQUENCE {} OPTIONAL
            nonCriticalExtensions
        } OPTIONAL
}
__ ***************
-- RRC CONNECTION REQUEST
__ **************
RRCConnectionRequest ::= SEQUENCE {
    -- TABULAR: Integrity protection shall not be performed on this message.
    -- User equipment IEs
        initialUE-Identity
                                         InitialUE-Identity,
        establishmentCause
                                        EstablishmentCause,
        -- protocolErrorIndicator is MD, but for compactness reasons no default value
        -- has been assigned to it.
                                       ProtocolErrorIndicator,
        protocolErrorIndicator
    -- Measurement IEs
                                                                            OPTIONAL,
        measuredResultsOnRACH
                                       MeasuredResultsOnRACH
        Non critical Extensions
        v3d0NonCriticalExtensions
           NONONCriticalExtensions SEQUENCE {
    rRCConnectionRequest-v3d0ext RRCConnectionRequest-v3d0ext-IEs,
        -- Reserved for future non critical extension
            v4b0NonCriticalExtensions SEQUENCE {
    rrcConnectionRequest-v4b0ext RRCConnectionRequest-v4b0ext-IEs,
    v590NonCriticalExtensions SEQUENCE {
        rrcConnectionRequest-v590ext RRCConnectionRequest-v590ext-
                                                        RRCConnectionRequest-v590ext-IEs,
```

```
-- Reserved for future non critical extension
                    {\tt nonCriticalExtensions} \qquad \qquad {\tt SEQUENCE} \ \{ \} \qquad {\tt OPTIONAL}
                  OPTIONAL
               OPTIONAL
            OPTIONAL
}
RRCConnectionRequest-v3d0ext-IEs ::= SEQUENCE {
    -- User equipment IEs
       uESpecificBehaviourInformation1idle
                                               UESpecificBehaviourInformationlidle OPTIONAL
}
{\tt RRCConnectionRequest-v4b0ext-IEs} \; ::= \; \; \; {\tt SEQUENCE} \; \left\{ \right. \\
   -- User equipment IEs
       accessStratumReleaseIndicator
                                               AccessStratumReleaseIndicator
}
RRCConnectionRequest-v590ext-IEs ::= SEQUENCE {
   -- User equipment IEs
      predefinedConfigStatusInfo
                                          BOOLEAN
}
__ *********************
-- RRC CONNECTION SETUP
__ ***************
RRCConnectionSetup ::= CHOICE {
        SEQUENCE {
rrcConnectionSetup-r3
laterNorgeria
        -- Container for additional R99 extensions
           rrcConnectionSetup-r3-add-ext BIT STRING OPTIONAL, v4b0NonCriticalExtensions SEQUENCE {
               rrcConnectionSetup-v4b0ext RRCConnectionSetup-v4b0ext-IEs, v590NonCriticalExtensions SEQUENCE {
                   rrcConnectionSetup-v590ext RRCConnectionSetup-v590ext-IEs, nonCriticalExtensions SEQUENCE {} OPTIONAL
                  OPTIONAL
            } OPTIONAL
       } OPTIONAL
       er-than-r3 SEQUENCE {
initialUE-Identity Initial
    later-than-r3
       initialUE-Identity InitialUE-Identity, rrc-TransactionIdentifier RRC-TransactionIden criticalExtensions CHOICE {
                                       RRC-TransactionIdentifier,
        criticalExtensions
                rrcConnectionSetup-r4 SEQUENCE {
v4d0NonCritical
                rrcConnectionSetup-r4 RRCConnectionSetup-r4-IEs, v4d0NonCriticalExtensions SEQUENCE {
                    -- Container for adding non critical extensions after freezing REL-5
                    rrcConnectionSetup-v590ext RRCConnectionSetup-v590ext-IEs, nonCriticalExtensions SEQUENCE {} OPTIONAL
                    } OPTIONAL
                }
                   OPTIONAL
                                  CHOICE {
            criticalExtensions
                   SEQUENCE {
rrcConnectionSetup-r5 RRCConnectionSetup-r5-IEs,
                    -- Container for adding non critical extensions after freezing REL-6
                    rrcConnectionSetup-r5-add-ext BIT STRING OPTIONAL, nonCriticalExtensions SEQUENCE {} OPTIONAL
                                       SEQUENCE {}
                criticalExtensions
           }
       }
}
RRCConnectionSetup-r3-IEs ::= SEQUENCE {
    -- TABULAR: Integrity protection shall not be performed on this message.
    -- User equipment IEs
       activationTime
                                       ActivationTime
                                                                            OPTIONAL,
       new-U-RNTI
                                        U-RNTI,
```

```
new-c-RNTI
                                                              C-RNTI
                                                                                                                        OPTIONAL,
            rrc-StateIndicator
                                                              RRC-StateIndicator,
            utran-DRX-CycleLengthCoeff
                                                            UTRAN-DRX-CycleLengthCoefficient,
             -- TABULAR: If capabilityUpdateRequirement is not present, the default value
             -- defined in 10.3.3.2 shall be used.
            capabilityUpdateRequirement CapabilityUpdateRequirement
      -- Radio bearer IEs
            srb-InformationSetupList SRB-InformationSetupList2,
Fransport channel IEs
ul-CommonTransChInfo
      -- Transport channel IEs
            ul-CommonTransChInfo
                                                            UL-CommonTransChInfo
            -- NOTE: ul-AddReconfTransChInfoList should be optional in later versions of
             -- this message
            ul-AddReconfTransChInfoList
                                                              UL-AddReconfTransChInfoList,
            dl-CommonTransChInfo
                                                              DL-CommonTransChInfo
                                                                                                                        OPTIONAL,
             -- NOTE: dl-AddReconfTransChInfoList should be optional in later versions
             -- of this message
            dl-AddReconfTransChInfoList DL-AddReconfTransChInfoList,
      -- Physical channel IEs
            frequencyInfo
                                                             FrequencyInfo
            maxAllowedUL-TX-Power
ul-ChannelRequirement
                                                              MaxAllowedUL-TX-Power
                                                                                                                        OPTIONAL,
                                                              UL-ChannelRequirement
                                                                                                                       OPTIONAL,
            dl-Information DL-CommonInformation

DL-InformationPerRL-List

DL-InformationPerRL-List
                                                                                                                       OPTIONAL,
                                                              DL-InformationPerRL-List
                                                                                                                        OPTIONAL
}
RRCConnectionSetup-v4b0ext-IEs ::= SEQUENCE {
            capabilityUpdateRequirement-r4-ext CapabilityUpdateRequirement-r4-ext OPTIONAL,
      -- Physical channel IEs
            -- ssdt-UL extends SSDT-Information, which is included in
            -- DL-CommonInformation. FDD only.
            ssdt-UL-r4
                                                                      SSDT-UL
                                                                                                                               OPTIONAL,
             -- The order of the RLs in IE cell-id-PerRL-List is the same as
             -- in IE DL-InformationPerRL-List included in this message
            cell-id-PerRL-List
                                                                     CellIdentity-PerRL-List
                                                                                                                            OPTIONAL
}
RRCConnectionSetup-v590ext-IEs ::= SEQUENCE {
      -- User equipment IEs
            systemSpecificCapUpdateReq SystemSpecificCapUpdateReq-v590ext
                                                                                                                            OPTIONAL,
      -- Physical channel IEs
            dl-TPC-PowerOffsetPerRL-List DL-TPC-PowerOffsetPerRL-List
                                                                                                                      OPTIONAL
}
RRCConnectionSetup-r4-IEs ::= SEQUENCE {
      -- TABULAR: Integrity protection shall not be performed on this message.
            activationTime
                                                              ActivationTime
                                                                                                                        OPTIONAL.
                                                               U-RNTI,
            new-U-RNTI
            new-c-RNTI
                                                              C-RNTT
                                                                                                                        OPTIONAL,
            rrc-StateIndicator
                                                              RRC-StateIndicator,
            utran-DRX-CycleLengthCoeff UTRAN-DRX-CycleLengthCoefficient,
             -- TABULAR: If capabilityUpdateRequirement is not present, the default value
            -- defined in 10.3.3.2 shall be used.
            capabilityUpdateRequirement CapabilityUpdateRequirement-r4
                                                                                                                      OPTIONAL,
            capability and capabi
      -- Radio bearer IEs
                                                           SRB-InformationSetupList2,
      -- Transport channel IEs
            ul-CommonTransChInfo
                                                           UL-CommonTransChInfo-r4
                                                                                                                        OPTIONAL,
            ul-AddReconfTransChInfoList UL-AddReconfTransChInfoList
                                                                                                                       OPTIONAL,
            dl-CommonTransChInfo
                                                               DL-CommonTransChInfo-r4
                                                                                                                        OPTIONAL,
            dl-AddReconfTransChInfoList DL-AddReconfTransChInfoList-r4
                                                                                                                       OPTIONAL.
      -- Physical channel IEs
            frequencyInfo
                                                              FrequencyInfo
                                                                                                                        OPTIONAL,
                                                           MaxAllowedUL-TX-Power
UL-ChannelRequirement-
            maxAllowedUL-TX-Power
                                                                                                                       OPTIONAL,
            ul-ChannelRequirement
dl-CommonInformation
                                                              UL-ChannelRequirement-r4
                                                                                                                        OPTIONAL,
                                                             DL-CommonInformation-r4
                                                                                                                        OPTIONAL.
            dl-InformationPerRL-List
                                                           DL-InformationPerRL-List-r4
                                                                                                                        OPTIONAL
}
RRCConnectionSetup-r5-IEs ::= SEQUENCE {
      -- TABULAR: Integrity protection shall not be performed on this message.
            activationTime
                                                              ActivationTime
                                                                                                                         OPTIONAL,
            new-U-RNTI
                                                               U-RNTI,
            new-c-RNTI
                                                              C-RNTI
                                                                                                                        OPTIONAL,
            -- TABULAR: If capabilityUpdateRequirement is not present, the default value
             -- defined in 10.3.3.2 shall be used.
                                                             CapabilityUpdateRequirement-r5
            capabilityUpdateRequirement
                                                                                                                      OPTIONAL,
```

```
-- Specification mode information
                                    CHOICE {
       specificationMode
           complete
                                       SEQUENCE {
               -- Radio bearer IEs
               srb-InformationSetupList
                                            SRB-InformationSetupList2,
               -- Transport channel IEs
               ul-CommonTransChInfo
                                            UL-CommonTransChInfo-r4
                                                                              OPTIONAL.
              ul-AddReconfTransChInfoList UL-AddReconfTransChInfoList
                                                                           OPTIONAL,
               dl-CommonTransChInfo
                                            DL-CommonTransChInfo-r4
                                                                              OPTIONAL,
              dl-AddReconfTransChInfoList
                                            DL-AddReconfTransChInfoList-r4
                                                                              OPTIONAL
           },
           preconfiguration
                                        SEQUENCE {
               -- All IEs that include an FDD/TDD choice are split in two IEs for this message,
               -- one for the FDD only elements and one for the TDD only elements, so that one
               -- FDD/TDD choice in this level is sufficient.
               preConfiqMode
                                           CHOICE {
                                            PredefinedConfigIdentity,
                  predefinedConfigIdentity
                     defaultConfigIdentity

DefaultConfigMode,

DefaultConfigTal
                                               SEQUENCE {
                  defaultConfig
                     defaultConfigMode
                                                   DefaultConfigIdentity-r5
                  }
               }
           }
       }.
   -- Physical channel IEs
                                   FrequencyInfo
       frequencyInfo
                                                                      OPTIONAL,
                                   MaxAllowedUL-TX-Power
       maxAllowedUL-TX-Power
       ul-ChannelRequirement
                                    UL-ChannelRequirement-r4
                                                                      OPTIONAL,
       dl-CommonInformation
                                    DL-CommonInformation-r4
                                                                      OPTIONAL.
       dl-InformationPerRL-List
                                    DL-InformationPerRL-List-r5bis
                                                                     OPTIONAL
}
  ************
-- RRC CONNECTION SETUP COMPLETE
__ ****************
RRCConnectionSetupComplete ::= SEQUENCE {
   -- TABULAR: Integrity protection shall not be performed on this message.
   -- User equipment IEs
                                    RRC-TransactionIdentifier,
       rrc-TransactionIdentifier
       startList
                                    STARTList,
       ue-RadioAccessCapability
                                    UE-RadioAccessCapability
                                                                     OPTIONAL,
   -- Other IEs
                                    InterRAT-UE-RadioAccessCapabilityList OPTIONAL,
       ue-RATSpecificCapability
   -- Non critical extensions
       v370NonCriticalExtensions
                                       SEQUENCE {
           rrcConnectionSetupComplete-v370ext RRCConnectionSetupComplete-v370ext,
                                            SEQUENCE {
           v380NonCriticalExtensions
               \verb|rrcConnectionSetupComplete-v380ext-IEs|, \\
               -- Reserved for future non critical extension
               v3a0NonCriticalExtensions
                                              SEQUENCE {
                  \verb|rrcConnectionSetupComplete-v3a0ext| RRCConnectionSetupComplete-v3a0ext-IEs|,
                  laterNonCriticalExtensions
                                                   SEOUENCE {
                      -- Container for additional R99 extensions
                      rrcConnectionSetupComplete-r3-add-ext
                                                              BIT STRING
                                                                             OPTIONAL,
                                               SEQUENCE {
                      v3g0NonCriticalExtensions
                          \verb|rrcConnectionSetupComplete-v3g0ext-IEs|, \\
                          v4b0NonCriticalExtensions
                                                           SEQUENCE {
                             {\tt rrcConnectionSetupComplete-v4b0ext}
                                                       RRCConnectionSetupComplete-v4b0ext-IEs,
                             v590NonCriticalExtensions
                                                              SEQUENCE {
                                 {\tt rrcConnectionSetupComplete-v590ext}
                                                           RRCConnectionSetupComplete-v590ext-IEs,
                                 nonCriticalExtensions
                                                                  SEQUENCE { } OPTIONAL
                             }
                                    OPTIONAL
                                 OPTIONAL
                             OPTIONAL
                          OPTIONAL
                      OPTIONAL
           }
                  OPTIONAL
              OPTIONAL
}
RRCConnectionSetupComplete-v370ext ::= SEQUENCE {
   -- User equipment IEs
       ue-RadioAccessCapability-v370ext UE-RadioAccessCapability-v370ext OPTIONAL
```

```
}
RRCConnectionSetupComplete-v380ext-IEs ::= SEQUENCE {
   -- User equipment IEs

    ue-RadioAccessCapability-v380ext
    UE-RadioAccessCapability-v380ext

    dl-PhysChCapabilityFDD-v380ext
    DL-PhysChCapabilityFDD-v380ext

                                                                            OPTIONAL,
}
{\tt RRCConnectionSetupComplete-v3a0ext-IEs} \; ::= \; {\tt SEQUENCE} \; \left\{ \right. \\
   -- User equipment IEs
      ue-RadioAccessCapability-v3a0ext UE-RadioAccessCapability-v3a0ext OPTIONAL
}
RRCConnectionSetupComplete-v3g0ext-IEs ::= SEQUENCE {
   -- User equipment IEs
      ue-RadioAccessCapability-v3g0ext UE-RadioAccessCapability-v3g0ext OPTIONAL
}
RRCConnectionSetupComplete-v4b0ext-IEs ::= SEQUENCE {
   -- User equipment IEs
                                          UE-RadioAccessCapability-v4b0ext
      ue-RadioAccessCapability-v4b0ext
                                                                               OPTIONAL
}
RRCConnectionSetupComplete-v590ext-IEs ::= SEQUENCE {
   -- User equipment IEs
      ue-RadioAccessCapability-v590ext
                                          UE-RadioAccessCapability-v590ext
                                                                               OPTIONAL,
   -- Other IEs
      ue-RATSpecificCapability-v590ext InterRAT-UE-RadioAccessCapability-v590ext OPTIONAL
}
__ ***************
-- RRC FAILURE INFO
__ *************************
RRC-FailureInfo ::= CHOICE {
                                            SEQUENCE {
  r3
       rRC-FailureInfo-r3
                                               RRC-FailureInfo-r3-IEs,
       laterNonCriticalExtensions SEQUENCE {
            -- Container for additional R99 extensions
          rrc-FailureInfo-r3-add-ext BIT STRING
                                                      OPTIONAL.
          nonCriticalExtensions
                                                  SEQUENCE {} OPTIONAL
         OPTIONAL
   criticalExtensions
                                            SEQUENCE {}
}
RRC-FailureInfo-r3-IEs ::= SEQUENCE {
  -- Non-RRC IEs
      failureCauseWithProtErr
                                                   FailureCauseWithProtErr
}
__ ****************************
-- RRC STATUS
__ ****************
RRCStatus ::= SEQUENCE {
   -- Other IEs
       -- TABULAR: Identification of received message is nested in
       -- ProtocolErrorMoreInformation
       -- Container for additional R99 extensions
          rrcStatus-r3-add-ext BIT STRING OPTIONAL, nonCriticalExtensions SEQUENCE {} OPTIO
                                       SEQUENCE {} OPTIONAL
       } OPTIONAL
}
__ *******************
-- SECURITY MODE COMMAND
__ ***************
SecurityModeCommand ::= CHOICE {
```

```
SEQUENCE {
securityModeCommand-r3
laterNonCode()
        securityModeCommand-r3 SecurityModeCommand-r3-IEs, laterNonCriticalExtensions SEQUENCE {
            -- Container for additional R99 extensions
            securityModeCommand-r3-add-ext BIT STRING OPTIONAL, nonCriticalExtensions SEQUENCE {} OPTIONAL
        } OPTIONAL
       er-than-r3 SEQUENCE {
    rrc-TransactionIdentifier RRC-TransactionIdentifier,
    criticalExtensions SEQUENCE {}
    later-than-r3
        criticalExtensions
}
SecurityModeCommand-r3-IEs ::= SEQUENCE {
-- TABULAR: Integrity protection shall always be performed on this message.
    -- User equipment IEs
       rrc-TransactionIdentifier RRC-TransactionIdentifier,
securityCapability SecurityCapability,
cipheringModeInfo CipheringModeInfo OPTIONAL,
integrityProtectionModeInfo IntegrityProtectionModeInfo OPTIONAL,
    -- Core network IEs
        cn-DomainIdentity
                                          CN-DomainIdentity,
    -- Other IEs
        ue-SystemSpecificSecurityCap InterRAT-UE-SecurityCapList
                                                                                OPTIONAL
}
__ **************
-- SECURITY MODE COMPLETE
__ ***************
SecurityModeComplete ::= SEQUENCE {
-- TABULAR: Integrity protection shall always be performed on this message.
    -- User equipment IEs
        rrc-TransactionIdentifier RRC-TransactionIdentifier, ul-IntegProtActivationInfo IntegrityProtActivationInfo
                                                                                OPTIONAL,
    -- Radio bearer IEs
        rb-UL-CiphActivationTimeInfo RB-ActivationTimeInfoList laterNonCriticalExtensions SEQUENCE {
                                                                                 OPTIONAL,
             -- Container for additional R99 extensions
             securityModeComplete-r3-add-ext BIT STRING OPTIONAL,
            OPTIONAL
}
__ *******************************
-- SECURITY MODE FAILURE
__ ****************
SecurityModeFailure ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier RRC-TransactionIdentifier, failureCause FailureCauseWithProtErr, laterNonCriticalExtensions SEQUENCE {
            -- Container for additional R99 extensions
            securityModeFailure-r3-add-ext BIT STRING OPTIONAL, nonCriticalExtensions SEQUENCE {} OPTIONAL
        } OPTIONAL
}
__ ***************
-- SIGNALLING CONNECTION RELEASE
__ ****************
SignallingConnectionRelease ::= CHOICE {
                                   SEQUENCE {
        signallingConnectionRelease-r3 SignallingConnectionRelease-r3-IEs,
laterNonCriticalExtensions SEQUENCE {
            -- Container for additional R99 extensions
             signallingConnectionRelease-r3-add-ext BIT STRING
                                                                            OPTIONAL.
                                               SEQUENCE {} OPTIONAL
            nonCriticalExtensions
```

```
} OPTIONAL
        later-than-r3
                                                        SEQUENCE {
              rrc-TransactionIdentifier RRC-TransactionIdentifier,
               criticalExtensions
                                                                             SEQUENCE {}
}
SignallingConnectionRelease-r3-IEs ::= SEQUENCE {
       -- User equipment IEs
             rrc-TransactionIdentifier RRC-TransactionIdentifier,
        -- Core network IEs
              cn-DomainIdentity
                                                                            CN-DomainIdentity
__ **************
-- SIGNALLING CONNECTION RELEASE INDICATION
__ ******************
SignallingConnectionReleaseIndication ::= SEQUENCE {
        -- Core network IEs
               -- Container for additional R99 extensions
                       signallingConnectionReleaseIndication-r3-add-ext BIT STRING OPTIONAL,
                       } OPTIONAL
}
__ ***************
-- SYSTEM INFORMATION for BCH
__ ***************
SystemInformation-BCH ::= SEQUENCE {
        -- Other information elements
               sfn-Prime
                                                                          SFN-Prime,
               payload
                                                                             CHOICE {
                                                                                   NULL,
                       noSegment
                                                                                      FirstSegment,
                       firstSegment
                       subsequentSegment SubsequentSegment, lastSegmentShort LastSegment SequentSegment LastSegment SequentSegmentShort LastSegmentShort LastSegmentS
                                                                                      LastSegmentShort,
                                                                                     .
LastSegmentShort,
                               firstSegment
                                                                                           FirstSegmentShort
                              lastSegmentShort LastSegcompleteSIB-List
                        lastAndComplete
                                                                                      LastSegmentShort,
                                                                                            CompleteSIB-List
                       lastAndCompleteAndFirst SEQUENCE {
   lastSegmentShort LastSeg
   completeSIB-List Complete
                                                                                      LastSegmentShort,
                                                                                              CompleteSIB-List,
                               firstSegment
                                                                                             FirstSegmentShort
                                                                           CompleteSIB-List,
                              pleteSIB-List
pleteAndFirst
completeSIB-List
                       completeSIB-List
                                                                                     SEQUENCE {
                        completeAndFirst
                                                                                            CompleteSIB-List,
                               firstSegment
                                                                                              FirstSegmentShort
                       completeSIB
                                                                                      CompleteSIB,
                       lastSegment
                                                                                      LastSegment,
                       spare5
                                                                                      NULL,
                       spare4
                                                                                      NULL,
                                                                                      NULL,
                       spare3
                       spare2
                                                                                      NULL.
                       spare1
                                                                                      NULL
}
__ ****************
-- SYSTEM INFORMATION for FACH
```

```
SystemInformation-FACH ::= SEQUENCE {
   -- Other information elements
                                      CHOICE {
       payload
           noSegment
                                         NULL,
           firstSegment
                                          FirstSegment,
           subsequentSegment
lastSegmentShort
                                         SubsequentSegment,
LastSegmentShort,
                                         SEQUENCE {
           lastAndFirst
               lastSegmentShort
                                         LastSegmentShort,
FirstSegmentShort
               firstSegment
              lastSegmentShort LastSectompleteSIB-List
           lastAndComplete
                                            LastSegmentShort,
                                             CompleteSIB-List
           lastAndCompleteAndFirst SEQUENCE {
   lastSegmentShort LastSeg
   completeSIB-List Complet
   firstSegment
                                         LastSegmentShort,
                                             CompleteSIB-List,
              rirstSegmentS

CompleteSIB-List,
mpleteAndFirst SEQUENCE {
   completeSIB-List CompleteSIB-List
   firstSegment

pleteST-
                                             FirstSegmentShort
           },
           completeSIB-List
           completeAndFirst
                                             CompleteSIB-List,
                                              FirstSegmentShort
                                       CompleteSIB,
           completeSIB
           lastSegment
                                          LastSegment,
           spare5
                                          NULL,
           spare4
                                          NULL,
           spare3
                                          NULL,
                                          NULL,
           spare2
           spare1
                                          NULL
}
__ ***************
-- First segment
__ *****************
                                 SEQUENCE {
FirstSegment ::=
   -- Other information elements
                                 SIB-Type,
      sib-Type
       seg-Count
                                      SegCount,
       sib-Data-fixed
                                      SIB-Data-fixed
}
__ ***************
-- First segment (short)
__ ****************************
   stSegmentShort ::=
-- Other information elements
sib-Type SIB-Type,
SegCount,
SIB-Data-variable
FirstSegmentShort ::=
}
__ ***************
-- Subsequent segment
__ ****************
SubsequentSegment ::=
                                  SEQUENCE {
   -- Other information elements
      sib-Type
       segmentIndex
                                      SegmentIndex,
                                    SIB-Data-fixed
       sib-Data-fixed
}
__ ****************
-- Last segment
```

```
__ *******************************
LastSegment ::=
                              SEQUENCE {
   -- Other information elements
      sib-Type
                                SIB-Type,
      segment.Index
                                 SegmentIndex,
       -- For sib-Data-fixed, in case the SIB data is less than 222 bits, padding
       -- shall be used. The same padding bits shall be used as defined in clause 12.1
      sib-Data-fixed
                                 SIB-Data-fixed
}
                                    SEQUENCE {
LastSegmentShort ::=
   -- Other information elements
      sib-Type
                                 SIB-Type,
      segmentIndex
                                 SegmentIndex,
      sib-Data-variable
                                 SIB-Data-variable
}
__ ***************
-- Complete SIB
__ ***************
                              SEQUENCE (SIZE (1..maxSIBperMsg)) OF
CompleteSIB-List ::=
                                 CompleteSIBshort
CompleteSIB ::=
                              SEQUENCE {
   -- Other information elements
                                  SIB-Type,
      sib-Type
       -- For sib-Data-fixed, in case the SIB data is less than 226 bits, padding
       -- shall be used. The same padding bits shall be used as defined in clause 12.1
                                 BIT STRING (SIZE (226))
      sib-Data-fixed
}
CompleteSIBshort ::=
                                    SEQUENCE {
  -- Other information elements
sib-Type SIB-Type,
      sib-Data-variable
                                 SIB-Data-variable
}
__ ***************
-- SYSTEM INFORMATION CHANGE INDICATION
__ *******************
SystemInformationChangeIndication ::= SEQUENCE {
   -- Other IEs
      laterNonCriticalExtensions
                                     BCCH-ModificationInfo,
                                     SEQUENCE {
          -- Container for additional R99 extensions
          systemInformationChangeIndication-r3-add-ext BIT STRING OPTIONAL, nonCriticalExtensions SEQUENCE {} OPTIONAL
          nonCriticalExtensions
       } OPTIONAL
}
__ **************
-- TRANSPORT CHANNEL RECONFIGURATION
__ *******************
TransportChannelReconfiguration ::= CHOICE {
                              SEQUENCE {
      transportChannelReconfiguration-r3
      transportChannelReconfiguration-v3a0ext
                                  TransportChannelReconfiguration-v3a0ext,
          laterNonCriticalExtensions
                                        SEQUENCE {
             -- Container for additional R99 extensions
             transportChannelReconfiguration-r3-add-ext BIT STRING OPTIONAL,
             v4b0NonCriticalExtensions SEQUENCE {
                 transportChannelReconfiguration-v4b0ext
                                         TransportChannelReconfiguration-v4b0ext-IEs,
SEQUENCE {
                 v590NonCriticalExtensions
```

```
{\tt transportChannelReconfiguration-v590ext}
                                                         TransportChannelReconfiguration-v590ext-IEs,
                        nonCriticalExtensions
                                                        SEQUENCE {}
                                                                         OPTIONAL
                           OPTIONAL
                        OPTIONAL
                    OPTIONAL
                OPTIONAL
    later-than-r3
                                    SEQUENCE {
        rrc-TransactionIdentifier
                                        RRC-TransactionIdentifier,
        criticalExtensions
                                         CHOICE {
            r4
                                             SEQUENCE {
                transportChannelReconfiguration-r4
                                                 TransportChannelReconfiguration-r4-IEs,
                                                    SEQUENCE {
                v4d0NonCriticalExtensions
                    -- Container for adding non critical extensions after freezing REL-5
                    transportChannelReconfiguration-r4-add-ext
                                                                  BIT STRING
                                                                                     OPTIONAL,
                                                     SEQUENCE {
                    v590NonCriticalExtensions
                        {\tt transportChannelReconfiguration-v590ext}
                                                    {\tt TransportChannelReconfiguration-v590ext-IEs,}
                        {\tt nonCriticalExtensions}
                                                        SEQUENCE {}
                                                                        OPTIONAL
                        OPTIONAL
                    OPTIONAL
                }
            criticalExtensions
                                             CHOICE {
                                                SEQUENCE {
                r5
                    transportChannelReconfiguration-r5
                                                     TransportChannelReconfiguration-r5-IEs,
                    -- Container for adding non critical extensions after freezing REL-6
                    transportChannelReconfiguration-r5-add-ext
                                                                    BIT STRING
                                                                                     OPTIONAL,
                    nonCriticalExtensions
                                                    SEQUENCE {}
                                                                     OPTIONAL
                },
                                                SEQUENCE {}
                criticalExtensions
            }
        }
    }
}
TransportChannelReconfiguration-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
       rrc-TransactionIdentifier
                                        RRC-TransactionIdentifier,
        integrityProtectionModeInfo
                                        IntegrityProtectionModeInfo
                                                                             OPTIONAL.
        cipheringModeInfo
                                        CipheringModeInfo
                                                                             OPTIONAL,
                                        ActivationTime
        activationTime
                                                                             OPTIONAL,
       new-U-RNTI
                                        U-RNTI
                                                                             OPTIONAL,
        new-C-RNTI
                                        C-RNTI
                                                                             OPTIONAL.
        rrc-StateIndicator
                                        RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff
                                        UTRAN-DRX-CycleLengthCoefficient
    -- Core network IEs
       cn-InformationInfo
                                        CN-InformationInfo
                                                                             OPTIONAL,
    -- UTRAN mobility IEs
       ura-Identity
                                        URA-Identity
                                                                             OPTIONAL,
    -- Radio bearer IEs
        dl-CounterSynchronisationInfo DL-CounterSynchronisationInfo
                                                                             OPTIONAL.
    -- Transport channel IEs
                                                                             OPTIONAL,
        ul-CommonTransChInfo
                                        UL-CommonTransChInfo
        ul-AddReconfTransChInfoList
                                        UL-AddReconfTransChInfoList
                                                                             OPTIONAL,
        modeSpecificTransChInfo
                                        CHOICE {
                                             SECUENCE {
            fdd
                cpch-SetID
                                                 CPCH-Set ID
                                                                             OPTIONAL.
                addReconfTransChDRAC-Info
                                                 DRAC-StaticInformationList OPTIONAL
            },
            tdd
                                            NULL
                                                                             OPTIONAL.
        dl-CommonTransChInfo
                                        DL-CommonTransChInfo
                                                                             OPTIONAL,
        dl-AddReconfTransChInfoList
                                        DL-AddReconfTransChInfoList
                                                                             OPTIONAL,
    -- Physical channel IEs
                                                                             OPTIONAL,
       frequencyInfo
                                        FrequencyInfo
        maxAllowedUL-TX-Power
                                        MaxAllowedUL-TX-Power
                                                                             OPTIONAL,
                                        UL-ChannelRequirement
        ul-ChannelRequirement
                                                                             OPTIONAL,
        modeSpecificPhysChInfo
                                        CHOICE {
                                             SECTIENCE {
            fdd
                dl-PDSCH-Information
                                                DL-PDSCH-Information
                                                                             OPTIONAL
            },
            tdd
                                        NULL
        dl-CommonInformation
                                        DL-CommonInformation
                                                                             OPTIONAL.
        dl-InformationPerRL-List
                                        DL-InformationPerRL-List
                                                                             OPTIONAL
```

```
}
TransportChannelReconfiguration-v3a0ext ::= SEQUENCE {
                                                                            OPTIONAL
    new-DSCH-RNTI
                                     DSCH-RNTI
TransportChannelReconfiguration-v4b0ext-IEs ::= SEQUENCE {
    -- Physical channel IEs
        -- ssdt-UL extends SSDT-Information, which is included in
        -- DL-CommonInformation. FDD only.
        ssdt-UL-r4
                                              SSDT-UL
                                                                                   OPTIONAL,
        -- The order of the RLs in IE cell-id-PerRL-List is the same as
        -- in IE DL-InformationPerRL-List included in this message
        cell-id-PerRL-List
                                              CellIdentity-PerRL-List
                                                                                   OPTIONAL
}
TransportChannelReconfiguration-v590ext-IEs ::= SEQUENCE {
    -- Physical channel IEs
        dl-TPC-PowerOffsetPerRL-List DL-TPC-PowerOffsetPerRL-List OPTIONAL
}
{\tt TransportChannelReconfiguration-r4-IEs} \; ::= \; {\tt SEQUENCE} \; \left\{ \right.
     -- User equipment IEs
        integrityProtectionModeInfo IntegrityProtectionModeInfo cipheringModeInfo CipheringModeInfo
                                                                              OPTIONAL.
        cipheringModeInfo
                                         CipheringModeInfo
                                                                                OPTIONAL.
        activationTime
                                         ActivationTime
                                                                                OPTIONAL,
        new-U-RNTI
                                         U-RNTI
                                                                                OPTIONAL,
        new-C-RNTI
                                          C-RNTI
                                                                                OPTIONAL,
        new-DSCH-RNTI
                                         DSCH-RNTI
                                                                                OPTIONAL,
        utran-DRX-CycleLengthCoeff UTRAN-DRX-CycleLengthCoeff UTRAN-DRX-CycleLengthCoeff
                                         UTRAN-DRX-CycleLengthCoefficient
                                                                               OPTIONAL,
    -- Core network IEs
        cn-InformationInfo
                                         CN-InformationInfo
                                                                                OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity
                                        URA-Identity
                                                                                OPTIONAL.
    -- Radio bearer IEs
        dl-CounterSynchronisationInfo DL-CounterSynchronisationInfo
                                                                               OPTIONAL,
    -- Transport channel IEs
        Transport channel IES
ul-CommonTransChInfo UL-CommonTransChInfo-r4
ul-AddReconfTransChInfoList UL-AddReconfTransChInfoList
                                                                                OPTIONAL,
        ul-AddReconITranschinfo
                                                                              OPTIONAL,
                                         CHOICE {
                                            SEQUENCE {
                cpch-SetID
                                                  CPCH-Set.ID
                                                                                OPTIONAL.
                 addReconfTransChDRAC-Info
                                                  DRAC-StaticInformationList OPTIONAL
            },
            tdd
                                              NULL
                                                                                OPTIONAL.
        dl-CommonTransChInfo DL-CommonTransChInfo-r4
dl-AddReconfTransChInfoList DL-AddReconfTransChInfoList-r4
                                                                                OPTIONAL,
    dl-AddReconiliano---
-- Physical channel IEs
                                                                                OPTIONAL,
                                         FrequencyInfo
                                                                                OPTIONAL,
        frequencyInfo FrequencyInfo
maxAllowedUL-TX-Power
ul-ChannelRequirement UL-ChannelRequirement-r4
modeSpecificPhysChInfo CHOICE {
                                                                                OPTIONAL,
                                                                                OPTIONAL,
                                         SEQUENCE {
            fdd
                                                  DL-PDSCH-Information
                dl-PDSCH-Information
                                                                               OPTIONAL
            tdd
                                        NULL
        dl-CommonInformation DL-CommonInformation-r4
dl-InformationPerRL-List DL-InformationPerRL-List-r4
                                                                                OPTIONAL.
                                                                               OPTIONAL
}
TransportChannelReconfiguration-r5-IEs ::= SEQUENCE {
    -- User equipment IEs
        OPTIONAL.
        cipheringModeInfo
                                          CipheringModeInfo
                                                                                OPTIONAL,
                                         ActivationTime
                                                                                OPTIONAL,
        activationTime
        new-U-RNTI
                                         U-RNTI
                                                                                OPTIONAL,
        new-C-RNTI
                                          C-RNTI
                                                                                OPTIONAL,
        new-DSCH-RNTI
                                         DSCH-RNTI
                                                                                OPTIONAL,
        new-H-RNTT
                                         H-RNTT
                                                                                OPTIONAL.
        rrc-StateIndicator
                                         RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff UTRAN-DRX-CycleLengthCoefficient OPTIONAL,
    -- Core network IEs
        cn-InformationInfo
                                        CN-InformationInfo
                                                                                OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity
                                          URA-Identity
                                                                                OPTIONAL,
```

```
-- Radio bearer IEs
    dl-CounterSynchronisation:---
Transport channel IES
ul-CommonTransChInfo
ul-AddReconfTransChInfoList
modeSpecificTransChInfo
fdd

fdd

GPCH-SetID
        dl-CounterSynchronisationInfo DL-CounterSynchronisationInfo-r5 OPTIONAL,
                                           UL-CommonTransChInfo-r4 OPTIONAL, UL-AddReconfTransChInfoList OPTIONAL,
                 cpch-SetID
                                                                                   OPTIONAL.
                 addReconfTransChDRAC-Info
                                                     DRAC-StaticInformationList OPTIONAL
             },
             tdd
                                                NULL
                                                                                   OPTIONAL.
        dl-CommonTransChInfo DL-CommonTransChInfo-r4 OPTIONAL, dl-AddReconfTransChInfoList DL-AddReconfTransChInfoList-r5 OPTIONAL,
        rrequencyInfo FrequencyInfo OPTIONAL,
maxAllowedUL-TX-Power MaxAllowedUL-TX-Power OPTIONAL,
ul-ChannelRequirement UL-ChannelRequirement-r5 OPTIONAL,
modeSpecificPhysChInfo CHOICE {
fdd SEOUENGE '
    -- Physical channel IEs
                                           SEQUENCE {
                 dl-PDSCH-Information
                                                    DL-PDSCH-Information
                                                                                  OPTIONAL
             tdd
                                           NULL
        dl-HSPDSCH-Information DL-HSPDSCH-Information dl-CommonInformation DL-CommonInformation-r5 dl-InformationPerRL-List DL-InformationPerRL-List-r5
                                                                                  OPTIONAL,
                                                                                   OPTIONAL,
}
************
-- TRANSPORT CHANNEL RECONFIGURATION COMPLETE
__ ***************
TransportChannelReconfigurationComplete ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier RRC-TransactionIdentifier,
ul-IntegProtActivationInfo IntegrityProtActivationInfo
                                                                                  OPTIONAL,
         -- TABULAR: UL-TimingAdvance is applicable for TDD mode only.
                                  UL-TimingAdvance
        ul-TimingAdvance
                                                                                   OPTIONAL,
        count-C-ActivationTime ActivationTime OPTIONAL, rb-UL-CiphActivationTimeInfo RB-ActivationTimeInfoList OPTIONAL, ul-CounterSynchronisationInfo laterNonCriticalExtensions SEQUENCE {
    -- Radio bearer IEs
             -- Container for additional R99 extensions
             transportChannelReconfigurationComplete-r3-add-ext BIT STRING OPTIONAL,
             nonCriticalExtensions
                                         SEQUENCE { } OPTIONAL
         } OPTIONAL
}
__ ****************************
-- TRANSPORT CHANNEL RECONFIGURATION FAILURE
__ ******************
TransportChannelReconfigurationFailure ::= SEQUENCE {
    -- User equipment IEs
        Jser equipment IEs
rrc-TransactionIdentifier
failureCause
laterNonCriticalExtensions
RRC-TransactionIdentifier,
FailureCauseWithProtErr,
SEQUENCE {
             -- Container for additional R99 extensions
             transportChannelReconfigurationFailure-r3-add-ext BIT STRING OPTIONAL,
            } OPTIONAL
}
__ **********************
-- TRANSPORT FORMAT COMBINATION CONTROL in AM or IIM RLC mode
__ *******************
TransportFormatCombinationControl ::= SEQUENCE {
        -- rrc-TransactionIdentifier is always included in this version of the specification
        rrc-TransactionIdentifier RRC-TransactionIdentifier
                                                                                   OPTIONAL.
```

```
modeSpecificInfo
                                          CHOICE {
           fdd
                                                NULL,
           tdd
                                                SEQUENCE {
                                                    TFCS-Identity OPTIONAL
               tfcs-TD
       dpch-TFCS-InUplink TFC-Subset,
activationTimeForTFCSubset ActivationTime
tfc-ControlDuration TFC-ControlDuration
laterNonCriticalExtensions SEQUENCE {
                                                                               OPTIONAL.
                                                                               OPTIONAL,
           -- Container for additional R99 extensions
                                               3-add-ext BIT STRING OPTIONAL, SEQUENCE {} OPTIONAL
            transportFormatCombinationControl-r3-add-ext
               nonCriticalExtensions
           OPTIONAL
}
__ ***************
-- TRANSPORT FORMAT COMBINATION CONTROL FAILURE
__ ***************
TransportFormatCombinationControlFailure ::= SEQUENCE {
       rrc-TransactionIdentifier RRC-TransactionIdentifier, failureCause laterNonCriticalExtensions SEQUENCE {
    -- User equipment IEs
            -- Container for additional R99 extensions
           transportFormatCombinationControlFailure-r3-add-ext BIT STRING OPTIONAL,
                                          SEQUENCE {} OPTIONAL
           nonCriticalExtensions
          OPTIONAL
__ ****************
-- UE CAPABILITY ENQUIRY
__ ***************
UECapabilityEnquiry ::= CHOICE {
       SEQUENCE {

ueCapabilityEnquiry-r3 UECapabilityEnquiry-r3-IEs,
laterNonCriticalExtensions SEQUENCE {
            -- Container for additional R99 extensions
           ueCapabilityEnquiry-v4b0ext UECapabilityEnquiry-v4b0ext-IEs, v590NonCriticalExtensions SEQUENCE {
                                                SEQUENCE {
UECapabilityEnquiry-v590ext-IEs,
SEQUENCE {}
OPTIONAL
                   ueCapabilityEnquiry-v590ext
                   nonCriticalExtensions
                                      OPTIONAL
                   OPTIONAL
           OPTIONAL
                          SEQUENCE {
    later-than-r3
       rrc-TransactionIdentifier RRC-TransactionIdentifier,
        criticalExtensions
                                       SEQUENCE {}
}
UECapabilityEnquiry-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
      User equipment IEs
rrc-TransactionIdentifier RRC-TransactionIdentifier,
capabilityUpdateRequirement CapabilityUpdateRequirement
}
UECapabilityEnquiry-v4b0ext-IEs ::= SEQUENCE {
      capabilityUpdateRequirement-r4-ext CapabilityUpdateRequirement-r4-ext
}
UECapabilityEnquiry-v590ext-IEs ::= SEQUENCE {
       systemSpecificCapUpdateReq SystemSpecificCapUpdateReq-v590ext
__ *****************
-- UE CAPABILITY INFORMATION
```

__ ***************

```
UECapabilityInformation ::= SEQUENCE {
        -- User equipment IEs
                                                               RRC-TransactionIdentifier
UE-RadioAccessCapability
              rrc-TransactionIdentifier
                                                                                                                                          OPTIONAL,
              ue-RadioAccessCapability
                                                                                                                                        OPTIONAL,
       -- Other IEs
              ue-RATSpecificCapability
                                                                      InterRAT-UE-RadioAccessCapabilityList
       OPTIONAL,
              v370NonCriticalExtensions
                                                                                SEQUENCE {
                     ueCapabilityInformation-v370ext UECapabilityInformation-v370ext,
                      v380NonCriticalExtensions SEQUENCE {
                             ueCapabilityInformation-v380ext
v3a0NonCriticalExtensions
UECapabilityInformation-v380ext-IEs,
v3a0NonCriticalExtensions
                                    ueCapabilityInformation-v3a0ext UECapabilityInformation-v3a0ext-IEs, laterNonCriticalExtensions SEQUENCE {
                                            -- Container for additional R99 extensions
                                           ueCapabilityInformation-r3-add-ext BIT STRING OPTIONAL,
                                            -- Reserved for future non critical extension
                                            v4b0NonCriticalExtensions
                                                                                                      SEQUENCE {
                                                   ueCapabilityInformation-v4b0ext UECapabilityInformation-v4b0ext, v590NonCriticalExtensions SEQUENCE {
                                                          ueCapabilityInformation-v590ext UECapabilityInformation-v590ext,
                                                         nonCriticalExtensions
                                                                                                                           SEQUENCE {} OPTIONAL
                                                                OPTIONAL
                                                         OPTIONAL
                                                   OPTIONAL
                                           OPTIONAL
                     }
                                    OPTIONAL
                             OPTIONAL
}
UECapabilityInformation-v370ext ::= SEQUENCE {
       -- User equipment IEs
                                                                                                                                                             OPTIONAL
              ue-RadioAccessCapability-v370ext UE-RadioAccessCapability-v370ext
}
UECapabilityInformation-v380ext-IEs ::= SEQUENCE {
       -- User equipment IEs
                                                                                UE-RadioAccessCapability-v380ext
              ue-RadioAccessCapability-v380ext
                                                                                                                                                               OPTIONAL,
              dl-PhysChCapabilityFDD-v380ext
                                                                                       DL-PhysChCapabilityFDD-v380ext
}
UECapabilityInformation-v3a0ext-IEs ::= SEQUENCE {
       -- User equipment IEs
              ue-RadioAccessCapability-v3a0ext
                                                                                    UE-RadioAccessCapability-v3a0ext
                                                                                                                                                                OPTIONAL
}
UECapabilityInformation-v4b0ext ::= SEQUENCE {
      -- User equipment IEs
              ue-RadioAccessCapability-v4b0ext
                                                                                       UE-RadioAccessCapability-v4b0ext
                                                                                                                                                                OPTIONAL
}
UECapabilityInformation-v590ext ::= SEQUENCE {
       -- User equipment IEs
              ue-RadioAccessCapability-v3g0ext
                                                                                       UE-RadioAccessCapability-v3q0ext
                                                                                                                                                                OPTIONAL.
              ue-RadioAccessCapability-v590ext
                                                                                       UE-RadioAccessCapability-v590ext
                                                                                                                                                                 OPTIONAL,
       -- Other IEs
             ue-RATSpecificCapability-v590ext InterRAT-UE-RadioAccessCapability-v590ext OPTIONAL
}
__ **************
-- UE CAPABILITY INFORMATION CONFIRM
__ ******************
{\tt UECapabilityInformationConfirm ::= CHOICE } \{
                                                                 SEOUENCE {
      r3
              UECapabilityInformationConfirm-r3-IEs, laterNonCriticalExtensions SECTION SECT
              ueCapabilityInformationConfirm-r3
                     -- Container for additional R99 extensions ueCapabilityInformationConfirm-r3-add-ext
                                                                               r3-add-ext BIT STRING SEQUENCE {} OPTIONAL
                                                                                                                                       OPTIONAL,
                     nonCriticalExtensions
              }
                   OPTIONAL
       },
```

```
later-than-r3
                              SEQUENCE {
      rrc-TransactionIdentifier RRC-TransactionIdentifier, criticalExtensions SEQUENCE {}
}
UECapabilityInformationConfirm-r3-IEs ::= SEQUENCE {
   -- User equipment IEs
     rrc-TransactionIdentifier RRC-TransactionIdentifier
}
__ ****************
-- UPLINK DIRECT TRANSFER
__ ***************
UplinkDirectTransfer ::= SEQUENCE {
   -- Core network IEs
      cn-DomainIdentity
                                   CN-DomainIdentity,
      nas-Message
                                  NAS-Message,
   -- Measurement IEs
      measuredResultsOnRACH MeasuredResultsOnRACH laterNonCriticalExtensions SEQUENCE {
                                                         OPTIONAL,
          -- Container for additional R99 extensions
          uplinkDirectTransfer-r3-add-ext BIT STRING OPTIONAL,
         nonCriticalExtensions
                                     SEQUENCE {} OPTIONAL
       } OPTIONAL
}
__ ****************
-- UPLINK PHYSICAL CHANNEL CONTROL
__ *****************
UplinkPhysicalChannelControl ::= CHOICE {
                              SEQUENCE {
       \verb"uplinkPhysicalChannelControl-r3" UplinkPhysicalChannelControl-r3-IEs",
       laterNonCriticalExtensions
                                      SEQUENCE {
           -- Container for additional R99 extensions
          uplinkPhysicalChannelControl-r3-add-ext
                                                BIT STRING
              -- Extension mechanism for non- release4 information
              noncriticalExtensions
                                     SEQUENCE {}
                                                                       OPTIONAL
            OPTIONAL
       } OPTIONAL
                              SEQUENCE {
   later-than-r3
      rrc-TransactionIdentifier
criticalExtensions
RRC-TransactionIdentifier,
CHOICE {
                                  CHOICE {
       criticalExtensions
                                   SEQUENCE {
              uplinkPhysicalChannelControl-r4 UplinkPhysicalChannelControl-r4-IEs,
              v4d0NonCriticalExtensions SEQUENCE {
                 -- Container for adding non critical extensions after freezing REL-5 \,
                  uplinkPhysicalChannelControl-r4-add-ext BIT STRING OPTIONAL,
                                             SEQUENCE { } OPTIONAL
                 nonCriticalExtensions
                   OPTIONAL
              }
          criticalExtensions
                                 CHOICE {
                                          SEQUENCE {
                 uplinkPhysicalChannelControl-r5 UplinkPhysicalChannelControl-r5-IEs,
                 -- Container for adding non critical extensions after freezing REL-6
                 uplinkPhysicalChannelControl-r5-add-ext BIT STRING OPTIONAL,
                                            SEQUENCE {} OPTIONAL
                 nonCriticalExtensions
              criticalExtensions
                                         SEQUENCE {}
         }
      }
}
UplinkPhysicalChannelControl-r3-IEs ::= SEQUENCE {
   -- User equipment IEs
      rrc-TransactionIdentifier
                                 RRC-TransactionIdentifier,
   -- Physical channel IEs
      ccTrCH-PowerControlInfo
                                 CCTrCH-PowerControlInfo
                                                                  OPTIONAL,
```

```
timingAdvance
                                    UL-TimingAdvanceControl
                                                                      OPTIONAL,
       alpha
                                    Alpha
                                                                      OPTIONAL,
       specialBurstScheduling SpecialBurstScheduling prach-ConstantValue ConstantValue
                                                                      OPTIONAL,
       prach-ConstantValue
                                                                      OPTIONAL,
       pusch-ConstantValue
                                    ConstantValueTdd
                                                                      OPTIONAL
}
UplinkPhysicalChannelControl-v4b0ext-IEs ::= SEQUENCE {
    -- In case of TDD, openLoopPowerControl-IPDL-TDD is included instead of IE
   -- up-IPDL-Parameters in up-OTDOA-AssistanceData
   openLoopPowerControl-IPDL-TDD OpenLoopPowerControl-IPDL-TDD-r4 OPTIONAL
}
UplinkPhysicalChannelControl-r4-IEs ::= SEQUENCE {
   -- Physical channel IEs
                                    CCTrCH-PowerControlInfo-r4 OPTIONAL, SpecialBurstScheduling OPTIONAL,
       ccTrCH-PowerControlInfo
       specialBurstScheduling
                                   SpecialBurstScheduling
       tddOption
                                    CHOICE {
                                        SEQUENCE {
           tdd384
              timingAdvance
                                            UL-TimingAdvanceControl-r4 OPTIONAL,
                                            Alpha
                                                                      OPTIONAL,
               alpha
              prach-ConstantValue
                                            ConstantValueTdd
                                                                      OPTIONAL,
               pusch-ConstantValue
                                            ConstantValueTdd
                                                                      OPTIONAL,
              openLoopPowerControl-IPDL-TDD OpenLoopPowerControl-IPDL-TDD-r4 OPTIONAL
           tdd128
                                        SEQUENCE {
              ul-SynchronisationParameters UL-SynchronisationParameters-r4 OPTIONAL
       }
}
UplinkPhysicalChannelControl-r5-IEs ::= SEQUENCE {
    -- Physical channel IEs
       CHOICE {
           tdd384
                                       SEQUENCE {
               timingAdvance
                                            UL-TimingAdvanceControl-r4 OPTIONAL,
                                           ConstantValueTdd
               alpha
                                                                      OPTIONAL,
              prach-ConstantValue
                                                                      OPTIONAL,
              pusch-ConstantValue
                                            ConstantValueTdd
                                                                      OPTIONAL,
               openLoopPowerControl-IPDL-TDD OpenLoopPowerControl-IPDL-TDD-r4 OPTIONAL,
              hs-SICH-Power-Control HS-SICH-Power-Control-Info-TDD384 OPTIONAL
                                        SEQUENCE {
              ul-SynchronisationParameters
                                            UL-SynchronisationParameters-r4 OPTIONAL
       }
  **************
-- URA UPDATE
__ ****************
URAUpdate ::= SEQUENCE {
       u-RNTI U-RNTI,
ura-UpdateCause URA-UpdateCause,
protocolErrorIndicator ProtocolErrorIndicatorWithMoreInfo,
laterNonCriticalExtensions SEQUENCE {
    -- User equipment IEs
          -- Container for additional R99 extensions
          uraUpdate-r3-add-ext BIT STRING nonCriticalExtensions SEQUENC
                                                   OPTIONAL,
                                        SEQUENCE {}
                                                       OPTIONAL
         OPTIONAL
}
__ ****************
-- URA UPDATE CONFIRM
__ ****************
URAUpdateConfirm ::= CHOICE {
       SEQUENCE {
uraUpdateConfirm-r3
URAUpdateConfirm-r3-IEs,
                                        SEQUENCE {
       laterNonCriticalExtensions
```

```
-- Container for additional R99 extensions
           uraUpdateConfirm-r3-add-ext BIT STRING
                                                       OPTIONAL
OPTIONAL
                                                          OPTIONAL,
           nonCriticalExtensions
                                          SEQUENCE {}
          OPTIONAL
    later-than-r3
                                  SEQUENCE {
       {\tt rrc-TransactionIdentifier} \qquad {\tt RRC-TransactionIdentifier},
       criticalExtensions
                                      CHOICE {
           r5
                                         SEQUENCE {
               uraUpdateConfirm-r5
nonCriticalExtensions
                                              URAUpdateConfirm-r5-IEs,
                                              SEQUENCE {} OPTIONAL
           },
           criticalExtensions
                                         SEQUENCE {}
       }
   }
}
URAUpdateConfirm-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
       rrc-TransactionIdentifier
                                      RRC-TransactionIdentifier,
       integrityProtectionModeInfo
                                       IntegrityProtectionModeInfo
                                                                          OPTIONAL,
       cipheringModeInfo
                                       CipheringModeInfo
                                                                          OPTIONAL,
       new-U-RNTI
                                       U-RNTI
                                                                          OPTIONAL,
       new-C-RNTI
                                      C-RNTI
                                                                          OPTIONAL.
       rrc-StateIndicator
                                      RRC-StateIndicator,
       utran-DRX-CycleLengthCoeff
                                      UTRAN-DRX-CycleLengthCoefficient
                                                                         OPTIONAL,
    -- CN information elements
       cn-InformationInfo
                                      CN-InformationInfo
                                                                          OPTIONAL,
   -- UTRAN mobility IEs
       ura-Identity
                                      URA-Identity
                                                                          OPTIONAL,
    -- Radio bearer IEs
       dl-CounterSynchronisationInfo DL-CounterSynchronisationInfo
                                                                          OPTIONAL
}
URAUpdateConfirm-r5-IEs ::= SEQUENCE {
    -- User equipment IEs
       integrityProtectionModeInfo
                                      IntegrityProtectionModeInfo
                                                                          OPTIONAL.
       cipheringModeInfo
                                      CipheringModeInfo
                                                                          OPTIONAL,
       new-U-RNTI
                                      U-RNTI
                                                                          OPTIONAL,
       new-C-RNTI
                                      C-RNTI
                                                                          OPTIONAL,
       rrc-StateIndicator
                                      RRC-StateIndicator,
       utran-DRX-CycleLengthCoeff
                                      UTRAN-DRX-CycleLengthCoefficient
                                                                          OPTIONAL,
   -- CN information elements
       cn-InformationInfo
                                      CN-InformationInfo
                                                                          OPTIONAL,
   -- UTRAN mobility IEs
                                      URA-Identity
       ura-Identity
                                                                          OPTIONAL.
    -- Radio bearer IEs
       dl-CounterSynchronisationInfo DL-CounterSynchronisationInfo-r5
                                                                        OPTIONAL
}
__ ****************
-- URA UPDATE CONFIRM for CCCH
__ *************************
URAUpdateConfirm-CCCH ::= CHOICE {
                                   SEQUENCE {
       uraUpdateConfirm-CCCH-r3
       uraUpdateConfirm-CCCH-r3 URAUpdateConfirm-CCCH-r3-IEs, laterNonCriticalExtensions SEQUENCE {
            -- Container for additional R99 extensions
           uraUpdateConfirm-CCCH-r3-add-ext BIT STRING
                                                                OPTIONAL,
                                         SEQUENCE {} OPTIONAL
           nonCriticalExtensions
       } OPTIONAL
   later-than-r3
                                 SEQUENCE {
       u-RNTI
rrc-TransactionIdentifier RRC-Transac
SEQUENCE {}
                                   U-RNTÏ,
                                      RRC-TransactionIdentifier,
}
URAUpdateConfirm-CCCH-r3-IEs ::= SEQUENCE {
   -- User equipment IEs
       u-RNTI
                                       U-RNTI,
   -- The rest of the message is identical to the one sent on DCCH.
       uraUpdateConfirm
                                      URAUpdateConfirm-r3-IEs
}
```

```
__ **************
-- UTRAN MOBILITY INFORMATION
__ ****************
UTRANMobilityInformation ::= CHOICE {
                                SEQUENCE {
       utranMobilityInformation-r3 UTRANMobilityInformation-r3-IEs, v3a0NonCriticalExtensions SEQUENCE {
          utranMobilityInformation-v3a0ext UTRANMobilityInformation-v3a0ext-IEs, laterNonCriticalExtensions SEQUENCE {
          laterNonCriticalExtensions
              -- Container for additional R99 extensions
              OPTIONAL,
              nonCriticalExtensions
                                                                 OPTIONAL
          }
                 OPTIONAL
              OPTIONAL
   later-than-r3
                                SEQUENCE {
       rrc-TransactionIdentifier RRC-TransactionIdentifier,
       criticalExtensions
                                   CHOICE {
                                       SEQUENCE {
              {\tt utranMobilityInformation-r5-IEs,}
                                           SEQUENCE {}
              nonCriticalExtensions
                                                         OPTIONAL
          criticalExtensions
                                      SEQUENCE {}
       }
   }
}
UTRANMobilityInformation-r3-IEs ::= SEQUENCE {
   -- User equipment IEs
       rrc-TransactionIdentifier RRC-TransactionIdentifier, integrityProtectionModeInfo CipheringModeInfo CipheringModeInfo
                                                                   OPTIONAL,
                                                                     OPTIONAL,
       new-II-RNTT
                                   II-RNTT
                                                                     OPTIONAL.
       new-C-RNTI
                                   C-RNTI
                                                                     OPTIONAL,
       ue-ConnTimersAndConstants
                                   UE-ConnTimersAndConstants
                                                                     OPTIONAL,
   -- CN information elements
      cn-InformationInfo
                                   CN-InformationInfoFull
                                                                     OPTIONAL,
   -- UTRAN mobility IEs
       ura-Identity
                                  URA-Identity
                                                                    OPTIONAL,
   -- Radio bearer IEs
      dl-CounterSynchronisationInfo DL-CounterSynchronisationInfo
                                                                   OPTIONAL,
   -- Extension mechanism for non- release99 information
                                               OPTIONAL
       nonCriticalExtensions
                                    SEQUENCE {}
}
UTRANMobilityInformation-v3a0ext-IEs ::= SEQUENCE {
                                       UE-ConnTimersAndConstants-v3a0ext
   ue-ConnTimersAndConstants-v3a0ext
UTRANMobilityInformation-r5-IEs ::= SEQUENCE {
   -- User equipment IEs
       OPTIONAL,
       cipheringModeInfo
                                    CipheringModeInfo
                                                                     OPTIONAL,
       new-U-RNTI
                                   U-RNTI
                                                                     OPTIONAL,
       new-C-RNTI
                                   C-RNTI
                                                                     OPTIONAL.
       ue-ConnTimersAndConstants
                                   UE-ConnTimersAndConstants-r5
                                                                    OPTIONAL,
   -- CN information elements
      cn-InformationInfo
                                    CN-InformationInfoFull
                                                                     OPTIONAL,
   -- UTRAN mobility IEs
      ura-Identity
                                   URA-Identity
                                                                    OPTIONAL,
   -- Radio bearer IEs
      dl-CounterSynchronisationInfo DL-CounterSynchronisationInfo-r5
}
__ *****************
-- UTRAN MOBILITY INFORMATION CONFIRM
__ ***************************
UTRANMobilityInformationConfirm ::= SEQUENCE {
   -- User equipment IEs
       rrc-TransactionIdentifier
                                   RRC-TransactionIdentifier,
       ul-IntegProtActivationInfo
                                    IntegrityProtActivationInfo
                                                                    OPTIONAL,
```

```
-- Radio bearer IEs
        count-C-ActivationTime ActivationTime
rb-UL-CiphActivationTimeInfo RB-ActivationTimeInfoList
                                                                               OPTIONAL,
                                                                              OPTIONAL,
        ul-CounterSynchronisationInfo UL-CounterSynchronisationInfo
                                                                              OPTIONAL,
        laterNonCriticalExtensions
                                             SEQUENCE {
            -- Container for additional R99 extensions
                                                           BIT STRING
OPTIONAL
            utranMobilityInformationConfirm-r3-add-ext
                                                                             OPTIONAL.
            nonCriticalExtensions
                                             SEQUENCE {}
           OPTIONAL
}
__ ***************
-- UTRAN MOBILITY INFORMATION FAILURE
__ **************
UTRANMobilityInformationFailure ::= SEQUENCE {
    -- UE information elements
        rrc-TransactionIdentifier RRC-TransactionIdentifie failureCause FailureCauseWithProtErr, laterNonCriticalExtensions SEQUENCE {
                                         RRC-TransactionIdentifier,
             -- Container for additional R99 extensions
                                             e-r3-add-ext BIT STRING SEQUENCE {} OPTIONAL
            utranMobilityInformationFailure-r3-add-ext
                                                                             OPTIONAL,
            nonCriticalExtensions
           OPTIONAL
}
END
```

11.3 Information element definitions

```
InformationElements DEFINITIONS AUTOMATIC TAGS ::=
__ *****************
     CORE NETWORK INFORMATION ELEMENTS (10.3.1)
__ *****************
BEGIN
IMPORTS
   hiPDSCHidentities,
   hiPUSCHidentities,
   hiRM,
   maxAC
   maxAdditionalMeas,
   maxASC,
   maxASCmap,
   maxASCpersist,
   maxCCTrCH,
   maxCellMeas,
   maxCellMeas-1,
   maxCNdomains,
   maxCPCHsets,
   maxDPCH-DLchan,
   maxDPDCH-III.
   maxDRACclasses,
   maxFACHPCH,
   maxFreq,
   maxFreqBandsFDD,
   maxFreqBandsTDD,
   maxFreqBandsGSM,
   maxGERAN-SI,
   maxHProcesses,
   maxHSDSCHTBIndex,
   maxHSDSCHTBIndex-tdd384,
   maxHSSCCHs,
   maxInterSysMessages,
   maxLoCHperRLC,
   maxMAC-d-PDUsizes,
   maxMeasEvent,
   maxMeasIntervals,
   maxMeasParEvent.
   maxNumCDMA2000Freqs,
   maxNumFDDFreqs,
```

```
maxNumGSMFreqRanges,
   maxNumTDDFreqs,
   maxOtherRAT,
   maxOtherRAT-16,
   maxPage1,
   maxPCPCH-APsig,
   maxPCPCH-APsubCh,
   maxPCPCH-CDsig,
   maxPCPCH-CDsubCh,
   maxPCPCH-SF,
   maxPCPCHs,
   maxPDCPAlgoType,
   maxPDSCH,
   maxPDSCH-TFCIgroups,
   maxPRACH,
   maxPRACH-FPACH,
   maxPredefConfig,
   maxPUSCH.
   maxQueueIDs,
   maxRABsetup,
   maxRAT,
   maxRB,
   maxRBallRABs,
   maxRBMuxOptions,
   maxRBperRAB,
   maxReportedGSMCells,
   maxSRBsetup,
   maxRL,
   maxRL-1,
   maxROHC-PacketSizes-r4,
   maxROHC-Profile-r4,
   maxSCCPCH,
   maxSat,
   maxSIB.
   maxSIB-FACH,
   maxSystemCapability,
   maxTF,
   maxTF-CPCH,
   maxTFC,
   maxTFCsub,
   maxTFCI-2-Combs,
   maxTGPS,
   maxTrCH,
   maxTrCHpreconf,
   maxTS,
   maxTS-1,
   maxTS-2,
   maxTS-LCR,
   maxTS-LCR-1,
   maxURA,
   maxURNTI-Group
FROM Constant-definitions;
Ansi-41-IDNNS ::=
                                            BIT STRING (SIZE (14))
                                    ENUMERATED {
CN-DomainIdentity ::=
                                        cs-domain,
                                        ps-domain }
CN-DomainInformation ::=
                                    SEQUENCE {
    cn-DomainIdentity
                                        CN-DomainIdentity,
    cn-DomainSpecificNAS-Info
                                        NAS-SystemInformationGSM-MAP
}
CN-DomainInformationFull ::=
                                    SEQUENCE {
   cn-DomainIdentity
                                     CN-DomainIdentity,
    cn-DomainSpecificNAS-Info
                                       NAS-SystemInformationGSM-MAP,
                                        CN-DRX-CycleLengthCoefficient
   cn-DRX-CycleLengthCoeff
}
                                    SEQUENCE (SIZE (1..maxCNdomains)) OF
CN-DomainInformationList ::=
                                        CN-DomainInformation
CN-DomainInformationListFull ::=
                                    SEQUENCE (SIZE (1..maxCNdomains)) OF
                                        CN-DomainInformationFull
CN-DomainSysInfo ::=
                                    SEQUENCE {
    cn-DomainIdentity
                                        CN-DomainIdentity,
                                        CHOICE {
    cn-Type
```

```
gsm-MAP
                                            NAS-SystemInformationGSM-MAP,
       ansi-41
                                            NAS-SystemInformationANSI-41
    cn-DRX-CycleLengthCoeff
                                        CN-DRX-CycleLengthCoefficient
CN-DomainSysInfoList ::=
                                    SEQUENCE (SIZE (1..maxCNdomains)) OF
                                        CN-DomainSysInfo
CN-InformationInfo ::=
                                    SEQUENCE {
                                     PLMN-Identity
                                                                           OPTIONAL,
   plmn-Identity
    cn-CommonGSM-MAP-NAS-SysInfo
                                                                           OPTIONAL,
                                        NAS-SystemInformationGSM-MAP
    cn-DomainInformationList
                                        CN-DomainInformationList
                                                                            OPTIONAL
CN-InformationInfoFull ::=
                                   SEQUENCE {
                                      PLMN-Identity
   plmn-Identity
                                                                            OPTIONAL,
                                       NAS-SystemInformationGSM-MAP OPTIONAL CN-DomainInformationListFull OPTIONAL
    cn-CommonGSM-MAP-NAS-SysInfo
                                                                            OPTIONAL
   cn-DomainInformationListFull
}
Digit ::=
                                    INTEGER (0..9)
Gsm-map-IDNNS ::=
                                            SEQUENCE {
                                                    CHOICE {
   routingbasis
                                                        SEQUENCE {
       localPTMSI
           routingparameter
                                                            RoutingParameter
        tMSIofsamePLMN
                                                         SEQUENCE {
           routingparameter
                                                            RoutingParameter
        tMSIofdifferentPLMN
                                                         SEQUENCE {
           routingparameter
                                                            RoutingParameter
                                                         SEQUENCE {
        iMSIresponsetopaging
           routingparameter
                                                            RoutingParameter
        iMSIcauseUEinitiatedEvent
                                                         SEOUENCE {
           routingparameter
                                                            RoutingParameter
        iMEI
                                                         SEQUENCE {
                                                            RoutingParameter
           routingparameter
        spare2
                                                         SEQUENCE {
          routingparameter
                                                            RoutingParameter
        spare1
                                                         SEQUENCE {
           routingparameter
                                                            RoutingParameter
    -- dummy is not used in this version of the specification and
    -- it should be ignored by the receiver.
                                            BOOLEAN
IMEI ::=
                                    SEQUENCE (SIZE (15)) OF
                                        IMEI-Digit
IMEI-Digit ::=
                                    INTEGER (0..15)
IMSI-GSM-MAP ::=
                                    SEQUENCE (SIZE (6..21)) OF
                                        Digit
IntraDomainNasNodeSelector ::=
                                                SEQUENCE {
                                                    CHOICE {
   version
       release99
                                                         SEQUENCE {
                                                            CHOICE {
           cn-Type
               gsm-Map-IDNNS
                                                                Gsm-map-IDNNS,
                ansi-41-IDNNS
                                                                 Ansi-41-IDNNS
           }
        later
                                                         SEQUENCE {
                                                            BIT STRING (SIZE (15))
           futurecoding
}
LAI ::=
                                    SEQUENCE {
```

```
plmn-Identity
                                    PLMN-Identity,
                                     BIT STRING (SIZE (16))
   lac
}
MCC ::=
                                 SEQUENCE (SIZE (3)) OF
                                    Digit
MNC ::=
                                 SEQUENCE (SIZE (2..3)) OF
                                     Digit
                                 OCTET STRING (SIZE (1..4095))
NAS-Message ::=
{\tt NAS-Synchronisation-Indicator} \ ::= \ {\tt BIT} \ {\tt STRING}({\tt SIZE}(4))
NAS-SystemInformationGSM-MAP ::=
                                 OCTET STRING (SIZE (1..8))
                                 BIT STRING (SIZE (32))
P-TMSI-GSM-MAP ::=
PagingRecordTypeID ::=
                                 ENUMERATED {
                                     imsi-GSM-MAP,
                                     tmsi-GSM-MAP-P-TMSI,
                                     imsi-DS-41,
                                     tmsi-DS-41 }
                                 SEQUENCE {
PLMN-Identity ::=
   mcc
                                    MCC,
   mnc
                                     MNC
}
PLMN-Type ::=
                                 CHOICE {
                                  SEQUENCE {
   gsm-MAP
     plmn-Identity
                                       PLMN-Identity
   },
                                 SEQUENCE {
   ansi-41
      p-REV
                                    P-REV,
       min-P-REV
                                     Min-P-REV,
       sid
                                    SID,
                                    NID
      nid
   gsm-MAP-and-ANSI-41
                               SEQUENCE {
       plmn-Identity
                                 PLMN-Identity,
       p-REV
                                     P-REV,
                                    Min-P-REV,
       min-P-REV
       sid
                                    SID,
       nid
                                    NID
   },
                                 NULL
   spare
}
RAB-Identity ::=
                                 CHOICE {
  gsm-MAP-RAB-Identity
                                  BIT STRING (SIZE (8)),
   ansi-41-RAB-Identity
                                    BIT STRING (SIZE (8))
}
RAI ::=
                                 SEQUENCE {
                                     LAI.
   lai
   rac
                                     RoutingAreaCode
                         BIT STRING (SIZE (8))
RoutingAreaCode ::=
RoutingParameter ::=
                                            BIT STRING (SIZE (10))
TMSI-GSM-MAP ::=
                                 BIT STRING (SIZE (32))
__ ***************
     UTRAN MOBILITY INFORMATION ELEMENTS (10.3.2)
__ ***************
AccessClassBarred ::=
                                 ENUMERATED {
                                    barred, notBarred }
AccessClassBarredList ::=
                                 SEQUENCE (SIZE (maxAC)) OF
                                    AccessClassBarred
                                ENUMERATED {
AllowedIndicator ::=
```

```
allowed, notAllowed }
CellAccessRestriction ::=
                                   SEQUENCE {
                                       CellBarred,
    cellBarred
    cellReservedForOperatorUse
                                       ReservedIndicator,
    cellReservationExtension
                                       ReservedIndicator,
    -- NOTE: IE accessClassBarredList should not be included if the IE CellAccessRestriction
    -- is included in the IE SysInfoType4
    accessClassBarredList
                                       AccessClassBarredList
                                                                           OPTIONAL
}
CellBarred ::=
                                   CHOICE {
                                       SEQUENCE {
   barred
       intraFreqCellReselectionInd
                                          AllowedIndicator,
       t-Barred
                                           T-Barred
   notBarred
                                       NULL
}
CellIdentity ::=
                                   BIT STRING (SIZE (28))
                                   SEQUENCE (SIZE (1..maxRL)) OF CellIdentity
CellIdentity-PerRL-List ::=
                                  SEQUENCE {
CellSelectReselectInfoSIB-3-4 ::=
                                       MappingInfo
                                                                           OPTIONAL.
    mappingInfo
    cellSelectQualityMeasure
                                       CHOICE {
                                           SEQUENCE {
       cpich-Ec-NO
           -- Default value for q-HYST-2-S is q-HYST-1-S
                                                                           OPTIONAL
            q-HYST-2-S
                                               0-Hyst-S
            -- Default value for q-HYST-2-S is q-HYST-1-S
        },
       cpich-RSCP
                                           NULL
    },
    modeSpecificInfo
                                       CHOICE {
                                           SEQUENCE {
        fdd
           s-Intrasearch
                                               S-SearchQual
                                                                           OPTIONAL,
           s-Intersearch
                                               S-SearchOual
                                                                           OPTIONAL.
           s-SearchHCS
                                               S-SearchRXLEV
                                                                           OPTIONAL,
           rat-List
                                               RAT-FDD-InfoList
                                                                           OPTIONAL,
                                               Q-QualMin,
           q-QualMin
           q-RxlevMin
                                               Q-RxlevMin
        },
        tdd
                                           SEQUENCE {
                                               S-SearchRXLEV
                                                                           OPTIONAL,
           s-Intrasearch
           s-Intersearch
                                               S-SearchRXLEV
                                                                          OPTIONAL,
            s-SearchHCS
                                               S-SearchRXLEV
                                                                           OPTIONAL.
                                               RAT-TDD-InfoList
           rat-List
                                                                           OPTIONAL,
            q-RxlevMin
                                               Q-RxlevMin
        }
    },
    q-Hyst-1-S
                                       Q-Hyst-S,
    t-Reselection-S
                                       T-Reselection-S,
   hcs-ServingCellInformation
                                       HCS-ServingCellInformation
                                                                          OPTIONAL,
   maxAllowedUL-TX-Power
                                       MaxAllowedUL-TX-Power
}
MapParameter ::=
                                   INTEGER (0..99)
                                   SEQUENCE {
Mapping ::=
                                       RAT.
   rat
   mappingFunctionParameterList
                                       MappingFunctionParameterList
}
Mapping-LCR-r4 ::=
                                   SEOUENCE {
   mappingFunctionParameterList
                                       MappingFunctionParameterList
MappingFunctionParameter ::=
                                   SEQUENCE {
    {\tt functionType}
                                       MappingFunctionType,
    mapParameter1
                                       MapParameter
                                                                           OPTIONAL,
   mapParameter2
                                       MapParameter,
    -- The presence of upperLimit is conditional on the number of repetition
    upperLimit
                                       UpperLimit
                                                                           OPTIONAL
MappingFunctionParameterList ::= SEQUENCE (SIZE (1..maxMeasIntervals)) OF
                                       MappingFunctionParameter
```

```
MappingFunctionType ::=
                                  ENUMERATED {
                                      linear,
                                      functionType2,
                                       functionType3,
                                      functionType4 }
-- In MappingInfo list, mapping for FDD and 3.84Mcps TDD is defined.
-- For 1.28Mcps TDD, Mapping-LCR-r4 is used instead.
MappingInfo ::=
                                  SEQUENCE (SIZE (1..maxRAT)) OF
-- Actual value Q-Hyst-S = IE value * 2
O-Hyst-S ::=
                                  INTEGER (0..20)
                                  ENUMERATED {
                                     utra-FDD,
                                      utra-TDD,
                                      gsm,
                                      cdma2000 }
                                  SEQUENCE {
RAT-FDD-Info ::=
   rat-Identifier
                                     RAT-Identifier,
   s-SearchRAT
                                      S-SearchQual,
   s-HCS-RAT
                                      S-SearchRXLEV
                                                                             OPTIONAL,
   s-Limit-SearchRAT
                                      S-SearchQual
}
RAT-FDD-InfoList ::=
                                  SEQUENCE (SIZE (1..maxOtherRAT)) OF
                                      RAT-FDD-Info
RAT-Identifier ::=
                                  ENUMERATED {
                                     gsm, cdma2000 }
                                  SEQUENCE {
RAT-TDD-Info ::=
                                     RAT-Identifier,
   rat-Identifier
   s-SearchRAT
                                      S-SearchRXLEV,
   s-HCS-RAT
                                      S-SearchRXLEV
                                                                         OPTIONAL,
   s-Limit-SearchRAT
                                      S-SearchRXLEV
RAT-TDD-InfoList ::=
                                  SEQUENCE (SIZE (1..maxOtherRAT)) OF
                                      RAT-TDD-Info
ReservedIndicator ::=
                                  ENUMERATED {
                                      reserved,
                                      notReserved }
-- Actual value S-SearchQual = IE value * 2
S-SearchQual ::=
                                      INTEGER (-16..10)
-- Actual value S-SearchRXLEV = (IE value * 2) + 1
                                      INTEGER (-53..45)
S-SearchRXLEV ::=
T-Barred ::=
                                  ENUMERATED {
                                      s10, s20, s40, s80,
                                      s160, s320, s640, s1280 }
T-Reselection-S ::=
                                  INTEGER (0..31)
-- For UpperLimit, the used range depends on the RAT used.
UpperLimit ::=
                                  INTEGER (1..91)
URA-Identity ::=
                                  BIT STRING (SIZE (16))
                                  SEQUENCE (SIZE (1..maxURA)) OF
URA-IdentityList ::=
                                      URA-Identity
__ ****************************
      USER EQUIPMENT INFORMATION ELEMENTS (10.3.3)
__ ***************
AccessStratumReleaseIndicator ::=
                                  ENUMERATED {
                                      rel-4, rel-5, spare14, spare13,
                                      spare12, spare11, spare10, spare9, spare8,
                                      spare7, spare6, spare5, spare4, spare3, spare2, spare1 }
```

```
-- TABULAR : for ActivationTime, value 'now' always appear as default, and is encoded
-- by absence of the field
ActivationTime ::=
                                   INTEGER (0..255)
BackoffControlParams ::=
                                  SEQUENCE {
                                    N-AP-RetransMax,
   n-AP-RetransMax
   n-AccessFails
                                       N-AccessFails,
   nf-BO-NoAICH
                                       NF-BO-NoAICH,
   ns-BO-Busy
                                       NS-BO-Busy,
   nf-BO-AllBusy
                                       NF-BO-AllBusy,
                                       NF-BO-Mismatch,
   nf-BO-Mismatch
    t-CPCH
                                       T-CPCH
}
C-RNTI ::=
                                   BIT STRING (SIZE (16))
CapabilityUpdateRequirement ::=
                                  SEQUENCE {
   ue-RadioCapabilityFDDUpdateRequirement BOOLEAN,
    -- ue-RadioCapabilityTDDUpdateRequirement is for 3.84Mcps TDD update requirement
    \verb"ue-RadioCapabilityTDDUpdateRequirement" BOOLEAN",
    systemSpecificCapUpdateReqList
                                     SystemSpecificCapUpdateReqList
                                                                          OPTIONAL
CapabilityUpdateRequirement-r4-ext ::= SEOUENCE {
    ue-RadioCapabilityUpdateRequirement-TDD128 BOOLEAN
CapabilityUpdateRequirement-r4 ::= SEQUENCE {
    ue-RadioCapabilityFDDUpdateRequirement-FDD BOOLEAN,
   ue-RadioCapabilityTDDUpdateRequirement-TDD384 BOOLEAN, ue-RadioCapabilityTDDUpdateRequirement-TDD128 BOOLEAN,
    systemSpecificCapUpdateReqList SystemSpecificCapUpdateReqList OPTIONAL
CellUpdateCause ::=
                                   ENUMERATED {
                                       cellReselection,
                                       periodicalCellUpdate,
                                       uplinkDataTransmission,
                                       utran-pagingResponse,
                                       re-enteredServiceArea,
                                       radiolinkFailure.
                                       rlc-unrecoverableError,
                                       spare1 }
ChipRateCapability ::=
                                   ENUMERATED {
                                       mcps3-84, mcps1-28 }
CipheringAlgorithm ::=
                                   ENUMERATED {
                                       uea0, uea1 }
CipheringModeCommand ::=
                                   CHOICE {
    startRestart
                                       CipheringAlgorithm,
                               NULL
    dummy
}
CipheringModeInfo ::=
                                   SEQUENCE {
    -- TABULAR: The ciphering algorithm is included in the CipheringModeCommand.
                           CipheringModeCommand,
    cipheringModeCommand
                                                                           OPTIONAL,
   activationTimeForDPCH
                                       ActivationTime
   rb-DL-CiphActivationTimeInfo
                                      RB-ActivationTimeInfoList
                                                                          OPTIONAL
CN-DRX-CycleLengthCoefficient ::= INTEGER (6..9)
CN-PagedUE-Identity ::=
                                   CHOICE {
    imsi-GSM-MAP
                                       IMSI-GSM-MAP,
    tmsi-GSM-MAP
                                       TMSI-GSM-MAP,
    p-TMSI-GSM-MAP
                                       P-TMSI-GSM-MAP,
    imsi-DS-41
                                       IMSI-DS-41,
    tmsi-DS-41
                                       TMSI-DS-41,
    spare3
                                       NULL,
    spare2
                                       NULL,
    spare1
                                       NULL
CompressedModeMeasCapability ::= SEQUENCE {
    fdd-Measurements
                                       BOOLEAN,
```

```
-- TABULAR: The IEs tdd-Measurements, gsm-Measurements and multiCarrierMeasurements
    -- are made optional since they are conditional based on another information element.
    -- Their absence corresponds to the case where the condition is not true.
                                      BOOLEAN
                                                                           OPTIONAL.
    tdd-Measurements
    gsm-Measurements
                                       GSM-Measurements
                                                                           OPTIONAL,
    multiCarrierMeasurements
                                       BOOLEAN
                                                                           OPTIONAL
}
CompressedModeMeasCapability-LCR-r4 ::= SEQUENCE {
    tdd128-Measurements
                                           BOOLEAN
                                                                           OPTIONAL
CompressedModeMeasCapabFDDList ::= SEQUENCE (SIZE (1..maxFreqBandsFDD)) OF
                                       CompressedModeMeasCapabFDD
CompressedModeMeasCapabFDD ::=
                                   SEQUENCE {
                                       RadioFrequencyBandFDD OPTIONAL,
    radioFrequencyBandFDD
    dl-MeasurementsFDD
                                       BOOLEAN,
    ul-MeasurementsFDD
}
CompressedModeMeasCapabTDDList ::= SEQUENCE (SIZE (1..maxFreqBandsTDD)) OF
                                       CompressedModeMeasCapabTDD
CompressedModeMeasCapabTDD ::=
                                   SECTIENCE {
   radioFrequencyBandTDD
                                   RadioFrequencyBandTDD,
    dl-MeasurementsTDD
                                       BOOLEAN,
    ul-MeasurementsTDD
                                       BOOLEAN
CompressedModeMeasCapabGSMList ::= SEQUENCE (SIZE (1..maxFreqBandsGSM)) OF
                                       CompressedModeMeasCapabGSM
CompressedModeMeasCapabGSM ::=
                                   SEQUENCE {
    radioFrequencyBandGSM
                                       RadioFrequencyBandGSM,
    dl-MeasurementsGSM
                                       BOOLEAN,
   ul-MeasurementsGSM
                                       BOOLEAN
}
CompressedModeMeasCapabMC ::=
                                   SEQUENCE {
    dl-MeasurementsMC
                                       BOOLEAN,
    ul-MeasurementsMC
                                       BOOLEAN
}
CPCH-Parameters ::=
                                   SEQUENCE {
    initialPriorityDelayList
                                       InitialPriorityDelayList
                                                                         OPTIONAL,
                                       BackoffControlParams.
    backoffControlParams
    -- TABULAR: TPC step size nested inside PowerControlAlgorithm
    powerControlAlgorithm
                                       PowerControlAlgorithm,
                                       DL-DPCCH-BER
    dl-DPCCH-BER
}
DL-CapabilityWithSimultaneousHS-DSCHConfig ::= ENUMERATED{kbps32, kbps64, kbps128, kbps384}
DL-DPCCH-BER ::=
                                   INTEGER (0..63)
DL-PhysChCapabilityFDD ::=
                                   SEOUENCE {
   maxNoDPCH-PDSCH-Codes
                                      INTEGER (1..8),
    maxNoPhysChBitsReceived
                                       MaxNoPhysChBitsReceived,
    support For SF-512
                                       BOOLEAN.
    supportOfPDSCH
                                       BOOLEAN,
    simultaneousSCCPCH-DPCH-Reception SimultaneousSCCPCH-DPCH-Reception
}
DL-PhysChCapabilityFDD-v380ext ::=
                                           SEQUENCE {
    supportOfDedicatedPilotsForChEstimation SupportOfDedicatedPilotsForChEstimation
                                                                                          OPTIONAL
                                                 ENUMERATED { true }
SupportOfDedicatedPilotsForChEstimation ::=
DL-PhysChCapabilityTDD ::=
                                   SEQUENCE {
   maxTS-PerFrame
                                       MaxTS-PerFrame,
   maxPhysChPerFrame
                                       MaxPhysChPerFrame,
   minimumSF
                                       MinimumSF-DL,
    supportOfPDSCH
                                       BOOLEAN,
    maxPhysChPerTS
                                       MaxPhysChPerTS
}
```

```
DL-PhysChCapabilityTDD-LCR-r4 ::= SEQUENCE {
    maxTS-PerSubFrame
                                         MaxTS-PerSubFrame-r4,
   maxPhysChPerFrame
                                         MaxPhysChPerSubFrame-r4,
    minimumSF
                                         MinimumSF-DL,
    supportOfPDSCH
                                         BOOLEAN,
    maxPhysChPerTS
                                         MaxPhysChPerTS,
    supportOf8PSK
                                         BOOLEAN
}
DL-TransChCapability ::=
                                    SEQUENCE {
   maxNoBitsReceived
                                       MaxNoBits,
    maxConvCodeBitsReceived
                                         MaxNoBits.
    turboDecodingSupport
                                        TurboSupport,
    maxSimultaneousTransChs
                                         MaxSimultaneousTransChsDL,
    maxSimultaneousCCTrCH-Count
                                        MaxSimultaneousCCTrCH-Count,
   maxReceivedTransportBlocks
                                        MaxTransportBlocksDL,
                                         MaxNumberOfTFC-DL,
    maxNumberOfTFC
    maxNumberOfTF
                                         MaxNumberOfTF
}
DRAC-SysInfo ::=
                                     SEQUENCE {
    transmissionProbability
                                         TransmissionProbability,
    maximumBitRate
                                         MaximumBitRate
}
DRAC-SysInfoList ::=
                                     SEQUENCE (SIZE (1..maxDRACclasses)) OF
                                         DRAC-SysInfo
DSCH-RNTI ::=
                                     BIT STRING (SIZE (16))
                                     BIT STRING (SIZE (32))
ESN-DS-41 ::=
EstablishmentCause ::=
                                     ENUMERATED {
                                         originatingConversationalCall,
                                         originatingStreamingCall,
                                         originatingInteractiveCall,
                                         originatingBackgroundCall,
                                         originatingSubscribedTrafficCall,
                                         {\tt terminatingConversationalCall,}
                                         terminatingStreamingCall,
                                         terminatingInteractiveCall,
                                         terminatingBackgroundCall,
                                         emergencyCall,
                                         interRAT-CellReselection,
                                         interRAT-CellChangeOrder,
                                         registration,
                                         detach.
                                         originatingHighPrioritySignalling,
                                         originatingLowPrioritySignalling,
                                         callRe-establishment,
                                         terminatingHighPrioritySignalling,
                                         terminatingLowPrioritySignalling,
                                         terminatingCauseUnknown,
                                         spare12,
                                         spare11,
                                         spare10,
                                         spare9,
                                         spare8,
                                         spare7,
                                         spare6,
                                         spare5,
                                         spare4,
                                         spare3,
                                         spare2,
                                         spare1 }
FailureCauseWithProtErr ::=
                                     CHOICE {
    configurationUnsupported
                                         NULL,
    physicalChannelFailure
                                         NULL.
    incompatible {\tt Simultaneous} Reconfiguration
    compressedModeRuntimeError
                                         TGPSI,
    protocolError
                                        ProtocolErrorInformation,
    cellUpdateOccurred
                                        NULL,
    invalidConfiguration
                                        NULL,
    configurationIncomplete
                                        NULL,
    unsupportedMeasurement
                                         NULL,
    spare7
                                         NULL,
```

```
spare6
                                      NULL,
                                      NULL,
   spare5
   spare4
                                      NULL,
                                      NULL,
   spare3
   spare2
                                      NULL.
   spare1
                                      NULL
}
FailureCauseWithProtErrTrId ::= SEQUENCE {
       rrc-TransactionIdentifier RRC-TransactionIdentifier,
       failureCause
                                      FailureCauseWithProtErr
}
groupReleaseInformation
                                             GroupReleaseInformation
\label{thm:convergence} {\tt GroupReleaseInformation} ::= \\ {\tt SEQUENCE} \ \big\{
   uRNTI-Group
                                      U-RNTI-Group
}
GSM-Measurements ::=
                                  SEQUENCE {
   gsm900
                                      BOOLEAN,
                                      BOOLEAN,
   dcs1800
                                      BOOLEAN
   gsm1900
}
H-RNTI ::=
                                  BIT STRING (SIZE (16))
HSDSCH-physical-layer-category ::=
                                     INTEGER (1..64)
UESpecificBehaviourInformation1idle ::= BIT STRING (SIZE (4))
UESpecificBehaviourInformationlinterRAT ::= BIT STRING (SIZE (8))
IMSI-and-ESN-DS-41 ::=
                                  SEQUENCE {
   imsi-DS-41
                                      TMST-DS-41.
   esn-DS-41
                                      ESN-DS-41
IMSI-DS-41 ::=
                                  OCTET STRING (SIZE (5..7))
InitialPriorityDelayList ::= SEQUENCE (SIZE (1..maxASC)) OF
                                      NS-IP
InitialUE-Identity ::=
                                  CHOICE {
                                      IMSI-GSM-MAP,
   imsi
   tmsi-and-LAI
                                      TMSI-and-LAI-GSM-MAP,
   p-TMSI-and-RAI
                                      P-TMSI-and-RAI-GSM-MAP,
   imei
                                      IMEI,
   esn-DS-41
                                      ESN-DS-41,
   imsi-DS-41
                                      IMSI-DS-41,
   imsi-and-ESN-DS-41
                                      IMSI-and-ESN-DS-41,
   tmsi-DS-41
                                      TMSI-DS-41
}
IntegrityCheckInfo ::=
                                  SEQUENCE {
   egricycheckinio ::=
messageAuthenticationCode
rrc-MessageSequenceNumber
                                      MessageAuthenticationCode,
                                      RRC-MessageSequenceNumber
}
IntegrityProtActivationInfo ::=
                                  SEQUENCE {
   rrc-MessageSequenceNumberList
                                     RRC-MessageSequenceNumberList
IntegrityProtectionAlgorithm ::=
                                  ENUMERATED {
                                      uial }
IntegrityProtectionModeCommand ::= CHOICE {
   startIntegrityProtection SEQUENCE {
                                          IntegrityProtInitNumber
       integrityProtInitNumber
   modify
                                      SEQUENCE {
       dl-IntegrityProtActivationInfo
                                        IntegrityProtActivationInfo
```

```
}
IntegrityProtectionModeInfo ::=
                                   SEOUENCE {
    -- TABULAR: DL integrity protection activation info and Integrity
    -- protection intialisation number have been nested inside
    -- IntegrityProtectionModeCommand.
    integrityProtectionModeCommand IntegrityProtectionModeComman IntegrityProtectionAlgorithm IntegrityProtectionAlgorithm
                                         IntegrityProtectionModeCommand,
                                                                             OPTIONAL
}
IntegrityProtInitNumber ::=
                                    BIT STRING (SIZE (32))
MaxHcContextSpace ::=
                                         ENUMERATED {
                                             by512, by1024, by2048, by4096,
                                             by8192 }
                                         ENUMERATED {
MaxHcContextSpace-r5-ext ::=
                                             by16384, by32768, by65536, by131072 }
                                    ENUMERATED {
MaxROHC-ContextSessions-r4 ::=
                                             s2, s4, s8, s12, s16, s24, s32, s48,
                                             s64, s128, s256, s512, s1024, s16384 }
                                     ENUMERATED {
MaximumAM-EntityNumberRLC-Cap ::=
                                         dummy, am4, am5, am6,
                                         am8, am16, am30 }
-- Actual value MaximumBitRate = IE value * 16
                                     INTEGER (0..32)
MaximumBitRate ::=
MaximumRLC-WindowSize ::=
                                    ENUMERATED { mws2047, mws4095 }
MaxNoDPDCH-BitsTransmitted ::=
                                     ENUMERATED {
                                         b600, b1200, b2400, b4800,
                                         b9600, b19200, b28800, b38400,
                                         b48000, b57600 }
MaxNoBits ::=
                                     ENUMERATED {
                                         b640, b1280, b2560, b3840, b5120,
                                         b6400, b7680, b8960, b10240,
                                         b20480, b40960, b81920, b163840 }
MaxNoPhysChBitsReceived ::=
                                     ENUMERATED {
                                         dummy, b1200, b2400, b3600, b4800, b7200, b9600, b14400,
                                         b19200, b28800, b38400, b48000,
                                         b57600, b67200, b76800 }
                                     ENUMERATED {
MaxNoSCCPCH-RL ::=
                                         rl1 }
MaxNumberOfTF ::=
                                     ENUMERATED {
                                         tf32, tf64, tf128, tf256,
                                         tf512, tf1024 }
                                     ENUMERATED {
MaxNumberOfTFC-DL ::=
                                         tfc16, tfc32, tfc48, tfc64, tfc96,
                                         tfc128, tfc256, tfc512, tfc1024 }
                                     ENUMERATED {
MaxNumberOfTFC-UL ::=
                                         dummy1, dummy2, tfc16, tfc32, tfc48, tfc64,
                                         tfc96, tfc128, tfc256, tfc512, tfc1024 }
-- the values 1 ...4 for MaxPhysChPerFrame are not used in this version of the protocol
MaxPhysChPerFrame ::=
                                     INTEGER (1..224)
MaxPhysChPerSubFrame-r4 ::=
                                    INTEGER (1..96)
MaxPhysChPerTimeslot ::=
                                     ENUMERATED {
                                         ts1, ts2 }
-- the values 1 \dots4 for MaxPhysChPerTS are not used in this version of the protocol
MaxPhysChPerTS ::=
                                     INTEGER (1..16)
MaxSimultaneousCCTrCH-Count ::=
                                    INTEGER (1..8)
MaxSimultaneousTransChsDL ::=
                                    ENUMERATED {
```

```
e4, e8, e16, e32 }
MaxSimultaneousTransChsUL ::=
                                         ENUMERATED {
                                              dummy, e4, e8, e16, e32 }
MaxTransportBlocksDL ::=
                                         ENUMERATED {
                                              tb4, tb8, tb16, tb32, tb48,
                                              tb64, tb96, tb128, tb256, tb512 }
MaxTransportBlocksUL ::=
                                         ENUMERATED {
                                              dummy, tb4, tb8, tb16, tb32, tb48, tb64, tb96, tb128, tb256, tb512 }
MaxTS-PerFrame ::=
                                         INTEGER (1..14)
MaxTS-PerSubFrame-r4 ::=
                                         INTEGER (1..6)
-- TABULAR: MeasurementCapability contains dependencies to UE-MultiModeRAT-Capability,
-- the conditional fields have been left mandatory for now.
MeasurementCapability ::= SEQUENCE {
                                   CompressedModeMeasCapability,
    downlinkCompressedMode
    uplinkCompressedMode
                                              CompressedModeMeasCapability
}
    surementCapabilityExt ::= SEQUENCE{
compressedModeMeasCapabFDDList CompressedModeMeasCapabFDDList compressedModeMeasCapabGSMList compressedModeMeasCapabGSMList compressedModeMeasCapabMC SEQUENCE CompressedModeMeasCapabGSMList CompressedModeMeasCapabMC OPTIONAL OPTIONAL
MeasurementCapabilityExt ::=
                                             CompressedModeMeasCapabGSMList OPTIONAL,
CompressedModeMeasCapabMC OPTIONAL
    compressedModeMeasCapabMC
}
MeasurementCapability-r4-ext ::= SEQUENCE {
    downlinkCompressedMode-LCR
                                             CompressedModeMeasCapability-LCR-r4,
    uplinkCompressedMode-LCR
                                              {\tt Compressed Mode Meas Capability-LCR-r4}
}
                                       BIT STRING (SIZE (32))
MessageAuthenticationCode ::=
                                         ENUMERATED {
MinimumSF-DL ::=
                                             sf1, sf16 }
MinimumSF-UL ::=
                                         ENUMERATED {
                                             sf1, sf2, sf4, sf8, dummy }
MultiModeCapability ::=
                                         ENUMERATED {
                                             tdd, fdd, fdd-tdd }
MultiRAT-Capability ::= SEQUENCE {
    supportOfGSM
                                             BOOLEAN,
    supportOfMulticarrier
}
MultiModeRAT-Capability-v590ext ::= SEQUENCE {
    supportOfUTRAN-ToGERAN-NACC
                                             BOOLEAN
N-300 ::=
                                         INTEGER (0..7)
N-301 ::=
                                         INTEGER (0..7)
N-302 ::=
                                         INTEGER (0..7)
N-304 ::=
                                         INTEGER (0..7)
N-308 ::=
                                         INTEGER (1..8)
N-310 ::=
                                         INTEGER (0..7)
                                         ENUMERATED {
N-312 ::=
                                              s1, s50, s100, s200, s400,
                                              s600, s800, s1000 }
                                         ENUMERATED {
N-312ext ::=
                                             s2, s4, s10, s20 }
                                              ENUMERATED {
N-312-r5 ::=
                                              s1, s2, s4, s10, s20,
s50, s100, s200, s400,
```

```
s600, s800, s1000 }
                                    ENUMERATED {
N-313 ::=
                                        s1, s2, s4, s10, s20,
                                         s50, s100, s200 }
                                    ENUMERATED {
    s1, s50, s100, s200, s400,
N-315 ::=
                                        s600, s800, s1000 }
N-315ext ::=
                                    ENUMERATED {
                                        s2, s4, s10, s20 }
                                        ENUMERATED {
N-315-r5 ::=
                                        s1, s2, s4, s10, s20,
                                        s50, s100, s200, s400,
                                        s600, s800, s1000 }
N-AccessFails ::=
                                    INTEGER (1..64)
                                    INTEGER (1..64)
N-AP-RetransMax ::=
                                    ENUMERATED {
NetworkAssistedGPS-Supported ::=
                                        networkBased,
                                        ue-Based,
                                        bothNetworkAndUE-Based,
                                        noNetworkAssistedGPS }
NF-BO-AllBusy ::=
                                    INTEGER (0..31)
NF-BO-NoAICH ::=
                                    INTEGER (0..31)
NF-BO-Mismatch ::=
                                    INTEGER (0..127)
NS-BO-Busy ::=
                                    INTEGER (0..63)
NS-IP ::=
                                    INTEGER (0..28)
P-TMSI-and-RAI-GSM-MAP ::=
                                    SEQUENCE {
   p-TMSI
                                        P-TMSI-GSM-MAP,
                                        RAI
   rai
}
PagingCause ::=
                                    ENUMERATED {
                                        terminatingConversationalCall,
                                        terminatingStreamingCall,
                                        terminatingInteractiveCall,
                                        terminatingBackgroundCall,
                                        terminatingHighPrioritySignalling,
                                        terminatingLowPrioritySignalling,
                                        terminatingCauseUnknown,
                                        spare
 }
                                    CHOICE {
PagingRecord ::=
    cn-Identity
                                        SEQUENCE {
      pagingCause
                                          PagingCause,
        cn-DomainIdentity
                                            CN-DomainIdentity,
       cn-pagedUE-Identity
                                            CN-PagedUE-Identity
    utran-Identity
                                        SEQUENCE {
                                           U-RNTI,
        cn-OriginatedPage-connectedMode-UE SEQUENCE {
                                                PagingCause,
            pagingCause
            cn-DomainIdentity
                                                CN-DomainIdentity,
            pagingRecordTypeID
                                                PagingRecordTypeID
        }
                                                                             OPTIONAL
    }
}
PagingRecord2-r5 ::=
                                    CHOICE {
    utran-SingleUE-Identity
                                   SEQUENCE {
                                            U-RNTI,
        u-RNTI
        cn-OriginatedPage-connectedMode-UE SEQUENCE {
           pagingCause
                                                PagingCause,
                                                CN-DomainIdentity,
            cn-DomainIdentity
            pagingRecordTypeID
                                                PagingRecordTypeID
```

```
OPTIONAL.
        rrc-ConnectionReleaseInformation
                                            RRC-ConnectionReleaseInformation
                                              SEQUENCE ( SIZE (1 .. maxURNTI-Group) ) OF
    utran-GroupIdentity
                                                  GroupIdentityWithReleaseInformation
}
                           SEQUENCE (SIZE (1..maxPage1)) OF
PagingRecordList ::=
                                         PagingRecord
PagingRecord2List-r5 ::=
                                     SEQUENCE (SIZE (1..maxPage1)) OF
                                         PagingRecord2-r5
PDCP-Capability ::=
                                     SEQUENCE {
    losslessSRNS-RelocationSupport BOOLEAN,
    -- If present, the "maxHcContextSpace" in the IE "PDCP-Capability-r5-ext" overrides the -- "supported" value in this IE. The value in this IE may be used by a pre-REL-5 UTRAN.
    supportForRfc2507
                                         CHOICE {
        notSupported
                                              NULL.
        supported
                                              MaxHcContextSpace
}
PDCP-Capability-r4-ext ::= SEQUENCE {
    supportForRfc3095
                                     CHOICE {
        notSupported
        supported
                                             SEQUENCE {
            maxROHC-ContextSessions
                                                 MaxROHC-ContextSessions-r4 DEFAULT s16,
            reverseCompressionDepth
                                                  INTEGER (0..65535) DEFAULT 0
    }
}
PDCP-Capability-r5-ext ::= SEQUENCE {
    supportForRfc3095ContextRelocation BOOLEAN,
    maxHcContextSpace
                                              MaxHcContextSpace-r5-ext OPTIONAL
}
PhysicalChannelCapability ::= SEQUENCE {
fddPhysChCapability SEQUENCE {
            uplinkPhysChCapability

UL-PhysChCapability

UL-PhysChCapability
           downlinkPhysChCapability
         -- tddPhysChCapability describes the 3.84Mcps TDD physical channel capability
            PhysChCapability SEQUENCE {
  downlinkPhysChCapability DL-Phys
  uplinkPhysChCapability
        tddPhysChCapability
                                                 DL-PhysChCapabilityTDD,
            uplinkPhysChCapability
                                                  UL-PhysChCapabilityTDD
        }
                                                      OPTIONAL
-- PhysicalChannelCapability-LCR-r4 describes the 1.28Mcps TDD physical channel capability
PhysicalChannelCapability-LCR-r4 ::= SEQUENCE {
        tdd128-PhysChCapability
            128-PhysChCapability
downlinkPhysChCapability
                                              SEQUENCE {
                                                  DL-PhysChCapabilityTDD-LCR-r4,
            uplinkPhysChCapability
                                                  UL-PhysChCapabilityTDD-LCR-r4
                                                      OPTIONAL
}
-- PhysicalChannelCapability-hspdsch-r5 describes the HS-PDSCH physical channel capability
{\tt PhysicalChannelCapability-hspdsch-r5} ::= \\ {\tt SEQUENCE} \ \{
                                                      CHOICE {
    fdd-hspdsch
        supported
                                                       SEQUENCE {
            hsdsch-physical-layer-category
                                                             HSDSCH-physical-layer-category,
            supportOfDedicatedPilotsForChannelEstimationOfHSDSCH BOOLEAN,
            -- simultaneousSCCPCH-DPCH-HSDSCH-Reception shall be true only if the
            -- IE SimultaneousSCCPCH-DPCH-Reception indicates support of simultaneous
            -- reception of S-CCPCH and DPCH
            simultaneousSCCPCH-DPCH-HSDSCH-Reception
                                                             BOOLEAN
        },
        unsupported
                                                          NULL
    tdd384-hspdsch
                                                      CHOICE {
                                                          HSDSCH-physical-layer-category,
        supported
        unsupported
                                                          NIII.I.
    tdd128-hspdsch
                                                      CHOICE {
                                                          HSDSCH-physical-layer-category,
        supported
        unsupported
                                                          NULL
```

```
}
PNBSCH-Allocation-r4 ::=
                                      SEQUENCE {
       numberOfRepetitionsPerSFNPeriod ENUMERATED {
                                          c2, c3, c4, c5, c6, c7, c8, c9, c10,
                                          c12, c14, c16, c18, c20, c24, c28, c32,
                                          c36, c40, c48, c56, c64, c72, c80 }
}
ProtocolErrorCause ::=
                                  ENUMERATED {
                                      asn1-ViolationOrEncodingError,
                                      messageTypeNonexistent,
                                      messageNotCompatibleWithReceiverState,
                                       ie-ValueNotComprehended,
                                      informationElementMissing,
                                      messageExtensionNotComprehended,
                                      spare2, spare1 }
ProtocolErrorIndicator ::=
                                  ENUMERATED {
                                      noError, errorOccurred }
ProtocolErrorIndicatorWithMoreInfo ::=
                                  CHOICE {
   noError
                                      NITIT.T.
   errorOccurred
                                      SEQUENCE {
       rrc-TransactionIdentifier
                                         RRC-TransactionIdentifier,
       protocolErrorInformation
                                          ProtocolErrorInformation
}
ProtocolErrorMoreInformation ::=
                                  SEQUENCE {
   diagnosticsType
                                      CHOICE {
                                          CHOICE {
       type1
           asn1-ViolationOrEncodingError
                                           NULL
           messageTypeNonexistent
                                              NULL,
           messageNotCompatibleWithReceiverState
                                              IdentificationOfReceivedMessage,
           ie-ValueNotComprehended
                                              IdentificationOfReceivedMessage,
           messageExtensionNotComprehended
                                              IdentificationOfReceivedMessage,
                                              NULL.
           spare1
           spare2
                                              NULL
       spare
                                          NULL
   }
}
RadioFrequencyBandFDD ::=
                                  ENUMERATED {
   -- fdd2100, fdd1900, fdd1800 correspond to Band I, Band II and Band III respectively
                                      fdd2100,
                                       fdd1900.
                                       fdd1800, spare5, spare4, spare3, spare2, spare1 }
                                  ENUMERATED {spare8, spare7, spare6, spare5,
RadioFrequencyBandFDDSpare ::=
                                              spare4, spare3, spare2, spare1}
RadioFrequencyBandTDDList ::=
                                   ENUMERATED {
                                      a, b, c, ab, ac, bc, abc, spare }
                                  ENUMERATED {a, b, c, spare}
RadioFrequencyBandTDD ::=
                                   ENUMERATED {
RadioFrequencyBandGSM ::=
                                      asm450,
                                      qsm480,
                                      gsm850,
                                      gsm900P,
                                      gsm900E,
                                       qsm1800,
                                      qsm1900,
                                      spare9, spare8, spare7, spare6, spare5,
                                      spare4, spare3, spare2, spare1}
Rb-timer-indicator ::=
                                  SEQUENCE {
   t314-expired
                                      BOOLEAN,
   t315-expired
                                      BOOLEAN }
Re-EstablishmentTimer ::=
                                  ENUMERATED {
```

```
useT314, useT315
}
                                     CHOICE {
RedirectionInfo ::=
    frequencyInfo
                                         FrequencyInfo,
                                         InterRATInfo
    interRATInfo
}
RejectionCause ::=
                                     ENUMERATED {
                                         congestion,
                                         unspecified }
                                     ENUMERATED {
ReleaseCause ::=
                                         normalEvent,
                                         unspecified,
                                         pre-emptiveRelease,
                                         congestion,
                                         re-establishmentReject,
                                         directedsignallingconnectionre-establishment,
                                         userInactivity,
                                         spare }
                                 SEQUENCE {
RF-Capability ::=
        fddRF-Capability
                                        SEQUENCE {
            ue-PowerClass
            ue-PowerClass
txRxFrequencySeparation
                                             UE-PowerClass,
                                             TxRxFrequencySeparation
        tddRF-Capability
                                                     SEQUENCE {
           ue-PowerClass
                                      UE-PowerClass,
            {\tt radioFrequencyTDDB} and {\tt List} \qquad {\tt RadioFrequencyB} and {\tt TDDL} {\tt ist} \,,
            chipRateCapability
                                        ChipRateCapability
                                             OPTIONAL
}
                                       SEQUENCE {
RF-Capability-r4-ext ::=
                                 UE-PowerClass,
                                                     SEQUENCE {
        tddRF-Capability
           ue-PowerClass
            {\tt radioFrequencyBandTDDList} \quad {\tt RadioFrequencyBandTDDList},
            chipRateCapability
                                        ChipRateCapability
        }
                                             OPTIONAL
}
                                    SEQUENCE {
RLC-Capability ::=
    -- If present, the "totalRLC-AM-BufferSize" in the IE "RLC-Capability-r5-ext" overrides the
    -- corresponding value in this IE. The value in this IE may be used by a pre-REL-5 UTRAN.
    totalRLC-AM-BufferSize
                                        TotalRLC-AM-BufferSize,
                                        MaximumRLC-WindowSize,
   maximumRLC-WindowSize
   maximumAM-EntityNumber
                                        MaximumAM-EntityNumberRLC-Cap
RLC-Capability-r5-ext ::=
                                             SEQUENCE {
                                       TotalRLC-AM-BufferSize-r5-ext
    totalRLC-AM-BufferSize
                                                                             OPTIONAL
RRC-ConnectionReleaseInformation ::= CHOICE {
   noRelease
                                             NULL.
    release
                                             SEQUENCE {
        releaseCause
                                                 ReleaseCause
}
RRC-MessageSequenceNumber ::=
                                   INTEGER (0..15)
{\tt RRC-MessageSequenceNumberList} \ ::= \ \ {\tt SEQUENCE} \ ({\tt SIZE} \ ({\tt 4..5})) \ {\tt OF}
                                         RRC-MessageSequenceNumber
RRC-StateIndicator ::=
                                     ENUMERATED {
                                         cell-DCH, cell-FACH, cell-PCH, ura-PCH }
RRC-TransactionIdentifier ::=
                                     INTEGER (0..3)
S-RNTI ::=
                                     BIT STRING (SIZE (20))
S-RNTI-2 ::=
                                     BIT STRING (SIZE (10))
SecurityCapability ::=
                                     SEQUENCE {
                                        BIT STRING {
    cipheringAlgorithmCap
```

```
-- For each bit value '0' means false/ not supported
                                            spare15(0),
                                            spare14(1),
                                            spare13(2),
                                            spare12(3),
                                            spare11(4),
                                            spare10(5),
                                            spare9(6),
                                            spare8(7),
                                            spare7(8),
                                            spare6(9),
                                            spare5(10),
                                            spare4(11),
                                            spare3(12),
                                            spare2(13),
                                            uea1(14),
                                            uea0(15)
                                                (SIZE (16)),
    integrityProtectionAlgorithmCap
                                        BIT STRING {
                                        -- For each bit value '0' means false/ not supported
                                            spare15(0),
                                            spare14(1),
                                            spare13(2),
                                            spare12(3),
                                            spare11(4),
                                            spare10(5),
                                            spare9(6),
                                            spare8(7),
                                            spare7(8),
                                            spare6(9),
                                            spare5(10),
                                            spare4(11),
                                            spare3(12),
                                            spare2(13),
                                            uia1(14),
                                            spare0(15)
                                                 (SIZE (16))
}
SimultaneousSCCPCH-DPCH-Reception ::= CHOICE {
    notSupported
                                        SEQUENCE {
    supported
       maxNoSCCPCH-RL
                                            MaxNoSCCPCH-RL,
        -- simultaneous
SCCPCH-DPCH-DPDCH-Reception is applicable only if
        -- the IE Support of PDSCH = TRUE
        -- Note: the reference to DPDCH in the element name below is incorrect (see tabular). The
        -- name is not changed, to keep it aligned with R99.
        simultaneousSCCPCH-DPCH-DPDCH-Reception
                                                    BOOLEAN
}
SRNC-Identity ::=
                                   BIT STRING (SIZE (12))
START-Value ::=
                                    BIT STRING (SIZE (20))
                                    SEQUENCE (SIZE (1..maxCNdomains)) OF
STARTList ::=
                                        STARTSingle
STARTSingle ::=
                                    SEQUENCE {
                                        CN-DomainIdentity,
    cn-DomainIdentity
    start-Value
                                        START-Value
}
CapabilityUpdateRequirement-r5 ::= SEQUENCE {
    ue-RadioCapabilityFDDUpdateRequirement-FDD BOOLEAN,
    ue-RadioCapabilityTDDUpdateRequirement-TDD384 BOOLEAN,
    ue-RadioCapabilityTDDUpdateRequirement-TDD128
                                                    BOOLEAN,
                                        SystemSpecificCapUpdateReqList-r5 OPTIONAL
    systemSpecificCapUpdateReqList
                                    ENUMERATED {
SystemSpecificCapUpdateReq ::=
                                        gsm }
SystemSpecificCapUpdateReq-v590ext ::=
                                            ENUMERATED {
                                        geranIu }
                                        ENUMERATED {
SystemSpecificCapUpdateReq-r5 ::=
```

```
gsm, geranIu }
SystemSpecificCapUpdateReqList ::= SEQUENCE (SIZE (1..maxSystemCapability)) OF
                                            SystemSpecificCapUpdateReq
SystemSpecificCapUpdateReqList-r5 ::= SEQUENCE (SIZE (1..maxSystemCapability)) OF
                                            SystemSpecificCapUpdateReq-r5
T-300 ::=
                                        ENUMERATED {
                                           ms100, ms200, ms400, ms600, ms800,
                                            {\tt ms1000}\,,\ {\tt ms1200}\,,\ {\tt ms1400}\,,\ {\tt ms1600}\,,
                                            ms1800, ms2000, ms3000, ms4000,
                                            ms6000, ms8000 }
                                        ENUMERATED {
T-301 ::=
                                            ms100, ms200, ms400, ms600, ms800,
                                            ms1000, ms1200, ms1400, ms1600,
                                            ms1800, ms2000, ms3000, ms4000,
                                            ms6000, ms8000, spare }
T-302 ::=
                                        ENUMERATED {
                                            ms100, ms200, ms400, ms600, ms800,
                                            {\tt ms1000,\ ms1200,\ ms1400,\ ms1600,}
                                            ms1800, ms2000, ms3000, ms4000, ms6000, ms8000, spare }
T-304 ::=
                                        ENUMERATED {
                                           ms100, ms200, ms400,
                                            ms1000, ms2000, spare3, spare2, spare1 }
T-305 ::=
                                           noUpdate, m5, m10, m30,
                                            m60, m120, m360, m720 }
                                        ENUMERATED {
T-307 ::=
                                           s5, s10, s15, s20,
s30, s40, s50, spare }
т-308 ::=
                                        ENUMERATED {
                                            ms40, ms80, ms160, ms320 }
T-309 ::=
                                        INTEGER (1..8)
                                        ENUMERATED {
T-310 ::=
                                            ms40, ms80, ms120, ms160, ms200, ms240, ms280, ms320 }
T-311 ::=
                                        ENUMERATED {
                                           ms250, ms500, ms750, ms1000,
                                            ms1250, ms1500, ms1750, ms2000 }
-- The value 0 for T-312 is not used in this version of the specification
                                        INTEGER (0..15)
T-313 ::=
                                        INTEGER (0..15)
T-314 ::=
                                        ENUMERATED {
                                           s0, s2, s4, s6, s8,
s12, s16, s20 }
                                        ENUMERATED {
T-315 ::=
                                           s0, s10, s30, s60, s180,
                                            s600, s1200, s1800 }
                                        ENUMERATED {
T-316 ::=
                                            s0, s10, s20, s30, s40,
                                            s50, s-inf, spare }
-- All the values are changed to "infinity" in Rel-5
T-317 ::=
                                            infinity0, infinity1, infinity2, infinity3, infinity4,
infinity5, infinity6, infinity7}
T-CPCH ::=
                                        ENUMERATED {
                                           ct0, ct1 }
                                       SEQUENCE {
TMSI-and-LAI-GSM-MAP ::=
```

```
tmsi
                                                               TMSI-GSM-MAP,
      lai
}
TMSI-DS-41 ::=
                                                         OCTET STRING (SIZE (2..17))
TotalRLC-AM-BufferSize ::=
                                                        ENUMERATED {
                                                               dummy, kb10, kb50, kb100,
                                                                kb150, kb500, kb1000, spare }
TotalRLC-AM-BufferSize-r5-ext ::= ENUMERATED {
                                                               kb200, kb300, kb400, kb750 }
-- Actual value TransmissionProbability = IE value * 0.125
TransmissionProbability ::= INTEGER (1..8)
TransportChannelCapability ::= SEQUENCE {
    dl-TransChCapability DL-TransChCapability,
    ul-TransChCapability UL-TransChCapability
}
                                                     CHOICE {
TurboSupport ::=
                                                         NULÌ,
    notSupported
      supported
                                                               MaxNoBits
}
TxRxFrequencySeparation ::=
                                                         ENUMERATED {
                                                          mhz190, mhz174-8-205-2,
                                                               mhz134-8-245-2 }
U-RNTI ::=
                                                         SEQUENCE {
                                                             SRNC-Identity,
     srnc-Identity
      s-RNTI
                                                                S-RNTI
U-RNTI-Group ::=
                                                        CHOICE {
-- TABULAR: not following the tabular strictly, but this will most likely save bits
     all
                                                               NULL,
      u-RNTI-BitMaskIndex-b1
                                                               BIT STRING (SIZE (31)),
      u-RNTI-BitMaskIndex-b2
                                                              BIT STRING (SIZE (30)),
                                                   BIT STRING (SIZE (29)),
BIT STRING (SIZE (28)),
BIT STRING (SIZE (27)),
BIT STRING (SIZE (26)),
BIT STRING (SIZE (26)),
BIT STRING (SIZE (26)),
BIT STRING (SIZE (24)),
BIT STRING (SIZE (24)),
BIT STRING (SIZE (22)),
BIT STRING (SIZE (22)),
BIT STRING (SIZE (21)),
BIT STRING (SIZE (20)),
BIT STRING (SIZE (20)),
BIT STRING (SIZE (19)),
BIT STRING (SIZE (19)),
BIT STRING (SIZE (16)),
BIT STRING (SIZE (16)),
BIT STRING (SIZE (16)),
BIT STRING (SIZE (14)),
BIT STRING (SIZE (13)),
BIT STRING (SIZE (12)),
BIT STRING (SIZE (11)),
BIT STRING (SIZE (10)),
BIT STRING (SIZE (6)),
BIT STRING (SIZE (5)),
BIT STRING (SIZE (3)),
BIT STRING (SIZE (3)),
BIT STRING (SIZE (2)),
      u-RNTI-BitMaskIndex-b3
                                                               BIT STRING (SIZE (29)),
      u-RNTI-BitMaskIndex-b4
                                                              BIT STRING (SIZE (28)),
      u-RNTI-BitMaskIndex-b5
u-RNTI-BitMaskIndex-b6
      u-RNTI-BitMaskIndex-b7
      u-RNTI-BitMaskIndex-b8
u-RNTI-BitMaskIndex-b9
      u-RNTI-BitMaskIndex-b10
u-RNTI-BitMaskIndex-b11
      u-RNTI-BitMaskIndex-b12
      u-RNTI-BitMaskIndex-b13
u-RNTI-BitMaskIndex-b14
      u-RNTI-BitMaskIndex-b15
      u-RNTI-BitMaskIndex-b16
u-RNTI-BitMaskIndex-b17
      u-RNTI-BitMaskIndex-b18
u-RNTI-BitMaskIndex-b19
      u-RNTI-BitMaskIndex-b20
      u-RNTI-BitMaskIndex-b21
u-RNTI-BitMaskIndex-b22
      u-RNTI-BitMaskIndex-b23
      u-RNTI-BitMaskIndex-b24
      u-RNTI-BitMaskIndex-b25
      u-RNTI-BitMaskIndex-b26
      u-RNTI-BitMaskIndex-b27
      u-RNTI-BitMaskIndex-b28
      u-RNTI-BitMaskIndex-b29
      u-RNTI-BitMaskIndex-b30
                                                             BIT STRING (SIZE (1))
      u-RNTI-BitMaskIndex-b31
}
U-RNTI-Short ::=
                                                         SEQUENCE {
    srnc-Identity
                                                           SRNC-Identity,
      s-RNTI-2
                                                               S-RNTT-2
UE-ConnTimersAndConstants ::= SEQUENCE {
-- Optional is used also for parameters for which the default value is the last one read in SIB1
```

```
-- t-301 and n-301 should not be used by the UE in this version of the specification
                                         T-301
                                                                              DEFAULT ms2000.
   n-301
                                         N-301
                                                                              DEFAULT 2,
    t-302
                                         T-302
                                                                              DEFAULT ms4000.
   n-302
                                         N - 302
                                                                              DEFAULT 3.
    t-304
                                         T-304
                                                                              DEFAULT ms2000,
    n-304
                                         N-304
                                                                              DEFAULT 2,
                                         T-305
    t-305
                                                                              DEFAULT m30,
    t-307
                                         T - 307
                                                                              DEFAULT s30,
    t-308
                                         T-308
                                                                              DEFAULT ms160,
                                         T-309
    t-309
                                                                              DEFAULT 5,
    t.-310
                                         T - 310
                                                                              DEFAULT ms160.
   n-310
                                         N - 310
                                                                              DEFAULT 4.
    t-311
                                         T-311
                                                                              DEFAULT ms2000,
                                         T-312
                                                                              DEFAULT 1,
    -- n-312 shall be ignored if n-312 in UE-ConnTimersAndConstants-v3a0ext is present, and the
    -- value of that element shall be used instead.
   n-312
                                         M = 312
                                                                              DEFAULT s1,
                                         T-313
    t.-313
                                                                              DEFAULT 3.
                                         N-313
                                                                              DEFAULT s20,
   n-313
                                                                              DEFAULT s12,
    t.-314
                                         T - 314
    t-315
                                         T-315
                                                                              DEFAULT s180,
    -- n-315 shall be ignored if n-315 in UE-ConnTimersAndConstants-v3a0ext is present, and the
    -- value of that element shall be used instead.
    n-315
                                         N-315
                                                                              DEFAULT s1.
    t-316
                                         T-316
                                                                              DEFAULT s30,
    t-317
                                         T-317
                                                                              DEFAULT infinity4
}
UE-ConnTimersAndConstants-v3a0ext ::=
                                            SEQUENCE {
                                         N-312ext
                                                                                  OPTIONAL.
                                                                                  OPTIONAL
                                         N-315ext
}
                                       SEQUENCE {
UE-ConnTimersAndConstants-r5 ::=
-- Optional is used also for parameters for which the default value is the last one read in SIB1
- t -301 and n -301 should not be used by the UE in this version of the specification
   t-301
                                         T-301
                                                                              DEFAULT ms2000.
   n - 301
                                         N = 301
                                                                              DEFAULT 2.
    t-302
                                         T-302
                                                                              DEFAULT ms4000,
    n-302
                                         N-302
                                                                              DEFAULT 3,
    t-304
                                         T-304
                                                                              DEFAULT ms2000,
    n-304
                                                                              DEFAULT 2,
                                         N - 304
    t-305
                                         T-305
                                                                              DEFAULT m30,
    t-307
                                         T-307
                                                                              DEFAULT s30,
    t-308
                                         T-308
                                                                              DEFAULT ms160,
    t-309
                                         T-309
                                                                              DEFAULT 5,
    t-310
                                         T = 310
                                                                              DEFAULT ms160,
   n-310
                                         N-310
                                                                              DEFAULT 4,
                                         T-311
                                                                              DEFAULT ms2000,
    t-311
                                         T-312
                                                                              DEFAULT 1,
    t-312
   n-312
                                         N-312-r5
                                                                              DEFAULT s1.
    t-313
                                         T-313
                                                                              DEFAULT 3,
                                         N-313
                                                                              DEFAULT s20,
    n-313
    t-314
                                         T-314
                                                                              DEFAULT s12,
                                         T - 315
                                                                              DEFAULT s180,
    t-315
    n-315
                                         N-315-r5
                                                                              DEFAULT s1,
    t-316
                                         T-316
                                                                              DEFAULT s30,
    t-317
                                         T-317
                                                                              DEFAULT infinity4
}
UE-IdleTimersAndConstants ::=
                                     SEQUENCE {
                                        T-300,
                                         N-300,
                                         T-312.
    -- n-312 shall be ignored if n-312 in UE-IdleTimersAndConstants-v3a0ext is present, and the
    -- value of that element shall be used instead.
                                        N-312
UE-IdleTimersAndConstants-v3a0ext ::=
                                             SEQUENCE {
                                         N-312ext
                                                                                  OPTIONAL
UE-MultiModeRAT-Capability ::=
                                   SEQUENCE {
                                     MultiRAT-Capability,
   multiRAT-CapabilityList
   multiModeCapability
                                        MultiModeCapability
}
```

```
UE-PowerClass ::=
                                   INTEGER (1..4)
IJE-PowerClassExt ::=
                                   ENUMERATED {class1, class2, class3, class4,
                                         spare4, spare3, spare2, spare1 }
                                   SEQUENCE {
UE-RadioAccessCapability ::=
    -- UE-RadioAccessCapability is compatible with R99, although accessStratumReleaseIndicator
    -- is removed from this IE, since its encoding did not does in bits. The
    -- accessStratumReleaseIndicator is provided in the relevant REL-4 extension IEs.
   pdcp-Capability
                                       PDCP-Capability,
    rlc-Capability
                                       RLC-Capability,
                                     TransportChannelCapability,
    transportChannelCapability
                                      RF-Capability,
    rf-Capability
                                PhysicalChannelCapability,
UE-MultiModeRAT-Capability,
    physicalChannelCapability
    ue-MultiModeRAT-Capability
                                   SecurityCapability,
UE-Positioning
    {\tt securityCapability}
    ue-positioning-Capability
                                       UE-Positioning-Capability,
    measurementCapability
                                      MeasurementCapability
                                                                    OPTIONAL
}
UE-RadioAccessCapabilityInfo ::= SEQUENCE {
    ue-RadioAccessCapability
                                        UE-RadioAccessCapability,
    ue-RadioAccessCapability-v370ext UE-RadioAccessCapability-v370ext
}
UE-RadioAccessCapability-v370ext ::= SEQUENCE {
   ue-RadioAccessCapabBandFDDList
                                       UE-RadioAccessCapabBandFDDList
UE-RadioAccessCapability-v380ext ::=
                                        SEQUENCE {
                                          UE-PositioningCapabilityExt-v380
   ue-PositioningCapabilityExt-v380
UE-RadioAccessCapability-v3a0ext ::=
                                       SEOUENCE {
    ue-PositioningCapabilityExt-v3a0
                                         UE-PositioningCapabilityExt-v3a0
UE-RadioAccessCapability-v3g0ext ::=
                                        SEQUENCE {
   ue-PositioningCapabilityExt-v3g0
                                            UE-PositioningCapabilityExt-v3g0
UE-PositioningCapabilityExt-v380 ::= SEQUENCE {
   rx-tx-TimeDifferenceType2Capable
                                        BOOLEAN
                                       SEQUENCE {
UE-PositioningCapabilityExt-v3a0 ::=
    validity-CellPCH-UraPCH
                                            ENUMERATED { true }
UE-PositioningCapabilityExt-v3g0 ::=
                                        SEOUENCE {
                                        ENUMERATED { true }
    sfn-sfnType2Capability
UE-RadioAccessCapabBandFDDList ::= SEQUENCE (SIZE (1..maxFreqBandsFDD)) OF
                                            UE-RadioAccessCapabBandFDD
UE-RadioAccessCapabBandFDD ::= SEQUENCE{
    radioFrequencyBandFDD
                                       RadioFrequencyBandFDD,
    fddRF-Capability
                                        SEQUENCE {
        ue-PowerClass
                                            UE-PowerClassExt,
        txRxFrequencySeparation
                                            {\tt TxRxFrequencySeparation}
                                                                    OPTIONAL,
    measurementCapability
                                       MeasurementCapabilityExt
}
UE-RadioAccessCapability-v4b0ext ::=
                                        SEQUENCE {
    pdcp-Capability-r4-ext
                                        {\tt PDCP-Capability-r4-ext},\\
                                        SEQUENCE {
    tdd-CapabilityExt
        rf-Capability
                                            RF-Capability-r4-ext,
        physicalChannelCapability-LCR
                                            PhysicalChannelCapability-LCR-r4,
        measurementCapability-r4-ext
                                           MeasurementCapability-r4-ext
                                               OPTIONAL,
    -- IE " AccessStratumReleaseIndicator" is not needed in RRC CONNECTION SETUP COMPLETE
    {\tt accessStratumReleaseIndicator}
                                                AccessStratumReleaseIndicator
}
UE-RadioAccessCapabilityComp ::= SEQUENCE {
```

```
totalAM-RLCMemoryExceeds10kB
                                            BOOLEAN,
    rf-CapabilityComp
                                            RF-CapabilityComp
}
RF-CapabilityComp ::= SEQUENCE {
                            CHOICE {
        not.Support.ed
                                        NULL.
                                        RF-CapabBandListFDDComp
        supported
    tdd384-RF-Capability
                            CHOICE {
       notSupported
                                        NULL.
                                        RadioFrequencyBandTDDList
        supported
    tdd128-RF-Capability
                            CHOICE {
        notSupported
                                        NULL,
        supported
                                        RadioFrequencyBandTDDList
}
RF-CapabBandFDDComp ::= ENUMERATED { notSupported, mhz190,
                                        mhz174-8-205-2, mhz134-8-245-2 }
RF-CapabBandListFDDComp ::= SEQUENCE (SIZE (1..maxFreqBandsFDD)) OF
    -- the first entry corresponds with the first value of IE RadioFrequencyBandFDD,
    -- fdd2100, and so on
   RF-CapabBandFDDComp
UE-RadioAccessCapability-v590ext ::=
                                        SEQUENCE {
    dl-CapabilityWithSimultaneousHS-DSCHConfig DL-CapabilityWithSimultaneousHS-DSCHConfig
    OPTIONAL,
    pdcp-Capability-r5-ext
                                        PDCP-Capability-r5-ext,
    rlc-Capability-r5-ext
                                        RLC-Capability-r5-ext,
    physicalChannelCapability
                                        PhysicalChannelCapability-hspdsch-r5,
    multiModeRAT-Capability-v590ext
                                        MultiModeRAT-Capability-v590ext
}
UL-PhysChCapabilityFDD ::=
                                    SEQUENCE {
    maxNoDPDCH-BitsTransmitted
                                        MaxNoDPDCH-BitsTransmitted,
    supportOfPCPCH
                                        BOOLEAN
}
UL-PhysChCapabilityTDD ::=
                                    SEQUENCE {
                                        MaxTS-PerFrame,
   maxTS-PerFrame
    {\tt maxPhysChPerTimeslot}
                                        MaxPhysChPerTimeslot,
    minimumSF
                                        MinimumSF-UL,
    supportOfPUSCH
}
UL-PhysChCapabilityTDD-LCR-r4 ::=
                                    SEQUENCE {
   maxTS-PerSubFrame
                                        MaxTS-PerSubFrame-r4,
   maxPhysChPerTimeslot
                                        MaxPhysChPerTimeslot,
   minimumSF
                                        MinimumSF-UL,
    supportOfPUSCH
                                        BOOLEAN,
    supportOf8PSK
                                        BOOLEAN
}
UL-TransChCapability ::=
                                    SEQUENCE {
   maxNoBitsTransmitted
                                      MaxNoBits,
    maxConvCodeBitsTransmitted
                                        MaxNoBits,
    turboEncodingSupport
                                        TurboSupport,
    maxSimultaneousTransChs
                                        MaxSimultaneousTransChsUL,
    modeSpecificInfo
                                        CHOICE {
        fdd
                                            NULL.
        tdd
                                            SEOUENCE {
            maxSimultaneousCCTrCH-Count
                                                MaxSimultaneousCCTrCH-Count
   maxTransmittedBlocks
                                        MaxTransportBlocksUL,
                                        MaxNumberOfTFC-UL,
    maxNumberOfTFC
                                        MaxNumberOfTF
    maxNumberOfTF
}
                                    SEQUENCE {
UE-Positioning-Capability ::=
    standaloneLocMethodsSupported
                                            BOOLEAN,
    ue-BasedOTDOA-Supported
                                            BOOLEAN,
    networkAssistedGPS-Supported
                                            NetworkAssistedGPS-Supported,
    supportForUE-GPS-TimingOfCellFrames
                                            BOOLEAN,
                                            BOOLEAN
    supportForIPDL
```

```
}
\mbox{\tt UE-SecurityInformation} ::= \mbox{\tt SEQUENCE} \ \{
                                     START-Value
   start-CS
URA-UpdateCause ::=
                                   ENUMERATED {
                                       changeOfURA.
                                       periodicURAUpdate,
                                       dummy,
                                       spare1 }
UTRAN-DRX-CycleLengthCoefficient ::= INTEGER (3..9)
WaitTime ::=
                                   INTEGER (0..15)
__ ***************
      RADIO BEARER INFORMATION ELEMENTS (10.3.4)
__ ****************
AlgorithmSpecificInfo ::=
                                  CHOICE {
   rfc2507-Info
                                     RFC2507-Info
}
AlgorithmSpecificInfo-r4 ::= rfc2507-Info
                                CHOICE {
                                  RFC2507-Info,
RFC3095-Info-r4
   rfc3095-Info
}
CID-InclusionInfo-r4 ::=
                                   ENUMERATED {
                                     pdcp-Header,
                                       rfc3095-PacketFormat }
 -- Upper limit of COUNT-C is 2^32 - 1
COUNT-C ::=
                                   INTEGER (0..4294967295)
-- Upper limit of COUNT-C-MSB is 2^25 - 1
COUNT-C-MSB ::=
                                   INTEGER (0..33554431)
DefaultConfigIdentity ::=
                                  INTEGER (0..10)
DefaultConfigIdentity-r4 ::=
                                  INTEGER (0..12)
DefaultConfigIdentity-r5 ::=
                                  INTEGER (0..13)
DefaultConfigMode ::=
                                   ENUMERATED {
                                       fdd,
                                       tdd }
                                   SEQUENCE {
DL-AM-RLC-Mode ::=
                                  BOOLEAN,
  inSequenceDelivery
   receivingWindowSize
                                       ReceivingWindowSize,
                                      DL-RLC-StatusInfo
   dl-RLC-StatusInfo
}
DL-AM-RLC-Mode-r5 ::=
                                     SEQUENCE {
                                     OctetModeRLC-SizeInfoType1,
BOOLEAN,
   dl-RLC-PDU-size
   inSequenceDelivery
                                     ReceivingWindowSize,
    receivingWindowSize
   dl-RLC-StatusInfo
                                       DL-RLC-StatusInfo
DL-CounterSynchronisationInfo ::= SEQUENCE {
                                           RB-WithPDCP-InfoList OPTIONAL
   rB-WithPDCP-InfoList
}
DL-CounterSynchronisationInfo-r5 ::= SEQUENCE {
    RB-WithPDCP-InfoList rb-PDCPContextRelocationList RB-PDCPContextRelocation
                                           RB-WithPDCP-InfoList OPTIONAL, RB-PDCPContextRelocationList OPTIONAL
}
DL-LogicalChannelMapping ::=
                                  SEQUENCE {
    -- TABULAR: DL-TransportChannelType contains TransportChannelIdentity as well.
   dl-TransportChannelType DL-TransportChannelType, logicalChannelIdentity LogicalChannelIdentity
}
```

```
DL-LogicalChannelMapping-r5 ::= SEQUENCE {
    -- TABULAR: DL-TransportChannelType contains TransportChannelIdentity as well.
   dl-TransportChannelType DL-TransportChannelType-r5,
                                                                             OPTIONAL
    logicalChannelIdentity
                                        LogicalChannelIdentity
{\tt DL-LogicalChannelMappingList} ::= \\ {\tt SEQUENCE} \ ({\tt SIZE} \ ({\tt 1..maxLoCHperRLC})) \ {\tt OF} \\
                                        DL-LogicalChannelMapping
{\tt DL-LogicalChannelMappingList-r5} \ ::= \ {\tt SEQUENCE} \ ({\tt SIZE} \ ({\tt 1..maxLoCHperRLC})) \ {\tt OF}
                                        DL-LogicalChannelMapping-r5
                                    SEQUENCE {
DL-RFC3095-r4 ::=
   cid-InclusionInfo
                                        CID-InclusionInfo-r4,
    max-CID
                                         INTEGER (1..16383)
                                                                             DEFAULT 15,
                                        INTEGER (0..65535)
                                                                             DEFAULT 0
   reverseDecompressionDepth
}
DL-RLC-Mode ::=
                                    CHOICE {
   dl-AM-RLC-Mode
                                        DL-AM-RLC-Mode,
    dl-UM-RLC-Mode
                                        NULL,
    dl-TM-RLC-Mode
                                        DL-TM-RLC-Mode
DI-RIC-Mode-r5 ::=
                                        CHOICE {
   dl-AM-RLC-Mode-r5
                                        DL-AM-RLC-Mode-r5,
    dl-UM-RLC-Mode-r5
                                        DL-UM-RLC-Mode-r5,
    dl-TM-RLC-Mode
                                        DL-TM-RLC-Mode
}
DL-RLC-StatusInfo ::=
                                    SEQUENCE {
                                       TimerStatusProhibit
   timerStatusProhibit
    -- dummy is not used in this version of the specification, it should not be sent
    \mbox{--} and if received they should be ignored.
                                                                         OPTIONAL,
    dummy
                                    TimerEPC
    missingPDU-Indicator
                                            BOOLEAN,
    timerStatusPeriodic
                                        TimerStatusPeriodic
                                                                             OPTIONAL
}
DL-TM-RLC-Mode ::=
                                    SEQUENCE {
   segmentationIndication
                                            BOOLEAN
DL-TransportChannelType ::=
                                    CHOICE {
                                        TransportChannelIdentity,
    fach
                                         NULL,
                                         TransportChannelIdentity,
    dsch
    dch-and-dsch
                                         TransportChannelIdentityDCHandDSCH
DL-TransportChannelType-r5 ::=
                                        CHOICE {
                                         TransportChannelIdentity,
   dch
    fach
                                         TransportChannelIdentity,
    dsch
   dch-and-dsch
                                        TransportChannelIdentityDCHandDSCH,
                                        MAC-d-FlowIdentity,
   hsdsch
    dch-and-hsdsch
                                        MAC-d-FlowIdentityDCHandHSDSCH
DL-UM-RLC-LT-size ::=
                                        ENUMERATED {
                                        size7, size15 }
DL-UM-RLC-Mode-r5 ::=
                                        SEQUENCE {
   dl-UM-RLC-LI-size
                                        DL-UM-RLC-LI-size
ExpectReordering ::=
                                    ENUMERATED {
                                        reorderingNotExpected,
                                        reorderingExpected }
ExplicitDiscard ::=
                                     SEQUENCE {
   timerMRW
                                        TimerMRW,
    timerDiscard
                                        TimerDiscard,
                                        MaxMRW
   maxMRW
HeaderCompressionInfo ::=
                                   SEQUENCE {
    algorithmSpecificInfo
                                        AlgorithmSpecificInfo
```

```
}
HeaderCompressionInfoList ::= SEQUENCE (SIZE (1..maxPDCPAlgoType)) OF
                                      HeaderCompressionInfo
HeaderCompressionInfo-r4 ::= SEQUENCE {
                                   AlgorithmSpecificInfo-r4
   algorithmSpecificInfo
HeaderCompressionInfoList-r4 ::=
                                   SEQUENCE (SIZE (1..maxPDCPAlgoType)) OF
                                       HeaderCompressionInfo-r4
LogicalChannelIdentity ::=
                                   INTEGER (1..15)
LosslessSRNS-RelocSupport ::=
                                   CHOICE {
                                      MaxPDCP-SN-WindowSize,
  supported
   notSupported
                                       NULL
MAC-d-HFN-initial-value ::=
                                   BIT STRING (SIZE (24))
MAC-LogicalChannelPriority ::=
                                   INTEGER (1..8)
MaxDAT ::=
                                   ENUMERATED {
                                       dat1, dat2, dat3, dat4, dat5, dat6, dat7, dat8, dat9, dat10, dat15, dat20,
                                       dat25, dat30, dat35, dat40 }
MaxDAT-Retransmissions ::=
                                   SEQUENCE {
                                       MaxDAT.
   maxDAT
   timerMRW
                                       TimerMRW,
   maxMRW
                                       MaxMRW
}
MaxMRW ::=
                                    ENUMERATED {
                                       mm1, mm4, mm6, mm8, mm12, mm16,
                                       mm24, mm32 }
MaxPDCP-SN-WindowSize ::=
                                   ENUMERATED {
                                       sn255, sn65535 }
MaxRST ::=
                                    ENUMERATED {
                                       rst1, rst4, rst6, rst8, rst12,
                                       rst16, rst24, rst32 }
NoExplicitDiscard ::=
                                   ENUMERATED {
                                       dt10, dt20, dt30, dt40, dt50,
                                        dt60, dt70, dt80, dt90, dt100 }
PDCP-Info ::=
                                  SEQUENCE {
                                      LosslessSRNS-RelocSupport
   losslessSRNS-RelocSupport
                                                                           OPTIONAL,
    -- TABULAR: pdcp-PDU-Header is MD in the tabular format and it can be encoded
    -- in one bit, so the OPTIONAL is removed for compactness.
                                       PDCP-PDU-Header,
   pdcp-PDU-Header
                                PDCP-PDU-Header,
HeaderCompressionInfoList OPTIONAL
   headerCompressionInfoList
}
PDCP-Info-r4 ::=
                                  SEQUENCE {
   losslessSRNS-RelocSupport
                                       LosslessSRNS-RelocSupport
                                                                          OPTIONAL,
    -- TABULAR: pdcp-PDU-Header is MD in the tabular format and it can be encoded
    \mbox{--} in one bit, so the OPTIONAL is removed for compactness.
    pdcp-PDU-Header
                                       PDCP-PDU-Header,
                                       HeaderCompressionInfoList-r4
   headerCompressionInfoList
}
PDCP-InfoReconfig ::=
                                   SEQUENCE {
   pdcp-Info
                                       PDCP-Info,
    -- dummy is not used in this version of the specification and
    -- it should be ignored.
                                      INTEGER (0..65535)
   dummy
PDCP-InfoReconfig-r4 ::=
                                   SEQUENCE {
                                       PDCP-Info-r4
   pdcp-Info
                                   ENUMERATED {
PDCP-PDU-Header ::=
                                       present, absent }
```

```
INTEGER (0..65535)
PDCP-SN-Info ::=
                                                                    ENUMERATED {
Poll-PDU ::=
                                                                            pdu1, pdu2, pdu4, pdu8, pdu16,
                                                                            pdu32, pdu64, pdu128 }
Poll-SDU ::=
                                                                     ENUMERATED {
                                                                           sdu1, sdu4, sdu16, sdu64 }
PollingInfo ::=
                                                                    SEQUENCE {
                                                                          TimerPollProhibit
TimerPoll
        timerPollProhibit
                                                                                                                                                OPTIONAL.
        timerPoll
                                                                                                                                                OPTIONAL,
       poll-PDU
                                                                         Poll-PDU
                                                                                                                                                OPTIONAL,
       poll-SDU
                                                                           Poll-SDU
                                                                                                                                                OPTIONAL,
       lastTransmissionPDU-Poll
                                                                          BOOLEAN,
       lastRetransmissionPDU-Poll
                                                                        BOOLEAN,
       pollWindow
                                                                           PollWindow
                                                                                                                                               OPTIONAL,
       timerPollPeriodic
                                                                          TimerPollPeriodic
PollWindow ::=
                                                                     ENUMERATED {
                                                                           pw50, pw60, pw70, pw80, pw85,
                                                                            pw90, pw95, pw99 }
PredefinedConfigIdentity ::=
                                                                   INTEGER (0..15)
                                                                    INTEGER (0..15)
PredefinedConfigValueTag ::=
PredefinedRB-Configuration ::= SEQUENCE {
    re-EstablishmentTimer Re-Esta
    srb-InformationList SRB-InformationList RB-InformationList RB-Info
                                                                   Re-EstablishmentTimer,
                                                                           SRB-InformationSetupList,
       rb-InformationList
                                                                           RB-InformationSetupList
}
PreDefRadioConfiguration ::=
                                                                SEQUENCE {
      -- Radio bearer IEs
              predefinedRB-Configuration PredefinedRB-Configuration,
       -- Transport channel IEs
              preDefTransChConfiguration
Physical channel IEs
                                                                              {\tt PreDefTransChConfiguration},
        -- Physical channel IEs
              preDefPhyChConfiguration
                                                                                 PreDefPhyChConfiguration
}
PredefinedConfigStatusList ::=
                                                                                    SEQUENCE (SIZE (maxPredefConfig)) OF
                                                                                    PredefinedConfigStatusInfo
PredefinedConfigStatusInfo ::= CHOICE {
        storedWithValueTagSameAsPrevius NULL,
                                                                           CHOICE {
              notStored
                                                                              NULL,
               storedWithDifferentValueTag
                                                                                   PredefinedConfigValueTag
}
{\tt PredefinedConfigStatusListComp} \; ::= \; {\tt SEQUENCE} \; \; \{ \\
        setsWithDifferentValueTag PredefinedConfigSetsWithDifferentValueTag,
                                                                          PredefinedConfigStatusListVarSz
                                                                                                                                                                OPTIONAL
        otherEntries
PredefinedConfigSetsWithDifferentValueTag ::= SEQUENCE (SIZE (1..2)) OF
                                                                                           {\tt PredefinedConfigSetWithDifferentValueTag}
PredefinedConfigSetWithDifferentValueTag ::= SEQUENCE {
                                                                                           INTEGER (0..10)
      startPosition
                                                                                                                               DEFAULT 0,
        -- numberOfEntries
                                                                                           INTEGER (6..16),
        -- numberOfEntries is covered by the size of the list in IE PredefinedConfigValueTagList
                                                                                           PredefinedConfigValueTagList
       valueTaqList
}
PredefinedConfigValueTagList ::= SEQUENCE (SIZE (1..maxPredefConfig)) OF
                                                                                  PredefinedConfigValueTag
PredefinedConfigStatusListVarSz ::= SEQUENCE (SIZE (1..maxPredefConfig)) OF
                                                                                   PredefinedConfigStatusInfo
RAB-Info ::=
                                                                     SEQUENCE {
```

```
rab-Identity
                                      RAB-Identity,
    cn-DomainIdentity
                                       CN-DomainIdentity,
                                   NAS-Synchronisation-Indicator OPTIONAL,
   nas-Synchronisation-Indicator
   re-EstablishmentTimer
                                      Re-EstablishmentTimer
RAB-InformationList ::=
                                  SEQUENCE (SIZE (1..maxRABsetup)) OF
                                       RAB-Info
RAB-InformationReconfigList ::=
                                   SEQUENCE (SIZE (1.. maxRABsetup)) OF
                                       RAB-InformationReconfig
                                   SEQUENCE {
RAB-InformationReconfig ::=
   rab-Identity
                                      RAB-Identity,
    cn-DomainIdentity
                                       CN-DomainIdentity,
   nas-Synchronisation-Indicator
                                       NAS-Synchronisation-Indicator
}
                                       SEQUENCE {
RAB-Info-Post ::=
                                      RAB-Identity,
   rab-Identity
                                       CN-DomainIdentity,
    cn-DomainIdentity
                                       NAS-Synchronisation-Indicator OPTIONAL
   nas-Synchronisation-Indicator
}
                                  SEQUENCE {
RAB-InformationSetup ::=
                                       RAB-Info.
   rab-Info
   rb-InformationSetupList
                                       RB-InformationSetupList
}
RAB-InformationSetup-r4 ::=
                                   SEQUENCE {
                                       RAB-Info,
   rab-Info
    rb-InformationSetupList
                                       RB-InformationSetupList-r4
RAB-InformationSetup-r5 ::=
                                   SEQUENCE {
   rab-Info
                                       RAB-Info,
   rb-InformationSetupList
                                       RB-InformationSetupList-r5
                                   SEQUENCE (SIZE (1..maxRABsetup)) OF
RAB-InformationSetupList ::=
                                       RAB-InformationSetup
                                   SEQUENCE (SIZE (1..maxRABsetup)) OF
RAB-InformationSetupList-r4 ::=
                                       RAB-InformationSetup-r4
RAB-InformationSetupList-r5 ::=
                                   SEQUENCE (SIZE (1..maxRABsetup)) OF
                                       RAB-InformationSetup-r5
                                   SEQUENCE {
RB-ActivationTimeInfo ::=
   rb-Identity
                                       RB-Identity,
   rlc-SequenceNumber
                                       RLC-SequenceNumber
RB-ActivationTimeInfoList ::=
                                   SEQUENCE (SIZE (1..maxRB)) OF
                                       RB-ActivationTimeInfo
RB-COUNT-C-Information ::=
                                   SEQUENCE {
   rb-Identity
                                       RB-Identity,
    count-C-UL
                                       COUNT-C,
   count-C-DL
                                       COUNT-C
}
RB-COUNT-C-InformationList ::=
                                   SEQUENCE (SIZE (1..maxRBallRABs)) OF
                                      RB-COUNT-C-Information
RB-COUNT-C-MSB-Information ::=
                                   SEQUENCE {
    rb-Identity
                                       RB-Identity,
    count-C-MSB-UL
                                       COUNT-C-MSB,
    count-C-MSB-DL
                                       COUNT-C-MSB
RB-COUNT-C-MSB-InformationList ::= SEQUENCE (SIZE (1..maxRBallRABs)) OF
                                       RB-COUNT-C-MSB-Information
                                   INTEGER (1..32)
RB-Identity ::=
RB-IdentityList ::=
                                   SEQUENCE (SIZE (1..maxRB)) OF
                                       RB-Identity
```

```
RB-InformationAffected ::=
                                 SEQUENCE {
                                      RB-Identity,
   rb-Identity
                                      RB-MappingInfo
   rb-MappingInfo
}
RB-InformationAffected-r5 ::=
                                   SEQUENCE {
   rb-Identity
                                       RB-Identity,
   rb-MappingInfo
                                       RB-MappingInfo-r5
RB-InformationAffectedList ::=
                                   SEQUENCE (SIZE (1..maxRB)) OF
                                       RB-InformationAffected
RB-InformationAffectedList-r5 ::=
                                   SEQUENCE (SIZE (1..maxRB)) OF
                                      RB-InformationAffected-r5
RB-InformationReconfig ::=
                                   SEQUENCE {
   rb-Identity
                                      RB-Identity,
   pdcp-Info
                                      PDCP-InfoReconfig
                                                                          OPTIONAL,
   pdcp-SN-Info
                                      PDCP-SN-Info
                                                                          OPTIONAL,
                                      RLC-Info
   rlc-Info
                                                                          OPTIONAL,
   rb-MappingInfo
                                      RB-MappingInfo
                                                                          OPTIONAL,
   rb-StopContinue
                                      RB-StopContinue
                                                                          OPTIONAL
}
RB-InformationReconfig-r4 ::=
                                  SEQUENCE {
   rb-Identity
                                      RB-Identity,
   pdcp-Info
                                       PDCP-InfoReconfig-r4
                                                                          OPTIONAL,
   pdcp-SN-Info
                                      PDCP-SN-Info
                                                                          OPTIONAL,
   rlc-Info
                                                                          OPTIONAL,
                                      RLC-Info
   rb-MappingInfo
                                       RB-MappingInfo
                                                                          OPTIONAL,
   rb-StopContinue
                                      RB-StopContinue
                                                                          OPTIONAL
}
RB-InformationReconfig-r5 ::= SEQUENCE {
   rb-Identity
                                      RB-Identity,
   pdcp-Info
                                      PDCP-InfoReconfig-r4
                                                                         OPTIONAL,
   pdcp-SN-Info
                                      PDCP-SN-Info
                                                                         OPTIONAL,
   rlc-Info
                                      RLC-Info-r5
                                                                         OPTIONAL,
   rb-MappingInfo
                                       RB-MappingInfo-r5
                                                                          OPTIONAL,
   rb-StopContinue
                                      RB-StopContinue
                                                                          OPTIONAL
}
RB-InformationReconfigList ::= SEQUENCE (SIZE (1..maxRB)) OF
                                      RB-InformationReconfig
RB-InformationReconfigList-r4 ::= SEQUENCE (SIZE (1..maxRB)) OF
                                       RB-InformationReconfig-r4
                                   SEQUENCE (SIZE (1..maxRB)) OF
RB-InformationReconfigList-r5 ::=
                                       RB-InformationReconfig-r5
RB-InformationReleaseList ::=
                                   SEQUENCE (SIZE (1..maxRB)) OF
                                      RB-Identity
                                   SEQUENCE {
RB-InformationSetup ::=
   rb-Identity
                                      RB-Identity,
   pdcp-Info
                                       PDCP-Info
                                                                          OPTIONAL,
   rlc-InfoChoice
                                       RLC-InfoChoice,
   rb-MappingInfo
                                      RB-MappingInfo
}
RB-InformationSetup-r4 ::=
                                  SEQUENCE {
   rb-Identity
                                      RB-Identity,
                                       PDCP-Info-r4
   pdcp-Info
                                                                         OPTIONAL.
   rlc-InfoChoice
                                       RLC-InfoChoice,
   rb-MappingInfo
                                      RB-MappingInfo
}
RB-InformationSetup-r5 ::=
                                  SEQUENCE {
   rb-Identity
                                      RB-Identity,
   pdcp-Info
                                       PDCP-Info-r4
                                                                          OPTIONAL,
   rlc-InfoChoice
                                       RLC-InfoChoice-r5,
   rb-MappingInfo
                                      RB-MappingInfo-r5
}
RB-InformationSetupList ::=
                                 SEQUENCE (SIZE (1..maxRBperRAB)) OF
                                       RB-InformationSetup
```

```
RB-InformationSetupList-r4 ::= SEQUENCE (SIZE (1..maxRBperRAB)) OF
                                       RB-InformationSetup-r4
RB-InformationSetupList-r5 ::= SEQUENCE (SIZE (1..maxRBperRAB)) OF
                                       RB-InformationSetup-r5
                                   SEQUENCE (SIZE (1..maxRBMuxOptions)) OF
RB-MappingInfo ::=
                                        RB-MappingOption
RB-MappingInfo-r5 ::=
                                        SEQUENCE (SIZE (1..maxRBMuxOptions)) OF
                                        RB-MappingOption-r5
RB-MappingOption ::=
                                   SEQUENCE {
   ul-LogicalChannelMappings
                                       UL-LogicalChannelMappings
                                                                            OPTIONAL,
                                        UL-LogicalChannelMappings OPTIONAL DL-LogicalChannelMappingList OPTIONAL
    dl-LogicalChannelMappingList
}
RB-MappingOption-r5 ::=
                                       SEQUENCE {
   ul-LogicalChannelMappings
   ul-LogicalChannelMappings UL-LogicalChannelMappings DL-LogicalChannelMappingList-r5
                                                                            OPTIONAL,
                                                                            OPTIONAL
}
RB-PDCPContextRelocation ::=
                                      SEQUENCE {
   rb-Identity
dl-RFC3095-Context-Relocation
ul-RFC3095-Context-Relocation
                                          RB-Identity,
                                            BOOLEAN,
                                          BOOLEAN
}
RB-PDCPContextRelocationList ::=
                                            SEQUENCE (SIZE (1..maxRBallRABs)) OF
                                            RB-PDCPContextRelocation
RB-StopContinue ::=
                                   ENUMERATED {
                                       stopRB, continueRB }
RB-WithPDCP-Info ::=
                                    SEQUENCE {
   rb-Identity
                                       RB-Identity,
   pdcp-SN-Info
                                        PDCP-SN-Info
RB-WithPDCP-InfoList ::=
                                    SEQUENCE (SIZE (1..maxRBallRABs)) OF
                                       RB-WithPDCP-Info
ReceivingWindowSize ::=
                                    ENUMERATED {
                                       rw1, rw8, rw16, rw32, rw64, rw128, rw256,
                                        rw512, rw768, rw1024, rw1536, rw2047,
                                        rw2560, rw3072, rw3584, rw4095 }
RFC2507-Info ::=
                                    SEQUENCE {
                                       INTEGER (1..65535)
  f-MAX-PERIOD
                                                                           DEFAULT 256,
                                        INTEGER (1..255)
INTEGER (60..65535)
   f-MAX-TIME
                                                                            DEFAULT 5,
                                                                            DEFAULT 168,
   max-HEADER
   tcp-SPACE
                                        INTEGER (3..255)
                                                                            DEFAULT 15,
                                        INTEGER (3..65535)
   -- TABULAR: expectReordering has only two possible values, so using Optional or Default
    -- would be wasteful
    expectReordering
                                        ExpectReordering
}
RFC3095-Info-r4 ::=
                              SEQUENCE {
                                       ROHC-ProfileList-r4,
    rohcProfileList
    ul-RFC3095
                                        UL-RFC3095-r4
                                                                            OPTIONAL,
   dl-RFC3095
                                       DL-RFC3095-r4
                                                                            OPTIONAL
}
RLC-Info ::=
                                    SEQUENCE {
   ul-RLC-Mode
                                        UL-RLC-Mode
                                                                            OPTIONAL,
   dl-RLC-Mode
                                        DL-RLC-Mode
                                                                            OPTIONAL
}
RLC-Info-r5 ::=
                                    SEQUENCE {
   ul-RLC-Mode
                                       UL-RLC-Mode
                                                                            OPTIONAL,
   dl-RLC-Mode-r5
                                       DL-RLC-Mode-r5
                                                                            OPTIONAL,
   rlc-OneSidedReEst
                                       BOOLEAN
RLC-InfoChoice ::=
                                    CHOICE {
   rlc-Info
                                        RLC-Info,
```

```
same-as-RB
                                         RB-Identity
}
RLC-InfoChoice-r5 ::=
                                         CHOICE {
   rlc-Info-r5
                                          RLC-Info-r5,
                                         RB-Identity
    same-as-RB
}
                                    INTEGER (0..4095)
RLC-SequenceNumber ::=
RLC-SizeInfo ::=
                                    SEQUENCE {
                                         INTEGER (1..maxTF)
   rlc-SizeIndex
RLC-SizeExplicitList ::=
                                   SEQUENCE (SIZE (1..maxTF)) OF
                                        RLC-SizeInfo
ROHC-Profile-r4 ::=
                                     INTEGER (1..3)
ROHC-ProfileList-r4 ::=
                                  SEQUENCE (SIZE (1..maxROHC-Profile-r4)) OF
                                         ROHC-Profile-r4
ROHC-PacketSize-r4 ::=
                                     INTEGER (2..1500)
                                  SEQUENCE (SIZE (1..maxROHC-PacketSizes-r4)) OF
ROHC-PacketSizeList-r4 ::=
                                        ROHC-PacketSize-r4
SRB-InformationSetup ::= SEQUENCE {
   -- The default value for rb-Identity is the smallest value not used yet.
                                         RB-Identity
                                                                               OPTIONAL.
   rb-Identity
    rlc-InfoChoice
                                         RLC-InfoChoice,
   rb-MappingInfo
                                         RB-MappingInfo
}
SRB-InformationSetup-r5 ::= SEQUENCE {
    -- The default value for rb-Identity is the smallest value not used yet.
    rb-Identity
                                        RB-Identity
                                                                               OPTIONAL,
   rlc-InfoChoice
                                         RLC-InfoChoice-r5,
   rb-MappingInfo
                                         RB-MappingInfo-r5
                                    SEQUENCE (SIZE (1..maxSRBsetup)) OF
SRB-InformationSetupList ::=
                                         SRB-InformationSetup
SRB-InformationSetupList-r5 ::=
                                     SEQUENCE (SIZE (1..maxSRBsetup)) OF
                                         SRB-InformationSetup-r5
SRB-InformationSetupList2 ::=
                                     SEQUENCE (SIZE (3..4)) OF
                                         SRB-InformationSetup
TimerDiscard ::=
                                     ENUMERATED {
                                         td0-1, td0-25, td0-5, td0-75,
                                         td1, td1-25, td1-5, td1-75,
td2, td2-5, td3, td3-5, td4,
                                         td4-5, td5, td7-5 }
TimerEPC ::=
                                     ENUMERATED {
                                         te50, te60, te70, te80, te90,
                                         te100, te120, te140, te160, te180, te200, te300, te400, te500, te700,
                                          te900 }
TimerMRW ::=
                                     ENUMERATED {
                                         te50, te60, te70, te80, te90, te100,
                                          tel20, tel40, tel60, tel80, te200,
                                         te300, te400, te500, te700, te900 }
TimerPoll ::=
                                     ENUMERATED {
                                         tp10, tp20, tp30, tp40, tp50, tp60, tp70, tp80, tp90, tp100,
                                          tp110, tp120, tp130, tp140, tp150,
                                          tp160, tp170, tp180, tp190, tp200, tp210, tp220, tp230, tp240, tp250,
                                          tp260, tp270, tp280, tp290, tp300,
                                          tp310, tp320, tp330, tp340, tp350,
                                          tp360, tp370, tp380, tp390, tp400,
                                          tp410, tp420, tp430, tp440, tp450, tp460, tp470, tp480, tp490, tp500,
```

```
tp510, tp520, tp530, tp540, tp550,
                                            tp600, tp650, tp700, tp750, tp800, tp850, tp900, tp950, tp1000 }
TimerPollPeriodic ::=
                                        ENUMERATED {
                                            tper100, tper200, tper300, tper400,
                                            tper500, tper750, tper1000, tper2000 }
TimerPollProhibit ::=
                                        ENUMERATED {
                                            tpp10, tpp20, tpp30, tpp40, tpp50,
                                            tpp60, tpp70, tpp80, tpp90, tpp100,
                                            tpp110, tpp120, tpp130, tpp140, tpp150, tpp160, tpp170, tpp180, tpp190, tpp200,
                                            tpp210, tpp220, tpp230, tpp240, tpp250,
                                            tpp260, tpp270, tpp280, tpp290, tpp300,
                                            tpp310, tpp320, tpp330, tpp340, tpp350,
                                            tpp360, tpp370, tpp380, tpp390, tpp400, tpp410, tpp420, tpp430, tpp440, tpp450,
                                            tpp460, tpp470, tpp480, tpp490, tpp500,
                                            tpp510, tpp520, tpp530, tpp540, tpp550, tpp600, tpp650, tpp700, tpp750, tpp800,
                                            tpp850, tpp900, tpp950, tpp1000 }
TimerRST ::=
                                        ENUMERATED {
                                            tr50, tr100, tr150, tr200, tr250, tr300, tr350, tr400, tr450, tr500, tr550,
                                            tr600, tr700, tr800, tr900, tr1000 }
                                        ENUMERATED {
TimerStatusPeriodic ::=
                                            tsp100, tsp200, tsp300, tsp400, tsp500, tsp750, tsp1000, tsp2000 }
TimerStatusProhibit ::=
                                        ENUMERATED {
                                            tsp10,tsp20,tsp30,tsp40,tsp50,
                                            tsp60,tsp70,tsp80,tsp90,tsp100,
                                            tsp110,tsp120,tsp130,tsp140,tsp150,
                                            tsp160,tsp170,tsp180,tsp190,tsp200,
                                            tsp210,tsp220,tsp230,tsp240,tsp250,
                                            tsp260,tsp270,tsp280,tsp290,tsp300,
                                            tsp310,tsp320,tsp330,tsp340,tsp350,
                                            tsp360,tsp370,tsp380,tsp390,tsp400,
                                            tsp410,tsp420,tsp430,tsp440,tsp450,
                                            tsp460,tsp470,tsp480,tsp490,tsp500,
                                            tsp510,tsp520,tsp530,tsp540,tsp550,
                                            tsp600,tsp650,tsp700,tsp750,tsp800,
                                            tsp850,tsp900,tsp950,tsp1000 }
TransmissionRLC-Discard ::=
                                      CHOICE {
    timerBasedExplicit
                                            ExplicitDiscard,
    timerBasedNoExplicit
                                            NoExplicitDiscard,
    maxDAT-Retransmissions
                                            MaxDAT-Retransmissions,
    noDiscard
                                            MaxDAT
}
TransmissionWindowSize ::=
                                        ENUMERATED {
                                            tw1, tw8, tw16, tw32, tw64, tw128, tw256, tw512, tw768, tw1024, tw1536, tw2047,
                                            tw2560, tw3072, tw3584, tw4095 }
III.-AM-RIC-Mode ::=
                                        SEQUENCE {
    transmissionRLC-Discard
                                            TransmissionRLC-Discard,
    transmissionWindowSize
                                            TransmissionWindowSize,
    timerRST
                                            TimerRST,
    max-RST
                                            MaxRST,
                                                                                    OPTIONAL
    pollingInfo
                                            PollingInfo
}
UL-CounterSynchronisationInfo ::=
                                          SEQUENCE {
    rB-WithPDCP-InfoList
                                                 RB-WithPDCP-InfoList OPTIONAL,
    startList
                                                 STARTList
UL-LogicalChannelMapping ::=
                                       SEOUENCE {
    -- TABULAR: UL-TransportChannelType contains TransportChannelIdentity as well.
    ul-TransportChannelType
                                            UL-TransportChannelType,
                                            LogicalChannelIdentity
    logicalChannelIdentity
    rlc-SizeList
                                            CHOICE {
        allSizes
                                                 NULL,
```

```
configured
                                                                                 NULL,
              explicitList
                                                                                   RLC-SizeExplicitList
       mac-LogicalChannelPriority MAC-LogicalChannelPriority
UL-LogicalChannelMappingList ::= SEQUENCE {
        -- rlc-LogicalChannelMappingIndicator shall be set to TRUE in this version
        -- of the specification
       {\tt rlc-LogicalChannelMappingIndicator} \quad {\tt BOOLEAN},
       ul-LogicalChannelMapping
                                                                           SEQUENCE (SIZE (maxLoCHperRLC)) OF
                                                                            UL-LogicalChannelMapping
}
UL-LogicalChannelMapping,
      twoLogicalChannels
                                                                           UL-LogicalChannelMappingList
}
UL-RFC3095-r4 ::=
                                                                    SEQUENCE {
      cid-InclusionInfo
                                                                     CID-InclusionInfo-r4,
                                                                                                                                               DEFAULT 15,
       max-CID
                                                                            INTEGER (1..16383)
       rohcPacketSizeList
                                                                            ROHC-PacketSizeList-r4
}
                                                                   CHOICE {
UL-RLC-Mode ::=
      ul-AM-RLC-Mode
                                                                        UL-AM-RLC-Mode,
       ul-UM-RLC-Mode
                                                                            UL-UM-RLC-Mode,
      ul-TM-RLC-Mode
                                                                           UL-TM-RLC-Mode,
                                                                           NULL
       spare
}
       transmissionRLC-Discard Transm
UL-TM-RLC-Mode ::=
                                                                  TransmissionRLC-Discard OPTIONAL, BOOLEAN
       transmissionRLC-Discard SEQUENCE {
UL-UM-RLC-Mode ::=
                                                                        TransmissionRLC-Discard OPTIONAL
}
UL-TransportChannelType ::= CHOICE {
                                                                            TransportChannelIdentity,
       rach
       cpch
                                                                             NULL,
                                                                            TransportChannelIdentity
       usch
}
 __ **************
           TRANSPORT CHANNEL INFORMATION ELEMENTS (10.3.5)
__ ****************
AddOrReconfMAC-dFlow ::=
                                                                 SEQUENCE {
       mac-hs-AddReconfQueue-List
                                                                                            MAC-hs-AddReconfQueue-List OPTIONAL,
       mac-hs-DelQueue-List
                                                                                           MAC-hs-DelQueue-List OPTIONAL
}
AllowedTFC-List ::=
                                                                     SEQUENCE (SIZE (1..maxTFC)) OF
                                                                            TFC-Value
AllowedTFI-List ::=
                                                                     SEQUENCE (SIZE (1..maxTF)) OF
                                                                           INTEGER (0..31)
BitModeRLC-SizeInfo ::=
                                                                    CHOICE {
                                                                          INTEGER (0..127),
       sizeType1
        -- Actual value sizeType2 = (part1 * 8) + 128 + part2
                                                                            SEQUENCE {
        sizeType2
                                                                                   INTEGER (0..15),
               part2
                                                                                    INTEGER (1..7)
                                                                                                                                                 OPTIONAL
        -- Actual value sizeType3 = (part1 * 16) + 256 + part2
        sizeType3
                                                                             SEQUENCE {
                                                                                    INTEGER (0..47),
            part1
               part2
                                                                                    INTEGER (1..15)
                                                                                                                                               OPTIONAL
        },
```

```
-- Actual value sizeType4 = (part1 * 64) + 1024 + part2
    sizeType4
                                          SEQUENCE {
                                              INTEGER (0..62),
        part1
                                              INTEGER (1..63)
                                                                               OPTIONAL
        part2
    }
}
-- Actual value BLER-QualityValue = IE value * 0.1
BLER-QualityValue ::=
                                     INTEGER (-63..0)
ChannelCodingType ::=
                                     CHOICE {
    -- noCoding is only used for TDD in this version of the specification, -- otherwise it should be ignored
    noCoding
                                          NULL,
    convolutional
                                          CodingRate,
    turbo
                                          NULL
}
CodingRate ::=
                                      ENUMERATED {
                                          half,
                                          third }
CommonDynamicTF-Info ::=
                                      SEQUENCE {
                                         CHOICE {
    rlc-Size
                                              SEQUENCE {
        fdd
            octetModeRLC-SizeInfoType2
                                                 OctetModeRLC-SizeInfoType2
                bitModeRLC-SizeInfo BitModeRLC-SizeInfo, octetModeRLC-SizeInfoTypel OctetModeRLC-SizeInfoTypel
            commonTDD-Choice
                bitModeRLC-SizeInfo
                                                      OctetModeRLC-SizeInfoType1
        }
                                      SEQUENCE (SIZE (1..maxTF)) OF
    numberOfTbSizeList
                                             NumberOfTransportBlocks,
    logicalChannelList
                                      LogicalChannelList
}
CommonDynamicTF-Info-DynamicTTI ::= SEQUENCE {
    commonTDD-Choice
        bitModeRLC-SizeInfo BitModeRLC-SizeInfo, octetModeRLC-SizeInfoType1 OctetModeRLC-SizeInfoType1
       bitModeRLC-SizeInfo
                                 NumberOfTbSizeAndTTIList,
    numberOfTbSizeAndTTIList
    logicalChannelList
                                         LogicalChannelList
}
CommonDynamicTF-InfoList ::= SEQUENCE (SIZE (1..maxTF)) OF
                                         CommonDynamicTF-Info
{\tt CommonDynamicTF-InfoList-DynamicTTI} \ ::= \ {\tt SEQUENCE} \ ({\tt SIZE} \ ({\tt 1..maxTF})) \ {\tt OF}
                                          CommonDynamicTF-Info-DynamicTTI
CommonTransChTFS ::=
                                      SEQUENCE {
                                          CHOICE {
    tti
        tti10
                                               CommonDynamicTF-InfoList,
        tti20
                                               CommonDynamicTF-InfoList,
        tti40
                                              CommonDynamicTF-InfoList,
                                              CommonDynamicTF-InfoList,
        tti80
        dynamic
                                              CommonDynamicTF-InfoList-DynamicTTI
    semistaticTF-Information
                                          SemistaticTF-Information
}
CommonTransChTFS-LCR ::=
                                          SEQUENCE {
    tti
                                          CHOICE {
                                              CommonDynamicTF-InfoList,
                                              CommonDynamicTF-InfoList,
        tti10
        tti20
                                              CommonDynamicTF-InfoList,
        tti40
                                              CommonDynamicTF-InfoList,
        tti80
                                              CommonDynamicTF-InfoList,
                                              CommonDynamicTF-InfoList-DynamicTTI
        dynamic
    semistaticTF-Information
                                        SemistaticTF-Information
CPCH-SetID ::=
                                     INTEGER (1..maxCPCHsets)
```

```
CRC-Size ::=
                                    ENUMERATED {
                                        crc0, crc8, crc12, crc16, crc24 }
DedicatedDynamicTF-Info ::=
                                    SEQUENCE {
   rlc-Size
                                       CHOICE {
       bitMode
                                            BitModeRLC-SizeInfo,
       octetModeType1
                                            OctetModeRLC-SizeInfoType1
    numberOfTbSizeList
                                    SEQUENCE (SIZE (1..maxTF)) OF
    NumberOfTransportBlocks,
                                    LogicalChannelList
    logicalChannelList
}
DedicatedDynamicTF-Info-DynamicTTI ::= SEQUENCE {
   rlc-Size
                                       CHOICE {
       bitMode
                                            BitModeRLC-SizeInfo,
       octetModeType1
                                            OctetModeRLC-SizeInfoType1
    numberOfTbSizeAndTTIList
                                        NumberOfTbSizeAndTTIList,
    logicalChannelList
                                   LogicalChannelList
DedicatedDynamicTF-InfoList ::= SEQUENCE (SIZE (1..maxTF)) OF
                                        DedicatedDynamicTF-Info
DedicatedDynamicTF-InfoList-DynamicTTI ::= SEQUENCE (SIZE (1..maxTF)) OF
                                        DedicatedDynamicTF-Info-DynamicTTI
DedicatedTransChTFS ::=
                                   SEOUENCE
                                        CHOICE {
        tti10
                                            DedicatedDynamicTF-InfoList,
        tti20
                                            DedicatedDynamicTF-InfoList,
                                            DedicatedDynamicTF-InfoList,
        t.t.i40
        tti80
                                            DedicatedDynamicTF-InfoList,
        dvnamic
                                            DedicatedDynamicTF-InfoList-DynamicTTI
    },
    semistaticTF-Information
                                        SemistaticTF-Information
}
 - The maximum allowed size of DL-AddReconfTransChInfo2List sequence is 16
DL-AddReconfTransChInfo2List ::= SEQUENCE (SIZE (1..maxTrCHpreconf)) OF
                                        DL-AddReconfTransChInformation2
-- The maximum allowed size of DL-AddReconfTransChInfoList sequence is 16
DL-AddReconfTransChInfoList ::= SEQUENCE (SIZE (1..maxTrCHpreconf)) OF
                                        DL-AddReconfTransChInformation
-- The maximum allowed size of DL-AddReconfTransChInfoList-r4 sequence is 16
DL-AddReconfTransChInfoList-r4 ::= SEQUENCE (SIZE (1..maxTrCHpreconf)) OF
                                        DL-AddReconfTransChInformation-r4
-- The maximum allowed size of DL-AddReconfTransChInfoList-r5 sequence is 16
DL-AddReconfTransChInfoList-r5 ::= SEQUENCE (SIZE (1..maxTrCHpreconf)) OF
                                        DL-AddReconfTransChInformation-r5
-- ASN.1 for IE "Added or Reconfigured DL TrCH information"
-- in case of messages other than: Radio Bearer Release message and
-- Radio Bearer Reconfiguration message
DL-AddReconfTransChInformation ::= SEQUENCE {
   dl-transportChannelType DL-TrCH-Type, dl-transportChannelIdentity TransportChannelType CHOICE {
                                        TransportChannelIdentity,
       explicit-config
                                            TransportFormatSet,
       sameAsULTrCH
                                            UL-TransportChannelIdentity
    dch-QualityTarget
                                        QualityTarget
                                                                             OPTIONAL,
    -- dummy is not used in this version of the specification, it should
    -- not be sent and if received it should be ignored.
    dummy
                                        TM-SignallingInfo
                                                                            OPTIONAL
DL-AddReconfTransChInformation-r4 ::= SEQUENCE {
                                      DL-TrCH-Type,
    dl-TransportChannelType
    dl-transportChannelIdentity
                                        TransportChannelIdentity,
    tfs-SignallingMode
        explicit-config
                                            TransportFormatSet.
        sameAsULTrCH
                                            UL-TransportChannelIdentity
```

```
OPTIONAL
    dch-QualityTarget
                                         QualityTarget
}
DL-AddReconfTransChInformation-r5 ::=
                                        SEQUENCE {
    dl-TransportChannelType
                                         DL-TrCH-TypeId1-r5,
    tfs-SignallingMode
                                         CHOICE {
        explicit-config
                                             TransportFormatSet,
        sameAsULTrCH
                                             UL-TransportChannelIdentity,
        hsdsch
                                             HSDSCH-Info
    dch-QualityTarget
                                                                              OPTIONAL
                                         QualityTarget
}
-- ASN.1 for IE "Added or Reconfigured DL TrCH information"
-- in case of Radio Bearer Release message and
-- Radio Bearer Reconfiguration message
DL-AddReconfTransChInformation2 ::= SEQUENCE {
    dl-TransportChannelType
                                        DL-TrCH-Type,
    transportChannelIdentity
                                         TransportChannelIdentity,
    tfs-SignallingMode
                                         CHOICE {
        explicit-config
                                             TransportFormatSet,
        sameAsULTrCH
                                             UL-TransportChannelIdentity
    qualityTarget
                                         QualityTarget
                                                                              OPTIONAL
}
DL-CommonTransChInfo ::=
                                    SEQUENCE {
    sccpch-TFCS
                                        TFCS
    -- modeSpecificInfo should be optional. A new version of this IE should be defined
    -- to be used in later versions of messages using this {\tt IE}
    modeSpecificInfo
                                        CHOICE {
        fdd
                                             SEQUENCE {
            dl-Parameters
                                                 CHOICE {
                dl-DCH-TFCS
                                                     TFCS.
                sameAsUL
                                                     NULL
                                                                              OPTIONAL
        },
                                             SEQUENCE {
        tdd
            individualDL-CCTrCH-InfoList
                                                 IndividualDL-CCTrCH-InfoList
                                                                              OPTIONAL
        }
    }
}
DL-CommonTransChInfo-r4 ::=
                                    SEQUENCE {
    sccpch-TFCS
                                         TFCS
                                                                              OPTIONAL.
    modeSpecificInfo
                                         CHOICE {
        fdd
                                             SEQUENCE {
            dl-Parameters
                                                 CHOICE {
                dl-DCH-TFCS
                                                     SEQUENCE {
                    tfcs
                                                                              OPTIONAL.
                                                         TFCS
                                                     NULL
                sameAsUL
            }
                                                                              OPTIONAL
        },
                                             SEOUENCE {
            individualDL-CCTrCH-InfoList
                                                 IndividualDL-CCTrCH-InfoList
                                                                              OPTIONAL
        OPTIONAL
DL-DeletedTransChInfoList ::=
                                    SEQUENCE (SIZE (1..maxTrCH)) OF
                                         {\tt DL-TransportChannelIdentity}
DL-DeletedTransChInfoList-r5 ::=
                                    SEQUENCE (SIZE (1..maxTrCH)) OF
                                        DL-TransportChannelIdentity-r5
DL-TransportChannelIdentity ::=
                                         SEQUENCE {
    dl-TransportChannelType
                                         DL-TrCH-Type,
    dl-TransportChannelIdentity
                                        TransportChannelIdentity
}
DL-TransportChannelIdentity-r5 ::=
                                        SEQUENCE {
    dl-TransportChannelType
                                        DL-TrCH-TypeId2-r5
}
```

```
DL-TrCH-Type ::= ENUMERATED {dch, dsch}
DL-TrCH-TypeId1-r5 ::=
                                        CHOICE {
                                            TransportChannelIdentity,
    dch
    dsch
                                            TransportChannelIdentity,
    hsdsch
}
DL-TrCH-TypeId2-r5 ::=
                                       CHOICE {
    dch
                                            TransportChannelIdentity,
    dsch
                                            TransportChannelIdentity,
    hsdsch
                                            MAC-d-FlowIdentity
}
DRAC-ClassIdentity ::=
                                       INTEGER (1..maxDRACclasses)
DRAC-StaticInformation ::=
                                       SEOUENCE {
    transmissionTimeValidity
                                           TransmissionTimeValidity,
    timeDurationBeforeRetry
                                            TimeDurationBeforeRetry,
    drac-ClassIdentity
                                            DRAC-ClassIdentity
}
DRAC-StaticInformationList ::=
                                       SEQUENCE (SIZE (1..maxTrCH)) OF
                                            DRAC-StaticInformation
ExplicitTFCS-Configuration ::=
                                       CHOICE {
   complete
                                            TFCS-ReconfAdd,
    addition
                                            TFCS-ReconfAdd,
    removal
                                            TFCS-RemovalList,
                                            SEQUENCE {
    replacement
        tfcsRemoval
                                                TFCS-RemovalList,
         tfcsAdd
                                                TFCS-ReconfAdd
}
GainFactor ::=
                                       INTEGER (0..15)
GainFactorInformation ::=
                                        CHOICE {
    signalledGainFactors
                                           SignalledGainFactors,
    computedGainFactors
                                           ReferenceTFC-ID
HSDSCH-Info ::=
                                       SEQUENCE {
    harqInfo
                                           HARO-Info
                                                                       OPTIONAL,
    addOrReconfMAC-dFlow
                                            AddOrReconfMAC-dFlow OPTIONAL
                                       SEQUENCE {
HARQ-Info ::=
                                           INTEGER (1..8),
    numberOfProcesses
    memoryPartitioning
                                            CHOICE {
                                                NULL,
        implicit
                                                SEQUENCE (SIZE (1..maxHProcesses)) OF
        explicit
                                                     HARQMemorySize
}
HARQMemorySize ::=
                                        ENUMERATED {
                                            hms800, hms1600, hms2400, hms3200, hms4000,
                                            hms4800, hms5600, hms6400, hms7200, hms8000, hms8800, hms9600, hms10400, hms11200, hms12000,
                                            hms12800, hms13600, hms14400, hms15200, hms16000, hms17600, hms19200, hms20800, hms22400, hms24000,
                                            hms25600, hms27200, hms28800, hms30400, hms32000,
                                            hms36000, hms40000, hms44000, hms48000, hms52000, hms56000, hms60000, hms64000, hms68000, hms72000,
                                            hms76000, hms80000, hms88000, hms96000, hms104000,
                                            hms112000, hms120000, hms128000, hms136000, hms144000,
                                            hms152000, hms160000, hms176000, hms192000, hms208000, hms224000, hms240000, hms256000, hms272000, hms288000,
                                            hms304000 }
IndividualDL-CCTrCH-Info ::=
                                       SEQUENCE {
    dl-TFCS-Identity
                                           TFCS-Identity,
    tfcs-SignallingMode
                                           CHOICE {
         explicit-config
                                                TFCS
         sameAsUL
                                                TFCS-Identity
    }
}
```

```
IndividualDL-CCTrCH-InfoList ::= SEQUENCE (SIZE (1..maxCCTrCH)) OF
                                      IndividualDL-CCTrCH-Info
IndividualUL-CCTrCH-Info ::=
                                  SEQUENCE {
  ul-TFCS-Identity
                                    TFCS-Identity,
   ul-TFCS
                                      TFCS ,
                                      TFC-Subset
   tfc-Subset
}
IndividualUL-CCTrCH-InfoList ::= SEQUENCE (SIZE (1..maxCCTrCH)) OF
                                      IndividualUL-CCTrCH-Info
LogicalChannelByRB ::=
                                  SEQUENCE {
   rb-Identity
                                      RB-Identity,
   logChOfRb
                                      INTEGER (0..1)
                                                                        OPTIONAL
}
LogicalChannelList ::=
                                  CHOICE {
                                          NULL,
       allSizes
       configured
                                          NULL,
                                          SEQUENCE (SIZE (1..15)) OF
       explicitList
                                              LogicalChannelByRB
}
{\tt MAC-d-FlowIdentityDCHandHSDSCH} \ ::= \ {\tt SEQUENCE} \ \{
                         TransportChannelIdentity,
MAC-d-FlowIdentity
   dch-transport-ch-id
   hsdsch-transport-ch-id
}
MAC-d-FlowIdentity ::=
                                  INTEGER (0..7)
MAC-d-PDU-SizeInfo-List ::= SEQUENCE (SIZE(1.. maxMAC-d-PDUsizes)) OF
                                      MAC-d-PDUsizeInfo
--MAC-d-Pdu sizes need to be defined
MAC-d-PDUsizeInfo ::= SEQUENCE{
   mac-d-PDU-Size
                                      INTEGER (1..5000),
   mac-d-PDU-Index
                                      INTEGER (0..7)
MAC-hs-AddReconfQueue-List ::=
                                          SEQUENCE (SIZE(1..maxQueueIDs)) OF
                                   MAC-hs-AddReconfQueue
MAC-hs-AddReconfQueue ::= SEQUENCE {
   mac-hsQueueId
                                      INTEGER(0..7),
                                      MAC-d-FlowIdentity,
   mac-dFlowId
   reorderingReleaseTimer
                                      T1-ReleaseTimer,
   mac-hsWindowSize
                                      MAC-hs-WindowSize,
                                                                       OPTIONAL
   mac-d-PDU-SizeInfo-List
                                     MAC-d-PDU-SizeInfo-List
}
MAC-hs-DelQueue-List ::=
                                      SEQUENCE (SIZE(1..maxQueueIDs)) OF
                                      MAC-hs-DelQueue
                                  SEQUENCE {
MAC-hs-DelOueue ::=
   mac-hsQueueId
                                      INTEGER(0..7)
MAC-hs-WindowSize ::=
                                  ENUMERATED {
                                      mws4, mws6, mws8, mws12, mws16, mws24, mws32 }
NumberOfTbSizeAndTTIList ::=
                                  SEQUENCE (SIZE (1..maxTF)) OF SEQUENCE {
       numberOfTransportBlocks
                                          NumberOfTransportBlocks,
                                          TransmissionTimeInterval
       transmissionTimeInterval
MessType ::=
                                  ENUMERATED {
                                      transportFormatCombinationControl }
Non-allowedTFC-List ::=
                                  SEQUENCE (SIZE (1..maxTFC)) OF
                                      TFC-Value
                                  CHOICE {
NumberOfTransportBlocks ::=
                                      NULL,
   zero
   small
                                      INTEGER (2..17),
                                      INTEGER (18..512)
   large
```

```
}
OctetModeRLC-SizeInfoType1 ::= CHOICE {
    -- Actual size = (8 * sizeType1) + 16
    sizeType1
                                           INTEGER (0..31),
    sizeType2
                                           SEQUENCE {
        -- Actual size = (32 * part1) + 272 + (part2 * 8)
                                               INTEGER (0..23),
        part1
                                               INTEGER (1..3)
                                                                                OPTIONAL
    sizeType3
                                           SEQUENCE {
        -- Actual size = (64 * part1) + 1040 + (part2 * 8)
        part1
                                               INTEGER (0..61),
                                               INTEGER (1..7)
                                                                                OPTIONAL
        part2
}
OctetModeRLC-SizeInfoType2 ::= CHOICE {
    -- Actual size = (sizeType1 * 8) + 48
                                           INTEGER (0..31),
    sizeType1
    -- Actual size = (sizeType2 * 16) + 312
                                           INTEGER (0..63),
    sizeType2
    -- Actual size = (sizeType3 *64) + 1384
    sizeType3
                                          INTEGER (0..56)
}
PowerOffsetInformation ::= SEQUENCE { gainFactorInformation GainFactorInformation,
    -- PowerOffsetPp-m is always absent in TDD
                                                                                OPTIONAL
    powerOffsetPp-m
                                          PowerOffsetPp-m
}
PowerOffsetPp-m ::=
                                      INTEGER (-5..10)
PreDefTransChConfiguration ::= SEQUENCE {
  ul-CommonTransChInfo UL-CommonTransChInfo,
  ul-AddReconfTrChInfoList UL-AddReconfTransChInfoList,
  dl-CommonTransChInfo DL-CommonTransChInfo,
  dl-TrChInfoList DL-AddReconfTransChInfoList
}
                             SEQUENCE {
   alityTarget ::=
bler-QualityValue
QualityTarget ::=
                                       BLER-QualityValue
RateMatchingAttribute ::=
                                     INTEGER (1..hiRM)
ReferenceTFC-ID ::=
                                     INTEGER (0..3)
   ul-TransportChannelType UL-TrCl
restrictedTrChIdentity Transport
allowedTFI-List
RestrictedTrChInfo ::=
                                     UL-TrCH-Type,
                                          TransportChannelIdentity,
                                          AllowedTFI-List
                                                                                OPTIONAL
}
RestrictedTrChInfoList ::=
                                SEQUENCE (SIZE (1..maxTrCH)) OF
                                         RestrictedTrChInfo
SemistaticTF-Information ::= SEQUENCE {
    -- TABULAR: Transmission time interval has been included in the IE CommonTransChTFS.
    rateMatchingAttribute
                                          ChannelCodingType,
                                          RateMatchingAttribute,
    crc-Size
                                          CRC-Size
}
SignalledGainFactors ::= modeSpecificInfo
                                     SEQUENCE {
   modeSpecificInfo
                                       CHOICE {
                                             SEQUENCE {
        fdd
            gainFactorBetaC
                                                  GainFactor
        tdd
                                               NULL
    },
    gainFactorBetaD
                                         GainFactor,
    referenceTFC-ID
                                          ReferenceTFC-ID
                                                                                OPTIONAL
SplitTFCI-Signalling ::=
                                     SEQUENCE {
```

```
splitType
                                        SplitType
                                                                         OPTIONAL,
    tfci-Field2-Length
                                        INTEGER (1..10)
                                                                         OPTIONAL,
                                        ExplicitTFCS-Configuration OPTIONAL,
TFCI-Field2-Information OPTIONAL
    tfci-Field1-Information
    tfci-Field2-Information
SplitType ::=
                                    ENUMERATED {
                                        hardSplit, logicalSplit }
T1-ReleaseTimer ::=
                                     ENUMERATED {
                                        rt10, rt20, rt30, rt40, rt50,
rt60, rt70, rt80, rt90, rt100,
                                         rt120, rt140, rt160, rt200, rt300,
                                         rt400 }
TFC-Subset ::=
                                    CHOICE {
                                       TFC-Value,
    minimumAllowedTFC-Number
    allowedTFC-List
                                        AllowedTFC-List,
   non-allowedTFC-List
                                       Non-allowedTFC-List,
   restrictedTrChInfoList
                                        RestrictedTrChInfoList,
    fullTFCS
                                        NULL
}
TFC-Subset-ID-With3b ::=
                                   INTEGER (0..7)
                                   INTEGER (0..31)
TFC-Subset-ID-With5b ::=
TFC-Subset-ID-With10b ::=
                                    INTEGER (0..1023)
                                     SEQUENCE (SIZE (1.. maxTFCsub)) OF SEQUENCE \{
TFC-SubsetList ::=
   modeSpecificInfo
                                        CHOICE {
       fdd
        tdd
                                             SEQUENCE {
            tfcs-ID
                                                 TFCS-Identity
                                                                  OPTIONAL
        }
                                        TFC-Subset
    tfc-Subset
}
TFC-Value ::=
                                    INTEGER (0..1023)
TFCI-Field2-Information ::=
                                     CHOICE {
    tfci-Range
                                        TFCI-RangeList,
    explicit-config
                                         ExplicitTFCS-Configuration
}
TFCI-Range ::=
                                     SEQUENCE {
   maxTFCIField2Value
                                        INTEGER (1..1023),
    tfcs-InfoForDSCH
                                         TFCS-InfoForDSCH
}
                                     SEQUENCE (SIZE (1..maxPDSCH-TFCIgroups)) OF
TFCI-RangeList ::=
                                        TFCI-Range
TFCS ::=
                                     CHOICE {
   normalTFCI-Signalling
                                        ExplicitTFCS-Configuration,
    splitTFCI-Signalling
                                        SplitTFCI-Signalling
TFCS-Identity ::=
                                    SEQUENCE {
                                                                            DEFAULT 1,
                                        TFCS-IdentityPlain
    tfcs-ID
    sharedChannelIndicator
                                         BOOLEAN
}
TFCS-IdentityPlain ::=
                                    INTEGER (1..8)
TFCS-InfoForDSCH ::=
                                     CHOICE {
   ctfc2bit
                                        INTÈGER (0..3),
                                         INTEGER (0..15),
INTEGER (0..63),
    ct.fc4bit
    ctfc6bit
   ctfc8bit
                                        INTEGER (0..255),
                                         INTEGER (0..4095),
    ctfc12bit
                                        INTEGER (0..65535),
    ctfc16bit
                                        INTEGER (0..16777215)
    ctfc24bit
TFCS-ReconfAdd ::=
                                    SEQUENCE {
   ctfcSize
                                         CHOICE {
```

```
SEQUENCE (SIZE (1..maxTFC)) OF SEQUENCE {
        ctfc2Bit
                                               INTEGER (0..3),
           ctfc2
           powerOffsetInformation
                                               PowerOffsetInformation
                                                                              OPTIONAL
        ctfc4Bit
                                           SEQUENCE (SIZE (1..maxTFC)) OF SEQUENCE {
                                               INTEGER (0..15),
           ctfc4
           powerOffsetInformation
                                               PowerOffsetInformation
                                                                              OPTIONAL
        ctfc6Bit
                                           SEQUENCE (SIZE (1..maxTFC)) OF SEQUENCE {
           ctfc6
                                               INTEGER (0..63),
           powerOffsetInformation
                                               PowerOffsetInformation
                                                                              OPTIONAL
        },
        ctfc8Bit
                                           SEQUENCE (SIZE (1..maxTFC)) OF SEQUENCE {
           ctfc8
                                               INTEGER (0..255),
           powerOffsetInformation
                                               PowerOffsetInformation
        },
        ctfc12Bit
                                           SEQUENCE (SIZE(1..maxTFC)) OF SEQUENCE {
           ctfc12
                                               INTEGER (0..4095),
           powerOffsetInformation
                                               PowerOffsetInformation
                                           SEQUENCE (SIZE (1..maxTFC)) OF SEQUENCE {
        ctfc16Bit
           ctfc16
                                               INTEGER(0..65535),
           powerOffsetInformation
                                               PowerOffsetInformation
                                                                              OPTIONAL
                                           SEQUENCE (SIZE (1..maxTFC)) OF SEQUENCE {
   INTEGER(0..16777215),
        ctfc24Bit
           ctfc24
           powerOffsetInformation
                                               PowerOffsetInformation
                                                                              OPTIONAL
    }
}
TFCS-Removal ::=
                                   SEQUENCE {
                                       INTEGER (0..1023)
   tfci
TFCS-RemovalList ::=
                                   SEQUENCE (SIZE (1..maxTFC)) OF
                                       TFCS-Removal
TimeDurationBeforeRetry ::=
                                  INTEGER (1..256)
TM-SignallingInfo ::=
                                   SEQUENCE {
   messType
                                       MessType,
                                       CHOICE {
    tm-SignallingMode
       mode1
                                           NULL
                                           SEQUENCE {
            -- in ul-controlledTrChList, TrCH-Type is always DCH
           ul-controlledTrChList
                                               UL-ControlledTrChList
        }
    }
}
TransmissionTimeInterval ::=
                                   ENUMERATED {
                                     tti10, tti20, tti40, tti80 }
TransmissionTimeValidity ::=
                                  INTEGER (1..256)
TransportChannelIdentity ::=
                                   INTEGER (1..32)
TransportChannelIdentityDCHandDSCH ::= SEQUENCE {
                         TransportChannelIdentity,
   dch-transport-ch-id
                                   TransportChannelIdentity
   dsch-transport-ch-id
}
TransportFormatSet ::=
                                  CHOICE {
   dedicatedTransChTFS
                                     DedicatedTransChTFS,
   commonTransChTFS
                                       CommonTransChTFS
}
                                       CHOICE {
TransportFormatSet-LCR ::=
   dedicatedTransChTFS
                                       DedicatedTransChTFS,
   commonTransChTFS-LCR
                                       CommonTransChTFS-LCR
}
-- The maximum allowed size of UL-AddReconfTransChInfoList sequence is 16
UL-AddReconfTransChInfoList ::= SEQUENCE (SIZE (1..maxTrCHpreconf)) OF
                                       UL-AddReconfTransChInformation
```

```
UL-AddReconfTransChInformation ::= SEQUENCE {
   ul-TransportChannelType UL-TrCH-Type,
transportChannelIdentity TransportChan
transportFormatSet TransportForm
                                       TransportChannelIdentity,
                                       TransportFormatSet
                                  SEQUENCE {
UL-CommonTransChInfo ::=
    -- TABULAR: tfc-subset is applicable to FDD only, TDD specifies tfc-subset in individual
    -- CCTrCH Info.
    tfc-Subset
                                       TFC-Subset
                                                                           OPTIONAL,
   prach-TFCS
                                       TFCS
                                                                           OPTIONAL,
    modeSpecificInfo
                                       CHOICE {
                                           SEQUENCE {
       fdd
           ul-TFCS
                                           TFCS
        },
       tdd
                                           SEQUENCE {
           individualUL-CCTrCH-InfoList IndividualUL-CCTrCH-InfoList
                                                                           OPTIONAL
        }
    }
                                                                           OPTIONAL
}
UL-CommonTransChInfo-r4 ::=
                                  SEQUENCE {
    -- TABULAR: tfc-subset is applicable to FDD only, TDD specifies tfc-subset in individual
    -- CCTrCH Info.
   tfc-Subset
                                       TFC-Subset
                                                                           OPTIONAL,
   prach-TFCS
                                                                           OPTIONAL,
                                       TFCS
   modeSpecificInfo
                                       CHOICE {
                                           SEQUENCE {
       fdd
           ul-TFCS
                                               TFCS
                                           SEQUENCE {
       tdd
           individualUL-CCTrCH-InfoList
                                              IndividualUL-CCTrCH-InfoList
                                                                           OPTIONAL,
    tfc-SubsetList
                                       TFC-SubsetList
                                                                           OPTIONAL
}
-- In UL-ControlledTrChList, TrCH-Type is always DCH
UL-ControlledTrChList ::=
                            SEQUENCE (SIZE (1..maxTrCH)) OF
                                       TransportChannelIdentity
UL-DeletedTransChInfoList ::= SEQUENCE (SIZE (1..maxTrCH)) OF
                                      UL-TransportChannelIdentity
{\tt UL-TransportChannelIdentity} ::= \\ {\tt SEQUENCE} \ \big\{
                                  UL-TrCH-Type,
    ul-TransportChannelType
    ul-TransportChannelIdentity
                                       TransportChannelIdentity
}
UL-TrCH-Type ::= ENUMERATED {dch, usch}
                                  SEQUENCE (SIZE (1..maxTrCH)) OF
USCH-TransportChannelsInfo ::=
                                       SEQUENCE {
    usch-TransportChannelIdentity
                                           TransportChannelIdentity,
    usch-TFS
                                           {\tt TransportFormatSet}
}
__ ***************
___
      PHYSICAL CHANNEL INFORMATION ELEMENTS (10.3.6)
__ *******************************
ACK-NACK-repetitionFactor ::=
                                  INTEGER(1..4)
AC-To-ASC-Mapping ::=
                                   INTEGER (0..7)
AC-To-ASC-MappingTable ::=
                                  SEQUENCE (SIZE (maxASCmap)) OF
                                       AC-To-ASC-Mapping
AccessServiceClass-FDD ::=
                                   SEQUENCE {
                                   INTEGER (0..15),
   availableSignatureStartIndex
    availableSignatureEndIndex
                                       INTEGER (0..15),
   assignedSubChannelNumber
                                      BIT STRING {
                                           b3(0),
```

```
b2(1),
                                              b1(2),
                                              b0(3)
                                                   (SIZE(4))
AccessServiceClass-TDD ::=
                                     SEQUENCE {
    channelisationCodeIndices
                                          BIT STRING {
                                              chCodeIndex7(0),
                                              chCodeIndex6(1),
                                              chCodeIndex5(2),
                                              chCodeIndex4(3),
                                              chCodeIndex3(4),
                                              chCodeIndex2(5),
                                              chCodeIndex1(6),
                                              chCodeIndex0(7)
                                              } (SIZE(8))
                                                                       OPTIONAL,
                                          CHOICE {
    subchannelSize
        size1
                                              NULL,
        size2
                                              SEQUENCE {
            -- subch0 means bitstring '01' in the tabular, subch1 means bitsring '10'
                                                  ENUMERATED { subch0, subch1 } OPTIONAL
            subchannels
        size4
                                              SEQUENCE {
            subchannels
                                                  BIT STRING {
                                                      subCh3(0),
                                                      subCh2(1),
                                                      subCh1(2),
                                                      subCh0(3)
                                                      } (SIZE(4))
                                                                       OPTIONAL
                                              SEQUENCE {
            subchannels
                                                  BIT STRING {
                                                      subCh7(0),
                                                      subCh6(1),
                                                      subCh5(2),
                                                      subCh4(3),
                                                      subCh3(4),
                                                      subCh2(5),
                                                      subCh1(6),
                                                      subCh0(7)
                                                      } (SIZE(8))
                                                                       OPTIONAL
        }
}
AccessServiceClass-TDD-LCR-r4 ::= SEQUENCE {
    availableSYNC-UlCodesIndics
                                          BIT STRING {
                                              sulCodeIndex7(0),
                                              sulCodeIndex6(1),
                                              sulCodeIndex5(2),
                                              sulCodeIndex4(3),
                                              sulCodeIndex3(4),
                                              sulCodeIndex2(5),
                                              sulCodeIndex1(6),
                                              sulCodeIndex0(7)
                                              } (SIZE(8))
                                                                         OPTIONAL,
    subchannelSize
                                          CHOICE {
        size1
                                              NULL,
                                              SEQUENCE {
            -- subch0 means bitstring '01' in the tabular, subch1 means bitsring '10'. subchannels ENUMERATED { subch0, subch1 } OPTIONAL
        },
        size4
                                              SEQUENCE {
                                                  BIT STRING {
            subchannels
                                                      subCh3(0),
                                                      subCh2(1),
                                                      subCh1(2),
                                                      subCh0(3)
                                                                          OPTIONAL
                                                      } (SIZE(4))
                                              SEQUENCE {
            subchannels
                                                  BIT STRING {
                                                      subCh7(0),
                                                      subCh6(1),
                                                      subCh5(2),
                                                      subCh4(3),
                                                      subCh3(4),
```

```
subCh2(5),
                                                   subCh1(6),
                                                   subCh0(7)
                                                   } (SIZE(8))
                                                                     OPTIONAL
   }
}
AICH-Info ::=
                                   SEQUENCE {
                                   ChannelisationCode256,
   channelisationCode256
                                       BOOLEAN.
    sttd-Indicator
    aich-TransmissionTiming
                                       AICH-TransmissionTiming
AICH-PowerOffset ::=
                                   INTEGER (-22..5)
AICH-TransmissionTiming ::=
                                  ENUMERATED {
                                      e0, e1 }
AllocationPeriodInfo ::=
                                   SEQUENCE {
    allocationActivationTime
                                    INTEGER (0..255),
                                       INTEGER (1..256)
    allocationDuration
-- Actual value Alpha = IE value * 0.125
                                  INTEGER (0..8)
AP-AICH-ChannelisationCode ::=
                                  INTEGER (0..255)
AP-PreambleScramblingCode ::=
                                  INTEGER (0..79)
AP-Signature ::=
                                   INTEGER (0..15)
                                   SEQUENCE {
AP-Signature-VCAM ::=
   ap-Signature
                                      AP-Signature,
   availableAP-SubchannelList
                                       AvailableAP-SubchannelList OPTIONAL
}
AP-Subchannel ::=
                                  INTEGER (0..11)
ASCSetting-FDD ::=
                                       SEOUENCE {
    -- TABULAR: accessServiceClass-FDD is MD in tabular description
    -- Default value is previous ASC
    -- If this is the first ASC, the default value is all available signature and sub-channels
   accessServiceClass-FDD
                                           AccessServiceClass-FDD OPTIONAL
}
ASCSetting-TDD ::=
                                       SEQUENCE {
   -- TABULAR: accessServiceClass-TDD is MD in tabular description
    -- Default value is previous ASC
    -- If this is the first ASC, the default value is all available channelisation codes and
    -- all available sub-channels with subchannelSize=size1.
   accessServiceClass-TDD
                                           AccessServiceClass-TDD OPTIONAL
}
ASCSetting-TDD-LCR-r4 ::=
                                              SEQUENCE {
   -- TABULAR: accessServiceClass-TDD-LCR is MD in tabular description
    -- Default value is previous ASC
    -- If this is the first ASC, the default value is all available SYNC_UL codes and
    -- all available sub-channels with subchannelSize=size1.
    accessServiceClass-TDD-LCR
                                             AccessServiceClass-TDD-LCR-r4 OPTIONAL
}
AvailableAP-Signature-VCAMList ::= SEQUENCE (SIZE (1..maxPCPCH-APsig)) OF
                                       AP-Signature-VCAM
                                   SEQUENCE (SIZE (1..maxPCPCH-APsig)) OF
AvailableAP-SignatureList ::=
                                       AP-Signature
AvailableAP-SubchannelList ::=
                                   SEQUENCE (SIZE (1..maxPCPCH-APsubCh)) OF
                                       AP-Subchannel
AvailableMinimumSF-ListVCAM ::=
                                   SEQUENCE (SIZE (1..maxPCPCH-SF)) OF
                                      AvailableMinimumSF-VCAM
AvailableMinimumSF-VCAM ::=
                                   SEQUENCE {
   minimumSpreadingFactor
                                      MinimumSpreadingFactor,
```

```
nf-Max
                                       NF-Max,
    maxAvailablePCPCH-Number MaxAvailablePCPCH-Number, availableAP-Signature-VCAMList AvailableAP-Signature-VCAMList
}
AvailableSignatures ::=
                               BIT STRING {
                                     signature15(0),
                                     signature14(1),
                                     signature13(2),
                                     signature12(3),
                                     signature11(4),
                                     signature10(5),
                                     signature9(6),
                                     signature8(7),
                                     signature7(8),
                                     signature6(9),
                                     signature5(10),
                                     signature4(11),
                                     signature3(12),
                                     signature2(13),
                                     signature1(14),
                                     signature0(15)
                                          (SIZE(16))
AvailableSubChannelNumbers ::=
                                    BIT STRING {
                                         subCh11(0),
                                         subCh10(1),
                                         subCh9(2),
                                         subCh8(3),
                                         subCh7(4),
                                         subCh6(5),
                                         subCh5(6),
                                         subCh4(7),
                                         subCh3(8),
                                         subCh2(9),
                                         subCh1(10),
                                         subCh0(11)
                                              (SIZE(12))
BurstType ::=
                                     ENUMERATED {
                                         type1, type2 }
-- Actual value Bler-Target = IE value * 0.05
Bler-Target ::=
                                    INTEGER (-63..0)
CCTrCH-PowerControlInfo ::=
                                    SEQUENCE {
                                        TFCS-Identity
                                                                             OPTIONAL,
    tfcs-Identity
    ul-DPCH-PowerControlInfo
                                        UL-DPCH-PowerControlInfo
CCTrCH-PowerControlInfo-r4 ::=
                                    SEOUENCE {
                                        TFCS-Identity
                                                                             OPTIONAL,
    tfcs-Identity
    ul-DPCH-PowerControlInfo
                                        UL-DPCH-PowerControlInfo-r4
CCTrCH-PowerControlInfo-r5 ::=
                                    SEQUENCE {
    tfcs-Identity
                                        TFCS-Identity
                                                                              OPTIONAL,
    ul-DPCH-PowerControlInfo
                                         UL-DPCH-PowerControlInfo-r5
}
CD-AccessSlotSubchannel ::=
                                    INTEGER (0..11)
CD-AccessSlotSubchannelList ::=
                                    SEQUENCE (SIZE (1..maxPCPCH-CDsubCh)) OF
                                         CD-AccessSlotSubchannel
CD-CA-ICH-ChannelisationCode ::=
                                    INTEGER (0..255)
CD-PreambleScramblingCode ::=
                                    INTEGER (0..79)
CD-SignatureCode ::=
                                     INTEGER (0..15)
CD-SignatureCodeList ::=
                                     SEQUENCE (SIZE (1..maxPCPCH-CDsig)) OF
                                        CD-SignatureCode
CellAndChannelIdentity ::=
                                    SEQUENCE {
   burstType
                                         BurstType,
                                         MidambleShiftLong,
    midambleShift
    timeslot
                                         TimeslotNumber,
```

```
cellParametersID
                                     CellParametersID
                                  INTEGER (0..127)
CellParametersID ::=
Cfntargetsfnframeoffset ::=
                                     INTEGER(0..255)
ChannelAssignmentActive ::=
                                  CHOICE {
   notActive
                                      NULL,
   isActive
                                      AvailableMinimumSF-ListVCAM
                                  INTEGER (0..255)
ChannelisationCode256 ::=
ChannelReqParamsForUCSM ::=
                                  SEQUENCE {
   availableAP-SignatureList
                                   AvailableAP-SignatureList,
   availableAP-SubchannelList
                                      AvailableAP-SubchannelList
                                                                        OPTIONAL
}
ClosedLoopTimingAdjMode ::=
                                  ENUMERATED {
                                      slot1, slot2 }
CodeNumberDSCH ::=
                                  INTEGER (0..255)
CodeRange ::=
                                  SECUENCE {
   pdsch-CodeMapList
                                      PDSCH-CodeMapList
CodeWordSet ::=
                                  ENUMERATED {
                                      longCWS,
                                      mediumCWS,
                                      shortCWS,
                                      ssdtOff }
                                  SEQUENCE {
CommonTimeslotInfo ::=
   -- TABULAR: secondInterleavingMode is MD, but since it can be encoded in a single
    -- bit it is not defined as OPTIONAL.
   secondInterleavingMode
                                      SecondInterleavingMode,
                                      TFCI-Coding
   tfci-Coding
                                                                         OPTIONAL,
   puncturingLimit
                                      PuncturingLimit,
   repetitionPeriodAndLength
                                      RepetitionPeriodAndLength
                                                                        OPTIONAL
}
CommonTimeslotInfoSCCPCH ::=
                                 SEQUENCE {
   -- TABULAR: secondInterleavingMode is MD, but since it can be encoded in a single
   -- bit it is not defined as OPTIONAL.
   secondInterleavingMode
                                     SecondInterleavingMode,
   tfci-Coding
                                      TFCI-Coding
                                                                        OPTIONAL,
   puncturingLimit
                                      PuncturingLimit,
   repetitionPeriodLengthAndOffset RepetitionPeriodLengthAndOffset OPTIONAL
}
ConstantValue ::=
                                  INTEGER (-35..-10)
ConstantValueTdd ::=
                                  INTEGER (-35..10)
CPCH-PersistenceLevels ::=
                                  SEQUENCE {
   cpch-SetID
                                     CPCH-SetID,
   dynamicPersistenceLevelTF-List
                                      DynamicPersistenceLevelTF-List
}
CPCH-PersistenceLevelsList ::=
                                  SEQUENCE (SIZE (1..maxCPCHsets)) OF
                                      CPCH-PersistenceLevels
CPCH-SetInfo ::=
                                   SEQUENCE {
   cpch-SetID
                                      CPCH-SetID,
   transportFormatSet
                                      TransportFormatSet,
                                      TFCS,
   tfcs
                                    AP-PreambleScramblingCode,
   ap-PreambleScramblingCode
   ap-AICH-ChannelisationCode
                                      AP-AICH-ChannelisationCode,
   cd-PreambleScramblingCode
                                      CD-PreambleScramblingCode,
   cd-CA-ICH-ChannelisationCode
                                      CD-CA-ICH-ChannelisationCode,
   cd-AccessSlotSubchannelList
                                      CD-AccessSlotSubchannelList
                                                                         OPTIONAL,
   cd-SignatureCodeList
                                      CD-SignatureCodeList
                                                                         OPTIONAL,
   deltaPp-m
                                      DeltaPp-m,
                                      UL-DPCCH-SlotFormat,
   ul-DPCCH-SlotFormat
   n-StartMessage
                                      N-StartMessage,
   n-EOT
                                      N-EOT,
```

```
-- TABULAR: VCAM info has been nested inside ChannelAssignmentActive,
    -- which in turn is mandatory since it's only a binary choice.
   channelAssignmentActive ChannelAssignmentActive, cpch-StatusIndicationMode pcpch-ChannelInfoList PCPCH-ChannelInfoList
                                       CPCH-StatusIndicationMode,
                                   SEQUENCE (SIZE (1..maxCPCHsets)) OF
CPCH-SetInfoList ::=
                                        CPCH-SetInfo
CPCH-StatusIndicationMode ::=
                                    ENUMERATED {
                                        pa-mode,
                                        pamsf-mode }
CQI-RepetitionFactor ::=
                                    INTEGER(1..4)
CSTCH-PowerOffset ::=
                                    INTEGER (-10..5)
-- DefaultDPCH-OffsetValueFDD and DefaultDPCH-OffsetValueTDD corresponds to
-- IE "Default DPCH Offset Value" depending on the mode.
-- Actual value DefaultDPCH-OffsetValueFDD = IE value * 512
                                   INTEGER (0..599)
DefaultDPCH-OffsetValueFDD ::=
DefaultDPCH-OffsetValueTDD ::=
                                   INTEGER (0..7)
                                    INTEGER (-10..10)
DeltaPp-m ::=
DeltaCQI ::=
                                    INTEGER (0..8)
DeltaNACK ::=
                                    INTEGER (0..8)
DeltaACK ::=
                                    INTEGER (0..8)
-- Actual value DeltaSIR = IE value * 0.1
DeltaSIR ::=
                                    INTEGER (0..30)
DL-CCTrCh ::=
                                    SEQUENCE {
                                     TFCS-IdentityPlain
   tfcs-ID
                                                                           DEFAULT 1,
   timeInfo
                                        TimeInfo,
    commonTimeslotInfo
                                       CommonTimeslotInfo
                                                                            OPTIONAL,
    dl-CCTrCH-TimeslotsCodes
                                        DownlinkTimeslotsCodes
                                                                            OPTIONAL,
   ul-CCTrChTPCList
                                       UL-CCTrChTPCList
                                                                            OPTIONAL
}
                                    SEQUENCE {
DL-CCTrCh-r4 ::=
   tfcs-ID
                                        TFCS-IdentityPlain
                                                                           DEFAULT 1,
    timeInfo
                                        TimeInfo.
    commonTimeslotInfo
                                        CommonTimeslotInfo
                                                                           OPTIONAL,
    tddOption
                                        CHOICE {
                                          SEQUENCE {
                                                DownlinkTimeslotsCodes OPTIONAL
           dl-CCTrCH-TimeslotsCodes
        tdd128
                                           SEQUENCE {
           dl-CCTrCH-TimeslotsCodes
                                                DownlinkTimeslotsCodes-LCR-r4 OPTIONAL
    ul-CCTrChTPCList
                                      UL-CCTrChTPCList
                                                               OPTIONAL
}
DL-CCTrChList ::=
                                    SEQUENCE (SIZE (1..maxCCTrCH)) OF
                                        DL-CCTrCh
DL-CCTrChList-r4 ::=
                                    SEQUENCE (SIZE (1..maxCCTrCH)) OF
                                        DL-CCTrCh-r4
                                    SEQUENCE (SIZE (1..maxCCTrCH)) OF
DL-CCTrChListToRemove ::=
                                        TFCS-IdentityPlain
DL-CCTrChTPCList ::=
                                    SEQUENCE (SIZE (0..maxCCTrCH)) OF
                                            TFCS-Identity
DL-ChannelisationCode ::=
                                    SEQUENCE {
    secondaryScramblingCode
                                     SecondaryScramblingCode
                                                                           OPTIONAL,
    sf-AndCodeNumber
                                       SF512-AndCodeNumber,
    scramblingCodeChange
                                       ScramblingCodeChange
                                                                            OPTIONAL
DL-ChannelisationCodeList ::=
                                   SEQUENCE (SIZE (1..maxDPCH-DLchan)) OF
```

```
DL-ChannelisationCode
```

```
DL-CommonInformation ::=
                                   SEQUENCE {
                                       DL-DPCH-InfoCommon
   dl-DPCH-InfoCommon
                                                                  OPTIONAL,
   modeSpecificInfo
                                       CHOICE {
                                          SEQUENCE {
       fdd
           defaultDPCH-OffsetValue
                                              DefaultDPCH-OffsetValueFDD OPTIONAL,
                                              DPCH-CompressedModeInfo OPTIONAL,
           dpch-CompressedModeInfo
           tx-DiversityMode
                                              TX-DiversityMode
                                                                         OPTIONAL,
           ssdt-Information
                                              SSDT-Information
                                                                          OPTIONAL
       },
       tdd
                                          SEQUENCE {
           defaultDPCH-OffsetValue
                                              DefaultDPCH-OffsetValueTDD OPTIONAL
       }
   }
}
                                   SEQUENCE {
DL-CommonInformation-r4 ::=
   dl-DPCH-InfoCommon
                                      DL-DPCH-InfoCommon-r4
   modeSpecificInfo
                                       CHOICE {
                                          SEQUENCE {
       fdd
           defaultDPCH-OffsetValue
                                              DefaultDPCH-OffsetValueFDD OPTIONAL,
           dpch-CompressedModeInfo
                                               DPCH-CompressedModeInfo OPTIONAL,
           tx-DiversityMode
                                              TX-DiversityMode
                                                                         OPTIONAL.
           ssdt-Information
                                              SSDT-Information-r4
                                                                         OPTIONAL
       },
        tdd
                                           SEQUENCE {
           tddOption
                                              CHOICE {
               tdd384
                                                  NULL,
               t.dd128
                                                   SEQUENCE {
                   tstd-Indicator
                                                      BOOLEAN
           }.
           defaultDPCH-OffsetValue
                                             DefaultDPCH-OffsetValueTDD OPTIONAL
       }
   }
}
DL-CommonInformation-r5 ::=
                                   SEQUENCE {
   dl-DPCH-InfoCommon
                                      DL-DPCH-InfoCommon-r4
   modeSpecificInfo
                                       CHOICE {
                                          SEQUENCE {
       fdd
           defaultDPCH-OffsetValue
                                              DefaultDPCH-OffsetValueFDD OPTIONAL,
                                               DPCH-CompressedModeInfo OPTIONAL,
           dpch-CompressedModeInfo
           tx-DiversityMode
                                              TX-DiversityMode
                                                                          OPTIONAL,
           ssdt-Information
                                              SSDT-Information-r4
                                                                         OPTIONAL
       },
       tdd
                                           SEQUENCE {
           tddOption
                                               CHOICE {
               tdd384
                                                  NULL,
               tdd128
                                                   SEQUENCE {
                   tstd-Indicator
                                                      BOOLEAN
           defaultDPCH-OffsetValue
                                             DefaultDPCH-OffsetValueTDD OPTIONAL
   },
                                      ENUMERATED { true }
                                                                OPTIONAL
   mac-hsResetIndicator
DL-CommonInformationPost ::=
                                   SEQUENCE {
   dl-DPCH-InfoCommon
                                      DL-DPCH-InfoCommonPost
DL-CommonInformationPredef ::=
                                   SEQUENCE {
   dl-DPCH-InfoCommon
                                      DL-DPCH-InfoCommonPredef
                                                                  OPTIONAL
}
DL-CompressedModeMethod ::=
                                   ENUMERATED {
                                       puncturing, sf-2,
                                       higherLayerScheduling }
DL-DPCH-InfoCommon ::=
                                   SEQUENCE {
   cfnHandling
                                      CHOICE {
       maintain
                                          NULL,
                                          SEQUENCE {
       initialise
           cfntargetsfnframeoffset
                                              Cfntargetsfnframeoffset
                                                                                 OPTIONAL
```

```
modeSpecificInfo
                                          CHOICE {
                                             SEQUENCE {
        fdd
            dl-DPCH-PowerControlInfo DL-DPCH-PowerControlInfo OPTIONAL, powerOffsetPilot-pdpdch PowerOffsetPilot-pdpdch, dl-rate-matching-restriction Dl-rate-matching-restriction OPTIONAL,
             -- TABULAR: The number of pilot bits is nested inside the spreading factor.
                                         SF512-AndPilot,
            spreadingFactorAndPilot
             positionFixedOrFlexible
                                                   PositionFixedOrFlexible,
             tfci-Existence
                                                   BOOLEAN
        },
                                               SEQUENCE {
        t.dd
            dl-DPCH-PowerControlInfo
                                                   DL-DPCH-PowerControlInfo OPTIONAL
        }
    }
}
                                           SEQUENCE {
DL-DPCH-InfoCommon-r4 ::=
    cfnHandling
                                           CHOICE {
                                               NULL,
        maintain
                                                SEQUENCE {
        initialise
            cfntargetsfnframeoffset
                                                    Cfntargetsfnframeoffset
                                                                                          OPTIONAL
    modeSpecificInfo
                                          CHOICE {
            SEQUENCE {

dl-DPCH-PowerControlInfo
 powerOffsetPilot-pdpdch
 dl-rate-matching-restriction

CHOICE {

SEQUENCE {

DL-DPCH-PowerControlInfo
 PowerOffsetPilot-pdpdch,
 Dl-rate-matching-restriction
        fdd
                                                                                          OPTIONAL,
             -- TABULAR: The number of pilot bits is nested inside the spreading factor.
            spreadingFactorAndPilot SF512-AndPilot, positionFixedOrFlexible PositionFixedOr
                                                   PositionFixedOrFlexible,
            tfci-Existence
                                                   BOOLEAN
        }.
        tdd
                                               SEQUENCE {
            dl-DPCH-PowerControlInfo
                                                  DL-DPCH-PowerControlInfo
                                                                                           OPTIONAL
    },
-- The IE mac-d-HFN-initial-value should be absent in the RRCConnectionSetup-r4-IEs or
-- RRCConnectionSetup-r5-IEs or HandoverToUTRANCommand-r4-IEs or HandoverToUTRANCommand-r5-IEs and
-- if the IE is included, the general error handling for conditional IEs applies.
    mac-d-HFN-initial-value
                                          MAC-d-HFN-initial-value
}
DL-DPCH-InfoCommonPost ::=
                                      SEOUENCE {
   dl-DPCH-PowerControlInfo
                                                                                     OPTIONAL
                                        DL-DPCH-PowerControlInfo
DL-DPCH-InfoCommonPredef ::= SEQUENCE { modeSpecificInfo CHOICE
                                     CHOICE {
        fdd
                                            SEQUENCE {
             -- TABULAR: The number of pilot bits is nested inside the spreading factor.
            spreadingFactorAndPilot SF512-AndPilot, positionFixedOrFlexible PositionFixedOr
                                                   PositionFixedOrFlexible,
            tfci-Existence
                                                   BOOLEAN
        tdd
                                               SEQUENCE {
            commonTimeslotInfo
                                                   CommonTimeslotInfo
        }
    }
}
DL-DPCH-InfoPerRL ::=
                                       CHOICE {
                                           SEQUENCE {
                                           PCPICH-UsageForChannelEst,
        pCPICH-UsageForChannelEst
        dpch-FrameOffset
                                               DPCH-FrameOffset,
        secondaryCPICH-Info
                                               SecondaryCPICH-Info
                                                                                  OPTIONAL,
        dl-ChannelisationCodeList
                                             DL-ChannelisationCodeList,
                                               TPC-CombinationIndex,
        tpc-CombinationIndex
        ssdt-CellIdentity
                                               SSDT-CellIdentity
                                                                                   OPTIONAL,
        closedLoopTimingAdjMode
                                               ClosedLoopTimingAdjMode
                                                                                  OPTIONAL
    },
        dl-CCTrChListToEstablish
                                         SEQUENCE {
    tdd
                                          DL-CCTrChList
                                                                                  OPTIONAL,
                                               DL-CCTrChListToRemove
        dl-CCTrChListToRemove
                                                                                 OPTIONAL
    }
```

```
}
DL-DPCH-InfoPerRL-r4 ::=
                                  CHOICE {
   fdd
                                     SEQUENCE {
                                     PCPICH-UsageForChannelEst, DPCH-FrameOffset,
       pCPICH-UsageForChannelEst
       dpch-FrameOffset
                                      SecondaryCPICH-Info
DL-ChannelisationCodeList,
       secondaryCPICH-Info
                                                                        OPTIONAL,
       dl-ChannelisationCodeList
                                         TPC-CombinationIndex,
       tpc-CombinationIndex
       ssdt-CellIdentity
                                          SSDT-CellIdentity
                                                                         OPTIONAL,
       closedLoopTimingAdjMode
                                        ClosedLoopTimingAdjMode
                                                                         OPTIONAL
   },
                                   SEQUENCE {
                                      DL-CCTrChList-r4
       dl-CCTrChListToEstablish
                                                                        OPTIONAL,
       dl-CCTrChListToRemove
                                          DL-CCTrChListToRemove
                                                                        OPTIONAL
}
DL-DPCH-InfoPerRL-r5 ::=
                                  CHOICE {
                                      SEOUENCE {
   fdd
                                      PCPICH-UsageForChannelEst,
       pCPICH-UsageForChannelEst
       dpch-FrameOffset
                                         DPCH-FrameOffset,
       secondaryCPICH-Info
                                          SecondaryCPICH-Info
                                                                        OPTIONAL,
                                       SecondaryCP1CH-Info
DL-ChannelisationCodeList,
       dl-ChannelisationCodeList
                                         TPC-CombinationIndex,
       tpc-CombinationIndex
       powerOffsetTPC-pdpdch
                                          PowerOffsetTPC-pdpdch
                                                                        OPTIONAL,
       ssdt-CellIdentity
                                         SSDT-CellIdentity
                                         ClosedLoopTimingAdjMode
       closedLoopTimingAdjMode
                                                                        OPTIONAL
                                    SEQUENCE {
                                     DL-CCTrChList-r4
       dl-CCTrChListToEstablish
                                                                        OPTIONAL,
                                         DL-CCTrChListToRemove
       dl-CCTrChListToRemove
                                                                        OPTIONAL
}
DL-DPCH-InfoPerRL-PostFDD ::=
                                                         SEQUENCE {
       pCPICH-UsageForChannelEst dl-ChannelisationCode
                                              PCPICH-UsageForChannelEst,
                                              DL-ChannelisationCode,
       tpc-CombinationIndex
                                              TPC-CombinationIndex
}
                                          SEQUENCE {
DL-DPCH-InfoPerRL-PostTDD ::=
   dl-DPCH-TimeslotsCodes
                                              DownlinkTimeslotsCodes
DL-DPCH-InfoPerRL-PostTDD-LCR-r4 ::= SEQUENCE {
                                             DownlinkTimeslotsCodes-LCR-r4
   dl-CCTrCH-TimeslotsCodes
DL-DPCH-PowerControlInfo ::=
                                    SEQUENCE {
   modeSpecificInfo
                                          CHOICE {
       fdd
                                              SEQUENCE {
           dpc-Mode
                                                 DPC-Mode
       }.
       tdd
                                              SEQUENCE {
           tpc-StepSizeTDD
                                                 TPC-StepSizeTDD
                                                                       OPTIONAL
   }
}
DL-FrameType ::=
                                  ENUMERATED {
                                      dl-FrameTypeA, dl-FrameTypeB }
DL-HSPDSCH-Information ::=
                                  SEQUENCE {
   hs-scch-Info
                                  HS-SCCH-Info OPTIONAL,
   measurement-feedback-Info
                                  Measurement-Feedback-Info OPTIONAL,
                                  CHOICE {
   modeSpecificInfo
                                  CHOICE {
   t.dd
           tdd384
                                          SEQUENCE {
              dl-HSPDSCH-TS-Configuration DL-HSPDSCH-TS-Configuration OPTIONAL
           tdd128
                                      SECTIENCE {
               hs-PDSCH-Midamble-Configuration-tdd128
                      HS-PDSCH-Midamble-Configuration-TDD128
                                                                                 OPTIONAL
           }
       }.
       fdd
                                  NIII.T.
```

```
}
-- The IE 'DL-HSPDSCH-TS-Configuration' applies to tdd-384 REL-5 onward
DL-HSPDSCH-TS-Configuration ::= SEQUENCE (SIZE (1..maxTS-2)) OF
                                  SEQUENCE {
   timeslot
                                        TimeslotNumber,
   midambleShiftAndBurstType
                                        MidambleShiftAndBurstType-DL
}
DL-InformationPerRL ::=
                                SEQUENCE {
                                  CHOICE {
   modeSpecificInfo
       fdd
                                       SEQUENCE {
          primaryCPICH-Info
                                            PrimaryCPICH-Info,
           pdsch-SHO-DCH-Info
                                            PDSCH-SHO-DCH-Info
                                                                     OPTIONAL,
           pdsch-CodeMapping
                                            PDSCH-CodeMapping
                                                                      OPTIONAL
       },
       tdd
                                       PrimaryCCPCH-Info
                                  DL-DPCH-InfoPerRL
   dl-DPCH-InfoPerRL
                                                                     OPTIONAL,
   sccpch-InfoforFACH
                                    SCCPCH-InfoForFACH
                                                                      OPTIONAL
}
DL-InformationPerRL-r4 ::= SEQUENCE {
   modeSpecificInfo
                                   CHOICE {
       fdd
                                       SEQUENCE {
          primaryCPICH-Info
                                           PrimaryCPICH-Info,
          pdsch-SHO-DCH-Info
                                            PDSCH-SHO-DCH-Info
                                                                     OPTIONAL,
          pdsch-CodeMapping
                                            PDSCH-CodeMapping
                                                                      OPTIONAL
       },
       tdd
                                       PrimaryCCPCH-Info-r4
   dl-DPCH-InfoPerRL
                                   DL-DPCH-InfoPerRL-r4
                                                                     OPTIONAL,
   sccpch-InfoforFACH
                                   SCCPCH-InfoForFACH-r4
                                                                     OPTIONAL,
   cell-id
                                                                      OPTIONAL
                                    CellIdentity
}
DL-InformationPerRL-r5 ::= SEQUENCE {
                                 CHOICE {
   modeSpecificInfo
       fdd
                                       SEQUENCE {
          primaryCPICH-Info
                                            PrimaryCPICH-Info,
           pdsch-SHO-DCH-Info
                                                                     OPTIONAL,
                                            PDSCH-SHO-DCH-Info
           pdsch-CodeMapping
                                            PDSCH-CodeMapping
                                                                      OPTIONAL,
          servingHSDSCH-RL-indicator
                                           BOOLEAN
       tdd
                                       PrimaryCCPCH-Info-r4
                                  DL-DPCH-InfoPerRL-r5
   dl-DPCH-InfoPerRL
                                                                     OPTIONAL,
   sccpch-InfoforFACH
                                     SCCPCH-InfoForFACH-r4
                                                                      OPTIONAL,
   cell-id
                                    CellIdentity
                                                                     OPTIONAL
DL-InformationPerRL-r5bis ::= SEQUENCE {
   modeSpecificInfo
                                CHOICÈ {
                                     SEQUENCE {
       fdd
           primaryCPICH-Info
                                            PrimaryCPICH-Info,
           pdsch-SHO-DCH-Info
                                            PDSCH-SHO-DCH-Info
                                                                      OPTIONAL.
          pdsch-CodeMapping
                                            PDSCH-CodeMapping
                                                                     OPTIONAL
       },
       tdd
                                       PrimaryCCPCH-Info-r4
                                  DL-DPCH-InfoPerRL-r5
SCCPCH-InfoForFACH-r4
   dl-DPCH-InfoPerRL
                                                                     OPTIONAL,
   sccpch-InfoforFACH
                                                                     OPTIONAL.
   cell-id
                                    CellIdentity
                                                                      OPTIONAL
DL-InformationPerRL-List ::= SEQUENCE (SIZE (1..maxRL)) OF
                                     DL-InformationPerRL
DL-InformationPerRL-List-r4 ::=
                                 SEQUENCE (SIZE (1..maxRL)) OF
                                    DL-InformationPerRL-r4
DL-InformationPerRL-List-r5 ::= SEQUENCE (SIZE (1..maxRL)) OF
                                    DL-InformationPerRL-r5
DL-InformationPerRL-List-r5bis ::=
                                    SEQUENCE (SIZE (1..maxRL)) OF
                                        DL-InformationPerRL-r5bis
```

```
DL-InformationPerRL-ListPostFDD ::= SEQUENCE (SIZE (1..maxRL)) OF
                                       DL-InformationPerRL-PostFDD
                                  SEQUENCE {
DL-InformationPerRL-PostFDD ::=
           primaryCPICH-Info
                                               PrimaryCPICH-Info,
    dl-DPCH-InfoPerRL
                                       DL-DPCH-InfoPerRL-PostFDD
}
DL-InformationPerRL-PostTDD ::=
                                SEQUENCE {
    primaryCCPCH-Info
                                       PrimaryCCPCH-InfoPost,
    dl-DPCH-InfoPerRL
                                       DL-DPCH-InfoPerRL-PostTDD
}
DL-InformationPerRL-PostTDD-LCR-r4 ::= SEQUENCE {
   primaryCCPCH-Info
                                       PrimaryCCPCH-InfoPostTDD-LCR-r4,
    dl-DPCH-InfoPerRL
                                       DL-DPCH-InfoPerRL-PostTDD-LCR-r4
}
DL-PDSCH-Information ::=
                                  SEQUENCE {
   pdsch-SHO-DCH-Info
                                       PDSCH-SHO-DCH-Info
                                                                          OPTIONAL,
                                       PDSCH-CodeMapping
    pdsch-CodeMapping
                                                                          OPTIONAL
Dl-rate-matching-restriction ::= SEQUENCE {
   restrictedTrCH-InfoList
                                      RestrictedTrCH-InfoList
                                                                         OPTIONAL
DL-TPC-PowerOffsetPerRL ::= SEQUENCE {
       powerOffsetTPC-pdpdch
                                           PowerOffsetTPC-pdpdch
                                                                         OPTIONAL
-- NOTE: The radio links in the following list have a one-to-one mapping with the
-- radio links in the message.
DL-TPC-PowerOffsetPerRL-List ::=
                                 SEOUENCE (SIZE (1..maxRL)) OF
                                       DL-TPC-PowerOffsetPerRL
DL-TS-ChannelisationCode ::=
                                   ENUMERATED {
                                       cc16-1, cc16-2, cc16-3, cc16-4,
                                       cc16-5, cc16-6, cc16-7, cc16-8,
                                       cc16-9, cc16-10, cc16-11, cc16-12,
                                       cc16-13, cc16-14, cc16-15, cc16-16 }
DL-TS-ChannelisationCodesShort ::= SEQUENCE {
    codesRepresentation
                                       CHOICE {
        consecutive
                                          SEQUENCE {
           firstChannelisationCode
                                               DL-TS-ChannelisationCode,
                                               DL-TS-ChannelisationCode
            lastChannelisationCode
                                           BIT STRING {
        bitmap
                                               chCode16-SF16(0),
                                               chCode15-SF16(1),
                                               chCode14-SF16(2),
                                               chCode13-SF16(3),
                                               chCode12-SF16(4),
                                               chCode11-SF16(5),
                                               chCode10-SF16(6),
                                               chCode9-SF16(7),
                                               chCode8-SF16(8),
                                               chCode7-SF16(9),
                                               chCode6-SF16(10),
                                               chCode5-SF16(11),
                                               chCode4-SF16(12),
                                               chCode3-SF16(13),
                                               chCode2-SF16(14).
                                               chCode1-SF16(15)
                                               } (SIZE (16))
DownlinkAdditionalTimeslots ::=
                                   SEOUENCE {
   parameters
       sameAsLast.
                                           SEQUENCE {
           timeslotNumber
                                               TimeslotNumber
        },
        newParameters
                                           SEQUENCE {
           individualTimeslotInfo
                                               IndividualTimeslotInfo,
           dl-TS-ChannelisationCodesShort
                                               DL-TS-ChannelisationCodesShort
```

```
}
}
DownlinkAdditionalTimeslots-LCR-r4 ::= SEQUENCE {
   parameters
                                       CHOICE {
                                         SEQUENCE {
       sameAsLast
           timeslotNumber
                                               TimeslotNumber-LCR-r4
       newParameters
                                           SEQUENCE {
           individualTimeslotInfo
                                               IndividualTimeslotInfo-LCR-r4,
           dl-TS-ChannelisationCodesShort
                                               DL-TS-ChannelisationCodesShort
    }
}
                              SEQUENCE {
DownlinkTimeslotsCodes ::=
    firstIndividualTimeslotInfo IndividualTimeslotInfo,
   dl-TS-ChannelisationCodesShort
                                       DL-TS-ChannelisationCodesShort,
   moreTimeslots
                                       CHOICE {
                                           NULL,
       noMore
                                           CHOICE {
       additionalTimeslots
           consecutive
                                               INTEGER (1..maxTS-1),
           timeslotList
                                               SEQUENCE (SIZE (1..maxTS-1)) OF
                                                   DownlinkAdditionalTimeslots
        }
    }
}
DownlinkTimeslotsCodes-LCR-r4 ::= SEQUENCE {
    firstIndividualTimeslotInfo
                                       IndividualTimeslotInfo-LCR-r4,
    dl-TS-ChannelisationCodesShort
                                       DL-TS-ChannelisationCodesShort,
   moreTimeslots
                                       CHOICE {
                                           NULL,
       noMore
       additionalTimeslots
                                           CHOICE {
                                               INTEGER (1..maxTS-LCR-1),
           consecutive
            timeslotList
                                               SEQUENCE (SIZE (1..maxTS-LCR-1)) OF
                                                   DownlinkAdditionalTimeslots-LCR-r4
        }
}
DPC-Mode ::=
                                    ENTIMERATED {
                                       singleTPC.
                                       tpcTripletInSoft }
-- Actual value DPCCH-PowerOffset = IE value * 2
DPCCH-PowerOffset ::=
                                   INTEGER (-82..-3)
-- Actual value DPCCH-PowerOffset2 = 2 + (IE value * 4)
DPCCH-PowerOffset2 ::=
                                   INTEGER (-28..-13)
DPCH-CompressedModeInfo ::=
                                   SEQUENCE {
   tgp-SequenceList
                                     TGP-SequenceList
DPCH-CompressedModeStatusInfo ::= SEQUENCE {
    {\tt tgps-Reconfiguration-CFN} \qquad \qquad {\tt TGPS-Reconfiguration-CFN},
    tgp-SequenceShortList
                                          SEQUENCE (SIZE (1..maxTGPS)) OF
                                           TGP-SequenceShort
}
 -- Actual value DPCH-FrameOffset = IE value * 256
DPCH-FrameOffset::=
                                   INTEGER (0..149)
DSCH-Mapping ::=
                                   SEQUENCE {
   maxTFCI-Field2Value
                                       MaxTFCI-Field2Value,
    spreadingFactor
                                       SF-PDSCH,
                                       CodeNumberDSCH,
   codeNumber
   multiCodeInfo
                                       MultiCodeInfo
DSCH-MappingList ::=
                                   SEQUENCE (SIZE (1..maxPDSCH-TFCIgroups)) OF
                                       DSCH-Mapping
DSCH-RadioLinkIdentifier ::=
                                   INTEGER (0..511)
                                   SEQUENCE (SIZE (1..maxTrCH)) OF
DSCH-TransportChannelsInfo ::=
                                       SEQUENCE {
```

```
dsch-transport-channel-identity
                                            TransportChannelIdentity,
    dsch-TFS
                                            TransportFormatSet
}
DurationTimeInfo ::=
                                    INTEGER (1..4096)
DynamicPersistenceLevel ::=
                                    INTEGER (1..8)
DynamicPersistenceLevelList ::=
                                    SEQUENCE (SIZE (1..maxPRACH)) OF
                                        DynamicPersistenceLevel
DynamicPersistenceLevelTF-List ::= SEQUENCE (SIZE (1..maxTF-CPCH)) OF
                                        DynamicPersistenceLevel
                                    SEQUENCE {
FACH-PCH-Information ::=
    transportFormatSet
                                        TransportFormatSet,
    transportChannelIdentity
                                        TransportChannelIdentity,
    ctch-Indicator
                                        BOOLEAN
FACH-PCH-InformationList ::=
                                    SEQUENCE (SIZE (1..maxFACHPCH)) OF
                                        FACH-PCH-Information
Feedback-cycle ::=
                                    ENUMERATED {
                                        fc0, fc2, fc4, fc8, fc10, fc20, fc40, fc80, fc160}
FPACH-Info-r4 ::=
                                        SEQUENCE {
   timeslot
                                        TimeslotNumber-LCR-r4,
    channelisationCode
                                        TDD-FPACH-CCode16-r4,
   \verb|midambleShiftAndBurstType|\\
                                        MidambleShiftAndBurstType-LCR-r4,
                                        Wi-LCR
FrequencyInfo ::=
                                    SEQUENCE {
                                        CHOICE {
    modeSpecificInfo
        fdd
                                            FrequencyInfoFDD,
        tdd
                                            FrequencyInfoTDD
}
FrequencyInfoFDD ::=
                                    SEOUENCE {
   uarfcn-UL
                                        UARFCN
                                                             OPTIONAL,
   uarfcn-DL
                                        UARFCN
}
FrequencyInfoTDD ::=
                                    SEQUENCE {
   uarfcn-Nt
                                        UARFCN
                                    ENUMERATED {
HS-ChannelisationCode-LCR ::=
                                        cc16-1, cc16-2, cc16-3, cc16-4,
                                        cc16-5, cc16-6, cc16-7, cc16-8,
                                        cc16-9, cc16-10, cc16-11, cc16-12,
                                        cc16-13, cc16-14, cc16-15, cc16-16 }
HS-PDSCH-Midamble-Configuration-TDD128 ::= SEQUENCE {
    midambleAllocationMode
                                        CHOICE {
        defaultMidamble
                                            NULL.
        common Midamble
                                            NULL,
        ueSpecificMidamble
                                            INTEGER (0..15)
    -- Actual value midambleConfiguration = IE value * 2
   midambleConfiguration
                                        INTEGER (1..8)
}
HS-SCCH-Info ::=
                                    SEOUENCE {
                                        CHOICE {
    modeSpecificInfo
        fdd
                                            SEQUENCE {
            hS-SCCHChannelisationCodeInfo
                                                SEQUENCE (SIZE (1..maxHSSCCHs)) OF
                                                    HS-SCCH-Codes,
            dl-ScramblingCode
                                                SecondaryScramblingCode
                                                                             OPTIONAL
        bb†
                                            CHOICE {
            tdd384
                                                SEQUENCE {
                                                   INTEGER (-7..8),
                nack-ack-power-offset
                hs-SICH-PowerControl-Info
                                                   HS-SICH-Power-Control-Info-TDD384,
                hS-SCCH-SetConfiguration
                                                   SEQUENCE (SIZE (1..maxHSSCCHs)) OF
                        HS-SCCH-TDD384
                },
```

```
tdd128
                                                SEQUENCE (SIZE (1..maxHSSCCHs)) OF
                                                    HS-SCCH-TDD128
        }
    }
HS-SCCH-Codes ::=
                                   INTEGER (0..127)
HS-SCCH-TDD128 ::=
                               SEQUENCE {
    timeslotNumber
                                       TimeslotNumber-LCR-r4,
    firstChannelisationCode
                                        HS-ChannelisationCode-LCR,
    secondChannelisationCode
                                       HS-ChannelisationCode-LCR,
    midambleAllocationMode
                                       CHOICE {
       defaultMidamble
                                           NULL,
       commonMidamble
                                            NULL,
       ueSpecificMidamble
                                           INTEGER(0..15)
    -- Actual value midambleConfiguration = IE value * 2
    midambleConfiguration
                                       INTEGER (1..8),
    bler-target
                                        Bler-Target,
   hs-sich-configuration
                                       HS-SICH-Configuration-TDD128
}
HS-SICH-Configuration-TDD128 ::= SEQUENCE {
    timeslotNumber
                                       TimeslotNumber-LCR-r4.
    channelisationCode
                                       HS-ChannelisationCode-LCR,
    midambleAllocationMode
                                       CHOICE {
        defaultMidamble
                                           NULL.
       ueSpecificMidamble
                                           SEQUENCE {
           midambleShift
                                               MidambleShiftLong
    -- Actual value midambleConfiguration = IE value * 2
                                       INTEGER (1..8),
   midambleConfiguration
    nack-ack-power-offset
                                       INTEGER (-7..8),
    power-level-HSSICH
                                        INTEGER (-120..-58),
                                       ENUMERATED { s1, s2, s3 , spare1}
    tpc-step-size
}
HS-SCCH-TDD384 ::=
                               SEQUENCE {
    timeslotNumber
                                       TimeslotNumber,
                                        DL-TS-ChannelisationCode,
    channelisationCode
                                        CHOICE {
    midambleAllocationMode
       defaultMidamble
                                           NULL,
        commonMidamble
                                            NULL,
       ueSpecificMidamble
                                            SEQUENCE {
                                               MidambleShiftLong
           midambleShift
    midambleconfiguration
                                       MidambleConfigurationBurstTypeland3,
    bler-target
                                       Bler-Target,
                                       HS-SICH-Configuration-TDD384
   hs-sich-configuration
}
HS-SICH-Configuration-TDD384 ::= SEQUENCE {
    timeslotNumber
                                       TimeslotNumber,
    channelisationCode
                                        DL-TS-ChannelisationCode,
    midambleAllocationMode
                                        CHOICE {
       defaultMidamble
                                           NULL,
       ueSpecificMidamble
                                           SEQUENCE {
                                               MidambleShiftLong
           midambleShift
    midambleconfiguration
                                       MidambleConfigurationBurstTypeland3
}
HS-SICH-Power-Control-Info-TDD384 ::= SEQUENCE {
    -- Actual value ul-target-SIR = IE value * 0.5
                                       INTEGER (-22..40),
    ul-target-SIR
   hs-sich-ConstantValue
                                       ConstantValue
IndividualTimeslotInfo ::=
                                    SEQUENCE {
    timeslotNumber
                                       TimeslotNumber,
    tfci-Existence
   midambleShiftAndBurstType
                                       MidambleShiftAndBurstType
```

```
IndividualTimeslotInfo-LCR-r4 ::= SEQUENCE {
        timeslotNumber
                                                                                     TimeslotNumber-LCR-r4,
        tfci-Existence
                                                                                     BOOLEAN,
        midambleShiftAndBurstType
                                                                                     MidambleShiftAndBurstType-LCR-r4,
                                                                                    ENUMERATED { mod-QPSK, mod-8PSK },
        modulation
        ss-TPC-Symbols
                                                                                     ENUMERATED { zero, one, sixteenOverSF },
        additionalSS-TPC-Symbols
                                                                                    INTEGER(1..15)
                                                                                                                               OPTIONAL
}
IndividualTimeslotInfo-LCR-r4-ext ::=
                                                                                            SEQUENCE {
-- timeslotNumber and tfci-Existence is taken from IndividualTimeslotInfo.
-- midambleShiftAndBurstType in IndividualTimeslotInfo shall be ignored.
        midambleShiftAndBurstType
                                                                                   MidambleShiftAndBurstType-LCR-r4
                                                                                     ENUMERATED { mod-QPSK, mod-8PSK },
ENUMERATED { zero, one, sixteenOverSF }
        modulation
        ss-TPC-Symbols
}
IndividualTS-Interference ::=
                                                                            SEQUENCE {
                                                                                     TimeslotNumber,
        timeslot
        ul-TimeslotInterference
                                                                                     TDD-UL-Interference
                                                                             SEQUENCE (SIZE (1..maxTS)) OF
IndividualTS-InterferenceList ::=
                                                                                     IndividualTS-Interference
ITP ::=
                                                                             ENUMERATED {
                                                                                    mode0, mode1 }
NidentifyAbort ::= INTEGER (1..128)
MaxAllowedUL-TX-Power ::=
                                                                            INTEGER (-50..33)
MaxAvailablePCPCH-Number ::=
                                                                           INTEGER (1..64)
MaxPowerIncrease-r4 ::=
                                                                            INTEGER (0..3)
MaxTFCI-Field2Value ::=
                                                                            INTEGER (1..1023)
Measurement-Feedback-Info ::=
                                                                             SEQUENCE {
        modeSpecificInfo
                                                                             CHOICE {
                                                                                     SEQUENCE {
                 fdd
                         measurementPowerOffset
                                                                                            MeasurementPowerOffset,
                         feedback-cycle
                                                                                              Feedback-cycle,
                                                                                             CQI-RepetitionFactor,
                         cqi-RepetitionFactor
                         deltaCQI
                                                                                             DeltaCQI
                 },
                 tdd
                                                                                     NULL
        }
}
MidambleConfigurationBurstTypeland3 ::= ENUMERATED {ms4, ms8, ms16}
MidambleConfigurationBurstType2 ::=
                                                                                 ENUMERATED {ms3, ms6}
                                                                            SEQUENCE {
MidambleShiftAndBurstType ::=
        burstType
                                                                                    CHOICE {
                                                                                            SEQUENCE {
                type1
                         \verb|midamble| Configuration BurstType| and 3 \verb|Midamble| Configuration BurstType| and 3 \verb|, in the configuration b
                         midambleAllocationMode
                                                                                                      CHOICE {
                                  defaultMidamble
                                                                                                               NULL,
                                  common Midamble
                                                                                                               NULL,
                                  ueSpecificMidamble
                                                                                                               SEQUENCE {
                                          midambleShift
                                                                                                                       MidambleShiftLong
                         }
                 },
                                                                                              SEQUENCE {
                 type2
                         \verb|midamble| Configuration BurstType2|
                                                                                                      MidambleConfigurationBurstType2,
                                                                                                       CHOICE {
                         midambleAllocationMode
                                 defaultMidamble
                                                                                                              NULL,
                                  commonMidamble
                                                                                                               NULT.
                                  ueSpecificMidamble
                                                                                                               SEQUENCE {
                                          midambleShift
                                                                                                                       MidambleShiftShort
                         }
                 },
```

```
SEQUENCE {
            midambleConfigurationBurstTypeland3 MidambleConfigurationBurstTypeland3,
                                                 CHOICE {
            midambleAllocationMode
                defaultMidamble
                                                     NULL,
                ueSpecificMidamble
                                                      SEQUENCE {
                    midambleShift
                                                         MidambleShiftLong
            }
       }
    }
}
MidambleShiftAndBurstType-LCR-r4 ::=
                                       SEQUENCE {
    midambleAllocationMode
                                         CHOICE {
        defaultMidamble
                                             NULL,
        commonMidamble
                                             NULL,
        ueSpecificMidamble
                                             SEQUENCE {
                                                 INTEGER (0..15)
            midambleShift
    -- Actual value midambleConfiguration = IE value * 2
    midambleConfiguration
                                        INTEGER (1..8)
}
MidambleShiftAndBurstType-DL ::=
                                         SEQUENCE {
    burstType
                                         CHOICE {
                                             SEQUENCE {
        type1
            \verb| midamble| Configuration BurstType| 1 and 3 \verb| Midamble| Configuration BurstType| 1 and 3, \\
            midambleAllocationMode
                                                 CHOICE {
                defaultMidamble
                                                     NULL,
                commonMidamble
                                                     NULL,
                ueSpecificMidamble
                                                     SEQUENCE {
                    midambleShift
                                                         MidambleShiftLong
            }
        },
                                             SEQUENCE {
        type2
            \verb|midamble| Configuration BurstType2|
                                                 MidambleConfigurationBurstType2,
            midambleAllocationMode
                                                  CHOICE {
                defaultMidamble
                                                     NULL,
                common Midamble
                                                     NULL,
                ueSpecificMidamble
                                                     SEQUENCE {
                    midambleShift
                                                         MidambleShiftShort
           }
       }
}
MidambleShiftLong ::=
                                    INTEGER (0..15)
MidambleShiftShort ::=
                                     INTEGER (0..5)
MinimumSpreadingFactor ::=
                                     ENUMERATED {
                                         sf4, sf8, sf16, sf32,
                                         sf64, sf128, sf256 }
MultiCodeInfo ::=
                                     INTEGER (1..16)
N-EOT ::=
                                     INTEGER (0..7)
                                     ENUMERATED {
N-GAP ::=
                                         f2, f4, f8 }
N-PCH ::=
                                     INTEGER (1..8)
N-StartMessage ::=
                                     INTEGER (1..8)
NB01 ::=
                                     INTEGER (0..50)
NF-Max ::=
                                     INTEGER (1..64)
NumberOfDPDCH ::=
                                     INTEGER (1..maxDPDCH-UL)
NumberOfFBI-Bits ::=
                                     INTEGER (1..2)
```

```
OpenLoopPowerControl-TDD ::= SEQUENCE {
                                    PrimaryCCPCH-TX-Power,
   primaryCCPCH-TX-Power
   -- alpha, prach-ConstantValue, dpch-ConstantValue and pusch-ConstantValue
   -- shall be ignored in 1.28Mcps TDD mode.
   alpha
                                     Alpha
                                                                OPTIONAL.
                                     ConstantValueTdd,
ConstantValueTdd OPTIONAL
                                     ConstantValueTdd,
   prach-ConstantValue
   dpch-ConstantValue
   pusch-ConstantValue
}
OpenLoopPowerControl-IPDL-TDD-r4 ::= SEQUENCE {
   ipdl-alpha
                                     Alpha.
   maxPowerIncrease
                                     MaxPowerIncrease-r4
                                ENUMERATED {
PagingIndicatorLength ::=
                                     pi4, pi8, pi16 }
PC-Preamble ::=
                                  INTEGER (0..7)
                                 ENUMERATED {
PCP-Length ::=
                                    as0, as8 }
PCPCH-ChannelInfo ::=
                                  SEQUENCE {
                                 INTEGER (0..79),
INTEGER (0..511),
   pcpch-UL-ScramblingCode
   pcpch-DL-ChannelisationCode
                                  SecondaryScramblingCode
   pcpch-DL-ScramblingCode
                                                                      OPTIONAL,
                                     PCP-Length,
   pcp-Length
   ucsm-Info
                                     UCSM-Info
                                                                      OPTIONAL
}
PCPCH-ChannelInfoList ::=
                                SEQUENCE (SIZE (1..maxPCPCHs)) OF
                                     PCPCH-ChannelInfo
PCPICH-UsageForChannelEst ::=
                                  ENUMERATED {
                                     mayBeUsed,
                                     shallNotBeUsed }
PDSCH-CapacityAllocationInfo ::= SEQUENCE {
   -- pdsch-PowerControlInfo is conditional on new-configuration branch below, if this
   -- selected the IE is OPTIONAL otherwise it should not be sent
   pdsch-PowerControlInfo
                            PDSCH-PowerControlInfo
                                                                      OPTIONAL,
   pdsch-AllocationPeriodInfo
                                   AllocationPeriodInfo,
   configuration
                                     CHOICE {
       figuration
old-Configuration
                                      SEQUENCE {
          tfcs-ID
                                            TFCS-IdentityPlain
                                                                               DEFAULT 1,
          pdsch-Identity
                                             PDSCH-Identity
       new-Configuration
                                         SEQUENCE {
                                           PDSCH-Info,
         pdsch-Info
                                             PDSCH-Identity
                                                                      OPTIONAL
           pdsch-Identity
       }
   }
PDSCH-CapacityAllocationInfo-r4 ::= SEQUENCE {
   pdsch-AllocationPeriodInfo
AllocationPeriodInfo,
   configuration
                                     CHOICE {
                                      SEQUENCE {
       old-Configuration
                                             TFCS-IdentityPlain
          tfcs-TD
                                                                             DEFAULT 1.
          pdsch-Identity
                                             PDSCH-Identity
       new-Configuration
                                       SEQUENCE {
                                         PDSCH-Info-r4,
          pdsch-Info
           pdsch-Identity
                                                                       OPTIONAL.
                                             PDSCH-Identity
          pdsch-PowerControlInfo
                                            PDSCH-PowerControlInfo OPTIONAL
   }
}
PDSCH-CodeInfo ::=
                                  SEQUENCE {
   spreadingFactor
                                     SF-PDSCH,
                                     CodeNumberDSCH,
   codeNumber
                                     MultiCodeInfo
   multiCodeInfo
PDSCH-CodeInfoList ::=
                                SEQUENCE (SIZE (1..maxTFCI-2-Combs)) OF
                                     PDSCH-CodeInfo
```

```
SEQUENCE {
PDSCH-CodeMap ::=
                                  SF-PDSCH,
   spreadingFactor
   multiCodeInfo
                                     MultiCodeInfo,
   codeNumberStart
                                     CodeNumberDSCH,
   codeNumberStop
                                     CodeNumberDSCH
}
PDSCH-CodeMapList ::=
                                  SEQUENCE (SIZE (1..maxPDSCH-TFCIgroups)) OF
                                     PDSCH-CodeMap
                                  SEQUENCE {
PDSCH-CodeMapping ::=
                                     SecondaryScramblingCode OPTIONAL,
   dl-ScramblingCode
                                     CHOICE {
   signallingMethod
       codeRange
                                        CodeRange,
                                         DSCH-MappingList,
       tfci-Range
                                         PDSCH-CodeInfoList,
       explicit-config
       replace
                                         ReplacedPDSCH-CodeInfoList
}
PDSCH-Identity ::=
                                 INTEGER (1..hiPDSCHidentities)
                                  SEQUENCE {
PDSCH-Info ::=
                                                                       DEFAULT 1,
   tfcs-ID
                                  TFCS-IdentityPlain
   commonTimeslotInfo
                                     CommonTimeslotInfo
                                                                       OPTIONAL,
                                     DownlinkTimeslotsCodes
   pdsch-TimeslotsCodes
                                                                       OPTIONAL
}
PDSCH-Info-r4 ::=
                                     SEQUENCE {
   tfcs-ID
                                     TFCS-IdentityPlain
   commonTimeslotInfo
                                     CommonTimeslotInfo
                                                                       OPTIONAL,
   tddOption
                                     CHOICE {
       tdd384
                                        SEQUENCE {
          pdsch-TimeslotsCodes
                                          DownlinkTimeslotsCodes
                                                                      OPTIONAL
          pdsch-TimeslotsCodes SEQUENCE {
       tdd128
                                            DownlinkTimeslotsCodes-LCR-r4 OPTIONAL
   }
}
PDSCH-Info-LCR-r4 ::=
                                  SEQUENCE {
                                  SEQUENCE {
TFCS-IdentityPlain
                                                                      DEFAULT 1,
   tfcs-ID
   commonTimeslotInfo
                                      CommonTimeslotInfo
                                                                       OPTIONAL,
   pdsch-TimeslotsCodes
                                     DownlinkTimeslotsCodes-LCR-r4
                                                                       OPTIONAL
}
PDSCH-PowerControlInfo ::= SEQUENCE {
   tpc-StepSizeTDD
                                     TPC-StepSizeTDD
                                                                        OPTIONAL,
                                     UL-CCTrChTPCList
   ul-CCTrChTPCList
                                                                        OPTIONAL
}
   CH-SHO-DCH-Info ::= SEQUENCE {
dsch-RadioLinkIdentifier DSCH-Ra
RI,-Ide
PDSCH-SHO-DCH-Info ::=
                                 DSCH-RadioLinkIdentifier,
   rl-IdentifierList
                                     RL-IdentifierList
                                                                       OPTIONAL
}
                               SEQUENCE {
PDSCH-SysInfo ::=
                                     PDSCH-Identity,
   pdsch-Identity
   pdsch-Info
                                     PDSCH-Info,
   dsch-TFS
                                     TransportFormatSet
                                                                        OPTIONAL,
   dsch-TFCS
                                                                        OPTIONAL
}
PDSCH-SysInfo-HCR-r5 ::=
                                         SEQUENCE {
   pdsch-Identity
                                   PDSCH-Identity,
                                     PDSCH-Info,
   pdsch-Info
   dsch-TransportChannelsInfo
                                     DSCH-TransportChannelsInfo
                                                                      OPTIONAL.
   dsch-TFCS
                                     TFCS
                                                                        OPTIONAL
}
PDSCH-SysInfo-LCR-r4 ::=
                                 SEQUENCE {
   pdsch-Identity
                                     PDSCH-Identity,
   pdsch-Info
                                      PDSCH-Info-LCR-r4,
   dsch-TFS
                                      TransportFormatSet
                                                                        OPTIONAL,
   dsch-TFCS
                                      TFCS
                                                                        OPTIONAL
```

```
}
                                   SEQUENCE (SIZE (1..maxPDSCH)) OF
PDSCH-SysInfoList ::=
                                       PDSCH-SysInfo
PDSCH-SysInfoList-HCR-r5 ::=
                                        SEQUENCE (SIZE (1..maxPDSCH)) OF PDSCH-SysInfo-HCR-r5
PDSCH-SysInfoList-LCR-r4 ::= SEQUENCE (SIZE (1..maxPDSCH)) OF
                                        PDSCH-SysInfo-LCR-r4
                                    SEQUENCE (SIZE (1..maxPDSCH)) OF
PDSCH-SysInfoList-SFN ::=
                                        SEQUENCE {
    pdsch-SysInfo
                                            PDSCH-SysInfo,
   sfn-TimeInfo
                                            SFN-TimeInfo
                                                                            OPTIONAL
}
PDSCH-SysInfoList-SFN-HCR-r5 ::=
                                            SEQUENCE (SIZE (1..maxPDSCH)) OF
                                         SEQUENCE {
                                            PDSCH-SysInfo-HCR-r5,
    pdsch-SysInfo
    sfn-TimeInfo
                                             SFN-TimeInfo
                                                                            OPTIONAL
}
PDSCH-SysInfoList-SFN-LCR-r4 ::= SEQUENCE (SIZE (1..maxPDSCH)) OF
                                        SEQUENCE {
                                            PDSCH-SysInfo-LCR-r4,
    pdsch-SysInfo
    sfn-TimeInfo
                                            SFN-TimeInfo
                                                                             OPTIONAL
PersistenceScalingFactor ::=
                                    ENUMERATED {
                                         psf0-9, psf0-8, psf0-7, psf0-6,
                                         psf0-5, psf0-4, psf0-3, psf0-2 }
                                    SEQUENCE (SIZE (1..maxASCpersist)) OF
PersistenceScalingFactorList ::=
                                        PersistenceScalingFactor
PI-CountPerFrame ::=
                                    ENUMERATED {
                                        e18, e36, e72, e144 }
PichChannelisationCodeList-LCR-r4 ::= SEQUENCE (SIZE (1..2)) OF
                                            DL-TS-ChannelisationCode
                                    CHOICE {
PICH-Info ::=
    fdd
                                        SEQUENCE {
                                         ChannelisationCode256,
        channelisationCode256
        pi-CountPerFrame
                                            PI-CountPerFrame,
        sttd-Indicator
                                            BOOLEAN
    tdd
                                       SEQUENCE {
                                            TDD-PICH-CCode
        channelisationCode
                                                                             OPTIONAL,
        timeslot
                                            TimeslotNumber
        timeslot
midambleShiftAndBurstType
midambleShiftAndBurstType
repetitionPeriodLengthOffset
RepPerLengthOffset-PICH
PagingIndicatorLength
                                                                             OPTIONAL,
                                            MidambleShiftAndBurstType,
                                            RepPerLengthOffset-PICH
                                                                             OPTIONAL,
                                                                           DEFAULT pi4,
                                                                             DEFAULT f4,
        n-GAP
                                                                             DEFAULT 2
        n-PCH
                                            N-PCH
    }
PICH-Info-LCR-r4 ::=
                                    SEQUENCE {
                                       TimeslotNumber-LCR-r4
    timeslot
                                                                             OPTIONAL.
    \verb|pichChannelisationCodeList-LCR-r4| PichChannelisationCodeList-LCR-r4|,
                                MidambleShiltAngurselyee - RepPerLengthOffset-PICH
   midambleShiftAndBurstType
                                        MidambleShiftAndBurstType-LCR-r4,
   repetitionPeriodLengthOffset
                                                                             OPTIONAL,
                                                                         DEFAULT pi4,
   pagingIndicatorLength
                                        PagingIndicatorLength
                                                                         DEFAULT f4,
   n-GAP
                                        N-GAP
   n-PCH
                                        N-PCH
                                                                         DEFAULT 2
}
                                   INTEGER (-10..5)
PICH-PowerOffset ::=
PilotBits128 ::=
                                    ENUMERATED {
                                        pb4, pb8 }
PilotBits256 ::=
                                    ENUMERATED {
                                        pb2, pb4, pb8 }
    -- Actual measurement power offset value = IE value * 0.5
MeasurementPowerOffset ::=
                                    INTEGER (-12..26)
```

```
PositionFixedOrFlexible ::=
                                   ENUMERATED {
                                       fixed,
                                       flexible }
PowerControlAlgorithm ::=
                                   CHOICE {
    algorithm1
                                       TPC-StepSizeFDD,
                                       NULL
    algorithm2
PowerOffsetPilot-pdpdch ::=
                                  INTEGER (0..24)
PowerOffsetTPC-pdpdch ::=
                                  INTEGER (0..24)
PowerRampStep ::=
                                   INTEGER (1..8)
PRACH-ChanCodes-LCR-r4 ::=
                                   SEQUENCE (SIZE (1..4)) OF
                                       TDD-PRACH-CCode-LCR-r4
PRACH-Definition-LCR-r4 ::=
                                   SEQUENCE {
                                      TimeslotNumber-PRACH-LCR-r4,
   timeslot
    prach-ChanCodes-LCR
                                       PRACH-ChanCodes-LCR-r4,
    midambleShiftAndBurstType
                                       MidambleShiftAndBurstType-LCR-r4,
    fpach-Info
                                       FPACH-Info-r4
PRACH-Midamble ::=
                                   ENUMERATED {
                                       direct,
                                       direct-Inverted }
PRACH-Partitioning ::=
                                   CHOICE {
                                      SEQUENCE (SIZE (1..maxASC)) OF
    -- TABULAR: If only "NumASC+1" (with, NumASC+1 < maxASC) ASCSetting-FDD are listed,
    -- the remaining (NumASC+2 through maxASC) ASCs are unspecified.
                                           ASCSetting-FDD,
                                       SEQUENCE (SIZE (1..maxASC)) OF
    -- TABULAR: If only "NumASC+1" (with, NumASC+1 < maxASC) ASCSetting-TDD are listed,
    -- the remaining (NumASC+2 through maxASC) ASCs are unspecified.
                                           ASCSetting-TDD
}
PRACH-Partitioning-LCR-r4 ::=
                                  SEQUENCE (SIZE (1..maxASC)) OF
    -- TABULAR: If only "NumASC+1" (with, NumASC+1 < maxASC) ASCSetting-TDD-LCR-r4 are listed,
    -- the remaining (NumASC+2 through maxASC) ASCs are unspecified.
                                           ASCSetting-TDD-LCR-r4
                                   SEQUENCE {
PRACH-PowerOffset ::=
   powerRampStep
                                     PowerRampStep,
   preambleRetransMax
                                       PreambleRetransMax
}
PRACH-RACH-Info ::=
                                   SEQUENCE {
   modeSpecificInfo
                                     CHOICE {
                                           SEQUENCE {
           availableSignatures
                                               AvailableSignatures,
                                               SF-PRACH,
           availableSF
           preambleScramblingCodeWordNumber
                                               PreambleScramblingCodeWordNumber,
           puncturingLimit
                                              PuncturingLimit,
           availableSubChannelNumbers
                                              AvailableSubChannelNumbers
        },
        tdd
                                           SEQUENCE {
           timeslot
                                            TimeslotNumber,
           channelisationCodeList
                                               TDD-PRACH-CCodeList,
           prach-Midamble
                                               PRACH-Midamble
        }
    }
}
PRACH-RACH-Info-LCR-r4 ::=
                                   SEOUENCE {
    sync-UL-Info
                                       SYNC-UL-Info-r4,
   prach-DefinitionList
                                       SEQUENCE (SIZE (1..maxPRACH-FPACH)) OF
                                           PRACH-Definition-LCR-r4
}
{\tt PRACH-SystemInformation} ::= \\ {\tt SEQUENCE} \ \{
                                   PRACH-RACH-Info,
   prach-RACH-Info
    transportChannelIdentity
                                       TransportChannelIdentity,
                                                                           OPTIONAL.
    rach-TransportFormatSet
                                       TransportFormatSet
```

```
rach-TFCS
                                       TFCS
                                                                             OPTIONAL,
                                        PRACH-Partitioning
   prach-Partitioning
                                                                             OPTIONAL,
   persistenceScalingFactorList PersistenceScalingFactorList
                                                                            OPTIONAL,
                                       AC-To-ASC-MappingTable
    ac-To-ASC-MappingTable
                                                                            OPTIONAL,
    modeSpecificInfo
                                        CHOICE {
        fdd
                                           SEQUENCE {
                                                                          OPTIONAL,
            primaryCPICH-TX-Power
                                                PrimaryCPICH-TX-Power
                                                PRACH-PowerOffset
                                                                             OPTIONAL,
            constantValue
            prach-PowerOffset
                                                                            OPTIONAL,
            rach-TransmissionParameters
                                                RACH-TransmissionParameters OPTIONAL,
            aich-Info
                                                AICH-Info
                                                                            OPTIONAL
        },
        tdd
                                            NULL
    }
}
{\tt PRACH-SystemInformation-LCR-r4} \ ::= \ {\tt SEQUENCE} \ \{
   prach-RACH-Info-LCR PRACH-RACH-Info-LCR-r4, rach-TransportFormatSet-LCR prach-Partitioning-LCR PRACH-Dartitioning-LCR
                                                                       OPTIONAL,
                                       PRACH-Partitioning-LCR-r4
   prach-Partitioning-LCR
                                                                        OPTIONAL
}
PRACH-SystemInformationList ::= SEQUENCE (SIZE (1..maxPRACH)) OF
                                        PRACH-SystemInformation
PRACH-SystemInformationList-LCR-r4 ::= SEQUENCE (SIZE (1..maxPRACH)) OF
                                            PRACH-SystemInformation-LCR-r4
PreambleRetransMax ::=
                                    INTEGER (1..64)
PreambleScramblingCodeWordNumber ::=
                                      INTEGER (0..15)
                                SEQUENCE {
PreDefPhyChConfiguration ::=
    ul-DPCH-InfoPredef
                                       UL-DPCH-InfoPredef.
    dl-CommonInformationPredef
                                        DL-CommonInformationPredef OPTIONAL
PrimaryCCPCH-Info ::=
                                    CHOICE {
                                        SEQUENCE {
    fdd
        tx-DiversityIndicator
                                            BOOLEAN
                                        SEQUENCE {
    t.dd
        -- syncCase should be ignored for 1.28Mcps TDD mode
        syncCase
                                            CHOICE {
            syncCase1
                                                SEQUENCE {
               timeslot
                                                    TimeslotNumber
            },
            syncCase2
                                                SEQUENCE {
                timeslotSync2
                                                    TimeslotSync2
            }
                                                                             OPTIONAL,
        cellParametersID
                                            CellParametersID
                                                                             OPTIONAL,
        sctd-Indicator
                                            BOOLEAN
    }
}
PrimaryCCPCH-Info-r4 ::=
                                    CHOICE {
                                       SEQUENCE {
        tx-DiversityIndicator
                                            BOOLEAN
    },
                                        SEQUENCE {
    tdd
        tddOption
                                            CHOICE {
            tdd384
                                                SEQUENCE {
                syncCase
                                                    CHOICE {
                                                         SEQUENCE {
                    syncCase1
                        timeslot
                                                            TimeslotNumber
                    },
                    syncCase2
                                                         SEQUENCE {
                                                             TimeslotSync2
                        timeslotSync2
                                                                             OPTIONAL
                }
            tdd128
                                                SEQUENCE {
                tstd-Indicator
                                                    BOOLEAN
        cellParametersID
                                            CellParametersID
                                                                           OPTIONAL,
        sctd-Indicator
                                            BOOLEAN
```

```
}
}
PrimaryCCPCH-Info-LCR-r4 ::= SEQUENCE {
       tstd-Indicator
                                                                               BOOLEAN,
       cellParametersID
                                                                                 CellParametersID
                                                                                                                                              OPTIONAL,
       sctd-Indicator
                                                                                BOOLEAN
}
-- For 1.28Mcps TDD, the following IE includes elements for the PCCPCH Info additional to those
-- in PrimaryCCPCH-Info
PrimaryCCPCH-Info-LCR-r4-ext ::= SEQUENCE {
       tstd-Indicator
                                                                               BOOLEAN
PrimaryCCPCH-InfoPost ::=
                                                                     SEQUENCE {
       syncCase
                                                                             CHOICE {
                                                                                     SEQUENCE {
               syncCase1
                    timeslot
                                                                                               TimeslotNumber
                                                                                        SEQUENCE {
                syncCase2
                    timeslotSync2
                                                                                             TimeslotSync2
        cellParametersID
                                                                               CellParametersID.
        sctd-Indicator
                                                                                BOOLEAN
PrimaryCCPCH-InfoPostTDD-LCR-r4 ::= SEQUENCE {
       tstd-Indicator
                                                                               BOOLEAN,
        cellParametersID
                                                                                 CellParametersID,
       sctd-Indicator
                                                                                BOOLEAN
}
PrimaryCCPCH-TX-Power ::=
                                                                     INTEGER (6..43)
PrimaryCPTCH-Info ::=
                                                                      SEQUENCE {
      primaryScramblingCode
                                                                         PrimaryScramblingCode
PrimaryCPICH-TX-Power ::=
                                                                       INTEGER (-10..50)
PrimaryScramblingCode ::=
                                                                       INTEGER (0..511)
PuncturingLimit ::=
                                                                        ENUMERATED {
                                                                                pl0-40, pl0-44, pl0-48, pl0-52, pl0-56,
                                                                                 pl0-60, pl0-64, pl0-68, pl0-72, pl0-76,
                                                                                pl0-80, pl0-84, pl0-88, pl0-92, pl0-96, pl1 }
PUSCH-CapacityAllocationInfo ::= SEQUENCE {
               pusch-AllocationPending NULL,
pusch-AllocationAssignment SEOUE
       pusch-Allocation
                                                                                      SEQUENCE {
                       pusch-AllocationPeriodInfo AllocationPeriodInfo,
                       pusch-PowerControlInfo
                                                                                                UL-TargetSIR
                                                                                                                                                       OPTIONAL,
                        configuration
                                                                                               CHOICE {
                                old-Configuration
                                                                                                 SEQUENCE {
                                                                                                             TFCS-IdentityPlain
                                      tfcs-ID
                                                                                                                                                                       DEFAULT 1,
                                       pusch-Identity
                                                                                                               PUSCH-Identity
                                new-Configuration
                                                                                                     SEQUENCE {
                                                                                                         PUSCH-Info,
                                    pusch-Info
                                                                                                                 PUSCH-Identity
                                       pusch-Identity
                                                                                                                                                       OPTIONAL
                                }
                     }
             }
       }
}
               pusch-AllocationPending pusch-
PUSCH-CapacityAllocationInfo-r4 ::= SEQUENCE {
       pusch-Allocation
                                                                                        SEQUENCE {
                                                                                     AllocationPeriodInfo,
                       pusch-AllocationPeriodInfo
pusch-PowerControlInfo
                                                                                                PUSCH-PowerControlInfo-r4 OPTIONAL,
                        configuration
                                                                                             CHOICE {
                               old-Configuration
                                                                                                     SEQUENCE {
                                       tfcs-ID
                                                                                                                 TFCS-IdentityPlain
                                                                                                                                                                       DEFAULT 1,
```

```
pusch-Identity
                                                    PUSCH-Identity
               }.
                                              SEQUENCE {
               new-Configuration
                  pusch-Info
                                                   PUSCH-Info-r4,
                                                     PUSCH-Identity
                   pusch-Identity
                                                                       OPTIONAL
           }
       }
   }
}
PUSCH-Identity ::=
                                  INTEGER (1..hiPUSCHidentities)
PUSCH-Info ::=
                                  SEOUENCE {
                                     TFCS-IdentityPlain
                                                                    DEFAULT 1,
OPTIONAL,
OPTIONAL
   tfcs-ID
   commonTimeslotInfo
                                      CommonTimeslotInfo
   pusch-TimeslotsCodes
                                     UplinkTimeslotsCodes
}
PUSCH-Info-r4 ::=
                                  SEQUENCE {
   tfcs-ID
                                     TFCS-IdentityPlain
                                                                        DEFAULT 1,
   commonTimeslotInfo
                                      CommonTimeslotInfo
                                                                        OPTIONAL,
   tddOption
                                      CHOICE {
                                        SEQUENCE {
       tdd384
         pusch-TimeslotsCodes
                                          UplinkTimeslotsCodes
                                                                       OPTIONAL
       tdd128
                                        SEQUENCE {
          pusch-TimeslotsCodes
                                             UplinkTimeslotsCodes-LCR-r4 OPTIONAL
   }
}
PUSCH-Info-LCR-r4 ::=
                                 SEQUENCE {
   tfcs-ID
                                     TFCS-IdentityPlain
                                                                        DEFAULT 1,
   commonTimeslotInfo
                                                                        OPTIONAL.
                                      CommonTimeslotInfo
                                      UplinkTimeslotsCodes-LCR-r4
   pusch-TimeslotsCodes
                                                                        OPTIONAL
}
PUSCH-PowerControlInfo-r4 ::= SEQUENCE {
   -- The IE ul-TargetSIR corresponds to PRX-PUSCHdes for 1.28Mcps TDD
   -- Actual value PRX-PUSCHdes = (value of IE "ul-TargetSIR" - 120)
   ul-TargetSIR
                                     UL-TargetSIR,
   tddOption
                                      CHOICE {
       t.dd384
                                         NULL,
       tdd128
                                          SEQUENCE {
          tpc-StepSize
                                             TPC-StepSizeTDD
                                                                       OPTIONAL
   }
}
PUSCH-SysInfo ::=
                                  SEQUENCE {
   pusch-Identity
                                   PUSCH-Identity,
   pusch-Info
                                      PUSCH-Info,
   usch-TFS
                                      TransportFormatSet
                                                                        OPTIONAL,
   usch-TFCS
}
PUSCH-SysInfo-HCR-r5 ::=
                                         SEQUENCE {
   pusch-Identity
                                    PUSCH-Identity,
   pusch-Info
                                     PUSCH-Info,
   usch-TransportChannelsInfo
                                      USCH-TransportChannelsInfo
                                                                       OPTIONAL,
   usch-TFCS
                                      TFCS
                                                                        OPTIONAL
                                  SEQUENCE {
PUSCH-SysInfo-LCR-r4 ::=
   pusch-Identity
                                     PUSCH-Identity,
   pusch-Info
                                      PUSCH-Info-LCR-r4,
   usch-TFS
                                      TransportFormatSet
                                                                        OPTIONAL,
   usch-TFCS
                                                                        OPTIONAL
                                      TFCS
PUSCH-SysInfoList ::=
                                  SEQUENCE (SIZE (1..maxPUSCH)) OF
                                     PUSCH-SysInfo
PUSCH-SysInfoList-HCR-r5 ::=
                                      SEQUENCE (SIZE (1..maxPUSCH)) OF PUSCH-SysInfo-HCR-r5
PUSCH-SysInfoList-LCR-r4 ::=
                                SEQUENCE (SIZE (1..maxPUSCH)) OF
```

PUSCH-SysInfo-LCR-r4

```
PUSCH-SysInfoList-SFN ::= SEQUENCE (SIZE (1..maxPUSCH)) OF
                                      SEQUENCE {
   pusch-SysInfo
                                         PUSCH-SysInfo,
   sfn-TimeInfo
                                          SFN-TimeInfo
                                                                       OPTIONAL
}
PUSCH-SysInfoList-SFN-HCR-r5 ::=
                                         SEQUENCE (SIZE (1..maxPUSCH)) OF
                                      SEQUENCE {
   pusch-SysInfo
                                       PUSCH-SysInfo-HCR-r5,
                                          SFN-TimeInfo
                                                                        OPTIONAL
   sfn-TimeInfo
}
PUSCH-SysInfoList-SFN-LCR-r4 ::=
                                      SEQUENCE (SIZE (1..maxPUSCH)) OF
                                      SEQUENCE {
   pusch-SysInfo
                                          PUSCH-SysInfo-LCR-r4,
   sfn-TimeInfo
                                          SFN-TimeInfo
                                                                        OPTIONAL
}
RACH-TransmissionParameters ::=
                                 SEQUENCE {
   mmax
                                      INTEGER (1..32),
   nb01Min
                                      NB01,
   nb01Max
                                      NB01
}
ReducedScramblingCodeNumber ::=
                                 INTEGER (0..8191)
RepetitionPeriodAndLength ::= CHOICE {
   repetitionPeriod1
                                     NULL,
   -- repetitionPeriod2 could just as well be NULL also.
   repetitionPeriod2 INTEGER (1..1),
   repetitionPeriod4
                                      INTEGER (1..3),
                                     INTEGER (1..7),
   repetitionPeriod8
   repetitionPeriod16
                                    INTEGER (1..15),
                                      INTEGER (1..31),
   repetitionPeriod32
                                     INTEGER (1..63)
   repetitionPeriod64
}
RepetitionPeriodLengthAndOffset ::= CHOICE {
   repetitionPeriod1
   repetitionPeriod2
                                      SEQUENCE {
       length
                                          NULL,
       offset
                                          INTEGER (0..1)
   repetitionPeriod4
                                      SEQUENCE {
                                         INTEGÈR (1..3),
       length
       offset
                                          INTEGER (0..3)
   repetitionPeriod8
                                      SEQUENCE {
                                          INTEGER (1..7),
       length
       offset
                                          INTEGER (0..7)
   repetitionPeriod16
                                      SEQUENCE {
                                          INTEGÈR (1..15),
       length
       offset
                                          INTEGER (0..15)
   repetitionPeriod32
                                      SEQUENCE {
       length
                                          INTEGER (1..31),
                                          INTEGER (0..31)
       offset
   repetitionPeriod64
                                      SEQUENCE {
       length
                                         INTEGER (1..63),
                                          INTEGER (0..63)
       offset
   }
}
ReplacedPDSCH-CodeInfo ::=
                                 SEQUENCE {
                                    MaxTFCI-Field2Value,
   tfci-Field2
   spreadingFactor
                                      SF-PDSCH.
   codeNumber
                                      CodeNumberDSCH,
   multiCodeInfo
                                      MultiCodeInfo
}
ReplacedPDSCH-CodeInfoList ::= SEQUENCE (SIZE (1..maxTFCI-2-Combs)) OF
                                      ReplacedPDSCH-CodeInfo
                                  CHOICE {
RepPerLengthOffset-PICH ::=
```

```
rpp4-2
                                       INTEGER (0..3),
                                        INTEGER (0..7),
   rpp8-2
   rpp8-4
                                        INTEGER (0..7),
   rpp16-2
                                        INTEGER (0..15),
   rpp16-4
                                        INTEGER (0..15),
   rpp32-2
                                       INTEGER (0..31),
                                        INTEGER (0..31),
INTEGER (0..63),
   rpp32-4
   rpp64-2
   rpp64-4
                                        INTEGER (0..63)
                                    SEQUENCE {
RestrictedTrCH ::=
   dl-restrictedTrCh-Type
                                       DL-TrCH-Type,
   restrictedDL-TrCH-Identity
                                       TransportChannelIdentity,
   allowedTFIList
                                       AllowedTFI-List
}
                                    SEQUENCE (SIZE(1..maxTrCH)) OF
RestrictedTrCH-InfoList ::=
                                       RestrictedTrCH
RL-AdditionInformation ::=
                                    SEQUENCE {
                                      PrimaryCPICH-Info,
   primaryCPICH-Info
    dl-DPCH-InfoPerRL
                                        DL-DPCH-InfoPerRL,
   tfci-CombiningIndicator
                                       BOOLEAN,
                                       SCCPCH-InfoForFACH
   sccpch-InfoforFACH
                                                                            OPTIONAL
}
RL-AdditionInformationList ::=
                                    SEQUENCE (SIZE (1..maxRL-1)) OF
                                       RL-AdditionInformation
RL-IdentifierList ::=
                                    SEQUENCE (SIZE (1..maxRL)) OF
                                       PrimaryCPICH-Info
                                    SEQUENCE (SIZE (1..maxRL)) OF
RL-RemovalInformationList ::=
                                        PrimaryCPICH-Info
RPP ::=
                                    ENUMERATED {
                                       mode0, mode1 }
S-Field ::=
                                    ENUMERATED {
                                        elbit, e2bits }
                                    ENUMERATED {
SCCPCH-ChannelisationCode ::=
                                        cc16-1, cc16-2, cc16-3, cc16-4,
                                        cc16-5, cc16-6, cc16-7, cc16-8,
                                        cc16-9, cc16-10, cc16-11, cc16-12,
                                        cc16-13, cc16-14, cc16-15, cc16-16 }
SCCPCH-ChannelisationCodeList ::=
                                    SEQUENCE (SIZE (1..16)) OF
                                       SCCPCH-ChannelisationCode
SCCPCH-InfoForFACH ::=
                                    SEOUENCE {
    secondaryCCPCH-Info
                                        SecondaryCCPCH-Info,
                                        TFCS,
    modeSpecificInfo
                                    CHOICE {
        fdd
                                        SEQUENCE {
            fach-PCH-InformationList
                                                FACH-PCH-InformationList,
            sib-ReferenceListFACH
                                                SIB-ReferenceListFACH
        },
        tdd
                                        SEQUENCE {
            fach-PCH-InformationList
                                               FACH-PCH-InformationList
    }
}
SCCPCH-InfoForFACH-r4 ::=
                                       SEQUENCE {
    secondaryCCPCH-Info
                                        SecondaryCCPCH-Info-r4,
    tfcs
                                        TFCS,
    fach-PCH-InformationList
                                       FACH-PCH-InformationList,
   modeSpecificInfo
                                    CHOICE {
       fdd
                                      SEQUENCE {
                                          SIB-ReferenceListFACH
           sib-ReferenceListFACH
        },
        tdd
                                        NIII.I.
}
SCCPCH-SystemInformation ::=
                                    SEQUENCE {
```

```
secondaryCCPCH-Info
                                         SecondaryCCPCH-Info,
    tfcs
                                                                               OPTIONAL,
    fach-PCH-InformationList
                                         FACH-PCH-InformationList
                                                                              OPTIONAL,
    pich-Info
                                                                               OPTIONAL
                                         PICH-Info
SCCPCH-SystemInformation-LCR-r4-ext ::= SEQUENCE { secondaryCCPCH-LCR-Extensions SecondaryCCPCH-Info-LCR-r4-ext,
    -- pich-Info in the SCCPCH-SystemInformation IE shall be absent,
    -- and instead the following used.
    pich-Info
                                     PICH-Info-LCR-r4
                                                                              OPTIONAL
SCCPCH-SystemInformationList ::= SEQUENCE (SIZE (1..maxSCCPCH)) OF
                                         SCCPCH-SystemInformation
-- SCCPCH-SystemInformationList-LCR-r4-ext includes elements additional to those in
-- SCCPCH-SystemInformationList for the 1.28 \text{Mcps} TDD. The order of the IEs
-- indicates which SCCPCH-SystemInformation-LCR-r4-ext IE extends which
-- SCCPCH-SystemInformation IE.
\texttt{SCCPCH-SystemInformationList-LCR-r4-ext} \ ::= \ \texttt{SEQUENCE} \ (\texttt{SIZE} \ (\texttt{1..maxSCCPCH})) \ \texttt{OF}
                                                  SCCPCH-SystemInformation-LCR-r4-ext
ScramblingCodeChange ::=
                                     ENUMERATED {
                                         codeChange, noCodeChange }
ScramblingCodeType ::=
                                     ENUMERATED {
                                         shortSC
                                         longSC }
SecondaryCCPCH-Info ::=
                                     SEQUENCE {
    modeSpecificInfo
                                     CHOICE {
                                          SEQUENCE {
        fdd
             -- dummyl is not used in this version of the specification and should be ignored.
            dummv1
                                             PCPICH-UsageForChannelEst,
            -- dummy2 is not used in this version of the specification. It should not
             -- be sent and if received it should be ignored.
            dummy2
                                             SecondaryCPICH-Info
                                                                              OPTIONAL,
            secondaryScramblingCode
                                             SecondaryScramblingCode
                                                                              OPTIONAL,
            sttd-Indicator
                                             BOOLEAN,
            sf-AndCodeNumber
                                             SF256-AndCodeNumber,
            pilotSymbolExistence
                                            BOOLEAN,
            tfci-Existence
positionFixedOrFlexible PositionFixed
TimingOffset
                                            BOOLEAN,
                                             PositionFixedOrFlexible,
                                                                              DEFAULT 0
        },
                                         SEQUENCE {
        tdd.
            -- TABULAR: the offset is included in CommonTimeslotInfoSCCPCH
            commonTimeslotInfo CommonTimeslotInfoSCCPCH, individualTimeslotInfo IndividualTimeslotInfo,
            channelisationCode
                                            SCCPCH-ChannelisationCodeList
        }
    }
SecondaryCCPCH-Info-r4 ::= SEQUENCE {
    modeSpecificInfo CHOICE {
                                      SEQUENCE {
                                         SecondaryScramblingCode BOOLEAN,
            secondaryScramblingCode
                                                                        OPTIONAL,
            sttd-Indicator
                                             SF256-AndCodeNumber,
            sf-AndCodeNumber
            pilotSymbolExistence
                                             BOOLEAN,
            tfci-Existence
                                             BOOLEAN,
            positionFixedOrFlexible
                                             PositionFixedOrFlexible,
                                                                               DEFAIIT O
            timingOffset
                                             TimingOffset
        },
                                         SEQUENCE {
            -- TABULAR: the offset is included in CommonTimeslotInfoSCCPCH
            commonTimeslotInfo
                                             CommonTimeslotInfoSCCPCH,
            tddOption
                                              CHOICE {
                                                SEQUENCE {
                tdd384
                                                     IndividualTimeslotInfo
                    individualTimeslotInfo
                 tdd128
                                                SEQUENCE {
                    individualTimeslotInfo
                                                      IndividualTimeslotInfo-LCR-r4
            channelisationCode
                                            SCCPCH-ChannelisationCodeList
```

```
}
   }
}
SecondaryCCPCH-Info-LCR-r4-ext ::= SEQUENCE {
   individualTimeslotLCR-Ext IndividualTimeslotInfo-LCR-r4-ext
   secondaryDL-ScramblingCode SecondaryDL-ScramblingCode Channel
SecondaryCPICH-Info ::=
                                      SecondaryScramblingCode
                                                                         OPTIONAL,
                                       ChannelisationCode256
                                  INTEGER (1..15)
SecondaryScramblingCode ::=
SecondInterleavingMode ::=
                                  ENUMERATED {
                                       frameRelated, timeslotRelated }
-- SF256-AndCodeNumber encodes both "Spreading factor" and "Code Number"
SF256-AndCodeNumber ::=
                                   CHOICE {
   sf4
                                       INTEGER (0..3),
   sf8
                                       INTEGER (0..7),
   sf16
                                       INTEGER (0..15),
                                       INTEGER (0..31),
   sf32
   sf64
                                       INTEGER (0..63),
    sf128
                                       INTEGER (0..127),
                                       INTEGER (0..255)
   sf256
}
-- SF512-AndCodeNumber encodes both "Spreading factor" and "Code Number"
SF512-AndCodeNumber ::= CHOICE {
                                       INTEGER (0..3),
   sf4
   sf8
                                       INTEGER (0..7),
   sf16
                                       INTEGER (0..15),
   sf32
                                       INTEGER (0..31),
   sf64
                                       INTEGER (0..63),
                                       INTEGER (0..127),
   sf128
   sf256
                                       INTEGER (0..255),
    sf512
                                       INTEGER (0..511)
}
-- SF512-AndPilot encodes both "Spreading factor" and "Number of bits for Pilot bits"
SF512-AndPilot ::=
                                 CHOICE {
                                       NULL,
   sfd8
                                       NULL,
   sfd16
                                       NULL,
   sfd32
                                       NULL,
   sfd64
                                      NULL,
   sfd128
                                       PilotBits128,
   sfd256
                                      PilotBits256,
    sfd512
                                       NULL
SF-PDSCH ::=
                                   ENUMERATED {
                                       sfp4, sfp8, sfp16, sfp32,
                                       sfp64, sfp128, sfp256 }
SF-PRACH ::=
                                   ENUMERATED {
                                      sfpr32, sfpr64, sfpr128, sfpr256 }
SFN-TimeInfo ::=
                                   SEQUENCE {
   activationTimeSFN
                                      INTEGER (0..4095),
                                   DurationTimeInfo
   physChDuration
}
SpecialBurstScheduling ::=
                                      INTEGER (0..7)
SpreadingFactor ::=
                                   ENUMERATED {
                                       sf4, sf8, sf16, sf32,
                                       sf64, sf128, sf256 }
SRB-delay ::=
                                   INTEGER (0..7)
SSDT-CellIdentity ::=
                                   ENUMERATED {
                                       ssdt-id-a, ssdt-id-b, ssdt-id-c,
                                       ssdt-id-d, ssdt-id-e, ssdt-id-f,
                                       ssdt-id-g, ssdt-id-h }
SSDT-Information ::=
                                   SEQUENCE {
```

```
s-Field
                                      S-Field,
                                      CodeWordSet
   codeWordSet
}
SSDT-Information-r4 ::=
                                  SEQUENCE {
                                   S-Field,
  s-Field
   codeWordSet
                                      CodeWordSet,
                                                                              OPTIONAL
   ssdt-UL-r4
                                      SSDT-UL
}
SSDT-UL ::=
                                  ENUMERATED {
                                      ul, ul-AndDL }
SynchronisationParameters-r4 ::= SEQUENCE {
   sync-UL-CodesBitmap
                                   BIT STRING {
                                         code7(0),
                                           code6(1),
                                           code5(2),
                                           code4(3),
                                           code3(4),
                                           code2(5),
                                           code1(6),
                                           code0(7)
                                           } (SIZE (8)),
                                      FPACH-Info-r4,
   fpach-Info
    -- Actual value prxUpPCHdes = IE value - 120
   prxUpPCHdes
                                      INTEGER (0..62),
   sync-UL-Procedure
                                      SYNC-UL-Procedure-r4
                                                                             OPTIONAL
}
SYNC-UL-Procedure-r4 ::=
                                  SEQUENCE {
  max-SYNC-UL-Transmissions
powerRampStep
                                   ENUMERATED { tr1, tr2, tr4, tr8 },
                                      INTEGER (0..3)
}
SYNC-UL-Info-r4 ::=
                                  SEQUENCE {
  NC-UL-Into-r4 ::=
sync-UL-Codes-Bitmap
                                     BIT STRING {
                                          code7(0),
                                           code6(1),
                                           code5(2),
                                           code4(3),
                                           code3(4).
                                           code2(5),
                                           code1(6),
                                           code0(7)
   } ( SIZE (8)),
-- Actual value prxUpPCHdes = IE value - 120
pryUpPCHdes
                  INTEGER (0..62),
   prxUpPCHdes
   powerRampStep
                                       INTEGER (0..3),
   max-SYNC-UL-Transmissions
                                      ENUMERATED { tr1, tr2, tr4, tr8 } ,
                                      INTEGER(1..32)
   mmax
TDD-FPACH-CCode16-r4 ::=
                                   ENUMERATED {
                                      cc16-1, cc16-2, cc16-3, cc16-4,
                                       cc16-5, cc16-6, cc16-7, cc16-8,
                                       cc16-9, cc16-10, cc16-11, cc16-12,
                                       cc16-13, cc16-14, cc16-15, cc16-16 }
                                  INTEGER (-110..-52)
TDD-UIL-Interference ::=
TDD-PICH-CCode ::=
                                   ENUMERATED {
                                      cc16-1, cc16-2, cc16-3, cc16-4,
                                       cc16-5, cc16-6, cc16-7, cc16-8,
                                       cc16-9, cc16-10, cc16-11, cc16-12,
                                       cc16-13, cc16-14, cc16-15, cc16-16 }
TDD-PRACH-CCode8 ::=
                                   ENUMERATED {
                                      cc8-1, cc8-2, cc8-3, cc8-4,
                                       cc8-5, cc8-6, cc8-7, cc8-8 }
                                   ENUMERATED {
TDD-PRACH-CCode16 ::=
                                      cc16-1, cc16-2, cc16-3, cc16-4,
                                       cc16-5, cc16-6, cc16-7, cc16-8,
                                       cc16-9, cc16-10, cc16-11, cc16-12,
                                       cc16-13, cc16-14, cc16-15, cc16-16 }
TDD-PRACH-CCode-LCR-r4 ::=
                                  ENUMERATED {
```

```
cc4-1, cc4-2, cc4-3, cc4-4,
                                          cc8-1, cc8-2, cc8-3, cc8-4,
                                          cc8-5, cc8-6, cc8-7, cc8-8,
                                          cc16-1, cc16-2, cc16-3, cc16-4,
                                          cc16-5, cc16-6, cc16-7, cc16-8,
                                          cc16-9, cc16-10, cc16-11, cc16-12,
                                          cc16-13, cc16-14, cc16-15, cc16-16 }
                                     CHOICE {
TDD-PRACH-CCodeList ::=
                                         SEQUENCE (SIZE (1..8)) OF
                                             TDD-PRACH-CCode8,
-- Channelisation codes cc16-9, cc16-10, cc16-11, cc16-12, cc16-13, cc16-14,
-- cc16-15 and cc16-16 shall not be used
                                          SEQUENCE (SIZE (1..8)) OF
                                              TDD-PRACH-CCode16
}
TFC-ControlDuration ::=
                                     ENUMERATED {
                                          tfc-cd1, tfc-cd2, tfc-cd4, tfc-cd8,
                                          tfc-cd16, tfc-cd24, tfc-cd32, tfc-cd48, tfc-cd64, tfc-cd128,
                                          tfc-cd192, tfc-cd256, tfc-cd512 }
                                     ENUMERATED {
TFCI-Coding ::=
                                         tfci-bits-4, tfci-bits-8, tfci-bits-16, tfci-bits-32 }
TGCFN ::=
                                     INTEGER (0..255)
-- In TGD, value 270 represents "undefined" in the tabular description.
TGD ::=
                                     INTEGER (15..270)
TGL ::=
                                     INTEGER (1..14)
TGMP ::=
                                     ENUMERATED {
                                         tdd-Measurement, fdd-Measurement,
                                          gsm-CarrierRSSIMeasurement,
                                          gsm-initialBSICIdentification, gsmBSICReconfirmation,
                                         multi-carrier }
TGP-Sequence ::=
                                     SEQUENCE {
    tgpsi
                                         TGPSI.
    tgps-Status
                                          CHOICE {
        activate
                                              SEQUENCE {
           tgcfn
                                                  TGCFN
                                              NULL
        deactivate
    tgps-ConfigurationParams
                                         TGPS-ConfigurationParams
                                                                             OPTIONAL
}
                                    INTEGER (0..255)
TGPS-Reconfiguration-CFN ::=
                                     SEQUENCE (SIZE (1..maxTGPS)) OF
TGP-SequenceList ::=
                                         TGP-Sequence
TGP-SequenceShort ::=
                                     SEQUENCE {
                                         TGPSI,
    tgpsi
    tgps-Status
                                          CHOICE {
                                              SEQUENCE {
       activate
            tgcfn
                                                  TGCFN
        deactivate
                                              NULL
    }
}
                                     INTEGER (1..144)
-- TABULAR: In TGPRC, value 0 represents "infinity" in the tabular description.
TGPRC ::=
                                     INTEGER (0..511)
TGPS-ConfigurationParams ::=
                                     SEQUENCE {
   tgmp
                                         TGMP,
                                          TGPRC,
    tgprc
    tgsn
                                          TGSN,
    tgl1
                                         TGL,
                                          TGL
                                                                               OPTIONAL,
    tq12
    tgd
                                          TGD,
```

```
tgpl1
                                       TGPL,
    tgp12
                                       TGPL
                                                                           OPTIONAL,
                                       RPP,
   rpp
   itp
                                       ITP,
    -- TABULAR: Compressed mode method is nested inside UL-DL-Mode
                                      UL-DL-Mode,
   dl-FrameType
                                       DL-FrameType.
                                       DeltaSIR.
   deltaSIR1
   deltaSIRAfter1
                                       DeltaSIR,
   deltaSIR2
                                       DeltaSIR
                                                                           OPTIONAL,
   deltaSIRAfter2
                                      DeltaSIR
                                                                           OPTIONAL,
   nidentifyAbort
                                       NidentifvAbort
                                                                           OPTIONAL.
    treconfirmAbort
                                       TreconfirmAbort
                                                                           OPTIONAL
}
TGPSI ::=
                                   INTEGER (1..maxTGPS)
                                   INTEGER (0..14)
TGSN ::=
TimeInfo ::=
                                   SEQUENCE {
                                                                          OPTIONAL.
   activationTime
                                      ActivationTime
   durationTimeInfo
                                       DurationTimeInfo
                                                                          OPTIONAL
TimeslotList ::=
                                   SEOUENCE (SIZE (1..maxTS)) OF
                                       TimeslotNumber
TimeslotList-r4 ::=
                                   CHOICE {
                                      SEQUENCE (SIZE (1..maxTS)) OF
   tdd384
                                          TimeslotNumber,
   tdd128
                                       SEQUENCE (SIZE (1..maxTS-LCR)) OF
                                          TimeslotNumber-LCR-r4
}
-- If TimeslotNumber is included for a 1.28Mcps TDD description, it shall take values from 0..6
TimeslotNumber ::=
                                       INTEGER (0..14)
TimeslotNumber-LCR-r4 ::=
                                      INTEGER (0..6)
TimeslotNumber-PRACH-LCR-r4 ::= INTEGER (1..6)
TimeslotSync2 ::=
                              INTEGER (0..6)
-- Actual value TimingOffset = IE value * 256
TimingOffset ::=
                                  INTEGER (0..149)
TPC-CombinationIndex ::=
                                   INTEGER (0..5)
-- Actual value TPC-StepSizeFDD = IE value + 1
TPC-StepSizeFDD ::=
                                  INTEGER (0..1)
TPC-StepSizeTDD ::=
                                  INTEGER (1..3)
-- Actual value TreconfirmAbort = IE value * 0.5 seconds
TreconfirmAbort ::= INTEGER (1..20)
TX-DiversityMode ::=
                                   ENUMERATED {
                                      noDiversity,
                                       sttd.
                                       closedLoopMode1,
                                       closedLoopMode2 }
UARFCN ::=
                              INTEGER (0..16383)
UCSM-Info ::=
                                   SEQUENCE {
   minimumSpreadingFactor
                                      MinimumSpreadingFactor,
                                       NF-Max,
   channelReqParamsForUCSM
                                       ChannelReqParamsForUCSM
}
UL-CCTrCH ::=
                                   SEQUENCE {
   tfcs-ID
                                       TFCS-IdentityPlain
                                                                         DEFAULT 1,
   ul-TargetSIR
                                       UL-TargetSIR,
   timeInfo
                                      TimeInfo,
    commonTimeslotInfo
                                       CommonTimeslotInfo
                                                                          OPTIONAL,
   ul-CCTrCH-TimeslotsCodes
                                     UplinkTimeslotsCodes
                                                                           OPTIONAL
}
```

```
UL-CCTrCH-r4 ::=
                                   SEQUENCE {
                                       TFCS-IdentityPlain
                                                                           DEFAULT 1,
   tfcs-ID
    -- The IE ul-TargetSIR corresponds to PRX-DPCHdes for 1.28Mcps TDD
    -- Actual value PRX-DPCHdes = (value of IE "ul-TargetSIR" - 120)
   ul-TargetSIR
                                       UL-TargetSIR,
    timeInfo
                                       TimeInfo,
    commonTimeslotInfo
                                       CommonTimeslotInfo
                                                                           OPTIONAL,
                                       CHOICE {
    tddOption
       tdd384
                                           SEQUENCE {
         ul-CCTrCH-TimeslotsCodes
                                              UplinkTimeslotsCodes
                                                                          OPTIONAL
       tdd128
                                           SEQUENCE {
           ul-CCTrCH-TimeslotsCodes
                                               UplinkTimeslotsCodes-LCR-r4 OPTIONAL
    }
}
UL-CCTrCHList ::=
                                   SEQUENCE (SIZE (1..maxCCTrCH)) OF
                                       UL-CCTrCH
UL-CCTrCHList-r4 ::=
                                   SEQUENCE (SIZE (1..maxCCTrCH)) OF
                                       UL-CCTrCH-r4
                                   SEQUENCE (SIZE (1..maxCCTrCH)) OF
UL-CCTrCHListToRemove ::=
                                       TFCS-IdentityPlain
UL-CCTrChTPCList ::=
                                   SEQUENCE (SIZE (0..maxCCTrCH)) OF
                                           TFCS-Identity
UL-ChannelRequirement ::=
                                   CHOICE {
   ul-DPCH-Info
                                       UL-DPCH-Info,
    cpch-SetInfo
                                       CPCH-SetInfo
}
UL-ChannelRequirement-r4 ::=
                                   CHOICE {
   ul-DPCH-Info
                                     UL-DPCH-Info-r4,
   cpch-SetInfo
                                       CPCH-SetInfo
}
UL-ChannelRequirement-r5 ::=
                                   CHOICE {
   ul-DPCH-Info
                                       UL-DPCH-Info-r5,
    cpch-SetInfo
                                       CPCH-SetInfo
}
UL-ChannelRequirementWithCPCH-SetID ::= CHOICE {
   ul-DPCH-Info
                                       UL-DPCH-Info,
    cpch-SetInfo
                                       CPCH-SetInfo.
    cpch-SetID
                                       CPCH-SetID
UL-ChannelRequirementWithCPCH-SetID-r4 ::= CHOICE {
   ul-DPCH-Info
                                       UL-DPCH-Info-r4,
    cpch-SetInfo
                                       CPCH-SetInfo,
   cpch-SetID
                                       CPCH-SetID
}
UL-ChannelRequirementWithCPCH-SetID-r5 ::= CHOICE {
                                       UL-DPCH-Info-r5,
   ul-DPCH-Info
   cpch-SetInfo
                                       CPCH-SetInfo,
                                       CPCH-Set.ID
    cpch-SetID
                                   ENUMERATED {
UL-CompressedModeMethod ::=
                                       higherLayerScheduling }
UL-DL-Mode ::=
                                   CHOICE {
                                       UL-CompressedModeMethod,
   ul
    dl
                                       DL-CompressedModeMethod,
                                           SEQUENCE {
    ul-and-dl
                                           UL-CompressedModeMethod,
       ul
        dl
                                           DL-CompressedModeMethod
    }}
                                   ENUMERATED {
UL-DPCCH-SlotFormat ::=
                                       slf0, slf1, slf2 }
UL-DPCH-Info ::=
                                   SEQUENCE {
```

```
ul-DPCH-PowerControlInfo
                                        UL-DPCH-PowerControlInfo
                                                                             OPTIONAL,
    modeSpecificInfo
                                         CHOICE {
        fdd
                                             SEQUENCE {
            scramblingCodeType
                                                 ScramblingCodeType,
            scramblingCode
                                                 UL-ScramblingCode,
            numberOfDPDCH
                                                 NumberOfDPDCH
                                                                             DEFAULT 1,
            spreadingFactor
                                                 SpreadingFactor,
                                                 BOOLEAN,
            tfci-Existence
            -- numberOfFBI-Bits is conditional based on history
            numberOfFBI-Bits
                                                 NumberOfFBI-Bits
                                                                              OPTIONAL,
            puncturingLimit
                                                 PuncturingLimit
        },
                                             SEQUENCE {
        bb+
            ul-TimingAdvance
                                                 UL-TimingAdvanceControl
                                                                             OPTIONAL,
            ul-CCTrCHList
                                                 UL-CCTrCHList
                                                                              OPTIONAL,
            ul-CCTrCHListToRemove
                                                 UL-CCTrCHListToRemove
                                                                             OPTIONAL
        }
    }
}
UL-DPCH-Info-r4 ::=
                                    SEQUENCE {
    ul-DPCH-PowerControlInfo
                                         UL-DPCH-PowerControlInfo-r4
                                                                             OPTIONAL,
    {\tt modeSpecificInfo}
                                         CHOICE {
                                             SEQUENCE {
        fdd
                                                 ScramblingCodeType,
            scramblingCodeType
                                                 UL-ScramblingCode,
            scramblingCode
            numberOfDPDCH
                                                 {\tt NumberOfDPDCH}
                                                                             DEFAULT 1,
                                                 SpreadingFactor,
            spreadingFactor
            tfci-Existence
                                                 BOOLEAN,
            -- numberOfFBI-Bits is conditional based on history
            numberOfFBI-Bits
                                                 NumberOfFBI-Bits
                                                                             OPTIONAL.
            puncturingLimit
                                                 PuncturingLimit
        },
                                             SEQUENCE {
        tdd
            ul-TimingAdvance
                                                 UL-TimingAdvanceControl-r4 OPTIONAL,
            ul-CCTrCHList
                                                 UL-CCTrCHList-r4
                                                                             OPTIONAL.
            ul-CCTrCHListToRemove
                                                 UL-CCTrCHListToRemove
                                                                             OPTIONAL
        }
    }
}
UL-DPCH-Info-r5 ::=
                                     SEOUENCE {
    ul-DPCH-PowerControlInfo
                                         UL-DPCH-PowerControlInfo-r5
                                                                             OPTIONAL,
                                         CHOICE {
    modeSpecificInfo
                                             SEQUENCE {
        fdd
            scramblingCodeType
                                                 ScramblingCodeType,
            scramblingCode
                                                 UL-ScramblingCode,
            numberOfDPDCH
                                                 NumberOfDPDCH
                                                                             DEFAULT 1,
            spreadingFactor
                                                 SpreadingFactor,
            tfci-Existence
                                                 BOOLEAN,
            -- numberOfFBI-Bits is conditional based on history
            numberOfFBI-Bits
                                                 NumberOfFBI-Bits
                                                                             OPTIONAL,
            puncturingLimit
                                                 PuncturingLimit
        },
                                             SEQUENCE {
            ul-TimingAdvance
                                                 UL-TimingAdvanceControl-r4 OPTIONAL,
            ul-CCTrCHList
                                                 UL-CCTrCHList-r4
                                                                             OPTIONAL.
            ul-CCTrCHListToRemove
                                                 UL-CCTrCHListToRemove
                                                                             OPTIONAL
        }
    }
}
UL-DPCH-InfoPostFDD ::=
                                    SEQUENCE {
    ul-DPCH-PowerControlInfo
                                        UL-DPCH-PowerControlInfoPostFDD,
            scramblingCodeType
                                                 ScramblingCodeType,
            reducedScramblingCodeNumber
                                                 ReducedScramblingCodeNumber,
            spreadingFactor
                                                 SpreadingFactor
}
UL-DPCH-InfoPostTDD ::=
                                     SEQUENCE {
                                        UL-DPCH-PowerControlInfoPostTDD,
    ul-DPCH-PowerControlInfo
    ul-TimingAdvance
                                         UL-TimingAdvanceControl
                                                                                 OPTIONAL,
    ul-CCTrCH-TimeslotsCodes
                                        UplinkTimeslotsCodes
}
UL-DPCH-InfoPostTDD-LCR-r4 ::=
                                    SEQUENCE {
    ul-DPCH-PowerControlInfo
                                        III.-DPCH-PowerControlInfoPostTDD-LCR-r4.
```

```
ul-TimingAdvance
                                        UL-TimingAdvanceControl-LCR-r4
                                                                                    OPTIONAL,
    ul-CCTrCH-TimeslotsCodes
                                        UplinkTimeslotsCodes-LCR-r4
}
UL-DPCH-InfoPredef ::=
                                    SEQUENCE {
                                        UL-DPCH-PowerControlInfoPredef,
   ul-DPCH-PowerControlInfo
    modeSpecificInfo
                                        CHOICE {
                                            SEQUENCE {
        fdd
            tfci-Existence
                                                BOOLEAN,
           puncturingLimit
                                                PuncturingLimit
        },
        t dd
                                            SEQUENCE {
            commonTimeslotInfo
                                                CommonTimeslotInfo
        }
    }
}
UL-DPCH-PowerControlInfo ::=
                                    CHOICE {
                                        SEQUENCE {
       dpcch-PowerOffset
                                            DPCCH-PowerOffset,
        pc-Preamble
                                            PC-Preamble,
        sRB-delay
                                            SRB-delay,
        -- TABULAR: TPC step size nested inside PowerControlAlgorithm
        powerControlAlgorithm
                                           PowerControlAlgorithm
    tdd
                                        SEQUENCE {
        ul-TargetSIR
                                            UL-TargetSIR
                                                                        OPTIONAL,
        ul-OL-PC-Signalling
                                            CHOICE {
           broadcast-UL-OL-PC-info
                                               NULL.
            individuallySignalled
                                                SEQUENCE {
                                               IndividualTS-InterferenceList,
                individualTS-InterferenceList
                dpch-ConstantValue
                                                   ConstantValueTdd,
                primaryCCPCH-TX-Power
                                                   PrimaryCCPCH-TX-Power
            }
        }
                                                                        OPTIONAL
    }
}
UL-DPCH-PowerControlInfo-r4 ::=
                                    CHOICE {
                                        SEQUENCE {
        dpcch-PowerOffset
                                            DPCCH-PowerOffset,
        pc-Preamble
                                            PC-Preamble.
                                            SRB-delay,
        sRB-delay
        -- TABULAR: TPC step size nested inside PowerControlAlgorithm
       powerControlAlgorithm
                                           PowerControlAlgorithm
    },
    tdd.
                                       SEQUENCE {
        -- The IE ul-TargetSIR corresponds to PRX-DPCHdes for 1.28Mcps TDD
        -- Actual value PRX-DPCHdes = (value of IE "ul-TargetSIR" - 120)
        ul-TargetSIR
                                           UL-TargetSIR
                                                                        OPTIONAL.
        ul-OL-PC-Signalling
                                            CHOICE {
           broadcast-UL-OL-PC-info
                                                NULL,
            individuallySignalled
                                                SEQUENCE {
                                                    CHOICE {
                tddOption
                    tdd384
                                                        SEQUENCE {
                        individualTS-InterferenceList
                                                           IndividualTS-InterferenceList,
                        dpch-ConstantValue
                                                            ConstantValue
                    },
                    tdd128
                                                        SEQUENCE {
                        tpc-StepSize
                                                            TPC-StepSizeTDD
                primaryCCPCH-TX-Power
                                                   PrimaryCCPCH-TX-Power
           }
       }
    }
}
UL-DPCH-PowerControlInfo-r5 ::=
                                   CHOICE {
                                       SEQUENCE {
        dpcch-PowerOffset
                                            DPCCH-PowerOffset,
                                            PC-Preamble,
        pc-Preamble
                                            SRB-delay,
        sRB-delay
        -- TABULAR: TPC step size nested inside PowerControlAlgorithm
        powerControlAlgorithm
                                          PowerControlAlgorithm,
        deltaACK
                                            DeltaACK
                                                        OPTIONAL,
        deltaNACK
                                           DeltaNACK
                                                       OPTIONAL.
        ack-NACK-repetition-factor
                                            ACK-NACK-repetitionFactor OPTIONAL
```

```
},
                                      SEQUENCE {
    tdd
        -- The IE ul-TargetSIR corresponds to PRX-DPCHdes for 1.28Mcps TDD
        -- Actual value PRX-DPCHdes = (value of IE "ul-TargetSIR" - 120)
       ul-TargetSIR
                                        UL-TargetSIR
       ul-OL-PC-Signalling
                                           CHOICE {
           broadcast-UL-OL-PC-info
                                               NULL,
           individuallySignalled
                                               SEQUENCE {
                tddOption
                                                  CHOICE {
                   tdd384
                                                       SEQUENCE {
                       individualTS-InterferenceList
                                                        IndividualTS-InterferenceList,
                       dpch-ConstantValue
                                                           ConstantValue
                    },
                   tdd128
                                                       SECUENCE {
                       tpc-StepSize
                                                           TPC-StepSizeTDD
                primaryCCPCH-TX-Power
                                                  PrimaryCCPCH-TX-Power
           }
      }
   }
\verb"UL-DPCH-PowerControlInfoPostFDD" ::= SEQUENCE \ \{
   -- DPCCH-PowerOffset2 has a smaller range to save bits
   dpcch-PowerOffset
                                       DPCCH-PowerOffset2,
   pc-Preamble
                                       PC-Preamble,
   sRB-delay
                                       SRB-delay
}
UL-DPCH-PowerControlInfoPostTDD ::= SEQUENCE {
   ul-TargetSIR
                                       UL-TargetSIR,
    ul-TimeslotInterference
                                       TDD-UL-Interference
}
UL-DPCH-PowerControlInfoPostTDD-LCR-r4 ::= SEQUENCE {
   -- The IE ul-TargetSIR corresponds to PRX-DPCHdes for 1.28Mcps TDD
    -- Actual value PRX-DPCHdes = (value of IE "ul-TargetSIR" - 120)
   ul-TargetSIR
                                       UL-TargetSIR
UL-DPCH-PowerControlInfoPredef ::=
                                       CHOICE {
                                       SEQUENCE {
        -- TABULAR: TPC step size nested inside PowerControlAlgorithm
       powerControlAlgorithm
                                       PowerControlAlgorithm
                                       SEQUENCE {
        -- dpch-ConstantValue shall be ignored if in 1.28Mcps TDD mode.
       dpch-ConstantValue
                                           ConstantValueTdd
}
UL-Interference ::=
                                   INTEGER (-110..-70)
UL-ScramblingCode ::=
                                  INTEGER (0..16777215)
UL-SynchronisationParameters-r4 ::= SEQUENCE {
                                       INTEGER (1..8),
   stepSize
    frequency
                                       INTEGER (1..8)
-- Actual value UL-TargetSIR = (IE value * 0.5) - 11
                                   INTEGER (0..62)
UL-TargetSIR ::=
UL-TimingAdvance ::=
                                   INTEGER (0..63)
UL-TimingAdvanceControl ::=
                                   CHOICE {
   disabled
                                       NULL,
    enabled
                                       SEQUENCE {
       ul-TimingAdvance
                                           UL-TimingAdvance
                                                                          OPTIONAL,
       activationTime
                                           ActivationTime
                                                                          OPTIONAL
UL-TimingAdvanceControl-r4 ::=
                                   CHOICE {
   disabled
                                       NULL,
    enabled
                                       SEQUENCE {
```

```
tddOption
                                             CHOICE {
                                                 SEQUENCE {
            tdd384
                ul-TimingAdvance
                                                     UL-TimingAdvance
                                                                                      OPTIONAL,
                                                     ActivationTime
                activationTime
                                                                                      OPTIONAL
            },
            tdd128
                                                 SEQUENCE {
                ul-SynchronisationParameters
                                                     UL-SynchronisationParameters-r4 OPTIONAL,
                synchronisationParameters
                                                     SynchronisationParameters-r4
                                                                                     OPTIONAL
            }
        }
    }
}
UL-TimingAdvanceControl-LCR-r4 ::= CHOICE {
                                         NULL,
    disabled
    enabled
                                         SEQUENCE {
        ul-SynchronisationParameters
                                             UL-SynchronisationParameters-r4 OPTIONAL,
        synchronisationParameters
                                             SynchronisationParameters-r4 OPTIONAL
}
UL-TS-ChannelisationCode ::=
                                     ENUMERATED {
                                         cc1-1, cc2-1, cc2-2,
                                         cc4-1, cc4-2, cc4-3, cc4-4,
                                         cc8-1, cc8-2, cc8-3, cc8-4,
                                         cc8-5, cc8-6, cc8-7, cc8-8,
                                         cc16-1, cc16-2, cc16-3, cc16-4,
                                         cc16-5, cc16-6, cc16-7, cc16-8,
                                         cc16-9, cc16-10, cc16-11, cc16-12,
                                         cc16-13, cc16-14, cc16-15, cc16-16 }
UL-TS-ChannelisationCodeList ::=
                                     SEQUENCE (SIZE (1..2)) OF
                                         UL-TS-ChannelisationCode
UplinkAdditionalTimeslots ::=
                                     SEQUENCE {
    parameters
                                         CHOICE {
                                             SEQUENCE {
        sameAsLast
            timeslotNumber
                                                 TimeslotNumber
        newParameters
                                             SEQUENCE {
            individualTimeslotInfo
                                                         IndividualTimeslotInfo,
            ul-TS-ChannelisationCodeList
                                                         UL-TS-ChannelisationCodeList
    }
}
                                         SEQUENCE {
UplinkAdditionalTimeslots-LCR-r4 ::=
    parameters
                                         CHOICE {
                                             SEOUENCE {
        sameAsLast
            timeslotNumber
                                                 TimeslotNumber
        newParameters
                                             SEQUENCE {
            individualTimeslotInfo
                                                         IndividualTimeslotInfo-LCR-r4,
            ul-TS-ChannelisationCodeList
                                                         UL-TS-ChannelisationCodeList
    }
}
UplinkTimeslotsCodes ::=
                                     SEQUENCE {
    dynamicSFusage
                                         BOOLEAN,
    firstIndividualTimeslotInfo
                                         IndividualTimeslotInfo.
    ul-TS-ChannelisationCodeList
                                         UL-TS-ChannelisationCodeList,
    moreTimeslots
                                         CHOICE {
        noMore
                                             NULL,
        additionalTimeslots
                                             CHOICE {
                                                 SEQUENCE {
            consecutive
                numAdditionalTimeslots
                                                     INTEGER (1..maxTS-1)
            timeslotList
                                                 SEQUENCE (SIZE (1..maxTS-1)) OF
                                                     UplinkAdditionalTimeslots
}
UplinkTimeslotsCodes-LCR-r4 ::=
                                     SEQUENCE {
    dynamicSFusage
                                         BOOLEAN,
    firstIndividualTimeslotInfo
                                         IndividualTimeslotInfo-LCR-r4,
    ul-TS-ChannelisationCodeList
                                         UL-TS-ChannelisationCodeList,
```

```
CHOICE {
   moreTimeslots
                                         NULL,
       noMore
       additionalTimeslots
                                          CHOICE {
                                            SEQUENCE {
           consecutive
              numAdditionalTimeslots
                                                 INTEGER (1..maxTS-LCR-1)
           timeslotList
                                            SEQUENCE (SIZE (1..maxTS-LCR-1)) OF
                                                  UplinkAdditionalTimeslots-LCR-r4
      }
   }
}
Wi-LCR ::=
                                                                       INTEGER(1..4)
__ ****************
     MEASUREMENT INFORMATION ELEMENTS (10.3.7)
__ *****************************
AcquisitionSatInfo ::=
                                  SEQUENCE {
   satID
                                     SatID,
    -- Actual value dopplerOthOrder = IE value * 2.5
                                      INTEGER (-2048..2047),
   doppler0thOrder
   extraDopplerInfo
                                      ExtraDopplerInfo
                                                                        OPTIONAL,
   codePhase
                                      INTEGER (0..1022),
                                      INTEGER (0..19),
   integerCodePhase
   gps-BitNumber
                                     INTEGER (0..3),
   codePhaseSearchWindow
                                      CodePhaseSearchWindow,
   azimuthAndElevation
                                    AzimuthAndElevation
                                                                        OPTIONAL
}
AcquisitionSatInfoList ::= SEQUENCE (SIZE (1..maxSat)) OF
                                      AcquisitionSatInfo
                                  SEQUENCE (SIZE (1..maxAdditionalMeas)) OF
AdditionalMeasurementID-List ::=
                                     MeasurementIdentity
AlmanacSatInfo ::=
                                  SEQUENCE {
                                      INTEGER (0..3),
   dataID
   satID
                                      SatID,
                                      BIT STRING (SIZE (16)),
   t-oa
                                      BIT STRING (SIZE (8)),
                                      BIT STRING (SIZE (16)),
   deltaI
   omegaDot
                                      BIT STRING (SIZE (16)),
   satHealth
                                      BIT STRING (SIZE (8)),
                                      BIT STRING (SIZE (24)),
   a-Sqrt
                                      BIT STRING (SIZE (24)),
   omega0
                                      BIT STRING (SIZE (24)),
   m0
   omega
                                      BIT STRING (SIZE (24)),
   af0
                                      BIT STRING (SIZE (11)),
                                      BIT STRING (SIZE (11))
   af1
}
AlmanacSatInfoList ::=
                                  SEQUENCE (SIZE (1..maxSat)) OF
                                      AlmanacSatInfo
AverageRLC-BufferPayload ::=
                                  ENUMERATED {
                                      pla0, pla4, pla8, pla16, pla32,
                                      pla64, pla128, pla256, pla512,
                                      pla1024, pla2k, pla4k, pla8k, pla16k, pla32k, pla64k, pla128k, pla256k,
                                      pla512k, pla1024k, spare12, spare11,
                                       spare10, spare9, spare8, spare7, spare6,
                                      spare5, spare4, spare3, spare2, spare1 }
                                  SEQUENCE {
AzimuthAndElevation ::=
   -- Actual value azimuth = IE value * 11.25
                                      INTEGER (0..31),
   -- Actual value elevation = IE value * 11.25
                                      INTEGER (0..7)
BadSatList ::=
                                  SEQUENCE (SIZE (1..maxSat)) OF
                                      INTEGER (0..63)
Frequency-Band ::=
                                  ENUMERATED {
```

```
dcs1800BandUsed, pcs1900BandUsed }
BCCH-ARFCN ::=
                                   INTEGER (0..1023)
BLER-MeasurementResults ::=
                                   SEQUENCE {
   transportChannelIdentity
                                   TransportChannelIdentity,
   dl-TransportChannelBLER
                                      DL-TransportChannelBLER
                                                                         OPTIONAL
}
BLER-MeasurementResultsList ::=
                                   SEQUENCE (SIZE (1..maxTrCH)) OF
                                      BLER-MeasurementResults
BLER-TransChIdList ::=
                                   SEQUENCE (SIZE (1..maxTrCH)) OF
                                       TransportChannelIdentity
                                   ENUMERATED {
BSIC-VerificationRequired ::=
                                      required, notRequired }
BSICReported ::=
                                   CHOICE {
    -- Value maxCellMeas is not allowed for verifiedBSIC
                                       INTEGER (0..maxCellMeas),
   verifiedBSIC
   nonVerifiedBSIC
                                       BCCH-ARFCN
BurstModeParameters ::=
                                   SECUENCE {
   burstStart
                                      INTEGER (0..15),
   burstLength
                                       INTEGER (10..25),
                                       INTEGER (1..16)
   burstFreq
}
                                  CHOICE {
CellDCH-ReportCriteria ::=
                                   IntraFreqReportingCriteria,
   intraFreqReportingCriteria
   periodicalReportingCriteria
                                      PeriodicalReportingCriteria
}
CellDCH-ReportCriteria-LCR-r4 ::= CHOICE {
                                 IntraFreqReportingCriteria-LCR-r4,
   intraFreqReportingCriteria
   periodicalReportingCriteria
                                      PeriodicalReportingCriteria
 - Actual value CellIndividualOffset = IE value * 0.5
                                  INTEGER (-20..20)
CellIndividualOffset ::=
CellInfo ::=
                                   SEQUENCE {
   cellIndividualOffset
                                      CellIndividualOffset
                                                                         DEFAULT 0,
                                       ReferenceTimeDifferenceToCell
   referenceTimeDifferenceToCell
                                                                         OPTIONAL.
   modeSpecificInfo
                                      CHOICE {
                                          SEQUENCE {
           primaryCPICH-Info
                                              PrimaryCPICH-Info
                                                                         OPTIONAL,
                                              PrimaryCPICH-Info
PrimaryCPICH-TX-Power
           primaryCPICH-TX-Power
                                                                         OPTIONAL,
           readSFN-Indicator
                                              BOOLEAN,
           tx-DiversityIndicator
                                              BOOLEAN
                                         SEQUENCE {
           primaryCCPCH-Info
                                             PrimaryCCPCH-Info,
           primaryCCPCH-TX-Power
                                              PrimaryCCPCH-TX-Power
                                                                         OPTIONAL,
           timeslotInfoList
                                              TimeslotInfoList
                                                                        OPTIONAL,
           readSFN-Indicator
                                              BOOLEAN
       }
   }
}
                                   SEQUENCE {
CellInfo-r4 ::=
   cellIndividualOffset
                                       CellIndividualOffset
                                                                          DEFAULT 0.
                                       ReferenceTimeDifferenceToCell
   referenceTimeDifferenceToCell
                                                                          OPTIONAL,
   modeSpecificInfo
                                       CHOICE {
       fdd
                                         SEOUENCE {
                                              PrimaryCPICH-TX-Power OPTIONAL, BOOLEAN
                                              PrimaryCPICH-Info
           primaryCPICH-Info
           primaryCPICH-TX-Power
           readSFN-Indicator
                                              BOOLEAN,
                                              BOOLEAN
           tx-DiversityIndicator
       },
                                          SEQUENCE {
           primaryCCPCH-Info
                                              PrimaryCCPCH-Info-r4,
           primaryCCPCH-TX-Power
                                              PrimaryCCPCH-TX-Power
                                                                        OPTIONAL,
                                              TimeslotInfoList-r4
           timeslotInfoList
                                                                         OPTIONAL.
           readSFN-Indicator
                                              BOOLEAN
```

```
}
}
                                 SEQUENCE {
CellInfoSI-RSCP ::=
   cellIndividualOffset
                                     CellIndividualOffset
                                                                       DEFAULT 0.
                                     ReferenceTimeDifferenceToCell OPTIONAL,
   referenceTimeDifferenceToCell
                                     CHOICE {
   modeSpecificInfo
       fdd
                                         SEQUENCE {
                                            PrimaryCPICH-Info
          primaryCPICH-Info
                                                                      OPTIONAL.
           primaryCPICH-TX-Power
                                             PrimaryCPICH-TX-Power
                                                                       OPTIONAL,
           readSFN-Indicator
                                             BOOLEAN.
           tx-DiversityIndicator
                                             BOOLEAN
       },
                                         SEQUENCE {
       tdd
           primaryCCPCH-Info
                                           PrimaryCCPCH-Info,
           primaryCCPCH-TX-Power
                                             PrimaryCCPCH-TX-Power
                                                                       OPTIONAL,
           timeslotInfoList
                                             TimeslotInfoList
                                                                       OPTIONAL.
           readSFN-Indicator
                                             BOOLEAN
   cellSelectionReselectionInfo CellSelectReselectInfoSIB-11-12-RSCP
                                                                              OPTIONAL
}
CellInfoSI-RSCP-LCR-r4 ::=
                                SEQUENCE {
                                  CellIndividualOffset
   cellIndividualOffset
                                                                      DEFAULT 0,
   referenceTimeDifferenceToCell
                                     ReferenceTimeDifferenceToCell
                                                                    OPTIONAL,
                                     PrimaryCCPCH-Info-LCR-r4,
   primaryCCPCH-Info
                                     PrimaryCCPCH-TX-Power
   primaryCCPCH-TX-Power
                                                                       OPTIONAL.
                                                                       OPTIONAL,
   timeslotInfoList
                                     TimeslotInfoList-LCR-r4
   readSFN-Indicator
                                    BOOLEAN,
   cellSelectionReselectionInfo
                                     CellSelectReselectInfoSIB-11-12-RSCP
                                                                               OPTIONAL
}
   cellIndividualOffset
CellInfoSI-ECNO ::=
                                  CellIndividualOffset
                                                                      DEFAULT 0,
   referenceTimeDifferenceToCell
                                     ReferenceTimeDifferenceToCell
                                                                      OPTIONAL,
   {\tt modeSpecificInfo}
                                     CHOICE {
       fdd
                                       SEQUENCE {
           primaryCPICH-Info
                                             PrimaryCPICH-Info
                                                                       OPTIONAL,
                                             PrimaryCPICH-TX-Power
           primaryCPICH-TX-Power
                                                                       OPTIONAL.
           readSFN-Indicator
                                             BOOLEAN,
           tx-DiversityIndicator
                                             BOOLEAN
       },
       tdd
                                         SEQUENCE {
           primaryCCPCH-Info
                                            PrimaryCCPCH-Info,
           primaryCCPCH-TX-Power
                                             PrimaryCCPCH-TX-Power
                                                                       OPTIONAL.
           timeslotInfoList
                                             TimeslotInfoList
                                                                       OPTIONAL,
           readSFN-Indicator
                                             BOOLEAN
   cellSelectionReselectionInfo CellSelectReselectInfoSIB-11-12-ECNO
                                                                           OPTIONAL
CellInfoSI-ECNO-LCR-r4 ::= SEQUENCE {
   cellIndividualOffset
                                     CellIndividualOffset
                                                                       DEFAULT 0,
   referenceTimeDifferenceToCell
                                     ReferenceTimeDifferenceToCell
                                                                      OPTIONAL,
                                     PrimaryCCPCH-Info-LCR-r4,
   primaryCCPCH-Info
   primaryCCPCH-TX-Power
                                     PrimaryCCPCH-TX-Power
                                                                       OPTIONAL.
   timeslotInfoList
                                     TimeslotInfoList-LCR-r4
                                                                       OPTIONAL,
                                     BOOLEAN,
   readSFN-Indicator
   cellSelectionReselectionInfo
                                     CellSelectReselectInfoSIB-11-12-ECN0
                                                                           OPTIONAL
CellInfoSI-HCS-RSCP ::=
                                  SEQUENCE {
   cellIndividualOffset
                                     CellIndividualOffset
                                                                       DEFAULT 0,
   referenceTimeDifferenceToCell
                                     ReferenceTimeDifferenceToCell
                                                                       OPTIONAL,
   modeSpecificInfo
                                     CHOICE {
       fdd
                                         SEQUENCE {
           primaryCPICH-Info
                                             PrimaryCPICH-Info
                                                                       OPTIONAL.
           primaryCPICH-TX-Power
                                             PrimaryCPICH-TX-Power
                                                                       OPTIONAL,
           readSFN-Indicator
                                             BOOLEAN,
           tx-DiversityIndicator
                                            BOOLEAN
       },
       t dd
                                         SEQUENCE {
                                             PrimaryCCPCH-Info,
           primaryCCPCH-Info
           primaryCCPCH-TX-Power
                                             PrimaryCCPCH-TX-Power
                                                                       OPTIONAL,
```

```
timeslotInfoList
                                             TimeslotInfoList
                                                                       OPTIONAL,
           readSFN-Indicator
                                              BOOLEAN
    cellSelectionReselectionInfo
                                    CellSelectReselectInfoSIB-11-12-HCS-RSCP
                                                                                OPTIONAL
}
CellInfoSI-HCS-RSCP-LCR-r4 ::= SEQUENCE {
   cellIndividualOffset
                                   CellIndividualOffset
                                                                        DEFAULT 0,
   referenceTimeDifferenceToCell
                                      ReferenceTimeDifferenceToCell
                                                                        OPTIONAL,
                                     PrimaryCCPCH-Info-LCR-r4,
   primaryCCPCH-Info
   primaryCCPCH-TX-Power
                                     PrimaryCCPCH-TX-Power
                                                                        OPTIONAL.
   timeslotInfoList
                                     TimeslotInfoList-LCR-r4
                                                                        OPTIONAL,
   readSFN-Indicator
                                     BOOLEAN,
   cellSelectionReselectionInfo
                                     CellSelectReselectInfoSIB-11-12-HCS-RSCP
}
   cellIndividualOffset
CellInfoST-HCS-ECNO ::=
                                  SEQUENCE {
                                    CellIndividualOffset
   referenceTimeDifferenceToCell
                                      ReferenceTimeDifferenceToCell
                                                                        OPTIONAL,
   modeSpecificInfo
                                      CHOICE {
                                         SEQUENCE {
       fdd
           primaryCPICH-Info
                                             PrimaryCPICH-Info
                                                                        OPTIONAL,
                                             PrimaryCPICH-TX-Power
           primaryCPICH-TX-Power
                                             BOOLEAN,
           readSFN-Indicator
                                             BOOLEAN
           tx-DiversityIndicator
                                         SEQUENCE {
           primaryCCPCH-Info
                                             PrimaryCCPCH-Info,
           primaryCCPCH-TX-Power
                                                                        OPTIONAL.
                                             PrimaryCCPCH-TX-Power
           timeslotInfoList
                                             TimeslotInfoList
                                                                        OPTIONAL,
           readSFN-Indicator
   cellSelectionReselectionInfo
                                    CellSelectReselectInfoSIB-11-12-HCS-ECN0
                                                                               OPTIONAL
}
CellInfoSI-HCS-ECN0-LCR-r4 ::=
                                SEQUENCE {
   cellIndividualOffset
                                     CellIndividualOffset
                                                                        DEFAULT 0,
   referenceTimeDifferenceToCell
                                      ReferenceTimeDifferenceToCell
                                                                       OPTIONAL,
                                      PrimaryCCPCH-Info-LCR-r4,
   primaryCCPCH-Info
   primaryCCPCH-TX-Power
                                     PrimaryCCPCH-TX-Power
                                                                        OPTIONAL.
                                     TimeslotInfoList-LCR-r4
   timeslotInfoList
                                                                        OPTIONAL,
   readSFN-Indicator
                                     BOOLEAN,
   cellSelectionReselectionInfo
                                  CellSelectReselectInfoSIB-11-12-HCS-ECNO OPTIONAL
}
CellMeasuredResults ::=
                                  SEQUENCE {
   cellIdentity
                                     CellIdentity
                                                                        OPTIONAL,
   -- dummy is not used in this version of the specification, it should
    -- not be sent and if received it should be ignored.
                                                    OPTIONAL,
                 SFN-SFN-ObsTimeDifference
   dummy
   cellSynchronisationInfo CellSynchronisationInfo
                                                                OPTIONAL,
                                     CHOICE {
   modeSpecificInfo
                                         SEQUENCE {
       fdd
           primaryCPICH-Info
                                             PrimaryCPICH-Info,
           cpich-Ec-N0
                                              CPICH-Ec-N0
                                                                        OPTIONAL,
           cpich-RSCP
                                              CPICH-RSCP
                                                                        OPTIONAL,
           pathloss
                                             Pathloss
                                                                        OPTIONAL
       },
       tdd
                                          SEQUENCE {
           cellParametersID
                                             CellParametersID,
           proposedTGSN
                                                                        OPTIONAL,
           primaryCCPCH-RSCP
                                             PrimaryCCPCH-RSCP
                                                                        OPTIONAL,
           pathloss
                                             Pathloss
                                                                        OPTIONAL.
           timeslotISCP-List
                                             TimeslotISCP-List
                                                                        OPTIONAL
   }
}
CellMeasurementEventResults ::=
                                      SEQUENCE (SIZE (1..maxCellMeas)) OF
                                         PrimaryCPICH-Info,
   tdd
                                      SEQUENCE (SIZE (1..maxCellMeas)) OF
                                          PrimaryCCPCH-Info
CellMeasurementEventResults-LCR-r4 ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
```

PrimaryCCPCH-Info-LCR-r4

```
CellReportingQuantities ::=
                                   SEQUENCE {
    -- dummy is not used in this version of the specification, it should
    -- not be sent and if received it should be ignored.
                           SFN-SFN-OTD-Type,
    dummy
    cellIdentity-reportingIndicator
                                                         BOOLEAN,
    cellSynchronisationInfoReportingIndicator
                                                         BOOLEAN,
                                        CHOICE {
    modeSpecificInfo
        fdd
                                             SEQUENCE {
            cpich-Ec-NO-reportingIndicator
                                                                     BOOLEAN,
            cpich-RSCP-reportingIndicator
                                                                     BOOLEAN.
            pathloss-reportingIndicator
                                                                 BOOLEAN
                                            SEQUENCE {
            timeslotISCP-reportingIndicator
                                                                 BOOLEAN,
            proposedTGSN-ReportingRequired
                                                                 BOOLEAN,
            primaryCCPCH-RSCP-reportingIndicator
                                                                     BOOLEAN,
            pathloss-reportingIndicator
                                                                 BOOLEAN
        }
    }
}
CellSelectReselectInfoSIB-11-12 ::= SEQUENCE {
    q-Offset1S-N
                                         O-OffsetS-N
                                                                              DEFAULT 0.
    q-Offset2S-N
                                         O-OffsetS-N
                                                                              OPTIONAL,
    maxAllowedUL-TX-Power
                                         MaxAllowedUL-TX-Power
                                                                              OPTIONAL,
    hcs-NeighbouringCellInformation-RSCP
                                                HCS-NeighbouringCellInformation-RSCP
    OPTIONAL,
    {\tt modeSpecificInfo}
                                         CHOICE {
        fdd
                                             SEQUENCE {
            q-QualMin
                                                 Q-QualMin
                                                                              OPTIONAL,
            q-RxlevMin
                                                 Q-RxlevMin
                                                                              OPTIONAL
        },
        tdd
                                             SEOUENCE {
            q-RxlevMin
                                                 Q-RxlevMin
                                                                              OPTIONAL
        },
                                             SEQUENCE {
        gsm
            q-RxlevMin
                                                 Q-RxlevMin
                                                                              OPTIONAL
    }
}
CellSelectReselectInfoSIB-11-12-RSCP ::=
                                            SEQUENCE {
    q-OffsetS-N
                                    Q-OffsetS-N
                                                                     DEFAULT 0,
    maxAllowedUL-TX-Power
                                         MaxAllowedUL-TX-Power
                                                                              OPTIONAL,
    modeSpecificInfo
                                         CHOICE {
        fdd
                                             SEOUENCE {
            q-QualMin
                                                 Q-QualMin
                                                                              OPTIONAL,
            q-RxlevMin
                                                 Q-RxlevMin
                                                                              OPTIONAL
        },
                                             SEQUENCE {
        tdd
            q-RxlevMin
                                                 Q-RxlevMin
                                                                              OPTIONAL
        },
                                             SEQUENCE {
        gsm
            q-RxlevMin
                                                 Q-RxlevMin
                                                                             OPTIONAL
    }
CellSelectReselectInfoSIB-11-12-ECN0 ::=
                                            SEQUENCE {
    q-Offset1S-N
                                         Q-OffsetS-N
                                                                         DEFAULT 0,
    q-Offset2S-N
                                         Q-OffsetS-N
                                                                         DEFAULT 0,
    maxAllowedUL-TX-Power
                                         MaxAllowedUL-TX-Power
                                                                              OPTIONAL,
    modeSpecificInfo
                                         CHOICE {
        fdd
                                             SEQUENCE {
                                                 Q-QualMin
                                                                              OPTIONAL,
            q-QualMin
            q-RxlevMin
                                                 Q-RxlevMin
                                                                              OPTIONAL
        },
        tdd
                                             SEQUENCE {
            q-RxlevMin
                                                 Q-RxlevMin
                                                                              OPTIONAL
        },
                                             SEQUENCE {
        gsm
            q-RxlevMin
                                                 Q-RxlevMin
                                                                            OPTIONAL
    }
}
```

```
CellSelectReselectInfoSIB-11-12-HCS-RSCP ::= SEQUENCE {
                         Q-OffsetS-N
   q-OffsetS-N
                                                                 DEFAULT 0,
   maxAllowedUL-TX-Power
                                   MaxAllowedUL-TX-Power
                                                                       OPTIONAL,
   hcs-NeighbouringCellInformation-RSCP
                                            HCS-NeighbouringCellInformation-RSCP
   OPTIONAL,
   modeSpecificInfo
                                      CHOICE {
       fdd
                                         SEOUENCE {
           q-QualMin
                                              Q-QualMin
                                                                        OPTIONAL.
           q-RxlevMin
                                              Q-RxlevMin
                                                                         OPTIONAL
                                          SEQUENCE {
       tdd
                                             Q-RxlevMin
           q-RxlevMin
                                                                       OPTIONAL
       },
                                          SEQUENCE {
       gsm
          q-RxlevMin
                                             Q-RxlevMin
                                                                        OPTIONAL
   }
}
CellSelectReselectInfoSIB-11-12-HCS-ECN0 ::=
                                            SEQUENCE {
                  Q-OffsetS-N
   q-Offset1S-N
                                                                    DEFAULT 0.
                                                                   DEFAULT 0,
   q-Offset2S-N
                                      O-OffsetS-N
   maxAllowedUL-TX-Power
                                     MaxAllowedUL-TX-Power
                                                                         OPTIONAL,
   hcs-NeighbouringCellInformation-ECN0
                                            HCS-NeighbouringCellInformation-ECN0
   OPTIONAL,
                                      CHOICE {
   modeSpecificInfo
       fdd
                                          SEQUENCE {
                                              Q-QualMin
           q-QualMin
                                                                         OPTIONAL,
           q-RxlevMin
                                              Q-RxlevMin
                                                                        OPTIONAL
                                          SEQUENCE {
       tdd
                                            Q-RxlevMin
                                                                       OPTIONAL
          q-RxlevMin
       },
                                          SEQUENCE {
       gsm
                                                                       OPTIONAL
           q-RxlevMin
                                              Q-RxlevMin
   }
}
CellSelectReselectInfo-v590ext ::= SEQUENCE {
   deltaQrxlevmin
                                 DeltaQrxlevmin
                                                                 OPTIONAL,
                                  DeltaRSCP
                                                                 OPTIONAL
   deltaOhcs
}
CellsForInterFreqMeasList ::=
                                  SEQUENCE (SIZE (1..maxCellMeas)) OF
                                     InterFreqCellID
                                      SEQUENCE (SIZE (1..maxCellMeas)) OF
CellsForInterRATMeasList ::=
                                     InterRATCellID
CellsForIntraFreqMeasList ::=
                                  SEQUENCE (SIZE (1..maxCellMeas)) OF
                                     IntraFreqCellID
CellSynchronisationInfo ::=
                                  SEOUENCE {
                                  CHOICE {
   modeSpecificInfo
                                        SEQUENCE {
                                          CountC-SFN-Frame-difference OPTIONAL,
           countC-SFN-Frame-difference
                                             INTEGER(0..38399)
       },
       tdd
                                        SEQUENCE {
           countC-SFN-Frame-difference
                                         CountC-SFN-Frame-difference OPTIONAL
       }
   }
}
CellToReport ::=
                                  SEQUENCE {
   bsicReported
                                     BSICReported
CellToReportList ::=
                                  SEQUENCE (SIZE (1..maxCellMeas)) OF
                                      CellToReport
CodePhaseSearchWindow ::=
                                  ENUMERATED {
                                      w1023, w1, w2, w3, w4, w6, w8, w12, w16, w24, w32, w48, w64,
                                      w96, w128, w192 }
CountC-SFN-Frame-difference ::= SEQUENCE {
   -- Actual value countC-SFN-High = IE value * 256
   countC-SFN-High
                                 INTEGER(0..15),
```

```
off
                                      INTEGER(0..255)
}
-- SPARE: CPICH-Ec-No, Max = 49
-- Values above Max are spare
CPICH-Ec-N0 ::=
                                      INTEGER (0..63)
-- SPARE: CPICH- RSCP, Max = 91
-- Values above Max are spare
CPICH-RSCP ::=
                                      INTEGER (0..127)
DeltaPRC ::=
                                      INTEGER (-127..127)
--Actual value DeltaQrxlevmin = IE value * 2
DeltaQrxlevmin ::= INTEGER (-2..-1)
DeltaRSCP ::= INTEGER (-5..-1)
DeltaRSCPPerCell ::= SEQUENCE {
                                      DeltaRSCP OPTIONAL
    deltaRSCP
-- Actual value DeltaRRC = IE value * 0.032
                                      INTEGER (-7..7)
DeltaRRC ::=
DGPS-CorrectionSatInfo ::=
                                      SEQUENCE {
    satID
                                          SatID,
    iode
                                           IODE,
                                           UDRE.
    udre
    prc
                                           PRC,
                                          RRC,
    rrc
-- dummy1 and dummy2 are not used in this version of the specification and should be ignored.
                                      DeltaPRC.
    dummy2
                                      DeltaRRC,
    -- dummy3 and dummy4 are not used in this version of the specification. They should not
    -- be sent and if received they should be ignored.
                                      DeltaPRC
    dummv3
                                                            OPTIONAL,
    dummy4
                                      DeltaRRC
                                                           OPTIONAL
                                      SEQUENCE (SIZE (1..maxSat)) OF
DGPS-CorrectionSatInfoList ::=
                                          DGPS-CorrectionSatInfo
DiffCorrectionStatus ::=
                                      ENUMERATED {
                                          udre-1-0, udre-0-75, udre-0-5, udre-0-3,
                                           udre-0-2, udre-0-1, noData, invalidData }
DL-TransportChannelBLER ::=
                                      INTEGER (0..63)
                                      ENUMERATED {
DopplerUncertainty ::=
                                          hz12-5, hz25, hz50, hz100, hz200,
                                           spare3, spare2, spare1 }
EllipsoidPoint ::=
                                      SEQUENCE {
    legsoldPoint ::= SEQUENCE {
latitudeSign ENUMERATED { north, south },
latitude INTEGER (0..8388607),
longitude INTEGER (-8388608..8388607)
}
EllipsoidPointAltitude ::=
                                      SEQUENCE {
   INTEGER (0..8388607),
INTEGER (-8388608..8388607),
    latitude
longitude
    latitude
    INTEGER (0..32767)
    altitude
}
EllipsoidPointAltitudeEllipsoide ::=
                                          SEQUENCE {
    latitudeSign ENUMERATED { north, south }, latitude INTEGER (0..8388607),
   latitude INTEGER (U..838000,,, longitude INTEGER (-8388608.8388607), altitudeDirection altitude INTEGER (0..32767),
    uncertaintySemiMajor INTEGER (0..127), uncertaintySemiMinor INTEGER (0..127),
```

```
-- Actual value orientationMajorAxis = IE value * 2
    orientationMajorAxis INTEGER (0..89),
    uncertaintyAltitude
                            INTEGER (0..127),
                           INTEGER (0..100)
    confidence
}
EllipsoidPointUncertCircle ::=
                                   SEQUENCE {
    latitudeSign ENUMERATED { north, south }, latitude INTEGER (0..8388607), longitude INTEGER (-8388608 8388607)
    longitude
                            INTEGER (-8388608..8388607),
    uncertaintyCode
                           INTEGER (0..127)
}
EllipsoidPointUncertEllipse ::=
                                    SEQUENCE {
    latitude
                           INTEGER (0..8388607),
   longitude INTEGER (-8388608..8388607), uncertaintySemiMajor INTEGER (0..127), uncertaintySemiMinor INTEGER (0..127),
    -- Actual value orientationMajorAxis = IE value * 2
    orientationMajorAxis INTEGER (0..89),
                            INTEGER (0..100)
    confidence
}
EnvironmentCharacterisation ::=
                                    ENUMERATED {
                                         possibleHeavyMultipathNLOS,
                                         lightMultipathLOS,
                                         notDefined,
                                        spare }
                                    SEQUENCE {
Eventla ::=
    {\tt triggeringCondition}
                                       TriggeringCondition2,
    reportingRange
                                         ReportingRange,
   forbiddenAffectCellList
                                        ForbiddenAffectCellList
                                                                            OPTIONAL,
                                        W,
   reportDeactivationThreshold
                                        ReportDeactivationThreshold,
    reportingAmount
                                        ReportingAmount,
    reportingInterval
                                        ReportingInterval
}
Eventla-r4 ::=
                                    SEQUENCE {
   triggeringCondition
                                     TriggeringCondition2,
    reportingRange
                                        ReportingRange,
   forbiddenAffectCellList
                                        ForbiddenAffectCellList-r4
                                                                            OPTIONAL,
                                        W.
    reportDeactivationThreshold
                                        ReportDeactivationThreshold,
    reportingAmount
                                        ReportingAmount,
    reportingInterval
                                        ReportingInterval
}
Event1a-LCR-r4 ::=
                                    SEQUENCE {
   triggeringCondition
                                     TriggeringCondition2,
                                        ReportingRange,
    reportingRange
    forbiddenAffectCellList
                                        ForbiddenAffectCellList-LCR-r4
                                                                             OPTIONAL,
   reportDeactivationThreshold
                                        ReportDeactivationThreshold,
    reportingAmount
                                        ReportingAmount,
    reportingInterval
                                        ReportingInterval
}
Event1b ::=
                                    SEQUENCE {
   triggeringCondition
                                        TriggeringCondition1,
                                         ReportingRange,
    {\tt reportingRange}
    forbiddenAffectCellList
                                        ForbiddenAffectCellList
                                                                           OPTIONAL,
}
Event1b-r4 ::=
                                    SEQUENCE {
    triggeringCondition
                                        TriggeringCondition1,
    reportingRange
                                         ReportingRange,
                                                                           OPTIONAL,
    forbiddenAffectCellList
                                        ForbiddenAffectCellList-r4
}
Event1b-LCR-r4 ::=
                                    SEQUENCE {
```

```
triggeringCondition
                                      TriggeringCondition1,
    reportingRange
                                       ReportingRange,
   forbiddenAffectCellList
                                       ForbiddenAffectCellList-LCR-r4
                                                                             OPTIONAL,
                                   SEQUENCE {
Event1c ::=
                                      ReplacementActivationThreshold,
   replacementActivationThreshold
   reportingAmount
                                       ReportingAmount,
   reportingInterval
                                       ReportingInterval
}
Eventle ::=
                               SEQUENCE {
   triggeringCondition
                                       TriggeringCondition2,
   thresholdUsedFrequency
                                       ThresholdUsedFrequency
}
Event1f ::=
                               SEQUENCE {
   triggeringCondition
                                       TriggeringCondition1,
   thresholdUsedFrequency
                                       ThresholdUsedFrequency
}
                                   SEQUENCE {
Event2a ::=
   -- dummy is not used in this version of the specification and should be ignored
                                       Threshold,
   dummy
   usedFreqW
                                       W,
   hysteresis
                                       HysteresisInterFreq,
   timeToTrigger
                                       TimeToTrigger,
   reportingCellStatus
                                       ReportingCellStatus
                                                                         OPTIONAL.
   nonUsedFregParameterList
                                      NonUsedFregParameterList
                                                                          OPTIONAL
}
Event2b ::=
                                  SEQUENCE {
   {\tt usedFreqThreshold}
                                      Threshold,
   usedFreqW
                                      W,
   hysteresis
                                      HysteresisInterFreq,
                                      TimeToTrigger,
   timeToTrigger
   reportingCellStatus
                                      ReportingCellStatus
                                                                          OPTIONAL,
   nonUsedFreqParameterList
                                     NonUsedFreqParameterList
                                                                          OPTIONAL
}
Event2c ::=
                                   SEQUENCE {
   hysteresis
                                     HysteresisInterFreq,
    timeToTrigger
                                       TimeToTrigger,
   reportingCellStatus
                                      ReportingCellStatus
                                                                         OPTIONAL,
   nonUsedFreqParameterList
                                       NonUsedFreqParameterList
                                                                          OPTIONAL
}
Event2d ::=
                                   SEQUENCE {
  usedFreqThreshold
                                      Threshold,
   usedFreqW
                                       W,
   hysteresis
                                       HysteresisInterFreq,
    timeToTrigger
                                      TimeToTrigger,
   reportingCellStatus
                                       ReportingCellStatus
                                                                          OPTIONAL
}
Event2e ::=
                                   SEQUENCE {
                                     HysteresisInterFreq,
  hysteresis
    timeToTrigger
                                       TimeToTrigger,
   reportingCellStatus
                                      ReportingCellStatus
                                                                          OPTIONAL.
   nonUsedFreqParameterList
                                      NonUsedFreqParameterList
                                                                          OPTIONAL
}
                                   SEQUENCE {
Event2f ::=
   usedFreqThreshold
                                       Threshold,
                                       W,
    usedFreqW
                                       HysteresisInterFreq,
   hysteresis
   timeToTrigger
                                       TimeToTrigger,
   {\tt reportingCellStatus}
                                      ReportingCellStatus
                                                                         OPTIONAL
}
Event3a ::=
                                   SEQUENCE {
   thresholdOwnSystem
                                      Threshold,
                                       W,
    thresholdOtherSystem
                                       Threshold,
   hysteresis
                                      Hysteresis,
    timeToTrigger
                                       TimeToTrigger.
                                                                          OPTIONAL
    reportingCellStatus
                                       ReportingCellStatus
```

```
}
Event3b ::=
                                       SEQUENCE {
                                         Threshold,
    thresholdOtherSystem
    hysteresis
                                           Hysteresis,
    timeToTrigger
                                           TimeToTrigger,
   reportingCellStatus
                                           ReportingCellStatus
                                                                                 OPTIONAL
}
                                       SEQUENCE {
Event3c ::=
                                          Threshold,
    thresholdOtherSystem
   hvsteresis
                                           Hysteresis,
    timeToTrigger
                                           TimeToTrigger,
   reportingCellStatus
                                           ReportingCellStatus
                                                                                  OPTIONAL
}
Event3d ::=
                                       SEQUENCE {
   hysteresis
                                          Hysteresis,
    timeToTrigger
                                           TimeToTrigger,
    reportingCellStatus
                                                                                  OPTIONAL
                                           ReportingCellStatus
                                       ENUMERATED {
EventIDInterFreq ::=
                                           e2a, e2b, e2c, e2d, e2e, e2f, spare2, spare1 }
EventIDInterRAT ::=
                                       ENUMERATED {
                                          e3a, e3b, e3c, e3d }
                                       ENUMERATED {
EventIDIntraFreq ::=
                                           ela, elb, elc, eld, ele,
                                            elf, elg, elh, eli, spare7,
                                            spare6, spare5, spare4, spare3, spare2,
                                           spare1 }
EventResults ::=
                                      CHOICE {
   intraFreqEventResults
interFreqEventResults
interFRATEventResults
                                      IntraFreqEventResults,
                                          InterFreqEventResults,
InterRATEventResults,
   interRATEventResults InterRATEventResults,
trafficVolumeEventResults TrafficVolumeEventResults,
qualityEventResults QualityEventResults,
ue-InternalEventResults UE-InternalEventResults,
    ue-positioning-MeasurementEventResults
                                                       UE-Positioning-MeasurementEventResults,
    spare
                                           NULL
}
ExtraDopplerInfo ::=
                                     SEQUENCE {
    -- Actual value doppler1stOrder = IE value * 0.023
    doppler1stOrder
                                           INTEGER (-42..21),
    dopplerUncertainty
                                           DopplerUncertainty
}
FACH-MeasurementOccasionInfo ::= SEQUENCE {
    fACH-meas-occasion-coeff INTEGER (1..12) inter-freq-FDD-meas-ind BOOLEAN,
    -- inter-freq-TDD-meas-ind is for 3.84 \text{Mcps} TDD. For 1.28 \text{Mcps} TDD, the IE in
    -- FACH-MeasurementOccasionInfo-LCR-r4-ext is used.
    inter-freq-TDD-meas-ind
                                          BOOLEAN,
    inter-RAT-meas-ind
                                           SEQUENCE (SIZE (1..maxOtherRAT)) OF
                                                RAT-Type
                                                                                   OPTIONAL
}
FACH-MeasurementOccasionInfo-LCR-r4-ext ::= SEQUENCE {
    inter-freq-TDD128-meas-ind
FilterCoefficient ::=
                                       ENUMERATED {
                                           fc0, fc1, fc2, fc3, fc4, fc5,
                                           fc6, fc7, fc8, fc9, fc11, fc13,
                                           fc15, fc17, fc19, spare1 }
 - Actual value FineSFN-SFN = IE value * 0.0625
FineSFN-SFN ::=
                                      INTEGER (0..15)
ForbiddenAffectCell ::=
                                      CHOICE {
                                           PrimaryCPICH-Info,
   fdd
    t.dd
                                           PrimaryCCPCH-Info
```

```
ForbiddenAffectCell-r4 ::=
                                    CHOICE {
   fdd
                                        PrimaryCPICH-Info,
    tdd
                                        PrimaryCCPCH-Info-r4
ForbiddenAffectCell-LCR-r4 ::=
                                    SEQUENCE {
                                        PrimaryCCPCH-Info-LCR-r4
ForbiddenAffectCellList ::=
                                   SEQUENCE (SIZE (1..maxCellMeas)) OF
                                        ForbiddenAffectCell
ForbiddenAffectCellList-r4 ::=
                                        SEQUENCE (SIZE (1..maxCellMeas)) OF
                                        ForbiddenAffectCell-r4
ForbiddenAffectCellList-LCR-r4 ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                        ForbiddenAffectCell-LCR-r4
FreqQualityEstimateQuantity-FDD ::= ENUMERATED {
                                        cpich-Ec-N0,
                                        cpich-RSCP }
\label{eq:continuous_prop_state} \texttt{FreqQualityEstimateQuantity-TDD} \; ::= \; \texttt{ENUMERATED} \; \; \{
                                        primaryCCPCH-RSCP }
GPS-MeasurementParam ::=
                                   SEQUENCE {
                                     INTEGÈR (0..63),
   satelliteID
                                        INTEGER (0..63),
    C-N0
   doppler
                                       INTEGER (-32768..32768),
    wholeGPS-Chips
                                        INTEGER (0..1022),
                                       INTEGER (0..1023),
   fractionalGPS-Chips
   multipathIndicator
                                      MultipathIndicator,
    pseudorangeRMS-Error
                                        INTEGER (0..63)
GPS-MeasurementParamList ::= SEQUENCE (SIZE (1..maxSat)) OF
                                        GPS-MeasurementParam
GSM-CarrierRSSI ::=
                                   BIT STRING (SIZE (6))
GSM-MeasuredResults ::=
                                    SEQUENCE {
                                       GSM-CarrierRSSI
   gsm-CarrierRSSI
    -- dummy is not used in this version of the specification, it should
    \mbox{--} not be sent and if received it should be ignored.
                                        INTEGER (46..173)
                                                                            OPTIONAL.
   dummy
    bsicReported
                                        BSICReported,
    observedTimeDifferenceToGSM
                                       ObservedTimeDifferenceToGSM
                                                                           OPTIONAL
}
GSM-MeasuredResultsList ::= SEQUENCE (SIZE (1..maxReportedGSMCells)) OF
                                       GSM-MeasuredResults
GPS-TOW-1msec ::=
                                   INTEGER (0..604799999)
GPS-TOW-Assist ::=
                                    SEQUENCE {
   satID
                                       SatID,
    tlm-Message
                                        BIT STRING (SIZE (14)),
                                        BIT STRING (SIZE (2)),
   tlm-Reserved
    alert
                                        BOOLEAN,
                                        BOOLEAN
   antiSpoof
}
                                   SEQUENCE (SIZE (1..maxSat)) OF
GPS-TOW-AssistList ::=
                                        GPS-TOW-Assist
HCS-CellReselectInformation-RSCP ::=
                                            SEOUENCE {
    -- TABULAR: The default value for penaltyTime is "notUsed"
    -- Temporary offset is nested inside PenaltyTime-RSCP
   penaltyTime
                                                PenaltyTime-RSCP
}
HCS-CellReselectInformation-ECN0 ::=
                                          SEQUENCE {
    -- TABULAR: The default value for penaltyTime is "notUsed"
    -- Temporary offset is nested inside PenaltyTime-ECNO
   penaltyTime
                                        PenaltyTime-ECN0
```

```
HCS-NeighbouringCellInformation-RSCP ::= SEQUENCE {
   hcs-PRIO
                                      HCS-PRIO
                                                                           DEFAULT 0,
    q-HCS
                                                                           DEFAULT 0,
                                       O-HCS
   hcs-CellReselectInformation
                                       HCS-CellReselectInformation-RSCP
}
\verb|HCS-NeighbouringCellInformation-ECN0| ::= SEQUENCE \{|
   hcs-PRIO
                                       HCS-PRIO
                                                                           DEFAULT 0,
                                       O-HCS
                                                                           DEFAULT 0,
    hcs-CellReselectInformation
                                       HCS-CellReselectInformation-ECN0
}
HCS-PRIO ::=
                                   INTEGER (0..7)
HCS-ServingCellInformation ::=
                                   SEOUENCE {
                                                                           DEFAULT 0.
   hcs-PRIO
                                       HCS-PRIO
    q-HCS
                                       O-HCS
                                                                           DEFAULT 0.
    t.-CR-Max
                                       T-CRMax
                                                                           OPTIONAL
}
-- Actual value Hysteresis = IE value * 0.5
                                   INTEGER (0..15)
Hysteresis ::=
-- Actual value HysteresisInterFreq = IE value * 0.5
HysteresisInterFreq ::=
                                   INTEGER (0..29)
InterFreqCell ::=
                                   SEQUENCE {
   frequencyInfo
                                       FrequencyInfo,
   nonFreqRelatedEventResults
                                       CellMeasurementEventResults
InterFreqCell-LCR-r4 ::=
                         SEQUENCE {
                                       FrequencyInfo.
   frequencyInfo
    {\tt nonFreqRelatedEventResults}
                                       CellMeasurementEventResults-LCR-r4
InterFreqCellID ::=
                                   INTEGER (0..maxCellMeas-1)
   erFreqCellInfoList ::=
removedInterFreqCellList
newInterFreqCellList
cellsForInterFreqMeasList
InterFreqCellInfoList ::=
                                   SEQUENCE {
                                   RemovedInterFreqCellList
                                                                          OPTIONAL.
                                       NewInterFreqCellList
                                                                          OPTIONAL.
                                      CellsForInterFreqMeasList
                                                                          OPTIONAL
InterFreqCellInfoList-r4 ::=
    removedInterFreqCelList
                                 SEQUENCE {
                                   RemovedInterFreqCellList
                                                                          OPTIONAL.
    newInterFreqCellList
                                      NewInterFreqCellList-r4
                                                                           OPTIONAL,
    cellsForInterFreqMeasList
                                      CellsForInterFreqMeasList
                                                                           OPTIONAL
}
InterFreqCellInfoSI-List-RSCP ::=
                                      SEQUENCE {
   removedInterFreqCellList
                                       RemovedInterFreqCellList
   newInterFreqCellList
                                       NewInterFreqCellSI-List-RSCP
                                                                          OPTIONAL
}
InterFreqCellInfoSI-List-ECN0 ::=
                                       SEQUENCE {
   removedInterFreqCellList
                                       RemovedInterFreqCellList
                                                                          OPTIONAL.
   newInterFreqCellList
                                       NewInterFreqCellSI-List-ECN0
                                                                          OPTIONAL
}
InterFreqCellInfoSI-List-HCS-RSCP ::=
                                           SEQUENCE {
                                       RemovedInterFreqCellList
   removedInterFreqCellList
                                                                          OPTIONAL,
                                       NewInterFreqCellSI-List-HCS-RSCP OPTIONAL
   newInterFreqCellList
InterFreqCellInfoSI-List-HCS-ECN0 ::=
                                           SEQUENCE {
   removedInterFreqCellList
                                       RemovedInterFreqCellList
                                                                           OPTIONAL,
                                       NewInterFreqCellSI-List-HCS-ECNO OPTIONAL
   newInterFreqCellList
}
InterFreqCellInfoSI-List-RSCP-LCR ::=
                                           SEQUENCE {
   removedInterFreqCellList
                                       RemovedInterFreqCellList
                                                                          OPTIONAL.
                                       NewInterFreqCellSI-List-RSCP-LCR-r4 OPTIONAL
   newInterFreqCellList
InterFreqCellInfoSI-List-ECNO-LCR ::=
                                          SEQUENCE {
   removedInterFreqCellList
                                       RemovedInterFreqCellList
                                                                          OPTIONAL.
    newInterFreqCellList
                                       NewInterFreqCellSI-List-ECN0-LCR-r4 OPTIONAL
```

```
}
InterFreqCellInfoSI-List-HCS-RSCP-LCR ::= SEQUENCE {
  removedInterFreqCellList RemovedInterFreqCellList OPTIONAL, newInterFreqCellList NewInterFreqCellSI-List-HCS-RSCP-LCR-r4 OPTIONAL
InterFreqCellInfoSI-List-HCS-ECNO-LCR ::=
                                                  SEOUENCE {
   removedInterFreqCellList RemovedInterFreqCellList OPTIONAL,
newInterFreqCellList NewInterFreqCellSI-List-HCS-ECNO-LCR-r4 OPTIONAL
                          SEQUENCE (SIZE (1..maxFreq)) OF
InterFreqCellList ::=
                                         InterFreqCell
InterFreqCellList-LCR-r4-ext ::= SEQUENCE (SIZE (1..maxFreq)) OF
                                         InterFreqCell-LCR-r4
InterFreqCellMeasuredResultsList ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                         CellMeasuredResults
                                     CHOICE {
InterFreqEvent ::=
   event2a
                                        Event2a,
    event2b
                                         Event 2b,
   event2c
                                         Event2c,
    event 2d
                                         Event 2d.
    event 2e
                                         Event 2e,
    event2f
                                         Event2f
}
                                    SEQUENCE (SIZE (1..maxMeasEvent)) OF
InterFreqEventList ::=
                                         InterFreqEvent
--Following IE shall be used regardless of CPICH RSCP(FDD) or Primary CCPCH RSCP(TDD)
--The order of the list corresponds to the order of the cells in Inter-FrequencyMeasuredResultsList
InterFrequencyMeasuredResultsList-v590ext ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                                  DeltaRSCPPerCell
Inter-FreqEventCriteria-v590ext ::= SEQUENCE {
    threholdUsedFrequency-delta
                                             DeltaRSCP,
    threholdUsedFrequency-delta DeltaRSCP, threholdNonUsedFrequency-deltaList ThreholdNonUsedFrequency-deltaList
                                                                                      OPTIONAL
}
--The order of the list corresponds to the order of the events in Inter-FreqEventList
Inter-FreqEventCriteriaList-v590ext ::= SEQUENCE (SIZE (1..maxMeasEvent)) OF
                                             Inter-FreqEventCriteria-v590ext
--The order of the list corresponds to the order of relevant events in Intra-FreqEventCriteriaList
--i.e. the first element of the list corresponds to the first occurance of event le, 1f, 1h, 1i,
--the second element of the list corresponds to the second occurance of event 1e, 1f, 1h, 1i
Intra-FreqEventCriteriaList-v590ext ::= SEQUENCE (SIZE (1..maxMeasEvent)) OF
                                              DeltaRSCP
--Following IE shall be used regardless of CPICH RSCP(FDD) or Primary CCPCH RSCP(TDD)
--The order of the list corresponds to the order of the cells in Intra-FrequencyMeasuredResultsList
IntraFrequencyMeasuredResultsList-v590ext ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                                  DeltaRSCPPerCell
IntraFreqReportingCriteria-1b-r5 ::= SEQUENCE {
   periodicReportingInfo-1b
                                         PeriodicReportingInfo-1b
}
PeriodicReportingInfo-1b ::= SEQUENCE {
   reportingAmount
                                         ReportingAmount,
                                         ReportingInterval
   reportingInterval
}
InterFreqEventResults ::=
                                   SEQUENCE {
                                        EventIDInterFreq,
   eventID
    interFreqCellList
                                         InterFreqCellList
                                                                              OPTIONAL
InterFreqEventResults-LCR-r4-ext ::=
                                         SEQUENCE {
   event.ID
                                         EventIDInterFreq,
    interFreqCellList
                                         InterFreqCellList-LCR-r4-ext OPTIONAL
}
\label{eq:continuous_sequence} \mbox{InterFreqMeasQuantity} ::= \qquad \qquad \mbox{SEQUENCE} \ \{
    reportingCriteria
                                         CHOICE {
```

```
SEQUENCE {
       intraFreqReportingCriteria
           intraFreqMeasQuantity
                                           IntraFreqMeasQuantity
       interFreqReportingCriteria
                                      SEQUENCE {
          filterCoefficient
                                           FilterCoefficient
                                                                    DEFAULT fc0,
           modeSpecificInfo
                                           CHOICE {
                                              SEQUENCE {
              fdd
                  freqQualityEstimateQuantity-FDD
FreqQualityEstimateQuantity-FDD
              tdd
                                               SEQUENCE {
                  freqQualityEstimateQuantity-TDD
                                                  FreqQualityEstimateQuantity-TDD
          }
      }
   }
}
InterFreqMeasuredResults ::=
                                SEQUENCE {
   frequencyInfo
                                    FrequencyInfo
                                                                     OPTIONAL.
   utra-CarrierRSSI
                                    UTRA-CarrierRSSI
                                                                     OPTIONAL,
   interFreqCellMeasuredResultsList
                                    InterFreqCellMeasuredResultsList
                                                                     OPTIONAL
}
InterFreqMeasuredResultsList ::= SEQUENCE (SIZE (1..maxFreq)) OF
                                    InterFreqMeasuredResults
InterFreqMeasurementSysInfo-RSCP ::= SEQUENCE {
   interFreqCellInfoSI-List
                                       InterFreqCellInfoSI-List-RSCP
                                                                       OPTIONAL
}
InterFreqMeasurementSysInfo-ECN0 ::=
                                      SEQUENCE {
   interFreqCellInfoSI-List
                                   InterFreqCellInfoSI-List-ECN0 OPTIONAL
InterFreqMeasurementSysInfo-HCS-RSCP ::=
                                      SEOUENCE {
   interFreqCellInfoSI-List
                                   InterFreqCellInfoSI-List-HCS-RSCP OPTIONAL
InterFreqMeasurementSysInfo-HCS-ECN0 ::= SEQUENCE {
   interFreqCellInfoSI-List
                                   InterFreqCellInfoSI-List-HCS-ECN0 OPTIONAL
InterFreqMeasurementSysInfo-RSCP-LCR-r4 ::= SEQUENCE {
   interFreqCellInfoSI-List
                                       InterFreqCellInfoSI-List-RSCP-LCR
                                                                           OPTIONAL
}
InterFreqMeasurementSysInfo-ECN0-LCR-r4 ::= SEQUENCE {
   interFreqCellInfoSI-List
                                    InterFreqCellInfoSI-List-ECN0-LCR
                                                                       OPTIONAL
}
InterFreqMeasurementSysInfo-HCS-RSCP-LCR-r4 ::=
                                              SEOUENCE {
   interFreqCellInfoSI-List InterFreqCellInfoSI-List-HCS-RSCP-LCR OPTIONAL
InterFreqMeasurementSysInfo-HCS-ECN0-LCR-r4 ::= SEQUENCE {
   interFreqCellInfoSI-List InterFreqCellInfoSI-List-HCS-ECNO-LCR OPTIONAL
   InterFreqReportCriteria ::=
                                  IntraFreqReportingCriteria,
                                    InterFreqReportingCriteria,
   periodicalReportingCriteria
                                   PeriodicalWithReportingCellStatus,
                                    ReportingCellStatusOpt
   noReporting
}
InterFreqReportCriteria-r4 ::=
                                CHOICE {
   intraFreqReportingCriteria
                                 IntraFreqReportingCriteria-r4,
   interFreqReportingCriteria
                                    InterFreqReportingCriteria,
   periodicalReportingCriteria
                                    PeriodicalWithReportingCellStatus,
                                   ReportingCellStatusOpt
   noReporting
}
InterFreqReportingCriteria ::=
                                SEQUENCE {
   interFreqEventList
                                    InterFreqEventList
                                                                    OPTIONAL
}
InterFreqReportingQuantity ::=
                                SEOUENCE {
```

```
utra-Carrier-RSSI
                                       BOOLEAN,
   frequencyQualityEstimate
nonFreqRelatedQuantities
                                      BOOLEAN,
CellReportingQuantities
}
InterFrequencyMeasurement ::= SEQUENCE {
                                    InterFreqCellInfoList,
    interFreqCellInfoList
                                                                             OPTIONAL.
    interFreqMeasQuantity
                                         InterFreqMeasOuantity
                                                                            OPTIONAL,
    interFreqReportingQuantity
                                        InterFreqReportingQuantity
    measurementValidity
                                        MeasurementValidity
                                                                             OPTIONAL,
    interFreqSetUpdate
                                        UE-AutonomousUpdateMode
                                                                             OPTIONAL,
                                        InterFreqReportCriteria
    reportCriteria
}
{\tt InterFrequencyMeasurement-r4 ::= SEQUENCE } \{
                             InterFreqCellInfoList-r4,
   interFreqCellInfoList
    interFreqMeasQuantity
interFreqReportingQuantity
InterFreqReportingQu
MeasurementValidity

MeasurementValidity
                                       InterFreqMeasQuantity
InterFreqReportingQuantity
                                                                             OPTIONAL,
                                                                             OPTIONAL,
   measurementValidity
                                                                             OPTIONAL,
    interFreqSetUpdate
                                         UE-AutonomousUpdateMode
                                                                             OPTIONAL,
                                        InterFreqReportCriteria-r4
    reportCriteria
}
InterRAT-TargetCellDescription ::= SEQUENCE {
    technologySpecificInfo
                                        CHOICE {
        gsm
                                            SEQUENCE {
            bsic
                                                BSIC,
            frequency-band
                                                 Frequency-Band,
                                                 BCCH-ARFCN,
            bcch-ARFCN
                                                 NC-Mode
                                                                     OPTIONAL
           ncMode
        is-2000
                                             NULL,
        spare2
                                             NULL,
        spare1
                                             NULL
}
InterRATCellID ::=
                               INTEGER (0..maxCellMeas-1)
   removedInterRATCellList RemovedT
InterRATCellInfoList ::=
                                    RemovedInterRATCellList,
    -- NOTE: Future revisions of dedicated messages including IE newInterRATCellList
    -- should use a corrected version of this {\tt IE}
    cellsForInterRATMeasList CellsForInterRATM
                                   CellsForInterRATMeasList
                                                                            OPTIONAL
}
InterRATCellInfoList-B ::= SEQUENCE {
   removedInterRATCellList RemovedInterRATCellList,
    -- NOTE: IE newInterRATCellList should be optional. However, system information
    \mbox{--} does not support message versions. Hence, this can not be corrected
   newInterRATCellList
                                    NewInterRATCellList-B
}
InterRATCellInfoList-r4 ::= SEQUENCE {
    removedInterRATCellList Rem
                                            RemovedInterRATCellList,
    newInterRATCellList
                                             NewInterRATCellList
                                                                                 OPTIONAL.
    cellsForInterRATMeasList
                                            CellsForInterRATMeasList
                                                                                 OPTIONAL
}
InterRATCellIndividualOffset ::=
                                            INTEGER (-50..50)
InterRATEvent ::=
                                CHOICE {
                                         Event3a.
    event.3a
    event.3b
                                         Event.3b.
    event3c
                                         Event3c,
                                         Event3d
    event3d
}
InterRATEventList ::= SEQUENCE (SIZE (1..maxMeasEvent)) OF
                                        InterRATEvent
InterRATEventResults ::=
                                    SEOUENCE {
    eventID
                                        EventIDInterRAT,
                                         CellToReportList
    cellToReportList
}
                                    ENUMERATED {
InterRATInfo ::=
```

```
gsm }
                                       SEQUENCE {
InterRATMeasQuantity ::=
    measQuantityUTRAN-QualityEstimate
                                          IntraFreqMeasQuantity
                                                                         OPTIONAL,
    ratSpecificInfo
                                        CHOICE {
                                               SEQUENCE {
       gsm
                                                   MeasurementQuantityGSM,
           measurementQuantity
           filterCoefficient
           bsic-VerificationRequired
                                                   BSIC-VerificationRequired
                                               SEQUENCE {
        is-2000
                                                   INTEGER (0..63),
           tadd-EcIo
                                                   INTEGER (0..15),
           tcomp-EcIo
           softSlope
                                                   INTEGER (0..63)
                                                                          OPTIONAL,
           addIntercept
                                                   INTEGER (0..63)
                                                                           OPTIONAL
        }
    }
}
InterRATMeasuredResults ::=
                              CHOICE {
    qsm
                                       GSM-MeasuredResultsList,
    spare
                                       NULL
InterRATMeasuredResultsList ::= SEQUENCE (SIZE (1..maxOtherRAT-16)) OF
                                       InterRATMeasuredResults
                              SEQUENCE {
InterRATMeasurement ::=
                             InterRATCellInfoList
    interRATCellInfoList
                                                                           OPTIONAL,
                                      InterRATMeasQuantity
    interRATMeasQuantity
                                                                           OPTIONAL.
    interRATReportingQuantity
reportCriteria
                                       InterRATReportingQuantity OPTIONAL,
                                      InterRATReportCriteria
    reportCriteria
}
InterRATMeasurement-r4 ::=
                                 SEQUENCE {
    interRATCellInfoList
                                  InterRATCellInfoList-r4
InterRATMeasQuantity
                                                                           OPTIONAL,
    interRATMeasQuantity
                                                                           OPTIONAL,
                                      InterRATReportingQuantity
InterRATReportCriteria
    interRATReportingQuantity
                                                                     OPTIONAL,
    reportCriteria
}
InterRATMeasurementSysInfo ::= SEQUENCE {
                                       InterRATCellInfoList
    interRATCellInfoList
                                                                          OPTIONAL
InterRATMeasurementSysInfo-B ::= SEQUENCE {
                                      InterRATCellInfoList-B
                                                                     OPTIONAL
    interRATCellInfoList
InterRATReportCriteria ::= CHOICE {
   interRATReportingCriteria
                                InterRATReportingeries.,
PeriodicalWithReportingCellStatus,
                                       InterRATReportingCriteria,
    periodicalReportingCriteria
    noReporting
                                     ReportingCellStatusOpt
InterRATReportingCriteria ::= SEQUENCE {
    interRATEventList
                              InterRATEventList
                                                                  OPTIONAL
InterRATReportingQuantity ::= SEQUENCE {
   utran-EstimatedQuality ratSpecificInfo
                                      BOOLEAN,
                                   CHOICE {
                                           SEQUENCE {
       gsm
                                               BOOLEAN,
           dummy
                                               BOOLEAN.
           {\tt observedTimeDifferenceGSM}
           gsm-Carrier-RSSI
                                               BOOLEAN
    }
}
IntraFreqCellID ::=
                                  INTEGER (0..maxCellMeas-1)
IntraFreqCellInfoList ::=
                                   SEQUENCE {
    removedIntraFreqCellList
                                                                          OPTIONAL,
                                   RemovedIntraFreqCellList
    newIntraFreqCellList
                                       NewIntraFreqCellList
                                                                           OPTIONAL,
    cellsForIntraFreqMeasList
                                     CellsForIntraFreqMeasList
}
```

```
IntraFreqCellInfoList-r4 ::= SEQUENCE {
   removedIntraFreqCellList RemovedIntraFreqCellList
   newIntraFreqCellList NewIntraFreqCellList-r4
   cellsForIntraFreqMeasList CellsForIntraFreqMeasList
                                                                                   OPTIONAL,
                                                                                   OPTIONAL,
                                                                                   OPTIONAL
}
IntraFreqCellInfoSI-List-RSCP ::= SEQUENCE {
    removedIntraFreqCellList RemovedIntraFreqCellList newIntraFreqCellList NewIntraFreqCellSI-List-R
                                                                                   OPTIONAL,
    newIntraFreqCellList
                                           NewIntraFreqCellSI-List-RSCP
IntraFreqCellInfoSI-List-ECN0 ::= SEQUENCE {
  removedIntraFreqCellList RemovedIntraFreqCellList
  newIntraFreqCellList NewIntraFreqCellSI-List-ECN0
                                                                                   OPTIONAL,
}
IntraFreqCellInfoSI-List-HCS-RSCP ::= SEQUENCE {
    removedIntraFreqCellList RemovedIntraFreqCellList NewIntraFreqCellSI-List-HCS-RSCP
                                                                                   OPTIONAL,
OPTIONAL,
}
IntraFreqCellInfoSI-List-RSCP-LCR-r4 ::= SEQUENCE {
   removedIntraFreqCellList RemovedIntraFreqCellList NewIntraFreqCellSI-List-RSCP-LCR-r4
                                                                                    OPTIONAL,
}
IntraFreqCellInfoSI-List-ECN0-LCR-r4 ::=
                                                     SEQUENCE {
   removedIntraFreqCellList RemovedIntraFreqCellList
                                                                                    OPTIONAL,
                                           NewIntraFreqCellSI-List-ECN0-LCR-r4
    newIntraFreqCellList
}
IntraFreqCellInfoSI-List-HCS-RSCP-LCR-r4 ::=
                                                        SEQUENCE {
   removedIntraFreqCellList RemovedIntraFreqCellList
                                                                                   OPTIONAL.
    newIntraFreqCellList
                                            NewIntraFreqCellSI-List-HCS-RSCP-LCR-r4
}
IntraFreqCellInfoSI-List-HCS-ECNO-LCR-r4 ::=
                                                        SEQUENCE {
   removedIntraFreqCellList RemovedIntraFreqCellList
                                                                                   OPTIONAL.
    newIntraFreqCellList
                                           NewIntraFreqCellSI-List-HCS-ECN0-LCR-r4
}
IntraFreqEvent ::=
                                        CHOICE {
                                           Eventla,
    e1b
                                            Event1b,
                                            Event1c.
    elc
    e1d
                                            NULL,
    e1e
                                            Eventle,
    e1f
                                            Event1f,
                                            NULL.
    e1a
                                            ThresholdUsedFrequency,
    e1h
    eli
                                            ThresholdUsedFrequency
}
                                       CHOICE {
IntraFreqEvent-r4 ::=
    e1a
                                            Eventla-r4,
                                            Event1b-r4,
    e1c
                                            Event1c,
                                            NULL.
    e1d
    e1e
                                            Eventle,
    e1f
                                            Event1f,
    e1g
    e1h
                                            ThresholdUsedFrequency,
    eli
                                            ThresholdUsedFrequency
IntraFreqEvent-LCR-r4 ::=
                                        CHOICE {
                                            Eventla-LCR-r4,
    e1a
    e1b
                                            Event1b-LCR-r4,
    e1c
                                            Event1c,
    e1d
                                            NULL,
                                            Eventle.
    e1e
    e1f
                                            Event.1f.
                                            NULL,
    e1a
```

```
e1h
                                        ThresholdUsedFrequency,
   eli
                                        ThresholdUsedFrequency
}
IntraFreqEvent-1d-r5 ::=
                               SEQUENCE {
   triggeringCondition
                                        TriggeringCondition2 OPTIONAL,
                                        BOOLEAN
                                                                OPTIONAL
   useCIO
}
IntraFreqEventCriteria ::=
                                   SEQUENCE {
                                      IntraFregEvent,
   event
   hvsteresis
                                       Hysteresis,
    timeToTrigger
                                       TimeToTrigger,
    reportingCellStatus
                                       ReportingCellStatus
                                                                           OPTIONAL
                                  SEQUENCE {
IntraFreqEventCriteria-r4 ::=
                                       IntraFreqEvent-r4,
    event
   hysteresis
                                       Hysteresis,
    timeToTrigger
                                        TimeToTrigger,
   reportingCellStatus
                                                                           OPTIONAL
                                       ReportingCellStatus
IntraFreqEventCriteria-LCR-r4 ::= SEQUENCE {
    event
                                       IntraFregEvent-LCR-r4,
   hysteresis
                                        Hysteresis,
    timeToTrigger
                                       TimeToTrigger,
   reportingCellStatus
                                       ReportingCellStatus
                                                                          OPTIONAL
}
IntraFreqEventCriteriaList ::=
                                  SEQUENCE (SIZE (1..maxMeasEvent)) OF
                                       IntraFreqEventCriteria
IntraFreqEventCriteriaList-r4 ::= SEQUENCE (SIZE (1..maxMeasEvent)) OF
                                       IntraFreqEventCriteria-r4
IntraFreqEventCriteriaList-LCR-r4 ::= SEQUENCE (SIZE (1..maxMeasEvent)) OF
                                       IntraFreqEventCriteria-LCR-r4
IntraFreqEventResults ::=
                                    SEQUENCE {
                                       EventIDIntraFreq,
    eventID
    cellMeasurementEventResults
                                       CellMeasurementEventResults
}
IntraFreqMeasQuantity ::=
                                    SEQUENCE {
                                                                          DEFAULT fc0,
    filterCoefficient
                                        FilterCoefficient
    {\tt modeSpecificInfo}
                                        CHOICE {
                                        SEQUENCE {
        fdd
            intraFreqMeasQuantity-FDD
                                           IntraFreqMeasQuantity-FDD
        },
       tdd
                                       SEQUENCE {
            intraFreqMeasQuantity-TDDList
                                           IntraFreqMeasQuantity-TDDList
    }
}
-- If IntraFreqMeasQuantity-FDD is used in InterRATMeasQuantity, then only
-- cpich-Ec-NO and cpich-RSCP are allowed.
-- dummy is not used in this version of the specification, it should
-- not be sent and if received it should be ignored.
IntraFreqMeasQuantity-FDD ::=
                                    ENUMERATED {
                                       cpich-Ec-N0,
                                        cpich-RSCP,
                                        pathloss,
                                        dummy }
-- dummy is not used in this version of the specification, it should
-- not be sent and if received it should be ignored.
IntraFreqMeasQuantity-TDD ::=
                                   ENUMERATED {
                                       primaryCCPCH-RSCP,
                                        pathloss,
                                        timeslotISCP.
                                        dummy }
IntraFreqMeasQuantity-TDDList ::=
                                   SEQUENCE (SIZE (1..4)) OF
                                        IntraFreqMeasOuantity-TDD
IntraFreqMeasuredResultsList ::=
                                    SEQUENCE (SIZE (1..maxCellMeas)) OF
```

CellMeasuredResults

```
IntraFreqMeasurementSysInfo-RSCP ::=
                                         SEQUENCE {
    intraFreqMeasurementID
                                         MeasurementIdentity
                                                                      DEFAULT 1,
                                         IntraFreqCellInfoSI-List-RSCP
    intraFreqCellInfoSI-List
                                                                               OPTIONAL,
                                         IntraFreqMeasQuantity
    intraFreqMeasQuantity
                                                                               OPTIONAL,
    intraFreqReportingQuantityForRACH
                                         IntraFreqReportingQuantityForRACH OPTIONAL,
    maxReportedCellsOnRACH
                                         MaxReportedCellsOnRACH
                                                                               OPTIONAL.
    {\tt reportingInfoForCellDCH}
                                         ReportingInfoForCellDCH
                                                                               OPTIONAL
                                              SEQUENCE {
IntraFreqMeasurementSysInfo-ECN0 ::=
                                                                 DEFAULT 1,
    intraFreqMeasurementID
                                         MeasurementIdentity
    intraFreqCellInfoSI-List
                                         IntraFreqCellInfoSI-List-ECNO OPTIONAL,
    intraFreqMeasQuantity
                                         IntraFreqMeasQuantity
                                                                               OPTIONAL,
    intra Freq Reporting Quantity For RACH \qquad Intra Freq Reporting Quantity For RACH \qquad OPTIONAL\,,
    maxReportedCellsOnRACH
                                         MaxReportedCellsOnRACH
                                                                              OPTIONAL.
    reportingInfoForCellDCH
                                         ReportingInfoForCellDCH
                                                                               OPTIONAL.
}
IntraFreqMeasurementSysInfo-HCS-RSCP ::=
                                             SEQUENCE {
                             MeasurementIdentity
    intraFreqMeasurementID
                                                                      DEFAULT 1,
    intraFreqCellInfoSI-List
                                         IntraFreqCellInfoSI-List-HCS-RSCP OPTIONAL,
    intraFreqMeasQuantity
                                         IntraFreqMeasQuantity
                                                                               OPTIONAL.
    intraFreqReportingQuantityForRACH IntraFreqReportingQuantityForRACH OPTIONAL,
    maxReportedCellsOnRACH
                                         MaxReportedCellsOnRACH
                                                                               OPTIONAL,
    reportingInfoForCellDCH
                                         ReportingInfoForCellDCH
                                                                              OPTIONAL
}
IntraFreqMeasurementSysInfo-HCS-ECN0 ::=
                                             SEQUENCE {
                             MeasurementIdentity DEFAULT 1,
IntraFreqCellInfoSI-List-HCS-ECNO OPTIONAL,
    intraFreqMeasurementID
    intraFreqCellInfoSI-List
    intraFreqMeasQuantity
                                         IntraFreqMeasQuantity
                                                                               OPTIONAL,
    intraFreqReportingQuantityForRACH IntraFreqReportingQuantityForRACH OPTIONAL,
                                                                               OPTIONAL,
    maxReportedCellsOnRACH
                                         MaxReportedCellsOnRACH
    reportingInfoForCellDCH
                                         ReportingInfoForCellDCH
                                                                               OPTIONAL
{\tt IntraFreqMeasurementSysInfo-RSCP-LCR-r4} \ ::= \ {\tt SEQUENCE} \ \big\{
    intraFreqMeasurementID MeasurementIdentity
intraFreqCellInfoSI-List IntraFreqCellInfoSI-
intraFreqMeasQuantity IntraFreqMeasQuantity
                                                                     DEFAULT 1,
                                         IntraFreqCellInfoSI-List-RSCP-LCR-r4
    intraFreqMeasQuantity
                                         IntraFreqMeasQuantity
                                                                               OPTIONAL.
    intra Freq Reporting Quantity For RACH \\ Intra Freq Reporting Quantity For RACH \\
                                                                               OPTIONAL,
    maxReportedCellsOnRACH
                                         {\tt MaxReportedCellsOnRACH}
                                                                               OPTIONAL,
    {\tt reportingInfoForCellDCH}
                                         ReportingInfoForCellDCH-LCR-r4
                                                                               OPTIONAL
}
IntraFreqMeasurementSysInfo-ECN0-LCR-r4 ::=
                                                 SEQUENCE {
    intraFreqCellInfoSI-List
                                         MeasurementIdentity
                                                                      DEFAULT 1,
                                         IntraFreqCellInfoSI-List-ECN0-LCR-r4
                                                                                   OPTIONAL,
                                                                               OPTIONAL,
    intraFreqMeasOuantity
                                         IntraFreqMeasQuantity
    \verb|intraFreqReportingQuantityForRACH| IntraFreqReportingQuantityForRACH| OPTIONAL, \\
    maxReportedCellsOnRACH
                                         MaxReportedCellsOnRACH
                                                                               OPTIONAL,
    reportingInfoForCellDCH
                                         ReportingInfoForCellDCH-LCR-r4
                                                                              OPTIONAL
}
IntraFreqMeasurementSysInfo-HCS-RSCP-LCR-r4 ::= SEQUENCE {
    intraFreqMeasurementID MeasurementIdentity
                                                                      DEFAULT 1.
    intraFreqCellInfoSI-List
                                         IntraFreqCellInfoSI-List-HCS-RSCP-LCR-r4
                                                                                       OPTIONAL,
                                        IntraFreqMeasQuantity
    intraFreqMeasOuantity
                                                                              OPTIONAL.
    intra Freq Reporting Quantity For RACH \qquad Intra Freq Reporting Quantity For RACH \qquad OPTIONAL\,,
    maxReportedCellsOnRACH
                                         MaxReportedCellsOnRACH
                                                                               OPTIONAL,
    reportingInfoForCellDCH
                                         ReportingInfoForCellDCH-LCR-r4
                                                                              OPTIONAL
}
IntraFreqMeasurementSysInfo-HCS-ECN0-LCR-r4 ::= SEQUENCE {
                             MeasurementIdentity
    intraFreqMeasurementID
                                                                      DEFAULT 1,
    intraFreqCellInfoSI-List
                                         IntraFreqCellInfoSI-List-HCS-ECN0-LCR-r4
                                                                                       OPTIONAL,
                                         IntraFreqMeasQuantity
                                                                               OPTIONAL,
    intraFreqMeasQuantity
    intraFreqMeasQuantity IntraFreqMeasQuantity
intraFreqReportingQuantityForRACH IntraFreqReportingQuantityForRACH
                                                                               OPTIONAL,
    maxReportedCellsOnRACH
                                         MaxReportedCellsOnRACH
                                                                               OPTIONAL,
    reportingInfoForCellDCH
                                         ReportingInfoForCellDCH-LCR-r4
                                                                               OPTIONAL
}
IntraFreqReportCriteria ::=
                                     CHOICE {
    intraFreqReportingCriteria
                                        IntraFreqReportingCriteria,
    periodicalReportingCriteria
                                         PeriodicalWithReportingCellStatus,
                                         ReportingCellStatusOpt
    noReporting
```

```
}
IntraFreqReportCriteria-r4 ::= CHOICE {
                                    IntraFreqReportingCriteria-r4,
    intraFreqReportingCriteria
    periodicalReportingCriteria
                                        PeriodicalWithReportingCellStatus,
                                       ReportingCellStatusOpt
    noReporting
}
IntraFreqReportingCriteria ::= SEQUENCE {
    eventCriteriaList
                                      IntraFreqEventCriteriaList
                                                                       OPTIONAL
IntraFreqReportingCriteria-r4 ::= SEQUENCE {
    eventCriteriaList
                                       IntraFreqEventCriteriaList-r4 OPTIONAL
}
IntraFreqReportingCriteria-LCR-r4 ::= SEQUENCE {
    eventCriteriaList
                                       IntraFreqEventCriteriaList-LCR-r4 OPTIONAL
}
   IntraFreqReportingQuantity ::=
                                   CellReportingQuantities,
   monitoredSetReportingQuantities CellReportingQuantities, detectedSetReportingQuantities CellReportingQuantities
                                       CellReportingQuantities,
                                                                          OPTIONAL
}
IntraFreqReportingQuantityForRACH ::= SEQUENCE {
                                        SFN-SFN-OTD-Type,
    sfn-SFN-OTD-Type
   modeSpecificInfo
                                        CHOICE {
                                           SEQUENCE {
        fdd
            intraFreqRepQuantityRACH-FDD
                                            IntraFreqRepQuantityRACH-FDD
        },
                                           SEQUENCE {
       tdd
            intra Freq Rep Quantity RACH-TDD List \\ Intra Freq Rep Quantity RACH-TDD List \\
    }
}
IntraFreqRepQuantityRACH-FDD ::=
                                    ENUMERATED {
                                       cpich-EcNO, cpich-RSCP,
                                       pathloss, noReport }
IntraFreqRepQuantityRACH-TDD ::=
                                    ENUMERATED {
                                       timeslotISCP,
                                        primaryCCPCH-RSCP,
                                       noReport }
IntraFreqRepQuantityRACH-TDDList ::= SEQUENCE (SIZE (1..2)) OF
                                       IntraFreqRepQuantityRACH-TDD
                                  SEQUENCE {
IntraFrequencyMeasurement ::=
                                   IntraFreqCellInfoList
IntraFreqMeasQuantity
    intraFreqCellInfoList
                                                                           OPTIONAL,
    intraFreqMeasQuantity
                                                                          OPTIONAL,
                                       IntraFreqReportingQuantity
    intraFreqReportingQuantity
                                                                           OPTIONAL.
   measurementValidity
                                       MeasurementValidity
                                                                           OPTIONAL,
   reportCriteria
                                       IntraFreqReportCriteria
                                                                           OPTIONAL
                                 SEQUENCE {
IntraFrequencyMeasurement-r4 ::=
                                       IntraFreqCellInfoList-r4
                                                                        OPTIONAL,
    intraFreqCellInfoList
    intraFreqMeasQuantity
                                       IntraFreqMeasQuantity
                                                                           OPTIONAL,
    intraFreqReportingQuantity
                                       IntraFreqReportingQuantity
                                                                           OPTIONAL,
   measurementValidity
                                       MeasurementValidity
                                                                           OPTIONAL,
                                       IntraFreqReportCriteria-r4
    reportCriteria
                                                                          OPTIONAL
}
IODE ::=
                                    INTEGER (0..255)
IP-Length ::=
                                    ENUMERATED {
                                       ip15, ip110 }
IP-PCCPCH-r4 ::=
                                    BOOLEAN
IP-Spacing ::=
                                    ENUMERATED {
                                       e5, e7, e10, e15, e20, e30, e40, e50 }
IP-Spacing-TDD ::=
                                        ENUMERATED {
```

```
e30, e40, e50, e70, e100}
IS-2000SpecificMeasInfo ::=
                                     ENUMERATED {
                                         frequency, timeslot, colourcode,
                                         outputpower, pn-Offset }
                                     ENUMERATED {
MaxNumberOfReportingCellsType1 ::=
                                         e1, e2, e3, e4, e5, e6}
MaxNumberOfReportingCellsType2 ::= ENUMERATED {
                                         e1, e2, e3, e4, e5, e6, e7, e8, e9, e10, e11, e12}
MaxNumberOfReportingCellsType3 ::= ENUMERATED {
                                         viactCellsPlus1,
                                         viactCellsPlus2,
                                         viactCellsPlus3,
                                         viactCellsPlus4,
                                         viactCellsPlus5.
                                         viactCellsPlus6 }
                                     ENUMERATED {
MaxReportedCellsOnRACH ::=
                                         noReport,
                                         currentCell,
                                         currentAnd-1-BestNeighbour,
                                         current And-2-Best Neighbour.
                                         currentAnd-3-BestNeighbour,
                                         currentAnd-4-BestNeighbour,
                                         currentAnd-5-BestNeighbour,
                                         currentAnd-6-BestNeighbour }
MeasuredResults ::=
                                     CHOICE {
    \verb"intraFreqMeasuredResultsList"
                                         IntraFreqMeasuredResultsList,
    interFreqMeasuredResultsList
                                         InterFreqMeasuredResultsList,
    interRATMeasuredResultsList
                                     InterRATMeasuredResultsList,
    trafficVolumeMeasuredResultsList TrafficVolumeMeasuredResultsList,
                                         QualityMeasuredResults,
    qualityMeasuredResults
    ue-InternalMeasuredResults
                                         UE-InternalMeasuredResults,
                                         UE-Positioning-MeasuredResults,
    ue-positioning-MeasuredResults
    spare
                                         NULL
}
MeasuredResults-v390ext ::=
                                             SEQUENCE {
    ue-positioning-MeasuredResults-v390ext
                                                              UE-Positioning-MeasuredResults-v390ext
MeasuredResults-v590ext ::= CHOICE {
    \verb|intraFrequencyMeasuredResultsList|
                                             IntraFrequencyMeasuredResultsList-v590ext,
    interFrequencyMeasuredResultsList
                                             InterFrequencyMeasuredResultsList-v590ext
}
MeasuredResults-LCR-r4 ::=
                                     CHOICE {
    intraFreqMeasuredResultsList
                                        IntraFreqMeasuredResultsList,
    interFreqMeasuredResultsList
interRATMeasuredResultsList
                                         InterFreqMeasuredResultsList,
                                     InterRATMeasuredResultsList,
    trafficVolumeMeasuredResultsList
                                         TrafficVolumeMeasuredResultsList,
    qualityMeasuredResults
                                         QualityMeasuredResults,
    ue-InternalMeasuredResults
                                         UE-InternalMeasuredResults-LCR-r4,
    ue-positioniing-MeasuredResults
                                         UE-Positioning-MeasuredResults,
                                         NIII.I.
    spare
MeasuredResultsList ::=
                                     SEQUENCE (SIZE (1..maxAdditionalMeas)) OF
                                         MeasuredResults
MeasuredResultsList-LCR-r4-ext ::= SEQUENCE (SIZE (1..maxAdditionalMeas)) OF
                                         MeasuredResults-LCR-r4
                                     SEQUENCE {
MeasuredResultsOnRACH ::=
    currentCell
                                         SEQUENCE {
        {\tt modeSpecificInfo}
                                             CHOICE {
            fdd
                                                 SEQUENCE {
                measurementQuantity
                                                      CHOICE {
                    cpich-Ec-N0
                                                          CPICH-Ec-N0,
                     cpich-RSCP
                                                          CPICH-RSCP,
                    pathloss
                                                          Pathloss,
                                                          NULL
                    spare
```

```
},
                                              SEQUENCE {
                                                  TimeslotISCP-List
PrimaryCCPCH-RSCP
               timeslotISCP
                                                                       OPTIONAL,
               primaryCCPCH-RSCP
                                                                         OPTIONAL
   }.
   monitoredCells
                                    MonitoredCellRACH-List
                                                                        OPTIONAL
}
MeasurementCommand ::=
                                  CHOICE {
                                      MeasurementType,
   setup
   modify
                                      SEOUENCE {
      measurementType
                                         MeasurementType
                                                                        OPTIONAL
                                      NULL
   release
}
MeasurementCommand-r4 ::= CHOICE {
                                      MeasurementType-r4,
   setup
                                      SEQUENCE {
   modify
      measurementType
                                                                  OPTIONAL
                                         MeasurementType-r4
   release
}
MeasurementControlSysInfo ::= SEQUENCE {
    -- CHOICE cellSelectQualityMeasure represents PCCPCH-RSCP in TDD mode.
                                      CHOICE {
   use-of-HCS
                                      SEQUENCE
       hcs-not-used
         cellSelectQualityMeasure CHOICE {
    cpich-RSCP SEQUENCE
              cpich-RSCP
                  intraFreqMeasurementSysInfo
                                                     IntraFreqMeasurementSysInfo-RSCP
   OPTIONAL.
                  interFreqMeasurementSysInfo
                                                    InterFreqMeasurementSysInfo-RSCP
                                                                                         OPTIONAL
                                      SEQUENCE {
               cpich-Ec-N0
                  intraFreqMeasurementSysInfo
                                                      IntraFreqMeasurementSysInfo-ECN0
   OPTIONAL,
                   \verb|interFreqMeasurementSysInfo|\\
                                                                                       OPTIONAL
                                                    InterFreqMeasurementSysInfo-ECN0
           },
           interRATMeasurementSysInfo InterRATMeasurementSysInfo-B
                                                                           OPTIONAL
       hcs-used
                                      SEQUENCE
                                      CHOICE {
           cellSelectQualityMeasure
              cpich-RSCP
                                      SECUENCE
                  intraFreqMeasurementSysInfo
                                                     IntraFreqMeasurementSysInfo-HCS-RSCP
   OPTIONAL,
                  interFreqMeasurementSysInfo
                                                    InterFreqMeasurementSysInfo-HCS-RSCP
   OPTIONAL
               cpich-Ec-NO SEQUENCE {
                  intraFreqMeasurementSysInfo
                                                     IntraFreqMeasurementSysInfo-HCS-ECN0
   OPTIONAL,
                   interFreqMeasurementSysInfo
                                                    InterFreqMeasurementSysInfo-HCS-ECN0
   OPTIONAL
                          }
           interRATMeasurementSysInfo InterRATMeasurementSysInfo OPTIONAL
       }
                                                                         OPTIONAL,
   trafficVolumeMeasSysInfo
                                     TrafficVolumeMeasSysInfo
    -- dummy is not used in this version of specification and it shall be ignored by the UE.
              UE-InternalMeasurementSysInfo
                                                 OPTIONAL
}
MeasurementControlSysInfo-LCR-r4-ext ::= SEQUENCE {
   \operatorname{\mathsf{--}} CHOICE use-of-HCS shall have the same value as the use-of-HCS
   -- in MeasurementControlSysInfo
   -- CHOICE cellSelectQualityMeasure represents PCCPCH-RSCP in TDD mode.
                                      CHOICE {
   use-of-HCS
                                      SEQUENCE
       hcs-not-used
           -- CHOICE cellSelectQualityMeasure shall have the same value as the
           -- cellSelectQualityMeasure in MeasurementControlSysInfo
           cellSelectQualityMeasure CHOICE {
               cpich-RSCP
                                      SEOUENCE
                   \verb|intraFreqMeasurementSysInfo| IntraFreqMeasurementSysInfo-RSCP-LCR-r4| OPTIONAL, \\
```

```
},
                cpich-Ec-N0
                                       SEQUENCE
                    \verb|intraFreqMeasurementSysInfo| IntraFreqMeasurementSysInfo-ECN0-LCR-r4| OPTIONAL, \\
                    interFreqMeasurementSysInfo InterFreqMeasurementSysInfo-ECN0-LCR-r4 OPTIONAL
            }
        },
       hcs-used
                                       SEQUENCE
            -- CHOICE cellSelectQualityMeasure shall have the same value as the
            -- cellSelectQualityMeasure in MeasurementControlSysInfo
                                       CHOICE {
            cellSelectQualityMeasure
                cpich-RSCP
                                       SEOUENCE
                   intraFreqMeasurementSysInfo IntraFreqMeasurementSysInfo-HCS-RSCP-LCR-r4
    OPTIONAL,
                    interFreqMeasurementSysInfo InterFreqMeasurementSysInfo-HCS-RSCP-LCR-r4 OPTIONAL
                cpich-Ec-N0
                                       SEQUENCE
                                                   {
                   \verb|intraFreqMeasurementSysInfo| IntraFreqMeasurementSysInfo-HCS-ECN0-LCR-r4| \\
    OPTIONAL.
                    interFreqMeasurementSysInfo InterFreqMeasurementSysInfo-HCS-ECN0-LCR-r4 OPTIONAL
            }
        }
    }
MeasurementIdentity ::=
                          INTEGER (1..16)
MeasurementQuantityGSM ::=
                                    ENUMERATED {
                                       gsm-CarrierRSSI,
                                        dummy }
                                    SEQUENCE {
MeasurementReportingMode ::=
                                       TransferMode,
   measurementReportTransferMode
   periodicalOrEventTrigger
                                       PeriodicalOrEventTrigger
}
MeasurementType ::=
                                    CHOICE {
    intraFrequencyMeasurement
                                       IntraFrequencyMeasurement,
    \verb"interFrequency Measurement"
                                       InterFrequencyMeasurement,
    interRATMeasurement
                                       InterRATMeasurement,
    ue-positioning-Measurement
                                       UE-Positioning-Measurement,
    trafficVolumeMeasurement
                                       {\tt Traffic Volume Measurement},
    qualityMeasurement
                                       QualityMeasurement,
    ue-InternalMeasurement
                                       UE-InternalMeasurement
MeasurementType-r4 ::=
                                   CHOICE {
    intraFrequencyMeasurement
                                       IntraFrequencyMeasurement-r4,
                                       InterFrequencyMeasurement-r4,
    \verb"interFrequency Measurement"
    interRATMeasurement
                                       InterRATMeasurement-r4,
    up-Measurement
                                       UE-Positioning-Measurement-r4,
    trafficVolumeMeasurement
                                       TrafficVolumeMeasurement,
                                       OualityMeasurement,
    qualityMeasurement
    ue-InternalMeasurement
                                       UE-InternalMeasurement-r4
MeasurementValidity ::=
                                   SECTIENCE {
    ue-State
                                       ENUMERATED {
                                           cell-DCH, all-But-Cell-DCH, all-States }
}
                                    SEQUENCE (SIZE (1..8)) OF
MonitoredCellRACH-List ::=
                                       MonitoredCellRACH-Result
MonitoredCellRACH-Result ::=
                                    SEOUENCE {
                                       SFN-SFN-ObsTimeDifference
    sfn-SFN-ObsTimeDifference
                                                                          OPTIONAL,
    modeSpecificInfo
                                        CHOICE {
                                            SEQUENCE {
           primaryCPICH-Info
                                               PrimaryCPICH-Info,
                                               CHOICE {
            measurementQuantity
                cpich-Ec-N0
                                                   CPICH-Ec-N0,
                cpich-RSCP
                                                   CPICH-RSCP,
                pathloss
                                                   Pathloss,
                                                   NULL
                spare
            }
                                                                           OPTIONAL
        },
```

```
SEQUENCE {
        t.dd
                                               CellParametersID,
           cellParametersID
           primaryCCPCH-RSCP
                                               PrimaryCCPCH-RSCP
}
                                  ENUMERATED {
MultipathIndicator ::=
                                       nm,
                                        low,
                                       medium,
                                       high }
N-CR-T-CRMaxHyst ::=
                                   SEQUENCE {
   n-CR
                                       INTEGER (1..16)
                                                                          DEFAULT 8,
                                       T-CRMaxHyst
    t-CRMaxHvst
}
NavigationModelSatInfo ::=
                                   SEQUENCE {
                                       SatID,
    satID
    satelliteStatus
                                       SatelliteStatus,
    ephemerisParameter
                                       EphemerisParameter OPTIONAL
NavigationModelSatInfoList ::= SEQUENCE (SIZE (1..maxSat)) OF
                                       NavigationModelSatInfo
EphemerisParameter ::=
                                            SEQUENCE {
   codeOnL2
                                       BIT STRING (SIZE (2)),
   uraIndex
                                       BIT STRING (SIZE (4)),
    satHealth
                                       BIT STRING (SIZE (6)),
   iodc
                                       BIT STRING (SIZE (10)),
    12Pflag
                                       BIT STRING (SIZE (1)),
   sf1Revd
                                       SubFramelReserved,
    t-GD
                                       BIT STRING (SIZE (8)),
    t-oc
                                       BIT STRING (SIZE (16)),
   af2
                                       BIT STRING (SIZE (8)),
   af1
                                       BIT STRING (SIZE (16)),
   af0
                                       BIT STRING (SIZE (22)),
   c-rs
                                       BIT STRING (SIZE (16)),
   delta-n
                                       BIT STRING (SIZE (16)),
                                       BIT STRING (SIZE (32)),
   m0
                                       BIT STRING (SIZE (16)),
   c-uc
                                       BIT STRING (SIZE (32)),
   c-us
                                       BIT STRING (SIZE (16)),
   a-Sqrt
                                       BIT STRING (SIZE (32)),
                                       BIT STRING (SIZE (16)),
    t.-oe
   fitInterval
                                       BIT STRING (SIZE (1)),
   aodo
                                       BIT STRING (SIZE (5)),
                                       BIT STRING (SIZE (16)),
   c-ic
                                       BIT STRING (SIZE (32)),
   omega0
    c-is
                                       BIT STRING (SIZE (16)),
   i0
                                       BIT STRING (SIZE (32)),
                                       BIT STRING (SIZE (16)),
   c-rc
                                       BIT STRING (SIZE (32)),
   omega
                                       BIT STRING (SIZE (24)),
BIT STRING (SIZE (14))
    omegaDot
    iDot
NC-Mode ::=
                                   BIT STRING (SIZE (3))
                                   SEQUENCE {
Neighbour ::=
   modeSpecificInfo
                                   CHOICE {
                                    SEQUENCE {
           neighbourIdentity
                                               PrimaryCPICH-Info
                                                                                   OPTIONAL,
                                             UE-RX-TX-TimeDifferenceType2Info
           uE-RX-TX-TimeDifferenceType2Info
                                                                                   OPTIONAL
                                       SEQUENCE {
           neighbourAndChannelIdentity CellAndChannelIdentity
                                                                                   OPTIONAL
    neighbourQuality
                                     NeighbourQuality,
    sfn-SFN-ObsTimeDifference2
                                      SFN-SFN-ObsTimeDifference2}
Neighbour-v390ext ::=
                                           SEQUENCE {
                                  CHOICE {
    modeSpecificInfo
       fdd
                                    SEQUENCE {
           frequencyInfo
                                               FrequencyInfo
```

```
tdd
                                     NULL
   }
}
NeighbourList ::=
                                  SEQUENCE (SIZE (1..maxCellMeas)) OF
                                      Neighbour
-- The order of the cells in IE NeighbourList-v390ext shall be the
-- same as the order in IE NeighbourList
NeighbourList-v390ext ::=
                                          SEQUENCE (SIZE (1..maxCellMeas)) OF
                                     Neighbour-v390ext
NeighbourQuality ::=
                                 SEQUENCE {
   ue-Positioning-OTDOA-Quality
                                     UE-Positioning-OTDOA-Quality
NewInterFreqCell ::=
                                  SEQUENCE {
   interFreqCellID
                                      InterFreqCellID
                                                                         OPTIONAL,
   frequencyInfo
                                      FrequencyInfo
                                                                         OPTIONAL,
   cellInfo
                                      CellInfo
}
NewInterFreqCell-r4 ::= SEQUENCE { InterFreqCellID
                                    InterFreqCellID
   interFreqCellID
                                                                        OPTIONAL,
    frequencyInfo
                                      FrequencyInfo
                                                                         OPTIONAL,
   cellInfo
                                      CellInfo-r4
NewInterFreqCellList ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                     NewInterFreqCell
NewInterFreqCellList-r4 ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                      NewInterFreqCell-r4
NewInterFreqCellSI-RSCP ::=
                                      SEQUENCE {
    interFreqCellID
                                      InterFreqCellID
                                                                         OPTIONAL,
    frequencyInfo
                                      FrequencyInfo
                                                                         OPTIONAL,
   cellInfo
                                      CellInfoSI-RSCP
}
                                    SEQUENCE {
InterFreqCellID
NewInterFreqCellSI-ECN0 ::=
   interFreqCellID
                                                                         OPTIONAL,
                                   Interrection
FrequencyInfo
    frequencyInfo
                                                                         OPTIONAL,
   cellInfo
                                      CellInfoSI-ECN0
}
NewInterFreqCellSI-HCS-RSCP ::=
   interFreqCellID
   frequencyInfo
                                  SEQUENCE (
InterFreqCellID
FrequencyInfo
                                                                        OPTIONAL,
   frequencyInfo
                                                                         OPTIONAL,
                                      CellInfoSI-HCS-RSCP
   cellInfo
}
                                  SEQUENCE (
InterFreqCellID
NewInterFreqCellSI-HCS-ECN0 ::=
   interFreqCellID
                                                                         OPTIONAL,
   frequencyInfo
                                      FrequencyInfo
                                                                         OPTIONAL,
                                      CellInfoSI-HCS-ECN0
   cellInfo
}
                                  SEQUENCE {
InterFreqCellID
NewInterFreqCellSI-RSCP-LCR-r4 ::=
   interFregCellID
                                                                        OPTIONAL.
   frequencyInfo
                                      FrequencyInfo
                                                                         OPTIONAL,
   cellInfo
                                      CellInfoSI-RSCP-LCR-r4
}
NewInterFreqCellSI-ECN0-LCR-r4 ::=
                                        SEQUENCE {
    interFreqCellID
                                      InterFreqCellID
                                                                         OPTIONAL,
    frequencyInfo
                                       FrequencyInfo
                                                                         OPTIONAL,
                                      CellInfoSI-ECN0-LCR-r4
   cellInfo
}
NewInterFreqCellSI-HCS-RSCP-LCR-r4 ::=
                                         SEQUENCE {
   interFreqCellID
                                      InterFreqCellID
                                                                         OPTIONAL,
   frequencyInfo
                                      FrequencyInfo
                                                                         OPTIONAL,
   cellInfo
                                      CellInfoSI-HCS-RSCP-LCR-r4
NewInterFreqCellSI-HCS-ECN0-LCR-r4 ::=
                                        SEOUENCE {
                                                                         OPTIONAL,
   interFreqCellID
                                      InterFreqCellID
```

```
frequencyInfo
                                                                         FrequencyInfo
                                                                                                                                            OPTIONAL,
       cellInfo
                                                                         CellInfoSI-HCS-ECN0-LCR-r4
}
NewInterFreqCellSI-List-ECN0 ::=
                                                                                SEQUENCE (SIZE (1..maxCellMeas)) OF
                                                                         NewInterFreqCellSI-ECN0
                                                                                        SEQUENCE (SIZE (1..maxCellMeas)) OF
NewInterFreqCellSI-List-HCS-RSCP ::=
                                                                         NewInterFreqCellSI-HCS-RSCP
NewInterFreqCellSI-List-HCS-ECN0 ::=
                                                                                        SEQUENCE (SIZE (1..maxCellMeas)) OF
                                                                         NewInterFreqCellSI-HCS-ECN0
NewInterFreqCellSI-List-RSCP ::=
                                                                         SEQUENCE (SIZE (1..maxCellMeas)) OF
                                                                         NewInterFreqCellSI-RSCP
NewInterFreqCellSI-List-ECN0-LCR-r4 ::=
                                                                                SEQUENCE (SIZE (1..maxCellMeas)) OF
                                                                         NewInterFreqCellSI-ECN0-LCR-r4
{\tt NewInterFreqCellSI-List-HCS-RSCP-LCR-r4} \ ::= \ {\tt SEQUENCE} \ ({\tt SIZE} \ ({\tt 1..maxCellMeas})) \ {\tt OF} \ ({\tt NewInterFreqCellSI-List-HCS-RSCP-LCR-r4}) \ ({\tt SIZE} \ ({\tt 1..maxCellMeas})) \ {\tt OF} \ ({\tt NewInterFreqCellSI-List-HCS-RSCP-LCR-r4}) \ ({\tt SIZE} \ ({\tt 1..maxCellMeas})) \ {\tt OF} \ ({\tt NewInterFreqCellSI-List-HCS-RSCP-LCR-r4}) \ ({\tt SIZE} \ ({\tt 1..maxCellMeas})) \ {\tt OF} \ ({\tt NewInterFreqCellSI-List-HCS-RSCP-LCR-r4}) \ ({\tt SIZE} \ ({\tt 1..maxCellMeas})) \ {\tt OF} \ ({\tt 1..maxCellMeas}) \ ({\tt 1..maxCellMeas}
                                                                         {\tt NewInterFreqCellSI-HCS-RSCP-LCR-r4}
NewInterFreqCellSI-List-HCS-ECN0-LCR-r4 ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                                                         NewInterFreqCellSI-HCS-ECN0-LCR-r4
NewInterFreqCellSI-List-RSCP-LCR-r4 ::=
                                                                                SEQUENCE (SIZE (1..maxCellMeas)) OF
                                                                         NewInterFreqCellSI-RSCP-LCR-r4
NewInterRATCell ::=
                                                          SEOUENCE {
                                                                         InterRATCellID
       interRATCellID
                                                                                                                 OPTIONAL,
       technologySpecificInfo
                                                                         CHOICE {
                                                                              SEQUENCE {
              qsm
                      cellSelectionReselectionInfo
                                                                                        CellSelectReselectInfoSIB-11-12
                                                                                                                                                         OPTIONAL.
                      interRATCellIndividualOffset
                                                                                        InterRATCellIndividualOffset,
                     bsic
                                                                                        BSIC,
                      frequency-band
                                                                                        Frequency-Band,
                     bcch-ARECN
                                                                                        BCCH-ARFCN.
                      -- dummy is not used in this version of the specification, it should
                      -- not be sent and if received it should be ignored.
                                                                                        NULL
               },
                                                                                SEQUENCE {
               is-2000
                     is-2000SpecificMeasInfo
                                                                                        IS-2000SpecificMeasInfo
               -- ASN.1 inconsistency: NewInterRATCellList should be optional within
               -- InterRATCellInfoList. The UE shall consider IE NewInterRATCell with
               -- technologySpecificInfo set to "absent" as valid and handle the
               -- message as if the IE NewInterRATCell was absent
                                                                                NULL,
              spare1
                                                                                NULL
       }
NewInterRATCell-B ::=
                                                                  SEQUENCE {
                                                                         InterRATCellID
                                                                                                              OPTIONAL,
       interRATCellID
                                                                         CHOICE {
       technologySpecificInfo
                                                                                SEQUENCE {
                     cellSelectionReselectionInfo
                                                                                       CellSelectReselectInfoSIB-11-12
                                                                                                                                                           OPTIONAL,
                      interRATCellIndividualOffset
                                                                                        InterRATCellIndividualOffset,
                     bsic
                                                                                        BSTC.
                      frequency-band
                                                                                        Frequency-Band,
                      bcch-ARFCN
                                                                                        BCCH-ARFCN,
                      -- dummy is not used in this version of the specification, it should
                      -- not be sent and if received it should be ignored.
                                                                                        NULL
                                                                                                                             OPTIONAL
                     dummy
               is-2000
                                                                                SEQUENCE {
                     is-2000SpecificMeasInfo
                                                                                        IS-2000SpecificMeasInfo
                 - ASN.1 inconsistency: NewInterRATCellList-B should be optional within
               -- InterRATCellInfoList-B. The UE shall consider IE NewInterRATCell-B with
               -- technologySpecificInfo set to "absent" as valid and handle the
               -- message as if the IE NewInterRATCell-B was absent
               absent
                                                                                NULL,
              spare1
                                                                                 NULL
       }
}
```

```
NewInterRATCellList ::=
                             SEQUENCE (SIZE (1..maxCellMeas)) OF
                                      NewInterRATCell
NewInterRATCellList-B ::=
                                   SEQUENCE (SIZE (1..maxCellMeas)) OF
                                      NewInterRATCell-B
NewIntraFreqCell ::=
                                 SEOUENCE {
                                      IntraFreqCellID
                                                                         OPTIONAL,
   intraFregCellID
    cellInfo
                                      CellInfo
NewIntraFreqCell-r4 ::= SEQUENCE {
   intraFreqCellID IntraF
                                      IntraFreqCellID
                                                                         OPTIONAL,
   cellInfo
                                      CellInfo-r4
NewIntraFreqCellList ::=
                                  SEQUENCE (SIZE (1..maxCellMeas)) OF
                                      NewIntraFreqCell
NewIntraFreqCellList-r4 ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                      NewIntraFreqCell-r4
NewIntraFreqCellSI-RSCP ::=
                                      SEQUENCE {
   intraFreqCellID
                                      IntraFreqCellID
                                                                          OPTIONAL,
   cellInfo
                                      CellInfoST-RSCP
}
\label{eq:new_intra} \mbox{NewIntraFreqCellSI-ECNO} ::= \mbox{SEQUENCE} \ \{
   intraFreqCellID
                                      IntraFregCellID
                                                                          OPTIONAL.
                                      CellInfoSI-ECN0
   cellInfo
NewIntraFreqCellSI-HCS-RSCP ::= SEQUENCE {
                                  IntraFreqCellID
   intraFreqCellID
                                                                          OPTIONAL,
                                      CellInfoSI-HCS-RSCP
   cellInfo
}
NewIntraFreqCellSI-HCS-ECN0 ::= SEQUENCE {
                                  IntraFreqCellID
                                                                          OPTIONAL,
   intraFreqCellID
   cellInfo
                                       CellInfoSI-HCS-ECN0
}
NewIntraFreqCellSI-RSCP-LCR-r4 ::= SEQUENCE { intraFreqCellID IntraFreqCe
   intraFreqCellID
                                       IntraFreqCellID
                                                                         OPTIONAL,
    cellInfo
                                       CellInfoSI-RSCP-LCR-r4
}
NewIntraFreqCellSI-ECN0-LCR-r4 ::=
                                   SEQUENCE {
   intraFreqCellID
                                       IntraFreqCellID
                                                                          OPTIONAL,
                                       CellInfoSI-ECN0-LCR-r4
NewIntraFreqCellSI-HCS-RSCP-LCR-r4 ::= SEQUENCE {
   intraFreqCellID
                                       IntraFreqCellID
                                                                          OPTIONAL,
                                       CellInfoSI-HCS-RSCP-LCR-r4
   cellInfo
}
NewIntraFreqCellSI-HCS-ECN0-LCR-r4 ::= SEQUENCE {
   intraFreqCellID
                                       IntraFreqCellID
                                                                         OPTIONAL,
                                       CellInfoSI-HCS-ECN0-LCR-r4
    cellInfo
}
NewIntraFreqCellSI-List-RSCP ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                          NewIntraFreqCellSI-RSCP
                                    SEQUENCE (SIZE (1..maxCellMeas)) OF
NewIntraFreqCellSI-List-ECN0 ::=
                                       NewIntraFreqCellSI-ECN0
NewIntraFreqCellSI-List-HCS-RSCP ::=
                                       SEQUENCE (SIZE (1..maxCellMeas)) OF
                                       NewIntraFreqCellSI-HCS-RSCP
                                       SEQUENCE (SIZE (1..maxCellMeas)) OF
NewIntraFreqCellSI-List-HCS-ECN0 ::=
                                       NewIntraFreqCellSI-HCS-ECN0
NewIntraFreqCellSI-List-RSCP-LCR-r4 ::=
                                           SEQUENCE (SIZE (1..maxCellMeas)) OF
                                           NewIntraFreqCellSI-RSCP-LCR-r4
                                         SEQUENCE (SIZE (1..maxCellMeas)) OF
NewIntraFreqCellSI-List-ECN0-LCR-r4 ::=
                                       NewIntraFreqCellSI-ECN0-LCR-r4
```

```
NewIntraFreqCellSI-List-HCS-RSCP-LCR-r4 ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                          NewIntraFreqCellSI-HCS-RSCP-LCR-r4
NewIntraFreqCellSI-List-HCS-ECNO-LCR-r4 ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                          NewIntraFreqCellSI-HCS-ECN0-LCR-r4
    -- IE "nonUsedFreqThreshold" is not needed in case of event 2a
-- In case of event 2a UTRAN should include value 0 within IE "nonUsedFreqThreshold"
    -- In case of event 2a, the UE shall be ignore IE "nonUsedFreqThreshold"
    -- In later versions of the message including this IE, a special version of
    -- IE "NonUsedFreqParameterList" may be defined for event 2a, namely a
    -- version not including IE "nonUsedFreqThreshold"
                            SEQUENCE {
NonUsedFregParameter ::=
   nonUsedFreqThreshold
                                         Threshold,
   nonUsedFreqW
}
NonUsedFreqParameterList ::=
                                      SEQUENCE (SIZE (1..maxFreq)) OF
                                          NonUsedFreqParameter
                                      INTEGER (0..4095)
ObservedTimeDifferenceToGSM ::=
                                      ENUMERATED {
OTDOA-SearchWindowSize ::=
                                         c20, c40, c80, c160, c320,
                                          c640, c1280, moreThan1280 }
-- SPARE: Pathloss, Max = 158
-- Values above Max are spare
                                      INTEGER (46..173)
Pathloss ::=
PenaltyTime-RSCP ::=
                                      CHOICE {
                                          NULL,
   notUsed
                                          TemporaryOffset1,
    pt10
   pt20
                                          TemporaryOffset1,
   pt30
                                          TemporaryOffset1,
    pt40
                                          TemporaryOffset1,
   pt50
                                          TemporaryOffset1,
                                          TemporaryOffset1
    pt60
PenaltyTime-ECN0 ::=
                                      CHOICE {
                                          NULL.
   not.Used
                                          TemporaryOffsetList,
    pt10
    pt20
                                          TemporaryOffsetList,
   pt30
                                          TemporaryOffsetList,
    pt40
                                          TemporaryOffsetList,
                                          TemporaryOffsetList,
    pt50
    pt60
                                          TemporaryOffsetList
                                      ENUMERATED {
PendingTimeAfterTrigger ::=
                                          ptat0-25, ptat0-5, ptat1,
                                          ptat2, ptat4, ptat8, ptat16 }
PeriodicalOrEventTrigger ::=
                                      ENUMERATED {
                                         periodical,
                                          eventTrigger }
PeriodicalReportingCriteria ::=
                                      SEQUENCE {
                                         ReportingAmount
   reportingAmount
                                                                          DEFAULT ra-Infinity.
   reportingInterval
                                          ReportingIntervalLong
PeriodicalWithReportingCellStatus ::= SEQUENCE {
   periodicalReportingCriteria, PeriodicalReportingCriteria,
   reportingCellStatus
                                         ReportingCellStatus
                                                                                OPTIONAL
}
PLMNIdentitiesOfNeighbourCells ::= SEQUENCE {
        plmmsOfIntraFreqCellsList
plmmsOfInterFreqCellsList
plmmsOfInterFreqCellsList
plmmsOfInterRATCellsList
plmmsOfInterRATCellsList
                                                                               OPTIONAL,
                                                                               OPTIONAL,
                                                                                OPTIONAL
}
PLMNsOfInterFreqCellsList ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                              SEQUENCE {
                                                  PLMN-Identity
    plmn-Identity
                                                                              OPTIONAL
```

```
SEQUENCE (SIZE (1..maxCellMeas)) OF
PLMNsOfIntraFreqCellsList ::=
                                              SEQUENCE {
                                                  PLMN-Identity
                                                                              OPTIONAL
    plmn-Identity
PLMNsOfInterRATCellsList ::=
                                         SEQUENCE (SIZE (1..maxCellMeas)) OF
                                              SEOUENCE {
                                                 PLMN-Identity
   plmn-Identity
                                                                              OPTIONAL
}
                                    CHOICE {
PositionEstimate ::=
    ellipsoidPoint EllipsoidPoint,
ellipsoidPointUncertCircle EllipsoidPointUncertCircle,
ellipsoidPointUncertEllipse EllipsoidPointUncertEllipse,
ellipsoidPointAltitude EllipsoidPointAltitudeEllipse
}
PositioningMethod ::=
                                      ENUMERATED {
                                         otdoa,
                                          gps,
                                          otdoaOrGPS, cellID }
-- Actual value PRC = IE value * 0.32
PRC ::=
                                      INTEGER (-2047..2047)
-- SPARE: PrimaryCCPCH-RSCP, Max = 91
-- Values above Max are spare
PrimaryCCPCH-RSCP ::=
                                     INTEGER (0..127)
Q-HCS ::=
                                     INTEGER (0..99)
Q-OffsetS-N ::=
                                     INTEGER (-50..50)
Q-QualMin ::=
                                      INTEGER (-24..0)
-- Actual value Q-RxlevMin = (IE value * 2) + 1
                                     INTEGER (-58..-13)
Q-RxlevMin ::=
QualityEventResults ::=
                                     SEQUENCE (SIZE (1..maxTrCH)) OF
                                         TransportChannelIdentity
QualityMeasuredResults ::= blerMeasurementResultsList
                                      SEQUENCE {
                                      BLER-MeasurementResultsList
                                                                              OPTIONAL,
    modeSpecificInfo
                                         CHOICE {
        fdd
                                            NULL.
        tdd
                                              SEQUENCE {
            sir-MeasurementResults
                                                 SIR-MeasurementList OPTIONAL
        }
    }
}
QualityMeasurement ::= qualityReportingQuantity
                                     SEQUENCE {
                                          QualityReportingQuantity OPTIONAL,
                                          QualityReportCriteria
    reportCriteria
}
QualityReportCriteria ::= qualityReportingCriteria
                                     CHOICE {
    QualityReportingCriteria, periodicalReportingCriteria, noReporting
                                         PeriodicalReportingCriteria,
    noReporting
}
QualityReportingCriteria ::= SEQUENCE (SIZE (1..maxTrCH)) OF
                                          QualityReportingCriteriaSingle
QualityReportingCriteriaSingle ::= SEQUENCE {
    transportChannelIdentity TransportChannelIdentity,
    totalCRC
                                          INTEGER (1..512),
    badCRC
                                         INTEGER (1..512),
                                         INTEGER (1..512)
    pendingAfterTrigger
}
QualityReportingQuantity ::= SEQUENCE {
    dl-TransChBLER
                                       BOOLEAN,
    bler-dl-TransChIdList
                                          BLER-TransChIdList
                                                                              OPTIONAL.
    modeSpecificInfo
                                          CHOICE {
```

```
fdd
                                            NULL,
        tdd
                                             SEQUENCE {
            sir-TFCS-List
                                                 SIR-TFCS-List
                                                                             OPTIONAL
}
                                     ENUMERATED {
RAT-Type ::=
                                         gsm, is2000 }
ReferenceCellPosition ::=
                                     CHOICE {
                                        EllipsoidPoint,
    ellipsoidPoint
    ellipsoidPointWithAltitude
                                        EllipsoidPointAltitude
-- ReferenceLocation, as defined in 23.032
                                SEQUENCE {
ReferenceLocation ::=
    \verb|ellipsoidPointAltitudeEllipsoide|\\
                                             EllipsoidPointAltitudeEllipsoide
ReferenceTimeDifferenceToCell ::= CHOICE {
    -- Actual value accuracy40 = IE value * 40
                                         INTEGER (0..960),
    accuracy40
    -- Actual value accuracy256 = IE value * 256
                                         INTEGER (0..150),
    accuracy256
    -- Actual value accuracy2560 = IE value * 2560
    accuracy2560
                                         INTEGER (0..15)
}
RemovedInterFreqCellList ::=
                                    CHOICE {
                                        NULL,
    removeAllInterFreqCells
                                         SEQUENCE (SIZE (1..maxCellMeas)) OF
    removeSomeInterFreqCells
                                             InterFreqCellID,
                                         NULL
    removeNoInterFreqCells
}
RemovedInterRATCellList ::= CHOICE {
                               NULL,
   removeAllInterRATCells
                                    SEQUENCE (SIZE (1..maxCellMeas)) OF
    removeSomeInterRATCells
                                            InterRATCellID,
    removeNoInterRATCells
                                    NULL
}
RemovedIntraFreqCellList ::= removeAllIntraFreqCells
                                    CHOICE {
    removeSomeIntraFreqCells
                                        SEQUENCE (SIZE (1..maxCellMeas)) OF
                                             IntraFreqCellID,
    removeNoIntraFreqCells
                                        NIII.I.
ReplacementActivationThreshold ::= ENUMERATED {
                                         notApplicable, t1, t2,
                                         t3, t4, t5, t6, t7 }
ReportDeactivationThreshold ::=
                                     ENUMERATED {
                                         notApplicable, t1, t2,
                                         t3, t4, t5, t6, t7 }
                                     ENUMERATED {
ReportingAmount ::=
                                         ral, ra2, ra4, ra8, ra16, ra32,
                                         ra64, ra-Infinity }
ReportingCellStatus ::=
                                     CHOICE {
                                         MaxNumberOfReportingCellsType1,
    withinActiveSet
    withinMonitoredSetUsedFreq
                                         MaxNumberOfReportingCellsType1,
    within {\tt Active And Or Monitored Used Freq} \quad {\tt Max Number Of Reporting Cells Type 1}, \\
    withinDetectedSetUsedFreq
                                         MaxNumberOfReportingCellsType1,
    {\tt withinMonitoredAndOrDetectedUsedFreq}
                                  {\tt MaxNumberOfReportingCellsType1},
    allActiveplusMonitoredSet
                                        MaxNumberOfReportingCellsType3,
    allActivePlusDetectedSet
                                         MaxNumberOfReportingCellsType3,
    allActivePlusMonitoredAndOrDetectedSet
                                       MaxNumberOfReportingCellsType3,
    withinVirtualActSet
                                    MaxNumberOfReportingCellsType1,
    withinMonitoredSetNonUsedFreq
                                        MaxNumberOfReportingCellsType1,
    within \verb|Monitored| And \verb|OrVirtual| Active SetNon \verb|UsedFreq|
                                         MaxNumberOfReportingCellsType1,
    allVirtualActSetplusMonitoredSetNonUsedFreq
```

```
MaxNumberOfReportingCellsType3,
        withinActSetOrVirtualActSet-InterRATcells
                                                                                  MaxNumberOfReportingCellsType2,
        within {\tt ActSetAndOrMonitoredUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreqOrVirt
                                                                                  MaxNumberOfReportingCellsType2
}
ReportingCellStatusOpt ::= SEQUENCE {
     reportingCellStatus
                                                                              ReportingCellStatus
                                                                                                                                                            OPTIONAL
ReportingInfoForCellDCH ::= SEQUENCE { intraFreqReportingQuantity IntraF
                                                                       IntraFreqReportingQuantity,
        intraFreqkeportingMode measurementReportingMode
                                                                                  MeasurementReportingMode,
        reportCriteria
                                                                                  CellDCH-ReportCriteria
}
ReportingInfoForCellDCH-LCR-r4 ::= SEQUENCE {
        intraFreqReportingQuantity IntraFreqReportingQuantity,
measurementReportingMode MeasurementReportingMode,
reportCriteria
        reportCriteria
                                                                                 CellDCH-ReportCriteria-LCR-r4
ReportingInterval ::=
                                                                        ENUMERATED {
                                                                                  noPeriodicalreporting, ri0-25,
                                                                                  ri0-5, ri1, ri2, ri4, ri8, ri16 }
                                                                           ENUMERATED {
ReportingIntervalLong ::=
                                                                                  ril0, ril0-25, ril0-5, ril1,
                                                                                   ril2, ril3, ril4, ril6, ril8,
                                                                                  ril12, ril16, ril20, ril24,
                                                                           ril28, ril32, ril64 }
-- When the value 'ril0' is used, the UE behaviour is not
                                                                           -- defined.
-- Actual value ReportingRange = IE value * 0.5
ReportingRange ::=
                                                                          INTEGER (0..29)
RL-AdditionInfoList ::= SEQUENCE (SIZE (1..maxRL)) OF
                                                                                  PrimaryCPICH-Info
                                                                    SEQUENCE {
RL-InformationLists ::=
                                                                         RL-AdditionInfoList OPTIONAL, RL-RemovalInformationList OPTIONAL
        rl-AdditionInfoList
        rL-RemovalInformationList
}
                                                                          ENUMERATED {
RLC-BuffersPayload ::=
                                                                                   pl0, pl4, pl8, pl16, pl32,
                                                                                   pl64, pl128, pl256, pl512, pl1024,
                                                                                   pl2k, pl4k, pl8k, pl16k, pl32k,
                                                                                   pl64k, pl128k, pl256k, pl512k, pl1024k,
                                                                                   spare12, spare11, spare10, spare9, spare8,
                                                                                   spare7, spare6, spare5, spare4, spare3,
                                                                                   spare2, spare1 }
  -- Actual value RRC = IE value * 0.032
                                                                          INTEGER (-127..127)
SatData ::=
                                                                           SECUENCE!
        satID
                                                                                   SatID,
        iode
                                                                                   IODE
}
                                                                          SEQUENCE (SIZE (0..maxSat)) OF
SatDataList ::=
                                                                                   SatData
SatelliteStatus ::=
                                                                           ENUMERATED {
                                                                                  ns-NN-U,
                                                                                   es-SN
                                                                                   es-NN-U,
                                                                                   rev2,
                                                                                   rev }
 -- Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [12].
                                                                           INTEGER (0..63)
SatID ::=
                                                               ENUMERATED { false }
SFN-Offset-Validity ::=
```

```
SFN-SFN-Drift ::=
                                    ENUMERATED {
                                        sfnsfndrift0, sfnsfndrift1, sfnsfndrift2,
                                        sfnsfndrift3, sfnsfndrift4, sfnsfndrift5,
                                        sfnsfndrift8, sfnsfndrift10, sfnsfndrift15,
                                        sfnsfndrift25, sfnsfndrift35, sfnsfndrift50,
                                        {\tt sfnsfndrift65}, \ {\tt sfnsfndrift80}, \ {\tt sfnsfndrift100},\\
                                        sfnsfndrift-1, sfnsfndrift-2, sfnsfndrift-3,
                                        sfnsfndrift-4, sfnsfndrift-5, sfnsfndrift-8,
                                        sfnsfndrift-10, sfnsfndrift-15, sfnsfndrift-25,
                                        sfnsfndrift-35, sfnsfndrift-50, sfnsfndrift-65,
                                        sfnsfndrift-80, sfnsfndrift-100}
SFN-SFN-ObsTimeDifference ::= CHOICE {
   type1
                                       SFN-SFN-ObsTimeDifferencel,
                                        SFN-SFN-ObsTimeDifference2
    type2
}
-- SPARE: SFN-SFN-ObsTimeDifference1, Max = 9830399
-- For 1.28Mcps TDD, Max value of SFN-SFN-ObsTimeDifferencel is 3276799.
-- Values above Max are spare
SFN-SFN-ObsTimeDifference1 ::=
                                   INTEGER (0..16777215)
-- SPARE: SFN-SFN-ObsTimeDifference2, Max = 40961
-- For 1.28Mcps TDD, Max value of SFN-SFN-ObsTimeDifference2 is 27649.
-- Values above Max are spare
SFN-SFN-ObsTimeDifference2 ::=
                                  INTEGER (0..65535)
SFN-SFN-OTD-Type ::=
                                    ENUMERATED {
                                       noReport,
                                        type1,
                                        type2 }
SFN-SFN-RelTimeDifferencel ::= SEQUENCE {
    sfn-Offset. INTEGE
    sfn-Offset
                                     INTEGER (0 .. 4095),
   sfn-sfn-Reltimedifference
                                       INTEGER (0.. 38399)
}
SFN-TOW-Uncertainty ::=
                                    ENUMERATED {
                                        lessThan10,
                                        moreThan10 }
SIR ::=
                                    INTEGER (0..63)
SIR-MeasurementList ::=
                                    SEQUENCE (SIZE (1..maxCCTrCH)) OF
                                        SIR-MeasurementResults
SIR-MeasurementResults ::=
                                    SEOUENCE {
   tfcs-ID
                                       TFCS-IdentityPlain,
   sir-TimeslotList
                                        SIR-TimeslotList
}
SIR-TFCS ::=
                                   TFCS-IdentityPlain
                                    SEQUENCE (SIZE (1..maxCCTrCH)) OF
STR-TFCS-List ::=
                                        SIR-TFCS
                                    SEQUENCE (SIZE (1..maxTS)) OF
SIR-TimeslotList ::=
-- SubFramelReserved, reserved bits in subframe 1 of the GPS navigation message
SubFramelReserved ::= SEQUENCE {
   reserved1
                                       BIT STRING (SIZE (23)),
                                        BIT STRING (SIZE (24)),
   reserved2
   reserved3
                                        BIT STRING (SIZE (24)),
   reserved4
                                        BIT STRING (SIZE (16))
}
T-ADVinfo ::=
                                    SEQUENCE {
                                        INTEGER(0..2047),
                t-ADV
                                        INTEGER(0..4095)
}
```

```
T-CRMax ::=
                                    CHOICE {
   notUsed
                                        NULL,
                                        N-CR-T-CRMaxHyst,
   t30
   t60
                                        N-CR-T-CRMaxHyst,
    t120
                                        N-CR-T-CRMaxHyst,
   t180
                                        N-CR-T-CRMaxHyst,
                                        N-CR-T-CRMaxHyst
   t.240
}
T-CRMaxHyst ::=
                                    ENUMERATED {
                                        notUsed, t10, t20, t30,
                                        t40, t50, t60, t70 }
TemporaryOffset1 ::=
                                    ENUMERATED {
                                        to3, to6, to9, to12, to15,
                                         to18, to21, infinite }
TemporaryOffset2 ::=
                                    ENUMERATED {
                                        to2, to3, to4, to6, to8,
                                        to10, to12, infinite }
TemporaryOffsetList ::=
    temporaryOffset1
    temporaryOffset2
                                    SEQUENCE
                                        TemporaryOffset1,
                                        TemporaryOffset2
}
Threshold ::=
                                    INTEGER (-115..0)
-- The order of the list corresponds to the order of frequency defined in Inter-FreqEventCriteria
ThreholdNonUsedFrequency-deltaList ::= SEQUENCE (SIZE (1..maxFreq)) OF
                                            DeltaRSCPPerCell
ThresholdPositionChange ::=
                                    ENUMERATED {
                                        pc10, pc20, pc30, pc40, pc50,
                                         pc100, pc200, pc300, pc500,
                                        pc1000, pc2000, pc5000, pc10000,
                                        pc20000, pc50000, pc100000 }
ThresholdSFN-GPS-TOW ::=
                                    ENUMERATED {
                                        ms1, ms2, ms3, ms5, ms10,
                                        ms20, ms50, ms100 }
                                    ENUMERATED {
ThresholdSFN-SFN-Change ::=
                                        c0-25, c0-5, c1, c2, c3, c4, c5,
                                         c10, c20, c50, c100, c200, c500,
                                        c1000, c2000, c5000 }
                                    INTEGER (-115..165)
ThresholdUsedFrequency ::=
-- Actual value TimeInterval = IE value * 20.
TimeInterval ::=
                                    INTEGER (1..13)
TimeslotInfo ::=
                                    SEQUENCE {
    timeslotNumber
                                        TimeslotNumber,
   burstType
                                        BurstType
}
TimeslotInfo-LCR-r4 ::=
                                    SEQUENCE {
    timeslotNumber
                                        TimeslotNumber-LCR-r4
                                    SEQUENCE (SIZE (1..maxTS)) OF
TimeslotInfoList ::=
                                        TimeslotInfo
TimeslotInfoList-LCR-r4 ::=
                                    SEQUENCE (SIZE (1..maxTS-LCR)) OF
                                        TimeslotInfo-LCR-r4
TimeslotInfoList-r4 ::=
                                    CHOICE {
   tdd384
                                       SEQUENCE (SIZE (1..maxTS)) OF
                                            TimeslotInfo,
                                        SEQUENCE (SIZE (1..maxTS-LCR)) OF
    tdd128
                                            TimeslotInfo-LCR-r4
}
-- SPARE: TimeslotISCP, Max = 91
-- Values above Max are spare
```

```
TimeslotISCP ::=
                                      INTEGER (0..127)
-- TimeslotISCP-List shall not include more than 6 elements in 1.28Mcps TDD mode.
TimeslotISCP-List ::=
                                      SEQUENCE (SIZE (1..maxTS)) OF
                                           TimeslotISCP
TimeslotListWithISCP ::=
                                      SEQUENCE (SIZE (1..maxTS)) OF
                                           TimeslotWithISCP
TimeslotWithISCP ::=
                                     SEQUENCE {
                                           TimeslotNumber,
    timeslot
    timeslotISCP
                                           TimeslotISCP
TimeToTrigger ::=
                                       ENUMERATED {
                                           ttt0, ttt10, ttt20, ttt40, ttt60,
                                            ttt80, ttt100, ttt120, ttt160,
                                            ttt200, ttt240, tt320, ttt640,
                                           ttt1280, ttt2560, ttt5000 }
TrafficVolumeEventParam ::=
                                       SEOUENCE {
                                           TrafficVolumeEventType,
    eventID
    reportingThreshold
                                           TrafficVolumeThreshold,
                                           TimeToTrigger
    timeToTrigger
                                                                                   OPTIONAL.
    pendingTimeAfterTrigger
                                           PendingTimeAfterTrigger
                                                                                   OPTIONAL,
    tx-InterruptionAfterTrigger
                                          TX-InterruptionAfterTrigger
                                                                                  OPTIONAL
}
TrafficVolumeEventResults ::= SEQUENCE {
    ul-transportChannelCausingEvent UL-TrCH-Identity,
    trafficVolumeEventIdentity
                                          TrafficVolumeEventType
}
TrafficVolumeEventType ::= ENUMERATED {
                                           e4a,
                                           e4b }
TrafficVolumeMeasQuantity ::=
                                       CHOICE {
                                        NULL,
   rlc-BufferPayload
    averageRLC-BufferPayload
                                            TimeInterval,
    varianceOfRLC-BufferPayload
                                           TimeInterval
}
    TrafficVolumeMeasSysInfo ::=
                                        MeasurementIdentity
                                                                          DEFAULT 4,
    {\tt trafficVolumeMeasurementObjectList} \quad {\tt TrafficVolumeMeasurementObjectList} \quad {\tt OPTIONAL}, \\
    trafficVolumeMeasQuantity TrafficVolumeMeasQuantity OPTIONAL, trafficVolumeReportingQuantity TrafficVolumeReportingQuantity OPTIONAL,
    -- dummy is not used in this version of specification, it should
    -- not be sent and if received it should be ignored.
                                           TrafficVolumeReportingCriteria
                                                                                  OPTIONAL,
    dummy
    measurementValidity
                                           MeasurementValidity
                                                                                   OPTIONAL,
    measurementReportingMode
                                           MeasurementReportingMode,
                                          TrafficVolumeReportCriteriaSysInfo
    reportCriteriaSysInf
}
TrafficVolumeMeasuredResults ::= SEQUENCE {
    rb-Identity RB-Identity, rlc-BuffersPayload RLC-BuffersPayload AverageRLC-BufferPayload VarianceOfRLC-BufferPayload
   rb-Identity
                                           - Durrersray10ad
AverageRLC-BufferPayload
VarianceOfRLC-BufferPayload
                                                                                  OPTIONAL,
                                          RLC-BuffersPayload
                                                                                   OPTIONAL,
TrafficVolumeMeasuredResultsList ::= SEQUENCE (SIZE (1..maxRB)) OF
                                           TrafficVolumeMeasuredResults
TrafficVolumeMeasurement ::= SEQUENCE {
    trafficVolumeMeasurementObjectList TrafficVolumeMeasurementObjectList OPTIONAL, trafficVolumeMeasQuantity TrafficVolumeMeasQuantity OPTIONAL, trafficVolumeReportingQuantity TrafficVolumeReportingQuantity OPTIONAL, measurementValidity MeasurementValidity OPTIONAL,
                                                                                OPTIONAL,
    reportCriteria
                                           TrafficVolumeReportCriteria
}
TrafficVolumeMeasurementObjectList ::= SEQUENCE (SIZE (1..maxTrCH)) OF
```

UL-TrCH-Identity

```
TrafficVolumeReportCriteria ::= CHOICE {
    trafficVolumeReportingCriteria TrafficVolumeReportingCriteria,
    periodicalReportingCriteria
                                        PeriodicalReportingCriteria,
    noReporting
                                        NULL
}
TrafficVolumeReportCriteriaSysInfo ::= CHOICE {
    trafficVolumeReportingCriteria TrafficVolumeReportingCriteria, periodicalReportingCriteria PeriodicalReportingCriteria
   periodicalReportingCriteria
                                        PeriodicalReportingCriteria
}
TrafficVolumeReportingCriteria ::= SEQUENCE {
    -- NOTE: transChCriteriaList should be mandatory in later versions of this message
    transChCriteriaList
                                        TransChCriteriaList
}
TrafficVolumeReportingQuantity ::= SEQUENCE {
   rlc-RB-BufferPayload
    rlc-RB-BufferPayloadAverage
                                        BOOLEAN,
                                        BOOLEAN
    rlc-RB-BufferPayloadVariance
                                    ENUMERATED {
TrafficVolumeThreshold ::=
                                         th8, th16, th32, th64, th128,
                                         th256, th512, th1024, th2k, th3k,
                                         th4k, th6k, th8k, th12k, th16k,
                                         th24k, th32k, th48k, th64k, th96k,
                                         th128k, th192k, th256k, th384k,
                                         th512k, th768k }
                                    SEQUENCE {
TransChCriteria ::=
   ul-transportChannelID
                                        UL-TrCH-Identity
                                                                             OPTIONAL,
                                         SEQUENCE (SIZE (1..maxMeasParEvent)) OF
    eventSpecificParameters
                                            TrafficVolumeEventParam
                                                                             OPTIONAL
TransChCriteriaList ::=
                               SEQUENCE (SIZE (1..maxTrCH)) OF
                                         TransChCriteria
TransferMode ::=
                                    ENUMERATED {
                                        acknowledgedModeRLC,
                                         unacknowledgedModeRLC }
TransmittedPowerThreshold ::=
                                    INTEGER (-50..33)
TriggeringCondition1 ::=
                                    ENUMERATED {
                                        activeSetCellsOnly,
                                         monitoredSetCellsOnly,
                                        activeSetAndMonitoredSetCells }
                                    ENUMERATED {
TriggeringCondition2 ::=
                                        activeSetCellsOnly,
                                         monitoredSetCellsOnly,
                                         activeSetAndMonitoredSetCells,
                                         detectedSetCellsOnly,
                                         detectedSetAndMonitoredSetCells }
TX-InterruptionAfterTrigger ::=
                                    ENUMERATED {
                                        txiat0-25, txiat0-5, txiat1,
                                         txiat2, txiat4, txiat8, txiat16 }
UDRE ::=
                                     ENUMERATED {
                                         lessThan1,
                                         between1-and-4,
                                         between4-and-8,
                                        over8 }
                                    SEQUENCE {
UE-6AB-Event ::=
    timeToTrigger
                                        TimeToTrigger,
    transmittedPowerThreshold
                                        TransmittedPowerThreshold
}
                                    SEQUENCE {
UE-6FG-Event ::=
                                       TimeToTrigger,
   timeToTrigger
    -- in 1.28 Mcps TDD ue-RX-TX-TimeDifferenceThreshold corresponds to T_{\text{ADV}} Threshold
   ue-RX-TX-TimeDifferenceThreshold UE-RX-TX-TimeDifferenceThreshold
}
```

```
-- dummy and dummy2 are not used in this version of the specification, they should
-- not be sent and if received they should be ignored.
                                   CHOICE {
UE-AutonomousUpdateMode ::=
   dummy
                                        NULL.
    onWithNoReporting
                                        NULL,
                                        RL-InformationLists
    dummy2
}
UE-InternalEventParam ::=
                                    CHOICE {
   event6a
                                        UE-6AB-Event,
    event.6b
                                        UE-6AB-Event.
    event6c
                                        TimeToTrigger,
    event6d
                                        TimeToTrigger,
    event6e
                                        TimeToTrigger,
    event6f
                                        UE-6FG-Event,
                                        UE-6FG-Event
    event6q
UE-InternalEventParamList ::=
                                    SEQUENCE (SIZE (1..maxMeasEvent)) OF
                                        UE-InternalEventParam
UE-InternalEventResults ::=
                                    CHOICE {
   event.6a
                                        NULL,
                                        NULL,
    event6b
    event6c
                                        NULL,
    event6d
                                        NULL,
    event6e
                                        NULL.
    event6f
                                        PrimaryCPICH-Info,
                                        PrimaryCPICH-Info,
    event6q
    spare
                                        NULL
UE-InternalMeasQuantity ::=
                                    SEOUENCE {
    measurementQuantity
                                        UE-MeasurementQuantity,
    filterCoefficient
                                        FilterCoefficient
                                                                             DEFAULT fc0
}
UE-InternalMeasuredResults ::=
                                    SEQUENCE {
    modeSpecificInfo
                                        CHOICE {
                                          SEQUENCE {
        fdd
            ue-TransmittedPowerFDD
                                                UE-TransmittedPower
                                                                             OPTIONAL,
            ue-RX-TX-ReportEntryList
                                                UE-RX-TX-ReportEntryList
                                                                             OPTIONAL
                                            SEQUENCE {
            ue-TransmittedPowerTDD-List
                                                UE-TransmittedPowerTDD-List OPTIONAL,
                                                UL-TimingAdvance
                                                                             OPTIONAL
            appliedTA
        }
    }
}
UE-InternalMeasuredResults-LCR-r4 ::=
                                        SEQUENCE {
       ue-TransmittedPowerTDD-List
                                            UE-TransmittedPowerTDD-List
                                                                             OPTIONAL,
        t-ADVinfo
                                            T-ADVinfo
                                                                             OPTIONAL
}
UE-InternalMeasurement ::=
                                    SEQUENCE {
   ue-InternalMeasQuantity
                                        UE-InternalMeasQuantity
                                                                             OPTIONAL,
    ue-InternalReportingQuantity
                                        UE-InternalReportingQuantity
                                                                             OPTIONAL,
    reportCriteria
                                        UE-InternalReportCriteria
}
UE-InternalMeasurement-r4 ::=
                                    SEQUENCE {
    ue-InternalMeasQuantity
                                        UE-InternalMeasQuantity
                                                                             OPTIONAL.
    ue-InternalReportingQuantity
                                        UE-InternalReportingQuantity-r4
                                                                             OPTIONAL,
    reportCriteria
                                        UE-InternalReportCriteria
}
UE-InternalMeasurementSysInfo ::=
                                    SEQUENCE {
    ue-InternalMeasurementID
                                        MeasurementIdentity
                                                                     DEFAULT 5,
    ue-InternalMeasQuantity
                                        UE-InternalMeasQuantity
}
UE-InternalReportCriteria ::=
                                    CHOICE {
    ue-InternalReportingCriteria
                                        UE-InternalReportingCriteria,
   periodicalReportingCriteria
                                        PeriodicalReportingCriteria,
                                        NULL
    noReporting
}
```

```
{\tt UE-InternalReportingCriteria} ::= \qquad {\tt SEQUENCE} \ \{
   ue-InternalEventParamList UE-InternalEventParamList OPTIONAL
}
UE-InternalReportingQuantity ::= SEQUENCE {
   ue-TransmittedPower
                                     BOOLEAN,
                                      CHOICE {
   modeSpecificInfo
       fdd
                                      SEQUENCE {
         ue-RX-TX-TimeDifference
                                          BOOLEAN
       tdd
                                        SEQUENCE {
           appliedTA
                                             BOOLEAN
       }
   }
}
UE-InternalReportingQuantity-r4 ::= SEQUENCE {
   ue-TransmittedPower
   modeSpecificInfo
                                      CHOICE {
                                         SEQUENCE {
       fdd
           ue-RX-TX-TimeDifference
                                             BOOLEAN
       },
       t.dd
                                          SEQUENCE {
                                             CHOICE {
           tddOption
               tdd384
                                               SEQUENCE {
                 appliedTA
                                                    BOOLEAN
               tdd128
                                                 SEOUENCE {
                 t-ADVinfo
                                                     BOOLEAN
           }
       }
   }
}
-- TABULAR: UE-MeasurementQuantity, for 3.84 Mcps TDD only the first two values
-- ue-TransmittedPower and utra-Carrier-RSSI are used.
-- For 1.28 Mcps TDD ue-RX-TX-TimeDifference corresponds to T-ADV in the tabular
UE-MeasurementQuantity ::= ENUMERATED {
                                      ue-TransmittedPower,
                                      utra-Carrier-RSSI,
                                      ue-RX-TX-TimeDifference }
UE-RX-TX-ReportEntry ::= SEQUENCE {
                                  PrimaryCPICH-Info,
   primaryCPICH-Info
    ue-RX-TX-TimeDifferenceType1
                                     UE-RX-TX-TimeDifferenceType1
UE-RX-TX-ReportEntryList ::= SEQUENCE (SIZE (1..maxRL)) OF
                                     UE-RX-TX-ReportEntry
-- SPARE: UE-RX-TX-TimeDifferenceType1, Max = 1280
-- Values above Max are spare
UE-RX-TX-TimeDifferenceTypel ::= INTEGER (768..1791)
UE-RX-TX-TimeDifferenceType2 ::= INTEGER (0..8191)
UE-RX-TX-TimeDifferenceType2Info ::=
                                     SEQUENCE {
   ue-RX-TX-TimeDifferenceType2
                                      UE-RX-TX-TimeDifferenceType2,
   neighbourQuality
                                          NeighbourQuality
}
-- In 1.28 Mcps TDD, actual value for
-- T-ADV Threshold = (UE-RX-TX-TimeDifferenceThreshold - 768) * 0.125
UE-RX-TX-TimeDifferenceThreshold ::= INTEGER (768..1280)
UE-TransmittedPower ::=
                                  INTEGER (0..104)
UE-TransmittedPowerTDD-List ::= SEQUENCE (SIZE (1..maxTS)) OF
                                      UE-TransmittedPower
UL-TrCH-Identity ::=
                                      CHOICE {
                                      TransportChannelIdentity,
   dch
    -- Default transport channel in the UL is either RACH or CPCH, but not both.
    rachorcpch
                                      NULL,
    usch
                                      TransportChannelIdentity
```

```
}
UE-Positioning-Accuracy ::=
                                          BIT STRING (SIZE (7))
UE-Positioning-CipherParameters ::=
    cipheringKeyFlag
                                           SEQUENCE {
                                        BIT STRING (SIZE (1)),
                                       INTEGER (0..65535)
    cipheringSerialNumber
}
UE-Positioning-Error ::=
                                                SEQUENCE {
                                       UE-Positioning-ErrorCause,
    errorReason
    ue-positioning-GPS-additionalAssistanceDataRequest
                                                               UE-Positioning-GPS-
AdditionalAssistanceDataRequest OPTIONAL
}
UE-Positioning-ErrorCause ::=
                                                ENUMERATED {
                                        notEnoughOTDOA-Cells,
                                        notEnoughGPS-Satellites,
                                        assistanceDataMissing,
                                        notAccomplishedGPS-TimingOfCellFrames,
                                        undefinedError,
                                        requestDeniedByUser,
                                        notProcessedAndTimeout,
                                        referenceCellNotServingCell }
UE-Positioning-EventParam ::=
                                                SEQUENCE {
                                        ReportingAmount,
   reportingAmount
   reportFirstFix
                                        BOOLEAN,
   measurementInterval
                                        UE-Positioning-MeasurementInterval,
    eventSpecificInfo
                                        UE-Positioning-EventSpecificInfo
                                                SEQUENCE (SIZE (1..maxMeasEvent)) OF
UE-Positioning-EventParamList ::=
                                       UE-Positioning-EventParam
UE-Positioning-EventSpecificInfo ::=
                                                CHOICE {
                                        ThresholdPositionChange,
    e7a
    e7b
                                        ThresholdSFN-SFN-Change,
    e7c
                                        ThresholdSFN-GPS-TOW
}
{\tt UE-Positioning-GPS-AcquisitionAssistance} \; ::= \; \; \; {\tt SEQUENCE} \; \left\{ \right. \\
                            INTEGER (0..604799999),
UTRAN-GPSReferenceTime
    gps-ReferenceTime
    utran-GPSReferenceTime
                                                                       OPTIONAL,
    satelliteInformationList
                                      AcquisitionSatInfoList
}
UE-Positioning-GPS-AdditionalAssistanceDataRequest ::= SEQUENCE {
   almanacRequest
                          BOOLEAN,
   utcModelRequest
                                       BOOLEAN,
   ionosphericModelRequest
                                       BOOLEAN,
   navigationModelRequest
                                      BOOLEAN,
    dgpsCorrectionsRequest
                                       BOOLEAN,
                                      BOOLEAN,
   referenceLocationRequest
   referenceTimeRequest
                                       BOOLEAN,
    aquisitionAssistanceRequest
                                       BOOLEAN,
    realTimeIntegrityRequest
                                      BOOLEAN,
   navModelAddDataRequest
                                       UE-Positioning-GPS-NavModelAddDataReq OPTIONAL
}
UE-Positioning-GPS-Almanac ::=
                                                SEQUENCE {
                                    BIT STRING (SIZE (8)),
    almanacSatInfoList
                                        AlmanacSatInfoList,
    sv-GlobalHealth
                                        BIT STRING (SIZE (364))
                                                                          OPTIONAL
}
UE-Positioning-GPS-AssistanceData ::=
                                                SEQUENCE {
                                                    UE-Positioning-GPS-ReferenceTime
    ue-positioning-GPS-ReferenceTime
    OPTIONAL,
                                                ReferenceLocation
    ue-positioning-GPS-ReferenceLocation
                                                                                    OPTIONAL,
                                                    UE-Positioning-GPS-DGPS-Corrections
    ue-positioning-GPS-DGPS-Corrections
    OPTIONAL,
    ue-positioning-GPS-NavigationModel
                                                   UE-Positioning-GPS-NavigationModel
    OPTIONAL,
    ue-positioning-GPS-IonosphericModel
                                                   UE-Positioning-GPS-IonosphericModel
    OPTIONAL.
```

```
ue-positioning-GPS-UTC-Model
                                                  UE-Positioning-GPS-UTC-Model
    OPTIONAL,
   ue-positioning-GPS-Almanac
                                                  UE-Positioning-GPS-Almanac
   OPTIONAL,
   ue-positioning-GPS-AcquisitionAssistance
                                                  UE-Positioning-GPS-AcquisitionAssistance
   OPTIONAL,
   ue-positioning-GPS-Real-timeIntegrity
                                                  BadSatList
                                                                                      OPTIONAL.
    -- dummy is not used in this version of the specification, it should
    -- not be sent and if received it should be ignored.
                   UE-Positioning-GPS-ReferenceCellInfo
}
UE-Positioning-GPS-DGPS-Corrections ::=
                                         SEOUENCE {
                                      INTEGER (0..604799),
    statusHealth
                                       DiffCorrectionStatus,
   dgps-CorrectionSatInfoList
                                      DGPS-CorrectionSatInfoList
}
UE-Positioning-GPS-IonosphericModel ::=
                                          SEQUENCE {
                                       BIT STRING (SIZE (8)),
   alfa0
                                       BIT STRING (SIZE (8)),
   alfa1
    alfa2
                                       BIT STRING (SIZE (8)),
   alfa3
                                       BIT STRING (SIZE (8)),
                                       BIT STRING (SIZE (8)),
   beta0
                                       BIT STRING (SIZE (8)),
   beta1
   beta2
                                       BIT STRING (SIZE (8)),
   beta3
                                       BIT STRING (SIZE (8))
}
UE-Positioning-GPS-MeasurementResults ::=
                                               SEOUENCE {
   referenceTime
                                     CHOICE {
                                      UTRAN-GPSReferenceTimeResult,
       utran-GPSReferenceTimeResult
       gps-ReferenceTimeOnly
                                           INTEGER (0..604799999)
    gps-MeasurementParamList
                                     GPS-MeasurementParamList
}
UE-Positioning-GPS-NavigationModel ::=
                                              SEOUENCE {
   navigationModelSatInfoList
                                     NavigationModelSatInfoList
UE-Positioning-GPS-NavModelAddDataReq ::=
                                              SEQUENCE {
                                      INTEGER (0..1023),
    gps-Week
    -- SPARE: gps-Toe, Max = 167
    -- Values above Max are spare
   gps-Toe
                                       INTEGER (0..255),
    -- SPARE: tToeLimit, Max = 10
    -- Values above Max are spare
    tToeLimit
                                      INTEGER (0..15),
    satDataList
                                       SatDataList
}
UE-Positioning-GPS-ReferenceCellInfo ::=
                                             SEQUENCE {
                       CHOICE {
   modeSpecificInfo
                                      SEQUENCE {
       fdd
                                          PrimaryCPICH-Info
           referenceIdentity
        tdd
                                       SEQUENCE {
           referenceIdentity
                                         CellParametersID
        }
    }
UE-Positioning-GPS-ReferenceTime ::=
                                               SEOUENCE {
                                       INTEGER (0..1023),
   qps-Week
    gps-tow-1msec
                                       GPS-TOW-1msec, utran-GPSReferenceTime
                                                                                          UTRAN-
                              OPTIONAL,
GPSReferenceTime
   sfn-tow-Uncertainty
                                     SFN-TOW-Uncertainty
                                                                          OPTIONAL,
                                       UTRAN-GPS-DriftRate
    utran-GPS-DriftRate
                                                                          OPTIONAL.
   gps-TOW-AssistList
                                       GPS-TOW-AssistList
                                                                          OPTIONAL
UE-Positioning-GPS-UTC-Model ::=
                                              SEOUENCE {
   a1
                                       BIT STRING (SIZE (24)),
    a0
                                       BIT STRING (SIZE (32)),
                                      BIT STRING (SIZE (8)),
    t-ot
                                       BIT STRING (SIZE (8)),
    wn-t.
                                       BIT STRING (SIZE (8)),
    delta-t-LS
```

```
wn-lsf
                                        BIT STRING (SIZE (8)),
    dn
                                        BIT STRING (SIZE (8)),
    delta-t-LSF
                                        BIT STRING (SIZE (8))
}
UE-Positioning-IPDL-Parameters ::=
                                                SEQUENCE {
                                        IP-Spacing,
    ip-Spacing
    ip-Length
                                        IP-Length,
    ip-Offset
                                        INTEGER (0..9),
    seed
                                        INTEGER (0..63),
    burstModeParameters
                                        BurstModeParameters
                                                                    OPTIONAL
}
UE-Positioning-IPDL-Parameters-r4 ::=
                                                SEQUENCE {
    modeSpecificInfo
                                        CHOICE {
                                            SEQUENCE {
       fdd
            ip-Spacing
                                                IP-Spacing,
            ip-Length
                                                IP-Length,
            ip-Offset
                                                INTEGER (0..9),
                                                INTEGER (0..63)
            seed
        },
        tdd
                                            SEQUENCE {
            ip-Spacing-TDD
                                                IP-Spacing-TDD,
                                                INTEGER (0..14),
            ip-slot
                                                INTEGER (0..4095),
            ip-Start
            ip-PCCPCG
                                                IP-PCCPCH-r4
                                                                        OPTIONAL.
    burstModeParameters
                                       BurstModeParameters
                                                                        OPTIONAL
}
UE-Positioning-IPDL-Parameters-TDD-r4-ext ::= SEQUENCE {
                                        IP-Spacing-TDD,
    ip-Spacing
    ip-slot
                                        INTEGER (0..14)
    ip-Start
                                        INTEGER (0..4095),
    ip-PCCPCG
                                        IP-PCCPCH-r4
                                                                        OPTIONAL,
    burstModeParameters
                                       BurstModeParameters
}
UE-Positioning-MeasuredResults ::=
                                                SEQUENCE {
    ue-positioning-OTDOA-Measurement
                                                    UE-Positioning-OTDOA-Measurement
    OPTIONAL.
    ue-positioning-PositionEstimateInfo
                                                   UE-Positioning-PositionEstimateInfo
        OPTIONAL,
    ue-positioning-GPS-Measurement
                                                    UE-Positioning-GPS-MeasurementResults
       OPTIONAL,
    ue-positioning-Error
                                                    UE-Positioning-Error
    OPTIONAL
UE-Positioning-MeasuredResults-v390ext ::=
   -_ ...ue-Positioning-OTDOA-Measurement-v390ext
                                               SEOUENCE {
                                                  UE-Positioning-OTDOA-Measurement-v390ext
                                                SEQUENCE {
UE-Positioning-Measurement ::=
    ue-positioning-ReportingQuantity
                                                    UE-Positioning-ReportingQuantity,
    reportCriteria
                                       UE-Positioning-ReportCriteria,
    ue-positioning-OTDOA-AssistanceData
                                            UE-Positioning-OTDOA-AssistanceData
    OPTIONAL,
    ue-positioning-GPS-AssistanceData
                                                   UE-Positioning-GPS-AssistanceData
    OPTIONAL
   ue-positioning-ReportingQuantity-v390ext UE-PositionAL,
UE-Positioning-Measurement-v390ext ::=
                                                   UE-Positioning-ReportingQuantity-v390ext
                                       MeasurementValidity
    measurementValidity
    ue-positioning-OTDOA-AssistanceData-UEB
                                                   UE-Positioning-OTDOA-AssistanceData-UEB
    OPTIONAL
}
UE-Positioning-Measurement-r4 ::=
                                                SEQUENCE {
   ue-positioning-ReportingQuantity
                                                   UE-Positioning-ReportingQuantity-r4,
    measurementValidity
                                                    MeasurementValidity
    OPTIONAL,
    reportCriteria
                                                   UE-Positioning-ReportCriteria,
    ue-positioning-OTDOA-AssistanceData
                                                   UE-Positioning-OTDOA-AssistanceData-r4
    OPTIONAL.
```

```
ue-positioning-GPS-AssistanceData
                                                   UE-Positioning-GPS-AssistanceData
   OPTIONAL
}
UE-Positioning-MeasurementEventResults ::=
                                               CHOICE {
                                       UE-Positioning-PositionEstimateInfo,
                                       UE-Positioning-OTDOA-Measurement,
    event.7b
    event.7c
                                       UE-Positioning-GPS-MeasurementResults,
    spare
UE-Positioning-MeasurementInterval ::=
                                               ENUMERATED {
                                       e5, e15, e60, e300,
                                       e900, e1800, e3600, e7200 }
UE-Positioning-MethodType ::=
                                               ENUMERATED {
                                       ue-Assisted,
                                       ue-Based.
                                       ue-BasedPreferred,
                                       ue-AssistedPreferred }
                                         SEQUENCE {
UE-Positioning-OTDOA-AssistanceData ::=
                                           UE-Positioning-OTDOA-ReferenceCellInfo
    ue-positioning-OTDOA-ReferenceCellInfo
    OPTIONAL.
   ue-positioning-OTDOA-NeighbourCellList
                                                      UE-Positioning-OTDOA-NeighbourCellList
       OPTIONAL
}
UE-Positioning-OTDOA-AssistanceData-r4 ::= SEQUENCE {
   ue-positioning-OTDOA-ReferenceCellInfo
                                                  UE-Positioning-OTDOA-ReferenceCellInfo-r4
       OPTIONAL,
    ue-positioning-OTDOA-NeighbourCellList
                                                  UE-Positioning-OTDOA-NeighbourCellList-r4
       OPTIONAL
}
UE-Positioning-OTDOA-AssistanceData-r4ext ::= SEQUENCE \{
   -- In case of TDD these IPDL parameters shall be used for the reference cell instead of
    -- IPDL Parameters in IE UE-Positioning-OTDOA-ReferenceCellInfo
   ue-Positioning-IPDL-Parameters-TDD-r4-ext
                                                   UE-Positioning-IPDL-Parameters-TDD-r4-ext
   OPTIONAL,
    -- These IPDL parameters shall be used for the neighbour cells in case of TDD instead of
    -- IPDL Parameters in IE UE-Positioning-OTDOA-NeighbourCellInfoList. The cells shall be
    -- listed in the same order as in IE UE-Positioning-OTDOA-NeighbourCellInfoList
    ue-Positioning-IPDL-Parameters-TDDList-r4-ext UE-Positioning-IPDL-Parameters-TDDList-r4-ext
    OPTIONAL
}
UE-Positioning-OTDOA-AssistanceData-UEB ::= SEQUENCE {
                                               UE-Positioning-OTDOA-ReferenceCellInfo-UEB
   ue-positioning-OTDOA-ReferenceCellInfo-UEB
               OPTIONAL,
   ue-positioning-OTDOA-NeighbourCellList-UEB
                                                           UE-Positioning-OTDOA-NeighbourCellList-
UEB
               OPTIONAL
}
UE-Positioning-IPDL-Parameters-TDDList-r4-ext ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                           UE-Positioning-IPDL-Parameters-TDD-r4-ext
UE-Positioning-OTDOA-Measurement ::=
                                               SEQUENCE {
                                       INTEGER (0..4095),
    sfn
   modeSpecificInfo
                                   CHOICE {
        fdd
                                       SEQUENCE {
           referenceCellIDentity
                                               PrimaryCPICH-Info,
           ue-RX-TX-TimeDifferenceType2Info
                                               UE-RX-TX-TimeDifferenceType2Info
        },
                                           SEQUENCE {
        t.dd
           referenceCellIdentity
                                           CellParametersID
        }
    },
                                       NeighbourList
   neighbourList
                                                                           OPTIONAL
}
UE-Positioning-OTDOA-Measurement-v390ext ::=
                                                       SEQUENCE {
   neighbourList-v390ext
                                               NeighbourList-v390ext
UE-Positioning-OTDOA-NeighbourCellInfo ::= SEQUENCE {
   modeSpecificInfo CHOICE {
                                       SEOUENCE {
       fdd
```

```
primaryCPICH-Info
                                                PrimaryCPICH-Info
        tdd
                                        SEOUENCE {
            cellAndChannelIdentity
                                                CellAndChannelIdentity
        }
                                        FrequencyInfo
    frequencyInfo
                                                                            OPTIONAL.
    ue-positioning-IPDL-Paremeters
                                                    UE-Positioning-IPDL-Parameters
    OPTIONAL,
    sfn-SFN-RelTimeDifference
                                        SFN-SFN-RelTimeDifferencel,
    sfn-SFN-Drift
                                        SFN-SFN-Drift
                                                                            OPTIONAL,
                                        OTDOA-SearchWindowSize,
    searchWindowSize
    positioningMode
                       CHOICE {
                                                SEQUENCE {},
        ueBased
        ueAssisted
                                                SEQUENCE {}
}
UE-Positioning-OTDOA-NeighbourCellInfo-r4 ::= SEQUENCE {
    modeSpecificInfo CHOICE {
                                        SEQUENCE {
       fdd
            primaryCPICH-Info
                                                PrimaryCPICH-Info
        tdd
                                        SEQUENCE {
            cellAndChannelIdentity
                                                CellAndChannelIdentity
        }
    frequencyInfo
                                        FrequencyInfo
                                                                            OPTIONAL,
    ue-positioning-IPDL-Paremeters
                                        UE-Positioning-IPDL-Parameters-r4 OPTIONAL,
                                        SFN-SFN-RelTimeDifference1,
    sfn-SFN-RelTimeDifference
    sfn-Offset-Validity
                                        SFN-Offset-Validity
                                                                            OPTIONAL.
    sfn-SFN-Drift
                                        SFN-SFN-Drift
                                                                            OPTIONAL,
    searchWindowSize
                                        OTDOA-SearchWindowSize,
                      CHOICE {
    positioningMode
                                                SEQUENCE {
        ueBased
           relativeNorth
                                                INTEGER (-20000..20000)
                                                                                    OPTIONAL,
           relativeEast
                                                INTEGER (-20000..20000)
                                                                                    OPTIONAL,
           relativeAltitude
                                                INTEGER (-4000..4000)
                                                                                    OPTIONAL,
           fineSFN-SFN
                                                FineSFN-SFN
                                                                                    OPTIONAL,
            -- actual value roundTripTime = (IE value * 0.0625) + 876
            roundTripTime
                                                INTEGER (0.. 32766)
                                                                                    OPTIONAL
        }.
        ueAssisted
                                                SEQUENCE {}
}
UE-Positioning-OTDOA-NeighbourCellInfo-UEB ::= SEQUENCE {
    modeSpecificInfo CHOICE {
        fdd
                                        SEQUENCE {
           primaryCPICH-Info
                                                PrimaryCPICH-Info
        },
        tdd
                                        SEOUENCE {
            cellAndChannelIdentity
                                                CellAndChannelIdentity
        }
                                                                            OPTIONAL.
    frequencyInfo
                                        FrequencyInfo
    ue-positioning-IPDL-Paremeters
                                        UE-Positioning-IPDL-Parameters
                                                                            OPTIONAL,
    sfn-SFN-RelTimeDifference
                                        SFN-SFN-RelTimeDifference1,
    sfn-SFN-Drift
                                        SFN-SFN-Drift
                                                                            OPTIONAL,
    searchWindowSize
                                        OTDOA-SearchWindowSize.
                                        INTEGER (-20000..20000)
   relativeNorth
                                                                            OPTIONAL,
    relativeEast
                                        INTEGER (-20000..20000)
                                                                            OPTIONAL,
                                        INTEGER (-4000..4000)
    relativeAltitude
                                                                            OPTIONAL,
    fineSFN-SFN
                                        FineSFN-SFN.
    -- actual value roundTripTime = (IE value * 0.0625) + 876
    roundTripTime
                                        INTEGER (0..32766)
                                                                            OPTIONAL
}
UE-Positioning-OTDOA-NeighbourCellList ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                            UE-Positioning-OTDOA-NeighbourCellInfo
UE-Positioning-OTDOA-NeighbourCellList-r4 ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                                UE-Positioning-OTDOA-NeighbourCellInfo-r4
UE-Positioning-OTDOA-NeighbourCellList-UEB ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                            UE-Positioning-OTDOA-NeighbourCellInfo-UEB
UE-Positioning-OTDOA-Quality ::=
                                            SEQUENCE {
```

```
stdResolution
                                     BIT STRING (SIZE (2)),
   numberOfOTDOA-Measurements
                                      BIT STRING (SIZE (3)),
   stdOfOTDOA-Measurements
                                      BIT STRING (SIZE (5))
}
UE-Positioning-OTDOA-ReferenceCellInfo ::=
                                                  SEQUENCE {
                                      INTEGER (0..4095)
   OPTIONAL.
   modeSpecificInfo CHOICE {
       fdd
                                               SEQUENCE {
          primaryCPICH-Info
                                               PrimaryCPICH-Info
       }.
       tdd
                                               SEQUENCE {
           cellAndChannelIdentity
                                               CellAndChannelIdentity
       }
   frequencyInfo
                                     FrequencyInfo
                                                                         OPTIONAL.
   positioningMode CHOICE {
                                               SEQUENCE {},
       ueBased
       ueAssisted
                                               SEQUENCE {}
   },
   ue-positioning-IPDL-Paremeters
                                              UE-Positioning-IPDL-Parameters OPTIONAL
}
UE-Positioning-OTDOA-ReferenceCellInfo-r4 ::= SEQUENCE {
   sfn
                                      INTEGER (0..4095)
   OPTIONAL.
   modeSpecificInfo CHOICE {
       fdd
                                               SEQUENCE {
                                               PrimaryCPICH-Info
          primaryCPICH-Info
       tdd
                                               SEQUENCE {
           cellAndChannelIdentity
                                               CellAndChannelIdentity
       }
   frequencyInfo
                                      FrequencyInfo
                                                                          OPTIONAL,
   positioningMode CHOICE {
                                               SEQUENCE {
       ueBased
           cellPosition
                                                      ReferenceCellPosition OPTIONAL,
           -- actual value roundTripTime = (IE value * 0.0625) + 876
           roundTripTime
                                               INTEGER (0..32766)
                                                                              OPTIONAL
       },
                                               SEQUENCE {}
       ueAssisted
   ue-positioning-IPDL-Paremeters
                                             UE-Positioning-IPDL-Parameters-r4 OPTIONAL
}
UE-Positioning-OTDOA-ReferenceCellInfo-UEB ::=
                                                      SEQUENCE {
                                       INTEGER (0..4095)
                                                                          OPTIONAL,
   modeSpecificInfo CHOICE {
       fdd
                                               SEOUENCE {
                                               PrimaryCPICH-Info
          primaryCPICH-Info
                                               SEQUENCE {
       t.dd
           cellAndChannelIdentity
                                               CellAndChannelIdentity
       }
   frequencyInfo
                                       FrequencyInfo
                                                                          OPTIONAL,
   cellPosition
                                       ReferenceCellPosition
                                                                          OPTIONAL,
    -- actual value roundTripTime = (IE value * 0.0625) + 876
                                       INTEGER (0..32766)
   roundTripTime
                                                                          OPTIONAL,
                                      UE-Positioning-IPDL-Parameters
   ue-positioning-IPDL-Paremeters
                                                                          OPTIONAL
}
                                                     SEQUENCE {
UE-Positioning-PositionEstimateInfo ::=
   referenceTime
                                  CHOICE {
       utran-GPSReferenceTimeResult
                                           UTRAN-GPSReferenceTimeResult,
       gps-ReferenceTimeOnly
                                           INTEGER (0..604799999),
                                           SEQUENCE {
       cell-Timing
                                                       INTEGER (0..4095),
           sfn
                                           CHOICE {
           modeSpecificInfo
               fdd
                                                   SEQUENCE {
                   primaryCPICH-Info
                                                      PrimaryCPICH-Info
               tdd
                                                   SEQUENCE {
                   cellAndChannelIdentity
                                                      CellAndChannelIdentity
               }
           }
```

```
positionEstimate
                                       PositionEstimate
}
UE-Positioning-ReportCriteria ::=
    Positioning-ReportingCriteria UE-Positioning Lee-positioning-ReportingCriteria PeriodicalReportingCriteria,
                                                CHOICE {
                                                    UE-Positioning-EventParamList,
    noReporting
                                        NULL
UE-Positioning-ReportingQuantity ::=
  methodType
  positioningMethod
                                                 SEQUENCE {
                                        UE-Positioning-MethodType,
                                        PositioningMethod,
    -- dummyl is not used in this version of specification and it should
    -- be ignored.
                                         UE-Positioning-ResponseTime,
    dummv1
   norizontal-Accuracy
gps-TimingOfCellWanted
                                         UE-Positioning-Accuracy
                                                                             OPTIONAL,
                                        BOOLEAN,
    -- dummy2 is not used in this version of specification and it should
    -- be ignored.
    dummy2
                                        BOOLEAN,
    dummy2
additionalAssistanceDataRequest BOOLEAN,
EnvironmentCharacterisation OPTIONAL
}
UE-Positioning-ReportingQuantity-v390ext ::=
                                                    SEQUENCE {
   vertical-Accuracy
                                                 UE-Positioning-Accuracy
UE-Positioning-ReportingQuantity-r4 ::=
                                                 SEQUENCE {
                                      UE-Positioning-MethodType,
   methodType
    positioningMethod
                                         PositioningMethod,
   horizontalAccuracy
                                                                             OPTIONAL.
                                        UE-Positioning-Accuracy
    verticalAccuracy
                                        UE-Positioning-Accuracy
                                                                             OPTIONAL,
    gps-TimingOfCellWanted
                                        BOOLEAN,
    additionalAssistanceDataReq BOOLEAN,
environmentCharacterisation EnvironmentCharacterisation OPTIONAL
UE-Positioning-ResponseTime ::=
                                            ENUMERATED {
                                        s1, s2, s4, s8, s16,
                                         s32, s64, s128 }
-- SPARE: UTRA-CarrierRSSI, Max = 76
-- Values above Max are spare
                                    INTEGER (0..127)
UTRA-CarrierRSSI ::=
UTRAN-GPS-DriftRate ::=
                                    ENUMERATED {
                                     utran-GPSDrift0, utran-GPSDrift1, utran-GPSDrift2,
                                     utran-GPSDrift5, utran-GPSDrift10, utran-GPSDrift15,
                                     utran-GPSDrift25, utran-GPSDrift50, utran-GPSDrift-1,
                                     utran-GPSDrift-2, utran-GPSDrift-5, utran-GPSDrift-10,
                                     utran-GPSDrift-15, utran-GPSDrift-25, utran-GPSDrift-50}
                                        SEQUENCE {
UTRAN-GPSReferenceTime ::=
    -- For utran-GPSTimingOfCell values above 2322431999999 are not
    -- used in this version of the specification
    -- Actual value utran-GPSTimingOfCell = (ms-part * 4294967296) + ls-part
    utran-GPSTimingOfCell SEQUENCE {
        ms-part
                                        INTEGER (0..1023),
        ls-part
                                         INTEGER (0..4294967295)
    },
    modeSpecificInfo
                                     CHOICE {
                                        SEQUENCE {
           referenceIdentity
                                           PrimaryCPICH-Info
        tdd
                                       SEQUENCE {
                                           CellParametersID
           referenceIdentity
                    OPTIONAL,
    sfn
                                         INTEGER (0..4095)
}
UTRAN-GPSReferenceTimeResult ::=
                                                 SEQUENCE {
    -- For ue-GPSTimingOfCell values above 37158911999999 are not
    -- used in this version of the specification
    -- Actual value ue-GPSTimingOfCell = (ms-part * 4294967296) + ls-part
```

```
ue-GPSTimingOfCell SEQUENCE {
                                      INTEGER (0.. 16383),
       ms-part
                                      INTEGER (0..4294967295)
       ls-part
   modeSpecificInfo
                                  CHOICE {
                                    SEQUENCE {
                                        PrimaryCPICH-Info
           referenceIdentity
       },
       tdd
                                    SEQUENCE {
          referenceIdentity
                                        CellParametersID
   },
                                      INTEGER (0..4095)
   sfn
}
                                 ENUMERATED {
VarianceOfRLC-BufferPayload ::=
                                      plv0, plv4, plv8, plv16, plv32, plv64,
                                      plv128, plv256, plv512, plv1024,
                                      plv2k, plv4k, plv8k, plv16k, spare2, spare1 }
-- Actual value W = IE value * 0.1
                                  INTEGER (0..20)
__ *****************
      OTHER INFORMATION ELEMENTS (10.3.8)
__ **************
                                  INTEGER (0..7)
BCC ::=
BCCH-ModificationInfo ::=
                                   MIB-ValueTag,
   mib-ValueTag
   bcch-ModificationTime
                                                                       OPTIONAL
                                      BCCH-ModificationTime
}
-- Actual value BCCH-ModificationTime = IE value * 8
BCCH-ModificationTime ::=
                                  INTEGER (0..511)
BSIC ::=
                                  SEQUENCE {
                                      NCC,
                                      BCC
   bcc
}
CBS-DRX-LevellInformation ::= SEQUENCE {
    ctch-AllocationPeriod INTEGE
   ctch-AllocationPeriod
                                      INTEGER (1..256),
                                      INTEGER (0..255)
   cbs-FrameOffset
}
CDMA2000-Message ::=
                                 SEQUENCE {
                                      BIT STRING (SIZE (8)),
   msg-Type
                                      BIT STRING (SIZE (1..512))
   payload
CDMA2000-MessageList ::=
                                      SEQUENCE (SIZE (1..maxInterSysMessages)) OF
                                          CDMA2000-Message
CDMA2000-UMTS-Frequency-List ::=
                                      SEQUENCE (SIZE (1..maxNumCDMA2000Freqs)) OF
                                          FrequencyInfoCDMA2000
                                      INTEGER (1..4)
CellValueTag ::=
--Actual value = 2^(IE value)
ExpirationTimeFactor ::=
                                      INTEGER (1..8)
FDD-UMTS-Frequency-List ::=
                                      SEQUENCE (SIZE (1..maxNumFDDFreqs)) OF
                                          FrequencyInfoFDD
                                      SEQUENCE {
FrequencyInfoCDMA2000 ::=
                                          band-Class BIT STRING (SIZE (5)),
cdma-Freq BIT STRING (SIZE(11))
}
GERAN-SystemInfoBlock ::=
                                      OCTET STRING (SIZE (1..23))
GERAN-SystemInformation ::=
                                      SEQUENCE (SIZE (1..maxGERAN-SI)) OF GERAN-SystemInfoBlock
GSM-BA-Range ::=
                                      SEQUENCE {
```

```
gsmLowRangeUARFCN
                                                                   UARFCN,
                                            gsmUpRangeUARFCN
                                                                   UARFCN
}
                                       SEQUENCE (SIZE (1..maxNumGSMFreqRanges)) OF
GSM-BA-Range-List ::=
                                           GSM-BA-Range
-- This IE is formatted as 'TLV' and is coded in the same way as the Mobile Station Classmark 2
-- information element in [5]. The first octet is the Mobile station classmark 2 IEI and its value
-- shall be set to 33H. The second octet is the Length of mobile station classmark 2 and its value
-- shall be set to 3. The octet 3 contains the first octet of the value part of the Mobile Station
-- Classmark 2 information element, the octet 4 contains the second octet of the value part of the
-- Mobile Station Classmark 2 information element and so on. For each of these octets, the first/
-- leftmost/ most significant bit of the octet contains b8 of the corresponding octet of the Mobile
-- Station Classmark 2.
GSM-Classmark2 ::=
                                   OCTET STRING (SIZE (5))
-- This IE is formatted as 'V' and is coded in the same way as the value part in the Mobile station
-- classmark 3 information element in [5]
-- The value part is specified by means of CSN.1, which encoding results in a bit string, to which
-- final padding may be appended upto the next octet boundary [5]. The first/ leftmost bit of the
-- CSN.1 bit string is placed in the first/ leftmost/ most significant bit of the first
-- octet. This continues until the last bit of the CSN.1 bit string, which is placed in the last/
-- rightmost/ least significant bit of the last octet.
GSM-Classmark3 ::=
                                   OCTET STRING (SIZE (1..32))
                                   SEQUENCE (SIZE (1..maxInterSysMessages)) OF
GSM-MessageList ::=
                                       BIT STRING (SIZE (1..512))
GsmSecurityCapability ::=
                                   BIT STRING {
                                       -- For each bit value '0' means false/ not supported
                                        a5-7(0),
                                       a5-6(1).
                                        a5-5(2),
                                        a5-4(3),
                                       a5-3(4),
                                        a5-2(5),
                                       a5-1(6)
                                          (SIZE (7))
IdentificationOfReceivedMessage ::= SEQUENCE {
       rrc-TransactionIdentifier RRC-TransactionIdentifier,
       receivedMessageType
                                       ReceivedMessageType
}
InterRAT-ChangeFailureCause ::= CHOICE {
                                   NULL,
    configurationUnacceptable
    physicalChannelFailure
                                       NULL.
   protocolError
                                       ProtocolErrorInformation,
   unspecified
                                       NULL,
    spare4
                                       NIII.I.
    spare3
                                       NULL,
    spare2
                                       NULL.
    spare1
                                       NULL
}
GERANIu-MessageList ::=
                                  SEQUENCE (SIZE (1..maxInterSysMessages)) OF
                                       BIT STRING (SIZE (1..32768))
GERANIu-RadioAccessCapability ::= BIT STRING (SIZE (1..170))
InterRAT-UE-RadioAccessCapability ::= CHOICE {
                                       SEQUENCE {
   asm
                                           GSM-Classmark2,
        qsm-Classmark2
       gsm-Classmark3
                                           GSM-Classmark3
    cdma2000
                                       SEQUENCE {
       cdma2000-MessageList
                                           CDMA2000-MessageList
}
InterRAT-UE-RadioAccessCapabilityList ::= SEQUENCE (SIZE(1..maxInterSysMessages)) OF
                                           InterRAT-UE-RadioAccessCapability
InterRAT-UE-RadioAccessCapability-v590ext ::= SEQUENCE {
   geranIu-RadioAccessCapability GERANIu-RadioAccessCapability
```

```
InterRAT-UE-SecurityCapability ::= CHOICE {
                                         SEQUENCE {
   asm
        gsmSecurityCapability
                                         {\tt GsmSecurityCapability}
}
                                    SEQUENCE (SIZE(1..maxInterSysMessages)) OF
InterRAT-UE-SecurityCapList ::=
                                        InterRAT-UE-SecurityCapability
InterRAT-HO-FailureCause ::=
                                    CHOICE {
    configurationUnacceptable
                                        NULL.
    physicalChannelFailure
                                        NIII.I.
    protocolError
                                        ProtocolErrorInformation,
    interRAT-ProtocolError
                                        NULL,
   unspecified
                                        NULL,
    spare11
                                        NIII.I.
    spare10
                                        NULL.
    spare9
                                        NULL,
    spare8
                                        NULL,
    spare7
                                        NULL.
    spare6
                                        NULL,
    spare5
                                        NULL,
    spare4
                                        NULL,
                                        NULT.
    spare3
    spare2
                                        NULL.
    spare1
                                        NULL
}
MasterInformationBlock ::=
                                  SEQUENCE {
        mib-ValueTag
                                        MIB-ValueTag,
        -- TABULAR: The PLMN identity and ANSI-41 core network information
        -- are included in PLMN-Type.
                                        PLMN-Type,
        plmn-Type
        sibSb-ReferenceList
                                        SIBSb-ReferenceList,
    -- Extension mechanism for non- release99 information
                                                                             OPTIONAL
       nonCriticalExtensions
                                       SEQUENCE {}
}
MIB-ValueTag ::=
                                    INTEGER (1..8)
NCC ::=
                                    INTEGER (0..7)
PLMN-ValueTag ::=
                                    INTEGER (1..256)
{\tt PredefinedConfigIdentityAndValueTag} ::= {\tt SEQUENCE} \ \{
    predefinedConfigIdentity
                                            PredefinedConfigIdentity,
    predefinedConfigValueTag
                                            PredefinedConfigValueTag
}
ProtocolErrorInformation ::=
                                    SEOUENCE {
    diagnosticsType
                                      CHOICE {
                                            SEQUENCE {
        type1
            protocolErrorCause
                                                 ProtocolErrorCause
        },
        spare
                                            NULL
}
                                    ENUMERATED {
ReceivedMessageType ::=
                                         activeSetUpdate,
                                         cellChangeOrderFromUTRAN,
                                         cellUpdateConfirm,
                                         counterCheck,
                                         downlinkDirectTransfer,
                                         interRATHandoverCommand,
                                         measurementControl,
                                         pagingType2,
                                         physicalChannelReconfiguration,
                                         physicalSharedChannelAllocation,
                                         radioBearerReconfiguration,
                                        radioBearerRelease,
                                         radioBearerSetup,
                                         rrcConnectionRelease,
                                         rrcConnectionReject,
                                         rrcConnectionSetup.
                                         securityModeCommand,
```

```
signallingConnectionRelease,
                                             transportChannelReconfiguration,
                                             transportFormatCombinationControl,
                                             ueCapabilityEnquiry,
                                             ueCapabilityInformationConfirm,
                                             uplinkPhysicalChannelControl,
                                             uraUpdateConfirm,
                                             {\tt utranMobilityInformation,}
                                             assistanceDataDelivery,
                                             spare6, spare5, spare4, spare3, spare2,
                                             spare1
}
Rplmn-Information ::=
                                             SEQUENCE {
                                                 gsm-BA-Range-List
                                                                            GSM-BA-Range-List OPTIONAL,
                                                  fdd-UMTS-Frequency-List FDD-UMTS-Frequency-List
    OPTIONAL.
                                                  tdd-UMTS-Frequency-List TDD-UMTS-Frequency-List
    OPTIONAL,
                                                 cdma2000-UMTS-Frequency-List CDMA2000-UMTS-Frequency-
        OPTIONAL
List
Rplmn-Information-r4 ::= SEQUENCE {
   gsm-BA-Range-List GSM-BA-Range-List
   fdd-UMTS-Frequency-List FDD-UMTS-Frequency-List
                                                                                     OPTIONAL.
                                                                                     OPTIONAL,
    tdd-UMTS-Frequency-List FDD-UMTS-Frequency-List tdd384-UMTS-Frequency-List TDD-UMTS-Frequency-List tdd128-UMTS-Frequency-List TDD-UMTS-Frequency-List cdma2000-UMTS-Frequency-List CDMA2000-UMTS-Frequency-List
                                                                                     OPTIONAL,
                                                                                     OPTIONAL,
                                                                                OPTIONAL
}
SchedulingInformation ::=
                                        SEQUENCE {
    scheduling
                                             SEQUENCE {
         segCount.
                                                                                       DEFAULT 1.
                                                 SegCount
         sib-Pos
                                                 CHOICE {
             -- The element name indicates the repetition period and the value
             -- (multiplied by two) indicates the position of the first segment.
                                                      INTEGER (0..1),
             rep4
                                                      INTEGER (0..3),
             rep8
             rep16
                                                      INTEGER (0..7),
             rep32
                                                      INTEGER (0..15),
             rep64
                                                      INTEGER (0..31),
             rep128
                                                      INTEGER (0..63),
             rep256
                                                      INTEGER (0..127),
             rep512
                                                      INTEGER (0..255),
             rep1024
                                                      INTEGER (0..511),
                                                      INTEGER (0..1023),
             rep2048
             rep4096
                                                      INTEGER (0..2047)
         sib-PosOffsetInfo
                                                 SibOFF-List
                                                                                     OPTIONAL
    }
}
SchedulingInformationSIB ::=
                                             SEQUENCE {
                                             SIB-TypeAndTag,
    sib-Type
    scheduling
                                             SchedulingInformation
SchedulingInformationSIBSb ::=
                                            SEQUENCE {
    sibSb-Type
                                             SIBSb-TypeAndTag,
                                             SchedulingInformation
    scheduling
}
                                        INTEGER (1..16)
SegCount ::=
SegmentIndex ::=
                                        INTEGER (1..15)
-- Actual value SFN-Prime = 2 * IE value
SFN-Prime ::=
                                        INTEGER (0..2047)
SIB-Data-fixed ::=
                                        BIT STRING (SIZE (222))
SIB-Data-variable ::=
                                        BIT STRING (SIZE (1..214))
                                  INTEGER (0..15)
SIBOccurIdentity ::=
```

```
SIBOccurrenceIdentityAndValueTag ::= SEQUENCE {
    sibOccurIdentity
                                    SIBOccurIdentity,
    sibOccurValueTag
                                    SIBOccurValueTag
}
SIBOccurValueTag ::=
                               INTEGER (0..15)
                                    SEQUENCE (SIZE (1..maxSIB)) OF
SIB-ReferenceList ::=
                                        SchedulingInformationSIB
SIBSb-ReferenceList ::=
                                   SEQUENCE (SIZE (1..maxSIB)) OF
                                        SchedulingInformationSIBSb
SIB-ReferenceListFACH ::=
                                    SEQUENCE (SIZE (1..maxSIB-FACH)) OF
                                        SchedulingInformationSIB
                                    ENUMERATED {
SIB-Type ::=
                                        masterInformationBlock,
                                        systemInformationBlockType1,
                                        systemInformationBlockType2,
                                        systemInformationBlockType3,
                                        systemInformationBlockType4,
                                        systemInformationBlockType5,
                                        systemInformationBlockType6,
                                        systemInformationBlockType7,
                                        systemInformationBlockType8,
                                        systemInformationBlockType9,
                                        systemInformationBlockType10,
                                        systemInformationBlockTypel1,
                                        systemInformationBlockType12,
                                        systemInformationBlockType13,
                                        systemInformationBlockType13-1,
                                        systemInformationBlockType13-2,
                                        systemInformationBlockType13-3,
                                        systemInformationBlockType13-4,
                                        systemInformationBlockType14,
                                        systemInformationBlockType15,
                                        systemInformationBlockType15-1,
                                        systemInformationBlockType15-2,
                                        systemInformationBlockType15-3,
                                        systemInformationBlockType16,
                                        systemInformationBlockType17,
                                        systemInformationBlockType15-4,
                                        systemInformationBlockType18,
                                        schedulingBlock1,
                                        schedulingBlock2,
                                        systemInformationBlockType15-5,
                                        spare1, spare2 }
SIB-TypeAndTag ::=
                                    CHOICE {
                                        PLMN-ValueTag,
    svsInfoTvpe1
                                        CellValueTag,
    sysInfoType2
    sysInfoType3
                                        CellValueTag,
    sysInfoType4
                                        CellValueTag,
    sysInfoType5
                                        CellValueTag,
                                        CellValueTag,
    sysInfoType6
    sysInfoType7
                                        NULL,
    sysInfoType8
                                        CellValueTag,
    sysInfoType9
                                        NULL,
    sysInfoType10
                                        NULT.
    sysInfoType11
                                        CellValueTag,
    sysInfoType12
                                        CellValueTag,
    sysInfoType13
                                        CellValueTag,
    sysInfoType13-1
                                        CellValueTag,
    sysInfoType13-2
                                        CellValueTag,
    sysInfoType13-3
                                        CellValueTag,
                                        CellValueTag,
    sysInfoType13-4
    sysInfoType14
                                        NULL,
                                        CellValueTag,
    sysInfoType15
    sysInfoType16
                                        PredefinedConfigIdentityAndValueTag,
    sysInfoType17
    sysInfoType15-1
                                        CellValueTag,
    sysInfoType15-2
                                        SIBOccurrenceIdentityAndValueTag,
                                        SIBOccurrenceIdentityAndValueTag,
    sysInfoType15-3
    sysInfoType15-4
                                        CellValueTag,
                                        CellValueTag,
    sysInfoType18
    sysInfoType15-5
                                        CellValueTag,
    spare5
                                        NULL,
```

```
spare4
                                           NULL,
                                           NULL,
    spare3
    spare2
                                           NULL,
                                           NULL
    spare1
SIBSb-TypeAndTag ::=
                                           CHOICE {
                                           PLMN-ValueTag,
    sysInfoType1
    sysInfoType2
                                           CellValueTag,
    sysInfoType3
                                           CellValueTag,
    sysInfoType4
                                           CellValueTag,
                                           CellValueTag,
    sysInfoType5
    sysInfoType6
                                           CellValueTag,
    sysInfoType7
                                           NULL,
    sysInfoType8
                                           CellValueTag,
    sysInfoType9
                                           NULL,
    sysInfoType10
                                           NULL,
    sysInfoType11
                                           CellValueTag,
                                           CellValueTag,
    sysInfoType12
                                           CellValueTag,
    sysInfoType13
    sysInfoType13-1
                                           CellValueTaq,
    sysInfoType13-2
                                           CellValueTag,
    sysInfoType13-3
                                           CellValueTag,
                                           CellValueTag,
    sysInfoType13-4
                                           NIII.I.
    svsInfoTvpe14
    sysInfoType15
                                           CellValueTag,
    sysInfoType16
                                           PredefinedConfigIdentityAndValueTag,
    sysInfoType17
    sysInfoTypeSB1
                                           CellValueTag,
                                           CellValueTag,
    sysInfoTypeSB2
    sysInfoType15-1
                                           CellValueTag,
                                           SIBOccurrenceIdentityAndValueTag,
    sysInfoType15-2
    sysInfoType15-3
                                           SIBOccurrenceIdentityAndValueTag,
    sysInfoType15-4
                                           CellValueTag,
    sysInfoType18
                                           CellValueTag,
                                           CellValueTag,
    sysInfoType15-5
    spare3
                                           NULL,
    spare2
                                           NULL,
    spare1
                                           NULL
SibOFF ::=
                                       ENUMERATED {
                                           so2, so4, so6, so8, so10,
                                            so12, so14, so16, so18,
                                            so20, so22, so24, so26,
                                           so28, so30, so32 }
SibOFF-List ::=
                                       SEQUENCE (SIZE (1..15)) OF
                                           SibOFF
                                       SEQUENCE {
SysInfoType1 ::=
    -- Core network IEs
        cn-CommonGSM-MAP-NAS-SysInfo NAS-SystemInformationGSM-MAP,
        cn-DomainSysInfoList
                                           CN-DomainSysInfoList,
    -- User equipment IEs
                                                                                 OPTIONAL,

    ue-ConnTimersAndConstants
    UE-ConnTimersAndConstants

    ue-IdleTimersAndConstants
    UE-IdleTimersAndConstants

                                                                                  OPTIONAL,
    -- Extension mechanism for non- release99 information
        v3a0NonCriticalExtensions SEQUENCE {
   sysInfoType1-v3a0ext SysInfoType1-v3a0ext-IEs,
   nonCriticalExtensions SEQUENCE {} OPTIONAL
                                      OPTIONAL
}
SysInfoType1-v3a0ext-IEs ::= SEQUENCE {
    ue-ConnTimersAndConstants-v3a0ext
                                                UE-ConnTimersAndConstants-v3a0ext,
    ue-IdleTimersAndConstants-v3a0ext
                                                UE-IdleTimersAndConstants-v3a0ext
}
SysInfoType2 ::=
                                      SEQUENCE {
    -- UTRAN mobility IEs
        ura-IdentityList
                                           URA-IdentityList,
    -- Extension mechanism for non- release99 information
        nonCriticalExtensions
                                           SEQUENCE {}
                                                                                   OPTIONAL
}
SysInfoType3 ::=
                                       SEOUENCE {
        sib4indicator
                                           BOOLEAN,
```

```
CellIdentity,
cellSelectReselectInfo
cellAccessRestriction
CellAccessPestriction
CellAccessPestriction
     -- UTRAN mobility IEs
     -- Extension mechanism for non- release99 information
         v4b0NonCriticalExtensions SEQUENCE {
             sysInfoType3-v4b0ext SysInfoType3-v4b0ext-IEs,
v590NonCriticalExtension SEQUENCE {
   sysInfoType3-v590ext SysInfoType3-v590ext,
   nonCriticalExtensions SEQUENCE {}
}
OPTIONAL
                                                                                              OPTIONAL
         }
}
SysInfoType3-v4b0ext-IEs ::= SEQUENCE {
    mapping-LCR
                                         Mapping-LCR-r4
                                                                                          OPTIONAL
SysInfoType3-v590ext ::= SEQUENCE {
    cellSelectReselectInfo-v590ext
                                              CellSelectReselectInfo-v590ext
                                                                                        OPTIONAL
SysInfoType4 ::=
                                        SEQUENCE {
     -- UTRAN mobility IEs
                                              CellIdentity,
         cellIdentity
         cellSelectReselectInfo
cellAccessRestriction
                                              CellSelectReselectInfoSIB-3-4,
                                             CellAccessRestriction,
     -- Extension mechanism for non- release99 information
         v4b0NonCriticalExtensions SEQUENCE {
    sysInfoType4-v4b0ext SysInfoType4-v4b0ext-IEs,
    v590NonCriticalExtension SEQUENCE {
        sysInfoType4-v590ext SysInfoType4-v590ext,
        nonCriticalExtensions SEQUENCE {}
                                                                                               OPTIONAL
                  OPTIONAL
              OPTIONAL
}
SysInfoType4-v4b0ext-IEs ::= SEQUENCE {
    mapping-LCR
                                          Mapping-LCR-r4
                                                                                          OPTIONAL
}
SysInfoType4-v590ext ::= SEQUENCE {
    cellSelectReselectInfo-v590ext
                                              CellSelectReselectInfo-v590ext OPTIONAL
SysInfoType5 ::=
                                        SEQUENCE {
         sib6indicator
                                            BOOLEAN,
     -- Physical channel IEs
        pich-PowerOffset
                                             PICH-PowerOffset,
         modeSpecificInfo
                                              CHOICE {
                                                 SEQUENCE {
             fdd
                   aich-PowerOffset
                                                        AICH-PowerOffset
                                                   SEQUENCE {
              tdd
    -- If PDSCH/PUSCH is configured for 1.28Mcps TDD, the following IEs should be absent
    -- and the info included in the tdd128SpecificInfo\ instead.
    -- If PDSCH/PUSCH is configured for 3.84Mcps TDD in R5, HCR-r5-SpecificInfo should also be
    -- included.
                  pusch-SysInfoList-SFN
                                                        PUSCH-SysInfoList-SFN
                                                                                         OPTIONAL.
                  pdsch-SysInfoList-SFN
                                                        PDSCH-SysInfoList-SFN
                                                                                          OPTIONAL,
                  openLoopPowerControl-TDD
                                                        OpenLoopPowerControl-TDD
              }
         },
         primaryCCPCH-Info
                                              PrimaryCCPCH-Info
                                                                                          OPTIONAL.
         prach-SystemInformationList PRACH-SystemInformationList, sCCPCH-SystemInformationList, SCCPCH-SystemInformationList,
         prach-SystemInformationList
         -- cbs-DRX-LevellInformation is conditional on any of the CTCH indicator IEs in
         -- sCCPCH-SystemInformationList
         cbs-DRX-LevellInformation
                                              CBS-DRX-LevellInformation
                                                                                        OPTIONAL,
     -- Extension mechanism for non- release99 information
         v4b0NonCriticalExtensions SEQUENCE {
    sysInfoType5-v4b0ext SysInf
                                                SysInfoType5-v4b0ext-IEs
                                                                                        OPTIONAL,
         -- Extension mechanism for non- rel-4 information
             v590NonCriticalExtensions SEQUENCE {
    sysInfoType5-v590ext
    nonCriticalExtensions SE(
    OPTIONAL
                                                        SysInfoType5-v590ext-IEs OPTIONAL,
                                                        SEQUENCE {}
                                                                                              OPTIONAL
              }
```

```
}
                                                          OPTIONAL
}
SysInfoType5-v4b0ext-IEs ::= SEQUENCE {
       -- The following IE PNBSCH-Allocation-r4 shall be used for 3.84Mcps TDD only.
      pNBSCH-Allocation-r4 PNBSCH-Allocation-r4 OPTIONAL,
      -- In case of TDD, the following IE is included instead of the
      -- IE up-IPDL-Parameter in up-OTDOA-AssistanceData.
      openLoopPowerControl-IPDL-TDD OpenLoopPowerControl-IPDL-TDD-r4 OPTIONAL,
-- If SysInfoType5 is sent to describe a 1.28Mcps TDD cell, the IE PRACH-RACH-Info included in
-- PRACH-SystemInformationList shall be ignored, the IE PRACH-Partitioning and the
-- IE rach-TransportFormatSet shall be absent and the corresponding IE in the following
-- PRACH-SystemInformationList-LCR-r4 shall be used
      prach-SystemInformationList-LCR-r4 PRACH-SystemInformationList-LCR-r4 OPTIONAL,
      tdd128SpecificInfo
                                                  SEQUENCE {
             pusch-SysInfoList-SFN PUSCH-SysInfoList-SFN-LCR-r4 OPTIONAL, pdsch-SysInfoList-SFN PDSCH-SysInfoList-SFN-LCR-r4 OPTIONAL, pCCPCH-LCR-Extensions PrimaryCCPCH-Info-LCR-r4-ext OPTIONAL, sCCPCH-LCR-ExtensionsList SCCPCH-SystemInformationList-LCR-r4-ext
                                                                                                                OPTIONAL.
                                                         RadioFrequencyBandFDDSpare
      frequencyBandIndicator
                                                                                                                 OPTIONAL
SysInfoType5-v590ext-IEs ::= SEQUENCE {
                                         SEQUENCE {
      hcr-r5-SpecificInfo
                                                         PUSCH-SysInfoList-SFN-HCR-r5
             pusch-SysInfoList-SFN
                                                                                                                        OPTIONAL,
             pdsch-SysInfoList-SFN
                                                                 PDSCH-SysInfoList-SFN-HCR-r5
                                                                                                                        OPTIONAL
}
SysInfoType6 ::=
                                                           SEQUENCE {
      -- Physical channel IEs
             pich-PowerOffset
                                                                 PICH-PowerOffset,
                         aich-PowerOffset SEQUENCE {
aich-powerOffset Transfer August 1
             modeSpecificInfo
                    fdd
                                                                           AICH-PowerOffset,
                          -- dummy is not used in this version of specification, it should
                           -- not be sent and if received it should be ignored.
                                                                               CSICH-PowerOffset
                    },
                                                                        SEQUENCE {
                    tdd
                          -- If PDSCH/PUSCH is configured for 1.28Mcps TDD, pusch-SysInfoList-SFN,
                          -- pdsch-SysInfoList-SFN and openLoopPowerControl-TDD should be absent
                          -- and the info included in the tdd128SpecificInfo instead.
                           -- If PDSCH/PUSCH is configured for 3.84 \text{Mcps} TDD in R5, HCR-r5-SpecificInfo should
                           -- also be included.
                                                                               PUSCH-SysInfoList-SFN
                          pusch-SysInfoList-SFN
                                                                                                                              OPTIONAL.
                          pdsch-SysInfoList-SFN
                                                                             PDSCH-SysInfoList-SFN
                                                                                                                              OPTIONAL,
                          openLoopPowerControl-TDD
                                                                               OpenLoopPowerControl-TDD
                   }
             },
            primaryCCPCH-Info PrimaryCCPCH-Info OPTIONAL, prach-SystemInformationList PRACH-SystemInformationList OPTIONAL, sCCPCH-SystemInformationList SCCPCH-SystemInformationList OPTIONAL, cbs-DRX-LevellInformation CBS-DRX-LevellInformation OPTIONAL, -- Conditional on any of the CREST CREST
             -- Conditional on any of the CTCH indicator IEs in
             -- sCCPCH-SystemInformationList
       -- Extension mechanism for non- release99 information
             v4b0NonCriticalExtensions SEQUENCE {
   sysInfoType6-v4b0ext SysInfoType6-v4b0ext-IEs OPTIONAL,
             -- Extension mechanism for non- rel-4 information
                   v590NonCriticalExtensions SEQUENCE {
    sysInfoType6-v590ext Sys
                                                                   SysInfoType6-v590ext-IEs
                                                                                                                                 OPTIONAL,
                          sysInfoTypeo-vost
nonCriticalExtensions OPTIONAL
                                                                               SEQUENCE {}
                                                                                                                                    OPTIONAL
                    }
             }
}
SysInfoType6-v4b0ext-IEs ::= SEQUENCE {
       -- openLoopPowerControl-IPDL-TDD is present only if IPDLs are applied for TDD
      openLoopPowerControl-IPDL-TDD OpenLoopPowerControl-IPDL-TDD-r4 OPTIONAL,
       -- If SysInfoType6 is sent to describe a 1.28Mcps TDD cell, the IE PRACH-RACH-Info included
      -- in PRACH-SystemInformationList shall be ignored, the IE PRACH-Partitioning and the
      -- IE rach-TransportFormatSet shall be absent and the corresponding IEs in the following
       -- PRACH-SystemInformationList-LCR-r4 shall be used
      \verb|prach-SystemInformationList-LCR-r4| PRACH-SystemInformationList-LCR-r4| OPTIONAL, \\
      tdd128SpecificInfo
                                                    SEQUENCE {
             pusch-SysInfoList-SFN
                                                                 PUSCH-SysInfoList-SFN-LCR-r4 OPTIONAL,
```

```
pdsch-SysInfoList-SFN PDSCH-SysInfoList-SFN-LCR-r4 OPTIONAL,
              pCCPCH-LCR-Extensions
                                                                      PrimaryCCPCH-Info-LCR-r4-ext
                                                                                                                                OPTIONAL,
              pCCPCH-LCR-Extensions primaryCCPCH-Inio-LCR-r4-ext OPTIONAL, sCCPCH-LCR-ExtensionsList SCCPCH-SystemInformationList-LCR-r4-ext OPTIONAL
                                                                                                                         OPTIONAL,
       frequencyBandIndicator
                                                            RadioFrequencyBandFDDSpare
                                                                                                                         OPTIONAL
}
SysInfoType6-v590ext-IEs ::= SEQUENCE {
                                                SEQUENCE {
       hcr-r5-SpecificInfo
              pusch-SysInfoList-SFN
                                                                      PUSCH-SysInfoList-SFN-HCR-r5
                                                                                                                                  OPTIONAL,
              pdsch-SysInfoList-SFN
                                                                       PDSCH-SysInfoList-SFN-HCR-r5
                                                                                                                                 OPTIONAL
                                                                                                                                 OPTIONAL
}
SysInfoType7 ::=
                                                               SEQUENCE {
       -- Physical channel IEs
              modeSpecificInfo
                                                                        CHOICE {
                                                                              SEQUENCE {
                     fdd
                           ul-Interference
                                                                                     UL-Interference
                     },
                                                                              NULL
                     tdd
              },
              prach-Information-SIB5-List
                                                                      DynamicPersistenceLevelList,
             prach-Information-SIB6-List
                                                                      DynamicPersistenceLevelList
                                                                                                                                        OPTIONAL.
                                                                       ExpirationTimeFactor
              expirationTimeFactor
                                                                                                                                       OPTIONAL.
       -- Extension mechanism for non- release99 information
              nonCriticalExtensions
                                                                      SEQUENCE {}
                                                                                                                                       OPTIONAL
}
SysInfoType8 ::=
                                                              SEQUENCE {
       -- User equipment IEs
              cpch-Parameters
                                                                      CPCH-Parameters,
       -- Physical channel IEs
              cpch-SetInfoList
                                                                      CPCH-SetInfoList.
              csich-PowerOffset
                                                                      CSICH-PowerOffset,
       -- Extension mechanism for non- release99 information
            nonCriticalExtensions
                                                                     SEQUENCE {}
                                                                                                                                         OPTIONAL
}
SysInfoType9 ::=
                                                               SEQUENCE {
       -- Physical channel IEs
              cpch-PersistenceLevelsList
                                                                      CPCH-PersistenceLevelsList,
       -- Extension mechanism for non- release99 information
             nonCriticalExtensions
                                                                       SEQUENCE {}
                                                                                                                                        OPTIONAL
}
SysInfoType10 ::=
                                                                SEQUENCE {
       -- User equipment IEs
              drac-SysInfoList
                                                                       DRAC-SysInfoList,
       -- Extension mechanism for non- release99 information
             nonCriticalExtensions
                                                                      SEQUENCE {}
                                                                                                                                        OPTIONAL
}
SysInfoType11 ::=
                                                               SEQUENCE {
             sib12indicator
                                                                      BOOLEAN,
       -- Measurement IEs
             fach-MeasurementOccasionInfoFACH-MeasurementOccasionInfomeasurementControlSysInfoMeasurementControlSysInfo,
                                                                                                                                      OPTIONAL,
       -- Extension mechanism for non- release99 information
              v4b0NonCriticalExtensions SEQUENCE {
    sysInfoType11-v4b0ext SysInfoType11-v4b0ext-IEs
    v590NonCriticalExtension SEQUENCE {
        sysInfoType11-v590ext SysInfoType11-v590ext-IEs,
        reconstruction SysInfoType11-v590ext-IEs,
        re
                                                                                                                                     OPTIONAL,
                                                                                    SysInfoType11-v590ext-IEs,
                                                                                      SEQUENCE {}
                            nonCriticalExtensions
                                                                                                                                               OPTIONAL
                                                                      OPTIONAL
                     }
              }
                                                               OPTIONAL
}
SysInfoType11-v4b0ext-IEs ::= SEQUENCE {
       fach-MeasurementOccasionInfo-LCR-Ext
                                                                              FACH-MeasurementOccasionInfo-LCR-r4-ext OPTIONAL,
       measurementControlSysInfo-LCR
                                                                              MeasurementControlSysInfo-LCR-r4-ext
}
SysInfoType11-v590ext-IEs ::= SEQUENCE {
       -- The order of the list corresponds to the order of cell in newIntraFrequencyCellInfoList
       newIntraFrequencyCellInfoList-v590ext SEQUENCE (SIZE (1..maxCellMeas)) OF
                                                                                     CellSelectReselectInfo-v590ext OPTIONAL,
       --The order of the list corresponds to the order of cell in newInterFrequencyCellInfoList
```

```
newInterFrequencyCellInfoList-v590ext SEQUENCE (SIZE (1..maxCellMeas)) OF
                                               CellSelectReselectInfo-v590ext OPTIONAL,
    --The order of the list corresponds to the order of cell in newInterRATCellInfoList
   newInterRATCellInfoList-v590ext
                                           SEQUENCE (SIZE (1..maxCellMeas)) OF
                                               CellSelectReselectInfo-v590ext OPTIONAL,
    intraFreqEventCriteriaList-v590ext
                                           Intra-FreqEventCriteriaList-v590ext
                                                                                   OPTIONAL,
    intraFreqReportingCriteria-1b-r5
                                           IntraFreqReportingCriteria-1b-r5 OPTIONAL,
    intraFreqEvent-1d-r5
                                           IntraFreqEvent-1d-r5
                                                                               OPTIONAL
}
                                   SEQUENCE {
SysInfoType12 ::=
    -- Measurement IEs
        fach-MeasurementOccasionInfo
                                       FACH-MeasurementOccasionInfo
                                                                         OPTIONAL.
        measurementControlSysInfo
                                      MeasurementControlSysInfo,
    -- Extension mechanism for non- release99 information
       sysInfoType12-v4b0ext
                                           SysInfoType12-v4b0ext-IEs
                                                                         OPTIONAL.
           v590NonCriticalExtension
                                           SEOUENCE {
               sysInfoType12-v590ext
                                               SysInfoType12-v590ext-IEs,
                                               SEQUENCE {}
                                                                               OPTIONAL
           }
        }
                                   OPTIONAL
SysInfoType12-v4b0ext-IEs ::= SEQUENCE {
    fach-MeasurementOccasionInfo-LCR-Ext
                                           FACH-MeasurementOccasionInfo-LCR-r4-ext OPTIONAL,
    measurementControlSysInfo-LCR
                                           MeasurementControlSysInfo-LCR-r4-ext
}
SysInfoType12-v590ext-IEs ::= SEQUENCE {
    --The order of the list corresponds to the order of cell in newIntraFrequencyCellInfoList
    newIntraFrequencyCellInfoList-v590ext SEQUENCE (SIZE (1..maxCellMeas)) OF
                                               CellSelectReselectInfo-v590ext OPTIONAL,
    --The order of the list corresponds to the order of cell in newInterFrequencyCellInfoList
   newInterFrequencyCellInfoList-v590ext SEQUENCE (SIZE (1..maxCellMeas)) OF
                                              CellSelectReselectInfo-v590ext OPTIONAL,
    --The order of the list corresponds to the order of cell in newInterRATCellInfoList
   newInterRATCellInfoList-v590ext
                                           SEQUENCE (SIZE (1..maxCellMeas)) OF
                                               CellSelectReselectInfo-v590ext OPTIONAL,
    intraFreqEventCriteriaList-v590ext
                                           Intra-FreqEventCriteriaList-v590ext
                                                                                   OPTIONAL,
                                           IntraFreqReportingCriteria-lb-r5 OPTIONAL, IntraFreqEvent-ld-r5 OPTIONAL
    intraFreqReportingCriteria-1b-r5
    intraFreqEvent-1d-r5
                                           IntraFregEvent-1d-r5
}
SysInfoType13 ::=
                                   SEQUENCE {
    -- Core network IEs
       cn-DomainSysInfoList
                                       CN-DomainSysInfoList,
    -- User equipment IEs

    ue-IdleTimersAndConstants
    UE-IdleTimersAndConstants

    capabilityUpdateRequirement
    CapabilityUpdateRequirement

                                                                          OPTIONAL,
                                                                         OPTIONAL,
    -- Extension mechanism for non- release99 information
       v3a0NonCriticalExtensions
                                           SEQUENCE {
           sysInfoType13-v3a0ext
                                           SysInfoType13-v3a0ext-IEs,
               sysInfoType13-v4b0ext
           v4b0NonCriticalExtensions
                                           SEQUENCE {
                                               SysInfoType13-v4b0ext-IEs,
           -- Extension mechanism for non- release99 information
               nonCriticalExtensions
                                               SEQUENCE {}
                                                                               OPTIONAL
                                       OPTIONAL
        }
                                   OPTIONAL
}
SysInfoType13-v3a0ext-IEs ::= SEQUENCE {
   ue-IdleTimersAndConstants-v3a0ext
                                           UE-IdleTimersAndConstants-v3a0ext
SysInfoType13-v4b0ext-IEs ::= SEQUENCE {
    capabilityUpdateRequirement-r4Ext CapabilityUpdateRequirement-r4-ext OPTIONAL
                                   SEQUENCE {
SysInfoType13-1 ::=
    -- ANSI-41 IEs
       ansi-41-RAND-Information
                                       ANSI-41-RAND-Information,
    -- Extension mechanism for non- release99 information
                                       SEQUENCE {}
                                                                           OPTIONAL
       nonCriticalExtensions
SysInfoType13-2 ::=
                                  SEQUENCE {
    -- ANSI-41 IEs
```

```
ansi-41-UserZoneID-Information ANSI-41-UserZoneID-Information,
   -- Extension mechanism for non- release99 information
       nonCriticalExtensions
                                    SEQUENCE {}
                                                                      OPTIONAL
}
SysInfoType13-3 ::=
                                 SEQUENCE {
   -- ANSI-41 IEs
       ansi-41-PrivateNeighbourListInfo ANSI-41-PrivateNeighbourListInfo,
   -- Extension mechanism for non- release99 information
       nonCriticalExtensions
                                     SEQUENCE {}
                                                                       OPTIONAL
}
                                 SEQUENCE {
SysInfoType13-4 ::=
   -- ANSI-41 IEs
       ansi-41-GlobalServiceRedirectInfo
                                     ANSI-41-GlobalServiceRedirectInfo,
   -- Extension mechanism for non- release99 information
       nonCriticalExtensions SEQUENCE {}
                                                                      OPTIONAL
}
                                SEQUENCE {
SysInfoType14 ::=
   -- Physical channel IEs
       individualTS-InterferenceList IndividualTS-InterferenceList, expirationTimeFactor ExpirationTimeFactor
                                                                       OPTIONAL,
   -- Extension mechanism for non- release99 information
       nonCriticalExtensions
                                     SEQUENCE {}
                                                                      OPTIONAL
}
SysInfoType15 ::=
                                 SEQUENCE {
   -- Measurement IEs
       ue-positioning-GPS-CipherParameters
                                           UE-Positioning-CipherParameters
       ue-positioning-GPS-ReferenceLocationReferenceLocation,ue-positioning-GPS-ReferenceTimeUE-Positioning-GPS-ReferenceTime,
       ue-positioning-GPS-ReferenceTime
       ue-positioning-GPS-Real-timeIntegrity
                                                BadSatList
                                                                                   OPTIONAL,
   -- Extension mechanism for non- release99 information
       v4b0NonCriticalExtensions SEQUENCE {
    sysInfoType15-v4b0ext SysInfoType15-v4b0ext-IEs,
       -- Extension mechanism for non- release4 information
          OPTIONAL
       } OPTIONAL
}
SysInfoType15-v4b0ext-IEs ::= SEQUENCE {
   SysInfoType15-1 ::=
                                SEQUENCE {
   -- DGPS corrections
       ue-positioning-GPS-DGPS-Corrections
                                                UE-Positioning-GPS-DGPS-Corrections,
   -- Extension mechanism for non- release99 information
      nonCriticalExtensions
                                     SEQUENCE {}
                                                           OPTIONAL
}
SysInfoType15-2 ::=
                                 SEQUENCE {
    -- Ephemeris and clock corrections
       transmissionTOW
                                     INTEGER (0..604799),
       satID
                                     SatID.
       ephemerisParameter
                                     EphemerisParameter,
   -- Extension mechanism for non- release99 information
                                     SEQUENCE {}
      nonCriticalExtensions
                                                      OPTIONAL
}
                                 SEQUENCE {
SysInfoType15-3 ::=
   -- Almanac and other data
       ue-positioning-GPS-Almanac INTEGER (0.. 604799),
                                                 UE-Positioning-GPS-Almanac
   OPTIONAL,
                                               UE-Positioning-GPS-IonosphericModel
       ue-positioning-GPS-IonosphericModel
   OPTIONAL,
       ue-positioning-GPS-UTC-Model
                                                UE-Positioning-GPS-UTC-Model
   OPTIONAL,
                                     BIT STRING (SIZE (1..32)) OPTIONAL,
                                     BIT STRING (SIZE (8))
                                                              OPTIONAL,
       lsbTOW
   -- Extension mechanism for non- release99 information
```

```
SEQUENCE {}
       nonCriticalExtensions
                                                                   OPTIONAL
}
SysInfoType15-4 ::=
                                   SEQUENCE {
    -- Measurement IEs
       ue-positioning-OTDOA-CipherParameters UE-Positioning-CipherParameters ue-positioning-OTDOA-AssistanceData UE-Positioning-OTDOA-AssistanceData,
                                                                                      OPTIONAL,
       v3a0NonCriticalExtensions SEQUENCE {
    sysInfoType15-4-v3a0ext SysInf
                                              SysInfoType15-4-v3a0ext,
        -- Extension mechanism for non- release99 information
           v4b0NonCriticalExtensions SEQUENCE {
                sysInfoType15-4-v4b0ext
                                                   SysInfoType15-4-v4b0ext,
               nonCriticalExtensions
                                                   SEOUENCE {}
                                                                  OPTIONAL
              OPTIONAL
           OPTIONAL
}
SysInfoType15-4-v3a0ext ::= SEQUENCE {
                                   SFN-Offset-Validity OPTIONAL
  sfn-Offset-Validity
}
SysInfoType15-4-v4b0ext ::= SEQUENCE {
   ue-Positioning-OTDOA-AssistanceData-r4ext UE-Positioning-OTDOA-AssistanceData-r4ext OPTIONAL
SysInfoType15-5 ::=
                                  SEQUENCE {
    -- Measurement IEs
       ue-positioning-OTDOA-AssistanceData-UEB
                                                UE-Positioning-OTDOA-AssistanceData-UEB,
       v3a0NonCriticalExtensions SEQUENCE {
    sysInfoType15-5-v3a0ext SysInfoType15-5-v3a0ext,
        -- Extension mechanism for non- release99 information
                                              SEQUENCE {}
          nonCriticalExtensions
        } OPTIONAL
}
SysInfoType15-5-v3a0ext ::= SEQUENCE {
   sfn-Offset-Validity SFN-Offset-Validity
SysInfoType16 ::=
                                  SEQUENCE {
   -- Radio bearer IEs
       preDefinedRadioConfiguration PreDefRadioConfiguration,
    -- Extension mechanism for non- release99 information
       nonCriticalExtensions
                                       SEQUENCE {}
                                                                            OPTIONAL
}
                                  SEQUENCE {
SysInfoType17 ::=
    -- Physical channel IEs
        -- If PDSCH/PUSCH is configured for 1.28Mcps TDD, pusch-SysInfoList and
        -- pdsch-SysInfoList should be absent and the info included in the
        -- tdd128SpecificInfo instead.
        -- If PDSCH/PUSCH is configured for 3.84Mcps TDD in R5, HCR-r5-SpecificInfo should also be
        -- included.
                                       PUSCH-SysInfoList
                                                                       OPTIONAL,
       pusch-SysInfoList
                                      PDSCH-SysInfoList
       pdsch-SysInfoList
                                                                       OPTIONAL,
    -- Extension mechanism for non- release99 information
       v4b0NonCriticalExtensions SEQUENCE {
   sysInfoType17-v4b0ext SysInf
                                         SysInfoType17-v4b0ext-IEs,
           }
                                       OPTIONAL
        }
                                   OPTIONAL
}
SysInfoType17-v4b0ext-IEs ::= SEQUENCE {
    tdd128SpecificInfo SEQUENCE {
    pusch-SysInfoList PUSCH-
                                 PUSCH-SysInfoList-LCR-r4
                                                                       OPTIONAL,
                                       PDSCH-SysInfoList-LCR-r4
       pdsch-SysInfoList
                                                                       OPTIONAL
                                                                       OPTIONAL
}
SysInfoType17-v590ext-IEs ::= SEQUENCE {
   hcr-r5-SpecificInfo SEQUENCE {
   pusch-SysInfoList PUSCH-SysI
                                   PUSCH-SysInfoList-HCR-r5
                                                               OPTIONAL,
                            PDSCH-SysInfoList-HCR-r5
       pdsch-SysInfoList
                                                               OPTIONAL
    }
                                                                OPTIONAL
}
```

```
SEQUENCE {
SysInfoType18 ::=
        idleModePLMNIdentities
                                        PLMNIdentitiesOfNeighbourCells
                                                                             OPTIONAL,
        connectedModePLMNIdentities PLMNIdentitiesOfNeighbourCells OPTIONAL,
    -- Extension mechanism for non- release99 information
                                        SEQUENCE {}
       nonCriticalExtensions
}
SysInfoTypeSB1 ::=
                                    SEQUENCE {
    -- Other IEs
       sib-ReferenceList
                                         SIB-ReferenceList,
    -- Extension mechanism for non- release99 information
                                         SEQUENCE {}
        nonCriticalExtensions
                                                                              OPTIONAL
}
SysInfoTypeSB2 ::=
                                    SEQUENCE {
    -- Other IEs
        sib-ReferenceList
                                        SIB-ReferenceList,
    -- Extension mechanism for non- release99 information
        nonCriticalExtensions
                                        SEQUENCE {}
                                                                              OPTIONAL
}
TDD-UMTS-Frequency-List ::=
                                         SEQUENCE (SIZE (1..maxNumTDDFreqs)) OF
                                             FrequencyInfoTDD
__ ***************
      ANSI-41 INFORMATION ELEMENTS (10.3.9)
__ ****************
ANSI-41-GlobalServiceRedirectInfo ::= ANSI-41-NAS-Parameter
ANSI-41-PrivateNeighbourListInfo ::= ANSI-41-NAS-Parameter ANSI-41-RAND-Information ::= ANSI-41-NAS-Parameter
ANSI-41-PrivateNeighbours:

ANSI-41-RAND-Information ::=

ANSI-41-NAS-Parameter

ANSI-41-NAS-Parameter

ANSI-41-NAS-Parameter

BIT STRING (SIZE (1...)
                                        BIT STRING (SIZE (1..2048))
Min-P-REV ::=
                                        BIT STRING (SIZE (8))
{\tt NAS-SystemInformationANSI-41} ::= \\ {\tt ANSI-41-NAS-Parameter}
                                         BIT STRING (SIZE (16))
P-REV ::=
                                        BIT STRING (SIZE (8))
SID ::=
                                         BIT STRING (SIZE (15))
END
```

11.4 Constant definitions

Constant-definitions DEFINITIONS AUTOMATIC TAGS ::=

BEGIN

```
INTEGER ::= 64
hiPDSCHidentities
hiPUSCHidentities
                            INTEGER ::= 64
                          INTEGER ::= 256
                           INTEGER ::= 16
INTEGER ::= 4
maxAC
maxAdditionalMeas
                           INTEGER ::= 8
maxASC
\max ASCmap
                            INTEGER ::= 7
maxASCpersist
                           INTEGER ::= 6
                            INTEGER ::= 8
maxCCTrCH
maxCellMeas
                            INTEGER ::= 32
                          INTEGER ::= 31
maxCellMeas-1
maxCNdomains
                            INTEGER ::= 4
                           INTEGER ::= 16
maxCPCHsets
                           INTEGER ::= 8
maxDPCH-DLchan
maxDPDCH-UL
                            INTEGER ::= 6
maxDRACclasses
                           INTEGER ::= 8
maxFACHPCH
                            INTEGER ::= 8
                           INTEGER ::= 8
maxFreq
                          INTEGER ::= 8
maxFreqBandsFDD
maxFreqBandsTDD
maxFreqBandsGSM
maxFreqBandsTDD
                           INTEGER ::= 4
                           INTEGER ::= 16
maxGERAN-SI
                            INTEGER ::= 8
                            INTEGER ::= 8
maxHProcesses
```

```
maxHSDSCHIBITIONINTEGER::=4maxHSSCCHsINTEGER::=4maxInterSysMessagesINTEGER::=4maxLoCHperRLCINTEGER::=2maxMAC-d-PDUsizesINTEGER::=8INTEGER::=8
    maxMeasEvent INTEGER ::= 8
maxMeasIntervals INTEGER ::= 3
maxMeasParEvent INTEGER ::= 3
maxNumCDMA2000Freqs INTEGER ::= 8
maxNumGSMFreqRanges INTEGER ::= 32
maxNumFDDFreqs INTEGER ::= 8
maxNumTDDFreqs INTEGER ::= 8
maxNofMeas INTEGER ::= 16
maxOtherRAT INTEGER ::= 15
maxNoulmeas INTEGER ::= 8
maxOtherRAT INTEGER ::= 16
maxPagel INTEGER ::= 16
maxPagel INTEGER ::= 16
maxPCPCH-APsig INTEGER ::= 16
maxPCPCH-APsubCh INTEGER ::= 16
maxPCPCH-CDsig INTEGER ::= 12
maxPCPCH-CDsubCh INTEGER ::= 12
maxPCPCH-CDsubCh INTEGER ::= 16
maxPCPCH-SF INTEGER ::= 7
maxPCPCHS INTEGER ::= 64
maxPDCPAlgoType INTEGER ::= 8
maxPDSCH INTEGER ::= 8
maxPDSCH-TFCIgroups INTEGER ::= 8
maxPACH INTEGER ::= 16
maxPACH-FPACH INTEGER ::= 8
maxPrach-FPACH INTEGER ::= 8
maxPusch INTEGER ::= 8
maxPusch INTEGER ::= 16
maxPUSCH INTEGER ::= 8
      maxOtherRAT-16
maxPagel
maxPCDC
                                                                                                                                                 INTEGER ::= 8
INTEGER ::= 8
        maxQueueIDs
                                                                                                                                                INTEGER ::= 16
        maxRABsetup

        maxRABSetup
        INTEGER
        :: = 16

        maxRAT
        INTEGER
        :: = 16

        maxRB
        INTEGER
        :: = 32

        maxRBallRABS
        INTEGER
        :: = 27

        maxRBMuxOptions
        INTEGER
        :: = 8

        maxReportedGSMCells
        INTEGER
        :: = 8

        maxRL
        INTEGER
        :: = 8

     maxReportedGSMCells
maxRL
maxRL-1
maxRFC3095-CID
maxROHC-PacketSizes-r4
maxROHC-Profile-r4
maxROHC-Profile-r4
maxROHC-Profile-r4
INTEGER
INTEG
                                                                                                                                                   INTEGER ::= 16
        maxSCCPCH
                                                                                                                                                  INTEGER ::= 32
INTEGER ::= 8
       maxSIB
       maxSIB-FACH
      maxS1B-FACHINTEGER:: = 8maxSIBperMsgINTEGER:: = 16maxSRBsetupINTEGER:: = 8maxSystemCapabilityINTEGER:: = 16maxTFINTEGER:: = 32
                                                                                                                                                    INTEGER ::= 32
INTEGER ::= 16
       maxTF
       maxTF-CPCH
        maxTFC
                                                                                                                                                  INTEGER ::= 1024
      maxTFCsub INTEGER ::= 1024
maxTFCI-2-Combs INTEGER ::= 512
maxTGPS INTEGER ::= 6
maxTrCH
         -- maxTrCHpreconf should be 16 but has been set to 32 for compatibility
       maxTrCHpreconf INTEGER ::= 32 maxTS INTEGER ::= 14
                                                                                                                                                   INTEGER ::= 13
INTEGER ::= 12
        maxTS-1
        maxTS-2
                                                                                                                                                   INTEGER ::= 6
        maxTS-LCR
                                                                                                                                                      INTEGER ::= 5
INTEGER ::= 8
        maxTS-LCR-1
        maxURA
        maxURNTI-Group
                                                                                                                                                    INTEGER ::= 8
```

11.5 RRC information between network nodes

Internode-definitions DEFINITIONS AUTOMATIC TAGS ::=

BEGIN

IMPORTS

```
HandoverToUTRANCommand,
    MeasurementReport,
    PhysicalChannelReconfiguration,
    RadioBearerReconfiguration,
    RadioBearerRelease,
    RadioBearerSetup,
    RRC-FailureInfo,
    TransportChannelReconfiguration
FROM PDU-definitions
-- Core Network IEs :
    CN-DomainIdentity,
    CN-DomainInformationList,
    CN-DomainInformationListFull,
    CN-DRX-CycleLengthCoefficient,
   NAS-SystemInformationGSM-MAP,
-- UTRAN Mobility IEs :
    CellIdentity,
   URA-Identity,
-- User Equipment IEs :
   AccessStratumReleaseIndicator,
    C-RNTI,
    ChipRateCapability,
    DL-CapabilityWithSimultaneousHS-DSCHConfig,
    DL-PhysChCapabilityFDD-v380ext,
    DL-PhysChCapabilityTDD,
    DL-PhysChCapabilityTDD-LCR-r4,
    GSM-Measurements,
    HSDSCH-physical-layer-category,
    FailureCauseWithProtErr,
    MaxHcContextSpace,
    MaximumAM-EntityNumberRLC-Cap,
    MaximumRLC-WindowSize,
    MaxNoPhysChBitsReceived,
    MaxPhysChPerFrame,
    MaxPhysChPerSubFrame-r4,
    MaxPhysChPerTS,
    MaxROHC-ContextSessions-r4,
    MaxTS-PerFrame,
    MaxTS-PerSubFrame-r4,
    MinimumSF-DL,
    MultiModeCapability,
    MultiRAT-Capability,
    NetworkAssistedGPS-Supported,
    RadioFrequencyBandTDDList,
    RLC-Capability,
    RRC-MessageSequenceNumber,
    SecurityCapability,
    SimultaneousSCCPCH-DPCH-Reception,
    STARTList,
    STARTSingle,
    START-Value,
    {\tt SupportOfDedicatedPilotsForChEstimation,}
    TransportChannelCapability,
    TxRxFrequencySeparation,
    U-RNTI.
    UE-MultiModeRAT-Capability,
    UE-PowerClassExt,
    UE-RadioAccessCapabBandFDDList,
    UE-RadioAccessCapability,
    UE-RadioAccessCapability-v370ext,
    UE-RadioAccessCapability-v380ext,
    UE-RadioAccessCapability-v3a0ext,
    UE-RadioAccessCapability-v3g0ext,
    UE-RadioAccessCapability-v4b0ext,
    UE-RadioAccessCapability-v590ext,
    UL-PhysChCapabilityFDD,
    UL-PhysChCapabilityTDD,
    UL-PhysChCapabilityTDD-LCR-r4,
-- Radio Bearer IEs :
    PredefinedConfigStatusList,
    PredefinedConfigValueTag,
    RAB-InformationSetupList,
    RAB-InformationSetupList-r4,
    RAB-InformationSetupList-r5,
    RB-Identity,
    SRB-InformationSetupList,
    SRB-InformationSetupList-r5,
```

```
-- Transport Channel IEs :
    CPCH-SetID,
    DL-CommonTransChInfo,
    DL-CommonTransChInfo-r4,
    DL-AddReconfTransChInfoList,
    DL-AddReconfTransChInfoList-r4,
    DL-AddReconfTransChInfoList-r5,
    DRAC-StaticInformationList,
    UL-CommonTransChInfo,
    UL-CommonTransChInfo-r4,
    UL-AddReconfTransChInfoList,
-- Physical Channel IEs :
    PrimaryCPICH-Info,
   TPC-CombinationIndex,
-- Measurement IEs :
   Inter-FreqEventCriteriaList-v590ext,
    Intra-FreqEventCriteriaList-v590ext,
    IntraFreqEvent-1d-r5,
    IntraFreqReportingCriteria-1b-r5,
    MeasurementIdentity,
    MeasurementReportingMode,
    MeasurementType,
    MeasurementType-r4,
    AdditionalMeasurementID-List,
    PositionEstimate.
-- Other IEs :
    GERANIu-RadioAccessCapability,
    InterRAT-UE-RadioAccessCapabilityList,
    InterRAT-UE-RadioAccessCapability-v590ext,
    UESpecificBehaviourInformationlidle,
    UESpecificBehaviourInformationlinterRAT
FROM InformationElements
    maxCNdomains,
    maxNoOfMeas,
   maxRB,
   maxRBallRABs,
    maxRFC3095-CID,
    maxSRBsetup,
   maxRL
FROM Constant-definitions
-- Part 1: Class definitions similar to what has been defined in 11.1 for RRC messages
-- Information that is tranferred in the same direction and across the same path is grouped
__ ***************
-- RRC information, to target RNC
__ ****************
-- RRC Information to target RNC sent either from source RNC or from another RAT
ToTargetRNC-Container ::= CHOICE {
    interRATHandoverInfo
                                        InterRATHandoverInfoWithInterRATCapabilities-r3,
    srncRelocation
                                        SRNC-RelocationInfo-r3,
   rfc3095-ContextInfo
                                         RFC3095-ContextInfo-r5,
    extension
                                         NULL
}
__ ***************
-- RRC information, target RNC to source RNC
__ ****************
TargetRNC-ToSourceRNC-Container ::= CHOICE {
    RadioBearerSetup, RadioBearerSetup, radioBearerReconfiguration RadioBearerReconfiguration RadioBearerRelease RadioRearorPellease
   radioBearerSetup
                                        RadioBearerReconfiguration,
   radioBearerRelease RadioBearerRelease, transportChannelReconfiguration physicalChannelReconfiguration physicalChannelReconfiguration, rrc-FailureInfo
    rrc-FailureInfo
                                        RRC-FailureInfo,
    -- IE dl-DCCHmessage consists of an octet string that includes the IE DL-DCCH-Message
dL-DCCHmessage OCTET STRING,
    dL-DCCHmessage
```

```
extension
                                    NULL
}
-- Part 2: Container definitions, similar to the PDU definitions in 11.2 for RRC messages
-- In alphabetical order
__ ***************
-- Handover to UTRAN information
__ ***************
InterRATHandoverInfoWithInterRATCapabilities-r3 ::= CHOICE {
                                 SEQUENCE {
       -- IE InterRATHandoverInfoWithInterRATCapabilities-r3-IEs also
       -- includes non critical extensions
       interRATHandoverInfoWithInterRATCapabilities-v390ext
   {\tt InterRATHandoverInfoWithInterRATCapabilities-v390ext-IEs},
          -- Reserved for future non critical extension
          nonCriticalExtensions SEQUENCE {} OPTIONAL
             OPTIONAL
   criticalExtensions
                                 SEQUENCE {}
}
InterRATHandoverInfoWithInterRATCapabilities-r3-IEs ::=
                                                       SEOUENCE {
       -- The order of the IEs may not reflect the tabular format
       -- but has been chosen to simplify the handling of the information in the BSC
   -- Other IEs
       ue-RATSpecificCapability InterRAT-UE-RadioAccessCapabilityList OPTIONAL,
-- interRATHandoverInfo, Octet string is used to obtain 8 bit length field prior to
-- actual information. This makes it possible for BSS to transparently handle information
       -- received via GSM air interface even when it includes non critical extensions.
       -- The octet string shall include the InterRATHandoverInfo information
       -- The BSS can re-use the 04.18 length field received from the MS
       interRATHandoverInfo
                                     OCTET STRING (SIZE (0..255))
}
InterRATHandoverInfoWithInterRATCapabilities-v390ext-IEs ::= SEQUENCE {
   -- User equipment IEs
       failureCauseWithProtErr
                                         FailureCauseWithProtErr
                                                                               OPTIONAL
}
__ *******************
-- RFC3095 context, source RNC to target RNC
__ ***************
RFC3095-ContextInfo-r5 ::= CHOICE {
                                 SEQUENCE {
       rFC3095-ContextInfoList-r5 RFC3095-ContextInfoList-r5,
       \mbox{--}\mbox{ Reserved} for future non critical extension
       nonCriticalExtensions
                                     SEQUENCE {} OPTIONAL
   criticalExtensions
                                SEQUENCE {}
}
RFC3095-ContextInfoList-r5 ::= SEQUENCE (SIZE (1..maxRBallRABs)) OF
                                    RFC3095-ContextInfo
__ *************************
-- SRNC Relocation information
__ ****************
SRNC-RelocationInfo-r3 ::= CHOICE {
           v380NonCriticalExtensions SRNC-RelocationInfo-r3-IEs,
                                 SEQUENCE {
       sRNC-RelocationInfo-r3
              sRNC-RelocationInfo-v380ext SRNC-RelocationInfo-v380ext-IEs,
               -- Reserved for future non critical extension
               v390NonCriticalExtensions
                                                SEOUENCE {
```

```
sRNC-RelocationInfo-v390ext
                                                         SRNC-RelocationInfo-v390ext-IEs,
                    v3a0NonCriticalExtensions
                                                         SEQUENCE {
                        sRNC-RelocationInfo-v3a0ext
                                                             SRNC-RelocationInfo-v3a0ext-IEs,
                                                             SEQUENCE {
                        v3b0NonCriticalExtensions
                            sRNC-RelocationInfo-v3b0ext
                                                                 SRNC-RelocationInfo-v3b0ext-IEs,
                            v3c0NonCriticalExtensions
                                                                 SEOUENCE {
                                sRNC-RelocationInfo-v3c0ext
                                                                     SRNC-RelocationInfo-v3c0ext-IEs,
                                                                     SEQUENCE {
                                laterNonCriticalExtensions
                                    sRNC-RelocationInfo-v3d0ext
                                                                         SRNC-RelocationInfo-v3d0ext-
IEs,
                                     -- Container for additional R99 extensions
                                    sRNC-RelocationInfo-r3-add-ext
                                                                         BIT STRING
                                    (CONTAINING SRNC-RelocationInfo-v3h0ext-IEs)
                                                                                         OPTIONAL,
                                    v3g0NonCriticalExtensions
                                                                         SEQUENCE {
                                        sRNC-RelocationInfo-v3g0ext
                                                                             SRNC-RelocationInfo-v3g0ext-IEs,
                                        v4b0NonCriticalExtensions
                                                                             SEQUENCE {
                                            sRNC-RelocationInfo-v4b0ext
                                                                                 SRNC-RelocationInfo-v4b0ext-Il
                                                                                 SEQUENCE {
                                             v590NonCriticalExtensions
                                                 sRNC-RelocationInfo-v590ext
                                                                                 SRNC-RelocationInfo-v590ext-I
                                                 -- Reserved for future non critical extension
                                                 nonCriticalExtensions
                                                                                 SEQUENCE {} OPTIONAL
                                                    OPTIONAL
                                                 OPTIONAL
                                            OPTIONAL
                                        OPTIONAL
                                    OPTIONAL
                                OPTIONAL
                            OPTIONAL
                        OPTIONAL
            }
                    OPTIONAL
    later-than-r3
                                    CHOICE {
                                        SEQUENCE {
       r4
            sRNC-RelocationInfo-r4
                                            SRNC-RelocationInfo-r4-IEs,
            v4d0NonCriticalExtensions
                                        SEQUENCE {
                sRNC-RelocationInfo-v4d0ext
                                                SRNC-RelocationInfo-v4d0ext-IEs,
                -- Container for adding non critical extensions after freezing REL-5
                                                   BIT STRING
                sRNC-RelocationInfo-r4-add-ext
                                                                     OPTIONAL,
                                                 SEQUENCE {
                v590NonCriticalExtensions
                    sRNC-RelocationInfo-v590ext
                                                        SRNC-RelocationInfo-v590ext-IEs,
                    nonCriticalExtensions
                                                    SEQUENCE {} OPTIONAL
                } OPTIONAL
            }
                OPTIONAL
        },
        criticalExtensions
                                        CHOICE {
                                            SEQUENCE {
            r5
                sRNC-RelocationInfo-r5
                                                SRNC-RelocationInfo-r5-IEs,
                sRNC-RelocationInfo-r5-add-ext
                                                BIT STRING
                                                                 OPTIONAL,
                nonCriticalExtensions
                                                SEQUENCE {}
                                                                 OPTIONAL
            },
                                                 SEQUENCE {}
            criticalExtensions
        }
    }
}
SRNC-RelocationInfo-r3-IEs ::=
                                    SEQUENCE {
    -- Non-RRC IEs
        stateOfRRC
                                        StateOfRRC,
        stateOfRRC-Procedure
                                        StateOfRRC-Procedure,
    -- Ciphering related information IEs
    -- If the extension v380 is included use the extension for the ciphering status per CN domain
       cipheringStatus
                                       CipheringStatus,
        calculationTimeForCiphering
                                        CalculationTimeForCiphering
                                                                             OPTIONAL,
        -- The order of occurrence in the IE cipheringInfoPerRB-List is the
        -- same as the RBs in SRB-InformationSetupList in RAB-InformationSetupList.
        -- The signalling RBs are supposed to be listed
        -- first. Only UM and AM RBs that are ciphered are listed here
                                                                             OPTIONAL.
        cipheringInfoPerRB-List
                                        CipheringInfoPerRB-List
        count-C-List
                                        COUNT-C-List
                                                                             OPTIONAL,
        integrityProtectionStatus
                                        IntegrityProtectionStatus,
         -- In the IE srb-SpecificIntegrityProtInfo, the first information listed corresponds to
         -- signalling radio bearer RBO and after the order of occurrence is the same as the SRBs in
        -- SRB-InformationSetupList
        srb-SpecificIntegrityProtInfo
                                        SRB-SpecificIntegrityProtInfoList,
                                        ImplementationSpecificParams
        implementationSpecificParams
    -- User equipment IEs
                                        U-RNTI,
        u-RNTI
```

```
C-RNTI
                                        C-RNTI
                                                                            OPTIONAL,
        ue-RadioAccessCapability
                                        UE-RadioAccessCapability,
       ue-Positioning-LastKnownPos
                                       UE-Positioning-LastKnownPos
                                                                            OPTIONAL,
    -- Other IEs
       ue-RATSpecificCapability
                                        InterRAT-UE-RadioAccessCapabilityList
                                                                              OPTIONAL,
    -- UTRAN mobility IEs
       ura-Identity
                                        URA-Identity
                                                                            OPTIONAL.
    -- Core network IEs
        cn-CommonGSM-MAP-NAS-SysInfo
                                       NAS-SystemInformationGSM-MAP,
        cn-DomainInformationList
                                        CN-DomainInformationList
                                                                            OPTIONAL,
    -- Measurement IEs
        ongoingMeasRepList
                                        OngoingMeasRepList
                                                                            OPTIONAL.
    -- Radio bearer IEs
       predefinedConfigStatusList
                                        PredefinedConfigStatusList,
        srb-InformationList
                                        SRB-InformationSetupList,
       rab-InformationList
                                        RAB-InformationSetupList
                                                                            OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo
                                        UL-CommonTransChInfo
                                                                            OPTIONAL,
        ul-TransChInfoList
                                        UL-AddReconfTransChInfoList
        modeSpecificInfo
                                        CHOICE {
                                           SEQUENCE {
           fdd
                                                                            OPTIONAL,
                cpch-SetID
                                                CPCH-Set.ID
                transChDRAC-Info
                                                DRAC-StaticInformationList OPTIONAL
            },
            tdd
                                            NULL
        dl-CommonTransChInfo
                                        DL-CommonTransChInfo
                                                                            OPTIONAL,
                                        DL-AddReconfTransChInfoList
        dl-TransChInfoList
                                                                            OPTIONAL,
    -- Measurement report
       measurementReport
                                       MeasurementReport
                                                                            OPTIONAL.
}
SRNC-RelocationInfo-v380ext-IEs ::= SEQUENCE {
    -- Ciphering related information IEs
        cn-DomainIdentity
                                            CN-DomainIdentity,
        cipheringStatusList
                                            CipheringStatusList
}
SRNC-RelocationInfo-v390ext-IEs ::= SEQUENCE {
        cn-DomainInformationList-v390ext
                                            CN-DomainInformationList-v390ext
                                                                                    OPTIONAL,
        ue-RadioAccessCapability-v370ext
                                            UE-RadioAccessCapability-v370ext
                                                                                    OPTIONAL,
        ue-RadioAccessCapability-v380ext
                                            UE-RadioAccessCapability-v380ext
                                                                                    OPTIONAL.
        dl-PhysChCapabilityFDD-v380ext
                                            DL-PhysChCapabilityFDD-v380ext,
        failureCauseWithProtErr
                                            FailureCauseWithProtErr
                                                                                    OPTIONAL
}
SRNC-RelocationInfo-v3a0ext-IEs ::= SEQUENCE {
        cipheringInfoForSRB1-v3a0ext
                                            CipheringInfoPerRB-List-v3a0ext,
        ue-RadioAccessCapability-v3a0ext
                                            UE-RadioAccessCapability-v3a0ext
                                                                                    OPTIONAL,
        -- cn-domain identity for IE startValueForCiphering-v3a0ext is specified
        -- in subsequent extension (SRNC-RelocationInfo-v3b0ext-IEs)
                                           START-Value
        startValueForCiphering-v3a0ext
}
SRNC-RelocationInfo-v3b0ext-IEs ::= SEQUENCE {
        -- cn-domain identity for IE startValueForCiphering-v3a0ext included in previous extension
        cn-DomainIdentity
                                       CN-DomainIdentity,
        -- the IE startValueForCiphering-v3b0ext contains the start values for each CN Domain. The
        -- value of start indicated by the IE startValueForCiphering-v3a0ext should be set to the
        -- same value as the start-Value for the corresponding cn-DomainIdentity in the IE
        -- startValueForCiphering-v3b0ext
        startValueForCiphering-v3b0ext
                                            STARTList2
                                                                                    OPTIONAL
}
SRNC-RelocationInfo-v3c0ext-IEs ::= SEQUENCE {
        -- IE rb-IdentityForHOMessage includes the identity of the RB used by the source SRNC
        -- to send the message contained in the IE 'TargetRNC-ToSourceRNC-Container'.
        -- Only included if type is 'UE involved'
        rb-IdentityForHOMessage
                                            RB-Identity
                                                                OPTIONAL
}
SRNC-RelocationInfo-v3d0ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        uESpecificBehaviourInformation1idle
                                              UESpecificBehaviourInformationlidle
        uESpecificBehaviourInformationlinterRAT
                                                   UESpecificBehaviourInformationlinterRAT
    OPTIONAL
}
```

```
SRNC-RelocationInfo-v3g0ext-IEs ::= SEQUENCE {
        ue-RadioAccessCapability-v3q0ext UE-RadioAccessCapability-v3q0ext
                                                                                        OPTIONAL
}
SRNC-RelocationInfo-v3h0ext-IEs ::= SEQUENCE {
       tpc-CombinationInfoList TPC-CombinationInfoList OPTIONAL,
                                         SEQUENCE {}
        nonCriticalExtension
                                                                       OPTIONAL
}
SRNC-RelocationInfo-v4d0ext-IEs ::= SEQUENCE {
        tpc-CombinationInfoList TPC-CombinationInfoList OPTIONAL
TPC-CombinationInfoList ::= SEQUENCE (SIZE (1..maxRL)) OF
        TPC-Combination-Info
STARTList 2 ::=
                                     SEQUENCE (SIZE (2..maxCNdomains)) OF
                                         STARTSingle
SRNC-RelocationInfo-v4b0ext-IEs ::= SEQUENCE {
        ue-RadioAccessCapability-v4b0ext UE-RadioAccessCapability-v4b0ext
                                                                                       OPTIONAL
SRNC-RelocationInfo-v590ext-IEs ::= SEQUENCE {
        ue-RadioAccessCapability-v590ext UE-RadioAccessCapability-v590ext
                                                                                       OPTIONAL.
        ue-RATSpecificCapability-v590ext
                                             InterRAT-UE-RadioAccessCapability-v590ext OPTIONAL
CipheringInfoPerRB-List-v3a0ext ::= SEQUENCE {
                                         BIT STRING (SIZE (7))
        dl-UM-SN
CipheringStatusList ::= SEQUENCE (SIZE (1..maxCNdomains)) OF
                                         CipheringStatusCNdomain
CipheringStatusCNdomain ::=
                                          SEQUENCE {
        cn-DomainIdentity
                                         CN-DomainIdentity,
                                         CipheringStatus
        cipheringStatus
}
SRNC-RelocationInfo-r4-IEs ::=
                                         SEQUENCE {
    -- Non-RRC IEs
        \operatorname{\mathsf{--}} IE rb-IdentityForHOMessage includes the identity of the RB used by the source SRNC
        -- to send the message contained in the IE 'TargetRNC-ToSourceRNC-Container'.
        -- Only included if type is 'UE involved'
        rb-IdentityForHOMessage RB-Identity
                                                                               OPTIONAL,
        stateOfRRC
                                         StateOfRRC.
        stateOfRRC-Procedure
                                        StateOfRRC-Procedure,
    -- Ciphering related information IEs
        cipheringStatusList CipheringStatusList-r4,
latestConfiguredCN-Domain CN-DomainIdentity,
calculationTimeForCiphering CalculationTimeForCiphering
                                                                               OPTIONAL.
        count-C-List COUNT-C-List cipheringInfoPerRB-List CipheringInfoPerRB-List-r4
                                                                               OPTIONAL,
                                                                               OPTIONAL.
    -- Integrity protection related information IEs
        integrityProtectionStatus IntegrityProtectionStatus, srb-SpecificIntegrityProtInfo SRB-SpecificIntegrityProtInfoList,
        integrityProtectionStatus
        OPTIONAL,
    -- User equipment IEs
        11-RNTT
                                         II-RNTT.
        ue-RadioAccessCapability UE-RadioAccessCapability
                                                                               OPTIONAL,
                                         UE-RadioAccessCapability-r4,

    ue-RadioAccessCapability-ext
    UE-RadioAccessCapabBandFDDList

    ue-Positioning-LastKnownPos
    UE-Positioning-LastKnownPos

                                                                               OPTIONAL,
        uESpecificBehaviourInformationlidle UESpecificBehaviourInformationlidle
                                                                                           OPTIONAL.
        uESpecificBehaviourInformationlinterRAT UESpecificBehaviourInformationlinterRAT
    OPTIONAL,
    -- Other IEs
        ue-RATSpecificCapability
                                         InterRAT-UE-RadioAccessCapabilityList OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity
                                         URA-Identity
                                                                               OPTIONAL,
    -- Core network IEs
        cn-CommonGSM-MAP-NAS-SysInfo NAS-SystemInformationGSM-MAP,
        cn-DomainInformationList
                                         CN-DomainInformationListFull
                                                                              OPTIONAL,
    -- Measurement IEs
        ongoingMeasRepList
                                         OngoingMeasRepList-r4
                                                                               OPTIONAL,
    -- Radio bearer IEs
        predefinedConfigStatusList
                                         PredefinedConfigStatusList,
```

```
srb-InformationList
                                       SRB-InformationSetupList,
       rab-InformationList
                                       RAB-InformationSetupList-r4
                                                                           OPTIONAL,
    -- Transport channel IEs
       ul-CommonTransChInfo
                                       UL-CommonTransChInfo-r4
                                                                           OPTIONAL.
       ul-TransChInfoList
                                       UL-AddReconfTransChInfoList
                                                                           OPTIONAL,
       modeSpecificInfo
                                       CHOICE {
           fdd
                                           SEQUENCE {
               cpch-SetID
                                               CPCH-SetID
                                                                           OPTIONAL.
               transChDRAC-Info
                                               DRAC-StaticInformationList OPTIONAL
           },
           t.dd
                                           NULL
                                                                           OPTIONAL.
       dl-CommonTransChInfo
                                       DL-CommonTransChInfo-r4
                                                                           OPTIONAL,
       dl-TransChInfoList
                                       DL-AddReconfTransChInfoList-r4
                                                                           OPTIONAL,
    -- Measurement report
       measurementReport
                                       MeasurementReport
                                                                           OPTIONAL.
       failureCause
                                       FailureCauseWithProtErr
                                                                           OPTIONAL
}
                                       SEQUENCE {
SRNC-RelocationInfo-r5-IEs ::=
     - Non-RRC IEs
        -- IE rb-IdentityForHOMessage includes the identity of the RB used by the source SRNC
        -- to send the message contained in the IE 'TargetRNC-ToSourceRNC-Container'.
        -- Only included if type is "UE involved"
       rb-IdentityForHOMessage
                                     RB-Identity
                                                                           OPTIONAL.
       stateOfRRC
                                       StateOfRRC,
       stateOfRRC-Procedure
                                       StateOfRRC-Procedure,
    -- Ciphering related information IEs
        cipheringStatusList
                                       CipheringStatusList-r4,
       latestConfiguredCN-Domain
                                       CN-DomainIdentity,
       calculationTimeForCiphering
                                       CalculationTimeForCiphering
                                                                           OPTIONAL.
       count-C-List
                                      COUNT-C-List
                                                                           OPTIONAL,
       cipheringInfoPerRB-List
                                      CipheringInfoPerRB-List-r4
                                                                           OPTIONAL,
    -- Integrity protection related information IEs
                                    IntegrityProtectionStatus,
       integrityProtectionStatus
       srb-SpecificIntegrityProtInfo
                                      SRB-SpecificIntegrityProtInfoList OPTIONAL,
       implementationSpecificParams
                                       ImplementationSpecificParams
                                                                           OPTIONAL.
    -- User equipment IEs
                                       U-RNTI,
       u-RNTI
       c-RNTI
                                       C-RNTI
                                                                           OPTIONAL,
       ue-RadioAccessCapability
                                       UE-RadioAccessCapability-r5,
       ue-RadioAccessCapability-ext
                                       UE-RadioAccessCapabBandFDDList
                                                                           OPTIONAL.
       ue-Positioning-LastKnownPos
                                       UE-Positioning-LastKnownPos
                                                                           OPTIONAL,
       uESpecificBehaviourInformationlidle
                                       UESpecificBehaviourInformation1idle
                                                                              OPTIONAL,
       {\tt uESpecificBehaviourInformationlinterRAT}
                                       UESpecificBehaviourInformationlinterRAT
                                                                                   OPTIONAL,
    -- Other IEs
       ue-RATSpecificCapability
                                       InterRAT-UE-RadioAccessCapabilityList-r5
                                                                                   OPTIONAL,
    -- UTRAN mobility IEs
       ura-Identity
                                       URA-Identity
                                                                           OPTIONAL,
    -- Core network IEs
       cn-CommonGSM-MAP-NAS-SysInfo
                                       NAS-SystemInformationGSM-MAP,
       cn-DomainInformationList
                                       CN-DomainInformationListFull
                                                                           OPTIONAL.
   -- Measurement IEs
       ongoingMeasRepList
                                       OngoingMeasRepList-r5
                                                                           OPTIONAL,
    -- Radio bearer IEs
       predefinedConfigStatusList
                                       PredefinedConfigStatusList,
       srb-InformationList
                                       SRB-InformationSetupList-r5,
       rab-InformationList
                                       RAB-InformationSetupList-r5
                                                                           OPTIONAL,
    -- Transport channel IEs
       ul-CommonTransChInfo
                                       UL-CommonTransChInfo-r4
                                                                           OPTIONAL,
                                       UL-AddReconfTransChInfoList
       ul-TransChInfoList
                                                                           OPTIONAL.
       modeSpecificInfo
                                       CHOICE {
           fdd
                                           SEQUENCE {
               cpch-Set.ID
                                               CPCH-SetID
               transChDRAC-Info
                                               DRAC-StaticInformationList OPTIONAL
           },
           tdd
                                                                           OPTIONAL,
       dl-CommonTransChInfo
                                       DL-CommonTransChInfo-r4
                                                                           OPTIONAL.
       dl-TransChInfoList
                                       DL-AddReconfTransChInfoList-r5
                                                                           OPTIONAL,
    -- PhyCH IEs
       tpc-CombinationInfoList
                                       TPC-CombinationInfoList
                                                                           OPTIONAL,
    -- Measurement report
       measurementReport
                                       MeasurementReport
                                                                           OPTIONAL,
    -- Other IEs
       failureCause
                                       FailureCauseWithProtErr
                                                                           OPTIONAL
```

```
}
-- IE definitions
CalculationTimeForCiphering ::=
                                   SEQUENCE {
                                    CellIdentity,
                                       INTEGER (0..4095)
    sfn
}
CipheringInfoPerRB ::=
                                    SEQUENCE {
   dl-HFN
                                       BIT STRING (SIZE (20..25)),
                                        BIT STRING (SIZE (20..25))
    ul-HFN
CipheringInfoPerRB-r4 ::=
                                   SEQUENCE {
   rb-Identity
                                       RB-Identity,
                                        BIT STRING (SIZE (20..25)),
    dl-HFN
   dl-UM-SN
                                       BIT STRING (SIZE (7))
                                                                           OPTIONAL,
   ul-HFN
                                       BIT STRING (SIZE (20..25))
}
-- TABULAR: CipheringInfoPerRB-List, multiplicity value numberOfRadioBearers
-- has been replaced with maxRB.
                                    SEQUENCE (SIZE (1..maxRB)) OF
CipheringInfoPerRB-List ::=
                                       CipheringInfoPerRB
CipheringInfoPerRB-List-r4 ::=
                                    SEQUENCE (SIZE (1..maxRB)) OF
                                       CipheringInfoPerRB-r4
CipheringStatus ::=
                                    ENUMERATED {
                                       started, notStarted }
CipheringStatusList-r4 ::=
                                    SEQUENCE (SIZE (1..maxCNdomains)) OF
                                        CipheringStatusCNdomain-r4
CipheringStatusCNdomain-r4 ::=
                                    SEQUENCE {
       cn-DomainIdentity
                                    CN-DomainIdentity,
       cipheringStatus
                                        CipheringStatus,
       start-Value
                                       START-Value
}
                                     SEQUENCE {
CN-DomainInformation-v390ext ::=
    cn-DRX-CycleLengthCoeff
                                       CN-DRX-CycleLengthCoefficient
CN-DomainInformationList-v390ext ::= SEQUENCE (SIZE (1..maxCNdomains)) OF
                                       CN-DomainInformation-v390ext
CompressedModeMeasCapability-r4 ::= SEQUENCE {
    fdd-Measurements
                                       BOOLEAN,
    -- TABULAR: The IEs tdd-Measurements, gsm-Measurements and multiCarrierMeasurements
    -- are made optional since they are conditional based on another information element.
    -- Their absence corresponds to the case where the condition is not true.
    tdd384-Measurements
                                       BOOLEAN
                                                                            OPTIONAL,
                                                                            OPTIONAL.
    tdd128-Measurements
                                       BOOLEAN
    gsm-Measurements
                                       GSM-Measurements
                                                                            OPTIONAL,
    multiCarrierMeasurements
                                       BOOLEAN
                                                                            OPTIONAL
}
COUNT-C-List ::=
                                       SEQUENCE (SIZE (1..maxCNdomains)) OF
                                        COUNT-CSingle
COUNT-CSingle ::=
                                       SEOUENCE {
   cn-DomainIdentity
                                        CN-DomainIdentity,
    count-C
                                       BIT STRING (SIZE (32))
}
                                  SEQUENCE {
DL-PhysChCapabilityFDD-r4 ::=
                                       INTEGER (1..8),
   maxNoDPCH-PDSCH-Codes
   maxNoDPCH-PDSCH-Codes
maxNoPhysChBitsReceived
                                       MaxNoPhysChBitsReceived,
    supportForSF-512
                                       BOOLEAN,
    supportOfPDSCH
                                       BOOLEAN,
    \verb|simultaneousSCCPCH-DPCH-Reception| SimultaneousSCCPCH-DPCH-Reception|,
    supportOfDedicatedPilotsForChEstimation SupportOfDedicatedPilotsForChEstimation
                                                                                           OPTIONAL
DL-PhysChCapabilityFDD-r5 ::=
                                  SEQUENCE {
```

```
maxNoDPCH-PDSCH-Codes
                                        INTEGER (1..8),
                                         MaxNoPhysChBitsReceived,
    maxNoPhysChBitsReceived
    supportForSF-512
                                        BOOLEAN,
    supportOfPDSCH
                                        BOOLEAN,
    simultaneousSCCPCH-DPCH-Reception SimultaneousSCCPCH-DPCH-Reception,
    supportOfDedicatedPilotsForChEstimation
                                               SupportOfDedicatedPilotsForChEstimation
                                                                                               OPTIONAL,
                                        CHOICE {
    fdd-hspdsch
                                             SEQUENCE {
        supported
            hsdsch-physical-layer-category
                                                 HSDSCH-physical-layer-category,
            supportOfDedicatedPilotsForChannelEstimationOfHSDSCH BOOLEAN,
            -- simultaneousSCCPCH-DPCH-HSDSCH-Reception shall be true only if the
            -- IE SimultaneousSCCPCH-DPCH-Reception indicates support of simultaneous
            -- reception of S-CCPCH and DPCH
            simultaneousSCCPCH-DPCH-HSDSCH-Reception
                                                         BOOLEAN
        unsupported
                                             NULL
    }
}
DL-PhysChCapabilityTDD-r5 ::=
                                     SEQUENCE {
    maxTS-PerFrame
                                        MaxTS-PerFrame,
    {\tt maxPhysChPerFrame}
                                         MaxPhysChPerFrame,
    minimumSF
                                         MinimumSF-DL,
    supportOfPDSCH
                                        BOOLEAN.
    maxPhysChPerTS
                                         MaxPhysChPerTS,
    tdd384-hspdsch
                                         CHOICE {
        supported
                                             HSDSCH-physical-layer-category,
        unsupported
}
DL-PhysChCapabilityTDD-LCR-r5 ::= SEQUENCE {
    maxTS-PerSubFrame
                                         MaxTS-PerSubFrame-r4,
    maxPhysChPerFrame
                                         MaxPhysChPerSubFrame-r4,
    minimumSF
                                         MinimumSF-DL.
    supportOfPDSCH
                                         BOOLEAN,
                                         MaxPhysChPerTS,
    maxPhysChPerTS
    supportOf8PSK
                                         BOOLEAN,
    tdd128-hspdsch
                                         CHOICE {
        supported
                                             HSDSCH-physical-layer-category,
        unsupported
    }
}
DL-RFC3095-Context ::=
                                     SEQUENCE {
    rfc3095-Context-Identity
                                         INTEGER (0..16383),
                                         ENUMERATED {u, o, r},
    dl-mode
    dl-ref-ir
                                         OCTET STRING ( SIZE (1..3000)),
                                         INTEGER (0..4294967295) OPTIONAL,
INTEGER (0..4294967295) OPTIONAL,
    dl-ref-time
    dl-curr-time
                                         INTEGER (0..65535)
                                                                     OPTIONAL,
    dl-svn-offset-id
                                         INTEGER (0..4294967295)
    dl-syn-slope-ts
                                                                     OPTIONAL,
    dl-dyn-changed
                                         BOOLEAN
                                    BIT STRING (SIZE (1..512))
ImplementationSpecificParams ::=
IntegrityProtectionStatus ::=
                                     ENUMERATED {
                                         started, notStarted }
InterRAT-UE-RadioAccessCapabilityList-r5 ::=
                                                 SEQUENCE {
    inter \texttt{RAT-UE-RadioAccessCapability} \quad \textbf{InterRAT-UE-RadioAccessCapabilityList},
    geranIu-RadioAccessCapability
                                        GERANIu-RadioAccessCapability
                                                                                      OPTIONAL
}
MaxHcContextSpace-r5 ::=
                                         ENUMERATED {
                                             by512, by1024, by2048, by4096, by8192,
                                             by16384, by32768, by65536, by131072 }
MeasurementCapability-r4 ::=
                                     SEQUENCE {
    downlinkCompressedMode
                                         CompressedModeMeasCapability-r4,
                                         CompressedModeMeasCapability-r4
    uplinkCompressedMode
}
                                     CHOICE {
MeasurementCommandWithType ::=
                                         MeasurementType,
    setup
    modify
                                         NULL,
```

```
release
                                         NULL
}
MeasurementCommandWithType-r4 ::=
                                    CHOICE {
                                         MeasurementType-r4,
    setup
    modify
   release
                                          NULL
}
OngoingMeasRep ::=
                                     SEQUENCE {
   measurementIdentity
                                         MeasurementIdentity,
    -- TABULAR: The CHOICE Measurement in the tabular description is included
    -- in MeasurementCommandWithType
    measurementCommandWithType
                                        MeasurementCommandWithType,
    measurementReportingMode
                                         MeasurementReportingMode
                                                                               OPTIONAL,
    additionalMeasurementID-List
                                         AdditionalMeasurementID-List
                                                                              OPTIONAL
}
OngoingMeasRep-r4 ::=
                                     SEQUENCE {
    measurementIdentity
                                         MeasurementIdentity,
    -- TABULAR: The CHOICE Measurement in the tabular description is included
    -- in MeasurementCommandWithType-r4.
    measurementCommandWithType MeasurementCommandWithType-r4, measurementReportingMode MeasurementReportingMode
    additionalMeasurementID-List AdditionalMeasurementID-List
                                                                              OPTIONAL
}
OngoingMeasRep-r5 ::=
                                     SEQUENCE {
   measurementIdentity
                                         MeasurementIdentity,
    -- TABULAR: The CHOICE Measurement in the tabular description is included
    -- in MeasurementCommandWithType-r4.
   measurementCommandWithType MeasurementCommandWithType-r4,
   measurementReportingMode MeasurementReportingMode additionalMeasurementID-List AdditionalMeasurementID-List measurementCommand-v590ext CHOICE {
                                                                               OPTIONAL,
                                                                               OPTIONAL,
        -- the choice "intra-frequency" shall be used for the case of intra-frequency measurement,
        -- as well as when intra-frequency events are configured for inter-frequency measurement
                                             Intra-FreqEventCriteriaList-v590ext,
        intra-frequency
        inter-frequency
                                             Inter-FreqEventCriteriaList-v590ext
           OPTIONAL,
    } OPIIONAL,
intraFreqReportingCriteria-1b-r5
                                             IntraFreqReportingCriteria-1b-r5
    intraFreqEvent-1d-r5
                                             IntraFreqEvent-1d-r5
                                                                                       OPTIONAL
}
OngoingMeasRepList ::=
                                   SEQUENCE (SIZE (1..maxNoOfMeas)) OF
                                         OngoingMeasRep
OngoingMeasRepList-r4 ::=
                                     SEQUENCE (SIZE (1..maxNoOfMeas)) OF
                                         OngoingMeasRep-r4
OngoingMeasRepList-r5 ::=
                                     SEQUENCE (SIZE (1..maxNoOfMeas)) OF
                                         OngoingMeasRep-r5
PDCP-Capability-r4 ::=
                                     SEQUENCE {
    losslessSRNS-RelocationSupport
                                         BOOLEAN,
    supportForRfc2507
                                          CHOICE {
        notSupported
        supported
                                              MaxHcContextSpace
    },
    supportForRfc3095
                                         CHOICE {
        notSupported
                                             NULL,
        supported
                                              SEQUENCE {
            maxROHC-ContextSessions
                                                 MaxROHC-ContextSessions-r4 DEFAULT s16,
            reverseCompressionDepth
                                                  INTEGER (0..65535)
                                                                               DEFAULT 0
        }
    }
}
PDCP-Capability-r5 ::=
                                     SEQUENCE {
    losslessSRNS-RelocationSupport
                                         BOOLEAN
    supportForRfc2507
                                          CHOICE {
        notSupported
                                             MaxHcContextSpace-r5
        supported
    supportForRfc3095
                                          CHOICE {
        notSupported
        supported
                                              SECUENCE {
                                                  MaxROHC-ContextSessions-r4 DEFAULT s16,
            maxROHC-ContextSessions
```

```
reverseCompressionDepth
                                               INTEGER (0..65535)
                                                                         DEFAULT 0,
           supportForRfc3095ContextRelocation BOOLEAN
        }
    }
}
                                       SEQUENCE {
PhysicalChannelCapability-r4 ::=
                                         SEQUENCE {
        fddPhysChCapability
           downlinkPhysChCapability
                                           	ext{DL-PhysChCapabilityFDD-r4},
           uplinkPhysChCapability
                                               UL-PhysChCapabilityFDD
                                                  OPTIONAL,
                                           SEQUENCE {
        tdd384-PhysChCapability
                                          DL-PhysChCapabilityTDD,
UL-PhysChCapabilityTDD
           downlinkPhysChCapability
           uplinkPhysChCapability
                                                  OPTIONAL,
        tdd128-PhysChCapability
                                           SEQUENCE {
                                           DL-PhysChCapabilityTDD-LCR-r4,
           downlinkPhysChCapability
           uplinkPhysChCapability
                                               UL-PhysChCapabilityTDD-LCR-r4
}
                                       SEQUENCE {
PhysicalChannelCapability-r5 ::=
        {\tt fddPhysChCapability}
                                           SEQUENCE {
           downlinkPhysChCapability
                                              DL-PhysChCapabilityFDD-r5,
           uplinkPhysChCapability
                                               UL-PhysChCapabilityFDD
                                                 OPTIONAL,
        tdd384-PhysChCapability
                                           SEQUENCE {
                                          DL-PhysChCapabilityTDD-r5,
           downlinkPhysChCapability
                                              UL-PhysChCapabilityTDD
           uplinkPhysChCapability
                                                  OPTIONAL,
                                          SEQUENCE {
        tdd128-PhysChCapability
                                           DL-PhysChCapabilityTDD-LCR-r5,
           downlinkPhysChCapability
           uplinkPhysChCapability
                                               UL-PhysChCapabilityTDD-LCR-r4
        }
                                                   OPTIONAL
}
RF-Capability-r4 ::=
                                   SEQUENCE {
       fddRF-Capability
                                      SEQUENCE {
                                          UE-PowerClassExt,
           ue-PowerClass
           txRxFrequencySeparation
                                          TxRxFrequencySeparation
                                                                       OPTIONAL,
        tdd384-RF-Capability
                                       SEQUENCE {
           ue-PowerClass
                                           UE-PowerClassExt,
           radioFrequencyBandTDDList
                                           RadioFrequencyBandTDDList,
           chipRateCapability
                                           ChipRateCapability
                                                                      OPTIONAL,
        tdd128-RF-Capability
                               SEQUENCE {
                                       UE-PowerClassExt,
           ue-PowerClass
           radioFrequencyBandTDDList
                                           RadioFrequencyBandTDDList,
           chipRateCapability
                                           ChipRateCapability
        }
                                                                       OPTIONAL
}
                                   SEQUENCE {
RFC3095-ContextInfo ::=
                                      RB-Identity,
   rb-Identity
                                      RFC3095-Context-List
    rfc3095-Context-List
}
RFC3095-Context-List ::=
                                  SEQUENCE (SIZE (1..maxRFC3095-CID)) OF SEQUENCE {
   dl-RFC3095-Context
                                      DL-RFC3095-Context OPTIONAL,
   ul-RFC3095-Context
                                       UL-RFC3095-Context
                                                              OPTIONAL
RLC-Capability-r5 ::=
                                   SEQUENCE {
    totalRLC-AM-BufferSize
                                  TotalRLC-AM-BufferSize-r5,
    maximumRLC-WindowSize
                                       MaximumRLC-WindowSize,
   maximumAM-EntityNumber
                                      MaximumAM-EntityNumberRLC-Cap
}
{\tt SRB-SpecificIntegrityProtInfo} ::= {\tt SEQUENCE} \ \{
    ul-RRC-HFN
                                       BIT STRING (SIZE (28)),
    dl-RRC-HFN
                                       BIT STRING (SIZE (28)),
    ul-RRC-SequenceNumber
                                       RRC-MessageSequenceNumber,
    dl-RRC-SequenceNumber
                                       RRC-MessageSequenceNumber
}
SRB-SpecificIntegrityProtInfoList ::= SEQUENCE (SIZE (4..maxSRBsetup)) OF
                                       SRB-SpecificIntegrityProtInfo
```

```
StateOfRRC ::=
                                    ENUMERATED {
                                        cell-DCH, cell-FACH,
                                        cell-PCH, ura-PCH }
                                    ENUMERATED {
StateOfRRC-Procedure ::=
                                        awaitNoRRC-Message,
                                        awaitRB-ReleaseComplete,
                                        awaitRB-SetupComplete,
                                        awaitRB-ReconfigurationComplete,
                                        awaitTransportCH-ReconfigurationComplete,
                                        awaitPhysicalCH-ReconfigurationComplete,
                                        awaitActiveSetUpdateComplete,
                                        awaitHandoverComplete,
                                        sendCellUpdateConfirm,
                                        sendUraUpdateConfirm,
                                        -- dummy is not used in this version of specification
                                        -- It should not be sent
                                        dummy,
                                        otherStates
}
TotalRLC-AM-BufferSize-r5 ::=
                                    ENUMERATED {
                                        kb10, kb50, kb100, kb150, kb200,
                                        kb300, kb400, kb500, kb750, kb1000 }
TPC-Combination-Info ::= SEQUENCE {
       primaryCPICH-Info
                                            PrimaryCPICH-Info,
        tpc-CombinationIndex
                                           TPC-CombinationIndex
}
UE-MultiModeRAT-Capability-r5 ::= SEQUENCE {
    multiRAT-CapabilityList MultiRAT-Capability,
                                        MultiModeCapability,
    multiModeCapability
    supportOfUTRAN-ToGERAN-NACC
                                       BOOLEAN
}
UE-Positioning-Capability-r4 ::= SEQUENCE {
    standaloneLocMethodsSupported
                                           BOOLEAN,
    ue-BasedOTDOA-Supported
                                           BOOLEAN,
    networkAssistedGPS-Supported
                                           NetworkAssistedGPS-Supported,
    supportForUE-GPS-TimingOfCellFrames
                                           BOOLEAN.
    supportForIPDL
                                           BOOLEAN,
    rx-tx-TimeDifferenceType2Capable
                                           BOOLEAN,
    validity-CellPCH-UraPCH
                                            ENUMERATED { true }
                                                                    OPTIONAL,
    sfn-sfnType2Capability
                                            ENUMERATED { true }
                                                                    OPTIONAL
}
UE-Positioning-LastKnownPos ::= SEQUENCE {
                                    INTEGER (0..4095),
       sfn
                                        CellIdentity,
        cell-id
                                       PositionEstimate
        positionEstimate
}
UE-RadioAccessCapability-r4 ::=
                                    SEQUENCE {
                                        AccessStratumReleaseIndicator,
    accessStratumReleaseIndicator
    pdcp-Capability
                                        PDCP-Capability-r4,
    rlc-Capability
                                        RLC-Capability,
    transportChannelCapability
                                        TransportChannelCapability,
    rf-Capability
                                       RF-Capability-r4,
    physicalChannelCapability
                                       PhysicalChannelCapability-r4,
    ue-MultiModeRAT-Capability
                                        UE-MultiModeRAT-Capability,
    securityCapability
                                       SecurityCapability,
    ue-positioning-Capability
                                       UE-Positioning-Capability-r4,
    measurementCapability
                                        MeasurementCapability-r4
                                                                        OPTIONAL
}
UE-RadioAccessCapability-r5 ::=
                                   SEQUENCE {
                                        AccessStratumReleaseIndicator,
    accessStratumReleaseIndicator
    dl-CapabilityWithSimultaneousHS-DSCHConfig
                                        DL-CapabilityWithSimultaneousHS-DSCHConfig OPTIONAL,
    pdcp-Capability
                                        PDCP-Capability-r5,
    rlc-Capability
                                        RLC-Capability-r5,
    {\tt transportChannelCapability}
                                       TransportChannelCapability,
    rf-Capability
                                        RF-Capability-r4,
    physicalChannelCapability
                                       PhysicalChannelCapability-r5,
    ue-MultiModeRAT-Capability
                                       UE-MultiModeRAT-Capability-r5,
    securityCapability
                                        SecurityCapability,
```

```
ue-positioning-Capability
                                         UE-Positioning-Capability-r4,
    measurementCapability
                                         MeasurementCapability-r4
                                                                          OPTIONAL
UL-RFC3095-Context ::=
                                     SEOUENCE {
                                         INTEGER (0..16383),
    rfc3095-Context-Identity
                                         ENUMERATED {u, o, r},
    ul-mode
    ul-ref-ir
                                         OCTET STRING ( SIZE (1..3000)),
    ul-ref-time
                                         INTEGER (0..4294967295)
                                                                      OPTIONAL,
    ul-curr-time
                                         INTEGER (0..4294967295)
                                                                      OPTIONAL,
    ul-syn-offset-id
                                         INTEGER (0..65535)
                                                                      OPTIONAL,
                                         INTEGER (0..4294967295)
    ul-syn-slope-ts
                                                                      OPTIONAL.
    ul-ref-sn-1
                                         INTEGER (0..65535)
                                                                      OPTIONAL
}
END
```

12 Message transfer syntax

Transfer syntax for RRC PDUs is derived from their ASN.1 definitions by use of Packed Encoding Rules, unaligned as specified in X.691 [49], and with adapted final padding. If special encoding is used, it is indicated in the ECN module defined for each ASN.1 module. The use of special encoding is defined in [14].

The following encoding rules apply in addition to what has been specified in X.691 [49]:

- When a bit string value is placed in a bit-field as specified in 15.6 to 15.11 in [11], the leading bit of the bit string value shall be placed in the leading bit of the bit-field, and the trailing bit of the bit string value shall be placed in the trailing bit of the bit-field.

NOTE: The terms "leading bit" and "trailing bit" are defined in ITU-T Rec. X.680 | ISO/IEC 8824-1. When using the "bstring" notation, the leading bit of the bit string value is on the left, and the trailing bit of the bit string value is on the right.

12.1 Structure of encoded RRC messages

An RRC PDU, which is the bit string that is exchanged between peer entities/ across the radio interface, is the concatenation of a basic production, an extension and padding, in that order.

RRC PDUs shall be mapped to and from RLC SDUs upon transmission and reception as follows:

- when delivering an RRC PDU as an RLC SDU to the RLC layer for transmission, the first bit of the RRC PDU shall be represented as the first bit in the RLC SDU and onwards; and
- upon reception of an RLC SDU from the RLC layer, the first bit of the RLC SDU shall represent the first bit of the RRC PDU and onwards.

12.1.1 Basic production

The 'basic production' is obtained by applying UNALIGNED PER to the abstract syntax value (the ASN.1 description) as specified in X.691, except for the 0 to 7 bits added at the end to produce a multiple of 8 bits. The basic production can have any positive number of bits, not necessarily a multiple of 8 bits.

12.1.2 Extension

Emitters compliant with this version of the specification of the protocol shall, unless indicated otherwise on a PDU type basis, set the extension part empty. Emitters compliant with a later version might send non-empty extensions.

12.1.3 Padding

Emitters compliant with this version of the specification of the protocol shall, unless indicated otherwise on a PDU type basis, pad the basic production with the smallest number of bits required to meet the size constraints of the lower layers. Padding bits shall be set to 0.

Receivers compliant with this version of the specification have no need to distinguish the extension and padding parts, and shall, unless indicated otherwise on a PDU type basis, accept RRC PDUs with any bit string in the extension and padding parts.




Figure 12.1.3-1: Padding

When using AM or UM mode, RLC requires that the RRC PDU length is a multiple of 8 bits.

When using Tr mode, RLC does neither impose size requirements nor perform padding. This implies that RRC has to take into account the transport format set defined for the transport channel across which the message is to be sent. RRC shall add the lowest number of padding bits required to fit the size specified for the selected transport format.

For system information blocks, building the PDU involves two steps. The first step is the building of the System Information Blocks, in which step padding is not applied (the rules for extension apply). The second step is the building of the RRC PDUs, involving segmentation and concatenation of System Information Blocks, and then padding as described above for Tr mode. The procedure is shown by means of an example as described in Figure 12.1.3-2. The example includes two System Information Blocks, SIBn and SIBn+1, of which only SIBn includes a protocol extension. The two System Information Blocks used in the example do not require segmentation and are concatenated into one SYSTEM INFORMATION message.




Figure 12.1.3-2: Padding for System Information

PCI: Protocol control information at SYSTEM INFORMATION message level

SI: SYSTEM INFORMATION message

For system information blocks, RRC may also add padding information at the end of IE "SIB data fixed", used both within IE "Last segment" and IE "Complete SIB". The IE "SIB data fixed" has a fixed length i.e. no length denominator used. In case the remaining amount of "SIB data" information is insufficient to fill the IE completely, RRC includes padding bits.

Since no length denominator is included, the receiving RRC cannot remove the padding added by the sender. However, since the padding used is the same as the padding added by the PER encoder to achieve octet alignment, the receiver can handle it.

NOTE 1 The mechanism described above implies that the PDU provided to the ASN.1 decoder may have more than 7 padding bits included. For a complete System Information Block of length 215 bits, 11 padding bits are added by RRC. Since the decoder requires an octet aligned input, 6 additional bits need to be added. In this (worst) case, a total of 17 padding bits is included.

NOTE 2 For the above cases, use of padding bits is possible and more efficient than including a length denominator.

When using the RRC padding described above, the segment has a fixed length, which completely fills the transport block. Therefore, in this case no RRC padding is added within the SYSTEM INFORMATION message. This is illustrated by means of the following figure.




Figure 12.1.3-3: No RRC padding for System Information

12.2 ECN link module for RRC

END

```
RRC-ECN-Link-Module LINK-DEFINITIONS ::=
BEGIN
IMPORTS
   RRC-encodings
                                -- Encoding objects for RRC messages
FROM RRC-Encoding-Definitions;
ENCODE Class-definitions
    WITH RRC-encodings
    COMPLETED BY PER-BASIC-UNALIGNED
ENCODE PDU-definitions
    WITH RRC-encodings
    COMPLETED BY PER-BASIC-UNALIGNED
ENCODE InformationElements
    WITH RRC-encodings
    COMPLETED BY PER-BASIC-UNALIGNED
ENCODE Internode-definitions
    WITH RRC-encodings
    COMPLETED BY PER-BASIC-UNALIGNED
```

12.3 ECN modules for RRC

The encoding definition module "RRC-Encoding-Definitions" contains definition of the encoding object set "RRC-encodings". The encoding object set contains all the specialized encoding for RRC.

```
RRC-Encoding-Definitions ENCODING-DEFINITIONS ::=
BEGIN
EXPORTS
   RRC-encodings;
RRC-encodings #ENCODINGS ::= {
    -- Trailing bits
   outer-encoding
}
__*********************
-- The trailing bits in all RRC messages shall be ignored
-- (including unknown message contents & unknown extensions).
-- This overrides the default PER behaviour which pads the last
-- octet with zero bits.
__**********************
outer-encoding #OUTER ::= {
   ENCODER-DECODER {
   DECODE AS IF {
       POST-PADDING
                     encoder-option
}
END
Class-definitions-ECN-Module ENCODING-DEFINITIONS ::=
BEGIN
END
PDU-definitions-ECN-Module ENCODING-DEFINITIONS ::=
BEGIN
END
InformationElements-ECN-Module ENCODING-DEFINITIONS ::=
BEGIN
Internode-definitions-ECN-Module ENCODING-DEFINITIONS ::=
BEGIN
```

12.4 RRC messages encoded otherwise

NOTE: The messages included in this section are not specified by means of ASN.1.

12.4.1 Messages using tabular encoding specification

The encoding of the message is specified by means of a table listing the information elements known in the message and their order of their appearance in the message.

When a field extends over more than one octet, the order of bit values progressively decreases as the octet number increases. The least significant bit of the field is represented by the lowest numbered bit of the highest numbered octet of the field.

12.4.1.1 TRANSPORT FORMAT COMBINATION CONTROL using transparent DCCH

There are three possible formats for the transparent format combination control mode used on a transparent mode DCCH. The mode to be used is configured during establishment of the transparent mode DCCH.

12.4.1.1.1 TRANSPORT FORMAT COMBINATION CONTROL, 3 bit format

The 3 bit format is as follows:

3	2	1	Transport Format Combination Set Identity value
0	0	0	0
0	0	1	1
0	1	0	2
1	1	1	7

12.4.1.1.2 TRANSPORT FORMAT COMBINATION CONTROL, 5 bit format

The 5 bit format is as follows:

5	4	3	2	1	Transport Format Combination Set Identity value
0	0	0	0	0	0
0	0	0	0	1	1
0	0	0	1	0	2
1	1	1	1	1	31

12.4.1.1.3 TRANSPORT FORMAT COMBINATION CONTROL, 10 bit format

The 10 bit format is as follows:

	Octet 1			Oc	t 2					
10	9	8	7	6	5	4	3	2	1	Transport Format Combination Set Identity value
0	0	0	0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0	0	1	1
0	0	0	0	0	0	0	0	1	0	2
1	1	1	1	1	1	1	1	1	1	1023

13 Protocol timers, counters, other parameters and default configurations

The information provided in subclauses 13.1 and 13.2 shall be treated as informative. The normative text is specified in the relevant subclauses in clause 8 and clause 8 shall prevail.

13.1 Timers for UE

Timer	Start	Stop	At expiry
T300	Transmission of RRC CONNECTION REQUEST	Reception of RRC CONNECTION SETUP	Retransmit RRC CONNECTION REQUEST if V300 =< N300, else go to Idle mode
T302	Transmission of CELL UPDATE/URA UPDATE	Reception of CELL UPDATE CONFIRM/URA UPDATE CONFIRM	Retransmit CELL UPDATE/URA UPDATE if V302 =< N302, else, go to Idle mode
T304	Transmission of UE CAPABILITY INFORMATION	Reception of UE CAPABILITY INFORMATION CONFIRM	Retransmit UE CAPABILITY INFORMATION if V304 =< N304, else initiate a cell update procedure
T305	Entering CELL_FACH or URA_PCH or CELL_PCH state. Reception of CELL UDPATE CONFIRM/URA UPDATE CONFIRM.	Entering another state.	Transmit CELL UPDATE if T307 is not activated and the UE detects "in service area". Otherwise, if T307 is not active, start T307.
T307	When the timer T305 has expired and the UE detects "out of service area".	When the UE detects "in service area".	Transit to idle mode
T308	Transmission of RRC CONNECTION RELEASE COMPLETE	Not stopped	Transmit RRC CONNECTION RELEASE COMPLETE if V308 <=N308, else go to idle mode.
T309	Upon reception of CELL CHANGE ORDER FROM UTRAN message	Successful response to a connection establishment request in the new cell.	Resume the connection to UTRAN
T310	Transmission of PUSCH CAPACITY REQUEST	Reception of PHYSICAL SHARED CHANNEL ALLOCATION	Transmit PUSCH CAPACITY REQUEST if V310 =< N310, else procedure stops.
T311	Reception of PHYSICAL SHARED CHANNEL ALLOCATION message with the CHOICE "PUSCH allocation" set to "PUSCH allocation pending".	Reception of PHYSICAL SHARED CHANNEL ALLOCATION message with CHOICE "PUSCH allocation" set to "PUSCH allocation assignment".	UE may initiate a PUSCH capacity request procedure.
T312	When the UE starts to establish dedicated CH	When the UE detects N312 "in sync" indication from L1.	The criteria for physical channel establishment failure is fulfilled
T313	When the UE detects consecutive N313 "out of sync" indication from L1.	When the UE detects consecutive N315 "in sync" indication from L1.	The criteria for Radio Link failure is fulfilled.
T314	When the criteria for radio link failure are fulfilled. The timer is started if radio bearer(s) that are associated with T314 exist of if only RRC connection exists.	When the Cell Update procedure has been completed.	See subclause 8.3.1.13.
T315	When the criteria for radio link failure are fulfilled. The timer is started only if radio bearer(s) that are associated with T315 exist.	When the Cell Update procedure has been completed.	See subclause 8.3.1.14.

Timer	Start	Stop	At expiry
T316	When the UE detects "out of service area" in URA_PCH or CELL_PCH state	When the UE detects "in service area".	Initiate cell update procedure if in service area is detected. Otherwise start timer T317, transit to CELL_FACH state and initiate cell update procedure when the UE detects "in service area".
T317	When the T316 expires or when in CELL_FACH state, the UE detects "out of service area".	When the UE detects "in service area".	T317 never expires.

13.2 Counters for UE

Counter	Reset	Incremented	When reaching max value
V300	When initiating the procedure RRC connection establishment	Upon expiry of T300.	When V300 > N300, the UE enters idle mode.
V302	When initiating the procedure Cell update or URA update	Upon expiry of T302	When V302 > N302 the UE enters idle mode.
V304	When sending the first UE CAPABILITY INFORMATION message.	Upon expiry of T304	When V304 > N304 the UE initiates the Cell update procedure
V308	When sending the first RRC CONNECTION RELEASE COMPLETE message in a RRC connection release procedure.	Upon expiry of T308	When V308 > N308 the UE stops re-transmitting the RRC CONNECTION RELEASE COMPLETE message.
V310	When sending the first PUSCH CAPACITY REQUEST message in a PUSCH capacity request procedure	Upon expiry of T310	When V310 > N310 the UE stops re-transmitting the PUSCH CAPACITY REQUEST message.

13.3 UE constants and parameters

Constant	Usage
N300	Maximum number of retransmissions of the RRC CONNECTION REQUEST message
N302	Maximum number of retransmissions of the CELL UPDATE / URA UPDATE message
N304	Maximum number of retransmissions of the UE CAPABILITY INFORMATION message
N308	Maximum number of retransmissions of the RRC CONNECTION RELEASE COMPLETE
	message
N310	Maximum number of retransmission of the PUSCH CAPACITY REQUEST message
N312	Maximum number of "in sync" received from L1.
N313	Maximum number of successive "out of sync" received from L1.
N315	Maximum number of successive "in sync" received from L1 during T313 is activated.

13.4 UE variables

13.4.0 CELL_INFO_LIST

This variable contains cell information on intra-frequency, inter-frequency and inter-RAT cells, as received in messages System Information Block Type 11, System Information Block Type 12, and MEASUREMENT CONTROL.

The first position in Intra-frequency cell info list corresponds to Intra-frequency cell id 0, the second to Intra-frequency cell id 1, etc.

The first position in Inter-frequency cell info list corresponds to Inter-frequency cell id 0, the second to Inter-frequency cell id 1, etc.

The first position in Inter-RAT cell info list corresponds to Intra-frequency cell id 0, the second to Inter-RAT cell id 1, etc.

This variable shall be cleared at cell re-selection, when leaving UTRA RRC connected mode, when switched off as well as at selection of a new PLMN.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Intra-frequency cell info	OP	1 <maxcel IMeas></maxcel 		
>CHOICE position status	MP			
>>Occupied				
>>>Cell info	MP		Cell info 10.3.7.2	
>>Vacant				No data
Inter-frequency cell info	OP	1 <maxcel IMeas></maxcel 		
>CHOICE position status	MP			
>>Occupied				
>>>Frequency info	MP		Frequency info 10.3.6.36	
>>>Cell info	MP		Cell info 10.3.7.2	
>>Vacant				No data
Inter-RAT cell info	OP	1 <maxcel IMeas></maxcel 		
>CHOICE position status	MP			
>>Occupied				
>>>CHOICE Radio Access Technology				
>>>GSM				
>>>>Cell selection and reselection info	MP		Cell selection and re- selection info for SIB11/12 10.3.2.4	
>>>>BSIC	MP		BSIC 10.3.8.2	
>>>>BCCH ARFCN	MP		Integer (01023)	[43]
>>>IS-2000			<u> </u>	
>>>>System specific measurement info			enumerated (frequency, timeslot, colour code, output power, PN offset)	For IS-2000, use fields from TIA/EIA/IS-2000.5, subclause 3. 7.3.3.2.27, Candidate Frequency Neighbour List Message
>>Vacant				No data

13.4.00 Void

13.4.0a CELL_UPDATE_STARTED

This variable indicates whether a cell update or URA update procedure is in progress.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Cell update started	MP		Boolean	TRUE means a cell or URA update procedure is in progress. Set to FALSE when entering UTRA RRC connected mode. Set to FALSE when leaving UTRA RRC connected mode.

13.4.1 CIPHERING_STATUS

This variable contains information about the current status of ciphering in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Status for each CN domain	MP	<1 to maxCNDo mains>		
>CN domain identity	MP		CN domain identity 10.3.1.1	
>Status	MP		Enumerated(Not started, Started)	Set to "Not started" when entering UTRA RRC connected mode. Set to "Not started" when leaving UTRA RRC connected mode.
Reconfiguration	MP		Boolean	TRUE means an RRC procedure performing reconfiguration of ciphering is ongoing. Set to FALSE when entering UTRA RRC connected mode. Set to FALSE when leaving UTRA RRC connected mode.

13.4.2 Void

13.4.2a CONFIGURATION_INCOMPLETE

This variable indicates whether a received measurement control message contains invalid an incomplete measurement configuration.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Configuration incomplete	MP		Boolean	TRUE: An incomplete configuration has been detected. Set to FALSE when entering UTRA RRC connected mode. Set to FALSE when leaving UTRA RRC connected mode.

13.4.3 C_RNTI

This variable stores the assigned C-RNTI for this UE when in CELL_FACH state.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
C-RNTI	OP		C-RNTI 10.3.3.8	Cleared when entering UTRA RRC connected mode when not otherwise stated in the procedure. Cleared when leaving UTRA RRC connected mode.

13.4.3a DSCH_RNTI

This variable stores the assigned DSCH-RNTI for this UE when in CELL_DCH state.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
DSCH-RNTI	OP		DSCH-RNTI 10.3.3.9a	Cleared when entering UTRA RRC connected mode when not otherwise stated in the procedure. Cleared when leaving UTRA RRC connected mode.

13.4.4 Void

13.4.5 ESTABLISHED_RABS

This variable is used to store information about the established radio access bearers and signalling radio bearers in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
RAB information	OP	1 to <maxrabs etup></maxrabs 		For each RAB established. Cleared when entering UTRA RRC connected mode when not otherwise stated in the procedure. Cleared when leaving UTRA RRC connected mode.
>RAB info	MP		RAB info 10.3.4.8	
>RB information	MP	1 to <maxrbpe r RAB></maxrbpe 		For each RB belonging to the RAB
>>RB identity	MP		RB identity 10.3.4.16	
>>Subflow	MP		Integer(0< maxSubflow count>)	Reference to the RAB subflow implemented by this RB
>>RB started	MD		Enumerated(stopped, started)	Default value is started
Signalling radio bearer information	OP	1 to < maxSRBse tup>		In the order of RB0 and upwards. Cleared when leaving UTRA RRC connected mode.
>RB started	MD		Enumerated(Default value is started

Information Element/Group name	Need	Multi	Type and reference	Semantics description
			stopped, started)	

13.4.5a ESTABLISHED_SIGNALLING_CONNECTIONS

This variable is used to store information about established signalling connections.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Signalling connection list	OP	1 to <maxcndo mains></maxcndo 		For each established signalling connection. Cleared when entering UTRA RRC connected mode when not otherwise stated in the procedure. Cleared when leaving UTRA RRC connected mode.
>Signalling connection identity	MP		CN domain identity 10.3.1.1	

13.4.6 ESTABLISHMENT_CAUSE

This variable is used to store the cause for establishment of a signalling connection received by upper layers, to be used at RRC connection establishment or Initial Direct Transfer.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Establishment cause	OP		Establishme	Cleared when leaving UTRA
			nt cause	RRC connected mode.
			10.3.3.11	

13.4.7 FAILURE_CAUSE

This variable contains the cause for failure of a UE initiated procedure, to be reported in a retransmitted message.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Failure cause	OP		Failure cause 10.3.3.13	Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode.

13.4.8 FAILURE_INDICATOR

This variable indicates whether the procedure has failed for a UE initiated procedure.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Failure indicator	MP		Boolean	TRUE: Procedure has failed. Set to FALSE when entering UTRA RRC connected mode. Set to FALSE when leaving UTRA RRC connected mode.

13.4.80 H_RNTI

This variable stores the assigned H-RNTI for this UE when in CELL-DCH state and a HS-DSCH transport channel has been allocated.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
H-RNTI	OP		H-RNTI 10.3.3.14a	Cleared when entering UTRA RRC connected mode when not otherwise stated in the procedure. Cleared when leaving UTRA RRC connected mode.	REL-5

13.4.800 HS_DSCH_RECEPTION

This variable indicates whether HS-DSCH reception procedures are ongoing.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
HS-DSCH reception	MP		Boolean	TRUE: HS-DSCH reception is ongoing. Set to FALSE when entering UTRA RRC connected mode when not otherwise stated in the procedure. Set to FALSE when leaving UTRA RRC connected mode.	REL-5

13.4.8a INCOMPATIBLE_SECURITY_RECONFIGURATION

This variable indicates whether an incompatible simultaneous reconfiguration of a security function has been received.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Incompatible security reconfiguration	MP		Boolean	TRUE: An incompatible simultaneous security reconfiguration has been detected. Set to FALSE when entering UTRA RRC connected mode. Set to FALSE when leaving UTRA RRC connected mode.

13.4.9 INITIAL_UE_IDENTITY

In this variable the identity used by the UE when establishing an RRC connection is stored.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Initial UE identity	OP		Initial UE identity	Cleared when leaving UTRA RRC connected mode.
			10.3.3.15	RRC connected mode.

13.4.9a INTEGRITY_PROTECTION_ACTIVATION_INFO

This variable contains information to be sent to UTRAN about when a new integrity protection configuration shall be activated in the uplink for signalling radio bearers in case of modification of integrity protection.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Uplink Integrity protection activation info	OP		Integrity protection activation info 10.3.3.17	Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode.

13.4.10 INTEGRITY_PROTECTION_INFO

This variable contains information about the current status of the integrity protection in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Status	MP		Enumerated(Not started, Started)	Set to "Not started" when entering UTRA RRC connected mode. Set to "Not started" when leaving UTRA RRC connected mode.
Reconfiguration	MP		Boolean	TRUE means a reconfiguration of integrity protection is ongoing. Set to FALSE when entering UTRA RRC connected mode. Set to FALSE when leaving UTRA RRC connected mode.
Signalling radio bearer specific integrity protection information	OP	1 to <maxsrbs etup></maxsrbs 		When integrity protection is started, status information for RB0- RB4 in that order. Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode.
>Uplink RRC HFN	MP		Bit string (28)	
>Downlink RRC HFN	MP		Bit string (28)	
>Uplink RRC Message sequence number	MP		Integer (0 15)	
>Downlink RRC Message sequence number	OP		Integer (0 15)	

13.4.10a INTER_RAT_HANDOVER_INFO_TRANSFERRED

This variable stores information about the inter RAT handover info that has been transferred to another RAT.

Information Element/Group name	Need	Multi	Type and referenc e	Semantics description	Version
Predefined configuration status information	OP		Predefin ed configura tion status informati on 10.3.4.5 a	Cleared upon entering connected mode in another RAT	
Predefined configuration status information compressed	OP		Predefin ed configura tion status informati on compres sed 10.3.4.5 b	Cleared upon entering connected mode in another RAT	REL-5
UE security information	OP		UE security informati on 10.3.3.4 2b	Cleared upon entering connected mode in another RAT	
UE radio access capability	OP		UE radio access capabilit y 10.3.3.4	Cleared upon entering connected mode in another RAT	
UE radio access capability extension	OP		UE radio access capabilit y extensio n 10.3.3.4 2a	Cleared upon entering connected mode in another RAT	
UE radio access capability compressed	OP		UE radio access capabilit y compres sed 10.3.3.4 20		REL-5
UE system specific capability	OP	1 to <maxsyst emCapab ility></maxsyst 	Inter- RAT UE radio access capabilit y 10.3.8.7	Cleared upon entering connected mode in another RAT	
>Inter-RAT UE radio access capability	MP		Inter- RAT UE radio access capabilit y 10.3.8.7		

13.4.11 INVALID_CONFIGURATION

This variable indicates whether a received message contained an invalid configuration, by means of invalid values or invalid combinations of information elements.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Invalid configuration	MP		Boolean	TRUE: An invalid configuration has been detected. Set to FALSE when entering UTRA RRC connected mode. Set to FALSE when leaving UTRA RRC connected mode.

13.4.11a LATEST_CONFIGURED_CN_DOMAIN

This variable stores the CN-domain that was most recently configured to be used for ciphering and integrity protection.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Latest configured CN domain	OP		CN domain identity 10.3.1.1	Cleared when entering UTRA RRC connected mode when not stated otherwise in the procedure. Cleared when leaving UTRA RRC connected mode.

13.4.11b LATEST_CONFIGURED_SRB_DELAY_AND_PC_PREAMBLE

This variable stores the SRB delay and PC preamble to be used for establishing the DPCH after failure of hard handover, inter-RAT handover from UTRAN, or cell change order from UTRAN.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
SRB delay	OP		Integer (07)	Cleared when entering UTRA RRC connected mode when not stated otherwise in the procedure.
PC preamble	OP		Integer (07)	Cleared when entering UTRA RRC connected mode when not stated otherwise in the procedure.

13.4.12 MEASUREMENT_IDENTITY

This variable stores the measurements configured in the UE. For each configured measurement, the information below shall be stored.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
MEASUREMENT CONTROL	OP		MEASUREM ENT CONTROL 10.2.17, System Information Block type 11 10.2.48.8.12, System Information Block type 12 10.2.48.8.13	Information as contained in these messages. Cleared when entering UTRA RRC connected mode when not stated otherwise in the procedure (8.4.1.8-8.4.1.9). Cleared when leaving UTRA RRC connected mode when not stated otherwise in the procedure (8.4.1.9a).

13.4.13 Void

13.4.14 ORDERED_RECONFIGURATION

This variable stores information about an ongoing Reconfiguration procedure.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Ordered reconfiguration	МР		Boolean	TRUE means that a Reconfiguration procedure is ongoing. Set to FALSE when entering UTRA RRC connected mode. Set to FALSE when leaving UTRA RRC connected mode.

13.4.15 PDCP_SN_INFO

This variable contains PDCP receive sequence numbers for one or several radio bearers to be included in a response message to UTRAN.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
RB with PDCP information list	OP	1 to <maxrball RABs></maxrball 		Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode.
>RB with PDCP information	MP		RB with PDCP information 10.3.4.22	

13.4.15a PHYSICAL_SHARED_CHANNEL_CONFIGURATION

This variable is used only for TDD to store information about the physical shared channel configuration in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
PUSCH configuration	OP			Cleared when entering and leaving UTRA RRC connected mode.
>PUSCH info	MP		PUSCH info 10.3.6.63	
>PUSCH Identity	OP		Integer(1 hiPUSCHide ntities)	
>PUSCH power control info	OP		PUSCH power control info 10.3.6.65	
PDSCH configuration	OP			Cleared when entering and leaving UTRA RRC connected mode.
>PDSCH Info	MP		PDSCH Info 10.3.6.44	
>PDSCH Identity	OP		Integer(1hi PDSCHident ities)	
>PDSCH power control info	OP		PDSCH power control info 10.3.6.45	
ISCP Timeslot list	OP	1 to maxTS		Cleared when entering and leaving UTRA RRC connected mode.
>Timeslot number	MP		Timeslot number 10.3.6.84	Timeslot numbers, for which the UE shall report the timeslot ISCP in PUSCH CAPACITY REQUEST message

13.4.16 PROTOCOL_ERROR_INDICATOR

This variable indicates whether there exist a protocol error that is to be reported to UTRAN.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Protocol error indicator	MP		Protocol error indicator 10.3.3.27	Set to FALSE when entering UTRA RRC connected mode. Set to FALSE when leaving UTRA RRC connected mode.

13.4.17 PROTOCOL_ERROR_INFORMATION

This variable contains diagnostics to be reported to UTRAN for a message that was not completely understood.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Protocol error information	OP		Protocol	Cleared when entering UTRA
			error	RRC connected mode.
			information	Cleared when leaving UTRA
			10.3.8.12	RRC connected mode.

13.4.18 PROTOCOL_ERROR_REJECT

This variable indicates whether there has occurred a severe protocol error causing the ongoing procedure to fail.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Protocol error reject	MP		Boolean	TRUE: a severe protocol error has occurred. Set to FALSE when entering UTRA RRC connected mode. Set to FALSE when leaving UTRA RRC connected mode.

13.4.19 RB_TIMER_INDICATOR

This variable contains information to be sent to UTRAN if any of the timers T314 or T315 has expired when the UE sends a cell update with cause RL failure.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
RB timer indicator	OP		RB timer indicator 10.3.3.28	Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode.

13.4.20 RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO

This variable contains information to be sent to UTRAN about when a new ciphering configuration shall be activated in the uplink for radio bearers using RLC-AM or RLC-UM.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
RB uplink ciphering activation time info	OP		RB activation time info 10.3.4.13	Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode.

13.4.20a SECURITY_MODIFICATION

This variable contains information on which CN domain is affected by the ongoing security reconfiguration.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Status for each CN domain	MP	<1 to maxCNDo mains>		
>CN domain identity	MP		CN domain identity 10.3.1.1	
>Status	MP		Enumerated(Affected, Not Affected)	

13.4.21 SELECTED_PLMN

This variable contains the type of and identity of the selected PLMN.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
PLMN Type	MP		PLMN Type	
			10.3.1.12	
CHOICE identity type	MP			
>PLMN identity			PLMN	
			identity	
			10.3.1.11	
>SID			SID	
			10.3.9.11	

CHOICE identity type	Condition under which the given <i>identity type</i> is chosen			
PLMN identity	PLMN Type is "GSM-MAP"			
SID	PLMN Type is "ANSI-41"			

13.4.22 START_THRESHOLD

This variable contains information about the maximum allowed value of the START for a CN domain.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
THRESHOLD	ОР		Integer (01048576)	20 bits. Cleared when entering UTRA RRC connected mode when not stated otherwise in the procedure. Cleared when leaving UTRA RRC connected mode.

13.4.23 START_VALUE_TO_TRANSMIT

This variable contains the value of START for new radio bearer(s) to be transmitted in a response message.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
START	OP		START 10.3.3.38	Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode.

13.4.24 TFC_SUBSET

This variable contains information about the TFC subset(s) applicable to the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
CHOICE mode	MP				
>FDD					
>>Current TFC subset	MP		Transport Format Combinati on Subset 10.3.5.22	Set to "Full transport format set" when entering UTRA RRC connected mode when not stated otherwise in the procedure.	
>>Duration	OP		TFC Control duration 10.3.6.80	Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode.	
>>Default TFC subset	OP		Transport	The TFC subset to go	

Information	Need	Multi	Type and reference	Semantics description	Version
Element/Group name			Format Combinati on Subset 10.3.5.22	back to when any temporary limitation is released. Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode.	
>>TFC subset list	MP	1 to <maxtf Csub></maxtf 			REL-4
>>>TFC subset	MP		Transport Format Combinati on Subset 10.3.5.22		REL-4
>TDD >>TFCS list	MP	1 to < maxCCT rCH >		One TFCS is created when entering UTRA RRC connected mode when not stated otherwise in the procedure.	
>>>TFCS identity	MP		Transport Format Combinati on Set Identity 10.3.5.21	"TFCS ID" is set to 1 when entering UTRA RRC connected mode when not stated otherwise in the procedure. "Shared channel indicator" is set to FALSE when entering UTRA RRC connected mode when not stated otherwise in the procedure.	
>>>Current TFC subset	MP		Transport Format Combinati on Subset 10.3.5.22	Set to "Full transport format set" when entering UTRA RRC connected mode when not stated otherwise in the procedure.	
>>>>Duration	OP		TFC Control duration 10.3.6.80	Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode.	
>>>>Default TFC subset	OP		Transport Format Combinati on Subset 10.3.5.22	The TFC subset to go back to when any temporary limitation is released. Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode.	

Information	Need	Multi	Type and	Semantics description	Version
Element/Group name			reference		
>>TFC subset list	MP	1 to			REL-4
		<maxtf< td=""><td></td><td></td><td></td></maxtf<>			
		Csub>			
>>>TFCS identity	MP		Transport		REL-4
-			Format		
			Combinati		
			on Set		
			Identity		
			10.3.5.21		
>>>TFC subset	MP		Transport		REL-4
			Format		
			Combinati		
			on Subset		
			10.3.5.22		

13.4.25 TGPS_IDENTITY

This variable contains the configuration parameters of all the configured compressed mode transmission gap pattern sequences.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Transmission gap pattern sequence	OP	1 to <maxtgp S></maxtgp 		Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode.
>TGPSI	MP		TGPSI 10.3.6.82	
>TGPS Status Flag	MP		Enumerated(activate, deactivate)	This flag indicates whether the Transmission Gap Pattern Sequence shall be activated or deactivated.
> Current TGPS Status Flag	MP		Enumerated(active, inactive)	This flag indicates the current status of the Transmission Gap Pattern Sequence, whether it is active or inactive
>TGCFN	CV-Active		Integer (0255)	Connection Frame Number of the first frame of the first pattern within the Transmission Gap Pattern Sequence.
>Transmission gap pattern sequence configuration parameters	MP			Information as contained in the IE group "Transmission gap pattern sequence configuration parameters" in IE "DPCH compressed mode info" 10.3.6.33.

Condition	Explanation		
Active	This IE is mandatory present when the value of the IE "TGPS Status Flag" is "Activate" and not needed		
	otherwise.		

13.4.26 TGSN_REPORTED

This variable specifies whether an IE "Proposed TGSN" was reported to the UTRAN

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Proposed TGSN reported	MP		Boolean	Set to FALSE when entering UTRA RRC connected mode. Set to FALSE when leaving
				UTRA RRC connected mode.

13.4.26a TIMERS_AND_CONSTANTS

This variable contains the values for all timers and constants used in connected mode.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
UE Timers and constants in connected mode	MD		UE Timers and constants in connected mode 10.3.3.43	Default value means that for all timers and constants - for parameters with need MD, the defaults specified in 10.3.3.43 apply and - for parameters with need OP, the parameters are absent. All parameters are set to the default value when leaving UTRA RRC connected mode to another RAT.

13.4.27 TRANSACTIONS

This variable stores the identifications of the ongoing RRC procedure transactions.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	-
Accepted transactions	OP	1 to		Cleared when leaving UTRA
·		<maxtrans< td=""><td></td><td>RRC connected mode.</td></maxtrans<>		RRC connected mode.
		actions>		
>Message type	MP		Message	
			Type	
>RRC transaction identifier	MP		RRC	
			transaction	
			identifier	
			10.3.3.36	
Rejected transactions	OP	1 to		Cleared when leaving UTRA
		<maxtrans< td=""><td></td><td>RRC connected mode.</td></maxtrans<>		RRC connected mode.
		actions>		
>Message type	MP		Message	
			Type	
>RRC transaction identifier	MP		RRC	
			transaction	
			identifier	
			10.3.3.36	

13.4.27a TRIGGERED_1A_EVENT

This variable contains information about a 1a event that has been triggered in the UE. There is one such variable per 1a event configured in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Cells triggered	OP	1 to <		Cleared when entering UTRA
		maxCellMe		RRC connected mode.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
		as>		Cleared when leaving UTRA RRC connected mode.
>primary CPICH	MP		Primary CPICH info 10.3.6.60	
>sent reports	MP		Integer(1Inf inity)	Number of reports sent to UTRAN in case of event triggered periodical reporting
Cells recently triggered	OP	1 to < maxCellMe as>		
>primary CPICH	MP		Primary CPICH info 10.3.6.60	
>sent reports	MP		Integer(1Inf inity)	Number of reports sent to UTRAN in case of event triggered periodical reporting
Periodical reporting running	MP		Boolean	

13.4.27bTRIGGERED_1B_EVENT

This variable contains information about a 1b event that has been triggered in the UE. There is one such variable per 1b event configured in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
Cells triggered	OP	1 to < maxCell Meas>		Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode.	
>primary CPICH	MP		Primary CPICH info 10.3.6.60		
>sent reports	MP		Integer(1 Infinity)	Number of reports sent to UTRAN in case of event triggered periodical reporting	REL-5
Cells recently triggered	OP	1 to < maxCell Meas>			REL-5
>primary CPICH	MP		Primary CPICH info 10.3.6.60		REL-5
>sent reports	MP		Integer(1 Infinity)	Number of reports sent to UTRAN in case of event triggered periodical reporting.	REL-5
Periodical reporting running	MP		Boolean		REL-5

13.4.27c TRIGGERED_1C_EVENT

This variable contains information about a 1c event that has been triggered in the UE. There is one such variable per 1c event configured in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Cells triggered	OP	1 to < maxCellMe as>		Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode.
>primary CPICH	MP		Primary CPICH info 10.3.6.60	
>sent reports	MP		Integer(1Inf inity)	Number of reports sent to UTRAN in case of event triggered periodical reporting
Cells recently triggered	OP	1 to < maxCellMe as>		
>primary CPICH	MP		Primary CPICH info 10.3.6.60	
>sent reports	MP		Integer(1Inf inity)	Number of reports sent to UTRAN in case of event triggered periodical reporting
Periodical reporting running	MP		Boolean	

13.4.27dBEST_CELL_1D_EVENT

This variable contains information about a 1d event that has been triggered in the UE. There is one such variable per 1d event configured in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Best cell	OP		Primary CPICH info 10.3.6.60	Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode.

13.4.27e TRIGGERED_1E_EVENT

This variable contains information about a 1e event that has been triggered in the UE. There is one such variable per 1e event configured in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Cells triggered	OP	1 to < maxCellMe as>		Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode.
>primary CPICH	MP		Primary CPICH info 10.3.6.60	
Cells recently triggered	OP	1 to < maxCellMe as>		
>primary CPICH	MP		Primary CPICH info 10.3.6.60	

13.4.27f TRIGGERED_1F_EVENT

This variable contains information about a 1f event that has been triggered in the UE. There is one such variable per 1f event configured in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Cells triggered	OP	1 to < maxCellMe as>		Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode.
>primary CPICH	MP		Primary CPICH info 10.3.6.60	
Cells recently triggered	OP	1 to < maxCellMe as>		
>primary CPICH	MP		Primary CPICH info 10.3.6.60	

13.4.27f1 TRIGGERED_1G_EVENT

This variable contains information about a 1g event that has been triggered in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Cells triggered	OP	1 to < maxCellMe as>		
>Primary CCPCH info	MP		Primary CCPCH info 10.3.6.57	

13.4.27f2 TRIGGERED_1H_EVENT

This variable contains information about a 1h event that has been triggered in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Cells triggered	OP	1 to < maxCellMe as>		
>Primary CCPCH info	MP		Primary CCPCH info 10.3.6.57	

13.4.27f3 TRIGGERED_1I_EVENT

This variable contains information about a 1i event that has been triggered in the UE.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Cells triggered	OP	1 to <		
		maxCellMe		
		as>		
>Primary CCPCH info	MP		Primary	
-			CCPCH info	
			10.3.6.57	

13.4.27f4 BEST_FREQUENCY_2A_EVENT

This variable contains information about a 2a event that has been configured in the UE. There is one such variable per 2a event configured in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Best frequency	MP		Frequency	
			info	
			10.3.6.36	

13.4.27f5 TRIGGERED_2B_EVENT

This variable contains information about a 2b event that has been configured in the UE. There is one such variable per 2b event configured in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Frequency triggered	OP	1 to < maxCellMe as>		
>Frequency	MP	Frequency info 10.3.6.36		

13.4.27f6 TRIGGERED_2C_EVENT

This variable contains information about a 2c event that has been configured in the UE. There is one such variable per 2c event configured in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Frequency triggered	OP	1 to < maxCellMe as>		
>Frequency	MP	Frequency info 10.3.6.36		

13.4.27f7 TRIGGERED_2D_EVENT

This variable contains information about a 2d event that has been configured in the UE. There is one such variable per 2d event configured in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Event triggered	OP		Boolean	

13.4.27f8 TRIGGERED_2E_EVENT

This variable contains information about a 2e event that has been configured in the UE. There is one such variable per 2e event configured in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Frequency triggered	OP	1 to < maxCellMe as>		
>Frequency	MP	Frequency info 10.3.6.36		

13.4.27f9 TRIGGERED_2F_EVENT

This variable contains information about a 2f event that have been configured in the UE. There is one such variable per 2f event configured in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Event triggered	OP		Boolean	

13.4.27f10 TRIGGERED_3A_EVENT

This variable contains information about a 3a event that has been configured in the UE. There is one such variable per event 3a configured in the UE.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
CHOICE system	OP			
>GSM				
>>CHOICE BSIC	MP			
>>>Verified BSIC		0 to <maxcellm eas></maxcellm 		
>>>Inter-RAT cell id	MP		Integer(0< maxCellMea s>-1)	
>>>Non verified BSIC		0 to <maxcellm eas></maxcellm 		
>>>BCCH ARFCN	MP		Integer (01023)	

13.4.27f11 TRIGGERED_3B_EVENT

This variable contains information about a 3b event that has been configured in the UE. There is one such variable per event 3b configured in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE system	OP			
>GSM				
>>CHOICE BSIC	MP			
>>>Verified BSIC		0 to <maxcellm eas></maxcellm 		
>>>Inter-RAT cell id	MP		Integer(0< maxCellMea s>-1)	
>>>Non verified BSIC		0 to <maxcellm eas></maxcellm 	,	
>>>BCCH ARFCN	MP		Integer (01023)	

13.4.27f12 TRIGGERED_3C_EVENT

This variable contains information about a 3c event that has been configured in the UE. There is one such variable per event 3c configured in the UE.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
CHOICE system	OP			
>GSM				
>>CHOICE BSIC	MP			
>>>Verified BSIC		0 to		
		<maxcellm< td=""><td></td><td></td></maxcellm<>		
		eas>		
>>>>Inter-RAT cell id	MP		Integer(0< maxCellMea s>-1)	
>>>Non verified BSIC		0 to <maxcellm eas></maxcellm 	·	
>>>BCCH ARFCN	MP		Integer (01023)	

13.4.27f13 BEST_CELL_3D_EVENT

This variable contains information about a 3d event that has been configured in the UE. There is one such variable per event 3a configured in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE system				
>GSM				
>>CHOICE BSIC	MP			
>>>Verified BSIC				
>>>Inter-RAT cell id	MP		Integer(0< maxCellMea s>-1)	
>>>Non verified BSIC				
>>>BCCH ARFCN	MP		Integer (01023)	

13.4.27f14 TRIGGERED_6A_EVENT

This variable contains information about a 6a event that has been configured in the UE. There is one such variable per 6a event configured in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Event triggered	OP		Boolean	

13.4.27f15 TRIGGERED_6B_EVENT

This variable contains information about a 6b event that has been configured in the UE. There is one such variable per 6b event configured in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Event triggered	OP		Boolean	

13.4.27f16 TRIGGERED_6C_EVENT

This variable contains information about a 6c event that has been configured in the UE. There is one such variable per 6c event configured in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Event triggered	OP		Boolean	

13.4.27f17 TRIGGERED_6D_EVENT

This variable contains information about a 6d event that has been configured in the UE. There is one such variable per 6d event configured in the UE.

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
Event triggered	OP		Boolean	

13.4.27f18 TRIGGERED_6E_EVENT

This variable contains information about a 6e event that has been configured in the UE. There is one such variable per 6e event configured in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Event triggered	OP		Boolean	

13.4.27f19 TRIGGERED_6F_EVENT

This variable contains information about a 6f event that has been configured in the UE. There is one such variable per 6f event configured in the UE.

Information	Need	Multi	Type and	Semantics description	Version
Element/Group name			reference		
CHOICE mode					
>FDD					
Event triggered_RL	OP	<maxrl< td=""><td>Boolean</td><td></td><td></td></maxrl<>	Boolean		
		>			
>1.28 Mcps TDD					REL-4
>>T _{ADV}	MP		TADV info		REL-4
			10.3.7.11		
			2		

13.4.27f20 TRIGGERED_6G_EVENT

This variable contains information about a 6g event that has been configured in the UE. There is one such variable per 6g event configured in the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Event triggered_RL	OP	<maxrl></maxrl>	Boolean	

13.4.27g UE_CAPABILITY_REQUESTED

This variable stores information about the UE capabilities that have been requested by UTRAN but that have not yet been transferred to UTRAN.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
UE radio access capability	OP		UE radio access capability 10.3.3.42	Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode.
UE radio access capability extension	OP		UE radio access capability extension 10.3.3.42a	Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode.
UE system specific capability	OP	1 to < maxInterSy sMessages >		
>Inter-RAT UE radio access capability	MP		Inter-RAT UE radio access capability 10.3.8.7	Includes inter-RAT classmark. Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode.

13.4.28 UE_CAPABILITY_TRANSFERRED

This variable stores information about which UE capabilities that have been transferred to UTRAN.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
UE radio access capability	OP		UE radio access capability 10.3.3.42	Cleared when entering UTRA RRC connected mode when not stated otherwise in the procedure. Cleared when leaving UTRA RRC connected mode.
UE radio access capability extension	OP		UE radio access capability	Cleared when entering UTRA RRC connected mode when not stated otherwise in the

Information Element/Group name	Need	Multi	Type and reference	Semantics description
			extension 10.3.3.42a	procedure. Cleared when leaving UTRA RRC connected mode.
UE system specific capability	OP	1 to <maxsyste mCapabilit y></maxsyste 		
>Inter-RAT UE radio access capability	MP		Inter-RAT UE radio access capability 10.3.8.7	Includes inter-RAT classmark. Cleared when entering UTRA RRC connected mode when not stated otherwise in the procedure. Cleared when leaving UTRA RRC connected mode.

13.4.28a UE_POSITIONING_GPS_DATA

Information Element/Group	Need	Multi	Type and	Semantics description
name	Need	With	reference	Semantics description
GPS Data ciphering info	OP		UE	
or o bata diprioring into	Oi		positioning	
			Ciphering	
			info	
			10.3.7.86	
GPS Deciphering Keys	OP			
>Current deciphering key	MP		Bit string(56)	
>Next deciphering key	MP		Bit string(56)	
UE positioning GPS reference	OP		UE	
time			positioning	
			GPS	
			reference	
			time	
			10.3.7.96	
UE positioning GPS reference	OP		Ellipsoid	A priori knowledge of UE 3-D
UE position			point with	position.
			altitude and	
			uncertainty	
			ellipsoid	
			10.3.8.4c	
UE positioning GPS DGPS	OP		UE	
corrections			positioning	
			GPS DGPS	
			corrections	
115 ''' : 000 : "	0.5	4.	10.3.7.91	
UE positioning GPS navigation	OP	1 to		
model >SatID	MP	<maxsat></maxsat>	Francisco e marka el/	Satellite ID
>5atiD	MP		Enumerated(063)	Satellite ID
>GPS Ephemeris and Clock	MP		UE	
Correction parameters	IVIF		positioning	
Correction parameters			GPS	
			Ephemeris	
			and Clock	
			Correction	
			parameters	
			10.3.7.91a	
UE positioning GPS ionospheric	OP		UE	
model			positioning	
			GPS	
			ionospheric	
			model	
			10.3.7.92	
UE positioning GPS UTC model	OP		UE	
			positioning	

Information Element/Group name	Need	Multi	Type and reference	Semantics description
			GPS UTC	
			model	
			10.3.7.97	
UE positioning GPS almanac	OP			
>SatID	MP	1 to		
		<maxsatal< td=""><td></td><td></td></maxsatal<>		
		manacStor		
		age>		
>>WN _a	MP			Same as IE in 10.3.7.89
>>DataID	MP			Same as IE in 10.3.7.89
>>e	MP			Same as IE in 10.3.7.89
>>t _{oa}	MP			Same as IE in 10.3.7.89
>>δl	MP			Same as IE in 10.3.7.89
>>OMEGADOT	MP			Same as IE in 10.3.7.89
>>SV Health	MP			Same as IE in 10.3.7.89
>>A ^{1/2}	MP			Same as IE in 10.3.7.89
>>OMEGA ₀	MP			Same as IE in 10.3.7.89
>>M ₀	MP			Same as IE in 10.3.7.89
>>w	MP			Same as IE in 10.3.7.89
>>af ₀	MP			Same as IE in 10.3.7.89
>>af ₁	MP			Same as IE in 10.3.7.89
>SV Global Health	OP			Same as IE in 10.3.7.89
UE positioning GPS acquisition	OP		UE	
assistance			positioning	
			GPS	
			acquisition	
			assistance	
			10.3.7.88	
UE positioning GPS real-time	OP		UE	
integrity			positioning	
			GPS real-	
			time integrity	
			10.3.7.95	

13.4.28b UE_POSITIONING_OTDOA_DATA_UE_ASSISTED

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
UE positioning OTDOA reference cell info for UE-assisted	OP		UE positioning OTDOA reference cell info 10.3.7.108	
UE positioning OTDOA neighbour cell list for UE- assisted	OP	1 to <maxcellm eas></maxcellm 		
>UE positioning OTDOA neighbour cell info for UE- assisted	MP		UE positioning OTDOA neighbour cell info 10.3.7.106	

13.4.28c UE_POSITIONING_OTDOA_DATA_UE_BASED

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
OTDOA Deciphering Keys	OP			
>Current deciphering key	MP		Bit string(56)	
>Next deciphering key	MP		Bit string(56)	
OTDOA Data ciphering info	OP		UE	
			positioning	
			Ciphering	
			info	
			10.3.7.86	
UE positioning OTDOA	OP		UE	
reference cell info for UE-based			positioning	
			OTDOA	
			reference	
			cell info for	
			UE-based	
			10.3.7.108a	
UE positioning OTDOA	OP	1 to		
neighbour cell list for UE-based		<maxcellm< td=""><td></td><td></td></maxcellm<>		
		eas>		
>UE positioning OTDOA	MP		UE	
neighbour cell info for UE-based			positioning	
			OTDOA	
			neighbour	
			cell info for	
			UE-based	
			10.3.7.106	

13.4.29 UNSUPPORTED_CONFIGURATION

This variable indicates whether a received message contained a configuration that is not supported by the UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Unsupported configuration	MP		Boolean	TRUE: An unsupported configuration has been detected. Set to FALSE when entering UTRA RRC connected mode. Set to FALSE when leaving UTRA RRC connected mode.

13.4.30 URA_IDENTITY

This variable stores the assigned URA identity for this UE when in URA_PCH state.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
URA identity	OP		URA identity 10.3.2.6	Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode.

13.4.31 U_RNTI

This variable stores the assigned U-RNTI for this UE.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
U-RNTI	OP		U-RNTI 10.3.3.47	Cleared when leaving UTRA RRC connected mode.

13.4.32 VALUE_TAG

This variable contains information about the value tag for the last received system information block of a given type, for all system information blocks using value tags. The UE shall maintain one instance of this variable for the current selected cell. The UE may store several instances of this variable, one for each cell, to be used if the UE returns to these cells.

All IEs in this variable shall be cleared when switched off. All IEs in this variable except for the IE "SIB 16 value tag list" shall be cleared at selection of a new PLMN. The IE "SIB 16 value tag list" is cleared at selection of a new PLMN which is not indicated by higher layers to be equivalent to the previously selected PLMN.

Information Element/Group name	Need	Multi	Type and reference	Semantics description
MIB value tag	OP		MIB value	Value tag for the master
, and the second			tag 10.3.8.9	information block
SB 1 value tag	OP		Cell value	Value tag for the scheduling
			tag 10.3.8.4	block type 1
SB 2 value tag	OP		Cell value	Value tag for the scheduling
			tag 10.3.8.4	block type 2
SIB 1 value tag	CV-GSM		PLMN value	Value tag for the system
ŭ			tag 10.3.8.10	information block type 1
SIB 2 value tag	OP		Cell value	Value tag for the system
Ğ			tag 10.3.8.4	information block type 2
SIB 3 value tag	OP		Cell value	Value tag for the system
			tag 10.3.8.4	information block type 3
SIB 4 value tag	OP		Cell value	Value tag for the system
3			tag 10.3.8.4	information block type 4
SIB 5 value tag	OP		Cell value	Value tag for the system
O.D. o value tag	0.		tag 10.3.8.4	information block type 5
SIB 6 value tag	OP	1	Cell value	Value tag for the system
CID o value tag			tag 10.3.8.4	information block type 6
CHOICE mode	MP		tag 10.0.0.1	miorination block type c
>FDD	IVII			
>>SIB 8 value tag	OP		Cell value	Value tag for the system
Sib 6 value tag	OF .		tag 10.3.8.4	information block type 8
, TDD			tag 10.3.0.4	· · ·
>TDD	OP		Cell value	(no data) Value tag for the system
SIB 11 value tag	UP			
CID 40 value tea	OP		tag 10.3.8.4	information block type 11
SIB 12 value tag	OP		Cell value	Value tag for the system
CID 42 value to a	CV/ ANICI		tag 10.3.8.4	information block type 12
SIB 13 value tag	CV-ANSI		Cell value	Value tag for the system
OID 40.4 value 45 5	0)/ 44/0/		tag 10.3.8.4	information block type 13
SIB 13.1 value tag	CV-ANSI		Cell value	Value tag for the system
015 40 0	0)/ 44/0/		tag 10.3.8.4	information block type 13.1
SIB 13.2 value tag	CV-ANSI		Cell value	Value tag for the system
	01/ 11/0/		tag 10.3.8.4	information block type 13.2
SIB 13.3 value tag	CV-ANSI		Cell value	Value tag for the system
	01/ 11/0/		tag 10.3.8.4	information block type 13.3
SIB 13.4 value tag	CV-ANSI		Cell value	Value tag for the system
			tag 10.3.8.4	information block type 13.4
SIB 15 value tag	OP		Cell value	Value tag for the system
		1	tag 10.3.8.4	information block type 15
SIB 15.1 value tag	OP		Cell value	Value tag for the system
			tag 10.3.8.4	information block type 15.1
SIB 15.2 value tag list	OP	1 to		List of value tags for all stored
		<maxsat></maxsat>		occurrences of system
				information block type 15.2
>SIB 15.2 value tag	MP		Cell value	
			tag 10.3.8.4	
>SIB occurrence identity and	MP		SIB	

Information Element/Group name	Need	Multi	Type and reference	Semantics description
value tag			occurrence identity and value tag 10.3.8.20b	
SIB 15.3 value tag list	OP	1 to <maxsat></maxsat>		List of value tags for all stored occurrences of system information block type 15.3
>SIB 15.3 value tag	MP		PLMN value tag 10.3.8.10	Value tag for the system information block type 15.3
>SIB occurrence identity and value tag	MP		SIB occurrence identity and value tag 10.3.8.20b	
SIB 15.4 value tag	OP		Cell value tag 10.3.8.4	Value tag for the system information block type 15.4
SIB 15.5 value tag	OP		Cell value tag 10.3.8.4	Value tag for the system information block type 15.5
SIB 16 value tag list	OP	1 to <maxpred efConfig></maxpred 		List of value tags for all stored occurrences of the system information block type 16
>Predefined configuration identity and value tag	MP		Predefined configuration identity and value tag 10.3.8.11	
SIB 18 value tag	OP		Cell value tag 10.3.8.4	Value tag for the system information block type 18

Condition	Explanation
GSM	This information is optional when the PLMN Type in the variable SELECTED_PLMN is "GSM-MAP" and never stored otherwise.
ANSI	This information is optional when the PLMN Type in the variable SELECTED_PLMN is "ANSI-41" and never stored otherwise.

13.5 UE RRC Procedure Performance

This subclause defines the performance requirements related to RRC procedures in the UE. Where the total delay is impacted by processing of variable length on the physical layer (e.g. physical layer synchronisation), references to appropriate specifications are given.

13.5.1 Definitions

The following definitions of N1 and N2 are valid only for this UE RRC Procedure Performance specification.

N1 = upper limit on the time required to execute modifications in UE after the reception of a UTRAN -> UE message has been completed. Where applicable (e.g. the physical layer transmission is impacted), the changes shall be adopted in the beginning of the next TTI starting after N1. N1 is specified as a multiple of 10 ms.

N2 = number of 10 ms radio frames from end of reception of UTRAN -> UE message on UE physical layer before the transmission of the UE -> UTRAN response message must be ready to start on a transport channel with no access delay other than the TTI alignment (e.g. DCH, therefore excluding delays caused by RACH procedure etc). The UE response message transmission from the physical layer shall begin at the latest (N2*10)+TTI ms after completion of the reception of the last TTI carrying the triggering UTRAN -> UE message. When Target State is CELL_DCH, the UE response message transmission from the physical layer may be additionally delayed by the value of IE "SRB delay".

N1 and N2 are independent (e.g. N2-N1 is not restricted to being less than or equal to 10ms).

13.5.2 RRC procedure performance values

NOTE: Times indicated in the table do not include cell reselection.

RRC Connection Management Procedures Broadcast of system Information INFORMATION SYSTEM INFORMATION SYSTEM INFORMATION INFORMATION SYSTEM INFORMATION INFORMATION SYSTEM INFORMATION INFORMATION INFORMATION INFORMATION INFORMATION INFORMATION INFORMATION	Procedure title:	UTRAN -> UE	UE -> UTRAN	N1	N2	Notes
Broadcast of system information SYSTEM	RRC Connection					
Information INFORMATION System Information messages, because there is not response message from the UE.	Management Procedures					
Information INFORMATION System Information messages, because there is no response message from the UE.	Broadcast of system	SYSTEM				N2 is not applicable for any
Master Information Block Master Information Block Master Information Block INFORMATION SYSTEM INFORMATION INFORMATION SYSTEM INFORMATION System Information Block type INFORMATION INF		INFORMATION				
Master Information Block SYSTEM INFORMATION SYSTEM INFORMA						
Master Information Block SYSTEM INFORMATION SYSTEM INFORMATION System Information Block type 1 System Information Block type 4 System Information Block type 5 System Information Block type 6 System Information Block type 7 System Information Block type 8 System Information Block type 9 System Information Block type 1 System Information Block type 1 System Information Block type 4 INFORMATION System Information Block type 5 System Information Block type 6 System Information Block type 7 System Information Block type 8 System Information Block type 9 System Information Block type 1 InFORMATION System Information Block type 1 InFORMATION System Information Block type 1 InFORMATION System Informa						
INFORMATION Shall be lost due to processing of a MIB received with no detectable errors. This means that the UE shall buffer all system information data received after the MIB until the data can be processed according to the information in the MIB, unless the MIB was received erroneously. System Information Block type INFORMATION System Information Block type SYSTEM INFORMATION INFORMATIO	Master Information Block	SYSTEM		5	NA	
of a MIB received with no detectable errors. This means that the UE shall buffer all system information data received after the MIB until the data can be processed according to the information in the MIB, unless the MIB was received erroneously. System Information Block type 1 NFORMATION 2 SYSTEM 10 NA 1	master information 2.55tt					
System Information Block type SYSTEM NFORMATION System Information Block type SYSTEM INFORMATION INFORMATI						
that the UE shall buffer all system information data received after the MIB until the data can be processed according to the information in the MIB, unless the MIB was received erroneously. System Information Block type 2						
System Information Block type 10						
System Information Block type 1 SYSTEM INFORMATION 10 NA INFORMATION 29 NA INFORMATION 10 NA INFORMATI						
System Information Block type 1						
System Information Block type INFORMATION System Information Block type INFORMATION System Information Block type INFORMATION System Information Block type SYSTEM INFORMATION System Information Block type SYSTEM INFORMATION System Information Block type INFORMATION INFO						
System Information Block type 1NFORMATION 2YSTEM 1NFORMATION 3YSTEM 3YSTEM 3NA						
System Information Block type SYSTEM INFORMATION SYSTEM INFORMATION SYSTEM INFORMATION SYSTEM INFORMATION SYSTEM INFORMATION SYSTEM INFORMATION System Information Block type SYSTEM INFORMATION INFO						
System Information Block type 1						
1	System Information Block type	CVCTEM		10	NΙΛ	received enoneously.
System Information Block type 2	1			10	INA	
2	System Information Block type			10	NΙΛ	
System Information Block type SYSTEM INFORMATION SYSTEM INFORMATION INFORM				10	INA	
System Information Block type SYSTEM 10				10	NΙΛ	
System Information Block type 4				10	INA	
System Information Block type SYSTEM 10				10	NIA	
System Information Block type SYSTEM INFORMATION System Information Block type SYSTEM INFORMATION System Information Block type To INFORMATION System Information Block type SYSTEM INFORMATION INF	a system information block type			10	INA	
System Information Block type SYSTEM INFORMATION	Cyatam Information Disaletyna			10	NΙΛ	
System Information Block type 6	1 = -			10	INA	
System Information Block type SYSTEM INFORMATION SY				10	NΙΛ	
System Information Block type 7 INFORMATION System Information Block type 8 INFORMATION System Information Block type 9 INFORMATION System Information Block type 10 INFORMATION System Information Block type 11 INFORMATION System Information Block type 12 System Information Block type 13 INFORMATION System Information Block type 14 INFORMATION System Information Block type 15 INA INFORMATION TO NA INFORMATION TO NA INFORMATION System Information Block type 10 INFORMATION System Information Block type 11 INFORMATION System Information Block type 12 System Information Block type 13 INFORMATION System Information Block type 14 INFORMATION System Information Block type SYSTEM INFORMATION INFORMATION System Information Block type SYSTEM INFORMATION INFORMATION INFORMATION INFORMATION System Information Block type SYSTEM INFORMATION INFORMAT				10	INA	
7 INFORMATION System Information Block type SYSTEM INFORMATION	_			-	NIA.	
System Information Block type 8 SYSTEM INFORMATION 5 System Information Block type 9 INFORMATION 5 System Information Block type 10 INFORMATION 5 System Information Block type 10 INFORMATION 5 System Information Block type 11 INFORMATION 5 System Information Block type 11 INFORMATION 5 System Information Block type 12 INFORMATION 5 System Information Block type 13 INFORMATION 5 System Information Block type 13 INFORMATION 5 System Information Block type 14 INFORMATION 5 System Information Block type 5 SYSTEM 10 INFORMATION 5 System Information Block type 5 SYSTEM 10 INFORMATION 10 INF				Э	INA	
System Information Block type SYSTEM 10 System Information Block type SYSTEM 10 NA INFORMATION System Information Block type SYSTEM				4.0	N 1 A	
System Information Block type SYSTEM INFORMATION 5 NA 9 INFORMATION 5 NA System Information Block type SYSTEM INFORMATION 10 NA 11 INFORMATION 10 NA 12 INFORMATION 10 NA 12 INFORMATION 10 NA 13 INFORMATION 10 NA 13 INFORMATION 10 NA System Information Block type SYSTEM INFORMATION 10 NA System Information Block type SYSTEM INFORMATION 10 NA System Information Block type SYSTEM INFORMATION 10 NA	_ · ·			10	NA	
9 INFORMATION System Information Block type SYSTEM 10 INFORMATION System Information Block type SYSTEM 11 INFORMATION System Information Block type SYSTEM 12 INFORMATION System Information Block type SYSTEM 13 INFORMATION System Information Block type SYSTEM 14 INFORMATION System Information Block type SYSTEM 10 NA 11 NA 12 NA 13 INFORMATION 14 INFORMATION System Information Block type SYSTEM 10 NA	_			-	NI A	
System Information Block type SYSTEM INFORMATION 5 NA System Information Block type SYSTEM INFORMATION 10 NA	System Information Block type			5	NA	
10	9	INFORMATION		-	NI A	
System Information Block type SYSTEM INFORMATION 10 NA				5	NA	
11				4.0	110	
System Information Block type SYSTEM INFORMATION 10 NA System Information Block type SYSTEM INFORMATION 10 NA 3 INFORMATION 10 NA System Information Block type SYSTEM INFORMATION 10 NA 14 INFORMATION 10 NA System Information Block type SYSTEM INFORMATION 10 NA				10	NA	
12 INFORMATION System Information Block type SYSTEM 13 INFORMATION System Information Block type SYSTEM 14 INFORMATION System Information Block type SYSTEM 10 NA INFORMATION 10 NA NA						
System Information Block type SYSTEM 10 NA INFORMATION 11 NA INFORMATION 12 NA INFORMATION 12 NA INFORMATION 13 NA INFORMATION 14 INFORMATION 15 NA INFORMAT				10	NA	
System Information Block type SYSTEM 10 NA 14 INFORMATION System Information Block type SYSTEM 10 NA						
System Information Block type SYSTEM 10 NA 14 INFORMATION 10 NA System Information Block type SYSTEM 10 NA	,			10	NA	
14 INFORMATION System Information Block type SYSTEM 10 NA						
System Information Block type SYSTEM 10 NA				10	NA	
				10	NA	
	15	INFORMATION			ļ	
System Information Block type SYSTEM 10 NA	1 -			10	NA	
16 INFORMATION						
System Information Block type SYSTEM 10 NA	, ,			10	NA	
18 INFORMATION I	18	INFORMATION				

Procedure title:	UTRAN -> UE	UE -> UTRAN	N1	N2	Notes
RRC connection establishment Target state CELL_DCH	RRC CONNECTION SETUP	RRC CONNECTION SETUP COMPLETE	10	NA	N1 measures time to the start of tx / rx on DPCH. N2 cannot be specified, because RRC CONNECTION SETUP COMPLETE message is transmitted only after physical layer synchronisation, which also depends on the Node B. The performance of the physical layer synchronisation procedure is specified in [19] and [20]
RRC connection establishment Target state CELL_FACH	RRC CONNECTION SETUP	RRC CONNECTION SETUP COMPLETE	10	11	N1 and N2 applicable as defined (N2 can be tested from the initiation of the power ramp on RACH).
RRC connection release From CELL_DCH state	RRC CONNECTION RELEASE	RRC CONNECTION RELEASE COMPLETE	5	8	N1 sets the requirement for the time from the completion of the last repetition of the RRC CONNECTION RELEASE COMPLETE message to the release of the physical channel. N2 sets the requirement from the end of successful reception of the RRC CONNECTION RELEASE message to the start of the first transmission of the RRC CONNECTION RELEASE CONNECTION RELEASE COMPLETE message.
RRC connection release From CELL_FACH state	RRC CONNECTION RELEASE	RRC CONNECTION RELEASE COMPLETE	NA	11	N1 represents UE internal configuration that cannot be externally observed.
Paging	PAGING TYPE 1	CELL UPDATE	10	11+ T	T is the repetition period of SIB7 (applicable for FDD) and SIB14 (applicable for TDD)
UE capability enquiry	UE CAPABILITY ENQUIRY	UE CAPABILITY INFORMATION	NA	8	N1 is not applicable because the UE configuration does not change.
Security mode control	SECURITY MODE COMMAND	SECURITY MODE COMPLETE	5	8	
Signalling connection release procedure	SIGNALLING CONNECTION RELEASE		5	NA	N2 is not applicable because there is no response message.
Counter check	COUNTER CHECK	COUNTER CHECK RESPONSE	NA	8	N1 is not applicable because the UE configuration does not change.
Radio Bearer control procedures					
Radio bearer establishment Target state CELL_DCH	RADIO BEARER SETUP	RADIO BEARER SETUP COMPLETE / FAILURE	10	NA	N2 cannot be specified, because the RADIO BEARER SETUP COMPLETE / FAILURE message is transmitted only after physical layer synchronisation, which depends also on Node B.
Radio bearer establishment From state CELL_FACH to state CELL_FACH	RADIO BEARER SETUP	RADIO BEARER SETUP COMPLETE / FAILURE	10	11	

Procedure title:	UTRAN -> UE	UE -> UTRAN	N1	N2	Notes
Radio bearer establishment	RADIO	RADIO BEARER	NA	NA	N1 and N2 cannot be
	BEARER	SETUP			specified, because UE need to
From CELL_DCH to	SETUP	COMPLETE			read SIBs on BCH before
CELL_FACH					sending RADIO BEARER
					SETUP COMPLETE
Radio bearer reconfiguration	RADIO	RADIO BEARER	10	NA	N2 cannot be specified,
Target state CELL_DCH	BEARER RECONFIGURA	RECONFIGURAT ION COMPLETE /			because the RADIO BEARER RECONFIGURATION
Target state CLLL_DOT	TION	FAILURE			COMPLETE / FAILURE
	11011	171120112			message is transmitted only
					after physical layer
					synchronisation, which
					depends also on Node B.
Radio bearer reconfiguration	RADIO	RADIO BEARER	10	11	
From state CELL_FACH to	BEARER RECONFIGURA	RECONFIGURAT ION COMPLETE /			
state CELL_FACH	TION	FAILURE			
Radio bearer reconfiguration	RADIO	RADIO BEARER	NA	NA	N1 and N2 cannot be
Tradic board, root, ingaranon	BEARER	RECONFIGURAT			specified, because UE need to
From state CELL_DCH to	RECONFIGURA	ION COMPLETE			read SIBs on BCH before
state CELL_FACH	TION				sending RADIO BEARER
					RECONFIGURATION
Radio bearer release	RADIO	RADIO BEARER	10	11	COMPLETE
Target state CELL_DCH	BEARER	RELEASE	10	' '	
rarget state OLLL_DOTT	RELEASE	COMPLETE /			
		FAILURE			
Radio bearer release	RADIO	RADIO BEARER	10	11	
From state CELL_FACH to	BEARER	RELEASE			
state CELL_FACH	RELEASE	COMPLETE /			
Radio bearer release	RADIO	FAILURE RADIO BEARER	NA	NA	N1 and N2 cannot be
From state CELL_DCH to	BEARER	RELEASE	INA	INA	specified, because UE need to
state CELL_FACH	RELEASE	COMPLETE			read SIBs on BCH before
_					sending RADIO BEARER
					RECONFIGURATION
					COMPLETE
Transport channel	TRANSPORT CHANNEL	TRANSPORT CHANNEL	10	NA	N2 cannot be specified,
reconfiguration	RECONFIGURA	RECONFIGURAT			because the TRANSPORT CHANNEL
Target state CELL_DCH	TION	ION COMPLETE /			RECONFIGURATION
		FAILURE			COMPLETE / FAILURE
					message is transmitted only
					after physical layer
					synchronisation, which
Transport channel	TRANSPORT	TRANSPORT	10	11	depends also on Node B.
reconfiguration	CHANNEL	CHANNEL	'	' '	
	RECONFIGURA	RECONFIGURAT			
From state CELL_FACH to	TION	ION COMPLETE /			
state CELL_FACH	TDANIODOS	FAILURE		N. 4	NA INO
Transport channel	TRANSPORT	TRANSPORT	NA	NA	N1 and N2 cannot be
reconfiguration	CHANNEL RECONFIGURA	CHANNEL RECONFIGURAT			specified, because UE need to read SIBs on BCH before
From state CELL_DCH to	TION	ION COMPLETE			sending TRANSPORT
state CELL_FACH					CHANNEL
_					RECONFIGURATION
					COMPLETE
Transport format combination	TRANSPORT	TRANSPORT	5	8	
control	FORMAT COMBINATION	FORMAT COMBINATION			
AM or UM RLC mode	CONTROL	CONTROL			
, o. o. n. n.co mode	JOHNOL	FAILURE			
Transport format combination	TRANSPORT		5	NA	N2 is not applicable because
control	FORMAT				no response message is
Transparent made	COMBINATION				defined.
Transparent mode	CONTROL	<u> </u>		1	

Procedure title:	UTRAN -> UE	UE -> UTRAN	N1	N2	Notes
Physical channel reconfiguration Target state CELL_DCH	PHYSICAL CHANNEL RECONFIGURA TION	PHYSICAL CHANNEL RECONFIGURAT ION COMPLETE / FAILURE	8	NA	N2 cannot be specified, because the PHYSICAL CHANNEL RECONFIGURATION COMPLETE / FAILURE message is transmitted only after physical layer synchronisation, which depends also on Node B.
Physical channel reconfiguration From state CELL_FACH to state CELL_FACH	PHYSICAL CHANNEL RECONFIGURA TION	PHYSICAL CHANNEL RECONFIGURAT ION COMPLETE / FAILURE	8	9	
Physical channel reconfiguration From state CELL_DCH to state CELL_FACH	PHYSICAL CHANNEL RECONFIGURA TION	PHYSICAL CHANNEL RECONFIGURAT ION COMPLETE	NA	NA	N1 and N2 cannot be specified, because UE need to read SIBs on BCH before sending PHYSICAL CHANNEL RECONFIGURATION COMPLETE
Physical Shared Channel Allocation [TDD only]	PHYSICAL SHARED CHANNEL ALLOCATION		5	NA	N2 is not applicable because no response message is defined.
Uplink Physical Channel Control [TDD only]	UPLINK PHYSICAL CHANNEL CONTROL		8	NA	Requirements for outer loop and timing advance adjustments are defined in [22] and [20]. N2 is not applicable because there is no response message.
RRC connection mobility procedures					
Cell update	CELL UPDATE CONFIRM	UTRAN MOBILITY INFORMATION CONFIRM	5	8	
		PHYSICAL CHANNEL RECONFIGURAT ION COMPLETE Target state CELL_FACH	8	9	
		PHYSICAL CHANNEL RECONFIGURAT ION COMPLETE Target state CELL_DCH	8	NA	N2 cannot be specified, because the PHYSICAL CHANNEL RECONFIGURATION COMPLETE / FAILURE message is transmitted only after physical layer synchronisation, which depends also on Node B.
		TRANSPORT CHANNEL RECONFIGURAT ION COMPLETE Target state CELL_FACH	10	11	

Procedure title:	UTRAN -> UE	UE -> UTRAN	N1	N2	Notes
		TRANSPORT CHANNEL RECONFIGURAT ION COMPLETE Target state CELL_DCH	10	NA	N2 cannot be specified, because the PHYSICAL CHANNEL RECONFIGURATION COMPLETE / FAILURE message is transmitted only after physical layer synchronisation, which depends also on Node B.
		RADIO BEARER RECONFIGURAT ION COMPLETE Target state CELL_FACH	10	11	
		RADIO BEARER RECONFIGURAT ION COMPLETE Target state CELL_DCH	10	NA	N2 cannot be specified, because the PHYSICAL CHANNEL RECONFIGURATION COMPLETE / FAILURE message is transmitted only after physical layer synchronisation, which depends also on Node B.
		RADIO BEARER RELEASE COMPLETE Target state CELL_DCH	10	11	
URA update	URA UPDATE CONFIRM	UTRAN MOBILITY INFORMATION CONFIRM	5	8	
UTRAN mobility information	UTRAN MOBILITY INFORMATION	UTRAN MOBILITY INFORMATION CONFIRM / FAILURE	5	8	
Active set update	ACTIVE SET UPDATE	ACTIVE SET UPDATE COMPLETE / FAILURE	NA	8	The requirements on UE combining and power control performance for both UL and DL are specified by RAN WG4 in [21] and [19]. Also in case of branch addition the COMPLETE / FAILURE message is transmitted without waiting for the new branch to
					stabilise, therefore N2 is specified.
Inter-RAT handover to UTRAN	HANDOVER TO UTRAN COMMAND (other system)	HANDOVER TO UTRAN COMPLETE	NA	NA	The performance of this procedure is specified in 05.10.
Inter-RAT handover from UTRAN Measurement procedures	HANDOVER FROM UTRAN COMMAND	HANDOVER FROM UTRAN FAILURE	NA	NA	The performance of this procedure is specified in [19] and [20].
Measurement control	MEASUREMEN T CONTROL	MEASUREMENT CONTROL FAILURE	5	8	Response to measurement inquiry depends on physical layer measurement. Response time is defined in [19] and [20]. N1 and N2 only define the processing of the message.

13.6 RB information parameters for signalling radio bearer RB 0

The following Radio Bearer parameter values apply for signalling radio bearer RB0:

Information element/ Group name	Value	Comment
RLC info		
>Uplink RLC mode	TM	
>>Transmission RLC discard	omitted	Neither discard is used, nor will there be a reset
>>Segmentation indication	FALSE	
>Downlink RLC mode	UM	
RB mapping info		Single multiplexing option
>Uplink mapping info		
>>UL transport channel	RACH	RACH corresponding with selected PRACH
>>RLC size list	N/A	The first TF defined in the Transport Format Set for the transport channel that is used
>>MAC logical channel priority	1	
>Downlink mapping info		
>>DL transport channel	FACH	

Procedure descriptions in subclause 8.6.4.8 shall not be applied for the IE "RB mapping info" that is used for signalling radio bearer RB0.

13.6a RB information parameters for SHCCH

The following Radio Bearer parameter values apply for SHCCH:

Information element/ Group name	Value	Comment
RLC info		
>Uplink RLC mode	TM	
>>Transmission RLC discard	omitted	Neither discard is used, nor will there be a reset
>>Segmentation indication	FALSE	
>Downlink RLC mode	UM	
RB mapping info		
>Uplink mapping info		Option 1
>>UL transport channel	RACH	RACH corresponding with selected PRACH
>>RLC size list	N/A	The first TF defined in the Transport Format Set for
		the transport channel that is used
>>MAC logical channel priority	1	
>Downlink mapping info		
>>DL transport channel	FACH	
>Uplink mapping info		Option 2
>>UL transport channel	USCH	
>>UL Transport Channel Identity	1	
>>MAC logical channel priority	1	
>>RLC size list	N/A	The first TF defined in the Transport Format Set for
		the transport channel that is used
>Downlink mapping info		
>>DL transport channel	DSCH	
>>DL Transport Channel Identity	1	

13.6b RB information parameters for BCCH mapped to FACH

The following Radio Bearer parameter values apply for BCCH mapped to FACH:

Information element/ Group name	Value	Comment
Downlink RLC mode	TM	
Segmentation indication	FALSE	

13.6c RB information parameters for PCCH mapped to PCH

The following Radio Bearer parameter values apply for PCCH mapped to PCH:

Information element/ Group name	Value	Comment
Downlink RLC mode	TM	
Segmentation indication	FALSE	

13.6d Parameters for BCCH mapped to BCH

The transport format parameters for BCH are specified in [34].

13.7 Parameter values for default radio configurations

The UE shall support the use of the default radio configurations that are specified in the following.

NOTE 1: These configurations are based on [41] and cover a number of RAB and signalling connection configurations.

In the table that is used to specify the parameter values for these default configurations, the following principles are used:

- Optional IEs that are not used are omitted;
- In case no parameter value is specified in a column, this means the value given the previous (left side) column applies.
- NOTE 2: If needed, signalling radio bearer RB4 is established after the completion of handover.
- NOTE 3: For each default configuration, the value of FDD, 3.84 Mcps TDD and 1.28 Mcps TDD parameters are specified. All parameters apply to FDD, 3.84 Mcps TDD and 1.28 Mcps TDD modes, unless explicitly stated otherwise. It should be noted that in this respect default configurations differ from pre-defined configurations, which only include parameter values for one mode.
- NOTE 4: The transport format sizes, indicated in the following table, concern the RLC PDU size, since all configurations concern dedicated channels. The transport block sizes indicated in TS 34.108 are different since these include the size of the MAC header.

Configuration	3.4 kbps signalling	13.6 kbps signalling	7.95 kbps speech + 3.4 kbps signalling	12.2 kbps speech + 3.4 kbps signalling
D (04.400				
Ref 34.108	2	3	6	4
Default configuration identity	0	1	2	3
RB INFORMATION				
rb-Identity	RB1: 1, RB2: 2, RB3: 3	RB1: 1, RB2: 2, RB3: 3	RB1: 1, RB2: 2, RB3: 3, RB5: 5, RB6: 6	RB1: 1, RB2: 2, RB3: 3, RB5: 5, RB6: 6, RB7: 7
rlc-InfoChoice	RIc-info	RIc-info	RIc-info	RIc-info
>ul-RLC-Mode	RB1: UM RB2- RB3: AM	RB1: UM RB2- RB3: AM	RB1: UM RB2- RB3: AM RB5-RB6: TM	RB1: UM RB2- RB3: AM RB5-RB7: TM
>>transmissionRLC- DiscardMode	RB1: N/A RB2- RB3: NoDiscard	RB1: N/A RB2- RB3: NoDiscard	RB1: N/A RB2- RB3: NoDiscard RB5- RB6: N/A	RB1: N/A RB2- RB3: NoDiscard RB5- RB7: N/A
>>>maxDat	RB1: N/A RB2- RB3: 15	RB1: N/A RB2- RB3: 15	RB1: N/A RB2- RB3: 15 RB5- RB6: N/A	RB1: N/A RB2- RB3: 15 RB5- RB7: N/A

Configuration	3.4 kbps signalling	13.6 kbps	7.95 kbps speech	12.2 kbps speech
		signalling	+	+
			3.4 kbps signalling	3.4 kbps signalling
>>transmissionWindowSiz	RB1: N/A	RB1: N/A	RB1: N/A	RB1: N/A
е	RB2- RB3: 128 for	RB2- RB3: 128 for	RB2- RB3: 128 for	RB2- RB3: 128 for
	UEs with more than 10 kbyte "total RLC	UEs with more than 10 kbyte "total RLC	UEs with more than 10 kbyte "total RLC	UEs with more than 10 kbyte "total RLC
	AM buffer size" and	AM buffer size" and	AM buffer size" and	AM buffer size" and
	32 otherwise	32 otherwise	32 otherwise	32 otherwise
			RB5- RB6: N/A	RB5- RB7: N/A
>>timerRST	RB1: N/A	RB1: N/A	RB1: N/A	RB1: N/A
	RB2- RB3: 300	RB2- RB3: 300	RB2- RB3: 300 RB5- RB6: N/A	RB2- RB3: 300 RB5- RB7: N/A
>>max-RST	RB1: N/A	RB1: N/A	RB1: N/A	RB1: N/A
	RB2- RB3: 1	RB2- RB3: 1	RB2- RB3: 1 RB5- RB6: N/A	RB2- RB3: 1 RB5- RB7: N/A
>>pollingInfo	RB1: N/A RB2- RB3: as below	RB1: N/A RB2- RB3: as below	RB1: N/A RB2- RB3: as below RB5- RB6: N/A	RB1: N/A RB2- RB3: as below RB5- RB7: N/A
>>>lastTransmissionPDU- Poll	RB2- RB3: FALSE	RB2- RB3: FALSE	RB2- RB3: FALSE	RB2- RB3: FALSE
>>>lastRetransmissionPD U-Poll	RB2- RB3: FALSE	RB2- RB3: FALSE	RB2- RB3: FALSE	RB2- RB3: FALSE
>>>timerPollPeriodic	RB2- RB3: 300	RB2- RB3: 100	RB2- RB3: 300	RB2- RB3: 300
>>segmentationIndication	RB1- RB3: N/A	RB1- RB3: N/A	RB1- RB3: N/A RB5- RB6: FALSE	RB1- RB3: N/A RB5- RB7: FALSE
>dl-RLC-Mode	RB1: UM	RB1: UM	RB1: UM	RB1: UM
	RB2- RB3: AM	RB2- RB3: AM	RB2- RB3: AM RB5- RB6: TM	RB2- RB3: AM RB5- RB7: TM
>>inSequenceDelivery	RB1: N/A	RB1: N/A RB2- RB3: TRUE	RB1: N/A	RB1: N/A
Mr. 1 . O:	RB2- RB3: TRUE		RB2- RB3: TRUE RB5- RB6: N/A	RB2- RB3: TRUE RB5- RB7: N/A
>>receivingWindowSize	RB1: N/A RB2- RB3: 128 for	RB1: N/A RB2- RB3: 128 for	RB1: N/A RB2- RB3: 128 for	RB1: N/A RB2- RB3: 128 for
	UEs with more than	UEs with more than	UEs with more than	UEs with more than
	10 kbyte "total RLC	10 kbyte "total RLC	10 kbyte "total RLC	10 kbyte "total RLC
	AM buffer size" and	AM buffer size" and	AM buffer size" and	AM buffer size" and
	32 otherwise	32 otherwise	32 otherwise RB5- RB6: N/A	32 otherwise RB5- RB7: N/A
>>dl-RLC-StatusInfo	RB1: N/A	RB1: N/A	RB1: N/A	RB1: N/A
	RB2- RB3: as below	RB2- RB3: as below	RB2- RB3: as below RB5- RB6: N/A	RB2- RB3: as below RB5- RB7: N/A
>>>timerStatusProhibit	RB2- RB3: 100	RB2- RB3: 100	RB2- RB3: 100	RB2- RB3: 100
>>>missingPDU-Indicator	RB2- RB3: FALSE	RB2- RB3: FALSE	RB2- RB3: FALSE	RB2- RB3: FALSE
>>>timerStatusPeriodic >>segmentationIndication	RB2- RB3: 300 RB1- RB3: N/A	RB2- RB3: 100 RB1- RB3: N/A	RB2- RB3: 300 RB1- RB3: N/A	RB2- RB3: 300 RB1- RB3: N/A
rb-MappingInfo	RDI-RD3. N/A	RDI- RD3. N/A	RB5- RB6: FALSE	RB5- RB7: FALSE
>UL-	OneLogicalChannel	OneLogicalChannel	OneLogicalChannel	OneLogicalChannel
LogicalChannelMappings	J. J	2.1020gloaiOriaililei	J. J	J. J
>>ul- TransportChannelType	Dch	Dch	Dch	Dch
>>>transportChannelIdentit	RB1- RB3: 1	RB1- RB3: 1	RB1- RB3: 3	RB1- RB3: 4
У			RB5: 1, RB6: 2	RB5: 1, RB6: 2, RB7: 3
>>logicalChannelIdentity	RB1: 1, RB2: 2, RB3: 3	RB1: 1, RB2: 2, RB3: 3	RB1: 1, RB2: 2, RB3: 3	RB1: 1, RB2: 2, RB3: 3
			RB5- RB6: N/A	RB5- RB7: N/A
>>rlc-SizeList	RB1- RB3:	RB1- RB3:	RB1- RB3:	RB1- RB3:
	configured	configured	configured RB5- RB6: N/A	configured RB5- RB7: N/A
>>mac-	RB1: 1, RB2: 2,	RB1: 1, RB2: 2,	RB1: 1, RB2: 2,	RB1: 1, RB2: 2,
LogicalChannelPriority	RB3: 3	RB3: 3	RB3: 3 RB5- RB6: 5	RB3: 3 RB5- RB7: 5
>DL- logicalChannelMappingList				

Configuration	3.4 kbps signalling		7.95 kbps speech	12.2 kbps speech
		signalling	+	+ 3.4 kbps signalling
			3.4 kbps signalling	3.4 kops signalling
>>Mapping option 1	One mapping option	One mapping option	One mapping option	One mapping option
>>>dl-	Dch	Dch	Dch	Dch
TransportChannelType	DD4 DD0 4	DD4 DD0 4	DD4 DD0 0	DD4 DD0 4
>>>transportChannellden tity	RB1- RB3: 1	RB1- RB3: 1	RB1- RB3: 3 RB5: 1, RB6: 2	RB1- RB3: 4 RB5: 1, RB6: 2, RB7: 3
>>>logicalChannelIdentity	RB1: 1, RB2: 2, RB3: 3	RB1: 1, RB2: 2, RB3: 3	RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A	RB1: 1, RB2: 2, RB3: 3 RB5- RB7: N/A
TrCH INFORMATION PER TrCH				
UL-				
AddReconfTransChInfoList				
>Uplink transport channel type	dch	dch	dch	dch
>transportChannelIdentity	TrCH1: 1	TrCH1: 1	TrCH1: 1, TrCH2: 2, TrCH3: 3	TrCH1: 1, TrCH2: 2, TrCH3: 3, TrCH4: 4
>transportFormatSet	DedicatedTransChT FS	DedicatedTransChT FS	DedicatedTransChT FS	DedicatedTransChT FS
>>dynamicTF-information				
>>>tf0/ tf0,1	TrCH1: (0x144, 1x144)	TrCH1: (0x144, 1x144)	TrCH1: (0x75) TrCH2: (0x 84 1x84) TrCH3: (0x144, 1x144)	TrCH1: (0x81) TrCH2: (0x 103, 1x103) TrCH3: (0x 60, 1x60) TrCH4: (0x144, 1x144)
>>>>rlcSize	BitMode	BitMode	BitMode	BitMode
>>>>sizeType	TrCH1: type 2, part1= 2, part2= 0 (144)	TrCH1: type 2, part1= 2, part2= 0 (144)	TrCH1: type 1: 75 TrCH2: type 1: 84 TrCH3: 2: type 2, part1= 2, part2= 0 (144)	TrCH1: type 1: 81 TrCH2: type 1: 103 TrCH3: type 1: 60 TrCH4: 2: type 2, part1= 2, part2= 0 (144)
>>>numberOfTbSizeList	TrCH1: Zero, one	TrCH1: Zero, one	TrCH1: Zero TrCH2-3: Zero, one	TrCH1: Zero TrCH2-4: Zero, one
>>>>logicalChannelList	All	All	All	All
>>>tf 1	N/A	N/A	TrCH1: (1x39) TrCH2- TrCH4: N/A	TrCH1: (1x39) TrCH2- TrCH4: N/A
>>>numberOfTransportBl ocks			TrCH1: One	TrCH1: One
>>>rlc-Size			TrCH1: BitMode	TrCH1: BitMode
>>>>sizeType			TrCH1: 1: 39	TrCH1: 1: 39
>>>>numberOfTbSizeList			TrCH1: One	TrCH1: One
>>>>logicalChannelList			TrCH1: all	TrCH1: all
>>>tf 2	N/A	N/A	TrCH1: (1x75)	TrCH1: (1x81)
>>>numberOfTransportBl			TrCH2- TrCH3: N/A TrCH1: One	TrCH2- TrCH4: N/A TrCH1: One
ocks >>>>rlc-Size			TrCH1: BitMode	TrCH1: BitMode
>>>sizeType			TrCH1: type 1: 75	TrCH1: type 1: 81
>>>numberOfTbSizeList			TrCH1: One	TrCH1: One
>>>logicalChannelList			TrCH1: all	TrCH1: all
>>semistaticTF-Information				
>>>tti	TrCH1: 40	TrCH1: 10	TrCH1- TrCH2: 20 TrCH3: 40	TrCH1- TrCH3: 20 TrCH4: 40
>>>channelCodingType	Convolutional	Convolutional	Convolutional	Convolutional
>>>codingRate	TrCH1: Third	TrCH1: Third	TrCH1- TrCH2: Third TrCH3: Third	TrCH1- TrCH2: Third TrCH3: Half TrCH4: Third

Configuration	3.4 kbps signalling	13.6 kbps	7.95 kbps speech	12.2 kbps speech
		signalling	+	+
			3.4 kbps signalling	3.4 kbps signalling
>>>rateMatchingAttribute	TrCH1: 160	TrCH1: 160	TrCH1: 200	TrCH1: 200
· · · · · · · · · · · · · · · · · · ·			TrCH2: 190	TrCH2: 190
			TrCH3: 160	TrCH3: 235
				TrCH4: 160
>>>crc-Size	TrCH1: 16	TrCH1: 16	TrCH1: 12	TrCH1: 12
			TrCH2: 0	TrCH2- TrCH3: 0
			TrCH3: 16	TrCH4: 16
DL-				
AddReconfTransChInfoList	ما ماه	ماماد	ماماد	ماماد
>Downlink transport	dch	dch	dch	dch
channel type >dl-	TrCH1: 1	TrCH1: 1	TrCH1: 1, TrCH2: 2,	TrCH1: 1, TrCH2: 2,
TransportChannelIdentity	ПСПІ. І	ПСПТ. Т	TrCH1: 1, 11CH2: 2,	TrCH1: 1, 11CH2: 2,
(should be as for UL)			ПСПЗ. З	11003. 3, 11004. 4
>tfs-SignallingMode	SameAsUL	SameAsUL	Explicit	Explicit
>tis-Signallingivioue	SameASUL	SameASUL	<only on="" td="" tf0="" trch1<=""><td><only on="" td="" tf0="" trch1<=""></only></td></only>	<only on="" td="" tf0="" trch1<=""></only>
			is different and	is different and
			shown below>	shown below>
>>transportFormatSet			DedicatedTransChT	DedicatedTransChT
->transporti officioci			FS	FS
>>>dynamicTF-information				
>>>tf0/ tf0,1			TrCH1: (1x0)	TrCH1: (1x0)
>>>rlcSize			BitMode	bitMode
>>>>sizeType			TrCH1: type 1: 0	TrCH1: type 1: 0
>>>>numberOfTbSizeList			TrCH1: One	TrCH1: One
>>>logicalChannelList			All	All
>>ULTrCH-Id	TrCH1: 1	TrCH1: 1	TrCH1: 1, TrCH2: 2,	TrCH1: 1, TrCH2: 2,
			TrCH3: 3	TrCH3: 3, TrCH4: 4
>dch-QualityTarget				
>>bler-QualityValue	TrCH1: 5x10 ⁻²	TrCH1: 5x10 ⁻²	TrCH1: 7x10 ⁻³	TrCH1: 7x10 ⁻³
			TrCH2- TrCH3:	TrCH2- TrCH4:
			Absent	Absent
TrCH INFORMATION,				
COMMON				
ul-CommonTransChInfo				
>tfcs-ID (TDD only)	1	1	1	1
>sharedChannelIndicator	FALSE	FALSE	FALSE	FALSE
(TDD only)				
>tfc-Subset	Absent, not required	Absent, not required	Absent, not required	Absent, not required
>ul-TFCS	Normal TFCI	Normal TFCI	Normal TFCI	Normal TFCI
	signalling	signalling	signalling	signalling
>>explicitTFCS-	Complete	Complete	Complete	Complete
ConfigurationMode	0.4.00	0.4.054	0.4.154	0.4.054
>>>ctfcSize	Ctfc2Bit	Ctfc2Bit	Ctfc4Bit	Ctfc6Bit
>>>>TFCS representation	Addition	Addition	Addition	Addition
>>>>TFCS list				
>>>>TFCS 1	(TF0)	(TF0)	(TF0, TF0, TF0)	(TF0, TF0, TF0,
>>>>>ctfc	0	0	0	TF0) 0
>>>>>gainFactorInform	Computed	Computed	Computed	Computed
ation	Joinpuleu	Joinpalea	Joinpuleu	Joinpalea
>>>>>>referenceTFCId	0	0	0	0
>>>>TFCS 2	(TF1)	(TF1)	(TF1, TF0, TF0)	(TF1, TF0, TF0,
	4	4	4	TF0)
>>>>>CtfC	1 Signalled	1 Signallad	1 Computed	•
>>>>>gainFactorInform ation	Signalled	Signalled	Computed	Computed
>>>>>>βc (FDD only)	11	11	N/A	N/A
•	15	15	N/A	N/A
>>>>>βd				
>>>>>referenceTFCId	0	0	0	0

Configuration	3.4 kbps signalling	13.6 kbps	7.95 kbps speech	12.2 kbps speech
_		signalling	+	+
			3.4 kbps signalling	3.4 kbps signalling
>>>>TFCS 3			(TF2, TF1, TF0)	(TF2, TF1, TF1,
			, , ,	TF0)
>>>>>ctfc			5	11
>>>>>gainFactorInform ation			Computed	Computed
>>>>>>referenceTFCId			0	0
>>>>TFCS 4			(TF0, TF0, TF1)	(TF0, TF0, TF0, TF1)
>>>>>ctfc			6	12
>>>>>gainFactorInform ation			Computed	Computed
>>>>>βc (FDD only)			N/A	N/A
>>>>>βd			N/A	N/A
>>>>>referenceTFCId			0	0
>>>>TFCS 5			(TF1, TF0, TF1)	(TF1, TF0, TF0, TF1)
>>>>>ctfc			7	13
>>>>>gainFactorInform			Computed	Computed
>>>>>referenceTFCId			0	0
>>>>TFCS 6			(TF2, TF1, TF1)	(TF2, TF1, TF1, TF1)
>>>>>ctfc			11	23
>>>>>gainFactorInform			Signalled	Signalled
>>>>>βc (FDD only)			11	11
>>>>>βd			15	15
>>>>>referenceTFCId			0	0
dl-CommonTransChInfo				
>tfcs-SignallingMode	Same as UL	Same as UL	Same as UL	Same as UL
PhyCH INFORMATION FDD				
UL-DPCH-InfoPredef				
>ul-DPCH-				
PowerControlInfo	A.1. 141 A	A1 11 4	A1 1/1 4	A1 11 4
>>powerControlAlgorithm	Algorithm 1	Algorithm 1	Algorithm 1	Algorithm 1
>>>tpcStepSize >tfci-Existence	TRUE	TRUE	TRUE	TRUE
>puncturingLimit	1	1	1	0.88
DL-			'	0.00
CommonInformationPredef				
>dl-DPCH-InfoCommon				
>>spreadingFactor	256	128	128	128
>>tfci-Existence	FALSE	FALSE	FALSE	FALSE
>>pilotBits >>positionFixed	4 N/A	4 N/A	4 Fixed	4 Fixed
>>pusitionFixed	IN/ <i>F</i> 1	IN/A	FIXEU	I IXCU
PhyCH INFORMATION				
3.84 Mcps TDD UL-DPCH-InfoPredef				
>ul-DPCH-IntoPredet				
PowerControlInfo				
>>dpch-ConstantValue	0	0	0	0
>commonTimeslotInfo				
>>secondInterleavingMode	frameRelated	frameRelated	frameRelated	frameRelated
>>tfci-Coding	4	4	16	16
>>puncturingLimit	1	0.92	0.52	0.88
>>repetitionPeriodAndLeng th	repetitionPeriod1	repetitionPeriod1	repetitionPeriod1	repetitionPeriod1

Configuration	3.4 kbps signalling	13.6 kbps signalling	7.95 kbps speech	12.2 kbps speech
			3.4 kbps signalling	3.4 kbps signalling
DL-				
CommonInformationPredef				
>dl-DPCH-InfoCommon				
>>commonTimeslotInfo				
>>secondInterleavingMod	frameRelated	frameRelated	frameRelated	frameRelated
е				
>>>tfci-Coding	4	4	16	16
>>>puncturingLimit	1	0.92	0.52	0.92
>>>repetitionPeriodAndLe ngth	repetitionPeriod1	repetitionPeriod1	repetitionPeriod1	repetitionPeriod1
PhyCH INFORMATION				
1.28 Mcps TDD				
UL-DPCH-InfoPredef				
>commonTimeslotInfo				
>>secondInterleavingMode	frameRelated	frameRelated	frameRelated	frameRelated
>>tfci-Coding	4	4	16	16
>>puncturingLimit	1	0.64	0.80	0.60
>>repetitionPeriodAndLeng	repetitionPeriod1	repetitionPeriod1	repetitionPeriod1	repetitionPeriod1
th				
DL-				
CommonInformationPredef				
>dl-DPCH-InfoCommon				
>>commonTimeslotInfo				
>>>secondInterleavingMod	frameRelated	frameRelated	frameRelated	frameRelated
е				
>>>tfci-Coding	4	4	16	16
>>>puncturingLimit	1	0.64	0.80	0.60
>>>repetitionPeriodAndLe ngth	repetitionPeriod1	repetitionPeriod1	repetitionPeriod1	repetitionPeriod1

Configuration	28.8 kbps conv. CS- data + 3.4 kbps signalling	32 kbps conv. CS- data + 3.4 kbps signalling	64kbps conv. CS- data + 3.4 kbps signalling	14.4 kbps streaming CS- data + 3.4 kbps signalling
Ref 34.108	12	14	13	15
Default configuration identity	4	5	6	7
RB INFORMATION				
rb-Identity	RB1: 1, RB2: 2, RB3: 3, RB5: 5			
rlc-InfoChoice	Rlc-info	RIc-info	RIc-info	RIc-info
>ul-RLC-Mode	RB1: UM RB2- RB3: AM RB5: TM			
>>transmissionRLC- DiscardMode	RB1: N/A RB2- RB3: NoDiscard RB5: N/A			
>>>maxDat	RB1: N/A RB2- RB3: 15 RB5: N/A			
>>transmissionWindowSiz e	RB1: N/A RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise RB5: N/A	RB1: N/A RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise RB5: N/A	RB1: N/A RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise RB5: N/A	RB1: N/A RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise RB5: N/A
>>timerRST	RB1: N/A RB2- RB3: 300 RB5: N/A			

Configuration	28.8 kbps conv. CS- data + 3.4 kbps signalling	32 kbps conv. CS- data + 3.4 kbps signalling	64kbps conv. CS- data + 3.4 kbps signalling	14.4 kbps streaming CS- data +
				3.4 kbps signalling
>>max-RST	RB1: N/A RB2- RB3: 1 RB5: N/A			
>>pollingInfo	RB1: N/A RB2- RB3: as below RB5: N/A			
>>>lastTransmissionPDU- Poll	RB2- RB3: FALSE	RB2- RB3: FALSE	RB2- RB3: FALSE	RB2- RB3: FALSE
>>>lastRetransmissionPD U-Poll	RB2- RB3: FALSE	RB2- RB3: FALSE	RB2- RB3: FALSE	RB2- RB3: FALSE
>>>timerPollPeriodic	RB2- RB3: 300	RB2- RB3: 300	RB2- RB3: 300	RB2- RB3: 300
>>segmentationIndication	RB1- RB3: N/A RB5: FALSE			
>dl-RLC-Mode	RB1: UM RB2- RB3: AM RB5: TM			
>>inSequenceDelivery	RB1: N/A RB2- RB3: TRUE			
>>receivingWindowSize	RB5: N/A RB1: N/A RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise RB5: N/A	RB5: N/A RB1: N/A RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise RB5: N/A	RB5: N/A RB1: N/A RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise RB5: N/A	RB5: N/A RB1: N/A RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise RB5: N/A
>>dl-RLC-StatusInfo	RB1: N/A RB2- RB3: as below RB5: N/A			
>>>timerStatusProhibit	RB2- RB3: 100	RB2- RB3: 100	RB2- RB3: 100	RB2- RB3: 100
>>>missingPDU-Indicator	RB2- RB3: FALSE	RB2- RB3: FALSE	RB2- RB3: FALSE	RB2- RB3: FALSE
>>>timerStatusPeriodic	RB2- RB3: 300	RB2- RB3: 300	RB2- RB3: 300	RB2- RB3: 300
>>segmentationIndication	RB1- RB3: N/A RB5: FALSE			
rb-MappingInfo	0 1 : 101 1	0 1 : 101	0 1 : 101	0 1 101 1
>UL- LogicalChannelMappings	OneLogicalChannel	OneLogicalChannel	OneLogicalChannel	OneLogicalChannel
>>ul- TransportChannelType	Dch	Dch	Dch	Dch
>>>transportChannelIdenti ty	RB1- RB3: 2 RB5: 1			
>>logicalChannelIdentity	RB1: 1, RB2: 2, RB3: 3 RB5: N/A			
>>rlc-SizeList	RB1- RB3: configured RB5: N/A	RB1- RB3: configured RB5: N/A	RB1- RB3: configured RB5: N/A	RB1- RB3: configured RB5: N/A
>>mac- LogicalChannelPriority	RB1: 1, RB2: 2, RB3: 3 RB5: 5			
>DL- logicalChannelMappingList				
>>Mapping option 1 >>>dl-	One mapping option Dch	One mapping option Dch	One mapping option Dch	One mapping option Dch
TransportChannelType >>>>transportChannelIden tity	RB1- RB3: 2 RB5: 1			
>>>logicalChannelIdentity	RB1: 1, RB2: 2, RB3: 3 RB5: N/A			
TrCH INFORMATION PER TrCH				

Configuration	28.8 kbps conv. CS- data +	32 kbps conv. CS- data +	64kbps conv. CS- data +	14.4 kbps streaming CS-
	3.4 kbps signalling	3.4 kbps signalling	3.4 kbps signalling	data +
UL-				3.4 kbps signalling
AddReconfTransChInfoLis t				
>Uplink transport channel type	dch	dch	dch	dch
>transportChannelIdentity	TrCH1: 1, TrCH2: 2	TrCH1: 1, TrCH2: 2	TrCH1: 1, TrCH2: 2	TrCH1: 1, TrCH2: 2
>transportFormatSet	DedicatedTransChT FS	DedicatedTransChT FS	DedicatedTransChT FS	DedicatedTransChT FS
>>dynamicTF-information				
>>>tf0/ tf0,1	TrCH1: (0x576, 1x576, 2x576) TrCH2: (0x144, 1x144)	TrCH1: (0x640, 1x640) TrCH2: (0x144, 1x144)	TrCH1: (0x640, 2x640) TrCH2: (0x144, 1x144)	TrCH1: (0x576, 1x576) TrCH2: (0x144, 1x144)
>>>rlcSize	TrCH1: OctetMode TrCH2:BitMode	TrCH1: OctetMode TrCH2:BitMode	TrCH1: OctetMode TrCH2:BitMode	TrCH1: OctetMode TrCH2:BitMode
>>>>sizeType	TrCH1: type 2, part1= 9, part2= 2 (576) TrCH2: type 2, part1= 2, part2= 0 (144)	TrCH1: type 2, part1= 11, part2= 2 (640) TrCH2: type 2, part1= 2, part2= 0 (144)	TrCH1: type 2, part1= 11, part2= 2 (640) TrCH2: type 2, part1= 2, part2= 0 (144)	TrCH1: type 2, part1= 9, part2= 2 (576) TrCH2: type 2, part1= 2, part2= 0 (144)
>>>numberOfTbSizeList	TrCH1: Zero,1, 2 TrCH2: Zero, one	TrCH1: Zero, one TrCH2: Zero, one	TrCH1: Zero, 2 TrCH2: Zero, one	TrCH1: Zero, one, TrCH2: Zero, one
>>>>logicalChannelList	All	All	All	All
>>semiStaticTF- Information				
>>>tti	TrCH1: 40 TrCH2: 40	TrCH1: 20 TrCH2: 40	TrCH1: 20 TrCH2: 40	TrCH1: 40 TrCH2: 40
>>>channelCodingType	TrCH1: Turbo TrCH2: Convolutional	TrCH1: Turbo TrCH2: Convolutional	TrCH1: Turbo TrCH2: Convolutional	TrCH1: Turbo TrCH2: Convolutional
>>>codingRate	TrCH1: N/A TrCH2: Third	TrCH1: N/A TrCH2: Third	TrCH1: N/A TrCH2: Third	TrCH1: N/A TrCH2: Third
>>>rateMatchingAttribute	TrCH1: 180 TrCH2: 160	TrCH1: 185 TrCH2: 160	TrCH1: 170 TrCH2: 160	TrCH1: 165 TrCH2: 160
>>>crc-Size	TrCH1: 16 TrCH2: 16	TrCH1: 16 TrCH2: 16	TrCH1: 16 TrCH2: 16	TrCH1: 16 TrCH2: 16
DL- AddReconfTransChInfoLis t				
>Downlink transport channel type	dch	dch	dch	dch
>dl- TransportChannelIdentity (should be as for UL)	TrCH1: 1, TrCH2: 2	TrCH1: 1, TrCH2: 2	TrCH1: 1, TrCH2: 2	TrCH1: 1, TrCH2: 2
>tfs-SignallingMode	SameAsUL	SameAsUL	SameAsUL	SameAsUL
>>transportFormatSet				
>>>dynamicTF-information >>>>tf0/tf0,1				
>>>rlcSize				
>>>>sizeType >>>numberOfTbSizeList				
>>>numberOf1bSizeList >>>>logicalChannelList				
>>ULTrCH-Id >dch-QualityTarget	TrCH1: 1, TrCH2: 2	TrCH1: 1, TrCH2: 2	TrCH1: 1, TrCH2: 2	TrCH1: 1, TrCH2: 2
>>bler-QualityValue	TrCH1: 2x10 ⁻³ TrCH2: Absent	TrCH1: 2x10 ⁻³ TrCH2: Absent	TrCH1: 2x10 ⁻³ TrCH2: Absent	TrCH1: 1x10 ⁻² TrCH2: Absent
TrCH INFORMATION, COMMON	HOHZ. ADSCHIL	HOHZ. ADSEIR	HOHZ. ADSEIR	TIOTIZ. ADSCIIL
ul-CommonTransChInfo				
>tfcs-ID (TDD only)	1	1	1	1

Configuration	28.8 kbps conv. CS- data + 3.4 kbps signalling	32 kbps conv. CS- data + 3.4 kbps signalling	64kbps conv. CS- data + 3.4 kbps signalling	14.4 kbps streaming CS- data +
				3.4 kbps signalling
>sharedChannelIndicator (TDD only)	FALSE	FALSE	FALSE	FALSE
>tfc-Subset	Absent, not required	Absent, not required	Absent, not required	Absent, not required
>ul-TFCS	Normal TFCI	Normal TFCI	Normal TFCI	Normal TFCI
>>explicitTFCS-	signalling Complete	signalling Complete	signalling Complete	signalling Complete
ConfigurationMode	Complete	Complete	Complete	Complete
>>>ctfcSize	Ctfc4Bit	Ctfc2Bit	Ctfc2Bit	Ctfc4Bit
>>>>TFCS representation	Addition	Addition	Addition	Addition
>>>>TFCS list	(TF0, TF0)	(TF0, TF0)	(TF0, TF0)	(TF0, TF0)
>>>>>ctfc	0	0	0	0
>>>>>gainFactorInform	Computed	Computed	Computed	Computed
>>>>>referenceTFCld	0	0	0	0
>>>>TFCS 2	(TF1, TF0)	(TF1, TF0)	(TF1, TF0)	(TF1, TF0)
>>>>>ctfc >>>>>gainFactorInform	1 Computed	1 Computed	1 Computed	Computed
ation	Computed	Computed	Computed	Computed
>>>>>βc (FDD only)	N/A	N/A	N/A	N/A
>>>>>βd	N/A	N/A	N/A	N/A
>>>>>referenceTFCld	0	0	0	0
>>>>TFCS 3	(TF2, TF0)	(TF0, TF1)	(TF0, TF1)	(TF0, TF1)
>>>>>ctfc >>>>>gainFactorInform	2 Computed	2 Computed	2 Computed	2 Computed
ation	Computed	Computed	Computed	Computed
>>>>>referenceTFCId	0	0	0	0
>>>>TFCS 4	(TF0, TF1)	(TF1, TF1)	(TF1, TF1)	(TF1, TF1)
>>>>>ctfc	3	3	3	3
>>>>>gainFactorInform ation	Computed	Signalled	Signalled	Signalled
>>>>>βc (FDD only)	N/A	8	8	11
>>>>>βd	N/A	15	15	15
>>>>>referenceTFCld	0	0	0	0
>>>>TFCS 5	(TF1, TF1)	N/A	N/A	
>>>>>ctfc >>>>>gainFactorInform	4 Computed			
ation	Compared			
>>>>>referenceTFCId	0			
>>>>TFCS 6	(TF2, TF1)	N/A	N/A	
>>>>>ctfc >>>>>gainFactorInform	5 Signalled			
ation	J.g			
>>>>>βc (FDD only)	8			
>>>>>βd	15			
>>>>>referenceTFCId	0			
>>>>TFCS 7				
>>>>>ctic				
ation				
>>>>>referenceTFCld				
>>>>>TFCS 8				
>>>>>cπc >>>>>gainFactorInform				
ation				
>>>>>referenceTFCId				
>>>>TFCS 9				
>>>>>ctfc >>>>>gainFactorInform				
ation				

Configuration	28.8 kbps conv. CS- data +	32 kbps conv. CS- data +	64kbps conv. CS- data +	14.4 kbps streaming CS-
	3.4 kbps signalling	3.4 kbps signalling	3.4 kbps signalling	data + 3.4 kbps signalling
>>>>>referenceTFCId				
>>>>TFCS 10				
>>>>>ctfc				
>>>>>gainFactorInform ation				
>>>>>βc (FDD only)				
>>>>>βd				
>>>>>referenceTFCId				
dl-CommonTransChInfo				
>tfcs-SignallingMode	Same as UL	Same as UL	Same as UL	Same as UL
PhyCH INFORMATION				
FDD				
UL-DPCH-InfoPredef				
>ul-DPCH- PowerControlInfo				
>>powerControlAlgorithm	Algorithm 1	Algorithm 1	Algorithm 1	Algorithm 1
>>>tpcStepSize	1	1	1	1
>tfci-Existence	TRUE	TRUE	TRUE	TRUE
>puncturingLimit	0.92	0.8	0.92	1
DL- CommonInformationPrede				
f >dl-DPCH-InfoCommon				
>>spreadingFactor	64	64	32	128
>>spreading-actor >>tfci-Existence	TRUE	TRUE	TRUE	TRUE
>>pilotBits	8	8	8	8
>>pilotbits >>positionFixed	Flexible	Flexible	Flexible	Flexible
PhyCH INFORMATION	1 IEXIDIE	1 IEXIDIE	I ICAIDIC	1 IEXIDIE
3.84 Mcps TDD				
UL-DPCH-InfoPredef				
>ul-DPCH-				
PowerControlInfo				
>>dpch-ConstantValue	0	0	0	0
>commonTimeslotInfo				
>>secondInterleavingMod e	frameRelated	frameRelated	frameRelated	frameRelated
>>tfci-Coding	16	8	8	8
>>puncturingLimit	0.44	0.8	0.56	0.8
>>repetitionPeriodAndLen gth	repetitionPeriod1	repetitionPeriod1	repetitionPeriod1	repetitionPeriod1
DL-				
CommonInformationPrede f				
>dl-DPCH-InfoCommon				
>>commonTimeslotInfo				
>>>secondInterleavingMo de	frameRelated	frameRelated	frameRelated	frameRelated
>>>tfci-Coding	16	8	8	8
>>>puncturingLimit	0.44	0.64	0.56	0.8
>>>repetitionPeriodAndLe	repetitionPeriod1	repetitionPeriod1	repetitionPeriod1	repetitionPeriod1
ngth PhyCH INFORMATION	'	'	'	'
1.28 Mcps TDD				
UL-DPCH-InfoPredef				
>commonTimeslotInfo				
>>secondInterleavingMod e	frameRelated	frameRelated	frameRelated	frameRelated
>>tfci-Coding	16	8	8	8
>>puncturingLimit	0.64	0.60	0.64	1

Configuration	28.8 kbps conv. CS- data + 3.4 kbps signalling	32 kbps conv. CS- data + 3.4 kbps signalling	64kbps conv. CS- data + 3.4 kbps signalling	14.4 kbps streaming CS- data + 3.4 kbps signalling
>>repetitionPeriodAndLen gth	repetitionPeriod1	repetitionPeriod1	repetitionPeriod1	repetitionPeriod1
DL- CommonInformationPrede f				
>dl-DPCH-InfoCommon				
>>commonTimeslotInfo				
>>>secondInterleavingMo de	frameRelated	frameRelated	frameRelated	frameRelated
>>>tfci-Coding	16	8	8	8
>>>puncturingLimit	0.64	0.60	0.64	0.88
>>>repetitionPeriodAndLe ngth	repetitionPeriod1	repetitionPeriod1	repetitionPeriod1	repetitionPeriod1

Configuration	28.8 kbps streaming CS- data + 3.4 kbps signalling	57.6 kbps streaming CS- data + 3.4 kbps signalling	12.2 kbps speech(multimode) + 3.4 kbps signalling
Ref 34.108	16	17	1a
Default configuration identity	8	9	10
RB INFORMATION		55 55	
rb-Identity	RB1: 1, RB2: 2, RB3: 3, RB5: 5	RB1: 1, RB2: 2, RB3: 3, RB5: 5	RB1: 1, RB2: 2, RB3: 3, RB5: 5, RB6: 6, RB7: 7
rlc-InfoChoice	RIc-info	RIc-info	RIc-info
>ul-RLC-Mode	RB1: UM RB2- RB3: AM RB5: TM	RB1: UM RB2- RB3: AM RB5: TM	RB1: UM RB2- RB3: AM RB5-RB7: TM
>>transmissionRLC- DiscardMode	RB1: N/A RB2- RB3: NoDiscard RB5: N/A	RB1: N/A RB2- RB3: NoDiscard RB5: N/A	RB1: N/A RB2- RB3: NoDiscard RB5- RB7: N/A
>>>maxDat	RB1: N/A RB2- RB3: 15 RB5: N/A	RB1: N/A RB2- RB3: 15 RB5: N/A	RB1: N/A RB2- RB3: 15 RB5- RB7: N/A
>>transmissionWindowSiz e	RB1: N/A RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise RB5: N/A	RB1: N/A RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise RB5: N/A	RB1: N/A RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise RB5- RB7: N/A
>>timerRST	RB1: N/A RB2- RB3: 300 RB5: N/A	RB1: N/A RB2- RB3: 300 RB5: N/A	RB1: N/A RB2- RB3: 300 RB5- RB7: N/A
>>max-RST	RB1: N/A RB2- RB3: 1 RB5: N/A	RB1: N/A RB2- RB3: 1 RB5: N/A	RB1: N/A RB2- RB3: 1 RB5- RB7: N/A
>>pollingInfo	RB1: N/A RB2- RB3: as below RB5: N/A	RB1: N/A RB2- RB3: as below RB5: N/A	RB1: N/A RB2- RB3: as below RB5- RB7: N/A
>>>lastTransmissionPDU- Poll	RB2- RB3: FALSE	RB2- RB3: FALSE	RB2- RB3: FALSE
>>>lastRetransmissionPD U-Poll	RB2- RB3: FALSE	RB2- RB3: FALSE	RB2- RB3: FALSE
>>>timerPollPeriodic	RB2- RB3: 300	RB2- RB3: 300	RB2- RB3: 300
>>segmentationIndication	RB1- RB3: N/A RB5: FALSE	RB1- RB3: N/A RB5: FALSE	RB1- RB3: N/A RB5- RB7: FALSE

Configuration	28.8 kbps streaming CS-	57.6 kbps streaming CS-	12.2 kbps speech(multimode
	data +	data +) +
	3.4 kbps signalling	3.4 kbps signalling	3.4 kbps signalling
>dl-RLC-Mode	RB1: UM	RB1: UM	RB1: UM
	RB2- RB3: AM	RB2- RB3: AM	RB2- RB3: AM
	RB5: TM	RB5: TM	RB5- RB7: TM
>>inSequenceDelivery	RB1: N/A	RB1: N/A	RB1: N/A
	RB2- RB3: TRUE RB5: N/A	RB2- RB3: TRUE RB5: N/A	RB2- RB3: TRUE RB5- RB7: N/A
>>receivingWindowSize	RB1: N/A	RB1: N/A	RB1: N/A
	RB2- RB3: 128 for	RB2- RB3: 128 for	RB2- RB3: 128 for
	UEs with more than	UEs with more than	UEs with more than
	10 kbyte "total RLC	10 kbyte "total RLC	10 kbyte "total RLC
	AM buffer size" and	AM buffer size" and	AM buffer size" and 32 otherwise
	32 otherwise RB5: N/A	32 otherwise RB5: N/A	RB5- RB7: N/A
>>dl-RLC-StatusInfo	RB1: N/A	RB1: N/A	RB1: N/A
>>ui-RLC-Statusiiiio	RB2- RB3: as below	RB2- RB3: as below	RB2- RB3: as below
	RB5: N/A	RB5: N/A	RB5- RB7: N/A
>>>timerStatusProhibit	RB2- RB3: 100	RB2- RB3: 100	RB2- RB3: 100
>>>missingPDU-Indicator	RB2- RB3: FALSE	RB2- RB3: FALSE	RB2- RB3: FALSE
>>>timerStatusPeriodic	RB2- RB3: 300	RB2- RB3: 300	RB2- RB3: 300
>>segmentationIndication	RB1- RB3: N/A	RB1- RB3: N/A	RB1- RB3: N/A
rb-MappingInfo	RB5: FALSE	RB5: FALSE	RB5- RB7: FALSE
>UL-	Onal agicalChannal	Onal agicalChannal	Onal agicalChannal
LogicalChannelMappings	OneLogicalChannel	OneLogicalChannel	OneLogicalChannel
>>ul-	Dch	Dch	Dch
TransportChannelType	Dail	Don	Dail
>>>transportChannelIdenti	RB1- RB3: 2	RB1- RB3: 2	RB1- RB3: 4
ty	RB5: 1	RB5: 1	RB5: 1, RB6: 2,
			RB7: 3
>>logicalChannelIdentity	RB1: 1, RB2: 2,	RB1: 1, RB2: 2,	RB1: 1, RB2: 2,
	RB3: 3	RB3: 3	RB3: 3
	RB5: N/A	RB5: N/A	RB5- RB7: N/A
>>rlc-SizeList	RB1- RB3:	RB1- RB3:	RB1- RB3:
	configured	configured	configured
	RB5: N/A	RB5: N/A	RB5- RB7: N/A
>>mac-	RB1: 1, RB2: 2, RB3: 3	RB1: 1, RB2: 2, RB3: 3	RB1: 1, RB2: 2, RB3: 3
LogicalChannelPriority	RB5: 5	RB5: 5	RB5- RB7: 5
>DL-	NB3. 3	NDO. 0	100-101.5
IogicalChannelMappingList			
>>Mapping option 1	One mapping option	One mapping option	One mapping option
>>>dl-	Dch	Dch	Dch
TransportChannelType			
>>>>transportChannelIden	RB1- RB3: 2	RB1- RB3: 2	RB1- RB3: 4
tity	RB5: 1	RB5: 1	RB5: 1, RB6: 2,
>>>logicalChannelIdentity	RB1: 1, RB2: 2,	RB1: 1, RB2: 2,	RB7: 3 RB1: 1, RB2: 2,
///iogicalorialineilderitity	RB3: 3	RB3: 3	RB3: 3
	RB5: N/A	RB5: N/A	RB5- RB7: N/A
TrCH INFORMATION PER			
TrCH			
UL-			
AddReconfTransChInfoLis t			
>Uplink transport channel	dch	dch	dch
type			
>transportChannelIdentity	TrCH1: 1, TrCH2: 2	TrCH1: 1, TrCH2: 2	TrCH1: 1, TrCH2: 2, TrCH3: 3, TrCH4: 4
>transportFormatSet	DedicatedTransChT	DedicatedTransChT	DedicatedTransChT
	FS	FS	FS
>>dynamicTF-information			

Configuration	28.8 kbps streaming CS- data +	57.6 kbps streaming CS- data +	12.2 kbps speech(multimode) +
	3.4 kbps signalling	3.4 kbps signalling	3.4 kbps signalling
>>>tf0/ tf0,1	TrCH1: (0x576, 1x576, 2x576) TrCH2: (0x144, 1x144)	TrCH1: (0x576, 1x576, 2x576, 3x576, 4x576) TrCH2: (0x144, 1x144)	TrCH1: (0x81) TrCH2: (0x 103 TrCH3: (0x 60) TrCH4: (0x144)
>>>rlcSize	TrCH1: OctetMode TrCH2:BitMode	TrCH1: OctetMode TrCH2:BitMode	BitMode
>>>>sizeType	TrCH1: type 2, part1= 9, part2= 2 (576) TrCH2: type 2, part1= 2, part2= 0 (144)	TrCH1: type 2, part1= 9, part2= 2 (576) TrCH2: type 2, part1= 2, part2= 0 (144)	TrCH1: type 1: 81 TrCH2: type 1: 103 TrCH3: type 1: 60 TrCH4: 2: type 2, part1= 2, part2= 0 (144)
>>>>numberOfTbSizeList	TrCH1: Zero, one, 2 TrCH2: Zero, one	TrCH1: Zero, one, 2, 3, 4 TrCH2: Zero, one	TrCH1-4: Zero
>>>logicalChannelList	All	All	All
>>>tf 1			TrCH1: (1x39) TrCH2: (1x53) TrCH3: (1x60) TrCH4: (1x144)
>>>numberOfTransportBl ocks			TrCH1-3: One
>>>rlc-Size			TrCH1-3: BitMode
>>>>sizeType			TrCH1: 1: 39 TrCH2: 1: 53 TrCH3: 1: 60
>>>numberOfTbSizeList			TrCH1-3: One
>>>logicalChannelList			TrCH1-3: all
>>>tf 2			TrCH1: (1x42) TrCH2: (1x63) TrCH3- TrCH4: N/A
>>>numberOfTransportBl ocks			TrCH1-2: One
>>>rlc-Size			TrCH1: BitMode
>>>>sizeType			TrCH1: type 1: 42 TrCH2: type 1: 63
>>>numberOfTbSizeList			TrCH1-2: One
>>>>logicalChannelList			TrCH1: all
>>>tf 3			TrCH1: (1x55) TrCH2: (1x84) TrCH3- TrCH4: N/A
>>>numberOfTransportBl ocks			TrCH1-2: One
>>>rlc-Size			TrCH1: BitMode
>>>>sizeType			TrCH1: type 1: 55 TrCH2: type 1: 84
>>>numberOfTbSizeList			TrCH1-2: One
>>>logicalChannelList			TrCH1: all
>>>tf 4			TrCH1: (1x75) TrCH2: (1x103) TrCH3- TrCH4: N/A
>>>numberOfTransportBl ocks			TrCH1-2: One
>>>rlc-Size			TrCH1: BitMode
>>>>sizeType			TrCH1: type 1: 75 TrCH2: type 1: 103
>>>numberOfTbSizeList			TrCH1-2: One
>>>logicalChannelList		_	TrCH1: all
>>>tf 5			TrCH1: (1x81) TrCH2- TrCH4: N/A

	Configuration	28.8 kbps streaming CS- data +	57.6 kbps streaming CS- data +	12.2 kbps speech(multimode) +
Sobstact				,
				TrCH1: One
>>>>numberOfTbSizeList TrCH1: One >>>>slogicalChamnelList TrCH1: 40 TrCH1: 40 TrCH1: 40 TrCH1: 40 TrCH1: 40 TrCH1: 40 TrCH2: 40 TrCH1: TrCH3: 20 TrCH4: 40 TrCH1: TrCH2: 40 TrCH4: 40 TrCH2: 40 TrCH4: 40 TrCH4: 40 TrCH2: 40 TrCH2: 40 TrCH2: 40 TrCH2: 40 TrCH2: 40 TrCH2: 41 TrCH2: 41 TrCH2: 41 TrCH2: 41 TrCH2: 41 TrCH3: 41 TrCH4: 41 TrCH4: 41 TrCH2: 41	>>>rlc-Size			
>>>>EgamiStaticTh- Information TrCH1: 40 TrCH2: 40 TrCH1: 1/2 TrCH1: 1/2 TrCH1: 1/2 TrCH2: 40 TrCH1: 1/2 TrCH2: 40 TrCH1: 1/2 TrCH2: 40 TrCH2: 41 TrCH2: 41 TrCH2: 11 TrCH2: 11 TrCH2: 11 TrCH2: 11 TrCH2: 11 TrCH3: 11 TrCH3: 11 TrCH3: 12 TrCH3: 12 TrCH3: 12 TrCH3: 12 TrCH4: 16 TrCH2: 16 TrCH2: 16 TrCH2: 16 TrCH2: 16 TrCH3: 16 TrC	>>>>sizeType			TrCH1: type 1: 81
Information				TrCH1: all
Systi				
TrCH2: 40		TrCH1: 40	TrCH1: 40	TrCH1- TrCH3: 20
>>>channelCodingType TrCH1: Turbo TrCH2: Convolutional TrCH2: Convolutional TrCH2: Convolutional TrCH2: Convolutional TrCH2: Third Convolutional TrCH2: Third Convolutional TrCH1: Turbo TrCH2: Third TrCH1: Turbo TrCH2: Third TrCH1: Turbo TrCH2: Third TrCH1: TrCH2: Third TrCH1: TrCH2: Third TrCH1: TrCH2: Third TrCH1: Third TrCH1: Third TrCH2: Third TrCH2: Third TrCH1: 14 TrCH1: 190 TrCH2: 190 TrCH2: 190 TrCH2: 190 TrCH2: 190 TrCH2: 190 TrCH2: 190 TrCH3: 335 TrCH4: 160 TrCH2: 190 TrCH3: 190 TrCH3: 170 TrCH3: 170 TrCH3: 170 TrCH3: 170	1			
TrCH2:	>>>channelCodingType			
>>>>codingRate TrCH1: N/A TrCH2: Third TrCH1: N/A TrCH2: Third TrCH1: Third TrCH1: Third TrCH2: Third TrCH1: Third TrCH2: Third TrCH3: Half TrCH4: Third TrCH2: Third TrCH2: 160 TrCH1: 145 TrCH2: 160 TrCH1: 190 TrCH3: 235 TrCH4: 160 TrCH2: 190 TrCH3: 235 TrCH4: 160 TrCH4: 160 TrCH4: 160 TrCH4: 16 TrCH4: 17 TrCH4: 16 TrCH4: 17 TrCH4: 17 TrCH4: 17 TrCH4: 17 TrCH4: 17	3 71	TrCH2:	TrCH2:	
TrCH2: Third		Convolutional	Convolutional	
TrCH2: Third	>>>codingRate	TrCH1: N/A	TrCH1: N/A	TrCH1- TrCH2:
Normal TFCH Normal TFCL Normal	Į ,	TrCH2: Third	TrCH2: Third	Third
>>>rateMatchingAttribute TrCH1: 155 TrCH2: 160 TrCH1: 145 TrCH2: 160 TrCH1: 200 TrCH2: 190 TrCH2: 190 TrCH2: 135 TrCH4: 160 >>>crc-Size TrCH1: 16 TrCH2: 16 TrCH1: 16 TrCH2: 16 TrCH1: 12 TrCH2: 16 TrCH1: 12 TrCH2: 16 DL- AddReconfTransChInfoLis t DL- AddReconfTransChInfoLis t TrCH1: 1, TrCH2: 16 TrCH1: 1, TrCH2: 16 >Downlink transport channel type dch dch dch >dl- TransportChannelIdentity (should be as for UL) TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2, TrCH3: 3, TrCH4: 4 >>tfs-SignallingMode SameAsUL SameAsUL Independent -Only f0 on TrCH1 is different and shown below> >>transportFormatSet DedicatedTransChT FS DedicatedTransChT FS >>>systof(bf0,1) TrCH1: (1x0) >>>sizeType TrCH1: (1x0) >>>sizeType TrCH1: (1x0) >>>sysizeType TrCH1: 0ne >>>numberOfTbSizeList TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2 >>>lul-TrCH-Id TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2 >bler-QualityValue TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH2: A				TrCH3: Half
TrCH2: 160				TrCH4: Third
TrCH3: 235 TrCH4: 16	>>>rateMatchingAttribute			
TrCH1: 16		TrCH2: 160	TrCH2: 160	
>>>cro-Size TrCH1: 16 TrCH2: 12 TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2 TrCH3: 3, TrCH4: 4 TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 1 TrCH1: 1, TrCH2: 2 TrCH1: 1, TrC				
DL- AddReconfTransChInfoLis t >Downlink transport dch dch channel type >dI- TrCH1: 1, TrCH2: 2 >dI- TransportChannelIdentity (should be as for UL) >tfs-SignallingMode >>trs-SignallingMode >>trs-Signalling >>trs-Signalling TrcH1: 1, TrcH2: 2 TrcH1: 1, TrcH2: 2 TrcH1: 1, TrcH1: 1,				
DL- AddReconfTransChInfoLis t Downlink transport channel type >dch TrCH1: 1, TrCH2: 2 TransportChannelIdentity (should be as for UL) >tfs-SignallingMode >>tfs-SignallingMode the pendent (Only tf0 on TrCH1 is different and shown below)	>>>crc-Size			
DL- AddReconfTransChInfoLis t >Downlink transport channel type >dl- TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2 TrCH3: 3, TrCH4: 4 SameAsUL SameAsUL SameAsUL Independent (Only tf0 on TrCH1 is different and shown belows) >>transportFormatSet >>>transportFormatSet >>>stransportFormatSet >>>stransportFormatSet >>>stransportFormatSet >>>stransportFormatSet >>>stransportFormatSet >>>bitMode TrCH1: (1x0) TrCH1: (1x10) TrCH1: (1x0) TrCH1: (1x10) TrCH1: (1x0) TrCH1: (1x10) TrCH1: (1x0) TrCH1: (1x0		TrCH2: 16	TrCH2: 16	
AddReconfTransChInfoLis t >Downlink transport channel type >dl- TransportChannelIdentity (should be as for UL) >tfs-SignallingMode >>tfs-SignallingMode >>transportFormatSet >>tmansportFormatSet >>stameAsUL SameAsUL SameAsUL Independent (Only ft0 on TrCH1 is different and shown belows) >>transportFormation >>>tf0 tf0,1 >>>srlcSize >>>numberOfTbSizeList >>>lutrrCH-Id TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2 TrCH1: (1x0) bitMode >>>>sizeType >>>numberOfTbSizeList >>bitMode TrCH1: 0ne All >>ULTrCH-Id TrCH1: 1, TrCH2: 2 TrCH1: 1x10 ⁻² TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH2: TrCH4: Absent TrCH2: TrCH4: Absent TrCH3: ATTCH4: Absent TrCH4: TrCH4: Absent TrCH5: ID (TDD only) 1				TrCH4: 16
channel type >dl- TransportChannelIdentity (should be as for UL) >tfs-SignallingMode >sameAsUL SameAsUL SameAsUL Independent -(Only tf0 on TrCH1 is different and shown below> >>tfoly tf0,1 >>>strounder of the time of time of the time of time of the time of t	AddReconfTransChInfoLis			
>dI- TransportChannelIdentity (should be as for UL) TrCH1: 1, TrCH2: 2 TrCH3: 3, TrCH4: 4 >tfs-SignallingMode SameAsUL Independent -Only tf0 on TrCH1 is different and shown below> >>tfrshoft fformation DedicatedTransChT FS >>>stransportFormatSet TrCH1: (1x0) >>>stf0/ tf0,1 TrCH1: (1x0) >>>slogicalChannelList TrCH1: type 1: 0 TrCH1: type 1: 0 >>>logicalChannelList TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2 TrCH3: 3, TrCH4: 4 >dch-QualityTarget TrCH1: 1x10 ⁻² TrCH2: Absent TrCH1: 7x10 ⁻³ TrCH2: TrCH4: Absent TrCH INFORMATION, COMMON TrCH1: 1x10 ⁻² TrCH2: Absent TrCH1: 7x10 ⁻³ TrCH2: TrCH4: Absent TrCB INFORMATION, COMMON TrCH1: 1x10 ⁻² TrCH2: Absent TrCH3: 3, TrCH4: 4 Vefc-ID (TDD only) 1 1 >sharedChannelIndicator (TDD only) 1 1 >sharedChannelIndicator (TDD only) FALSE FALSE FALSE FALSE FALSE Very Interpretation Absent, not required Absent, not required Pomplete Complete Complete	>Downlink transport	dch	dch	dch
TransportChannelIdentity (should be as for UL) >tfs-SignallingMode >>tfs-SignallingMode >>tfs-Signalling Independent	channel type			
SameAsUL	TransportChannelIdentity	TrCH1: 1, TrCH2: 2	TrCH1: 1, TrCH2: 2	
>>>dynamicTF-information >>>>tf0/tf0,1 >>>>rlcSize bitMode >>>>sizeType TrCH1: type 1: 0 >>>numberOfTbSizeList >>>logicalChannelList >>ULTrCH-Id TrCH1: 1, TrCH2: 2 TrCH1: 1x10 ⁻² TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH3: 3, TrCH4: 4 Absent TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH3: 3, TrCH4: 4 FALSE TrCH3: 3, TrCH4: 4 Absent TrCH2- TrCH4: Absent TrCH2- TrCH4: Absent TrCH3: Absent TrCH4: Absent TrCH4: TrCH4: Absent TrCH5- TrCH4: Absent TrCH6- Tr	>tfs-SignallingMode	SameAsUL	SameAsUL	<only and="" below="" different="" is="" on="" shown="" tf0="" trch1=""></only>
>>>>tfl0/ tf0,1 >>>>rlcSize >>>>sizeType >>>>logicalChannelList >>ULTrCH-Id TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2 TrCH3: 3, TrCH4: 4 >dch-QualityTarget >>bler-QualityValue TrCH1: 1x10 ⁻² TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH3: 3, TrCH4: 4 >dch-QualityValue TrCH3: 1x10 ⁻² TrCH3: Absent TrCH4: 1x10 ⁻³ TrCH4: Absent TrCH4: Absent TrCH5-ID (TDD only) >ffc-Subset Absent, not required Absent, not required Absent, not required Absent, not required >vexplicitTFCS- Normal TFCI signalling	>>transportFormatSet			
>>>>rlcSize >>>>sizeType >>>>numberOfTbSizeList >>>>logicalChannelList >>ULTrCH-Id TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2 TrCH3: 3, TrCH4: 4 >dch-QualityTarget >>bler-QualityValue TrCH1: 1x10 ⁻² TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH3: 3, TrCH4: 4 >dch-QualityTarget >>bler-QualityValue TrCH1: 1x10 ⁻² TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH3: 3, TrCH4: 4 >dch-QualityValue TrCH1: 1x10 ⁻² TrCH1: 1x10 ⁻² TrCH1: 7x10 ⁻³ TrCH2- TrCH4: Absent TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH3: 3, TrCH4: 4 >>bler-QualityValue TrCH1: 1x10 ⁻² TrCH1: 1x10 ⁻² TrCH1: 7x10 ⁻³ TrCH2- TrCH4: Absent TrCH2: Absent TrCH3: 3, TrCH4: 4 >>bler-QualityValue TrCH3: 3, TrCH4: 4 >>bler-QualityValue TrCH1: 1x10 ⁻² TrCH1: 1x10 ⁻² TrCH1: 1x10 ⁻² TrCH1: 1x10 ⁻² TrCH3: 3, TrCH4: 4 >>bler-QualityValue TrCH1: 1x10 ⁻² TrCH1: 1x10 ⁻³ TrCH1: 7x10 ⁻³ TrCH2: Absent TrCH1: 7x10 ⁻³ TrCH2: Absent TrCH1: 7x10 ⁻³ TrCH3: 3, TrCH4: 4 >>bler-QualityValue TrCH3: 3, TrCH4: 4 >>bler-QualityValue TrCH3: 3, TrCH4: 4 >>bler-QualityValue TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2:				
>>>>sizeType >>>>numberOfTbSizeList >>>>logicalChannelList >>ULTrCH-Id TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2 TrCH3: 3, TrCH4: 4 >dch-QualityTarget >>bler-QualityValue TrCH1: 1x10 ⁻² TrCH2: Absent TrCH3: 3, TrCH4: 4				\ /
>>>>numberOfTbSizeList >>>>logicalChannelList >>ULTrCH-Id TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2 TrCH3: 3, TrCH4: 4 >dch-QualityTarget >>bler-QualityValue TrCH1: 1x10 ⁻² TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH3: 3, TrCH4: 4 TrCH1: 1x10 ⁻² TrCH1: 1x10 ⁻² TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH3: 7x10 ⁻³ TrCH2- TrCH4: Absent TrCH2- TrCH4: Absent TrCH3: Absent TrCH3: 7x10 ⁻³ TrCH3:				
>>>>logicalChannelList >>ULTrCH-Id TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2 TrCH3: 3, TrCH4: 4 >dch-QualityTarget >>bler-QualityValue TrCH1: 1x10 ⁻² TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH2: TrCH3: 3, TrCH4: 4				
>>ULTrCH-Id TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2 TrCH1: 1, TrCH2: 2 TrCH3: 3, TrCH4: 4 >>bler-QualityValue TrCH1: 1x10 ⁻² TrCH1: 1x10 ⁻² TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH2: TrCH2: TrCH3: 3, TrCH4: 4 TrCH1: 1x10 ⁻² TrCH1: 1x10 ⁻² TrCH2: TrCH2: TrCH2: TrCH2: TrCH2: TrCH2: TrCH2: TrCH2: TrCH3: TrCH2: TrCH3:				
TrCH3: 3, TrCH4: 4				
>dch-QualityTargetTrCH1: 1x10^2 TrCH2: AbsentTrCH1: 1x10^2 TrCH2: AbsentTrCH1: 1x10^2 TrCH2: AbsentTrCH1: 7x10^3 TrCH2- TrCH4: AbsentTrCH INFORMATION, COMMONCOMMONInterpretation of the composition of the compo	>>ULTrCH-Id	TrCH1: 1, TrCH2: 2	TrCH1: 1, TrCH2: 2	
>>bler-QualityValue	>dch-QualityTarget			<u> </u>
TrCH2: Absent TrCH2: Absent TrCH2: Absent TrCH2- TrCH4: Absent TrCH1. TXT0 TrCH INFORMATION, COMMON ul-CommonTransChInfo >tfcs-ID (TDD only) 1 1 1 1 >sharedChannelIndicator (TDD only) >tfc-Subset Absent, not required Absent, not required Absent, not required >ul-TFCS Normal TFCI signalling signalling >>explicitTFCS- Complete Complete Complete		TrCU1: 1×10-2	TrCU1: 1×10-2	TrCU1. 7v10-3
COMMON ul-CommonTransChInfo >tfcs-ID (TDD only) >sharedChannelIndicator (TDD only) >tfc-Subset Absent, not required Absent, not re	, , , , , , , , , , , , , , , , , , , ,			TrCH2- TrCH4:
>tfcs-ID (TDD only) 1 1 1 >sharedChannelIndicator (TDD only) FALSE FALSE FALSE >tfc-Subset Absent, not required Absent, not required Absent, not required >ul-TFCS Normal TFCI signalling Normal TFCI signalling Normal TFCI signalling >>explicitTFCS- Complete Complete Complete				
>sharedChannelIndicator (TDD only) FALSE FALSE FALSE >tfc-Subset Absent, not required Absent, not required Absent, not required >ul-TFCS Normal TFCI signalling Normal TFCI signalling Normal TFCI signalling >>explicitTFCS- Complete Complete Complete	ul-CommonTransChInfo			
>sharedChannelIndicator (TDD only) FALSE FALSE FALSE >tfc-Subset Absent, not required Absent, not required Absent, not required >ul-TFCS Normal TFCI signalling Normal TFCI signalling Normal TFCI signalling >>explicitTFCS- Complete Complete Complete	>tfcs-ID (TDD only)	1	1	1
>tfc-Subset Absent, not required Absent, not required Absent, not required >ul-TFCS Normal TFCI Normal TFCI Normal TFCI signalling signalling signalling >>explicitTFCS- Complete Complete Complete	>sharedChannelIndicator	FALSE	FALSE	FALSE
>ul-TFCS Normal TFCI signalling Normal TFCI signalling Normal TFCI signalling Normal TFCI signalling >>explicitTFCS- Complete Complete Complete		Absent not required	Absent not required	Absent not required
signalling signalling signalling >>explicitTFCS- Complete Complete Complete				
>>explicitTFCS- Complete Complete Complete	31 11 00			
	>>explicitTFCS-			
	ConfigurationMode			

Configuration	28.8 kbps streaming CS-	57.6 kbps streaming CS-	12.2 kbps speech(multimode
	data + 3.4 kbps signalling	data + 3.4 kbps signalling) + 3.4 kbps signalling
>>>ctfcSize	Ctfc4Bit	Ctfc4Bit	Ctfc8Bit
>>>TFCS representation	Addition	Addition	Addition
>>>>TFCS list	7 taattori	7 tadition	/ tadition
>>>>TFCS 1	(TF0, TF0)	(TF0, TF0)	(TF0, TF0, TF0, TF0)
>>>>>ctfc	0	0	0
>>>>>gainFactorInform ation	Computed	Computed	Computed
>>>>>>referenceTFCId	0	0	0
>>>>TFCS 2	(TF1, TF0)	(TF1, TF0)	(TF1, TF0, TF0, TF0)
>>>>>ctfc	1	1	1
>>>>>gainFactorInform ation	Computed	Computed	Computed
>>>>>βc (FDD only)	N/A	N/A	N/A
>>>>>βd	N/A	N/A	N/A
>>>>>referenceTFCId	0	0	0
>>>>TFCS 3	(TF2, TF0)	(TF2, TF0)	(TF2, TF1, TF0, TF0)
>>>>>ctfc	2	2	8
>>>>>gainFactorInform ation	Computed	Computed	Computed
>>>>>referenceTFCId	0	0	0
>>>>TFCS 4	(TF0, TF1)	(TF3, TF0)	(TF3, TF2, TF0, TF0)
>>>>>ctfc	3	3	15
>>>>>gainFactorInform ation	Computed	Computed	Computed
>>>>>βc (FDD only)	N/A	N/A	N/A
>>>>>βd	N/A	N/A	N/A
>>>>>>referenceTFCId	0	0	0
>>>>>TFCS 5	(TF1, TF1)	(TF4, TF0)	(TF4, TF3, TF0, TF0)
>>>>>ctfc	4	4	22
>>>>>gainFactorInform ation	Computed	Computed	Computed
>>>>>>referenceTFCId	0	0	0
>>>>>TFCS 6	(TF2, TF1)	(TF0, TF1)	(TF5, TF4, TF1, TF0)
>>>>>ctfc	5	5	59
>>>>>gainFactorInform ation	Signalled	Computed	Computed
>>>>>βc (FDD only)	8	N/A	N/A
>>>>>βd	15	N/A	N/A
>>>>>>referenceTFCld	0	(TE4, TE4)	(TEO TEO TEO TEA)
>>>>TFCS 7		(TF1, TF1)	(TF0,TF0,TF0,TF1)
>>>>>ctfc >>>>>gainFactorInform		Computed	60 Computed
ation		0	·
>>>>>referenceTFCId		(TF2, TF1)	0 (TF1,TF0,TF0,TF1)
>>>>>ctfc		7	61
>>>>>gainFactorInform ation		Computed	Computed
>>>>>referenceTFCId		0	0
>>>>TFCS 9		(TF3, TF1)	(TF2,TF1,TF0,TF1)
>>>>>ctfc		8	68
>>>>> sgainFactorInform ation		Computed	Computed

Configuration	28.8 kbps streaming CS-	57.6 kbps streaming CS-	12.2 kbps speech(multimode
	data +	data +) +
	3.4 kbps signalling	3.4 kbps signalling	3.4 kbps signalling
>>>>>referenceTFCId		0	0
>>>>TFCS 10		(TF4, TF1)	(TF3,TF2,TF0,TF1)
>>>>>ctfc		9	75
>>>>>gainFactorInform ation		Signalled	Computed
>>>>>βc (FDD only)		8	N/A
>>>>>βd		15	N/A
>>>>>referenceTFCId		0	0
>>>>TFCS 11			(TF4,TF3,TF0,TF1)
>>>>>ctfc			82
>>>>>gainFactorInform			Computed
ation			
>>>>>referenceTFCId			(TEE TEA TEA TEA)
>>>>TFCS 12			(TF5,TF4,TF1,TF1) 119
>>>>>ctfc >>>>>gainFactorInform			Signalled
ation			
>>>>>βc (FDD only)			11
>>>>>βd			15
>>>>>referenceTFCId			0
dl-CommonTransChInfo			
>tfcs-SignallingMode	Same as UL	Same as UL	Same as UL
PhyCH INFORMATION FDD			
UL-DPCH-InfoPredef			
>ul-DPCH-			
PowerControlInfo			
>>powerControlAlgorithm	Algorithm 1	Algorithm 1	Algorithm 1
>>>tpcStepSize	1	1	1
>tfci-Existence	TRUE	TRUE	TRUE
>puncturingLimit DL-	I	1	0.88
CommonInformationPrede			
>dl-DPCH-InfoCommon			
>>spreadingFactor	64	32	128
>>tfci-Existence	TRUE	TRUE	FALSE
>>pilotBits	8	8	4
>>positionFixed	Flexible	Flexible	Fixed
PhyCH INFORMATION 3.84 Mcps TDD			
UL-DPCH-InfoPredef			
>ul-DPCH-			
PowerControlInfo			
>>dpch-ConstantValue	0	0	0
>commonTimeslotInfo			
>>secondInterleavingMod e	frameRelated	frameRelated	frameRelated
>>tfci-Coding	16	16	16
>>puncturingLimit	0.44	0.48	0.88
>>repetitionPeriodAndLen gth	repetitionPeriod1	repetitionPeriod1	repetitionPeriod1
DL-			
CommonInformationPrede f			
>dl-DPCH-InfoCommon			
>>commonTimeslotInfo			
>>>secondInterleavingMo	frameRelated	frameRelated	frameRelated
de			

Configuration	28.8 kbps streaming CS- data + 3.4 kbps signalling	57.6 kbps streaming CS- data + 3.4 kbps signalling	12.2 kbps speech(multimode) + 3.4 kbps signalling
>>>tfci-Coding	16	16	16
>>>puncturingLimit	0.44	0.48	0.92
>>>repetitionPeriodAndLe ngth	repetitionPeriod1	repetitionPeriod1	repetitionPeriod1
PhyCH INFORMATION 1.28 Mcps TDD			
UL-DPCH-InfoPredef			
>commonTimeslotInfo			
>>secondInterleavingMod e	frameRelated	frameRelated	
>>tfci-Coding	16	16	
>>puncturingLimit	0.64	0.72	
>>repetitionPeriodAndLen gth	repetitionPeriod1	repetitionPeriod1	
DL- CommonInformationPrede f			
>dl-DPCH-InfoCommon			
>>commonTimeslotInfo			
>>>secondInterleavingMo de	frameRelated	frameRelated	frameRelated
>>>tfci-Coding	16	16	16
>>>puncturingLimit	0.64	0.72	0.92
>>>repetitionPeriodAndLe ngth	repetitionPeriod1	repetitionPeriod1	repetitionPeriod1

Configuration	10.2/6.7/5.9/4.75 kbps speech + 3.4 kbps signalling	7.4/6.7/5.9/4.75 kbps speech + 3.4 kbps signalling
Ref 34.108	N/A	N/A
Default configuration	11	12
identity		12
RB INFORMATION		
rb-Identity	RB1: 1, RB2: 2,	RB1: 1, RB2: 2,
10-identity	RB3: 3, RB5: 5,	RB3: 3, RB5: 5,
	RB6: 6, RB7: 7,	RB6: 6, RB7: 7
	RB8: 8	11.00.0, 11.07.7
rlc-InfoChoice	RIc-info	RIc-info
>ul-RLC-Mode	RB1: UM	RB1: UM
	RB2- RB3: AM	RB2- RB3: AM
	RB5-RB7: TM	RB5-RB6: TM
>>transmissionRLC-	RB1: N/A	RB1: N/A
DiscardMode	RB2- RB3:	RB2- RB3:
	NoDiscard	NoDiscard
	RB5- RB7: N/A	RB5- RB6: N/A
>>>maxDat	RB1: N/A	RB1: N/A
	RB2- RB3: 15	RB2- RB3: 15
transparia ai an Min da Cin	RB5- RB7: N/A	RB5- RB6: N/A
>>transmissionWindowSiz	RB1: N/A RB2- RB3: 128 for	RB1: N/A RB2- RB3: 128 for
e	UEs with more than	UEs with more than
	10 kbyte "total RLC	10 kbyte "total RLC
	AM buffer size" and	AM buffer size" and
	32 otherwise	32 otherwise
	RB5- RB7: N/A	RB5- RB6: N/A
>>timerRST	RB1: N/A	RB1: N/A
	RB2- RB3: 300	RB2- RB3: 300
	RB5- RB7: N/A	RB5- RB6: N/A
>>max-RST	RB1: N/A	RB1: N/A
	RB2- RB3: 1	RB2- RB3: 1
	RB5- RB7: N/A	RB5- RB6: N/A
>>pollingInfo	RB1: N/A	RB1: N/A
	RB2- RB3: as below RB5- RB7: N/A	RB2- RB3: as below RB5- RB6: N/A
>>>lastTransmissionPDU-	RB2- RB3: FALSE	RB2- RB3: FALSE
Poll		
>>>lastRetransmissionPD U-Poll	RB2- RB3: FALSE	RB2- RB3: FALSE
>>>timerPollPeriodic	RB2- RB3: 300	RB2- RB3: 300
>>segmentationIndication	RB1- RB3: N/A	RB1- RB3: N/A
	RB5- RB7: FALSE	RB5- RB6: FALSE
>dl-RLC-Mode	RB1: UM	RB1: UM
	RB2- RB3: AM RB5- RB7: TM	RB2- RB3: AM RB5- RB6: TM
	RB8: TM	RB7: TM
>>inSequenceDelivery	RB1: N/A	RB1: N/A
	RB2- RB3: TRUE	RB2- RB3: TRUE
	RB5- RB8: N/A	RB5- RB7: N/A
>>receivingWindowSize	RB1: N/A	RB1: N/A
	RB2- RB3: 128 for	RB2- RB3: 128 for
	UEs with more than	UEs with more than
	10 kbyte "total RLC	10 kbyte "total RLC
	AM buffer size" and	AM buffer size" and
	32 otherwise	32 otherwise
# DLO C: : : : :	RB5- RB8: N/A	RB5- RB7: N/A
>>dl-RLC-StatusInfo	RB1: N/A	RB1: N/A
	RB2- RB3: as below	RB2- RB3: as below RB5- RB7: N/A
>>>timerStatusProhibit	RB5- RB8: N/A RB2- RB3: 100	RB5- RB7: N/A RB2- RB3: 100
>>>timerStatusPronibit >>>missingPDU-Indicator	RB2- RB3: T00	RB2- RB3: 100 RB2- RB3: FALSE
>>>timerStatusPeriodic	RB2- RB3: 300	RB2- RB3: 300
uniterotatusi enoute	11D2-11D3, 300	11DZ-11DJ, JUU

>>segmentationIndication rb-MappingInfo >UL- LogicalChannelMappings >>ul- TransportChannelType >>>transportChannelIdentit	RB1- RB3: N/A RB5- RB8: FALSE OneLogicalChannel	RB1- RB3: N/A RB5- RB7: FALSE OneLogicalChannel
>UL- LogicalChannelMappings >>ul- TransportChannelType		
>UL- LogicalChannelMappings >>ul- TransportChannelType	OneLogicalChannel	Onel oricalChannel
LogicalChannelMappings >>ul- TransportChannelType	OneLogicalChannel	Onel odicalChannel
>>ul- TransportChannelType		
TransportChannelType		
	Dch	Dch
>>>transportChannalldantit		
>>>iransportonannendentit	RB1- RB3: 4	RB1- RB3: 3
у	RB5: 1, RB6: 2,	RB5: 1, RB6: 2
	RB7: 3,	
>>logicalChannelIdentity	RB1: 1, RB2: 2,	RB1: 1, RB2: 2,
	RB3: 3	RB3: 3
	RB5- RB7: N/A	RB5- RB6: N/A
>>rlc-SizeList	RB1- RB3:	RB1- RB3:
	configured	configured
	RB5- RB7: N/A	RB5- RB6: N/A
>>mac-	RB1: 1, RB2: 2,	RB1: 1, RB2: 2,
LogicalChannelPriority	RB3: 3	RB3: 3
	RB5- RB7: 5	RB5- RB6: 5
>DL-		
logicalChannelMappingList		
>>Mapping option 1	One mapping option	One mapping option
>>>dl-	Dch	Dch
TransportChannelType	טטו	וויסטו
>>>transportChannelIden	RB1- RB3: 4	RB1- RB3: 3
	RB1- RB3: 4 RB5: 1, RB6: 2,	
tity		RB5: 1, RB6: 2,
1 : 101 111 13	RB7: 3, RB8: 5	RB7:4
>>>logicalChannelIdentity	RB1: 1, RB2: 2,	RB1: 1, RB2: 2,
	RB3: 3	RB3: 3
	RB5- RB8: N/A	RB5- RB7: N/A
TrCH INFORMATION PER		
TrCH		
UL-		
AddReconfTransChInfoList		
>Uplink transport channel	dch	dch
type		
>transportChannelIdentity	TrCH1: 1, TrCH2: 2,	TrCH1: 1, TrCH2: 2,
	TrCH3: 3, TrCH4: 4	TrCH3: 3
>transportFormatSet	DedicatedTransChT	DedicatedTransChT
	FS	FS
>>dynamicTF-information		
>>>tf0/ tf0,1	TrCH1: (0x65)	TrCH1: (0x61)
	TrCH2: (0x 99)	TrCH2: (0x 87)
	TrCH3: (0x 40,	TrCH3: (0x 144,
	1x40)	1x144)
	TrCH4: (0x144,	
	1x144) `	
>>>>rlcSize	BitMode	BitMode
>>>>sizeType	TrCH1: type 1: 65	TrCH1: type 1: 61
"	TrCH2: type 1: 99	TrCH2: type 1: 87
	TrCH3: type 1: 40	TrCH3: 2: type 2,
	TrCH4: 2: type 2,	part1= 2, part2= 0
	part1= 2, part2= 0	(144)
	(144)	
>>>numberOfTbSizeList	TrCH1-2: Zero	TrCH1-2: Zero
	TrCH3-4: Zero, one	TrCH3: Zero, one
>>>logicalChannelList	All	All
>>>tf 1	TrCH1: (1x39)	TrCH1: (1x39)
' " '	TrCH2: (1x 53)	TrCH2: (1x53)
	TrCH3- TrCH4: N/A	TrCH3: N/A
>>>numberOfTransportBl	TrCH1: One	TrCH1: One
ocks	TrCH2: One	TrCH2: One
>>>rlc-Size	TrCH1-2: BitMode	TrCH1-2: BitMode
	TrCH1: 1: 39	TrCH1: 1: 39
>>>>sizeType		TrCH1: 1: 39
	TrCH2: 1: 53 TrCH1-2: One	TrCH1: 1: 53 TrCH1-2: One
>>>>numberOfTbSizeList	Trumi-2. One	CH -2" ()NA

Systr 2	>>>>logicalChannelList	TrCH1: all	TrCH1: all
Tr.CH2: (1x63) Tr.CH3: N/A		TrCH1: (1x42)	TrCH1: (1x42)
>>>>numberOfTransportBI ocks TrCH1: One TrCh2: One TrCh2: One TrCh2: One TrCh2: One TrCh2: One TrCh2: One TrCh1: BitMode TrCH1: BitMode TrCH1: BitMode TrCH1: BitMode TrCH1: BitMode TrCH1: Spe 1: 42 TrCH1: type 1: 42 TrCH1: type 1: 42 TrCH2: Upe 1: 63 TrCH2: One TrCH3:		TrCH2: (1x63)	
ocks Tr.Ch2: One Tr.Ch2: One >>>>>IT.Ch1: BitMode Tr.Ch1: BitMode Tr.Ch1: Iype 1: 42 Tr.Ch1: Iype 1: 63 Tr.Ch1: Iype 1: 63 Tr.Ch2: Iype 1: 63 Tr.Ch2: Iype 1: 63 Tr.Ch2: One Tr.Ch2: Ch2: Ch2: Ch2: Ch2: Ch2: Ch2: Ch2:			
>>>>ric-Size			
>>>>sizeType TrCH1: type 1: 42 TrCH2: type 1: 63 TrCH1: type 1: 63 TrCH2: type 1: 63 TrCH2: type 1: 63 TrCH2: type 1: 63 TrCH2: one TrCH2: one TrCH2: One TrCH2: One TrCH2: One TrCH1: all TrCH2: type 1: 76 TrCH2: (1x76) TrCH2: (1x76) TrCH2: (1x76) TrCH3: N/A TrCH2: cone TrCH2: One TrCH2: One TrCH2: One TrCH2: One TrCH2: type 1: 76 TrCH1: type 1: 55 TrCH2: type 1: 76 TrCH1: type 1: 55 TrCH2: type 1: 76 TrCH2: One TrCH2: type 1: 76 TrCH3: One TrCH2: type 1: 76 TrCH1: One TrCH2: type 1: 76 TrCH2: type 1: 55 TrCH2: type 1: 76 TrCH2: type 1: 76 </td <td></td> <td></td> <td></td>			
TricH2: type 1: 63			
>>>>numberOfTbSizeList TrCH1: One TrCH2: One	>>>>sizeType		TrCH1: type 1: 42
TrCH2: One			
>>>>logicalChannelList	>>>>numberOf1bSizeList		
TrCH2: all TrCH2: all TrCH2: all	1		
System	>>>>logicalChanneiList		-
TrCH2: (1x76) TrCH3: N/A TrCH3: N/A	>>+f 2		
TrCH3: TrCH4: N/A TrCH3: N/A TrCH3: N/A TrCH3: N/A TrCH1: One TrCH1: One TrCH2: One TrCH2: One TrCH2: One TrCH2: One TrCH2: One TrCH2: Size TrCH1: BitMode TrCH1: BitMode TrCH1: BitMode TrCH1: BitMode TrCH1: BitMode TrCH1: SitMode TrCH1: SitMode TrCH1: SitMode TrCH1: SitMode TrCH1: One TrCH1: One TrCH2: One TrCH3: One	>>>u 3		
>>>>numberOfTransportBl ocks TrCh1: One TrCh2: One TrCh2: One TrCh1: BitMode TrCh1: Ch1: BitMode TrCh2: One TrCh1: BitMode >>>>sizeType TrCH1: type 1: 55 TrCH1: type 1: 55 TrCH2: type 1: 76 TrCH1: type 1: 55 TrCH2: type 1: 76 >>>>numberOfTbSizeList TrCH1: One TrCH2: One TrCH2: type 1: 76 >>>>logicalChannelList TrCH1: all TrCH2: One TrCH2: One >>>tf 4 TrCH1: (1x58) TrCH2: (1x99) TrCH2: (1x99) TrCH3: (1x99) TrCH3: (1x97) TrCH3: N/A TrCH1: (1x58) TrCH2: (1x99) TrCH2: (1x97) TrCH3: N/A TrCH1: (1x58) TrCH2: (1x97) TrCH3: N/A TrCH1: One TrCH2: (1x87) TrCH3: One TrCH1: One TrCH3: One TrCH1: BitMode TrCH1: One TrCH2: One TrCH1: (1x61) TrCH2: all TrCH1: (1x61)			
ocks TrCh2: One TrCh2: One >>>>Inch1: BitMode TrCH1: BitMode TrCH1: BitMode >>>>>sizeType TrCH1: type 1: 55 TrCH1: type 1: 76 TrCH2: type 1: 76 TrCH2: type 1: 76 TrCH2: type 1: 76 >>>>numberOfTbSizeList TrCH2: One TrCH2: One TrCH1: One TrCH1: One TrCH2: One TrCH2: all TrCH2: all TrCH2: all >>>Inch2: all TrCH2: all TrCH2: all TrCH2: all TrCH2: all TrCH2: all TrCH3: N/A TrCH3: N/A TrCH3: N/A >>>numberOfTransportBl TrCH1: BitMode TrCH1: Dne TrCH2: Dne TrCH1: BitMode TrCH1: BitMode >>>>numberOfTbSizeList TrCH1: One TrCH2: One TrCH2: One TrCH1: One TrCH1: One TrCH3: One TrCH4: N/A TrCH1: One TrCH4: N/A TrCH1: TrCH2: One	>>>>numberOfTransportBl		
>>>sizeType TrCH1: BitMode TrCH1: BitMode >>>>sizeType TrCH1: type 1: 55 TrCH2: type 1: 76 TrCH1: type 1: 76 >>>>numberOfTbSizeList TrCH1: One TrCH2: One TrCH1: One TrCH2: One >>>slogicalChannelList TrCH1: all TrCH2: all TrCH2: all TrCH2: all TrCH2: dall >>>tf 4 TrCH1: (1x58) TrCH2: (1x99) TrCH3- TrCH4: N/A TrCH2: (1x87) TrCH3: N/A >>>numberOfTransportBl ocks TrCH1: One TrCh2: One TrCH1: One TrCH2: One >>>rch3- TrCH1: Vppe 1: 58 TrCH2: type 1: 99 TrCH1: One TrCH2: One TrCH1: One TrCH2: One >>>>numberOfTbSizeList TrCH1: Cone TrCH2: One TrCH1: One TrCH2: One TrCH1: One TrCH2: One >>>>logicalChannelList TrCH1: One TrCH2- TrCH4: N/A TrCH2: all TrCH1: Gall TrCH1: Gall >>>>tf 5 TrCH1: One TrCH2- TrCH4: N/A TrCH2- TrCH4: N/A >>>>numberOfTransportBl ocks TrCH1: One TrCH2- TrCH4: N/A TrCH1: One TrCH2: all >>>>tf 5 TrCH1: One TrCH2- TrCH4: N/A TrCH1: One TrCH2: all >>>>numberOfTransportBl ocks TrCH1: One TrCH1: One TrCH1: One >>>>tf 5 TrCH1: TrCH2: One TrCH1: One TrCH1: One TrCH1: One <td>=</td> <td></td> <td></td>	=		
>>>>sizeType TrCH1: type 1: 55 TrCH2: type 1: 76 TrCH1: type 1: 55 TrCH2: type 1: 76 TrCH1: type 1: 55 TrCH2: type 1: 76 >>>>numberOfTbSizeList TrCH1: One TrCH2: One TrCH2: One TrCH2: all TrCH2: all TrCH2: all TrCH2: all TrCH2: all TrCH2: all TrCH2: (1x87) TrCH3: TrCH4: N/A TrCH3: N/A TrCH1: (1x58) TrCH2: (1x87) TrCH2: (1x87) TrCH3: TrCH4: N/A >>>>numberOfTransportBI Ocks TrCH1: One TrCh2: One TrCh2: One TrCh2: One TrCH2: Upe 1: 99 TrCH2: type 1: 99 TrCH2: type 1: 99 TrCH2: type 1: 99 TrCH2: type 1: 99 TrCH2: one TrCH2: One TrCH2: One TrCH2: One TrCH2: One TrCH2: all TrCH2: all TrCH2: all TrCH2: all TrCH2: all TrCH2: all TrCH2: all TrCH2: all TrCH2: all TrCH1: One TrCH1: One Ocks >>>slogicalChannelList TrCH1: BitMode TrCH1: One TrCH2: One TrCH1: One TrCH2: TrCH4: N/A TrCH2: TrCH4: N/A TrCH2: TrCH4: N/A TrCH2: TrCH4: N/A TrCH1: BitMode TrCH1: Dne TrCH1: One TrCH1: One >>>sizeType TrCH1: BitMode TrCH1: One TrCH1: One TrCH1: Dne TrCH1: One >>>sizeType TrCH1: BitMode TrCH1: One TrCH1: One >>>sizeType TrCH1: TrCH2: TrCH4: N/A TrCH1: One >>>sizeType TrCH1: One TrCH1: One >>>sizeType TrCH1: TrCH2: TrCH4: N/A TrCH1: One >>>sizeType TrCH1: One TrCH1: One >>>semistaticTF-Information TrCH1: TrCH2: TrCH2: TrCH3: 0 TrCH1: TrCH2: TrCH3: 0 TrCH3: 100 <			
TrCH2: type 1: 76			
>>>>numberOfTbSizeList TrCH1: One TrCH2: all >>>>tf 4 TrCH1: (1x58) TrCH2: all TrCH2: all TrCH2: all TrCH2: all TrCH2: (1x87) TrCH3: TrCH4: N/A TrCH3: N/A >>>numberOfTransportBl ocks TrCH1: (1x58) TrCH4: N/A TrCH3: N/A >>>>numberOfTransportBl ocks TrCH1: BitMode TrCH1: BitMode TrCH2: One TrCH2: One TrCH2: One TrCH2: Uppe 1: 58 TrCH1: Uppe 1: 58 TrCH2: Uppe 1: 58 TrCH2: Uppe 1: 58 TrCH2: Uppe 1: 87 TrCH2: Uppe 1: 87 TrCH2: Uppe 1: 87 TrCH2: One TrCH3: One	· · · · · · · · · · · · · · · · · · ·		
TrCH2: One	>>>>numberOfTbSizeList		
>>>IogicalChannelList TrCH1: all TrCH2: all TrCH2: all TrCH2: all TrCH2: all TrCH2: all TrCH2: (1x98) TrCH2: (1x98) TrCH2: (1x99) TrCH3- TrCH4: N/A >>>>numberOfTransportBl ocks TrCH1: One TrCH1: One TrCH2: Uppe 1: 58 TrCH2: Uppe 1: 99 TrCH2: Uppe 1: 87 >>>>numberOfTbSizeList TrCH1: One TrCH1: One TrCH1: Uppe 1: 58 TrCH2: Uppe 1: 99 TrCH2: Uppe 1: 87 >>>>numberOfTbSizeList TrCH1: One TrCH1: One TrCH2: One TrCH2: One TrCH2: Uppe 1: 87 >>>>logicalChannelList TrCH1: One TrCH1: One TrCH1: One TrCH2: all TrCH2: TrCH4: N/A TrCH2- TrCH4: N/A >>>>tf 5 TrCH1: One TrCH1: All TrCH2: All TrCH1: All TrCH2: All TrCH1: All TrCH			
TrCH2: all	>>>>logicalChannelList		
TrCH2: (1x99) TrCH2: (1x87) TrCH3: N/A TrCH3: N/A TrCH3: N/A TrCH3: N/A TrCH3: N/A TrCH3: N/A TrCH1: One TrCh2: One TrCh2: One TrCh2: One TrCh2: One TrCh2: One TrCH1: BitMode TrCH1: BitMode TrCH1: BitMode TrCH1: BitMode TrCH1: BitMode TrCH1: BitMode TrCH1: Uspe 1: 58 TrCH2: Uspe 1: 99 TrCH2: Uspe 1: 87 TrCH2: Uspe 1: 87 TrCH2: One TrCH3: One		TrCH2: all	TrCH2: all
TrCH3- TrCH4: N/A TrCH3: N/A N	>>>tf 4		TrCH1: (1x58)
>>>>numberOfTransportBI ocks TrCH1: One TrCh2: One TrCH1: One TrCh2: One >>>>rlc-Size TrCH1: BitMode TrCH1: BitMode >>>>sizeType TrCH1: type 1: 58 TrCH2: type 1: 99 TrCH1: type 1: 58 TrCH2: type 1: 87 >>>>numberOfTbSizeList TrCH1: One TrCH2: One TrCH1: dll TrCH2: One >>>>logicalChannelList TrCH1: all TrCH2: mone >>>tf 5 TrCH1: (1x65) TrCH1: (1x61) TrCH2: TrCH4: N/A >>>>numberOfTransportBI ocks TrCH1: BitMode >>>>rlc-Size TrCH1: BitMode TrCH1: Dne >>>>sizeType TrCH1: type 1: 42 TrCH1: type 1: 42 >>>>numberOfTbSizeList TrCH1: One TrCH1: type 1: 42 >>>sizeType TrCH1: One TrCH1: all >>>>sizeType TrCH1: TrCH3: 20 TrCH1: all >>>semistaticTF-Information TrCH1: TrCH3: 20 TrCH1: all >>>channelCodingType Convolutional Convolutional >>>channelCodingType Convolutional TrCH1: TrCH2: TrCH3: 40 >>>codingRate TrCH1: 120 TrCH1: 1200 TrCH2: 190 TrCH2: 190 TrCH2			TrCH2: (1x87)
ocks TrCh2: One TrCh2: One >>>>rlc-Size TrCH1: BitMode TrCH1: BitMode >>>>sizeType TrCH1: type 1: 58			
>>>>rlc-Size TrCH1: BitMode TrCH1: BitMode >>>>sizeType TrCH1: type 1: 58 TrCH2: type 1: 99 TrCH1: type 1: 58 TrCH2: type 1: 87 >>>>numberOfTbSizeList TrCH1: One TrCH2: One TrCH1: One TrCH2: One >>>>logicalChannelList TrCH1: all TrCH2: all TrCH1: all TrCH2: all >>>tf 5 TrCH1: (1x65) TrCH2- TrCH4: N/A TrCH1: (1x61) TrCH2- TrCH4: N/A >>>numberOfTransportBl ocks TrCH1: One TrCH1: One >>>rlc-Size TrCH1: BitMode TrCH1: BitMode >>>sizeType TrCH1: type 1: 42 TrCH1: type 1: 42 >>>sologicalChannelList TrCH1: One TrCH1: all >>>semistaticTF-Information TrCH1: all TrCH1: all >>>channelCodingType Convolutional Convolutional >>>channelCodingType Convolutional Convolutional >>>codingRate TrCH1: TrCH2: TrCH2: Third TrCH1: TrCH2: Third TrCH3: 235 TrCH3: 190 TrCH2: 190 TrCH3: 235 TrCH3: 160 TrCH4: 160 TrCH2: 0 TrCH2: 0 TrCH4: 16 TrCH2: 0 TrCH2: 0 TrCH3: 16	=		
>>>>sizeType TrCH1: type 1: 58 TrCH2: type 1: 99 TrCH1: type 1: 58 TrCH2: type 1: 87 >>>>numberOfTbSizeList TrCH1: One TrCH2: One TrCH1: One TrCH2: One >>>logicalChannelList TrCH1: all TrCH2: all TrCH1: all TrCH2: all >>>tf 5 TrCH1: (1x65) TrCH2- TrCH4: N/A TrCH1: (1x61) TrCH2- TrCH4: N/A >>>numberOfTransportBl ocks TrCH1: One TrCH1: Done >>>rlc-Size TrCH1: BitMode TrCH1: BitMode >>>sizeType TrCH1: type 1: 42 TrCH1: type 1: 42 >>>numberOfTbSizeList TrCH1: One TrCH1: One >>>sizeType TrCH1: One TrCH1: One >>>sizeType TrCH1: TrCH2: TrCH1: all >>>sizeType TrCH1: TrCH2: One TrCH1: One >>>sizeType TrCH1: TrCH2: TrCH1: all >>>sizeType TrCH1: TrCH2: One TrCH1: One >>>sizeType TrCH1: TrCH2: One TrCH1: TrCH2: One >>>sizeType TrCH1: TrCH2:			
TrCH2: type 1: 99			
>>>>numberOfTbSizeList TrCH1: One TrCH2: One TrCH1: One TrCH2: One >>>>logicalChannelList TrCH1: all TrCH2: hl/A >>>tf 5 TrCH1: (1x65) TrCH1: (1x61) TrCH2: TrCH4: N/A >>>numberOfTransportBl ocks TrCH1: One TrCH1: One >>>srlc-Size TrCH1: BitMode TrCH1: BitMode >>>sizeType TrCH1: type 1: 42 TrCH1: type 1: 42 >>>numberOfTbSizeList TrCH1: One TrCH1: One TrCH1: One >>>slogicalChannelList TrCH1: all TrCH1: all TrCH1: all >>semistaticTF-Information TrCH1: TrCH3: 20 TrCH1: all TrCH1: TrCH2: 20 TrCH3: 40 >>>channelCodingType Convolutional Convolutional >>>codingRate TrCH1- TrCH2: TrCH2: Third TrCH3: 40 TrCH1: TrCH3: 10 TrCH1: 200 TrCH3: 13: 160 >>>rateMatchingAttribute TrCH1: 12 TrCH2: 190 TrCH2: 190 TrCH2: 190 TrCH2: 190 TrCH2: 190 TrCH3: 160 TrCH4: 160 >>>crc-Size TrCH1: 12 TrCH3: 0 TrCH2: 0 TrCH3: 16 TrCH4: 16 DL-AddReconfTransChInfoList AddReconfTransChInfoList Adch >odl- Adch Adch	>>>>size l ype		
TrCH2: One TrCH2: One Section			
>>>slogicalChannelList TrCH1: all TrCH2: all TrCH2: all TrCH2: all TrCH2: all TrCH2: all TrCH2: all >>>tf 5 TrCH1: (1x65) TrCH4: N/A TrCH1: (1x61) TrCH2- TrCH4: N/A >>>>numberOfTransportBI ocks TrCH1: One TrCH1: One >>>>rlc-Size TrCH1: BitMode TrCH1: BitMode >>>>sizeType TrCH1: type 1: 42 TrCH1: type 1: 42 >>>numberOfTbSizeList TrCH1: One TrCH1: type 1: 42 >>>numberOfTbSizeList TrCH1: all TrCH1: One >>>sopigicalChannelList TrCH1: all TrCH1: all >>semistaticTF-Information TrCH1: all TrCH1: all >>semistaticTF-Information TrCH1: all TrCH1: all >>>channelCodingType Convolutional Convolutional >>>channelCodingType Convolutional Convolutional >>>codingRate TrCH1: TrCH2: TrCH2: TrCH1: TrCH2: TrCH3: Third TrCH4: Third TrCH3: Third TrCH4: 160 TrCH3: 1200 TrCH2: 190 TrCH2: 100 TrCH2:	>>>>numberOf1bSizeList		
TrCH2: all	>>> logicalChannell ist		
>>>tf 5 TrCH1: (1x65) TrCH2: N/A TrCH1: (1x61) TrCH2- TrCH4: N/A >>>>numberOfTransportBI ocks TrCH1: One TrCH1: One >>>>rlc-Size TrCH1: BitMode TrCH1: BitMode >>>>sizeType TrCH1: type 1: 42 TrCH1: type 1: 42 >>>numberOfTbSizeList TrCH1: One TrCH1: One >>>>logicalChannelList TrCH1: all TrCH1: all >>>semistaticTF-Information TrCH1: TrCH3: 20 TrCH3: 40 >>>channelCodingType Convolutional Convolutional >>>codingRate TrCH1- TrCH2: TrCH2: TrCH3: 40 TrCH1- TrCH2: TrCH3: 40 >>>codingRate TrCH1- TrCH2: TrCH2: TrCH3: TrCH3: Third TrCH3: Third TrCH4: Third TrCH3: TrCH3: Third TrCH3: Third >>>rateMatchingAttribute TrCH1: 200 TrCH2: 190 TrCH2: 190 TrCH2: 190 TrCH2: 190 TrCH3: 160 TrCH4: 160 >>>crc-Size TrCH1: 12 TrCH3: 0 TrCH2: 0 TrCH2: 0 TrCH3: 16 TrCH4: 16 TrCH3: 16 DL-AddReconfTransChInfoList >Downlink transport channel type dch dch	////JogicalCharmelList		
TrCH2-TrCH4: N/A >>>>numberOfTransportBl ocks >>>>rlc-Size	>>>tf 5		
>>>>numberOfTransportBI ocks >>>>rlc-Size	777.1.0		
ocks TrCH1: BitMode TrCH1: BitMode >>>>sizeType TrCH1: type 1: 42 TrCH1: type 1: 42 >>>>numberOfTbSizeList TrCH1: One TrCH1: One >>>>logicalChannelList TrCH1: all TrCH1: all >>semistaticTF-Information TrCH1- TrCH3: 20 TrCH1- TrCH2: 20 >>>tti TrCH4: 40 TrCH3: 40 >>>channelCodingType Convolutional Convolutional >>>codingRate TrCH1- TrCH2: TrCH2: Third TrCH3: Half TrCH3: Third TrCH3: Half TrCH3: Half TrCH3: Third TrCH3: Third >>>rateMatchingAttribute TrCH1: 200 TrCH2: 190 TrCH2: 190 TrCH2: 190 TrCH2: 190 TrCH3: 160 TrCH4: 160 TrCH3: 12 TrCH3: 0 TrCH3: 16 >>>crc-Size TrCH1: 12 TrCH3: 0 TrCH2: 0 TrCH2: 0 TrCH3: 16 DL-AddReconfTransChInfoList Addh >Downlink transport channel type dch >dl-	>>>>numberOfTransportBl		
>>>>sizeType TrCH1: type 1: 42 TrCH1: type 1: 42 >>>>numberOfTbSizeList TrCH1: One TrCH1: One >>>slogicalChannelList TrCH1: all TrCH1: all >>semistaticTF-Information TrCH1: all TrCH1: all >>>semistaticTF-Information TrCH1: TrCH3: 20 TrCH1: TrCH2: 20 TrCH4: 40 TrCH3: 40 Convolutional >>>channelCodingType Convolutional Convolutional TrCH1: TrCH2: TrCH2: TrCH1: TrCH2: Third TrCH3: Half TrCH3: Third TrCH3: Half TrCH3: Half TrCH3: Third TrCH4: Third >>>rateMatchingAttribute TrCH1: 200 TrCH1: 200 TrCH2: 190 TrCH2: 190 TrCH2: 190 TrCH3: 160 TrCH4: 160 TrCH4: 160 >>>crc-Size TrCH1: 12 TrCH3: 0 TrCH2: 0 TrCH2: 0 TrCH2: 0 TrCH3: 16 DL-AddReconfTransChInfoList AddReconfTransChInfoList >Downlink transport channel type dch >dl-	ocks		
>>>>numberOfTbSizeList TrCH1: One TrCH1: One >>>>logicalChannelList TrCH1: all TrCH1: all >>semistaticTF-Information TrCH1- TrCH3: 20 TrCH1- TrCH2: 20 TrCH3: 40 >>>tti TrCH4: 40 TrCH3: 40 >>>channelCodingType Convolutional >>>codingRate TrCH1- TrCH2: TrCH1- TrCH2: Third TrCH3: Half TrCH3: Half TrCH3: Half TrCH4: Third >>>rateMatchingAttribute TrCH1: 200 TrCH1: 200 TrCH2: 190 TrCH2: 190 TrCH2: 190 TrCH3: 160 >>>crc-Size TrCH1: 12 TrCH1: 12 TrCH3: 160 >>>crc-Size TrCH1: 12 TrCH3: 0 TrCH2: 0 TrCH2: 0 TrCH3: 16 DL-AddReconfTransChInfoList AddReconfTransChInfoList >Downlink transport channel type dch dch	>>>>rlc-Size	TrCH1: BitMode	TrCH1: BitMode
>>>>logicalChannelList TrCH1: all TrCH1: all >>semistaticTF-Information TrCH1- TrCH3: 20 TrCH1- TrCH2: 20 TrCH3: 40 >>>channelCodingType Convolutional Convolutional >>>codingRate TrCH1- TrCH2: TrCH1- TrCH2: Third TrCH1- TrCH2: Third TrCH3: Half TrCH3: Half TrCH3: Third TrCH4: Third >>>rateMatchingAttribute TrCH1: 200 TrCH1: 200 TrCH2: 190 TrCH2: 190 TrCH3: 160 TrCH3: 235 TrCH3: 160 TrCH4: 160 >>>crc-Size TrCH1: 12 TrCH2: 0 TrCH2: 0 TrCH2: 0 TrCH2: 0 TrCH4: 16 DL- AddReconfTransChInfoList Adch >Downlink transport channel type dch >dl-	>>>>sizeType	TrCH1: type 1: 42	TrCH1: type 1: 42
>>semistaticTF-Information >>>tti	>>>>numberOfTbSizeList		TrCH1: One
>>>tti TrCH1- TrCH3: 20 TrCH4: 40 TrCH1- TrCH2: 20 TrCH3: 40 >>>channelCodingType Convolutional Convolutional >>>>codingRate TrCH1- TrCH2: Third TrCH3: Half TrCH3: Half TrCH4: Third TrCH1- TrCH2: Third TrCH3: Third >>>rateMatchingAttribute TrCH1: 200 TrCH2: 190 TrCH2: 190 TrCH3: 235 TrCH4: 160 TrCH1: 200 TrCH3: 160 >>>crc-Size TrCH1: 12 TrCH2- TrCH3: 0 TrCH4: 16 TrCH1: 12 TrCH2: 0 TrCH3: 16 DL- AddReconfTransChInfoList dch >Downlink transport channel type dch		TrCH1: all	TrCH1: all
TrCH4: 40	>>semistaticTF-Information		
>>>channelCodingType Convolutional Convolutional >>>>codingRate TrCH1- TrCH2: TrCH1- TrCH2: Third Third TrCH3: Half TrCH3: Half TrCH4: Third TrCH3: Third TrCH3: Third TrCH3: Third TrCH4: Third >>>rateMatchingAttribute TrCH1: 200 TrCH1: 200 TrCH2: 190 TrCH2: 190 TrCH3: 235 TrCH3: 160 TrCH4: 160 TrCH1: 12 TrCH3: 160 TrCH2: 0 TrCH2: 0 TrCH2: 0 TrCH4: 16 DL-AddReconfTransChInfoList AddhacconfTransChInfoList >Downlink transport channel type dch	>>>tti		
>>>>codingRate			
Third			
TrCH3: Half TrCH3: Third TrCH4: Third TrCH4: Third TrCH4: Third TrCH1: 200 TrCH1: 200 TrCH2: 190 TrCH2: 190 TrCH3: 235 TrCH3: 160 TrCH4: 160 TrCH4: 160 TrCH4: 160 TrCH2: 0 TrCH2: 0 TrCH2: 0 TrCH3: 16 TrCH3: 16 TrCH4: 16 TrCH3: 1	>>>>codingRate		
TrCH4: Third		-	
>>>rateMatchingAttribute			Trums: Third
TrCH2: 190 TrCH2: 190 TrCH3: 235 TrCH3: 160 >>>crc-Size TrCH1: 12 TrCH1: 12 TrCH2- TrCH3: 0 TrCH2: 0 TrCH4: 16 TrCH3: 16 DL- AddReconfTransChInfoList >Downlink transport dch channel type >dl-	>>>rateMatching Attribute		TrCH1: 200
TrCH3: 235 TrCH4: 160 >>>crc-Size TrCH1: 12 TrCH2- TrCH3: 0 TrCH3: 16 TrCH2: 0 TrCH3: 16 DL- AddReconfTransChInfoList >Downlink transport channel type >dl-	>iateiviatoriirigAttribute		
TrCH4: 160			
>>>crc-Size			
TrCH2- TrCH3: 0 TrCH2: 0 TrCH3: 16 DL- AddReconfTransChInfoList >Downlink transport channel type >dl-	>>>crc-Size		TrCH1: 12
TrCH4: 16 TrCH3: 16 DL- AddReconfTransChInfoList >Downlink transport dch channel type >dl-			
DL- AddReconfTransChInfoList >Downlink transport dch channel type >dl-			
>Downlink transport dch dch channel type dl-	DL-		
channel type >dl-			
>dl-		dch	dch
· 			
I ransportChannelIdentity			
	IransportChannelIdentity		

(O: II: M I	I	I
>tfs-SignallingMode	Independent	Independent
	<only on="" td="" tf0="" trch1<=""><td><only on="" td="" tf0="" trch1<=""></only></td></only>	<only on="" td="" tf0="" trch1<=""></only>
	and tf0/tf1 on	and tf0/tf1 on
	TrCH5 are different	TrCH4 are different
	and shown below>	and shown below>
>>transportFormatSet		<u> </u>
>>>dynamicTF-information		
•	= 0.11 (1 0)	
>>>>tf0/ tf0,1	TrCH1: (1x0)	TrCH1: (1x0)
	TrCH5: (0x3, 1x3)	TrCH4: (0x3, 1x3)
>>>rlcSize	BitMode	bitMode
>>>>sizeType	TrCH1: type 1: 0	TrCH1: type 1: 0
7.	TrCH5: type 1: 3	TrCH4: type 1: 3
>>>numberOfTbSizeList	TrCH1: One	TrCH1: One
	TrCH5: Zero, one	TrCH4: Zero, one
logicalChannell ist	All	
>>>>logicalChannelList	1 2 22	All
>>>semistaticTF-	same as UL except	same as DL except
Information	for TrCH5	for TrCH4
>>>>tti	TrCH5: 20	TrCH4: 20
>>>>channelCodingType	Convolutional	Convolutional
>>>>codingRate	TrCH5: Third	TrCH4: Third
>>>rateMatchingAttribute	TrCH5: 200	TrCH4: 111110
>>>crc-Size	TrCH5: 12	TrCH4: 12
>>ULTrCH-Id	TrCH1: 1, TrCH2: 2,	TrCH1: 1, TrCH2: 2,
	TrCH3: 3, TrCH4: 4,	TrCH3: 3
>dch-QualityTarget		
>>bler-QualityValue	T 0114 = 13-3	T 0114 = 1:-3
ZZBICI Quality value	TrCH1: 7x10 ⁻³	TrCH1: 7x10 ⁻³
	TrCH2- TrCH5:	TrCH2- TrCH4:
	Absent	Absent
TrCH INFORMATION,		
COMMON		
ul-CommonTransChInfo		
	 	_
>tfcs-ID (TDD only)	1	1
>sharedChannelIndicator	FALSE	FALSE
(TDD only)		
> tfc-Subset	Absent, not required	Absent, not required
>ul-TFCS	Normal TFCI	Normal TFCI
7 4	signalling	signalling
>>explicitTFCS-	Complete	Complete
	Complete	Complete
ConfigurationMode	0.4 - 5.1	0.4 0.51
>>>ctfcSize	Ctfc6Bit	Ctfc6Bit
>>>>TFCS representation	Addition	Addition
>>>>TFC list		
>>>>TFC 1	(TF0, TF0, TF0,	(TF0, TF0, TF0)
	TF0)	(1. 5, 1. 5, 1. 6)
		0
>>>>>ctfc	0	0
>>>>>gainFactorInform	Computed	Computed
ation		
>>>>>>referenceTFCld	0	0
>>>>TFC 2	(TF1, TF0, TF0,	(TF1, TF0, TF0)
		` ' ' ' ' ' '
	1 1F())	
>>>>>ctfc	TF0)	1
>>>>>ctfc	1	1
>>>>>gainFactorInform		1 Computed
	1 Computed	Computed
>>>>>gainFactorInform ation	1	'
>>>>>gainFactorInform ation >>>>>>βc (FDD only)	1 Computed	Computed N/A
>>>>>gainFactorInform ation >>>>>>βc (FDD only) >>>>>>βd	1 Computed N/A N/A	Computed N/A N/A
>>>>>gainFactorInform ation >>>>>>βc (FDD only) >>>>>>βd >>>>>>referenceTFCId	1 Computed N/A N/A 0	Computed N/A N/A 0
>>>>>gainFactorInform ation >>>>>>βc (FDD only) >>>>>>βd	1 Computed N/A N/A 0 (TF2, TF1, TF0,	Computed N/A N/A
>>>>>gainFactorInform ation >>>>>>βc (FDD only) >>>>>>βd >>>>>>referenceTFCId	1 Computed N/A N/A 0	Computed N/A N/A 0
$>>>>> gainFactorInform \\ ation \\ >>>>> \beta c (FDD only) \\ >>>>>> \beta d \\ >>>>> TFC 3$	1 Computed N/A N/A 0 (TF2, TF1, TF0,	Computed N/A N/A 0
$\begin{tabular}{lllllllllllllllllllllllllllllllllll$	1 Computed N/A N/A 0 (TF2, TF1, TF0, TF0) 8	Computed N/A N/A 0 (TF2, TF1, TF0)
$\begin{tabular}{lllllllllllllllllllllllllllllllllll$	1 Computed N/A N/A 0 (TF2, TF1, TF0, TF0)	N/A N/A 0 (TF2, TF1, TF0)
$\label{eq:controller} $$ >>>>> \beta c (FDD only) $$ >>>>> \beta d $$ >>>>> FC 3 $$ >>>>> Ctfc $$ >>>>> gainFactorInform ation $$ $$ $$ >>>> Ctfc $$ >>>>> gainFactorInform ation $$ $$ >>>> Ctfc $$ >>>>> Ctfc $$ >>>>> Ctfc $$ >>>>> Ctfc $$ $$ >>>>> Ctfc $$ $$ $$ $$ $$ $$ $$ $$ $$ $$ $$ $$ $$$	1 Computed N/A N/A 0 (TF2, TF1, TF0, TF0) 8 Computed	Computed N/A N/A 0 (TF2, TF1, TF0) 8 Computed
$\begin{tabular}{lllllllllllllllllllllllllllllllllll$	1 Computed N/A N/A 0 (TF2, TF1, TF0, TF0) 8 Computed 0	Computed N/A N/A 0 (TF2, TF1, TF0) 8 Computed 0
$\label{eq:controller} $$ >>>>> \beta c (FDD only) $$ >>>>> \beta d $$ >>>>> FC 3 $$ >>>>> Ctfc $$ >>>>> gainFactorInform ation $$ $$ and $$ a$	1 Computed N/A N/A 0 (TF2, TF1, TF0, TF0) 8 Computed 0 (TF3, TF2, TF0,	Computed N/A N/A 0 (TF2, TF1, TF0) 8 Computed
$\label{eq:controller} $$>>>>> \beta c (FDD only)$$ $>>>>> \beta d$$ $>>>>> Feference TFC Id$$ $>>>>> TFC 3$$ $>>>>> gain Factor Inform ation$$>>>>> reference TFC Id$$ $>>>>> Feference TFC Id$$ $>>>>> TFC 3$$ $$ $>>>>> TFC 3$$ $$ $>>>>> TFC 3$$ $$ $>>>>> TFC 3$$ $$ $$ $$ $$ $$ $$ $$ $$ $$ $$ $$ $$$	1 Computed N/A N/A 0 (TF2, TF1, TF0, TF0) 8 Computed 0 (TF3, TF2, TF0, TF0)	Computed N/A N/A 0 (TF2, TF1, TF0) 8 Computed 0
>>>>>gainFactorInform ation >>>>>>βc (FDD only) >>>>>>βd >>>>>referenceTFCId >>>>>>tfc 3 >>>>>ctfc >>>>>>gainFactorInform ation >>>>>referenceTFCId	1 Computed N/A N/A 0 (TF2, TF1, TF0, TF0) 8 Computed 0 (TF3, TF2, TF0,	Computed N/A N/A 0 (TF2, TF1, TF0) 8 Computed 0

	T = .	T = .
>>>>>gainFactorInform	Computed	Computed
ation		
>>>>>βc (FDD only)		
>>>>>βd		
>>>>>>referenceTFCId	0	0
>>>>TFC 5	(TF4, TF3, TF0,	(TF4, TF3, TF0)
	TF0)	
>>>>>ctfc	22	22
>>>>>gainFactorInform	Computed	Computed
ation		
>>>>>referenceTFCld	0	(TEE TEA TEO)
>>>>TFC 6	(TF5, TF4, TF1,	(TF5, TF4, TF0)
	TF0)	20
>>>>>ctfc >>>>>gainFactorInform	59 Computed	29 Computed
ation	Computed	Computed
>>>>>>βc (FDD only)		
>>>>>βd	0	
>>>>>>referenceTFCId	(TEO TEO TEO	(TEO TEO TE1)
>>>>TFC 7	(TF0, TF0, TF0,	(TF0, TF0, TF1)
>>>>>	TF1)	20
>>>>>CtfC	60 Computed	30 Computed
>>>>>gainFactorInform	Computed	Computed
>>>>>>referenceTFCId	0	0
>>>>>TFC 8	(TF1, TF0, TF0,	(TF1, TF0, TF1)
	TF1)	(11 1, 11 0, 11 1)
>>>>>ctfc	61	31
>>>>>gainFactorInform	computed	computed
ation		
>>>>>βc (FDD only)		
>>>>>βd		
>>>>>referenceTFCId	0	0
>>>>TFC 9	(TF2, TF1, TF0,	(TF2, TF1, TF1)
	TF1)	(2, ,)
>>>>>ctfc	68	38
>>>>>gainFactorInform	computed	computed
ation		
>>>>>>referenceTFCld	0	0
>>>>TFC 10	(TF3, TF2, TF0,	(TF3, TF2, TF1)
-	TF1)	
>>>>>ctfc	75	45
>>>>>gainFactorInform	computed	computed
ation		
>>>>>βc (FDD only)		
>>>>>βd		
>>>>>>referenceTFCId	0	0
>>>>TFC 11	(TF4, TF3, TF0,	(TF4, TF3, TF1)
	TF1)	
>>>>>ctfc	82	52
>>>>>gainFactorInform	computed	computed
ation		
>>>>>>referenceTFCId	0 /TE5 TE4 TE4	(TEE TEA TEA)
>>>>TFC 12	(TF5, TF4, TF1, TF1)	(TF5, TF4, TF1)
>>>>>ctfc	97	59
>>>>>scitc	signalled	signalled
ation	Jigilalieu	Signalieu
>>>>>>βc (FDD only)	11	11
	15	15
>>>>>βd		
>>>>>>referenceTFCId	0	0
> TFC subset list	(append ===== 40.0)	(opensh rate 7.4)
>>TFC subset 1	(speech rate 10.2)	(speech rate 7.4)

>>> Allowed transport	(TFC1, TFC2,	(TFC1, TFC2,
format combination list	TFC7, TFC8, TFC6,	TFC7, TFC8, TFC6,
TOTTIAL COMBINATION IIST		
	TFC12)	TFC12)
>>TFC subset 2	(speech rate 6.7)	(speech rate 6.7)
>>> Allowed transport	(TFC1, TFC2,	(TFC1, TFC2,
format combination list	TFC7, TFC8, TFC5,	TFC7, TFC8, TFC5,
	TFC11)	TFC11)
>>TFC subset 3	(speech rate 5.9)	(speech rate 5.9)
	(TFC1, TFC2,	
>>> Allowed transport		(TFC1, TFC2,
format combination list	TFC7, TFC8, TFC4,	TFC7, TFC8, TFC4,
	TFC10)	TFC10)
>>TFC subset 4	(speech rate 4.75)	(speech rate 4.75)
>>> Allowed transport	(TFC1, TFC2,	(TFC1, TFC2,
format combination list	TFC7, TFC8, TFC3,	TFC7, TFC8, TFC3,
	TFC9)	TFC9)
dl CommonTranaChlafa	11 00)	11 03)
dl-CommonTransChInfo		
>tfcs-SignallingMode	Independent	Independent
ul-CommonTransChInfo		
>tfcs-ID (TDD only)	1	1
>sharedChannelIndicator	FALSE	FALSE
	· / LOL	· /\LOL
(TDD only)	Absort	Absort
> tfc-Subset	Absent, not required	Absent, not required
>dl-TFCS	Normal TFCI	Normal TFCI
	signalling	signalling
>>explicitTFCS-	Complete	Complete
ConfigurationMode		
>>ctfcSize	Ctfc6Bit	Ctfc6Bit
>>>TFCS representation	Addition	Addition
>>>>TFCS list		
>>>>TFC 1	(TF0, TF0, TF0,	(TF0, TF0, TF0,
	TF0, TF0)	TF0)
>>>>>ctfc	0	0
	•	•
>>>>TFC 2	(TF1, TF0, TF0,	(TF1, TF0, TF0,
	TF0, TF0)	TF0)
>>>>>ctfc	1	1
>>>>TFC 3	(TF2, TF1, TF0,	(TF2, TF1, TF0,
	TF0, TF0)	TF0)
>>>>>ctfc	8	8
>>>>TFC 4	(TF3, TF2, TF0,	(TF3, TF2, TF0,
<i>>>>>></i> 11 C 4		, , , ,
	TF0, TF0)	TF0)
>>>>>ctfc	15	15
>>>>TFC 5	(TF4, TF3, TF0,	(TF4, TF3, TF0,
	TF0, TF0)	TF0)
>>>>>ctfc	22	22
>>>>TFC 6	(TF5, TF4, TF1,	(TF5, TF4, TF0,
	TF0, TF0)	TF0)
	· ' /	- /
>>>>>ctfc	59	29
	(TF0, TF0, TF0,	(TF0, TF0, TF1,
>>>>TFC 7	,	
>>>> IFG /	TF1, TF0)	TF0)
>>>>>IFC /	,	
>>>>>ctfc	TF1, TF0) 60	TF0) 30
	TF1, TF0) 60 (TF1, TF0, TF0,	TF0) 30 (TF1, TF0, TF1,
>>>>>ctfc	TF1, TF0) 60 (TF1, TF0, TF0, TF1, TF0)	TF0) 30 (TF1, TF0, TF1, TF0)
>>>>>ctfc >>>>>TFC 8 >>>>>ctfc	TF1, TF0) 60 (TF1, TF0, TF0, TF1, TF0) 61	TF0) 30 (TF1, TF0, TF1, TF0) 31
>>>>>ctfc	TF1, TF0) 60 (TF1, TF0, TF0, TF1, TF0) 61 (TF2, TF1, TF0,	TF0) 30 (TF1, TF0, TF1, TF0) 31 (TF2, TF1, TF1,
>>>>>ctfc >>>>>TFC 8 >>>>>ctfc	TF1, TF0) 60 (TF1, TF0, TF0, TF1, TF0) 61	TF0) 30 (TF1, TF0, TF1, TF0) 31
>>>>>ctfc >>>>>TFC 8 >>>>>ctfc	TF1, TF0) 60 (TF1, TF0, TF0, TF1, TF0) 61 (TF2, TF1, TF0,	TF0) 30 (TF1, TF0, TF1, TF0) 31 (TF2, TF1, TF1,
>>>>>ctfc >>>>>TFC 8 >>>>>tfc >>>>>ctfc >>>>>ctfc >>>>>ctfc	TF1, TF0) 60 (TF1, TF0, TF0, TF1, TF0) 61 (TF2, TF1, TF0, TF1, TF0, TF1, TF0) 68	TF0) 30 (TF1, TF0, TF1, TF0) 31 (TF2, TF1, TF1, TF0) 37
>>>>>ctfc >>>>>TFC 8 >>>>>ctfc >>>>>TFC 9	TF1, TF0) 60 (TF1, TF0, TF0, TF1, TF0) 61 (TF2, TF1, TF0, TF1, TF0, TF1, TF0) 68 (TF3, TF2, TF0,	TF0) 30 (TF1, TF0, TF1, TF0) 31 (TF2, TF1, TF1, TF0) 37 (TF3, TF2, TF1,
>>>>>ctfc >>>>>TFC 8 >>>>>TFC 9 >>>>>tfc >>>>>TFC 10	TF1, TF0) 60 (TF1, TF0, TF0, TF1, TF0) 61 (TF2, TF1, TF0, TF1, TF0, TF1, TF0) 68 (TF3, TF2, TF0, TF1, TF0, TF1, TF0)	TF0) 30 (TF1, TF0, TF1, TF0) 31 (TF2, TF1, TF1, TF0) 37 (TF3, TF2, TF1, TF0)
>>>>>ctfc >>>>>TFC 8 >>>>>TFC 9 >>>>>TFC 10 >>>>>>tfc	TF1, TF0) 60 (TF1, TF0, TF0, TF1, TF0) 61 (TF2, TF1, TF0, TF1, TF0) 68 (TF3, TF2, TF0, TF1, TF0) 75	TF0) 30 (TF1, TF0, TF1, TF0) 31 (TF2, TF1, TF1, TF0) 37 (TF3, TF2, TF1, TF0) 55
>>>>>ctfc >>>>>TFC 8 >>>>>TFC 9 >>>>>tfc >>>>>TFC 10	TF1, TF0) 60 (TF1, TF0, TF0, TF1, TF0) 61 (TF2, TF1, TF0, TF1, TF0, TF1, TF0) 68 (TF3, TF2, TF0, TF1, TF0, TF1, TF0) 75 (TF4, TF3, TF0,	TF0) 30 (TF1, TF0, TF1, TF0) 31 (TF2, TF1, TF1, TF0) 37 (TF3, TF2, TF1, TF0) 55 (TF4, TF3, TF1,
>>>>>ctfc >>>>>TFC 8 >>>>>TFC 9 >>>>>TFC 10 >>>>>>tfc	TF1, TF0) 60 (TF1, TF0, TF0, TF1, TF0) 61 (TF2, TF1, TF0, TF1, TF0) 68 (TF3, TF2, TF0, TF1, TF0) 75	TF0) 30 (TF1, TF0, TF1, TF0) 31 (TF2, TF1, TF1, TF0) 37 (TF3, TF2, TF1, TF0) 55
>>>>>ctfc >>>>>TFC 8 >>>>>TFC 9 >>>>>tfc >>>>>TFC 9	TF1, TF0) 60 (TF1, TF0, TF0, TF1, TF0) 61 (TF2, TF1, TF0, TF1, TF0, TF1, TF0) 68 (TF3, TF2, TF0, TF1, TF0, TF1, TF0) 75 (TF4, TF3, TF0,	TF0) 30 (TF1, TF0, TF1, TF0) 31 (TF2, TF1, TF1, TF0) 37 (TF3, TF2, TF1, TF0) 55 (TF4, TF3, TF1,
>>>>>ctfc >>>>>TFC 8 >>>>>ctfc >>>>>>tfc >>>>>TFC 9 >>>>>tfc >>>>>tfc >>>>>TFC 10 >>>>>TFC 11 >>>>>>tfc	TF1, TF0) 60 (TF1, TF0, TF0, TF1, TF0) 61 (TF2, TF1, TF0) 68 (TF3, TF2, TF0, TF1, TF0) 75 (TF4, TF3, TF0, TF1, TF0) 82	TF0) 30 (TF1, TF0, TF1, TF0) 31 (TF2, TF1, TF1, TF0) 37 (TF3, TF2, TF1, TF0) 55 (TF4, TF3, TF1, TF0) 52
>>>>>ctfc >>>>>TFC 8 >>>>>TFC 9 >>>>>tfc >>>>>tfc >>>>>TFC 9	TF1, TF0) 60 (TF1, TF0, TF0, TF0, TF1, TF0) 61 (TF2, TF1, TF0, TF1, TF0, TF1, TF0) 68 (TF3, TF2, TF0, TF1, TF0) 75 (TF4, TF3, TF0, TF1, TF0) 82 (TF5, TF4, TF1,	TF0) 30 (TF1, TF0, TF1, TF0) 31 (TF2, TF1, TF1, TF0) 37 (TF3, TF2, TF1, TF0) 55 (TF4, TF3, TF1, TF0) 52 (TF5, TF4, TF1,
>>>>>ctfc >>>>>TFC 8 >>>>>ctfc >>>>>>TFC 9 >>>>>TFC 10 >>>>>TFC 11 >>>>>>TFC 11	TF1, TF0) 60 (TF1, TF0, TF0, TF1, TF0) 61 (TF2, TF1, TF0) 68 (TF3, TF2, TF0, TF1, TF0) 75 (TF4, TF3, TF0, TF1, TF0) 82	TF0) 30 (TF1, TF0, TF1, TF0) 31 (TF2, TF1, TF1, TF0) 37 (TF3, TF2, TF1, TF0) 55 (TF4, TF3, TF1, TF0) 52

>>>>TFC 13	(TF0, TF0, TF0,	(TF0, TF0, TF0,
	TF0, TF1)	TF1)
>>>>>ctfc	120	60
>>>>TFC 14	(TF1, TF0, TF0,	(TF1, TF0, TF0,
	TF0, TF1)	TF1)
>>>>>ctfc	121	61
>>>>TFC 15	(TF2, TF1, TF0,	(TF2, TF1, TF0,
	TF0, TF1)	TF1)
>>>>>ctfc	128	68
>>>>TFC 16	(TF3, TF2, TF0,	(TF3, TF2, TF0,
	TF0, TF1)	TF1) 75
>>>>>ctfc	135	
>>>>> IFC 17	(TF4, TF3, TF0, TF0, TF1)	(TF4, TF3, TF0, TF1)
>>>>>ctfc	152	82
>>>>>TFC 18	(TF5, TF4, TF1,	(TF5, TF4, TF0,
<i>>>>></i> 11 C 10	TF0, TF1)	TF1)
>>>>>ctfc	189	89
>>>>TFC 19	(TF0, TF0, TF0,	(TF0, TF0, TF1,
	TF1, TF1)	TF1)
>>>>>ctfc	180	90
>>>>>TFC 20	(TF1, TF0, TF0,	(TF1, TF0, TF1,
	TF1, TF1)	TF1)
>>>>>ctfc	181	91
>>>>TFC 21	(TF2, TF1, TF0,	(TF2, TF1, TF1,
	TF1, TF1)	TF1)
>>>>>ctfc	188	98
>>>>TFC 22	(TF3, TF2, TF0,	(TF3, TF2, TF1,
	TF1, TF1)	TF1)
>>>>>ctfc	195	105
>>>>TFC 23	(TF4, TF3, TF0,	(TF4, TF3, TF1,
	TF1, TF1)	TF1)
>>>>>ctfc	239	112
>>>>TFC 24	(TF5, TF4, TF1,	(TF5, TF4, TF1,
	TF1, TF1)	TF1)
>>>>>ctfc	218	119
PhyCH INFORMATION		
FDD		
UL-DPCH-InfoPredef		
>ul-DPCH-		
PowerControlInfo	Algorithm 1	Algorithm 1
>>powerControlAlgorithm	Algorithm 1	+ · ·
>>>tpcStepSize	TRUE	TRUE
>tfci-Existence		
>puncturingLimit	0.88	0.88
DL- CommonInformationPredef		
>dl-DPCH-InfoCommon		
>>spreadingFactor	128	128
>>tfci-Existence	FALSE	FALSE
>>tici-Existence >>pilotBits	4	4
>>pilotbits >>positionFixed	Fixed	Fixed
positioni ixeu	INGU	i indu
PhyCH INFORMATION		
3.84 Mcps TDD		
UL-DPCH-InfoPredef		
>ul-DPCH-		
PowerControlInfo		
>>dpch-ConstantValue	0	0
>commonTimeslotInfo	-	-
>>secondInterleavingMode	frameRelated	frameRelated
>>tfci-Coding	16	16
	1 0.60	1 0.00
>>puncturingLimit >>repetitionPeriodAndLeng	0.60 repetitionPeriod1	0.60 repetitionPeriod1

T		•
DL-		
CommonInformationPredef		
>dl-DPCH-InfoCommon		
>>commonTimeslotInfo		
>>>secondInterleavingMod	frameRelated	frameRelated
е		
>>>tfci-Coding	16	16
>>>puncturingLimit	0.60	0.60
>>>repetitionPeriodAndLe	repetitionPeriod1	repetitionPeriod1
ngth		
PhyCH INFORMATION		
1.28 Mcps TDD		
UL-DPCH-InfoPredef		
>commonTimeslotInfo		
>>secondInterleavingMode	frame Related	frame Related
>>tfci-Coding	16	16
>>puncturingLimit	0.64	0.64
>>repetitionPeriodAndLeng	repetitionPeriod1	repetitionPeriod1
th		
DL-		
CommonInformationPredef		
>dl-DPCH-InfoCommon		
>>commonTimeslotInfo		
>>>secondInterleavingMod	frame Related	frame Related
е		
>>>tfci-Coding	16	16
>>>puncturingLimit	0.64	0.64
>>>repetitionPeriodAndLe	repetitionPeriod1	repetitionPeriod1
ngth		

Configuration	12.65/8.85/6.6 kbps
Johngaration	speech +
	3.4 kbps signalling
Ref 34.108	62
Default configuration	13
identity	13
RB INFORMATION	
rb-Identity	RB1: 1, RB2: 2,
	RB3: 3, RB5: 5,
	RB6: 6, RB8: 8
rlc-InfoChoice	RIc-info
>ul-RLC-Mode	RB1: UM
	RB2- RB3: AM
transmissismPLC	RB5-RB6: TM RB1: N/A
>>transmissionRLC- DiscardMode	RB1: N/A RB2- RB3:
Discardiviode	NoDiscard
	RB5- RB6: N/A
>>>maxDat	RB1: N/A
	RB2- RB3: 15
	RB5- RB6: N/A
>>transmissionWindowSiz	RB1: N/A
е	RB2- RB3: 128 for
	UEs with more than 10 kbyte "total RLC
	AM buffer size" and
	32 otherwise
	RB5- RB6: N/A
>>timerRST	RB1: N/A
	RB2- RB3: 300
	RB5- RB6: N/A
>>max-RST	RB1: N/A
	RB2- RB3: 1
>>pollingInfo	RB5- RB6: N/A RB1: N/A
>>poliliigiiilo	RB2- RB3: as below
	RB5- RB6: N/A
>>>lastTransmissionPDU-	RB2- RB3: FALSE
Poll	
>>>lastRetransmissionPD U-Poll	RB2- RB3: FALSE
>>>timerPollPeriodic	RB2- RB3: 300
>>segmentationIndication	RB1- RB3: N/A
# BL 0.11	RB5- RB6: FALSE
>dl-RLC-Mode	RB1: UM RB2- RB3: AM
	RB5- RB6: TM
	RB8: TM
>>inSequenceDelivery	RB1: N/A
	RB2- RB3: TRUE
	RB5- RB6: N/A
	RB8: N/A
>>receivingWindowSize	RB1: N/A
	RB2- RB3: 128 for
	UEs with more than 10 kbyte "total RLC
	AM buffer size" and
	32 otherwise
	RB5- RB6: N/A
	RB8: N/A
>>dl-RLC-StatusInfo	RB1: N/A
	RB2- RB3: as below
	RB5- RB6: N/A RB8: N/A
>>>timerStatusProhibit	RB2- RB3: 100
>>>missingPDU-Indicator	RB2- RB3: FALSE
	o / (LOL

>>segmentationIndication	time a "Ctatua Da via dia	DD0 DD0, 200
rb-MappingInfo >UL- LogicalChannelMappings >>ul- TransportChannelType >>>transportChannelIdentit y >>logicalChannelIdentity >>rlc-SizeList >>nac- LogicalChannelPriority RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A >>rlc-SizeList RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A >>mac- LogicalChannelPriority RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A >>mac- LogicalChannelMappingList >>Mapping option 1 >>>dl- IogicalChannelMappingList >>Mapping option 1 >>>dl- TransportChannelType >>>>transportChannelIdentity RB1: 1, RB2: 2, RB3: 3 RB5- RB6: 5 >DL- logicalChannelMappingList >>Mapping option 1 Dch TransportChannelType >>>>lransportChannelIdentity RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A RB6: N/A RB7: 1, RB6: 2, RB8: 5 >>>logicalChannelIdentity RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A RB6: N/A RB7: 1, RB6: 2, RB8: 5 >>>logicalChannelIdentity TrCH INFORMATION PER TrCH UL- AddReconfTransChInfoList >Uplink transport channel type >transportChannelIdentity TrCH1: 1, TrCH2: 2, TrCH4: 4 >transportFormatSet DedicatedTransChT FS >>dynamicTF-information >>>trCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144) >>>>rlcSize BitMode >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>>loricH2: (1x 78) TrCH4: N/A >>>>numberOfTbSizeList TrCH1: 0ne ocks TrCH1: 1: 40 TrCH2: 1: 78 TrCH1: 2: One >>>>sizeType TrCH1: 1: 40 TrCH2: 1: 78 TrCH1: 1: 78 TrCH1: One ocks TrCH1: 1: 78	>>>timerStatusPeriodic	RB2- RB3: 300
rb-MappingInfo >UL- LogicalChannelMappings >>ul- TransportChannelType >>>transportChannelIdentity y >>rlc-SizeList RB1- RB3: 4 RB5- RB6: N/A >>rlc-SizeList RB1- RB3: configured RB5- RB6: N/A >>mac- LogicalChannelMappingList >>DL- logicalChannelMappingList >>Mapping option 1 >>>dl- TransportChannelIdentity RB1- RB3: 4 RB5- RB6: N/A >>mac- LogicalChannelMappingList >>Mapping option 1 Dch TransportChannelType >>>>transportChannelIden tity RB1- RB3: 4 RB5- RB6: 5 >>logicalChannelMappingList >>Mapping option 1 ChannelType RB1- RB3: 4 RB5: 1, RB6: 2, RB8: 5 >>>logicalChannelIdentity RB1- RB3: 4 RB5: 1, RB6: 2, RB8: 5 >>>logicalChannelIdentity RB1- RB3: 4 RB5: 1, RB6: 2, RB8: 5 >>>logicalChannelIdentity RB1- RB3: 4 RB5: 1, RB6: 2, RB8: 5 >>>logicalChannelIdentity RB1- RB3: 4 RB5: 1, RB6: 2, RB8: 5 >>>logicalChannelIdentity RB1- RB3: 4 RB5: 1, RB6: 2, RB8: 5 >>>logicalChannelIdentity RB1- RB3: 4 RB5: 1, RB6: 2, RB8: 5 >>>logicalChannelIdentity RB1- RB3: 4 RB5: 1, RB6: 2, RB8: 5 >>>logicalChannelIdentity RB1- RB3: 4 RB5: 1, RB6: 2, RB8: 5 >>>logicalChannelIdentity RB1- RB3: 4 RB5- RB6: N/A RB6: N/A RB6: N/A RB7- RB6: N/A RB8: N/A TrCH INFORMATION PER TrCH UL- AddReconfTransChInfoList >Uplink transport channel type >transportFormatSet DedicatedTransChT FS >>dynamicTF-information >>>trCH1: 1, TrCH2: 2, TrCH4: (0x 181) TrCH4: (0x 144, 1x 144) >>>>rlc-Size BitMode >>>>logicalChannelList TrCH1: (1x40) TrCH2: (1x 78) TrCH2: (1x 78) TrCH2: (1x 78) TrCH4: N/A >>>>numberOfTbSizeList TrCH1: 1: 40 TrCH2: One >>>>sizeType TrCH1: 1: 78	>>segmentationIndication	RB1- RB3: N/A
Trick Tric		RB5- RB6: FALSE
Trick Tric		RB8: FALSE
SUL- LogicalChannelMappings South TransportChannelType South TransportChannelType South TransportChannelIdentity South TransportChannelIdentity South TransportChannelIdentity South TransportChannelIdentity South TransportChannelIdentity South TransportChannelIdentity South TransportChannelPriority South TransportChannelPriority South TransportChannelIdentity South Tr	rh-ManningInfo	
LogicalChannelMappings >>ul- TransportChannelType >>stransportChannelIdentity y >>logicalChannelIdentity RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A >>rlc-SizeList RB1- RB3: configured RB5- RB6: N/A >>mac- LogicalChannelPriority RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A >>mac- LogicalChannelPriority RB1: 1, RB2: 2, RB3: 3 RB5- RB6: 5 >DL- logicalChannelMappingList >>Mapping option 1 >>>dl- TransportChannelType >>>transportChannelIden tity RB1: 1, RB2: 2, RB3: 3 RB5- RB6: 5 >>>logicalChannelIdentity RB1: 1, RB2: 2, RB3: 3 RB5- RB6: 5 >>>logicalChannelIdentity RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A RB8: 1, RB6: 2, RB8: 5 RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A RB8: N/A TrCH INFORMATION PER TrCH UL- AddReconfTransChInfoList >Uplink transport channel dch type >transportChannelIdentity TrCH1: 1, TrCH2: 2, TrCH4: 4 >transportFormatSet DedicatedTransChT FS >>dynamicTF-information >>>trCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144) >>>>rlcSize BitMode >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>>logicalChannelList All >>>sologicalChannelList All >>>sologicalChannelList TrCH1: (1x40) TrCH2: (1x 78) TrCH2: One >>>>sizeType TrCH1: 1-2: BitMode >>>>sologicalChannelList TrCH1: 1: 78 TrCH1: 1: 70ne		Onel odicalChannel
>>ul- TransportChannelType		Offecogleaterialities
TransportChannelType >>>transportChannelIdentit y		
>>>transportChannelIdentit y RB1- RB3: 4 RB5: 1, RB6: 2. >>logicalChannelIdentity RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A >>rlc-SizeList RB1- RB3: configured RB5- RB6: N/A >>mac- RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A >>DL- logicalChannelPriority RB3: 3 RB5- RB6: 5 >DL- logicalChannelIMappingList S-Mapping option 1 Dch Dch Dch Dch TransportChannelIden tity RB1: 1, RB2: 2, RB3: 3 RB5- RB6: 5 >>>logicalChannelIden RB1- RB3: 4 RB5: 1, RB6: 2, RB8: 5 >>>logicalChannelIdentity RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A RB8: N/A TrCH INFORMATION PER TrCH UL- AddReconfTransChInfoList S-Uplink transport channel type >transportChannelIdentity TrCH1: 1, TrCH2: 2, TrCH4: 4 DedicatedTransChT FS >>dynamicTF-information S->tf0/ tf0,1 TrCH2: (0x 181) TrCH4: (0x144, 1x144) TrCH4: (2x144, 1x144) TrCH4: 2: type 1: 181 TrCH4: 2: type 2, part1 = 2, part2 = 0 (144) TrCH4: Zero, one S->>logicalChannelList All TrCH2: DirCH2: Cone S->>>logicalChannelList All TrCH2: DirCH2: Cone S->>>sizeType TrCH1: 1, TrCH1: (1x40) TrCH2: Cone S->>>sizeType TrCH1: 12 BitMode TrCH2: Cone S->>>sizeType TrCH1: 12 Cone S	1	Dch
Section		
>>logicalChannelIdentity RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A >>rlc-SizeList RB1- RB3: configured RB5- RB6: N/A >>mac-LogicalChannelPriority RB1: 1, RB2: 2, RB3: 3 RB5- RB6: 5 >DL-logicalChannelMappingList RB1: 1, RB2: 2, RB3: 3 RB5- RB6: 5 >>Mapping option 1 One mapping option Dch >>>al-TransportChannelType RB1- RB3: 4 RB5: 1, RB6: 2, RB8: 5 >>>logicalChannelIdentity RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A RB8: N/A TrCH INFORMATION PER TrCH TrCH INFORMATION PER TrCH UL-AddReconfTransChInfoList JedicatedTransChT FS >Uplink transport channel dentity TrCH1: 1, TrCH2: 2, TrCH4: 4 >transportFormatSet DedicatedTransChT FS >>dynamicTF-information TrCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144) >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>>numberOfTbSizeList TrCH1: (1x40) TrCH2: (1x 78) TrCH4: N/A >>>>numberOfTransportBl ocks TrCH1: One TrCH2: Die Mode >>>>sizeType TrCH1: One TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1-2: BitMode >>>>sizeType TrCH1: 1: 40 TrCH1: 1: 40 TrCH1: 1: 78 TrCH2: 1: 78	>>>transportChannelIdentit	RB1- RB3: 4
>>logicalChannelIdentity RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A >>rlc-SizeList RB1- RB3: configured RB5- RB6: N/A >>mac-LogicalChannelPriority RB1: 1, RB2: 2, RB3: 3 RB5- RB6: 5 >DL-logicalChannelMappingList RB1: 1, RB2: 2, RB3: 3 RB5- RB6: 5 >>Mapping option 1 One mapping option Dch >>>al-TransportChannelType RB1- RB3: 4 RB5: 1, RB6: 2, RB8: 5 >>>logicalChannelIdentity RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A RB8: N/A TrCH INFORMATION PER TrCH TrCH INFORMATION PER TrCH UL-AddReconfTransChInfoList JedicatedTransChT FS >Uplink transport channel dentity TrCH1: 1, TrCH2: 2, TrCH4: 4 >transportFormatSet DedicatedTransChT FS >>dynamicTF-information TrCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144) >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>>numberOfTbSizeList TrCH1: (1x40) TrCH2: (1x 78) TrCH4: N/A >>>>numberOfTransportBl ocks TrCH1: One TrCH2: Die Mode >>>>sizeType TrCH1: One TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1-2: BitMode >>>>sizeType TrCH1: 1: 40 TrCH1: 1: 40 TrCH1: 1: 78 TrCH2: 1: 78	l v	RB5: 1, RB6: 2.
RB3: 3 RB5- RB6: N/A		
RB5- RB6: N/A	Friegram Griannian actions	
>>rlc-SizeList RB1- RB3: configured RB5- RB6: N/A >>mac- LogicalChannelPriority RB1: 1, RB2: 2, RB3: 3 RB5- RB6: 5 >DL- logicalChannelMappingList >>Mapping option 1 >>>dl- TransportChannelType >>>stransportChannelIden tity RB1- RB3: 4 RB5: 1, RB6: 2, RB3: 5 >>>logicalChannelIdentity RB1- RB3: 4 RB5: 1, RB6: 2, RB3: 3 RB5- RB6: N/A RB8: N/A TrCH INFORMATION PER TrCH UL- AddReconfTransChInfoList >Uplink transport channel type >transportChannelIdentity TrCH1: 1, TrCH2: 2, TrCH4: 4 >transportFormatSet DedicatedTransChT FS >>dynamicTF-information >>>tf0/ tf0,1 TrCH1: (0x72) TrCH2: (0x 181) TrCH2: (0x 184) TrCH2: type 1: 181 TrCH2: type 1: 72 TrCH2: type 1: 181 TrCH2: 2, part1= 2, part2= 0 (144) >>>>numberOfTbSizeList TrCH1: (1x40) TrCH2: (1x 78) TrCH2: One >>>>sizeType TrCH1: 1: 40 TrCH2: 1: 78 TrCH1: 1: 40 TrCH2: 1: 78 TrCH1: 1: 40 TrCH2: 1: 78 TrCH1-2: BitMode TrCH1: 1: 40 TrCH2: 1: 78 TrCH1-2: One		
configured RB5- RB6: N/A >>mac- LogicalChannelPriority RB1: 1, RB2: 2, RB3: 3	Cinal int	
RB5- RB6: N/A	>>ric-SizeList	
>>mac- LogicalChannelPriority RB1: 1, RB2: 2, RB3: 3 RB5- RB6: 5 >DL- logicalChannelMappingList >>Mapping option 1 >>>d- TransportChannelType >>>>transportChannelIden tity RB1: 1, RB2: 4 RB5: 1, RB6: 2, RB8: 5 >>>logicalChannelIdentity RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A RB8: N/A TrCH INFORMATION PER TrCH UL- AddReconfTransChInfoList >Uplink transport channel type >transportChannelIdentity TrCH1: 1, TrCH2: 2, TrCH4: 4 >transportFormatSet DedicatedTransChT FS >>dynamicTF-information >>>tf0/ tf0,1 TrCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144) >>>>rlcSize BitMode >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>>tf 1 TrCH1: (1x40) TrCH2: (1x 78) TrCH2: (1x 78) TrCH2: One >>>>sizeType TrCH1: 1: 40 TrCH2: DistMode >>>>sizeType TrCH1: 1: 40 TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1: 1: 40 TrCH2: 1: 78		
LogicalChannelPriority RB3: 3 RB5- RB6: 5		
RB5- RB6: 5		RB1: 1, RB2: 2,
RB5- RB6: 5	LogicalChannelPriority	
Sold- Internation Sold-		RB5- RB6: 5
logicalChannelMappingList	>DI -	
>>Mapping option 1 >>>dl- TransportChannelType >>>>transportChannelIden tity RB1- RB3: 4 RB5: 1, RB6: 2, RB8: 5 >>>logicalChannelIdentity RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A RB8: N/A TrCH INFORMATION PER TrCH UL- AddReconfTransChInfoList >Uplink transport channel type >transportChannelIdentity TrCH1: 1, TrCH2: 2, TrCH4: 4 >transportFormatSet DedicatedTransChT FS >>dynamicTF-information >>>tf0/ tf0,1 TrCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144) >>>>rlcSize BitMode >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>>numberOfTbSizeList TrCH1: (1x40) TrCH2: (1x 78) TrCH4: N/A TrCH1: One TrCH2: 1: 40 TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1: 1: 78 TrCH1: 1: 78		
>>>dl- TransportChannelType >>>>transportChannelIden tity RB1- RB3: 4 RB5: 1, RB6: 2, RB8: 5 >>>logicalChannelIdentity RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A RB8: N/A TrCH INFORMATION PER TrCH UL- AddReconfTransChInfoList >Uplink transport channel type >transportChannelIdentity TrCH1: 1, TrCH2: 2, TrCH4: 4 >transportFormatSet DedicatedTransChT FS >>dynamicTF-information >>>tf0/ tf0,1 TrCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144) >>>>rlcSize BitMode >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>>logicalChannelList All >>>tf 1 TrCH1: (1x40) TrCH2: (1x 78) TrCH4: N/A TrCH1: One TrCH2: One >>>>sizeType TrCH1: 1: 40 TrCH2: 1: 78 TrCH1: 1: 40 TrCH2: 1: 78 TrCH1: 1: 78 TrCH1: 1: 78 TrCH1: 1: 78		One manning entire
TransportChannelType >>>>transportChannelIden tity RB1- RB3: 4 RB5: 1, RB6: 2, RB8: 5 >>>logicalChannelIdentity RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A RB8: N/A TrCH INFORMATION PER TrCH UL- AddReconfTransChInfoList >Uplink transport channel type >transportChannelIdentity TrCH1: 1, TrCH2: 2, TrCH4: 4 >transportFormatSet DedicatedTransChT FS >>dynamicTF-information >>>tf0/ tf0,1 TrCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144) >>>>rlcSize BitMode >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>>logicalChannelList TrCH1: (1x40) TrCH2: (1x 78) TrCH4: N/A TrCH1: One TrCH2: Dne TrCH1: 1: 40 TrCH2: 1: 78 >>>>logicalType TrCH1: 1: 40 TrCH2: 1: 78 TrCH1: 1: 40 TrCH2: 1: 78 TrCH1: 1: 78		
>>>>transportChannelIden tity RB1- RB3: 4 RB5: 1, RB6: 2, RB8: 5 >>>logicalChannelIdentity RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A RB8: N/A TrCH INFORMATION PER TrCH UL- AddReconfTransChInfoList >Uplink transport channel type >transportChannelIdentity TrCH1: 1, TrCH2: 2, TrCH4: 4 >transportFormatSet DedicatedTransChT FS >>dynamicTF-information >>>tf0/ tf0,1 TrCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144) >>>>rlcSize BitMode >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>>logicalChannelList All >>>tf 1 TrCH1: (1x40) TrCH2: (1x 78) TrCH4: N/A >>>>numberOfTransportBl ocks TrCH1: One ocks TrCH1: 1: 40 TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1: 2: BitMode		DCN
>>>>transportChannelIden tity RB1- RB3: 4 RB5: 1, RB6: 2, RB8: 5 >>>logicalChannelIdentity RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A RB8: N/A TrCH INFORMATION PER TrCH UL- AddReconfTransChInfoList >Uplink transport channel type >transportChannelIdentity TrCH1: 1, TrCH2: 2, TrCH4: 4 >transportFormatSet DedicatedTransChT FS >>dynamicTF-information >>>tf0/ tf0,1 TrCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144) >>>>rlcSize BitMode >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>>logicalChannelList All >>>tf 1 TrCH1: (1x40) TrCH2: (1x 78) TrCH4: N/A >>>>numberOfTransportBl ocks TrCH1: One ocks TrCH1: 1: 40 TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1: 2: BitMode		
RB8: 5 >>>logicalChannelIdentity RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A RB8: N/A TrCH INFORMATION PER TrCH UL- AddReconfTransChInfoList >Uplink transport channel type >transportChannelIdentity TrCH1: 1, TrCH2: 2, TrCH4: 4 >transportFormatSet DedicatedTransChT FS >>dynamicTF-information >>>tf0/ tf0,1 TrCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144) >>>>rlcSize BitMode >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1 = 2, part2 = 0 (144) >>>>logicalChannelList All >>>t1 TrCH1: (1x40) TrCH2: (1x 78) TrCH4: N/A >>>>numberOfTransportBl ocks TrCH1: BitMode >>>>sizeType TrCH1: 1: 40 TrCH2: 1: 78 >>>>logicalChanelChanelList TrCH1: 1: 40 TrCH2: 1: 78 >>>>sizeType TrCH1: 1: 40 TrCH2: 1: 78 TrCH1: 1: 40 TrCH2: 1: 78 TrCH1: 1: 40 TrCH2: 1: 78 TrCH1-2: One		
RB8: 5 >>>logicalChannelIdentity RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A RB8: N/A TrCH INFORMATION PER TrCH UL- AddReconfTransChInfoList >Uplink transport channel type >transportChannelIdentity TrCH1: 1, TrCH2: 2, TrCH4: 4 >transportFormatSet DedicatedTransChT FS >>dynamicTF-information >>>tf0/ tf0,1 TrCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144) >>>>rlcSize BitMode >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1 = 2, part2 = 0 (144) >>>>logicalChannelList All >>>t1 TrCH1: (1x40) TrCH2: (1x 78) TrCH4: N/A >>>>numberOfTransportBl ocks TrCH1: BitMode >>>>sizeType TrCH1: 1: 40 TrCH2: 1: 78 >>>>logicalChanelChanelList TrCH1: 1: 40 TrCH2: 1: 78 >>>>sizeType TrCH1: 1: 40 TrCH2: 1: 78 TrCH1: 1: 40 TrCH2: 1: 78 TrCH1: 1: 40 TrCH2: 1: 78 TrCH1-2: One	•	
>>>logicalChannelIdentity RB1: 1, RB2: 2, RB3: 3 RB5- RB6: N/A RB8: N/A TrCH INFORMATION PER TrCH UL- AddReconfTransChInfoList >Uplink transport channel type >transportChannelIdentity TrCH1: 1, TrCH2: 2, TrCH4: 4 >transportFormatSet DedicatedTransChT FS >>dynamicTF-information >>>tf0/ tf0,1 TrCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144) >>>>rlcSize BitMode >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>>numberOfTbSizeList TrCH1: (1x40) TrCH2: (1x 78) TrCH4: N/A >>>>numberOfTransportBl ocks TrCH1: 0ne TrCH2: One >>>>sizeType TrCH1: 1: 40 TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1: 2: One		
RB3: 3 RB5- RB6: N/A RB8: N/A TrCH INFORMATION PER TrCH UL- AddReconfTransChInfoList >Uplink transport channel type >transportChannelIdentity TrCH1: 1, TrCH2: 2, TrCH4: 4 >transportFormatSet DedicatedTransChT FS >>dynamicTF-information >>>tf0/ tf0,1 TrCH2: (0x 181) TrCH4: (0x144, 1x144) >>>>rlcSize BitMode >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>numberOfTbSizeList TrCH1: (1x40) TrCH2: (1x 78) TrCH4: N/A >>>>numberOfTransportBl ocks TrCH1-2: BitMode >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>>logicalChannelList All >>>tf TrCH1: (1x40) TrCH2: (1x 78) TrCH4: N/A TrCH2: One TrCH2: One TrCH2: One TrCH2: One TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1-2: DitMode	>>>IndicalChannelIdentity	
RB5- RB6: N/A RB8: N/A TrCH INFORMATION PER TrCH UL- AddReconfTransChInfoList >Uplink transport channel type >transportChannelIdentity TrCH1: 1, TrCH2: 2, TrCH4: 4 >transportFormatSet DedicatedTransChT FS >>dynamicTF-information >>>tf0/ tf0,1 TrCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144) >>>>rlcSize BitMode >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>numberOfTbSizeList TrCH1: (1x40) TrCH2: (1x 78) TrCH4: N/A >>>numberOfTransportBI ocks TrCH1: One TrCH2: One >>>sizeType TrCH1: 1: 40 TrCH2: 1: 78 >>>numberOfTbSizeList TrCH1: 1: 40 TrCH2: 1: 78 >>>numberOfTbSizeList TrCH1: 1: 40 TrCH2: 1: 78 >>>numberOfTbSizeList TrCH1: 1: 40 TrCH2: 1: 78	logical Orial menderitity	
TrCH INFORMATION PER TrCH UL- AddReconfTransChInfoList >Uplink transport channel type >transportChannelIdentity TrCH1: 1, TrCH2: 2, TrCH4: 4 >transportFormatSet DedicatedTransChT FS >>dynamicTF-information >>>tf0/ tf0,1 TrCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144) >>>>rlcSize BitMode >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>>numberOfTbSizeList TrCH1: (1x40) TrCH2: (1x 78) TrCH4: N/A >>>>numberOfTransportBl ocks TrCH1: One TrCH2: One >>>sizeType TrCH1: 1: 40 TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1: 1: 40 TrCH2: 1: 78 >>>numberOfTbSizeList TrCH1: 1: 40 TrCH2: 1: 78 >>>numberOfTbSizeList TrCH1: 1: 40 TrCH2: 1: 78		
TrCH INFORMATION PER TrCH UL- AddReconfTransChInfoList >Uplink transport channel type >transportChannelIdentity TrCH1: 1, TrCH2: 2, TrCH4: 4 >transportFormatSet DedicatedTransChT FS >>dynamicTF-information >>>tf0/ tf0,1 TrCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144) >>>>rlcSize BitMode >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>>numberOfTbSizeList TrCH1: (1x40) TrCH2: (1x 78) TrCH4: N/A >>>>numberOfTransportBl ocks TrCH1: One TrCH2: One >>>>sizeType TrCH1: 1: 40 TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1: 1: 40 TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1: 1: 40 TrCH2: 1: 78 TrCH1: 1: 78		
TrCH UL- AddReconfTransChInfoList >Uplink transport channel type >transportChannelIdentity TrCH1: 1, TrCH2: 2, TrCH4: 4 >transportFormatSet DedicatedTransChT FS >>dynamicTF-information >>>tf0/ tf0,1 TrCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144) >>>>rlcSize BitMode >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>>logicalChannelList TrCH1: (1x40) TrCH2: (1x 78) TrCH2: (1x 78) TrCH4: N/A >>>>numberOfTransportBl ocks TrCH1: One TrCH2: One >>>>sizeType TrCH1: 1: 40 TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1: 1: 40 TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1: 1: 40 TrCH2: 1: 78 TrCH2: One		KRR: N/A
UL- AddReconfTransChInfoList >Uplink transport channel type >transportChannelIdentity TrCH1: 1, TrCH2: 2, TrCH4: 4 >transportFormatSet DedicatedTransChT FS >>dynamicTF-information >>>tf0/ tf0,1 TrCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144) >>>>rlcSize BitMode >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>>logicalChannelList TrCH1: (1x40) TrCH2: (1x 78) TrCH2: (1x 78) TrCH4: N/A >>>>numberOfTransportBl ocks TrCH1: One TrCH2: One >>>>sizeType TrCH1: 1: 40 TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1: 1: 40 TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1: 1: 40 TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1: 1: 40 TrCH2: 1: 78		
AddReconfTransChInfoList		
>Uplink transport channel typedch>transportChannelIdentityTrCH1: 1, TrCH2: 2, TrCH4: 4>transportFormatSetDedicatedTransChT FS>>dynamicTF-informationTrCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144)>>>rlcSizeBitMode>>>ssizeTypeTrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144)>>>numberOfTbSizeListTrCH1: 2: Zero TrCH4: Zero, one>>>logicalChannelListAll>>>tf 1TrCH1: (1x40) TrCH2: (1x 78) TrCH4: N/A>>>numberOfTransportBl ocksTrCH1: One TrCH2: One>>>sizeTypeTrCH1: 1: 40 TrCH2: 1: 78>>>numberOfTbSizeListTrCH1-2: One	UL-	
>Uplink transport channel typedch>transportChannelIdentityTrCH1: 1, TrCH2: 2, TrCH4: 4>transportFormatSetDedicatedTransChT FS>>dynamicTF-informationTrCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144)>>>rlcSizeBitMode>>>ssizeTypeTrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144)>>>numberOfTbSizeListTrCH1: 2: Zero TrCH4: Zero, one>>>logicalChannelListAll>>>tf 1TrCH1: (1x40) TrCH2: (1x 78) TrCH4: N/A>>>numberOfTransportBl ocksTrCH1: One TrCH2: One>>>sizeTypeTrCH1: 1: 40 TrCH2: 1: 78>>>numberOfTbSizeListTrCH1-2: One	AddReconfTransChInfoList	
type		dch
>transportChannelIdentity TrCH1: 1, TrCH2: 2, TrCH4: 4 >transportFormatSet DedicatedTransChT FS >>dynamicTF-information TrCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144) >>>rlcSize BitMode >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>numberOfTbSizeList TrCH1: 2: Zero TrCH4: Zero, one >>>stf 1 TrCH1: (1x40) TrCH2: (1x 78) TrCH4: N/A >>>numberOfTransportBI ocks TrCH1: One TrCH2: One >>>sizeType TrCH1: 1: 40 TrCH2: 1: 78 >>>numberOfTbSizeList TrCH1: 1: 78	I	
TrCH4: 4 >transportFormatSet DedicatedTransChT FS >>dynamicTF-information >>>tf0/ tf0,1 TrCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144) >>>>rlcSize BitMode >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>>numberOfTbSizeList TrCH1: 2: Zero TrCH4: Zero, one >>>stf 1 TrCH1: (1x40) TrCH2: (1x 78) TrCH4: N/A >>>>numberOfTransportBl TrCH1: One TrCH2: One >>>>sizeType TrCH1: 1: 40 TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1: 1: 40 TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1-2: One		TrCH1: 1 TrCH2: 2
>transportFormatSet DedicatedTransChT FS >>dynamicTF-information TrCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144) >>>rlcSize BitMode >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>>numberOfTbSizeList TrCH1-2: Zero TrCH4: Zero, one >>>stf 1 TrCH1: (1x40) TrCH2: (1x 78) TrCH4: N/A >>>>numberOfTransportBI ocks TrCH1: One TrCH2: One >>>>rlc-Size TrCH1: 1: 40 TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1: 1: 78		
FS	transport (C)	
>>dynamicTF-information >>>tf0/tf0,1	>transportFormatSet	
>>>tf0/ tf0,1 TrCH1: (0x72) TrCH2: (0x 181) TrCH4: (0x144, 1x144) >>>>rlcSize BitMode >>>>sizeType TrCH1: type 1: 72 TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>>numberOfTbSizeList TrCH4: Zero, one >>>slogicalChannelList >>>tf 1 TrCH1: (1x40) TrCH2: (1x 78) TrCH4: N/A >>>>numberOfTransportBl ocks TrCH1: One TrCH2: One >>>sizeType TrCH1: 1: 40 TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1: 1: 40 TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1-2: One		FS
TrCH2: (0x 181)	>>dynamicTF-information	
TrCH2: (0x 181)	>>>tf0/ tf0,1	TrCH1: (0x72)
TrCH4: (0x144, 1x144)	1	
1x144)		
>>>rlcSize		
>>>>sizeType	>>>rlcSize	, , , , , , , , , , , , , , , , , , ,
TrCH2: type 1: 181 TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>>numberOfTbSizeList TrCH1-2: Zero TrCH4: Zero, one >>>logicalChannelList All >>>tf 1 TrCH1: (1x40) TrCH2: (1x 78) TrCH4: N/A >>>>numberOfTransportBl ocks TrCH2: One >>>>rlc-Size TrCH1: 1: 40 TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1: 1: 40 TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1-2: One		
TrCH4: 2: type 2, part1= 2, part2= 0 (144) >>>>numberOfTbSizeList	>>>>size i ype	
part1= 2, part2= 0 (144)		
(144)		
>>>numberOfTbSizeList		part1= 2, part2= 0
>>>numberOfTbSizeList		(144)
TrCH4: Zero, one	>>>>numberOfTbSizeList	TrCH1-2: Zero
>>>logicalChannelList All >>>tf 1 TrCH1: (1x40)	- I S I S I S I S I S I S I S I S I S I	
>>>tf 1	>>> ogicalChannoll_ist	·
TrCH2: (1x 78) TrCH4: N/A		
TrCH4: N/A	>>>ti 1	
>>>numberOfTransportBl TrCH1: One ocks TrCH2: One >>>>rlc-Size TrCH1-2: BitMode >>>>sizeType TrCH1: 1: 40 TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1-2: One		
ocks TrCH2: One >>>>rlc-Size TrCH1-2: BitMode >>>>sizeType TrCH1: 1: 40 TrCH2: 1: 78 >>>numberOfTbSizeList TrCH1-2: One		
ocks TrCH2: One >>>>rlc-Size TrCH1-2: BitMode >>>>sizeType TrCH1: 1: 40 TrCH2: 1: 78 >>>>numberOfTbSizeList TrCH1-2: One	>>>>numberOfTransportBl	TrCH1: One
>>>rlc-Size	-	TrCH2: One
>>>>sizeType	>>>rlc-Size	
TrCH2: 1: 78 >>>numberOfTbSizeList TrCH1-2: One		
>>>>numberOfTbSizeList TrCH1-2: One		
>>>>logicalChannelList TrCH1: all		

	r =
>>>tf 2	TrCH1: (1x54)
	TrCH2: (1x113)
	TrCH4: N/A
>>>>numberOfTransportBl	TrCH1: One
ocks	TrCh2: One
>>>rlc-Size	TrCH1: BitMode
>>>>sizeType	TrCH1: type 1: 54
· · · · · · · · · · · · · · · · · · ·	
	TrCH2: type 1: 113
>>>>numberOfTbSizeList	TrCH1: One
	TrCH2: One
logicalChannell ist	TrCH1: all
>>>>logicalChannelList	
	TrCH2: all
>>>tf 3	TrCH1: (1x64)
/// U	T-0110: (1x04)
	TrCH2: (1x181)
	TrCH4: N/A
>>>>numberOfTransportBl	TrCH1: One
ocks	TrCh2: One
>>>>rlc-Size	TrCH1: BitMode
>>>>sizeType	TrCH1: type 1: 64
	TrCH2: type 1: 181
>>>>numberOfTbSizeList	TrCH1: One
IIIIIIDGI OI I DOIZELISI	
	TrCH2: One
>>>>logicalChannelList	TrCH1: all
J. J	TrCH2: all
>>>tf 4	TrCH1: (1x72)
	TrCH2: N/A
	TrCH4: N/A
>>>>numberOfTransportBl	TrCH1: One
ocks	
	= 0.11. 5.11.
>>>rlc-Size	TrCH1: BitMode
>>>>sizeType	TrCH1: type 1: 72
>>>>numberOfTbSizeList	TrCH1: One
1 1 10 11 1	
>>>>logicalChannelList	TrCH1: all
>>>logicalChannelList	TrCH1: all
>>semistaticTF-Information	
	TrCH1: all TrCH1- TrCH2: 20
>>semistaticTF-Information	TrCH1- TrCH2: 20
>>semistaticTF-Information >>>tti	TrCH1- TrCH2: 20 TrCH4: 40
>>semistaticTF-Information >>>tti >>>channelCodingType	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional
>>semistaticTF-Information >>>tti >>>channelCodingType	TrCH1- TrCH2: 20 TrCH4: 40
>>semistaticTF-Information >>>tti	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2:
>>semistaticTF-Information >>>tti >>>channelCodingType	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third
>>semistaticTF-Information >>>tti >>>channelCodingType	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third
>>semistaticTF-Information >>>tti >>channelCodingType >>>codingRate	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third
>>semistaticTF-Information >>>tti >>>channelCodingType	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH1: 200
>>semistaticTF-Information >>>tti >>channelCodingType >>>codingRate	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH1: 200 TrCH2: 190
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH1: 200 TrCH2: 190 TrCH4: 170
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH1: 200 TrCH2: 190 TrCH4: 170
>>semistaticTF-Information >>>tti >>channelCodingType >>>codingRate	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH1: 200 TrCH2: 190 TrCH2: 170 TrCH4: 170 TrCH1: 12
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH1: 200 TrCH2: 190 TrCH2: 170 TrCH1: 12 TrCH1: 12 TrCH2: 0
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH1: 200 TrCH2: 190 TrCH2: 170 TrCH4: 170 TrCH1: 12
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH1: 200 TrCH2: 190 TrCH2: 170 TrCH1: 12 TrCH1: 12 TrCH2: 0
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH1: 200 TrCH2: 190 TrCH2: 170 TrCH1: 12 TrCH1: 12 TrCH2: 0
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH1: 200 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH1: 200 TrCH2: 190 TrCH2: 170 TrCH1: 12 TrCH1: 12 TrCH2: 0
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList >Downlink transport	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH1: 200 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList >Downlink transport channel type	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH1: 200 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList >Downlink transport channel type >dl-	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH1: 200 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList >Downlink transport channel type	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH1: 200 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList >Downlink transport channel type >dl- TransportChannelIdentity	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH1: 200 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList >Downlink transport channel type >dl-	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH1: 200 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList >Downlink transport channel type >dl- TransportChannelIdentity	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH2: 190 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList >Downlink transport channel type >dl- TransportChannelIdentity	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH1: 200 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList >Downlink transport channel type >dl- TransportChannelIdentity	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH2: 190 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList >Downlink transport channel type >dl- TransportChannelIdentity	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH2: 190 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16 Independent <only and="" are="" different<="" on="" td="" tf0="" tf1="" trch1="" trch5=""></only>
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList >Downlink transport channel type >dl- TransportChannelIdentity	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH2: 190 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList >Downlink transport channel type >dl- TransportChannelIdentity >tfs-SignallingMode	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH2: 190 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16 Independent <only and="" are="" different<="" on="" td="" tf0="" tf1="" trch1="" trch5=""></only>
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList >Downlink transport channel type >dl- TransportChannelIdentity >tfs-SignallingMode >>transportFormatSet	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH2: 190 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16 Independent <only and="" are="" different<="" on="" td="" tf0="" tf1="" trch1="" trch5=""></only>
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList >Downlink transport channel type >dl- TransportChannelIdentity >tfs-SignallingMode >>transportFormatSet >>>dynamicTF-information	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH1: 200 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16 dch Independent <only and="" are="" below="" different="" on="" shown="" tf0="" tf1="" trch1="" trch5=""></only>
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList >Downlink transport channel type >dl- TransportChannelIdentity >tfs-SignallingMode >>transportFormatSet	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH1: 200 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16 dch Independent <only and="" are="" below="" different="" on="" shown="" tf0="" tf1="" trch1="" trch5=""></only>
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList >Downlink transport channel type >dl- TransportChannelIdentity >tfs-SignallingMode >>transportFormatSet >>>dynamicTF-information	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH2: 190 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16 dch Independent <only and="" are="" below="" different="" on="" shown="" tf0="" tf1="" trch1="" trch5=""> TrCH1: (1x0)</only>
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList >Downlink transport channel type >dl- TransportChannelIdentity >tfs-SignallingMode >>transportFormatSet >>>dynamicTF-information >>>tf0/ tf0,1	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH2: 190 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16 Independent <only and="" are="" below="" different="" on="" shown="" tf0="" tf1="" trch1="" trch5=""> TrCH1: (1x0) TrCH5: (0x3, 1x3)</only>
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList >Downlink transport channel type >dl- TransportChannelIdentity >tfs-SignallingMode >>transportFormatSet >>>dynamicTF-information	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH2: 190 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16 dch Independent <only and="" are="" below="" different="" on="" shown="" tf0="" tf1="" trch1="" trch5=""> TrCH1: (1x0)</only>
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList >Downlink transport channel type >dl- TransportChannelIdentity >tfs-SignallingMode >>transportFormatSet >>>dynamicTF-information >>>tf0,1 >>>>rlcSize	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH2: 190 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16 Independent <only and="" are="" below="" different="" on="" shown="" tf0="" tf1="" trch1="" trch5=""> TrCH1: (1x0) TrCH5: (0x3, 1x3) BitMode</only>
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList >Downlink transport channel type >dl- TransportChannelIdentity >tfs-SignallingMode >>transportFormatSet >>>dynamicTF-information >>>tf0/ tf0,1	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH2: 190 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16 Independent <only and="" are="" below="" different="" on="" shown="" tf0="" tf1="" trch1="" trch5=""> TrCH1: (1x0) TrCH5: (0x3, 1x3) BitMode TrCH1: type 1: 0</only>
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList >Downlink transport channel type >dl- TransportChannelIdentity >tfs-SignallingMode >>transportFormatSet >>>dynamicTF-information >>>tf0,1 >>>>rlcSize	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH2: 190 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16 Independent <only and="" are="" below="" different="" on="" shown="" tf0="" tf1="" trch1="" trch5=""> TrCH1: (1x0) TrCH5: (0x3, 1x3) BitMode TrCH1: type 1: 0 TrCH5: type 1: 3</only>
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList >Downlink transport channel type >dl- TransportChannelIdentity >tfs-SignallingMode >>transportFormatSet >>>dynamicTF-information >>>tf0,1 >>>>rlcSize	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH2: 190 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16 Independent <only and="" are="" below="" different="" on="" shown="" tf0="" tf1="" trch1="" trch5=""> TrCH1: (1x0) TrCH5: (0x3, 1x3) BitMode TrCH1: type 1: 0 TrCH5: type 1: 3</only>
>>semistaticTF-Information >>>tti >>>channelCodingType >>>codingRate >>>rateMatchingAttribute >>>crc-Size DL- AddReconfTransChInfoList >Downlink transport channel type >dl- TransportChannelIdentity >tfs-SignallingMode >>transportFormatSet >>>dynamicTF-information >>>>tf0/ tf0,1 >>>>rlcSize >>>>sizeType	TrCH1- TrCH2: 20 TrCH4: 40 Convolutional TrCH1- TrCH2: Third TrCH4: Third TrCH2: 190 TrCH2: 190 TrCH4: 170 TrCH1: 12 TrCH2: 0 TrCH4: 16 Independent <only and="" are="" below="" different="" on="" shown="" tf0="" tf1="" trch1="" trch5=""> TrCH1: (1x0) TrCH5: (0x3, 1x3) BitMode TrCH1: type 1: 0</only>

	1 A II
>>>logicalChannelList	All
>>>semistaticTF-	same as UL except
Information	for TrCH5
>>>>tti	TrCH5: 20
>>>>channelCodingType	Convolutional
>>>>codingRate	TrCH5: Third
>>>rateMatchingAttribute	TrCH5: 205
>>>crc-Size	TrCH5: 8
>>ULTrCH-Id	TrCH1: 1, TrCH2: 2,
	TrCH4: 4,
>dch-QualityTarget	
>>bler-QualityValue	TrCH1: 7x10 ⁻³
	TrCH2: Absent
	TrCH4- TrCH5:
	Absent
TrCH INFORMATION,	
COMMON	
ul-CommonTransChInfo	
>tfcs-ID (TDD only)	1
>sharedChannelIndicator	FALSE
(TDD only)	1 ALUL
> tfc-Subset	Aboost not received
	Absent, not required
>ul-TFCS	Normal TFCI
	signalling
>>explicitTFCS-	Complete
ConfigurationMode	
>>>ctfcSize	Ctfc6Bit
>>>>TFCS representation	Addition
>>>>TFC list	
>>>>TFC 1	(TF0, TF0, TF0)
>>>>>ctfc	0
>>>>>gainFactorInform	Computed
ation	
>>>>>>referenceTFCId	0
>>>>TFC 2	(TF1, TF0, TF0)
>>>>>ctfc	1
>>>>>gainFactorInform	Computed
ation	
>>>>>βc (FDD only)	N/A
	N/A
>>>>>βd	N/A
>>>>>>referenceTFCId	0
>>>>TFC 3	(TF2, TF1, TF0)
>>>>>ctfc	7
	Computed
>>>>>gainFactorInform	Computed
>>>>>gainFactorInform ation	
>>>>>gainFactorInform ation >>>>>referenceTFCId	0
>>>>>gainFactorInform ation >>>>>>referenceTFCId >>>>>TFC 4	0 (TF3, TF2, TF0)
>>>>>gainFactorInform ation >>>>>>TFC 4 >>>>>>ctfc	0 (TF3, TF2, TF0) 13
>>>>>gainFactorInform ation >>>>>>referenceTFCId >>>>>TFC 4	0 (TF3, TF2, TF0)
>>>>>gainFactorInform ation >>>>>>TFC 4 >>>>>>ctfc	0 (TF3, TF2, TF0) 13
>>>>>gainFactorInform ation >>>>>referenceTFCId >>>>>TFC 4 >>>>>ctfc >>>>>>gainFactorInform ation	0 (TF3, TF2, TF0) 13
>>>>>gainFactorInform ation >>>>>>referenceTFCId >>>>>TFC 4 >>>>>ctfc >>>>>>gainFactorInform ation >>>>>βc (FDD only)	0 (TF3, TF2, TF0) 13
>>>>>gainFactorInform ation >>>>>>referenceTFCId >>>>>TFC 4 >>>>>ctfc >>>>>painFactorInform ation >>>>>βc (FDD only) >>>>>>βd	0 (TF3, TF2, TF0) 13 Computed
$\label{eq:controller} $$ >>>>> referenceTFCId $$ >>>>> TFC 4 $$ >>>>> ctfc $$ >>>>> gainFactorInform ation $$ >>>>> \betac (FDD only) $$ >>>>> \betad $$ >>>>> referenceTFCId $$ >>>>>> pferenceTFCId $$ >>>>> pferenceTFCId $$ >>>>> pferenceTFCId $$ >>>>> pferenceTFCId $$ >>>>> pferenceTFCId $$ >>>>>> pferenceTFCId $$ >>>>> pferenceTFCId $$ >>>>> pferenceTFCId $$ $$ $$ >>>>>> pferenceTFCId $$ $$ $$ >>>>> pferenceTFCId $$ $$ $$ $$ $$ $$ $$ $$ $$ $$ $$ $$ $$$	0 (TF3, TF2, TF0) 13 Computed
$\label{eq:controller} $$ >>>>> gainFactorInform ation $$ >>>> referenceTFCId $$ >>>>> Ctfc $$ >>>>> gainFactorInform ation $$ >>>>> \betac (FDD only) $$ >>>>> \betad $$ >>>>> referenceTFCId $$ >>>>> TFC 5$ $$ $$ $$$	0 (TF3, TF2, TF0) 13 Computed 0 (TF4, TF3, TF0)
$\label{eq:controller} $$ >>>>> & \text{pain-FactorInform ation} $$ >>>>> & \text{preserved} $$ >>>> & \text{preserved} $$ >>>>> & \text{preserved} $$ >>>> & \text{preserved} $$ >>>> & \text{preserved} $$ >>>> & \text{preserved} $$ >>>>> & \text{preserved} $$ >>>> & \text{preserved} $$ >>>>> & \text{preserved} $$ >>>> & \text{preserved} $$ >>> & \text{preserved} $$ >> & \text{preserved} $$ >>> & \text{preserved} $$ >>> & \text{preserved} $$ >>> & \text{preserved} $$ >>> & \text{preserved} $$ >> & pre$	0 (TF3, TF2, TF0) 13 Computed 0 (TF4, TF3, TF0) 19
$\label{eq:controller} $$ >>>>> gainFactorInform ation $$ >>>> referenceTFCId $$ >>>>> Ctfc $$ >>>>> gainFactorInform ation $$ >>>>> \betac (FDD only) $$ >>>>> \betad $$ >>>>> referenceTFCId $$ >>>>> TFC 5$ $$ $$ $$$	0 (TF3, TF2, TF0) 13 Computed 0 (TF4, TF3, TF0)
$\label{eq:controller} $$ >>>>> painFactorInform ation $$ >>>> referenceTFCId $$ >>>>> Ctfc $$ >>>>> painFactorInform ation $$ >>>>> \betac (FDD only) $$ >>>>> \betad $$ >>>>> referenceTFCId $$ >>>>> TFC 5 $$ >>>>> ctfc $$ >>>>> Ctfc $$ >>>>> Ctfc $$ >>>>> Ctfc $$ >>>>> TFC 5 $$ >>>>> Ctfc $$ $$ >>>>> Ctfc $$ >>>>> Ctfc $$ $$ >>>>> Ctfc $$ $$ >>>>> Ctfc $$ $$ >>>>> Ctfc $$ $$ $$ >>>>> Ctfc $$ $$ $$ $$ $$ $$ $$ $$ $$ $$ $$ $$ $$$	0 (TF3, TF2, TF0) 13 Computed 0 (TF4, TF3, TF0) 19
$\begin{tabular}{lll} >>>>>>gainFactorInform \\ ation \\ >>>>>TFC 4 \\ >>>>>ctfc \\ >>>>>ctfc \\ >>>>>sgainFactorInform \\ ation \\ >>>>>\beta c (FDD only) \\ >>>>>FeferenceTFCId \\ >>>>>TFC 5 \\ >>>>>ctfc \\ >>>>>sgainFactorInform \\ ation \\ >>>>>TFC 5 \\ >>>>>ctfc \\ >>>>>sgainFactorInform \\ ation \\ \end{tabular}$	0 (TF3, TF2, TF0) 13 Computed 0 (TF4, TF3, TF0) 19
$\begin{tabular}{lll} >>>>>>& painFactorInform \\ ation &>>>>> referenceTFCId \\ >>>>>TFC 4 \\ >>>>> ctfc \\ >>>>> gainFactorInform \\ ation &>>>>> \beta c \ (FDD \ only) \\ >>>>> FG \ (FDD \ only) \\ >>>>> TFC 5 \\ >>>>> ctfc \\ >>>>> ctfc \\ >>>>> referenceTFCId \\ >>>>>> referenceTFCId \\ >>>>> referenceTFCId \\ >>>>>> referenceTFCId \\ >>>>> referenceTFCId \\ >>>> referenceTFCId \\ >>>> referenceTFCId \\ >>>> referenceTFCId \\ >>>>> referenceTFCId \\ >>>> referenceTFCId \\ >>> referenceTFCId \\ >>>> referenceTFCId \\ >>>> referenceTFCId \\ >>> referenceTFCId \\ >> referenceTFCId \\ >>> referenceTFCId \\ >>> referenceTFCId \\ >>> referenceTFCId \\ >> referenceTFCId \\ >>> referenceTFCId \\ >> referenceTFCID \\$	0 (TF3, TF2, TF0) 13 Computed 0 (TF4, TF3, TF0) 19 Computed
$\begin{tabular}{lll} >>>>>>& painFactorInform \\ ation &>>>>> referenceTFCId \\ >>>>>TFC 4 \\ >>>>> ctfc \\ >>>>> gainFactorInform \\ ation &>>>>> \betac (FDD only) \\ >>>>>> \betad \\ >>>>> referenceTFCId \\ >>>>> tfC 5 \\ >>>>> ctfc \\ >>>>> referenceTFCId \\ >>>>> referenceTFCId \\ >>>>> referenceTFCId \\ >>>>> TFC 5 \\ >>>>> referenceTFCId \\ >>>>> TFC 6 \\ \end{tabular}$	0 (TF3, TF2, TF0) 13 Computed 0 (TF4, TF3, TF0) 19 Computed 0 (TF0, TF0, TF1)
$\begin{tabular}{lll} >>>>>>&painFactorInform \\ ation &>>>>>referenceTFCId \\ >>>>>TFC 4 \\ >>>>>ctfc \\ >>>>>&painFactorInform \\ ation &>>>>>&\beta c (FDD only) \\ >>>>>>&pd \\ >>>>>&referenceTFCId \\ >>>>>>&referenceTFCId \\ >>>>>>>&referenceTFCId \\ >>>>>>>&referenceTFCId \\ >>>>>>>&referenceTFCId \\ >>>>>>&referenceTFCId \\ >>>>>>>&referenceTFCId \\ >>>>>>>>>>>>>> \\ TFC 6 \\ >>>>>>>>>>>> \\ TFC 6 \\ >>>>>>>>>>> \\ TFC 6 \\ >>>>>>>>>> \\ TFC 6 \\ >>>>>>>> \\ TFC 6 \\ >>>>>>> \\ TFC 6 \\ >>>>>>> \\ TFC 6 \\ >>>>>>> \\ TFC 6 \\ TFC 1 \\ TFC$	0 (TF3, TF2, TF0) 13 Computed 0 (TF4, TF3, TF0) 19 Computed 0 (TF0, TF0, TF1) 20
$\begin{tabular}{lll} >>>>>>&painFactorInform \\ ation &>>>>>referenceTFCId \\ >>>>>TFC 4 &>>>>>ctfc \\ >>>>>&painFactorInform \\ ation &>>>>>&pc (FDD only) \\ >>>>>>&pd & painFactorInform \\ >>>>>&pd & painFactorInform \\ >>>>>&pd & painFactorInform \\ >>>>>&pd & painFactorInform \\ >>>>>&painFactorInform \\ ation &>>>>>&painFactorInform \\ ation &>>>>>&painFactorInform \\ >>>>>&painFactorInform \\ >>>>>&painFactorInform \\ >>>>>&painFactorInform \\ >>>>>>&painFactorInform \\ >>>>>&painFactorInform \\ >>>>>>&painFactorInform \\ >>>>>>>&painFactorInform \\ >>>>>>>>>>>>&painFactorInform \\ >>>>>>>>>>>>>>>>&painFactorInform \\ >>>>>>>>>>>>>>>>>>>>>>>&painFactorInform \\ >>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>$	0 (TF3, TF2, TF0) 13 Computed 0 (TF4, TF3, TF0) 19 Computed 0 (TF0, TF0, TF1)
$\begin{tabular}{lll} >>>>>>& painFactorInform ation \\ >>>>>TFC 4 \\ >>>>> ctfc \\ >>>>>& painFactorInform ation \\ >>>>>& (FDD only) \\ >>>>>& pd \\ >>>>>& pd \\ >>>>>& tfc \\ >>>>>& painFactorInform ation \\ >>>>>& pd \\ >>>>>& pd \\ >>>>& pd \\ >>>>>& pd \\ >>>>& pd \\ >>>>>& pd \\ >>>>& pd \\ >>>>>& pd \\ >>>>>& pd \\ >>>>& pd \\ >>>>>& pd \\ >>>> & pd \\ >>>>>& pd \\ >>>> & pd \\ >>>>>& pd \\ >>>> & pd \\ >>>>& pd \\ >>>>>& pd \\ >>>>>& pd \\ >>>>>& pd \\ >>>> & pd \\ >>>>>& pd \\ >>>>> & pd \\ >>>> & pd \\ >> & pd \\ >>>> & pd \\ >> & pd \\ >>>> & pd \\ >> & pd \\ >>> & pd \\ >> & pd \\ >> & pd \\ >>> & pd \\ >> & pd \\$	0 (TF3, TF2, TF0) 13 Computed 0 (TF4, TF3, TF0) 19 Computed 0 (TF0, TF0, TF1) 20

>>>>>βd	
>>>>>referenceTFCld	0
>>>>TFC 7	~
	(TF1, TF0, TF1)
>>>>>ctfc	21
>>>>>gainFactorInform	Computed
ation	·
>>>>>>referenceTFCId	0
	~
>>>>TFC 8	(TF2, TF1, TF1)
>>>>>ctfc	27
>>>>>gainFactorInform	computed
ation	computed
_	
>>>>>>βc (FDD only)	
>>>>>βd	
	1
>>>>>>referenceTFCId	0
>>>>TFC 9	(TF3, TF2, TF1)
>>>>>ctfc	33
>>>>>gainFactorInform	computed
	computed
ation	
>>>>>referenceTFCId	0
>>>>TFC 10	(TF4, TF3, TF1)
	39
>>>>>ctfc	
>>>>>gainFactorInform	signalled
ation	<u> </u>
>>>>>βc (FDD only)	11
>>>>>βd	15
>>>>>referenceTFCId	0
> TFC subset list	
	(1 (0 0)
>>TFC subset 1	(speech rate 6.6)
>>> Allowed transport	(TFC1, TFC2,
format combination list	TFC3, TFC6, TFC7,
	TFC8)
L. TEC auboot 2	(anacah rata 0.05)
>>TFC subset 2	(speech rate 8.85)
>>> Allowed transport	(TFC1, TFC2,
	(TFC1, TFC2,
>>> Allowed transport	(TFC1, TFC2, TFC3, TFC4, TFC6,
>>> Allowed transport format combination list	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9)
>>> Allowed transport format combination list >>TFC subset 3	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65)
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2,
>>> Allowed transport format combination list >>TFC subset 3	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5,
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5,
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8,
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5,
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10)
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8,
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10)
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10)
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo >tfcs-ID (TDD only)	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10)
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo >tfcs-ID (TDD only) >sharedChannelIndicator	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10)
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo >tfcs-ID (TDD only) >sharedChannelIndicator (TDD only)	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10)
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo >tfcs-ID (TDD only) >sharedChannelIndicator (TDD only) > tfc-Subset	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10)
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo >tfcs-ID (TDD only) >sharedChannelIndicator (TDD only) > tfc-Subset	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10)
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo >tfcs-ID (TDD only) >sharedChannelIndicator (TDD only)	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10) Independent 1 FALSE Absent, not required Normal TFCI
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo >tfcs-ID (TDD only) >sharedChannelIndicator (TDD only) > tfc-Subset >dl-TFCS	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10) Independent 1 FALSE Absent, not required Normal TFCI signalling
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo >tfcs-ID (TDD only) >sharedChannelIndicator (TDD only) > tfc-Subset >dl-TFCS >>explicitTFCS-	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10) Independent 1 FALSE Absent, not required Normal TFCI
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo >tfcs-ID (TDD only) >sharedChannelIndicator (TDD only) > tfc-Subset >dl-TFCS >>explicitTFCS-ConfigurationMode	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10) Independent 1 FALSE Absent, not required Normal TFCI signalling Complete
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo >tfcs-ID (TDD only) >sharedChannelIndicator (TDD only) > tfc-Subset >dl-TFCS >>explicitTFCS-	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10) Independent 1 FALSE Absent, not required Normal TFCI signalling
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo >tfcs-ID (TDD only) >sharedChannelIndicator (TDD only) > tfc-Subset >dl-TFCS >>explicitTFCS- ConfigurationMode >>>ctfcSize	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10) Independent 1 FALSE Absent, not required Normal TFCI signalling Complete Ctfc8Bit
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo >tfcs-ID (TDD only) >sharedChannelIndicator (TDD only) > tfc-Subset >dl-TFCS >>explicitTFCS- ConfigurationMode >>>ctfcSize >>>>TFCS representation	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10) Independent 1 FALSE Absent, not required Normal TFCI signalling Complete
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo >tfcs-ID (TDD only) >sharedChannelIndicator (TDD only) > tfc-Subset >dl-TFCS >>explicitTFCS- ConfigurationMode >>>ctfcSize >>>>TFCS representation >>>>TFCS list	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10) Independent 1 FALSE Absent, not required Normal TFCI signalling Complete Ctfc8Bit Addition
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo >tfcs-ID (TDD only) >sharedChannelIndicator (TDD only) > tfc-Subset >dl-TFCS >>explicitTFCS- ConfigurationMode >>>ctfcSize >>>>TFCS representation	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10) Independent 1 FALSE Absent, not required Normal TFCI signalling Complete Ctfc8Bit Addition (TF0, TF0, TF0,
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo >tfcs-ID (TDD only) >sharedChannelIndicator (TDD only) > tfc-Subset >dl-TFCS >>explicitTFCS- ConfigurationMode >>>ctfcSize >>>>TFCS representation >>>>TFCS list	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10) Independent 1 FALSE Absent, not required Normal TFCI signalling Complete Ctfc8Bit Addition
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo >tfcs-ID (TDD only) >sharedChannelIndicator (TDD only) > tfc-Subset >dl-TFCS >>explicitTFCS- ConfigurationMode >>>ctfcSize >>>>TFCS representation >>>>TFCS list >>>>>TFCS 1	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10) Independent 1 FALSE Absent, not required Normal TFCI signalling Complete Ctfc8Bit Addition (TF0, TF0, TF0, TF0, TF0)
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo >tfcs-ID (TDD only) >sharedChannelIndicator (TDD only) > tfc-Subset >dl-TFCS >>explicitTFCS- ConfigurationMode >>>ctfcSize >>>>TFCS representation >>>>>TFCS list >>>>>>TFCS 1	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10) Independent 1 FALSE Absent, not required Normal TFCI signalling Complete Ctfc8Bit Addition (TF0, TF0, TF0, TF0, TF0) 0
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo >tfcs-ID (TDD only) >sharedChannelIndicator (TDD only) > tfc-Subset >dl-TFCS >>explicitTFCS- ConfigurationMode >>>ctfcSize >>>>TFCS representation >>>>TFCS list >>>>>TFCS 1	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10) Independent 1 FALSE Absent, not required Normal TFCI signalling Complete Ctfc8Bit Addition (TF0, TF0, TF0, TF0, TF0) 0 (TF1, TF0, TF0,
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo >tfcs-ID (TDD only) >sharedChannelIndicator (TDD only) > tfc-Subset >dl-TFCS >>explicitTFCS- ConfigurationMode >>>ctfcSize >>>>TFCS representation >>>>TFCS list >>>>>>TFC 1 >>>>>>TFC 2	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10) Independent 1 FALSE Absent, not required Normal TFCI signalling Complete Ctfc8Bit Addition (TF0, TF0, TF0, TF0, TF0) 0 (TF1, TF0, TF0, TF0, TF0)
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo >tfcs-ID (TDD only) >sharedChannelIndicator (TDD only) > tfc-Subset >dl-TFCS >>explicitTFCS- ConfigurationMode >>>ctfcSize >>>>TFCS representation >>>>>TFCS list >>>>>>TFCS 1	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10) Independent 1 FALSE Absent, not required Normal TFCI signalling Complete Ctfc8Bit Addition (TF0, TF0, TF0, TF0, TF0) 0 (TF1, TF0, TF0, TF0, TF0) 1
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo >tfcs-ID (TDD only) >sharedChannelIndicator (TDD only) > tfc-Subset >dl-TFCS >>explicitTFCS- ConfigurationMode >>>ctfcSize >>>>TFCS representation >>>>TFCS list >>>>>>TFC 1 >>>>>>TFC 2	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10) Independent 1 FALSE Absent, not required Normal TFCI signalling Complete Ctfc8Bit Addition (TF0, TF0, TF0, TF0, TF0) 0 (TF1, TF0, TF0, TF0, TF0) 1
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo >tfcs-ID (TDD only) >sharedChannelIndicator (TDD only) > tfc-Subset >dl-TFCS >>explicitTFCS- ConfigurationMode >>>ctfcSize >>>>TFCS representation >>>>TFCS list >>>>>>TFC 1 >>>>>>>TFC 2 >>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10) Independent 1 FALSE Absent, not required Normal TFCI signalling Complete Ctfc8Bit Addition (TF0, TF0, TF0, TF0, TF0) 0 (TF1, TF0, TF0, TF0, TF0) 1 (TF2, TF1, TF0,
>>> Allowed transport format combination list >>TFC subset 3 >>> Allowed transport format combination list dl-CommonTransChInfo >tfcs-SignallingMode ul-CommonTransChInfo >tfcs-ID (TDD only) >sharedChannelIndicator (TDD only) > tfc-Subset >dl-TFCS >>explicitTFCS- ConfigurationMode >>>ctfcSize >>>>TFCS representation >>>>TFCS list >>>>>>TFC 1 >>>>>>>TFC 2 >>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>	(TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) (speech rate 12.65) (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10) Independent 1 FALSE Absent, not required Normal TFCI signalling Complete Ctfc8Bit Addition (TF0, TF0, TF0, TF0, TF0) 0 (TF1, TF0, TF0, TF0, TF0) 1

>>>>TFC 4	(TF3, TF2, TF0, TF0)
otfo	13
>>>>>ctfc >>>>>TFC 5	(TF4, TF3, TF0,
>>>>> IFC 5	TF0)
>>>>>ctfc	19
>>>>TFC 6	(TF0, TF0, TF1,
77771100	TF0)
>>>>>ctfc	20
>>>>TFC 7	(TF1, TF0, TF1,
777771101	TF0)
>>>>>ctfc	21
>>>>TFC 8	(TF2, TF1, TF1,
	TF0)
>>>>>ctfc	27
>>>>TFC 9	(TF3, TF2, TF1,
	TF0)
>>>>>ctfc	33
>>>>TFC 10	(TF4, TF3, TF1,
	TF0)
>>>>>ctfc	39
>>>>TFC 11	(TF0, TF0, TF0,
	TF1)
>>>>>ctfc	40
>>>>TFC 12	(TF1, TF0, TF0,
	TF1)
>>>>>ctfc	41
>>>>TFC 13	(TF2, TF1, TF0,
	TF1)
>>>>>ctfc	47
>>>>TFC 14	(TF3, TF2, TF0,
-16-	TF1)
>>>>>ctfc >>>>TFC 15	53 (TF4, TF3, TF0,
>>>>> 1FC 15	TF1)
>>>>>ctfc	59
>>>>TFC 16	(TF0, TF0, TF1,
7777711010	TF1)
>>>>>ctfc	60
>>>>TFC 17	(TF1, TF0, TF1,
	TF1)
>>>>>ctfc	61
>>>>TFC 18	(TF2, TF1, TF1,
	TF1)
>>>>>ctfc	67
>>>>TFC 19	(TF3, TF2, TF1,
	TF1)
>>>>>ctfc	73
>>>>TFC 20	(TF4, TF3, TF1,
	TF1)
>>>>>ctfc	79
PhyCH INFORMATION	
FDD	
UL-DPCH-InfoPredef	
>ul-DPCH- PowerControlInfo	
>>powerControllalgorithm	Algorithm 1
>>>tpcStepSize	1
>tfci-Existence	TRUE
>puncturingLimit	0.84
DL-	0.07
CommonInformationPredef	
>dl-DPCH-InfoCommon	
>>spreadingFactor	128
>>tfci-Existence	FALSE
101 = 210101100	

>>pilotBits	4
>>positionFixed	Fixed

14 Specific functions

14.1 Intra-frequency measurements

14.1.1 Intra-frequency measurement quantities

A measurement quantity is used to evaluate whether an intra-frequency event has occurred or not. It can be:

- 1 Downlink E_c/N₀.
- 2 Downlink path loss.

For FDD:

Pathloss in dB = Primary CPICH Tx power - CPICH RSCP.

For Primary CPICH Tx power the IE "Primary CPICH Tx power" shall be used. The unit is dBm.

CPICH RSCP is the result of the CPICH RSCP measurement. The unit is dBm.

For TDD:

Pathloss in dB = Primary CCPCH TX power - Primary CCPCH RSCP.

For Primary CCPCH TX power the IE "Primary CCPCH TX Power" shall be used. The unit is dBm.

Primary CCPCH RSCP is the result of the Primary CCPCH RSCP measurement. The unit is dBm.

If necessary Pathloss shall be rounded up to the next higher integer.

Results higher than 158 shall be reported as 158.

Results lower than 46 shall be reported as 46.

- 3 Downlink received signal code power (RSCP) after despreading.
- 4 ISCP measured on Timeslot basis.

A description of those values can be found in [7] and [8].

14.1.2 Intra-frequency reporting events for FDD

Within the measurement reporting criteria field in the Measurement Control message the UTRAN notifies the UE which events should trigger a measurement report. The listed events are the toolbox from which the UTRAN can choose the reporting events that are needed for the implemented handover evaluation function, or other radio network functions.

All the specified events are measured with respect to any of the measurement quantities given in subclause 14.1.1. The measurement quantities are measured on the monitored primary common pilot channels (CPICH) of the cell defined in the measurement object.

Special mechanisms for the events are illustrated in subclause 14.1.4 and 14.1.5.

NOTE: The events below are numbered 1A, 1B, 1C,... since all intra-frequency reporting events would be labelled 1X, inter-frequency reporting events would be labelled 2X, and so on for the other measurement types.

When one intra-frequency measurement identity corresponds to multiple intra-frequency events with identical event identities, the UE behaviour is not specified.

14.1.2.1 Reporting event 1A: A Primary CPICH enters the reporting range

When an intra-frequency measurement configuring event 1a is set up, the UE shall:

- 1> create a variable TRIGGERED_1A_EVENT related to that measurement, which shall initially be empty;
- 1> delete this variable when the measurement is released.

When event 1A is configured in the UE, the UE shall:

- 1> if "Measurement quantity" is "pathloss" and Equation 1 below is fulfilled for one or more primary CPICHs, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 2 below is fulfilled for one or more primary CPICHs, for each of these primary CPICHs:
 - 2> if all required reporting quantities are available for that cell; and
 - 2> if the equations have been fulfilled for a time period indicated by "Time to trigger", and if that primary CPICH is part of cells allowed to trigger the event according to "Triggering condition 2", and if that primary CPICH is not included in the "cells triggered" in the variable TRIGGERED_1A_EVENT:
- 3> include that primary CPICH in the "cells recently triggered" in the variable TRIGGERED_1A_EVENT.
 - 1> if the value of "Reporting deactivations threshold" for this event is greater than or equal to the current number of cells in the active set or equal to 0 and any primary CPICHs are stored in the "cells recently triggered" in the variable TRIGGERED_1A_EVENT:
 - 2> if "Reporting interval" for this event is not equal to 0:
- 3> if the IE "Periodical reporting running" in the variable TRIGGERED_1A_EVENT is set to FALSE:
 - 4> start a timer with the value of "Reporting interval" for this event and set the IE "Periodical reporting running" in the variable TRIGGERED_1A_EVENT to TRUE;
- 3> set "sent reports" for the primary CPICHs in "cells recently triggered" in the variable TRIGGERED_1A_EVENT to 1.
 - 2> send a measurement report with IEs set as below:
- 3> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1a"; and
- 3> include in "cell measurement event results" all entries of the "cells recently triggered" in the variable TRIGGERED_1A_EVENT in descending order according to the configured measurement quantity taking into account the cell individual offset for each of those cells;
- 3> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset for each cell.
 - 2> move all entries from "cells recently triggered" to "cells triggered" in the variable TRIGGERED_1A_EVENT.
 - 1> if the timer for the periodical reporting has expired:
 - 2> if any primary CPICH is included in the "cells triggered" in the variable TRIGGERED_1A_EVENT:
- 3> if "Reporting interval" for this event is not equal to 0, and if "Amount of reporting" is greater than "sent reports" stored for any of these primary CPICHs, in "cells triggered" in the variable TRIGGERED_1A_EVENT:
 - 4> increment the stored counter "sent reports" for all CPICHs in "cell triggered" in variable TRIGGERED_1A_EVENT;
 - 4> start a timer with the value of "Reporting interval" for this event;
 - 4> send a measurement report with IEs set as below:
 - 5> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1a"; and

- 5> include in "cell measurement event results" all entries of the variable TRIGGERED_1A_EVENT with value of IE "sent reports" smaller than value of "Amount of reporting" in descending order according to the configured measurement quantity taking into account the cell individual offset for each of those cells;
- 5> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset for each cell.
- 4> if "sent reports" in variable TRIGGERED_1A_EVENT is greater than "Amount of reporting" for all entries:
 - 5> set the IE "Periodical Reporting running" in the variable TRIGGERED_1A_EVENT to FALSE and disable the timer for the periodical reporting.
- 1> if "Measurement quantity" is "pathloss" and Equation 3 below is fulfilled for a primary CPICH, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 4 below is fulfilled for a primary CPICH; or
- 1> if a primary CPICH is no longer part of the cells allowed to trigger the event according to the "Triggering condition 2":
 - 2> if that primary CPICH is included in the "cells triggered" or "cells recently triggered" in the variable TRIGGERED_1A_EVENT:

3> remove the entry of that primary CPICH from "cells triggered" or "cells recently triggered" in the variable TRIGGERED_1A_EVENT.

- 3> if no entry in the variable TRIGGERED_1A_EVENT has a value of "sent reports" smaller than "Amount of reporting":
 - 4> stop the reporting interval timer;
 - 4> set the IE "Periodical reporting running" in the variable TRIGGERED_1A_EVENT to FALSE.

This event is only applicable to the CELL_DCH state. When the measurement is setup in CELL_DCH or upon transition to CELL_DCH the UE shall:

- 1> if the "Triggering condition 2" includes active set cells:
 - 2> include the primary CPICH of all cells in the current active set into the "cells triggered" in the variable TRIGGERED_1A_EVENT with the counter "sent reports" set to "Amount of reporting".

Equation 1 (Triggering condition for pathloss)

$$10 \cdot LogM_{New} + CIO_{New} \leq W \cdot 10 \cdot Log\left(1 / \sum_{i=1}^{N_A} (1 / M_i)\right) + (1 - W) \cdot 10 \cdot LogM_{Best} + (R_{1a} - H_{1a} / 2),$$

Equation 2 (Triggering condition for all the other measurement quantities)

$$10 \cdot Log M_{New} + CIO_{New} \ge W \cdot 10 \cdot Log \left(\sum_{i=1}^{N_A} M_i \right) + (1 - W) \cdot 10 \cdot Log M_{Best} - (R_{1a} - H_{1a}/2),$$

Equation 3 (Leaving triggering condition for pathloss)

$$10 \cdot LogM_{New} + CIO_{New} > W \cdot 10 \cdot Log\left(1/\sum_{i=1}^{N_A} (1/M_i)\right) + (1-W) \cdot 10 \cdot LogM_{Best} + (R_{1a} + H_{1a}/2),$$

Equation 4 (Leaving triggering condition for all the other measurement quantities)

$$10 \cdot Log M_{New} + CIO_{New} < W \cdot 10 \cdot Log \left(\sum_{i=1}^{N_A} M_i \right) + (1 - W) \cdot 10 \cdot Log M_{Best} - (R_{1a} + H_{1a}/2),$$

The variables in the formula are defined as follows:

 M_{New} is the measurement result of the cell entering the reporting range.

 CIO_{New} is the individual cell offset for the cell entering the reporting range if an individual cell offset is stored for that cell. Otherwise it is equal to 0.

 M_i is a measurement result of a cell not forbidden to affect reporting range in the active set.

 N_A is the number of cells not forbidden to affect reporting range in the current active set.

For pathloss

 M_{Best} is the measurement result of the cell not forbidden to affect reporting range in the active set with the lowest measurement result, not taking into account any cell individual offset.

for other measurements quantities.

 M_{Best} is the measurement result of the cell not forbidden to affect reporting range in the active set with the highest measurement result, not taking into account any cell individual offset.

W is a parameter sent from UTRAN to UE.

 R_{1a} is the reporting range constant.

 H_{1a} is the hysteresis parameter for the event 1a.

If the measurement results are pathloss or CPICH-Ec/No then M_{New} , M_i and M_{Best} are expressed as ratios.

If the measurement result is CPICH-RSCP then M_{New} , M_i and M_{Best} are expressed in mW.

14.1.2.2 Reporting event 1B: A primary CPICH leaves the reporting range

When an intra-frequency measurement configuring event 1b is set up, the UE shall:

- 1> create a variable TRIGGERED_1B_EVENT related to that measurement, which shall initially be empty;
- 1> delete this variable when the measurement is released.

When event 1B is configures in the UE, the UE shall:

- 1> if "Measurement quantity" is "pathloss" and Equation 1 below is fulfilled for one or more primary CPICHs, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 2 below is fulfilled for one or more primary CPICHs, for each of these primary CPICHs:
 - 2> if all required reporting quantities are available for that cell, and if the equations have been fulfilled for a time period indicated by "Time to trigger", and if that primary CPICH is part of cells allowed to trigger the event according to "Triggering condition 1", and if that primary CPICH is not included in the "cells triggered" in the variable TRIGGERED_1B_EVENT:
- 3> include that primary CPICH in the "cells recently triggered" in the variable TRIGGERED 1B EVENT.
 - 1> if any primary CPICHs are stored in the "cells recently triggered" in the variable TRIGGERED_1B_EVENT:
 - 2> if "Periodic reporting info-1b" is present, and "Reporting interval" for this event is not equal to 0:
- 3> if the IE "Periodical reporting running" in the variable TRIGGERED_1B_EVENT is set to FALSE:
 - 4> start a timer with the value of "Reporting interval" for this event and set the IE "Periodical reporting running" in the variable TRIGGERED_1B_EVENT to TRUE;
- 3> set "sent reports" for the primary CPICHs in "cells recently triggered" in the variable TRIGGERED_1B_EVENT to 1.
 - 2> send a measurement report with IEs set as below:
- 3> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1b"; and

3> include in "cell measurement event results" all entries of "cells recently triggered" in the variable TRIGGERED_1B_EVENT in ascending order according to the configured measurement quantity taking into account the cell individual offset for each of those cells;

3> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset for each cell.

- 2> move all entries from IE "cells recently triggered" to "cells triggered" in the variable TRIGGERED_1B_EVENT.
- 1> if the timer for the periodical reporting has expired:
 - 2> if any primary CPICH is included in the "cells triggered" in the variable TRIGGERED_1B_EVENT:
 - 3> if "Periodic reporting info-1b" is present:
 - 4> if "Reporting interval" is not equal to 0, and if "Amount of reporting" is greater than "sent reports" stored for any of these primary CPICHs, in "cells triggered" in the variable TRIGGERED_1B_EVENT:
 - 5> increment the stored counter "sent reports" for all CPICHs in "cell triggered" in variable TRIGGERED_1B_EVENT;
 - 5> start a timer with the value of "Reporting interval-1b" for this event;
 - 5> send a measurement report with IEs set as below:
 - 6> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1b"; and
 - 6> include in "cell measurement event results" all entries of the variable TRIGGERED_1B_EVENT with value of IE "sent reports" smaller than value of "Amount of reporting" in ascending order according to the configured measurement quantity taking into account the cell individual offset for each of those cells;
 - 6> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset for each cell.
 - 5> if "sent reports" in variable TRIGGERED_1B_EVENT is greater than "Amount of reporting" for all entries:
 - 6> set the IE "Periodical Reporting running" in the variable TRIGGERED_1B_EVENT to FALSE and disable the timer for the periodical reporting.
- 1> if "Measurement quantity" is "pathloss" and Equation 3 below is fulfilled for a primary CPICH, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 4 below is fulfilled for a primary CPICH; or
- 1> if a primary CPICH is no longer part of the cells allowed to trigger the event according to the "Triggering condition 1":
 - 2> if that primary CPICH is included in the "cells triggered" in the variable TRIGGERED 1B EVENT:
- 3> remove the entry of that primary CPICH from "cells triggered" in the variable TRIGGERED_1B_EVENT.

Equation 1 (Triggering condition for pathloss)

$$10 \cdot Log M_{Old} + CIO_{Old} \ge W \cdot 10 \cdot Log \left(1 / \sum_{i=1}^{N_A} (1/M_i) \right) + (1-W) \cdot 10 \cdot Log M_{Best} + (R_{1b} + H_{1b} / 2),$$
 Equation 2 (Triggering condition for all the other measurement quantities)

$$10 \cdot Log M_{Old} + CIO_{Old} \le W \cdot 10 \cdot Log \left(\sum_{i=1}^{N_A} M_i\right) + (1 - W) \cdot 10 \cdot Log M_{Best} - (R_{1b} + H_{1b}/2)$$
, Equation 3 (Leaving triggering condition for pathloss)

 $10 \cdot LogM_{Old} + CIO_{Old} < W \cdot 10 \cdot Log\left(1/\sum_{i=1}^{N_A} (1/M_i)\right) + (1-W) \cdot 10 \cdot LogM_{Best} + (R_{1b} - H_{1b} / 2)$, Equation 4 (Leaving triggering condition for all the other measurement quantities)

$$10 \cdot Log M_{old} + CIO_{old} > W \cdot 10 \cdot Log \left(\sum_{i=1}^{N_A} M_i\right) + (1-W) \cdot 10 \cdot Log M_{Best} - (R_{1b} - H_{1b}/2)$$
, The variables in the formula are defined as follows:

 M_{Old} is the measurement result of the cell leaving the reporting range.

*CIO*_{Old} is the individual cell offset for the cell leaving the reporting range if an individual cell offset is stored for that cell. Otherwise it is equal to 0.

 M_i is a measurement result of a cell not forbidden to affect reporting range in the active set.

 N_A is the number of cells not forbidden to affect reporting range in the current active set.

For pathloss

 M_{Best} is the measurement result of the cell not forbidden to affect reporting range in the active set with the lowest measurement result, not taking into account any cell individual offset.

for other measurements quantities.

 M_{Best} is the measurement result of the cell not forbidden to affect reporting range in the active set with the highest measurement result, not taking into account any cell individual offset.

W is a parameter sent from UTRAN to UE.

 R_{1b} is the reporting range constant.

 H_{1b} is the hysteresis parameter for the event 1b.

If the measurement results are pathloss or CPICH-Ec/No then M_{Old} , M_i and M_{Best} are expressed as ratios.

If the measurement result is CPICH-RSCP then M_{Old} , M_i and M_{Best} are expressed in mW.

14.1.2.3 Reporting event 1C: A non-active primary CPICH becomes better than an active primary CPICH

When an intra-frequency measurement configuring event 1c is set up, the UE shall:

- 1> create a variable TRIGGERED_1C_EVENT related to that measurement, which shall initially be empty;
- 1> delete this variable when the measurement is released.

When event 1C is configured in the UE, the UE shall:

- 1> if "Measurement quantity" is "pathloss" and Equation 1 below is fulfilled for one or more primary CPICHs, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 2 below is fulfilled for one or more primary CPICHs, for each of these primary CPICHs:
 - 2> if all required reporting quantities are available for that cell; and
 - 2> if the equations have been fulfilled for a time period indicated by "Time to trigger", and if the primary CPICH that is better is not included in the active set but the other primary CPICH is any of the primary CPICHs included in the active set, and if that first primary CPICH is not included in the "cells triggered" in the variable TRIGGERED_1C_EVENT:
- 3> include that primary CPICH in the "cells recently triggered" in the variable TRIGGERED_1C_EVENT.
 - 1> if the value of "Replacement activation threshold" for this event is less than or equal to the current number of cells in the active set or equal to 0 and if any primary CPICHs are stored in the "cells recently triggered" in the variable TRIGGERED_1C_EVENT:

- 2> if "Reporting interval" for this event is not equal to 0:
- 3> if the IE "Periodical reporting running" in the variable TRIGGERED_1C_EVENT is set to FALSE:
 - 4> start a timer for with the value of "Reporting interval" for this event and set the IE "Periodical reporting running" in the variable TRIGGERED_1C_EVENT to TRUE.
- 3> set "sent reports" for that primary CPICH in the variable TRIGGERED 1C EVENT to 1.
 - 2> send a measurement report with IEs set as below:
- 3> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1c"; and
- 3> include in "cell measurement event results" all entries of the "cells recently triggered" in the variable TRIGGERED_1C_EVENT not in the active set as well as the "primary CPICH info" of all the primary CPICHs in the active set for which the measured value is worse (i.e. greater for pathloss and less for the other measurement quantities) than the one of the entry in "cell recently triggered" that has the best measured value taking into account their cell individual offset. The "primary CPICH info" for those cells shall be ordered according to their measured value taking into account their cell individual offset, beginning with the best cell to the worst one;
- 3> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset for each cell.
 - 2> move all entries from "cells recently triggered" to "cells triggered" in the variable TRIGGERED_1C_EVENT.
 - 1> if the timer for the periodical reporting has expired:
 - 2> if any primary CPICH is included in the "cells triggered" in the variable TRIGGERED_1C_EVENT, and not included in the current active set:
- 3> if "Reporting interval" for this event is not equal to 0, and if "Amount of reporting" is greater than "sent reports" stored for that primary CPICH, in "cells triggered" in the variable TRIGGERED_1C_EVENT:
 - 4> increment the stored counter "sent reports" for all CPICH in "cell triggered" in variable TRIGGERED_1C_EVENT;
 - 4> start a timer with the value of "Reporting interval" for this event;
 - 4> send a measurement report with IEs set as below:
 - 5> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1c"; and
 - 5> include in "cell measurement event results" all entries of the variable TRIGGERED_1C_EVENT with value of IE "sent report" smaller than value of "Amount of reporting" and that are not part of the active set as well as the "primary CPICH info" of all the primary CPICHs in the active set for which the measured value is worse (i.e. greater for pathloss and less for the other measurement quantities) than the one of the entry in "cell recently triggered" that has the best measured value, ordering the "primary CPICH info" according to their measured value beginning with the best cell to the worst one, taking into account the cell individual offset for each cell;
 - 5> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset for each cell.
 - 4> if "sent reports" in variable TRIGGERED_1C_EVENT is greater than "Amount of reporting" for all entries:
 - 5> set the IE "Periodical Reporting running" in the variable TRIGGERED_1C_EVENT to FALSE and disable the timer for the periodical reporting.
 - 1> if "Measurement quantity" is "pathloss" and Equation 3 below is fulfilled for a primary CPICH, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 4 below is fulfilled for a primary CPICH or;
 - 1> if a primary CPICH is added to the active set:

2> if that primary CPICH is included in the "cells triggered" or "cells recently triggered" in the variable TRIGGERED_1C_EVENT:

3> remove the entry of that primary CPICH from "cells triggered" or "cells recently triggered" in the variable TRIGGERED_1C_EVENT.

3> if no entry in the variable TRIGGERED_1C_EVENT has a value of "sent reports" smaller than "Amount of reporting":

4> stop the reporting interval timer;

4> set the IE "Periodical reporting running" in the variable TRIGGERED 1C EVENT to FALSE.

Equation 1 (Triggering condition for pathloss)

$$10 Log M_{ew} + CIQ_{ew} \leq 10 Log M_{eAS} + CIQ_{eAS} - H_{lc}/2$$

Equation 2 (Triggering condition for all the other measurement quantities)

$$10 Log M_{ev} + CIQ_{ev} \ge 10 Log M_{eAS} + CIQ_{eAS} + H_{lo}/2$$

Equation 3 (Leaving triggering condition for pathloss)

$$10 Log M_{ev} + CIQ_{ev} > 10 Log M_{PAS} + CIQ_{PAS} + H_{Ic}/2$$

Equation 4 (Leaving triggering condition for all the other measurement quantities)

$$10 Log M_{PW} + CIQ_{PW} < 10 Log M_{PAS} + CIQ_{PAS} - H_{Ic}/2$$

The variables in the formula are defined as follows:

 M_{New} is the measurement result of the cell not included in the active set.

 CIO_{New} is the individual cell offset for the cell becoming better than the cell in the active set if an individual cell offset is stored for that cell. Otherwise it is equal to 0.

For pathloss:

 M_{InAS} is the measurement result of the cell in the active set with the highest measurement result.

For other measurement quantities:

 M_{lnAS} is the measurement result of the cell in the active set with the lowest measurement result.

 CIO_{InAS} is the individual cell offset for the cell in the active set that is becoming worse than the new cell.

 H_{1c} is the hysteresis parameter for the event 1c.

If the measurement results are pathloss or CPICH-Ec/No then M_{New} and M_{inAS} are expressed as ratios.

If the measurement result is CPICH-RSCP then M_{New} and M_{inAS} are expressed in mW.




Figure 14.1.2.3-1 [Informative]: A primary CPICH that is not included in the active set becomes better than a primary CPICH that is in the active set

In this figure, the parameters hysteresis and time to trigger, as well as the cell individual offsets for all cells are equal to 0. In this example the cells belonging to primary CPICH 1 and 2 are in the active set, but the cells transmitting primary CPICH 3 and CPICH 4 are not (yet) in the active set.

The first measurement report is sent when primary CPICH 4 becomes better than primary CPICH 2. The "cell measurement event result" of the measurement report contains the information of primary CPICH 4 and CPICH 2.

Assuming that the active set has been updated after the first measurement report (active set is now primary CPICH 1 and primary CPICH 4), the second report is sent when primary CPICH 3 becomes better than primary CPICH 1. The "cell measurement event result" of the second measurement report contains the information of primary CPICH 3 and primary CPICH 1.

14.1.2.4 Reporting event 1D: Change of best cell

When an intra-frequency measurement configuring event 1d is set up, the UE shall:

- 1> create a variable TRIGGERED_1D_EVENT related to that measurement, which shall initially contain the best cell in the active set when the measurement is initiated;
- 1> delete this variable when the measurement is released.
- 1> As soon as the best cell in the active set has been evaluated by the UE (and stored in the TRIGGERED_1D_EVENT variable) and provided that there is more than one cell in the active set, trigger an immediate measurement report with IEs set as below:
 - 2> set in "intra-frequency measurement event results"; "Intrafrequency event identity" to "1d" and "cell measurement event results" to the CPICH info of the primary CPICH stored in the TRIGGERED_1D_EVENT variable;
 - 2> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2

When event 1D is configured in the UE, the UE shall:

- 1> if IE "useCIO" is present and its value is TRUE, take into account the Cell Individual Offset for evaluation of the Equation 1 and 2, otherwise do not take it into account.
- 1> if "Measurement quantity" is "pathloss" and Equation 1 below is fulfilled for a primary CPICH that is not stored in "Best cell" in variable BEST_CELL_1D_EVENT, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 2 below is fulfilled for a primary CPICH that is not stored in "Best cell" in variable BEST_CELL_1D_EVENT:

NOTE: If the equations are simultaneously fulfilled for more than one primary CPICH, the UE should report only one event 1D, triggered by the best primary CPICH.

- 2> if all required reporting quantities are available for that cell, and if the equations have been fulfilled for a time period indicated by "Time to trigger" and if IE "Triggering condition 2" is absent or if it is present and that primary CPICH is part of cells allowed to trigger the event according to "Triggering condition 2":
- 3> set "best cell" in the variable BEST_CELL_1D_EVENT to that primary CPICH that triggered the event;
- 3> send a measurement report with IEs set as below:
 - 4> set in "intra-frequency measurement event results"; "Intrafrequency event identity" to "1d" and "cell measurement event results" to the CPICH info of the primary CPICH that triggered the report.
 - 4> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2.

This event is only applicable to the CELL_DCH state. Upon transition to CELL_DCH the UE shall:

1> set "best cell" in the variable BEST_CELL_1D_EVENT to the best cell of the primary CPICHs included in the active set.

Equation 1 (Triggering condition for pathloss)

$$10 Log M_{otBest} + CIQ_{otBest} \le 10 Log M_{est} + CIQ_{est} - H_{ld}/2$$

Equation 2 (Triggering condition for all the other measurement quantities)

$$10 Log M_{totBest} + CIQ_{totBest} \ge 10 Log M_{test} + CIQ_{test} + H_{td}/2$$

The variables in the formula are defined as follows:

 $M_{NotBest}$ is the measurement result of a cell not stored in "best cell" in the variable BEST_CELL_1D_EVENT.

CIO_{NotBest} is the cell individual offset of a cell not stored in "best cell" in the variable BEST_CELL_1D_EVENT.

 M_{Best} is the measurement result of the cell stored in "best cell" in variable BEST_CELL_1D_EVENT.

CIO_{Best} is the cell individual offset of a cell stored in "best cell" in the variable BEST_CELL_1D_EVENT.

 H_{1d} is the hysteresis parameter for the event 1d.

If the measurement results are pathloss or CPICH-Ec/No then $M_{Not Best}$ and M_{Best} are expressed as ratios.

If the measurement result is CPICH-RSCP then $M_{Not Best}$ and M_{Best} are expressed in mW.




Figure 14.1.2.4-1 [Informative]: A primary CPICH becomes better than the previously best primary CPICH

In this figure, the parameters hysteresis and time to trigger, as well as the cell individual offsets for all cells are equal to 0.

14.1.2.5 Reporting event 1E: A Primary CPICH becomes better than an absolute threshold

When an intra-frequency measurement configuring event 1e is set up, the UE shall:

- 1> create a variable TRIGGERED_1E_EVENT related to that measurement, which shall initially be empty;
- 1> delete this variable when the measurement is released.

When event 1E is configured in the UE, the UE shall:

- 1> if "Measurement quantity" is "pathloss" and Equation 1 below is fulfilled for a primary CPICH, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 2 below is fulfilled for one or more primary CPICHs, for each of these primary CPICHs:
 - 2> if all required reporting quantities are available for that cell, and if the equations have been fulfilled for a time period indicated by "Time to trigger", and if that primary CPICH is part of cells allowed to trigger the event according to "Triggering condition 2", and that primary CPICH is not included in the "cells triggered" in the variable TRIGGERED_1E_EVENT:
- 3> include that primary CPICH in the "cells recently triggered" in the variable TRIGGERED_1E_EVENT.
 - 1> if any primary CPICHs are stored in the "cells recently triggered" in the variable TRIGGERED_1E_EVENT:
 - 2> send a measurement report with IEs set as below:
- 3> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1e"; and
- 3> include in "cell measurement event results" all entries of the "cells recently triggered" in the variable TRIGGERED_1E_EVENT in descending order according to the configured measurement quantity taking into account the cell individual offset for each of those cells;
- 3> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset for each cell.
 - 2> move all entries from "cells recently triggered" to "cells triggered" in the variable TRIGGERED_1E_EVENT.
 - 1> if "Measurement quantity" is "pathloss" and Equation 3 below is fulfilled for a primary CPICH, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 4 below is fulfilled for a primary CPICH; or
 - 1> if a primary CPICH is no longer part of the cells allowed to trigger the event according to the "Triggering condition 2":
 - 2> if that primary CPICH is included in the "cells triggered" in the variable TRIGGERED_1E_EVENT:
- 3> remove that primary CPICH and sent reports from "cells triggered" in the variable TRIGGERED_1E_EVENT.

This event is only applicable to the CELL_DCH state. When the measurement is setup in CELL_DCH or upon transition to CELL_DCH the UE shall:

- 1> if the "Triggering condition 2" includes active set cells:
 - 2> include the primary CPICH of all cells in the current active set that fulfil the equations 1 or 2 according to the "Measurement quantity" of event 1e into the "cells triggered" in the variable TRIGGERED_1E_EVENT.

Equation 1 (Triggering condition for pathloss)

$$10 Log M_{ew} + CIQ_{ew} \leq T_{le} - H_{le}/2$$

Equation 2 (Triggering condition for all the other measurement quantities)

$$10 Log M_{ew} + CI Q_{ew} \ge T_{le} + H_{le}/2$$

Equation 3 (Leaving triggering condition for pathloss)

$$10 Log M_{Pew} + CIQ_{Pew} > T_{le} + H_{le}/2$$

Equation 4 (Leaving triggering condition for all the other measurement quantities)

$$10 Log M_{ew} + CIQ_{ew} < T_{le} - H_{le}/2$$
,

The variables in the formula are defined as follows:

 M_{New} is the measurement result of a cell that becomes better than an absolute threshold.

 CIO_{New} is the individual cell offset for the cell becoming better than the absolute threshold. Otherwise it is equal to

 T_{1e} is an absolute threshold.

 H_{1e} is the hysteresis parameter for the event 1e.

If the measurement results are pathloss or CPICH-Ec/No then M_{New} is expressed as ratios.

If the measurement result is CPICH-RSCP then M_{New} is expressed in mW.




Figure 14.1.2.5-1 [Informative]: Event-triggered report when a Primary CPICH becomes better than an absolute threshold

In this figure, the parameters hysteresis and time to trigger, as well as the cell individual offsets for all cells are equal to 0.

14.1.2.6 Reporting event 1F: A Primary CPICH becomes worse than an absolute threshold

When an intra-frequency measurement configuring event 1F is set up, the UE shall:

- 1> create a variable TRIGGERED_1F_EVENT related to that measurement, which shall initially be empty;
- 1> delete this variable when the measurement is released.

When event 1F is configured in the UE, the UE shall:

- 1> if "Measurement quantity" is "pathloss" and Equation 1 below is fulfilled for one or more primary CPICHs, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 2 below is fulfilled for one or more primary CPICHs, for each of these primary CPICHs:
 - 2> if all required reporting quantities are available for that cell, and if the equations have been fulfilled for a time period indicated by "Time to trigger", and if that primary CPICH is part of cells allowed to trigger the event according to "Triggering condition 1", and that primary CPICH is not included in the "cells triggered" in the variable TRIGGERED_1F_EVENT:

- 3> include that primary CPICH in the "cells recently triggered" in the variable TRIGGERED_1F_EVENT.
 - 1> if any primary CPICHs are stored in the "cells recently triggered" in the variable TRIGGERED_1F_EVENT:
 - 2> send a measurement report with IEs set as below:
- 3> set in "intra-frequency event measurement results": "Intrafrequency event identity" to "1f"; and
- 3> include in "cell measurement event results" all entries of the "cells recently triggered" in the variable TRIGGERED_1F_EVENT in descending order according to the configured measurement quantity taking into account the cell individual offset for each of those cells;
- 3> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset for each cell;
 - 2> move all entries from "cells recently triggered" to "cells triggered" in the variable TRIGGERED_1F_EVENT.
 - 1> if "Measurement quantity" is "pathloss" and Equation 3 below is fulfilled for a primary CPICH, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 4 below is fulfilled for a primary CPICH; or
 - 1> if a primary CPICH is no longer part of the cells allowed to trigger the event according to the "Triggering condition 1":
 - 2> if that primary CPICH is included in the "cells triggered" in the variable TRIGGERED_1F_EVENT:
- 3> remove that primary CPICH from "cells triggered" in the variable TRIGGERED_1F_EVENT.

Equation 1 (Triggering condition for pathloss)

$$10 Log M_{ld} + CIQ_{ld} \ge T_{1f} + H_{1f}/2$$
,

Equation 2 (Triggering condition for all the other measurement quantities)

$$10 Log M_{ld} + CIQ_{ld} \le T_{1f} - H_{1f}/2$$
,

Equation 3 (Leaving triggering condition for pathloss)

$$10 Log M_{ld} + CIQ_{ld} < T_{1f} - H_{1f}/2$$
,

Equation 4 (Leaving triggering condition for all the other measurement quantities)

$$10 Log M_{ld} + CIQ_{ld} > T_{1f} + H_{1f}/2$$
,

The variables in the formula are defined as follows:

 M_{Old} is the measurement result of a cell that becomes worse than an absolute threshold

CIO_{old} is the individual cell offset for the cell becoming worse than the absolute threshold. Otherwise it is equal to 0.

 T_{If} is an absolute threshold

 H_{1f} is the hysteresis parameter for the event 1f.

If the measurement results are pathloss or CPICH-Ec/No then M_{Old} is expressed as ratios.

If the measurement result is CPICH-RSCP then M_{Old} is expressed in mW.




Figure 14.1.2.6-1 [Informative]: Event-triggered report when a Primary CPICH becomes worse than an absolute threshold

In this figure, the parameters hysteresis and time to trigger, as well as the cell individual offsets for all cells are equal to 0.

14.1.3 Intra-frequency reporting events for TDD

14.1.3.1 Reporting event 1G: Change of best cell (TDD)

When event 1G is configured in the UE, the UE shall:

- 1> if the equation 1 is fulfilled for a P-CCPCHs during the time "Time to trigger" and if that P-CCPCH is not included in the "primary CCPCH info" in the variable TRIGGERED_1G_EVENT:
 - 2> include that P-CCPCH in "cells triggered" in the variable TRIGGERED_1G_EVENT;
 - 2> send a measurement report with IEs set as below:
- 3> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1g";
- 3> set the first entry in "cell measurement event results" to the "Cell parameters ID" of the P-CCPCH which was stored in the variable TRIGGERED_1G_EVENT;
- 3> include all entries in "cells triggered" in variable TRIGGERED_1G_EVENT in "cell measurement event results" in the measurement report in descending order according to:

$$10 \cdot LogM + O$$

where M is the P-CCPCH RSCP and O the individual offset of a cell;

- 3> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset for each cell.
- 1> if Equation 2 below is fulfilled for a primary CCPCH:
 - 2> if a primary CCPCH is included in the "cells triggered" in the variable TRIGGERED_1G_EVENT:
- 3> remove the entry of that primary CCPCH from "cells triggered" in the variable TRIGGERED_1G_EVENT;

The UE shall use the equations below for evaluation of reporting event 1g:

Equation 1

$$10 \cdot Log M + O_i - H_{1g} > 10 \cdot Log M_{previou\underline{s} \ best} + O_{previou\underline{s} \ best}$$

The variables in the formula are defined as follows:

M_{previous best} is the current P-CCPCH RSCP of the previous best cell expressed in mW

 $O_{previous\ best}$ is the cell individual offset of the previous best cell

 M_i is the current P-CCPCH RSCP of the currently evaluated cell i expressed in mW

 O_i is the cell individual offset of the currently evaluated cell i

 H_{1g} is the hysteresis parameter for the event 1g.

Equation 2

$$10 Log M_{l} + O_{l} + H_{lg} < 10 Log M_{previous best} + O_{previous best}$$

The variables in the formula are defined as follows:

 $M_{previous_best}$ is the current P-CCPCH RSCP of the previous best cell expressed in mW

 $O_{previous_best}$ is the cell individual offset of the previous best cell

 M_i is the current P-CCPCH RSCP of the currently evaluated cell i expressed in mW

 O_i is the cell individual offset of the currently evaluated cell i

 H_{1g} is the hysteresis parameter for the event 1g.




Figure 14.1.3.1-1: A P-CCPCH RSCP becomes better than the previous best P-CCPCH RSCP

14.1.3.2 Reporting event 1H: Timeslot ISCP below a certain threshold (TDD)

When event 1h is configured in the UE, the UE shall:

- 1> if equation 1 is fulfilled for a time period indicated by "Time to trigger" and if that P-CCPCH is not included in the IE "cells triggered" in the variable TRIGGERED_1H_EVENT:
 - 2> include that P-CCPCH in the IE "cells triggered" in the variable TRIGGERED_1H_EVENT;
 - 2> send a measurement report with the IEs set as below:

3> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1h" and in "cell measurement event results" the "Cell parameters ID" of the P-CCPCH that triggered the report;

3> include in "Cell measured results" the "Timeslot ISCP" of those cells that are included in the variable TRIGGERED_1H_EVENT.

- 1> if a primary CCPCH is included in the "cells triggered" in the variable TRIGGERED_1H_EVENT:
 - 2> send a measurement report with IEs set as below:

3> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1h" and "cell measurement event results" to the "Cell parameters ID" of the P-CCPCH that triggered the report;

3> set in "measured results" the "Timeslot ISCP" of those cells that are included in the variable TRIGGERED_1H_EVENT and "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset for each cell.

1> if Equation 2 below is fulfilled for a primary CCPCH:

2> if a primary CCPCH is included in the "cells triggered" in the variable TRIGGERED_1H_EVENT:

3> remove the entry of that primary CCPCH from "cells triggered" in the variable TRIGGERED_1H_EVENT.

The UE shall use the equations below for evaluation of reporting event 1h:

Equation 1

$$10 \cdot Log M_i + H_{1h} + O_i < T_{1h},$$

Equation 2

$$10 \cdot Log M_i - H_{1h} + O_i > T_{1h},$$

The variables in the formula are defined as follows:

 M_i is the Timeslot ISCP of the currently evaluated cell i expressed in mW

 O_i is the cell individual offset of the currently evaluated cell i

 T_{1h} is the Threshold for event 1h

 H_{1h} is the hysteresis parameter for the event 1h.

Before any evaluation is done, the Timeslot ISCP expressed in mW is filtered according to subclause 8.6.7.2.




Figure 14.1.3.2-1: An ISCP value of a timeslot drops below an absolute threshold

14.1.3.3 Reporting event 1I: Timeslot ISCP above a certain threshold (TDD)

When event 1i is configured in the UE, the UE shall:

1> if equation 1 is fulfilled for a time period indicated by "Time to trigger" and if that P-CCPCH is not included in the IE "cells triggered" in the variable TRIGGERED_1I_EVENT:

2> include that P-CCPCH in the IE "cells triggered" in the variable TRIGGERED_1I_EVENT;

2> send a measurement report with the IEs set as below:

3> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1i" and in "cell measurement event results" to the "Cell parameters ID" of the P-CCPCH that triggered the report;

3> include in "measured results" the "Timeslot ISCP" of those cells that are included in the variable TRIGGERED_1I_EVENT and "additional measured results" according to 8.4.2, not taking into account the cell individual offset for each cell.

1> if a primary CCPCH is included in the "cells triggered" in the variable TRIGGERED_1I_EVENT:

2> if Equation 2 below is fulfilled for a primary CCPCH:

3> if a primary CCPCH is included in the "cells triggered" in the variable TRIGGERED_1I_EVENT:

4> remove the entry of that primary CCPCH from "cells triggered" in the variable TRIGGERED_1I_EVENT.

The UE shall use the equation below for evaluation of reporting event 1i:

Equation 1

$$10 \cdot Log M_i - H_{1i} + O_i > T_{1h},$$

Equation 2

$$10 \cdot Log M_i + H_{1i} + O_i < T_{1h},$$

The variables in the formula are defined as follows:

 M_i is the Timeslot ISCP of the currently evaluated cell *i* expressed in mW

 O_i is the cell individual offset of the currently evaluated cell i

 T_{1i} is the Threshold for event 1i

 H_{li} is the hysteresis parameter for the event 1i.

Before any evaluation is done, the Timeslot ISCP expressed in mW is filtered according to subclause 8.6.7.2.




Figure 14.1.3.3-1: An ISCP value of a timeslot exceeds a certain threshold

14.1.4 Event-triggered periodic intra-frequency measurement reports (informative)

14.1.4.1 Cell addition failure (FDD only)




Figure 14.1.4.1-1: Periodic reporting triggered by event 1A

When a cell enters the reporting range and triggers event 1A, the UE shall transmit a MEASUREMENT REPORT to the UTRAN and typically this may result in an update of the active set. However, in some situations the UTRAN may be unable to add a strong cell to the active set typically due to capacity shortage for example.

The UE shall continue reporting after the initial report by reverting to periodical measurement reporting if the reported cell is not added to the active set. This is illustrated in Figure 14.1.4.1-1. During periodic reporting the UE shall transmit MEASUREMENT REPORT messages to the UTRAN at predefined intervals. The reports shall include reporting information of the cells in the current active set and of the monitored cell(s) in the reporting range.

Event-triggered periodic measurement reporting shall be terminated if:

- 1> there are no longer any monitored cell(s) within the reporting range; or
- 1> the UTRAN has added cells to the active set so that it includes the maximum number of cells (defined by the **reporting deactivation threshold** parameter), which are allowed for event 1A to be triggered; or
- 1> the UE has sent the maximum number of MEASUREMENT REPORT messages (defined by the **amount of reporting** parameter).

The reporting period is assigned by the UTRAN (with the **Reporting interval** parameter). If the reporting interval is set to zero event-triggered periodic measurement reporting shall not be applied.

14.1.4.1a Cell removal failure (FDD only)




Figure 14.1.4.1a: Periodic reporting triggered by event 1B

When a cell enters the removal range and triggers event 1B, the UE shall transmit a MEASUREMENT REPORT to the UTRAN and typically this may result in the removal of the weakest active cell. If the UTRAN is unable to receive MEASUREMENT REPORT after the maximum retransmission, it is beneficial to receive continuous reports in this case as well.

The UE shall revert to periodical measurement reporting if the UTRAN does not update the active set after the transmission of the measurement report. This is illustrated in Figure 14.1.4.1a. During periodic reporting the UE shall transmit MEASUREMENT REPORT messages to the UTRAN at predefined intervals.

Event-triggered periodic measurement reporting shall be terminated if:

- 1> there are no longer any monitored cell(s) within the removal range; or
- 1> the UTRAN has removed cells from the active set so that there are no longer the minimum amount of active cells for event 1B to be triggered; or
- 1> the UE has sent the maximum number of MEASUREMENT REPORT messages (defined by the "amount of reporting" parameter).

The reporting period is assigned by the UTRAN (with the "Reporting interval" parameter). If the reporting interval is set to zero, event-triggered periodic measurement reporting shall not be applied.

14.1.4.2 Cell replacement failure (FDD only)




Figure 14.1.4.1-2: Periodic reporting triggered by event 1C

When a cell enters the replacement range and triggers event 1C, the UE shall transmit a MEASUREMENT REPORT to the UTRAN and typically this may result in the replacement of the weakest active cell. If the UTRAN is unable to replace the cell due to for example capacity shortage, it is beneficial to receive continuous reports in this case as well.

The UE shall revert to periodical measurement reporting if the UTRAN does not update the active set after the transmission of the measurement report. This is illustrated in Figure 14.1.4.1-2. During periodic reporting the UE shall transmit MEASUREMENT REPORT messages to the UTRAN at predefined intervals. The reports shall include reporting information of the cells in the current active set and of the monitored cell(s) in the replacement range.

Event-triggered periodic measurement reporting shall be terminated if:

- 1> there are no longer any monitored cell(s) within the replacement range; or
- 1> the UTRAN has removed cells from the active set so that there are no longer the minimum amount of active cells for event 1C to be triggered (as defined by the **replacement activation threshold** parameter); or
- 1> the UE has sent the maximum number of MEASUREMENT REPORT messages (defined by the **amount of reporting** parameter).

The reporting period is assigned by the UTRAN (with the **Reporting interval** parameter). If the reporting interval is set to zero, event-triggered periodic measurement reporting shall not be applied.

14.1.5 Mechanisms available for modifying intra-frequency measurement reporting behaviour (informative)

14.1.5.1 Hysteresis

To limit the amount of event-triggered reports, a hysteresis parameter may be connected with each reporting event given above. The value of the hysteresis is given to the UE in the Reporting criteria field of the Measurement Control message.

In the example in Figure 14.1.5.1-1, the hysteresis ensures that the event 1D (FDD) or IG(TDD) (primary CPICH(FDD)/CCPCH(TDD) 2 becomes the best cell) is not reported until the difference is equal to the hysteresis value. The fact that primary CPICH(FDD)/CCPCH(TDD) 1 becomes best afterwards is not reported at all in the example since the primary CPICH(FDD)/CCPCH(TDD) 1 does not become sufficiently better than the primary CPICH(FDD)/CCPCH(TDD) 2.




Figure 14.1.5.1-1: Hysteresis limits the amount of measurement reports

14.1.5.2 Time-to-trigger

To limit the measurement signalling load, a time-to-trigger parameter could be connected with each reporting event given above. The value of the time-to-trigger is given to the UE in the Reporting criteria field of the Measurement Control message.

The effect of the time-to-trigger is that the report is triggered only after the conditions for the event have existed for the specified time-to-trigger. In the following FDD example in Figure 14.1.5.2-1, the use of time-to-trigger means that the event (primary CPICH 3 enters the reporting range) is not reported until is has been within the range for the time given by the time-to-trigger parameter.




Figure 14.1.5.2-1: Time-to-trigger limits the amount of measurement reports

In the following TDD example in Figure 14.1.5.2-2, the use of time-to-trigger means that the event (Timeslot ISCP upon certain threshold) is not reported until it has been upon the threshold for the time given by the time-to trigger parameter.




Figure 14.1.5.2-2: Time-to-trigger limits the amount of measurement reports

NOTE: The time-to-trigger could be combined with hysteresis, i.e. a hysteresis value is added to the measurement quantity before evaluating if the time-to-trigger timer should be started.

14.1.5.3 Cell individual offsets

For each cell that is monitored, an offset can be assigned with inband signalling. The offset can be either positive or negative. The offset is added to the measurement quantity before the UE evaluates if an event has occurred. The UE receives the cell individual offsets for each primary CPICH(FDD)/CCPCH(TDD) in the IE "Cell individual offset" included in the IE "Cell info" associated with each measurement object included in the MEASUREMENT CONTROL message.

For the FDD example, in Figure 14.1.5.3-1, since an offset is added to primary CPICH 3, it is the dotted curve that is used to evaluate if an event occurs. Hence, this means that measurement reports from UE to UTRAN are triggered when primary CPICH plus the corresponding offset, i.e. the dotted curve, leaves and enters the reporting range and when it gets better than primary CPICH 1 (if these events have been ordered by UTRAN). This offset mechanism provides the network with an efficient tool to change the reporting of an individual primary CPICH.

By applying a positive offset, as in Figure 14.1.5.3-1, the UE will send measurement reports as if the primary CPICH is offset *x* dB better than what it really is. This could be useful if the operator knows that a specific cell is interesting to monitor more carefully, even though it is not so good for the moment. In the example in Figure 14.1.5.3-1, the operator might know by experience that in this area primary CPICH 3 can become good very quickly (e.g. due to street corners) and therefore that it is worth reporting more intensively. Depending on the implemented handover evaluation algorithm, this may result in the cell with primary CPICH 3 being included in the active set earlier than would have been the case without the positive offset.




Figure 14.1.5.3-1: A positive offset is applied to primary CPICH 3 before event evaluation in the UE

For the TDD example, in Figure 14.1.5.3-2, an offset is added to primary CCPCH2, it is the dotted curve that is used to evaluate if the primary CCPCH2 becomes better than primary CCPCH1 (ordered by the UTRAN).




Figure 14.1.5.3-2: A positive offset is applied to primary CCPCH 2

Correspondingly, the operator can choose to apply a negative offset to a primary CCPCH. Then the reporting on that primary CCPCH is limited and the corresponding cell may be, at least temporarily excluded from the active set or as a target cell for handover.

It is important to note that the offset is added before triggering events, i.e. the offset is added by the UE before evaluating if a measurement report should be sent as opposed to offsets that are applied in the network and used for the actual handover evaluation. It should also be noted that the cell individual offset is not used in all measurement reporting events, and that it is not applied to all events in the same way.

14.1.5.4 Forbid a Primary CPICH to affect the reporting range (FDD only)

The reporting range affects the reporting events 1A and 1B presented above. The reporting range is defined as a function of all the Primary CPICHs in the active set (see 14.1.2.1 and 14.1.2.2). If the parameter W is set to 0, the reporting range is defined relative to the best Primary CPICH. However, there could be cases where it is good to forbid a specific Primary CPICH to affect the reporting range. For example in Figure 14.1.5.4-1 the network has requested the UE to not let Primary CPICH 3 affect the reporting range. This mechanism could be effective if the operator knows by experience that the quality of Primary CPICH 3 is very unstable in a specific area and therefore should not affect the reporting of the other Primary CPICHs.

The UE shall ignore that a Primary CPICH is forbidden to affect the reporting range if all of the following conditions are fulfilled:

- the Primary CPICH is included in active set; and
- all cells in active set are defined as Primary CPICHs forbidden to affect the reporting range.




Figure 14.1.5.4-1: Primary CPICH 3 is forbidden to affect the reporting range

14.1.6 Report quantities in intra-frequency measurements

The quantities that the UE shall report to UTRAN when the event is triggered for an intra-frequency measurement are given by the IE "Intra-frequency reporting quantity" stored for this measurement and can be the following:

- 1 SFN-SFN observed time difference
- 2 Cell synchronisation information
- 3 Cell Identity
- 4 Downlink E_c/N_0 (FDD).
- 5 Downlink path loss.

For FDD:

Pathloss in dB = Primary CPICH Tx power - CPICH RSCP.

- For Primary CPICH Tx power the IE "Primary CPICH Tx power" shall be used. The unit is dBm.
- CPICH RSCP is the result of the CPICH RSCP measurement. The unit is dBm.

For TDD:

Pathloss in dB = Primary CCPCH TX power - Primary CCPCH RSCP.

- For Primary CCPCH TX power the IE "Primary CCPCH TX Power" shall be used. The unit is dBm.
- Primary CCPCH RSCP is the result of the Primary CCPCH RSCP measurement. The unit is dBm.

If necessary Pathloss shall be rounded up to the next higher integer.

Results higher than 158 shall be reported as 158.

Results lower than 46 shall be reported as 46.

- 6 Downlink received signal code power (RSCP) after despreading (of a primary CPICH for FDD, and of a primary CCPCH for TDD).
- 7 ISCP measured on Timeslot basis. (TDD)

8 Proposed TGSN (TDD)

A description of those values can be found in [7] and [8].

14.2 Inter-frequency measurements

14.2.0a Inter-frequency measurement quantities

The two first measurement quantities listed below are used by the UE to evaluate whether an inter-frequency measurement event has occurred or not, through the computation of a frequency quality estimate. The quantity to use to compute the frequency quality estimate for an inter-frequency measurement is given in the "Inter-frequency measurement quantity" stored for that measurement. In the FDD case, all three measurement quantities can be used for the update of the virtual active set of the non-used frequencies as described in subclause 14.11.

- 1 Downlink Ec/No (FDD)
- 2 Downlink received signal code power (RSCP) after despreading.
- 3 Downlink path loss.

For FDD:

Pathloss in dB = Primary CPICH Tx power - CPICH RSCP.

- For Primary CPICH Tx power the IE "Primary CPICH Tx power" shall be used. The unit is dBm.
- CPICH RSCP is the result of the CPICH RSCP measurement. The unit is dBm.

For TDD:

Pathloss in dB = Primary CCPCH TX power - Primary CCPCH RSCP.

- For Primary CCPCH TX power the IE "Primary CCPCH TX Power" shall be used. The unit is dBm.
- Primary CCPCH RSCP is the result of the Primary CCPCH RSCP measurement. The unit is dBm.

A description of those values can be found in [7] and [8].

14.2.0b Frequency quality estimate

14.2.0b.1 FDD cells

The frequency quality estimate used in events 2a, 2b 2c, 2d, 2e and 2f is defined as:

$$Q_{frequencyj} = 10 \cdot Log M_{frequencyj} = W_{j} \cdot 10 \cdot Log \left(\sum_{i=1}^{N_{A,j}} M_{i,j} \right) + (1 - W_{j}) \cdot 10 \cdot Log M_{Best,j},$$

The variables in the formula are defined as follows ("the virtual active set on frequency j" should be understood as the active set if frequency j is the used frequency. If frequency j is a non-used frequency, the way the virtual active set is initiated and updated is described in subclause 14.11):

 $Q_{frequency i}$ is the estimated quality of the virtual active set on frequency j.

 $M_{\text{frequency }j}$ is the estimated quality of the virtual active set on frequency j.

M_{i i} is a measurement result of cell i in the virtual active set on frequency j.

 N_{Aj} is the number of cells in the virtual active set on frequency j.

 $M_{\text{Best } j}$ is the measurement result of the cell in the virtual active set on frequency j with the highest measurement result.

W_i is a parameter sent from UTRAN to UE and used for frequency j.

If the measurement result is CPICH-Ec/No then $M_{Frequency}$, M_{ij} and M_{Best} are expressed as ratios.

If the measurement result is CPICH-RSCP or PCCPCH-RSCP then $M_{Frequency}$, M_{ij} and M_{Best} are expressed in mW.

14.2.0b.2 TDD cells

$$Q_{i, frequency j} = 10 \cdot Log M_{i, frequency j} + O_{i, j}$$

 $Q_{i,frequencyj}$ is the estimated quality of cell i on frequency j.

 $M_{\text{frequency } j} \text{ is the measurement result for Primary CCPCH RSCP of cell } i \text{ on frequency } j \text{ expressed in } mW.$

 $O_{i,j}$ is the cell individual offset of the currently evaluated cell i on frequency j. O_{ij} is set by IE "Cell individual offset"

14.2.0c Inter-frequency reporting quantities

The quantities that the UE shall report for each cell to UTRAN when the event is triggered for an inter-frequency measurement is given by the "Inter-frequency reporting quantity" IE stored for this measurement and can be the following, from 1 to 8. The quantity number 9 can be reported for each frequency that triggered the report.

- 1 Cell identity
- 2 SFN-SFN observed time difference
- 3 Cell synchronisation information
- 4 Downlink Ec/No (FDD)
- 5 Downlink path loss.

For FDD:

Pathloss in dB = Primary CPICH Tx power - CPICH RSCP.

- For Primary CPICH Tx power the IE "Primary CPICH Tx power" shall be used. The unit is dBm.
- CPICH RSCP is the result of the CPICH RSCP measurement. The unit is dBm.

For TDD:

Pathloss in dB = Primary CCPCH TX power - Primary CCPCH RSCP.

- For Primary CCPCH TX power the IE "Primary CCPCH TX Power" shall be used. The unit is dBm.
- Primary CCPCH RSCP is the result of the Primary CCPCH RSCP measurement. The unit is dBm.

If necessary Pathloss shall be rounded up to the next higher integer.

Results higher than 158 shall be reported as 158.

Results lower than 46 shall be reported as 46.

- 6 Downlink received signal code power (RSCP) after despreading (of a primary CPICH for FDD, and of a primary CCPCH for TDD).
- 7 ISCP measured on Timeslot basis. (TDD)
- 8 Proposed TGSN (TDD)
- 9 UTRA carrier RSSI

A description of those values can be found in [7] and [8].

14.2.1 Inter-frequency reporting events

Within the measurement reporting criteria field in the MEASUREMENT CONTROL message UTRAN notifies the UE which events should trigger the UE to send a MEASUREMENT REPORT message. The listed events are the toolbox from which the UTRAN can choose the reporting events that are needed for the implemented handover evaluation function, or other radio network functions.

All events are evaluated with respect to one of the measurement quantities given in subclause 14.2.0a. The measurement quantities are measured on the monitored primary common pilot channels (CPICH) in FDD mode and the monitored primary common control channels (PCCPCH) in TDD mode of the cell defined in the measurement object. A "non-used frequency" is a frequency that the UE has been ordered to measure upon but is not used for the connection. A "used frequency" is a frequency that the UE has been ordered to measure upon and is also currently used for the connection.

The "monitored set on non-used frequency" consists of cells in "cells for measurement" (or all cells in CELL_INFO_LIST if "cells for measurement" is not present) that are not part of the virtual active set on that non-used frequency.

When one inter-frequency measurement identity corresponds to multiple inter-frequency events with identical event identities, the UE behaviour is not specified.

14.2.1.1 Event 2a: Change of best frequency.

When event 2a is configured in the UE within a measurement, the UE shall:

- 1> when the measurement is initiated or resumed:
 - 2> store the used frequency in the variable BEST_FREQUENCY_2A_EVENT.
- 1> if equation 1 below has been fulfilled for a time period indicated by "Time to trigger" for a frequency included for that event and which is not stored in the variable BEST_FREQUENCY_2A_EVENT:
 - 2> send a measurement report with IEs set as below:
- 3> set in "inter-frequency measurement event results":
 - 4> "inter-frequency event identity" to "2a"; and
 - 4> "Frequency info" to the frequency that triggered the event; and
 - 4> "Non frequency related measurement event results" to the "Primary CPICH info" of the best primary CPICH for FDD cells or "Primary CCPCH info" to the "Cells parameters ID" of the best primary CCPCH for TDD cells on that frequency, not taking into account the cell individual offset.
- 3> if a non-used frequency triggered the measurement report:
 - 4> include in IE "Inter-frequency measured results list" the measured results for the non-used frequency that triggered the event, not taking into account the cell individual offset.
- 3> if the used frequency triggered the measurement report:
 - 4> do not include the IE "Inter-frequency measured results list" in the measurement report.

3> set the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset;

2> update the variable BEST_FREQUENCY_2A_EVENT with that frequency.

Equation 1:

$$Q_{NotBest} \ge Q_{Best} + H_{2a}/2$$

The variables in the formula are defined as follows:

 $Q_{Not\ Best}$ is the quality estimate of a frequency not stored the "best frequency" in the variable BEST_FREQUENCY_2A_EVENT.

 Q_{Best} is the quality estimate of the frequency stored in "best frequency" in the variable BEST FREQUENCY_2A_EVENT.

 H_{2a} is the hysteresis parameter for the event 2a in that measurement.

14.2.1.2 Event 2b: The estimated quality of the currently used frequency is below a certain threshold **and** the estimated quality of a non-used frequency is above a certain threshold.

When an inter-frequency measurement configuring event 2b is set up, the UE shall:

- 1> create a variable TRIGGERED_2B_EVENT related to that measurement, which shall initially be empty;
- 1> delete this variable when the measurement is released.

When event 2b is configured in the UE within a measurement, the UE shall:

- 1> if equations 1 and 2 below have been fulfilled for a time period indicated by "Time to Trigger" from the same instant, respectively for one or several non-used frequencies included for that event and for the used frequency:
 - 2> if any of those non-used frequency is not stored in the variable TRIGGERED_2B_EVENT:

3> store the non-used frequencies that triggered the event and that were not previously stored in the variable TRIGGERED_2B_EVENT into that variable;

- 3> send a measurement report with IEs set as below:
 - 4> set in "inter-frequency measurement event results":
 - 5> "inter-frequency event identity" to "2b"; and
 - 5> for each non-used frequency that triggered the event, beginning with the best frequency:
 - 6> "Frequency info" to that non-used frequency; and
 - 6> "Non frequency related measurement event results" to the "Primary CPICH info" of the best primary CPICH for FDD cells or "Primary CCPCH info" to the "Cell parameters ID" of the best primary CCPCH for TDD cells on that non-used frequency, not taking into account the cell individual offset.
 - 4> include in IE "Inter-frequency measured results list" the measured results for each non-used frequency that triggered the event, not taking into account the cell individual offset;
 - 4> set the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset.
 - 1> if equation 3 below is fulfilled for a non-used frequency stored in the variable TRIGGERED_2B_EVENT:
 - 2> remove that non-used frequency from the variable TRIGGERED_2B_EVENT.
 - 1> if equation 4 below is fulfilled for the used frequency:
 - 2> clear the variable TRIGGERED_2B_EVENT.

Triggering conditions:

Equation 1:

$$Q_{Nonused} \ge T_{Nonused} + H_{2b}/2$$

The variables in the formula are defined as follows:

 $Q_{Non used}$ is the quality estimate of a non-used frequency that becomes better than an absolute threshold.

 $T_{Non used 2b}$ is the absolute threshold that applies for this non-used frequency in that measurement.

 H_{2b} is the hysteresis parameter for the event 2b.

Equation 2:

$$Q_{U_{SP}} \leq T_{U_{SP}} - H_{2h}/2$$

The variables in the formula are defined as follows:

 Q_{Used} is the quality estimate of the used frequency.

 $T_{Used\ 2b}$ is the absolute threshold that applies for the used frequency in that measurement.

 H_{2b} is the hysteresis parameter for the event 2b.

Leaving triggered state condition:

Equation 3:

$$Q_{Nonused} < T_{Nonused} - H_{2b}/2$$

The variables in the formula are defined as follows:

 $Q_{Non used}$ is the quality estimate of a non-used frequency that is stored in the variable TRIGGERED_2B_EVENT.

 $T_{Non used 2b}$ is the absolute threshold that applies for this non-used frequency in that measurement.

 H_{2b} is the hysteresis parameter for the event 2b.

Equation 4:

$$Q_{Used} > T_{Usedb} + H_{2b}/2$$

The variables in the formula are defined as follows:

 Q_{Used} is the quality estimate of the used frequency.

 $T_{Used\ 2b}$ is the absolute threshold that applies for the used frequency in that measurement.

 H_{2b} is the hysteresis parameter for the event 2b.

14.2.1.3 Event 2c: The estimated quality of a non-used frequency is above a certain threshold

When an inter-frequency measurement configuring event 2c is set up, the UE shall:

- 1> create a variable TRIGGERED_2C_EVENT related to that measurement, which shall initially be empty;
- 1> delete this variable when the measurement is released.

When event 2c is configured in the UE within a measurement, the UE shall:

- 1> if equation 1 below has been fulfilled for one or several non-used frequencies included for that event during the time "Time to trigger":
 - 2> if any of those non-used frequencies is not stored in the variable TRIGGERED_2C_EVENT:

3> store the non-used frequencies that triggered the event and that were not previously stored in the variable TRIGGERED_2C_EVENT into that variable;

3> send a measurement report with IEs set as below:

4> set in "inter-frequency measurement event results":

5> "inter-frequency event identity" to "2c"; and

- 5> for each non-used frequency that triggered the event, beginning with the best frequency:
 - 6> "Frequency info" to that non-used frequency; and
 - 6> "Non frequency related measurement event results" to the "Primary CPICH info" of the best primary CPICH for FDD cells or "Primary CCPCH info" to the "Cell parameters ID" of the best primary CCPCH for TDD cells on that non-used frequency, not taking into account the cell individual offset.
- 4> include in IE "Inter-frequency measured results list" the measured results for each non-used frequency that triggered the event, not taking into account the cell individual offset;
- 4> set the IE "additional measured results" according to subclause 8.4.2 not taking into account the cell individual offset.
- 1> if equation 2 below is fulfilled for a non-used frequency stored in the variable TRIGGERED_2C_EVENT:
 - 2> remove that non-used frequency from the variable TRIGGERED_2C_EVENT.

Triggering condition:

Equation 1:

$$Q_{Nonused} \ge T_{Nonused} + H_{2c}/2$$

The variables in the formula are defined as follows:

 $Q_{Non\ used}$ is the quality estimate of a non-used frequency that becomes better than an absolute threshold.

 $T_{Non used 2c}$ is the absolute threshold that applies for this non-used frequency in that measurement.

 H_{2c} is the hysteresis parameter for the event 2c.

Leaving triggered state condition:

Equation 2:

$$Q_{Nonused} < T_{Nonused} = -H_{2c}/2$$

The variables in the formula are defined as follows:

 $Q_{Non\ used}$ is the quality estimate of a non-used frequency stored in the variable TRIGGERED_2C_EVENT.

 $T_{Non\ used\ 2c}$ is the absolute threshold that applies for this non-used frequency in that measurement.

 H_{2c} is the hysteresis parameter for the event 2c.

14.2.1.4 Event 2d: The estimated quality of the currently used frequency is below a certain threshold

A UE shall be able to perform this measurement and the corresponding event reporting without requiring compressed mode.

When an inter-frequency measurement configuring event 2d is set up, the UE shall:

- 1> create a variable TRIGGERED_2D_EVENT related to that measurement, which shall initially be set to FALSE;
- 1> delete this variable when the measurement is released.

When event 2d is configured in the UE within a measurement, the UE shall:

- 1> if equation 1 below has been fulfilled for the used frequency during the time "Time to trigger":
 - 2> if the variable TRIGGERED_2D_EVENT is set to FALSE:
- 3> set the variable TRIGGERED_2D_EVENT to TRUE;

3> send a measurement report with IEs set as below:

- 4> set in "inter-frequency event results": "inter-frequency event identity" to "2d" and no IE "Inter-frequency cells", not taking into account the cell individual offset;
- 4> include in IE "Inter-frequency measured results list" the measured results for the used frequency, not taking into account the cell individual offset;
- 4> set the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset.
- 1> if the variable TRIGGERED 2D EVENT is set to TRUE and if equation 2 is fulfilled for the used frequency:
 - 2> set the variable TRIGGERED_2D_EVENT to FALSE.

Triggering condition:

Equation 1:

$$Q_{Used} \leq T_{Usedd} - H_{2d}/2$$

The variables in the formula are defined as follows:

 Q_{Used} is the quality estimate of the used frequency.

 $T_{Used\ 2d}$ is the absolute threshold that applies for the used frequency and event 2d.

 H_{2d} is the hysteresis parameter for the event 2d.

Leaving triggered state condition:

Equation 2:

$$Q_{lsed} > T_{llsedd} + H_{2d}/2$$

The variables in the formula are defined as follows:

 Q_{Used} is the quality estimate of the used frequency.

 $T_{Used\ 2d}$ is the absolute threshold that applies for the used frequency and event 2d.

 H_{2d} is the hysteresis parameter for the event 2d.

14.2.1.5 Event 2e: The estimated quality of a non-used frequency is below a certain threshold

When an inter-frequency measurement configuring event 2e is set up, the UE shall:

- 1> create a variable TRIGGERED_2E_EVENT related to that measurement, which shall initially be empty;
- 1> delete this variable when the measurement is released.

When event 2e is configured in the UE within a measurement, the UE shall:

- 1> if equation 1 below has been fulfilled for one or several non-used frequencies included for that event during the time "Time to trigger":
 - 2> if any of those non-used frequencies is not stored in the variable TRIGGERED_2E_EVENT:
- 3> store the non-used frequencies that triggered the event and that were not previously stored in the variable TRIGGERED_2E_EVENT into that variable;
- 3> send a measurement report with IEs set as below:
 - 4> set in "inter-frequency measurement event results":

- 5> "inter-frequency event identity" to "2e"; and
- 5> for each non-used frequency that triggered the event, beginning with the best frequency:
 - 6> "Frequency info" to that non-used frequency; and
 - 6> "Non frequency related measurement event results" to the "Primary CPICH info" of the best primary CPICH for FDD cells or "Primary CCPCH info" to the "Cell parameters ID" of the best primary CCPCH for TDD cells on that non-used frequency, not taking into account the cell individual offset.
 - 4> include in the IE "Inter-frequency measured results list" the measured results for each non-used frequency that triggered the event, not taking into account the cell individual offset;
- 4> set the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset.
- 1> if equation 2 below is fulfilled for a non-used frequency stored in the variable TRIGGERED_2E_EVENT:
 - 2> remove that non-used frequency from the variable TRIGGERED_2E_EVENT.

Triggering condition:

Equation 1:

$$Q_{Nonused} \leq T_{NonusedDe} - H_{2e}/2$$

The variables in the formula are defined as follows:

 $Q_{Non used}$ is the quality estimate of a non-used frequency that becomes worse than an absolute threshold.

 $T_{Non \, used \, 2e}$ is the absolute threshold that applies for that non-used frequency for that event.

 H_{2e} is the hysteresis parameter for the event 2e.

Leaving triggered state condition:

Equation 2:

$$Q_{Nonused} > T_{Nonused} + H_{2e}/2$$

The variables in the formula are defined as follows:

Q_{Non used} is the quality estimate of a non-used frequency stored in the variable TRIGGERED_2E_EVENT.

 $T_{Non \, used \, 2e}$ is the absolute threshold that applies for that non-used frequency for that event.

 H_{2e} is the hysteresis parameter for the event 2e.

14.2.1.6 Event 2 f: The estimated quality of the currently used frequency is above a certain threshold

A UE shall be able to perform this measurement and the corresponding event reporting without requiring compressed mode.

When an inter-frequency measurement configuring event 2f is set up, the UE shall:

- 1> create a variable TRIGGERED_2F_EVENT related to that measurement, which shall initially be set to FALSE;
- 1> delete this variable when the measurement is released.

When event 2f is configured in the UE within a measurement, the UE shall:

- 1> if equation 1 below has been fulfilled for the used frequency during the time "Time to trigger":
 - 2> if the variable TRIGGERED_2F_EVENT is set to FALSE:

3> set the variable TRIGGERED_2F_EVENT to TRUE;

3> send a measurement report with IEs set as below:

- 4> set in "inter-frequency event results": "inter-frequency event identity" to "2f", and no IE "Inter-frequency cells";
- 4> include in IE "Inter-frequency measured results list" the measured results for the used frequency, not taking into account the cell individual offset;
- 4> set the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset.

1> if the variable TRIGGERED_2F_EVENT is set to TRUE and if equation 2 is fulfilled for the used frequency:

2> set the variable TRIGGERED_2F_EVENT to FALSE.

Triggering condition:

Equation 1:

$$Q_{Used} \ge T_{Used} + H_{2f}/2$$

The variables in the formula are defined as follows:

 Q_{Used} is the quality estimate of the used frequency.

 $T_{Used\ 2f}$ is the absolute threshold that applies for the used frequency and event 2f.

 H_{2f} is the hysteresis parameter for the event 2f.

Leaving triggered state condition:

Equation 2:

$$Q_{Used} < T_{Used2f} - H_{2f}/2$$

The variables in the formula are defined as follows:

 Q_{Used} is the quality estimate of the used frequency.

 $T_{Used\ 2f}$ is the absolute threshold that applies for the used frequency and event 2f.

 H_{2f} is the hysteresis parameter for the event 2f.

14.3 Inter-RAT measurements

14.3.0a Inter-RAT measurement quantities

A measurement quantity is used by the UE to evaluate whether an inter-RAT measurement event has occurred or not.

The measurement quantity for UTRAN is used to compute the frequency quality estimate for the active set, as described in the next subclause, and can be:

- 1 Downlink Ec/No.
- 2 Downlink received signal code power (RSCP) after despreading.

The measurement quantity for GSM can be:

1 GSM Carrier RSSI

A description of those values can be found in [7] and [8].

14.3.0b Frequency quality estimate of the UTRAN frequency

The estimated quality of the active set in UTRAN in event 3a is defined as:

$$Q_{UTRAN} = 10 \cdot LogM_{UTRAN} = W \cdot 10 \cdot Log\left(\sum_{i=1}^{N_A} M_i\right) + (1 - W) \cdot 10 \cdot LogM_{Best},$$

The variables in the formula are defined as follows:

 Q_{UTRAN} is the estimated quality of the active set on the currently used UTRAN frequency.

M_{UTRAN} is the estimated quality of the active set on currently used UTRAN frequency expressed in another unit.

 M_i is the measurement result of cell i in the active set, according to what is indicated in the IE "Measurement quantity for UTRAN quality estimate".

N_A is the number of cells in the active set.

M_{Best} is the measurement result of the cell in the active set with the highest measurement result.

W is a parameter sent from UTRAN to UE.

If the measurement result is CPICH-Ec/No M_{UTRAN} , M_i and M_{Best} are expressed as ratios.

If the measurement result is CPICH-RSCP or PCCPCH-RSCP, M_{UTRAN} , M_i and M_{Best} are expressed in mW.

14.3.0c Inter-RAT reporting quantities

The quantities that the UE shall report to UTRAN when the event is triggered for an inter-RAT measurement are given by the IE "Inter-RAT reporting quantity" stored for that measurement, and can be the following:

In the case the other RAT is GSM:

- 1 Observed time difference to the GSM cell
 - The reference cell in the UTRAN is one of the cells in the active set.
- 2 GSM carrier RSSI

A description of those values can be found in [7] and [8].

14.3.1 Inter-RAT reporting events

Within the measurement reporting criteria field in the MEASUREMENT CONTROL message the UTRAN notifies the UE which events should trigger the UE to send a MEASUREMENT REPORT message. The listed events are the toolbox from which the UTRAN can choose the reporting events that are needed for the implemented handover evaluation function, or other radio network functions.

All events are measured with respect to one of the measurement quantities given in subclause 14.3.0a, and of the frequency quality estimate given in subclause 14.3.0b. For UTRAN the measurement quantities are measured on the monitored primary common pilot channels (CPICH) in FDD mode and the monitored primary common control channels (PCCPCH) in TDD mode of the cell defined in the measurement object. For other RATs the measurement quantities are system-specific. A "used UTRAN frequency" is a frequency that the UE have been ordered to measure upon and is also currently used for the connection to UTRAN. "Other system" is e.g. GSM.

In the text below describing the events:

- "The BCCH ARFCN and BSIC combinations considered in that inter-RAT measurement" shall be understood as the BCCH ARFCN and BSIC combinations of the inter-RAT cells pointed at in the IE "Cells for measurement" if it has been received for that inter-RAT measurement, or otherwise of the cells included in the "inter-RAT cell info" part of the variable CELL_INFO LIST.

"The BCCH ARFCNs considered in that inter-RAT measurement" shall be understood as the BCCH ARFCNs of the inter-RAT cells pointed at in the IE "Cells for measurement" if it has been received for that inter-RAT measurement, or otherwise of the cells included in the "inter-RAT cell info" part of the variable CELL_INFO LIST

When one inter-RAT measurement identity corresponds to multiple inter-RAT events with identical event identities, the UE behaviour is not specified.

14.3.1.1 Event 3a: The estimated quality of the currently used UTRAN frequency is below a certain threshold **and** the estimated quality of the other system is above a certain threshold.

When an inter-RAT measurement configuring event 3a is set up, the UE shall:

- 1> create a variable TRIGGERED_3A_EVENT related to that measurement, which shall initially be empty;
- 1> delete this variable when the measurement is released.

When event 3a is configured in the UE within a measurement, the UE shall:

- 1> if the other RAT is GSM, and if IE "BSIC verification required" is set to "required":
 - 2> if equations 1 and 2 below have both been fulfilled for a time period indicated by "Time to trigger" from the same instant, respectively for the used UTRAN frequency and for one or several GSM cells that match any of the BCCH ARFCN and BSIC combinations considered in that inter-RAT measurement:
- 3> if the Inter-RAT cell id of any of those GSM cells is not stored in the variable TRIGGERED_3A_EVENT:
 - 4> store the Inter-RAT cell ids of the GSM cells that triggered the event and that were not previously stored in the variable TRIGGERED_3A_EVENT into that variable.
 - 4> send a measurement report with IEs set as below:
 - 5> in "inter-RAT measurement event result": "inter-RAT event identity" to "3a", "CHOICE BSIC" to "verified BSIC" and "Inter-RAT cell id" to the GSM cells that triggered the event (best one first), taking into account the cell individual offset of the GSM cells;
 - 5> "measured results" and possible "additional measured results" according to subclause 8.6.7.5 and 8.4.2, respectively, not taking into account the cell individual offset.
 - 2> if equation 4 is fulfilled for a GSM cell whose inter-RAT cell id is stored in the variable TRIGGERED_3A_EVENT:
- 3> remove the inter-RAT cell id of that GSM cell from the variable TRIGGERED_3A_EVENT.
 - 2> if equation 3 is fulfilled for the used frequency in UTRAN:
- 3> clear the variable TRIGGERED 3A EVENT.
 - 1> if the other RAT is GSM, and if IE "BSIC verification required" is set to "not required":
 - 2> if equations 1 and 2 below have been fulfilled for a time period indicated by "Time to trigger" from the same instant, respectively for the used UTRAN frequency and for one or several BCCH ARFCNs considered in that inter-RAT measurement:
- 3> if any of those BCCH ARFCNs is not stored into the variable TRIGGERED_3A_EVENT:
 - 4> store the BCCH ARFCNs that triggered the event and that were not previously stored in the variable TRIGGERED_3A_EVENT into that variable;
 - 4> send a measurement report with IEs set as below:
 - 5> in "inter-RAT measurement event result": "inter-RAT event identity" to "3a", "CHOICE BSIC" to "non verified BSIC" and "BCCH ARFCN" to BCCH ARFCNs that triggered the event (best one first), taking into account the cell individual offset of the GSM cells;

5> "measured results" and possible "additional measured results" according to subclause 8.6.7.5 and 8.4.2, respectively, not taking into account the cell individual offset.

2> if equation 4 is fulfilled for a BCCH ARFCN that is stored in the variable TRIGGERED_3A_EVENT:

3> remove that BCCH ARFCN from the variable TRIGGERED_3A_EVENT.

2> if equation 3 is fulfilled for the used frequency in UTRAN:

3> clear the variable TRIGGERED_3A_EVENT.

Triggering conditions:

Equation 1:

$$Q_{Used} \leq T_{Used} - H_{3a}/2$$

The variables in the formula are defined as follows:

 Q_{Used} is the quality estimate of the used UTRAN frequency.

 T_{Used} is the absolute threshold that applies for the used frequency in that measurement.

 H_{3a} is the hysteresis parameter for event 3a.

Equation 2:

$$M_{OtherRAT} + CIQ_{theRAT} \ge T_{OtherRAT} + H_{3a}/2$$

The variables in the formula are defined as follows:

 $M_{Other\,RAT}$ is the measurement quantity for the cell of the other system.

CIO_{Other RAT} is the cell individual offset for the cell of the other system.

 $T_{Other\ RAT}$ is the absolute threshold that applies for the other system in that measurement.

 H_{3a} is the hysteresis parameter for event 3a.

Leaving triggered state conditions:

Equation 3:

$$Q_{Isod} > T_{IIsod} + H_{3a}/2$$

The variables in the formula are defined as follows:

 Q_{Used} is the quality estimate of the used UTRAN frequency.

 T_{Used} is the absolute threshold that applies for the used frequency in that measurement.

 H_{3a} is the hysteresis parameter for event 3a.

Equation 4:

$$M_{OtherRAT} + CIQ_{theRAT} < T_{OtherRAT} - H_{3a}/2$$

The variables in the formula are defined as follows:

 $M_{Other\,RAT}$ is the measurement quantity for the cell of the other system. $M_{Other\,RAT}$ is expressed in dBm.

CIO_{Other RAT} is the cell individual offset for the cell of the other system.

 $T_{Other\,RAT}$ is the absolute threshold that applies for the other system in that measurement.

 H_{3a} is the hysteresis parameter for event 3a.

14.3.1.2 Event 3b: The estimated quality of other system is below a certain threshold

When an inter-RAT measurement configuring event 3b is set up, the UE shall:

- 1> create a variable TRIGGERED_3B_EVENT related to that measurement, which shall initially be empty;
- 1> delete this variable when the measurement is released.

When event 3b is configured in the UE within a measurement, the UE shall:

- 1> if the other RAT is GSM, and if IE "BSIC verification required" is set to "required":
 - 2> if equation 1 below has been fulfilled for a time period indicated by "time to trigger" for one or several GSM cells that match any of the BCCH ARFCN and BSIC combinations considered in that inter-RAT measurement:
- 3> if the inter-RAT cell id of any of those GSM cell is not stored in the variable TRIGGERED_3B_EVENT:
 - 4> store the inter-RAT cell ids of the GSM cells that triggered the event and that were not previously stored in the variable TRIGGERED_3B_EVENT into that variable;
 - 4> send a measurement report with IEs set as below:
 - 5> set in "inter-RAT measurement event result": "inter-RAT event identity" to "3b", "CHOICE BSIC" to "verified BSIC" and "Inter-RAT cell id" to the GSM cells that triggered the event (worst one first), taking into account the cell individual offset of the GSM cells;
 - 5> set the IE "measured results" and the IE "additional measured results" according to subclause 8.6.7.5 and 8.4.2, respectively, not taking into account the cell individual offset.
 - 2> if equation 2 below is fulfilled for a GSM cell whose inter-RAT cell id is stored in the variable TRIGGERED_3B_EVENT:
- 3> remove the inter-RAT cell id of that GSM cell from the variable TRIGGERED 3B EVENT.
 - 1> if the other RAT is GSM, and if IE "BSIC verification required" is set to "not required":
 - 2> if equation 1 below has been fulfilled for a time period indicated by "time to trigger" for one or several of the BCCH ARFCNs considered in that inter-RAT measurement:
- 3> if any of those BCCH ARFCN is not stored into the variable TRIGGERED_3B_EVENT:
 - 4> store the BCCH ARFCNs that triggered the event and that were not previously stored in the variable TRIGGERED_3B_EVENT into that variable;
 - 4> send a measurement report with IEs set as below:
 - 5> set in "inter-RAT measurement event result": "inter-RAT event identity" to "3b", "CHOICE BSIC" to "non verified BSIC" and "BCCH ARFCN" to BCCH ARFCNs that triggered the event (worst one first), taking into account the cell individual offset of the GSM cells;
 - 5> set the IE "measured results" and the IE "additional measured results" according to subclause 8.6.7.5 and 8.4.2, respectively, not taking into account the cell individual offset.
 - 2> if equation 2 below is fulfilled for a BCCH ARFCN that is stored in the variable TRIGGERED_3B_EVENT:
- 3> remove that BCCH ARFCN from the variable TRIGGERED_3B_EVENT.

Triggering condition:

Equation 1:

$$M_{OtherRAT} + CIQ_{therRAT} \leq T_{OtherRAT} - H_{3h}/2$$

The variables in the formula are defined as follows:

 $M_{Other\,RAT}$ is the measurement quantity for the cell of the other system.

CIO_{Other RAT} is the cell individual offset for the cell of the other system.

 $T_{Other\,RAT}$ is the absolute threshold that applies for the other system in that measurement.

 H_{3b} is the hysteresis parameter for event 3b.

Leaving triggered state condition:

Equation 2:

$$M_{OtherRAT} + CIQ_{therRAT} > T_{OtherRAT} + H_{3b}/2$$

The variables in the formula are defined as follows:

 $M_{Other\ RAT}$ is the measurement quantity for the cell of the other system. $M_{Other\ RAT}$ is expressed in dBm.

*CIO*_{Other RAT} is the cell individual offset for the cell of the other system.

 $T_{Other\ RAT}$ is the absolute threshold that applies for the other system in that measurement.

 H_{3b} is the hysteresis parameter for event 3b.

14.3.1.3 Event 3c: The estimated quality of other system is above a certain threshold

When an inter-RAT measurement configuring event 3c is set up, the UE shall:

- 1> create a variable TRIGGERED_3C_EVENT related to that measurement, which shall initially be empty;
- 1> delete this variable when the measurement is released.

When event 3c is configured in the UE within a measurement, the UE shall:

- 1> if the other RAT is GSM, and if IE "BSIC verification required" is set to "required":
 - 2> if equation 1 below has been fulfilled for a time period indicated by "time to trigger" for one or several GSM cells that match any of the BCCH ARFCN and BSIC combinations considered in that inter-RAT measurement:
- 3> if the inter-RAT cell id of any of those GSM cell is not stored in the variable TRIGGERED_3C_EVENT:
 - 4> store the Inter-RAT cell ids of the GSM cells that triggered the event and that were not previously stored in the variable TRIGGERED_3C_EVENT into that variable;
 - 4> send a measurement report with IEs set as below:
 - 5> set in "inter-RAT measurement event result": "inter-RAT event identity" to "3c", "CHOICE BSIC" to "verified BSIC" and "Inter-RAT cell id" to the GSM cells that triggered the event (best one first), taking into account the cell individual offset of the GSM cells;
 - 5> set the IE "measured results" and the IE "additional measured results" according to subclause 8.6.7.5 and 8.4.2, respectively, not taking into account the cell individual offset.
 - 2> if equation 2 below is fulfilled for a GSM cell whose inter-RAT cell id is stored in the variable TRIGGERED 3C EVENT:
- 3> remove the inter-RAT cell id of that GSM cell from the variable TRIGGERED_3C_EVENT.
 - 1> if the other RAT is GSM, and if IE "BSIC verification required" is set to "not required":
 - 2> if equation 1 below has been fulfilled for a time period indicated by "time to trigger" for one or several of the BCCH ARFCNs considered in that inter-RAT measurement:

- 3> if any of those BCCH ARFCN is not stored into the variable TRIGGERED_3C_EVENT:
 - 4> store the BCCH ARFCNs that triggered the event and that were not previously stored in the variable TRIGGERED_3C_EVENT into that variable;
 - 4> send a measurement report with IEs set as below:
 - 5> set in "inter-RAT measurement event result": "inter-RAT event identity" to "3c", "CHOICE BSIC" to "non verified BSIC" and "BCCH ARFCN" to BCCH ARFCNs that triggered the event (best one first), taking into account the cell individual offset of the GSM cells;
 - 5> set the IE "measured results" and the IE "additional measured results" according to subclause 8.6.7.5 and 8.4.2, respectively, not taking into account the cell individual offset.
 - 2> if equation 2 is fulfilled for a BCCH ARFCN that is stored in the variable TRIGGERED_3C_EVENT:
- 3> remove that BCCH ARFCN from the variable TRIGGERED_3C_EVENT.

Triggering condition:

Equation 1:

$$M_{Other\,RAT} + CIQ_{ther\,RAT} \ge T_{Other\,RAT} + H_{3c}/2$$

The variables in the formula are defined as follows:

 $M_{Other\ RAT}$ is the measurement quantity for the cell of the other system. $M_{Other\ RAT}$ is expressed in dBm.

CIO_{Other RAT} is the cell individual offset for the cell of the other system.

 $T_{Other\ RAT}$ is the absolute threshold that applies for the other system in that measurement.

 H_{3c} is the hysteresis parameter for event 3c.

Leaving triggered state condition:

Equation 2:

$$M_{OtherRAT} + CIQ_{therRAT} < T_{OtherRAT} - H_{\chi}/2$$

The variables in the formula are defined as follows:

 $M_{Other\,RAT}$ is the measurement quantity for the cell of the other system. $M_{Other\,RAT}$ is expressed in dBm.

CIO_{Other RAT} is the cell individual offset for the cell of the other system.

 $T_{Other\ RAT}$ is the absolute threshold that applies for the other system in that measurement.

 H_{3c} is the hysteresis parameter for event 3c.

14.3.1.4 Event 3d: Change of best cell in other system

When an inter-RAT measurement configuring event 3d is set up, the UE shall:

1> create a variable BEST_CELL_3D_EVENT related to that measurement;

1> delete this variable when the measurement is released.

When event 3d is configured in the UE within a measurement, the UE shall:

- 1> if the other RAT is GSM, and if IE "BSIC verification required" is set to "required":
 - 2> when the measurement is initiated or resumed:
- 3> store in the variable BEST_CELL_3D_EVENT the Inter-RAT cell id of the GSM cell that has the best measured quantity among the GSM cells that match any of the BCCH ARFCN and BSIC combinations considered in that inter-RAT measurement, not taking into account the cell individual offset of the GSM cells;
- 3> send a measurement report with IE set as below:
 - 4> set in "inter-RAT measurement event result": "inter-RAT event identity" to "3d", "CHOICE BSIC" to "verified BSIC" and "Inter-RAT cell id" to the GSM cell that is stored in the variable BEST_CELL_3D_EVENT;
 - 4> set the IE "measured results" and the IE "additional measured results" according to subclause 8.6.7.5 and 8.4.2, respectively, not taking into account the cell individual offset.
 - 2> if equation 1 has been fulfilled for a time period indicated by "time to trigger" for a GSM cell that is different from the one stored in BEST_CELL_3D_EVENT and that matches any of the BCCH ARFCN and BSIC combinations considered in that inter-RAT measurement:
- 3> store the Inter-RAT cell id of that GSM cell in the variable BEST_CELL_3D_EVENT;
- 3> send a measurement report with IEs set as below:
 - 4> set in "inter-RAT measurement event result": "inter-RAT event identity" to "3d", "CHOICE BSIC" to "verified BSIC" and "Inter-RAT cell id" to the GSM cell is now stored in BEST_CELL_3D_EVENT;
 - 4> set the IE "measured results" and the IE "additional measured results" according to subclause 8.6.7.5 and 8.4.2, respectively, not taking into account the cell individual offset.
 - 1> if the other RAT is GSM, and if IE "BSIC verification required" is set to "not required":
 - 2> when the measurement is initiated or resumed:
- 3> store in the variable BEST_CELL_3D_EVENT the BCCH ARFCN of the GSM cell that has the best measured quantity among the BCCH ARFCNs considered in that inter-RAT measurement;
- 3> send a measurement report with IE set as below:
 - 4> set in "inter-RAT measurement event result": "inter-RAT event identity" to "3d", "CHOICE BSIC" to "non verified BSIC" and "BCCH ARFCN" to the BCH ARFCN that is stored in the variable BEST CELL 3D EVENT;
 - 4> set the IE "measured results" and the IE "additional measured results" according to subclause 8.6.7.5 and 8.4.2, respectively, not taking into account the cell individual offset.
 - 2> if equation 1 below has been fulfilled for a time period indicated by "time to trigger" for one of the BCCH ARFCNs considered in that inter-RAT measurement and different from the one stored in BEST_CELL_3D_EVENT:
- 3> store the BCCH ARFCN of that GSM cell in the variable BEST_CELL_3D_EVENT;
- 3> send a measurement report with IEs set as below:
 - 4> set in "inter-RAT measurement event result": "inter-RAT event identity" to "3d", "CHOICE BSIC" to "non verified BSIC" and "BCCH ARFCN" to the BCCH ARFCN that is now stored in the variable BEST_CELL_3D_EVENT;
 - 4> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset.

Equation 1:

$$M_{N_{ew}} \ge M_{R_{est}} + H_{3J}/2$$

The variables in the formula are defined as follows:

 M_{New} is the measurement quantity for a GSM cell that is not stored in the variable BEST_CELL_3D_EVENT.

 M_{Best} is the measurement quantity for a GSM cell that is stored in the variable BEST_CELL_3D_EVENT.

 H_{3d} is the hysteresis parameter for event 3d.

14.3.2 GSM measurements in compressed mode

14.3.2.1 GSM RSSI measurements

The UE shall perform GSM RSSI measurements in the gaps of compressed mode pattern sequence specified for GSM RSSI measurement purpose. The UE cannot be required to measure "Observed time difference to GSM" in gaps specified for this purpose.

14.3.2.2 Initial BSIC identification

The UE shall perform Initial BSIC identification in compressed mode pattern sequence specified for Initial BSIC identification measurement purpose.

The parameter "N identify abort" in the IE "DPCH compressed mode info" indicates the maximum number of patterns that the UE shall use to attempt to decode the unknown BSIC of the GSM cell in the initial BSIC identification procedure.

The UE shall be able to measure the "Observed time difference to GSM cell" during a compressed mode pattern sequence configured for this purpose.

The BSIC identification procedure is defined in detail in [19].

14.3.2.3 BSIC re-confirmation

The UE shall perform BSIC re-confirmation in compressed mode pattern sequence specified for BSIC re-confirmation measurement purpose.

The parameter "T reconfirm abort" in the IE "DPCH compressed mode info" indicates the maximum time allowed for the re-confirmation of the BSIC of one GSM cell in the BSIC re-confirmation procedure.

The UE shall be able to measure the "Observed time difference to GSM cell" during a compressed mode pattern sequence configured for this purpose.

The BSIC re-confirmation procedure is defined in detail in [19].

14.4 Traffic Volume Measurements

14.4.1 Traffic Volume Measurement Quantity

Traffic volume measurements may be configured by RRC to assist with dynamic radio bearer control. The reported quantities that can be configured are:

- 1 Buffer Occupancy.
- 2 Average of Buffer Occupancy.
- 3 Variance of Buffer Occupancy.

A description of these values can be found in [15].

When a report is triggered, the UE shall provide the requested quantities for the acknowledged and unacknowledged mode RBs mapped onto the transport channels identified.

When the RLC buffer payload, Average of RLC buffer payload or Variance of RLC buffer payload is reported, the measured quantity shall be rounded upwards to the closest higher value possible to report.

14.4.2 Traffic Volume reporting triggers

Traffic volume measurement reports can be triggered using two different mechanisms, periodical and event triggered. The reporting criteria are specified in the measurement control message.

All the specified events are evaluated with respect to the Transport Channel Traffic Volume (TCTV). This quantity is equal to the sum of the Buffer Occupancy for all logical channels mapped onto a transport channel. The events on a given transport channel shall be evaluated at least at every TTI (may be more often) as described in [15].

When one traffic volume measurement identity corresponds to multiple traffic volume events with identical event identities for the same transport channel, the UE behaviour is not specified.

When a traffic volume measurement is set up, the UE shall:

- 1> if the IE "report criteria" is set to "Traffic volume measurement reporting criteria":
 - 2> for each IE "Parameters sent for each transport channel":
- 3> if the IE "Uplink transport channel type" is not included; or
- 3> if the IE "Uplink Transport Channel Type" has the value "DCH" or "USCH" and the IE "UL transport channel id" is not included:
 - 4> for each IE "Parameters required for each Event":
 - 5> for each uplink transport channel on which the UE is supposed to report (see below):
 - 6> configure an event trigger defined by the values in the IEs "Measurement Identity", "Traffic volume event identity", "Reporting threshold", "Time to trigger", "Pending time after trigger" and "Tx Interruption after trigger".

3> else:

- 4> for each IE "Parameters required for each Event":
 - 5> for the uplink transport channel defined by the IEs "Uplink transport channel type" and "UL transport channel id":
 - 6> configure an event trigger defined by the values in the IEs "Measurement Identity", "Traffic volume event identity", "Reporting threshold", "Time to trigger", "Pending time after trigger" and "Tx Interruption after trigger".

1> else:

- 2> if the IE "report criteria" is set to "Periodical reporting criteria":
- 2> configure periodical triggers with period equal to the value in the IE "Reporting Interval" and with number of transmissions equal to the value in the IE "Amount of reporting" for the measurement identified by the IE "Measurement Identity".

For each transport channel for which an event trigger has been configured, the UE shall:

- 1> for each event configured for this transport channel:
 - 2> if the TCTV is larger than the threshold in IE "Reporting threshold" at TVM setup or modify; or
 - 2> if the TCTV becomes larger than the threshold in IE "Reporting threshold" while the event is configured:
- 3> if the IE "Traffic volume event identity" has value "4a":

- 4> if the IE "Time to trigger" is not present; and
- 4> if the Pending-time-after-trigger timer for this event is not active:
 - 5> if the IE "Pending time after trigger" is included:
 - 6> start the Pending-time-after-trigger timer for this event with the value in this IE.
 - 5> trigger a report for the measurement identified by the IE "Measurement Identity".
- 4> else:
 - 5> start the Time-to-trigger timer for this event with the value in the IE "Time to trigger".
- 3> if the IE "Traffic volume event identity" has value "4b":
 - 4> if the Time-to-trigger timer for this event is active:
 - 5> stop this timer.
 - 2> if the TCTV is smaller than the threshold in IE "Reporting threshold" at TVM setup or modify; or
 - 2> if the TCTV becomes smaller than the threshold in IE "Reporting threshold" while the event is configured:
- 3> if the IE "Traffic volume event identity" has value "4a":
 - 4> if the Time-to-trigger timer for this event is active:
 - 5> stop this timer.
- 3> if the IE "Traffic volume event identity" has value "4b":
 - 4> if the IE "Time to trigger" is not present; and
 - 4> if the Pending-time-after-trigger timer for this event is not active:
 - 5> if the IE "Pending time after trigger" is included:
 - 6> start the Pending-time-after-trigger timer for this event with the value in this IE.
 - 5> trigger a report for the measurement identified by the IE "Measurement Identity".
 - 4> else:
 - 5> start the Time-to-trigger timer for this event with the value in the IE "Time to trigger".

When the Time-to-trigger timer for an event elapses:

- 1> if the Pending-time-after-trigger timer for this event is not active:
 - 2> trigger a report for the measurement identified by the IE "Measurement Identity" corresponding to this event;
 - 2> if the IE "Pending time after trigger" is included:
- 3> start the Pending-time-after-trigger timer for this event with the value in this IE.

When the Pending-time-after-trigger for an event elapses:

- 1> if the IE "Traffic volume event identity" has value "4a":
 - 2> if the TCTV is larger than the threshold in IE "Reporting threshold":
- 3> if the IE "Time to trigger" is not present:
 - 4> trigger a report for the measurement identified by the IE "Measurement Identity" corresponding to this event:
 - 4> start the Pending-time-after-trigger timer for this event with the value in the IE "Pending time after trigger".

3> else:

- 4> start the Time-to-trigger timer for this event with the value in the IE "Time to trigger".
- 1> if the IE "Traffic volume event identity" has value "4b":
 - 2> if the TCTV is smaller than the threshold in IE "Reporting threshold":
- 3> if the IE "Time to trigger" is not present:
 - 4> trigger a report for the measurement identified by the IE "Measurement Identity" corresponding to this event:
 - 4> start the Pending-time-after-trigger timer for this event with the value in the IE "Pending time after trigger".

3> else:

4> start the Time-to-trigger timer for this event with the value in the IE "Time to trigger".

When a periodical trigger elapses, the UE shall:

- 1> trigger a report for the measurement identified by the IE "Measurement Identity";
- 1> if the number of reports triggered by this periodical trigger reaches the value in the IE "Amount of reporting":
 - 2> disable this periodical trigger.

When a report is triggered for a given IE "Measurement Identity", the UE shall:

- 1> consider the variable MEASUREMENT_IDENTITY corresponding to this measurement identity;
- 1> if the report is triggered by an event trigger:
 - 2> include the IE "Event results";
 - 2> set the IE "Uplink transport channel type causing the event" to the type of the transport channel which triggered the report;
 - 2> if the transport channel type is "DCH" or "USCH":
- 3> include the IE "UL Transport Channel identity" and set it to the identity of the transport channel which triggered the report.
 - 2> else:
- 3> not include the IE "UL Transport Channel identity".
 - 2> set the IE "Traffic volume event identity" to the identity of the event that triggered the report;
 - 2> if the IE "Tx interruption after trigger" for the event that triggered the report is included:
- 3> if the UE is in CELL_FACH state:
 - 4> prohibit DTCH transmissions on the RACH;
 - 4> if the Tx interruption timer is not running; or
 - 4> if the Tx interruption timer is running and still has a value larger than the IE "Tx interruption after trigger" for the event, i.e. it was started earlier by another event with a larger value in IE "Tx interruption after trigger":
 - 5> start the Tx interruption timer with the value in the IE "Tx interruption after trigger" for this event.
 - 4> when it receives from the UTRAN a message causing the transition to CELL_DCH state; or
 - 4> when the Tx interruption timer elapses:

- 5> stop the timer;
- 5> resume these transmissions.
- 1> if the IE "Traffic volume measurement object" is not included:
 - 2> report on all the uplink transport channels as specified below.
- 1> if the IE "Traffic volume measurement object" is included:
 - 2> report on the uplink transport channels identified in this IE as specified below.
- 1> for each UM or AM RB mapped onto a transport channel on which the UE is expected to report:
 - 2> add an element in the IE "Traffic volume measurement results";
 - 2> set the value of the IE "RB Identity" to the identity of the considered radio bearer;
 - 2> if the RB is mapped onto one logical channel:
- 3> if the IE "RLC Buffer Payload for each RB" is set to TRUE:
 - 4> include the IE "RLC Buffers Payload" and set it to the Buffer Occupancy value for this logical channel, rounded up to the next allowed value.
- 3> if the IE "Average of RLC Buffer Payload for each RB" is set to TRUE:
 - 4> include and set the IE "Average of RLC Buffer Payload" to the Buffer Occupancy for this logical channel averaged over the interval specified in the IE "Time Interval to take an average or a variance" (see [15]), rounded up to the next allowed value.
- 3> if the IE "Variance of RLC Buffer Payload for each RB" is set to TRUE:
 - 4> include and set the IE "Variance of RLC Buffer Payload" to the variance of the Buffer Occupancy for this logical channel computed over the interval specified in the IE "Time Interval to take an average or a variance" (see [15]), rounded up to the next allowed value.
 - 2> if the RB is mapped onto two logical channels:
- 3> if one logical channel is mapped onto transport channels on which the UE is supposed to report:
 - 4> if the IE "RLC Buffer Payload for each RB" is set to TRUE:
 - 5> include and set the IE "RLC Buffers Payload" to the Buffer Occupancy value for this logical channel, rounded up to the next allowed value.
 - 4> if the IE "Average of RLC Buffer Payload for each RB" is set to TRUE:
 - 5> include and set the IE "Average of RLC Buffer Payload" to the Buffer Occupancy for this logical channel averaged over the interval specified in the IE "Time Interval to take an average or a variance" (see [15]), rounded up to the next allowed value.
 - 4> if the IE "Variance of RLC Buffer Payload for each RB" is set to TRUE:
 - 5> include and set the IE "Variance of RLC Buffer Payload" to the variance of the Buffer Occupancy for this logical channel computed over the interval specified in the IE "Time Interval to take an average or a variance" (see [15]), rounded up to the next allowed value.
- 3> if both logical channels are mapped onto transport channels on which the UE is supposed to report:
 - 4> if the IE "RLC Buffer Payload for each RB" is set to TRUE:
 - 5> include and set the IE "RLC Buffers Payload" to the sum of the Buffer Occupancy values for the two logical channels, rounded up to the next allowed value.
 - 4> if the IE "Average of RLC Buffer Payload for each RB" is set to TRUE:

- 5> include and set the IE "Average of RLC Buffer Payload" to the sum of the Buffer Occupancy for the two logical channels averaged over the interval specified in the IE "Time Interval to take an average or a variance" (see [15]) and rounded up to the next allowed value.
- 4> if the IE "Variance of RLC Buffer Payload for each RB" is set to TRUE:
 - 5> include and set the IE "Variance of RLC Buffer Payload" to the variance of the sum of the Buffer Occupancy for the two logical channels, computed over the interval specified in the IE "Time Interval to take an average or a variance" (see [15]) and rounded up to the next allowed value.

14.4.2.1 Reporting event 4 A: Transport Channel Traffic Volume becomes larger than an absolute threshold




Figure 14.4.2.1-1: Event triggered report when Transport Channel Traffic Volume becomes larger than a certain threshold

If the monitored Transport Channel Traffic Volume (TCTV) [15] is larger than an absolute threshold at TVM setup or modify, or is larger at activation of the monitored transport channel, or becomes larger than an absolute threshold while the event is configured i.e. if TCTV>Reporting threshold, this event could trigger a report. The event could be triggered again only if TCTV becomes smaller than the Reporting threshold and later TCTV>Reporting threshold is verified again.

14.4.2.2 Reporting event 4 B: Transport Channel Traffic Volume becomes smaller than an absolute threshold




Figure 14.4.2.1-2: Event triggered report when Transport Channel Traffic Volume becomes smaller than certain threshold

If the monitored Transport Channel Traffic Volume (TCTV) [15] is smaller than an absolute threshold at TVM setup or modify, or is smaller at activation of the monitored transport channel, or becomes smaller than an absolute threshold while the event is configured i.e. if TCTV<Reporting threshold, this event could trigger a report. The event could be triggered again only if TCTV becomes bigger than the Reporting threshold and later TCTV<Reporting threshold is verified again.

14.4.3 Traffic volume reporting mechanisms

Traffic volume measurement triggering could be associated with both a *time-to-trigger* and a *pending time after trigger*. The time-to-trigger is used to get time domain hysteresis, i.e. the condition must be fulfilled during the time-to-trigger time before a report is sent. Pending time after trigger is used to limit consecutive reports when one traffic volume measurement report already has been sent and enables periodic reporting while the TCTV remains above(4a) or below(4b) the threshold. This is described in detail below.

14.4.3.1 Pending time after trigger

This timer is started in the UE when a measurement report has been triggered by a given event. The UE is then forbidden to send new measurement reports triggered by the same event during this time period. Instead the UE waits until the timer has expired. If the Transport Channel Traffic Volume [15] is still above the threshold for event 4a, or below the threshold for event 4b when the timer expires, the UE sends a new measurement report, and the timer is restarted. Otherwise it waits for a new triggering.




Figure 14.4.3.1-1: Pending time after trigger limits the amount of consecutive measurement reports

Figure 14.4.3.1-1 shows that by increasing the pending time after trigger a triggered second event does not result in a measurement report. The figure assumes absence of the IE "Time to trigger".

14.4.3.2 Time-to-trigger

The timer is started in the UE when the Transport Channel Traffic Volume triggers the event. If the TCTV crosses the threshold before the timer expires, the timer is stopped. If the timer expires then a report is triggered.




Figure 14.4.3.1-2: Time-to-trigger is used to achieve time hysteresis

Figure 14.4.3.1-2 shows that by increasing the time-to-trigger the report is not triggered.

14.4.4 Interruption of user data transmission

By including the IE "Tx Interruption after trigger", a UE in CELL_FACH state may be instructed by the UTRAN to prohibit transmission of user data on the RACH temporarily after a measurement report has been triggered.

The UE shall only resume transmission of user data, when:

- 1> it receives from the UTRAN a message allocating a dedicated physical channel, leading to the transition to CELL_DCH state; or
- 1> the time period indicated by the IE "Tx Interruption after trigger" elapses.

The transmission on signalling radio bearers shall not be interrupted.

14.5 Quality Measurements

14.5.1 Quality reporting measurement quantities

For quality measurements, the following measurement quantities are used:

- 1. Downlink transport channel BLER
- 2. Timeslot SIR (TDD only)

14.5.2 Quality reporting events

When one measurement identity corresponds to multiple quality events for the same transport channel, the UE behaviour is not specified.

14.5.2.1 Reporting event 5A: A predefined number of bad CRCs is exceeded

When this event is ordered by UTRAN in a measurement control message, the UE shall send a measurement report when the amount of bad CRCs during a predefined sliding window exceeds a predefined number.

The following three parameters are used in the scheme:

- Total CRC = the length of the sliding window over which the number of bad CRCs are counted.

- **Bad CRC** = the number of bad CRC that is required within the latest "Total CRC" received CRCs for the event to be triggered.
- **Pending after trigger** = a new event can not be triggered until "Pending after trigger" CRCs have been received,

When a DCH is established, the UE shall begin to count the number of bad CRCs within the last "Total CRC" received CRCs. No event can be triggered until at least "Total CRC" CRCs have been received. For each new received CRC, the UE shall compare the number of bad CRCs within the latest "Total CRC" received CRCs with the parameter "Bad CRC". An event shall be triggered if the number of bad CRCs is equal or larger than "Bad CRC".

At the time when the event is triggered a pending time after trigger timer is started with the length of "Pending after trigger" CRCs. A new event can not be triggered until Pending after trigger" CRCs have been received. When Pending after trigger" CRCs have been received the event evaluation start again and a new event can be triggered.




Figure 14.5.2.1-1: Event triggered CRC error reporting

14.6 UE internal measurements

14.6.1 UE internal measurement quantities

For UE internal measurements the following measurement quantities exist:

- 1. UE transmission (Tx) power, for TDD measured on a timeslot basis.
- 2. UE received signal strength power (RSSI).
- 3. UE Rx-Tx time difference (FDD only).
- 4. T_{ADV} (1.28 Mcps TDD).

14.6.2 UE internal measurement reporting events

In the Measurement reporting criteria field in the Measurement Control messages, the UTRAN notifies the UE of which events should trigger a measurement report. UE internal measurement reporting events that can trigger a report are given below. The reporting events are marked with vertical arrows in the figures below. All events can be combined with time-to-trigger.

NOTE: The reporting events are numbered 6A, 6B, 6C,.. where 6 denotes that the event belongs to the type UE internal measurements.

When one measurement identity corresponds to multiple internal events with identical event identities, the UE behaviour is not defined.

14.6.2.1 Reporting event 6A: The UE Tx power becomes larger than an absolute threshold

When a UE internal measurement configuring event 6a is set up, the UE shall:

- 1> create a variable TRIGGERED_6A_EVENT related to that measurement, which shall initially be set to FALSE;
- 1> delete this variable when the measurement is released.

When this event is ordered by UTRAN in a measurement control message, the UE shall:

- 1> if the UE Tx power (for TDD within a single TS) is greater than the value in IE "UE Transmitted Power Tx power threshold" stored for this event in the variable MEASUREMENT_IDENTITY for a time period indicated by the IE "time_to_trigger":
 - 2> if the variable TRIGGERED_6A_EVENT is set to FALSE:
- 3> set the variable TRIGGERED_6A_EVENT to TRUE;
- 3> send a measurement report with IEs set as below:
 - 4> set in "UE internal measurement event results": "UE internal event identity" to "6a";
 - 4> set the IE "measured results" and the IE "additional measured results" according to 8.4.2.
 - 1> if the variable TRIGGERED_6A_EVENT is set to TRUE and if the UE Tx power (for TDD within a single TS) is less or equal the value in IE "UE Transmitted Power Tx power threshold" stored for this event in the variable MEASUREMENT_IDENTITY:
 - 2> set the variable TRIGGERED_6A_EVENT to FALSE.

14.6.2.2 Reporting event 6B: The UE Tx power becomes less than an absolute threshold

When a UE internal measurement configuring event 6b is set up, the UE shall:

- 1> create a variable TRIGGERED 6B EVENT related to that measurement, which shall initially be set to FALSE;
- 1> delete this variable when the measurement is released.

- 1> if the UE Tx power (for TDD within a single TS) is less than the value in IE "UE Transmitted Power Tx power threshold" stored for this event in the variable MEASUREMENT_IDENTITY for a time period indicated by the IE "time_to_trigger":
 - 2> if the variable TRIGGERED_6B_EVENT is set to FALSE:
- 3> set the variable TRIGGERED_6B_EVENT to TRUE;
- 3> send a measurement report with IEs set as below:
 - 4> set in "UE internal measurement event results": "UE internal event identity" to "6b";
 - 4> set the IE "measured results" and the IE "additional measured results" according to 8.4.2.
 - 1> if the variable TRIGGERED_6B_EVENT is set to TRUE and if the UE Tx power (for TDD within a single TS) is greater or equal the value in IE "UE Transmitted Power Tx power threshold" stored for this event in the variable MEASUREMENT_IDENTITY:
 - 2> set the variable TRIGGERED_6B_EVENT to FALSE.




Figure 14.6.2.2-1: Event-triggered measurement reports when the UE Tx power becomes larger or less than absolute thresholds

14.6.2.3 Reporting event 6C: The UE Tx power reaches its minimum value

When a UE internal measurement configuring event 6c is set up, the UE shall:

- 1> create a variable TRIGGERED_6C_EVENT related to that measurement, which shall initially be set to FALSE;
- 1> delete this variable when the measurement is released.

- 1> if the UE Tx power is equal its minimum value (for TDD its minimum value on a single TS) for a time period indicated by the IE "time_to_trigger":
 - 2> if the variable TRIGGERED 6C EVENT is set to FALSE:
- 3> set the variable TRIGGERED_6C_EVENT to TRUE;
- 3> send a measurement report with IEs set as below:
 - 4> set in "UE internal measurement event results": "UE internal event identity" to "6c";
 - 4> set the IE "measured results" and the IE "additional measured results" according to 8.4.2.
 - 1> if the variable TRIGGERED_6C_EVENT is set to TRUE and if the UE Tx power is greater than its minimum value:
 - 2> set the variable TRIGGERED_6C_EVENT to FALSE.




Figure 14.6.2.3-1: Event-triggered measurement report when the UE Tx power reaches its minimum value

14.6.2.4 Reporting event 6D: The UE Tx power reaches its maximum value

When a UE internal measurement configuring event 6d is set up, the UE shall:

- 1> create a variable TRIGGERED_6D_EVENT related to that measurement, which shall initially be set to FALSE;
- 1> delete this variable when the measurement is released.

When this event is ordered by UTRAN in a measurement control message, the UE shall:

- 1> if the UE Tx power equals the maximum UE TX power (for TDD its maximum value on a single TS) for a time period indicated by the IE "time_to_trigger":
 - 2> if the variable TRIGGERED_6D_EVENT is set to FALSE:
- 3> set the variable TRIGGERED_6D_EVENT to TRUE;
- 3> send a measurement report with IEs set as below:
 - 4> set in "UE internal measurement event results": "UE internal event identity" to "6d";
 - 4> set the IE "measured results" and the IE "additional measured results" according to 8.4.2.
 - 1> if the variable TRIGGERED_6D_EVENT is set to TRUE and if the UE Tx power is less than the maximum UE TX power:
 - 2> set the variable TRIGGERED_6D_EVENT to FALSE.

NOTE: The maximum UE TX power is defined in subclause 8.6.6.8.




Figure 14.6.2.4-1: Event-triggered report when the UE Tx power reaches its maximum value

14.6.2.5 Reporting event 6E: The UE RSSI reaches the UE's dynamic receiver range

When a UE internal measurement configuring event 6e is set up, the UE shall:

- 1> create a variable TRIGGERED_6E_EVENT related to that measurement, which shall initially be set to FALSE;
- 1> delete this variable when the measurement is released.

When this event is ordered by UTRAN in a measurement control message, the UE shall:

- 1> if the UE RSSI is greater or equal the UE's dynamic receiver range for a time period indicated by the IE "time_to_trigger":
 - 2> if the variable TRIGGERED_6E_EVENT is set to FALSE:
- 3> set the variable TRIGGERED_6E_EVENT to TRUE;
- 3> send a measurement report with IEs set as below:
 - 4> set in "UE internal measurement event results": "UE internal event identity" to "6e";
 - 4> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2.
 - 1> if the variable TRIGGERED_6E_EVENT is set to TRUE and if the UE RSSI is less than the UE's dynamic receiver range:
 - 2> set the variable TRIGGERED_6E_EVENT to FALSE.

14.6.2.6 Reporting event 6F (FDD): The UE Rx-Tx time difference for a RL included in the active set becomes larger than an absolute threshold

When a UE internal measurement configuring event 6f is set up, the UE shall:

- 1> create a variable TRIGGERED_6F_EVENT related to that measurement, which shall initially be set to FALSE for each RL;
- 1> delete this variable when the measurement is released.

- 1> if the UE Rx-Tx time difference for a RL included in the active set is greater than the value in the IE "UE Rx-Tx time difference threshold" stored for this event in the variable MEASUREMENT_IDENTITY for a time period indicated by the IE "time_to_trigger":
 - 2> if the variable TRIGGERED_6F_EVENT is set to FALSE for this RL:

- 3> set the variable TRIGGERED_6F_EVENT to TRUE for this RL;
- 3> send a measurement report with IEs set as below:
 - 4> set in "UE internal measurement event results": "UE internal event identity" to "6f";
 - 4> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2.
 - 1> if the variable TRIGGERED_6F_EVENT is set to TRUE for a RL and if the UE RX-Tx time difference for this RL included in the active set is less than or equal to the value in the IE "UE Rx-Tx time difference threshold" stored for this event in the variable MEASUREMENT_IDENTITY:
 - 2> set the variable TRIGGERED_6F_EVENT to FALSE for this RL.

14.6.2.6a Reporting event 6F (1.28 Mcps TDD): The time difference indicated by T_{ADV} becomes larger than an absolute threshold

When a UE internal measurement configuring event 6f is set up, the UE shall:

- 1> create a variable TRIGGERED_6F_EVENT related to that measurement, which shall initially be set to the currently measured T_{ADV};
- 1> delete this variable when the measurement is released.

When this event is ordered by UTRAN in a measurement control message, the UE shall:

- 1> if the absolute value of the difference between the measured T_{ADV} and the T_{ADV} stored in the variable TRIGGERED_6F_EVENT is greater than the predefined threshold configured with the IE " T_{ADV} Threshold" for this event in the variable MEASUREMENT_IDENTITY for a time period indicated by the IE "time_to_trigger":
 - 2> set the variable TRIGGERED_6F_EVENT to the currently measured T_{ADV};
 - 2> send a measurement report with IEs set as below:
- 3> set the IE " T_{ADV} " to the measured value, and the IE "SFN" to the SFN during which the latest measurement was performed, in the IE " T_{ADV} Info";
- 3> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2.

14.6.2.7 Reporting event 6G: The UE Rx-Tx time difference for a RL included in the active set becomes less than an absolute threshold

When a UE internal measurement configuring event 6g is set up, the UE shall:

- 1> create a variable TRIGGERED_6G_EVENT related to that measurement, which shall initially be set to FALSE for each RL:
- 1> delete this variable when the measurement is released.

- 1> if the UE Rx-Tx time difference for a RL included in the active set is less than the value in IE "UE Rx-Tx time difference threshold" stored for this event in the variable MEASUREMENT_IDENTITY for a time period indicated by the IE "time_to_trigger":
 - 2> if the variable TRIGGERED_6G_EVENT is set to FALSE for this RL:
- 3> set the variable TRIGGERED_6G_EVENT to TRUE for this RL;
- 3> send a measurement report with IEs set as below:
 - 4> set in "UE internal measurement event results": "UE internal event identity" to "6g";
 - 4> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2.

1> if the variable TRIGGERED_6G_EVENT is set to TRUE for a RL and if the UE RX-Tx time difference for this RL included in the active set is greater or equal the value in IE "UE Rx-Tx time difference threshold" stored for this event in the variable MEASUREMENT_IDENTITY:

2> set the variable TRIGGERED_6G_EVENT to FALSE for this RL.

14.7 UE positioning measurements

14.7.1 UE positioning measurement quantities

The quantity to measure for UE positioning is dependent on the positioning method and the method type requested in the IE "UE positioning reporting quantity".

- 1 SFN-SFN observed time difference type 2, mandatory.
- 2 Rx-Tx time difference type 2, optional.
- 3 GPS timing of cell fames, optional.

The definition of other GPS measurements is not within the scope of this specification.

14.7.2 Void

14.7.3 UE positioning reporting events

In the IE "UE positioning reporting criteria" in the Measurement Control messages, the UTRAN notifies the UE of which events should trigger a measurement report. UE positioning reporting events that can trigger a report are given below. The content of the measurement report is dependant on the positioning method and method type requested in the IE "UE positioning reporting quantity" of the Measurement Control message and is described in detail in [18].

When one measurement identity corresponds to multiple positioning events with identical event identities, the UE behaviour is not defined.

14.7.3.1 Reporting Event 7a: The UE position changes more than an absolute threshold

This event is used for UE-based methods only.

- 1> if the UE changes its position compared to the last reported position by more than the threshold defined by the IE "Threshold position change"; or
- 1> if no position has been reported since the event was configured and the UE changes its position compared to the first position estimate obtained after the event was configured by more than the threshold defined by the IE "Threshold position change":
 - 2> send a measurement report as specified in subclause 8.6.7.19.1b;
 - 2> if the value of IE "Amount of Reporting" in variable MEASUREMENT_IDENTITY for this event is greater than one:
- 3> decrease IE "Amount of Reporting" in variable MEASUREMENT_IDENTITY for this event by one.
 - 2> if the value of IE "Amount of Reporting" in variable MEASUREMENT_IDENTITY for this event is equal to one:
- 3> delete this event from the list of events in variable MEASUREMENT IDENTITY.
 - 1> if the UE is unable to evaluate the event because a position measurement is not available:
 - 2> not send a report.

14.7.3.2 Reporting Event 7b: SFN-SFN measurement changes more than an absolute threshold

When this event is ordered by UTRAN in a measurement control message, the UE shall:

- 1> send a measurement report when the SFN-SFN time difference measurement type 2 of any measured cell changes more than the threshold defined by the IE "Threshold SFN-SFN change"; and
- 1> if UTRAN set IE "Method Type" in "UE positioning reporting quantity" in the MEASUREMENT CONTROL message to "UE-based":
 - 2> act as specified in subclause 8.6.7.19.1b.
- 1> if UTRAN set IE "Method Type" in "UE positioning reporting quantity" in the MEASUREMENT CONTROL message to "UE-assisted":
 - 2> act as specified in subclause 8.6.7.19.1a.
- 1> if UTRAN set IE "Method Type" in "UE positioning reporting quantity" in the MEASUREMENT CONTROL message to "UE-assisted preferred but UE-based allowed" or "UE-based preferred but UE-assisted allowed":
 - 2> the UE may choose to act according to either subclause 8.6.7.19.1a or 8.6.7.19.1b.
- 1> if the value of IE "Amount of Reporting" in variable MEASUREMENT_IDENTITY for this event is greater than one:
 - 2> decrease IE "Amount of Reporting" in variable MEASUREMENT_IDENTITY for this event by one.
- 1> if the value of IE "Amount of Reporting" in variable MEASUREMENT_IDENTITY for this event is equal to one:
 - 2> delete this event from the list of events in variable MEASUREMENT IDENTITY.

14.7.3.3 Reporting Event 7c: GPS time and SFN time have drifted apart more than an absolute threshold

- 1> send a measurement report when the GPS Time Of Week and the SFN timer have drifted apart more than the threshold defined by the IE "Threshold SFN-GPS TOW"; and
- 1> if UTRAN set IE "Method Type" in "UE positioning reporting quantity" in the MEASUREMENT CONTROL message to "UE based":
 - 2> act as specified in subclause 8.6.7.19.1b.
- 1> if UTRAN set IE "Method Type" in "UE positioning reporting quantity" in the MEASUREMENT CONTROL message to "UE assisted":
 - 2> act as specified in subclause 8.6.7.19.1a.
- 1> if UTRAN set IE "Method Type" in "UE positioning reporting quantity" in the MEASUREMENT CONTROL message to "UE assisted preferred but UE based allowed" or "UE based preferred but UE assisted allowed":
 - 2> act as specified in subclause 8.6.7.19.1a or in subclause 8.6.7.19.1b depending on the method type chosen by the UE.
- 1> if the value of IE "Amount of Reporting" in variable MEASUREMENT_IDENTITY for this event is greater than one:
 - 2> decrease IE "Amount of Reporting" in variable MEASUREMENT_IDENTITY for this event by one.
- 1> if the value of IE "Amount of Reporting" in variable MEASUREMENT_IDENTITY for this event is equal to one:
 - 2> delete this event from the list of events in variable MEASUREMENT_IDENTITY.

14.8 Dynamic Resource Allocation Control of Uplink DCH (FDD only)

The network uses this procedure to dynamically control the allocation of resources on an uplink DCH.

This procedure shall be activated in the UE when it has been allocated an uplink DCH with DRAC static information elements. Such uplink DCHs can be established through RB establishment procedure, RB reconfiguration procedure, RB release procedure or Transport Channel Reconfiguration procedure by setting the DRAC static information elements to indicate that the DCH is controlled by the DRAC procedure.

The UE shall periodically listen to the System Information Block 10 of each cell in its Active Set. The scheduling information of System Information Block 10 and the SCCPCH info on which the System Information Block 10 is transmitted are provided to the UE when the DCH is set up and when a cell is added in its active set. In case several System Information Block 10 messages from different cells are scheduled at the same time, the UE shall only listen to the System Information Block 10 broadcast in the cell of its Active Set having the best CPICH measurements.

Upon reception of a SYSTEM INFORMATION message comprising a System Information Block 10,the UE shall:

- 1. Determine and store the most stringent DRAC parameters from the last received values from each cell of its active set (i.e. select the lowest product p_{tr}*maximum bit rate corresponding to its DRAC class identity)
- 2. Determine the allowed subset of TFCS according to the selected maximum bit rate value, and store it for later usage.

The allowed subset of TFCS are the ones of the TFCS for which the sum of bit rates of the DCH controlled by DRAC is lower than Maximum Bit Rate IE, i.e.

$$\sum_{\text{DCHi controlled by DRAC}} TBS size_{i} \ / \ TTI_{i} < Maximum Bit Rate$$

After the first System Information Block 10 has been received, the UE shall start the following process:

- 1. At the start of the next TTI, the UE shall randomly select p ε [0,1].
- 2. If p < ptr, the UE shall transmit on the DCH controlled by DRAC during $T_{validity}$ frames using the last stored allowed subset of TFCS and comes back to step 1, otherwise the UE shall stop transmission on these DCH during T_{retry} frames and then comes back to step 1.

Transmission time validity ($T_{validity}$) and Time duration before retry (T_{retry}) are indicated to the UE at the establishment of a DCH controlled by this procedure and may be changed through RB or transport channel reconfiguration. The UE shall always use the latest received DRAC static parameters.

A UE that supports the simultaneous reception of one SCCPCH and one DPCH shall support the DRAC procedure.

14.9 Downlink power control

14.9.1 Generalities

This function is implemented in the UE in order to set the SIR target value on each CCTrCH used for the downlink power control. This SIR value shall be adjusted according to an autonomous function in the UE in order to achieve the same measured quality as the quality target set by UTRAN. The quality target is set as the transport channel BLER value for each transport channel as signalled by UTRAN. For CPCH the quality target is set as the BER of the DL DPCCH as signalled by UTRAN.

When transport channel BLER is used the UE shall run a quality target control loop such that the quality requirement is met for each transport channel, which has been assigned a BLER target.

When DL DPCCH BER is used the UE shall run a quality target control loop such that the quality requirement is met for each CPCH transport channel, which has been assigned a DL DPCCH BER target.

The UE shall set the SIR target when the physical channel has been set up or reconfigured. It shall not increase the SIR target value before the power control has converged on the current value. The UE may estimate whether the power control has converged on the current value, by comparing the averaged measured SIR to the SIR target value.

14.9.2 Downlink power control in compressed mode

In compressed mode, the target SIR needs to be changed in several frames compared to normal mode. For this purpose, four values DeltaSIR1, DeltaSIRafter1, DeltaSIR2 and DeltaSIRafter2 are signalled by the UTRAN to the UE (see subclause 10.2.9).

For each frame, the target SIR offset during compressed mode, compared to normal mode is:

$$\Delta SIR = max (\Delta SIR1_compression, ..., \Delta SIRn_compression) + \Delta SIR1_coding + \Delta SIR2_coding$$

where n is the number of TTI lengths for all TrChs of the CCTrCh, F_i is the length in number of frames of the i-th TTI and where Δ SIR coding fulfils:

- ΔSIR1_coding= DeltaSIR1 if the start of the first transmission gap in the transmission gap pattern is within the current frame.
- ΔSIR1_coding= DeltaSIRafter1 if the current frame just follows a frame containing the start of the first transmission gap in the transmission gap pattern.
- ΔSIR2_coding= DeltaSIR2 if the start of the second transmission gap in the transmission gap pattern is within the current frame.
- ΔSIR2_coding= DeltaSIRafter2 if the current frame just follows a frame containing the start of the second transmission gap in the transmission gap pattern.
- Δ SIR1_coding= 0 and Δ SIR2_coding= 0 otherwise.

and $\Delta SIRi_compression$ is defined by :

- ΔSIRi_compression = 3 dB for downlink frames compressed by reducing the spreading factor by 2.
- $\Delta SIRi_compression = 10 log (15*F_i / (15*F_i TGL_i))$ if there is a transmission gap created by puncturing method within the current TTI of length F_i frames, where TGL_i is the gap length in number of slots (either from one gap or a sum of gaps) in the current TTI of length F_i frames.
- Δ SIRi_compression = 0 dB in all other cases.

Several compressed mode patterns applying to the same frames should be avoided as much as possible.

In particular; several simultaneous patterns by puncturing applying to the same frames shall be considered as a protocol error by the UE. The handling of this error is described in the procedure descriptions in clause 8

In case several compressed mode patterns are used simultaneously, a Δ SIR offset is computed for each compressed mode pattern and the sum of all Δ SIR offsets is applied to the frame.

14.10 Calculated Transport Format Combination

The Calculated Transport Format Combination (CTFC) is a tool for efficient signalling of transport format combinations.

Let I be the number of transport channels that are included in the transport format combination. Each transport channel $TrCH_i$, i = 1, 2, ..., I, has L_i transport formats, i.e. the transport format indicator TFI_i can take L_i values, $TFI_i \in \{0,1,2,...,L_i-1\}$.

Define
$$P_i = \prod_{j=0}^{i-1} L_j$$
, where $i = 1, 2, ..., I$, and $L_0 = 1$.

Let $TFC(TFI_1, TFI_2, ..., TFI_l)$ be the transport format combination for which $TrCH_1$ has transport format TFI_1 , $TrCH_2$ has transport format TFI_2 , etc. The corresponding $CTFC(TFI_1, TFI_2, ..., TFI_l)$ is then computed as:

$$CTFC(TFI_1, TFI_2, ..., TFI_I) = \sum_{i=1}^{I} TFI_i \cdot P_i.$$

For FACH and PCH transport channels, "TrCH₁" corresponds to the transport channel listed at the first position in IE "FACH/PCH information" in IE "Secondary CCPCH System Information", "TrCH₂" corresponds to the transport channel listed at the second position in IE "FACH/PCH information" and so on.

For all other transport channels in FDD and for all configured transport channels of the same transport channel type (i.e. DCH, DSCH, USCH) in TDD, " $TrCH_1$ " corresponds to the transport channel having the lowest transport channel identity in the transport format combination mapped to the TFCI field. " $TrCH_2$ " corresponds to the transport channel having the next lowest transport channel identity, and so on.

14.11 UE autonomous update of virtual active set on non-used frequency (FDD only)

In the text that follows:

- a "non-used frequency" is a frequency that the UE has been ordered to measure upon but is not used for the connection. A "used frequency" is a frequency that the UE has been ordered to measure upon and is also currently used for the connection;
- a "non-used frequency (resp. cell) considered in an inter-frequency measurement" shall be understood as a non-used frequency (resp. cell) included in the list of cells pointed at in the IE "cells for measurement" if it was received for that measurement, or otherwise as a non-used frequency (resp. cell) included in the "Inter-frequency cell info" part of the variable CELL_INFO_LIST.

For event-triggered inter frequency measurements it is possible to use intra-frequency measurement reporting events for support of maintenance of an active set associated with a non-used frequency considered in that measurement, a "virtual active set" and used in the evaluation of the frequency quality estimates. The "initial virtual active set" for a frequency is the virtual active set that is associated to that frequency just after a message was received that sets up or modifies the inter-frequency measurement.

The way the virtual active sets are initiated and updated for the non-used frequencies considered in an inter-frequency measurement is described in the two subclauses below.

The UE shall support a single virtual active set per non-used frequency.

14.11.1 Initial virtual active set

If the UE receives a MEASUREMENT CONTROL message that sets up or modifies an inter-frequency measurement and includes the IE "Inter-frequency set update", the UE shall:

- 1> for each non-used frequency F_i considered in the measurement:
 - 2> include in the initial virtual active set the N_i cells that have either the greatest downlink E_c/N₀ or the greatest downlink RSCP after despreading or the lowest pathloss (depending on what is indicated in the IE "interfrequency measurement quantity"), among the cells on frequency F_i considered in that inter-frequency measurement, where:
- 3> if event 1a is configured for the used frequency in an intra-frequency measurement:

$$N_i = \min(N_{la}, N_{Cells Fi})$$
 if $N_{1a} \neq 0$ and $N_i = N_{Cells Fi}$ otherwise.

where:

 N_{1a} is the "Reporting deactivation threshold" included in the intra-frequency measurement for the first event 1a defined in the intra-frequency measurement with the lowest identity.

 $N_{Cells} F_i$ is the number of cells on frequency F_i considered in that inter-frequency measurement.

3> else:

$$N_i = N_{Cells Fi}$$

where:

 $N_{Cells\ Fi}$ is the number of cells on frequency F_i considered in that inter-frequency measurement.

14.11.2 Virtual active set update during an inter-frequency measurement

For an inter-frequency measurement, the UE shall:

- 1> apply the events of type 1a, 1b and 1c that were defined for the used frequency in other stored measurements of type "intra-frequency" at the time the inter-frequency measurement was set up; and
- 1> update the virtual active set for the non-used frequencies considered in that measurement according to the following rules:
 - 2> if several events of type 1a (resp. 1b,1c) were defined for the used frequency when the inter-frequency measurement was set up, only the first 1a event (resp 1b, 1c) that was defined in the measurement with the lowest measurement identity shall apply to the non-used frequencies;
 - 2> all the cells considered in the inter-frequency measurements shall be able to affect the reporting range for event 1a and 1b. (i.e. the IE "Cells forbidden to affect reporting range" possibly stored for the intra-frequency measurements on the used frequency does not apply to the non-used frequencies considered in the interfrequency measurement);
 - 2> the IEs "amount of reporting" and "reporting interval" that were stored for the intra-frequency measurements on the used frequency shall not be considered if reports of the virtual active set updates are needed.
- 1> if event 1a is applicable to the non-used frequencies considered in the inter-frequency measurement:
 - 2> when this event is triggered (according to the criteria described in subclause 14.1.2.1) by a cell for a non-used frequency considered in that measurement:
- 3> if the "Reporting deactivation threshold" is equal to 0, or if the "Reporting deactivation threshold" is different from 0 and the number of cells included in the virtual active set for that frequency is less than or equal to the "Reporting deactivation threshold":
 - 4> add the primary CPICH that enters the reporting range to the "virtual active set".
 - 2> if event 1b is applicable for the non-used frequencies considered in that inter-frequency measurement, when this event is triggered (according to the criteria described in subclause 14.1.2.2) by a cell for a non-used frequency considered in that measurement:
- 3> if the number of cells included in the virtual active set is greater than 1:
 - 4> remove the primary CPICH that leaves the reporting range from the "virtual active set".
 - 2> if event 1c is applicable for the non-used frequencies considered in that inter-frequency measurement, when this event is triggered (according to the criteria described in subclause 14.1.2.3) by a cell for a non-used frequency considered in that measurement:
- 3> if the "Reporting activation threshold" is equal to 0, or if the "Reporting activation threshold" is different from 0 and the number of cells included in the virtual active set for that frequency is greater than or equal to the "Reporting activation threshold":
 - 4> rank all active and non-active primary CPICHs and take the *n* best cells to create a new "virtual active set", where *n* is the number of active primary CPICHs in the "virtual active set".
 - 1> if Event 1a is not defined for the used frequency in other stored measurements of type "intra-frequency" at the time the inter-frequency measurement was set up:

2> the UE shall continuously update the virtual active set to consist of all cells on frequency F_i considered in that inter-frequency measurement, without sending any corresponding measurement report.

If none of the cells that are considered in the measurement on this frequency were measured, the UE may treat the virtual active set as empty and follow the appropriate initialisation procedured in subclause 14.11.1 when any relevant cell can first be measured.

14.12 Provision and reception of RRC information between network nodes

14.12.0 General

In certain cases, e.g., when performing handover to UTRAN or when performing SRNC relocation, RRC information may need to be transferred between UTRAN nodes, between UTRAN and another RAT, between nodes within another RAT or between the UE and another RAT.

The RRC information exchanged between network nodes or between the UE and another RAT is typically transferred by means of RRC information containers. An RRC information container is a self-contained and extensible RRC information unit that may be used to transfer a number of different RRC messages, one at a time. As stated before, RRC information containers may be used to transfer RRC messages across interfaces other than the Uu interface. The RRC messages that may be included in RRC information containers have similar characteristics as the RRC messages that are transferred across the Uu interface.

The RRC messages that are sent to/ from the UE, e.g., HANDOVER TO UTRAN COMMAND, INTER RAT HANDOVER INFO are covered by (sub)clauses 8, 9, 10, 11.0-11.4 and 12 of this specification. The following subclauses concern RRC messages exchanged between network nodes.

In future versions of this specification, it is possible to extend the RRC messages transferred across interfaces other than Uu. For these RRC messages the same extension mechanism applies as defined for RRC messages transferred across the Uu interface, as is specified in subclause 10.1, i.e., both critical and non-critical extensions may be added.

The transfer syntax for RRC information containers and RRC messages transferred between network nodes is derived from their ASN.1 definitions by use of Packed Encoding Rules, unaligned (X.691). It should be noted that the encoder adds final padding to achieve octet alignment. The resulting octet string is, carried in a container, transferred between the network nodes.

When using a separate RRC information container for each endpoint, the receiving RRC protocol entity is able to interpret the received container; this means that the receiver need not take into account information about the (network interface) message used in transferring the container.

The following encoding rules apply in addition to what has been specified in X.691 [49]:

1> When a bit string value is placed in a bit-field as specified in 15.6 to 15.11 in [11], the leading bit of the bit string value shall be placed in the leading bit of the bit-field, and the trailing bit of the bit string value shall be placed in the trailing bit of the bit-field.

NOTE: The terms "leading bit" and "trailing bit" are defined in ITU-T Rec. X.680 | ISO/IEC 8824-1. When using the "bstring" notation, the leading bit of the bit string value is on the left, and the trailing bit of the bit string value is on the right.

14.12.0a General error handling for RRC messages exchanged between network nodes

The error handling for RRC messages that are exchanged between network nodes applies the same principles as defined for other RRC messages.

Although the same principles apply for network nodes receiving unknown, unforeseen and erroneous RRC messages received in RRC information containers, the notification of the error should be done in a different manner, as specified in the following:

The network node receiving an invalid RRC message from another network node should:

- 1> if the received RRC message was unknown, unforeseen or erroneous:
 - 2> prepare an RRC FAILURE INFO message, including the IE "Failure cause" set to "Protocol error" and the IE "Protocol error information" including an IE "Protocol error cause" which should be set as follows:
- 3> to "ASN.1 violation or encoding error" upon receiving an RRC message for which the encoded message does not result in any valid abstract syntax value;
- 3> to "Message type non-existent or not implemented" upon receiving an unknown RRC message type;
- 3> to "Message extension not comprehended" upon receiving an RRC message including an undefined critical message extension:
- 3> to "Information element value not comprehended" upon receiving an RRC message including an mandatory IE for which no default value is defined and for which either the value is set to spare or for which the encoded IE does not result in a valid transfer syntax. The same applies for conditional IEs, for which the conditions for presence are met, the IE is present but has a value set to spare or for which the encoded IE does not result in a valid transfer syntax;
- 3> to "Information element missing" upon receiving an RRC information container with an absent conditional IE for which the conditions for presence are met.
 - 1> if there was another failure to perform the operation requested by the received RRC message:
 - 2> prepare an RRC FAILURE INFO message, including the IE "Failure cause" set to a value that reflects the failure cause.
 - 1> send the RRC FAILURE INFO message to the network node from which the invalid RRC protocol information was received.
 - NOTE 1: The appropriate (failure) messages used across the network interfaces may not support the inclusion of a RRC information container. In this case, the information contained in the RRC FAILURE INFO message may need to be transferred otherwise e.g. by mapping to a cause value (e.g. a cause value in the RR-HANDOVER FAILURE message when there is a error associated with the RRC-HANDOVER TO UTRAN COMMAND message).
 - NOTE 2 In case the RRC procedure used to perform SRNS relocation fails e.g. due to non comprehension, the source RNC may notify the target RNC by including the diagnostics information (IEs "Protocol error" and "Protocol error information") in the "RRC message "SRNS Relocation" Info sent in the RRC information container" used for a subsequent relocation request.

14.12.1 RRC Information to target RNC

The RRC information container "RRC Information to target RNC" may either be sent from source RNC or from another RAT. In case of handover to UTRAN, this information originates from another RAT, while in case of SRNC relocation the RRC information originates from the source RNC. In case of handover to UTRAN, the RRC information transferred may provide UTRAN specific information, as defined in the INTER RAT HANDOVER INFO WITH INTER RAT CAPABILITIES message, that the target RNC needs when preparing the handover command message. In case of SRNC relocation and handover/cell reselection from GERAN *Iu mode*, the RRC information transferred specifies the configuration of RRC and the lower layers it controls, e.g., including the radio bearer and transport channel configuration. It is used by the target RNC to initialise RRC and the lower layer protocols to facilitate SRNC relocation and handover/cell reselection from GERAN *Iu mode* in a manner transparent to the UE.

RFC 3095 CONTEXT INFO is used to transfer the compressor and decompressor context information of the RFC 3095 protocol from source RNC to target RNC.

Information Element/Group Name	Need	Multi	Type and reference	Semantics description	Version
CHOICE case	MP			At least one spare choice, Criticality: Reject, is needed	
>Handover to UTRAN			INTER RAT HANDOVER INFO WITH INTER RAT CAPABILITI ES 14.12.4.1		
>SRNC relocation			SRNS RELOCATIO N INFO 14.12.4.2		
>RFC 3095 context info			RFC 3095 CONTEXT INFO 14.12.4.4		REL-5

14.12.2 RRC information, target RNC to source RNC

There are 2 possible cases for RNC relocation:

- 1. The UE is already under control of target RNC; and
- 2. The SRNC Relocation with Hard Handover (UE still under control of SRNC), but UE is moving to a location controlled by the target RNC (based on measurement information).

In case 1 the relocation is transparent to the UE and there is no "reverse" direction container. The SRNC just assigns the 'serving' function to the target RNC, which then becomes the Serving RNC.

In case 2 the relocation is initiated by SRNC, which also provides the RRC Initialisation Information to the target RNC. Base on this information, the target RNC prepares the Hard Handover Message ("Physical channel reconfiguration" (subclause 8.2.6), "radio bearer establishment" (subclause 8.2.1), "Radio bearer reconfiguration" (subclause 8.2.2), "Radio bearer release" (subclause 8.2.3) or "Transport channel reconfiguration" (subclause 8.2.4).

In case 2 two possibilities are defined in order to transmit the relocation message from the target RNC to the source RNC which can be chosen by the source RNC by including or not including the IE "RB Id for handover message" in the IE "SRNS Relocation Info".

In case the IE "RB Id for handover message" has been received by the target RNC in the IE "SRNS Relocation Info", the target RNC should choose the IE "DL DCCH message" and include the DL DCCH message that should be transmitted transparently to the UE by the source RNC. In that case, the target RNC is integrity protecting the message if applicable.

If the target RNC did not receive the IE "RB Id for handover message" in the IE "SRNS Relocation Info" the target RNC should use another choice. In that case, the source RNC should integrity protect the message before transmitting it to the UE if applicable.

The source RNC then transmits the Handover Message to the UE, which then performs the handover.

In the successful case, the UE transmits an XXX COMPLETE message, using the new configuration, to the target RNC.

In case of failure, the UE transmits an XXX FAILURE, using the old configuration, to the source RNC and the RRC context remains unchanged (has to be confirmed and checked with the SRNS relocation procedure).

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Hame			reference	
CHOICE RRC message	MP			At least one spare choice,
				Criticality: Reject, is needed
>RADIO BEARER SETUP			RADIO	
FIGURE BEAUCER OF TO				
			BEARER	
	1		SETUP	
			SETUP	

Information Element/Group	Need	Multi	Type and	Semantics description
name			reference	
			10.2.31	
>RADIO BEARER			RADIO	
RECONFIGURATION			BEARER	
			RECONFIG	
			URATION	
			10.2.25	
>RADIO BEARER RELEASE			RADIO	
			BEARER	
			RELEASE	
			10.2.28	
>TRANSPORT CHANNEL			TRANSPOR	
RECONFIGURATION			T CHANNEL	
			RECONFIG	
			URATION	
			10.2.51	
>PHYSICAL CHANNEL			PHYSICAL	
RECONFIGURATION			CHANNEL	
			RECONFIG	
			URATION	
			10.2.20	
>RRC FAILURE INFO			RRC	
			FAILURE	
			INFO	
			10.2.41	
			а	
>DL DCCH message			OCTET	
			STRING	

14.12.3 Void

14.12.4 RRC messages exchanged between network nodes

14.12.4.0 HANDOVER TO UTRAN COMMAND

This RRC message is sent between network nodes to transfer the actual handover command including the details of the radio configuration to be used upon handover to UTRAN as compiled by the target RNC.

Direction: target RNC →source RAT

The message is exactly the same as the HANDOVER TO UTRAN COMMAND defined in subclause 10.2.16a.

14.12.4.0a INTER RAT HANDOVER INFO

This RRC message is sent between network nodes to transfer information relevant for the target RNC when preparing for handover to UTRAN.

Direction: source RNC/RAT \rightarrow target RAT

The message is exactly the same as the INTER RAT HANDOVER INFO defined in subclause 10.2.16d

14.12.4.1 INTER RAT HANDOVER INFO WITH INTER RAT CAPABILITIES

This RRC message is sent between network nodes when preparing for an inter RAT handover to UTRAN.

Direction: source RAT→target RNC

Information Element/Group	Need	Multi	Type and	Semantics description
Name			reference	-

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
UE Information elements				
Predefined configuration status information	OP		Predefined configuration status information 10.3.4.5a	
Predefined configuration status information compressed	OP		Predefined configuration status information compressed 10.3.4.5b	REL-5
UE security information	OP		UE security information 10.3.3.42b	
UE Specific Behaviour Information 1 interRAT	OP		UE Specific Behaviour Information 1 interRAT 10.3.3.52	This IE shall not be included in this version of the protocol
UE capability container	OP			
>UE radio access capability	MP		UE radio access capability 10.3.3.42	
>UE radio access capability extension	MP		UE radio access capability extension 10.3.3.42a	Although this IE is not always required, the need has been set to MP to align with the ASN.1
UE radio access capability compressed	OP		UE radio access capability compressed 10.3.3.420	REL-5
Other Information elements				
UE system specific capability	OP	1 to <maxsyste mCapabilit y></maxsyste 		
>Inter-RAT UE radio access capability	MP		Inter-RAT UE radio access capability 10.3.8.7	
Failure cause	OP		Failure cause 10.3.3.13	Diagnostics information related to an earlier handover to UTRAN request
Protocol error information	CV-ProtErr		Protocol error information 10.3.8.12	

Condition	Explanation
ProtErr	This IE is mandatory present if the IE "Protocol error
	indicator" is included and has the value "TRUE".
	Otherwise it is not needed.

NOTE1: To facilitate that network nodes can transparently forward the RRC information received, the INTER RAT HANDOVER INFO WITH INTER RAT CAPABILITIES should include the entire INTER RAT HANDOVER INFO message. The network node, which may not be able to decode the information received, may only append some information to what was received.

NOTE2: The above table does not need to reflect the order of the information elements in the actual encoded message. The order, that is reflected in the ASN.1, should be chosen in a manner that avoids that network nodes need to perform reordering of information elements.

14.12.4.2 SRNS RELOCATION INFO

This RRC message is sent between network nodes when preparing for an SRNS relocation or a handover/cell reselection from GERAN *Iu mode*.

With the presence or absence of the IE "RB identity for Hard Handover message" the source RNC indicates to the target SRNC whether the source RNC expects to receive the choice "DL DCCH message" in the IE "RRC information, target RNC to source RNC" in case the SRNS relocation is of type "UE involved". Furthermore the target RNC uses this information for the calculation of the MAC-I.

Direction: source RNC/RAT→target RNC

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
Non RRC IEs				
>RB identity for Handover message	OP		RB identity 10.3.4.16	Gives the id of the radio bearer on which the source RNC will transmit the RRC message in the case the relocation is of type "UE involved". In handover from GERAN <i>Iu mode</i> this IE is always set to 2.
>State of RRC	MP		RRC state indicator, 10.3.3.35a	
>State of RRC procedure	MP		Enumerated (await no RRC message, await RB Release Complete, await RB Setup Complete, await RB Reconfigurat ion Complete, await Transport CH Reconfigurat ion Complete, await Physical CH Reconfigurat ion Complete, await Complete, aw	

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
Ciphering related information				
>Ciphering status for each CN domain	MP	<1 to maxCNDo mains>		
>>CN domain identity	MP		CN domain identity 10.3.1.1	
>>Ciphering status	MP		Enumerated(Not started, Started)	
>>START	MP		START 10.3.3.38	START value to be used in this CN domain.
>Latest configured CN domain	MP		CN domain identity 10.3.1.1	Value contained in the variable of the same name. In case this variable is empty, the source RNC can set any CN domain identity. In that case, the Ciphering status and the Integrity protection status should be Not started and the target RNC should not initialise the variable Latest configured CN domain.
>Calculation time for ciphering related information	CV- Ciphering			Time when the ciphering information of the message were calculated, relative to a cell of the target RNC. In handover and cell reselection from GERAN <i>Iu mode</i> this field is not present.
>>Cell Identity	MP		Cell Identity 10.3.2.2	Identity of one of the cells under the target RNC and included in the active set of the current call
>>SFN	MP		Integer(040 95)	
>COUNT-C list	OP	1 to <maxcndo mains></maxcndo 	,	COUNT-C values for radio bearers using transparent mode RLC
>>CN domain identity	MP		CN domain identity 10.3.1.1	
>>COUNT-C	MP		Bit string(32)	
>Ciphering info per radio bearer	OP	1 to <maxrb></maxrb>	3(2)	For signalling radio bearers this IE is mandatory.
>>RB identity	MP		RB identity 10.3.4.16	
>>Downlink HFN	MP		Bit string(2025	This IE is either RLC AM HFN (20 bits) or RLC UM HFN (25 bits)
>>Downlink SN	CV-SRB1		Bit String(7)	VT(US) of RLC UM
>>Uplink HFN	MP		Bit string(2025	This IE is either RLC AM HFN (20 bits) or RLC UM HFN (25 bits)
Integrity protection related information				
>Integrity protection status	MP		Enumerated(Not started, Started)	
>Signalling radio bearer specific integrity protection information	CV-IP	4 to <maxsrbs etup></maxsrbs 	,	
>>Uplink RRC HFN	MP	,	Bit string (28)	For each SRB, in the case activation times for the next IP configuration to be applied on

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
				this SRB have already been reached this IE corresponds to the last value used. Else this value corresponds to the value the source would have initalized the HFN to at the activation time. Increment of HFN due to RRC SN roll over is taken care of by target based on value sent by the source.
>>Downlink RRC HFN	MP		Bit string (28)	For each SRB, in the case activation times for the next IP configuration to be applied on this SRB have already been reached this IE corresponds to the last value used. Else this value corresponds to the value the source would have initalized the HFN to at the activation time. Increment of HFN due to RRC SN roll over is taken care of by target based on value sent by the source. In particular, for SRB2, this IE should not take into account the RRC message that will trigger the relocation.
>>Uplink RRC Message sequence number	MP		Integer (0 15)	For each SRB, this IE corresponds to the last value received or in the case activation time was not reached for a configuration the value equals (activation time - 1).
>>Downlink RRC Message sequence number	MP		Integer (0 15)	For each SRB, this IE corresponds to the last value used or in the case activation time was not reached for a configuration the value equals (activation time -1). In particular, for SRB2, this IE should not take into account the RRC message that will trigger the relocation.
>Implementation specific parameters	OP		Bit string (1512)	anggor and renocation.
RRC IEs				
UE Information elements >U-RNTI	MP		U-RNTI 10.3.3.47	G-RNTI is placed in this field when performing handover or cell reselection from GERAN <i>Iu mode.</i>
>C-RNTI	OP		C-RNTI 10.3.3.8	
>UE radio access Capability	MP		UE radio access capability 10.3.3.42	
>UE radio access capability extension	OP		UE radio access capability extension 10.3.3.42a	
>Last known UE position	OP			
>>SFN	MP		Integer	Time when position was

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
			(04095)	estimated
>>Cell ID	MP		Cell identity; 10.3.2.2	Indicates the cell, the SFN is valid for.
>>CHOICE Position estimate	MP			
>>>Ellipsoid Point			Ellipsoid Point;	
			10.3.8.4a	
>>>Ellipsoid point with uncertainty circle			Ellipsoid point with uncertainty	
			circle 10.3.8.4d	
>>>Ellipsoid point with uncertainty ellipse			Ellipsoid point with uncertainty ellipse 10.3.8.4e	
>>>Ellipsoid point with altitude			Ellipsoid point with altitude	
			10.3.8.4b	
>>>Ellipsoid point with altitude and uncertainty ellipsoid			Ellipsoid point with altitude and uncertainty ellipsoid 10.3.8.4c	
>UE Specific Behaviour Information 1 idle	OP		UE Specific Behaviour Information idle 1 10.3.3.51	This IE should be included if received via the "INTER RAT HANDOVER INFO", the "RRC CONNECTION REQUEST", the IE "SRNS RELOCATION INFO" or the "Inter RAT Handover Info with Inter RAT Capabilities"
>UE Specific Behaviour Information 1 interRAT	OP		UE Specific Behaviour Information 1 interRAT 10.3.3.52	This IE should be included if received via the "INTER RAT HANDOVER INFO", the "RRC CONNECTION REQUEST", the IE "SRNS RELOCATION INFO" or the "Inter RAT Handover Info with Inter RAT Capabilities"
Other Information elements				
>UE system specific capability	OP	1 to <maxsyste mCapabilit y></maxsyste 		
>>Inter-RAT UE radio access capability	MP		Inter-RAT UE radio access capability 10.3.8.7	
UTRAN Mobility Information elements				
>URA Identifier	OP		URA identity 10.3.2.6	
CN Information Elements				
>CN common GSM-MAP NAS system information	MP		NAS system information (GSM-MAP) 10.3.1.9	
>CN domain related information	OP	1 to <maxcndo mains></maxcndo 		CN related information to be provided for each CN domain
>>CN domain identity	MP			

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
>>CN domain specific GSM- MAP NAS system info	MP		NAS system information (GSM-MAP) 10.3.1.9	
>>CN domain specific DRX cycle length coefficient	MP		CN domain specific DRX cycle length coefficient, 10.3.3.6	
Measurement Related Information elements				
>For each ongoing measurement reporting	OP	1 to <maxnoof Meas></maxnoof 		
>>Measurement Identity	MP		Measuremen t identity 10.3.7.48	
>>Measurement Command	MP		Measuremen t command 10.3.7.46	
>>Measurement Type	CV-Setup		Measuremen t type 10.3.7.50	
>>Measurement Reporting Mode	OP		Measuremen t reporting mode 10.3.7.49	
>>Additional Measurements list	OP		Additional measuremen ts list 10.3.7.1	
>>CHOICE Measurement	OP			
>>>Intra-frequency >>>>Intra-frequency cell info	OP		Intra- frequency cell info list 10.3.7.33	
>>>>Intra-frequency measurement quantity	OP		Intra- frequency measuremen t quantity 10.3.7.38	
>>>>Intra-frequency reporting quantity	OP		Intra- frequency reporting quantity 10.3.7.41	
>>>Reporting cell status	OP		Reporting cell status 10.3.7.61	
>>>Measurement validity	OP		Measuremen t validity 10.3.7.51	
>>>CHOICE report criteria	OP			
>>>>Intra-frequency measurement reporting criteria			Intra- frequency measuremen t reporting criteria 10.3.7.39	
>>>>Periodical reporting			Periodical reporting criteria 10.3.7.53	
>>>>No reporting			NULL	

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
>>>Inter-frequency				
>>>Inter-frequency cell info	OP		Inter- frequency cell info list 10.3.7.13	
>>>Inter-frequency measurement quantity	OP		Inter- frequency measuremen t quantity 10.3.7.18	
>>>Inter-frequency reporting quantity	OP		Inter- frequency reporting quantity 10.3.7.21	
>>>Reporting cell status	OP		Reporting cell status 10.3.7.61	
>>>Measurement validity	ОР		Measuremen t validity 10.3.7.51	
>>>Inter-frequency set update	OP		Inter- frequency set update 10.3.7.22	
>>>>CHOICE report criteria	OP			
>>>>Intra-frequency measurement reporting criteria			Intra- frequency measuremen t reporting criteria 10.3.7.39	
>>>>Inter-frequency measurement reporting criteria			Inter- frequency measuremen t reporting criteria 10.3.7.19	
>>>>Periodical reporting			Periodical reporting criteria 10.3.7.53	
>>>>No reporting			NULL	
>>>Inter-RAT >>>>Inter-RAT cell info	ОР		Inter-RAT cell info list 10.3.7.23	
>>>>Inter-RAT measurement quantity	OP		Inter-RAT measuremen t quantity 10.3.7.29	
>>>Inter-RAT reporting quantity	OP		Inter-RAT reporting quantity 10.3.7.32	
>>>Reporting cell status	OP		Reporting cell status 10.3.7.61	
>>>Measurement validity	OP		Measuremen t validity 10.3.7.51	
>>>>CHOICE report criteria	OP			
>>>>Inter-RAT measurement reporting criteria			Inter-RAT measuremen t reporting	

Criteria 10.3.7.30	Information Element/Group Name	Need	Multi	Type and reference	Semantics description
>>>>No reporting Periodical reporting reporting criteria 10.3.7.53 >>>>Traffic Volume Periodical reporting criteria 10.3.7.53 >>>>Traffic Volume Periodical reporting criteria >>>>Traffic volume Periodical reporting criteria >>>>Traffic volume Periodical reporting criteria >>>>Traffic volume reporting Periodical reporting criteria >>>>Traffic volume reporting Periodical reporting criteria >>>>>Traffic volume reporting criteria >>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>					
Perporting criteria 10.3.7.53 10.3.7.53 10.3.7.53 10.3.7.54 10.3.7.74 10.3.7.74 10.3.7.74 10.3.7.74 10.3.7.74 10.3.7.74 10.3.7.74 10.3.7.74 10.3.7.74 10.3.7.74 10.3.7.75 10.3.7.74 10.3.7.75 10.3.7.74 10.3.7.74 10.3.7.74 10.3.7.74 10.3.7.74 10.3.7.74 10.3.7.75 10.3.7.74 10.3.7.75 10.3.7.74 10.3.7.75 10.3.7					
	>>>>Periodical reporting				
10.3.7.53					
>>>>No reporting >>>>No reporting >>>>Traffic volume measurement Object >>>>Traffic volume measurement Quantity >>>>>Traffic volume reporting quantity >>>>>Measurement validity >>>>>Measurement validity >>>>>Nessurement validity >>>>>>>>>Traffic volume measurement reporting criteria >>>>>>>>>>>>>>>>Traffic volume measurement reporting criteria >>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>					
>>>Traffic volume measurement Object OP measurement Object OP Traffic volume measurement quantity OP Traffic volume measurement quantity OP Traffic volume measurement quantity Traffic volume measurement quantity OP Traffic volume reporting quantity 10.3.7.71 >>>>Measurement validity OP Measurement t validity 10.3.7.74 >>>>Measurement t validity 10.3.7.74 >>>>>Possilia volume measurement reporting criteria OP >>>>>Periodical reporting >>>>>No reporting >>>>Quality measurement quantity >>>>CHOICE report criteria OP >>>>>>>>>Periodical reporting >>>>Quality measurement quantity >>>>Cuality measurement reporting criteria OP >>>>>Cuality measurement quantity >>>>>Cuality measurement reporting criteria OP >>>>>Cuality measurement reporting criteria OP	>>>> No reporting				
>>>>Traffic volume measurement OP Traffic volume measurement tobject 10.3.7.70 >>>>Traffic volume measurement quantity OP Traffic volume measurement tologiect volume measurement tologiect volume measurement tologiect volume reporting quantity >>>>>Traffic volume reporting quantity OP Traffic volume reporting quantity >>>>>Measurement validity OP Measurement tologiect volume reporting quantity 10.3.7.74 >>>>>Measurement validity OP Measurement tologiect volume reporting quantity 10.3.7.51 >>>>>>Traffic volume measurement reporting criteria OP Traffic volume measurement treporting criteria 10.3.7.51 >>>>>Periodical reporting Periodical reporting reporting reporting retreira 10.3.7.53 NULL >>>>>No reporting NULL >>>>>Quality measurement quantity measurement reporting criteria 10.3.7.59 OP >>>>>>>Periodical reporting reporting criteria 10.3.7.58 Periodical reporting criteria 10.3.7.58 >>>>>>>>>>No reporting public measurement reporting criteria 10.3.7.53 NULL >>>>>>>>>>>>>>>>>>>>>>>>>>>>>>				NOLL	
measurement Object under the properties of the p		OP		Traffic	
tobject 10.3.7.70					
10.3.7.70	Object			measuremen	
>>>>Traffic volume measurement quantity					
measurement quantity >>>>Traffic volume reporting quantity >>>>Measurement validity >>>>Measurement validity >>>>CHOICE report criteria >>>>>Periodical reporting quantity >>>>CHOICE report criteria >>>>>Periodical reporting quantity >>>>CHOICE report criteria >>>>>Periodical reporting >>>>CHOICE report criteria 10.3.7.72 >>>>>Periodical reporting >>>>> No reporting >>>>Cuality >>>>>CHOICE report criteria 10.3.7.59 >>>>>Cuality measurement reporting criteria 10.3.7.59 >>>>>Cuality measurement reporting criteria 10.3.7.59 >>>>>Cuality measurement reporting criteria 10.3.7.59 >>>>Cuality measurement reporting criteria 10.3.7.59 >>>>Cuality measurement reporting criteria 10.3.7.59 >>>>Cuality measurement reporting criteria 10.3.7.59 >>>>>Cuality measurement reporting criteria 10.3.7.59 >>>>>Cuality measurement reporting criteria 10.3.7.59 >>>>>Cuality measurement reporting criteria 10.3.7.59 >>>>>>>>>>>Due internal >>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>					
quantity measuremen t quantity 10.3.7.71		OP			
t quantity 10.3.7.71 10.3.7.71 10.3.7.71					
10.3.7.71	quantity				
>>>>Traffic volume reporting quantity					
quantity volume reporting quantity 10.3.7.74 >>>>Measurement validity 10.3.7.51 >>>>CHOICE report criteria OP >>>>>Traffic volume measurement reporting criteria 10.3.7.72 >>>>Periodical reporting Periodical reporting criteria 10.3.7.53 >>>>Quality 10.3.7.53 >>>>CHOICE report criteria Periodical reporting criteria 10.3.7.53 >>>>>No reporting NULL >>>>>Cuality measurement quantity 10.3.7.59 >>>>>CHOICE report criteria OP >>>>>Periodical reporting Criteria 10.3.7.59 >>>>>CUality measurement quantity 10.3.7.58 >>>>>Periodical reporting Criteria 10.3.7.58 >>>>>>CUBLITY 10.3.7.58 >>>>>CUBLITY 10.3.7.58 >>>>>CUBLITY 10.3.7.58 >>>>>CUBLITY 10.3.7.58 >>>>>CUBLITY 10.3.7.58 >>>>>CUBLITY 10.3.7.58 >>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>	>>>>Traffic volume reporting	OP			
reporting quantity 10.3.7.74 >>>>Measurement validity >>>>CHOICE report criteria >>>>>Traffic volume measurement reporting criteria >>>>>Periodical reporting >>>>>No reporting >>>>CAuality >>>>CHOICE report criteria >>>>>Periodical reporting >>>>>No reporting >>>>>CAUAlity >>>>>CHOICE report criteria >>>>>>>>>>>>>>>>>Periodical reporting >>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>		-			
quantity 10.3.7.74	4			reporting	
>>>>CHOICE report criteria >>>>CHOICE report criteria >>>>Traffic volume measurement reporting criteria >>>>Periodical reporting >>>>No reporting >>>>Quality >>>>CHOICE report criteria OP Quality measurement quantity 10.3.7.59 >>>>Periodical reporting >>>>No reporting >>>>>CHOICE report criteria OP Quality measurement quantity 10.3.7.59 >>>>>Periodical reporting >>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>					
t validity 10.3.7.51 >>>>CHOICE report criteria >>>>>Traffic volume measurement reporting criteria >>>>Periodical reporting >>>>No reporting >>>>Quality >>>>Quality >>>>Quality measurement reporting criteria >>>>>Quality measurement reporting criteria 10.3.7.59 >>>>>Periodical reportining >>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>					
>>>>CHOICE report criteria >>>>>Traffic volume measurement reporting criteria >>>>>Periodical reporting	>>>>Measurement validity	OP			
>>>>CHOICE report criteria >>>>>Traffic volume measurement reporting criteria					
>>>>Traffic volume measurement reporting criteria reporting criteria >>>>Periodical reporting >>>>No reporting >>>>Quality >>>>Quality >>>>Quality measurement reporting reporting measurement quantity >>>>>Quality measurement reporting reporting measurement quantity >>>>> Quality measurement quantity >>>> Quality measurement quantity neasurement reporting criteria 10.3.7.59 >>>> Periodical report criteria >>>> Quality measurement reporting criteria 10.3.7.58 >>>> Periodical reporting >>>> Periodical reporting reporting reporting criteria 10.3.7.58 >>>> UE internal measurement quantity 10.3.7.79 >>>> UE internal reporting QP UE internal measuremen t quantity 10.3.7.79 >>>> UE internal reporting QP UE internal reporting quantity 10.3.7.82	2112127			10.3.7.51	
measurement reporting criteria volume measuremen t reporting criteria 10.3.7.72 >>>>Periodical reporting Periodical reporting criteria 10.3.7.53 >>>>No reporting NULL >>>>Quality Periodical reporting Periodical reporting criteria 10.3.7.53 >>>>No reporting Periodical reporting Periodical reporting criteria 10.3.7.59 >>>>CHOICE report criteria Periodical reporting Periodical reporting criteria 10.3.7.58 >>>>Periodical reporting Periodical reporting Periodical reporting criteria 10.3.7.53 >>>>No reporting Periodical reporting Periodical reporting Periodical reporting criteria 10.3.7.53 >>>>No reporting Periodical		OP		T ("	
reporting criteria					
t reporting criteria 10.3.7.72 >>>>Periodical reporting Periodical reporting criteria 10.3.7.53 >>>>No reporting NULL >>>Quality Periodical reporting Periodical reporting criteria 10.3.7.53 >>>>Quality Periodical Periodical Periodical reporting Periodical Peri					
>>>>Periodical reporting Periodical reporting criteria 10.3.7.53 >>>>>No reporting NULL >>>Quality >>>Quality measurement quantity quantity >>>>CHOICE report criteria >>>>Periodical reporting nuantity Quality measurement quantity neasurement reporting criteria 10.3.7.59 >>>>Periodical report criteria >>>>Periodical reporting criteria 10.3.7.58 >>>>>Periodical reporting reporting criteria 10.3.7.58 >>>>>Designation of the propertion of the porting criteria 10.3.7.58 >>>>> Periodical reporting reporting reporting criteria 10.3.7.58 >>>>> No reporting >>>> UE internal >>> UE internal measurement quantity 10.3.7.79 >>>> UE internal reporting	reporting criteria				
>>>>Periodical reporting reporting reporting criteria 10.3.7.53 >>>>No reporting NULL >>>Quality Periodical reporting reporting reporting criteria 10.3.7.59 >>>Cauglity Periodical report reporting report					
reporting criteria 10.3.7.53 >>>>No reporting NULL >>>Quality >>>Quality Reasurement quantity 10.3.7.59 >>>>CHOICE report criteria Periodical reporting criteria 10.3.7.58 >>>>Periodical reporting Periodical reporting criteria 10.3.7.53 >>>>No reporting Periodical reporting Periodical reporting criteria 10.3.7.53 >>>>DuE internal Popular Popu				10.3.7.72	
Criteria 10.3.7.53	>>>>Periodical reporting			Periodical	
>>>>No reporting >>>Quality >>>Quality measurement quantity Popular quantity Description Quality measurement quantity					
>>>>No reporting >>>Quality >>>Quality					
>>>Quality >>>>Quality measurement quantity To an approximate the first properties of the first prope	No see setting				
>>>>Quality measurement quantity Section Paragraphic Paragraphic				NULL	
quantity measuremen t quantity 10.3.7.59 >>>>CHOICE report criteria OP >>>>Quality measurement reporting criteria 10.3.7.58 >>>>Periodical reporting Periodical reporting criteria 10.3.7.53 >>>>No reporting NULL >>>UE internal measurement quantity 0P UE internal measuremen t quantity 10.3.7.79 >>>>UE internal reporting OP UE internal reporting quantity 10.3.7.82 >>>>CHOICE report criteria OP		OP		Quality	
t quantity 10.3.7.59 >>>>CHOICE report criteria >>>>Quality measurement reporting criteria 10.3.7.58 >>>>Periodical reporting >>>>No reporting >>>UE internal measurement quantity >>>UE internal reporting >>>>UE internal reporting >>>>UE internal reporting OP		OF		•	
>>>>CHOICE report criteria >>>>>Quality measurement reporting criteria reporting criteria >>>>Periodical reporting Periodical reporting criteria 10.3.7.58 >>>>>Periodical reporting criteria 10.3.7.53 >>>>>No reporting >>>UE internal >>>UE internal measurement quantity >>>UE internal reporting QP UE internal reporting Periodical reporting UUL >>>UE internal measurement quantity 10.3.7.79 UE internal reporting quantity 10.3.7.82	quantity				
>>>>CHOICE report criteria >>>>>Quality reporting criteria Quality measuremen t reporting criteria 10.3.7.58					
>>>>Quality measurement reporting criteria Second	>>>>CHOICE report criteria	OP			
t reporting criteria 10.3.7.58 >>>>Periodical reporting Periodical reporting criteria 10.3.7.53 >>>>No reporting NULL >>>UE internal >>>UE internal measurement quantity UE internal measuremen t quantity 10.3.7.79 >>>>UE internal reporting OP UE internal reporting quantity 10.3.7.82 >>>>CHOICE report criteria OP	>>>>Quality measurement				
criteria 10.3.7.58 >>>>Periodical reporting Periodical reporting criteria 10.3.7.53 >>>>No reporting NULL >>>UE internal >>>>UE internal measurement quantity OP UE internal measurement t quantity 10.3.7.79 >>>>UE internal reporting quantity 10.3.7.82 >>>>CHOICE report criteria OP	reporting criteria				
10.3.7.58					
>>>>Periodical reporting Periodical reporting criteria 10.3.7.53 >>>>No reporting NULL >>>UE internal >>>>UE internal measurement quantity OP UE internal measurement t quantity 10.3.7.79 >>>>UE internal reporting quantity reporting quantity 10.3.7.82					
reporting criteria 10.3.7.53 >>>>No reporting NULL >>>UE internal >>>UE internal measurement quantity UE internal measuremen t quantity 10.3.7.79 >>>>UE internal reporting quantity 10.3.7.82 >>>>CHOICE report criteria OP	>>>> Pariodical reporting				
criteria 10.3.7.53 >>>>No reporting NULL >>>UE internal >>>>UE internal measurement quantity OP UE internal measuremen t quantity 10.3.7.79 >>>>UE internal reporting quantity reporting quantity 10.3.7.82 >>>>CHOICE report criteria OP					
>>>>No reporting >>>UE internal >>>UE internal measurement quantity OP UE internal measurement t quantity 10.3.7.79 >>>>UE internal reporting quantity OP UE internal reporting quantity 10.3.7.82					
>>>>No reporting >>>UE internal >>>UE internal measurement quantity OP UE internal measuremen t quantity 10.3.7.79 >>>>UE internal reporting quantity OP UE internal reporting quantity 10.3.7.82					
>>>UE internal >>>>UE internal measurement quantity OP UE internal measuremen t quantity 10.3.7.79 >>>>UE internal reporting quantity OP UE internal reporting quantity 10.3.7.82 >>>>CHOICE report criteria OP	>>>>No reporting				
quantity measuremen t quantity 10.3.7.79 >>>>UE internal reporting quantity OP UE internal reporting quantity 10.3.7.82 >>>>CHOICE report criteria OP	>>>UE internal				
t quantity 10.3.7.79 >>>>UE internal reporting quantity OP UE internal reporting quantity 10.3.7.82 >>>>CHOICE report criteria OP		OP			
>>>UE internal reporting quantity OP UE internal reporting reporting quantity 10.3.7.79 UE internal reporting quantity 10.3.7.82	quantity				
>>>UE internal reporting quantity UE internal reporting quantity 10.3.7.82 >>>>CHOICE report criteria OP					
quantity reporting quantity 10.3.7.82	115 (at 1	OD	1		
quantity 10.3.7.82 >>>>CHOICE report criteria OP		OP			
10.3.7.82	quantity				
>>>>CHOICE report criteria OP					
	>>>>CHOICE report criteria	OP		10.0.7.02	
r>>>>∪⊑ internal measurement i lu⊨internal l	>>>>UE internal measurement	1		UE internal	

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
reporting criteria			measuremen	
			t reporting	
			criteria	
			10.3.7.80	
>>>>Periodical reporting			Periodical	
			reporting	
			criteria	
			10.3.7.53	
>>>>No reporting			NULL	
>>>UE positioning				
>>>>LCS reporting quantity	OP		LCS	
			reporting	
			quantity	
			10.3.7.111	
>>>>CHOICE report criteria	OP			
>>>>LCS reporting criteria			LCS	
			reporting	
			criteria	
			10.3.7.110	
>>>>Periodical reporting			Periodical	
			reporting	
			criteria	
			10.3.7.53	
>>>>No reporting				
Radio Bearer Information				
Elements				
>Predefined configuration status	OP		Predefined	
information			configuration	
			status	
			information	
			10.3.4.5a	
>Signalling RB information list	MP	1 to		For each signalling radio
		<maxsrbs< td=""><td></td><td>bearer</td></maxsrbs<>		bearer
		etup>		
>>Signalling RB information	MP		Signalling	
			RB	
			information	
			to setup	
			10.3.4.24	
>RAB information list	OP	1 to		Information for each RAB
		<maxrabs< td=""><td></td><td></td></maxrabs<>		
		etup>		
>>RAB information	MP		RAB	
			information	
			to setup	
			10.3.4.10	
Transport Channel				
Information Elements				
Uplink transport channels				
>UL Transport channel	OP		UL Transport	
information common for all			channel	
transport channels			information	
			common for	
			all transport	
			channels	
			10.3.5.24	
>UL transport channel	OP	1 to		
information list		<maxtrch< td=""><td></td><td></td></maxtrch<>		
	L	>		
>>UL transport channel	MP		Added or	
information			reconfigured	
			UL TrCH	
			information	
	OP		10.3.5.2	
>CHOICE mode				

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
>>FDD				
>>>CPCH set ID	OP		CPCH set ID 10.3.5.5	
>>>Transport channel information for DRAC list	OP	1 to <maxtrch ></maxtrch 		
>>>>DRAC static information	MP		DRAC static information 10.3.5.7	
>>TDD				(no data)
Downlink transport channels				
>DL Transport channel information common for all transport channels	OP		DL Transport channel information common for all transport channels 10.3.5.6	
>DL transport channel information list	OP	1 to <maxtrch ></maxtrch 		
>>DL transport channel information	MP		Added or reconfigured DL TrCH information 10.3.5.1	
PhyCH information elements				
>TPC Combination Info list	OP	1 to <maxrl></maxrl>		
>>Primary CPICH info	MP		Primary CPICH info 10.3.6.60	
>>TPC combination index	MP		TPC combination index 10.3.6.85	
Other Information elements				
>Measurement report	OP		MEASUREM ENT REPORT 10.2.1.9	
>Failure cause	OP		Failure cause 10.3.3.13	Diagnostics information related to an earlier SRNC Relocation request (see NOTE 2 in 14.12.0a)
>Protocol error information	CV-ProtErr		Protocol error information 10.3.8.12	

Multi Bound	Explanation
MaxNoOfMeas	Maximum number of active measurements, upper
	limit 16

Condition	Explanation
Setup	The IE is mandatory present when the IE Measurement command has the value "Setup", otherwise the IE is not needed.
Ciphering	The IE is mandatory present when the IE Ciphering Status has the value "started" and the ciphering counters need not be reinitialised, otherwise the IE is not needed.
IP	The IE is mandatory present when the IE Integrity protection status has the value "started" and the integrity protection counters need not be reinitialised, otherwise the IE is not needed.
ProtErr	This IE is mandatory present if the IE "Protocol error indicator" is included and has the value "TRUE". Otherwise it is not needed.
SRB1	The IE is mandatory present for RB1. Otherwise it is not needed.

14.12.4.3 Void

14.12.4.4 RFC 3095 CONTEXT INFO

This RRC message is sent between network nodes in SRNS relocation. It is used to transfer the compressor and decompressor context information of the RFC 3095 protocol.

Direction: source RNC \rightarrow target RNC

999

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
RFC 3095 context	MP	1 to <maxrball RABs></maxrball 			REL-5
>RB identity	MP	IVAD32	RB identity 10.3.4.16		REL-5
>RFC 3095 context list	MP	1 to <maxrfc3 095-CID></maxrfc3 			REL-5
>>Downlink RFC 3095 context	OP				REL-5
>>>Downlink RFC 3095 context identity	MP		Integer (016383)		REL-5
>>>DL_MODE	MP		Enumerated (u, o, r)	RFC 3095 mode in downlink before SRNS relocation.	REL-5
>>>REF_IR	MP		Octet string (13000)	The RTP IR header (see section 5.7.7 of RFC3095 for detailed format) corresponding to the oldest header in the compressor sliding window.	REL-5
>>>REF_TIME	OP		Integer (04294967 295)	Arrival time (at the compressor) of REF_IR in milliseconds. See sections 4.5.4 and 6.5.1 of RFC3095.	REL-5
>>>CURR_TIME	OP		Integer (04294967 295)	Current time in milliseconds. See section 6.5.1 of RFC3095.	REL-5
>>>SYN_OFFSET_ID	OP		Integer (065535)	Last synchronized offset of IP-ID. See section 4.5.5 and 6.5.1 of RFC3095 (termed "Offset_I").	REL-5
				It is related to the compression and decompression of IP-ID and is the synchronized offset between the IP-ID value and the SN value (in the same header) during the last SO state before the relocation procedure.	
>>>SYN_SLOPE_TS	OP		Integer (04294967 295)	Last synchronized slope of TS. See sections 5.5.1.2 and 5.7 of RFC3095.	REL-5
				In SO state, TS(n) = TS(m) + (n-m) * SYN_SLOPE_TS, where n and m are, the RTP SN of the current and	

				the reference	
				packet,	
				respectively. The unit of	
				SYN_SLOPE_TS	
				depends on	
				whether TS is	
				scaled before	
				compression or	
				not.	
>>>DYN_CHANGED	MP		Boolean	Information	REL-5
				whether dynamic	
				fields other than RTP SN, RTP TS	
				and IP-ID have	
				changed in the	
				headers that are	
				stored in the	
				sliding window.	
				Set to TRUE if	
				changed and	
				FALSE if not	
>>Uplink RFC 3095 context	OP			changed.	REL-5
>>Uplink RFC 3095 context	MP		Integer		REL-5
identity	'''		(016383)		
>>>UL_MODE	MP		Enumerated	RFC 3095 mode	REL-5
			(u, o, r)	in uplink	
>>>REF_IR	MP		Octet string	The RTP IR	REL-5
			(13000)	header (see	
				section 5.7.7 of IETF RFC3095 for	
				detailed format)	
				corresponding to	
				the last correctly	
				decompressed	
				header.	
>>>REF_TIME	OP		Integer	Arrival time (at the	REL-5
			(04294967	decompressor) of	
			295)	REF_IR in milliseconds.	
				See sectionss	
				4.5.4 and 6.5.1 of	
				RFC3095.	
>>>CURR_TIME	OP		Integer	Current time in	REL-5
			(04294967	milliseconds. See	
			295)	section 6.5.1 of	
SSSVN OFFSET ID	OP	1	Intogor	RFC3095. Last synchronized	REL-5
>>>SYN_OFFSET_ID	J UF		Integer (065535)	offset of IP-ID.	KEL-0
			(00000)	See sectionss	
				4.5.5 and 6.5.1 of	
				RFC3095	
				(termed"Offset_I")	
				It is uplated to the	
				It is related to the	
				compression and decompression of	
				IP-ID and is the	
				synchronized	
				offset between the	
				IP-ID value and	
				the SN value (in	
				the same header)	
				during the last SO	
				state before the	
1	1	1	1	relocation	l

			procedure.	
>>>SYN_SLOPE_TS	OP	Integer (04294967 295)	Last synchronized slope of TS. See sectionss 5.5.1.2 and 5.7 of RFC3095. In SO state, TS(n) = TS(m) + (n-m) * SYN_SLOPE_TS, where n and m are, the RTP SN of the current and the reference packet, respectively. The unit of SYN_SLOPE_TS depends on whether TS is scaled before compression or not.	REL-5
>>>REF_SN_1	OP	Integer (065535)	Corresponds to the RTP Sequence Number of the predecessor of the latest RTP packet. This could be used to perform local repair of context by decompressor in U or O mode (see 'ref - 1' in section5.3.2.2.5 in IETF RFC3095 for further explanation).	REL-5

14.13 Void

14.14 Versatile Channel Assignment Mode (VCAM) mapping rule (FDD only)

When Versatile Channel Assignment Method (VCAM) is used in the CPCH procedure, the following mapping rules shall be used to specify one PCPCH.

If the number of PCPCHs is less than or equal to 16, there is a one to one mapping between the CA index and the PCPCH index. Thus a suitable AP signature (and/or AP sub-channel) number is transmitted for the required spreading factor based on the broadcast system information, and the assigned PCPCH index (having the requested spreading factor) corresponds to the received CA index.

When the number of PCPCHs is greater than 16, a combination of an AP signature (and/or AP sub-channel) number and a CA signature number specifies one PCPCH as follows:

In VCAM mapping rule, a combination of an AP signature (and/or AP sub-channel) number and a CA signature number specifies one PCPCH. In a CPCH set, there are K available PCPCHs which are numbered k=0,1,..., K-1, and there are K available Minimum Spreading Factor A_r , r=0,1,...,K-1, that a UE can request and use. The maximum available number of PCPCHs and the number of available AP signatures (and/or AP sub-channels) for A_r are denoted as PO_r and S_r ,

respectively, for r=0,1,...,R-1. Let P_r be equal to 16 if $P0_r$ is less than 16 and to $P0_r$ otherwise. T_r represents the number of CA signatures for A_r , which are needed for specifying PCPCH. The default value of T_r is 16.

 S_r always satisfies $S_r \ge \min\{s : s \in N, s \times T_r \ge P_r\}$, where N is the set of positive integers.

The list of available AP signatures (and/or AP sub-channels) for each A_r is renumbered from signature index 0 to signature index S_r -1, starting with the lowest AP signature (and/or AP sub-channel) number, and continuing in sequence, in the order of increasing signature numbers.

Then for given AP signature (and/or AP sub-channel) number and CA signature number, the number *k* that signifies the assigned PCPCH is obtained as:

$$k = \{[(i+n) \bmod S_r] + j \times S_r\} \bmod P_r$$

where i (i=0,1,..., S_r -1) is the AP signature (and/or AP sub-channel) index for A_r , j (j=0,1,...,min(P_r , T_r)-1) is the CA signature number for A_r and n is a nonnegative integer which satisfies

$$n \times M_r \times S_r \le i + j \times S_r < (n+1) \times M_r \times S_r$$
 where $M_r = \min\{m : m \in N, (m \times S_r) \bmod P_r = 0\}$.

An example of the above mapping rule is shown in [38].

Annex A (informative): USIM parameters

A.1 Introduction

This annex contains recommendations about the RRC parameters to be stored in the USIM.

A.2 Ciphering information

Information Element/Group name	Need	Multi	Type and reference	Semantics description
Cipher key for each CN domain	MP	<1 to maxCNDo mains>		Cipher key is described in [40].
>CK	MP		Bit string (128)	
Integrity key for each CN domain	MP	<1 to maxCNDo mains>		Integrity key is described in [40].
>IK	MP		Bit string (128)	
THRESHOLD	MP		Bit string (20)	
START value for each CN domain	MP	<1 to maxCNDo mains>		START value is described in [40].
>START	MP		Bit string (20)	
KSI, Key set identifier for each CN domain	MP	<1 to maxCNDo mains>		Key set identifier is described in [40].
>KSI	MP		Bit string (3)	

A.3 Frequency information

Neighbour cell list.

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
FDD cell list	OP	<1 to maxFDDFr eqList>			
>UARFCN uplink (Nu)	OP		Integer(016 383)	[21] If IE not present, default duplex distance of 190 MHz shall be used.	
>UARFCN downlink (Nd)	MP		Integer(0 16383)	[21]	
>Primary scrambling code	OP	<1 to maxFDDFr eqCellList>	Primary CPICH info 10.3.6.60		
3.84 Mcps TDD cell list	OP	<1 to maxTDDFr eqList>			
>UARFCN (Nt)	MP		Integer(0 16383)	[22]	
>Cell parameters ID	OP	<1 to maxTDDFr	Integer (0127)	The Cell parameters ID is	

Information Element/Group name	Need	Multi	Type and reference	Semantics description	Version
		eqCellList>		described in [32].	
1.28 Mcps TDD cell list	OP	<1 to maxTDDFr eqList>			REL-4
>UARFCN (Nt)	MP		Integer(0 16383)	[22]	REL-4
>Cell parameters ID	OP	<1 to maxTDDFr eqCellList>	Integer (0127)	The Cell parameters ID is described in [32].	REL-4
GSM Neighbour cell list	OP				
>GSM neighbour cell info	MP	<1 to maxGSMC ellList>			
>>BSIC	MP				
>>BCCH ARFCN	MP				

A.4 Multiplicity values and type constraint values

Constant	Explanation	Value
Ciphering information		
maxCNDomains	Maximum number of CN domains	4
Frequency information		
maxFDDFreqList	Maximum number of FDD carrier frequencies to be stored in USIM	4
maxTDDFreqList	Maximum number of TDD carrier frequencies to be stored in USIM	4
maxFDDFreqCellList	Maximum number of neighbouring FDD cells on one carrier to be stored in USIM	32
maxTDDFreqCellList	Maximum number of neighbouring TDD cells on one carrier to be stored in USIM	32
maxGSMCellList	Maximum number of GSM cells to be stored in USIM	32

Annex B (informative): Description of RRC state transitions

This annex contains Stage 2 description of RRC states and state transitions.

B.1 RRC states and state transitions including GSM

After power on, the UE stays in Idle Mode until it transmits a request to establish an RRC Connection. In Idle Mode the connection of the UE is closed on all layers of the access stratum. In Idle Mode the UE is identified by non-access stratum identities such as IMSI, TMSI and P-TMSI. In addition, the UTRAN has no own information about the individual Idle Mode UEs, and it can only address e.g. all UEs in a cell or all UEs monitoring a paging occasion. The UE behaviour within this mode is described in [4].

The UTRA RRC Connected Mode is entered when the RRC Connection is established. The UE is assigned a radio network temporary identity (RNTI) to be used as UE identity on common transport channels.

The RRC states within UTRA RRC Connected Mode reflect the level of UE connection and which transport channels that can be used by the UE.

For inactive stationary data users the UE may fall back to PCH on both the Cell and URA levels. That is, upon the need for paging, the UTRAN checks the current level of connection of the given UE, and decides whether the paging message is sent within the URA, or should it be sent via a specific cell.

B.2 Transition from Idle Mode to UTRA RRC Connected Mode

The transition to the UTRA RRC Connected Mode from the Idle Mode can only be initiated by the UE by transmitting a request for an RRC Connection. The event is triggered either by a paging request from the network or by a request from upper layers in the UE.

When the UE receives a message from the network that confirms the RRC connection establishment, the UE enters the CELL_FACH or CELL_DCH state of UTRA RRC Connected Mode.

In the case of a failure to establish the RRC Connection the UE goes back to Idle Mode. Possible causes are radio link failure, a received reject response from the network or lack of response from the network (timeout).

B.2.1 Transitions for Emergency Calls

Refer to [4] for all states and procedures referred to in this subclause. When UE leaves idle mode from state *Camped on any cell* in order to make an emergency call, moving to state *Connected mode (emergency calls only)*, the UE shall attempt to access the current serving cell. If the access attempt to the serving cell fails the UE shall use the *Cell Reselection* procedure. If no acceptable cell is found, the UE shall use the *Any cell selection*. When returning to idle mode, the UE shall use the procedure *Cell selection when leaving connected mode* in order to find an acceptable cell to camp on, state *Camped on any cell*.

B.3 UTRA RRC Connected Mode States and Transitions

B.3.1 CELL_DCH state

The CELL_DCH state is characterised by

- A dedicated physical channel is allocated to the UE in uplink and downlink.
- The UE is known on cell level according to its current active set.
- Dedicated transport channels, downlink and uplink (TDD) shared transport channels, and a combination of these transport channels can be used by the UE.

The CELL_DCH-state is entered from the Idle Mode through the setup of an RRC connection, or by establishing a dedicated physical channel from the CELL_FACH state.

A PDSCH may be assigned to the UE in this state, to be used for a DSCH. In TDD a PUSCH may also be assigned to the UE in this state, to be used for a USCH. If PDSCH or PUSCH are used for TDD, a FACH transport channel may be assigned to the UE for reception of physical shared channel allocation messages.

B.3.1.1 Transition from CELL DCH to Idle Mode

Transition to Idle Mode is realised through the release of the RRC connection.

B.3.1.2 Transition from CELL_DCH to CELL_FACH state

Transition to CELL_FACH state occurs when all dedicated channels have been released, which may be

a) via explicit signalling (e.g. PHYSICAL CHANNEL RECONFIGURATION, RADIO BEARER RECONFIGURATION, RADIO BEARER RELEASE, RADIO BEARER SETUP, TRANSPORT CHANNEL RECONFIGURATION, etc.).

at the end of the time period for which the dedicated channel was allocated (TDD)

B.3.1.3 Transition from CELL_DCH to CELL_PCH state

Transition to CELL_PCH state occurs via explicit signalling (e.g. PHYSICAL CHANNEL RECONFIGURATION, RADIO BEARER RECONFIGURATION, RADIO BEARER RELEASE, RADIO BEARER SETUP, TRANSPORT CHANNEL RECONFIGURATION, etc.).

B.3.1.4 Transition from CELL_DCH to URA_PCH state

Transition to URA_PCH state occurs via explicit signalling (e.g. PHYSICAL CHANNEL RECONFIGURATION, RADIO BEARER RECONFIGURATION, RADIO BEARER RELEASE, RADIO BEARER SETUP, TRANSPORT CHANNEL RECONFIGURATION, etc.).

B.3.1.5 Radio Resource Allocation tasks (CELL_DCH)

For the DCH, several physical channel allocation strategies may be applied. The allocations can be either permanent (needing a DCH release message) or based on time or amount-of-data.

Resource allocation can be done separately for each packet burst with fast signalling on the DCH

For each radio frame the UE and the network indicate the current data rate (in uplink and downlink respectively) using the transport format combination indicator (TFCI). However, in TDD, DCH and DSCH or USCH may be mapped on different CCTrCHs, their TFCI are totally independent. DCH transmission is not modified by the simultaneous existence of DSCH/USCH. If the configured set of combinations (i.e. transport format set for one transport channel) are found to be insufficient to retain the QoS requirements for a transport channel, the network initiates a reconfiguration of the transport format set (TFS) for that transport channel. This reconfiguration can be done during or in between data transmission. Further, the network can reconfigure the physical channel allowing an increase or decrease of the peak data rate.

For the uplink data transmission, the UE reports the observed traffic volume to the network in order for the network to re-evaluate the current allocation of resources. This report contains e.g. the amount of data to be transmitted or the buffer status in the UE.

B.3.1.6 RRC Connection mobility tasks (CELL_DCH)

Depending on the amount and frequency of data macrodiversity (soft handover) may or may not be applied.

The RRC Connection mobility is handled by measurement reporting, soft handover and Timing re-initialised or Timing-maintained hard handover procedures.

B.3.1.7 UE Measurements (CELL DCH)

The UE performs measurements and transmit measurement reports according to the measurement control information.

The UE uses the connected mode measurement control information received in other states until new measurement control information has been assigned to the UE.

B.3.1.8 Acquisition of system information (CELL DCH)

FDD UEs with certain capabilities reads system information broadcast on FACH.

TDD UEs reads the BCH to acquire valid system information. For each acquisition, the UE may need different combinations of system information broadcast on BCH. The scheduling on the broadcast channel is done in such way that the UE knows when the requested information can be found.

B.3.2 CELL FACH state

The CELL_FACH state is characterised by:

- No dedicated physical channel is allocated to the UE.
- The UE continuously monitors a FACH in the downlink.
- The UE is assigned a default common or shared transport channel in the uplink (e.g. RACH) that it can use anytime according to the access procedure for that transport channel.
- The position of the UE is known by UTRAN on cell level according to the cell where the UE last made a cell update.
- In TDD mode, one or several USCH or DSCH transport channels may have been established.

B.3.2.1 Transition from CELL_FACH to CELL_DCH state

A transition occurs, when a dedicated physical channel is established via explicit signalling (e.g. PHYSICAL CHANNEL RECONFIGURATION, RADIO BEARER RECONFIGURATION, RADIO BEARER RELEASE, RADIO BEARER SETUP, TRANSPORT CHANNEL RECONFIGURATION, etc.).

B.3.2.2 Transition from CELL FACH to CELL PCH state

The transition occurs when UTRAN orders the UE to move to CELL_PCH state, which is done via explicit signalling (e.g. CELL UPDATE CONFIRM, RADIO BEARER RECONFIGURATION, etc.).

B.3.2.3 Transition from CELL FACH to Idle Mode

Upon release of the RRC connection, the UE moves to the idle mode.

B.3.2.4 Transition from CELL FACH to URA PCH State

The transition occurs when UTRAN orders the UE to move to URA _PCH state, which is done via explicit signalling (e.g. URA UPDATE CONFIRM, RADIO BEARER RECONFIGURATION, etc.).

B.3.2.5 Radio Resource Allocation Tasks (CELL_FACH)

In the CELL_ FACH state the UE will monitor an FACH. It is enabled to transmit uplink control signals and it may be able to transmit small data packets on the RACH.

The network can assign the UE transport channel parameters (e.g. transport format sets) in advance, to be used when a DCH is used. Upon assignment of the physical channel for DCH, the UE moves to CELL_DCH state and uses the pre-assigned TFS for the DCH.

If no UE dedicated physical channel or transport channel configuration has been assigned, the UE uses the common physical channel and transport channel configuration according to the system information.

For the uplink data transmission, the UE reports the observed traffic volume to the network in order for the network to re-evaluate the current allocation of resources. This report contains e.g. the amount of data to be transmitted or the buffer status in the UE.

When there is either user or control data to transmit, a selection procedure determines whether the data should be transmitted on a common transport channel, or if a transition to CELL_DCH should be executed. The selection is dynamic and depends on e.g. traffic parameters (amount of data, packet burst frequency).

In FDD mode, the UTRAN can assign CPCH resources to the UE in CELL_FACH state. When CPCH resources are assigned, the UE will continue to monitor FACHs. When CPCH resources are assigned, the UE will use CPCH for all uplink traffic in accordance with RB mapping.

In FDD mode, UTRAN may configure the UE to provide CPCH measurement reports of traffic volume on each CPCH channel used. With these measures, the UTRAN can reallocate network resources on a periodic basis. The UTRAN allocates CPCH Sets to each cell and assigns UEs to one of the cell's CPCH Sets. The UEs can dynamically access the CPCH resources without further UTRAN control.

In the TDD mode, the UTRAN can assign USCH / DSCH resources to the UE in CELL_FACH state. When USCH / DSCH resources are assigned, the UE will continue to monitor FACHs, depending on the UE capability. The UE may use the USCH / DSCH to transmit signalling messages or user data in the uplink and / or the downlink using USCH and / or DSCH when resources are allocated to cell and UE is assigned use of those USCH / DSCH.

For the uplink data transmission on USCH the UE reports to the network the traffic volume (current size of RLC data buffers), The UTRAN can use these measurement reports to re-evaluate the current allocation of the USCH / DSCH resources.

B.3.2.6 RRC Connection mobility tasks (CELL_FACH)

In this state the location of the UE is known on cell level. A cell update procedure is used to report to the UTRAN, when the UE selects a new cell to observe the common downlink channels of a new cell. Downlink data transmission on the FACH can be started without prior paging.

The UE monitors the broadcast channel and system information on BCCH of its own and neighbour cells and from this the need for the updating of cell location is identified.

The UE performs cell reselection and upon selecting a new UTRA cell, it initiates a cell update procedure. Upon selecting a new cell belonging to another radio access system than UTRA, the UE enters idle mode and makes an access to that system according to its specifications.

B.3.2.7 UE Measurements (CELL_FACH)

The UE performs measurements and transmit measurement reports according to the measurement control information.

By default, the UE uses the measurement control information broadcast within the system information. However, for measurements for which the network also provides measurement control information within a MEASUREMENT CONTROL message, the latter information takes precedence.

B.3.2.8 Transfer and update of system information (CELL_FACH)

The UE reads the BCH to acquire valid system information. For each acquisition, the UE may need different combinations of system information broadcast on BCH. The scheduling on the broadcast channel is done in such way that the UE knows when the requested information can be found.

When the system information is modified, the scheduling information is updated to reflect the changes in system information transmitted on BCH. The new scheduling information is broadcast on FACH in order to inform UEs about the changes. If the changes are applicable for the UE, the modified system information is read on BCH.

B.3.3 CELL PCH state

The CELL_PCH state is characterised by:

- No dedicated physical channel is allocated to the UE.
- The UE selects a PCH with the algorithm specified in subclause 8.5.19, and uses DRX for monitoring the selected PCH via an associated PICH.
- No uplink activity is possible.
- The position of the UE is known by UTRAN on cell level according to the cell where the UE last made a cell update in CELL_FACH state.

The DCCH logical channel cannot be used in this state. If the network wants to initiate any activity, it needs to make a paging request on the PCCH logical channel in the known cell to initiate any downlink activity.

B.3.3.1 Transition from CELL PCH to CELL FACH state

The UE is transferred to CELL_FACH state:

- a) by paging from UTRAN (PAGING TYPE1 message)
- b) through any uplink access

B.3.3.2 Radio Resource Allocation Tasks (CELL_PCH)

In CELL_PCH state no resources have been granted for data transmission. For this purpose, a transition to another state has to be executed.

The UE may use Discontinuous Reception (DRX) in order to reduce power consumption. When DRX is used the UE needs only to receive at one paging occasion per DRX cycle. The UE may be instructed to use a specific DRX cycle length by the network. The UE determines its paging occasions in the same way as for Idle Mode, see [4].

B.3.3.3 RRC Connection mobility tasks (CELL_PCH)

In the CELL_PCH state, the UE mobility is performed through cell reselection procedures, which may differ from the one defined in [4].

The UE performs cell reselection and upon selecting a new UTRA cell, it moves to CELL_FACH state and initiates a cell update procedure in the new cell. After the cell update procedure has been performed, the UE changes its state back to CELL_PCH state if neither the UE nor the network has any more data to transmit.

Upon selecting a new cell belonging to another radio access system than UTRA, the UE enters idle mode and make an access to that system according to its specifications.

In case of low UE activity, UTRAN may want to reduce the cell-updating overhead by ordering the UE to move to the URA_PCH State. This transition is made via the CELL_FACH state. UTRAN may apply an inactivity timer, and optionally, a counter, which counts the number of cell updates e.g. UTRAN orders the UE to move to URA_PCH when the number of cell updates has exceeded certain limits (network parameter).

B.3.3.4 UE Measurements (CELL_PCH)

The UE performs measurements and transmit measurement reports according to the measurement control information.

The UE uses the measurement control information according to the system information when no UE dedicated measurement control information has been assigned.

B.3.3.5 Transfer and update of system information (CELL_PCH)

The UE reads the BCH to acquire valid system information. For each acquisition, the UE may need different combinations of system information broadcast on BCH. The scheduling on the broadcast channel is done in such way that the UE knows when the requested information can be found.

B.3.4 URA PCH State

The URA_PCH state is characterised by:

- No dedicated channel is allocated to the UE.
- The UE selects a PCH with the algorithm specified in subclause 8.5.19, and uses DRX for monitoring the selected PCH via an associated PICH.
- No uplink activity is possible.
- The location of the UE is known on UTRAN Registration area level according to the URA assigned to the UE during the last URA update in CELL_FACH state.

The DCCH logical channel cannot be used in this state. If the network wants to initiate any activity, it needs to make a paging request on the PCCH logical channel within the URA where the location of the UE is known. If the UE needs to transmit anything to the network, it goes to the CELL_FACH state. The transition to URA_PCH State can be controlled with an inactivity timer, and optionally, with a counter that counts the number of cell updates. When the number of cell updates has exceeded certain limits (a network parameter), then the UE changes to the URA_PCH State.

URA updating is initiated by the UE, which, upon the detection of the Registration area, sends the network the Registration area update information on the RACH of the new cell.

B.3.4.1 Transition from URA_PCH State to CELL_FACH State (URA_PCH)

Any activity causes the UE to be transferred to CELL_FACH State.

- a) Uplink access is performed by RACH.
- b) by paging from UTRAN (PAGING TYPE1 message).

NOTE: The release of an RRC connection is not possible in the URA_PCH State. The UE will first move to CELL_FACH State to perform the release signalling.

B.3.4.2 Radio Resource Allocation Tasks (URA_PCH)

In URA_PCH State no resources have been granted for data transmission. For this purpose, a transition to CELL_FACH State has to be executed.

The UE may use Discontinuous Reception (DRX) in order to reduce power consumption. When DRX is used the UE needs only to receive at one paging occasion per DRX cycle. The UE may be instructed to use a specific DRX cycle length by the network. The UE determines its paging occasions in the same way as for Idle Mode, see [4].

B.3.4.3 RRC Connection mobility tasks (URA_PCH)

In URA_PCH State the location of a UE is known on UTRAN Registration area level.

In this state, the UE mobility is performed through URA reselection procedures, which may differ from the definitions in [4]. The UE performs cell reselection and upon selecting a new UTRA cell belonging to a URA that does not match the URA used by the UE, the UE moves to CELL_FACH state and initiates a URA update towards the network. After the URA update procedure has been performed, the UE changes its state back to URA_PCH state if neither the UE nor the network has any more data to transmit.

Upon selecting a new cell belonging to another radio access system than UTRA, the UE enters idle mode and makes an access to that system according to its specifications.

B.3.4.4 UE Measurements (URA PCH)

The UE performs measurements and transmit measurement reports according to the measurement control information.

The UE uses the measurement control information according to the system information when no UE dedicated measurement control information has been assigned.

B.3.4.5 Transfer and update of system information (URA_PCH)

The same mechanisms to transfer and update system information as for state CELL_PCH are applicable for UEs in URA_PCH state.

B.3.5 States and Transitions for Cell Reselection in URA_PCH, CELL_PCH, and CELL_FACH




Figure B.3.5-1: UTRA RRC Connected mode cell reselection for URA_PCH, CELL_PCH, and CELL_FACH

In some states the UE performs cell reselection procedures. The UE selects a suitable cell (defined in [4]) and radio access technology based on connected mode radio measurements and cell reselection criteria.

Figure B.3.5-1 shows the states and procedures in the cell reselection process in connected mode.

When a cell reselection is triggered, the UE evaluates the cell reselection criteria based on radio measurements, and if a better cell is found that cell is selected, procedure Cell reselection (see [4]). If the change of cell implies a change of radio access technology, the RRC connection is released, and the UE enters idle mode of the other RAT. If no suitable cell is found in the cell reselection procedure, the UE eventually enters idle mode.

When an Initial cell reselection is triggered, the UE shall use the Initial cell reselection procedure (see [4]) to find a suitable cell. One example where this procedure is triggered is at radio link failure, where the UE may trigger an initial cell reselection in order to request re-establishment of the RRC connection. If the UE is unable to find a suitable cell, the UE eventually enters idle mode.

B.4 Inter-RAT handover with CS domain services

When using CS domain services, UTRAN is using an Inter-Radio access system Handover Procedure and GSM is using a Handover procedure for the transition from UTRA RRC Connected Mode to GSM Connected Mode.

B.5 Inter-RAT handover with PS domain services

When using PS domain services, the UE initiates cell reselection from a GSM/GPRS cell to a UTRAN cell and then uses the RRC Connection Establishment procedure for the transition to UTRA RRC Connected mode.

When the RRC Connection is established from Idle Mode (GPRS Packet Idle Mode) the RRC CONNECTION REQUEST message contains an indication, that UTRAN needs to continue an already established GPRS UE context from the CN. This indication allows UTRAN to e.g. prioritise the RRC CONNECTION REQUEST from the UE.

In UTRA RRC connected mode UTRAN is using UE or network initiated cell reselection to change from a UTRAN cell to a GSM/GPRS cell. If the cell reselection was successful the UE enters Idle Mode (GPRS Packet Idle Mode). The UE sends a packet channel request from Idle Mode (GPRS Packet Idle mode) to establish a Temporary Block flow and enter GPRS Packet Transfer Mode. In the GPRS Packet Transfer Mode the UE sends a RA Update request message. The RA Update Request message sent from the UE contains an indication that GSM/GPRS need to continue an already established UTRAN UE context from the CN. This means that the RA Update request is always sent for the transition from UTRA RRC Connected Mode to GSM/GPRS regardless if the RA is changed or not.

NOTE: The reason for using RA update instead of a new message is to reduce the impact on the existing GSM/GPRS specification.

B.6 Inter-RAT handover with simultaneous PS and CS domain services

B.6.1 Inter-RAT handover UTRAN to GSM / BSS

For a UE in CELL_DCH state using both CS and PS Domain services the Inter-RAT handover procedure is based on measurement reports from the UE but initiated from UTRAN.

The UE performs the Inter-RAT handover from UTRA RRC Connected Mode to GSM Connected Mode first. When the UE has sent handover complete message to GSM / BSS the UE initiates a temporary block flow towards GPRS and sends a RA update request.

If the Inter-RAT handover from UTRA RRC Connected Mode to GSM Connected Mode was successful the handover is considered as successful regardless if the UE was able to establish a temporary block flow or not towards GPRS.

In case of Inter-RAT handover failure the UE has the possibility to go back to UTRA RRC Connected Mode and reestablish the connection in the state it originated from.

B.6.2 Inter-RAT handover GSM / BSS to UTRAN

For a UE in GSM Connected Mode using both CS and PS domain services the Inter-RAT handover procedure is based on measurement reports from the UE but initiated from GSM / BSS.

The UE performs the Inter-RAT handover from GSM Connected Mode to UTRA RRC Connected Mode.

In UTRA RRC Connected Mode both services are established in parallel.

If the Inter-RAT handover from GSM Connected mode to UTRA RRC Connected Mode was successful the handover is considered as successful.

In case of Inter-RAT handover failure the UE has the possibility to go back to GSM Connected Mode and re-establish the connection in the state it originated from.

Annex C (informative): Change history

_	1			_	Change history		
Date	TSG #	TSG Doc.	CR	Rev	Subject/Comment	Old	New
10/1999	RP-05	RP-99524	-		Approved at TSG-RAN #5 and placed under Change Control	-	3.0.0
12/1999	RP-06 RP-06	RP-99650 RP-99654	001 005	1	Modification of RRC procedure specifications Introduction of Information Element for Power Control Algorithm	3.0.0	3.1.0
	RP-06	RP-99654	007	1	RRC parameters for SSDT	3.0.0	3.1.0
	RP-06	RP-99656	007	1	•	3.0.0	3.1.0
					Inclusion of information elements for integrity protection		
	RP-06	RP-99656	010	2	Security mode control procedure	3.0.0	3.1.0
	RP-06	RP-99656	011	3	Updates of the system information procedure	3.0.0	3.1.0
	RP-06	RP-99656	012	2	Inter-frequency measurements and reporting	3.0.0	3.1.0
	RP-06	RP-99656	013	1	Inter-system measurements and reporting	3.0.0	3.1.0
	RP-06	RP-99656	014	1	Additional measurements in RRC measurement messages	3.0.0	3.1.0
	RP-06	RP-99656	015	3	Value range for Measurement Information Elements	3.0.0	3.1.0
	RP-06	RP-99656	016	2	Message contents for inter system handover to UTRAN	3.0.0	3.1.0
	RP-06	RP-99652	017		Inclusion of ciphering information elements	3.0.0	3.1.0
	RP-06	RP-99651	018		Corrections and editorial changes	3.0.0	3.1.0
	RP-06	RP-99654	019	1	Algorithm for CTCF Calculation	3.0.0	3.1.0
	RP-06	RP-99651	025		Logical CH for RRC Connection Re-establishment (RRC Connection Re-establishment deleted in RAN_10, RP-000715)	3.0.0	3.1.0
	RP-06	RP-99719	026	1	Gain Factors	3.0.0	3.1.0
	RP-06	RP-99654	027	1	Parameters for CELL UPDATE CONFIRM message	3.0.0	3.1.0
	RP-06	RP-99651	028		Cell Update Cause	3.0.0	3.1.0
	RP-06	RP-99654	029	1	RRC Initialisation Information	3.0.0	3.1.0
	RP-06	RP-99656	034	1	Open loop power control for PRACH	3.0.0	3.1.0
	RP-06	RP-99652	038		Addition of the UE controlled AMR mode adaptation	3.0.0	3.1.0
	RP-06	RP-99651	039		Information elements for RLC reset	3.0.0	3.1.0
	RP-06	RP-99656	040		Support for DS-41 Initial UE Identity	3.0.0	3.1.0
	RP-06	RP-99656	042	2	Integration of Cell Broadcast Service (CBS)	3.0.0	3.1.0
	RP-06	RP-99654	044	1	Gated transmission of DPCCH	3.0.0	3.1.0
	RP-06	RP-99656	045	ŀ	Modification to the Transport Format Combination Control message	3.0.0	3.1.0
	RP-06	RP-99656	046		New Information elements and modifications to messages required in order to support configuration and re-configuration of the DSCH	3.0.0	3.1.0
	DD 00	DD 00054	0.47		in FDD mode	0.0.0	0.4.0
	RP-06	RP-99654	047	1	Editorial Corrections and Alignments with Layer 1 specifications	3.0.0	3.1.0
	RP-06	RP-99654	048	1	Information elements for TDD shared channel operation	3.0.0	3.1.0
	RP-06	RP-99656	049		Description of CN dependent IEs in Master Information Block	3.0.0	3.1.0
	RP-06	RP-99650	050		UE capability information elements	3.0.0	3.1.0
	RP-06	RP-99656	051	1	UTRAN response time to uplink feedback commands of TX diversity control	3.0.0	3.1.0
	RP-06	RP-99654	052		New and corrected CPCH parameters	3.0.0	3.1.0
	RP-06	RP-99654	053	2	Compressed mode parameters without gating	3.0.0	3.1.0
	RP-06	RP-99654	054		Transport format combination set and transport format combination subset	3.0.0	3.1.0
	RP-06	RP-99656	055	1	Information elements for cell selection and reselection	3.0.0	3.1.0
	RP-06	RP-99654	056		Corrections and Alignments of the RRC to the L1 for TDD	3.0.0	3.1.0
·	RP-06	RP-99656	057	1	Introduction of a SCCH procedure	3.0.0	3.1.0
	RP-06	RP-99656	061		Support for DS-41 Paging UE Identity	3.0.0	3.1.0
	RP-06	RP-99656	062	2	Support for cdma2000 Hard Handover	3.0.0	3.1.0
	RP-06	RP-99656	063	1	Provide necessary signalling to support FDD DSCH	3.0.0	3.1.0
	RP-06	RP-99654	064	l	RRC procedure interactions	3.0.0	3.1.0
	RP-06	RP-99654	066	1	Transfer of UE capabilities	3.0.0	3.1.0
	RP-06	RP-99654	067	t	Selection of initial UE identity	3.0.0	3.1.0
	RP-06	RP-99657	069	1	UE capability verification in the security mode control procedure	3.0.0	3.1.0
	RP-06	RP-99657	070	1	DPCH initial power	3.0.0	3.1.0
	RP-06	RP-99657	070	l'	Actions when entering idle mode	3.0.0	3.1.0

D /	I=00 #	I-00 D		I_	Change history	la	I.
Date	TSG #	TSG Doc. RP-99657	CR 072	Rev	Subject/Comment Specification of inter-frequency and inter-system reporting events	Old 3.0.0	New 3.1.0
					for FDD		
	RP-06	RP-99657	073	1	Signalling radio bearers	3.0.0	3.1.0
	RP-06	RP-99654	074		CN information elements	3.0.0	3.1.0
	RP-06	RP-99654	076		UE information elements	3.0.0	3.1.0
	RP-06	RP-99657	077	1	Radio bearer, transport channel and physical channel information elements	3.0.0	3.1.0
	RP-06	RP-99654	078		Other information elements	3.0.0	3.1.0
	RP-06	RP-99657	079	2	RRC signalling for PDCP	3.0.0	3.1.0
	RP-06	RP-99654	080		Content of Measurement Control Messages	3.0.0	3.1.0
	RP-06	RP-99654	081		RRC Information Elements to support Block STTD transmission diversity in TDD	3.0.0	3.1.0
	RP-06	RP-99657	082	1	Signalling connection release	3.0.0	3.1.0
	RP-06	RP-99657	083	1	Addition of cell access restriction information elements to System Information	3.0.0	3.1.0
	RP-06	RP-99655	085	1	RRC Connection Establishment parameters	3.0.0	3.1.0
	RP-06	RP-99657	092	1	Support of UE autonomous update of a active set on a non-used frequency	3.0.0	3.1.0
	RP-06	RP-99657	095	1	TPC combining for power control	3.0.0	3.1.0
	RP-06	RP-99653	096	1	Editorial Modification of IEs in RRC messages	3.0.0	3.1.0
	RP-06	RP-99655	097	Ĭ	Selection of SCCPCH	3.0.0	3.1.0
	RP-06	RP-99655	098	1	RRC Initialisation Information	3.0.0	3.1.0
	RP-06	RP-99657	100	1	Support of physical channel establishment and failure criteria in the UE	3.0.0	3.1.0
	RP-06	RP-99655	102	1	RRC Connection Re-establishment (Message deleted in RAN_10, RP-000715)	3.0.0	3.1.0
	RP-06	RP-99657	106	1	System information on FACH	3.0.0	3.1.0
	RP-06	RP-99657	108	1	SAPs and Primitives for DS-41 mode	3.0.0	3.1.0
	RP-06	RP-99655	109	1	TX Diversity Mode for Dedicated Channel	3.0.0	3.1.0
	RP-06	RP-99657	110	1	RACH message length signalling on System Information	3.0.0	3.1.0
	RP-06	RP-99657	113	1	Routing of NAS messages in UTRAN	3.0.0	3.1.0
	RP-06	RP-99655	116	3	TBS Identification in TFS	3.0.0	3.1.0
	RP-06	RP-99657	117	1	Merging the hard handover and some radio bearer control procedures	3.0.0	3.1.0
	RP-06	RP-99653	120	1	Selected RRC message transfer syntax	3.0.0	3.1.0
	RP-06	RP-99657	121		Efficient rate command signalling	3.0.0	3.1.0
03/2000	RP-07	RP-000043	122		TDD Mode BCH Reception in Cell DCH State	3.1.0	3.2.0
	RP-07	RP-000043	123		Uplink Outer Loop Power Control in TDD Mode	3.1.0	3.2.0
	RP-07	RP-000043		1	TFS TB Size Calculation with Bit Aligned TDD MAC Headers	3.1.0	3.2.0
	RP-07	RP-000043			Grouping of DRAC IEs, and detailed definitions of these IEs	3.1.0	3.2.0
	RP-07	RP-000043			Correction of specifications for the 'Dynamic Resource Allocation Control of Uplink DCH' Procedure	3.1.0	3.2.0
	RP-07	RP-000043	131	2	Clarification of PDCP info and PDCP capability IEs	3.1.0	3.2.0
	RP-07	RP-000043			Editorial change to "Specification of system information block	3.1.0	3.2.0
	DD 07	DD 000040	122	-	characteristics" Additions of CBS related Information Elements	210	2 2 0
	RP-07	RP-000043		-		3.1.0	3.2.0
	RP-07	RP-000043		1	Signalling for computed gain factors	3.1.0	3.2.0
	RP-07	RP-000043		1	General error handling procedures	3.1.0	3.2.0
	RP-07	RP-000043		1	RRC message extensions	3.1.0	3.2.0
	RP-07	RP-000043		<u> </u>	Padding of RRC messages using RLC transparent mode	3.1.0	3.2.0
	RP-07	RP-000043		2	UE information elements	3.1.0	3.2.0
	RP-07	RP-000043			Other information elements	3.1.0	3.2.0
	RP-07	RP-000043		3	Integrity protection function	3.1.0	3.2.0
	RP-07	RP-000043		4	RAB-RB relations	3.1.0	3.2.0
	RP-07	RP-000043		1	Inter-system handover from UTRAN	3.1.0	3.2.0
	RP-07	RP-000043		3	Handover to UTRAN including procedure for pre- configuration	3.1.0	3.2.0
	RP-07	RP-000043		2	RRC measurement filtering parameters	3.1.0	3.2.0
	RP-07	RP-000043	147		New event "RL out of UE Rx window"	3.1.0	3.2.0
	RP-07	RP-000044	148	1	Access control on RACH	3.1.0	3.2.0
	RP-07	RP-000044	149	2	cdma2000 Hard Handover	3.1.0	3.2.0
	RP-07	RP-000044	150	1	CPCH parameters with corrections	3.1.0	3.2.0

Deta	ITCO #	ITCO Dec	CD	ln.	Change history	014	New
Date	RP-07	TSG Doc. RP-000044	CR 152	Kev	Subject/Comment U-plane AM RLC reconfiguration by cell update procedure	Old 3.1.0	New 3.2.0
	RP-07	RP-000044		2	CPCH	3.1.0	3.2.0
	RP-07	RP-000044		3	Information elements for ASC in TDD	3.1.0	3.2.0
	_	RP-000044		1			3.2.0
	RP-07				Addition of timing advance value in handover related messages	3.1.0	
	RP-07	RP-000044		2	Physical channel description for TDD	3.1.0	3.2.0
	RP-07	RP-000044	159		Message contents for the intersystem command message to UTRAN operating in TDD mode	3.1.0	3.2.0
	RP-07	RP-000044	160		Corrections on use of PUSCH power control info and minor corrections	3.1.0	3.2.0
	RP-07	RP-000044	162	2	UE individual DRX cycles in CELL_PCH and URA_PCH states	3.1.0	3.2.0
	RP-07	RP-000044	163		Correction to Transport Format Combination Control procedure	3.1.0	3.2.0
	RP-07	RP-000044	164	3	Downlink outer loop power control	3.1.0	3.2.0
	RP-07	RP-000044	165	2	Redirection of RRC connection setup	3.1.0	3.2.0
	RP-07	RP-000044	166	2	Inter-frequency measurements in CELL_FACH state	3.1.0	3.2.0
	RP-07	RP-000044	167		List of found editorial mistakes in the Dec99 version of 25.331 (V3.1.0)	3.1.0	3.2.0
	RP-07	RP-000044	168	1	Transport block size	3.1.0	3.2.0
	RP-07	RP-000044	169	1	Cell Access Restriction	3.1.0	3.2.0
	RP-07	RP-000044	170	1	Editorial modification	3.1.0	3.2.0
	RP-07	RP-000044		1	Modification of DPCH info	3.1.0	3.2.0
	RP-07	RP-000045		1	Measurement control message	3.1.0	3.2.0
	RP-07	RP-000045		2	Reporting cell status	3.1.0	3.2.0
	RP-07	RP-000045		Ι-	Additional IE for RB release	3.1.0	3.2.0
	RP-07	RP-000045			Available SF in PRACH info	3.1.0	3.2.0
	RP-07	RP-000045			Traffic volume measurement event	3.1.0	3.2.0
	RP-07	RP-000045			Report of multiple cells on an event result	3.1.0	3.2.0
	RP-07	RP-000045			Editorial modification on Direct Transfer	3.1.0	3.2.0
				ļ			
	RP-07	RP-000045		ļ.,	Correction of the Security Mode Control procedure	3.1.0	3.2.0
	RP-07	RP-000045		1	Maximum calculated Transport Format Combination	3.1.0	3.2.0
	RP-07	RP-000045			Additional DPCH IEs to align 25.331 with 25.214	3.1.0	3.2.0
	RP-07	RP-000045		1	RB – DCH mapping	3.1.0	3.2.0
	RP-07	RP-000045		1	Modifications related to FDD mode DSCH	3.1.0	3.2.0
	RP-07	RP-000045	189	1	Identification of Shared Channel Physical Configuration in TDD Mode	3.1.0	3.2.0
	RP-07	RP-000045	192	1	Uplink Outer Loop Power Control During Hard Handover	3.1.0	3.2.0
	RP-07	RP-000045			Support of Multiple CCTrCH's in TDD Mode	3.1.0	3.2.0
	RP-07	RP-000045	194	1	Uplink Physical Channel Control in TDD Mode	3.1.0	3.2.0
	RP-07	RP-000045	201	1	Transfer of initial information from UE to target RNC prior to handover to UTRAN	3.1.0	3.2.0
	RP-07	RP-000045	202	1	CN information elements	3.1.0	3.2.0
	RP-07	RP-000045	203		UTRAN mobility information elements	3.1.0	3.2.0
	RP-07	RP-000045	204	1	RB information elements	3.1.0	3.2.0
	RP-07	RP-000046		1	Physical channel information elements	3.1.0	3.2.0
	RP-07	RP-000046		1	UE capability information elements	3.1.0	3.2.0
	RP-07	RP-000046			UE variables	3.1.0	3.2.0
	RP-07	RP-000046		1	Actions when entering idle mode	3.1.0	3.2.0
	RP-07	RP-000046		 	Usage of pilot bits	3.1.0	3.2.0
	RP-07	RP-000046		1	System information procedure corrections	3.1.0	3.2.0
	RP-07	RP-000046		1	Reconfiguration of ciphering	3.1.0	3.2.0
	RP-07	RP-000046		1	Enhancements to RRC connection re-establishment procedure	3.1.0	3.2.0
	RP-07	RP-000046		<u> </u>	(Message subsequently deleted in RAN_!), RP-000715)	3.1.0	3.2.0
					addition of reverse direction container description		
	RP-07	RP-000046		1	Changes in RRC messages to support lossless SRNC relocation	3.1.0	3.2.0
	RP-07	RP-000046		1	Measurements of unlisted neighbouring cells	3.1.0	3.2.0
	RP-07	RP-000046	234	2	Inclusion of Location Services	3.1.0	3.2.0
	RP-07	RP-000046	236	1	Application of Access Service Classes and relation to Access Classes	3.1.0	3.2.0
	RP-07	RP-000046	252	1	DRX indicator presence and state entering mechanism at the end of a procedure	3.1.0	3.2.0

Change history												
Date	TSG#	TSG Doc.	CR	Rev	Subject/Comment	Old	New					
	RP-07	RP-000046	254	1	Physical shared channel allocation procedure	3.1.0	3.2.0					
	RP-07	RP-000046	255		Corrections to TDD specific parameters in PICH info	3.1.0	3.2.0					
	RP-07	RP-000046	256		Editorial modifications	3.1.0	3.2.0					
	RP-07	RP-000046	259	2	Introduction of mapping function information in Cell selection and	3.1.0	3.2.0					
	RP-07	RP-000046	263		Ciphering and integrity HFN	3.1.0	3.2.0					
	RP-07	RP-000046	267		New SIB for UP	3.1.0	3.2.0					
	RP-07	RP-000047	268		Removal of synchronization Case 3	3.1.0	3.2.0					
	RP-07	RP-000047	271		TX Diversity	3.1.0	3.2.0					
	RP-07	RP-000047	272		Update of tabular format clause 10	3.1.0	3.2.0					
	RP-07	RP-000047	273		ASN.1 description	3.1.0	3.2.0					
06/2000	RP-08	RP-000222	228	5	Downlink power control in compressed mode	3.2.0	3.3.0					
	RP-08	RP-000222	260	1	Clarification on physical channel allocations in TDD	3.2.0	3.3.0					
	RP-08	RP-000222	261	4	TDD Measurements and Reporting	3.2.0	3.3.0					
	RP-08	RP-000222	262	4	Signalling of IEs related to System Information on FACH	3.2.0	3.3.0					
	RP-08	RP-000222	265	3	Transport Format Combination Control	3.2.0	3.3.0					
	RP-08	RP-000222	269	1	Signalling of partial failure in radio bearer related procedures	3.2.0	3.3.0					
	RP-08	RP-000222	275		Clarification on PDCP info	3.2.0	3.3.0					
	RP-08	RP-000222	279		Editorial modification on Transport Ch capability	3.2.0	3.3.0					
	RP-08	RP-000222	280		Editorial modification on CN IE	3.2.0	3.3.0					
	RP-08	RP-000222	281	3	Editorial modification on Physical CH IE	3.2.0	3.3.0					
	RP-08	RP-000222		1	Editorial modification on ASN.1 description	3.2.0	3.3.0					
	RP-08	RP-000222	283	1	IEs on SIB5/6	3.2.0	3.3.0					
	RP-08	RP-000222		2	Re-establishment timer	3.2.0	3.3.0					
	RP-08	RP-000222		1	CN DRX cycle coefficient	3.2.0	3.3.0					
	RP-08	RP-000222		1	Cell Access Restriction	3.2.0	3.3.0					
	RP-08	RP-000222		1	Cell selection and re-selection parameters	3.2.0	3.3.0					
	RP-08	RP-000222		2	Modification on Measurement IE	3.2.0	3.3.0					
	RP-08	RP-000222		1	RACH Transmission parameters	3.2.0	3.3.0					
	RP-08	RP-000222		1	SCCPCH System Info	3.2.0	3.3.0					
	RP-08	RP-000222		1	Addition of HFN for RRC CONNECTION RE-ESTABLISHMENT	3.2.0	3.3.0					
				·	COMPLETE							
	RP-08	RP-000223	294	1	RLC reconfiguration indicator	3.2.0	3.3.0					
	RP-08	RP-000223		3	RLC Info	3.2.0	3.3.0					
	RP-08	RP-000223		1	Usage of Transport CH ID	3.2.0	3.3.0					
	RP-08	RP-000223	298	2	Transport format combination set	3.2.0	3.3.0					
	RP-08	RP-000223	300	1	Usage of U-RNTI and C-RNTI in DL DCCH message	3.2.0	3.3.0					
	RP-08	RP-000223	301		Description of Cell Update Procedure	3.2.0	3.3.0					
	RP-08	RP-000223		1	System information modification procedure	3.2.0	3.3.0					
	RP-08	RP-000223			Functional descriptions of the RRC messages	3.2.0	3.3.0					
	RP-08	RP-000223			Clarification of CTFC calculation	3.2.0	3.3.0					
	RP-08	RP-000223		3	Compressed mode parameters	3.2.0	3.3.0					
	RP-08	RP-000223		2	Signalling procedure for periodic local authentication	3.2.0	3.3.0					
	RP-08	RP-000223		5	Editorial corrections on security	3.2.0	3.3.0					
	RP-08	RP-000223		2	Security capability	3.2.0	3.3.0					
	RP-08	RP-000223	312	1	Corrections on ASN.1 definitions	3.2.0	3.3.0					
	RP-08	RP-000223	313	2	DRX cycle lower limit	3.2.0	3.3.0					
	RP-08	RP-000223	314	1	Removal of CPICH SIR measurement quantity	3.2.0	3.3.0					
	RP-08	RP-000223	315	1	Signalling connection release request	3.2.0	3.3.0					
	RP-08	RP-000223	318	1	Change to IMEI coding from BCD to hexadecimal	3.2.0	3.3.0					
	RP-08	RP-000223	319	1	Removal of RLC sequence numbers from RRC initialisation	3.2.0	3.3.0					
	RP-08	RP-000223	320	3	information Addition of the length of PDCP sequence numbers into PDCP info	3.2.0	3.3.0					
-	RP-08	RP-000223		1	BSIC verification of GSM cells	3.2.0	3.3.0					
	RP-08	RP-000224		Ľ	Reporting cell status	3.2.0	3.3.0					
	RP-08	RP-000224 RP-000224		1	RRC measurement filtering parameters	3.2.0	3.3.0					
				-	= 1							
	RP-08	RP-000224		2	Cell-reselection parameter signalling	3.2.0	3.3.0					
	RP-08	RP-000224	328	3	Multiplicity values	3.2.0	3.3.0					

_	I			-	Change history		1
Date	TSG # RP-08	TSG Doc.	CR	Rev	Subject/Comment	Old	New
		RP-000224			Quality measurements	3.2.0	3.3.0
	RP-08 RP-08	RP-000224		4	CPCH Status Indication mode correction End of CPCH transmission	3.2.0	3.3.0
		RP-000224		4		3.2.0	3.3.0
	RP-08	RP-000224			Handover to UTRAN procedure	3.2.0	3.3.0
	RP-08	RP-000224			Harmonization of access service classes in FDD and TDD	3.2.0	3.3.0
	RP-08	RP-000224	334	1	Correction to usage of primary CCPCH info and primary CPICH info	3.2.0	3.3.0
	RP-08	RP-000224	335	i i	Corrections and clarifications on system information handling	3.2.0	3.3.0
	RP-08	RP-000224	336	i i	Editorial corrections	3.2.0	3.3.0
	RP-08	RP-000224	337	1	Editorial corrections on uplink timing advance	3.2.0	3.3.0
	RP-08	RP-000224	339		Correction of Transport Format Combination tabular format and	3.2.0	3.3.0
					ASN.1		
	RP-08	RP-000224		1	UE variables	3.2.0	3.3.0
	RP-08	RP-000224		1	General error handling	3.2.0	3.3.0
	RP-08	RP-000224		1	System Information extensibility in ASN.1 definitions	3.2.0	3.3.0
	RP-08	RP-000224			Usage of pilot bits	3.2.0	3.3.0
	RP-08	RP-000224	346	3	RRC connection release procedure	3.2.0	3.3.0
	RP-08	RP-000225		1	Alignment of Section 10.3 on methodology defined in 25.921	3.2.0	3.3.0
	RP-08	RP-000225	348		Modifications of cell (re)selection parameters	3.2.0	3.3.0
	RP-08	RP-000225	350	1	GPS time-of-week represented as seconds and fractions of	3.2.0	3.3.0
	DD 00	DD 000005	254	2	seconds	2.0.0	2.2.0
	RP-08	RP-000225		2	CPCH corrections	3.2.0	3.3.0
	RP-08	RP-000225			PLMN type selection	3.2.0	3.3.0
	RP-08	RP-000225		3	Paging and establishment cause values	3.2.0	3.3.0
	RP-08	RP-000225			Common channel configurations	3.2.0	3.3.0
	RP-08	RP-000225		2	Clarification of prioritization of logical channels in UE	3.2.0	3.3.0
	RP-08	RP-000225		2	UE capability corrections	3.2.0	3.3.0
	RP-08	RP-000225	358	2	Clarification of HFN	3.2.0	3.3.0
	RP-08	RP-000225	359	3	Clarification of Integrity Protection	3.2.0	3.3.0
	RP-08	RP-000225	360	1	RRC message size optimization regarding TrCH parameters	3.2.0	3.3.0
	RP-08	RP-000225	361		Protocol extensions in ASN	3.2.0	3.3.0
	RP-08	RP-000225	362	1	Downloading of pre- defined configurations via SIB 16	3.2.0	3.3.0
	RP-08	RP-000225	363	1	Optimization of System Information	3.2.0	3.3.0
	RP-08	RP-000225	364	1	CPCH gain factor	3.2.0	3.3.0
	RP-08	RP-000225	368	2	SFN Transmission Rate in TDD Mode	3.2.0	3.3.0
	RP-08	RP-000225	371	1	Integrity Control	3.2.0	3.3.0
	RP-08	RP-000225	372	i i	Modification to measurement event evaluation	3.2.0	3.3.0
	RP-08	RP-000225		f	System Information related parameters	3.2.0	3.3.0
	RP-08	RP-000226		1	Changes in RB mapping info	3.2.0	3.3.0
	RP-08	RP-000226		1	Editorial corrections to PRACH system information and Cell info	3.2.0	3.3.0
	RP-08	RP-000226		 	Editorial Corrections to 25.331 Procedures and Tabular Format	3.2.0	3.3.0
	RP-08	RP-000226		1	Corrections to figures and procedures for the failure cases	3.2.0	3.3.0
	RP-08	RP-000226		 	Corrections to rigures and procedures for the failure cases Corrections on use of ORDERED_CONFIG	3.2.0	3.3.0
	RP-08	RP-000226		1	Corrections on use of ORDERED_CONFIG Corrections to Transport Channel and RB Reconfiguration	3.2.0	3.3.0
	111 -00	111 -000220	302	l	procedures	5.2.0	5.5.0
	RP-08	RP-000226	383	1	Corrections to INITIAL DIRECT TRANSFER and UE CAPABILITY	3.2.0	3.3.0
					INFORMATION CONFIRM procedures		
	RP-08	RP-000226	384		Corrections to Transparent mode signalling info Tabular format and ASN.1	3.2.0	3.3.0
	RP-08	RP-000226	385	1	Corrections to Soft Handover messages and procedures	3.2.0	3.3.0
	RP-08	RP-000226		1	Corrections to RRC CONNECTION REJECT procedures	3.2.0	3.3.0
	RP-08	RP-000226		1	Transport format combination in TDD and Transport channel ID	3.2.0	3.3.0
-	RP-08	RP-000226		1	Signalling for dynamic TTI in TDD	3.2.0	3.3.0
	RP-08	RP-000226		1	Usage of DCCH for Shared Channel Allocation message	3.2.0	3.3.0
					Correction to physical channel IEs in TDD		
	RP-08	RP-000226		1		3.2.0	3.3.0
	RP-08	RP-000226		1	TDD preconfiguration for Handover to UTRAN	3.2.0	3.3.0
	RP-08	RP-000226		<u> </u>	Corrections to measurement control descriptions and messages	3.2.0	3.3.0
	RP-08	RP-000226		1	Corrections on ASN.1 definitions	3.2.0	3.3.0
	RP-08	RP-000226	395		Addition of the Segmentation indication field for transparent mode	3.2.0	3.3.0

_	1			_	Change history		T
Date	TSG #	TSG Doc.	CR	Rev	Subject/Comment	Old	New
					RLC in the RLC Info		
	RP-08	RP-000226		1	Radio Bearer identity for CCCH	3.2.0	3.3.0
	RP-08	RP-000226		1	ASN.1 definitions for RRC information between network nodes	3.2.0	3.3.0
	RP-08	RP-000227		1	NAS Routing	3.2.0	3.3.0
	RP-08	RP-000227			DPCCH power control preamble	3.2.0	3.3.0
	RP-08	RP-000227		2	Modifications of Assisted GPS Messages	3.2.0	3.3.0
	RP-08	RP-000227			Choice of Initial UE Identity	3.2.0	3.3.0
	RP-08	RP-000227			ANSI-41 information elements	3.2.0	3.3.0
	RP-08	RP-000227		1	RLC value ranges	3.2.0	3.3.0
	RP-08	RP-000227		1	HFN Reset	3.2.0	3.3.0
	RP-08	RP-000227		1	Clarification on ciphering parameters and integrity protection procedure in case of SRNS relocation	3.2.0	3.3.0
	RP-08	RP-000227	410	1	Clarification of compressed mode activation and configuration failure	3.2.0	3.3.0
	RP-08	RP-000227	412	1	Modification of the RLC Size IE	3.2.0	3.3.0
	RP-08	RP-000227	414		CPCH DL Power control	3.2.0	3.3.0
	RP-08	RP-000227	415	1	SFN measurements in TDD	3.2.0	3.3.0
09/2000	RP-09	RP-000361	356	3	Clarification on multiplicity of PCH and PICH and S-CCPCH selection	3.3.0	3.4.0
	RP-09	RP-000361	403	3	Parameters to be stored in the USIM	3.3.0	3.4.0
	RP-09	RP-000361	413	3	Optimization of Inter-system handover message	3.3.0	3.4.0
	RP-09	RP-000361	416	2	Timing Advance in Handover Procedures	3.3.0	3.4.0
	RP-09	RP-000361	417	2	Synchronization of Timing Advance and Timing Deviation Measurement	3.3.0	3.4.0
	RP-09	RP-000361	418		Downlink Physical Channels Per Timeslot	3.3.0	3.4.0
	RP-09	RP-000361	419		TDD Mode DCH Reception in Cell DCH State	3.3.0	3.4.0
	RP-09	RP-000361	420	2	Downlink Power Control During DTX in TDD Mode	3.3.0	3.4.0
	RP-09	RP-000361	421	1	Paging Indicator Length Definition	3.3.0	3.4.0
	RP-09	RP-000361	422		Updating & alignment of RRC containers & handover to UTRAN information transfer	3.3.0	3.4.0
	RP-09	RP-000361	424		Default values for UE timers and counters	3.3.0	3.4.0
	RP-09	RP-000361	425	1	Security mode control	3.3.0	3.4.0
	RP-09	RP-000361	426	1	Corrections and Editorial updates to chapter 8	3.3.0	3.4.0
	RP-09	RP-000361	427		Corrections and editorial updates to chapter 10	3.3.0	3.4.0
	RP-09	RP-000361	428		Transition from CELL_DCH to CELL_PCH and URA_PCH state	3.3.0	3.4.0
	RP-09	RP-000361	430		Assisted GPS Messaging and Procedures	3.3.0	3.4.0
	RP-09	RP-000361	431	2	Corrections to Activation Time use	3.3.0	3.4.0
	RP-09	RP-000361			Editorial Corrections to measurement reporting range	3.3.0	3.4.0
	RP-09	RP-000361		4	Default DPCH offset value and DPCH offset	3.3.0	3.4.0
	RP-09	RP-000361		3	RLC info	3.3.0	3.4.0
	RP-09	RP-000362			Clarification of the description of IE semantics in "RB with PDCP information"	3.3.0	3.4.0
	RP-09	RP-000362	438	1	Editorial corrections on security	3.3.0	3.4.0
	RP-09	RP-000362			Editorial correction to RB mapping info	3.3.0	3.4.0
	RP-09	RP-000362		1	Compressed mode configuration failure	3.3.0	3.4.0
	RP-09	RP-000362			Gain factors for TDD	3.3.0	3.4.0
	RP-09	RP-000362			Introduction of Default DPCH Offset Value in TDD	3.3.0	3.4.0
	RP-09	RP-000362		1	Optimization of handover to UTRAN command	3.3.0	3.4.0
	RP-09	RP-000362			Editorial corrections	3.3.0	3.4.0
	RP-09	RP-000362		1	Mapping of channelisation code	3.3.0	3.4.0
	RP-09	RP-000362		2	DL TFCS Limitation	3.3.0	3.4.0
	RP-09	RP-000362		-	SIB offset	3.3.0	3.4.0
	RP-09	RP-000362		1	RRC CONNECTION RELEASE cause	3.3.0	3.4.0
	RP-09	RP-000362			Addition of RACH TFCS	3.3.0	3.4.0
	RP-09	RP-000362		2	Cell Identity	3.3.0	3.4.0
	RP-09	RP-000362			Editorial Modifications	3.3.0	3.4.0
	RP-09	RP-000362		1	TDD PRACH Power Control for Spreading Factor 8/16	3.3.0	3.4.0
	RP-09	RP-000362		 	TDD CCTrCH Repetition Length Definition	3.3.0	3.4.0
				1	, ,		
	RP-09	RP-000362	40/	1	Reporting threshold of traffic volume measurements	3.3.0	3.4.0

	Change history												
Date	TSG #	TSG Doc.	CR	Rev	Subject/Comment	Old	New						
	RP-09	RP-000362	459	2	UP GPS assistance data for SIB	3.3.0	3.4.0						
	RP-09	RP-000362	461	1	Support of cell update confirm on CCCH	3.3.0	3.4.0						
	RP-09	RP-000363	462	1	Max Window Size in RLC capabilities	3.3.0	3.4.0						
	RP-09	RP-000363	463	3	UE handling of CFN	3.3.0	3.4.0						
	RP-09	RP-000363	464	1	Correction of padding description in clause 12	3.3.0	3.4.0						
	RP-09	RP-000363	465	1	Window size in RLC info	3.3.0	3.4.0						
	RP-09	RP-000363	466	1	TFC Control Duration	3.3.0	3.4.0						
	RP-09	RP-000363	467		System Information Block Tabular Information	3.3.0	3.4.0						
	RP-09	RP-000363	469	1	Frequency encoding in inter-system handover messages	3.3.0	3.4.0						
	RP-09	RP-000363	470		RRC message size optimization regarding TFS parameters	3.3.0	3.4.0						
	RP-09	RP-000363	471	2	RACH selection	3.3.0	3.4.0						
	RP-09	RP-000363	472		DRX cycle lower limit	3.3.0	3.4.0						
	RP-09	RP-000363	474		Rx window size in RLC info	3.3.0	3.4.0						
	RP-09	RP-000363	476	1	Corrections & optimizations regarding system information blocks of length 215221	3.3.0	3.4.0						
	RP-09	RP-000363	477	1	Corrections on 8.1.1 resulting from RRC review at R2#14	3.3.0	3.4.0						
	RP-09	RP-000363	478	1	Corrections to the RRC connection release procedure	3.3.0	3.4.0						
	RP-09	RP-000363	479	1	New release cause for signalling connection re-establishment	3.3.0	3.4.0						
	RP-09	RP-000363	480	1	Correction to IE midamble shift and burst type	3.3.0	3.4.0						
	RP-09	RP-000363	481	1	Correction in RLC info	3.3.0	3.4.0						
	RP-09	RP-000363	483	Ī	Description of CTCH occasions	3.3.0	3.4.0						
	RP-09	RP-000363	485	1	TDD CCTrCH UL/DL Pairing for Inner Loop Power Control	3.3.0	3.4.0						
	RP-09	RP-000363	486	1	DCCH and BCCH Signalling of TDD UL OL PC Information	3.3.0	3.4.0						
	RP-09	RP-000364	487	1	Broadcast SIBs for TDD UL OL PC Information	3.3.0	3.4.0						
	RP-09	RP-000364	490	1	CPCH corrections	3.3.0	3.4.0						
	RP-09	RP-000364	492	3	Corrections to Security IEs	3.3.0	3.4.0						
	RP-09	RP-000364		1	Corrections to parameters to be stored in the USIM	3.3.0	3.4.0						
	RP-09	RP-000364	496	1	Editorial corrections	3.3.0	3.4.0						
	RP-09	RP-000364	497	2	Physical Shared Channel Allocation procedure	3.3.0	3.4.0						
	RP-09	RP-000364	498		Correction to Transport Format Combination Control Message	3.3.0	3.4.0						
	RP-09	RP-000364	499	1	Usage of Cell Parameter ID	3.3.0	3.4.0						
	RP-09	RP-000364	500	i i	RB description for SHCCH	3.3.0	3.4.0						
	RP-09	RP-000364	501	1	Use of LI in UM	3.3.0	3.4.0						
	RP-09	RP-000364		1	Minor Corrections to RRC Protocol Specification	3.3.0	3.4.0						
	RP-09	RP-000364	503	1	Correction to Cell Update Cause	3.3.0	3.4.0						
	RP-09	RP-000364			Correction on T307 definition	3.3.0	3.4.0						
	RP-09	RP-000364			Corrections to relative priorities in RRC Protocol	3.3.0	3.4.0						
	RP-09	RP-000364		1	Unification of Reconfiguration Procedures	3.3.0	3.4.0						
	RP-09	RP-000364		1	Changes to section 8.2 proposed at Paris RRC Ad Hoc	3.3.0	3.4.0						
	RP-09	RP-000364		Ħ	Establishment Cause	3.3.0	3.4.0						
	RP-09	RP-000364		1	PRACH partitioning	3.3.0	3.4.0						
	RP-09	RP-000364		Ħ	Editorial Correction on Active Set Update	3.3.0	3.4.0						
	RP-09	RP-000364		 	Editorial Correction regarding system information	3.3.0	3.4.0						
-	RP-09	RP-000365		1	Clarification on Reporting Cell Status	3.3.0	3.4.0						
	RP-09	RP-000365		1	Editorial corrections on RRC Connection Establishment and	3.3.0	3.4.0						
					Release procedures NOTE: In subclause 8.1.4.6, the change from "decrease" to "increase" for V308 was decided to be incorrect after discussion on the TSG-RAN WG2 reflector and was not implemented								
	RP-09	RP-000365			Gated Transmission Control Info	3.3.0	3.4.0						
	RP-09	RP-000365	515	1	Cell selection/reselection parameters for SIB 3/4	3.3.0	3.4.0						
	RP-09	RP-000365	516		Implementation of Ec/N0 parameters and optimization of SIB 11/12	3.3.0	3.4.0						
	RP-09	RP-000365	517	Ī	PRACH Info	3.3.0	3.4.0						
	RP-09	RP-000365	518	1	Uplink DPCH power control info	3.3.0	3.4.0						
	RP-09	RP-000365	519	Ī	AICH power offset value range	3.3.0	3.4.0						
	RP-09	RP-000365	520		Direct paging of RRC connected UE in CELL_PCH/URA_PCH NOTE: This CR was postponed in TSG-RAN #9 and was wrongly	3.3.0	3.4.0						
	DD 00	DD 000005	E04	-	included in v3.4.0. This was corrected in v3.4.1	2 2 2	2.4.0						
	RP-09	RP-000365	521	1	Corrections to Sections 1-7	3.3.0	3.4.0						

Data	TSG #	TSG Doc.	CR	Day	Change history	Old	Now
Date	RP-09	RP-000365		Rev	Subject/Comment Error handling for Uplink Physical Channel Control procedure	3.3.0	New 3.4.0
	RP-09	RP-000365			Corrections to downlink outer loop power control in compressed mode	3.3.0	3.4.0
	RP-09	RP-000365	524	1	Clarification on measurement procedure using compressed mode	3.3.0	3.4.0
	RP-09	RP-000365	525	1	Updates to cell and URA update procedures based on RRC Ad Hoc	3.3.0	3.4.0
	RP-09	RP-000365	526	1	Updates to RNTI allocation procedure based on RRC Ad Hoc	3.3.0	3.4.0
	RP-09	RP-000365	528		PRACH constant value	3.3.0	3.4.0
	RP-09	RP-000365	530	1	Corrections to the paging procedure	3.3.0	3.4.0
	RP-09	RP-000365	532	1	Moving of text from 25.304	3.3.0	3.4.0
	RP-09	RP-000365		1	Message extensibility	3.3.0	3.4.0
	RP-09	RP-000365		1	Additions to "State of RRC Procedure" in RRC Initialisation information, source RNC to target RNC	3.3.0	3.4.0
	RP-09	RP-000365	535	1	Support of codec negotiation	3.3.0	3.4.0
	-	=	-		Removal of contents of CR 520 from v3.4.0, because it was postponed at TSG-RAN #9 and by accident included anyway.	3.4.0	3.4.1
12/2000	RP-10	RP-000570	536		Downlink outer-loop power control in compressed mode	3.4.1	3.5.0
	RP-10	RP-000570	537	1	Correction in the use of "U-RNTI Short"	3.4.1	3.5.0
	RP-10	RP-000570	538		Corrections related to UE Timing	3.4.1	3.5.0
	RP-10	RP-000570	539		Corrections to SFN-SFN definition	3.4.1	3.5.0
	RP-10	RP-000570	541	1	Corrections to definition and use of Activation Time	3.4.1	3.5.0
	RP-10	RP-000570	542		Corrections to logical channel priorities	3.4.1	3.5.0
	RP-10	RP-000570		1	Correction to codec negotiation	3.4.1	3.5.0
	RP-10	RP-000570		1	CFN-SFN observed time difference measurement	3.4.1	3.5.0
	RP-10	RP-000570		1	Correction to timing indication for hard handover	3.4.1	3.5.0
	RP-10	RP-000570		1	UE Radio Access Capability Corrections	3.4.1	3.5.0
	RP-10	RP-000570		1	RRC establishment and paging causes for NAS signalling	3.4.1	3.5.0
	RP-10	RP-000570			Corrections to Intra-frequency measurements and Traffic volume measurements	3.4.1	3.5.0
	RP-10	RP-000570		1	PRACH/RACH System information	3.4.1	3.5.0
	RP-10	RP-000570		1	GSM Measurement reporting	3.4.1	3.5.0
	RP-10 RP-10	RP-000570 RP-000570		1	BLER measurement and quality target Clarification of PDCP sequence number window terminology	3.4.1	3.5.0 3.5.0
	RP-10	RP-000570		1	,	3.4.1	3.5.0
	RP-10	RP-000570		!	Clarification on Error Handling Removal of compressed mode measurement purpose "other"	3.4.1	3.5.0
	RP-10	RP-000570			Clarification of compressed mode measurement purpose "GSM"	3.4.1	3.5.0
	RP-10	RP-000570		2	Reporting multiple GSM cells	3.4.1	3.5.0
	RP-10	RP-000571		1	Number of RLs that can be removed in Active Set update	3.4.1	3.5.0
	RP-10	RP-000571		1	Clarification on Segment Index	3.4.1	3.5.0
	RP-10	RP-000571		3	RRC procedure performance requirements	3.4.1	3.5.0
	RP-10	RP-000571		1	Correction of newInterSystemCellList and MeasurementControlSysInfo in ASN.1	3.4.1	3.5.0
	RP-10	RP-000571	573	4	Removal of Flow Id concept while maintaining lu interface flexibility	3.4.1	3.5.0
	RP-10	RP-000571		2	Ciphering and reset	3.4.1	3.5.0
	RP-10	RP-000571		1	Corrections and clarifications concerning inter-RAT change procedures	3.4.1	3.5.0
	RP-10	RP-000571		1	General Security Clarifications	3.4.1	3.5.0
	RP-10	RP-000571			Clarification on RB 0	3.4.1	3.5.0
	RP-10	RP-000571			Clarification on the transition of RRC state	3.4.1	3.5.0
	RP-10	RP-000571		1	UP measurements for RRC information to target RNC	3.4.1	3.5.0
	RP-10	RP-000571		<u> </u>	Correction on LCS reporting criteria	3.4.1	3.5.0
	RP-10	RP-000574		1	CSICH Corrections	3.4.1	3.5.0
	RP-10	RP-000571		1	Clarification to handling of satellite health issues	3.4.1	3.5.0
	RP-10	RP-000571		<u> </u>	Clarification on activation time	3.4.1	3.5.0
	RP-10	RP-000571			Clarification on activation time for ciphering in TM	3.4.1	3.5.0
	RP-10	RP-000571		2	Measurement procedures and messages	3.4.1	3.5.0
	RP-10 RP-10	RP-000571 RP-000571		1	Inter-RAT UE radio access capability Clarification on cell update/URA update procedures	3.4.1	3.5.0 3.5.0
	RP-10	RP-000571		4	Protocol States and Process	3.4.1	3.5.0

_	1	I		_	Change history		1
Date	TSG #	TSG Doc.	CR	_	Subject/Comment	Old	New
	RP-10	RP-000571		1	System Information	3.4.1	3.5.0
	RP-10	RP-000715	597	5	RRC Connection Management Procedures, Generic procedures and actions	3.4.1	3.5.0
	RP-10	RP-000572	598	1	Paging Procedures	3.4.1	3.5.0
	RP-10	RP-000572	599		NAS signalling Procedures	3.4.1	3.5.0
	RP-10	RP-000572	600	3	Radio Bearer Control Procedures	3.4.1	3.5.0
	RP-10	RP-000572		1	Corrections to the Counter Check Procedure	3.4.1	3.5.0
	RP-10	RP-000572	602		Tabular Information and ASN.1	3.4.1	3.5.0
	RP-10	RP-000572		2	Corrections to Measurement Occasion concept	3.4.1	3.5.0
	RP-10	RP-000572	606		Corrections concerning optimisation of RB information	3.4.1	3.5.0
	RP-10	RP-000572	608	1	Corrections to security	3.4.1	3.5.0
	RP-10	RP-000572		1	Ciphering activation time for DPCH	3.4.1	3.5.0
	RP-10	RP-000572			Confirmation of signalling connection establishment	3.4.1	3.5.0
	RP-10	RP-000572	611	2	RACH Sub-channel signalling	3.4.1	3.5.0
	RP-10	RP-000572		2	Assistance data delivery for UP	3.4.1	3.5.0
	RP-10	RP-000572		1	Clarification of LCS measurements	3.4.1	3.5.0
	RP-10	RP-000572		2	Configuration of RLC PDU sizes for logical channels	3.4.1	3.5.0
	RP-10	RP-000574			PICH power offset for TDD	3.4.1	3.5.0
	RP-10	RP-000572			Correction for PDSCH power control for TDD	3.4.1	3.5.0
	RP-10	RP-000574			Usage of dynamic spreading factor in uplink	3.4.1	3.5.0
	RP-10	RP-000572			Correction of Midamble Shift for Burst Type 3	3.4.1	3.5.0
	RP-10	RP-000572			Correction of text concerning Scheduling of System Information	3.4.1	3.5.0
	RP-10	RP-000572		1	Alignment of GSM'99 BA Range concept and its inclusion in UTRA	3.4.1	3.5.0
	RP-10	RP-000572		1	Clarification of RB mapping info	3.4.1	3.5.0
	RP-10	RP-000572		1	Correction to UE multi-RAT capability	3.4.1	3.5.0
	RP-10	RP-000573		Ė	Correction to PDCP sequence number exchange during hard	3.4.1	3.5.0
	IXI - IO	141 -000373	020		handover	5.4.1	5.5.0
	RP-10	RP-000573	628	2	DCH Quality Target	3.4.1	3.5.0
	RP-10	RP-000573	629	1	Simultaneous release of RBs and signalling connection	3.4.1	3.5.0
	RP-10	RP-000573	630		Correction on Transport Channel Reconfiguration	3.4.1	3.5.0
	RP-10	RP-000573	631		Limitation of DRX cycle length	3.4.1	3.5.0
	RP-10	RP-000574	632		Signalling of the alpha value in TDD for open loop power control	3.4.1	3.5.0
	RP-10	RP-000573	633		Support for improved compressed mode handling for TDD	3.4.1	3.5.0
	DD 40	DD 000570	000		measurements	0.4.4	0.5.0
	RP-10	RP-000573			Usage of secondary CPICH and secondary scrambling code	3.4.1	3.5.0
	RP-10	RP-000573			Expiration time of SIB type 7, 14	3.4.1	3.5.0
	RP-10	RP-000573			Correction to integrity protection	3.4.1	3.5.0
22/222/	RP-10	RP-000684			Downlink Outer Loop Control	3.4.1	3.5.0
03/2001	RP-11	RP-010029		2	RL Failure in cell update procedure	3.5.0	3.6.0
	RP-11	RP-010029		1	Clarification on COUNTER CHECK	3.5.0	3.6.0
	RP-11	RP-010029		2	Traffic Volume Measurement corrections	3.5.0	3.6.0
	RP-11	RP-010029		2	Reserved TFCI for the TDD Special Burst	3.5.0	3.6.0
	RP-11	RP-010029		Ш	Correction to description of RRC state transitions	3.5.0	3.6.0
	RP-11	RP-010029			RLC re-establish correction	3.5.0	3.6.0
	RP-11	RP-010029		1	Removal of RLC logical channel mapping indicator	3.5.0	3.6.0
	RP-11	RP-010029			New paging and establishment cause "Unknown"	3.5.0	3.6.0
	RP-11	RP-010029		1	Miscellaneous procedure corrections	3.5.0	3.6.0
	RP-11	RP-010029			Corrections to compressed mode pattern sequence handling	3.5.0	3.6.0
	RP-11	RP-010029			Inter-system change clarifications	3.5.0	3.6.0
	RP-11	RP-010029		1	RLC status transmission in CELL_PCH and URA_PCH	3.5.0	3.6.0
	RP-11	RP-010029		1	Clarification of RB information parameter values for SRB0	3.5.0	3.6.0
	RP-11	RP-010029			Encoding for RRC- container	3.5.0	3.6.0
	RP-11	RP-010029		2	Update of message extension and encoding descriptions	3.5.0	3.6.0
	RP-11	RP-010032		4	Introduction of default pre-defined configurations	3.5.0	3.6.0
	RP-11	RP-010029	669	2	Security corrections	3.5.0	3.6.0
	RP-11	RP-010029	670		Clarifications on Blind Handover Support	3.5.0	3.6.0
	RP-11	RP-010029	671	1	Missing descriptions of UE actions	3.5.0	3.6.0
	RP-11	RP-010029	672	2	Corrections on UE Positioning information	3.5.0	3.6.0

Doto	TCC #	Tec Dec	CP	Davi	Change history	Old	Now
Date	TSG # RP-11	TSG Doc. RP-010029	CR 674	Rev 1	Subject/Comment Security related corrections to SRNS	Old 3.5.0	New 3.6.0
	RP-11	RP-010029		2	Downlink power offsets	3.5.0	3.6.0
	RP-11	RP-010032		2	Checking the integrity of UE security capabilities	3.5.0	3.6.0
	RP-11	RP-010274		1	Clarification to Secondary CCPCH info	3.5.0	3.6.0
					-		
	RP-11	RP-010030		1	Miscellaneous corrections	3.5.0	3.6.0
	RP-11	RP-010030			Removal of Layer 3 filtering for RACH	3.5.0	3.6.0
	RP-11	RP-010030		2	Correction of compressed mode parameters	3.5.0	3.6.0
	RP-11	RP-010030		_	Removal of immediate cell evaluation	3.5.0	3.6.0
	RP-11	RP-010030		2	Scheduling of SIB 15.2 and SIB 15.3	3.5.0	3.6.0
	RP-11	RP-010030		1	Correction to ECN modules	3.5.0	3.6.0
	RP-11	RP-010030		1	Improvement of the description of timing advance for TDD	3.5.0	3.6.0
	RP-11	RP-010030			Correction on timing advance and allocation for shared channels	3.5.0	3.6.0
	RP-11	RP-010030		1	Clarification on SF 1 signalling	3.5.0	3.6.0
	RP-11	RP-010030		1	Correction to power control in TDD	3.5.0	3.6.0
	RP-11	RP-010030	690		Midamble - Channelisation code association for TDD	3.5.0	3.6.0
	RP-11	RP-010030	691		Network requested reporting for physical shared channel allocation	3.5.0	3.6.0
	RP-11	RP-010030	693		System Information	3.5.0	3.6.0
	RP-11	RP-010030	694	1	Clarification on Transport Channel Identity	3.5.0	3.6.0
	RP-11	RP-010030	696	1	Editorial Correction	3.5.0	3.6.0
	RP-11	RP-010030	698	2	Correction to add coding of intra domain NAS node selector	3.5.0	3.6.0
	RP-11	RP-010030	700	1	Corrections to system information block characteristics in TDD	3.5.0	3.6.0
	RP-11	RP-010030	701	2	ASN.1 corrections	3.5.0	3.6.0
	RP-11	RP-010030	702	2	Measurement related corrections	3.5.0	3.6.0
	RP-11	RP-010031		1	Clarifications on TFC Control procedure	3.5.0	3.6.0
	RP-11	RP-010031		2	Association of PLMN ID to neighbour cells	3.5.0	3.6.0
	RP-11			1	TFCS Selection Guidelines	3.5.0	3.6.0
	RP-11			Ľ	Special Burst Scheduling During DTX in TDD	3.5.0	3.6.0
	RP-11	RP-010031		1	Radio Link Failure Criteria in TDD	3.5.0	3.6.0
	RP-11	RP-010031		1	Correction & Clarification to TDD RACH Subchannels	3.5.0	3.6.0
	RP-11	RP-010031		1	Number of retransmission of RRC CONNECTION REQUEST	3.5.0	3.6.0
	RP-11	RP-010031		-	Uplink Frequency Notification	3.5.0	3.6.0
	RP-11	RP-010031				3.5.0	3.6.0
	KP-II	KP-010031	7 15		Clarification of Radio Bearer Mapping for DCH/DSCH Transport Channels	3.5.0	3.6.0
	RP-11	RP-010031	716		Correction of mismatches between tabular and ASN.1	3.5.0	3.6.0
	RP-11	RP-010031	717		Correction to discontinuous reception in TDD	3.5.0	3.6.0
	RP-11	RP-010031	718		Power control preamble	3.5.0	3.6.0
	RP-11	RP-010031			Maximum number of AM entity	3.5.0	3.6.0
	RP-11	RP-010031		1	Real-time Integrity Broadcast	3.5.0	3.6.0
	RP-11			3	Moving Real-time Integrity description to different chapter	3.5.0	3.6.0
	RP-11			1	Removal of the payload unit concept	3.5.0	3.6.0
	RP-11			Ė	Security related corrections to SRNS	3.5.0	3.6.0
	RP-11	RP-010031		1	Periodic PLMN selection correction	3.5.0	3.6.0
	RP-11	RP-010031		1	Modification of "SSDT Information" IE parameters to indicate if	3.6.0	4.0.0
	1712-11	NF -010042	003	ľ	SSDT is used in the UL only	3.0.0	4.0.0
	RP-11	RP-010041	692	1	Idle allocation for Node B synchronisation	3.6.0	4.0.0
	RP-11	RP-010037	706	1	Physical channel configuration information elements for 1.28 Mcps	3.6.0	4.0.0
					TDD		
	RP-11	RP-010037		2	Changes to Measurement Related Signalling and Introduction of Cell (Re)selection Parameters for 1.28Mcps TDD	3.6.0	4.0.0
	RP-11	RP-010037	708	1	Introduction of RACH Parameters for 1.28 Mcps TDD	3.6.0	4.0.0
	RP-11	RP-010037	709		Introduction of UE radio access capability Parameters for 1.28 Mcps TDD	3.6.0	4.0.0
	RP-11	RP-010040	722	1	Introduction of IPDLs for TDD	3.6.0	4.0.0
	RP-11	RP-010039	726	1	ROHC updates to RRC	3.6.0	4.0.0
06/2001	RP-12	RP-010311	731		Clarification of the IE 'spreading factor' in Uplink DPCH info for FDD mode	4.0.0	4.1.0
	RP-12	RP-010311	733		Correction of UE Radio Access Capability depending on UTRAN FDD bands	4.0.0	4.1.0
	RP-12	RP-010311	735		Clarification on Security mode control	4.0.0	4.1.0

D-1	T00 "	ITO C C	0.5		Change history	01.	IN-
Date	TSG #	TSG Doc.	CR	Rev	Subject/Comment	Old	New
	RP-12	RP-010311			Correction of TrCH parameter handling TFC Subsets in TDD	4.0.0	4.1.0
	RP-12 RP-12	RP-010311			RRC containers	4.0.0	4.1.0
	RP-12 RP-12	RP-010311 RP-010311				4.0.0 4.0.0	4.1.0
					Various corrections		4.1.0
	RP-12	RP-010311			General error handling for system information	4.0.0	4.1.0
	RP-12	RP-010311			Order of elements in strings	4.0.0	4.1.0
	RP-12	RP-010311 RP-010312			Configuration consistency checks Compressed mode corrections	4.0.0	4.1.0
	RP-12				•	4.0.0	4.1.0
	RP-12	RP-010312			Correction concerning inter-RAT procedures	4.0.0	4.1.0
	RP-12	RP-010312			Measurement corrections RLC Tr Discard	4.0.0	4.1.0
	RP-12	RP-010312				4.0.0	4.1.0
	RP-12	RP-010312			Annex B CPCH Correction	4.0.0	4.1.0
	RP-12	RP-010312			SIB Correction for CSICH Power Offset	4.0.0	4.1.0
	RP-12	RP-010312			Transfer of Last known position in case of SRNS relocation	4.0.0	4.1.0
	RP-12	RP-010312			Corrections to UE Positioning measurements	4.0.0	4.1.0
	RP-12	RP-010312			GSM measurements in compressed mode	4.0.0	4.1.0
	RP-12	RP-010312			Correction of Activation Time in Inter-Rat HO Commands	4.0.0	4.1.0
	RP-12	RP-010313			Clarification of FRESH in SRNS relocation	4.0.0	4.1.0
	RP-12	RP-010313			Correction to UE timers and constants in idle mode	4.0.0	4.1.0
	RP-12	RP-010313			Clarification on multiframe allocation in TDD	4.0.0	4.1.0
	RP-12	RP-010313			Predefined parameters for logical channels	4.0.0	4.1.0
	RP-12	RP-010313			Pathloss calculation	4.0.0	4.1.0
	RP-12	RP-010313			Clarification on periodic measurement reporting	4.0.0	4.1.0
	RP-12	RP-010313	803	1	Handling of IE PRACH TFCS and Primary CPICH/Primary CCPCH info	4.0.0	4.1.0
	RP-12	RP-010313	805		Correction to FACH measurement occasion in TDD	4.0.0	4.1.0
	RP-12	RP-010313	807		Clarification of L1 synchronization procedures	4.0.0	4.1.0
	RP-12	RP-010313	809		Correction of Activation Time definition	4.0.0	4.1.0
	RP-12	RP-010314			Corrections to RRC procedure performance	4.0.0	4.1.0
	RP-12	RP-010314	815		Removal of mapping function	4.0.0	4.1.0
	RP-12	RP-010314	817		Security clarifications	4.0.0	4.1.0
	RP-12	RP-010314	819		Corrections to UE Positioning	4.0.0	4.1.0
	RP-12	RP-010314	825		Definition of DPCH numbering	4.0.0	4.1.0
	RP-12	RP-010314	827		Corrections to System Information Procedure	4.0.0	4.1.0
	RP-12	RP-010314	829		Relation between DOFF and DPCH Frame Offset	4.0.0	4.1.0
	RP-12	RP-010314	831		Procedures for "same as UL"	4.0.0	4.1.0
	RP-12	RP-010314	837		Editorial and minor corrections	4.0.0	4.1.0
	RP-12	RP-010314	839		Editorial Correction	4.0.0	4.1.0
	RP-12	RP-010315	843		Corrections on OTDOA-IPDL specific burst parameter semantic description	4.0.0	4.1.0
	RP-12	RP-010315	845		Error handling for messages sent from another RAT	4.0.0	4.1.0
	RP-12	RP-010315			Needed TFC in the TFCS for TDD	4.0.0	4.1.0
	RP-12	RP-010315			Clarification of TFCS selection guidelines	4.0.0	4.1.0
	RP-12	RP-010315			Clarification of Traffic Volume measurements	4.0.0	4.1.0
	RP-12	RP-010315			CFN synchronisation problems at timing re-initialised hard handover	4.0.0	4.1.0
	RP-12	RP-010315	866		Corrections on UP Assistance Message Descriptions	4.0.0	4.1.0
	RP-12	RP-010315			Correction on Area Scope of SIB 15.3	4.0.0	4.1.0
	RP-12	RP-010315			Correction to AICH power offset	4.0.0	4.1.0
	RP-12	RP-010316			Clarification on IE 'Downlink rate matching restriction information'	4.0.0	4.1.0
	RP-12	RP-010316			Corrections on Tabular/ASN.1	4.0.0	4.1.0
	RP-12	RP-010316			Corrections on Tabular and ASN.1 inconsistencies	4.0.0	4.1.0
	RP-12	RP-010316			Editorial corrections on Tabular and ASN.1 inconsistencies	4.0.0	4.1.0
	RP-12	RP-010316			UE Positioning corrections to ASN.1 and tabular	4.0.0	4.1.0
	RP-12	RP-010316			Corrections to resolve inconsistencies between Tabular and ASN.1	4.0.0	4.1.0
	RP-12	RP-010316			UE positioning OTDOA Neighbour Cell Info	4.0.0	4.1.0
	RP-12	RP-010316			DRAC corrections	4.0.0	4.1.0
	RP-12	RP-010316			ASN.1 Correction of IE TFCS ID	4.0.0	4.1.0

	I=c -	I=0	1		Change history	I	
Date	TSG #	TSG Doc.	CR	Rev	Subject/Comment	Old	New
	RP-12	RP-010316			Correction of IE IODE range in AGPS Positioning	4.0.0	4.1.0
	RP-12 RP-12	RP-010317			Correction to BurstModeParameters in IPDL	4.0.0	4.1.0
	RP-12	RP-010317 RP-010317			Corrections on inconsistencies between Tabular and ASN.1	4.0.0 4.0.0	4.1.0 4.1.0
	RP-12	RP-010317			Naming of message abstract types in ASN.1 Information elements outside the extension container		4.1.0
	RP-12	RP-010317			Correction concerning DRX cycle upon inter-RAT change towards	4.0.0	4.1.0
					UTRAN		
	RP-12	RP-010323			Corrections to IPDLs for TDD	4.0.0	4.1.0
	RP-12	RP-010323		2	Correction to 1.28Mcps TDD RACH parameters and operation	4.0.0	4.1.0
	RP-12	RP-010323			TFCI coding in case of 8PSK	4.0.0	4.1.0
	RP-12	RP-010323		1	Structure and naming of information elements	4.0.0	4.1.0
09/2001	RP-13	RP-010544			UL Transport Channel Type Correction	4.1.0	4.2.0
	RP-13	RP-010544	0908		Guidelines concerning conditions, spares, defaults and correction of inconsistencies	4.1.0	4.2.0
	RP-13	RP-010544	0910		Correction to TDD DL DPCH Common Timeslot Info	4.1.0	4.2.0
	RP-13	RP-010544	0912		TDD System Information Update in Cell_DCH	4.1.0	4.2.0
	RP-13	RP-010544	0914		Editorial Corrections	4.1.0	4.2.0
	RP-13	RP-010544			UL DPCH Power Control Info in TDD	4.1.0	4.2.0
	RP-13	RP-010544	0918		CN-originated paging in CELL_PCH and URA_PCH state	4.1.0	4.2.0
	RP-13	RP-010544	0920		Corrections to UE variable handling	4.1.0	4.2.0
	RP-13	RP-010544			Inter-frequency measurements	4.1.0	4.2.0
	RP-13	RP-010544	0924		Inter-RAT measurements	4.1.0	4.2.0
	RP-13	RP-010671	0926	1	Intra-frequency measurements	4.1.0	4.2.0
	RP-13	RP-010545	0928		Multiplexing configuration corrections	4.1.0	4.2.0
	RP-13	RP-010545	0930		Reception of non-dedicated control channels mapped on FACH in CELL_FACH state	4.1.0	4.2.0
	RP-13	RP-010545	0932		Removal of C-RNTI when entering CELL_DCH	4.1.0	4.2.0
	RP-13	RP-010545	0935		TF and TFC set definition	4.1.0	4.2.0
	RP-13	RP-010545	0937		Correction of remaining ASN.1/Tabular inconsistencies	4.1.0	4.2.0
	RP-13	RP-010545	0939		CPICH Ec/N0 Range	4.1.0	4.2.0
	RP-13	RP-010545	0941		Priorities for IDNNS coding	4.1.0	4.2.0
	RP-13	RP-010545	0943		Dedicated pilots and S-CPICH specification related to UE specific beamforming	4.1.0	4.2.0
	RP-13	RP-010545	0945		Security corrections	4.1.0	4.2.0
	RP-13	RP-010546	0953		Intra-frequency measurement events for TDD corrections	4.1.0	4.2.0
	RP-13	RP-010546	0955		Inconsistencies between ASN.1 and tabular format	4.1.0	4.2.0
	RP-13	RP-010546	0957		TDD PICH corrections and clarifications	4.1.0	4.2.0
	RP-13	RP-010546	0959		Messages on CCCH	4.1.0	4.2.0
	RP-13	RP-010546			Clarification of Parameter Values for Default Radio Configurations	4.1.0	4.2.0
	RP-13	RP-010546	0963		Clarification to usage of default values in "Cell Selection and Reselection for SIB11/12Info"	4.1.0	4.2.0
	RP-13	RP-010546	0965		Clarification of handling of System information block 14	4.1.0	4.2.0
	RP-13	RP-010546	0967		Description of UE behaviour when receiving UE positioning related information	4.1.0	4.2.0
	RP-13	RP-010546	0982		Clarification on periodic measurement reporting	4.1.0	4.2.0
	RP-13	RP-010546	0984		Corrections and clarifications on Measurement procedures description	4.1.0	4.2.0
	RP-13	RP-010547	0986		Lossless Criteria in PDCP Info	4.1.0	4.2.0
	RP-13	RP-010547			Corrections to cell reselection parameter values	4.1.0	4.2.0
	RP-13	RP-010547			Correction to signalling connection release	4.1.0	4.2.0
	RP-13	RP-010547			Corrections to cell update procedures	4.1.0	4.2.0
	RP-13	RP-010547			PDCP configuration and PS domain configuration checks	4.1.0	4.2.0
	RP-13	RP-010547			Correction to handling of RRC transaction identifier for Cell Update, URA Update and RRC connection setup		4.2.0
	RP-13	RP-010547	0998	1	Correction of UE capabilities regarding Rx-Tx time difference type 2 measurement	4.1.0	4.2.0
	RP-13	RP-010547	1000		Correction to handling of IE 'Downlink info for each radio link'	4.1.0	4.2.0
	RP-13	RP-010547			Redundant IE in Traffic volume measurement system information	4.1.0	4.2.0
	RP-13	RP-010547			Editorial corrections	4.1.0	4.2.0
	RP-13	RP-010548			MAC logical channel priority added to definition of RB0 and	4.1.0	4.2.0
					SHCCH		

					Change history		
Date	TSG#	TSG Doc.	CR	Rev	Subject/Comment	Old	New
	RP-13	RP-010548	1010		Control of primary CCPCH RSCP measurement in PUSCH CAPACITY REQUEST message	4.1.0	4.2.0
	RP-13	RP-010548	1014		Various minor corrections	4.1.0	4.2.0
	RP-13	RP-010548	1016		Range of T312	4.1.0	4.2.0
	RP-13	RP-010548	1018		Bitstring of channelisationCodeIndices	4.1.0	4.2.0
	RP-13	RP-010548	1020		Transmission of UE CAPABILITY INFORMATION message	4.1.0	4.2.0
	RP-13	RP-010548	1022		Multiple UE capabilities procedures	4.1.0	4.2.0
	RP-13	RP-010548	1024		Corrections to information elements outside the extension container	4.1.0	4.2.0
	RP-13	RP-010548	1026		SFN reporting	4.1.0	4.2.0
	RP-13	RP-010548	1028		TFCI combining indicator	4.1.0	4.2.0
	RP-13	RP-010549	1030		RLC reset on a Signalling Radio Bearer	4.1.0	4.2.0
	RP-13	RP-010549	1034		Quality Indication for UE Positioning Parameters	4.1.0	4.2.0
	RP-13	RP-010549	1036		Editorial Correction for UE Positioning	4.1.0	4.2.0
	RP-13	RP-010549	1038		Clarification on the current status of ciphering	4.1.0	4.2.0
	RP-13				Clarification on HFN initialization at SRB and RB setup	4.1.0	4.2.0
	RP-13	RP-010549			Clarification on Inter-RAT measurement	4.1.0	4.2.0
	RP-13	RP-010549	1052		Clarification on re-assembly of segments	4.1.0	4.2.0
	RP-13	RP-010549			Minor Corrections	4.1.0	4.2.0
	RP-13	RP-010549			Support of dedicated pilots for channel estimation	4.1.0	4.2.0
	RP-13	RP-010549			Correction to SRNS relocation handling	4.1.0	4.2.0
	RP-13	RP-010550			Correction to RLC state variables	4.1.0	4.2.0
	RP-13	RP-010550			Reading of CN information in SIB 1 inRRC Connected Mode	4.1.0	4.2.0
	RP-13	RP-010550			Restricting the maximum amount of preconfigurations in case of	4.1.0	4.2.0
	1 10	141 010000	1000		equivalent PLMNs	1	1.2.0
	RP-13	RP-010554	0933		Order of bits in bitstrings	4.1.0	4.2.0
	RP-13	RP-010554	0946		Selection of the RFC3095 CID transmission	4.1.0	4.2.0
	RP-13	RP-010554	0970		Correction of IPDL parameters for TDD enhancements in ASN.1 description	4.1.0	4.2.0
	RP-13	RP-010554		1	1.28 Mcps TDD PICH, Midamble and UL timing advance control corrections	4.1.0	4.2.0
	RP-13	RP-010554			Introduction of 1.28 Mcps TDD Mode in clause 13.7	4.1.0	4.2.0
	RP-13	RP-010554			Tadv in 1.28 Mcps TDD	4.1.0	4.2.0
	RP-13	RP-010554	0974		Correction and clarification to PRACH in 1.28 Mcps TDD	4.1.0	4.2.0
10/2001	-	-	-		Replacement of incorrect (R'99) version of ASN.1 by correct (Rel-4) version of ASN.1.		4.2.1
12/2001	RP-14	RP-010763			Corrections to RRC information containers	4.2.1	4.3.0
	RP-14	RP-010763			Removal of Block SSTD	4.2.1	4.3.0
	RP-14	RP-010763			COUNT-C-SFN frame difference measurement	4.2.1	4.3.0
	RP-14	RP-010763			Trigger for deletion of ciphering and integrity keys	4.2.1	4.3.0
	RP-14	RP-010763			Correction to P_compensation calculation for GSM neighbour cells	4.2.1	4.3.0
	RP-14	RP-010763			Preconfigurations in case of equivalent PLMNs	4.2.1	4.3.0
	RP-14	RP-010763			Handling of DRX cycle and U-RNTI in RRC connection setup and handling of TrCH information	4.2.1	4.3.0
	RP-14	RP-010763			Correction to Information Element names	4.2.1	4.3.0
	RP-14	RP-010763			Correction of Description of IE "SSDT Information"	4.2.1	4.3.0
	RP-14	RP-010763			Clarification on Cell Identity and correction to reference to BAND_INDICATOR	4.2.1	4.3.0
	RP-14	RP-010764			Clarification to Measured Results on RACH and Measurement Events	4.2.1	4.3.0
	RP-14	RP-010764			Inconsistency between ASN.1 and tabular wrt. RPLMN information	4.2.1	4.3.0
	RP-14	RP-010764			General clarification on Establishment of Access Service Classes	4.2.1	4.3.0
	RP-14	RP-010764			Clarification on TX diversity indicator IE and STTD indicator IE	4.2.1	4.3.0
	RP-14	RP-010764			Different diversity modes used in the same active set	4.2.1	4.3.0
	RP-14	RP-010764			Issues regarding signalling connection establishment and RRC connection release	4.2.1	4.3.0
	RP-14	RP-010764			Presence of AC to ASC mapping in SIB5 and SIB6	4.2.1	4.3.0
	RP-14	RP-010764			RRC establishment cause at inter-RAT cell change order to UTRAN	4.2.1	4.3.0
	RP-14	RP-010764			Start of timers at radio link failure	4.2.1	4.3.0
	RP-14	RP-010765	1144		Handling of the number of FBI bits sent in Uplink DPCH info	4.2.1	4.3.0
	RP-14	RP-010765	1146		Bit string order when using PER	4.2.1	4.3.0

_	I== - ::	I	T	-	Change history		T
Date	TSG #	TSG Doc.	CR	Rev	Subject/Comment	Old	New
	RP-14	RP-010765			Clarification on DRX cycle length in connected mode	4.2.1	4.3.0
	RP-14	RP-010765	1152		Correction to error condition on downlink information for each radio link	4.2.1	4.3.0
	RP-14	RP-010765	1154		Correction of inconsistencies between tabular and ASN.1	4.2.1	4.3.0
	RP-14	RP-010765			Measurement related corrections	4.2.1	4.3.0
	RP-14	RP-010765			Inconsistency between hard-coded preconfigurations parameters	4.2.1	4.3.0
					and procedure text		
	RP-14	RP-010765	1166		PLMN search in CELL_PCH/URA_PCH states with 80ms DRX cycle	4.2.1	4.3.0
	RP-14	RP-010765	1168		Correction to CFN calculation for FDD	4.2.1	4.3.0
	RP-14	RP-010765			Correction to radio bearer control	4.2.1	4.3.0
	RP-14	RP-010766	1172		Handling of IE "frequency info"	4.2.1	4.3.0
	RP-14	RP-010766	1174		Correction to Radio Bearer Release	4.2.1	4.3.0
	RP-14	RP-010940	1178	1	Correction to RACH reporting	4.2.1	4.3.0
	RP-14	RP-010766	1180		Correction to URA/Cell update and other minor corrections	4.2.1	4.3.0
	RP-14	RP-010766	1182		Correction to Active Set Update	4.2.1	4.3.0
	RP-14	RP-010766	1184		Correction of Traffic Volume Measurement Criteria	4.2.1	4.3.0
	RP-14	RP-010941	1186	1	Correction of UE Positioning	4.2.1	4.3.0
	RP-14	RP-010766	1203		Invalid RRC CONNECTION REJECT	4.2.1	4.3.0
	RP-14	RP-010766	1214		Security baseline for corrections	4.2.1	4.3.0
	RP-14	RP-010766	1220		Pending integrity protection activation time for UL RB0	4.2.1	4.3.0
	RP-14	RP-010767	1222		Correction of rate matching restriction function	4.2.1	4.3.0
	RP-14	RP-010773	1096		Usage of UM RLC Special Length Indicator	4.2.1	4.3.0
	RP-14	RP-010773	1120		Corrections to REL-4 LCR Tabular Description and ASN1 Code	4.2.1	4.3.0
	RP-14	RP-010773			Correction of FPACH parameter definition for 1.28Mcps TDD	4.2.1	4.3.0
	RP-14	RP-010773			Correction of 1.28Mcps TDD	4.2.1	4.3.0
	RP-14	RP-010773			Correction and Clarification to Open Loop Power Control in 1.28 Mcps TDD	4.2.1	4.3.0
	RP-14	RP-010773	1206		Extensions of IE value ranges in tabular	4.2.1	4.3.0
03/2002	RP-15	RP-020070			Constant value range correction for DPCH and PUSCH in TDD	4.3.0	4.4.0
	RP-15	RP-020070	1231			4.3.0	4.4.0
	RP-15	RP-020070	1233			4.3.0	4.4.0
	RP-15	RP-020070	1227		Channel Allocation message Correction to TF selection when using UL RLC TM	4.3.0	4.4.0
	RP-15	RP-020070	_		Correction to the UE behaviour in case of SRNS relocation	4.3.0	4.4.0
	RP-15	RP-020070			Header Compression protocols re-initialisation during SRNS	4.3.0	4.4.0
	DD 45	DD 000070	1010		Relocation	100	4.4.0
	RP-15	RP-020070			Misalignments between tabular and ASN.1 related to UE Positioning, tabular correction	4.3.0	4.4.0
	RP-15	RP-020070			Corrections to comments in ASN.1	4.3.0	4.4.0
	RP-15	RP-020070			Correction to restarting of T308	4.3.0	4.4.0
	RP-15	RP-020070			Clarification of the use of T309 during inter-RAT cell reselections	4.3.0	4.4.0
	RP-15	RP-020071	1251		Measurement Corrections	4.3.0	4.4.0
	RP-15	RP-020239	1253	1	Existence of TFCI bits	4.3.0	4.4.0
	RP-15	RP-020071	1258		Corrections of inconsistency between procedural description, tabular and ASN.1	4.3.0	4.4.0
	RP-15	RP-020071	1260		Corrections to Expiration Time Factor and Expiration Time formula for SIB 7 and SIB 14	4.3.0	4.4.0
	RP-15	RP-020071	1262		Corrections to Reporting Cell Status	4.3.0	4.4.0
	RP-15	RP-020071	1268		Correction to inter frequency measurements	4.3.0	4.4.0
	RP-15	RP-020071			Actions at reception of system information block type 1	4.3.0	4.4.0
	RP-15	RP-020071			Tx diversity and no diversity in the same active set	4.3.0	4.4.0
	RP-15	RP-020071			Correction to cell update	4.3.0	4.4.0
	RP-15	RP-020071			Successful and unsuccessful procedures	4.3.0	4.4.0
	RP-15	RP-020072			Measurement related corrections	4.3.0	4.4.0
	RP-15	RP-020072			Clarifications on Event 1D	4.3.0	4.4.0
	RP-15	RP-020205		1	Security corrections	4.3.0	4.4.0
				Ľ	Transition from CELL_DCH to CELL_FACH state	4.3.0	4.4.0
1	RP-15	RP-020072	1285		I I ransition from CELL DUH to CELL FACH State	4.30	4.4 ()

	I=0.0 ::	I=== =		-	Change history		
Date	TSG #	TSG Doc.	CR	Rev	Subject/Comment	Old	New
	RP-15	RP-020072			Spare values in ASN.1	4.3.0	4.4.0
	RP-15	RP-020072			Actions on reception of measurement related IEs	4.3.0	4.4.0
	RP-15	RP-020231		1	Removal of channel coding option "no coding" for FDD and 3.84 Mcps TDD	4.3.0	4.4.0
	RP-15	RP-020072			Timing Indication when moving to CELL_DCH state	4.3.0	4.4.0
	RP-15	RP-020072			Correction to processing RB mapping info	4.3.0	4.4.0
	RP-15	RP-020072			RRC Connection Release following network authentication failure	4.3.0	4.4.0
	RP-15	RP-020072			Clarification on serving cell in SIB11	4.3.0	4.4.0
	RP-15	RP-020073			Treatment of optional elements in RB control messages	4.3.0	4.4.0
	RP-15	RP-020073			Procedure Performance for TDD UL physical Channel Control	4.3.0	4.4.0
	RP-15	RP-020250		1	Clarification to physical channel establishment criteria	4.3.0	4.4.0
	RP-15	RP-020249		1	OTDOA Assistance Data	4.3.0	4.4.0
	RP-15	RP-020073			Retransmission of uplink direct transfer at RLC re-establishment and inter-RAT change	4.3.0	4.4.0
	RP-15	RP-020073			Correction to IE "UL interference" for UTRA TDD	4.3.0	4.4.0
	RP-15	RP-020074			Corrections of UE Positioning requirements	4.3.0	4.4.0
	RP-15	RP-020074			Multimode speech in default configurations	4.3.0	4.4.0
	RP-15	RP-020073			Correction to UE Id for DSCH	4.3.0	4.4.0
	RP-15	RP-020073			Corrections to support combined Cell/URA update and SRNS relocation	4.3.0	4.4.0
	RP-15	RP-020073			Number of UTRAN and Inter-RAT frequencies	4.3.0	4.4.0
	RP-15	RP-020073	1353		Abortion of signalling connection establishment	4.3.0	4.4.0
	RP-15	RP-020073	1358		Modification of GPS timing representation to avoid large integers	4.3.0	4.4.0
	RP-15	RP-020074	1360		Additional TFCS selection guidelines	4.3.0	4.4.0
	RP-15	RP-020074	1362		Clarification of layer 3 filtering of measurements in the UE	4.3.0	4.4.0
	RP-15	RP-020210	1364		Improved readability of procedural text	4.3.0	4.4.0
	RP-15	RP-020228	1366		Clarification on ICS version within UE radio access capabilities	4.3.0	4.4.0
	RP-15	RP-020233	1368		Clarification of Maximum number of TFC in the TFCS	4.3.0	4.4.0
	RP-15	RP-020238	1370		Support of UP measurement reporting in CELL_PCH/URA_PCH	4.3.0	4.4.0
	RP-15	RP-020082	1122	2	Correction to include Cell ID for Cell_DCH state	4.3.0	4.4.0
	RP-15	RP-020082	1187	2	Correction of Transparent mode signalling for UL rate control	4.3.0	4.4.0
	RP-15	RP-020082	1188	2	Introduction of default radio configurations for UMTS_AMR2 with four speech modes	4.3.0	4.4.0
	RP-15	RP-020082	1223	1	Acquisition of PLMN identity of neighbour cells via SIB 18	4.3.0	4.4.0
	RP-15	RP-020082	1254		Various ASN.1 Corrections	4.3.0	4.4.0
	RP-15	RP-020082	1290		Handover from UTRAN failure	4.3.0	4.4.0
	RP-15	RP-020082	1335		Corrections to indicate that SIB 14 is not used by 1.28 TDD	4.3.0	4.4.0
	RP-15	RP-020084	1129	2	Support of flexible hard split mode	4.4.0	5.0.0
	RP-15	RP-020090	1225	1	Introduction of the parameters of OTDOA with IPDL for 1.28 Mcps TDD	4.4.0	5.0.0
	RP-15	RP-020085		1	Radio link timing	4.4.0	5.0.0
	RP-15	RP-020094		2	Introduction of HSDPA	4.4.0	5.0.0
06/2002	RP-16	RP-020330	1373		ASN.1 Corrections	5.0.0	5.1.0
	RP-16	RP-020330	1376		Clarification of unnecessary MP IEs in RADIO BEARER RECONFIGURATION	5.0.0	5.1.0
	RP-16	RP-020330	1379		Correction on SIB type	5.0.0	5.1.0
	RP-16	RP-020330	1382		Clarification to the handling of IE "Cells for measurement" received in SIB 11/12	5.0.0	5.1.0
	RP-16	RP-020330		1	Correction to Cell Update procedure	5.0.0	5.1.0
	RP-16	RP-020330	1388		Correction to handling of FACH measurement occasion info in SIB12	5.0.0	5.1.0
	RP-16	RP-020331	1392		Actions when optional IE "Maximum allowed UL TX power" is missing	5.0.0	5.1.0
	RP-16	RP-020331	1395		Corrections concerning default configurations	5.0.0	5.1.0
	RP-16	RP-020331	1398		Correction concerning when hard handover specific handling applies	5.0.0	5.1.0
	RP-16	RP-020331	1401		Handling of variables CELL_INFO_LIST and MEASUREMENT_IDENTITY	5.0.0	5.1.0
	RP-16	RP-020331	1404		IE "Cell Synchronisation Information"	5.0.0	5.1.0
	RP-16	RP-020331	1407		Corrections to Cell Individual Offset	5.0.0	5.1.0
	RP-16	RP-020332	1410		Clarification to Compressed Mode Status Info	5.0.0	5.1.0

		Change history						
Date	TSG#	TSG Doc.	CR	Rev	Subject/Comment	Old	New	
	RP-16	RP-020332	1413		Clarification of OTDOA quality figure	5.0.0	5.1.0	
	RP-16	RP-020332	1416		Correction to Cell Access Restriction for SIB4	5.0.0	5.1.0	
	RP-16	RP-020332	1419		Corrections concerning spare values and comments	5.0.0	5.1.0	
	RP-16	RP-020332	1423		Variable for shared channel configurations	5.0.0	5.1.0	
	RP-16	RP-020332	1426	1	Integrity protection on RB0	5.0.0	5.1.0	
	RP-16	RP-020333	1429	1	Periodic cell update clarifications	5.0.0	5.1.0	
	RP-16	RP-020333	1432		Multiple cells triggering event 1D	5.0.0	5.1.0	
	RP-16	RP-020333	1435		Disjoint Active Sets in the Active Set Update procedure	5.0.0	5.1.0	
	RP-16	RP-020333	1438		Deletion on compressed mode patterns when moving to CELL_FACH state	5.0.0	5.1.0	
	RP-16	RP-020333	1441		TDD C-RNTI in Cell DCH	5.0.0	5.1.0	
	RP-16	RP-020333		1	CCTrCH Release in TDD	5.0.0	5.1.0	
	RP-16	RP-020334			Layer 3 retransmission of SIGNALLING CONNECTION RELEASE INDICATION	5.0.0	5.1.0	
	RP-16	RP-020334	1450		Alignment of tabular and ASN.1 for UTRAN GPS timing of cell frames resolution	5.0.0	5.1.0	
	RP-16	RP-020334	1453		Correction to Default Radio Configuration Timers	5.0.0	5.1.0	
	RP-16	RP-020334		1	Clarification to number of L3 filters	5.0.0	5.1.0	
	RP-16	RP-020334		1	Correction to 3G to 2G Inter-RAT handover for multi-domain RABs	5.0.0	5.1.0	
	RP-16	RP-020334		1	DCH quality target	5.0.0	5.1.0	
	RP-16	RP-020335			Correction to RB Mapping Info	5.0.0	5.1.0	
	RP-16	RP-020335		1	Ciphering activation for TM bearers	5.0.0	5.1.0	
	RP-16	RP-020335		1	TFCS selection guideline correction	5.0.0	5.1.0	
	RP-16	RP-020382		1	Clarification of Measurement Validity and Valid Measurement Objects	5.0.0	5.1.0	
	RP-16	RP-020363	1483		Remaining clarification of Measurement Validity and Valid Measurement Objects	5.0.0	5.1.0	
	RP-16	RP-020381	1486	1	Traffic Volume Measurement clarifications	5.0.0	5.1.0	
	RP-16	RP-020335	1489		Correction to handling of IE 'Downlink information for each RL'	5.0.0	5.1.0	
	RP-16	RP-020336			Corrections to Security procedure on Missing integrity protection reset on relocation and counter check response actions for asymmetric bearer configurations	5.0.0	5.1.0	
	RP-16	RP-020336	1495		Corrections to cell update interactions with security and SRNS Relocation	5.0.0	5.1.0	
	RP-16	RP-020336	1498		"Out of service" area definition	5.0.0	5.1.0	
	RP-16	RP-020339	1473		RRC connection release procedure in CELL_DCH state	5.0.0	5.1.0	
	RP-16	RP-020339	1475		Correction to DL TM DCCH TF size for Default Configurations	5.0.0	5.1.0	
	RP-16	RP-020339	1477		Corrections in ASN.1 related to SRNS relocation	5.0.0	5.1.0	
	RP-16	RP-020341	1499		HS-DSCH related corrections	5.0.0	5.1.0	
	RP-16	RP-020341	1500		Removal of BLER threshold from IE "Measurement Feedback info"	5.0.0	5.1.0	
	RP-16	RP-020345	1501		RFC 3095 context relocation	5.0.0	5.1.0	
09/2002	RP-17	RP-020541	1504	1	UE behaviour when active set cells are not included in CELL_INFO_LIST	5.1.0	5.2.0	
	RP-17	RP-020541	1507	1	Corrections to handling of IE "Cells for measurement"	5.1.0	5.2.0	
	RP-17	RP-020541	1510		Clarification on the use of UE radio access capability extensions within the INTER RAT HANDOVER INFO message	5.1.0	5.2.0	
	RP-17	RP-020541	1513	1	Correction to RRC connection procedure	5.1.0	5.2.0	
	RP-17	RP-020541	1516	l	Correction to the variable TGPS_IDENTITY	5.1.0	5.2.0	
	RP-17	RP-020541		1	Missing IEs in RLC info	5.1.0	5.2.0	
	RP-17	RP-020542		1	Corrections of UE internal measurement reporting events	5.1.0	5.2.0	
	RP-17	RP-020542		2	UE behaviour upon reception of reconfiguration	5.1.0	5.2.0	
	RP-17	RP-020542			Application of integrity keys in case of a pending CN domain switch during a SRNS relocation	5.1.0	5.2.0	
	RP-17	RP-020542	1537	1	Clarifications on Quality Measurements	5.1.0	5.2.0	
	RP-17	RP-020542			Correction of DPCH constant value in TDD default radio configurations	5.1.0	5.2.0	
	RP-17	RP-020542	1543		Handling of UE internal measurement information in broadcast	5.1.0	5.2.0	
	RP-17	RP-020543		1	Observed time difference to GSM reporting indicator	5.1.0	5.2.0	
	RP-17	RP-020543			Corrections on Security relative to ciphering of TM bearers and to SRNS relocation	5.1.0	5.2.0	
	RP-17	RP-020543	1554	1	Coding of IE NC mode	5.1.0	5.2.0	
	RP-17	RP-020543		1	Clarification to filtered measurement quantities	5.1.0	5.2.0	
					•			

					Change history		
Date	TSG#	TSG Doc.	CR	Rev	Subject/Comment	Old	New
	RP-17	RP-020543	1560		Inconsistencies in triggering and reporting for events 1a, 1b,1c, 1e and 1f	5.1.0	5.2.0
	RP-17	RP-020543	1563	1	Optional and Mandatory fields in Measurement Control	5.1.0	5.2.0
	RP-17	RP-020544	1566		Clarifications to Reporting Cell Status	5.1.0	5.2.0
	RP-17	RP-020544	1569		Clarification to minimum SF	5.1.0	5.2.0
	RP-17	RP-020544	1572		Clarifications to inter-frequency measurements	5.1.0	5.2.0
	RP-17	RP-020544	1578	2	Ciphering when HO to UMTS of signalling only connection	5.1.0	5.2.0
	RP-17	RP-020544	1581		Inter RAT handover from UTRAN	5.1.0	5.2.0
	RP-17	RP-020544	1584		Correction to Cell Update procedure with cause "Radio link failure"	5.1.0	5.2.0
	RP-17	RP-020545	1587		Correction to the handling of IE "UTRAN DRX cycle length coefficient" in CELL/URA UPDATE procedure	5.1.0	5.2.0
	RP-17	RP-020545	1590		Correction to RLC unrecoverable error occurs in CELL_DCH state	5.1.0	5.2.0
	RP-17	RP-020545	1593		Use of scrambling change when activating CM pattern using SF/2 by MEASUREMENT CONTROL	5.1.0	5.2.0
	RP-17	RP-020545			Actions when optional IE "Maximum allowed UL TX power" is missing	5.1.0	5.2.0
	RP-17	RP-020630		1	IP_offset correction	5.1.0	5.2.0
	RP-17	RP-020545	1602		Clarification on the IE "Frequency Info"	5.1.0	5.2.0
	RP-17	RP-020546			Correction of RNTI used in PUSCH capacity request and physical shared channel allocation	5.1.0	5.2.0
	RP-17	RP-020546			Correction to allowed logical channel list choice for RACH transport channels		5.2.0
	RP-17	RP-020654	_	1	Clarification of SRNS Relocation Info	5.1.0	5.2.0
	RP-17	RP-020546			DCH quality target	5.1.0	5.2.0
	RP-17	RP-020546			Handling of variables CELL_INFO_LIST and MEASUREMENT_IDENTITY(2)	5.1.0	5.2.0
	RP-17	RP-020546	1620	1	Correction of secondary CCPCH selection and PRACH selection	5.1.0	5.2.0
	RP-17	RP-020547	1623		RRC TVM Corrections	5.1.0	5.2.0
	RP-17	RP-020547	1626		Correction of Transmission Gap Distance semantics description	5.1.0	5.2.0
	RP-17	RP-020547	1629		Corrections to Active Set Update and simultaneous reconfiguration	5.1.0	5.2.0
	RP-17	RP-020547	1632		UE behaviour following RLC size change	5.1.0	5.2.0
	RP-17	RP-020547	1635		RRC SN in uplink	5.1.0	5.2.0
	RP-17	RP-020547	1638		Multiplexing of Tr mode RBs of different CN domains on the same transport channel	5.1.0	5.2.0
	RP-17	RP-020548	1641		Security clarifications	5.1.0	5.2.0
	RP-17	RP-020548			Correction to the actions of "out of service area" and "in service area"	5.1.0	5.2.0
	RP-17	RP-020548			TVM: pending time after trigger and initial conditions	5.1.0	5.2.0
	RP-17	RP-020548		1	Handling of Downlink information for each RL in reconfiguration messages	5.1.0	5.2.0
	RP-17	RP-020548			Corrections to Cell Update/URA Update Procedure in case of nested cell updates and simultaneous SRNS relocation	5.1.0	5.2.0
	RP-17	RP-020548			Corrections to security	5.1.0	5.2.0
	RP-17	RP-020631		1	SRNS relocation with integrity	5.1.0	5.2.0
	RP-17	RP-020549			Reception of MEASUREMENT CONTROL in state CELL_FACH	5.1.0	5.2.0
	RP-17	RP-020549			Unsupported configuration	5.1.0	5.2.0
	RP-17	RP-020549			Handover corrections	5.1.0	5.2.0
	RP-17	RP-020558		1	Correction of SFN-SFN Measurement	5.1.0	5.2.0
	RP-17	RP-020559	1661		Corrections to Synchronisation for 1.28 Mcps TDD	5.1.0	5.2.0
	RP-17	RP-020553			Corrections on Power Control for 1.28 Mcps TDD	5.1.0	5.2.0
	RP-17	RP-020553	1659		Correction to RLC entity re-establishment during SRNS relocation	5.1.0	5.2.0
	RP-17	RP-020553	1663		Reintroduction of IE "SRB delay" in Rel-4 ASN.1	5.1.0	5.2.0
	RP-17	RP-020553	1665		Corrections to ASN.1 for SRNC relocation container	5.1.0	5.2.0
	RP-17	RP-020553	1667		Unused elements in ASN.1	5.1.0	5.2.0
	RP-17	RP-020557	1547		Correction on Radio link timing	5.1.0	5.2.0
	RP-17	RP-020662	1651	2	Physical layer IEs for HSDPA	5.1.0	5.2.0
	RP-17	RP-020557	1652		Transport channel information elements for HSDPA	5.1.0	5.2.0
	RP-17	RP-020590			TX diversity on radio links in the active set	5.1.0	5.2.0
	RP-17	RP-020557			Mandatory Support of dedicated pilots for channel estimation	5.1.0	5.2.0
12/2002	RP-18	RP-020721	1687		Corrections to IEs "Ellipsoid point with Altitude and uncertainty	5.2.0	5.3.0
					Ellipsoid" and "Ellipsoid point with uncertainty Ellipse"		

					Change history		
Date	TSG #	TSG Doc.	CR	_	Subject/Comment	Old	New
	RP-18	RP-020721		1	Handling of Ciphering and integrity protection activation times	5.2.0	5.3.0
	RP-18	RP-020721	1693		Handling of measurements at state transitions to/from DCH state.	5.2.0	5.3.0
	RP-18	RP-020721		2	Measurement related corrections	5.2.0	5.3.0
	RP-18	RP-020721	1699		ASN.1 of the SRNS relocation info	5.2.0	5.3.0
-	RP-18	RP-020721		1	Corrections to PRACH selection	5.2.0	5.3.0
	RP-18	RP-020722			TDD Downlink Path Loss for interfrequency measurement	5.2.0	5.3.0
-	RP-18	RP-020892		1	Correction on coding of GSM Classmark 2 and 3	5.2.0	5.3.0
-	RP-18	RP-020722	_		Correction on Frame Allocation Calculation	5.2.0	5.3.0
-	RP-18	RP-020722			Inter-frequency measurements	5.2.0	5.3.0
-	RP-18	RP-020722			Maximum Allowed UL TX Power	5.2.0	5.3.0
	RP-18	RP-020722			START values for the initialisation of SRB counters and UTRAN incorrect actions	5.2.0	5.3.0
	RP-18	RP-020723			Correction to the RRC transaction table management	5.2.0	5.3.0
	RP-18	RP-020723			Use of DCH Quality Target with Blind Transport Format Detection	5.2.0	5.3.0
	RP-18	RP-020723			Correction to storing current TFC subset in variable TFC_SUBSET for TDD	5.2.0	5.3.0
	RP-18	RP-020723			Security at inter-RAT handover	5.2.0	5.3.0
	RP-18	RP-020723			Integrity protection activations times	5.2.0	5.3.0
	RP-18	RP-020723			Additional measurements	5.2.0	5.3.0
	RP-18	RP-020724	1754		DPCH compressed mode info in Downlink information common for all RLs	5.2.0	5.3.0
	RP-18	RP-020724		1	Handling of RB mapping	5.2.0	5.3.0
	RP-18	RP-020724			RLC window size in default configurations	5.2.0	5.3.0
	RP-18	RP-020724			Corrections to Activation time	5.2.0	5.3.0
	RP-18	RP-020724	1772		Numbering of "ASC Setting" IEs included in "PRACH partitioning" IE	5.2.0	5.3.0
	RP-18	RP-020724	1779	2	Correction on support for compressed mode	5.2.0	5.3.0
	RP-18	RP-020903	1734	3	Introduction of backwards compatible correction mechanism	5.2.0	5.3.0
	RP-18	RP-020727	1776		Signalling of the timing adjustment mode for closed loop Tx diversity	5.2.0	5.3.0
	RP-18	RP-020893	1810		Handling of hyper frame numbers	5.2.0	5.3.0
	RP-18	RP-020726	1760	2	Early UE Specific Behaviour Information in RRC Connection Request / interRAT info	5.2.0	5.3.0
	RP-18	RP-020858	1701		Correction of ASN1 IE "InterFreqCellInfoList-r4"	5.2.0	5.3.0
	RP-18	RP-020858	1703		Correction of Special Burst Scheduling for TDD	5.2.0	5.3.0
	RP-18	RP-020858	1705		Correction of measurement reporting event 6f for 1.28 Mcps TDD	5.2.0	5.3.0
	RP-18	RP-020858	1781		Ciphering during SRNS relocation without reuse of COUNT-C	5.2.0	5.3.0
	RP-18	RP-020858	1783		Correction to IE 'Intra Domain NAS Node Selector'	5.2.0	5.3.0
	RP-18	RP-020858	1785		Correction to PRACH selection	5.2.0	5.3.0
	RP-18	RP-020859	1787		Correction to reporting event 6f for FDD	5.2.0	5.3.0
	RP-18	RP-020859	1802		ASN.1 corrections	5.2.0	5.3.0
	RP-18	RP-020859			Asymmetric ROHC Configuration	5.2.0	5.3.0
	RP-18	RP-020859			Reference Cell for GSM OTD Measurement	5.2.0	5.3.0
	RP-18	RP-020736			RRC container for RFC3095 context	5.2.0	5.3.0
	RP-18	RP-020736			Correction to IE 'Access stratum release indicator'	5.2.0	5.3.0
	RP-18	RP-020736			RLC capability for HSDPA	5.2.0	5.3.0
	RP-18	RP-020736			Dedicated pilot bits for HS-DSCH	5.2.0	5.3.0
	RP-18	RP-020736			Expansion of CPICH RSCP range	5.2.0	5.3.0
	RP-18	RP-020736			L3 Retransmission of event 1b	5.2.0	5.3.0
	RP-18	RP-020736			DPC mode change in ACTIVE SET UPDATE message	5.2.0	5.3.0
	RP-18	RP-020736			Correction to handling of IE 'Downlink information for each RL'	5.2.0	5.3.0
	RP-18	RP-020896		2	HSDPA parameter value ranges	5.2.0	5.3.0
03/2003		RP-030103			ASN.1 of the SRNS relocation Info	5.3.0	5.4.0
	RP-19	RP-030103			Correction to procedural text for Physical Shared Channel Allocation (TDD only)	5.3.0	5.4.0
	RP-19	RP-030103		1	CM and state transition related to measurements, additional measurements, virtual active set and periodic measurements	5.3.0	5.4.0
	RP-19	RP-030103			Physical channel failure and radio link re-establishment	5.3.0	5.4.0
	RP-19	RP-030103	1825		Correction concerning bit numbering convention	5.3.0	5.4.0

D-1-	ITOO #	TOO Dee	lon.	I	Change history		IN
Date	TSG # RP-19	TSG Doc. RP-030104	CR	Rev	Subject/Comment Additional Measurement reporting list	Old 5.3.0	New 5.4.0
	RP-19	RP-030104		2	Correction on RRC integrity protection procedure	5.3.0	5.4.0
	RP-19	RP-030104			Reporting Cell Status and Event 2A	5.3.0	5.4.0
	RP-19	RP-030104			Correction to the handling of variable TGPS_IDENTITY and IE	5.3.0	5.4.0
	1(1-13	1030104	1040		'Triggering condition 1/2'	3.3.0	5.4.0
	RP-19	RP-030104	1843	1	Hard handover with pending ciphering activation times	5.3.0	5.4.0
	RP-19	RP-030105	1846		Correction of default configurations	5.3.0	5.4.0
	RP-19	RP-030105	1849		Correction to UE behaviour on entering RRC Connected mode	5.3.0	5.4.0
	RP-19	RP-030105	1855		Update of Start values in USIM on inter-RAT transitions and transitions to idle mode	5.3.0	5.4.0
	RP-19	RP-030082	1858		Corrections to Channelisation Code TFCI Mapping for TDD	5.3.0	5.4.0
	RP-19	RP-030111	1860		Correction of PNBSCH for 1.28Mcps TDD	5.3.0	5.4.0
	RP-19	RP-030111	1862		Correction of SFN-SFN observed time difference for 1.28Mcps TDD	5.3.0	5.4.0
	RP-19	RP-030111	1864	3	ASN.1 corrections concerning missing UE capability extensions	5.3.0	5.4.0
	RP-19	RP-030111	1866		Extensions for 1.28 Mcps specific elements in system information	5.3.0	5.4.0
	RP-19	RP-030111	1868		Corrections to power control parameter signalling for 1.28 Mcps TDD	5.3.0	5.4.0
	RP-19	RP-030117	1872		TDD HS-SICH Power Control	5.3.0	5.4.0
	RP-19	RP-030117	1873		Usage of separate scrambling code for HSDPA	5.3.0	5.4.0
	RP-19	RP-030119	1874		TDD HS-DSCH midamble shift and burst type	5.3.0	5.4.0
	RP-19	RP-030117	1875		Corrections to the IE "Added or Reconfigured MAC-d flow" and the associated table in 10.3.10	5.3.0	5.4.0
	RP-19	RP-030117	1877	1	Network Assisted Cell Change from UTRAN to GERAN	5.3.0	5.4.0
	RP-19	RP-030117	1878	1	Defining more than one DSCH / USCH transport channel in PDSCH and PUSCH system information (TDD only)	5.3.0	5.4.0
	RP-19	RP-030117	1879		Introducing the use of pre-defined configurations within UTRA	5.3.0	5.4.0
	RP-19	RP-030120	1880		Group release (without security	5.3.0	5.4.0
	RP-19	RP-030105	1884		Correction to Inter-RAT Measurement Report	5.3.0	5.4.0
	RP-19	RP-030106	1887		Correction of signalling of transport block size for DSCH	5.3.0	5.4.0
	RP-19	RP-030106	1890		PS service continuity when moving between 3G and 2G	5.3.0	5.4.0
	RP-19	RP-030106	1893	1	Multiple activations of the same compressed mode pattern	5.3.0	5.4.0
	RP-19	RP-030106	1896		Setting of ciphering activation time for TM bearers	5.3.0	5.4.0
	RP-19	RP-030117	1897		Correction of shadow CR implementation	5.3.0	5.4.0
	RP-19	RP-030111	1899		Removal of MRRU parameter in PDCP info	5.3.0	5.4.0
	RP-19	RP-030117	1900		Measurement event for evaluation of best HS-DSCH cel	5.3.0	5.4.0
	RP-19	RP-030105	1902	1	NAS and Integrity procedure interaction	5.3.0	5.4.0
	RP-19	RP-030117	1903		Correction to USBI	5.3.0	5.4.0
	RP-19	RP-030187	1909		GPS navigation model update mechanism	5.3.0	5.4.0
	RP-19	RP-030201	1910		Layer 3 filtering definition	5.3.0	5.4.0
	RP-20	RP-030293	1913		Handling of UP Assistance Data	5.4.0	5.5.0
	RP-20	RP-030293		1	Concerns on Procedures for Cell-ID Positioning Method	5.4.0	5.5.0
	RP-20	RP-030293	1919		Inconsistency between Procedural, ASN.1, and Tabular Aspects of UE Positioning Error	5.4.0	5.5.0
	RP-20	RP-030293	1922		Removal of FFS (For further Study) and references to other working groups	5.4.0	5.5.0
	RP-20	RP-030293	1926		Key handling when entering idle mode and coding of security capabilities	5.4.0	5.5.0
	RP-20	RP-030293	1929		Security actions when SIM is present on RRC Connection Request	5.4.0	5.5.0
	RP-20	RP-030294	1932		Update of interfrequency measurement cell info list, reading of SIB11/12, inclusion of Measured Results on RACH	5.4.0	5.5.0
	RP-20	RP-030294	1937		Additional measurements without measurement validity	5.4.0	5.5.0
	RP-20	RP-030294	1940		Handover to UTRAN in macrodiversity	5.4.0	5.5.0
	RP-20	RP-030294	1943	1	TVM Reporting in CELL_PCH state	5.4.0	5.5.0
	RP-20	RP-030294	1946	1	Initialisation of the Virtual Active Set	5.4.0	5.5.0
	RP-20	RP-030295	1949		IE 'Tx diversity mode' in ACTIVE SET UPDATE message	5.4.0	5.5.0
	RP-20	RP-030295	1952	1	Correction to transport channel traffic volume measurement events 4a and 4b	5.4.0	5.5.0
	RP-20	RP-030295	1955		Maximum Number of GPS Almanac Messages to be Stored in UE_POSITIONING_GPS_DATA	5.4.0	5.5.0
	RP-20	RP-030374	1958	2	Stopping of RLC entities at relocation	5.4.0	5.5.0
	RP-20	RP-030369	1978	4	Ciphering Mode info IE in 2G-3G Handover	5.4.0	5.5.0

					Change history		
Date	TSG#	TSG Doc.	CR	Rev	Subject/Comment	Old	New
	RP-20	RP-030295	1981		START values on 2G-3G handover	5.4.0	5.5.0
	RP-20	RP-030298			ROHC profile signalling	5.4.0	5.5.0
	RP-20	RP-030298		1	Optimisation of the INTER RAT HANDOVER INFO message	5.4.0	5.5.0
	RP-20	RP-030350	1987	2	Corrections to security procedures in case of pending security configurations at SRNS Relocation	5.4.0	5.5.0
	RP-20	RP-030371	1990		Setting of T317 to infinity and out of service behaviour	5.4.0	5.5.0
	RP-20	RP-030303	1960		Correction to the IE "HS-DSCH capability class"	5.4.0	5.5.0
	RP-20	RP-030303	1961		Correction of 'RB mapping info' in case HS-DSCH + DCH	5.4.0	5.5.0
	RP-20	RP-030303	1963		Explanation of CV-UE for the IE MidambleShift in the tabular	5.4.0	5.5.0
09/2003	RP-21	RP-030484	1993		Handling of key sets at Inter-RAT Handover to UTRAN	5.5.0	5.6.0
	RP-21	RP-030484	1996		Correction to UE Positioning privacy procedures	5.5.0	5.6.0
	RP-21	RP-030520	2003	2	START calculation in connected mode	5.5.0	5.6.0
	RP-21	RP-030506	2000	1	Reconfiguration with state transition to an indicated cell on a	5.5.0	5.6.0
					different frequency		
	RP-21	RP-030484			PRACH channelisation code list limitation to align with TS 25.221	5.5.0	5.6.0
	RP-21	RP-030484			Handling of transport channel information at radio bearer release	5.5.0	5.6.0
	RP-21	RP-030485	2015		Corrections for TDD for the IEs 'Downlink DPCH info common for all radio links'	5.5.0	5.6.0
	RP-21	RP-030485	2018		TFCS selection guidelines for TFC Subset	5.5.0	5.6.0
	RP-21	RP-030485			Value range of UE Rx-Tx time difference type 2 measurement	5.5.0	5.6.0
	RP-21	RP-030485	2033		Activation Time for DSCH	5.5.0	5.6.0
	RP-21	RP-030485	2044		Correction of PDCP Configuration for RFC 2507	5.5.0	5.6.0
	RP-21	RP-030486	2048		Corrections to event list handling	5.5.0	5.6.0
	RP-21	RP-030486	2051		Corrections to RACH reporting	5.5.0	5.6.0
	RP-21	RP-030486	2054		Corrections to modification of Additional Measurement lists	5.5.0	5.6.0
	RP-21	RP-030486	2057		UE positioning support in the UE	5.5.0	5.6.0
	RP-21	RP-030478	2064		Elimination of EPC mechanism	5.5.0	5.6.0
	RP-21	RP-030486	2069		UE behaviour in transition from CELL_DCH to CELL_FACH/ CELL_PCH/URA_PCH and Out of Service is detected	5.5.0	5.6.0
	RP-21	RP-030505	2072	1	Radio link failure during reconfiguration procedure	5.5.0	5.6.0
	RP-21	RP-030491	2020		Ciphering of TM SRBs	5.5.0	5.6.0
	RP-21	RP-030491	2022	1	Correction on PDCP Header compression Configuration	5.5.0	5.6.0
	RP-21	RP-030491	2027		Corrections for TDD PUSCH	5.5.0	5.6.0
	RP-21	RP-030495	1997		Correction to UE behaviour on T317 expiry	5.5.0	5.6.0
	RP-21	RP-030495	2029		Correcting value range of MAC-hs buffer ID	5.5.0	5.6.0
	RP-21	RP-030495	2030		Correction of handling of IE "MAC-hs reset indicator" in Added or Reconfigured DL TrCH information	5.5.0	5.6.0
	RP-21	RP-030495	2035	1	UE capability signalling for UMTS1800	5.5.0	5.6.0
	RP-21	RP-030495	2039		Handover between UTRAN and GERAN lu mode	5.5.0	5.6.0
	RP-21	RP-030495	2040		Updated references to the RRC State Indicator IE	5.5.0	5.6.0
	RP-21	RP-030495	2041		Corrections to Event 1D	5.5.0	5.6.0
	RP-21	RP-030449	2028		Reconfiguration of MAC-d flow	5.5.0	5.6.0
	RP-21	RP-030462	2061		HS-SCCH transmit diversity mode	5.5.0	5.6.0
	RP-21	RP-030503	2066		Scrambling code & phase reference combinations for HS-DSCH (solution 2)	5.5.0	5.6.0
12/2003	RP-22	RP-030617	2075		Unsuccessful security mode control procedure and Integrity Protection	5.6.0	5.7.0
	RP-22	RP-030625	2076		START value calculation for RLC size change	5.6.0	5.7.0
	RP-22	RP-030617	2079		UE Positioning UE based assisted GPS	5.6.0	5.7.0
	RP-22	RP-030617	2085	Ī	Handling of zero-rate TrCHs in TFCS	5.6.0	5.7.0
	RP-22	RP-030617	2091	3	Measurement control for A-GPS	5.6.0	5.7.0
	RP-22	RP-030621	2093		Corrections to 1.28 Mcps TDD power control: ASN1/Tabular consistency, correction of omissions	5.6.0	5.7.0
	RP-22	RP-030621	2095		UpPCH power control for 1.28Mcps	5.6.0	5.7.0
	RP-22	RP-030617		1	Interaction between compressed mode pattern activation and message activation time	5.6.0	5.7.0
	RP-22	RP-030625	2103		Initialisation of virtual active set	5.6.0	5.7.0
	RP-22	RP-030611		1	Correction to Redirection procedure at RRC Connection Setup	5.6.0	5.7.0
	RP-22	RP-030610			SFN associated with GPS timing of cell frame	5.6.0	5.7.0

					Change history		
Date	TSG#	TSG Doc.	CR	Rev	Subject/Comment	Old	New
	RP-22	RP-030618			Measurement Handling In State Transition for UE Positioning	5.6.0	5.7.0
	RP-22	RP-030618			Corrections to UE positioning reporting for UE assisted and UE based methods	5.6.0	5.7.0
	RP-22	RP-030662		1	SIB 7 reading	5.6.0	5.7.0
	RP-22	RP-030662			HFN initialisation in case of pending security configurations	5.6.0	5.7.0
	RP-22	RP-030621		1	General protocol error handling failure for DL CCCH messages due to ASN.1 error	5.6.0	5.7.0
	RP-22	RP-030621			Corrections relating to 1.28 Mcps TDD	5.6.0	5.7.0
	RP-22	RP-030621			Missing CHOICE RLC Info type in the ASN.1 IE "RB-InformationSetup-r4"	5.6.0	5.7.0
	RP-22	RP-030625		1	RRM in PCH/FACH	5.6.0	5.7.0
	RP-22	RP-030625			Correction of operating band reference	5.6.0	5.7.0
	RP-22	RP-030713		1	Re-ordering Queue and HARQ Ids	5.6.0	5.7.0
	RP-22	RP-030625			Correction to the procedural description: Reconfiguration of MAC-d flow	5.6.0	5.7.0
	RP-22	RP-030625		1	Enhancement of RRC transaction identifier for measurement control message	5.6.0	5.7.0
	RP-22	RP-030629			Inclusion of a default configuration identity for AMR-WB	5.6.0	5.7.0
	RP-22	RP-030625			TDD C-RNTI in Cell DCH	5.6.0	5.7.0
	RP-22 RP-22	RP-030662 RP-030625			Additional Measurements List Modify IP activation time for RB0	5.6.0 5.6.0	5.7.0 5.7.0
	RP-22 RP-22	RP-030625 RP-030722		3		5.6.0	5.7.0
	RP-22 RP-22	RP-030722 RP-030612		3	Minimum UE capability class Measured results on RACH	5.6.0	5.7.0
	RP-22 RP-22	RP-030612 RP-030625		4	COUNT-I reverting in case Security Mode Control procedure failure	5.6.0	5.7.0
	Editorial	KF -030023	2139		Repair corrupted figures	5.7.0	5.7.1
03/2004	RP-23	RP-040095	2167	2	Response on SRNS Relocation with Cell Update	5.7.1	5.8.0
03/2004	RP-23	RP-040095		_	TPC Combination Index in SRNC relocation	5.7.1	5.8.0
	RP-23	RP-040107		1	Correction to "Current TGPS Status Flag"	5.7.1	5.8.0
	RP-23	RP-040095		1	Invalidation of START value in USIM/UE.	5.7.1	5.8.0
	RP-23	RP-040095		1	Uplink Integrity protection handling in case of N302 increment	5.7.1	5.8.0
	RP-23	RP-040095		1	Amount of reporting for UE-based and UE assisted A-GPS	5.7.1	5.8.0
	RP-23	RP-040101		1	Ensuring decoding possibility related to Introduction of new bands	5.7.1	5.8.0
	RP-23	RP-040101		1	Clarification to multimode indication	5.7.1	5.8.0
	RP-23	RP-040101			Correction for 1.28 Mcps TDD Power Control	5.7.1	5.8.0
	RP-23	RP-040101			Missing "pdcp-SN-info" in ASN.1 IE "RB-InformationReconfig-r4"	5.7.1	5.8.0
	RP-23	RP-040107	2206		Correction to HS-SCCH info	5.7.1	5.8.0
	RP-23	RP-040107	2208		Correction to HS-SCCH info	5.7.1	5.8.0
	RP-23	RP-040107	2212		Correction to activation time for HS-DSCH reconfiguration in TDD	5.7.1	5.8.0
	RP-23	RP-040131	2216	3	Connected mode handling IE 'CN domain system information' in SIB1	5.7.1	5.8.0
	RP-23	RP-040096	2220		Correction to event 6D	5.7.1	5.8.0
	RP-23	RP-040096	2224	1	Correction to UE positioning reporting for GPS standalone operation mode	5.7.1	5.8.0
	RP-23	RP-040092			Frequency band alignment with 25.101	5.7.1	5.8.0
	RP-23	RP-040096	2234		UTRAN setting of the activation time for TM bearers in Ciphering Mode info IE	5.7.1	5.8.0
	RP-23	RP-040096			Corrections to "Entered parameter"	5.7.1	5.8.0
	RP-23	RP-040097			Corrections to TFC Subset Functionality	5.7.1	5.8.0
	RP-23	RP-040097		1	Waiting for RLC-ACK on UMI	5.7.1	5.8.0
	RP-23	RP-040101		1	General correction and alignment of the ASN.1 and tabular	5.7.1	5.8.0
	RP-23	RP-040101			Introduction of VLEC in every message branch	5.7.1	5.8.0
	RP-23	RP-040107			Simultaneous Reception of S-CCPCH and HS-DSCH	5.7.1	5.8.0
	RP-23	RP-040107			Cell reselection between UTRAN and GERAN lu mode	5.7.1	5.8.0
	RP-23	RP-040108			HSDPA related corrections on buffer flushing on state transitions, RAT transitions, error cases, MAC-hs reconfiguration and readiness to receive HS-PDSCH	5.7.1	5.8.0
	RP-23	RP-040106	2264	2	Signalling of MAC-hs Reset	5.7.1	5.8.0
	RP-23	RP-040131	2266	2	Modification of Inter-frequency CELL_INFO_LIST	5.7.1	5.8.0
	RP-23	RP-040131			[VAS] 1B-1C conflicts when 1A is not configured	5.7.1	5.8.0
	RP-23	RP-040131		1	Handling of wait time in RRC connection reject	5.7.1	5.8.0
	RP-23	RP-040108	2273		Misalignments between R'99 and Rel-5 procedures	5.7.1	5.8.0

	I=== ::	1		_	Change history		T
Date	TSG #	TSG Doc.	CR	Rev	Subject/Comment	Old	New
	RP-23	RP-040097			Issues related to Inter-RAT and Inter-frequency handovers	5.7.1	5.8.0
	RP-23	RP-040097	_	1	Corrections to reconfiguration scenarios and ciphering of TM RBs	5.7.1	5.8.0
	RP-23	RP-040129	_		HSDPA capability for multimode FDD-TDD terminals	5.7.1	5.8.0
06/2004	RP-24	RP-040203	_		Empty non-critical extensions	5.8.0	5.9.0
	RP-24	RP-040211		1	Missing 'v3g0' extension in the UE CAPABILITY INFORMATION	5.8.0	5.9.0
	RP-24	RP-040203	2302		Correction on System Information in TDD	5.8.0	5.9.0
	RP-24	RP-040236	2304		Corrections to Cell Change Order from UTRAN procedure	5.8.0	5.9.0
	RP-24	RP-040206	2307		Correction on SFN-SFN time difference misalignment in 1.28 Mcps TDD	5.8.0	5.9.0
	RP-24	RP-040207	2310		ASN.1 correction leftovers	5.8.0	5.9.0
	RP-24	RP-040210	2312		Closing the REL-5 extensions in the ASN.1	5.8.0	5.9.0
	RP-24	RP-040207	2315		Incorrect presence of UE-RadioAccessCapability extension in RRC CONNECTION SETUP COMPLETE	5.8.0	5.9.0
	RP-24	RP-040210	2317		Unnecessary MAC-d flow identity in the IE 'DL-TrCH-Type-r5'	5.8.0	5.9.0
	RP-24	RP-040211	2319	1	UE capability enquiry for GERAN lu mode	5.8.0	5.9.0
	RP-24	RP-040207	2322		Clean up of SRNS Relocation Info REL-4 version	5.8.0	5.9.0
	RP-24	RP-040210	2324		Tabular correction for RADIO BEARER RELEASE message	5.8.0	5.9.0
	RP-24	RP-040210	2326		Misalignments betwen R"99 and Rel-5 procedures	5.8.0	5.9.0
	RP-24	RP-040210	2328		Erroneous setting of Re-establsish Indicator in case of SRNS relocation	5.8.0	5.9.0
	RP-24	RP-040207	2331		Correction to IE 'Cell Info'	5.8.0	5.9.0
	RP-24	RP-040210	2333		Correction Concerning UE Positioning Measurement	5.8.0	5.9.0
	RP-24	RP-040236	2335		Pending compressed mode reconfigurations	5.8.0	5.9.0
		RP-040236	2337		Active compressed mode patterns with same measurement purpose	5.8.0	5.9.0
	RP-24	RP-040211	2339		Correction to Information Elements for UE Rx-Tx time difference	5.8.0	5.9.0
	RP-24	RP-040210	2341		Naming correction in the HS-DSCH IE Measurement Feedback Information	5.8.0	5.9.0
	RP-24	RP-040206	2344		Clarification about open loop power control in 1.28Mcps TDD	5.8.0	5.9.0
	RP-24	RP-040206	2347		Clarification about measurement control system information in TDD mode	5.8.0	5.9.0
	RP-24	RP-040211	2349		Correction to timing-maintained hard handover regarding the UL transmission timing	5.8.0	5.9.0
	RP-24	RP-040236		3	Selection of suitable cell	5.8.0	5.9.0
	RP-24	RP-040236	2355		Check of the PLMN identity in the MIB when selecting a new cell	5.8.0	5.9.0
	RP-24	RP-040211			Compressed INTER RAT HANDOVER INFO message modifications/corrections	5.8.0	5.9.0
	RP-24	RP-040224	2360		RLC size handling and RLC re-establishment	5.8.0	5.9.0
	RP-24	RP-040212	2362		Restrict operation of the virtual active set	5.8.0	5.9.0
	RP-24	RP-040213	2364		Usage of different RB mapping info	5.8.0	5.9.0
	RP-24	RP-040256	2366	1	Clarification on UE procedure in case of HHO failure	5.8.0	5.9.0

History

	Document history							
V5.0.0	March 2002	Publication						
V5.1.0	June 2002	Publication						
V5.2.0	September 2002	Publication						
V5.3.0	December 2002	Publication						
V5.4.0	March 2003	Publication						
V5.5.0	June 2003	Publication						
V5.6.0	September 2003	Publication						
V5.7.1	January 2004	Publication						
V5.8.0	March 2004	Publication						
V5.9.0	June 2004	Publication						