ETSITS 129 344 V19.0.0 (2025-10)



Universal Mobile Telecommunications System (UMTS); LTE;

Proximity-services (ProSe) function to Home Subscriber Server (HSS) aspects; Stage 3

(3GPP TS 29.344 version 19.0.0 Release 19)



Reference RTS/TSGC-0429344vj00 Keywords LTE,UMTS

ETSI

650 Route des Lucioles F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B Association à but non lucratif enregistrée à la Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from the ETSI Search & Browse Standards application.

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format on ETSI deliver repository.

Users should be aware that the present document may be revised or have its status changed, this information is available in the Milestones listing.

If you find errors in the present document, please send your comments to the relevant service listed under <u>Committee Support Staff</u>.

If you find a security vulnerability in the present document, please report it through our Coordinated Vulnerability Disclosure (CVD) program.

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2025. All rights reserved.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for ETSI members and non-members, and can be found in ETSI SR 000 314: "Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards", which is available from the ETSI Secretariat. Latest updates are available on the ETSI IPR online database.

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

DECTTM, **PLUGTESTS**TM, **UMTS**TM and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP**TM, **LTE**TM and **5G**TM logo are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2M**TM logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM**[®] and the GSM logo are trademarks registered and owned by the GSM Association.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found at 3GPP to ETSI numbering cross-referencing.

Modal verbs terminology

In the present document "shall", "shall not", "should", "should not", "may", "need not", "will", "will not", "can" and "cannot" are to be interpreted as described in clause 3.2 of the <u>ETSI Drafting Rules</u> (Verbal forms for the expression of provisions).

"must" and "must not" are NOT allowed in ETSI deliverables except when used in direct citation.

Contents

Intell	ectual Property Rights	2
Legal	l Notice	2
Moda	al verbs terminology	2
Forev	word	5
1	Scope	
	•	
2	References	
3	Definitions, symbols and abbreviations	
3.1 3.2	Definitions	
4	General Description	
4.1	Introduction	
5	Procedure Descriptions	
5.1	Introduction	
5.2 5.2.1	General	
5.2.1	Detailed Behaviour of the ProSe Function	
5.2.3	Detailed Behaviour of the HSS	
5.2.5	Update ProSe Subscriber Data	
5.3.1	General	
5.3.2	Detailed behaviour of the ProSe Function	
5.3.3	Detailed behaviour of the HSS	
5.4	Notification Procedure	
5.4.1	General	
5.4.2	Detailed Behaviour of the ProSe Function	
5.4.3	Detailed Behaviour of the HSS	
5.5	Reset	13
5.5.1	General	13
5.5.2	Detailed behaviour of the ProSe Function	13
5.5.3	Detailed behaviour of the HSS	
5.6	Initial Location Information Retrieval	14
5.6.1	General	
5.6.2	Detailed Behaviour of the ProSe Function	
5.6.3	Detailed Behaviour of the HSS	15
6	Protocol Specification and Implementations.	16
6.1	Introduction	
6.1.1	Use of Diameter Base Protocol.	
6.1.2	Securing Diameter Messages	
6.1.3	Accounting Functionality	
6.1.4	Use of Sessions	
6.1.5	Transport Protocol	
6.1.6	Routing Considerations	
6.1.7	Advertising Application Support	
6.1.8	Diameter Application Identifier	
6.1.9	Use of the Supported-Features AVP	
6.2	Commands	
6.2.1	Introduction	
6.2.2	Command-Code Values	
6.2.3	ProSe-Subscriber-Information-Request (PIR) Command	
6.2.4	ProSe-Subscriber-Information-Answer (PIA) Command	
6.2.5	Update-ProSe-Subscriber-Data-Request (UPR) Command	
6.2.6 6.2.7	ProSe-Notify-Request (PNR) Command	
0.4.7	1 1000-110th y-request (1 11rt) Collinatia	∠∪

6.2.8	ProSe-Notify-A	nswer (PNA) Command	20
6.2.9	Reset-Request (RSR) Command	20
6.2.10	Reset-Answer (RSA) Command	21
6.2.11	ProSe-Initial-Lo	ocation-Information-Request (PSR) Command	21
6.2.12		ocation-Information-Answer (PSA) Command	
6.3	AVPs		22
6.3.1	General		22
6.3.2	ProSe-Subscrip	tion-Data	23
6.3.3		on	
6.3.4	ProSe-Allowed	-PLMN	24
6.3.5	ProSe-Direct-A	llowed	24
6.3.6	UPR-Flags		25
6.3.7			
6.3.8		/P for the PC4a application	
6.3.9		ocation-Information	
6.3.10			
6.3.11		Features	
6.3.12	1.1		
6.3.13		covery-Range	
6.3.14			
6.3.15			
6.4		and Experimental-Result AVP Values	
6.4.1			
6.4.2			
6.4.3		ures	
6.4.3.1			
6.4.3.2		R_ERROR_USER_UNKNOWN (5001)	
6.4.3.3		R_ERROR_UNKNOWN_PROSE_SUBSCRIPTION (5610)	
6.4.3.4		R_ERROR_PROSE_NOT_ALLOWED (5611)	
6.4.3.5		R_ERROR_ UE_LOCATION_UNKNOWN (5612)	
		(
Annex	A (normative):	Diameter overload control mechanism	
A.1			
A.2			
A.3	ProSe Function bel	naviour	29
	B (Informative):	Diameter overload node behaviour	
B.1	Message prioritizat	ion	30
Annex	C (normative)	Diameter message priority mechanism	31
C.1		Diameter message priority meenanism	
C.2			
C.2.1			
C.2.1		Function behaviour	
C.2.2	1155 and 1105c	Tunction ochavioui	
Annex	D (normative):	Diameter load control mechanism	32
D.1	General		32
D.2	HSS behaviour		32
D.3	ProSe Function bel	naviour	32
A mrs a==	E (information)	Change history	21
Annex	E (informative):	Change history	33
History	7		3/

Foreword

This Technical Specification has been produced by the 3rd Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
 - 1 presented to TSG for information;
 - 2 presented to TSG for approval;
 - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

1 Scope

The present document describes the Diameter-based PC4a interface between the Proximity-based Services (ProSe) Function and the Home Subscriber Server (HSS) defined for ProSe.

This specification defines the Diameter application for PC4a reference point between the ProSe Function and the HSS. The interactions between the ProSe Function and the HSS are specified.

The stage 2 description for Proximity-based Services (ProSe) features in EPS is specified in 3GPP TS 23.303 [2].

2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the same Release as the present document*.

[1]	3GPP TR 21.905: "Vocabulary for 3GPP Specifications".
[2]	3GPP TS 23.303: "Proximity based services; Stage 2".
[3]	Void.
[4]	3GPP TS 33.210: "3G Security; Network Domain Security; IP Network Layer Security".
[5]	IETF RFC 4960: "Stream Control Transmission Protocol".
[6]	3GPP TS 29.229: "Cx and Dx interfaces based on the Diameter protocol".
[7]	3GPP TS 23.003: "Numbering, addressing and identification".
[8]	IETF RFC 5234: "Augmented BNF for Syntax Specifications: ABNF".
[9]	3GPP TS 29.228: "IP multimedia (IM) Subsystem Cx and Dx Interfaces; Signalling flows and Message Elements".
[10]	3GPP TS 29.272: "Evolved Packet System; MME and SGSN Related Interfaces Based on Diameter Protocol".
[11]	3GPP TS 23.007: "Restoration procedures".
[12]	3GPP TS 29.329: "Sh Interface based on the Diameter protocol".
[13]	void
[14]	3GPP TS 29.173: "Location Services (LCS); Diameter-based SLh interface for Control Plane LCS".
[15]	IETF RFC 7683: "Diameter Overload Indication Conveyance".
[16]	3GPP TS 24.334: "Proximity-services (ProSe) User Equipment (UE) to ProSe function protocol aspects; Stage 3".
[17]	3GPP TS 24.333: "Proximity-services (ProSe) Management Objects (MO); Stage 3".
[18]	3GPP TS 29.061: "Interworking between the Public Land Mobile Network (PLMN) supporting packet based services and Packet Data Networks (PDN)".

[19]	3GPP TS 32.251: "Telecommunication management; Charging management; Packet Switched (PS) domain charging".
[20]	3GPP TS 32.298: "Charging Management; CDR parameter description".
[21]	IETF RFC 7944: "Diameter Routing Message Priority".
[22]	IETF RFC 8583: "Diameter Load Information Conveyance".
[23]	IETF RFC 6733: "Diameter Base Protocol".

3 Definitions, symbols and abbreviations

3.1 Definitions

For the purposes of the present document, the terms and definitions given in TR 21.905 [1] and the following apply. A term defined in the present document takes precedence over the definition of the same term, if any, in TR 21.905 [1].

3.2 Abbreviations

For the purposes of the present document, the abbreviations given in 3GPP TR 21.905 [1] and the following apply. An abbreviation defined in the present document takes precedence over the definition of the same abbreviation, if any, in 3GPP TR 21.905 [1].

DRMP Diameter Routing Message Priority
DSCP Differentiated Services Code Point
ProSe Proximity-based Services

4 General Description

4.1 Introduction

The PC4a reference point between the ProSe Function and the HSS is defined in the 3GPP TS 23.303 [2].

This document describes the PC4a interface related procedures, message parameters and protocol specifications.

The PC4a interface allows the ProSe Function to retrieve ProSe related subscription data in order to authorise access from the UE for ProSe.

5 Procedure Descriptions

5.1 Introduction

This clause describes the Diameter-based PC4a interface related procedures and information elements exchanged between the ProSe Function and the HSS.

In the tables that describe the Information Elements transported by each Diameter command, each Information Element is marked as (M) Mandatory, (C) Conditional or (O) Optional in the "Cat." column. For the correct handling of the Information Element according to the category type, see the description detailed in clause 6 of the 3GPP TS 29.228 [9].

5.2 ProSe Subscriber Information Retrieval

5.2.1 General

This procedure shall be used between the ProSe Function and the HSS for authorization of the UE for ProSe. The procedure shall be invoked by the ProSe Function and is used:

- to request ProSe related subscription data.

This procedure is mapped to the commands ProSe-Subscriber-Information-Request/Answer (PIR/PIA) in the Diameter application specified in clause 6. Tables 5.2.1-1 and 5.2.1-2 detail the involved information elements.

Table 5.2.1-1: ProSe Subscriber Information Retrieval Request

Information Element Name	Mapping to Diameter AVP	Cat.	Description
IMSI	User-Name (See IETF RFC 6733 [23])	М	This information element shall contain the user IMSI, formatted according to 3GPP TS 23.003 [7], clause 2.2.
Supported Features (See 3GPP TS 29.229 [6])	Supported-Features	0	If present, this information element shall contain the list of features supported by the origin host.

Table 5.2.1-2: ProSe Subscriber Information Retrieval Answer

Information Element Name	Mapping to Diameter AVP	Cat.	Description
Result (See 6)	Result-Code / Experimental- Result	M	This IE shall contain the result of the operation. The Result-Code AVP shall be used to indicate success / errors as defined in the Diameter base protocol (see IETF RFC 6733 [23]). The Experimental-Result AVP shall be used for PC4a errors. This is a grouped AVP which shall contain the 3GPP Vendor ID in the Vendor-Id AVP, and the error code in the Experimental-Result-Code AVP. The following errors are applicable: - User Unknown - Unknown ProSe Subscription - ProSe Not Allowed
ProSe Subscription Data (See 6.3.2)	ProSe- Subscription-Data	С	This information element shall contain the ProSe Subscription Data that gives the user permission to use ProSe.
MSISDN (See 3GPP TS 29.329 [12])	MSISDN	С	This information element shall contain the user MSISDN, formatted according to 3GPP TS 29.329 [12]. It shall be present if available.
Visited PLMN Id (See 3GPP TS 29.272 [10])	Visited-PLMN-Id	С	This IE shall contain the MCC and the MNC of the PLMN where the UE is registered, see 3GPP TS 23.003 [7]. It shall be present if the UE is roaming in a PLMN different from the Home PLMN.
Supported Features (See 3GPP TS 29.229 [6])	Supported- Features	0	If present, this information element shall contain the list of features supported by the origin host.
Reset-IDs (See 3GPP TS 29.272 [10])	Reset-ID	0	The Reset-ID uniquely identifies a fallible resource in the HSS's realm on which the user (IMSI) depends. In the event of a restart of the fallible resource a Reset message containing the Reset-ID will exactly identify the impacted subscribers.

5.2.2 Detailed Behaviour of the ProSe Function

The ProSe Function shall make use of this procedure to request ProSe related subscription data.

If the ProSe Function retrieved the ProSe related subscription data, the ProSe Function shall perform the authorisation for ProSe as described in the 3GPP TS 23.303 [2].

5.2.3 Detailed Behaviour of the HSS

When receiving a ProSe Subscriber Information Retrieval Request the HSS shall check if the IMSI for whom data is requested exists in the HSS. If not, an Experimental-Result of DIAMETER_ERROR_USER_UNKNOWN shall be returned.

If the IMSI exists but there is not any ProSe subscription data for the IMSI, the HSS shall return an Experimental-Result of DIAMETER_ERROR_UNKNOWN_PROSE_SUBSCRIPTION.

If the UE is not allowed to use ProSe in the visited PLMN, the HSS shall return an Experimental-Result of DIAMETER_ERROR_PROSE_NOT_ALLOWED. Otherwise, the HSS shall return a Result-Code of DIAMETER_SUCCESS and shall store ProSe Function identity (the ProSe Function identity is received within the Origin-Host AVP) and download the ProSe subscription data to the ProSe Function. The HSS shall provide the Visited PLMN ID of where the UE is registered if the UE is roaming in a PLMN different from the Home PLMN.

5.3 Update ProSe Subscriber Data

5.3.1 General

The Update ProSe Subscriber Data procedure shall be used between the ProSe Function and the HSS to update the subscriber related data downloaded by means of the ProSe Subscriber Information Retrieval operation (see clause 5.2) and stored in the ProSe Function.

It shall be used to update subscriber related data in the ProSe Function due to administrative changes of the user data in the HSS, i.e. if the user was given a subscription and the subscription has changed. It shall be used at least to perform the following:

- update of all of ProSe subscription data of the subscriber,
- update of a subset of the ProSe subscription data of the subscriber,
- deletion of the ProSe subscription data of the subscriber.

The procedure will also be triggered when the VPLMN has changed.

This procedure is mapped to the commands Update-ProSe-Subscriber-Data-Request/Answer (UPR/UPA) in the Diameter application specified in clause 6.

Table 5.3.1-1 specifies the involved information elements for the request.

Table 5.3.1-2 specifies the involved information elements for the answer.

Table 5.3.1-1: Update ProSe Subscriber Data Request

Information element name	Mapping to Diameter AVP	Cat.	Description
IMSI	User-Name (See IETF RFC 673 3 [23])	M	This information element shall contain the user IMSI, formatted according to 3GPP TS 23.003 [7], clause 2.2.
Supported Features (See 3GPP TS 29.2 29 [6])	Supported- Features	0	If present, this information element shall contain the list of features supported by the origin host.
ProSe Subscription Data (See 6.3.2)	ProSe- Subscription- Data	С	This information element shall contain the ProSe Subscription Data that gives the user permission to use ProSe.
Visited PLMN Id (See 3GPP TS 29.2 72 [10])	Visited-PLMN- Id	O	This IE shall contain the MCC and the MNC of the PLMN where the UE is registered, see 3GPP TS 23.003 [7]. It shall be present if the UE is roaming in a PLMN different from the Home PLMN.
UPR Flags	UPR-Flags	М	This Information Element shall contain a bit mask. See clause 6.3.6 for the meaning of the bits.
Reset-IDs (See 3GPP TS 29.2 72 [10])	Reset-ID	0	The Reset-ID uniquely identifies a fallible resource in the HSS's realm on which the user (IMSI) depends. In the event of a restart of the fallible resource a Reset message containing the Reset-ID will exactly identify the impacted subscribers.

Table 5.3.1-2: Update ProSe Subscriber Data Answer

Information element name	Mapping to Diameter AVP	Cat.	Description
Supported Features (See 3GPP TS 29.2 29 [6])	Supported- Features	0	If present, this information element shall contain the list of features supported by the origin host.
Result (See 6.4)	Result-Code / Experimental- Result	М	This IE shall contain the result of the operation. The Result-Code AVP shall be used to indicate success / errors as defined in the Diameter base protocol (see IETF RFC 6733 [23]). The Experimental-Result AVP shall be used for PC4a errors. This is a grouped AVP which shall contain the 3GPP Vendor ID in the Vendor-Id AVP, and the error code in the Experimental-Result-Code AVP. The following errors are applicable in this case: - User Unknown - Unknown ProSe Subscription

5.3.2 Detailed behaviour of the ProSe Function

When receiving a Update ProSe Subscriber Data request, the ProSe Function shall check whether the IMSI is known.

If it is not known, a result code of DIAMETER_ERROR_USER_UNKNOWN shall be returned.

If it is known, the ProSe Function shall update the corresponding data according to the indication as sent in the request, and acknowledge the Update ProSe Subscriber Data message by returning an Update ProSe Subscriber Data Answer. If the UPR-Flags indicates that the ProSe subscription data is to be deleted, the ProSe Function shall delete the associated ProSe UE context if it has been stored before.

If the update of the subscription data succeeds in the ProSe Function, the Result-Code shall be set to DIAMETER_SUCCESS.

If the ProSe Function cannot fulfil the received request for other reasons, e.g. due to a database error, it shall set the Result-Code to DIAMETER_UNABLE_TO_COMPLY. In this case, the ProSe Function shall mark the subscription record "Subscriber data to be restored in the HSS".

5.3.3 Detailed behaviour of the HSS

The HSS shall make use of this procedure to update the relevant subscriber related data in the ProSe Function to replace a specific part of the user data stored in the ProSe Function with the data sent.

If the ProSe related subscription data is updated or revoked, the HSS sends the updated ProSe subscription data to the ProSe Function. The HSS shall include the UPR-Flags to indicate which part of the data is updated. If all of the ProSe subscription data is to be removed, the HSS shall set the "Removal of all ProSe Subscription Data" bit of the UPR-Flags, and the HSS shall delete the ProSe Function Identity if it is stored for this subscriber.

5.4 Notification Procedure

5.4.1 General

6.3.7)

This procedure shall be used between the ProSe Function and the HSS when the HSS needs to be notified about:

- revocation of authorization for ProSe direct service on one PLMN.
- removal of the subscription data from the ProSe Function either by an MMI interaction or automatically.

This procedure is mapped to the commands ProSe-Notify-Request/Answer (PNR/PNA) in the Diameter application specified in clause 6. Tables 5.4.1-1 and 5.4.1-2 detail the involved information elements.

Information Element **Mapping to Diameter** Cat. Description Name AVP IMSI User-Name (See С This information element shall contain the user IMSI, formatted according to 3GPP TS 23.003 [7], clause 2.2. IETF RFC 6733 [23]) It shall be present if the revocation is for a specific UE. If present, this information element shall contain the list of Supported Features Supported-Features (See features supported by the origin host. 3GPP TS 29.229 [6]) PLMN ID (see Visited-PLMN-Id С This information element shall contain the MCC and the MNC of the PLMN where the UE's authorization for 3GPP TS 29.272 [10]) ProSe direct service is revoked, see 3GPP TS 23.003 [7]. It shall be present if the ProSe Function revokes the authorization for ProSe direct service in a specific PLMN. PNR Flags (see **PNR-Flags** С This Information Element shall contain a bit mask. See

6.3.7 for the meaning of the bits.

Table 5.4.1-1: ProSe Notify Request

Table 5.4.1-2: ProSe Notify Answer

Information Element Name	Mapping to Diameter AVP	Cat.	Description
Result (See 6)	Result-Code / Experimental- Result	M	This IE shall contain the result of the operation. The Result-Code AVP shall be used to indicate success / errors as defined in the Diameter base protocol (see IETF RFC 6733 [23]). The Experimental-Result AVP shall be used for PC4a errors. This is a grouped AVP which shall contain the 3GPP Vendor ID in the Vendor-Id AVP, and the error code in the Experimental-Result-Code AVP. The following errors are applicable: - User Unknown - Unknown ProSe Subscription
Supported Features (See 3GPP TS 29.229 [6])	Supported- Features	0	If present, this information element shall contain the list of features supported by the origin host.

5.4.2 Detailed Behaviour of the ProSe Function

The ProSe Function shall make use of this procedure to revoke authorization for ProSe direct service.

The ProSe Function shall make use of this procedure to inform the HSS when the subscription data is deleted from the ProSe Function database due to MMI interaction or automatically.

The ProSe Function shall send the updated ProSe Permission and the PLMN ID for which the ProSe Permission is to be updated. If the revocation is for a single UE in the indicated PLMN, the ProSe Function shall include IMSI in the request.

5.4.3 Detailed Behaviour of the HSS

When receiving a ProSe Notify Request the HSS shall check if the IMSI, if present in the message, exists in the HSS. If not, an Experimental-Result of DIAMETER_ERROR_USER_UNKNOWN shall be returned.

If the IMSI exists but there is not any ProSe subscription data for the IMSI and the PLMN ID as indicated by the Visited-PLMN-Id AVP in the request, the HSS shall return an Experimental-Result of DIAMETER_ERROR_UNKNOWN_PROSE_SUBSCRIPTION.

If the PNR-Flags indicates revocation of authorization for ProSe direct service, and

- if the IMSI exists and there is ProSe subscription data for the IMSI and the PLMN ID as indicated by the Visited-PLMN-Id AVP in the request, the HSS shall revoke ProSe direct service as indicated by the PNR Flags received in the request on that PLMN for the user and update the ProSe Subscription data accordingly. The HSS shall set the result code to DIAMETER_SUCCESS.
- if IMSI is not present in the message, the HSS shall check if there are any users subscribed to ProSe subscription for the PLMN as indicated by the Visited-PLMN-Id AVP in the request, and if yes, revoke ProSe direct service as indicated by the PNR Flags received in the request on that PLMN for all the impacted users and update their ProSe Subscription data accordingly. The HSS shall set the result code to DIAMETER_SUCCESS.

If the PNR Flags indicates the subscription data is deleted from the ProSe Function, the HSS shall remove the ProSe Function Identity for the subscriber and set the result code to DIAMETER_SUCCESS.

For any other reasons if the HSS cannot fulfil the received request, e.g. due to a database error, it shall set the result code to DIAMETER UNABLE TO COMPLY.

5.5 Reset

5.5.1 General

The Reset Procedure shall be used by the HSS, after a restart, to indicate to the ProSe Function that a failure has occurred.

The Reset Procedure may also be used by the HSS as part of operation and maintenance actions e.g. to allow planned HSS outage without service interruption.

This procedure is mapped to the commands Reset-Request/Answer (RSR/RSA) in the Diameter application specified in clause 6.

Table 5.5.1-1 specifies the involved information elements for the request.

Table 5.5.1-2 specifies the involved information elements for the answer.

Table 5.5.1-1: Reset Request

Information element name	Mapping to Diameter AVP	Cat.	Description
User Id List (See 3GPP TS 29.2 72 [10])	User-Id	0	This IE shall contain a list of ProSe User-Ids where a ProSe User-Id comprises the leading digits of an IMSI (i.e. MCC, MNC, leading digits of MSIN) and it shall identify the set of subscribers whose IMSIs begin with the User-Id. The HSS may include this information element if the occurred failure is limited to subscribers identified by one or more User-Ids.
Supported Features (See 3GPP TS 29.2 29 [6])	Supported- Features	0	If present, this information element shall contain the list of features supported by the origin host.
Reset-IDs (See 3GPP TS 29.2 72 [10])	Reset-ID	0	If present, this information element identifies together with the HSS's realm the set of impacted subscribers.

Table 5.5.1-2: Reset Answer

Information element name	Mapping to Diameter AVP	Cat.	Description
Supported Features (See 3GPP TS 29.2 29 [6])	Supported- Features	0	If present, this information element shall contain the list of features supported by the origin host.
Result (See 6.4)	Result-Code / Experimental- Result	M	This IE shall contain the result of the operation. The Result-Code AVP shall be used to indicate success / errors as defined in the Diameter base protocol (see IETF RFC 6733 [23]). The Experimental-Result AVP shall be used for PC4a errors. This is a grouped AVP which shall contain the 3GPP Vendor ID in the Vendor-Id AVP, and the error code in the Experimental-Result-Code AVP. There are no Experimental-Result codes applicable for this command.

5.5.2 Detailed behaviour of the ProSe Function

When receiving a Reset message the ProSe Function shall mark all impacted subscriber records "Subscriber DataConfirmed in HSS" as "Not Confirmed", as defined in 3GPP TS 23.007 [11]. If the Reset-IDs IE is supported and received, the ProSe Function shall make use of the Reset-IDs (together with the HSS's realm) in order to determine which subscriber records are impacted (i.e. check whether at least one received Reset-ID is associated with the subscriber, and the HSS's realm identity received in the Origin-Realm AVP matches the value stored after successful ProSe-Subscriber-Information retrieval); otherwise the ProSe Function shall make use of the HSS Identity received in

the Origin-Host AVP (by comparing it with the value stored after successful ProSe-Subscriber-Information retrieval) and may make use of the received User-Id-List (if any) in order to determine which subscriber records are impacted.

5.5.3 Detailed behaviour of the HSS

The HSS shall make use of this procedure in order to indicate to all relevant ProSe Functions that the HSS has restarted and may have lost the current ProSe Function Identity of some of its subscribers who may be currently roaming in the ProSe Function Area and that the HSS, therefore, cannot send an Update ProSe Subscriber Data messages when needed.

If the Reset-ID feature is not supported by the ProSe Function and the HSS, the HSS may include a list of User Ids identifying a subset of subscribers served by the HSS, if the occurred failure is limited to those subscribers.

If the Reset-ID feature is supported by the ProSe Function, the HSS optionally may include one (or several) Reset-ID AVPs identifying e.g. failed hardware components if the occured failure is limited to those subscribers associated with e.g. the identified failed hardware components.

5.6 Initial Location Information Retrieval

5.6.1 General

This procedure shall be used between the ProSe Function and the HSS for retrieving the initial location information of the UE for EPC-levelProSe discovery. The procedure shall be invoked by the ProSe Function and is used:

- to request the initial location information of the UE.

This procedure is mapped to the commands ProSe-Initial-Location-Information-Request/Answer (PLR/PLA) in the Diameter application specified in clause 6.

Table 5.4.1/1 specifies the involved information elements for the request.

Table 5.4.1/2 specifies the involved information elements for the answer.

Table 5.6.1/1: ProSe Initial Location Information Request

Information Element Name	Mapping to Diameter AVP	Cat.	Description
IMSI	User-Name (See ETF RFC 6733 [23])	М	This information element shall contain the user IMSI, formatted according to 3GPP TS 23.003 [7], clause 2.2.
Supported Features (See 3GPP TS 29.229 [6])	Supported-Features	0	If present, this information element shall contain the list of features supported by the origin host.

Table 5.6.1/2: ProSe Initial Location Information Answer

Information Element Name	Mapping to Diameter AVP	Cat.	Description
Result (See 6)	Result-Code / Experimental- Result	M	This IE shall contain the result of the operation. The Result-Code AVP shall be used to indicate success / errors as defined in the Diameter base protocol (see IETF RFC 6733 [23]). The Experimental-Result AVP shall be used for PC4a errors. This is a grouped AVP which shall contain the 3GPP Vendor ID in the Vendor-Id AVP, and the error code in the Experimental-Result-Code AVP. The following errors are applicable: - User Unknown - UE Location Unknown
ProSe Initial Location Information (See 6.3.9)	ProSe-Initial- Location- Information	С	This information element shall contain the location information of the UE.
Visited PLMN Id (See 3GPP TS 29.272 [10])	Visited-PLMN-Id	С	This IE shall contain the MCC and the MNC of the PLMN where the UE is registered, see 3GPP TS 23.003 [7]. It shall be present if the UE is roaming in a PLMN different from the Home PLMN.
Supported Features (See 3GPP TS 29.229 [6])	Supported- Features	0	If present, this information element shall contain the list of features supported by the origin host.

5.6.2 Detailed Behaviour of the ProSe Function

To request the initial location information of the targeted UE, the ProSe Function shall include the corresponding IMSI in the user profile of the targeted user in ProSe Initial Location Information Request.

NOTE: The user profile for the targeted user is stored in the ProSe Function according to clause 7.2.2.3 of 3GPP TS 24.334 [16].

5.6.3 Detailed Behaviour of the HSS

When receiving a ProSe Initial Location Information Request the HSS shall check whether the IMSI is known.

If it is not known, a result code of DIAMETER_ERROR_USER_UNKNOWN shall be returned.

If it is known and the MME is not the serving node currently registered in HSS for the UE, the HSS shall return an Experimental-Result of DIAMETER_ERROR_UE_LOCATION_UNKNOWN. If it is known and the MME is the serving node currently registered in HSS for the UE, the HSS shall return a Result-Code of DIAMETER_SUCCESS and provide the location information of the UE to the ProSe Function. The HSS shall provide the Visited PLMN ID of where the UE is registered if the UE is roaming in a PLMN different from the Home PLMN.

NOTE: When requesting the UE location via S6a, the HSS does not set the "Current Location Request" bit in the IDR-Flags in the Insert Subscriber Data Request message.

6 Protocol Specification and Implementations

6.1 Introduction

6.1.1 Use of Diameter Base Protocol

The Diameter base protocol as specified in IETF RFC 6733 [23] shall apply except as modified by the defined support of the methods and the defined support of the commands and AVPs, result and error codes as specified in this specification. Unless otherwise specified, the procedures (including error handling and unrecognised information handling) shall be used unmodified.

6.1.2 Securing Diameter Messages

For secure transport of Diameter messages, see 3GPP TS 33.210 [4]

6.1.3 Accounting Functionality

Accounting functionality (Accounting Session State Machine, related command codes and AVPs) shall not be used on the PC4a interface.

6.1.4 Use of Sessions

Between the ProSe Function and the HSS, Diameter sessions shall be implicitly terminated. An implicitly terminated session is one for which the server does not maintain state information. The client shall not send any re-authorization or session termination requests to the server.

The Diameter base protocol specified in IETF RFC 6733 [23] includes the Auth-Session-State AVP as the mechanism for the implementation of implicitly terminated sessions.

The client (server) shall include in its requests (responses) the Auth-Session-State AVP set to the value NO_STATE_MAINTAINED (1), as described in IETF RFC 6733 [23]. As a consequence, the server shall not maintain any state information about this session and the client shall not send any session termination request. Neither the Authorization-Lifetime AVP nor the Session-Timeout AVP shall be present in requests or responses.

6.1.5 Transport Protocol

Diameter messages over the PC4a interface shall make use of SCTP, see IETF RFC 4960 [5].

6.1.6 Routing Considerations

This clause specifies the use of the Diameter routing AVPs Destination-Realm and Destination-Host.

The PC4a reference point is defined as an intra-operator interface, and both the ProSe Function and the HSS are located in the home PLMN of the UE that requests ProSe. If the ProSe Function knows the address/name of the HSS for a certain user, both the Destination-Realm and Destination-Host AVPs shall be present in the request. Otherwise, the Destination-Realm AVP shall be present and the command shall be routed to the next Diameter node. Consequently, the Destination-Host AVP is declared as optional in the ABNF for all requests initiated by the ProSe Function.

The HSS obtains the Destination-Host AVP to use in requests towards the ProSe Function, from the Origin-Host AVP received in previous requests from the ProSe Function. Consequently, the Destination-Host AVP is declared as mandatory in the ABNF for all requests initiated by the HSS.

If the Vendor-Specific-Application-ID AVP is received in any of the commands, it shall be ignored by the receiving node, and it shall not be used for routing purposes.

6.1.7 Advertising Application Support

The ProSe Function and the HSS shall advertise support of the Diameter PC4a Application by including the value of the application identifier in the Auth-Application-Id AVP within the Vendor-Specific-Application-Id grouped AVP of the Capabilities-Exchange-Request and Capabilities-Exchange-Answer commands.

The vendor identifier value of 3GPP (10415) shall be included in the Supported-Vendor-Id AVP of the Capabilities-Exchange-Request and Capabilities-Exchange-Answer commands, and in the Vendor-Id AVP within the Vendor-Specific-Application-Id grouped AVP of the Capabilities-Exchange-Request and Capabilities-Exchange-Answer commands.

The Vendor-Id AVP included in Capabilities-Exchange-Request and Capabilities-Exchange-Answer commands that is not included in the Vendor-Specific-Application-Id AVPs as described above shall indicate the manufacturer of the Diameter node as per IETF RFC 6733 [23].

6.1.8 Diameter Application Identifier

The PC4a interface protocol shall be defined as an IETF vendor specific Diameter application, where the vendor is 3GPP. The vendor identifier assigned by IANA to 3GPP (http://www.iana.org/assignments/enterprise-numbers) is 10415.

The Diameter application identifier assigned to the PC4a interface application is 16777336 (allocated by IANA).

6.1.9 Use of the Supported-Features AVP

When new functionality is introduced on the PC4a interface, it should be defined as optional. If backwards incompatible changes cannot be avoided, the new functionality shall be introduced as a new feature and support advertised with the Supported-Features AVP. The usage of the Supported-Features AVP on the PC4a interface is consistent with the procedures for the dynamic discovery of supported features as defined in clause 7.2 of 3GPP TS 29.229 [6].

When extending the application by adding new AVPs for a feature, the new AVPs shall have the M bit cleared and the AVP shall not be defined mandatory in the command ABNF.

As defined in 3GPP TS 29.229 [6], the Supported-Features AVP is of type grouped and contains the Vendor-Id, Feature-List-ID and Feature-List AVPs. On the all reference points as specified in this specification, the Supported-Features AVP is used to identify features that have been defined by 3GPP and hence, for features defined in this document, the Vendor-Id AVP shall contain the vendor ID of 3GPP (10415). If there are multiple feature lists defined for the reference point, the Feature-List-ID AVP shall differentiate those lists from one another.

6.2 Commands

6.2.1 Introduction

This clause defines the Command code values and related ABNF for each command described in this specification.

6.2.2 Command-Code Values

This clause defines Command-Code values for the PC4a interface application as allocated by IANA.

Every command is defined by means of the ABNF syntax IETF RFC 5234 [8], according to the Command Code Format (CCF) specification defined in IETF RFC 6733 [23]. In the case, the definition and use of an AVP is not specified in this document, the guidelines in IETF RFC 6733 [23] shall apply.

The Vendor-Specific-Application-Id AVP shall not be included in any command sent by Diameter nodes supporting applications defined in this specification. If the Vendor-Specific-Application-Id AVP is received in any of the commands defined in this specification, it shall be ignored by the receiving node.

NOTE: The Vendor-Specific-Application-Id is included as an optional AVP in all Command Code Format specifications defined in this specification in order to overcome potential interoperability issues with intermediate Diameter agents non-compliant with the IETF RFC 6733 [23].

The following Command Codes are defined in this specification:

Table 6.2.2-1: Command-Code values for PC4a

Command-Name	Abbreviation	Code	Clause
ProSe-Subscriber-Information-	PIR	8388664	6.2.3
Request			
ProSe-Subscriber-Information-	PIA	8388664	6.2.4
Answer			
Update-ProSe-Subscriber-Data-	UPR	8388665	6.2.5
Request			
Update-ProSe-Subscriber-Data-	UPA	8388665	6.2.6
Answer			
ProSe-Notify-Request	PNR	8388666	6.2.7
ProSe-Notify-Answer	PNA	8388666	6.2.8
Reset-Request	RSR	322	6.2.9
Reset-Answer	RSA	322	6.2.10
ProSe-Initial-Location-	PSR	8388713	6.2.11
Information-Request			
ProSe-Initial-Location-	PSA	8388713	6.2.12
Information-Answer			

For these commands, the Application-ID field shall be set to 16777336 (application identifier of the PC4a interface application, allocated by IANA).

6.2.3 ProSe-Subscriber-Information-Request (PIR) Command

The ProSe-Subscriber-Information-Request (PIR) command, indicated by the Command-Code field set to 8388664 and the "R" bit set in the Command Flags field, is sent from the ProSe Function to the HSS.

Message Format

```
< ProSe-Subscriber-Information-Request > ::=
                                              < Diameter Header: 8388664, REQ, PXY, 16777336 >
                              < Session-Id >
                              [DRMP]
                              [ Vendor-Specific-Application-Id ]
                              { Auth-Session-State }
                              { Origin-Host }
                              { Origin-Realm }
                              [ Destination-Host ]
                              { Destination-Realm }
                              { User-Name }
                              *[ Supported-Features ]
                              [ OC-Supported-Features ]
                              *[ AVP ]
                              *[ Proxy-Info ]
                              *[ Route-Record ]
```

6.2.4 ProSe-Subscriber-Information-Answer (PIA) Command

The ProSe-Subscriber-Information-Answer (PIA) command, indicated by the Command-Code field set to 8388664 and the "R" bit cleared in the Command Flags field, is sent from the HSS to the ProSe Function.

Message Format

```
{ Origin-Realm }
[ ProSe-Subscription-Data ]
[ MSISDN ]
[ Visited-PLMN-Id ]
*[ Supported-Features ]
[ OC-Supported-Features ]
[ OC-OLR ]
*[ Load ]
*[ AVP ]
*[ Reset-ID ]
[ Failed-AVP ]
*[ Proxy-Info ]
*[ Route-Record ]
```

6.2.5 Update-ProSe-Subscriber-Data-Request (UPR) Command

The Update-ProSe Subscriber Data-Request (UPR) command, indicated by the Command-Code field set to 8388665 and the 'R' bit set in the Command Flags field, is sent from the HSS to the ProSe Function.

Message Format when used over the PC4a application:

```
< Update-ProSe-Subscriber-Data-Request > ::= < Diameter Header: 8388665, REQ, PXY, 16777336 >
                                     < Session-Id >
                                     [DRMP]
                                     [ Vendor-Specific-Application-Id ]
                                     { Auth-Session-State }
                                     { Origin-Host }
                                     { Origin-Realm }
                                     { Destination-Host }
                                     { Destination-Realm }
                                     { User-Name }
                                     *[ Supported-Features ]
                                     [ ProSe Subscription-Data ]
                                     [ Visited-PLMN-Id ]
                                     { UPR-Flags }
                                     *[ Reset-ID ]
                                     *[ AVP ]
                                     *[ Proxy-Info ]
                                     *[ Route-Record ]
```

6.2.6 Update-ProSe-Subscriber-Data-Answer (UPA) Command

The Update-ProSe Subscriber Data-Answer (UPA) command, indicated by the Command-Code field set to 8388665 and the 'R' bit cleared in the Command Flags field, is sent from the ProSe Function to the HSS.

Message Format when used over the PC4a application:

6.2.7 ProSe-Notify-Request (PNR) Command

The ProSe-Notify-Request (PNR) command, indicated by the Command-Code field set to 8388666 and the "R" bit set in the Command Flags field, is sent from the ProSe Function to the HSS.

Message Format

```
< ProSe-Notify-Request > ::= < Diameter Header: 8388666, REQ, PXY, 16777336 >
                              < Session-Id >
                              [DRMP]
                              [ Vendor-Specific-Application-Id ]
                              { Auth-Session-State }
                              { Origin-Host }
                              { Origin-Realm }
                              [ Destination-Host ]
                              { Destination-Realm }
                              [ User-Name ]
                              [ ProSe-Permission ]
                              [ Visited-PLMN-Id ]
                              [PNR-Flags]
                              *[ Supported-Features ]
                              [ OC-Supported-Features ]
                              *[ AVP ]
                              *[ Proxy-Info ]
                              *[ Route-Record ]
```

6.2.8 ProSe-Notify-Answer (PNA) Command

The ProSe-Notify-Answer (PNA) command, indicated by the Command-Code field set to 8388666 and the "R" bit cleared in the Command Flags field, is sent from the HSS to the ProSe Function.

Message Format

```
< ProSe-Notify-Answer > ::= < Diameter Header: 8388666, PXY, 16777336 >
                             < Session-Id >
                             [DRMP]
                             [ Vendor-Specific-Application-Id ]
                             [ Result-Code ]
                             [Experimental-Result]
                             { Auth-Session-State }
                              { Origin-Host }
                              { Origin-Realm }
                             *[ Supported-Features ]
                             [ OC-Supported-Features ]
                             [OC-OLR]
                             *[Load]
                             *[ AVP ]
                             [Failed-AVP]
                             *[ Proxy-Info ]
                             *[ Route-Record ]
```

6.2.9 Reset-Request (RSR) Command

The Reset-Request (RSR) command, indicated by the Command-Code field set to 322 and the 'R' bit set in the Command Flags field, is sent from HSS to the ProSe Function.

Message Format when used over the PC4a application:

```
{ Origin-Host }
{ Origin-Realm }
{ Destination-Host }
{ Destination-Realm }
*[ Supported-Features ]
*[ User-Id ]
*[ Reset-ID ]
*[ AVP ]
*[ Proxy-Info ]
*[ Route-Record ]
```

6.2.10 Reset-Answer (RSA) Command

The Reset-Answer (RSA) command, indicated by the Command-Code field set to 322 and the 'R' bit cleared in the Command Flags field, is sent from ProSe Function to HSS.

Message Format when used over the PC4a application:

6.2.11 ProSe-Initial-Location-Information-Request (PSR) Command

The ProSe-Initial-Location-Information-Request (PSR) command, indicated by the Command-Code field set to 8388713 and the "R" bit set in the Command Flags field, is sent from the ProSe Function to the HSS.

Message Format

6.2.12 ProSe-Initial-Location-Information-Answer (PSA) Command

The ProSe-Initial-Location-Information-Answer (PSA) command, indicated by the Command-Code field set to 8388713 and the "R" bit cleared in the Command Flags field, is sent from the HSS to the ProSe Function.

Message Format

```
< ProSe-Subscriber-Information-Answer > ::=
                                              < Diameter Header: 8388713, PXY, 16777336 >
                              < Session-Id >
                              [DRMP]
                               Vendor-Specific-Application-Id ]
                               Result-Code ]
                              [Experimental-Result]
                               Auth-Session-State }
                              { Origin-Host }
                              { Origin-Realm }
                              [ ProSe-Initial-Location-Information ]
                              [ Visited-PLMN-Id ]
                              *[ Supported-Features ]
                              *[ AVP ]
                              [Failed-AVP]
                              *[ Proxy-Info ]
                              *[ Route-Record ]
```

6.3 AVPs

6.3.1 General

The following table specifies the Diameter AVPs defined for the PC4a interface protocol, their AVP Code values, types, possible flag values and whether or not the AVP may be encrypted. The Vendor-ID header of all AVPs defined in this specification shall be set to 3GPP (10415).

AVP Flag rules Attribute Name AVP Code Clause Value Type Must May Should Must Mav defined not not Encr. ProSe-Subscription-Data 3701 6.3.2 Grouped M,V No Unsigned32 M,V ProSe-Permission 3702 6.3.3 No ProSe-Allowed-PLMN 3703 6.3.4 Grouped M,V No ProSe-Direct-Allowed 3704 6.3.5 Unsigned32 M,V No UPR-Flags 3705 6.3.6 Unsigned32 M,V No PNR-Flags 3706 6.3.7 Unsigned32 M,V Nο ProSe-Initial-Location-Information 3707 6.3.9 Grouped M,V No

Table 6.3.1-1: PC4a specific Diameter AVPs

- NOTE 1: The AVP header bit denoted as "M", indicates whether support of the AVP is required. The AVP header bit denoted as "V", indicates whether the optional Vendor-ID field is present in the AVP header. For further details, see IETF RFC 6733 [23].
- NOTE 2: If the M-bit is set for an AVP and the receiver does not understand the AVP, it shall return a rejection. If the M-bit is not set for an AVP, the receiver shall not return a rejection, whether or not it understands the AVP. If the receiver understands the AVP but the M-bit value does not match with the definition in this table, the receiver shall ignore the M-bit.

The following table specifies the Diameter AVPs re-used by the PC4a interface protocol from existing Diameter Applications, including a reference to their respective specifications and when needed, a short description of their use within PC4a.

Any other AVPs from existing Diameter Applications, except for the AVPs from Diameter Base Protocol, do not need to be supported. The AVPs from Diameter Base Protocol are not included in table 6.3.1-2, but they may be re-used for the PC4a protocol.

Table 6.3.1-2: PC4a re-used Diameter AVPs

Attribute Name	Reference	Comments	M-bit
Visited-PLMN- Id	3GPP TS 29.272 [10]		
Supported- Features	3GPP TS 29.229 [6]		
Feature-List- ID	3GPP TS 29.229 [6]		
Feature-List	3GPP TS 29.229 [6]		
User-Id	3GPP TS 29.272 [10]	See clause 6.3.8	
Reset-ID	3GPP TS 29.272 [10]		
MSISDN	3GPP TS 29.329 [12]		
MME-Name	3GPP TS 29.173 [14]	See clause 6.3.10	
E-UTRAN- Cell-Global- Identity	3GPP TS 29.272 [10]		
Tracking Area	3GPP TS 29.272 [10]		
Age-Of- Location- Information	3GPP TS 29.272 [10]		
3GPP- Charging- Characteristics	3GPP TS 29.061 [18]	See 3GPP TS 32.251 [19] Annex A and 3GPP TS 32.298 [20] clause 5.1.2.2.7. This attribute holds the ProSe-related Charging Characteristics for a ProSe subscriber.	Must set
OC- Supported- Features	IETF RFC 7683 [15]	See clause 6.3.11	Must set
OC-OLR	IETF RFC 7683 [15]	See clause 6.3.12	Must set
DRMP	IETF RFC 7944 [21]	see clause 6.3.14	Must not set
Load	IETF RFC 8583 [22]	See clause 6.3.15	Must not set
		sed AVPs override those of the defining specifications that are referenced.	/alues

include: "Must set", "Must not set". If the M-bit setting is blank, then the defining specification applies.

NOTE 2: If the M-bit is set for an AVP and the receiver does not understand the AVP, it shall return a rejection. If the M-bit is not set for an AVP, the receiver shall not return a rejection, whether or not it understands the AVP. If the receiver understands the AVP but the M-bit value does not match with the definition in this table, the receiver shall ignore the M-bit.

6.3.2 ProSe-Subscription-Data

The ProSe-Subscription-Data AVP is of type Group. It shall contain the ProSe related subscription data.

AVP format

```
ProSe-Subscription-Data ::= <AVP header: 3701 10415>
         { ProSe-Permission }
         *[ ProSe-Allowed-PLMN ]
         [ 3GPP-Charging-Characteristics ]
         *[AVP]
```

6.3.3 ProSe-Permission

The ProSe-Permission AVP is of type Unsigned32 and it shall contain a bit mask that indicates the permissions for ProSe subscribed by the user. The meaning of the bits shall be as defined in table 6.3.3/1:

Table 6.3.3-1: ProSe-Permission

Bit	Name	Description
0	ProSe Direct	This bit, when set, indicates that the user is allowed to use
	Discovery	ProSe Direct Discovery.
1	EPC-level ProSe	This bit, when set, indicates that the user is allowed to use EPC-
	Discovery	level ProSe Discovery.
2	EPC support WLAN	This bit, when set, indicates that the user is allowed to use EPC
	Direct Discovery	support WLAN Direct Discovery and Communication.
	and Communication	
3	one-to-many ProSe	This bit, when set, indicates that the user is allowed to use one-
	Direct	to-many ProSe Direct Communication.
	Communication	
4	one-to-one ProSe	This bit, when set, indicates that the user is allowed to use one-
	Direct	to-one ProSe Direct Communication.
	Communication	
5	UE-to-Network	This bit, when set, indicates that the user is allowed to act as a
	Relay	UE-to-Network relay.
6	Remote-UE-access	This bit, when set, indicates that the user is allowed to act as a
		Remote-UE.
7	Restricted ProSe	This bit, when set, indicates that the user is allowed to use
	Direct Discovery	restricted ProSe Direct Discovery.
NOTE:	Bits not defined in this t	able shall be cleared by the HSS and discarded by the receiving
	ProSe Function.	

6.3.4 ProSe-Allowed-PLMN

The ProSe-Allowed-PLMN AVP is of type Group. It shall contain the PLMN where the UE is authorised to announce or monitor or both for ProSe Discovery or to use ProSe direct communication.

AVP format

ProSe-Allowed-PLMN ::= <AVP header: 3703 10415>

[Visited-PLMN-Id]

[Authorized-Discovery-Range]

[ProSe-Direct-Allowed]

*[AVP]

The Authorized-Discovery-Range Information Element should only be present if the Visited-PLMN-Id is the PLMN-Id of the HPLMN; otherwise it should be absent.

6.3.5 ProSe-Direct-Allowed

The ProSe-Direct-Allowed AVP is of type Unsigned32 and it shall contain a bit mask that indicates the services the UE is authorised to use for ProSe Direct functionalities in a specific PLMN. The meaning of the bits shall be as defined in table 6.3.5-1:

Table 6.3.5-1: ProSe-Direct-Allowed

Bit	Name	Description			
0	Announce	This bit, when set, indicates that the user is allowed to announce			
		in the corresponding PLMN for open ProSe Discovery.			
1	Monitor	This bit, when set, indicates that the user is allowed to monitor in			
		the corresponding PLMN for open ProSe Discovery.			
2	Communication	This bit, when set, indicates that the user is allowed for ProSe			
		direct one to many communication in the corresponding PLMN.			
3	One-to-one	This bit, when set, indicates that the user is allowed to perform			
	Communication	one-to-one ProSe Direct Communication.			
4	Discoverer	This bit, when set, indicates that the user is allowed to perform			
		discoverer operation in the corresponding PLMN for ProSe			
		Discovery Model B.			
5	Discoveree	This bit, when set, indicates that the user is allowed to perform			
		discoveree operation in the corresponding PLMN for ProSe			
		Discovery Model B.			
6	Restricted-	This bit, when set, indicates that the user is allowed to announce			
	announce	in the corresponding PLMN for restricted ProSe Discovery.			
7	Restricted-	This bit, when set, indicates that the user is allowed to monitor in			
	monitoring	the corresponding PLMN for restricted ProSe Discovery.			
8	Application-	This bit, when set, indicates that the user is allowed to announce			
	controlled extension	or monitor with application-controlled extension in the			
		corresponding PLMN for restricted ProSe Discovery			
9	On-demand	This bit, when set, indicates that the user is allowed to perform			
	announcing	on-demand announcing in the corresponding PLMN for			
		restricted ProSe Discovery			
NOTE:	NOTE: Bits not defined in this table shall be cleared by the HSS and discarded by the receiving				
	ProSe Function.				

6.3.6 UPR-Flags

The UPR-Flags AVP is of type Unsigned32 and it shall contain a bit mask. The meaning of the bits is defined in table 6.3.6-1:

Table 6.3.6-1: UPR-Flags

Bit	Name	Description		
0	Update	This bit, when set, indicates that the ProSe subscriber related		
		data are updated.		
1	Removal	This bit, when set, indicates that all of the ProSe subscriber		
		related data are removed.		
2	Reset-ID Update	This bit, when set, indicates that the complete list on Reset-IDs		
		is updated.		
3	Reset-ID Removal	This bit, when set, indicates that the complete list on Reset-IDs		
		is removed.		
NOTE:	NOTE: Bits not defined in this table shall be cleared by the sending HSS and discarded by the			
receiving ProSe Function.				

6.3.7 PNR-Flags

The PNR-Flags AVP is of type Unsigned32 and it shall contain a bit mask. The meaning of the bits shall be as defined in table 6.3.7-1:

Table 6.3.7-1: PNR-Flags

bit	name	Description				
0	Direct Discovery Revoked	This bit, when set, shall indicate to the HSS that the authorization for ProSe direct discovery is to be revoked on the indicated PLMN.				
1	Direct Communication Revoked	This bit, when set, shall indicate to the HSS that the authorization for ProSe direct communication is to be revoked on the indicated PLMN.				
2	Purged UE	This bit, when set, shall indicate to the HSS that the subscriber's data has been deleted from the ProSe Function.				
	NOTE 1: Bits not defined in this table shall be cleared by the sending ProSe Function and					
	discarded by the receiving HSS.					
NOTE 2:	FE 2: If Purged UE bit is set, all other bits in this table shall be cleared by the sending ProSe					
	Function and discarded by the receiving HSS.					

6.3.8 Feature-List AVP for the PC4a application

The syntax of this AVP is defined in 3GPP TS 29.229 [6].

For the PC4a application, the meaning of the bits shall be as defined in table 6.3.8/1 for the Feature-List-ID 1.

Table 6.3.8/1: Features of Feature-List-ID 1 used in PC4a

Feature	Feature	M/O	Description
bit			
0	Reset-IDs	0	Support of Reset-IDs This feature is applicable to the PIR/PIA and UPR/UPA and RSR/RSA command pairs over the PC4a interface. If the ProSe Function indicates in the PIR command that it does not support Reset-IDs, the HSS shall not include Reset-ID AVPs in RSR commands sent to that Prose Function.

Feature bit: The order number of the bit within the Supported-Features AVP, e.g. "1".

Feature: A short name that can be used to refer to the bit and to the feature, e.g. "ODB-HPLMN-APN".

M/O: Defines if the implementation of the feature is mandatory ("M") or optional ("O").

Description: A clear textual description of the feature.

Features that are not indicated in the Supported-Features AVPs within a given application message shall not be used to construct that message.

6.3.9 ProSe-Initial-Location-Information

The ProSe-Initial-Location-Information AVP is of type Grouped. This AVP shall contain the location information of the UE.

AVP format

ProSe-Initial-Location-Information ::= <AVP header: 3707 10415>

[MME-Name]

[E-UTRAN-Cell-Global-Identity]

[Tracking-Area-Identity]

[Age-Of-Location-Information]

*[AVP]

6.3.10 MME-Name

The MME-Name AVP is of type DiameterIdentity. This AVP shall contain the Diameter identity of the serving MME and is specified in 3GPP TS 29.173 [14] clause 6.4.4.

6.3.11 OC-Supported-Features

The OC-Supported-Features AVP is of type Grouped and it is defined in IETF RFC 7683 [15]. This AVP is used to support Diameter overload control mechanism, see Annex A for more information.

6.3.12 OC-OLR

The OC-OLR AVP is of type Grouped and it is defined in IETF RFC 7683 [15]. This AVP is used to support Diameter overload control mechanism, see Annex A for more information.

6.3.13 Authorized-Discovery-Range

The Authorized-Discovery-Range AVP is of type Unsigned32 and it shall contain a value that indicates the authorised announcing range (short/medium/long) at which the UE is allowed to announce in the given PLMN according to the defined announcing authorisation policy for this UE. Refer to 3GPP TS 24.334 [16] for the policy handling and to 3GPP TS 24.333 [17] for the possible values of the range.

6.3.14 DRMP

The DRMP AVP is of type Enumerated and it is defined in IETF RFC 7944 [21]. This AVP allows the HSS and the ProSe Function to indicate the relative priority of Diameter messages over the PC4a interface. The DRMP AVP may be used to set the DSCP marking for transport of the associated Diameter message.

6.3.15 Load

The Load AVP is of type Grouped and it is defined in IETF RFC 8583 [22]. This AVP is used to support Diameter load control mechanism, see Annex D for more information.

6.4 Result-Code AVP and Experimental-Result AVP Values

6.4.1 General

This clause defines result code values that shall be supported by all Diameter implementations that conform to this specification.

6.4.2 Success

Result codes that fall within the Success category shall be used to inform a peer that a request has been successfully completed. The Result-Code AVP values defined in Diameter base protocol specified in IETF RFC 6733 [23] shall be applied.

6.4.3 Permanent Failures

6.4.3.1 General

Errors that fall within the Permanent Failures category shall be used to inform the peer that the request has failed, and should not be attempted again. The Result-Code AVP values defined in Diameter base protocol specified in IETF RFC 6733 [23] shall be applied. When one of the result codes defined here is included in a response, it shall be inside an Experimental-Result AVP and the Result-Code AVP shall be absent.

6.4.3.2 DIAMETER_ERROR_USER_UNKNOWN (5001)

This result code shall be sent by the HSS to indicate that the user identified by the IMSI is unknown. This error code is defined in 3GPP TS 29.229 [6].

6.4.3.3 DIAMETER_ERROR_UNKNOWN_PROSE_SUBSCRIPTION (5610)

This result code shall be sent by the HSS to indicate that no ProSe subscription is associated with the IMSI.

6.4.3.4 DIAMETER_ERROR_ PROSE_NOT_ALLOWED (5611)

This result code shall be sent by the HSS to indicate that ProSe is not allowed to be used in the specific PLMN where the UE is registered.

6.4.3.5 DIAMETER_ERROR_ UE_LOCATION_UNKNOWN (5612)

This result code shall be sent by the HSS to indicate that the initial location of the UE is unknown.

Annex A (normative): Diameter overload control mechanism

A.1 General

Diameter overload control mechanism is an optional feature.

IETF RFC 7683 [15] specifies a Diameter overload control mechanism which includes the definition and the transfer of related AVPs between Diameter nodes.

It is recommended to make use of IETF RFC 7683 [15] on the PC4a interface where, when applied, the ProSe Function shall behave as reacting nodes and the HSS as a reporting node.

A.2 HSS behaviour

The HSS requests traffic reduction from the ProSe Function when it is in an overload situation, including OC-OLR AVP in answer commands as described in IETF RFC 7683 [15].

The HSS identifies that it is in an overload situation by implementation specific means. For example, the HSS may take into account the traffic over the PC4a interface or other interfaces, the level of usage of internal resources (CPU, memory), the access to external resources, etc.

The HSS determines the specific contents of OC-OLR AVP in overload reports and the HSS decides when to send OC-OLR AVPs by implementation specific means.

A.3 ProSe Function behaviour

The ProSe Function applies required traffic reduction received in answer commands to subsequent applicable requests, as per IETF RFC 7683 [15].

The ProSe Function achieves requested traffic reduction by implementation specific means. For example, the ProSe Funtion may implement message throttling with prioritization or a message retaining mechanism for operations that can be postponed. As a result of the need to throttle traffic, the ProSe Function may reject Registration Request, Discovery Request, Proximity Requests initiated by UEs. The possible related error messages used over PC3 are described in the 3GPP TS 24.334 [16].

Annex B (Informative): Diameter overload node behaviour

B.1 Message prioritization

This clause describes possible behaviours of the ProSe Function regarding message prioritisation in an informative purpose.

The ProSe Function may take the following into account when making throttling decisions:

- Identification of the procedures that can be deferred (e.g. Proximity Requests), so to avoid to drop non deferrable procedures;
- Prioritisation of certain types of request (e.g. between ProSe-Subscriber-Information-Request (PIR) and ProSe-Notify-Request (PNR)) according to the context of their use, in particular:
- Higher prioritisation for commands that are related to a registered user for a service, so to avoid the interruption of the registered service for the user.

Annex C (normative): Diameter message priority mechanism

C.1 General

IETF RFC 7944 [21] specifies a Diameter routing message priority mechanism that allows Diameter nodes to indicate the relative priority of Diameter messages. With this information, other Diameter nodes may leverage the relative priority of Diameter messages into routing, resource allocation, set the DSCP marking for transport of the associated Diameter message, and also abatement decisions when overload control is applied.

C.2 PC4a interface

C.2.1 General

The Diameter message priority mechanism is an optional feature.

It is recommended to make use of IETF RFC 7944 [21] over the PC4a interface of an operator network when the overload control defined in Annex A is applied on this PC4a interface.

C.2.2 HSS and ProSe Function behaviour

When the HSS or the ProSe Function support the Diameter message priority mechanism over the PC4a interface, the HSS or the ProSe Function shall comply with IETF RFC 7944 [21].

The HSS or the ProSe Function sending a request shall determine the required priority according to its policies. When priority is required, the HSS or the ProSe Function shall include the DRMP AVP indicating the required priority level in the request it sends, and shall prioritise the request according to the required priority level.

When the HSS or the ProSe Function receive the corresponding response, it shall prioritise the received response according to the priority level received within the DRMP AVP if present in the response, otherwise according to the priority level of the corresponding request.

When the HSS or the ProSe Function receives a request, it shall handle the request according to the received DRMP AVP priority level. For the response, the HSS or the ProSe Function may modify the priority level received in the DRMP AVP according to its policies and shall handle the response according to the required priority level. If the required priority level is different from the priority level received in the request, the HSS or the ProSe Function shall include the DRMP AVP in the response.

The HSS and the ProSe Function decisions for a required priority and for the priority level value are implementation specific.

If:

- the HSS and the ProSe Function supports using the Diameter message priority mechanism for DSCP marking purposes,
- the transport network utilizes DSCP marking, and
- message-dependant DSCP marking is possible for the protocol stack transporting Diameter,

then the HSS and the ProSe Function shall set the DSCP marking for transport of the request or response according to the required priority level.

Diameter requests related to high priority traffic shall contain a DRMP AVP with a high priority of which the level value is operator dependent.

Annex D (normative): Diameter load control mechanism

D.1 General

Diameter load control mechanism is an optional feature.

IETF RFC 8583 [22] specifies a Diameter load control mechanism which includes the definition and the transfer of related AVPs between Diameter nodes.

It is recommended to make use of IETF draft-ieft-dime-load-03 [22] on the PC4a interface where, when applied, the ProSe Function shall behave as reacting node and the HSS as a reporting node.

D.2 HSS behaviour

The HSS may report its current load by including a Load AVP of type HOST in answer commands as described in IETF RFC 8583 [22].

The HSS calculates its current load by implementation specific means. For example, the HSS may take into account the traffic over the PC4a interface or other interfaces, the level of usage of internal resources (e.g. CPU, memory), the access to external resources, etc.

The HSS determines when to send Load AVPs of type HOST by implementation specific means.

D.3 ProSe Function behaviour

When performing next hop Diameter Agent selection for requests that are routed based on realm, the ProSe Function may take into account load values from Load AVPs of type PEER received from candidate next hop Diameter nodes, as per IETF RFC 8583 [22].

Annex E (informative): Change history

Change history							
Date	Meeting	TDoc	CR	Rev	Cat	Subject/Comment	New version
2014-04	CT4#64bi s					Implementation of C4-140706, C4-140707	0.1.0
2014-05	CT4#65	C4-141169				Implementation of C4-140917, C4-141072, C4-141159, C4-141077	0.2.0
2014-07	CT4#66	C4-141668				Implementation of C4-141504, C4-141507, C4-141510, C4-141636	0.3.0
2014-09	CT#65	CP-140497				Presented for information and approval	1.0.0
2014-09	CT#65					Approved at CT#65	12.0.0
2014-12	CT#66	CP-140778	000 4	1		Purge Procedure	12.1.0
		CP-140778	000 5	2		MSISDN over PC4a	
		CP-140778	000 6	2		Reset-ID	
		CP-140778	000 7	3		ProSe Initial Location Information Retrieval	
		CP-140778	000 8	2		Update of AVP naming	
		CP-140778	000 9	2		Diameter Overload Control over PC4a	
		CP-140778	001 0	2		Codes Assignment for PC4a	
2015-03	CT#67	CP-150028	001	1		Correction of references	12.2.0
		CP-150028	001	2		Introduction of Authorized Discovery Range Indication for announcing UE	
2015-06	CT#68	CP-150257	001	6		Correction and Clean-up on PC4a	12.3.0
		CP-150257	001 5	4		Addition of Charging Characteristics in ProSe Subscriber data for PC4a	
2015-12	CT#70	CP-150759	001	1		Reference to DOIC updated with IETF RFC 7683	12.4.0
2015-12	CT#70	CP-150760	001	3		Enhancements to subscription data	13.0.0
2016-03	CT#71	CP-160023	001	1		Diameter message priority over PC4a	13.1.0
2016-12	CT#74	CP-160664	002	-		Correction to change IETF drmp draft version to official RFC 7944	13.2.0
2016-12	CT#74	CP-160681	001	1		Load Control	14.0.0
2017-03	CT#75	CP-170048	002	-		Update of reference for the Diameter base protocol	14.1.0
2017-03	CT#75	CP-170048	002	1		Handling of the Vendor-Specific-Application-Id AVP	14.1.0
2017-03	CT#75	CP-170048	002	1		Cardinality of the Failed-AVP AVP in answer	14.1.0
2017-06	CT#76	CP-171018	002	1		Support for signaling transport level packet marking	14.2.0
2017-09	CT#77	CP-172013	002	-		Correction of DRMP Procedures	14.3.0
2018-06	CT#80		1'		-	Update to Rel-15 version (MCC)	15.0.0
2019-09	CT#85	CP192094	002 9	1		draft-ietf-dime-load published as RFC 8583	15.1.0
2020-06	CT#88e		Ĭ			Update to Rel-16 version (MCC)	16.0.0
2022-04	-	-	-	-	-	Update to Rel-17 version (MCC)	17.0.0
2024-03	-	-	-	-	-	Update to Rel-18 version (MCC)	18.0.0
2025-10	-	-	-	-	-	Update to Rel-19 version (MCC)	19.0.0

History

	Document history					
V19.0.0	October 2025	Publication				