

Draft **ETSI EN 303 648** V1.1.2 (2020-03)



**Reconfigurable Radio Systems (RRS);
Radio Equipment (RE) reconfiguration architecture**

Reference

REN/RRS-0227

Keywords

architecture, radio, SDR

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

Important notice

The present document can be downloaded from:

<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at www.etsi.org/deliver.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://portal.etsi.org/People/CommitteeSupportStaff.aspx>

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2020.

All rights reserved.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members.

3GPP™ and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

oneM2M™ logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners.

GSM® and the GSM logo are trademarks registered and owned by the GSM Association.

Contents

Intellectual Property Rights	5
Foreword.....	5
Modal verbs terminology.....	5
1 Scope	6
2 References	6
2.1 Normative references	6
2.2 Informative references.....	6
3 Definition of terms, symbols and abbreviations.....	7
3.1 Terms.....	7
3.2 Symbols.....	10
3.3 Abbreviations	10
4 Architectural Reference Model for Reconfigurable Radio Equipment	11
4.1 Introduction	11
4.2 Reconfigurable Radio Equipment - Architecture Components for Radio Reconfiguration	12
4.2.1 High level description.....	12
4.2.2 Communication Services Layer (CSL).....	13
4.2.3 Radio Control Framework (RCF)	16
4.2.4 Unified Radio Application (URA).....	17
4.2.5 Architectural Components System Requirements mapping.....	17
4.3 Reconfigurable Radio Equipment - Architecture Reference Model for Multiradio Applications	17
4.3.1 High level description.....	17
4.3.2 Reference Model System Requirements mapping	19
4.4 Reconfigurable Radio Equipment - radio computer	19
4.4.1 High level description.....	19
4.4.2 radio computer System Requirement Mapping.....	22
4.5 Reconfigurable Radio Equipment - the Radio Virtual Machine.....	23
4.5.1 Radio Virtual Machine basic principles.....	23
4.5.2 RVM System Requirement Mapping	23
4.6 Reconfigurable Radio Equipment - Unified Radio Applications	24
4.6.1 Introduction.....	24
4.6.2 Distribution and Installation of RAP	24
4.6.3 Operational Structure of URA	31
4.6.4 URA System Requirement Mapping	35
4.7 Security architecture for reconfigurable Radio Equipment	35
4.7.1 Description.....	35
4.7.2 Security Components System Requirements mapping	36
5 Reference Points.....	38
5.1 Introduction	38
5.2 Reference Points required for Installation/uninstallation and creating/deleting an instance of a URA.....	39
5.3 Reference Points required for list checking of URA	39
5.3.1 Reference Points required for updating instance of URA	40
5.3.2 Reference Points required for configuring URA parameters.....	40
5.4 Reference Points required for activation/deactivation of URA	41
5.5 Reference Points required for transferring context information.....	41
5.6 Reference Points required for creating data flow and sending/receiving user data	42
5.7 Reference Points required for radio environment measurements	43
5.8 Reference Points required for reporting discovered peer equipment.....	43
5.9 Reference Points required for flexible data flow	44
5.10 Reference Points required for data flow control.....	44
5.11 Reference Points required for synchronizing radio time	45
5.12 Reference Points required for control of reconfigurable RF transceiver	45
5.13 Reference points required for security functions.....	46
6 Reconfigurable RE high level operating procedures.....	48

6.0	Introduction	48
6.1	Procedures for installation/uninstallation and creating/deleting instance of a URA	48
6.2	Procedures for list checking of URA.....	53
6.2.0	General.....	53
6.2.1	Procedures for updating instance of URA	54
6.2.2	Procedures for configuring URA parameters.....	56
6.3	Procedures for activation/deactivation of URA.....	57
6.4	Procedures for transferring context information.....	58
6.5	Procedure for creating data flow and sending/receiving user data	60
6.6	Procedures for radio environment measurements.....	65
6.7	Procedure for reporting discovered peer equipment.....	66
6.8	Procedure for flexible data flow	66
6.9	Procedure for data flow control	67
6.10	Procedure for synchronizing radio time	69
6.11	Procedure for control of reconfigurable RF transceiver	70
6.12	Procedure for RE Configuration Policy endorsement, distribution and validation	78
6.13	Procedure for configuration enforcement.....	80
6.14	Procedures for long-term management.....	82
Annex A (informative): Distributed Computations on Multiple radio computers.....		88
A.0	Introduction	88
A.1	Procedures of RA Distributed Installation on Multiple radio computers	88
History		89

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "*Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards*", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

Foreword

This draft European Standard (EN) has been produced by ETSI Technical Committee Reconfigurable Radio Systems (RRS), and is now submitted for the combined Public Enquiry and Vote phase of the ETSI standards EN Approval Procedure.

Proposed national transposition dates	
Date of latest announcement of this EN (doa):	3 months after ETSI publication
Date of latest publication of new National Standard or endorsement of this EN (dop/e):	6 months after doa
Date of withdrawal of any conflicting National Standard (dow):	6 months after doa

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

1 Scope

The scope of the present document is to define the radio reconfiguration related architecture for reconfigurable Radio Equipment except for reconfigurable mobile devices which are covered in ETSI EN 303 095 [i.4], ETSI EN 302 969 [i.9] to ETSI EN 303 146-4 [i.13]. The work is based on the system requirements defined in ETSI EN 303 641 [1] and the Use Cases defined in ETSI TR 103 062 [i.1], ETSI TR 102 944 [i.2], ETSI TR 103 585 [i.3].

2 References

2.1 Normative references

References are either specific (identified by date of publication and/or edition number or version number) or non-specific. For specific references, only the cited version applies. For non-specific references, the latest version of the referenced document (including any amendments) applies.

Referenced documents which are not found to be publicly available in the expected location might be found at <https://docbox.etsi.org/Reference>.

NOTE: While any hyperlinks included in this clause were valid at the time of publication, ETSI cannot guarantee their long term validity.

The following referenced documents are necessary for the application of the present document.

- [1] ETSI EN 303 641: "Reconfigurable Radio Systems (RRS); Radio Equipment (RE) reconfiguration requirements".

2.2 Informative references

References are either specific (identified by date of publication and/or edition number or version number) or non-specific. For specific references, only the cited version applies. For non-specific references, the latest version of the referenced document (including any amendments) applies.

NOTE: While any hyperlinks included in this clause were valid at the time of publication, ETSI cannot guarantee their long term validity.

The following referenced documents are not necessary for the application of the present document but they assist the user with regard to a particular subject area.

- [i.1] ETSI TR 103 062: "Reconfigurable Radio Systems (RRS) Use Cases and Scenarios for Software Defined Radio (SDR) Reference Architecture for Mobile Device".
- [i.2] ETSI TR 102 944: "Reconfigurable Radio Systems (RRS); Use Cases for Baseband Interfaces for Unified Radio Applications of Mobile Device".
- [i.3] ETSI TR 103 585: "Reconfigurable Radio Systems (RRS); Radio Equipment (RE) reconfiguration use cases".
- [i.4] ETSI EN 303 095: "Reconfigurable Radio Systems (RRS); Radio reconfiguration related architecture for Mobile Devices (MD)".
- [i.5] Recommendation ITU-T M.60: "Maintenance Terminology and Definitions".
- [i.6] ETSI TS 103 436: "Reconfigurable Radio Systems (RRS); Security requirements for reconfigurable radios".
- [i.7] ETSI TR 103 087: "Reconfigurable Radio Systems (RRS); Security related use cases and threats".
- [i.8] Directive 2014/53/EU of the European Parliament and of the Council of 16 April 2014 on the harmonisation of the laws of the Member States relating to the making available on the market of Radio Equipment and repealing Directive 1999/5/EC.

- [i.9] ETSI EN 302 969: "Reconfigurable Radio Systems (RRS); Radio Reconfiguration related requirements for Mobile Devices".
- [i.10] ETSI EN 303 146-1: "Reconfigurable Radio Systems (RRS); Mobile Device (MD) information models and protocols; Part 1: Multiradio Interface (MURI)".
- [i.11] ETSI EN 303 146-2: "Reconfigurable Radio Systems (RRS); Mobile Device (MD) information models and protocols; Part 2: Reconfigurable Radio Frequency Interface (RRFI)".
- [i.12] ETSI EN 303 146-3: "Reconfigurable Radio Systems (RRS); Mobile Device (MD) information models and protocols; Part 3: Unified Radio Application Interface (URAI)".
- [i.13] ETSI EN 303 146-4: "Reconfigurable Radio Systems (RRS); Mobile Device (MD) information models and protocols; Part 4: Radio Programming Interface (RPI)".

3 Definition of terms, symbols and abbreviations

3.1 Terms

For the purposes of the present document, the following terms apply:

Baseband Parameter Aggregation (BPA): unit collecting all the context information to be transferred to the monitor

NOTE: The BPA unit converts the context information into metric(s) such that a minimum bandwidth is consumed during the procedure of transferring the context information to the monitor. Those metrics may include Received Signal Strength Indication (RSSI) measurement, multi-RAT performance metrics, etc.

broadcast identifier (broadcast ID): identifier linking a data packet to all available radio computers

Communication Services Layer (CSL): layer related to communication services supporting generic applications

NOTE: A communication services layer supports generic applications like Internet access. In the present document, it consists of Administrator, Mobility Policy Manager (MPM), Networking stack and Monitor.

computational resources: part of Radio Equipment hardware working under OS control and on which Applications, among others, are executed

configcodes: result of compiling the source codes of a Radio Application (RA), which is either configuration codes of Radio Virtual Machine (RVM) or executable codes for a particular target platform

NOTE: In the case when RA provider makes a high level code based on a target platform, a result of compiling RA source codes is configcodes which is executable on the target platform. In the other case, when RA provider makes a high level code without considering a target platform, a result of front-end compiling of RA source codes is an Intermediate Representation (IR) which should be back-end compiled for operating on a specific target platform.

data flow: logical channel between Flow Controller (FC) and an Unified Radio Applications (URA) created by FC to send to or receive data elements (octets, packets or other granularity) from URA

distributed computations: computational model in which components located on networked computers communicate and coordinate their actions by passing messages interacting with each other in order to achieve a common goal

environmental information: set of values that can affect the execution of RAs on a radio computer

NOTE: Environmental Information consists of information related to the execution of RA(s), such as Buffer Overflow, Resource Allocation, etc.

Functional Block (FB): function needed for real-time implementation of RA(s)

NOTE 1: A functional block includes not only the modem functions in Layer1 (L1), Layer2 (L2), and Layer 3 (L3) but also all the control functions that should be processed in real-time for implementing given RA(s).

NOTE 2: Functional blocks are categorized into Standard Functional Blocks (SFBs) and User Defined Functional Blocks (UDFBs). In more details:

- 1) *SFB* can be shared by many RAs. For example, Forward Error Correction (FEC), Fast Fourier Transform (FFT)/Inverse Fast Fourier Transform (IFFT), (de)interleaver, Turbo coding, Viterbi coding, Multiple Input Multiple Output (MIMO), Beamforming, etc. are the typical category of standard functional block.
- 2) *UDFB* include those functional blocks that are dependent upon a specific RA. They are used to support special function(s) required in a specific RA or to support a special algorithm used for performance improvement. In addition, a user defined functional block can be used as a baseband controller functional block which controls the functional blocks operating in baseband processor in real-time and to control some context information processed in real-time.

NOTE 3: Each functional block has its unique name, Input, Output, and properties.

multicast identifier (multicast ID): identifier linking a data packet to a group of radio computers

NOTE: A group of radio computers consists of at least two radio computers. The way for implementing the radio computer grouping is the choice of the manufacturers.

peer equipment: any communication counterpart of a reconfigurable Radio Equipment

NOTE: The peer equipment can be reached by establishing a (logical) communications link (i.e. an association) between the reconfigurable Radio Equipment and peer equipment. Examples of peer equipment include Wide Local Area Network (WLAN) access points, Internet Protocol (IP) access nodes, etc.

Radio Application (RA): software which enforces the generation of the transmit RF signals or the decoding of the receive RF signals

NOTE 1: The Software is executed on a particular radio platform or an RVM as part of the radio platform.

NOTE 2: RAs might have different forms of representation. They are represented as:

- Source codes including Radio Library calls of Radio Library native implementation and Radio HAL calls;
- IRs including Radio Library calls of Radio Library native implementation and radio HAL calls;
- Executable codes for a particular radio platform.

radio computer: part of Radio Equipment working under ROS control and on which RAs are executed

NOTE 1: A radio computer typically includes programmable processors, hardware accelerators, peripherals, software, etc. RF part is considered to be part of peripherals.

NOTE 2: The Radio Platform is the hardware part of the radio computer.

Radio Control Framework (RCF): control framework which, as a part of the OS, extends OS capabilities in terms of radio resource management

NOTE: RCF is a control framework which consists of Configuration Manager (CM), Radio Connection Manager (RCM), Flow Controller (FC) and Multiradio Controller (MRC). The Resource Manager (RM) is typically part of OS.

Radio Controller (RC): functional component of RA for transferring context information from corresponding RAs to monitor

NOTE: A RC, which may operate in computational resources in non real-time, accesses RAs which operates in radio computer in real time. The monitor, to which the context information is transferred using RC, provides context information to Administrator and/or Mobility Policy Manager (MPM) for application(s) to be performed using the context information, for example, terminal-centric configuration.

Radio Equipment (RE): As defined in the Radio Equipment Directive, Article 2(1)(1) [i.8].

NOTE: Excerpt from the Radio Equipment Directive: "*radio equipment' means an electrical or electronic product, which intentionally emits and/or receives radio waves for the purpose of radio communication and/or radiodetermination, or an electrical or electronic product which must be completed with an accessory, such as antenna, so as to intentionally emit and/or receive radio waves for the purpose of radio communication and/or radiodetermination*".

radio frequency transceiver (RF transceiver): part of Radio Platform converting, for transmission, baseband signals into radio signals, and, for reception, radio signals into baseband signals

radio library: library of SFB that is provided by a platform vendor in a form of platform-specific executable code

NOTE 1: SFBs implement reference codes of functions which are typical for radio signal processing. They are not atomic and their source codes are typed and visible for RA developers.

NOTE 2: A SFB is implemented through a Radio Hardware Abstraction Layer (HAL) when the SFB is implemented on hardware accelerators. Radio HAL is part of ROS.

Radio Operating System (ROS): any appropriate OS empowered by RCF

NOTE: ROS provides RCF capabilities as well as traditional management capabilities related to management of RP such as resource management, file system support, unified access to hardware resources, etc.

radio platform: part of Radio Equipment hardware which relates to radio processing capability, including programmable hardware components, hardware accelerators, RF transceiver, and antenna(s)

NOTE 1: A Radio Platform is a piece of hardware capable of generating RF signals or receiving RF signals, including Base-Band and RF processing. By nature, it is heterogeneous hardware including different processing elements such as fixed accelerators, e.g. Application-Specific Integrated Circuit (ASIC), or reconfigurable accelerators, e.g. FPGAs, etc.

NOTE 2: In case of multiple radio computers, there is an independent Radio Platform for each of the radio computers.

radio reconfiguration: reconfiguration of parameters related to air interface

Radio Virtual Machine (RVM): abstract machine which supports reactive and concurrent executions

NOTE: A RVM may be implemented as a controlled execution environment which allows the selection of a trade-off between flexibility of base band code development and required (re-)certification efforts.

reconfigurable Radio Equipment: Radio Equipment with radio communication capabilities providing support for radio reconfiguration

NOTE: Reconfigurable Radio Equipment includes Smartphones, Feature phones, Tablets, Laptops, Connected Vehicle communication platform, Network platform, IoT device, etc.

reference point: conceptual point at the conjunction of two non-overlapping functions that can be used to identify the type of information passing between these functions

NOTE: This definition is introduced by Recommendation ITU-T M.60 [i.5].

routing entity: entity which directs network packets from their source toward their destination through intermediate network nodes by specific packet forwarding mechanisms

NOTE 1: In the present document, source and destination relate either to CSL or radio computers.

NOTE 2: The directing of packets may include decision making and physical routing.

shadow radio platform: platform where configcodes can be directly executed when it corresponds to the target radio platform or, when it corresponds to an RVM, compiled and executed

NOTE: If the shadow radio platform is equivalent to the target radio platform, then a front-end compiler will generate the executable code for the target radio platform and configcodes are equivalent to the executable code for that radio platform.

unicast identifier (unicast ID): identifier linking a data packet to a specific radio computer

Unified Radio Application (URA): Radio Application which complies with the reconfigurable RE framework defined in the present document

3.2 Symbols

For the purposes of the present document, the following symbols apply:

M_1	Number of SFBs implemented on Radio computer
M_2	Number of SFBs implemented on hardware accelerators

3.3 Abbreviations

For the purposes of the present document, the following abbreviations apply:

AOT	Ahead-Of-Time
ASF	Administrator Security Function
ASIC	Applications-Specific Integrated Circuit
BE	Back End
BPA	Baseband Parameter Aggregation
CII	Context Information Interface
CM	Configuration Manager
CSL	Communication Services Layer
FC	Flow Controller
FEC	Forward Error Correction
FFT	Fast Fourier Transform
FM	File Manager
GGSN	Gateway GPRS Support Node
gMURI	generalized MultiRadio Interface
GPRS	General Packet Radio Service
GPS	Global Positioning System
gRPI	generalized Radio Programming Interface
gRRFI	generalized Reconfigurable Radio Frequency Interface
gURAI	generalized Unified Radio Applications Interface
HAL	Hardware Abstraction Layer
HW	HardWare
HW/SW	Hardware/Software
ID	IDentification
IFFT	Inverse Fast Fourier Transform
IP	Internet Protocol
IR	Intermediate Representation
JIT	Just-In-Time
KMS	Key Management System
MAC	Medium Access Control
MIMO	Multi-Input-Multi-Output
MPM	Mobility Policy Manager
MRC	MultiRadio Controller
MURI	MULTiRadio Interface
OEM	Original Equipment Manufacturer
OS	Operating System
RA	Radio Application
RAP	Radio Application Package
RAT	Radio Access Technology
RC	Radio Controller
RCF	Radio Control Framework
RCM	Radio Connection Manager
RE	Radio Equipment
RERC	Radio Equipment Reconfiguration Class
RF	Radio Frequency

RM	Resource Manager
ROS	Radio Operating System
RPI	Radio Programming Interface
RRFI	Reconfigurable Radio Frequency Interface
RRS-CM	RRS Configuration Manager
RRS-CP	RRS Configuration Provider
RVM	Radio Virtual Machine
SDR	Software Defined Radio
SFB	Standard Functional Block
SW	SoftWare
TAD	Transfer of Authority Document
TCP	Transmission Control Protocol
TX/RX	Transmission/Reception
UDFB	User Defined Functional Block
URA	Unified Radio Applications
URAI	Unified Radio Applications Interface
WLAN	Wireless Local Area Network

4 Architectural Reference Model for Reconfigurable Radio Equipment

4.1 Introduction

The present document describes those elements of a Radio Equipment which is related to the software radio reconfiguration only. For this reason, the usage of the term "architecture" is limited to those elements and not to the overall HW/SW architecture of a Radio Equipment which is out of the scope of the present document.

The present document is organized as follows:

- Clause 4.2 describes the reconfigurable Radio Equipment architecture in term of its components and entities.
- Clause 4.3 describes the architecture reference model for multiradio applications.
- Clause 4.4 describes the "radio computer".
- Clause 4.5 describes the Radio Virtual Machine as part of the architecture.
- Clause 4.6 describes the Unified Radio Application.
- Clause 4.7 describes the security architecture for reconfigurable Radio Equipment.
- Clause 5 describes the (logical) interfaces between the identified components/entities.
- Clause 6 lists the operating procedures of a reconfigurable Radio Equipment.
- Clause 4 includes a list of Tables mapping the system requirements as defined in ETSI EN 303 641 [1] to the different entities/components/units which have been identified. In general, according to the Radio Equipment Reconfiguration Class (RERC) [1], all the related mandatory functional requirements described in ETSI EN 303 641 [1] shall be implemented.

4.2 Reconfigurable Radio Equipment - Architecture Components for Radio Reconfiguration

4.2.1 High level description

Figure 4.2.1-1 shows the reconfigurable Radio Equipment architectural components related to the radio reconfiguration as well as the related entities. The main difference between the mobile device architecture ETSI EN 303 095 [i.4] and the generalized Radio Equipment architecture defined in the present document is that a mobile device includes only one radio computer, while the generalized Radio Equipment may include one or more radio computers.

As shown in Figure 4.2.1-1, the following components can be identified:


- Communication Services Layer (CSL):
 - 4 logical entities: Administration, Mobility Policy Manager, Networking Stack and Monitor.
- Radio Control Framework (RCF):
 - 5 logical entities: Configuration Manager, Radio Connection Manager, Multi-Radio Controller, Resource Manager and Flow Controller.
- Unified Radio Applications (URA).
- Radio Platform (consisting of RF transceiver(s), Baseband(s), etc.).

NOTE: When the Radio Platform consists of multiple baseband processors and/or RF transceivers, the reconfigurable Radio Equipment architecture supports the computational/spectral load balancing.

These 4 components consist of Software (CSL, RCF) and/or Hardware (Radio Platform) entities and they shall be interconnected through well-defined interfaces as follows:

- Generalized Multiradio Interface (gMURI) between CSL and RCF.
- Generalized Unified Radio Application Interface (gURAI) between RCF and URA.
- Generalized Reconfigurable Radio Frequency Interface (gRRFI) between URA and RF transceiver(s).

The above mentioned interfaces are not covered by the present document.



NOTE: Interfaces gMURI, gURAI and gRRFI in Figure 4.2.1-1 are used to interconnect components of different stakeholders.

Figure 4.2.1-1: Reconfigurable Radio Equipment Architecture Components for Radio Reconfiguration

For each components, the required entities depend on the RERC [1]. A Reconfigurable Radio Equipment shall support all the components and their entities as required by the corresponding RERC as shown in Table 4.2.1-1. In case that a Reconfigurable Radio Equipment supports multiple RERCs, the concerned Reconfigurable Radio Equipment shall support all the components and entities related to the highest supported RERC.

Table 4.2.1-1: Required Components of the Reconfigurable Radio Equipment Architecture in function of the Radio Equipment Reconfiguration Class

Radio Equipment Reconfiguration Class	Required CSL Entities	Required RCF Entities	Interfaces
RERC-0	None	None	None
RERC-1	Administrator, Mobility Policy Manager, Networking Stack, Monitor	Configuration Manager, Radio Connection Manager, Flow Controller	gMURI
RERC-2, RERC-5	Administrator, Mobility Policy Manager, Networking Stack, Monitor	Configuration Manager, Radio Connection Manager, Multi-Radio Controller, Flow Controller	gMURI, gURAI, gRRFI
RERC-3, RERC-6	Administrator, Mobility Policy Manager, Networking Stack, Monitor	Configuration Manager, Radio Connection Manager, Multi-Radio Controller, Flow Controller	gMURI, gURAI, gRRFI
RERC-4, RERC-7	Administrator, Mobility Policy Manager, Networking Stack, Monitor	Configuration Manager, Radio Connection Manager, Multi-Radio Controller, Resource Manager, Flow Controller	gMURI, gURAI, gRRFI

The following clauses describe in more details the identified components as well as the related logical entities.

4.2.2 Communication Services Layer (CSL)

The CSL is a layer related to communication services providing multiradio and non-radio functionalities. The typical examples of communication services related to multiradio functionalities are management for activating corresponding radio application or controlling data flows for each radio application. The typical example of communication services related to non-radio functionalities is Internet access using TCP (Transmission Control Protocol) and IP (Internet Protocol). A Radio Equipment shall support one or multiple radio computers. The CSL shall assign a Unicast ID, Multicast ID or Broadcast ID which is linking a data packet to a specific radio computer, a group of radio computers or all available radio computers respectively.

NOTE 1: In the present document, the scope of applications has been extended from Mobile Devices [i.4] to Radio Equipment including one or multiple radio computers. Consequently, the assignment of a Unicast ID, Multicast ID or Broadcast ID is added in the present document. In the case of [i.4], such IDs were not required, because only a single radio computer is supported.

The CSL shall be interconnected with all radio computers through a routing entity.

NOTE 2: The implementation of the routing entity and its interfaces is the choice of the manufacturer and thus out of scope of the present document.

Figure 4.2.2-1 is a conceptual diagram showing the routing of the CSL data packets to the corresponding radio computer (and vice versa, i.e. from radio computer to CSL) in the case of unicast. The routing entity interprets the Unicast ID and forwards the data packets from the CSL to the corresponding radio computer (i.e. address translation is performed) and vice versa (i.e. from radio computer to CSL).

Figure 4.2.2-2 is a conceptual diagram showing the routing of the CSL data packets to the corresponding radio computers in the case of multicast. The routing entity interprets the multicast ID and forwards the data packets from the CSL to the corresponding radio computers (i.e. address translation is performed). For the reverse link (i.e. from radio computer to CSL), unicast is applied.

Figure 4.2.2-3 is a conceptual diagram showing the routing of the CSL data packets to the corresponding radio computers in the case of broadcast. The routing entity interprets the broadcast ID and forwards the data packets from the CSL to the all available radio computers. For the reverse link (i.e. from radio computer to CSL), unicast is applied.




Figure 4.2.2-1: Conceptual diagram showing the routing of the CSL message(s) to the corresponding radio computer(s) and the routing of each radio computer's information to the CSL in the case of unicast transmission




Figure 4.2.2-2: Conceptual diagram showing the routing of the CSL message(s) to the corresponding radio computer(s) in the case of multicast transmission




Figure 4.2.2-3: Conceptual diagram showing the routing of the CSL message(s) to the corresponding radio computer(s) in the case of broadcast transmission

CSL includes the following 4 entities:

- **Administrator entity**

- The Administrator entity shall include at least functions to request installation or uninstallation of URA, and creating or deleting instances of URA. This should include the provision of information about the URA, their status, etc. In addition, the Administrator entity shall include two sub-entities:
 - the Administrator Security Function (ASF); and
 - the RRS Configuration Manager (RRS-CM).

NOTE 1: In case that a snapshot function is required, the Administrator entity may store relevant RAPs, their configuration parameters and information on the URA installation and execution history. When required, the same steps can be executed by the Administrator entity to fall back to a previous snapshot.

- **Mobility Policy Manager (MPM) entity**

- The MPM shall include at least functions for monitoring of the radio environments and RE capabilities, to request activation or deactivation of URA, and to provide information about the URA list. It shall also make selection among different radio access technologies and discover peer communication equipment and arrangement of associations. In addition, the MPM may request a computational/spectral load balancing among baseband processors and RF transceivers in radio platform when the number of baseband processors and RF transceivers in radio platform exceeds one.

NOTE 2: The additional functionality regarding load balancing is required, e.g. in the case of distributed computations.

- Explanation: The requirement for computational and/or spectral resources varies depending on the situation of each base station in the case of network application. For example, the required traffic of each base station can rapidly and unexpectedly vary due to natural disasters, sports games, accidents, etc.

- Explanation: When the reconfigurable Radio Equipment is shared with multiple stakeholders, e.g. multiple network operators share a single network infrastructure; the policy of using both computational and spectral resources may have to be controlled for a desired performance requirement at each operation.
- **Networking stack entity**
 - The Networking stack entity shall include at least functions for sending and receiving of user data.
 - The Networking stack entity shall translate the radio computer ID to a target network address and vice versa.
- **Monitor entity**
 - The Monitor entity shall include at least functions to transfer information from URA to user or proper destination entity in RE. In addition, in case that distributed computation is applied, the Monitor shall receive the computational/spectral resource usage status.

4.2.3 Radio Control Framework (RCF)

The RCF provides a generic environment for the execution of URA, and a uniform way of accessing the functionality of the radio computer and individual RAs. RCF provides services to CSL via the generalized Multiradio Interface (gMURI).

The RCF includes the following 5 entities for managing URA [i.2]:

- **Configuration Manager (CM) entity**
 - The CM shall include at least functions for installing/uninstalling and creating/deleting instances of URA as well as management of and access to the radio parameters of the URA.
- **Radio Connection Manager (RCM) entity**
 - The RCM shall include at least functions for activating/deactivating URA according to user requests, and to management of user data flows, which can also be switched from one RA to another.
- **Flow Controller (FC) entity**
 - The FC shall include at least functions for sending and receiving of user data packets and controlling the flow of signalling packets.
- **Multiradio Controller (MRC) entity**
 - The MRC shall include at least functions to schedule the requests for radio resources issued by concurrently executing URA, and to detect and manage the interoperability problems among the concurrently executed URA. In addition, in case that distributed computation is applied, the MRC shall include a function to report spectral resource usage status.
- **Resource Manager (RM) entity**
 - The RM shall include at least functions to manage the computational resources, to share them among simultaneously active URA, and to guarantee their real-time execution. In addition, in case that distributed computation is applied, RM shall include a function to report computational resource usage status.

4.2.4 Unified Radio Application (URA)

As described in clause 4.2.3, the RCF, which represents functionalities provided by the radio computer, requires all RAs to be subject to a common reconfiguration, multiradio execution and resource sharing strategy framework (depending on the concerned RERC). Since all RAs exhibit a common behaviour from the reconfigurable RE perspective, those RAs are called URAs. The services relate to activation and deactivation, peer equipment discovery and maintenance of communication over user data flows are provided at generalized Unified Radio Application Interface (gURAI), which is an interface between URA and RCF.

4.2.5 Architectural Components System Requirements mapping

The logical entities above described are mapped to the system requirements described in ETSI EN 303 641 [1] as shown in Table 4.2.5-1.

Table 4.2.5-1: Mapping of Architectural Components to the system requirements described in ETSI TS 103 436 [1]

Entity/Component/Unit	System Requirements [1]	Comments
Administrator	R-FUNC-RER-01 R-FUNC-RER-02 R-FUNC-SEC-01 R-FUNC-SEC-02 R-FUNC-RER-16	The reconfigurable RE configuration is performed through downloading of the RAP into the reconfigurable RE and its installation. The requirements are described in clauses 6.4.1, 6.4.2, and 6.6 of [1].
Mobility Policy Manager	R-FUNC-RAT-04 R-FUNC-RER-03 R-FUNC-RER-16	RAP into the reconfigurable RE and its installation. The requirements are described in clauses 6.1.4 and 6.4.3 of [1].
Networking stack	R-FUNC-RA-04	Management of data flows is required for basic TX/RX operation. The requirement is described in clause 6.2.4 of [1].
Flow Control	R-FUNC-RAT-05	
Monitor	R-FUNC-RA-05	The RC in RA ensures the availability of context information. The requirement is described in clause 6.2.5 of [1].
Configuration Manager	R-FUNC-RER-03	The radio configuration of a reconfigurable RE is realized with the activation of URA. The requirement is described in clause 6.4.3 of [1].
Radio Connection Manager		
Multiradio Controller	R-FUNC-RAT-01 R-FUNC-RAT-02 R-FUNC-RAT-03 R-FUNC-RAT-05 R-FUNC-RAT-06	The proposed Radio Equipment Architecture is suitable to support Multiple (parallel) connections to (heterogeneous) RATs. The requirements are described in clauses 6.1.1 and 6.1.2 of [1].
Resource Manager	R-FUNC-RER-05	In case of dynamic resource sharing, the resource allocation is performed in run time. The requirements are described in clause 6.4.5 of [1].

4.3 Reconfigurable Radio Equipment - Architecture Reference Model for Multiradio Applications

4.3.1 High level description

Figure 4.3.1-1 exemplifies a Reconfigurable RE architecture reference model for multiradio applications. As shown in Figure 4.3.1-1, the reconfigurable RE architecture shall include at least one radio computer.




Figure 4.3.1-1: Reconfigurable Radio Equipment (RE) architecture Reference Model for multiradio applications

In the example of Figure 4.3.1-1, the operation of Computational Resources is performed by a given Operating System (OS), which is preferably performed on non-real-time basis, whereas radio computer(s)'s operation is performed by another OS, which should support real-time operations of URA. The OS of radio computer(s) is referred to as Radio OS (ROS) in the present document and can belong to its own radio computer.

In the example of Figure 4.3.1-1, the red-dotted part illustrates the non-real-time processing.

The Computational Resources execute the following functional components:

- A non-real time OS for execution of Administrator, MPM, Networking stack and Monitor which are part of the CSL as above described.
- The Radio Controller (RC) in Radio Application (RA) sending context information to the Monitor and send/receive data to/from Networking stack.

The radio computer(s) shall include the following components:

- A Real-time Radio Operating System (ROS).
- The 5 entities of the RCF, specified in clause 4.2.3, are classified into two groups. One group relates to real-time execution and the other group to non-real-time execution as shown in Figure 4.3.1-1. Which entities of RCF interface relate to real-time and non-real-time execution, can be determined by each vendor.

4.3.2 Reference Model System Requirements mapping

The architecture reference model above described is mapped to the system requirements described in ETSI EN 303 641[1] as shown in Table 4.3.2-1.

Table 4.3.2-1: Mapping of Reference Model to the system requirements described in ETSI TS 103 436 [1]

Entity/Component/Unit	System Requirements [1]	Comments
Computational Resources (vendor specific)	R-FUNC-RA-05	The Radio Controller in RA ensures the availability of context information. The requirement is described in clause 6.2.5 of [1].
radio computer(s)	R-FUNC-RER-09, R-FUNC-RA-06	ROS enables management of timing constraints and provides interface between URA and Radio Platform. The requirements are described in clauses 6.4.9 and 6.2.6 of [1].

4.4 Reconfigurable Radio Equipment - radio computer

4.4.1 High level description

The System Architecture for multiple radio computers is illustrated in Figure 4.4.1-1 and Figure 4.4.1-2. Some of the entities included in the figures below may be located externally (in the "Cloud") in order to off-load processing from the concerned Radio Equipment. For example, the Back End compiler in Figure 4.4.1-1 is moved into the "Cloud" as illustrated in Figure 4.4.1-2.




Figure 4.4.1-1: System architecture for radio computers where Radio Library and Back End (BE) compiler are included within the radio computers

NOTE 1: According to the Figure 4.4.1-1, a RadioApp can be distributed onto multiple radio computers.




Figure 4.4.1-2: System architecture for radio computer where Radio Library and BE compiler are provided at a cloud outside the radio computer

NOTE 2: According to Figure 4.4.1-2, this is a special case for platforms which do not have enough resources for Back-end compilation. For such low-complexity devices, it is assumed that only a single radio computer is present.

Certification is required for Configcodes.

The radio computer shall provide communication capabilities for reconfigurable REs and shall consist of:

- ROS including RCF.
- URA configuration codes (configcodes), which are:
 - Executable codes for RERC-2, RERC-3 and RERC-4.
 - Source codes or IR for RERC-5, RERC-6 and RERC-7.
- Radio Virtual Machine (RVM) for RERC-5, RERC-6 and RERC-7.
- Radio Library Native Implementation for RERC-5, RERC-6 and RERC-7 when URA configcodes is compiled within RE, or when URA configcodes is compiled in a cloud with dynamic linking.
- Radio platform.

URA Configcodes shall be executable codes for RERC-2, RERC-3 and RERC-4, or shall be interpreted by the RVM for RERC-5, RERC-6 and RERC-7.

For RERC-2, RERC-3 and RERC-4, a front-end compiler shall generate the executable code for the target platform and configcodes are equivalent to the executable code for that target platform. Hence, Radio Library native implementation and Back-end Compiler shown with the dotted line in Figure 4.4.1-1 is not required in the radio computer.

The RVM (see also clause 4.4) is an Abstract Machine which is capable of executing configcodes and it is independent of the hardware. The implementation of an RVM is target radio computer specific and it includes the Back-end Compiler which might provide Just-in-Time (JIT) or Ahead-of-Time (AOT) method for compilation of configcodes into executable codes.

For RERC-5, RERC-6 and RERC-7, where URA configcodes are source codes or IR, the Back-end Compiler can be implemented in 2 different ways as follows:

- 1) The URA configcodes are source codes or Intermediate Representation (IR) that is to be compiled at a given RE.
- 2) The URA configcodes are source codes or Intermediate Representation (IR) that is to be compiled at a Cloud.

In the former cases, as shown in Figure 4.4.1-1, Radio Library Native Implementation and Back-end Compiler are given in radio computer. Therefore, in this case, URA configcodes is downloaded into radio computer in the form of source code or IR and it is transformed into corresponding executable code through the Back-end Compiler within radio computer. Note that the Back-end Compiler can be a part of RVM in this case. In the latter case, as shown in Figure 4.4.1-2, the compilation process is performed at a cloud not within radio computer. Therefore, URA configcodes is downloaded into radio computer in the form of executable code as a result of the compilation at the cloud. It means that platform vendor should provide the Back-end Compiler and/or Radio Library Native Implementation at a cloud in accordance with their Radio Platform. Note that the Radio Library Native Implementation should be provided in a cloud/RE in the case of static/dynamic linking which will be explained in more detail in clause 4.6.

The Radio Library shall consist of Standard Functional Blocks (SFBs) representing the computational basis. An RA shall be expressed as a set of these interconnecting SFBs together with User Defined Functional Blocks (UDFBs) [1]. SFBs to be provided from the Radio Library normative description shall be represented in a platform-independent normative language. The native implementation of the Radio Library shall be provided as platform-specific codes of the SFBs from the library for the target platform. A Radio Library shall be extendable.

As illustrated in Figure 4.4.1-1 and Figure 4.4.1-2, the access to a RadioApp Store shall require an interface: the generalized Radio Programming Interface (gRPI). The definition of this interface is out of scope of the present document.

4.4.2 radio computer System Requirement Mapping

The radio computer above described is mapped to the system requirements described in ETSI EN 303 641 [1] as shown in Table 4.4.2-1.

Table 4.4.2-1: Mapping of radio computer to the system requirements described in ETSI TS 103 436 [1]

Entity/Component/Unit	System Requirements [1]	Comments
radio computer Architecture	R-FUNC-RER-04 R-FUNC-RER-10 R-FUNC-RER-13 R-FUNC-RER-16	The requirements are described in clauses 6.4.4, 6.4.10, 6.4.13 and 6.4.16 of [1]
Radio Platform	R-FUNC-RAT-02 R-FUNC-RAT-03 R-FUNC-RA-01 R-FUNC-RA-03 R-FUNC-FB-04 R-FUNC-FB-05 R-FUNC-RAT-05 R-FUNC-RAT-06	The requirements are described in clauses 6.5.2 and 6.5.3 of [1]
Radio Library	R-FUNC-FB-06	The requirement is described in clause 6.3.6 of [1]
	R-FUNC-FB-01	The requirement is described in clause 6.3.1 of [1]
Radio Virtual Machine	R-FUNC-RER-13	The requirement is described in clause 6.4.13 of [1]
Configcodes	R-FUNC-RER-01 R-FUNC-RER-02 R-FUNC-RER-04	The requirements are described in clauses 6.4.1, 6.4.2 and 6.4.4 of [1]
Radio Applications	R-FUNC-RA-02 R-FUNC-FB-03	The requirement is described in clause 6.2.2 of [1]
Interfaces	R-FUNC-RER-04	The requirement is described in clause 6.4.4 of [1]
	R-FUNC-RFT-01	The requirement is described in clause 6.5.1 of [1]

4.5 Reconfigurable Radio Equipment - the Radio Virtual Machine

4.5.1 Radio Virtual Machine basic principles

The RVM shall enable a RA to choose one among multiple available protection classes for code to be executed on the RVM as well as a protection class for the RF front-end. Depending on the combination of chosen RF & RVM protection classes, the required re-certification process of the software reconfigurable radio platform will be more or less complex. The basic principle is illustrated in Figure 4.5.1-1.




Figure 4.5.1-1: A typical Radio Equipment architecture comprising an RVM Software Component selecting RF and/or RVM protection class(es)

A typical Radio Equipment architecture includes an RF transceiver chain, Analog-to-Digital converters, Digital-to-Analog converters, Base Band Processing, etc. An RVM controls RF transceiver chain, in particular for selection of an RF Protection Class.

4.5.2 RVM System Requirement Mapping

The RVM above described is mapped to the system requirements described in ETSI EN 303 641 [1] as shown in Table 4.5.2-1.

Table 4.5.2-1: Mapping of RVM to the system requirements described in ETSI TS 103 436 [1]

Entity/Component/Unit	System Requirements [1]	Comments
Radio Virtual Machine	R-FUNC-RER-13	The requirement is described in clause 6.4.13 of [1]
	R-FUNC-RER-14	
	R-FUNC-RER-13 R-FUNC-RER-15 R-FUNC-RFT-09	The requirements are described in clauses 6.4.13, 6.4.15 and 6.5.9 of [1]

4.6 Reconfigurable Radio Equipment - Unified Radio Applications

4.6.1 Introduction

As already described in clause 4.3.2, RAs loaded into a Reconfigurable RE are called URAs.

The procedure of distributing and executing RA codes consists of 3 steps: design time, installation time, and run time. Figures 4.6.2-1, 4.6.2-2, 4.6.2-3, 4.6.2-4 and 4.6.2-5 illustrate these three steps for the case of platform-specific executable code, platform-independent source code (static/dynamic linking), and platform-independent IR (static/dynamic linking), respectively.

4.6.2 Distribution and Installation of RAP

In this clause, the procedure of distribution and installation of RA codes on the target reconfigurable REs is presented. During the design time, the RA codes provider will generate a Radio Application Package (RAP) that includes metadata (e.g. for pipeline configuration) and RA codes. Note that the RC codes are part of the RA codes. In case that RC codes are executed in the non-real-time environment, they are compiled to be executed in a given Computational Resources before they are included in the RAP.

During the installation time, the RAP will be downloaded from a RadioApp Store and installed in the reconfigurable RE. The RA codes, including RC codes, and metadata (e.g. for pipeline configuration) included in the RAP are installed in the reconfigurable RE. Note that the RC codes are installed in the Computational Resources for operations that do not have to be executed in real time processing such as context information processing, while the Functional Block (SFBs & UDFBs) codes shall be installed in the radio computers to be processed in real-time




Figure 4.6.2-1: Conceptual diagram for adopting platform-specific executable code for radio application package for RERC-2, RERC-3 and RERC-4

NOTE: It is assumed that a single Radio OS is handling all radio computers. In practice, it is also possible that each radio computer uses its own Radio OS. Then, the distribution of tasks needs to be done by the programmer.

Figure 4.6.2-1 illustrates a block-diagram corresponding to the case of distributing Configcodes that are executable in a given reconfigurable RE. When the Configcodes are executable, the Functional Blocks (SFBs & UDFBs) are executed on the radio computer. They are compiled for each target platform during the design time to generate the corresponding Configcodes. This means that UDFB and SFB code are compiled in accordance with a given radio computer before they are included in the RAP during the design time. After compilation, the Configcodes including both UDFB and SFB codes are installed and loaded into reconfigurable RE to be operated on the ROS.




Figure 4.6.2-2: Conceptual Diagram of adopting platform-independent source code (static linking) for radio application package for RERC-5, RERC-6 and RERC-7




Figure 4.6.2-3: Conceptual Diagram of adopting platform-independent source code (dynamic linking) for radio application package for RERC-5, RERC-6 and RERC-7

Figure 4.6.2-2 and Figure 4.6.2-3 illustrate a block-diagram corresponding to the case of distributing Configcodes in a form of platform-independent source code for static and dynamic linking respectively. When the Configcodes are provided in a platform-independent source code, the RA codes include the RC and UDFB codes only. As for the SFBs, the metadata provides information for efficient compilation. The function calls of the SFBs that are needed to execute the target URA are contained in the Configcodes. The Configcodes consisting of the UDFBs are compiled (e.g. in reconfigurable RE or in the cloud) during the installation time. The native implementation of SFBs is done before run time and is contained in the native library.

In the case of static linking, as illustrated in Figure 4.6.2-2, the linking of UDFBs with SFBs is performed during installation time. During the run time, the compiled codes are loaded to be executed on the ROS.

In the case of dynamic linking, as illustrated in Figure 4.6.2-3, the linking of UDFBs with SFBs is performed during run time.

In both cases, the compilation process during Installation time can be done using one of the two procedures as discussed in clause 4.4 which is summarized as follows:

- 1) Installation Time functions is performed within the Radio Equipment or alternatively.
- 2) Some of the Installation Time functions except for the function of Installer itself are performed externally (i.e. in the "Cloud"). Typically, such a Cloud service is controlled by the platform vendor.

Depending on the upper choice, the Radio Equipment Architecture may change. For example, with compilation being executed in the Cloud, no compiler is required in the Radio Equipment. Note that, for the cloud service of compiling URA configcodes in the case of dynamic linking, Radio Library Native Implementation should be provided within RE.

As shown in Figures 4.6.2-2 and 4.6.2-3, the RA code might be optionally encrypted. If the RA code was originally encrypted then the corresponding Configcodes should be decrypted before the compilation during the installation time.




Figure 4.6.2-4: Conceptual Diagram of adopting platform-independent IR (static linking) for radio application package for RERC-5, RERC-6 and RERC-7




Figure 4.6.2-5: Conceptual Diagram of adopting platform-independent IR (dynamic linking) for radio application package for RERC-5, RERC-6 and RERC-7

Figure 4.6.2-4 and Figure 4.6.2-5 illustrate a block-diagram corresponding to the case of distributing Configcodes in a form of platform-independent IR for static and dynamic linking respectively. When the Configcodes are provided in the platform-independent IR, the RA codes which include the UDFB codes are front-end compiled during the design time. At the installation time, the front-end compiled UDFB codes of Configcodes are back-end compiled at reconfigurable RE to be translated into an executable code specific to a given radio computer. The native implementation of SFBs is done before run time and is contained in the native library.

In the case of static linking, as illustrated in Figure 4.6.2-4, the linking of UDFBs with SFBs is performed during installation time. During the run time, the back-end compiled codes are loaded to be executed on the ROS.

In the case of dynamic linking, as illustrated in Figure 4.6.2-5, the linking of UDFBs with SFBs is performed during run time.

In both cases, the compilation process during Installation time can be done using one of the two procedures as discussed in clause 4.4 which is summarized as follows:

- 1) Installation Time functions is performed within the Radio Equipment or alternatively.
- 2) Some of the Installation Time functions except for the function of Installer itself are performed externally (i.e. in the "Cloud"). Typically, such a Cloud service is controlled by the platform vendor.

Depending on the upper choice, the Radio Equipment Architecture may change. For example, with compilation being executed in the Cloud, no compiler is required in the Radio Equipment. Note that, for the cloud service of compiling URA configcodes in the case of dynamic linking, Radio Library Native Implementation should be provided within RE.

In the case of adopting platform-independent IR, the UDFB codes of Configcodes are back-end compiled for a given radio computer during the installation time.

4.6.3 Operational Structure of URA

In this clause the operational structure of URA in run time is presented. For simplicity, this clause assumes the case where the Radio Equipment has one radio computer. In the case of multiple radio computers, the same structure shown in each figure is repeated for each of the radio computers in a given Radio Equipment. Two different cases are considered:

- 1) The URA configcodes are executable on a given RE.
- 2) The URA configcodes are source codes or Intermediate Representation (IR) that is to be compiled at a given RE.




Figure 4.6.3-1: Operational structure of URA when URA configcodes are executable on a target platform




Figure 4.6.3-2: Operational structure of URA when URA configcodes are source codes or IR to be compiled




Figure 4.6.3-3: Operational structure of URA when URA configcodes are combined (executable & IR) codes

Note that SFBs are classified into two groups, i.e. requiring or not dedicated hardware accelerators. In case that a hardware accelerator is used, it is accessed through the Radio Hardware Abstraction Layer (HAL). In the other case, platform specific code is provided for the concerned SFB by the Radio Library.

The first case (i.e. executable code is provided) is illustrated in Figure 4.6.3-1. Here the SFBs and UDFBs needed to perform a given URA are already bound in the executable configcodes of URA.

The second case (i.e. Source Code or IR is provided) is illustrated in Figure 4.6.3-2. In this case, the UDFBs needed to perform a given URA are included in the configcodes of the URA and shall be compiled (see also Figure 4.4.1-1) for Source Code (by the Compiler) or IR (by the Back End Compiler) respectively. Note that the native implementation of Radio Library shall be prepared in a given RE separately because the Radio Library native implementation cannot be contained in URA configcodes. As mentioned earlier, the function calls of SFB(s) are provided in the metadata. Generally, the native implementation of Radio Library is provided by the radio computer vendor because Radio Library includes SFB(s) that is/are implemented on the radio computer. These SFBs can be implemented without using hardware accelerator(s) or for combining accelerator(s) and program code to generate another SFB(s).

The third case is illustrated in Figure 4.6.3-3 which is a hybrid of the former two cases. Here, URA consists of executable codes and IR codes. Operational procedure for the executable codes in this case is equivalent to that of the first case, i.e. shown in Figure 4.6.3-1, whereas the IR part shall be processed in the RVM. In this way, IR can be executed in run-time. The RVM may be implemented, for example, as an interpreter, a just-in-time compiler, etc.

In the above explained 3 cases a Radio Hardware Abstraction Layer (HAL) includes hardware abstraction for SFBs implementation using hardware accelerator(s). This means that, whenever the SFB(s) to be implemented using hardware accelerator(s) is/are called in a given URA code, they are implemented directly on a corresponding hardware accelerator(s) via the Radio HAL. As it will be discussed later in this clause, the Radio HAL includes also a hardware abstraction for the UDFB(s) that is/are composed of a set of SFBs at least one of which is implemented using the hardware accelerator(s).

SFBs typically include all those functional blocks which are commonly used in URA (e.g. such as Fast Fourier Transform (FFT), etc.) and those functionalities that are implemented very efficiently using special-purpose accelerator(s) in a given radio platform (e.g. such as Turbo coder). SFBs can thus be implemented in Software or dedicated Hardware.

The UDFB Set shown in Figure 4.6.3-2 includes all the UDFBs to be used in a given URA. It is important that any SFB can be modified and/or extended as appropriate by replacing it with UDFB(s). Therefore, UDFB(s) could be good candidate(s) for SFBs extension, which means that they might become SFBs later (and become "atomic" as the normal SFBs) through an extension of the Standard Radio Library (e.g. by approval through the community). Since any UDFB Set is to be provided by the RA provider (e.g. a 3rd party different from the radio computer vendor), in order for RCF to be able to perform basic controls of every UDFB, control interface functions such as "*start*", "*stop*", "*pause*", "*get_port*" and "*initialize*" may have to be specified for the corresponding UDFB(s).

The Operational structure of URA depicted in Figure 4.6.3-2 includes the following components:

- **URA** includes SFB(s) and UDFB(s) in accordance with the contents of metadata in a given RAP.
- **Radio Library** contains a platform specific code of SFBs that will be implemented on the radio computer.

NOTE 1: Those SFBs which are implemented using hardware accelerator(s) are supported by the Radio HAL. In this case, the Radio Library typically contains corresponding function calls to access hardware accelerator(s).

- **UDFB Set** includes all the UDFBs to be used in given URA and is in general provided by the RA provider. UDFBs are included in RAP together with metadata and RC code. Since UDFBs are in general modified and/or extended version of SFBs, UDFBs in many cases have a dependency on SFBs.
- **Radio HAL** is to abstract radio platform and it shall support SFBs to be implemented using hardware accelerator in order for each of those SFBs to be implemented directly on corresponding hardware accelerator(s). The Radio HAL is platform specific and is not standardized.
- **Radio Platform Driver** is a hardware driver used by the ROS to access the radio platform.
- **Radio Platform** in general includes RF transceiver, antenna(s), fixed and/or configurable hardware accelerator and/or programmable IP core(s).

Figure 4.6.3-4 illustrates an implementation of functional blocks on a given radio computer. In the example shown in Figure 4.6.3-4, the number of SFBs for programmable components has been set to M_1 and the number of SFBs requiring dedicated hardware accelerators has been set to M_2 , while the total number of SFBs is $M = M_1 + M_2$. As mentioned earlier in this clause, some SFBs, for example FFT, Turbo decoder, Multi-Input-Multi-Output (MIMO) decoder, etc. can be implemented directly on the corresponding hardware accelerator, for example to achieve high performance and low power consumption. Those SFBs that are executed by the hardware accelerator(s) are supported by the Radio HAL for the implementation on the corresponding dedicated accelerator(s). This means that, when each SFB to be implemented on the dedicated accelerator(s) is called in URA, it is implemented directly on the corresponding dedicated accelerator(s) through Radio HAL. Similarly, operations such as bit-reverse, multiply and accumulation, etc. are introduced by SFBs, e.g. for programmable components.

Consequently, the SFB/UDFB execution codes required on the radio computer consists of the following two parts: one part is execution codes implemented on programmable components and the other part is Radio HAL codes implemented on dedicated accelerators. It can be summarized as follows:

$$\{C: \text{execution codes required on radio computer for SFBs/UDFBs implementation}\} = \{A: \text{execution codes for SFBs/UDFBs for programmable components}\} + \{B: \text{Radio HAL codes for SFBs/UDFBs requiring dedicated hardware accelerators}\},$$

meaning that:

$$C = A + B$$

where the portion of A and B will be determined by each vendor. It particularly means that:

$$\{\text{SFBs/UDFBs}\} = \{\text{SFBs/UDFBs for programmable components}\} \cup \{\text{SFBs/UDFBs requiring dedicated hardware accelerators}\}$$

where:

$$\{\text{SFBs/UDFBs for programmable components}\} \cap \{\text{SFBs/UDFBs requiring dedicated hardware accelerators}\} = \emptyset.$$

The reason why SFBs are classified into two groups, (i.e. requiring or not dedicated hardware accelerators), is that each category has its own pros and cons. The former, since it is implemented on dedicated hardware accelerators, is advantageous, e.g. for power consumption, speed-up operation, and, cost-effectiveness while the latter is advantageous mainly for flexibility. It is expected that the dedicated hardware accelerator(s) will be used relatively more widely at the beginning stage until programmable devices become competitive to dedicated hardware devices in performance. As semiconductor technology evolves, the SFBs for programmable components will gradually become more and more dominant in a long term standpoint.




Figure 4.6.3-4: Implementation of functional blocks libraries on each radio computer

NOTE 2: This operation needs to be performed for each radio computer in case of multiple radio computers.

4.6.4 URA System Requirement Mapping

The URA above described is mapped to the system requirements described in ETSI TS 103 436 [1] as shown in Table 4.6.4-1.

Table 4.6.4-1: Mapping of URA to the system requirements described in ETSI TS 103 436 [1]

Entity/Component/Unit	System Requirements [1]	Comments
Configcodes	R-FUNC-RER-01	The requirements are described in clauses 6.4.1, 6.4.2 and 6.4.4 of [1].
	R-FUNC-RER-02	
	R-FUNC-RER-04	
Functional Blocks	R-FUNC-RA-02	The requirement is described in clause 6.2.2 of [1].
	R-FUNC-RER-13	The requirement is described in clause 6.4.13 of [1].
	R-FUNC-RER-12	
Radio Library	R-FUNC-FB-02	The requirement is described in clause 6.3.2 of [1].
	R-FUNC-FB-06	The requirement is described in clause 6.3.6 of [1].
	R-FUNC-FB-01	The requirement is described in clause 6.3.1 of [1].
Radio Applications	R-FUNC-RER-07	The requirement is described in clause 6.4.7 of [1].
	R-FUNC-RA-06	The requirements are described in clauses 6.2.6, 6.2.5 and 6.2.2 of [1].
	R-FUNC-RA-05	
	R-FUNC-RA-02	

4.7 Security architecture for reconfigurable Radio Equipment

4.7.1 Description

The security architecture for reconfigurable Radio Equipment extends the architecture defined in clause 4.2 of the present document in order to ensure the security of the reconfigurable platform and of the digital assets.

NOTE: The rationale for the selection of security component, and the description of the security functions' operations, are detailed in ETSI TR 103 087 [i.7] with their normative counterpart being specified in ETSI TS 103 436 [i.6].

The security architecture relies on the following additional entities on the device:

- The Administrator Security Function (ASF), as sub-entity of the Administrator on the device end-point responsible for ensuring confidentiality, integrity, and authenticity of assets such as the RE Configuration Policy, and RAP(s), and supporting the non-repudiation, remote attestation, and configuration enforcement strategies.
- The RRS Configuration Manager (RRS-CM), a sub-entity of the Administrator in charge of long-term management.
- The Root of Trust, providing security services, such as secure storage, with a high level of security assurance.

Figure 4.7.1-1 illustrates the additional entities of the security architecture on the device.




Figure 4.7.1-1: Reconfigurable Radio Equipment Architecture with security components

The Hardware Root of Trust Interface is not covered in the present document.

Furthermore, the security architecture relies on the following external entities ETSI TS 103 436 [i.6] and ETSI TR 103 087 [i.7]:

- Asset Endorsement Functions, responsible for the security of digital assets (such as RE Configuration Policy, RAP and other assets).
- Command Security Functions, responsible for the security of remote commands being sent to the device.
- Verifying Entity and Requestor, supporting remote attestation.
- Manufacturer Key Management System (OEM KMS), RRS Configuration Authority (RRS-CA), and RRS Configuration Provider (RRS-CP), supporting the long-term management framework.

4.7.2 Security Components System Requirements mapping

The logical entities above described are mapped to the system requirements described in clause 6.6 of ETSI EN 303 641 [1] as shown in Table 4.7.2-1.

Table 4.7.2-1: Mapping of Security Components to the system requirements described in ETSI EN 303 641 [1]

Entity/Component/Unit	System Requirements [1]	Comments
Administrator Security Function (ASF)	R-FUNC-SEC-01 R-FUNC-SEC-02 R-FUNC-SEC-03 R-FUNC-SEC-04	In addition to supporting operations related to asset protection, the ASF acts as a proxy to other security functions on the platform, as detailed in [i.7]. The requirements are described in clauses 6.6.1, 6.6.2, 6.6.3 and 6.6.4 of [1].
RRS Configuration Manager (RRS-CM)	R-FUNC-SEC-03	The operations of long-term management are detailed in [i.7], clause 11, with related requirements in [i.6]. The requirement is described in clause 6.6.3 of [1].
Root of Trust	R-FUNC-SEC-04	The exact nature of the Root of Trust depends on industry best practices and the concept of security tiers introduced in [i.6]. The requirement is described in clause 6.6.4 of [1].
Asset Endorsement Functions	R-FUNC-SEC-01 R-FUNC-SEC-02	These functions are the ASF's external peers. In particular, they provide proof that assets originate from authorized sources. The requirements are described in clauses 6.6.1 and 6.6.2 of [1].
Command Security Functions	R-FUNC-SEC-03	Commands are processed by the Administrator after having being validated by the ASF. Command Security Functions provide, in particular, proof that configuration commands originate from authorized sources. The configuration enforcement framework is detailed in [i.7], clause 10, with related requirements in [i.6]. The requirement is described in clause 6.6.3 of [1].
Verifying Entity Requestor	R-FUNC-SEC-03	The requestors typically wish to assert high level claims about the platform. The Verifying Entity translates these claims into atomic attestation requests towards platform components. Remote attestation is detailed in [i.7], clause 9, with related requirements in [i.6]. The requirement is described in clause 6.6.3 of [1].
Manufacturer Key Management System (OEM KMS)	R-FUNC-SEC-03	The operations of the long-term management framework are detailed in [i.7], clause 11, with related requirements in [i.6].
RRS Configuration Authority (RRS-CA)		The requirement is described in clause 6.6.3 of [1].
RRS Configuration Provider (RRS-CP)		

5 Reference Points

5.1 Introduction

Figure 5.1-1 illustrates the entire architecture of RE with all the reference points being specified between corresponding entities. For simplicity, this clause assumes that the Radio Equipment has only one radio computer. In the case of multiple radio computers, the structure of RCF, URA, and Radio Platform is repeated for each of the radio computers with a single CSL in a given Radio Equipment. Note that all the reference points shown in Figure 5.1-1 shall remain the same in each radio computer. Each solid line between two blocks denotes a reference point (i.e. a logical or physical interface) defined between the two blocks through which direct interaction(s) between the two blocks is(are) performed, whereas each dotted line between two blocks denotes that interaction(s) between the two blocks is performed through ROS based on (a) command(s) issued by a corresponding block. As it will be shown, blocks in RCF, i.e. CM, RCM, MRC, and RM, issue the command for the interaction(s) to take place at URA through ROS. The definition of each reference point is based on the three kinds of interfaces, i.e. gMURI which are interfaces between entities of CSL and that of RCF, gURAI which are interfaces between URA and entities of RCF, and generalized Reconfigurable Radio Frequency Interfaces (gRRFI) which are interfaces between URA and Radio Frequency (RF) part. In addition to gMURI, gURAI, and gRRFI, interfaces between entities of RCF have also been defined as reference points. In the present document, the reference points are classified according to procedures of their functions such that the classification of each of the reference points becomes coincident with each of the procedures defined in clause 6.




Figure 5.1-1: Entire architecture of reference points for the RE

5.2 Reference Points required for Installation/uninstallation and creating/deleting an instance of a URA




Figure 5.2-1: Illustration of reference points for installation/uninstallation and creating/deleting instance of a URA

Figure 5.2-1 illustrates reference points, CF1a, CF1b, CF4, and CF5, which are related to the installation/uninstallation (CF1a) or creation/deletion (CF1b, CF4, CF5) instance of a URA.

Reference Point **CF1a** is an interface between Administrator and CM, through which Administrator requests CM to perform the installation/uninstallation of a URA and receives a response from CM.

Reference Point **CF1b** is an interface between Administrator and CM, through which Administrator requests CM to create/delete an instance of an URA and receives a response from CM.

Reference Point **CF4** provides interaction between CM and MRC, through which CM requests MRC to send the parameters related to radio resources to CM, and receives a response (i.e. the requested parameters) from MRC during the procedure of creating an instance of URA.

Reference Point **CF5** provides interaction between CM and RM, through which CM requests RM to send the parameters related to computational resources to CM, and receives a response (i.e. the requested parameters) from RM during the procedure of creating an instance of URA.

5.3 Reference Points required for list checking of URA




Figure 5.3-1: Illustration of reference points for obtaining the lists of URA

Figure 5.3-1 illustrates the reference points CF1c and CF2, which are related to URA list checking.

Reference Point **CF1c** is an interface between Administrator and CM, through which Administrator requests CM to send the URA list, and receives a response (i.e. the URA list), from CM.

Reference Point **CF2** is an interface between MPM and CM, through which MPM requests CM to send the URA list and receives a response (i.e. the URA list), from CM.

5.3.1 Reference Points required for updating instance of URA




Figure 5.3.1-1: Illustration of reference points for updating instance of URA

Figure 5.3.1-1 illustrates the reference points CF1d, which is related to updating instance of URA.

Reference Point **CF1d** is an interface between Administrator and CM, through which Administrator requests CM to update instance of URA, and receives a response from CM.

5.3.2 Reference Points required for configuring URA parameters




Figure 5.3.2-1: Illustration of reference points for configuring URA parameters

Figure 5.3.2-1 illustrates the reference points CF1e, which is related to configuring URA parameters.

Reference Point **CF1e** is an interface between Administrator and CM, through which Administrator requests CM to configure URA parameters, and receives a response from CM.

5.4 Reference Points required for activation/deactivation of URA




Figure 5.4-1: Illustration of reference point for activation/deactivation of URA

Figure 5.4-1 illustrates reference point CTRL1a, which is related to the activation/deactivation of URA.

Reference Point **CTRL1a** is an interface between MPM and RCM, through which MPM requests RCM to perform the activation/deactivation of a URA, and receives a response from RCM.

5.5 Reference Points required for transferring context information




Figure 5.5-1: Illustration of reference points for context information transfer

Figure 5.5-1 illustrates reference point CII, which is related to the transfer of context information.

Reference Point **CII** is an interface between Monitor and RC in the URA, through which Monitor requests RC in URA to send context information and receives a response (i.e. the context information), from RC in the URA.

Explanation: The context information is generated from corresponding functional block(s) of URA and transferred to RC which, in turn, transfer it to Monitor upon request.

Note that CII is an interface between Monitor in the CSL and RC part in the URA as shown in Figure 5.5-1. While functional blocks in the Radio Application code are loaded as the URA for real-time processing, the RC part in the Radio Application code is loaded at the same level where the Monitor is located because the interaction between RC and Monitor is executed in non real-time. Consequently, CII does not break the interface hierarchy defined in the present document.

5.6 Reference Points required for creating data flow and sending/receiving user data




Figure 5.6-1: Illustration of reference points for creating data flow and sending/receiving user data

Figure 5.6-1 illustrates reference points CTRL1b, CTRL2, DCTRL1, DCTRL2, and DCTRL3, which are used for creating data flow and for sending and receiving user data as follows:

- Reference Point **CTRL1b** is an interface between MPM and RCM, through which MPM requests RCM to create a data flow or a network association with a peer equipment and receives a response from RCM.
- Reference Point **CTRL2** provides interaction between RCM and FC, which is used together with CTRL1b for creating a data flow.
- Reference Point **DCTRL1** is an interface between FC and Networking Stack, through which FC receives/transfers user data from/to Networking stack for the procedure of sending/receiving data. When Networking Stack sends data, the FC can optionally send back an acknowledgement at the end of transmission.
- Reference Point **DCTRL2** is an interface between FC and URA, through which FC transfers user data to URA and requests URA to transfer information related to user data (such as throughput, data bandwidth, etc.) to FC. Through the same interface the FC can also receive data from URA, i.e. user data (data reception) or user data information upon request (and before actual data transmission).
- Reference Point **DCTRL3** is an interface between URA and RF transceiver, through which URA receives/transmits user data from/to RF transceiver.

5.7 Reference Points required for radio environment measurements




Figure 5.7-1: Illustration of reference points for radio environment measurements

Figure 5.7-1 illustrates reference point CTRL1c, which is related to the radio environment measurements.

Reference Point **CTRL1c** is an interface between MPM and RCM, through which MPM requests RCM to start/stop measurements for radio environment and receives a response from RCM.

5.8 Reference Points required for reporting discovered peer equipment




Figure 5.8-1: Illustration of reference points for reporting discovered peer equipment

Figure 5.8-1 illustrates reference point CTRL3, which is related to reporting discovered peer equipment.

Reference Point **CTRL3** is an interface between RCM and URA, through which RCM requests URA to report discovered peer equipment and receives a response (i.e. Information about discovered peer equipment) from URA.

5.9 Reference Points required for flexible data flow




Figure 5.9-1: Illustration of reference points for flexible data flow

- Figure 5.9-1 illustrates reference point CTRL1d, which is related to the flexible data flow.
- Reference Point **CTRL1d** is an interface between MPM and RCM, through which MPM requests RCM to move/partition/combine data flow and receives a response from RCM.

5.10 Reference Points required for data flow control




Figure 5.10-1: Illustration of reference points for data flow control

Figure 5.10-1 illustrates reference point CTRL4 and CTRL5, which are related to the data flow control.

Reference Point **CTRL4** is an interface between FC and N/W stack, through which FC requests N/W stack to change the configuration of data flow and receives a response from N/W stack. Reference Point **CTRL5** is an interface between URA and FC, through which URA requests FC to change the configuration of data flow and receives a response from FC.

5.11 Reference Points required for synchronizing radio time




Figure 5.11-1: Illustration of reference points for synchronizing radio time

Figure 5.11-1 illustrates reference point CTRL6, which is related to the synchronizing radio time.

Reference Point **CTRL6** is an interface between MRC and URA, through which MRC requests URA to get synchronizing radio time and receives a response (i.e. synchronized radio time) from URA.

5.12 Reference Points required for control of reconfigurable RF transceiver




Figure 5.12-1: Illustration of reference points for spectrum control services

Figure 5.12-1 illustrates reference point CTRL7a, which is related to the spectrum control services.

Reference Point **CTRL7a** is an interface between URA and RF transceiver, through which URA requests RF transceiver to set up centre frequency/bandwidth/sampling rate and receives a response from RF transceiver.

Reference Point **CTRL7a** is an interface between URA and RF transceiver, through which URA requests RF transceiver to get Tx/Rx chain parameters and receives a response (i.e. the Tx/Rx chain parameters) from RF transceiver.




Figure 5.12-2: Illustration of reference points for power control services

Figure 5.12-2 illustrates reference point CTRL7b, which is related to the power control services.

Reference Point **CTRL7b** is an interface between URA and RF transceiver, through which URA requests RF transceiver to set up maximum transmit power/antenna power/rx gain and receives a response from RF transceiver.




Figure 5.12-3: Illustration of reference points for antenna management services

Figure 5.12-3 illustrates reference point CTRL7c, which is related to the antenna management services.

Reference Point **CTRL7c** is an interface between URA and RF transceiver, through which URA requests RF transceiver to select tx/rx antenna port and receives a response from RF transceiver.




Figure 5.12-4: Illustration of reference points for chain control services

Figure 5.12-4 illustrates reference point CTRL7d, which is related to the chain control services.

Reference Point **CTRL7d** is an interface between URA and RF transceiver, through which URA requests RF transceiver to set start&stop time for transmission/reception, and receives a response from RF transceiver.

Reference Point **CTRL7d** is an interface between URA and RF transceiver, through which URA requests RF transceiver to update chain parameters and receives a response from RF transceiver.




Figure 5.12-5: Illustration of reference points for RVM protection services

Figure 5.12-5 illustrates reference point CTRL7e, which is related to the RVM protection services.

Reference Point **CTRL7e** is an interface between URA and RF transceiver, through which URA requests RF transceiver to select RF protection class and receives a response from RF transceiver.

Reference Point **CTRL7e** is an interface between URA and RF transceiver, through which URA requests RF transceiver to change of RF protection class and receives a response from RF transceiver.

Reference Point **CTRL7e** is an interface between URA and RF transceiver, through which URA requests RF transceiver to get RF protection class status, information on data modification by RF protection, information on cross RAT interference by RF protection, emergency switch off of RF front-end, and receives a response from RF transceiver.

5.13 Reference points required for security functions

Figures 5.13-1 to 5.13-4 illustrate the required reference points for each security functions.




Figure 5.13-1: Illustration of reference points for protection of RE Configuration Policy, RAP, and other assets




Figure 5.13-2: Illustration of reference points for protection of configuration enforcement commands




Figure 5.13-3: Illustration of reference points for remote attestation




Figure 5.13-4: Illustration of reference points for long-term management

The reference points are defined as follows:

- Reference Point **RRS-sec-1**: indirect interactions between the ASF and Asset Endorsement Functions for the validation of the RE Configuration Policy, RAP, and other assets (signature verification).
- Reference Point **RRS-sec-2**: direct interactions between the ASF and the RadioApp Store for communication security.
- Reference Point **RRS-sec-3**: direct interactions between the ASF and Command Security Functions for the validation of configuration enforcement commands.
- Reference Point **RRS-sec-4**: direct interactions between the ASF and the Verifying Entity for remote attestation.
- Reference Point **RRS-sec-5**: offline provisioning of secrets by the manufacturer into the Hardware Root of Trust.
- Reference Point **RRS-sec-6**: direct interactions between the RRS-CM and the ASF (providing access to security functions).

- Reference Point **RRS-sec-7**: direct interactions between the RRS-CA and the RRS-CM for transfer of authority and designation of the RRS-CP.
- Reference Point **RRS-sec-8**: direct interactions between the RRS-CP and the RRS-CM for provisioning of the RRS Configuration Profile.

6 Reconfigurable RE high level operating procedures

6.0 Introduction

In this clause, sequence diagrams are introduced which cover unicast, multicast and broadcast routing between CSL and Radio Computer(s). In order to differentiate these three types of identifiers, the following generic representation is used: RC_x, where "x" indicates the transmission mode including unicast (x=U), multicast (x=M), and broadcast (x=B).

Furthermore, in the sequence diagrams below, the data packets from/to CSL contain the URA ID which is used to identify the target URA (for information flow from CSL towards URA) / source URA (for information flow from URA towards CSL).

6.1 Procedures for installation/uninstallation and creating/deleting instance of a URA

Figure 6.1-1 illustrates a signalling diagram associated with the installation and uninstallation of a URA.

- In case of installation failure, CM reports to Administrator the failure of URA installation using an *InstallRAFailCnf* signal including RAP (P1) ID, radio computer (RC1) ID and failure reason via routing entity.

The procedure for the uninstallation is shown in Figure 6.1-1 and it can be summarized as follows:

- Administrator transfers an *UninstallRReq* signal including the ID of the URA (R1) to be uninstalled and radio computer ID corresponding to RC_x to routing entity.
- Routing entity transfers the *UninstallRReq* signal to CM in the target radio computer (RC1) based on radio computer ID.
- CM sends the *UninstallRReq* signal including URA (R1) ID to FM.
- FM performs the uninstallation of URA and sends back an *UninstallRACnf* signal including the URA (R1) ID to CM.
- CM sends the *UninstallRACnf* signal including URA (R1) ID and radio computer (RC1) ID to Administrator via routing entity.

Figure 6.1-2 illustrates a signalling diagram showing the procedure of creation and deletion of an instance of a URA.




Figure 6.1-2: URA creation and deletion

The procedure related to the creation of an instance of an URA can be summarized as follows:

- For creating an instance of an installed URA, Administrator transfers an *InstantiateRAReq* signal including the ID of the URA (R1) to be instantiated and the ID of radio computer corresponding to RC_x to routing entity.
- Routing entity transfers the *InstantiateRAReq* signal to CM in the target radio computer (RC1) based on radio computer ID.
- CM transfers an *RMPParameterReq* signal and an *MRCParameterReq* signal including the ID of the URA (R1) in order to get the parameters needed for URA activation (e.g. Forward Error Correction (FEC) parameters, MIMO parameters, bandwidth, etc.) to RM and MRC.
- CM receives an *RMPParameterCnf* signal including the ID of the URA (R1) and radio resource parameters from RM.
- CM receives an *MRCParameterCnf* signal including the ID of the URA (R1) and computational resource parameters from MRC.
- CM transfers URA (R1) ID, radio computer (RC1) ID and the received parameters for performing the URA instantiation to ROS.
- After creating an instance, CM transfers an *InstantiateRACnf* signal including URA (R1) ID and radio computer (RC1) ID to Administrator via routing entity.
- If CM fails to get parameters needed for URA activation from RM and/or MRC, RM and/or MRC reports the failure of parameters transfer to CM using an *RMPParameterFailCnf* and/or *MRCParameterFailCnf* signal respectively. In this case CM transfers an *InstantiateRAFailCnf* signal including URA (R1) ID, radio computer (RC1) ID to routing entity and the reasons for instantiation failure.
- Routing entity transfers the *InstantiateRAFailCnf* signal to Administrator.

The procedure for deleting an instance of an URA can be summarized as follows:

- Administrator transfers the ID of the URA (R1) to be deleted and the ID of the radio computer corresponding to RC_x using a *DeInstantiateRAReq* signal to routing entity.
- Routing entity transfers the *DeInstantiateRAReq* signal to CM in radio computer (RC1) based on radio computer ID.
- Upon request from CM ROS deletes the instance of the designated URA.
- CM acknowledges the completion of the procedure sending a *DeInstantiateRACnf* signal to Administrator via routing entity.

Figure 6.1-3 illustrates in more details the security mechanisms involved during RAP provisioning and installation, in particular before the *DownloadRAPReq* and *InstallRAReq* signals as illustrated by Figure 6.1-1.




Figure 6.1-3: Signalling diagram for RAP endorsement, distribution and validation

The procedure can be summarized as follows:

- The RAP is assembled by the RAP Provisioning Entity (e.g. a Software Manufacturer).
- The RAP is submitted by the RAP Provisioning Entity to the RAP Endorsement Function (a specialization of the Asset Endorsement Functions) via the *EndorseRAPReq()* signal.
- The RAP Endorsement Functions signs the RAP via the reflexive *SignRAP()* signal.
- The RAP Provisioning Entity receives a *EndorseRAPCnf()* signal confirming successful endorsement (signature) of the RAP.
- The RAP Provisioning Entity sends a *PublishRAPReq()* signal to the RadioApp Store for publication of the RAP.
- The RadioApp Store sends a *PublishRAPCnf()* signal to the RAP Provisioning Entity, confirming that the RAP is published and available for download by Reconfigurable REs.
- The RadioApp Store and the Administrator on the Reconfigurable RE mutually authenticate each other. On the Reconfigurable RE this is done through an exchange of *RAppStoreAuthReq()* and *RAppStoreAuthCnf()* signals between the Administrator and the Administrator Security Function.
- The RadioApp Store may filter the set of available RAPs into a subset suitable for the Reconfigurable RE.

- The Administrator sends a *DownloadRAPReq()* signal to the RadioApp Store in order to download an RAP.
- The RadioApp Store sends a *DownloadRAPCnf()* signal to the Administrator.
- The Administrator sends a *ValidateRAPReq()* signal to the Administrator Security Function in order to verify the digital signature of the RAP. The verification operation is illustrated by the reflexive *CheckRAP()* signal:
 - Upon failure the Administrator Security Function sends a *ValidateRAPFail()* signal to the Administrator and the procedure is aborted.
 - Upon success the Administrator Security Function sends a *ValidateRAPCnf()* signal to the Administrator.
- The Administrator sends a *InstalRARReq()* signal including radio computer ID corresponding to RC_x to the routing entity.
- The routing entity transfers the *InstalRARReq()* signal to the Configuration Manager in the Radio Control Framework of the radio computer (RC1) and the installation procedure continues (refer to Figure 6.1-1).

NOTE: The upper procedure covers integrity and authentication of RAPs at installation time. Run-time integrity verification is out of scope of the present document and left as an implementation choice.

6.2 Procedures for list checking of URA

6.2.0 General

Figure 6.2.0-1 illustrates a signalling diagram related to the list checking of URA.





Figure 6.2.0-1: URA list checking

The procedure can be summarized as follows:

- Administrator or MPM transfers a *ListRARReq* signal including radio computer ID corresponding to RC_x to routing entity.
- Routing entity transfers the *ListRARReq* signal to CM in the radio computer (RC1) based on radio computer ID for obtaining the URA list.
- CM transfers the URA list information to Administrator or MPM using an *RAList* signal via routing entity.

6.2.1 Procedures for updating instance of URA

Figure 6.2.1-1 illustrates a signalling diagram related to updating instance of URA.






Figure 6.2.1-1: Updating instance of URA

NOTE 1: The upper procedure assumes that the internal structure of a functional block (i.e. either SFB or UDFB) is modified while the external inputs/outputs of the functional block as well as their connection to other functional blocks remain unchanged.

The procedure can be summarized as follows:

- For updating instance of (part of) URA, Administrator transfers an *UpdateRAReq* signal including the ID of the URAs (R1, R2), the ID of the functional blocks (FB1, FB2), and radio computer corresponding to RC_x to routing entity.

NOTE 2: FB1 in URA R1 is updated to FB2 in URA R2.

- Routing entity transfers the *UpdateRAReq* signal to CM in the target radio computer (RC1) based on radio computer ID.
- CM acquires configuration parameters of the functional block (FB1) in URA (R1) by *AcqConfParams*.
- Upon request from CM, ROS deletes the instance of the designated URA based on the URA (R1) ID.
- For creating an instance of an installed (part of) URA, CM transfers an *RMPParameterReq* signal and an *MRCParameterReq* signal including the ID of the URA (R2), and the ID of the functional block (FB2) in order to get the parameters needed for URA activation (e.g. Forward Error Correction (FEC) parameters, MIMO parameters, bandwidth, etc.) to RM and MRC.
- CM receives an *RMPParameterCnf* signal including the ID of the URA (R2), the ID of the functional block (FB2) and radio resource parameters from RM.
- CM receives an *MRCParameterCnf* signal including the ID of the URA (R2), the ID of the functional block (FB2) and computational resource parameters from MRC.

- CM transfers the ID of the URAs (R1, R2) ID, the ID of the functional blocks (FB1, FB2), radio computer (RC1) ID and the received parameters for performing the URA instantiation to ROS.
- After creating an instance, CM transfers an *UpdateRACnf* signal including URAs (R1, R2) ID, functional blocks (FB1, FB2) ID, and radio computer ID corresponding to RC_x to Administrator via routing entity.
- Routing entity transfers the *UpdateRACnf* signal to Administrator.
- If CM fails to get parameters needed for URA activation from RM and/or MRC, RM and/or MRC reports the failure of parameters transfer to CM using an *RMPParameterFailCnf* and/or *MRCParameterFailCnf* signal respectively. In this case CM transfers an *InstantiateRAFailCnf* signal including URA (R2) ID, functional block (FB2) ID, and radio computer (RC2) ID to routing entity and the reasons for instantiation failure.
- Routing entity transfers the *InstantiateRAFailCnf* signal to Administrator.

6.2.2 Procedures for configuring URA parameters

Figure 6.2.2-1 illustrates a signalling diagram related to configuring URA parameters.




Figure 6.2.2-1: Configuring URA parameters

The procedure can be summarized as follows:

- Administrator transfers a *ConfRAParamsReq* signal including parameters, the ID of the URA (R1) and radio computer ID according to RC_x to routing entity.
- Routing entity transfers the *ConfRAParamsReq* signal to CM in the radio computer (RC1) based on radio computer ID.
- Upon request from CM, ROS transfers the parameters to the designated URA.
- After URA is reconfigured, CM sends *ConfRAParamsCnf* including the ID of the URA (R1) and radio computer according to RC_x to routing entity.
- Routing entity transfers the *ConfRAParamsCnf* signal to Administrator in the radio computer (RC1) based on radio computer ID.
- If URA reconfiguration is failed, CM reports the failure to Administrator by transferring the failed URA (R1) ID and failure reason in the *ActivateFailCnf* signal via routing entity.

6.3 Procedures for activation/deactivation of URA

Figure 6.3-1 illustrates a signalling diagram related to the activation of an URA.




Figure 6.3-1: URA Activation

The procedure can be summarized as follows:

- MPM transfers an *ActivateReq* signal including the ID of the URA (R1) and radio computer ID corresponding to RC_x to routing entity.
- Routing entity transfers the *ActivateReq* signal to RCM in the radio computer (RC1) based on radio computer ID.
- Upon request from RCM, ROS activates the designated URA.
- After ROS completes the activation of the URA, RCM sends back to MPM an *ActivateCnf* signal via routing entity.
- If URA activation is failed, RCM reports the failure to MPM by transferring the failed URA (R1) ID and failure reason in the *ActivateFailCnf* signal via routing entity.

Figure 6.3-2 illustrates a signalling diagram related to the deactivation of an URA.




Figure 6.3-2: URA deactivation

The procedure can be summarized as follows:

- In case of hard deactivation, MPM transfers an *HardDeactivateReq* signal including the ID of the URA (R1) and radio computer ID corresponding to RC_x to deactivate to routing entity.
- Routing entity transfers the *HardDeactivateReq* signal to RCM in the radio computer (RC1) based on radio computer ID.
- Upon request from RCM, ROS deactivates the designated URA.
- After ROS completes the hard deactivation of the URA, RCM acknowledges the completion of the procedure by sending an *HardDeactivateCnf* signal to MPM via routing entity.
- In case of soft deactivation, MPM transfers a *SoftDeactivateReq* signal including the ID of the URA (R1) and radio computer (RC1) ID to routing entity.
- Routing entity transfers the *SoftDeactivateReq* signal to RCM in the radio computer (RC1) based on radio computer ID.
- Upon request from RCM, ROS deactivates the designated URA.
- After ROS completes the soft deactivation of the URA, RCM acknowledges the completion of the procedure by sending a *SoftDeactivateCnf* signal to MPM via routing entity.

6.4 Procedures for transferring context information

Figure 6.4-1 illustrates a signalling diagram related to the transfer of context information.




Figure 6.4-1: Context information transfer

The procedure can be summarized as follows:

- Monitor transfers a *ContextInformationReq* signal including URA (R1) ID to RC in URA.
- RC in URA transfers a *ContextInformation* signal including URA (R1) ID and context information (ConInf) generated in corresponding functional block(s) in URA to Monitor.
- In the case of using a Baseband Parameter Aggregation (BPA) unit ETSI TR 102 944 [i.2], RC in URA transfers the *ContextInformation* signal including URA (R1) ID and context information (ConInf) to BPA unit. Then the BPA unit aggregates and compresses the context information in order to minimize the bandwidth occupied by the context information to be transferred. Upon completion of the procedure of context information aggregation and compression, BPA unit transfers an *AggregatedMetric* signal including URA (R1) ID and aggregated metric(s) (Metric) to Monitor.
- In the case of generating context information failure, RC in URA transfers a *ContextInformationFailCnf* signal including to URA (R1) ID and failure reason to Monitor.

6.5 Procedure for creating data flow and sending/receiving user data

Figure 6.5-1 illustrates a signalling diagram related to the creation of a network association.




Figure 6.5-1: Creation of a network association

The procedure can be summarized as follows:

- MPM transfers an *AssociateReq* signal including URA (R1) ID, peer equipment (E1) ID and radio computer ID corresponding to RC_x to routing entity.
- Routing entity transfers the *AssociateReq* signal to RCM in the radio computer (RC1) based on radio computer ID, where the peer equipment might be Wireless Local Area Network (WLAN) access point(s), Internet Protocol (IP) access node(s) (such as Gateway General Packet Radio Service (GPRS) Support Node (GGSN), etc.) in cellular networks, or Bluetooth® headset, digital radio/television broadcasting station(s), Global Positioning System (GPS) satellite(s), etc.
- Upon request from RCM for ROS to create a network association, ROS transfers the *AssociateReq* signal from RCM to URA. Then, URA transfers the ID of corresponding peer equipment (E1) using a *NetAssociateReq* signal.
- Upon completion of the network association creation, peer equipment transfers a *NetAssociateCnf* signal to URA. Then ROS transfers an *AssociateCnf* signal to RCM, which, in turn, transfers it to routing entity, and routing entity then transfers it to MPM.

- Upon transferring the *LogicalRadioLinkCnf* signal from peer equipment to URA, ROS transfers a *CreateDataFlowCnf* signal including network association (N1) ID and URA (R1) ID to RCM. After RCM receives *CreateDataFlowCnf*, RCM creates link (L) ID.
- In order to set up a data flow, RCM transfers a *CreateFlowReq* signal including network association (N1) ID and URA (R1) ID to FC. After creating the data flow, FC transfers a *CreateFlowCnf* signal including network association (N1) ID, URA (R1) ID, and the other RE user (U2) ID to RCM and transfers a *DataFlow* signal including data flow (F1) ID and radio computer (RC1) ID to Networking Stack via routing entity.
- RCM transfers the *CreateDataFlowCnf* signal including network association (N1) ID, URA (R1) ID, the other RE user (U2) ID, link (L) ID, and radio computer (RC1) ID to MPM via routing entity.
- In case of failure, when URA receives a *LogicalRadioLinkRej* signal from the peer equipment, ROS transfers a *CreateDataFlowFailCnf* signal including network association (N1) ID, radio computer (RC1) ID and failure reason to RCM, which transfers it to MPM to acknowledge the failure of creating the data flow via routing entity.

Figure 6.5-3 illustrates a signalling diagram related to the creation of a logical radio link association initiated Radio Equipment 2 (RE2).




Figure 6.5-3: Creation of a logical radio link association initiated by Radio Equipment 2 (RE2)

The procedure can be summarized as follows:

- Network transfers a *LogicalRadioLinkReq* signal including user (U1) ID, the other RE user (U2) ID, and peer equipment (E1) ID to peer equipment.
- Upon transferring the *LogicalRadioLinkReq* signal including user (U1) ID and the other RE user (U2) ID from peer equipment to URA, URA requests ROS to create a data flow using the *CreateDataFlowReq* signal including peer equipment (E1) ID, active URA (A1) ID, user (U1) ID and the other RE user (U2) ID.

- Upon transferring the *CreateDataFlowReq* signal from URA to RCM, RCM creates link (L) ID. After RCM creates link (L) ID, ROS transfers a *CreateDataFlowCnf* signal including network association (N1) ID and URA (R1) ID to URA.
- In order to set up a data flow, RCM transfers a *CreateFlowReq* signal including network association (N1) ID and URA (R1) ID to FC. After creating the data flow, FC transfers a *CreateFlowCnf* signal including network association (N1) ID, URA (R1) ID, created data flow (F1) ID, and radio computer ID corresponding to RC_x to RCM and transfers a *DataFlow* signal including data flow (F1) ID to Networking Stack via routing entity.
- RCM transfers the *CreateDataFlowCnf* signal including network association (N1) ID, URA (R1) ID, the other RE user (U2) ID link (L) ID, and radio computer (RC1) ID to MPM via routing entity.
- In case of failure for creation of a logical radio link association, ROS transfers a *CreateDataFlowFailCnf* signal including network association (N1) ID, radio computer (RC1) ID and failure reason to URA and RCM transfers it to MPM to acknowledge the failure of creating the data flow via routing entity. URA transfers *LogicalRadioLinkRej* to peer equipment (E1) and upon receiving the *LogicalRadioLinkRej* signal, the Network transfers a *LogicalRadioLinkRej* signal to the other RE.

Figure 6.5-4 illustrates a signalling diagram of sending data.




Figure 6.5-4: Signalling Diagram of sending data

The procedure can be summarized as follows:

- Networking stack transfers a *SendUserDataReq* signal together with data flow (F1) ID, radio computer ID corresponding to RC_x and user data to routing entity.
- Routing entity transfers the *SendUserDataReq* signal to FC in the radio computer (RC1) based on radio computer ID in order to send user data.
- Upon receiving the *SendUserDataReq* signal including data flow (F1) ID and user data, FC transfers a *SendDataReq* signal together with data flow (F1) ID and user data to URA.

- URA transfers data flow (F1) ID, RF transceiver (T1) ID, and user data using a *TransmitData* signal to RF transceiver.
- Upon completion of sending data, URA sends back to FC a *SendDataCnf* signal including data flow (F1) ID as an acknowledgement.
- Upon receiving the *SendDataCnf* signal, FC transfers a *SendUserDataCnf* signal together with data flow (F1) ID and radio computer (RC1) ID to routing entity.
- Routing entity transfers the *SendUserDataCnf* signal to Networking stack.
- In the case of data transfer failure, URA reports the failure of sending data to FC by transferring a *SendDataFailCnf* signal including data flow (F1) ID and reason of the failure.
- Upon receiving the *DataFailCnf* signal, FC transfers a *SendUserDataFailCnf* signal together with data flow (F1) ID and radio computer (RC1) ID to routing entity.
- Routing entity transfers the *SendUserDataFailCnf* signal to Networking stack.

Figure 6.5-5 illustrates a signalling diagram related to data receiving.




Figure 6.5-5: Signalling diagram of receiving data

The procedure can be summarized as follows:

- Networking stack transfers a *ReceiveUserDataReq* signal together with data flow (F1) ID and radio computer ID corresponding to RC_x to routing entity.
- Routing entity transfers the *ReceiveUserDataReq* signal to FC in the radio computer (RC1) based on radio computer ID in order to receive user data.
- Upon receiving the *ReceiveUserDataReq* signal including data flow (F1) ID, FC transfers a *ReceiveDataReq* signal together with data flow (F1) ID to URA.
- URA transfers data flow (F1) ID and RF transceiver (T1) ID using a *ReceiveDataReq* signal to RF transceiver.
- RF transceiver transfers *ReceiveData* including data flow (F1) ID and user data to URA.
- URA transfers a *Data* signal including data flow (F1) ID and user data to FC after receiving the data from RF transceiver.

- FC transfers a *UserData* signal including data flow (F1) ID, radio computer (RC1) ID and user data received from URA to Networking stack via routing entity.

6.6 Procedures for radio environment measurements

Figure 6.6-1 illustrates a signalling diagram related to the radio environment measurements.




Figure 6.6-1: Radio environment measurements

The procedure can be summarized as follows:

- MPM transfers a *StartStopRadioMeasurementsReq* signal including URA (R1) ID, radio computer ID corresponding to RC_x and start/stop configuration to routing entity.
- Routing entity transfers the *StartStopRadioMeasurementsReq* signal to RCM in the radio computer (RC1) based on radio computer ID.
- Then, RCM transfers a *StartStopRadioMeasurementsReq* including URA (R1) ID and start/stop configuration (StartStop) to URA.
- Upon completion of the start/stop radio environment measurement, URA transfers a *StartStopRadioMeasurementsCnf* signal including URA (R1) ID, start/stop configuration (StartStop), and radio measurement to RCM.
- Then, RCM transfers a *StartStopRadioMeasurementsCnf* signal including URA (R1) ID, radio computer (RC1) ID, start/stop configuration (StartStop), and radio measurement (RadioEnv) to MPM via routing entity.

- In the case of the start/stop radio environment measurement failure, URA transfers a *Start/StopRadioMeasurementsFailCnf* signal including URA (R1) ID, start/stop configuration (StartStop), and failure reason to RCM. Then, RCM transfers a *Start/StopRadioMeasurementsFailCnf* signal including URA (R1) ID, radio computer (RC1) ID, start/stop configuration (StartStop), and failure reason to MPM via routing entity.

6.7 Procedure for reporting discovered peer equipment

Figure 6.7-1 illustrates a signalling diagram related to report discovered peer equipment.




Figure 6.7-1: Report of discovered peer equipment

The procedure can be summarized as follows:

- Peer equipment transfers a *AssociationFeasibilityMessage* signal including peer equipment (E1) ID to URA.
- RCM transfers a *ReportPeerEquipmentsReq* signal including URA (R1) ID to URA.
- URA transfers a *InformationPeerEquipments* signal including URA (R1) ID and peer equipment (E1) ID to RCM.
- RCM transfers a *InformationPeerEquipments* signal including URA (R1) ID, radio computer ID corresponding to RC_x and peer equipment (E1) ID to MPM via routing entity.

6.8 Procedure for flexible data flow

Figure 6.8-1 illustrates a signalling diagram related to the flexible data flow.




Figure 6.8-1: Flexible data flow

The procedure can be summarized as follows:

- MPM transfers a *ChangeDataFlowReq* signal including URA (R1) ID, radio computer ID corresponding to RC_x, active URA (A1) ID, data flow 1 (F1) ID, action configuration such as move/partition/combine of the data flow (Action), and computational resource parameters (Param) to routing entity.
- Routing entity transfers the *ChangeDataFlowReq* signal to RCM in the radio computer (RC1) based on radio computer ID.
- RCM transfers a *ChangeDataFlowReq* signal including URA (R1) ID, active URA (A1) ID, data flow 1 (F1) ID, action configuration (Action), and computational resource parameters (Param) to URA.
- Upon completion of changing data flow, URA transfers a *ChangeDataFlowCnf* signal including URA (R1) ID, active URA (A1) ID, data flow 1 (F1) ID, action configuration (Action), and computational resource parameters (Param) to RCM. Then, RCM transfers *ChangeDataFlowCnf* signal including URA (R1) ID, radio computer (RC1) ID, active URA (A1) ID, data flow 1 (F1) ID, action configuration (Action), and computational resource parameters (Param) to MPM via routing entity.
- In the case of changing data flow failure, URA transfers a *ChangeDataFlowFailCnf* signal including URA (R1) ID, active URA (A1) ID, data flow 1 (F1) ID, action configuration (Action), and failure reason to RCM. Then, RCM transfers *ChangeDataFlowFailCnf* signal including URA (R1) ID, radio computer (RC1) ID, active URA (A1) ID, data flow 1 (F1) ID, action configuration (Action), and failure reason to MPM via routing entity.

6.9 Procedure for data flow control

Figure 6.9-1 illustrates a signalling diagram related to the data flow control.




Figure 6.9-1: Data flow control

The procedure can be summarized as follows:

- URA transfers a *ChangingDataFlowReq* signal including URA (R1) ID, data flow 1 (F1) ID, and data flow 2 (F2) ID to FC.
- FC transfers a *ChangingDataFlowReq* signal including URA (R1) ID, radio computer ID corresponding to RC_x, data flow 1 (F1) ID, and data flow 2 (F2) ID to Networking stack via routing entity.
- Upon completion of data flow configuration changes, Networking stack transfers a *ChangingDataFlowCnf* signal including URA (R1) ID, radio computer (RC1) ID according to RC_x, data flow 1 (F1) ID, and data flow 2 (F2) ID to routing entity.
- Routing entity transfers the *ChangingDataFlowCnf* signal to FC in the radio computer (RC1) based on radio computer ID.
- Then FC transfers a *ChangingDataFlowCnf* signal to URA.
- In the case of a data flow configuration changes failure, Networking stack transfers a *ChangingDataFlowFailCnf* signal including URA (R1) ID, radio computer (RC1) ID according to RC_x, data flow 1 (F1) ID, and data flow 2 (F2) ID to routing entity.
- Routing entity transfers the *ChangingDataFlowFailCnf* signal to FC in the radio computer (RC1) based on radio computer ID.
- Then FC transfers *ChangingDataFlowFailCnf* signal to URA.

6.10 Procedure for synchronizing radio time

Figure 6.10-1 illustrates a signalling diagram related to the synchronizing radio time.




Figure 6.10-1: Synchronizing radio time

The procedure can be summarized as follows:

- MRC transfers a *SynchronizeTimeReq* signal including URA1 (R1) ID, URA2 (R2) ID, and synchronize radio time (*t*) to URA1 and URA2.
- Upon completion of synchronizing radio time at both URA1 and URA2, URA1 transfers a *SynchronizeTimeCnf* signal including URA1 (R1) ID and synchronize radio time (*t*) to MRC. Then URA 2 transfers a *SynchronizeTimeCnf* signal including URA2 (R2) ID and synchronize radio time (*t*) to MRC.
- In the case of completion of synchronizing radio time at URA1 and failure of synchronizing radio time at URA2, URA1 transfers a *SynchronizeTimeCnf* signal including URA1 (R1) ID and synchronize radio time (*t*) to MRC. Then URA 2 transfers a *SynchronizeTimeFailCnf* signal including URA2 ID, synchronize radio time (*t*), and failure reason to MRC.

- In the case of failure of synchronizing radio time at URA1 and completion of synchronizing radio time at URA2, URA1 transfers a *SynchronizeTimeFailCnf* signal including URA1 (R1) ID, synchronize radio time (t), and failure reason to MRC. Then URA 2 transfers a *SynchronizeTimeCnf* signal including URA2 (R2) ID and synchronize radio time (t) to MRC.
- In the case of failure of synchronizing radio time at URA1 and failure of synchronizing radio time at URA2, URA1 transfers a *SynchronizeTimeFailCnf* signal including URA1 (R1) ID, synchronize radio time (t), failure reason to MRC. Then URA 2 transfers a *SynchronizeTimeFailCnf* signal including URA2 (R2) ID, synchronize radio time (t), failure reason to MRC.

6.11 Procedure for control of reconfigurable RF transceiver

Figure 6.11-1 illustrates a signalling diagram related to the spectrum control services.




Figure 6.11-1: Spectrum control services

The procedure can be summarized as follows:

- In the case of request of centre frequency, URA transfers a *CentreFreqSetupReq* signal including URA (R1) ID, RF transceiver (T1) ID, and centre frequency parameter to RF transceiver.
- Upon completion of request of centre frequency, URA transfers a *CentreFreqSetupCnf* signal including URA (R1) ID, RF transceiver (T1) ID, and centre frequency parameter to RF transceiver.
- In the case of request of centre frequency failure, URA transfers a *CentreFreqSetupCnf* signal including URA (R1) ID, RF transceiver (T1) ID, and failure reason to RF transceiver.

- In the case of request of bandwidth, URA transfers a *BWSetupReq* signal including URA (R1) ID, RF transceiver (T1) ID, and bandwidth parameter to RF transceiver.
- Upon completion of request of bandwidth, URA transfers a *BWSetupCnf* signal including URA (R1) ID, RF transceiver (T1) ID, and bandwidth parameter to RF transceiver.
- In the case of request of centre frequency failure, URA transfers a *BWSetupFailCnf* signal including URA (R1) ID, RF transceiver (T1) ID, and failure reason to RF transceiver.
- In the case of request of sampling rate, URA transfers a *SamplingRateSetupReq* signal including URA (R1) ID, RF transceiver (T1) ID, and sampling rate parameter to RF transceiver.
- Upon completion of request of sampling rate, URA transfers a *SamplingRateSetupCnf* signal including URA (R1) ID, RF transceiver (T1) ID, and sampling rate parameter to RF transceiver.
- In the case of request of sampling rate failure, URA transfers a *SamplingRateSetupFailCnf* signal including URA (R1) ID, RF transceiver (T1) ID, and failure reason to RF transceiver.
- In the case of request of Tx Chain Parameters, URA transfers a *TxChainParametersGettingReq* signal including URA (R1) ID, RF transceiver (T1) ID, and chain parameter to RF transceiver.
- Upon completion of request of Tx Chain Parameters, URA transfers a *TxChainParametersGettingCnf* signal including URA (R1) ID, RF transceiver (T1) ID, and chain parameter to RF transceiver.
- In the case of request of Tx Chain Parameters failure, URA transfers a *TxChainParametersGettingFailCnf* signal including URA (R1) ID, RF transceiver (T1) ID, and failure reason to RF transceiver.
- In the case of request of Rx Chain Parameters, URA transfers a *RxChainParametersGettingReq* signal including URA (R1) ID, RF transceiver (T1) ID, and chain parameter to RF transceiver.
- Upon completion of request of Rx Chain Parameters, URA transfers a *RxChainParametersGettingCnf* signal including URA (R1) ID, RF transceiver (T1) ID, and chain parameter to RF transceiver.
- In the case of request of Rx Chain Parameters failure, URA transfers a *RxChainParametersGettingFailCnf* signal including URA (R1) ID, RF transceiver (T1) ID, and failure reason to RF transceiver.

Figure 6.11-2 illustrates a signalling diagram related to the power control services.




Figure 6.11-2: Power control services

The procedure can be summarized as follows:

- In the case of request of max tx power, URA transfers a *MaxTxPowerSetupReq* signal including URA (R1) ID, RF transceiver (T1) ID, and max tx power parameter to RF transceiver.
- Upon completion of request of max tx power, URA transfers a *MaxTxPowerSetupCnf* signal including URA (R1) ID, RF transceiver (T1) ID, and max tx power parameter to RF transceiver.
- In the case of request of max tx power failure, URA transfers a *MaxTxPowerSetupFailCnf* signal including URA (R1) ID, RF transceiver (T1) ID, and failure reason to RF transceiver.
- In the case of request of antenna power, URA transfers a *AntPowerSetupReq* signal including URA (R1) ID, RF transceiver (T1) ID, and antenna power parameter to RF transceiver.
- Upon completion of request of antenna power, URA transfers a *AntPowerSetupCnf* signal including URA (R1) ID, RF transceiver (T1) ID, and antenna power parameter to RF transceiver.
- In the case of request of antenna power failure, URA transfers a *AntPowerSetupFailCnf* signal including URA (R1) ID, RF transceiver (T1) ID, and failure reason to RF transceiver.

- In the case of request of rx gain, URA transfers a *RxGainSetupReq* signal including URA (R1) ID, RF transceiver (T1) ID, and rx gain parameter to RF transceiver.
- Upon completion of request of rx gain, URA transfers a *RxGainSetupCnf* signal including URA (R1) ID, RF transceiver (T1) ID, and rx gain parameter to RF transceiver.
- In the case of request of rx gain failure, URA transfers a *RxGainSetupFailCnf* signal including URA (R1) ID, RF transceiver (T1) ID, and failure reason to RF transceiver.

Figure 6.11-3 illustrates a signalling diagram related to the antenna management services.




Figure 6.11-3: Antenna management services

The procedure can be summarized as follows:

- In the case of request of antenna port selection, URA transfers a *AntPortSelectionReq* signal including URA (R1) ID, RF transceiver (T1) ID, Tx/Rx configuration, and antenna port parameter to RF transceiver.
- Upon completion of request of antenna port selection, URA transfers a *AntPortSelectionCnf* signal including URA (R1) ID, RF transceiver (T1) ID, Tx/Rx configuration, and antenna port parameter to RF transceiver.
- In the case of request of antenna port selection failure, URA transfers a *AntPortSelectionFailCnf* signal including URA (R1) ID, RF transceiver (T1) ID, Tx/Rx configuration, and failure reason to RF transceiver.

Figure 6.11-4 illustrates a signalling diagram related to the Tx/Rx chain control services.




Figure 6.11-4: Tx/Rx chain control services

The procedure can be summarized as follows:

- In the case of request of Tx/Rx start time, URA transfers a *Tx/RxStartTimeSetupReq* signal including URA (R1) ID, RF transceiver (T1) ID, Tx/Rx configuration, and time to RF transceiver.
- Upon completion of request of Tx/Rx start time, URA transfers a *Tx/RxStartTimeSetupCnf* signal including URA (R1) ID, RF transceiver (T1) ID, Tx/Rx configuration, and time to RF transceiver.
- In the case of request of Tx/Rx start time, URA transfers a *Tx/RxStartTimeSetupFailCnf* signal including URA (R1) ID, RF transceiver (T1) ID, Tx/Rx configuration, and failure reason to RF transceiver.
- In the case of request of Tx/Rx stop time, URA transfers a *Tx/RxStopTimeSetupReq* signal including URA (R1) ID, RF transceiver (T1) ID, Tx/Rx configuration, and time to RF transceiver.
- Upon completion of request of Tx/Rx stop time, URA transfers a *Tx/RxStopTimeSetupCnf* signal including URA (R1) ID, RF transceiver (T1) ID, Tx/Rx configuration, and time to RF transceiver.
- In the case of request of Tx/Rx start time, URA transfers a *Tx/RxStopTimeSetupFailCnf* signal including URA (R1) ID, RF transceiver (T1) ID, Tx/Rx configuration, and failure reason to RF transceiver.

- In the case of request of chain parameter update, URA transfers a *Tx/RxChainParamUpdateReq* signal including URA (R1) ID, RF transceiver (T1) ID, and computational resource parameters to RF transceiver.
- Upon completion of request of Tx/Rx stop time, URA transfers a *Tx/RxChainParamUpdateCnf* signal including URA (R1) ID, RF transceiver (T1) ID, and computational resource parameters to RF transceiver.
- In the case of request of Tx/Rx start time, URA transfers a *Tx/RxChainParamUpdateFailCnf* signal including URA (R1) ID, RF transceiver (T1) ID, and failure reason to RF transceiver.

Figure 6.11-5 illustrates a signalling diagram related to the RVM protection services.




Figure 6.11-5: RVM protection services

The procedure can be summarized as follows:

- In the case of request of RF protection class selection, URA transfers a *RFPProtectionClassSelectionReq* signal including URA (R1) ID, RF transceiver (T1) ID, and RF protection class parameters to RF transceiver.
- Upon completion of request of RF protection class selection, URA transfers a *RFPProtectionClassSelectionCnf* signal including URA (R1) ID, RF transceiver (T1) ID, and RF protection class parameters to RF transceiver.

- In the case of request of RF protection class selection, URA transfers a *RFProtectionClassSelectionFailCnf* signal including URA (R1) ID, RF transceiver (T1) ID, and failure reason to RF transceiver.
- In the case of request of RF protection class status, URA transfers a *RFProtectionClassStatusReq* signal including URA (R1) ID and RF transceiver (T1) ID to RF transceiver.
- Upon completion of request of RF protection class status, URA transfers a *RFProtectionClassStatusCnf* signal including URA (R1) ID, RF transceiver (T1) ID, and RF protection status to RF transceiver.
- In the case of request of RF protection class status, URA transfers a *RFProtectionClassStatusFailCnf* signal including URA (R1) ID, RF transceiver (T1) ID, and failure reason to RF transceiver.
- In the case of request of RF protection class change, URA transfers a *RFProtectionClassChangeReq* signal including URA (R1) ID, RF transceiver (T1) ID, RF protection class parameter1, and RF protection class parameter2 to RF transceiver.
- Upon completion of request of RF protection class change, URA transfers a *RFProtectionClassChangeCnf* signal including URA (R1) ID, RF transceiver (T1) ID, RF protection class parameter1, and RF protection class parameter2 to RF transceiver.
- In the case of request of RF protection class change, URA transfers a *RFProtectionClassChangeFailCnf* signal including URA (R1) ID, RF transceiver (T1) ID, and failure reason to RF transceiver.
- In the case of request of RF data modification information, URA transfers a *RFDataModificationInformReq* signal including URA (R1) ID, RF transceiver (T1) ID, RF data modification information to RF transceiver. Then, RF transceiver transfers a *RFDataModificationInform* signal including URA (R1) ID, RF transceiver (T1) ID, RF data modification information to URA.
- In the case of request of RF emergency off, URA transfers a *RFEmergencyOffReq* signal including URA (R1) ID and RF transceiver (T1) ID to RF transceiver. Then, RF transceiver transfers a *RFEmergencyOffReq* signal including URA (R1) ID and RF transceiver (T1) ID to URA.
- In the case of request of cross RAT interface information, URA transfers a *CrossRATInterfaceInformationReq* signal including URA (R1) ID, RF transceiver (T1) ID, and RAT to RF transceiver. Then, RF transceiver transfers a *CrossRATInterfaceInform* signal including URA (R1) ID, RF transceiver (T1) ID and RAT to URA.

6.12 Procedure for RE Configuration Policy endorsement, distribution and validation

Figure 6.12-1 illustrates the procedure for provisioning the RE Configuration Policy to the Reconfigurable RE.




Figure 6.12-1: Signalling diagram for RE Configuration Policy endorsement, distribution and validation

The procedure can be summarized as follows:

- The RE Configuration Policy is assembled by the RE Configuration Policy Provisioning Entity (e.g. the device manufacturer).
- The RE Configuration Policy is submitted by the RE Configuration Policy Provisioning Entity to the RE Configuration Policy Endorsement Function (a specialization of the Asset Endorsement Functions) via the *EndorseREConfPolReq()* signal.
- The RE Configuration Policy Endorsement Functions signs the RE Configuration Policy via the reflexive *SignREConfPol()* signal.
- The RE Configuration Policy Provisioning Entity receives a *EndorseREConfPolCnf()* signal confirming successful endorsement (signature) the RE Configuration Policy.
- The RE Configuration Policy Provisioning Entity sends a *PublishREConfPolReq()* signal to the RadioApp Store for publication of the RE Configuration Policy.
- The RadioApp Store sends a *PublishREConfPolCnf()* signal to the RE Configuration Policy Provisioning Entity, confirming that the RE Configuration Policy is published and available for download by Reconfigurable REs.
- The RadioApp Store and the Administrator on the Reconfigurable RE mutually authenticate each other. On the Reconfigurable RE this is done through an exchange of *RAppStoreAuthReq()* and *RAppStoreAuthCnf()* signals between the Administrator and the Administrator Security Function.
- The Administrator sends a *DownloadREConfPolReq()* signal to the RadioApp Store in order to download the RE Configuration Policy.
- The RadioApp Store sends a *DownloadREConfPolCnf()* signal to the Administrator.

- The Administrator sends a *ValidateREConfPolReq()* signal to the Administrator Security Function in order to verify the digital signature of the RE Configuration Policy. The verification operation is illustrated by the reflexive *CheckREConfPolSign()* signal:
 - Upon failure the Administrator Security Function sends a *ValidateREConfPolFail()* signal to the Administrator and the procedure is aborted.
 - Upon success the Administrator Security Function sends a *ValidateREConfPolCnf()* signal to the Administrator.
- The Administrator sends a reflexive *InstalREConfPolReq()* signal in order to install the RE Configuration Policy.

6.13 Procedure for configuration enforcement

Configuration enforcement is introduced in ETSI TS 103 436 [i.6], clause 10.

Figure 6.13-1 illustrates the procedure for sending a remote control command by a remote controller.




Figure 6.13-1: Signalling diagram for sending a remote control command

The procedure can be summarized as follows:

- The Remote Controller, a network entity that represents the sending party, first assembles a command message by sending a reflexive *AssembleCmdMsg()* signal.
- The Remote Controller encrypts the command message by sending a reflexive *EncryptCmdMsg()* signal.
- The encrypted command message is submitted by the Remote Controller to the Command Endorsement Function via an *EndorseCmdMsgReq()* signal.
- The Command Endorsement Function signs the encrypted command message via a reflexive *SignCmdMsg()* signal.

- The encrypted and signed command message is returned from the Command Endorsement Function to the Remote Controller via an *EndorseCmdMsgCnf()* signal.

NOTE: The procedure explicitly follows the best practice of separating the encryption and digital signature operations - in particular with regard to key material. It would also be valid to have the Command Endorsement Function perform these two operations sequentially if using different keys, an option which is not illustrated in the diagram above.

- The Remote Controller sends the encrypted and signed command message to the Administrator on the Reconfigurable RE via a *SendCmdMsgReq()* signal:
 - If the message distribution system provides a return channel, the Administrator may confirm reception of the command message via a *SendCmdMsgCnf()* signal.
- The Administrator sends a *ValidateCmdMsgReq()* signal to the Administrator Security Function in order to verify the digital signature of the command message. The verification operation is illustrated by the reflexive *CheckCmdMsg()* signal:
 - Upon failure the Administrator Security Function sends a *ValidateCmdMsgFail()* signal to the Administrator and the procedure is aborted.
 - Upon success the Administrator Security Function sends a *ValidateCmdMsgCnf()* signal to the Administrator.
- The Administrator request decryption of the command message by sending a *DecipherCmdMsgReq()* signal to the Administrator Security Function. The decryption operation is illustrated by the reflexive *DecipherCmdMsg()* signal.
- The Administrator Security Function returns the deciphered and previously validated command message to the Administrator via a *DecipherCmdMsgCnf()* signal.
- The Administrator processes the command message. This is illustrated by the reflexive *ProcessCmdMsg()* signal.

6.14 Procedures for long-term management

Long-term management is introduced in ETSI TS 103 436 [i.6], clause 11.

Figure 6.14-1 illustrates the transfer of authority between two RRS Configuration Authorities.




Figure 6.14-1: Signalling diagram for transferring authority between two RRS Configuration Authorities

The procedure can be summarized as follows:

- The future RRS Configuration Authority prepares its credentials via the reflexive *PrepareCredentials()* signal and requests a transfer of authority from the current RRS Configuration Authority via a *AuthorityTransferReq()* signal.
- The current RRS Configuration Authority verifies the validity of the transfer request via a reflexive *AuthorityTransferCheck()* signal:
 - Upon failure, the current RRS Configuration Authority sends an *AuthorityTransferReject()* signal and the procedure is aborted.
 - Upon success, the current RRS Configuration Authority prepares a Transfer of Authority Document (TAD) to the benefit of the future RRS Configuration Authority via the reflexive *PrepareTAD()* signal, and signs it via the reflexive *EndorseCA()* signal. The signed TAD is returned to the future RRS Configuration Authority via the *AuthorityTransferCnf()* signal.

NOTE 1: The steps described above should be viewed as a combination of administrative procedures between the two RRS Configuration Authorities, complemented by an electronic exchange protocol.

- The future RRS Configuration Authority indicates the transfer of authority to the Reconfigurable RE via an *InstallTADReq()* signal sent to the RRS Configuration Manager, providing the latter with the new, signed TAD.
- The RRS Configuration Manager verifies that the entity which signed the new TAD is the current RRS Configuration Authority via the reflexive *ConfigAuthorityCheck()* signal. This includes the verification of the complete chain of TADs.
- The RRS Configuration Manager sends a *VerifyRootTADReq()* signal to request verification of the root TAD by the Hardware Root of Trust.
- The Hardware Root of Trust verifies the root TAD via a reflexive *RootTADCheck()* signal:
 - Upon failure, the Hardware Root of Trust sends a *VerifyRootTADFail()* signal and the procedure is aborted.
 - Upon success, the Hardware Root of Trust sends a *VerifyRootTADCnf()* signal.
- The RRS Configuration Manager verifies the signature of the new TAD via the reflexive *TADCheck()* signal. Upon success the new TAD is installed, and the future RRS Configuration Authority, which so far was only a candidate from the point of view of the RRS Configuration Manager, effectively becomes the current RRS Configuration Authority.

Figure 6.14-2 illustrates the procedure for designating a legitimate RRS Configuration Provider RRS Configuration Authority.




Figure 6.14-2: Signalling diagram for designating a legitimate RRS Configuration Provider

The procedure can be summarized as follows:

- The candidate RRS Configuration Provider prepares its credentials via the reflexive *PrepareCredentials()* signal and requests validation of its status as a configuration provider from the current RRS Configuration Authority via a *ValidateConfigProviderReq()* signal.
- The current RRS Configuration Authority verifies the validity of the request via a reflexive *ConfigProviderCheck()* signal:
 - Upon failure, the current RRS Configuration Authority sends an *ValidateConfigProviderFail()* signal and the procedure is aborted.
 - Upon success, the current RRS Configuration Authority prepares a RRS Configuration Provider Profile (or completes the one provide by the RRS Configuration Provider) via the reflexive *PrepareCPProfile()* signal, and signs it via the reflexive *EndorseCP()* signal. The signed profile is returned to the RRS Configuration Provider via the *ValidateConfigProviderCnf()* signal.

NOTE 2: The steps described above should be viewed as a combination of administrative procedures between the RRS Configuration Provider and the RRS Configuration Authority, complemented by an electronic exchange protocol.

- The current RRS Configuration Authority indicates the new RRS Configuration Provider to the Reconfigurable Equipment via an *InstallCPPProfileReq()* signal sent to the RRS Configuration Manager, which provides the signed RRS Configuration Provider Profile.
- The RRS Configuration Manager verifies that the entity which signed the received RRS Configuration Profile is the current RRS Configuration Authority via the reflexive *ConfigAuthorityCheck()* signal. This includes the verification of the complete chain of TADs.
- The RRS Configuration Manager sends a *VerifyRootTADReq()* signal to request verification of the root TAD by the Hardware Root of Trust.
- The Hardware Root of Trust verifies the root TAD via a reflexive *RootTADCheck()* signal.
 - Upon failure, the Hardware Root of Trust sends a *VerifyRootTADFail()* signal and the procedure is aborted.
 - Upon success, the Hardware Root of Trust sends a *VerifyRootTADCnf()* signal.
- The RRS Configuration Manager verifies the signature of the received RRS Configuration Provider Profile via the reflexive *CPPProfileCheck()* signal. Upon success the RRS Configuration Provider Profile is installed, and the candidate RRS Configuration Provider is accepted by the Reconfigurable RE.

Figure 6.14-3 illustrates the distribution of an RRS Configuration Profile by the RRS Configuration Providers.




Figure 6.14-3: Signalling diagram for distributing RRS Configuration Profiles

The Procedure can be summarized as follows:

- The RRS Configuration Provider prepares a new RRS Configuration Profile for the Reconfigurable RE via a reflexive *PrepareConfigProfile()* signal.
- The RRS Configuration Provider signs the new RRS Configuration Profile via a reflexive *EndorseConfigProfile()* signal.
- The RRS Configuration Provider sends an *InstallConfigProfileReq()* signal to the RRS Configuration Manager, in order to request installation of the new RRS configuration Profile on the Reconfigurable RE.
- The RRS Configuration Manager verifies that the RRS Configuration Provider is entitled to provide RRS Configuration Profiles to the Reconfigurable RE, via a reflexive *ConfigProviderCheck()* signal. This includes verification of the RRS Configuration Provider Profile and of the complete chain of TADs.
- The RRS Configuration Manager requests verification of the root TAD by the Hardware Root of Trust via a *VerifyRootTADReq()* signal.
- The Hardware Root of Trust verifies the root TAD via a reflexive *RootTADCheck()* signal:
 - Upon failure, the Hardware Root of Trust sends a *VerifyRootTADFail()* signal and the procedure is aborted. The RRS Configuration Manager may send an *InstallConfigProfileFail()* signal to the RRS Configuration Provider.
 - Upon success, the Hardware Root of Trust sends a *VerifyRootTADCnf()* signal:
- The RRS Configuration Manager verifies the signature of the new RRS Configuration Profile via a reflexive *ConfigProfileCheck()* signal:
 - Upon failure, the RRS Configuration Manager sends an *InstallConfigProfileFail()* signal to the RRS Configuration Provider.
 - Upon success, the RRS Configuration Manager installs the new RRS Configuration Profile, and sends an *InstallConfigProfileCnf()* signal to the RRS Configuration Provider.

Annex A (informative): Distributed Computations on Multiple radio computers

A.0 Introduction

This annex describes in generic terms how a URA could be distributed onto multiple radio computers based on the framework defined in the present document.

A.1 Procedures of RA Distributed Installation on Multiple radio computers




Figure A.1: Conceptual diagram of RA distributed installation on multiple radio computers

The Procedure can be summarized as follows:

- The URA will be split into two RAPs, each of which is being load onto a specific Radio Computer in the reconfigurable Radio Equipment.
- Administrator sends an *InstallRAReq* for each of the RAPs, i.e. including RAP (P1) ID and RAP (P2) ID as well as radio computer (RC1) ID and radio computer (RC2) ID applying unicast.

NOTE: The interworking of multiple Radio Computers, including synchronization, data exchange, etc. is out of scope of the present document.

History

Document history			
V1.1.2	March 2020	EN Approval Procedure	AP 20200621: 2020-03-23 to 2020-06-22