ES 201 652 V1.1.1 (1999-06)

ETSI Standard

Telecommunications Management Network (TMN); Radio specific performance monitoring information model for Synchronous Digital Hierarchy (SDH) radio relay network element



Reference DES/TMN-00006 (fao00icp.PDF)

Keywords

DRRS, management, network, performance, radio, SDH

ETSI

Postal address F-06921 Sophia Antipolis Cedex - FRANCE

Office address

650 Route des Lucioles - Sophia Antipolis Valbonne - FRANCE Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16 Siret N° 348 623 562 00017 - NAF 742 C Association à but non lucratif enregistrée à la Sous-Préfecture de Grasse (06) N° 7803/88

Internet

secretariat@etsi.fr Individual copies of this ETSI deliverable can be downloaded from http://www.etsi.org If you find errors in the present document, send your comment to: editor@etsi.fr

Copyright Notification

No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

> © European Telecommunications Standards Institute 1999. All rights reserved.

Contents

Intellectual Property Rights		
Forev	word	5
1	Scope	6
2	References	6
3	Symbols and abbreviations	
3.1	Symbols	
3.2	Abbreviations	
4	Registration supporting Abstract Syntax Notation No.1 (ASN.1)	
5	Information model of Radio specific Performance Monitoring	9
5.1	Void	9
5.2	Object class definitions	
5.2.1	Radio SPI Current Data	
5.2.2	Radio Sink Synchronous Physical Interface Current Data	
5.2.3	Radio Sink Synchronous Physical Interface History Data	
5.2.4	Radio Source Synchronous Physical Interface Current Data	
5.2.5	Radio Source Synchronous Physical Interface History Data	
5.2.6	Radio Performance Monitoring Properties	
5.2.7	SDH Radio Protection Current Data	
5.2.8	SDH Radio Protection History Data	
5.3	Package definitions	
5.3.1	Received Level Second Counter List	
5.3.2	Received Power Level Current Data	
5.3.3	Received Power Level Tide Mark	
5.3.4	Transmitted Level Second Counter List	
5.3.5	Transmitted Power Level Current Data	
5.3.6	Transmitted Power Level Tide Mark	
5.4	Attribute definitions	
5.4.1	Number of Supported Tx Thresholds	
5.4.2	Number of Supported Rx Thresholds	
5.4.3	Power Level Threshold List	
5.4.4	Protection Switch Actual Count	
5.4.5	Protection Switch Actual Duration	
5.4.6	Failed Switch Request Count	
5.4.7	Failed Switch Request Duration	
5.4.8	Received Level Second Counter List	
5.4.9	Received Power Level.	
5.4.10	Received Power Level Tide Mark Maximum	
5.4.11	Received Power Level Tide Mark Minimum	
5.4.12	2 Iransmitted Level Second Counter List	
5.4.13	Nominal Transmitted Power Level	
5.4.14	Offset Transmitted Power Level	
5.4.15	Offset Transmitted Power Level Tide Mark Maximum	15 1 <i>5</i>
5.4.10	b Oliset Fransmitted Power Level Fide Mark Minimum	
J.4.1/	Premitted DV Thresholds Dange	
5 4 10	Default TV Threeholds List	
5 4 20	Default IA Hildsholds List	
5 4 21	Default RA THESHOLUS LIST	
J.4.21	Nauto FIVI FIOPETILES	
5.5 5.6	voiu	
5.0 5 7	volu Name binding definitions	
5.7 571	Dadio Sink SDI Current Data - Dadio SDI TTD Sink	۱۵ 10 ۱ <i>۲</i>
5.7.1	Kaulo Shik Sel Culten Dala - Kaulo Sel I Le Silk	

5.7.2 Radio Source SPI Current Data - Radio SPI TTP Source			17
5.7.3	SDH Radio Protection Current Data - Protection Unit		17
5.7.4	Radio Performanc	e Properties - SDH NE	17
Annex A (informative):		Inheritance Relationship of Radio Performance Management	. 18
Annex B (informative):		Containment Relationship of Radio Performance Management	. 20
History			. 21

4

Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in SR 000 314: "Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards", which is available **free of charge** from the ETSI Secretariat. Latest updates are available on the ETSI Web server (http://www.etsi.org/ipr).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Foreword

This ETSI Standard (ES) has been produced by ETSI Technical Committee Telecommunications Management Network (TMN).

The present document describes the performance monitoring information model specific to Radio Relay Network Elements, which use the SDH multiplexing structure.

1 Scope

The present document defines the information model to be used at the interface between network elements and management systems, for the management of SDH radio Network Element additional specific performance monitoring parameters.

6

Considering that:

- ETS 300 635 defines SDH Radio specific functional blocks for transmission at STM-N data rate;
- ETS 300 785 defines SDH Radio specific functional blocks for transmission at STM-0 data rate;
- EN 301 645 defines SDH Radio Relay equipment information model for use on Q interfaces;
- ETS 300 304 defines the SDH information model for the Network Element view;
- EN 301 167, ETS 300 417, ITU-T Recommendations G.783 and G.784 define the performance monitoring architecture and requirements for generic functional blocks used also in DRRS;
- EN 301 129 defines additional radio specific performance monitoring parameters;
- ETS 300 411 defines the generic performance monitoring Information Model for SDH Network Element.

The present document defines:

- the information model for radio specific performance monitoring parameters for SDH radio Network Elements.

The present document does not define:

- the protocol stack to be used for message communication;
- the network level management processes;
- the application contexts;
- the conformance requirements to be met by an implementation of this information model;
- information model for the generic performance monitoring Information Model for SDH Network Element.

The Information Model defined here (and the corresponding Message Set) is concerned with the management of network elements, the equipment by which they are implemented and the functions contained within them. More precisely, it applies to an Equipment Domain visible at the Element Manager to Element interface and is only concerned with information available within that domain. Information proper to the domain of a Network Level Management Process is not included within this model.

2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- · For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies.
- A non-specific reference to an ES shall also be taken to refer to later versions published as an EN with the same number.
- [1] ETS 300 635: "Transmission and Multiplexing (TM); Synchronous Digital Hierarchy (SDH); Radio specific functional blocks for transmission of M x STM-N".

ETS 300 785: "Transmission and Multiplexing (TM); Synchronous Digital Hierarchy (SDH);

[2]

	Radio specific functional blocks for transmission of M x sub-STM-1".
[3]	ETS 300 411: "Transmission and Multiplexing (TM); Performance monitoring; Information model for the Network Element (NE) view".
[4]	ETS 300 417: "Transmission and Multiplexing (TM); Generic functional requirements for Synchronous Digital Hierarchy (SDH) equipment".
[5]	TR 101 035: "Transmission and Multiplexing (TM); Synchronous Digital Hierarchy (SDH) aspects regarding Digital Radio Relay Systems (DRRS)".
[6]	ETS 300 304: "Transmission and Multiplexing (TM); Synchronous Digital Hierarchy (SDH); Information model for the Network Element (NE) view".
[7]	ITU-T Recommendation G.774.1: "Synchronous Digital Hierarchy (SDH) performance monitoring for the network element view".
[8]	ITU-T Recommendation G.774.8: "Synchronous Digital Hierarchy (SDH) management of radio- relay systems for the network element view".
[9]	ITU-T Recommendation X.721: "Information technology - Open Systems Interconnection - Structure of management information: Definition of management information".
[10]	ITU-T Recommendation M.3100: "Generic network information model".
[11]	ITU-T Recommendation X.720: "Information technology - Open Systems Interconnection - Structure of management information: Management information model".
[12]	ITU-T Recommendation G.774: "Synchronous digital hierarchy (SDH) management information model for the network element view".
[13]	ITU-T Recommendation X.722: "Information technology - Open Systems Interconnection - Structure of Management Information: Guidelines for the definition of managed objects".
[14]	ITU-T Recommendation X.701: "Information technology - Open Systems Interconnection - Systems management overview".
[15]	ITU-T Recommendation X.710: "Information technology - Open Systems Interconnection - Common Management Information Service".
[16]	ITU-T Recommendation X.711: "Information technology - Open Systems Interconnection - Common Management Information Protocol: Specification".
[17]	ITU-T Recommendation X.731: "Information technology - Open Systems Interconnection - Systems Management: State management function".
[18]	ITU-T Recommendation X.730: "Information technology - Open Systems Interconnection - Systems Management: Object management function".

- [19] ITU-T Recommendation X.733: "Information technology Open Systems Interconnection -Systems Management: Alarm reporting function".
- [20] ITU-T Recommendation X.734: "Information technology Open Systems Interconnection -Systems Management: Event report management function".
- [21] ITU-T Recommendation X.735: "Information technology Open Systems Interconnection -Systems Management: Log control function".
- [22] EN 301 129: "Transmission and Multiplexing (TM); Digital Radio Relay Systems (DRRS); Synchronous Digital Hierarchy (SDH); System performance monitoring parameters of SDH DRRS".

[23] EN 301 167: "Transmission and Multiplexing (TM); Management of Synchronous Digital Hierarchy (SDH) transmission equipment; Fault management and performance monitoring; Functional description".

8

3 Symbols and abbreviations

3.1 Symbols

For the purposes of the present document, the following symbols apply:

dBDecibeldBmDecibel relative to 1 milliWatt

3.2 Abbreviations

For the purposes of the present document, the following abbreviations apply:

ATPC	Automatic Transmit Power Control
DEN	Draft European Norm
DRRS	Digital Radio Relay System
EN	European Norm
ES	Errored Second
ETS	European Telecommunication Standard
ETSI	European Telecommunications Standards Institute
IF	Intermediate Frequency
ITU-R	International Telecommunication Union Radio Sector (former CCIR)
ITU-T	International Telecommunication Union Telecommunication Sector
	(former CCITT)
NE	Network Element
POH	Path OverHead
PM	Performance Monitoring
QOS	Quality of Service
RF	Radio Frequency
ROHA	Radio OverHead Access
RPS	Radio Protection Switching
RRR	Radio Relay Regenerator
RRT	Radio Relay Terminal
RS	Regenerator Section
RSOH	Regenerator Section OverHead
RSPI	Radio Synchronous Physical Interface
RST	Regenerator Section Termination
SDH	Synchronous Digital Hierarchy
SES	Severely Errored Second
SEMF	Synchronous Element Management Function
SF	Signal Fail
STM-n	Synchronous Transport Module n
Sub-STM-1	Sub Synchronous Transport Module 1 (also defined as STM-0 in ITU-T Recommendation G.861)
TMN	Telecommunication Management Network
UAS	UnAvailable Second
VC-n	Virtual Container n

4 Registration supporting Abstract Syntax Notation No.1 (ASN.1)

 $\label{eq:linear} Dentmn06 ~ \{ itu(0) ~ identified-organization(4) ~ etsi(0) ~ ets(xxx) ~ informationModel(0) ~ asnlModule(2) ~ dentmn06(0) \}$

```
DEFINITIONS IMPLICIT TAGS ::=
BEGIN
-- EXPORT Everything
            OBJECT IDENTIFIER ::= {itu(0) identified-organization(4) etsi(0) ets(xxx)
dentmn06
informationModel(0) }
                      OBJECT IDENTIFIER ::= {dentmn06 managedObjectClass(3)}
arppObjectClass
                     OBJECT IDENTIFIER ::= {dentmn06 nameBinding(6)}
OBJECT IDENTIFIER ::= {dentmn06 attribute(7)}
arppNameBinding
arppAttribute
                 OBJECT IDENTIFIER ::= {dentmn06 action(9)}
arppAction
                     OBJECT IDENTIFIER := {dentmn06 package(4)}
arppPackage
                     OBJECT IDENTIFIER ::= {dentmn06 notification(10)}
arppNotification
IMPORT
    Count
        FROM Attribute-ASN1Module { joint-iso-itu(2) ms(9) smi(3) part2(2) asn1Module(2) 1 }
    SDHGranularityPeriod
FROM SDHPMASN1 { itu(0) recommendation(0) g(7) g774(774) hyphen(127) pm(1) informationModel(0)
asnlModule(2) sdhmsp(0) };
Countor := CHOICE {
                                            [0] NULL,
                             null
                                  [1] INTEGER }
                     counter
NumberOfSupportedThresholds ::= INTEGER
PLThreshold ::= INTEGER
PLThresholdList ::= SEQUENCE OF PLThreshold
ThresholdRange ::= SEQUENCE{
             minValue INTEGER,
maxValue INTEGER}
CounterList ::= SEQUENCE OF Count
                                      -- Count imported from X721 Attribute-ASN1 Module
END
```

5 Information model of Radio specific Performance Monitoring

5.1 Void

radioSPICurrentData

5.2 Object class definitions

MANAGED OBJECT CLASS

5.2.1 Radio SPI Current Data

```
DERIVED FROM sdhCurrentData ;
    CHARACTERIZED BY
        radioSPICurrentDataPackage PACKAGE
            BEHAVIOUR radioSPICurrentDataBeh ;
            ATTRIBUTES
                 granularityPeriod REQUIRED VALUES SDHRadioPM.SDHGranularityPeriod,
                 pLThresholdList GET-REPLACE ;;;
REGISTERED AS { arppObjectClass 1} ;
radioSPICurrentDataBeh BEHAVIOUR
DEFINED AS
"The radioSPICurrentData object class is not a instanciable superclass used to hold the monitoring
of the physical characteristics and the current register counts of the Radio Synchronous Physical
Interface during a collection period.
Subclasses of this managed object class have the capability to monitor power levels by using a
sequence of counters.
The conditions that define each counter behaviour are determined by associating the i-th counter to
the i-th threshold value contained in the pLThresholdList attribute. The length of the counter list
attribute shall always match the length of the pLThresholdList attribute. The pLThresholdList
attribute may contain unordered values.
A counter value is incremented if, during a one-second period, the power level exceeds the
associated threshold value.
Specific instances obtained by instanciation of subclasses of this managed object class shall be
explicitly created by the manager. The value of pLThresholdList attribute can be provided by the manager in the creation request. If not specified by the manager it is taken from the default power
threshold list contained in the SDHRadioPMProperties object.
The create request will fail if:
- The length of the pLThresholdList sequence is greater than the value specified in the
numberOfSupportedThresholds attribute defined in the SDHRadioPMProperties object;
- Any of the threshold values of the pLThresholdList sequence is outside the limits defined in the
permittedThresholdRange attribute defined in the SDHRadioPMProperties object.
A QOS alarm notification may be emitted in association only to the first counter per performance
primitive. The presence of the rLSCounterList or tLSCounterList attribute ID in the field of the
CounterThresholdAttributeList attribute in a referenced thresholdData managed object class will
```

trigger the notification emission by comparing the threshold value with the counter value of the first member of the rLSCounterList or tLSCounterList attribute. The unavailableTimeAlarmPackage is not used in this class.";

5.2.2 Radio Sink Synchronous Physical Interface Current Data

radioSinkSPICurrentData MANAGED OBJECT CLASS DERIVED FROM radioSPICurrentData ; CHARACTERIZED BY rxPowerLevelCurrentDataPackage, rLSCounterListPackage, radioSinkSPICurrentDataPackage PACKAGE BEHAVIOUR radioSinkSPICurrentDataBeh ;;; CONDITIONAL PACKAGES rxPowerLevelTideMarkPackage PRESENT IF " An instance supports it " ; REGISTERED AS { arppObjectClass 2} radioSinkSPICurrentDataBeh BEHAVIOUR DEFINED AS "Instances of this managed object class are used to hold the monitoring of the physical characteristics and current register counts for an instance of the radioSPITTPSink (or subclass) managed object class during a collection period. The observed performance primitive is the RL Received (Power) Level. The monitored performance event is the RLTS Received (Power) Level Threshold Second. This managed object class shall support at least two counters. A number greater than two is optional. An instance of this managed object class uses an instance of the radioSinkSPIHistoryData for data history retention."

5.2.3 Radio Sink Synchronous Physical Interface History Data

```
radioSinkSPIHistoryData MANAGED OBJECT CLASS
   DERIVED FROM historyData ;
   CHARACTERIZED BY
        radioSinkSPIHistoryDataPackage
                                        PACKAGE
           BEHAVIOUR radioSinkSPIHistoryDataBeh ;
           ATTRIBUTES
                rLSCounterList GET ;;;
CONDITIONAL PACKAGES
       rxPowerLevelTideMarkPackage PRESENT IF " The containing radioSinkSPICurrentData
   contains this package "
REGISTERED AS { arppObjectClass 3};
radioSinkSPIHistoryDataBeh BEHAVIOUR
DEFINED AS
"Instances of this class are used to store the observed events of a radioSinkSPICurrentData object
at the end of an observation period.
An instance of this managed object class is contained by a radioSinkSPICurrentData managed object
instance. The threshold values associated with the counters recorded in the rLSCounterList attribute
are the ones contained in the pLThresholdList attribute of the containing current data instance." ;
```

5.2.4 Radio Source Synchronous Physical Interface Current Data

```
MANAGED OBJECT CLASS
radioSourceSPICurrentData
    DERIVED FROM radioSPICurrentData ;
    CHARACTERIZED BY
        txPowerLevelCurrentDataPackage,
        tLSCounterListPackage,
        radioSourceSPICurrentDataPackage PACKAGE
            BEHAVIOUR radioSourceSPICurrentDataBeh ;;;
    CONDITIONAL PACKAGES
        txPowerLevelTideMarkPackage PRESENT IF " An instance supports it " ;
REGISTERED AS { arppObjectClass 4 };
radioSourceSPICurrentDataBeh BEHAVIOUR
DEFINED AS
"Instances of this managed object class are used to hold the monitoring of the physical
characteristics and current register counts for an instance of the radioSPITTPSource ( or subclass )
managed object class during a collection period.
The creation request of istances of this managed object class will fail if ATPC is not present.
The observed performance primitive is the TL Transmitted ( Power ) Level.
The monitored performance event is the TLTS Transmitted ( Power ) Level Threshold Second.
This managed object class will support at least one counter per performance primitive. An additional
one is optional.
An instance of this managed object class uses an instance of the radioSourceSPIHistoryData for data
history retention." ;
```

5.2.5 Radio Source Synchronous Physical Interface History Data

radioSourceSPIHistoryData MANAGED OBJECT CLASS DERIVED FROM historyData ; CHARACTERIZED BY radioSourceSPIHistoryDataPackage PACKAGE BEHAVIOUR radioSourceSPIHistoryDataBeh ; ATTRIBUTES " Instances of this class are used to store the observed events of a radioSourceSPICurrentData object at the end of an observation period.

An instance of this managed object class is contained by a radioSourceSPICurrentData managed object instance. The threshold values associated with the counters recorded in the tLSCounterList attribute are the ones contained in the pLThresholdList attribute of the containing current data instance." ;

5.2.6 Radio Performance Monitoring Properties

```
sdhRadioPMProperties MANAGED OBJECT CLASS
    DERIVED FROM top ;
    CHARACTERIZED BY
        sdhRadioPMPropertiesPackage PACKAGE
            BEHAVIOUR sdhRadioPMPropertiesBeh ;
            ATTRIBUTES
                numberOfSupportedRxThresholds GET,
                numberOfSupportedTxThresholds GET,
                permittedRxThresholdsRange GET,
                permittedTxThresholdsRange
                                             GET
                defaultRxThresholdsList GET,
defaultTxThresholdsList GET,
                radioPMPropertiesId GET ;;;
REGISTERED AS { arppObjectClass 6};
sdhRadioPMPropertiesBeh BEHAVIOUR
DEFINED AS
" Typically only one instance of this class is automatically instanciated by the agent (if the
additional radio performance parameters are supported). The values of the attributes of this class
define:
```

- the maximum number of Rx/Tx thresholds supported by the NE;

- the permitted range of Rx/Tx thresholds;

- the thresholds default values when not specified by the manager in the creation request of current data instances.

If PM is only unidirectionally supported the supported thresholds number of the unsupported direction is zero and the associated default threshold list is empty and the range attribute values are meaningless";

5.2.7 SDH Radio Protection Current Data

```
sdhRadioProtectionCurrentData MANAGED OBJECT CLASS
    DERIVED FROM sdhCurrentData ;
    CHARACTERIZED BY
        sdhRadioProtectionCurrentDataPackage PACKAGE
            BEHAVIOUR sdhRadioProtectionCurrentDataBeh ;
            ATTRIBUTES
                granularityPeriod REQUIRED VALUES SDHRadioPM.SDHGranularityPeriod,
                                                                                                pSAC
REPLACE-WITH-DEFAULT GET,
                fSRC
                       REPLACE-WITH-DEFAULT GET,
                pSAD
                       REPLACE-WITH-DEFAULT GET
                fSRD REPLACE-WITH-DEFAULT GET ;;;
REGISTERED AS { arppObjectClass 7} ;
sdhRadioProtectionCurrentDataBeh
                                    BEHAVIOUR
DEFINED AS
" Instances of the sdhRadioProtectionCurrentData managed object class are used to hold the current
register counts for a radio protection during a collection period. The following performance
primitives are observed:
PSA Protection Switch Actual
fSR failedSwitch Request.
For the PSA performance primitive, the following performance events are defined :
PSAC Protection Switch Actual Count
PSAD Protection Switch Actual Duration
For the fSR performance primitive, the following performance events are defined :
fSRC failed Switch Request Count
fSRD failed Switch Request Duration.
This managed object class will use the sdhRadioProtectionHistoryData managed object class for
history retention.
   [1] the meaningless of protection counters is defined for different cases of protection schemes.
Tn
This is reflected in this information model fragment by means of different syntax of the counter
attributes. A NULL value is used to indicated an meaningless measure.
```

5.2.8 SDH Radio Protection History Data

sdhRadioProtectionHistoryData MANAGED OBJECT CLASS DERIVED FROM HistoryData ; CHARACTERIZED BY sdhRadioProtectionHistoryDataPackage PACKAGE

BEHAVIOUR sdhRadioProtectionHistoryDataBeh ; ATTRIBUTES pSAC GET . fSRC GET, pSAD GET, fSRD GET ;;; REGISTERED AS { arppObjectClass 8} ; sdhRadioProtectionHistoryDataBeh BEHAVIOUR DEFINED AS " Instances of this managed object class are used to store the observed events of a sdhRadioProtectionCurrentData object at the end of an observation period. An instance of this managed object class is contained in an instance of the sdhRadioProtectionCurrentData.

5.3 Package definitions

5.3.1 Received Level Second Counter List

```
rLSCounterListPackage PACKAGE
BEHAVIOUR
rLSCounterListPackageBeh;
ATTRIBUTES
rLSCounterList REPLACE-WITH-DEFAULT GET;
REGISTERED AS { arppPackage 1};
rLSCounterListPackageBeh BEHAVIOUR
DEFINED AS
" This package is used to monitor the received power level by means of an ordered list of counters.
";
5.3.2 Received Power Level Current Data
rxPowerLevelCurrentDataPackage PACKAGE
```

```
BEHAVIOUR
rxPowerLevelCurrentDataPackageBeh ;
ATTRIBUTES
rxPowerLevel GET ;
REGISTERED AS { arppPackage 2} ;
rxPowerLevelCurrentDataPackageBeh BEHAVIOUR
DEFINED AS
" This package is used to store the gauge of a received power level value " ;
```

5.3.3 Received Power Level Tide Mark

```
rxPowerLevelTideMarkPackage PACKAGE
BEHAVIOUR
    rxPowerLevelTideMarkPackageBeh ;
ATTRIBUTES
    rxPowerLevelTideMarkMax GET ,
    rxPowerLevelTideMarkMin GET ;
REGISTERED AS { arppPackage 3} ;
rxPowerLevelTideMarkPackageBeh BEHAVIOUR
DEFINED AS
" This Package is used to store the minimum and the
" This Package is used to store the minimum and the
" This Package is used to store the minimum and the
" This Package is used to store the minimum and the
" This Package is used to store the minimum and the"
```

```
" This Package is used to store the minimum and the maximum values reached by the received power level gauge during an observation period. " ;
```

5.3.4 Transmitted Level Second Counter List

```
tLSCounterListPackage PACKAGE
BEHAVIOUR
tLSCounterListPackageBeh;
ATTRIBUTES
tLSCounterList REPLACE-WITH-DEFAULT GET;
REGISTERED AS { arppPackage 4 };
tLSCounterListPackageBeh BEHAVIOUR
DEFINED AS
" This package is used to monitor the transmitted power level by means of an ordered list of
counters. ";
```

5.3.5 Transmitted Power Level Current Data

```
txPowerLevelCurrentDataPackage PACKAGE
BEHAVIOUR
txPowerLevelCurrentDataPackageBeh;
ATTRIBUTES
nomTxPowerLevel GET,
offsetTxPowerLevel GET;
REGISTERED AS { arppPackage 5 } ;
txPowerLevelCurrentDataPackageBeh BEHAVIOUR
```

DEFINED AS
" This package is used to store the gauge of two values :
- an integer fixed value expressed in dBm defining the nominal i.e. the maximum transmitted power
value which is equipment dependent,
- an integer offset value expressed in dB representing the variation with respect to the nominal

13

value." ;

5.3.6 Transmitted Power Level Tide Mark

txPowerLevelTideMarkPackage PACKAGE

```
BEHAVIOUR
    txPowerLevelTideMarkPackageBeh ;
ATTRIBUTES
    offsetTxPowerLevelTideMarkMax    GET ,
    offsetTxPowerLevelTideMarkMin    GET ;
```

REGISTERED AS { arppPackage 6 } ; txPowerLevelTideMarkPackageBeh BEHAVIOUR

DEFINED AS

" This Package is used to store the minimum and the maximum values reached by the transmitted power level gauge (offset values) during an observation period. " ;

5.4 Attribute definitions

5.4.1 Number of Supported Tx Thresholds

numberOfSupportedTxThresholds ATTRIBUTE

WITH ATTRIBUTE SYNTAX SDHRadioPM.NumberOfSupportedThresholds;

MATCHES FOR EQUALITY, ORDERING ;

BEHAVIOUR numberOfSupportedTxThresholdsBeh ;

REGISTERED AS { arppAttribute 1 } ;

numberOfSupportedTxThresholdsBeh BEHAVIOUR

"This attribute is used to hold the maximum supported number of thresholds for TL performance primitive monitoring ";

5.4.2 Number of Supported Rx Thresholds

numberOfSupportedRxThresholds ATTRIBUTE

WITH ATTRIBUTE SYNTAX SDHRadioPM.NumberOfSupportedThresholds; MATCHES FOR EQUALITY, ORDERING ;

BEHAVIOUR numberOfSupportedRxThresholdsBeh ; REGISTERED AS { arppAttribute 2 } ;

numberOfSupportedRxThresholdsBeh BEHAVIOUR

DEFINED AS

"This attribute is used to hold the maximum supported number of thresholds for RL performance primitive monitoring " ;

5.4.3 Power Level Threshold List

```
pLThresholdList ATTRIBUTE
WITH ATTRIBUTE SYNTAX SDHRadioPM.PLThresholdList;
MATCHES FOR EQUALITY;
BEHAVIOUR pLThresholdListBeh;
REGISTERED AS { arppAttribute 3 };
pLThresholdListBeh BEHAVIOUR
DEFINED AS
" This attribute is used to define the threshold values that determine the associated counter behaviour.
This is an ordered set valued attribute whose single members have a one to one relationship w
```

This is an ordered set valued attribute whose single members have a one to one relationship with members of the rLSCounterList or tLSCounterList attributes.

The pLCounterThresholdAssignment sub-field defines the threshold values as a positive integer. The associated measure unit will be interpreted as expressed in minus dBm when referred to RLS counters or in dB (offset value) when referred to TLS counters";

5.4.4 Protection Switch Actual Count

pSAC ATTRIBUTE
WITH ATTRIBUTE SYNTAX SDHRadioPM.Counter;
MATCHES FOR EQUALITY, ORDERING;
BEHAVIOUR pSACBeh;
REGISTERED AS { arppAttribute 4 };
pSACBeh BEHAVIOUR
DEFINED AS
"" The value of the pSAC attribute represents the second second

" The value of the pSAC attribute represents the count of actual switches occurred on a protection unit. For a protected protection unit it is the count of actual service switches to any protecting protection unit. For a protecting protection unit it is the count of actual service switches from any protected protection unit. ";

5.4.5 Protection Switch Actual Duration

```
pSAD ATTRIBUTE
   WITH ATTRIBUTE SYNTAX SDHRadioPM.Counter ;
   MATCHES FOR EQUALITY, ORDERING ;
   BEHAVIOUR pSADBeh ;
REGISTERED AS { arppAttribute 5 } ;
pSADBeh BEHAVIOUR
DEFINED AS
   " The value of the pSAD attribute represents the count of seconds during which the service was
   actually switched on a protection unit. For a protected protection unit the service is switched if
   it is carried on this protection unit. " ;
```

5.4.6 Failed Switch Request Count

```
fSRC ATTRIBUTE
   WITH ATTRIBUTE SYNTAX SDHRadioPM.Counter ;
   MATCHES FOR EQUALITY, ORDERING ;
   BEHAVIOUR fSRCBeh ;
REGISTERED AS { arppAttribute 6 } ;
fSRCBeh BEHAVIOUR
DEFINED AS
" The value of the fSRC attribute represents the number of the occurrences in a time period of the
following events:
   A: a PSR is activated on a working channel and the protecting channels are not available.
   B: a working channel is restored from a protecting channel while a PSR is still active on the
channel.
A FSRC is defined only for working channels.
If a PSR is already present on a protection unit, toggling among different priority PSR on the same
unit, will not increment the counter. ";
```

5.4.7 Failed Switch Request Duration

```
fSRD ATTRIBUTE
   WITH ATTRIBUTE SYNTAX SDHRadioPM.Counter ;
   MATCHES FOR EQUALITY, ORDERING ;
   BEHAVIOUR fSRDBeh ;
REGISTERED AS { arppAttribute 7 } ;
fSRDBeh BEHAVIOUR
DEFINED AS
   " The value of the fSRD attribute represents the count of seconds in a time period for which, at
least for a fraction of one second, a protection switch request is detected active on a channel
   carrying regular traffic and the request cannot be serviced. " ;
```

5.4.8 Received Level Second Counter List

```
rLSCounterList ATTRIBUTE
WITH ATTRIBUTE SYNTAX SDHRadioPM. CounterList;
MATCHES FOR EQUALITY;
BEHAVIOUR rLSCounterListBeh;
REGISTERED AS { arppAttribute 8 };
rLSCounterListBeh BEHAVIOUR
DEFINED AS
" This attribute is used to hold the count of the Received Level Second events during a collection
period.
This is an ordered set valued attribute whose single members have a one to one relationship with
members of the pLCounterThresholdAssignmentList attribute.
Each associated threshold determines the condition under which the count is activated. ";
```

5.4.9 Received Power Level

```
rxPowerLevel ATTRIBUTE
DERIVED FROM " Rec. X721 : 1992 " : gauge ;
BEHAVIOUR rxPowerLevelBeh ;
REGISTERED AS { arppAttribute 9 } ;
rxPowerLevelBeh BEHAVIOUR
DEFINED AS
" The value of the rxPowerLevel attribute represents the received power level.
It is a positive integer with associated measure unit expressed in minus dBm. " ;
```

5.4.10 Received Power Level Tide Mark Maximum

```
rxPowerLevelTideMarkMax ATTRIBUTE
DERIVED FROM " Rec. X721 : 1992 " : tideMark;
BEHAVIOUR rxPowerLevelTideMarkMaxBeh ;
REGISTERED AS { arppAttribute 10 } ;
rxPowerLevelTideMarkMaxBeh BEHAVIOUR
DEFINED AS
```

" This attribute is used to store the maximum value reached by the received power level gauge during an observation period. " ;

5.4.11 Received Power Level Tide Mark Minimum

rxPowerLevelTideMarkMin ATTRIBUTE DERIVED FROM " Rec. X721 : 1992 " : tideMark; BEHAVIOUR rxPowerLevelTideMarkMinBeh ; REGISTERED AS { arppAttribute 11 } ; rxPowerLevelTideMarkMinBeh BEHAVIOUR DEFINED AS " This attribute is used to store the minimum value reached by the received power level gauge during an observation period. " ;

5.4.12 Transmitted Level Second Counter List

tLSCounterList ATTRIBUTE
WITH ATTRIBUTE SYNTAX SDHRadioPM.CounterList;
MATCHES FOR EQUALITY;
BEHAVIOUR tLSCounterListBeh;
REGISTERED AS { arppAttribute 12 };
tLSCounterListBeh BEHAVIOUR
DEFINED AS
" This attribute is used to hold the count of the Transmitted Level Second events during a
collection period.
This is an ordered set valued attribute whose single members have a one to one relationship with
members of the pLCounterThresholdAssignmentList attribute.
Each associated threshold determines the condition under which the count is activated. ";

5.4.13 Nominal Transmitted Power Level

```
nomTxPowerLevel ATTRIBUTE
    DERIVED FROM " Rec. X721 : 1992 " : gauge ;
    BEHAVIOUR nomTxPowerLevelBeh ;
REGISTERED AS { arppAttribute 13 } ;
nomTxPowerLevelBeh BEHAVIOUR
DEFINED AS
 " The value of the nomTxPowerLevel is represented by an integer fixed value expressed in dBm
defining the nominal i.e. the maximum transmitted power value which is equipment dependent." ;
```

5.4.14 Offset Transmitted Power Level

```
offsetTxPowerLevel ATTRIBUTE
    DERIVED FROM " Rec. X721 : 1992 " : gauge ;
    BEHAVIOUR offsetTxPowerLevelBeh ;
REGISTERED AS { arppAttribute 14 } ;
offsetTxPowerLevelBeh BEHAVIOUR
DEFINED AS
    " The value of the offsetTxPowerLevel is represented by an integer offset value expressed in dB
representing the variation with respect to the nominal value." ;
```

5.4.15 Offset Transmitted Power Level Tide Mark Maximum

offsetTxPowerLevelTideMarkMax ATTRIBUTE
 DERIVED FROM " Rec. X721 : 1992 " : tideMark;
 BEHAVIOUR offsetTxPowerLevelTideMarkMaxBeh ;
REGISTERED AS { arppAttribute 15 };
offsetTxPowerLevelTideMarkMaxBeh BEHAVIOUR
DEFINED AS
 " This attribute is used to store the maximum value reached by the transmitted power level gauge
during an observation period. " ;

5.4.16 Offset Transmitted Power Level Tide Mark Minimum

offsetTxPowerLevelTideMarkMin ATTRIBUTE DERIVED FROM " Rec. X721 : 1992 " : tideMark; BEHAVIOUR offsetTxPowerLevelTideMarkMinBeh ; REGISTERED AS { arppAttribute 16 }; offsetTxPowerLevelTideMarkMinBeh BEHAVIOUR DEFINED AS " This attribute is used to store the minimum value reached by the transmitted power level gauge during an observation period. " ;

5.4.17 Permitted TX Thresholds Range

permittedTxThresholdsRange ATTRIBUTE WITH ATTRIBUTE SYNTAX SDHRadioPM.ThresholdRange; MATCHES FOR EQUALITY ; BEHAVIOUR permittedTxThresholdsRangeBeh ; REGISTERED AS { arppAttribute 17 } ; permittedTxThresholdsRangeBeh BEHAVIOUR DEFINED AS "This attribute is used to define for the

"This attribute is used to define for the transmitter the maximum and minimum allowable values for a threshold value expressed in dB " ;

16

5.4.18 Permitted RX Thresholds Range

permittedRxThresholdsRange ATTRIBUTE
 WITH ATTRIBUTE SYNTAX SDHRadioPM.ThresholdRange;
 MATCHES FOR EQUALITY;
 BEHAVIOUR permittedRxThresholdsRangeBeh;
REGISTERED AS { arppAttribute 18 };
permittedRxThresholdsRangeBeh BEHAVIOUR
DEFINED AS
 "This attribute is used to define for the receiver the maximum and minimum allowable values for a
threshold value expressed in - dBm ";

5.4.19 Default TX Thresholds List

defaultTxThresholdsList ATTRIBUTE
 WITH ATTRIBUTE SYNTAX SDHRadioPM.ThresholdList;
 MATCHES FOR EQUALITY;
 BEHAVIOUR defaultTxThresholdsListBeh;
REGISTERED AS { arppAttribute 19 };
defaultTxThresholdsListBeh BEHAVIOUR
DEFINED AS
"This attribute is used to define for the transmitter"

"This attribute is used to define for the transmitter a threshold default value expressed in dB " ;

5.4.20 Default RX Thresholds List

```
defaultRxThresholdsList ATTRIBUTE
   WITH ATTRIBUTE SYNTAX SDHRadioPM.ThresholdList;
   MATCHES FOR EQUALITY;
   BEHAVIOUR defaultRxThresholdsListBeh;
REGISTERED AS { arppAttribute 20 };
defaultRxThresholdsListBeh BEHAVIOUR
DEFINED AS
"This attribute is used to define for the receiver the default threshold values expressed in -
dBm".
```

5.4.21 Radio PM Properties

```
radioPMPropertiesId ATTRIBUTE
WITH ATTRIBUTE SYNTAX SDHRadioPM.NameType ;
MATCHES FOR EQUALITY ;
BEHAVIOUR radioPMPropertiesIdBeh ;
REGISTERED AS { arppAttribute 21 } ;
radioPMPropertiesIdBeh BEHAVIOUR
DEFINED AS
"This attribute is used as a RDN for naming instances of the sdhRadioPMProperties object class " ;
```

5.5 Void

5.6 Void

5.7 Name binding definitions

5.7.1 Radio Sink SPI Current Data - Radio SPI TTP Sink

```
radioSinkSPICurrentData-radioSPITTPSink NAME BINDING
SUBORDINATE OBJECT CLASS radioSinkSPICurrentData AND SUBCLASSES ;
NAMED BY
SUPERIOR OBJECT CLASS radioSPITTPSink AND SUBCLASSES ;
WITH ATTRIBUTE scannerId ;
CREATE
WITH-REFERENCE-OBJECT,
WITH-REFERENCE-OBJECT,
WITH-AUTOMATIC-INSTANCE-NAMING ;
DELETE
DELETES-CONTAINED-OBJECTS ;
REGISTERED AS { ArppNameBinding 1 };
```

5.7.2 Radio Source SPI Current Data - Radio SPI TTP Source

```
radioSourceSPICurrentData-radioSPITTPSource NAME BINDING
SUBORDINATE OBJECT CLASS radioSourceSPICurrentData AND SUBCLASSES;
NAMED BY
SUPERIOR OBJECT CLASS radioSPITTPSource AND SUBCLASSES;
WITH ATTRIBUTE scannerId;
CREATE
WITH-REFERENCE-OBJECT,
WITH-AUTOMATIC-INSTANCE-NAMING;
DELETE
DELETE
DELETES-CONTAINED-OBJECTS;
REGISTERED AS { ArppNameBinding 2 };
```

5.7.3 SDH Radio Protection Current Data - Protection Unit

```
sdhRadioProtectionCurrentData-protectionUnit NAME BINDING
SUBORDINATE OBJECT CLASS sdhRadioProtectionCurrentData AND SUBCLASSES ;
NAMED BY
SUPERIOR OBJECT CLASS protectionUnit AND SUBCLASSES ;
WITH ATTRIBUTE scannerId ;
CREATE
WITH-REFERENCE-OBJECT,
WITH-REFERENCE-OBJECT,
WITH-AUTOMATIC-INSTANCE-NAMING ;
DELETE
DELETES-CONTAINED-OBJECTS ;
REGISTERED AS { ArppNameBinding 3 } ;
```

5.7.4 Radio Performance Properties - SDH NE

```
sdhRadioPMProperties-sdhNE NAME BINDING
SUBORDINATE OBJECT CLASS sdhRadioPMProperties AND SUBCLASSES ;
NAMED BY
SUPERIOR OBJECT CLASS sdhNE AND SUBCLASSES ;
WITH ATTRIBUTE radioPMPropertiesId ;
REGISTERED AS { ArppNameBinding 4 } ;
```

Annex A (informative): Inheritance Relationship of Radio Performance Management



Figure A.1

Annex B (informative): Containment Relationship of Radio Performance Management



Figure B.1

History

Document history							
V1.1.1	March 1999	Membership Approval Procedure	MV 9922:	1999-03-30 to 1999-05-28			
V1.1.1	June 1999	Publication					