
# ETSI ES 202 336-3 V1.1.1 (2009-10)

ETSI Standard

Environmental Engineering (EE);
Monitoring and Control Interface for Infrastructure Equipment
(Power, Cooling and Building Environment Systems used in
Telecommunication Networks);
Part 3: AC UPS power system control and
monitoring information model



#### Reference

#### DES/EE-02037-3

#### Keywords

control, interface, management, power, system

#### **ETSI**

650 Route des Lucioles F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C Association à but non lucratif enregistrée à la Sous-Préfecture de Grasse (06) N° 7803/88

#### Important notice

Individual copies of the present document can be downloaded from: <u>http://www.etsi.org</u>

The present document may be made available in more than one electronic version or in print. In any case of existing or perceived difference in contents between such versions, the reference version is the Portable Document Format (PDF). In case of dispute, the reference shall be the printing on ETSI printers of the PDF version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<a href="http://portal.etsi.org/tb/status/status.asp">http://portal.etsi.org/tb/status/status.asp</a>

If you find errors in the present document, please send your comment to one of the following services: <u>http://portal.etsi.org/chaircor/ETSI\_support.asp</u>

#### **Copyright Notification**

No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2009.
All rights reserved.

**DECT**<sup>TM</sup>, **PLUGTESTS**<sup>TM</sup>, **UMTS**<sup>TM</sup>, **TIPHON**<sup>TM</sup>, the TIPHON logo and the ETSI logo are Trade Marks of ETSI registered for the benefit of its Members.

**3GPP**<sup>™</sup> is a Trade Mark of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **LTE**<sup>™</sup> is a Trade Mark of ETSI currently being registered

for the benefit of its Members and of the 3GPP Organizational Partners.

GSM® and the GSM logo are Trade Marks registered and owned by the GSM Association.

# Contents

Intell	lectual Property Rights		4
Fore	word		4
1	Scope		5
2 2.1 2.2	Normative reference	eses	5
3 3.1 3.2	Definitions	viations	6
4	AC UPS power system	ms	9
5		alarms, events, data, data records, configuration and control with PS power system	13
Anno	ex A (normative):	Summary of mandatory and non-mandatory monitoring/supervision information and functions for On-line AC UPS power systems	
Anno	ex B (normative):	Summary of mandatory and non-mandatory monitoring/supervision information and functions for Off-line AC UPS power systems	21
Anno	ex C (normative):	Summary of mandatory and non-mandatory monitoring/supervision information and functions for Line-interactiv AC UPS power systems	24
Anno	ex D (normative):	Mandatory XML structure and elements	28
D.1	Structure of an XML	document for a AC UPS power system	28
D.2	The specific XML ele	ements of an AC UPS power system	29
Anno	ex E (informative):	Bibliography	30
Histo	ory		31

## Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (http://webapp.etsi.org/IPR/home.asp).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

#### **Foreword**

This ETSI Standard (ES) has been produced by ETSI Technical Committee Environmental Engineering (EE).

The present document is part 3 of a multi-part deliverable covering Monitoring and Control Interface for Infrastructure Equipment (Power, Cooling and Building Environment Systems used in Telecommunication Networks), as identified below:

Part 1: "Generic Interface";

Part 2: "DC power system control and monitoring information model";

Part 3: "AC UPS power system control and monitoring information model";

Part 4: "AC distribution power system control and monitoring information model";

Part 5: "AC diesel back-up generator system control and monitoring information model";

Part 6: "Air conditioning system control and monitoring information model";

Part 7: "Other utilities system control and monitoring information model";

Part 8: "Remote Power Feeding System control and monitoring information model".

## 1 Scope

The present document applies to monitoring and control of AC UPS power systems for telecommunication equipment.

The document defines:

- The monitored and controlled AC UPS power system architectures.
- The minimum set of exchanged information required at the interface, described in "natural language" in text
- The XML files with tags and variables corresponding to the data in the tables.

### 2 References

References are either specific (identified by date of publication and/or edition number or version number) or non-specific.

- For a specific reference, subsequent revisions do not apply.
- Non-specific reference may be made only to a complete document or a part thereof and only in the following cases:
  - if it is accepted that it will be possible to use all future changes of the referenced document for the purposes of the referring document;
  - for informative references.

Referenced documents which are not found to be publicly available in the expected location might be found at <a href="http://docbox.etsi.org/Reference">http://docbox.etsi.org/Reference</a>.

NOTE: While any hyperlinks included in this clause were valid at the time of publication ETSI cannot guarantee their long term validity.

### 2.1 Normative references

The following referenced documents are indispensable for the application of the present document. For dated references, only the edition cited applies. For non-specific references, the latest edition of the referenced document (including any amendments) applies.

- [1] ETSI ES 202 336-1: "Environmental Engineering (EE); Monitoring and Control Interface for Infrastructure Equipment (Power, Cooling and Building Environment Systems used in Telecommunication Networks) Part 1: Generic Interface".
- [2] ETSI EN 300 132-3: "Environmental Engineering (EE); Power supply interface at the input to telecommunications equipment; Part 3: Operated by rectified current source, alternating current source or direct current source up to 400 V".

### 2.2 Informative references

The following referenced documents are not essential to the use of the present document but they assist the user with regard to a particular subject area. For non-specific references, the latest version of the referenced document (including any amendments) applies.

- [i.1] IEEE 802.1 to 802.11: "IEEE Standard for Local & Metropolican Area Network".
- [i.2] ISO/IEC 10164: "Information technology -- Open Systems Interconnection -- Systems Management: Objects and attributes for access control".

[i.3]	ISO/IEC 8879: "Information processing Text and office systems Standard Generalized Markup Language (SGML)".
[i.4]	ETSI EN 300 132-2: "Environmental Engineering (EE); Power supply interface at the input to telecommunications equipment; Part 2: Operated by direct current (dc)".
[i.5]	ETSI EN 302 099: "Environmental Engineering (EE); Powering of equipment in access network".
[i.6]	ETSI TR 102 121: "Environmental Engineering (EE); Guidance for power distribution to telecommunication and datacom equipment".
[i.7]	ETSI ES 202 336-2: "Environmental Engineering (EE); Monitoring and Control Interface for Infrastructure Equipment (Power, Cooling and Building Environment Systems used in Telecommunication Networks); Part 2: DC power system control and monitoring information model".

## 3 Definitions and abbreviations

### 3.1 Definitions

For the purposes of the present document, the following terms and definitions apply:

NOTE: Terms referring to energy interface, equipment and distribution are described in power distribution standards EN 300 132-2 [i.4], EN 300 132-3 [2] for ac and dc interface and EN 302 099 [i.5] for access network equipment powering.

**alarm:** any information signalling abnormal state, i.e. different to specified normal state of hardware, software, environment condition (temperature, humidity, etc.)

NOTE: The alarm signal should be understood by itself by an operator and should always have at least one severity qualification or codification (colour, level, etc.).

EXAMPLE: Rectifier failure, battery low volage, etc.

alarm loop: electrical loop which open or closed state correspond to alarm start (set) or end (clear) state

alarm message: text parts of the alarm structure

alarm structure: organized set of information fields in an alarm data frame (time stamp, set/clear, text, etc.)

battery: complete arrangement of battery cells or blocks in one string or more in parallel

battery cell: basic electrochemical element (e.g. a 2 V nominal cell for a high capacity lead acid battery)

battery string: a number of serially interconnected battery blocks or cells

**client post:** any device (laptop, PDA, console, etc.) connected to servers via the operation system networks to perform maintenance or supervision operations

**Control form Style Sheet (CSS):** simple mechanism for adding style (e.g. fonts, colors, spacing) to Web documents. Tutorials, books, mailing lists for users, etc.

Control Unit (CU): integrated unit in an equipment to monitor and control this equipment through sensors and actuators

Data Gathering Unit (DGU): functional unit used for several functions:

- collect serial, digital, and analog data from several equipment;
- option to send (output) serial or digital commands;
- forward/receive information to/from the Local/Remote Management Application via agreed protocols;
- mediation between interfaces and protocols.

NOTE: This function may be integrated as part of specific equipment.

**Dynamic Host Control Protocol (DHCP):** protocol used for self configuration of TCP/IP parameters of a workstation assigning IP address and a subnetwork mask

NOTE: DHCP may also configure DNS.

**Dynamic Name Server (DNS):** associates a single domain name to an IP address

dynamic synoptic: dynamic display of geographical maps, networks, installations and equipment

ethernet: LAN protocol

NOTE: Equivalent to IEEE 802.1 to IEEE 802.11 [i.1].

event: any information signalling a change of state which is not an alarm: e.g. battery test, change of state of battery charge

NOTE: The event signal should be understood by itself by an operator and should always have at least one severity qualification or codification (color, level, etc.). It should be transmitted in a formatted structure with text message and other fields like for alarm, e.g. an event can be coded as an alarm with severity "0".

eXtensible Style sheet Language (XSL): language for expressing style sheets

NOTE: It consists of two parts, a language for transforming XML documents, and an XML vocabulary for specifying formatting semantics. An XSL style sheet specifies the presentation of a class of XML documents by describing how an instance of the class is transformed into an XML document that uses the formatting vocabulary.

**infrastructure equipment:** power, cooling and building environment systems used in telecommunications centres and Access Networks locations

EXAMPLE: Cabinets, shelters, underground locations, etc.

intranet: internal company network generally using Ethernet protocol and extended IP addresses

logbook: chronological file that contains alarm and event messages may be paper or electronic

Management Information Base (MIB): dynamic data base that gathers all objects and should evolve to include automatic and manual configuration tools with self coherence tests

menu: list of possible input command choices that may be presented in different ways on a display

NOTE: Selection is normally made by a keyboard, a pointing device, a mouse or directly by finger on a sensitive screen.

object: class description of items that accept a set of properties or functions

NOTE: Generic objects can include more specific items and inherit from their properties. If correctly structured, object programming can allow the system to evolve, i.e. be more future-proof. The code should intrinsically be open and structured.

**PHP:** powerful tool for making dynamic and interactive Web pages

pop-up: information or command screen that appears when a menu choice is selected

NOTE: For example this may be a pop-up menu when the pointer is on a title button.

**REpresentational State Transfer (REST):** way to build an application for distributed system as www

**Simple Object Access Protocol (SOAP):** way to communicate between applications running on different operating systems, with different technologies and programming languages

NOTE: SOAP communicates over HTTP, because HTTP is supported by all Internet browsers and servers, SOAP traffic is not blocked by firewalls and proxy servers (see W3C).

Systems Management Function (SMF): object properties or classes with projection on CMIS application context communication

NOTE: Set of ISO system management functions according to ISO/IEC 10164 [i.2].

**Uninterruptible Power Supply (UPS):** device or system that provides electrical power without interruption in the event that commercial power drops to un unacceptable voltage level

warning: low severity alarm

web: common name for the Internet or Intranet

windows: virtual area on the display that corresponds to a specific application

**World Wide Web Consortium (W3C):** consortium founded in October 1994 to develop common interoperable protocols and promote World Wide Web

NOTE: See http://www.w3c.org.

XCU: CU enabled to communicate using XML interface as defined in the present document

**XHTML:** stricter and cleaner version of HTML. XHTML consists of all the elements in HTML 4.01 combined with the syntax of XML. It can be read by all XML browser (see W3C)

eXtensible Mark-up Language (XML): application profile or restricted form of SGML

NOTE: By construction, XML documents are conforming SGML the Standard Generalized Markup Language

(ISO/IEC 8879 [i.3]). documents.XML is designed to describe data and focus on what data is. XML should be discerned from the well known Hypertext Transfer Mark-up Language (HTML) which was designed to display data and to focus on how data looks.

XML Schema Definition (XSD): new more detailed XML description compared to the previous one, the DTD

#### 3.2 Abbreviations

For the purposes of the present document, the following abbreviations apply:

AC Alternating Current

CU Control Unit of an equipment CSS Control form Style Sheet

DC Direct Current
DGU Data Gathering Unit

DHCP Dynamic Host Control Protocol

DNS Dynamic Name Server

HTML Hypertex Transfer Make-up Language

HTTP HyperTex Transfer Protocol

IP Internet Protocol
LAN Local Array Network
LVD Low Voltage Disconnection
MIB Mnagement Information Base
MN Management Network

REST REpresentational State Transfer RMA Remote Management Application

SBS Static Bypass Switch

SMF Systems Management Function SOAP Simple Object Access Protocol

TCP	Transmission Control Protocol for IP
UPS	Uninterruptible Power Supply
W3C	World Wide Web Consortium
XCU	XML enabled CU
XML	eXtensible Mark-up Language (see W3C)
XSD	XML Schema Definition
XSL	eXtensible Style sheet Language

# 4 AC UPS power systems

The AC UPS power systems subset described in ES 202 336-1 [1] and TR 102 121 [i.6] provides electrical power without interruption in the event that commercial power drops to un unacceptable voltage level.

The AC UPS power system provide uninterruptible 230V/400V; 50 Hz voltage according EN 300 132-3 [2], in period defined by capacity of installed back-up battery.

The AC UPS power systems addressed by the present document can be single phase input/single phase output, three phases input/single phase output and three phases input/three phases output.

The following configurations of static AC UPS power system will be under the scope of the present document: On-line AC UPS, Modular On-line AC UPS, Off-line AC UPS and Line-interactive AC UPS, which are depicted in figures 1 to figure 4.

In the case of paralleled AC UPS systems there can be an aditional control unit (device) which controls parallel operation of the AC UPS systems. Parallel operation of UPS systems is outside the scope of the present document.

Mandatory and non-mandatory monitoring/supervision information and functions for On-line AC UPS and Modular On-line AC UPS are given in annex A.

Mandatory and non-mandatory monitoring/supervision information and functions for Off-line AC UPS are given in annex B.

Mandatory and non-mandatory monitoring/supervision information and functions for Line-interactive AC UPS are given in annex C.




Figure 1: On-line AC UPS - normal operation






Figure 2: Off-line AC UPS - normal operation



NOTE 1: Battery can be central, or each module can have own battery.

NOTE 2: SBS can be central, or each module can have own SBS.

Figure 3: Modular On-line AC UPS - normal operation



NOTE 1: Rectifier and inverter in operation. Inverter synchronized to mains supply but not carrying load current.

NOTE 2: Bold lines indicate the load current path.

Figure 4: Line-interactive AC UPS - normal operation

#### The main elements of AC UPS power systems are:

- rectifier that converts AC voltage to DC voltage (i.e. 230 VAC/400VAC to DC voltage);
- battery (one or more strings of cells) that stores energy and can power the loads when AC interrupts or rectifiers fail. There can be test and permanent battery monitoring systems to reduce the failure detection time and the MTTR;
- protection and distribution (DC bus, breaker, etc.) to power different user loads and discriminate faults;
- inverter that converts DC voltage to AC voltage (i.e. DC voltage to 230 VAC/400VAC);
- Static Bypass Switch (SBS) monitors output and input voltage (mains AC voltage) of UPS, and synchronizes UPS output voltage to the input voltage, or transfers theinput voltage to the output to supply Current using equipment;
- External (Manual) Bypass that transfers input voltage to the output to supply Current using equipment, in the case of UPS failure, UPS service, maintenance, etc.;
- a system monitoring and control unit (XCU) to monitor voltage, current, power, temperature etc, extend alarms and provide system control functionality.

NOTE: In Modular On-line AC UPS power system, each module is consist of rectifier and inverter. Construction of the AC UPS module can be 1 phase input/1 phase output and 3 phases input/3 phases output. Modular On-line AC UPS power system can be 1 phase input/1 phase output, 3 phases input/1 phases output and 3 phases input/3 phases output.

Several measurements are possible: UPS input parameters: voltages, current, frequency, power, Power Factor (PF), etc., UPS output parameters: voltages, current, frequency, power, Power Factor (PF), etc., battery parameters: voltage, current andtemperature, etc.

Several controls are possible: to adjust rectifier voltage and battery current, to start a battery test procedure, to adjust output UPS voltage and frequency, etc.

# Summary of possible alarms, events, data, data records, configuration and control with explanation for AC UPS power system

In table 1 are given possible alarms, events, data, data records, configuration and control with explanation for AC UPS power system.

The "Explanation" column provided in the following data tables has been used where necessary to further explain the statements in the "Monitored information" column. The "Element type" column gives the assigned name used in XML coding and the "Monitored information" column provides details of the condition or state being monitored. The identifiers used in the Type column of the following tables are described in ES 202 336-1 [1].

NOTE: There can be others alarm, event, data, data record, configuration and control for an AC UPS power system, but they are not under the scope of the present document.

Annex A standardizes alarms, events, data, data records, configuration and control for an On-line AC UPS. Table A.1 corresponds to mandatory and non-mandatory data that shall be provided for an On-line AC UPS and Modular On-line AC UPS in different configurations (1 phase input/1 phase output, 3 phases input/1 phase output and 3 phases input/3 phases output).

Annex B standardizes alarms, events, data, data records, configuration and control for a Off-line AC UPS. Table B.1 corresponds to mandatory and non-mandatory data that shall be provided for an Off-line AC UPS.

Annex C standardizes alarms, events, data, data records, configuration and control for Line-interactive AC UPS. Table C.1 corresponds to mandatory and non-mandatory data that shall be provided for a Line-interactiveAC UPS.

Tables A.1, B.1 and C.1 will have the necessary information for specific AC UPS systems, such as: On-line, Modular On-line, Off-line and Line-interactive.

Each table summarizes mandatory (normative) and non-mandatory (informative) monitoring/supervision information and functions of different AC UPS power systems.

Annex D standardizes XML coding structures for these data.

Table 1: possible alarm, event, data, data record, configuration and control

Element type	Monitored information	Explanation
Description	Device description (hardware and software)	
	Battery circuit protection	DC fuse or circuit breaker tripped or in open position
	Battery discharge (e.g. due to mains loss, mains out of limits or not enough UPS power)	
	Battery in charging mode	
	Battery in BOOST charging mode	Voltage level for fast battery charging, e.g. 2,35 V/cell
	Battery test failure	Battery failed to pass defined test criteria e.g. autonomy time, voltage threshold
alarm	Battery replacement needed (based on time counters or specific conditions)	
	Battery over-temperature	Battery temperature exceeds high limit setting
	Float voltage out of limits (e.g. relative to temperature)	Output DC voltage from rectifier
	Low Voltage Disconnect open (active)	When there is a battery or load disconnecting device the alarm indicates the disconnection has occurred

Element type	Monitored information	Explanation
Description	Device description (hardware and software)	
	Low DC shutdown voltage (LVD)	Battery discharged to minimum permissible level
	Low DC warning voltage	Battery nearly discharged
	Earth leakage detection on high voltage battery	
	Earthing of one battery pole	in case any battery poles are not grounded
	Battery temperature out of limits (jar or ambient lead acid batteries)	
	Battery temperature sensor failure	This sensor is for example placed on the battery jar or close to the battery
	Unbalanced discharge branch current	
	Unbalanced charge branch current	
	Cribalariood charge branch current	
	Absongs of input voltage or input voltage is out from limited values	_
	Absence of input voltage or input voltage is out from limited values	
	Short circuit and overload at the output of UPS	
	Peak current limiter active	Peak current limiter activated and UPS switched to bypass operation
	Absence of output voltage or output voltage is out from limited values	
	Output frequency is out from limited values	
	Temperature of UPS is out of limit (internal UPS temperature out of limit)	UPS temperature exceeds high limit setting
	Static by-pass in normal operation	
	Failure on static by-pass	
	Bypass out of tolerance	Bypass input voltage outside tolerance
	Synchronization error	UPS unable to synchroniyze with input frequency
	Load is supplied from static by-pass	
	Load is supplied from manual by-pass	
	Signalization of proper work of UPS	
	Failure of UPS	
	Failure of rectifier	
	Failure of inverter	M
	Signalization of proper work of UPS module Failure of UPS module	In Modular On-line AC UPS In Modular On-line AC UPS
	Failure of OPS module	In Modular On-line AC UPS
	Failure of inverter in UPS module	In Modular On-line AC UPS
	Output UPS circuit protection	AC fuse or circuit breaker tripped or in open position
	Forced cooling failure (fan failure)	In case of UPS forced cooling
	Forced cooling failure (fan failure) of specific UPS module	In Modular On-line AC UPS
	Alarm set and clear (data log)	Ohanna at
	Details of any change of configuration and parameters of UPS	Change of parameter e.g. float voltage change, output voltage change
event	Change of UPS operating mode	Change of operation e.g. Boost charge , load supplied from static by-pass, battery test
	Battery test execution report	
	Status change or fast repetition (charge-discharge event)	
	Indication of restart with back-up or customized parameters (auto-recovery in case of Control Unit reset or replacement)	
	power interconnection	
	powor interconnection	<u> </u>

Element type	Monitored information	Explanation
Description	Device description (hardware and software)	
	Input phase AC voltage (±2 V)	Phases L1, L2, L3 for 3 phases input UPS
	Input line AC voltage (±2 V)	Line L1-L2; L1-L3; L2-L3 for 3 phases input UPS
	Input AC current (±2 %)	Current in phases L1, L2 and L3 for 3 phases input UPS
	Input AC current (±2 %) of each UPS module Input frequency (±0,1 Hz)	In Modular On-line AC UPS
	Input power factor	
	Input active power	In W
	Input reactive power	In VAr
	input reactive power	In VA. Can be calculated as
	Total Input power	$S = sqrt (P^2 + Q^2)$
	Total harmonic current distortion at the UPS input	In %, or in A per harmonics
	Output phase AC voltage (±2 V)	Phases L1, L2, L3 for 3 phases output UPS
	Output line AC voltage (±2 V)	Line L1-L2; L1-L3; L2-L3 for 3 phases output UPS
	Output AC current (±2 %)	Current in phases L1, L2 and L3 for 3 phases output UPS
	Output AC current (±2 %) of each UPS module	In Modular On-line AC UPS
	Average value of AC output load current I <sub>AV</sub> (±5 %) over a preset	
	time window	
	Output frequency (±0,1 Hz)	
	Output power factor	
	Output active power	In W
	Output reactive power	In VAr
data	Total output power	In VA. Can be calculated as $S = sqrt(P^2 + Q^2)$
	Total harmonic voltage distortion at the UPS output	In %, or in V per harmonics
	Static by-pass current (±2 %)	
	(== ,o,	
	Internal UPS temperature (±1 °C)	Measured at temperature critical place inside UPS e.g. on the heater with power components
	Room temperature (±1 °C)	Temperature in the room where the UPS is mounted
	Battery temperature (±1 °C)	
	Total Battery voltage ±1 V - this precision is required for floating voltage derating detection and temperature charge compensation (around -3 mV/K/cell).	DC voltage at the rectifier output
	Charge and discharge battery current I <sub>Batt</sub> (±1 %)	
	Battery branch current (±1 %)	
	Estimated remaining battery autonomy (time) during discharge	
	Battery age since date of installation	
	Estimated remaining battery capacity (due to ageing) at full charge (±5 %)	
	Power capacity management (ratio) = Used/Installed power	
	Battery discharge alarm duration	Time period over which battery is discharging e.g. caused by actual mains supply failure or insufficient output power from rectifiers
		due to failure

Element type	Monitored information	Explanation
Description	Device description (hardware and software)	
	Battery temperature	Battery temperature data log at 1 hour interval limited to a defined number of records
	AC output current	Average current data log e.g. at 5 min interval limited to a defined number of records
	AC output voltage	Voltage record e.g. at 1 hour interval limited to a defined number of records
data record	Output frequency	Average frequency data log e.g. at 5 min interval limited to a defined number of records
	Detailed battery test data record : discharge chart, temperature, string current, cell voltages	
	Input (AC) energy consumption over preset period	<u></u>
	AC output total power	This value can be calculated by the AC power system controller from AC output voltage and current measurements
	Date and time	
	Sliding time window to capture maximum output AC current All XCU alarm/event/test/command parameters (time-out, counter, thresholds, etc.)	Period of time over which power data logging is carried out
	Range of frequency synchronization	Range of input frequency when the output and input frequency are the same (max ±2,5 Hz)
	Low DC shutdown voltage (LVD)	
	Low DC warning voltage	
	Battery capacity	
	Output low voltage threshold	
config	Battery over-temperature threshold	+
	Unbalanced charge branchcurrent (persistent string branch charge current difference/mean string charge current value)	
	Unbalanced branch discharge current (persistent string branch	
	discharge current difference/mean string discharge current value)	
	battery test parameters	
	Output overload threshold (consumed power/ useful power where useful power is installed power without redundancy or battery	
	recharge power).	
	Maximum battery charging current	
	Battery charging voltage (boost, float voltage)	
	Battery life expectancy at 20 °C (as provided by manufacturer)	
	Any forced change of operating mode e.g. battery discharge test,	
	boost charge  XCU program download with default to previous release	
	Default values resetting (safe value for XCU)	
oont	Battery test on demand	
control	UPS power device control (rectifiers, inverter, static by-pass, Low	
	Voltage Disconnection, etc.)	N
	UPS module control	In Modular On-line AC UPS
	Acknowledge battery replacement Acknowledge alarms	
	promoting diaming	

# Annex A (normative):

# Summary of mandatory and non-mandatory monitoring/supervision information and functions for On-line AC UPS power systems

This annex gathers the information needed on the Remote Management Application (RMA) for different types of On-Line and Modular On-line AC UPS power system. It specifies the mandatory and not-mandatory requirements that must be provided in all cases.

NOTE 1: These tables do not specify the power equipment by itself. These tables refer to subsets or devices that are not necessarily present in each equipment configuration. As a matter of fact, one alarm and its class apply only in case of the presence of this subset or device.

When an optional alarm that requires a parameter set is present, the corresponding parameter set is mandatory in the control section in order to allow remote adjustment under appropriate login procedure.

According to their element type (Description, Alarm, Data, etc.), as defined in ES 202 336-1 [1] the information shall be provided by the Control Unit (XCU).

NOTE 2: If there is no XCU this data should be provided by the Data Gathering Unit (DGU).

When a CU has a field databus connected to the DGU, at least, the DGU shall store data (record measurements, log files). The XCU which has the XML interface over Ethernet TCP/IP, shall store these data.

- NOTE 3: Partial communication network failures e.g. XCU link fault should be detected by an upper element of the network e.g. the RMA (refer to figure 1 of ES 202 336-1 [1]).
- NOTE 4: Clause 9.4.4 of ES 202 336-1 [1] details the parameters associated with XML elements e.g. time delay, severity of alarm element. The tables below do not include the application of these parameters.
- NOTE 5: Table A.1 specifies mandatory and non-mandatory requirements for On-line and Modular On-line AC UPS power systems. **M** specified mandatory requirements and **NM** specified non-mandatory requirements. Blank fields means there is no requirements for specific type of AC UPS.

Table A.1

		On line AC UPS (MONOLITE)			Modular On line AC UPS	
Element type	Monitored information	1ph.in./ 1ph.out	3ph.in./ 1ph.out	3ph.in./ 3ph.out	1ph.in./ 1ph.out; 3ph.in./ 1ph.out	3ph.in./ 3ph.out
Description	Device description (hardware and software)					
	Battery circuit protection	NM	NM	M	М	М
	Battery discharge (e.g. due to mains loss, mains out of limits or not enough UPS power)	М	М	М	М	М
	Battery in charging mode	NM	NM	М	М	М
	Battery in BOOST charging mode	NM	NM	NM	NM	NM
	Battery test failure	M	M	M	M	М
	Battery replacement needed (based on time counters or specific conditions)	NM	NM	М	М	М
alarm	Battery over-temperature	MN	М	M	М	М
alailii						
	Float voltage out of limits (e.g. relative to temperature)	NM	М	М	М	М
	Low Voltage Disconnect open (active)	NM	NM	M	М	М
	Low DC shutdown voltage (LVD)	M	М	M	M	М
	Low DC warning voltage	NM	NM	NM	NM	NM
	Earth leakage detection on high voltage battery	NM	NM	NM	NM	NM
	Earthing of one battery pole	NM	NM	NM	NM	NM

	Monitored information	_	line AC U	-	Modular On line AC UPS	
Element type		1ph.in./ 1ph.out	3ph.in./ 1ph.out	3ph.in./ 3ph.out	1ph.in./ 1ph.out; 3ph.in./ 1ph.out	3ph.in./ 3ph.out
Description	Device description (hardware and software)					
	Battery temperature out of limits (jar or ambient lead acid batteries)	NM	NM	М	М	М
	Battery temperature sensor failure	NM	NM	М	NM	M
	Unbalanced discharge branch current	NM	NM	NM	NM	NM
	Unbalanced charge branch current	NM	NM	NM	NM	NM
	- Hadian on a go and had a go					
	Absence of input voltage or input voltage is out from limited values	М	М	М	М	М
	Short circuit and overload at the output of UPS	М	М	М	М	М
	Peak current limiter active	NM	NM	NM	NM	NM
	Absence of output voltage or output voltage is out from limited values	М	М	М	М	М
	Output frequency is out from limited values	NM	М	М	М	М
	Temperature of UPS is out of limit (internal UPS temperature out of limit)	NM	NM	М	М	М
	Static by-pass is in normal operation	NM	NM	М	М	М
	Failure on static by-pass	NM	М	М	М	М
	Bypass out of tolerance	NM	М	М	М	М
	Synchronization error	NM	М	М	М	М
	Load is supplied from static by-pass	М	М	М	М	М
	Load is supplied from manual by-pass	NM	NM	М	М	М
	Signalization of proper work of UPS	М	М	M	M	М
	Failure of UPS	М	М	M	M	М
	Failure of rectifier	NM	NM	М		
	Failure of inverter	NM	NM	M		
	Signalization of proper work of UPS module				M	М
	Failure of UPS module				M	М
	Failure of rectifier in UPS module				NM	NM
	Failure of inverter in UPS module				NM	NM
	Output UPS circuit protection	NM	NM	M	M	M
	Forced cooling failure (fan failure)	NM	NM	M	М	М
	Forced cooling failure (fan failure) of specific UPS module				NM	М
	Alarm set and clear (date log)	NM	М	М	М	М
	Details of any change of configuration and parameters of UPS	NM	М	М	М	М
	Change of UPS operating mode	NM	NM	М	М	М
	Battery test execution report	NM	NM	М	М	М
event	Status change or fast repetition (charge-discharge event)	NM	NM	М	М	М
	Indication of restart with back-up or customized parameters (auto-recovery in case of Control Unit reset or replacement)	NM	NM	М	М	М
	Power interconnection	NM	NM	М	NM	М

			line AC U		Mod On line	
Element type	Monitored information	1ph.in./ 1ph.out	3ph.in./ 1ph.out	3ph.in./ 3ph.out	1ph.in./ 1ph.out; 3ph.in./ 1ph.out	3ph.in./ 3ph.out
Description	Device description (hardware and software)					
	Input phase AC voltage (±2 V)	NM	М	M	М	M
	Input line AC voltage (±2 V)		М	М	NM	М
	Input AC current (±2 %)	NM	NM	М	NM	M
	Input AC current (±2 %) of each UPS module				NM	NM
	Input frequency (±0,1 Hz)	NM	NM	M	M	M
	Input power factor	NM	NM	NM	NM	NM
	Input active power	NM	NM	NM	NM	NM
	Input reactive power	NM	NM	NM	NM	NM
	Total Input power	NM	NM	M	M	M
	Total harmonic current distortion at the UPS input Output phase AC voltage (±2 V)	NM NM	NM M	NM M	NM M	NM M
	Output line AC voltage (±2 V)	INIVI	IVI	M	IVI	M
	Output AC current (±2 %)	NM	М	M	М	M
	Output AC current (±2 %) of each UPS module	INIVI	IVI	IVI	M	M
	Average value of AC output load current I <sub>Av</sub> (±5 %) over a preset time window	NM	NM	NM	NM	NM
	Output frequency (±0,1 Hz)	NM	М	М	М	М
	Output power factor	NM	NM	M	NM	M
	Output active power	NM	NM	M	NM	M
	Output reactive power	NM	NM	NM	NM	NM
	Output power	NM	М	М	М	М
data	Total harmonic voltage distortion at the UPS output	NM	NM	NM	NM	NM
data	Static by-pass current (±2 %)	NM	NM	М	NM	М
	Internal UPS temperature (±1 °C)	NM	M	М	М	M
	Room temperature (±1 °C)	NM	NM	NM	NM	NM
	Battery temperature (±1 °C)	NM	NM	М	NM	M
	Total Battery voltage (±1 V) - this precision is required for floating voltage derating detection and temperature charge compensation (around -3 mV/K/cell).	NM	М	М	М	М
	Charge and discharge battery current I <sub>Batt</sub> (±1 %)	NM	М	М	М	М
	Battery branch current (±1 %)	NM	NM	NM	NM	NM
	Estimated remaining battery autonomy (time) during discharge	NM	NM	М	М	М
	Battery age since date of installation	NM	NM	NM	NM	NM
	Estimated remaining battery capacity (due to ageing) at full charge (±5 %)	NM	NM	М	NM	М
	Power capacity management (ratio) = Used/Installed power	NM	NM	NM	NM	NM
	Battery discharge alarm duration	NM	NM	М	NM	М
	XCU program download with default to previous release	NM	NM	М	NM	М
	Battery temperature	NM	NM	М	М	М
	AC output current	NM	NM	М	М	М
	AC output voltage	NM	NM	М	M	М
data record	Output frequency	NM	NM	М	М	М
10001d	Detailed battery test data record : discharge chart, temperature, string current, cell voltages	NM	NM	NM	NM	NM
	Input (AC) energy consumption over preset period	NM	NM	NM	NM	NM
	AC output total power	NM	NM	M	M	M

	Monitored information	On line AC UPS (MONOLITE)			Modular On line AC UPS	
Element type		1ph.in./ 1ph.out	3ph.in./ 1ph.out	3ph.in./ 3ph.out	1ph.in./ 1ph.out; 3ph.in./ 1ph.out	3ph.in./ 3ph.out
Description	Device description (hardware and software)					
	Date and time Sliding time window to capture maximum output AC current All XCU alarm/event/test/command parameters (time-out, counter, thresholds, etc.) Range of frequency synchronization	NM NM	NM NM	M M	NM NM	M M
	Low DC shutdown voltage	M	M	M	M	M
	Low DC warning voltage	NM	NM	NM	NM	NM
	Battery capacity	NM	NM	M	M	M
	Output low voltage threshold	NM	M	M	M	M
	Battery over-temperature threshold	NM	NM	М	М	М
config	Unbalanced charge branch current (persistent string branch charge current difference/mean string charge current value)	NM	NM	NM	NM	NM
	Unbalanced branch discharge current (persistent string branch discharge current difference/mean string discharge current value)	NM	NM	NM	NM	NM
	battery test parameters Output overload threshold (consumed power/ useful	NM	NM	M	NM	M
	power where useful power is installed power without redundancy or battery recharge power)	NM	NM	NM	NM	NM
	Maximum battery charging current	NM	М	М	М	M
	Battery charging votage (boost, float voltage)	NM	NM	М	М	М
	Battery life expectancy at 20 °C (as provided by battery manufacturer)	NM	NM	NM	NM	NM
	Any forced change of operating mode e.g. battery discharge test, boost charge	NM	NM	М	М	М
	XCU program download with default to previous release	NM	NM	М	М	М
	Default values resetting (safe value for XCU)	NM	М	M	М	M
control	Battery test on demand	NM	NM	М	М	M
	UPS power device control (rectifiers, inverter, static by-pass, Low Voltage Disconnection, etc)	NM	NM	М	М	М
	UPS module control				М	M
	Acknowledge battery replacement	NM	NM	М	М	М
	Acknowledge alarms	NM	NM	NM	NM	NM

## Annex B (normative):

# Summary of mandatory and non-mandatory monitoring/supervision information and functions for Off-line AC UPS power systems

This annex gathers the information needed on the Remote Management Application (RMA) for Off-Line AC UPS power system. It specifies the mandatory and not-mandatory requirements that must be provided in all cases.

NOTE 1: These tables do not specify the power equipment by itself. These tables refer to subsets or devices that are not necessarily present in each equipment configuration. As a matter of fact, one alarm and its class apply only in case of the presence of this subset or device.

When an optional alarm that requires a parameter set is present, the corresponding parameter set is mandatory in the control section in order to allow remote adjustment under appropriate login procedure.

According to their element type (Description, Alarm, Data, etc.), as defined in ES 202 336-1 [1] the information shall be provided by the Control Unit (XCU).

NOTE 2: If there is no XCU this data should be provided by the Data Gathering Unit (DGU).

When a CU has a field databus connected to the DGU, at least, the DGU shall store data (record measurements, log files). The XCU which has the XML interface over Ethernet TCP/IP, shall store these data.

- NOTE 3: Partial communication network failures e.g. XCU link fault should be detected by an upper element of the network e.g. the RMA (refer to figure 1 of ES 202 336-1 [1]).
- NOTE 4: Clause 9.4.4 of ES 202 336-1 [1] details the parameters associated with XML elements e.g. time delay, severity of alarm element. The tables below do not include the application of these parameters.
- NOTE 5: Table B.1 specifies mandatory and non-mandatory requirements for Off-line AC UPS power systems.

  M specified mandatory requirements and NM specified non-mandatory requirements. Blank fields means there is no requirements for specific type of UPS.

Table B.1

Element type	Monitored information	Off-line AC UPS	
Description	Description Device description (hardware and software)		
	Battery circuit protection	NM	
	Battery discharge (e.g. due to mains loss, mains out of limits or not enough UPS power)	М	
	Battery in charging mode	М	
	Battery in BOOST charging mode	NM	
	Battery test failure	NM	
	Battery replacement needed (based on time counters or specific conditions)	NM	
	Battery over-temperature	NM	
	Float voltage out of limits (e.g. relative to temperature)	NM	
alarm	Low Voltage Disconnect open (active)	NM	
	Low DC shutdown voltage(LVD)	M	
	Low DC warning voltage	NM	
	Earth leakage detection on high voltage battery	NM	
	Earthing of one battery pole	NM	
	Battery temperature out of limits (jar or ambient lead acid batteries)	М	
	Battery temperature sensor failure	NM	
	Unbalanced discharge branch current	NM	
	Unbalanced charge branch current	NM	

Element type	ement type Monitored information			
Description	Device description (hardware and software)			
	Absence of input voltage or input voltage is out from limited values	М		
	Short circuit and overload at the output of UPS	NM		
	Absence of output voltage or output voltage is out from limited values	M		
	Output frequency is out from limited values	M		
	Temperature of UPS is out of limit (internal UPS temperature out of limit)	NM		
	Static by-pass is in normal operation	NM		
	Failure on static by-pass	NM		
	Load is supplied from static by-pass (normal working operation)	NM		
	Load is supplied from inverter	NM		
	Load is supplied from manual by-pass	NM		
	Signalization of proper work of UPS	M		
	Failure of UPS	M		
	Failure of rectifier	NM		
	Failure of inverter	NM		
	Output UPS circuit protection	NM		
	Forced cooling failure (fan failure)	NM		
	Alarm set and clear (data log)	M		
	Details of any change of configuration and parameters of UPS	M		
	Change of UPS operating mode	M		
event	Battery test execution report	NM		
	Status change or fast repetition (charge-discharge event)	NM		
	Indication of restart with back-up or customized parameters (auto-recovery	NM		
	in case of Control Unit reset or replacement)			
	power interconnection	NM		
	Input phase AC voltage (±2 V)	M		
	Input line AC voltage (±2 V)	NM		
	Input AC current (±2 %)	M		
	Input frequency (±0,1 Hz)	M		
	Input power factor	NM		
	Input active power	NM		
	Input reactive power	NM		
	Total Input power	NM		
	Total harmonic current distortion at the UPS input	NM		
	output phase AC voltage (±1 V)	M		
	output line AC voltage (±1 V)	NM		
	output AC current (±2 %)	М		
	Average value of AC output load current I <sub>Av</sub> (±5 %) over a preset time	NM		
	window			
	Output frequency (±0,1 Hz)	M		
	Output power factor	NM		
	Output active power	NM		
data	Output reactive power	NM		
	Total Output power	NM		
	Total harmonic voltage distortion at the UPS output	NM		
	Static by-pass current (±2 %)	NM		
	Internal UPS temperature (±1 °C)	NM		
	Room temperature (±1 °C)	NM		
	Battery temperature (±1 °C)	NM		
	Total Battery voltage ±1 V	N 4		
	- this precision is required for floating voltage derating detection and	М		
	temperature charge compensation (around -3 mV/K/cell).			
	Charge and discharge battery current I <sub>Batt</sub> (±1 %)	M		
	Battery string current (±1 %)	NM		
	Estimated remaining battery autonomy (time) during discharge	NM		
	Battery age since date of installation	NM		
	Estimated remaining battery capacity (due to ageing) at full charge (±5 %)	NM		
	Power capacity management (ratio) = Used/Installed power	NM		
	Battery discharge alarm duration	NM		
	XCU program download with default to previous release	NM		
	1 1 - 3 22 22 25 27 28 28 28 28 28			

Element type				
Description	Device description (hardware and software)			
	Battery temperature	NM		
	AC output current	NM		
	AC output voltage	NM		
data record	Output frequency	NM		
uata recoru	Detailed battery test data record: discharge chart, temperature, string current, cell voltages	NM		
	Input (AC) energy consumption over preset period	NM		
	AC output power	NM		
	Date and time	M		
	Sliding time window to capture maximum output AC current All XCU alarm/event/test/command parameters (time-out, counter, thresholds, etc.)	NM		
	Low DC shutdown voltage	M		
	Low DC warning voltage	NM		
	Battery capacity	NM		
	Output low voltage threshold	NM		
	Battery over-temperature threshold	NM		
config	Unbalanced charge branch current (persistent string branch charge current difference/mean string charge current value)	NM		
	Unbalanced branchdischarge current (persistent string branch discharge current difference/mean string discharge current value)	NM		
	battery test parameters	NM		
	Output overload threshold (consumed power/useful power where useful power is installed power without redundancy or battery recharge power)	NM		
	Maximum battery charging current	M		
	Baterry charging voltage	NM		
	Battery life expectancy at 20 °C (as provided by manufacturer)	NM		
	Any forced change of operating mode e.g. battery discharge test, boost charge	М		
control	XCU program download with default to previous release	М		
	Default values resetting (safe value for XCU)	М		
	Battery test on demand	NM		
	UPS power device control (rectifiers, inverter, static by-pass, Low Voltage Disconnection, etc.)	NM		
	Acknowledge battery replacement	NM		
	Acknowledge alarms	NM		

# Annex C (normative):

# Summary of mandatory and non-mandatory monitoring/supervision information and functions for Line-interactiv AC UPS power systems

This annex gathers the information needed on the Remote Management Application (RMA) for different types of Line-interactiv AC UPS power system. It specifies the mandatory and not-mandatory requirements that must be provided in all cases.

NOTE 1: These tables do not specify the power equipment by itself. These tables refer to subsets or devices that are not necessarily present in each equipment configuration. As a matter of fact, one alarm and its class apply only in case of the presence of this subset or device.

When an optional alarm that requires a parameter set is present, the corresponding parameter set is mandatory in the control section in order to allow remote adjustment under appropriate login procedure.

According to their element type (Description, Alarm, Data, etc.), as defined in ES 202 336-1 [1] the information shall be provided by the Control Unit (XCU).

NOTE 2: If there is no XCU this data should be provided by the Data Gathering Unit (DGU).

When a CU has a field databus connected to the DGU, at least, the DGU shall store data (record measurements, log files). The XCU which has the XML interface over Ethernet TCP/IP, shall store these data.

- NOTE 3: Partial communication network failures e.g. XCU link fault should be detected by an upper element of the network e.g. the RMA (refer to figure 1 of ES 202 336-1 [1]).
- NOTE 4: Clause 9.4.4 of ES 202 336-1 [1] details the parameters associated with XML elements e.g. time delay, severity of alarm element. The tables below do not include the application of these parameters.
- NOTE 5: Table C.1 specifies mandatory and non-mandatory requirements for Line-interactive AC UPS power systems. **M** specified mandatory requirements and **NM** specified non-mandatory requirements. Blank fields means there is no requirements for specific type of UPS.

Table C.1

Description   Device description (hardware and software)	Element type	Lline-interactive AC UPS	
Battery discharge (e.g. due to mains loss, mains out of limits or not enough UPS power)  Battery in charging mode  Battery in charging mode  Battery replacement needed (based on time counters or specific conditions)  Battery over-temperature  Float voltage out of limits (e.g. relative to temperature)  Low Voltage Disconnect open (active)  Low DC shutdown voltage  Earth leakage detection on high voltage battery  Battery temperature out of limits (jar or ambient lead acid batteries)  MMEattery temperature sensor failure  Inhalanced discharge branch current  Unbalanced discharge branch current  Unbalanced charge branch current  Absence of input voltage or input voltage is out from limited values  M Output frequency is out from limited values  M Output frequency is out from limited values  M Temperature of UPS is out of limit Internal UPS temperature out of limit)  M Static by-pass is in normal operation  Failure on static by-pass  Synchronization error  Load is supplied from static by-pass (normal working operation)  M Eailure of UPS  M Failure of UPS  M Failure of inverter  M M Failure of inverter  M M Failure of inverter  NM Failure of UPS  M Failure of inverter  M M Failure of inverter  M M Failure of inverter  NM Failure of proper work of UPS  M Failure of inverter  NM Failure of proper work of UPS  M Battery text execution report  M M Battery text execution report  M M Battery text execution report  NM M Battery text execution repor	scription	Device description (hardware and software)	
IUPS power) Battery in charging mode Battery in BOOST charging mode Battery test failure Battery test failure Battery restrictions Battery over-temperature  Float voltage out of limits (e.g. relative to temperature)  M  Float voltage out of limits (e.g. relative to temperature)  Low Voltage Disconnect open (active) Low DC shutdown voltage M Low DC warning voltage Battery temperature out of limits (jar or ambient lead acid batteries)  Battery temperature out of limits (jar or ambient lead acid batteries)  NM  Battery temperature sensor failure  NM  Unbalanced discharge branch current  Unbalanced charge branch current  NM  Absence of input voltage or input voltage is out from limited values  Short circuit and overload at the output of UPS  Absence of output voltage or output voltage is out from limited values  M  Output frequency is out from limited values  Temperature of UPS is out of limit Internal UPS temperature out of limit)  Static by-pass is in normal operation  Failure on static by-pass  Synchronization error  Load is supplied from static by-pass (normal working operation)  M  Signalization of proper work of UPS  Failure of Inverter  Load is supplied from manual by-pass  Failure of IUPS  Failure of IUPS  Failure of IVPS  Failure of IVPS operating mode  M  Change of UPS operating mode  M  Battery test execution report  NM	E	Battery circuit protection	M
Battery in BOOST charging mode Battery test failure Battery replacement needed (based on time counters or specific conditions) NM Battery over-temperature  Float voltage out of limits (e.g. relative to temperature)  Low Voltage Disconnect open (active) Low DC shutdown voltage Meanth leakage detection on high voltage battery Battery temperature out of limits (jar or ambient lead acid batteries) NM Battery temperature sensor failure  Inbalanced discharge branch current Unbalanced discharge branch current Unbalanced charge branch current NM Absence of input voltage or input voltage is out from limited values Moutput frequency is out from limited values Moutput UPS is out of limit Internal UPS temperature out of limit) Moutput December of UPS Moutput December of UPS Moutput UPS circuit protection Moutput December of UPS Moutput Moutput December of UPS Moutput Moutput Moutput Moutput Moutput Moutput Moutput Moutput Moutput Moutp	L	JPS power)	М
Battery in BOOST charging mode Battery test failure Battery replacement needed (based on time counters or specific conditions) NM Battery over-temperature  Float voltage out of limits (e.g. relative to temperature)  Low Voltage Disconnect open (active) Low DC shutdown voltage Meanth leakage detection on high voltage battery Battery temperature out of limits (jar or ambient lead acid batteries) NM Battery temperature sensor failure  Inbalanced discharge branch current Unbalanced discharge branch current Unbalanced charge branch current NM Absence of input voltage or input voltage is out from limited values Moutput frequency is out from limited values Moutput UPS is out of limit Internal UPS temperature out of limit) Moutput December of UPS Moutput December of UPS Moutput UPS circuit protection Moutput December of UPS Moutput Moutput December of UPS Moutput Moutput Moutput Moutput Moutput Moutput Moutput Moutput Moutput Moutp	E	Battery in charging mode	M
Battery replacement needed (based on time counters or specific conditions) Battery over-temperature  Float voltage out of limits (e.g. relative to temperature)  Low Voltage Disconnect open (active)  Low DC shutdown voltage  Low DC warning voltage  Earth leakage detection on high voltage battery  Battery temperature out of limits (jar or ambient lead acid batteries)  NM  Battery temperature sensor failure  Unbalanced discharge branch current  Unbalanced discharge branch current  NM  Absence of input voltage or input voltage is out from limited values  Short circuit and overload at the output of UPS  NM  Absence of output voltage or output voltage is out from limited values  M  Output frequency is out from limited values  Temperature of UPS is out of limit Internal UPS temperature out of limit)  M Static by-pass is in normal operation  Failure on static by-pass  NM  Synchronization error  NM  Load is supplied from inverter  Load is supplied from static by-pass (normal working operation)  M Load is supplied from manual by-pass  Failure of UPS  Failure of UPS  M  Failure of inverter  Output UPS circuit protection  M  Failure of inverter  NM  Alarm set and clear (data log)  Details of any change of configuration and parameters of UPS  M  Battery test execution report  NM			NM
Battery over-temperature			NM
Float voltage out of limits (e.g. relative to temperature)  Low Voltage Disconnect open (active)  Low DC shutdown voltage  Earth leakage detection on high voltage battery  Earth leakage detection on high voltage battery  Earthing of one battery pole  Battery temperature out of limits (jar or ambient lead acid batteries)  NM  Battery temperature sensor failure  NM  Unbalanced discharge branch current  Unbalanced charge branch current  NM  Absence of input voltage or input voltage is out from limited values  M Short circuit and overload at the output of UPS  NM  Absence of output voltage or output voltage is out from limited values  M Output frequency is out from limited values  M Temperature of UPS is out of limit Internal UPS temperature out of limit)  M Static by-pass is in normal operation  Failure on static by-pass  NM  Synchronization error  Load is supplied from static by-pass (normal working operation)  M Load is supplied from manual by-pass  NM  Signalization of proper work of UPS  Failure of UPS  M Failure of inverter  Output UPS circuit protection  Forced cooling failure (fan failure)  M Alarm set and clear (data log)  Details of any change of configuration and parameters of UPS  M Battery test execution report  NM  NM  Battery test execution report	E	Battery replacement needed (based on time counters or specific conditions)	NM
Low Voltage Disconnect open (active) Low DC shutdown voltage Low DC warning voltage Earth leakage detection on high voltage battery Earth leakage detection on high voltage battery NM Earthing of one battery pole NM Battery temperature out of limits (jar or ambient lead acid batteries) NM Battery temperature sensor failure NM Unbalanced discharge branch current NM Unbalanced charge branch current NM Absence of input voltage or input voltage is out from limited values NM Absence of output voltage or output voltage is out from limited values M Coutput frequency is out from limited values M Temperature of UPS is out of limit Internal UPS temperature out of limit) NM Failure on static by-pass NM Synchronization error Load is supplied from static by-pass (normal working operation) NM Load is supplied from manual by-pass NNM Signalization of proper work of UPS Failure of UPS M Failure of UPS M Failure of inverter Output UPS circuit protection NM Failure of inverter NM Output UPS circuit protection M Forced cooling failure (fan failure) Alarm set and clear (data log) Details of any change of configuration and parameters of UPS M Change of UPS operating mode M Battery test execution report NM Battery test execution report	E	3attery over-temperature	M
Low DC shutdown voltage			M
Low DC warning voltage Earth leakage detection on high voltage battery Earthing of one battery pole NM Battery temperature out of limits (jar or ambient lead acid batteries) NM Battery temperature sensor failure NM Unbalanced discharge branch current Unbalanced charge branch current NM Absence of input voltage or input voltage is out from limited values NM Absence of output voltage or output voltage is out from limited values NM Absence of output voltage or output voltage is out from limited values NM Temperature of UPS is out of limit Internal UPS temperature out of limit) NM Static by-pass is in normal operation NM Failure on static by-pass NM Synchronization error NM Load is supplied from static by-pass (normal working operation) M Load is supplied from manual by-pass NM Signalization of proper work of UPS M Failure of UPS M Failure of IPS M Failure of inverter NM Failure of inverter NM Output UPS circuit protection M Forced cooling failure (fan failure) M Alarm set and clear (data log) Details of any change of configuration and parameters of UPS M Battery test execution report NM Battery test execution report	L	Low Voltage Disconnect open (active)	M
Earth leakage detection on high voltage battery Earthing of one battery pole Battery temperature out of limits (jar or ambient lead acid batteries) NM Battery temperature sensor failure  Unbalanced discharge branch current Unbalanced charge branch current NM  Absence of input voltage or input voltage is out from limited values Mont circuit and overload at the output of UPS NM Absence of output voltage or output voltage is out from limited values Moutput frequency is out from limited values Moutput on static by-pass in normal operation Moutput on static by-pass Moutput lead is supplied from inverter Moutput of inverter Moutput OPS Moutput OPS Failure of rectifier NM Failure of inverter NM Alarm set and clear (data log) Details of any change of configuration and parameters of UPS Moutput Mo			1
Earthing of one battery pole Battery temperature out of limits (jar or ambient lead acid batteries) NM Battery temperature sensor failure NM Unbalanced discharge branch current Unbalanced charge branch current NM Absence of input voltage or input voltage is out from limited values NM Short circuit and overload at the output of UPS NM Absence of output voltage or output voltage is out from limited values M Output frequency is out from limited values M Temperature of UPS is out of limit Internal UPS temperature out of limit) NM Static by-pass is in normal operation NM Failure on static by-pass NM Synchronization error Load is supplied from static by-pass (normal working operation) M Load is supplied from manual by-pass NM Signalization of proper work of UPS Failure of ectifier NM Failure of rectifier NM Failure of inverter NM Output UPS circuit protection M Forced cooling failure (fan failure) Alarm set and clear (data log) Details of any change of configuration and parameters of UPS M Battery test execution report NM Datatt Battery test execution report NM NM			
Battery temperature out of limits (jar or ambient lead acid batteries)  Battery temperature sensor failure  Unbalanced discharge branch current  Unbalanced charge branch current  NM  Absence of input voltage or input voltage is out from limited values  Short circuit and overload at the output of UPS  NM  Absence of output voltage or output voltage is out from limited values  M  Output frequency is out from limited values  M  Temperature of UPS is out of limit Internal UPS temperature out of limit)  Static by-pass is in normal operation  Failure on static by-pass  NM  Synchronization error  Load is supplied from static by-pass (normal working operation)  M  Load is supplied from inverter  M  Load is supplied from manual by-pass  NM  Signalization of proper work of UPS  Failure of UPS  Failure of rectifier  NM  Failure of rectifier  NM  Output UPS circuit protection  Forced cooling failure (fan failure)  Alarm set and clear (data log)  Details of any change of configuration and parameters of UPS  M  Change of UPS operating mode  Battery test execution report  NM  NM			1
alarm  Unbalanced discharge branch current Unbalanced charge branch current Unbalanced charge branch current  Absence of input voltage or input voltage is out from limited values Short circuit and overload at the output of UPS Absence of output voltage or output voltage is out from limited values M Output frequency is out from limited values M Temperature of UPS is out of limit Internal UPS temperature out of limit) M Static by-pass is in normal operation Failure on static by-pass NM Synchronization error NM Load is supplied from static by-pass (normal working operation) M Load is supplied from manual by-pass Signalization of proper work of UPS Failure of UPS Failure of rectifier Failure of inverter NM Output UPS circuit protection Forced cooling failure (fan failure) Alarm set and clear (data log) Details of any change of configuration and parameters of UPS M Change of UPS operating mode M Battery test execution report NM			
Unbalanced discharge branch current Unbalanced charge branch current NM  Absence of input voltage or input voltage is out from limited values Short circuit and overload at the output of UPS NM Absence of output voltage or output voltage is out from limited values M Output frequency is out from limited values M Temperature of UPS is out of limit Internal UPS temperature out of limit) M Static by-pass is in normal operation Failure on static by-pass NM Synchronization error NM Load is supplied from static by-pass (normal working operation) M Load is supplied from inverter M Load is supplied from manual by-pass NM Signalization of proper work of UPS M Failure of UPS M Failure of inverter NM Output UPS circuit protection Forced cooling failure (fan failure) M Alarm set and clear (data log) Details of any change of configuration and parameters of UPS M Battery test execution report NM Battery test execution report			
Unbalanced charge branch current  Absence of input voltage or input voltage is out from limited values  M Short circuit and overload at the output of UPS  Absence of output voltage or output voltage is out from limited values  M Output frequency is out from limited values  Temperature of UPS is out of limit Internal UPS temperature out of limit)  M Static by-pass is in normal operation  Failure on static by-pass  NM Synchronization error  Load is supplied from static by-pass (normal working operation)  M Load is supplied from manual by-pass  NM Signalization of proper work of UPS  Failure of UPS  M Failure of inverter  NM Output UPS circuit protection  Forced cooling failure (fan failure)  M Alarm set and clear (data log) Details of any change of configuration and parameters of UPS  Change of UPS operating mode  M Battery test execution report	<u> </u>	Battery temperature sensor failure	NM
Absence of input voltage or input voltage is out from limited values  M Short circuit and overload at the output of UPS  Absence of output voltage or output voltage is out from limited values  M Output frequency is out from limited values  M Temperature of UPS is out of limit Internal UPS temperature out of limit)  Static by-pass is in normal operation  Failure on static by-pass  NM Synchronization error  Load is supplied from static by-pass (normal working operation)  Load is supplied from inverter  M Load is supplied from manual by-pass  NM Signalization of proper work of UPS  Failure of UPS  Failure of rectifier  NM Failure of rectifier  NM Output UPS circuit protection  Forced cooling failure (fan failure)  Alarm set and clear (data log)  Details of any change of configuration and parameters of UPS  M Change of UPS operating mode  M Battery test execution report			
Short circuit and overload at the output of UPS Absence of output voltage or output voltage is out from limited values M Output frequency is out from limited values M Temperature of UPS is out of limit Internal UPS temperature out of limit) M Static by-pass is in normal operation NM Failure on static by-pass NM Synchronization error Load is supplied from static by-pass (normal working operation) M Load is supplied from inverter M Load is supplied from manual by-pass NM Signalization of proper work of UPS M Failure of UPS M Failure of inverter Output UPS circuit protection M Forced cooling failure (fan failure) M Alarm set and clear (data log) Details of any change of configuration and parameters of UPS M Change of UPS operating mode M Battery test execution report NM Battery test execution report	L	Jnbalanced charge branch current	NM
Absence of output voltage or output voltage is out from limited values  Output frequency is out from limited values  Temperature of UPS is out of limit Internal UPS temperature out of limit)  M Static by-pass is in normal operation  Failure on static by-pass  NM Synchronization error  Load is supplied from static by-pass (normal working operation)  Load is supplied from inverter  Load is supplied from manual by-pass  NM Signalization of proper work of UPS  Failure of UPS  Failure of inverter  Output UPS circuit protection  Forced cooling failure (fan failure)  Alarm set and clear (data log)  Details of any change of configuration and parameters of UPS  M Change of UPS operating mode  Battery test execution report  NM			
Output frequency is out from limited values Temperature of UPS is out of limit Internal UPS temperature out of limit)  Static by-pass is in normal operation Failure on static by-pass Synchronization error Load is supplied from static by-pass (normal working operation)  Load is supplied from inverter M Load is supplied from manual by-pass NM Signalization of proper work of UPS M Failure of UPS M Failure of rectifier NM Output UPS circuit protection Forced cooling failure (fan failure)  Alarm set and clear (data log) Details of any change of configuration and parameters of UPS M Change of UPS operating mode Battery test execution report  M M  N  N  N  N  N  N  N  N  N  N  N			
Temperature of UPS is out of limit Internal UPS temperature out of limit)  Static by-pass is in normal operation  Failure on static by-pass  Synchronization error  Load is supplied from static by-pass (normal working operation)  Load is supplied from inverter  M  Load is supplied from manual by-pass  NM  Signalization of proper work of UPS  Failure of UPS  M  Failure of rectifier  NM  Failure of inverter  NM  Output UPS circuit protection  Forced cooling failure (fan failure)  Alarm set and clear (data log)  Details of any change of configuration and parameters of UPS  M  Change of UPS operating mode  Battery test execution report			
Static by-pass is in normal operation NM Failure on static by-pass NM Synchronization error NM Load is supplied from static by-pass (normal working operation) M Load is supplied from inverter M Load is supplied from manual by-pass NM Signalization of proper work of UPS M Failure of UPS M Failure of rectifier NM Failure of inverter NM Output UPS circuit protection M Forced cooling failure (fan failure) M Alarm set and clear (data log) M Details of any change of configuration and parameters of UPS M Change of UPS operating mode M Battery test execution report NM			
Failure on static by-pass NM Synchronization error NM Load is supplied from static by-pass (normal working operation) M Load is supplied from inverter M Load is supplied from manual by-pass NM Signalization of proper work of UPS M Failure of UPS M Failure of rectifier NM Failure of inverter NM Output UPS circuit protection M Forced cooling failure (fan failure) M Alarm set and clear (data log) M Details of any change of configuration and parameters of UPS M Change of UPS operating mode M Battery test execution report NM			
Synchronization error  Load is supplied from static by-pass (normal working operation)  Load is supplied from inverter  Load is supplied from manual by-pass  NM  Signalization of proper work of UPS  Failure of UPS  M  Failure of rectifier  NM  Failure of inverter  Output UPS circuit protection  Forced cooling failure (fan failure)  Alarm set and clear (data log)  Details of any change of configuration and parameters of UPS  Change of UPS operating mode  M  Battery test execution report			
Load is supplied from static by-pass (normal working operation)  Load is supplied from inverter  Load is supplied from manual by-pass  NM  Signalization of proper work of UPS  Failure of UPS  M  Failure of rectifier  NM  Failure of inverter  Output UPS circuit protection  Forced cooling failure (fan failure)  Alarm set and clear (data log)  Details of any change of configuration and parameters of UPS  Change of UPS operating mode  M  Battery test execution report			
Load is supplied from inverter  Load is supplied from manual by-pass  Signalization of proper work of UPS  Failure of UPS  Failure of rectifier  NM  Failure of inverter  Output UPS circuit protection  Forced cooling failure (fan failure)  Alarm set and clear (data log)  Details of any change of configuration and parameters of UPS  Change of UPS operating mode  Battery test execution report  NM  NM			
Load is supplied from manual by-pass NM Signalization of proper work of UPS M Failure of UPS M Failure of rectifier NM Failure of inverter NM Output UPS circuit protection M Forced cooling failure (fan failure) M Alarm set and clear (data log) M Details of any change of configuration and parameters of UPS M Change of UPS operating mode M Battery test execution report NM	Ŀ	Load is supplied from static by-pass (normal working operation)	
Signalization of proper work of UPS  Failure of UPS  Failure of rectifier  NM  Failure of inverter  Output UPS circuit protection  Forced cooling failure (fan failure)  Alarm set and clear (data log)  Details of any change of configuration and parameters of UPS  Change of UPS operating mode  Battery test execution report  M  M  NM			
Failure of UPS  Failure of rectifier  Failure of inverter  Output UPS circuit protection  Forced cooling failure (fan failure)  Alarm set and clear (data log)  Details of any change of configuration and parameters of UPS  Change of UPS operating mode  Battery test execution report  M  M  NM			
Failure of rectifier  Failure of inverter  Output UPS circuit protection  Forced cooling failure (fan failure)  Alarm set and clear (data log)  Details of any change of configuration and parameters of UPS  Change of UPS operating mode  Battery test execution report  NM			
Failure of inverter  Output UPS circuit protection  Forced cooling failure (fan failure)  Alarm set and clear (data log)  Details of any change of configuration and parameters of UPS  Change of UPS operating mode  Battery test execution report  NM			
Output UPS circuit protection  Forced cooling failure (fan failure)  Alarm set and clear (data log)  Details of any change of configuration and parameters of UPS  Change of UPS operating mode  Battery test execution report  M  NM			
Forced cooling failure (fan failure)  Alarm set and clear (data log)  Details of any change of configuration and parameters of UPS  Change of UPS operating mode  Battery test execution report  M			
Alarm set and clear (data log)  Details of any change of configuration and parameters of UPS  Change of UPS operating mode  Battery test execution report  M			
Details of any change of configuration and parameters of UPS  Change of UPS operating mode  M  Battery test execution report  NM			
Change of UPS operating mode M Battery test execution report NM			
Battery test execution report NM			
	[F		1
Status change or fast repetition (charge-discharge event)  NM		Status change or fast repetition (charge-discharge event)	
Indication of restart with back-up or customized parameters (auto-recovery in	li li	ndication of restart with back-up or customized parameters (auto-recovery in	NM
case of Control Unit reset or replacement)  power interconnection  NM			NIN A

Element type	Monitored information	Lline-interactive AC UPS
Description	Device description (hardware and software)	
	Input phase AC voltage (±2 V)	M
	Input line AC voltage (±2 V)	NM
	Input AC current (±2 %)	M
	Input frequency (±0,1 Hz)	M
	Input power factor	NM
	Input active power	NM
	Input reactive power	NM
	Total Input power	NM
	Total harmonic current distortion at the UPS input	NM
	Output phase AC voltage (±2 V)	M
	Output line AC voltage (±2 V)	NM
	Output AC current (±2 %)	M
	Average value of AC output load current I <sub>Av</sub> (±5 %) over a preset time window	NM
	Output frequency (±0,1 Hz)	М
	Output power factor	NM
	Output active power	NM
	Output reactive power	NM
1.4.	Total Output power	M
data	Total harmonic voltage distortion at the UPS output	NM
	Static by-pass current (±2 %)	NM
	Internal UPS temperature (±1 °C)	M
	Room temperature (±1 °C)	NM
	Battery temperature (±1 °C)	M
	Total Battery voltage ±1 V	
	- this precision is required for floating voltage derating detection and	M
	temperature charge compensation (around -3 mV/K/cell)	
	Charge and discharge battery current I <sub>Batt</sub> (±1 %)	M
	Battery branch current (±1 %)	NM
	Estimated remaining battery autonomy (time) during discharge	NM
	Battery age since date of installation	NM
	Estimated remaining battery capacity (due to ageing) at full charge (±5 %)	NM
	Power capacity management (ratio) = Used/Installed power	NM
	Battery discharge alarm duration	NM
	XCU program download with default to previous release	NM
data record		NM
	Battery temperature	
	AC output voltage	M M
	AC output voltage Output frequency	M
		IVI
	Detailed battery test data record: discharge chart, temperature, string current, cell voltages	NM
	Input (AC) energy consumption over preset period	NM
	AC output power	NM

Element type	Monitored information	Lline-interactive AC UPS	
Description	Device description (hardware and software)		
·	Date and time	М	
	Sliding time window to capture maximum output AC current		
	All XCU alarm/event/test/command parameters (time-out,counter,thresholds,	M	
	etc.)		
	Low DC shutdown voltage (LVD)	M	
	Low DC warning voltage	NM	
	Battery capacity	M	
	Output low voltage threshold	М	
	Battery over-temperature threshold	NM	
config	Unbalanced charge branch current (persistent string branch charge current difference/mean string charge current value)	NM	
	Unbalanced branch discharge current (persistent string branch discharge current difference/mean string discharge current value)	NM	
		NIM	
	battery test parameters	NM	
	Output overload threshold (consumed power/useful power where useful power is installed power without redundancy or battery recharge power)	NM	
	Maximum battery charging current	M	
	Battery charging voltage (boost, float voltage)	NM	
	Battery life expectancy at 20 °C (as provided by manufacturer)	NM	
control	Any forced change of operating mode e.g. battery discharge test, boost charge	M	
	XCU program download with default to previous release	M	
	Default values resetting (safe value for XCU)	M	
	Battery test on demand	NM	
	UPS power device control (rectifiers, inverter, static by-pass, Low Voltage Disconnection, etc.)	NM	
	Acknowledge battery replacement	NM	
	Acknowledge alarms	NM	

# Annex D (normative): Mandatory XML structure and elements

# D.1 Structure of an XML document for a AC UPS power system

In the site DGU XML data structure as described in ES 202 336-1 [1].

The XML structure shall be as follows:

NOTE: Indicate precisely the generic mandatory XML structure and where to put the information if it exists (where it starts and stops). Every equipment and element, should be considered as a folder in the XML structure.

```
<site id="23" status ="normal">
    <energy system id="1" status="normal">
        <description table>
        </description table>
        <ac_ups_system id="1" status="normal">
            <description_table>
            </description_table>
            <alarm table>
            </alarm_table>
            <event_table>
            </event table>
            <data table>
            </data_table>
            <data_record_table>
            </data_record_table>
            <config_table>
            </config_table>
<control_table>
            </control table>
        </ac_ups_system>
    </energy_system>
</site>
```

An AC UPS power system XCU will only generate the XML document "ac\_ups\_system.xml". This file can be downloaded by the DGU of the site and embedded in the "site.xml" document. In this case, the structure of the document is as follows:

```
<ac ups system id="1" status="normal">
    <description table>
    </description_table>
    <alarm_table>
    </alarm_table>
    <event_table>
    </event_table>
    <data_table>
    </data table>
    <data record table>
    </data_record_table>
    <config_table>
    </config_table>
    <control_table>
    </control_table>
</ac_ups_system>
```

# D.2 The specific XML elements of an AC UPS power system

Here follows the specific tags for XML elements that are not detailed in ES 202 336-1 [1].

As "AC UPS System" can be very complex, the manufacturer is free to add sub-equipments in the XML structure to provide more detailed information, data, control, etc.

The allowed child elements of <ac\_ups\_system> are:

Table D.1

Child Element	Description	Datatype
<rectifier></rectifier>	For detailed information about rectifier (or rectifier in UPS module). This equipment is already described in ES 202 336-2 [i.7] about DC Systems	xs:complexType
<inverter></inverter>	For detailed information about inverter (or inverterer in UPS module)	xs:complexType
<static_bypass_switch></static_bypass_switch>	For detailed information about SBS	xs:complexType
<battery></battery>	For detailed information about the battery	xs:complexType
<pre><pre><pre><pre>con_and_distribution&gt;</pre></pre></pre></pre>	For detailed information about the protections and the distribution	xs:complexType

# Annex E (informative): Bibliography

- IEC EN 62040: "Uninterruptiple Power System (UPS)".
- ETSI TR 102 446: "Environmental Engineering (EE); General requirements for UPS for use in Telecommunications Environment".

# History

Document history				
V1.1.1	August 2009	Membership Approval Procedure	MV 20091016:	2009-08-18 to 2009-10-16
V1.1.1	October 2009	Publication		