



EUROPEAN
TELECOMMUNICATION
STANDARD

FINAL DRAFT
pr **ETS 300 286-5**

March 1997

Source: ETSI TC-SPS

Reference: DE/SPS-05061-T-5

ICS: 33.020

Key words: ISDN, DSS1, supplementary service, UUS, testing, TSS&TP, network

**Integrated Services Digital Network (ISDN);
User-to-User Signalling (UUS) supplementary service;
Digital Subscriber Signalling System No. one (DSS1) protocol;
Part 5: Test Suite Structure and Test Purposes (TSS&TP)
specification for the network**

ETSI

European Telecommunications Standards Institute

ETSI Secretariat

Postal address: F-06921 Sophia Antipolis CEDEX - FRANCE

Office address: 650 Route des Lucioles - Sophia Antipolis - Valbonne - FRANCE

X.400: c=fr, a=atlas, p=etsi, s=secretariat - **Internet:** secretariat@etsi.fr

Tel.: +33 4 92 94 42 00 - Fax: +33 4 93 65 47 16

Copyright Notification: No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 1997. All rights reserved.

Contents

Foreword	5
1 Scope	7
2 Normative references	7
3 Definitions	8
3.1 Definitions related to conformance testing	8
3.2 Definitions related to ETS 300 286-1	8
4 Abbreviations	9
5 Test Suite Structure (TSS)	10
6 Test Purposes (TP)	10
6.1 Introduction	10
6.1.1 TP naming convention	11
6.1.2 Source of TP definition	11
6.1.3 TP structure	11
6.1.4 Test strategy	12
6.1.5 Test of point-to-multipoint configurations	12
6.2 Network TPs for UUS	12
6.2.1 Served user	12
6.2.1.1 Service 1	12
6.2.1.1.1 Activation	12
6.2.1.1.1.1 Implicitly requested	12
6.2.1.1.1.2 Explicitly requested	13
6.2.1.1.2 Invocation	14
6.2.1.1.2.1 During call establishment	14
6.2.1.1.2.2 During call clearing	14
6.2.1.1.2.2.1 Clearing initiated by the calling user	14
6.2.1.1.2.2.2 Clearing initiated by the called user	16
6.2.1.2 Service 2	16
6.2.1.2.1 Activation	16
6.2.1.2.2 Invocation	18
6.2.1.3 Service 3	20
6.2.1.3.1 Activation	20
6.2.1.3.1.1 During call establishment	20
6.2.1.3.1.2 During active call state	21
6.2.1.3.2 Invocation	22
6.2.1.3.3 Flow control	23
6.2.2 Remote user	24
6.2.2.1 Service 1	24
6.2.2.1.1 Activation	24
6.2.2.1.1.1 Implicitly requested	24
6.2.2.1.1.2 Explicitly requested	24
6.2.2.1.2 Invocation	35
6.2.2.1.2.1 During call establishment	35
6.2.2.1.2.2 During call clearing	37
6.2.2.1.2.2.1 Clearing initiated by the calling user	37
6.2.2.1.2.2.2 Clearing initiated by the called user	37
6.2.2.2 Service 2	41
6.2.2.2.1 Activation	41
6.2.2.2.2 Invocation	45

6.2.2.3	Service 3	47
	6.2.2.3.1 Activation	47
	6.2.2.3.1.1 During call establishment	47
	6.2.2.3.1.2 During active call state	51
	6.2.2.3.2 Invocation	53
	6.2.2.3.3 Flow control	55
7	Compliance	56
8	Requirements for a comprehensive testing service	56
	History	57

Foreword

This final draft European Telecommunication Standard (ETS) has been produced by the Signalling Protocols and Switching (SPS) Technical Committee of the European Telecommunications Standards Institute (ETSI), and is now submitted for the Voting phase of the ETSI standards approval procedure.

This ETS is part 5 of a multi-part standard covering the Digital Subscriber Signalling System No. one (DSS1) protocol specification for the Integrated Services Digital Network (ISDN) User-to-User (UUS) supplementary service, as described below:

Part 1: "Protocol specification";

Part 2: "Protocol Implementation Conformance Statement (PICS) proforma specification";

Part 3: "Test Suite Structure and Test Purposes (TSS&TP) specification for the user";

Part 4: "Abstract Test Suite (ATS) and partial Protocol Implementation eXtra Information for Testing (PIXIT) proforma specification for the user";

Part 5: "TSS&TP specification for the network";

Part 6: "ATS and partial PIXIT proforma specification for the network".

Proposed transposition dates	
Date of latest announcement of this ETS (doa):	3 months after ETSI publication
Date of latest publication of new National Standard or endorsement of this ETS (dop/e):	6 months after doa
Date of withdrawal of any conflicting National Standard (dow):	6 months after doa

Blank page

1 Scope

This fifth part of ETS 300 286 specifies the Test Suite Structure and Test Purposes (TSS&TP) for the Network side of the T reference point or coincident S and T reference point (as defined in ITU-T Recommendation I.411 [7]) of implementations conforming to the stage three standard for the User-to-User Signalling (UUS) supplementary service for the pan-European Integrated Services Digital Network (ISDN) by means of the Digital Subscriber Signalling System No. one (DSS1) protocol, ETS 300 286-1 [1].

A further part of this ETS specifies the Abstract Test Suite (ATS) and partial PIXIT proforma based on this ETS. Other parts specify the TSS&TP and the ATS and partial PIXIT proforma for the User side of the T reference point or coincident S and T reference point of implementations conforming to ETS 300 286-1 [1].

2 Normative references

This ETS incorporates by dated and undated reference, provisions from other publications. These normative references are cited at the appropriate places in the text and the publications are listed hereafter. For dated references, subsequent amendments to or revisions of any of these publications apply to this ETS only when incorporated in it by amendment or revision. For undated references the latest edition of the publication referred to applies.

- [1] ETS 300 286-1 (1996): "Integrated Services Digital Network (ISDN); User-to-User Signalling (UUS) supplementary service; Digital Subscriber Signalling System No. one (DSS1) protocol; Part 1: Protocol specification".
- [2] ETS 300 286-2 (1996): "Integrated Services Digital Network (ISDN); User-to-User Signalling (UUS) supplementary service; Digital Subscriber Signalling System No. one (DSS1) protocol; Part 2: Protocol Implementation Conformance Statement (PICS) proforma specification".
- [3] ISO/IEC 9646-1: "Information Technology - OSI Conformance Testing Methodology and Framework; Part 1: General Concepts".
- [4] ISO/IEC 9646-2: "Information Technology - OSI Conformance Testing Methodology and Framework; Part 2: Abstract Test Suite specification".
- [5] ISO/IEC 9646-3: "Information Technology - OSI Conformance Testing Methodology and Framework; Part 3: The Tree and Tabular Combined Notation".
- [6] ETS 300 196-1: "Integrated Services Digital Network (ISDN); Generic functional protocol for the support of supplementary services; Digital Subscriber Signalling System No. one (DSS1) protocol; Part 1: Protocol specification".
- [7] ITU-T Recommendation I.411 (1993): "ISDN user-network interfaces - Reference configurations".
- [8] ETS 300 102-1: "Integrated Services Digital Network (ISDN); User-network interface layer 3; Specifications for basic call control".
- [9] ITU-T Recommendation I.112 (1993): "Vocabulary and terms for ISDNs".
- [10] CCITT Recommendation E.164 (1991): "Numbering plan for the ISDN era".
- [11] ITU-T Recommendation I.210 (1993): "Principles of the telecommunication services supported by an ISDN and the means to describe them".
- [12] I-ETS 300 316: "Integrated Services Digital Network (ISDN); Digital Subscriber Signalling System No. one (DSS1); Protocol Implementation Conformance Statement (PICS) proforma specification for signalling network layer protocol for circuit-mode basic call control (basic access, network)".

- [13] I-ETS 300 317: "Integrated Services Digital Network (ISDN); Digital Subscriber Signalling System No. one (DSS1); Protocol Implementation Conformance Statement (PICS) proforma specification for signalling network layer protocol for circuit-mode basic call control (primary rate access, network)".

3 Definitions

For the purposes of this ETS, the following definitions apply.

3.1 Definitions related to conformance testing

abstract test case: Refer to ISO/IEC 9646-1 [3].

Abstract Test Suite (ATS): Refer to ISO/IEC 9646-1 [3].

active test: A test case where the IUT is required to send a particular message, but not in reaction to a received message. This would usually involve the use of PIXIT information to see how this message can be generated and quite often is specified in an ATS using an implicit send event.

Implementation Under Test (IUT): Refer to ISO/IEC 9646-1 [3].

implicit send event: Refer to ISO/IEC 9646-3 [5].

lower tester: Refer to ISO/IEC 9646-1 [3].

passive test: A test case where the IUT is required to respond to a protocol event (e.g. received message) with another protocol event (e.g. send message) which normally does not require any special operator intervention as associated with the implicit send event.

point of control and observation: Refer to ISO/IEC 9646-1 [3].

Protocol Implementation Conformance Statement (PICS): Refer to ISO/IEC 9646-1 [3].

PICS proforma: Refer to ISO/IEC 9646-1 [3].

Protocol Implementation eXtra Information for Testing (PIXIT): Refer to ISO/IEC 9646-1 [3].

PIXIT proforma: Refer to ISO/IEC 9646-1 [3].

system under test: Refer to ISO/IEC 9646-1 [3].

Test Purpose (TP): Refer to ISO/IEC 9646-1 [3].

3.2 Definitions related to ETS 300 286-1

call reference: See ETS 300 102-1 [8], subclause 4.3.

called user: The user at the destination side of the call.

calling user: The user at the origination side of the call.

component: See ETS 300 196-1 [6], subclause 11.2.2.1.

Integrated Services Digital Network (ISDN): See ITU-T Recommendation I.112 [9], definition 308.

ISDN number: A number conforming to the numbering and structure specified in CCITT Recommendation E.164 [10].

invoke component: See ETS 300 196-1 [6], subclause 11.2.2.1.

network: The DSS1 protocol entity at the Network side of the user-network interface where a T reference point or coincident S and T reference point applies.

network (S/T): The DSS1 protocol entity at the Network side of the user-network interface where a coincident S and T reference point applies.

network (T): The DSS1 protocol entity at the Network side of the user-network interface where a T reference point applies (Network connected to Private ISDN).

return error component: See ETS 300 196-1 [6], subclause 11.2.2.1.

return result component: See ETS 300 196-1 [6], subclause 11.2.2.1.

served user: The served user is the user who invokes the UUS supplementary service. The served user is the calling user except for service 3 where the called user, as a network option can invoke the service 3 in the Active call state.

service; telecommunication service: See ITU-T Recommendation I.112 [9], definition 201.

supplementary service: See ITU-T Recommendation I.210 [11], subclause 2.4.

4 Abbreviations

For the purposes of this ETS, the following abbreviations apply:

ATM	Abstract Test Method
ATS	Abstract Test Suite
CES	Connection Endpoint Suffix
CR	Call Reference
ISDN	Integrated Services Digital Network
IUT	Implementation Under Test
N00	Null call state
N01	Call Initiated call state
N02	Overlap Sending call state
N03	Outgoing Call Proceeding call state
N04	Call Delivered call state
N06	Call Present call state
N07	Call Received call state
N08	Connect Request call state
N09	Incoming Call Proceeding call state
N10	Active call state
N11	Disconnect Request call state
N12	Disconnect Indication call state
N19	Release Request call state
N25	Overlap Receiving call state
PICS	Protocol Implementation Conformance Statement
PIXIT	Protocol Implementation eXtra Information for Testing
TP	Test Purpose
TSS	Test Suite Structure
UUS	User-to-User Signalling
UUS1/2/3	UUS service 1/2/3

5 Test Suite Structure (TSS)

Served user	Group
- <u>Service 1</u>	
- activation	
- implicit	(01)
- explicit	(02)
- invocation	
- during call establishment	(03)
- during call clearing	
- initiated by the calling user	(04)
- initiated by the called user	(05)
- <u>Service 2</u>	
- activation	(06)
- invocation	(07)
- <u>Service 3</u>	
- activation	
- during call establishment	(08)
- during active call state	(09)
- invocation	(10)
- flow control	(11)
Remote user	
- <u>Service 1</u>	
- activation	
- implicit	(12)
- explicit	(13)
- invocation	
- during call establishment	(14)
- during call clearing	
- initiated by the calling user	(15)
- initiated by the called user	(16)
- <u>Service 2</u>	
- activation	(17)
- invocation	(18)
- <u>Service 3</u>	
- activation	
- during call establishment	(19)
- during active call state	(20)
- invocation	(21)
- flow control	(22)

NOTE: Numbers in brackets represent group numbers and are used in TP identifiers.

Figure 1: Test suite structure

6 Test Purposes (TP)

6.1 Introduction

For each test requirement a TP is defined.

6.1.1 TP naming convention

TPs are numbered, starting at 001, within each group. Groups are organized according to the TSS. Additional references are added to identify the actual test suite and whether it applies to the network or the user (see table 1).

Table 1: TP identifier naming convention scheme

Identifier:	<ss>_<iut><group>_<nnn>		
<ss>	=	supplementary service: e.g. "UUS"	
<iut>	=	type of IUT:	U User N Network
<group>	=	group	2 digit field representing group reference according to TSS
<nnn>	=	sequential number	(001-999)

6.1.2 Source of TP definition

The TPs are based on ETS 300 286-1 [1].

6.1.3 TP structure

Each TP has been written in a manner which is consistent with all other TPs. The intention of this is to make the TPs more readable and checkable. A particular structure has been used and this is illustrated in table 2. This table should be read in conjunction with any TP, i.e. use a TP as an example to fully understand the table.

Table 2: Structure of a single TP for UUS

TP part	Text	Example
Header	<Identifier> <i>tab</i> <paragraph number in base ETS> <i>tab</i> <type of test> <i>tab</i> <condition> <i>CR.</i>	see table 1 subclause 0.0.0 valid, invalid, inopportune mandatory, optional, conditional
Stimulus	Ensure that the IUT in the <basic call state> <trigger> <i>see below for message structure</i> <i>or</i> <goal>	N10 etc. receiving a XXXX message to request a ...
Reaction	<action> <conditions> <i>if the action is sending</i> <i>see below for message structure</i> <next action>, <i>etc.</i> and remains in the same state <i>or</i> and enters state <state>	sends, saves, does, etc. using en bloc sending, ...
Message structure	<message type> message containing a a) <info element> information element with b) a <field name> encoded as <i>or</i> including <coding of the field> and <i>back to a or b,</i>	SETUP, FACILITY, CONNECT, ... Bearer capability, Facility, ...
NOTE:	Text in italics will not appear in TPs and text between <> is filled in for each TP and may differ from one TP to the next.	

6.1.4 Test strategy

As the base standard ETS 300 286-1 [1] contains no explicit requirements for testing, the TPs were generated as a result of an analysis of the base standard and the PICS specification ETS 300 286-2 [2]. The criteria applied include the following:

- only the requirements from the point of view of the T or coincident S and T reference point are considered;
- whether or not a test case can be built from the TP is not considered.

6.1.5 Test of point-to-multipoint configurations

In the case of a point-to-multipoint configuration several terminals may be attached to one basic access interface. Each terminal will use a different Connection Endpoint Suffix (CES). To reflect this in the TPs, the CES for which a message is received or sent (e.g. "...on receipt of an ALERTING message for CES1...") is named explicitly where this clarification is needed.

6.2 Network TPs for UUS

All PICS items referred to in this subclause are as specified in ETS 300 286-2 [2] unless indicated otherwise by another numbered reference.

6.2.1 Served user

6.2.1.1 Service 1

Selection: Does the IUT support service 1. PICS: MC 2.1.

6.2.1.1.1 Activation

6.2.1.1.1.1 Implicitly requested

UUS_N01_001 **subclause 9.1.1.1.1** **valid** **mandatory**

Ensure that the IUT, in the call state N00, receiving a valid SETUP message with a User-user information element without user information and the network can accept the request,
accepts the message (resulting in the inclusion of the same User-user information element in the SETUP message sent to the remote user) and enters the call state N01.

UUS_N01_002 **subclause 9.1.1.1.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N00, receiving a valid SETUP message with a User-user information element without user information and the network cannot accept the request,
discards the User-user information element (resulting in the sending of a SETUP message without User-user information element to the remote user) and enters the call state N01.

UUS_N01_003 **subclause 9.1.1.1.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N00, receiving a valid SETUP message with a User-user information element of less than 3 octets in length,
discards the User-user information element (resulting in the sending of a SETUP message without User-user information element to the remote user) and enters the call state N01.

6.2.1.1.1.2 Explicitly requested

Selection: Does the IUT support the explicit request of service 1. PICS: MC 2.1.2.

UUS_N02_001 subclause 9.1.1.2.1 valid mandatory

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred, accepts the message (resulting in the inclusion of the same Facility information element in the SETUP message sent to the remote user) and enters the call state N01.

UUS_N02_002 subclause 9.1.1.2.1 valid mandatory

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required, accepts the message (resulting in the inclusion of the same Facility information element in the SETUP message sent to the remote user) and enters the call state N01.

UUS_N02_003 subclause 9.1.1.2.2 inopportune mandatory

Ensure that the IUT, in the call state N00 receiving a SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 and an incompatible bearer capability, sends a RELEASE COMPLETE message without UserUserService return error component and enters the call state N00.

UUS_N02_004 subclause 9.1.1.2.2 inopportune mandatory

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred and the resources are not available, continues with normal call handling and includes a UserUserService return error component with the value "rejectedByNetwork" in a valid SETUP ACKNOWLEDGE, CALL PROCEEDING, PROGRESS, ALERTING or CONNECT message.

UUS_N02_005 subclause 9.1.1.2.2 inopportune mandatory

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred and the service 1 is not subscribed to, continues with normal call handling and includes a UserUserService return error component with the value "rejectedByNetwork" in a valid SETUP ACKNOWLEDGE, CALL PROCEEDING, PROGRESS, ALERTING or CONNECT message.

UUS_N02_006 subclause 9.1.1.2.2 inopportune mandatory

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required and the resources are not available, sends a DISCONNECT or RELEASE COMPLETE message, with cause value #47 "resources unavailable", including a UserUserService return error component with the value "rejectedByNetwork" and enters the call state N12 or N00.

UUS_N02_007 subclause 9.1.1.2.2 inopportune mandatory

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required and the service 1 is not subscribed to, sends a DISCONNECT or RELEASE COMPLETE message, with cause value #50 "requested facility not subscribed", including a UserUserService return error component with the value "rejectedByNetwork" and enters the call state N12 or N00.

6.2.1.1.2 Invocation**6.2.1.1.2.1 During call establishment****UUS_N03_001 subclause 9.1.2.1.1 valid mandatory**

Ensure that the IUT, in the call state N00, receiving a valid SETUP message including a User-user information element with user information,

accepts the message (resulting in the sending of a SETUP message to the remote user with the same User-user information element) sends a SETUP ACKNOWLEDGE or a CALL PROCEEDING message and enters the call state N02 or N03.

NOTE: This TP corresponds to the invocation of service 1 simultaneously with the activation by the same User-user information element.

UUS_N03_002 subclause 9.1.2.1.1 valid mandatory

Ensure that the IUT, in the call state N00, receiving a valid SETUP message including a UserUserService invoke component indicating service 1 and a User-user information element with user information,

accepts the message (resulting in the sending of a SETUP message to the remote user with the same UserUserService invoke component and User-user information element) sends a SETUP ACKNOWLEDGE or a CALL PROCEEDING message and enters the call state N02 or N03.

UUS_N03_003 subclause 9.1.2.1.2 invalid mandatory

Ensure that the IUT, in the call state N00, receiving a valid SETUP message including a User-user information element with user information with an overall length exceeding 131 octets,

continues normal call handling, and optionally sends a STATUS message with cause value #43 "access information discarded".

6.2.1.1.2.2 During call clearing**6.2.1.1.2.2.1 Clearing initiated by the calling user****UUS_N04_001 subclause 9.1.2.2.1.a valid mandatory**

Ensure that the IUT, in the call state N02 and in the service 1 active state, receiving a DISCONNECT message with a User-user information element,

accepts the message (resulting in the inclusion of a User-user information element in the DISCONNECT message sent to the remote user), sends a RELEASE message and enters the call state N19.

UUS_N04_002 subclause 9.1.2.2.1.a valid mandatory

Ensure that the IUT, in the call state N03 and in the service 1 active state, receiving a DISCONNECT message with a User-user information element,

accepts the message (resulting in the inclusion of a User-user information element in the DISCONNECT message sent to the remote user), sends a RELEASE message and enters the call state N19.

UUS_N04_003 subclause 9.1.2.2.1.a valid mandatory

Ensure that the IUT, in the call state N04 and in the service 1 active state, receiving a DISCONNECT message with a User-user information element,

accepts the message (resulting in the inclusion of a User-user information element in the DISCONNECT message sent to the remote user), sends a RELEASE message and enters the call state N19.

UUS_N04_004 subclause 9.1.2.2.1.a valid mandatory

Ensure that the IUT, in the call state N10 (outgoing call) and in the service 1 active state, receiving a DISCONNECT message with a User-user information element,

accepts the message (resulting in the inclusion of a User-user information element in the DISCONNECT message sent to the remote user), sends a RELEASE message and enters the call state N19.

- UUS_N04_005** **subclause 9.1.2.2.2** **invalid** **mandatory**
Ensure that the IUT, in the call state N02, with the service 1 not activated, receiving a DISCONNECT message with a User-user information element,
discards the User-user information element (resulting in the sending of a DISCONNECT or RELEASE message to the remote user without User-user information element), sends a RELEASE message optionally including a Cause information element with the cause value #43 "access information discarded" and enters the call state N19.
- UUS_N04_006** **subclause 9.1.2.2.2** **invalid** **mandatory**
Ensure that the IUT, in the call state N03, with the service 1 not activated, receiving a DISCONNECT message with a User-user information element,
discards the User-user information element (resulting in the sending of a DISCONNECT or RELEASE message to the remote user without User-user information element), sends a RELEASE message optionally including a Cause information element with the cause value #43 "access information discarded" and enters the call state N19.
- UUS_N04_007** **subclause 9.1.2.2.2** **invalid** **mandatory**
Ensure that the IUT, in the call state N04, with the service 1 not activated, receiving a DISCONNECT message with a User-user information element,
discards the User-user information element (resulting in the sending of a DISCONNECT or RELEASE message to the remote user without User-user information element), sends a RELEASE message optionally including a Cause information element with the cause value #43 "access information discarded" and enters the call state N19.
- UUS_N04_008** **subclause 9.1.2.2.2** **invalid** **mandatory**
Ensure that the IUT, in the call state N10 (outgoing call), with the service 1 not activated, receiving a DISCONNECT message with a User-user information element,
discards the User-user information element (resulting in the sending of a DISCONNECT or RELEASE message to the remote user without User-user information element), sends a RELEASE message optionally including a Cause information element with the cause value #43 "access information discarded" and enters the call state N19.
- UUS_N04_009** **subclause 9.1.2.2.2** **invalid** **mandatory**
Ensure that the IUT, in the call state N02 and in the service 1 active state, receiving a DISCONNECT message with a User-user information element with the overall length exceeding 131 octets,
discards the User-user information element (resulting in the sending of a DISCONNECT or RELEASE message to the remote user without User-user information element), sends a RELEASE message optionally including a Cause information element with the cause value #43 "access information discarded" and enters the call state N19.
- UUS_N04_010** **subclause 9.1.2.2.2** **invalid** **mandatory**
Ensure that the IUT, in the call state N03 and in the service 1 active state, receiving a DISCONNECT message with a User-user information element with the overall length exceeding 131 octets,
discards the User-user information element (resulting in the sending of a DISCONNECT or RELEASE message to the remote user without User-user information element), sends a RELEASE message optionally including a Cause information element with the cause value #43 "access information discarded" and enters the call state N19.
- UUS_N04_011** **subclause 9.1.2.2.2** **invalid** **mandatory**
Ensure that the IUT, in the call state N04 and in the service 1 active state, receiving a DISCONNECT message with a User-user information element with the overall length exceeding 131 octets,
discards the User-user information element (resulting in the sending of a DISCONNECT or RELEASE message to the remote user without User-user information element), sends a RELEASE message optionally including a Cause information element with the cause value #43 "access information discarded" and enters the call state N19.
- UUS_N04_012** **subclause 9.1.2.2.2** **invalid** **mandatory**
Ensure that the IUT, in the call state N10 and in the service 1 active state, receiving a DISCONNECT message with a User-user information element with the overall length exceeding 131 octets,
discards the User-user information element (resulting in the sending of a DISCONNECT or RELEASE message to the remote user without User-user information element), sends a RELEASE message optionally including a Cause information element with the cause value #43 "access information discarded" and enters the call state N19.

6.2.1.1.2.2 Clearing initiated by the called user

No test requirement for this group.

6.2.1.2 Service 2

Selection: Does the IUT support service 2. PICS: MC 2.2.

6.2.1.2.1 Activation**UUS_N06_001 subclause 9.2.1.1 valid mandatory**

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 preferred, accepts the message (resulting in the inclusion of a Facility information element including a UserUserService invoke component indicating service 2 preferred in the SETUP message sent to the remote user) and enters the call state N01.

UUS_N06_002 subclause 9.2.1.1 valid mandatory

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 required, accepts the message (resulting in the inclusion of a Facility information element including a UserUserService invoke component indicating service 2 required in the SETUP message sent to the remote user) and enters the call state N01.

UUS_N06_003 subclause 9.2.1.1 valid mandatory

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 preferred, to indicate that the remote user has accepted the request in an ALERTING message, continues normal call handling, sends an ALERTING message with a Facility information element including a UserUserService return result component and enters the call state N04.

UUS_N06_004 subclause 9.2.1.1 valid mandatory

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 required, to indicate that the remote user has accepted the request in an ALERTING message, continues normal call handling, sends an ALERTING message with a Facility information element including a UserUserService return result component and enters the call state N04.

UUS_N06_005 subclause 9.2.1.2 inopportune mandatory

Ensure that the IUT, in the call state N00 receiving a SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 and an incompatible bearer capability, sends a RELEASE COMPLETE message without UserUserService return error component and enters the call state N00.

UUS_N06_006 subclause 9.2.1.2 inopportune mandatory

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 preferred and the resources are not available, continues with normal call handling and includes a UserUserService return error component with the value "rejectedByNetwork" in a valid SETUP ACKNOWLEDGE, CALL PROCEEDING, PROGRESS, ALERTING or CONNECT message.

UUS_N06_007 subclause 9.2.1.2 inopportune mandatory

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 preferred and the service 2 is not subscribed to, continues with normal call handling and includes a UserUserService return error component with the value "rejectedByNetwork" in a valid SETUP ACKNOWLEDGE, CALL PROCEEDING, PROGRESS, ALERTING or CONNECT message.

UUS_N06_008 **subclause 9.2.1.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 required and the resources are not available,

sends a DISCONNECT or RELEASE COMPLETE message, with cause value #47 "resources unavailable", including a UserUserService return error component with the value "rejectedByNetwork" and enters the call state N12 or N00.

UUS_N06_009 **subclause 9.2.1.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 required and the service 2 is not subscribed to,

sends a DISCONNECT or RELEASE COMPLETE message, with cause value #50 "requested facility not subscribed", including a UserUserService return error component with the value "rejectedByNetwork" and enters the call state N12 or N00.

UUS_N06_010 **subclause 9.2.1.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 preferred, to indicate that the remote user (not a private ISDN) has neither accepted nor rejected service 2 in the ALERTING message,

continues normal call handling, sends an ALERTING message with a Facility information element including a UserUserService return error component with the value "rejectedByUser" and enters the call state N10.

UUS_N06_011 **subclause 9.2.1.2, clause 10** **inopportune** **mandatory**

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 preferred, to indicate that the remote user (private ISDN) has neither accepted nor rejected service 2 in the ALERTING message,

continues normal call handling, sends an ALERTING message with a Facility information element including a UserUserService return error component with the value "rejectedByUser" or "rejectedByNetwork" and enters the call state N10.

NOTE 1: Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

UUS_N06_012 **subclause 9.2.1.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 required, to indicate that the remote user (not a private ISDN) has neither accepted nor rejected service 2 in an ALERTING message,

sends a DISCONNECT message with cause value #69 "requested facility not implemented" and a Facility information element including a UserUserService return error component with the value "rejectedByUser" and enters the call state N12.

UUS_N06_013 **subclause 9.2.1.2, clause 10** **inopportune** **mandatory**

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 required, to indicate that the remote user (private ISDN) has neither accepted nor rejected service 2 in an ALERTING message,

sends a DISCONNECT message with cause value #69 "requested facility not implemented" and a Facility information element including a UserUserService return error component with the value "rejectedByUser" or "rejectedByNetwork" and enters the call state N12.

NOTE 2: Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

UUS_N06_014 **subclause 9.2.1.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 required, to indicate that the remote user has cleared the call before having accepted or rejected service 2,

sends a DISCONNECT message and enters the call state N12.

UUS_N06_015 **subclause 9.2.1.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N00, receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 preferred, to indicate that the remote user (not a private ISDN), has rejected the service 2 request in an ALERTING message, continues normal call handling, sends an ALERTING message with a Facility information element including a UserUserService return error component with the value "rejectedByUser" and enters the call state N04.

UUS_N06_016 **subclause 9.2.1.2, clause 10** **inopportune** **mandatory**

Ensure that the IUT, in the call state N00, receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 preferred, to indicate that the remote user (private ISDN), has rejected the service 2 request in an ALERTING message, continues normal call handling, sends an ALERTING message with a Facility information element including a UserUserService return error component with the value "rejectedByUser" or "rejectedByNetwork" and enters the call state N04.

NOTE 3: Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

UUS_N06_017 **subclause 9.2.1.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 preferred, to indicate that the called network which does not know that a point-to-point arrangement exists at the remote user's interface, has rejected the service 2 request, continues normal call handling, sends an ALERTING message with a Facility information element including a UserUserService return error component with the value "rejectedByUser" and enters the call state N04.

UUS_N06_018 **subclause 9.2.1.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 required, to indicate that the called network which does not know that a point-to-point arrangement exists at the remote users interface, has rejected the service 2 request, sends a DISCONNECT message with a Facility information element including a UserUserService return error component with the value "rejectedByUser" and cause value #69 "requested facility not implemented" and enters the call state N12.

6.2.1.2.2 **Invocation****UUS_N07_001** **subclause 9.2.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N04 and in the service 2 active state, receiving a USER INFORMATION message including a User-user information element and no More data information element, accepts the message (resulting in the sending of a USER INFORMATION message to the served user with a User-user information element and no More data information element), sends no message and remains in the same state.

UUS_N07_002 **subclause 9.2.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N04 and in the service 2 active state, receiving a USER INFORMATION message including a User-user information element and a More data information element, accepts the message (resulting in the sending of a USER INFORMATION message to the served user with a User-user information element and a More data information element), sends no message and remains in the same state.

UUS_N07_003 **subclause 9.2.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N04 and in the service 2 active state, receiving two USER INFORMATION messages both including a User-user information element, accepts the messages (resulting in the sending of two USER INFORMATION messages to the served user with a User-user information element), sends no message and remains in the same state.

- UUS_N07_004** **subclause 9.2.2.2** **invalid** **mandatory**
 Ensure that the IUT, in the call state N04, with service 2 not activated, receiving a USER INFORMATION message including a User-user information element,
 discards the message, optionally sends a STATUS message with cause value #43 "access information discarded" and remains in the same state.
- UUS_N07_005** **subclause 9.2.2.2** **invalid** **optional**
 Ensure that the IUT, in the call state N10, with service 2 not activated, receiving a USER INFORMATION message including a User-user information element,
 discards the message, optionally sends a STATUS message with cause value #43 "access information discarded" and remains in the same state.
Selection: In Service 2, ability to accept USER INFORMATION messages for delivery in call state N10. PICS: SC 6.1.
- UUS_N07_006** **subclause 9.2.2.2** **invalid** **mandatory**
 Ensure that the IUT, in the call state N04 and in the service 2 active state, receiving three USER INFORMATION messages both including a User-user information element,
 discards the third message, optionally sends a STATUS message with cause value #43 "access information discarded" and remains in the same state.
- UUS_N07_007** **subclause 9.2.2.2** **invalid** **mandatory**
 Ensure that the IUT, in the call state N04 and in the service 2 active state, receiving a USER INFORMATION message including a User-user information element with an overall length exceeding 131 octets,
 discards the message, optionally sends a STATUS message with cause value #43 "access information discarded" and remains in the same state.
- UUS_N07_008** **subclause 9.2.2.2** **invalid** **mandatory**
 Ensure that the IUT, in the call state N03 and in the service 2 active state, receiving a USER INFORMATION message including a User-user information element,
 discards the message and sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state";
 or
 sends a STATUS ENQUIRY message and remains in the same state.
- UUS_N07_009** **subclause 9.2.2.2** **invalid** **optional**
 Ensure that the IUT, in the call state N10 and in the service 2 active state, receiving a USER INFORMATION message including a User-user information element,
 discards the message and sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state";
 or
 sends a STATUS ENQUIRY message and remains in the same state.
Selection: In service 2, ability to accept USER INFORMATION messages for delivery in call state N10 NOT supported. PICS: NOT SC 6.1.
- UUS_N07_010** **subclause 9.2.2.2** **invalid** **mandatory**
 Ensure that the IUT, in the call state N12 and in the service 2 active state, receiving a USER INFORMATION message including a User-user information element,
 discards the message and sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state";
 or
 sends a STATUS ENQUIRY message and remains in the same state.

UUS_N07_011 **subclause 9.2.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N19 and in the service 2 active state, receiving a USER INFORMATION message including a User-user information element,
 discards the message and sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state";
 or
 sends a STATUS ENQUIRY message and remains in the same state.

6.2.1.3 **Service 3**

Selection: Does the IUT support service 3. PICS: MC 2.3.

6.2.1.3.1 **Activation****6.2.1.3.1.1** **During call establishment****UUS_N08_001** **subclause 9.3.1.1.1** **valid** **mandatory**

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 preferred,
 accepts the message (resulting in the inclusion of a UserUserService invoke component indicating service 3 preferred in the SETUP message sent to the remote user) and enters the call state N01.

UUS_N08_002 **subclause 9.3.1.1.1** **valid** **mandatory**

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 required,
 accepts the message (resulting in the inclusion of a UserUserService invoke component indicating service 3 required in the SETUP message sent to the remote user) and enters the call state N01.

UUS_N08_003 **subclause 9.3.1.1.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N00 receiving a SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 and an incompatible bearer capability,
 sends a RELEASE COMPLETE message without UserUserService return error component and enters the call state N00.

UUS_N08_004 **subclause 9.3.1.1.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 preferred and the resources are not available,
 continues with normal call handling and includes a UserUserService return error component with the value "rejectedByNetwork" in a valid SETUP ACKNOWLEDGE, CALL PROCEEDING, PROGRESS, ALERTING or CONNECT message.

UUS_N08_005 **subclause 9.3.1.1.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 preferred and the service 3 is not subscribed to,
 continues with normal call handling and includes a UserUserService return error component with the value "rejectedByNetwork" in a valid SETUP ACKNOWLEDGE, CALL PROCEEDING, PROGRESS, ALERTING or CONNECT message.

UUS_N08_006 **subclause 9.3.1.1.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 required and the resources are not available,
 sends a DISCONNECT or RELEASE COMPLETE message, with cause value #47 "resources unavailable", including a UserUserService return error component with the value "rejectedByNetwork" and enters the call state N12 or N00.

UUS_N08_007 **subclause 9.3.1.1.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N00 receiving a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 required and the service 3 is not subscribed to,

sends a DISCONNECT or RELEASE COMPLETE message, with cause value #50 "requested facility not subscribed", including a UserUserService return error component with the value "rejectedByNetwork" and enters the call state N12 or N00.

6.2.1.3.1.2 **During active call state****UUS_N09_001** **subclause 9.3.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N10, receiving a valid FACILITY message including a Facility information element with a UserUserService invoke component indicating service 3, preferred,

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService invoke component indicating service 3 preferred in the FACILITY message sent to the remote user), sends no message and remains in the same state.

UUS_N09_002 **subclause 9.3.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N10, having sent a FACILITY message including a Facility information element with a UserUserService invoke component indicating service 3, preferred, receiving a FACILITY message including a Facility information element with a UserUserService return result component,

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return result component in the FACILITY message sent to the remote user), sends no message and remains in the same state.

UUS_N09_003 **subclause 9.3.1.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N03, having received a valid FACILITY message including a Facility information element with a UserUserService invoke component indicating service 3, preferred,

sends a FACILITY message including a Facility information element with a UserUserService return error component indicating "rejectedByNetwork" and remains in the same state.

UUS_N09_004 **subclause 9.3.1.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N04, having received a valid FACILITY message including a Facility information element with a UserUserService invoke component indicating service 3, preferred,

sends a FACILITY message including a Facility information element with a UserUserService return error component indicating "rejectedByNetwork" and remains in the same state.

UUS_N09_005 **subclause 9.3.1.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N12, having received a valid FACILITY message including a Facility information element with a UserUserService invoke component indicating service 3 preferred,

sends a FACILITY message including a Facility information element with a UserUserService return error component indicating "rejectedByNetwork" and remains in the same state.

UUS_N09_006 **subclause 9.3.1.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N19, having received a valid FACILITY message including a Facility information element with a UserUserService invoke component indicating service 3 preferred,

sends a FACILITY message including a Facility information element with a UserUserService return error component indicating "rejectedByNetwork" and remains in the same state.

UUS_N09_007 **subclause 9.3.1.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N10, having received a valid FACILITY message including a Facility information element with a UserUserService invoke component indicating service 3 and service 3 is not subscribed to,

sends a FACILITY message including a Facility information element with a UserUserService return error component indicating "rejectedByNetwork" and remains in the same state.

UUS_N09_008 **subclause 9.3.1.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N10, having received a valid FACILITY message including a Facility information element with a UserUserService invoke component indicating service 3 and resources are not available,

sends a FACILITY message including a Facility information element with a UserUserService return error component indicating "rejectedByNetwork" and remains in the same state.

UUS_N09_009 **subclause 9.3.1.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N10, having sent a FACILITY message including a Facility information element with a UserUserService invoke component indicating service 3, preferred, receiving a FACILITY message including a Facility information element with a UserUserService return error component indicating "rejectedByUser",

sends no message and remains in the same state.

6.2.1.3.2 **Invocation****UUS_N10_001** **subclause 9.3.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N10 and in the service 3 active state, receiving a USER INFORMATION message including a User-user information element and no More data information element,

accepts the message (resulting in the sending of a USER INFORMATION message to the remote user with a User-user information element and no More data information element), sends no message and remains in the same state.

UUS_N10_002 **subclause 9.3.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N10 and in the service 3 active state, receiving a USER INFORMATION message including a User-user information element and a More data information element,

accepts the message (resulting in the sending of a USER INFORMATION message to the remote user with a User-user information element and no More data information element), sends no message and remains in the same state.

UUS_N10_003 **subclause 9.3.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N10, with service 3 not activated, receiving a USER INFORMATION message including a User-user information element,

discards the message, optionally sends a STATUS message with cause value #43 "access information discarded" and remains in the same state.

UUS_N10_004 **subclause 9.3.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N10 and in the service 3 active state, receiving a USER INFORMATION message including a User-user information element with an overall length exceeding 131 octets,

discards the message, optionally sends a STATUS message with cause value #43 "access information discarded" and remains in the same state.

UUS_N10_005 **subclause 9.3.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N03 and in the service 3 active state, receiving a USER INFORMATION message including a User-user information element,

discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;

or

discards the message, sends a STATUS ENQUIRY message and remains in the same state.

UUS_N10_006 **subclause 9.3.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N04 and in the service 3 active state, receiving a USER INFORMATION message including a User-user information element,

discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;

or

discards the message, sends a STATUS ENQUIRY message and remains in the same state.

UUS_N10_007 **subclause 9.3.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N12 and in the service 3 active state, receiving a USER INFORMATION message including a User-user information element,

discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;

or

discards the message, sends a STATUS ENQUIRY message and remains in the same state.

UUS_N10_008 **subclause 9.3.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N19 and in the service 3 active state, receiving a USER INFORMATION message including a User-user information element,

discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;

or

discards the message, sends a STATUS ENQUIRY message and remains in the same state.

6.2.1.3.3 **Flow control****UUS_N11_001** **subclause 9.3.3.1** **valid** **mandatory**

Ensure that the IUT, in the call state N10 and in the service 3 active state, within the period T2-UUS3 (10 s), receiving N (16) USER INFORMATION messages,

sends no message and remains in the same state.

UUS_N11_002 **subclause 9.3.3.1** **valid** **mandatory**

Ensure that the IUT, in the call state N10 and in the service 3 active state, within the period T2-UUS3 (10 s), having already received N (16) USER INFORMATION messages, receiving a USER INFORMATION message,

sends a CONGESTION CONTROL message including a Congestion level information element indicating "receiver not ready" and a Cause information element with the cause value #43 "access information discarded" and remains in the same state.

UUS_N11_003 **subclause 9.3.3.1** **valid** **mandatory**

Ensure that the IUT, in the call state N10 and in the service 3 active state, within the period T2-UUS3 (10 s), having sent a CONGESTION CONTROL message including a Congestion level information element indicating "receiver not ready", receiving a USER INFORMATION message,

sends no message and remains in the same state.

UUS_N11_004 **subclause 9.3.3.1** **valid** **mandatory**

Ensure that the IUT, in the call state N10 and in the service 3 active state, within the period T2-UUS3 (10 s), having sent a CONGESTION CONTROL message including a Congestion level information element indicating "receiver not ready", to indicate that the flow control restrictions has been removed,

sends a CONGESTION CONTROL message including a Congestion level information element indicating "receiver ready" and remains in the same state.

NOTE: The expiration of T2-UUS3 (10 s) shall remove the flow control restrictions.

UUS_N11_005 **subclause 9.3.3.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N10 and in the service 3 active state, receiving a CONGESTION CONTROL message,

sends a STATUS message including a Cause information element with the cause value #111 "protocol error, unspecified" and remains in the same state.

UUS_N11_006 **subclause 9.3.3.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N04 and in the service 3 active state, receiving a CONGESTION CONTROL message,

sends a STATUS message including a Cause information element with the cause value #101 "message not compatible with call state" and remains in the same state.

6.2.2 Remote user**6.2.2.1 Service 1**

Selection: Does the IUT support service 1. PICS: MC 2.1

6.2.2.1.1 Activation**6.2.2.1.1.1 Implicitly requested****UUS_N12_001 subclause 9.1.1.1.1 valid mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a User-user information element without user information, having received an ALERTING message, sends no message and enters the call state N07.

6.2.2.1.1.2 Explicitly requested**UUS_N13_001 subclause 9.1.1.2.1 valid mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred, receiving an ALERTING message including a Facility information element with a UserUserService return result component,

accepts the message (resulting in the inclusion of the same Facility information element in the ALERTING message sent to the served user) and enters the call state N07.

UUS_N13_002 subclause 9.1.1.2.1 valid mandatory

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred, and receiving an ALERTING message including a Facility information element with a UserUserService return result component for CES1 and a UserUserService return error component for CES2, with CES1 sending prior to CES2,

accepts the message (resulting in the inclusion of the same Facility information element in the ALERTING message sent to the served user) and enters the call state N07 for CES1;

discards the message (resulting in the sending of no message to the served user), sends a RELEASE message including a Cause information element with the cause value #26 "Non-selected user clearing" and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_003 subclause 9.1.1.2.1 valid mandatory

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required, receiving an ALERTING message including a Facility information element with a UserUserService return result component,

accepts the message (resulting in the inclusion of the same Facility information element in the ALERTING message sent to the served user) and enters the call state N07.

UUS_N13_004 subclause 9.1.1.2.1 valid mandatory

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required, and receiving an ALERTING message including a Facility information element with a UserUserService return result component for CES1 and a UserUserService return error component for CES2, with CES1 sending prior to CES2,

accepts the message (resulting in the inclusion of the same Facility information element in the ALERTING message sent to the served user) and enters the call state N07 for CES1;

discards the message (resulting in the sending of no message to the served user), sends a RELEASE message including a Cause information element with the cause value #26 "Non-selected user clearing" and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_005 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred, receiving a CONNECT message including a Facility information element with a UserUserService return result component,

accepts the message (resulting in the inclusion of the same Facility information element in the CONNECT message sent to the served user), sends a CONNECT ACKNOWLEDGE message and enters the call state N10.

UUS_N13_006 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N07 for CES1 and CES2, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred, receiving a CONNECT message including a Facility information element with a UserUserService return result component for CES1,

accepts the message (resulting in the sending of a CONNECT message to the served user with the same User-user information element), sends a CONNECT ACKNOWLEDGE message and enters the call state N10 for CES1;

sends a RELEASE message including a Cause information element with the cause value #26 "Non-selected user clearing" and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_007 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required, receiving a CONNECT message including a Facility information element with a UserUserService return result component,

accepts the message (resulting in the inclusion of the same Facility information element in the CONNECT message sent to the served user), sends a CONNECT ACKNOWLEDGE message and enters the call state N10.

UUS_N13_008 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N07 for CES1 and CES2, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required, receiving a CONNECT message including a Facility information element with a UserUserService return result component for CES1,

accepts the message (resulting in the sending of a CONNECT message to the served user with the same User-user information element), sends a CONNECT ACKNOWLEDGE message and enters the call state N10 for CES1;

sends a RELEASE message including a Cause information element with the cause value #26 "Non-selected user clearing" and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_009 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred, receiving a RELEASE COMPLETE message including a Facility information element with a UserUserService return result component,

accepts the message (resulting in the inclusion of the same Facility information element in the DISCONNECT message sent to the served user), and enters the call state N00.

UUS_N13_010 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required, receiving a RELEASE COMPLETE message including a Facility information element with a UserUserService return result component,

accepts the message (resulting in the inclusion of the same Facility information element in the DISCONNECT message sent to the served user), and enters the call state N00.

UUS_N13_011 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred for CES1 and CES2, receiving a RELEASE COMPLETE message (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" for CES1 and with the cause value #17 "user busy" for CES2, with CES1 sending prior to CES2,

discards the User-user and Cause information elements, sends no message and enters the call state N00 for CES1;

accepts the message (resulting in the inclusion of a User-user information element and a Cause information element with the cause value #17 "user busy" in the DISCONNECT message sent to the served user), sends no message and enters the call state N00 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_012 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required for CES1 and CES2, receiving a RELEASE COMPLETE message (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" for CES1 and with the cause value #17 "user busy" for CES2, with CES1 sending prior to CES2,

discards the User-user and Cause information elements, sends no message and enters the call state N00 for CES1;

accepts the message (resulting in the inclusion of a User-user information element and a Cause information element with the cause value #17 "user busy" in the DISCONNECT message sent to the served user), sends no message and enters the call state N00 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_013 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred for CES1 and CES2, receiving a RELEASE COMPLETE message for CES1 (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" and a RELEASE COMPLETE message for CES2 (premature call clearing) without User-user information element and including a Cause information element with the cause value #17 "user busy", with CES1 sending prior to CES2,

discards the User-user and Cause information elements, sends no message and enters the call state N00 for CES1;

accepts the message (resulting in the inclusion of no User-user information element and a Cause information element with the cause value #17 "user busy" in the DISCONNECT message sent to the served user), sends no message and enters the call state N00 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_014 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required for CES1 and CES2, receiving a RELEASE COMPLETE message for CES1 (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" and a RELEASE COMPLETE message for CES2 (premature call clearing) without User-user information element and including a Cause information element with the cause value #17 "user busy", with CES1 sending prior to CES2,

discards the User-user and Cause information elements, sends no message and enters the call state N00 for CES1;

accepts the message (resulting in the inclusion of no User-user information element and a Cause information element with the cause value #17 "user busy" in the DISCONNECT message sent to the served user), sends no message and enters the call state N00 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_015 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred for CES1 and CES2, receiving a RELEASE COMPLETE message (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" for CES1 and CES2, with CES1 sending prior to CES2,

accepts the message (resulting in the inclusion of a User-user information element and a Cause information element with the cause value #21 "call rejected" in the DISCONNECT message sent to the served user), sends no message and enters the call state N00 for CES1;

discards the User-user and Cause information elements, sends no message and enters the call state N00 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_016 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required for CES1 and CES2, receiving a RELEASE COMPLETE message (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" for CES1 and CES2, with CES1 sending prior to CES2,

accepts the message (resulting in the inclusion of a User-user information element and a Cause information element with the cause value #21 "call rejected" in the DISCONNECT message sent to the served user), sends no message and enters the call state N00 for CES1;

discards the User-user and Cause information elements, sends no message and enters the call state N00 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_017 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N25 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred, receiving a DISCONNECT message including a Facility information element with a UserUserService return result component,

accepts the message (resulting in the inclusion of the same Facility information element in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19.

UUS_N13_018 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N25 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required, receiving a DISCONNECT message including a Facility information element with a UserUserService return result component,

accepts the message (resulting in the inclusion of the same Facility information element in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19.

UUS_N13_019 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N25 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred for CES1 and CES2, receiving a DISCONNECT message (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" for CES1 and with the cause value #17 "user busy" for CES2, with CES1 sending prior to CES2,

discards the User-user and Cause information elements, sends a RELEASE message and enters the call state N19 for CES1;

accepts the message (resulting in the inclusion of a User-user information element and a Cause information element with the cause value #17 "user busy" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_020 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N25 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required for CES1 and CES2, receiving a DISCONNECT message (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" for CES1 and with the cause value #17 "user busy" for CES2, with CES1 sending prior to CES2,

discards the User-user and Cause information elements, sends a RELEASE message and enters the call state N19 for CES1;

accepts the message (resulting in the inclusion of a User-user information element and a Cause information element with the cause value #17 "user busy" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_021 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N25 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred for CES1 and CES2, receiving a DISCONNECT message for CES1 (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" and a DISCONNECT message for CES2 (premature call clearing) without User-user information element and including a Cause information element with the cause value #17 "user busy", with CES1 sending prior to CES2,

discards the User-user and Cause information elements, sends a RELEASE message and enters the call state N19 for CES1;

accepts the message (resulting in the inclusion of no User-user information element and a Cause information element with the cause value #17 "user busy" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_022 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N25 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required for CES1 and CES2, receiving a DISCONNECT message for CES1 (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" and a DISCONNECT message for CES2 (premature call clearing) without User-user information element and including a Cause information element with the cause value #17 "user busy", with CES1 sending prior to CES2,

discards the User-user and Cause information, sends a RELEASE message and enters the call state N19 for CES1;

accepts the message (resulting in the inclusion of no User-user information element and a Cause information element with the cause value #17 "user busy" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_023 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N25 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred for CES1 and CES2, receiving a DISCONNECT message (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" for CES1 and CES2, with CES1 sending prior to CES2,

accepts the message (resulting in the inclusion of a User-user information element and a Cause information element with the cause value #21 "call rejected" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19 for CES1;

discards the User-user and Cause information elements, sends a RELEASE message and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_024 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N25 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required for CES1 and CES2, receiving a DISCONNECT message (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" for CES1 and CES2, with CES1 sending prior to CES2,

accepts the message (resulting in the inclusion of a User-user information element and a Cause information element with the cause value #21 "call rejected" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19 for CES1;

discards the User-user and Cause information elements, sends a RELEASE message and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_025 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N09 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred, receiving a DISCONNECT message including a Facility information element with a UserUserService return result component,

accepts the message (resulting in the inclusion of the same Facility information element in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19.

UUS_N13_026 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N09 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required, receiving a DISCONNECT message including a Facility information element with a UserUserService return result component,

accepts the message (resulting in the inclusion of the same Facility information element in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19.

UUS_N13_027 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N09 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred for CES1 and CES2, receiving a DISCONNECT message (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" for CES1 and with the cause value #17 "user busy" for CES2, with CES1 sending prior to CES2,

discards the User-user and Cause information elements, sends a RELEASE message and enters the call state N19 for CES1;

accepts the message (resulting in the inclusion of a User-user information element and a Cause information element with the cause value #17 "user busy" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_028 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N09 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required for CES1 and CES2, receiving a DISCONNECT message (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" for CES1 and with the cause value #17 "user busy" for CES2, with CES1 sending prior to CES2,

discards the User-user and Cause information elements, sends a RELEASE message and enters the call state N19 for CES1;

accepts the message (resulting in the inclusion of a User-user information element and a Cause information element with the cause value #17 "user busy" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_029 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N09 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred for CES1 and CES2, receiving a DISCONNECT message for CES1 (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" and a DISCONNECT message for CES2 (premature call clearing) without User-user information element and including a Cause information element with the cause value #17 "user busy", with CES1 sending prior to CES2,

discards the User-user and Cause information elements, sends a RELEASE message and enters the call state N19 for CES1;

accepts the message (resulting in the inclusion of no User-user information element and a Cause information element with the cause value #17 "user busy" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_030 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N09 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required for CES1 and CES2, receiving a DISCONNECT message for CES1 (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" and a DISCONNECT message for CES2 (premature call clearing) without User-user information element and including a Cause information element with the cause value #17 "user busy", with CES1 sending prior to CES2,

discards the User-user and Cause information elements, sends a RELEASE message and enters the call state N19 for CES1;

accepts the message (resulting in the inclusion of no User-user information element and a Cause information element with the cause value #17 "user busy" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_031 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N09 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred for CES1 and CES2, receiving a DISCONNECT message (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" for CES1 and CES2, with CES1 sending prior to CES2,

accepts the message (resulting in the inclusion of a User-user information element and a Cause information element with the cause value #21 "call rejected" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19 for CES1;

discards the User-user and Cause information elements, sends a RELEASE message and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_032 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N09 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required for CES1 and CES2, receiving a DISCONNECT message (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" for CES1 and CES2, with CES1 sending prior to CES2,

accepts the message (resulting in the inclusion of a User-user information element and a Cause information element with the cause value #21 "call rejected" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19 for CES1;

discards the User-user and Cause information elements, sends a RELEASE message and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_033 **subclause 9.1.1.2.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred, receiving a CONNECT message without service 1 accept or reject,

accepts the message (resulting in the sending of a CONNECT message to the served user with the error value "rejectedByUser"), sends a CONNECT ACKNOWLEDGE message and enters the call state N10.

UUS_N13_034 **subclause 9.1.1.2.2, clause 10** **inopportune** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred, receiving a CONNECT message without service 1 accept or reject,

accepts the message (resulting in the sending of a CONNECT message to the served user with the error value "rejectedByUser" or "rejectedByNetwork"), sends a CONNECT ACKNOWLEDGE message and enters the call state N10.

Selection: T reference point procedures supported. PICS: R 3.2.

NOTE 1: Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

UUS_N13_035 **subclause 9.1.1.2.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required, receiving a CONNECT message without service 1 accept or reject,

accepts the message (resulting in the sending of a DISCONNECT message to the served user with the cause value #69 "requested facility not implemented" and the error value "rejectedByUser"), sends a DISCONNECT message with cause value #31 "normal unspecified and enters the call state N12.

UUS_N13_036 **subclause 9.1.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N07 for CES1 and CES2, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required, receiving a CONNECT message without service 1 accept nor reject for CES1,

accepts the message (resulting in the sending of a DISCONNECT message to the served user with the cause value #69 "requested facility not implemented" and the error value "rejectedByUser"), sends a DISCONNECT message with cause value #31 "normal unspecified and enters the call state N12 for CES1;

sends a RELEASE message including a Cause information element with the cause value #26 "Non-selected user clearing" and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_037 **subclause 9.1.1.2.2, clause 10** **inopportune** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required, receiving a CONNECT message without service 1 accept or reject,

accepts the message (resulting in the sending of a DISCONNECT message to the served user with the cause value #69 "requested facility not implemented" and the error value "rejectedByUser" or "rejectedByNetwork"), sends a DISCONNECT message with cause value #31 "normal unspecified" and enters the call state N12.

Selection: T reference point procedures supported. PICS: R 3.2.

NOTE 2: Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

UUS_N13_038 **subclause 9.1.1.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred, receiving a DISCONNECT message without UserUserService return result or return error component,

accepts the message (resulting in the sending of a DISCONNECT message to the served user without service 1 related component), sends a RELEASE message without service 1 related component and enters the call state N19.

UUS_N13_039 **subclause 9.1.1.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required, receiving a DISCONNECT message without UserUserService return result or return error component,

accepts the message (resulting in the sending of a DISCONNECT message to the served user without service 1 related component), sends a RELEASE message without service 1 related component and enters the call state N19.

UUS_N13_040 **subclause 9.1.1.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred, receiving an ALERTING message including a Facility information element with a UserUserService return error component with the value "rejectedByUser",

accepts the message (resulting in the inclusion of a UserUserService return error component with the value "rejectedByUser" in the ALERTING message sent to the served user), sends no message and enters the call state N07.

UUS_N13_041 **subclause 9.1.1.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred, and receiving an ALERTING message including a Facility information element with a UserUserService return error component with the value "rejectedByUser" for CES1 and a UserUserService return result component for CES2, with CES1 sending prior to CES2,

accepts the message (resulting in the inclusion of a UserUserService return error component with the value "rejectedByUser" in the ALERTING message sent to the served user), sends no message and enters the call state N07 for CES1,

discards the message, sends no message and enters the call state N07 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_042 **subclause 9.1.1.2.2, clause 10** **invalid** **optional**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred, receiving an ALERTING message including a Facility information element with a UserUserService return error component with the value "rejectedByNetwork",

accepts the message (resulting in the inclusion of a UserUserService return error component with the value "rejectedByUser" or "rejectedByNetwork" in the ALERTING message sent to the served user), sends no message and enters the call state N07.

Selection: T reference point procedures supported. PICS: R 3.2.

NOTE 3: Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

UUS_N13_043 **subclause 9.1.1.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred, receiving a CONNECT message including a Facility information element with a UserUserService return error component with the value "rejectedByUser",

accepts the message (resulting in the inclusion of a UserUserService return error component with the value "rejectedByUser" in the CONNECT message sent to the served user), sends a CONNECT ACKNOWLEDGE message and enters the call state N10.

UUS_N13_044 **subclause 9.1.1.2.2, clause 10** **invalid** **optional**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 preferred, receiving a CONNECT message including a Facility information element with a UserUserService return error component with the value "rejectedByNetwork",

accepts the message (resulting in the inclusion of a UserUserService return error component with the value "rejectedByUser" or "rejectedByNetwork" in the CONNECT message sent to the served user), sends a CONNECT ACKNOWLEDGE message and enters the call state N10.

Selection: T reference point procedures supported. PICS: R 3.2.

NOTE 4: Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

UUS_N13_045 **subclause 9.1.1.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required, receiving a DISCONNECT message with a Facility information element including a UserUserService return error component with the value "rejectedByUser" and a Cause information element with the cause value #29 "facility rejected",

accepts the message (resulting in the sending of a DISCONNECT message to the served user with the error value "rejectedByUser" and the cause value #29 "facility rejected"), sends a RELEASE message and enters the call state N19.

UUS_N13_046 **subclause 9.1.1.2.2, clause 10** **invalid** **optional**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required, receiving a DISCONNECT message with a Facility information element including a UserUserService return error component with the value "rejectedByNetwork" and a Cause information element with the cause value #29 "facility rejected",

accepts the message (resulting in the sending of a DISCONNECT message to the served user with the error value "rejectedByUser" or "rejectedByNetwork" and the cause value #29 "facility rejected"), sends a RELEASE message and enters the call state N19.

Selection: T reference point procedures supported. PICS: R 3.2.

NOTE 5: Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

UUS_N13_047 **subclause 9.1.1.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required, receiving a RELEASE COMPLETE message with a Facility information element including a UserUserService return error component with the value "rejectedByUser" and a Cause information element with the cause value #29 "facility rejected",

accepts the message (resulting in the sending of a DISCONNECT message to the served user with the error value "rejectedByUser" and the cause value #29 "facility rejected"), sends no message and enters the call state N00.

UUS_N13_048 **subclause 9.1.1.2.2, clause 10** **invalid** **optional**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required, receiving a RELEASE COMPLETE message with a Facility information element including a UserUserService return error component with the value "rejectedByNetwork" and a Cause information element with the cause value #29 "facility rejected",

accepts the message (resulting in the sending of a DISCONNECT message to the served user with the error value "rejectedByUser" or "rejectedByNetwork" and the cause value #29 "facility rejected"), sends no message and enters the call state N00.

Selection: T reference point procedures supported. PICS: R 3.2.

NOTE 6: Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

UUS_N13_049 **subclause 9.1.1.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required, receiving an ALERTING message including a Facility information element with a UserUserService return error component with the error value "rejectedByUser",

accepts the message (resulting in the sending of a DISCONNECT message to the served user with the error value "rejectedByUser" and the cause value #69 "requested facility not implemented"), sends a DISCONNECT message with the cause value #31 "normal, unspecified" and enters the call state N12.

UUS_N13_050 **subclause 9.1.1.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required, and receiving an ALERTING message including a Facility information element with a UserUserService return error component with the value "rejectedByUser" for CES1 and a UserUserService return result component for CES2, with CES1 sending prior to CES2,

accepts the message (resulting in the sending of a DISCONNECT message to the served user with the error value "rejectedByUser" and the cause value #69 "requested facility not implemented"), sends a DISCONNECT message with the error value "rejectedByUser" and the cause value #31 "normal, unspecified" and enters the call state N12 for CES1;

discards the message and sends a RELEASE message including a Cause information element with the cause value #26 "Non-selected user clearing" and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N13_051 **subclause 9.1.1.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required, receiving an ALERTING message including a Facility information element with a UserUserService return error component with the error value "rejectedByNetwork",

accepts the message (resulting in the sending of a DISCONNECT message to the served user with the error value "rejectedByUser" or "rejectedByNetwork" and the cause value #69 "requested facility not implemented"), sends a DISCONNECT message with the error value "rejectedByUser" and the cause value #31 "normal, unspecified" and enters the call state N12.

Selection: T reference point procedures supported. PICS: R 3.2.

NOTE 7: Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

UUS_N13_052 **subclause 9.1.1.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required, receiving a CONNECT message including a Facility information element with a UserUserService return error component with the error value "rejectedByUser",

accepts the message (resulting in the sending of a DISCONNECT message to the served user with the error value "rejectedByUser" and the cause value #69 "requested facility not implemented"), sends a DISCONNECT message with the error value "rejectedByUser" and the cause value #29 "facility rejected" and enters the call state N12.

UUS_N13_053 **subclause 9.1.1.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1 required, receiving a CONNECT message including a Facility information element with a UserUserService return error component with the error value "rejectedByNetwork",

accepts the message (resulting in the sending of a DISCONNECT message to the served user with the error value "rejectedByUser" or "rejectedByNetwork" and the cause value #69 "requested facility not implemented"), sends a DISCONNECT message with the error value "rejectedByUser" and the cause value #29 "facility rejected" and enters the call state N12.

Selection: T reference point procedures supported. PICS: R 3.2.

NOTE 8: Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

6.2.2.1.2 Invocation**6.2.2.1.2.1 During call establishment****UUS_N14_001 subclause 9.1.2.1.1 valid mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message including a User-user information element, and receiving an ALERTING message with a User-user information element including user information,

accepts the message (resulting in the sending of an ALERTING message to the served user with the same User-user information element) sends no message and enters the call state N07.

UUS_N14_002 subclause 9.1.2.1.1 valid mandatory

Ensure that the IUT, in the call state N06, having sent a valid SETUP message including a User-user information element, and receiving an ALERTING message with a User-user information element including user information for CES1 and CES2, with CES1 sending prior to CES2,

accepts the message (resulting in the sending of an ALERTING message to the served user with the same User-user information element), sends no message and enters the call state N07 for CES1;

discards the message, sends no message and enters the call state N07 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13]

UUS_N14_003 subclause 9.1.2.1.1 valid mandatory

Ensure that the IUT, in the call state N07, having sent a valid SETUP message including a User-user information element and received an ALERTING message with a User-user information element including user information, and receiving a CONNECT message with a User-user information element including user information,

accepts the message (resulting in the sending of a CONNECT message to the served user with the same User-user information element) sends a CONNECT ACKNOWLEDGE message and enters the call state N10.

UUS_N14_004 subclause 9.1.2.1.1 valid mandatory

Ensure that the IUT, in the call state N07 for CES1 and CES2, having sent a valid SETUP message including a User-user information element and received an ALERTING message with a User-user information element including user information for CES1 and CES2, and receiving a CONNECT message with a User-user information element including user information for CES1,

accepts the message (resulting in the sending of a CONNECT message to the served user with the same User-user information element) sends a CONNECT ACKNOWLEDGE message and enters the call state N10 for CES1, and sends a RELEASE message including a Cause information element with the cause value #26 "Non-selected user clearing" and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13]

UUS_N14_005 subclause 9.1.2.1.1 valid mandatory

Ensure that the IUT, in the call state N06, having sent a valid SETUP message including a User-user information element, and receiving a CONNECT message with a User-user information element including user information,

accepts the message (resulting in the sending of a CONNECT message to the served user with the same User-user information element) sends a CONNECT ACKNOWLEDGE message and enters the call state N10.

NOTE: This test purpose correspond to the activation and the invocation of UUS service 1 at the same time.

UUS_N14_006 subclause 9.1.2.1.1 valid mandatory

Ensure that the IUT, in the call state N07 for CES1 and CES2, having sent a valid SETUP message including a User-user information element, receiving a CONNECT message with a User-user information element including user information for CES1,

accepts the message (resulting in the sending of a CONNECT message to the served user with the same User-user information element) sends a CONNECT ACKNOWLEDGE message and enters the call state N10 for CES1;

sends a RELEASE message including a Cause information element with the cause value #26 "Non-selected user clearing" and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13]

UUS_N14_007 **subclause 9.1.2.1.1** **valid** **mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1, and receiving an ALERTING message with a Facility information element including a UserUserService return result component and a User-user information element with user information,

accepts the message (resulting in the sending of an ALERTING message to the served user with a Facility information element including a UserUserService return result component and with the same User-user information element) sends no message and enters the call state N07.

Selection: Does the IUT support the procedures associated with the explicit request of service 1.
PICS: MC 2.1.2.

UUS_N14_008 **subclause 9.1.2.1.1** **valid** **mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1, and receiving an ALERTING message with a Facility information element including a UserUserService return result component and a User-user information element with user information for CES1 and CES2, with CES1 sending prior to CES2,

accepts the message (resulting in the sending of an ALERTING message to the served user with a Facility information element including a UserUserService return result component and with the same User-user information element), sends no message and enters the call state N07 for CES1; discards the message, sends no message and enters the call state N07 for CES2.

Selection: Does the IUT support the procedures associated with the explicit request of service 1.
PICS: MC 2.1.2 AND
Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13]

UUS_N14_009 **subclause 9.1.2.1.1** **valid** **mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1, and receiving a CONNECT message with a Facility information element including a UserUserService return result component and a User-user information element with user information,

accepts the message (resulting in the sending of a CONNECT message to the served user with a Facility information element including a UserUserService return result component and with the same User-user information element) sends a CONNECT ACKNOWLEDGE message and enters the call state N10.

Selection: Does the IUT support the procedures associated with the explicit request of service 1.
PICS: MC 2.1.2.

UUS_N14_010 **subclause 9.1.2.1.1** **valid** **mandatory**

Ensure that the IUT, in the call state N07 and in the active state for service 1 requested explicitly, for CES1 and CES2, receiving a CONNECT message with a Facility information element including a UserUserService return result component and a User-user information element with user information for CES1,

accepts the message (resulting in the sending of a CONNECT message to the served user with a Facility information element including a UserUserService return result component and with the same User-user information element), sends a CONNECT ACKNOWLEDGE message and enters the call state N10 for CES1;

discards the message, sends a RELEASE message including a Cause information element with the cause value #26 "Non-selected user clearing" and enters the call state N19 for CES2.

Selection: Does the IUT support the procedures associated with the explicit request of service 1.
PICS: MC 2.1.2 AND
Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N14_011 **subclause 9.1.2.1.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message including a User-user information element with user information, and receiving an ALERTING message including a User-user information element with an overall length exceeding 131 octets,

discards the User-user information element (resulting in the sending of an ALERTING message to the served user without User-user information element), sends no message or optionally sends a STATUS message with cause value #43 "access information discarded" and enters the call state N07.

UUS_N14_012 **subclause 9.1.2.1.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message including a User-user information element with user information, and receiving a CONNECT message including a User-user information element with an overall length exceeding 131 octets,
discards the User-user information element (resulting in the sending of a CONNECT message to the served user without User-user information element), continue normal call handling, and optionally sends a STATUS message with cause value #43 "access information discarded" and enters the call state N10.

UUS_N14_013 **subclause 9.1.2.1.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1, and receiving an ALERTING message including a User-user information element (service 1 is not yet activated),
discards the User-user information element (resulting in the sending of an ALERTING message to the served user without User-user information element), sends no message or optionally sends a STATUS message with cause value #43 "access information discarded" and enters the call state N10.

UUS_N14_014 **subclause 9.1.2.1.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 1, and receiving a CONNECT message including a User-user information element (service 1 is not yet activated),
discards the User-user information element (resulting in the sending of a CONNECT message to the served user without User-user information element), continue normal call handling and optionally sends a STATUS message with cause value #43 "access information discarded" and enters the call state N10.

6.2.2.1.2.2 **During call clearing****6.2.2.1.2.2.1** **Clearing initiated by the calling user****UUS_N15_001** **subclause 9.1.2.1.1** **valid** **mandatory**

Ensure that the IUT, in the call state N07 and in the service 1 active state, for CES1 and CES2, to indicate that the served user has sent a DISCONNECT message including a User-user information element (premature call clearing),

send a RELEASE message including a User-user information element and enters the call state N19 for CES1 and CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

6.2.2.1.2.2.2 **Clearing initiated by the called user****UUS_N16_001** **subclause 9.1.2.2.1.b** **valid** **mandatory**

Ensure that the IUT, in the call state N10 (incoming call) and in the service 1 active state, receiving a DISCONNECT message including a User-user information element,
accepts the message (resulting in the inclusion of a User-user information element in the DISCONNECT message sent to served user), sends a RELEASE message and enters the call state N19.

UUS_N16_002 **subclause 9.1.2.2.1.b** **valid** **mandatory**

Ensure that the IUT, in the call state N06 and in the service 1 active state, receiving a RELEASE COMPLETE message (premature call clearing) including a User-user information element,
accepts the message (resulting in the inclusion of a User-user information element in the DISCONNECT message sent to served user), sends no message and enters the call state N00.

Selection: Point-to-point configuration supported. PICS: R 7.1 [12] and [13].

UUS_N16_003 **subclause 9.1.2.2.1.b** **valid** **mandatory**

Ensure that the IUT, in the call state N06 and in the service 1 active state (implicitly requested), for CES1 and CES2, receiving a RELEASE COMPLETE message (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" for CES1 and with the cause value #17 "user busy" for CES2, with CES1 sending prior to CES2,

discards the User-user and Cause information elements, sends no message and enters the call state N00 for CES1;

accepts the message (resulting in the inclusion of a User-user information element and a Cause information element with the cause value #17 "user busy" in the DISCONNECT message sent to the served user), sends no message and enters the call state N00 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N16_004 **subclause 9.1.2.2.1.b** **valid** **mandatory**

Ensure that the IUT, in the call state N06 and in the service 1 active state (implicitly requested), for CES1 and CES2, receiving a RELEASE COMPLETE message for CES1 (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" and a RELEASE COMPLETE message for CES2 (premature call clearing) without User-user information element and including a Cause information element with the cause value #17 "user busy", with CES1 sending prior to CES2,

discards the User-user and Cause information elements, sends no message and enters the call state N00 for CES1;

accepts the message for CES2 (resulting in the inclusion of no User-user information element and a Cause information element with the cause value #17 "user busy" in the DISCONNECT message sent to the served user), sends no message and enters the call state N00 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N16_005 **subclause 9.1.2.2.1.b** **valid** **mandatory**

Ensure that the IUT, in the call state N06 and in the service 1 active state (implicitly requested), for CES1 and CES2, receiving a RELEASE COMPLETE message (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" for CES1 and CES2, with CES1 sending prior to CES2,

accepts the message (resulting in the inclusion of a User-user information element and a Cause information element with the cause value #21 "call rejected" in the DISCONNECT message sent to the served user), sends no message and enters the call state N00 for CES1;

discards the User-user and Cause information elements, sends no message and enters the call state N00 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N16_006 **subclause 9.1.2.2.1.b** **valid** **mandatory**

Ensure that the IUT, in the call state N25 and in the service 1 active state, receiving a DISCONNECT message (premature call clearing) including a User-user information element,

accepts the message (resulting in the inclusion of a User-user information element in the DISCONNECT message sent to served user), sends a RELEASE message and enters the call state N19.

Selection: Point-to-point configuration supported. PICS: R 7.1 [12] and [13].

UUS_N16_007 **subclause 9.1.2.2.1.b** **valid** **mandatory**

Ensure that the IUT, in the call state N25 and in the service 1 active state (implicitly requested), for CES1 and CES2, receiving a DISCONNECT message (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" for CES1 and with the cause value #17 "user busy" for CES2, with CES1 sending prior to CES2,

discards the User-user and Cause information elements, sends a RELEASE message and enters the call state N19 for CES1;

accepts the message (resulting in the inclusion of a User-user information element and a Cause information element with the cause value #17 "user busy" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N16_008 **subclause 9.1.2.2.1.b** **valid** **mandatory**

Ensure that the IUT, in the call state N25 and in the service 1 active state (implicitly requested), for CES1 and CES2, receiving a DISCONNECT message for CES1 (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" and a DISCONNECT message for CES2 (premature call clearing) without User-user information element and including a Cause information element with the cause value #17 "user busy", with CES1 sending prior to CES2,

discards the User-user and Cause information elements, sends a RELEASE message and enters the call state N19 for CES1;

accepts the message (resulting in the inclusion of no User-user information element and a Cause information element with the cause value #17 "user busy" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N16_009 **subclause 9.1.2.2.1.b** **valid** **mandatory**

Ensure that the IUT, in the call state N25 and in the service 1 active state (implicitly requested), for CES1 and CES2, receiving a DISCONNECT message (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" for CES1 and CES2, with CES1 sending prior to CES2,

accepts the message (resulting in the inclusion of a User-user information element and a Cause information element with the cause value #21 "call rejected" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19 for CES1;

discards the User-user and Cause information elements, sends a RELEASE message and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N16_010 **subclause 9.1.2.2.1.b** **valid** **mandatory**

Ensure that the IUT, in the call state N09 and in the service 1 active state, receiving a DISCONNECT message (premature call clearing) including a User-user information element,

accepts the message (resulting in the inclusion of a User-user information element in the DISCONNECT message sent to served user), sends a RELEASE message and enters the call state N19.

Selection: Point-to-point configuration supported. PICS: R 7.1 [12] and [13].

UUS_N16_011 **subclause 9.1.2.2.1.b** **valid** **mandatory**

Ensure that the IUT, in the call state N09 and in the service 1 active state (implicitly requested), for CES1 and CES2, receiving a DISCONNECT message (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" for CES1 and with the cause value #17 "user busy" for CES2, with CES1 sending prior to CES2,

discards the User-user and Cause information elements, sends a RELEASE message and enters the call state N19 for CES1;

accepts the message (resulting in the inclusion of a User-user information element and a Cause information element with the cause value #17 "user busy" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N16_012 **subclause 9.1.2.2.1.b** **valid** **mandatory**

Ensure that the IUT, in the call state N09 and in the service 1 active state (implicitly requested), for CES1 and CES2, receiving a DISCONNECT message for CES1 (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" and a DISCONNECT message for CES2 (premature call clearing) without User-user information element and including a Cause information element with the cause value #17 "user busy", with CES1 sending prior to CES2,

discards the User-user and Cause information elements, sends a RELEASE message and enters the call state N19 for CES1;

accepts the message (resulting in the inclusion of no User-user information element and a Cause information element with the cause value #17 "user busy" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N16_013 **subclause 9.1.2.2.1.b** **valid** **mandatory**

Ensure that the IUT, in the call state N09 and in the service 1 active state (implicitly requested), for CES1 and CES2, receiving a DISCONNECT message (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" for CES1 and CES2, with CES1 sending prior to CES2,

accepts the message (resulting in the inclusion of a User-user information element and a Cause information element with the cause value #21 "call rejected" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19 for CES1;

discards the User-user and Cause information elements, sends a RELEASE message and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N16_014 **subclause 9.1.2.2.1.b** **valid** **mandatory**

Ensure that the IUT, in the call state N07 and in the service 1 active state, receiving a DISCONNECT message (premature call clearing) including a User-user information element,

accepts the message (resulting in the inclusion of a User-user information element in the DISCONNECT message sent to served user), sends a RELEASE message and enters the call state N19.

Selection: Point-to-point configuration supported. PICS: R 7.1 [12] and [13].

UUS_N16_015 **subclause 9.1.2.2.1.b** **valid** **mandatory**

Ensure that the IUT, in the call state N07 and in the service 1 active state, for CES1 and CES2, receiving a DISCONNECT message (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" for CES1 and with the cause value #17 "user busy" for CES2, with CES1 sending prior to CES2,

discards the User-user and Cause information elements, sends a RELEASE message and enters the call state N19 for CES1;

accepts the message (resulting in the inclusion of a User-user information element and a Cause information element with the cause value #17 "user busy" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N16_016 **subclause 9.1.2.2.1.b** **valid** **mandatory**

Ensure that the IUT, in the call state N07 and in the service 1 active state, for CES1 and CES2, receiving a DISCONNECT message for CES1 (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" and a DISCONNECT message for CES2 (premature call clearing) without User-user information element and including a Cause information element with the cause value #17 "user busy", with CES1 sending prior to CES2,

discards the User-user and Cause information elements, sends a RELEASE message and enters the call state N19 for CES1;

accepts the message (resulting in the inclusion of no User-user information element and a Cause information element with the cause value #17 "user busy" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N16_017 **subclause 9.1.2.2.1.b** **valid** **mandatory**

Ensure that the IUT, in the call state N07 and in the service 1 active state, for CES1 and CES2, receiving a DISCONNECT message (premature call clearing) including a User-user information element and a Cause information element with the cause value #21 "call rejected" for CES1 and CES2, with CES1 sending prior to CES2,

accepts the message (resulting in the inclusion of a User-user information element and a Cause information element with the cause value #21 "call rejected" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19 for CES1;

discards the User-user and Cause information elements, sends a RELEASE message and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N16_018 **subclause 9.1.2.2.1.b** **valid** **mandatory**

Ensure that the IUT, in the call state N10 (incoming call) and in the service 1 active state, receiving a RELEASE message (call clearing failure) including a User-user information element,

accepts the message (resulting in the inclusion of a User-user information element in the RELEASE message sent to served user), sends a RELEASE COMPLETE message and enters the call state N00.

UUS_N16_019 **subclause 9.1.2.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N10, (incoming call) with service 1 not activated, receiving a DISCONNECT message including a User-user information element,
 sends a RELEASE message optionally including a Cause information element with cause value #43 "access information discarded" and enters the call state N19.

UUS_N16_020 **subclause 9.1.2.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N10 (incoming call) and in the service 1 active state, receiving a DISCONNECT message including a User-user information element with an overall length exceeding 131 octets,
 sends a RELEASE message optionally including a Cause information element with cause value #43 "access information discarded" and enters the call state N19.

6.2.2.2 **Service 2**

Selection: Does the IUT support service 2. PICS: MC 2.2.

6.2.2.2.1 **Activation****UUS_N17_001** **subclause 9.2.1.1** **valid** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 preferred, receiving an ALERTING message including a Facility information element with a UserUserService return result component,
 accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return result component in the ALERTING message sent to the served user),
 sends no message and enters the call state N07.

UUS_N17_002 **subclause 9.2.1.1** **valid** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 required, receiving an ALERTING message including a Facility information element with a UserUserService return result component,
 accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return result component in the ALERTING message sent to the served user),
 sends no message and enters the call state N07.

UUS_N17_003 **subclause 9.2.1.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 preferred, receiving a CONNECT message (does not receive an ALERTING message),
 accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" or "rejectedByNetwork" in the CONNECT message sent to the served user), sends a CONNECT ACKNOWLEDGE enters the call state N10.

NOTE 1: Implicit rejection of Service 2.
 Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

UUS_N17_004 **subclause 9.2.1.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 required, receiving a CONNECT message (does not receive an ALERTING message),
 accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" and a Cause information element with the cause value #69 "requested facility not implemented" in the DISCONNECT message sent to the served user), sends a DISCONNECT message and enters the call state N12.

NOTE 2: Implicit rejection of Service 2.

UUS_N17_005 **subclause 9.2.1.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 required, receiving a CONNECT message (does not receive an ALERTING message),

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" or "rejectedByNetwork" and a Cause information element with the cause value #69 "requested facility not implemented" in the DISCONNECT message sent to the served user), sends a DISCONNECT message and enters the call state N12.

NOTE 3: Implicit rejection of Service 2.
Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

UUS_N17_006 **subclause 9.2.1.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 preferred, receiving an ALERTING message without UserUserService return result or return error component,

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByNetwork" in the ALERTING message sent to the served user), sends no message and enters the call state N07.

NOTE 4: Implicit rejection of Service 2.

UUS_N17_007 **subclause 9.2.1.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 required, receiving an ALERTING message without UserUserService return result or return error component,

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" and a Cause information element with the cause value #69 "requested facility not implemented" in the DISCONNECT message sent to the served user), sends a DISCONNECT message and enters the call state N12.

NOTE 5: Implicit rejection of Service 2.

UUS_N17_008 **subclause 9.2.1.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 required, receiving an ALERTING message without UserUserService return result or return error component,

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" or "rejectedByNetwork" and a Cause information element with the cause value #69 "requested facility not implemented" in the DISCONNECT message sent to the served user), sends a DISCONNECT message and enters the call state N12.

Selection: T reference point procedures supported. PICS: R 3.2.

NOTE 6: Implicit rejection of Service 2.
Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

UUS_N17_009 **subclause 9.2.1.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 preferred, receiving a DISCONNECT message without UserUserService return error component,

accepts the message (resulting in the sending of a DISCONNECT message to the served user without service return result or return error component), sends a RELEASE message and enters the call state N19.

UUS_N17_010 **subclause 9.2.1.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 required, receiving a DISCONNECT message without UserUserService return error component,
 accepts the message (resulting in the sending of a DISCONNECT message to the served user without service return result or return error component), sends a RELEASE message and enters the call state N19.

UUS_N17_011 **subclause 9.2.1.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 preferred, receiving an ALERTING message including a Facility information element with a UserUserService return error component with the value "rejectedByUser",
 accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" in the ALERTING message sent to the served user), sends no message and enters the call state N07.

UUS_N17_012 **subclause 9.2.1.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 preferred, receiving an ALERTING message including a Facility information element with a UserUserService return error component with the value "rejectedByNetwork",
 accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" or "rejectedByNetwork" in the ALERTING message sent to the served user), sends no message and enters the call state N07.
Selection: T reference point procedures supported. PICS: R 3.2.

NOTE 7: Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

UUS_N17_013 **subclause 9.2.1.2** **valid** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 required, receiving an ALERTING message including a Facility information element with a UserUserService return error component, indicating "rejectedByUser",
 accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" and a Cause information element with the cause value #69 "requested facility not implemented" in the DISCONNECT message sent to the served user), sends a DISCONNECT message with cause value #31 "normal unspecified" and enters the call state N12.

UUS_N17_014 **subclause 9.2.1.2, clause 10** **valid** **mandatory**

Ensure that the IUT, in the call state N06 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 required, receiving an ALERTING message including a Facility information element with a UserUserService return error component, indicating "rejectedByNetwork",
 accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" or "rejectedByNetwork" and a Cause information element with the cause value #69 "requested facility not implemented" in the DISCONNECT message sent to the served user), sends a DISCONNECT message with cause value #31 "normal unspecified" and enters the call state N12.
Selection: T reference point procedures supported. PICS: R 3.2.

NOTE 8: Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

UUS_N17_015 **subclause 9.2.1.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 required, receiving a DISCONNECT message with cause value #29 "facility rejected" and with a Facility information element including a UserUserService return error component with the value "rejectedByUser",

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" and a Cause information element with the cause value #29 "facility rejected" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19.

UUS_N17_016 **subclause 9.2.1.2, clause 10** **invalid** **optional**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 required, receiving a DISCONNECT message with cause value #29 "facility rejected" and with a Facility information element including a UserUserService return error component with the value "rejectedByNetwork",

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" or "rejectedByNetwork" and a Cause information element with the cause value #29 "facility rejected" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19.

Selection: T reference point procedures supported. PICS: R 3.2.

NOTE 9: Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

UUS_N17_017 **subclause 9.2.1.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 required, receiving a RELEASE COMPLETE message with cause value #29 "facility rejected" and with a Facility information element including a UserUserService return error component with the value "rejectedByUser",

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" and a Cause information element with the cause value #29 "facility rejected" in the RELEASE COMPLETE message sent to the served user), sends no message and enters the call state N00.

UUS_N17_018 **subclause 9.2.1.2, clause 10** **invalid** **optional**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 2 required, receiving a RELEASE COMPLETE message with cause value #29 "facility rejected" and with a Facility information element including a UserUserService return error component with the value "rejectedByNetwork",

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" or "rejectedByNetwork" and a Cause information element with the cause value #29 "facility rejected" in the RELEASE COMPLETE message sent to the served user), sends no message and enters the call state N00.

Selection: T reference point procedures supported. PICS: R 3.2.

NOTE 10: Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

6.2.2.2.2 Invocation**UUS_N18_001 subclause 9.2.2.2 valid mandatory**

Ensure that the IUT, in the call state N07 and in the service 2 active state, receiving a USER INFORMATION message including a User-user information element and no More data information element,

accepts the message (resulting in the sending of a USER INFORMATION message to the served user with a User-user information element and no More data information element), sends no message and remains in the same state.

UUS_N18_002 subclause 9.2.2.2 valid mandatory

Ensure that the IUT, in the call state N07 and in the service 2 active state, receiving a USER INFORMATION message including a User-user information element and a More data information element,

accepts the message (resulting in the sending of a USER INFORMATION message to the served user with a User-user information element and a More data information element), sends no message and remains in the same state.

UUS_N18_003 subclause 9.2.2.2 valid mandatory

Ensure that the IUT, in the call state N07 and in the service 2 active state, receiving two USER INFORMATION messages both including a User-user information element,

accepts the messages (resulting in the sending of two USER INFORMATION messages to the served user with a User-user information element), sends no message and remains in the same state.

UUS_N18_004 subclause 9.2.2.2 invalid mandatory

Ensure that the IUT, in the call state N07, with service 2 not activated, receiving a USER INFORMATION message including a User-user information element,

discards the message, optionally sends a STATUS message with cause value #43 "access information discarded" and remains in the same state.

UUS_N18_005 subclause 9.2.2.2 invalid mandatory

Ensure that the IUT, in the call state N07 and in the service 2 active state, receiving three USER INFORMATION messages including a User-user information element,

discards the third message, optionally sends a STATUS message with cause value #43 "access information discarded" and remains in the same state.

UUS_N18_006 subclause 9.2.2.2 invalid mandatory

Ensure that the IUT, in the call state N07 and in the service 2 active state, receiving a USER INFORMATION message including a User-user information element with an overall length exceeding 131 octets,

discards the message, optionally sends a STATUS message with cause value #43 "access information discarded" and remains in the same state.

UUS_N18_007 subclause 9.2.2.2 invalid mandatory

Ensure that the IUT, in the call state N06 and in the service 2 active state, receiving a USER INFORMATION message including a User-user information element,

discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;

or

discards the message, sends a STATUS ENQUIRY message and remains in the same state.

UUS_N18_008 subclause 9.2.2.2 invalid mandatory

Ensure that the IUT, in the call state N25 and in the service 2 active state, receiving a USER INFORMATION message including a User-user information element,

discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;

or

discards the message, sends a STATUS ENQUIRY message and remains in the same state.

UUS_N18_009 **subclause 9.2.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N09 and in the service 2 active state, receiving a USER INFORMATION message including a User-user information element,
discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;
or
discards the message, sends a STATUS ENQUIRY message and remains in the same state.

UUS_N18_010 **subclause 9.2.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N08 and in the service 2 active state, receiving a USER INFORMATION message including a User-user information element,
discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;
or
discards the message, sends a STATUS ENQUIRY message and remains in the same state.

UUS_N18_011 **subclause 9.2.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N10 and in the service 2 active state, receiving a USER INFORMATION message including a User-user information element,
discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;
or
discards the message, sends a STATUS ENQUIRY message and remains in the same state.

UUS_N18_012 **subclause 9.2.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N12 and in the service 2 active state, receiving a USER INFORMATION message including a User-user information element,
discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;
or
discards the message, sends a STATUS ENQUIRY message and remains in the same state.

UUS_N18_013 **subclause 9.2.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N19 and in the service 2 active state, receiving a USER INFORMATION message including a User-user information element,
discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;
or
discards the message, sends a STATUS ENQUIRY message and remains in the same state.

6.2.2.3 Service 3

Selection: Does the IUT support service 3. PICS: MC 2.3.

6.2.2.3.1 Activation**6.2.2.3.1.1 During call establishment****UUS_N19_001 subclause 9.3.1.1.1 valid mandatory**

Ensure that the IUT, in the call state N07 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 preferred, receiving a CONNECT message including a Facility information element with a UserUserService return result component,

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return result component in the CONNECT message sent to the served user), sends a CONNECT ACKNOWLEDGE message and enters the call state N10.

UUS_N19_002 subclause 9.3.1.1.1 valid mandatory

Ensure that the IUT, in the call state N07 for CES1 and CES2, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 preferred, receiving a CONNECT message including a Facility information element with a UserUserService return result component for CES1,

accepts the message (resulting in the sending of a CONNECT message to the served user including a UserUserService return result component), sends a CONNECT ACKNOWLEDGE message and enters the call state N10 for CES1;

sends a RELEASE message including a Cause information element with the cause value #26 "Non-selected user clearing" and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N19_003 subclause 9.3.1.1.1 valid mandatory

Ensure that the IUT, in the call state N07 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 required, receiving a CONNECT message including a Facility information element with a UserUserService return result component,

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return result component in the CONNECT message sent to the served user), sends a CONNECT ACKNOWLEDGE message and enters the call state N10.

UUS_N19_004 subclause 9.3.1.1.1 valid mandatory

Ensure that the IUT, in the call state N07 for CES1 and CES2, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 required, receiving a CONNECT message including a Facility information element with a UserUserService return result component for CES1,

accepts the message (resulting in the sending of a CONNECT message to the served user including a UserUserService return result component) sends a CONNECT ACKNOWLEDGE message and enters the call state N10 for CES1;

sends a RELEASE message including a Cause information element with the cause value #26 "Non-selected user clearing" and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N19_005 subclause 9.3.1.1.2 invalid mandatory

Ensure that the IUT, in the call state N07 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 preferred, receiving a DISCONNECT message without UserUserService return error component,

accepts the message (resulting in the sending of a DISCONNECT message to the served user without UserUserService return error component), sends a RELEASE message and enters the call state N19.

UUS_N19_006 **subclause 9.3.1.1.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N07 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 required, receiving a DISCONNECT message without UserUserService return error component,
 accepts the message (resulting in the sending of a DISCONNECT message to the served user without UserUserService return error component), sends a RELEASE message and enters the call state N19.

UUS_N19_007 **subclause 9.3.1.1.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N07 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 preferred, receiving a CONNECT message without UserUserService return result or return error component,
 accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" in the CONNECT message sent to the served user), sends a CONNECT ACKNOWLEDGE message and enters the call state N10.

UUS_N19_008 **subclause 9.3.1.1.2** **valid** **mandatory**

Ensure that the IUT, in the call state N07 for CES1 and CES2, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 preferred, receiving a CONNECT message without UserUserService return result or return error component for CES1,

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" in the CONNECT message sent to the served user) sends a CONNECT ACKNOWLEDGE message and enters the call state N10 for CES1;

sends a RELEASE message including a Cause information element with the cause value #26 "Non-selected user clearing" and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N19_009 **subclause 9.3.1.1.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N07 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 preferred, receiving a CONNECT message without UserUserService return result or return error component,

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" or "rejectedByNetwork" in the CONNECT message sent to the served user), sends a CONNECT ACKNOWLEDGE message and enters the call state N10.

Selection: T reference point procedures supported. PICS: R 3.2.

NOTE 1: Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

UUS_N19_010 **subclause 9.3.1.1.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N07 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 required, receiving a CONNECT message without UserUserService return result or return error component,

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" and a Cause information element with the cause value #69 "requested facility not implemented" in the DISCONNECT message sent to the served user), sends a DISCONNECT message with cause value #31 "normal unspecified" and enters the call state N11.

UUS_N19_011 **subclause 9.3.1.1.2** **valid** **mandatory**

Ensure that the IUT, in the call state N07 for CES1 and CES2, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 required, receiving a CONNECT message without UserUserService return result or return error component for CES1,

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" and a Cause information element with the cause value #69 "requested facility not implemented" in the DISCONNECT message sent to the served user) sends a DISCONNECT message with cause value #31 "normal unspecified and enters the call state N11 for CES1;

sends a RELEASE message including a Cause information element with the cause value #26 "Non-selected user clearing" and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N19_012 **subclause 9.3.1.1.2** **inopportune** **mandatory**

Ensure that the IUT, in the call state N07 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 required, receiving a CONNECT message without UserUserService return result or return error component,

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" or "rejectedByNetwork" and a Cause information element with the cause value #69 "requested facility not implemented" in the DISCONNECT message sent to the served user), sends a DISCONNECT message with cause value #31 "normal unspecified and enters the call state N11.

Selection: T reference point procedures supported. PICS: R 3.2.

NOTE 2: Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

UUS_N19_013 **subclause 9.3.1.1.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N07, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 preferred, receiving a CONNECT message including a Facility information element with a UserUserService return error component with the value "rejectedByUser",

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" in the CONNECT message sent to the served user), sends a CONNECT ACKNOWLEDGE message and enters the call state N10.

UUS_N19_014 **subclause 9.3.1.1.2** **valid** **mandatory**

Ensure that the IUT, in the call state N07 for CES1 and CES2, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 preferred, receiving a CONNECT message including a Facility information element with a UserUserService return error component with the value "rejectedByUser" for CES1,

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" in the CONNECT message sent to the served user) sends a CONNECT ACKNOWLEDGE message and enters the call state N10 for CES1;

sends a RELEASE message including a Cause information element with the cause value #26 "Non-selected user clearing" and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N19_015 **subclause 9.3.1.1.2, clause 10** **invalid** **optional**

Ensure that the IUT, in the call state N07, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 preferred, receiving a CONNECT message including a Facility information element with a UserUserService return error component with the value "rejectedByNetwork",

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" or "rejectedByNetwork" in the CONNECT message sent to the served user), sends a CONNECT ACKNOWLEDGE message and enters the call state N10.

Selection: T reference point procedures supported. PICS: R 3.2.

NOTE 3: Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

UUS_N19_016 **subclause 9.3.1.1.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N07 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 required, receiving a DISCONNECT message with cause value #29 "facility rejected" and with a Facility information element including a UserUserService return error component with the value "rejectedByUser",

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" and a Cause information element with the cause value #29 "facility rejected" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19.

UUS_N19_017 **subclause 9.3.1.1.2, clause 10** **invalid** **mandatory**

Ensure that the IUT, in the call state N07 having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 required, receiving a DISCONNECT message with cause value #29 "facility rejected" and with a Facility information element including a UserUserService return error component with the value "rejectedByNetwork",

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" or "rejectedByNetwork" and a Cause information element with the cause value #29 "facility rejected" in the DISCONNECT message sent to the served user), sends a RELEASE message and enters the call state N19.

Selection: T reference point procedures supported. PICS: R 3.2.

NOTE 4: Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

UUS_N19_018 **subclause 9.3.1.1.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 required, receiving a RELEASE COMPLETE message with cause value #29 "facility rejected" and with a Facility information element including a UserUserService return error component with the value "rejectedByUser",

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" and a Cause information element with the cause value #29 "facility rejected" in the DISCONNECT message sent to the served user), sends no message and enters the call state N00.

UUS_N19_019 **subclause 9.3.1.1.2** **valid** **mandatory**

Ensure that the IUT, in the call state N06 for CES1 and CES2, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 required, receiving a RELEASE COMPLETE message with cause value #29 "facility rejected" and including a Facility information element with a UserUserService return error component with the value "rejectedByUser" for CES1 and CES2, with CES1 sending prior to CES2,

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" and a Cause information element with the cause value #69 "requested facility not implemented" in the DISCONNECT message sent to the served user) sends a DISCONNECT message with cause value #31 "normal, unspecified" and enters the call state N12 for CES1;

sends a RELEASE message including a Cause information element with the cause value #26 "Non-selected user clearing" and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13].

UUS_N19_020 **subclause 9.3.1.1.2, clause 10** **invalid** **optional**

Ensure that the IUT, in the call state N06, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 required, receiving a RELEASE COMPLETE message with cause value #29 "facility rejected" and with a Facility information element including a UserUserService return error component with the value "rejectedByNetwork",

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" or "rejectedByNetwork" and a Cause information element with the cause value #29 "facility rejected" in the DISCONNECT message sent to the served user), sends no message and enters the call state N00.

Selection: T reference point procedures supported. PICS: R 3.2.

NOTE 5: Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

UUS_N19_021 **subclause 9.3.1.1.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N07, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 required, receiving a CONNECT message including a Facility information element with a UserUserService return error component,

sends a DISCONNECT message with cause value #31 "normal, unspecified" and enters the call state N12.

UUS_N19_022 **subclause 9.3.1.1.2** **valid** **mandatory**

Ensure that the IUT, in the call state N07 for CES1 and CES2, having sent a valid SETUP message with a Facility information element including a UserUserService invoke component indicating service 3 required, receiving a CONNECT message including a Facility information element with a UserUserService return error component with the value "rejectedByUser",

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return error component with the value "rejectedByUser" and a Cause information element with the cause value #69 "requested facility not implemented" in the DISCONNECT message sent to the served user) sends a DISCONNECT message with cause value #31 "normal, unspecified" and enters the call state N12 for CES1;

sends a RELEASE message including a Cause information element with the cause value #26 "Non-selected user clearing" and enters the call state N19 for CES2.

Selection: Point-to-multipoint configuration supported. PICS: R 7.2 [12] and [13]

6.2.2.3.1.2 **During active call state****UUS_N20_001** **subclause 9.3.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N10, having sent a FACILITY message including a Facility information element with a UserUserService invoke component indicating service 3, preferred, receiving a FACILITY message including a Facility information element with a UserUserService return result component,

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService return result component in the FACILITY message sent to the served user), sends no message and remains in the same state.

UUS_N20_002 **subclause 9.3.1.2.1** **valid** **optional**

Ensure that the IUT, in the call state N10, receiving a valid FACILITY message including a Facility information element with a UserUserService invoke component indicating service 3, preferred,

accepts the message (resulting in the inclusion of a Facility information element with a UserUserService invoke component in the FACILITY message sent to the served user), sends no message and remains in the same state.

Selection: Does the IUT support the request of service 3 by the called user. PICS: SC 7.1.

UUS_N20_003 **subclause 9.3.1.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N10, having sent a FACILITY message including a Facility information element with a UserUserService invoke component indicating service 3, preferred, receiving a FACILITY message including a Facility information element with a UserUserService return error component indicating "rejectedByUser",

accepts the message (resulting in the inclusion of a Facility information element including a UserUserService return error component with the value "rejectedByUser" in the FACILITY message sent to the served user), sends no message and remains in the same state.

UUS_N20_004 **subclause 9.3.1.2.2, clause 10** **invalid** **optional**

Ensure that the IUT, in the call state N10, having sent a FACILITY message including a Facility information element with a UserUserService invoke component indicating service 3, preferred, receiving a FACILITY message including a Facility information element with a UserUserService return error component indicating "rejectedByNetwork",

accepts the message (resulting in the inclusion of a Facility information element including a UserUserService return error component with the value "rejectedByUser" or "rejectedByNetwork" in the FACILITY message sent to the served user), sends no message and remains in the same state.

Selection: T reference point procedures supported. PICS: R 3.2.

NOTE 1: Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

UUS_N20_005 **subclause 9.3.1.2.1** **valid** **mandatory**

Ensure that the IUT, in the call state N10, having sent a FACILITY message including a Facility information element with a UserUserService invoke component indicating service 3 preferred, on expiry of timer T1-UUS3,

rejects the service 3 toward the requesting network (resulting in the sending of a FACILITY message to the served user including a Facility information element with a UserUserService invoke component with the error value "rejectedByUser") and remains in the same state.

UUS_N20_006 **subclause 9.3.1.2.1, clause 10** **valid** **optional**

Ensure that the IUT, in the call state N10, having sent a FACILITY message including a Facility information element with a UserUserService invoke component indicating service 3 preferred, on expiry of timer T1-UUS3,

rejects the service 3 toward the requesting network (resulting in the sending of a FACILITY message to the served user including a Facility information element with a UserUserService invoke component with the error value "rejectedByUser" or "rejectedByNetwork") and remains in the same state.

Selection: T reference point procedures supported. PICS: R 3.2.

NOTE 2: Both error values "rejectedByUser" or "rejectedByNetwork" can be received depending if an ISUP network has been encountered or not.

UUS_N20_007 **subclause 9.3.1.2.2** **invalid** **optional**

Ensure that the IUT, in the call state N06, having received a valid FACILITY message including a Facility information element with a UserUserService invoke component indicating service 3 preferred,

sends a FACILITY message including a Facility information element with a UserUserService return error component indicating "rejectedByNetwork" and remains in the same state.

Selection: Does the IUT support the request of service 3 by the called user. PICS: SC 7.1.

UUS_N20_008 **subclause 9.3.1.2.2** **invalid** **optional**

Ensure that the IUT, in the call state N25, having received a valid FACILITY message including a Facility information element with a UserUserService invoke component indicating service 3, preferred,

sends a FACILITY message including a Facility information element with a UserUserService return error component indicating "rejectedByNetwork" and remains in the same state.

Selection: Does the IUT support the request of service 3 by the called user. PICS: SC 7.1.

UUS_N20_009 **subclause 9.3.1.2.2** **invalid** **optional**

Ensure that the IUT, in the call state N09, having received a valid FACILITY message including a Facility information element with a UserUserService invoke component indicating service 3, preferred,

sends a FACILITY message including a Facility information element with a UserUserService return error component indicating "rejectedByNetwork" and remains in the same state.

Selection: Does the IUT support the request of service 3 by the called user. PICS: SC 7.1.

UUS_N20_010 **subclause 9.3.1.2.2** **invalid** **optional**

Ensure that the IUT, in the call state N07, having received a valid FACILITY message including a Facility information element with a UserUserService invoke component indicating service 3, preferred,

sends a FACILITY message including a Facility information element with a UserUserService return error component indicating "rejectedByNetwork" and remains in the same state.

Selection: Does the IUT support the request of service 3 by the called user. PICS: SC 7.1.

UUS_N20_011 **subclause 9.3.1.2.2** **invalid** **optional**
 Ensure that the IUT, in the call state N08, having received a valid FACILITY message including a Facility information element with a UserUserService invoke component indicating service 3, preferred,
 sends a FACILITY message including a Facility information element with a UserUserService return error component indicating "rejectedByNetwork" and remains in the same state.
Selection: Does the IUT support the request of service 3 by the called user. PICS: SC 7.1.

UUS_N20_012 **subclause 9.3.1.2.2** **invalid** **optional**
 Ensure that the IUT, in the call state N12, having received a valid FACILITY message including a Facility information element with a UserUserService invoke component indicating service 3, preferred,
 sends a FACILITY message including a Facility information element with a UserUserService return error component indicating "rejectedByNetwork" and remains in the same state.
Selection: Does the IUT support the request of service 3 by the called user. PICS: SC 7.1.

UUS_N20_013 **subclause 9.3.1.2.2** **invalid** **optional**
 Ensure that the IUT, in the call state N19, having received a valid FACILITY message including a Facility information element with a UserUserService invoke component indicating service 3, preferred,
 sends a FACILITY message including a Facility information element with a UserUserService return error component indicating "rejectedByNetwork" and remains in the same state.
Selection: Does the IUT support the request of service 3 by the called user. PICS: SC 7.1.

6.2.2.3.2 **Invocation**

UUS_N21_001 **subclause 9.3.2.1** **valid** **mandatory**
 Ensure that the IUT, in the call state N10 and in the service 3 active state, receiving a USER INFORMATION message including a User-user information element and no More data information element,
 accepts the message (resulting in the sending of a USER INFORMATION message to the served user with a User-user information element and no More data information element), sends no message and remains in the same state.

UUS_N21_002 **subclause 9.3.2.1** **valid** **mandatory**
 Ensure that the IUT, in the call state N10 and in the service 3 active state, receiving a USER INFORMATION message including a User-user information element and a More data information element,
 accepts the message (resulting in the sending of a USER INFORMATION message to the served user with a User-user information element and a More data information element), sends no message and remains in the same state.

UUS_N21_003 **subclause 9.3.2.2** **invalid** **mandatory**
 Ensure that the IUT, in the call state N10, with service 3 not activated, receiving a USER INFORMATION message including a User-user information element,
 discards the message, optionally sends a STATUS message with cause value #43 "access information discarded" and remains in the same state.

UUS_N21_004 **subclause 9.3.2.2** **invalid** **mandatory**
 Ensure that the IUT, in the call state N10 and in the service 3 active state, receiving a USER INFORMATION message including a User-user information element with an overall length exceeding 131 octets,
 discards the message, optionally sends a STATUS message with cause value #43 "access information discarded" and remains in the same state.

UUS_N21_005 **subclause 9.3.2.2** **invalid** **mandatory**
 Ensure that the IUT, in the call state N06 and in the service 3 active state, receiving a USER INFORMATION message including a User-user information element,
 discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;
 or
 discards the message, sends a STATUS ENQUIRY message and remains in the same state.

UUS_N21_006 **subclause 9.3.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N25 and in the service 3 active state, receiving a USER INFORMATION message including a User-user information element,
discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;
or
discards the message, sends a STATUS ENQUIRY message and remains in the same state.

UUS_N21_007 **subclause 9.3.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N09 and in the service 3 active state, receiving a USER INFORMATION message including a User-user information element,
discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;
or
discards the message, sends a STATUS ENQUIRY message and remains in the same state.

UUS_N21_008 **subclause 9.3.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N07 and in the service 3 active state, receiving a USER INFORMATION message including a User-user information element,
discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;
or
discards the message, sends a STATUS ENQUIRY message and remains in the same state.

UUS_N21_009 **subclause 9.3.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N08 and in the service 3 active state, receiving a USER INFORMATION message including a User-user information element,
discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;
or
discards the message, sends a STATUS ENQUIRY message and remains in the same state.

UUS_N21_010 **subclause 9.3.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N12 and in the service 3 active state, receiving a USER INFORMATION message including a User-user information element,
discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;
or
discards the message, sends a STATUS ENQUIRY message and remains in the same state.

UUS_N21_011 **subclause 9.3.2.2** **invalid** **mandatory**

Ensure that the IUT, in the call state N19 and in the service 3 active state, receiving a USER INFORMATION message including a User-user information element,
discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;
or
discards the message, sends a STATUS ENQUIRY message and remains in the same state.

6.2.2.3.3 Flow control

Selection: Coincident S and T reference point procedures supported. PICS: R 3.1.

UUS_N22_001 **subclause 9.3.3.1** **valid** **mandatory**
Ensure that the IUT, in the call state N10 and in the service 3 active state, within the period T2-UUS3 (10 s), receiving N (16) USER INFORMATION messages,
sends no message and remains in the same state.

UUS_N22_002 **subclause 9.3.3.1** **valid** **mandatory**
Ensure that the IUT, in the call state N10 and in the service 3 active state, within the period T2-UUS3 (10 s), having already received N (16) USER INFORMATION messages, receiving a USER INFORMATION message,
discards the last received USER INFORMATION message, sends a CONGESTION CONTROL message including a Congestion level information element indicating "receiver not ready" and a Cause information element with the cause value #43 "access information discarded" and remains in the same state.

UUS_N22_003 **subclause 9.3.3.1** **valid** **mandatory**
Ensure that the IUT, in the call state N10 and in the service 3 active state, within the period T2-UUS3 (10 s), having sent a CONGESTION CONTROL message including a Congestion level information element indicating "receiver not ready", receiving a USER INFORMATION message,
sends no message and remains in the same state.

UUS_N22_004 **subclause 9.3.3.1** **valid** **mandatory**
Ensure that the IUT, in the call state N10 and in the service 3 active state, on expiry of T2-UUS3 (10 s), having sent a CONGESTION CONTROL message including a Congestion level information element indicating "receiver not ready",
sends a CONGESTION CONTROL message including a Congestion level information element indicating "receiver ready" and remains in the same state.

UUS_N22_005 **subclause 9.3.3.2** **inopportune** **mandatory**
Ensure that the IUT, in the call state N10 and in the service 3 active state, receiving a CONGESTION CONTROL message,
sends a STATUS message including a Cause information element with the cause value #111 "protocol error, unspecified" and remains in the same state.

UUS_N22_006 **subclause 9.3.3.2** **inopportune** **mandatory**
Ensure that the IUT, in the call state N06 and in the service 3 active state, receiving a CONGESTION CONTROL message,
discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;
or
discards the message, sends a STATUS ENQUIRY message and remains in the same state.

UUS_N22_007 **subclause 9.3.3.2** **inopportune** **mandatory**
Ensure that the IUT, in the call state N25 and in the service 3 active state, receiving a CONGESTION CONTROL message,
discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;
or
discards the message, sends a STATUS ENQUIRY message and remains in the same state.

UUS_N22_008 **subclause 9.3.3.2** **inopportune** **mandatory**
Ensure that the IUT, in the call state N09 and in the service 3 active state, receiving a CONGESTION CONTROL message,
discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;
or
discards the message, sends a STATUS ENQUIRY message and remains in the same state.

UUS_N22_009 **subclause 9.3.3.2** **inopportune** **mandatory**
Ensure that the IUT, in the call state N07 and in the service 3 active state, receiving a CONGESTION CONTROL message,
discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;
or
discards the message, sends a STATUS ENQUIRY message and remains in the same state.

UUS_N22_010 **subclause 9.3.3.2** **inopportune** **mandatory**
Ensure that the IUT, in the call state N08 and in the service 3 active state, receiving a CONGESTION CONTROL message,
discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;
or
discards the message, sends a STATUS ENQUIRY message and remains in the same state.

UUS_N22_011 **subclause 9.3.3.2** **inopportune** **mandatory**
Ensure that the IUT, in the call state N12 and in the service 3 active state, receiving a CONGESTION CONTROL message,
discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;
or
discards the message, sends a STATUS ENQUIRY message and remains in the same state.

UUS_N22_012 **subclause 9.3.3.2** **inopportune** **mandatory**
Ensure that the IUT, in the call state N19 and in the service 3 active state, receiving a CONGESTION CONTROL message,
discards the message, sends a STATUS message with cause value #98 "message not compatible with call state or message type non-existent or not implemented" or with cause value #101 "message not compatible with call state" and remains in the same state;
or
discards the message, sends a STATUS ENQUIRY message and remains in the same state.

7 Compliance

An ATS which complies with this TSS&TP specification shall:

- a) consist of a set of test cases corresponding to the set or to a subset of the TPs specified in clause 6;
- b) use a TSS which is an appropriate subset of the whole of the TSS specified in clause 5;
- c) use the same naming conventions for the test groups and test cases;
- d) maintain the relationship specified in clause 6 between the test groups and TPs and the entries in the PICS proforma to be used for test case deselection;
- e) comply with ISO/IEC 9646-2 [4].

In the case of a) or b) above, a subset shall be used only where a particular Abstract Test Method (ATM) makes some TPs untestable. All testable TPs from clause 6 shall be included in a compliant ATS.

8 Requirements for a comprehensive testing service

As a minimum the Multi-party test method, as specified in ISO/IEC 9646-2 [4], shall be used by any organization claiming to provide a comprehensive testing service for network equipment claiming conformance to ETS 300 286-1 [1].

History

Document history			
July 1996	Public Enquiry	PE 109:	1996-07-08 to 1996-11-01
March 1997	Vote	V 9720:	1997-03-18 to 1997-05-16