

# ETSI TS 134 123-1 V3.1.0 (2000-09)

---

*Technical Specification*

**Universal Mobile Telecommunications System (UMTS);  
User Equipment (UE) conformance specification;  
Part 1: Protocol conformance specification  
(3GPP TS 34.123-1 version 3.1.0 Release 1999)**

---



---

**Reference**

RTS/TSGT-0134123-aUR

---

**Keywords**

UMTS

**ETSI**

650 Route des Lucioles  
F-06921 Sophia Antipolis Cedex - FRANCE

---

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C  
Association à but non lucratif enregistrée à la  
Sous-Préfecture de Grasse (06) N° 7803/88

---

**Important notice**

Individual copies of the present document can be downloaded from:

<http://www.etsi.org>

The present document may be made available in more than one electronic version or in print. In any case of existing or perceived difference in contents between such versions, the reference version is the Portable Document Format (PDF). In case of dispute, the reference shall be the printing on ETSI printers of the PDF version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status. Information on the current status of this and other ETSI documents is available at <http://www.etsi.org/tb/status/>

If you find errors in the present document, send your comment to:  
editor@etsi.fr

---

**Copyright Notification**

No part may be reproduced except as authorized by written permission.  
The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2000.

All rights reserved.

---

## Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: *"Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards"*, which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<http://www.etsi.org/ipr>).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

---

## Foreword

This Technical Specification (TS) has been produced by the ETSI 3<sup>rd</sup> Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under [www.etsi.org/key](http://www.etsi.org/key).

# Contents

Foreword .....	20
Introduction .....	20
1 Scope .....	21
2 References .....	21
3 Definitions and abbreviations.....	22
3.1 Definitions .....	22
3.2 Abbreviations .....	22
4 Overview .....	22
4.1 Test Methodology .....	22
4.1.1 Testing of optional functions and procedures .....	22
4.1.2 Test interfaces and facilities .....	22
4.2 Implicit Testing .....	22
5 Reference Conditions .....	22
5.1 Generic setup procedures .....	23
6 Idle mode operations .....	24
6.1 In a pure 3GPP environment .....	26
6.1.1 PLMN selection and reselection .....	26
6.1.1.1 Manual mode PLMN selection / re-selection and UE indication of available PLMNs.....	26
6.1.1.2 Manual mode PLMN selection / reselection; independence of RF level and preferred PLMN .....	29
6.1.1.3 Automatic mode PLMN selection.....	31
6.1.1.4 UE will transmit only if PLMN available .....	34
6.1.1.4.3 Test purpose .....	34
6.1.1.4.4 Method of test.....	34
6.1.2 Radio access mode selection and reselection.....	35
6.1.2.1 UE selects radio access mode (FDD/TDD) on request by the servicing network.....	35
6.1.3 Cell selection and reselection .....	35
6.1.3.1 Cell selection.....	35
6.1.3.2 Cell selection on release of DCCH and DTCH.....	37
6.1.3.3 Cell reselection.....	37
6.1.3.4 Cell reselection using reselection timing parameters .....	39
6.1.3.5 Cell reselection if HCS is used.....	41
6.1.3.6 Cell reselection due to UE rejection "LA not allowed" .....	41
6.1.3.7 Cell reselection due to UE rejection "Roaming not allowed in this LA" .....	44
6.1.3.8 Emergency calls .....	46
6.1.3.8.2 Conformance requirement .....	47
6.1.3.9 Immediate cell evaluation .....	48
6.1.3.10 Reading SIB prior to RACH transmission .....	50
6.1.4 Location registration .....	51
6.2 Multi-mode environment (2G/3G case) .....	51
6.2.1 PLMN selection and reselection .....	51
6.2.2 Cell selection and reselection .....	51
6.2.2.1 Cell selection; UTRAN / GSM .....	51
6.2.2.2 Cell reselection; UTRAN to GSM .....	53
6.2.2.3 Cell reselection timings; GSM to UTRAN .....	55
6.2.3 Location registration .....	58
7 Layer 2 .....	59
7.1 MAC.....	59
7.1.1 Permission to access the network .....	59
7.1.2 RACH/FACH procedures .....	60
7.1.2.1 Selection and control of Power Level .....	60
7.1.2.2 Correct application of Dynamic Persistence .....	61

7.1.2.3	Correct Selection of RACH parameters .....	62
7.1.3	Dynamic Radio Bearer Control .....	63
7.1.4	RACH/FACH transmission and retransmission .....	64
7.1.5	MAC Access Control Function.....	64
7.1.6	Inband identification of UE on FACH.....	64
7.1.7	Inband identification of UE on DSCH.....	64
7.1.8	Mapping between logical channels and transport channels .....	65
7.1.8.1	DCCH mapped to RACH/FACH .....	65
7.1.8.2	DTCH or DCCH mapped to DSCH or USCH .....	66
7.1.8.3	DTCH or DCCH mapped to CPCH .....	69
7.1.8.4	DTCH or DCCH mapped to DCH .....	72
7.1.8.5	CCCH mapped to RACH/FACH .....	75
7.1.8.6	DTCH mapped to RACH/FACH .....	76
7.1.8.6.3	Test purpose .....	76
7.1.9	Selection of appropriate Transport format for each Transport Channel depending on instantaneous source rate.....	77
7.1.9.1	Selection of Transport Format depending on instantaneous source rate .....	77
7.1.10	Priority handling between data flows of one UE .....	80
7.1.10.1	Priority handling between data flows of one UE .....	80
7.1.11	Ciphering for transparent RLC .....	82
7.1.11.1	Ciphering.....	82
7.1.12	Control of RACH transmissions. ....	83
7.1.12.1	Access Service class selection for RACH transmission.....	83
7.1.12.2	Control of RACH transmissions for FDD mode .....	85
7.1.13	Control of CPCH transmissions.....	86
7.1.13.1	Control of CPCH transmissions for FDD .....	86
7.2	RLC testing .....	89
7.2.1	Transparent mode .....	89
7.2.1.1	Segmentation and reassembly .....	89
7.2.2	Unacknowledged mode .....	89
7.2.2.1	General information for UM tests .....	89
7.2.2.2	Segmentation and reassembly / Selection of 7 or 15 bit Length Indicators .....	91
7.2.2.3	Segmentation / 7-bit Length Indicators / Padding.....	93
7.2.2.4	Segmentation / 7-bit Length Indicators / LI = 0 .....	94
7.2.2.5	Segmentation / 7-bit Length Indicators / Invalid LI value .....	95
7.2.2.6	Segmentation / 7-bit Length Indicators / LI value > PDU size .....	97
7.2.2.7	Segmentation / 15-bit Length Indicators / Padding .....	98
7.2.2.8	Segmentation / 15-bit Length Indicators / LI = 0 .....	99
7.2.2.9	Segmentation / 15-bit Length Indicators / One octet short LI .....	100
7.2.2.10	Segmentation / 15-bit Length Indicators / LI value > PDU size .....	102
7.2.3	Acknowledged mode .....	103
7.2.3.1	General information for AM tests .....	103
7.2.3.2	Segmentation and reassembly / Selection of 7 or 15 bit Length Indicators .....	105
7.2.3.3	Segmentation / 7-bit Length Indicators / Padding or Piggy-backed Status .....	108
7.2.3.4	Segmentation / 7-bit Length Indicators / LI = 0 .....	109
7.2.3.5	Segmentation / 7-bit Length Indicators / Reserved LI value.....	110
7.2.3.6	Segmentation / 7-bit Length Indicators / LI value > PDU size .....	111
7.2.3.7	Segmentation / 15-bit Length Indicators / Padding or Piggy-backed Status .....	112
7.2.3.8	Segmentation / 15-bit Length Indicators / LI = 0 .....	114
7.2.3.9	Segmentation / 15-bit Length Indicators / One octet short LI .....	115
7.2.3.10	Segmentation / 15-bit Length Indicators / Reserved LI value.....	116
7.2.3.11	Segmentation / 15-bit Length Indicators / LI value > PDU size .....	117
7.2.3.12	Correct use of Sequence Numbering.....	118
7.2.3.13	Control of Transmit Window .....	120
7.2.3.14	Control of Receive Window.....	123
7.2.3.15	Polling for status / Last PU in transmission queue.....	124
7.2.3.16	Polling for status / Last PU in retransmission queue.....	126
7.2.3.17	Polling for status / Poll every Poll_PU PUs.....	127
7.2.3.18	Polling for status / Poll every Poll_SDU SDUs .....	129
7.2.3.19	Polling for status / Timer triggered polling (Timer_Poll_Periodic) .....	131

7.2.3.20	Polling for status / Polling on Poll_Window% of transmission window .....	133
7.2.3.21	Polling for status / Operation of Timer_Poll timer / Timer expiry .....	134
7.2.3.22	Polling for status / Operation of Timer_Poll timer / Stopping Timer_Poll timer .....	136
7.2.3.23	Polling for status / Operation of Timer_Poll timer / Restart of the Timer_Poll timer .....	138
7.2.3.24	Polling for status / Operation of timer Timer_Poll_Prohibit .....	139
7.2.3.25	Receiver Status Triggers / Detection of missing PUs .....	141
7.2.3.26	Receiver Status Triggers / Operation of timer Timer_Status_Periodic .....	142
7.2.3.27	Receiver Status Triggers / Operation of timer Timer_Status_Prohibit .....	144
7.2.3.28	Timer based discard, with explicit signalling / Expiry of Timer_Discard .....	146
7.2.3.29	Timer based discard, with explicit signalling / Failure of MRW procedure .....	148
7.2.3.30	SDU discard after MaxDAT number of retransmissions .....	150
7.2.3.31	Operation of the RLC Reset procedure / UE Originated .....	152
7.2.3.32	Operation of the RLC Reset procedure / UE Terminated .....	154
7.3	PDCP .....	156
7.3.1	General .....	156
7.3.1.1	General assumptions .....	156
7.3.1.2	Common Test sequences and Default message contents for PDCP .....	156
7.3.1.2.1	Common Test sequences for PDCP .....	157
7.3.1.2.2	Default PDCP Message Contents .....	159
7.3.2	IP Header Compression and PID assignment .....	161
7.3.2.1	UE in RLC AM .....	161
7.3.2.1.1	Transmission of uncompressed Header .....	161
7.3.2.1.2	Transmission of compressed Header .....	168
7.3.2.2	UE in RLC UM .....	176
7.3.2.2.1	Transmission of uncompressed Header .....	176
7.3.2.2.2	Transmission of compressed Header .....	184
7.3.2.2.3	Extension of used compression methods .....	192
7.3.2.2.4	Compression type used for different entities .....	198
7.3.2.2.5	Reception of not defined PID values .....	204
7.3.3	PDCP sequence numbering when lossless SRNS Relocation .....	208
7.3.3.1	Data transmission if lossless SRNS Relocation is supported .....	208
7.3.3.2	Synchronisation of PDCP sequence numbers .....	212
7.4	BMC .....	217
7.4.1	General BMC message reception .....	218
7.4.1.1	UE in RRC Idle mode .....	218
7.4.1.2	UE in RRC Connected mode, state CELL_PCH .....	220
7.4.1.3	UE in RRC Connected mode, state URA_PCH .....	222
7.4.2	BMC message reception procedure .....	225
7.4.2.1	Reception of certain CBS message types .....	225
8.	Radio Resource Control RRC .....	230
8.1	RRC Connection Management Procedure .....	230
8.1.1	Paging .....	230
8.1.1.1	Paging for Connection in idle mode .....	230
8.1.1.2	Paging for Connection in connected mode (CELL_PCH) .....	232
8.1.1.3	Paging for Connection in connected mode (URA_PCH) .....	234
8.1.1.4	Paging for Notification in idle mode .....	235
8.1.1.5	Paging for Notification in connected mode (CELL_PCH) .....	240
8.1.1.6	Paging for Notification in connected mode (URA_PCH) .....	243
8.1.1.7	Paging for Connection in connected mode (CELL_DCH) .....	244
8.1.1.8	Paging for Connection in connected mode (CELL_FACH) .....	246
8.1.2	RRC Connection Establishment .....	247
8.1.2.1	RRC Connection Establishment in CELL_DCH state: Success .....	247
8.1.2.2	RRC Connection Establishment: Success after T300 timeout .....	249
8.1.2.3	RRC Connection Establishment: Failure (V300 is greater than N300) .....	250
8.1.2.4	RRC Connection Establishment: Reject ("wait time" is not equal to 0) .....	252
8.1.2.5	RRC Connection Establishment: Reject ("wait time" is not equal to 0 and V300 is greater than N300) .....	254
8.1.2.6	RRC Connection Establishment: Reject ("wait time" is set to 0) .....	255
8.1.2.7	RRC Connection Establishment in CELL_FACH state: Success .....	257
8.1.2.8	RRC Connection Establishment : Invalid system information message reception .....	259

8.1.3	RRC Connection Release.....	260
8.1.3.1	RRC Connection Release in CELL_DCH state: Success.....	260
8.1.3.2	RRC Connection Release in CELL_FACH state: Success .....	262
8.1.3.3	RRC Connection Release in CELL_FACHstate: Failure.....	264
8.1.4	RRC Connection Re-Establishment.....	265
8.1.4.1	RRC Connection Re-Establishment: Success .....	265
8.1.4.2	RRC Connection Re-Establishment: Success after T301 timeout ( T314 and T315 are running) .....	266
8.1.4.3	RRC Connection Re-Establishment: Success after reception of invalid message(V301 is not greater than N301) .....	268
8.1.4.4	RRC Connection Re-Establishment: Failure after reception of invalid message (V301 is greater than N301) .....	270
8.1.4.5	RRC Connection Re-Establishment: Failure (Release).....	272
8.1.4.6	RRC Connection Re-Establishment: Failure(T315=0,T314=0).....	275
8.1.4.7	RRC Connection Re-Establishment: Success(T314=0, T315>0 and radio link failure) .....	277
8.1.4.8	RRC Connection Re-Establishment: Success(T314>0, T315=0 and radio link failure) .....	280
8.1.4.9	RRC Connection Re-Establishment: Failure (T314 is timeout and T315=0) .....	282
8.1.4.10	RRC Connection Re-Establishment: Failure (T315 is timeout and T314=0) .....	284
8.1.4.11	RRC Connection Re-Establishment: Success( Unrecoverble error in RLC ).....	287
8.1.5	UE capability .....	290
8.1.5.1	UE Capability: Success .....	290
8.1.5.2	UE Capability: Success after T304 timeout .....	292
8.1.5.3	UE Capability: Failure (After N304 re-transmissions) .....	293
8.1.6	Direct Transfer.....	295
8.1.6.1	Direct Transfer in CELL DCH state(invalid message reception).....	295
8.1.6.2	Direct Transfer in CELL FACH state(invalid message reception) .....	296
8.1.7	Security mode control.....	297
8.1.8	Counter check .....	300
8.1.9	Signalling Connection Release Request .....	302
8.2	Radio Bearer control procedure .....	303
8.2.1	Radio Bearer Establishment.....	303
8.2.1.1	Radio Bearer Establishment for transition from CELL_DCH to CELL_DCH: Success(Data integrity protection algorithm is not applied).....	303
8.2.1.2	Radio Bearer Establishment for transition from CELL_DCH to CELL_DCH: Success(Effectuated Data integrity protection algorithm).....	304
8.2.1.3	Radio Bearer Establishment for transition from CELL_DCH to CELL_DCH: Failure (Unsupported or Unacceptable configuration) .....	306
8.2.1.4	Radio Bearer Establishment for transition from CELL_DCH to CELL_DCH: Failure (Physical channel Failure and successful reversion to old configuration) .....	307
8.2.1.5	Radio Bearer Establishment for transition from CELL_DCH to CELL_DCH: Failure (Physical channel Failure and reversion failure).....	308
8.2.1.6	Radio Bearer Establishment for transition from CELL_DCH to CELL_DCH: Failure (Incompatible simultaneous reconfiguration) .....	310
8.2.1.7	Radio Bearer Establishment for transition from CELL_DCH to CELL_DCH: Failure (Invalid message reception).....	311
8.2.1.8	Radio Bearer Establishment for transition from CELL_DCH to CELL_FACH: Success .....	312
8.2.1.9	Radio Bearer Establishment for transition from CELL_DCH to CELL_FACH: Failure (Unsupported or Unacceptable configuration) .....	313
8.2.1.10	Radio Bearer Establishment for transition from CELL_DCH to CELL_FACH: Failure (Physical channel Failure).....	314
8.2.1.11	Radio Bearer Establishment for transition from CELL_DCH to CELL_FACH: Failure (Incompatible simultaneous reconfiguration) .....	315
8.2.1.12	Radio Bearer Establishment for transition from CELL_DCH to CELL_FACH: Failure (Invalid message reception).....	317
8.2.1.13	Radio Bearer Establishment for transition from CELL_FACH to CELL_DCH: Success .....	318
8.2.1.14	Radio Bearer Establishment for transition from CELL_FACH to CELL_DCH: Failure (Unsupported or Unacceptable configuration) .....	319
8.2.1.15	Radio Bearer Establishment for transition from CELL_FACH to CELL_DCH: Failure (Physical channel Failure and successful reversion to old configuration) .....	320
8.2.1.16	Radio Bearer Establishment for transition from CELL_FACH to CELL_DCH: Failure (Physical channel Failure and reversion failure).....	321

8.2.1.17	Radio Bearer Establishment for transition from CELL_FACH to CELL_DCH: Failure (Incompatible simultaneous reconfiguration) .....	323
8.2.1.18	Radio Bearer Establishment for transition from CELL_FACH to CELL_DCH: Failure (Invalid message reception) .....	324
8.2.1.19	Radio Bearer Establishment for transition from CELL_FACH to CELL_FACH: Success .....	325
8.2.1.20	Radio Bearer Establishment for transition from CELL_FACH to CELL_FACH: Failure (Unsupported or Unacceptable configuration) .....	326
8.2.1.21	Radio Bearer Establishment for transition from CELL_FACH to CELL_FACH: Failure (Incompatible simultaneous reconfiguration) .....	327
8.2.1.22	Radio Bearer Establishment for transition from CELL_FACH to CELL_FACH: Failure (Invalid message reception) .....	328
8.2.2	Radio Bearer Reconfiguration .....	330
8.2.2.1	Radio Bearer Reconfiguration ( Hard handover ) from CELL_DCH to CELL_DCH: Success .....	330
8.2.2.2	Radio Bearer Reconfiguration from CELL_DCH to CELL_DCH: Failure (Unsupported or Unacceptable configuration) .....	331
8.2.2.3	Radio Bearer Reconfiguration from CELL_DCH to CELL_DCH: Failure (Physical channel failure and reversion to old configuration) .....	332
8.2.2.4	Radio Bearer Reconfiguration from CELL_DCH to CELL_DCH : Failure (Physical channel failure and reversion failure) .....	334
8.2.2.5	Radio Bearer Reconfiguration from CELL_DCH to CELL_DCH: Failure (Incompatible simultaneous reconfiguration) .....	335
8.2.2.6	Radio Bearer Reconfiguration from CELL_DCH to CELL_DCH: Failure (Invalid message reception) .....	336
8.2.2.7	Radio Bearer Reconfiguration from CELL_DCH to CELL_DCH :Failure (Suspension of signalling bearer) .....	338
8.2.2.8	Radio Bearer Reconfiguration from CELL_DCH to CELL_FACH: Success .....	339
8.2.2.9	Radio Bearer Reconfiguration from CELL_DCH to CELL_FACH: Failure (Unsupported or Unacceptable configuration) .....	340
8.2.2.10	Radio Bearer Reconfiguration from CELL_DCH to CELL_FACH: Failure (Physical channel failure ) .....	341
8.2.2.11	Radio Bearer Reconfigure from CELL_DCH to CELL_FACH: Failure (Incompatible simultaneous reconfiguration) .....	343
8.2.2.12	Radio Bearer Reconfiguration from CELL_DCH to CELL_FACH: Failure (Invalid message reception) .....	344
8.2.2.13	Radio Bearer Reconfiguration from CELL_DCH to CELL_FACH: Failure (Suspension of signalling bearer) .....	345
8.2.2.14	Radio Bearer Reconfiguration: from CELL_FACH to CELL_DCH: Success .....	346
8.2.2.15	Radio Bearer Reconfiguration from CELL_FACH to CELL_DCH: Failure (Unsupported or Unacceptable configuration) .....	347
8.2.2.16	Radio Bearer Reconfiguration from CELL_FACH to CELL_DCH: Failure (Physical channel failure and reversion to old configuration) .....	348
8.2.2.17	Radio Bearer Reconfiguration from CELL_FACH to CELL_DCH: Failure (Physical channel failure and reversion failure) .....	350
8.2.2.18	Radio Bearer Reconfigure from CELL_FACH to CELL_DCH: Failure (Incompatible simultaneous reconfiguration) .....	351
8.2.2.19	Radio Bearer Reconfiguration from CELL_FACH to CELL_DCH: Failure (Invalid message reception) .....	352
8.2.2.20	Radio Bearer Reconfiguration from CELL_FACH to CELL_DCH: Failure (Suspension of signalling bearer) .....	354
8.2.2.21	Radio Bearer Reconfiguration from CELL_FACH to CELL_FACH:Success .....	355
8.2.2.22	Radio Bearer Reconfiguration from CELL_FACH to CELL_FACH: Failure (Unsupported or Unacceptable configuration) .....	356
8.2.2.23	Radio Bearer Reconfiguration from CELL_FACH to CELL_FACH: Failure (Physical channel failure) .....	357
8.2.2.24	Radio Bearer Reconfiguration from CELL_FACH to CELL_FACH: Failure (Incompatible simultaneous reconfiguration) .....	358
8.2.2.25	Radio Bearer Reconfiguration from CELL_FACH to CELL_FACH: Failure (Invalid message reception) .....	360
8.2.2.26	Radio Bearer Reconfiguration from CELL_FACH to CELL_FACH :Failure (Suspension of signalling bearer) .....	361



8.2.3	Radio Bearer Release.....	362
8.2.3.1	Radio Bearer Release for transition from CELL_DCH to CELL_DCH: Success .....	362
8.2.3.2	Radio Bearer Release for transition from CELL_DCH to CELL_DCH: Failure (Unsupported or Unacceptable configuration) .....	363
8.2.3.3	Radio Bearer Release for transition from CELL_DCH to CELL_DCH: Failure (Physical channel failure and reversion to old configuration) .....	364
8.2.3.4	Radio Bearer Release for transition from CELL_DCH to CELL_DCH: Failure (Physical channel failure and reversion failure) .....	365
8.2.3.5	Radio Bearer Release for transition from CELL_DCH to CELL_DCH: Failure (Incompatible simultaneous reconfiguration) .....	367
8.2.3.6	Radio Bearer Release for transition from CELL_DCH to CELL_DCH: Failure (Invalid message reception) .....	368
8.2.3.7	Radio Bearer Release for transition from CELL_DCH to CELL_FACH: Success .....	369
8.2.3.8	Radio Bearer Release for transition from CELL_DCH to CELL_FACH: Failure (Unsupported or Unacceptable configuration) .....	370
8.2.3.9	Radio Bearer Release for transition from CELL_DCH to CELL_FACH: Failure (Physical channel failure) .....	372
8.2.3.10	Radio Bearer Release for transition from CELL_DCH to CELL_FACH: Failure (Incompatible simultaneous reconfiguration) .....	373
8.2.3.11	Radio Bearer Release for transition from CELL_DCH to CELL_FACH: Failure (Invalid message reception) .....	374
8.2.3.12	Radio Bearer Release for transition from CELL_FACH to CELL_DCH: Success .....	375
8.2.3.13	Radio Bearer Release for transition from CELL_FACH to CELL_DCH: Failure (Unsupported or Unacceptable configuration) .....	376
8.2.3.14	Radio Bearer Release for transition from CELL_FACH to CELL_DCH: Failure (Physical channel failure and reversion to old configuration) .....	378
8.2.3.15	Radio Bearer Release for transition from CELL_FACH to CELL_DCH: Failure (Physical channel failure and reversion failure) .....	379
8.2.3.16	Radio Bearer Release for transition from CELL_FACH to CELL_DCH: Failure (Incompatible simultaneous reconfiguration) .....	380
8.2.3.17	Radio Bearer Release for transition from CELL_FACH to CELL_DCH: Failure (Invalid message reception) .....	381
8.2.3.18	Radio Bearer Release for transition from CELL_FACH to CELL_FACH: Success .....	383
8.2.3.19	Radio Bearer Release for transition from CELL_FACH to CELL_FACH: Failure (Unsupported or Unacceptable configuration) .....	384
8.2.3.20	Radio Bearer Release for transition from CELL_FACH to CELL_FACH: Failure (Incompatible simultaneous reconfiguration) .....	385
8.2.3.21	Radio Bearer Release for transition from CELL_FACH to CELL_FACH: Failure (Invalid message reception) .....	386
8.2.4	Transport channel reconfiguration .....	387
8.2.4.1	Transport channel reconfiguration from CELL_DCH to CELL_DCH (Hard handover to same radio frequency): Success with no transport channel type switching .....	387
8.2.4.2	Transport channel reconfiguration from CELL_DCH to CELL_DCH: Failure (Unsupported or Unacceptable configuration) .....	389
8.2.4.3	Transport channel reconfiguration from CELL_DCH to CELL_DCH: Failure (Physical channel failure and reversion to old configuration) .....	390
8.2.4.4	Transport channel reconfiguration from CELL_DCH to CELL_DCH: Failure (Physical channel failure and reversion failure) .....	391
8.2.4.5	Transport Channel Reconfiguration from CELL_DCH to CELL_DCH: Failure (Incompatible simultaneous reconfiguration) .....	393
8.2.4.6	Transport channel reconfiguration from CELL_DCH to CELL_DCH: Failure (Invalid message reception) .....	394
8.2.4.7	Transport channel reconfiguration from CELL_DCH to CELL_FACH: Success .....	395
8.2.4.8	Transport channel reconfiguration from CELL_DCH to CELL_FACH: Failure (Unsupported or Unacceptable configuration) .....	396
8.2.4.9	Transport channel reconfiguration from CELL_DCH to CELL_FACH: Failure (Physical channel failure and reversion to old configuration) .....	397
8.2.4.10	Transport channel reconfiguration from CELL_DCH to CELL_FACH: Failure (Physical channel failure and reversion failure) .....	399

8.2.4.11	Transport Channel Reconfiguration from CELL_DCH to CELL_FACH: Failure (Incompatible simultaneous reconfiguration).....	400
8.2.4.12	Transport channel reconfiguration from CELL_DCH to CELL_FACH: Failure (Invalid message reception) .....	402
8.2.4.13	Transport channel reconfiguration from CELL_FACH to CELL_DCH : Success .....	403
8.2.4.14	Transport channel reconfiguration from CELL_FACH to CELL_DCH: Failure (Unsupported or Unacceptable configuration) .....	404
8.2.4.15	Transport channel reconfiguration from CELL_FACH to CELL_DCH: Failure (Physical channel failure and reversion to old channel).....	405
8.2.4.16	Transport channel reconfiguration from CELL_FACH to CELL_DCH: Failure (Physical channel failure and reversion failure).....	406
8.2.4.17	Transport Channel Reconfiguration from CELL_FACH to CELL_DCH: Failure (Incompatible simultaneous reconfiguration).....	408
8.2.4.18	Transport channel reconfiguration from CELL_FACH to CELL_DCH: Failure (Invalid message reception) .....	409
8.2.4.19	Transport channel reconfiguration from CELL_FACH to CELL_FACH: Success with no transport channel type switching.....	410
8.2.4.20	Transport channel reconfiguration from CELL_FACH to CELL_FACH: Failure (Unsupported or Unacceptable configuration) .....	411
8.2.4.21	Transport channel reconfiguration from CELL_FACH to CELL_FACH: Failure (Physical channel failure) .....	412
8.2.4.22	Transport Channel Reconfiguration from CELL_FACH to CELL_FACH: Failure (Incompatible simultaneous reconfiguration).....	414
8.2.4.23	Transport channel reconfiguration from CELL_FACH to CELL_FACH: Failure (Invalid message reception).....	415
8.2.5	Transport format combination control.....	416
8.2.5.1	Transport format combination control in CELL_DCH : restriction.....	416
8.2.5.2	Transport format combination control in CELL_DCH: release a restriction .....	417
8.2.5.3	Transport format combination control in CELL_DCH: Failure (Incompatible simultaneous reconfiguration).....	418
8.2.5.4	Transport format combination control in CELL_DCH: Failure (Invalid message reception).....	421
8.2.6	Physical channel reconfiguration.....	422
8.2.6.1	Physical channel reconfiguration for transition from CELL_DCH to CELL_DCH ( Hard handover to another frequency ): Success .....	422
8.2.6.2	Physical channel reconfiguration for transition from CELL_DCH to CELL_DCH ( Hard handover to another frequency ): Failure (Unsupported or Unacceptable configuration).....	423
8.2.6.3	Physical channel reconfiguration for transition from CELL_DCH to CELL_DCH ( Hard handover to another frequency ): Failure (Physical channel failure and reversion to old channel) ....	425
8.2.6.4	Physical channel reconfiguration for transition from CELL_DCH to CELL_DCH ( Hard handover to another frequency ): Failure (Physical channel failure and reversion failure).....	426
8.2.6.5	Physical channel reconfiguration for transition from CELL_DCH to CELL_DCH ( Hard handover to another frequency): Failure (Incompatible simultaneous reconfiguration) .....	427
8.2.6.6	Physical channel reconfiguration for transition from CELL_DCH to CELL_DCH ( Hard handover to another frequency): Failure (Invalid message reception).....	429
8.2.6.7	Physical channel reconfiguration for transition from CELL_DCH to CELL_FACH: Success .....	430
8.2.6.8	Physical channel reconfiguration for transition from CELL_DCH to CELL_FACH: Failure (Unsupported or Unacceptable configuration) .....	431
8.2.6.9	Physical channel reconfiguration for transition from CELL_DCH to CELL_FACH: Failure (Physical channel failure).....	432
8.2.6.10	Physical channel reconfiguration for transition from CELL_DCH to CELL_FACH: Failure (Incompatible simultaneous reconfiguration) .....	433
8.2.6.11	Physical channel reconfiguration for transition from CELL_DCH to CELL_FACH: Failure (Invalid message reception) .....	435
8.2.6.12	Physical channel reconfiguration for transition from CELL_FACH to CELL_DCH: Success .....	436
8.2.6.13	Physical channel reconfiguration for transition from CELL_FACH to CELL_DCH: Failure (Unsupported or Unacceptable configuration) .....	437
8.2.6.14	Physical channel reconfiguration for transition from CELL_FACH to CELL_DCH: Failure (Physical channel failure and reversion to old configuration).....	438
8.2.6.15	Physical channel reconfiguration for transition from CELL_FACH to CELL_DCH: Failure (Physical channel failure and reversion failure).....	439

8.2.6.16	Physical channel reconfiguration for transition from CELL_FACH to CELL_DCH: Failure (Incompatible simultaneous reconfiguration) .....	441
8.2.6.17	Physical channel reconfiguration for transition from CELL_FACH to CELL_DCH: Failure (Invalid message reception) .....	442
8.2.6.18	Physical channel reconfiguration for transition from CELL_FACH to CELL_FACH: Success .....	443
8.2.6.19	Physical channel reconfiguration for transition from CELL_FACH to CELL_FACH: Failure (Unsupported or Unacceptable configuration) .....	444
8.2.6.20	Physical channel reconfiguration for transition from CELL_FACH to CELL_FACH: Failure (Physical channel failure) .....	445
8.2.6.21	Physical channel reconfiguration for transition from CELL_FACH to CELL_FACH: Failure (Incompatible simultaneous reconfiguration) .....	446
8.2.6.22	Physical channel reconfiguration for transition from CELL_FACH to CELL_FACH: Failure (Invalid message reception) .....	448
8.2.7	Physical Shared Channel Allocation[TDD only] .....	449
8.2.8	PUSCH capacity request[TDD only] .....	449
8.2.9	Downlink outer loop control .....	449
8.2.9.1	Downlink outer loop control: Increase is Disallowed .....	449
8.2.9.2	Downlink outer loop control: Increase is Allowed .....	451
8.2.9.3	Downlink outer loop control: Failure (Invalid message reception) .....	452
8.3	RRC connection mobility procedure .....	454
8.3.1	Cell Update .....	454
8.3.1.1	Cell Update: cell reselection in CELL_FACH .....	454
8.3.1.2	Cell Update: cell reselection in CELL_PCH .....	457
8.3.1.3	Cell Update: periodical cell update in CELL_FACH .....	460
8.3.1.4	Cell Update: periodical cell update in CELL_PCH .....	464
8.3.1.5	Cell Update: UL data transmission in URA_PCH .....	468
8.3.1.6	Cell Update: UL data transmission in CELL_PCH .....	471
8.3.1.7	Cell Update: paging response in URA_PCH .....	475
8.3.1.8	Cell Update: paging response in CELL_PCH .....	480
8.3.1.9	Cell Update: re-entering of service area after T305 expiry and being out of service area .....	485
8.3.1.10	Cell Update: expiry of T307 after T305 expiry and being out of service area .....	488
8.3.1.11	Cell Update: Success after T302 time-out .....	489
8.3.1.12	Cell Update: Failure (After Maximum Re-transmissions) .....	491
8.3.1.13	Cell Update: Reception of Invalid CELL UPDATE CONFIRM Message .....	493
8.3.1.14	Cell Update: Radio Bearer Control for Transition from CELL_DCH to CELL_FACH .....	495
8.3.1.15	Cell Update: Acknowledged Mode RLC Reset .....	501
8.3.2	URA Update .....	504
8.3.2.1	URA Update: URA reselection .....	504
8.3.2.2	URA Update: periodical URA update .....	506
8.3.2.3	URA Update: re-entering of service area after T306 expiry .....	507
8.3.2.4	URA Update: loss of service after expiry of timers T307 and T306 .....	509
8.3.2.5	URA Update: Success after Confirmation error of URA-ID list .....	510
8.3.2.6	URA Update: Failure ( V303 is greater than N303 : Confirmation error of URA-ID list ) .....	512
8.3.2.7	URA Update: Success after T303 timeout .....	513
8.3.2.8	URA Update: Failure ( V303 is greater than N303:T303 timeout ) .....	515
8.3.3	RNTI reallocation .....	517
8.3.3.1	RNTI reallocation: Success .....	517
8.3.3.2	RNTI reallocation: Failure (Invalid message reception) .....	519
8.3.4	Active set update in soft handover .....	521
8.3.4.1	Active set update in soft handover: Radio Link addition .....	521
8.3.4.2	Active set update in soft handover : Radio Link removal .....	523
8.3.4.3	Active set update in soft handover: Combined radio link addition and removal (active set is not full) .....	525
8.3.4.4	Active set update in soft handover: Unsupported Configuration in the UE .....	527
8.3.4.5	Active set update in soft handover: Combined radio link addition and removal (active set is full) .....	529
8.3.4.6	Active set update in soft handover: Subsequent reception of ACTIVE SET UPDATE message / Incompatible simultaneous reconfiguration .....	531
8.3.4.7	Active set update in soft handover: Invalid Message Reception .....	535
8.3.5	Hard Handover .....	537
8.3.6	Inter system hard handover to UTRAN .....	537

8.3.7	Inter system hard handover from UTRAN .....	537
8.3.8	Inter system cell reselection to UTRAN .....	537
8.3.9	Inter system cell reselection from UTRAN .....	537
8.4	Measurement procedure .....	538
8.4.1	Measurement Control and Report .....	538
8.4.1.1	Measurement Control and Report: Intra-frequency measurement for transition from idle mode to CELL_DCH state .....	538
8.4.1.2	Measurement Control and Report: Inter-frequency measurement for transition from idle mode to CELL_DCH state .....	547
8.4.1.3	Measurement Control and Report: Intra-frequency measurement for transition from idle mode to CELL_FACH state .....	550
8.4.1.4	Measurement Control and Report: Inter-frequency measurement for transition from idle mode to CELL_FACH state .....	555
8.4.1.5	Measurement Control and Report: Intra-frequency measurement for transition from CELL_DCH to CELL_FACH state .....	560
8.4.1.6	Measurement Control and Report: Inter-frequency measurement for transition from CELL_DCH to CELL_FACH state .....	568
8.4.1.7	Measurement Control and Report: Intra-frequency measurement for transition from CELL_FACH to CELL_DCH state .....	575
8.4.1.8	Measurement Control and Report: Inter-frequency measurement for transition from CELL_FACH to CELL_DCH state .....	586
8.4.1.9	Measurement Control and Report: Unsupported measurement in the UE .....	595
8.4.1.10	Measurement Control and Report: Failure (Invalid Message Reception) .....	597
9	Elementary procedures of mobility management .....	600
9.1	TMSI reallocation .....	600
9.1.2	Test purpose .....	600
9.1.3	Method of test .....	600
9.2	Authentication .....	603
9.2.1	Authentication accepted .....	603
9.2.2	Authentication rejected by the network .....	604
9.2.3	Authentication rejected by the UE (MAC code failure) .....	607
9.2.4	Authentication rejected by the UE (SQN failure) .....	608
9.3	Identification .....	609
9.3.1	General Identification .....	609
9.3.2	Handling of IMSI shorter than the maximum length .....	612
9.4	Location updating .....	615
9.4.1	Location updating / accepted .....	615
9.4.2	Location updating / rejected .....	620
9.4.2.1	Location updating / rejected / IMSI invalid .....	620
9.4.2.2	Location updating / rejected / PLMN not allowed .....	623
9.4.2.3	Location updating / rejected / location area not allowed .....	627
9.4.2.4	Location updating / rejected / roaming not allowed in this location area .....	631
9.4.3	Location updating / abnormal cases .....	638
9.4.3.1	Location updating / abnormal cases / random access fails .....	638
9.4.3.2	Location updating / abnormal cases / attempt counter less or equal to 4, LAI different .....	640
9.4.3.3	Location updating / abnormal cases / attempt counter equal to 4 .....	646
9.4.3.4	Location updating / abnormal cases / attempt counter less or equal to 4, stored LAI equal to broadcast LAI .....	653
9.4.4	Location updating / release / expiry of T3240 .....	660
9.4.5	Location updating / periodic .....	661
9.4.5.1	Location updating / periodic spread .....	661
9.4.5.2	Location updating / periodic normal / test 1 .....	662
9.4.5.3	Location updating / periodic normal / test 2 .....	664
9.4.5.4	Location updating / periodic HPLMN search .....	667
9.4.5.4.1	Location updating / periodic HPLMN search / UE waits time T .....	667
9.4.5.4.2	Location updating / periodic HPLMN search / UE in manual mode .....	668
9.4.5.4.3	Location updating / periodic HPLMN search / UE waits at least two minutes and at most T minutes .....	669
9.4.6	Location updating / interworking of attach and periodic .....	671
9.5	MM connection .....	672

9.5.1	Introduction .....	672
9.5.2	MM connection / establishment with cipher.....	673
9.5.3	MM connection / establishment without cipher.....	674
9.5.4	MM connection / establishment rejected .....	675
9.5.5	MM connection / establishment rejected cause 4 .....	676
9.5.6	MM connection / expiry T3230.....	678
9.5.7	MM connection / abortion by the network.....	679
9.5.7.1	MM connection / abortion by the network / cause #6 .....	679
9.5.7.2	MM connection / abortion by the network / cause not equal to #6 .....	682
9.5.8	MM connection / follow-on request pending.....	683
9.5.8.1	MM connection / follow-on request pending / test 1 .....	683
9.5.8.2	MM connection / follow-on request pending / test 2 .....	684
9.5.8.3	MM connection / follow-on request pending / test 3 .....	686
10	Circuit Switched Call Control (CC).....	688
10.1	Circuit switched Call Control (CC) state machine verification.....	688
10.1.1	General on CC state machine verification .....	688
10.1.2	Establishment of an outgoing call.....	689
10.1.2.1	Outgoing call / U0 null state .....	691
10.1.2.1.1	Outgoing call / U0 null state / MM connection requested .....	691
10.1.2.2	Outgoing call / U0.1 MM connection pending.....	692
10.1.2.2.1	Outgoing call / U0.1 MM connection pending / CM service rejected.....	692
10.1.2.2.2	Outgoing call / U0.1 MM connection pending / CM service accepted.....	693
10.1.2.2.3	Outgoing call / U0.1 MM connection pending / lower layer failure.....	695
10.1.2.3	Outgoing call / U1 call initiated .....	696
10.1.2.3.1	Outgoing call / U1 call initiated / receiving CALL PROCEEDING .....	696
10.1.2.3.2	Outgoing call / U1 call initiated / rejecting with RELEASE COMPLETE .....	697
10.1.2.3.3	Outgoing call / U1 call initiated / T303 expiry .....	699
10.1.2.3.4	Outgoing call / U1 call initiated / lower layer failure .....	700
10.1.2.3.5	Outgoing call / U1 call initiated / receiving ALERTING.....	702
10.1.2.3.6	Outgoing call / U1 call initiated / entering state U10 .....	703
10.1.2.3.7	Outgoing call / U1 call initiated / unknown message received.....	704
10.1.2.4	Outgoing call / U3 UE originating call proceeding.....	705
10.1.2.4.1	Outgoing call / U3 UE originating call proceeding / ALERTING received.....	705
10.1.2.4.2	Outgoing call / U3 UE originating call proceeding / CONNECT received.....	706
10.1.2.4.3	Outgoing call / U3 UE originating call proceeding / PROGRESS received without in band information .....	708
10.1.2.4.4	Outgoing call / U3 UE originating call proceeding / PROGRESS with in band information .....	709
10.1.2.4.5	Outgoing call / U3 UE originating call proceeding / DISCONNECT with in band tones.....	711
10.1.2.4.6	Outgoing call / U3 UE originating call proceeding / DISCONNECT without in band tones.....	712
10.1.2.4.7	Outgoing call / U3 UE originating call proceeding / RELEASE received .....	713
10.1.2.4.8	Outgoing call / U3 UE originating call proceeding / termination requested by the user .....	715
10.1.2.4.9	Outgoing call / U3 UE originating call proceeding / traffic channel allocation .....	716
10.1.2.4.10	Outgoing call / U3 UE originating call proceeding / timer T310 time-out.....	717
10.1.2.4.11	Outgoing call / U3 UE originating call proceeding / lower layer failure.....	718
10.1.2.4.12	Outgoing call / U3 UE originating call proceeding / unknown message received .....	719
10.1.2.4.13	Outgoing call / U3 UE originating call proceeding / Internal alerting indication.....	721
10.1.2.5	Outgoing call / U4 call delivered .....	722
10.1.2.5.1	Outgoing call / U4 call delivered / CONNECT received .....	722
10.1.2.5.2	Outgoing call / U4 call delivered / termination requested by the user.....	723
10.1.2.5.3	Outgoing call / U4 call delivered / DISCONNECT with in band tones .....	724
10.1.2.5.4	Outgoing call / U4 call delivered / DISCONNECT without in band tones .....	725
10.1.2.5.5	Outgoing call / U4 call delivered / RELEASE received.....	727
10.1.2.5.6	Outgoing call / U4 call delivered / lower layer failure .....	728
10.1.2.5.7	Outgoing call / U4 call delivered / traffic channel allocation .....	729
10.1.2.5.8	Outgoing call / U4 call delivered / unknown message received .....	730
10.1.2.6	U10 call active .....	732
10.1.2.6.1	U10 call active / termination requested by the user.....	732
10.1.2.6.2	U10 call active / RELEASE received .....	733
10.1.2.6.3	U10 call active / DISCONNECT with in band tones .....	734
10.1.2.6.4	U10 call active / DISCONNECT without in band tones .....	736

10.1.2.6.5	U10 call active / RELEASE COMPLETE received .....	737
10.1.2.6.6	U10 call active / SETUP received .....	738
10.1.2.7	U11 disconnect request .....	740
10.1.2.7.1	U11 disconnect request / clear collision .....	740
10.1.2.7.2	U11 disconnect request / RELEASE received .....	741
10.1.2.7.3	U11 disconnect request / timer T305 time-out .....	742
10.1.2.7.4	U11 disconnect request / lower layer failure .....	744
10.1.2.7.5	U11 disconnect request / unknown message received .....	745
10.1.2.8	U12 disconnect indication .....	746
10.1.2.8.1	U12 disconnect indication / call releasing requested by the user .....	746
10.1.2.8.2	U12 disconnect indication / RELEASE received .....	747
10.1.2.8.3	U12 disconnect indication / lower layer failure .....	749
10.1.2.8.4	U12 disconnect indication / unknown message received .....	750
10.1.2.9	Outgoing call / U19 release request .....	751
10.1.2.9.1	Outgoing call / U19 release request / timer T308 time-out .....	751
10.1.2.9.2	Outgoing call / U19 release request / 2nd timer T308 time-out .....	752
10.1.2.9.3	Outgoing call / U19 release request / RELEASE received .....	754
10.1.2.9.4	Outgoing call / U19 release request / RELEASE COMPLETE received .....	755
10.1.2.9.5	Outgoing call / U19 release request / lower layer failure .....	757
10.1.3	Establishment of an incoming call / Initial conditions .....	758
10.1.3.1	Incoming call / U0 null state .....	760
10.1.3.1.1	Incoming call / U0 null state / SETUP received with a non supported bearer capability .....	760
10.1.3.2	Incoming call / U6 call present .....	761
10.1.3.2.1	Incoming call / U6 call present / automatic call rejection .....	761
10.1.3.3	Incoming call / U9 mobile terminating call confirmed .....	763
10.1.3.3.1	Incoming call / U9 mobile terminating call confirmed / alerting or immediate connecting .....	763
10.1.3.3.2	Incoming call / U9 mobile terminating call confirmed / DTCH assignment .....	764
10.1.3.3.3	Incoming call / U9 mobile terminating call confirmed / termination requested by the user .....	765
10.1.3.3.4	Incoming call / U9 mobile terminating call confirmed / DISCONNECT received .....	766
10.1.3.3.5	Incoming call / U9 mobile terminating call confirmed / RELEASE received .....	768
10.1.3.3.6	Incoming call / U9 mobile terminating call confirmed / lower layer failure .....	769
10.1.3.3.7	Incoming call / U9 mobile terminating call confirmed / unknown message received .....	771
10.1.3.4	Incoming call / U7 call received .....	772
10.1.3.4.1	Incoming call / U7 call received / call accepted .....	772
10.1.3.4.2	Incoming call / U7 call received / termination requested by the user .....	773
10.1.3.4.3	Incoming call / U7 call received / DISCONNECT received .....	774
10.1.3.4.4	Incoming call / U7 call received / RELEASE received .....	776
10.1.3.4.5	Incoming call / U7 call received / lower layer failure .....	777
10.1.3.4.6	Incoming call / U7 call received / unknown message received .....	778
10.1.3.4.7	Incoming call / U7 call received / DTCH assignment .....	779
10.1.3.4.8	Incoming call / U7 call received / RELEASE COMPLETE received .....	781
10.1.3.5	Incoming call / U8 connect request .....	782
10.1.3.5.1	Incoming call / U8 connect request / CONNECT acknowledged .....	782
10.1.3.5.2	Incoming call / U8 connect request / timer T313 time-out .....	783
10.1.3.5.3	Incoming call / U8 connect request / termination requested by the user .....	785
10.1.3.5.4	Incoming call / U8 connect request / DISCONNECT received with in-band information .....	786
10.1.3.5.5	Incoming call / U8 connect request / DISCONNECT received without in-band information .....	787
10.1.3.5.6	Incoming call / U8 connect request / RELEASE received .....	788
10.1.3.5.7	Incoming call / U8 connect request / lower layer failure .....	790
10.1.3.5.8	Incoming call / U8 connect request / DTCH assignment .....	791
10.1.3.5.9	Incoming call / U8 connect request / unknown message received .....	792
10.1.4	In call functions .....	793
10.1.4.1	In-call functions / DTMF information transfer .....	793
10.1.4.1.1	In-call functions / DTMF information transfer / basic procedures .....	793
10.1.4.2	In-call functions / user notification .....	795
10.1.4.2.1	In-call functions / User notification / UE terminated .....	795
10.1.4.3	In-call functions / channel changes .....	796
10.1.4.3.1	In-call functions / channel changes / a successful channel change in active state/ Hard handover .....	797

10.1.4.3.2	In-call functions / channel changes / an unsuccessful channel change in active mode/Hard handover .....	798
10.1.4.4	In-call functions / UE terminated in-call modification .....	799
10.1.4.4.1	In-call functions / UE terminated in-call modification / modify when new mode is not supported .....	799
10.1.4.5	In-call functions / UE originated in-call modification .....	801
10.1.4.5.1	In-call functions / UE originated in-call modification / a successful case of modifying .....	801
10.1.4.5.2	In-call functions / UE originated in-call modification / modify rejected .....	803
10.1.4.5.3	In-call functions / UE originated in-call modification / an abnormal case of acceptance .....	804
10.1.4.5.4	In-call functions / UE originated in-call modification / an abnormal case of rejection .....	805
10.1.4.5.5	In-call functions / UE originated in-call modification / time-out of timer T323 .....	807
10.1.4.5.6	In-call functions / UE originated in-call modification / a successful channel change in state mobile originating modify .....	808
10.1.4.5.7	In-call functions / UE originated in-call modification / an unsuccessful channel change in state mobile originating modify .....	809
10.1.4.5.8	In-call functions / UE originated in-call modification / unknown message received .....	811
10.1.4.5.9	In-call functions / UE originated in-call modification / a release complete received .....	812
10.2	Call Re-establishment .....	814
10.2.1	Call Re-establishment/call present, re-establishment allowed .....	814
10.2.2	Call Re-establishment/call under establishment, transmission stopped .....	815
10.3	User to user signalling .....	817
11	Session Management Procedures .....	820
11.1	PDP context activation .....	820
11.1.1	Initiated by the UE .....	820
11.1.1.1	Attach initiated by context activation/QoS Offered by Network is the QoS Requested .....	820
11.1.1.2	QoS offered by the network is a lower QoS .....	822
11.1.1.2.1	QoS accepted by UE .....	822
11.1.1.2.2	QoS rejected by UE .....	823
11.1.2	PDP context activation requested by the network, successful and unsuccessful .....	824
11.1.3	Abnormal Cases .....	827
11.1.3.1	T3380 Expiry .....	827
11.1.3.2	Collision of UE initiated and network requested PDP context activation .....	828
11.1.4	Secondary PDP context activation procedures .....	830
11.1.4.1	Successful Secondary PDP Context Activation Procedure Initiated by the UE .....	830
11.1.4.1.1	QoS Offered by Network is the QoS Requested .....	830
11.1.4.1.2	QoS Offered by Network is a lower QoS .....	832
11.1.4.2	Abnormal cases .....	834
11.1.4.2.1	T3380 Expiry .....	834
11.2	PDP context modification procedure .....	836
11.2.1	Network initiated PDP context modification .....	836
11.2.1.5	Test requirements .....	838
11.2.2	UE initiated PDP context modification (FFS) .....	838
11.2.3	Abnormal cases (FFS) .....	838
11.2.3.1	T3381 expiry .....	838
11.2.3.2	Collision of UE and network initiated PDP context modification procedures .....	838
11.3	PDP context deactivation procedure .....	838
11.3.1	PDP context deactivation initiated by the UE .....	838
11.3.1.5	Test requirements .....	840
11.3.2	PDP context deactivation initiated by the network .....	840
11.3.2.5	Test requirements .....	841
11.3.3	Abnormal cases .....	841
11.3.3.1	T3390 Expiry .....	841
11.3.3.2	Collision of UE and network initiated PDP context deactivation requests .....	843
11.4	Unknown or Unforeseen Transaction Identifier/Non-semantical Mandatory Information Element Errors .....	845
11.4.1	Error cases .....	845
12	Elementary procedure for Packet Switched Mobility Management .....	848
12.1	Applicability, default conditions and default messages .....	848
12.2	PS attach procedure .....	848
12.2.1	Normal PS attach .....	848

12.2.1.1	PS attach / accepted.....	848
12.2.1.2	PS attach / rejected / IMSI invalid / illegal UE .....	851
12.2.1.3	PS attach / rejected / IMSI invalid / PS services not allowed.....	854
12.2.1.4	PS attach / rejected / PLMN not allowed .....	856
12.2.1.5	PS attach / rejected / roaming not allowed in this location area.....	858
12.2.1.6	PS attach / abnormal cases / access barred due to access class control .....	866
12.2.1.7	PS attach / abnormal cases / change of cell into new routing area .....	869
12.2.1.8	PS attach / abnormal cases / power off .....	870
12.2.1.9	PS attach / abnormal cases / PS detach procedure collision.....	872
12.2.2	Combined PS attach.....	874
12.2.2.1	Combined PS attach / PS and non-PS attach accepted.....	874
12.2.2.2	Combined PS attach / PS only attach accepted .....	878
12.2.2.3	Combined PS attach / PS attach while IMSI attach .....	883
12.2.2.4	Combined PS attach / rejected / IMSI invalid / illegal ME .....	885
12.2.2.5	Combined PS attach / rejected / PS services and non-PS services not allowed .....	887
12.2.2.6	Combined PS attach / rejected / PS services not allowed .....	890
12.2.2.7	Combined PS attach / rejected / location area not allowed .....	893
12.2.2.8	Combined PS attach / abnormal cases / attempt counter check / miscellaneous reject causes.....	897
12.2.2.9	Combined PS attach / abnormal cases / PS detach procedure collision .....	900
12.3	PS detach procedure.....	903
12.3.1	UE initiated PS detach procedure .....	903
12.3.1.1	PS detach / power off / accepted .....	903
12.3.1.2	PS detach / accepted.....	904
12.3.1.3	PS detach / abnormal cases / attempt counter check / procedure timeout .....	906
12.3.1.4	PS detach / abnormal cases / GMM common procedure collision.....	908
12.3.1.5	PS detach / power off / accepted .....	910
12.3.1.6	PS detach / accepted / PS/IMSI detach .....	911
12.3.1.7	PS detach / accepted / IMSI detach.....	913
12.3.1.8	PS detach / abnormal cases / change of cell into new routing area .....	915
12.3.1.9	PS detach / abnormal cases / PS detach procedure collision.....	917
12.3.2	Network initiated PS detach procedure.....	918
12.3.2.1	PS detach / re-attach not required / accepted .....	918
12.3.2.2	PS detach / rejected / IMSI invalid / PS services not allowed.....	920
12.3.2.3	PS detach / IMSI detach / accepted.....	923
12.3.2.4	PS detach / re-attach requested / accepted .....	925
12.3.2.5	PS detach / rejected / location area not allowed .....	927
12.4	Routing area updating procedure .....	931
12.4.1	Normal routing area updating .....	931
12.4.1.1	Routing area updating / accepted .....	931
12.4.1.2	Routing area updating / rejected / IMSI invalid / illegal ME .....	934
12.4.1.3	Routing area updating / rejected / UE identity cannot be derived by the network .....	937
12.4.1.4	Routing area updating / rejected / location area not allowed .....	939
12.4.1.5	Routing area updating / abnormal cases / attempt counter check / miscellaneous reject causes .....	942
12.4.1.6	Routing area updating / abnormal cases / change of cell into new routing area.....	946
12.4.1.7	Routing area updating / abnormal cases / change of cell during routing area updating procedure .....	949
12.4.1.8	Routing area updating / abnormal cases / P-TMSI reallocation procedure collision .....	951
12.4.2	Combined routing area updating.....	953
12.4.2.1	Combined routing area updating / combined RA/LA accepted .....	953
12.4.2.2	Combined routing area updating / UE in CS operation at change of RA.....	956
12.4.2.3	Combined routing area updating / RA only accepted .....	958
12.4.2.4	Combined routing area updating / rejected / PLMN not allowed.....	963
12.4.2.5	Combined routing area updating / rejected / roaming not allowed in this location area .....	965
12.4.2.6	Combined routing area updating / abnormal cases / access barred due to access class control .....	970
12.4.2.7	Combined routing area updating / abnormal cases / attempt counter check / procedure timeout .....	975
12.4.2.8	Combined routing area updating / abnormal cases / change of cell into new routing area .....	978
12.4.2.9	Combined routing area updating / abnormal cases / change of cell during routing area updating procedure .....	981
12.4.2.10	Combined routing area updating / abnormal cases / PS detach procedure collision .....	983
12.4.3	Periodic routing area updating.....	986
12.4.3.1	Periodic routing area updating / accepted .....	986



12.4.3.2	Periodic routing area updating / accepted / T3312 default value .....	987
12.4.3.3	Periodic routing area updating / no cell available / network mode I .....	989
12.4.3.4	Combined periodic routing area updating / no cell available .....	992
12.5	P-TMSI reallocation .....	994
12.6	PS authentication and ciphering .....	996
12.6.1	Test of authentication .....	996
12.6.1.1	Authentication accepted .....	996
12.6.1.2	Authentication rejected by the network .....	998
12.6.1.3	Authentication rejected by the UE .....	1000
12.6.1.3.1	GMM cause 'MAC failure' .....	1000
12.6.1.3.2	GMM cause 'Synch failure' .....	1003
12.6.2	Test of ciphering mode setting .....	1006
12.6.2.1	Ciphering mode / start ciphering .....	1006
12.6.2.2	Ciphering mode / stop ciphering .....	1009
12.6.2.3	Ciphering mode / IMEISV request .....	1012
12.7	Identification procedure .....	1015
12.7.1	General Identification .....	1015
12.8	GMM READY timer handling .....	1017
13	General Tests .....	1020
13.1	Emergency call / general .....	1020
13.2	Emergency call .....	1020
13.2.1	Emergency call / with USIM .....	1020
13.2.1.1	Emergency call / with USIM / accept case .....	1020
13.2.2	Emergency call / without USIM .....	1022
13.2.2.1	Emergency call / without USIM / accept case .....	1022
13.2.2.2	Emergency call / without USIM / reject case .....	1024
14	Radio Bearer Services .....	1027
14.1	General information for radio bearer tests .....	1027
14.1.1	UE radio bearer test mode activation procedure .....	1027
14.2	Combinations on DPCH .....	1028
14.2.1	Stand-alone UL:1.7 DL:1.7 kbps SRBs for DCCH .....	1028
14.2.2	Stand-alone UL:3.4 DL:3.4 kbps SRBs for DCCH .....	1028
14.2.3	Stand-alone UL:13.6 DL:13.6 kbps SRBs for DCCH .....	1028
14.2.4	Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH ..	1028
14.2.5	Conversational / speech / UL:10.2 DL:10.2 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH ..	1031
14.2.6	Conversational / speech / UL:7.95 DL:7.95 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH ..	1034
14.2.7	Conversational / speech / UL:7.4 DL:7.4 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....	1037
14.2.8	Conversational / speech / UL:6.7 DL:6.7 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....	1040
14.2.9	Conversational / speech / UL:5.9 DL:5.9 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....	1043
14.2.10	Conversational / speech / UL:5.15 DL:5.15 kbps / CS RAB + UL:1.7 DL:1.7 kbps SRBs for DCCH ..	1046
14.2.11	Conversational / speech / UL:4.75 DL:4.75 kbps / CS RAB + UL:1.7 DL:1.7 kbps SRBs for DCCH ..	1049
14.2.12	Conversational / unknown / UL:28.8 DL:28.8 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....	1052
14.2.13	Conversational / unknown / UL:64 DL:64 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH ....	1054
14.2.13.1	Conversational / unknown / UL:64 DL:64 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 20 ms TTI .....	1054
14.2.13.2	Conversational / unknown / UL:64 DL:64 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 40 ms TTI .....	1056
14.2.14	Conversational / unknown / UL:32 DL:32 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH ....	1058
14.2.14.1	Conversational / unknown / UL:32 DL:32 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 20 ms TTI .....	1058
14.2.14.2	Conversational / unknown / UL:32 DL:32 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 40 ms TTI .....	1059
14.2.15	Streaming / unknown / UL:14.4/DL:14.4 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....	1061
14.2.16	Streaming / unknown / UL:28.8/DL:28.8 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....	1063
14.2.17	Streaming / unknown / UL:57.6/DL:57.6 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....	1063
14.2.18	Streaming / unknown / UL:0 DL:64 kbps / CS or PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH ....	1067
14.2.19	Streaming / unknown / UL:64 DL:0 kbps / CS or PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH ....	1071
14.2.20	Streaming / unknown / UL:0 DL:128 kbps / CS or PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH ..	1075

14.2.21	Streaming / unknown / UL:128 DL:0 kbps / CS or PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH	1079
14.2.22	Streaming / unknown / UL:0 DL:384 kbps / CS or PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH	1083
14.2.23	Interactive or background / UL:32 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH	1088
14.2.23.1	Interactive or background / UL:32 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 10 ms TTI	1088
14.2.23.2	Interactive or background / UL:32 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 20 ms TTI	1089
14.2.24	Interactive or background / UL:64 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH	1089
14.2.25	Interactive or background / UL:32 DL: 64 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH	1089
14.2.26	Interactive or background / UL:64 DL: 64 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH	1089
14.2.27	Interactive or background / UL:64 DL:128 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH	1089
14.2.28	Interactive or background / UL:128 DL:128 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH	1089
14.2.29	Interactive or background / UL:64 DL:144 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH	1089
14.2.30	Interactive or background / UL:144 DL:144 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH	1089
14.2.31	Interactive or background / UL:64 DL:256 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH	1090
14.2.31.1	Interactive or background / UL:64 DL:256 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH / 10 ms TTI	1090
14.2.31.2	Interactive or background / UL:64 DL:256 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH / 20 ms TTI	1090
14.2.32	Interactive or background / UL:64 DL:384 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH	1090
14.2.32.1	Interactive or background / UL:64 DL:384 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH / 10 ms TTI	1090
14.2.32.2	Interactive or background / UL:64 DL:384 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH / 20 ms TTI	1090
14.2.33	Interactive or background / UL:128 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH	1090
14.2.33.1	Interactive or background / UL:128 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 10 ms TTI	1090
14.2.33.2	Interactive or background / UL:128 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 20 ms TTI	1090
14.2.34	Interactive or background / UL:384 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH	1091
14.2.34.1	Interactive or background / UL:384 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 10 ms TTI	1091
14.2.34.2	Interactive or background / UL:384 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 20 ms TTI	1091
14.2.35	Interactive or background / UL:64 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH	1091
14.2.35.1	Interactive or background / UL:64 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 10 ms TTI	1091
14.2.35.2	Interactive or background / UL:64 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 20 ms TTI	1091
14.2.36	Interactive or background / UL:128 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH	1091
14.2.37	Interactive or background / UL:384 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH	1091
14.2.37.1	Interactive or background / UL:384 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 10 ms TTI	1091
14.2.37.2	Interactive or background / UL:384 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 20 ms TTI	1091
14.2.38	Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:32 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH	1092
14.2.39	Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:32 DL:64 kbps / PS RAB+ UL:3.4 DL: 3.4 kbps SRBs for DCCH	1092
14.2.40	Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:64 kbps / PS RAB+ UL:3.4 DL: 3.4 kbps SRBs for DCCH	1092
14.2.41	Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:128 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH	1092
14.2.42	Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:256 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH	1092
14.2.43	Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH	1092

14.2.43.1	Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 10 ms TTI.....	1092
14.2.43.2	Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 20 ms TTI.....	1093
14.2.44	Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:128 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....	1093
14.2.45	Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Streaming / unknown / UL:57.6 DL:57.6 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....	1093
14.2.46	Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Streaming / unknown / UL:0 DL:64 kbps / CS or PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....	1093
14.2.47	Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Streaming / unknown / UL:0 DL:128 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....	1093
14.2.48	Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Streaming / unknown / UL:0 DL:384 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....	1093
14.2.49	Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Conversational / unknown / UL:64 DL:64 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....	1093
14.2.50	Conversational / unknown / UL:64 DL:64 kbps / CS RAB + Conversational / unknown / UL:64 DL:64 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....	1094
14.2.51	Conversational / unknown / UL:64 DL:64 kbps / CS RAB + Interactive or background / UL:64 DL:64 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....	1094
14.2.52	Conversational / unknown / UL:64 DL:64 kbps / CS RAB + Interactive or background / UL:64 DL:128 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....	1094
14.2.53	Conversational / unknown / UL:64 DL:64 kbps / CS RAB + Interactive or background / UL:128 DL:128 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....	1094
14.2.54	Interactive or background / UL:64 DL:128 kbps / PS RAB + Streaming / unknown / UL:0 DL:64 kbps / CS or PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....	1094
14.2.55	Interactive or background / UL:64 DL:128 kbps / PS RAB + Streaming / unknown / UL:0 DL:128 kbps / CS or PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....	1094
14.3	Combinations on PDSCH and DPCH .....	1094
14.3.1	Interactive or background / UL:64 DL:256 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH ..	1094
14.3.2	Interactive or background / UL:64 DL:384 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH ..	1095
14.3.3	Interactive or background / UL:64 DL:2048 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH	1095
14.3.4	Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:256 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....	1095
14.3.5	Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....	1095
14.3.6	Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....	1095
14.4	Combinations on SCCPCH .....	1095
14.4.1	Stand-alone signalling RB for PCCH .....	1095
14.4.2	Interactive/Background 32 kbps PS RAB + SRBs for CCCH + SRB for DCCH + SRB for BCCH .....	1095
14.4.3	Interactive/Background 32 kbps RAB + SRBs for PCCH + SRB for CCCH + SRB for DCCH + SRB for BCCH .....	1095
14.5	Combinations on PRACH .....	1096
14.5.1	Interactive/Background 32 kbps PS RAB + SRB for CCCH + SRB for DCCH .....	1096
15	Supplementary Services .....	1097
16	Short message service (SMS).....	1098
16.1	Short message service point to point on CS mode .....	1098
16.1.1	SMS mobile terminated .....	1098
16.1.2	SMS mobile originated .....	1104
16.1.3	Test of memory full condition and memory available notification:.....	1108
16.1.4	Test of the status report capabilities and of SMS-COMMAND:.....	1112
16.1.5	Test of message class 0 to 3.....	1115
16.1.5.1	Short message class 0.....	1115
16.1.5.2	Test of class 1 short messages.....	1118
16.1.5.3	Test of class 2 short messages .....	1119
16.1.5.4	Test of class 3 short messages .....	1122
16.1.6	Test of short message type 0.....	1122
16.1.7	Test of the replace mechanism for SM type 1-7 .....	1122

16.1.8	Test of the reply path scheme .....	1125
16.1.9	Multiple SMS mobile originated .....	1128
16.1.9.1	UE in idle mode .....	1128
16.1.9.2	UE in active mode.....	1131
16.2	Short message service point to point on PS mode.....	1133
16.2.1	SMS mobile terminated .....	1133
16.2.2	SMS mobile originated .....	1139
16.2.3	Test of memory full condition and memory available notification:.....	1142
16.2.4	Test of the status report capabilities and of SMS-COMMAND: .....	1147
16.2.5	Test of message class 0 to 3 .....	1150
16.2.5.1	Short message class 0.....	1150
16.2.5.2	Test of class 1 short messages.....	1152
16.2.5.3	Test of class 2 short messages.....	1153
16.2.5.4	Test of class 3 short messages.....	1156
16.2.6	Test of short message type 0.....	1156
16.2.7	Test of the replace mechanism for SM type 1-7 .....	1156
16.2.8	Test of the reply path scheme .....	1159
16.2.9	Multiple SMS mobile originated .....	1162
16.2.9.1	UE in idle mode .....	1162
16.2.9.2	UE in active mode.....	1164
16.3	Short message service cell broadcast .....	1166
16.4	Default message contents: .....	1168
16.4.1	Default message contents for SM-CP protocol.....	1168
16.4.2	Default message contents for SM-RP protocol.....	1168
16.4.3	Default message contents for SM-TP protocol .....	1169
17	User Equipment features (MMI, VHE, MexE, SAT).....	1170
17.1	Test of autocalling restrictions .....	1170
17.1.1	General.....	1170
17.1.2	Constraining the access to a single number (TS 22.001 category 3) .....	1170
17.1.3	Constraining the access to a single number (TS 22.001 categories 1 and 2) .....	1172
17.1.4	Behaviour of the UE when its list of blacklisted numbers is full.....	1174
<b>Annex A: Default RRC Message Contents.....</b>		<b>1175</b>
<b>Annex B (informative): Change history .....</b>		<b>1361</b>

---

# Foreword

This Technical Specification (TS) has been produced by the 3<sup>rd</sup> Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
  - 1 presented to TSG for information;
  - 2 presented to TSG for approval;
  - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

---

# Introduction

The present document is the first part of a multi-part conformance specification. TS 34.123-2 (part 2) [11] contains a pro-forma for the Implementation Conformance Statement (ICS). TS 34.123-3 (part 3) [12] contains a detailed and executable description of the test cases written in a standard testing language, TTCN, as defined in ISO/IEC 9646.

For at least a minimum set of services, the prose descriptions of test cases will have a matching detailed test case implemented in TTCN [12].

The minimum set of services are defined as:

- voice calls;
- emergency calls;
- SMS (both Point-to-point and Cell broadcast);
- Circuit Switched data at up to 64 k bits/second;
- fax;

including the underlying layers to support these services.

Release 99 will also include the areas:

- auto-calling restrictions.

The present document may contain descriptions of tests for additional services, but these tests may not have matching TTCN test cases.

The present document will not contain any tests on the USIM, or the interface between the UE and the USIM. These tests are documented elsewhere.

Version 1.0.0 of this specification is intended to be at least 60% complete as judged against its anticipated release 99 contents. Version 3.0.0 is intended to be better than 98% complete as judged against its anticipated release 99 contents. These figures should not be taken as representing test coverage of the release 99 core specifications.

---

# 1 Scope

The present document specifies the protocol conformance testing for the 3<sup>rd</sup> Generation User Equipment (UE).

This is the first part of a multi-part test specification. The following information can be found in this part:

- the overall test structure;
- the test configurations;
- the conformance requirement and reference to the core specifications;
- the test purposes; and
- a brief description of the test procedure, the specific test requirements and short message exchange table.

The following information relevant to testing can be found in accompanying specifications:

- the default setting of the test parameters [9]
- the applicability of each test case [11]

A detailed description of the expected sequence of messages can be found in the 3<sup>rd</sup> part of this test specification.

The Implementation Conformance Statement (ICS) pro-forma can be found in the 2<sup>nd</sup> part of this specification.

---

# 2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies.

- [1] 3GPP TR 21.905: "3G Vocabulary".
- [2] 3GPP TS 23.003: "Numbering, Addressing and Identification".
- [3] 3GPP TS 23.022: "Functions related to Mobile Station (MS) in idle mode".
- [4] 3GPP TS 24.008: "Mobile Radio Interface Layer 3 specification; Core Network Protocols - Stage 3".
- [5] 3GPP TS 25.214: "FDD; physical layer procedures".
- [6] 3GPP TS 25.321: "Medium Access Control (MAC) Protocol Specification".
- [7] 3GPP TS 25.322: "Radio Link Control (RLC) Protocol Specification".
- [8] 3GPP TS 25.331: "Radio Resource Control (RRC) Protocol Specification".
- [9] 3GPP TS 34.108: "Reference Environment for Conformance Testing of 3G user equipment (UE)".
- [10] 3GPP TS 34.109: "Logical Test Interface (TDD and FDD)".
- [11] 3GPP TS 34.123-2: "Mobile Station (MS) Conformance Specification, Part 2 - ICS".

- [12] 3GPP TS 34.123-3: " Mobile Station (MS) Conformance Specification, Part 3 - Abstract Test Suites".
- [13] 3GPP TS 11.10: "Mobile Station (MS) Conformance Specification".

---

## 3 Definitions and abbreviations

### 3.1 Definitions

For the purposes of the present document, the terms and definitions given in TR 21.905 apply, unless specified below.

**example:** text used to clarify abstract rules by applying them literally.

### 3.2 Abbreviations

For the purposes of the present document, the abbreviations specified in TR 25.905 apply, with any additional abbreviations specified below:

SS	System Simulator
----	------------------

---

## 4 Overview

### 4.1 Test Methodology

#### 4.1.1 Testing of optional functions and procedures

Any function or procedure which is optional, as indicated in this TS , may be subject to a conformance test if it is implemented in the UE.

A declaration by the apparatus supplier (ICS) is used to determine whether an optional function/procedure has been implemented.

#### 4.1.2 Test interfaces and facilities

Detailed descriptions of the UE test interfaces and special facilities for testing are provided in [10].

### 4.2 Implicit Testing

For some 3GPP signalling and protocol features conformance is not verified explicitly in this TS. This does not imply that correct functioning of these features is not essential, but that these are implicitly tested to a sufficient degree in other tests.

---

## 5 Reference Conditions

The reference environments used by all signalling and protocol tests are specified in TS 34.108. Where a test requires an environment that is different, this will be specified in the test itself.

## 5.1 Generic setup procedures

A set of basic generic procedures for radio resource signalling, and generic setup procedures for layer 3 NAS signalling are described in TS 34.108 Clause 7. These procedures are used in numerous test cases throughout this specification.



## 6 Idle mode operations

NOTE: Most of the default settings in the tables below will most likely be merged into TS 34.108, 6.1.

In the following paragraphs some explanatory text is given concerning the nature of the tests in this subclause and the general behaviour of the SS is described.

Since the conformance requirements of most of the tests in this subclause cannot be tested explicitly, testing is done implicitly by testing the UE behaviour from its responses to the SS.

The SS transmits one BCCH per cell as indicated in the initial conditions for each test. These are referred to as Cell 1, Cell 2, etc. Each of these cell control channels are non-combined with DCCHs. It is assumed that the SS can simultaneously transmit [seven] BCCH and monitor [three] random access channels. For inter-frequency tests it is assumed that at least one of the BCCH and one of the monitored random access channels is in a different frequency band from the others. In some cases, a test is performed in multiple stages in order that the requirements can be tested within the above constraints.

For any UE all the carriers are in its supported band(s) of operation.

Unless otherwise stated in the method of test, in all of the tests of this subclause:

- the SS is continuously paging the UE on all cells at the start of the test and does not respond to RACH requests from the UE. Where a test specifies that the UE is not paged in a particular cell, only idle paging is transmitted according to TS 24.008 (see subclause 3.2.2.2);
- the default values of the system information data fields given in table 6.1.3.1 are used;
- the USIM is in the idle updated state in the default location area with a TMSI assigned at the beginning of each test;
- the [UTRA RF Channel Number list] used for the carriers in each test are chosen from those in table 6.1.3.1 with adjacent carriers separated by a minimum of three RF channels.

The absolute accuracy of the UE signal level measurements is assumed to be  $[\pm 6 \text{ dB}]$ . A difference of at least  $[8 \text{ dB}]$  is allowed for cases of discrimination between cell selection criteria ( $S$ ), immediate cell evaluation reselection criteria ( $S_n$ ) and cell reselection criteria ( $S_n$ ) values and 0.

The relative accuracy of the UE signal level measurements is assumed to be  $[\pm 3 \text{ dB}]$  for the signal levels used in the tests of this subclause.. A difference of at least  $[5 \text{ dB}]$  is allowed for cases of discrimination between  $S$  or  $S_n$  values on different carriers.

NOTE 1: The accuracy of UE signal level measurements is specified in TS 25.101 for FDD and in TS 25.102 for TDD. For all of the tests in this subclause, the signal levels used are greater than  $[1 \text{ dB}]$  above reference sensitivity level.

NOTE 2: The tolerance on timers specified in TS 25.304 is  $[\pm 10 \text{ \%}]$  except for Treselection where it is  $[\pm 2 \text{ seconds}]$ . In the tests of this subclause, the test requirements include these tolerances. Consequently, the times stated in the test requirement sometimes differ from the corresponding timer in the conformance requirement.

Where pulsed signals are specified, the SS tolerance on pulse width is  $[\pm 2 \text{ \%}]$  and the SS tolerance on power level  $[\pm 1 \text{ dB}]$ .

**Table 6.1.3.1: Default values of the system information fields**

[Editor's Note: the table below needs further review and updates according to TS 25.331]

Parameter	TS 25.331 reference	Abbr.	Normal Setting
Cell channel description		-	Any values
MAX retrans		-	1
TX-integer		-	Any value
CELL_BAR_QUALIFY		CBQ	0
CELL_BAR_ACCESS		CBA	0 (not barred)
AC CN		AC	All 0
RE		RE	0 (re-establishment allowed)
NCC		NCC	Any value
Cell Identity		-	Any value
MCC, MNC		PLMN	MS Home PLMN
LAC		LAC	1111 (Hex)
ATT		-	0 (Attach/Detach not allowed)
BS_AG_BLKES_RES		-	Any values
CCCH_CONF		-	1 basic physical channel used for CCCH, non-combined with DCCHs.
T3212		-	Any values
BS_PA_MFRMS		BPM	5 frames
Cell Options		-	Any values
Qhyst		CRH	[4 dB]
P_MAX		MTMC	Max. output power of MS
UE_TXPWR_MAX_RACH			Max. TX power level an UE may use when accessing the cell on RACH (read in system information) (dBm)
Qmin		RAM	[-90] (dB or dBm)
Qoffset <sub>s,n</sub>		CRO	0
[FFS: TEMPORARY_OFFSET]		TO	0
Treselection		PT	0
[FFS: Power Offset]		PO	0
[BA ARFCN]		BA	All 0 except:
			[List of radio channels to be broadcasted in system information TBD]
<i>Cell_selection_and_reselection_quality_measure</i>		-	CPICH $E_c/N_0$
<i>UE_TXPWR_MAX_RACH</i>		-	21 dBm
<i>Accepts intra-freq. cell selection</i>		-	No

Editor's note: Note that the table has been extended with the parameters "Cell\_selection\_and\_reselection\_quality\_measure", "UE\_TXPWR\_MAX\_RACH" and "Accepts intra-freq. cell selection"

**Table 6.1.3.2: Downlink Physical Channels**

Physical Channel	Power	NOTE
CPICH	CPICH $E_c/I_{or}$ = -10 dB	
PCCPCH	PCCPCH $E_c/I_{or}$ = -12 dB	
SCCPCH	SCCPCH $E_c/I_{or}$ = -12 dB	
AICH	AICH $E_c/I_{or}$ = -15 dB	
SCH	SCH $E_c/I_{or}$ = -12 dB	This power shall be divided equally between Primary and Secondary Synchronization channels
PICH	PICH $E_c/I_{or}$ = -15 dB	
DPCH	Test dependent power	
OCNS	Necessary power so that total transmit power spectral density of BS ( $I_{or}$ ) adds to one	

**Table 6.1.3.3: Default radio conditions**

Parameter	Unit	Value
$I_{oc}$	dBm/3.8 4 MHz	-70
<i>Propagation Condition</i>		Static

## 6.1 In a pure 3GPP environment

### 6.1.1 PLMN selection and reselection

#### 6.1.1.1 Manual mode PLMN selection / re-selection and UE indication of available PLMNs

##### 6.1.1.1.1 Definition

Test to verify that the UE can present the available PLMNs to the user when asked to do so in manual mode and that the displayed PLMNs can be selected. If a "PLMN not allowed" or a PLMN with "LA not allowed" is selected, the UE shall enter limited service.

##### 6.1.1.1.2 Conformance requirement

1. At switch on, the MS selects the registered PLMN (if it is available) using all access technologies that the MS is capable of and attempts to perform a Location Registration. The MS shall start its search using the access technology type stored in the RPLMN Last Used Access Technology data field on the SIM. If the RPLMN Last Used Access Technology is not available then an MS capable of GSM access technology shall start its search using GSM access technology.

On recovery from lack of coverage, the MS selects the registered PLMN (if it is available) using all access technologies that the MS is capable of and, if necessary attempts to perform a Location Registration.

If successful registration is achieved, the MS indicates the selected PLMN.

If there is no registered PLMN, or if registration is not possible due to the PLMN being unavailable or registration failure, the MS follows either Automatic or Manual Network Selection Mode Procedure depending on its operating mode.

2. Manual mode - Here the MS indicates to the user which PLMNs are available. Only when the user makes a manual selection does the MS try to obtain normal service on the VPLMN.

3. Manual Network Selection Mode Procedure:

The MS indicates whether there are any PLMNs, which are available using all supported access technologies. This includes "Forbidden PLMNs" and PLMNs which only offer services not supported by the MS.

If displayed, PLMNs meeting the criteria above are presented in the following order:

3.1 HPLMN;

3.2 PLMNs contained in the "User Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);

3.3 PLMNs contained in the "Operator Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);

3.4 Other PLMN/access technology combinations with received high quality signal in random order;

3.5 Other PLMN/access technology combinations in order of decreasing signal quality.

The user may select his desired PLMN and the MS then initiates registration on this PLMN using the access technology chosen by the user for that PLMN or using the highest priority available access technology for that PLMN, if the associated access technologies have a priority order. (This may take place at any time during the presentation of PLMNs). For such a registration, the MS shall ignore the contents of the forbidden LAI and PLMN lists.

If the user does not select a PLMN, the selected PLMN shall be the one that was selected before the PLMN selection procedure started. If no such PLMN was selected or that PLMN is no longer available, then the MS shall attempt to camp on any acceptable cell and enter the limited service state.

4. To prevent repeated attempts to have roaming service on a not allowed LA, when the MS is informed that an LA is forbidden, the LA is added to a list of "forbidden LAs for roaming" which is stored in the MS. This list is deleted when the MS is switched off or when the SIM is removed. Such area restrictions are always valid for complete location areas independent of possible subdivision into GPRS routing areas.

If a "PLMN not allowed" message is received by an MS in response to an LR request from a VPLMN, that VPLMN is added to a list of "forbidden PLMNs" in the SIM and thereafter that VPLMN will not be accessed by the MS when in automatic mode. A PLMN is removed from the "forbidden" list if, after a subsequent manual selection of that PLMN, there is a successful LR. This list is retained when the MS is switched off or the SIM is removed. The HPLMN shall not be stored on the list of "forbidden PLMNs".

## References

1. TS 23.122, 4.4.3.1
2. TS 23.122, 3.1
3. TS 23.122, 4.4.3.1.2
4. TS 23.122, 3.1

NOTE: TS 31.102 defines the USIM fields

### 6.1.1.1.3 Test purpose

1. To verify that if no RPLMN exists at power-on, the UE shall camp on any acceptable cell and enter the limited service state.
2. To verify that in Manual Network Selection Mode Procedure the UE presents PLMNs in a prioritized order.
3. To verify that if a PLMN with LA rejection "LA not allowed" or "PLMN not allowed" is selected, the UE enters limited service.

### 6.1.1.1.4 Method of test

#### Initial conditions

The UE is in manual mode.

The SIM fields EF<sub>UPLMNsel</sub> (UPLMN selector), EF<sub>OPLMNsel</sub> (OPLMN selector) and EF<sub>PHPLMNAT</sub> (Preferred HPLMN Access Technology) shall only contain UTRAN as the Access Technology Identifier.

The SIM fields EF<sub>UPLMNsel</sub> and EF<sub>OPLMNsel</sub> shall only contain one PLMN as indicated in the table.

PLMN 1 is the HPLMN (i.e. IMSI). There is no RPLMN stored in the SIM (i.e. field EF<sub>BCCH</sub>).

The UE is equipped with a SIM containing default values except for those values listed in table [FFS].

Parameters changed from the default values in table 6.1.3.1 and table [FFS].

Parameter	Unit	Cell 1	Cell 2	Cell 3	Cell 4	Cell 5
$\hat{I}_{or}/I_{oc}$	dB	2.5	4.5	7.5		
$CPICH_{Ec/Io}$	dB	-18	-16	-13	[FFS: High Q signal]	[FFS: Not high Q signal]
$CPICH_{RSCP}$	dBm	-78	-76	-73		
$Q_{qualmin}$	dB	-20	-20	-20		
$Q_{rxlevmin}$	dBm	-100	-100	-100		
$S_{qual}$	dB	2	4	7		
$S_{rxlev}$	dBm	22	24	27		
<i>PLMN</i>		PLMN 1	PLMN 2	PLMN 3	PLMN 4	PLMN 5
<i>SIM field for storing PLMN</i>		EF <sub>IMSI</sub> (IMSI)	EF <sub>UPLMNsel</sub> (UPLMN selector)	EF <sub>OPLMNsel</sub> (OPLMN selector)	Other PLMN than on the SIM	Other PLMN than on the SIM

### Test procedure

- The SS activates cells 1-4
- The UE is switched on
- The SS waits until UE says "Emergency calls only"
- The UE is requested to display the PLMN list. PLMN 1 is selected manually
- The SS sends SYSTEM INFORMATION to the UE to inform it that PLMN 1 belongs to a "LA not allowed"
- The SS waits until UE says "Emergency calls only"
- Step d-g) is repeated except that in d), PLMN 2 is selected and in e), the UE is informed that PLMN 2 belongs to a "PLMN not allowed"
- Step d-g) is repeated except that in d), PLMN 3 is selected and in e), the UE is informed that PLMN 3 belongs to a "LA not allowed"
- Step d-g) is repeated except that in d), PLMN 4 is selected and in e), the UE is informed that PLMN 4 belongs to a "LA not allowed"
- Step d-g) is repeated except that in d), PLMN 5 is selected and in e), the UE is informed that PLMN 5 belongs to a "LA not allowed"

#### 6.1.1.1.5 Test Requirements

- In step d), the selected PLMN shall be displayed as PLMN 1 within 2 min.
- In step g), the selected PLMN shall be displayed as PLMN 2 within 2 min.
- In step h), the selected PLMN shall be displayed as PLMN 3 within 2 min.
- In step i), the selected PLMN shall be displayed as PLMN 4 within 2 min.
- In step j), the selected PLMN shall be displayed as PLMN 5 within 2 min.

[Editor's note: The 2 min. must be confirmed]

[Editor's note: The time 2 min is taken from the GSM 11.10-1, test case 26.3.4]

[Editor's note: It is assumed that the displayed PLMN reflects the cell camped on and that it is not necessary to test that the UE actually camps on that cell]

### 6.1.1.2 Manual mode PLMN selection / reselection; independence of RF level and preferred PLMN

#### 6.1.1.2.1 Definition

Test to verify that in Manual Network Selection Mode, the UE is able to obtain normal service on a PLMN which is neither the better nor a preferred PLMN and that it tries to obtain service on a VPLMN if and only if the user selects it manually.

#### 6.1.1.2.2 Conformance requirement

1. At switch on, the MS selects the registered PLMN (if it is available) using all access technologies that the MS is capable of and attempts to perform a Location Registration. The MS shall start its search using the access technology type stored in the RPLMN Last Used Access Technology data field on the SIM. If the RPLMN Last Used Access Technology is not available then an MS capable of GSM access technology shall start its search using GSM access technology.

On recovery from lack of coverage, the MS selects the registered PLMN (if it is available) using all access technologies that the MS is capable of and, if necessary attempts to perform a Location Registration.

If successful registration is achieved, the MS indicates the selected PLMN.

If there is no registered PLMN, or if registration is not possible due to the PLMN being unavailable or registration failure, the MS follows either Automatic or Manual Network Selection Mode Procedure depending on its operating mode.

2. Manual mode - Here the MS indicates to the user which PLMNs are available. Only when the user makes a manual selection does the MS try to obtain normal service on the VPLMN.3. Manual Network Selection Mode Procedure:

The MS indicates whether there are any PLMNs, which are available using all supported access technologies. This includes "Forbidden PLMNs" and PLMNs which only offer services not supported by the MS.

If displayed, PLMNs meeting the criteria above are presented in the following order:

1.1 HPLMN;

1.2 PLMNs contained in the "User Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);

1.3 PLMNs contained in the "Operator Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);

1.4 Other PLMN/access technology combinations with received high quality signal in random order;

1.5 Other PLMN/access technology combinations in order of decreasing signal quality.

The user may select his desired PLMN and the MS then initiates registration on this PLMN using the access technology chosen by the user for that PLMN or using the highest priority available access technology for that PLMN, if the associated access technologies have a priority order. (This may take place at any time during the presentation of PLMNs). For such a registration, the MS shall ignore the contents of the forbidden LAI and PLMN lists.

#### References

1. TS 23.122, 4.4.3.1
2. TS 23.122, 3.1
3. TS 23.122, 4.4.3.1.2

NOTE: TS 31.102 defines the USIM fields

## 6.1.1.2.3 Test purpose

1. To verify that the selected PLMN at switch-on is the HPLMN
2. To verify that in Manual Network Selection Mode Procedure the UE tries to obtain service on a VPLMN if and only if the user selects it manually
3. To verify that the UE is able to obtain normal service on a PLMN which is neither the better nor a preferred PLMN.

## 6.1.1.2.4 Method of test

## Initial conditions

The UE is in manual mode.

PLMN 1 is the HPLMN (i.e. IMSI). There is no RPLMN stored in the SIM (i.e. field EF<sub>BCCH</sub>).

PLMN 2 is not contained in any preferred PLMN list on the SIM.

PLMN 3 is contained in the UPLMN selector list on the SIM and has a different MCC-MNC from PLMN 1.

The UE is equipped with a SIM containing default values except for those values listed in table [FFS].

Parameters changed from the default values in table 6.1.3.1 and table [FFS].

Parameter	Unit	Cell 1			Cell 2
		T1	T2	T3	
<i>UTRA RF Channel Number</i>		UARFCN 1			UARFCN 2
$\hat{I}_{or}/I_{oc}$	dB	-4.74	-	0.02	-7.25
<i>CPICH_Ec/Io</i>	dB	-16	OFF	-13	-18
<i>CPICH_RSCP</i>	dBm	-85	-	-80	-87
<i>Qqualmin</i>	dB	-20	-	-20	-20
<i>Qrxlevmin</i>	dBm	-100	-	-100	-100
<i>Squal</i>	dB	4	-	7	2
<i>Srxlev</i>	dBm	15	-	20	13
<i>PLMN</i>		PLMN 1	-	PLMN 3	PLMN 2

## Test procedure

- a) The SS activates cells 1 and 2 with T1 defined parameters.
- b) The UE is switched on.
- c) PLMN 1 is selected
- d) The SS waits for RRC CONNECTION REQUEST from the UE. A complete Location Update is done.
- e) Cell 1 is switched off as described for T2.
- f) The SS waits to see if there is any RRC CONNECTION REQUEST from the UE
- g) Cell 1 is switched on and set according to T3
- h) The SS waits to see if there is any RRC CONNECTION REQUEST from the UE
- i) PLMN 2 is selected manually
- j) The SS waits for RRC CONNECTION REQUEST from the UE. A complete Location Update is done.
- k) Cell 2 is switched off
- l) The SS waits to see if there is any RRC CONNECTION REQUEST from the UE

#### 6.1.1.2.5 Test Requirements

- 1) In step d), there shall be a response on Cell 1 within 2 min. The selected PLMN shall be PLMN 1.
- 2) In step f), there shall be no response from the UE within 2 min.
- 3) In step h), there shall be no response from the UE within 2 min.
- 4) In step j), there shall be a response on Cell 2 within 2 min. The selected PLMN shall be PLMN 2.
- 5) In step l), there shall be no response from the UE within 2 min.

[Editor's note: The time 2 min is taken from the GSM 11.10-1, test case 26.3.4]

#### 6.1.1.3 Automatic mode PLMN selection

##### 6.1.1.3.1 Definition

Test to verify that in Automatic Network Selection Mode, the UE selects PLMNs in a prioritized order and that a "PLMN not allowed" or a PLMN with "LA not allowed" is not selected.

##### 6.1.1.3.2 Conformance requirement

1. At switch on, the MS selects the registered PLMN (if it is available) using all access technologies that the MS is capable of and attempts to perform a Location Registration. The MS shall start its search using the access technology type stored in the RPLMN Last Used Access Technology data field on the SIM. If the RPLMN Last Used Access Technology is not available then an MS capable of GSM access technology shall start its search using GSM access technology.

On recovery from lack of coverage, the MS selects the registered PLMN (if it is available) using all access technologies that the MS is capable of and, if necessary attempts to perform a Location Registration.

If successful registration is achieved, the MS indicates the selected PLMN. If there is no registered PLMN, or if registration is not possible due to the PLMN being unavailable or registration failure, the MS follows either Automatic or Manual Network Selection Mode Procedure depending on its operating mode.

2. Automatic Network Selection Mode Procedure:

The MS selects and attempts registration on other PLMNs, if available and allowable in the following order:

- 1.1 HPLMN (if not previously selected);
- 1.2 Each PLMN in the "User Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order)
- 1.3 Each PLMN in the "Operator Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order)
- 1.4 Other PLMN/access technology combinations with received high quality signal in random order
- 1.5 Other PLMN/access technology combinations in order of decreasing signal quality

If successful registration is achieved, the MS indicates the selected PLMN.

If registration cannot be achieved because no PLMNs are available and allowable, the MS indicates "no service" to the user, waits until a new PLMN is available and allowable and then repeats the procedure.

If there were one or more PLMNs which were available and allowable, but an LR failure made registration on those PLMNs unsuccessful or an entry in a forbidden LAI list prevented a registration attempt, the MS selects the first such PLMN again and enters a limited service state.



3. To prevent repeated attempts to have roaming service on a not allowed LA, when the MS is informed that an LA is forbidden, the LA is added to a list of "forbidden LAs for roaming" which is stored in the MS. This list is deleted when the MS is switched off or when the SIM is removed. Such area restrictions are always valid for complete location areas independent of possible subdivision into GPRS routing areas.

If a "PLMN not allowed" message is received by an MS in response to an LR request from a VPLMN, that VPLMN is added to a list of "forbidden PLMNs" in the SIM and thereafter that VPLMN will not be accessed by the MS when in automatic mode. A PLMN is removed from the "forbidden" list if, after a subsequent manual selection of that PLMN, there is a successful LR. This list is retained when the MS is switched off or the SIM is removed. The HPLMN shall not be stored on the list of "forbidden PLMNs".

## References

1. TS 23.122, 4.4.3.1
2. TS 23.122, 4.4.3.1.1
3. TS 23.122, 3.1

NOTE: TS 31.102 defines the USIM fields

### 6.1.1.3.3 Test purpose

1. To verify that the selected PLMN at switch-on is the HPLMN if no RPLMN exists
  2. To verify that in Automatic Network Selection Mode Procedure the UE selects PLMNs in a prioritized order.
  3. To verify that a PLMN with LA rejection "LA not allowed" or "PLMN not allowed" is not selected
- 6.1.1.3.4 Method of test

### Initial conditions

The UE is in automatic mode. The SIM fields EF<sub>UPLMNsel</sub> (UPLMN selector), EF<sub>OPLMNsel</sub> (OPLMN selector) and EF<sub>PHPLMNAT</sub> (Preferred HPLMN Access Technology) shall only contain UTRAN as the Access Technology Identifier.

The SIM fields EF<sub>UPLMNsel</sub> and EF<sub>OPLMNsel</sub> shall only contain one PLMN as indicated in the table.

PLMN 1 is the HPLMN (i.e. IMSI). There is no RPLMN stored in the SIM (i.e. field EF<sub>BCCH</sub>).

The UE is equipped with a SIM containing default values except for those values listed in table [FFS].

Parameters changed from the default values in table 6.1.3.1 and table [FFS].Parameter	Unit	Cell 1	Cell 2	Cell 3	Cell 4	Cell 5
$\hat{I}_{or}/I_{oc}$	dB	2.5	4.5	7.5		
$CPICH\_Ec/I_o$	dB	-18	-16	-13	[FFS: High Q signal]	[FFS: Not high Q signal]
$CPICH\_RSCP$	dBm	-78	-76	-73		
$Q_{qualmin}$	dB	-20	-20	-20		
$Q_{rxlevmin}$	dBm	-100	-100	-100		
$S_{qual}$	dB	2	4	7		
$S_{rxlev}$	dBm	22	24	27		
$PLMN$		PLMN 1	PLMN 2	PLMN 3	PLMN 4	PLMN 5
<i>SIM field for storing PLMN</i>		EF <sub>IMSI</sub> (IMSI)	EF <sub>UPLMNsel</sub> (UPLMN selector)	EF <sub>OPLMNsel</sub> (OPLMN selector)	Other PLMN than on the SIM	Other PLMN than on the SIM

#### Test procedure

- The SS activates cells 1-4
- The UE is switched on.
- The SS waits until the selected PLMN is displayed
- The SS sends SYSTEM INFORMATION to the UE to inform it that PLMN 1 belongs to a “LA not allowed”
- Step c-d) is repeated except that in d) the UE is informed that PLMN 2 belongs to a “PLMN not allowed”
- Step c-d) is repeated except that in d) the UE is informed that PLMN 3 belongs to a “LA not allowed”
- Step c-d) is repeated except that in d) the UE is informed that PLMN 4 belongs to a “LA not allowed”
- Step c-d) is repeated except that in d) the UE is informed that PLMN 5 belongs to a “LA not allowed”
- The SS waits until “Emergency calls only” is shown

#### 6.1.1.3.5 Test Requirements

- In step c), the selected PLMN shall be displayed as PLMN 1 within 2 min.
- In step e), the selected PLMN shall be displayed as PLMN 2 within 2 min.
- In step f), the selected PLMN shall be displayed as PLMN 3 within 2 min.
- In step g), the selected PLMN shall be displayed as PLMN 4 within 2 min.
- In step h), the selected PLMN shall be displayed as PLMN 5 within 2 min.
- In step i), the UE shall say “Emergency calls only” within 2 min.

[Editor's note: The time 2 min is taken from the GSM 11.10-1, test case 26.3.4][Editor's note: It is assumed that the displayed PLMN reflects the cell camped on and that it is not necessary to test that the UE actually camps on that cell]

#### 6.1.1.4 UE will transmit only if PLMN available

##### 6.1.1.4.1 Definition

Test to verify that the UE will not produce any RF transmission if no PLMN is available.

##### 6.1.1.4.2 Conformance requirement

The UE shall monitor the DPCCCH quality in order to detect a loss of the signal on Layer 1, as specified in TS 25.214. The thresholds  $Q_{out}$  and  $Q_{in}$  specify at what DPCCCH quality levels the UE shall shut its power off and when it may turn its transmitter on respectively. The thresholds are not defined explicitly, but are defined by the conditions under which the UE shall shut its transmitter off and turn it on.

##### References

1. TS 25.101, 6.4.4 and TS 25.214, 4

##### 6.1.1.4.3 Test purpose

1. To verify that the UE does not give any "Service indication" when no PLMN is available
2. To verify that the UE will not produce any RF transmission when no PLMN is available

##### 6.1.1.4.4 Method of test

##### Initial conditions

Parameters changed from the default values in table 6.1.3.1 and table [FFS].

Parameter	Unit	Cell 1	Cell 2	Cell 3
$\hat{I}_{or}/I_{oc}$	dB	7.5	4.5	2.5
$CPICH\_Ec/I_o$	dB	-13	-16	-18
$CPICH\_RSCP$	dBm	-73	-76	-78
$Q_{qualmin}$	dB	-20	-20	-20
$Q_{rxlevmin}$	dBm	-100	-100	-100
$S_{qual}$	dB	7	4	2
$S_{rxlev}$	dBm	27	24	22

##### Test procedure

- a) The SS activates the cells 1-3 and monitors them for random access requests from the UE
- b) The UE is switched on.
- c) The SS waits for random access request from the UE
- d) Cells 1-3 are switched off
- e) The SS shall wait 20 sec. to allow the UE to detect the loss of cells  
[Editor's note: 20 sec. is taken from the equiv. GSM test case and must be confirmed]
- f) By MMI, an attempt to originate a call is made
- g) By MMI, an attempt to originate an emergency call is made (only if UE supports speech)

##### 6.1.1.4.5 Test Requirements

- 1) In step c), there shall be a response on cell 1 within 2 min.

2) In step f) and g), the UE shall not produce any RF output, neither give any “service indication”.

[Editor's note: 2 min. is taken from the equiv. GSM test case and must be confirmed]

## 6.1.2 Radio access mode selection and reselection

### 6.1.2.1 UE selects radio access mode (FDD/TDD) on request by the servicing network

Tests to verify that the UE selects the radio access mode requested by the servicing network.

FFS

## 6.1.3 Cell selection and reselection

### 6.1.3.1 Cell selection

#### 6.1.3.1.1 Definition

Test to verify that the UE is capable of selecting a cell that fulfils the “suitable” cell criteria. The test covers both Initial and Stored cell selection.

#### 6.1.3.1.2 Conformance requirement

1. Cell selection procedure to find a suitable cell to camp on:

1.1 Create a candidate list of potential cells to camp on, using:

1.1.1 Initial Cell Selection procedure; or

1.1.2 Stored Information Cell Selection procedure

1.2 For each cell on the candidate list, measure the quality value,  $Q_{\text{meas,LEV}}$

1.3 For each cell on the candidate list calculate the cell selection value,  $S_{\text{qual}}$  and  $S_{\text{rxlev}}$

1.4 Rank the cells and select the best cell

1.5 Select the cell that fulfils the criteria  $Q_{\text{map,n}} > Q_{\text{map,s}} + Q_{\text{offsets,n}}$  best. Check if the selected cell fulfils all requirements for a suitable cell. If so, choose this cell to camp on. If this cell does not fulfil all requirements for a suitable cell, this cell and all cells on the same frequency shall be removed as candidates for cell selection in case the barred cell does not accept intra-frequency cell selection and re-selection. On the other hand, in case the barred cell accepts intra-frequency cell selection and re-selection, only the barred cell shall be removed as candidate for cell selection, and step 1.4 shall be repeated for the remaining cells.

2. A suitable cell must fulfil all the following requirements.

2.1 The cell is part of the selected PLMN.

2.2 The cell is not barred [details are FFS].

2.3 The cell is not part of a forbidden registration area [details are FFS].

2.4 The cell selection criteria are fulfilled ( $S_{\text{qual}} > 0$  and  $S_{\text{rxlev}} > 0$ )

2.5 The SoLSA criteria are fulfilled [FFS].

2.6 The cell is not an operator-only cell, unless the UE has those access rights.

3. The UE shall be able to calculate correctly the cell selection criteria, Squal and Srxlev

## References

1. TS 25.304, 5.2.2.1.1
2. TS 25.304, 4.3
3. TS 25.304, 5.2.2.1.2

### 6.1.3.1.3 Test purpose

Test to verify that the UE selects the correct cell according to the requirements for cell selection:

1. To verify that the UE selects suitable cells in descending order of received signal strength  $Q_{\text{meas}}$  according to conformance requirement 1.
2. To verify that:
  - 1.1 The UE does not select a cell of a PLMN, which is not the selected PLMN.
  - 1.2 The UE does not select a cell, which is barred.
  - 1.3 The UE does not select a cell with  $S < 0$ .

The conformance requirement 2.3 (forbidden registration area), 2.5 (SolSA) and 2.6 (operator-only cell) is not covered by the test.

### 6.1.3.1.4 Method of test

#### Initial conditions

The relative RF signal to total interference ratio at the UE ( $CPICH\_Ec/I_o$ ) between the cells shall be:

Cell 1 (barred) > Cell 2 ( $S < 0$ ) > Cell 3 > Cell 4

Cell 1 must be on a different frequency than the other cells because it is barred (conformance requirement 1.4).

Parameters changed from the default values in table 6.1.3.1.

Parameter	Unit	Cell 1	Cell 2	Cell 3	Cell 4
<i>UTRA RF Channel Number</i>		UARFCN 1	UARFCN 2	UARFCN 2	UARFCN 2
$\hat{I}_{or}/I_{oc}$	dB	5.9	7.5	4.5	2.5
$CPICH\_Ec/I_o$	dB	-11	-13	-16	-18
$CPICH\_RSCP$	dBm	-74	-73	-76	-78
$Q_{qualmin}$	dB	-20	-5	-20	-20
$Q_{rxlevmin}$	dBm	-100	-100	-100	-100
<i>Squal</i>	dB	9	-8	4	2
<i>Srxlev</i>	dBm	26	27	24	22
<i>CellBarred</i>		1	0	0	0

#### Test procedure

- a) The SS activates the cells 1-4 and monitors cell 2, 3 and 4 for random access requests from the UE
- b) The UE is switched on.
- c) The SS waits for random access request from the UE

- d) The UE is switched off.
- e) The SS monitors cell 1, 2 and 3 for random access requests from the UE.
- f) The UE is switched on.
- g) The SS waits to see if there is any random access requests from the UE.
- h) The stored information cell selection list in the UE is deleted and the UE is switched off.
- i) Step a-g) is repeated except that Cell 1 is set to belong to a different PLMN instead of being barred.
- j) Step a-g) is repeated except that  $Q_{rxlevmin}$  is set to -70 instead of being barred.  $S_{rxlev}$  will be negative.

#### 6.1.3.1.5 Test requirements

- 1) In step c), the first response from the UE shall be on cell 3 within 33 seconds. There shall be no response from the UE on cell 2 (Initial cell selection).

[Editor's note: The 33 seconds is taken from GSM as there is no requirement in UMTS to the initial cell selection time. UMTS should not have worse performance than GSM]

- 2) In step g), there shall be no response from the UE on cell 1 or 2 within 33 seconds (Stored cell selection).

[Editor's note: The 33 seconds is taken from GSM as there is no requirement in UMTS to the stored cell selection time. UMTS should not have worse performance than GSM]

- 3) In i) the responses shall be as in previous test requirements 1) and 2).
- 4) In j) the responses shall be as in previous test requirements 1) and 2).

#### 6.1.3.2 Cell selection on release of DCCH and DTCH

FFS.

#### 6.1.3.3 Cell reselection

##### 6.1.3.3.1 Definition

Test to verify that the UE performs the cell reselection correctly for intra/inter-frequency cells if the serving cell becomes barred or  $S < 0$ .

##### 6.1.3.3.2 Conformance requirement

- 1. While camped on a cell of the selected PLMN ("camped normally"), the UE may need to select a different cell ("normal cell reselection" state). The following events trigger a cell reselection:

- 1.1 Time for cell re-selection evaluation

- 1.2 Cell selection criterion  $S$  is not fulfilled

- 1.3 Cell has become barred or forbidden

In case 1.2 and 1.3, the parameters  $Q_{hyst}$  and  $T_{reselection}$  shall not be considered in the criteria.

- 2. The UE shall perform a cell reselection if a non-serving cell is evaluated to be better than the serving cell. The best cell is the cell with the highest cell-ranking criterion  $R$  and ( $S_{qual} > 0$ ,  $S_{rxlev} > 0$ ). The UE shall reselect the new cell, if the cell reselection criteria are fulfilled during a time interval  $T_{reselection}$ .

3. Non-suitable cells ( $S_{qual} > 0$  or  $S_{rxlev} > 0$ ): If the best cell according to cell reselection criteria, does not fulfil all requirements for a suitable cell, that cell, together with all cells on that frequency shall be removed as candidate for cell re-selection.
4. Cell re-selection is correct if within  $N_t$  [FFS] seconds the UE re-selects a new cell, which fulfils the cell re-selection criteria and stays steady on that cell until the channel conditions are changed again.

## References

1. TS 25.304, 5.2.2.4.1
2. TS 25.304, 5.2.2.4.5
3. TS 25.304, 5.2.2.4.4
4. TS 25.133, 4.3.2.1.2

### 6.1.3.3.3 Test purpose

1. To verify that the UE meets conformance requirement 1.2 and 1.3
2. To verify that the UE meets conformance requirement 2
3. To verify that the UE meets conformance requirement 3

NOTE: Interfrequency cell reselection caused by a better cell being found (conformance requirement 1.1 and 4) is tested in TS 34.121, 8.2.3.2 Cell re-selection multi carrier multi cell case. Conformance requirement 4 applies also to the cell reselection criteria  $S < 0$ .

### 6.1.3.3.4 Method of test

#### Initial conditions

Treselection,  $Q_{hyst}$ ,  $Q_{offset}$ ,  $TEMP\_OFFSET$  and  $PENALTY\_TIME$  are not used, so the cell-ranking criterion  $R$  equals  $Q$ .

The relative RF signal to total interference ratio at the UE ( $CPICH\_Ec/I_o$ ) between the cells shall be:

Cell 1 > Cell 2 > Cell 3 > Cell 4

Cells 1 and 2 are on a different frequency than the other cells (Cell 1 will become barred and therefore both cells 1 and 2 removed from the candidate list)

Parameters changed from the default values in table 6.1.3.1.

Parameter	Unit	Cell 1	Cell 2	Cell 3	Cell 4
UTRA RF Channel Number		UARFCN 1	UARFCN 1	UARFCN 2	UARFCN 2
$\hat{I}_{or}/I_{oc}$	dBm	4.4	2.4	-5.3	-7.3
$CPICH\_Ec/I_o$	dB	-13	-15	-17	-19
$CPICH\_RSCP$	dBm	-76	-78	-85	-87
$Q_{qualmin}$	dB	-20	-20	-20	-20
$Q_{rxlevmin}$	dBm	-100	-100	-100	-100
$S_{qual}$	dB	7	5	3	1
$S_{rxlev}$	dBm	24	22	15	13

## Test procedure

- a) The SS activates cells 1, 2, 3 and 4. The SS monitors cells 1, 2 and 3 for random access requests from the UE.

- b) The UE is switched on.
- c) The SS waits for random access request from the UE
- d) The SS sets Cell 1 to be barred
- e) The SS waits for random access request from the UE
- f) The stored information cell selection list in the UE is deleted and the UE is switched off.
- g) Step a-e) is repeated except that in step d),  $Q_{qualmin}$  is increased to -10 dB, so S will become negative instead of the cell being barred while maintaining the same RF level.
- f) The stored information cell selection list in the UE is deleted and the UE is switched off.
- h) Step a-e) is repeated except that in step d), Cell 1 shall be on another PLMN while maintaining the same RF level.

#### 6.1.3.3.5 Test requirements

- 1) In step c), the UE shall respond on Cell 1 within 33 seconds

[Editor's note: The 33 seconds is taken from GSM as there is no requirement in UMTS to the initial cell selection time. UMTS should not have worse performance than GSM]

- 2) In step e), the UE shall respond on Cell 3 within 12 seconds

NOTE 1: 1280 msec. for DRX cycle + 1280 msec. for system info scheduling + 5 sec. actual reselection time + 1280 msec. for reading neighbour BCCH + 25%. Allow 12 sec.

- 3) The responses in step g) shall first be a response on Cell 1 and then a response on Cell 2.
- 4) The responses in step h) shall first be a response on Cell 1 and then a response on Cell 3.

#### 6.1.3.4 Cell reselection using reselection timing parameters

##### 6.1.3.4.1 Definition

Test to verify that the UE performs the cell reselection correctly if system information parameters  $Q_{offset}$ ,  $Q_{hyst}$ ,  $TEMP\_OFFSET$ ,  $PENALTY\_TIME$  and  $T_{reselection}$  are applied for non-hierarchical cell structures.

##### 6.1.3.4.2 Conformance requirement

- 1. While camped on a cell of the selected PLMN ("camped normally"), the UE may need to select a different cell ("normal cell reselection" state). The following events trigger a cell reselection:
  - 1.1 Time for cell re-selection evaluation
  - 1.2 Cell selection criterion S is not fulfilled
  - 1.3 Cell has become barred or forbiddenIn case 1.2 and 1.3, the parameters  $Q_{hyst}$  and  $T_{reselection}$  shall not be considered in the criteria.
- 2. The UE shall perform a cell reselection if a non-serving cell is evaluated to be better than the serving cell. The best cell is the cell with the highest cell-ranking criterion R and ( $S_{qual} > 0$ ,  $S_{rxlev} > 0$ ). The UE shall reselect the new cell, if the cell reselection criteria are fulfilled during a time interval  $T_{reselection}$ .
- 3. The cell-ranking criterion R is calculated using the  $Q_{offset}$ ,  $Q_{hyst}$ ,  $TEMP\_OFFSET$ ,  $PENALTY\_TIME$  and  $T_{reselection}$  parameters.



4. Cell re-selection is correct if within  $N_t$  [FFS] seconds the UE re-selects a new cell, which fulfils the cell re-selection criteria and stays steady on that cell until the channel conditions are changed again.

## References

1. TS 25.304, 5.2.2.4
2. TS 25.304, 5.2.2.4.5
3. TS 25.304, 5.2.2.4.5
4. TS 25.133, 4.3.2.1.2

### 6.1.3.4.3 Test purpose

1. To verify conformance requirement 1.1
2. To verify conformance requirement 2
3. To verify conformance requirement 3

NOTE: Interfrequency cell reselection caused by a better cell being found (conformance requirement 1.1 and 4) is tested in TS 34.121, 8.2.3.2 Cell re-selection multi carrier multi cell case. Conformance requirement 4 applies also to the cell reselection criteria  $S < 0$ .

### 6.1.3.4.4 Method of test

#### Initial conditions

Serving cell: T1: Cell 1, T2: Cell 2, T3: Cell 3

Parameters changed from the default values in table 6.1.3.1.

Parameter	Unit	Cell 1		Cell 2		Cell 3	Cell 4
		T1	T2	T1	T2	T3	T3
<i>UTRA RF Channel Number</i>	dB	UARFCN 1		UARFCN 1		UARF CN 2	UARF CN 2
$\hat{I}_{or}/I_{oc}$	dB	-3.71	0.06	-5.71	3.06	5.87	5.87
<i>CPICH<sub>E</sub>c/I<sub>o</sub></i>	dB	-16		-18	-13	-11	-11
<i>CPICH RSCP</i>	dBm	-84	-80	-86	-77	-74	-74
<i>Q<sub>qualmin</sub></i>	dB	-20		-20		-20	-20
<i>Q<sub>rxlevmin</sub></i>	dBm	-100		-100		-100	-100
<i>S<sub>qual</sub></i>	dB	4		2	7	9	9
<i>S<sub>rxlev</sub></i>	dBm	16	20	14	13	26	26
<i>Q<sub>hyst<sub>s</sub></sub></i>	dB	4		0			
<i>Treselection<sub>s</sub></i>	sec	10		10			
<i>PENALTY_TIME<sub>n</sub></i>	sec	-		-		40	60
<i>TEMP_OFFSET<sub>n</sub></i>	dB	-		-		5	5
<i>Qoffset<sub>s,n</sub></i>	dB	n=1,2,3,4: 0		n=3,4: 1			
<i>R<sub>s</sub></i>	dB	-12		-13			
<i>R<sub>n</sub></i>	dB	n=2: -18	n=2: -13	n=3,4: -17 to -12			

Note 1: The initial cell selection, after the UE has been switched on, is based on a comparison of the active cells' Q value, not R.

## Test procedure

- a) The SS activates cells 1 and 2 with T1 defined parameters. The UE is not paged on Cell 1. The SS monitors Cell 2 for random access requests from the UE.
- b) The UE is switched on.
- c) The SS waits to see if there is any random access request from the UE
- d) The SS increases the level of Cell 2 to -13 dB as described for T2.
- e) The SS waits for random access request from the UE
- f) The SS sets  $Q_{\text{hyst}}$  to 2 dB so  $R_s$  will be -14 dB
- g) The SS waits for random access request from the UE
- h) When the SS receives a response on Cell 2, the SS stops paging in that cell. The SS activates cells 3 and 4 as described for T3 and continuously pages the UE on these cells. The SS monitors cells 3 and 4 for random access requests from the MS.
- i) The SS waits for random access request from the UE

### 6.1.3.4.5 Test Requirements

- 1) In step c), there shall be no response from the UE on Cell 2 within 50 seconds

[Editor's note: The 50 seconds is taken from GSM as there is no requirement in UMTS to the initial cell selection time. UMTS should not have worse performance than GSM]

- 2) In step e), there shall be no response from the UE on Cell 2 within 50 seconds
- 3) In step g), the UE shall respond on Cell 2 within 20 seconds

NOTE 1: Actual reselection time of 5 sec. (due to changed RF conditions, conformance req. 4) + Treselection time of 10 sec. + 25%. Allow 20 sec.

- 4) In step i), there shall be no response from the UE on Cell 3 within 48 seconds of activating the cells but the UE shall respond on Cell 3 within 75 seconds The response on Cell 3 shall be before any response on Cell 4.

NOTE 2: Minimum time of 48 sec. set by  $\text{PENALTY\_TIME (cell 3) + Treselection time} - 2 \text{ sec. tolerance}$ .  
Maximum time of 75 sec. set by  $\text{PENALTY\_TIME (cell 3) + Treselection time} + 1280 \text{ msec. for DRX cycle} + 1280 \text{ msec. for system info scheduling} + 5 \text{ sec. actual reselection time} + 1280 \text{ msec. for reading neighbour BCCH} + 25\%$ .

### 6.1.3.5 Cell reselection if HCS is used

FFS.

### 6.1.3.6 Cell reselection due to UE rejection "LA not allowed"

#### 6.1.3.6.1 Definition

Test to verify that a UE camping on a cell which has a "Regionally restricted service" will select a different cell in order to fulfill the normal service state. This ensures that the UE is camped on a cell from which it can reliably decode downlink data and with which it has a high probability of communications on the uplink.

#### 6.1.3.6.2 Conformance requirement

1. In response to a registration attempt, when receiving an LU reject with cause value "LA not allowed", the UE stores this LAI in a list of "forbidden LAIs for regional provision of service", to prevent repeated attempts to access a cell of the forbidden LA. This list is deleted when the MS is switched off or the SIM is removed. If the MS cannot find a suitable cell, the MS performs the PLMN selection procedure.
2. When the MS is camped on a cell, the LA of which belongs to the list of forbidden LA for regional provision of service, the MS is not allowed to initiate establishment of a CM connection except for an emergency call; it may respond to paging.
3. There are a number of situations in which the MS is unable to obtain normal service from a PLMN. These include:
  - 3.1 Failure to find a suitable cell of the selected PLMN;
  - 3.2 No SIM in the MS;
  - 3.3 A "PLMN not allowed" response to an LR;
  - 3.4 An "illegal MS", "illegal ME" or "IMSI unknown in HLR" response to an LR; (Any SIM in the ME is then considered "invalid".)

Under any of these conditions, the MS attempts to camp on an acceptable cell, irrespective of its PLMN identity, so that emergency calls can be made if necessary. No LR requests are made until a valid SIM is present and either a suitable cell is found or a manual network reselection is performed.

4. The cell reselection procedure shall be triggered in the following cases:
  - 4.1 Time for cell re-selection evaluation;
  - 4.2 Cell selection criterion S is not fulfilled;
  - 4.3 Cell has become barred or forbidden.

In case 4.2 and 4.3, the parameters  $Q_{\text{hyst}}$  and  $T_{\text{reselction}}$  shall not be considered in the criteria.
5. Non-suitable cells ( $S_{\text{qual}} > 0$  or  $S_{\text{rxlev}} > 0$ ): If the best cell according to cell reselection criteria, does not fulfil all requirements for a suitable cell, that cell, together with all cells on that frequency shall be removed as candidate for cell re-selection.
6. A new LU attempt shall only be performed when a new LA (or new PLMN) is entered according to the cell reselection procedure.

#### References

1. TS 23.122, 3.2
2. TS 23.122, 3.4.2
3. TS 23.122, 3.5
4. TS 25.304, 5.2.2.4.1
5. TS 25.304, 5.2.2.4.4
6. TS 23.122, Table 2

#### 6.1.3.6.3 Test purpose

1. To verify that if an LU is rejected with cause "LA not allowed" that the LAI of that cell is written into a forbidden list which prevents the UE from performing LU onto another cell in that LA. This is verified indirectly in test purposes 2, 3 and 4.
2. To verify that cell reselection is triggered when the UE receives an LU reject with cause value "LA not allowed"

3. To verify that if no suitable cells exist, the UE will not reject a cell for camping on because that cell is part of a LA in the list of "forbidden LAIs for regional provision of service". This is verified indirectly by making the UE attempt an emergency call and checking that the RRC CONNECTION REQUEST is transmitted on the correct cell.
4. To verify that a new LU attempt will be performed when a new LA (or new PLMN) is entered.

#### 6.1.3.6.4 Method of test

##### Initial conditions

Treselection, Qhyst, TEMP\_OFFSET and PENALTY\_TIME are not used.

The relative RF signal to total interference ratio at the UE ( $CPICH_{Ec/I_0}$ ) between the cells shall be:

Cell 1 > Cell 2 > Cell 3

Parameters changed from the default values in table 6.1.3.1 and table [FFS].

Parameter	Unit	Cell 1	Cell 2	Cell 3
$\hat{I}_{or}/I_{oc}$	dB	7.5	4.5	2.5
$CPICH_{Ec/I_0}$	dB	-13	-16	-18
$CPICH_{RSCP}$	dBm	-73	-76	-78
$Q_{qualmin}$	dB	-20	-20	-20
$Q_{rxlevmin}$	dBm	-100	-100	-100
$S_{qual}$	dB	7	4	2
$S_{rxlev}$	dBm	27	24	22
$Q_{offset_{s,n}}$	dB		4	
$R_n = Q_n - Q_{offset_{s,n}}$	dB		-20	
$LAC$		H1111	H2222	H1111
$ATT$		1	1	1

##### Test procedure

- a) The SS activates cells 1 and 3. The SS monitors cells 1 and 3 for random access requests from the UE until step g) has been completed. Only idle-paging is sent on all channels.

[Editor's note: Idle paging in this case ?. The UE shall not be paged in any cell ]

- b) The UE is switched on.
- c) The SS waits for random access request from the UE
- d) When the UE performs an IMSI attach onto Cell 1 by sending a LOCATION UPDATING REQUEST, the SS shall reject it with cause "LA not allowed".
- e) 30 seconds after the UE has returned to idle mode (RRC CONNECTION RELEASE after LU reject), the UE is manually commanded to set up an emergency call.

[Editor's note: The 30 seconds is taken from GSM as there is no requirement in UMTS. UMTS should not have worse performance than GSM]

- f) The SS waits for RRC CONNECTION REQUEST from the UE
- g) The SS rejects the CM service request from the UE, with a CM service reject message with cause value #17 (Network Failure).

NOTE: Cause values #4 (IMSI unknown in VLR) or #6 (Illegal ME) lead to unwanted behaviour of the mobile.

- h) 10 seconds after the UE has returned to idle mode (channel release after CM service reject), the SS sets  $Q_{offset_{s,n}}$  of Cell 2 to 0 so  $R_n$  becomes  $-16$ .

[Editor's note: The 10 seconds is taken from GSM as there is no requirement in UMTS. UMTS should not have worse performance than GSM]

- i) The SS shall accept any LU on Cell 2.

#### 6.1.3.6.5 Test requirements

- 1) In step c), the UE shall respond on Cell 1 within 33 sec. of switch-on.

[Editor's note: The 33 seconds is taken from GSM as there is no requirement in UMTS to the initial cell selection time. UMTS should not have worse performance than GSM]

- 2) In step f), the UE shall access on Cell 3 within 15 seconds of being commanded to set up the emergency call.

[Editor's note: The 15 seconds is taken from GSM as there is no requirement in UMTS. UMTS should not have worse performance than GSM]

- 3) In step i), the UE shall reselect and access onto Cell 2 requesting an LU within 30 seconds after having activated Cell 2.

[Editor's note: The 30 seconds is taken from GSM as there is no requirement in UMTS. UMTS should not have worse performance than GSM]

### 6.1.3.7 Cell reselection due to UE rejection "Roaming not allowed in this LA"

#### 6.1.3.7.1 Definition

Test to verify that a UE camping on a cell and receiving a "Roaming not allowed in this LA" will select a different cell in order to fulfill the normal service state. This ensures that the UE is camped on a cell from which it can reliably decode downlink data and with which it has a high probability of communications on the uplink.

#### 6.1.3.7.2 Conformance requirement

1. To prevent repeated attempts to have roaming service on a not allowed LA, when the UE is informed that an LA is forbidden, the LA is added to a list of "forbidden LAs for roaming" which is stored in the UE.
2. If the LR response "Roaming not allowed in this LA" is received, the PLMN Automatic or Manual Mode Selection Procedure is followed, depending on whether the UE is in automatic or manual mode.
3. Cell selection procedure to find a suitable cell to camp on:
  - 3.1 Create a candidate list of potential cells to camp on, using:
    - 3.1.1 Initial Cell Selection procedure; or
    - 3.1.2 Stored Information Cell Selection procedure
  - 3.2 For each cell on the candidate list, measure the quality value,  $Q_{meas,LEV}$
  - 3.3 For each cell on the candidate list calculate the cell selection value,  $S_{qual}$  and  $S_{rxlev}$
  - 3.4 Rank the cells and select the best cell
  - 3.5 Select the cell that fulfils the criteria  $Q_{map,n} > Q_{map,s} + Q_{offsets,n}$  best. Check if the selected cell fulfils all requirements for a suitable cell. If so, choose this cell to camp on. If this cell does not fulfil all requirements for a suitable cell, this cell and all cells on the same frequency shall be removed as candidates for cell selection in case the barred cell does not accept intra-frequency cell selection and re-selection. On the other

hand, in case the barred cell accepts intra-frequency cell selection and re-selection, only the barred cell shall be removed as candidate for cell selection, and step 3.4 shall be repeated for the remaining cells.

4. A suitable cell must fulfil certain requirements, among those:
  - the cell is not part of a forbidden registration area [details are FFS].
5. A new LU attempt shall only be performed when a new LA (or new PLMN) is entered according to the cell reselection procedure.

## References

1. TS 23.122, 3.1
2. TS 23.122, 4.4.5 and 4.3.3 L3
3. TS 25.304, 5.2.2.1.1
4. TS 25.304, 4.3
5. TS 23.122, Table 2

### 6.1.3.7.3 Test purpose

1. To verify that if an LU is rejected with cause "Roaming not allowed in this LA" that the LAI of that cell is written into a forbidden list which prevents the UE from camping onto any cell in that LA.
2. To verify that if the UE has received the cause "Roaming not allowed in this LA", in response to a LU attempt, the Network Selection Procedure is initiated. This is verified indirectly by test purpose 3, in that the new LA is accessed as part of cell selection.
3. To verify that if an LU is rejected, when attempting LU in a LA with LAI = LAI1, with cause "Roaming not allowed in this LA" and only cells of the selected PLMN are available, the UE will only camp and attempt LU in any LA with LAI <> LAI1.
4. To verify that a new LU attempt will be performed when a new LA (or new PLMN) is entered.

### 6.1.3.7.4 Method of test

#### Initial conditions

The relative RF signal to total interference ratio at the UE ( $CPICH_{Ec/Io}$ ) between the cells shall be:

Cell 1 > Cell 2

[Editor's note: Do we need different carrier freq. for Cell 1 and 2 ? In the cell selection procedure, all cells on the same freq. as the non-suitable/rejected cell are removed. But in this case, the two cells belong to different LA, so is it still needed to have diff. freq. ?]

[Editor's note: Do both cells belong to the same PLMN ?]

Parameters changed from the default values in table 6.1.3.1 and table [FFS].

Parameter	Unit	Cell 1	Cell 2
$\hat{I}_{or}/I_{oc}$	dB	3.06	0.06
$CPICH_{Ec/Io}$	dB	-13	-16
$CPICH_{RSCP}$	dBm	-77	-80
$Q_{qualmin}$	dB	-20	-20
$Q_{rxlevmin}$	dBm	-100	-100
$S_{qual}$	dB	7	4
$S_{rxlevmin}$	dB	23	20
$MNC$		MNC <> HPLMN	MNC <> HPLMN
$MCC$		MCC of HPLMN	MCC of HPLMN
$LAC$		H1111	H2222
$ATT$		1	1

### Test procedure

- The SS activates cells 1 and 2 and monitors both cells for random access requests from the UE. Only Idle paging is sent on all channels.
- [Editor's note: Idle paging in this case ? The UE shall not be paged in any cell]**
- The UE is switched on.
- The SS waits for random access request from the UE
- When the UE performs an IMSI attach onto Cell 1 by sending a LOCATION UPDATING REQUEST, the SS shall reject it with cause "Roaming not allowed in this LA".
- The SS waits for random access request from the UE
- The SS shall accept any LU on Cell 2.
- The SS waits to see if there is any random access requests from the UE

#### 6.1.3.7.5 Test requirements

- In step c), the UE shall respond on Cell 1 within 33 sec. of switch-on.  
**[Editor's note: The 33 seconds is taken from GSM as there is no requirement in UMTS to the initial cell selection time. UMTS should not have worse performance than GSM]**
- In step e), the UE shall initiate the Network Selection Procedure and access onto Cell 2 as part of cell selection within 33 sec. from returning to idle mode after the LU reject.  
**[Editor's note: The 33 seconds is taken from GSM as there is no requirement in UMTS. UMTS should not have worse performance than GSM]**
- In step g), there shall be no response from the UE within [TBD] sec.

### 6.1.3.8 Emergency calls

#### 6.1.3.8.1 Definition

Test to verify that the UE shall be able to initiate emergency calls when no suitable cells of the selected PLMN are available, but at least one acceptable cell is available.

#### 6.1.3.8.2 Conformance requirement

1. When in a limited service state, the UE shall be able to initiate emergency calls.
2. Select the cell that fulfils the  $Q_{\text{map},n} > Q_{\text{map},s} + Q_{\text{offsets},n}$  best. Check if the selected cell fulfils all requirements for a suitable cell. If so, choose this cell to camp on. If this cell does not fulfil all requirements for a suitable cell, this cell and all cells on the same frequency shall be removed as candidates for cell selection in case the barred cell does not accept intra-frequency cell selection and re-selection. On the other hand, in case the barred cell accepts intra-frequency cell selection and re-selection, only the barred cell shall be removed as candidate for cell selection, and the procedure shall be repeated for the remaining cells. The same applies in cell reselection.
3. If the UE is unable to find any suitable cell of selected PLMN using the Initial cell selection procedure, it shall attempt to camp on highest ranked acceptable cell and enter the Camped on any cell state, where it can only obtain limited service.
4. The UE shall perform a cell reselection if a non-serving cell is evaluated to be better than the serving cell. The best cell is the cell with the highest cell-ranking criterion R and ( $S_{\text{qual}} > 0$ ,  $S_{\text{rxlev}} > 0$ ). The UE shall reselect the new cell, if the cell reselection criteria are fulfilled during a time interval  $T_{\text{reselction}}$ .
5. If no suitable cell is found, the UE shall attempt to find an acceptable cell of any PLMN, state *Any cell selection*. This state is also entered if a non-access stratum registration procedure is rejected, or if there is no USIM in the UE. If an acceptable cell is found, the UE shall camp on this cell and obtain limited service, state *Camped on any cell*. In this state, the UE shall behave as specified for state *Camped normally*, but typically with a different PLMN. Additionally, the UE shall regularly attempt to find a suitable cell using stored information, trying all radio access technologies that are supported by the UE. If a suitable cell is found, the PLMN is reselected.

When a cell reselection is triggered, the UE shall evaluate the cell reselection criteria based on radio measurements, and if a better cell is found that cell is selected, procedure *Any cell reselection*. The change of cell may imply a change of radio access technology.

#### References

1. TS 25.304, 4.3
2. TS 25.304, 5.2.2.1.1 and 5.2.2.4.4
3. TS 25.304, 5.2.2.1.1
4. TS 25.304, 5.2.2.4.5
5. TS 25.304, 5.2.1

#### 6.1.3.8.3 Test purpose

1. To verify that the UE shall be able to initiate emergency calls when no suitable cells of the selected PLMN are available, but at least one acceptable cell is available.
2. To verify that the UE selects a cell with  $S > 0$  (acceptable cell) and  $\text{CellBarred} = 0$  when no suitable cells of the selected PLMN are available.
3. To verify that the UE ranks the cells according to the cell-ranking criterion R which in this test case equals Q as  $Q_{\text{hyst}}$ ,  $Q_{\text{offset}}$ ,  $\text{TEMP\_OFFSET}$  and  $\text{PENALTY\_TIME}$  parameters are not used. Treselection is not used either.

#### 6.1.3.8.4 Method of test

##### Initial conditions

The relative RF signal to total interference ratio at the UE ( $CPICH\_Ec/I_o$ ) between the cells shall be:

Cell 2 ( $S < 0$ ) > Cell 1 (barred) > Cell 3

Parameters changed from Default values table 6.1.3.1.



Parameter	Unit	Cell 1	Cell 2	Cell 3
$\hat{I}_{or}/I_{oc}$	dB	4.5	7.5	2.5
<i>CPICH_Ec/Io</i>	dB	-16	-13	-18
<i>CPICH_RSCP</i>	dBm	-76	-73	-78
<i>Qqualmin</i>	dB	-20	-10	-20
<i>Qrxlevmin</i>	dBm	-100	-100	-100
<i>Squal</i>	dB	4	-3	2
<i>Srxlev</i>	dBm	24	27	22
<i>CellBarred</i>		1	0	0
<i>PLMN</i>		forbidden	forbidden	forbidden

NOTE: All the BCCH cells belong to the same PLMN, which is not the UE's home PLMN and is in the SIM's forbidden PLMN's list.

[Editor's note: PLMN must be replaced with MNC, MCC values]

#### Test procedure

- The SS activates the cells. The SS monitors for RA attempts from the UE on cells 1, 2 and 3 for the duration of the test.
- The UE is switched on.
- 50 seconds after switch on, an emergency call is initiated on the UE.
- The SS waits for random access request from the UE.
- The SS changes the CellBarred of Cell 1 to 0.
- After 12 seconds an emergency call is initiated on the UE.

NOTE: 1280 msec. for DRX cycle + 1280 msec. for system info scheduling + 5 sec. actual reselection time + 1280 msec. for reading neighbour BCCH + 25%. Allow 12 sec.

- The SS waits for random access request from the UE.

#### 6.1.3.8.5 Test requirements

- In step d), the first access from the UE shall be on Cell 3.
- In step g), the first access from the UE shall be on Cell 1.

#### 6.1.3.9 Immediate cell evaluation

##### 6.1.3.9.1 Definition

Test to verify that the UE performs the Immediate cell evaluation procedure correctly and selects the best cell among the cells on the same frequency.

##### 6.1.3.9.2 Conformance requirement

- When UE leaves idle mode, state *Camped normally*, in order to enter connected mode, state *Connected mode*, the UE shall use the *Immediate cell evaluation* procedure (UTRA only) in order to select the best cell on the current frequency for the access attempt. This procedure allows the UE to reduce power consumption spent on radio measurements, still enabling the UE to select the best cell for access, thus minimising the interference in the system. If no suitable cell is found, the UE shall use the *Cell reselection* procedure.
- The immediate cell evaluation shall be triggered prior to RACH transmission.

3. The transition to the UTRAN Connected Mode from the Idle Mode can only be initiated by the UE by transmitting a request for an RRC Connection. The event is triggered either by a paging request from the network or by a request from upper layers in the UE. When the UE receives a message from the network that confirms the RRC connection establishment, the UE enters the CELL\_FACH or CELL\_DCH state of UTRAN Connected Mode.
4. The following steps shall be carried out when an immediate cell evaluation has been triggered:
  - 4.1 The candidate list of potential cells to camp on consists of the cells in the current registration area listed for intra-frequency measurements in system information of the serving cell.
  - 4.2 For each cell on the candidate list, measure the quality value,  $Q_{\text{meas,LEV}}$
  - 4.3 For each cell on the candidate list calculate the cell selection values,  $S_{\text{qual}}$  and  $S_{\text{rxlev}}$
  - 4.4 Rank the cells and select the best cell
  - 4.5 Select the neighbouring cell that fulfils the  $Q_{\text{map,n}} > Q_{\text{map,s}} + Q_{\text{offset,s,n}}$  criteria best.  
If the best cell does not fulfil all other requirements for a suitable cell, UE shall trigger cell re-selection
5. If more than one neighbouring cell fulfils the criteria, the UE shall choose the cell where the difference between  $Q_{\text{map,n}}$  and  $(Q_{\text{map,s}} + Q_{\text{offset}})$  is highest. If no neighbouring cell fulfils the criteria, the UE shall keep the serving cell.

## References

1. TS 25.304, 5.2.1
2. TS 25.304, 5.2.2.2.1
3. TS 25.331, 9.2
4. TS 25.304, 5.2.2.2.1
5. TS 25.304, 5.2.2.2.2

### 6.1.3.9.3 Test purpose

To verify that

1. The UE meets conformance requirement 1.
2. The UE meets conformance requirement 4
3. The UE meets conformance requirement 5

### 6.1.3.9.4 Method of test

#### Initial conditions

The  $Q_s + Q_{\text{offset,s,n}}$  difference between the cells shall be:

T1: Cell 4 (other freq.) > Cell 1 > Cell 2 > Cell 3

T2: Cell 4 (other freq.) > Cell 2 > Cell 1 > Cell 3

Offset parameters are applied to the cell-ranking criterion R to ensure normal cell reselection is not triggered but instead cell evaluation.

Parameters changed from the default values in table 6.1.3.1.

Parameter	Unit	Cell 1	Cell 2		Cell 3		Cell 4
			T1	T2	T1	T2	
<i>UTRA RF Channel Number</i>		UARFCN 1	UARFCN 1		UARFCN 1		UARFCN 2
$\hat{I}_{or}/I_{oc}$	dBm	7.5	4.5		2.5		5.87
<i>CPICH_Ec/Io</i>	dB	-13	-16		-18		-11
<i>CPICH_RSCP</i>	dBm	-73	-76		-78		-74
<i>Qqualmin</i>	dB	-20	-20		-20		-20
<i>Qrxlevmin</i>	dBm	-100	-100		-100		-100
<i>Squal</i>	dB	7	4		2		9
<i>Srxlev</i>	dBm	27	24		22		26
<i>Qhyst<sub>s</sub></i>	dB	20	20		20		20
<i>Treselection<sub>s</sub></i>	sec	-	-		-		-
<i>PENALTY_TIME<sub>n</sub></i>	sec	-	-		-		-
<i>TEMP_OFFSET<sub>n</sub></i>	dB	20	20		20		20
<i>CellBarred</i>		0	0		0		0
<i>n</i>		n=2,3:	n=1,3:		n=1,2:		n=1,2,3:
<i>Qoffset<sub>s,n</sub></i>	dB	0	0	4	0	4	0
<i>Q<sub>s</sub> + Qoffset<sub>s,n</sub></i>	dB	-13	-16	-12	-18	-14	-11

### Test procedure

- The SS activates cell 1-4 according to T1. The SS monitors cells 1, 2 and 3 for random access requests from the UE.
- The UE is switched on.
- The SS waits for random access request from the UE
- The parameters are changed as described for T2
- A call is initiated on the UE
- The UE transmits an RRC CONNECTION REQ and the SS sends a RRC CONNECTION CNF.
- The SS waits for random access request from the UE

[Editor's note: How do we ensure that the cell is found is Immediate Cell Evaluation and not during Connected Mode ?]

#### 6.1.3.9.5 Test Requirements

- In step c), the UE shall respond on Cell 1 within 33 seconds (Initial cell selection in Idle mode)

[Editor's note: The 33 seconds is taken from GSM as there is no requirement in UMTS to the initial cell selection time. UMTS should not have worse performance than GSM]

- In step g), the UE shall respond on Cell 2 within [TBD] seconds (Immediate Cell Evaluation)

#### 6.1.3.10 Reading SIB prior to RACH transmission

FFS.

## 6.1.4 Location registration

UE location registration capabilities are tested under clause 9.4 ..

## 6.2 Multi-mode environment (2G/3G case)

### 6.2.1 PLMN selection and reselection

### 6.2.2 Cell selection and reselection

#### 6.2.2.1 Cell selection; UTRAN / GSM

##### 6.2.2.1.1 Definition

Test to verify that the UE performs cell selection correctly when both a GSM and UTRA network is available.

##### 6.2.2.1.2 Conformance requirement

1. Cell selection procedure to find a suitable cell to camp on:
  - 1.1 Create a candidate list of potential cells to camp on, using:
    - 1.1.1 Initial Cell Selection procedure; or
    - 1.1.2 Stored Information Cell Selection procedure
  - 1.2 For each cell on the candidate list, measure the quality value,  $Q_{\text{meas,LEV}}$
  - 1.3 For each cell on the candidate list calculate the cell selection value,  $S_{\text{qual}}$  and  $S_{\text{rxlev}}$
  - 1.4 Rank the cells and select the best cell
  - 1.5 Select the cell that fulfils the criteria  $Q_{\text{map},n} > Q_{\text{map},s} + Q_{\text{offsets},n}$  best. Check if the selected cell fulfils all requirements for a suitable cell. If so, choose this cell to camp on. If this cell does not fulfil all requirements for a suitable cell, this cell and all cells on the same frequency shall be removed as candidates for cell selection in case the barred cell does not accept intra-frequency cell selection and re-selection. On the other hand, in case the barred cell accepts intra-frequency cell selection and re-selection, only the barred cell shall be removed as candidate for cell selection, and step 1.4 shall be repeated for the remaining cells.
2. Different types of measurements are used in different radio access technologies and modes for the cell selection and reselection (CPICH Ec/N0 or CPICH SIR in UTRA FDD, P-CCPCH RSCP in UTRA TDD, RXLEV in GSM). Whenever a direct comparison of these measurements is required, mapping functions shall be applied. Mapping functions are used for mapping a certain range of measurement values  $Q_{\text{meas\_LEV}}$  (CPICH\_EC/N0, CPICH\_RSCP\_LEV, P-CCPCH\_RSCP\_LEV, RXLEV) to a representing quality value  $Q_{\text{map}}$  (0..99, step size 1).
3. In the *Initial cell selection* procedure, the UE shall select one radio access technology and search for a suitable cell. If no suitable cell is found, the UE shall select another radio access technology and search for a suitable cell, and so on. In the *Stored information cell selection* procedure, the UE may use stored information about the selected PLMN. The information may contain information from several radio access technologies.

## References

1. TS 25.304, 5.2.2.1.1
2. TS 25.304, 7.1
3. TS 25.304, 5.2.1

## 6.2.2.1.3 Test purpose

To verify that

1. The UE meets conformance requirement 1.
2. The UE meets conformance requirement 2
3. The UE meets conformance requirement 3

## 6.2.2.1.4 Method of test

## Initial conditions

The relative RF signal to total interference ratio at the UE ( $CPICH_{Ec}/I_o$ ) between the cells shall be:

T1: Cell 1 < Cell 2 < Cell 3 < Cell 4 < Cell 5 < Cell 6

T2: Cell 1 > Cell 2 > Cell 3 > Cell 4 > Cell 5 > Cell 6

Cell 2 and 5 have  $S < 0$ , Cell 3 and 6 are barred.

Parameters changed from the default values in table 6.1.3.1. Parameter	Unit	Cell 1 (UTRAN)		Cell 2 (UTRAN)		Cell 3 (UTRAN)	
		T1	T2	T1	T2	T1	T2
Channel Number		UARFCN 1		UARFCN 1		UARFCN 2	
$\hat{I}_{or}/I_{oc}$	dBm	-5.71	3.06	-3.71	0.06	0.02	-7.25
$CPICH_{Ec}/I_o$	dB	-18	-13	-16	-16	-13	-18
$CPICH_{RSCP}$	dBm	-86	-77	-84	-80	-80	-87
$Q_{qualmin}$	dB	-20		-10			
$Q_{rxlevmin}$	dBm	-100		-100		-100	
$S_{qual}$	dB	2	7	-6	-6	7	2
$S_{rxlev}$	dBm	14	23	16	20	20	13
CellBarred		0		0		1	

Parameter	Unit	Cell 4 (GSM)		Cell 5 (GSM)		Cell 6 (GSM)	
		T1	T2	T1	T2	T1	T2
Channel Number		ARFCN 1		ARFCN 2		ARFCN 3	
RF Signal Level	dBm	-70	-95	-60	-100	-50	-105
$RXLEV_{ACCESS\_MIN}$	dBm	-100		-50		-110	
C1	dBm	30	5	-10	-50	60	5
CellBarred		0		0		1	

## Test procedure

- a) The SS activates the cells 1-6 according to T1 and monitors cell 1, 2 and 3 for random access request from the UE
- b) The UE is switched on.

- c) The SS waits for random access request from the UE
- d) The UE is switched off.
- e) The SS monitors cells 4, 5 and 6 for random access requests from the UE.
- f) The UE is switched on.
- g) The SS waits to see if there is any random access request from the UE.
- h) The stored information cell selection list in the UE is deleted and the UE is switched off.
- i) Step a-g) is repeated except that the cells are set according to T2 and Cell 1 is set to another PLMN

#### 6.2.2.1.5 Test Requirements

- 1) In step c), the first response from the UE shall be on Cell 1 within 33 seconds. (Initial cell selection)  
[Editor's note: The 33 seconds is taken from GSM as there is no requirement in UMTS to the initial cell selection time. UMTS should not have worse performance than GSM]
- 2) In step g), there shall be no response from the UE on either Cell 4, 5 or 6 within 33 seconds. (Stored Information cell selection)  
[Editor's note: The 33 seconds is taken from GSM as there is no requirement in UMTS to the stored cell selection time. UMTS should not have worse performance than GSM]
- 3) In step i), the first response from the UE shall be on Cell 4. (Initial cell selection) and no other responses

### 6.2.2.2 Cell reselection; UTRAN to GSM

#### 6.2.2.2.1 Definition

Test to verify that the UE performs cell reselection correctly when both a GSM and UTRAN network is available and if the serving cell becomes barred or  $S < 0$ .

#### 6.2.2.2.2 Conformance requirement

- 1. While camped on a cell of the selected PLMN ("camped normally"), the UE may need to select a different cell ("normal cell reselection" state). The following events trigger a cell reselection:
  - 1.1 Time for cell re-selection evaluation
  - 1.2 Cell selection criterion S is not fulfilled
  - 1.3 Cell has become barred or forbiddenIn case 1.2 and 1.3 the parameters  $Q_{hyst}$  and  $T_{reselection}$  shall not be considered in the criteria.
- 2. The UE shall perform a cell reselection if a non-serving cell is evaluated to be better than the serving cell. The best cell is the cell with the highest cell-ranking criterion R and ( $S_{qual} > 0$ ,  $S_{rxlev} > 0$ ). The UE shall reselect the new cell, if the cell reselection criteria are fulfilled during a time interval  $T_{reselection}$ .
- 3. Non-suitable cells ( $S_{qual} > 0$  or  $S_{rxlev} > 0$ ): If the best cell according to cell reselection criteria, does not fulfil all requirements for a suitable cell, that cell, together with all cells on that frequency shall be removed as candidate for cell re-selection.
- 4. Different types of measurements are used in different radio access technologies and modes for the cell selection and reselection (CPICH  $E_c/N_0$  or CPICH SIR in UTRA FDD, P-CCPCH RSCP in UTRA TDD, RXLEV in GSM). Whenever a direct comparison of these measurements is required, mapping functions shall be applied.

Mapping functions are used for mapping a certain range of measurement values  $Q_{\text{meas\_LEV}}$  ( $CPICH\_EC/N0$ ,  $CPICH\_RSCP\_LEV$ ,  $P\text{-}CCPCH\_RSCP\_LEV$ ,  $RXLEV$ ) to a representing quality value  $Q_{\text{map}}$  (0..99, step size 1).

## References

1. TS 25.304, 5.2.2.4.1
2. TS 25.304, 5.2.2.4.5
3. TS 25.304, 5.2.2.4.4.
4. TS 25.304, 7.1

### 6.1.2.2.3 Test purpose

1. To verify that the UE meets conformance requirement 1.2 and 1.4
2. To verify that the UE meets conformance requirement 2
3. To verify that the UE meets conformance requirement 3

NOTE: Cell reselection caused by a better cell being found (conformance requirement 2.1) is tested in TS 34.121, 8.2.3.3 Cell re-selection UTRAN to GSM.

### 6.2.2.2.4 Method of test

#### Initial conditions

Treselection,  $Q_{\text{hyst}}$ ,  $Q_{\text{offset}}$ ,  $TEMP\_OFFSET$  and  $PENALTY\_TIME$  are not used, so the cell-ranking criterion  $R$  equals  $Q$ .

The relative RF signal to total interference ratio at the UE ( $CPICH\_Ec/I_o$ ) between the cells shall be:

Cell 1 (UTRAN) > Cell 2 (GSM) > Cell 3 (GSM)

Parameters changed from the default values in table 6.1.3.1.

Parameter	Unit	Cell 1 (UTRAN)
<i>Channel Number</i>		UARFCN 1
$\hat{I}_{or}/I_{oc}$	dBm	5.87
<i>CPICH_Ec/I_o</i>	dB	-11
<i>CPICH RSCP</i>	dBm	-74
<i>Qqualmin</i>	dB	-20
<i>Qrxlevmin</i>	dBm	-100
<i>Squal</i>	dB	9
<i>Srxlev</i>	dBm	26

Parameter	Unit	Cell 2 (GSM)	Cell 3 (GSM)
<i>Channel Number</i>		ARFCN 1	ARFCN 2
<i>RF Signal Level</i>	dBm	-80	-90
<i>RXLEV_ACCESS_MIN</i>	dBm	-100	-100
<i>C1</i>	dBm	20	10

## Test procedure

- a) The SS activates cells 1, 2, and 3. The SS monitors cells 1, 2 and 3 for random access requests from the UE.
- b) The UE is switched on.
- c) The SS waits for random access request from the UE
- d) The SS sets Cell 1 to be barred
- e) The SS waits for random access request from the UE
- f) The stored information cell selection list in the UE is deleted and the UE is switched off.
- g) Step a-e) is repeated except that in step d), Qqualmin is increased to -5 dB, so S will become negative instead of being barred
- h) The stored information cell selection list in the UE is deleted and the UE is switched off.
- i) Step a-e) is repeated except that in step d), Cell 1 shall be on another PLMN while maintaining the same RF level.

### 6.2.2.2.5 Test Requirements

- 1) In step c), the UE shall respond on Cell 1 within 33 seconds

[Editor's note: The 33 seconds is taken from GSM as there is no requirement in UMTS to the initial cell selection time. UMTS should not have worse performance than GSM]

- 2) In step e), the UE shall respond on Cell 2 within 12 seconds.

NOTE: 1280 msec. for DRX cycle + 1280 msec. for system info scheduling + 5 sec. actual reselection time + 1280 msec. for reading neighbour BCCH + 25%. Allow 12 sec.

- 3) The responses in step g) shall first be a response on Cell 1 and then a response on Cell 2.
- 4) The responses in step i) shall first be a response on Cell 1 and then a response on Cell 2.

### 6.2.2.3 Cell reselection timings; GSM to UTRAN

#### 6.2.2.3.1 Definition

Test to verify that the UE meets the cell reselection timing requirements when both a GSM and UTRAN network is available.

#### 6.2.2.3.2 Conformance requirement

1. If the broadcast neighbour cell list includes UTRAN cells or UTRAN frequencies (with or without scrambling code group information), the UE shall, at least every 5 seconds update the value RLA\_C for the serving cell and each of the at least 6 strongest non serving GSM cells.
  - 1.1 The UE shall then reselect a suitable UTRAN cell if its measured RSCP value exceeds the value of RLA\_C for the serving cell and all of the suitable non-serving GSM cells by the value XXX\_Qoffset for a period of 5 seconds and, for FDD, the UTRAN cells measured Ec/No value is equal or greater than the value FDD\_Qmin.
    - Ec/No and RSCP are the measured quantities
    - FDD\_Qmin and XXX\_Qoffset are broadcast on BCCH of the serving cell. XXX indicates other radio access technology/mode.
  - 1.2 In case of a cell reselection occurring within the previous 15 seconds, XXX\_Qoffset is increased by 5 dB.



1.3 Cell reselection to UTRAN shall not occur within 5 seconds after the UE has reselected a GSM from an UTRAN cell if a suitable GSM cell can be found.

1.4 If more than one UTRAN cell fulfils the above criteria, the UE shall select the cell with the greatest  $Q_{meas}$  value.

2. The UE shall be able to identify and select a new best UTRAN cell, which is part of the neighbour cell list, within 30 seconds after it has been activated under the condition that there is only one UTRAN frequency in the neighbour cell list. The allowed time is increased by 30 seconds for each additional UTRAN frequency in the neighbour cell list. However, multiple UTRAN cells on the same frequency in the neighbour cell list does not increase the allowed time.

NOTE: Definitions of measurements are in 3G TS 25.215 and 3G TS 25.101, 3.2 and GSM 05.08, 6.1.

## References

1. GSM TS 05.08, 6.6.4
2. GSM TS 05.08, 6.6

### 6.1.2.3.3 Test purpose

1. To verify that
  - 1.1 The UE meets conformance requirement 1.1 and additionally, that no reselection is performed if the period is less than 5 sec.
  - 1.2 The UE meets conformance requirement 1.2
  - 1.3 The UE meets conformance requirement 1.3

### 6.2.2.3.4 Method of test

#### Initial conditions

Parameter	Unit	Cell 1 (GSM)
<i>Absolute RF Channel Number</i>		ARFCN 1
<i>RF Signal Level</i>	dBm	-75
<i>RXLEV_ACCESS_MIN</i>	dBm	-100
<i>MS_TXPWR_MAX_CCH</i>	dBm	Max. output power of MS
<i>FDD_Qmin</i>	dBm	-20
<i>XXX_Qoffset</i>	dBm	5

Parameters changed from the default values in table 6.1.3.1.

Parameter	Unit	Cell 2 (UTRAN)
<i>UTRA RF Channel Number</i>		UARFCN 1
$\hat{I}_{or}/I_{oc}$	dB	-4.74
<i>CPICH_Ec/I<sub>o</sub></i>	dB	-16
<i>CPICH_RSCP</i>	dBm	-85
<i>Q<sub>qualmin</sub></i>	dB	-20
<i>Q<sub>rxlevmin</sub></i>	dBm	-100
<i>S<sub>qual</sub></i>	dB	4
<i>S<sub>rxlevmin</sub></i>	dBm	15

### Test procedure

NOTE: Step a-c): Test purpose 1.3. Step d-g): test purpose 1.1. Step h-k): test purpose 1.2

- The SS activates the channels. The UE is not paged on any of the cells.
- The UE is switched on.
- After 50 seconds, the SS starts paging continuously on cells 1 and 2 for 20 seconds. The SS monitors cells 1 and 2 for random access requests from the UE.
- The SS stops paging on cells 1 and 2 and waits for 20 seconds. (The UE should revert to Cell 1 due to cell reselection).
- The SS starts paging continuously on Cell 2.
- The SS decreases the transmit level of Cell 1 to -95dBm for a period of 4 s (RSCP will then exceed RXLEV by more than XXX\_Qoffset) and then changes the level back to the original value.
- The UE waits to see if there is any random access requests from the UE on Cell 2
- The SS decreases the transmit level of Cell 1 to -95dBm and waits for the UE to access on Cell 2. The SS records the time t from the decrease in the level of Cell 1 to the first response from the UE.
- The SS stops paging on Cell 2 and changes the transmit level of Cell 1 back to the original value.
- The SS waits 20 seconds. (The UE should revert to Cell 1 due to cell reselection).
- The SS decreases the transmit level of Cell 1 to -95dBm. After t+2 seconds, the SS starts paging continuously on Cell 1, changes the level of Cell 1 back to the original level and waits to see if there is any random access request on Cell 1.

#### 6.2.2.3.5 Test Requirements

- In step c), the UE shall transmit 2 random access requests on Cell 1 followed by 2 random access requests on Cell 2. Subsequent random access requests on Cell 1 shall not occur within 4,5 sec of the second random access request on Cell 1.
- In step g), there shall be no access on Cell 2 within 34 seconds of decreasing the level of Cell 1.
- In step h), the UE shall respond on Cell 2.
- In step k), there shall be no response on Cell 1 within 11 seconds after the level of Cell 1 is changed back to the original level.

NOTE: The 11 seconds is derived from (t+15) seconds minimum cell reselection timer minus (t+2) seconds from the start of step k) up to the increase of the level of Cell 1. A further 2 seconds are subtracted to cover for any uncertainty introduced by the random access process occurring after step g).

## 6.2.3 Location registration

[FFS]

---

## 7 Layer 2

### 7.1 MAC

#### General

If not otherwise mentioned, the same procedures as used in RRC test specification (TS 34.123-1) or in the Generic procedure (TS 34.108) applies to reach Initial conditions for MAC testing.

If not explicitly described, the same message contents and settings are applied as described in the RRC test description default settings.

#### 7.1.1 Permission to access the network

This is a placeholder.

7.1.1.1 Void

7.1.1.2 Definition and applicability

Yet to be standardised, but expected to include all UE.

7.1.1.3 Conformance requirement

TBD

#### Reference(s)

TBD

7.1.1.4 Test purpose

If the Broadcast channel carries access information (e.g. access class), this subclause will carry tests to ensure that an UE will not try and access the network if its access class is not appropriate.

7.1.1.5 Method of test

#### Initial conditions

The UE shall be attached to the network and in idle mode.

#### Related ICS/IXIT Statement(s)

TBD

#### Test procedure

This subclause details the test procedure.

7.1.1.6 Test requirements

This subclause details the conditions to be met for successful completion of the test.

## 7.1.2 RACH/FACH procedures

### 7.1.2.1 Selection and control of Power Level

#### 7.1.2.1.1 Definition and applicability

All UE.

#### 7.1.2.1.2 Conformance requirement

1. The UE sets the preamble transmit power to the value  $P_{\text{RACH}}$  given in subclause 5.1.1 of 25.214.
2. If the UE does not detect the positive or negative acquisition indicator corresponding to the selected signature in the downlink access slot corresponding to the selected uplink access slot, the UE increases the preamble transmission power with the specified offset  $\Delta P_0$ .

#### Reference(s)

TS 25.214 clause 6.

TS 25.321 subclause 11.2.

#### 7.1.2.1.3 Test purpose

To verify that the UE selects the correct preamble transmit power according to the value of  $I_{\text{BTS}}$  transmitted in layer 3 messages on the BCH, and that:

- if the RACH access is not responded to, the power is stepped according to the power step  $\Delta P_0$ .
- if the RACH access is negatively acknowledged, the power is stepped according to the power step  $\Delta P_1$ .

#### 7.1.2.1.4 Method of test

##### Initial conditions

The UE is attached to the network and in idle mode.

##### Related ICS/IXIT Statement(s)

TBD

##### Foreseen Final State of the UE

The same as the initial conditions.

##### Test procedure

- a) The SS pages the UE until it performs a RACH access.
- b) The SS measures the power level of the RACH access.
- c) The SS does not acknowledge the RACH access, causing the UE to retry.
- d) The SS again measures the power level of the RACH access.
- e) The SS repeats the procedure from step c) until the maximum number of retries  $N_{\text{RA}}$  have been attempted, and monitors the RACH channel until  $T_{\text{xx}} + X_s$  to ensure that no further RACH accesses occur.
- f) The SS pages the UE until it performs a RACH access.

- g) The SS responds with a negative acquisition indicator on the AICH.
- h) The SS measures the power level of the next RACH access.
- i) The SS repeats steps g) and h) until the maximum number of retries  $N_{RA}$  have been attempted.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	←		PAGE	
2	→		CHANNEL REQUEST	Power should be set to $L_{Perch} + I_{BTS} + C$
3			Wait for $T = ??$	
4	→		CHANNEL REQUEST	Power should be set to $L_{Perch} + I_{BTS} + C + \Delta P_0$
5	→		CHANNEL REQUEST	Power should be set to $L_{Perch} + I_{BTS} + C + 2\Delta P_0$
6			...	Repeat (step 5)
7	→		CHANNEL REQUEST	Power should be set to $L_{Perch} + I_{BTS} + C + n\Delta P_0$
8			Wait for $T = ??$	
9	←		PAGE	
10	→		CHANNEL REQUEST	Power should be set to $L_{Perch} + I_{BTS} + C$
11	←		AICH = NEG ACQUISITION IND	Power should be set to $L_{Perch} + I_{BTS} + C + \Delta P_1$
12	→		CHANNEL REQUEST	Power should be set to $L_{Perch} + I_{BTS} + C$
13	←		AICH = NEG ACQUISITION IND	Power should be set to $L_{Perch} + I_{BTS} + C + 2\Delta P_1$
14			...	Repeat (step 13)
15	←		AICH = NEG ACQUISITION IND	Power should be set to $L_{Perch} + I_{BTS} + C + n\Delta P_1$

#### 7.1.2.1.5 Test requirements

Initially, the measured power level should be:

- $P_{RACH} = L_{Perch} + I_{BTS} + \text{Constant value}$ .

Where  $I_{BTS}$  and the Constant value are set by the SS, and  $L_{Perch}$  is the measured path loss on the PCCPCH, and reported back to the SS in measurement reports.

Subsequently the power should increase by  $\Delta P_0$  steps each retransmission until  $N_{RA}$  number of attempts have been made.

Then, no further RACH accesses should be received for then next  $T$  seconds.

At the start of the next phase of the test, the measured power level should be  $P_{RACH} = L_{Perch} + I_{BTS} + \text{Constant value}$ . Subsequently the power should increase in  $\Delta P_1$  steps until  $N_{RA}$  number of attempts have been made.

#### 7.1.2.2 Correct application of Dynamic Persistence

##### 7.1.2.2.1 Definition and applicability

All UE.

##### 7.1.2.2.2 Conformance requirement

The UE implements the dynamic persistence algorithm by:

1. reading the current dynamic persistence value from the BCH;
2. perform a random draw against the current dynamic persistence value. The random function is TBD;
3. defer transmission for one frame and repeat the process if the result of the random draw is negative, otherwise proceed with a CHANNEL REQUEST.

## Reference(s)

TS 25.214 clause 6.

## 7.1.2.2.3 Test purpose

To verify that if the dynamic persistence value in the last appropriate message on the BCH is set to zero, the UE will not attempt a RACH access.

## 7.1.2.2.4 Method of test

## Initial conditions

The SS will be transmitting BCCH messages with the dynamic persistence value set to zero.

The UE shall be attached to the network and in idle mode.

## Related ICS/IXIT Statement(s)

TBD

## Foreseen Final State of the UE

The same as the initial conditions.

## Test procedure

- a) The SS repeatedly pages the UE for  $T_{??}$  seconds.
- b) The SS monitors the RACH for a CHANNEL REQUEST message from the UE.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		←	PAGE	
2			Wait for T = ??	

## 7.1.2.2.5 Test requirements

The SS should not detect any access on the RACH.

## 7.1.2.3 Correct Selection of RACH parameters

## 7.1.2.3.1 Definition and applicability

All UE.

## 7.1.2.3.2 Conformance requirement

The following parameters are randomly selected by the physical layer (possibly within constraints defined by ASC parameters):

- PRACH initial access slot;
- PRACH signature.

## Reference(s)

TS 25.321 clause A.1.

## 7.1.2.3.3 Test purpose

To verify that the UE selects the correct initial access slot and PRACH signature.

## 7.1.2.3.4 Method of test

## Initial conditions

The UE shall be attached to the network and in idle mode. The SS will broadcast the Access Service Class parameters [on the BCH?].

## Related ICS/IXIT Statement(s)

TBD

## Foreseen Final State of the UE

The same as the initial conditions.

## Test procedure

- a) The SS pages the UE until it performs a RACH access.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	←		PAGE	
2	→		CHANNEL REQUEST	Access slot and signature should be in accordance with ASC parameters

## 7.1.2.3.5 Test requirements

The RACH access should take place on a PRACH access slot, and using a PRACH signature allowed by the UE Access Service Class.

## 7.1.3 Dynamic Radio Bearer Control

## 7.1.3.1 Definition and applicability

Not yet defined in core spec.

## 7.1.3.2 Conformance requirement

The algorithm exists in the UE and is controlled by the network. The algorithm requests to RRC for a reconfiguring of radio resources, details are ffs.

## Reference(s)

TS 25.321 subclause 11.1.

## 7.1.3.3 Test purpose

To verify that the RRC reconfiguration algorithm is correctly applied.



## 7.1.3.4 Method of test

Initial conditions

TBD

Related ICS/IXIT Statement(s)

TBD

Foreseen Final State of the UE

TBD

Test procedure

TBD

Expected sequence

Step	Direction	Message	Comments

## 7.1.3.5 Test requirements

TBD

## 7.1.4 RACH/FACH transmission and retransmission

Ensure the Stop and wait ARQ protocol is adhered to when RACH and FACH messages are lost.

## 7.1.5 MAC Access Control Function

Ensure the slotted ALOHA protocol is followed when RACH collisions occur.

## 7.1.6 Inband identification of UE on FACH

Check that the UE does not respond to FACH messages addressed to different RNTIs.

## 7.1.7 Inband identification of UE on DSCH

Check that the UE does not respond to DSCH traffic addressed to different RNTIs.

NOTE: The following items are FFS:

- user-plane MAC tests;
- prioritization of data on DTCH/DCCH;
- multicast channel.

## 7.1.8 Mapping between logical channels and transport channels

### 7.1.8.1 DCCH mapped to RACH/FACH

#### 7.1.8.1.1 Definition and applicability

#### 7.1.8.1.2 Conformance requirement

TCTF field, C/T field, UE-Id type field and UE-Id are included in the MAC header.

#### Reference(s)

TS 25.321 clause 9.2.1.1.

#### 7.1.8.1.3 Test purpose

To verify that the TCTF field, C/T field, UT-Id type and UE-Id field are correctly applied when a DCCH is mapped to the RACH/FACH

#### 7.1.8.1.4 Method of test

#### Initial conditions

#### System Simulator:

1 cell, default parameters, Ciphering Off.

#### User Equipment:

The UE shall operate under normal test conditions, Ciphering Off.

The Test-USIM shall be inserted.

The UE is in Connected mode and a connection is established as described in the RRC connection establishment procedure specified in TS 34.108, clause 7.1.2.

#### Foreseen Final State of the UE

TBD

#### Test procedure

- a) After having performed a packet switched connection establishment the SS sets up a Radio Bearer to establish a signalling radio bearer with DCCH mapping to RACH.
- b) The UE shall confirm the Radio Bearer configurations.
- c) The SS starts the Reallocation procedure to assign a new C\_RNTI.
- d) After having received the newly assigned C\_RNTI parameter, the UE shall confirm the completion of this procedure.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	←		RADIO BEARER SETUP	Establish Signalling Radio Bearer.
2	→		RADIO BEARER SETUP COMPLETE	
3	←		RNTI REALLOCATION	Assign an new C_RNTI.
4	→		RNTI REALLOCATION COMPLETE	This message shall be send on the DCCH.

Specific Message Contents

RADIO BEARER SET UP:

Information Element	Value/remark
RB mapping info	
- Number of Logical channels	1
- Transport channel type	RACH.

#### 7.1.8.1.5 Test Requirement

The UE shall confirm reallocation procedure by sending the RNTI REALLOCATION COMPLETE message. The message shall be returned on the configured channel on MAC level. This shall verify, that the mapped channels are used as configured.

### 7.1.8.2 DTCH or DCCH mapped to DSCH or USCH

#### 7.1.8.2.1 Definition and applicability

Applicable for if mode TDD only or FDD only is supported.

#### 7.1.8.2.2 Conformance requirement

The TCTF field is included in the MAC header for TDD only. The UE-Id type and UE-Id are included in the MAC header for FDD only. The C/T field is included if multiplexing on MAC is applied.

#### Reference(s)

TS 25.321 clause 9.2.1.1.

#### 7.1.8.2.3 Test purpose

To verify when DTCH or DCCH is mapped to DSCH or USCH, the TCTF field is applied for TDD only, the UE-Id type and UE-Id are applied for FDD only. If multiplexing on MAC is applied, C/T field is included, otherwise, the C/T field is not included in the MAC header.

#### 7.1.8.2.4 Method of test

Initial conditions

System Simulator:

1 cell, default parameters. Ciphering Off.

**User Equipment:**

The UE shall operate under normal test conditions, Ciphering Off.

The Test-USIM shall be inserted.

The UE is in Connected mode and a connection is established as described in the TS 34.123-1, 7.3 PDCP testing, clause "Setup a UE originated PS session using IP Header compression in AM RLC (using Loop back test mode 1).

**Related ICS/IXIT Statement(s)**

TBD

**Foreseen Final State of the UE****Test procedure**

- a) The SS sends a certain data block to the UE.
- b) After having received the data block via configured mapped channels, the UE forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its MAC configuration to the SS.
- c) The SS receives the returned data block and checks its MAC header whether the TCTF is applied for TDD only, or the UE-Id type and UE-Id are applied for FDD only and the C/T field shall not be applied.
- d) The SS configures the RLC
- e) The SS starts a Radio Bearer Reconfiguration procedure to be connected in RLC transparent mode and configures the Radio Bearer for multiplexing.
- f) The SS sends a certain data block to the UE.
- g) After having received the data block via configured mapped channels, the UE forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its MAC configuration to the SS.
- h) The SS receives the returned data block and check its MAC header whether the TCTF is applied for TDD only, or the UE-Id type and UE-Id are applied for FDD only and the C/T field is applied.
- i) The SS reconfigures its RLC mode to be in AM.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	←		DATA BLOCK	The SS sends one data block with MAC header, sets TCTF as "DCCH or DTCH over USCH or DSCH" for TDD only, or sets UE-Id type as "C-RNTI", and UE-Id as C-RNTI of UE for FDD only.
2	→		LOOP BACK DATA BLOCK	SS receives the loop back data block from the Uplink RB and checks the MAC header.
3				SS sends CMAC_MAC_HEADER_REQ with enable_mac_header and CRLC_CONFIG_REQ with RLC mode as "AM mode".
4	←		RADIO BEARER RECONFIGURE	Reconfigures the downlink and uplink radio bearer as multiplexing .
5	→		RADIO BEARER RECONFIGURATION COMPLETE	
6				SS sends CMAC_MAC_HEADER_REQ with disable_mac_header and CRLC_CONFIG_REQ with RLC mode as "Transparent mode".
7	←		DATA BLOCK	The SS sends one data block with MAC header, sets TCTF as "DCCH or DTCH over USCH or DSCH" for TDD only, or sets UE-Id type as "C-RNTI", and UE-Id as C-RNTI of UE for FDD only and C/T field is included.
8	→		LOOP BACK DATA BLOCK	SS receives the loop back data block from the Uplink RB and checks the MAC header.
9				SS sends CMAC_MAC_HEADER_REQ with enable_mac_header and CRLC_CONFIG_REQ with RLC mode as "AM mode".

Specific Message Contents

RADIO BEARER SET UP:

Information Element	Value/remark
RLC info - RLC mode	AM RLC
RB mapping info -Downlink - Number of logical channels - Downlink transport channel type	1 DSCH
-Uplink - Number of logical channels - Uplink transport channel type	1 USCH

RADIO BEARER RECONFIGURE:

Information Element	Value/remark
RLC info - RLC mode	AM RLC
RB mapping info -Downlink - Number of logical channels - Downlink transport channel type	2 DSCH
-Uplink - Number of logical channels - Uplink transport channel type	2 USCH

#### 7.1.8.2.5 Test requirements

TCTF field in the MAC header of loop back data block is "DTCH or DCCH over DSCH or USCH" for TDD only. The UE-ID type and UE-Id are applied in the MAC header for FDD only. If multiplexing on MAC is applied, C/T field is included, otherwise, C/T field is not included.

### 7.1.8.3 DTCH or DCCH mapped to CPCH

#### 7.1.8.3.1 Definition and applicability

#### 7.1.8.3.2 Conformance requirement

UE-Id type field and UE-Id are included in the MAC header. The C/T field is included in the MAC header if multiplexing on MAC is applied.

#### Reference(s)

TS 25.321 subclause 9.2.1.1.

#### 7.1.8.3.3 Test purpose

To verify when DTCH or DCCH mapped to CPCH, UE-Id type field and UE-Id are included in the MAC header. if multiplexing on MAC is applied, the C/T field is included in the MAC header, otherwise, C/T field is not included.

#### 7.1.8.3.4 Method of test

##### Initial conditions

##### System Simulator:

1 cell, default parameters, Ciphering Off.

##### User Equipment:

The UE shall operate under normal test conditions, Ciphering Off.

The Test-USIM shall be inserted.

The UE is in Connected mode and a connection is established as described in the TS 34.123-1, 7.3 PDCP testing, clause "Setup a UE originated PS session using IP Header compression in UM RLC (using Loop back test mode 1).

##### Related ICS/IXIT Statement(s)

TBD

##### Foreseen Final State of the UE

##### Test procedure

- The SS reconfigures its RLC mode to be in transparent mode RLC. Afterwards it sends a certain data block to the UE .
- After having received the data block via configured mapped channels, the UE forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its MAC configuration to the SS.
- The SS receives the returned data block and checks its MAC header, whether a UE-Id type and a UE-Id are included.
- The SS reconfigures its RLC mode to be in AM.

- e) The SS starts a Radio Bearer Reconfiguration procedure to be connected in RLC transparent mode and configures the Radio Bearer for multiplexing.
- f) The SS sends the next data block via its MAC entity with MAC header, including the UE-Id type as "C-RNTI" and UE-Id as C-RNTI of the UE.C/T field.
- g) After having received the data block via configured mapped channels, the UE forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its MAC configuration to the SS.
- h) The SS receives the returned data block and checks its MAC header, whether UE-Id type, UE-Id field are included and C/T field is applied or not.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		←	DATA BLOCK	The SS sends one data block with MAC header, sets UE-Id type as "C-RNTI", and UE-Id as C-RNTI of UE.
2		→	LOOP BACK DATA BLOCK	SS receives the loop back data block from the Uplink RB and checks the MAC header.
3				SS sends CMAC_MAC_HEADER_REQ with enable_mac_header and CRLC_CONFIG_REQ with RLC mode as "AM mode".
4		←	RADIO BEARER RECONFIGURE	Reconfigures the downlink and uplink radio bearer as multiplexing.
5		→	RADIO BEARER RECONFIGURATION COMPLETE	
6				SS sends CMAC_MAC_HEADER_REQ with disable_mac_header and CRLC_CONFIG_REQ with RLC mode as "Transparent mode".
7		←	DATA BLOCK	The SS sends one data block with MAC header, sets UE-Id type as "C-RNTI", and UE-Id as C-RNTI of UE.
8		→	LOOP BACK DATA BLOCK	SS receives the loop back data block from the Uplink RB and checks the MAC header.
9				SS sends CMAC_MAC_HEADER_REQ with enable_mac_header and CRLC_CONFIG_REQ with RLC mode as "AM mode".

Specific Message Contents

RADIO BEARER SET UP:

Information Element	Value/remark
RLC info - RLC mode	AM RLC
RB mapping info -Downlink - Number of logical channels - Downlink transport channel type	1 DSCH
-Uplink - Number of logical channels - Uplink transport channel type	1 CPCH

RADIO BEARER RECONFIGURE:

Information Element	Value/remark
RLC info - RLC mode	AM RLC
RB mapping info -Downlink - Number of logical channels - Downlink transport channel type	2 DSCH
-Uplink - Number of logical channels - Uplink transport channel type	2 CPCH



#### 7.1.8.3.5 Test requirements

The UE-Id type and UE-Id field are included in the MAC header. When multiplexing on MAC is not applied, C/T field is included in the MAC header. Otherwise, C/T field is not included.

#### 7.1.8.4 DTCH or DCCH mapped to DCH

##### 7.1.8.4.1 Definition and applicability

All UE.

##### 7.1.8.4.2 Conformance requirement

DTCH or DCCH mapped to DCH, no multiplexing of dedicated channels on MAC: -no MAC header is required.

DTCH or DCCH mapped to DCH, with multiplexing of dedicated channels on MAC: -C/T field is included in MAC header.

##### Reference(s)

TS 25.321 subclause 9.2.1.1.

##### 7.1.8.4.3 Test purpose

To verify when DTCH or DCCH mapped to DCH, if multiplexing of dedicated channels on MAC is applied, C/T field is included in the MAC header, if multiplexing of dedicated channels on MAC isn't applied, no MAC header is included.

##### 7.1.8.4.4 Method of test

##### Initial conditions

##### System Simulator:

1 cell, default parameters, Ciphering Off.

##### User Equipment:

The UE shall operate under normal test conditions, Ciphering Off.

The Test-USIM shall be inserted.

The UE is in Connected mode and a connection is established as described in the TS 34.123-1, 7.3 PDCP testing, clause "Setup a UE originated PS session using IP Header compression in UM RLC (using Loop back test mode 1).

##### Related ICS/IXIT Statement(s)

TBD

##### Foreseen Final State of the UE

##### Test procedure

- a) The SS reconfigures its RLC mode to be in transparent mode RLC. Afterwards it sends a certain data block to the UE.
- b) The SS sends a certain data block without MAC header.
- c) After having received the data block via configured mapped channels, the UE forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its MAC configuration to the SS.

- d) The SS receives the returned data block and checks its MAC header, whether MAC header is included or not.
- e)
- f) The SS starts a Radio Bearer Reconfiguration procedure to be connected in RLC transparent mode and configures the Radio Bearer for multiplexing.
- g) The SS sends a data block with C/T field.
- h) i) After having received the data block via configured mapped channels, the UE forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its MAC configuration to the SS.
- i) The SS receives the returned data block and checks its MAC header, whether C/T field is applied.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	←		DATA BLOCK	The SS sends one data block without MAC header.
2	→		LOOP BACK DATA BLOCK	SS receives the loop back data block from the Uplink RB and checks whether MAC header is applied or not.
3				SS sends CMAC_MAC_HEADER_REQ with enable_mac_header and CRLC_CONFIG_REQ with RLC mode as "AM mode".
4	←		RADIO BEARER RECONFIGURE	Reconfigures the downlink and uplink radio bearer as multiplexing.
5	→		RADIO BEARER RECONFIGURATION COMPLETE	
6				SS sends CMAC_MAC_HEADER_REQ with disable_mac_header and CRLC_CONFIG_REQ with RLC mode as "Transparent mode".
7	←		DATA BLOCK	The SS sends one data block with C/T field.
8	→		LOOP BACK DATA BLOCK	SS receives the loop back data block from the Uplink RB and checks whether C/T field is applied or not.
9				SS sends CMAC_MAC_HEADER_REQ with enable_mac_header and CRLC_CONFIG_REQ with RLC mode as "AM mode".

Specific Message Contents

RADIO BEARER SET UP:

Information Element	Value/remark
RLC info - RLC mode	AM RLC
RB mapping info -Downlink - Number of logical channels - Downlink transport channel type	1 DCH
-Uplink - Number of logical channels - Uplink transport channel type	1 DCH

RADIO BEARER RECONFIGURE:

Information Element	Value/remark
RLC info - RLC mode	AM RLC
RB mapping info -Downlink - Number of logical channels - Downlink transport channel type	2 DCH
-Uplink - Number of logical channels - Uplink transport channel type	2 DCH

#### 7.1.8.4.5 Test requirements

If multiplexing on MAC is applied, the C/T field is included in the MAC header, otherwise, the MAC header is not applied.

## 7.1.8.5 CCCH mapped to RACH/FACH

### 7.1.8.5.1 Definition and applicability

All UE.

### 7.1.8.5.2 Conformance requirement

TCTF field is included in the MAC header.

### Reference(s)

TS 25.321 clause 9.2.1.1.

### 7.1.8.5.3 Test purpose

To verify that the TCTF field is included in MAC header when CCCH mapped to RACH/FACH.

### 7.1.8.5.4 Method of test

#### Initial conditions

System Simulator:

1 cell, default parameters, Ciphering Off.

User Equipment:

The UE shall operate under normal test conditions, Ciphering Off.

The Test-USIM shall be inserted.

#### Related ICS/IXIT Statement(s)

TBD

#### Foreseen Final State of the UE

#### Test procedure

- a) The SS broadcast SYSTEM INFORMATION
- b) The SS sends PAGING TYPE 1 to the UE
- c) After having received the paging type 1 message, the UE asks for a RRC connection.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	←		SYSTEM INFORMATION	
2	←		PAGE TYPE 1	Page UE
3		→	RRC CONNECTION REQUEST	This message is transmitted on Uplink CCCH mapped to RACH, SS read the MAC header to checks whether the TCTF field is applied or not.

#### 7.1.8.5.5 Test requirements

The TCTF field is applied to the MAC header of RRC CONNECTION REQUEST.

### 7.1.8.6 DTCH mapped to RACH/FACH

#### 7.1.8.6.1 Definition and applicability

All UE.

#### 7.1.8.6.2 Conformance requirement

TCTF field, C/T field, UE-Id type and UE-Id are included in the MAC header.

#### Reference(s)

TS 25.321 clause 9.2.1.1.

#### 7.1.8.6.3 Test purpose

To verify that the TCTF field, C/T field, UE Id type and UE Id field are included in the MAC header when DTCH mapped to RACH/FACH.

#### 7.1.8.6.4 Method of test

##### Initial conditions

System Simulator:

1 cell, default parameters, Ciphering Off.

User Equipment:

The UE shall operate under normal test conditions, Ciphering Off.

The Test-USIM shall be inserted.

The UE is in Connected mode and a connection is established as described in the TS 34.123-1, 7.3 PDCP testing, clause "Setup a UE originated PS session using IP Header compression in AM RLC (using Loop back test mode 1).

#### Related ICS/IXIT Statement(s)

TBD

#### Foreseen Final State of the UE

#### Test procedure

- The SS reconfigures its RLC mode to be in transparent mode RLC. Afterwards it sends a certain data block to the UE.
- The SS sends a certain data block with MAC header, sets the TCTF as "DTCH or DCCH over FACH", the UE-Id type as "C-RNTI", the UE-Id as the C-RNTI of UE, and the C/T field as "Logical channel 1".
- After having received the data block via configured mapped channels, the UE forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its MAC configuration to the SS.
- The SS receives the returned data block and checks its MAC header, whether the TCTF field, C/T field, UE-Id type and UE-Id are included in the MAC header or not.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				SS sends CMAC_MAC_HEADER_REQ with disable_mac_header and CRLC_CONFIG_REQ with RLC mode as "Transparent mode"
2		←	DATA BLOCK	The SS sends one data block with MAC header, TCTF set as "DTCH or DCCH over FACH", UE-Id type as "C-RNTI", UE-Id as C-RNTI of UE, C/T field as "Logical channel 1"
3		→	LOOP BACK DATA BLOCK	SS receives the loop back data block from the Uplink RB and checks whether MAC header is applied or not.
4				SS sends CMAC_MAC_HEADER_REQ with enable_mac_header and CRLC_CONFIG_REQ with RLC mode as "AM mode"

Specific Message Contents

RADIO BEARER SET UP:

Information Element	Value/remark
RLC info - RLC mode	AM RLC
RB mapping info -Downlink - Number of logical channels - Downlink transport channel type	1 DCH
-Uplink - Number of logical channels - Uplink transport channel type	1 DCH

#### 7.1.8.6.5 Test requirements

CTCF shall be "DCCH or DTCH over RACH", C/T field ,UE-Id type, UE-Id field are included in the MAC header.

### 7.1.9 Selection of appropriate Transport format for each Transport Channel depending on instantaneous source rate

#### 7.1.9.1 Selection of Transport Format depending on instantaneous source rate

##### 7.1.9.1.1 Definition and applicability

All UE.

##### 7.1.9.1.2 Conformance requirement

Given the Transport Format combination set assigned by RRC, MAC selects the appropriate transport format within an assigned transport format set for each active transport channel depending on source rate. The control of transport formats ensures efficient use of transport channels.

Reference(s)

TS 25.321 subclause 25.301 5.3.1.2

#### 7.1.9.1.3 Test purpose

To verify that appropriate transport format is selected for each transport channel depending on source rate.

#### 7.1.9.1.4 Method of test

##### Initial conditions

##### System Simulator:

1 cell, default parameters, Ciphering Off.

##### User Equipment:

The UE shall operate under normal test conditions, Ciphering Off.

The Test-USIM shall be inserted.

The UE is in Connected mode and a connection is established as described in the TS 34.123-1, 7.3 PDCP testing, clause "Setup a UE originated PS session using IP Header compression in AM RLC (using Loop back test mode 1), but for two Radio Bearer entities. Therefore two uplink- and downlink settings shall be configured.

##### Related ICS/IXIT Statement(s)

TBD

##### Foreseen Final State of the UE

##### Test procedure

- a) The SS sends certain data blocks.
- b) After having received the data block via configured mapped channels, the UE forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its MAC configuration to the SS.
- c) The SS receives the returned data and read the TFCI which indicate the Transport Format.
- d) The SS checks, that high data rate RBs have a high bit rate Transport Format.
- e) The SS reconfigures its RLC mode to be in AM RLC.
- f) Repeat step a) to e) for different data rates.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				SS sends CMAC_MAC_HEADER_REQ with disable_mac_header, and CRLC_CONFIG_REQ with RLC mode as "Transparent Mode" for each Radio Bearer.
2	←		DATA BLOCKS	
3	→		LOOP BACK DATA BLOCKS	Read the Transfer Format of loop back data blocks, the high bit transfer format apply to the Radio Bearer with high data rate.
4				SS sends CMAC_MAC_HEADER_REQ with disable_mac_header, and CRLC_CONFIG_REQ with RLC mode as "Transparent Mode".
5				The step 1 to 10 shall be repeated for different data rates.

Specific Message Contents

RADIO BEARER SET UP:

Information Element	Value/remark
RLC info	
- RLC mode	AM RLC
RB1	
- TTI	10ms
- Downlink	
- Number of logical channels	1
- Downlink transport channel type	DCH
RB2	
- TTI	10ms
- Uplink	
- Number of logical channels	1
- Uplink transport channel type	DCH
RB3	
- TTI	80ms
- Downlink	
- Number of logical channels	1
- Downlink transport channel type	DCH
RB4	
- TTI	80ms
- Uplink	
- Number of logical channels	1
- Uplink transport channel type	DCH
TFS	TF0 (1X366)
	TF1 (2X366)
	TF2 (4X366)
	TF3 (8X366)

#### 7.1.9.1.5 Test requirements

The "High bit rate" TF is applied to the high data rate Radio Bearer. That is, the bit rate of TF in RB2 should be not less than RB4.



## 7.1.10 Priority handling between data flows of one UE

### 7.1.10.1 Priority handling between data flows of one UE

#### 7.1.10.1.1 Definition and applicability

#### 7.1.10.1.2 Conformance requirement

When selecting between the Transport Format Combinations in the given Transport Format Combination Set, priorities of the data flows to be mapped onto the corresponding Transport Channels can be taken into account.

#### Reference(s)

TS 25.301 subclause 5.3.1.2.

#### 7.1.10.1.3 Test purpose

To verify that the priority between data flows of one UE was correctly handled.

#### 7.1.10.1.4 Method of test

#### Initial conditions

##### System Simulator:

1 cell, default parameters, Ciphering Off.

##### User Equipment:

The UE shall operate under normal test conditions, Ciphering Off.

The Test-USIM shall be inserted.

The UE is in Connected mode and a connection is established as described in the TS 34.123-1, 7.3 PDCP testing, clause "Setup a UE originated PS session using IP Header compression in AM RLC (using Loop back test mode 1), but for two Radio Bearer entities. Therefore two uplink- and downlink settings shall be configured.

#### Related ICS/IXIT Statement(s)

TBD

#### Foreseen Final State of the UE

#### Test procedure

- a) The SS sends certain data blocks.
- b) After having received the data block via configured mapped channels, the UE forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its MAC configuration to the SS.
- c) The SS receives the returned data and reads the TFCI which indicates the Transport Format.
- d) The SS checks that high data rate RBs have a high bit rate Transport Format.
- e) The SS reconfigures its RLC mode to be in AM RLC.
- f) Repeat step a) to e) repeat with different MAC logical channel priority (MAC priority of RB1 and RB2 set as 3, MAC priority of RB3 and RB4 set as 1).

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				SS sends CMAC_MAC_HEADER_REQ with disable_mac_header, and CRLC_CONFIG_REQ with RLC mode as "Transparent Mode".
2	←		DATA BLOCKS	
3	→		LOOP BACK DATA BLOCKS	Read the Transfer Format of loop back data blocks, the high bit transfer format apply to the Radio Bearer with high MAC logical channel priority.
4				SS sends CMAC_MAC_HEADER_REQ with disable_mac_header, and CRLC_CONFIG_REQ with RLC mode as "Transparent Mode".
5				The step 1 to 4 shall be repeated with different MAC logical channel priority.

Specific Message Contents

RADIO BEARER SET UP:

Information Element	Value/remark
RLC info	
- RLC mode	AM RLC
RB1 mapping info	
- MAC logical channel priority	4
- Downlink	
- Number of logical channels	1
- Downlink transport channel type	DCH
RB2 mapping info	
- MAC logical channel priority	4
- Uplink	
- Number of logical channels	1
- Uplink transport channel type	DCH
RB3 mapping info	
- MAC logical channel priority	2
- Downlink	
- Number of logical channels	1
- Downlink transport channel type	DCH
RB4 mapping info	
- MAC logical channel priority	2
- Uplink	
- Number of logical channels	1
- Uplink transport channel type	DCH
TFS	TF0 (1X366)
	TF1 (2X366)
	TF2 (4X366)
	TF3 (8X366)

#### 7.1.10.1.5 Test requirements

The high bit rate TF is applied to high MAC logical channel priority Radio Bearer. That is, the bit rate of TF in RB4 should be not less than RB2.

## 7.1.11 Ciphering for transparent RLC

### 7.1.11.1 Ciphering

#### 7.1.11.1.1 Definition and applicability

All UE.

#### 7.1.11.1.2 Conformance requirement

Ciphering is performed in the MAC layer for transparent RLC mode.

#### Reference(s)

TS 25.301 subclause 5.3.1.2.

#### 7.1.11.1.3 Test purpose

To verify that the ciphering is performed in the MAC layer for transparent RLC mode.

#### 7.1.11.1.4 Method of test

##### Initial conditions

System Simulator:

1 cell, default parameters. Transparent Mode, Ciphering On.

User Equipment:

The UE shall operate under normal test conditions, Ciphering On.

The Test-USIM shall be inserted.

The UE is in Connected mode and a connection is established as described in the TS 34.123-1, 7.3 PDCP testing, clause "Setup a UE originated PS session using IP Header compression in AM RLC (using Loop back test mode 1).

##### Related ICS/IXIT Statement(s)

TBD

##### Foreseen Final State of the UE

##### Test procedure

- a) The MAC entity of SS was configured as Ciphering mode as "Start" with CMAC\_CONFIG-REQ primitive.
- b) SS configures its RLC entity "Transparent mode".
- c) The SS sends a DATA BLOCK from RLC PCO without MAC header. After having received the data block via configured mapped channels, the UE forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its MAC configuration to the SS.
- d) The SS checks the returned data blocks and compare it with the data block asw sent before.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				SS sends CMAC_CONFIG-REQ to set ciphering mode as "Start".
2				SS sends CMAC_MAC_HEADER_REQ with disable_mac_header and CRLC_CONFIG_REQ with RLC mode as "Transparent mode".
3	←		DATA BLOCKS	SS sends data blocks from downlink radio bearer, The data blocks is ciphered by SS and deciphered by UE.
4	→		LOOP BACK DATA BLOCKS	SS receives loop back data blocks from uplink radio bearer. The loop back data is ciphered by UE and deciphered by SS.
5				SS sends CMAC_MAC_HEADER_REQ with enable_mac_header and CRLC_CONFIG_REQ with RLC mode as "AM mode".

Specific Message Contents

RADIO BEARER SET UP:

Information Element	Value/remark
Ciphering mode info - Ciphering mode command - Ciphering algorithm	Start UEA 1, kasumi.
RLC info - RLC mode	Transparent RLC
RB mapping info -Downlink - Number of logical channels - Downlink transport channel type	1 DCH
-Uplink - Number of logical channels - Uplink transport channel type	1 DCH

#### 7.1.11.1.5 Test requirements

The loop back data shall be identical to the data sent out by SS.

### 7.1.12 Control of RACH transmissions.

#### 7.1.12.1 Access Service class selection for RACH transmission

##### 7.1.12.1.1 Definition and applicability

All UE.

##### 7.1.12.1.2 Conformance requirement

The following ASC selection scheme shall be applied, where NumASC is the highest available ASC number and MinMLP the highest logical channel priority assigned to one logical channel:

In case all TBs in the TB set have the same MLP, select  $ASC = \min(\text{NumASC}, \text{MLP})$ ;

In case TBs in a TB set have different priority, determine the highest priority level MinMLP and select  $ASC = \min(\text{NumASC}, \text{MinMLP})$ .

Reference(s)

TS 25.321 subclause 11.2.1

7.1.12.1.3 Test purpose

To verify that MAC selection ASC correctly.

7.1.12.1.4 Method of test

Initial conditions

System Simulator:

1 cell, default parameters, Ciphering Off.

User Equipment:

The UE shall operate under normal test conditions, Ciphering Off.

The Test-USIM shall be inserted

The UE is in Connected mode and a connection is established as described in the TS 34.123-1, 7.3 PDCP testing, clause "Setup a UE originated PS session using IP Header compression in AM RLC (using Loop back test mode 1).

Related ICS/IXIT Statement(s)

TBD

Foreseen Final State of the UE

Test procedure

- a) The SS configures its RLC entity for "Transparent Mode".
- b) The MAC entity in the SS side is configured with ASC as 4.
- c) The SS sends certain data blocks to UE.
- d) After having received the data block via configured mapped channels, the UE forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its MAC configuration to the SS.
- e) The SS receives the returned data blocks from the UE.
- f) The MAC entity in SS side was reconfigured with ASC as any other data than 4.
- g) The SS sends the next data blocks to UE.
- h) The SS doesn't receive any data blocks from the UE within 30 seconds.
- i) The SS configures its RLC entity for AM mode" ..
- j) The SS sends RADIO BEARER RELEASE message to UE.
- k) The UE sends RADIO BEARER RELEASE COMPLETE message to SS.
- l) The procedure from a to n was repeated 3 times with MAC logical priority set as 3, 2, 1 and configure the ASC in system simulator as 3, 2, 1 accordingly.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				SS sends CMAC_MAC_HEADER_REQ with disable_mac_header and CRLC_CONFIG_REQ with RLC mode as "Transparent mode".
2			CMAC_CONFIG-Req	SS sets the ASC as 4.
3	←		DATA BLOCKS	SS sends data blocks.
4	→		LOOP BACK DATA BLOCKS	SS shall receive the data block from UE.
5			CMAC_CONFIG-Req	SS sets the ASC as other value than 4.
6	←		DATA BLOCKS	SS sends data blocks.
7	→		LOOP BACK DATA BLOCKS	SS shall not receive the loop back data blocks from UE in 30s.
8				SS sends CMAC_MAC_HEADER_REQ with enable_mac_header and CRLC_CONFIG_REQ with RLC mode as "AM mode".
9			Repeat Step 1 to step 8 shall be repeated 3 times with MAC Priority set as 3, 2, 1 and the ASC of SS set as 3, 2, 1 accordingly	

#### 7.1.12.1.5 Test requirements

When the ASC in SS side match with the MAC priority, SS can receive the loop back data blocks, otherwise, The SS can't receive the loop back data blocks. This requirement applies to the different MAC priority.

### 7.1.12.2 Control of RACH transmissions for FDD mode

#### 7.1.12.2.1 Definition and applicability

All UE.

#### 7.1.12.2.2 Conformance requirement

MAC receives the following RACH transmission control parameters from RRC with the CMAC-Config-REQ primitive: maximum number of preamble ramping cycles Mmax.

When preamble transmission counter M larger than Mmax, then the procedure will stop and enter Error handling procedure.

#### Reference(s)

TS25.321 11.2.2, TS25.321 Figure 11.2.2.1

#### 7.1.12.2.3 Test purpose

To verify that the MAC entity controls RACH transmission correctly.

#### 7.1.12.2.4 Method of test

#### Initial conditions

System Simulator:

1 cell, default parameters, Ciphering Off.

SS broadcast System Information 5 with Mmax in RACH transmission parameters set as 0.

User Equipment:

The UE shall operate under normal test conditions, Ciphering Off.

The Test-USIM shall be inserted.

The UE is in Connected mode and a connection is established as described in the TS 34.123-1, 7.3 PDCP testing, clause "Setup a UE originated PS session using IP Header compression in AM RLC (using Loop back test mode 1).

Related ICS/IXIT Statement(s)

TBD

Foreseen Final State of the UE

The same as the initial conditions.

Test procedure

- a) The SS configures its RLC entity for "Transparent Mode" .
- b) The SS sends certain DATA BLOCKS.
- c) The SS shall not receive any LOOP BACK DATA BLOCKS within 30s.

Expected sequence:

Step	Direction		Message	Comments
	UE	SS		
1				SS sends CMAC_MAC_HEADER_REQ with disable_mac_header and CRLC_CONFIG_REQ with RLC mode as "Transparent mode".
2		←	DATA BLOCKS	
3				SS shall not receive returned data blocks within 30s.
4				SS sends CMAC_MAC_HEADER_REQ with enable_mac_header and CRLC_CONFIG_REQ with RLC mode as "AM mode".

#### 7.1.12.2.5 Test requirements

The SS does not receive loop back data blocks from UE when  $M_{\max}$  set as 0.

### 7.1.13 Control of CPCH transmissions.

#### 7.1.13.1 Control of CPCH transmissions for FDD

##### 7.1.13.1.1 Definition and applicability

All UE.

##### 7.1.13.1.2 Conformance requirement

1. If counter M is not less than  $N_{\text{access\_fails}}$ , the UE shall execute an access failure error procedure and the CPCH access procedure ends.
2. If the sum of the Frame Count Transmitted counter plus the number of frames in the next TTI is larger than  $NF_{\max}$ , the UE shall exit the CPCH transmission procedure.

Reference(s) TS25.321 11.3

TS 25.214 clause 6.

#### 7.1.13.1.3 Test purpose

To verify that the MAC entity control CPCH transmission correctly.

#### 7.1.13.1.4 Method of test

Initial conditions

System Simulator:

1 cell, default parameters, Ciphering Off.

User Equipment:

The UE shall operate under normal test conditions, Ciphering Off.

The Test-USIM shall be inserted.

The UE is in Connected mode and a connection is established as described in the TS 34.123-1, 7.3 PDCP testing, clause "Setup a UE originated PS session using IP Header compression in AM RLC (using Loop back test mode 1).

Related ICS/IXIT Statement(s)

TBD

Foreseen Final State of the UE

The same as the initial conditions.

Test procedure

- a) The SS configures its RLC entity for "Transparent Mode"
- b) The SS sends certain DATA BLOCKS to UE with UE-Id type and UE-Id field.
- c) After having received the data block via configured mapped channels, the UE forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its MAC configuration to the SS.
- d) The SS receives returned DATA BLOCKS.
- e) The SS configures its RLC entity for "AM mode"
- f) The SS starts the RB reconfiguration procedure by sending the RADIO BEARER RECONFIGURATION message with parameter: N\_access\_fails = 0.
- g) After having received the UE confirmation for the reconfiguration procedure, the SS configures its RLC entity for "Transparent Mode"
- h) The SS sends certain DATA BLOCKS.
- i) The SS shall not receive any LOOP BACK DATA BLOCKS within 30s.
- j) The SS configures its RLC entity for "AM mode".
- k) The SS starts the RB reconfiguration procedure by sending the RADIO BEARER RECONFIGURATION message with parameter: NF\_max equal = 0, and N\_access\_failure = 64.
- l) The SS receives RADIO BEARER RECONFIGURE COMPLETE.



- m) After having received the UE confirmation for the reconfiguration procedure, the SS configures its RLC entity for "Transparent Mode".
- n) The SS sends certain DATA BLOCKS.
- o) The SS shall not receive any returned DATA BLOCKS within 30s.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
5				SS sends CMAC_MAC_HEADER_REQ with disable_mac_header and CRLC_CONFIG_REQ with RLC mode as "Transparent mode".
6	←		DATA BLOCKS	
7	←		LOOP BACK DATA BLOCKS	
8				SS sends CMAC_MAC_HEADER_REQ with enable_mac_header and CRLC_CONFIG_REQ with RLC mode as "AM mode".
9	←		RADIO BEARER RECONFIGURATION	Set N_access_fails as 0.
10	→		RADIO BEARER RECONFIGURATION COMPLETE	
11				SS sends CMAC_MAC_HEADER_REQ with disable_mac_header and CRLC_CONFIG_REQ with RLC mode as "Transparent mode".
12	←		DATA BLOCK	
13				The SS can't receive loop back data blocks from UE in 30s.
14				SS sends CMAC_MAC_HEADER_REQ with enable_mac_header and CRLC_CONFIG_REQ with RLC mode as "AM mode".
15	←		RADIO BEARER RECONFIGURATION	Set NF_max as 0 and N_access_fails as 64.
16	→		RADIO BEARER RECONFIGURATION COMPLETE	
17				SS sends CMAC_MAC_HEADER_REQ with disable_mac_header and CRLC_CONFIG_REQ with RLC mode as "Transparent mode".
18	→		DATA BLOCK	UE was triggered to send data block.
19				The SS can't receive data from UE in 30s
20				SS sends CMAC_MAC_HEADER_REQ with enable_mac_header and CRLC_CONFIG_REQ with RLC mode as "AM mode".

## Specific Message Contents

## RADIO BEARER SET UP:

Information Element	Value/remark
RLC info	
- RLC mode	AM RLC
RB mapping info	
-Downlink	
- Number of logical channels	1
- Downlink transport channel type	CPCH
-Uplink	
- Number of logical channels	1
- Uplink transport channel type	CPCH
NF_max	64
N_access_fails	64

## 7.1.13.1.5 Test requirements

The SS can't receives data blocks from UE when N\_access\_fails or NF\_max set as 0.

## 7.2 RLC testing

### 7.2.1 Transparent mode

#### 7.2.1.1 Segmentation and reassembly

Transparent mode segmentation and reassembly are not tested in this release of the specification.

### 7.2.2 Unacknowledged mode

#### 7.2.2.1 General information for UM tests

A generic Radio Access Bearer is provided for UM tests. This RAB is based upon the Stand-alone 3.4kbps UL/DL Signalling RB, with an additional UM 3.4kbps path mapped to a DTCH. This logical channel is multiplexed on the same transport channel as the DCCH.

The UM test RAB is set up using the Generic Procedure described in Clause 7.1.3 of TS 34.108, and with the default RAB replaced as follows:

Higher layer	RAB/signalling RB		SRB#1	SRB#2	SRB#3	SRB#4	RAB #1
	User of Radio Bearer		RRC	RRC	NAS_DT High prio	NAS_DT Low prio	User Plane
RLC	Logical channel type		DCCH	DCCH	DCCH	DCCH	DTCH
	RLC mode		UM	AM	AM	AM	UM
	Payload sizes, bit		136	128	128	128	136
	Max data rate, bps		3400	3200	3200	3200	3400
	RLC header, bit		8	16	16	16	8
MAC	MAC header, bit		4	4	4	4	4
	MAC multiplexing		4 logical channel multiplexing				
Layer 1	TrCH type		DCH				
	TB sizes, bit		148				
	TFS	TF0, bts	0				
		TF1, bits	1x148				
	TTI, ms		40				
	Coding type		CC 1/3				
	CRC, bit		16				
	Max number of bits/TTI before rate matching		516				
	Uplink: Max number of bits/radio frame before rate matching		129				

Table 7.2/1 RAB Configuration for UM testing (7-bit Lis)

The UM test RAB is used in all tests with the following exceptions:

- Tests that only involve 15-bit length indicators
- Tests that explicitly specify a different Radio Bearer configuration

Tests that involve only 15-bit length indicators require a modified Radio Bearer configuration. To accommodate the larger payload size, these tests use a coded composite transport channel consisting of two DCH. The first DCH is specified as for the 7-bit length indicators, but not including the DTCH (RAB#1). This is shown in Table 7.2/2A

Higher layer	Signalling RB: <b>DCH 0</b>		SRB#1	SRB#2	SRB#3	SRB#4
	User of Radio Bearer		RRC	RRC	NAS_DT High prio	NAS_DT Low prio
RLC	Logical channel type		DCCH	DCCH	DCCH	DCCH
	RLC mode		UM	AM	AM	AM
	Payload sizes, bit		136	128	128	128
	Max data rate, bps		3400	3200	3200	3200
	RLC header, bit		8	16	16	16
MAC	MAC header, bit		4	4	4	4
	MAC multiplexing		4 logical channel multiplexing			
Layer 1	TrCH type		DCH			
	TB sizes, bit		148			
	TFS	TF0, bts	0			
		TF1, bits	1x148			
	TTI, ms		40			
	Coding type		CC 1/3			
	CRC, bit		16			
	Max number of bits/TTI before rate matching		516			
	Uplink: Max number of bits/radio frame before rate matching		129			

Table 7.2/2A SRB Configuration for UM testing (15-bit Lis)

This DCH is combined with a traffic DCH (at lower MAC priority) as described in Table 7.2/2B

Higher layer	RAB: <b>DCH 1</b>		<b>RAB</b>
RLC	Logical channel type		DTCH
	RLC mode		UM
	Payload sizes, bit		1280
	Max data rate, bps		64000
	RLC header, bit		8
MAC	MAC header, bit		0
	MAC multiplexing		N/A
Layer 1	TrCH type		DCH
	TB sizes, bit		1288
	TFS	TF0, bits	0
		TF1, bits	1x1288
	TTI, ms		20
	Coding type		TC
	CRC, bit		16

**Table 7.2/2B RAB Configuration for UM testing (15-bit Lis)**

All other settings are the same.

## 7.2.2.2 Segmentation and reassembly / Selection of 7 or 15 bit Length Indicators

### 7.2.2.2.1 Definition

For RLC PDUs smaller than 124 bytes in length, the UE RLC should assume received PDUs have 7-bit length indicators, and for PDUs of 124 bytes and larger the UE should assume 15-bit length indicators. The UE should also add the same size length indicators to outgoing RLC PDUs.

This requirement applies to all UE that support RLC PDU sizes of 124 bytes or greater.

### 7.2.2.2.2 Conformance requirement

The size of the Length Indicator may be either 7bits or 15bits.

If RLC PDUs always carry only one PU, 7bit indicators are used in a particular RLC PDU if the address space is sufficient to indicate all SDU segment borders. Otherwise 15bit Length Indicators are applied.

The length of the Length Indicator only depends on the size of the largest RLC PDU. The length of the Length Indicator is always the same for all PUs, for one RLC entity.

RLC SDUs might be segmented. If possible, the last segment of a SDU shall be concatenated with the first segment of the next SDU in order to fill the data field completely and avoid unnecessary padding

### Reference(s)

TS 25.322 Clauses 9.2.2.8, 9.2.2.9

### 7.2.2.2.3 Test purpose

To test that if PDU carries a single PU, and the PU size is small enough that a 7 bit indicator is sufficient, 7 bit indicators are used, otherwise, 15 bit indicators are used.

## 7.2.2.2.4 Method of test

## Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the following exceptions:

Higher layer	RAB/Signalling RB		RAB
RLC	Logical channel type		DTCH
	RLC mode		UM
	Payload sizes, bit		960
	Max data rate, bps		48000
	RLC header, bit		8
MAC	MAC header, bit		0
	MAC multiplexing		N/A
Layer 1	TrCH type		DCH
	TB sizes, bit		968
	TFS	TF0, bits	0
		TF1, bits	1x968
	TTI, ms		20
	Coding type		TC
	CRC, bit		16

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into loop-back mode 1 with the UL SDU size set to 40 bytes.

## Test procedure

- The SS transmits an RLC SDU of size 80 bytes.
- The SS checks the length indicator sizes and values of the RLC PDU returned on the uplink.
- The SS reconfigures the Transport Channel as follows:

Higher layer	RAB/Signalling RB		RAB
RLC	Logical channel type		DTCH
	RLC mode		UM
	Payload sizes, bit		1280
	Max data rate, bps		64000
	RLC header, bit		8
MAC	MAC header, bit		0
	MAC multiplexing		N/A
Layer 1	TrCH type		DCH
	TB sizes, bit		1288
	TFS	TF0, bits	0
		TF1, bits	1x1288
	TTI, ms		20
	Coding type		TC
	CRC, bit		16

All other settings the same.

- d) The SS transmits an RLC SDUs of size 80 bytes.
- e) The SS checks the length indicator sizes and values of the RLC PDU returned on the uplink
- f) The SS may optionally release the radio bearer.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures
2		←	DOWNLINK RLC PDU	80 byte SDU + padding
3		→	UPLINK RLC PDU	40 byte SDU + padding
4		←	TRANSPORT CHANNEL RECONFIGURATION	PU size > 127 bytes
5		←	DOWNLINK RLC PDU	80 byte SDU + padding
6		→	UPLINK RLC PDU	40 byte SDU + padding
7			RB RELEASE	Optional step

#### 7.2.2.2.5 Test requirements

The UE shall send 7 bit length indicators with values that correctly indicate the end of SDU in step b).

The UE shall send 15 bit length indicators with values that correctly indicate the end of SDU in step e).

### 7.2.2.3 Segmentation / 7-bit Length Indicators / Padding

#### 7.2.2.3.1 Definition

The RLC segments SDUs into blocks according to the configured payload unit size. Length indicators are added to indicate: the boundaries of SDUs within a PU, the addition of padding bytes.

This test applies to all UE.

#### 7.2.2.3.2 Conformance requirement

The Length Indicator is used to indicate, each time, the end of an SDU occurs in the PU. The Length Indicator points out the number of octets between the end of the last Length Indicator field and up to and including the octet at the end of an SDU segment

A PU that has unused space, to be referred to as padding, must use a Length Indicator to indicate that this space is used as padding. A padding Length Indicator must be placed after any Length Indicators for a PU.

One length indicator field shall be included for each end of a SDU that the PDU includes. The length indicator shall be set equal to the number octets between the end of the header fields and the end of the segment. If padding is needed another length indicator shall be added

#### Reference(s)

TS 25.322 Clauses 9.2.2.8 and 11.2.2.1.

#### 7.2.2.3.3 Test purpose

To test that a large SDU is correctly segmented and padding added at the end.

#### 7.2.2.3.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for UM 7-bit length indicator tests in Clause 7.2.2.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into loop-back mode 1 with the UL SDU size set to 18 bytes.

##### Test procedure

- a) The SS transmits an RLC SDU of size 18 bytes.
- b) The SS checks the length indicator sizes and values of the RLC PDU returned on the uplink, and checks the length and content of the received RLC SDU.
- c) The SS may optionally release the radio bearer.

##### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures
2		←	DOWNLINK RLC PDU	SDU 1
3		←	DOWNLINK RLC PDU	SDU 1 & Padding
4		→	UPLINK RLC PDU	No LI
5		→	UPLINK RLC PDU	Check Lis and re-assembled SDU
6			RB RELEASE	Optional step

#### 7.2.2.3.5 Test requirements

The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have a LI indicating the PDU contains an SDU boundary after octet 1 of the data field, and the second shall indicate that the remainder of the PDU contains padding.

The length and data content of the received SDU should be the same as the transmitted SDU.

#### 7.2.2.4 Segmentation / 7-bit Length Indicators / LI = 0

##### 7.2.2.4.1 Definition

Tests the behaviour of the RLC when an SDU exactly fills a PU.

This test applies to all UE.

##### 7.2.2.4.2 Conformance requirement

If the PDU is exactly filled with the last segment of a SDU and there is no room for a length indicator field a length indicator field set to only 0's shall be included in the next PDU.

## Reference(s)

TS 25.322 Clause 11.2.2.1

## 7.2.2.4.3 Test purpose

To test that where an SDU exactly fills a PU, an LI of value zero is placed as the first LI in the next PU.

## 7.2.2.4.4 Method of test

## Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for UM 7-bit length indicator tests in Clause 7.2.2.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into loop-back mode 1 with the UL SDU size set to 17 bytes.

## Test procedure

- a) The SS transmits an RLC SDU of size 34 bytes.
- b) The SS checks the length indicator sizes and values of the RLC PDUs returned on the uplink, and checks the length and content of the received RLC SDU.
- c) The SS may optionally release the radio bearer.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures
2	←		DOWNLINK RLC PDU	SDU 1
3	←		DOWNLINK RLC PDU	SDU 1
4	←		DOWNLINK RLC PDU	LI=0 and padding
5	→		UPLINK RLC PDU	No Lis
6	→		UPLINK RLC PDU	Check Lis and re-assembled SDU
7			RB RELEASE	Optional step

## 7.2.2.4.5 Test requirements

The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have an LI indicating that the SDU exactly filled the previous PU, and an LI indicating that the remainder of the PDU contains padding.

The length of the received SDU should be 17 bytes, and the data content the same as the first 17 bytes of the transmitted SDU.

## 7.2.2.5 Segmentation / 7-bit Length Indicators / Invalid LI value

## 7.2.2.5.1 Definition

Tests the behaviour of the RLC when a PDU contains an invalid length indicator.



This test applies to all UE.

#### 7.2.2.5.2 Conformance requirement

Upon reception of an UMD PDU that contains Length Indicator value 1111110 ("piggybacked STATUS PDU") the receiver shall discard that UMD PDU.

#### Reference(s)

TS 25.322 Clause 11.2.4.1.

#### 7.2.2.5.3 Test purpose

To test that PDUs with invalid length indicators are discarded by the receiving RLC.

#### 7.2.2.5.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for UM 7-bit length indicator tests in Clause 7.2.2.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into loop-back mode 1 with the UL SDU size set to 24 bytes.

##### Test procedure

- a) The SS transmits two RLC SDUs of size 24 bytes. In the third PDU for transmission, the SS sets the value of the second (padding) LI to 1111110.
- b) The SS checks the length indicator sizes and values of any RLC PDUs returned on the uplink, and checks for the presence of any received RLC SDUs.
- c) The SS may optionally release the radio bearer.

##### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures
2		←	DOWNLINK RLC PDU	SDU 1
3		←	DOWNLINK RLC PDU	SDU 1 & SDU 2
4		←	DOWNLINK RLC PDU	SDU 2 and invalid LI (=11111110)
5		→	UPLINK RLC PDU	SDU 1
6		→	UPLINK RLC PDU	SDU 1: Check Lis and re-assembled SDU
7			RB RELEASE	Optional step

#### 7.2.2.5.5 Test requirements

The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have a LI indicating the end of the SDU, and a padding LI.

The length and data content of the received SDU should be the same as the first transmitted SDU. The second SDU should not be returned.

## 7.2.2.6 Segmentation / 7-bit Length Indicators / LI value > PDU size

### 7.2.2.6.1 Definition

Tests the behaviour of the RLC when a PDU contains an invalid length indicator.

This test applies to all UE.

### 7.2.2.6.2 Conformance requirement

If the length indicator of a PDU has a value that is larger than the PDU size, the PDU shall be discarded and treated as a missing PDU.

If a PDU with sequence number < VR(US) is missing then all SDUs that have segments in this PDU shall be discarded.

### Reference(s)

TS 25.322 Clauses 11.2.4.2 and 11.2.3.

### 7.2.2.6.3 Test purpose

To test that PDUs with length indicators that point beyond the end of the PDU are discarded by the receiving RLC.

### 7.2.2.6.4 Method of test

#### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for UM 7-bit length indicator tests in Clause 7.2.2.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into loop-back mode 1 with the UL SDU size set to 24 bytes.

#### Test procedure

- The SS transmits three RLC SDUs of size 24 bytes. All the SDUs are concatenated or segmented over successive RLC PDUs. In the third PDU for transmission, the SS sets value of the length indicator to be 18 (decimal).
- The SS checks the length indicator sizes and values of the RLC PDUs returned on the uplink, and checks the length and content of the received RLC SDUs.
- The SS may optionally release the radio bearer.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures
2		←	DOWNLINK RLC PDU	SDU 1
3		←	DOWNLINK RLC PDU	SDU 1 & SDU 2
4		←	DOWNLINK RLC PDU	SDU 2 & SDU 3, with bad LI
5		←	DOWNLINK RLC PDU	SDU 3
6		←	DOWNLINK RLC PDU	SDU 3 and padding
7		→	UPLINK RLC PDU	SDU 1
8		→	UPLINK RLC PDU	SDU 1 and padding: Check Lis and re-assembled SDU
9			RB RELEASE	Optional step

#### 7.2.2.6.5 Test requirements

The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have a LI indicating the end of an SDU and an LI indicating that the remainder of the PDU contains padding.

The length and data content of the received SDU should be the same as the first transmitted SDU. No further SDUs or PDUs should be received.

### 7.2.2.7 Segmentation / 15-bit Length Indicators / Padding

#### 7.2.2.7.1 Definition

The RLC segments SDUs into blocks according to the configured payload unit size. Length indicators are added to indicate: the boundaries of SDUs within a PU, the addition of padding bytes.

This test applies to UE that support packet data.

#### 7.2.2.7.2 Conformance requirement

The Length Indicator is used to indicate, each time, the end of an SDU occurs in the PU. The Length Indicator points out the number of octets between the end of the last Length Indicator field and up to and including the octet at the end of an SDU segment

A PU that has unused space, to be referred to as padding, must use a Length Indicator to indicate that this space is used as padding. A padding Length Indicator must be placed after any Length Indicators for a PU.

One length indicator field shall be included for each end of a SDU that the PDU includes. The length indicator shall be set equal to the number octets between the end of the header fields and the end of the segment. If padding is needed another length indicator shall be added

#### Reference(s)

TS 25.322 Clauses 9.2.2.8 and 11.2.2.1.

#### 7.2.2.7.3 Test purpose

To test that a large SDU is correctly segmented and padding added at the end.

#### 7.2.2.7.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for UM 15-bit length indicator tests in Clause 7.2.2.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into loop-back mode 1 with the UL SDU size set to 161 bytes.

##### Test procedure

- a) The SS transmits an RLC SDU of size 161 bytes.
- b) The SS checks the length indicator sizes and values of the RLC PDU returned on the uplink, and checks the length and content of the received RLC SDU.
- c) The SS may optionally release the radio bearer.

##### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures
2		←	DOWNLINK RLC PDU	SDU 1
3		←	DOWNLINK RLC PDU	SDU 1 & Padding
4		→	UPLINK RLC PDU	No LI
5		→	UPLINK RLC PDU	Check Lis and re-assembled SDU
6			RB RELEASE	Optional step

#### 7.2.2.7.5 Test requirements

The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have a LI indicating the PDU contains an SDU boundary after octet 1 of the data field, and the second shall indicate that the remainder of the PDU contains padding.

The length and data content of the received SDU should be the same as the transmitted SDU.

### 7.2.2.8 Segmentation / 15-bit Length Indicators / LI = 0

#### 7.2.2.8.1 Definition

Tests the behaviour of the RLC when an SDU exactly fills a PU.

This test applies to all UE.

#### 7.2.2.8.2 Conformance requirement

If the PDU is exactly filled with the last segment of a SDU and there is no room for a length indicator field a length indicator field set to only 0's shall be included in the next PDU.

## Reference(s)

TS 25.322 Clause 11.2.2.1.

## 7.2.2.8.3 Test purpose

To test that where an SDU exactly fills a PU, an LI of value zero is placed as the first LI in the next PU.

## 7.2.2.8.4 Method of test

## Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for UM 15-bit length indicator tests in Clause 7.2.2.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into loop-back mode 1 with the UL SDU size set to 160 bytes.

## Test procedure

- a) The SS transmits an RLC SDU of size 320 bytes.
- b) The SS checks the length indicator sizes and values of the RLC PDUs returned on the uplink, and checks the length and content of the received RLC SDU.
- c) The SS may optionally release the radio bearer.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures
2	←		DOWNLINK RLC PDU	SDU 1
3	←		DOWNLINK RLC PDU	SDU 1
4	←		DOWNLINK RLC PDU	LI=0 and padding
5	→		UPLINK RLC PDU	No Lis
6	→		UPLINK RLC PDU	Check Lis and re-assembled SDU
7			RB RELEASE	Optional step

## 7.2.2.8.5 Test requirements

The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have an LI indicating that the SDU exactly filled the previous PU, and an LI indicating that the remainder of the PDU contains padding.

The length of the received SDU should be 160 bytes, and the data content the same as the first 160 bytes of the transmitted SDU.

## 7.2.2.9 Segmentation / 15-bit Length Indicators / One octet short LI

## 7.2.2.9.1 Definition

Tests the behaviour of the RLC when 15-bit length indicators are used, and an SDU fills a PU to one byte short of the payload size.

This test applies to all UE that support packet data.

#### 7.2.2.9.2 Conformance requirement

In the case where the last segment of an RLC SDU is one octet short of exactly filling the last RLC PU, and 15-bit Length Indicators are used, the next Length Indicator shall be placed as the first Length Indicator in the next PU and have value LI=111 1111 1111 1011.

#### Reference(s)

TS 25.322 Clause 9.2.2.8.

#### 7.2.2.9.3 Test purpose

To test that where an SDU is one byte short of filling a PU, an LI indicating one byte short is placed as the first LI in the next PU.

#### 7.2.2.9.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for UM 15-bit length indicator tests in Clause 7.2.2.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into loop-back mode 1 with the UL SDU size set to 159 bytes.

##### Test procedure

- a) The SS transmits an RLC SDU of size 320 bytes.
- b) The SS checks the length indicator sizes and values of the RLC PDUs returned on the uplink, and checks the length and content of the received RLC SDU.
- c) The SS may optionally release the radio bearer.

##### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures
2		←	DOWNLINK RLC PDU	SDU 1
3		←	DOWNLINK RLC PDU	SDU 1
4		←	DOWNLINK RLC PDU	LI=0 and padding
5		→	UPLINK RLC PDU	No Lis
6		→	UPLINK RLC PDU	Check Lis and re-assembled SDU
7			RB RELEASE	Optional step

#### 7.2.2.9.5 Test requirements

The UE shall return two RLC PDUs. The first shall have no Lis. The second shall have an LI indicating that the SDU was one byte short of filling the previous PU, and an LI indicating that the remainder of the PDU contains padding.

The length of the received SDU should be 159 bytes, and the data content the same as the first 159 bytes of the transmitted SDU.

## 7.2.2.10 Segmentation / 15-bit Length Indicators / LI value > PDU size

### 7.2.2.10.1 Definition

Tests the behaviour of the RLC when a PDU contains an invalid length indicator.

This test applies to all UE.

### 7.2.2.10.2 Conformance requirement

If the length indicator of a PDU has a value that is larger than the PDU size, the PDU shall be discarded and treated as a missing PDU.

If a PDU with sequence number < VR(US) is missing then all SDUs that have segments in this PDU shall be discarded.

### Reference(s)

TS 25.322 Clauses 11.2.4.2 and 11.2.3.

### 7.2.2.10.3 Test purpose

To test that PDUs with length indicators that point beyond the end of the PDU are discarded by the receiving RLC.

### 7.2.2.10.4 Method of test

#### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for UM 15-bit length indicator tests in Clause 7.2.2.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into loop-back mode 1 with the UL SDU size set to 220 bytes.

#### Test procedure

- The SS transmits three RLC SDUs of size 220 bytes. All the SDUs are concatenated or segmented over successive RLC PDUs. In the third PDU for transmission, the SS sets value of the length indicator to be 161 (decimal).
- The SS checks the length indicator sizes and values of the RLC PDUs returned on the uplink, and checks the length and content of the received RLC SDUs.
- The SS may optionally release the radio bearer.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures
2		←	DOWNLINK RLC PDU	SDU 1
3		←	DOWNLINK RLC PDU	SDU 1 & SDU 2
4		←	DOWNLINK RLC PDU	SDU 2 & SDU 3, with bad LI
5		←	DOWNLINK RLC PDU	SDU 3
6		←	DOWNLINK RLC PDU	SDU 3 and padding
7		→	UPLINK RLC PDU	SDU 1
8		→	UPLINK RLC PDU	SDU 1 and padding: Check Lis and re-assembled SDU
9			RB RELEASE	Optional step

#### 7.2.2.10.5 Test requirements

The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have a LI indicating the end of an SDU and an LI indicating that the remainder of the PDU contains padding.

The length and data content of the received SDU should be the same as the first transmitted SDU. No further SDUs or PDUs should be received.

## 7.2.3 Acknowledged mode

### 7.2.3.1 General information for AM tests

A generic Radio Access Bearer is provided for AM tests. This RAB is based upon the Stand-alone 3.4kbps UL/DL Signalling RB, with an additional AM 3.4kbps path mapped to a DTCH. This logical channel is multiplexed on the same transport channel as the DCCH.

The AM test RAB is set up using the Generic Procedure described in Clause 7.1.3 of TS 34.108, and with the default RAB replaced as shown in Tables 7.2/3A and 7.23B:



Higher layer	RAB/signalling RB		SRB#1	SRB#2	SRB#3	SRB#4	RAB #1
	User of Radio Bearer		RRC	RRC	NAS_DT High prio	NAS_DT Low prio	User Plane
RLC	Logical channel type		DCCH	DCCH	DCCH	DCCH	DTCH
	RLC mode		UM	AM	AM	AM	AM
	Payload sizes, bit		136	128	128	128	128
	Max data rate, bps		3400	3200	3200	3200	3200
	RLC header, bit		8	16	16	16	16
MAC	MAC header, bit		4	4	4	4	4
	MAC multiplexing		4 logical channel multiplexing				
Layer 1	TrCH type		DCH				
	TB sizes, bit		148				
	TFS	TF0, bts	0				
		TF1, bits	1x148				
	TTI, ms		40				
	Coding type		CC 1/3				
	CRC, bit		16				
	Max number of bits/TTI before rate matching		516				
	Uplink: Max number of bits/radio frame before rate matching		129				

**Table 7.2/3A RAB Configuration for AM testing (7-bit Lis)**

Unless specified in individual test cases, the default RLC settings are given in Table 7.2/3.

Uplink RLC	
Transmission RLC discard	
Max DAT retransmissions	
Max_DAT	4
Transmission window size	128
Timer_RST	500
Max_RST	4
Polling info	
Timer_poll_prohibit	disabled
Timer_poll	disabled
Poll_PU	disabled
Poll_SDU	disabled
Last transmission PU poll	TRUE
Last retransmission PU poll	TRUE
Poll_Window	disabled
Timer_poll_periodic	disabled
Downlink RLC	
In-sequence delivery	TRUE
Receiving window size	128
Timer_Status_Prohibit	disabled
Timer_EPC	disabled
Missing PU Indicator	TRUE
Timer_STATUS_periodic	disabled

**Table 7.2/3B RLC Parameters for AM testing**

The AM test RAB is used in all tests with the following exceptions:

- Tests that only involve 15-bit length indicators
- Tests that explicitly specify a different Radio Bearer configuration

Tests that involve only 15-bit length indicators require a modified Radio Bearer configuration. To accommodate the larger payload size, these tests use a coded composite transport channel consisting of two DCH. The first DCH is specified as for the 7-bit length indicators, but not including the DTCH (RAB#1). This is shown in Table 7.2/4A

Higher layer	Signalling RB: <b>DCH 0</b>		<b>SRB#1</b>	<b>SRB#2</b>	<b>SRB#3</b>	<b>SRB#4</b>
	User of Radio Bearer		RRC	RRC	NAS_DT High prio	NAS_DT Low prio
RLC	Logical channel type		DCCH	DCCH	DCCH	DCCH
	RLC mode		UM	AM	AM	AM
	Payload sizes, bit		136	128	128	128
	Max data rate, bps		3400	3200	3200	3200
	RLC header, bit		8	16	16	16
MAC	MAC header, bit		4	4	4	4
	MAC multiplexing		4 logical channel multiplexing			
Layer 1	TrCH type		DCH			
	TB sizes, bit		148			
	TFS	TF0, bts	0			
		TF1, bits	1x148			
	TTI, ms		40			
	Coding type		CC 1/3			
	CRC, bit		16			
	Max number of bits/TTI before rate matching		516			
	Uplink: Max number of bits/radio frame before rate matching		129			

Table 7.2/4A SRB Configuration for AM testing (15-bit Lis)

This DCH is combined with a traffic DCH (at lower MAC priority) as described in Table 7.2/4B

Higher layer	RAB: <b>DCH 1</b>		<b>RAB</b>			
RLC	Logical channel type		DTCH			
	RLC mode		AM			
	Payload sizes, bit		1280			
	Max data rate, bps		64000			
	RLC header, bit		16			
MAC	MAC header, bit		0			
	MAC multiplexing		N/A			
Layer 1	TrCH type		DCH			
	TB sizes, bit		1296			
	TFS	TF0, bits	0			
		TF1, bits	1x1296			
	TTI, ms		20			
	Coding type		TC			
	CRC, bit		16			

Table 7.2/4B RAB Configuration for UM testing (15-bit Lis)

All other settings are the same.

### 7.2.3.2 Segmentation and reassembly / Selection of 7 or 15 bit Length Indicators

#### 7.2.3.2.1 Definition

For RLC PDUs smaller than 124 bytes in length, the UE RLC should assume received PDUs have 7-bit length indicators, and for PDUs of 124 bytes and larger the UE should assume 15-bit length indicators. The UE should also add the same size length indicators to outgoing RLC PDUs.

This requirement applies to all UE that support RLC PDU sizes of 124 bytes or greater.

### 7.2.3.2.2 Conformance requirement

The size of the Length Indicator may be either 7bits or 15bits.

If RLC PDUs always carry only one PU, 7bit indicators are used in a particular RLC PDU if the address space is sufficient to indicate all SDU segment borders. Otherwise 15bit Length Indicators are applied.

The length of the Length Indicator only depends on the size of the largest RLC PDU. The length of the Length Indicator is always the same for all PUs, for one RLC entity.

RLC SDUs might be segmented. If possible, the last segment of a SDU shall be concatenated with the first segment of the next SDU in order to fill the data field completely and avoid unnecessary padding

### Reference(s)

TS 25.322 Clauses 9.2.2.8, 9.2.2.9

### 7.2.2.2.3 Test purpose

To test that if PDU carries a single PU, and the PU size is small enough that a 7 bit indicator is sufficient, 7 bit indicators are used, otherwise, 15 bit indicators are used.

### 7.2.3.2.4 Method of test

#### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the following exceptions:

Higher layer	RAB/Signalling RB		RAB
RLC	Logical channel type		DTCH
	RLC mode		AM
	Payload sizes, bit		960
	Max data rate, bps		48000
	RLC header, bit		16
MAC	MAC header, bit		0
	MAC multiplexing		N/A
Layer 1	TrCH type		DCH
	TB sizes, bit		976
	TFS	TF0, bits	0
		TF1, bits	1x976
	TTI, ms		20
	Coding type		TC
	CRC, bit		16

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into loop-back mode 1 with the UL SDU size set to 40 bytes.

### Test procedure

- The SS transmits an RLC SDU of size 80 bytes. The PDU carrying this SDU is transmitted with a poll for status.
- The SS checks the length indicator sizes and values of the RLC PDU returned on the uplink.

c) The SS reconfigures the Transport Channel as follows:

Higher layer	RAB/Signalling RB		RAB
RLC	Logical channel type		DTCH
	RLC mode		AM
	Payload sizes, bit		1280
	Max data rate, bps		64000
	RLC header, bit		16
MAC	MAC header, bit		0
	MAC multiplexing		N/A
Layer 1	TrCH type		DCH
	TB sizes, bit		1296
	TFS	TF0, bits	0
		TF1, bits	1x1296
	TTI, ms		20
	Coding type		TC
	CRC, bit		16

All other settings the same.

- d) The SS transmits an RLC SDUs of size 80 bytes. The PDU carrying this SDU is transmitted with a poll for status.
- e) The SS checks the length indicator sizes and values of the RLC PDU returned on the uplink
- f) The SS may optionally release the radio bearer.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures 80 byte SDU + padding + poll 40 byte SDU + piggy-backed status + poll <i>If piggy-backed status is not used in 3</i>
2		←	DOWNLINK RLC PDU	
3		→	UPLINK RLC PDU	
3a		→	STATUS PDU	
4		←	STATUS PDU	
5		←	TRANSPORT CHANNEL RECONFIGURATION	PU size > 127 bytes
6		←	DOWNLINK RLC PDU	80 byte SDU + padding + poll 40 byte SDU + piggy-backed status + poll <i>If piggy-backed status is not used in 7</i>
7		→	UPLINK RLC PDU	
7a		→	STATUS PDU	
8		←	STATUS PDU	
9			RB RELEASE	Optional step

#### 7.2.3.2.5 Test requirements

The UE shall send 7 bit length indicators with values that correctly indicate the end of SDU in step b).

The UE shall send 15 bit length indicators with values that correctly indicate the end of SDU in step e).

### 7.2.3.3 Segmentation / 7-bit Length Indicators / Padding or Piggy-backed Status

#### 7.2.3.3.1 Definition

The RLC segments SDUs into blocks according to the configured payload unit size. Length indicators are added to indicate: the boundaries of SDUs within a PU, the addition of padding bytes.

This test applies to all UE.

#### 7.2.3.3.2 Conformance requirement

The Length Indicator is used to indicate, each time, the end of an SDU occurs in the PU. The Length Indicator points out the number of octets between the end of the last Length Indicator field and up to and including the octet at the end of an SDU segment

A PU that has unused space, to be referred to as padding, must use a Length Indicator to indicate that this space is used as padding. A padding Length Indicator must be placed after any Length Indicators for a PU.

If padding or piggybacking is added another length indicator shall be added, see subclause 9.2.2.8

#### Reference(s)

TS 25.322 Clauses 9.2.2.8 and 11.3.2.1.2.

#### 7.2.3.3.3 Test purpose

To test that a large SDU is correctly segmented and padding added at the end.

#### 7.2.3.3.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into loop-back mode 1 with the UL SDU size set to 17 bytes.

##### Test procedure

- a) The SS transmits an RLC SDU of size 17 bytes, and polls the receiver for status.
- b) The SS checks the length indicator sizes and values of the RLC PDU returned on the uplink, and checks the length and content of the received RLC SDU.
- c) The SS may optionally release the radio bearer.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures
2		←	DOWNLINK RLC PDU	SDU 1
3		←	DOWNLINK RLC PDU	SDU 1 +poll + Padding
4		→	UPLINK RLC PDU	No LI
5		→	UPLINK RLC PDU	Check Lis and re-assembled SDU
5a		→	STATUS PDU	<i>If piggy-backed status is not used in 5</i>
6		←	STATUS PDU	
7			RB RELEASE	Optional step

#### 7.2.3.3.5 Test requirements

The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have a LI indicating the PDU contains an SDU boundary after octet 1 of the data field, and the second shall indicate either that the remainder of the PDU contains padding, or that it contains a piggy-backed status PDU.

The length and data content of the received SDU should be the same as the transmitted SDU.

#### 7.2.3.4 Segmentation / 7-bit Length Indicators / LI = 0

##### 7.2.3.4.1 Definition

Tests the behaviour of the RLC when an SDU exactly fills a PU.

This test applies to all UE.

##### 7.2.3.4.2 Conformance requirement

If the PDU is exactly filled with the last segment of a SDU and there is no room for a length indicator field a length indicator field set to only 0's shall be included in the next PDU.

##### Reference(s)

TS 25.322 Clause 11.3.2.1.

##### 7.2.3.4.3 Test purpose

To test that where an SDU exactly fills a PU, an LI of value zero is placed as the first LI in the next PU.

##### 7.2.3.4.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into loop-back mode 1 with the UL SDU size set to 16 bytes.

## Test procedure

- a) The SS transmits an RLC SDU of size 32 bytes. The SS polls the receiver for status in the last RLC PDU sent.
- b) The SS checks the length indicator sizes and values of the RLC PDUs returned on the uplink, and checks the length and content of the received RLC SDU.
- c) The SS may optionally release the radio bearer.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures
2		←	DOWNLINK RLC PDU	SDU 1
3		←	DOWNLINK RLC PDU	SDU 1
4		←	DOWNLINK RLC PDU	LI=0, poll and padding
5		→	UPLINK RLC PDU	No Lis
6		→	UPLINK RLC PDU	(Poll) Check Lis and re-assembled SDU
6a		→	STATUS PDU	<i>If piggy-backed status is not used in 6</i>
7		←	STATUS PDU	
8			RB RELEASE	Optional step

## 7.2.3.4.5 Test requirements

The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have an LI indicating that the SDU exactly filled the previous PU, and an LI indicating either that the remainder of the PDU contains padding, or that it contains a piggy-backed STATUS PDU.

The length of the received SDU should be 16 bytes, and the data content the same as the first 16 bytes of the transmitted SDU.

## 7.2.3.5 Segmentation / 7-bit Length Indicators / Reserved LI value

## 7.2.3.5.1 Definition

Tests the behaviour of the RLC when a PDU contains an invalid length indicator.

This test applies to all UE.

## 7.2.3.5.2 Conformance requirement

Upon reception of an AMD PDU that contains Length Indicator value “1111100” or “1111101”: PDUs with this coding will be discarded by this version of the protocol.

## Reference(s)

TS 25.322 Clause 9.2.2.8.

## 7.2.3.5.3 Test purpose

To test that PDUs with reserved length indicators are discarded by the receiving RLC.

#### 7.2.3.5.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

The following RLC parameter values are used in place of the values in Clause 7.2.3.1:

Downlink RLC Timer_STATUS_periodic	200
---------------------------------------	-----

These settings apply to both the uplink and downlink DTCH.

##### Test procedure

- The SS transmits two RLC SDUs of size 24 bytes. In the second PDU, the SS sets the value of the LI to 1111100. In the fourth PDU for transmission, the SS sets the value of the second (padding) LI to 1111101.
- The SS waits to receive a status report from the UE.
- The SS may optionally release the radio bearer.

##### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures
2	←		DOWNLINK RLC PDU #0	SDU 1
3	←		DOWNLINK RLC PDU #1	SDU 1 + SDU 2, LI = 1111100
4	←		DOWNLINK RLC PDU #2	SDU 2
5	←		DOWNLINK RLC PDU #3	SDU 2 + poll, second LI = 1111101
6	→		STATUS PDU	Nack PDUs 1 and 3
7			RB RELEASE	Optional step

#### 7.2.3.5.5 Test requirements

The UE shall return a STATUS PDU indicating that PDUs with sequence numbers 1 and 3 were incorrectly received.

### 7.2.3.6 Segmentation / 7-bit Length Indicators / LI value > PDU size

#### 7.2.3.6.1 Definition

Tests the behaviour of the RLC when a PDU contains an invalid length indicator.

This test applies to all UE.

#### 7.2.3.6.2 Conformance requirement

If the length indicator of a PDU has a value that is larger than the PDU size, the PDU shall be discarded and treated as a missing PDU.



## Reference(s)

TS 25.322 Clause 11.3.4.5.

## 7.2.3.6.3 Test purpose

To test that PDUs with length indicators that point beyond the end of the PDU are discarded by the receiving RLC.

## 7.2.3.6.4 Method of test

## Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

These settings apply to both the uplink and downlink DTCH.

## Test procedure

- a) The SS transmits three RLC SDUs of size 23 bytes. All the SDUs are concatenated or segmented over successive RLC PDUs. In the third PDU for transmission, the SS sets value of the length indicator to be 17 (decimal).
- b) The SS checks the length indicator sizes and values of the RLC PDUs returned on the uplink, and checks the length and content of the received RLC SDUs.
- c) The SS may optionally release the radio bearer.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures
2		←	DOWNLINK RLC PDU #0	SDU 1
3		←	DOWNLINK RLC PDU #1	SDU 1 & SDU 2
4		←	DOWNLINK RLC PDU #2	SDU 2 & SDU 3, with bad LI
5		←	DOWNLINK RLC PDU #3	SDU 3
6		←	DOWNLINK RLC PDU #4	SDU 3, poll and padding
7		→	STATUS PDU	Nack PDU #2
8			RB RELEASE	Optional step

## 7.2.3.6.5 Test requirements

The UE shall indicate that the PDU with sequence number 2 was not received correctly.

## 7.2.3.7 Segmentation / 15-bit Length Indicators / Padding or Piggy-backed Status

## 7.2.3.7.1 Definition

The RLC segments SDUs into blocks according to the configured payload unit size. Length indicators are added to indicate: the boundaries of SDUs within a PU, the addition of padding bytes.

This test applies to all UE.

### 7.2.3.7.2 Conformance requirement

The Length Indicator is used to indicate, each time, the end of an SDU occurs in the PU. The Length Indicator points out the number of octets between the end of the last Length Indicator field and up to and including the octet at the end of an SDU segment

A PU that has unused space, to be referred to as padding, must use a Length Indicator to indicate that this space is used as padding. A padding Length Indicator must be placed after any Length Indicators for a PU.

If padding or piggybacking is added another length indicator shall be added, see subclause 9.2.2.8

### Reference(s)

TS 25.322 Clauses 9.2.2.8 and 11.3.2.1.2.

### 7.2.3.7.3 Test purpose

To test that a large SDU is correctly segmented and padding added at the end.

### 7.2.3.7.4 Method of test

#### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 15-bit length indicator tests in Clause 7.2.3.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into loop-back mode 1 with the UL SDU size set to 161 bytes.

#### Test procedure

- a) The SS transmits an RLC SDU of size 161 bytes, and polls the receiver for status.
- b) The SS checks the length indicator sizes and values of the RLC PDU returned on the uplink, and checks the length and content of the received RLC SDU.
- c) The SS may optionally release the radio bearer.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures SDU 1 SDU 1 +poll + Padding No LI Check Lis and re-assembled SDU <i>If piggy-backed status is not used in 5</i>
2	←		DOWNLINK RLC PDU	
3	←		DOWNLINK RLC PDU	
4	→		UPLINK RLC PDU	
5	→		UPLINK RLC PDU	
5a	→		STATUS PDU	Optional step
6	←		STATUS PDU	
7			RB RELEASE	

#### 7.2.3.7.5 Test requirements

The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have a LI indicating the PDU contains an SDU boundary after octet 1 of the data field, and the second shall indicate either that the remainder of the PDU contains padding, or that it contains a piggy-backed status PDU.

The length and data content of the received SDU should be the same as the transmitted SDU.

### 7.2.3.8 Segmentation / 15-bit Length Indicators / LI = 0

#### 7.2.3.8.1 Definition

Tests the behaviour of the RLC when an SDU exactly fills a PU.

This test applies to all UE.

#### 7.2.3.8.2 Conformance requirement

If the PDU is exactly filled with the last segment of a SDU and there is no room for a length indicator field a length indicator field set to only 0's shall be included in the next PDU.

#### Reference(s)

TS 25.322 Clause 11.3.2.1.

#### 7.2.3.8.3 Test purpose

To test that where an SDU exactly fills a PU, an LI of value zero is placed as the first LI in the next PU.

#### 7.2.3.8.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 15-bit length indicator tests in Clause 7.2.3.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into loop-back mode 1 with the UL SDU size set to 160 bytes.

##### Test procedure

- a) The SS transmits an RLC SDU of size 320 bytes. The SS polls the receiver for status in the last RLC PDU sent.
- b) The SS checks the length indicator sizes and values of the RLC PDUs returned on the uplink, and checks the length and content of the received RLC SDU.
- c) The SS may optionally release the radio bearer.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures
2		←	DOWNLINK RLC PDU	SDU 1
3		←	DOWNLINK RLC PDU	SDU 1
4		←	DOWNLINK RLC PDU	LI=0, poll and padding
5		→	UPLINK RLC PDU	No Lis
6		→	UPLINK RLC PDU	(Poll) Check Lis and re-assembled SDU
6a		→	STATUS PDU	<i>If piggy-backed status is not used in 6</i>
7		←	STATUS PDU	
8			RB RELEASE	Optional step

#### 7.2.3.8.5 Test requirements

The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have an LI indicating that the SDU exactly filled the previous PU, and an LI indicating either that the remainder of the PDU contains padding, or that it contains a piggy-backed STATUS PDU.

The length of the received SDU should be 160 bytes, and the data content the same as the first 160 bytes of the transmitted SDU.

### 7.2.3.9 Segmentation / 15-bit Length Indicators / One octet short LI

#### 7.2.3.9.1 Definition

Tests the behaviour of the RLC when 15-bit length indicators are used, and an SDU fills a PU to one byte short of the payload size.

This test applies to all UE.

#### 7.2.3.9.2 Conformance requirement

In the case where the last segment of an RLC SDU is one octet short of exactly filling the last RLC PU, and 15-bit Length Indicators are used, the next Length Indicator shall be placed as the first Length Indicator in the next PU and have value LI=111 1111 1111 1011.

#### Reference(s)

TS 25.322 Clause 9.2.2.8.

#### 7.2.3.9.3 Test purpose

To test that where an SDU is one byte short of filling a PU, an LI indicating one byte short is placed as the first LI in the next PU.

#### 7.2.3.9.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 15-bit length indicator tests in Clause 7.2.3.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into loop-back mode 1 with the UL SDU size set to 159 bytes.

### Test procedure

- a) The SS transmits an RLC SDU of size 320 bytes. The SS polls the receiver for status in the last RLC PDU sent.
- b) The SS checks the length indicator sizes and values of the RLC PDUs returned on the uplink, and checks the length and content of the received RLC SDU.
- c) The SS may optionally release the radio bearer.

### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures
2		←	DOWNLINK RLC PDU	SDU 1
3		←	DOWNLINK RLC PDU	SDU 1
4		←	DOWNLINK RLC PDU	LI=0, poll and padding
5		→	UPLINK RLC PDU	No Lis
6		→	UPLINK RLC PDU	(Poll) Check Lis and re-assembled SDU
6a		→	STATUS PDU	<i>If piggy-backed status is not used in 6</i>
7		←	STATUS PDU	
8			RB RELEASE	Optional step

#### 7.2.3.9.5 Test requirements

The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have an LI indicating that the SDU was one byte short of filling the previous PU, and an LI indicating that the remainder of the PDU contains padding.

The length of the received SDU should be 159 bytes, and the data content the same as the first 159 bytes of the transmitted SDU.

### 7.2.3.10 Segmentation / 15-bit Length Indicators / Reserved LI value

#### 7.2.3.10.1 Definition

Tests the behaviour of the RLC when a PDU contains an invalid length indicator.

This test applies to all UE.

#### 7.2.3.10.2 Conformance requirement

Upon reception of an AMD PDU that contains Length Indicator value “111111111111100” or “111111111111101”: PDUs with this coding will be discarded by this version of the protocol.

#### Reference(s)

TS 25.322 Clause 9.2.2.8.

#### 7.2.3.10.3 Test purpose

To test that PDUs with reserved length indicators are discarded by the receiving RLC.

## 7.2.3.10.4 Method of test

## Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 15-bit length indicator tests in Clause 7.2.3.1.

The following RLC parameter values are used in place of the values in Clause 7.2.3.1:

Downlink RLC Timer_STATUS_periodic	200
---------------------------------------	-----

These settings apply to both the uplink and downlink DTCH.

## Test procedure

- The SS transmits two RLC SDUs of size 240 bytes. In the second PDU, the SS sets the value of the LI to 111111111111100. In the fourth PDU for transmission, the SS sets the value of the second (padding) LI to 111111111111101.
- The SS waits to receive a status report from the UE.
- The SS may optionally release the radio bearer.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures
2	←		DOWNLINK RLC PDU #0	SDU 1
3	←		DOWNLINK RLC PDU #1	SDU 1 + SDU 2, LI = 111111111111100
4	←		DOWNLINK RLC PDU #2	SDU 2
5	←		DOWNLINK RLC PDU #3	SDU 2 + poll, second LI = 111111111111101
6	→		STATUS PDU	Nack PDUs 1 and 3
7			RB RELEASE	Optional step

## 7.2.3.10.5 Test requirements

The UE shall return a STATUS PDU indicating that PDUs with sequence numbers 1 and 3 were incorrectly received.

## 7.2.3.11 Segmentation / 15-bit Length Indicators / LI value &gt; PDU size

## 7.2.3.11.1 Definition

Tests the behaviour of the RLC when a PDU contains an invalid length indicator.

This test applies to all UE.

## 7.2.3.11.2 Conformance requirement

If the length indicator of a PDU has a value that is larger than the PDU size, the PDU shall be discarded and treated as a missing PDU.

## Reference(s)

TS 25.322 Clause 11.3.4.5.

## 7.2.3.11.3 Test purpose

To test that PDUs with length indicators that point beyond the end of the PDU are discarded by the receiving RLC.

## 7.2.3.11.4 Method of test

## Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 15-bit length indicator tests in Clause 7.2.3.1.

These settings apply to both the uplink and downlink DTCH.

## Test procedure

- a) The SS transmits three RLC SDUs of size 230 bytes. All the SDUs are concatenated or segmented over successive RLC PDUs. In the third PDU for transmission, the SS sets value of the length indicator to be 161 (decimal).
- b) The SS checks the length indicator sizes and values of the RLC PDUs returned on the uplink, and checks the length and content of the received RLC SDUs.
- c) The SS may optionally release the radio bearer.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures
2		←	DOWNLINK RLC PDU #0	SDU 1
3		←	DOWNLINK RLC PDU #1	SDU 1 & SDU 2
4		←	DOWNLINK RLC PDU #2	SDU 2 & SDU 3, with bad LI
5		←	DOWNLINK RLC PDU #3	SDU 3
6		←	DOWNLINK RLC PDU #4	SDU 3, poll and padding
7		→	STATUS PDU	Nack PDU #2
8			RB RELEASE	Optional step

## 7.2.3.11.5 Test requirements

The UE shall indicate that the PDU with sequence number 2 was not received correctly.

## 7.2.3.12 Correct use of Sequence Numbering

## 7.2.3.12.1 Definition

Peer RLC entities use sequence numbering to detect missing PDUs, and for flow control purposes. This test checks that in basic, normal operation, the sequence numbering is interpreted correctly and applied correctly by the UE RLC layer.

This test applies to all UE.

### 7.2.3.12.2 Conformance requirement

PUs are sequentially and independently numbered and may have the value 0 through  $n - 1$  (where  $n$  is the modulus of the sequence numbers). The modulus equals  $2^{12}$  for AM ...; the sequence numbers cycle through the entire range: 0 through  $2^{12} - 1$  for AM.

If the PDU is transmitted for the first time, the Sequence Number field shall be set equal to VT(S) and VT(S) shall be updated

#### Reference(s)

TS 25.322, Clauses 9.4 and 11.3.2.1.

### 7.2.3.12.3 Test purpose

1. To verify that the UE transmits the first PDU with the Sequence Number field equal to 0.
2. To verify that the UE increments the Sequence Number field according to the number of PUs transmitted.
3. To verify that the UE wraps the Sequence Number after transmitting the  $2^{12}$ -1th PU.

### 7.2.3.12.4 Method of test

#### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

The following RLC parameter values are used in place of the values in Clause 7.2.3.1:

Uplink RLC Transmission window size	4096
Downlink RLC Receiving window size	4096

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in loop-back mode 1 with the UL SDU size set to 31 bytes.

#### Test procedure

- a) The SS sends 2048 RLC SDUs to the UE, each of 31 bytes. The SS polls for status on each 128<sup>th</sup> RLC PDU transmitted
- b) The SS checks the sequence numbers of the RLC PDUs it receives in the uplink
- c) The SS checks the content of the SDUs it receives from the UE.
- d) The SS may optionally release the radio bearer.



Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures
2	←		DOWNLINK RLC PDU #0	
3	←		DOWNLINK RLC PDU #1	
			...	Transmission of DOWNLINK PDUs continues
4	→		UPLINK RLC PDU	
5	→		UPLINK RLC PDU	
	→		...	
6	←		DOWNLINK RLC PDU #4095	SN should be set to 0 SN should be set to 1 Transfer of RLC PDUs continues to SN = 4 095
7	←		DOWNLINK RLC PDU #0	
8	→		UPLINK RLC PDU	SN should be set to 4095 SN should be set to 0 Optional step
9	→		UPLINK RLC PDU	
10			RB RELEASE	

#### 7.2.3.12.5 Test requirements

The first PDU received should have the SN field set to 0. The second PDU should have the SN field set to 1, and the 4 096<sup>th</sup> PDU should have the SN field set to 0.

The size and data content of the received SDUs shall match those of the transmitted SDUs.

### 7.2.3.13 Control of Transmit Window

#### 7.2.3.13.1 Definition

This test is to check that the UE is able to correctly control its RLC transmission window. Correct operation of RLC windowing is critical for acknowledged mode operation.

This test applies to all UE.

#### 7.2.3.13.2 Conformance requirement

The transmitter shall not transmit a new PU if  $VT(S) \geq VT(MS)$ .

#### Reference(s)

TS 25.322, Clause 9.4.

#### 7.2.3.13.3 Test purpose

1. To verify that the UE does not transmit PUs with sequence numbers outside of the transmit window.

#### 7.2.3.13.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

The following RLC parameter values are used in place of the values in Clause 7.2.3.1:

Uplink RLC Transmission window size	8
Downlink RLC Missing PU Indicator Receiving window size	FALSE 8

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in loop-back mode 1 with the UL SDU size set to 15 bytes.

### Test procedure

Let  $W$  be the size of the transmit window.

The length of all transmitted SDUs is set to 15 bytes.

- The SS transmits  $3*W$  RLC SDUs to the UE, polling regularly.
- The SS checks the RLC SDUs received on the uplink, but does not reply to poll requests from the UE, or transmit STATUS PDUs for any other reason.
- After confirming that the UE has stopped transmitting RLC SDUs for at least  $(2*W*TTI)$  ms, the SS transmits a STATUS PDU acknowledging all the RLC PDUs received so far.
- The SS again checks the RLC SDUs received on the uplink, but does not reply to poll requests from the UE, or transmit further STATUS PDUs for any other reason.
- After confirming that the UE has again stopped transmitting RLC SDUs for at least  $(2*W*TTI)$  ms, the SS transmits a STATUS PDU acknowledging all the RLC PDUs received so far.
- The SS checks the RLC SDUs received on the uplink.
- The SS may optionally release the radio bearer.

NOTE: Window arithmetic is carried out modulo 4096.

The test procedure is run with the window transmit window size set to the default (8), and the repeated with the transmit window size set to 1536.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures
2		←	DOWNLINK RLC PDU	SDU 1
3		←	DOWNLINK RLC PDU	SDU 2
4		←	DOWNLINK RLC PDU	SDU 3
5		←	DOWNLINK RLC PDU	SDU 4
6		←	...	SS continues to transmit RLC SDUs
7		←	DOWNLINK RLC PDU	SDU 3W
8		→	UPLINK RLC PDU	SDU 1
9		→	UPLINK RLC PDU	SDU 2
10		→	...	SS continues to receive RLC SDUs
11		→	UPLINK RLC PDU	SDU W
12				No transmissions from UE
13		←	STATUS PDU	
14		→	UPLINK RLC PDU	SDU W+1
15		→	UPLINK RLC PDU	SDU W+2
16		→	...	SS continues to receive RLC SDUs
17		→	UPLINK RLC PDU	SDU 2W
18				No transmissions from UE
19		←	STATUS PDU	
20		→	UPLINK RLC PDU	SDU 2W+1
21		→	UPLINK RLC PDU	SDU 2W+2
22		←	...	SS continues to receive RLC SDUs
23		→	UPLINK RLC PDU	SDU 3W
24			RB RELEASE	Optional step

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

### 7.2.3.13.5 Test requirements

From steps 8 to 11, the SDU contents reassembled from the uplink shall match those of the first W transmitted SDUs.

At step 12 there shall be no further transmission on the uplink DTCH whilst the SS is waiting.

After step 13, the UE shall resume transmission of the next W SDUs. The contents of these SDUs shall match those of SDUs W+1 to 2\*W sent on the downlink.

At step 18 there shall be no further transmission on the uplink DTCH whilst the SS is waiting.

After step 19, the UE shall resume transmission of the next W SDUs. The contents of these SDUs shall match those of SDUs 2\*W+1 to 3\*W sent on the downlink.

### 7.2.3.14 Control of Receive Window

#### 7.2.3.14.1 Definition

This test is to check that the UE is able to correctly control its RLC receive window. Correct operation of RLC windowing is critical for acknowledged mode operation.

This test applies to all UE.

#### 7.2.3.14.2 Conformance requirement

Upon reception of a PU with  $SN < VR(R)$  or  $SN \geq VR(MR)$  the receiver shall discard the PU.

#### Reference(s)

TS 25.32, Clause 11.3.4.2.

#### 7.2.3.14.3 Test purpose

1. To verify that the UE discards PUs with sequence numbers outside of the receive window.

#### 7.2.3.14.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

The following RLC parameter values are used in place of the values in Clause 7.2.3.1:

Uplink RLC Transmission window size	8
Downlink RLC Missing PU Indicator Receiving window size	FALSE 8

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in loop-back mode 1 with the UL SDU size set to 15 bytes.

##### Test procedure

Let W be the size of the receive window.

The length of all transmitted SDUs is set to 15 bytes.

- a) The SS transmits  $2 \cdot W$  RLC SDUs to the UE, polling only on the last RLC PDU.
- b) The SS checks the RLC SDUs received on the uplink, and after receiving the STATUS PDU from the UE it transmits a further RLC SDU. The SS sets the sequence numbers for the associated RLC PDU above the top of the receive window, for example,  $2 \cdot W + 1$ .
- c) The SS transmits a further RLC SDU with the sequence number set to the value of the next sequence number within the receive window.
- d) The SS checks the RLC SDUs received on the uplink.
- e) The SS may optionally release the radio bearer.

This test case is run once for the default receive window size (8) and again with the receive window size set to 1536.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures
2		←	DOWNLINK RLC PDU	SDU 1
3		←	DOWNLINK RLC PDU	SDU 2
4		←	...	SS continues to transmit RLC SDUs
5		←	DOWNLINK RLC PDU	SDU 2W + Poll
6		→	STATUS PDU	
7		→	UPLINK RLC PDU	SDU 1
8		→	UPLINK RLC PDU	SDU 2
9			...	UE continues to transmit RLC SDUs
10		→	UPLINK RLC PDU	SDU W
11		←	DOWNLINK RLC PDU	SDU 2W+1, SN = 2W+1
12		←	DOWNLINK RLC PDU	SDU 2W+2, SN = W+1
13		→	UPLINK RLC PDU	SDU 2W+2
14			RB RELEASE	Optional step

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

#### 7.2.3.14.5 Test requirements

The SS shall receive back SDUs 1 to W, and SDU 2\*W + 2 only. No other SDUs shall be looped back.

### 7.2.3.15 Polling for status / Last PU in transmission queue

#### 7.2.3.15.1 Definition

This case tests that the UE will poll for a status request on the last PU in its transmission queue when that mode is enabled. Incorrect operation of polling will cause degradation of service, or at worst service failure.

This test applies to all UE.

#### 7.2.3.15.2 Conformance requirement

The Polling bit shall be set to 1 if any of following conditions are fulfilled except when the poll prohibit function is used and the timer Timer\_Poll\_Prohibit is active:

1. Last PU in buffer is used and the last PU available for transmission is transmitted.

#### Reference

25.322 Clause 11.3.2.1.1.

#### 7.2.3.15.3 Test purpose

1. To verify that a poll is performed when only one PU is available for transmission, and the poll prohibit timer is function is not used.

2. To verify that a poll is performed when only one PU is available for transmission, and the poll prohibit timer is function is used, but inactive.

#### 7.2.3.15.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

The following RLC parameter values are used in place of the values in Clause 7.2.3.1:

Uplink RLC Polling info	First run	Second run
Timer_poll_prohibit	disabled	200
Last transmission PU poll	TRUE	TRUE
Last retransmission PU poll	FALSE	FALSE

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in loop-back mode 1 with the UL SDU size set to 31 bytes.

##### Test procedure

- a) The SS transmits an RLC SDU of length 63 bytes to the UE.
- b) The SS checks the uplink RLC PDUs for a poll for status flag.
- c) The SS may optionally release the radio bearer.

The test is repeated using the RLC parameters given in the Second run column of the configuration table for the initial conditions.

##### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures
2	←		DOWNLINK RLC PDU	SDU 1
3	←		DOWNLINK RLC PDU	SDU 1
4	←		DOWNLINK RLC PDU	SDU 1
5	←		DOWNLINK RLC PDU	SDU 1 + Poll
6	→		STATUS PDU	
7	→		UPLINK RLC PDU	SDU 1
8	→		UPLINK RLC PDU	SDU 1 + Poll
9			RB RELEASE	Optional step

#### 7.2.3.15.5 Test requirements

The Poll bit shall be set in the RLC Header of the PDU returned in step 8.

### 7.2.3.16 Polling for status / Last PU in retransmission queue

#### 7.2.3.16.1 Definition

This case tests that the UE will poll for a status request on the last PU in its retransmission queue when that mode is enabled. Incorrect operation of polling will cause degradation of service, or at worst service failure.

This test applies to all UE.

#### 7.2.3.16.2 Conformance requirement

The Polling bit shall be set to 1 if any of following conditions are fulfilled except when the poll prohibit function is used and the timer Timer\_Poll\_Prohibit is active:

- 1) ...
- 2) Last PU in retransmission buffer is used and the last PU to be retransmitted is transmitted

#### Reference

25.322 Clause 11.3.2.1.1.

#### 7.2.3.16.3 Test purpose

1. To verify that a poll is performed when only one PU is available for retransmission, and the poll prohibit timer is function is not used.
2. To verify that a poll is performed when only one PU is available for retransmission, and the poll prohibit timer is function is used, but inactive.

#### 7.2.3.16.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

The following RLC parameter values are used in place of the values in Clause 7.2.3.1:

Uplink RLC Polling info	First run	Second run
Timer_poll_prohibit	disabled	200
Last transmission PU poll	FALSE	FALSE
Last retransmission PU poll	TRUE	TRUE

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in loop-back mode 1 with the UL SDU size set to 31 bytes.

##### Test procedure

- a) The SS transmits an RLC SDU of length 63 bytes to the UE.
- b) The SS checks the uplink RLC PDUs for a poll for status flag.
- c) The SS transmits a STATUS PDU negatively acknowledging the uplink RLC PDUs as missing.

- d) The SS waits for the RLC PDUs to be retransmitted and then checks the uplink RLC PDUs for a poll for status flag.
- e) The SS may optionally release the radio bearer.

The test is repeated using the RLC parameters given in the Second run column of the configuration table for the initial conditions.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			RB ESTABLISHMENT	See generic procedures
2		←	DOWNLINK RLC PDU	SDU 1
3		←	DOWNLINK RLC PDU	SDU 1
4		←	DOWNLINK RLC PDU	SDU 1
5		←	DOWNLINK RLC PDU	SDU 1 + Poll
6		→	STATUS PDU	
7		→	UPLINK RLC PDU	SDU 1
8		→	UPLINK RLC PDU	SDU 1
9		←	STATUS PDU	NAK: SN=0 and SN=1
10		...		Wait for retransmission
11		→	UPLINK RLC PDU	SDU 1
12		→	UPLINK RLC PDU	SDU 1 + Poll
13			RB RELEASE	Optional step

#### 7.2.3.16.5 Test requirements

The Poll bit shall be set in the RLC Header of the PDU returned in step 12.

#### 7.2.3.17 Polling for status / Poll every Poll\_PU PUs

##### 7.2.3.17.1 Definition

This case tests that the UE will poll for a status request every Poll\_PU PUs when that mode is enabled. Incorrect operation of polling will cause degradation of service, or at worst service failure.

This test applies to all UE.

##### 7.2.3.17.2 Conformance requirement

VT(PU) should be incremented for both new and retransmitted PUs. When it reaches Poll\_PU a new poll is transmitted and the state variable is set to zero.

The Polling bit shall be set to 1 if ... Every Poll\_PU PU is used and when VT(PU)=Poll\_PU

##### Reference

25.322 Clauses 9. 4, 9.6 and 11.3.2.1.1.

##### 7.2.3.17.3 Test purpose

1. To verify that a poll is performed when VT(PU) reaches Poll\_PU.
2. To verify VT(PU) is incremented for both new and retransmitted PUs.



## 7.2.3.17.4 Method of test

## Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

The following RLC parameter values are used in place of the values in Clause 7.2.3.1:

Uplink RLC	
Polling info	
Poll_PU	4
Last transmission PU poll	FALSE
Last retransmission PU poll	FALSE

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in loop-back mode 1 with the UL SDU size set to 15 bytes.

## Test procedure

Let the value of Poll\_PU be P

- The SS sends  $2 * P + 2$  RLC SDUs of size 15 bytes to the UE in PDUs with sequence numbers that are contiguous, starting from zero.
- The SS checks the sequence numbers and polling bits of the RLC SDUs returned on the uplink.
- The SS sends a STATUS PDU negatively acknowledging two RLC PDUs with a sequence numbers of already transmitted PDUs. The other PDUs are acknowledged as received correctly.
- The SS checks the sequence numbers and polling bits of the RLC SDUs returned on the uplink.
- The SS terminates the connection.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	←		DOWNLINK RLC PDU	SDU 1
2	←		DOWNLINK RLC PDU	SDU 2
3	←		...	SS continues to transmit RLC SDUs
4	←		DOWNLINK RLC PDU	SDU 2P+2
5	→		UPLINK RLC PDU	SDU 1
6	→		UPLINK RLC PDU	SDU 2
7	→		...	SS continues to receive RLC SDUs
8	→		UPLINK RLC PDU	SDU P, Poll
9	←		STATUS PDU	NAK SN=0 and SN=1
10	→		UPLINK RLC PDU	SDU 1
11	→		UPLINK RLC PDU	SDU 2
12	→		UPLINK RLC PDU	SDU P+1
13	→		UPLINK RLC PDU	SDU P+2, Poll
14	→		...	SS continues to receive RLC SDUs
15	→		UPLINK RLC PDU	SDU 2*P+2, Poll
16			RB RELEASE	Optional step

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

#### 7.2.3.17.5 Test requirements

The SS shall receive a poll for status in the RLC PDUs sent on the uplink in steps 8, 13 and 15 above.

#### 7.2.3.18 Polling for status / Poll every Poll\_SDU SDUs

##### 7.2.3.18.1 Definition

This case tests that the UE will poll for a status request every Poll\_SDU SDUs when that mode is enabled. Incorrect operation of polling will cause degradation of service, or at worst service failure.

This test applies to all UE.

##### 7.2.3.18.2 Conformance requirement

The state variable VT(SDU) is used when the poll every Poll\_SDU SDU function is used. It is incremented with 1 for each SDU that is transmitted. When it reaches Poll\_SDU a new poll is transmitted and the state variable is set to zero. The poll bit should be set in the PU that contains the last segment of the SDU. The initial value of this variable is 0.

The Polling bit shall be set to 1 if ... Every Poll\_SDU is used and VT(SDU)=Poll\_SDU and the PDU contains the last segment that SDU

##### Reference

25.322 Clauses 9. 4, 9.6 and 11.3.2.1.1.

##### 7.2.3.18.3 Test purpose

1. To verify that a poll is performed when VT(SDU) reaches Poll\_ SDU.
2. To verify that the poll is sent in the last PDU of the SDU.

## 7.2.3.18.4 Method of test

## Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

The following RLC parameter values are used in place of the values in Clause 7.2.3.1:

Uplink RLC Polling info Poll_SDU	1
--	---

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in loop-back mode 1 with the UL SDU size set to 63 bytes.

Let the value of Poll\_SDU be P.

- The SS sends  $2 * P$  RLC SDUs of size 15 bytes to the UE in PDUs with sequence numbers that are contiguous, starting from zero.
- The SS checks the sequence numbers and polling bits of the RLC SDUs returned on the uplink.
- The SS terminates the connection.

The test is repeated with Poll\_SDU set to 64.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		←	DOWNLINK RLC PDU	SDU 1
2		←	DOWNLINK RLC PDU	SDU 2
3		←	...	SS continues to transmit RLC SDUs
4		←	DOWNLINK RLC PDU	SDU 2P
5	→		UPLINK RLC PDU	SDU 1 Expanded to 63 bytes by test function
6	→		UPLINK RLC PDU	
7	→		...	SS continues to receive RLC SDUs
8	→		UPLINK RLC PDU	SDU P, Poll
9	←		STATUS PDU	
10	→		UPLINK RLC PDU	SDU P+1 Expanded to 63 bytes by test function
11	→		UPLINK RLC PDU	
12	→		...	SS continues to receive RLC SDUs
13	→		UPLINK RLC PDU	SDU 2P, Poll Optional step
14			RB RELEASE	

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

### 7.2.3.18.5 Test requirements

The UE shall return uplink PDUs that contain polls for status in sequence numbers  $4 * P - 1$  and  $8 * P - 1$ . No other PDUs should poll for status.

## 7.2.3.19 Polling for status / Timer triggered polling (Timer\_Poll\_Periodic)

### 7.2.3.19.1 Definition

This case tests that the UE will poll for a status request every Timer\_Poll\_Periodic ms when that mode is enabled. Incorrect operation of polling will cause degradation of service, or at worst service failure.

This test applies to all UE.

### 7.2.3.19.2 Conformance requirement

The timer is started when the RLC entity is created. Each time the timer expires a poll is transmitted (either by the transmission of a PDU which was not yet sent, or by a retransmission) and the timer is restarted. If there is no PU to be transmitted and all PUs have already been acknowledged, a poll shall not be transmitted and the timer shall only be restarted.

The Polling bit shall be set to 1 if ... timer based polling is used and Timer\_Poll\_Periodic has expired.

### Reference

25.322 Clauses 9.5 and 11.3.2.1.1.

### 7.2.3.19.3 Test purpose

1. To verify that the UE polls the SS in the next PDU to be transmitted or retransmitted each time the Timer\_Poll\_Periodic timer expires.
2. To verify that if there is no PU to be transmitted, and all the PUs have already been acknowledged, the timer is restarted, but no poll is sent..

### 7.2.3.19.4 Method of test

#### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

The following RLC parameter values are used in place of the values in Clause 7.2.3.1:

Uplink RLC Polling info Timer_poll_periodic	First run	Second run
	100	2000

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in loop-back mode 1 with the UL SDU size set to 15 bytes.

#### Test procedure

Let T be the value of Timer\_Poll\_Periodic

- a) The SS waits for at least  $2 * T$  ms before starting any transmissions, and monitors the uplink.

- b) The SS sends  $T * 0.1$  RLC SDUs of size 15 bytes to the UE.
- c) The SS waits for the first PDU to be received with the P bit set, records the arrival time ( $T_1$ ) and responds with a STATUS PDU normally.
- d) The SS waits for the reception of the next PDU with the P bit set, records the arrival time ( $T_2$ ), and then transmits a STATUS PDU reporting that none of the unacknowledged PDUs were correctly received.
- e) The SS waits for the next PDU received with the P bit set, and records the arrival time ( $T_3$ ).
- f) The SS waits for the reception of the next PDU with the P bit set and records the arrival time ( $T_4$ ).
- g) The SS may optionally release the radio bearer.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		←	DOWNLINK RLC PDU	SDU 1
2		←	...	SS continues to transmit RLC SDUs
3		←	DOWNLINK RLC PDU	SDU 0.1T
4		→	UPLINK RLC PDU	SDU 1
5		→	UPLINK RLC PDU	SDU 2
6		→	...	SS continues to receive RLC PDUs
7		→	UPLINK RLC PDU	SN = ceil(T/TTI), Poll: Note $T_1$
8		←	STATUS PDU	ACK SN 0 to SN ceil(T/TTI)
9		→	UPLINK RLC PDU	SN = ceil(T/TTI)+1
10		→	...	SS continues to receive RLC PDUs
11		→	UPLINK RLC PDU	SN = ceil(2T/TTI), Poll: Note $T_2$
12		←	STATUS PDU	NAK SN ceil(T/TTI)+1 to SN ceil(2T/TTI)
13		→	UPLINK RLC PDU	PDUs including some retransmissions
14		→	UPLINK RLC PDU	
15		→	...	SS continues to receive RLC PDUs
16		→	UPLINK RLC PDU	Poll: Note $T_3$
17		←	STATUS PDU	Normal
18		→	...	SS continues to receive RLC PDUs
19		→	UPLINK RLC PDU	Poll: Note $T_4$
20			RB RELEASE	Optional step

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

#### 7.2.3.19.5 Test requirements

Time  $T_2 - T_1$  should be  $T \pm TTI$  ms.

Time  $T_4 - T_3$  should be  $T \pm TTI$  ms.

### 7.2.3.20 Polling for status / Polling on Poll\_Window% of transmission window

#### 7.2.3.20.1 Definition

This case tests that the UE will poll for a status request every Timer\_Poll\_Periodic ms when that mode is enabled. Incorrect operation of polling will cause degradation of service, or at worst service failure.

This test applies to all UE.

#### 7.2.3.20.2 Conformance requirement

The Polling bit shall be set to 1 if ... Poll\_Window% of transmission window is used, and:

$$\left[ 1 - \frac{(Tx\_Window\_Size + VT(MS) - VT(S)) \bmod Tx\_Window\_Size}{Tx\_Window\_Size} \right] * 100 > Poll\_Window$$

#### Reference

25.322 Clause 11.3.2.1.1.

#### 7.2.3.20.3 Test purpose

1. To verify that the UE polls the SS once the window based polling equation is satisfied.

#### 7.2.3.20.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

The following RLC parameter values are used in place of the values in Clause 7.2.3.1:

Uplink RLC	
Polling info	
Poll_Window	50
Transmission window size	8
Downlink RLC	
Receiving window size	8

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in loop-back mode 1 with the UL SDU size set to 15 bytes.

##### Test procedure

Let W be the size of the transmission window.

- a) The SS transmits  $(W/2) + 2$  RLC SDUs of size 15 bytes.
- b) The SS checks the sequence number of the first uplink PDU to be received with the P bit set.
- c) The SS sends another RLC SDU of size 15 bytes.
- d) The SS checks the sequence number of the next uplink PDU to be received with the P bit set.
- e) The SS sends a STATUS PDU acknowledging the first two RLC PDUs received, followed by two further RLC SDUs.

- f) The SS checks the sequence number of the next uplink PDU to be received with the P bit set
- g) The SS may optionally release the radio bearer

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		←	DOWNLINK RLC PDU	SDU 1
2		←	...	SS continues to transmit RLC SDUs
3		←	DOWNLINK RLC PDU	SDU W/2
4		→	UPLINK RLC PDU	SDU 1
5		→	UPLINK RLC PDU	SDU 2
6		→	...	SS continues to receive RLC PDUs
7		→	UPLINK RLC PDU	SN = W/2+1, Poll
3		←	DOWNLINK RLC PDU	
9		→	UPLINK RLC PDU	SN = W/2+2, Poll
8		←	STATUS PDU	ACK SN 0 to 3
3		←	DOWNLINK RLC PDU	
3		←	DOWNLINK RLC PDU	
11		→	UPLINK RLC PDU	SN = W/2+3
11		→	UPLINK RLC PDU	SN = W/2+4, Poll
20			RB RELEASE	Optional step

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

#### 7.2.3.20.5 Test requirements

The SS shall receive RLC PDUs with the P bit set in PDUs with sequence numbers of 5, 6 and 8. No other PDUs should have their P bits set.

#### 7.2.3.21 Polling for status / Operation of Timer\_Poll timer / Timer expiry

##### 7.2.3.21.1 Definition

This case tests that the UE will retransmit a poll for status if it does not receive a STATUS PDU within Timer\_Poll ms after a poll for status is transmitted. Incorrect operation of polling will cause degradation of service, or possible service failure.

This test applies to all UE.

##### 7.2.3.21.2 Conformance requirement

This timer is started when the transmitting side sends a poll to the peer entity. The timer is stopped when receiving a STATUS PDU that contains an acknowledgement or negative acknowledgement of the AMD PDU that triggered the timer.

If the timer expires and no STATUS PDU containing an acknowledgement or negative acknowledgement of the AMD PDU that triggered the timer has been received, the receiver is polled once more (either by the transmission of a PDU which was not yet sent, or by a retransmission) and the timer is restarted. If there is no PU to be transmitted and all PUs have already been acknowledged, the receiver shall not be polled.

If a new poll is sent when the timer is running it is restarted

The Polling bit shall be set to 1 if ... Poll timer is used and timer Timer\_Poll has expired

## Reference

25.322 Clause 9.5 and 11.3.2.1.1.

## 7.2.3.21.3 Test purpose

1. To verify that if the timer expires and no STATUS PDU containing an acknowledgement or negative acknowledgement of the AMD PDU that triggered the timer has been received, the receiver is polled once more.

## 7.2.3.21.4 Method of test

## Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

The following RLC parameter values are used in place of the values in Clause 7.2.3.1:

Uplink RLC	First run	Second run
Polling info		
Timer_poll	500	1000
Timer_Poll_Periodic	2000	2000

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in loop-back mode 1 with the UL SDU size set to 15 bytes.

## Test procedure

Let T be the value of the Timer\_Poll\_Periodic timer.

- a) The SS transmits at least  $2 * T / TTI$  SDUs of size 15 bytes..
- b) The SS receives PDUs from the UE, and notes the time on receiving the first PU with the P bit set, but does not respond. This time will be recorded as  $T_1$ .
- c) The SS continues to receive PDUs from the UE and notes the time on receipt of the next PU with the P bit set. This time will be recorded as  $T_2$ .
- d) The SS may optionally release the radio bearer

The test case is run once for each set of initial RLC parameters.



Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	←		DOWNLINK RLC PDU	SDU 1
2	←		...	SS continues to transmit RLC SDUs
3	←		DOWNLINK RLC PDU	SDU ceil(2T/TTI)
4	→		UPLINK RLC PDU	SDU 1
5	→		UPLINK RLC PDU	SDU 2
6	→		...	SS continues to receive RLC PDUs
7	→		UPLINK RLC PDU	SN = ceil(T/TTI), Poll: Note T <sub>1</sub>
8	→		UPLINK RLC PDU	SN = ceil(T/TTI)+1
9	→		...	SS continues to receive RLC PDUs
10	→		UPLINK RLC PDU	Poll: Note T <sub>2</sub>
11			RB RELEASE	Optional step

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

#### 7.2.3.21.5 Test requirements

For the first run, the measured time  $T_2 - T_1$  should be  $500 \pm 40$  ms (TTI = 40 ms).

For the second run, the measured time  $T_2 - T_1$  should be  $1000 \pm 40$  ms.

### 7.2.3.22 Polling for status / Operation of Timer\_Poll timer / Stopping Timer\_Poll timer

#### 7.2.3.22.1 Definition

This case tests that the UE will stop the Timer\_Poll timer if it receives a STATUS PDU within Timer\_Poll ms after a poll for status is transmitted. Incorrect operation of polling will cause degradation of service, or possible service failure.

This test applies to all UE.

#### 7.2.3.22.2 Conformance requirement

This timer is started when the transmitting side sends a poll to the peer entity. The timer is stopped when receiving a STATUS PDU that contains an acknowledgement or negative acknowledgement of the AMD PDU that triggered the timer.

If the timer expires and no STATUS PDU containing an acknowledgement or negative acknowledgement of the AMD PDU that triggered the timer has been received, the receiver is polled once more (either by the transmission of a PDU which was not yet sent, or by a retransmission) and the timer is restarted. If there is no PU to be transmitted and all PUs have already been acknowledged, the receiver shall not be polled.

If a new poll is sent when the timer is running it is restarted

#### Reference

25.322 Clause 9.5.

#### 7.2.3.22.3 Test purpose

1. To verify that the timer is stopped when receiving a STATUS PDU that contains an acknowledgement or negative acknowledgement of the AMD PDU that triggered the timer.

## 7.2.3.22.4 Method of test

## Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

The following RLC parameter values are used in place of the values in Clause 7.2.3.1:

Uplink RLC	First run	Second run
Polling info		
Timer_poll	500	1000
Timer_Poll_Periodic	2000	2000

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in loop-back mode 1 with the UL SDU size set to 15 bytes.

## Test procedure

Let T be the value of the Timer\_Poll\_Periodic timer.

- The SS transmits at least  $2 * T / TTI$  SDUs of size 15 bytes.
- The SS receives PDUs from the UE, and notes the time on receiving the first PDU with the P bit set. This time will be recorded as  $T_1$ .
- The SS sends a STATUS PDU acknowledging all the PDUs up to and including the PDU carrying the poll request.
- The SS continues to receive PDUs from the UE and notes the time on receipt of the next PU with the P bit set. This time will be recorded as  $T_2$ .
- The SS may optionally release the radio bearer

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		←	DOWNLINK RLC PDU	SDU 1
2		←	...	SS continues to transmit RLC SDUs
3		←	DOWNLINK RLC PDU	SDU $\text{ceil}(2T/TTI)$
4	→		UPLINK RLC PDU	SDU 1
5	→		UPLINK RLC PDU	SDU 2
6		→	...	SS continues to receive RLC PDUs
7	→		UPLINK RLC PDU	SN = $\text{ceil}(T/TTI)$ , Poll: Note $T_1$
8	←		STATUS PDU	ACK SN 0 to SN $\text{ceil}(T/TTI)$
9	→		UPLINK RLC PDU	SN = $\text{ceil}(T/TTI)+1$
10		→	...	SS continues to receive RLC PDUs
11	→		UPLINK RLC PDU	SN = $\text{ceil}(2T/TTI)$ , Poll: Note $T_2$
12			RB RELEASE	Optional step

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

7.2.3.22.5
Test requirements

For both execution runs, the measured time  $T_2 - T_1$  should be  $2000 \pm 40$  ms (TTI = 40ms).

7.2.3.23
Polling for status / Operation of Timer\_Poll timer / Restart of the Timer\_Poll timer

7.2.3.23.1
Definition

This case tests that the UE will restart the Timer\_Poll timer if another poll request is transmitted whilst the timer is running. Incorrect operation of polling will cause degradation of service, or possible service failure.

This test applies to all UE.

7.2.3.23.2
Conformance requirement

This timer is started when the transmitting side sends a poll to the peer entity. The timer is stopped when receiving a STATUS PDU that contains an acknowledgement or negative acknowledgement of the AMD PDU that triggered the timer.

If the timer expires and no STATUS PDU containing an acknowledgement or negative acknowledgement of the AMD PDU that triggered the timer has been received, the receiver is polled once more (either by the transmission of a PDU which was not yet sent, or by a retransmission) and the timer is restarted. If there is no PU to be transmitted and all PUs have already been acknowledged, the receiver shall not be polled.

If a new poll is sent when the timer is running it is restarted

Reference

25.322 Clause 9.5.

7.2.3.23.3
Test purpose

1. To verify that if a new poll is sent when the timer is running it is restarted.

7.2.3.23.4
Method of test

Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

The following RLC parameter values are used in place of the values in Clause 7.2.3.1:

Uplink RLC	
Polling info	
Timer_poll	500
Poll_PU	10
Poll_SDU	12

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in loop-back mode 1 with the UL SDU size set to 15 bytes.

## Test procedure

Let T be the value of the Timer\_Poll timer.

- a) The SS starts transmission of at least Poll\_SDU + ceil(T / TTI) SDUs of size 15 bytes.
- b) Whilst transmitting, the SS receives PDUs from the UE, and notes the time on receiving the second PDU with the P bit set. This time will be recorded as T<sub>1</sub>.
- c) The SS sends a STATUS PDU acknowledging all the PDUs up to, but not including the PDU carrying the poll request.
- d) The SS continues to receive PDUs from the UE and notes the time on receipt of the next PU with the P bit set. This time will be recorded as T<sub>2</sub>.
- e) The SS may optionally release the radio bearer

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		←	DOWNLINK RLC PDU	SDU 1
2		←	...	SS continues to transmit RLC SDUs
3		←	DOWNLINK RLC PDU	SDU (Poll_SDU + ceil(T / TTI))
4	→		UPLINK RLC PDU	SDU 1
5	→		UPLINK RLC PDU	SDU 2
6		→	...	SS continues to receive RLC PDUs
7		→	UPLINK RLC PDU	SN = poll_PU - 1, Poll, Timer_Poll started
8		→	...	SS continues to receive RLC PDUs
9		→	UPLINK RLC PDU	SN = poll_SDU - 1, Poll, Timer_Poll restarted: Note T <sub>1</sub>
10	←		STATUS PDU	ACK SN 0 to SN = poll_SDU - 2
11	→		UPLINK RLC PDU	SN = poll_SDU
12		→	...	SS continues to receive RLC PDUs
13		→	UPLINK RLC PDU	SN = poll_SDU + ceil(T/TTI), Poll: Note T <sub>2</sub>
14			RB RELEASE	Optional step

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

### 7.2.3.23.5 Test requirements

The measured time T<sub>2</sub> – T<sub>1</sub> should be 500 ± 40 ms (TTI = 40ms).

### 7.2.3.24 Polling for status / Operation of timer Timer\_Poll\_Prohibit

#### 7.2.3.24.1 Definition

This case tests that the UE will not send a poll request within Timer\_Poll\_Prohibit ms of a previous poll request when this mode of operation is enabled. Incorrect operation of polling will cause degradation of service, or possible service failure.

This test applies to all UE.

### 7.2.3.24.2 Conformance requirement

This timer is used to prohibit transmission of polls within a certain period. A poll shall be delayed until the timer expires if a poll is triggered when the timer is active. Only one poll shall be transmitted when the timer expires even if several polls were triggered when the timer was active. If there is no PU to be transmitted and all PUs have already been acknowledged, a poll shall not be transmitted. This timer will not be stopped by a STATUS PDU. The value of the timer is signalled by RRC.

The Polling bit shall be set to 1 if any of following conditions are fulfilled except when the poll prohibit function is used and the timer Timer\_Poll\_Prohibit is active (the different triggers are described in 9.7.4).

### Reference

25.322 Clauses 9.5 and 11.3.2.1.1.

### 7.2.3.24.3 Test purpose

1. To verify that no poll is transmitted if one or several polls are triggered when the Timer\_Poll\_Prohibit timer is active and has not expired.

### 7.2.3.24.4 Method of test

#### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

The following RLC parameter values are used in place of the values in Clause 7.2.3.1:

Uplink RLC	
Polling info	
Timer_poll_prohibit	500
Poll_PU	10
Poll_SDU	12
Poll_Window	50
Transmission window size	32
Downlink RLC	
Receiving window size	32

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in loop-back mode 1 with the UL SDU size set to 15 bytes.

### Test procedure

Let T be the value of the Timer\_Poll\_Prohibit timer.

- a) The SS starts transmission of at least  $(\text{Transmission Window Size} / 2) + \text{ceil}(T / \text{TTI})$  SDUs of size 15 bytes.
- b) Whilst transmitting, the SS receives PDUs from the UE, and notes the time on receiving the first PDU with the P bit set. This time will be recorded as  $T_1$ .
- c) The SS does not respond to the poll request.
- d) The SS continues to receive PDUs from the UE and notes the time on receipt of the next PU with the P bit set. This time will be recorded as  $T_2$ .
- e) The SS may optionally release the radio bearer

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		←	DOWNLINK RLC PDU	SDU 1
2		←	...	SS continues to transmit RLC SDUs
3		←	DOWNLINK RLC PDU	SDU Poll_PU
4		→	UPLINK RLC PDU	SDU 1
5		→	UPLINK RLC PDU	SDU 2
6		→	...	SS continues to receive RLC PDUs
7		→	UPLINK RLC PDU	SN = Poll_PU - 1, Poll: Note T <sub>1</sub>
8		→	...	SS continues to receive RLC PDUs
9		→	UPLINK RLC PDU	SN = poll_SDU - 1, No Poll
10		→	UPLINK RLC PDU	SN = (Transmission Window Size / 2) - 1, No Poll
11		→	...	SS continues to receive RLC PDUs
12		→	UPLINK RLC PDU	SN = poll_PU + ceil(T/TTI), Poll: Note T <sub>2</sub>
13			RB RELEASE	Optional step

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

#### 7.2.3.24.5 Test requirements

The measured time  $T_2 - T_1$  should be  $500 \pm 40$  ms (TTI = 40ms).

### 7.2.3.25 Receiver Status Triggers / Detection of missing PUs

#### 7.2.3.25.1 Definition

This case tests that the UE transmits a status report whenever it detects that a PU is missing, if this mode of operation is enabled. Incorrect operation of status reporting will cause degradation of service, or possible service failure.

This test applies to all UE.

#### 7.2.3.25.2 Conformance requirement

The receiver in any of following cases initiates this procedure ... Detection of missing PUs is used and a missing PU is detected.

#### Reference

25.322 Clause 11.5.2.

#### 7.2.3.25.3 Test purpose

1. To verify that a status report is transmitted if there are one or more missing PUs..

#### 7.2.3.25.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

These settings apply to both the uplink and downlink DTCH.

##### Test procedure

- a) The SS transmits 7 SDUs, each of size 15 bytes, in PDUs with consecutive sequence numbers starting from 0, followed by 5 SDUs in PDUs with consecutive sequence numbers starting from 8, followed by an SDU in a PDU with a sequence number of 15.
- b) While transmitting, the SS monitors the uplink for STATUS PDUs.
- c) The SS may optionally release the radio bearer

##### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		←	DOWNLINK RLC PDU	SN = 0
2		←	...	SS continues to transmit RLC SDUs
3		←	DOWNLINK RLC PDU	SN = 6
4		←	DOWNLINK RLC PDU	SN = 8
5		→	STATUS PDU	
6		←	DOWNLINK RLC PDU	
7		←	...	SS continues to receive RLC PDUs
8		←	DOWNLINK RLC PDU	SN = 12
9		←	DOWNLINK RLC PDU	SN = 15
10		→	STATUS PDU	
11			RB RELEASE	Optional step

#### 7.2.3.25.5 Test requirements

A STATUS PDU should be received from the UE after step 4, indicating that the PDU with sequence number 7 was missing.

A STATUS PDU should be received from the UE after step 9, indicating that the PDUs with sequence numbers 13 and 14 were missing.

#### 7.2.3.26 Receiver Status Triggers / Operation of timer Timer\_Status\_Periodic

##### 7.2.3.26.1 Definition

This case tests that the UE transmits a status report every Timer\_Status\_Periodic ms when this mode of operation is enabled. Incorrect operation of status reporting will cause degradation of service, or possible service failure.

This test applies to all UE.

### 7.2.3.26.2 Conformance requirement

This timer is only used when timer based status report sending is used. The timer is started when the RLC entity is created. Each time the timer expires a status report is transmitted and the timer is restarted. The value of the timer is signalled by RRC.

The receiver in any of following cases initiates this procedure ... The timer based STATUS transfer is used and the timer Timer\_Status\_Periodic has expired.

### Reference

25.322 Clauses 9.5, 9.7.2 and 11.5.2.

### 7.2.3.26.3 Test purpose

1. To verify that a status report is transmitted each time the Timer\_Status\_Periodic timer expires.

### 7.2.3.26.4 Method of test

#### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

The following RLC parameter values are used in place of the values in Clause 7.2.3.1:

Downlink RLC Timer_STATUS_periodic	100
---------------------------------------	-----

These settings apply to both the uplink and downlink DTCH.

### Test procedure

Let T be the value of the Timer\_STATUS\_periodic timer.

- a) The SS starts transmission of at least  $\text{ceil}(2 * T / \text{TTI})$  SDUs of size 15 bytes.
- b) The SS waits to receive a STATUS PDU and notes the time. This time will be recorded as  $T_1$ .
- c) The SS waits to receive a second STATUS PDU and notes the time. This time will be recorded as  $T_2$ .
- d) The SS may optionally release the radio bearer



Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		←	DOWNLINK RLC PDU	SDU 1
2		←	...	SS continues to transmit RLC SDUs
3		←	DOWNLINK RLC PDU	SDU $\text{ceil}(T/\text{TTI})-1$
4		→	STATUS PDU	Note T <sub>1</sub>
5		←	DOWNLINK RLC PDU	
6		←	...	SS continues to receive RLC PDUs
7		←	DOWNLINK RLC PDU	SDU $\text{ceil}(2T/\text{TTI})-1$
8		→	STATUS PDU	Note T <sub>2</sub>
9			RB RELEASE	Optional step

#### 7.2.3.26.5 Test requirements

The measured time  $T_2 - T_1$  should be  $100 \pm 40$  ms (TTI = 40ms).

### 7.2.3.27 Receiver Status Triggers / Operation of timer Timer\_Status\_Prohibit

#### 7.2.3.27.1 Definition

This case tests that the UE transmits a status report every Timer\_Status\_Prohibit ms when this mode of operation is enabled. Incorrect operation of status reporting will cause degradation of service, or possible service failure.

This test applies to all UE.

#### 7.2.3.27.2 Conformance requirement

If any of following conditions are fulfilled the sending of the status report shall be delayed, even if any of the conditions above are fulfilled:

- 1) STATUS prohibit is used and the timer Timer\_Status\_Prohibit is active.

The status report shall be transmitted after the Timer\_Status\_Prohibit has expired. The receiver shall send only one status report, even if there are several triggers when the timer is running.

#### Reference

25.322 Clause 11.5.2.

#### 7.2.3.27.3 Test purpose

1. To verify that a status report is not transmitted while the Timer\_Status\_Prohibit timer is active.
2. To verify that only one status report is sent on the expiry of the Timer\_Status\_Prohibit timer if several triggers occur while it is active.

## 7.2.3.27.4 Method of test

## Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

The following RLC parameter values are used in place of the values in Clause 7.2.3.1:

Downlink RLC	
Timer_Status_Prohibit	500
Timer_STATUS_periodic	200

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in loop-back mode 1 with the UL SDU size set to 15 bytes.

## Test procedure

Let  $T_{pro}$  be the value of the Timer\_Status\_Prohibit timer, and  $T_{per}$  be the value of the Timer\_Status\_Periodic timer.

- The SS starts transmission of at least  $\text{ceil}(2 * T_{pro} / TTI) + \text{ceil}(T_{per}/TTI)$  SDUs of size 15 bytes.
- Whilst transmitting, the SS monitors the uplink for a STATUS PDU and notes the time. This time will be recorded as  $T_1$ .
- The SS sets the P bit in a downlink PDU transmitted within the next  $\text{floor}(T_{pro}/TTI)$  PDUs.
- The SS waits to receive a second STATUS PDU and notes the time. This time will be recorded as  $T_2$ .
- The SS may optionally release the radio bearer

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		←	DOWNLINK RLC PDU	SDU 1
2		←	...	SS continues to transmit RLC SDUs
3		←	DOWNLINK RLC PDU	SDU $\text{ceil}(T_{per}/TTI)$
4		→	STATUS PDU	Note $T_1$
5		←	DOWNLINK RLC PDU	Poll
6		←	...	SS continues to receive RLC PDUs
7		←	DOWNLINK RLC PDU	SDU $\text{ceil}(T_{pro} / TTI) + \text{ceil}(T_{per}/TTI)$
8		→	STATUS PDU	Note $T_2$
9			RB RELEASE	Optional step

## 7.2.3.27.5 Test requirements

The measured time  $T_2 - T_1$  should be  $500 \pm 40$  ms ( $TTI = 40$ ms).

### 7.2.3.28 Timer based discard, with explicit signalling / Expiry of Timer\_Discard

#### 7.2.3.28.1 Definition

This case tests that when the transmission of an SDU exceeds a time limit, the SDU is discarded by the sender, and the discard is signalled to the receiver. SDU discard is used to keep network delays within limits, and incorrect operation will effect the quality of service.

#### 7.2.3.28.2 Conformance requirement

If the transmission time exceeds a predefined value for a SDU in acknowledged mode RLC, this SDU is discarded in the transmitter and a Move Receiving Window (MRW) command is sent to the receiver so that AMD PDUs carrying that SDU are discarded in the receiver and the receiver window is updated accordingly.

This status report is sent even if the 'STATUS prohibit' is used and the timer 'Timer\_Status\_Prohibit' is active.

The STATUS PDUs have higher priority than data PDUs.

The sender shall start timer Timer\_MRW. If a new SDU discard procedure is triggered when Timer\_MRW is running, no new MRW SUFIs should be sent before the STATUS PDU is received indicating the appropriate value of VR(R).

If Timer\_MRW expires before a STATUS PDU is received indicating a value of VR(R) greater or equal to the MRW parameter then the STATUS(MRW) shall be retransmitted, VT(MRW) is incremented by one and Timer\_MRW restarted. MRW SUFI should be exactly the same as previously transmitted even though some new SDUs would have been discarded during the running of the Timer\_MRW.

If the number of retransmission of a MRW command (i.e. VT(MRW)) reaches MaxMRW, an error indication shall be passed to RRC and RESET procedure should be performed.

#### Reference

25.322 Clauses 9.7.3.1, 11.6.2, 11.6.5 and 11.6.6.2.

#### 7.2.3.28.3 Test purpose

1. To verify that if the transmission time for an SDU exceeds Timer\_Discard, the SDU is discarded in the transmitter and the MRW procedure is invoked.
2. To verify that the MRW procedure status report is sent even if the 'STATUS prohibit' is used and the timer 'Timer\_Status\_Prohibit' is active.

#### 7.2.3.28.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

The following RLC parameter values are used in place of the values in Clause 7.2.3.1:

Uplink RLC	
Transmission RLC discard	
Timer based with explicit signalling	
Timer_MRW	500
Timer_Discard	1
MaxMRW	1
Polling info	
Timer_poll_periodic	100
Downlink RLC	
Timer_Status_Prohibit	1000
Timer_STATUS_periodic	100

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in loop-back mode 1 with the UL SDU size set to 55 bytes.

### Test procedure

- a) The SS sends at least 2 RLC SDUs of size 15 bytes.
- b) Whilst transmitting, the SS notes the time that the first RLC PDU is received on the uplink. This time will be recorded as  $T_1$ .
- c) The SS checks the RLC PDUs received on the uplink and responds to all poll requests with a STATUS PDU, negatively acknowledging the RLC PDU with sequence number 0, and positively acknowledging all other RLC PDUs received.
- d) After a delay of 0.6 seconds from transmitting the last RLC SDU, the SS sends a further RLC SDU of size 15 bytes.
- e) The SS monitors received STATUS PDUs for the presence of a MRW SUFI, noting the time it was received. This time will be recorded as  $T_2$ .
- f) The SS checks any RLC SDUs reassembled from the uplink.
- g) The SS may optionally release the radio bearer

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	←		DOWNLINK RLC PDU	SDU 1
2	←		DOWNLINK RLC PDU	SDU 2
3	←		...	SS continues to send RLC PDUs
4	→		UPLINK RLC PDU	SDU 1
5	→		...	SS continues to receive RLC PDUs
6	→		UPLINK RLC PDU	Poll
7	←		STATUS PDU	NAK SN=0
8	→		...	SS continues to receive RLC PDUs
9	→		UPLINK RLC PDU	Poll
10	←		STATUS PDU	NAK SN=0
11	←		DOWNLINK RLC PDU	SDU 3
12	→		...	SS continues to receive RLC PDUs
13	→		STATUS PDU	MRW Command: Note T <sub>2</sub>
14			RB RELEASE	Optional step

#### 7.2.3.28.5 Test requirements

The measured time  $T_2 - T_1$  should be  $1000 \pm 40$  ms (TTI = 40ms). The STATUS PDU shall contain MRW SUFIs indicating that the first four PDUs should be discarded, and that the data indicated in the fifth PDU by the first LI should also be discarded.

#### 7.2.3.29 Timer based discard, with explicit signalling / Failure of MRW procedure

##### 7.2.3.29.1 Definition

This case tests that if a failure occurs during the signalling of an SDU discard to the receiver, the retransmission protocol operates correctly. SDU discard is used to keep network delays within limits, and incorrect operation will effect the quality of service.

##### 7.2.3.29.2 Conformance requirement

If the transmission time exceeds a predefined value for a SDU in acknowledged mode RLC, this SDU is discarded in the transmitter and a Move Receiving Window (MRW) command is sent to the receiver so that AMD PDUs carrying that SDU are discarded in the receiver and the receiver window is updated accordingly.

This status report is sent even if the 'STATUS prohibit' is used and the timer 'Timer\_Status\_Prohibit' is active.

The STATUS PDUs have higher priority than data PDUs.

The sender shall start timer Timer\_MRW. If a new SDU discard procedure is triggered when Timer\_MRW is running, no new MRW SUFIs should be sent before the STATUS PDU is received indicating the appropriate value of VR(R).

If Timer\_MRW expires before a STATUS PDU is received indicating a value of VR(R) greater or equal to the MRW parameter then the STATUS(MRW) shall be retransmitted, VT(MRW) is incremented by one and Timer\_MRW restarted. MRW SUFI should be exactly the same as previously transmitted even though some new SDUs would have been discarded during the running of the Timer\_MRW.

If the number of retransmission of a MRW command (i.e. VT(MRW)) reaches MaxMRW, an error indication shall be passed to RRC and RESET procedure should be performed.

## Reference

25.322 Clauses 9.7.3.1, 11.6.2, 11.6.5 and 11.6.6.2.

### 7.2.3.29.3 Test purpose

1. To verify that when Timer\_MRW expires before a STATUS PDU is received indicating a value of VR(R) greater or equal to the MRW parameter then the STATUS(MRW) is retransmitted, VT(MRW) is incremented by one and Timer\_MRW is restarted.
2. To verify that if a new SDU discard procedure is triggered when Timer\_MRW is running, no new MRW SUFIs are sent before the STATUS PDU is received indicating the appropriate value of VR(R).
3. To verify that when the number of retransmissions of a MRW command reaches MaxMRW, an error indication is passed to RRC and RESET procedure is initiated.

### 7.2.3.29.4 Method of test

#### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

The following RLC parameter values are used in place of the values in Clause 7.2.3.1:

Uplink RLC	
Transmission RLC discard	
Timer based with explicit signalling	
Timer_MRW	500
Timer_Discard	0.5
MaxMRW	4
Polling info	
Poll_PU	2

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in loop-back mode 1 with the UL SDU size set to 31 bytes.

#### Test procedure

- a) The SS sends 4 RLC SDUs of size 31 bytes.
- b) The SS checks the RLC PDUs received on the uplink and responds to all poll requests as follows: While the VR(H) is 4 or less, with a STATUS PDU, negatively acknowledging the RLC PDU with sequence number 0, and positively acknowledging all other RLC PDUs received. While the VR(H) is greater than 4, a STATUS PDU negatively acknowledging RLC PDUs with sequence numbers 0 and 4, and positively acknowledging all others.
- c) The SS monitors received STATUS PDUs for the presence of an MRW SUFI, noting the time it was received. This time will be recorded as  $T_1$ .
- d) The SS makes no response, but monitors for the next STATUS PDU containing an MRW SUFI, noting the time it was received. This time will be recorded as  $T_2$ .

- e) The SS sends a STATUS PDU indicating the discard of SDU 1 moving VR(R) to 4.
- f) The SS monitors for further STATUS PDUs containing an MRW SUFI, or for a RESET PDU. The SS records the number of STATUS PDUs it received with MRW SUFI before it received the RESET PDU.
- g) The SS checks any RLC SDUs reassembled from the uplink.
- h) The SS may optionally release the radio bearer

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		←	DOWNLINK RLC PDU	SDU 1
2		←	DOWNLINK RLC PDU	SDU 1
3		←	DOWNLINK RLC PDU	SDU 2
4		←	...	SS continues to send RLC PDUs
5		←	DOWNLINK RLC PDU	SDU 4
6		→	UPLINK RLC PDU	SDU 1
7		→	...	SS continues to receive RLC PDUs
8		→	UPLINK RLC PDU	Poll
9		←	STATUS PDU	NAK SN=0
10		→	...	SS continues to receive RLC PDUs
11		→	UPLINK RLC PDU	Poll
12		←	STATUS PDU	NAK SN=0, 4
13		→	...	SS continues to receive RLC PDUs
14		→	STATUS PDU	MRW Command: Note T <sub>1</sub>
15		→	STATUS PDU	MRW Command: Note T <sub>2</sub>
16		←	STATUS PDU	VR(R) = 4
17		→	STATUS PDU	MRW Command, discard SDU 3
18		→	STATUS PDU	MRW Command
19		→	STATUS PDU	MRW Command
20		→	STATUS PDU	MRW Command
21		→	RESET PDU	
22			RB RELEASE	Optional step

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

#### 7.2.3.29.5 Test requirements

The measured time  $T_2 - T_1$  should be  $500 \pm 40$  ms (TTI = 40ms).

After step 16, the SS should detect 4 repeats of the MRW command before a RESET PDU is sent.

#### 7.2.3.30 SDU discard after MaxDAT number of retransmissions

##### 7.2.3.30.1 Definition

This case tests that if a PDU is unsuccessfully transmitted MaxDAT times, the SDU it carries, and therefore all other associated PDUs, are discarded by the transmitter and receiver. This mode of SDU discard is used to minimize data loss, and incorrect operation will effect the quality of service.

#### 7.2.3.30.2 Conformance requirement

There is one VT(DAT) for each PU and it is incremented each time the PU is transmitted. The initial value of this variable is 0.

It is the maximum value for the number of retransmissions of a PU. This parameter is an upper limit of counter VT(DAT). When the value of VT(DAT) comes to MaxDAT, error recovery procedure will be performed.

If SDU discard after MaxDAT number of retransmission is used and  $VT(DAT) > MaxDAT$  for any PU the sender shall initiate the SDU discard with explicit signalling procedure.

#### Reference

25.322 Clauses 9.4, 9.6 and 11.3.4.4.

#### 7.2.3.30.3 Test purpose

1. To verify that if  $VT(DAT) > MaxDAT$  for any PU the sender initiates the SDU discard with explicit signalling procedure.

#### 7.2.3.30.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in loop-back mode 1 with the UL SDU size set to 31 bytes.

##### Test procedure

- a) The SS sends 2 RLC SDUs of size 31 bytes.
- b) The SS checks the RLC PDUs received on the uplink and responds to all poll requests with a STATUS PDU negatively acknowledging the RLC PDU with sequence number 0, and positively acknowledging all other RLC PDUs received.
- c) The SS monitors received STATUS PDUs for the presence of an MRW SUFI.
- d) The SS checks any RLC SDUs reassembled from the uplink.
- e) The SS may optionally release the radio bearer



Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		←	DOWNLINK RLC PDU	SDU 1
2		←	DOWNLINK RLC PDU	SDU 1
3		←	DOWNLINK RLC PDU	SDU 2
4		←	DOWNLINK RLC PDU	SDU 2
5		→	UPLINK RLC PDU	SDU 1
6		→	...	SS continues to receive RLC PDUs
7		→	UPLINK RLC PDU	SDU 2, Poll
8		←	STATUS PDU	NAK SN=0
9		→	UPLINK RLC PDU	Retransmit SN=0, Poll
10		←	STATUS PDU	NAK SN=0
11		→	UPLINK RLC PDU	Retransmit SN=0, Poll
12		←	STATUS PDU	NAK SN=0
13		→	UPLINK RLC PDU	Retransmit SN=0, Poll
14		←	STATUS PDU	NAK SN=0
15		→	UPLINK RLC PDU	Retransmit SN=0, Poll
16		←	STATUS PDU	NAK SN=0
17		→	STATUS PDU	MRW Command
18			RB RELEASE	Optional step

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

#### 7.2.3.30.5 Test requirements

The uplink RLC PDU with sequence number 0 shall be retransmitted four times, then the SS shall detect a STATUS PDU with an MRW command.

### 7.2.3.31 Operation of the RLC Reset procedure / UE Originated

#### 7.2.3.31.1 Definition

This case tests that when an unrecoverable protocol error occurs the UE will initiate and perform the RLC Reset procedure. Incorrect operation of this procedure may cause loss of service.

#### 7.2.3.31.2 Conformance requirement

The procedure shall be initiated when a protocol error occurs.

The sender sends the RESET PDU when it is in data transfer ready state and enters reset pending state. The sender shall start the timer Timer\_RST and increase VT(RST) with 1.

Upon reception of a RESET PDU the receiver shall respond with a RESET ACK PDU. The receiver resets the state variables to their initial value and resets configurable parameters to their configured value.

Upon reception of a RESET ACK the Timer\_RST shall be stopped. The sender resets the state variables to their initial value and resets configurable parameters to their configured value. The sender shall enter data transfer ready state.

Upon expiry of Timer\_RST the sender shall retransmit the RESET PDU and increase VT(RST) with 1.

If VT(RST) becomes larger or equal to MaxRST the RRC layer shall be informed.

#### Reference

25.322 Clause 11.4.

### 7.2.3.31.3 Test purpose

1. To verify that the Reset procedure is initiated when a protocol error occurs.
2. To verify that the sender resets state variables to their initial value and resets configurable parameters to their configured value.

### 7.2.3.31.4 Method of test

#### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

The following RLC parameter values are used in place of the values in Clause 7.2.3.1:

Uplink RLC Transmission RLC discard No discard	
--	--

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in loop-back mode 1 with the UL SDU size set to 31 bytes.

#### Test procedure

- a) The SS sends 2 RLC SDUs of size 31 bytes.
- b) The SS checks the RLC PDUs received on the uplink and responds to all poll requests with a STATUS PDU negatively acknowledging the RLC PDU with sequence number 0, and positively acknowledging all other RLC PDUs received.
- c) The SS notes the time that the RESET PDU is received. This time will be recorded as  $T_1$ .
- d) The SS makes no response, and notes the time that the next RESET PDU is received. This time will be recorded as  $T_2$ .
- e) The SS sends a RESET ACK PDU.
- f) The SS sends an RLC SDU of size 31 bytes.
- g) The SS responds normally to poll requests
- h) The SS checks any RLC SDU received on the uplink.
- i) The SS may optionally release the radio bearer

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	←		DOWNLINK RLC PDU	SDU 1
2	←		DOWNLINK RLC PDU	SDU 1
3	←		DOWNLINK RLC PDU	SDU 2
4	←		DOWNLINK RLC PDU	SDU 2
5	→		UPLINK RLC PDU	SDU 1
6	→		...	SS continues to receive RLC PDUs
7	→		UPLINK RLC PDU	SDU 2, Poll
8	←		STATUS PDU	NAK SN=0
9	→		UPLINK RLC PDU	Retransmit SN=0, Poll
10	←		STATUS PDU	NAK SN=0
11	→		UPLINK RLC PDU	Retransmit SN=0, Poll
12	←		STATUS PDU	NAK SN=0
13	→		UPLINK RLC PDU	Retransmit SN=0, Poll
14	←		STATUS PDU	NAK SN=0
15	→		UPLINK RLC PDU	Retransmit SN=0, Poll
16	←		STATUS PDU	NAK SN=0
17	→		RESET PDU	Note T <sub>1</sub>
18	→		RESET PDU	Note T <sub>2</sub>
19	←		RESET ACK PDU	
20	←		DOWNLINK RLC PDU	SDU 3
21	←		DOWNLINK RLC PDU	SDU 3
22	→		UPLINK RLC PDU	SDU 3, SN=0
23	→		UPLINK RLC PDU	SDU 3
24			RB RELEASE	Optional step

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

#### 7.2.3.31.5 Test requirements

The measured time  $T_2 - T_1$  should be  $500 \pm 40$  ms (TTI = 40ms).

The SS shall receive an RLC SDU with contents that match the third RLC SDU sent to the UE. The first RLC PDU containing that SDU shall have sequence number 0.

### 7.2.3.32 Operation of the RLC Reset procedure / UE Terminated

#### 7.2.3.32.1 Definition

This case tests that when an unrecoverable protocol error occurs the UE will initiate and perform the RLC Reset procedure. Incorrect operation of this procedure may cause loss of service.

#### 7.2.3.32.2 Conformance requirement

The procedure shall be initiated when a protocol error occurs.

The sender sends the RESET PDU when it is in data transfer ready state and enters reset pending state. The sender shall start the timer Timer\_RST and increase VT(RST) with 1.

Upon reception of a RESET PDU the receiver shall respond with a RESET ACK PDU. The receiver resets the state variables to their initial value and resets configurable parameters to their configured value.

Upon reception of a RESET ACK the Timer\_RST shall be stopped. The sender resets the state variables to their initial value and resets configurable parameters to their configured value. The sender shall enter data transfer ready state.

Upon expiry of Timer\_RST the sender shall retransmit the RESET PDU and increase VT(RST) with 1.

If VT(RST) becomes larger or equal to MaxRST the RRC layer shall be informed.

#### Reference

25.322 Clause 11.4.

#### 7.2.3.32.3 Test purpose

1. To verify that upon reception of a RESET PDU the receiver responds with a RESET ACK PDU.
2. To verify that the receiver resets its state variables to their initial value and resets configurable parameters to their configured value.

#### 7.2.3.32.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (Clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in Clause 7.2.3.1.

The following RLC parameter values are used in place of the values in Clause 7.2.3.1:

Uplink RLC Transmission RLC discard No discard	
--	--

These settings apply to both the uplink and downlink DTCH.

##### Test procedure

- a) The SS sends 2 RLC SDUs of size 31 bytes.
- b) The SS checks the STATUS PDUs received on the uplink until both SDUs have been acknowledged.
- c) The SS transmits a RESET PDU, and notes the time that it is transmitted. This time will be recorded as  $T_1$ .
- d) The SS monitors the uplink for a RESET ACK PDU and notes the time that it is received. This time will be recorded as  $T_2$ .
- e) The SS sends an RLC SDU of size 31 bytes.
- f) The SS checks for STATUS PDUs received on the uplink until the SDU has been acknowledged.
- g) The SS may optionally release the radio bearer

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		←	DOWNLINK RLC PDU	SDU 1
2		←	DOWNLINK RLC PDU	SDU 1
3		←	DOWNLINK RLC PDU	SDU 2
4		←	DOWNLINK RLC PDU	SDU 2
5		→	STATUS PDU	ACK SN=0, 1, 2 and 3
6		←	RESET PDU	Note T <sub>1</sub>
7		→	RESET ACK PDU	Note T <sub>2</sub>
8		←	DOWNLINK RLC PDU	SDU 3
9		←	DOWNLINK RLC PDU	SDU 3
10		→	STATUS PDU	ACK SN=0 and 1
11			RB RELEASE	Optional step

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

### 7.2.3.32.5 Test requirements

The SS shall receive a RESET ACK PDU in step 7. The measured time  $T_2 - T_1$  shall be  $500 \pm 40$  ms (TTI = 40ms).

The SS shall receive acknowledgements for the third RLC SDU transmitted.

## 7.3 PDCP

### 7.3.1 General

#### 7.3.1.1 General assumptions

If not otherwise mentioned, the same procedures as used in RRC test specification (TS 34.123-1) or in the Generic procedure (TS 34.108) applies to reach Initial conditions for PDCP testing. In this test description, common test sequences for PDCP (subclause 7.3.4.1) are defined and are applied either as preamble or postamble to establish or release a Packet Switched (PS) connection for a test case.

If not explicitly described, the same message contents and settings are applied as described in the RRC test description default settings.

Detailed IP header compression coding mechanism as well as mechanism related error recovery and packet reordering described in IETF RFC 2507 are not verified.

For PDCP testing TCP/IP data type and UDP/IP data type as Non-TCP/IP data types are applied for IP data.

An UE supporting IP Header compression method RFC 2507 shall be capable to store a header compression context of at least 512 bytes (Integer).

It shall be possible to reconfigure PDCP settings while Loop back mode 1. With the applied test method using Loop back mode 1, the UE as Originator and Receiver of PDCP SDUs (concurrent transmission) is tested.

#### 7.3.1.2 Common Test sequences and Default message contents for PDCP

##### General

The settings and parameter used in the "Common Test sequences for PDCP" are described in the "Default PDCP Message Contents". If not explicitly shown there, the message contents are identical with the default contents for the same message type of layer 3 messages for RRC tests, to establish a packet switched session or connection. The contents of test case specific message parameters are described in the test case (Expected Sequence). If not explicitly shown, default settings and parameter are used as message content for all Common Test sequences.

### 7.3.1.2.1 Common Test sequences for PDCP

#### 7.3.1.2.1.1 Setup a UE originated PS session using IP Header compression in AM RLC (using Loop back test mode 1)

##### Initial Conditions

UE is in Idle mode.

##### Test procedure

After having received the System Informations, the SS starts to setup a RRC connection. After connection establishment and Radio Bearer Setup, the UE Loop back mode 1 is activated and the UE test loop mode 1 is closed.

##### Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		←	SYSTEM INFORMATION	Connection Setup message PS sessions in AM RLC used in RRC testing matches here
2		→	RRC CONNECTION REQUEST	
3		←	RRC CONNECTION SETUP	
4		→	RRC CONNECTION SETUP COMPLETE	The Radio Bearer configuration is as described in TS 34.108, clause 6.10, RAB No. 23: QoS parameter: Traffic Class: Interactive or Background, max. UL:64 kbps max. DL:64 kbps, Residual BER as described in TS 34.108, clause: 6.10.
5		←	ACTIVATE RB TEST MODE	
6		→	ACTIVATE RB TEST MODE COMPLETE	
7		←	RADIO BEARER SETUP	
8		→	RADIO BEARER SETUP COMPLETE	The SS initiates test loop mode 1 using loop back scheme 1, indicated by the Parameter: "UE test loop mode" 1 (X1=0 and X2=0) The "DCCH dummy transmission" not used: disabled: (Y1=0)
9		←	CLOSE UE TEST LOOP	
10		→	CLOSE UE TEST LOOP COMPLETE	After having received the test mode acknowledgement, the loop back mode 1 is activated.

##### Specific message contents

The contents of test case specific message parameters are described in the test case (Expected Sequence). Default contents of messages are described in the clause Default PDCP Message Contents.

#### 7.3.1.2.1.2 Setup a UE originated PS session using IP Header compression in UM RLC (using Loop back test mode 1)

##### Initial Conditions

UE is in Idle mode.

##### Test procedure

After having received the System Information, the SS starts to setup a RRC connection. After connection establishment and Radio Bearer Setup, the UE Loop back mode 1 is activated and the UE test loop mode 1 is closed.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	←		SYSTEM INFORMATION	Connection Setup message PS sessions in UM RLC used in RRC testing matches here
2	→		RRC CONNECTION REQUEST	
3	←		RRC CONNECTION SETUP	
4	→		RRC CONNECTION SETUP COMPLETE	The Radio Bearer configuration is as described in TS 34.108, clause 6.10, RAB No. 23: QoS parameter: Traffic Class: Interactive or Background, max. UL:64 kbps max. DL:64 kbps, Residual BER as described in TS 34.108, clause: 6.10.
5	←		ACTIVATE RB TEST MODE	
6	→		ACTIVATE RB TEST MODE COMPLETE	
7	←		RADIO BEARER SETUP	
8	→		RADIO BEARER SETUP COMPLETE	The SS initiates test loop mode 1 using loop back scheme 1, indicated by the Parameter: "UE test loop mode"1 (X1=0 and X2=0) The "DCCH dummy transmission" not used: disabled: (Y1=0) After having received the test mode acknowledgement, the loop back mode 1 is activated.
9	←		CLOSE UE TEST LOOP	
10	→		CLOSE UE TEST LOOP COMPLETE	

## Specific message contents

The contents of test case specific message parameters are described in the test case (Expected Sequence) Default contents of messages are described in the clause Default PDCP Message Contents.

#### 7.3.1.2.1.3 Deactivate a UE originated PS session using IP Header compression (using Loop back test mode 1)

## Initial Conditions

UE is in connected mode, a UE test loop back mode session for PDCP is established, and the loop mode 1 is "closed".

## Test procedure

The UE opens the loop back mode 1, deactivates the test mode and the PS session, releases the Radio Bearer and enters Idle mode.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	←		OPEN UE TEST LOOP	The SS terminates the test loop mode 1 using loop back scheme 1, (see described parameter) After having received the test mode acknowledgement, the loop back mode 1 is deactivated.
2	→		OPEN UE TEST LOOP COMPLETE	
3	←		DEACTIVATE RB TEST MODE	SS stops the test loop mode 1 UE shall confirm the former message. Afterwards, the UE returns to normal operation SS terminates the connection UE confirms the connection release and returns to Idle mode
4	→		DEACTIVATE RB TEST MODE COMPLETE	
5	←		RRC CONNECTION RELEASE	
6	→		RRC CONNECTION RELEASE COMPLETE	

## Specific message contents

The contents of test case specific message parameters are described in the test case (Expected Sequence). Default contents of messages are described in the clause Default PDCP Message Contents.

### 7.3.1.2.2 Default PDCP Message Contents

This clause contains the default values of RRC messages used for PDCP testing, other than those specified in TS 34.108 clauses 6 and 9, and default values of PDCP messages. Unless indicated otherwise in specific test cases, only PDCP related specific message contents are described here which shall be transmitted by the system simulator in RRC messages, and which are required to be received from the UE under test. If not explicitly described, the message contents are identical with the default contents for the same message type of layer 3 messages for RRC tests, to establish a packet switched session or connection.

The necessary L3 messages are listed in alphabetic order, with the exception of the SYSTEM INFORMATION messages, where it is the information elements which are listed in alphabetic order (this is because some information elements occur in several SYSTEM INFORMATION types).

In this clause, decimal values are normally used. However, sometimes a hexadecimal value, indicated by an "H", or a binary value, indicated by a "B" is used.

#### Default SYSTEM INFORMATION:

NOTE 1: SYSTEM INFORMATION BLOCK TYPE 1 (except for PLMN type "GSM-MAP"), SYSTEM INFORMATION BLOCK TYPE 8, SYSTEM INFORMATION BLOCK TYPE 9, SYSTEM INFORMATION BLOCK TYPE 10, SYSTEM INFORMATION BLOCK TYPE 14, SYSTEM INFORMATION BLOCK TYPE 15 and SYSTEM INFORMATION BLOCK TYPE 16 messages are not used.



## Contents of CONNECTION SETUP message:

Capability update requirement	TRUE
- UE radio access capability update requirement	UE only supports 1 system
- System specific capability update requirement	
list	
- System specific capability update requirement	GSM

## Contents of CONNECTION SETUP COMPLETE message:

UE radio access capability	Value will be checked. Stated capability must be compatible with 34.123-2 (c.f. PICS/PIXIT statements in GSM) and the user settings
- Conformance test compliance	
- PDCP Capability	
- Max PDCP SN	
- Support of lossless SRNS relocation	
- Supported algorithm types	
- RFC2507	
- Maximum MAX_HEADER	
- Maximum TCP_SPACE	
- Maximum NON_TCP_SPACE	
- RLC Capability	
- Transport channel capability	
- RF Capability	
- Physical channel capability	
- UE multi-mode/multi-RAT capability	
- Security Capability	
- LCS Capability	
- Measurement capability	
UE system specific capability	Value will be check. UE must include the classmark information for the supported system

## Contents of ACTIVATE RB TEST MODE message:

Protocol Discriminator	TS 24.007, 11.2.3.1.1
Skip indicator	TS 24.007, 11.2.3.1.2
Message type	01000100B

## Contents of ACTIVATE RB TEST MODE COMPLETE message:

Protocol Discriminator	TS 24.007, 11.2.3.1.1
Skip indicator	TS 24.007, 11.2.3.1.2
Message type	01000101B

## Contents of DEACTIVATE RB TEST MODE message:

Protocol Discriminator	TS 24.007, 11.2.3.1.1
Skip indicator	TS 24.007, 11.2.3.1.2
Message type	01000110B

## Contents of DEACTIVATE RB TEST MODE COMPLETE message:

Protocol Discriminator	TS 24.007, 11.2.3.1.1
Skip indicator	TS 24.007, 11.2.3.1.2
Message type	01000111B

Contents of CLOSE UE TEST LOOP message:

Protocol Discriminator	TS 24.007, 11.2.3.1.1
Skip indicator	TS 24.007, 11.2.3.1.2
Message type	01000000B
UE test loop mode	000000100B (X2=0 and X1=0 for UE test mode 1, Y1=0 DCCH dummy transmission disabled)
UE test loop mode 1 LB setup	
- Length of UE loop mode 1 LB setup IE	4 octets
- LB setup list	
- LB setup RAB subflow #1	
- P1 (uplink PDCP header compression shall be performed)	0 = PDCP header compression enabled
- P2 (downlink PDCP header compression shall be performed)	0 = PDCP header compression enabled
- Z13...Z0 (Uplink RLC SDU size in bits)	0...16383 (binary coded, Z13 most significant bit); value as negotiated

Contents of CLOSE UE TEST LOOP COMPLETE message:

Protocol Discriminator	TS 24.007, 11.2.3.1.1
Skip indicator	TS 24.007, 11.2.3.1.2
Message type	01000001B

Contents of OPEN UE TEST LOOP message:

IE Identifier (only in AM)	1000xxxx
Protocol Discriminator	TS 24.007, 11.2.3.1.1
Skip indicator	TS 24.007, 11.2.3.1.2
Message type	01000010B

Contents of OPEN UE TEST LOOP COMPLETE message:

Protocol Discriminator	TS 24.007, 11.2.3.1.1
Skip indicator	TS 24.007, 11.2.3.1.2
Message type	01000011B

## 7.3.2 IP Header Compression and PID assignment

### 7.3.2.1 UE in RLC AM

#### 7.3.2.1.1 Transmission of uncompressed Header

##### 7.3.2.1.1.1 Definition and applicability

Applicable for all UEs supporting RLC AM and a Radio Bearer as described in the Common Test Sequences. The UE shall be capable to deal with a TCP/IP and UDP/IP data packets with uncompressed IP header.

##### 7.3.2.1.1.2 Conformance requirement

Packet Data Convergence Protocol shall perform the following functions:

- ...

- transfer of user data. Transmission of user data means that PDCP receives PDCP SDU from the NAS and forwards it to the RLC layer and vice versa;

PDCP shall be able (...) to handle them with a correct header compression algorithm and furthermore to indicate the type of the packet within a certain algorithm.

PID value 0 is reserved permanently for no compression

#### Reference(s)

TS 25.323 clause 5

TS 25.323 subclause 5.1.1

#### 7.3.2.1.1.3 Test purpose

The test case consists of two test procedures:

The first test procedure verifies, that the "PDCP Data" PDU is used for uncompressed IP header packets, if no IP header compression is negotiated by RRC. The second test procedure verifies, that the "PDCP No header" PDU is used for uncompressed IP header packets, if no IP header compression is negotiated by RRC.

1. To verify, that the UE transmits and receives in unacknowledged mode (RLC AM) TCP/IP and UDP/IP data packets without IP header compression as negotiated by RRC.
2. To verify, that PID assignment rules are correctly applied, if usage of "PDCP Data" PDU are negotiated, i.e. the UE shall recognize PID value = 0 for a received TCP/IP and UDP/IP data packet and it shall use PID=0 to transmit IP data packets, if no IP header compression is negotiated. If usage of "PDCP No Header" PDU is negotiated, no PID assignment is used for transmitting and receiving TCP/IP and UDP/IP data packets.

#### 7.3.2.1.1.4 Method of test

Initial conditions

UE is in Idle mode

Related ICS/IXIT Statement(s)

#### 1. Test procedure: Transmission of uncompressed IP header packets using PDCP Data PDU

- a) The SS setups a packet switched session including radio bearer and test loop back mode 1 in RLC AM using Common test procedures for mobile originated PS switched sessions. Usage of "PDCP Data" PDU has been negotiated by RRC.
- b) The SS sends a TCP/IP data packet with uncompressed IP Header.
- c) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PDCP PDU type and shall handle the received data packet with the appropriate decoding method. Then it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration using PDCP Data PDU.
- d) The SS receives and decodes the TCP/IP data packet. The decoded data packet shall be identical with the data as sent before.
- e) Step b) to d) shall be repeated by sending a UDP/IP data packet with uncompressed IP Header.

The SS deactivates the Loop back test mode and terminates the connection.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
Setup a UE originated PS session using IP Header compression in AM RLC (using Loop back test mode 1)				
1	←	PDCP Data	<p>The SS creates a TCP/IP packet without IP header compression (PDCP Data PDU).</p> <p>The SS sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content to the UE: PDU type = 000 (PDCP Data PDU) PID = 0 (uncompressed IP header) data: below described TCP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU and recognizes PID value = 0 (no IP header compression applied for this TCP/IP data packet) Therefore, no IP header decompression is applied for this packet.</p> <p>The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>	
2	→	PDCP Data	<p>The UE sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content back to the SS: data: former received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function for the received data</p>	
3	←	PDCP Data	<p>The SS creates a UDP/IP packet without IP header compression (PDCP Data PDU).</p> <p>The SS sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content to the UE: PDU type = 000 (PDCP Data PDU) PID = 0 (uncompressed IP header) data: below described UDP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU and recognizes with PID value = 0, there was no IP header compression applied for the UDP/IP packet. Therefore, no IP header decompression is applied for this packet.</p> <p>The data packet is forwarded via PDCP-SAP to the Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>	

Step	Direction		Message	Comments
	UE	SS		
4		→	PDCCP Data	<p>The UE sends a PDCCP Data PDU using the RLC-AM-Data-Request Primitive with the following content back to the SS: data: former received UDP/IP packet</p> <p>After reception of this UDP/IP data packet, the SS decodes the received data</p>
Deactivate a UE originated PS session using IP Header compression (using Loop back test mode 1)				

### Specific Message Contents

#### RRC CONNECTION SETUP message

The contents of the RRC CONNECTION SETUP message applied in the preamble "Setup a UE originated PS session using IP Header compression in AM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for AM) with the following exceptions:

Information Element	Value/remark
Capability update requirement - UE radio access capability update requirement	TRUE NOTE: Value will be checked. Stated capability must be compatible with 34.123-2 (c.f. PICS/PIXIT statements in GSM) and the user settings

#### RADIO BEARER SETUP message

The contents of the RADIO BEARER SETUP message applied in the preamble "Setup a UE originated PS session using IP Header compression in AM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for AM) which fits to the below described parameters with the following exceptions:

Information Element	Value/remark
RAB information for setup - RAB info - RAB identity	No. # 23 as described in TS 34.108, Table 6.10.2.1.1 Prioritised RABs. QoS parameter: Traffic Class: Interactive or Background, max. UL: 64 kbps as described in TS 34.108, subclause 6.10.2.4.1.22 including described physical channel parameters, configuration for AM RLC max. DL: 64 kbps as described in TS 34.108, subclause 6.10.2.4.1.23 including described physical channel parameters, Residual BER as described in TS 34.108, clause: 6.10 Related Signalling RB UL: 3.4 kbps, DL: 3.4 kbps DCCH, No. #2 (as described in TS 34.108, Table 6.10.2.1.2) PS domain
- CN domain identity - RB information to setup - RB identity - PDCCP info - Support of lossless SRNS relocation	5  False (IE "Support of lossless SRNS relocation" only present, if RLC "In-sequence delivery" is TRUE and in AM)
- PDCCP PDU header - RLC info - Downlink RLC mode	present  (AM RLC)

#### Content of PDCCP Data PDU (Step 1)

Information Element	Value/remark
PDU type	000
PID	00000 (No header compression, PID = 0)
Data	PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

## Content of PDCP Data PDU (Step 3)

Information Element	Value/remark
PDU type	000
PID	00000 (No header compression, PID = 0)
Data	PDCP test data type #2: UDP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

**2. Test procedure: Transmission of uncompressed IP header packets using No Header PDU**

- a) The SS setups a packet switched session including radio bearer and test loop back mode 1 in RLC AM using Common test procedures for mobile originated PS switched sessions. Usage of "PDCP No Header" PDU has been negotiated by RRC.
- b) The SS sends a TCP/IP data packet with uncompressed IP Header.
- c) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PDCP PDU type and shall handle the received data packet with the appropriate decoding method. Then it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration using PDCP No Header PDU.
- d) The SS receives and decodes the TCP/IP data packet. The decoded data packet shall be identical with the data as sent before.
- e) Step b) to d) shall be repeated by sending a UDP/IP data packet with uncompressed IP Header.
- f) The SS deactivates the Loop back test mode and terminates the connection.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
Setup a UE originated PS session using IP Header compression in AM RLC (using Loop back test mode 1)				
1	←	PDCP No Header	<p>The SS creates a TCP/IP packet without IP header compression (PDCP No Header PDU).</p> <p>The SS sends a PDCP No Header PDU using the RLC-AM-Data-Request Primitive with the following content to the UE: data: below described TCP/IP packet</p> <p>After having received the PDCP No Header PDU, the UE decodes the PDU and recognizes, there was no PID applied for the TCP/IP packet. Therefore, no IP header decompression shall be applied for this packet. Then, the data packet is forwarded via PDCP-SAP to the Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>	
2	→	PDCP No Header	<p>The UE sends a PDCP No Header PDU using the RLC-AM-Data-Request Primitive with the following content back to the SS: data: former received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function for the received data</p>	
3	←	PDCP No Header	<p>The SS creates a UDP/IP packet without IP header compression (PDCP No Header PDU).</p> <p>The SS sends a PDCP No Header PDU using the RLC-AM-Data-Request Primitive with the following content to the UE: data: below described UDP/IP packet</p> <p>After having received the PDCP No Header PDU, the UE decodes the PDU and recognizes, there was no PID applied for the UDP/IP packet. Therefore, no IP header decompression shall be applied for this packet. Then, the data packet is forwarded via PDCP-SAP to the Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>	
4	→	PDCP No Header	<p>The UE sends a PDCP No Header PDU using the RLC-AM-Data-Request Primitive with the following content back to the SS: data: former received TCP/IP packet</p> <p>After reception of this UDP/IP data packet, the SS decodes the received data</p>	
Deactivate a UE originated PS session using IP Header compression (using Loop back test mode 1)				

## Specific Message Contents

## RRC CONNECTION SETUP message

The contents of the RRC CONNECTION SETUP message applied in the preamble "Setup a UE originated PS session using IP Header compression in AM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for AM) with the following exceptions:

Information Element	Value/remark
Capability update requirement - UE radio access capability update requirement	TRUE NOTE: Value will be checked. Stated capability must be compatible with 34.123-2 (c.f. PICS/PIXIT statements in GSM) and the user settings

## RADIO BEARER SETUP message

The contents of the RADIO BEARER SETUP message applied in the preamble "Setup a UE originated PS session using IP Header compression in AM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for AM) which fits to the below described parameters with the following exceptions:

Information Element	Value/remark
RAB information for setup - RAB info - RAB identity	No. # 23 as described in TS 34.108, Table 6.10.2.1.1 Prioritised RABs. QoS parameter: Traffic Class: Interactive or Background, max. UL: 64 kbps as described in TS 34.108, subclause 6.10.2.4.1.22 including described physical channel parameters, configuration for AM RLC max. DL: 64 kbps as described in TS 34.108, subclause 6.10.2.4.1.23 including described physical channel parameters, Residual BER as described in TS 34.108, clause: 6.10 Related Signalling RB UL: 3.4 kbps, DL: 3.4 kbps DCCH, No. #2 (as described in TS 34.108, Table 6.10.2.1.2) PS domain
- CN domain identity	5
- RB information to setup - RB identity - PDCP info - Support of lossless SRNS relocation	False (IE "Support of lossless SRNS relocation" only present, if RLC "In-sequence delivery" is TRUE and in AM) absent
- PDCP PDU header - RLC info - Downlink RLC mode	(AM RLC)

## Content of PDCP No Header PDU (Step 1)

Information Element	Value/remark
Data	PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.



## Content of PDCP No Header PDU (Step 3)

Information Element	Value/remark
Data	PDCP test data type #2: UDP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

## 7.3.2.1.1.5 Test requirements

**1. Test requirements: Transmission of uncompressed IP header packets using PDCP Data PDU**

The UE shall return the TCP/IP and UDP/IP data packets as indication, that the former packets have been received and handled correctly (PDCP Data PDU). This verifies, that the PDCP configuration on UE side works as negotiated by the RRC.

**2. Test requirements: Transmission of uncompressed IP header packets using PDCP No Header PDU**

The UE shall return the TCP/IP and UDP/IP data packets as indication, that the former packets have been received and handled correctly (PDCP No Header PDU). This verifies, that the PDCP configuration on UE side works as negotiated by the RRC.

## 7.3.2.1.2 Transmission of compressed Header

## 7.3.2.1.2.1 Definition and applicability

Applicable for all UEs supporting RLC AM and a Radio Bearer as described in the Common Test Sequences.

The UE shall be capable to deal with compressed TCP/IP and UDP/IP data packets and furthermore to establish a PDCP entity which applies IP header compression method RFC 2507.

## 7.3.2.1.2.2 Conformance requirement

Packet Data Convergence Protocol shall perform the following functions:

- ...

- transfer of user data. Transmission of user data means that PDCP receives PDCP SDU from the NAS and forwards it to the RLC layer and vice versa;

PDCP shall be able (...) to handle them with a correct header compression algorithm and furthermore to indicate the type of the packet within a certain algorithm.

## Reference(s)

TS 25.323 clause 5

TS 25.323 subclause 5.1.1

## 7.3.2.1.2.3 Test purpose

1. To verify, that the UE transmits and receives in unacknowledged mode (RLC AM) TCP/IP and UDP/IP data packets by using IP header compression method as described in RFC2507 as negotiated by RRC.
2. To verify, that the PID assignment rules are correctly applied by the UE. The UE shall use the correct PID value for the applied optimisation method for transmitting and receiving TCP/IP and UDP/IP data packets.

## 7.3.2.1.2.4 Method of test

## Initial conditions

UE is in Idle mode

## Related ICS/IXIT Statement(s)

Support of IP header compression method RFC 2507 - YES/NO

## Test procedure

- a) The SS setups a packet switched session including radio bearer and test loop back mode 1 in RLC AM using Common test procedures for mobile originated PS switched sessions. Usage of "PDCP Data" PDU has been negotiated by RRC.

- b) The SS sends a "normal" TCP/IP data packet (no compression packet type), PID=0.

NOTE: According to the compression algorithm RFC 2507, this is necessary for the decompression unit to create the internal CONTEXT with assigned CID.

- c) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet with the correct decompression method. Then, it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.

- d) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.

- e) The SS sends a TCP/IP data packet with packet type: Full\_Header, PID=1.

NOTE: According to the compression algorithm RFC 2507, this is necessary to transmit the created CONTEXT and the assigned CID.

- f) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet with the correct decompression method. Then, it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.

- g) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.

- h) The SS sends a TCP/IP data packet with packet type: Compressed\_TCP, PID=2.

- i) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet with the correct decompression method. Then, it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.

- j) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.

- k) The SS sends a TCP/IP data packet with packet type: Compressed\_TCP\_nondelta, PID=3.

- l) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet with the correct decompression method. Then, it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.

- m) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.

- n) Step b) to d) is repeated for a "normal" UDP/IP data packet, PID=0.

- o) Step e) to g) is repeated for a UDP/IP data packet with packet type: Full\_Header, PID=1.

- p) The SS sends a UDP/IP data packet with packet type: Compressed\_non\_TCP, PID=4.

- q) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet with the correct decompression method. Then, it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.
- r) The SS receives and decodes the UDP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.
- s) The SS deactivates the Loop back test mode and terminates the connection.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
Setup a UE originated PS session using IP Header compression in AM RLC (using Loop back test mode 1)				
1	←	PDCP Data	<p>The SS creates a TCP/IP packet without IP header compression.</p> <p>The SS sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content to the UE: PDU type = 000 (PDCP Data PDU) PID = 0 (uncompressed IP header) data: below described TCP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU and recognizes PID value = 0 (no IP header compression applied for this TCP/IP data packet) Therefore, no IP header decompression is applied for this packet.</p> <p>The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>	
2	→	PDCP Data	<p>The UE sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content back to the SS: PDU type = 000 (PDCP Data PDU) PID value = 0 to 5, except 4 (depending on the TCP/IP header format used by the UE) data: former received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function dependent the assigned PID.</p>	
3	←	PDCP Data	<p>The SS sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content to the UE: PDU type = 000 (PDCP Data PDU) PID = 1 (Full_Header packet type [TCP/IP]) data: below described TCP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU, recognizes PID value = 1 applied for this TCP/IP data packet and decompresses it with the appropriate method. The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>	
4	→	PDCP Data	<p>The UE sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content back to the SS: PDU type = 000 (PDCP Data PDU) PID value = 0 to 5, except 4 (depending on which TCP/IP header format is used by the UE) data: former received TCP/IP packet</p>	

Step	Direction		Message	Comments
	UE	SS		
				After reception of this TCP/IP data packet, the SS applies the appropriate decoding function dependent the assigned PID.
5	←		PDCP Data	<p>The SS sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content to the UE:  PDU type = 000 (PDCP Data PDU)  PID = 2 (Compressed_TCP packet type)  data: below described TCP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU, recognizes PID value = 2 applied for this TCP/IP data packet and decompress it with the appropriate method. The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>
6	→		PDCP Data	<p>The UE sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content back to the SS:  PDU type = 000 (PDCP Data PDU)  PID value = 0 to 5, except 4 (depending on which TCP/IP header format is used by the UE)  data: former received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function dependent the assigned PID.</p>
7	←		PDCP Data	<p>The SS sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content to the UE:  PDU type = 000 (PDCP Data PDU)  PID = 3 (Compressed_TCP_nondelta packet type)  data: below described TCP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU, recognizes PID value = 3 applied for this TCP/IP data packet and decompress it with the appropriate method. The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>
8	→		PDCP Data	<p>The UE sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content back to the SS:  PDU type = 000 (PDCP Data PDU)  PID value = 0 to 5, except 4 (depending on which TCP/IP header format is used by the UE)  data: former received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function dependent the assigned PID.</p>

Step	Direction		Message	Comments
	UE	SS		
9	←		PDCP Data	<p>The SS creates a UDP/IP packet without compressed IP header compression.</p> <p>The SS sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content to the UE:  PDU type = 000 (PDCP Data PDU)  PID = 0 (uncompressed IP header)  data: below described UDP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU and recognizes with PID value = 0, there was no IP header compression applied for the UDP/IP packet. Therefore, no IP header decompression is applied for this packet.</p> <p>The data packet is forwarded via PDCP-SAP to the Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>
10	→		PDCP Data	<p>The UE sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content back to the SS:  PDU type = 000 (Data PDU with Header)  PID value = 0, 1 or 4 (depending on which UDP/IP header format is used by the UE)  data: below described UDP/IP packet</p> <p>After reception of this UDP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>
11	←		PDCP Data	<p>The SS sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content to the UE:  PDU type = 000 (PDCP Data PDU)  PID = 1 (Full_Header packet type)  data: below described UDP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU and recognizes PID value = 1 applied for this UDP/IP data packet and decompress it with the appropriate method.</p> <p>The data packet is forwarded via PDCP-SAP to the Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>
12	→		PDCP Data	<p>The UE sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content back to the SS:  PDU type = 000 (Data PDU with Header)  PID value = 0, 1 or 4 (depending on which UDP/IP header format is used by the UE)  data: below described UDP/IP packet</p>

Step	Direction		Message	Comments
	UE	SS		
				After reception of this UDP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.
13	←		PDCP Data	<p>The SS sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content to the UE:  PDU type = 000 (PDCP Data PDU)  PID = 4 (Compressed _non-TCP packet type)  data: below described UDP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU and recognizes PID value = 4 applied for this UDP/IP data packet and decompress it with the appropriate method.</p> <p>The data packet is forwarded via PDCP-SAP to the Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>
14	→		PDCP Data	<p>The UE sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content back to the SS:  PDU type = 000 (Data PDU with Header)  PID value = 0,1 or 4 (depending on which UDP/IP header format is used by the UE)  data: below described UDP/IP packet</p> <p>After reception of this UDP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>
Deactivate a UE originated PS session using IP Header compression (using Loop back test mode 1)				

### Specific Message Contents

#### RRC CONNECTION SETUP message

The contents of the RRC CONNECTION SETUP message applied in the preamble "Setup a UE originated PS session using IP Header compression in AM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for AM) with the following exceptions:

Information Element	Value/remark
Capability update requirement - UE radio access capability update requirement	<p>TRUE</p> <p>NOTE: Value will be checked. Stated capability must be compatible with 34.123-2 (c.f. PICS/PIXIT statements in GSM) and the user settings</p>

## RADIO BEARER SETUP message

The contents of the RADIO BEARER SETUP message applied in the preamble "Setup a UE originated PS session using IP Header compression in AM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for AM) which fit to the here described parameters with the following exceptions:

Information Element	Value/remark
RAB information for setup - RAB info - RAB identity          - CN domain identity - RB information to setup - RB identity - PDCP info - Support of lossless SRNS relocation  - PDCP PDU header - Header compression information CHOICE <i>algorithm type</i> - RFC2507 - F_MAX_PERIOD - F_MAX_TIME - MAX_HEADER - TCP_SPACE - NON_TCP_SPACE - EXPECT_REORDERING - RLC info - Downlink RLC mode	No. # 23 as described in TS 34.108, Table 6.10.2.1.1 Prioritised RABs. QoS parameter: Traffic Class: Interactive or Background, max. UL: 64 kbps as described in TS 34.108, subclause 6.10.2.4.1.22 including described physical channel parameters, configuration for AM RLC max. DL: 64 kbps as described in TS 34.108, subclause 6.10.2.4.1.23 including described physical channel parameters, Residual BER as described in TS 34.108, clause: 6.10 Related Signalling RB UL: 3.4 kbps, DL: 3.4 kbps DCCH, No. #2 (as described in TS 34.108, Table 6.10.2.1.2) PS domain  5  False (IE "Support of lossless SRNS relocation" only present, if RLC "In-sequence delivery" is TRUE and in AM) present 1  256   (Default) 5     (Default) 168   (Default) 15                   (Default) 15                   (Default) reordering expected   (Default)  (AM RLC)

## Content of PDCP Data PDU (Step 1)

Information Element	Value/remark
PDU type PID Data	000 00000 (No header compression, PID = 0) PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

## Content of PDCP Data PDU (Step 3)

Information Element	Value/remark
PDU type PID Data	000 00001 (Full_Header, PID = 1) PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.



## Content of PDCP Data PDU (Step 5)

Information Element	Value/remark
PDU type	000
PID	00010 (Compressed_TCP, PID = 2)
Data	PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

## Content of PDCP Data PDU (Step 7)

Information Element	Value/remark
PDU type	000
PID	00011 (Compressed_TCP_non-delta, PID = 3)
Data	PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

## Content of PDCP Data PDU (Step 9)

Information Element	Value/remark
PDU type	000
PID	00000 (No header compression, PID = 0)
Data	PDCP test data type #2: UDP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

## Content of PDCP Data PDU (Step 11)

Information Element	Value/remark
PDU type	000
PID	00001 (Full_Header, PID = 1)
Data	PDCP test data type #2: UDP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

## Content of PDCP Data PDU (Step 13)

Information Element	Value/remark
PDU type	000
PID	00100 (Compressed_non-TCP, PID = 4)
Data	PDCP test data type #2: UDP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

## 7.3.2.1.2.5 Test requirements

The UE shall return the TCP/IP and UDP/IP data packets as indication, that the former packets have been received and handled with the correct compression method. This verifies, that the PDCP configuration on UE side works as negotiated by the RRC.

## 7.3.2.2 UE in RLC UM

## 7.3.2.2.1 Transmission of uncompressed Header

## 7.3.2.2.1.1 Definition and applicability

Applicable for all UEs supporting RLC UM and a Radio Bearer as described in the Common Test Sequences.

The UE shall be capable to deal with a TCP/IP and UDP/IP data packets with uncompressed IP header.

#### 7.3.2.2.1.2 Conformance requirement

Packet Data Convergence Protocol shall perform the following functions:

- ...

- transfer of user data. Transmission of user data means that PDCP receives PDCP SDU from the NAS and forwards it to the RLC layer and vice versa;

PDCP shall be able (...) to handle them with a correct header compression algorithm and furthermore to indicate the type of the packet within a certain algorithm.

PID value 0 is reserved permanently for no compression

#### Reference(s)

TS 25.323 clause 5

TS 25.323 subclause 5.1.1

#### 7.3.2.2.1.3 Test purpose

The test case consists of two test procedures:

The first test procedure verifies, that the "PDCP Data" PDU is used for uncompressed IP header packets, if no IP header compression is negotiated by RRC. The second test procedure verifies, that the "PDCP No header" PDU is used for uncompressed IP header packets, if no IP header compression is negotiated by RRC.

1. To verify, that the UE transmits and receives in unacknowledged mode (RLC UM) TCP/IP and UDP/IP data packets without IP header compression as negotiated by RRC.
2. To verify, that PID assignment rules are correctly applied, if usage of "PDCP Data" PDU are negotiated, i.e. the UE shall recognize PID value = 0 for a received TCP/IP and UDP/IP data packet and it shall use PID=0 to transmit IP data packets, if no IP header compression is negotiated. If usage of "PDCP No Header" PDU is negotiated, no PID assignment is used for transmitting and receiving TCP/IP and UDP/IP data packets.

#### 7.3.2.2.1.4 Method of test

Initial conditions

UE is in Idle mode

Related ICS/IXIT Statement(s)

#### 1. Test procedure: Transmission of uncompressed IP header packets using PDCP Data PDU

- a) The SS setups a packet switched session including radio bearer and test loop back mode 1 in RLC UM using Common test procedures for mobile originated PS switched sessions. Usage of "PDCP Data" PDU has been negotiated by RRC.
- b) The SS sends a TCP/IP data packet with uncompressed IP Header.
- c) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PDCP PDU type and shall handle the received data packet with the appropriate decoding method. Then it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration using PDCP Data PDU.
- d) The SS receives and decodes the TCP/IP data packet. The decoded data packet shall be identical with the data as sent before.

- e) Step b) to d) shall be repeated by sending a UDP/IP data packet with uncompressed IP Header.

The SS deactivates the Loop back test mode and terminates the connection.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
Setup a UE originated PS session using IP Header compression in UM RLC (using Loop back test mode 1)				
1	←	PDCP Data	<p>The SS creates a TCP/IP packet without IP header compression (PDCP Data PDU).</p> <p>The SS sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content to the UE: PDU type = 000 (PDCP Data PDU) PID = 0 (uncompressed IP header) data: below described TCP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU and recognizes PID value = 0 (no IP header compression applied for this TCP/IP data packet) Therefore, no IP header decompression is applied for this packet.</p> <p>The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>	
2	→	PDCP Data	<p>The UE sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS: data: former received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function for the received data</p>	
3	←	PDCP Data	<p>The SS creates a UDP/IP packet without IP header compression (PDCP Data PDU).</p> <p>The SS sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content to the UE: PDU type = 000 (PDCP Data PDU) PID = 0 (uncompressed IP header) data: below described UDP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU and recognizes with PID value = 0, there was no IP header compression applied for the UDP/IP packet. Therefore, no IP header decompression is applied for this packet.</p> <p>The data packet is forwarded via PDCP-SAP to the Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>	

Step	Direction		Message	Comments
	UE	SS		
4		→	PDCCP Data	<p>The UE sends a PDCCP Data PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS: data: former received TCP/IP packet</p> <p>After reception of this UDP/IP data packet, the SS decodes the received data</p>
Deactivate a UE originated PS session using IP Header compression (using Loop back test mode 1)				

### Specific Message Contents

#### RRC CONNECTION SETUP message

The contents of the RRC CONNECTION SETUP message applied in the preamble "Setup a UE originated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) with the following exceptions:

Information Element	Value/remark
Capability update requirement - UE radio access capability update requirement	TRUE NOTE: Value will be checked. Stated capability must be compatible with 34.123-2 (c.f. PICS/PIXIT statements in GSM) and the user settings

#### RADIO BEARER SETUP message

The contents of the RADIO BEARER SETUP message applied in the preamble "Setup a UE originated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) which fits to the below described parameters with the following exceptions:

Information Element	Value/remark
RAB information for setup - RAB info - RAB identity	No. # 23 as described in TS 34.108, Table 6.10.2.1.1 Prioritised RABs. QoS parameter: Traffic Class: Interactive or Background, max. UL: 64 kbps as described in TS 34.108, subclause 6.10.2.4.1.22 including described physical channel parameters, configuration for UM RLC max. DL: 64 kbps as described in TS 34.108, subclause 6.10.2.4.1.23 including described physical channel parameters, Residual BER as described in TS 34.108, clause: 6.10 Related Signalling RB UL: 3.4 kbps, DL: 3.4 kbps DCCH, No. #2 (as described in TS 34.108, Table 6.10.2.1.2) PS domain
- CN domain identity - RB information to setup - RB identity - PDCCP info - Support of lossless SRNS relocation	5  False (IE "Support of lossless SRNS relocation" only present, if RLC "In-sequence delivery" is TRUE and in UM) present
- PDCCP PDU header - RLC info - Downlink RLC mode	(UM RLC)

#### Content of PDCCP Data PDU (Step 1)

Information Element	Value/remark
PDU type	000
PID	00000 (No header compression, PID = 0)
Data	PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

## Content of PDCP Data PDU (Step 3)

Information Element	Value/remark
PDU type	000
PID	00000 (No header compression, PID = 0)
Data	PDCP test data type #2: UDP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

**2. Test procedure: Transmission of uncompressed IP header packets using No Header PDU**

- a) The SS setups a packet switched session including radio bearer and test loop back mode 1 in RLC UM using Common test procedures for mobile originated PS switched sessions. Usage of "PDCP No Header" PDU has been negotiated by RRC.
- b) The SS sends a TCP/IP data packet with uncompressed IP Header.
- c) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PDCP PDU type and shall handle the received data packet with the appropriate decoding method. Then it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration using PDCP No Header PDU.
- d) The SS receives and decodes the TCP/IP data packet. The decoded data packet shall be identical with the data as sent before.
- e) Step b) to d) shall be repeated by sending a UDP/IP data packet with uncompressed IP Header.
- f) The SS deactivates the Loop back test mode and terminates the connection.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
Setup a UE originated PS session using IP Header compression in UM RLC (using Loop back test mode 1)				
1	←	PDCP No Header	<p>The SS creates a TCP/IP packet without IP header compression (PDCP No Header PDU).</p> <p>The SS sends a PDCP No Header PDU using the RLC-UM-Data-Request Primitive with the following content to the UE: data: below described TCP/IP packet</p> <p>After having received the PDCP No Header PDU, the UE decodes the PDU and recognizes, there was no PID applied for the TCP/IP packet. Therefore, no IP header decompression shall be applied for this packet. Then, the data packet is forwarded via PDCP-SAP to the Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>	
2	→	PDCP No Header	<p>The UE sends a PDCP No Header PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS: data: former received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function for the received data</p>	
3	←	PDCP No Header	<p>The SS creates a UDP/IP packet without IP header compression (PDCP No Header PDU).</p> <p>The SS sends a PDCP No Header PDU using the RLC-UM-Data-Request Primitive with the following content to the UE: data: below described UDP/IP packet</p> <p>After having received the PDCP No Header PDU, the UE decodes the PDU and recognizes, there was no PID applied for the UDP/IP packet. Therefore, no IP header decompression shall be applied for this packet. Then, the data packet is forwarded via PDCP-SAP to the Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>	
4	→	PDCP No Header	<p>The UE sends a PDCP No Header PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS: data: former received UDP/IP packet</p> <p>After reception of this UDP/IP data packet, the SS decodes the received data</p>	
Deactivate a UE originated PS session using IP Header compression (using Loop back test mode 1)				

## Specific Message Contents

## RRC CONNECTION SETUP message

The contents of the RRC CONNECTION SETUP message applied in the preamble "Setup a UE originated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) with the following exceptions:

Information Element	Value/remark
Capability update requirement - UE radio access capability update requirement	TRUE NOTE: Value will be checked. Stated capability must be compatible with 34.123-2 (c.f. PICS/PIXIT statements in GSM) and the user settings

## RADIO BEARER SETUP message

The contents of the RADIO BEARER SETUP message applied in the preamble "Setup a UE originated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) which fits to the below described parameters with the following exceptions:

Information Element	Value/remark
RAB information for setup - RAB info - RAB identity	No. # 23 as described in TS 34.108, Table 6.10.2.1.1 Prioritised RABs. QoS parameter: Traffic Class: Interactive or Background, max. UL: 64 kbps as described in TS 34.108, subclause 6.10.2.4.1.22 including described physical channel parameters, configuration for UM RLC max. DL: 64 kbps as described in TS 34.108, subclause 6.10.2.4.1.23 including described physical channel parameters, Residual BER as described in TS 34.108, clause: 6.10 Related Signalling RB UL: 3.4 kbps, DL: 3.4 kbps DCCH, No. #2 (as described in TS 34.108, Table 6.10.2.1.2) PS domain
- CN domain identity	
- RB information to setup	
- RB identity	5
- PDCP info	
- Support of lossless SRNS relocation	False (IE "Support of lossless SRNS relocation" only present, if RLC "In-sequence delivery" is TRUE and in UM)
- PDCP PDU header	absent
- RLC info	
- Downlink RLC mode	(UM RLC)

## Content of PDCP No Header PDU (Step 1)

Information Element	Value/remark
Data	PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.



## Content of PDCP No Header PDU (Step 3)

Information Element	Value/remark
Data	PDCP test data type #2: UDP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

## 7.3.2.2.1.5 Test requirements

**1. Test requirements: Transmission of uncompressed IP header packets using PDCP Data PDU**

The UE shall return the TCP/IP and UDP/IP data packets as indication, that the former packets have been received and handled correctly (PDCP Data PDU). This verifies, that the PDCP configuration on UE side works as negotiated by the RRC.

**2. Test requirements: Transmission of uncompressed IP header packets using PDCP No Header PDU**

The UE shall return the TCP/IP and UDP/IP data packets as indication, that the former packets have been received and handled correctly (PDCP No Header PDU). This verifies, that the PDCP configuration on UE side works as negotiated by the RRC.

## 7.3.2.2.2 Transmission of compressed Header

## 7.3.2.2.2.1 Definition and applicability

Applicable for all UEs supporting RLC UM and a Radio Bearer as described in the Common Test Sequences.

The UE shall be capable to deal with compressed TCP/IP and UDP/IP data packets and furthermore to establish a PDCP entity which applies IP header compression method RFC 2507.

## 7.3.2.2.2.2 Conformance requirement

Packet Data Convergence Protocol shall perform the following functions:

- ...

- transfer of user data. Transmission of user data means that PDCP receives PDCP SDU from the NAS and forwards it to the RLC layer and vice versa;

PDCP shall be able (...) to handle them with a correct header compression algorithm and furthermore to indicate the type of the packet within a certain algorithm.

## Reference(s)

TS 25.323 clause 5

TS 25.323 subclause 5.1.1

## 7.3.2.2.2.3 Test purpose

1. To verify, that the UE transmits and receives in unacknowledged mode (RLC UM) TCP/IP and UDP/IP data packets by using IP header compression method as described in RFC2507 as negotiated by RRC.
2. To verify, that the PID assignment rules are correctly applied by the UE. The UE shall use the correct PID value for the applied optimisation method for transmitting and receiving TCP/IP and UDP/IP data packets.

## 7.3.2.2.2.4 Method of test

## Initial conditions

UE is in Idle mode

## Related ICS/IXIT Statement(s)

Support of IP header compression method RFC 2507 - YES/NO

## Test procedure

- a) The SS setups a packet switched session including radio bearer and test loop back mode 1 in RLC UM using Common test procedures for mobile originated PS switched sessions. Usage of "PDCP Data" PDU has been negotiated by RRC.

- b) The SS sends a "normal" TCP/IP data packet (no compression packet type), PID=0.

NOTE: According to the compression algorithm RFC 2507, this is necessary for the decompression unit to create the internal CONTEXT with assigned CID.

- c) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet with the correct decompression method. Then, it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.

- d) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.

- e) The SS sends a TCP/IP data packet with packet type: Full\_Header, PID=1.

NOTE: According to the compression algorithm RFC 2507, this is necessary to transmit the created CONTEXT and the assigned CID.

- f) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet with the correct decompression method. Then, it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.

- g) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.

- h) The SS sends a TCP/IP data packet with packet type: Compressed\_TCP, PID=2.

- i) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet with the correct decompression method. Then, it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.

- j) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.

- k) The SS sends a TCP/IP data packet with packet type: Compressed\_TCP\_nondelta, PID=3.

- l) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet with the correct decompression method. Then, it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.

- m) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.

- n) Step b) to d) is repeated for a "normal" UDP/IP data packet, PID=0.

- o) Step e) to g) is repeated for a UDP/IP data packet with packet type: Full\_Header, PID=1.

- p) The SS sends a UDP/IP data packet with packet type: Compressed\_non\_TCP, PID=4.

- q) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet with the correct decompression method. Then, it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.
- r) The SS receives and decodes the UDP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.
- s) The SS deactivates the Loop back test mode and terminates the connection.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
Setup a UE originated PS session using IP Header compression in UM RLC (using Loop back test mode 1)				
1	←	PDCP Data	<p>The SS creates a TCP/IP packet without IP header compression.</p> <p>The SS sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content to the UE: PDU type = 000 (PDCP Data PDU) PID = 0 (uncompressed IP header) data: below described TCP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU and recognizes PID value = 0 (no IP header compression applied for this TCP/IP data packet) Therefore, no IP header decompression is applied for this packet.</p> <p>The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>	
2	→	PDCP Data	<p>The UE sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS: PDU type = 000 (PDCP Data PDU) PID value = 0 to 5, except 4 (depending on the TCP/IP header format used by the UE) data: former received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function dependent the assigned PID.</p>	
3	←	PDCP Data	<p>The SS sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content to the UE: PDU type = 000 (PDCP Data PDU) PID = 1 (Full_Header packet type [TCP/IP]) data: below described TCP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU, recognizes PID value = 1 applied for this TCP/IP data packet and decompresses it with the appropriate method. The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>	
4	→	PDCP Data	<p>The UE sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS: PDU type = 000 (PDCP Data PDU) PID value = 0 to 5, except 4 (depending on which TCP/IP header format is used by the UE) data: former received TCP/IP packet</p>	

Step	Direction		Message	Comments
	UE	SS		
				After reception of this TCP/IP data packet, the SS applies the appropriate decoding function dependent the assigned PID.
5	←		PDCP Data	<p>The SS sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content to the UE:  PDU type = 000 (PDCP Data PDU)  PID = 2 (Compressed_TCP packet type)  data: below described TCP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU, recognizes PID value = 2 applied for this TCP/IP data packet and decompress it with the appropriate method. The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>
6	→		PDCP Data	<p>The UE sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS:  PDU type = 000 (PDCP Data PDU)  PID value = 0 to 5, except 4 (depending on which TCP/IP header format is used by the UE)  Data: former received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function dependent the assigned PID.</p>
7	←		PDCP Data	<p>The SS sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content to the UE:  PDU type = 000 (PDCP Data PDU)  PID = 3 (Compressed_TCP_nondelta packet type)  Data: below described TCP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU, recognizes PID value = 3 applied for this TCP/IP data packet and decompress it with the appropriate method. The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>
8	→		PDCP Data	<p>The UE sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS:  PDU type = 000 (PDCP Data PDU)  PID value = 0 to 5, except 4 (depending on which TCP/IP header format is used by the UE)  data: former received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function dependent the assigned PID.</p>

Step	Direction		Message	Comments
	UE	SS		
9	←		PDCP Data	<p>The SS creates a UDP/IP packet without compressed IP header compression.</p> <p>The SS sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content to the UE:  PDU type = 000 (PDCP Data PDU)  PID = 0 (uncompressed IP header)  Data: below described UDP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU and recognizes with PID value = 0, there was no IP header compression applied for the UDP/IP packet. Therefore, no IP header decompression is applied for this packet.</p> <p>The data packet is forwarded via PDCP-SAP to the Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>
10	→		PDCP Data	<p>The UE sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS:  PDU type = 000 (Data PDU with Header)  PID value = 0, 1 or 4 (depending on which UDP/IP header format is used by the UE)  data: below described UDP/IP packet</p> <p>After reception of this UDP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>
11	←		PDCP Data	<p>The SS sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content to the UE:  PDU type = 000 (PDCP Data PDU)  PID = 1 (Full_Header packet type)  data: below described UDP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU and recognizes PID value = 1 applied for this UDP/IP data packet and decompress it with the appropriate method.</p> <p>The data packet is forwarded via PDCP-SAP to the Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>
12	→		PDCP Data	<p>The UE sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS:  PDU type = 000 (Data PDU with Header)  PID value = 0, 1 or 4 (depending on which UDP/IP header format is used by the UE)  data: below described UDP/IP packet</p>

Step	Direction		Message	Comments
	UE	SS		
				After reception of this UDP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.
13	←		PDCP Data	<p>The SS sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content to the UE:  PDU type = 000 (PDCP Data PDU)  PID = 4 (Compressed _non-TCP packet type)  data: below described UDP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU and recognizes PID value = 1 applied for this UDP/IP data packet and decompress it with the appropriate method.</p> <p>The data packet is forwarded via PDCP-SAP to the Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>
14	→		PDCP Data	<p>The UE sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS:  PDU type = 000 (Data PDU with Header)  PID value = 0,1 or 4 (depending on which UDP/IP header format is used by the UE)  data: below described UDP/IP packet</p> <p>After reception of this UDP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>
Deactivate a UE originated PS session using IP Header compression (using Loop back test mode 1)				

### Specific Message Contents

#### RRC CONNECTION SETUP message

The contents of the RRC CONNECTION SETUP message applied in the preamble "Setup a UE originated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) with the following exceptions:

Information Element	Value/remark
Capability update requirement - UE radio access capability update requirement	<p>TRUE</p> <p>NOTE: Value will be checked. Stated capability must be compatible with 34.123-2 (c.f. PICS/PIXIT statements in GSM) and the user settings</p>

## RADIO BEARER SETUP message

The contents of the RADIO BEARER SETUP message applied in the preamble "Setup a UE originated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) which fit to the here described parameters with the following exceptions:

Information Element	Value/remark
RAB information for setup - RAB info - RAB identity        - CN domain identity - RB information to setup - RB identity - PDCP info - Support of lossless SRNS relocation  - PDCP PDU header - Header compression information CHOICE <i>algorithm type</i> - RFC2507 - F_MAX_PERIOD - F_MAX_TIME - MAX_HEADER - TCP_SPACE - NON_TCP_SPACE - EXPECT_REORDERING  - RLC info - Downlink RLC mode	No. # 23 as described in TS 34.108, Table 6.10.2.1.1 Prioritised RABs. QoS parameter: Traffic Class: Interactive or Background, max. UL: 64 kbps as described in TS 34.108, subclause 6.10.2.4.1.22 including described physical channel parameters, configuration for UM RLC max. DL: 64 kbps as described in TS 34.108, subclause 6.10.2.4.1.23 including described physical channel parameters, Residual BER as described in TS 34.108, clause: 6.10 Related Signalling RB UL: 3.4 kbps, DL: 3.4 kbps DCCH, No. #2 (as described in TS 34.108, Table 6.10.2.1.2) PS domain  5  False (IE "Support of lossless SRNS relocation" only present, if RLC "In-sequence delivery" is TRUE and in UM) present 1  256 (Default) 5 (Default) 168 (Default) 15 (Default) 15 (Default) reordering expected (Default)  (UM RLC)

## Content of PDCP Data PDU (Step 1)

Information Element	Value/remark
PDU type PID Data	000 00000 (No header compression, PID = 0) PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

## Content of PDCP Data PDU (Step 3)

Information Element	Value/remark
PDU type PID Data	000 00001 (Full_Header, PID = 1) PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.



## Content of PDCP Data PDU (Step 5)

Information Element	Value/remark
PDU type	000
PID	00010 (Compressed_TCP, PID = 2)
Data	PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

## Content of PDCP Data PDU (Step 7)

Information Element	Value/remark
PDU type	000
PID	00011 (Compressed_TCP_non-delta, PID = 3)
Data	PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

## Content of PDCP Data PDU (Step 9)

Information Element	Value/remark
PDU type	000
PID	00000 (No header compression, PID = 0)
Data	PDCP test data type #2: UDP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

## Content of PDCP Data PDU (Step 11)

Information Element	Value/remark
PDU type	000
PID	00001 (Full_Header, PID = 1)
Data	PDCP test data type #2: UDP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

## Content of PDCP Data PDU (Step 13)

Information Element	Value/remark
PDU type	000
PID	00100 (Compressed_non-TCP, PID = 4)
Data	PDCP test data type #2: UDP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

## 7.3.2.2.5 Test requirements

The UE shall return the TCP/IP and UDP/IP data packets as indication, that the former packets have been received and handled with the correct compression method. This verifies, that the PDCP configuration on UE side works as negotiated by the RRC.

## 7.3.2.2.3 Extension of used compression methods

## 7.3.2.2.3.1 Definition and applicability

Applicable for all UEs supporting RLC UM and a Radio Bearer as described in the Common Test Sequences.

The UE shall be capable to deal with compressed TCP/IP data packets and furthermore to establish a PDCP entity which applies IP header compression method: RFC 2507.

#### 7.3.2.2.3.2 Conformance requirement

Packet Data Convergence Protocol shall perform the following functions:

- ...

- transfer of user data. Transmission of user data means that PDCP receives PDCP SDU from the NAS and forwards it to the RLC layer and vice versa;

PDCP shall be able (...) to handle them with a correct header compression algorithm and furthermore to indicate the type of the packet within a certain algorithm.

The PDCP layer shall be able to support several header compression algorithms and it shall always be possible to extend the list of supported algorithms in the future.

The table (PID value allocation table) is reconfigured every time the PDCP entity is reconfigured.

The assignment of the PID values follow the general rules listed below:

- PID values are reassigned for the PDCP entity after renegotiation of the header compression algorithms;
- the list of negotiated (or re-negotiated) header compression entities shall be examined, starting from the first one in the list. The number of PID values to be assigned is specified in the subclause for this algorithm;

#### Reference(s)

TS 25.323 clause 5

TS 25.323 subclause 5.1.1

TS 25.323 subclause 5.1

#### 7.3.2.2.3.3 Test purpose

1. To verify, that the UE is able to handle an extended PID value allocation table after PDCP reconfiguration as configured by RRC.

#### 7.3.2.2.3.4 Method of test

##### Initial conditions

UE is in Idle mode

##### Related ICS/IXIT Statement(s)

Support of IP header compression method RFC 2507 - YES/NO

##### Test procedure

- a) The SS setups a packet switched session including radio bearer and test loop back mode 1 in RLC UM using Common test procedures for mobile originated PS switched sessions (with test loop back mode 1). Usage of "PDCP Data PDU" and no optimisation method has been negotiated by RRC.
- b) The SS sends a TCP/IP data packet (no compression packet type), PID=0.
- c) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet correctly. Afterwards it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.
- d) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.

- e) The SS reconfigures (using RRC Radio Bearer Reconfiguration message) the PDCP entity by extending the PID value allocation table and therefore the applied optimisation method with the IP header compression method RFC 2507. The test loop back mode 1 in RLC UM is still active.
- f) The SS sends a TCP/IP data packet (no compression packet type), PID=0.
- g) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet correctly. Afterwards it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.
- h) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.
- i) The SS sends a TCP/IP data packet with packet type: Full\_Header, PID=1.
- j) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet correctly. Afterwards it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.
- k) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.
- l) The SS deactivates the Loop back test mode and terminates the connection.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
Setup a UE originated PS session using IP Header compression in UM RLC (using Loop back test mode 1)				
1	←	PDCP Data	<p>The SS creates a TCP/IP packet without IP header compression.</p> <p>The SS sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content to the UE: PDU type = 000 (PDCP Data PDU) PID = 0 (uncompressed IP header) data: below described TCP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU and recognizes PID value = 0 (no IP header compression applied for this TCP/IP data packet) Therefore, no IP header decompression shall be applied for this packet.</p> <p>The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>	
2	→	PDCP Data	<p>The UE sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS: PDU type = 000 (PDCP Data PDU) PID value = 0 data: former received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>	
3	←	RRC RADIO BEARER RECONFIGURATION	SS extends the "PID value allocation table" with IP header compression PID (RFC 2507) in the UE.	
4	→	RRC RADIO BEARER RECONFIGURATION COMPLETE	UE acknowledges its new settings	
5	←	PDCP Data	<p>The SS sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content to the UE: PDU type = 000 (PDCP Data PDU) PID = 0 (normal packet type [TCP/IP]) data: below described TCP/IP packet.</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU and recognizes PID value = 0 (no IP header compression applied for this TCP/IP data packet) Therefore, no IP header decompression shall be applied for this packet.</p> <p>The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>	

Step	Direction		Message	Comments
	UE	SS		
6	→		PDCP Data	<p>The UE sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS: PDU type = 000 (PDCP Data PDU) PID value = 0 to 5, except 4 (depending on which TCP/IP header format is used by the UE) data: former received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>
7	←		PDCP Data	<p>The SS sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content to the UE: PDU type = 000 (PDCP Data PDU) PID = 1 (Full_Header packet type [TCP/IP]) data: below described TCP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU and recognizes PID value = 1 applied for this TCP/IP data packet and shall decompress it with the appropriate method.</p> <p>The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>
8	→		PDCP Data	<p>The UE sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS: PDU type = 000 (PDCP Data PDU) PID value = 0 to 5, except 4 (depending on the TCP/IP header format used by UE) data: former received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>
Deactivate a UE originated PS session using IP Header compression (using Loop back test mode 1)				

## Specific Message Contents

## RRC RADIO BEARER RECONFIGURATION message

The contents of the RRC RADIO BEARER RECONFIGURATION message applied in the preamble "Setup a UE originated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) with the following exceptions:

Information Element	Value/remark
RB information to reconfigure list	1
RB information to reconfigure	
- PDCP info	
- PDCP PDU header	present
- Header compression information	1
CHOICE <i>algorithm type</i>	
- RFC2507	
- F_MAX_PERIOD	256 (Default)
- F_MAX_TIME	5 (Default)
- MAX_HEADER	168 (Default)
- TCP_SPACE	15 (Default)
- NON_TCP_SPACE	15 (Default)
- EXPECT_REORDERING	reordering expected (Default)

## RRC CONNECTION SETUP message

The contents of the RRC CONNECTION SETUP message applied in the preamble "Setup a UE originated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) with the following exceptions:

Information Element	Value/remark
Capability update requirement	
- UE radio access capability update requirement	TRUE NOTE: Value will be checked. Stated capability must be compatible with 34.123-2 (c.f. PICS/PIXIT statements in GSM) and the user settings

## RADIO BEARER SETUP message

The contents of the RADIO BEARER SETUP message applied in the preamble "Setup a UE originated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) which fit to the here described parameters with the following exceptions:

Information Element	Value/remark
RAB information for setup - RAB info - RAB identity      - CN domain identity - RB information to setup - RB identity - PDCP info - PDCP PDU header - RLC info - Downlink RLC mode	No. # 23 as described in TS 34.108, Table 6.10.2.1.1 Prioritised RABs. QoS parameter: Traffic Class: Interactive or Background, max. UL: 64 kbps as described in TS 34.108, subclause 6.10.2.4.1.22 including described physical channel parameters, configuration for UM RLC max. DL: 64 kbps as described in TS 34.108, subclause 6.10.2.4.1.23 including described physical channel parameters, Residual BER as described in TS 34.108, clause: 6.10 Related Signalling RB UL: 3.4 kbps, DL: 3.4 kbps DCCH, No. #2 (as described in TS 34.108, Table 6.10.2.1.2) PS domain  5  present  (UM RLC)

## Content of PDCP Data PDU (Step 1 and 5)

Information Element	Value/remark
PDU type PID Data	000 00000 (No header compression, PID = 0) PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

## Content of PDCP Data PDU (Step 7)

Information Element	Value/remark
PDU type PID Data	000 00001 (Full_Header, PID = 1) PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

## 7.3.2.2.3.5 Test requirements

After PDCP reconfiguration, the UE shall return the TCP/IP data packets as indication, that the extension of used optimisation method are applied by UE. This verifies, that the PDCP configuration on UE side works as negotiated by the RRC.

## 7.3.2.2.4 Compression type used for different entities

## 7.3.2.2.4.1 Definition and applicability

Applicable only for an UE supporting the establishment of more than one PDCP entity in parallel, i.e. it shall be possible to configure more than one Radio Bearer Loop Back entities (each PDCP entity are assigned via PDCP-SAP to its own Radio Bearer Loop Back entity).

Applicable for all UEs supporting RLC UM and a Radio Bearer as described in the Test procedure.

The UE shall be capable to deal with compressed TCP/IP data packets and furthermore it shall apply IP header compression method RFC 2507.

#### 7.3.2.2.4.2 Conformance requirement

Packet Data Convergence Protocol shall perform the following functions:

- ...

- transfer of user data. Transmission of user data means that PDCP receives PDCP SDU from the NAS and forwards it to the RLC layer and vice versa;

PDCP shall be able (...) to handle them with a correct header compression algorithm and furthermore to indicate the type of the packet within a certain algorithm.

The assignment of the PID values follow the general rules listed below:

- PID values are assigned independently to each PDCP entity;

Different PDCP entities may include header compression algorithms of the same type

#### Reference(s)

TS 25.323 clause 5

TS 25.323 subclause 5.1.1

TS 25.323 subclause 5.1

#### 7.3.2.2.4.3 Test purpose

NOTE: For this test case, the SS shall be configured to handle more than one received PDCP messages in parallel.

1. To verify, that a configured IP header compression algorithm are applied to compress and decompress TCP/IP data packets by several PDCP entities in parallel, if more than one entities are established, i.e. the UE uses the same PID to transmit two TCP/IP data packets with the same content in parallel using two Radio Bearer configurations.

#### 7.3.2.2.4.4 Method of test

Initial conditions

UE is in Idle mode

Related ICS/IXIT Statement(s)

Establishment of more than one PDCP entities - YES/NO

Support of IP header compression method RFC 2507 - YES/NO

Test procedure

- a) The SS setups a packet switched session including two radio bearer configurations in parallel in test loop back mode 1 and in RLC UM using Common test procedures for mobile originated PS switched sessions. Usage of IP header compression method RFC 2507 has been negotiated by RRC.
- b) The SS sends in parallel a "normal" TCP/IP data packet, PID=0 via both PDCP configurations to their peer entities.
- c) After having received the TCP/IP data packets, the PDCP entities of the UE shall recognize the PID value and shall handle the received data packet independent of the used PID with the correct decompression method. Then they forward the data to their Radio Bearer Loop Back entity. Both received data shall be returned by each Radio Bearer Loop Back entity.



- d) The SS receives and decodes TCP/IP data packets according to the inserted PID. The decoded data packets shall be identical with the data as sent before.
- e) After having received the TCP/IP data packets, the PDCP entities of the UE shall recognize the PID value and shall handle the received data packets independent of the used PID with the correct decompression method. Then they forward the data to their Radio Bearer Loop Back entity. Both received data shall be returned by each Radio Bearer Loop Back entity.
- f) The SS receives and decodes TCP/IP data packets according to the inserted PID. The decoded data packets shall be identical with the data as sent before.
- g) The SS deactivates the Loop back test mode and terminates the connection.

**Expected sequence**

Step	Direction		Message	Comments
	UE	SS		
Setup a UE originated PS session using IP Header compression in UM RLC (using Loop back test mode 1)				
1	←	PDCP Data	<p>The SS sends in parallel a PDCP Data PDU using the RLC-UM-Data-Request Primitive via both PDCP entities with the following contents to the UE: PDU type = 000 (PDCP Data PDU) PID = 0 (uncompressed IP header) data: below described TCP/IP packet</p> <p>After having received both PDCP Data PDUs, the UE decodes each PDU and recognizes PID value = 0 (no IP header compression applied for both TCP/IP data packets).</p> <p>Although the same PID is used for both PDUs, the UE shall handle them with the correct method and it forwards both data packets via PDCP-SAPs to their Radio Bearer Loop Back (RB LB) entities.</p> <p>The RB LB entities in loop back mode 1 return the received data packets and send them back to their PDCP entities.</p>	
2	→	PDCP Data	<p>The UE sends back for each PDCP configuration a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS: PDU type = 000 (PDCP Data PDU) PID value = 0 to 5, except 4 (depending on the TCP/IP header format used by UE) data: former received TCP/IP packet</p> <p>After reception of TCP/IP data packets, the SS applies the appropriate decoding function for both received messages depending on which PID was assigned to the received data</p>	
3	←	PDCP Data	<p>The SS sends in parallel a PDCP Data PDU using the RLC-UM-Data-Request Primitive via both PDCP entities with the following contents to the UE: PDU type = 000 (PDCP Data PDU) PID = 1 (Full_Header packet type [TCP/IP]) data: below described TCP/IP packet</p> <p>After having received both PDCP Data PDUs, the UE decodes each PDU and recognizes PID value = 1 (Full_Header packet type applied for both TCP/IP data packets).</p> <p>Although the same PID is used for both PDUs, the UE shall handle them with the correct method and it forwards both data packets via PDCP-SAPs to their Radio Bearer Loop Back (RB LB) entities.</p> <p>The RB LB entities in loop back mode 1 return the received data packets and send them back to their PDCP entities.</p>	

Step	Direction		Message	Comments
	UE	SS		
4	→		PDCP Data	<p>The UE sends back for each PDCP configuration a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS:  PDU type = 000 (PDCP Data PDU)  PID value = 0 to 5, except 4 (depending on the TCP/IP header format used by UE)  data: former received TCP/IP packet</p> <p>After reception of TCP/IP data packets, the SS applies the appropriate decoding function for both received messages depending on which PID was assigned to the received data</p>
Deactivate a UE originated PS session using IP Header compression (using Loop back test mode 1)				

### Specific Message Contents

#### RRC CONNECTION SETUP message

The contents of the RRC CONNECTION SETUP message applied in the preamble "Setup a UE originated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) with the following exceptions:

Information Element	Value/remark
Capability update requirement - UE radio access capability update requirement	TRUE NOTE: Value will be checked. Stated capability must be compatible with 34.123-2 (c.f. PICS/PIXIT statements in GSM) and the user settings

#### RADIO BEARER SETUP message

The contents of the RADIO BEARER SETUP message applied in the preamble "Setup a UE originated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) which fit to the here described parameters with the following exceptions:

Information Element	Value/remark
RAB information for setup - RAB info - RAB identity           - CN domain identity - RB information to setup - RB identity - PDCP info - PDCP PDU header - Header compression information CHOICE <i>algorithm type</i> - RFC2507 - F_MAX_PERIOD - F_MAX_TIME - MAX_HEADER - TCP_SPACE - NON_TCP_SPACE - EXPECT_REORDERING - RLC info - Downlink RLC mode - RB information to setup           - RB identity - PDCP info - PDCP PDU header - Header compression information CHOICE <i>algorithm type</i> - RFC2507 - F_MAX_PERIOD - F_MAX_TIME - MAX_HEADER - TCP_SPACE - NON_TCP_SPACE - EXPECT_REORDERING - RLC info - Downlink RLC mode	No. # 23 as described in TS 34.108, Table 6.10.2.1.1 Prioritised RABs. QoS parameter: Traffic Class: Interactive or Background, max. UL: 64 kbps as described in TS 34.108, subclause 6.10.2.4.1.22 including described physical channel parameters, configuration for UM RLC configuration for UM RLC max. DL: 64 kbps as described in TS 34.108, subclause 6.10.2.4.1.23 including described physical channel parameters, Residual BER as described in TS 34.108, clause: 6.10 Related Signalling RB UL: 3.4 kbps, DL: 3.4 kbps DCCH, No. #2 (as described in TS 34.108, Table 6.10.2.1.2) PS domain  5  present 1  256 (Default) 5 (Default) 168 (Default) 15 (Default) 15 (Default) reordering expected (Default)  (UM RLC) (NOTE: for RB ID 6, the same RAB configurations are used (No. # 23 as described in TS 34.108) as described for RB ID 5) 6  present 1  256 (Default) 5 (Default) 168 (Default) 15 (Default) 15 (Default) reordering expected (Default)  (UM RLC)

## Content of PDCP Data PDU (Step 1)

Information Element	Value/remark
PDU type	000
PID	00000 (No header compression, PID = 0)
Data	PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

## Content of PDCP Data PDU (Step 3)

Information Element	Value/remark
PDU type	000
PID	00001 (Full_Header, PID = 1)
Data	PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

#### 7.3.2.2.4.5 Test requirements

The UE shall return both TCP/IP data packets as indication that the former received data packets associated with the same PID value are handled in parallel with the same decompression method. This verifies, that more than one PDCP configuration on UE side using the same compression method is able to apply it in parallel.

#### 7.3.2.2.5 Reception of not defined PID values

##### 7.3.2.2.5.1 Definition and applicability

Applicable for all UEs supporting RLC UM and a Radio Bearer as described in the Common Test Sequences.

The UE shall be capable to deal with compressed TCP/IP data packets and furthermore to establish a PDCP entity, which applies PDCP Data PDU if no IP header compression method, is negotiated.

The UE shall not forward invalid PDCP PDU data contents to its Radio Bearer.

##### 7.3.2.2.5.2 Conformance requirement

PDCP shall be able (...) to handle them with a correct header compression algorithm and furthermore to indicate the type of the packet within a certain algorithm;

PID values that are used and are not defined invalidate the PDCP PDU;

##### Reference(s)

TS 25.323 subclause 5.1.1

TS 25.323 subclause 5.1.2.1

##### 7.3.2.2.5.3 Test purpose

1. To verify, that a UE considers a received PDCP PDU message with not defined PID value as invalid, i.e. such an invalid PDCP PDU is not forwarded to the Radio Bearer entity on UE side. Therefore the UE using loop back mode 1 does not return such data packet to the SS.

##### 7.3.2.2.5.4 Method of test

##### Initial conditions

UE is in Idle mode

##### Related ICS/IXIT Statement(s)

##### Test procedure

- a) The SS setups a packet switched session including radio bearer and test loop back mode 1 in RLC UM using Common test procedures for mobile originated PS switched sessions. Usage of "PDCP Data PDU" and no PDCP IP header compression method has been negotiated by RRC.
- b) The SS sends a "normal" TCP/IP data packet (no compression packet type), PID=0.

- c) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet with the correct decoding method. Afterwards it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.
- d) The SS receives and decodes TCP/IP data packets according to the inserted PID. The decoded data packets shall be identical with the data as sent before.
- e) The SS sends a TCP/IP data packet with packet type: Full\_Header, PID=1.
- f) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet with the correct decoding method. Afterwards it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.
- g) The SS waits an amount of time to make sure, that no returned data packet was sent by UE.
- h) The SS deactivates the Loop back test mode and terminates the connection.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
Setup a UE originated PS session using IP Header compression in UM RLC (using Loop back test mode 1)				
1	←	PDCP Data	<p>The SS sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content to the UE: PDU type = 000 (PDCP Data PDU) PID = 0 (uncompressed IP header) data: below described TCP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU and recognizes PID value = 0 (no IP header compression applied for this TCP/IP data packet) Therefore, no IP header decompression shall be applied for this packet.</p> <p>The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>	
2	→	PDCP Data	<p>The UE sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS: PDU type = 000 (PDCP Data PDU) PID value = 0 data: former received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>	
3	←	PDCP Data	<p>The SS sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content to the UE: PDU type = 000 (PDCP Data PDU) PID = 1 (Full_Header packet type [TCP/IP]) data: below described TCP/IP packet.</p> <p>After having received the PDCP Data PDU, the UE shall recognize, that a not defined PID value (as negotiated by RRC) is inserted in the PDCP PDU.</p> <p>The UE shall consider this PDU as invalid, i.e. the data packet is not forwarded via PDCP-SAP to its Radio Bearer Loop Back (RB LB) entity.</p> <p>Therefore this data packet is not returned to the SS.</p>	
4			<p>The SS waits a amount of time to make sure, that the former data packet is not returned to the SS.</p>	
Deactivate a UE originated PS session using IP Header compression (using Loop back test mode 1)				

## Specific Message Contents

## RRC CONNECTION SETUP message

The contents of the RRC CONNECTION SETUP message applied in the preamble "Setup a UE originated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) with the following exceptions:

Information Element	Value/remark
Capability update requirement - UE radio access capability update requirement	TRUE NOTE: Value will be checked. Stated capability must be compatible with 34.123-2 (c.f. PICS/PIXIT statements in GSM) and the user settings

## RADIO BEARER SETUP message

The contents of the RADIO BEARER SETUP message applied in the preamble "Setup a UE originated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) which fit to the here described parameters with the following exceptions:

Information Element	Value/remark
RAB information for setup - RAB info - RAB identity	No. # 23 as described in TS 34.108, Table 6.10.2.1.1 Prioritised RABs. QoS parameter: Traffic Class: Interactive or Background, max. UL: 64 kbps as described in TS 34.108, subclause 6.10.2.4.1.22 including described physical channel parameters, configuration for UM RLC max. DL: 64 kbps as described in TS 34.108, subclause 6.10.2.4.1.23 including described physical channel parameters, Residual BER as described in TS 34.108, clause: 6.10 Related Signalling RB UL: 3.4 kbps, DL: 3.4 kbps DCCH, No. #2 (as described in TS 34.108, Table 6.10.2.1.2) PS domain
- CN domain identity	
- RB information to setup	
- RB identity	5
- PDCP info	
- PDCP PDU header	present
- RLC info	
- Downlink RLC mode	(UM RLC)

## Content of PDCP Data PDU (Step 1)

Information Element	Value/remark
PDU type	000
PID	00000 (No header compression, PID = 0)
Data	PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.



## Content of PDCP Data PDU (Step 3)

Information Element	Value/remark
PDU type	000
PID	00001 (Full_Header, PID = 1)
Data	PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

## 7.3.2.2.5.5 Test requirements

The UE shall return the received TCP/IP data packet using the PDCP Data PDU with PID = 0 as indication, that the UE works as configured.

The UE shall not return the TCP/IP data packet using the PDCP Data PDU with PID = 1 as indication, that this PDU was considered as invalid by the UE. This verifies, that the PDCP configuration on UE side has considered this PDU as invalid.

## 7.3.3 PDCP sequence numbering when lossless SRNS Relocation

## 7.3.3.1 Data transmission if lossless SRNS Relocation is supported

## 7.3.3.1.1 Definition and applicability

Applicable for all UEs supporting RLC AM, RLC in-sequence delivery, a Radio Bearer as described in the Common Test Sequences and lossless SRNS relocation.

The UE shall be capable to deal with uncompressed TCP/IP data packets and furthermore to establish a PDCP entity which applies PDCP Sequence Numbering

## 7.3.3.1.2 Conformance requirement

The PDCP layer shall carry out the following functions during lossless SRNS relocation:

- forwarding of PDCP SDUs and associated sequence numbering;

## Reference(s)

TS 25.323 subclause 5.4

## 7.3.3.1.3 Test purpose

1. To verify, that a UE supporting lossless SRNS relocation is able to receive and to send IP data packets by using PDCP Sequence Numbering as negotiated by RRC.

## 7.3.3.1.4 Method of test

## Initial conditions

SS: 2 cells - Cell A belonging to the valid SRNS (Source SRNS), Cell B belonging to the DRNS (Target SRNS). Both cells are neighbour cells. Cell A has a higher RF power level than Cell B such that an UE shall find Cell A more suitable for service.

UE: It is in Idle mode and has selected cell A with valid SRNS (Source SRNS).

## Related ICS/IXIT Statement(s)

Support of lossless SRNS Relocation - YES/NO

Support of RLC in-sequence delivery - YES/NO

## Test procedure

- a) The SS setups a packet switched session including Radio Bearer and test loop back mode 1 in RLC AM and in-sequence delivery using Common test procedures for mobile originated PS switched sessions in Cell A. Usage of "PDCP Data" PDU, support of lossless SRNS relocation and no IP header compression has been negotiated by RRC. The PDCP SN window size has been negotiated by RRC.
- b) The SS sends a TCP/IP data packet (no compression packet type), PID=0.
- c) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet correctly. Afterwards it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.
- d) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.
- e) The SS starts to broadcast BCCH messages on the primary CPICH in cell B with a power level higher than in cell A. The UE shall chose cell B to be more suitable for service and hence perform a cell reselection.
- f) After completion of cell reselection, the UE transmits a CELL UPDATE message to the SS on the uplink CCCH of cell B with the Cell update cause "Cell Reselection".
- g) After having performed SRNS relocation (target RNC allocated with new S-RNTI for the UE), the Target SRNS is the valid SRNS and the SS sends a "CELL UPDATE CONFIRM" message with new RNC\_ID to indicate the completion of the cell update.
- h) The UE shall confirm the reallocation.
- i) The SS sends the next TCP/IP data packet (no compression packet type), PID=0 using the "PDCP Data" PDU to the UE.
- j) After having received the TCP/IP data packet, the UE shall recognize the PID value and shall handle the received data packet correctly. Afterwards it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.
- k) The SS receives and decodes TCP/IP data packets according to the inserted PID. The decoded data packets shall be identical with the data as sent before.
- l) The SS deactivates the Loop back test mode and terminates the connection.

## Expected sequence

Step	Direction		Message	Comments	
	UE	SS			
Setup a UE originated PS session using IP Header compression in AM RLC (using Loop back test mode 1) in Cell A					
1	←	PDCP Data	<p>The SS creates a TCP/IP packet without IP header compression.</p> <p>The SS sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content to the UE: PDU type = 000 (PDCP Data PDU) PID = 0 (uncompressed IP header) data: below described TCP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU and recognizes PID value = 0 (no IP header compression applied for this TCP/IP data packet) Therefore, no IP header decompression shall be applied for this packet.</p> <p>The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>		
2	→	PDCP Data	<p>The UE sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content back to the SS: PDU type = 000 (PDCP Data PDU) PID value = 0 data: former received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>		
3	→	RRC CELL UPDATE	<p>The SS increases the RF power level of cell B and decreases the power level of Cell A such that the UE finds cell B more suitable for service.</p>		
4			<p>The UE cell reselection is performed and Cell B are selected for service.</p>		
5			<p>Then, the UE shall inform the SS about the new cell selection by sending cell update with new parameters (parameter values as used in RRC testing).</p>		
6			←	RRC CELL UPDATE CONFIRM	<p>After having performed SRNS relocation, the Target SRNS is the valid SRNS and the SS sends a "CELL UPDATE CONFIRM" message with new parameter "RNC_ID" to indicate the completion of SRNS relocation (parameters as used in RRC testing).</p>
7			→	RNTI REALLOCATION COMPLETE	<p>The UE confirms the newly received information (parameters as used in RRC testing).</p>

Step	Direction		Message	Comments
	UE	SS		
8		←	PDCP Data	<p>The SS sends the next PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content to the UE:  PDU type = 000 (PDCP Data PDU)  PID = 0 (uncompressed IP header)  data: below described TCP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU and recognizes PID value = 0 (no IP header compression applied for this TCP/IP data packet)</p> <p>Therefore, no IP header decompression shall be applied for this packet.</p> <p>The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>
9		→	PDCP Data	<p>The UE sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content back to the SS:  PDU type = 000 (PDCP Data PDU)  PID value = 0  data: former received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>
Deactivate a UE originated PS session using IP Header compression (using Loop back test mode 1)				

### Specific Message Contents

#### RRC CONNECTION SETUP message

The contents of the RRC CONNECTION SETUP message applied in the preamble "Setup a UE originated PS session using IP Header compression in AM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for AM) with the following exceptions:

Information Element	Value/remark
Capability update requirement - UE radio access capability update requirement	TRUE NOTE: Value will be checked. Stated capability must be compatible with 34.123-2 (c.f. PICS/PIXIT statements in GSM) and the user settings

#### RADIO BEARER SETUP message

The contents of the RADIO BEARER SETUP message applied in the preamble "Setup a UE originated PS session using IP Header compression in AM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for AM) which fit to the here described parameters with the following exceptions:

Information Element	Value/remark
RAB information for setup - RAB info - RAB identity        - CN domain identity - RB information to setup - RB identity - PDCP info - Max PDCP SN - Support of lossless SRNS relocation - PDCP PDU header - RLC info - Downlink RLC mode - In-sequence delivery	No. # 23 as described in TS 34.108, Table 6.10.2.1.1 Prioritised RABs. QoS parameter: Traffic Class: Interactive or Background, max. UL: 64 kbps as described in TS 34.108, subclause 6.10.2.4.1.22 including described physical channel parameters, configuration for AM RLC max. DL: 64 kbps as described in TS 34.108, subclause 6.10.2.4.1.23 including described physical channel parameters, Residual BER as described in TS 34.108, clause: 6.10 Related Signalling RB UL: 3.4 kbps, DL: 3.4 kbps DCCH, No. #2 (as described in TS 34.108, Table 6.10.2.1.2) PS domain  5  65535 TRUE present  (AM RLC) True

## Content of PDCP Data PDU (Step 1)

Information Element	Value/remark
PDU type PID Data	000 00000 (No header compression, PID = 0) PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

## Content of PDCP Data PDU (Step 8)

Information Element	Value/remark
PDU type PID Data	000 00000 (No header compression, PID = 0) PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

## 7.3.3.1.5 Test requirements

After having sent the "RRC RNTI REALLOCATION COMPLETE", the UE shall return the received TCP/IP data packets as indication, that it supports lossless SRNS relocation. This implicitly verifies, that Sequence Numbering is used for lossless SRNS relocation.

## 7.3.3.2 Synchronisation of PDCP sequence numbers

## 7.3.3.2.1 Definition and applicability

Applicable for all UEs supporting RLC AM, RLC in-sequence delivery, a Radio Bearer as described in the Common Test Sequences.

The UE shall be capable to deal with compressed TCP/IP and UDP/IP data packets and furthermore it shall be capable to use IP Header compression method RFC 2507.

#### 7.3.3.2.2 Conformance requirement

The PDCP SeqNum PDU shall be sent once by the peer PDCP entities when synchronisation of the PDCP SN is required. (...) Synchronisation of PDCP SN is required after (...) RB reconfiguration.

#### Reference(s)

TS 25.323 subclause 5.4

#### 7.3.3.2.3 Test purpose

1. To verify, that the UE supporting lossless SRNS relocation as negotiated by RRC is able to handle the "PDCP SeqNum" PDU to synchronize the used PDCP Sequence Number after reconfiguration of the Radio Bearer.

#### 7.3.3.2.4 Method of test

##### Initial conditions

SS: 2 cells - Cell A belonging to the valid SRNS (Source SRNS), Cell B belonging to the DRNS (Target SRNS). Both cells are neighbour cells. Cell A has a higher RF power level than Cell B such that an UE shall find Cell A more suitable for service.

UE: It is in Idle mode and has selected cell A with valid SRNS (Source SRNS).

##### Related ICS/IXIT Statement(s)

Support of lossless SRNS relocation - YES/NO

Support of RLC in-sequence delivery - YES/NO

##### Test procedure

- a) The SS setups a packet switched session including Radio Bearer and test loop back mode 1 in RLC AM and in-sequence delivery using Common test procedures for mobile originated PS switched sessions in Cell A. Usage of "PDCP Data" PDU, support of lossless SRNS relocation and no IP header compression has been negotiated by RRC. The PDCP SN window size has been negotiated by RRC.
- b) The SS sends a TCP/IP data packet (no compression packet type), PID=0.
- c) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet correctly. Afterwards it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.
- d) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.
- e) The SS reconfigures (using RRC Radio Bearer Reconfiguration message) the PDCP entity by extending the PID value allocation table and therefore the applied optimisation method with the IP header compression method RFC 2507. The test loop back mode 1 in RLC AM is still active.
- f) The SS sends the next TCP/IP data packet (no compression packet type), PID=0 using the "PDCP SeqNum" PDU including the current PDCP Sequence Number value to the UE.
- g) After having received the TCP/IP data packet, the UE shall recognize the PID value and shall handle the received data packet correctly. Afterwards it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.

- h) The SS receives and decodes TCP/IP data packets according to the inserted PID. The decoded data packets shall be identical with the data as sent before.
- i) The SS deactivates the Loop back test mode and terminates the connection.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
Setup a UE originated PS session using IP Header compression in AM RLC (using Loop back test mode 1) in Cell A				
1	←	PDCP Data	<p>The SS creates a TCP/IP packet without IP header compression.</p> <p>The SS sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content to the UE: PDU type = 000 (PDCP Data PDU) PID = 0 (uncompressed IP header) data: below described TCP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU and recognizes PID value = 0 (no IP header compression applied for this TCP/IP data packet) Therefore, no IP header decompression shall be applied for this packet.</p> <p>The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>	
2	→	PDCP Data	<p>The UE sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content back to the SS: PDU type = 000 (PDCP Data PDU) PID value = 0 data: former received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>	
3	←	RRC RADIO BEARER RECONFIGURATION	SS extends the "PID value allocation table" with IP header compression PID (RFC 2507) in the UE.	
4	→	RRC RADIO BEARER RECONFIGURATION COMPLETE	UE acknowledges its new settings	
5	←	PDCP SeqNum	<p>The SS sends a PDCP SeqNum PDU including its current Sequence Number with the following content to the UE: PDU type = 001 (PDCP SeqNum PDU) PID = 0 (normal packet type [TCP/IP]) SeqNum = current PDCP Sequence Number data: below described TCP/IP packet</p> <p>After having received the PDCP SeqNum PDU, the UE shall set the received PDCP Sequence Number as its own valid value. It decodes the PDU, recognizes PID value = 0 applied for this TCP/IP data packet and shall decompress it with the appropriate method.</p> <p>The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop Back (RB LB) entity.</p> <p>The RB LB entity in loop back mode 1 returns the received data packet and sends it back to its PDCP entity.</p>	



Step	Direction		Message	Comments
	UE	SS		
6		→	PDCP PDU	<p>The UE sends a PDCP PDU with PDCP Header back to the SS. The content is as follows:  PDU type = 000 (PDCP Data PDU)  PID value = 0 to 5, except 4 (depending on the TCP/IP Header format used by UE)  SeqNum: current UE value, (optional parameter, depending on the used PDU)  data: former received TCP/IP packet.</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>
Deactivate a UE originated PS session using IP Header compression (using Loop back test mode 1)				

### Specific Message Contents

#### RRC RADIO BEARER RECONFIGURATION message

The contents of the RRC RADIO BEARER RECONFIGURATION message applied in the preamble "Setup a UE originated PS session using IP Header compression in AM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for AM) with the following exceptions:

Information Element	Value/remark
RB information to reconfigure list	1
RB information to reconfigure	
- PDCP info	
- Max PDCP SN	65535
- Support of lossless SRNS relocation	TRUE
- PDCP PDU header	present
- Header compression information	1
CHOICE <i>algorithm type</i>	
- RFC2507	
- F_MAX_PERIOD	256 (Default)
- F_MAX_TIME	5 (Default)
- MAX_HEADER	168 (Default)
- TCP_SPACE	15 (Default)
- NON_TCP_SPACE	15 (Default)
- EXPECT_REORDERING	reordering expected (Default)

#### RRC CONNECTION SETUP message

The contents of the RRC CONNECTION SETUP message applied in the preamble "Setup a UE originated PS session using IP Header compression in AM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for AM) with the following exceptions:

Information Element	Value/remark
Capability update requirement	
- UE radio access capability update requirement	TRUE
	NOTE: Value will be checked. Stated capability must be compatible with 34.123-2 (c.f. PICS/PIXIT statements in GSM) and the user settings

#### RADIO BEARER SETUP message

The contents of the RADIO BEARER SETUP message applied in the preamble "Setup a UE originated PS session using IP Header compression in AM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for AM) which fit to the here described parameters with the following exceptions:

Information Element	Value/remark
RAB information for setup - RAB info - RAB identity        - CN domain identity - RB information to setup - RB identity - PDCP info - Max PDCP SN - Support of lossless SRNS relocation - PDCP PDU header - RLC info - Downlink RLC mode - In-sequence delivery	No. # 23 as described in TS 34.108, Table 6.10.2.1.1 Prioritised RABs. QoS parameter: Traffic Class: Interactive or Background, max. UL: 64 kbps as described in TS 34.108, subclause 6.10.2.4.1.22 including described physical channel parameters, configuration for AM RLC max. DL: 64 kbps as described in TS 34.108, subclause 6.10.2.4.1.23 including described physical channel parameters, Residual BER as described in TS 24.108, clause: 6.10 Related Signalling RB UL: 3.4 kbps, DL: 3.4 kbps DCCH, No. #2 (as described in TS 34.108, Table 6.10.2.1.2) PS domain  5 65535 TRUE present  (AM RLC) True

#### Content of PDCP Data PDU (Step 1)

Information Element	Value/remark
PDU type PID Data	000 00000 (No header compression, PID = 0) PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

#### Content of PDCP SeqNum PDU (Step 5)

Information Element	Value/remark
PDU type PID Sequence number Data	001 00000 (No header compression, PID = 0) (16 Bit value) valid Sequence Number of the SS PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 5 Kbytes.

#### 7.3.3.2.5 Test requirements

After having received the TCP/IP data packet conveyed with the "PDCP SeqNum" PDU, the UE shall return the TCP/IP data packets as indication, that the UE is able to handle a Sequence Number synchronisation.

## 7.4 BMC

### General

For BMC test description it is assumed, that UE manufacturers define CB data contents (CB-Data 1 and 2) for two different CB message types and describe how the reception is indicated in a clear way on the UE side.

Only Cell Broadcast Services (CBS) as distributed BMC service are applied. For a UE supporting BMC, it is assumed, that there is a BMC entity established, if Initial conditions are reached.

If not otherwise mentioned, the same procedures as used in RRC test specification [TS 34.123-1] applies to reach Initial conditions for BMC testing. The system information methods used to configure the BMC channel are mapped onto one FACH.

It shall be possible to activate and deactivate a certain CB message ID according to (CB data 1 and 2) triggered by the user on the UE side.

## 7.4.1 General BMC message reception

### 7.4.1.1 UE in RRC Idle mode

#### 7.4.1.1.1 Definition and applicability

Applicable only for a UE supporting Cell Broadcast Services (CBS) as a type of Broadcast/Multicast Services.

It shall be possible to indicate the reception of certain CBS message contents carried with certain activated CB message types in a clear way on the UE side.

#### 7.4.1.1.2 Conformance requirement

A UE supporting Cell Broadcast Services shall be capable to receive BMC messages in RRC Idle mode.

#### Reference(s)

TS 25.324 subclause 9.1

#### 7.4.1.1.3 Test purpose

To verify, that a BMC configuration for a UE is able to receive activated CBS messages when in RRC Idle mode.

#### 7.4.1.1.4 Method of test

##### Initial conditions

UE is in RRC Idle mode; BMC entity is established

SS: 1 cell,

NOTE: The CB message ID stored on the SIM shall be known for this test (parameter for CBS PDU's). The CBS data type shall be allocated and activated in the UE.

##### Related ICS/IXIT Statement(s)

ICS: CBS message support - YES/No

IXIT: CBS-Data 1: Bitstring of  $N \times 8$  (where  $N \geq 1$  and less than 1246)

NOTE: For CB-Data 1 IXIT, the manufacturer shall define CBS data as Bitstring together with the CB message ID used for transmitting this CB data, which is indicated by the UE after reception in a clear way according to the capabilities stored on the SIM. Furthermore, the manufacturer shall describe the indication on the UE side (e.g. certain CBS traffic information)

##### Test procedure

- The UE in RRC Idle mode is triggered to wait for the next system information. The UE is activated to receive expected CBS messages as described by the manufacturer,

- b) The UE and the SS have configured their RLC, MAC and PHYs layers with all CB related system information, broadcasted by SS
- c) The SS sends the CBS message containing an activated CBS message type according to CB-Data 1 to the UE; this shall be repeated for "CPREP" times (indicated by parameter "repetition period" in the schedule information)
- d) The UE indicates in an unambiguous way, that this message was received, by certain clear indications (e.g. a unique part of the CB data contents)

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		←	SYSTEM INFORMATION	Transmit this message as described below on the BCCH, in addition to the regular BCCH transmissions (see RRC test description). Included are CB related system information parameter of the CBS: - CTCH ID, - FACH ID and associated format set, - S-CCPCH ID, - CBS DRX Level 1 information (optional) - optional: Period of CTCH allocation on S-CCPCH - optional: CBS frame offset
2				The SS waits for about 10 s to make sure, that the UE is configured to receive CBS data
3		←	BMC CBS Message	Activated CBS message with CB Data 1 message content as described by the manufacturer. This message shall be repeated "CPREP" times, Parameter: - Message_ID, - Serial-No, - Data coding scheme, - CB-Data 1,
4				After having received the BMC CBS message the UE shall indicate the reception of CB Data 1 in a clear way.

#### Specific Message Contents

##### SYSTEM INFORMATION TYPE 5

The contents of SYSTEM INFORMATION TYPE 5 Information Element in this test case are identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] with the following exceptions:

Information Element	Value/remark
CHOICE mode	(see RRC default test settings)
PRACH system information	(see RRC default test settings)
Secondary CCPCH system	
- Secondary CCPCH information	1
- TFCS	(see RRC default test settings)
- FACH/PCH information	1
- TFS	(see RRC default test settings)
- CTCH indicator	TRUE
- PICH info	(see RRC default test settings)

## BMC CBS Message

Information Element Message Type	Value/remark 1 (CBS message)
Message ID	Bitstring (16) CB message ID, it shall fit to the stored Message ID in the SIM inserted in the UE (source and type) [see TS 23.041] according to the transmitted CB-Data 1 content.
Serial Number - Geographic Scope Indicator (2 bit) - Message Code (10 bit) - Update Number (4 bit)	[see TS 23.041] 11 (Normal Cell wide) in accordance with the Message ID for a new message: 0000, incremented by one for each repetition
Data Coding Scheme	Bitstring (16) ID of the alphabet/coding and the applied language [see TS 23.041]
CB Data	Bitstring (N*8), [see Ixit value: CB-Data 1]

## 7.4.1.1.5 Test requirements

The UE shall store and decode a received activated CBS message.

## 7.4.1.2 UE in RRC Connected mode, state CELL\_PCH

## 7.4.1.2.1 Definition and applicability

Applicable only for a UE supporting Cell Broadcast Services (CBS) as a type of Broadcast/Multicast Services.

It shall be possible to indicate the reception of certain CBS message contents carried with certain activated CB message types in a clear way on the UE side.

## 7.4.1.2.2 Conformance requirement

A UE supporting Cell Broadcast Service (CBS) shall be capable to receive BMC messages (...) in CELL\_PCH RRC-state of Connected mode.

## Reference(s)

TS 25.324 subclause 9.1

## 7.4.1.2.3 Test purpose

To verify, that a BMC configuration for a UE is able to receive activated CBS messages when in RRC Connected mode, state CELL\_PCH.

## 7.4.1.2.4 Method of test

## Initial conditions

UE is in Connected mode state CELL\_PCH; BMC entity is established

SS: 1 cell,

NOTE: The CB message ID stored on the SIM shall be known for this test (parameter for CBS PDU's). The CBS data type shall be allocated and activated in the UE.

## Related ICS/IXIT Statement(s)

ICS: CBS message support - YES/No

IXIT: CBS-Data 1: Bitstring of  $N \times 8$  (where  $N \geq 1$  and less than 1246)

NOTE: For CB-Data 1 IXIT, the manufacturer shall define CBS data as Bitstring together with the CB message ID used for transmitting this CB data, which is indicated by the UE after reception in a clear way according to the capabilities stored on the SIM. Furthermore, the manufacturer shall describe the indication on the UE side (e.g. certain CBS traffic information)

#### Test procedure

- The UE in RRC CELL\_PCH is triggered to wait for the next system information. The UE is activated to receive expected CBS messages as described by the manufacturer,
- The UE and the SS have configured their RLC, MAC and PHYs layers with all CB related system information, broadcasted by SS
- The SS sends the CBS message containing an activated CBS message type according to CB-Data 1 to the UE; this shall be repeated for "CPREP" times (indicated by parameter "repetition period" in the schedule information)
- The UE indicates in an unambiguous way, that this message was received, by certain clear indications (e.g. a unique part of the CB data contents)

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		←	SYSTEM INFORMATION	Transmit this message as described below on the BCCH, in addition to the regular BCCH transmissions (see RRC test description). Included are CB related system information parameter of the CBS: - CTCH ID, - FACH ID and associated format set, - S-CCPCH ID, - CBS DRX Level 1 information (optional) - optional: Period of CTCH allocation on S-CCPCH - optional: CBS frame offset
2				The SS waits for about 10 s to make sure, that the UE is configured to receive CBS data
3		←	BMC CBS Message	Activated CBS message with CB Data 1 message content as described by the manufacturer. This message shall be repeated "CPREP" times, Parameter: - Message_ID, - Serial-No, - Data coding scheme, - CB-Data 1,
4				After having received the BMC CBS message the UE shall indicate the reception of CB Data 1 in a clear way.

#### Specific Message Contents

##### SYSTEM INFORMATION TYPE 6

The contents of SYSTEM INFORMATION TYPE 6 Information Element in this test case are identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] with the following exceptions:

Information Element	Value/remark
CHOICE mode	(see RRC default test settings)
PRACH system information	(see RRC default test settings)
Secondary CCPCH system	
- Secondary CCPCH information	1
- TFCS	(see RRC default test settings)
- FACH/PCH information	1
- TFS	(see RRC default test settings)
- CTCH indicator	TRUE
- PICH info	(see RRC default test settings)

### BMC CBS Message

Information Element	Value/remark
Message Type	1 (CBS message)
Message ID	Bitstring (16) CB message ID, it shall fit to the stored Message ID in the SIM inserted in the UE (source and type) [see TS 23.041] according to the transmitted CB-Data 1 content.
Serial Number	[see TS 23.041]
- Geographic Scope Indicator (2 bit)	11 (Normal Cell wide)
- Message Code (10 bit)	in accordance with the Message ID
- Update Number (4 bit)	for a new message: 0000, incremented by one for each repetition
Data Coding Scheme	Bitstring (16) ID of the alphabet/coding and the applied language [see TS 23.041]
CB Data	Bitstring (N*8), [see IXIT value: CB-Data 1]

#### 7.4.1.2.5 Test requirements

The UE shall store and decode a received activated CBS message.

### 7.4.1.3 UE in RRC Connected mode, state URA\_PCH

#### 7.4.1.3.1 Definition and applicability

Applicable only for a UE supporting Cell Broadcast Services (CBS) as a type of Broadcast/Multicast Services.

It shall be possible to indicate the reception of certain CBS message contents carried with certain activated CB message types in a clear way on the UE side.

#### 7.4.1.3.2 Conformance requirement

A UE supporting Cell Broadcast Service (CBS) shall be capable to receive BMC messages (...) in CELL\_URA RRC-state of Connected mode.

#### Reference(s)

TS 25.324 subclause 9.1

#### 7.4.1.3.3 Test purpose

To verify, that a BMC configuration for a UE is able to receive activated CBS messages when in RRC Connected mode, state CELL\_URA.

#### 7.4.1.3.4 Method of test

##### Initial conditions

UE is in Connected mode state CELL\_URA; BMC entity is established

SS: 1 cell,

NOTE: The CB message ID stored on the SIM shall be known for this test (parameter for CBS PDU's). The CBS data type shall be allocated and activated in the UE.

##### Related ICS/IXIT Statement(s)

ICS: CBS message support - YES/No

IXIT: CBS-Data 1: Bitstring of N\*8 (where  $N \geq 1$  and less than 1246)

NOTE: For CB-Data 1 IXIT, the manufacturer shall define CBS data as Bitstring together with the CB message ID used for transmitting this CB data, which is indicated by the UE after reception in a clear way according to the capabilities stored on the SIM. Furthermore, the manufacturer shall describe the indication on the UE side (e.g. certain CBS traffic information)

##### Test procedure

- a) The UE in RRC CELL\_URA is triggered to wait for the next system information. The UE is activated to receive expected CBS messages as described by the manufacturer,
- b) The UE and the SS have configured their RLC, MAC and PHYs layers with all CB related system information, broadcasted by SS
- c) The SS sends the CBS message containing an activated CBS message type according to CB-Data 1 to the UE, this shall be repeated for "CPREP" times (indicated by parameter "repetition period" in the schedule information)
- d) The UE indicates in an unambiguous way, that this message was received, by certain clear indications (e.g. a unique part of the CB data contents)



## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	←		SYSTEM INFORMATION	Transmit this message as described below on the BCCH, in addition to the regular BCCH transmissions (see RRC test description). Included are CB related system information parameter of the CBS: - CTCH ID, - FACH ID and associated format set, - S-CCPCH ID, - CBS DRX Level 1 information (optional) - optional: Period of CTCH allocation on S-CCPCH - optional: CBS frame offset
2				The SS waits for about 10 s to make sure, that the UE is configured to receive CBS data
3	←		BMC CBS Message	Activated CBS message with CB Data 1 message content as described by the manufacturer. This message shall be repeated "CPREP" times, Parameter: - Message_ID, - Serial-No, - Data coding scheme, - CB-Data 1,
4				After having received the BMC CBS message the UE shall indicate the reception of CB Data 1 in a clear way.

## Specific Message Contents

## SYSTEM INFORMATION TYPE 6

The contents of SYSTEM INFORMATION TYPE 6 Information Element in this test case are identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] with the following exceptions:

Information Element	Value/remark
CHOICE mode	(see RRC default test settings)
PRACH system information	(see RRC default test settings)
Secondary CCPCH system	
- Secondary CCPCH information	1
- TFCS	(see RRC default test settings)
- FACH/PCH information	1
- TFS	(see RRC default test settings)
- CTCH indicator	TRUE
- PICH info	(see RRC default test settings)

## BMC CBS Message

Information Element	Value/remark
Message Type	1 (CBS message)
Message ID	Bitstring (16) CB message ID, it shall fit to the stored Message ID in the SIM inserted in the UE (source and type) [see TS 23.041] according to the transmitted CB-Data 1 content.
Serial Number	[see TS 23.041]
- Geographic Scope Indicator (2 bit)	11 (Normal Cell wide)
- Message Code (10 bit)	in accordance with the Message ID
- Update Number (4 bit)	for a new message: 0000, incremented by one for each repetition
Data Coding Scheme	Bitstring (16) ID of the alphabet/coding and the applied language [see TS 23.041]
CB Data	Bitstring (N*8), [see IXIT value: CB-Data 1]

## 7.4.1.3.5 Test requirements

The UE shall store and decode a received activated CBS message.

## 7.4.2 BMC message reception procedure

## 7.4.2.1 Reception of certain CBS message types

## 7.4.2.1.1 Definition and applicability

Applicable only for a UE supporting Cell Broadcast Services (CBS) as type of Broadcast/Multicast Services.

It shall be possible to indicate the reception of two different CBS message contents carried with different activated CB message types in a clear way on the UE side.

It shall be possible to activate/deactivate the CBS message types used to receive CB Data 1 or 2.

## 7.4.2.1.2 Conformance requirement

A UE supporting Cell Broadcast Service (CBS) shall be capable to receive BMC messages in RRC Idle mode.

The BMC entity on the UE side evaluates received BMC Schedule Messages and takes decisions which BMC messages are received.

If not otherwise requested by upper layers, only those CB messages received in BMC CBS Messages are delivered to upper layers for which the Serial Number associated with the CB message has changed. This implies that the BMC shall store the last received Serial Number of each CB message activated by upper layers.

## Reference(s)

TS 25.324 subclause 9.1

TS 25.324 subclause 9.4

## 7.4.2.1.3 Test purpose

1. To verify, that a UE supporting CBS ignores a deactivated CBS message type which has been broadcasted by SS.
2. To verify, that a UE only stores Serial Numbers of a newly transmitted CBS messages. This shall be verified by indication of a received CBS message with changed Serial Number as indication for the storage of Serial Numbers.

#### 7.4.2.1.4 Method of test

##### Initial conditions

UE is in RRC Idle mode,

SS: 1 cell,

NOTE: The CB message ID stored on the SIM shall be known for this test (as parameter for the CBS message PDU). The CBS data type shall be allocated and in the UE. It shall be possible to activate/deactivate such CBS data type.

##### Related ICS/IXIT Statement(s)

ICS: CBS message support - YES/No

IXIT: - CBS-Data 1: Bitstring of  $N \times 8$  (where  $N \geq 1$  and less than 1246), with used CB message ID for CB-Data 1

- CBS-Data 2: Bitstring of  $N \times 8$  (where  $N \geq 1$  and less than 1246), with used CB message ID for CB-Data 2 (CB message ID for CB-Data 1 shall be different to CB message ID for CB-Data 2)

NOTE: For CBS data IXIT's, the manufacturer shall define CBS data as Bitstring as described in the IXIT, which is indicated by the UE after reception in a clear way according to the capabilities stored on the SIM. The manufacturer shall describe the indication on the UE side for both CBS data types (e.g. certain CBS broadcast information shown in the display of the UE)

##### Test procedure

- a) The UE in RRC Idle mode is triggered to wait for the next system information. The UE is activated to receive expected CBS messages (CBS data 1 and CBS data 2) as described by the manufacturer,
- b) The UE and the SS have configured their RLC, MAC and PHYs layers with all CB related system information, broadcasted by SS
- c) The SS sends the CBS message containing CBS data (CB-Data 1) as described by the manufacturer to the UE, this shall be repeated for "CPREP" times (as indicated by the parameter "repetition period" in the schedule information)
- d) The UE indicates on an unambiguous way, that this CBS data message (CB-Data 1) has been received by the UE (e.g. a unique part of the CBS data contents shown in the display)
- e) The SS sends a CBS Schedule message (inband schedule message) containing CB schedule parameter for the following CBS data message (CB-Data 2 as described by the manufacturer)
- f) The SS sends the new CBS message containing CBS data (CB-Data 2) as described by the manufacturer to the UE, this shall be repeated for "CPREP" times (as indicated by the parameter "repetition period" in the schedule information))
- g) The UE indicates on an unambiguous way, that this CBS data message (CB-Data 2) has been received by the UE (e.g. a unique part of the CBS data contents shown in the display)
- h) The UE deactivates the CB Message type ID used for CB-Data 1,
- i) The SS sends a CBS Schedule message (inband schedule message) containing schedule parameter for the next CBS data (CB-Data 1)
- j) The SS sends the CBS message containing CBS data (CB-Data 1) as described by the manufacturer to the UE, this shall be repeated for "CPREP" times (as indicated by the parameter "repetition period" in the schedule information)
- k) The UE ignores the newly received CBS data message (CB-Data 1), i.e. there is no indication as described in step d)

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	←		SYSTEM INFORMATION	Transmit these messages as described below on the BCCH, in addition to the regular BCCH transmissions. Included are all CB related system information parameter of the CBS: - CTCH ID, - FACH ID and associated format set, - S-CCPCH ID, - CBS DRX Level 1 information (optional) - Period of CTCH allocation on S-CCPCH (optional) - CBS frame offset (optional)
2				The SS waits for about 10 s to make sure, that the UE is configured to receive the CBS Data message
3			BMC CBS Message	Activated CBS message with certain CB data content (CBS data 1 as described by the manufacturer). This message shall be repeated "CPREP" times, Parameter: - Message_ID, - Serial-No, - Data coding scheme, - CB-Data 1
4				After having received the BMC CBS message (CB-Data 1) the UE shall indicate the reception in a clear way.
5	←		BMC CBS Schedule	Inband CBS schedule message with schedule parameter for the next CBS data message (CB-Data 2).
6	←		BMC CBS Message	Activated CBS message with certain CBS data content (CB-Data 2 as described by the manufacturer). This message shall be repeated "CPREP" times, Parameter: - Message_ID, - Serial-No, - Data coding scheme, - CB-Data 2
7				After having received the BMC CBS message (CBS data 2) the UE shall indicate the reception in a clear way. This implies that the changed Serial Number of the CBS message has been stored on the UE.
8				The UE deactivates "CB message type ID" used for CB-Data 1
9	←		BMC CBS Schedule	Inband CBS schedule message with schedule parameter for the next CB data message (CB-Data 1)
10	←		BMC CBS Message	CBS message with certain CBS data content (CB-Data 1 as described by the manufacturer). This message shall be repeated "CPREP" times, Parameter: - Message_ID, - Serial-No, - Data coding scheme, - CB-Data 1

11		After having received the BMC CBS message (CB-Data 1) the UE shall ignore the newly received CBS data 1 message, i.e. there is no indication as described by the manufacturer.
----	--	--

### Specific Message Contents

#### SYSTEM INFORMATION TYPE 6

The contents of SYSTEM INFORMATION TYPE 6 Information Element in this test case are identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] with the following exceptions:

Information Element	Value/remark
CHOICE mode	(see RRC default test settings)
PRACH system information	(see RRC default test settings)
Secondary CCPCH system	
- Secondary CCPCH information	1
- TFCS	(see RRC default test settings)
- FACH/PCH information	1
- TFS	(see RRC default test settings)
- CTCH indicator	TRUE
- PICH info	(see RRC default test settings)

#### BMC CBS Message (Step 3)

Information Element	Value/remark
Message Type	1 (CBS message)
Message ID	Bitstring (16) CB message ID, it shall fit to the stored Message ID in the SIM inserted in the UE (source and type) [see TS 23.041]
Serial Number	[see TS 23.041]
- Geographic Scope Indicator (2 bit)	11 (Normal Cell wide)
- Message Code (10 bit)	according with the Message ID
- Update Number (4 bit)	for a new message: 0000, incremented by one for each repetition
Data Coding Scheme	Bitstring (16) ID of the alphabet/coding and the applied language [see TS 23.041]
CB Data	Bitstring (N*8), [see IXIT value: CB-Data 1]

#### BMC CBS Message (Step 6)

Information Element	Value/remark
Message Type	1 (CBS message)
Message ID	Bitstring (16) CB message ID, it shall fit to the stored Message ID in the SIM inserted in the UE (source and type) [see TS 23.041]
Serial Number	[see TS 23.041]
- Geographic Scope Indicator (2 bit)	11 (Normal Cell wide)
- Message Code (10 bit)	according with the Message ID
- Update Number (4 bit)	for a new message: 0000, incremented by one for each repetition
Data Coding Scheme	Bitstring (16) ID of the alphabet/coding and the applied language [see TS 23.041]
CB Data	Bitstring (N*8), [see IXIT value: CB-Data 2]

## BMC CBS Message (Step 10)

Information Element Message Type	Value/remark 1 (CBS message)
Message ID	Bitstring (16) CB message ID, it shall fit to the stored Message ID in the SIM inserted in the UE (source and type) [see TS 23.041]
Serial Number - Geographic Scope Indicator (2 bit) - Message Code (10 bit) - Update Number (4 bit)	[see TS 23.041] 11 (Normal Cell wide) according with the Message ID for a new message: 0000, incremented by one for each repetition
Data Coding Scheme	Bitstring (16) ID of the alphabet/coding and the applied language [see TS 23.041]
CB Data	Bitstring (N*8), [see IXIT value: CB-Data 1]

## BMC Schedule Message (Step 5 and Step 9)

The parameters for BMC Schedule Message (inband schedule message) in Step 5 are inserted for CB-Data 2 and in Step 8 for CB-Data 1.

Information Element Message Type	Value/remark 2 (Schedule message)
Offset to begin CTCH BS index	calculated offset value of the BS (Integer: 0...255) as recommended in TR 25.925
Length of CBS Schedule Period	Number of consecutive CTCH BS of the next CBS Schedule Period, (Integer: 1...255) as recommended in TR 25.925
New Message Bitmap	Bitmap (N*8), N = Length of CBS Schedule Period as recommended in TR 25.925
Message Description - Message Description Type	1 for new message (see TS 25.324, Table 11.9-3) 5 for old message (see TS 25.324, Table 11.9-3)
- Message ID	CB message ID used for the next CB data
- Offset to CTCH (BS index of first transmission)	for Message description type 1 or 5: CB message ID IE included (see TS 23.041)

## 7.4.2.1.5 Test requirements

After having received the CB-Data 1 message (step 3), the UE shall store the Serial Number of this message and indicate the reception of the CBS message as described by the manufacturer.

After having received the CB-Data 2 message (step 6), the UE shall store the Serial Number of this message and indicate the reception of the CBS message as described by the manufacturer.

After CB-Data 1 message was broadcasted and repeated "CREP" times (step 9), the UE shall not indicate the reception for the deactivated CBS message (CB-Data 1).

---

## 8. Radio Resource Control RRC

### 8.1 RRC Connection Management Procedure

#### 8.1.1 Paging

##### 8.1.1.1 Paging for Connection in idle mode

###### 8.1.1.1.1 Definition

###### 8.1.1.1.2 Conformance requirement

In idle mode, UE monitors the paging occasions determined using parameters from SYSTEM INFORMATION BLOCK messages. When the UE receives a PAGING TYPE 1 message transmitted on PCCH during one of its assigned paging occasions, it should attempt to establish an RRC connection.

###### Reference

3GPP TS 25.331 clause 8.1.2, 3GPP TS 25.211 clause 5.3.3.7, 3GPP TS 25.304 clause 8.

###### 8.1.1.1.3 Test purpose

To confirm that the UE establishes an RRC connection after it receives a PAGING TYPE1 message which includes IE "Paging Record"(UE identity ) set to the IMSI of the UE.

###### 8.1.1.1.4 Method of test

###### Initial Condition

System Simulator : 1 cell

UE :Idle state with a CN UE identity (set to IMSI).

###### Test Procedure

The SS transmits a PAGING TYPE1 message, which includes an unmatched CN UE identity for the UE in the idle state. The UE shall not change its state. The SS transmits a PAGING TYPE1 message, which includes a matched CN UE identity for the UE in the idle state. During transmission of PAGING TYPE 1 messages, SS selects the correct paging indicator on the PICH in order to allow the UE to respond to paging. Then the UE transmits an RRC CONNECTION REQUEST to the SS, the SS transmits an RRC CONNECTION SETUP to the UE. When the UE receives this message, the UE establishes an RRC connection.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	SYSTEM INFORMATION BLOCK TYPE 13	Transmit these messages on the BCCH, in addition to the normal BCCH transmissions. See specific message contents.
2		←	PAGING TYPE1	The SS transmits the message, which includes an unmatched identity (incorrect IMSI), then the UE does not change its state.
3		←	PAGING TYPE1	The SS transmits the message, which includes a matched identity (test-SIM IMSI).
4		→	RRC CONNECTION REQUEST	
5		←	RRC CONNECTION SETUP	SS assigns DPCH resources to allow UE to establish an RRC connection.

## Specific Message Contents

## SYSTEM INFORMATION TYPE13

Information Element	Value/remark
CN domain system information list	Only 1 entry
CN domain system information	
- CN domain identity	Supported Domain ( PS Domain or CS Domain )
- CHOICE CN Type	Supported CN type
- CN domain specific NAS system information	Default
- CN domain specific DRX cycle length coefficient	6
UE Timers and constants in idle mode	
- T300	5 sec.
- N300	3
- T312	10 sec
- N312	200

## PAGING TYPE 1 (Step 2)

Information Element	Value/remark
Paging record list	Only 1 entry
Paging record	
CHOICE Paging originator	CN originator
- Paging cause	Terminating Call with one of the supported services ( Conversational Call, Streaming Call, Interactive Call, Background Call, SMS )
	Supported Domain ( PS Domain or CS Domain )
- CN domain identity	IMSI
- CHOICE UE Identity	Set to an arbitrary octet string of length 7 bytes which is different from the IMSI value stored in the USIM card.
- IMSI	

## PAGING TYPE 1 (Step 3)

Information Element	Value/remark
Paging record list	Only 1 entry
Paging record	
CHOICE Paging originator	CN originator
- Paging cause	Terminating Call with one of the supported services ( Conversational Call, Streaming Call, Interactive Call, Background Call, SMS )
	Supported Domain ( PS Domain or CS Domain )
- CN domain identity	IMSI
- CHOICE UE Identity	Set to the same octet string as in the IMSI stored in the USIM card
- IMSI	

## RRC CONNECTION REQUEST (Step 4)



Information Element	Value/remark
Initial UE identity	Same as the IMSI stored in the USIM card, or the registered TMSI or P-TMSI
Establishment Cause	Check to see if it is set to the same value as "Paging Cause" IE in the PAGING TYPE 1 message transmitted on step 3.
Protocol Error Indicator	Check to see if it is set to FALSE
Measured results on RACH	Not checked.

#### 8.1.1.1.5 Test requirement

After step 2 the UE shall not transmit on the uplink CCCH in order to establish a RRC connection.

After step 5 the UE shall have an RRC connection based on dedicated physical channel resources.

### 8.1.1.2 Paging for Connection in connected mode (CELL\_PCH)

#### 8.1.1.2.1 Definition

#### 8.1.1.2.2 Conformance requirement

In CELL\_PCH state, a UE can respond to a paging request from UTRAN. In this case, the UTRAN has requested to establish a connection with the UE. The UE should then attempt to perform a cell update procedure and move to CELL\_FACH state in order to respond to the paging using uplink CCCH.

#### Reference

3GPP TS 25.331 clause 8.1.2

#### 8.1.1.2.3 Test purpose

To confirm that the UE enters the CELL\_FACH state after it receives a PAGING TYPE1 message which indicates that the paging has originated from UTRAN. To verify that the UE performs cell update procedure after entering the CELL\_FACH state.

#### 8.1.1.2.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE :CELL\_PCH state with a valid U-RNTI already assigned by the SS

#### Test Procedure

The SS transmits a PAGING TYPE1 message, which includes an unmatched U-RNTI in CELL\_PCH state. The UE does not change its state. Then SS transmits a PAGING TYPE 1 message with a matched identifier but originates from the CN instead of UTRAN. The UE should not change state after receiving this message. The SS transmits a PAGING TYPE1 message, which includes a matched U-RNTI in the connected state. Then the UE enters the CELL\_FACH state and performs the cell updating procedure.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	SYSTEM INFORMATION BLOCK TYPE 13	Transmit these messages on the BCCH, in addition to the normal BCCH transmissions. See specific message contents
2		←	PAGING TYPE1	The SS transmits a message including an unmatched identifier. UE shall not respond to the paging.
3		←	PAGING TYPE1	The SS transmits a message includes a matched identifier but with the originator being the CN, UE shall not respond to the paging.
4		←	PAGING TYPE 1	The SS transmits the message with the UTRAN being the originator and including the UE's assigned U-RNTI
5		→	CELL UPDATE	The UE enters the CELL_FACH state. UE performs cell updating procedure. The CELL UPDATE message shall contain the value "Cell Update Cause" set to "paging response".

## Specific Message Contents

## PAGING TYPE 1 (Step 2)

Information Element	Value/remark
Paging record list	Only 1 entry
Paging record	
- CHOICE Paging originator	UTRAN originator
- U-RNTI	
- SRNC Identity	Set to an arbitrary 16-bit string which is different from the SRNC identity assigned.
- S-RNTI	Set to an arbitrary 20-bit string which is different from the S-RNTI assigned.

## PAGING TYPE 1 (Step 3)

Same as the PAGING TYPE 1 message as in Clause 8.1.1.1.4, with the exception that the "BCCH modification info" IE should be omitted in the message.

## PAGING TYPE 1 (Step 4)

Information Element	Value/remark
Paging record list	Only 1 entry
Paging record	
- CHOICE Paging originator	CN originator
- U-RNTI	
- SRNC Identity	Set to the same SRNC identity as previously assigned.
- S-RNTI	Set to the same S-RNTI as previously assigned.

## SYSTEM INFORMATION BLOCK TYPE 12

Same as the SYSTEM INFORMATION BLCOK TYPE 13 message used in Clause 8.1.1.1.3.

#### 8.1.1.2.5 Test requirement

After step 2 the UE shall not respond to the PAGING TYPE 1 message sent in step 2.

After step 3 the UE shall not respond to the PAGING TYPE 1 message sent in step 2.

After step 4 the UE shall enter the CELL\_FACH state and send a CELL\_UPDATE message with "Cell Update Cause" IE set to "paging response".

### 8.1.1.3 Paging for Connection in connected mode(URA\_PCH)

#### 8.1.1.3.1 Definition

#### 8.1.1.3.2 Conformance requirement

This procedure is used to transmit a PAGING TYPE 1 message from the network to selected UEs in URA\_PCH state using the paging control channel (PCCH). The UE listens to it and then enters the CELL\_FACH state.

#### Reference

3GPP TS 25.331 clause 8.1.2

#### 8.1.1.3.3 Test purpose

To confirm that the UE enters the CELL\_FACH state after it receives a PAGING TYPE1 message which includes IE "Paging Record"(U-RNTI) for the UE and which is set to "CN" in IE"paging originator".

#### 8.1.1.3.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE :URA\_PCH state with a valid U-RNTI assigned by the SS

#### Test Procedure

The SS transmits a PAGING TYPE1 message, which includes an unmatched U-RNTI in URA\_PCH state. The UE does not change its current state. The SS transmits a PAGING TYPE1 message which includes a matched U-RNTI in the connected state. Then the UE listens to it and enters the CELL\_FACH state.

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	PAGING TYPE1	The SS transmits the message that includes an unmatched identifier, then the UE does not change its state.
2		←	PAGING TYPE1	The SS transmits the message that includes a matched identifier.
3		→	CELL_UPDATE	The UE enters the CELL_FACH state.

## Specific Message Contents

## PAGING TYPE 1 (Step 1)

Information Element	Value/remark
Paging record list	Only 1 entry
Paging record	
- CHOICE Paging originator	UTRAN originator
- U-RNTI	
- SRNC Identity	Set to an unused SRNC identity which is different from the SRNC identity assigned.
- S-RNTI	Set to an arbitrary 20-bit string which is different from the S-RNTI assigned.

## PAGING TYPE 1 (Step 2)

Information Element	Value/remark
Paging record list	Only 1 entry
Paging record	
- CHOICE Paging originator	UTRAN originator
- U-RNTI	
- SRNC Identity	Set to the previously assigned SRNC identity
- S-RNTI	Set to previously assigned S-RNTI

## 8.1.1.3.5 Test requirement

After step 1 the UE shall not respond to the paging.

After step 2 the UE shall enter the CELL FACH state, and transmit CELL UPDATE message to initiate the cell updating procedure with the paging cause set to "paging response".

## 8.1.1.4 Paging for Notification in idle mode

## 8.1.1.4.1 Definition

## 8.1.1.4.2 Conformance requirement

When a system information block on the BCCH is modified, the PAGING TYPE 1 message can be sent on the PCCH to inform the UE about the changes, which are currently taking place in the idle mode. The PAGING TYPE 1 message includes the IE "BCCH Modification Information". Upon receiving this notification from the UTRAN, the UE shall read the relevant MIB and/or SIB(s) subsequently during idle mode.

## Reference

3GPP TS 25.331 clause 8.1.1.2

## 8.1.1.4.3 Test purpose

To confirm that the UE checks the new value tag of the master information block and reads the updated SYSTEM INFORMATION BLOCK messages after it receives a PAGING TYPE1 message which includes the IE "BCCH Modification Information".

## 8.1.1.4.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : Idle state with a CN UE identity .

### Test Procedure

The UE is in the idle state before it starts to change the SYSTEM INFORMATION BLOCK TYPE 1 or 13 messages, depending on the CN type supported by the UE. The SS transmits a PAGING TYPE1 message on the paging occasions assigned to the UE. The message shall include the IE "BCCH Modification Information" indicating the time when the first modified master information block is available. Before the starting time, SS continuously broadcast the original MASTER INFORMATION BLOCK and various types of SYSTEM INFORMATION BLOCK on the BCCH mapped to BCH transport channel. SS maintains this status until the SFN which corresponds to the starting time is reached. Then it transmits the new master information block followed by the new SYSTEM INFORMATION BLOCK TYPE 1 or 13 messages. In the new SIB TYPE 1 or 13 messages, the IE "DRX Cycle Length Coefficient" is altered when compared to the original SIB TYPE 1 or 13 messages. . At the next paging occasion, SS transmits a new PAGING TYPE 1 message. The message addresses the UE using its IMSI and the "paging cause" IE set to a terminating call type that is supported by the UE. The UE shall react to the PAGING TYPE 1 message and then send a RRC CONNECTION REQUEST message to SS.

Notes: For UEs supporting GSM-MAP CN type only, SYSTEM INFORMATION TYPE 1 messages are to be sent by SS in this test case. On the other hand, SS transmits SYSTEM INFORMATION TYPE 13 messages if the UE under test supports only ANSI-41 CN type

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	MASTER INFORMATION BLOCK  SYSTEM INFORMATION BLOCK TYPE 1 or SYSTEM INFORMATION BLOCK TYPE 13	SS transmits information on BCCH in order for UE to listen to one of the S-CCPCH physical channel, which carries PAGING TYPE 1 or 13 messages on PCCH. Relevant paging parameters are also broadcasted.
2		←	PAGING TYPE 1	SS transmits the message includes the IE "BCCH Modification Information", with the "Value Tag" changed from the "MIB Value Tag" of the current Master Information Block. Also the modification time is set to 4088 radio frame from the current SFN. SS continuously broadcast the same MASTER INFORMATION BLOCK and various types of SYSTEM INFORMATION BLOCK on BCCH for a period stretching 4087 frames.
3		←  ←	MASTER INFORMATION BLOCK  SYSTEM INFORMATION BLOCK TYPE 1 or SYSTEM INFORMATION BLOCK TYPE 13	SS starts to transmit the MIB with the "MIB Value Tag" IE different from the original setting.  At the same time, SS starts to transmit the affected SIB TYPE 1 or TYPE 13 messages continuously. The value of IE "DRx Cycle Length Coefficient" is changed in this message.  SS starts to monitor the uplink RACH after approximately 4087 frames from step 2.
4		←	PAGING TYPE 1	SS starts to transmit this message continuously on the PCCH according to the new value of "DRx Cycle Length Coefficient", at the next paging occasion immediately following step 3.
5		→	RRC CONNECTION REQUEST	UE transmits a request due to answer to the PAGING TYPE 1 received in step 4. The IE "Establishment Cause" should be set to "Terminating Call" supported by the UE and the "Initial UE Identity" set to UE's IMSI.
6		←	RRC CONNECTION REJECT	UE shall return to idle mode after receiving this message

## Specific Message Contents

## SYSTEM INFORMATION BLOCK TYPE 1 (Step 1) – for UEs supporting GSM-MAP core networks

Information Element	Value/remark
References to other system information blocks	Not Present
CN common GSM-MAP NAS system information	Location Area Information (LAI)
CN domain system information list	Supports both CS and PS domains
- CN domain system information	
- CN domain identity	CS domain
- CHOICE CN Type	GSM-MAP
- CN domain specific NAS system information	Set to the same octet string as in IE"CN common GSM MAP-NAS system information"
	12
- CN domain specific DRX cycle length coefficient	
- CN domain system information	
- CN domain identity	PS domain
- CHOICE CN Type	GSM-MAP
- CN domain specific NAS system information	Set to the same octet string as in IE"CN common GSM MAP-NAS system information"
	12
- CN domain specific DRX cycle length coefficient	
UE Timers and constants in idle mode	
- T300	Default
- N300	Default
- T312	Default
- N312	Default
UE Timers and constants in connected mode	Not Present

## SYSTEM INFORMATION BLOCK TYPE 13 (Step 1) – for UEs supporting ANSI-41 core networks

Information Element	Value/remark
References to other system information blocks	Not Present
CN domain system information list	Supports both CS and PS domains
CN domain system information	
- CN domain identity	CS
- CHOICE CN Type	ANSI-41
- CN domain specific NAS system information	
- ANSI-41 NAS System Information	
- ANSI-41 NAS Parameter	Set to an ANSI-41 user zone information
- CN domain specific DRX cycle length coefficient	12
- CN domain identity	PS
- CHOICE CN Type	ANSI-41
- CN domain specific NAS system information	
- ANSI-41 NAS System Information	
- ANSI-41 NAS Parameter	Set to an ANSI-41 user zone information
- CN domain specific DRX cycle length coefficient	12
UE Capability update requirement	Not Present

## PAGING TYPE 1 (Step 2)

Information Element	Value/remark
Paging record list	Only 1 entry
Paging record	
- CHOICE Paging originator	UTRAN originator
- U-RNTI	
- SRNC Identity	Arbitrarily selecte a SRNC identity which is different from current identity
- S-RNTI Identity	Arbitrarily selecte a S-RNTI identity which is different from current identity
BCCH modification info	
MIB Value Tag	2
BCCH Modification time	4088

## MASTER INFORMATION BLOCK (Step 3)

Information Element	Value/remark
MIB Value tag	2

## SYSTEM INFORMATION BLOCK TYPE 1 (Step 3) – for UEs supporting GSM-MAP core networks

Information Element	Value/remark
References to other system information blocks	Not Present
CN common GSM-MAP NAS system information	Location Area Information (LAI)
CN domain system information list	Supports both CS and PS domains
- CN domain system information	
- CN domain identity	CS domain
- CHOICE CN Type	GSM-MAP
- CN domain specific NAS system information	Set to the same octet string as in IE"CN common GSM MAP-NAS system information"
- CN domain specific DRX cycle length coefficient	6
- CN domain system information	
- CN domain identity	PS domain
- CHOICE CN Type	GSM-MAP
- CN domain specific NAS system information	Set to the same octet string as in IE"CN common GSM MAP-NAS system information"
- CN domain specific DRX cycle length coefficient	6
UE Timers and constants in idle mode	
- T300	Default
- N300	Default
- T312	Default
- N312	Default
UE Timers and constants in connected mode	Not Present



## SYSTEM INFORMATION BLOCK TYPE 13 (Step 3) – for UEs supporting ANSI-41 core networks

Information Element	Value/remark
References to other system information blocks	Not Present
CN domain system information list	Supports both CS and PS domains
CN domain system information	
- CN domain identity	CS domain
- CHOICE CN Type	ANSI-41
- CN domain specific NAS system information	
- ANSI-41 NAS system information	
- ANSI-41 NAS Parameter	Set to an ANSI-41 user zone information
- CN domain specific DRX cycle length coefficient	6
- CN domain identity	PS domain
- CHOICE CN Type	ANSI-41
- CN domain specific NAS system information	
- ANSI-41 NAS system information	
- ANSI-41 NAS Parameter	Set to an ANSI-41 user zone information
- CN domain specific DRX cycle length coefficient	6

## PAGING TYPE 1 (Step 4)

Information Element	Value/remark
Paging record list	Only 1 entry
Paging record	
- CHOICE Paging originator	CN originator
- Paging Cause	Terminating Call with one of the supported service (Conversation Call, Streaming Call, Interactive Call, Background Call, SMS)
	CS Domain
- CN Domain Identity	IMSI
- CHOICE UE Identity	Set to the same octet string as in the IMSI value stored in the USIM card
- IMSI	

## RRC CONNECTION REJECT (Step 6)

Information Element	Value/remark
Initial UE identity	
- CHOICE UE id type	IMSI
- IMSI	Set to the same octet string as in the IMSI value stored in the USIM card
Rejection cause	Unspecified
Wait time	0
Redirection info	Not Present

## 8.1.1.4.5 Test requirement

After step 5 the UE shall transmit RRC CONNECTION REQUEST message in response to the PAGING TYPE 1 messages sent starting from step 4.

## 8.1.1.5 Paging for Notification in connected mode (CELL\_PCH)

## 8.1.1.5.1 Definition

## 8.1.1.5.2 Conformance requirement

When a system information block on the BCCH is modified, the message PAGING TYPE1 can be sent on the PCCH to inform the UE about this change in the CELL\_PCH state. This message includes the IE"BCCH Modification

Information". Upon receiving this notification from the UTRAN, the UE shall read the relevant MIB and/or SIB(s) subsequently while in CELL\_PCH state.

#### Reference

3GPP TS 25.331 clause 8.1.1.2

#### 8.1.1.5.3 Test purpose

To confirm that the UE enters the CELL\_FACH state, checks the new value tag of the master information block, and read the SYSTEM INFORMATION messages after it receives a PAGING TYPE1 message which includes the IE "BCCH Modification Information"

#### 8.1.1.5.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_PCH state with valid a U-RNTI assigned to it.

#### Test Procedure

Identical test steps 1 to 5 in Clause 8.1.1.4 are applied to this test. However, the PAGING TYPE 1 messages used in step 2 and step 4 are altered. The changes are indicated in the specific message content paragraph under this clause. At step 6, UE shall send the CELL UPDATE message indicating the "cell update cause" to be "paging response". SS then replies with a CELL UPDATE CONFIRM message to allow the UE to transit to CELL\_FACH state.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	MASTER INFORMATION BLOCK  SYSTEM INFORMATION BLOCK TYPE 1 or SYSTEM INFORMATION BLOCK TYPE 13	SS transmits information on BCCH in order for UE to listen to one of the S-CCPCH physical channel, which carries PAGING TYPE 1 or 13 messages on PCCH. Relevant paging parameters are also broadcasted.
2		←	PAGING TYPE 1	SS transmits the paging message which comprises IE "BCCH Modification Information", with the "Value Tag" changed from the "MIB Value Tag" of the current Master Information Block. Also the modification time is set to 4088 radio frame from the current SFN. SS continuously broadcast the same MASTER INFORMATION BLOCK and various types of SYSTEM INFORMATION BLOCK on BCCH for a period stretching 4087 frames.
3		←  ←	MASTER INFORMATION BLOCK  SYSTEM INFORMATION BLOCK TYPE 1 or SYSTEM INFORMATION BLOCK TYPE 13	SS starts to transmit the MIB with the "MIB Value Tag" IE different from the original setting.  At the same time, SS starts to transmit the affected SIB TYPE 1 or TYPE 13 messages continuously. The value of IE "DRx Cycle Length Coefficient" is changed in this message.  SS starts to monitor the uplink RACH after approximately 4087 SFN from step 2.
4		←	PAGING TYPE 1	SS transmits this message continuously on the PCCH according to the new value of "DRx Cycle Length Coefficient", at the next paging occasion immediately following step 3. This message shall page the UE with its U-RNTI and setting the UTRAN as the paging originator.
5		→	CELL UPDATE	The IE "Cell Update Cause" should be set to "Paging Response" and the IE "U-RNTI" shall be similar to the UE's U-RNTI value. The "Protocol Error Indicator" IE shall be set to FALSE.
6		←	CELL UPDATE CONFIRM	UE shall transit to CELL_FACH state after receiving this message.

## Specific Message Contents

## SYSTEM INFORMATION BLOCK TYPE 1 or TYPE 13 (Step 1)

The content of this message is the same in the message used in step 1 specified in Clause 8.1.1.4.3.

## PAGING TYPE 1 (Step 2)

Information Element	Value/remark
Paging record list	Only 1 entry
Paging record	
- CHOICE Paging originator	UTRAN originator
- U-RNTI	
- SRNC Identity	Set to a different string from currently allocated SRNC identity
- S-RNTI	Set to an arbitrary 20-bits string
BCCH modification info	
- MIB Value Tag	2
- BCCH Modification time	4088

## MASTER INFORMATION BLOCK (Step 3) and

## SYSTEM INFORMATION BLOCK TYPE 1 or TYPE 13 (Step 3)

The content of these messages is the same in the message used in step 3 specified in Clause 8.1.1.4.4.

## PAGING TYPE 1 (Step 4)

Information Element	Value/remark
Paging record list	Only 1 entry
Paging record	
- CHOICE Paging originator	UTRAN originator
- U-RNTI	Equal to the U-RNTI assigned earlier.
- SRNC Identity	Same as the current SRNC allocated
- S-RNTI	Same as the current S-RNTI allocated
BCCH modification info	Not Present

## CELL UPDATE CONFIRM (Step 6 )

Information Element	Value/remark
DRX Indicator	DRx with Cell Updating

## 8.1.1.5.5 Test requirement

After step 5 the UE shall transmit a CELL UPDATE message with “cell update cause” IE set to “paging response”. Upon receiving CELL UPDATE CONFIRM message, the UE shall enter the CELL\_FACH state.

## 8.1.1.6 Paging for Notification in connected mode (URA\_PCH)

## 8.1.1.6.1 Definition

## 8.1.1.6.2 Conformance requirement

When a system information block on the BCCH is modified, the UTRAN can send a PAGING TYPE 1 message on the PCCH to inform UE about the changes while the UE is in the URA\_PCH state. This message includes the IE “BCCH Modification Information”. When receiving this message in URA\_PCH state, the UE shall read the relevant MIB and/or SIB(s).

## Reference

3GPP TS 25.331 clause 8.1.1.2

### 8.1.1.6.3 Test purpose

To confirm that the UE enters the CELL\_FACH state, checks the included new value tag of the master information block and reads the relevant SYSTEM INFORMATION block(s) after it receives a PAGING TYPE 1 message which includes the IE "BCCH Modification Information".

### 8.1.1.6.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : URA\_PCH state with a valid U-RNTI assigned.

#### Test Procedure

The UE is in the URA\_PCH state before the SS starts changing SYSTEM INFORMATION BLOCK messages. SS modifies its SYSTEM INFORMATION and updates the "value tag" of both the SYSTEM INFORMATION BLOCK TYPE 1 and of the MASTER INFORMATION BLOCK. After a while, the SS transmits a PAGING TYPE 1 message, which includes the IE "BCCH Modification Information". The UE enters the CELL\_FACH state and reads the modified SYSTEM INFORMATION BLOCK. The UE shall act according to the modified message. In this testcase, the UE shall adjust its paging occasions and read the new PCCH blocks newly assigned to it under DRX mode.

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	MASTER INFORMATION BLOCK SYSTEM INFORMATION	The SS changes the SYSTEM INFORMATION when the UE is in the connected state (URA_PCH).
2		←	PAGING TYPE 1	SS transmits the message includes the IE "BCCH Modification Information".
3				The UE enters the CELL_FACH state and reads the SYSTEM INFORMATION and then the UE follows this message.

#### Specific Message Contents

None

### 8.1.1.6.5 Test requirement

After step 2 the UE shall enter the CELL\_FACH state and read the SYSTEM INFORMATION message and follow it.

## 8.1.1.7 Paging for Connection in connected mode (CELL\_DCH)

### 8.1.1.7.1 Definition

### 8.1.1.7.2 Conformance requirement

This procedure is used to transmit a PAGING TYPE 2 message from the network to selected UEs in CELL\_DCH state using the dedicated control channel (DCCH). The UE listens to it and responds to this message accordingly.

#### Reference

3GPP TS 25.331 clause 8.1.9

## 8.1.1.7.3 Test purpose

To confirm that the UE responds this message after it receives a PAGING TYPE2 message which includes IE "Paging Record Type Identifier" for the UE.

## 8.1.1.7.4 Method of test

## Initial Condition

System Simulator : 1 cell.

UE : CELL\_DCH state, but neither a valid TMSI nor P-TMSI is assigned to the UE

## Test Procedure

The SS transmits a PAGING TYPE 2 message which includes a unmatched Paging Record Type Identifier in CELL\_DCH state. The UE shall not respond to this message. SS pages the UE again, this time with a matched Paging Record Type Identifier but with the IE "paging cause" set to one of the spare values. UE shall respond by transmitting a RRC STATUS message on the DCCH using RLC-AM mode. Finally, SS transmits a PAGING TYPE 2 message, which includes a matched Paging Record Type Identifier. Then the UE shall responds to this message by the transmission of an upper layer message.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	PAGING TYPE 2	The SS transmits the message includes an unmatched identifier, then the UE does not respond.
2		←	PAGING TYPE 2	The SS transmits the message includes a matched identifier. In the paging message, IE "paging cause" is set to one of the spare values.
3		→	RRC STATUS	The UE shall respond by reporting the protocol error to the SS.
4		←	PAGING TYPE 2	SS pages the UE with a matched identifier and with a valid "paging cause" IE.
5		→	UPLINK DIRECT TRANSFER	The UE shall respond to the paging message sent in step 4.

## Specific Message Contents

## PAGING TYPE 2 (Step 1)

Information Element	Value/remark
Paging cause	Terminating Call supported by the UE
CN domain identity	Domain supported by the UE
Paging Record Type Identifier	Set to "TMSI" or "P-TMSI"

## PAGING TYPE 2 (Step 2)

Information Element	Value/remark
Paging cause CN domain identity Paging Record Type Identifier	Use one of the spare values Domain supported by the UE Set to "IMSI (GSM-MAP)" for UEs supporting GSM-MAP core network type or "IMSI (DS-41)" for UEs supporting ANSI-41 core network type.

## RRC STATUS (Step 3)

Information Element	Value/remark
Protocol error information	Checked to see if set to "Information element value not comprehended"

## PAGING TYPE 2 (Step 4)

Information Element	Values/Remarks
Paging cause CN domain identity Paging Record Type Identifier	Terminating Call supported by the UE Domain supported by the UE Set to "IMSI (GSM-MAP)" for UEs supporting GSM-MAP core network type or "IMSI (DS-41)" for UEs supporting ANSI-41 core network type.

## UPLINK DIRECT TRANSFER (Step 5)

Only the message type IE for this message is checked.

## 8.1.1.7.5 Test requirement

After step 1 the UE shall not respond to the paging message on the DCCH.

After step 2 the UE shall respond to the paging message by transmitting RRC STATUS on the DCCH, stating the protocol error as "Information element value not comprehended".

After step 4 the UE shall respond to the paging message by transmitting a UPLINK DIRECT TRANSFER message on the uplink DCCH.

## 8.1.1.8 Paging for Connection in connected mode (CELL\_FACH)

## 8.1.1.8.1 Definition

## 8.1.1.8.2 Conformance requirement

This procedure is used to transmit a PAGING TYPE 2 message from the network to selected UEs in CELL\_FACH state using the dedicated control channel (DCCH). The UE shall listen to it and responds to this message accordingly.

## Reference

3GPP TS 25.331 clause 8.1.9

## 8.1.1.8.3 Test purpose

To confirm that the UE responds to a PAGING TYPE 2 message, which includes a matching value for IE "Paging Record Type Identifier".

#### 8.1.1.8.4 Method of test

##### Initial Condition

System Simulator : 1 cell

UE :CELL\_FACH state.

##### Test Procedure

The SS transmits a PAGING TYPE 2 message, which includes an unmatched Paging Record Type Identifier in CELL\_FACH state. The UE shall not respond to this message. The SS transmits a PAGING TYPE2 message, which includes a matched Paging Record Type Identifier. Then the UE shall respond by transmitting an upper layer message to answer this page.

##### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	PAGING TYPE2	The SS transmits the message includes a unmatched identifier, then the UE does not respond.
2		←	PAGING TYPE2	The SS transmits the message includes a matched identifier.
3				The UE responds by sending an upper layer message.

##### Specific Message Content

##### PAGING TYPE 2 (Step 1)

Use the same message content as in step 1 from 8.1.1.7.4

##### PAGING TYPE 2 (Step 2)

Use the same message content as in step 4 from 8.1.1.7.4

#### 8.1.1.8.5 Test requirement

After step 1 the UE shall not respond.

After step 2 the UE shall respond.

## 8.1.2 RRC Connection Establishment

### 8.1.2.1 RRC Connection Establishment in CELL\_DCH state: Success

#### 8.1.2.1.1 Definition

#### 8.1.2.1.2 Conformance requirement

1. The RRC connection establishment is initiated by the UE, which leaves the idle mode and transmits an RRC CONNECTION REQUEST message. This message shall include the IE"Initial UE identity" and is to be transmitted on the uplink CCCH.
2. After the UE receives an RRC CONNECTION SETUP message which includes the same value of the IE" Initial UE identity" ,radio resource parameters(i.e. Signalling link type and multiplexing info) and U-RNTI The UE then configures the layer 2 and layer 1 processing so as to support the DCCH according to the radio resource



parameters specified. The procedure successfully ends when the network receives an RRC CONNECTION SETUP COMPLETE message on the uplink DCCH.

## Reference

3GPP TS 25.331 clause 8.1.3

### 8.1.2.1.3 Test purpose

To confirm that the UE leaves the Idle Mode and correctly establishes a signalling link on the DCCH.

### 8.1.2.1.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE: Idle state

## Test Procedure

The UE transmits an RRC CONNECTION REQUEST message to the SS on the uplink CCCH by attempting to make an outgoing call . After SS receives this message, it assigns the necessary radio resources and U-RNTI to be used by the UE and then transmits an RRC CONNECTION SETUP message to the UE within timer T300. SS then waits for the UE to transmit an RRC CONNECTION SETUP COMPLETE message on the DCCH.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1	→		RRC CONNECTION REQUEST	By outgoing call operation
2		←	RRC CONNECTION SETUP	This message is not addressed to the UE.
3	→		RRC CONNECTION REQUEST	UE shall re-transmit the request message again after receiving a setup message not addressed to itself.
4		←	RRC CONNECTION SETUP	
5				The UE configures the layer 2 and layer 1 .
6	→		RRC CONNECTION SETUP COMPLETE	

## Specific Message Content

### RRC CONNECTION SETUP (Step 2):

Information Element	Value/remark
Initial UE Identity CHOICE UE id type IMSI	IMSI Set to an arbitrary octet string of length 7 which different from the IMSI value stored in the USIM card.

### 8.1.2.1.5 Test requirement

After step 2 the UE shall re-transmit the RRC CONNECTION REQUEST message again in order to continue the RRC connection establishment procedure.

After step6 the UE shall establish an RRC connection and continue the procedure of the outgoing call on the DCCH.

## 8.1.2.2 RRC Connection Establishment: Success after T300 timeout

### 8.1.2.2.1 Definition

### 8.1.2.2.2 Conformance requirement

1. The RRC connection establishment is initiated by the UE, which leaves the idle mode. The UE shall transmit an RRC CONNECTION REQUEST message which includes the IE "Initial UE identity". This message shall be sent on the uplink CCCH.
2. In the case of a failure to establish the RRC connection at the expiry of timer T300, the UE retries to establish the RRC connection until V300 is greater than N300.
3. When the UE receives a RRC CONNECTION SETUP message, which contains a protocol error and causing the internal variable `PROTOCOL_ERROR_REJECT` set to TRUE, it shall perform the appropriate error handling procedure.

### Reference

3GPP TS 25.331 clause 8.1.3

### 8.1.2.2.3 Test purpose

To confirm that the UE retries to establish the RRC connection until V300 is greater than N300 after the expiry of timer T300 when the SS transmits no response for an RRC CONNECTION REQUEST message.

### 8.1.2.2.4 Method of test

### Initial Condition

System Simulator : 1 cell

UE: Idle state

### Test Procedure

Before the test starts, an internal counter K in SS is initialized to a value = 1. Following this, the UE shall transmit an RRC CONNECTION REQUEST message to the SS on the uplink CCCH, after the operator attempts to make an outgoing call. SS ignores this message, increments K every time such a message is received and waits for T300 timer to expire. This cycle is repeated until K reaches N300. When K is equal to N300, the SS transmits the RRC CONNECTION SETUP message specified in step 5 to the UE and wait until T300 expires. The UE shall send another RRC CONNECTION REQUEST message on the uplink CCCH. SS verifies that the UE does not access the radio resource allocated in step 5. After confirming this restriction is observed, SS replies with a valid RRC CONNECTION SETUP message. The UE shall then acknowledge the establishment of RRC connection by sending the RRC CONNECTION SETUP COMPLETE message on uplink DCCH.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				SS initializes counter K to 1 . Operator is asked to make an outgoing call and SS starts to wait for RRC CONNECTION REQUEST on uplink CCCH.
2		→	RRC CONNECTION REQUEST	
3				SS checks to see if K is equal to N300. If so, goes to step 5. Else, continues to execute step 4.
4				SS increments K. The next step is step 2.
5		←	RRC CONNECTION SETUP	The message contains a protocol error, see specific message content. SS waits for T300 to expire again.
6		→	RRC CONNECTION REQUEST	UE shall not access the radio resource indicated in RRC CONNECTION SETUP message sent in step 5.
7		←	RRC CONNECTION SETUP	This is a legal message. See the clause 6.1 in TS 34.108 on default message content for RRC.
8				The UE configures the layer 2.
9		→	RRC CONNECTION SETUP COMPLETE	

## Specific Message Contents

## RRC CONNECTION SETUP (Step5)

Information Element	Value/remark
<b>Uplink Radio Resource</b> <i>CHOICE channel requirement</i>	Neither PRACH Info (for RACH) nor Uplink DPCH info is chosen. One of the spare value is used.

## 8.1.2.2.5 Test requirement

After step 5 the UE shall re-send another RRC CONNECTION REQUEST message and not access any radio resources specified in RRC CONNECTION SETUP message sent in step 5.

After step 8 the UE shall transmit an RRC CONNECTION SETUP COMPLETE message and establish an RRC connection on the DCCH logical channel.

## 8.1.2.3 RRC Connection Establishment: Failure (V300 is greater than N300)

## 8.1.2.3.1 Definition

## 8.1.2.3.2 Conformance requirement

1. The RRC connection establishment is initiated by the UE, which leaves the idle mode and transmits an RRC CONNECTION REQUEST message. This message shall include the IE "Initial UE identity" on the uplink CCCH.

2. In the case of a failure to establish the RRC connection after (N300+1) attempts, the UE goes back to idle mode.

## Reference

3GPP TS 25.331 clause 8.1.3

### 8.1.2.3.3 Test purpose

To confirm that the UE stops retrying to establish the RRC connection if V300 is greater than N300 and goes back to idle mode.

### 8.1.2.3.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE: Idle state

## Test Procedure

Before the test starts, SS initializes an internal counter K to 1. The UE transmits an RRC CONNECTION REQUEST message to the SS on the uplink CCCH by an outgoing call operation. SS shall not respond to any RRC CONNECTION REQUEST message, instead the counter K is increased by 1 every time such a message is received. To arrive at the verdict, the SS checks that a total of (N300+1) such messages are received.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				SS initializes counter K to 1 and then prompts the operator to make an outgoing call.
2	→		RRC CONNECTION REQUEST	
3				SS increments K by 1.
4				If K is greater than N300, goes to step 5 else proceed to step 2.
5				SS monitor the uplink CCCH for a time period enough for UE to go back to normal service. The exact amount of time to wait shall be derived from TS related to cell selection. If any uplink transmission is detected, the test fails.

## Specific Message Contents

None

### 8.1.2.3.5 Test requirement

After step 5, counter K shall be equal to (N300+1) and there shall be no uplink transmission in the monitoring period specified in step 5.

## 8.1.2.4 RRC Connection Establishment: Reject ("wait time" is not equal to 0)

### 8.1.2.4.1 Definition

#### 8.1.2.4.2 Conformance requirement

1. The RRC connection establishment is initiated by the UE, which leaves the idle mode and transmits an RRC CONNECTION REQUEST message. This message shall include the IE "Initial UE identity" and is to be sent on the uplink CCCH.
2. After the UE receives an RRC CONNECTION REJECT message which includes IE "wait time" not set to 0, and neither IE "frequency info" nor IE "system info" is present, the UE shall wait for a period specified in the IE "wait time". Thereafter re-transmit an RRC CONNECTION REQUEST message to attempt to establish the RRC connection again. However, either IE "frequency info" or IE "system info" is available in the message, the UE shall attempt to perform cell reselection using these information.

### Reference

3GPP TS 25.331 clause 8.1.3

#### 8.1.2.4.3 Test purpose

To confirm that the UE retries to establish the RRC connection after the "wait time" if the UE receives an RRC CONNECTION REJECT message which includes the IE "wait time" not set to 0.

To confirm that the UE perform a cell reselection when receiving an RRC CONNECTION REJECT message, containing relevant frequency information of the target cell to be re-selected.

#### 8.1.2.4.4 Method of test

### Initial Condition

System Simulator : 2 cells – both cell 1 and cell 2 are active and suitable for camping, but cell 1 is transmitted using a larger power. Cell 1 and cell 2 are being transmitted from different 2 UARFCNs.

UE: Idle state

### Test Procedure

The UE transmits an RRC CONNECTION REQUEST message to the SS on the uplink CCCH by an outgoing call operation in cell 1. SS rejects the first request by transmitting an RRC CONNECTION REJECT message which indicates a non-zero wait time. In this message, frequency information for cell 2 is available. SS then waits for RRC CONNECTION REQUEST message on the uplink CCCH of cell 2. SS will also monitor the uplink of cell 1 simultaneously to ensure that all transmission activities from cell 1 have ceased. When the UE has successfully camp onto cell 2, it shall send an RRC CONNECTION REQUEST with the same establishment cause as its previous attempt in cell 1. SS responds with an RRC CONNECTION REJECT message, indicating a non-zero "wait time" and omitting the IE "Redirection Info". The UE shall observe the wait time period indicated. After the wait time has elapsed, the UE shall re-transmit RRC CONNECTION REQUEST again. Finally, SS transmits an RRC CONNECTION SETUP message to establish an RRC connection with the UE, and the UE replies with an RRC CONNECTION SETUP COMPLETE message and enters CELL\_DCH state.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		→	RRC CONNECTION REQUEST	SS prompts the operator to make an outgoing call in cell 1.
2		←	RRC CONNECTION REJECT	This message shall includes the IE"wait time" set to 15 seconds and IE"frequency info" set to the UARFCN of cell 2.
3				SS waits for a period of time sufficient for UE to reselect to cell 2. At the same time, it monitor the uplink of cell 1 to make sure that all transmissions have ceased.
4		→	RRC CONNECTION REQUEST	UE shall attempt to re-start an RRC connection establishment procedure in cell 2. The establishment cause shall remained unchanged.
5		←	RRC CONNECTION REJECT	This message shall includes the IE"wait time" set to 15 seconds, but with IE"Redirection Info" absent.
6		→	RRC CONNECTION REQUEST	SS waits until the duration specified in IE"wait time" has elapsed and then listens to the uplink CCCH for a second RRC CONNECTION REQUEST message.
7		←	RRC CONNECTION SETUP	SS sends the message to UE, to setup an RRC connection with the UE.
8				The UE shall configure the layer 2 and layer 1 in order to access the uplink and downlink DCCH assigned..
9		→	RRC CONNECTION SETUP COMPLETE	

## Specific Message Contents

## RRC CONNECTION REQUEST (Step1)

Information Element	Value/remark
Initial UE Identity	Must be equal to U-RNTI assigned preeviously
Initial UE Capability	Must be compatible with UE settings in TS25.926
Establishment Cause	Must be "Originating Call"

## RRC CONNECTION REJECT (Step2)

Information Element	Value/remark
Wait time	15 seconds
Redirection Info	
Frequency Info	
UARFCN uplink (Nu)	Set to a different UARFCN from uplink carrier of cell 1
UARFCN uplink (Nd)	Not present – assuming a duplex distance of 190MHz.

## RRC CONNECTION REQUEST (Step4 and step6)

Same requirement as in step 1.

## RRC CONNECTION REJECT (Step5)

Information Element	Value/remark
Wait time	15 seconds
Redirection Info	Not present

## 8.1.2.4.5 Test requirement

After step 3 the UE shall have successfully re-selected to cell 2, using information transmitted in IE "frequency info" of RRC CONNECTION REJECT message. UE shall trigger the start of RRC connection establishment by transmitting RRC CONNECTION REQUEST. The establishment cause shall be similar to the message sent in step 1.

After step 5 the UE shall observe the period specified in IE "wait time" of an RRC CONNECTION REJECT message and not transmit an RRC CONNECTION REQUEST message in this period.

After step 7 the UE shall transmit an RRC CONNECTION SETUP COMPLETE message to SS on uplink DCCH and then establish an RRC connection.

## 8.1.2.5 RRC Connection Establishment: Reject ("wait time" is not equal to 0 and V300 is greater than N300)

## 8.1.2.5.1 Definition

## 8.1.2.5.2 Conformance requirement

1. The RRC connection establishment is initiated by the UE, which leaves the idle mode and transmits an RRC CONNECTION REQUEST message. This message shall include the IE "Initial UE identity" and is to be sent on the uplink CCCH.
2. After the UE receives an RRC CONNECTION REJECT message which includes IE "wait time" not set to 0, and neither IE "frequency info" nor IE "system info" is present, the UE shall wait for a period specified in the IE "wait time". Thereafter it re-transmits an RRC CONNECTION REQUEST message to attempt to establish the RRC connection again. In the case of a failure to establish the RRC connection after (N300+1) attempts, the UE goes back to idle mode.

## Reference

3GPP TS 25.331 clause 8.1.3

## 8.1.2.5.3 Test purpose

To confirm that the UE retries to establish the RRC connection after the "wait time" if the UE receives an RRC CONNECTION REJECT message which specifies a non-zero IE "wait time".

To confirm that the UE stops retrying to establish the RRC connection if V300 is greater than N300 and goes back to idle mode.

## 8.1.2.5.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE: Idle state

## Test Procedure

Before the test starts, SS initializes an internal counter K to 0. The UE transmits an RRC CONNECTION REQUEST message to the SS on the uplink CCCH, triggered by an outgoing data call operation. SS rejects all requests by

transmitting an RRC CONNECTION REJECT message which indicates a non-zero wait time and the counter K is increased by 1 every time such a message is received. To arrive at the verdict, the SS checks that a total of (N300+1) such messages are received.

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				SS initializes counter K to 0 and then prompts the operator to make an outgoing data call.
2		→	RRC CONNECTION REQUEST	Shall be sent on CCCH and contain the correct establishment cause.
3		←	RRC CONNECTION REJECT	This message includes the IE "wait time" set to 15 seconds.
4				SS increments K by 1.
5				If K is greater than N300, goes to step 6. Else SS waits for 15 sec before proceeding to step 2.
6				SS monitor the uplink CCCH for a time period enough for UE to go back to normal service. The exact amount of time to wait shall be derived from TS related to cell selection. If any uplink transmission is detected, the test fails.

#### Specific Message Contents

##### RRC CONNECTION REQUEST (Step2)

Information Element	Value/remark
Initial UE Identity	Must be equal to U-RNTI assigned previously
Initial UE Capability	Must be compatible with UE settings in TR25.926
Establishment Cause	Must be "Originating CS Data Call" or "Originating PS Data Call"

##### RRC CONNECTION REJECT (Step3)

Information Element	Value/remark
Wait time	15 seconds

#### 8.1.2.5.5 Test requirement

After step 6, counter K shall be equal to (N300+1) and there shall be no uplink transmission in the monitoring period specified in step 6.

#### 8.1.2.6 RRC Connection Establishment: Reject ("wait time" is set to 0)

##### 8.1.2.6.1 Definition

##### 8.1.2.6.2 Conformance requirement

1. The RRC connection establishment is initiated by the UE, which leaves the idle mode and transmits an RRC CONNECTION REQUEST message on the uplink CCCH.



2. In the case of a failure to establish the RRC connection by the reception of a RRC CONNECTION REJECT message which contains IE"wait time" equals to 0 , the UE shall go back to idle mode immediately.

## Reference

3GPP TS 25.331 clause 8.1.3

### 8.1.2.6.3 Test purpose

To confirm that the UE goes back to idle mode, if the SS transmits an RRC CONNECTION REJECT message which includes IE"wait time" set to 0. To confirm that the UE ignores an RRC CONNECT REJECT message not addressed to it. To confirm that the UE is capable of handling an erroneous RRC CONNECTION REJECT message correctly.

### 8.1.2.6.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : Idle state

## Test Procedure

The UE transmits an RRC CONNECTION REQUEST message to the SS on the uplink CCCH by making an outgoing call . After the SS receives this message, it transmits an RRC CONNECTION REJECT message which is not addressed to the UE. The UE shall disregard this message and proceed to re-transmit RRC CONNECTION REQUEST message upon T300 timer expiry. SS answers the second RRC CONNECTION REQUEST message by transmitting an RRC CONNECTION REJECT message with IE"wait time" set to 15 seconds, but without the mandatory IE"rejection cause". The UE shall continue to send the third RRC CONNECTION REQUEST message after a 15 second lapse. Next, the SS sends a legal RRC CONNECTION REJECT message which is expected to cause the UE to move to idle mode spontaneously. To confirm that finally the UE goes back to idle mode immediately after receiving the reject message, SS shall monitor the uplink CCCH for the next 60 second and verify that there is no further transmission in the uplink direction.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		→	RRC CONNECTION REQUEST	Test operator is prompted to make an out-going call,
2		←	RRC CONNECTION REJECT	IE"Initial UE identity" contains an identity different from any of the UE identities available.
3		→	RRC CONNECTION REQUEST	UE shall continue to send this message after T300 time-out.
4		←	RRC CONNECTION REJECT	IE"Reject Cause" is omitted, IE"wait time" is set to 15 seconds (maximum).
5		→	RRC CONNECTION REQUEST	UE shall continue to send this message after T300 time-out, but before the expiry of "wait time" IE indicated in RRC CONNECTION REJECT in step 4.
6		←	RRC CONNECTION REJECT	IE"wait time" is set to 0.
7				The UE goes back to idle mode..

## Specific Message Contents

## RRC CONNECTION REJECT (Step2)

Information Element	Value/remark
Initial UE Identity IMSI	Set to an arbitrary octet string of length 7 bytes, which is different from the IMSI stored in USIM.
Wait time	15 seconds
Redirection Info	Not present

## RRC CONNECTION REJECT (Step4)

Information Element	Value/remark
Initial UE Identity IMSI	Set to the identical octet string as the IMSI stored in the USIM card.
Reject Cause	Not Present
Wait time	15 seconds (Maximum)
Redirection Info	Not Present

## RRC CONNECTION REJECT (Step6)

Information Element	Value/remark
Initial UE Identity IMSI	Set to the identical octet string as the IMSI stored in the USIM card.
Reject Cause	Congestion
Wait time	0 second
Redirection Info	Not present

Note: T300 is set to 5 seconds and N300 is arbitrarily selected from 4 to 8 in SYSTEM INFORMATION BLOCK TYPE 1 message on BCCH.

## 8.1.2.6.5 Test requirement

After step 2 and step 4 the UE shall continue to re-transmit an RRC CONNECTION REQUEST message on uplink CCCH, at an interval of 5 seconds (T300).

After step6 the UE shall stop sending an RRC CONNECTION REQUEST message, go back to idle mode immediately and not transmit in the uplink direction again.

## 8.1.2.7 RRC Connection Establishment in CELL\_FACH state: Success

## 8.1.2.7.1 Definition

## 8.1.2.7.2 Conformance requirement

During the RRC connection establishment, the UTRAN might assign common physical resource to the UE using an RRC CONNECTION SETUP message. When no information about the physical channels accessible are available from the message, the UE shall utilize the PRACH and S-CCPCH information transmitted on the BCCH and then enter the CELL\_FACH. Subsequently, the UE shall establish the required signalling links with the UTRAN using common physical resources.

## Reference

3GPP TS25.331 clause 8.1.3

## 8.1.2.7.3 Test Purpose

To confirm that the UE is able to enter CELL\_FACH state and setup signalling links using common physical channels.

## 8.1.2.7.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE: Idle state

## Test Procedure

The UE transmits an RRC CONNECTION REQUEST message to the SS on the uplink CCCH by attempting to make an outgoing call. After the SS receives this message, it assigns the necessary radio resources and U-RNTI to be used by the UE, and then transmits an RRC CONNECTION SETUP message to the UE within timer T300. SS then waits for the UE to transmit an RRC CONNECTION SETUP COMPLETE message on the DCCH.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		→	RRC CONNECTION REQUEST	Test operator is requested to make an outgoing call. The UE shall transmit this message, indicating the correct establishment cause.
2		←	RRC CONNECTION SETUP	SS omits both IE"Uplink DPCH Info" and IE"Downlink DPCH Info" from the message.
3				The UE shall configure the layer 2 and layer 1.
4		→	RRC CONNECTION SETUP COMPLETE	UE shall send this message on the DCCH, carried by the assigned PRACH resources.

## Specific Message Content

## RRC CONNECTION REQUEST

Information Element	Value/remark
Establishment Cause	Originating PS Data Call

## RRC CONNECTION SETUP

For this message, the contents of the message to be used are basically identical to the message sub-type entitled "RRC CONNECTION SETUP message (Transition to CELL\_FACH)" found in the default message content part. The following exceptions are applicable in this test:

Information Element	Value/remark
Uplink DPCH Info	Not Present
Downlink information common for all radio links	Not Present
Downlink information per radio link list	Not Present

## RRC CONNECTION SETUP COMPLETE

Information Element	Value/remark
UE Radio Access Capability	Checked to see if compatible with the stated capability in PIXIT/PICS statements.

## 8.1.2.7.5 Test requirements

After step 3 the UE shall establish the RRC connection, and transmit RRC CONNECTION SETUP COMPLETE message on the DCCH using PRACH physical resource specified in system information block messages.

## 8.1.2.8 RRC Connection Establishment : Invalid system information message reception

## 8.1.2.8.1 Definition

## 8.1.2.8.2 Conformance requirement

The UE shall ignore the message and shall not select the cell, if the associated a SYSTEM INFORMATION message on the BCCH which includes the unknown value in the mandatory information element which criticality is set to “reject” in the master information block is broadcasting.

## Reference

3GPP TS 25.331 clause 8.1.1 clause 16

## 8.1.2.8.3 Test purpose

To confirm that the UE does not select the cell if the transmitted SYSTEM INFORMATION message on the BCCH which includes the unknown value in the mandatory information element whose criticality is set to “reject” value in the master information block is broadcasting

## 8.1.2.8.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : Power off

## Test Procedure

The SS broadcasts the SYSEM INFORMATION message on the BCCH which includes the PLMN Type information element having “spare value” in the master information block. When the UE is supplied the power, it finds that the SYSTEM INFORMATION message on the BCCH includes the unknown value in the mandatory information element and the UE shall ignore this message. When an outgoing call is attempted, the test operator shall be informed that the UE is in a “No Service” state. The UE shall not transmit an RRC CONNECTION REQUEST message on the uplink CCCH.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	SYSTEM INFORMATION	The SS broadcasts the SYSTEM INFORMATION message on the BCCH which includes an unknown value in the mandatory information element whose criticality is set to "reject" in the master information block.
2				The UE is supplied the power.
3				SS waits for 1 minute and then asks the test operator to attempt to make an outgoing call.
4				SS checks that no uplink transmission on CCCH is detected.

### Specific Message Contents

#### SYSTEM INFORMATION (master information block)

The contents of a SYSTEM INFORMATION message in this test case is identical to the corresponding message found in the default contents of layer 3 messages for RRC tests, with the following exceptions:

Information Element	Value/remark
PLMN Type	spare value

#### 8.1.2.8.5 Test requirement

After step3 the UE shall not transmit an RRC CONNECTION REQUEST message on the uplink CCCH.

## 8.1.3 RRC Connection Release

### 8.1.3.1 RRC Connection Release in CELL\_DCH state: Success

#### 8.1.3.1.1 Definition

#### 8.1.3.1.2 Conformance requirement

In case of an RRC connection release from CELL\_DCH state, the UTRAN transmits an RRC CONNECTION RELEASE message to the UE using unacknowledged mode on the DCCH. The UE then responds by transmitting an RRC CONNECTION RELEASE COMPLETE message using unacknowledged mode to UTRAN for N308 times, each time at the expiry of T308 timer. Then the UE leaves the RRC connected mode and initiates release of the layer2 signalling link. The RRC Connection Release procedure ends when all UE dedicated resources (such as radio resources and radio access bearers) associated with the RRC connection are released and the UE returns to idle mode.

### Reference

3GPP TS 25.331 clause 8.1.4

### 8.1.3.1.3 Test purpose

To confirm that the UE releases the L2 signalling link and dedicated resources and goes back to the idle state after it receives an RRC CONNECTION RELEASE message from the SS and transmits an RRC CONNECTION RELEASE COMPLETE message to the SS for N308 times at the interval specified by the value of T308 timer.

### 8.1.3.1.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH state

#### Test Procedure

The UE is brought to the CELL\_DCH state by prompting the operator to initiate an outgoing call. After the DCCH is established, SS transmits an RRC CONNECTION RELEASE message to the UE to disconnect the connection. SS then waits for the UE to transmit an RRC CONNECTION RELEASE COMPLETE message using unacknowledged mode. SS checks to see if P such messages has been received at each expiry of T308 timer. P is equal to the value of IE"Number of RRC Message Transmissions" in an RRC CONNECTION RELEASE message.

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is in the CELL_DCH state after a successful RRC connection establishment by virtue of the operator making an outgoing call.
2		←	RRC CONNECTION RELEASE	SS disconnect the connection established. The value in IE"Number of RRC Message Transmissions" is arbitrarily chosen from 4 to 8 and denoted by P.
3		→	RRC CONNECTION RELEASE COMPLETE	SS waits for the arrival of N308 such message at the expiry of each T308 timer, using unacknowledged mode.
4				The UE releases L2 signalling link and dedicated resources then the UE goes to idle mode.

#### Specific Message Content

##### RRC CONNECTION RELEASE (Step2)

Information Element	Value/remark
Number of RRC Message Transmission	Arbitrarily chosen between 4 and 8

### 8.1.3.1.5 Test requirement

After step2 the UE shall start to transmit P times RRC CONNECTION RELEASE COMPLETE messages at the expiry of each T308 timer.

After step3 the UE shall initiate the release L2 signalling link and dedicated resources, then it shall go to idle mode.

### 8.1.3.2 RRC Connection Release in CELL\_FACH state: Success

#### 8.1.3.2.1 Definition

#### 8.1.3.2.2 Conformance requirement

In case of RRC connection release from CELL\_FACH state, the RRC layer entity in the network may issues an RRC CONNECTION RELEASE message using unacknowledged mode on the DCCH. Upon the reception of this message, the UE-RRC transmits an RRC RELEASE COMPLETE message using acknowledged mode to UTRAN on the DCCH and goes back to idle mode after it receives a response from the UTRAN-RLC. If an invalid RRC CONNECTION RELEASE is received, the UE shall perform the appropriate error-handling mechanism and report the error to the UTRAN.

#### Reference

3GPP TS 25.331 clause 8.1.4

#### 8.1.3.2.3 Test purpose

To confirm that the UE releases the L2 signalling link and resources and goes back to the idle state after it receives an RRC CONNECTION RELEASE message from the SS. It shall transmit an RRC CONNECTION RELEASE COMPLETE message using acknowledged mode to the SS (e.g. the UE-RLC confirms the transmission of the RRC CONNECTION RELEASE COMPLETE message.). If the UE receives an invalid release message, it shall ignore the message and report this event to the SS.

#### 8.1.3.2.4 Method of test

##### Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH state

##### Test Procedure

The UE is brought to an initial state of CELL\_FACH. After the successful establishment of the RRC connection, the SS transmits an RRC CONNECTION RELEASE message to the UE to disconnect the radio link. However, the message contains an error in one of the mandatory IE. As a result, the UE shall not release the RRC connection and reply with RRC STATUS message indicating the error type. Then the SS transmits a second RRC CONNECTION RELEASE message with valid content. When the UE receives this message the UE transmits an RRC CONNECTION RELEASE COMPLETE message using acknowledged mode to the SS. Finally, SS checks that the UE performs proper layer 2 release.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is brought to the CELL_FACH state.
2		←	RRC CONNECTION RELEASE	The message contains an error in one of the conditional IE.
3		→	RRC STATUS	IE"Protocol Error Information" shall be set to "Message Extension Not Comprehended"
4		←	RRC CONNECTION RELEASE	SS sends this message using unacknowledged mode RLC operations on the uplink DCCH.
5		→	RRC CONNECTION RELEASE COMPLETE	The UE transmits this message using acknowledged mode.
6				The UE releases L2 signaling link and radio resources then the UE goes to idle mode.

## Specific Message Contents

## RRC CONNECTION RELEASE (Step 2)

Information Element	Value/remark
Number of RRC Message Transmissions	Arbitrarily selected from 1 to 8

## RRC STATUS

Information Element	Value/remark
Protocol Error Information	Checked to see if set to "Message Extension Not Comprehended"

## RRC CONNECTION RELEASE (Step 4)

Information Element	Value/remark
Number of RRC Message Transmissions	Not Present

## 8.1.3.2.5 Test requirement

After step 2 the UE shall maintain the RRC connection and respond to the RRC CONNECTION RELEASE message by sending RRC STATUS message. This message shall specify the cause "Message Extension Not Comprehended" in the IE"Protocol Error Information".

After step4 the UE shall transmit an RRC CONNECTION RELEASE COMPLETE messages using acknowledged mode then it shall receive a response for this message from the SS-RLC.

After step5 the UE shall release its L2 signalling link and radio resources, then it shall go back to idle mode.



### 8.1.3.3 RRC Connection Release in CELL\_FACH state: Failure

#### 8.1.3.3.1 Definition

#### 8.1.3.3.2 Conformance requirement

In case of RRC connection release from CELL\_FACH state, the RRC layer entity in the network issues an RRC CONNECTION RELEASE message using unacknowledged mode on the DCCH. When the UE does not succeed to transmit the RRC CONNECTION RELEASE COMPLETE message using acknowledged mode, it shall release all its radio resources, enter idle mode and the procedure ends on the UE side.

#### Reference

3GPP TS 25.331 clause 8.1.4

#### 8.1.3.3.3 Test purpose

To confirm that the UE releases all its radio resources and enters idle mode when the UE does not succeed in transmitting the RRC CONNECTION RELEASE COMPLETE message using acknowledged mode to the SS.(i.e. the UE-RLC cannot receive acknowledgement for the transmission of the RRC CONNECTION RELEASE COMPLETE message from SS.).

#### 8.1.3.3.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH state

#### Test Procedure

At the start of the test, the UE is brought to CELL\_FACH state. When the RRC connection has been established, the SS transmits an RRC CONNECTION RELEASE message to the UE to disconnect the radio link. When the UE receives this message the UE transmits an RRC CONNECTION RELEASE COMPLETE message using acknowledged mode to the SS. The SS ignores the message and does not transmit a STATUS PDU of RLC for this message. SS checks to see that UE continues to release all its radio resources and then enters idle mode.

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is brought into CELL_FACH state by asking the operator to perform an outgoing call attempt. Clause
2		←	RRC CONNECTION RELEASE	SS ask to disconnect the radio link
3		→	RRC CONNECTION RELEASE COMPLETE	The UE transmits this message using acknowledged mode. The SS ignores this message and shall not transmit a STATUS PDU of RLC for this message.
4				SS checks to make sure that UE releases its all radio resources and enter idle mode.

## Specific Message Contents

None

### 8.1.3.3.5 Test requirement

After step3 the UE shall release its L2 signalling link and radio resources then it shall go to idle mode.

## 8.1.4 RRC Connection Re-Establishment

### 8.1.4.1 RRC Connection Re-Establishment: Success

#### 8.1.4.1.1 Definition

#### 8.1.4.1.2 Conformance requirement

RRC connection re-establishment is needed, when a UE loses the radio connection due to e.g. radio link failure in CELL\_DCH state. After a successful cell re-selection and transiting to CELL\_FACH state, the UE transmits an RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE "U-RNTI" on the uplink CCCH to request for the re-establishment of an RRC connection. The UTRAN transmits an RRC CONNECTION RE-ESTABLISHMENT message on the downlink DCCH, which includes the new configuration information. Then the UE transmits an RRC CONNECTION RE-ESTABLISHMENT COMPLETE message on the uplink DCCH using AM RLC.

#### Reference

3GPP TS 25.331 clause 8.1.5

#### 8.1.4.1.3 Test purpose

To confirm that the UE tries to find a new cell by transiting to CELL\_FACH state, after detecting that a radio link failure has occurred. The UE shall then attempt to establish a new RRC connection using an RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE "U-RNTI". Finally when the SS allocates a new configuration to the UE using RRC CONNECTION RE-ESTABLISHMENT message, the UE shall establish a new RRC connection link.

#### 8.1.4.1.4 Method of test

#### Initial Condition

System Simulator : 2 cells • Cell 1 is active, Cell 2 is inactive •

UE: CELL\_DCH state in cell 1

#### Test Procedure

The UE is brought to CELL\_DCH state in a cell 1 after a successful outgoing call attempt. After the call has been established, the SS stops transmitting and receiving in a cell No.1 and begins to broadcast the BCCH in cell 2, the UE should detect a radio link failure in cell 1 and attempts to re-select to cell 2. It should then enter CELL\_FACH state and transmits an RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE "U-RNTI" on the uplink CCCH to SS. The SS transmits an RRC CONNECTION RE-ESTABLISHMENT message which includes a new configuration information. After the UE receives an RRC CONNECTION RE-ESTABLISHMENT message, it reconfigures the new radio connection and transmits an RRC CONNECTION RE-ESTABLISHMENT COMPLETE message on the uplink DCCH using AM RLC.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is brought to CELL_DCH state in a cell 1, after making a successful outgoing call.
2		←	BCCH	The SS starts transmitting the BCCH in a cell 2 using the same contents (except for cell identity which is set to "0000 0000 0000 0010") for system information sent on cell 1. SS starts to listen to the uplink CCCH of cell 2.
3				The SS stops transmitting and receiving in a cell .1.
4		→	RRC CONNECTION RE-ESTABLISHMENT REQUEST	The UE should find a new cell 2 and then transmits this message which includes the IE"U-RNTI" assigned previously.
5		←	RRC CONNECTION RE-ESTABLISHMENT	Including the new configuration information.
6		→	RRC CONNECTION RE-ESTABLISHMENT COMPLETE	

Specific Message Contents

Cell 1: SYSTEM INFORMATION TYPE 2

Information Element	Value/remark
UE Timers and constants in connected mode	
T301	8 seconds
T313	15 seconds
T314	20 seconds
T315	30 seconds
N313	50

#### 8.1.4.1.5 Test requirement

After step3, the UE shall detect the presence of cell 2 and attempts to re-established the lost RRC connection by transmitting RRC CONNECTION RE-ESTABLISHMENT REQUEST in the new cell.

After step5, the UE shall re-establish an RRC connection and observe the new configuration information specified in an RRC CONNECTION RE-ESTABLISHMENT message.

#### 8.1.4.2 RRC Connection Re-Establishment: Success after T301 timeout ( T314 and T315 are running)

##### 8.1.4.2.1 Definition

##### 8.1.4.2.2 Conformance requirement

1. RRC connection re-establishment is needed when a UE loses the radio connection due to e.g. radio link failure in CELL\_DCH state. After a cell re-selection to a new cell, the UE transits to CELL\_FACH state. In this state, the UE transmits an RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE"U-RNTI" on the uplink CCCH to request the re-establishment of an RRC connection.

2. In the case of a failure to re-establish the RRC connection after the expiry of timer T301, the UE retries to re-establish the RRC connection. Finally when the UTRAN allocates a new configuration to the UE using RRC CONNECTION ESTABLISHMENT message, the UE shall establish a new RRC connection link.

## Reference

3GPP TS 25.331 clause 8.1.5

### 8.1.4.2.3 Test purpose

To confirm that the UE retries to re-establish a new RRC connection after the expiry of timer T301. This occurs after the UE loses the radio connection and starts to transmit an RRC CONNECTION RE-ESTABLISHMENT REQUEST message.

### 8.1.4.2.4 Method of test

## Initial Condition

System Simulator : 2 cells • Cell 1 is active, Cell 2 is inactive •

UE: CELL\_DCH state in cell 1

## Test Procedure

The UE is in the CELL\_DCH state in cell 1, after making a successful outgoing call attempt. SS begins to broadcast the BCCH in cell 2 and then stops transmitting and receiving in cell 1. The UE shall detect a radio link failure and the presence of cell 2. It then enters CELL\_FACH state and transmits to SS an RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE "U-RNTI" on the uplink CCCH. The SS does not transmit an RRC CONNECTION RE-ESTABLISHMENT to answer to the request. This causes T301 timer to expire and the UE re-transmits an RRC CONNECTION RE-ESTABLISHMENT REQUEST message again. Then the SS transmits an RRC CONNECTION RE-ESTABLISHMENT message and the UE reconfigures the new radio connection and transmits an RRC CONNECTION RE-ESTABLISHMENT COMPLETE message on the uplink DCCH using AM RLC.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				SS prompts the operator to make an outgoing call. The UE is in the CELL_DCH state in cell 1.
2		←	BCCH	The SS starts to transmit BCCH in a cell 2, with the SYSTEM INFORMATION message similar (with the exception of cell identity IE) to that transmitted in cell 1.
3				The SS stops transmitting and receiving in cell 1.
4		→	RRC CONNECTION RE-ESTABLISHMENT REQUEST	The UE finds cell 2 and transmits this message which includes the IE"U-RNTI".
5				The SS does not transmit a response.
6		→	RRC CONNECTION RE-ESTABLISHMENT REQUEST	After the expiry of T301 the UE re-transmits this message.
7		←	RRC CONNECTION RE-ESTABLISHMENT	Including the new configuration information.
8		→	RRC CONNECTION RE-ESTABLISHMENT COMPLETE	

## Specific Message Contents

None

## 8.1.4.2.5 Test requirement

- After step3, the UE shall detect presence of cell 2 and starts to transmit an RRC CONNECTION RE-ESTABLISHMENT REQUEST message to setup the radio link again.

After step5, the UE shall re-transmit an RRC CONNECTION RE-ESTABLISHMENT REQUEST message on the uplink CCCH after the expiry of timer T301.

After step7 the UE shall re-establish an RRC connection in cell 2, using the new configuration commanded by the SS.

## 8.1.4.3 RRC Connection Re-Establishment: Success after reception of invalid message(V301 is not greater than N301)

## 8.1.4.3.1 Definition

## 8.1.4.3.2 Conformance requirement

1. RRC connection re-establishment is needed when a UE loses the radio connection due to e.g. radio link failure in CELL\_DCH state. After a cell re-selection to a new cell, the UE transits to CELL\_FACH state. In this state, the UE transmits an RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE"U-RNTI" on the uplink CCCH to request the re-establishment of an RRC connection.
2. In the case of a reception of an invalid RRC CONNECTION RE-ESTABLISHMENT message, the UE retries to re-establish the RRC connection until up to a maximum of N301 attempts after the expiry of timer T301.

## Reference

3GPP TS 25.331 clause 8.1.5

### 8.1.4.3.3 Test purpose

To confirm that the UE retries to re-establish a new RRC connection until its internal variable V301 is greater than N301 after the expiry of timer T301 when the UE receives an invalid RRC CONNECTION RE-ESTABLISHMENT message.

### 8.1.4.3.4 Method of test

#### Initial Condition

System Simulator : 2 cells • Cell 1 is active, Cell .2 is inactive •

UE: CELL\_DCH state in cell 1

#### Test Procedure

Before the test starts, a SS internal counter K is initialized to 1. The UE is in the CELL\_DCH state in cell 1, after making a successful outgoing call attempt. SS begins to broadcast the BCCH in cell 2 and then stops transmitting and receiving in cell 1. The UE shall detect a radio link failure and the presence of cell 2. It then enters CELL\_FACH state and transmits to SS an RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE "U-RNTI" on the uplink CCCH. The SS transmits an RRC CONNECTION RE-ESTABLISHMENT message to answer to the request which includes the "DRX Indicator" IE set to "spare value". After T301 timer expires, the UE re-transmits an RRC CONNECTION RE-ESTABLISHMENT REQUEST message again. When K is equal to N301-1 then the SS transmits an RRC CONNECTION RE-ESTABLISHMENT message and the UE reconfigures the new radio connection and transmits an RRC CONNECTION RE-ESTABLISHMENT COMPLETE message on the uplink DCCH using AM RLC.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				SS sets internal counter K to 1 and prompts the operator to make an outgoing call. The UE is in the CELL_DCH state in cell 1.
2		←	BCCH	The SS starts to transmit BCCH in a cell 2, with the SYSTEM INFORMATION message similar (with the exception of cell identity IE) to that transmitted in cell 1.
3				The SS stops transmitting and receiving in cell 1.
4		→	RRC CONNECTION RE-ESTABLISHMENT REQUEST	The UE finds cell 2 and transmits this message which includes the IE "U-RNTI".
5				If K is equal to N301-1 then next step is 7.
6		←	RRC CONNECTION RE-ESTABLISHMENT	The SS transmits a response which includes the "DRX indicator" IE set to "spare value" but increments K and moves to step 4 to wait for another uplink message.
7		←	RRC CONNECTION RE-ESTABLISHMENT	Including the new configuration information.
8		→	RRC CONNECTION RE-ESTABLISHMENT COMPLETE	

Specific Message Contents

None

#### 8.1.4.3.5 Test requirement

After step3, the UE shall detect presence of cell 2 and starts to transmit RRC CONNECTION RE-ESTABLISHMENT REQUEST message to setup the radio link again.

After step4, the UE shall re-transmit an RRC CONNECTION RE-ESTABLISHMENT REQUEST message on the uplink CCCH after the expiry of timer T301. The total number of RRC CONNECTION RE-ESTABLISHMENT messages received by SS shall be equal to N301-1 at an time interval equivalent to T301 timer value.

After step7 the UE shall re-establish an RRC connection in cell 2, using the new configuration commanded by the SS.

#### 8.1.4.4 RRC Connection Re-Establishment: Failure after reception of invalid message (V301 is greater than N301)

##### 8.1.4.4.1 Definition

##### 8.1.4.4.2 Conformance requirement

1. RRC connection re-establishment is needed when a UE loses the radio connection due to e.g. radio link failure in CELL\_DCH state. After cell re-selection and then transiting to CELL\_FACH state, the UE RRC transmits an

RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE "U-RNTI" on the uplink CCCH to request for re-establishment of an RRC connection.

2. In the case of a reception of an invalid RRC CONNECTION RE-ESTABLISHMENT message, if the UE retries to re-establish the RRC connection until up to a maximum of N301 attempts after the expiry of timer T301 and receives the invalid message, the UE goes back to idle mode.

#### Reference

3GPP TS 25.331 clause 8.1.5

#### 8.1.4.4.3 Test purpose

To confirm that the UE stops retrying to re-establish the RRC connection if its internal counter V301 is greater than N301 and then goes back to idle state.

#### 8.1.4.4.4 Method of test

#### Initial Condition

System Simulator : 2 cells • Cell 1 is active, Cell2 is inactive •

UE: CELL\_DCH state in cell 1

#### Test Procedure

The UE is in the CELL\_DCH state in a cell 1. SS begins to broadcast the BCCH in cell 2, and then stops transmitting and receiving in cell 1. The UE shall detect a radio link failure and the presence of cell 2. It then enters CELL\_FACH state and transmits to SS an RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE "U-RNTI" on the uplink CCCH. The SS transmits an RRC CONNECTION RE-ESTABLISHMENT message to answer to the request which includes the "DRX Indicator" IE set to "spare value", resulting in T301 timer to expire and the UE re-transmits an RRC CONNECTION RE-ESTABLISHMENT REQUEST message again. The SS keeps a count of the number of RRC CONNECTION RE-ESTABLISHMENT REQUEST messages received. The UE goes back to idle mode after N301 transmission attempts.



## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				SS set counter K to 1. The UE is in CELL_DCH state in a cell 1 after establishing an outgoing call.
2		←	BCCH	The SS starts to transmit BCCH in a cell 2.
3				The SS stops transmitting and receiving in a cell 1.
4		→	RRC CONNECTION RE-ESTABLISHMENT REQUEST	The UE finds new cell 2 and transmits this message which includes the IE "U-RNTI".
5		←	RRC CONNECTION RE-ESTABLISHMENT	The SS transmits a response which includes the "DRX indicator" IE set to "spare value" and increments K If K is greater than N301, then the next step is step 6 else go to step 4.
6				The UE goes back to idle mode.

## Specific Message Contents

None

## 8.1.4.4.5 Test requirement

- After step3 the UE shall find the presence of cell 2, enters CELL\_FACH state, and starts to transmit RRC CONNECTION RE-ESTABLISHMENT REQUEST message to setup the radio link again.
- After step5 the UE shall transmit an RRC CONNECTION RE-ESTABLISHMENT REQUEST message on the uplink CCCH after the expiry of timer T301 until V301 is greater than N301. If V301 is greater than N301 then the UE shall go back to idle mode.

## 8.1.4.5 RRC Connection Re-Establishment: Failure (Release)

## 8.1.4.5.1 Definition

## 8.1.4.5.2 Conformance requirement

RRC connection re-establishment is needed, when a UE loses the radio connection due to e.g. radio link failure in CELL\_DCH state. After the completion of cell re-selection and transiting to CELL\_FACH state, the UE transmits an RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE "U-RNTI" on the uplink CCCH to request for re-establishment of an RRC connection. The UTRAN transmits an RRC CONNECTION RELEASE message signifying that it is not able to accept the request, so the UE shall transmit an RRC CONNECTION RELEASE COMPLETE message to the UTRAN and goes back to idle mode.

## Reference

3GPP TS 25.331 clause 8.1.5

#### 8.1.4.5.3 Test purpose

To confirm that the UE transmits an RRC CONNECTION RELEASE COMPLETE message and goes back to idle mode after its request to re-establish an RRC connection was rejected by the SS in the new cell. The request to re-establish should be made with an RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE "U-RNTI".

#### 8.1.4.5.4 Method of test

##### Initial Condition

System Simulator : 2 cells Cell 1 is active, Cell 2 is inactive

UE: CELL\_DCH state in cell 1

##### Test Procedure

The UE starts from CELL\_DCH state in cell 1 after making a successful outgoing call. When the SS stops transmitting and receiving in cell 1 and begins to broadcast the BCCH in cell 2, the UE should detect radio link failure and the presence of cell 2. It then enters CELL\_FACH state and transmits an RRC CONNECTION RE-ESTABLISHMENT REQUEST message, which includes the IE "U-RNTI" on the uplink CCCH. The SS replies with a RRC CONNECTION RELEASE message on the downlink CCCH using transport mode operation. After the UE receives the RRC CONNECTION RELEASE message, it shall transmit an RRC CONNECTION RELEASE COMPLETE message on the uplink CCCH using RLC-TM. Finally, it goes back to idle mode.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is in the CELL_DCH state in cell 1 after completing a successful outgoing call setup.
2		←	BCCH	The SS transmits BCCH in cell 2
3				The SS stops transmitting and receiving in cell 1.
4		→	RRC CONNECTION RE-ESTABLISHMENT REQUEST	The UE finds new cell 2 and transmits this message which includes the IE "U-RNTI".
5		←	RRC CONNECTION RELEASE	SS rejects the re-establishment request. Sent on downlink CCCH using RLC-TM.
6		→	RRC CONNECTION RELEASE COMPLETE	This message shall be received on the uplink CCCH using RLC-TM. The UE goes back to idle mode after sending this message.

## Specific Message Contents

## RRC CONNECTION RELEASE: TM

Information Element	Value/remark
Message Type	
U-RNTI	Not Present
- SRNC Identity	Set to the same SRNC identity as previously assigned
- S-RNTI	Set to the same S-RNTI as previously assigned
Integrity check info	Not Checked
Number of RRC Message Transmissions	Not Present
Release cause	Check to see if set to "Re-establishment reject"

## RRC CONNECTION RELEASE COMPLETE: TM

Information Element	Semantics description
Message Type	
U-RNTI	
- SRNC Identity	Check the same SRNC identity as previously assigned
- S-RNTI	Check the same S-RNTI as previously assigned
Integrity check info	Not checked.

## 8.1.4.5.5 Test requirement

After step 3 the UE shall find the new cell 2 and transmits RRC CONNECTION RE-ESTABLISHMENT REQUEST to ask for re-connection of the radio link.

After step 5 the UE shall not transmit RRC CONNECTION RE-ESTABLISHMENT REQUEST message, instead it sends RRC CONNECTION RELEASE COMPLETE message on the uplink CCCH (transparent mode) and goes back to idle mode.

## 8.1.4.6 RRC Connection Re-Establishment: Failure(T315=0,T314=0)

### 8.1.4.6.1 Definition

### 8.1.4.6.2 Conformance requirement

RRC connection re-establishment is needed, when a UE loses the radio connection due to e.g. radio link failure in CELL\_DCH state. However the UE must enter to idle mode when T314 is set to 0 in RADIO BEARER SETUP message and also T315 is set to 0 in SYSTEM INFORMATION message.

### Reference

3GPP TS 25.331 clause 8.1.5

### 8.1.4.6.3 Test purpose

To confirm that the UE enters to idle mode, after detecting that a radio link failure has occurred.

### 8.1.4.6.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE: CELL\_DCH state

#### Test Procedure

The UE is brought to CELL\_DCH state, after successfully executing the mobile-terminated RRC connection establishment procedure as outlined in clause 7.1.2 in TS 34.108. The MASTER INFORMATION BLOCK and SYSTEM INFORMATION BLOCK TYPE 2 messages on the downlink BCCH is modified with respect to the default setting. Next, SS transmits RADIO BEARER SETUP message on the downlink DCCH in order to establish radio bearers for user-data on DTCH. In this message, the re-establishment timers T314 and T315 are both set to 0. The UE shall respond by sending a RADIO BEARER SETUP COMPLETE message on the uplink DCCH. After the DTCH has been established, the SS stops transmitting and receiving on the radio link except P-CCPCH, the UE should detect a radio link failure. Then the UE shall enter to idle mode as both T314 and T315 are set to 0. The SS transmits a PAGING TYPE1 message on the PCCH to confirm that the UE is in idle state., the UE transmits an RRC CONNECTION REQUEST message on the uplink CCCH. SS replies with an RRC CONNECTION SETUP message and allocates dedicated channels to the UE. Then, the UE shall complete this test by transmitting RRC CONNECTION SETUP COMPLETE message on the uplink DCCH.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	MASTER INFORMATION BLOCK SYSTEM INFORMATION BLOCK TYPE 2	T315=0
2		←	RADIO BEARER SETUP	T314=0
3		→	RADIO BEARER SETUP COMPLETE	
4				The UE is brought to CELL_DCH state, after making a successful outgoing call.
5				The SS stops transmitting and receiving on the radio link except the PCCPCH.
6				The UE should enter to idle mode after it detects the radio link failure and SS confirms that the UE does not transmit any RRC CONNECTION RE- ESTABLISHMENT REQUEST messages for 20 seconds.
7		←	PAGING TYPE1	SS resumes transmission and reception on radio links suspended in step 4. SS pages the UE using a matched identity (test- SIM IMSI).
8		→	RRC CONNECTION REQUEST	SS checks the following IEs : "Initial UE identity" – must be the same as test-SIM IMSI. "Establishment Cause – must "Terminating Call" "Protocol Indicator" – must be FALSE
9		←	RRC CONNECTION SETUP	SS assigns DPCH resources to allow UE to establish a RRC connection.
10		→	RRC CONNECTION SETUP COMPLETE	UE shall acknowledge the completion of RRC connection establishment procedure.

## Specific Message Contents

## MASTER INFORMATION BLOCK (Step 1)

Use the same message type in clause 6.1 of TS 34.108, with the following exception:

Information Element	Value/remark
MIB Value Tag	2

## SYSTEM INFORMATION BLOCK TYPE 2 (Step 1)

Use the same message type in clause 6.1 of TS 34.108, with the following exceptions:

Information Element	Value/remark
UE Timers and constants in connected mode	
T301	3 seconds
T313	15 seconds
T314	20 seconds
T315	0 seconds
N313	50

#### RADIO BEARER SETUP (Step 2)

The contents of RADIO BEARER SETUP message in this test case is identical to message sub-type titled “The others of speech in CS” in Annex A, with the following exceptions:

Information Element	Value/remark
RAB information to setup list	
- RAB information for setup	
- RAB info	
- RAB identity	1
- CN Domain Identity	One of the CN domains supported by the UE
- Re-establishment timer	
- CHOICE Timer value	T314
- T314 value	0

#### PAGING TYPE 1 (Step 7)

Information Element	Value/remark
Paging record list	Only 1 entry
Paging record	
CHOICE Paging originator	CN originator
- Paging cause	Terminating Call with one of the supported services (Conversational Call, Streaming Call, Interactive Call, Background Call, SMS)
- CN domain identity	Supported Domain ( PS Domain or CS Domain )
- CHOICE UE Identity	IMSI
- IMSI	Set to the same octet string as in the IMSI stored in the USIM card

#### 8.1.4.6.5 Test requirement

After step 5 the UE shall not transmit an RRC CONNECTION RE-ESTABLISHMENT REQUEST message.

After step 9 the UE shall have an RRC connection based on dedicated physical channel resources. SS verifies that the UE transmits RRC CONNECTION SETUP COMPLETE on the uplink DCCH.

#### 8.1.4.7 RRC Connection Re-Establishment: Success(T314=0, T315>0 and radio link failure)

##### 8.1.4.7.1 Definition

##### 8.1.4.7.2 Conformance requirement

RRC connection re-establishment is needed, when a UE loses the radio connection due to e.g. radio link failure in CELL\_DCH state. But the UE must release the radio bearer which is associated with T314 if T314 is set to 0. After a successful cell re-selection and a subsequent transition to CELL\_FACH state, the UE transmits an RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE “U-RNTI” on the uplink CCCH to request for the re-establishment of an RRC connection. The UTRAN transmits an RRC CONNECTION RE-ESTABLISHMENT message on the downlink DCCH, which includes the new configuration information assigned. Then the UE transmits an RRC CONNECTION RE-ESTABLISHMENT COMPLETE message on the uplink DCCH using AM RLC.

## Reference

3GPP TS 25.331 clause 8.1.5

### 8.1.4.7.3 Test purpose

To confirm that the UE indicates to the non-access stratum the release of radio access bearer which is associated with T314 and try to find a new cell by transiting to CELL\_FACH state, after detecting that a radio link failure has occurred. The UE shall then attempt to establish a new RRC connection using an RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE "U-RNTI". Finally when the UTRAN allocates a new configuration to the UE using RRC CONNECTION ESTABLISHMENT message, the UE shall establish a new RRC connection link.

### 8.1.4.7.4 Method of test

#### Initial Condition

System Simulator : 2 cells • Cell 1 is active, Cell 2 is inactive •

UE: CELL\_DCH state in cell 1, after executing a generic call set-up procedure for mobile originating CS or PS call (clauses 7.2.3.2 and 7.2.4.2 in TS 34.108). The exact procedure to apply depends on the CN domain(s) supported by the UE.

#### Test Procedure

The UE is brought to CELL\_DCH state in a cell 1 after making an successful outgoing call attempt. After the call has been established, SS begins to broadcast the BCCH in cell 2, and then stops transmitting and receiving in cell 1. The UE shall detect a radio link failure in cell 1 and indicate to the non-access stratum the release of the radio bearer which is associated with T314. It shall attempt to re-select to cell 2. It should then enter CELL\_FACH state and transmits an RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE "U-RNTI" on the uplink CCCH to SS. The SS transmits an RRC CONNECTION RE-ESTABLISHMENT message which includes a new configuration. After the UE receives an RRC CONNECTION RE-ESTABLISHMENT message, it reconfigures the new radio connection and transmits an RRC CONNECTION RE-ESTABLISHMENT COMPLETE message on the uplink DCCH using AM RLC.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER SETUP	T314=0
2		→	RADIO BEARER SETUP COMPLETE	
3				The UE is brought to CELL_DCH state in a cell 1, after making a successful outgoing call.
4		←	BCCH	The SS starts transmitting the BCCH in a cell 2 using the same contents (except for cell identity which is set to "0000 0000 0000 0010") for system information sent on cell 1. SS starts to listen to the uplink CCCH of cell 2.
5				The SS stops transmitting and receiving in a cell .1.
6				The UE detects the radio link failure which is associated with T314. The UE indicates to the non-access stratum the release of the affected radio bearer .
7		→	RRC CONNECTION RE-ESTABLISHMENT REQUEST	The UE should find a new cell 2 and then transmits this message which includes the IE"U-RNTI" assigned previously.
8		←	RRC CONNECTION RE-ESTABLISHMENT	Including the new configuration information.
9		→	RRC CONNECTION RE-ESTABLISHMENT COMPLETE	

Specific Message Contents

## RADIO BEARER SETUP

The contents of RADIO BEARER SETUP message in this test case is identical to those in default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
RAB information to setup list - RAB information to setup - RAB info - T314	0

### 8.1.4.7.5 Test requirement

After step5, the UE shall indicate to the non-access stratum the release of the radio bearer which is associated with T314. SS checks that no further data transmission from the affected radio bearer is received from the UE.

After step6, the UE shall detect the presence of cell 2 and attempts to re-established the lost RRC connection by transmitting RRC CONNECTION RE-ESTABLISHMENT REQUEST in the new cell.

After step8, the UE shall re-establish an RRC connection .



#### 8.1.4.8 RRC Connection Re-Establishment: Success(T314>0, T315=0 and radio link failure)

##### 8.1.4.8.1 Definition

##### 8.1.4.8.2 Conformance requirement

RRC connection re-establishment is needed, when a UE loses the radio connection due to e.g. radio link failure in CELL\_DCH state. But the UE must release the radio bearer which is associated with T315 if T315 is set to 0. After a successful cell re-selection and subsequent transition to CELL\_FACH state, the UE transmits an RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE "U-RNTI" on the uplink CCCH to request for the re-establishment of an RRC connection. The UTRAN transmits an RRC CONNECTION RE-ESTABLISHMENT message on the downlink DCCH, which includes the new configuration information assigned. Then the UE transmits an RRC CONNECTION RE-ESTABLISHMENT COMPLETE message on the uplink DCCH using AM RLC.

##### Reference

3GPP TS 25.331 clause 8.1.5

##### 8.1.4.8.3 Test purpose

To confirm that the UE shall indicate to the non-access stratum the release of radio access bearer which is associated with T315 and try to find a new cell by transiting to CELL\_FACH state, after detecting that a radio link failure has occurred. The UE shall then attempt to establish a new RRC connection using an RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE "U-RNTI". Finally when the SS allocates a new configuration to the UE using RRC CONNECTION RE-ESTABLISHMENT message, the UE shall establish a new RRC connection link.

##### 8.1.4.8.4 Method of test

##### Initial Condition

System Simulator : 2 cells • Cell 1 is active, Cell 2 is inactive •

UE: CELL\_DCH state in cell 1, after executing a generic call set-up procedure for mobile originating CS or PS call (clauses 7.2.3.2 and 7.2.4.2 in TS 34.108). The exact procedure to apply depends on the CN domain(s) supported by the UE.

##### Test Procedure

The UE is brought to CELL\_DCH state in a cell 1 after making an successful outgoing call attempt. After the call has been established, SS begins to broadcast the BCCH in cell 2, and then stops transmitting and receiving in cell 1. The UE shall detect a radio link failure in cell 1 and indicate to the non-access stratum the release of the radio bearer which is associated with T315. Then it shall attempt to re-select to cell 2. After that, it should then enter CELL\_FACH state and transmits an RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE "U-RNTI" on the uplink CCCH to SS. The SS transmits an RRC CONNECTION RE-ESTABLISHMENT message which includes a new configuration information. After the UE receives an RRC CONNECTION RE-ESTABLISHMENT message, it reconfigures the new radio connection and transmits an RRC CONNECTION RE-ESTABLISHMENT COMPLETE message on the uplink DCCH using AM RLC.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER SETUP	T315=0
2		→	RADIO BEARER SETUP COMPLETE	
3				The UE is brought to CELL_DCH state in a cell 1, after making a successful outgoing call.
4		←	BCCH	The SS starts transmitting the BCCH in a cell 2 using the same contents (except for cell identity which is set to "0000 0000 0000 0010") for system information sent on cell 1. SS starts to listen to the uplink CCCH of cell 2.
5				The SS stops transmitting and receiving in a cell .1.
6				The UE detects the radio link failure which is associated with T315. The UE indicates to the non-access stratum the release of the radio bearer .
7		→	RRC CONNECTION RE-ESTABLISHMENT REQUEST	The UE should find a new cell 2 and then transmits this message which includes the IE"U-RNTI" assigned previously.
8		←	RRC CONNECTION RE-ESTABLISHMENT	Including the new configuration information channel.
9		→	RRC CONNECTION RE-ESTABLISHMENT COMPLETE	

Specific Message Contents

#### RADIO BEARER SETUP

The contents of RADIO BEARER SETUP message in this test case is identical to those in default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
RAB information to setup list - RAB information to setup - RAB info - T314	0

#### 8.1.4.8.5 Test requirement

After step5, the UE shall indicate to the non-access stratum the release of the radio bearer which is associated with T314.

After step6, the UE shall detect the presence of cell 2 and attempts to re-established the lost RRC connection by transmitting RRC CONNECTION RE-ESTABLISHMENT REQUEST to the new cell.

After step8, the UE shall re-establish an RRC connection.

## 8.1.4.9 RRC Connection Re-Establishment: Failure (T314 is timeout and T315=0)

### 8.1.4.9.1 Definition

### 8.1.4.9.2 Conformance requirement

RRC connection re-establishment is needed, when a UE loses the radio connection due to e.g. radio link failure in CELL\_DCH state. When the UE could not find a new cell before timer T314 expires, the UE shall enter idle mode.

### Reference

3GPP TS 25.331 clause 8.1.5

### 8.1.4.9.3 Test purpose

To confirm that the UE enters idle mode, after T314 timeout following a radio link failure.

### 8.1.4.9.4 Method of test

### Initial Condition

System Simulator : 1 cell

UE: CELL\_DCH state

### Test Procedure

The UE is brought to CELL\_DCH state after a successful RRC connection establishment . After the DTCH has been established using radio bearer establishment procedure, the SS stops transmitting and receiving the DPCCH and DPDCH on the radio link. The UE shall detect a radio link failure. Before T314 is timeout, the UE shall continue to search for a new cell. During this period, SS transmits a PAGING TYPE1 message on the PCCH to confirm that the UE has not entered the idle state. This is confirmed when no response from UE is received before T314 timeout. After T314 timeout, the UE shall enter idle mode. The SS transmits a PAGING TYPE1 message on the PCCH again to confirm that the UE is in idle state. The UE shall respond by transmitting an RRC CONNECTION REQUEST message on the uplink CCCH.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER SETUP	T314=20 seconds
2		→	RADIO BEARER SETUP COMPLETE	
3				The UE is brought to CELL_DCH state, after making a successful outgoing call.
4				The SS stops transmitting and receiving the DPCCH and DPDCH on the radio link.
5		←	PAGING TYPE1	The SS transmits this message, which includes a matched identity (set to the test-USIM IMSI) before T314 timeout.
6				The SS confirms that the UE does not transmit a response in the next 20 seconds.
7		←	PAGING TYPE1	The SS transmits the message, which includes a matched identity (set to the test-USIM IMSI).
8		→	RRC CONNECTION REQUEST	SS checks the following IEs : "Initial UE identity" – must be the same as test-SIM IMSI. "Establishment Cause – must "Terminating Call" "Protocol Indicator" – must be FALSE
9		←	RRC CONNECTION SETUP	SS assigns DPCH resources to allow UE to establish a RRC connection.

## Specific Message Contents

## SYSTEM INFORMATION TYPE 2

Information Element	Value/remark
UE Timers and constants in connected mode	
T301	3 seconds
T313	15 seconds
T314	20 seconds
T315	0 seconds
N313	50

## RADIO BEARER SETUP (Step 1)

The contents of RADIO BEARER SETUP message in this test case is identical to the one found in clause of TS 34.108 with the following exceptions:

Information Element	Value/remark
RAB information to setup	
- RAB info	0000 0001B
- RAB identity	CS domain
- CN domain identity	
Re-establishment timer	
- T314	20 seconds
- RB information to setup	
- RB identity	5
- PDCP info	Not Present
- RLC info	
- Downlink RLC mode	TM RLC
- In-sequence delivery	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	2
- MAC logical channel priority	1
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	2
- Logical channel identity	1

## PAGING TYPE 1 (Step 5 and 7)

Information Element	Value/remark
Paging record list	Only 1 entry
Paging record	
CHOICE Paging originator	CN originator
- Paging cause	Terminating Call with one of the supported services ( Conversational Call, Streaming Call, Interactive Call, Background Call, SMS)
- CN domain identity	Supported Domain ( PS Domain or CS Domain )
- CHOICE UE Identity	IMSI
- IMSI	Set to the same octet string as in the IMSI stored in the USIM card

## RRC CONNECTION SETUP (Step 9)

Use the default message found in clause 9 of TS 34.108.

## 8.1.4.9.5 Test requirement

After step 5 the UE shall not transmits an RRC CONNECTION REQUEST message.

After step 9 the UE shall have an RRC connection based on dedicated physical channel resources.

## 8.1.4.10 RRC Connection Re-Establishment: Failure (T315 is timeout and T314=0)

## 8.1.4.10.1 Definition

## 8.1.4.10.2 Conformance requirement

RRC connection re-establishment is needed, when a UE loses the radio connection due to e.g. radio link failure in CELL\_DCH state. When the UE could not find a new cell before timer T315 is expires, the UE shall enter idle mode.

## Reference

3GPP TS 25.331 clause 8.1.5

#### 8.1.4.10.3 Test purpose

To confirm that the UE enters idle mode, after T315 is expires following a radio link failure.

#### 8.1.4.10.4 Method of test

##### Initial Condition

System Simulator : 1 cell

UE: CELL\_DCH state

##### Test Procedure

The UE is brought to CELL\_DCH state after a successful RRC connection establishment. After the DTCH has been established using the radio bearer establishment procedure, the SS stops transmitting and receiving the DPCH and DPDCH on the radio link. The UE shall detect a radio link failure. Before T315 is timeout, the UE shall continue to search for a new cell. During this period, SS transmits a PAGING TYPE1 message on the PCCH to confirm that the UE has not entered the idle state. This is confirmed when no response from the UE is received before T315 timeout. After T315 is timeout, the UE shall enter idle mode. The SS transmits a PAGING TYPE1 message on the PCCH again to confirm that the UE is in idle state. The UE shall respond by transmitting an RRC CONNECTION REQUEST message on the uplink CCCH.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER SETUP	T315=30 seconds
2		→	RADIO BEARER SETUP COMPLETE	
3				The UE is brought to CELL_DCH state, after making a successful outgoing call.
4				The SS stops transmitting and receiving the DPCH and DPDCH on the radio link.
5		←	PAGING TYPE1	The SS transmits this message, which includes a matched identity (set to the test-USIM IMSI) before T315 itimeout.
6				The SS confirms that the UE does not transmit a response in the next 30 seconds.
7		←	PAGING TYPE1	The SS transmits the message, which includes a matched identity (set to the test-USIM IMSI).
8		→	RRC CONNECTION REQUEST	SS checks the following IEs : "Initial UE identity" – must be the same as test-SIM IMSI. "Establishment Cause – must "Terminating Call" "Protocol Indicator" – must be FALSE
9		←	RRC CONNECTION SETUP	SS assigns DPCH resources to allow UE to establish a RRC connection.

## Specific Message Contents

## SYSTEM INFORMATION TYPE 2

Information Element	Value/remark
UE Timers and constants in connected mode	
T301	3 seconds
T313	15 seconds
T314	0 seconds
T315	30 seconds
N313	50

## RADIO BEARER SETUP (Step 1)

The contents of RADIO BEARER SETUP message in this test case is identical to the one found in clause 9 of TS 34.108 with the following exceptions:

Information Element	Value/remark
RAB information to setup	
- RAB info	0000 0001B
- RAB identity	CS domain
- CN domain identity	
Re-establishment timer	
- T315	30 seconds
- RB information to setup	
- RB identity	5
- PDCP info	Not Present
- RLC info	
- Downlink RLC mode	TM RLC
- In-sequence delivery	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	2
- MAC logical channel priority	1
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	2
- Logical channel identity	1

## PAGING TYPE 1 (Step 5 and 7)

Information Element	Value/remark
Paging record list	Only 1 entry
Paging record	
CHOICE Paging originator	CN originator
- Paging cause	Terminating Call with one of the supported services ( Conversational Call, Streaming Call, Interactive Call, Background Call, SMS)
- CN domain identity	Supported Domain ( PS Domain or CS Domain )
- CHOICE UE Identity	IMSI
- IMSI	Set to the same octet string as in the IMSI stored in the USIM card

## RRC CONNECTION SETUP (Step 9)

Use the default message found in clause 9 of TS 34.108.

## 8.1.4.10.5 Test requirement

After step 5 the UE shall not transmit an RRC CONNECTION REQUEST message.

After step 9 the UE shall have an RRC connection based on dedicated physical channel resources.

## 8.1.4.11 RRC Connection Re-Establishment: Success( Unrecoverable error in RLC )

## 8.1.4.11.1 Definition

## 8.1.4.11.2 Conformance requirement

RRC connection re-establishment is needed, when a UE loses the radio connection due to e.g. detection of RLC unrecoverable error ( amount of the retransmission of RESET\_PDU reaches the value of Max\_DAT and receives no ACK ) in CELL\_DCH state. After a successful cell re-selection and transition to CELL\_FACH state, the UE transmits an RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE"U-RNTI" on the uplink CCCH to request for the re-establishment of an RRC connection. The UTRAN transmits an RRC CONNECTION RE-ESTABLISHMENT message on the downlink DCCH, which includes the new configuration information assigned. Then the UE transmits an RRC CONNECTION RE-ESTABLISHMENT COMPLETE message on the uplink DCCH using AM RLC.



## Reference

3GPP TS 25.331 clause 8.1.5

### 8.1.4.11.3 Test purpose

To confirm that the UE tries to find a new cell by transiting to CELL\_FACH state, after detecting that a RLC unrecoverable error has occurred. The UE shall then attempt to establish a new RRC connection using an RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE "U-RNTI". Finally when the SS allocates a new configuration to the UE using RRC CONNECTION ESTABLISHMENT message, the UE shall establish a new RRC connection link.

### 8.1.4.11.4 Method of test

#### Initial Condition

System Simulator : 2 cells • Cell 1 is active, Cell 2 is inactive •

UE: CELL\_DCH state in cell 1

#### Test Procedure

The UE is brought to CELL\_DCH state in a cell 1 after a successful outgoing call attempt. After the call has been established, the SS transmits a PAGING TYPE2 message on the downlink DCCH. Then the UE transmits an UPLINK DIRECT TRANSFER message on the uplink using AM-RLC for the response and the SS does not transmit a STATUS PDU for the response to AM-RLC PDU. and begins to broadcast the BCCH in cell 2. The UE should detect an unrecoverable error in cell 1 and attempts to re-select to cell 2. It should then enter CELL\_FACH state and transmits an RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE "U-RNTI" on the uplink CCCH to SS. The SS transmits an RRC CONNECTION RE-ESTABLISHMENT message which includes "TRUE" in RLC reset indicator( for C-plane) IE and a new TFCS setting according to the new transport channel. After the UE receives an RRC CONNECTION RE-ESTABLISHMENT message, it reconfigures the RLC and the new radio connection and transmits an RRC CONNECTION RE-ESTABLISHMENT COMPLETE message on the uplink DCCH using AM RLC.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is brought to CELL_DCH state in a cell 1, after making a successful outgoing call.
2		←	PAGING TYPE2	The SS transmits a PAGING TYPE 2 message to the UE on the downlink DCCH in cell 1.
3		→	UPLINK DIRECT TRANSFER	The UE responds to the PAGING TYPE 2 message using AM-RLC but the SS does not transmit a STATUS PDU as an acknowledgement.
4		←	BCCH	The SS starts transmitting the BCCH in a cell 2 using the same contents (except for cell identity which is set to "0000 0000 0000 0010") for system information sent on cell 1. SS starts to listen to the uplink CCCH of cell 2.
5				The UE detects an unrecoverable error in the RLC level.
6		→	RRC CONNECTION RE-ESTABLISHMENT REQUEST	The UE should find a new cell 2 and then transmits this message which includes the IE "U-RNTI" assigned previously.
7		←	RRC CONNECTION RE-ESTABLISHMENT	Including the new configuration information.
8		→	RRC CONNECTION RE-ESTABLISHMENT COMPLETE	

## Specific Message Contents

## Cell 1: SYSTEM INFORMATION TYPE 2

Information Element	Value/remark
UE Timers and constants in connected mode	
T301	8 seconds
T313	15 seconds
T314	30 seconds
T315	30 seconds
N313	16

## 8.1.4.11.5 Test requirement

After step5, the UE shall detect the presence of cell 2 and attempt to re-established the RRC connection by transmitting RRC CONNECTION RE-ESTABLISHMENT REQUEST in the new cell.

After step7, the UE shall re-establish an RRC connection.

## 8.1.5 UE capability

### 8.1.5.1 UE Capability: Success

#### 8.1.5.1.1 Definition

#### 8.1.5.1.2 Conformance requirement

1. The UE CAPABILITY ENQUIRY message is sent by the UTRAN to request the UE to transmit its capability information related to any radio access network that is supported by the UE if the UTRAN needs an update of the UE's UMTS capability information or of its inter-system classmark.
2. When the UE receives a UE CAPABILITY ENQUIRY message, the UE transmits a UE CAPABILITY INFORMATION message on the uplink DCCH. Then the UTRAN transmits a UE CAPABILITY INFORMATION CONFIRM message.
3. If during the execution of UE capability update procedure, an invalid UE CAPABILITY INFORMATION CONFIRM is received, the UE shall respond with RRC STATUS message and decide whether to re-transmit UE CAPABILITY INFORMATION message by comparing its internal counter against N304.

#### Reference

3GPP TS 25.331 clause 8.1.6, 8.1.7

#### 8.1.5.1.3 Test purpose

To confirm that the UE transmits a UE CAPABILITY INFORMATION message after it receives a UE CAPABILITY ENQUIRY message from the SS. To confirm that the UE indicate an invalid message reception when erroneous downlink UE CAPABILITY ENQUIRY and UE CAPABILITY INFORMATION CONFIRM messages are received. The UE shall transmit RRC STATUS message with the correct error cause value to SS.

#### 8.1.5.1.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE: CELL\_DCH state

#### Test Procedure

The UE is brought to the CELL\_DCH state after a successful outgoing call attempt. The SS transmits an erroneous UE CAPABILITY ENQUIRY message containing spare value in the IE "Capability update requirement". After receiving such a message, the UE should report the error using RRC STATUS message with the appropriate error cause specified. Then SS transmits a UE CAPABILITY ENQUIRY message which includes the IE "Capability update requirement", the UE receives this message and transmits a UE CAPABILITY INFORMATION message on the uplink DCCH which includes the "Inter-system message" IE. The SS transmits a UE CAPABILITY INFORMATION CONFIRM message to the UE to complete the test. Then SS initiates another UE capability update procedure by transmitting the same UE CAPABILITY ENQUIRY using as in step 4. The UE shall reply with a UE CAPABILITY INFORMATION message on the uplink DCCH. When SS receives this message, it transmit an erroneous UE CAPABILITY INFORMATION CONFIRM message. The content of this message is a concatenation of the message type IE and an arbitrary 32-bits string. The UE shall detect a protocol error and send RRC STATUS message to report this event. After receiving RLC acknowledgement for this message, the UE shall re-transmit UE CAPABILITY INFORMATION message on the uplink DCCH. SS completes this test by an error-free UE CAPABILITY INFORMATION CONFIRM message similar to the message sent in step 6.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is brought to CELL_DCH state after an outgoing call has been established successfully.
2		←	UE CAPABILITY ENQUIRY	See specific message contents for this message
3		→	RRC STATUS	The IE "Protocol error cause" found in IE "Protocol error information" should be set to "Information element value not comprehended"
4		←	UE CAPABILITY ENQUIRY	Use default message.
5		→	UE CAPABILITY INFORMATION	The message shall include the IE "Inter-system message", which carries the GSM classmark information requested.
6		←	UE CAPABILITY INFORMATION CONFIRM	Use default message.
7		←	UE CAPABILITY ENQUIRY	Same as in step 4.
8		→	UE CAPABILITY INFORMATION	Shall be the same message content as in step 5.
9		←	UE CAPABILITY INFORMATION CONFIRM	This message contains an arbitrary 32-bits patterns, following the IE "Message Type"
10		→	RRC STATUS	UE shall detect an error and then transmit this message.
11		→	UE CAPABILITY INFORMATION	UE shall re-transmit this message after receiving acknowledgement from the SS for RRC STATUS message.
12		←	UE CAPABILITY INFORMATION CONFIRM	SS sends an error-free message to acknowledge the receipt of the uplink message.

## Specific Message Contents

## UE CAPABILITY ENQUIRY (Step 2 and 7)

Information Element	Value/remark
Capability update requirement - UE radio access capability update requirement - System specific capability update requirement list - System specific capability update requirement	TRUE  Contains a spare value in this IE

## RRC STATUS (Step 3)

Information Element	Value/remark
Protocol Error Information - Protocol Error Cause	Checked to see if set to "Information element not comprehended"

## UE CAPABILITY INFORMATION CONFIRM (Step 9)

Information Element	Value/remark
Unknown bit pattern	An arbitrary 32 bits

## RRC STATUS (Step 3)

Information Element	Value/remark
Protocol Error Information - Protocol Error Cause	Checked to see if set to "ASN.1 violation or encoding" or "conditional information element error"

#### 8.1.5.1.5 Test requirement

After step 2, the UE shall transmit a RRC STATUS message on the uplink DCCH, reporting the error with protocol error cause set to "Information element value not comprehended".

After step 4 the UE shall transmit a UE CAPABILITY INFORMATION message on the uplink DCCH to respond to the UE CAPABILITY ENQUIRY message.

After step 9, the UE shall transmit a RRC STATUS message on the uplink DCCH. The protocol error cause shall be set to "ASN.1 violation or encoding" or "conditional information element error".

After step 10, the UE shall re-transmit the UE CAPABILITY INFORMATION message with a similar content as in step 8.

### 8.1.5.2 UE Capability: Success after T304 timeout

#### 8.1.5.2.1 Definition

#### 8.1.5.2.2 Conformance requirement

1. The UE CAPABILITY ENQUIRY message is sent by the UTRAN to request the UE to transmit its capability information related to any radio access network that is supported by the UE, if the UTRAN needs an update of the UE's UMTS capability information or of its inter-system classmark.
2. After the UE receives a UE CAPABILITY ENQUIRY message, it transmits a UE CAPABILITY INFORMATION message on the uplink DCCH. If it fails to receive a UE CAPABILITY INFORMATION CONFIRM message, the UE re-transmits another UE CAPABILITY INFORMATION message until V304 is greater than N304.

#### Reference

3GPP TS 25.331 clause 8.1.6, 7

#### 8.1.5.2.3 Test purpose

To confirm that the UE re-transmits a UE CAPABILITY INFORMATION message until V304 is greater than N304, after the expiry of timer T304 when the UE cannot receive a UE CAPABILITY INFORMATION CONFIRM message in response to a UE CAPABILITY INFORMATION message.

#### 8.1.5.2.4 Method of test

##### Initial Condition

System Simulator : 1 cell

UE: CELL\_DCH state

##### Test Procedure

The UE is brought to CELL\_DCH state. When the SS transmits a UE CAPABILITY ENQUIRY message which includes the "Capability update requirement" IE, the UE shall reply with a UE CAPABILITY INFORMATION message on the uplink DCCH which includes the "Inter-system message" IE. The SS does not transmit a UE CAPABILITY

INFORMATION CONFIRM message to the UE, resulting in the T304 timer to expire. SS shall observe that the UE attempts to transmit a UE CAPABILITY INFORMATION message again. The UE shall re-transmit N304 times, and SS transmits a UE CAPABILITY INFORMATION CONFIRM message to answer the last request and completes this test procedure.

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is brought to CELL_DCH state. SS sets internal counter K =1
2		←	UE CAPABILITY ENQUIRY	Including the "Capability update requirement" IE.
3		→	UE CAPABILITY INFORMATION	Including the "Inter-system message" IE, which indicated the radio access network supported by the UE.
4				If K is greater to N304, then proceed to step 6.
5				The SS does not transmit a response and wait for T304 timer to expire. K=K+1 and goes to step 3.
6		←	UE CAPABILITY INFORMATION CONFIRM	Use default message contents

#### Specific Message Contents

None

#### 8.1.5.2.5 Test requirement

After step3 the UE shall re- transmits a UE CAPABILITY INFORMATION message on the uplink DCCH, after each expiry of timer T304. The UE CAPABILITY INFORMATION message shall contain IE" UE radio access capability" indicating the settings found in PIC/PIXIT statements. IE"UE system specific capability" shall carry relevant GSM classmark information. After (N304+1) re-transmissions, the UE shall receive a UE CAPABILITY INFORMATION CONFIRM message.

#### 8.1.5.3 UE Capability: Failure (After N304 re-transmissions)

##### 8.1.5.3.1 Definition

##### 8.1.5.3.2 Conformance requirement

1. The UE CAPABILITY ENQUIRY message is sent by the UTRAN to request the UE to transmit its capability information related to any radio access network that is supported by the UE if the UTRAN needs an update of the UE's UMTS capability information or of its inter-system classmark.
2. In the case of a failure to transmit a UE CAPABILITY INFORMATION in excess of N304 times, the UE initiates the RRC connection re-establishment procedure.

#### Reference

3GPP TS 25.331 clause 8.1.6, 8.1.7

### 8.1.5.3.3 Test purpose

To confirm that the UE stops retrying to transmit a UE CAPABILITY INFORMATION message if V304 is greater than N304. It then initiates the RRC re-establishment procedure.

### 8.1.5.3.4 Method of test

Initial Condition

System Simulator : 1 cell

UE: CELL\_DCH state

### Test Procedure

The UE is brought to CELL\_DCH state. When the SS transmits a UE CAPABILITY ENQUIRY message which includes the "Capability update requirement"IE, the UE receives this message and transmits a UE CAPABILITY INFORMATION message on the uplink DCCH which includes the "Inter-system message"IE. The SS does not respond with a UE CAPABILITY INFORMATION CONFIRM message but keeps a count on the number of messages received. When the T304 timer expires, the UE shall transmit a UE CAPABILITY INFORMATION message again. After sending (N304+1) messages, the UE shall stop sending UE CAPABILITY INFORMATION messages and initiates the RRC connection re-establishment procedure. This is verified in SS by the reception of RRC CONNECTION RE-ESTABLISHMENT REQUEST. SS allows UE to return to connected state by issuing RRC CONNECTION RE-ESTABLISHMENT message on the downlink CCCH.

### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE starts from CELL_DCH state. SS sets counter K to 1
2		←	UE CAPABILITY ENQUIRY	Including the "Capability update requirement"IE.
3		→	UE CAPABILITY INFORMATION	Including the "Inter-system message"IE.
4				The SS does not transmit a response and allows T304 timer to expire. SS increments counter K If K is greater than N304, proceeds to step 5 else returns to 3.
5		→	RRC CONNECTION RE-ESTABLISHMENT REQUEST	The UE assumes that radio link failure has occurred and transmits this message which includes the IE"U-RNTI" containing the U-RNTI allocated to the UE earlier.
6		←	RRC CONNECTION RE-ESTABLISHMENT	Including the new TFCS according to the new transport channel.
7		→	RRC CONNECTION RE-ESTABLISHMENT COMPLETE	

### Specific Message Contents

None

#### 8.1.5.3.5 Test requirement

After step3 the UE shall transmit a UE CAPABILITY INFORMATION message on the uplink DCCH. The UE shall re-transmit this message for N304 times. Thereafter, the UE shall initiate the RRC re-establishment procedure by sending the message RRC CONNECTION RE-ESTABLISHMENT REQUEST.

After step7 the UE shall have a new RRC connection, using the new transport format dictated in the RRC CONNECTION RE-ESTABLISHMENT message.

### 8.1.6 Direct Transfer

#### 8.1.6.1 Direct Transfer in CELL DCH state(invalid message reception)

##### 8.1.6.1.1 Definition

##### 8.1.6.1.2 Conformance requirement

The UE shall transmit an RRC STATUS message stating the reason “protocol error” in IE” failure cause” and also set value “Information element value not comprehended” in IE” Protocol error cause “ when the UE receives a DOWNLINK DIRECT TRANSFER message, which includes a spare value for the mandatory IE” CN domain identity” having criticality defined as “Reject”.

#### Reference

3GPP TS 25.331 clause 8.1.9

##### 8.1.6.1.3 Test purpose

To confirm that the UE transmits an RRC STATUS message on the DCCH using AM RLC if it receives a DOWNLINK DIRECT TRANSFER message specifying a spare value in the mandatory IE” CN domain identity”

##### 8.1.6.1.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

#### Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a DOWNLINK DIRECT TRANSFER message to the UE and includes the spare value in the mandatory IE” CN domain identity”. The UE shall transmit an RRC STATUS message on the DCCH using AM RLC, setting the value “protocol error” in IE” failure cause”. The error type “Information element value not comprehended” shall also be indicated in IE” Protocol error cause”.



Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	DOWNLINK DIRECT TRANSFER	
2		→	RRC STATUS	

Specific Message Contents

#### DOWNLINK DIRECT TRANSFER

The contents of DOWNLINK DIRECT TRANSFER message in this test case is identical to those in default contents of layer 3 messages for RRC tests with the following exceptions:.

Information Element	Value/remark
CN domain identity	Spare value

#### RRC STATUS

Information Element	Value/remark
Message Type	
Protocol error information	Information element value not comprehended
Other information element	Not checked

#### 8.1.6.1.5 Test requirement

After step1 the UE shall transmit a n RRC STATUS message on the DCCH using AM RLC setting “protocol error” in IE” failure cause” and setting “Information element value not comprehended” in IE” Protocol error cause”.

#### 8.1.6.2 Direct Transfer in CELL FACH state(invalid message reception)

##### 8.1.6.2.1 Definition

##### 8.1.6.2.2 Conformance requirement

The UE shall transmit an RRC STATUS message stating the reason “protocol error” in IE” failure cause” and also set value “Information element value not comprehended” in IE” Protocol error cause “ when the UE receives a DOWNLINK DIRECT TRANSFER message, which includes a spare value for the mandatory IE” CN domain identity” having criticality defined as “Reject”.

#### Reference

3GPP TS 25.331 clause 8.1.9

##### 8.1.6.2.3 Test purpose

To confirm that the UE transmits an RRC STATUS message on the DCCH using AM RLC if it receives a DOWNLINK DIRECT TRANSFER message specifying a spare value in the mandatory IE” CN domain identity”

##### 8.1.6.2.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

## Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a DOWNLINK DIRECT TRANSFER message to the UE and includes the spare value in the mandatory IE "CN domain identity". The UE shall transmit an RRC STATUS message on the DCCH using AM RLC, setting the value "protocol error" in IE "failure cause". The error type "Information element value not comprehended" shall also be indicated in IE "Protocol error cause".

### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	DOWNLINK DIRECT TRANSFER	
2		→	RRC STATUS	

### Specific Message Contents

#### DOWNLINK DIRECT TRANSFER

The contents of DOWNLINK DIRECT TRANSFER message in this test case is identical to those in default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
CN domain identity	Spare value

#### RRC STATUS

Information Element	Value/remark
Message Type	
Protocol error information	Information element value not comprehended
Other information element	Not checked

#### 8.1.6.2.5 Test requirement

After step1 the UE shall transmit a n RRC STATUS message on the DCCH using AM RLC setting "protocol error" in IE "failure cause" and setting "Information element value not comprehended" in IE "Protocol error cause".

## 8.1.7 Security mode control

#### 8.1.7.1 Definition

#### 8.1.7.2 Conformance requirement

1. This procedure is used to trigger the start of ciphering or to command a change of the cipher key, both for the signalling link and for a user plane connection.
2. The SRNC transmits a SECURITY MODE COMMAND message to the UE, which indicates the downlink activation time. The UE shall apply the old ciphering configuration before the stated downlink activation time. It shall start to decipher using the new ciphering configuration at the downlink activation time.
3. After the UE transmit the SECURITY MODE COMPLETE message, it starts to cipher transmission in the uplink using the new configuration at the uplink activation time. It shall transmit a SECURITY MODE COMPLETE message, which includes uplink activation time, and configure the downlink reception using new ciphering configuration at the beginning of downlink activation time.

### Reference

3GPP TS 25.331 clause 8.1.12

### 8.1.7.3 Test purpose

To confirm that the UE correctly communicates to the UTRAN and activates the new ciphering configurations after the stated activation time. To confirm that after the UE receives a SECURITY MODE COMMAND message, it transmits a SECURITY MODE COMPLETE message to the UTRAN using the old ciphering configuration.

### 8.1.7.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

#### Test Procedure

The UE is in the RRC connected state CELL\_DCH. The SS transmits a SECURITY MODE COMMAND message in which ciphering is requested to be activated, but the IE "Ciphering algorithm" is set to an unknown value. The UE shall not trigger any ciphering algorithm and it shall respond by sending SECURITY MODE FAILURE message on the DCCH. Next, SS transmits a valid SECURITY MODE COMMAND message which includes the downlink activation time for RB 3 and RB 4. Then the UE shall start to configure ciphering in downlink and transmits a SECURITY MODE COMPLETE message which contains the uplink activation time for RB 3 and RB 4. The UE shall be able to communicate with the SS in the downlink direction after the downlink activation time has passed. Moreover, it shall apply the ciphering algorithm in the uplink direction.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				RRC connected state on DCCH
2		←	SECURITY MODE COMMAND	IE "Ciphering Algorithm" is set to an invalid value
3		→	SECURITY MODE FAILURE	IE "Failure Cause" should be set to "Protocol Error" and IE "Protocol Error Information" should be set to "Information element value not comprehended".
4		←	SECURITY MODE COMMAND	See specific message contents.
5		→	SECURITY MODE COMPLETE	SS verifies that this message is sent unciphered.
6				In uplink direction, SS checks that all data from RB 3 and RB 4 are ciphered. In the downlink direction, SS verifies that data are ciphered only after the RLC sequence numbers indicated in step 4 have elapsed.

## Specific Message Contents

## SECURITY MODE COMMAND (Step 2)

Information Element	Value/remark
Ciphering mode info	Start
Ciphering mode command	1 of the 15 spare values
Security capability	Not Present
Activation time for DPCH	
Activation Time	
Radio bearer downlink ciphering activation time info	
Radio bearer activation time	2 RBs
RB identity <sub>1</sub>	3
RLC sequence number <sub>1</sub>	Current RLC SN + 2
RB identity <sub>2</sub>	4
RLC sequence number <sub>2</sub>	Current RLC SN + 2

## SECURITY MODE COMMAND (Step 4)

Information Element	Value/remark
Ciphering mode command	Start
Security capability	
Ciphering algorithm capability	0000000000000001B(UEA1)
Integrity protection algorithm capability	0000000000000001B(UEA1)
Activation time for DPCH	Not present
Activation time	
Radio bearer downlink ciphering activation time info	
Radio bearer activation time	2 RBs
RB identity <sub>1</sub>	3
RLC sequence number <sub>1</sub>	Current RLC SN+2
RB identity <sub>2</sub>	4
RLC sequence number <sub>2</sub>	Current RLC SN+2

## 8.1.7.5 Test requirement

After step 2 the UE shall transmit a SECURITY MODE FAILURE message to report protocol error detected in the earlier SECURITY MODE COMMAND message. The UE shall be able to communicate normally with the SS, with all control data unciphered.

After step 4 the UE shall RLC-acknowledge the receipt of the SECURITY MODE COMMAND message using unciphered mode. SS checks that the SECURITY MODE COMPLETE message is received unciphered.

After step 5 SS verifies that downlink control data from RB 3 and RB 4 are ciphered using UEA1 algorithm, after the RLC sequence numbers as a downlink activation time stated in step 4 have elapsed. In the uplink direction, the UE shall start to cipher on the uplink after the RLC sequence number as an uplink activation time stated in step 5 has elapsed.

## 8.1.8 Counter check

### 8.1.8.1 Definition

### 8.1.8.2 Conformance requirement

1. When the UE receives a COUNTER CHECK message that includes matched COUNT-C MSB values, the UE shall transmit a COUNTER CHECK RESPONSE message on the uplink DCCH and omitting "RB COUNT-C information" IE in this message.
2. When the UE receives a COUNTER CHECK message that includes any mismatched COUNT-C MSB values, the UE shall transmit a COUNTER CHECK RESPONSE message on the uplink DCCH and specifies the current COUNT-C information of the RAB(s) with mismatched values.

### Reference

3GPP TS 25.331 clause 8.1.15

### 8.1.8.3 Test purpose

To confirm that the UE transmits a COUNTER CHECK RESPONSE message after it receives a COUNTER CHECK message from the SS. To confirm that the UE responds to the reception of an invalid downlink COUNTER CHECK message by transmitting a RRC STATUS message on the uplink DCCH, stating the correct error cause value in message.

### 8.1.8.4 Method of test

#### Initial Condition

System Simulator: 1 cell

UE: CELL\_DCH state

#### Test Procedure

The UE is brought to the CELL\_DCH state after a successful outgoing call attempt. The SS transmits an erroneous COUNTER CHECK message. The content of this message is a concatenation of the message type IE and an arbitrary 32-bits string. The UE shall detect a protocol error and send RRC STATUS message to report this event. Next, the SS transmits a COUNTER CHECK message that includes the current COUNT-C MSB information in each radio access bearer. The UE shall react by sending a COUNTER CHECK RESPONSE message on the uplink DCCH, which does not include "RB COUNT-C information" IE. The SS transmits a COUNTER CHECK message which includes the current COUNT-C MSB information reversed all the bits in each radio bearer. The UE shall send a COUNTER CHECK RESPONSE message on the uplink DCCH, specifying the current COUNT-C information for each radio access bearer established.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is brought to CELL_DCH state after an outgoing call has been established successfully.
2		←	COUNTER CHECK	This message contains an arbitrary 32-bits pattern, following the IE "Message Type"
3		→	RRC STATUS	UE shall detect a protocol error and then transmit this message.
4		←	COUNTER CHECK	See specific message content.
5		→	COUNTER CHECK RESPONSE	The message shall not include the IE "RB COUNT-C information".
6		←	COUNTER CHECK	See specific message content.
7		→	COUNTER CHECK RESPONSE	The message shall include the IE "RB COUNT-C information".

## Specific Message Contents

## COUNTER CHECK (Step 2)

Information Element	Value/remark
Unknown bit pattern	An arbitrary 32-bits string

## RRC STATUS (Step 3)

Information Element	Value/remark
Protocol Error Information - Protocol Error Cause	Checked to see if set to "ASN.1 violation or encoding" or "conditional information element error"

## COUNTER CHECK (Step 4)

Information Element	Value/remark
Integrity check info RB COUNT-C MSB information - RB identity - COUNT-C MSB uplink - COUNT-C MSB downlink	Calculated value  5 Current COUNT-C MSB for RB#5 in uplink Current COUNT-C MSB for RB#5 in downlink

## COUNTER CHECK RESPONSE (Step 5)

Information Element	Value/remark
Integrity check info RB COUNT-C information - RB identity - COUNT-C uplink - COUNT-C downlink	Not checked Check to if this IE is absent

## COUNTER CHECK (Step 6)

Information Element	Value/remark
RB COUNT-C MSB information - RB identity - COUNT-C MSB uplink - COUNT-C MSB downlink	Check to see if set to 4 Toggle all bits of the current COUNT-C MSB in uplink for RB#5 Toggle all bits of the current COUNT-C MSB in downlink for RB#5

## COUNTER CHECK RESPONSE (Step 7)

Information Element	Value/remark
Integrity check info	Not checked
RB COUNT-C information	
- RB identity	Check to see if set to 5
- COUNT-C uplink	Check to see if set to Current COUNT-C for RB#5 in uplink
- COUNT-C downlink	Check to see if set to COUNT-C for RB#5 in downlink

## 8.1.8.5 Test requirement

After step 2, the UE shall transmit a RRC STATUS message on the uplink DCCH. The protocol error cause shall be set to "ASN.1 violation or encoding" or "conditional information element error".

After step 4 the UE shall transmit a COUNTER CHECK RESPONSE message which does not include the IE "RB COUNT-C information" to indicate that a matched comparison result is obtained.

After step 6, the UE shall transmit a COUNTER CHECK RESPONSE message which includes the IE "RB COUNT-C information" to report that a mismatch in COUNT-C value is detected in RB#5.

## 8.1.9 Signalling Connection Release Request

## 8.1.9.1 Definition

## 8.1.9.2 Conformance requirement

The UE shall initiate the signalling connection release procedure when the higher layer entities in the UE request to release one or more signalling session (one example of such case is location update failure). In this case, the UE shall transmit a SIGNALLING CONNECTION RELEASE REQUEST message, which includes the flow identifier of the signalling flow to be released.

## Reference

3GPP TS 25.331 clause 8.1.14

## 8.1.9.3 Test purpose

To confirm that the UE transmits a SIGNALLING CONNECTION RELEASE REQUEST message after it fails to receive a response for the LOCATION UPDATING REQUEST message.

## 8.1.9.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : Switched off

## Test Procedure

The UE is turned on and it shall find a suitable cell to camp on. The UE shall initiate a location updating procedure. The UE shall establish an RRC connection and transmits a LOCATION UPDATING REQUEST message using the INITIAL DIRECT TRANSFER message. The SS does not respond to this message, and the UE shall send a SIGNALLING CONNECTION RELEASE REQUEST message which includes the flow identifier with the same value as that in the INITIAL DIRECT TRANSFER message.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is powered on.
2	→		RRC CONNECTION REQUEST	UE shall initiate the location updating procedure.
3		←	RRC CONNECTION SETUP	
4				The UE configures the layer 2 and layer 1.
5	→		RRC CONNECTION SETUP COMPLETE	
6	→		INITIAL DIRECT TRANSFER (LOCATION UPDATING REQUEST)	LOCATION UPDATE REQUEST is embedded in this message transmission.
7				The SS does not respond and waits until the timer for location update procedure expires.
8	→		SIGNALLING CONNECTION RELEASE REQUEST	

Specific Message Content

SIGNALLING CONNECTION RELEASE REQUEST (Step 8)

Information Element	Value/remark
Flow Identifier	Check to see if this value is the as same as in the uplink INITIAL DIRECT TRANSFER message.

#### 8.1.9.5 Test requirement

After step 1 the UE shall initiate the LOCATION UPDATING procedure and establish an RRC connection.

After step 7 the UE shall transmit a SIGNALLING CONNECTION RELEASE REQUEST message which includes the same flow identifier as that found in the INITIAL DIRECT TRANSFER message.

## 8.2 Radio Bearer control procedure

### 8.2.1 Radio Bearer Establishment

#### 8.2.1.1 Radio Bearer Establishment for transition from CELL\_DCH to CELL\_DCH: Success(Data integrity protection algorithm is not applied)

##### 8.2.1.1.1 Definition

##### 8.2.1.1.2 Conformance requirement

The UE shall correctly set up a radio bearer according to a RADIO BEARER SETUP message and communicate with the UTRAN for its implementation.

(This is the case where data integrity protection algorithm is not applied.)

Reference

3GPP TS 25.331 clause 8.2.1



### 8.2.1.1.3 Test purpose

To confirm that the UE establishes a new radio bearer according to a RADIO BEARER SETUP message received from the SS.

### 8.2.1.1.4 Method of test

Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

### Test Procedure

The UE is in the CELL\_DCH state, after the test operator is prompted to make an out-going call. Before step 1, only signalling radio bearers have been established. The SS transmits a RADIO BEARER SETUP message to the UE after it sets up L1 including the start of tx/rx. This message requests the establishment of RABs for carrying the traffic of the speech call. After the UE receives this message, it configures them and establishes a radio bearer. Finally the UE transmits a RADIO BEARER SETUP COMPLETE message using AM RLC. Then the UE and the SS enters the communicating state.

### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER SETUP	This message do not contain IE "integrity check info" and "integrity protection mode info"
2		→	RADIO BEARER SETUP COMPLETE	This message do not contain "integrity check info" and "Uplink integrity activation info"
3				To confirm the communication.

### Specific Message Contents

For RADIO BEARER SETUP in step 1, using the message sub-type indicated as "Speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" found in default message content clause.

### 8.2.1.1.5 Test requirement

After step2 the UE shall communicate with the SS on the radio bearer for its implementation.

## 8.2.1.2 Radio Bearer Establishment for transition from CELL\_DCH to CELL\_DCH: Success(Effectuated Data integrity protection algorithm)

### 8.2.1.2.1 Definition

.

### 8.2.1.2.2 Conformance requirement

The UE shall correctly set up a radio bearer according to a RADIO BEARER SETUP message, which applies data integrity function, and then communicate with the UTRAN for its implementation.

### Reference

3GPP TS 25.331 clause 8.2.1, 8.5.11.

### 8.2.1.2.3 Test purpose

To confirm that the UE establishes a new radio bearer according to a RADIO BEARER SETUP message which contains IE“Integrity check info” and IE“Integrity protection mode info” received from the SS.

### 8.2.1.2.4 Method of test

Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH and data integrity algorithm is not applied

### Test Procedure

The UE is in the CELL\_DCH state, after the test operator is prompted to make an out-going data call. Before step 1, only signalling radio bearers have been established. The SS transmits a RADIO BEARER SETUP message which is including IE“integrity check info” and “integrity protection mode info” to the UE after it sets up L1 including the start of tx/rx. This message requests the establishment of RABs for carrying the traffic of the call. After the UE receives this message, it configures them and establishes a radio bearer. Finally the UE transmits a RADIO BEARER SETUP COMPLETE message which is including IE“integrity check info” using AM RLC. Then the UE and the SS enters the communicating state.

### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER SETUP	This message contain IE “integrity check info” and “integrity protection mode info”
2		→	RADIO BEARER SETUP COMPLETE	This message contain “integrity check info”
3				To confirm the communication.

### Specific Message Contents

For RADIO BEARER SETUP in step 1, using the message sub-types indicated as “Speech in CS” or “Packet to CELL\_DCH from CELL\_DCH in PS” as found in default message content clause.

### RADIO BEARER SETUP

The contents of RADIO BEARER SETUP message in this test case is identical to identical message sub-type found in TS 34.108 Clause 8, with the following exceptions:

Information Element	Value/remark
Integrity check info	Bit string (32) MAC-I See TS33.102
- Message authentication code	0
- RRC Message sequence number	Present
Integrity protection mode info	"Start"
- Integrity protection mode command	Not present ( It is needed only when the IE"Integrity protection mode command" has the value "modify" . )
- Downlink integrity protection activation info	"0001 <sub>2</sub> "; UIA1, Kasumi
- integrity protection algorithm	Bit string (32) FRESH See TS33.102
- integrity protection initialisation number	

**RADIO BEARER SETUP COMPLETE**

Information Element	Value/remark
Integrity check info	Not checked(MAC-I See TS33.102)
- Message authentication code	Not checked
- RRC Message sequence number	Not checked
Uplink Integrity protection activation info	Not checked
Hyper Frame Number	Not checked

**8.2.1.2.5 Test requirement**

After step2 the UE shall communicate with the SS on the radio bearer for its implementation. This can be verified by the correct reproduction of the u-plane data transmitted and received between the test operator and SS.

**8.2.1.3 Radio Bearer Establishment for transition from CELL\_DCH to CELL\_DCH: Failure (Unsupported or Unacceptable configuration)****8.2.1.3.1 Definition****8.2.1.3.2 Conformance requirement**

The UE shall keep its old configuration when the UE receives a RADIO BEARER SETUP message which includes unsupported configuration parameters and transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to "configuration unacceptable" in IE" failure cause".

**Reference**

3GPP TS 25.331 clause 8.2.1

**8.2.1.3.3 Test purpose**

To confirm that the UE keeps its configuration and transmits a RADIO BEARER SETUP FAILURE message in case of receiving a RADIO BEARER SETUP message which includes parameters of its unsupported configuration.

**8.2.1.3.4 Method of test****Initial Condition**

System Simulator : 1 cell

UE : CELL\_DCH

**Test Procedure**

The UE is in the CELL\_DCH state. The SS transmits a RADIO BEARER SETUP message as the frequency cannot be supported by the UE. After the UE receives this message, it transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to "configuration unacceptable" in IE" failure cause".

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER SETUP	Including the unsupported configuration for the UE.
2		→	RADIO BEARER SETUP FAILURE	The UE does not change the configuration.

Specific Message Contents

#### RADIO BEARER SETUP

The contents of RADIO BEARER SETUP message in this test case is identical to those in default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Frequency info - UARFCN uplink(Nu) - UARFCN downlink(Nd)	16383. Not Present.

#### RADIO BEARER SETUP FAILURE

Information Element	Value/remark
Message Type Failure cause Other information element	Configuration unacceptable Not checked

#### 8.2.1.3.5 Test requirement

After step1 the UE shall keep its configuration and transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to “configuration unacceptable” in IE” failure cause”.

#### 8.2.1.4 Radio Bearer Establishment for transition from CELL\_DCH to CELL\_DCH: Failure (Physical channel Failure and successful reversion to old configuration)

##### 8.2.1.4.1 Definition

##### 8.2.2.1.4.2 Conformance requirement

The UE shall revert to the old configuration when the UE fails to configure the new radio bearer by the T312 expiry and transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to “physical channel failure” in IE” failure cause”.

#### Reference

3GPP TS 25.331 clause 8.2.1

##### 8.2.1.4.3 Test purpose

To confirm that the UE reverts to the old configuration and transmits a RADIO BEARER SETUP FAILURE message when the UE fails to configure the new radio bearer following detection of physical channel failure after T312 expiry.

##### 8.2.1.4.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

### Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a RADIO BEARER SETUP message to the UE and does not configure the new radio bearer. Then after T312 expiry, the UE reverts to the old configuration and transmits a RADIO BEARER SETUP FAILURE message on the DCCCH using AM RLC which is set to “physical channel failure” in IE” failure cause”.

### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER SETUP	The SS does not configure the new radio bearer stated in the message.
2				The UE does not configure the new radio bearer and reverts to the old configuration.
3		→	RADIO BEARER SETUP FAILURE	UE shall transmit this message using the old RRC signalling bearer operating in RLC-AM mode.

### Specific Message Contents

#### RADIO BEARER SETUP FAILURE

Information Element	Value/remark
Message Type	
Failure cause	Physical channel failure
Other information element	Not checked

#### 8.2.1.4.5 Test requirement

After step2 the UE shall revert to the old configuration and transmit a RADIO BEARER SETUP FAILURE message on the DCCCH using AM RLC which is set to “physical channel failure” in IE” failure cause”.

#### 8.2.1.5 Radio Bearer Establishment for transition from CELL\_DCH to CELL\_DCH: Failure (Physical channel Failure and reversion failure)

##### 8.2.1.5.1 Definition

##### 8.2.1.5.2 Conformance requirement

The UE shall perform an RRC connection re-establishment procedure when the UE fails to revert to the old configuration after the detection of physical channel failure in the radio bearer establishment procedure.

### Reference

3GPP TS 25.331 clause 8.2.1

##### 8.2.1.5.3 Test purpose

To confirm that the UE initiates an RRC connection re-establishment procedure when the UE cannot establish the new radio bearer for the L1 configuration and cannot revert to the old configuration.

## 8.2.1.5.4 Method of test

## Initial Condition

System Simulator : 2 cells- Cell 1 is active, Cell 2 is inactive

UE : CELL\_DCH in cell No.1

## Test Procedure

The UE is in the CELL\_DCH state in cell 1. The SS begins to broadcast the BCCH in cell 2, with a power level suitable for camping but lower than that of cell 1. Next, SS transmits a RADIO BEARER SETUP message to the UE. As the SS does not configure the new radio bearer and deletes the old configuration the UE fails to configure L1 and fails to revert to the old configuration. Then the UE shall find cell 2 and transmits to it an RRC CONNECTION RE-ESTABLISHMENT REQUEST message, which includes the IE "U-RNTI" on the uplink CCCH. The SS transmits an RRC CONNECTION RE-ESTABLISHMENT message, which includes a new TFCS according to the new transport channel. After the UE receives an RRC CONNECTION RE-ESTABLISHMENT message, it reconfigures the new radio connection and transmits an RRC CONNECTION RE-ESTABLISHMENT COMPLETE message on the uplink DCCH using AM RLC.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	BCCH	The SS transmits a BCCH in cell 2 but with a lower power level than in cell 1.
2		←	RADIO BEARER SETUP	The SS does not configure the new radio bearer and delete the old configuration.
3				The UE shall detect a failure to configure the new radio bearers and also subsequently, cannot revert to old configuration.
4		→	RRC CONNECTION RE-ESTABLISHMENT REQUEST	The UE shall detect the presence of cell.2 and transmits this message which includes the IE "U-RNTI" it has been assigned to.
5		←	RRC CONNECTION RE-ESTABLISHMENT	Including the new TFCS according to the new transport channel.
6		→	RRC CONNECTION RE-ESTABLISHMENT COMPLETE	

## Specific Message Contents

None

## 8.2.1.5.5 Test requirement

After step3 the UE shall find a new cell 2, enter CELL\_FACH state, and transmit RRC CONNECTION RE-ESTABLISHMENT REQUEST message.

After step6 the UE shall re-establish an RRC connection in cell 2.

### 8.2.1.6 Radio Bearer Establishment for transition from CELL\_DCH to CELL\_DCH: Failure (Incompatible simultaneous reconfiguration)

#### 8.2.1.6.1 Definition

#### 8.2.1.6.2 Conformance requirement

The UE shall keep its old configuration when the UE receives another RADIO BEARER SETUP message before the UE configures the radio bearer according to a RADIO BEARER SETUP message and the UE shall transmit an RRC STATUS message on the DCCH using AM RLC which is set to “incompatible simultaneous reconfiguration” in IE “failure cause”.

#### Reference

3GPP TS 25.331 clause 8.2.1

#### 8.2.1.6.3 Test purpose

To confirm that the UE keeps its configuration and transmits an RRC STATUS message when the UE receives another RADIO BEARER SETUP message before the UE configures the radio bearer according to a RADIO BEARER SETUP message.

#### 8.2.1.6.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

#### Test Procedure

The UE is in the CELL\_DCH state. When the SS transmits a RADIO BEARER SETUP message to the UE before the UE configures the radio bearer the UE keeps the old configuration and transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to “incompatible simultaneous reconfiguration in IE “failure cause”.

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER SETUP	Including IE “Uplink DPCH info”
2		←	RADIO BEARER SETUP	SS send this message before the expiry of activation time specified in RADIO BEARER SETUP message of step 1.
3		→	RADIO BEARER SETUP FAILURE	The UE does not change the configuration.

#### Specific Message Contents

For RADIO BEARER SETUP in step 1, use the message sub-type indicated as “Speech in CS” found in Annex A, with the exception of the following Information Elements:

## RADIO BEARER SETUP (Step 1)

Information Element	Value/remark
Activation Time	[256+Current CFN-[current CFN mod 8 + 8 ]]MOD 256

## RADIO BEARER SETUP (Step 2)

For RADIO BEARER SETUP in step 2, use the message sub-type indicated as "Packet to CELL\_DCH from CELL\_DCH in PS" found in Annex A, with the exception of the following Information Elements:

Information Element	Value/remark
Activation Time	Not Present

## RADIO BEARER SETUP FAILURE

Information Element	Value/remark
Message Type	
Failure case	Incompatible simultaneous reconfiguration
Other information element	Not checked

## 8.2.1.6.5 Test requirement

After step2 the UE shall keep its configuration and transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to "Incompatible simultaneous reconfiguration" in IE"failure cause".

## 8.2.1.7 Radio Bearer Establishment for transition from CELL\_DCH to CELL\_DCH: Failure (Invalid message reception)

## 8.2.1.7.1 Definition

## 8.2.1.7.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a RADIO BEARER SETUP message, which includes the spare value in the mandatory IE" DRX indicator" and criticality is defined as "Reject". Then it transmits a RADIO BEARER SETUP FAILURE message which is set to "protocol error" in IE" failure cause" and is set to "Information element value not comprehended" in IE" Protocol error cause".

## Reference

3GPP TS 25.331 clause 8.2.1

## 8.2.1.7.3 Test purpose

To confirm that the UE transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC if it receives a RADIO BEARER SETUP message which indicates the spare value in the mandatory IE" DRX indicator" whose criticality is defined as "Reject".

## 8.2.1.7.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

## Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a RADIO BEARER SETUP message to the UE which indicates a spare value in the mandatory IE" DRX indicator" whose criticality is defined as "Reject". The UE keeps the old configuration and transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set



to “protocol error” in IE” failure cause”, and is set to “Information element value not comprehended” in IE” Protocol error cause”.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER SETUP	
2		→	RADIO BEARER SETUP FAILURE	The UE does not change the configuration.

Specific Message Contents

#### RADIO BEARER SETUP

The contents of RADIO BEARER SETUP message in this test case is identical to that of default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
DRX indicator	spare value

#### RADIO BEARER SETUP FAILURE

Information Element	Value/remark
Message Type	
Failure cause	
- Failure cause	Protocol error
- Protocol error information	
- Protocol error cause	Information element value not comprehended
Other information element	Not checked

#### 8.2.1.7.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to “protocol error” in IE” failure cause” and set to “Information element value not comprehended” in IE” Protocol error cause”.

#### 8.2.1.8 Radio Bearer Establishment for transition from CELL\_DCH to CELL\_FACH: Success

##### 8.2.1.8.1 Definition

##### 8.2.1.8.2 Conformance requirement

The UE shall correctly set up a radio bearer according to a RADIO BEARER SETUP message and communicate with the UTRAN for its implementation.

#### Reference

3GPP TS 25.331 clause 8.2.1

##### 8.2.1.8.3 Test purpose

To confirm that the UE establishes a new radio bearer according to a RADIO BEARER SETUP message received from the SS.

## 8.2.1.8.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

## Test Procedure

The UE is in the CELL\_DCH state, after the test operator is asked to initiate a packet-switched data call. The SS transmits a RADIO BEARER SETUP message to the UE after it sets up L1. After the UE receives this message, it configures them and establishes a radio bearer. Finally the UE transmits a RADIO BEARER SETUP COMPLETE message using AM RLC. Then the UE and the SS enters the communicating state.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER SETUP	SS requests test operator to make an outgoing packet-switched data call.
2		→	RADIO BEARER SETUP COMPLETE	
3				To confirm the communication between UE and SS, based on the exchange of packets.

## Specific Message Contents

For RADIO BEARER SETUP message in step 1, use the message sub-type indicated as “Packet to CELL\_DCH from CELL\_FACH in PS” found in default message content clause.

## 8.2.1.8.5 Test requirement

After step2 the UE shall communicate with the SS on the radio bearer for its implementation.

## 8.2.1.9 Radio Bearer Establishment for transition from CELL\_DCH to CELL\_FACH: Failure (Unsupported or Unacceptable configuration)

## 8.2.1.9.1 Definition

## 8.2.1.9.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a RADIO BEARER SETUP message, which indicates an unsupported configuration parameters and transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to “configuration unacceptable” in IE” failure cause”.

## Reference

3GPP TS 25.331 clause 8.2.1

## 8.2.1.9.3 Test purpose

To confirm that the UE keeps its configuration and transmits a RADIO BEARER SETUP FAILURE message in case of receiving a RADIO BEARER SETUP message which includes parameters of unsupported configuration.

## 8.2.1.9.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

## Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a RADIO BEARER SETUP message specifying a frequency that cannot be supported by the UE. After the UE receives this message, it transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to "configuration unacceptable" in IE" failure cause".

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER SETUP	Including the unsupported configuration for the UE.
2		→	RADIO BEARER SETUP FAILURE	The UE does not change the configuration.

## Specific Message Contents

## RADIO BEARER SETUP

The contents of RADIO BEARER SETUP message in this test case is identical to that of default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Frequency info - UARFCN uplink(Nu) - UARFCN downlink(Nd)	16384. Not present

## RADIO BEARER SETUP FAILURE

Information Element	Value/remark
Message Type Failure cause Other information element	Configuration unacceptable Not checked

## 8.2.1.9.5 Test requirement

After step1 the UE shall keep its configuration and transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC, setting value "configuration unacceptable" in IE" failure cause".

## 8.2.1.10 Radio Bearer Establishment for transition from CELL\_DCH to CELL\_FACH: Failure (Physical channel Failure)

## 8.2.1.10.1 Definition

## 8.2.1.10.2 Conformance requirement

The UE shall initiate the cell update procedure when the UE failed to access the assigned physical channel according to a RADIO BEARER SETUP message when transiting from CELL\_DCH state to CELL\_FACH state.

## Reference

3GPP TS 25.331 clause 8.2.1

## 8.2.1.10.3 Test purpose

To confirm that the UE perform a cell update procedure when the UE cannot use the assigned physical channel according to a RADIO BEARER SETUP message as it transits from CELL\_DCH to CELL\_FACH.

## 8.2.1.10.4 Method of test

## Initial Condition

System Simulator : 2 cells- Cell 1 is active, Cell 2 is inactive

UE : CELL\_DCH

## Test Procedure

The UE is in the CELL\_DCH state in cell 1. The SS begins to broadcast the BCCH in cell 2 and transmits a RADIO BEARER SETUP message as the transition occurs from CELL\_DCH to CELL\_FACH. The UE cannot access the assigned physical channel, as the SS does not transmit any data on the downlink common channel in cell 1. Then the UE shall initiate the cell update procedure in cell 2.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	BCCH	The SS broadcasts BCCH in cell No. 2.
2		←	RADIO BEARER SETUP	Assigned the transition from CELL_DCH to CELL_FACH
3				The UE cannot use the assigned the physical channel.
4		→	CELL UPDATE	The UE finds a new cell 2and begins a cell update procedure.
5		←	CELL UPDATE CONFIRM	In the CELL_FACH state

## Specific Message Contents

None

## 8.2.1.10.5 Test requirement

After step3 the UE shall find a new cell No.2 and enter to CELL\_FACH state. Then the UE shall initiate a cell update procedure in cell No.2.

## 8.2.1.11 Radio Bearer Establishment for transition from CELL\_DCH to CELL\_FACH: Failure (Incompatible simultaneous reconfiguration)

## 8.2.1.11.1 Definition

## 8.2.1.11.2 Conformance requirement

The UE shall keep its old configuration when the UE receives another RADIO BEARER SETUP message before the UE configures the radio bearer according to a RADIO BEARER SETUP message. The UE shall transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to "Incompatible simultaneous reconfiguration" in IE"failure cause".

## Reference

3GPP TS 25.331 clause 8.2.1

## 8.2.1.11.3 Test purpose

To confirm that the UE keeps its configuration and transmits a RADIO BEARER SETUP FAILURE message when the UE receives another RADIO BEARER SETUP message before the UE configures the radio bearer according to a RADIO BEARER SETUP message.

## 8.2.1.11.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

## Test Procedure

The UE is in the CELL\_DCH state. The SS sends a RADIO BEARER SETUP message to request the UE to perform radio bearer establishment procedure. Before the UE can complete the configuration of the radio bearer, the SS transmits another RADIO BEARER SETUP message. The UE shall keep the old configuration and transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to "incompatible simultaneous reconfiguration" in IE "failure cause".

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER SETUP	Message includes IE "PRACH info (for RACH)"
2		←	RADIO BEARER SETUP	Message includes the IE "Uplink DPCH info"
3		→	RADIO BEARER SETUP FAILURE	The UE does not change the configuration. UE shall not have access to the DTCH channel indicated in the RADIO BEARER SETUP messages of step 1 and step 2.

## Specific Message Contents

## RADIO BEARER SETUP (Step 1)

For this message, use the message sub-type entitled "Packet to CELL\_FACH from CELL\_DCH in PS" in the default message content. Information element(s) to be changed are listed below:

Information Element	Value/remark
Activation Time	Current CFN-[current CFN mod 8 + 8]

## RADIO BEARER SETUP (Step 2)

For this message, use the message sub-type entitled "Packet to CELL\_DCH from CELL\_DCH in PS" in the default message content. Information element(s) to be changed are listed below:

Information Element	Value/remark
Activation Time	Not Present.

#### RADIO BEARER SETUP FAILURE

Information Element	Value/remark
Message Type	
Failure cause	Incompatible simultaneous reconfiguration
Other information element	Not checked

#### 8.2.1.11.5 Test requirement

After step2 the UE shall keep its configuration and not access any of the DTCH traffic channels specified in either of the RADIO BEARER SETUP message. It shall transmit an RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to "Incompatible simultaneous reconfiguration" in IE"failure cause".

#### 8.2.1.12 Radio Bearer Establishment for transition from CELL\_DCH to CELL\_FACH: Failure (Invalid message reception)

##### 8.2.1.12.1 Definition

##### 8.2.1.12.2 Conformance requirement

The UE shall keep its old configuration when it receives a RADIO BEARER SETUP message, which includes the spare value in the mandatory IE" DRX indicator" with criticality defined as "Reject". It shall then transmit a RADIO BEARER SETUP FAILURE message which is set to "protocol error" in IE" failure cause" and also contains value "Information element value not comprehended" in IE" Protocol error cause".

#### Reference

3GPP TS 25.331 clause 8.2.1

##### 8.2.1.12.3 Test purpose

To confirm that the UE transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC if the received a RADIO BEARER SETUP message, which includes the spare value in the mandatory IE" DRX indicator" with criticality defined as "Reject".

##### 8.2.1.12.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

#### Test Procedure

The UE is in the CELL\_DCH state, after the test operator makes an outgoing packet-switched data call. The SS transmits a RADIO BEARER SETUP message to the UE which includes the spare value in the mandatory IE" DRX indicator" with criticality defined as "Reject". The UE shall keep the old configuration and transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC. The value "protocol error" shall be set in IE" failure cause" and also value "Information element value not comprehended" set in IE" Protocol error cause".

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER SETUP	SS sends this message which contains an error in the IE"DRX Indicator".
2		→	RADIO BEARER SETUP FAILURE	The UE does not change the configuration.

Specific Message Contents

#### RADIO BEARER SETUP

The contents of RADIO BEARER SETUP message in this test case is identical the message sub-type indicated by "Packet to CELL\_FACH from CELL\_DCH in PS" in the default contents clause of layer 3 messages for RRC tests. The following exceptions should be applied:

Information Element	Value/remark
DRX indicator	spare value

#### RADIO BEARER SETUP FAILURE

Information Element	Value/remark
Message Type	
Failure cause	
- Failure cause	Protocol error
- Protocol error information	
- Protocol error cause	Information element value not comprehended
Other information element	Not checked

#### 8.2.1.12.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to "protocol error" in IE" failure cause" and is set to "Information element value not comprehended" in IE" Protocol error cause".

#### 8.2.1.13 Radio Bearer Establishment for transition from CELL\_FACH to CELL\_DCH: Success

##### 8.2.1.13.1 Definition

##### 8.2.1.13.2 Conformance requirement

The UE shall correctly set up a radio bearer according to a RADIO BEARER SETUP message and communicate with the UTRAN for its implementation.

#### Reference

3GPP TS 25.331 clause 8.2.1

##### 8.2.1.13.3 Test purpose

To confirm that the UE establishes a new radio bearer according to a RADIO BEARER SETUP message received from the SS.

##### 8.2.1.13.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

### Test Procedure

The UE is in the CELL\_FACH state, after SS prompts the test operator to initiate a packet-switched data call. The SS transmits a RADIO BEARER SETUP message to the UE after it sets up L1 including the start of tx/rx. After the UE receives this message, it configures them and establishes the required radio bearers. Finally the UE transmits a RADIO BEARER SETUP COMPLETE message using AM RLC. Then the UE and the SS enters the communicating state.

### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER SETUP	
2		→	RADIO BEARER SETUP COMPLETE	
3				To confirm the communication

### Specific Message Contents

#### RADIO BEARER SETUP

The contents of RADIO BEARER SETUP message in this test case is identical the message sub-type indicated by "Packet to CELL\_DCH from CELL\_FACH in PS" in the default contents clause of layer 3 messages for RRC tests.

#### 8.2.1.13.5 Test requirement

After step2 the UE shall communicate with the SS using the radio bearer indicated in RADIO BEARER SETUP message. Particularly, SS should be able to receive packet data using a terminal equipment (TE) attached to the UE.,.

#### 8.2.1.14 Radio Bearer Establishment for transition from CELL\_FACH to CELL\_DCH: Failure (Unsupported or Unacceptable configuration)

##### 8.2.1.14.1 Definition

##### 8.2.1.14.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a RADIO BEARER SETUP message which includes an unsupported configuration and then transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC, which sets value "configuration unacceptable" in IE" failure cause".

### Reference

3GPP TS 25.331 clause 8.2.1

##### 8.2.1.14.3 Test purpose

To confirm that the UE keeps its configuration and transmits a RADIO BEARER SETUP FAILURE message in case of it receiving a RADIO BEARER SETUP message, which includes parameters of an unsupported configuration.

##### 8.2.1.14.4 Method of test

### Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH



## Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a RADIO BEARER SETUP message with a stated frequency that cannot be supported by the UE. After the UE receives this message, it shall transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC setting value “configuration unacceptable” in IE” failure cause”.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER SETUP	This message includes an unsupported configuration for the UE.
2		→	RADIO BEARER SETUP FAILURE	The UE shall transmit this message using RLC-AM mode and do not change the current configuration.

## Specific Message Contents

### RADIO BEARER SETUP

The contents of RADIO BEARER SETUP message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Frequency info - UARFCN uplink(Nu) - UARFCN downlink(Nd)	0 Not Present

### RADIO BEARER SETUP FAILURE

Information Element	Value/remark
Message Type	
Failure cause	Configuration unacceptable
Other information element	Not checked

#### 8.2.1.14.5 Test requirement

After step1 the UE shall keep its configuration and transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to “configuration unacceptable” in IE” failure cause”.

### 8.2.1.15 Radio Bearer Establishment for transition from CELL\_FACH to CELL\_DCH: Failure (Physical channel Failure and successful reversion to old configuration)

#### 8.2.1.15.1 Definition

#### 8.2.1.15.2 Conformance requirement

The UE shall attempt to revert to the old configuration when the UE fails to configure the new radio bearer by the T312 expiry. It shall transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC containing value “physical channel failure” in IE” failure cause”.

## Reference

3GPP TS 25.331 clause 8.2.1

## 8.2.1.15.3 Test purpose

To confirm that the UE reverts to the old configuration and transmits a RADIO BEARER SETUP FAILURE message when the UE fails to configure the new radio bearer when it detects physical channel failure, followed by the T312 expiry.

## 8.2.1.15.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

## Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a RADIO BEARER SETUP message to the UE and does not configure the new radio bearer. After T312 expiry, the UE shall revert to the old configuration and transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC. The content of the message shall indicate “physical channel failure” in IE” failure cause”.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER SETUP	The SS does not configure a new radio bearer.
2				The UE does not configure a new radio bearer but reverts to the old configuration.
3		→	RADIO BEARER SETUP FAILURE	

## Specific Message Contents

## RADIO BEARER SETUP FAILURE

Information Element	Value/remark
Message Type	
Failure cause	Physical channel failure
Other information element	Not checked

## 8.2.1.15.5 Test requirement

After step2 the UE shall revert to the old configuration and transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to “physical channel failure” in IE” failure cause”.

## 8.2.1.16 Radio Bearer Establishment for transition from CELL\_FACH to CELL\_DCH: Failure (Physical channel Failure and reversion failure)

## 8.2.1.16.1 Definition

## 8.2.1.16.2 Conformance requirement

The UE shall perform an RRC connection re-establishment procedure when the UE fails to revert to the old configuration after the detection of physical channel failure in the radio bearer establishment procedure.

## Reference

3GPP TS 25.331 clause 8.2.1

## 8.2.1.16.3 Test purpose

To confirm that the UE initiates an RRC connection re-establishment procedure when the UE cannot establish the new radio bearer for the L1 configuration and subsequently fail to revert to the old configuration.

## 8.2.1.16.4 Method of test

## Initial Condition

System Simulator : 2 cells- Cell 1 is active, Cell 2 is inactive

UE : CELL\_FACH in cell 1

## Test Procedure

The UE is in the CELL\_FACH state in cell 1. The SS begins to broadcast the BCCH in cell 2 but with a transmission level lower than that for cell 1. It then transmits a RADIO BEARER SETUP message to the UE from cell 1. Then the SS deletes the old downlink channel configuration after sending this message. This causes the UE to fail to configure L1 and could not revert to the old configuration. The UE shall find the presence of cell 2 and transmits an RRC CONNECTION RE-ESTABLISHMENT REQUEST message. The message shall include the IE "U-RNTI" and sent on the uplink CCCH. The SS responds with an RRC CONNECTION RE-ESTABLISHMENT message, which includes a new TFCS according to the new transport channel. After the UE receives an RRC CONNECTION RE-ESTABLISHMENT message, it reconfigures the new radio connection and transmits an RRC CONNECTION RE-ESTABLISHMENT COMPLETE message on the uplink DCCH using AM RLC.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	BCCH	The SS transmits the BCCH in cell 2, but with a power level lower than that in cell 1.
2		←	RADIO BEARER SETUP	The SS does not configure the new radio bearer and instead delete the old configuration.
3				The UE cannot configure a new radio bearer and cannot revert to old configuration.
4		→	RRC CONNECTION RE-ESTABLISHMENT REQUEST	The UE shall find the presence of cell 2. It shall then transmit this message including its assigned U-RNTI in the IE "U-RNTI".
5		←	RRC CONNECTION RE-ESTABLISHMENT	Including the new TFCS according to the new transport channel.
6		→	RRC CONNECTION RE-ESTABLISHMENT COMPLETE	

## Specific Message Contents

**RADIO BEARER SETUP** The contents of RADIO BEARER SETUP message in this test case is identical to the message sub-type "Packet to CELL\_DCH from CELL\_FACH in PS" found in the default contents of layer 3 messages for RRC tests.

## RRC CONNECTION RE-ESTABLISHMENT REQUEST

Information Element	Value/remark
U-RNTI	Set to assigned UE U-RNTI in RRC CONNECTION SETUP message.
Protocol error indication	FALSE

## RRC CONNECTION RE-ESTABLISHMENT COMPLETE

Information Element	Value/remark
Radio bearer uplink ciphering activation time info	Not Present
RB with PDCP information list - RB with PDCP information list	Not Present

## 8.2.1.16.5 Test requirement

After step3 the UE shall find the presence of cell 2, which is suitable for camping. It shall then enter CELL\_FACH state and transmit a RRC CONNECTION RE-ESTABLISHMENT REQUEST message to prevent the RRC connection from being lost.

After step6 the UE shall re-establish an RRC connection, using the new TFCS settings specified in RRC CONNECTION RE-ESTABLISHMENT message

## 8.2.1.17 Radio Bearer Establishment for transition from CELL\_FACH to CELL\_DCH: Failure (Incompatible simultaneous reconfiguration)

## 8.2.1.17.1 Definition

## 8.2.1.17.2 Conformance requirement

The UE shall keep its old configuration, when it receives another RADIO BEARER SETUP message before it can complete the configuration of the radio bearer according to the first RADIO BEARER SETUP message. The UE shall transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC with value "Incompatible simultaneous reconfiguration" set in IE"failure cause".

## Reference

3GPP TS 25.331 clause 8.2.1

## 8.2.1.17.3 Test purpose

To confirm that the UE keeps its configuration and transmits a RADIO BEARER SETUP FAILURE message when the UE receives another RADIO BEARER SETUP message, before the UE configures the radio bearer according to an earlier RADIO BEARER SETUP message.

## 8.2.1.17.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

## Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a RADIO BEARER SETUP message, requesting the UE to setup radio bearers using DPCH physical channels. The activation time of this event is specified to be 255 frames from the SS's current CFN. However, SS sends another RADIO BEARER SETUP message before 255 frames has passed. The UE shall then abandon its current reconfiguration operation, keep the old configuration, and transmit a RADIO

BEARER SETUP FAILURE message on the DCCH using AM RLC. This message shall contain the value "Incompatible simultaneous reconfiguration" in IE "failure cause".

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER SETUP	Including IE "Uplink DPCH info"
2		←	RADIO BEARER SETUP	
3		→	RADIO BEARER SETUP FAILURE	The UE does not change the configuration and transmit this message on its uplink DCCH using the same RLC-AM mode radio bearer before step 1.

Specific Message Contents

RADIO BEARER SETUP (for Step 2)

For this message, use the message sub-type entitled "Packet to CELL\_DCH from CELL\_FACH in PS" in the default message content. Information element(s) to be changed are listed below:

Information Element	Value/remark
Activation Time	Current CFN-[current CFN mod 8 + 8]

RADIO BEARER SETUP FAILURE

Information Element	Value/remark
Message Type	
Failure cause	Incompatible simultaneous reconfiguration
Other information element	Not checked

8.2.1.17.5 Test requirement

After step2 the UE shall keep its configuration and transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to "Incompatible simultaneous reconfiguration" in IE "failure cause".

8.2.1.18 Radio Bearer Establishment for transition from CELL\_FACH to CELL\_DCH: Failure (Invalid message reception)

8.2.1.18.1 Definition

8.2.1.18.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a RADIO BEARER SETUP message, which includes the spare value in the mandatory IE "DRX indicator" having criticality defined as "Reject". It shall transmit a RADIO BEARER SETUP FAILURE message which set value "protocol error" in IE "failure cause" and also value "Information element value not comprehended" in IE "Protocol error cause".

Reference

3GPP TS 25.331 clause 8.2.1

8.2.1.18.3 Test purpose

To confirm that the UE transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC if it receives a RADIO BEARER SETUP message, with a spare value in the mandatory IE "DRX indicator" and having criticality defined as "Reject".

## 8.2.118.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

## Test Procedure

The UE is in CELL\_FACH state. The SS transmits a RADIO BEARER SETUP message to the UE which includes a spare value in the mandatory IE" DRX indicator" with criticality defined as "Reject". The UE keeps the old configuration and transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC. This message shall specify "protocol error" in IE" failure cause" and also set the value "Information element value not comprehended" in IE" Protocol error cause".

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER SETUP	
2		→	RADIO BEARER SETUP FAILURE	The UE does not change the configuration.

## Specific Message Contents

## RADIO BEARER SETUP

The contents of RADIO BEARER SETUP message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
DRX indicator	spare value

## RADIO BEARER SETUP FAILURE

Information Element	Value/remark
Message Type	
Failure cause	
- Failure cause	Protocol error
- Protocol error information	
- Protocol error cause	Information element value not comprehended
Other information element	Not checked

## 8.2.1.18.5 Test requirement

After step1 the UE shall keep its old configuration and transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC. The message shall indicate the reason of failure as "protocol error" in IE" failure cause" and set the value "Information element value not comprehended" in IE" Protocol error cause".

## 8.2.1.19 Radio Bearer Establishment for transition from CELL\_FACH to CELL\_FACH: Success

## 8.2.1.19.1 Definition

## 8.2.1.19.2 Conformance requirement

The UE shall correctly set up a radio bearer according to a RADIO BEARER SETUP message and communicate with the UTRAN for its implementation.

## Reference

3GPP TS 25.331 clause 8.2.1

## 8.2.1.19.3 Test purpose

To confirm that the UE establishes a new radio bearer according to a RADIO BEARER SETUP message received from the SS.

## 8.2.1.19.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

## Test Procedure

The UE is in the CELL\_FACH state, after the test operator is being prompted to make an outgoing packet-switched call. The SS transmits a RADIO BEARER SETUP message to the UE after it sets up L1 including the start of tx/rx. After the UE receives this message, it configures them and establishes a radio bearer. Finally the UE transmits a RADIO BEARER SETUP COMPLETE message using AM RLC. Then the UE and the SS enters the communicating state.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER SETUP	
2		→	RADIO BEARER SETUP COMPLETE	
3				To confirm the proper establishment of the new radio bearer by checking the packet data exchanged between the SS and a TE attached to the UE.

## Specific Message Contents

## RADIO BEARER SETUP

For this message, use the message sub-type entitled "Packet to CELL\_FACH from CELL\_FACH in PS" in the default message content.

## 8.2.1.19.5 Test requirement

After step2 the UE shall communicate with the SS using the new radio bearer , this can be confirmed by the exchange of packet data between a terminal equipment (TE) attached to the UE and the SS,

## 8.2.1.20 Radio Bearer Establishment for transition from CELL\_FACH to CELL\_FACH: Failure (Unsupported or Unacceptable configuration)

## 8.2.1.20.1 Definition

## 8.2.1.20.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a RADIO BEARER SETUP message which includes an unsupported configuration and it shall transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC setting the value "configuration unacceptable" into IE" failure cause".

## Reference

3GPP TS 25.331 clause 8.2.1

## 8.2.1.20.3 Test purpose

To confirm that the UE keeps its original configuration and transmits a RADIO BEARER SETUP FAILURE message when it receives a RADIO BEARER SETUP message indicating an unsupported configuration.

## 8.2.1.20.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

## Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a RADIO BEARER SETUP message specifying a frequency which is not supported by the UE. After the UE receives this message, it transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to “configuration unacceptable” in IE” failure cause”.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER SETUP	Including the unsupported configuration for the UE.
2		→	RADIO BEARER SETUP FAILURE	The UE does not change the configuration.

## Specific Message Contents

## RADIO BEARER SETUP

The contents of RADIO BEARER SETUP message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Frequency info - UARFCN uplink(Nu) - UARFCN downlink(Nd)	63947 Not present

## RADIO BEARER SETUP FAILURE

Information Element	Value/remark
Message Type Failure cause Other information element	Configuration unacceptable Not checked

## 8.2.1.20.5 Test requirement

After step1 the UE shall keep its configuration and transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC and set value “configuration unacceptable” in IE” failure cause”.

## 8.2.1.21 Radio Bearer Establishment for transition from CELL\_FACH to CELL\_FACH: Failure (Incompatible simultaneous reconfiguration)

## 8.2.1.21.1 Definition



## 8.2.121.2 Conformance requirement

The UE shall keep its old configuration when the UE receives another RADIO BEARER SETUP message before the UE configures the radio bearer according to a RADIO BEARER SETUP message and the UE shall transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to “Incompatible simultaneous reconfiguration” in IE “failure cause”.

## Reference

3GPP TS 25.331 clause 8.2.1

## 8.2.1.21.3 Test purpose

To confirm that the UE keeps its configuration and transmits a RADIO BEARER SETUP FAILURE message when the UE receives another RADIO BEARER SETUP message before the UE configures the radio bearer according to a RADIO BEARER SETUP message.

## 8.2.1.21.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

## Test Procedure

The UE is in the CELL\_FACH state. When the SS transmits a RADIO BEARER SETUP message to the UE before the UE configures the radio bearer the UE keeps the old configuration and transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to “Incompatible simultaneous reconfiguration” in IE “failure cause”.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER SETUP	Including IE “Uplink DPCH info”
2		←	RADIO BEARER SETUP	
3		→	RADIO BEARER SETUP FAILURE	The UE does not change the configuration.

## Specific Message Contents

## RADIO BEARER SETUP FAILURE

Information Element	Value/remark
Message Type	
Failure cause	Incompatible simultaneous reconfiguration
Other information element	Not checked

## 8.2.1.21.5 Test requirement

After step2 the UE shall keep its configuration and transmit an RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to “Incompatible simultaneous reconfiguration” in IE “failure cause”.

## 8.2.1.22 Radio Bearer Establishment for transition from CELL\_FACH to CELL\_FACH: Failure (Invalid message reception)

## 8.2.1.22.1 Definition

## 8.2.1.22.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a RADIO BEARER SETUP message, which includes a spare value for the mandatory IE "DRX indicator" having criticality defined as "Reject". It shall then transmit a RADIO BEARER SETUP FAILURE message stating the reason "protocol error" in IE "failure cause" and also set value "Information element value not comprehended" in IE "Protocol error cause".

## Reference

3GPP TS 25.331 clause 8.2.1

## 8.2.1.22.3 Test purpose

To confirm that the UE transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC if it receives a RADIO BEARER SETUP message specifying a spare value in the mandatory IE "DRX indicator"

## 8.2.1.22.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

## Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a RADIO BEARER SETUP message to the UE and includes the spare value in the mandatory IE "DRX indicator". The UE shall keep the old configuration and transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC, setting the value "protocol error" in IE "failure cause". The error type "Information element value not comprehended" shall also be indicated in IE "Protocol error cause".

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER SETUP	
2		→	RADIO BEARER SETUP FAILURE	The UE does not change the configuration.

## Specific Message Contents

## RADIO BEARER SETUP

The contents of RADIO BEARER SETUP message in this test case is identical to the message sub-type "Packet to CELL\_FACH from CELL\_FACH in PS", which is found in the default contents clause of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
DRX indicator	spare value

## RADIO BEARER SETUP FAILURE

The expected content of RADIO BEARER SETUP FAILURE message is shown below:

Information Element	Value/remark
Message Type	
Failure cause	
- Failure cause	Protocol error
- Protocol error information	
- Protocol error cause	Information element value not comprehended
Other information element	Not checked

#### 8.2.1.22.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC setting “protocol error” in IE” failure cause” and setting “Information element value not comprehended” in IE” Protocol error cause”.

## 8.2.2 Radio Bearer Reconfiguration

### 8.2.2.1 Radio Bearer Reconfiguration ( Hard handover ) from CELL\_DCH to CELL\_DCH: Success

#### 8.2.2.1.1 Definition

#### 8.2.2.1.2 Conformance requirement

The UE shall correctly reconfigure a radio bearer and L1 according to the RADIO BEARER RECONFIGURATION message, which specifies a hard handover to another radio frequency. After executing the reconfiguration, the UE shall be able to communicate with the UTRAN on the newly configured radio bearer.

#### Reference

3GPP TS 25.331 clause 8.2.2

#### 8.2.2.1.3 Test purpose

To confirm that the UE reconfigures a new radio bearer by following a RADIO BEARER RECONFIGURATION message, which indicates a hard handover to another radio frequency.

#### 8.2.2.1.4 Method of test

#### Initial Condition

System Simulator : 2 cells – cell 1 and cell 6 are active. The CPICH<sub>Ec/No</sub> and CPICH RSCP of cell 4 are improved to –15dB and –70dBm respectively. The  $Q_{rxlevmin}$  and  $Q_{rxqualmin}$  values in SYSTEM INFORMATION BLOCK TYPE 3 and 4 messages of cell 6 is changed to –90dBm and –20dB respectively

UE : CELL\_DCH in cell 1

#### Test Procedure

The UE is in the CELL\_DCH state in cell 1. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE, which commands that hard handover to cell 6 be performed.. The UE reconfigures the new physical channel parameters and transmits a RADIO BEARER RECONFIGURATION COMPLETE message using AM RLC.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RECONFIGURATION	Hard handover to cell 6,
2				UE shall suspend all uplink transmissions to cell 1 and shall commence the reconfiguration of the affected physical channel parameters to that of cell 6.
3		→	RADIO BEARER RECONFIGURATION COMPLETE	

Specific Message Contents

#### RADIO BEARER RECONFIGURATION

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to the message sub-type titled "Packet to CELL\_DCH from CELL\_DCH in PS" in Annex A, with the following exceptions:

Information Element	Value/remark
Frequency info - UARFCN uplink(Nu) - UARFCN downlink(Nd)	Same uplink UARFCN as used for cell 6 Same downlink UARFCN as used for cell 6
Downlink information for each radio links - Primary CPICH info - Primary Scrambling Code	Same downlink UARFCN as used for cell 6 350

#### 8.2.2.1.5 Test requirement

After step1 the UE shall reconfigure the radio links with the SS.

After step3 the UE shall change its physical channel configuration and communicate with the SS on the DCCH and DTCH of cell 6.

#### 8.2.2.2 Radio Bearer Reconfiguration from CELL\_DCH to CELL\_DCH: Failure (Unsupported or Unacceptable configuration)

##### 8.2.2.2.1 Definition

##### 8.2.2.2.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a RADIO BEARER RECONFIGURATION message which includes unsupported configuration parameters and transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "configuration unacceptable" in IE" failure cause

#### Reference

3GPP TS 25.331 clause 8.2.2

##### 8.2.2.2.3 Test purpose

To confirm that the UE transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC if the received RADIO BEARER RECONFIGURATION message includes unsupported configuration parameters.

## 8.2.2.2.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

## Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE, which includes unsupported configuration parameters for the UE. The UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to “configuration unacceptable” in IE” failure cause”.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RECONFIGURATION	Including unsupported configuration by the UE
2		→	RADIO BEARER RECONFIGURATION FAILURE	The UE does not change the radio bearer.

## Specific Message Contents

## RADIO BEARER RECONFIGURATION

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to those in the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Frequency info - UARFCN uplink(Nu) - UARFCN downlink(Nd)	63984. Not Present

## RADIO BEARER RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type Failure cause Other information element	“RADIO BEARER RECONFIGURATION FAILURE” Configuration unacceptable Not checked

## 8.2.2.2.5 Test requirement

After step2 the UE shall keep its old configuration and transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC with the value “configuration unacceptable” set in IE” failure cause”.

## 8.2.2.3 Radio Bearer Reconfiguration from CELL\_DCH to CELL\_DCH: Failure (Physical channel failure and reversion to old configuration)

## 8.2.2.3.1 Definition

## 8.2.2.3.2 Conformance requirement

The UE shall revert to the old configuration when the UE fails to reconfigure the new physical channel by received RADIO BEARER RECONFIGURATION message and transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to “physical channel failure” in IE” failure cause”.

## Reference

3GPP TS 25.331 clause 8.2.2

## 8.2.2.3.3 Test purpose

To confirm that the UE reverts to the old configuration and transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC if the UE fails to reconfigure the new radio bearer according to the RADIO BEARER RECONFIGURATION message received previously.

## 8.2.2.3.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

## Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE which includes the new radio bearer parameters but it does not reconfigure L1 according to the settings found in the message. The UE shall revert to the old configuration. Then the UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting value “.physical channel failure” in IE” failure cause”.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RECONFIGURATION	
2				SS does not reconfigure L1 parameters to reflect the radio bearer reconfigurations specified in the message.
3		→	RADIO BEARER RECONFIGURATION FAILURE	The UE shall detect a failure to reconfigure the new radio bearer, and send this message using the old radio bearer configuration.

## Specific Message Contents

## RADIO BEARER RECONFIGURATION

## RADIO BEARER RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	“RADIO BEARER RECONFIGURATION FAILURE”
Failure cause	Physical channel failure
Other information element	Not checked

## 8.2.2.3.5 Test requirement

After step2 the UE shall revert to the old configuration and transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC setting value “.physical channel failure” in IE” failure cause”.

#### 8.2.2.4 Radio Bearer Reconfiguration from CELL\_DCH to CELL\_DCH : Failure (Physical channel failure and reversion failure)

##### 8.2.2.4.1 Definition

##### 8.2.2.4.2 Conformance requirement

The UE shall perform an RRC connection re-establishment procedure when the UE fails to revert to the old configuration after the detection of physical channel failure in the radio bearer reconfiguration procedure.

##### Reference

3GPP TS 25.331 clause 8.2.2

##### 8.2.2.4.3 Test purpose

To confirm that the UE initiates an RRC connection re-establishment procedure when the UE cannot reconfigure the new radio bearer, and a subsequent failure to revert to the old configuration.

##### 8.2.2.4.4 Method of test

##### Initial Condition

System Simulator : 2 cells - Cell 1 is active, Cell 2 is inactive

UE : CELL\_DCH in cell 1

##### Test Procedure

The UE is in the CELL\_DCH state in a cell 1. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE, which includes the new radio bearer parameters. The SS does not reconfigure L1 in accordance to the settings in the message and delete all radio bearer related contexts in cell 1. At the same time, SS begins to broadcast the BCCH in a cell 2. The UE discovers that it cannot reconfigure the new radio bearer and wants to revert to the old configuration. The UE shall find cell 2 and transmit to it an RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE "U-RNTI" on the uplink CCCH. The SS transmits an RRC CONNECTION RE-ESTABLISHMENT message which specifies a new TFCS according to the new transport channel allocated. After the UE receives an RRC CONNECTION RE-ESTABLISHMENT message, it reconfigures the new radio connection and transmits an RRC CONNECTION RE-ESTABLISHMENT COMPLETE message on the uplink DCCH using AM RLC.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RECONFIGURATION	
2				The SS does not reconfigure the new radio bearer and delete the old configuration in cell 1.
3				The UE fails to reconfigure a new radio bearer.
4		←	BCCH	The SS transmits a BCCH in a cell 2 and delete the old radio bearer.
5		→	RRC CONNECTION RE-ESTABLISHMENT REQUEST	The UE finds cell.2and transmits this message which includes the IE"U-RNTI" it was previously assigned.
6		←	RRC CONNECTION RE-ESTABLISHMENT	This message includes a new TFCS according to the new transport channel indicated in RRC CONNECTION RE-ESTABLISHMENT message.
7		→	RRC CONNECTION RE-ESTABLISHMENT COMPLETE	

Specific Message Contents

None

#### 8.2.2.4.5 Test requirement

After step4 the UE shall detect the presence of cell.2, enters CELL\_FACH state, and transmit RRC CONNECTION RE-ESTABLISHMENT to attempt to keep the current RRC connection.

After step7 the UE shall successfully re-establish an RRC connection.

#### 8.2.2.5 Radio Bearer Reconfiguration from CELL\_DCH to CELL\_DCH: Failure (Incompatible simultaneous reconfiguration)

##### 8.2.2.5.1 Definition

##### 8.2.2.5.2 Conformance requirement

The UE shall keep its old configuration when the UE receives another RADIO BEARER RECONFIGURATION message before the UE can configure the radio bearer according to an earlier RADIO BEARER RECONFIGURATION message. The UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC setting "Incompatible simultaneous reconfiguration" in IE"failure cause".

#### Reference

3GPP TS 25.331 clause 8.2.2

##### 8.2.2.5.3 Test purpose

To confirm that the UE keeps its configuration and transmits an RADIO BEARER RECONFIGURATION FAILURE message when the UE receives another RADIO BEARER RECONFIGURATION message before the UE can complete the configuration of the radio bearer indicated in an earlier RADIO BEARER RECONFIGURATION message.



## 8.2.2.5.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

## Test Procedure

The UE is in the CELL\_DCH state. When the SS transmits a RADIO BEARER RECONFIGURATION message to the UE before the UE configures the requested radio bearer(s), the UE keeps the old configuration and transmits an RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC. This message shall set value "Incompatible simultaneous reconfiguration" in IE "failure cause".

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RECONFIGURATION	Including IE "Uplink DPCH info"
2		←	RADIO BEARER RECONFIGURATION	Sent before the "activation time" in step 1 has elapsed
3		→	RADIO BEARER RECONFIGURATION FAILURE	The UE does not change the configuration.

## Specific Message Contents

## RADIO BEARER RECONFIGURATION (Step 1)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to those in the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Activation Time	Current CFN-[current CFN mod 8 + 8 ]

## RADIO BEARER RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	"RADIO BEARER RECONFIGURATION FAILURE"
Failure cause	Incompatible simultaneous reconfiguration
Other information element	Not checked

## 8.2.2.5.5 Test requirement

After step2 the UE shall keep its configuration and transmit an RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which contains the value "Incompatible simultaneous reconfiguration" set in IE "failure cause".

## 8.2.2.6 Radio Bearer Reconfiguration from CELL\_DCH to CELL\_DCH: Failure (Invalid message reception)

## 8.2.2.6.1 Definition

## 8.2.2.6.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a RADIO BEARER RECONFIGURATION message, which includes the spare value in the mandatory IE "DRX indicator" having criticality defined as "Reject". The UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message which is set to "protocol error" in IE "failure cause" and is set to "Information element value not comprehended" in IE "Protocol error cause".

## Reference

3GPP TS 25.331 clause 8.2.2

## 8.2.2.6.3 Test purpose

To confirm that the UE transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC, if it receives a RADIO BEARER RECONFIGURATION message containing a spare value in the mandatory IE" DRX indicator" with criticality defined as "Reject".

## 8.2.2.6.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

## Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE which includes the spare value in the mandatory IE" DRX indicator" which criticality is defined as "Reject". The UE keeps the old configuration and transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "protocol error" in IE" failure cause" and is set to "Information element value not comprehended" in IE" Protocol error cause".

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RECONFIGURATION	The message contains a illegal error in a mandatory IE.
2		→	RADIO BEARER RECONFIGURATION FAILURE	The UE does not change the configuration.

## Specific Message Contents

## RADIO BEARER RECONFIGURATION

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to the corresponding message found in the default contents of layer 3 messages for RRC tests, with the following exceptions:

Information Element	Value/remark
DRX indicator	spare value

## RADIO BEARER RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	"RADIO BEARER RECONFIGURATION FAILURE"
Failure cause	
- Failure cause	Protocol error
- Protocol error information	
- Protocol error cause	Information element value not comprehended
Other information element	Not checked

## 8.2.2.6.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC stating the reason "protocol error" in IE" failure cause". The message shall contain the value "Information element value not comprehended" in IE" Protocol error cause".

### 8.2.2.7 Radio Bearer Reconfiguration from CELL\_DCH to CELL\_DCH :Failure (Suspension of signalling bearer)

#### 8.2.2.7.1 Definition

#### 8.2.2.7.2 Conformance requirement

The UE shall revert to the old configuration prior to the reception of RADIO BEARER RECONFIGURATION message, which includes IE "RBSuspend/resume" specified as "Suspend", and transmit a RADIO BEARER RECONFIGURATION FAILURE message to UTRAN

#### Reference

3GPP TS 25.331 clause 8.2.2

#### 8.2.2.7.3 Test purpose

To confirm that the UE reverts to the old configuration and transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC if the UE fails to reconfigure the new radio bearer according to a RADIO BEARER RECONFIGURATION message.

#### 8.2.2.7.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

#### Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE which specifies the suspension of a signalling radio bearer to be reconfigured. The UE shall revert to the old configuration. Then the UE transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC with the IE "failure cause" set to "configuration unacceptable".

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RECONFIGURATION	Specifies a signalling radio bearer to be suspended.
2		→	RADIO BEARER RECONFIGURATION FAILURE	The UE shall revert to the old configuration

#### Specific Message Contents

#### RADIO BEARER RECONFIGURATION

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
RB information to reconfigure list RB information to reconfigure I -RB identity -RB suspend/resume	3 "Suspend"

#### RADIO BEARER RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type Failure cause Other information element	"RADIO BEARER RECONFIGURATION FAILURE" Configuration unacceptable Not checked

#### 8.2.2.7.5 Test requirement

After step2 the UE shall revert to the old configuration and transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC specifying the reason "configuration unacceptable" in IE" failure cause".

### 8.2.2.8 Radio Bearer Reconfiguration from CELL\_DCH to CELL\_FACH: Success

#### 8.2.2.8.1 Definition

#### 8.2.2.8.2 Conformance requirement

The UE shall correctly reconfigure a radio bearer according to a RADIO BEARER RECONFIGURATION message which is communicate with the UTRAN on the new radio bearer in case of a transition from CELL\_DCH to CELL\_FACH in the same cell.

#### Reference

3GPP TS 25.331 clause 8.2.2

#### 8.2.2.8.3 Test purpose

To confirm that the UE establishes the reconfigured radio bearer(s) using common physical channel, after a RADIO BEARER RECONFIGURATION message has been received from the SS.

#### 8.2.2.8.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

#### Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE, which includes the new radio bearer parameters and sets up L1 including the start of tx/rx. The UE reconfigures the new radio bearer and transmits a RADIO BEARER RECONFIGURATION COMPLETE message using AM RLC.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RECONFIGURATION	
2				Reconfiguration of radio bearer
3		→	RADIO BEARER RECONFIGURATION COMPLETE	

Specific Message Contents

RADIO BEARER RECONFIGURATION (Step 1)

Use the same message sub-type titled "Packet to CELL\_DCH from CELL\_FACH in PS" in Annex A.

#### 8.2.2.8.5 Test requirement

After step1 the UE shall reconfigure the radio links with the SS.

After step3 the UE shall change its radio bearer configuration and communicate with the SS on the DCCH and DTCH, using the common physical channel allocated in RADIO BEARER RECONFIGURATION message.

#### 8.2.2.9 Radio Bearer Reconfiguration from CELL\_DCH to CELL\_FACH: Failure (Unsupported or Unacceptable configuration)

##### 8.2.2.9.1 Definition

##### 8.2.2.9.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a RADIO BEARER RECONFIGURATION message which includes unsupported configuration parameters and transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "configuration unacceptable" in IE" failure cause

Reference

3GPP TS 25.331 clause 8.2.2

##### 8.2.2.9.3 Test purpose

To confirm that the UE transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC if the received RADIO BEARER RECONFIGURATION message indicates an unsupported configuration parameters.

##### 8.2.2.9.4 Method of test

Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE, which includes unsupported configuration parameters for the UE. The UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "configuration unacceptable" in IE" failure cause".

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RECONFIGURATION	Including unsupported configuration by the UE
2		→	RADIO BEARER RECONFIGURATION FAILURE	The UE does not change the radio bearer.

Specific Message Contents

#### RADIO BEARER RECONFIGURATION

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to the corresponding message found in the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Frequency info - UARFCN uplink(Nu) - UARFCN downlink(Nd)	63984. Not Present

#### RADIO BEARER RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type Failure cause Other information element	"RADIO BEARER RECONFIGURATION FAILURE" Configuration unacceptable Not checked

##### 8.2.2.9.5 Test requirement

After step2 the UE shall keep its old configuration and transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC, stating the reason "configuration unacceptable" in IE" failure cause".

#### 8.2.2.10 Radio Bearer Reconfiguration from CELL\_DCH to CELL\_FACH: Failure (Physical channel failure )

##### 8.2.2.10.1 Definition

##### 8.2.2.10.2 Conformance requirement

The UE shall initiate the cell reselection procedure when the UE cannot use the assigned physical channel according to a RADIO BEARER CHANNEL RECONFIGURATION message, during the transition from CELL\_DCH to CELL\_FACH.

#### Reference

3GPP TS 25.331 clause 8.2.2

##### 8.2.2.10.3 Test purpose

To confirm that the UE initiate a cell reselection after encountering a physical channel failure, when attempting to transit from CELL\_DCH to CELL\_FACH state during the execution of radio bearer reconfiguration procedure. The UE is first instructed to select the cell implied in the RADIO BEARER RECONFIGURATION message, but discover a failure as the indicated cell is not present.

##### 8.2.2.10.4 Method of test

#### Initial Condition

System Simulator : 2 cells – Cell 1 is active and cell 2 is inactive

UE : CELL\_DCH

### Test Procedure

The UE is in the CELL\_DCH state. SS starts to transmit the BCCH for cell 2, but with a power level lower than that of cell 1. Following this, the SS send a RADIO BEARER RECONFIGURATION message to the UE, which includes relevant information about the target cell's P-CPICH. SS selects an unused primary scrambling code for P-CPICH, which neither matches the code used by cell 1 nor cell 2. This should lead to the detection of a physical channel failure in the UE. The UE shall trigger a cell reselection and initiate a cell update procedure if it is able to access cell 2. When SS receives a CELL UPDATE message in cell 2 on uplink CCCH, it replies with CELL UPDATE CONFIRM message.

### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				SS begin to broadcast the BCCH data in cell 2, but with a power level lower than in cell 1.
2		←	RADIO BEARER RECONFIGURATION	The message includes IE "Primary CPICH Info" and set the IE "Primary Scrambling Code" to an unknown value (not used by cell 1 or cell 2).
3				UE shall detect a "physical channel failure" condition and then trigger a cell reselection procedure.
4		→	CELL UPDATE	After successfully camping onto cell 2, UE shall initiate a cell update procedure. The updating cause shall be set to "cell reselection"
5		←	CELL UPDATE CONFIRM	Contains cell

### Specific Message Contents

#### RADIO BEARER RECONFIGURATION

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Downlink information for each radio link - Primary CPICH Info - Primary Scrambling Code	Set to an unused code different from the 3 cells defined.

#### CELL UPDATE

Information Element	Value/remark
U-RNTI	The assigned U-RNTI indicated in RRC CONNECTION SETUP message
Cell Update Cause	Cell Reselection

#### 8.2.2.10.5 Test requirement

After step3, the UE shall discover the presence of cell 2, enter CELL\_FACH and then perform a cell updating procedure by the transmission of CELL UPDATE using RLC-TM mode on CCCH. The UE shall transit to CELL\_PCH state to monitor the PCCH channel after the reception of CELL UPDATE CONFIRM message.

### 8.2.2.11 Radio Bearer Reconfigure from CELL\_DCH to CELL\_FACH: Failure (Incompatible simultaneous reconfiguration)

#### 8.2.2.11.1 Definition

#### 8.2.2.11.2 Conformance requirement

The UE shall keep its old configuration when the UE receives another RADIO BEARER RECONFIGURATION message before it completes the re-configuring the radio bearer according to an earlier RADIO BEARER RECONFIGURATION message. The UE shall transmit an RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting “incompatible simultaneous reconfiguration” in IE”failure cause”.

#### Reference

3GPP TS 25.331 clause 8.2.2

#### 8.2.2.11.3 Test purpose

To confirm that the UE keeps its current radio bearer configurations and transmits an RADIO BEARER RECONFIGURATION FAILURE message when the UE receives another RADIO BEARER RECONFIGURATION message before it is able to complete an earlier reconfiguration request.

#### 8.2.2.11.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

#### Test Procedure

The UE is in the CELL\_DCH state. When the SS transmits a RADIO BEARER RECONFIGURATION message to the UE before the UE configures the radio bearer the UE keeps the old configuration and transmits an RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to “incompatible simultaneous reconfiguration” in IE”failure cause”.

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RECONFIGURATION	Including IE”Uplink DPCH info”
2		←	RADIO BEARER RECONFIGURATION	
3		→	RADIO BEARER RECONFIGURATION FAILURE	The UE does not change the configuration.

#### Specific Message Contents

The contents of RADIO BEARER RECONFIGURATION messages in this test case is identical to the corresponding message found in the default contents of layer 3 messages for RRC tests with the following exceptions:



## RADIO BEARER RECONFIGURATION (Step 1)

Information Element	Value/remark
Activation Time	Current CFN-[current CFN mod 8 + 8 ]

## RADIO BEARER RECONFIGURATION (Step 2)

Information Element	Value/remark
Activation Time	Not Present

## RADIO BEARER RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	"RRC STATUS"
Failure cause	Incompatible simultaneous reconfiguration
Other information element	Not checked

## 8.2.2.11.5 Test requirement

After step2 the UE shall keep its exiting radio bearer configuration and transmit an RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RL, with the value "incompatible simultaneous reconfiguration" in IE"failure cause".

## 8.2.2.12 Radio Bearer Reconfiguration from CELL\_DCH to CELL\_FACH: Failure (Invalid message reception)

## 8.2.2.12.1 Definition

## 8.2.2.12.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a RADIO BEARER RECONFIGURATION message which includes the spare value in the mandatory IE" DRX indicator", possessing a criticality level defined as "Reject". It shall transmit a RADIO BEARER RECONFIGURATION FAILURE message which is set to "protocol error" in IE" failure cause" and is also set to "Information element value not comprehended" in IE" Protocol error cause".

## Reference

3GPP TS 25.331 clause 8.2.2

## 8.2.2.12.3 Test purpose

To confirm that the UE transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC to respond to an earlier RADIO BEARER RECONFIGURATION message, which applies a spare value in the mandatory IE" DRX indicator" having criticality defined as "Reject".

## 8.2.2.12.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

## Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE which includes a spare value in the mandatory IE" DRX indicator". The UE keeps the old configuration and transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting "protocol error" in IE" failure cause" and setting "Information element value not comprehended" in IE" Protocol error cause".

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RECONFIGURATION	
2		→	RADIO BEARER RECONFIGURATION FAILURE	The UE does not change the configuration.

Specific Message Contents

#### RADIO BEARER RECONFIGURATION

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
DRX indicator	spare value

#### RADIO BEARER RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	"RADIO BEARER RECONFIGURATION FAILURE"
Failure cause	
- Failure cause	Protocol error
- Protocol error information	
- Protocol error cause	Information element value not comprehended
Other information element	Not checked

##### 8.2.2.12.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC with "protocol error" specified in IE" failure cause" and also "Information element value not comprehended" specified in IE" Protocol error cause".

#### 8.2.2.13 Radio Bearer Reconfiguration from CELL\_DCH to CELL\_FACH: Failure (Suspension of signalling bearer)

##### 8.2.2.13.1 Definition

##### 8.2.2.13.2 Conformance requirement

The UE shall revert to the configuration prior to the reception of the RADIO BEARER RECONFIGURATION message which indicates suspension for an existing signalling radio bearer in IE"RB suspend/resume". It shall transmit a RADIO BEARER RECONFIGURATION FAILURE message to UTRAN

#### Reference

3GPP TS 25.331 clause 8.2.2

##### 8.2.2.13.3 Test purpose

To confirm that the UE reverts to the old configuration and transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC if the UE receives RADIO BEARER RECONFIGURATION message asking for the suspension of an existing signalling radio bearer.

##### 8.2.2.13.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

### Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE which includes the IE"RB suspend/resume" set to "Suspend" for one signalling radio bearer. The UE shall revert to the old configuration. Then the UE transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "configuration unacceptable" in IE" failure cause".

### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1	←		RADIO BEARER RECONFIGURATION	The message requests for the suspension of a current available signalling radio bearer
2	→		RADIO BEARER RECONFIGURATION FAILURE	The UE shall revert to the old configuration

### Specific Message Contents

#### RADIO BEARER RECONFIGURATION

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to those in the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
RB information to reconfigure list RB information to reconfigure I -RB Identity -RB suspend/resume	3 "Suspend"

#### RADIO BEARER RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type Failure cause Other information element	"RADIO BEARER RECONFIGURATION FAILURE" configuration unacceptable Not checked

#### 8.2.2.13.5 Test requirement

After step2 the UE shall revert to the old configuration and transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC specifying "configuration unacceptable " in IE" failure cause".

#### 8.2.2.14 Radio Bearer Reconfiguration: from CELL\_FACH to CELL\_DCH: Success

##### 8.2.2.14.1 Definition

##### 8.2.2.14.2 Conformance requirement

The UE shall correctly reconfigure a radio bearer according to a RADIO BEARER RECONFIGURATION message which is communicate with the UTRAN on the new radio bearer in case of a transition from CELL\_FACH to CELL\_DCH in the same cell.

### Reference

3GPP TS 25.331 clause 8.2.2

## 8.2.2.14.3 Test purpose

To confirm that the UE establishes a new radio bearer by following a RADIO BEARER RECONFIGURATION message received from the SS.

## 8.2.2.14.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

## Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE which includes the new radio bearer parameters and sets up L1 including the start of tx/rx. The UE reconfigures the new radio bearer and transmits a RADIO BEARER RECONFIGURATION COMPLETE message using AM RLC.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1	←		RADIO BEARER RECONFIGURATION	This message includes IE"Uplink DPCCH Info"
2				Reconfiguration of radio bearer
3	→		RADIO BEARER RECONFIGURATION COMPLETE	

## Specific Message Contents

## RADIO BEARER RECONFIGURATION (Step 1)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A.

## 8.2.2.14.5 Test requirement

After step2 the UE shall change its radio bearer configuration and communicate with the SS on the DCCH and DTCH which are being carried by the DPCCH physical channel resources.

## 8.2.2.15 Radio Bearer Reconfiguration from CELL\_FACH to CELL\_DCH: Failure (Unsupported or Unacceptable configuration)

## 8.2.2.15.1 Definition

## 8.2.2.15.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a RADIO BEARER RECONFIGURATION message which includes unsupported configuration parameters and transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "configuration unacceptable" in IE" failure cause

## Reference

3GPP TS 25.331 clause 8.2.2

## 8.2.2.15.3 Test purpose

To confirm that the UE transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC if the RADIO BEARER RECONFIGURATION message received includes unsupported configuration parameters.

## 8.2.2.15.4 Method of test

Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

## Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE which includes unsupported configuration parameters of the UE. The UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC and set "configuration unacceptable" in IE "failure cause".

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RECONFIGURATION	The message includes an unsupported configuration for the UE
2		→	RADIO BEARER RECONFIGURATION FAILURE	The UE does not change the radio bearer.

## Specific Message Contents

## RADIO BEARER RECONFIGURATION

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to those in the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Frequency info	
- UARFCN uplink(Nu)	63984
- UARFCN downlink(Nd)	Not Present

## RADIO BEARER RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	
Failure cause	Configuration unacceptable
Other information element	Not checked

## 8.2.2.15.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC stating "configuration unacceptable" in IE "failure cause".

## 8.2.2.16 Radio Bearer Reconfiguration from CELL\_FACH to CELL\_DCH: Failure (Physical channel failure and reversion to old configuration)

## 8.2.2.16.1 Definition

## 8.2.2.16.2 Conformance requirement

The UE shall revert to the old configuration when the UE fails to reconfigure the new physical channel by received RADIO BEARER RECONFIGURATION message and transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to “physical channel failure” in IE” failure cause”.

## Reference

3GPP TS 25.331 clause 8.2.2

## 8.2.2.16.3 Test purpose

To confirm that the UE reverts to the old configuration and transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC if the UE fails to reconfigure the new radio bearer according to a RADIO BEARER RECONFIGURATION message.

## 8.2.2.16.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

## Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE, which includes the new radio bearer parameters and does not reconfigure L1. Therefore, the UE cannot reconfigure the new radio bearer and shall attempt to revert to the old configuration. Then the UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC, with the value “physical channel failure” in IE” failure cause”.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RECONFIGURATION	
2				The SS does not reconfigures L1 including the start of tx/rx
3		→	RADIO BEARER RECONFIGURATION FAILURE	The UE fails to reconfigure a new radio bearer.

## Specific Message Contents

## RADIO BEARER RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	
Failure cause	Physical channel failure
Other information element	Not checked

## 8.2.2.16.5 Test requirement

After step2 the UE shall revert to the old configuration and transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting “physical channel failure” in IE” failure cause”.

### 8.2.2.17 Radio Bearer Reconfiguration from CELL\_FACH to CELL\_DCH: Failure (Physical channel failure and reversion failure)

#### 8.2.2.17.1 Definition

#### 8.2.2.17.2 Conformance requirement

The UE shall perform an RRC connection re-establishment procedure when the UE fails to revert to the old configuration after the detection of physical channel failure in the radio bearer reconfiguration procedure.

#### Reference

3GPP TS 25.331 clause 8.2.2

#### 8.2.2.17.3 Test purpose

To confirm that the UE initiates an RRC connection re-establishment procedure, when the UE cannot reconfigure the new radio bearer following a failure to configure L1 parameters for the new radio bearer settings and also a reversion failure to the old configuration.

#### 8.2.2.17.4 Method of test

#### Initial Condition

System Simulator : 2 cells - Cell 1 is active, Cell 2 is inactive

UE : CELL\_FACH in cell 1

#### Test Procedure

The UE is in the CELL\_FACH state in cell 1. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE, which includes the new radio bearer parameters but does not reconfigure L1 to cater to the new radio bearer settings. The UE cannot reconfigure the new radio bearer and wants to revert to the old configuration. But the SS does not configure the old radio bearer and begins to broadcast the BCCH in a cell 2 and stops broadcasting the BCCH in cell 1. Then the UE finds a new cell 2 and transmits to it an RRC CONNECTION RE-ESTABLISHMENT REQUEST message, which includes the IE "U-RNTI" on the uplink CCCH. The SS replies with an RRC CONNECTION RE-ESTABLISHMENT message, specifying a new TFCS according to the new transport channel. After the UE receives an RRC CONNECTION RE-ESTABLISHMENT message, it reconfigures the new radio connection and transmits an RRC CONNECTION RE-ESTABLISHMENT COMPLETE message on the uplink DCCH using AM RLC.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RECONFIGURATION	
2				The SS does not reconfigure the new radio bearer and delete the old configuration.
3				The UE shall detect a failure to reconfigure a new radio bearer, and start to revert to old configuration.
4		←	BCCH	The SS starts to transmit the BCCH in cell 2 and delete the old radio bearer settings in cell 1.
5		→	RRC CONNECTION RE-ESTABLISHMENT REQUEST	The UE shall find cell.2 and transmits this message which includes the IE"U-RNTI" it possesses.
6		←	RRC CONNECTION RE-ESTABLISHMENT	Including the new TFCS according to the new transport channel.
7		→	RRC CONNECTION RE-ESTABLISHMENT COMPLETE	

Specific Message Contents

None

#### 8.2.2.17.5 Test requirement

After step4 the UE shall detect the presence of cell 2, enter CELL\_FACH state, and attempt to perform RRC connection re-establishment procedure.

After step7 the UE shall successfully re-establish an RRC connection, and be able to access the dedicated physical resources in cell 2.

#### 8.2.2.18 Radio Bearer Reconfigure from CELL\_FACH to CELL\_DCH: Failure (Incompatible simultaneous reconfiguration)

##### 8.2.2.18.1 Definition

##### 8.2.2.18.2 Conformance requirement

The UE shall keep its old configuration when the UE receives another RADIO BEARER RECONFIGURATION message before it completes the reconfiguration of the new radio bearers specified in RADIO BEARER RECONFIGURATION message. Following this, the UE shall transmit an RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC with value "incompatible simultaneous reconfiguration" set in IE" failure cause".

Reference

3GPP TS 25.331 clause 8.2.2

##### 8.2.2.18.3 Test purpose

To confirm that the UE keeps its configuration and transmits an RADIO BEARER RECONFIGURATION FAILURE message when the UE receives another RADIO BEARER RECONFIGURATION message before the UE configures the radio bearer according to a RADIO BEARER RECONFIGURATION message.



## 8.2.2.18.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

## Test Procedure

The UE is in the CELL\_FACH state. When the SS transmits a RADIO BEARER RECONFIGURATION message to the UE before the completion of a radio bearer reconfiguration commanded earlier, the UE keeps the old configuration. The UE shall also transmit an RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to “incompatible simultaneous reconfiguration” in IE”failure cause”.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1	←		RADIO BEARER RECONFIGURATION	Including IE”Uplink DPCH info”
2	←		RADIO BEARER RECONFIGURATION	Sent before the elapse of the “Activation Time” indicated in the previous RADIO BEARER RECONFIGURATION message.
3	→		RADIO BEARER RECONFIGURATION FAILURE	The UE does not change the configuration.

## Specific Message Contents

## RADIO BEARER RECONFIGURATION

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Activation Time	Current CFN-[current CFN mod 8 + 8 ]

## RADIO BEARER RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	“RADIO BEARER RECONFIGURATION FAILURE”
Failure cause	Incompatible simultaneous reconfiguration
Other information element	Not checked

## 8.2.2.18.5 Test requirement

After step2 the UE shall keep its configuration and transmit an RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to “incompatible simultaneous reconfiguration” in IE”failure cause”.

## 8.2.2.19 Radio Bearer Reconfiguration from CELL\_FACH to CELL\_DCH: Failure (Invalid message reception)

## 8.2.2.19.1 Definition

## 8.2.2.19.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a RADIO BEARER RECONFIGURATION message, which includes the spare value in the mandatory IE” DRX indicator” with criticality defined as “Reject”. Then it shall

transmit a RADIO BEARER RECONFIGURATION FAILURE message setting “protocol error” in IE” failure cause” and also setting “Information element value not comprehended” in IE” Protocol error cause”.

#### Reference

3GPP TS 25.331 clause 8.2.2

#### 8.2.2.19.3 Test purpose

To confirm that the UE transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC if it receives a RADIO BEARER RECONFIGURATION message which includes the spare value in the mandatory IE” DRX indicator”, with criticality defined as “Reject”.

#### 8.2.2.19.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

#### Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE which includes the spare value in the mandatory IE” DRX indicator”. The UE shall keep the old configuration and transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC indicating “protocol error” in IE” failure cause” and also set “Information element value not comprehended” in IE” Protocol error cause”.

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RECONFIGURATION	
2		→	RADIO BEARER RECONFIGURATION FAILURE	The UE does not change the configuration.

#### Specific Message Contents

#### RADIO BEARER RECONFIGURATION

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
DRX indicator	spare value

#### RADIO BEARER RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	“RADIO BEARER RECONFIGURATION FAILURE”
Failure cause	
- Failure cause	Protocol error
- Protocol error information	
- Protocol error cause	Information element value not comprehended
Other information element	Not checked

#### 8.2.2.19.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC, which contain the cause “protocol error” in IE” failure cause” and “Information element value not comprehended” in IE” Protocol error cause”.

## 8.2.2.20 Radio Bearer Reconfiguration from CELL\_FACH to CELL\_DCH: Failure (Suspension of signalling bearer)

### 8.2.2.20.1 Definition

### 8.2.2.20.2 Conformance requirement

The UE shall revert to the configuration prior to the reception of the RADIO BEARER RECONFIGURATION message which specifies the suspension of an existing signalling radio bearer. It shall then transmit a RADIO BEARER RECONFIGURATION FAILURE message to UTRAN

### Reference

3GPP TS 25.331 clause 8.2.2

### 8.2.2.20.3 Test purpose

To confirm that the UE reverts to the old configuration and transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC if the UE fails to reconfigure the new radio bearer due to an inappropriate suspension request in RADIO BEARER RECONFIGURATION message.

### 8.2.2.20.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

#### Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE, which includes the IE"RB suspend/resume" set to "Suspend" for one existing signalling radio bearer. The UE shall revert to the old configuration. Then the UE transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC indicating "configuration unacceptable" in IE" failure cause".

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RECONFIGURATION	The message includes IE"RB suspend/resume" for one of the signalling radio bearer.
2		→	RADIO BEARER RECONFIGURATION FAILURE	The UE shall revert to the old configuration

#### Specific Message Contents

#### RADIO BEARER RECONFIGURATION

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
RB information to reconfigure list RB information to reconfigure I -RB identity -RB suspend/resume	2 Set to the "Suspend"

#### RADIO BEARER RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type Failure cause Other information element	"RADIO BEARER RECONFIGURATION FAILURE" configuration unacceptable Not checked

#### 8.2.2.20.5 Test requirement

After step2 the UE shall revert to the old configuration and transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC. This message shall contain the value "configuration unacceptable" in IE "failure cause".

### 8.2.2.21 Radio Bearer Reconfiguration from CELL\_FACH to CELL\_FACH:Success

#### 8.2.2.21.1 Definition

#### 8.2.2.21.2 Conformance requirement

The UE shall correctly reconfigure a radio bearer according to a RADIO BEARER RECONFIGURATION message which is communicate with the UTRAN on the new radio bearer and a transition from CELL\_FACH to CELL\_FACH in the another cell.

#### Reference

3GPP TS 25.331 clause 8.2.2

#### 8.2.2.22.3 Test purpose

To confirm that the UE establishes a new radio bearer by following a RADIO BEARER RECONFIGURATION message received from the SS.

#### 8.2.2.21.4 Method of test

#### Initial Condition

System Simulator : 2 cells Cell 1 is active, Cell 2 is inactive

UE : CELL\_FACH

#### Test Procedure

The UE is in the CELL\_FACH state. SS begins to broadcast the BCCH of cell 2. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE which includes the new transport channel parameter reconfigure for transit. The UE reconfigures the new transport channel and transmits a RADIO BEARER RECONFIGURATION COMPLETE message using AM RLC.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	BCCH	The SS starts to broadcast the BCCH in cell 2.
2		←	RADIO BEARER RECONFIGURATION	including Primary CPICH Info for cell 2.
3				Reconfiguration of Transport channel
4		→	RADIO BEARER RECONFIGURATION COMPLETE	Received on the uplink DCCH of cell 2.

Specific Message Contents

#### RADIO BEARER RECONFIGURATION (Step 2)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_FACH in PS" in Annex A.

#### 8.2.2.21.5 Test requirement

After step3 the UE shall transit from CELL\_FACH to CELL\_FACH in the another cell and communicate with the SS on the DCCH and DTCH using the modified transport channel configurations

#### 8.2.2.22 Radio Bearer Reconfiguration from CELL\_FACH to CELL\_FACH: Failure (Unsupported or Unacceptable configuration)

##### 8.2.2.22.1 Definition

##### 8.2.2.22.2 Conformance requirement

This procedure is used to handle the case of a failure to reconfigure radio bearer(s) or signalling link(s), following a detection of an unsupported configuration by the UE.

#### Reference

3GPP TS 25.331 clause 8.2.2

##### 8.2.2.22.3 Test purpose

To confirm that the UE transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC if the received RADIO BEARER RECONFIGURATION message includes unsupported configuration parameters.

##### 8.2.2.22.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

#### Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE, which includes unsupported configuration parameters for the UE. The UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "configuration unacceptable" in IE" failure cause".

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RECONFIGURATION	Including unsupported configuration by the UE
2		→	RADIO BEARER RECONFIGURATION FAILURE	The UE does not change the radio bearer.

Specific Message Contents

## RADIO BEARER RECONFIGURATION

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to those in the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Frequency info - UARFCN uplink(Nu) - UARFCN downlink(Nd)	63984. Not Present

## RADIO BEARER RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type Failure cause Other information element	"RADIO BEARER RECONFIGURATION FAILURE" Configuration unacceptable Not checked

### 8.2.2.22.5 Test requirement

After step2 the UE shall keep its old configuration and transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC with the value "configuration unacceptable" set in IE" failure cause".

## 8.2.2.23 Radio Bearer Reconfiguration from CELL\_FACH to CELL\_FACH: Failure (Physical channel failure)

### 8.2.2.23.1 Definition

### 8.2.2.23.2 Conformance requirement

The UE shall initiate the cell reselection procedure when the UE cannot use the assigned physical channel according to a RADIO BEARER RECONFIGURATION message, during the transition from CELL\_FACH to CELL\_FACH in the another cell.

### Reference

3GPP TS 25.331 clause 8.2.2

### 8.2.2.23.3 Test purpose

To confirm that the UE reverts to the old configuration and transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC if the UE fails to reconfigure the new radio bearer according to the RADIO BEARER RECONFIGURATION message received previously.

### 8.2.2.23.4 Method of test

### Initial Condition

System Simulator : 3 cells Cell 1 is active, Cell 2 is inactive, Cell 3 is inactive

UE : CELL\_FACH

### Test Procedure

The UE is in the CELL\_FACH state in cell 1. The SS begins to broadcast the BCCH in cell 2 and then transmits a RADIO BEARER RECONFIGURATION message, resulting in the UE to attempt to transit from CELL\_FACH in cell 1 to CELL\_FACH in cell 3. The UE is expected to fail to access the assigned physical channel as the SS ceases downlink transmission in cell 3. After the UE successfully camp onto cell 2, it shall initiate the cell update procedure in cell 2. The procedure completes when the SS confirms UE's cell update request.

### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	BCCH	The SS starts to broadcast the BCCH in cell 2.
2		←	RADIO BEARER RECONFIGURATION	The message assigns common resources so that the UE is expected to execute a transition from CELL_FACH in cell 1 to CELL_FACH in cell 3
3				The UE shall detect a failure to use the assigned common physical channel and try to perform a cell reselection.
4		→	CELL UPDATE	The UE discover the presence of cell 2 and triggers a cell update procedure.
5		←	CELL UPDATE CONFIRM	SS sends this message so that the UE moves to CELL_PCH state.

### Specific Message Contents

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_FACH in PS" in Annex A, with the following exceptions:

Information Element	Value/remark
Downlink information for each radio links - Primary CPICH Info - Primary scrambling code	200

### 8.2.23.5 Test requirement

After step3 the UE shall discover the presence of cell 2, enter CELL\_FACH state, and initiate a cell update procedure in that cell.

### 8.2.2.24 Radio Bearer Reconfiguration from CELL\_FACH to CELL\_FACH: Failure (Incompatible simultaneous reconfiguration)

#### 8.2.2.24.1 Definition

#### 8.2.2.24.2 Conformance requirement

The UE shall keep its old configuration when the UE receives another RADIO BEARER RECONFIGURATION message before the UE can configure the radio bearer according to an earlier RADIO BEARER RECONFIGURATION message. The UE shall transmit an RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC setting "incompatible simultaneous reconfiguration" in IE"failure cause".

## Reference

3GPP TS 25.331 clause 8.2.2

## 8.2.2.24.3 Test purpose

To confirm that the UE keeps its configuration and transmits an RADIO BEARER RECONFIGURATION FAILURE message when the UE receives another RADIO BEARER RECONFIGURATION message before the UE can complete the configuration of the radio bearer indicated in an earlier RADIO BEARER RECONFIGURATION message.

## 8.2.2.24.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

## Test Procedure

The UE is in the CELL\_FACH state. When the SS transmits a RADIO BEARER RECONFIGURATION message to the UE before the UE configures the requested radio bearer(s), the UE keeps the old configuration and transmits an RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC. This message shall set value "incompatible simultaneous reconfiguration" in IE "failure cause".

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RECONFIGURATION	Including IE "Uplink DPCH info"
2		←	RADIO BEARER RECONFIGURATION	Sent before the "activation time" in step 1 has elapsed
3		→	RADIO BEARER RECONFIGURATION FAILURE	The UE does not change the configuration.

## Specific Message Contents

## RADIO BEARER RECONFIGURATION (Step 1)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to those in the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Activation Time	Current CFN-[current CFN mod 8 + 8]

## RC STATUS

Information Element	Value/remark
Message Type	"RADIO BEARER RECONFIGURATION FAILURE"
Failure cause	Incompatible simultaneous reconfiguration
Other information element	Not checked

## 8.2.2.24.5 Test requirement

After step2 the UE shall keep its configuration and transmit an RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which contains the value "incompatible simultaneous reconfiguration" set in IE "failure cause".



## 8.2.2.25 Radio Bearer Reconfiguration from CELL\_FACH to CELL\_FACH: Failure (Invalid message reception)

### 8.2.2.25.1 Definition

### 8.2.2.25.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a RADIO BEARER RECONFIGURATION message, which includes the spare value in the mandatory IE" DRX indicator" having criticality defined as "Reject". The UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message which is set to "protocol error" in IE" failure cause" and is set to "Information element value not comprehended" in IE" Protocol error cause".

### Reference

3GPP TS 25.331 clause 8.2.2

### 8.2.2.25.3 Test purpose

To confirm that the UE transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC, if it receives a RADIO BEARER RECONFIGURATION message containing a spare value in the mandatory IE" DRX indicator" with criticality defined as "Reject".

### 8.2.2.25.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

#### Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE which includes the spare value in the mandatory IE" DRX indicator" which criticality is defined as "Reject". The UE keeps the old configuration and transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "protocol error" in IE" failure cause" and is set to "Information element value not comprehended" in IE" Protocol error cause".

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1	←		RADIO BEARER RECONFIGURATION	The message contains a illegal error in a mandatory IE.
2	→		RADIO BEARER RECONFIGURATION FAILURE	The UE does not change the configuration.

#### Specific Message Contents

#### RADIO BEARER RECONFIGURATION

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to the corresponding message found in the default contents of layer 3 messages for RRC tests, with the following exceptions:

Information Element	Value/remark
DRX indicator	spare value

#### RADIO BEARER RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	"RADIO BEARER RECONFIGURATION FAILURE"
Failure cause	
- Failure cause	Protocol error
- Protocol error information	
- Protocol error cause	Information element value not comprehended
Other information element	Not checked

#### 8.2.2.25.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC stating the reason "protocol error" in IE" failure cause". The message shall contain the value "Information element value not comprehended" in IE" Protocol error cause".

#### 8.2.2.26 Radio Bearer Reconfiguration from CELL\_FACH to CELL\_FACH :Failure (Suspension of signalling bearer)

##### 8.2.2.26.1 Definition

##### 8.2.2.26.2 Conformance requirement

The UE shall revert to the old configuration prior to the reception of RADIO BEARER RECONFIGURATION message, which includes IE"RBSuspend/resume" specified as "Suspend", and transmit a RADIO BEARER RECONFIGURATION FAILURE message to UTRAN

#### Reference

3GPP TS 25.331 clause 8.2.2

##### 8.2.2.26.3 Test purpose

To confirm that the UE reverts to the old configuration and transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC if the UE fails to reconfigure the new radio bearer according to a RADIO BEARER RECONFIGURATION message.

##### 8.2.2.26.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

#### Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE which specifies the suspension of a signalling radio bearer to be reconfigured. The UE shall revert to the old configuration. Then the UE transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC with the IE" failure cause" set to "configuration unacceptable".

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RECONFIGURATION	Specifies a signalling radio bearer to be suspended.
2		→	RADIO BEARER RECONFIGURATION FAILURE	The UE shall revert to the old configuration

Specific Message Contents

## RADIO BEARER RECONFIGURATION

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
RB information to reconfigure list RB information to reconfigure I -RB identity -RB suspend/resume	3 "Suspend"

## RADIO BEARER RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	"RADIO BEARER RECONFIGURATION FAILURE"
Failure cause	Configuration unacceptable
Other information element	Not checked

### 8.2.2.26.5 Test requirement

After step2 the UE shall revert to the old configuration and transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC specifying the reason "configuration unacceptable" in IE" failure cause".

## 8.2.3 Radio Bearer Release

### 8.2.3.1 Radio Bearer Release for transition from CELL\_DCH to CELL\_DCH: Success

#### 8.2.3.1.1 Definition

#### 8.2.3.1.2 Conformance requirement

The UE shall correctly release a radio bearer according to a RADIO BEARER RELEASE message.

#### Reference

3GPP TS 25.331 clause 8.2.3

#### 8.2.3.1.3 Test purpose

To confirm that the UE release the existing radio bearer according to a RADIO BEARER RELEASE message received from the SS.

## 8.2.3.1.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

## Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a RADIO BEARER RELEASE message to the UE. The UE release the radio bearer and transmits a RADIO BEARER RELEASE COMPLETE message on the uplink DCCH using AM RLC.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RELEASE	
2				Release the radio bearer
3		→	RADIO BEARER RELEASE COMPLETE	

## Specific Message Contents

None

## 8.2.3.1.5 Test requirement

After step1 the UE shall release its radio bearers.

After step3 the UE shall stop communicating on the released radio bearers, no uplink transmission shall be observed originating from the released link. The remaining radio bearers shall continue to be operational.

## 8.2.3.2 Radio Bearer Release for transition from CELL\_DCH to CELL\_DCH: Failure (Unsupported or Unacceptable configuration)

## 8.2.3.2.1 Definition

## 8.2.3.2.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a RADIO BEARER RELEASE message which includes unsupported configuration parameters and transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, setting value "configuration unacceptable" in IE" failure cause".

## Reference

3GPP TS 25.331 clause 8.2.3

## 8.2.3.2.3 Test purpose

To confirm that the UE keeps its current configuration and transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, if the received RADIO BEARER RELEASE message indicates an unsupported configuration parameters for the UE.

## 8.2.3.2.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

## Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a RADIO BEARER RELEASE message to the UE specifying a frequency which is not supported by the UE. The UE transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC indicating "configuration unacceptable" in IE" failure cause".

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RELEASE	Including unsupported configuration by the UE
2		→	RADIO BEARER RELEASE FAILURE	The UE does not change the radio bearer.

## Specific Message Contents

## RADIO BEARER RELEASE

The contents of RADIO BEARER RELEASE message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Frequency info	
- UARFCN uplink(Nu)	63984
- UARFCN downlink(Nd)	Not Present

## RADIO BEARER RELEASE FAILURE

Information Element	Value/remark
Message Type	
Failure cause	Configuration unacceptable
Other information element	Not checked

## 8.2.3.2.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC with the IE" failure cause" set to "configuration unacceptable". The UE shall be able to continue receiving and sending user data.

## 8.2.3.3 Radio Bearer Release for transition from CELL\_DCH to CELL\_DCH: Failure (Physical channel failure and reversion to old configuration)

## 8.2.3.3.1 Definition

## 8.2.3.3.2 Conformance requirement

The UE shall revert to the old configuration when the UE fails to configure the new radio bearer by timer T312 expiry and transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC which is set to "physical channel failure" in IE" failure cause".

## Reference

3GPP TS 25.331 clause 8.2.3

## 8.2.3.3.3 Test purpose

To confirm that the UE reverts to the old configuration and transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC if the UE fails to release the radio bearer according to a RADIO BEARER RELEASE message by timer T312 expiry.

## 8.2.3.3.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

## Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a RADIO BEARER RELEASE message but it does not configure L1 correspondingly. This causes the UE to fail to release the radio bearer, and after T312 expiry the UE reverts to the old configuration. The UE then transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC which specifies “physical channel failure” in IE “failure cause”.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1	←		RADIO BEARER RELEASE	
2				The SS does not configure L1 to reflect the release of the indicated bearer.
3	→		RADIO BEARER RELEASE FAILURE	After T312 expiry, the UE finds that it fails to release a radio bearer and reverts to the old configuration.

## Specific Message Contents

## RADIO BEARER RELEASE FAILURE

Information Element	Value/remark
Message Type	
Failure cause	Physical channel failure
Other information element	Not checked

## 8.2.3.3.5 Test requirement

After step2 the UE shall revert to the old configuration and transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC which includes the value “physical channel failure” in IE “failure cause”.

## 8.2.3.4 Radio Bearer Release for transition from CELL\_DCH to CELL\_DCH: Failure(Physical channel failure and reversion failure)

## 8.2.3.4.1 Definition

## 8.2.3.4.2 Conformance requirement

The UE shall perform an RRC connection re-establishment procedure when the UE fails to revert to the old configuration after the detection of physical channel failure in the radio bearer release procedure.

## Reference

3GPP TS 25.331 clause 8.2.3

## 8.2.3.4.3 Test purpose

To confirm that the UE initiates an RRC connection re-establishment procedure when the UE cannot revert to the old configuration after encountering a physical channel failure during the execution of a radio bearer release procedure.

## 8.2.3.4.4 Method of test

## Initial Condition

System Simulator : 2 cells - Cell 1 is active, Cell.2 is inactive

UE : CELL\_DCH in cell 1

## Test Procedure

The UE is in the CELL\_DCH state in cell 1. The SS begins to broadcast the BCCH in cell 2 with a lower power level than for cell 1. At the same time, it transmits a RADIO BEARER RELEASE message to the UE but does not configure L1. As a result, the UE fails to release the radio bearer properly and tries to revert to the old configuration after T312 expiry. But the SS deletes the old radio bearer so the UE shall find the availability of cell 2 and transmits to it an RRC CONNECTION RE-ESTABLISHMENT REQUEST message, which includes the IE "U-RNTI" and sent on the uplink CCCH. The SS transmits an RRC CONNECTION RE-ESTABLISHMENT message, which includes a new TFCS according to the new transport channel. After the UE receives an RRC CONNECTION RE-ESTABLISHMENT message, it reconfigures the new radio connection and transmits an RRC CONNECTION RE-ESTABLISHMENT COMPLETE message on the uplink DCCH using AM RLC.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1	←		BCCH	The SS starts to transmit the BCCH for cell 2 but at a lower power level than cell 1.
2	←		RADIO BEARER RELEASE	
3				The SS does not configure L1 and deletes the old configuration. This is expected to cause the UE to fail in the release the radio bearer and can not revert to the old configuration.
4	→		RRC CONNECTION RE-ESTABLISHMENT REQUEST	The UE shall find cell 2 and then transmit this message which includes the IE "U-RNTI" set to its assigned connected mode identity.
5	←		RRC CONNECTION RE-ESTABLISHMENT	Including the new TFCS according to the new transport channel.
6	→		RRC CONNECTION RE-ESTABLISHMENT COMPLETE	

## Specific Message Contents

None.

#### 8.2.3.4.5 Test requirement

After step 3 the UE shall find the presence of cell 2, enter CELL\_FACH state, and transmits RRC CONNECTION RE-ESTABLISHMENT REQUEST message on the uplink CCCH of cell 2.

After step 6 the UE shall successfully re-establish an RRC connection, after sending RRC CONNECTION RE-ESTABLISHMENT COMPLETE message.

#### 8.2.3.5 Radio Bearer Release for transition from CELL\_DCH to CELL\_DCH: Failure (Incompatible simultaneous reconfiguration)

##### 8.2.3.5.1 Definition

##### 8.2.3.5.2 Conformance requirement

The UE shall keep its old configuration when the UE receives another RADIO BEARER RELEASE message before the UE is able to release the indicated radio bearer according to a RADIO BEARER RELEASE message. The UE shall transmit an RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC which is set to “incompatible simultaneous reconfiguration” in IE “failure cause”.

#### Reference

3GPP TS 25.331 clause 8.2.3

##### 8.2.3.5.3 Test purpose

To confirm that the UE keeps its configuration when the UE receives another RADIO BEARER RELEASE message before the UE releases the radio bearer according to the earlier RADIO BEARER RELEASE message.

##### 8.2.3.5.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

#### Test Procedure

The UE is in the CELL\_DCH state. SS transmits a RADIO BEARER RELEASE message on the downlink DCCH, requesting the UE to release all radio bearers mapped to dedicated transport channels. Next, the SS transmits another RADIO BEARER RELEASE message to the UE before the UE is able to release the radio bearers requested in the earlier message. The UE shall keep the old configuration. It shall transmit an RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC which is set to “incompatible simultaneous reconfiguration” in IE “failure cause”.



Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RELEASE	
2		←	RADIO BEARER RELEASE	Message sent before the "activation time" indicated in the message of step 1 has elapsed.
3		→	RADIO BEARER RELEASE FAILURE	The UE does not change the configuration.

Specific Message Contents

#### RADIO BEARER RELEASE (Step 1)

The contents of RADIO BEARER RELEASE message in this test case is identical to the message sub-type title "Packet to CELL\_FACH from CELL\_DCH in PS" found in Annex A, with the following exceptions:

Information Element	Value/remark
Activation Time	Current CFN-[current CFN mod 8 + 8 ]

#### RADIO BEARER RELEASE (Step 2)

The contents of RADIO BEARER RELEASE message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_DCH in PS" found in Annex A.

#### RADIO BEARER RELEASE FAILURE

Information Element	Value/remark
Message Type	
Failure cause	Incompatible simultaneous reconfiguration
Other information element	Not checked

#### 8.2.3.5.5 Test requirement

After step2 the UE shall keep its old configuration and transmit an RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC which is set to "incompatible simultaneous reconfiguration" in IE"failure cause".

#### 8.2.3.6 Radio Bearer Release for transition from CELL\_DCH to CELL\_DCH: Failure (Invalid message reception)

##### 8.2.3.6.1 Definition

##### 8.2.3.6.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a RADIO BEARER RELEASE message which includes the spare value in the mandatory IE" DRX indicator". It shall transmit a RADIO BEARER RELEASE FAILURE message which contains value "protocol error" in IE" failure cause" and value "Information element value not comprehended" in IE" Protocol error cause".

#### Reference

3GPP TS 25.331 clause 8.2.3

##### 8.2.3.6.3 Test purpose

To confirm that the UE transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC if it receives a RADIO BEARER RELEASE message, which uses a spare value in the mandatory IE" DRX indicator".

## 8.2.3.6.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

## Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a RADIO BEARER RELEASE message to the UE which includes the spare value in the mandatory IE "DRX indicator". The UE keeps the old configuration and transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC. This message shall indicate "protocol error" in IE "failure cause" and also "Information element value not comprehended" in IE "Protocol error cause".

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1	←		RADIO BEARER RELEASE	
2		→	RADIO BEARER RELEASE FAILURE	The UE shall not change the configuration.

## Specific Message Contents

## RADIO BEARER RELEASE

The contents of RADIO BEARER RELEASE message in this test case is identical to that found in default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
DRX indicator	Spare value

## RADIO BEARER RELEASE FAILURE

Information Element	Value/remark
Message Type	
Failure cause	
- Failure cause	Protocol error
- Protocol error information	
- Protocol error cause	Information element value not comprehended
Other information element	Not checked

## 8.2.3.6.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, which is set to "protocol error" in IE "failure cause" and is set to "Information element value not comprehended" in IE "Protocol error cause".

## 8.2.3.7 Radio Bearer Release for transition from CELL\_DCH to CELL\_FACH: Success

## 8.2.3.7.1 Definition

## 8.2.3.7.2 Conformance requirement

The UE shall correctly release a radio bearer according to a RADIO BEARER RELEASE message, when the common physical channel are requested to be used for the remaining radio bearers.

## Reference

3GPP TS 25.331 clause 8.2.3

## 8.2.3.7.3 Test purpose

To confirm that the UE release the existing the radio bearer according to a RADIO BEARER RELEASE message received from the SS.

## 8.2.3.7.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

## Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a RADIO BEARER RELEASE message to the UE. The UE release the radio bearer and transmits a RADIO BEARER RELEASE COMPLETE message on the uplink DCCH using AM RLC.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RELEASE	SS releases the radio bearer in the fashion specified in the message and allocate common channel resources to carry the remaining radio bearers.
2				UE shall release radio bearers on dedicated transport channels, and reconfigure the remaining radio bearers using the given common control channel.
3		→	RADIO BEARER RELEASE COMPLETE	UE shall be able to continue communication over the remaining radio bearers using the allocated common control channels.

## Specific Message Contents

## RADIO BEARER RELEASE (Step 1)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A.

## 8.2.3.7.5 Test requirement

After step3 the UE shall release the specified radio bearer(s) and cease any further uplink transmission from these radio bearer(s). At the same time, it shall resume the transmission or reception of data for the previously suspended radio bearers.

## 8.2.3.8 Radio Bearer Release for transition from CELL\_DCH to CELL\_FACH: Failure (Unsupported or Unacceptable configuration)

## 8.2.3.8.1 Definition

#### 8.2.3.8.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a RADIO BEARER RELEASE message, which includes an unsupported configuration parameters and then transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, setting "configuration unacceptable" in IE" failure cause".

#### Reference

3GPP TS 25.331 clause 8.2.3

#### 8.2.3.8.3 Test purpose

To confirm that the UE keeps its configuration and transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC if the received RADIO BEARER RELEASE message includes unsupported configuration parameters for the UE.

#### 8.2.3.8.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

#### Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a RADIO BEARER RELEASE message to the UE as the frequency cannot be supported by the UE. The UE transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC and set value "configuration unacceptable" in IE" failure cause"..

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RELEASE	The message Includes a configuration unsupported by the UE.
2		→	RADIO BEARER RELEASE FAILURE	The UE does not alter the current radio bearer configuration.

#### Specific Message Contents

#### RADIO BEARER RELEASE

The contents of RADIO BEARER RELEASE message in this test case is identical to those in the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Frequency info - UARFCN uplink(Nu) - UARFCN downlink(Nd)	63984 Not present

**RADIO BEARER RELEASE FAILURE**

Information Element	Value/remark
Message Type Failure cause Other information element	Configuration unacceptable Not checked

**8.2.3.8.5 Test requirement**

After step2 the UE shall keep its old configuration and transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC which is set to “configuration unacceptable” in IE” failure cause”.

**8.2.3.9 Radio Bearer Release for transition from CELL\_DCH to CELL\_FACH: Failure (Physical channel failure)****8.2.3.9.1 Definition****8.2.3.9.2 Conformance requirement**

The UE shall initiate the cell update procedure when the UE cannot use the assigned physical channel according to a RADIO BEARER RELEASE message as the transition from CELL\_DCH to CELL\_FACH.

**Reference**

3GPP TS 25.331 clause 8.2.3

**8.2.3.9.3 Test purpose**

To confirm that the UE perform a cell update procedure when the UE cannot use the assigned physical channel according to a RADIO BEARER RELEASE message as the transition from CELL\_DCH to CELL\_FACH.

**8.2.3.9.4 Method of test****Initial Condition**

System Simulator : 2 cells ☐ No.1 is active, No.2 is inactive ☐

UE : CELL\_DCH

**Test Procedure**

The UE is in the CELL\_DCH state in cell No.1. The SS begins to broadcast the BCCH in cell No.2 and transmits a RADIO BEARER RELEASE message as the transition from CELL\_DCH to CELL\_FACH. The UE cannot use the assigned physical channel as the SS does not transmit any data on the DL common channel in cell No.1. Then the UE initiate the cell update procedure in cell No.2.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	BCCH	The SS broadcasts BCCH in cell No.2.
2		←	RADIO BEARER RELEASE	Assigned the transition from CELL_DCH to CELL_FACH
3				The UE cannot use the assigned the physical channel.
4		→	CELL UPDATE	The UE finds a new cell •No.2• and begins a cell update procedure.
5		←	CELL UPDATE CONFIRM	In the CELL_FACH state

Specific Message Contents

None

#### 8.2.3.9.5 Test requirement

After step3 the UE shall find a new cell No.2 and enter to CELL\_FACH state. Then the UE shall initiate a cell update procedure in cell No.2.

#### 8.2.3.10 Radio Bearer Release for transition from CELL\_DCH to CELL\_FACH: Failure (Incompatible simultaneous reconfiguration)

##### 8.2.3.10.1 Definition

##### 8.2.3.10.1 Conformance requirement

The UE shall keep its old configuration when the UE receives another RADIO BEARER RELEASE message, before the UE manages to release the radio bearer specified in the RADIO BEARER RELEASE message. The UE shall transmit an RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC and set value “incompatible simultaneous reconfiguration” in IE”failure cause”.

Reference

3GPP TS 25.331 clause 8.2.3

##### 8.2.3.10.2 Test purpose

To confirm that the UE keeps its configuration when the UE receives another RADIO BEARER RELEASE message before the UE has completed the release of the radio bearer according to a RADIO BEARER RELEASE message.

##### 8.2.3.10.3 Method of test

Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

Test Procedure

The UE is in the CELL\_DCH state. When the SS transmits a RADIO BEARER RELEASE message to the UE before the it completes the releases of the requested radio bearer, the UE keeps the old configuration. Thereafter, it transmits

an RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC and set “incompatible simultaneous reconfiguration” in IE”failure cause”.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1	←		RADIO BEARER RELEASE	
2	←		RADIO BEARER RELEASE	Sent before the passing of the “activation time” indicated in RADIO BEARER RELEASE message in step 1.
3	→		RADIO BEARER RELEASE FAILURE	The UE shall not change the radio bearer configuration.

Specific Message Contents

#### RADIO BEARER RELEASE (Step 1)

The contents of RADIO BEARER RELEASE message in this test case is identical to those found in the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Activation Time	Current CFN-[current CFN mod 8 + 8 ]

#### RADIO BEARER RELEASE FAILURE

Information Element	Value/remark
Message Type	
Failure cause	Incompatible simultaneous reconfiguration
Other information element	Not checked

#### 8.2.3.10.4 Test requirement

After step2 the UE shall keep its old configuration and transmit an RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, setting “incompatible simultaneous reconfiguration” in IE”failure cause”.

#### 8.2.3.11 Radio Bearer Release for transition from CELL\_DCH to CELL\_FACH: Failure (Invalid message reception)

##### 8.2.3.11.1 Definition

##### 8.2.3.11.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a RADIO BEARER RELEASE message. The message uses a spare value for the mandatory IE” DRX indicator”. Upon receiving this message, the UE shall transmit a RADIO BEARER RELEASE FAILURE message containing the value “protocol error” in IE” failure cause” and also the value “Information element value not comprehended” in IE” Protocol error cause”.

#### Reference

3GPP TS 25.331 clause 8.2.3

##### 8.2.3.11.3 Test purpose

To confirm that the UE transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC if it receives a RADIO BEARER RELEASE message which uses a spare value in the mandatory IE” DRX indicator”.

## 8.2.3.11.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

## Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a RADIO BEARER RELEASE message to the UE which indicates a spare value in the mandatory IE "DRX indicator". The UE shall keep the old configuration and then transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC. The content of this message shall indicate "protocol error" in IE "failure cause" and also "Information element value not comprehended" in IE "Protocol error cause".

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RELEASE	This message uses a spare value for a mandatory IE.
2		→	RADIO BEARER RELEASE FAILURE	The UE does not change the configuration.

## Specific Message Contents

## RADIO BEARER RELEASE

The contents of RADIO BEARER RELEASE message in this test case is identical to those found in the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
DRX indicator	Spare value

## RADIO BEARER RELEASE FAILURE

Information Element	Value/remark
Message Type	
Failure cause	
- Failure cause	Protocol error
- Protocol error information	
- Protocol error cause	Information element value not comprehended
Other information element	Not checked

## 8.2.3.11.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC which set "protocol error" in IE "failure cause" and also set "Information element value not comprehended" in IE "Protocol error cause".

## 8.2.3.12 Radio Bearer Release for transition from CELL\_FACH to CELL\_DCH: Success

## 8.2.3.12.1 Definition

## 8.2.3.12.2 Conformance requirement

The UE shall correctly release a radio bearer according to a RADIO BEARER RELEASE message.



## Reference

3GPP TS 25.331 clause 8.2.3

## 8.2.3.12.3 Test purpose

To confirm that an UE, in state CELL\_FACH, releases the radio access bearers on RACH and FACH transport channels. After the release, it shall access the affected radio bearers on the newly allocated DCH transport channel.

## 8.2.3.12.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

## Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a RADIO BEARER RELEASE message to the UE. In this message, SS commands the UE to release radio bearers on RACH and FACH. At the same time, SS allocates DCH to support the affected radio bearers. The UE shall release the indicated radio bearer and transmits a RADIO BEARER RELEASE COMPLETE message on the uplink DCCH using AM RLC.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RELEASE	
2				UE shall release the radio access bearers carried by RACH and FACH transport channels.
3		→	RADIO BEARER RELEASE COMPLETE	

## Specific Message Contents

## RADIO BEARER RELEASE (Step 1)

Use the same message sub-type titled "Packet to CELL\_DCH from CELL\_FACH in PS" in Annex A.

## 8.2.3.12.5 Test requirement

After step3 the UE shall stop communicating on the released radio bearers, and resume all suspended radio bearer using the dedicated physical channel allocated.

## 8.2.3.13 Radio Bearer Release for transition from CELL\_FACH to CELL\_DCH: Failure (Unsupported or Unacceptable configuration)

## 8.2.3.13.1 Definition

## 8.2.3.13.2 Conformance requirement

The UE shall keep its old configuration when it receives a RADIO BEARER RELEASE message which specifies unsupported configuration parameters for the UE. Then the UE shall transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC which, setting value "configuration unacceptable" in IE" failure cause".

## Reference

3GPP TS 25.331 clause 8.2.3

## 8.2.3.13.3 Test purpose

To confirm that the UE keeps its configuration and transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC if the received RADIO BEARER RELEASE message requests for unsupported configuration parameters for the UE.

## 8.2.3.13.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

## Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a RADIO BEARER RELEASE message to the UE, referring to a frequency which cannot be supported by the UE. The UE shall transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC and set "configuration unacceptable" in IE" failure cause".

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RELEASE	The message contains a configuration not supported by the UE
2		→	RADIO BEARER RELEASE FAILURE	The UE shall not change the radio bearer configuration.

## Specific Message Contents

## RADIO BEARER RELEASE

The contents of RADIO BEARER RELEASE message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Frequency info - UARFCN uplink(Nu) - UARFCN downlink(Nd)	63984 Not Present

## RADIO BEARER RELEASE FAILURE

Information Element	Value/remark
Message Type Failure cause Other information element	Configuration unacceptable Not checked

## 8.2.3.13.5 Test requirement

After step2 the UE shall keep its old configuration and transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, stating the reason "configuration unacceptable" in IE" failure cause".

### 8.2.3.14 Radio Bearer Release for transition from CELL\_FACH to CELL\_DCH: Failure (Physical channel failure and reversion to old configuration)

#### 8.2.3.14.1 Definition

#### 8.2.3.14.2 Conformance requirement

The UE shall revert to the old configuration when the UE fails to configure the new radio bearer before T312 timer expiry. Then it shall transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, setting the value “physical channel failure” in IE” failure cause”.

#### Reference

3GPP TS 25.331 clause 8.2.3

#### 8.2.3.14.3 Test purpose

To confirm that the UE reverts to the old configuration and transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC if the UE fails to release the radio bearer in accordance the specified settings in RADIO BEARER RELEASE message by T312 timer expiry.

#### 8.2.3.14.4 Method of test

##### Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

##### Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a RADIO BEARER RELEASE message and does not configure L1. The UE is expected to encounter a failure while releasing the radio bearer. After T312 timer expiry, the UE shall revert to the old radio bearer configuration, so the UE transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC which is set to “.physical channel failure” in IE” failure cause”.

##### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RELEASE	
2				The SS does not configure L1.
3		→	RADIO BEARER RELEASE FAILURE	After T312 expiry the UE fails to release a radio bearer and reverts to the old configuration.

##### Specific Message Contents

##### RADIO BEARER RELEASE FAILURE

Information Element	Value/remark
Message Type	
Failure cause	Physical channel failure
Other information element	Not checked

#### 8.2.3.14.5 Test requirement

After step2 the UE shall revert to the old configuration and transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, setting the value “physical channel failure” in IE” failure cause”.

### 8.2.3.15 Radio Bearer Release for transition from CELL\_FACH to CELL\_DCH: Failure(Physical channel failure and reversion failure)

#### 8.2.3.15.1 Definition

#### 8.2.3.15.2 Conformance requirement

The UE shall perform an RRC connection re-establishment procedure when the UE fails to revert to the old configuration after the detection of physical channel failure in the radio bearer release procedure.

#### Reference

3GPP TS 25.331 clause 8.2.3

#### 8.2.3.15.3 Test purpose

To confirm that the UE initiates an RRC connection re-establishment procedure when the UE cannot revert to the old configuration, following a physical channel failure during the radio bearer release.

#### 8.2.3.15.4 Method of test

#### Initial Condition

System Simulator : 2 cells - Cell.1 is active, Cell 2 is inactive

UE : CELL\_FACH in cell No.1

#### Test Procedure

The UE is in the CELL\_FACH state in cell 1. The SS begins to broadcast the BCCH in cell 2 and then transmits a RADIO BEARER RELEASE message to the UE, but it does not configure L1. This is expected to cause the UE to experience a failure to release the radio bearer and it subsequently tries to revert to the old configuration after T312 expiry. The SS deletes the old radio bearer, so the UE shall find cell 2 and transmits to it an RRC CONNECTION RE-ESTABLISHMENT REQUEST message, which includes the IE "U-RNTI" on the uplink CCCH. After receiving this message, the SS transmits an RRC CONNECTION RE-ESTABLISHMENT message which includes a new TFCS according to the new transport channel. After the UE receives an RRC CONNECTION RE-ESTABLISHMENT message, it reconfigures the new radio connection and transmits an RRC CONNECTION RE-ESTABLISHMENT COMPLETE message on the uplink DCCH using AM RLC.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	BCCH	The SS starts to transmit the BCCH in a cell 2.
2		←	RADIO BEARER RELEASE	
3				The SS does not configure L1 and deletes the old configuration so the UE cannot release the radio bearer and also fails revert to the old configuration.
4		→	RRC CONNECTION RE-ESTABLISHMENT REQUEST	The UE finds a new cell 2 and then transmits this message which includes the IE"U-RNTI" it has been assigned to.
5		←	RRC CONNECTION RE-ESTABLISHMENT	Including the new TFCS according to the new transport channel.
6		→	RRC CONNECTION RE-ESTABLISHMENT COMPLETE	

Specific Message Contents

None.

#### 8.2.3.15.5 Test requirement

After step3 the UE shall find the presence of cell 2, enter CELL\_FACH state, and transmit a RRC CONNECTION RE-ESTABLISHMENT REQUEST on the uplink CCCH.

After step6 the UE shall successfully re-establish an RRC connection and access the dedicated physical channels assigned.

#### 8.2.3.16 Radio Bearer Release for transition from CELL\_FACH to CELL\_DCH: Failure (Incompatible simultaneous reconfiguration)

##### 8.2.3.16.1 Definition

##### 8.2.3.16.2 Conformance requirement

The UE shall keep its old configuration when the UE receives another RADIO BEARER RELEASE message before the UE is able to release the radio bearer according to an earlier RADIO BEARER RELEASE message. The UE shall then transmit an RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, setting value "incompatible simultaneous reconfiguration" in IE"failure cause".

Reference

3GPP TS 25.331 clause 8.2.3

##### 8.2.3.16.3 Test purpose

To confirm that the UE keeps its old configuration when it receives another RADIO BEARER RELEASE message before it releases the radio bearer according to an earlier RADIO BEARER RELEASE message.

## 8.2.3.16.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

## Test Procedure

The UE is in the CELL\_FACH state. When the SS transmits a RADIO BEARER RELEASE message to the UE before the UE completes the release of the radio bearer, it shall keep the old configuration and transmit an RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC. This message shall specify the reason “incompatible simultaneous reconfiguration” in IE”failure cause”.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RELEASE	
2		←	RADIO BEARER RELEASE	Sent before the expiry stated in IE “Activation Time” of RADIO BEARER RELEASE message in step 1.
3		→	RADIO BEARER RELEASE FAILURE	The UE does not change the configuration.

## Specific Message Contents

## RADIO BEARER RELEASE (Step 1)

The contents of RADIO BEARER RELEASE message in this test case is identical to those found in default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Activation Time Info	Current CFN-[current CFN mod 8 + 8 ]

## RADIO BEARER RELEASE FAILURE

Information Element	Value/remark
Message Type	
Failure cause	Incompatible simultaneous reconfiguration
Other information element	Not checked

## 8.2.3.16.5 Test requirement

After step2 the UE shall keep its old configuration and transmit an RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, and set the value “incompatible simultaneous reconfiguration” in IE”failure cause”.

## 8.2.3.17 Radio Bearer Release for transition from CELL\_FACH to CELL\_DCH: Failure (Invalid message reception)

## 8.2.3.17.1 Definition

.

## 8.2.3.17.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a RADIO BEARER RELEASE message which uses a spare value in the mandatory IE” DRX indicator”. It shall transmit a RADIO BEARER RELEASE FAILURE message which indicate the value “protocol error” in IE” failure cause” and setting “Information element value not comprehended” in IE” Protocol error cause”.

## Reference

3GPP TS 25.331 clause 8.2.3

## 8.2.3.17.3 Test purpose

To confirm that the UE transmits RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC if it receives a RADIO BEARER RELEASE message which uses a spare value in the mandatory IE" DRX indicator".

## 8.2.3.17.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

## Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a RADIO BEARER RELEASE message to the UE containing a spare value in the mandatory IE" DRX indicator". The UE keeps the old configuration and transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, which shall indicate the reason "protocol error" in IE" failure cause" and also "Information element value not comprehended" in IE" Protocol error cause".

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1	←		RADIO BEARER RELEASE	
2	→		RADIO BEARER RELEASE FAILURE	The UE shall not change its current configuration.

## Specific Message Contents

## RADIO BEARER RELEASE

The contents of RADIO BEARER RELEASE message in this test case is identical to those for the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
DRX indicator	spare value

## RADIO BEARER RELEASE FAILURE

Information Element	Value/remark
Message Type	
Failure cause	
- Failure cause	Protocol error
- Protocol error information	
- Protocol error cause	Information element value not comprehended
Other information element	Not checked

## 8.2.3.17.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, setting "protocol error" in IE" failure cause" and also indicating "Information element value not comprehended" in IE" Protocol error cause".

### 8.2.3.18 Radio Bearer Release for transition from CELL\_FACH to CELL\_FACH: Success

#### 8.2.3.18.1 Definition

.

#### 8.2.3.18.2 Conformance requirement

The UE shall correctly release a radio bearer according to the RADIO BEARER RELEASE message received.

#### Reference

3GPP TS 25.331 clause 8.2.3

#### 8.2.3.18.3 Test purpose

To confirm that the UE release the existing the radio bearer(s) according to the RADIO BEARER RELEASE message received from the SS.

#### 8.2.3.18.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

#### Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a RADIO BEARER RELEASE message to the UE. The UE release the radio bearer and transmits a RADIO BEARER RELEASE COMPLETE message on the uplink DCCH using AM RLC.

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RELEASE	
2				The UE shall release the requested radio bearer(s), and stop transmitting using these radio bearer(s).
3		→	RADIO BEARER RELEASE COMPLETE	

#### Specific Message Contents

None

#### 8.2.3.18.5 Test requirement

After step1 the UE shall cease the transmission and reception of the affected radio bearers.

After step3 the UE shall stop communicating on radio bearers to be released.



### 8.2.3.19 Radio Bearer Release for transition from CELL\_FACH to CELL\_FACH: Failure (Unsupported or Unacceptable configuration)

#### 8.2.3.19.1 Definition

.

#### 8.2.3.19.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a RADIO BEARER RELEASE message that specifies an unsupported configuration. It shall then transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC and setting the cause “configuration unacceptable” in IE” failure cause”.

#### Reference

3GPP TS 25.331 clause 8.2.3

#### 8.2.3.19.3 Test purpose

To confirm that the UE keeps its configuration and transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, if the received RADIO BEARER RELEASE message includes unsupported configuration parameters.

#### 8.2.3.19.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

#### Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a RADIO BEARER RELEASE message to the UE specifying a frequency, which cannot be supported by the UE. The UE shall transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, indicating “configuration unacceptable” in IE” failure cause”..

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RELEASE	Including an unsupported configuration for the UE
2		→	RADIO BEARER RELEASE FAILURE	The UE shall not change the radio bearer.

#### Specific Message Contents

#### RADIO BEARER RELEASE

The contents of RADIO BEARER RELEASE message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Frequency info - UARFCN uplink(Nu) - UARFCN downlink(Nd)	63984 Not Present

**RADIO BEARER RELEASE FAILURE**

Information Element	Value/remark
Message Type Failure cause Other information element	Configuration unacceptable Not checked

**8.2.3.19.5 Test requirement**

After step2 the UE shall keep its old configuration and transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, and set “configuration unacceptable” in IE” failure cause”.

**8.2.3.20 Radio Bearer Release for transition from CELL\_FACH to CELL\_FACH: Failure (Incompatible simultaneous reconfiguration)****8.2.3.20.1 Definition**

.

**8.2.3.20.2 Conformance requirement**

The UE shall keep its old configuration when the UE receives another RADIO BEARER RELEASE message, before the UE releases the radio bearer according to an earlier RADIO BEARER RELEASE message. The UE shall transmit an RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, indicating “incompatible simultaneous reconfiguration” in IE”failure cause”.

**Reference**

3GPP TS 25.331 clause 8.2.3

**8.2.3.20.3 Test purpose**

To confirm that the UE keeps its configuration when it receives another RADIO BEARER RELEASE message before it manage to release the radio bearer according to a RADIO BEARER RELEASE message.

**8.2.3.20.4 Method of test****Initial Condition**

System Simulator : 1 cell

UE : CELL\_FACH

**Test Procedure**

The UE is in the CELL\_FACH state. SS transmits a RADIO BEARER RELEASE message on the downlink DCCH, requesting the UE to release all radio access bearers established. Next, SS transmits another RADIO BEARER RELEASE message to the UE before it completes the release of the radio bearers specified in the earlier message. The UE shall keep the old configuration. It then transmits an RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, setting “incompatible simultaneous reconfiguration” in IE”failure cause”.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	RADIO BEARER RELEASE	
2		←	RADIO BEARER RELEASE	Sent before the passing of the time indicated in "Activation Time Info" in the RADIO BEARER RELEASE message of step 1.
3		→	RADIO BEARER RELEASE FAILURE	The UE does not change the configuration.

Specific Message Contents

#### RADIO BEARER RELEASE (Step 1)

The contents of RADIO BEARER RELEASE message in this test case is identical to the message sub-type titled "Packet to CELL\_FACH from CELL\_FACH in PS" in Annex A with the following exceptions:

Information Element	Value/remark
Activation Time Info	Current CFN-[current CFN mod 8 + 8 ]

#### RADIO BEARER RELEASE (Step 2)

The contents of RADIO BEARER RELEASE message in this test case is identical to the message sub-type titled "Packet to CELL\_FACH from CELL\_FACH in PS" in Annex A.

#### RADIO BEARER RELEASE FAILURE

Information Element	Value/remark
Message Type	
Failure cause	Incompatible simultaneous reconfiguration
Other information element	Not checked

#### 8.2.3.20.5 Test requirement

After step2 the UE shall keep its old configuration and transmit an RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, and setting "incompatible simultaneous reconfiguration" in IE"failure cause".

#### 8.2.3.21 Radio Bearer Release for transition from CELL\_FACH to CELL\_FACH: Failure (Invalid message reception)

##### 8.2.3.21.1 Definition

.

##### 8.2.3.21.2 Conformance requirement

The UE shall keep its old configuration when it receives a RADIO BEARER RELEASE message, including a spare value in the mandatory IE" DRX indicator". It shall transmit a RADIO BEARER RELEASE FAILURE message with the cause "protocol error" in IE" failure cause" and also the cause "Information element value not comprehended" set in IE" Protocol error cause".

#### Reference

3GPP TS 25.331 clause 8.2.3

##### 8.2.3.21.3 Test purpose

To confirm that the UE transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, if it receives a RADIO BEARER RELEASE message using a spare value in the mandatory IE" DRX indicator".

## 8.2.3.21.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

## Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a RADIO BEARER RELEASE message to the UE which includes the use of a spare value in the mandatory IE "DRX indicator". The UE shall keep the old configuration intact and transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC. The message shall state "protocol error" in IE "failure cause", and also indicate "Information element value not comprehended" in IE "Protocol error cause".

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1	←		RADIO BEARER RELEASE	This message contains a mandatory IE error.
2	→		RADIO BEARER RELEASE FAILURE	The UE does not change the configuration.

## Specific Message Contents

## RADIO BEARER RELEASE

The contents of RADIO BEARER RELEASE message in this test case is identical to those found in the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
DRX indicator	spare value

## RADIO BEARER RELEASE FAILURE

Information Element	Value/remark
Message Type	
Failure cause	
- Failure cause	Protocol error
- Protocol error information	
- Protocol error cause	Information element value not comprehended
Other information element	Not checked

## 8.2.3.21.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC. This uplink message shall state the reason "protocol error" in IE "failure cause" and also indicate "Information element value not comprehended" in IE "Protocol error cause".

## 8.2.4 Transport channel reconfiguration

## 8.2.4.1 Transport channel reconfiguration from CELL\_DCH to CELL\_DCH (Hard handover to same radio frequency): Success with no transport channel type switching

## 8.2.4.1.1 Definition

#### 8.2.4.1.2 Conformance requirement

The UE shall correctly reconfigure a radio bearer according to the TRANSPORT CHANNEL RECONFIGURATION message, which specifies a hard handover to another cell. After the completion of this procedure, the UE shall be able to communicate with the UTRAN on the new transport channel.

#### Reference

3GPP TS 25.331 clause 8.2.4

#### 8.2.4.1.3 Test purpose

To confirm that the UE reconfigures a new transport channel according to a TRANSPORT CHANNEL RECONFIGURATION message, which also specifies that a hard handover to another cell be performed simultaneously.

#### 8.2.4.1.4 Method of test

##### Initial Condition

System Simulator : 2 cells – cell 1 and cell 2 are both active

UE : CELL\_DCH in cell 1

##### Test Procedure

The UE is in the CELL\_DCH state in cell 1. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE, which includes new transport channel parameters to be applied in cell 2. The UE shall reconfigure the new transport channel and then transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH of cell 2 using AM RLC.

##### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	TRANSPORT CHANNEL RECONGURATION	Hard handover to cell 2. Including UE information elements("TFS")
2				UE shall suspend all uplink transmissions and reconfigure itself to use the new transport channel parameters
3		→	TRANSPORT CHANNEL RECONFIGURATION COMPLETE	

##### Specific Message Contents

##### TRANSPORT CHANNEL RECONFIGURATION

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type titled "Packet to CELL\_DCH from CELL\_DCH in PS" in Annex A, with the following exceptions:

Information Element	Value/remark
TrCH Information Elements	
-Uplink transport Channels	
-Added or Reconfigured TrCH information list	Number of Transport blocks = 2
-Downlink transport Channels	
-Added or Reconfigured TrCH information list	Number of Transport blocks = 2
Downlink information for each radio links	Same downlink UARFCN as used for cell 2
- Primary CPICH info	
- Primary Scrambling Code	150

#### 8.2.4.1.5 Test requirement

After step1 the UE shall reconfigure the radio links affected by the changes for uplink and downlink DCH. The UE shall stop transmitting on the uplink of cell 1.

After step3 the UE shall continue to communicate with the SS on the DCCH of cell 2, using the new Transport Format Set (TFS) applicable on the existing transport channel.

#### 8.2.4.2 Transport channel reconfiguration from CELL\_DCH to CELL\_DCH: Failure (Unsupported or Unacceptable configuration)

##### 8.2.4.2.1 Definition

##### 8.2.4.2.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a TRANSPORT CHANNEL RECONFIGURATION message which includes unsupported configuration parameters and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to “configuration unacceptable” in IE” failure cause

##### Reference

3GPP TS 25.331 clause 8.2.4

##### 8.2.4.2.3 Test purpose

To confirm that the UE transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC if the received TRANSPORT CHANNEL RECONFIGURATION message specifies unsupported configuration parameters.

##### 8.2.4.2.4 Method of test

##### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

##### Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE, which includes unsupported configuration parameters of the UE. The UE transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, reporting the event “configuration unacceptable” in IE” failure cause”.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	TRANSPORT CHANNEL RECONGURATION	Including unsupported configuration by the UE
2		→	TRANSPORT CHANNEL RECONFIGURATION FAILURE	The UE shall not change the settings used by the transport channel.

Specific Message Contents

#### TRANSPORT CHANNEL RECONFIGURATION

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
TrCH Information Elements	
-Uplink transport Channels	
-Added or Reconfigured TrCH information list	Number of Transport blocks = 4096
-Downlink transport Channels	
-Added or Reconfigured TrCH information list	Selected value as the UE can not support. Number of Transport blocks = 4096

#### TRANSPORT CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	"TRANSPORT CHANNEL RECONFIGURATION FAILURE"
Failure cause	Configuration unacceptable
Other information element	Not checked

#### 8.2.4.2.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, indicating "configuration unacceptable" in IE" failure cause".

#### 8.2.4.3 Transport channel reconfiguration from CELL\_DCH to CELL\_DCH: Failure (Physical channel failure and reversion to old configuration)

##### 8.2.4.3.1 Definition

##### 8.2.4.3.2 Conformance requirement

The UE shall revert to the old configuration when the UE fails to reconfigure the new physical channel by received TRANSPORT CHANNEL RECONFIGURATION message and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "physical channel failure" in IE" failure cause".

#### Reference

3GPP TS 25.331 clause 8.2.4

##### 8.2.4.3.3 Test purpose

To confirm that the UE reverts to the old configuration and transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, if the UE fails to reconfigure the new transport channel according to a TRANSPORT CHANNEL RECONFIGURATION message.

## 8.2.4.3.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

## Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE, which includes new transport channel parameters but it does not reconfigure the new transport channel. Therefore, the UE cannot reconfigure them and have to revert to the old configuration. Then the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting "physical channel failure" in IE" failure cause".

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	TRANSPORT CHANNEL RECONGURATION	Specifies a change in the TFS of the dedicated transport channel used.
2				The SS does not reconfigure the transport channel, leading to the UE unable to reconfigure the new transport channel.
3		→	TRANSPORT CHANNEL RECONFIGURATION FAILURE	The UE reverts to the old configuration and transmits this message.

## Specific Message Contents

## TRANSPORT CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	"TRANSPORT CHANNEL RECONFIGURATION FAILURE"
Failure cause	Physical channel failure
Other information element	Not checked

## 8.2.4.3.5 Test requirement

After step2 the UE shall revert to the old configuration and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, and it shall set the value "physical channel failure" in IE" failure cause".

## 8.2.4.4 Transport channel reconfiguration from CELL\_DCH to CELL\_DCH: Failure (Physical channel failure and reversion failure)

## 8.2.4.4.1 Definition

## 8.2.4.4.2 Conformance requirement

This procedure is used to failure of reconfiguration for a transport channel because of physical channel failure and reversion failure for the transition from CELL\_FACH to CELL\_FACH in the same cell..

## Reference

3GPP TS 25.331 clause 8.2.4



#### 8.2.4.4.3 Test purpose

To confirm that the UE initiates an RRC connection re-establishment procedure when the UE cannot reconfigure the new transport channel due to a failure of L1 configuration, and subsequently fail to revert to the old configuration after T312 expiry.

#### 8.2.4.4.4 Method of test

##### Initial Condition

System Simulator : 2 cells – Cell 1 is active, Cell 2 is inactive

UE : CELL\_DCH in cell 1

##### Test Procedure

The UE is in the CELL\_DCH state in cell 1. SS begins to broadcast the BCCH of cell 2 using a power level lower than that applied for cell 1. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE. The message specifies a new set of transport channel parameters but the SS does not reconfigure L1 correspondingly. At the same time, SS deletes its current contexts for cell 1. As a result, the UE cannot reconfigure the new transport channel and shall attempt to revert to the old configuration. The UE shall find the presence of cell 2 and then transmit an RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE "U-RNTI" on the uplink CCCH. The SS transmits an RRC CONNECTION RE-ESTABLISHMENT message, which includes a new TFCS according to the new transport channel assigned. After the UE receives an RRC CONNECTION RE-ESTABLISHMENT message, it reconfigures the new radio connection and transmits an RRC CONNECTION RE-ESTABLISHMENT COMPLETE message on the uplink DCCH using AM RLC.

##### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	BCCH	SS begins to transmit the BCCH for cell 2,
2		←	TRANSPORT CHANNEL RECONGURATION	Specifies the use of a new setting for transport channel.
3				The SS does not reconfigure L1 and deletes the old configuration present in cell 1..
4				The UE fails to reconfigure a new transport channel.
5		→	RRC CONNECTION RE-ESTABLISHMENT REQUEST	The UE detects the presence of cell.2, and then transmits this message which includes the IE "U-RNTI".
6		←	RRC CONNECTION RE-ESTABLISHMENT	Including the new TFCS according to the new transport channel.
7		→	RRC CONNECTION RE-ESTABLISHMENT COMPLETE	

##### Specific Message Contents

None

#### 8.2.4.4.5 Test requirement

After step4 the UE shall discover cell 2, enter CELL\_FACH state, and then transmit a RRC CONNECTION RE-ESTABLISHMENT REQUEST message.

After step7 the UE shall successfully re-establish an RRC connection in cell 2.

## 8.2.4.5 Transport Channel Reconfiguration from CELL\_DCH to CELL\_DCH: Failure (Incompatible simultaneous reconfiguration)

### 8.2.4.5.1 Definition

### 8.2.4.5.2 Conformance requirement

The UE shall keep its old configuration when the UE receives another TRANSPORT CHANNEL RECONFIGURATION message, before the UE completes the configuration of the transport channel according to a TRANSPORT CHANNEL RECONFIGURATION message received earlier. The UE shall transmit an TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to “incompatible simultaneous reconfiguration” in IE “failure cause”.

### Reference

3GPP TS 25.331 clause 8.2.4

### 8.2.4.5.3 Test purpose

To confirm that the UE keeps its current configuration, transmits an TRANSPORT CHANNEL RECONFIGURATION FAILURE message when it receives another TRANSPORT CHANNEL RECONFIGURATION message before the completion of an earlier reconfiguration request.

### 8.2.4.5.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

#### Test Procedure

The UE is in the CELL\_DCH state. When the SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE before the UE has successfully configured the transport channel specified in an earlier message, the UE keeps the old configuration. After that, the UE shall transmit an TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, indicating “incompatible simultaneous reconfiguration” in IE “failure cause”.

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	TRANSPORT CHANNEL RECONFIGURATION	Including IE “Uplink DPCH info”
2		←	TRANSPORT CHANNEL RECONFIGURATION	Sent before the time specified in IE “Activation Time Info” of message in step 1 has elapsed.
3		→	TRANSPORT CHANNEL RECONFIGURATION FAILURE	The UE shall not change the configuration.

#### Specific Message Contents

The contents of TRANSPORT CHANNEL RECONFIGURATION messages in this test case is identical to the corresponding message found in the default contents of layer 3 messages for RRC tests with the following exceptions:

## TRANSPORT CHANNEL RECONFIGURATION (Step 1)

Information Element	Value/remark
Activation Time	Current CFN-[current CFN mod 8 + 8 ]

## TRANSPORT CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	"TRANSPORT CHANNEL RECONFIGURATION FAILURE"
Failure cause	Incompatible simultaneous reconfiguration
Other information element	Not checked

## 8.2.4.5.5 Test requirement

After step2 the UE shall keep its configuration and transmit an TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, stating the reason "incompatible simultaneous reconfiguration" in IE"failure cause".

## 8.2.4.6 Transport channel reconfiguration from CELL\_DCH to CELL\_DCH: Failure (Invalid message reception)

## 8.2.4.6.1 Definition

## 8.2.4.6.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a TRANSPORT CHANNEL RECONFIGURATION message which makes use of a spare value in the mandatory IE" DRX indicator". Then it shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message with the value "protocol error" set in IE" failure cause" and also "Information element value not comprehended" in IE" Protocol error cause".

## Reference

3GPP TS 25.331 clause 8.2.4

## 8.2.4.6.3 Test purpose

To confirm that the UE transmits TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, if the received TRANSPORT CHANNEL RECONFIGURATION message comprises a spare value in the mandatory IE" DRX indicator".

## 8.2.4.6.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

## Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE, which includes a spare value in the mandatory IE" DRX indicator". The UE shall keep the old configuration and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, specifying "protocol error" in IE" failure cause" and also indicating "Information element value not comprehended" in IE" Protocol error cause".

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	TRANSPORT CHANNEL RECONFIGURATION	Contains an illegal value for a mandatory IE
2		→	TRANSPORT CHANNEL RECONFIGURATION FAILURE	The UE does not change the configuration.

Specific Message Contents

#### TRANSPORT CHANNEL RECONFIGURATION

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to those in the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
DRX indicator	spare value

#### TRANSPORT CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	"TRANSPORT CHANNEL RECONFIGURATION FAILURE"
Failure cause	
- Failure cause	Protocol error
- Protocol error information	
- Protocol error cause	Information element value not comprehended
Other information element	Not checked

#### 8.2.4.6.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC. The message shall specify "protocol error" in IE" failure cause" and set value "Information element value not comprehended" in IE" Protocol error cause".

#### 8.2.4.7 Transport channel reconfiguration from CELL\_DCH to CELL\_FACH: Success

##### 8.2.4.7.1 Definition

##### 8.2.4.7.2 Conformance requirement

The UE shall correctly reconfigure the transport channels according to TRANSPORT CHANNEL RECONFIGURATION message, after it is requested to perform a transition from CELL\_DCH to CELL\_FACH in the same cell in conjunction with the transport channel reconfiguration.

#### Reference

3GPP TS 25.331 clause 8.2.4

##### 8.2.4.7.3 Test purpose

To confirm that the UE reconfigures a new Transport channel according to a TRANSPORT CHANNEL RECONFIGURATION message received from the SS.

##### 8.2.4.7.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

### Test Procedure

The UE is in the CELL\_DCH state. The SS transmits TRANSPORT CHANNEL RECONFIGURATION message to the UE which omits IE“ Uplink DPCH info” and IE” Downlink DPCH info” . This should cause the UE to perform a state transition from CELL\_DCH to CELL\_FACH in the same cell. The UE then reconfigures the new transport channel according to this message and reconfigure the new physical channel according to the system information messages. Finally, the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message using AM RLC.

### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	TRANSPORT CHANNEL RECONFIGURATION	IE”Uplink DPCH Info” and IE”Downlink DPCH Info” are not specified.
2				UE shall perform the reconfiguration of transport channel
3		→	TRANSPORT CHANNEL RECONFIGURATION COMPLETE	

### Specific Message Contents

None.

#### 8.2.4.7.5 Test requirement

After step3 the UE shall transit from CELL\_DCH to CELL\_FACH in the same cell, and then continue to communicate with SS on the new transport channel and common physical channels.

#### 8.2.4.8 Transport channel reconfiguration from CELL\_DCH to CELL\_FACH: Failure (Unsupported or Unacceptable configuration)

##### 8.2.4.8.1 Definition

##### 8.2.4.8.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a TRANSPORT CHANNEL RECONFIGURATION message which includes unsupported configuration parameters and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to “configuration unacceptable” in IE” failure cause

### Reference

3GPP TS 25.331 clause 8.2.4

##### 8.2.4.8.3 Test purpose

To confirm that the UE transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC if the received TRANSPORT CHANNEL RECONFIGURATION message includes unsupported configuration parameters.

## 8.2.4.8.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

## Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE, which includes unsupported configuration parameters for the UE. The UE transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to “configuration unacceptable” in IE” failure cause”.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	TRANSPORT CHANNEL RECONGURATION	Including an unsupported transport channel configuration for the UE
2		→	TRANSPORT CHANNEL RECONFIGURATION FAILURE	The UE does not change the transport channel.

## Specific Message Contents

## TRANSPORT CHANNEL RECONFIGURATION

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
TrCH Information Elements -Uplink transport Channels >Added or Reconfigured TrCH information list	Number of transport blocks = 4096
-Downlink transport Channels >Added or Reconfigured TrCH information list	Number of transport blocks = 4096

## TRANSPORT CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	
Failure cause	Configuration unacceptable
Other information element	Not checked

## 8.2.4.8.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, which shall contains cause “configuration unacceptable” in IE” failure cause”.

## 8.2.4.9 Transport channel reconfiguration from CELL\_DCH to CELL\_FACH: Failure (Physical channel failure and reversion to old configuration)

## 8.2.4.9.1 Definition

#### 8.2.4.9.2 Conformance requirement

The UE shall revert the old configuration when it fails to reconfigure the new transport channel requested. When reversion is successful, it shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message to UTRAN.

#### Reference

3GPP TS 25.331 clause 8.2.4

#### 8.2.4.9.3 Test purpose

To confirm that the UE reverts to the old configuration and transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, if the UE fails to reconfigure the new transport channel according to the TRANSPORT CHANNEL RECONFIGURATION message received.

#### 8.2.4.9.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

#### Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE which includes the new transport channel parameters. However, it does not reconfigure the new transport channel to reflect change. As a result, the UE should encounter difficulties in the reconfigure process and after T312 expiry, it shall revert to its stored old configuration. When the UE manages to return to the old configuration, it transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC and set the reason "physical channel failure" in IE" failure cause".

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	TRANSPORT CHANNEL RECONGURATION	
2				The SS does not reconfigure the transport channel hence the UE could not access the new transport channel.
3		→	TRANSPORT CHANNEL RECONFIGURATION FAILURE	After T312 expiry, the UE reverts to the old configuration and transmits this message using the original transport channel settings.

Specific Message Contents

#### TRANSPORT CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	TRANSPORT CHANNEL RECONFIGURATION FAILURE
Failure cause	Physical channel failure
Other information element	Not checked

#### 8.2.4.9.5 Test requirement

After step2 the UE shall attempt revert to the old configuration and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC. The failure message shall contain the reason "physical channel failure" in IE" failure cause".

#### 8.2.4.10 Transport channel reconfiguration from CELL\_DCH to CELL\_FACH: Failure (Physical channel failure and reversion failure)

##### 8.2.4.10.1 Definition

##### 8.2.4.10.2 Conformance requirement

The UE shall initiate a RRC connection re-establishment procedure, after it encounters a physical channel failure followed by an inability to revert to the old transport channel configuration.

#### Reference

3GPP TS 25.331 clause 8.2.4

##### 8.2.4.10.3 Test purpose

To confirm that the UE initiates an RRC connection re-establishment procedure when the UE fails successively in the following actions: (a) configure the new transport channel according to TRANSPORT CHANNEL RECONFIGURATION message received and (b) revert to the old channel configuration after timer T312 expiry.

##### 8.2.4.10.4 Method of test

#### Initial Condition

System Simulator : 2 cells - Cell 1 is active, Cell 2 is inactive

UE : CELL\_DCH in cell 1



## Test Procedure

The UE is in the CELL\_DCH state in cell 1. SS begins to transmit the BCCH for cell 2. The SS then transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE, which specifies the new transport channel parameters on common physical channel. But the SS does not reconfigure the L1 parameters and the new transport channel to reflect this change. Consequently, the UE discovers that it cannot reconfigure the new transport channel and try to revert to the old configuration. At this time, SS deletes all context related to the old configuration in cell 1. Then the UE should find cell 2 and transmits an RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE"U-RNTI" on the uplink CCCH. After the reception of such a message, the SS transmits an RRC CONNECTION RE-ESTABLISHMENT message and includes a new TFCS for the new transport channel in cell 2. After receiving this message, the UE reconfigures the new radio connection and transmits an RRC CONNECTION RE-ESTABLISHMENT COMPLETE message on the uplink DCCH using AM RLC.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	BCCH	The SS starts to transmit the BCCH cell 2.
2		←	TRANSPORT CHANNEL RECONGURATION	
3				The SS does not reconfigure L1. At the same time, it deletes the old channel configuration.
4				The UE fails to reconfigure a new transport channel.
5		→	RRC CONNECTION RE-ESTABLISHMENT REQUEST	The UE shall discover the presence of cell 2 and transmits this message, which includes the IE"U-RNTI".
6		←	RRC CONNECTION RE-ESTABLISHMENT	A new TFCS is commanded according to the new transport channel.
7		→	RRC CONNECTION RE-ESTABLISHMENT COMPLETE	

## Specific Message Contents

None

### 8.2.4.10.5 Test requirement

After step4 the UE shall find cell 2, enter CELL\_FACH state and then initiate RRC connection re-establishment procedure in cell 2.

After step7 the UE shall successfully re-establish an RRC connection in cell 2.

### 8.2.4.11 Transport Channel Reconfiguration from CELL\_DCH to CELL\_FACH: Failure (Incompatible simultaneous reconfiguration)

#### 8.2.4.11.1 Definition

#### 8.2.4.11.2 Conformance requirement

The UE shall keep its old configuration when the UE receives another TRANSPORT CHANNEL RECONFIGURATION message before the UE configures the transport channel, according to an earlier TRANSPORT CHANNEL RECONFIGURATION message. The UE shall transmit an TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC which specifies "incompatible simultaneous reconfiguration" in IE"failure cause".

## Reference

3GPP TS 25.331 clause 8.2.4

## 8.2.4.11.3 Test purpose

To confirm that the UE keeps its configuration and transmits an TRANSPORT CHANNEL RECONFIGURATION FAILURE message when the UE receives another TRANSPORT CHANNEL RECONFIGURATION message, before the UE had completed the configuration of the transport channel originating from an earlier TRANSPORT CHANNEL RECONFIGURATION message.

## 8.2.4.11.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

## Test Procedure

The UE is in the CELL\_DCH state. SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to request for a reconfiguration of the transport channel, leading to a state transition to CELL\_FACH. However, before the completion of this process, SS sends a second TRANSPORT CHANNEL RECONFIGURATION message. The UE shall keep the old configuration as if no reconfiguration has occurred and then transmit an TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC. The status message shall indicate "incompatible simultaneous reconfiguration" in IE "failure cause".

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	TRANSPORT CHANNEL RECONFIGURATION	IE "Activation Time Info" is included
2		←	TRANSPORT CHANNEL RECONFIGURATION	Sent before the activation time requested in step 1 has passed.
3		→	TRANSPORT CHANNEL RECONFIGURATION FAILURE	The UE does not change the configuration.

## Specific Message Contents

## TRANSPORT CHANNEL RECONFIGURATION (Step 1)

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Activation Time Info	Current CFN-[current CFN mod 8 + 8 ]

## TRANSPORT CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	"TRANSPORT CHANNEL RECONFIGURATION FAILURE"
Failure cause	Incompatible simultaneous reconfiguration
Other information element	Not checked

## 8.2.4.11.5 Test requirement

After step2 the UE shall keep its configuration and then transmit an TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, containing the reason "incompatible simultaneous reconfiguration" in IE "failure cause".

## 8.2.4.12 Transport channel reconfiguration from CELL\_DCH to CELL\_FACH: Failure (Invalid message reception)

### 8.2.4.12.1 Definition

### 8.2.4.12.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a TRANSPORT CHANNEL RECONFIGURATION message which makes use of a spare value in the mandatory IE "DRX indicator". Then it shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message, setting the value "protocol error" in IE "failure cause" and also setting "Information element value not comprehended" in IE "Protocol error cause".

### Reference

3GPP TS 25.331 clause 8.2.4

### 8.2.4.12.3 Test purpose

To confirm that the UE transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC if it receives a TRANSPORT CHANNEL RECONFIGURATION message which uses a spare value in the mandatory IE "DRX indicator".

### 8.2.4.12.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

#### Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE, and includes a spare value in the mandatory IE "DRX indicator". The UE shall keep the old configuration and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC. The message shall specify "protocol error" in IE "failure cause" and also "Information element value not comprehended" in IE "Protocol error cause".

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	TRANSPORT CHANNEL RECONFIGURATION	Contains a mandatory IE error.
2		→	TRANSPORT CHANNEL RECONFIGURATION FAILURE	The UE shall not change the configuration.

#### Specific Message Contents

#### TRANSPORT CHANNEL RECONFIGURATION

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
DRX indicator	spare value

#### TRANSPORT CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	"TRANSPORT CHANNEL RECONFIGURATION FAILURE"
Failure cause	
- Failure cause	Protocol error
- Protocol error information	
- Protocol error cause	Information element value not comprehended
Other information element	Not checked

#### 8.2.4.12.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC. The UE shall set "protocol error" in IE" failure cause" and also "Information element value not comprehended" in IE" Protocol error cause".

#### 8.2.4.13 Transport channel reconfiguration from CELL\_FACH to CELL\_DCH : Success

##### 8.2.4.13.1 Definition

##### 8.2.4.13.2 Conformance requirement

The UE shall correctly reconfigure the transport channels according to TRANSPORT CHANNEL RECONFIGURATION message, which trigger a state transition from CELL\_FACH to CELL\_DCH in the same cell.

##### Reference

3GPP TS 25.331 clause 8.2.4

##### 8.2.4.13.3 Test purpose

To confirm that the UE reconfigures a new transport channel using dedicated physical channel according to a TRANSPORT CHANNEL RECONFIGURATION message received from the SS.

##### 8.2.4.13.4 Method of test

##### Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

##### Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE, which includes IE" Uplink DPCH info" and IE" Downlink DPCH info" leading to a state transition from CELL\_FACH to CELL\_DCH in the same cell. The UE shall reconfigure the new transport channel according to this message and then reconfigure the new physical channel according to the system information message. Finally, the UE transmits a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message using AM RLC.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	TRANSPORT CHANNEL RECONFIGURATION	Includes both IE"Uplink DPCH Info" and IE"Downlink DPCH Info" in the message.
2				Reconfiguration of transport channel
3		→	TRANSPORT CHANNEL RECONFIGURATION COMPLETE	

Specific Message Contents

None.

#### 8.2.4.13.5 Test requirement

After step3 the UE shall transit from CELL\_FACH to CELL\_DCH in the same cell, and continue to communicate with SS using the new transport channel configuration based on DPCH physical channels.

#### 8.2.4.14 Transport channel reconfiguration from CELL\_FACH to CELL\_DCH: Failure (Unsupported or Unacceptable configuration)

##### 8.2.4.14.1 Definition

##### 8.2.4.14.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a TRANSPORT CHANNEL RECONFIGURATION message which includes unsupported configuration parameters and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "configuration unacceptable" in IE" failure cause

#### Reference

3GPP TS 25.331 clause 8.2.4

##### 8.2.4.14.3 Test purpose

To confirm that the UE transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC when it receives a TRANSPORT CHANNEL RECONFIGURATION message which includes unsupported configuration parameters.

##### 8.2.4.14.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

#### Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE, which includes unsupported configuration parameters for the UE. The UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting "configuration unacceptable" in IE" failure cause".

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	TRANSPORT CHANNEL RECONGURATION	The message includes unsupported configuration by the UE
2		→	TRANSPORT CHANNEL RECONFIGURATION FAILURE	The UE shall not change the transport channel.

Specific Message Contents

#### TRANSPORT CHANNEL RECONFIGURATION

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to those in the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
TrCH Information Elements -Uplink transport Channels -Added or Reconfigured TrCH information list	Number of transport channels = 4096
-Downlink transport Channels -Added or Reconfigured TrCH information list	Number of transport channels = 4096

#### TRANSPORT CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	"TRANSPORT CHANNEL RECONFIGURATION FAILURE"
Failure cause	Configuration unacceptable
Other information element	Not checked

##### 8.2.4.14.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC. The UE shall set "configuration unacceptable" in IE" failure cause" of the message.

#### 8.2.4.15 Transport channel reconfiguration from CELL\_FACH to CELL\_DCH: Failure (Physical channel failure and reversion to old channel)

##### 8.2.4.15.1 Definition

##### 8.2.4.15.2 Conformance requirement

The UE shall revert to the old configuration when the UE has failed to reconfigure the new transport channel requested, and then transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message to UTRAN.

#### Reference

3GPP TS 25.331 clause 8.2.4

##### 8.2.4.15.3 Test purpose

To confirm that the UE reverts to the old configuration and transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, if the UE fails to reconfigure the new transport channel according to a TRANSPORT CHANNEL RECONFIGURATION message.

## 8.2.4.15.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

## Test Procedure

The UE is in the CELL\_DCH state. SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE, which includes the new transport channel parameters. However, SS does not reconfigure the new transport channel accordingly. Hence, the UE shall experience a failure in the reconfiguration process. After T312 expiry, the UE shall revert to the old channel configuration. Then the UE transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, stating the reason “physical channel failure” in IE” failure cause”.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	TRANSPORT CHANNEL RECONGURATION	Message includes IE“Downlink DPCH Info” and IE“Uplink DPCH Info”
2				SS does not reconfigure the transport channel causing the UE to detect a physical channel failure.
3		→	TRANSPORT CHANNEL RECONFIGURATION FAILURE	After T312 expiry the UE shall revert to the old configuration and transmit this message.

## Specific Message Contents

## TRANSPORT CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	TRANSPORT CHANNEL RECONFIGURATION FAILURE
Failure cause	Physical channel failure
Other information element	Not checked

## 8.2.4.15.5 Test requirement

After step2 the UE shall revert to the old configuration and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting the value “physical channel failure” in IE” failure cause”.

## 8.2.4.16 Transport channel reconfiguration from CELL\_FACH to CELL\_DCH: Failure (Physical channel failure and reversion failure)

## 8.2.4.16.1 Definition

## 8.2.4.16.2 Conformance requirement

The UE shall initiate a RRC re-establishment procedure when it fails to revert to the old channel configuration, following a physical channel failure in the transport channel reconfiguration procedure.

## Reference

3GPP TS 25.331 clause 8.2.4

## 8.2.4.16.3 Test purpose

To confirm that the UE initiates an RRC connection re-establishment procedure, when the UE cannot reconfigure the new transport channel for the failure of L1 configuration and subsequently fails to revert to the old configuration after T312 expiry.

## 8.2.4.16.4 Method of test

## Initial Condition

System Simulator : 2 cells - Cell 1 is active, Cell 2 is inactive

UE : CELL\_FACH in cell 1

## Test Procedure

The UE is in the CELL\_FACH state in a cell 1. SS begins to broadcast the BCCH of cell 2 at a power level lower than in cell 1, and then it transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE in cell 1. The message includes a new set of transport channel parameters. However, the SS does not reconfigure L1 and the new transport channel accordingly. At the same time, it deletes the current channel configurations in cell 1. As a result, the UE cannot reconfigure the new transport channel and an attempt to revert to the old configuration fails. The UE shall then find that cell 2 is available, camp onto it, and transmits an RRC CONNECTION RE-ESTABLISHMENT REQUEST message. This message shall include the IE "U-RNTI" on the uplink CCCH. When the SS receives this message, it transmits an RRC CONNECTION RE-ESTABLISHMENT message, which specifies a new TFCS according to the new transport channel used. After the UE receives this message, it reconfigures the new radio connection and transmits an RRC CONNECTION RE-ESTABLISHMENT COMPLETE message on the uplink DCCH using AM RLC.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	BCCH	The SS starts to transmit BCCH in cell 2
2		←	TRANSPORT CHANNEL RECONGURATION	
3				The SS does not reconfigure L1 and transport channel, it also deletes its current contexts for cell 1.
4				The UE shall experience a failure to reconfigure a new transport channel and also fails to revert to old configuration.
5		→	RRC CONNECTION RE-ESTABLISHMENT REQUEST	The UE shall find cell 2, camp onto it, and then transmits this message which includes the IE "U-RNTI".
6		←	RRC CONNECTION RE-ESTABLISHMENT	Including the new TFCS according to the new transport channel.
7		→	RRC CONNECTION RE-ESTABLISHMENT COMPLETE	

## Specific Message Contents

None

## 8.2.4.16.5 Test requirement

After step4 the UE shall find the presence of cell 2, enter CELL\_FACH state, and transmit RRC RE-ESTABLISHMENT REQUEST message to attempt to setup the RRC connection in cell 2.



After step7 the UE shall successfully re-establish the RRC connection in cell 2.

#### 8.2.4.17 Transport Channel Reconfiguration from CELL\_FACH to CELL\_DCH: Failure (Incompatible simultaneous reconfiguration)

##### 8.2.4.17.1 Definition

##### 8.2.4.17.2 Conformance requirement

The UE shall keep its old configuration when it receives another TRANSPORT CHANNEL RECONFIGURATION message before it can configure the transport channel according to a TRANSPORT CHANNEL RECONFIGURATION message received earlier. The UE shall transmit an TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting "incompatible simultaneous reconfiguration" in IE" failure cause".

##### Reference

3GPP TS 25.331 clause 8.2.4

##### 8.2.4.17.3 Test purpose

To confirm that the UE keeps its configuration and transmits an TRANSPORT CHANNEL RECONFIGURATION FAILURE message when it receives another TRANSPORT CHANNEL RECONFIGURATION message before the completion of an earlier request for transport channel reconfiguration.

##### 8.2.4.17.4 Method of test

##### Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

##### Test Procedure

The UE is in the CELL\_FACH state. When the SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE before it has successfully configured the transport channel based on an earlier request. It shall respond by keeping the old configuration and then transmitting an TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC. The content of the failure message shall indicate "incompatible simultaneous reconfiguration" in IE"failure cause".

##### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	TRANSPORT CHANNEL RECONFIGURATION	Includes the IE"Uplink DPCH info"
2		←	TRANSPORT CHANNEL RECONFIGURATION	Sent before the elapse of the activation time specified in step 1.
3		→	TRANSPORT CHANNEL RECONFIGURATION FAILURE	The UE does not change the configuration.

##### Specific Message Contents

##### TRANSPORT CHANNEL RECONFIGURATION (Step 1)

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Activation Time Info	Current CFN-[current CFN mod 8 + 8 ]

#### TRANSPORT CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	"TRANSPORT CHANNEL RECONFIGURATION FAILURE"
Failure cause	Incompatible simultaneous reconfiguration
Other information element	Not checked

#### 8.2.4.17.5 Test requirement

After step2 the UE shall keep its configuration and transmit an TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting the value to "incompatible simultaneous reconfiguration" in IE"failure cause".

#### 8.2.4.18 Transport channel reconfiguration from CELL\_FACH to CELL\_DCH:Failure (Invalid message reception)

##### 8.2.4.18.1 Definition

##### 8.2.4.18.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a TRANSPORT CHANNEL RECONFIGURATION message which includes a spare value in the mandatory IE" DRX indicator". The UE shall then transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message, specifying "protocol error" in IE" failure cause" and also "Information element value not comprehended" in IE" Protocol error cause".

#### Reference

3GPP TS 25.331 clause 8.2.4

##### 8.2.4.18.3 Test purpose

To confirm that the UE transmits TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, if it receives a TRANSPORT CHANNEL RECONFIGURATION message which uses a spare value in the mandatory IE" DRX indicator".

##### 8.2.4.18.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

#### Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE, which includes a spare value in the mandatory IE" DRX indicator". The UE shall keep the old configuration and then transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC. This message shall contain the value "protocol error" in IE" failure cause" and also "Information element value not comprehended" in IE" Protocol error cause".

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	TRANSPORT CHANNEL RECONFIGURATION	Contains a error in one of the mandatory IE in the message.
2		→	TRANSPORT CHANNEL RECONFIGURATION FAILURE	The UE does not change the configuration.

Specific Message Contents

#### TRANSPORT CHANNEL RECONFIGURATION

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
DRX indicator	spare value

#### TRANSPORT CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	"TRANSPORT CHANNEL RECONFIGURATION FAILURE"
Failure cause	
- Failure cause	Protocol error
- Protocol error information	
- Protocol error cause	Information element value not comprehended
Other information element	Not checked

#### 8.2.4.18.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC. The content of the message shall specify "protocol error" in IE" failure cause" and also "Information element value not comprehended" in IE" Protocol error cause".

#### 8.2.4.19 Transport channel reconfiguration from CELL\_FACH to CELL\_FACH: Success with no transport channel type switching

##### 8.2.4.19.1 Definition

##### 8.2.4.19.2 Conformance requirement

The UE shall remain in CELL\_FACH state and transition from CELL\_FACH to CELL\_FACH in the another cell requested in the received TRANSPORT CHANNEL RECONFIGURATION message.

#### Reference

3GPP TS 25.331 clause 8.2.4

##### 8.2.4.19.3 Test purpose

To confirm that the UE reconfigures a new transport channel according to a TRANSPORT CHANNEL RECONFIGURATION message received from the SS.

##### 8.2.4.19.4 Method of test

#### Initial Condition

System Simulator : 2 cells Cell 1 is active, Cell 2 is inactive

UE : CELL\_FACH

### Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE, which includes new transport channel parameters for Hand Over. The UE reconfigures the new transport channel and transmits a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message using AM RLC.

### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	BCCH	The SS starts to broadcast the BCCH in cell 2.
2		←	TRANSPORT CHANNEL RECONGURATION	Including Primary CPICH Info
3				Reconfiguration of a new transport channel
4		→	TRANSPORT CHANNEL RECONFIGURATION COMPLETE	

### Specific Message Contents

None

### 8.2.4.19.5 Test requirement

After step3 the UE shall transit from CELL\_FACH to CELL\_FACH in the another cell and continue to communicate with the SS on the DCCH using the existing transport channel.

### 8.2.4.20 Transport channel reconfiguration from CELL\_FACH to CELL\_FACH: Failure (Unsupported or Unacceptable configuration)

#### 8.2.4.20.1 Definition

#### 8.2.4.20.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a TRANSPORT CHANNEL RECONFIGURATION message which includes unsupported configuration parameters and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to “configuration unacceptable” in IE” failure cause

### Reference

3GPP TS 25.331 clause 8.2.4

#### 8.2.4.20.3 Test purpose

To confirm that the UE transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC if the received TRANSPORT CHANNEL RECONFIGURATION message specifies unsupported configuration parameters.

#### 8.2.4.20.4 Method of test

### Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

### Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE, which includes unsupported configuration parameters of the UE. The UE transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, reporting the event "configuration unacceptable" in IE" failure cause".

### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	TRANSPORT CHANNEL RECONGURATION	Including unsupported configuration by the UE
2		→	TRANSPORT CHANNEL RECONFIGURATION FAILURE	The UE shall not change the settings used by the transport channel.

### Specific Message Contents

#### TRANSPORT CHANNEL RECONFIGURATION

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
TrCH Information Elements -Uplink transport Channels -Added or Reconfigured TrCH information list	Number of Transport blocks = 4096
-Downlink transport Channels -Added or Reconfigured TrCH information list	Selected value as the UE can not support. Number of Transport blocks = 4096

#### TRANSPORT CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	"TRANSPORT CHANNEL RECONFIGURATION FAILURE"
Failure cause	Configuration unacceptable
Other information element	Not checked

#### 8.2.4.20.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, indicating "configuration unacceptable" in IE" failure cause".

#### 8.2.4.21 Transport channel reconfiguration from CELL\_FACH to CELL\_FACH: Failure (Physical channel failure)

##### 8.2.4.21.1 Definition

##### 8.2.4.21.2 Conformance requirement

The UE shall initiate the cell reselection procedure when the UE cannot use the assigned physical channel according to a TRANSPORT CHANNEL RECONFIGURATION message, during the transition from CELL\_FACH to CELL\_FACH in the another cell.

## Reference

3GPP TS 25.331 clause 8.2.4

## 8.2.4.21.3 Test purpose

To confirm that the UE perform a cell reselection and cell update procedure when the it fail to access the assigned physical channel, according to a TRANSPORT CHANNEL RECONFIGURATION message, during the transition from CELL\_FACH to CELL\_FACH in the another cell.

## 8.2.4.21.4 Method of test

## Initial Condition

System Simulator : 3 cells Cell 1 is active, Cell 2 is inactive, Cell 3 is inactive

UE : CELL\_FACH

## Test Procedure

The UE is in the CELL\_FACH state in cell 1. The SS begins to broadcast the BCCH in cell 2 and then transmits a TRANSPORT CHANNEL RECONFIGURATION message, resulting in the UE to attempt to transit from CELL\_FACH in cell 1 to CELL\_FACH in cell 3. The UE is expected to fail to access the assigned physical channel as the SS ceases downlink transmission in cell 3. After the UE successfully camp onto cell 2, it shall initiate the cell update procedure in cell 2. The procedure completes when the SS confirms UE's cell update request.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	BCCH	The SS starts to broadcast the BCCH in cell 2.
2		←	TRANSPORT CHANNEL RECONFIGURATION	The message assigns common resources so that the UE is expected to execute a transition from CELL_FACH in cell 1 to CELL_FACH in cell 3
3				The UE shall detect a failure to use the assigned common physical channel and try to perform a cell reselection.
4		→	CELL UPDATE	The UE discover the presence of cell 2 and triggers a cell update procedure.
5		←	CELL UPDATE CONFIRM	SS sends this message so that the UE moves to CELL_PCH state.

## Specific Message Contents

None

## 8.2.4.21.5 Test requirement

After step3 the UE shall discover the presence of cell 2, enter CELL\_FACH state, and initiate a cell update procedure in that cell.

## 8.2.4.22 Transport Channel Reconfiguration from CELL\_FACH to CELL\_FACH: Failure (Incompatible simultaneous reconfiguration)

### 8.2.4.22.1 Definition

### 8.2.4.22.2 Conformance requirement

The UE shall keep its old configuration when the UE receives another TRANSPORT CHANNEL RECONFIGURATION message, before the UE completes the configuration of the transport channel according to a TRANSPORT CHANNEL RECONFIGURATION message received earlier. The UE shall transmit an TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to “incompatible simultaneous reconfiguration” in IE “failure cause”.

### Reference

3GPP TS 25.331 clause 8.2.4

### 8.2.4.22.3 Test purpose

To confirm that the UE keeps its current configuration, transmits an TRANSPORT CHANNEL RECONFIGURATION FAILURE message when it receives another TRANSPORT CHANNEL RECONFIGURATION message before the completion of an earlier reconfiguration request.

### 8.2.4.22.4 Method of test

### Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

### Test Procedure

The UE is in the CELL\_FACH state. When the SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE before the UE has successfully configured the transport channel specified in an earlier message, the UE keeps the old configuration. After that, the UE shall transmit an TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, indicating “incompatible simultaneous reconfiguration” in IE “failure cause”.

### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	TRANSPORT CHANNEL RECONFIGURATION	Including IE “Uplink DPCH info”
2		←	TRANSPORT CHANNEL RECONFIGURATION	Sent before the time specified in IE “Activation Time Info” of message in step 1 has elapsed.
3		→	TRANSPORT CHANNEL RECONFIGURATION FAILURE	The UE shall not change the configuration.

### Specific Message Contents

The contents of TRANSPORT CHANNEL RECONFIGURATION messages in this test case is identical to the corresponding message found in the default contents of layer 3 messages for RRC tests with the following exceptions:

## TRANSPORT CHANNEL RECONFIGURATION (Step 1)

Information Element	Value/remark
Activation Time	Current CFN-[current CFN mod 8 + 8 ]

## TRANSPORT CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	"TRANSPORT CHANNEL RECONFIGURATION FAILURE"
Failure cause	Incompatible simultaneous reconfiguration
Other information element	Not checked

## 8.2.4.22.5 Test requirement

After step2 the UE shall keep its configuration and transmit an TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, stating the reason "incompatible simultaneous reconfiguration" in IE"failure cause".

## 8.2.4.23 Transport channel reconfiguration from CELL\_FACH to CELL\_FACH: Failure (Invalid message reception)

## 8.2.4.23.1 Definition

## 8.2.4.23.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a TRANSPORT CHANNEL RECONFIGURATION message which makes use of a spare value in the mandatory IE" DRX indicator". Then it shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message with the value "protocol error" set in IE" failure cause" and also "Information element value not comprehended" in IE" Protocol error cause".

## Reference

3GPP TS 25.331 clause 8.2.4

## 8.2.4.23.3 Test purpose

To confirm that the UE transmits TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, if the received TRANSPORT CHANNEL RECONFIGURATION message comprises a spare value in the mandatory IE" DRX indicator".

## 8.2.4.23.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

## Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE, which includes a spare value in the mandatory IE" DRX indicator". The UE shall keep the old configuration and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, specifying "protocol error" in IE" failure cause" and also indicating "Information element value not comprehended" in IE" Protocol error cause".



Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	TRANSPORT CHANNEL RECONFIGURATION	Contains an illegal value for a mandatory IE
2		→	TRANSPORT CHANNEL RECONFIGURATION FAILURE	The UE does not change the configuration.

Specific Message Contents

## TRANSPORT CHANNEL RECONFIGURATION

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to those in the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
DRX indicator	spare value

## TRANSPORT CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	"TRANSPORT CHANNEL RECONFIGURATION FAILURE"
Failure cause	
- Failure cause	Protocol error
- Protocol error information	
- Protocol error cause	Information element value not comprehended
Other information element	Not checked

### 8.2.4.23.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC. The message shall specify "protocol error" in IE" failure cause" and set value "Information element value not comprehended" in IE" Protocol error cause".

## 8.2.5 Transport format combination control

### 8.2.5.1 Transport format combination control in CELL\_DCH : restriction

#### 8.2.5.1.1 Definition

#### 8.2.5.1.2 Conformance requirement

The UE shall change the subset of allowed transport format combination of uplink when the UE receives TRANSPORT FORMAT COMBINATION CONTROL message.

#### Reference

3GPP TS 25.331 clause 8.2.5

#### 8.2.5.1.3 Test purpose

To confirm that the UE do not transmit data on the DTCH in the uplink direction, following the reception of TRANSPORT FORMAT COMBINATION CONTROL message sent from the SS, which is set to "zero" in IE" Minimum allowed Transport format combination index".

## 8.2.5.1.4 Method of test

## Initial Condition

System Simulator : 1cell

UE :CELL\_DCH

## Test Procedure

The UE establishes a radio access bearer on the DCH for a communication. The SS transmits a TRANSPORT FORMAT COMBINATION CONTROL message, which indicates that only  $TFC_0$  is allowed on the uplink for DCH transport channel. The UE shall reconfigure the TFCS, stop any transmission on DTCH logical channel and then continues the communication on DCCH only.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				UE s in CELL_DCH state with a DTCH logical channel allocated for communication between UE and SS
2		←	TRANSPORT FORMAT COMBINATION CONTROL	Set to "zero" in IE" Minimum allowed Transport format combination index".
3				The UE shall not transmit any data on the DTCH.

## Specific Message Contents

## TRANSPORT FORMAT COMBINATION CONTROL

Information Element	Value/remark
TrCH information elements -Minimum allowed Transport format combination index	Set to "zero"

## 8.2.5.1.5 Test requirement

After step2 the UE shall stop transmitting data on the DTCH in the uplink.

## 8.2.5.2 Transport format combination control in CELL\_DCH: release a restriction

## 8.2.5.2.1 Definition

## 8.2.5.2.2 Conformance requirement

The UE shall change the subset of allowed transport format combination of uplink when it receives TRANSPORT FORMAT COMBINATION CONTROL message, specifying that an existing restriction for the usage of TFCS be removed.

## Reference

GPP TS 25.331 clause 8.2.5

### 8.2.5.2.3 Test purpose

To confirm that the UE resume transmission of data on the DTCH on the uplink, following the reception of TRANSPORT FORMAT COMBINATION CONTROL message which is set to “one” as the prior used transport format combination number in IE” Minimum allowed Transport format combination index”.

### 8.2.5.2.4 Method of test

Initial Condition

System Simulator : 1cell

UE : CELL\_DCH with DTCH allocated but fully restricted.

### Test Procedure

The UE is in CELL\_DCH state with DTCH allocated but fully restricted. The UE cannot transmit the data on the DTCH, as a result of the restriction on the transport format combination. Next, the SS transmits a TRANSPORT FORMAT COMBINATION CONTROL message which is set to “one” in IE” Minimum allowed Transport format combination index”

### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				No data transmission on the DTCH with a restriction in the uplink direction, following the execution of test 8.1.2.5.1.
2		←	TRANSPORT FORMAT COMBINATION CONTROL	Set to “one” IE” Minimum allowed Transport format combination index”.
3				The UE begins to transmit the data on the DTCH.

### Specific Message Contents

### TRANSPORT FORMAT COMBINATION CONTROL

Information Element	Value/remark
TrCH information elements -Minimum allowed Transport format combination index	Set to “one”

### 8.2.5.2.5 Test requirement

After step2 the UE shall begin to transmit the data on the DTCH in the uplink.

## 8.2.5.3 Transport format combination control in CELL\_DCH: Failure (Incompatible simultaneous reconfiguration)

### 8.2.5.3.1 Definition

### 8.2.5.3.2 Conformance requirement

The UE shall keep its old configuration when the UE receives another TRANSPORT FORMAT COMBINATION CONTROL message before the UE reconfigures the transport channel completely according to a similar message received earlier. The UE shall transmit an TRANSPORT FORMAT COMBINATION CONTROL FAILURE message on the DCCH using AM RLC indicating “incompatible simultaneous reconfiguration” in IE”failure cause”.

## Reference

3GPP TS 25.331 clause 8.2.5

### 8.2.5.3.3 Test purpose

To confirm that after the UE receives TRANSPORT FORMAT COMBINATION CONTROL message, it transmits TRANSPORT FORMAT COMBINATION CONTROL FAILURE message and keep the TFC subset as before the TRANSPORT FORMAT COMBINATION CONTROL message is received.

### 8.2.5.3.4 Method of test

#### Initial Condition

System Simulator: 1 cell

UE: CELL\_DCH

#### Test Procedure

The UE establishes a radio access bearer on the DCH for to be used for user-data exchange. SS sends a TRANSPORT CHANNEL RECONFIGURATION message on the downlink DCCH, to request that the channel coding scheme for a DCH be changed. After this message has been acknowledged by the UE RLC-AM entity, the SS transmits a TRANSPORT FORMAT COMBINATION CONTROL message, which includes a full restriction of the TFCS used in the uplink. The UE shall detect a failure to reconfigure the TFCS, then it transmits TRANSPORT FORMAT COMBINATION CONTROL FAILURE message on the uplink DCCH. After the activation time specified in the TRANSPORT CHANNEL RECONFIGURATION message has elapsed, the UE shall send TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH. SS verifies that reconfiguration is completed by checking that the user-data exchange is resumed on DTCH.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				UE is in CELL_DCH connected state, with a DTCH logical channel for user-data communication
2		←	TRANSPORT CHANNEL RECONFIGURATION	Requesting for a change in semi-static transport format for DCH carrying the DTCH. The dynamic part remains unchanged.
3		←	TRANSPORT FORMAT COMBINATION CONTROL	Requesting for a full restriction on TFCS for the DCH carrying DTCH.
4		→	TRANSPORT FORMAT COMBINATION CONTROL FAILURE	The UE shall keep the TFC subset as before the TRANSPORT FORMAT COMBINATION CONTROL message was received
5				The UE does not change the configuration of TFC and the UE continues reconfigure the affected transport channel.
6			TRANSPORT CHANNEL RECONFIGURATION COMPLETE	UE shall resume exchange of data over the DTCH logical channel.

Specific Message Contents

#### TRANSPORT CHANNEL RECONFIGURATION

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to those in the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
TrCH Information Elements - Uplink transport channels - Added or reconfigured TrCH information list - Transport channel identity - Semi-Static Transport Format Information - Type of channel coding	2  Select a different coding scheme from default message content

#### TRANSPORT FORMAT COMBINATION CONTROL

Information Element	Value/remark
DPCH TFCS in Uplink - Subset Representation - Allowed TFIs	Restricted TrCH information Not Present (All TFCs are restricted)

#### TRANSPORT FORMAT COMBINATION CONTROL FAILURE

Information Element	Value/remark
Message Type	"TRANSPORT FORMAT COMBINATION CONTROL FAILURE"
Failure cause	Incompatible simultaneous reconfiguration
Other information element	Not checked

#### 8.2.5.3.5 Test requirement

After step3 the UE continue the transport channel reconfiguration as if no TRANSPORT FORMAT COMBINATION CONTROL message was received. Then it shall transmit a TRANSPORT FORMAT COMBINATION CONTROL FAILURE message on the DCCH using AM RLC, stating the reason "Incompatible simultaneous reconfiguration" in IE" Failure cause".

After step6 the UE shall resume communication with SS on DTCH using the requested channel coding scheme on the transport blocks.

#### 8.2.5.4 Transport format combination control in CELL\_DCH: Failure (Invalid message reception)

##### 8.2.5.4.1 Definition

##### 8.2.5.4.2 Conformance requirement

The UE shall keep old configuration when it receives a TRANSPORT FORMAT COMBINATION CONTROL message which using a spare value in the mandatory IE "Minimum allowed Transport format combination index". It shall then transmits a TRANSPORT FORMAT COMBINATION CONTROL FAILURE message, indicating "protocol error" in IE "failure cause" and "Information element value not comprehended" in IE "Protocol error cause".

##### Reference

GPP TS 25.331 clause 8.2.5

##### 8.2.5.4.3 Test purpose

To confirm after the UE receives an invalid TRANSPORT FORMAT COMBINATION CONTROL message, it transmits TRANSPORT FORMAT COMBINATION CONTROL FAILURE message and keep the TFC subset as if no TRANSPORT FORMAT COMBINATION CONTROL message has been received.

##### 8.2.5.4.4 Method of test

##### Initial Condition

System Simulator: 1 cell

UE: CELL\_DCH

##### Test Procedure

The UE establishes a radio access bearer on the DCH for a communication. The SS transmits a TRANSPORT FORMAT COMBINATION CONTROL message, which uses a spare value in the mandatory IE "Minimum allowed Transport format combination index". The UE shall then transmit TRANSPORT FORMAT COMBINATION CONTROL FAILURE message and continues the communication using the radio access bearer.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				RRC connected state on the DTCH for a communication
2		←	TRANSPORT FORMAT COMBINATION CONTROL	Contains an error in a mandatory IE.
3		→	TRANSPORT FORMAT COMBINATION CONTROL FAILURE	The UE shall not change the configuration

Specific Message Contents

#### TRANSPORT FORMAT COMBINATION CONTROL

Information Element	Value/remark
DPCH TFCS in uplink - Minimum allowed Transport format combination index	Set to the value "MaxTFCSValue"

#### TRANSPORT FORMAT COMBINATION CONTROL FAILURE

Information Element	Value/remark
Message Type	"TRANSPORT FORMAT COMBINATION CONTROL FAILURE"
Failure cause	"protocol error"
Protocol error information -Protocol error case	Information element value not comprehended
Other information element	Not checked

#### 8.2.5.4.5 Test requirement

After step3 the UE shall keep its configuration before the TRANSPORT FORMAT COMBINATION CONTROL message was received and transmit a TRANSPORT FORMAT COMBINATION CONTROL FAILURE message on the DCCH using AM RLC. The UE shall set the value "protocol error" in IE "Failure cause" and the value "information element not comprehended" in IE "protocol error information". The UE shall continue communicate with SS using the radio access bearer.

### 8.2.6 Physical channel reconfiguration

#### 8.2.6.1 Physical channel reconfiguration for transition from CELL\_DCH to CELL\_DCH ( Hard handover to another frequency ): Success

##### 8.2.6.1.1 Definition

##### 8.2.6.1.2 Conformance requirement

The UE shall correctly reconfigure a physical channel according to the PHYSICAL CHANNEL RECONFIGURATION message received, which is used for hard handover purposes. It shall be able to communicate with the UTRAN on the new frequency subsequently.

#### Reference

3GPP TS 25.331 clause 8.2.6

##### 8.2.6.1.3 Test purpose

To confirm that the UE reconfigures the physical channel parameters according to a PHYSICAL CHANNEL RECONFIGURATION message received from the SS. After the reconfiguration, the UE shall resume normal transmission and reception operations.

## 8.2.6.1.4 Method of test

## Initial Condition

System Simulator : 2 cells - cell 1 and cell 6 are active. The  $Q_{rxlevmin}$  and  $Q_{rxqualmin}$  values in SYSTEM INFORMATION BLOCK TYPE 3 and 4 messages of cell 6 is changed to  $-90\text{dBm}$  and  $-20\text{dB}$  respectively

UE : CELL\_DCH in cell 1

## Test Procedure

The UE is in the CELL\_DCH state in cell 1. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE, which includes a new physical channel parameter specified in the "Frequency Info" IE. The UE shall reconfigure itself and tune to the new physical channel and transmits a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH of cell 6 using AM RLC.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	PHYSICAL CHANNEL RECONFIGURATION	Including new frequency information.
2				UE shall suspend uplink activities to cell 1 and begin to reconfigure the physical channel parameters.
3		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	

## Specific Message Contents

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type titled "Packet to CELL\_DCH from CELL\_DCH in PS" in Annex A, with the following exceptions:

Information Element	Value/remark
Frequency info	
- UARFCN uplink(Nu)	Same uplink UARFCN as used for cell 6
- UARFCN downlink(Nd)	Same downlink UARFCN as used for cell 6
Downlink information for each radio links	Same downlink UARFCN as used for cell 6
- Primary CPICH info	
- Primary Scrambling Code	350

## 8.2.6.1.5 Test requirement

After step2 the UE shall send PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH of cell 6, and then continue to communicate with SS on the new physical channel.

## 8.2.6.2 Physical channel reconfiguration for transition from CELL\_DCH to CELL\_DCH ( Hard handover to another frequency ): Failure (Unsupported or Unacceptable configuration)

## 8.2.6.2.1 Definition

## 8.2.6.2.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a PHYSICAL CHANNEL RECONFIGURATION message which includes an unsupported configuration and transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, with the reason "configuration unacceptable" in IE" failure cause".



## Reference

3GPP TS 25.331 clause 8.2.6

## 8.2.6.2.3 Test purpose

To confirm that the UE keeps its configuration and transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC if the received PHYSICAL CHANNEL RECONFIGURATION message includes unsupported configuration parameters for the UE.

## 8.2.6.2.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

## Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE which includes unsupported configuration parameters as the frequency cannot be supported by the UE. The UE transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "configuration unacceptable" in IE" failure cause".

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	PHYSICAL CHANNEL RECONFIGURATION	Includes an unsupported configuration as the frequency cannot be supported by the UE
2		→	PHYSICAL CHANNEL RECONFIGURATION FAILURE	The UE shall not change the physical channel and continue to communicate using the old configuration.

## Specific Message Contents

## PHYSICAL CHANNEL RECONFIGURATION

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Frequency info - UARFCN uplink(Nu) - UARFCN downlink(Nd)	63984 Not Present

## PHYSICAL CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type Failure cause Other information element	Configuration unacceptable Not checked

## 8.2.6.2.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC and set "configuration unacceptable" in IE" failure cause".

### 8.2.6.3 Physical channel reconfiguration for transition from CELL\_DCH to CELL\_DCH ( Hard handover to another frequency ): Failure (Physical channel failure and reversion to old channel)

#### 8.2.6.3.1 Definition

#### 8.2.6.3.2 Conformance requirement

The UE shall revert to the old configuration when the UE fails to reconfigure the new physical channel by the expiry of timer T312, and then transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC indicating “physical channel failure” in IE” failure cause”.

#### Reference

3GPP TS 25.331 clause 8.2.6

#### 8.2.6.3.3 Test purpose

To confirm that the UE reverts to the old configuration and transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC if the UE fails to reconfigure the new physical channel according to the received PHYSICAL CHANNEL RECONFIGURATION message by timer T312 expiry.

#### 8.2.6.3.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

#### Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE which includes new frequency parameters. However, the SS does not reconfigure the new physical channel. The UE is expected to encounter a failure to reconfigure the new physical channel and after T312 timer expiry the UE shall revert to the old configuration. Finally, the UE transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC specifies “physical channel failure” in IE” failure cause”.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	PHYSICAL CHANNEL RECONFIGURATION	Including a new frequency information
2				The SS does not reconfigure the physical channel so that the UE fails to reconfigure to the new physical channel.
3		→	PHYSICAL CHANNEL RECONFIGURATION FAILURE	After T312 expiry, the UE shall revert to the old configuration and transmits this message.

Specific Message Contents

#### PHYSICAL CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	
Failure cause	Physical channel failure
Other information element	Not checked

#### 8.2.6.3.5 Test requirement

After step2 the UE shall revert to the old configuration and transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, with the value “physical channel failure” in IE” failure cause”.

#### 8.2.6.4 Physical channel reconfiguration for transition from CELL\_DCH to CELL\_DCH ( Hard handover to another frequency ): Failure (Physical channel failure and reversion failure)

##### 8.2.6.4.1 Definition

##### 8.2.6.4.2 Conformance requirement

The UE shall perform an RRC connection re-establishment procedure when the UE fails to revert to the old configuration, after the detection of physical channel failure during the course of executing a physical channel reconfiguration procedure.

#### Reference

3GPP TS 25.331 clause 8.2.6

##### 8.2.6.4.3 Test purpose

To confirm that the UE initiates an RRC connection re-establishment procedure when the UE cannot reconfigure the new physical channel for the failure of L1 configuration and for the failure of the reversion to the old configuration.

##### 8.2.6.4.4 Method of test

#### Initial Condition

System Simulator : 2 cells- Cell 1 is active, Cell 2 is inactive

UE : CELL\_DCH in cell 1

## Test Procedure

The UE is in the CELL\_DCH state in cell 1. The SS begins to broadcast the BCCH in cell 2 and then transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE, which includes new uplink and downlink frequency parameters and does not reconfigure L1. The UE is expected to fail to reconfigure the new physical channel and tries to revert to the old configuration after T312 expiry. The SS then deletes the old physical channel so that the UE would perform cell reselection and finds cell 2. It shall then transmit an RRC CONNECTION RE-ESTABLISHMENT REQUEST message which includes the IE "U-RNTI" on the uplink CCCH. The SS transmits an RRC CONNECTION RE-ESTABLISHMENT message which includes a new TFCS according to the new transport channel. After the UE receives an RRC CONNECTION RE-ESTABLISHMENT message, it reconfigures the new radio connection and transmits an RRC CONNECTION RE-ESTABLISHMENT COMPLETE message on the uplink DCCH using AM RLC.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	BCCH	The SS transmits the BCCH in cell 2.
2		←	PHYSICAL CHANNEL RECONFIGURATION	The message includes new frequency information
3				SS does not reconfigure the physical channel to reflect the changes in step 2, at the same time, it deletes the old configuration so the UE cannot reconfigure the new physical channel and cannot revert to the old configuration.
4		→	RRC CONNECTION RE-ESTABLISHMENT REQUEST	The UE finds a new cell.2 and then transmits this message which includes the IE "U-RNTI" .
5		←	RRC CONNECTION RE-ESTABLISHMENT	This message indicates a new TFCS according to the new transport channel.
6		→	RRC CONNECTION RE-ESTABLISHMENT COMPLETE	

## Specific Message Contents

None.

### 8.2.6.4.5 Test requirement

After step3 the UE shall find the availability of cell 2, enter CELL\_FACH state, and transmits RRC CONNECTION RE-ESTABLISHMENT message using RLC-TM mode on the uplink DCCH.

After step6 the UE shall be able to successfully re-establish an RRC connection in cell 2.

### 8.2.6.5 Physical channel reconfiguration for transition from CELL\_DCH to CELL\_DCH ( Hard handover to another frequency): Failure (Incompatible simultaneous reconfiguration)

#### 8.2.6.5.1 Definition

#### 8.2.6.5.2 Conformance requirement

The UE shall keep its old configuration when the UE receives another PHYSICAL CHANNEL RECONFIGURATION message before it completes the current reconfiguration according to an earlier PHYSICAL CHANNEL

RECONFIGURATION message. The UE shall transmit an PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting “incompatible simultaneous reconfiguration” in IE”failure cause”.

#### Reference

3GPP TS 25.331 clause 8.2.6

#### 8.2.6.5.3 Test purpose

To confirm that the UE keeps its current configuration when it receives another PHYSICAL CHANNEL RECONFIGURATION message before the completion of an existing physical channel reconfiguration .

#### 8.2.6.5.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

#### Test Procedure

The UE is in the CELL\_DCH state. When the SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE before it reconfigures the physical channel, the UE keeps the old configuration and transmits an PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC. This message shall indicate “incompatible simultaneous reconfiguration” in IE”failure cause”.

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	PHYSICAL CHANNEL RECONFIGURATION	
2		←	PHYSICAL CHANNEL RECONFIGURATION	Sent before the “Activation Time Info” specified in the message in step 1 has elapsed.
3		→	PHYSICAL CHANNEL RECONFIGURATION FAILURE	The UE does not change the configuration.

#### Specific Message Contents

#### PHYSICAL CHANNEL RECONFIGURATION

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Activation Time Info	Current CFN-[current CFN mod 8 + 8 ]

#### PHYSICAL CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	
Failure cause	Incompatible simultaneous reconfiguration
Other information element	Not checked

#### 8.2.6.5.5 Test requirement

After step2 the UE shall keep its old configuration and transmit an PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, which shall be set to “incompatible simultaneous reconfiguration” in IE”failure cause”.

## 8.2.6.6 Physical channel reconfiguration for transition from CELL\_DCH to CELL\_DCH ( Hard handover to another frequency): Failure (Invalid message reception)

### 8.2.6.6.1 Definition

### 8.2.6.6.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a PHYSICAL CHANNEL RECONFIGURATION message, which includes the spare value in the mandatory IE" DRX indicator". It shall then transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message which contains the value "protocol error" in IE" failure cause" and also "Information element value not comprehended" in IE" Protocol error cause".

### Reference

3GPP TS 25.331 clause 8.2.6

### 8.2.6.6.3 Test purpose

To confirm that the UE transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC if it receives a PHYSICAL CHANNEL RECONFIGURATION message which uses a spare value in the mandatory IE" DRX indicator".

### 8.2.6.6.4 Method of test

### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

### Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE , with a spare value in the mandatory IE" DRX indicator". The UE keeps the old configuration and transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, with a value "protocol error" in IE" failure cause" and also a value "Information element value not comprehended" in IE" Protocol error cause".

### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	PHYSICAL CHANNEL RECONFIGURATION	This message contains an error in one of the mandatory IEs.
2		→	PHYSICAL CHANNEL RECONFIGURATION FAILURE	The UE does not change the configuration.

### Specific Message Contents

### PHYSICAL CHANNEL RECONFIGURATION

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to those found in the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
DRX indicator	spare value

#### PHYSICAL CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	
Failure cause	
- Failure cause	Protocol error
- Protocol error information	
- Protocol error cause	Information element value not comprehended
Other information element	Not checked

#### 8.2.6.6.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting value "protocol error" in IE" failure cause" and also setting value "Information element value not comprehended" in IE" Protocol error cause".

#### 8.2.6.7 Physical channel reconfiguration for transition from CELL\_DCH to CELL\_FACH: Success

##### 8.2.6.7.1 Definition

##### 8.2.6.7.2 Conformance requirement

The UE shall correctly reconfigure a physical channel according to a PHYSICAL CHANNEL RECONFIGURATION message when asked to perform a transition from CELL\_DCH to CELL\_FACH.

#### Reference

3GPP TS 25.331 clause 8.2.6

##### 8.2.6.7.3 Test purpose

To confirm that the UE reconfigures a new physical channel according to the PHYSICAL CHANNEL RECONFIGURATION message received from the SS.

##### 8.2.6.7.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

#### Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE. The UE shall then reconfigure the new physical channel according to this message. Following this, it shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message using AM RLC on the RACH.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	PHYSICAL CHANNEL RECONFIGURATION	
2				Reconfiguration of physical channel
3		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	

Specific Message Contents

None.

#### 8.2.6.7.5 Test requirement

After step3 the UE shall transit from CELL\_DCH to CELL\_FACH and continue to communicate with SS on the common physical channel.

#### 8.2.6.8 Physical channel reconfiguration for transition from CELL\_DCH to CELL\_FACH: Failure (Unsupported or Unacceptable configuration)

##### 8.2.6.8.1 Definition

##### 8.2.6.8.2 Conformance requirement

The UE shall keep its old configuration when it receives a PHYSICAL CHANNEL RECONFIGURATION message which includes unsupported configuration parameters. It shall then transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, with the reason “configuration unacceptable” indicated in IE” failure cause”.

#### Reference

3GPP TS 25.331 clause 8.2.6

##### 8.2.6.8.3 Test purpose

To confirm that the UE keeps its configuration and transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, if the received PHYSICAL CHANNEL RECONFIGURATION message includes unsupported configuration parameters.

##### 8.2.6.8.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

#### Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE, which includes unsupported configuration parameters. Specifically, the frequency cannot be supported by the UE. The UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC which and indicating “configuration unacceptable” in IE” failure cause”.



Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	PHYSICAL CHANNEL RECONFIGURATION	The message specifies the usage of an unsupported configuration for the UE
2		→	PHYSICAL CHANNEL RECONFIGURATION FAILURE	The UE does not change the physical channel and continue to communicate with the SS using the original configuration.

Specific Message Contents

#### PHYSICAL CHANNEL RECONFIGURATION

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Frequency info - UARFCN uplink(Nu) - UARFCN downlink(Nd)	63984 Not Present

#### PHYSICAL CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type Failure cause Other information element	Configuration unacceptable Not checked

#### 8.2.6.8.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, with the reason “configuration unacceptable” specified in IE” failure cause”.

#### 8.2.6.9 Physical channel reconfiguration for transition from CELL\_DCH to CELL\_FACH: Failure (Physical channel failure)

##### 8.2.6.9.1 Definition

##### 8.2.6.9.2 Conformance requirement

The UE shall initiate the cell reselection procedure when the UE cannot use the assigned physical channel according to a PHYSICAL CHANNEL RECONFIGURATION message, during the transition from CELL\_DCH to CELL\_FACH.

#### Reference

3GPP TS 25.331 clause 8.2.6

##### 8.2.6.9.3 Test purpose

To confirm that the UE perform a cell reselection and cell update procedure when the it fail to access the assigned physical channel, according to a PHYSICAL CHANNEL RECONFIGURATION message, during the transition from CELL\_DCH to CELL\_FACH.

## 8.2.6.9.4 Method of test

## Initial Condition

System Simulator : 2 cells Cell 1 is active, Cell 2 is inactive

UE : CELL\_DCH

## Test Procedure

The UE is in the CELL\_DCH state in cell 1. The SS begins to broadcast the BCCH in cell 2 and then transmits a PHYSICAL CHANNEL RECONFIGURATION message, resulting in the UE to attempt to transit from CELL\_DCH to CELL\_FACH. The UE is expected to fail to access the assigned physical channel as the SS ceases downlink transmission in cell 1. After the UE successfully camp onto cell 2, it shall initiate the cell update procedure in cell 2. The procedure completes when the SS confirms UE's cell update request.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	BCCH	The SS starts to broadcast the BCCH in cell 2.
2		←	PHYSICAL CHANNEL RECONFIGURATION	The message assigns common resources so that the UE is expected to execute a transition from CELL_DCH to CELL_FACH
3				The UE shall detect a failure to use the assigned common physical channel and try to perform a cell reselection.
4		→	CELL UPDATE	The UE discover the presence of cell 2 and triggers a cell update procedure.
5		←	CELL UPDATE CONFIRM	SS sends this message so that the UE moves to CELL_PCH state.

## Specific Message Contents

None

## 8.2.6.9.5 Test requirement

After step3 the UE shall discover the presence of cell 2, enter CELL\_FACH state, and initiate a cell update procedure in that cell.

## 8.2.6.10 Physical channel reconfiguration for transition from CELL\_DCH to CELL\_FACH: Failure (Incompatible simultaneous reconfiguration)

## 8.2.6.10.1 Definition

## 8.2.6.10.2 Conformance requirement

The UE shall keep its old configuration when it receives another PHYSICAL CHANNEL RECONFIGURATION message before the existing reconfiguration request has been completed. The UE shall transmit an PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, indicating the reason "incompatible simultaneous reconfiguration" in IE"failure cause".

## Reference

3GPP TS 25.331 clause 8.2.6

## 8.2.6.10.3 Test purpose

To confirm that the UE keeps its original configuration when the UE receives a second PHYSICAL CHANNEL RECONFIGURATION message before it reconfigures the physical channel according to an earlier PHYSICAL CHANNEL RECONFIGURATION message.

## 8.2.6.10.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

## Test Procedure

The UE is in the CELL\_DCH state. When the SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE before the UE reconfigures the physical channel, the UE shall keep the old configuration and transmits an PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC. This message shall specify value "incompatible simultaneous reconfiguration" in IE "failure cause".

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	PHYSICAL CHANNEL RECONFIGURATION	
2		←	PHYSICAL CHANNEL RECONFIGURATION	Sent before the elapse of the time specified in "Activation Time Info" in the message of step 1.
3		→	PHYSICAL CHANNEL RECONFIGURATION FAILURE	The UE shall not change the configuration.

## Specific Message Contents

## PHYSICAL CHANNEL RECONFIGURATION (Step 1)

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Activation Time Info	Current CFN-[current CFN mod 8 + 8 ]

## PHYSICAL CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	
Failure cause	Incompatible simultaneous reconfiguration
Other information element	Not checked

## 8.2.6.10.5 Test requirement

After step2 the UE shall keep its old configuration, transmit an PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, and set the cause "incompatible simultaneous reconfiguration" in IE "failure cause".

## 8.2.6.11 Physical channel reconfiguration for transition from CELL\_DCH to CELL\_FACH: Failure (Invalid message reception)

### 8.2.6.11.1 Definition

### 8.2.6.11.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a PHYSICAL CHANNEL RECONFIGURATION message which includes the spare value in the mandatory IE "DRX indicator". It shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message, indicating "protocol error" in IE "failure cause" and indicating "Information element value not comprehended" in IE "Protocol error cause".

### Reference

3GPP TS 25.331 clause 8.2.6

### 8.2.6.11.3 Test purpose

To confirm that the UE transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, if the received a PHYSICAL CHANNEL RECONFIGURATION message uses a spare value in the mandatory IE "DRX indicator".

### 8.2.6.11.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH

#### Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE which contains a spare value in the mandatory IE "DRX indicator". The UE keeps the old configuration and transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, which comprises the reason "protocol error" in IE "failure cause" and reason "Information element value not comprehended" in IE "Protocol error cause".

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	PHYSICAL CHANNEL RECONFIGURATION	The message contains a error in one of the mandatory IE.
2		→	PHYSICAL CHANNEL RECONFIGURATION FAILURE	The UE shall not change the configuration.

#### Specific Message Contents

#### PHYSICAL CHANNEL RECONFIGURATION

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
DRX indicator	spare value

**PHYSICAL CHANNEL RECONFIGURATION FAILURE**

Information Element	Value/remark
Message Type	
Failure cause	
- Failure cause	Protocol error
- Protocol error information	
- Protocol error cause	Information element value not comprehended
Other information element	Not checked

**8.2.6.11.5 Test requirement**

After step1 the UE shall keep its old configuration and transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC. The failure message shall specify "protocol error" in IE" failure cause" and include "Information element value not comprehended" in IE" Protocol error cause".

**8.2.6.12 Physical channel reconfiguration for transition from CELL\_FACH to CELL\_DCH: Success****8.2.6.12.1 Definition****8.2.6.12.2 Conformance requirement**

The UE shall correctly reconfigure a physical channel according to a PHYSICAL CHANNEL RECONFIGURATION message, which triggers a transition from CELL\_FACH to CELL\_DCH.

**Reference**

3GPP TS 25.331 clause 8.2.6

**8.2.6.12.3 Test purpose**

To confirm that the UE reconfigures a new physical channel according to a PHYSICAL CHANNEL RECONFIGURATION message received from the UTRAN, in the case of an assignment of dedicated physical resource from the common physical channels used previously by the UE.

**8.2.6.12.4 Method of test****Initial Condition**

System Simulator : 1 cell

UE : CELL\_FACH

**Test Procedure**

The UE is in the CELL\_FACH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE to start a transition from CELL\_FACH to CELL\_DCH. The UE shall reconfigure the new physical channel correctly according to this message. To complete this procedure, the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message using AM RLC.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	PHYSICAL CHANNEL RECONFIGURATION	
2				The UE shall reconfigure the physical channel in order to start using the dedicated channels allocated.
3		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	

Specific Message Contents

None.

#### 8.2.6.12.5 Test requirement

After step3 the UE shall transit from CELL\_FACH to CELL\_DCH and continue to communicate with SS on the dedicated physical channel.

#### 8.2.6.13 Physical channel reconfiguration for transition from CELL\_FACH to CELL\_DCH: Failure (Unsupported or Unacceptable configuration)

##### 8.2.6.13.1 Definition

##### 8.2.6.13.2 Conformance requirement

The UE shall keep its old configuration when the it receives a PHYSICAL CHANNEL RECONFIGURATION message, which specifies unsupported configuration parameters for the UE. It shall then transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, reporting the cause "configuration unacceptable" in IE" failure cause".

Reference

3GPP TS 25.331 clause 8.2.6

##### 8.2.6.13.3 Test purpose

To confirm that the UE keeps its configuration and transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, if the received PHYSICAL CHANNEL RECONFIGURATION message includes unsupported configuration parameters.

##### 8.2.6.13.4 Method of test

Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE, which includes unsupported frequencies for the UE. The PHYSICAL CHANNEL RECONFIGURATION is structured in such a manner as to trigger a transition from CELL\_FACH to CELL\_DCH in the UE. The UE shall responds with a PHYSICAL CHANNEL RECONFIGURATION FAILURE message sent on the DCCH using AM RLC, setting "configuration unacceptable" in IE" failure cause".

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	PHYSICAL CHANNEL RECONFIGURATION	Includes unsupported frequencies for the UE
2		→	PHYSICAL CHANNEL RECONFIGURATION FAILURE	The UE shall not change the physical channel configuration, this message shall be sent using the original allocated physical resource.

Specific Message Contents

#### PHYSICAL CHANNEL RECONFIGURATION

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Frequency info - UARFCN uplink(Nu) - UARFCN downlink(Nd)	63984 Not Present

#### PHYSICAL CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type Failure cause Other information element	Configuration unacceptable Not checked

#### 8.2.6.13.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, the IE" failure cause" shall be set to "configuration unacceptable".

#### 8.2.6.14 Physical channel reconfiguration for transition from CELL\_FACH to CELL\_DCH: Failure (Physical channel failure and reversion to old configuration)

##### 8.2.6.14.1 Definition

##### 8.2.6.14.2 Conformance requirement

The UE shall revert to the old configuration when the UE fails to reconfigure the new physical channel by timer T312 expiry. It shall report the failure by transmitting a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, indicating "physical channel failure" in IE" failure cause".

#### Reference

3GPP TS 25.331 clause 8.2.6

##### 8.2.6.14.3 Test purpose

To confirm that the UE reverts to the old configuration and transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC if the UE fails to reconfigure the new physical channel according to a PHYSICAL CHANNEL RECONFIGURATION message by the T312 expiry.

## 8.2.6.14.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

## Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE, requesting it to transit from CELL\_FACH to CELL\_DCH due to a switch in physical resource reallocation. However, it does not reconfigure the new physical channel accordingly but continue to use the old configuration. Consequently, the UE shall fail to reconfigure the new physical channel, and after T312 expiry the UE attempt to revert to the old configuration. Then the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC which reports “physical channel failure” in IE” failure cause”.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	PHYSICAL CHANNEL RECONFIGURATION	
2				The SS does not reconfigure the physical channel, hence the UE shall detect a failure to reconfigure to the new physical channel.
3		→	PHYSICAL CHANNEL RECONFIGURATION FAILURE	After T312 expiry the UE reverts to the old configuration and transmits this message.

## Specific Message Contents

## PHYSICAL CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	
Failure cause	Physical channel failure
Other information element	Not checked

## 8.2.6.14.5 Test requirement

After step2 the UE shall revert to the old configuration and transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, specifying “physical channel failure” in IE” failure cause”.

## 8.2.6.15 Physical channel reconfiguration for transition from CELL\_FACH to CELL\_DCH: Failure (Physical channel failure and reversion failure)

## 8.2.6.15.1 Definition

## 8.2.6.15.2 Conformance requirement

The UE shall perform an RRC connection re-establishment procedure when the UE fails to revert to the old configuration after the detection of physical channel failure in the physical channel reconfiguration procedure.

## Reference

3GPP TS 25.331 clause 8.2.6



## 8.2.6.15.3 Test purpose

To confirm that the UE initiates an RRC connection re-establishment procedure after it fails to reconfigure the new physical channel and experiences a subsequent failure to revert to the old configuration.

## 8.2.6.15.4 Method of test

## Initial Condition

System Simulator : 2 cells- Cell 1 is active, Cell 2 is inactive

UE : CELL\_FACH in cell 1

## Test Procedure

The UE is in the CELL\_FACH state in cell 1. The SS begins to broadcast the BCCH in cell 2 and transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE, but it does not reconfigure L1 accordingly. This is expected to cause the UE to fail to reconfigure to the new physical channel. As a result, the UE shall try to revert to the old configuration after timer T312 expiry. However, the SS deletes the old physical channel before timer T312 has expired. Therefore, UE shall reselect to cell 2 and sends an RRC CONNECTION RE-ESTABLISHMENT REQUEST message, which includes its previously assigned U-RNTI on the uplink CCCH. The SS transmits an RRC CONNECTION RE-ESTABLISHMENT message, which includes a new TFCS according to the new transport channel used. After the UE receives this message, it reconfigures the new radio connection and transmits an RRC CONNECTION RE-ESTABLISHMENT COMPLETE message on the uplink DCCH using AM RLC.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	BCCH	The SS begins to transmit the BCCH in a cell 2.
2		←	PHYSICAL CHANNEL RECONFIGURATION	
3				The SS does not reconfigure the physical channel and deletes the old configuration. As a result, UE should encounter a failure to reconfigure the new physical channel, then attempt to revert to the old configuration.
4		→	RRC CONNECTION RE-ESTABLISHMENT REQUEST	The UE shall find cell 2 and then transmit this message with its U-RNTI included.
5		←	RRC CONNECTION RE-ESTABLISHMENT	This message specifies a new TFCS according to the new transport channel.
6		→	RRC CONNECTION RE-ESTABLISHMENT COMPLETE	UE shall send this message in the cell 2.

## Specific Message Contents

None.

## 8.2.6.15.5 Test requirement

After step3 the UE shall detect the presence of cell 2, camp onto it, and transmit a RRC CONNECTION RE-ESTABLISHMENT REQUEST message.

After step6 the UE shall successfully re-establish the RRC connection in cell 2.

## 8.2.6.16 Physical channel reconfiguration for transition from CELL\_FACH to CELL\_DCH: Failure (Incompatible simultaneous reconfiguration)

### 8.2.6.16.1 Definition

### 8.2.6.16.2 Conformance requirement

The UE shall keep its old configuration when it receives another PHYSICAL CHANNEL RECONFIGURATION message before the completion of an earlier physical channel reconfiguration procedure. Then the UE shall transmit an PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC and indicate “incompatible simultaneous reconfiguration” in IE “failure cause”.

### Reference

3GPP TS 25.331 clause 8.2.6

### 8.2.6.16.3 Test purpose

To confirm that the UE keeps its old configuration, if receives another PHYSICAL CHANNEL RECONFIGURATION message before it manages to complete reconfiguring the physical channel according to an earlier PHYSICAL CHANNEL RECONFIGURATION message.

### 8.2.6.16.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

#### Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to command the UE to perform a physical channel reconfiguration. The starting time for this action is specified. However, before the passing of the indicated starting time, SS sends another PHYSICAL CHANNEL RECONFIGURATION message. The UE shall stop the existing reconfiguration, maintains the old configuration, and transmits an PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC indicating “incompatible simultaneous reconfiguration” in IE “failure cause”.

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	PHYSICAL CHANNEL RECONFIGURATION	
2		←	PHYSICAL CHANNEL RECONFIGURATION	Sent before the elapse of the frame number specified in IE “activation time info” of the message dispatched in step 1.
3		→	PHYSICAL CHANNEL RECONFIGURATION FAILURE	The UE does not change the configuration.

#### Specific Message Contents

#### PHYSICAL CHANNEL RECONFIGURATION

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Activation Time Info	Current CFN-[current CFN mod 8 + 8 ]

#### PHYSICAL CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	
Failure cause	Incompatible simultaneous reconfiguration
Other information element	Not checked

#### 8.2.6.16.5 Test requirement

After step2 the UE shall keep its old configuration and transmit an PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting the value “incompatible simultaneous reconfiguration” in IE”failure cause”.

#### 8.2.6.17 Physical channel reconfiguration for transition from CELL\_FACH to CELL\_DCH: Failure (Invalid message reception)

##### 8.2.6.17.1 Definition

##### 8.2.6.17.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a PHYSICAL CHANNEL RECONFIGURATION message containing a spare value in the mandatory IE” DRX indicator”. It shall then transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message, set “protocol error” in IE” failure cause” and also set “Information element value not comprehended” in IE” Protocol error cause”.

#### Reference

3GPP TS 25.331 clause 8.2.6

##### 8.2.6.17.3 Test purpose

To confirm that the UE transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC if the received message uses a spare value in the mandatory IE” DRX indicator”.

##### 8.2.6.17.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

#### Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE which comprises a spare value in the mandatory IE” DRX indicator”. The UE keeps the old configuration and transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting “protocol error” in IE” failure cause” and also setting “Information element value not comprehended” in IE” Protocol error cause”.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	PHYSICAL CHANNEL RECONFIGURATION	Contains a mandatory error due to illegal use of spare value
2		→	PHYSICAL CHANNEL RECONFIGURATION FAILURE	The UE does not change the configuration.

Specific Message Contents

#### PHYSICAL CHANNEL RECONFIGURATION

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
DRX indicator	spare value

#### PHYSICAL CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	
Failure cause	
- Failure cause	Protocol error
- Protocol error information	
- Protocol error cause	Information element value not comprehended
Other information element	Not checked

#### 8.2.6.17.5 Test requirement

After step1 the UE shall keep its old configuration, transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC with “protocol error” in IE” failure cause” and also “Information element value not comprehended” in IE” Protocol error cause”.

#### 8.2.6.18 Physical channel reconfiguration for transition from CELL\_FACH to CELL\_FACH: Success

##### 8.2.6.18.1 Definition

##### 8.2.6.18.2 Conformance requirement

The UE shall correctly reconfigure a physical channel according to a PHYSICAL CHANNEL RECONFIGURATION message when asked to perform a transition from CELL\_FACH to CELL\_FACH in the another cell.

#### Reference

3GPP TS 25.331 clause 8.2.6

##### 8.2.6.18.3 Test purpose

To confirm that the UE reconfigures a new physical channel according to the PHYSICAL CHANNEL RECONFIGURATION message received from the SS.

##### 8.2.6.18.4 Method of test

#### Initial Condition

System Simulator : 2 cells Cell 1 is active, Cell 2 is inactive

UE : CELL\_FACH

#### Test Procedure

The UE is in the CELL\_FACH state. The SS starts to broadcast the BCCH in cell 2 and transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE. The UE shall then reconfigure the new physical channel according to this message. Following this, it shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message using AM RLC on the RACH.

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	BCCH	The SS starts to broadcast the BCCH in cell 2.
2		←	PHYSICAL CHANNEL RECONFIGURATION	
3				Reconfiguration of physical channel
4		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	

#### Specific Message Contents

None.

#### 8.2.6.18.5 Test requirement

After step3 the UE shall transit from CELL\_FACH to CELL\_FACH in the another cell and continue to communicate with SS on the common physical channel.

#### 8.2.6.19 Physical channel reconfiguration for transition from CELL\_FACH to CELL\_FACH: Failure (Unsupported or Unacceptable configuration)

##### 8.2.6.19.1 Definition

##### 8.2.6.19.2 Conformance requirement

The UE shall keep its old configuration when it receives a PHYSICAL CHANNEL RECONFIGURATION message which includes unsupported configuration parameters. It shall then transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, with the reason “configuration unacceptable” indicated in IE” failure cause”.

#### Reference

3GPP TS 25.331 clause 8.2.6

##### 8.2.6.19.3 Test purpose

To confirm that the UE keeps its configuration and transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, if the received PHYSICAL CHANNEL RECONFIGURATION message includes unsupported configuration parameters.

##### 8.2.6.19.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

### Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE, which includes unsupported configuration parameters. Specifically, the frequency cannot be supported by the UE. The UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC which and indicating "configuration unacceptable" in IE" failure cause".

### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	PHYSICAL CHANNEL RECONFIGURATION	The message specifies the usage of an unsupported configuration for the UE
2		→	PHYSICAL CHANNEL RECONFIGURATION FAILURE	The UE does not change the physical channel and continue to communicate with the SS using the original configuration.

### Specific Message Contents

#### PHYSICAL CHANNEL RECONFIGURATION

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Frequency info - UARFCN uplink(Nu) - UARFCN downlink(Nd)	63984 Not Present

#### PHYSICAL CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type Failure cause Other information element	Configuration unacceptable Not checked

#### 8.2.6.19.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, with the reason "configuration unacceptable" specified in IE" failure cause".

#### 8.2.6.20 Physical channel reconfiguration for transition from CELL\_FACH to CELL\_FACH: Failure (Physical channel failure)

##### 8.2.6.20.1 Definition

##### 8.2.6.20.2 Conformance requirement

The UE shall initiate the cell reselection procedure when the UE cannot use the assigned physical channel according to a PHYSICAL CHANNEL RECONFIGURATION message, during the transition from CELL\_FACH to CELL\_FACH in the another cell.

### Reference

3GPP TS 25.331 clause 8.2.6

## 8.2.6.20.3 Test purpose

To confirm that the UE perform a cell reselection and cell update procedure when the it fail to access the assigned physical channel, according to a PHYSICAL CHANNEL RECONFIGURATION message, during the transition from CELL\_FACH to CELL\_FACH in the another cell.

## 8.2.6.20.4 Method of test

## Initial Condition

System Simulator : 3 cells Cell 1 is active, Cell 2 is inactive, Cell 3 is inactive

UE : CELL\_FACH

## Test Procedure

The UE is in the CELL\_FACH state in cell 1. The SS begins to broadcast the BCCH in cell 2 and then transmits a PHYSICAL CHANNEL RECONFIGURATION message, resulting in the UE to attempt to transit from CELL\_FACH in cell 1 to CELL\_FACH in cell 3. The UE is expected to fail to access the assigned physical channel as the SS ceases downlink transmission in cell 3. After the UE successfully camp onto cell 2, it shall initiate the cell update procedure in cell 2. The procedure completes when the SS confirms UE's cell update request.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	BCCH	The SS starts to broadcast the BCCH in cell 2.
2		←	PHYSICAL CHANNEL RECONFIGURATION	The message assigns common resources so that the UE is expected to execute a transition from CELL_FACH in cell 1 to CELL_FACH in cell 3
3				The UE shall detect a failure to use the assigned common physical channel and try to perform a cell reselection.
4		→	CELL UPDATE	The UE discover the presence of cell 2 and triggers a cell update procedure.
5		←	CELL UPDATE CONFIRM	SS sends this message so that the UE moves to CELL_FACH state.

## Specific Message Contents

None

## 8.2.6.20.5 Test requirement

After step3 the UE shall discover the presence of cell 2, enter CELL\_FACH state, and initiate a cell update procedure in that cell.

## 8.2.6.21 Physical channel reconfiguration for transition from CELL\_FACH to CELL\_FACH: Failure (Incompatible simultaneous reconfiguration)

## 8.2.6.21.1 Definition

## 8.2.6.21.2 Conformance requirement

The UE shall keep its old configuration when it receives another PHYSICAL CHANNEL RECONFIGURATION message before the existing reconfiguration request has been completed. The UE shall transmit an PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, indicating the reason “incompatible simultaneous reconfiguration” in IE “failure cause”.

## Reference

3GPP TS 25.331 clause 8.2.6

## 8.2.6.21.3 Test purpose

To confirm that the UE keeps its original configuration when the UE receives a second PHYSICAL CHANNEL RECONFIGURATION message before it reconfigures the physical channel according to an earlier PHYSICAL CHANNEL RECONFIGURATION message.

## 8.2.6.21.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

## Test Procedure

The UE is in the CELL\_FACH state. When the SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE before the UE reconfigures the physical channel, the UE shall keep the old configuration and transmits an PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC. This message shall specify value “incompatible simultaneous reconfiguration” in IE “failure cause”.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	PHYSICAL CHANNEL RECONFIGURATION	
2		←	PHYSICAL CHANNEL RECONFIGURATION	Sent before the elapse of the time specified in “Activation Time Info” in the message of step 1.
3		→	PHYSICAL CHANNEL RECONFIGURATION FAILURE	The UE shall not change the configuration.

## Specific Message Contents

## PHYSICAL CHANNEL RECONFIGURATION (Step 1)

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:



Information Element	Value/remark
Activation Time Info	Current CFN-[current CFN mod 8 + 8 ]

#### PHYSICAL CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	
Failure cause	Incompatible simultaneous reconfiguration
Other information element	Not checked

#### 8.2.6.21.5 Test requirement

After step2 the UE shall keep its old configuration, transmit an PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, and set the cause "incompatible simultaneous reconfiguration" in IE"failure cause".

#### 8.2.6.22 Physical channel reconfiguration for transition from CELL\_FACH to CELL\_FACH: Failure (Invalid message reception)

##### 8.2.6.22.1 Definition

##### 8.2.6.22.2 Conformance requirement

The UE shall keep its old configuration when the UE receives a PHYSICAL CHANNEL RECONFIGURATION message which includes the spare value in the mandatory IE" DRX indicator" . It shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message, indicating "protocol error" in IE" failure cause" and indicating "Information element value not comprehended" in IE" Protocol error cause".

#### Reference

3GPP TS 25.331 clause 8.2.6

##### 8.2.6.22.3 Test purpose

To confirm that the UE transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, if the received a PHYSICAL CHANNEL RECONFIGURATION message uses a spare value in the mandatory IE" DRX indicator".

##### 8.2.6.22.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_FACH

#### Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE which contains a spare value in the mandatory IE" DRX indicator". The UE keeps the old configuration and transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, which comprises the reason "protocol error" in IE" failure cause" and reason "Information element value not comprehended" in IE" Protocol error cause".

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	PHYSICAL CHANNEL RECONFIGURATION	The message contains a error in one of the mandatory IE.
2		→	PHYSICAL CHANNEL RECONFIGURATION FAILURE	The UE shall not change the configuration.

Specific Message Contents

## PHYSICAL CHANNEL RECONFIGURATION

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
DRX indicator	spare value

## PHYSICAL CHANNEL RECONFIGURATION FAILURE

Information Element	Value/remark
Message Type	
Failure cause	
- Failure cause	Protocol error
- Protocol error information	
- Protocol error cause	Information element value not comprehended
Other information element	Not checked

### 8.2.6.22.5 Test requirement

After step1 the UE shall keep its old configuration and transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC. The failure message shall specify “protocol error” in IE” failure cause” and include “Information element value not comprehended” in IE” Protocol error cause”.

## 8.2.7 Physical Shared Channel Allocation[TDD only]

[Editor’s note : This message is not included in Release99 so this is FFS.]

## 8.2.8 PUSCH capacity request[TDD only]

[Editor’s note : This message is not included in Release99 so this is FFS.]

## 8.2.9 Downlink outer loop control

For all following sub-clauses, all references to RRC CONNECTION SETUP messages shall use the default settings provided in clause 9 of TS 34.108, unless otherwise stated.

### 8.2.9.1 Downlink outer loop control: Increase is Disallowed

#### 8.2.9.1.1 Definition

#### 8.2.9.1.2 Conformance requirement

The UE shall maintain its existing internal target SIR value after it has received DOWNLINK OUTER LOOP CONTROL message which forbids further adjustment of SIR target. This restriction shall be observed even if the UE has detect that the current SIR target is not sufficient to achieve the downlink quality demanded by the UTRAN.

## Reference

3GPP TS 25.331 clause 8.2.9

### 8.2.9.1.3 Test purpose

To confirm that the UE keeps its target SIR value after it receives a DOWNLINK OUTER LOOP CONTROL message with the IE “Downlink Outer Loop Control” set to “TRUE”.

### 8.2.9.1.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH state with the no restriction by the DL outer loop power control

#### Test Procedure

The UE is in the CELL\_DCH state and the SS adjusts its transmission power as the current SIR estimation by the UE has reached the same target SIR value determined autonomously by the UE. This condition can be observed when the TPC command bits on the DPCCH physical channel has stabilized (consistently alternating between values 0 and 1). The SS transmits the DOWNLINK OUTER LOOP CONTROL message, which is set to “TRUE” in IE “Downlink Outer Loop Control”. Then the SS generates erroneous frames such that the measured BLER in the UE falls below the value specified in IE “BLER Quality Value” of the RRC CONNECTION SETUP message received during the mobile-terminated RRC connection establishment procedure (described in clause 7.1.2 of TS 34.108). The UE shall detect this change but it maintains the current SIR target value and does not request that SS increases downlink transmission power by setting TPC in DPCCH to “1”.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The SS adjusts its transmission power as such that the measured value of SIR in the UE is the same as the SIR target value determined by the UE. The target SIR value is chosen by the UE in order that the target BLER value requested by SS is achieved.
2		←	DOWNLINK OUTER LOOP CONTROL	Set value "TRUE" in IE "Downlink Outer Loop Control".
3				The SS starts to generate some error frames. The current SIR target in the UE cannot guarantee target BLER value specified earlier.
4				The UE shall keep the existing SIR target value and it shall not request that the DL transmission power be increased using TPC bits in DPCH physical channel.

Specific Message Content

#### DOWNLINK OUTER POWER CONTROL

Information Element	Value/remark
Integrity check info	Not Present
Downlink Outer Loop Control	
- DL Outer loop control	Increased not allowed
Downlink DPCH power control information	
- DPC Mode	Single

#### 8.2.9.1.5 Test requirement

After step3 the SS shall keep the target SIR value as same as step1 and it shall not request for the downlink transmission power be increased by setting TPC bits to "1".

#### 8.2.9.2 Downlink outer loop control: Increase is Allowed

##### 8.2.9.2.1 Definition

##### 8.2.9.2.2 Conformance requirement

The downlink power control procedure is used to control the downlink outer loop power control running in the UE. If the UE receives the DOWNLINK OUTER LOOP CONTROL message with value "FALSE" in IE "Downlink Outer Loop Control", it shall remove any existing restriction of DL outer loop power control. The UE shall begin to increase its DL target SIR value and make the DL transmission power increase until the desired BLER value for the DPCH transport channel has been attained.

#### Reference

3GPP TS 25.331 clause 8.2.9

### 8.1.2.9.2.3 Test purpose

To confirm that the UE begins to exercise DL outer loop power control, in order to increase the target SIR value, after it had received a DOWNLINK OUTER LOOP CONTROL message specifying "FALSE" in IE "Downlink Outer Loop Control".

### 8.2.9.2.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH state with the restriction by the DL outer loop power control Test Procedure

The UE is in the CELL\_DCH state with the restriction by the DL outer loop power control. The internal SIR target value determined by the UE is expected to be insufficient to allow the UE to achieve target BLER figure. The SS transmits the DOWNLINK OUTER LOOP CONTROL message, setting the value "FALSE" in IE "Downlink Outer Loop Control". Then the UE shall update its SIR target value and make the DL transmission power increase.

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is brought to the same state as the end of step 4 in Clause 8.1.2.9.1.3.
2		←	DOWNLINK OUTER LOOP CONTROL	Set the value "FALSE" in IE "Downlink Outer Loop Control".
3				The UE shall begin to request that the DL transmission power be increased. This is done by setting the TPC field to "1" in DPCH.

### 8.2.9.2.5 Test requirement

After step3 the SS shall increase the DL transmission power more than step1.

## 8.2.9.3 Downlink outer loop control: Failure (Invalid message reception)

### 8.2.9.3.1 Definition

### 8.2.9.3.2 Conformance requirement

The UE shall correctly handle an erroneous DOWNLINK OUTER LOOP CONTROL message, and perform the appropriate error-handling procedure. Specifically, it shall not alter the downlink power control mechanism, which is currently being applied. It shall also transmit a RRC STATUS message using RLC-AM mode on the DCCH channel, state the appropriate failure cause.

#### Reference

3GPP TS 25.331 clause 8.2.9

### 8.2.9.3.3 Test purpose

To confirm that the UE transmits an RRC STATUS message on the DCCH using AM RLC when it receives a DOWNLINK OUTER LOOP CONTROL message, containing an invalid conditional IE with respect to the state of the UE.

## 8.2.9.3.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : CELL\_DCH and the integrity protection algorithm is not applied.

## Test Procedure

The UE is in CELL\_DCH state. Test steps 1 to 3 described in clause 8.2.9.1.4 are repeated. Next, the SS transmits another DOWNLINK OUTER LOOP CONTROL message, removing the power increase restriction, and at the same time includes the conditional IE "Integrity Check Info". The UE shall not request for an increase in the downlink transmission power through the TPC command field in DPCCH. It shall transmit RRC STATUS message stating the value "Message extension not comprehended" in IE "protocol cause".

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				Executes step 1 to step 3 in clause 8. 2.9.1.4.
2		←	DOWNLINK OUTER LOOP CONTROL	Contains an unexpected information element "Integrity Check Info" in the message. See specific message content.
3		→	RRC STATUS	The UE shall request for an increase in downlink transmission power. The message shall specify cause "Message extension is not comprehended" in IE "Protocol Error Information"
4				The UE shall not request for an increase in downlink transmission power. SS verifies the value of TPC field in DPCCH.

## Specific Message Content

## DOWNLINK OUTER LOOP CONTROL (Step 2)

The contents of DOWNLINK OUTER LOOP CONTROL message in this test case is identical to those of the default contents of layer 3 messages for RRC tests with the following exceptions:

Information Element	Value/remark
Integrity Check Info	Present
- Message authentication code	An arbitrary 32-bits string
- RRC Message Sequence	An arbitrarily chosen integer from range (0....15)

## RRC STATUS

Information Element	Value/remark
Message Type	
Protocol error information	Information element value not comprehended
Other information element	Not checked

## 8.2.9.3.5 Test requirement

After step4 the UE shall keep its restriction for increase in downlink transmission power and not set TPC command fields in DPCCH to "1". It shall transmit an RRC STATUS message on the DCCH using AM RLC, indicating "Information element value not comprehended" in IE "Protocol error cause".

## 8.3 RRC connection mobility procedure

### 8.3.1 Cell Update

#### 8.3.1.1 Cell Update: cell reselection in CELL\_FACH

##### 8.3.1.1.1 Definition

##### 8.3.1.1.2 Conformance requirement

This procedure is used to update UTRAN with the current cell of the UE after it has performed a cell reselection in CELL\_FACH state.

##### Reference

3GPP TS 25.331 clause 8.3.1

##### 8.3.1.1.3 Test purpose

To confirm that the UE executes a cell update procedure after the successful reselection of another UTRA cell. To confirm that the UE sends the correct uplink response message when executing cell update procedure due to cell reselection.

##### 8.3.1.1.4 Method of test

##### Initial Condition

System Simulator: 2 cells - Cell 1 is active, Cell 2 is inactive

UE: CELL\_FACH in cell 1

##### Test Procedure

The UE is in the CELL\_FACH state, camping onto cell 1. The SS starts to broadcast BCCH on the primary CPICH in cell 2 with a power level greater than that in cell 1. The UE shall find cell 2 to be more suitable for service and hence perform a cell reselection. After the completion of cell reselection, the UE shall transmit a CELL UPDATE message to the SS on the uplink CCCH of cell 2 and set IE "Cell update cause" to "Cell Reselection". After the SS receives this message, it transmits a CELL UPDATE CONFIRM message, which includes the IE "DRX Indicator" set to "DRX with Cell updating", to the UE on the downlink DCCH. SS verifies that the UE does not send any response to this message. UE shall move to CELL\_PCH state. SS then reverses the transmission power of cell 1 and cell 2. The UE shall send a CELL UPDATE message on the uplink CCCH of cell 1. SS replies with CELL UPDATE CONFIRM message and allocates new C-RNTI and U-RNTI identities to the UE. The IE "DRX Indicator" is set to "No DRX" in this message. The UE shall transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message. Following this, SS reverses the transmission power settings for cell 1 and cell 2 again. The UE shall initiate a cell update procedure by transmitting a CELL UPDATE message and stating the cause as 'cell re-selection'. SS replies with a CELL UPDATE CONFIRM message which contains IE "PRACH Info" and IE "Secondary CCPCH Info". The UE shall send PHYSICAL CHANNEL RECONFIGURATION COMPLETE message to acknowledge the assignment of the new physical resources.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is in the CELL_FACH state in cell 1
2		←	BCCH	The SS starts to broadcast BCCH on the primary CPICH in cell 2 with a power level that is higher than that in cell 1. The UE shall find that the cell 2 is better for service and perform a reselection. SS waits for the maximum duration required for the UE to camp to cell 2.
3		→	CELL UPDATE	Value "cell reselection" should be indicated in IE" Cell update cause"
4		←	CELL UPDATE CONFIRM	IE"DRX Indicator" is set to "DRX with cell updating"
5				SS checks the uplink PRACH channel to verify that no response is sent by UE. SS reverses the transmission power level of cell 1 and cell 2.
6		→	CELL UPDATE	UE shall revert to normal service in cell 1 and set the cause to "cell reselection".
7		←	CELL UPDATE CONFIRM	IE"DRX Indicator" is set to "No DRX". New C-RNTI and U-RNTI identities are assigned to the UE.
8		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	UE moves to CELL_FACH state and sends this message.
9				SS reverses the transmission power level of cell 1 and cell 2.
10		→	CELL UPDATE	UE shall detect that cell 2 has become stronger.
11		←	CELL UPDATE CONFIRM	IE"DRX Indicator" is set to "No DRX". At the same time, IE"PRACH Info" and IE"Secondary CCPCH Info" are also indicated.
12		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	UE moves to CELL_FACH state and sends this message on the new PRACH assigned in step 11.

## Specific Message Contents

## CELL UPDATE (Steps 3 and 6)

Use the same message sub-type found in Clause 8.1 of TS34.108.



Information Element	Value/remark
U-RNTI	Check to see if set to '0000 0000 0000 0001'
- SRNC Identity	Check to see if set to '0000 0000 0000 0000 0000 0001'
- S-RNTI	Not checked
Integrity check info	Check to see if set to 'FALSE'
AM_RLC error indicator (for C-plane)	Check to see if set to 'FALSE'
AM_RLC error indicator (for U-plane)	Check to see if it is present
Hyper frame number	Check to see if set to 'Cell Re-selection'
Cell Update Cause	Check to see if it is absent or set to 'FALSE'
Protocol error indicator	Check to see if it is absent
Measured results on RACH	Check to see if it is absent
Protocol error information	Check to see if it is absent

## CELL UPDATE CONFIRM (Step 4)

Use the same message sub-type found in Clause 8.1 of TS34.108, with the following exceptions:

Information Element	Value/remark
DRX Indicator	DRX with cell updating

## CELL UPDATE CONFIRM (Step 7)

Use the same message sub-type found in Clause 8.1 of TS34.108, with the following exceptions:

Information Element	Value/remark
New U-RNTI	'0000 0000 0000 0001'
- SRNC Identity	An arbitrary 20-bits string which is different from original S-RNTI
- S-RNTI	An arbitrary 16-bits string which is different from original C-RNTI.
New C-RNTI	

## CELL UPDATE (Step 10)

Use the same message sub-type found in Clause 8.1 of TS34.108.

Information Element	Value/remark
U-RNTI	Check to see if set to '0000 0000 0000 0001'
- SRNC Identity	Check to see if set to same string in IE"S-RNTI" in IE"New U-RNTI" of CELL UPDATE CONFIRM message in step 7.
- S-RNTI	Not checked
Integrity check info	Check to see if set to 'FALSE'
AM_RLC error indicator (for C-plane)	Check to see if set to 'FALSE'
AM_RLC error indicator (for U-plane)	Check to see if it is present
Hyper frame number	Check to see if set to 'Cell Re-selection'
Cell Update Cause	Check to see if it is absent or set to 'FALSE'
Protocol error indicator	Check to see if it is absent
Measured results on RACH	Check to see if it is absent
Protocol error information	Check to see if it is absent

## CELL UPDATE CONFIRM (Step 11)

Use the same message sub-type found in Clause 8.1 of TS34.108, with the following exceptions:

Information Element	Value/remark
PRACH Info (for RACH)	
- Available Signature	0 and 1
- Signature	Refer to the parameter set for TS 34.108
- Available SF	0
- Scrambling code number	Refer to the parameter set for TS 34.108
- Puncturing Limit	0 and 1
- Available Sub-Channel number	
- Sub-Channel number	
Downlink DPCH info for one radio link	
- Primary CPICH Info	
- Primary Scrambling Code	Set to the scrambling code for cell 1's P-CPICH.
- PDSCH with SHO DCH Info	Not Present.
- PDSCH code mapping	Not Present.
- Secondary CCPCH Info	
- Selection Indicator	Not Present
- Primary CPICH usage for channel estimation	TRUE
- Secondary CPICH Info	
- Secondary scrambling code	Not Present. Use default (Scrambling code of P-CPICH)
- Channelization code	1
- Secondary scrambling code	Not Present. Use default (Scrambling code of P-CPICH)
- STTD indicator	FALSE
- Spreading factor	256
- Code number	255
- Pilot symbol existence	TRUE
- TFCI existence	TRUE
- Fixed or Flexible Position	Flexible
- Timing Offset	0 chips

#### 8.3.1.1.5 Test requirement

After step 2 the UE shall reselect to cell 2 and then it shall transmit a CELL UPDATE message which, sets the value "cell reselection" in IE" Cell update cause".

After step 4 the UE shall not transmit any uplink message in response to the CELL UPDATE CONFIRMATION message received in step 4.

After step 5 the UE shall sent CELL UPDATE message to cell 2, in order to indicate that a cell reselection has taken place.

After step 7 the UE shall transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message to acknowledge that it has started to use the new RNTI identities allocated.

After step 9 the UE shall sent CELL UPDATE message to cell 1, in order to indicate that a cell reselection has taken place.

After step 11 the UE shall transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the new PRACH physical channel assigned previously in CELL UPDATE CONFIRM message sent in step 11.

### 8.3.1.2 Cell Update: cell reselection in CELL\_PCH

#### 8.3.1.2.1 Definition

#### 8.3.1.2.2 Conformance requirement

This procedure is to update UTRAN with information of the current cell, after a cell reselection has occurred in CELL\_PCH state.

#### Reference

3GPP TS 25.331 clause 8.3.1

### 8.3.1.2.3 Test purpose

To confirm that the UE, in CELL\_PCH state, executes a cell update procedure after the successful reselection of another UTRA cell. To confirm that the UE replies with an appropriate uplink message after receiving CELL UPDATE CONFIRM message during the cell update procedure.

### 8.3.1.2.4 Method of test

#### Initial Condition

System Simulator: 2 cells – Cell 1 is active, Cell 2 is inactive

UE: CELL\_PCH in cell 1

#### Test Procedure

The UE is brought to CELL\_PCH state and is camped onto cell 1. The SS starts to broadcast system information on the BCCH on the primary CPICH in cell 2. The transmission level of cell 2 is raised to be higher than in cell 1. When the UE detects the presence of cell 2, it moves to CELL\_FACH state and transmits a CELL UPDATE message on the uplink CCCH. The value "cell reselection" shall be set in IE "Cell update cause" in CELL UPDATE message. Upon reception of CELL\_UPDATE message, the SS transmits a CELL UPDATE CONFIRM message which includes the IEs "PRACH info", "Secondary CCPCH info" to the UE on the downlink DCCH. In this message, the IE "DRX Indicator" is set to "No DRX". Then the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH and enters CELL\_FACH state. SS exchanges the transmission power of cell 1 and cell 2, so that cell 1 becomes the stronger cell. UE shall initiate a cell update procedure again by transmitting CELL UPDATE message. SS replies with a CELL UPDATE CONFIRM message with the IE "DRX Indicator" set to "DRX with cell updating". After receiving this message, the UE returns to CELL\_PCH state without transmitting any uplink message. Finally, SS reverses the transmission strengths of cell 1 and cell 2 again. This will cause the UE to send CELL UPDATE message on the uplink PRACH of cell 2. SS then sends CELL UPDATE CONFIRM message with the assignment of new C-RNTI and U-RNTI identities. The UE shall transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message as a response.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is brought to CELL_PCH state in cell 1
2		←	BCCH	The SS starts to broadcast system information message on BCCH on the primary CPICH from cell 2. The transmission level of cell 2 is set to be higher than that in cell 1. The UE shall find that the cell 2 is better and attempt to perform a cell reselection.
3		→	CELL UPDATE	The UE moves to CELL_FACH state and transmits this message with the IE "Cell update cause" set to "cell reselection"
4		←	CELL UPDATE CONFIRM	The message includes IEs "PRACH info", "Secondary CCPCH info" and set IE "DRX Indicator" to "No DRX".
5		→	PHYSICAL CHANNEL RECONFIGURATION CONFIRM	UE stays in CELL_FACH state.
6				SS swaps the transmission power of cell 1 and cell 2, making cell 1 the stronger cell.
7		→	CELL UPDATE	
8		←	CELL UPDATE CONFIRM	IE "DRX Indicator" is set to "DRX with cell updating".
9				UE moves to CELL_PCH state. SS exchanges the transmission power of cell 1 and cell 2.
10		→	CELL UPDATE	UE shall re-select to cell 2 and transmit this message.
11		←	CELL UPDATE CONFIRM	Includes IE "new U-RNTI" and IE "new C-RNTI"
12		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	

## Specific Message Contents

## CELL UPDATE (Steps 3, 7 and 10)

Use the same message sub-type found in Clause 8.1 of TS34.108.

Information Element	Value/remark
U-RNTI	Check to see if set to '0000 0000 0000 0001'
- SRNC Identity	Check to see if set to '0000 0000 0000 0000 0000 0001'
- S-RNTI	Not checked
Integrity check info	Check to see if set to 'FALSE'
AM_RLC error indicator (for C-plane)	Check to see if set to 'FALSE'
AM_RLC error indicator (for U-plane)	Check to see if it is present
Hyper frame number	Check to see if set to 'Cell Re-selection'
Cell Update Cause	Check to see if it is absent or set to 'FALSE'
Protocol error indicator	Check to see if it is absent
Measured results on RACH	Check to see if it is absent
Protocol error information	Check to see if it is absent

## CELL UPDATE CONFIRM (Step 4)

Use the same message found in step 11 of Clause 8.1.3.1.1.3

**CELL UPDATE CONFIRM (Step 8)**

Use the same message sub-type found in Clause 8.1 of TS34.108, with the following exceptions:

Information Element	Value/remark
DRX Indicator	DRX with cell updating

**CELL UPDATE CONFIRM (Step 11)**

Use the same message sub-type found in Clause 8.1 of TS34.108, with the following exceptions:

Information Element	Value/remark
New U-RNTI - SRNC Identity - S-RNTI	'0000 0000 0000 0001' An arbitrary 20-bits string which is different from original S-RNTI
New C-RNTI	An arbitrary 16-bits string which is different from original C-RNTI.

**8.3.1.2.5 Test requirement**

After step 2 the UE shall reselect to cell 2 and transmit a CELL UPDATE message, containing the IE" Cell update cause" set to "cell reselection".

After step 4 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH.

After step 9 the UE shall detect that cell 2 has become the stronger cell. It shall send a CELL UPDATE message on cell 2' PRACH channel with the cause set to "cell reselection".

After step 11 the UE shall transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH.

**8.3.1.3 Cell Update: periodical cell update in CELL\_FACH****8.3.1.3.1 Definition****8.3.1.3.2 Conformance requirement**

This procedure is to update UTRAN with the current cell information, after the UE has remained in the service area in the CELL\_FACH state for a period exceeding the timer value T305.

**Reference**

3GPP TS 25.331 clause 8.3.1

**8.3.1.3.3 Test purpose**

To confirm that the UE executes a periodic cell update procedure following the expiry of timer T305. To confirm that the UE sends a correct response to the CELL UPDATE CONFIRM message. To confirm that the UE listens to the system information messages and then responds to a change in the setting for timer T305.

**8.3.1.3.4 Method of test****Initial Condition**

System Simulator: 1 cell

UE: CELL\_FACH

## Test Procedure

The UE is in CELL\_FACH state. When the UE detects the expiry of timer T305 according to the settings in system information, the UE transmits a CELL UPDATE message to the SS on the uplink CCCH with a cause indicating periodic cell updating. SS replies with a CELL UPDATE CONFIRM message, omitting the IEs "new C-RNTI", "new U-RNTI", "PRACH Info" and "Secondary CCPCH Info". The IE "DRX Indicator", however, is specified and set to "No DRX". SS verifies that the UE does not transmit any uplink message. SS then waits for T305 to expire again. The UE shall send another CELL UPDATE message to report periodic cell updating. After the SS receives this message, it transmits a CELL UPDATE CONFIRM message which includes the IEs "new C-RNTI", "new U-RNTI" to the UE on the downlink DCCH. Then the UE shall transmit an RNTI REALLOCATION COMPLETE message on the uplink DCCH to acknowledge the receipt of the new UE identities. SS once again allows T305 timer to expire, the UE shall transmit CELL UPDATE message for the third time. The new U-RNTI shall be indicated in this message together with the correct updating cause. In this sequence, SS replies with a CELL UPDATE CONFIRM message containing new channel parameters in IEs "PRACH Info" and "Secondary CCPCH Info". The UE shall then send a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message by using the newly allocated PRACH resources. Finally, the content of the SYSTEM INFORMATION BLOCK TYPE 2 is changed to disable periodic cell updating. SS then monitors the uplink DCCH for a period up to the maximum possible value for timer T305 (720 minutes) and verifies that no CELL\_UPDATE message is received. After this, the SS changes the timer T305 value to 5 minutes. UE shall resume periodic cell updating procedure and transmit CELL\_UPDATE message 5 minutes after this modification.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is in the CELL_FACH state. SS waits until T305 has expired.
2	→		CELL UPDATE	IE "Cell update cause" shall be set to "Periodic cell updating"
3		←	CELL UPDATE CONFIRM	No RNTI identities are given. No information on PRACH and S-CCPCH are provided.
4				SS verifies that no uplink message is received from UE. SS waits for another period to allow T305 to expire.
5	→		CELL UPDATE	Which is set to "periodic cell update" in IE "Cell update cause" for the expiry of timer T305.
6		←	CELL UPDATE CONFIRM	Including IEs "new C-RNTI", "new U-RNTI" and IE "DRX Indicator" is set to "No DRX"
7	→		RNTI REALLOCATION COMPLETE	
8				SS waits for a duration to allow timer T305 in the UE to expire.
9	→		CELL UPDATE	
10		←	CELL UPDATE CONFIRM	IEs "PRACH Info" and "Secondary CCPCH Info" are included.
11	→		PHYSICAL CHANNEL RECONFIGURATION COMPLETE	
12		←	MASTER INFORMATION BLOCK  SYSTEM INFORMATION BLOCK TYPE 2	SS changes the contents of MASTER INFORMATION BLOCK and SYSTEM INFORMATION BLOCK (see specific message contents). It waits for 720 minutes and checks that no CELL_UPDATE message is transmitted on uplink PRACH

13	←	MASTER INFORMATION BLOCK SYSTEM INFORMATION BLOCK TYPE 2	SS modified the contents of  MASTER INFORMATION BLOCK and SYSTEM INFORMATION BLOCK (see specific message)
14	→	CELL UPDATE	UE shall transmit this message 5 minutes after step 13, with "cell update cause" set to "periodic cell updating"
15	←	CELL UPDATE CONFIRM	

## Specific Message Contents

## CELL UPDATE (Step 2 and 5)

Information Element	Value/remark
U-RNTI - SRNC Identity - S-RNTI Integrity check info AM_RLC error indicator (for C-plane) AM_RLC error indicator (for U-plane) Hyper frame number Cell Update Cause Protocol error indicator Measured results on RACH Protocol error information	Check to see if set to '0000 0000 0001' Check to see if set to '0000 0000 0000 0000 0000 0001' Not checked Check to see if set to 'FALSE' Check to see if set to 'FALSE' Check to see if it is present Check to see if set to 'Periodic cell updating' Check to see if it is absent or set to 'FALSE' Check to see if it is absent Check to see if it is absent

## CELL UPDATE CONFIRM (Step 3)

Use the same message sub-type found in Clause 8.1 of TS34.108.

## CELL UPDATE CONFIRM (Step 6 and 15)

Use the same message sub-type found in Clause 8.1 of TS34.108, with the following exceptions:

Information Element	Value/remark
New U-RNTI - SRNC Identity - S-RNTI	Set to '0000 0000 0001' Set to an arbitrary string different from '0000 0000 0000 0000 0001'

## CELL UPDATE (Step 9 and 14)

Information Element	Value/remark
U-RNTI - SRNC Identity - S-RNTI  Integrity check info AM_RLC error indicator (for C-plane) AM_RLC error indicator (for U-plane) Hyper frame number Cell Update Cause Protocol error indicator Measured results on RACH Protocol error information	Check to see if set to '0000 0000 0000 0001' Check to see if set to same bit string as in IE"S-RNTI" in IE"U-RNTI" of the CELL UPDATE CONFIRM message sent in step 6. Not checked Check to see if set to 'FALSE' Check to see if set to 'FALSE' Check to see if it is present Check to see if set to 'Periodic cell updating' Check to see if it is absent or set to 'FALSE' Check to see if it is absent Check to see if it is absent

## CELL UPDATE CONFIRM (Step 10)

Use the same message sub-type found in Clause 8.1 of TS34.108, with the following exceptions:

Information Element	Value/remark
PRACH Info (for RACH)	
- Available Signature	0 and 1
- Signature	Refer to the parameter set for TS 34.108
- Available SF	0
- Scrambling code number	Refer to the parameter set for TS 34.108
- Puncturing Limit	
- Available Sub-Channel number	0 and 1
- Sub-Channel number	
Downlink DPCH info for one radio link	
- Primary CPICH Info	
- Primary Scrambling Code	Set to the scrambling code for cell 1's P-CPICH.
- PDSCH with SHO DCH Info	Not Present.
- PDSCH code mapping	Not Present.
- Secondary CCPCH Info	
- Selection Indicator	Not Present
- Primary CPICH usage for channel estimation	TRUE
- Secondary CPICH Info	
- Secondary scrambling code	Not Present. Use default (Scrambling code of P-CPICH)
- channelization code	1
- Secondary scrambling code	Not Present. Use default (Scrambling code of P-CPICH)
- STTD indicator	FALSE
- Spreading factor	256
- Code number	255
- Pilot symbol existence	TRUE
- TFCI existence	TRUE
- Fixed or Flexible Position	Flexible
- Timing Offset	0 chips

## MASTER INFORMATION BLOCK (Step 12)

Information Element	Value/remark
MIB Tag	2

## SYSTEM INFORMATION BLOCK TYPE 2 (Step 12)

Information Element	Value/remark
UE Timers and constants in connected mode T305	No update Infinity

## MASTER INFORMATION BLOCK (Step 13)

Information Element	Value/remark
MIB Tag	1

## SYSTEM INFORMATION BLOCK TYPE 2 (Step 13)

Information Element	Value/remark
UE Timers and constants in connected mode T305	5 minutes

## 8.3.1.3.5 Test requirement

After step 1 the UE shall detect the expiry of timer T305 then transmits a CELL UPDATE message setting value “periodic cell update” into IE” Cell update cause”.

After step 3 the UE shall not send any uplink message as a response to CELL UPDATE CONFIRM message sent in step 3.

After step 4 the UE shall send CELL UPDATE message, specifying the cell updating cause to be “periodic cell update”.

After step 6 the UE shall transmit an RNTI REALLOCATION COMPLETE message on the uplink DCCH.

After step 8 the UE shall send CELL UPDATE message, specifying the cell updating cause to be “periodic cell update”.

After step 10 the UE shall transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message using the PRACH radio resources allocated.



Between step 12 and step 13 the UE shall cease periodic cell updating activity and not transmit any CELL UPDATE messages.

After step 13 the UE shall transmit a CELL UPDATE message stating the cell update cause to be periodic updating, 5 minutes after the SS has modified the BCCH data.

#### 8.3.1.4 Cell Update: periodical cell update in CELL\_PCH

##### 8.3.1.4.1 Definition

##### 8.3.1.4.2 Conformance requirement

This procedure is to update UTRAN with the information of the current cell when the UE detects that it is still in the service area, while residing in the CELL\_PCH state, after the expiry of timer T305.

##### Reference

3GPP TS 25.331 clause 8.3.1

##### 8.3.1.4.3 Test purpose

To confirm that the UE, in CELL\_PCH state, executes a cell update procedure after the expiry of timer T305. To confirm that the UE sends an appropriate response message after receiving the CELL UPDATE CONFIRM message.

##### 8.3.1.4.4 Method of test

##### Initial Condition

System Simulator: 1 cell

UE: CELL\_PCH

##### Test Procedure

The UE starts from CELL\_PCH state. When the UE detects the expiry of periodic cell updating timer T305 according to the system information, the UE moves to CELL\_FACH state. It shall transmit a CELL UPDATE message on the uplink CCCH and set the value "periodic cell update" into IE "Cell update cause". SS answers with a CELL UPDATE CONFIRM message, with IE "DRX Indicator" set to "No DRX". IEs related to RNTI, PRACH and S-CCPCH are omitted from this message. SS checks to confirm that the UE does not send a response. SS sends a RNTI REALLOCATION message to the UE, stating the new C-RNTI identity to be used and also setting IE "DRX Indicator" to "DRX with cell updating". The UE shall reply with RNTI REALLOCATION COMPLETE message and transit to CELL\_PCH state. Next, SS stays idle until timer T305 is once again expired. The UE shall transmit CELL UPDATE message in order to initiate cell updating procedure. After the SS receives this message, it transmits a CELL UPDATE CONFIRM message which includes the IEs "new C-RNTI" and "new U-RNTI". Then the UE shall transmit an RNTI REALLOCATION COMPLETE message on the uplink DCCH and before entering CELL\_PCH state. In the next sequence, SS assigns a new U-RNTI identity to the UE by transmitting RNTI REALLOCATION message again. Once again, the IE "DRX Indicator" is set to "DRX with cell updating". After reception of this message, the UE moves to CELL\_PCH state and start to listen to the paging sub-channels derived based on the value of new U-RNTI given. Finally, SS waits until T305 has expired once more, the UE shall send CELL UPDATE message again on uplink CCCH. SS replies with CELL UPDATE CONFIRM which includes IEs "PRACH Info" and "Secondary CCPCH Info". The UE shall transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH using PRACH indicated in CELL UPDATE CONFIRM message.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is in the CELL_PCH state. SS waits until T305 has expired.
2		→	CELL UPDATE	The UE shall move to CELL_FACH state and transmits this message with the IE "Cell update cause" set to "periodic cell update".
3		←	CELL UPDATE CONFIRM	Does not include IEs "PRACH Info", "Secondary CCPCH Info", "new C-RNTI" or "new U-RNTI".
4				SS verifies that no response message is received.
5		←	RNTI REALLOCATION	Allocates a new C-RNTI identity to UE and set IE"DRX Indicator" to "DRX with Cell updating".
6		→	RNTI REALLOCATION COMPLETE	UE shall move to CELL_PCH state
7				SS remains idle for a period sufficient for T305 timer to expire.
8		→	CELL UPDATE	This message shall contain the new U-RNTI identity assigned in step 5.
9		←	CELL UPDATE CONFIRM	New C-RNTI and U-RNTI identities are assigned.
10		→	RNTI REALLOCATION COMPLETE	
11		←	RNTI REALLOCATION	SS assigns a new U-RNTI identity to the UE. At the same time, it sets IE"DRX Indicator" to "DRX with cell updating".
12		→	RNTI REALLOCATION COMPLETE	UE shall move to CELL_PCH state after sending this message.
13				SS waits for T305 to expire.
14			CELL UPDATE	
15			CELL UPDATE CONFIRM	Allocates new common physical resources by specifying IEs"PRACH Info" and "Secondary CCPCH Info".
16			PHYSICAL CHANNEL RECONFIGURATION COMPLETE	

## Specific Message Contents

## CELL UPDATE (Step 2)

Information Element	Value/remark
U-RNTI	Check to see if set to '0000 0000 0001'
- SRNC Identity	Check to see if set to '0000 0000 0000 0000 0000 0001'
- S-RNTI	Not checked
Integrity check info	Check to see if set to 'FALSE'
AM_RLC error indicator (for C-plane)	Check to see if set to 'FALSE'
AM_RLC error indicator (for U-plane)	Check to see if it is present
Hyper frame number	Check to see if set to 'Periodic cell updating'
Cell Update Cause	Check to see if it is absent or set to 'FALSE'
Protocol error indicator	Check to see if it is absent
Measured results on RACH	Check to see if it is absent
Protocol error information	Check to see if it is absent

## CELL UPDATE CONFIRM (Step 3)

Use the same message sub-type found in Clause 8.1 of TS34.108.

## RNTI REALLOCATION (Step 5 and step 11)

Use the same message sub-type found in Clause 8.1 of TS34.108, with the following exceptions:

Information Element	Value/remark
New U-RNTI	Set to '0000 0000 0001'
- SRNC Identity	Set to '0000 0000 0000 0000 1111'
- S-RNTI	Set to '0000 0000 0000 1111'
New C-RNTI	DRX with cell updating
DRX Indicator	

## CELL UPDATE (Step 8)

Information Element	Value/remark
U-RNTI	Check to see if set to '0000 0000 0001'
- SRNC Identity	Check to see if set to '0000 0000 0000 0000 1111'
- S-RNTI	Not checked
Integrity check info	Check to see if set to 'FALSE'
AM_RLC error indicator (for C-plane)	Check to see if set to 'FALSE'
AM_RLC error indicator (for U-plane)	Check to see if it is present
Hyper frame number	Check to see if set to 'Periodic cell updating'
Cell Update Cause	Check to see if it is absent or set to 'FALSE'
Protocol error indicator	Check to see if it is absent
Measured results on RACH	Check to see if it is absent
Protocol error information	Check to see if it is absent

## CELL UPDATE CONFIRM (Step 9)

Use the same message sub-type found in Clause 8.1 of TS34.108, with the following exceptions:

Information Element	Value/remark
New U-RNTI	
- SRNC Identity	Set to '0000 0000 0001'
- S-RNTI	Set to '0000 0000 0000 0000 1010'
New C-RNTI	Set to '0000 0000 0000 0101'

## CELL UPDATE (Step 14)

Information Element	Value/remark
U-RNTI	
- SRNC Identity	Check to see if set to '0000 0000 0001'
- S-RNTI	Check to see if set to '0000 0000 0000 0000 1111'
Integrity check info	Not checked
AM_RLC error indicator (for C-plane)	Check to see if set to 'FALSE'
AM_RLC error indicator (for U-plane)	Check to see if set to 'FALSE'
Hyper frame number	Check to see if it is present
Cell Update Cause	Check to see if set to 'Periodic cell updating'
Protocol error indicator	Check to see if it is absent or set to 'FALSE'
Measured results on RACH	Check to see if it is absent
Protocol error information	Check to see if it is absent

## CELL UPDATE CONFIRM (Step 15)

Use the same message sub-type found in Clause 8.1 of TS34.108, with the following exceptions:

Information Element	Value/remark
PRACH Info (for RACH)	
- Available Signature	0 and 1
- Signature	Refer to the parameter set for TS 34.108
- Available SF	0
- Scrambling code number	Refer to the parameter set for TS 34.108
- Puncturing Limit	0 and 1
- Available Sub-Channel number	
- Sub-Channel number	
Downlink DPCH info for one radio link	
- Primary CPICH Info	Set to the scrambling code for cell 1's P-CPICH.
- Primary Scrambling Code	Not Present.
- PDSCH with SHO DCH Info	Not Present.
- PDSCH code mapping	
- Secondary CCPCH Info	
- Selection Indicator	Not Present
- Primary CPICH usage for channel estimation	TRUE
- Secondary CPICH Info	
- Secondary scrambling code	Not Present. Use default (Scrambling code of P-CPICH)
- Channelization code	1
- Secondary scrambling code	Not Present. Use default (Scrambling code of P-CPICH)
- STTD indicator	FALSE
- Spreading factor	256
- Code number	255
- Pilot symbol existence	TRUE
- TFCI existence	TRUE
- Fixed or Flexible Position	Flexible
- Timing Offset	0 chips

## 8.3.1.4.5 Test requirement

After step 2 the UE shall detect the expiry of timer T305, it shall then move to CELL\_FACH state and transmits a CELL UPDATE message with the IE" Cell update cause" set to "periodic cell update".

After step 5 the UE shall reply with RNTI REALLOCATION COMPLETE message. It shall subsequently move to CELL\_PCH state.

After step 7 the UE shall initiate a cell updating procedure by the transmission of a CELL UPDATE message. In this message, it shall indicate the new U-RNTI value assigned in step 5 and also set IE"Cell Updating Cause" to "Periodic Cell Updating".

After step 11 the UE shall reply with RNTI REALLOCATION COMPLETE message. It shall subsequently move to CELL\_PCH state.

After step 13 the UE shall send a CELL UPDATE message. After step 15 the UE shall transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the new PRACH channel assigned by the received CELL UPDATE CONFIRM message in step 15.

### 8.3.1.5 Cell Update: UL data transmission in URA\_PCH

#### 8.3.1.5.1 Definition

#### 8.3.1.5.2 Conformance requirement

This procedure is to update UTRAN with the current cell information if the UE wants to transmit UL data while in URA\_PCH state.

#### Reference

3GPP TS 25.331 clause 8.3.1

#### 8.3.1.5.3 Test purpose

To confirm that the UE executes a cell update procedure when the UE transmits UL data if the UE is in URA\_PCH state. To confirm that the UE sends the correct response to CELL UPDATE CONFIRM message, after it has taken into consideration the current TFS and/or TFCS settings.

#### 8.3.1.5.4 Method of test

#### Initial Condition

System Simulator: 1cell

UE: URA\_PCH

#### Test Procedure

The UE starts from URA\_PCH state, after the operator initiates an outgoing packet data transmission. The UE then moves to CELL\_FACH state and transmits a CELL UPDATE message to the SS on the uplink CCCH, with the IE "Cell update cause" set to value "UL data transmission". After receiving such a message, SS transmits CELL UPDATE CONFIRM message without specifying any of the following IEs: "new C-RNTI", "new U-RNTI", "PRACH Info" and "Secondary CCPCH Info". The UE shall stay in CELL\_FACH state and transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the DCCH. SS waits until uplink data transmission is completed and sends a RNTI REALLOCATION message. The UE shall reply with RNTI REALLOCATION COMPLETE message. Since the IE "DRX Indicator" is set to "DRX with URA updating" in the downlink message, the UE shall move to URA\_PCH state. Next SS modifies the contents of SYSTEM INFORMATION BLOCK TYPE 5 and 6 messages. See specific message contents for further details. SS then prompts the test operator to transmit packet data. The UE shall send CELL UPDATE message and specifies the cause to be "UL data transmission". SS replies with the default CELL UPDATE CONFIRM message defined in TS 34.108. After receiving this message, the UE shall transmit TRANSPORT CHANNEL RECONFIGURATION COMPLETE message and remains in CELL\_FACH state. SS again waits for the transmission of user packet data to complete and then sends RNTI REALLOCATION message on the downlink DCCH. The IE "DRX Indicator" is set to "DRX with URA updating". The UE shall move to URA\_PCH state and acknowledges that it starts using the new RNTI identity provided. Finally, SS prompts the test operator to transmit packet data. The UE shall send CELL UPDATE message once more. After the SS receives this message, it replies with a CELL UPDATE CONFIRM message including the IEs "PRACH info", "Secondary CCPCH info". The IE "DRX Indicator" is set to "No DRX" in this message. The UE shall transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink PRACH specified in the CELL UPDATE CONFIRM message. Then the UE shall enter CELL\_FACH state and proceed to transmit packet data.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is brought to URA_PCH state. SS prompts the test operator to begin a packet data transmission.
2		→	CELL UPDATE	The UE shall move to CELL FACH state with the message set to "UL data transmission" in IE "Cell update cause".
3		←	CELL UPDATE CONFIRM	Use default message content.
4		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	
5				SS waits until transmission of uplink data has been completed.
6		←	RNTI REALLOCATION	IE "DRX Indicator" set to "DRX with URA update"
7		→	RNTI REALLOCATION COMPLETE	UE moves to URA_PCH state.
8				SS modifies MASTER INFORMATION BLOCK, SYSTEM INFORMATION BLOCK TYPE 5 and 6 messages. SS prompts test operator to initiate a packet data transmission.
9		→	CELL UPDATE	Should be same as in step 2
10		←	CELL UPDATE CONFIRM	Use default message content.
11		→	TRANSPORT CHANNEL RECONFIGURATION COMPLETE	
12				SS waits until transmission of uplink data has been completed.
13		←	RNTI REALLOCATION	IE "DRX Indicator" set to "DRX with URA update"
14		→	RNTI REALLOCATION COMPLETE	UE moves to URA_PCH state.
15				SS prompts test operator to initiate a packet data transmission.
16		→	CELL UPDATE	Should be same as in step 2
17		←	CELL UPDATE CONFIRM	Including the IEs "PRACH info", "Secondary CCPCH"
18		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	SS verifies that this message is received from PRACH physical channel using the configurations set in IE "PRACH Info" in CELL UPDATE CONFIRM message.

## Specific Message Contents

## CELL UPDATE (Step 2, 9 and 16)

Information Element	Value/remark
---------------------	--------------

U-RNTI - SRNC Identity - S-RNTI Integrity check info AM_RLC error indicator (for C-plane) AM_RLC error indicator (for U-plane) Hyper frame number Cell Update Cause Protocol error indicator Measured results on RACH Protocol error information	Check to see if set to '0000 0000 0001' Check to see if set to '0000 0000 0000 0000 1111' Not checked Check to see if set to 'FALSE' Check to see if set to 'FALSE' Check to see if it is present Check to see if set to 'UL Data Transmission' Check to see if it is absent or set to 'FALSE' Check to see if it is absent Check to see if it is absent
--	---

## CELL UPDATE CONFIRM (Step 3 and 10)

Use the same message sub-type found in Annex A.

## CELL UPDATE CONFIRM (Step 17)

Use the same message sub-type found in Annex A, with the following exceptions:

Information Element	Value/remark
PRACH Info (for RACH)	
- Available Signature	0
- Signature	Refer to the parameter set for TS 34.108
- Available SF	0
- Scrambling code number	Refer to the parameter set for TS 34.108
- Puncturing Limit	
- Available Sub-Channel number	
- Sub-Channel number	0
Downlink DPCH info for one radio link	
- Primary CPICH Info	
- Primary Scrambling Code	Set to the scrambling code for cell 1's P-CPICH.
- PDSCH with SHO DCH Info	Not Present.
- PDSCH code mapping	Not Present.
- Secondary CCPCH Info	
- Selection Indicator	Not Present
- Primary CPICH usage for channel estimation	TRUE
- Secondary CPICH Info	
- Secondary scrambling code	Not Present. Use default (Scrambling code of P-CPICH)
- Channelization code	1
- Secondary scrambling code	Not Present. Use default (Scrambling code of P-CPICH)
- STTD indicator	FALSE
- Spreading factor	256
- Code number	255
- Pilot symbol existence	TRUE
- TFCI existence	TRUE
- Fixed or Flexible Position	Flexible
- Timing Offset	0 chips

## RNTI REALLOCATION (Step 6)

Use the same message sub-type found in Annex A, with the following exceptions:

Information Element	Value/remark
New C-RNTI	'0000 0000 0000 1111'
DRX Indicator	DRX with URA updating

## RNTI REALLOCATION (Step 13)

Use the same message sub-type found in Annex A, with the following exceptions:

Information Element	Value/remark
New C-RNTI DRX Indicator	'0000 0000 1111 1111' DRX with URA updating

#### PHYSICAL CHANNEL RECONFIGURATION COMPLETE (Step 4 and 18)

Only the message type IE in this message will be checked.

#### TRANSPORT CHANNEL RECONFIGURATION COMPLETE (Step 12)

Only the message type IE in this message will be checked.

#### MASTER INFORMATION BLOCK (Step 8)

Use the same message sub-type found in Clause 6.1 of TS34.108, with the following exceptions:

Information Element	Value/remark
MIB Tag	2

#### SYSTEM INFORMATION BLOCK TYPE 5 and TYPE 6 (Step 8)

Use the same message sub-type found in Clause 6.1 of TS34.108, with the following exceptions:

Information Element	Value/remark
PRACH system information	
- RACH TFS	
- CHOICE Transport channel type	Common transport channels
- Dynamic Transport Format Information	
- Number of Transport blocks	1
- RLC Size	296 bits
- Semi-static Transport Format	
- Transmission time interval	80 msec
- Type of channel coding	No coding
- Coding Rate	No Present
- Rate matching attribute	1
- CRC Size	16 bits

#### 8.3.1.5.5 Test requirement

After step 1 the UE shall move to CELL\_FACH state to initiate a cell update procedure and transmits a CELL UPDATE message which is set to "UL data transmission" in IE" Cell update cause".

After step 3 the UE shall transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH.

After step 8 the UE shall initiate cell update procedure and transmit CELL UPDATE message on the uplink CCCH. The IE"Cell update cause" shall be set to "UL data transmission".

After step 10 the UE shall transmit TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH.

After step 15 the UE shall initiate cell update procedure and transmit CELL UPDATE message on the uplink CCCH. The IE"Cell update cause" shall be set to "UL data transmission".

After step 17 the UE shall transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH using the PRACH resources assigned in CELL UPDATE CONFIRM, which is sent in step 17.

#### 8.3.1.6 Cell Update: UL data transmission in CELL\_PCH

##### 8.3.1.6.1 Definition



#### 8.3.1.6.2 Conformance requirement

This procedure is to update UTRAN with the current cell of the UE if the UE wants to transmit UL data when the UE is in CELL\_PCH state.

#### Reference

3GPP TS 25.331 clause 8.3.1

#### 8.3.1.6.3 Test purpose

To confirm that the UE executes a cell update procedure when the UE transmits UL data if the UE is in CELL\_PCH state. To confirm that the UE sends the correct response to CELL UPDATE CONFIRM message, after it has taken into consideration the current TFS and/or TFCS settings.

#### 8.3.1.6.4 Method of test

#### Initial Condition

System Simulator: 1cell

UE: CELL\_PCH

#### Test Procedure

The UE is in the CELL\_PCH state. SS asks the test operator to send some packet data. The UE moves to CELL\_FACH state and transmits a CELL UPDATE message to the SS on the uplink CCCH, which shall indicate "UL data transmission" in IE" Cell update cause". After receiving such a message, SS transmits default CELL UPDATE CONFIRM message. The UE shall stay in CELL\_FACH state and transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the DCCH. SS waits until uplink data transmission is completed and sends a RNTI REALLOCATION message. The UE shall reply with RNTI REALLOCATION COMPLETE message. Since the IE"DRX Indicator" is set to "DRX with cell updating" in the downlink message, the UE shall move to CELL\_PCH state. Next SS modifies the contents of SYSTEM INFORMATION BLOCK TYPE 5 and 6 messages. See specific message contents for further details. SS then prompts the test operator to transmit packet data. The UE shall send CELL UPDATE message and specifies the cause to be "UL data transmission". SS replies with a CELL UPDATE CONFIRM message which assigns a new C-RNTI to the UE. After receiving this message, the UE shall transmit TRANSPORT CHANNEL RECONFIGURATION COMPLETE message and remains in CELL\_FACH state. SS again waits for the transmission of user packet data to complete and then sends RNTI REALLOCATION message on the downlink DCCH. The IE"DRX Indicator" is set to "DRX with cell updating". The UE shall move to CELL\_PCH state and acknowledges that it starts using the new RNTI identity provided. Finally, SS prompts the test operator to transmit packet data. The UE shall send CELL UPDATE message once more. After the SS receives this message, it transmits a CELL UPDATE CONFIRM message which includes the IEs" PRACH info" and set IE"DRX Indicator" to "No DRX". Then the UE shall enter to the CELL\_FACH state after sending PHYSICAL CHANNEL RECONFIGURATION COMPLETE message.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is in the CELL_PCH state. SS prompts the test operator to initiate a packet data call.
2		→	CELL UPDATE	The UE moves to CELL_FACH state and transmit this message which is set to "UL data transmission" in IE "Cell update cause".
3		←	CELL UPDATE CONFIRM	Use default message content.
4		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	
5				SS waits until transmission of uplink data has been completed.
6		←	RNTI REALLOCATION	IE "DRX Indicator" set to "DRX with cell update"
7		→	RNTI REALLOCATION COMPLETE	UE moves to CELL_PCH state.
8				SS modifies MASTER INFORMATION BLOCK, SYSTEM INFORMATION BLOCK TYPE 5 and 6 messages. SS prompts test operator to initiate a packet data transmission.
9		→	CELL UPDATE	Should be same as in step 2
10		←	CELL UPDATE CONFIRM	Use default message content.
11		→	TRANSPORT CHANNEL RECONFIGURATION COMPLETE	
12				SS waits until transmission of uplink data has been completed.
13		←	RNTI REALLOCATION	IE "DRX Indicator" set to "DRX with cell update"
14		→	RNTI REALLOCATION COMPLETE	UE moves to CELL_PCH state.
15				SS prompts test operator to initiate a packet data transmission.
16		→	CELL UPDATE	Should be same as in step 2
17		←	CELL UPDATE CONFIRM	Including the IE "PRACH info" and set IE "DRX Indicator" to "No DRX".
18		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	SS verifies that this message is received from PRACH physical channel using the configurations set in IE "PRACH Info" in CELL UPDATE CONFIRM message.

## Specific Message Contents

## CELL UPDATE (Step 2, 9 and 16)

Information Element	Value/remark
---------------------	--------------

U-RNTI	Check to see if set to '0000 0000 0001'
- SRNC Identity	Check to see if set to '0000 0000 0000 0000 1111'
- S-RNTI	Not checked
Integrity check info	Check to see if set to 'FALSE'
AM_RLC error indicator (for C-plane)	Check to see if set to 'FALSE'
AM_RLC error indicator (for U-plane)	Check to see if it is present
Hyper frame number	Check to see if set to 'UL Data Transmission'
Cell Update Cause	Check to see if it is absent or set to 'FALSE'
Protocol error indicator	Check to see if it is absent
Measured results on RACH	Check to see if it is absent
Protocol error information	Check to see if it is absent

**CELL UPDATE CONFIRM (Step 3 and 10)**

Use the same message sub-type found in Annex A.

**CELL UPDATE CONFIRM (Step 17)**

Use the same message sub-type found in Annex A, with the following exceptions:

Information Element	Value/remark
PRACH Info (for RACH)	
- Available Signature	0
- Signature	Refer to the parameter set for TS 34.108
- Available SF	0
- Scrambling code number	Refer to the parameter set for TS 34.108
- Puncturing Limit	
- Available Sub-Channel number	
- Sub-Channel number	0
Downlink DPCH info for one radio link	
- Primary CPICH Info	
- Primary Scrambling Code	Set to the scrambling code for cell 1's P-CPICH.
- PDSCH with SHO DCH Info	Not Present.
- PDSCH code mapping	Not Present.
- Secondary CCPCH Info	
- Selection Indicator	Not Present
- Primary CPICH usage for channel estimation	TRUE
- Secondary CPICH Info	
- Secondary scrambling code	Not Present. Use default (Scrambling code of P-CPICH)
- Channelization code	1
- Secondary scrambling code	Not Present. Use default (Scrambling code of P-CPICH)
- STTD indicator	FALSE
- Spreading factor	256
- Code number	255
- Pilot symbol existence	TRUE
- TFCI existence	TRUE
- Fixed or Flexible Position	Flexible
- Timing Offset	0 chips

**RNTI REALLOCATION (Step 6)**

Use the same message sub-type found in Annex A, with the following exceptions:

Information Element	Value/remark
New C-RNTI	'0000 0000 0000 1111'
DRX Indicator	DRX with cell updating

**RNTI REALLOCATION (Step 13)**

Use the same message sub-type found in Annex A, with the following exceptions:

Information Element	Value/remark
New C-RNTI DRX Indicator	'0000 0000 1111 1111' DRX with cell updating

PHYSICAL CHANNEL RECONFIGURATION COMPLETE (Step 4 and 18)

Only the message type IE in this message will be checked.

TRANSPORT CHANNEL RECONFIGURATION COMPLETE (Step 12)

Only the message type IE in this message will be checked.

MASTER INFORMATION BLOCK (Step 8)

Use the same message sub-type found in Clause 6.1 of TS34.108, with the following exceptions:

Information Element	Value/remark
MIB Tag	2

SYSTEM INFORMATION BLOCK TYPE 5 and TYPE 6 (Step 8)

Use the same message sub-type found in Clause 6.1 of TS34.108, with the following exceptions:

Information Element	Value/remark
PRACH system information	
- RACH TFS	
- CHOICE Transport channel type	Common transport channels
- Dynamic Transport Format Information	
- Number of Transport blocks	1
- RLC Size	296 bits
- Semi-static Transport Format	
- Transmission time interval	80 msec
- Type of channel coding	No coding
- Coding Rate	No Present
- Rate matching attribute	1
- CRC Size	16 bits

#### 8.3.1.6.5 Test requirement

After step 1 the UE shall move to CELL\_FACH state, initiate a cell update procedure for the UL data transmission, and transmit a CELL UPDATE message which is set to "UL data transmission" in IE" Cell update cause".

After step 3 the UE shall transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH.

After step 8 the UE shall initiate cell update procedure and transmit CELL UPDATE message on the uplink CCCH. The IE"Cell update cause" shall be set to "UL data transmission".

After step 10 the UE shall transmit TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH.

After step 15 the UE shall initiate cell update procedure and transmit CELL UPDATE message on the uplink CCCH. The IE"Cell update cause" shall be set to "UL data transmission".

After step 17 the UE shall transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH using the PRACH resources assigned in CELL UPDATE CONFIRM, which is sent in step 17.

#### 8.3.1.7 Cell Update: paging response in URA\_PCH

##### 8.3.1.7.1 Definition

#### 8.3.1.7.2 Conformance requirement

This procedure is to update UTRAN with the current cell of the UE after it receives a PAGING TYPE 1 message addressed to itself while it is in URA\_PCH state.

#### Reference

3GPP TS 25.331 clause 8.3.1

#### 8.3.1.7.3 Test purpose

To confirm that the UE executes a cell update procedure when it receives a PAGING TYPE1 message while operating in URA\_PCH state. To confirm that the UE responds with an appropriate uplink message after receiving a CELL UPDATE CONFIRM message during cell updating procedure triggered by paging.

#### 8.3.1.7.4 Method of test

##### Initial Condition

System Simulator: 1 cell

UE: URA\_PCH

##### Test Procedure

The UE is brought to URA\_PCH state. SS transmits a PAGING TYPE 1 message to page for the UE, setting IE" paging originator" to "UTRAN Originator". The UE shall move to CELL\_FACH state and transmits a CELL UPDATE message to the SS on the uplink CCCH. This message shall set IE" Cell update cause" to "Paging Response". After the SS receives this message, it transmits the default CELL UPDATE CONFIRM message. The UE shall stay in CELL\_FACH state and transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the DCCH. SS then sends a RNTI REALLOCATION message. The UE shall reply with RNTI REALLOCATION COMPLETE message. In this message, the IE"DRX Indicator" is set to "DRX with URA updating". As a result, the UE shall move to URA\_PCH state. Next SS modifies the contents of SYSTEM INFORMATION BLOCK TYPE 5 and 6 messages. See specific message contents for further details. SS pages the UE again using the U-RNTI identity. The UE shall send CELL UPDATE message and specify the cause to be "Paging Response". SS replies with the default CELL UPDATE CONFIRM message again. After receiving this message, the UE shall transmit TRANSPORT CHANNEL RECONFIGURATION COMPLETE message and remains in CELL\_FACH state. SS sends another RNTI REALLOCATION message on the downlink DCCH, with the IE"DRX Indicator" set to "DRX with URA updating". The UE shall move to URA\_PCH state and acknowledges that it starts using the new C-RNTI identity provided by transmitting RNTI REALLOCATION COMPLETE message. SS pages the UE again using PAGING TYPE 1 message. The UE shall send CELL UPDATE message once more. SS transmits a CELL UPDATE CONFIRM message which includes the IEs"new C-RNTI", "new U-RNTI" on the downlink DCCH. The UE shall send PHYSICAL CHANNEL RECONFIGURATION COMPLETE message. In the next sequence, SS transmits RNTI REALLOCATION message and assigns a new C-RNTI identity to the UE. The UE shall reply with RNTI REALLOCATION COMPLETE message and move to URA\_PCH state. SS then pages the UE once more using PAGING TYPE 1 message. The UE shall initial the cell update procedure by dispatching a CELL UPDATE message on the uplink CCCH. SS replies with a CELL UPDATE CONFIRM message which includes information of the PRACH channel to be used. The UE shall respond with a PHYSICAL CHANNEL RECONFIGURATION COMPLETE, sent on the DCCH supported by the PRACH indicated in CELL UPDATE CONFIRM message.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is first brought to URA_PCH state.
2		←	PAGING TYPE 1	SS transmits a PAGING TYPE1 message to the UE which includes the UE's assigned U-RNTI with the IE" paging originator" set to "UTRAN originator".
3		→	CELL UPDATE	The UE shall move to CELL_FACH state and transmits this message with the IE" Cell update cause" set to "paging response".
4		←	CELL UPDATE CONFIRM	Use the default message from TS 34.108 Clause 8.
5		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	The UE shall move to CELL_FACH state and transmits this message.
6				SS modifies MASTER INFORMATION BLOCK, SYSTEM INFORMATION BLOCK TYPE 5 and 6 message. The TFS of the PRACH is changed.
7		←	RNTI REALLOCATION	Allocates a new U-RNTI and set IE"DRX Indicator" to "DRX with URA updating".
8		→	RNTI REALLOCATION COMPLETE	UE moves to URA_PCH state.
9		←	PAGING TYPE 1	SS pages the UE again
10		→	CELL UPDATE	IE" Cell update cause" shall be set to "paging response".
11		←	CELL UPDATE CONFIRM	Use the default message from TS 34.108 Clause 8.
12		→	TRANSPORT CHANNEL RECONFIGURATION COMPLETE	The UE shall move to CELL_FACH state and transmits this message.
13		←	RNTI REALLOCATION	Allocates a new U-RNTI and set IE"DRX Indicator" to "DRX with URA updating".
14		→	RNTI REALLOCATION COMPLETE	UE moves to URA_PCH state.
15		←	PAGING TYPE 1	SS pages the UE again
16		→	CELL UPDATE	IE" Cell update cause" shall be set to "paging response".
17		←	CELL UPDATE CONFIRM	IE "new C-RNTI" is included in this message
18		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	
19		←	RNTI REALLOCATION	Allocates a new C-RNTI and set IE"DRX Indicator" to "DRX with URA updating".
20		→	RNTI REALLOCATION COMPLETE	UE moves to URA_PCH state.
21		←	PAGING TYPE 1	UE paged using U-RNTI identity.
22		→	CELL UPDATE	IE"Cell Update Cause" shall be set to "Paging Response"
23		←	CELL UPDATE CONFIRM	IE "PRACH Info" is included.

24	→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	This message shall be sent on the PRACH resource allocated in step 23.
----	---	---	--

## Specific Message Contents

## PAGING TYPE 1 (Step 2, 9, 15 and 21)


Information Element	Value/remark
CHOICE Paging Originator - U-RNTI - SRNC Identity - S-RNTI	UTRAN Originator  '0000 0000 0001' '0000 0000 0000 0000 0001'

## CELL UPDATE (Step 3, 10, 16 and 22)

Information Element	Value/remark
U-RNTI - SRNC Identity - S-RNTI Integrity check info AM_RLC error indicator (for C-plane) AM_RLC error indicator (for U-plane) Hyper frame number Cell Update Cause Protocol error indicator Measured results on RACH Protocol error information	   Check to see if set to '0000 0000 0001' Check to see if set to '0000 0000 0000 0000 0001' Not checked Check to see if set to 'FALSE' Check to see if set to 'FALSE' Check to see if it is present Check to see if set to 'Paging Response' Check to see if it is absent or set to 'FALSE' Check to see if it is absent Check to see if it is absent

## CELL UPDATE CONFIRM (Step 4 and 11)

Use the same message sub-type found in Annex A.

## PHYSICAL CHANNEL RECONFIGURATION (Step 5, 18 and 24)

Only the message type for this message is checked.

## MASTER INFORMATION BLOCK (Step 6)

Use the same message sub-type found in Clause 6.1 of TS34.108, with the following exceptions:

Information Element	Value/remark
MIB Tag	2

## SYSTEM INFORMATION BLOCK TYPE 5 and TYPE 6 (Step 6)

Use the same message sub-type found in Clause 6.1 of TS34.108, with the following exceptions:

Information Element	Value/remark
PRACH system information	
- RACH TFS	
- CHOICE Transport channel type	Common transport channels
- Dynamic Transport Format Information	
- Number of Transport blocks	1
- RLC Size	296 bits
- Semi-static Transport Format	
- Transmission time interval	80 msec
- Type of channel coding	No coding
- Coding Rate	No Present
- Rate matching attribute	1
- CRC Size	16 bits

### RNTI REALLOCATION (Step 7, 13 and 19)

Use the same message sub-type found in Annex A, with the following exceptions:

Information Element	Value/remark
New C-RNTI	Selects any arbitrary unused 16-bits string
DRX Indicator	DRX with URA updating

### TRANSPORT CHANNEL RECONFIGURATION (Step 12)

Only the message type for this message is checked.

### CELL UPDATE CONFIRM (Step 17)

Information Element	Value/remark
New C-RNTI	Selects any arbitrary unused 16-bits string

### CELL UPDATE CONFIRM (Step 23)

Use the same message sub-type found in Annex A, with the following exceptions:



Information Element	Value/remark
PRACH Info (for RACH)	
- Available Signature	1
- Signature	Refer to the parameter set for TS 34.108
- Available SF	0
- Scrambling code number	Refer to the parameter set for TS 34.108
- Puncturing Limit	
- Available Sub-Channel number	1
- Sub-Channel number	
Downlink DPCH info for one radio link	
- Primary CPICH Info	
- Primary Scrambling Code	Set to the scrambling code for cell 1's P-CPICH.
- PDSCH with SHO DCH Info	Not Present.
- PDSCH code mapping	Not Present.
- Secondary CCPCH Info	
- Selection Indicator	Not Present
- Primary CPICH usage for channel estimation	TRUE
- Secondary CPICH Info	
- Secondary scrambling code	Not Present. Use default (Scrambling code of P-CPICH)
- Channelization code	1
- Secondary scrambling code	Not Present. Use default (Scrambling code of P-CPICH)
- STTD indicator	FALSE
- Spreading factor	256
- Code number	255
- Pilot symbol existence	TRUE
- TFCI existence	TRUE
- Fixed or Flexible Position	Flexible
- Timing Offset	0 chips

#### 8.3.1.7.5 Test requirement

After step 2 the UE shall answer to the paging message then moves to CELL\_FACH state and transmit a CELL UPDATE message. This message shall set the value "paging response" into IE" Cell update cause".

After step 4 the UE shall transmit PHYSICAL CHANNEL RECONFIGURTION COMPLETE message on the uplink DCCH and enters CELL\_FACH state.

After step 9 the UE shall respond the paging by replying with a CELL UPDATE message. IE"Cell Update Cause" shall be set to "Paging Response" in this message.

After step 11 the UE shall transmit TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH.

After step 15 the UE shall answer the PAGING TYPE 1 message by sending a CELL UPDATE message. The IE"Cell Update Cause" shall have a value equals to "Paging Response".

After step 17 the UE shall transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH.

After step 21 the UE shall respond to the PAGING TYPE 1 message addressed to itself and initiate a cell update procedure. It shall transmit CELL UPDATE message with the IE"Cell Update Cause" set to "Paging Response" in this message.

After step 23 the UE shall send PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH using the PRACH channel indicated in CELL UPDATE CONFIRM message sent in step 23.

#### 8.3.1.8 Cell Update: paging response in CELL\_PCH

##### 8.3.1.8.1 Definition

#### 8.3.1.8.2 Conformance requirement

This procedure is to update UTRAN with the current cell when the UE receives a PAGING TYPE 1 message addressed to it while in CELL\_PCH state.

#### Reference

3GPP TS 25.331 clause 8.3.1

#### 8.3.1.8.3 Test purpose

To confirm that the UE executes a cell update procedure when the UE receives a PAGING TYPE1 message while in CELL\_PCH state. To confirm that the UE sends an appropriate uplink message after receiving a CELL UPDATE CONFIRM message during cell updating procedure due to paging.

#### 8.3.1.8.4 Method of test

##### Initial Condition

System Simulator: 1 cell

UE: CELL\_PCH

##### Test Procedure

The UE is in the CELL\_PCH state. The SS transmits a PAGING TYPE 1 message to the UE on the downlink PCCH which includes the connected mode identity of the UE and set value "UTRAN originator" into IE" paging originator". The UE shall respond to this message. Then the UE shall move to CELL\_FACH state and transmits a CELL UPDATE message to the SS on the uplink CCCH which and set the value "Paging Response" into IE" Cell update cause". After the SS receives this message, it transmits the default CELL UPDATE CONFIRM message. The UE shall stay in CELL\_FACH state and transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the DCCH. SS then sends a RNTI REALLOCATION message. The UE shall reply with RNTI REALLOCATION COMPLETE message. In this message, the IE"DRX Indicator" is set to "DRX with cell updating". As a result, the UE shall move to CELL\_PCH state. SS pages the UE again using the U-RNTI identity. The UE shall send CELL UPDATE message and specify the cause to be "Paging Response". SS replies with a CELL UPDATE CONFIRM message which comprises a new C-RNTI identity for the UE. After receiving this message, the UE shall transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message and remains in CELL\_FACH state. Next SS modifies the contents of SYSTEM INFORMATION BLOCK TYPE 5 and 6 messages. See specific message contents for further details. SS then sends another RNTI REALLOCATION message on the downlink DCCH, with the IE"DRX Indicator" set to "DRX with cell updating". The UE shall move to CELL\_PCH state and acknowledges that it starts using the new C-RNTI identity provided by transmitting RNTI REALLOCATION COMPLETE message. SS pages the UE again using PAGING TYPE 1 message. The UE shall send CELL UPDATE message once more. SS replies with a CELL UPDATE CONFIRM message which includes the IE"new C-RNTI" to the UE on the downlink DCCH. Then the UE shall transmit an TRANSPORT CHANNEL RECONFIGURTION COMPLETE message on the uplink DCCH and enters the CELL\_FACH state. In the final sequence, SS transmits RNTI REALLOCATION message and assigns a new C-RNTI identity to the UE. The UE shall reply with RNTI REALLOCATION COMPLETE message and move to CELL\_PCH state. SS then pages the UE once more using PAGING TYPE 1 message. The UE shall initial the cell update procedure by dispatching a CELL UPDATE message on the uplink CCCH. SS replies with a CELL UPDATE CONFIRM message which includes the IE"PRACH Info". The UE shall respond with a PHYSICAL CHANNEL RECONFIGURATION COMPLETE, sent on the DCCH supported by the PRACH indicated in CELL UPDATE CONFIRM message. Next, SS sends RNTI REALLOCATION message to UE with the "DRX Indicator" IE set to "DRX with cell updating". The UE shall respond by transmitting RNTI REALLOCATION COMPLETE message on the uplink DCCH and then move to CELL\_PCH state. SS pages the UE again using connected mode identity at the paging occasions assigned to the UE. The UE shall answer to the page and sent CELL UPDATE message on the uplink CCCH. SS responds to the reception of this message by transmitting a CELL UPDATE CONFIRM message on the downlink DCCH. In this message, a set of new PRACH resources is assigned. The UE shall acknowledge the receipt of this message and send PHYSICAL CHANNEL RECONFIGURATION COMPLETE on the uplink DCCH supported by the new PRACH channel.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is brought to CELL_PCH state.
2		←	PAGING TYPE 1	The SS transmits a PAGING TYPE1 message addressing the UE with its connected mode identity and set IE" paging originator" to "UTRAN originator".
3		→	CELL UPDATE	The UE shall move to CELL_FACH state and transmits this message with the IE" Cell update cause" set to "paging response".
4		←	CELL UPDATE CONFIRM	Use the default message from TS 34.108 Clause 8.
5		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	The UE shall move to CELL_FACH state and transmits this message.
6				SS modifies the contents of MASTER INFORMATION BLOCK, SYSTEM INFORMATION BLOCK TYPE 5 and 6 messages.
7		←	RNTI REALLOCATION	Allocates a new C-RNTI and set IE"DRX Indicator" to "DRX with cell updating"
8		→	RNTI REALLOCATION COMPLETE	UE moves to CELL_PCH state
9		←	PAGING TYPE 1	SS pages the UE again
10		→	CELL UPDATE	IE" Cell update cause" shall be set to "paging response"
11		←	CELL UPDATE CONFIRM	Contains the IE"new C-RNTI"
12		→	TRANSPORT CHANNEL RECONFIGURATION COMPLETE	The UE shall move to CELL_FACH state and transmit this message.
13		←	RNTI REALLOCATION	Allocates a new C-RNTI and set IE"DRX Indicator" to "DRX with cell updating".
14		→	RNTI REALLOCATION COMPLETE	UE moves to CELL_PCH state.
15		←	PAGING TYPE 1	SS pages the UE again
16		→	CELL UPDATE	IE" Cell update cause" shall be set to "paging response".
17		←	CELL UPDATE CONFIRM	Including IE "PRACH Info" in this message.
18		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	To be sent on the new PRACH channel.
19		←	RNTI REALLOCATION	Allocates a new C-RNTI and set IE"DRX Indicator" to "DRX with cell updating".
20		→	RNTI REALLOCATION COMPLETE	UE moves to CELL_PCH state.
21		←	PAGING TYPE 1	UE paged using U-RNTI identity.
22		→	CELL UPDATE	IE"Cell Update Cause" shall be set to "Paging Response"
23		←	CELL UPDATE CONFIRM	IE "PRACH Info" is included.
24		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	This message shall be sent on the PRACH resource allocated in step 23.

## Specific Message Contents

## PAGING TYPE 1

Information Element	Value/remark
CHOICE Paging Originator - U-RNTI - SRNC Identity - S-RNTI	UTRAN Originator  '0000 0000 0001' '0000 0000 0000 0000 0001'

## CELL UPDATE (Step 3, 10 and 16)

Information Element	Value/remark
U-RNTI - SRNC Identity - S-RNTI Integrity check info AM_RLC error indicator (for C-plane) AM_RLC error indicator (for U-plane) Hyper frame number Cell Update Cause Protocol error indicator Measured results on RACH Protocol error information	 Check to see if set to '0000 0000 0001' Check to see if set to '0000 0000 0000 0000 0001' Not checked Check to see if set to 'FALSE' Check to see if set to 'FALSE' Check to see if it is present Check to see if set to 'Paging Response' Check to see if it is absent or set to 'FALSE' Check to see if it is absent Check to see if it is absent

## CELL UPDATE CONFIRM (Step 4)

Use the same message sub-type found Annex A.

## PHYSICAL CHANNEL RECONFIGURATION (Step 5 and 18)

Only the message type for this message is checked.

## MASTER INFORMATION BLOCK (Step 8)

Use the same message sub-type found in Clause 6.1 of TS34.108, with the following exceptions:

Information Element	Value/remark
MIB Tag	2

## SYSTEM INFORMATION BLOCK TYPE 5 and TYPE 6 (Step 6)

Use the same message sub-type found in Clause 6.1 of TS34.108, with the following exceptions:

Information Element	Value/remark
PRACH system information - RACH TFS - CHOICE Transport channel type - Dynamic Transport Format Information - Number of Transport blocks - RLC Size - Semi-static Transport Format - Transmission time interval - Type of channel coding - Coding Rate - Rate matching attribute - CRC Size	 Common transport channels  1 296 bits  80 msec No coding No Present 1 16 bits

## RNTI REALLOCATION (Step 7 ,13 and 19)

Use the same message sub-type found in Annex A, with the following exceptions:

Information Element	Value/remark
New C-RNTI DRX Indicator	Selects any arbitrary unused 16-bits string DRX with cell updating

## TRANSPORT CHANNEL RECONFIGURATION (Step 12)

Only the message type for this message is checked.

## CELL UPDATE CONFIRM (Step 17)

Use the same message sub-type found in Annex A, with the following exceptions:

Information Element	Value/remark
PRACH Info (for RACH)	
- Available Signature	2
- Signature	Refer to the parameter set for TS 34.108
- Available SF	0
- Scrambling code number	Refer to the parameter set for TS 34.108
- Puncturing Limit	
- Available Sub-Channel number	2
- Sub-Channel number	
Downlink DPCH info for one radio link	
- Primary CPICH Info	
- Primary Scrambling Code	Set to the scrambling code for cell 1's P-CPICH.
- PDSCH with SHO DCH Info	Not Present.
- PDSCH code mapping	Not Present.
- Secondary CCPCH Info	
- Selection Indicator	Not Present
- Primary CPICH usage for channel estimation	TRUE
- Secondary CPICH Info	
- Secondary scrambling code	Not Present. Use default (Scrambling code of P-CPICH)
- Channelization code	1
- Secondary scrambling code	Not Present. Use default (Scrambling code of P-CPICH)
- STTD indicator	FALSE
- Spreading factor	256
- Code number	255
- Pilot symbol existence	TRUE
- TFCI existence	TRUE
- Fixed or Flexible Position	Flexible
- Timing Offset	0 chips

## CELL UPDATE CONFIRM (Step 23)

Use the same message sub-type found in Clause 9 of TS34.108, with the following exceptions:

Information Element	Value/remark
PRACH Info (for RACH)	
- Available Signature	1
- Signature	Refer to the parameter set for TS 34.108
- Available SF	0
- Scrambling code number	Refer to the parameter set for TS 34.108
- Puncturing Limit	
- Available Sub-Channel number	1
- Sub-Channel number	
Downlink DPCH info for one radio link	
- Primary CPICH Info	
- Primary Scrambling Code	Set to the scrambling code for cell 1's P-CPICH.
- PDSCH with SHO DCH Info	Not Present.
- PDSCH code mapping	Not Present.
- Secondary CCPCH Info	
- Selection Indicator	Not Present
- Primary CPICH usage for channel estimation	TRUE
- Secondary CPICH Info	
- Secondary scrambling code	Not Present. Use default (Scrambling code of P-CPICH)
- Channelization code	1
- Secondary scrambling code	Not Present. Use default (Scrambling code of P-CPICH)
- STTD indicator	FALSE
- Spreading factor	256
- Code number	255
- Pilot symbol existence	TRUE
- TFCI existence	TRUE
- Fixed or Flexible Position	Flexible
- Timing Offset	0 chips

#### 8.3.1.8.5 Test requirement

After step 2 the UE shall answer to the paging message, moves to CELL\_FACH state, and then transmits a CELL UPDATE message setting "paging response" into IE" Cell update cause".

After step 4 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH and then enter CELL\_FACH state.

After step 9 the UE shall respond to the paging again by sending CELL UPDATE message, with the IE"Cell update cause" set to "Paging response".

After step 11 the UE shall transmit TRANSPORT CHANNEL RECONFIGURATION COMPLETE message to end the cell updating procedure.

After step 15 the UE shall answers the paging message by sending a CELL UPDATE message, with the IE"Cell update cause" set to "Paging response".

After step 17 the UE shall transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH carried by the PRACH indicated in the CELL UPDATE CONFIRM message sent in step 17.

After step 21 the UE shall respond to the paging and initiate a cell update procedure. It shall transmit CELL UPDATE message with the IE"Cell Update Cause" set to "Paging Response" in this message.

After step 23 the UE shall send PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH using the PRACH channel indicated in CELL UPDATE CONFIRM message sent in step 23.

#### 8.3.1.9 Cell Update: re-entering of service area after T305 expiry and being out of service area

##### 8.3.1.9.1 Definition

#### 8.3.1.9.2 Conformance requirement

When a UE detects that it's out of service area after experiencing a T305 timer expiry, it shall try to search for a suitable cell to camp on. At the same time, it shall start timer T307. If the UE subsequently re-enters the service area of a cell before T307 expires, it shall perform a cell update procedure.

#### Reference

3GPP TS 25.331 clause 8.3.1

#### 8.3.1.9.3 Test purpose

To confirm that the UE performs a cell search after experiencing an "out of service area" condition following the expiry of timer T305. To confirm that the UE initiates cell updating procedure if it manages to re-enter the service area.

#### 8.3.1.9.4 Method of test

#### Initial Condition

System Simulator: 2 cells – Cell 1 is active with the CPICH Ec/No set to –80dB and the  $Q_{qualmin}$  value is at –90dBm. Cell 2 is inactive.

UE: CELL\_FACH in cell 1

#### Test Procedure

The UE is in the CELL\_FACH state. SS decreases the transmission power of cell 1 until the cell selection parameter  $S < 0$  (decrease transmission power of cell 1's CPICH by 15 dBm). Following the expiry of periodic cell updating timer T305 according to the system information, the UE shall detect that it is out of service area. Within the time interval equivalent to T307 timer value, the SS restores the transmission power of cell 1. The UE shall find that it is back in service area, and transmits a CELL UPDATE message to the SS on the uplink CCCH. In this message, the IE "Cell update cause" shall be set to "periodic cell update". After the SS receives this message, it transmits a CELL UPDATE CONFIRM message with the IE "DRX Indicator" set "No DRX" on the downlink DCCH. The UE shall enter CELL\_FACH state. Next, cell 1 is switched off. SS waits until T305 timer has expired and then turns on cell 2. The transmission level for cell 2 is such that the CPICH Ec/No value is estimated at –70dB.  $Q_{qualmin}$  of cell 2 is identical to the value used previously by cell 1. The UE shall discover that cell 1 is no longer suitable for camping and initiate a cell search. It shall detect the presence of cell 2 and reselects to this cell. Following this, it shall transmit CELL UPDATE message with the cause set to "Cell Reselection". SS ends this test by sending a CELL UPDATE CONFIRM message.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is in the CELL_FACH state of cell 1.
2				SS decreases the transmission power of cell 1 so that its S value falls below 0.
3				The UE shall detect a "out of service" condition upon expiry of timer T305 and it shall search for other cells to camp on. (T307 timer starts)
4				SS restores cell 1's original power level before T307 timer expires.
5		→	CELL UPDATE	The value "periodic cell update" should be found in IE "Cell update cause" in this message
6		←	CELL UPDATE CONFIRM	"DRX Indicator" is set to "No DRX"
7				SS switches off cell 1 and wait until T305 has expired.
8				SS turns on cell 2 and set the transmission strength of such that CPICH Ec/No is at -70dB.
9			CELL UPDATE	UE shall detect the presence of cell 2 and re-select to it. It shall transmit this message with cause set to "Cell Reselection"
10			CELL UPDATE CONFIRM	

## Specific Message Contents

## CELL UPDATE (Step 5)

Information Element	Value/remark
U-RNTI	Check to see if set to '0000 0000 0001'
- SRNC Identity	Check to see if set to '0000 0000 0000 0000 1111'
- S-RNTI	Not checked
Integrity check info	Check to see if set to 'FALSE'
AM_RLC error indicator (for C-plane)	Check to see if set to 'FALSE'
AM_RLC error indicator (for U-plane)	Check to see if it is present
Hyper frame number	Check to see if set to 'Periodic cell updating'
Cell Update Cause	Check to see if it is absent or set to 'FALSE'
Protocol error indicator	Check to see if it is absent
Measured results on RACH	Check to see if it is absent
Protocol error information	Check to see if it is absent

## CELL UPDATE CONFIRM (Step 6 and 10)

Use the same message sub-type found in Clause 8.1 of TS34.108.



## CELL UPDATE (Step 9)

Information Element	Value/remark
U-RNTI	
- SRNC Identity	Check to see if set to '0000 0000 0001'
- S-RNTI	Check to see if set to '0000 0000 0000 0000 1111'
Integrity check info	Not checked
AM_RLC error indicator (for C-plane)	Check to see if set to 'FALSE'
AM_RLC error indicator (for U-plane)	Check to see if set to 'FALSE'
Hyper frame number	Check to see if it is present
Cell Update Cause	Check to see if set to 'Cell Reselection'
Protocol error indicator	Check to see if it is absent or set to 'FALSE'
Measured results on RACH	Check to see if it is absent
Protocol error information	Check to see if it is absent

## 8.3.1.9.5 Test requirement

After step 4 the UE shall transmit a CELL UPDATE message in which the IE" Cell update cause" is set to the value "periodic cell update".

After step 8 the UE shall reselect to cell 2 and then transmit a CELL UPDATE message, with the IE"Cell Update Cause" set to "Cell Reselection".

## 8.3.1.10 Cell Update: expiry of T307 after T305 expiry and being out of service area

## 8.3.1.10.1 Definition

## 8.3.1.10.2 Conformance requirement

This procedure is required to cater for the case of a failure to update UTRAN with the current cell, after the expiry of T307. In this case, the UE shall return to idle mode and perform cell reselection if possible.

## Reference

3GPP TS 25.331 clause 8.3.1

## 8.3.1.10.3 Test purpose

To confirm that the UE moves to idle mode after the expiry of T307, indicating that it is out of service area when attempting to perform a periodic cell updating procedure.

## 8.3.1.10.4 Method of test

## Initial Condition

System Simulator: 1 cell

UE: CELL\_PCH

## Test Procedure

The UE is in CELL\_PCH state at the start of the test. Before the expiry of periodic cell updating timer T305, SS starts to decrease the downlink transmission power such that the UE discovers that the cell is no longer suitable for camping and this results in a "out of service area" condition. The SS continues to listen to the uplink channel to detect possible attempts to perform a cell updating procedure. The UE shall not send CELL UPDATE message on the uplink DCCH, instead it triggers timer T307. After the expiry of timer T307 the UE shall enter idle state. This is confirmed by the SS, when it sends a PAGING TYPE 1 message to the UE using its U-RNTI identity, and the UE does not respond to the page. SS then attempts to page for the UE again, this time using PAGING TYPE 2 message sent on downlink DCCH. Likewise, the UE shall not respond to this page.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is brought to CELL_PCH state.
2				SS starts to decrease the transmission power until the cell is no longer suitable for camping. The UE shall detect that it is out of service area and refrains from transmitting CELL_UPDATE message due to periodic cell updating.
3				The UE detects the expiry of timer T305 and it searches for other cells to camp on. After the expiry of timer T307, the UE shall enter idle mode.
4		←	PAGING TYPE 1	SS pages the UE at its assigned paging occasion using the allocated U-RNTI value. The UE shall not respond to this page as it has already entered the idle mode.
5		←	PAGING TYPE 2	SS pages the UE on the downlink DCCH. The UE shall not respond to this page.

## Specific Message Contents

## PAGING TYPE 1 (Step 4)

Information Element	Value/remark
Page record list - Paging record - CHOICE Paging originator - U-RNTI - SRNC Identity - S-RNTI BCCH Modification info	UTRAN Originator  Check to see if set to '0000 0000 0001' Check to see if set to '0000 0000 0000 0000 1111' Not Present.

## PAGING TYPE 2 (Step 5)

Information Element	Value/remark
Integrity check info Paging cause  CN domain identity Paging Record Type Identifier	Not Present Set to a cause corresponding to one radio access bearer services supported by the UE. CS-Domain IMSI

## 8.3.1.10.5 Test requirement

After step 4 the UE shall remain in the idle mode and not respond to the paging message sent on PCCH.

After step 5 the UE shall remain in the idle mode and not respond to the paging message addressed to it on the DCCH.

## 8.3.1.11 Cell Update: Success after T302 time-out

## 8.3.1.11.1 Definition

## 8.3.1.11.2 Conformance requirement

The UE transmits a CELL UPDATE message to the UTRAN when it needs to update the UTRAN with the current cell of the UE. When the UE does not receive a CELL UPDATE CONFIRM message upon expiry of timer T302, the UE transmits a CELL UPDATE message repeatedly until its internal counter V302 counter is greater than N302.

## Reference

3GPP TS 25.331 clause 8.3.1

## 8.3.1.11.3 Test purpose

To confirm that the UE repeats the transmission of CELL UPDATE message upon the expiry of timer T302, after failing to receive any response from the SS during T302 timer period.

## 8.3.1.11.4 Method of test

## Initial Condition

System Simulator: 1 cell

UE: CELL\_FACH

## Test Procedure

At the start of the test, the UE is brought to CELL\_FACH state. When the UE detects the expiry of periodic cell updating timer T305 according to the system information, the UE transmits a CELL UPDATE message to the SS on the uplink CCCH. The IE "Cell update cause" in this message shall be set to "periodic cell update". SS ignores this message, and the UE shall then re-transmit a CELL UPDATE message after the expiry of timer T302. When the SS has received (N302+1) such messages, it transmits a CELL UPDATE CONFIRM message with new values for "C-RNTI" to the UE. Finally, the UE shall transmit an RNTI REALLOCATION COMPLETE message on the uplink DCCH.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE starts from CELL_FACH state. SS initializes its internal counter K to 0 and wait until the expiry of T302 timer.
2		→	CELL UPDATE	The value "periodic cell update" shall be set in IE "Cell update cause" after the expiry of timer T305.
3				If K is equal to N302 then proceeds to step 5.
4				SS increments counter K, transmits no response to the UE and waits for an additional period equals to the value of timer T302. The next step is step 2.
5		←	CELL UPDATE CONFIRM	The message includes IEs "new C-RNTI". The IE "DRX Indicator" is set to "No DRX".
6		→	RNTI REALLOCATION COMPLETE	

## Specific Message Contents

## CELL UPDATE (Step 2)

Information Element	Value/remark
U-RNTI	Check to see if set to '0000 0000 0001'
- SRNC Identity	Check to see if set to '0000 0000 0000 0000 0001'
- S-RNTI	Not checked
Integrity check info	Check to see if set to 'FALSE'
AM_RLC error indicator (for C-plane)	Check to see if set to 'FALSE'
AM_RLC error indicator (for U-plane)	Check to see if it is present
Hyper frame number	Check to see if set to 'Periodic cell updating'
Cell Update Cause	Check to see if it is absent or set to 'FALSE'
Protocol error indicator	Check to see if it is absent
Measured results on RACH	Check to see if it is absent
Protocol error information	Check to see if it is absent

## CELL UPDATE CONFIRM (Step 5)

Use the same message sub-type found in Clause 8.1 of TS34.108, with the following exception:

Information Element	Value/remark
New C-RNTI	Set to an arbitrary string different from '0000 0000 0000 0001'

## 8.3.1.11.5 Test requirement

After step 1 the UE shall detect the expiry of timer T305 then transmit a CELL UPDATE message on the uplink CCCH, setting "periodic cell update" into IE" Cell update cause".

After step 2 the UE shall re-transmits a CELL UPDATE message after the expiry of timer T302. A total of (N302+1) transmissions shall be detected in SS.

After step5 the UE shall transmit an RNTI REALLOCATION COMPLETE message on the uplink DCCH and stays at CELL\_FACH state.

## 8.3.1.12 Cell Update: Failure (After Maximum Re-transmissions)

## 8.3.1.12.1 Definition

## 8.3.1.12.2 Conformance requirement

The UE transmits a CELL UPDATE message to the UTRAN when it needs to update UTRAN with information on the current cell of the UE. If the UE fails to receive a CELL UPDATE CONFIRM message, it re-transmits a CELL UPDATE message repeatedly upon the expiry of timer T302 until the value of V302 counter is greater than N302. If V302 is greater than N302, the UE stop the re-transmission and enters idle state.

## Reference

3GPP TS 25.331 clause 8.3.1

## 8.3.1.12.3 Test purpose

To confirm that the UE repeats the cell update procedure at the expiry of timer T302 and moves to idle state when its internal counter V302 is greater than N302.

## 8.3.1.12.4 Method of test

## Initial Condition

System Simulator: 1 cell

UE: CELL\_FACH

## Test Procedure

The UE is initially in CELL\_FACH state. When the UE detects the expiry of periodic cell updating timer T305, the UE transmits a CELL UPDATE message to the SS on the uplink CCCH to perform a periodic cell updating procedure. The SS ignores this message, and the UE shall attempt to re-transmit a CELL UPDATE message up to a maximum of (N302+1) times after the expiry of timer T302. After (N302+1) attempts, the UE shall return to idle state.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is in the CELL_FACH state. SS sets its internal counter K=1 and waits for a period equals to timer value T302. If CELL UPDATE message is received upon timer expiry, proceeds to step 2. Else goes to step 5.
2		→	CELL UPDATE	The value "periodic cell update" should be set in IE" Cell update cause" and this message should be sent for each expiry of timer T302.
3				SS transmits no response to the UE and increments counter K.
4				SS waits for an additional period equals to T302 timer. If CELL UPDATE message is received, proceed to step 2. Otherwise, terminates the test. If K is not equal to N302, the test should be considered as a failure.

## Specific Message Contents

## CELL UPDATE (Step 2)

Information Element	Value/remark
U-RNTI	Check to see if set to '0000 0000 0001'
- SRNC Identity	Check to see if set to '0000 0000 0000 0000 0001'
- S-RNTI	Not checked
Integrity check info	Check to see if set to 'FALSE'
AM_RLC error indicator (for C-plane)	Check to see if set to 'FALSE'
AM_RLC error indicator (for U-plane)	Check to see if it is present
Hyper frame number	Check to see if set to 'Periodic cell updating'
Cell Update Cause	Check to see if it is absent or set to 'FALSE'
Protocol error indicator	Check to see if it is absent
Measured results on RACH	Check to see if it is absent
Protocol error information	Check to see if it is absent

## 8.3.1.12.5 Test requirement

After step 1 the UE shall transmit a CELL UPDATE message on the uplink CCCH and set value "periodic cell update" into IE" Cell update cause".

After step 4 the counter K in SS shall be equal to N302.

### 8.3.1.13 Cell Update: Reception of Invalid CELL UPDATE CONFIRM Message

#### 8.3.1.13.1 Definition

#### 8.3.1.13.2 Conformance Requirement

If the UE encounters an invalid CELL UPDATE CONFIRM message while executing a cell update procedure, it shall check the current value of its internal counter V302. If V302 is not greater than N302, the UE shall set contexts pertaining to protocol error, re-transmits CELL UPDATE message on uplink CCCH, restart T302 timer and increments V302. It shall use the same "Cell Update Cause" as before receiving the invalid downlink message. On the other hand, if V302 is greater than N302, the UE shall abandon cell update procedure and enters idle mode.

#### 8.3.1.13.3 Test Purpose

To confirm that the UE retransmits CELL UPDATE message when it receives an erroneous CELL UPDATE message, if the number of retransmissions is not the maximum allowed value. To confirm that the UE returns to idle mode after sending maximum allowed number of CELL UPDATE messages without receiving a valid CELL UPDATE CONFIRM message.

#### 8.3.1.13.4 Method of Test

##### Initial Condition

System Simulator: 1 cell

UE: CELL\_PCH

##### Test Procedure

The UE is brought to CELL\_PCH state at the beginning of the test. SS pages the UE by sending PAGING TYPE 1 message using the U-RNTI identity assigned during RRC connection establishment procedure. The UE shall start to transmit CELL UPDATE message on the uplink CCCH. Upon receiving such a message, the SS replies with a CELL UPDATE CONFIRM message containing a protocol error in IE "DRX Indicator". The UE shall detect the protocol error and re-transmit CELL UPDATE message up to a maximum of N302 times. The time interval between the transmissions shall be approximately equal to T302. SS verifies that it receives a total of (N302+1) identical CELL UPDATE messages. The UE shall return to idle mode after all uplink transmissions have finished. SS verifies this by paging the UE using the U-RNTI identity. The UE shall not respond to this page.

## Expected Sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	PAGING TYPE 1	The UE is in the CELL_PCH state. SS sets its internal counter K=0 and waits for a period equals to timer value T302. SS pages for the UE using the allocated connected mode identity (U-RNTI). If CELL UPDATE message is received upon timer expiry, proceeds to step 2. Else goes to step 5.
2		→	CELL UPDATE	The value "paging response" should be set in IE" Cell update cause".
3		←	CELL UPDATE CONFIRM	SS transmits an invalid message. SS increments K.
4		→	CELL UPDATE	SS waits for T302 timer to expire. The UE shall send CELL UPDATE message.
5				If a CELL UPDATE message is received in step 4, SS increments K, restart T302 timer and returns to execute step 4. Else, SS proceeds to step 6.
6				SS verifies that K = (N302+1) and proceeds to the next step. Else, the test fails.
7		←	PAGING TYPE 1	SS pages the UE.
8				UE shall not respond.

## Specific Message Content

## CELL UPDATE (Step 2)

Information Element	Value/remark
U-RNTI	
- SRNC Identity	Check to see if set to '0000 0000 0001'
- S-RNTI	Check to see if set to '0000 0000 0000 0000 0001'
Integrity check info	Not checked
AM_RLC error indicator (for C-plane)	Check to see if set to 'FALSE'
AM_RLC error indicator (for U-plane)	Check to see if set to 'FALSE'
Hyper frame number	Check to see if it is present
Cell Update Cause	Check to see if set to 'Paging Response'
Protocol error indicator	Check to see if it is absent or set to 'FALSE'
Measured results on RACH	Check to see if it is absent
Protocol error information	Check to see if it is absent

## CELL UPDATE CONFIRM (Step 3)

Use the same message sub-type found in Clause 8.1 of TS34.108, with the following exception:

Information Element	Value/remark
DRX Indicator	Use one of the spare values.

## CELL UPDATE (Step 4)

Information Element	Value/remark
U-RNTI	Check to see if set to '0000 0000 0001'
- SRNC Identity	Check to see if set to '0000 0000 0000 0000 0001'
- S-RNTI	Not checked
Integrity check info	Check to see if set to 'FALSE'
AM_RLC error indicator (for C-plane)	Check to see if set to 'FALSE'
AM_RLC error indicator (for U-plane)	Check to see if it is present
Hyper frame number	Check to see if set to 'Paging Response'
Cell Update Cause	Check to see if it is set to 'TRUE'
Protocol error indicator	Check to see if it is absent
Measured results on RACH	Check to see if it is set to 'Information element value not comprehended'
Protocol error information	

## PAGING TYPE 1 (Step 1 and 7)

Information Element	Value/remark
Page record list	
- Paging record	
- CHOICE Paging originator	UTRAN Originator
- U-RNTI	
- SRNC Identity	'0000 0000 0001'
- S-RNTI	'0000 0000 0000 0000 0001'
BCCH Modification info	Not Present.

## 8.3.1.13.5 Test Requirement

After step 3 the UE shall continue to transmit CELL UPDATE message for N302 times.

At step 6 the counter K should be equal to (N302+1).

After step 7 the UE shall return to idle mode and not respond the PAGING TYPE 1 message sent by the SS.

## 8.3.1.14 Cell Update: Radio Bearer Control for Transition from CELL\_DCH to CELL\_FACH

## 8.3.1.14.1 Definition

## 8.3.1.14.2 Conformance Requirement

During a transition from CELL\_DCH state to CELL\_FACH state arising from the execution of radio bearer control procedure, the UE might be requested to re-select to an unknown cell. The UE shall select a cell and perform cell updating procedure. In order to distinguish the 2 cases of cell updating: (i) due to UE mobility and (ii) due to radio bearer control procedure, the update cause in CELL UPDATE message shall be different for these 2 cases. When the UTRAN receives this message, it is then able to decide whether to initiate RNC reallocation and the establishment of new configuration in the target RNC.

## 8.3.1.14.3 Test Purpose

To confirm that the UE perform a cell update procedure after being instructed to move from CELL\_DCH to CELL\_FACH state as a result of radio bearer control procedure. To confirm that the UE indicates cause "RB Control" when transmitting a CELL UPDATE message to the selected cell. To confirm that the UE transmit a compatible response to conclude the radio bearer control procedure.



## 8.3.1.14.4 Method of Test

## Initial Condition

System Simulator: 2 cells – both cell 1 and cell 2 are active and suitable for camping, but with cell 1 having a stronger transmission power.

UE: CELL\_DCH in cell 1

## Test Procedure

The UE is brought to CELL\_DCH state in cell 1, after the UE has successfully performed the RRC connection establishment procedure and was allocated dedicated physical resources. Next SS sends RADIO BEARER SETUP message to the UE on downlink DCCH. In this message, a DTCH channel is assigned to the UE. The UE shall reconfigure its channel resources and then return a RADIO BEARER SETUP COMPLETE message. Following this sequence, the UE sends RADIO BEARER RELEASE message to request that all radio bearers carried on dedicated physical channel to be released. However, this message does not contain information about the target cell to select when UE transits to CELL\_FACH state. The UE shall perform cell reselection and it shall detect the presence of cell 2. The UE shall send a CELL UPDATE message with cause set to “RB Control” on the uplink CCCH carried by PRACH physical channel, specified in cell 2’s system information message. SS replies with CELL UPDATE CONFIRM message, specifying the IE “PRACH Info” and “Secondary CCPCH Info”. To complete this procedure, the UE shall transmit RADIO BEARER RELEASE COMPLETE message on the DCCH, which is carried on the PRACH physical channel specified in system information messages broadcasted in cell 2.

## Expected Test Sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is in the CELL_DCH state after completing a successful RRC connection establishment procedure.
2		←	RADIO BEARER SETUP	Establishes DTCH logical channel.
3		→	RADIO BEARER SETUP COMPLETE	
4		←	RADIO BEARER RELEASE	Information on target cell is not specified.
5		→	CELL UPDATE	UE shall send this message on the uplink CCCH of cell 2. IE “Cell update cause” shall be set to “RB Control”.
6		←	CELL UPDATE CONFIRM	IEs “PRACH Info” and IE “Secondary CCPCH Info” are included in this message. IE “DRX Indicator” set to “No DRX”.
7		→	RADIO BEARER RELEASE COMPLETE	Sent on the PRACH given in system information messages.

## Specific Message Contents

## RADIO BEARER SETUP (Step 2)

Use the same message sub-type entitled “Packet to CELL\_DCH from CELL\_DCH in PS” found in Clause 9 of TS34.108, with the following exceptions:

Information Element	Value/remark
RAB information to setup list	
- RAB information for setup	
- RAB Info	4
- RAB Identity	PS
- CN Domain Identity	
- Re-establishment timer	
- T315	1800 seconds
- RB Info to setup list	
- RB Info to setup	
- RB Identity	5
- PDCP Info	Not Present.
- RLC Info	Use the same RLC configuration as in TS 34.108.
- RB Mapping Info	Use the same RLC multiplexing scheme as in TS 34.108.
RB to be affected list	Not Present.
UL Transport Channel information common to all transport channels	
- TFC Subset	Not Present – use default value, all TFCs are allowed.
- CHOICE Mode	FDD
- UL DCH TFCS	
- CHOICE TFCI Signalling	Normal
- TFCI Field 1 Information	
- CHOICE TFCS representation	Addition
- TFCS addition information	
- CHOICE CTFC Size	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10 of TS 34.108.
	Refer to TS 34.108 – This IE is repeated for the maximum number TFC to be added as specified in TS 34.108 for a selected transport channel
- CTFC Information	
- Power offset information	
- CHOICE Gain Factor	Signalled Gain Factors
- Gain factor $\beta_c$	0
- Gain factor $\beta_d$	0
- Reference TFC ID	Not Present
- Power offset Pp-m	0
Deleted TrCH information list (uplink)	Not Present
- Deleted UL TrCH information	
Added or Reconfigured TrCH information list	
- Added or Reconfigured UL TrCH information	
- Transport channel identity	2
- TFS	
- CHOICE Transport channel type	Dedicated transport channels
- Dynamic Transport Format Information	
- Number of Transport blocks	1
- RLC Size	128 bits
- Semi-static Transport Format	Use the same settings as in TS 34.108
- Transmission time interval	
- Type of channel coding	
- Coding Rate	
- Rate matching attribute	
- CRC size	
DL Transport Channel information common to all transport channels	Not Present
Deleted TrCH information list (downlink)	Not Present
Added or Reconfigured TrCH information list	Not Present
Frequency info	Not Present – use the existing frequency information
Maximum allow UL TX power	Not Present – use the allowable UL TX power as specified by the UE's RF power class.
CHOICE Channel requirement	Not Present.
Downlink information common for all radio links	Not Present.
Downlink information per radio link list	Not Present.

## RADIO BEARER SETUP COMPLETE (Step 3)

Only the message type is checked for this message.

#### RADIO BEARER RELEASE (Step 4)

Use the same message sub-type entitled “Packet to CELL\_FACH from CELL\_DCH in PS” found in Annex A, with the following exceptions:

Information Element	Value/remark
RAB information to release list	
- RB Identity	5
RB information to be affected list	
- RB information to be affected	CCCH for RRC (TM)
- RB identity	0
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- RLC logical channel mapping indicator	Not Present
- Uplink transport channel type	RACH
- UL Transport channel identity	Not Present
- Logical channel identity	5
- MAC logical channel priority	2
- Logical channel max loss	Not Present
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- DL Transport channel identity	Not Present
- Logical channel identity	6
- RB information to be affected	DCCH for RRC (UM)
- RB identity	1
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	1
- MAC logical channel priority	2
- Logical channel max loss	Not Present – Use default
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	1
- RB information to be affected	DCCH for RRC (AM)
- RB identity	2
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	2
- MAC logical channel priority	3
- Logical channel max loss	Not Present – Use default
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	2
- RB information to be affected	DCCH for NAS_DT-AM High Priority
- RB identity	3
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	3
- MAC logical channel priority	4
- Logical channel max loss	Not Present – Use default
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	3
- RB information to be affected	DCCH for NAS_DT-AM Low Priority
- RB identity	4
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Transport channel identity	1
- Logical channel identity	4
- MAC logical channel priority	5
- Logical channel max loss	Not Present – Use default
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Transport channel identity	1

<ul style="list-style-type: none"> <li>- Logical channel identity</li> <li>- RB information to be affected</li> <li>- RB identity</li> <li>- RB mapping info</li> <li>- Information for each multiplexing option</li> <li>- Number of RLC logical channels</li> <li>- Downlink transport channel type</li> <li>- DL Transport channel identity</li> <li>- Logical channel identity</li> <li>- RB information to be affected</li> <li>- RB identity</li> <li>- RB mapping info</li> <li>- Information for each multiplexing option</li> <li>- Number of RLC logical channels</li> <li>- Downlink transport channel type</li> <li>- DL Transport channel identity</li> <li>- Logical channel identity</li> </ul>	4 BCCH for RRC (TM) 5  1 FACH Not Present 5 PCCH for RRC (TM) 6  1 FACH Not Present 1
UL Transport Channel information common to all transport channels <ul style="list-style-type: none"> <li>- TFC Subset</li> <li>- CHOICE Mode</li> <li>- UL DCH TFCS</li> </ul>	Not Present – use default value, all TFCs are allowed. FDD Use the same TFCS as in IE “RACH TFCS” found in system information block type 5 messages of cell 2. Not Present.
Deleted TrCH information list (uplink) Added or Reconfigured TrCH information list <ul style="list-style-type: none"> <li>- Added or Reconfigured UL TrCH information</li> <li>- Transport channel identity</li> <li>- TFS</li> </ul>	1 Use the same TFS as in IE “RACH TFS” found in system information block type 5 messages of cell 2.
DL Transport Channel information common to all transport channels <ul style="list-style-type: none"> <li>- SCCPCH TFCS</li> <li>- DL DCH TFCS</li> </ul>	Use the same TFCS as in IE “TFCS” (for FACH) in IE “Secondary CCPCH system information” found in system information block type 5 messages of cell 2. Not Present.
Deleted TrCH information list (downlink)	Not Present
Added or Reconfigured TrCH information list	Not Present.
Frequency info	Not Present – use the existing frequency information
Maximum allow UL TX power	Not Present – use the allowable UL TX power as specified by the UE's RF power class.
CHOICE Channel requirement	Not Present.
Downlink information common for all radio links	Not Present.
Downlink information per radio link list	Not Present.

## CELL UPDATE (Step 5)

Information Element	Value/remark
U-RNTI	Check to see if set to '0000 0000 0001'
- SRNC Identity	Check to see if set to '0000 0000 0000 0000 0001'
- S-RNTI	Not checked
Integrity check info	Check to see if set to 'FALSE'
AM_RLC error indicator (for C-plane)	Check to see if set to 'FALSE'
AM_RLC error indicator (for U-plane)	Check to see if it is present
Hyper frame number	Check to see if set to 'RB Control'
Cell Update Cause	Check to see if it is absent or set to 'FALSE'
Protocol error indicator	Check to see if it is absent
Measured results on RACH	Check to see if it is absent
Protocol error information	Check to see if it is absent

## CELL UPDATE CONFIRM (Step 6)

Use the same message sub-type found in Annex A.

## RADIO BEARER RELEASE COMPLETE (Step 7)

Only the message type is checked in this message.

#### 8.3.1.14.5 Test Requirement

After step 4 the UE shall reselect to cell 2, perform a cell update procedure by transmitting CELL UPDATE message. In this message, the IE "Cell Update Cause" shall be set to "RB Control".

After step 6 the UE shall send RADIO BEARER RELEASE COMPLETE message on the DCCH carried by the PRACH channel. The applicable parameters of the PRACH resources are broadcasted on the system information messages of cell 2.

#### 8.3.1.15 Cell Update: Acknowledged Mode RLC Reset

##### 8.3.1.15.1 Definition

##### 8.3.1.15.2 Conformance Requirement

In CELL\_FACH, the UE shall ensure that all AM RLC entities (both signalling and u-plane links) are operational. In the event that an unrecoverable error has occurred, the UE shall trigger cell update procedure to report this event. The UE shall send CELL UPDATE message on the uplink CCCH and set the appropriate AM\_RLC error indicator IE(s) to TRUE. After receiving the CELL UPDATE CONFIRM message, the UE shall reset the affected AM RLC entities and then resume transmission and reception activities.

##### 8.3.1.15.3 Test Purpose

To confirm that the UE reports the occurrence of an unrecoverable error in a C-plane AM RLC entity by initiating cell update procedure. To confirm that the UE is able to resume normal C-plane data transmission and reception after the completion of cell update procedure.

##### 8.3.1.15.4 Method of Test

###### Initial Condition

System Simulator: 1 cell

UE: Idle Mode

###### Test Procedure

The UE is initially in idle mode and camped onto cell 1. SS pages the UE using the IMSI identity stored in the test USIM card, stating the cause as a terminating call with one of the traffic classes supported by the UE. The UE shall respond by transmitting the RRC CONNECTION REQUEST message on the uplink CCCH, triggering the start of RRC connection establishment procedure. SS assigns common physical resources to the UE by sending RRC CONNECTION SETUP message. The UE shall reply with RRC CONNECTION SETUP COMPLETE on the DCCH before transiting to CELL\_FACH state. Next, SS sends RADIO BEARER SETUP message on the DCCH using AM mode to establish a DTCH logical channel for u-plane packet data transfer. The UE shall reply with a RADIO BEARER SETUP COMPLETE message, sent using AM RLC on the DCCH. Then it activates the associated DTCH logical channel for user data transmission and reception. SS does not acknowledge the RADIO BEARER SETUP COMPLETE message. The UE shall continue to transmit the AM PDU carrying RADIO BEARER COMPLETE message until the maximum re-transmission count is reached. Thereafter, the UE shall start sending RESET PDUs to request that the AM RLC entity for RRC signalling be re-initialized. SS ignores the requests and wait for a duration equivalent to (MAX\_RST+1) times expiry of Timer\_RST. This figure is specified in IE "RLC info" of RADIO BEARER SETUP message in step 6. At this point, the UE shall initiate a cell update procedure by transmitting CELL UPDATE message on the uplink CCCH. The CELL UPDATE message shall specify the value "TRUE" in IE "AM\_RLC error indicator (for C-plane)". SS replies with CELL UPDATE CONFIRM message using the default message content. SS then attempts to perform a local authentication by transmitting a COUNTER CHECK message using AM RLC on DCCH. The UE shall respond by sending a COUNTER CHECK RESPONSE message on the uplink DCCH, verifying that the AM RLC entity for RRC signalling was successfully reset.

## Expected Test Sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is initially in idle mode.
2		←	PAGING TYPE 1	SS pages the UE, citing the cause as a terminating call with one of the supported traffic classes in the PAGING TYPE 1 message.
3		→	RRC CONNECTION REQUEST	Sent on CCCH using transparent mode.
4		←	RRC CONNECTION SETUP	Allocate common physical resources for signalling RBs.
5		→	RRC CONNECTION SETUP COMPLETE	Sent on CCCH using transparent mode.
6		←	RADIO BEARER SETUP	Establishes a DTCH logical channel operating in AM mode.
7		→	RADIO BEARER SETUP COMPLETE	UE shall stay in CELL_FACH state. SS does not acknowledge this AM PDU. The UE shall re-transmit this AM PDU until the maximum number has been reached.
8				UE shall start to transmit RESET PDU using AM RLC on the DCCH. SS does not respond to any PDU frames originating from the UE, and it waits for a period equivalent to (MAX_RST+1) times expiry of Timer_RST. This figure is specified in IE"RLC info" of RADIO BEARER SETUP message in step 6.
9		→	CELL UPDATE	UE shall send this message on CCCH. IE"AM_RLC Error Indication (for C-plane)" shall be set to 'TRUE'
10		←	CELL UPDATE CONFIRM	"DRX Indicator" set to "No DRX". UE shall transit to CELL_FACH state.
11		←	COUNTER CHECK	SS requests for a local authentication of the amount of data sent/received during the lifetime of the RRC connection.
12		→	COUNTER CHECK RESPONSE	This message shall be transmitted using AM RLC for RRC signalling on the uplink DCCH.

## Specific Message Contents

## PAGING TYPE 1 (Step 2)

Use the same message sub-type entitled "TM (Packet in PS)" found in Clause 9 of TS34.108.

## RRC CONNECTION REQUEST (Step 3)

Information Element	Value/remark
Initial UE Identity	Check to see if set to same value as the IMSI identity stored in the test USIM card.
Initial UE Capability - Maximum number of AM entities	Check to see if set to '4 to 8' or '16 to 32'.
Establishment Cause	Check to see if set to Terminating Call of a supported traffic class.
Protocol Error Indicator	Check to see if set to 'FALSE'.
Measured Results on RACH	Not checked.

## RRC CONNECTION SETUP (Step 4)

Use the same message sub-type entitled "Transition to CELL\_FACH" found in Clause 9 of TS34.108.

## RRC CONNECTION SETUP COMPLETE (Step 5)

Only the message type IE is checked in this message.

## RADIO BEARER SETUP (Step 6)

Use the same message sub-type entitled "Packet to CELL\_FACH from CELL\_FACH in PS" found in Clause 9 of TS34.108.

## RADIO BEARER SETUP COMPLETE (Step 7)

Only the message type IE is checked for this message.

## CELL UPDATE (Step 9)

Information Element	Value/remark
U-RNTI	Check to see if set to '0000 0000 0001'
- SRNC Identity	Check to see if set to '0000 0000 0000 0000 0001'
- S-RNTI	Not checked
Integrity check info	Check to see if set to 'FALSE'
AM_RLC error indicator (for C-plane)	Check to see if set to 'TRUE'
AM_RLC error indicator (for U-plane)	Check to see if it is present
Hyper frame number	Not checked
Cell Update Cause	Check to see if it is absent or set to 'FALSE'
Protocol error indicator	Check to see if it is absent
Measured results on RACH	Check to see if it is absent
Protocol error information	Check to see if it is absent

## CELL UPDATE CONFIRM (Step 10)

Use the same message sub-type found in Clause 9 of TS34.108.



## COUNTER CHECK (Step 11)

Information Element	Values/Remarks
Integrity check info	Not present
RB COUNT-C MSB Information	
- RB Identity	5
- COUNT-C-MSB-uplink	Set to an arbitrary integer equals to the 25 MSBs from COUNT-C for RB#5
- COUNT-C-MSB-downlink	Set to an arbitrary integer equals to the 25 MSBs from COUNT-C for RB#5

## COUNTER CHECK RESPONSE (Step 12)

Information Element	Values/Remarks
Integrity check info	Not checked
RB COUNT-C Information	Not checked
- RB Identity	
- COUNT-C-uplink	
- COUNT-C-downlink	

## 8.3.1.15.5 Test Requirement

After step 8 the UE shall transmit a CELL UPDATE message on the uplink CCCH to report the occurrence of an unrecoverable error in AM RLC entity for C-plane data.

After step 11 the UE shall send a COUNTER CHECK RESPONSE message on the uplink DCCH. This message shall be sent using the AM RLC entity for RRC signalling.

## 8.3.2 URA Update

## 8.3.2.1 URA Update: URA reselecion

## 8.3.2.1.1 Definition

## 8.3.2.1.2 Conformance requirement

This procedure is to update UTRAN with the current URA of the UE after a URA reselecion has occurred in URA\_PCH state. It may also be used for supervision of the RRC connection, even if no URA reselecion takes place.

## Reference

3GPP TS 25.331 clause 8.3.2

## 8.3.2.1.3 Test purpose

To confirm that the UE executes a URA update procedure after the successful URA reselecion.

## 8.3.2.1.4 Method of test

## Initial Condition

System Simulator: 2 cells - Cell 1 is active with URA-ID 1, Cell 2 is inactive with URA-ID 2

UE: URA\_PCH with URA-ID 1 in the list of URA-ID from cell 1

## Test Procedure

The UE is in the URA\_PCH state and assigned with only 1 URA identity in cell 1: URA-ID 1. The SS starts to broadcast BCCH in cell 2 with URA-ID 2 and stop transmitting BCCH in cell 1. This is expected to cause the UE to

perform a cell reselection to cell 2. When the UE finds that URA-ID 2 is not in its current list of URA-IDs, it moves to CELL\_FACH state and transmits a URA UPDATE message on the uplink CCCH. After the SS receives this message, it transmits URA UPDATE CONFIRM message which includes the IEs "DRX Indicator" and "URA-ID" to the UE on the downlink DCCH. The "DRX Indicator" is set to "DRX with URA updating". Finally, the UE returns to URA\_PCH state in cell 2 without sending a uplink response message.

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is updated with only 1 URA identity carried currently by cell 1. The starting state of the UE is URA_PCH
2		←	BCCH	SS starts sending BCCH for cell 2 with URA-ID 2 and ceases to transmit BCCH with URA-ID 1 carried by cell 1.
3		→	URA UPDATE	The UE shall perform a cell reselection first and then it finds that a new URA-ID 2 is not in the list of its URA-IDs stored. It shall then transmit this message and set value "URA reselection" into IE "URA update cause".
4		←	URA UPDATE CONFIRM	Message comprises IE "DRX Indicator" set "DRX with URA updating", and also IE "URA Identity" equals to "URA-ID 2".

#### Specific Message Contents

##### URA UPDATE (Step 3)

Information Element	Value/remark
U-RNTI	
- SRNC Identity	Check to see if set to '0000 0000 0001'
- S-RNTI	Check to see if set to '0000 0000 0000 0000 0001'
Integrity check info	Not checked
AM_RLC error indicator	Check to see if set to 'FALSE'
URA Update Cause	Check to see if set to 'Change of URA'
Protocol error indicator	Check to see if it is absent or set to 'FALSE'
Protocol error information	Check to see if it is absent

##### URA UPDATE CONFIRM (Step 4)

Use the same message sub-type found in Clause 8.1 of TS34.108, with the following exceptions:

Information Element	Value/remark
DRX Indicator	DRX with URA updating

#### 8.3.2.1.5 Test requirement

After step 2 the UE shall find that URA-ID 2 is not in its maintained list of URA-IDs. After cell reselection, the UE shall move to CELL\_FACH state and transmit URA UPDATE message setting value "Change of URA" into IE "URA update cause".

### 8.3.2.2 URA Update: periodical URA update

#### 8.3.2.2.1 Definition

#### 8.3.2.2.2 Conformance requirement

This procedure is to update UTRAN with the current URA of the UE when the UE detects that it is still within the service area after the expiry of periodic URA updating timer T306.

#### Reference

3GPP TS 25.331 clause 8.3.2

#### 8.3.2.2.3 Test purpose

To confirm that the UE executes a URA update procedure after the expiry of timer T306. To verify that the UE handles an invalid URA UPDATE CONFIRM message correctly when executing the URA update procedure.

#### 8.3.2.2.4 Method of test

#### Initial Condition

System Simulator: 1 cell

UE: URA\_PCH with URA-ID 1

#### Test Procedure

The UE is in the URA\_PCH state with URA-ID 1. When the UE detects the expiry of timer T306, set according to the value specified in system information, the UE moves to CELL\_FACH state and transmits a URA UPDATE message to the SS on the uplink CCCH. The message shall indicate the cause to be "periodic URA update" in IE "URA update cause". SS replies with an illegal URA UPDATE CONFIRM message sent on downlink CCCH, and check to see if the UE handles this event properly. The UE shall attempt to retransmit the identical URA UPDATE message. After the SS receives the second URA UPDATE message, it transmits a correct URA UPDATE CONFIRM message, which includes the IE "new U-RNTI", to the UE on the downlink DCCH. Then the UE shall then transmits an RNTI REALLOCATION COMPLETE message on the uplink DCCH. The UE returns to CELL\_FACH state.

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is in the URA_PCH state. SS wait until T306 timer has expired.
2		→	URA UPDATE	UE shall transmit this message and set value "periodic URA update" into IE "URA update cause".
3		←	URA UPDATE CONFIRM	SS sends an illegal message.
4		→	URA UPDATE	UE shall not return to idle mode immediately, but attempts to re-transmit this message.
5		←	URA UPDATE CONFIRM	Including IEs "new C-RNTI", and "new U-RNTI"
6		→	RNTI REALLOCATION COMPLETE	

## Specific Message Contents

## URA UPDATE (Step 2 and 4)

Information Element	Value/remark
U-RNTI	Check to see if set to '0000 0000 0001'
- SRNC Identity	Check to see if set to '0000 0000 0000 0000 0001'
- S-RNTI	Not checked
Integrity check info	Check to see if set to 'FALSE'
AM_RLC error indicator	Check to see if set to 'Periodic URA update'
URA Update Cause	Check to see if it is absent or set to 'FALSE'
Protocol error indicator	Check to see if it is absent
Protocol error information	

## URA UPDATE CONFIRM ( Step 3)

Use the same message sub-type found in Clause 8.1 of TS34.108, with the following exceptions:

Information Element	Value/remark
U-RNTI	Not Present

## URA UPDATE CONFIRM ( Step 5)

Use the same message sub-type found in Clause 8.1 of TS34.108, with the following exceptions:

Information Element	Value/remark
New U-RNTI	
SRNC Identity	'0000 0000 0001'
S-RNTI	'0000 0000 0000 0000 1111'

## RNTI REALLOCATION COMPLETE (Step 6)

Only the message type IE of this message is checked.

## 8.3.2.2.5 Test requirement

After step 2 the UE shall detect the expiry of timer T306, move to CELL\_FACH state, and transmit a URA UPDATE message which is set the value "periodic cell update" into IE" URA update cause".

After step 3 the UE shall re-transmit URA UPDATE message.

After step 5 the UE shall transmit an RNTI REALLOCATION COMPLETE message on the uplink DCCH and returns to the CELL\_FACH state.

## 8.3.2.3 URA Update: re-entering of service area after T306 expiry

## 8.3.2.3.1 Definition

## 8.3.2.3.2 Conformance requirement

This procedure is to update UTRAN with the current URA of the UE if the UE detects that it is out of service area after the expiry of timer T306, and then subsequently re-enters the service area before the expiry of T307.

## Reference

3GPP TS 25.331 clause 8.3.2

### 8.3.2.3.3 Test purpose

To confirm that the UE executes a URA update procedure when the UE re-enters the service area before the expiry of timer T307, after being out of service area at the expiry of timer T306.

### 8.3.2.3.4 Method of test

#### Initial Condition

System Simulator: 1 cell

UE: URA\_PCH updated with URA-ID 1

#### Test Procedure

The UE is initially in URA\_PCH state, updated with URA-ID 1. SS decrease the transmission power of cell such that cell selection figure of merit  $S < 0$ . When the UE detects the expiry of timer T306 according to the system information, the UE moves to CELL\_FACH state and finds that it is out of service area. The UE is expected to search for cell to camp. Then SS increases the transmission power so that the UE detects that it returns to normal service within T307. The UE shall move to CELL\_FACH state and starts transmitting a URA UPDATE message which contains the value "periodic URA update" in IE "URA update cause" to the SS on the uplink CCCH. After the SS receives this message, it transmits a URA UPDATE CONFIRM message which includes the IE "new C-RNTI", and "new U-RNTI" to the UE on the downlink DCCH. Then the UE shall transmit an RNTI REALLOCATION COMPLETE message on the uplink DCCH.

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE starts operating from URA_PCH state.
2				SS decreases the transmission power such that the cell is no longer suitable for camping i.e. $S < 0$ .
3				The UE shall attempt to perform a URA update upon the expiry of timer T306. It shall discover that it is out of service and starts searching for cell to camp. (T307 timer starts)
4				SS increases the transmission power to the original level before T307 expires.
5		→	URA UPDATE	Value "periodic URA update" shall be set in IE "URA update cause"
6		←	URA UPDATE CONFIRM	The message includes IEs "new C-RNTI", and "new U-RNTI"
7		→	RNTI REALLOCATION COMPLETE	

#### Specific Message Contents

Use the same message sub-type found in Clause 8.1 of TS34.108, with the following exceptions:

## URA UPDATE CONFIRM ( Step 6)

Information Element	Value/remark
New U-RNTI - SRNC Identity  - S-RNTI New C-RNTI	'0000 0000 0001' '0000 0000 1111 1111'  Arbitrary 16-bit string which is different the assigned C-RNTI in RRC CONNECTION SETUP message.

## 8.3.2.3.5 Test requirement

After step 2 the UE shall detect that it is out of service area and shall not send a URA UPDATE on the uplink CCCH channel.

After step 4 the UE shall transmit a URA UPDATE message which sets value "periodic URA update" into IE" URA update cause", before the expiry of timer T307.

After step 6 the UE shall transmit an RNTI REALLOCATION COMPLETE message on the uplink DCCH.

## 8.3.2.4 URA Update: loss of service after expiry of timers T307 and T306

## 8.3.2.4.1 Definition

## 8.3.2.4.2 Conformance requirement

This procedure is required to handle the case when the UE fails to update UTRAN with the current URA of after expiry of timers T307 and T306 consecutively. The UE shall move to idle mode subsequently.

## Reference

3GPP TS 25.331 clause 8.3.2

## 8.3.2.4.3 Test purpose

To confirm that the UE moves to idle mode after the expiry of timer T307, following an expiry of timer T306 when it discovers that it is out of service area.

## 8.3.2.4.4 Method of test

## Initial Condition

System Simulator : 1cell

UE : URA\_PCH updated with URA-ID 1

## Test Procedure

The UE is in URA\_PCH state with URA-ID 1. SS stops the downlink transmissions of cell 1. When the UE detects the expiry of periodic URA updating timer T306 according to the system information, the UE moves to CELL\_FACH state and detects that it is out of service area. After the expiry of timer T307, the UE moves to the idle state and start to perform cell reselection.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				Initially, the UE is in the URA_PCH state.
2				SS switched off the downlink transmission of cell 1 so that the UE detects that it is out of service area.
3				Upon the expiry of timer T306, the UE shall search for cell to camp and triggers T307 timer. SS listens to the uplink CCCH to verify that CELL UPDATE message is not transmitted.
4				After the expiry of timer T307, the UE enters idle state.

Specific Message Contents

None

#### 8.3.2.4.5 Test requirement

After step 2 the UE shall detect the expiry of timer T306, not transmit URA UPDATE message on the uplink CCCH, move to CELL\_FACH state, and start timer T307.

#### 8.3.2.5 URA Update: Success after Confirmation error of URA-ID list

##### 8.3.2.5.1 Definition

##### 8.3.2.5.2 Conformance requirement

While in connected mode, the UE keeps a temporary list of URA-IDs broadcasted in a cell. The UE transmits a URA UPDATE message to the UTRAN when it needs to update UTRAN with the current URA of the UE. UTRAN should respond to the URA UPDATE message by sending a URA UPDATE CONFIRM message. When the indicated URA-ID in the received URA UPDATE CONFIRM message is not found in the temporary list of URA-IDs, the UE transmits a URA UPDATE message repeatedly until its internal counter V303 is greater than N303.

#### Reference

3GPP TS 25.331 clause 8.3.2

##### 8.3.2.5.3 Test purpose

To confirm that the UE retries to perform the URA update procedure following a confirmation error of URA-ID list.

##### 8.3.2.5.4 Method of test

#### Initial Condition

System Simulator: 1 cell

#### UE: URA\_PCH updated with URA-ID 1 Test Procedure

At the start of this test, the UE is brought to URA\_PCH state and assigned a URA with URA-ID 1. When the UE detects the expiry of timer T306 according to the system information, the UE moves to CELL\_FACH state and transmits a URA UPDATE message to the SS on the uplink CCCH. The reason for performing URA updating shall be

set to "periodic URA update" in IE "URA update cause". After the SS receives this message, it transmits a URA UPDATE CONFIRM message which includes the IE "new C-RNTI", "new U-RNTI" and "URA-ID 2" to the UE on the downlink DCCH. The UE finds that the indicated URA-ID is not included in the temporary list of URA-IDs stored, then the UE shall retry to transmit a URA UPDATE message for a confirmation error of URA-ID list. SS continue to send the same URA UPDATE CONFIRM message until N303 URA UPDATE messages have been received. Then SS transmits a URA UPDATE CONFIRM message to the UE which includes IE "URA Identity" set to "URA-ID 1". The UE shall find this URA-ID in its URA-ID list and transmits an RNTI REALLOCATION COMPLETE message on the uplink DCCH.

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is URA_PCH state. SS initializes counter K to 0
2		→	URA UPDATE	This message shall contain value "periodic URA update" set in IE "URA update cause" after expiry of timer T306.
3				SS increments K by 1.
4		←	URA UPDATE CONFIRM	SS transmits this message, setting the value "URA-ID 2" to IE "URA Identity". If K is not greater than N303, SS waits for T303 to expires and then returns to step 2. If K is greater than N303, SS proceeds to step 5.
5		←	URA UPDATE CONFIRM	SS transmits this message, setting IE "URA Identity" to "URA-ID 1". This message also comprises IE "New U-RNTI".
6		→	RNTI REALLOCATION COMPLETE	

#### Specific Message Contents

##### URA UPDATE (Step 2)

Information Element	Value/remark
U-RNTI	Check to see if set to '0000 0000 0001'
- SRNC Identity	Check to see if set to '0000 0000 0000 0000 0001'
- S-RNTI	Not checked
Integrity check info	Check to see if set to 'FALSE'
AM_RLC error indicator	Check to see if set to 'Periodic URA update'
URA Update Cause	Check to see if it is absent or set to 'FALSE'
Protocol error indicator	Check to see if it is absent
Protocol error information	

##### URA UPDATE CONFIRM (Step 4)

Use the same message sub-type as specified in TS 34.108 Clause 8, with the following exceptions:

Information Element	Value/remark
DRX Indicator	DRX with Cell updating
URA Identity	2

##### URA UPDATE CONFIRM (Step 5)

Use the same message sub-type as specified in TS 34.108 Clause 8, with the following exceptions:



Information Element	Value/remark
New U-RNTI	'0000 0000 0001' '0000 0000 0000 0101 0101'
SRNC Identity	
S-RNTI	
URA Identity	1

#### RNTI REALLOCATION COMPLETE (Step 6)

Only the message type IE in this message is checked.

#### 8.3.2.5.5 Test requirement

After step 1 the UE shall detect the expiry of timer T306, move to CELL\_FACH state, transmit a URA UPDATE message on the uplink CCCH and set value "periodic URA update" into IE" URA update cause".

After step 2 the UE shall repeatedly re-transmit a URA UPDATE message after it detects a confirmation error of URA-ID list for the URA-ID indicated in the URA UPDATE CONFIRM message. A total of (N303+1) URA UPDATE messages shall be received by the SS.

After step 5 the UE shall transmit an RNTI REALLOCATION COMPLETE message on the uplink DCCH.

#### 8.3.2.6 URA Update: Failure ( V303 is greater than N303 : Confirmation error of URA-ID list )

##### 8.3.2.6.1 Definition

##### 8.3.2.6.2 Conformance requirement

While in connected mode, the UE keeps a temporary list of all URA-IDs broadcasted in a cell. It transmits a URA UPDATE message to the UTRAN when it needs to update UTRAN with the current URA of the UE. When the indicated URA-ID in the received URA UPDATE CONFIRM message is not in the list of URA-IDs, the UE transmits URA UPDATE messages repeatedly until its internal counter V303 is greater than N303. If V303 is greater than N303 then the UE enters idle state.

#### Reference

3GPP TS 25.331 clause 8.3.2

##### 8.3.2.6.3 Test purpose

To confirm that the UE make repeated attempts to perform the URA update procedure following a detection of a confirmation error of URA-ID list. It then moves to idle state when internal counter V303 is greater than N303.

##### 8.3.2.6.4 Method of test

#### Initial Condition

System Simulator: 1 cell

UE: URA\_PCH updated with URA-ID 1

#### Test Procedure

The UE is originally in the URA\_PCH state updated with URA-ID 1. When the UE detects the expiry of timer T306 according to the system information, the UE shall move to CELL\_FACH state and transmit a URA UPDATE message to the SS on the uplink CCCH. In this message, the value "periodic URA update" shall be set in IE" URA update

cause". After the SS receives this message, it transmits a URA UPDATE CONFIRM message which includes the IE "new C-RNTI", "new U-RNTI" and indicating the IE "URA Identity" to be "URA-ID 2" to the UE on the downlink DCCH. The UE finds that the indicated URA-ID is not included in the list of URA-IDs broadcasted, the UE shall retry to transmit a URA UPDATE message for N303 times. After that, the UE shall enter idle state.

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is in URA_PCH state at the start of the test. SS sets internal counter K to 1.
2		→	URA UPDATE	The message shall indicate "periodic URA update" in IE "URA update cause". This message is sent following the expiry of timer T306. SS increments counter K by 1.
3		←	URA UPDATE CONFIRM	The SS transmit this message and set IE "URA Identity" to "URA-ID 2". When K greater than N303 proceeds to step 4, else SS waits for T303 to expires and executes step 2.
4				SS waits for a T306 to verify that no further URA UPDATE messages are transmitted by UE. The counter K shall be equal to (N303+1). The UE shall enter idle state.

#### Specific Message Contents

##### URA UPDATE CONFIRM (Step 4)

Use the same message sub-type defined in TS 34.108 Clause 8, with the following exceptions:

Information Element	Value/remark
URA Identity	2

##### 8.3.2.6.5 Test requirement

After step 1 the UE shall detect the expiry of timer T306, then it shall move to CELL\_FACH state and transmit a URA UPDATE message on the uplink CCCH, setting value "periodic URA update" into IE "URA update cause".

After step 2 the UE shall retry to transmit a URA UPDATE message after it detects the confirmation error of URA-ID list for the URA-ID included in the URA UPDATE CONFIRM message.

After step 3 the UE shall stop transmitting URA UPDATE message and then enters idle state. The counter K shall be equal to (N303+1).

##### 8.3.2.7 URA Update: Success after T303 timeout

##### 8.3.2.7.1 Definition

##### 8.3.2.7.2 Conformance requirement

The UE transmits a URA UPDATE message to the UTRAN when it needs to update UTRAN with the current URA identity stored the UE. When the UE fails to receive any URA UPDATE CONFIRM message after T303 timer expiry,

it transmits a URA UPDATE message repeatedly at an interval of T303 timer value until its internal counter V303 is greater than N303.

## Reference

3GPP TS 25.331 clause 8.3.2

### 8.3.2.7.3 Test purpose

To confirm that the UE attempts to repeat the URA update procedure upon the expiry of timer T303. To confirm that a maximum of N303 re-transmission is performed.

### 8.3.2.7.4 Method of test

## Initial Condition

System Simulator : 1 cell

UE : URA\_PCH

## Test Procedure

The UE is in the URA\_PCH. When the UE detects the expiry of timer T306 according to the system information, the UE moves to CELL\_FACH state and transmits a URA UPDATE message to the SS on the uplink CCCH, setting value "periodic URA update" into IE" URA update cause". The SS ignores this message, the UE shall then retry to transmit a URA UPDATE message after the expiry of timer T303. SS continues to ignore further URA UPDATE message until it receives (N303+1) such message. Then it transmits a URA UPDATE CONFIRM message to the UE which includes IEs"new C-RNTI", "new U-RNTI". The UE shall then transmit an RNTI REALLOCATION COMPLETE message on the uplink DCCH.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is in URA_PCH state at the beginning of test. SS sets counter K to 1. SS waits for T306 to expire.
2		→	URA UPDATE	This message shall contain value "periodic URA update" in IE" URA update cause" sent upon the expiry of timer T306.
3				SS increments K by 1.
4				If K is not greater than N303, SS transmits no response to the UE, waits for an additional period equals to T303 timer and returns to step 2. Else, SS executes step 5.
5		←	URA UPDATE CONFIRM	This message includes IEs" new C-RNTI" , "new U-RNTI"
6		→	RNTI REALLOCATION COMPLETE	

## Specific Message Contents

### URA UPDATE CONFIRM (Step 5)

Use the same message sub-type as in TS 34.108 Clause 8, with the following exceptions:

Information Element	Value/remark
New U-RNTI SRNC Identity	'0000 0000 0001' Arbitrary 20-bit string which is different from S-RNTI field in IE"U-RNTI"
S-RNTI	
New C-RNTI	

#### 8.3.2.7.5 Test requirement

After step 1 the UE shall detect the expiry of timer T306, then it shall move to CELL\_FACH state and transmit a URA UPDATE message on the uplink CCCH. The updating cause shall be set to "periodic URA update" in IE" URA update cause".

After step 2 the UE shall retry to transmit a URA UPDATE message at each expiry of timer T303. UE shall attempt to re-transmit N303 URA UPDATE messages.

After step 5 the UE shall transmit an RNTI REALLOCATION COMPLETE message on the uplink DCCH.

### 8.3.2.8 URA Update: Failure ( V303 is greater than N303:T303 timeout )

#### 8.3.2.8.1 Definition

#### 8.3.2.8.2 Conformance requirement

The UE transmits a URA UPDATE message to the UTRAN when it needs to update the UTRAN with the current URA of the UE. When the UE fails to receive the URA UPDATE CONFIRM message , the UE transmits a URA UPDATE message repeatedly after every expiry of T303 until its internal counter V303 is greater than N303. If V303 is greater than N303, UE stops sending URA UPDATE message and then enters idle state.

#### Reference

3GPP TS 25.331 clause 8.3.2

#### 8.3.2.8.3 Test purpose

To confirm that the UE retries to perform the URA update procedure upon expiry of timer T303 and moves to idle state after retrying for N303 times.

#### 8.3.2.8.4 Method of test

#### Initial Condition

System Simulator : 1 cell

UE : URA\_PCH

#### Test Procedure

The UE is in the URA\_PCH state. When the UE detects the expiry of timer T306 according to the system information, the UE moves to CELL\_FACH state and transmits a URA UPDATE message to the SS on the uplink CCCH. This message shall contain value "periodic URA update" in IE" URA update cause". SS ignores this message, the UE shall continue to transmit URA UPDATE messages for N303 times after the expiry of timer T303. After N303 re-transmissions, the UE shall enter idle state.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is in URA_PCH state and SS sets counter K=0. SS wait until T303 expires.
2		→	URA UPDATE	The value "periodic URA update" shall be set in IE" URA update cause".
3				SS ignores the message, waits for T303 timer to expire and increments K by 1. If a message is received after T303 expiry, return to step 2. Else, go to step 4.
4				SS checks that K is equal to (N303+1).
5				The UE shall enter idle state.

Specific Message Contents

None

#### 8.3.2.8.5 Test requirement

After step 1 the UE shall detect the expiry of timer T306, then it shall move to CELL\_FACH state and transmit a URA UPDATE message on the uplink CCCH, setting "periodic URA update" into IE" URA update cause".

After step 2 the UE shall retry to transmit a URA UPDATE message after the expiry of timer T303. SS shall receive (N303+1) CELL UPDATE message. After this, the UE shall enter idle state.

### 8.3.3. RNTI reallocation

#### 8.3.3.1 RNTI reallocation: Success

##### 8.3.3.1.1 Definition

##### 8.3.3.1.2 Conformance requirement

This procedure is used by the network to assign a new RNTI identity to the UE. It is initiated by the UTRAN when it sends an RNTI REALLOCATION message, which includes a new C-RNTI and/or U-RNTI on the downlink DCCH. The UE starts to use the new identities and transmits an RNTI REALLOCATION COMPLETE message to the UTRAN on the uplink DCCH.

##### Reference

3GPP TS 25.331 clause 8.3.3

##### 8.3.3.1.3 Test purpose

To confirm that the UE starts to use the new identities after it receives an RNTI REALLOCATION message from the SS. To confirm that the UE use the new U-RNTI identity to calculate the applicable paging occasions.

*[Editor's note] In this test case, it is assumed that the paging occasion during connected states is determined using U-RNTI. From TS 25.304 Clause 8, this assumption cannot be confirmed. Further clarification is required regarding this issue.*

##### 8.3.3.1.4 Method of test

##### Initial Condition

System Simulator : 1cell

UE : CELL\_FACH

##### Test Procedure

Initially, the UE is in the CELL\_FACH state and it has been assigned a C-RNTI and U-RNTI. The SS transmits an RNTI REALLOCATION message which includes new C-RNTI and U-RNTI to the UE. Then the UE shall transmit an RNTI REALLOCATION COMPLETE message as confirmation and transits to CELL\_PCH state. SS pages the UE by sending a PAGING TYPE 1 message and specifying the newly assigned U-RNTI identity in this message. The UE shall transmit a CELL UPDATE message to the SS on the uplink CCCH which includes the U-RNTI identical to that found in RNTI REALLOCATION message received in step 2. The CELL UPDATE message shall also contain IE "Cell update cause" with this IE set to "paging response". After the SS receives this message, it transmits a CELL UPDATE CONFIRM message which includes IE "DRX Indicator" set to value "No DRX" to the UE on the downlink DCCH. The UE shall return to CELL\_FACH state.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The initial state of the UE is CELL_FACH state. UE has been allocated both C-RNTI and U-RNTI during RRC connection establishment phase.
2		←	RNTI REALLOCATION	Contains new C-RNTI and U-RNTI identities.
3		→	RNTI REALLOCATION COMPLETE	
4		←	PAGING TYPE 1	SS pages the UE using the new U-RNTI allocated in step 2.
5		→	CELL UPDATE	UE shall trigger cell updating. The message shall indicate the same U-RNTI assigned in the RNTI REALLOCATION message in step 2.
6		←	CELL UPDATE CONFIRM	IE"DRX indicator" is set to "No DRX".

Specific Message Content

#### RNTI REALLOCATION (Step 2)

Use the same message sub-type as in TS 34.108 Clause 8, with the following exceptions:

Information Element	Value/remark
New U-RNTI	
- SRNC Identity	'0000 0000 0001'
- S-RNTI	'0101 0101 0101 0101 0101'
New C-RNTI	'1010 1010 1010 1010'
DRX Indicator	DRX with cell updating

#### RNTI REALLOCATION COMPLETE (Step 3)

Only the message type IE is checked in this message.

#### PAGING TYPE 1 (Step 4)

Use the same message sub-type as in TS 34.108 Clause 8, with the following exceptions:

Information Element	Value/remark
Page Record List <ul style="list-style-type: none"> <li>- Paging record</li> <li>- CHOICE Paging originator</li> <li>- U-RNTI</li> <li>- SRNC Identity</li> <li>- S-RNTI</li> </ul> BCCH modification info	UTRAN originator '0000 0000 0001' '0101 0101 0101 0101 0101' Not Present

## CELL UPDATE (Step 5)

Information Element	Value/remark
U-RNTI <ul style="list-style-type: none"> <li>- SRNC Identity</li> <li>- S-RNTI</li> </ul> Integrity check info AM_RLC error indicator (for C-plane) AM_RLC error indicator (for U-plane) Hyper frame number Cell Update Cause Protocol error indicator Measured results on RACH Protocol error information	Check to see if set to '0000 0000 0001' Check to see if set to '0101 0101 0101 0101 0101' Not checked Check to see if set to 'FALSE' Check to see if set to 'FALSE' Check to see if it is present Check to see if set to 'Paging Response' Check to see if it is absent or set to 'FALSE' Check to see if it is absent Check to see if it is absent

## CELL UPDATE CONFIRM (Step 6)

Use the same message sub-type as in TS 34.108 Clause 8.


## 8.3.3.1.5 Test requirement

After step 2 the UE shall transmit an RNTI REALLOCATION COMPLETE message on the uplink DCCH. The MAC PDU carrying this message shall comprise either the new C-RNTI or U-RNTI allocated in the "UE-id" field of the MAC header.

After step 4 the UE shall transmit a CELL UPDATE message on the uplink CCCH with IE" Cell update cause" set to "paging response". The IE"U-RNTI" shall be identical to the IE"New RNTI" found in RNTI REALLOCATION message sent by the SS in step 2.

## 8.3.3.2 RNTI reallocation: Failure (Invalid message reception)

## 8.3.3.2.1 Definition

## 8.3.3.2.2 Conformance Requirements

When the UE receives an RNTI REALLOCATION message, which contains an error in one of the mandatory IE, it shall transmit a RNTI REALLOCATION FAILURE message on the DCCH using AM RLC and set the value "protocol error" in the IE"failure cause". The IE"protocol error information" in this message shall also be set to an appropriate value. The UE shall not utilize any identities relayed in the erroneous message, and it shall resume normal operations.

## 8.3.3.2.3 Test Purpose

To confirm that the UE ignore the new connected mode identities conveyed in an erroneous RNTI REALLOCATION message. To confirm that the UE report this event to the UTRAN by sending RNTI REALLOCATION FAILURE message, stating the appropriate failure cause and information.



## 8.3.3.2.4 Method of test

## Initial Conditions

System Simulator : 1 cell

UE : CELL\_FACH

## Test Procedure

The UE is brought to CELL\_FACH state. SS transmits a RNTI REALLOCATION message to the UE on the DCCH using UM-RLC mode. In this message, the IE "DRx Indicator" is set to one of the spare values. A new U-RNTI identity is also present in this message. The UE shall respond by transmitting the RNTI REALLOCATION FAILURE message, indicating "protocol error" in IE "failure cause" and also "Information element not comprehended" in IE "Protocol error information". After receiving the RNTI REALLOCATION FAILURE message, SS waits for a duration to allow T305 to expire. The UE shall transmit CELL UPDATE message with the original U-RNTI identity assigned. SS complete this test by sending CELL UPDATE CONFIRM message to the UE on the downlink DCCH.

## Expected Sequence

Step	Direction		Message	Comment
	UE	SS		
1				The initial state of the UE is CELL_FACH state.
2		←	RNTI REALLOCATION	Contains a new U-RNTI identity, but a spare value is used in the IE "DRx indicator"
3		→	RNTI REALLOCATION FAILURE	UE shall transmit this message to report the error in RNTI REALLOCATION message. It shall include the appropriate cause in the message.
4				SS waits for a period up to timer T305 to allow the UE to start performing a cell updating procedure.
5		→	CELL UPDATE	UE shall trigger periodic cell updating. The message shall not contain the U-RNTI given in the RNTI REALLOCATION message in step 2.
6		←	CELL UPDATE CONFIRM	

## Specific Message Content

## RNTI REALLOCATION (Step 2)

Use the same message sub-type as in TS 34.108 Clause 8, with the following exceptions:

Information Element	Value/remark
New U-RNTI - SRNC Identity - S-RNTI DRX Indicator	0000 0000 0001B 0000 0000 0000 0000 00011B Set to one of the spare value

## RNTI REALLOCATION FAILURE (Step 3)

Information Element	Value/remark
Failure Cause Protocol Error Information	Check to see if set to 'Protocol error' Check to see if set to 'Information Element not comprehended'

## CELL UPDATE (Step 5)

Information Element	Value/remark
U-RNTI - SRNC Identity - S-RNTI	Shall be the same as the original U-RNTI allocated Check to see if set to '0000 0000 0000 0001'B Check to see if set to '0000 0000 0000 0000 0000 0001'B
Integrity check info	Not checked
AM_RLC error indicator (for C-plane)	Check to see if set to 'FALSE'
AM_RLC error indicator (for U-plane)	Check to see if set to 'FALSE'
Hyper frame number	Check to see if it is present
Cell update cause	Check to see if set to 'Periodic Cell Updating'
Protocol error indicator	Check to see if it is absent or set to 'FALSE'
Measured results on RACH	Check to see if it is absent
Protocol error information	Check to see if it is absent

## CELL UPDATE CONFIRM (Step 6)

Use the same message sub-type as in TS 34.108 Clause 8

## 8.3.3.2.5 Test Requirement

After step 2 the UE shall transmit RNTI REALLOCATION FAILURE message, indicating the value "protocol error" in IE "failure cause" and also "information element not comprehended" in IE "protocol error information".

After step 4 the UE shall initiate a periodic cell updating procedure by transmitting CELL UPDATE message on the CCCH. In this message, the U-RNTI identity shall be set to the same value as assigned during the RRC connection establishment procedure.

## 8.3.4 Active set update in soft handover

## 8.3.4.1 Active set update in soft handover: Radio Link addition

## 8.3.4.1.1 Definition

## 8.3.4.1.2 Conformance requirement

Radio link addition is triggered in the network's RRC layer. The RRC entity in the network first configures the new radio link. Transmission and reception then begin immediately. This procedure is to update the active set of the connection between the UE and UTRAN. The UTRAN then transmits an ACTIVE SET UPDATE message to the UE. The UE configures layer 1 to begin reception for the additional radio link. After the UE receives confirmation from the physical layer in the UE, an ACTIVE SET UPDATE COMPLETE message is sent to the UTRAN.

## Reference

3GPP TS 25.331 clause 8.3.4

### 8.3.4.1.3 Test purpose

To confirm that the UE continues to communicate with the SS on both the additional radio link and an already existing radio link after the radio link addition.

### 8.3.4.1.4 Method of test

#### Initial Condition

System Simulator : 2cells - Cell 1 is active ,Cell 2 is active

UE : CELL\_DCH in cell 1

#### Test Procedure

Initially, the UE establishes a radio access bearer in the CELL\_DCH state in cell 1. The SS begins to configure the new radio link to be added from cell 2. Then the SS transmits to the UE an ACTIVE SET UPDATE message in cell 1 on DCCH using AM RLC which includes the IE" Radio Link Addition Information".(e.g.Downlink DPCH information and other optional parameters relevant for the additional radio links with Primary CPICH info used for the reference ID). When the UE receives this message, the UE shall configure layer 1 to begin reception without affecting the current uplink and downlink activities of existing radio links. After the UE confirms the synchronization with the new radio link from cell 2, the UE shall transmit an ACTIVE SET UPDATE COMPLETE message to the SS on the uplink DCCH using AM RLC. The UE continues to communicate with the SS on the both radio links. To test this condition, SS ceases the operations of all uplink and downlink DPCH from cell 1. SS shall observe that the data communication for both DCCH and DTCH channels continue as per normal using cell 2, as if cell 1 is still operational.

#### Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is brought to CELL_DCH state in cell 1, after the successful establishment of a radio access bearer service.
2				The SS configures an additional radio link in the downlink direction from cell 2.
3		←	ACTIVE SET UPDATE	SS transmits this message in cell 1 on downlink DCCH using AM RLC. The message includes IE" Radio Link Addition Information". (e.g.Downlink DPCH information and other optional parameters relevant for the additional radio links with Primary CPICH info used for the reference ID in cell 2)
4		→	ACTIVE SET UPDATE COMPLETE	The UE shall configure a new radio link to cell 2, without interfering with existing connections on the radio link in cell 1. SS ceases all Tx and Rx activities in cell 1. But it shall be able to communicate with UE through cell 2.

## Specific Message Content

## ACTIVE SET UPDATE

The message to be used in this test is defined in the default message content clause, with the following exceptions:

Information Element	Value/remark
Radio link addition information	
- Primary CPICH Info	Set to same code as assigned for cell 2
- Primary Scrambling Code	
- Downlink DPCH info for each RL	
- Primary CPICH usage for channel estimation	P-CPICH can be used.
- DPCH frame offset	0 chips
- Secondary CPICH info	Not Present
- DL channelisation code	This IE is repeated for all existing downlink DPCHs allocated to the UE
- Secondary scrambling code	Not Present
- CHOICE Spreading factor	512
- Code Number	For each DPCH, assign the same code number in the current code given in cell 1.
- Scrambling code change	Not Present
- TPC Combination Index	Not Present
- SSDT Cell Identity	Not Present
- Close loop timing adjustment mode	Not Present
- TFCI Combining Indicator	Not Present
- Secondary CCPCH Info	Not Present
- TFCS	Not Present
- FACH/PCH Information	Not Present
- Reference to other system information blocks	Not Present
Radio link removal information	Not Present

## 8.3.4.1.5 Test requirement

After step 3 the UE shall configure a new radio link to cell 2, with the connection on the old radio link in cell 1 remaining operational and unaffected. It shall transmit an ACTIVE SET UPDATE COMPLETE message on the uplink DCCH using AM RLC to acknowledge the completion of the active set additional procedure.

After step 4 the SS shall continue to communicate with the UE using the radio links added to the UE from cell 2.

## 8.3.4.2 Active set update in soft handover : Radio Link removal

## 8.3.4.2.1 Definition

## 8.3.4.2.2 Conformance requirement

This procedure is to update the active set of the connection between the UE and the UTRAN after the UTRAN has commanded a removal of a radio link from the current active set. The UTRAN RRC transmits an ACTIVE SET UPDATE message to the UE RRC. The UE RRC requests UE L1 to terminate transmission and reception of the radio link to be removed. The UE shall continue to communicate normally with the UTRAN using the new active set, without losing the connection link. After this the UE acknowledges the radio link removal by sending an ACTIVE SET UPDATE COMPLETE message to the UTRAN on DCCH using AM RLC.

## Reference

3GPP TS 25.331 clause 8.3.4

## 8.3.4.2.3 Test purpose

To confirm that the UE continues to communicate with the SS on the remaining radio link after radio link removal on the active set.

## 8.3.4.2.4 Method of test

## Initial Condition

System Simulator : 2cells - both Cell 1 and Cell 2 are active

UE : CELL\_DCH in cell 1

## Test Procedure

At the start of the test, the UE establishes a radio access bearer service in the CELL\_DCH state in cell 1. This is followed by a radio link addition procedure in cell 2. SS then transmits an ACTIVE SET UPDATE message, which includes IE" Radio Link Removal Information" and specifying the P-CPICH information of the cell to be removed. When the UE receives this message, the UE RRC entity shall request UE L1 entity to terminate transmission and reception of the radio link from cell 1. Then the UE transmits an ACTIVE SET UPDATE COMPLETE message to the SS on the uplink DCCH using AM RLC. The UE shall continue to communicate with the SS on the remained radio link in cell 2.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is in the CELL DCH state in cell 1. SS executes test 8. 3.4.1, and the UE shall update the active set to contain cell 1 and cell 2 after the radio link addition procedure.
2		←	ACTIVE SET UPDATE	The SS transmits this message on downlink DCCH using AM RLC which includes IE" Radio Link Removal Information".
3		→	ACTIVE SET UPDATE COMPLETE	The UE shall remove the radio link associated with cell 1.
4				The SS stops transmission on the downlink direction from cell 1 and the UE shall continue to communicate on the remaining radio link in cell 2.

## Specific Message Contents

## ACTIVE SET UPDATE

The message to be used in this test is the same as the message sub-type found in TS 34.108 clause 8, with the following exceptions:

Information Element	Value/remark
Radio link addition information	Not Present
Radio link removal information	1 radio link to be removed
- Primary CPICH info	
- Primary scrambling code	Set to the same P-CPICH scrambling code assigned for cell 1

#### 8.3.4.2.5 Test requirement

After step 2 the UE shall remove the radio link from cell 1 and it shall transmit an ACTIVE SET UPDATE COMPLETE message on the uplink DCCH using AM RLC.

After step 3 the UE shall continue to communicate on the remaining radio link from cell 2.

### 8.3.4.3 Active set update in soft handover: Combined radio link addition and removal (active set is not full)

#### 8.3.4.3.1 Definition

#### 8.3.4.3.2 Conformance requirement

When radio links are to be replaced, the UTRAN RRC first configures the UTRAN L1 to activate the radio link(s) that are being added. The UTRAN RRC then transmits an ACTIVE SET UPDATE message to the UE RRC, which shall configure the UE L1 to terminate transmission and reception on the removed radio link(s) and begin transmission and reception on the added radio link(s). At the completion of the reconfiguration of radio links, the UE shall acknowledge the replacement with an ACTIVE SET UPDATE COMPLETE message.

#### Reference

3GPP TS 25.331 clause 8.3.4

#### 8.3.4.3.3 Test purpose

To confirm that the UE continues to communicate with the SS on the added radio link and removes radio link which exists prior to the execution of active set update procedure.

#### 8.3.4.3.4 Method of test

#### Initial Condition

System Simulator : 2cells- Both Cell 1 and Cell 2 are active

UE :CELL\_DCH in cell 1 [Active set is not full.]

#### Test Procedure

The UE establishes a radio access bearer in the CELL\_DCH state in cell 1. SS begin to configure the new radio link in cell 2. Then the SS transmits to the UE an ACTIVE SET UPDATE message in cell 1 on DCCH using AM RLC. The message includes IE" Radio Link Addition Information". and IE" Radio Link Removal Information", indicating the removal of cell 1 and addition of cell 2 into the active set. When the UE receives this message, the UE RRC shall terminate the transmission and reception of the removed radio link in cell 1 and then configures layer 1 to begin transmission and reception in cell 2. After the UE received confirmations from the physical layer regarding the update of active set, it transmits an ACTIVE SET UPDATE COMPLETE message on the uplink DCCH to the SS. The UE shall continue to communicate with the SS on the added radio link in cell 2. When SS receives ACTIVE SET UPDATE COMPLETE message, it verifies that the UE has ceased any uplink transmission in cell 1.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is in the CELL_DCH state in cell 1
2				The SS configures an additional radio link in cell 2, starting the transmission and reception of data in cell 2. Clause
3		←	ACTIVE SET UPDATE	The SS transmit this message on downlink DCCH using AM RLC which includes IE" Radio Link Addition Information" for cell 2 and IE" Radio Link Removal Information" for cell 1.
4		→	ACTIVE SET UPDATE COMPLETE	The UE shall configure a new radio link in cell 2 and removes the old radio link in cell 1.
5				The SS removes the radio link from cell 1 and the UE shall continue to communicate on the added radio link in cell 2, and not transmit any data in cell 1.

## Specific Message Content

## ACTIVE SET UPDATE

The message to be used in this test is defined in the default message content clause, with the following exceptions:

Information Element	Value/remark
Radio link addition information	
- Primary CPICH Info	Set to same code as assigned for cell 2
- Primary Scrambling Code	
- Downlink DPCH info for each RL	P-CPICH can be used.
- Primary CPICH usage for channel estimation	0 chips
- DPCH frame offset	Not Present
- Secondary CPICH info	This IE is repeated for all existing downlink DPCHs allocated to the UE
- DL channelisation code	Not Present
- Secondary scrambling code	Not Present
- CHOICE Spreading factor	512
- Code Number	For each DPCH, assign the same code number in the current code given in cell 2.
- Scrambling code change	Not Present
- TPC Combination Index	Not Present
- SSDT Cell Identity	Not Present
- Close loop timing adjustment mode	Not Present
- TFCI Combining Indicator	Not Present
- Secondary CCPCH Info	Not Present
- TFCS	Not Present
- FACH/PCH Information	Not Present
- Reference to other system information blocks	Not Present
Radio link removal information	
- Primary CPICH Info	
- Primary Scrambling Code	Set to same code assigned as for cell 1

#### 8.3.4.3.5 Test requirement

After step 3 the UE shall remove the radio link in cell 1 and add the radio link in cell 2. Then the UE shall transmit an ACTIVE SET UPDATE COMPLETE message the uplink DCCH.

After step 4 the UE shall continue to communicate on the added radio link in cell 2. SS monitors the uplink direction to confirm that no data are designated for reception in cell 1.

### 8.3.4.4 Active set update in soft handover: Unsupported Configuration in the UE

#### 8.3.4.4.1 Definition

#### 8.3.4.4.2 Conformance requirement

If the UTRAN attempts to remove a radio link that is not currently present in the UE's active set, the UE transmits an ACTIVE SET UPDATE FAILURE message on the DCCH using AM RLC and maintain its current communication status with the radio links.

#### Reference

3GPP TS 25.331 clause 8.3.4

#### 8.3.4.4.3 Test purpose

To confirm that the UE transmits an ACTIVE SET UPDATE FAILURE message on the DCCH using AM RLC, following the reception of a message specifying the removal of a radio link unknown to the UE.

#### 8.3.4.4.4 Method of test

#### Initial Condition

System Simulator : 2cells - Cell 1 is active, Cell 2 is active.

UE :CELL\_DCH in cell 1.



## Test Procedure

The UE establishes a radio access bearer in the CELL\_DCH state in cell 1. SS requests for a radio link addition by executing the steps described in test case 8.3.4.1. The UE shall then include cell 2 into its active set and establish the transmission and reception capabilities related to cell 2. SS then transmits an ACTIVE SET UPDATE message in cell 1 on DCCH using AM RLC which includes IE" Radio Link Removal Information". This IE indicates that a cell with unknown P-CPICH scrambling code be removed from the active set. When the UE receives this message, it transmits an ACTIVE SET UPDATE FAILURE message which is set to "configuration unacceptable" in IE" failure cause" on the uplink DCCH using AM RLC to the SS, and continues to communicate on the existing radio links in cell 1 and cell 2.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is in the CELL_DCH state in cell 1.
2				SS commands the UE to perform a radio link addition procedure by executing the steps in test case 8.3.4.1. The UE shall respond accordingly. Both cell 1 and cell 2 should be found in the active set maintained by the UE.
3		←	ACTIVE SET UPDATE	The SS transmits this message on downlink DCCH using AM RLC which includes IE" Radio Link Removal Information". This content of this IE indicates an unknown cell.
4		→	ACTIVE SET UPDATE FAILURE	The message shall state "configuration unacceptable" in IE"failure cause". UE shall continue to communicate normally with both cells

## Specific Message Contents

### ACTIVE SET UPDATE (Step 3)

The message to be used in this test is defined in the default message content clause, with the following exceptions:

Information Element	Value/remark
Radio link addition information	Not Present
Radio link removal information	1 radio link to be removed
- Primary CPICH info	
- Primary scrambling code	Set to an unknown scrambling code not assigned to any cells.

### ACTIVE SET UPDATE FAILURE (Step 4)

Information Element	Value/remark
Integrity check info	Not Checked
Failure cause	Check to see if it's set to 'configuration unacceptable'

### 8.3.4.4.5 Test requirement

After step 3 the UE shall transmit an ACTIVE SET UPDATE FAILURE message, setting "configuration unacceptable" in IE" failure cause" and sent on the uplink DCCH using AM RLC.

After step 4 the UE shall continue to communicate on the radio links for both cell 1 and cell 2.

### 8.3.4.5 Active set update in soft handover: Combined radio link addition and removal (active set is full)

#### 8.3.4.5.1 Definition

#### 8.3.4.5.2 Conformance requirement

When the UE active set is full, the UE shall first remove the old radio link and then add the new radio link, after it receives an ACTIVE SET UPDATE message for the combined radio link addition and removal.

#### Reference

3GPP TS 25.331 clause 8.3.4

#### 8.3.4.5.3 Test purpose

To confirm that the UE removes one of existing radio links, which is indicated in an ACTIVE SET UPDATE message and continues to communicate on the added radio link.

#### 8.3.4.5.4 Method of test

#### Initial Condition

System Simulator : 3 cells - Cell 1 , Cell 2, and Cell 3 are all active

UE :CELL\_DCH in cell 1, cell 2 (The assumed maximum number for active set is 2.)

*[Editor's Note] The maximum number of radio link (i.e. MaxRL) specified in CR328 of TS 25.331 is 8. However, if the UE capability is more inferior in this aspect, can the assumption above still stands?*

#### Test Procedure

The UE establishes a radio access bearer in the CELL\_DCH state in cell 1 and cell 2. The SS configures the new radio link in cell 3 and sends an ACTIVE SET UPDATE message on DCCH using AM. This message includes IE" Radio Link Addition Information" indicating cell 3 to be added into the active set, and IE" Radio Link Removal Information" indicating the removal of cell 1 from the active set. When the UE receives this message, it shall not report a failure but firstly removes the indicated radio link and then adds the new radio link. Then the UE transmits an ACTIVE SET UPDATE COMPLETE message on the DCCH using AM RLC to the SS and continues to communicate with the SS on the added radio link and the remaining old radio link.

## Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is in the CELL_DCH state in cell 1 and cell 2.
2				The SS configures an additional radio link in for cell 3, and starts reception and transmission using cell 3.
3		←	ACTIVE SET UPDATE	The SS transmit this message on downlink DCCH using AM RLC which includes IE" Radio Link Addition Information" and IE" Radio Link Removal Information". The contents of the IE dictate the addition of cell 3 into the active set and removal of cell 1 from it.
4		→	ACTIVE SET UPDATE COMPLETE	The UE shall configure a new radio link in cell 3 and removes the old radio link in cell 1.
5				The SS removes the radio link in cell 1. The UE shall continue to communicate on the added radio link in cell 3 and also the existing radio link in cell 2.

## Specific Message Content

## ACTIVE SET UPDATE

The message to be used in this test case is identical to the same message sub-type found in TS 34.108 Clause 8clause, with the following exceptions:

Information Element	Value/remark
Radio link addition information	
- Primary CPICH Info	Set to same code as assigned for cell 3
- Primary Scrambling Code	
- Downlink DPCH info for each RL	P-CPICH can be used.
- Primary CPICH usage for channel estimation	0 chips
- DPCH frame offset	Not Present
- Secondary CPICH info	This IE is repeated for all existing downlink DPCHs allocated to the UE
- DL channelisation code	Not Present
- Secondary scrambling code	Not Present
- CHOICE Spreading factor	512
- Code Number	For each DPCH, assign the same code number in the current code given in cell3.
- Scrambling code change	Not Present
- TPC Combination Index	Not Present
- SSDT Cell Identity	Not Present
- Close loop timing adjustment mode	Not Present
- TFCI Combining Indicator	Not Present
- Secondary CCPCH Info	Not Present
- TFCS	Not Present
- FACH/PCH Information	Not Present
- Reference to other system information blocks	Not Present
Radio link removal information	
- Primary CPICH Info	
- Primary Scrambling Code	Set to same code assigned as for cell 1

#### 8.3.4.5.5 Test requirement

After step 3 the UE shall remove the radio link in cell 1 and add the radio link in cell 3. Then the UE shall transmit an ACTIVE SET UPDATE COMPLETE message on the uplink DCCH.

After step 4 the UE shall continue to communicate on the added radio link in cell 3 and on the existing old radio link in cell 2. It shall cease all transmission to cell 1.

#### 8.3.4.6 Active set update in soft handover: Subsequent reception of ACTIVE SET UPDATE message / Incompatible simultaneous reconfiguration

##### 8.3.4.6.1 Definition

##### 8.3.4.6.2 Conformance Requirements

The UE shall ignore a subsequent ACTIVE SET UPDATE message, while it is still processing an existing active set update procedure. It shall continue to configure itself in accordance to the first ACTIVE SET UPDATE message received. When encountering a “simultaneous reconfiguration” situation, the UE shall transmit a ACTIVE SET FAILURE message on the DCCH using AM RLC with value “incompatible simultaneous reconfiguration” set in IE “failure cause”. Then the UE shall continue to execute the ordered reconfiguration (for example due to a radio bearer reconfiguration) as if the ACTIVE SET UPDATE message has not been received.

#### Reference

3GPP TS 25.331 clause 8.3.4

##### 8.3.4.6.3 Test Purpose

To confirm that the UE continues to execute the prior active set update request, when it receives a subsequent ACTIVE SET UPDATE messages before it has completely executed the first update procedure. To confirm that the UE transmits an ACTIVE SET UPDATE FAILURE message to report the detection of a “incompatible simultaneous reconfiguration” condition, when an ACTIVE SET UPDATE message was received before the UE can complete an on-going radio bearer reconfiguration procedure.

## Method of test

## Initial Condition

System Simulator : 2 cells – both cell 1 and cell 2 are active

UE : CELL\_DCH in cell 1 and cell 2

## 8.3.4.6.4 Test Procedure

The UE establishes a radio access bearer in CELL\_DCH state in cell 1 and cell 2. SS transmits an ACTIVE SET UPDATE message to request for the removal of cell 1 from the active list. When the UE sends an acknowledgement for this message from its RLC entity, SS immediately transmits a second ACTIVE SET UPDATE message, which specifies cell 1 to be added into the active list. SS verifies that the UE ceases transmission on the radio link associated with cell 1 when the activation time indicated in the first ACTIVE SET UPDATE message is reached. Next, SS sends a RADIO BEARER RELEASE message using AM-RLC on the DCCH. In this message, SS requests the release of the radio access bearer. When RLC acknowledgement has been received from the UE, SS immediately sends an ACTIVE SET UPDATE message. In this message, SS commands the UE to add cell 1 into its active list with the activation time set to “now”. The UE shall react by transmitting ACTIVE SET UPDATE FAILURE message on the DCCH using AM-RLC mode. In this message, the IE “failure cause” shall be set to “incompatible simultaneous reconfiguration”. When the activation time stated in RADIO BEARER RELEASE message has elapsed, the UE shall transmit the RADIO BEARER RELEASE COMPLETE message to inform that the assigned radio access bearer is release. When SS receives this message, it verifies that UE continues to communicate with the SS on the radio link associated with cell 2 only, and that no user data are exchanged on the previously available radio access bearer.

## Expected Sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is CELL_DCH state in both cell 1 and cell 2.
2		←	ACTIVE SET UPDATE	The SS transmits this message on downlink DCCH using AM RLC, requesting for cell 1 to be removed from the active set.
3		←	ACTIVE SET UPDATE	Immediately after UE acknowledges the message in step 2, SS transmits this message. This message specifies that cell 1 be added into the active set.
4				SS waits until the activation time stated in step 2 has elapsed, and verifies that the UE stops transmitting on the radio link of cell 1.
5		→	ACTIVE SET UPDATE COMPLETE	UE shall transmit this message to signal the completion of the active set update procedure triggered in step 2.

6	←	RADIO BEARER RELEASE	SS checks that UE stops all uplink activities on the radio link associated with cell 1. SS requests that the radio access bearer allocated to the UE be released.
7	←	ACTIVE SET UPDATE	SS indicates that the UE shall reinstate cell 1 into its active set, immediately after RLC acknowledgement is received for the message sent in step 6.
8	→	ACTIVE SET UPDATE FAILURE	In IE "failure cause", the reason "incompatible simultaneous reconfiguration" shall be stated.
9	→	RADIO BEARER RELEASE COMPLETE	The UE shall send this message when the activation time specified in step 6 is reached. Upon reception of this message, SS verifies that there is no more uplink user traffic on the radio access bearer.

#### Specific Message Contents

#### ACTIVE SET UPDATE (Step 2)

Use the default message for this type found in Annex, with the following exceptions:

Information Element	Value/remark
Radio link addition information Radio link removal information - Primary CPICH info - Primary scrambling code	Not Present.  Set to the P-CPICH scrambling code assigned to cell 1.

#### ACTIVE SET UPDATE (Step 3)

Use the default message for this type found in Annex A, with the following exceptions

Information Element	Value/remark
Radio link addition information	
- Primary CPICH Info	Set to same code as assigned for cell 1
- Primary Scrambling Code	
- Downlink DPCH info for each RL	P-CPICH can be used.
- Primary CPICH usage for channel estimation	0 chips
- DPCH frame offset	Not Present
- Secondary CPICH info	This IE is repeated for all existing downlink DPCHs allocated to the UE
- DL channelisation code	Not Present
- Secondary scrambling code	Not Present
- CHOICE Spreading Factor	512
- Code Number	For each DPCH, assign the same code number in the current code given in cell 1.
- Scrambling code change	Not Present
- TPC Combination Index	Not Present
- SSDT Cell Identity	Not Present
- Close loop timing adjustment mode	Not Present
- TFCI Combining Indicator	Not Present
- Secondary CCPCH Info	Not Present
- TFCS	Not Present
- FACH/PCH information	Not Present
- Reference to other system information blocks	Not Present
Radio link removal information	Not Present

**ACTIVE SET UPDATE COMPLETE (Step 5)**

Only the message type for this message is checked.

**RADIO BEARER RELEASE (Step 6)**

Use the same message sub-type titled “AM or UM (The others of speech in CS)” found in Annex A.

**ACTIVE SET UPDATE (Step 7)**

Use the same message as in that for step 3, with the following exception:

Information Element	Value/remark
Activation Time	Not Present – use default

**ACTIVE SET UPDATE FAILURE (Step 8)**

Information Element	Value/remark
Failure Cause	Check to see if set to “Incompatible simultaneous reconfiguration”

**RADIO BEARER RELEASE COMPLETE (Step 9)**

Information Element	Value/remark
Integrity check Info	Not checked
Uplink integrity protection activation info	Not checked
Radio bearer uplink ciphering activation time info	Not checked

**8.3.4.6.5 Test Requirement**

After step 5 the UE shall ignore the second ACTIVE SET UPDATE message received, terminate the radio link in relation to cell 1, and transmit ACTIVE SET UPDATE COMPLETE using AM-RLC on the uplink DCCH of cell 2.

After step 7 the UE shall report the “incompatible simultaneous reconfiguration” error by transmitting ACTIVE SET UPDATE FAILURE message on the DCCH.

After step 8 the UE shall send RADIO BEARER RELEASE COMPLETE message to cell 2 on the uplink DCCH, using AM-RLC mode. The UE shall stop all transmissions of user traffic on the radio access bearer assigned.

### 8.3.4.7 Active set update in soft handover: Invalid Message Reception

#### 8.3.4.7.1 Definition

#### 8.3.4.7.2 Conformance Requirement

The UE shall keep its old configuration when the UE receives an ACTIVE SET UPDATE message, which omits a conditional IE. It shall transmit a ACTIVE SET UPDATE FAILURE message which set value “protocol error” in IE” failure cause” and also value “Conditional information element error” in IE” Protocol error cause”.

#### Reference

3GPP TS 25.331 clause 8.3.4

#### 8.3.4.7.3 Test Purpose

To confirm that the UE retains its active set list when it receives an ACTIVE SET UPDATE message, with a conditional IE missing in the message.

#### 8.3.4.7.4 Method of test

#### Initial Condition

System Simulator : 2 cells – both cell 1 and cell 2 are active.

UE : CELL\_DCH in cell 1 (Integrity protection algorithm is not applied at the start of test)

#### Test Procedure

The UE establishes a radio access bearer in CELL\_DCH in cell 1. SS requests that cell 2 be added into the active set by performing the steps described in test cases 8.3.4.1. The UE shall react accordingly and incorporate cell 2 into its active set. SS transmits an ACTIVE SET UPDATE message , with both IE”Integrity check info” and IE”Integrity protection mode info” present in the message. This message also commands the starting of integrity mode protection. However, the IE”integrity protection initialisation number” is omitted. The UE shall detect that it has received an invalid message. It shall then send a ACTIVE SET UPDATE FAILURE message, stating the reason “Conditional information element error” in the IE”Protocol error information”. The UE shall not remove cell 1 from its current active set.



## Expected Sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is CELL_DCH state in cell 1.
2				SS executes the steps in test case 8.3.4.1. The UE shall add cell 2 into its active set.
3		←	ACTIVE SET UPDATE	The SS transmits this message on downlink DCCH using AM RLC which includes IE"Integrity check info" and IE"Integrity protection mode info". This message indicates that integrity mode protection be started but omit the IE"integrity protection initialisation number". The message also specifies that cell 1 be removed from the active set.
4		→	ACTIVE SET UPDATE FAILURE	The message shall state "conditional information element error" in IE"protocol error information". UE shall continue to communicate normally with both cells.

## Specific Message Contents

## ACTIVE SET UPDATE (Step 3)

The message to be used in this test is defined in the default message content clause, with the following exceptions:

Information Element	Value/remark
Integrity Check Info <ul style="list-style-type: none"> <li>- Message authentication code</li> <li>- RRC Message sequence number</li> </ul>	Set to an arbitrary 32-bits string Set to an arbitrary integer between 0 and 15
Integrity Protection Mode Info <ul style="list-style-type: none"> <li>- Integrity protection mode command</li> <li>- Downlink integration protection activation info</li> </ul>	Start Not Present
<ul style="list-style-type: none"> <li>- Integrity protection algorithm</li> <li>- Integrity protection initialisation number</li> </ul>	Standard UMTS Integrity Algorithm UIA1 Not Present
Radio link addition information	Not Present
Radio link removal information <ul style="list-style-type: none"> <li>- Primary CPICH info</li> <li>- Primary scrambling code</li> </ul>	Set to the P-CPICH scrambling code assigned to cell 1.

## ACTIVE SET UPDATE FAILURE (Step 4)

Information Element	Value/remark
Protocol Error Information <ul style="list-style-type: none"> <li>- Protocol Error Cause</li> </ul>	Check to see if it's set to 'Conditional information element error'

## 8.3.4.7.5 Test Requirement

After step 3 the UE shall report a protocol error by transmitting the ACTIVE SET UPDATE FAILURE message on the DCCH. In this message, the value "Conditional information element error" shall be set in IE"Protocol Error Information". The UE shall continue to communicate normally with the SS using cell 1 and cell 2.

### 8.3.5 Hard Handover

[ Editor's note : This test is included in the "Physical channel reconfiguration" , "Radio bearer establishment" , "Radio bearer reconfiguration" , "Radio bearer release" and " Transport channel reconfiguration". ]

### 8.3.6 Inter system hard handover to UTRAN

[ Editor's note : This test is FFS until R2000 core specification will be defined.]

### 8.3.7 Inter system hard handover from UTRAN

[ Editor's note : This test is FFS until R2000 core specification will be defined.]

### 8.3.8 Inter system cell reselection to UTRAN

[ Editor's note : This test is FFS until R2000 core specification will be defined.]

### 8.3.9 Inter system cell reselection from UTRAN

[ Editor's note : This test is FFS until R2000 core specification will be defined.]

## 8.4 Measurement procedure

### 8.4.1 Measurement Control and Report

#### 8.4.1.1 Measurement Control and Report: Intra-frequency measurement for transition from idle mode to CELL\_DCH state

##### 8.4.1.1.1 Definition

##### 8.4.1.1.2 Conformance requirement

After a state transition from idle mode to CELL\_DCH state, the UE shall continue to monitor the list of neighbouring cells which is specified in the SYSTEM INFORMATION BLOCK TYPE 11 (or 12) messages on BCCH. The UE shall send a MEASUREMENT REPORT message when reporting criteria are satisfied. During CELL\_DCH state, if the UE receives a MEASUREMENT CONTROL message, it shall terminate existing monitoring activities for the neighbouring cells previously known from SYSTEM INFORMATION BLOCK TYPE 11 (or 12) messages. It shall perform the measurement and reporting tasks based on the latest MEASUREMENT CONTROL message received.

#### Reference

3GPP TS 25.331 clause 8.4.1.9

##### 8.4.1.1.3 Test Purpose

To confirm that the UE continue to monitor CPICH RSCP measurement quantity of the neighbour cells after it has entered the CELL\_DCH state from idle mode. When the criteria specified in BCCH have been met, it shall report the measurements to the SS using MEASUREMENT REPORT messages. To confirm that in CELL\_DCH state, the UE respond to a modification of measurement criteria and adjust its measurement and reporting mechanism accordingly. To confirm that the UE terminates monitoring and measurement activities for the neighbour cells found in SYSTEM INFORMATION BLOCK TYPE 11 (or 12) message, after it has received a MEASUREMENT CONTROL message which specifies the measurement type to be “intra-frequency measurement”. To confirm that the UE restart the monitoring and reporting activities based on the last MEASUREMENT CONTROL message received.

##### 8.4.1.1.4 Method of test

#### Initial Condition

System Simulator : 2 cells – Cell 1 is active and the downlink P-CPICH has a transmission level (RSCP) of –40 dBm, cell 2 is also active but with a P-CPICH transmission power 10dB below cell 1.

UE : idle state after having successfully camped onto cell 1.

#### Test Procedure

The UE is initially at idle mode and has selected cell 1 for camping. The SYSTEM BLOCK TYPE 11 message is modified with respect to the default settings to prevent reporting of CFN-SFN difference and also to include cell 2 into the monitored neighbour cell list. The key measurement parameters are as follow: measurement type = “intra-frequency measurement”, measurement quantity = “CPICH RSCP”, report criteria = “periodic reporting criteria”, reporting interval = “12 seconds”.

SS pages the UE with the cause set to terminating call of a supported traffic class. The UE shall transmit a RRC CONNECTION REQUEST message on the CCCH, SS replies with RRC CONNECTION SETUP message and allocates uplink and downlink DPDCH physical resources to the UE. UE then moves to CELL\_DCH state. After approximately 12 seconds, the UE shall transmit a MEASUREMENT REPORT message with measurement readings

from cell 2. SS waits for 25 seconds after the sending of RRC CONNECTION SETUP message to verify that 2 consecutive MEASUREMENT REPORT messages are received.

Then SS modifies the contents of MASTER INFORMATION BLOCK and SYSTEM INFORMATION BLOCK TYPE 12 messages. The measurement parameters for cell 2 are changed in the following manner: report criteria = "event-trigger", event identity = "1f", reporting threshold = "-65 dBm". SS then begins to decrease the transmission power of P-CPICH in cell 2 progressively at the rate of 0.5dB/sec. SS checks to see that no MEASUREMENT REPORT messages are sent within the next 12 seconds (which is due to periodic reporting). The UE shall detect this change and discontinue the periodic reporting of RSCP value estimation from cell 2. After approximately 35 seconds later, the UE shall transmit MEASUREMENT REPORT message to indicate that the RSCP of cell 2 has reached the threshold specified. In this message, the correct measurement identity shall be stated. Finally, SS sends a MEASUREMENT CONTROL message to request a periodic reporting of measurement quantity P-CPICH Ec/No from cell 2. The reporting interval is set to 32 seconds. Within the MEASUREMENT CONTROL message, a new measurement identity is assigned. After receiving this message, the UE shall stop reporting quantity P-CPICH RSCP of cell 2. Moreover, the UE shall start to transmit MEASUREMENT REPORT messages with the contents pertaining to new measurement identity on cell 2's P-CPICH Ec/No.

#### Expected Sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	SYSTEM INFORMATION BLOCK TYPE 11	The UE is idle mode and camped onto cell 1. Cell 2 is also active but the P-CPICH has a RSCP 10dB below that of cell 1. SYSTEM INFORMATION TYPE 12 to be transmitted is different from the default settings (see specific message contents)
2		←	PAGING TYPE 1	SS sends this message to page for the UE.
3		→	RRC CONNECTION REQUEST	
4		←	RRC CONNECTION SETUP	SS allocates DPCH physical channels to UE
5		→	RRC CONNECTION COMPLETE	UE transmits this message to acknowledge the SETUP message and moves to CELL_DCH state.
6		→	MEASUREMENT REPORT	SS waits for 25 seconds. It shall receive 2 consecutive MEASUREMENT REPORT messages
7		←	MASTER INFORMATION BLOCK SYSTEM INFORMATION BLOCK TYPE 12	SS modifies the contents of system information, so that measurement for cell 2 is changed to "event trigger" with "event identity" set to 1f. SS then reduces the transmission power of cell 2's P-CPICH progressively by 0.5dB/sec.
8				SS monitors the DCCH for the next 12 seconds to make sure that no further MEASUREMENT REPORT messages are transmitted.

9	→	MEASUREMENT REPORT	UE shall transmit this message approximately 35 seconds after step 7, as its internal estimation of the RSCP of cell 2 has dropped below the threshold.
10	←	MEASUREMENT CONTROL	A new measurement identity is assigned, with the reporting quantity changed to cell 2's P-CPICH Ec/No
11	→	MEASUREMENT REPORT	SS verifies that UE transmits MEASUREMENT REPORT messages periodically to report the P-CPICH Ec/No value of cell 2.

### Specific Message Contents

All messages indicated below shall use the same content as described in default message content, with the following exceptions:

## SYSTEM INFORMATION BLOCK TYPE 11 (Step 1)

Information Element	Value/Remark
Reference to other system information blocks	Not Present
FACH measurement occasion info	Not Present
Measurement control system information	
- Intra-frequency measurement system information	
- Intra-frequency measurement identity number	1
- Intra-frequency cell info list	
- Removed intra-frequency info list	Not Present
- New intra-frequency info list	
- Intra-frequency cell id	Set to id of cell 2
- Cell info	
- Cell individual offset	0 dB
- Reference time difference to cell	0 chips
- Primary CPICH Info	
- Primary Scrambling Code	Set to same code as used for cell 2
- Primary CPICH TX power	Not Present
- Read SFN Indicator	FALSE
- TX Diversity Indicator	FALSE
- Cell selection and Re-selection info for SIB11/12	
- Qoffset <sub>s,n</sub>	0dB
- Maximum allowed UL TX power	0dBm
- HCS neighbouring cell information	Not Present
- Qqualmin	-115dB
- Qrxlevmin	-20dB
- Intra-frequency measurement quantity	
- Filter Coefficient	0
- Measurement quantity	CPICH RSCP
- Intra-frequency measurement for RACH reporting	
- SFN-SFN observed time difference	No report
- Reporting quantity	No report
- Maximum number of reported cells on RACH	No report
- Reporting information for state CELL_DCH	
- Intra-frequency reporting quantity	
- Reporting quantities for active set cells	
- SFN-SFN observed time difference	No report
- Cell identity	FALSE
- CPICH Ec/No	FALSE
- CPICH RSCP	FALSE
- Pathloss	FALSE
- CFN-SFN observed time difference	FALSE
- Reporting quantities for monitored set cells	
- SFN-SFN observed time difference	No report
- Cell identity	TRUE
- CPICH Ec/No	FALSE
- CPICH RSCP	TRUE
- Pathloss	FALSE
- CFN-SFN observed time difference	FALSE
- Reporting quantities for detected cells	Not present
- CHOICE report criteria	Periodic reporting criteria
- Amount of reporting	Infinity
- Reporting interval	12 seconds
- Inter-frequency measurement system information	Not present
- Inter-system measurement system information	Not Present
- Traffic volume measurement system information	Not Present
- UE internal measurement system information	Not Present

## RRC CONNECTION REQUEST

Information Element	Value/Remarks
---------------------	---------------

Establishment cause	Check to see if set to terminating call of a supported traffic class
Measured results on RACH	Check to see if this IE is absent

## RRC CONNECTION SETUP

Use the message sub-type in default message content, which is marked as “Transition to CELL\_DCH”.



## MEASUREMENT REPORT (Step 6)

Information Element	Value/Remarks
Measurement identity number	Check to see if set to 1
Measurement Results	
- CHOICE measurement	Check to see if set to "Intra-frequency measured results list"
- Intra-frequency measured results	
- Cell measured results	
- Cell Identity	Check to see if set to the id of cell 2
- CFN-SFN observed time difference	Check to see if this IE is absent
- SFN-SFN observed time difference	Check to see if this IE is absent
- Primary CPICH Info	
- Primary Scrambling Code	Check to see if it's the same code for cell 2
- CPICH Ec/No	Check to see if this IE is absent
- CPICH RSCP	Check value to see if within acceptable range
- Pathloss	Check to see if this IE is absent
Event Results	Check to see if this IE is absent

## MASTER INFORMATION BLOCK (Step 7)

Information Element	Value/Remarks
MIB Tag	2

## SYSTEM INFORMATION BLOCK TYPE 12 (Step 7)

Information Element	Value/Remark
Reference to other system information blocks	Not Present
FACH measurement occasion info	Not Present
Measurement control system information	
- Intra-frequency measurement system information	
- Intra-frequency measurement identity number	2
- Intra-frequency cell info list	
- Removed intra-frequency info list	Not Present
- New intra-frequency info list	
- Intra-frequency cell id	Set to id of cell 2
- Cell info	
- Cell individual offset	0 dB
- Reference time difference to cell	0 chips
- Primary CPICH Info	
- Primary Scrambling Code	Set to same code as used for cell 2
- Primary CPICH TX power	Not Present
- Read SFN Indicator	FALSE
- TX Diversity Indicator	FALSE
- Cell selection and re-selection info for SIB11/12	
- Qoffset <sub>s,n</sub>	0dB
- Maximum allowed UL TX power	0dBm
- HCS neighbouring cell information	Not Present
- Qqualmin, Qrxlevmin	-20dB, -115dBm
- Intra-frequency measurement quantity	
- Filter Coefficient	0
- Measurement quantity	CPICH RSCP
- Intra-frequency measurement for RACH reporting	
- SFN-SFN observed time difference	No report
- Reporting quantity	No report
- Maximum number of reported cells on RACH	No report
- Reporting information for state CELL_DCH	
- Intra-frequency reporting quantity	
- Reporting quantities for active set cells	No report
- SFN-SFN observed time difference	FALSE
- Cell identity	FALSE
- CPICH Ec/No	FALSE
- CPICH RSCP	FALSE
- Pathloss	FALSE

- CFN-SFN observed time difference	FALSE
- Reporting quantities for monitored set cells	No report
- SFN-SFN observed time difference	TRUE
- Cell identity	FALSE
- CPICH Ec/No	TRUE
- CPICH RSCP	FALSE
- Pathloss	FALSE
- CFN-SFN observed time difference	Not present
- Reporting quantities for detected cells	Intra-frequency measurement reporting criteria
- CHOICE report criteria	
- Parameter required for each event	
- Intra-frequency event identity	Event type 1f
- Triggering condition	Monitored set cells
- Reporting range	Not present
- Cells forbidden to affect reporting	Not present
- W	Not present
- Hysteresis	Not Present
- Threshold Used Frequency	-65dBm
- Reporting deactivation threshold	Not present
- Replacement activation threshold	Not present
- Time to trigger	0
- Amount of reporting	Infinity
- Reporting Interval	8 seconds
- Reporting Cell Status	Not Present
- Inter-frequency measurement system information	Not present
- Inter-system measurement system information	Not Present
- Traffic volume measurement system information	Not Present
- UE internal measurement system information	Not Present

## MEASUREMENT REPORT (Step 9)

Information Element	Value/Remarks
Measurement identity number	Check to see if set to 2
Measurement Results	
- CHOICE measurement	Check to see if set to "Intra-frequency measured results list"
- Intra-frequency measured results	
- Cell measured results	
- Cell Identity	Check to see if set to the id of cell 2
- CFN-SFN observed time difference	Check to see if this IE is absent
- SFN-SFN observed time difference	Check to see if this IE is absent
- Primary CPICH Info	
- Primary Scrambling Code	Check to see if it's the same code for cell 2
- CPICH Ec/No	Check to see if this IE is absent
- CPICH RSCP	Check value to see if this is below threshold value specified
- Pathloss	Check to see if this IE is absent
Event Results	
- Intra-frequency event identity	Check to see if this is set to event '1f'
- Cell measured event results	
- Primary CPICH Info	
- Primary scrambling code	Check to see if it's set to cell 2's assigned scrambling code

## MEASUREMENT CONTROL

Information Element	Value/Remark
---------------------	--------------

Measurement Identity Number	3
Measurement Command	Setup
Measurement Reporting Mode	Not Present
Additional measurements list	Not Present
CHOICE measurement type	Intra-frequency measurement
- Intra-frequency cell info list	
- Removed intra-frequency info list	Not Present
- New intra-frequency info list	
- Intra-frequency cell id	Set to id of cell 2
- Cell info	
- Cell individual offset	0 dB
- Reference time difference to cell	0 chips
- Primary CPICH Info	
- Primary Scrambling Code	Set to same code as used for cell 2
- Primary CPICH TX power	Not Present
- Read SFN Indicator	FALSE
- TX Diversity Indicator	FALSE
- Intra-frequency measurement quantity	
- Filter Coefficient	0
- Measurement quantity	CPICH RSCP
- Intra-frequency reporting quantity	
- Reporting quantities for active set cells	Same as in default message content
- SFN-SFN observed time difference	No report
- Cell identity	FALSE
- CPICH Ec/No	FALSE
- CPICH RSCP	FALSE
- Pathloss	FALSE
- CFN-SFN observed time difference	FALSE
- Reporting quantities for monitored set cells	
- SFN-SFN observed time difference	No report
- Cell identity	TRUE
- CPICH Ec/No	TRUE
- CPICH RSCP	FALSE
- Pathloss	FALSE
- CFN-SFN observed time difference	FALSE
- Reporting quantities for detected cells	Not present
- Reporting cell status	Not present
- Measurement validity	Not present
- CHOICE report criteria	Periodical reporting criteria
- Amount of reporting	Infinity
- Reporting interval	32 seconds
DPCH compressed mode status info	Not Present

## MEASUREMENT REPORT (Step 11)

Information Element	Value/Remarks
Measurement identity number	Check to see if set to 3
Measurement Results	
- CHOICE measurement	Check to see if set to "Intra-frequency measured results list"
- Intra-frequency measured results	
- Cell measured results	
- Cell Identity	Check to see if set to the id of cell 2
- CFN-SFN observed time difference	Check to see if this IE is absent
- SFN-SFN observed time difference	Check to see if this IE is absent
- Primary CPICH Info	
- Primary Scrambling Code	Check to see if it's the same code for cell 2
- CPICH Ec/No	Check to see if this IE is present
- CPICH RSCP	Check to see if this IE is absent
- Pathloss	Check to see if this IE is absent
Event Results	Check to see if this IE is absent

## 8.4.1.1.5 Test Requirement

After step 5 the UE shall start to transmit MEASUREMENT REPORT message. The measurement quantity "CPICH RSCP" shall be reported to the SS at 12 seconds interval.

After step 7 UE shall not transmit any MEASUREMENT REPORT messages within 12 seconds after SS has modified the MASTER INFORMATION BLOCK and SYSTEM INFORMATION BLOCK TYPE 12 messages.

The UE shall transmit a MEASUREMENT REPORT message roughly 35 seconds after step 7, to report that the RSCP value for cell 2 has dropped below the threshold.

After step 10 the UE shall transmit MEASUREMENT REPORT messages at 32 seconds interval, with the IE "Measurement Identity" set to 3. The message shall also include an estimation of cell 2's P-CPICH Ec/No value.

#### 8.4.1.2 Measurement Control and Report: Inter-frequency measurement for transition from idle mode to CELL\_DCH state

##### 8.4.1.2.1 Definition

##### 8.4.1.2.2 Conformance requirement

After entering CELL\_DCH state from idle mode, the UE shall discontinue the monitoring of the list of neighbouring cells assigned in the SYSTEM INFORMATION BLOCK TYPE 11 messages on BCCH.

##### Reference

3GPP TS 25.331 clause 8.4.1.9

##### 8.4.1.2.3 Test Purpose

To confirm that the UE terminates the monitoring activities of the list of neighbouring cell assigned in the IE "inter-frequency cell info" in SYSTEM INFORMATION BLOCK TYPE 11 messages, after it enters CELL\_DCH state from idle mode.

##### 8.4.1.2.4 Method of test

##### Initial Condition

System Simulator: 2 cells – Cell 1 is active and has a transmission level (CPICH RSCP) of –50 dBm for P-CPICH, cell 2 is also active but with a transmission power 20dB below cell 1. The carrier frequency of cell 1 in the uplink direction is 1 UARFCN above that of cell 2, and in the downlink direction cell 1 carrier is 1 UARFCN above that of cell 2.

UE : idle state and after it has camped onto cell 1.

##### Test Procedure

The UE is initially at idle mode and has selected cell 1 for camping. The SYSTEM BLOCK INFORMATION TYPE 12 message is modified with respect to the default settings to prevent reporting of CFN-SFN difference, and also to include cell 2 into the monitored neighbour cells list. The key measurement parameters are as follow: measurement type = "inter-frequency measurement", measurement quantity = "CPICH RSCP".

SS pages the UE, stating the paging cause as terminating call for one of the traffic classes supported by the UE. The UE shall transmit a RRC CONNECTION REQUEST message on the CCCH, SS replies with RRC CONNECTION SETUP message and allocates uplink and downlink dedicated physical resources to the UE. UE then moves to CELL\_DCH. The UE shall not transmit any MEASUREMENT REPORT messages, which pertain to measurement readings from cells belonging to the monitored set.

## Expected Sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	SYSTEM INFORMATION BLOCK TYPE 11	The UE is idle mode and camped onto cell 1. Cell 2 is also active but has transmission power 20dB below that of cell 1. SYSTEM INFORMATION BLOCK TYPE 11 to be transmitted is different from the default settings (see specific message contents)
2		←	PAGING TYPE 1	SS sends this message to page for the UE.
3		→	RRC CONNECTION REQUEST	
4			RRC CONNECTION SETUP	SS allocates dedicated physical channels to UE, using compressed mode format
5		→	RRC CONNECTION SETUP COMPLETE	UE transmits this message to acknowledge the RRC CONNECTION SETUP message and moves to CELL_DCH state.
6				SS raises the transmission power of cell 2 by 10dB. SS checks to see that no MEASUREMENT REPORT messages are sent from UE to cell 1.

## Specific Message Content

All messages indicated below shall use the same content as described in default message content, with the following exceptions:

## SYSTEM INFORMATION BLOCK TYPE 11

Information Element	Value/Remark
Reference to other system information blocks	Not Present
FACH measurement occasion info	Not Present
Measurement control system information	
- Intra-frequency measurement system information	Not Present
- Inter-frequency measurement system information	
- Inter-frequency measurement identity number	1
- Inter-frequency cell info list	
- Removed intra-frequency info list	Not Present
- New inter-frequency info list	
- Inter-frequency cell id	Set to id of cell 2
- Frequency info	
- UARFCN uplink (Nu)	Set to the next uplink UARFCN after cell 1
- UARFCN downlink (Nd)	Set to the previous downlink UARFCN before cell 1
- Cell info	
- Cell individual offset	0 dB
- Reference time difference to cell	0 chips
- Primary CPICH Info	
- Primary Scrambling Code	Set to same code as used for cell 2
- Primary CPICH TX power	Not Present
- Read SFN Indicator	FALSE
- TX Diversity Indicator	FALSE
- Cell selection and re-selection info for SIB 11/12	
- Qoffset <sub>s,n</sub>	0 dB
- Maximum allowed UL TX power	0 dBm
- HCS neighbouring cell information	Not Present
- Qqualmin, Qrxlevmin	-20 dB, -115dBm
- Inter-frequency measurement quantity	
CHOICE Reporting criteria	Inter-frequency reporting criteria
- Filter coefficient	0
- Measurement quantity for frequency quality estimate	CPICH RSCP
- Inter-frequency measurement reporting criteria	
- Parameters required for each event	
- Inter-frequency event identity	2c
- Threshold used frequency	Not Present
- W used frequency	Not Present
- Hysteresis	2.0dB
- Time to trigger	0 sec
- Amount of reporting	Infinity
- Reporting interval	0
- Parameters required for each non used frequency	Not Present
- Threshold non-used frequency	-65dBm
- W non-used frequency	0
- Inter-system measurement system information	Not Present
- Traffic volume measurement system information	Not Present
- UE internal measurement system information	Not Present

## RRC CONNECTION REQUEST

Information Element	Value/Remarks
Establishment cause	Check to see if set to Terminating call of a supported traffic class
Measured results on RACH	Check to see if this IE is absent

## RRC CONNECTION SETUP

Use the message sub-type found in TS 34.108 clause 9 which is marked as “Transition to CELL\_DCH”, with the following exceptions:

Information Element	Value/Remarks
Downlink information common for all radio links	
- Downlink DPCH info common for all RL	
- Downlink DPCH power control information	
- DPC mode	0 (Single)
- Spreading factor	Refer to the parameter set in TS 34.108
- Fixed or flexible position	Flexible
- TFCI existence	FALSE
- Number of bits for Pilot bits (SF=128, 256)	Not Present
- Downlink DPCH Offset Value	0
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	Active
- Transmission gap pattern sequence configuration parameters	
- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- TIP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	F/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRAfter1	1.0
- DeltaSIR2	Not Present
- TX Diversity Mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	

### 8.4.1.2.5 Test Requirement

After step 5 the UE shall not transmit any MEASUREMENT REPORT messages pertaining to the measurement of CPICH Ec/No quantity of cell 2.

## 8.4.1.3 Measurement Control and Report: Intra-frequency measurement for transition from idle mode to CELL\_FACH state

### 8.4.1.3.1 Definition

### 8.4.1.3.2 Conformance requirement

During a transition from idle mode to CELL\_FACH state, the UE shall start to monitor neighbouring cells listed in the IE “Intra-frequency cell info” received in SYSTEM INFORMATION BLOCK TYPE 11. If a measurement report criteria is also specified, the UE shall store this information and apply these rules when deciding to transmit MEASUREMENT REPORT messages during a subsequent transition to CELL\_DCH state. If reporting during RACH transmissions is dictated by the UTRAN, the UE shall append the relevant measurement information when sending messages on RACH (e.g. RRC CONNECTION REQUEST and CELL UPDATE).

## Reference

3GPP TS 25.331, clause 8.4.1.9

## 8.4.1.3.3 Test Purpose

To confirm that the UE begins to monitor the neighbouring cells in the monitored list after it has entered the CELL\_FACH state. The list of neighbouring cell can be known from SYSTEM INFORMATION BLOCK TYPE 11 messages. If information regarding the intra-frequency measurement reporting criteria is also broadcasted, the UE shall save this information and apply the criteria during a subsequent transition to CELL\_DCH state. If RACH measurement reporting is dictated in SYSTEM INFORMATION BLOCK TYPE 11 messages, the UE shall include these measurements when transmitting on the RACH channel.

## 8.4.1.3.4 Method of test

## Initial Condition

System Simulator : 2 cells – both cell 1 and cell 2 are active. Cell 2 is transmitting at 15 dB below cell 1.

UE : idle state and camped onto cell 1.

## Test Procedure

The UE is initially at idle mode and has selected cell 1 for camping. The SYSTEM BLOCK TYPE 12 message is modified with respect to the default settings to prevent reporting of CFN-SFN difference and also to include cell 2 into the monitored neighbour cell list. The key measurement parameters are as follow: measurement type = “intra-frequency measurement”, measurement quantity = “CPICH Ec/No”, report criteria = “periodic reporting criteria”, reporting interval = “12 seconds”. In the system information message, reporting of CPICH Ec/No is also required for intra-frequency reporting when transmitting RACH messages to cell 1.

SS pages the UE with the cause specified as terminating call of one of the traffic classes supported by the UE. The UE shall transmit a RRC CONNECTION REQUEST message on the CCCH, SS replies with RRC CONNECTION SETUP message and allocates PRACH and S-CCPCH (FACH) physical channels for uplink and downlink use. UE shall then enter CELL\_FACH state. SS waits until timer T305 expires, the UE shall send a CELL UPDATE message including the measurement reading of cell 2's CPICH Ec/No values. SS then reply with CELL UPDATE CONFIRM message without changing the physical channel resources.

In the next sequence, SS transmits PHYSICAL CHANNEL RECONFIGURATION message, and allocates DPDCH channels to the UE. The UE shall transit to CELL\_DCH state and send a MEASUREMENT REPORT message, correctly stating the measurement identity. The measurement identity indicated shall match the value that was previously broadcasted on SYSTEM INFORMATION BLOCK TYPE 11 when the UE was still in idle mode.

## Expected Sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	SYSTEM INFORMATION BLOCK TYPE 2, SYSTEM INFORMATION BLOCK TYPE 11	The UE is idle mode and camped onto cell 1. Cell 2 is also active but has transmission power 15dB below that of cell 1. SYSTEM INFORMATION TYPE 2 and 11 to be transmitted are different from the default settings (see specific message contents)
2		←	PAGING TYPE 1	SS sends this message to page for the UE.
3		→	RRC CONNECTION REQUEST	The Ec/No value of P-CPICH of Cell 1 should be reported.
4		←	RRC CONNECTION SETUP	SS allocates common physical channels to UE.



5	→	RRC CONNECTION COMPLETE	UE shall enter CELL_FACH state, and transmit this message to acknowledge the SETUP message.
6			SS waits for 5 minutes (for the expiry of T305 timer), so that UE will initiate a periodic cell updating procedure.
7	→	CELL UPDATE	This message shall contain measurement readings of CPICH Ec/No for cell 1.
8	←	CELL UPDATE CONFIRM	SS does not change the physical channel allocation.
9	←	PHYSICAL CHANNEL RECONFIGURATION	SS assigns DPCH physical resources to the UE, but keeps the parameters for transport channels and RBs unchanged.
10	→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	UE shall transit to CELL_DCH state after sending this message.
11	→	MEASUREMENT REPORT	UE shall begin to report cell 2's CPICH Ec/No value periodically at 12 seconds interval. The measurement identity shall match that broadcasted in step 1

## Specific Message Content

## SYSTEM INFORMATION BLOCK TYPE 2

Information Element	Value/Remarks
UE Timers and constants in connected mode - T305	5 minutes.

## SYSTEM INFORMATION BLOCK TYPE 11

Information Element	Value/Remark
Reference to other system information blocks	
FACH measurement occasion info	
Measurement control system information	
- Intra-frequency measurement system information	
- Intra-frequency measurement identity number	5
- Intra-frequency cell info list	
- Removed intra-frequency info list	Not Present
- New intra-frequency info list	
- Intra-frequency cell id	Set to id of cell 2
- Cell info	
- Cell individual offset	0 dB
- Reference time difference to cell	0 chips
- Primary CPICH Info	
- Primary Scrambling Code	Set to same code as used for cell 2
- Primary CPICH TX power	Not Present
- Read SFN Indicator	FALSE
- TX Diversity Indicator	FALSE
- Cell selection and Re-selection info for SIB11/12	
- Qoffset <sub>s,n</sub>	0 dB
- Maximum allowed UL TX power	0 dBm
- HCS neighbouring cell information	Not Present
- Qqualmin, Qrxlevmin	-20dB, -115dBm
- Intra-frequency Measurement quantity	
- Filter Coefficient	0
- Measurement quantity	CPICH Ec/No
- Intra-frequency measurement for RACH reporting	
- SFN-SFN observed time difference	No report
- Reporting quantity	CPICH Ec/No
- Maximum number of reported cells on RACH	Current cell
- Reporting information for state CELL_DCH	
- Intra-frequency reporting quantity	
- Reporting quantities for active set cells	No report
- SFN-SFN observed time difference	FALSE
- Cell identity	FALSE
- CPICH Ec/No	FALSE
- CPICH RSCP	FALSE
- Pathloss	FALSE
- CFN-SFN observed time difference	FALSE
- Reporting quantities for monitored set cells	
- SFN-SFN observed time difference	No report
- Cell identity	TRUE
- CPICH Ec/No	TRUE
- CPICH RSCP	FALSE
- Pathloss	FALSE
- CFN-SFN observed time difference	FALSE
- Reporting quantities for detected set cells	Not present
- CHOICE report criteria	Periodical reporting criteria
- Amount of reporting	Infinity
- Reporting interval	12 seconds
- Reporting Cell Status	Not Present
- Inter-frequency measurement system information	Not Present
- Traffic volume measurement system	Not Present

information - UE internal measurement system information	Not Present
---	-------------

## PAGING TYPE 1

Information Element	Value/Remarks
Paging record list - Paging Record - CHOICE Paging originator  - Paging cause - CN domain identity - CHOICE UE identity - IMSI (DS-41) or IMSI (GSM-MAP)	CN Originator Terminating Call for one of the supported traffic classes PS Domain IMSI (DS-41) or IMSI (GSM-MAP) Set to the same IMSI (DS-41) or IMSI (GSM-MAP) digits found in the test USIM.

## RRC CONNECTION REQUEST

Information Element	Value/Remarks
Initial UE Identity	Check to see if it is the same as in PAGING TYPE 1 message
Establishment cause	Check to see if set to terminating call of the compatible traffic classes supported by the UE
Measured results on RACH - Measured result for current cell - CHOICE measurement quantity - CPICH Ec/No - Measured results for monitored cells	Check to see if value is present Check to see if this IE is absent

## RRC CONNECTION SETUP

Use the same message sub-type found in Clause 9 of TS34.108, which is entitled "Transition to CELL\_FACH".

## CELL UPDATE

Information Element	Value/Remarks
U-RNTI	Check to see if set to same U-RNTI value assigned in RRC CONNECTION SETUP message.
Integrity check info	Not checked
AM_RLC error indicator (for C-plane)	Check to see if set to 'FALSE'
AM_RLC error indicator (for U-plane)	Check to see if set to 'FALSE'
Hyper frame number	Check to see if it is present
Cell update cause	Check to see if set to 'Periodic cell updating'
Protocol error indicator	Check to see if set to 'FALSE'
Measured results on RACH - Measurement result for current cell - CHOICE measurement quantity - CPICH Ec/No  - Measurement results for monitored cells	CPICH Ec/No Checked to see if set to within an acceptable range. Checked to see if this IE is not present.
Protocol error information	Check to see if set to 'FALSE'

## PHYSICAL CHANNEL RECONFIGURATION

Use the same message sub-type found in Clause 9 of TS34.108, which is entitled "Packet to CELL\_DCH from CELL\_FACH".

## MEASUREMENT REPORT

Information Element	Value/Remarks
Measurement identity number	Check to see if set to 5
Measurement Results	
- CHOICE measurement	Check to see if set to "Intra-frequency measured results list"
- Intra-frequency measured results	
- Cell measured results	
- Cell Identity	Check to see if set to the id of cell 2
- SFN-SFN observed time difference	Check to see if this IE is absent
- CFN-SFN observed time difference	Check to see if this IE is absent
- Primary CPICH Info	
- Primary Scrambling Code	Check to see if it's the same code for cell 2
- CPICH Ec/No	Check to see if this IE is within acceptable range
- CPICH RSCP	Check to see if this IE is absent
- Pathloss	Check to see if this IE is absent
Event Results	Check to see if this IE is absent

## 8.4.1.3.5 Test Requirement

After step 3 the UE shall send RRC CONNECTION REQUEST message in response to the paging message sent by the SS, which includes reading of the current cell's CPICH Ec/No value.

After step 5 the UE shall not transmit any MEASUREMENT REPORT messages.

After step 6 the UE shall initiate cell update procedure by transmitting CELL UPDATE message. In this message, the cause shall be set to "periodic cell updating". It shall include measurement readings for the current cell (cell 1) CPICH Ec/No measurement quantity.

After step 10 the UE shall move to CELL\_DCH state and transmit MEASUREMENT REPORT messages at 12 seconds interval. In these messages, neighbouring cell 2's CPICH Ec/No value shall be reported. The IE "measurement identity" in this message shall match the IE "Intra-frequency measurement identity" found in SYSTEM INFORMATION BLOCK TYPE 11 messages transmitted in step 1.

## 8.4.1.4 Measurement Control and Report: Inter-frequency measurement for transition from idle mode to CELL\_FACH state

## 8.4.1.4.1 Definition

## 8.4.1.4.2 Conformance requirement

After entering CELL\_FACH state from idle mode, the UE shall start to monitor the list of "inter-frequency" neighbouring cells assigned in the SYSTEM INFORMATION BLOCK TYPE 11 messages on BCCH/FACH.

## Reference

3GPP TS 25.331, clause 8.4.1.10

## 8.4.1.4.3 Test Purpose

To confirm that the UE begins to monitor the list of neighbouring cell assigned in the IE "inter-frequency cell info" in SYSTEM INFORMATION BLOCK TYPE 11 messages, after it enters CELL\_FACH state from idle mode. However, it shall not transmit any MEASUREMENT REPORT messages to report measured results for inter-frequency cells.

## 8.4.1.4.3 Method of test

## Initial Condition

System Simulator : 2 cells – Cell 1 is active and has a downlink transmission level for CPICH RSCP at -40 dBm, cell 2 is also active but with a transmission power 10dB below cell 1. The carrier frequency of cell 2 in the uplink direction is 1 UARFCN above that of cell 2, and the downlink carrier is 1 UARFCN below that of cell 1.

UE : idle state and has successfully camped onto cell 1.

## Test Procedure

The UE is initially at idle mode and has selected cell 1 for camping. The SYSTEM BLOCK TYPE 12 message is modified with respect to the default settings to prevent reporting of CFN-SFN difference and also to include cell 2 into the monitored neighbour cell list for inter-frequency measurement type. The key measurement parameters are as follow: measurement type = “inter-frequency measurement”, measurement quantity = “CPICH Ec/No”.

SS pages the UE with the cause set to terminating call of a supported traffic class. The UE shall transmit a RRC CONNECTION REQUEST message on the CCCH, SS replies with RRC CONNECTION SETUP message and allocates PRACH channel in the uplink and S-CCPCH(FACH) channel on the downlink to the UE. UE then moves to CELL\_FACH. The UE shall not transmit any MEASUREMENT REPORT messages, which pertain to measurement readings from inter-frequency cells belonging to the monitored set. SS decreases the transmission power of CPICH in cell 1 by 10dB. At the same time, it raises the corresponding downlink transmission power of cell 2 by 10dB. This is expected to trigger a cell reselection in the UE. The UE shall send CELL UPDATE message to report this event. Upon receiving this message, SS replies with the default CELL UPDATE CONFIRM message.

## Expected Sequence

Step	Direction		Message	Comment
	UE	SS		
1		←	SYSTEM INFORMATION BLOCK TYPE 11	The UE is idle mode and camped onto cell 1. Cell 2 is also active but has transmission power 10dB below that of cell 1. SYSTEM INFORMATION TYPE 11 to be transmitted is different from the default settings (see specific message contents)
2		←	PAGING TYPE 1	SS sends this message to page for the UE.
3		→	RRC CONNECTION REQUEST	
4		←	RRC CONNECTION SETUP	SS allocates PRACH and S-CCPCH resources to UE
5		→	RRC CONNECTION COMPLETE	UE transmits this message to acknowledge the SETUP message and moves to CELL_FACH state.
6				SS checks to see that no MEASUREMENT REPORT messages are sent from UE to cell 1.
7				SS decreases the transmission power of cell 1 by 10dB and increases cell 2's downlink power by 10dB.
8		→	CELL UPDATE	UE shall detect that cell 2 has become stronger than cell 1. It sends this message after reselecting to cell 2

9	←	CELL UPDATE CONFIRM	Use default message.
---	---	---------------------	----------------------

Specific Message Content

All messages indicated below shall use the same content as described in default message content, with the following exceptions:

## SYSTEM INFORMATION BLOCK TYPE 11

clauseInformation Element	Value/Remark
Reference to other system information blocks	Not Present
FACH measurement occasion info	
- k_UTRA	2
- Other RAT present in inter-system cell info	Not Present
Measurement control system information	
- Intra-frequency measurement system information	Not Present
- Inter-frequency measurement system information	Not Present
- Inter-frequency measurement identity number	1
- Inter-frequency cell info list	
- Removed intra-frequency info list	Not Present
- New inter-frequency info list	
- Inter-frequency cell id	Set to id of cell 2
- Frequency info	
- UARFCN uplink (Nu)	Set to the next uplink UARFCN after cell 1
- UARFCN downlink (Nd)	Set to the previous downlink UARFCN before cell 1
- Cell info	
- Cell individual offset	0 dB
- Reference time difference to cell	0 chips
- Primary CPICH Info	
- Primary Scrambling Code	Set to same code as used for cell 2
- Primary CPICH TX power	Not Present
- Read SFN Indicator	FALSE
- TX Diversity Indicator	FALSE
- Cell selection and re-selection info for SIB 11/12	
- Qoffset <sub>s,n</sub>	0 dB
- Maximum allowed UL TX power	0 dBm
- HCS neighbouring cell information	Not Present
- Qqualmin, Qrxlevmin	-20dB, -115dBm
- Inter-frequency measurement quantity	
CHOICE Reporting criteria	Inter-frequency reporting criteria
- Filter coefficient	0
- Measurement quantity for frequency quality estimate	CPICH Ec/No
- Inter-frequency measurement reporting criteria	
- Parameters required for each event	
- Inter-frequency event identity	2c
- Threshold used frequency	Not Present
- W used frequency	
- Hysteresis	2.0dB
- Time to trigger	0 sec
- Amount of reporting	Infinity
- Reporting interval	0
- Parameters required for each non used frequency	Not Present
- Threshold non-used frequency	-55dBm
- W non-used frequency	0
- Inter-system measurement system information	Not Present
- Traffic volume measurement system information	Not Present
- UE internal measurement system information	Not Present

## PAGING TYPE 1

For this message, use the same message contents as in step 2 of clause 8. 4.1.3.3.

RRC CONNECTION REQUEST

Information Element	Value/Remarks
Establishment cause	Check to see if set to terminating call of the compatible traffic class supported by the UE
Measured results on RACH	Check to see if this IE is absent



## RRC CONNECTION SETUP

Use the message sub-type in default message content defined in TS 34.108 Clause 8, which is marked as “Transition to CELL\_FACH”.

## CELL UPDATE

Information Element	Value/Remarks
U-RNTI	Check to see if same to value as in PAGING TYPE 1 message
Integrity check info	Check to see if it is absent
AM_RLC error indication (for C-plane)	Check to see if it is set to FALSE
AM_RLC error indication (for U-plane)	Check to see if it is set to FALSE
Hyper frame number	Check to see if it is present
Cell update cause	Check to see if it is set to “Cell Reselection”
Protocol error info	Check to see if it is absent or set to FALSE
Measured results on RACH	Check to see if it is absent
Protocol error information	Check to see if it is absent

## CELL UPDATE CONFIRM

Use the message sub-type in default message content defined in TS 34.108 Clause 8.

### 8.4.1.4.5 Test Requirement

After step 5 the UE shall not transmit any MEASUREMENT REPORT messages pertaining to the measurement of CPICH Ec/No quantity for cell 2.

After step 7 the UE shall reselect to cell 2 and transmit a CELL UPDATE message on the uplink CCCH of cell 2.

### 8.4.1.5 Measurement Control and Report: Intra-frequency measurement for transition from CELL\_DCH to CELL\_FACH state

#### 8.4.1.5.1 Definition

#### 8.4.1.5.2 Conformance requirement

After entering CELL\_FACH state from CELL\_DCH state, the UE shall terminate intra-frequency type measurement reporting originating from a previous MEASUREMENT CONTROL message. If indicated in the system information messages, the UE shall start to monitor neighbouring cells. The UE shall apply the reporting criteria specified in system information during a subsequent return to CELL\_DCH state. If requested to perform measurement reporting on RACH channels, the UE shall append the measured results when transmitting uplink RACH messages.

#### Reference

3GPP TS 25.331, clause 8.4.1.7

#### 8.4.1.5.3 Test Purpose

To confirm that the UE ceases to perform intra-frequency measurement specified in a previously received MEASUREMENT CONTROL message, when it moves from CELL\_DCH state to CELL\_FACH state. To confirm that the UE read the system information when in CELL\_FACH state and starts to monitor the neighbouring cells as indicated in system information messages. To confirm that the UE performs measurements on uplink RACH channel and append the measured results in RACH messages, when requested in the system information messages.

#### 8.4.1.5.4 Method of test

##### Initial Condition

System Simulator: 3 cells – Cell 1 and cell 2 are active, but the transmitter of cell 3 is switched off. Cell 1 is transmitting its CPICH (RSCP) at 20 dB above cell 2. The downlink UTRA carriers transmission strength for cell 1 is identical to that of cell 2.

UE: idle state and camped onto cell 1.

##### Test Procedure

The UE is initially in idle mode and has selected cell 1 as the current cell. SYSTEM INFORMATION BLOCK TYPE 12 message is modified from its default message contents, in order to prevent the reporting of CFN-SFN difference. No measurement requirements are specified for the UE in system information block (type 11 and 12) messages.

SS then prompts the test operator to initiate an outgoing call. When UE transmits a RRC CONNECTION REQUEST message on RACH, SS replies with RRC CONNECTION SETUP message. Uplink and downlink DPDCH physical channels are allocated. Upon receiving RRC CONNECTION SETUP message, the UE shall transmit RRC CONNECTION SETUP COMPLETE message on DCCH and then moves to CELL\_DCH state. SS then sends a MEASUREMENT CONTROL message to UE. In this message, the SS requests the establishment of an intra-frequency measurement, based on an estimation of cell 2's CPICH Ec/No. At the same time, reporting of cell 2's CPICH is commanded with the reporting criteria set to "periodic reporting" and reporting interval set to 16 seconds. The UE shall start transmitting MEASUREMENT REPORT messages at 16 seconds interval corresponding to the requested reporting event.

SS transmits PHYSICAL CHANNEL RECONFIGURATION message, triggering a switch of transport channels from DCH/DCH to RACH/FACH. After receiving this message, the UE shall reconfigure itself and replies with PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on RACH. SS acknowledges this message and the UE shall move to CELL\_FACH state and read the system information messages. SS monitors the uplink to verify that no MEASUREMENT REPORT messages are received. In SYSTEM INFORMATION BLOCK TYPE 12 message, SS includes cell 3 into the neighbour cells monitoring list. IE "Intra-frequency reporting quantity for RACH Reporting" and IE "Maximum number of Reported cells on RACH" are also specified in this message. An event-triggered (event type 1a) reporting criterion is specified for intra-frequency measurements. The transmission strength of CPICH for cell 3 is increased until it exceeds the lower bound of the reporting range specified. SS then pages for the UE using PAGING TYPE 1 message. The UE shall respond with a CELL UPDATE message, which comprises CPICH Ec/No measurements for cell 1 and 3. Upon the receipt of CELL UPDATE message, SS replies with CELL UPDATE CONFIRM message. This message does not change the physical resource nor allocate any new RNTI identities. The UE shall remain in CELL\_FACH state. SS transmits PHYSICAL CHANNEL RECONFIGURATION message again, this time specifying dedicated physical resources for both uplink and downlink direction. The UE shall then send PHYSICAL CHANNEL RECONFIGURATION COMPLETE message and return to CELL\_DCH state. SS listens to the uplink DCCH for MEASUREMENT REPORT messages. SS verifies that all messages received pertain to the periodic measured value of cell 2's CPICH Ec/No value. UE shall not send any reports containing the measured values of cell 3.

## Expected Sequence

Step	Direction		Message	Comment
	UE	SS		
1				UE is initially in idle mode and test operator is asked to make an outgoing call.
2		→	RRC CONNECTION REQUEST	
3		←	RRC CONNECTION SETUP	Uplink and downlink DPCH resources are allocated.
4		→	RRC CONNECTION SETUP COMPLETE	UE shall move to CELL_DCH state.
5		←	MEASUREMENT CONTROL	SS requests for measurement and reporting of cell 2's CPICH Ec/No value.
6		→	MEASUREMENT REPORT	UE shall send periodic report at 16 seconds interval. SS waits for 2 consecutive reports before proceeding to step 7.
7		←	PHYSICAL CHANNEL RECONFIGURATION	SS switches the physical resources to common physical channels.
8		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	UE shall reconfigure its uplink and downlink channels before transiting to CELL_FACH state.
9		←	SYSTEM INFORMATION BLOCK TYPE 12	SS includes cell 3 into the monitored neighbour cell list. SS waits for 1 minutes and verifies that no MEASUREMENT REPORT messages are received. Cell 3 is switched on, and SS adjusts the transmission power for CPICH such that its Ec/No falls into the report range specified.
10		←	PAGING TYPE 1	SS pages for UE using the assigned U-RNTI identity.
11		→	CELL UPDATE	UE shall transmit this message with measured results on RACH channels for cell 1 and 3 appended.
12		←	CELL UPDATE CONFIRM	No change in physical resource allocation and RNTI identities.
13		←	PHYSICAL CHANNEL RECONFIGURATION	Allocates dedicated physical channels.
14		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	UE shall transit to CELL_DCH state.
15		←	MEASUREMENT REPORT	UE shall continue to report cell 2's CPICH Ec/No value on a periodic basis.

## Specific Message Content

## SYSTEM INFORMATION BLOCK TYPE 12

Information Element	Value/Remark
---------------------	--------------

Reference to other system information blocks	Not Present
FACH measurement occasion info	Not Present
Measurement control system information	
- Intra-frequency measurement system information	Not Present
- Inter-frequency measurement system information	Not Present
- Inter-system measurement system information	Not Present
- Traffic volume measurement system information	Not Present
- UE internal measurement system information	Not Present

RRC CONNECTION SETUP

Use the same message sub-type found in Clause 8.1 of TS34.108, which is entitled “Transition to CELL\_DCH”.

## MEASUREMENT CONTROL

Information Element	Value/Remark
Measurement Identity Number	5
Measurement Command	Setup
Measurement Reporting Mode	Not Present
Additional measurements list	Not Present
CHOICE measurement type	Intra-frequency measurement
- Intra-frequency cell info list	
- Removed intra-frequency info list	Not Present
- New intra-frequency info list	
- Intra-frequency cell id	Set to id of cell 2
- Cell info	
- Cell individual offset	0 dB
- Reference time difference to cell	0 chips
- Primary CPICH Info	
- Primary Scrambling Code	Set to same code as used for cell 2
- Primary CPICH TX power	Not Present
- Read SFN Indicator	FALSE
- TX Diversity Indicator	FALSE
- Intra-frequency measurement quantity	
- Filter Coefficient	0
- Measurement quantity	CPICH Ec/No
- Intra-frequency reporting quantity	
- Reporting quantities for active set cells	
- SFN-SFN observed time difference	No report
- Cell identity	TRUE
- CPICH Ec/No	TRUE
- CPICH RSCP	FALSE
- Pathloss	FALSE
- CFN-SFN observed time difference	FALSE
- Reporting quantities for monitored set cells	
- SFN-SFN observed time difference	No report
- Cell identity	TRUE
- CPICH Ec/No	TRUE
- CPICH RSCP	FALSE
- Pathloss	FALSE
- CFN-SFN observed time difference	FALSE
- Reporting quantities for detected cells	Not present
- Reporting cell status	Not present
- Measurement validity	Not present
- CHOICE report criteria	Periodical reporting criteria
- Amount of reporting	Infinity
- Reporting interval	16 seconds
DPCH compressed mode status info	Not Present

## MEASUREMENT REPORT (Step 6)

Information Element	Value/Remarks
Measurement identity number	Check to see if set to 5
Measurement Results	
- CHOICE measurement	Check to see if set to "Intra-frequency measured results list"
- Intra-frequency measured results	
- Cell measured results	
- Cell Identity	Check to see if set to the id of cell 2
- SFN-SFN observed time difference	Check to see if this IE is absent
- CFN-SFN observed time difference	Check to see if this IE is absent
- Primary CPICH Info	
- Primary Scrambling Code	Check to see if it's the same code for cell 2
- CPICH Ec/No	Check to see if this IE is present
- CPICH RSCP	Check to see if this IE is absent
- Pathloss	Check to see if this IE is absent
Event results	Check to see if this IE is absent

## PHYSICAL CHANNEL RECONFIGURATION (Step 7)

Use the same message sub-type found in Clause 8.1 of TS34.108, which is entitled “Packet to CELL\_FACH from CELL\_DCH in PS )”

## SYSTEM INFORMATION BLOCK TYPE 12

Information Element	Value/Remark
Reference to other system information blocks	Not Present
FACH measurement occasion info	Not Present
Measurement control system information	
- Intra-frequency measurement system information	
- Intra-frequency measurement identity number	6
- Intra-frequency cell info list	
- Removed intra-frequency info list	Not Present
- New intra-frequency info list	
- Intra-frequency cell id	Set to id of cell 3
- Cell info	
- Cell individual offset	0 dB
- Reference time difference to cell	0 chips
- Primary CPICH Info	
- Primary Scrambling Code	Set to same code as used for cell 3
- Primary CPICH TX power	Not Present
- Read SFN Indicator	FALSE
- TX Diversity Indicator	FALSE
- Cell selection and Re-selection info for SIB11/12	
- Qoffset <sub>s,n</sub>	0dB
- Maximum allowed UL TX power	0dBm
- HCS neighbouring cell information	Not Present
- Qqualmin, Qrxlevmin	-20dB, -115dBm
- Intra-frequency measurement quantity	
- Filter Coefficient	0
- Measurement quantity	CPICH Ec/No
- Intra-frequency measurement for RACH reporting	
- SFN-SFN observed time difference	No report
- Reporting quantity	CPICH Ec/No
- Maximum number of reported cells on RACH	Current cell + best neighbour
- Reporting information for state CELL_DCH	
- Intra-frequency reporting quantity	
- Reporting quantities for active set cells	
- SFN-SFN observed time difference	No report
- Cell identity	TRUE
- CPICH Ec/No	TRUE
- CPICH RSCP	FALSE
- Pathloss	FALSE
- CFN-SFN observed time difference	FALSE
- Reporting quantities for monitored set cells	
- SFN-SFN observed time difference	No report
- Cell identity	TRUE
- CPICH Ec/No	TRUE
- CPICH RSCP	FALSE
- Pathloss	FALSE
- CFN-SFN observed time difference	FALSE
- Reporting quantities for detected cells	Not present
- CHOICE report criteria	Intra-frequency measurement reporting criteria
- Parameter required for each event	Only 1 reporting event is defined
- Intra-frequency event identity	1a
- Triggering condition	Monitored set cells
- Reporting range	10.0 dB
- Cells forbidden to affect reporting	Not present
- W	0.0
- Hysteresis	1.0 dB
- Threshold used frequency	Not Present
- Reporting deactivation threshold	7
- Replacement activation threshold	Not Present
- Time to trigger	0
- Amount of reporting	Infinity
- Reporting Interval	8 seconds
- Inter-frequency measurement system	Not present

information	
- Inter-system measurement system information	Not present
- Traffic volume measurement system information	Not present
- UE internal measurement system information	Not present

## PAGING TYPE 1

Information Element	Value/Remarks
Page Record List	
- Page Record	
- CHOICE Paging originator	UTRAN Originator
- U-RNTI	Set to same U-RNTI value as assigned in the RRC CONNECTION SETUP message
BCCH modification info	Not Present

## CELL UPDATE

Information Element	Value/Remarks
U-RNTI	Check to see if same to value as in PAGING TYPE 1 message
Integrity check info	Check to see if it is absent
AM_RLC error indication (for C-plane)	Check to see if it is set to FALSE
AM_RLC error indication (for U-plane)	Check to see if it is set to FALSE
Hyper frame number	Check to see if it is present
Cell update cause	Check to see if it is set to "Paging Response"
Protocol error info	Check to see if it is absent or set to FALSE
Measured results on RACH	
- Measurement result for current cell	
- CHOICE measurement quantity	Check to see if set to CPICH Ec/No
- CPICH Ec/No	Check to see if it is within acceptable range
- Measurement results for monitored cells	
- SFN-SFN observed time difference	Not Checked
- Primary CPICH info	
- Primary scrambling code	Check to see if the same as cell 3's code.
- CHOICE measurement quantity	Check to see if set to CPICH Ec/No
- CPICH Ec/No	Check to see if it is within acceptable range
Protocol error information	Check to see if it is absent

## PHYSICAL CHANNEL RECONFIGURATION (Step 13)

Use the same message sub-type found in Clause 8.1 of TS34.108, which is entitled "Packet to CELL\_DCH from CELL\_FACH in PS )"

## MEASUREMENT REPORT (Step 15)

The contents of this message should be the same as in step 6.

## 8.4.1.5.5 Test Requirement

After step 5, the UE shall start to transmit MEASUREMENT REPORT messages at 16 seconds interval. The message shall contain the measured result of cell 2's CPICH Ec/No value.

After step 8, the UE shall not send any MEASUREMENT REPORT messages which report quantities requested in MEASUREMENT CONTROL messages in step 5.

After step 10, the UE shall respond to the paging and transmit a CELL UPDATE message. In this message, the measured values CPICH Ec/No for cell 1 and cell 3 shall be included.

After step 14, the UE shall revert to the original measurement reporting mechanism and send MEASUREMENT REPORT messages containing estimates for cell 2's CPICH Ec/No value. The UE shall not transmit any MEASUREMENT REPORT messages, which indicate measurement quantities of cell 3.



#### 8.4.1.6 Measurement Control and Report: Inter-frequency measurement for transition from CELL\_DCH to CELL\_FACH state

##### 8.4.1.6.1 Definition

##### 8.4.1.6.2 Conformance requirement

When transiting from CELL\_DCH state to CELL\_FACH state, the UE shall terminate all reporting activities related to inter-frequency measurements. After reaching CELL\_FACH state, the UE shall begin to monitor neighbouring cells listed in the IE "inter-frequency cell info" of the system information type 12 message.

##### Reference

3GPP TS 25.331, clause 8.4.1.7

##### 8.4.1.6.3 Test Purpose

To verify that UE ceases to transmit MEASUREMENT REPORT messages when moving from CELL\_DCH state to CELL\_FACH, even if it has detected that reporting criteria have been satisfied in CELL\_FACH state. To verify that the UE extracts information for inter-frequency measurement from system information messages after reaching CELL\_FACH state.

##### 8.4.1.6.4 Method of test

##### Initial Condition

SS: 2 cells – Both cell 1 and cell 2 are active. Cell 2 is allocated a frequency which is 1 UARFCN away from cell 1 in both uplink and downlink directions. The applicable radio conditions for cell 1 and cell 2 are as follow:

	Cell 1	Cell 2
UARFCN ( $N_u$ and $N_d$ )	Channel 1	Channel 2
CPICH RSCP	-75 dBm	-85 dBm
$Q_{rxlevmin}$	-90 dBm	-90 dBm
S	15	5

UE: idle state and camped onto cell 1.

##### Test Procedure

The UE is initially in idle mode. SS pages the UE with the cause set to terminating call for one of the supported traffic classes. The SYSTEM INFORMATION TYPE 12 message is modified so that no measurement tasks are to be performed by the UE. The UE shall respond to the paging by sending a RRC CONNECTION REQUEST message on the uplink CCCH carried by RACH. Upon receiving this message, SS allocates dedicated DPCH physical channels to the UE by transmitting RRC CONNECTION SETUP message. The UE shall reply by transmitting a RRC CONNECTION SETUP COMPLETE message. SS then checks the IE "Measurement Capability" of this message and verifies that the UE is capable of performing inter-frequency measurements under FDD mode. After the confirmation of the UE inter-frequency measurement ability, SS transmits PHYSICAL CHANNEL RECONFIGURATION message. In this message, information related to the radio bearers and uplink/downlink radio resources remain unchanged as compared to the equivalent IEs found in RRC CONNECTION SETUP message. The only difference concerns IE "DPCH compressed mode info", which indicates that the UE shall apply the given parameters for compressed mode operations. The UE shall return PHYSICAL CHANNEL RECONFIGURATION COMPLETE message to acknowledge that compressed mode mechanism can be exercised.

SS then sends a MEASUREMENT CONTROL message to the UE, specifying that cell 2 be the measurement object for inter-frequency type measurement. The periodic reporting criterion is selected for this measurement. SS waits for 8 seconds to allow the periodic timer to expire. The UE shall send a MEASUREMENT REPORT message containing

measured result of cell 2's reporting quantity (CPICH Ec/No). SS transmits PHYSICAL CHANNEL RECONFIGURATION message again, requesting the UE to switch from uplink and downlink DPCH to common physical channels. The UE shall return PHYSICAL CHANNEL RECONFIGURATION COMPLETE message and then move to CELL\_FACH state. SS waits for another 8 seconds to detect any possible uplink MEASUREMENT REPORT messages as a result of inter-frequency measurements. SS then increases the transmission power of cell 2 by 20 dB. SS waits for [x] seconds to allow the UE to perform cell re-selection. The UE shall transmit a CELL UPDATE message on the uplink CCCH of cell 2, specifying the cause as "cell re-selection". SS replies with CELL UPDATE CONFIRM message.

#### Expected Sequence

Step	Direction		Message	Comment
	UE	SS		
1				UE is initially in idle mode and camped onto cell 1. SYSTEM INFORMATION BLOCK TYPE 12 is redefined, disabling all measurement and reporting activities.
2		←	PAGING TYPE 1	SS pages UE with cause set terminating call for a supported traffic class
3		→	RRC CONNECTION REQUEST	
4		←	RRC CONNECTION SETUP	Uplink and downlink DPCH resources are allocated.
5		→	RRC CONNECTION SETUP COMPLETE	UE shall indicate that it's capable of performing inter-frequency measurement for FDD mode.
6		←	PHYSICAL CHANNEL RECONFIGURATION	SS instructs UE to begin compressed mode operation.
7		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	UE shall enter CELL_DCH state.
8		←	MEASUREMENT CONTROL	SS indicates that cell 2 be monitored. SS waits for 8 seconds.
9		→	MEASUREMENT REPORT	UE shall transmit this message to report cell 2's CPICH Ec/No value.
10		←	PHYSICAL CHANNEL RECONFIGURATION	SS changes the physical channel allocation to common channel configuration.
11		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	UE shall move to CELL_FACH state.
12				SS waits for 8 seconds to verify that no MEASUREMENT REPORT messages are detected.
13				SS changes SYSTEM INFORMATION BLOCK TYPE 12 message to request cell 2 to be included into neighbour cell list for inter-frequency measurements.
14				SS increases the transmission power of cell 2 by 20 dB, and then waits for [x] seconds to allow the UE to re-select to a new cell.
15		→	CELL UPDATE	UE shall detect that cell 2 has become the best cell and then perform cell re-selection procedure.
16		←	CELL UPDATE CONFIRM	

Notes:

The value [x] seconds is TBD, after the cell re-selection duration is determined from TS 25.304.

## Specific Message Content

### SYSTEM INFORMATION BLOCK TYPE 12

Information Element	Value/Remark
References to other system information blocks	Not Present
FACH measurement occasion info	
- k_UTRA	2
- Other RAT present in inter-system cell info	Not Present
Measurement control system information	
- Intra-frequency measurement system information	Not Present
- Inter-frequency measurement system information	Not Present
- Inter-system measurement system information	Not Present
- Traffic volume measurement system information	Not Present
- UE Internal measurement system information	Not Present

### PAGING TYPE 1

Information Element	Value/Remarks
Paging Record List	
- Paging Record	
- CHOICE Paging originator	CN Originator
- Paging cause	Terminating call for one of the supported traffic classes
- CN domain identity	CS Domain
- CHOICE UE Identity	IMSI (DS-41) or IMSI(GSM-MAP)
- IMSI (DS-41) or IMSI(GSM-MAP)	Set to the same digits as in USIM card
BCCH modification info	Not Present

### RRC CONNECTION SETUP

Use the same message sub-type found in Clause 9 of TS34.108, which is entitled "Transition to CELL\_DCH"

## RRC CONNECTION SETUP COMPLETE

Information Element	Value/Remarks
START List	
- CN Domain Identity	Check to see if it is present for all supported CN domains
- START	Check to see if it is present for all supported CN domains
UE Radio access capability	
- ICS Version	Checked to see if set to 'R99'
- PDCP capability	Not checked.
- RLC capability	Not checked.
- Transport channel capability	Not checked.
- RF capability	Not checked.
- Physical channel capability	Not checked.
- UE multi-mode/multi-RAT capability	Not checked.
- Security capability	Not checked.
- LCS capability	Not checked.
- Measurement capability	
- FDD measurements DL	Checked to see if set to 'TRUE'
- TDD measurements DL	Not checked.
- GSM measurements DL	Not checked.
- GSM 900 DL	Not checked.
- DCS 1800 DL	Not checked.
- GSM 1900 DL	Not checked.
- Multi-carrier measurement DL	Not checked.
- FDD measurements UL	Checked to see if set to 'TRUE'
- TDD measurements UL	Not checked.
- GSM measurements UL	Not checked.
- GSM 900 UL	Not checked.
- DCS 1800 UL	Not checked.
- GSM 1900 UL	Not checked.
- Multi-carrier measurement UL	Not checked.
UE system specific capability	Not checked.

## PHYSICAL CHANNEL RECONFIGURATION (Step 6)

Use the same message sub-type found in Clause 9 of TS34.108, which is entitled "( Packet to CELL\_DCH from CELL\_DCH in PS", with the following exceptions in the IE(s) concerned:

Information Element	Value/Remarks
Downlink information common for all radio links	
- Downlink DPCH info common for all RL	
- Downlink DPCH power control information	
- DPC mode	0 (Single)
- Spreading factor	Refer to the parameter set in TS 34.108
- Fixed or flexible position	Flexible
- TFCI existence	FALSE
- Number of bits for Pilot bits (SF=128, 256)	Not Present
- Downlink DPCH Offset Value	0
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	Active
- Transmission gap pattern sequence configuration parameters	
- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	F/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRAfter1	1.0
- DeltaSIR2	Not Present
- TX Diversity Mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	

## MEASUREMENT CONTROL (Step 8)

Information Element	Value/Remark
---------------------	--------------

Measurement Identity Number	15
Measurement Command	Setup
Measurement Reporting Mode	Not Present
Additional measurements list	Not Present
CHOICE measurement type	Inter-frequency measurement
- Inter-frequency cell info list	
- Removed inter-frequency info list	Not Present
- New inter-frequency info list	
- Inter-frequency cell id	Set to id of cell 2
- Frequency info	
- UARFCN uplink (Nu)	UARFCN of the uplink frequency for cell 2
- UARFCN downlink (Nd)	UARFCN of the downlink frequency for cell 2
- Cell info	
- Cell individual offset	0 dB
- Reference time difference to cell	0 chips
- Primary CPICH Info	
- Primary Scrambling Code	Set to same code as used for cell 2
- Primary CPICH TX power	Not Present
- Read SFN Indicator	FALSE
- TX Diversity Indicator	FALSE
- Inter-frequency measurement quantity	
- CHOICE reporting criteria	Inter-frequency reporting criteria
- Filter Coefficient	0
- Measurement quantity for frequency quality estimate	CPICH Ec/No
- Inter-frequency reporting quantity	
- UTRA Carrier RSSI	FALSE
- Frequency quality estimate	TRUE
- Non frequency related cell reporting quantities	
- SFN-SFN observed time difference	No report
- Cell Identity	FALSE
- CPICH Ec/No	FALSE
- CPICH RSCP	FALSE
- Pathloss	FALSE
- CFN-SFN observed time difference	FALSE
- Reporting cell status	Not present
- Measurement validity	Not present
- Inter-frequency set update	Not present
- CHOICE report criteria	Periodic reporting criteria
- Amount of reporting	Infinity
- Reporting interval	8 seconds
DPCH compressed mode status info	Not Present

## MEASUREMENT REPORT (Step 9)

Information Element	Value/Remarks
---------------------	---------------

Measurement identity number	Check to see if set to 15
Measurement Results	
- CHOICE measurement	Check to see if set to "Inter-frequency measured results list"
- Inter-frequency measurement results	
- Frequency info	
- UARFCN (uplink)	Check to see if set to the UARFCN of the uplink frequency for cell 2
- UARFCN (downlink)	Check to see if set to the UARFCN of the downlink frequency for cell 2
- UTRA carrier RSSI	Check to see if it is absent
- Inter-frequency cell measurement results	
- Cell measured results	
- Cell Identity	Check to see if set to the id of cell 2
- SFN-SFN observed time difference	Check to see if it is absent
- CFN-SFN observed time difference	Check to see if it is absent
- Primary CPICH Info	
- Primary Scrambling Code	Check to see if set to the same code for cell 2
- CPICH Ec/No	Check to see if it is present
- CPICH RSCP	Check to see if it is absent
- Pathloss	Check to see if it is absent
Event Results	Check to see if it is absent

### PHYSICAL CHANNEL RECONFIGURATION (Step 10)

Use the same message sub-type found in Clause 9 of TS34.108, which is entitled "(Packet to CELL\_FACH from CELL\_DCH in PS)".

### CELL UPDATE

Information Element	Value/Remarks
U-RNTI	Check to see if same to value as in RRC CONNECTION SETUP message
Integrity check info	Check to see if it is absent
AM_RLC error indication (for C-plane)	Check to see if it is set to FALSE
AM_RLC error indication (for U-plane)	Check to see if it is set to FALSE
Hyper frame number	Check to see if it is present
Cell update cause	Check to see if it is set to "Cell Reselection"
Protocol error info	Check to see if it is absent or set to FALSE
Measured results on RACH	Check to see if it is absent
Protocol error information	Check to see if it is absent

### CELL UPDATE CONFIRM

Use the same message sub-type found in Clause 9 of TS34.108.

#### 8.4.1.6.5 Test Requirement

After step 4 the UE shall transmit RRC CONNECTION SETUP COMPLETE message with the IE "Measurement capability", indicating that both uplink and downlink inter-frequency measurements for FDD mode are supported.

After step 8 the UE shall transmit MEASUREMENT REPORT message to report cell 2's CPICH Ec/No value.

After step 11 the UE shall stop sending MEASUREMENT REPORT messages, which contain inter-frequency measured results for cell 2's CPICH Ec/No value.

After step 14 the UE shall transmit CELL UPDATE message to inform that a cell reselection to cell 2 has occurred.

#### 8.4.1.7 Measurement Control and Report: Intra-frequency measurement for transition from CELL\_FACH to CELL\_DCH state

##### 8.4.1.7.1 Definition

##### 8.4.1.7.2 Conformance requirement

When transiting from CELL\_FACH state to CELL\_DCH state, the UE shall resume intra-frequency measurement if it has previously stored such a measurement context in CELL\_DCH state. If the measurement context indicates reporting in CELL\_DCH state, the UE shall re-start the associated reporting activities. In the case when the UE is not assigned any measurement tasks, it shall monitor the list of neighbouring cells stated in system information messages. It shall transmit MEASUREMENT REPORT messages when the reporting criteria (if specified in system information messages) are met. When in CELL\_DCH state, the UE shall override existing measurement and reporting contexts extracted from system information messages, if a MEASUREMENT CONTROL message is received. The UE shall then apply the new measurement and reporting parameters accordingly. If the UE has performed a cell reselection whilst out of CELL\_DCH state, the UE shall not re-start intra-frequency measurement previously designated to be resumed in CELL\_DCH state.

##### Reference

3GPP TS 25.331, clause 8.4.1.8

##### 8.4.1.7.3 Test Purpose

To confirm that UE resumes intra-frequency measurement and reporting when it enters CELL\_DCH state from CELL\_FACH state, if such a condition exists before entering CELL\_DCH state. To confirm that the UE continues to monitor the neighbour cells intra-frequency measurement list found in system information messages, if no previous assigned measurement is present. To confirm that the UE transmits MEASUREMENT REPORT messages if reporting conditions stated in system information messages have been satisfied. To confirm that a subsequent MEASUREMENT CONTROL message received in CELL\_DCH state

##### 8.4.1.7.4 Method of test

##### Initial Condition

System Simulator: 3 cells –All 3 are all active. The transmission power (RSCP) for CPICH of the 3 cells are as follow: cell 1 (-40dBm), cell 2 (-55dBm) and cell 3 (-70dBm).

UE: CELL\_FACH in cell 1.

##### Test Procedure

The UE is brought to CELL\_FACH state, after the test operator has successfully initiated a packet-switched data call. The SYSTEM INFORMATION BLOCK TYPE 12 message is changed with respect to the default message contents, specifying that cell 2 is to be included in the neighbouring cell list for intra-frequency measurement. Event 1e is selected in IE "Intra-frequency measurement reporting criteria".

SS send a PHYSICAL CHANNEL RECONFIGURATION message to UE, allocating dedicated physical channels on both uplink and downlink direction. Upon receiving such a message, the UE shall return PHYSICAL CHANNEL RECONFIGURATION COMPLETE message and move to CELL\_DCH state. The UE shall send MEASUREMENT REPORT messages to indicate that the measured result of cell 2, as the measurement quantity has exceeded the threshold value in system information message. After receiving this message, SS transmits MEASUREMENT CONTROL message in which it specifies that intra-frequency measurement for cell 3 shall be performed. The reporting criteria are the same as in SYSTEM INFORMATION BLOCK TYPE 12 message, except that the reporting threshold is lowered. After receiving such a message, the UE shall transmit another MEASUREMENT REPORT message. SS verifies that only measurement reading for cell 3 is included and no IEs shall be present, which pertain to measurement quantity in cell 2.

Next, SS sends PHYSICAL CHANNEL RECONFIGURATION message to UE. In this message, the physical channel resources are switched to common physical channels – PRACH (RACH) for the uplink and S-CCPCH (FACH) for the



downlink. UE shall reply with a PHYSICAL CHANNEL RECONFIGURATION COMPLETE and transits to CELL\_FACH. SS checks the uplink RACH to confirm that no MEASUREMENT REPORT messages are received. SS then transmits another MEASUREMENT CONTROL message. The key parameters employed are: measurement type = 'intra-frequency measurement', measurement object = 'cell 2', reporting criteria = 'periodic reporting', measurement validity = 'resume', UE state for reporting = 'CELL\_DCH'. SS waits for 10 seconds before sending a PHYSICAL CHANNEL RECONFIGURATION message, comprising DPDCH physical channels. UE shall then return to CELL\_DCH state, start to monitor the neighbour cell specified by the SS while the UE was in CELL\_FACH state. The UE shall resume periodic reporting of cell 2's CPICH RSCP measured results by sending MEASUREMENT REPORT messages. Following the reception of the MEASUREMENT REPORT message, SS commands the UE to stop performing measurements and generation of reports for cell 2. SS then verifies that no MEASUREMENT REPORT messages are detected.

In the next sequence, SS dispatches a PHYSICAL CHANNEL RECONFIGURATION message on the downlink DCCH. In this message, common physical channel resources are assigned to the UE. The UE shall respond with a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message and then transit to CELL\_FACH state. Then SS sends a MEASUREMENT CONTROL message, with the content identical to the previous message of the type transmitted in step 10. This effectively signifies that the UE shall re-start the intra-frequency measurement and reporting activities related to cell 2, when it subsequently manages to return to CELL\_DCH state. Following this, SS increases the P-CPICH RSCP of cell 3 to -45dBm and shortly after this, stops the transmission of all downlink physical channel of cell 1. SS then waits for T305 to expire. The UE shall discover a "out-of-service" condition and initiate a cell re-selection procedure. This can be verified by the SS receiving a CELL UPDATE message on the uplink CCCH, with the "cell update cause" IE set to "cell reselection". SS sends a PHYSICAL CHANNEL RECONFIGURATION message on the downlink DCCH, assigning DPCH channel in both uplink and downlink directions. The UE shall respond with a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message and then return to CELL\_FACH state. SS checks that the UE does not generate any MEASUREMENT REPORT messages on the uplink DCCH.

## Expected Sequence

Step	Direction		Message	Comment
	UE	SS		
1				UE is initially in CELL_FACH after having successfully connected a packet-switched data call. SYSTEM INFORMATION TYPE BLOCK TYPE 12 message is changed according to the descriptions in Specific Message Contents.
2		←	PHYSICAL CHANNEL RECONFIGURATION	Allocates DPDCH physical channels.
3		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	UE shall move to CELL_DCH state.
4		→	MEASUREMENT REPORT	Reports cell 2's RSCP value.
5		←	MEASUREMENT CONTROL	Specifies cell 3 as the measurement object for intra-frequency measurement. The reporting criteria is the same as defined in SYSTEM INFORMATION BLOCK TYPE 12 message, with the exception that threshold for event 1e is lowered.
6		→	MEASUREMENT REPORT	UE shall report the estimated value for cell 3's CPICH RSCP reading only.
7		←	PHYSICAL CHANNEL RECONFIGURATION	Allocates PRACH and S-CCPCH physical channels.
8		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	UE shall move to CELL_FACH state.
9				SS checks that no MEASUREMENT REPORT messages are sent by UE.
10		←	MEASUREMENT CONTROL	SS indicates that intra-frequency measurement and reporting for cell 2 be resumed if the UE subsequently transits to CELL_DCH state.
11		←	PHYSICAL CHANNEL RECONFIGURATION	SS waits for 10 seconds before sending this message. DPCH physical channels are assigned to the UE in this message.
12		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	UE shall return to CELL_DCH state.
13		→	MEASUREMENT REPORT	UE begins to report cell 2's measured results again.
14		←	MEASUREMENT CONTROL	Terminate all the intra-frequency measurement activity related to cell 2. SS checks that no more MEASUREMENT REPORT messages are sent by the UE.
15		←	PHYSICAL CHANNEL RECONFIGURATION	Allocates PRACH and S-CCPCH physical channels.
16		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	UE shall move to CELL_FACH state.
17		←	MEASUREMENT CONTROL	Message is the same as in step 10

18			SS increases the transmission power of cell 3 (P-CPICH RSCP is raised to $-45\text{dBm}$ ) and switches off all downlink transmissions for cell 1. SS then waits until T305 expires.
19	→	CELL UPDATE	UE shall re-selects to cell 2 and then perform a cell update procedure.
20	←	CELL UPDATE CONFIRM	UE shall stay in CELL_FACH state.
21	→	PHYSICAL CHANNEL RECONFIGURATION	DPCH physical channels are assigned to the UE in this message.
22	←	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	UE shall return to CELL_DCH state.
23			SS checks that no MEASUREMENT REPORT messages are received on uplink DCCH.

Specific Message Content

#### SYSTEM INFORMATION BLOCK TYPE 12

Information Element	Value/Remark
---------------------	--------------

Reference to other system information blocks	Not Present
FACH measurement occasion info	Not Present
Measurement control system information	
- Intra-frequency measurement system information	
- Intra-frequency measurement identity number	10
- Intra-frequency cell info list	
- Removed intra-frequency info list	Not Present
- New intra-frequency info list	
- Intra-frequency cell id	Set to id of cell 2
- Cell info	
- Cell individual offset	0 dB
- Reference time difference to cell	0 chips
- Primary CPICH Info	
- Primary Scrambling Code	Set to same code as used for cell 2
- Primary CPICH TX power	Not Present
- Read SFN Indicator	FALSE
- TX Diversity Indicator	FALSE
- Cell selection and Re-selection info for SIB11/12	
- Qoffset <sub>s,n</sub>	0dB
- Maximum allowed UL TX power	0dBm
- HCS neighbouring cell information	Not Present
- Qqualmin, Qrxlevmin	-20dB, -115dBm
- Intra-frequency measurement quantity	
- Filter Coefficient	0
- Measurement quantity	CPICH Ec/No
- Intra-frequency measurement for RACH reporting	Not Present
- Maximum number of reported cells on RACH	No report
- Reporting information for state CELL_DCH	
- Intra-frequency reporting quantity	
- Reporting quantities for active set cells	
- SFN-SFN observed time difference	No report
- Cell identity	FALSE
- CPICH Ec/No	FALSE
- CPICH RSCP	FALSE
- Pathloss	FALSE
- CFN-SFN observed time difference	FALSE
- Reporting quantities for monitored set cells	
- SFN-SFN observed time difference	No report
- Cell identity	TRUE
- CPICH Ec/No	FALSE
- CPICH RSCP	TRUE
- Pathloss	FALSE
- CFN-SFN observed time difference	FALSE
- Reporting quantities for detected cells	Not present
- CHOICE report criteria	Intra-frequency measurement reporting criteria
- Parameter required for each event	
- Intra-frequency event identity	1e
- Triggering condition	Monitored set cells
- Reporting range	Not present
- Cells forbidden to affect reporting	Not present
- W	Not present
- Hysteresis	Not Present
- Threshold used frequency	-60dBm
- Reporting deactivation threshold	Not present
- Replacement activation threshold	Not present
- Time to trigger	0
- Amount of reporting	Infinity
- Reporting Interval	16 seconds
- Inter-frequency measurement system information	Not Present
- Inter-system measurement system information	Not Present
- Traffic volume measurement system information	Not Present
- UE internal measurement system information	Not Present

## PHYSICAL CHANNEL RECONFIGURATION (Step 2)

Use the same message sub-type found in Clause 8.1 of TS34.108, which is entitled “Packet to CELL\_DCH from CELL\_FACH in PS”

## MEASUREMENT REPORT (Step 4)

Information Element	Value/Remarks
Measurement identity number	Check to see if set to 10
Measurement Results	
- CHOICE measurement	Check to see if set to "Intra-frequency measured results list"
- Intra-frequency measured results	
- Cell measured results	
- Cell Identity	Check to see if set to the id of cell 2
- SFN-SFN observed time difference	Check to see if this IE is absent
- CFN-SFN observed time difference	Check to see if this IE is absent
- Primary CPICH Info	
- Primary Scrambling Code	Check to see if it's the same code for cell 2
- CPICH Ec/No	Check to see if this IE is absent
- CPICH RSCP	Check to see if this IE is present
- Pathloss	Check to see if this IE is absent
Event Results	
- CHOICE event result	Check to see if it's set to 'Intra-frequency measurement event results'
- Intra-frequency event identity	Check to see if this IE is set to '1e'
- Cell measured event results	
- Primary CPICH info	
- Primary scrambling code	Check to see if it's the same code for cell 2

## MEASUREMENT CONTROL (Step 5)

Information Element	Value/Remark
---------------------	--------------

Measurement Identity Number	11
Measurement Command	Setup
Measurement Reporting Mode	Not Present
Additional measurements list	Not Present
CHOICE measurement type	Intra-frequency measurement
- Intra-frequency cell info list	
- Removed intra-frequency info list	Not Present
- New intra-frequency info list	
- Intra-frequency cell id	Set to id of cell 3
- Cell info	
- Cell individual offset	0 dB
- Reference time difference to cell	0 chips
- Primary CPICH Info	
- Primary Scrambling Code	Set to same code as used for cell 3
- Primary CPICH TX power	Not Present
- Read SFN Indicator	FALSE
- TX Diversity Indicator	FALSE
- Intra-frequency measurement quantity	
- Filter Coefficient	0
- Measurement quantity	CPICH RSCP
- Intra-frequency reporting quantity	
- Reporting quantities for active set cells	
- SFN-SFN observed time difference	No report
- Cell identity	FALSE
- CPICH Ec/No	FALSE
- CPICH RSCP	FALSE
- Pathloss	FALSE
- CFN-SFN observed time difference	FALSE
- Reporting quantities for monitored set cells	
- SFN-SFN observed time difference	No report
- Cell identity	TRUE
- CPICH Ec/No	FALSE
- CPICH RSCP	TRUE
- Pathloss	FALSE
- CFN-SFN observed time difference	FALSE
- Reporting quantities for detected cells	Not present
- Reporting cell status	Not present
- Measurement validity	Not present
- CHOICE report criteria	Intra-frequency measurement criteria
- Parameters required for each event	
- Intra-frequency event identity	1e
- Triggering condition	Monitored set cells
- Reporting Range	Not Present
- Cells forbidden to affect Reporting range	Not Present
- Primary CPICH Info	
- Primary Scrambling Code	Set to the same scrambling code for cell 3
- W	Not Present
- Hysteresis	Not Present
- Reporting deactivation threshold	Not Present
- Replacement activation threshold	Not Present
- Reporting Threshold	-90dBm
- Time to Trigger	0
- Amount of reporting	Infinity
- Reporting interval	16 seconds
DPCH compressed mode status info	Not Present

## MEASUREMENT REPORT (Step 6)

Information Element	Value/Remarks
---------------------	---------------

Measurement identity number	Check to see if set to 11
Measurement Results	
- CHOICE measurement	Check to see if set to "Intra-frequency measured results list"
- Intra-frequency measured results	
- Cell measured results	
- Cell Identity	Check to see if set to the id of cell 3
- SFN-SFN observed time difference	Check to see if this IE is absent
- CFN-SFN observed time difference	Check to see if this IE is absent
- Primary CPICH Info	
- Primary Scrambling Code	Check to see if it's the same code for cell 3
- CPICH Ec/No	Check to see if this IE is absent
- CPICH RSCP	Check to see if this IE is present
- Pathloss	Check to see if this IE is absent
Event Results	
- CHOICE event result	Check to see if it's set to 'Intra-frequency measurement event results'
- Intra-frequency event identity	Check to see if this IE is set to '1e'
- Cell measured event results	
- Primary CPICH info	
- Primary scrambling code	Check to see if it's the same code for cell 3

#### PHYSICAL CHANNEL RECONFIGURATION (Step 7 and 15)

Use the same message sub-type found in Clause 8.1 of TS34.108, which is entitled "Packet to CELL\_FACH from CELL\_DCH in PS"



## MEASUREMENT CONTROL (Step 10 and 17)

Information Element	Value/Remark
Measurement Identity Number	12
Measurement Command	Setup
Measurement Reporting Mode	Not Present
Additional measurements list	Not Present
CHOICE measurement type	Intra-frequency measurement
- Intra-frequency cell info list	
- Removed intra-frequency info list	Not Present
- New intra-frequency info list	
- Intra-frequency cell id	Set to id of cell 2
- Cell info	
- Cell individual offset	0 dB
- Reference time difference to cell	0 chips
- Primary CPICH Info	
- Primary Scrambling Code	Set to same code as used for cell 2
- Primary CPICH TX power	Not Present
- Read SFN Indicator	FALSE
- TX Diversity Indicator	FALSE
- Intra-frequency measurement quantity	
- Filter Coefficient	0
- Measurement quantity	CPICH RSCP
- Intra-frequency reporting quantity	
- Reporting quantities for active set cells	
- SFN-SFN observed time difference	No report
- Cell identity	FALSE
- CPICH Ec/No	FALSE
- CPICH RSCP	FALSE
- Pathloss	FALSE
- CFN-SFN observed time difference	FALSE
- Reporting quantities for monitored set cells	
- SFN-SFN observed time difference	No report
- Cell identity	TRUE
- CPICH Ec/No	FALSE
- CPICH RSCP	TRUE
- Pathloss	FALSE
- CFN-SFN observed time difference	FALSE
- Reporting quantities for detected cells	Not present
- Reporting cell status	Not present
- Measurement validity	Resume
- UE state	CELL_DCH
- CHOICE report criteria	Intra-frequency measurement criteria
- Parameters required for each event	
- Intra-frequency event identity	1e
- Triggering condition	Monitored set cells
- Reporting Range	Not Present
- Cells forbidden to affect Reporting range	Not Present
- Primary CPICH Info	
- Primary Scrambling Code	Set to the same scrambling code for cell 2
- W	Not Present
- Hysteresis	Not Present
- Reporting deactivation threshold	Not Present
- Replacement activation threshold	Not Present
- Reporting Threshold	-65dBm
- Time to Trigger	0
- Amount of reporting	Infinity
- Reporting interval	16 seconds
- Reporting cell status	Not Present
DPCH compressed mode status info	Not Present

## PHYSICAL CHANNEL RECONFIGURATION (Step 11 and 21)

Same as in step 2

## MEASUREMENT REPORT (Step 13)

Information Element	Value/Remarks
Measurement identity number	Check to see if set to 12
Measurement Results	
- CHOICE measurement	Check to see if set to "Intra-frequency measured results list"
- Intra-frequency measured results	
- Cell measured results	
- Cell Identity	Check to see if set to the id of cell 2
- SFN-SFN observed time difference	Check to see if this IE is absent
- CFN-SFN observed time difference	Check to see if this IE is absent
- Primary CPICH Info	
- Primary Scrambling Code	Check to see if it's the same code for cell 2
- CPICH Ec/No	Check to see if this IE is absent
- CPICH RSCP	Check to see if this IE is present
- Pathloss	Check to see if this IE is absent
Event Results	
- CHOICE event result	Check to see if it's set to 'Intra-frequency measurement event results'
- Intra-frequency event identity	Check to see if this IE is set to '1e'
- Cell measured event results	
- Primary CPICH info	
- Primary scrambling code	Check to see if it's the same code for cell 2

## MEASUREMENT CONTROL (Step 14)

Information Element	Value/Remarks
Measurement Identity Number	12
Measurement Command	Release
Measurement Reporting Mode	Not Present
Additional measurements list	Not Present
CHOICE Measurement type	Not Present
DPCH compressed mode status info	Not Present

## CELL UPDATE (Step 21)

Information Element	Value/Remarks
U-RNTI	
- SRNC Identity	Check to see if set to '0000 0000 0000 0001'
- S-RNTI	Check to see if set to '0000 0000 0000 0000 0000 0001'
Integrity check info	Not checked
AM_RLC error indicator (for C-plane)	Check to see if set to 'FALSE'
AM_RLC error indicator (for U-plane)	Check to see if set to 'FALSE'
Cell Update Cause	Check to see if set to 'Cell Re-selection'
Protocol error indicator	Check to see if it is absent or set to 'FALSE'
Measured results on RACH	Check to see if it is absent
Protocol error information	Check to see if it is absent

## CELL UPDATE (Step 21)

Use the default message content of the same message type in Annex A.

## 8.4.1.7.5 Test Requirement

After step 3 the UE shall report cell 2's CPICH RSCP value by transmitting a MEASUREMENT REPORT message.

After step 5 the UE shall delete all measurement and reporting contexts obtained from system information messages. However, it shall transmit a MEASUREMENT REPORT message containing measured results of cell 3's CPICH RSCP value only.

After step 8 the UE shall stop intra-frequency measurement reporting assigned previously in the MEASUREMENT CONTROL message received in step 5.

After step 12 the UE shall resume the measurement and reporting activities as specified in MEASUREMENT CONTROL message received in step 10. The UE shall transmit MEASUREMENT REPORT message, containing measured results of cell 2's CPICH RSCP value.

After step 14 the UE shall stop all measurement activities pertaining to cell 2, no MEASUREMENT REPORT messages shall be detectable by the SS in the uplink DCCH.

After step 19 the UE shall re-select to cell 3 and initiate a cell update procedure. SS shall receive a CELL UPDATE message on the uplink CCCH of cell 3, with the "cell update cause" IE stated as "cell re-selection".

After step 22 the UE shall not start to perform measurement for cell 2, no MEASUREMENT REPORT messages shall be detectable by the SS in the uplink DCCH.

#### 8.4.1.8 Measurement Control and Report: Inter-frequency measurement for transition from CELL\_FACH to CELL\_DCH state

##### 8.4.1.8.1 Definition

##### 8.4.1.8.2 Conformance requirement

When transiting from CELL\_FACH state to CELL\_DCH state, the UE shall stop monitoring the list of inter-frequency neighbour cells indicated in system information messages. If the UE has a previously stored inter-frequency measurement context marked as 'resume', it shall reinstate the suspended measurement and associated reporting activities after it has re-entered CELL\_DCH state. The UE shall be able to start/terminate inter-frequency measurement by decoding the "DPCH compressed mode status info" IE in MEASUREMENT CONTROL messages.

##### Reference

3GPP TS 25.331 clause 8.4.1.8, 8.5.7.6.13

##### 8.4.1.8.3 Test Purpose

To confirm that the UE erases all inter-frequency measurement contexts used in CELL\_FACH state, when it moves to CELL\_DCH. To confirm that the UE resumes inter-frequency measurements and reporting, which was assigned prior to CELL\_FACH state, after it moves to CELL\_DCH state. To confirm that the UE resumes inter-frequency measurement and reporting activities after it has received a MEASUREMENT CONTROL message specifying that a stored compressed mode pattern sequence be re-activated.

##### 8.4.1.8.4 Method of test

##### Initial Condition

SS: 3 cells – All 3 cells are active and the applicable radio conditions are stated in the table below:

	Cell 1	Cell 2	Cell 3
UARFCN ( $N_u$ and $N_d$ )	Channel 1	Channel 2	Channel 2
CPICH RSCP	-60 dBm	-65 dBm	-75 dBm
$Q_{rxlevmin}$	-90 dBm	-90 dBm	-90 dBm
S	30	25	15

UE: CELL\_FACH in cell 1 after an incoming packet-switched data call is successfully established.

##### Test Procedure

The UE is in CELL\_FACH state after a successful connection, triggered by an incoming packet-switched data call. SS modifies the content of SYSTEM INFORMATION BLOCK TYPE 12 message, which indicates that cell 2 shall be

included in the list of neighbouring cells to be monitored for inter-frequency measurements. Next, SS transmits MEASUREMENT CONTROL message to request the UE to execute an inter-frequency measurement for cell 3. The parameters of the reporting criteria are as follow: event-triggered with event identity = '2c', threshold for non-used frequency = '-80 dBm', hysteresis = '1.0dB', time to trigger = '10 seconds', amount of reporting = '1' and reporting interval = '0'. In the same message, IE "Measurement validity" is set to 'resume' and "UE state for reporting" is assigned the value 'CELL\_DCH'.

SS sends PHYSICAL CHANNEL RECONFIGURATION message to allocate dedicated physical channels to the UE. Simultaneously, SS uses this message to command UE to start applying compressed mode mechanism for DPCH. The UE shall reply with PHYSICAL CHANNEL RECONFIGURATION COMPLETE message and then move to CELL\_DCH state. SS waits for 10 seconds. The UE shall transmit MEASUREMENT REPORT message, containing the selected frequency quality estimate (in the case CPICH Ec/No) of cell 3. SS verifies that this message does not contain measured results for cell 2. After sending this message, the UE shall not transmit any more MEASUREMENT REPORT messages.

SS modifies the reporting criteria by transmitting a MEASUREMENT CONTROL message on the downlink DCCH using AM-RLC. In this message, SS commands the UE to perform inter-frequency measurement and reporting for cell 3 using periodic reporting mechanism. Upon receiving this message, the UE shall transmit MEASUREMENT REPORT message at 2 seconds interval. In the next sequence, SS transmits a PHYSICAL CHANNEL RECONFIGURATION message and deactivates the compressed mode pattern sequence with "TGPSI" IE set to 1. The UE shall respond by sending PHYSICAL CHANNEL RECONFIGURATION COMPLETE message and also stop the periodic reporting activities. Following this, SS sends a MEASUREMENT CONTROL message and re-activates the compressed mode pattern sequence by using the "DPCH compressed mode status" IE. SS confirms that the UE has reconfigured itself to start measurement reporting again. The SS shall be able to receive MEASUREMENT REPORT messages continuously at 2 seconds interval.

## Expected Sequence

Step	Direction		Message	Comment
	UE	SS		
1				UE is initially in CELL_FACH state after establishing an incoming packet-switched data call. SS modifies SYSTEM INFORMATION BLOCK TYPE 12 to include cell 2 into the neighbour cell list for inter-frequency measurements.
2		←	MEASUREMENT CONTROL	SS specifies inter-frequency measurement and reporting parameters for cell 3.
3		←	PHYSICAL CHANNEL RECONFIGURATION	SS allocates DPCH physical channels and specifies compressed mode parameters
4		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	UE moves to CELL_DCH state.
5		→	MEASUREMENT REPORT	UE shall resume inter-frequency measurement task for cell 3 and transmit this message to report the measured CPICH Ec/No value
6		←	MEASUREMENT CONTROL	SS changes the reporting criteria for cell 3 to 'periodic reporting'
7		→	MEASUREMENT REPORT	UE shall begin to transmit this message at 2 seconds interval.
8		←	PHYSICAL CHANNEL RECONFIGURATION	SS deactivates the currently used pattern sequence for compressed mode operation.
9		→	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	UE stays in CELL_DCH state. SS waits for 5 seconds and verifies that no MEASUREMENT REPORT messages are received.
10		←	MEASUREMENT CONTROL	SS activates the pattern sequence stored by the UE.
11		→	MEASUREMENT REPORT	SS checks that MEASUREMENT REPORT messages are received at 2 seconds interval.

## Specific Message Content

## SYSTEM INFORMATION BLOCK TYPE 12 (Step 1)

Information Element	Value/Remark
---------------------	--------------

References to other system information blocks	Not Present
FACH measurement occasion info	
- k_UTRA	2
- Other RAT present in inter-system cell info	Not Present
Measurement control system information	
- Intra-frequency measurement system information	Not Present
- Inter-frequency measurement system information	
- Inter-frequency measurement identity number	15
- Inter-frequency cell info list	
- Removed inter-frequency info list	Not Present
- New inter-frequency info list	
- Inter-frequency cell id	Set to id of cell 2
- Cell info	
- Cell individual offset	0 dB
- Reference time difference to cell	0 chips
- Primary CPICH Info	
- Primary Scrambling Code	Set to same code as used for cell 2
- Primary CPICH TX power	Not Present
- Read SFN Indicator	FALSE
- TX Diversity Indicator	FALSE
- Cell selection and Re-selection info for SIB11/12	
- Qoffset <sub>s,n</sub>	0dB
- Maximum allowed UL TX power	0dBm
- HCS neighbouring cell information	Not Present
- Qqualmin, Qrxlevmin	-20dB, -90dBm
- Inter-frequency measurement quantity	
- CHOICE reporting criteria	Inter-frequency reporting criteria
- Filter Coefficient	0
- Measurement quantity for frequency quality estimate	CPICH Ec/No
- Inter-frequency measurement reporting criteria	
- Parameters required for each event	
- Inter-frequency event identity	2c
- Threshold used frequency	Not Present
- W used frequency	Not Present
- Hysteresis	1.0dB
- Time to trigger	10 sec
- Amount of reporting	1
- Reporting interval	0
- Parameters required for each non used frequency	
- Threshold non-used frequency	-80dBm
- W non-used frequency	0.0
- Inter-system measurement system information	Not Present
- Traffic volume measurement system information	Not Present
- UE internal measurement system information	Not Present

## MEASUREMENT CONTROL (Step 2)

Information Element	Value/Remark
---------------------	--------------

Measurement Identity Number	14
Measurement Command	Setup
Measurement Reporting Mode	Not Present
Additional measurements list	Not Present
CHOICE measurement type	Inter-frequency measurement
- Inter-frequency cell info list	
- Removed inter-frequency info list	Not Present
- New inter-frequency info list	
- Inter-frequency cell id	Set to id of cell 3
- Frequency info	
- UARFCN uplink (Nu)	UARFCN of the uplink frequency for cell 3
- UARFCN downlink (Nd)	UARFCN of the downlink frequency for cell 3
- Cell info	
- Cell individual offset	0 dB
- Reference time difference to cell	0 chips
- Primary CPICH Info	
- Primary Scrambling Code	Set to same code as used for cell 3
- Primary CPICH TX power	Not Present
- Read SFN Indicator	FALSE
- TX Diversity Indicator	FALSE
- Inter-frequency measurement quantity	
- CHOICE reporting criteria	Inter-frequency reporting criteria
- Filter Coefficient	0
- Measurement quantity for frequency quality estimate	CPICH Ec/No
- Inter-frequency reporting quantity	
- UTRA Carrier RSSI	FALSE
- Frequency quality estimate	TRUE
- Non frequency related cell reporting quantities	
- SFN-SFN observed time difference	No report
- Cell Identity	TRUE
- CPICH Ec/No	FALSE
- CPICH RSCP	TRUE
- Pathloss	FALSE
- CFN-SFN observed time difference	FALSE
- Reporting cell status	Not present
- Measurement validity	
- Resume/Release	Resume
- UE State	CELL_DCH
- Inter-frequency set update	Not Present
- CHOICE report criteria	Inter-frequency measurement reporting criteria
- Parameters required for each event	
- Inter-frequency event identity	2c
- Threshold used frequency	Not Present
- W used frequency	Not Present
- Hysteresis	0
- Time to trigger	10 seconds
- Amount of reporting	1
- Reporting Interval	0
- Reporting cell status	Not Present
- Parameters required for each non-used frequency	
- Threshold non used frequency	-80 dBm
- W non-used frequency	0.0
DPCH compressed mode status info	Not Present

### PHYSICAL CHANNEL RECONFIGURATION (Step 3)

Use the same message sub-type found in Clause 9 of TS34.108, which is entitled “( Packet to CELL\_DCH from CELL\_FACH in PS”, with the following exceptions in the IE(s) concerned:

Information Element	Value/Remarks
Downlink information common for all radio links	
- Downlink DPCH info common for all RL	0 (Single)
- Downlink DPCH power control information	Refer to the parameter set in TS 34.108
- DPC mode	Flexible
- Spreading factor	FALSE
- Fixed or flexible position	Not Present
- TFCI existence	0
- Number of bits for Pilot bits (SF=128, 256)	1
- Downlink DPCH Offset Value	Active
- DPCH compressed mode info	
- TGPSI	FDD Measurement
- TGPS Status Flag	62
- Transmission gap pattern sequence configuration parameters	(Current CFN + (256 – TTI/10msec)) mod 256
- TGMP	8
- TGPRC	10
- TGCFN	5
- TGSN	15
- TGL1	35
- TGL2	35
- TGD	Mode 1
- TGPL1	Mode 1
- TGPL2	DL
- RPP	F/2
- ITP	Not Present
- UL/DL Mode	A
- Downlink compressed mode method	2.0
- Uplink compressed mode method	1.0
- Downlink frame type	Not Present
- DeltaSIR1	None
- DeltaSIRAfter1	Not Present
- DeltaSIR2	Not Present
- TX Diversity Mode	
- SSDT information	
- S field	
- Code Word Set	

## MEASUREMENT REPORT (Step 5)

Information Element	Value/Remarks
---------------------	---------------



Measurement identity number	Check to see if set to 14
Measurement Results	
- CHOICE measurement	Check to see if set to "Inter-frequency measured results list"
- Inter-frequency measurement results	
- Frequency info	
- UARFCN (uplink)	Check to see if set to the UARFCN of the uplink frequency for cell 3
- UARFCN (downlink)	Check to see if set to the UARFCN of the downlink frequency for cell 3
- UTRA carrier RSSI	Check to see if it is absent
- Inter-frequency cell measurement results	
- Cell measured results	
- Cell Identity	Check to see if set to the id of cell 3
- SFN-SFN observed time difference	Check to see if it is absent
- CFN-SFN observed time difference	Check to see if it is absent
- Primary CPICH Info	
- Primary Scrambling Code	Check to see if set to the same code for cell 3
- CPICH Ec/No	Check to see if it is present
- CPICH RSCP	Check to see if it is absent
- Pathloss	Check to see if it is absent
Event Results	
- CHOICE event result	Inter-frequency event results
- Inter-frequency event identity	Check to see if it's set to '2c'
- Inter-frequency cells	
- Frequency Info	
- UARFCN (uplink)	Check to see if set to the UARFCN of the uplink frequency for cell 3
- UARFCN (downlink)	Check to see if set to the UARFCN of the downlink frequency for cell 3
- Non frequency related measurement event results	
- Primary CPICH Info	
- Primary Scrambling Code	Check to see if set to the same code for cell 3

## MEASUREMENT CONTROL (Step 6)

Information Element	Value/Remark
---------------------	--------------

Measurement Identity Number	14
Measurement Command	Modify
Measurement Reporting Mode	Not Present
Additional measurements list	Not Present
CHOICE measurement type	Inter-frequency measurement
- Inter-frequency cell info list	
- Removed inter-frequency info list	Not Present
- New inter-frequency info list	
- Inter-frequency cell id	Set to id of cell 3
- Frequency info	
- UARFCN uplink (Nu)	UARFCN of the uplink frequency for cell 3
- UARFCN downlink (Nd)	UARFCN of the downlink frequency for cell 3
- Cell info	
- Cell individual offset	0 dB
- Reference time difference to cell	0 chips
- Primary CPICH Info	
- Primary Scrambling Code	Set to same code as used for cell 3
- Primary CPICH TX power	Not Present
- Read SFN Indicator	FALSE
- TX Diversity Indicator	FALSE
- Inter-frequency measurement quantity	
- CHOICE reporting criteria	Inter-frequency reporting criteria
- Filter Coefficient	1
- Measurement quantity for frequency quality estimate	CPICH Ec/No
- Inter-frequency reporting quantity	
- UTRA Carrier RSSI	FALSE
- Frequency quality estimate	TRUE
- Non frequency related cell reporting quantities	
- SFN-SFN observed time difference	No report
- Cell Identity	TRUE
- CPICH Ec/No	FALSE
- CPICH RSCP	TRUE
- Pathloss	FALSE
- CFN-SFN observed time difference	FALSE
- Reporting cell status	Not present
- Measurement validity	Not present
- Inter-frequency set update	Not Present
- CHOICE report criteria	Periodic reporting criteria
- Amount of reporting	Infinity
- Reporting interval	2000 milliseconds
DPCH compressed mode status info	Not Present

## MEASUREMENT REPORT (Step 7, 11)

Information Element	Value/Remarks
---------------------	---------------

Measurement identity number	Check to see if set to 14
Measured Results	
- CHOICE measurement	Check to see if set to "Inter-frequency measured results list"
- Inter-frequency measurement results	
- Frequency info	
- UARFCN (uplink)	Check to see if set to the UARFCN of the uplink frequency for cell 3
- UARFCN (downlink)	Check to see if set to the UARFCN of the downlink frequency for cell 3
- UTRA carrier RSSI	Check to see if it is absent
- Inter-frequency cell measurement results	
- Cell measured results	
- Cell Identity	Check to see if set to the id of cell 3
- SFN-SFN observed time difference	Check to see if it is absent
- Primary CPICH Info	
- Primary Scrambling Code	Check to see if set to the same code for cell 3
- CPICH Ec/No	Check to see if it is present
- CPICH RSCP	Check to see if it is absent
- Pathloss	Check to see if it is absent
- CFN-SFN observed time difference	Check to see if it is absent
Event Results	Check to see if it is absent

#### PHYSICAL CHANNEL RECONFIGURATION (Step 8)

Use the same message transmitted in step 3 with the following modifications:

Information Element	Value/Remarks
Downlink information common for all radio links	
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	Inactive

#### MEASUREMENT CONTROL (Step 10)

Information Element	Value/Remark
Measurement Identity Number	Any number except 14
Measurement Command	Release
Measurement Reporting Mode	Not Present
Additional measurements list	Not Present
CHOICE measurement type	Not Present
DPCH compressed mode status info	
- Transmission gap pattern sequence	
- TGPSI	1
- TGPS Flag	Active

##### 8.4.1.8.5 Test Requirement

After step 4 the UE shall transmit a MEASUREMENT REPORT message, containing the measured results for cell 3's CPICH Ec/No value. The UE shall not transmit any messages pertaining to cell 2's measurements.

After step 6 the UE shall send MEASUREMENT REPORT messages, which comprises cell 3's CPICH Ec/No measured value at 2 seconds interval. The "Event results" IE shall be omitted in these messages.

After step 8 the UE shall not transmit any MEASUREMENT REPORT messages.

After step 10 the UE shall resume the transmission of MEASUREMENT REPORT messages with identical contents as in those received after step 6.

## 8.4.1.9 Measurement Control and Report: Unsupported measurement in the UE

### 8.4.1.9.1 Definition

### 8.4.1.9.2 Conformance requirement

If the UTRAN indicates the UE to perform a measurement that is not supported in the UE, the UE shall keep the measurement configuration. Then the UE shall transmit a MEASUREMENT CONTROL FAILURE message on the DCCH using AM RLC.

### Reference

3GPP TS25.331 clause 8.4.1.

### 8.4.1.9.3 Test purpose

To confirm that the UE transmits a MEASUREMENT CONTROL FAILURE message, with the value “unsupported measurement” specified in IE “failure cause” when the SS commanded the UE to perform an unsupported measurement by sending a MEASUREMENT CONTROL message.

### 8.4.1.9.4 Method of test

#### Initial Condition

System Simulator : 1cell

UE : CELL\_DCH

[ Editor's note : It is assumed in this test that the UE under test does not possess any inter-system measurement capability. The mandatory type(s) of measurement capability that should be implemented by the UE is to be discussed ]

#### Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a MEASUREMENT CONTROL message which includes parameters (e.g. Measurement identity number : 2 , measurement command : Setup , measurement type: inter-system measurements, measurement reporting mode: unacknowledged and periodical reporting, measurement object: inter-system cell information, measurement quantity: Signal strength, reporting quantity: RSSI on BCCH carrier). As the UE under test does not support inter-system measurement, it shall transmit a MEASUREMENT CONTROL FAILURE message on the uplink DCCH using AM RLC.

Expected sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is in the CELL_DCH state.
2		←	MEASUREMENT CONTROL	Including the parameters (e.g. Measurement identity number : 2 , measurement command : Setup , measurement type: inter-system measurements, measurement reporting mode: unacknowledged and periodical reporting, measurement object: inter-system cell information, measurement quantity: Signal strength, reporting quantity: RSSI on BCCH carrier).
3		→	MEASUREMENT CONTROL FAILURE	Which is set to "unsupported measurement" in IE " failure cause".

## Specific Message Content

## MEASUREMENT CONTROL

Information Element	Value/Remark
Measurement Identity Number	2
Measurement Command	Setup
Measurement Reporting Mode	Unacknowledged mode
Additional measurements list	Not Present
CHOICE measurement type	Inter-system measurement
- Inter-system cell info list	
- Removed inter-system cells	Not Present
- New inter-system cells	1
- Inter-system cell id	
- CHOICE <i>Radio Access Technology</i>	GSM
- Qoffset <sub>s,n</sub>	Not Present
- HCS Neighbouring Cell Information	Not Present
- Qqualmin, Qrxlevmin	-20dB, -90dBm
- Maximum allowed UL TX power	Set to the maximum allowed by UE RF power class
- BSIC	Set to the BSIC code of cell 2
- BSIC ARFCN	Set to the ARFCN assigned to cell 2
- Output power	Not Present
- Inter-system measurement quantity	
- CHOICE <i>reporting criteria</i>	Inter-frequency reporting criteria
- Filter Coefficient	0
- Measurement quantity for frequency quality estimate	CPICH Ec/No
- Inter-system reporting quantity	
- UTRA Carrier RSSI	TRUE
- Frequency quality estimate	FALSE
- Non frequency related cell reporting quantities	
- SFN-SFN observed time difference	FALSE
- CPICH Ec/No	FALSE
- CPICH RSCP	FALSE
- Pathloss	FALSE
- CFN-SFN observed time difference	FALSE
- Reporting Cell Status	Not Present
- CHOICE Report Criteria	Periodical reporting criteria
- Amount of reporting	Infinity
- Reporting Interval	32 seconds
DPCH compressed mode status info	Not Present

## MEASUREMENT CONTROL FAILURE

Information Element	Value/Remarks
Failure cause	To check if it is set to "Unsupported measurement"

## 8.4.1.9.4 Test requirement

After step 2 the UE shall identify the unsupported measurement element in the MEASUREMENT CONTROL message and transmit a MEASUREMENT CONTROL FAILURE. In this message, the value "unsupported measurement" shall be specified in IE "failure cause".

## 8.4.1.10 Measurement Control and Report: Failure (Invalid Message Reception)

## 8.4.1.10.1 Definition

## 8.4.1.10.2 Conformance requirement

When the UE received a MEASUREMENT CONTROL message containing an unexpected conditional IE, it shall reply with a MEASUREMENT CONTROL FAILURE message stating the appropriate protocol error information. It shall

maintain the monitoring and measurement reporting mechanism as in before the MEASUREMENT CONTROL message has been received.

## Reference

3GPP TS 25.331 clause 8.4.1.9

### 8.4.1.10.3 Test Purpose

To confirm that the UE does not change its current monitoring and measurement settings after it has received an illegal MEASUREMENT CONTROL message, which contains an unexpected IE error. To confirm that the UE resume its normal measurement reporting operations after transmitting MEASUREMENT CONTROL FAILURE message to the SS.

### 8.4.1.10.4 Method of test

#### Initial Condition

System Simulator : 1 cell.

UE : CELL\_DCH

#### Test Procedure

The UE is initially brought to CELL\_DCH. SS transmits a MEASUREMENT CONTROL message to the UE, commanding it to start transmitting report messages for the reporting quantity "UE Transmitted Power". SS then waits for the MEASUREMENT RERORT message with the allocated measurement identity to arrive. Then it transmits the MEASUREMENT CONTROL message again. In this message, SS requests that the reporting activities for "UE Transmitted Power" be stopped. At the end of this message, SS appends an unknown information element. When the UE receives this message, it shall reply with MEASUREMENT CONTROL FAILURE message as it has detected a protocol error. It shall not cease to report its own transmission power level using MEASUREMENT REPORT messages.

#### Expected Sequence

Step	Direction		Message	Comment
	UE	SS		
1				The UE is CELL_DCH state in cell 1.
2		←	MEASUREMENT CONTROL	SS transmits this message on downlink DCCH to instruct UE to start reporting the quantity "UE transmit power".
3		→	MEASUREMENT REPORT	UE shall send this message periodically at 32 seconds interval
4		←	MEASUREMENT CONTROL	SS sends a MEASUREMENT CONTROL message to request that UE stop the reporting activity.
5		→	MEASUREMENT CONTROL FAILURE	UE shall maintain its current measurement context and send this message.
6		→	MEASUREMENT REPORT	32 seconds after step 3, UE shall continue to transmit this message to the SS.

## Specific Message Content

## MEASUREMENT CONTROL (Step 2)

Information Element	Value/Remark
Measurement Identity Number	3
Measurement Command	Setup
Measurement Reporting Mode	Not Present
Additional measurements list	Not Present
CHOICE measurement type	UE internal measurement
- UE internal measurement quantity	
- Measurement quantity	UE Transmitted Power
- Filter coefficient	0
- UE internal reporting quantity	
- UE Transmitted Power	TRUE
- UE Rx-Tx time difference	FALSE
CHOICE report criteria	Periodical reporting criteria
- Amount of reporting	Infinity
- Reporting interval	32 seconds
DPCH compressed mode status info	Not Present

## MEASUREMENT REPORT (Step 3)

Information Element	Value/Remarks
Measurement identity number	Check to see if set to 3
Measurement Results	
CHOICE measurement	Check to see if set to "UE internal measurement"
- UE Transmitted Power	Check to see if the reported power is compatible with RF class
- UE Rx-Tx report entries	Check to see if this IE is absent
Event Results	Check to see if this IE is absent

## MEASUREMENT CONTROL (Step 4)

Information Element	Value/Remark
Measurement Identity Number	3
Measurement Command	Stop
Measurement Reporting Mode	Not Present
Additional measurements list	Not Present
CHOICE measurement type	Contains an arbitrary value
DPCH compressed mode status info	Not Present

## MEASUREMENT CONTROL FAILURE (Step 5)

Information Element	Value/Remark
Failure cause	Check to see if set to "protocol error"
Protocol error information	Check to see if set to "Message extension not comprehended"

## MEASUREMENT REPORT (Step 6)

Same as in the requirement for step 3

## 8.4.1.10.5 Test Requirement

After step 4 the UE shall transmit MEASUREMENT FAILURE message, stating the IE "failure cause" as "protocol error" and IE "protocol error information" as "message extension not comprehended". It shall continue to send MEASUREMENT REPORT with the correct identity number and measurement result entries at approximately 32 seconds interval.



---

## 9 Elementary procedures of mobility management

The tests are based on TS 24.008.

In this clause, when the expected sequence require that "a mobile originated CM connection is attempted", it shall be for a service other than emergency call.

In this clause, a initial CM message is either a SETUP message, a REGISTER message or a CP-DATA message (in that case the acknowledged mode of operation on SAPI 3 will have be established and this message will be sent on SAPI 3).

### 9.1 TMSI reallocation

The intention of the TMSI Reallocation procedure is to assign a new temporary identity for the UE. If the message is not understood by the UE, the network could not establish a link to the UE. As this is a common MM procedure, it can be initiated at any time.

#### 9.1.1 Conformance requirement

- 1) A User Equipment shall acknowledge a new TMSI when explicitly allocated during a location updating procedure or an incoming call.
- 2) The TMSI shall be updated on the SIM when the User Equipment is correctly deactivated in accordance with the manufacturer's instructions.
- 3) A User Equipment shall answer paging with this TMSI and includes it in the Paging Response message.

#### Reference(s)

TS 24.008 Clause 4.3.1.

#### 9.1.2 Test purpose

To verify that the UE is able to receive and acknowledge a new TMSI by means of an explicit TMSI reallocation procedure.

To verify that the UE has stored the TMSI in a non-volatile memory.

The implicit reallocation procedure is tested in clause 9.4.1.

#### 9.1.3 Method of test

##### Initial conditions

- System Simulator:
  - two cells A and B, belonging to different location areas a and b, default parameters.
- User Equipment:
  - the UE has valid TMSI (= TMSI1), CKSN, Kc. It is "idle updated" on cell B.

##### Related ICS/IXIT statement(s)

Switch off button Yes/No.

Way to bring the UE into service.

Foreseen final state of the UE

The UE has a valid TMSI (= TMSI1), CKSN, Kc. It is "idle updated" on cell A.

#### Test Procedure

The UE is paged in cell B and the security mode is established. An explicit TMSI reallocation procedure is performed. The RRC CONNECTION is released. The UE is switched off and then its power supply is interrupted for 10 seconds. The power supply is resumed and then the UE is switched on and allowed sufficient time to guarantee that the UE is in service (listening to its paging subchannel). The system simulator then checks, by paging, whether the UE has stored the received TMSI.

The UE is made to select cell A. A normal location updating procedure is performed in cell A. An explicit TMSI reallocation procedure is performed and then the location updating procedure is accepted by the SS. The system simulator checks, by paging, whether the UE has stored the allocated TMSI.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		←	MOBILE TERMINATED ESTABLISHMENT OF RRC CONNECTION	The following messages are sent and shall be received on cell B. "Mobile identity" = TMSI1. Establishment Cause: Answer to paging.
2		→	PAGING RESPONSE	
3		←	SECURITY MODE COMMAND	The SS starts deciphering.
4		→	SECURITY MODE COMPLETE	The SS starts enciphering.
5		←	TMSI REALLOCATION COMMAND	"Mobile identity" = new TMSI (TMSI2) different from TMSI 1.
6		→	TMSI REALLOCATION COMPLETE	
7		←	RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
8	UE			If possible (see ICS), the UE is switched off.
8a	UE			The power supply is interrupted for 10 seconds.
9	UE			The UE is switched on.
10	SS			The SS waits an amount of time which is enough to guarantee that the UE is in service (listening to its paging subchannel).
11		←	MOBILE TERMINATED ESTABLISHMENT OF RRC CONNECTION	"Mobile identity" = TMSI2.
		→		Establishment Cause: Answer to paging.
12		←	PAGING RESPONSE	"Mobile identity" = TMSI2.
13		←	RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link. The following messages are sent and shall be received on cell A
14	SS			The RF level of cell B is lowered until the UE selects cell A. The RF level of cell B is set sufficiently low to ensure that cell B is not suitable as defined in subclause 6.6.2.
15		→	RRC CONNECTION REQUEST	Establishment cause: Location updating.
16		←	RRC CONNECTION SETUP	
17		→	LOCATION UPDATING REQUEST	location updating type = normal, "ciphering key sequence number" = CKSN, LAI = b, "mobile identity" = TMSI2.
18		←	TMSI REALLOCATION COMMAND	TMSI = TMSI1.
19		→	TMSI REALLOCATION COMPLETE	
20		←	LOCATION UPDATING ACCEPT	This message does not contain the optional Mobile Identity field.
21		←	RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link. The SS waits an amount of time which is enough to guarantee that the UE is "idle updated" on cell A.
22		←	MOBILE TERMINATED ESTABLISHMENT OF RRC CONNECTION	"Mobile identity" IE contains the new TMSI (= TMSI1).
		→		"Establishment cause": Answer to paging.
23		→	PAGING RESPONSE	"Mobile identity" IE contains the new TMSI (= TMSI1).
24		←	RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.

Specific message contents

None.

## 9.2 Authentication

The purpose of this procedure is to verify the user identity. A correct response is essential to guarantee the establishment of the connection. If not, the connection will drop.

The SS shall be able to handle vectors of AUTN, RAND, CK, IK, AUTS and XRES in a similar way as the MSC/BSS entities. The SS shall incorporate a test algorithm for generating RES and CK, IK from RAND, AUTN and IK which operates as described in annex 4.

### 9.2.1 Authentication accepted

#### 9.2.1.1 Definition

#### 9.2.1.2 Conformance requirement

- 1) A UE shall correctly respond to an AUTHENTICATION REQUEST message by sending an AUTHENTICATION RESPONSE message with the RES information field set to the same value as the one produced by the authentication algorithm in the network.
- 2) A UE shall indicate in a PAGING RESPONSE message the ciphering key sequence number which was allocated to it through the authentication procedure.

Reference(s)

TS 24.008 Clause 4.3.2a.

#### 9.2.1.3 Test purpose

- 1) To check that a UE correctly responds to an AUTHENTICATION REQUEST message by sending an AUTHENTICATION RESPONSE message with the SRES information field set to the same value as the one produced by the authentication algorithm in the network.
- 2) To check that a UE indicates in a PAGING RESPONSE message the ciphering key sequence number which was allocated to it through the authentication procedure.

#### 9.2.1.4 Method of test

Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE has valid TMSI, CKSN (CKSN1), CK, IK. It is "idle updated" on the cell.

Related ICS/IXIT statement(s)

None.

Foreseen final state of the UE

The UE has valid TMSI, CKSN and CK, IK. It is "idle updated" on the cell.

## Test Procedure

The UE is paged. After the UE has sent a PAGING RESPONSE message to the SS, the SS initiates an authentication procedure and checks the value RES sent by the UE in the AUTHENTICATION RESPONSE message. The RRC CONNECTION is released. The UE is paged and the SS checks the value of the ciphering key sequence number sent by the UE in the PAGING RESPONSE message.

### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			Mobile terminated establishment of Radio Resource Connection	See TS 34.108 clause 7.1.2
2	→		PAGING RESPONSE	Establishment Cause: Answer to paging.
3	←		AUTHENTICATION REQUEST	CKSN = CKSN1
4	→		AUTHENTICATION RESPONSE	The SS initiates authentication with CKSN2 different from CKSN1.
5	←		RRC CONNECTION RELEASE	"Auth. parameter RES" IE shall be bit exact with the value as produced by the authentication algorithm.
6			Mobile terminated establishment of Radio Resource Connection	After the sending of this message, the SS waits for the disconnection of the main signalling link. The SS waits an amount of time which is enough to guarantee that the UE is in service.
7	→		PAGING RESPONSE	See TS 34.108 clause 7.1.2
8	←		RRC CONNECTION RELEASE	Establishment Cause: Answer to paging.
				"Ciphering key sequence number" shall be the same as the value that was sent in the last AUTHENTICATION REQUEST message (= CKSN2).
				After the sending of this message, the SS waits for the disconnection of the main signalling link.

### Specific message contents

None.

#### 9.2.1.5 Test requirement

FFS

## 9.2.2 Authentication rejected by the network

### 9.2.2.1 Definition

### 9.2.2.2 Conformance requirement

- 1) After reception of an Authentication Reject message the UE shall:
  - 1.1 not perform normal location updating;
  - 1.2 not perform periodic location updating;
  - 1.3 not respond to paging with TMSI;
  - 1.4 reject any request from CM entity for MM connection except for emergency call;
  - 1.5 not perform IMSI detach if deactivated.
- 2) After reception of an Authentication Reject message the UE, if it supports speech, shall accept a request for an emergency call by sending a RRC CONNECTION REQUEST message with the establishment cause set to "emergency call" and include an IMEI as mobile identity in the CM SERVICE REQUEST message.
- 3) After reception of an Authentication Reject message the UE shall delete the stored LAI, CKSN and TMSI.

## Reference(s)

TS 24.008 Clause 4.3.2.5.

### 9.2.2.3 Test purpose

- 1) To check that ,after reception of an Authentication Reject message, the UE:
  - 1.1 does not perform normal location updating;
  - 1.2 does not perform periodic location updating;
  - 1.3 does not respond to paging with TMSI;
  - 1.4 rejects any request from CM entity for MM connection except for emergency call;
  - 1.5 does not perform IMSI detach if deactivated.
- 2) To check that, after reception of an Authentication Reject message the UE, if it supports speech, accepts a request for an emergency call by sending a RRC CONNECTION REQUEST message with the establishment cause set to "emergency call" and includes an IMEI as mobile identity in the CM SERVICE REQUEST message.
- 3) To check that, after reception of an Authentication Reject message and after having been deactivated and reactivated, the UE performs location updating using its IMSI as mobile identity and indicates deleted LAI and CKSN.

### 9.2.2.4 Method of test

#### Initial conditions

- System Simulator:
  - two cells: A and B, belonging to different location areas a and b;
  - IMSI attach/detach is allowed in both cells;
  - the T3212 time-out value is 1/10 hour in both cells.
- User Equipment:
  - the UE has valid TMSI, CKSN (CKSN2) , CK and IK. It is "idle updated" on cell B.

#### Related ICS/IXIT statement(s)

USIM removal possible while UE is powered Yes/No.

Switch off on button Yes/No.

Support of speech Yes/No.

#### Foreseen final state of the UE

The UE has valid TMSI, CKSN (CKSN1), CK and IK. It is "idle updated" on cell A.

#### Test procedure

The SS rejects an authentication. The RRC CONNECTION is released. The SS checks that the UE has entered the state MM IDLE substate NO IMSI, i.e. does not perform normal location updating, does not perform periodic updating, does not respond to paging, rejects any requests from CM entities except emergency calls and does not perform IMSI detach if USIM detachment is performed, switch off is performed, or the power is removed, depending on the UE (see ICS/IXIT).

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
The following messages are sent and shall be received on cell B				
1			Mobile terminated establishment of Radio Resource Connection	See TS 34.108 clause 7.1.2
2	→		PAGING RESPONSE	Establishment Cause: Answer to paging. "Ciphering key sequence number" shall be the same as the value that was sent in the last AUTHENTICATION REQUEST message (= CKSN2).
3	←		AUTHENTICATION REQUEST	
4	→		AUTHENTICATION RESPONSE	
5	←		AUTHENTICATION REJECT	
6	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
9			Mobile terminated establishment of Radio Resource Connection	See TS 34.108 clause 7.1.2
10	UE			The UE is paged in cell B. "Mobile identity" IE contains TMSI.
11	SS			The UE shall ignore this message. This is verified during 3 seconds.
12	UE			The SS waits for at least for 15 s.
13	UE			A MO CM connection is attempted.
14	UE			The UE shall not initiate an RRC connection establishment on cell A or cell B. This is checked during 3 seconds.
15	→		RRC CONNECTION REQUEST	If the UE supports speech (see ICS), an emergency call is attempted.
16	←		RRC CONNECTION SETUP	"Establishment cause": Emergency call.
17	→		RRC CONNECTION COMPLETE	
18	→		CM SERVICE REQUEST	"CM service type": Emergency call establishment. "Mobile identity": type of identity is set to IMEI.
19	←		CM SERVICE ACCEPT	
20	→		EMERGENCY SETUP	
21	←		RELEASE COMPLETE	"Cause" = unassigned number.
22	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
The following messages are sent and shall be received on cell A.				
23	SS			The RF levels are changed to make the UE reselect the cell A.
24	UE			The UE performs cell reselection according to procedure as specified in (this however is not checked until step 29). The UE shall not initiate an RRC connection establishment on cell A or on cell B.
25	SS			The SS waits at least 7 minutes for a possible periodic updating.
26	UE			The UE shall not initiate an RRC connection establishment on cell A or on cell B.
27	UE			If possible (see ICS) USIM detachment is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed.
28	UE			The UE shall not initiate an RRC connection establishment on cell A or on cell B. This is checked during 3 seconds.
29	UE			Depending on what has been performed in step 26 the UE is brought back to operation.
30	→		RRC CONNECTION REQUEST	"Establishment cause": Location updating.
31	←		RRC CONNECTION SETUP	
32	→		RRC CONNECTION COMPLETE	
33	→		LOCATION UPDATING REQUEST	"location updating type" = normal, "CKSN" = no key available, "Mobile Identity" = IMSI, "LAI" = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE).
34	←		AUTHENTICATION REQUEST	"CKSN" = CKSN1.
35	→		AUTHENTICATION RESPONSE	
36	←		LOCATION UPDATING ACCEPT	"Mobile Identity" = TMSI.

37	→	TMSI REALLOCATION COMPLETE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
38	←	RRC CONNECTION RELEASE	

#### Specific message contents

None.

#### 9.2.2.5 Test requirement

FFS

### 9.2.3 Authentication rejected by the UE (MAC code failure)

#### 9.2.3.1 Definition

Following a UMTS authentication challenge, the MS may reject the core network, on the grounds of an incorrect AUTN parameter (see TS 33.102).

If the MS considers the MAC code (supplied by the core network in the AUTN parameter) to be invalid, it shall send an AUTHENTICATION FAILURE message to the network, with the failure cause 'MAC failure' (see 33.102).

#### 9.2.3.2 Conformance requirement

A UE shall correctly respond to an AUTHENTICATION REQUEST message with the failure cause 'MAC failure' by sending an AUTHENTICATION FAILURE message.

#### Reference(s)

TS 24.008 Clause 4.3.2.5.1, 4.3.2.6

#### 9.2.3.3 Test purpose

To check that a UE shall correctly respond to an AUTHENTICATION REQUEST message with the failure cause 'MAC failure' by sending an AUTHENTICATION FAILURE message.

#### 9.2.3.4 Method of test

##### Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE has valid TMSI, CKSN (CKSN1), CK, IK. It is "idle updated" on the cell.

##### Related ICS/IXIT statement(s)

None.

##### Test procedure

The UE rejects an authentication. The AUTHENTICATION FAILURE is sent by UE. Upon receipt of the AUTHENTICATION FAILURE message, the network stops the timer T3260. In MAC failure case, the procedural behaviour is ffs.



Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			Mobile terminated establishment of Radio Resource Connection	See TS 34.108 clause 7.1.2
2	→		PAGING RESPONSE	CKSN = CKSN1
3	←		AUTHENTICATION REQUEST	with the failure cause 'MAC code failure'
4	→		AUTHENTICATION FAILURE	with reject cause "MAC failure"
5	←		IDENTITY REQUEST	
6	→		IDENTITY RESPONSE(IMSI)	
7	←		AUTHENTICATION REQUEST	with the failure cause 'MAC code failure'
8	→		AUTHENTICATION FAILURE	with reject cause "MAC failure"

Specific message contents

None.

9.2.3.5 Test requirement

FFS

## 9.2.4 Authentication rejected by the UE (SQN failure)

9.2.4.1 Definition

Following a UMTS authentication challenge, the MS may reject the core network, on the grounds of an incorrect AUTN parameter (see TS 33.102).

If the MS considers the SQN (supplied by the core network in the AUTN parameter) to be out of range, it shall send a AUTHENTICATION FAILURE message to the network, with the failure cause 'Synch failure' and parameter(AUTS) provided by the USIM (see TS 33.102)

9.2.4.2 Conformance requirement

A UE shall correctly respond to an AUTHENTICATION REQUEST message with the failure cause 'Synch failure' and parameter(AUTS) provided by the USIM (see TS 33.102) by sending an AUTHENTICATION FAILURE message.

Reference(s)

TS 24.008 Clause 4.3.2.5.1, 4.3.2.6

9.2.4.3 Test purpose

To check that a UE shall correctly respond to an AUTHENTICATION REQUEST message with the failure cause 'Synch failure' and parameter(AUTS) provided by the USIM (see TS 33.102) by sending an AUTHENTICATION FAILURE message.

9.2.4.4 Method of test

Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE has valid TMSI, CKSN (CKSN1), CK, IK. It is "idle updated" on the cell.

## Related ICS/IXIT statement(s)

None.

## Test procedure

The UE rejects an authentication. The AUTHENTICATION FAILURE is sent by UE.

Upon receipt of the AUTHENTICATION FAILURE message, the network stops the timer T3260. In Synch failure case, the core network may renegotiate with the HLR/AuC and provide the MS with new authentication parameters.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			Mobile terminated establishment of Radio Resource Connection	See TS 34.108 clause 7.1.2
2	→		PAGING RESPONSE	CKSN = CKSN1
3	←		AUTHENTICATION REQUEST	with the failure cause 'Synch failure'
4	→		AUTHENTICATION FAILURE	<i>"Auth. parameter RES" IE shall be bit exact with the value as produced by the authentication algorithm.</i>
5	←		AUTHENTICATION REQUEST	with the failure cause 'Synch failure'
6	→		AUTHENTICATION FAILURE	<i>"Auth. parameter RES" IE shall be bit exact with the value as produced by the authentication algorithm.</i>

## Specific message contents

None.

## 9.2.4.5 Test requirement

FFS

## 9.3 Identification

The purpose of this procedure is to check that the UE gives its identity as requested by the network. If this procedure does not work, it will not be possible for the network to rely on the identity claimed by the UE.

### 9.3.1 General Identification

#### 9.3.1.1 Conformance requirement

- 1) When requested by the network the User Equipment shall send its IMSI.
- 2) When requested by the network the User Equipment shall send the TMSI which it was previously allocated.
- 3) When requested by the network the User Equipment shall send its IMEI as stored in the Mobile Equipment.
- 4) When requested by the network the User Equipment shall send its IMEISV as stored in the Mobile Equipment.

## Reference(s)

TS 24.008 Clause 4.3.3.

#### 9.3.1.2 Test purpose

- 1) To verify that the UE sends identity information as requested by the system in the following cases: IMSI and TMSI are requested in non-ciphered mode, IMEI is requested in ciphered mode.
- 2) To verify that the UE sends its IMEI, when requested to do so, in non-ciphered mode.
- 3) To verify that the UE sends its IMEISV, when requested to do so, in non-ciphered mode.

#### 9.3.1.3 Method of test

##### 9.3.1.3.1 Identification / test 1

##### Initial conditions

- System Simulator:
  - 1 cell, default values.
- User Equipment:
  - the UE has a valid TMSI. It is "idle updated" on the cell.

##### Related ICS/IXIT statement(s)

IMEI of the ME.

##### Foreseen final state of the UE

The UE has a valid TMSI. It is "idle updated" on the cell.

##### Test Procedure

The SS requests identity information from the UE:

- IMSI in non SECURITY mode;
- allocated TMSI in non SECURITY mode;
- IMEI in SECURITY mode.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		←	MOBILE TERMINATED ESTABLISHMENT OF RRC CONNECTION	Establishment Cause: Answer to paging.  "Identity type" IE is IMSI. "Mobile identity" IE specifies the IMSI of the UE. "Identity type" IE is TMSI. "Mobile identity" IE specifies the allocated TMSI of the UE.  "Identity type" IE is IMEI. "Mobile identity" IE specifies the IMEI stored in the Mobile Equipment. After the sending of this message, the SS waits for the disconnection of the main signalling link.
		→		
		←		
2		→	PAGING RESPONSE	
3		←	IDENTITY REQUEST	
4		→	IDENTITY RESPONSE	
5		←	IDENTITY REQUEST	
6		→	IDENTITY RESPONSE	
7		←	SECURITY MODE COMMAND	
8		→	SECURITY MODE COMPLETE	
9		←	IDENTITY REQUEST	
10		→	IDENTITY RESPONSE	
11		←	RRC CONNECTION RELEASE	

Specific message contents

None.

#### 9.3.1.3.2 Identification / test 2

Initial conditions

- System Simulator:
  - 1 cell, default values.
- User Equipment:
  - the UE has a valid TMSI. It is in "idle updated".

Related ICS/IXIT statement(s)

IMEI of the ME.

IMEISV of the ME.

Foreseen final state of the UE

The UE has a valid TMSI. It is "idle updated".

Test Procedure

The SS requests identity information from the UE:

- IMEI in non security mode;
- IMEISV in non security mode.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		←	MOBILE TERMINATED ESTABLISHMENT OF RRC CONNECTION	Establishment Cause: Answer to paging.
		→		
2		←	PAGING RESPONSE	"Identity type" IE is IMEI. "Mobile identity" IE specifies the IMEI of the UE. "Identity type" IE is IMEIS. "Mobile identity" IE specifies the IMEISV of the UE. After the sending of this message, the SS waits for the disconnection of the main signalling link.
3		→	IDENTITY REQUEST	
4		←	IDENTITY RESPONSE	
5		→	IDENTITY REQUEST	
6		←	IDENTITY RESPONSE	
7		→	RRC CONNECTION RELEASE	
		←		

Specific message contents

None.

## 9.3.2 Handling of IMSI shorter than the maximum length

### 9.3.2.1 Conformance requirement

The UE shall be capable of handling an IMSI that is not of the maximum length.

Reference(s)

TS 24.008 Clause 10.5.1.4.

### 9.3.2.2 Test purpose

To check that the UE behaves correctly when activated with an IMSI of length less than the maximum length.

In this condition, the UE shall:

- perform location updating;
- answer to paging with IMSI;
- give the correct IMSI when asked by an IDENTITY REQUEST;
- attempt CM connection establishment when requested to;
- attempt call re-establishment when needed;
- attempt IMSI detach when needed;
- erase its TMSI when the IMSI is sent by the network in a LOCATION UPDATING ACCEPT or a TMSI REALLOCATION COMMAND message.

### 9.3.2.3 Method of test

Initial conditions

- System Simulator:
- 1 cell, default values;

- IMSI attach/detach bit set to "1".
- User Equipment:
  - the UE has no valid TMSI;
  - it is "idle updated";
  - the IMSI has the value 001011234.

#### Related ICS/IXIT statement(s)

On/Off switch - Yes/No.

#### Foreseen final state of UE

The UE has no valid TMSI. It is in "idle, updated".

#### Test Procedure

The UE is paged with its IMSI. The UE shall answer to paging and include the correct IMSI in the PAGING RESPONSE message. During call establishment, the SS asks for the IMSI of the UE. The UE shall answer by an IDENTITY RESPONSE message including the correct IMSI. During the active phase of the call, the SS stops sending valid SACCH frames. The UE performs call re-establishment. The UE shall include the correct IMSI in the CM RE-ESTABLISHMENT message. A TMSI REALLOCATION COMMAND including a TMSI is sent to the UE. The UE acknowledges this message. The call is release.

The UE is paged with its TMSI. The UE shall answer to paging and includes its TMSI in the PAGING RESPONSE message. During call establishment, the SS sends a TMSI REALLOCATION COMMAND including the IMSI to the UE. The UE shall acknowledge this message. The UE shall erase its TMSI. The call is released.

The UE is switched off or has its power source removed. The UE performs IMSI detach. The UE shall include the correct IMSI in the IMSI DETACH INDICATION message.

The UE is switched on or powered on. The UE performs IMSI attach. The UE shall include the correct IMSI in the LOCATION UPDATING REQUEST message. A TMSI is allocated to the UE.

The LAC of the cell is changed. The UE performs location updating. The SS includes the IMSI in the LOCATION UPDATING ACCEPT message.

A mobile originated CM connection is attempted. The UE shall include the correct IMSI in the CM SERVICE REQUEST message.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		←	MOBILE TERMINATED ESTABLISHMENT OF RRC CONNECTION	"mobile identity 1" contains IMSI of UE.  Establishment cause: Answer to paging.
		→		
2		←	PAGING RESPONSE	"mobile identity" contains the IMSI of the UE.
3		→	IDENTITY REQUEST	"identity type" IE is IMSI.
4		←	IDENTITY RESPONSE	"mobile identity" IE contains the IMSI of the UE.
5				The call is established using the sequence of the generic terminating call set-up procedure.
6	SS			The SS stops sending valid SACCH frames.
7		→	RRC CONNECTION REQUEST	
8		←	RRC CONNECTION SETUP	
9		→	CM REESTABLISHMENT REQUEST	"mobile identity" IE contains IMSI of the UE.
10		←	TMSI REALLOCATION COMMAND	"mobile identity" contains a TMSI.
11		→	TMSI REALLOCATION COMPLETE	
12		←	RRC CONNECTION RELEASE	After sending this message, the SS waits for the disconnection of the main signalling link.
13		←	MOBILE TERMINATED ESTABLISHMENT OF RRC CONNECTION	"mobile identity 1" contains TMSI of UE.  Establishment cause: Answer to paging.
		→		
14		←	PAGING RESPONSE	"mobile identity" contains the TMSI of the UE.
15		→	AUTHENTICATION REQUEST	
16		←	AUTHENTICATION RESPONSE	
17		→	TMSI REALLOCATION COMMAND	"mobile identity" contains a IMSI of UE.
18		→	TMSI REALLOCATION COMPLETE	
19		←	RRC CONNECTION RELEASE	
20	UE			If possible (see ICS) the UE is switched off, otherwise the UE has its power source removed.
21		→	RRC CONNECTION REQUEST	If the UE was switched off it performs IMSI detach.
22		←	RRC CONNECTION SETUP	
23		→	IMSI DETACH INDICATION	"mobile identity" contains IMSI of UE.
24		←	RRC CONNECTION RELEASE	
25	UE			The UE is switched on or has power restored.
26		→	RRC CONNECTION REQUEST	
27		←	RRC CONNECTION SETUP	
28		→	LOCATION UPDATING REQUEST	"mobile identity" contains IMSI of UE.
29		←	LOCATION UPDATING ACCEPT	"mobile identity" contains a TMSI.
30		→	TMSI REALLOCATION COMPLETE	
31		←	RRC CONNECTION RELEASE	
32	SS			The SS changes the LAC of the cell.
33		→	RRC CONNECTION REQUEST	Shall be sent within 35s of the LAC being changed.
34		←	RRC CONNECTION SETUP	
35		→	LOCATION UPDATING REQUEST	"mobile identity" contains TMSI of the UE.

36	←	LOCATION UPDATING ACCEPT	"mobile identity" contains IMSI of the UE.
37	←	RRC CONNECTION RELEASE	a mobile originated CM connection is attempted.
38	UE		
39	→	RRC CONNECTION REQUEST	
40	←	RRC CONNECTION SETUP	"mobile identity" contains IMSI of the UE.
41	→	CM SERVICE REQUEST	
42	←	RRC CONNECTION RELEASE	

Specific message contents

None.

## 9.4 Location updating

This procedure is used to register the UE in the network. If it is not performed correctly, no call can be established.

### 9.4.1 Location updating / accepted

#### 9.4.1.1 Conformance requirement

1.
  - 1.1 if the network accepts a location updating from the User Equipment and reallocates a TMSI in the Location Updating Accept message the User Equipment shall acknowledge the reception of the new TMSI;
  - 1.2 the User Equipment shall answer to paging with this TMSI and include it in a Paging Response message.
- 2 If the network accepts a location updating from the User Equipment and the Location Updating Accept message contains neither TMSI nor IMSI, the User Equipment shall answer to paging when addressed with the last allocated TMSI and include it in the Paging Response message.
3.
  - 3.1 if the network accepts a location updating from the User Equipment by use of a Location Updating Accept message containing the IMSI of the User Equipment, the User Equipment shall not answer paging with the last allocated TMSI;
  - 3.2 the User Equipment shall still answer paging with IMSI.
4. A User Equipment that supports either:
  - may ignore SYSTEM INFORMATION TYPE [T.B.D.] messages ; if it does so it shall assume that the SYSTEM INFORMATION TYPE 2 carries the complete BA, for selection of the cell , where it performs the location updating procedure.

This SYSTEM INFORMATION TYPE [T.B.D.] message may be sent by the network with either a L2 pseudo length of 18 or some other value.

See TS 24.008 Clauses 9.1.34 and 3.2.2.1.

Reference(s)

TS 24.008 Clause 4.4.4.6.

#### 9.4.1.2 Test purpose

- 1) To test the behaviour of the UE if the network accepts the location updating of the UE.



For the network response three different cases are identified:

- 1.1) TMSI is allocated;
- 1.2) location updating accept contains neither TMSI nor IMSI;
- 1.3) location updating accept contains IMSI.

#### 9.4.1.3 Method of test

##### 9.4.1.3.1 Location Updating/accepted/test1

Initial conditions:

- System Simulator:
  - two cells, A and B, belonging to different location areas with location area identification a and b of the same PLMN;
  - IMSI attach/detach is allowed in both cells;
  - the T3212 time-out value is 1/10 hour in both cells.
- User Equipment:
  - the UE has a valid TMSI (=TMSI1) and CKSN (=CKSN1). It is "idle updated" on cell A.

Related ICS/IXIT statement(s)

None.

Foreseen final state of the UE

The UE has no valid TMSI. It has valid CKSN and Kc. It is "idle, updated" on cell B.

#### Test Procedure

The UE is made to select cell B. A normal location updating with TMSI reallocation is performed in cell B. The RRC CONNECTION is released. The SS checks, by paging, that the UE has stored the newly allocated TMSI. The RRC CONNECTION is released. The UE is made to select cell A. A normal location updating is performed in cell A. The LOCATION UPDATING ACCEPT message contains neither IMSI nor TMSI. The SS checks, by paging, that the UE has kept the old TMSI. The RRC CONNECTION is released. The UE is made to select cell B. A normal location updating is performed in cell B. The LOCATION UPDATING ACCEPT message contains an IMSI. The SS checks, by paging, that the UE has deleted its TMSI and responds to paging with IMSI.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		The RF level of cell A is lowered until the UE selects cell B.
2	→		RRC CONNECTION REQUEST	"Establishment cause": Location updating.
3	←		RRC CONNECTION SETUP	
4	→		LOCATION UPDATING REQUEST	"location updating type" = normal, "CKSN" = CKSN1, "location area identification" = a, "mobile station classmark 1" as given by the ICS and "mobile identity" = TMSI1.
5	←		LOCATION UPDATING ACCEPT	"Mobile identity" = new TMSI (=TMSI2), LAI = b.
6	→		TMSI REALLOCATION COMPLETE	
7	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link. The SS waits an amount of time which is enough to guarantee that the UE is in service.
8	←		MOBILE TERMINATED ESTABLISHMENT OF RRC CONNECTION	"Mobile identity" IE contains the new TMSI (= TMSI2).
	→			
9	→		PAGING RESPONSE	"Mobile identity" IE contains the new TMSI (= TMSI2).
10	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
11		SS		The RF level of cell B is lowered until the UE selects cell A.
12	→		RRC CONNECTION REQUEST	"Establishment cause": Location updating
13	←		RRC CONNECTION SETUP	
14	→		LOCATION UPDATING REQUEST	"location updating type" = normal, "CKSN" = CKSN1, "location area identification" = b, "mobile station classmark 1" as given by the ICS and "mobile identity" = TMSI2.
15	←		LOCATION UPDATING ACCEPT	"Mobile identity" IE not included.
16	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link. The SS waits an amount of time which is enough to guarantee that the UE is in service.
17	←		MOBILE TERMINATED ESTABLISHMENT OF RRC CONNECTION	"Mobile identity" IE contains the TMSI (= TMSI2).
	→			
	←			
18	→		PAGING RESPONSE	"Mobile identity" IE contains the TMSI (=TMSI2).
19	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
20		SS		The RF level of cell A is lowered until the UE selects cell B.
21	→		RRC CONNECTION REQUEST	"Establishment cause": Location updating.
22	←		RRC CONNECTION SETUP	
23	→		LOCATION UPDATING REQUEST	"location updating type" = normal, "CKSN" = CKSN1, "location area identification" = a, "mobile station classmark 1" as given by the ICS and "mobile identity" = TMSI2.
24	←		LOCATION UPDATING ACCEPT	"Mobile identity" IE contains IMSI.
25	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link. The SS waits an amount of time which is enough to guarantee that the UE is in service.

26	←	MOBILE TERMINATED ESTABLISHMENT OF RRC CONNECTION	"Mobile identity" IE contains the old TMSI (= TMSI2).
27	UE		The UE shall ignore this message. This is checked during 5 seconds.
28	←	MOBILE TERMINATED ESTABLISHMENT OF RRC CONNECTION	"Mobile identity" IE contains the IMSI.
	→		
29	←	PAGING RESPONSE	"Mobile identity" IE contains the IMSI.
30	←	RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.

#### Specific message contents

None.

#### 9.4.1.3.2 Location Updating/accepted/test2

##### Initial conditions

- System Simulator:
  - two cells, A and B, belonging to different location areas with location area identification a and b of the same PLMN.
  - System information2ter is broadcasted on the two cells (Cell A with L2pseudolength=18, Cell B with L2pseudolength=0):
    - IMSI attach/detach is allowed in both cells;
    - the T3212 time-out value is 1/10 hour in both cells.
- User Equipment:
  - the UE has a valid TMSI (=TMSI1) and CKSN (=CKSN1). It is "idle updated" on cell A.

##### Related ICS/IXIT statement(s)

None.

##### Foreseen final state of the UE

The UE has no valid TMSI. It has valid CKSN and Kc. It is "idle, updated" on cell B.

##### Test Procedure

The UE is made to select cell B. A normal location updating with TMSI reallocation is performed in cell B. The RRC CONNECTION is released. The SS checks, by paging, that the UE has stored the newly allocated TMSI. The RRC CONNECTION is released. The UE is made to select cell A. A normal location updating is performed in cell A. The LOCATION UPDATING ACCEPT message contains neither IMSI nor TMSI. The SS checks, by paging, that the UE has kept the old TMSI. The RRC CONNECTION is released. The UE is made to select cell B. A normal location updating is performed in cell B. The LOCATION UPDATING ACCEPT message contains an IMSI. The SS checks, by paging, that the UE has deleted its TMSI and responds to paging with IMSI.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		The RF level of cell A is lowered until the UE selects cell B.
2	→		RRC CONNECTION REQUEST	"Establishment cause": Location updating.
3	←		RRC CONNECTION SETUP	
4	→		LOCATION UPDATING REQUEST	"location updating type" = normal, "CKSN" = CKSN1, "location area identification" = a, "mobile station classmark 1" as given by the ICS and "mobile identity" = TMSI1.
5	←		LOCATION UPDATING ACCEPT	"Mobile identity" = new TMSI (=TMSI2), LAI = b.
6	→		TMSI REALLOCATION COMPLETE	
7	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link. The SS waits an amount of time which is enough to guarantee that the UE is in service.
8	←		MOBILE TERMINATED ESTABLISHMENT OF RRC CONNECTION	"Mobile identity" IE contains the new TMSI (= TMSI2).
	→			
9	←		PAGING RESPONSE	"Mobile identity" IE contains the new TMSI (= TMSI2).
10	→		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
11		SS		The RF level of cell B is lowered until the UE selects cell A.
12	→		RRC CONNECTION REQUEST	"Establishment cause": Location updating
13	←		RRC CONNECTION SETUP	
14	→		LOCATION UPDATING REQUEST	"location updating type" = normal, "CKSN" = CKSN1, "location area identification" = b, "mobile station classmark 1" as given by the ICS and "mobile identity" = TMSI2.
15	←		LOCATION UPDATING ACCEPT	"Mobile identity" IE not included.
16	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link. The SS waits an amount of time which is enough to guarantee that the UE is in service.
17	←		MOBILE TERMINATED ESTABLISHMENT OF RRC CONNECTION	"Mobile identity" IE contains the TMSI (= TMSI2).
	→			
18	←		PAGING RESPONSE	"Mobile identity" IE contains the TMSI (=TMSI2).
19	→		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
20		SS		The RF level of cell A is lowered until the UE selects cell B.
21	→		RRC CONNECTION REQUEST	"Establishment cause": Location updating.
22	←		RRC CONNECTION SETUP	
23	→		LOCATION UPDATING REQUEST	"location updating type" = normal, "CKSN" = CKSN1, "location area identification" = a, "mobile station classmark 1" as given by the ICS and "mobile identity" = TMSI2.
24	←		LOCATION UPDATING ACCEPT	"Mobile identity" IE contains IMSI.
25	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link. The SS waits an amount of time which is enough to guarantee that the UE is in service.

26	←	MOBILE TERMINATED ESTABLISHMENT OF RRC CONNECTION	"Mobile identity" IE contains the old TMSI (= TMSI2).
27	UE		The UE shall ignore this message. This is checked during 5 seconds.
28	←	MOBILE TERMINATED ESTABLISHMENT OF RRC CONNECTION	"Mobile identity" IE contains the IMSI.
	→		
29	←	PAGING RESPONSE	"Mobile identity" IE contains the IMSI.
30	←	RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.

Specific message contents: [T.B.D.]

## 9.4.2 Location updating / rejected

### 9.4.2.1 Location updating / rejected / IMSI invalid

#### 9.4.2.1.1 Conformance requirement

- 1) If the network rejects a location updating from the User Equipment with the cause "IMSI unknown in HLR", "Illegal UE" or "Illegal ME" the User Equipment shall:
  - 1.1 not perform normal location updating;
  - 1.2 not perform periodic location updating;
  - 1.3 not respond to paging with IMSI;
  - 1.4 not respond to paging with TMSI;
  - 1.5 reject any request from CM entity for MM connection other than for emergency call;
  - 1.6 not perform IMSI detach if it is switched off or has its power source removed.
- 2) If the network rejects a location updating from the User Equipment with the cause "IMSI unknown in HLR", "Illegal UE" or "Illegal ME" the User Equipment, if it supports speech, shall accept a request for an emergency call by sending a RRC CONNECTION Request message with the establishment cause set to "emergency call" and include an IMEI as mobile identity in the CM SERVICE REQUEST message.
- 3) If the network rejects a location updating from the User Equipment with the cause "IMSI unknown in HLR", "Illegal UE" or "Illegal ME" the User Equipment shall delete the stored LAI, CKSN and TMSI.

#### Reference(s)

TS 24.008 Clause 4.4.4.7.

#### 9.4.2.1.2 Test purpose

To test the behaviour of the UE if the network rejects the location updating of the UE with the cause "IMSI unknown in HLR", "illegal UE" or "Illegal ME".

#### 9.4.2.1.3 Method of test

##### Initial conditions

- System Simulator:
  - two cells: A and B, belonging to different location areas of the same PLMN;
  - IMSI attach/detach is allowed in both cells;
  - the T3212 time-out value is 1/10 hour in both cells.
- User Equipment:
  - the UE has valid TMSI, CKSN and Kc. It is "idle updated" on cell A.

##### Related ICS/IXIT statement(s)

SIM removal possible while the UE is powered Yes/No.

Switch off on button Yes/No.

Support for speech Yes/No.

##### Foreseen final state of the UE

The UE has valid TMSI, CKSN and Kc. It is "idle updated" on cell A.

##### Test Procedure

The SS rejects a normal location updating with the cause value "IMSI unknown in HLR". The RRC CONNECTION is released. The SS checks that the UE has entered the state MM IDLE and the substate NO IMSI, i.e. does not perform normal location updating when a new cell of the same or another PLMN is entered, does not perform periodic updating, does not respond to paging, rejects any requests from CM entities except emergency calls and does not perform IMSI detach if it is switched off or has its power source removed.

The test is repeated with cause value "Illegal UE" and with cause value "Illegal ME".

## Expected sequence

The sequence is executed for execution counter  $k = 1, 2, 3$ .

Step	Direction		Message	Comments
	UE	SS		
1		SS		<p>The following messages are sent and shall be received on cell B. The RF level of cell A is lowered until the UE selects cell B. "Establishment cause": Location updating.</p> <p>"Reject cause" IE is "IMSI unknown in HLR" for <math>k = 1</math>, "Illegal UE" for <math>k = 2</math>, "Illegal ME" for <math>k = 3</math>. After the sending of this message, the SS waits for the disconnection of the main signalling link.</p>
2	→		RRC CONNECTION REQUEST	
3	←		RRC CONNECTION SETUP	
4	→		LOCATION UPDATING REQUEST	
5	←		LOCATION UPDATING REJECT	
6	→		RRC CONNECTION RELEASE	
7		SS		<p>The following messages are sent and shall be received on cell A. The RF levels are then changed again to make the UE reselect the cell A. The UE performs cell reselection according to procedure as specified in (this however is not checked until step 18). The UE shall not initiate an RRC connection establishment on cell A or on cell B.</p>
8		UE		
9		SS		<p>The SS waits at least 7 minutes for a possible periodic updating. The UE shall not initiate an RRC connection establishment on cell A or on cell B.</p>
10		UE		
11	←		MOBILE TERMINATED ESTABLISHMENT OF RRC CONNECTION	<p>The UE is paged in cell A. "Mobile identity" IE contains IMSI.</p> <p>The UE shall ignore this message. This is verified during 3 seconds.</p>
12		UE		
13	←		MOBILE TERMINATED ESTABLISHMENT OF RRC CONNECTION	<p>The UE is paged in cell A. "Mobile identity" IE contains TMSI.</p> <p>The UE shall ignore this message. This is verified during 3 seconds.</p>
14		UE		
15		UE		<p>A MO CM connection is attempted. The UE shall not initiate an RRC connection establishment on cell A or on cell B. This is checked during 3 seconds.</p>
16		UE		
17	→		CM SERVICE REQUEST	<p>If the UE supports speech (see ICS), it is made to perform an emergency call. "Establishment cause": Emergency call. This message is sent in cell A.</p> <p>"CM service type": Emergency call establishment. "Mobile identity": type of identity is set to IMEI.</p> <p>"Cause" = unassigned number. After the sending of this message, the SS waits for the disconnection of the main signalling link.</p>
18	←			
19	→			
20	←			
21	→			
22	←			
23	←			
24		UE		<p>If possible (see ICS) SIM detachment is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed. The UE shall not initiate an RRC connection establishment on cell A or on cell B. This is checked during 3 seconds.</p>
		UE		

25	UE		Depending on what has been performed in step 25 the UE is brought back to operation.
26	→	RRC CONNECTION REQUEST	"Establishment cause": Location updating.
27	←	RRC CONNECTION SETUP	
28	→	LOCATION UPDATING REQUEST	"location updating type" = normal, "CKSN" = no key available, "mobile station classmark 1" as given by the ICS, "Mobile Identity" = IMSI, "LAI" = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE).
29	←	AUTHENTICATION REQUEST	"CKSN" = CKSN1.
30	→	AUTHENTICATION RESPONSE	
31	←	LOCATION UPDATING ACCEPT	"Mobile Identity" = TMSI.
32	→	TMSI REALLOCATION COMPLETE	
33	←	RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.

#### Specific message contents

None.

### 9.4.2.2 Location updating / rejected / PLMN not allowed

#### 9.4.2.2.1 Conformance requirement

- 1) If the network reject a location updating from the User Equipment with the cause "PLMN not allowed" the User Equipment shall:
  - 1.1 not perform periodic updating;
  - 1.2 not perform IMSI detach when switched off;
  - 1.3 not perform IMSI attach when switched on in the same location area;
  - 1.4 not perform normal location updating when in the same PLMN and when that PLMN is not selected manually;
  - 1.5 reject any request from CM entity for MM connection other than for emergency call.
- 2) If the network rejects a location updating from the User Equipment with the cause "PLMN not allowed" the User Equipment shall:
  - 2.1 perform normal location updating when a new PLMN is entered;
  - 2.2 accept a request for an emergency call, if it supports speech, by sending a RRC CONNECTION Request message with the establishment cause set to "emergency call".
- 3) If the network rejects a location updating from the User Equipment with the cause "PLMN not allowed" and if after that the PLMN from which this rejection was received, is manually selected, the User Equipment shall perform a normal location updating procedure.

#### Reference(s)

TS 24.008 Clause 4.4.4.7.

#### 9.4.2.2.2 Test purpose

To test the behaviour of the UE if the network rejects the location updating of the UE with the cause "PLMN not allowed".



#### 9.4.2.2.3 Method of test

##### 9.4.2.2.3.1 Location updating / rejected / PLMN not allowed / test 1

#### Initial conditions

- System Simulator:
  - one cell: C, belonging to PLMN1;
  - two cells: A and B, belonging to different location areas a and b and belonging to PLMN2. PLMN2 is different from HPLMN and from PLMN1;
  - IMSI attach/detach is allowed in cells A and B but not in cell C;
  - the T3212 time-out value is 1/10 hour in cells A and B.
- User Equipment:
  - the UE has a valid TMSI. It is "idle updated" on cell C;
  - the UE is in manual mode for PLMN selection.

#### Related ICS/IXIT statement(s)

SIM removal possible while the UE is powered Yes/No.

Switch off on button Yes/No.

The UE is automatically in automatic mode after switch on Yes/No.

Support for speech Yes/No.

#### Foreseen final state of the UE

The UE has a valid TMSI. It is "idle updated" on cell C. The UE is in automatic mode for PLMN selection.

#### Test Procedure

The SS rejects a normal location updating with the cause value "PLMN not allowed". The RRC CONNECTION is released. The SS checks that the UE does not perform periodic updating, does not perform IMSI detach, does not perform IMSI attach if activated in the same location area, rejects any request for CM connection establishment other than emergency call, accepts a request for an emergency call and performs normal location updating only when a new PLMN is entered.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE		RRC CONNECTION REQUEST RRC CONNECTION SETUP LOCATION UPDATING REQUEST LOCATION UPDATING REJECT RRC CONNECTION RELEASE	The following messages are sent and shall be received on cell B. The UE is switched off (or power is removed). The SS activates cells A and B and deactivates cell C. Cell B has a level higher by at least 5 dB than cell A. The UE is switched on. (or power is reapplied) If necessary the UE is put in manual selection mode. The UE shall offer the new PLMN as available to the user. The PLMN is manually selected. "Establishment cause": Location updating.  "Reject cause" = PLMN not allowed. After the sending of this message, the SS waits for the disconnection of the main signalling link.
2	SS			
3	UE			
4	→SS			
5	←			
6	→			
7	←			
8	←			
9		SS		The SS waits for a possible periodic updating for 7 minutes.
10		UE		The UE shall not initiate an RRC connection establishment on cell A or on cell B.
11		UE		If possible (see ICS) SIM detachment is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed.
12		UE		The UE shall not initiate an RRC connection establishment on cell A or on cell B. This is checked during 3 seconds.
13		UE		Depending on what has been performed in step 11 the UE is brought back to operation. The UE is not made to select PLMN 2.
14		UE		The UE shall not initiate an RRC connection establishment. This is checked during 3 seconds.
15		SS		The following message are sent and shall be received on cell A.
16		UE		The RF level of cell B is lowered to make the UE reselect cell A. No access to the network shall be registered by the SS within one minute.
17		UE		If the UE supports speech (see ICS) it is made to perform an emergency.
18	→		RRC CONNECTION REQUEST RRC CONNECTION SETUP CM SERVICE REQUEST CM SERVICE ACCEPT EMERGENCY SETUP RELEASE COMPLETE RRC CONNECTION RELEASE	"Establishment cause": Emergency call.
19	←			
20	→			"CM service type" = Emergency call establishment.
21	←			
22	→			
23	←			Cause IE: "unassigned number".
24	←			After the sending of this message, the SS waits for the disconnection of the main signalling link.
25		UE		A MO CM connection is attempted.
26		UE		The UE shall not initiate an RRC connection establishment. This is checked during 3 seconds.
27	UE		RRC CONNECTION REQUEST RRC CONNECTION SETUP	The following messages are sent and shall be received on cell C. The UE is switched off. The SS activates cell C and deactivates cells A and B. The UE is switched on. If necessary the UE is placed into the automatic mode. "Establishment cause": Location updating.
28	SS			
29	UE			
30	→			
31	←			

32	→	LOCATION UPDATING REQUEST	"location updating type" = normal, "CKSN" = no key available, "LAI" = deleted LAI (the MCC and MNC hold the values of PLMN1, the LAC is coded FFFE) "mobile identity" = IMSI.
33	←	LOCATION UPDATING ACCEPT	"Mobile identity" = TMSI.
34	→	TMSI REALLOCATION COMPLETE	
35	←	RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.

Specific message contents:

None.

#### 9.4.2.2.3.2 Location updating / rejected / PLMN not allowed / test 2

Initial conditions

- System Simulator:
  - one cell C, belonging to PLMN1;
  - two cells A and B, belonging to different location areas a and b and belonging to PLMN2. PLMN2 is different from HPLMN;
  - IMSI attach/detach is allowed in cells A and B but not in cell C;
  - the T3212 time-out value is 1/10 hour in cells A and B.
- User Equipment:
  - the UE has a valid TMSI. It is "idle updated" on cell C.

Related ICS/IXIT statement(s)

SIM removal possible while UE is powered Yes/No.

Switch off on button Yes/No.

The UE is automatically in automatic mode after switch on Yes/No.

Foreseen final state of the UE

The UE has a valid TMSI. It is "idle, updated" on cell C.

The UE is in automatic mode for PLMN selection.

Test Procedure

The SS rejects a normal location updating with the cause value "PLMN not allowed". The RRC CONNECTION is released. Then the PLMN from which this rejection was received is manually selected and the SS checks that a normal location updating is performed.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The following messages are sent and shall be received on cell B. The UE is switched off (or power is removed).
2	SS			
3	UE			The SS activates cells A and B and deactivates cell C. Cell B has a level higher by at least 5 dB than cell A. The UE is switched on (or power is reapplied). If the UE is in manual mode, it shall offer the new PLMN as available to the user. In this case the PLMN is manually selected.
3a	UE			
4	→		RRC CONNECTION REQUEST	"Establishment cause": Location updating.
5	←		RRC CONNECTION SETUP	
6	→		LOCATION UPDATING REQUEST	"Reject cause" = PLMN not allowed. After the sending of this message, the SS waits for the disconnection of the main signalling link.
7	←		LOCATION UPDATING REJECT	
8	←		RRC CONNECTION RELEASE	The UE is made to search for PLMNs and the PLMN indicated by the SS is manually selected. "Establishment cause": Location updating.
9	UE			
10	→		RRC CONNECTION REQUEST	"location updating type" = normal, "CKSN" = no key available, "LAI" = deleted LAI (the MCC and MNC hold the values of PLMN1, the LAC is coded FFFE) "mobile identity" = IMSI.
11	←		RRC CONNECTION SETUP	
12	→		LOCATION UPDATING REQUEST	After the sending of this message, the SS waits for the disconnection of the main signalling link. The following messages are sent and shall be received on cell C. The UE is switched off. The SS activates cell C and deactivates cells A and B. The UE is switched on. If necessary, the UE is put into the automatic mode.
13	←		RRC CONNECTION RELEASE	
14	UE			"Establishment cause": Location updating.
15	SS			
16	UE			"location updating type" = normal, "CKSN" = no key available, "LAI" = deleted LAI (the MCC and MNC hold the values of PLMN1, the LAC is coded FFFE) "mobile identity" = IMSI.
17	→		RRC CONNECTION REQUEST	
18	←		RRC CONNECTION SETUP	"Mobile identity" = TMSI.
19	→		LOCATION UPDATING REQUEST	
20	←		LOCATION UPDATING ACCEPT	After the sending of this message, the SS waits for the disconnection of the main signalling link.
21	→		TMSI REALLOCATION COMPLETE	
22	←		RRC CONNECTION RELEASE	

## Specific message contents

None.

## 9.4.2.3 Location updating / rejected / location area not allowed

## 9.4.2.3.1 Conformance requirement

- 1) If the network rejects a location updating from the User Equipment with the cause "Location Area not allowed" the User Equipment shall:

- 1.1 not perform periodic updating;
- 1.2 not respond to paging with TMSI;
- 1.3 reject any request from CM entity for MM connection other than for emergency call;

1.4 not perform IMSI detach.

2) If the network rejects a location updating from the User Equipment with the cause "Location Area not allowed" the User Equipment shall:

2.1 perform normal location updating when a new location area is entered;

2.2 accept a request for an emergency call, if it supports speech, by sending a RRC CONNECTION Request message with the establishment cause set to "emergency call";

2.3 delete the list of forbidden LAs after switch off (power off).

#### Reference(s)

TS 24.008 Clause 4.4.4.7.

#### 9.4.2.3.2 Test purpose

To test the behaviour of the UE if the network rejects the location updating of the UE with the cause "Location Area not allowed".

To test that the UE deletes the list of forbidden LAs after switch off (power off).

#### 9.4.2.3.3 Method of test

##### Initial conditions

- System Simulator:
  - two cells: A and B, belonging to different location areas a and b;
  - IMSI attach/detach is allowed in both cells;
  - the T3212 time-out value is 1/10 hour in both cells.
- User Equipment:
  - the UE has a valid TMSI. It is "idle updated" on cell A.

##### Related ICS/IXIT statement(s)

Switch off on button Yes/No.

Support for speech Yes/No.

Method to clear the list of forbidden location areas periodically.

##### Foreseen final state of the UE

The UE has a valid TMSI. It is "idle updated" on cell A.

##### Test Procedure

The SS rejects a normal location updating with the cause value "Location Area not allowed". The RRC CONNECTION is released. The SS checks that the UE does not perform periodic updating, does not respond to paging with TMSI, rejects any requests from CM entities for MM-connections except emergency calls, does not perform IMSI detach, performs normal location updating when a new location area is entered and deletes the list of forbidden LAs when switched off.

Different types of UE may use different methods to periodically clear the list of forbidden location areas (e.g. every day at 12am). If the list is cleared while the test is being run, it may be necessary to re-run the test.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		The following messages are sent and shall be received on cell B. The RF level of cell A is lowered so that cell B is selected, while keeping the C1 and C2 of cell A greater than 10.
2	→		RRC CONNECTION REQUEST	"Establishment cause": Location updating.
3	←		RRC CONNECTION SETUP	
4	→		LOCATION UPDATING REQUEST	
5	←		LOCATION UPDATING REJECT	"Reject cause" = "Location Area not allowed".
6	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the mainsignalling link. The SS waits for a possible location updating for 7 minutes.
7		SS		The UE shall not initiate an RRC-connection establishment either on cell A or cell B.
8		UE		The UE is paged in cell B. "Mobile identity" = TMSI.
9	←		MOBILE TERMINATED ESTABLISHMENT OF RRC CONNECTION	
10		UE		The UE shall ignore this message. This is checked during 3 seconds.
11		UE		A MO CM connection is attempted.
12		UE		The UE shall not initiate an RRC connection establishment on cell A or cell B. This is checked during 3 seconds.
13		UE		If the UE supports speech (see ICS), it is made to perform an emergency call.
	→			"Establishment cause": Emergency call.
14	→		CM SERVICE REQUEST	
15	←		CM SERVICE ACCEPT	"CM service type": Emergency call establishment.
16	→		EMERGENCY SETUP	
17	←		RELEASE COMPLETE	Cause: "unassigned number".
18	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
19		UE		If possible (see ICS) switch off is performed. Otherwise the power is removed.
20		UE		The UE shall not initiate an RRC connection establishment on cell A or on cell B (check for IMSI detach) This is checked during 3 seconds.
21		UE		Depending on what has been performed in step 21 the UE is brought back to operation.
22	→		RRC CONNECTION REQUEST	"Establishment cause": Location updating.
23	←		RRC CONNECTION SETUP	
24	→		LOCATION UPDATING REQUEST	"location updating type" = normal, "CKSN" = no key available, "LAI" = deleted LAI, "mobile identity" = IMSI (This checks the deletion of the forbidden lists)
25	←		LOCATION UPDATING REJECT	"Reject cause" = "Location Area not allowed".
26	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link. The following messages are sent and shall be received on cell A.
27		SS		The RF level of cell B is lowered until the UE selects cell A.
28	→		RRC CONNECTION REQUEST	"Establishment cause": Location updating.
29	←		RRC CONNECTION SETUP	
30	→		LOCATION UPDATING REQUEST	
31	←		AUTHENTICATION REQUEST	
32	→		AUTHENTICATION RESPONSE	
33	←		LOCATION UPDATING ACCEPT	Mobile identity = TMSI.
34	→		TMSI REALLOCATION COMPLETE	

35	←	RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
----	---	------------------------	--

#### Specific message contents

None.

### 9.4.2.4 Location updating / rejected / roaming not allowed in this location area

#### 9.4.2.4.1 Conformance requirement

- 1) If the network rejects a location updating from the User Equipment with the cause "Roaming not allowed in this area" the User Equipment shall:
  - 1.1 not perform periodic updating;
  - 1.2 not respond to paging with TMSI;
  - 1.3 reject any request from CM entity for MM connection other than for emergency call;
  - 1.4 not perform IMSI detach.
- 2) If the network rejects a location updating from the User Equipment with the cause "Roaming not allowed in this area" the User Equipment shall:
  - 2.1 perform normal location updating when a new location area is entered;
  - 2.2 accept a request for an emergency call, if it supports speech, by sending a RRC CONNECTION Request message with the establishment cause set to "emergency call";
  - 2.3 periodically search for its HPLMN.
- 3) The User Equipment shall reset the list of "Forbidden location areas for roaming" when it is switched off or has its power source removed or when the SIM is removed.
- 4) The UE shall be capable of storing at least 6 entries in the list of "Forbidden location areas for roaming".

#### Reference(s)

TS 24.008 Clause 4.4.4.7.

#### 9.4.2.4.2 Test purposes

##### Test purpose 1

To test that on receipt of a rejection using the Roaming cause code, the UE ceases trying to update on that cell, that this situation continues for at least one periodic location interval period, and that the corresponding list is re-set by switching off the UE or removing its power source.

##### Test purpose 2

To test that if no cell is available, the UE does not answer to paging with TMSI, rejects a request from CM entity other than for emergency calls.

##### Test purpose 3

To test that at least 6 entries can be held in the list of "forbidden location areas for roaming" (the requirement is to store at least 10 entries. This is not fully tested by the third procedure).

#### Test purpose 4

To test that if a cell of the Home PLMN is available then the UE returns to it in preference to any other available cell.

#### Test purpose 5

To test that if the SIM is removed the list of "forbidden location areas for roaming" is cleared.

#### 9.4.2.4.3 Method of test

##### Initial conditions

The initial conditions shall be met before each of the different procedures.

- System Simulator:
  - for procedures 1, 2, 3 and 5: Two cells A and B, belonging to different location areas of the same PLMN with LAI a and b. The MCC of that PLMN is the same as that of the HPLMN. The MNC of that PLMN is different from that of the HPLMN;
  - for procedure 4: three cells A, B, C of the same PLMN which is not the HPLMN with 3 different location area codes. Cells should differ in signal strength by 10 dB with cell A being the strongest and cell C the weakest. There should be a 20 dB range between A and C. A should be set to a level of - 40 dBm;
  - IMSI attach/detach is allowed in every cell;
  - the T3212 time-out value is 1/10 hour in every cell.
- User Equipment:
  - procedures 1, 2, 3 and 5: The UE has valid TMSI, CKSN and Kc. It is "idle updated" on cell B;
  - procedure 4: The UE has valid TMSI, CKSN and Kc. It is "idle updated" on cell A;
  - the list of "forbidden location areas for roaming" shall be empty (this may be achieved by either removing the SIM or switching the UE OFF then ON or removing the UE power source depending on ICS).

##### Related ICS/IXIT statement(s)

SIM removal possible while UE is powered Yes/No.

Switch off on button Yes/No.

Support of speech Yes/No.

Method to clear the list of location areas for roaming periodically.

The UE is automatically in automatic mode after switch on Yes/No.

##### Foreseen final state of the UE

Procedures 1 and 5: The UE has no valid TMSI and no CKSN. It is "idle updated" on cell A.

Procedure 2 and 3: The UE has no valid TMSI and no CKSN. It is in the "limited service" state on cell A.

Procedure 4: The UE has no valid TMSI and no CKSN. It is "idle updated" on cell C.



## Test Procedures

### Procedure 1:

- The SS rejects a normal location updating with the cause value "Roaming not allowed in this area". The RRC CONNECTION is released. The SS checks that the UE does not perform periodic location updating procedure. The UE is turned off and then on. The SS checks that the UE performs location updating on the cell on which its location update request had been rejected (this checks that the LA is not the forbidden list after switch on). This procedure is performed another time but the deletion of the list is checked while removing the SIM (instead of turning off the UE).

### Procedure 2:

- The SS rejects a normal location updating with the cause value "Roaming not allowed in this area". The RRC CONNECTION is released. The SS checks that the UE does not answer to a paging message with TMSI, rejects a request from CM entity but supports an emergency call.

### Procedure 3:

- The SS rejects a normal location updating with the cause value "Roaming not allowed in this area". This is done for 6 different location areas. Then the SS checks that the UE does not attempt to begin a location updating procedure on the non-allowed location areas.

### Procedure 4:

- The SS accepts a periodic location updating on a cell not belonging to the HPLMN. Then when the UE attempts to perform a periodic location updating to this cell, the SS rejects this location updating with the cause value "Roaming not allowed in this area". Two cells are then available, one belonging to the HPLMN but with the weakest level. It is checked that the UE returns to its HPLMN.

### Procedure 5: If SIM removal is possible while UE is powered:

- The SS rejects a normal location updating with the cause value "Roaming not allowed in this area". The RRC CONNECTION is released. The SS checks that the UE does not perform periodic location updating procedure. The SIM is removed and inserted in the UE. The SS checks that the UE performs location updating on the cell on which its location update request had been rejected (this checks that the LA is not the forbidden list after switch on).

Different types of UE may use different methods to periodically clear the list of forbidden areas (e.g. every day at 12am) for roaming. If the list is cleared while the test is being run, it may be necessary to re-run the test.

## Expected sequence

The following procedure is used during the test:

- change\_LAI (x):
  - the purpose of this procedure is to change the value of Location Area Identifier of cell x;
  - the Location Area Identifier of cell x shall be changed. The code shall be chosen arbitrarily but shall be different from any previously used in this procedure. The code shall have the same MCC as the Home PLMN and shall not have the same MNC as the Home PLMN.

## Procedure 1

Step	Direction		Message	Comments
	UE	SS		
1		SS		<p>The following messages are sent and shall be received on cell A.</p> <p>The RF level of cell B is lowered until cell B is no more suitable and the UE selects cell A.</p> <p>"Establishment cause": Location updating.</p> <p>"Reject cause" IE is "Roaming not allowed in this location area".</p> <p>After the sending of this message, the SS waits for the disconnection of the main signalling link.</p>
2	→		RRC CONNECTION REQUEST	
3	←		RRC CONNECTION SETUP	
4	→		LOCATION UPDATING REQUEST	
5	←		LOCATION UPDATING REJECT	
6	←		RRC CONNECTION RELEASE	
7		SS		<p>The SS waits at least 7 minutes for a possible location updating.</p> <p>The UE shall not initiate an RRC connection establishment on cell A or on cell B.</p>
8		UE		
9		UE		<p>If possible (see ICS) the UE is switched off. Otherwise if possible the power is removed.</p> <p>Depending on what has been performed in step 9 the UE is brought back to operation and placed in a automatic mode.</p> <p>"Establishment cause": Location updating.</p> <p>Location Updating Type = normal.</p> <p>IE Mobile Identity not present.</p> <p>After the sending of this message, the SS waits for the disconnection of the main signalling link.</p>
10		UE		
11	→		RRC CONNECTION REQUEST	
12	←		RRC CONNECTION SETUP	
13	→		LOCATION UPDATING REQUEST	
14	←		LOCATION UPDATING ACCEPT	
15	←		RRC CONNECTION RELEASE	

## Procedure 2

Step	Direction	Message	Comments
1	SS		The following messages are sent and shall be received on cell A. The RF level of cell B is lowered until the UE selects cell A. The level of cell B shall be such that cell B is suitable for cell selection.
2	→	RRC CONNECTION REQUEST	"Establishment cause": Location updating This message is sent on cell A.
3	←	RRC CONNECTION SETUP	
4	→	LOCATION UPDATING REQUEST	
5	←	LOCATION UPDATING REJECT	"Reject cause" IE is "Roaming not allowed in this location area".
6	←	RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
7	→	RRC CONNECTION REQUEST	The following messages are sent and shall be received on cell B.
8	←	RRC CONNECTION SETUP	"Establishment cause": Location updating.
9	→	LOCATION UPDATING REQUEST	
10	←	LOCATION UPDATING REJECT	"Reject cause" IE is "Roaming not allowed in this location area".
11	←	RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
12	SS		The SS waits for a possible location updating procedure on both cells A and B for 2 minutes.
13	UE		The UE shall not initiate an RRC connection establishment on cell A or on cell B within 2 minutes after the end of step 11.
14	←	MOBILE TERMINATED ESTABLISHMENT OF RRC CONNECTION	"Mobile identity" = TMSI. This message is sent on cell A and on cell B.
15	UE		The UE shall not initiate an RRC connection on cell A or on cell B. This is checked during 3 seconds.
16	UE		A MO CM connection is attempted.
17	UE		The UE shall not initiate an RRC connection establishment on cell A or on cell B. This is checked during 3 seconds.
18	UE → ←		The following messages are sent and shall be received on cell A Steps 20 to 27 are performed if the UE supports speech. An emergency call is attempted. "Establishment cause":
19	→	CM SERVICE REQUEST	"CM service type": Emergency call establishment.
20	←	CM SERVICE ACCEPT	
21	→	EMERGENCY SETUP	
22	←	RELEASE COMPLETE	"Cause" = unassigned number.
23	→	RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.

## Procedure 3

Step	Direction		Message	Comments
	UE	SS		
1		SS		<p>The following messages are sent and shall be received on cell A</p> <p>The RF level of cell B is lowered until the UE selects cell A. The level of cell B shall be such that cell B is suitable for cell selection.</p> <p>"Establishment cause": Location updating.</p> <p>"Reject cause" IE is "Roaming not allowed in this location area".</p> <p>After the sending of this message, the SS waits for the disconnection of the main signalling link.</p>
2	→		RRC CONNECTION REQUEST	
3	←		RRC CONNECTION SETUP	
4	→		LOCATION UPDATING REQUEST	
5	←		LOCATION UPDATING REJECT	
6	←		RRC CONNECTION RELEASE	
9	→		RRC CONNECTION REQUEST	<p>The following messages are sent and shall be received on cell B.</p> <p>"Establishment cause": Location updating.</p> <p>"Reject cause" IE is "Roaming not allowed in this location area".</p> <p>After the sending of this message, the SS waits for the disconnection of the main signalling link.</p> <p>Change_LAI (A) within 5 seconds after step 12.</p>
10	←		RRC CONNECTION SETUP	
11	→		LOCATION UPDATING REQUEST	
12	←		LOCATION UPDATING REJECT	
13	←		RRC CONNECTION RELEASE	
14		SS		
17	→		RRC CONNECTION REQUEST	<p>The following messages are sent and shall be received on cell A.</p> <p>"Establishment cause": Location updating.</p> <p>"Reject cause" IE is "Roaming not allowed in this location area".</p> <p>After the sending of this message, the SS waits for the disconnection of the main signalling link.</p> <p>Change_LAI (B) within 5 seconds after step 20.</p>
18	←		RRC CONNECTION SETUP	
19	→		LOCATION UPDATING REQUEST	
20	←		LOCATION UPDATING REJECT	
21	→		RRC CONNECTION RELEASE	
22		SS		
25	→		RRC CONNECTION REQUEST	<p>The following messages are sent and shall be received on cell B.</p> <p>"Establishment cause": Location updating.</p> <p>"Reject cause" IE is "Roaming not allowed in this location area".</p> <p>After the sending of this message, the SS waits for the disconnection of the main signalling link.</p> <p>Change_LAI (A) within 5 seconds after step 28.</p>
26	←		RRC CONNECTION SETUP	
27	→		LOCATION UPDATING REQUEST	
28	←		LOCATION UPDATING REJECT	
29	←		RRC CONNECTION RELEASE	
30		SS		
33	→		RRC CONNECTION REQUEST	<p>The following messages are sent and shall be received on cell A.</p> <p>"Establishment cause": Location updating.</p> <p>"Reject cause" IE is "Roaming not allowed in this location area".</p> <p>After the sending of this message, the SS waits for the disconnection of the main signalling link.</p> <p>Change_LAI (B) within 5 seconds after step 36.</p>
34	←		RRC CONNECTION SETUP	
35	→		LOCATION UPDATING REQUEST	
36	←		LOCATION UPDATING REJECT	
37	←		RRC CONNECTION RELEASE	
38		SS		
41	→		RRC CONNECTION REQUEST	<p>The following messages are sent and shall be received on cell B.</p> <p>"Establishment cause": Location updating.</p>
42	←		RRC CONNECTION SETUP	

Step	Direction		Message	Comments
	UE	SS		
43	→		LOCATION UPDATING REQUEST	<p>"Reject cause" IE is "Roaming not allowed in this location area".</p> <p>After the sending of this message, the SS waits for the disconnection of the main signalling link.</p> <p>The SS waits for a possible location updating procedure on both cells A and B for 7 minutes.</p> <p>The UE shall not initiate an RRC connection establishment on cell A or on cell B within 7 minutes after the end of step 45.</p>
44	←		LOCATION UPDATING REJECT	
45	←		RRC CONNECTION RELEASE	
46		SS		
47		UE		

## Procedure 4

Step	Direction		Message	Comments
	UE	SS		
1		SS		<p>The following messages are sent and shall be received on cell A.</p> <p>The SS waits for a periodic location updating procedure on cell A for 7 minutes after the initial conditions have been established.</p> <p>"Establishment cause": Location updating.</p> <p>Location Updating Type = periodic.</p> <p>IE Mobile Identity not present.</p> <p>After the sending of this message, the SS waits for the disconnection of the main signalling link.</p> <p>The location area identity of cell C shall be changed to that of a location area in the Home PLMN.</p> <p>The SS waits for a periodic location updating procedure on cell A for 7 minutes.</p> <p>"Establishment cause": Location updating This message is sent on cell A within 7 minutes after the end of step 6.</p> <p>"Location updating type" = periodic.</p> <p>"Reject cause" IE is "Roaming not allowed in this location area".</p> <p>After the sending of this message, the SS waits for the disconnection of the main signalling link.</p>
2	→		RRC CONNECTION REQUEST	
3	←		RRC CONNECTION SETUP	
4	→		LOCATION UPDATING REQUEST	
5	←		LOCATION UPDATING ACCEPT	
6	←		RRC CONNECTION RELEASE	
7		SS		
8		SS		
9	→		RRC CONNECTION REQUEST	
10	←		RRC CONNECTION SETUP	
11	→		LOCATION UPDATING REQUEST	
12	←		LOCATION UPDATING REJECT	
13	←		RRC CONNECTION RELEASE	
16	→		RRC CONNECTION REQUEST	<p>The following messages are sent and shall be received on cell C.</p> <p>"Establishment cause": Location updating.</p> <p>IE Mobile Identity not present.</p> <p>After the sending of this message, the SS waits for the disconnection of the main signalling link.</p>
17	←		RRC CONNECTION SETUP	
18	→		LOCATION UPDATING REQUEST	
19	←		LOCATION UPDATING ACCEPT	
20	←		RRC CONNECTION RELEASE	

## Procedure 5

Step	Direction		Message	Comments
	UE	SS		
1		SS		<p>The following messages are sent and shall be received on cell A.</p> <p>The RF level of cell B is lowered until cell B is no longer suitable and the UE selects cell A.</p> <p>"Establishment cause": Location updating.</p> <p>"Reject cause" IE is "Roaming not allowed in this location area".</p> <p>After the sending of this message, the SS waits for the disconnection of the main signalling link.</p>
2	→		RRC CONNECTION REQUEST	
3	←		RRC CONNECTION SETUP	
4	→		LOCATION UPDATING REQUEST	
5	←		LOCATION UPDATING REJECT	
6	←		RRC CONNECTION RELEASE	
7		SS		<p>The SS waits at least 7 minutes for a possible location updating.</p> <p>The UE shall not initiate an RRC connection establishment on cell A or on cell B.</p>
8		UE		
9	UE			<p>The SIM is removed.</p> <p>The SIM is inserted into the ME.</p> <p>"Establishment cause": Location updating.</p> <p>Location Updating Type = normal.</p> <p>IE Mobile Identity not present.</p> <p>After the sending of this message, the SS waits for the disconnection of the main signalling link.</p>
10	UE			
11	→		RRC CONNECTION REQUEST	
12	←		RRC CONNECTION SETUP	
13	→		LOCATION UPDATING REQUEST	
14	←		LOCATION UPDATING ACCEPT	
15	←		RRC CONNECTION RELEASE	

## Specific message contents

None.

### 9.4.3 Location updating / abnormal cases

#### 9.4.3.1 Location updating / abnormal cases / random access fails

##### 9.4.3.1.1 Conformance requirement

If during the RRC connection establishment phase of a normal location updating procedure, RRC CONNECTION requests are not answered by the network, the User Equipment shall:

1. send (Max-Retrans+1) RRC CONNECTION Request messages;
2. not try to establish a connection during a period of T3213;
3. then perform a normal location updating procedure as it is still necessary;
4. not repeat the complete procedure if the original cause of the location updating procedure has disappeared.

## Reference(s)

TS 24.008 Clause 4.4.4.9.

##### 9.4.3.1.2 Test purpose

To verify that when during the RRC connection establishment phase of a location updating procedure, RRC CONNECTION requests are not answered by the network, after expiry of T3213 (= 4s in Phase 2) and when the cell reselection procedure is finished the complete procedure is repeated if still necessary.

#### 9.4.3.1.3 Method of test

##### Initial conditions

- System Simulator:
  - two cells: A and B of the same PLMN, belonging to different location areas with LAI a and b;
  - the RF power level of cell B is higher than the one of cell A;
  - IMSI attach/detach is not allowed in both cells;
  - the T3212 time-out value is set to infinite in both cells.
- User Equipment:
  - the UE has a valid TMSI, CKSN and Kc. It is "Idle updated" on cell B.

##### Related ICS/IXIT statement(s)

None.

##### Foreseen final state of the UE

The UE is "Idle updated" on cell A.

##### Test Procedure

The SS causes a random access failure in the UE during a normal location updating procedure. After the expiry of T3213 and when the cell reselection procedure is finished the UE will try to restart the normal location updating procedure.

The test is repeated but the original cause of the location updating procedure has disappeared. The SS then checks that the UE will not restart the location updating procedure.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The following messages are sent and shall be received on cell A. The RF level of cell B is lowered until the UE selects cell A. The RF level of cell B is set sufficiently low to ensure that cell B is not suitable as defined in GSM 05.08 subclause 6.6.2..
2	→		RRC CONNECTION REQUEST	Establishment cause: Location updating. This message is sent by the UE (Max_Retrans + 1) times.
3		SS		The SS waits for 4 seconds.
4	UE			The UE shall not send any layer 3 message during this time.
5	→		RRC CONNECTION REQUEST	Establishment cause: Location updating. The time difference between this message and the last RRC CONNECTION REQUEST sent in step 2 shall be in the range 4 s - 9 s.
6	←		RRC CONNECTION SETUP	location updating type = normal, CKSN = initial value, LAI = b, mobile station classmark 1 and mobile identity = TMSI.
7	→		LOCATION UPDATING REQUEST	
8	←		LOCATION UPDATING ACCEPT	Optional IE Mobile Identity not included After the sending of this message, the SS waits for the disconnection of the main signalling link.
9	←		RRC CONNECTION RELEASE	
10		SS		The RF level of cell B is set to the same value as for cell A.
11		SS		The RF level of cell A is lowered until the UE selects cell B. The RF level of cell A is kept sufficiently high to ensure that cell A is still suitable as defined in subclause 6.6.2.
12	→		RRC CONNECTION REQUEST	The following messages are sent and shall be received on cell B. Establishment cause: Location updating. This message is sent by the UE (Max_Retrans + 1) times.
13		SS		Immediately after the end of step 12 the RF level of cell A is set to the same value as for cell B.
14	UE			The UE shall not initiate an RRC connection establishment on cell A or on cell B. This is checked during 15 s.

## Specific message contents

None.

## 9.4.3.2 Location updating / abnormal cases / attempt counter less or equal to 4, LAI different

## 9.4.3.2.1 Conformance requirement

- 1) When a failure such as cases d), f) and g) of clause 4.4.4.9 of TS 24.008 has occurred during a normal location updating procedure, if the attempt counter is smaller than 4 and after expiry of T3211, the User Equipment shall resend its Location Updating Request message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating type set to "normal location updating".
- 2) When a failure such as cases d), f) and g) of clause 4.4.4.9 of TS 24.008 has occurred during a normal location updating procedure the User Equipment shall:
  - 2.1 not answer to paging with the previously allocated TMSI;
  - 2.2 not perform the IMSI detach procedure, when switched off.



- 3) When a failure such as case e) of clause 4.4.4.9 of TS 24.008 has occurred during a normal location updating procedure and when an emergency call establishment is requested by the user the User Equipment, if it supports speech, shall send a CM Service Request message with CM Service Type IE set to "emergency call establishment", CKSN IE set to "no key available" and Mobile Identity IE set to its IMSI and after acceptance by the network it shall send an Emergency Setup message.
- 4) When a failure such as cases d), f) and g) of clause 4.4.4.9 of TS 24.008 has occurred during a normal location updating procedure the User Equipment shall use a request from CM entity other than emergency call as a trigger for a normal location updating procedure and shall send a Location Updating Request message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating type IE set to "normal location updating".
- 5) When a failure such as cases d), f) and g) of clause 4.4.4.9 of TS 24.008 has occurred during a normal location updating procedure the User Equipment shall answer to paging with IMSI and shall send a Paging Response message with CKSN IE set to "no key available" and Mobile Identity IE set to its IMSI.
- 6) When a failure such as cases d), f) and g) of clause 4.4.4.9 of TS 24.008 has occurred during a normal location updating procedure the User Equipment shall perform a normal location updating procedure as soon as it enters a new cell.

## References

TS 24.008 Clauses 4.4.4.2, 4.4.4.9.

### 9.4.3.2.2 Test purpose

To verify that the UE performs normal location updating procedures when its attempt counter is smaller than 4.

To check that the UE does not perform the IMSI detach procedure when "idle not updated".

To verify that when "idle not updated" the UE can perform an emergency call.

To verify that when "idle not updated" the UE uses requests from CM layer other than emergency call as triggering of a normal location updating procedure.

To verify that the UE performs a normal location updating procedure if it enters a new cell while being "idle not updated".

### 9.4.3.2.3 Method of test

#### Initial conditions

- System Simulator:
  - two cells: A and B of the same PLMN, belonging to different location areas with LAI a and b;
  - ATT flag shall be set to IMSI attach/detach allowed.
- User Equipment:
  - the UE is "idle updated" on cell A. A valid CKSN value is stored in the SIM and is noted "initial CKSN". A TMSI is allocated.

#### Related ICS/IXIT statements

SIM removal possible while UE is powered Yes/No.

Switch off on button Yes/No.

Support for speech Yes/No.

Foreseen final state of the UE

The UE is "Idle updated" on cell A with a valid CKSN and a TMSI.

#### Test Procedure

The UE is made to perform a normal location updating procedure. Four types of failure cases are triggered:

- sending of a Location Updating Reject with cause randomly chosen between all defined cause values except 2, 3, 6, 11, 12 and 13 (which trigger a different action) (case g of TS 24.008 clause 4.4.4.9);
- RRC-connection failure (case d);
- sending of a RRC CONNECTION RELEASE message before the normal end of the procedure (case f);
- T3210 time-out (case e).

As there is no stored LAI or the stored LAI is different from the broadcast LAI, and the attempt counter in the UE shall be lower than 4, the UE enters the state MM IDLE and substate ATTEMPTING TO UPDATE and waits for T3211 seconds before trying again a location updating procedure.

Then the behaviour of the UE in the MM IDLE ATTEMPTING TO UPDATE SERVICE state is checked, that is:

- not answer to paging with TMSI;
- not perform an IMSI detach procedure;
- support request for emergency call;
- use requests from CM layer other than emergency call as triggering of a normal location updating procedure;
- perform normal location updating procedure when a new cell is entered.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
The following messages are sent and shall be received on cell B.				
1	UE			The RF level of cell A is lowered until the UE selects cell B. The RF level of cell A is set sufficiently low to ensure that cell A is not suitable as defined in subclause 6.6.2. Establishment cause: Location updating.
2	→		RRC CONNECTION REQUEST	
3	←		RRC CONNECTION SETUP	
4	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = initial value, LAI = a, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.
5	←		LOCATION UPDATING REJECT	IE Reject cause is set to a value arbitrarily chosen: * in table 10.66 of, causes #2, #3, #6, #11, #12 and #13 being excluded.
6	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
7	UE			The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the RRC CONNECTION release.
8	→		RRC CONNECTION REQUEST	Establishment cause: Location updating.
9	←		RRC CONNECTION SETUP	
10	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.
11	SS			The SS deactivates the SACCH on the dedicated RRC CONNECTION. The SS waits until there are no more SACCH frames in the uplink direction. This release connection is done within 8 SACCH frames.
12	UE			The UE shall not initiate an RRC connection establishment on cell A or on cell B within T3211 + RadioLinkTimeout after the SS deactivates the SACCH.
13	→		RRC CONNECTION REQUEST	Establishment cause: Location updating.
14	←		RRC CONNECTION SETUP	
15	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.
16	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
17	UE			The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the RRC CONNECTION release.
18	→		RRC CONNECTION REQUEST	Establishment cause: Location updating.
19	←		RRC CONNECTION SETUP	
20	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.
21	←		AUTHENTICATION REQUEST	CKSN = initial CKSN.
22	→		AUTHENTICATION RESPONSE	
23	←		LOCATION UPDATING ACCEPT	IE mobile Identity = new TMSI.
24	→		TMSI REALLOCATION COMPLETE	
25	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link. UE is now "idle updated" in cell B.
The following messages are sent and shall be received on cell A.				
26	UE			The RF level of cell B is lowered until the UE selects cell A. The RF level of cell B is set sufficiently low to ensure that cell B is not suitable as defined in subclause 6.6.2. Establishment cause: Location updating.
27	→		RRC CONNECTION REQUEST	
28	←		RRC CONNECTION SETUP	

Step	Direction		Message	Comments
	UE	SS		
29	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.
30		SS	MOBILE TERMINATED ESTABLISHMENT OF RRC CONNECTION	performs step 5 with reject cause #100 and step 6.
31	←			Mobile identity = old TMSI of the UE. This message is sent continuously to the UE during 8 seconds.
32		SS		The SS checks that there is no answer from the UE during 12 seconds.
33		SS		If during steps 31 and 32 the UE attempts to perform a location updating procedure the SS will perform step 30 and then continue the procedure.
34		UE		If possible (see ICS) SIM detachment is performed. Otherwise if possible (see ICS) mobile switch off is performed. Otherwise the power is removed.
35		UE		The UE shall not initiate an RRC connection establishment on cell A or on cell B. This is checked during 30 seconds.
36		UE		Depending on what has been performed in step 34 the UE is brought back to operation.
	→		LOCATION UPDATING REQUEST	Establishment cause: Location updating.
37	←			
	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.
38	←		AUTHENTICATION REQUEST	CKSN = initial CKSN.
39	→		AUTHENTICATION RESPONSE	
40	←		LOCATION UPDATING ACCEPT	IE mobile Identity = new TMSI.
41	→		TMSI REALLOCATION COMPLETE	
42	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link. UE is now "idle updated" in cell A.
43		UE		The RF level of cell A is lowered until the UE selects cell B. The RF level of cell A is set sufficiently low to ensure that cell A is not suitable as defined in subclause 6.6.2.
44	→		RRC CONNECTION REQUEST	Establishment cause: Location updating.
45	←		RRC CONNECTION SETUP	
46	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = initial value, LAI = a, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.
47	←		AUTHENTICATION REQUEST	
48	→		AUTHENTICATION RESPONSE	steps 49 and 50 are performed N times. N shall be chosen in such a way that T3210 expires. Depending on when T3210 expires in the UE, it is possible that on the Nth occurrence of step 50 the UE may send a L2 DISC rather than the AUTHENTICATION RESPONSE message.
49		SS		The SS checks that there is no more activity from the UE on the RRC CONNECTION after the DISC/UA exchange has been completed.
50		UE		If the UE supports speech it is made to perform an emergency call.
51	→		RRC CONNECTION REQUEST	Establishment cause: Emergency call.
52	←		RRC CONNECTION SETUP	
53	→		CM SERVICE REQUEST	CM service type = Emergency call establishment; CKSN = no key available; Mobile Identity = IMSI.
54	←		CM SERVICE ACCEPT	
55	→		EMERGENCY SETUP	
56	←		RELEASE COMPLETE	
57	←		RRC CONNECTION RELEASE	Cause = unassigned number.

Step	Direction		Message	Comments
	UE	SS		
58	→		RRC CONNECTION REQUEST	Establishment cause: Location updating The SS will wait at most 15 seconds for this message.
59	←		RRC CONNECTION SETUP	location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI. CKSN = initial CKSN.
60	→		LOCATION UPDATING REQUEST	
61	←		AUTHENTICATION REQUEST	
62	→		AUTHENTICATION RESPONSE	
63	←		LOCATION UPDATING ACCEPT	IE mobile Identity = new TMSI.
64	→		TMSI REALLOCATION COMPLETE	
65	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link. UE is now "idle updated" in cell B.
66	UE			The RF level of cell B is lowered until the UE selects cell A. The RF level of cell B is set sufficiently low to ensure that cell B is not suitable as defined in subclause 6.6.2.
67	→		RRC CONNECTION REQUEST	Establishment cause: Location updating.
68	←		RRC CONNECTION SETUP	location updating type = normal, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI. performs step 11. A MO CM connection is attempted before T3211 expiry.
69	→		LOCATION UPDATING REQUEST	
70	SS			
71	UE			
72	→		RRC CONNECTION REQUEST	Establishment cause: Location updating.  location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.
73	←		RRC CONNECTION SETUP	
74	→		LOCATION UPDATING REQUEST	
75	←		LOCATION UPDATING ACCEPT	
76	→		TMSI REALLOCATION COMPLETE	IE mobile Identity = new TMSI.
77	←		RRC CONNECTION RELEASE	
78	→		RRC CONNECTION REQUEST	Steps 80 to 83 are optional as the UE may have memorized the request for CM connection attempt Wait 10 s to decide whether to go directly to step 84.
79	←		RRC CONNECTION SETUP	Establishment cause: Not checked.
80	→		CM SERVICE REQUEST	CKSN = no key available, Mobile identity = TMSI.
81	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link. UE is now "idle updated" in cell A.
82	UE			The RF level of cell A is lowered until the UE selects cell B. The RF level of cell A is set sufficiently low to ensure that cell A is not suitable as defined in subclause 6.6.2.
83	→		RRC CONNECTION REQUEST	Establishment cause: Location updating.
84	←		RRC CONNECTION SETUP	location updating type = normal, CKSN = no key available LAI = a, mobile station classmark 1 as given by the ICS and mobile identity = TMSI. performs step 16.
85	→		LOCATION UPDATING REQUEST	
86	SS			
87	UE			
88	→		RRC CONNECTION REQUEST	The RF level of cell B is lowered until the UE selects cell A. The RF level of cell B is set sufficiently low to ensure that cell B is not suitable as defined in subclause 6.6.2.
89	←		RRC CONNECTION SETUP	Establishment cause: Location updating. The time interval between Cell B being set sufficiently low to ensure that Cell B is not suitable and this message shall be less than 20s.

Step	Direction		Message	Comments
	UE	SS		
90	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = no key available , LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), mobile station classmark 1 as given by the ICS and mobile identity = IMSI. CKSN = initial CKSN. Mobile identity = TMSI.  After the sending of this message, the SS waits for the disconnection of the main signalling link. UE is now "Idle, updated" in cell A.
91	←		AUTHENTICATION REQUEST	
92	→		AUTHENTICATION RESPONSE	
93	←		LOCATION UPDATING ACCEPT	
94	→		TMSI REALLOCATION COMPLETE	
95	←		RRC CONNECTION RELEASE	

### Specific message contents

None.

## 9.4.3.3 Location updating / abnormal cases / attempt counter equal to 4

### 9.4.3.3.1 Conformance requirement

- 1) When four failures such as cases d) to g) of clause 4.4.4.9 of TS 24.008 have occurred during a normal location updating procedure the User Equipment shall:
  - 1.1 perform location updating after T3212 expiry by sending a Location Updating Request message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating type set to "normal updating";
  - 1.2 if the T3212 initiated location updating was unsuccessful, then after T3211 expiry the User Equipment shall send a Location Updating Request message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating type IE set to "normal location updating".
- 2) When four failures such as cases d), f), g) of clause 4.4.4.9 of TS 24.008 have occurred during a normal location updating procedure the User Equipment, if it supports speech, shall be able to perform an emergency call i.e. the User Equipment is able to send a CM Service Request message with the CM Service Type IE set to "emergency call establishment", CKSN IE set to "no key is available" and Mobile Identity IE set to its IMSI and then send an Emergency Setup message.
- 3) When four failures such as cases d), f), g) of clause 4.4.4.9 of TS 24.008 have occurred during a normal location updating procedure:
  - 3.1 the User Equipment shall use a request from CM entity for MM connection for a service other than emergency call as a trigger for a normal location updating procedure and shall send a Location Updating Request message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating type IE set to "normal location updating";
  - 3.2 after a location updating triggered by a request from the CM layer which was .unsuccessful, after T3211 expiry the User Equipment shall send a Location Updating Request message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating type IE set to "normal location updating".
- 4) When four failures such as cases d), f), g) of clause 4.4.4.9 of TS 24.008 have occurred during a normal location updating procedure:
  - 4.1 the User Equipment shall perform a normal location updating procedure if it enters a new cell;

4.2 if this location updating is unsuccessful, after T3211 expiry the User Equipment shall send a Location Updating Request message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating type IE set to "normal location updating".

## References

TS 24.008 Clause 4.4.4.9.

### 9.4.3.3.2 Test purpose

To verify that the UE performs normal location updating procedures after T3212 expiry, when its attempt counter has reached value 4 and that the UE reset its attempt counter after a timer T3212 expiry.

To verify that the UE still follows the MM IDLE ATTEMPTING TO UPDATE state requirements after its attempt counter has reached value 4.

To verify that the attempt counter is reset in the cases where it has to be done.

### 9.4.3.3.3 Method of test

#### Initial conditions

- System Simulator:
  - two cells: A and B, belonging to different location areas a and b;
  - IMSI attach/detach is allowed in both cells;
  - T3212 is set to 6 minutes.
- User Equipment:
  - the UE is "Idle updated" on cell B with a valid CKSN and a TMSI.

#### Related ICS/IXIT statements

SIM removal possible while UE is powered Yes/No.

Switch off on button Yes/No.

Support of speech Yes/No.

#### Foreseen final state of the UE

The UE is "Idle updated" on cell A with a valid CKSN and a TMSI.

#### Test Procedure

The UE is made to perform a normal location updating. The SS triggers a failure in this procedure. After T3211 expiry the UE will try again the location updating procedure. The SS triggers again a failure. This is done again 2 times. At this point the attempt counter shall be equal to 4. It is then checked that T3212 has been started and that at its expiry the UE will try a normal location updating procedure. It is verified that the UE has reset its attempt counter after timer T3212 expiry.

Then it is checked that, when the attempt counter has reached the value of 4, the UE is in the MM IDLE state and ATTEMPTING TO UPDATE substate, that is:

- not perform an IMSI detach procedure;
- support request for emergency call;
- use requests from CM layer other than emergency call as triggering of a normal location updating procedure;

- perform normal location updating procedure when a new cell is entered.



## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The following messages are sent and shall be received on cell A. The RF level of cell B is lowered until the UE selects cell A. The RF level of cell B is set sufficiently low to ensure that cell B is not suitable as defined in subclause 6.6.2. Establishment cause: Location updating.
2	→		RRC CONNECTION REQUEST	location updating type = normal, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.
3	←		RRC CONNECTION SETUP	
4	→		LOCATION UPDATING REQUEST	
5	←		LOCATION UPDATING REJECT	IE Reject cause is set to #22 * in table 10.66 of, causes #2, #3, #6, #11, #12 and #13 being excluded.
6	←		RRC CONNECTION RELEASE	The SS waits for the disconnection of the main signalling link.
7	UE			The UE shall not initiate an RRC connection establishment on cell A or on cell B within T3211.
8	→		RRC CONNECTION REQUEST	Establishment cause: Location updating.
9	←		RRC CONNECTION SETUP	location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.
10	→		LOCATION UPDATING REQUEST	
11	SS			
12	UE			The SS deactivates the SACCH on the dedicated RRC CONNECTION and waits until there are no more SACCH frames in the uplink. This is done within 8 SACCH frames.
13	→		RRC CONNECTION REQUEST	The UE shall not initiate an RRC connection establishment on cell A or on cell B with T3211 + RadioLinkTimeout after the SS deactivates the SACCH. Establishment cause: Location updating.
14	←		RRC CONNECTION SETUP	
15	→		LOCATION UPDATING REQUEST	
16	←		AUTHENTICATION REQUEST	location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.
17	→		AUTHENTICATION RESPONSE	
18	UE			
19	→		RRC CONNECTION REQUEST	these steps (16 and 17) are performed N times. N shall be chosen in such a way that T3210 expires. Depending on when T3210 expires in the UE, it is possible that on the Nth occurrence of step 50 the UE may send a L2 DISC rather than the AUTHENTICATION RESPONSE message.
20	←		RRC CONNECTION SETUP	
21	→		LOCATION UPDATING REQUEST	
22	←		RRC CONNECTION RELEASE	The UE shall cease transmission (after the DISC/UA exchange has been completed) and then shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the expiry of T3210. Establishment cause: Location updating.
23	UE			location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.
24	→		RRC CONNECTION REQUEST	
25	←		RRC CONNECTION SETUP	

Step	Direction		Message	Comments
	UE	SS		
26	→		LOCATION UPDATING REQUEST	location updating type: "normal location update" CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE) mobile station classmark 1 as given by the ICS and mobile identity = IMSI.
27	←		LOCATION UPDATING REJECT	IE Reject cause = #17 "network failure".
28	←		RRC CONNECTION RELEASE	The SS waits for the disconnection of the main signalling link.
29	UE			The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the RRC CONNECTION release. Establishment cause: Location updating.
30	→		RRC CONNECTION REQUEST	
31	←		RRC CONNECTION SETUP	
32	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE) mobile station classmark 1 as given by the ICS and mobile identity = IMSI.
33	←		AUTHENTICATION REQUEST	CKSN = initial CKSN.
34	→		AUTHENTICATION RESPONSE	
35	←		LOCATION UPDATING ACCEPT	IE mobile Identity = new TMSI.
36	→		TMSI REALLOCATION COMPLETE	
37			RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link. UE is now "idle, updated" in cell A.
38	UE			The RF level of cell A is lowered until the UE selects cell B. The RF level of cell A is set sufficiently low to ensure that cell A is not suitable as defined in subclause 6.6.2. Establishment cause: Location updating.
39	→		RRC CONNECTION REQUEST	
40	←		RRC CONNECTION SETUP	
41	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = initial value, LAI = a, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.
42	←		LOCATION UPDATING REJECT	IE Reject cause is set to #42 * in table 10.66 of, causes #2, #3, #6, #11, #12 and #13 being excluded.
43	←		RRC CONNECTION RELEASE	The SS waits for the disconnection of the main signalling link.
44	UE			The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the RRC CONNECTION release. Establishment cause: Location updating.
45	→		RRC CONNECTION REQUEST	
46	←		RRC CONNECTION SETUP	
47	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.
48	SS			The SS deactivates the SACCH on the dedicated RRC CONNECTION and waits until there is no more SACCH frames in the uplink. This is done within 8 SACCH frames.
48a	UE			The UE shall not initiate an RRC connection establishment on cell A or on cell B within T3211 + RadioLinkTimeOut after the SS deactivates the SACCH. Establishment cause: Location updating.
49	→		RRC CONNECTION REQUEST	
50	←		RRC CONNECTION SETUP	
51	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.
52	←		RRC CONNECTION RELEASE	The SS waits for the disconnection of the main signalling link.

Step	Direction		Message	Comments
	UE	SS		
53		UE		The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the RRC CONNECTION release. Establishment cause: Location updating.
54	→		RRC CONNECTION REQUEST	
55	←		RRC CONNECTION SETUP	
56	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE) mobile station classmark 1 as given by the ICS and mobile identity = IMSI.
57		SS		performs step 42 with cause #38 and step 43.
58		UE		If the UE supports speech, it is made to perform an emergency call.
59	→		RRC CONNECTION REQUEST	Establishment cause: Emergency call.
60	←		RRC CONNECTION SETUP	
61	→		CM SERVICE REQUEST	CM service type = Emergency call establishment; CKSN = no key available; Mobile Identity = IMSI.
62	←		CM SERVICE ACCEPT	
63	→		EMERGENCY SETUP	
64	←		RELEASE COMPLETE	Cause = unassigned number.
65	←		RRC CONNECTION RELEASE	The SS waits for the disconnection of the main signalling link.
66		UE		If possible (see ICS) SIM detachment is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed.
67		UE		The UE shall not initiate an RRC connection establishment on cell A or on cell B. This is checked during 3 seconds.
68		UE		Depending on what has been performed in step 66 the UE is brought back to operation.
69	→		RRC CONNECTION REQUEST	Establishment cause: Location updating.
70	←		RRC CONNECTION SETUP	
71	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.
72	←		AUTHENTICATION REQUEST	CKSN = initial CKSN.
73	→		AUTHENTICATION RESPONSE	
74	←		LOCATION UPDATING ACCEPT	IE mobile Identity = new TMSI.
75	→		TMSI REALLOCATION COMPLETE	
76	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link. UE is now "idle, updated" in cell B.
77		UE		The RF level of cell B is lowered until the UE selects cell A. The RF level of cell B is set sufficiently low to ensure that cell B is not suitable as defined in subclause 6.6.2.
78	→		RRC CONNECTION REQUEST	Establishment cause: Location updating.
79	←		RRC CONNECTION SETUP	
80	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.
81	←		LOCATION UPDATING REJECT	IE Reject cause is set to #38 * in table 10.66 of, causes #2, #3, #6, #11, #12, and #13 being excluded.
82	←		RRC CONNECTION RELEASE	The SS waits for the disconnection of the main signalling link.
83		UE		The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the RRC CONNECTION release.
84	→		RRC CONNECTION REQUEST	Establishment cause: Location updating.
85	←		RRC CONNECTION SETUP	

Step	Direction		Message	Comments
	UE	SS		
86	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.
87		SS		The SS deactivates the SACCH on the dedicated RRC CONNECTION and waits until there is no more SACCH frames in the uplink. This is done within 8 SACCH frames.
88		UE		The UE shall not initiate an RRC connection establishment on cell A or on cell B within T3211 +RadioLinkTimeout seconds after the SS deactivates the SACCH.
89	→		RRC CONNECTION REQUEST	Establishment cause: Location updating.
90	←		RRC CONNECTION SETUP	
91	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.
92	←		RRC CONNECTION RELEASE	The SS waits for the disconnection of the main signalling link.
93		UE		The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the RRC CONNECTION release.
94	→		RRC CONNECTION REQUEST	Establishment cause: Location updating.
95	←		RRC CONNECTION SETUP	
96	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE) mobile station classmark 1 as given by the ICS and mobile identity = IMSI.
97		SS		performs step 48.
98		UE		A MO CM connection is attempted.
99	→		RRC CONNECTION REQUEST	Establishment cause: Location updating.
100	←		RRC CONNECTION SETUP	
101	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.
102		SS		performs step 52.
103		UE		The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the RRC CONNECTION release.
104	→		RRC CONNECTION REQUEST	Establishment cause: Location updating.
105	←		RRC CONNECTION SETUP	
106	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.
107	←		AUTHENTICATION REQUEST	CKSN = initial CKSN.
108	→		AUTHENTICATION RESPONSE	
109	←		LOCATION UPDATING ACCEPT	IE mobile Identity = new TMSI.
110	→		TMSI REALLOCATION COMPLETE	
111	←		RRC CONNECTION RELEASE	UE is now "idle, updated" in cell A The UE may or may not have memorized the request for CM connection. The steps 112 to 116 are therefore optional for the UE. The SS waits 10 second whether to decide to go directly to step 117.
112	→		RRC CONNECTION REQUEST	
113	←		RRC CONNECTION SETUP	
114	→		CM SERVICE REQUEST	CKSN = initial value, Mobile identity = TMSI.
115	←		CM SERVICE REJECT	cause #17 (network failure).
116	←		RRC CONNECTION RELEASE	The SS waits for the disconnection of the main signalling link.

Step	Direction		Message	Comments
	UE	SS		
117		UE		The RF level of cell A is lowered until the UE selects cell B. The RF level of cell A is set sufficiently low to ensure that cell A is not suitable as defined in subclause 6.6.2. Establishment cause: Location updating.
118	→		RRC CONNECTION REQUEST	
119	←		RRC CONNECTION SETUP	
120	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = initial value, LAI = a, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.
121	←		LOCATION UPDATING REJECT	IE Reject cause is set to #38 * in table 10.66 of, causes #2, #3, #6, #11, #12 and #13 being excluded.
122	←		RRC CONNECTION RELEASE	The SS waits for the disconnection of the main signalling link
123		UE		The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the RRC CONNECTION release.
124	→		RRC CONNECTION REQUEST	Establishment cause: Location updating.
125	←		RRC CONNECTION SETUP	
126	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.
127		SS		The SS stops any RF transmission on the dedicated RRC CONNECTION and waits until there is no more SACCH in the uplink.
128		UE		The UE shall not initiate an RRC connection establishment on cell A or on cell B within T3211 + RadioLinkTimeout seconds after the SS stops RF transmission.
129	→		RRC CONNECTION REQUEST	Establishment cause: Location updating.
130	←		RRC CONNECTION SETUP	
131	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.
132	←		RRC CONNECTION RELEASE	The SS waits for the disconnection of the main signalling link.
133		UE		The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the RRC CONNECTION release.
134	→		RRC CONNECTION REQUEST	Establishment cause: Location updating.
135	←		RRC CONNECTION SETUP	
136	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE) mobile station classmark 1 as given by the ICS and mobile identity = IMSI.
137		SS		performs steps 42 and 43.
138		UE		The RF level of cell B is lowered until the UE selects cell A. The RF level of cell B is set sufficiently low to ensure that cell B is not suitable as defined in subclause 6.6.2. Establishment cause: Location updating.
139	→		RRC CONNECTION REQUEST	
140	←		RRC CONNECTION SETUP	
141	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE) mobile station classmark 1 as given by the ICS and mobile identity = IMSI.
142		SS		performs the step 48.
143		UE		The UE shall not initiate an RRC connection establishment on cell A or on cell B until T3211 + RadioLinkTimeout after the SS deactivates the SACCH.
144	→		RRC CONNECTION REQUEST	Establishment cause: Location updating.
145	←		RRC CONNECTION SETUP	

Step	Direction		Message	Comments
	UE	SS		
146	→		LOCATION UPDATING REQUEST	location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI. CKSN = initial CKSN.  IE mobile Identity = new TMSI.
147	←		AUTHENTICATION REQUEST	
148	→		AUTHENTICATION RESPONSE	
149	←		LOCATION UPDATING ACCEPT	
150	→		TMSI REALLOCATION COMPLETE	
151	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link. UE is now "idle, updated" in cell A.

#### Specific message contents

None.

### 9.4.3.4 Location updating / abnormal cases / attempt counter less or equal to 4, stored LAI equal to broadcast LAI

#### 9.4.3.4.1 Conformance requirement

- 1) When a failure such as cases d), f) and g) of clause 4.4.4.9 of TS 24.008 has occurred during a periodic location updating procedure (the broadcast LAI is equal to the stored LAI):
  - 1.1 the User Equipment shall be able to establish an MM connection i.e. send a RRC CONNECTION Request and then a CM Service Request message, CKSN and LAI set to those which have been allocated to the User Equipment, Mobile Identity IE set to the TMSI which has been allocated to the User Equipment;
  - 1.2 then the User Equipment shall not attempt a location updating procedure.
- 2) When a failure such as cases d), f) and g) of clause 4.4.4.9 of TS 24.008 has occurred during an IMSI attach procedure (the broadcast LAI is equal to the stored LAI):
  - 2.1 the User Equipment shall be able to establish an MM connection i.e. send a RRC CONNECTION Request and then a CM Service Request message, CKSN and LAI set to those which have been allocated to the User Equipment, Mobile Identity IE set to the TMSI which has been allocated to the User Equipment;
  - 2.2 then the User Equipment shall not attempt a location updating procedure.
- 3) When a failure such as cases d), f) and g) of clause 4.4.4.9 of TS 24.008 has occurred during a periodic location updating procedure and the attempt counter is smaller than 4 the User Equipment shall send, after T3211 expiry, a Location Updating Request message with the Mobile Identity IE set to the TMSI which has been allocated to the User Equipment, CKSN IE and LAI set to those which have been allocated to the User Equipment and the Location Updating type set to "periodic updating".
  - 3.1 When the User Equipment's attempt counter reaches the value 4 (four failures such as cases d), f) and g) of clause 4.4.4.9 of TS 24.008 have occurred during a periodic location updating procedure) after T3212 expiry it shall send a Location Updating Request message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating type set to "normal".
- 4) When the User Equipment's attempt counter reaches the value 4 (four failures such as cases d), f) and g) of clause 4.4.4.9 of TS 24.008 have occurred during a periodic location updating procedure) it shall use a request for a CM connection other than emergency call as a trigger for a location updating procedure.
- 5) When a failure such as cases d), f) and g) of clause 4.4.4.9 of TS 24.008 has occurred during an IMSI attach procedure and the attempt counter is smaller than 4 the User Equipment shall send, after T3211 expiry, a Location Updating Request message with the Mobile Identity IE set to the TMSI which has been allocated to the User Equipment, CKSN IE and LAI set to those which have been allocated to the User Equipment and the Location Updating type set to "IMSI attach".

5.1 When the User Equipment's attempt counter reaches the value 4 (four failures such as cases d), f) and g) of clause 4.4.4.9 of TS 24.008 have occurred during an IMSI attach procedure) after T3212 expiry it shall send a Location Updating Request message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating type set to "normal".

- 6) When the User Equipment's attempt counter reaches the value 4 (four failures such as cases d), f) and g) of clause 4.4.4.9 of TS 24.008 have occurred during an IMSI attach procedure) it shall use a request for a CM connection other than emergency call as a trigger for a location updating procedure.

## References

TS 24.008 Clause 4.4.4.9.

### 9.4.3.4.2 Test purpose

To verify that in the case when the attempt counter is smaller than 4 and the broadcast LAI is equal to the stored LAI, the UE is in the MM IDLE state and NORMAL SERVICE substate. To verify that timer T3211 is stopped after a MM connection establishment.

To verify that the UE uses the T3211 timer, and that it enters the MM IDLE state and NORMAL SERVICE substate when its attempt counter reaches value 4 even in the case where the stored LAI is equal to the broadcast LAI.

### 9.4.3.4.3 Method of test

#### Initial conditions

- System Simulator:
  - one cell: B, belonging to location area b;
  - IMSI attach/detach is allowed;
  - T3212 is set to 6 minutes.
- User Equipment:
  - the UE is "Idle updated" on cell B with a valid CKSN and a TMSI.

#### Related ICS/IXIT statements

SIM removal possible while UE is powered Yes/No.

Switch off on button Yes/No.

#### Foreseen final state of the UE

The UE is "idle updated" on cell B with a valid CKSN and a TMSI.

#### Test Procedure

A failure during the periodic location updating is triggered: as the broadcast LAI is equal to the stored LAI, the UE is still in the MM IDLE state and NORMAL SERVICE substate and timer T3211 is started. A CM connection other than for emergency call is attempted. It is checked that this is possible and that T3211 is stopped. Same test is performed with a failure during an IMSI attach procedure.

Then failures are triggered during the periodic location updating to let the attempt counter to reach the value of 4. The UE shall enter the MM IDLE LIMITED SERVICE state and delete any TMSI, stored LAI, ciphering key sequence number and ciphering key. When the attempt counter reaches the value of 4, timer T3212 shall be started. At timer T3212 expiry a location updating procedure is started. A request for CM connection other than emergency call shall trigger a location updating procedure.

Same tests are performed when the failures are triggered during an IMSI attach procedure.





## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		The SS shall wait at most T3212 + 45 seconds.
2		→	RRC CONNECTION REQUEST	Establishment cause: Location updating.
3		←	RRC CONNECTION SETUP	
4		→	LOCATION UPDATING REQUEST	location updating type = periodic, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.
5		SS		performs step 5, of 9.4.3.2 with cause #17 and step 6 of 9.4.3.2.
6		UE		A MO CM connection is attempted.
7		→	RRC CONNECTION REQUEST	
8		←	RRC CONNECTION SETUP	
9		→	CM SERVICE REQUEST	CKSN = initial CKSN, Mobile Identity = TMSI.
10		←	CM SERVICE ACCEPT	
11		→	An initial CM message	
12			RRC CONNECTION RELEASE	The SS waits for the disconnection of the main signalling link.
13		SS		The UE shall not initiate an RRC connection establishment. This is checked during 2*T3211.
14		UE		If possible (see ICS) SIM detachment is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed.
15		→	RRC CONNECTION REQUEST	Steps 15 to 19 are optional.
16		←	RRC CONNECTION SETUP	
17		→	IMSI DETACH INDICATION	
18		←	RRC CONNECTION RELEASE	
19		UE		Depending on what has been performed in step 14 the UE is brought back to operation.
20		→	RRC CONNECTION REQUEST	Establishment cause: Location updating.
21		←	RRC CONNECTION SETUP	
22		→	LOCATION UPDATING REQUEST	location updating type = IMSI attach, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.
23		SS		performs step 11 of 9.4.3.2.
24		UE		A MO CM connection is attempted.
25		→	RRC CONNECTION REQUEST	
26		←	RRC CONNECTION SETUP	
27		→	CM SERVICE REQUEST	CKSN = initial CKSN, Mobile Identity = TMSI.
28		←	SECURITY MODE COMMAND	
29		→	SECURITY MODE COMPLETE	
30		→	An initial CM message	
31		←	RRC CONNECTION RELEASE	The SS waits for the disconnection of the main signalling link.
32		SS		The UE shall not initiate an RRC connection establishment. This is checked during 2*T3211 UE is "idle, updated" in cell B.
32/1		UE		If possible (see ICS) SIM detachment is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed.
32/2		→	RRC CONNECTION REQUEST	Steps 32/2 to 32/5 are optional.
32/3		←	RRC CONNECTION SETUP	
32/4		→	IMSI DETACH INDICATION	
32/5		←	RRC CONNECTION RELEASE	
32/6		UE		Depending on what has been performed in step 32/1, the UE is brought back to operation.
32/7		→	RRC CONNECTION REQUEST	Establishment cause: Location updating.
32/8		←	RRC CONNECTION SETUP	
32/9		→	LOCATION UPDATING REQUEST	location updating type = IMSI attach, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.
32/10		←	LOCATION UPDATING ACCEPT	without mobile identity

Step	Direction		Message	Comments
	UE	SS		
32/11	←		RRC CONNECTION RELEASE	<p>The SS shall wait at most T3212 + 15 seconds. Establishment cause: Location updating.</p> <p>location updating type = periodic, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI. performs step 16 of 9.4.3.2.</p> <p>The UE shall not initiate an RRC connection establishment during T3211 at least after the RRC CONNECTION release.</p> <p>Establishment cause: Location updating.</p> <p>location updating type = periodic, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI. performs step 5 of 9.4.3.2 with cause #17 and step 6 of 9.4.3.2.</p> <p>The UE shall not initiate an RRC connection establishment during T3211 at least after the RRC CONNECTION release.</p> <p>Establishment cause: Location updating.</p> <p>location updating type = periodic, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI. performs step 11 of 9.4.3.2.</p> <p>The UE shall not initiate an RRC connection establishment within T3211 + RadioLinkTimeout after the SS deactivates the SACCH.</p>
33	SS			
34	→		RRC CONNECTION REQUEST	
35	←		RRC CONNECTION SETUP	
36	→		LOCATION UPDATING REQUEST	
37	SS			
38	UE			
39	→		RRC CONNECTION REQUEST	
40	←		RRC CONNECTION SETUP	
41	→		LOCATION UPDATING REQUEST	
42	SS			
43	UE			
44	→		RRC CONNECTION REQUEST	
45	←		RRC CONNECTION SETUP	
46	→		LOCATION UPDATING REQUEST	
47	SS			
48	UE			
49	→		RRC CONNECTION REQUEST	Establishment cause: Location updating.
50	←		RRC CONNECTION SETUP	
51	→		LOCATION UPDATING REQUEST	
52	SS			<p>performs step 16 of 9.4.3.2.</p> <p>The UE shall not initiate an RRC connection establishment during T3212 - 15 seconds at least after the RRC CONNECTION release.</p> <p>Establishment cause: Location updating.</p> <p>location updating type = periodic or normal (see Note 1), CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE) mobile station classmark 1 as given by the ICS and mobile identity = IMSI.</p> <p>IE mobile Identity = TMSI.</p> <p>The SS waits for the disconnection of the main signalling link.</p> <p>The UE shall no initiate an RRC connection establishment earlier than T3212 - 15 seconds after the transmission of the RRC CONNECTION RELEASE in step 60.</p> <p>Establishment cause: Location updating.</p> <p>location updating type = periodic, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI. performs step 5 of 9.4.3.2 with cause #17 and step 6 of 9.4.3.2.</p>
53	UE			
54	→		RRC CONNECTION REQUEST	
55	←		RRC CONNECTION SETUP	
56	→		LOCATION UPDATING REQUEST	
57	←		AUTHENTICATION REQUEST	
58	→		AUTHENTICATION RESPONSE	
59a	←		LOCATION UPDATING ACCEPT	
			TMSI REALLOCATION	
59b	→		COMPLETE	
60	←		RRC CONNECTION RELEASE	
61	UE			
62	→		RRC CONNECTION REQUEST	
63	←		RRC CONNECTION SETUP	
64	→		LOCATION UPDATING REQUEST	
65	SS			

Step	Direction		Message	Comments
	UE	SS		
66	UE		RRC CONNECTION REQUEST RRC CONNECTION SETUP LOCATION UPDATING REQUEST	The UE shall not initiate an RRC connection establishment during T3211 at least after the RRC CONNECTION release.
67	→			Establishment cause: Location updating.
68	←			
69	→			location updating type = periodic, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.
70	SS			performs step 11 of 9.4.3.2.
71	UE			The UE shall not initiate an RRC connection establishment within T3211 + RadioLinkTimeout after the SS deactivates the SACCH.
72	→		RRC CONNECTION REQUEST RRC CONNECTION SETUP LOCATION UPDATING REQUEST	Establishment cause: Location updating.
73	←			
74	→			location updating type = periodic, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.
75	SS			performs step 16 of 9.4.3.2.
76	UE			The UE shall not initiate an RRC connection establishment during T3211 at least after the RRC CONNECTION release.
77	→		RRC CONNECTION REQUEST RRC CONNECTION SETUP LOCATION UPDATING REQUEST	Establishment cause: Location updating.
78	←			
79	→			location updating type = periodic, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.
80	SS			performs step 5 of 9.4.3.2 with cause #17 and step 6 of 9.4.3.2.
81	UE			A MO CM connection is attempted.
82	→		RRC CONNECTION REQUEST RRC CONNECTION SETUP LOCATION UPDATING REQUEST	Establishment cause: Location updating.
83	←			
84	→			location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE) mobile station classmark 1 as given by the ICS and mobile identity = IMSI.
85	←			IE mobile identity = TMSI.
86	→			
87	←		LOCATION UPDATING ACCEPT TMSI REALLOCATION COMPLETE RRC CONNECTION RELEASE	
88	→		RRC CONNECTION REQUEST RRC CONNECTION SETUP CM SERVICE REQUEST CM SERVICE REJECT RRC CONNECTION RELEASE	Steps 88 to 92 are optional Wait 10 s to decide whether to go directly to step 93.
89	←			
90	→			CKSN = no key available, Mobile identity = TMSI
91	←			cause #17 (network failure).
92	←			
93	UE			If possible (see ICS) SIM detachment is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed.
94	→		RRC CONNECTION REQUEST RRC CONNECTION SETUP IMSI DETACH INDICATION RRC CONNECTION RELEASE	Steps 94 to 97 are optional.
95	←			
96	→			
97	←			
98	UE		RRC CONNECTION REQUEST RRC CONNECTION SETUP LOCATION UPDATING REQUEST	Depending on what has been performed in step 97 the UE is brought back to operation.
99	→			Establishment cause: Location updating.
100	←			
101	→			location updating type = IMSI attach, CKSN = no key available, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.
102	SS			performs step 11 of 9.4.3.2.

Step	Direction		Message	Comments
	UE	SS		
103	UE		RRC CONNECTION REQUEST RRC CONNECTION SETUP LOCATION UPDATING REQUEST	The UE shall not initiate an RRC connection establishment within T3211 + RadioLinkTimeout after the SS deactivates the SACCH. Establishment cause: Location updating.  location updating type = IMSI attach, CKSN = no key available, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.
104	→			
105	←			
106	→			
107	←		RRC CONNECTION RELEASE	After the sending of the message the SS waits for the disconnection of the main signalling link.
108	UE		RRC CONNECTION REQUEST RRC CONNECTION SETUP LOCATION UPDATING REQUEST	The UE shall not initiate an RRC connection establishment during T3211 at least after the RRC CONNECTION release. Establishment cause: Location updating.  location updating type = IMSI attach, CKSN = no key available, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.
109	→			
110	←			
111	→			
112a	←		LOCATION UPDATING REJECT	IE Reject cause is set to a value arbitrarily chosen: * in table 10.66 of, causes #2, #3, #6, #11, #12, and #13 being excluded.
112b	→		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
113	UE		RRC CONNECTION REQUEST RRC CONNECTION SETUP LOCATION UPDATING REQUEST	The UE shall not initiate an RRC connection establishment during T3211 at least after the RRC CONNECTION release. Establishment cause: Location updating.  location updating type = IMSI attach, CKSN = no key available, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.
114	→			
115	←			
116	→			
117	SS		RRC CONNECTION REQUEST RRC CONNECTION SETUP	performs step 11 of 9.4.3.2. The UE shall not initiate an RRC connection establishment during T3212 - 15 seconds at least after the RRC CONNECTION release. Establishment cause: Location updating.
118	UE			
119	→			
120	←			
121	→		LOCATION UPDATING REQUEST	location updating type = periodic or normal or IMSI attach (see Note 2), CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE) mobile station classmark 1 as given by the ICS and mobile identity = IMSI.  IE mobile Identity = TMSI.
122	←		AUTHENTICATION REQUEST	
123	→		AUTHENTICATION RESPONSE	
124	←		LOCATION UPDATING ACCEPT	
125	→		TMSI REALLOCATION COMPLETE	
126	←		RRC CONNECTION RELEASE	
127	UE			If possible (see ICS) SIM detachment is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed.
128	→		RRC CONNECTION REQUEST	Steps 128 to 131 are optional.
129	←		RRC CONNECTION SETUP	
130	→		IMSI DETACH INDICATION	
131	←		RRC CONNECTION RELEASE	
132	UE		RRC CONNECTION REQUEST RRC CONNECTION SETUP LOCATION UPDATING REQUEST	Depending on what has been performed in step 130 the UE is brought back to operation. Establishment cause: Location updating.  location updating type = IMSI attach, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.
133	→			
134	←			
135	→			
136	SS			performs step 16 of 9.4.3.2.

Step	Direction		Message	Comments
	UE	SS		
137	UE			The UE shall not initiate an RRC connection establishment during T3211 at least after the RRC CONNECTION release.
138	→		RRC CONNECTION REQUEST RRC CONNECTION SETUP LOCATION UPDATING REQUEST	Establishment cause: Location updating.
139	←			location updating type = IMSI attach, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI. performs step 5 of 9.4.3.2 with cause #17 and step 6 of 9.4.3.2. The UE shall not initiate an RRC connection establishment during T3211 at least after the RRC CONNECTION release. Establishment cause: Location updating.
140	→			
141	SS			
142	UE			
143	→		RRC CONNECTION REQUEST RRC CONNECTION SETUP	Establishment cause: Location updating.
144	←			
145	→		LOCATION UPDATING REQUEST	location updating type = IMSI attach, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI. performs step 11 of 9.4.3.2. The UE shall not initiate an RRC connection establishment within T3211 + RadioLinkTimeout after the SS deactivates the SACCH. Establishment cause: Location updating.
146	SS			
147	UE			
148	→		RRC CONNECTION REQUEST RRC CONNECTION SETUP LOCATION UPDATING REQUEST	location updating type = IMSI attach, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI. performs step 16 of 9.4.3.2. The UE is made to perform a MO call. Establishment cause: Location updating.
149	←			
150	→			
151	SS		RRC CONNECTION REQUEST RRC CONNECTION SETUP LOCATION UPDATING REQUEST	location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE) mobile station classmark 1 as given by the ICS and mobile identity = IMSI.
152	UE			
153	→			
154	←			
155	→			
156	←		AUTHENTICATION REQUEST AUTHENTICATION RESPONSE LOCATION UPDATING ACCEPT TMSI REALLOCATION COMPLETE	IE mobile Identity = TMSI.
157	→			
158	←			
159	→			
160	←		RRC CONNECTION RELEASE	
161	UE		RRC CONNECTION REQUEST RRC CONNECTION SETUP CM SERVICE REQUEST CM SERVICE REJECT RRC CONNECTION RELEASE	Steps 161 to 166 are optional. An MO CM connection is attempted.
162	→			CKSN = initial value, Mobile identity = TMSI. cause #17 (network failure).
163	←			
164	→			
165	←			
166	←			

NOTE 1: the UE can include both types of Location updating. As T3212 expires it can be a periodic location updating procedure and as there is no stored LAI it can be a normal one.

NOTE 2: same problem as in note 1. Three types of location updating procedures should be allowed.

#### Specific message contents

None.

## 9.4.4 Location updating / release / expiry of T3240

### 9.4.4.1 Conformance requirement

The User Equipment receiving a LOCATION UPDATING REJECT message shall start T3240: it shall abort the RRC connection at the expiry of timer T3240.

### References

TS 24.008 Clauses 4.4.4.8 and 11.2.

### 9.4.4.2 Test purpose

To verify that the UE aborts the RRC-connection at the expiry of timer T3240.

### 9.4.4.3 Method of test

#### Initial conditions

- System Simulator:
  - two cells: A and B, belonging to different location areas a and b.
- User Equipment:
  - the UE has a valid TMSI. It is "idle updated" on cell A.

#### Related ICS/IXIT statements

None.

#### Foreseen final state of the UE

The UE is "idle updated" on cell B.

#### Test Procedure

A normal location updating procedure is performed. The RRC-connection is not released by the SS within the timer T3240. It is checked that the UE aborts the RRC-connection.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		The RF level of cell A is lowered until the UE selects cell B. "Establishment cause": Location updating.
2	→		RRC CONNECTION REQUEST	
3	←		RRC CONNECTION SETUP	
4	→		LOCATION UPDATING REQUEST	
5	←		LOCATION UPDATING ACCEPT	The SS waits T3240 expiry. The UE shall abort the RRC connection (disconnection of layer 2).
6		SS		
7		UE		

#### Specific message contents

None.

## 9.4.5 Location updating / periodic

### 9.4.5.1 Location updating / periodic spread

#### 9.4.5.1.1 Conformance requirement

- 1) The User Equipments shall perform spreading of the time before performing a periodic location updating when the location updating timer value is reduced.
- 2) The User Equipment shall reset timer T3212 when the User Equipment is deactivated, and shall start with a value between zero and the broadcasted value when reactivated in the same cell, IMSI attach being forbidden.
- 3) When activated the User Equipment shall start timer T3212 with a value randomly drawn in the allowed range.

NOTE: This conformance requirement is not covered by a test purpose. It is intended to be covered by a manufacturer declaration.

#### References

TS 24.008 Clause 4.4.2.

#### 9.4.5.1.2 Test purpose

- 1) To check that when the location updating timer is reduced, the timer running in the UE is started with a value depending on the current timer value and the new broadcasted T3212 value.
- 2) To verify that when the UE is reactivated in the same cell (as the one in which it was deactivated), IMSI attach being forbidden, the UE starts the timer T3212 with a value between zero and the broadcasted value.

NOTE: It is not tested that the value is random.

#### 9.4.5.1.3 Method of test

##### Initial conditions

- System Simulator:
  - one cell, T3212 is set to 30 minutes;
  - IMSI attach is allowed in the cell;
- User Equipment:
  - the UE is deactivated. The stored MCC, MNC and LAC correspond to the broadcasted values. The stored update status is "updated".

##### Related ICS/IXIT statements

None.

##### Foreseen final state of the UE

The UE has a valid TMSI. It is "idle updated".

##### Test procedure

The UE is activated. It performs IMSI attach. 3 minutes after the end of the IMSI attach procedure, the value of T3212 is set to 6 minutes. The UE shall perform periodic location updating 6 minutes after the end of the IMSI attach procedure.

Then, the IMSI attach/detach is forbidden. T3212 is still set to 6 minutes.

The UE is deactivated. The UE is reactivated. It is checked that the UE performs a periodic location updating during the 6 minutes following activation.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		UE		The UE is activated.
2	→		RRC CONNECTION REQUEST	"Establishment cause": Location updating.
3	←		RRC CONNECTION SETUP	
4	→		LOCATION UPDATING REQUEST	"location updating type": IMSI attach.
5	←		LOCATION UPDATING ACCEPT	
6	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
7		SS		3 minutes after step 6 the value of T3212 is set to 6 minutes.
8	→		RRC CONNECTION REQUEST	"Establishment cause": Location updating This message shall be sent by the UE between 5minutes 45s and 6minutes 15s after step 6.
9	←		RRC CONNECTION SETUP	
10	→		LOCATION UPDATING REQUEST	"location updating type": periodic updating.
11	←		LOCATION UPDATING ACCEPT	
12	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
13		SS		IMSI attach/detach is not allowed.
14		UE		The UE is deactivated.
15		UE		The UE is activated.
16		SS		The SS waits until the periodic location updating.
17	→		RRC CONNECTION REQUEST	"Establishment cause": Location updating This message shall arrive during the 7 minutes following the UE activation.
18	←		RRC CONNECTION SETUP	
19	→		LOCATION UPDATING REQUEST	"Location updating type" = periodic.
20	←		LOCATION UPDATING ACCEPT	
21	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.

#### Specific message contents

None.

### 9.4.5.2 Location updating / periodic normal / test 1

#### 9.4.5.2.1 Conformance requirement

- 1 The User Equipment shall stop and reset the timer T3212 of the periodic location updating procedure when the first MM message is received or SECURITY mode setting is completed in the case of MM connection establishment.
- 2 The User Equipment shall stop and reset the timer T3212 of the periodic location updating procedure when the User Equipment has responded to paging and thereafter has received the first correct L3 message that is not an RRC message.

#### References

TS 24.008 Clause 4.4.2.



#### 9.4.5.2.2 Test purpose

To verify that the UE stops and resets the timer T3212 of the periodic location updating procedure when:

- the first MM-message is received in the case of MM-connection establishment, security mode being not set;
- the UE has responded to paging and the first correct L3 message that is not an RRC message is received.

NOTE: T3212 is stopped when the MM-idle state is left and restarted when the MM sublayer returns to that state, substate NORMAL SERVICE or ATTEMPTING TO UPDATE. As a consequence, the exact time when T3212 is reset between those two events cannot be tested.

#### 9.4.5.2.3 Method of test

##### Initial conditions

- System Simulator:
  - 1 cell, default parameters;
  - IMSI attach/detach is not allowed;
  - the T3212 time-out value is 2/10 hour.
- User Equipment:
  - the UE has a valid TMSI. It is "idle updated".

##### Related ICS/IXIT statements

None.

##### Foreseen final state of the UE

The UE has a valid TMSI. It is "idle updated".

##### Test procedure

An UE originated MM connection is established and cleared. The RRC CONNECTION is released. It is checked that the UE performs a periodic location updating 12 minutes after the release of the RRC CONNECTION.

One minute after the periodic location updating, the UE is paged, it sends a RRC CONNECTION REQUEST message and the SS responds with an RRC CONNECTION SETUP message, a call is established and then cleared. It is checked that the UE performs a periodic location updating 12 minutes after the release of the link.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		UE		A MO CM connection is attempted.
2	→		RRC CONNECTION REQUEST	
3	←		RRC CONNECTION SETUP	
4	→		CM SERVICE REQUEST	
5	←		CM SERVICE REJECT	cause #17 (network failure).
6	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
7		SS		The SS waits until the periodic location updating.
8	→		RRC CONNECTION REQUEST	"Establishment cause": Location updating This message shall arrive between 11 minutes 45 s and 12 minutes 15 s after the last release of the RRC connection by the SS.
9	←		RRC CONNECTION SETUP	
10	→		LOCATION UPDATING REQUEST	"Location updating type" = periodic.
11	←		LOCATION UPDATING ACCEPT	
12	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
13		SS		The SS waits 1 minute.
14	←		MOBILE TERMINATED ESTABLISHMENT OF RRC CONNECTION	"Mobile identity" = IMSI.
	→			"Establishment cause": Answer to paging.
	←			
15	→		PAGING RESPONSE	
16	←		AUTHENTICATION REQUEST	
17	→		AUTHENTICATION RESPONSE	
18	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
19		SS		The SS waits until the periodic location updating.
20	→		RRC CONNECTION REQUEST	"Establishment cause": Location updating This message shall arrive between 11 minutes 45 s and 12 minutes 15 s after the last release of the RRC connection by the SS.
21	←		RRC CONNECTION SETUP	
22	→		LOCATION UPDATING REQUEST	"Location updating type" = periodic.
23	←		LOCATION UPDATING ACCEPT	
24	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.

## Specific message contents

None.

## 9.4.5.3 Location updating / periodic normal / test 2

## 9.4.5.3.1 Conformance requirement

When a LOCATION UPDATING ACCEPT or a LOCATION UPDATING REJECT message is received, the timer T3212 is stopped and reset and the User Equipment shall perform a periodic location updating after T3212 expiry.

## References

TS 24.008 Clause 4.4.2.

#### 9.4.5.3.2 Test purpose

To verify that the UE stops and resets the timer T3212 of the periodic location updating procedure when a LOCATION UPDATING ACCEPT message is received.

NOTE: T3212 is stopped when the MM-idle state is left and restarted when the MM sublayer returns to that state, substate NORMAL SERVICE or ATTEMPTING TO UPDATE. As a consequence, the exact time when T3212 is reset between those two events cannot be tested.

#### 9.4.5.3.3 Method of test

##### Initial conditions

- System Simulator:
  - 2 cells, IMSI attach/detach is allowed in both cells;
  - T3212 is set to 6 minutes.
- User Equipment:
  - the UE has a valid TMSI. It is "idle updated" on cell A.

##### Related ICS/IXIT statements

SIM removal possible while UE is powered Yes/No.

Switch off on button yes/No.

##### Foreseen final state of the UE

The UE has a valid TMSI. It is "idle updated" on cell B.

##### Test procedure

A normal location updating is performed. The RRC CONNECTION is released. One minute later, the UE is deactivated, then reactivated in the same cell. It is checked that the UE performs an IMSI attach and a periodic location updating 6 minutes after the IMSI attach.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		The following messages are sent and shall be received on cell B. The RF level of cell A is lowered until the UE selects cell B.
2	→		RRC CONNECTION REQUEST	"establishment cause": Location updating.
3	←		RRC CONNECTION SETUP	
4	→		LOCATION UPDATING REQUEST	"location updating type" = normal.
5	←		LOCATION UPDATING ACCEPT	
6	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
7		SS		The SS waits until the periodic location updating.
8	→		RRC CONNECTION REQUEST	"Establishment cause": Location updating This message shall arrive between 5 minutes 45s and 6 minutes 15 s after the last release of the RRC connection by the SS.
9	←		RRC CONNECTION SETUP	
10	→		LOCATION UPDATING REQUEST	"Location updating type" = periodic.
11	←		LOCATION UPDATING ACCEPT	
12	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
13		UE		If possible (see ICS) SIM removal is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed. steps 14 to 17 may be performed or not depending on the action made in step 13.
14	→		RRC CONNECTION REQUEST	
15	←		RRC CONNECTION SETUP	
16	→		IMSI DETACH INDICATION	
17	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
18		UE		Depending on what has been performed in step 13 the UE is brought back to operation.
19	→		RRC CONNECTION REQUEST	"Establishment cause": Location updating.
20	←		RRC CONNECTION SETUP	
21	→		LOCATION UPDATING REQUEST	"Location updating type" = IMSI attach.
22	←		LOCATION UPDATING ACCEPT	
23	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
24		SS		The SS waits until the periodic location updating.
25	→		RRC CONNECTION REQUEST	"Establishment cause": Location updating This message shall arrive between 5 minutes 45 s and 6 minutes 15s after the last release of the RRC connection by the SS.
26	←		RRC CONNECTION SETUP	
27	→		LOCATION UPDATING REQUEST	"Location updating type" = periodic.
28	←		LOCATION UPDATING ACCEPT	
29	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.

## Specific message contents

None.

#### 9.4.5.4 Location updating / periodic HPLMN search

##### 9.4.5.4.1 Location updating / periodic HPLMN search / UE waits time T

###### 9.4.5.4.1.1 Conformance requirement

When in automatic mode and roaming in the home country, the UE shall make an attempt to access the HPLMN, if the UE is on the VPLMN at time T after since the last attempt.

NOTE: This test is not intended to test every value in the range 6 minutes to 8 hours or the default of 30 minutes, but is intended to check that the mobile is capable of using the value stored on the SIM.

#### References

TS 22.011 Clause 3.2.2.5. and TS 23.122 4.4.3.3.

###### 9.4.5.4.1.2 Test purpose

To verify that when a cell of the HPLMN becomes available, following the successful location request on the VPLMN of the home country and after the first search the mobile has failed to find its HPLMN, that the UE shall perform a location update request on the HPLMN after time T. Where T is the HPLMN Search Period stored in the SIM.

###### 9.4.5.4.1.3 Method of test

#### Initial conditions

- System Simulator:
  - two cells A and B, belonging to different location areas with location identification a and b. Cell A shall be a cell of the HPLMN and Cell B shall be a cell of the VPLMN with a Country Code the same as that of Cell A. Initially Cell A shall not be broadcasting. IMSI attach/detach is not allowed on either cell.
- User Equipment:
  - the UE is switched off. The HPLMN Search Period on the SIM shall be set to 6 minutes. The location area information on the SIM is "deleted".

#### Related ICS/IXIT statements

Switch on/off button Yes/No.

#### Foreseen final state of the UE

The UE is "idle updated" on Cell A.

#### Test Procedure

Only Cell B shall be broadcasting. The UE shall be switched on either by using the Power Switch or by applying power. A normal location updating is performed on Cell B. Cell A shall be made available after 8 minutes, thus ensuring the UE fails to find the HPLMN during its first attempt. It is verified that the UE performs a location update request on Cell A, within 6 minutes after broadcasting of Cell A.

## Expected sequence

Step	Direction		Message	Contents
	UE	SS		
1	→	←	RRC CONNECTION REQUEST RRC CONNECTION SETUP LOCATION UPDATING REQUEST LOCATION UPDATING ACCEPT RRC CONNECTION RELEASE	The following messages shall be sent and received on Cell B. The UE is switched on by either using the Power Switch or by applying power. "Establishment cause": Location updating.
2				"Location Update Type": Normal.
3				
4				After sending this message the SS waits for the disconnection of the main signalling link. The SS waits a period of 8 minutes, this allowing the UE to make its first periodic search.
5				
6				
8	→	←	RRC CONNECTION REQUEST RRC CONNECTION SETUP LOCATION UPDATING REQUEST LOCATION UPDATING ACCEPT RRC CONNECTION RELEASE	Cell A is made available. Within 8 minutes after step 8 the following messages shall be sent and received on Cell A. "Establishment cause": Location updating.
9				"Location Update Type": normal.
10				
11				After sending this message the SS waits for the disconnection of the main signalling link.
12				
13				

## Specific message contents

None.

## 9.4.5.4.2 Location updating / periodic HPLMN search / UE in manual mode

## 9.4.5.4.2.1 Conformance requirement

The periodic attempts shall only be performed if in automatic mode when the UE is roaming in its home country.

## References

TS 22.011 Clause 3.2.2.5. and TS 23.122 4.4.3.3.

## 9.4.5.4.2.2 Test purpose

To verify that no HPLMN Search is performed when the UE is not in automatic mode.

## 9.4.5.4.2.3 Method of test

## Initial conditions

- System Simulator:
  - two cells A and B, belonging to different location areas with location identification a and b. Cell A shall be a cell of the HPLMN and Cell B shall be a cell of the VPLMN with a Country Code the same as that of Cell A. Initially Cell A shall not be broadcasting. IMSI attach/detach is not allowed on either cell.
- User Equipment:
  - the UE is switched off. The HPLMN Search Period on the SIM shall be set to 6 minutes. The location area information on the SIM is "deleted".

## Related ICS/IXIT statements

Switch on/off button Yes/No.

## Foreseen final state of the UE

The UE is "idle updated" on Cell B.

## Test Procedure

Only Cell B shall be broadcasting. The UE shall be switched on either by using the Power Switch or by applying power. A normal location updating is performed on Cell B. The UE is forced into manual selection mode. Cell A is made available. It is verified that the UE does not attempt to perform a location update on Cell A.

## Expected sequence

Step	Direction		Message	Contents
	UE	SS		
1	UE		RRC CONNECTION REQUEST RRC CONNECTION SETUP LOCATION UPDATING REQUEST LOCATION UPDATING ACCEPT RRC CONNECTION RELEASE	The following messages shall be sent and received on Cell B. The UE is switched on by either using the Power Switch or by applying power. "Establishment cause": Location updating.
2	→			"Location Update Type": Normal.
3	←			
4	→			After sending this message the SS waits for the disconnection of the main signalling link.
5	←			
6	←			
8	UE			The UE is forced into manual selection mode.
9	SS			Cell A is made available.
10	SS			The SS waits a period of 7 minutes. During this time no messages shall be received on Cell A.

## Specific message contents

None.

#### 9.4.5.4.3 Location updating / periodic HPLMN search / UE waits at least two minutes and at most T minutes

##### 9.4.5.4.3.1 Conformance requirement

After switch on, the UE waits at least 2 minutes and at most T minutes before the first HPLMN Search is attempted.

## References

TS 22.011 Clause 3.2.2.5. and TS 23.122 4.4.3.3.

##### 9.4.5.4.3.2 Test purpose

To verify that the UE waits at least 2 minutes and at most T minutes before attempting its first HPLMN Search.

##### 9.4.5.4.3.3 Method of test

## Initial Conditions

- System Simulator:

- two cells A and B, belonging to different location areas with location identification a and b. Cell A shall be a cell of the HPLMN and Cell B shall be a cell of the VPLMN with a Country Code the same as that of Cell A. Initially Cell A shall not be broadcasting. IMSI attach/detach is not allowed on either cell.
- User Equipment:
  - the UE is switched off. The HPLMN Search Period on the SIM shall be set to 6 minutes. The location area information on the SIM is "deleted".

#### Related ICS/IXIT statements

Switch on/off button Yes/No.

#### Foreseen final state of the UE

The UE is "idle updated" on Cell A.

#### Test Procedure

Only Cell B shall be broadcasting. The UE shall be switched on either by using the Power Switch or by applying power. A normal location updating is performed on Cell B. Cell A is made available. It is verified that the UE attempts to perform a location update on Cell A, after at least 2 minutes and at most T minutes have passed following power on.

#### Expected sequence

Step	Direction		Message	Contents
	UE	SS		
1	→	←	RRC CONNECTION REQUEST RRC CONNECTION SETUP LOCATION UPDATING REQUEST LOCATION UPDATING ACCEPT RRC CONNECTION RELEASE	The following messages shall be sent and received on Cell B. The UE is switched on by either using the Power Switch or by applying power. "Establishment cause": Location updating. "Location Update Type": Normal.  After sending this message the SS waits for the disconnection of the main signalling link.
2				
3				
4				
5				
6				
8	→	←	RRC CONNECTION REQUEST  RRC CONNECTION SETUP LOCATION UPDATING REQUEST LOCATION UPDATING ACCEPT RRC CONNECTION RELEASE	Cell A is made available. The SS waits a period of 2 minutes after the UE is switched on. During this time no messages shall be received on Cell A. The following messages shall be sent and received on cell A. Within T minutes after the UE is switched on the following messages shall be sent and received on cell A. "Establishment cause": Location updating This message shall be sent between 2 and 7 minutes after step 1 "Location Update Type": normal.  After sending this message the SS waits for the disconnection of the main signalling link.
9				
10				
11				
12				
13				
14				

#### Specific message contents

None.



## 9.4.6 Location updating / interworking of attach and periodic

### 9.4.6.1 Conformance requirement

- 1) If the User Equipment is in service state NO CELL AVAILABLE, LIMITED SERVICE, PLMN SEARCH or PLMN SEARCH-NORMAL SERVICE when the timer expires the location updating procedure is delayed until this service state is left.
- 2) The T3212 time-out value shall not be changed in the NO CELL AVAILABLE, LIMITED SERVICE, PLMN SEARCH and PLMN SEARCH-NORMAL SERVICE states.
- 3) If the selected cell is in the location area where the User Equipment is registered and IMSI ATTACH is not required and timer T3212 has not expired, then the state is NORMAL SERVICE.

### References

- 1) TS 24.008 Clause 4.4.2.
- 2) TS 24.008 Clause 4.4.2.
- 3) TS 24.008 Clause 4.2.1.1.

### 9.4.6.2 Test purpose

- 1) To check that if the PLU timer expires while the UE is out of coverage, the UE informs the network of its return to coverage.
- 2) To check that the PLU timer is not disturbed by cells of forbidden PLMNs.
- 3) To check that if the PLU timer does not expire while out of coverage and if the mobile returns to the LA where it is updated, the mobile does not inform the network of its return to coverage.

### 9.4.6.3 Method of test

#### Initial conditions

- System Simulator:
  - two cells, a and b, of different PLMNs;
  - T3212 is set to 12 minutes on cell a;
  - T3212 is set to 6 minutes on cell b;
  - IMSI attach is allowed in both cells.
- User Equipment:
  - the UE is deactivated. The PLMN of cell b is entered in the SIM's forbidden PLMN list.

#### Related ICS/IXIT statements

None.

#### Foreseen final state of the UE

The UE is "idle updated". The PLMN of cell b is entered in the SIM's forbidden PLMN list.

#### Test procedure

The UE is activated and placed in automatic network selection mode. It performs IMSI attach. 1 minute after the end of the IMSI attach procedure, cell a is switched off. The UE shall not location update on cell b. 8 minutes after the end of

the IMSI attach procedure, cell a is switched on. The UE shall not location update on cell a before 11,75 minutes after the end of the IMSI attach procedure. The UE shall perform a periodic location update on cell a between 11,75 minutes and 12,25 minutes after the end of the IMSI attach procedure.

3 minutes after the end of the periodic location updating procedure, cell a is switched off. The UE shall not location update on cell b. 14 minutes after the end of the periodic location updating procedure, cell a is switched on and cell b is switched off. The UE shall perform a location update on cell a before 17 minutes after the end of the periodic location updating procedure.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		UE		The UE is activated in automatic network selection mode.
2	→		RRC CONNECTION REQUEST	
3	←		RRC CONNECTION SETUP	
4	→		LOCATION UPDATING REQUEST	"location updating type": IMSI attach.
5	←		LOCATION UPDATING ACCEPT	
6	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
7		SS		1 minute after step 6, cell a is switched off.
8		SS		8 minutes after step 6, cell a is switched on.
9	→		RRC CONNECTION REQUEST	This message shall be sent by the UE between 11 minutes 45s and 12 minutes 15s after step 6.
10	←		RRC CONNECTION SETUP	
11	→		LOCATION UPDATING REQUEST	"location updating type": periodic updating.
12	←		LOCATION UPDATING ACCEPT	
13	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.
14		SS		3 minutes after step 13, cell a is switched off.
15		SS		14 minutes after step 13, cell a is switched on and cell b is switched off.
16	→		RRC CONNECTION REQUEST	This message shall be sent by the UE before 17 minutes after step 13.
17	←		RRC CONNECTION SETUP	
18	→		LOCATION UPDATING REQUEST	"Location updating type" = periodic.
19	←		LOCATION UPDATING ACCEPT	
22	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.

#### Specific message contents

None.

## 9.5 MM connection

### 9.5.1 Introduction

[tbd]

### 9.5.2 MM connection / establishment with cipher

#### 9.5.2.1 Conformance requirement

- 1) The User Equipment shall be able to correctly set up an MM connection in a Mobile Originating CM connection attempt and send a CM Service Request message with CKSN information element as stored in the SIM and Mobile Identity information element set to the TMSI.

- 2) The User Equipment shall be able to interpret cipher mode setting as acceptance of its CM service request i.e. send a CM message.

## References

TS 24.008 Clause 4.5.1.1.

### 9.5.2.2 Test purpose

To verify that the UE can correctly set up an MM connection in an origination and interpret cipher mode setting as acceptance of its CM service request.

### 9.5.2.3 Method of test

#### Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE has a valid TMSI. It is "idle updated".

#### Related ICS/IXIT statements

None.

#### Foreseen final state of the UE

The UE has valid TMSI, CKSN. It is "idle updated".

#### Test Procedure

A mobile originating CM connection is initiated. After the UE has sent the CM SERVICE REQUEST message to the SS, an authentication procedure and a security mode setting procedure are performed. Then, the UE sends a CM message and the SS clears the call and releases the RRC CONNECTION.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	→	UE		A MO CM connection is attempted.
2	→		RRC CONNECTION REQUEST	
3	←		RRC CONNECTION SETUP	
4	→		CM SERVICE REQUEST	
5	←		AUTHENTICATION REQUEST	
6	→		AUTHENTICATION RESPONSE	
7	←		SECURITY MODE COMMAND	
8	→		CIPHERING SECURITY MODE COMPLETE	
A9	→		SETUP	"Cause" IE: "unassigned number".
A10	←		RELEASE COMPLETE	
B9	→		REGISTER	
B10	←		RELEASE COMPLETE	
C9	→		CP-DATA	
C10	←		CP-ACK	
C11	←		CP-DATA	
C12	→		CP-ACK	
13	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.

Specific message contents

None.

### 9.5.3 MM connection / establishment without cipher

#### 9.5.3.1 Conformance requirement

Upon reception of the CM SERVICE ACCEPT message, the UE shall send a CM message.

#### References

TS 24.008 Clause 4.5.1.1.

#### 9.5.3.2 Test purpose

To verify that the UE can correctly set up an MM connection in an originating CM connection establishment when security mode setting is not required.

#### 9.5.3.3 Method of test

##### Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE has a valid TMSI. It is "idle updated".

##### Related ICS/IXIT statements

None.

##### Foreseen final state of the UE

The UE has a valid TMSI. It is "idle updated".

##### Test Procedure

A mobile originating CM connection is attempted. The MM-connection is established without invoking the security mode setting procedure.

Then, the UE sends a CM message and the SS releases the RRC CONNECTION.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		UE		A MO CM connection is attempted.
2	→		RRC CONNECTION REQUEST	
3	←		RRC CONNECTION SETUP	
4	→		CM SERVICE REQUEST	
5	←		CM SERVICE ACCEPT	
A6	→		SETUP	
B6	→		REGISTER	
C6	→		CP-DATA	
C7	←		CP-ACK	
C8	←		CP-DATA	
C9	→		CP-ACK	
10	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.

Specific message contents

None.

## 9.5.4 MM connection / establishment rejected

### 9.5.4.1 Conformance requirement

Upon reception of a CM SERVICE REJECT message, the UE shall not send any layer 3 message, start timer T3240 and enter the "wait for network command" state.

References

TS 24.008 Clause 4.5.1.1.

### 9.5.4.2 Test purpose

To verify that the UE does not send a layer 3 message when the service request is rejected by the SS.

### 9.5.4.3 Method of test

Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE has a valid TMSI. It is "idle updated".

Related ICS/IXIT statements

None.

Foreseen final state of the UE

The UE has a valid TMSI; It is "idle updated".

## Test Procedure

A mobile originating CM connection is attempted. After the UE has sent the CM SERVICE REQUEST message to the SS, the SS responds with a CM SERVICE REJECT message with reject cause "requested service option not subscribed". It is checked that the UE does not send a layer 3 message.

### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			A MO CM connection is attempted
2	→		RRC CONNECTION REQUEST	
3	←		RRC CONNECTION SETUP	
4	→		CM SERVICE REQUEST	
5	←		CM SERVICE REJECT	
6		SS		"Reject cause" IE: "requested service option not subscribed". The UE shall not send a layer 3 message. This is checked during 5 seconds.
7		←	RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.

### Specific message contents

None.

## 9.5.5 MM connection / establishment rejected cause 4

### 9.5.5.1 Conformance requirement

- 1) The User Equipment shall be able to correctly set up an MM connection in a Mobile Originating CM connection attempt and send a CM Service Request message with CKSN information element as stored in the SIM and Mobile Identity information element set to the TMSI.
- 2) The User Equipment, when receiving a CM SERVICE REJECT message with reject cause "IMSI unknown in VLR" shall wait for the network to release the RRC connection.
- 3) The User Equipment shall then be able to perform a location updating procedure.

### References

TS 24.008 Clause 4.5.1.1.

### 9.5.5.2 Test purpose

To verify that the UE can correctly accept a CM SERVICE REJECT message with reject cause "IMSI unknown in VLR".

### 9.5.5.3 Method of test

#### Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE has a valid TMSI. It is "idle updated".

## Related ICS/IXIT statements

None.

## Foreseen final state of the UE

The UE has valid TMSI, CKSN. It is "idle updated".

## Test Procedure

A mobile originating CM connection is attempted. After the UE has sent the CM SERVICE REQUEST message to the SS, the SS responds with a CM SERVICE REJECT message with reject cause "IMSI unknown in VLR". On receipt of this message, the UE shall delete any TMSI, LAI, cipher key and cipher key sequence number. The RRC CONNECTION is released. It is checked that the UE performs a normal location updating procedure.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		UE		A MO CM connection is attempted.
2	→		RRC CONNECTION REQUEST	
3	←		RRC CONNECTION SETUP	
4	→		CM SERVICE REQUEST	"Reject cause" = "IMSI unknown in VLR". After the sending of this message, the SS waits for the disconnection of the main signalling link.
5	←		CM SERVICE REJECT	
6	←		RRC CONNECTION RELEASE	
7	→		RRC CONNECTION REQUEST	"Establishment cause": Location updating.
8	←		RRC CONNECTION SETUP	
9	→		LOCATION UPDATING REQUEST	
10	←		AUTHENTICATION REQUEST	"Ciphering key sequence number" = "No key is available". "Mobile identity" = IMSI. "Location area identification" = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE).
11	→		AUTHENTICATION RESPONSE	
12	←		LOCATION UPDATING ACCEPT	
13	→		TMSI REALLOCATION COMPLETE	"Mobile identity" = new TMSI.
14	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.

## Specific message contents

None.

## 9.5.6 MM connection / expiry T3230

### 9.5.6.1 Conformance requirement

At T3230 expiry (i.e. no response is given but an RRC connection is available) the MM connection establishment shall be aborted.

## References

TS 24.008 Clauses 4.5.1.2 and 11.2.

### 9.5.6.2 Test purpose

To verify that at T3230 expiry, the UE aborts the MM-connection establishment.

## 9.5.6.3 Method of test

## Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE has a valid TMSI. It is "idle updated".

## Related ICS/IXIT statements

None.

## Foreseen final state of the UE

The UE has a valid TMSI. It is "idle updated".

## Test Procedure

A mobile originating CM connection is attempted. After the UE has sent the CM SERVICE REQUEST message to the SS, the SS waits for expiry of timer T3230. It is checked that the UE does not send a layer 3 message but waits for the release of the RRC-connection.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			A MO CM connection is attempted.
2	→		RRC CONNECTION REQUEST	
3	←		RRC CONNECTION SETUP	
4	→		CM SERVICE REQUEST	
5		SS		The SS waits for expiry of timer T3230.
6	←		CM SERVICE ACCEPT	
7	→		MM STATUS	"Reject cause " IE is "message not compatible with the call state or not implemented". After the sending of this message, the SS waits for the disconnection of the main signalling link.
8	←		RRC CONNECTION RELEASE	

## Specific message contents

None.

## 9.5.7 MM connection / abortion by the network

## 9.5.7.1 MM connection / abortion by the network / cause #6

## 9.5.7.1.1 Conformance requirement

- 1) Upon reception of an ABORT message, the UE shall release any ongoing MM connection and enter the "wait for network command" state.
- 2) If the cause in the ABORT message was cause #6, the User Equipment shall:
  - 2.1 not perform normal location updating;
  - 2.2 not perform periodic location updating;



2.3 not respond to paging with TMSI;

2.4 reject any request for Mobile Originating call establishment except Emergency call;

2.5 not perform IMSI detach if deactivated.

- 3) After reception of an ABORT message with cause #6, the User Equipment, if it supports speech, shall accept a request for an emergency call by sending a RRC CONNECTION Request message with the establishment cause set to "emergency call".
- 4) After reception of an ABORT message with cause #6, the User Equipment shall delete the stored LAI, CKSN and TMSI.

#### Reference(s)

TS 24.008 Clause 4.3.5.

#### 9.5.7.1.2 Test purpose

To check that upon reception of an ABORT message with cause #6 during call establishment:

- the UE does not send any layer 3 message;
- after reception of an ABORT message and after having been deactivated and reactivated, the UE performs location updating using its IMSI as mobile identity and indicates deleted LAI and CKSN;
- the UE does not perform location updating, does not answer to paging with TMSI, rejects any request for mobile originating call except emergency call, does not perform IMSI detach;
- the UE accepts a request for emergency call.

#### 9.5.7.1.3 Method of test

##### Initial Conditions

- System Simulator:
  - 2 cells, default parameters.
- User Equipment:
  - the UE has a valid TMSI, CKSN and Kc. It is "idle updated" on cell B.

##### Related ICS/IXIT Statement(s)

SIM removal possible while UE is powered Yes/No.

Switch off on button Yes/No.

Support of speech Yes/No.

##### Foreseen final state of the UE

The UE has a valid TMSI. It is "idle updated" on cell A.

##### Test procedure

A mobile originating CM connection is attempted. Upon reception of the AUTHENTICATION RESPONSE message, the SS sends an ABORT message with cause #6. The SS waits for 5 seconds. The UE shall not send any layer 3 message. The SS releases the RRC connection.

The SS checks that the UE has entered the state MM IDLE substate NO IMSI, i.e. does not perform normal location updating, does not perform periodic updating, does not respond to paging, rejects any requests from CM entities except emergency calls and does not perform IMSI detach if deactivated.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
The following messages are sent and shall be received on cell B				
1	UE	RRC CONNECTION REQUEST RRC CONNECTION SETUP CM SERVICE REQUEST AUTHENTICATION REQUEST AUTHENTICATION RESPONSE ABORT	A mobile originating CM connection is attempted.  "reject cause" = #6. The SS waits for 5 seconds. The UE shall not send any layer 3 message during that time. After the sending of this message, the SS waits for the disconnection of the main signalling link.	
2	→			
3	←			
4	→			
5	→			
6	→			
7	←			
8	SS			
9	UE			
10	←	RRC CONNECTION RELEASE		
The following messages are sent and shall be received on cell A.				
11	SS		The RF levels are changed to make the UE reselect cell A.	
12	UE		The UE performs cell reselection according to procedure as specified in (this however is not checked until step 22). The UE shall not initiate an RRC connection establishment on cell A or on cell B.	
13	SS		The SS waits at least 7 minutes for a possible periodic updating.	
14	UE		The UE shall not initiate an RRC connection establishment on cell A or on cell B.	
15	←	MOBILE TERMINATED ESTABLISHMENT OF RRC CONNECTION	"Mobile identity" IE contains TMSI.	
16	UE		The UE shall not initiate an RRC connection establishment on cell A or on cell B. This is verified during 3 seconds.	
17	UE		A MO CM connection is attempted.	
18	UE		The UE shall not initiate an RRC connection establishment on cell A or on cell B. This is checked during 3 seconds.	
19	UE	CM SERVICE REQUEST CM SERVICE ACCEPT EMERGENCY SETUP RELEASE COMPLETE RRC CONNECTION RELEASE	If the UE supports speech (see ICS), an emergency call is attempted.	
	→		"Establishment cause": Emergency call.	
	←			
20	→		"CM service type": Emergency call establishment.	
21	←			
22	→			
23	←			
24	←		"Cause" = unassigned number. After the sending of this message, the SS waits for the disconnection of the main signalling link.	
25	UE		If possible (see ICS) SIM detachment is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed.	
26	UE		The UE shall not initiate an RRC connection establishment on cell A or on cell B. This is checked during 3 seconds.	
27	UE	RRC CONNECTION REQUEST RRC CONNECTION SETUP LOCATION UPDATING REQUEST	Depending on what has been performed in step 29 the UE is brought back to operation.	
28	→		"Establishment cause": Location updating.	
29	←			
30	→		"location updating type" = normal, "CKSN" = no key available, "Mobile Identity" = IMSI, "LAI" = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE).	
31	←		"CKSN" = CKSN1.	
		AUTHENTICATION REQUEST		

Step	Direction		Message	Comments
	UE	SS		
32	→		AUTHENTICATION RESPONSE	"Mobile Identity" = TMSI.
33	←		LOCATION UPDATING ACCEPT	
34	→		TMSI REALLOCATION COMPLETE	
35	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.

#### Specific message contents

None.

### 9.5.7.2 MM connection / abortion by the network / cause not equal to #6

#### 9.5.7.2.1 Conformance requirement

Upon reception of an ABORT message, the UE shall release any ongoing MM connection and enter the "wait for network command" state.

#### Reference(s)

TS 24.008 Clause 4.3.5.

#### 9.5.7.2.2 Test purpose

To check that when multiple MM connections are established, the UE releases all MM connections upon reception of an ABORT message, in the case when the two MM connections are established for a mobile terminating call and a non call related supplementary service operation.

#### 9.5.7.2.3 Method of test

#### Initial Conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE is in state U10 of a mobile terminating call.

#### Related ICS/IXIT Statement(s)

The UE supports a non call related supplementary service operation during an active call Yes/No.

#### Foreseen final state of the UE

The UE has a valid TMSI. It is "idle updated".

#### Test procedure

A non call related supplementary service operation is attempted at the UE. Upon reception of the REGISTER message, the SS sends an ABORT message with cause # 17. The SS sends a DISCONNECT using the TI of the mobile terminating call. The UE shall send a RELEASE COMPLETE message with the PD and TI of the DISCONNECT message and with cause #81. The SS releases the RRC connection.

## Expected Sequence

This procedure is performed if the UE supports non call related supplementary service operation.

Step	Direction		Message	Comments
	UE	SS		
1	UE			A non call related supplementary service operation is attempted at the UE.  "reject cause" = #17. with the TI of the mobile terminating call. "cause" = #81. Same PD and TI as the DISCONNECT message. After the sending of this message, the SS waits for the disconnection of the main signalling link.
2	→		CM SERVICE REQUEST	
3	←		CM SERVICE ACCEPT	
4	→		REGISTER	
5	←		ABORT	
6	←		DISCONNECT	
7	→		RELEASE COMPLETE	
8	←		RRC CONNECTION RELEASE	

## Specific message contents

None.

## 9.5.8 MM connection / follow-on request pending

### 9.5.8.1 MM connection / follow-on request pending / test 1

#### 9.5.8.1.1 Conformance requirement

The UE shall not attempt to establish a new MM connection after location updating on the same RRC connection if not allowed by the network.

## Reference(s)

TS 24.008 Clause 4.4.4.6.

#### 9.5.8.1.2 Test purpose

To check that when the network does not include the follow on proceed IE in a LOCATION UPDATING ACCEPT message, a UE that has a CM application request pending does not attempt to establish a new MM connection on that RRC connection.

#### 9.5.8.1.3 Method of test

## Initial Conditions

- System Simulator:
  - 1 cell, ATT flag is set to "MSs in the cell shall apply IMSI attach and detach procedure".
- User Equipment:
  - the UE has a valid TMSI and is deactivated.

## Related ICS/IXIT Statement(s)

None.

Foreseen final state of the UE

The UE has a valid TMSI. It is "idle updated".

Test procedure

The UE is activated and a CM connection is attempted during the location updating procedure. The SS does not include the follow on proceed information element in the LOCATION UPDATING ACCEPT message. The SS waits for at least 8 seconds. The UE shall not send any layer 3 message for 8 seconds.

Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		UE		The UE is activated.
2	→		RRC CONNECTION REQUEST	
3	←		RRC CONNECTION SETUP	
4	→		LOCATION UPDATING REQUEST	location updating type = IMSI attach. Then the SS waits for 15 s. During this delay a CM connection is attempted.
5	←		LOCATION UPDATING ACCEPT	follow on proceed IE not included. The SS wait for at least 8 seconds.
6		SS		The UE shall not send any layer 3 message for 8 seconds after reception of the LOCATION UPDATING ACCEPT message.
7		UE		
8	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.

Specific message contents

None.

## 9.5.8.2 MM connection / follow-on request pending / test 2

### 9.5.8.2.1 Conformance requirement

A UE supporting the follow-on request procedure and having a CM connection request pending shall correctly establish an MM connection following a location update when allowed by the network.

Reference(s)

TS 24.008 Clause 4.4.4.6.

### 9.5.8.2.2 Test purpose

To check that when the network includes the follow on proceed IE in a LOCATION UPDATING ACCEPT message, a UE that supports the follow on request procedure and that has a CM application request pending establishes successfully a new MM connection on that RRC connection.

### 9.5.8.2.3 Method of test

Initial Conditions

- System Simulator:
  - 1 cell, ATT flag is set to "MSs in the cell shall apply IMSI attach and detach procedure".
- User Equipment:
  - the UE has a valid TMSI and is deactivated.

## Related ICS/IXIT Statement(s)

UE supports the follow on request procedure Yes/No.

## Foreseen final state of the UE

The UE has a valid TMSI. It is "idle updated".

## Test procedure

The UE is activated and a CM connection is attempted during the location updating procedure. The SS includes the follow on proceed information element in the LOCATION UPDATING ACCEPT message. The SS waits for at least 8 seconds.

If the UE supports the follow on request procedure:

- the UE shall send a CM SERVICE REQUEST. Upon reception of that message, the SS sends a CM SERVICE ACCEPT message. The UE shall send an initial CM message. Upon reception of that message, the SS releases the RRC connection.

If the UE does not support the follow on request procedure:

- the UE shall not send any layer 3 message for 8 seconds.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The UE is activated.
2	→		RRC CONNECTION REQUEST	
3	←		RRC CONNECTION SETUP	
4	→		LOCATION UPDATING REQUEST	Location updating type = IMSI attach. Then the SS waits for 15 s. During this delay a CM connection is attempted.
5	←		LOCATION UPDATING ACCEPT	follow on proceed IE included.
				If the UE supports the follow on request procedure (see ICS) steps A6 to A8 are performed, otherwise steps B6 to B7 are performed.
A6	→		CM SERVICE REQUEST	
A7	←		CM SERVICE ACCEPT	
A8	→		An initial CM message	
B6	SS			The SS wait for at least 8 seconds.
B7	UE			The UE shall not send any layer 3 message for 8 seconds after reception of the LOCATION UPDATING ACCEPT message.
9	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.

## Specific message contents

None.

### 9.5.8.3 MM connection / follow-on request pending / test 3

#### 9.5.8.3.1 Conformance requirement

- 1) The UE shall not set the follow on request bit in a LOCATION UPDATING REQUEST message if no MM connection request is pending.
- 2) When the network includes the follow on proceed IE in a LOCATION UPDATING ACCEPT message, a UE that has no CM application request pending shall not attempt to establish a new MM connection on that RRC connection.
- 3) The UE shall correctly handle a CM connection established by the network on the RRC connection that was used for the location updating procedure.

#### Reference(s)

TS 24.008 Clause 4.4.4.6.

#### 9.5.8.3.2 Test purpose

- 1) To check that a UE that has no CM application request pending sets the Follow-On-Request bit to No follow-on request pending in a LOCATION UPDATING REQUEST message.
- 2) To check that when the network includes the follow on proceed IE in a LOCATION UPDATING ACCEPT message, a UE that has no CM application request pending does not attempt to establish a new MM connection on that RRC connection.
- 3) To check that the UE accepts establishment by the network of a new MM connection on the existing RRC connection.

#### 9.5.8.3.3 Method of test

##### Initial Conditions

- System Simulator:
  - 1 cell, ATT flag is set to "MSs in the cell shall apply IMSI attach and detach procedure".
- User Equipment:
  - the UE has a valid TMSI and is deactivated.

##### Related ICS/IXIT Statement(s)

Supported services on TCH.

##### Foreseen final state of the UE

The UE has a valid TMSI. It is "idle updated".

##### Test procedure

The UE is activated. The UE performs location updating. The UE shall set the FOR bit to No follow-on request pending in the LOCATION UPDATING REQUEST message. The SS includes the follow on proceed information element in the LOCATION UPDATING ACCEPT message. The SS waits for 5 seconds. The UE shall not send any layer 3 message for 5 seconds. The SS sends a SETUP message to the UE requesting a basic service supported by the UE. The UE shall send either a CALL CONFIRMED message if it supports a service on TCH or a RELEASE COMPLETE with cause #88.



## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		UE		The UE is activated.
2	→		RRC CONNECTION REQUEST	
3	←		RRC CONNECTION SETUP	
4	→		LOCATION UPDATING REQUEST	"Location updating type" = IMSI attach. The FOR bit is set to No follow-on request pending.
5	←		LOCATION UPDATING ACCEPT	follow on proceed IE is included.
6		SS		The SS wait for 5 seconds.
7		UE		The UE shall not send any layer 3 message for 5 seconds after reception of the LOCATION UPDATING ACCEPT message.
8	←		SETUP	
A9	→		CALL CONFIRMED	If the UE supports a basic service on TCH.
B9	→		RELEASE COMPLETE	If the UE does not support any basic service on TCH. cause #88.
10	←		RRC CONNECTION RELEASE	After the sending of this message, the SS waits for the disconnection of the main signalling link.

## Specific message contents

None.

## 10 Circuit Switched Call Control (CC)

### 10.1 Circuit switched Call Control (CC) state machine verification

#### 10.1.1 General on CC state machine verification

The principle of checking the call control functions consists in the validation of each call control identified state.

State U0 as an initial state is not verified in the tests of 10.1.2 (establishment of an outgoing call).

State U0.1 is never verified.

The steps to be followed within each performed test are:

- bring the UE into the required state;
- trigger the tested event;
- check the UE response and new state.

In clauses 10.1.2 and 10.1.3 different tables are defined to bring the UE into the required initial state. The exact table to be chosen is specified individually in clause "Initial conditions" of "Method of test" for each test case.

For each test, unless otherwise specified, a circuit switched basic service among those supported by the UE but excluding the emergency call teleservice shall be chosen arbitrarily, and the test shall be performed according to that basic service. If the only circuit switched basic service supported by the mobile is emergency call, then the incoming call tests shall not be performed and the other call control tests shall be performed with the EMERGENCY SETUP message replacing the SETUP message.

The initial states are to be checked through STATUS ENQUIRY messages sent by the SS, when feasible. This is not explicitly stated in the tables of expected sequences of signalling messages. The checking of final states are explicitly included into the expected sequences of signalling messages.

The following postamble may be used by the SS to bring UE back to idle mode in those test cases, in which it is not already included into expected sequence of signalling messages:

**Table 10.1.1/1: A postamble to bring the UE back to idle mode.**

Step	Direction		Message	Comments
	UE	SS		
N n+1 n+2	<-- --> UE		RRC CONNECTION RELEASE RRC CONNECTION RELEASE COMPLETE	the UE shall release the main signalling link

The postamble has not been included into the all of the tests in order to leave an option to concatenate the procedures in the future by using a final state of a test case as an initial state to another one.

For the special case of U0, the state is checked by sending STATUS ENQUIRY message with all possible values of transaction identifier (seven values) as U0 is the only state in which for every TI the UE will answer with release complete with cause #81. If U0 is to be verified when no RRC connection exists, first a mobile terminating radio connection must be established.

The UE responses are either call management messages received by the SS or lower layers functions activated within the UE or MMI actions (e.g. the buzzing of an alerting tone).

A time-out within the UE is triggered by the SS when it does not answer back an UE expected response.

The test sequences may be split in 3 main groups:

- establishment and release of an outgoing call;
- establishment and release of an incoming call;
- in-call functions.

Some test cases use Basic Generic Procedures, "Mobile terminated establishment of rrc connection" and "Radio Bearer Setup Procedure" defined in TS34.108 clause 7.

General tolerance value on protocol timers defined in TS34.108 is used in some test cases if no specific tolerance on timer is defined in a test case.

Remark on verification of transient states:

Some call control states of the user equipment may be transient, depending on implementation, configuration of the UE and previous messages.

If a test starts in a transient state, then the test is executed without verification of the starting state.

## 10.1.2 Establishment of an outgoing call

Initial conditions

As a minimum requirement the UE is updated and has been given a TMSI, a ciphering key and cipher key sequence number, and the layer 2, RRC and MM functionalities have been verified.

There are as many CM initial conditions as states to be checked.

The tables below describe message exchanges which bring the UE in the requested initial states.

A state may be taken as initial only when all the states which lead to this initial states have been validated. The order followed in the test procedure will be U0, U0.1, U1, U3, U4, U10, U12, U19, U11 as seen in the table underneath.

The UE is brought again in the initial state starting with U0 at each new test performed.

**Table 10.1.2/1: Establishment of an outgoing call, procedure 1 (late assignment)**

Step	Direction		Message	Comments
	UE	SS		
1	->		RRC CONNECTION REQUEST	Initiate outgoing call
2	<-		RRC CONNECTION SETUP	
3	->		RRC CONNECTION SETUP COMPLETE	
4	->		CM SERVICE REQUEST	
5	<-		AUTHENTICATION REQUEST	U0.1
6	->		AUTHENTICATION RESPONSE	
7	<-		SECURITY MODE COMMAND	
8	->		SECURITY MODE COMPLETE	
9	->		SETUP	U1
10	<-		CALL PROCEEDING	U3
11	<-		ALERTING	U4
12			Radio Bearer Setup Procedure	DTCH, See TS34.108
13	<-		CONNECT	U10
14	->		CONNECT ACKNOWLEDGE	
A15	<-		DISCONNECT	U12 (note 1)
B15	<-		DISCONNECT	U12 (note 2)
B16	->		RELEASE	U19
C15			DISCONNECT	MMI action, terminate call
C16	->			U11

NOTE 1: The Progress Indicator IE with progress description #8 "in band information or appropriate pattern now available" is included.

NOTE 2: The Progress Indication IE is not included.

Table 10.1.2/2: Void

Table 10.1.2/3: Establishment of an outgoing call, procedure 3

Step	Direction		Message	Comments
	UE	SS		
1	->		RRC CONNECTION REQUEST	Initiate outgoing call
2	<-		RRC CONNECTION SETUP	
3	->		RRC CONNECTION SETUP COMPLETE	
4	->		CM SERVICE REQUEST	U0.1
5	<-		SECURITY MODE COMMAND	
6	->		SECURITY MODE COMPLETE	
7	->		SETUP	U1
8	<-		AUTHENTICATION REQUEST	
9	->		AUTHENTICATION RESPONSE	
10	<-		CALL PROCEEDING	U3
11			Radio Bearer Setup Procedure	DTCH, See TS34.108
12	<-		ALERTING	U4
13	->		CONNECT	
14	<-		CONNECT ACKNOWLEDGE	U10
A15	<-		DISCONNECT	U12 (note 6)
B15	<-		DISCONNECT	U12 (note 7)
B16	->		RELEASE	U19
C15				MMI action, terminate call
C16	->		DISCONNECT	U11

NOTE 6: The Progress Indicator IE with progress description #8 "in band information or appropriate pattern now available" is included.

NOTE 7: The Progress indicator IE is not included.

Table 10.1.2/4: Establishment of an outgoing call, procedure 4

Step	Direction		Message	Comments
	UE	SS		
1	->		RRC CONNECTION REQUEST	Initiate outgoing call
2	<-		RRC CONNECTION SETUP	
3	->		RRC CONNECTION SETUP COMPLETE	
4	->		CM SERVICE REQUEST	U0.1
5	<-		IDENTITY REQUEST	
6	->		IDENTITY RESPONSE	
7	<-		SECURITY MODE COMMAND	
8	->		SECURITY MODE COMPLETE	
9	->		SETUP	U1
10	<-		Radio Bearer Setup Procedure	DTCH (note 8), See TS34.108
11	<-		CALL PROCEEDING	U3
12	<-		ALERTING	U4
13	<-		CONNECT	
14	->		CONNECT ACKNOWLEDGE	U10
A15	<-		DISCONNECT	U12 (note 9)
B15	<-		DISCONNECT	U12 (note 10)
B16	->		RELEASE	U19
C15				MMI action, terminate call
C16	->		DISCONNECT	U11

NOTE 8: Assigned channel is appropriate for the chosen bearer capability (see 10.1).

NOTE 9: The Progress Indicator IE with progress description #8 "in band information or appropriate pattern now available" is included.

NOTE 10: The Progress Indicator IE is not included.

### 10.1.2.1 Outgoing call / U0 null state

#### 10.1.2.1.1 Outgoing call / U0 null state / MM connection requested

##### 10.1.2.1.1.1 Definition

The call control entity of the User Equipment requests the MM-sublayer to establish a mobile originating MM-connection. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.1.1.2 Conformance requirement

- 1) Upon initiation of an outgoing basic call by user the UE shall initiate establishment of an MM connection, using as first MM message a CM SERVICE REQUEST message with CM service type "Mobile originating call establishment or packet mode connection establishment".

### References

TS 24.008 clause 5.2.1.1, TS24.008 clause 4.5.1.1, TS 25.331 clause 8.1.3.

##### 10.1.2.1.1.3 Test purpose

To verify that upon initiation of an outgoing basic call by user the UE initiates establishment of an MM connection, using as first MM message a CM SERVICE REQUEST message with CM service type "Mobile originating call establishment or packet mode connection establishment".

##### 10.1.2.1.1.4 Method of test

### Related ICS/IXIT statements

- supported MO circuit switched basic services.

### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. When the SS receives CM SERVICE REQUEST, the contents of it shall be checked.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	->		RRC CONNECTION REQUEST	initiate outgoing call
2	<-		RRC CONNECTION SETUP	
3	->		RRC CONNECTION SETUP COMPLETE	
4	->		CM SERVICE REQUEST	
5	<-		RRC CONNECTION RELEASE	verify the type of call which is asked for "basic" or "emergency by the UE
6	->		RRC CONNECTION RELEASE COMPLETE	
7	UE			
				the UE shall release the main signalling link

Specific message contents:

None.

#### 10.1.2.1.1.5 Test requirements

After step 3 the UE shall initiate establishment of an MM connection, using as first MM message a CM SERVICE REQUEST message with CM service type "Mobile originating call establishment or packet mode connection establishment".

#### 10.1.2.2 Outgoing call / U0.1 MM connection pending

##### 10.1.2.2.1 Outgoing call / U0.1 MM connection pending / CM service rejected

###### 10.1.2.2.1.1 DefinitionDefinition

A request for MM connection is rejected by the SS. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

###### 10.1.2.2.1.2 Conformance requirement

Upon receiving indication of an MM-connection establishment being rejected, CC entity should inform upper layer of this rejection.

#### References

TS 24.008, clause 4.5.1.1 , TS 24.007, clause 6.2.2.

###### 10.1.2.2.1.3 Test purpose

To verify that a CC entity of the UE in CC-state U0.1, "MM-connection pending", upon the UE receiving a CM SERVICE REJECT message, returns to CC state U0, "Null".

###### 10.1.2.2.1.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

## Initial conditions

## System Simulator:

1 cell, default parameters.

## User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U0.1 by using table 10.1.2/1.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. When the SS receives CM SERVICE REQUEST, the contents of it shall be checked. The SS rejects it by CM SERVICE REJECT. Then the SS will check the state of the UE by using STATUS ENQUIRY with all the relevant transaction identifiers.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		CM SERVICE REJECT	cause shall be 81# (invalid TI value) repeat steps 2-3 to cover all the transaction identifiers from 000 ...110
2	<-		STATUS ENQUIRY	
3	->		RELEASE COMPLETE	
4		SS		
5	<-		RRC CONNECTION RELEASE	the UE shall release the main signalling link
6	->		RRC CONNECTION RELEASE COMPLETE	
7		UE		

## Specific message contents:

None.

## 10.1.2.2.1.5 Test requirements

After step 2 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

## 10.1.2.2.2 Outgoing call / U0.1 MM connection pending / CM service accepted

## 10.1.2.2.2.1 Definition

A CM request is accepted for the MM-connection by the SS. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

## 10.1.2.2.2.2 Conformance requirement

A CC entity of the UE in CC-state U0.1, "MM-connection pending", upon the UE receiving a CM SERVICE ACCEPT message, shall send a SETUP message specifying the Called party BCD number that was entered into the UE and then enter CC state U1, "Call initiated".

## References

TS 24.008, clause 4.5.1.1, TS24.008, clause 5.2.1.1.

## 10.1.2.2.2.3 Test purpose

To verify that a CC entity of the UE in CC-state U0.1, "MM-connection pending", upon the UE receiving a CM SERVICE ACCEPT message, sends a SETUP message specifying the Called party BCD number that was entered into the UE and then enters CC state U1, "Call initiated".

## 10.1.2.2.2.4 Method of test

## Related ICS/IXIT statements

- supported MO circuit switched basic services.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U0.1 by using table 10.1.2/1.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. When the UE is requesting a MM-connection, the SS will indicate acceptance by sending a CM SERVICE ACCEPT message. The UE shall respond with SETUP. Then the SS will check the state of the call control entity by STATUS ENQUIRY with the relevant transaction identifiers.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		CM SERVICE ACCEPT	
2	->		SETUP	with called party BCD number.
3	<-		STATUS ENQUIRY	
4	->		STATUS	cause shall be 30# (response to enq.) and state U1 call initiated.

## Specific message contents:

None.

## 10.1.2.2.2.5 Test requirements

After step 1 a CC entity of the UE in CC-state U0.1, "MM-connection pending", shall send a SETUP message specifying the Called party BCD number that was entered into the UE and then enter CC state U1, "Call initiated".



### 10.1.2.2.3 Outgoing call / U0.1 MM connection pending / lower layer failure

#### 10.1.2.2.3.1 Definition

The call control entity of the UE being in the state, U0.1, a lower layer failure is accomplished at the UE and consequently, communication at layer 3 level with the peer entity is terminated. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

#### 10.1.2.2.3.2 Conformance requirement

- 1) Upon a lower layer failure the UE releases the MM connection in progress and returns to idle mode. In that state no call exists, and the CC entities relating to the seven mobile originating transaction identifiers are in state U0, "Null".

#### References

TS 24.008, clause 4.5.1.2, TS 24.008, clause 5.2.1.1., TS 24.008 clause 5.5.3.2. and TS 24.008 clause 8.3.

#### 10.1.2.2.3.3 Test purpose

To verify that after the UE with a CC entity in state U0.1, "MM-connection pending", has detected a lower layer failure and has returned to idle mode, the CC entities relating to the seven mobile originating transaction identifiers are in state U0, "Null".

#### 10.1.2.2.3.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U0.1 by using table 10.1.2/1.

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. When the UE has sent a CM SERVICE REQUEST message, the SS generates a lower layer failure at the UE. The SS waits long enough to enable the UE to return to idle state listening to paging, and then pages UE to create RRC connection. Finally, the SS will check the state of the UE by using STATUS ENQUIRY with the relevant transaction identifiers.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		SS generates lower layer failure. SS waits 20 s for the UE to return to listening to paging. See TS34.108
2		SS		
3			SS Initiated Establishment of RRC Connection	cause shall be 81# (invalid TI value). repeat steps 4-5 to cover all the transaction identifiers from 000 ...110. the main signalling link shall be released.
4	<-		STATUS ENQUIRY	
5	->		RELEASE COMPLETE	
6		SS		
7	<-		RRC CONNECTION RELEASE	
8	->		RRC CONNECTION RELEASE COMPLETE	

Specific message contents:

None.

#### 10.1.2.2.3.5 Test requirements

After step 4 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

### 10.1.2.3 Outgoing call / U1 call initiated

#### 10.1.2.3.1 Outgoing call / U1 call initiated / receiving CALL PROCEEDING

##### 10.1.2.3.1.1 Definition

The call control entity of the UE being in the state, U1, a CALL PROCEEDING message is sent by the SS. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.3.1.2 Conformance requirement

- 1) A CC entity of the UE in CC-state U1, "Call initiated", upon receipt of a CALL PROCEEDING message, shall enter CC state U3, "Mobile originating call proceeding".

#### References

TS 24.008, clauses 5.2.1.1, 5.2.1.2 and 5.2.1.3.

##### 10.1.2.3.1.3 Test purpose

To verify that a CC entity of the UE in CC-state U1, "Call initiated", upon receipt of a CALL PROCEEDING message, enters CC state U3, "Mobile originating call proceeding".

##### 10.1.2.3.1.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U1 by using table 10.1.2/1.

### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U1. The SS sends a CALL PROCEEDING message to the UE. The SS checks by using the status enquiry procedure that the CC entity has entered the state U3.

### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		<-	CALL PROCEEDING	tone generation not mandatory
2		<-	STATUS ENQUIRY	
3		->	STATUS	cause 30#, state U3

Specific message contents:

None.

#### 10.1.2.3.1.5 Test requirements

After step 1 a CC entity of the UE in CC-state U1, "Call initiated", shall enter CC state U3, "Mobile originating call proceeding".

#### 10.1.2.3.2 Outgoing call / U1 call initiated / rejecting with RELEASE COMPLETE

##### 10.1.2.3.2.1 Definition

The call control entity of the UE being in the state, U1, the call is rejected by a RELEASE COMPLETE message sent by the SS. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.3.2.2 Conformance requirement

- 1) A CC entity of the UE in CC-state U1, "Call initiated", upon receipt of a RELEASE COMPLETE message with valid cause value, shall enter CC state U0, "Null".
- 2) On returning to idle mode, the CC entities relating to the seven mobile originating transaction identifiers shall be in state U0, "Null".
- 3) On releasing the MM-connection, the UE shall wait for MM layer release initiated by the network.

### References

Conformance requirement 1: TS 24.008, clause 5.4.2, TS 24.008, clause 5.4.4.

Conformance requirement 2: TS 24.008, clause 5.5.3.2.

Conformance requirement 3: TS 24.008, clause 5.4.4.1.3, TS 24.008, clause 4.5.3, TS 25.331, clause 8.1.4.

## 10.1.2.3.2.3 Test purpose

- 1) To verify that a CC entity of the UE in CC-state U1, "Call initiated", upon receipt of a RELEASE COMPLETE message with valid cause value, enters CC state U0, "Null".
- 2) To verify that in returning to idle mode, the CC entities relating to the seven mobile originating transaction identifiers are in state U0, "Null".
- 3) To verify that in releasing the MM-connection, the UE shall wait for MM layer release initiated by SS.

## 10.1.2.3.2.4 Method of test

## Related ICS/IXIT statements

- supported MO circuit switched basic services.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U1 by using table 10.1.2/1.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U1. The SS sends a RELEASE COMPLETE message to the UE. The SS checks by using the status enquiry procedure that the CC entity has entered the state U0 with all the relevant transaction identifiers.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		RELEASE COMPLETE	See specific message content below.  cause 81# (invalid TI value) repeat steps 2-3 to cover all the transaction identifiers from 000...110 the main signalling link shall be released.
2	<-		STATUS ENQUIRY	
3	->		RELEASE COMPLETE	
4		SS		
5	<-		RRC CONNECTION RELEASE	
6	->		RRC CONNECTION RELEASE COMPLETE	

Specific message contents:

RELEASE COMPLETE

1) With a valid cause value among:

related to numbering,

#1 unallocated number

#3 no route to destination

#22 number changed

#28 invalid number format

related to bearer capabilities,

#8 operator determined barring

#57 bearer capability not authorized

#58 bearer capability not presently available

#63 service or option not available

#65 bearer service not implemented

#34 no circuit/channel available (call queuing).

#### 10.1.2.3.2.5 Test requirements

After step 2 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

#### 10.1.2.3.3 Outgoing call / U1 call initiated / T303 expiry

##### 10.1.2.3.3.1 Definition

The call control entity of the UE being in the state, U1, if no response is then received from the SS, timer T303 expires at the UE side. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.3.3.2 Conformance requirement

- 1) A CC entity of the UE in CC-state U1, "Call initiated", upon expiry of T303 shall send a DISCONNECT message to its peer entity and enter state U11, "Disconnect request".

#### References

TS 24.008, clause 5.2.1.1, TS 24.008, clause 5.4.

##### 10.1.2.3.3.3 Test purpose

- 1) To verify that a CC entity of the UE in CC-state U1, "Call initiated", upon expiry of T303 sends a DISCONNECT message to its peer entity and enters state U11, "Disconnect request".

## 10.1.2.3.3.4 Method of test

## Related ICS/IXIT statements

- supported MO circuit switched basic services.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U1 by using table 10.1.2/1.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U1. When T303 expires at the UE, the UE shall send DISCONNECT. The SS checks by using the status enquiry procedure that the CC entity has entered the state U11, disconnect request.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		SS waits for T303 expiry.
2		->	DISCONNECT	Shall be transmitted between 24 s and 36 s after the CM SERVICE REQUEST.
3		<-	STATUS ENQUIRY	
4		->	STATUS	cause 30#, status U11

## Specific message contents:

None.

## 10.1.2.3.3.5 Test requirements

Upon expiry of timer T303, a CC entity of the UE in CC-state U1, "Call initiated", shall send a DISCONNECT message and enter state U11, "Disconnect request".

## 10.1.2.3.4 Outgoing call / U1 call initiated / lower layer failure

## 10.1.2.3.4.1 Definition

The call control entity of the UE being in the state, U1, a lower layer failure is accomplished at the UE and consequently, communication at layer 3 level with the peer entity is terminated. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

## 10.1.2.3.4.2 Conformance requirement

Upon a lower layer failure MM informs the relevant CM entities that the MM connection has been interrupted. As call re-establishment is not allowed, the CC entity must perform a local release. The UE returns to idle mode. In that state no call exists, and the CC entities relating to the seven mobile originating transaction identifiers are in state U0, "Null".

## References

TS 24.008, clause 4.5.2.3, TS 24.008, clause 5.2.1.1, TS 24.008 clause 5.5.3.2.

## 10.1.2.3.4.3 Test purpose

To verify that after the UE with a CC entity in state U1 "Call initiated", has detected a lower layer failure and has returned to idle mode, the CC entities relating to the seven mobile originating transaction identifiers are in state U0, "Null".

## 10.1.2.3.4.4 Method of test

## Related ICS/IXIT statements

- supported MO circuit switched basic services.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U1 by using table 10.1.2/4.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The UE is brought to the state U1. The SS generates a lower layer failure at the UE. The SS waits long enough to enable the UE to return to idle state listening to paging, and then pages UE to create RRC connection. Finally, the SS will check the state of the UE by using STATUS ENQUIRY with the relevant transaction identifiers.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS	Mobile terminated establishment of rrc connection STATUS ENQUIRY RELEASE COMPLETE	SS generates lower layer failure.
2		SS		SS waits 20 s for the UE to return to listening to paging.
3				
4	<-			
5	->			cause 81# (invalid TI value).
6		SS		repeat steps 4-5 to cover all the transaction identifiers from 000...110.
7	<-		RRC CONNECTION RELEASE RRC CONNECTION RELEASE COMPLETE	
8	->			
9		UE		the UE shall release the main signalling link.

## Specific message contents:

None.

## 10.1.2.3.4.5 Test requirements

After step 4 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

## 10.1.2.3.5 Outgoing call / U1 call initiated / receiving ALERTING

## 10.1.2.3.5.1 Definition

The call control entity of the UE being in the state, U1, an ALERTING message is sent to the UE as a indication that a call is being alerted at a called end. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

## 10.1.2.3.5.2 Conformance requirement

- 1) A CC entity of the UE in CC-state U1, "Call initiated", upon receipt of an ALERTING message, shall enter CC state U4, "Call delivered".

## References

TS 24.008, clause 5.2.1.1.

## 10.1.2.3.5.3 Test purpose

To verify that a CC entity of the UE in CC-state U1, "Call initiated", upon receipt of an ALERTING message, enters CC state U4, "Call delivered".

## 10.1.2.3.5.4 Method of test

## Related ICS/IXIT statements

- supported MO circuit switched basic services.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U1 by using table 10.1.2/4.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U1. The SS sends an ALERTING message to the UE. The SS checks by using the status enquiry procedure that the CC entity has entered the state U4, call delivered.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		ALERTING	cause 30#, state U4
2	<-		STATUS ENQUIRY	
3	->		STATUS	



Specific message contents:

None.

#### 10.1.2.3.5.5 Test requirements

After step 1 a CC entity of the UE in CC-state U1, "Call initiated", shall enter CC state U4, "Call delivered".

#### 10.1.2.3.6 Outgoing call / U1 call initiated / entering state U10

##### 10.1.2.3.6.1 Definition

The call control entity of the UE being in the state, U1, a CONNECT message is received by the UE. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.3.6.2 Conformance requirement

- 1) A CC entity of the UE in CC-state U1, "Call initiated", upon receipt of a CONNECT message, shall send a CONNECT ACKNOWLEDGE message to its peer entity and enter CC state U10, "Active".

#### References

TS 24.008, clause 5.2.1.1, TS 24.008, clause 5.2.1.6.

##### 10.1.2.3.6.3 Test purpose

To verify that a CC entity of the UE in CC-state U1, "Call initiated", upon receipt of a CONNECT message, sends a CONNECT ACKNOWLEDGE message to its peer entity and enters CC state U10, "Active".

##### 10.1.2.3.6.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U1 by using table 10.1.2/4.

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U1. The SS sends a CONNECT message to the UE. The UE shall respond by sending a CONNECT ACKNOWLEDGE message. The SS checks by using the status enquiry procedure that the CC entity has entered the state U10, active.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		CONNECT	cause 30#, state U10
2	->		CONNECT ACKNOWLEDGE	
3	<-		STATUS ENQUIRY	
4	->		STATUS	

Specific message contents:

None.

#### 10.1.2.3.6.5 Test requirements

After step 1 a CC entity of the UE in CC-state U1, "Call initiated", shall send a CONNECT ACKNOWLEDGE message and shall enter CC state U10, "Active".

#### 10.1.2.3.7 Outgoing call / U1 call initiated / unknown message received

##### 10.1.2.3.7.1 Definition

The call control entity of the UE being in the state, U1, an unknown message is received by the UE. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.3.7.2 Conformance requirement

- 1) A CC entity of the UE in CC-state U1, "Call initiated", upon receipt of a message with message type not defined for the protocol discriminator from its peer entity shall return a STATUS message.

#### References

TS 24.008 clause 8.4.

##### 10.1.2.3.7.3 Test purpose

To verify that a CC entity of the UE in CC-state U1, "Call initiated", upon receipt of a message with message type not defined for the protocol discriminator unknown message from its peer entity returns a STATUS message.

##### 10.1.2.3.7.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U1 by using table 10.1.2/1.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U1. The SS sends a message with message type not defined for the protocol discriminator to the UE. The UE shall respond with a STATUS message, and finally the SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		<-	unknown message	message type not defined for PD
2		->	STATUS	cause 97#, state U1
3		<-	STATUS ENQUIRY	
4		->	STATUS	cause 30#, state U1

## Specific message contents:

None.

### 10.1.2.3.7.5 Test requirements

After step 1 and step 3 a CC entity of the UE in CC-state U1, "Call initiated", shall return a STATUS message.

## 10.1.2.4 Outgoing call / U3 UE originating call proceeding

### 10.1.2.4.1 Outgoing call / U3 UE originating call proceeding / ALERTING received

#### 10.1.2.4.1.1 Definition

The call control entity of the UE being in the state, U3, an ALERTING message is sent to the UE as a indication that a call is being alerted at a called end. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

#### 10.1.2.4.1.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a ALERTING message shall enter CC-state U4, "Call Delivered".

## References

TS 24.008 clause 5.2.1.5.

#### 10.1.2.4.1.3 Test purpose

To verify that a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a ALERTING message enters CC-state U4, "Call Delivered".

#### 10.1.2.4.1.4 Method of test

## Related ICS/IXIT statements

- supported MO circuit switched basic services.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U3 by using table 10.1.2/3.

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U3. The SS sends an ALERTING message to the UE. The SS checks by using the status enquiry procedure that the CC entity has entered the state U4, call delivered.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		ALERTING	
2	<-		STATUS ENQUIRY	
3	->		STATUS	cause 30#, state U4

Specific message contents:

None.

#### 10.1.2.4.1.5 Test requirements

After step 1 a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", shall enter CC-state U4, "Call Delivered".

#### 10.1.2.4.2 Outgoing call / U3 UE originating call proceeding / CONNECT received

##### 10.1.2.4.2.1 Definition

The call control entity of the UE being in the state, U3, a CONNECT message is received by the UE. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.4.2.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a CONNECT message shall return a "CONNECT ACKNOWLEDGE" message to its peer entity and enter the CC state U10, "Active".
- 2) The UE shall then stop any locally generated indication.

#### References

Conformance requirement 1: TS 24.008 clause 5.2.1.6.

Conformance requirement 2: TS 24.008 clause 5.2.1.6.

#### 10.1.2.4.2.3 Test purpose

- 1) To verify that a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a CONNECT message returns a "CONNECT ACKNOWLEDGE" message to its peer entity and enters the CC state U10, "Active".

- 2) To verify that the UE stops locally generated indication, if any.

#### 10.1.2.4.2.4 Method of test

##### Related ICS/IXIT statements

- supported MO circuit switched basic services.

##### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U3 by using table 10.1.2/3.

##### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U3. The SS sends a RADIO BEARER SETUP for traffic channel to the UE. The UE shall respond with a RADIO BEARER SETUP COMPLETE message. The SS sends a CONNECT message to the UE. The UE shall respond by sending a CONNECT ACKNOWLEDGE message. The SS checks by using the status enquiry procedure that the CC entity has entered the state U10, active.

##### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			Radio Bearer Setup Procedure	(DTCH), See TS34.108 the UE shall stop tone generation, if any cause 30#, state U10
2	<-		CONNECT	
3	->		CONNECT ACKNOWLEDGE	
4	<-		STATUS ENQUIRY	
5	->		STATUS	

##### Specific message contents:

None.

#### 10.1.2.4.2.5 Test requirements

After step 1 a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", shall return a "CONNECT ACKNOWLEDGE" message and enter the CC state U10, "Active".

The UE shall stop locally generated indication.

#### 10.1.2.4.3 Outgoing call / U3 UE originating call proceeding / PROGRESS received without in band information

##### 10.1.2.4.3.1 Definition

The call control entity of the UE being in the state, U3, a PROGRESS message is received by the UE. The PROGRESS message does not contain indication of in-band information availability. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

## 10.1.2.4.3.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a PROGRESS message with valid cause values shall stay in CC-state U3.
- 2) After receipt of the PROGRESS message timer T310 shall be stopped.

## References

Conformance requirement 1: TS 24.008 clause 5.2.1.4.

Conformance requirement 2: TS 24.008 clause 11.3.

## 10.1.2.4.3.3 Test purpose

- 1) To verify that a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a PROGRESS message with valid cause values stays in CC-state U3.
- 2) To verify that after receipt of the PROGRESS message timer T310 is stopped.

## 10.1.2.4.3.4 Method of test

## Related ICS/IXIT statements

- supported MO circuit switched basic services.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U3 by using table 10.1.2/3.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U3. The SS sends a PROGRESS message not containing indication of in-band information availability to the UE. The SS checks that the UE has stopped T310, i.e. at T310 time-out no DISCONNECT message is sent by the UE. Then the SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		PROGRESS	(note) cause 30#, state U3 SS waits at least 45 seconds and checks no DISCONNECT is sent by the UE
2	<-		STATUS ENQUIRY	
3	->		STATUS	
4		SS		
5	<-		STATUS ENQUIRY	cause 30#, state U3
6	->		STATUS	

NOTE: Tested with a valid cause value among:

#4 call has returned to PLMN/ISDN  
#32 call is end-to-end PLMN/ISDN or  
any value in the set #(21-127)

Specific message contents:

None.

#### 10.1.2.4.3.5 Test requirements

After step 1 a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", shall stay in CC-state U3.

After step 3 SS waits at least 45 seconds and checks no DISCONNECT is sent by the UE

#### 10.1.2.4.4 Outgoing call / U3 UE originating call proceeding / PROGRESS with in band information

##### 10.1.2.4.4.1 Definition

The call control entity of the UE being in the state, U3, a PROGRESS message indicating availability of in band information is received by the UE. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.4.4.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a PROGRESS message indicating in-band announcement shall through-connect the traffic channel for speech, if DTCH is in a speech mode. If DTCH is not in speech mode, the UE shall not through-connect the DTCH.
- 2) After receipt of the PROGRESS message, T310 shall be stopped.

#### References

TS 25.331 clause 8.2.1., TS 24.008 clause 5.1.3, TS 24.008 clause 5.2.1.4., TS 24.008 clause 5.2.1.9, TS 24.008 clause 5.5.1., TS 24.008 clause 11.3.

##### 10.1.2.4.4.3 Test purpose

- 1) To verify that a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a PROGRESS message indicating in-band announcement through-connects the traffic channel for speech, if DTCH is in speech mode. If DTCH is not in a speech mode, the UE does not through-connect the DTCH.
- 2) To verify that after receipt of the PROGRESS message, T310 is stopped.

##### 10.1.2.4.4.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U3 by using table 10.1.2/3.

### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U3. The SS sends a RADIO BEARER SETUP for traffic channel to the UE. The UE shall respond with a RADIO BEARER SETUP COMPLETE message. The SS sends a PROGRESS message containing indication of in-band information availability to the UE. The SS checks that if channel mode is speech, the DTCH shall be through connected. If channel mode is not speech, the DTCH shall not be through connected. Also the SS checks that the UE has stopped T310, i.e. at T310 time-out no DISCONNECT message is sent by the UE. Then the SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.

### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			Radio Bearer Setup Procedure	(DTCH), See TS34.108
2		<-	PROGRESS	(note) the UE shall stop all the CC timers , if channel mode is speech, the DTCH shall be through connected. If channel mode is not speech, the DTCH shall not be through connected.
3		<-	STATUS ENQUIRY	
4		->	STATUS	cause 30#, state U3
5		SS		SS waits at least 45 seconds and checks no DISCONNECT is sent by the UE.
6		<-	STATUS ENQUIRY	
7		->	STATUS	cause 30#, state U3
8		SS		If the channel mode is speech the SS will check that the user connection for speech is attached (both downlink and uplink).

### Specific message contents:

NOTE: Tested with a valid cause value among:

#1 call is not end to end PLMN/ISDN

#2 destination address is non PLMN/ISDN

#3 originating address is non PLMN/ISDN

#8 in band information or appropriate pattern now available or any value in the set #(6-20).

### 10.1.2.4.4.5 Test requirements

After step 2 a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", shall through-connect the traffic channel for speech, if DTCH is in a speech mode. If DTCH is not in speech mode, the UE shall not through-connect the DTCH.

After step 2 the SS waits at least 45 seconds and checks no DISCONNECT is sent by the UE

After step 5 the SS checks that the user connection for speech is attached (both downlink and uplink), if the channel mode is speech.



#### 10.1.2.4.5      Outgoing call / U3 UE originating call proceeding / DISCONNECT with in band tones

##### 10.1.2.4.5.1      Definition

The call control entity of the UE being in the state, U3, a DISCONNECT message indicating availability of in band information is received by the UE. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.4.5.2      Conformance requirement

- 1) A CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a DISCONNECT with progress indicator #8, shall through-connect the speech channel to make in-band announcements available, if traffic channel is in speech mode. If DTCH is not in speech mode, the UE shall send a RELEASE message.

#### References

TS 24.008 clause 5.2.1.4., TS 24.008 clause 5.4.4.

##### 10.1.2.4.5.3      Test purpose

To verify that a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a DISCONNECT with progress indicator #8 through-connects the speech channel to make in-band announcements available, if traffic channel is in speech mode. If DTCH is not in speech mode, the UE sends a RELEASE message.

##### 10.1.2.4.5.4      Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U3 by using table 10.1.2/3.

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U3. The SS sends a RADIO BEARER SETUP for traffic channel to the UE. The UE shall respond with a RADIO BEARER SETUP COMPLETE message. The SS sends a DISCONNECT message containing indication of in-band information availability to the UE. The SS checks that if channel mode is speech, the DTCH shall be through connected and the UE enters state U12, disconnect indication. If channel mode is not speech, the DTCH shall not be through connected and the UE shall enter state U19, release request.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1 2		<-	Radio Bearer Setup Procedure DISCONNECT	(DTCH), See TS34.108 (note)
B3  B4 B5		SS  <- ->	  STATUS ENQUIRY STATUS	DTCH in speech mode: the SS will check that the audio path for in band tones is attached.  cause 30#, state U12
C3 C4 C5		-> <- ->	RELEASE STATUS ENQUIRY STATUS	DTCH is not in speech mode:  cause 30#, state U19

Specific message contents:

NOTE: the cause value:

#8 in band information or appropriate pattern now available.

#### 10.1.2.4.5.5 Test requirements

After step 2 a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", shall through-connect the speech channel to make in-band announcements available, if traffic channel is in speech mode. If DTCH is not in speech mode, the UE shall send a RELEASE message.

#### 10.1.2.4.6 Outgoing call / U3 UE originating call proceeding / DISCONNECT without in band tones

##### 10.1.2.4.6.1 Definition

The call control entity of the UE being in the state, U3, a DISCONNECT message is received by the UE. The DISCONNECT message does not contain indication of in-band information availability. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.4.6.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a DISCONNECT without progress indicator shall return a RELEASE message and enter the CC-state U19, "Release Request"

#### References

TS 24.008 clause 5.4.4.

##### 10.1.2.4.6.3 Test purpose

To verify that a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a DISCONNECT without progress indicator returns a RELEASE message and enters the CC-state U19, "Release Request".

##### 10.1.2.4.6.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

## Initial conditions

### System Simulator:

1 cell, default parameters.

### User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U3 by using table 10.1.2/3.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U3. The SS sends a DISCONNECT message not containing indication of in-band information availability to the UE. The UE shall respond with a RELEASE message. The SS checks by using the status enquiry procedure that the CC entity of the UE has entered the state U19, release request.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		<-	DISCONNECT	
2		->	RELEASE	
3		<-	STATUS ENQUIRY	
4		->	STATUS	cause 30#, state U19

## Specific message contents:

None.

### 10.1.2.4.6.5 Test requirements

After step 1 a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", shall send a RELEASE message and enter the CC-state U19, "Release Request".

### 10.1.2.4.7 Outgoing call / U3 UE originating call proceeding / RELEASE received

#### 10.1.2.4.7.1 Definition

The call control entity of the UE being in the state, U3, a RELEASE message is received by the UE. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

#### 10.1.2.4.7.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a RELEASE will return a RELEASE COMPLETE and enter the CC-state U0, "Null".
- 2) The UE on returning to the idle mode shall release the MM-connection and the CC-entities relating to the seven mobile originating transaction identifiers shall be in CC-state U0, "Null".
- 3) On releasing the MM-connection, the UE shall wait for MM layer release initiated by the network.

## References

Conformance requirement 1: TS 24.008 clause 5.4.2., TS 24.008 clause 5.4.4.

Conformance requirement 2: TS 24.008 clause 4.5.3., TS 24.008 clause 5.5.3.2.

Conformance requirement 3: TS 24.008, clause 5.4.4.1.3, TS 24.008, clause 4.5.3, TS 25.331, clause 8.1.4.

#### 10.1.2.4.7.3 Test purpose

- 1) To verify that a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a RELEASE will return a RELEASE COMPLETE and enter the CC-state U0, "Null".
- 2) To verify that the UE on returning to the idle mode releases the MM-connection and that the CC-entities relating to the seven mobile originating transaction identifiers are in CC-state U0, "Null".
- 3) To verify that in releasing the MM-connection, the UE shall wait for MM layer release initiated by SS.

#### 10.1.2.4.7.4 Method of test

##### Related ICS/IXIT statements

- supported MO circuit switched basic services.

##### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U3 by using table 10.1.2/3.

##### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U3. The SS sends a RELEASE message to the UE. The UE shall respond with a RELEASE COMPLETE message. The SS checks by using the status enquiry procedure that the CC entity has entered the state U0 with all the relevant transaction identifiers.

##### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		RELEASE	with cause "Normal, unspecified"
2	->		RELEASE COMPLETE	
3	<-		STATUS ENQUIRY	
4	->		RELEASE COMPLETE	
5		SS		
6	<-		RRC CONNECTION RELEASE	cause 81# (invalid TI value) repeat steps 3-4 to cover all the transaction identifiers from 000...110 the main signalling link shall be released.
7	->		RRC CONNECTION RELEASE COMPLETE	

##### Specific message contents:

None.

#### 10.1.2.4.7.5 Test requirements

After step 1 a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", shall send a RELEASE COMPLETE message.

After step 3 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

#### 10.1.2.4.8 Outgoing call / U3 UE originating call proceeding / termination requested by the user

##### 10.1.2.4.8.1 Definition

The call control entity of the UE being in the state, U3, the user requests to terminate the call. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.4.8.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon request by the user to terminate will send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

#### References

TS 24.007 clause 6.2.2., TS 24.008 clause 5.4.3.

##### 10.1.2.4.8.3 Test purpose

To verify that a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon request by the user to terminate will send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

##### 10.1.2.4.8.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator: 1 cell, default parameters.

User Equipment: The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U3 by using table 10.1.2/3.

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U3. The user requests termination of the call. The UE shall send a DISCONNECT message. The SS checks by using the status enquiry procedure that the CC entity has entered the state U11, disconnect request.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				MMI action, terminate call  cause 30#, state U11
2	->		DISCONNECT	
3	<-		STATUS ENQUIRY	
4	->		STATUS	

Specific message contents:

None.

#### 10.1.2.4.8.5 Test requirements

After step 1 a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", shall send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

#### 10.1.2.4.9 Outgoing call / U3 UE originating call proceeding / traffic channel allocation

##### 10.1.2.4.9.1 Definition

The call control entity of the UE being in the state, U3, a radio bearer establishment procedure is performed. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.4.9.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", when a traffic channel is allocated by the network performing the radio bearer establishment procedure, shall stay in CC-state U3.

#### References

TS 25.331 clause 8.2.1., TS 24.008 clause 5.2.1.9.

##### 10.1.2.4.9.3 Test purpose

To verify that a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", when a traffic channel is allocated by the network performing the radio bearer establishment procedure, stays in CC-state U3.

##### 10.1.2.4.9.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U3 by using table 10.1.2/3.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U3. The SS sends a RADIO BEARER SETUP for traffic channel to the UE. The UE shall respond with a RADIO BEARER SETUP COMPLETE message. The SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			Radio Bearer Setup Procedure	(DTCH), See TS34.108
2	<-		STATUS ENQUIRY	
3		->	STATUS	cause 30#, state U3

## Specific message contents:

None.

### 10.1.2.4.9.5 Test requirements

After step 1 the CC state U3, "Mobile Originating Call Proceeding", shall remain unchanged.

### 10.1.2.4.10 Outgoing call / U3 UE originating call proceeding / timer T310 time-out

#### 10.1.2.4.10.1 Definition

The call control entity of the UE being in the state, U3, if no response is then received from the SS, timer T310 expires at the UE side. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

#### 10.1.2.4.10.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding" shall, upon expiry of timer T310, and not before, initiate call release by sending DISCONNECT and enter the CC-state U11, "Disconnect Request".

## References

TS 24.008 clause 5.2.1.3./Abnormal case, TS24.008 clause 5.4.3, TS 24.008 clause 11.3.

#### 10.1.2.4.10.3 Test purpose

To verify that a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding" will, upon expiry of timer T310, initiate call release by sending DISCONNECT and enter the CC-state U11, "Disconnect Request".

#### 10.1.2.4.10.4 Method of test

## Related ICS/IXIT statements

- supported MO circuit switched basic services.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U3 by using table 10.1.2/3.

### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U3. The T310 expires at the UE and the UE shall send DISCONNECT. The SS checks timer T310 accuracy and that the CC entity has entered the state U11, disconnect request.

### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		the SS waits for T310 time-out check the timer T310 accuracy cause 30#, state U11
2	->		DISCONNECT	
3	<-		STATUS ENQUIRY	
4	->		STATUS	

Specific message contents:

None.

### 10.1.2.4.10.5 Test requirements

Upon expiry of timer T310, a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding" shall initiate call release by sending a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

### 10.1.2.4.11 Outgoing call / U3 UE originating call proceeding / lower layer failure

#### 10.1.2.4.11.1 Definition

The call control entity of the UE being in the state, U3, a lower layer failure is accomplished at the UE and consequently, communication at layer 3 level with the peer entity is terminated. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

#### 10.1.2.4.11.2 Conformance requirement

- 1) If a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding" has detected a lower layer failure and has returned to idle mode, the CC entities relating to the seven mobile originating transaction identifiers shall be in state U0, "Null".

### References

TS 24.008 clause 4.5.2.3., TS 24.008 clause 4.5.3., TS 24.008 clause 5.5.3.2., TS 25.331 clause 8.1.4.

### 10.1.2.4.11.3 Test purpose

To verify that a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding" having detected a lower layer failure and having returned to idle mode, the CC entities relating to the seven mobile originating transaction identifiers are in state U0, "Null".



## 10.1.2.4.11.4 Method of test

## Related ICS/IXIT statements

- supported MO circuit switched basic services.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U3 by using table 10.1.2/4.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The UE is brought to the state U3. The SS generates a lower layer failure at the UE. The SS waits long enough to enable the UE to return to idle state listening to paging, and then pages UE to create RRC connection. Finally, the SS will check the state of the UE by using STATUS ENQUIRY with the relevant transaction identifiers.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		SS generates lower layer failure SS waits 20 s for the UE to return to listening to paging See TS34.108
2		SS		
3			SS Initiated Establishment of RRC Connection	
4	<-		STATUS ENQUIRY	cause 81# (invalid TI value) repeat steps 4-5 to cover all the transaction identifiers from 000...110 the main signalling link shall be released.
5	->		RELEASE COMPLETE	
6		SS		
7	<-		RRC CONNECTION RELEASE	
8	->		RRC CONNECTION RELEASE COMPLETE	

## Specific message contents:

None.

## 10.1.2.4.11.5 Test requirements

After step 4 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

## 10.1.2.4.12 Outgoing call / U3 UE originating call proceeding / unknown message received

## 10.1.2.4.12.1 Definition

The call control entity of the UE being in the state, U3, an unknown message is received by the UE. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

## 10.1.2.4.12.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding" having received an unknown message from its peer entity shall return a STATUS message.

## References

TS 24.008 clause 8.5.

## 10.1.2.4.12.3 Test purpose

To verify that a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding" having received an unknown message from its peer entity returns a STATUS message.

## 10.1.2.4.12.4 Method of test

## Related ICS/IXIT statements

- supported MO circuit switched basic services.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U3 by using table 10.1.2/1.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U3. The SS sends a message with message type not defined for the protocol discriminator to the UE. The UE shall respond with a STATUS message, and finally the SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		<-	unknown message	message type not defined for PD
2		->	STATUS	cause 97#, state U3
3		<-	STATUS ENQUIRY	
4		->	STATUS	cause 30#, state U3

## Specific message contents:

None.

## 10.1.2.4.12.5 Test requirements

After step 1 a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", shall return a STATUS message.

### 10.1.2.4.13      Outgoing call / U3 UE originating call proceeding / Internal alerting indication

#### 10.1.2.4.13.1      Definition

The call control entity of the UE being in the state, U3, an ALERTING message is sent to the UE when the user connection is not attached to the radio path. This test is applicable for any equipment supporting mobile originated circuit switched basic service for telephony.

#### 10.1.2.4.13.2      Conformance requirement

- 1) When the call control entity of the UE in the "mobile originating call proceeding" state receives an ALERTING message then it shall enter "call delivered" state and, for speech calls, if the user connection is not attached to the radio path, the UE shall internally generate an alerting indication.

#### References

TS 24.008 clause 5.2.1.5.

#### 10.1.2.4.13.3      Test purpose

When the call control entity of the UE in the "mobile originating call proceeding" state receives an ALERTING message then it enters "call delivered" state and, for speech calls, if the user connection is not attached to the radio path, the UE generates internally an alerting indication.

#### 10.1.2.4.13.4      Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.
- way to give internally generated alerting indication for outgoing calls

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U3 by using table 10.1.2/1.

#### Test procedure

The SS sends an ALERTING message to the UE. The SS checks by using the status enquiry procedure that the CC entity has entered the state U4, call delivered. Also it is checked that the UE generates internally alerting indication to the user in the way described in the ICS/IXIT statements.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		ALERTING	the UE shall generate an alerting indication to the user in the way described in the ICS/IXIT statements cause 30#, state U4
2	<-		STATUS ENQUIRY	
3	->		STATUS	

Specific message contents:

None.

#### 10.1.2.4.13.5 Test requirements

After step 1 CC entity of the UE in CC state U3, the "Mobile Originating Call Proceeding" shall enter "Call Delivered" state and, for speech calls, if the user connection is not attached to the radio path, the UE shall internally generate an alerting indication.

#### 10.1.2.5 Outgoing call / U4 call delivered

##### 10.1.2.5.1 Outgoing call / U4 call delivered / CONNECT received

###### 10.1.2.5.1.1 Definition

The call control entity of the UE being in the state, U4, a CONNECT message is received by the UE. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

###### 10.1.2.5.1.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U4, "Call Delivered", upon receipt of the CONNECT message shall return a CONNECT ACKNOWLEDGE to its peer entity and enter the CC-state U10, "Active".

#### References

TS 24.008 clause 5.2.1.6.

###### 10.1.2.5.1.3 Test purpose

To verify that a CC-entity of the UE in CC-state U4, "Call Delivered", upon receipt of the CONNECT message returns a CONNECT ACKNOWLEDGE to its peer entity and enters the CC-state U10, "Active".

###### 10.1.2.5.1.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U4 by using table 10.1.2/3.

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U4. The SS sends a CONNECT message to the UE. The UE shall respond by sending a CONNECT ACKNOWLEDGE message. The SS checks by using the status enquiry procedure that the CC entity has entered the state U10, active.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-	>-	CONNECT	UE stops alerting, if applicable cause 30#, state U10
2			CONNECT ACKNOWLEDGE	
3			STATUS ENQUIRY	
4			STATUS	

Specific message contents:

None.

#### 10.1.2.5.1.5 Test requirements

After step 1 a CC entity of the UE in CC state U4, "Call Delivered", shall return a CONNECT ACKNOWLEDGE message and enter the CC state U10, "Active".

#### 10.1.2.5.2 Outgoing call / U4 call delivered / termination requested by the user

##### 10.1.2.5.2.1 Definition

The call control entity of the UE being in the state, U4, the user requests to terminate the call. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.5.2.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U4, "Call Delivered", upon request by the user to terminate shall send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

#### References

TS 24.007 clause 6.2.2., TS 24.008 clause 5.4.3.

##### 10.1.2.5.2.3 Test purpose

To verify that a CC-entity of the UE in CC-state U4, "Call Delivered", upon request by the user to terminate will send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

##### 10.1.2.5.2.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U4 by using table 10.1.2/3.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U4. The user requests termination of the call. The UE shall send a DISCONNECT message. The SS checks by using the status enquiry procedure that the CC entity has entered the state U11, disconnect request.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				MMI action, terminate call  cause 30#, state U11
2		->	DISCONNECT	
3		<-	STATUS ENQUIRY	
4		->	STATUS	

## Specific message contents:

None.

### 10.1.2.5.2.5 Test requirements

After step 1 a CC entity of the UE in CC state U4, "Call Delivered", shall send a DISCONNECT message and enter the CC state U11, "Disconnect Request".

### 10.1.2.5.3 Outgoing call / U4 call delivered / DISCONNECT with in band tones

#### 10.1.2.5.3.1 Definition

The call control entity of the UE being in the state, U4, a DISCONNECT message indicating availability of in band information is received by the UE. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

#### 10.1.2.5.3.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U4, "Call Delivered" shall, upon receipt of a DISCONNECT with a progress indicator indicating in-band information, shall through-connect the speech channel to make in-band announcements available, if traffic channel is in speech mode. If DTCH is not in speech mode, the UE shall send a RELEASE message.

## References

TS 25.331 clause 8.2.1., TS 24.008 clause 5.4.4.1.1., TS 24.008 clause 5.5.1., TS 24.008 clause 5.2.1.9.

#### 10.1.2.5.3.3 Test purpose

To verify that a CC-entity of the UE in CC-state U4, "Call Delivered", upon receipt of a DISCONNECT with a progress indicator indicating in-band information, through-connects the speech channel to make in-band announcements available, if traffic channel is in speech mode. If DTCH is not in speech mode, the UE shall send a RELEASE message.

#### 10.1.2.5.3.4 Method of test

## Related ICS/IXIT statements

- supported MO circuit switched basic services.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U4 by using table 10.1.2/3.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U4. The SS sends a DISCONNECT message containing indication of in-band information availability to the UE. The SS checks that if channel mode is MO telephony, the DTCH shall be through connected and the UE enters state U12, disconnect indication. If channel mode is not speech, the DTCH shall not be through connected and the UE shall enter state U19, release request.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		DISCONNECT	(note)
A2	SS			DTCH in speech mode: the SS will check that the audio path for in band tones is attached.
A3	<-		STATUS ENQUIRY	
A4	->		STATUS	cause 30#, state U12
B2	->		RELEASE	DTCH is not in speech mode:
B3	<-		STATUS ENQUIRY	
B4	->		STATUS	cause 30#, state U19

## Specific message contents:

NOTE: the Progress Indicator, Progress Description:

#8 in band information or appropriate pattern now available.

## 10.1.2.5.3.5 Test requirements

After step 1 a CC-entity of the UE in CC-state U4, "Call Delivered", shall through-connect the speech channel to make in-band announcements available, if traffic channel is in speech mode. If DTCH is not in speech mode, the UE shall send a RELEASE message.

## 10.1.2.5.4 Outgoing call / U4 call delivered / DISCONNECT without in band tones

## 10.1.2.5.4.1 Definition

The call control entity of the UE being in the state, U4, a DISCONNECT message is received by the UE. The DISCONNECT message does not contain indication of in-band information availability. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

## 10.1.2.5.4.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U4, "Call Delivered", upon receipt of a DISCONNECT without progress indicator, shall return a RELEASE message and enter the CC-state U19, "Release Request".

## References

TS 24.008 clause 5.4.4.

## 10.1.2.5.4.3 Test purpose

To verify that a CC-entity of the UE in CC-state U4, "Call Delivered", upon receipt of a DISCONNECT without progress indicator, returns a RELEASE message and enters the CC-state U19, "Release Request".

## 10.1.2.5.4.4 Method of test

## Related ICS/IXIT statements

- supported MO circuit switched basic services.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U4 by using table 10.1.2/3.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U4. The SS sends a DISCONNECT message not containing indication of in-band information availability to the UE. The UE shall respond with a RELEASE message. The SS checks by using the status enquiry procedure that the CC entity of the UE has entered the state U19, release request.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		DISCONNECT	without progress indicator
2	->		RELEASE	
3	<-		STATUS ENQUIRY	cause 30#, state U19
4	->		STATUS	

## Specific message contents:

None.

## 10.1.2.5.4.5 Test requirements

After step 1 a CC-entity of the UE in CC-state U4, "Call Delivered", shall return a RELEASE message and enter the CC-state U19, "Release Request".



#### 10.1.2.5.5 Outgoing call / U4 call delivered / RELEASE received

##### 10.1.2.5.5.1 Definition

The call control entity of the UE being in the state, U4, a RELEASE message is received by the UE. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.5.5.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U4, "Call Delivered", upon receipt of the RELEASE message shall respond with the RELEASE COMPLETE message and enter the CC-state U0, "Null".
- 2) The UE on returning to idle mode shall release the MM-connection and the CC-entities relating to the seven mobile originating transaction identifiers shall be in CC-state U0, "Null".

#### References

Conformance requirement 1: TS 24.008 clause 5.4.2., TS 24.008 clause 5.4.4.

Conformance requirement 2: TS 24.008 clause 4.5.3., TS 24.008 clause 5.5.3.2.

##### 10.1.2.5.5.3 Test purpose

- 1) To verify that a CC-entity of the UE in CC-state U4, "Call Delivered", upon receipt of the RELEASE message will respond with the RELEASE COMPLETE message and enter the CC-state U0, "Null".
- 2) To verify that the UE on returning the idle mode releases the MM-connection and that the CC-entities relating to the seven mobile originating transaction identifiers are in CC-state U0, "Null".

##### 10.1.2.5.5.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U4 by using table 10.1.2/3.

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U4. The SS sends a RELEASE message to the UE. The UE shall respond with a RELEASE COMPLETE message. The SS checks by using the status enquiry procedure that the CC entity has entered the state U0 with all the relevant transaction identifiers.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		RELEASE	with cause "Normal, unspecified"
2	->		RELEASE COMPLETE	
3	<-		STATUS ENQUIRY	
4	->		RELEASE COMPLETE	
5		SS		
6	<-		RRC CONNECTION RELEASE	cause 81# (invalid TI value) repeat steps 3-4 to cover all the transaction identifiers from 000...110 the main signalling link shall be released.
7	->		RRC CONNECTION RELEASE COMPLETE	

Specific message contents:

None.

#### 10.1.2.5.5.5 Test requirements

After step 1 a CC-entity of the UE in CC-state U4, "Call Delivered", shall respond with the RELEASE COMPLETE message.

After step 3 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

#### 10.1.2.5.6 Outgoing call / U4 call delivered / lower layer failure

##### 10.1.2.5.6.1 Definition

The call control entity of the UE being in the state, U4, a lower layer failure is accomplished at the UE and consequently, communication at layer 3 level with the peer entity is terminated. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.5.6.2 Conformance requirement

- 1) When CC-entity of the UE in CC-state U4, "Call Delivered" has detected a lower layer failure and has returned to idle mode, the CC-entities relating to the seven mobile originating transaction identifiers shall be in CC-state U0, "Null".

#### References

TS 24.008 clause 4.5.2.3., TS 24.008 clause 4.5.3., TS 24.008 clause 5.5.3.2., TS 25.331 clause 8.1.4.

##### 10.1.2.5.6.3 Test purpose

To verify that a CC-entity of the UE in CC-state U4, "Call Delivered" having detected a lower layer failure and has returned to idle mode, the CC-entities relating to the seven mobile originating transaction identifiers are in CC-state U0, "Null".

##### 10.1.2.5.6.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U4 by using table 10.1.2/3.

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The UE is brought to the state U4. The SS generates a lower layer failure at the UE. The SS waits long enough to enable the UE to return to idle state listening to paging, and then pages UE to create RRC connection. Finally, the SS will check the state of the UE by using STATUS ENQUIRY with the relevant transaction identifiers.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		SS generates lower layer failure SS waits 20 s for the UE to return to listening to paging See TS34.108
2		SS		
3			SS Initiated Establishment of RRC Connection	cause 81# (invalid TI value) repeat steps 4-5 to cover all the transaction identifiers from 000...110 the main signalling link shall be released.
4	<-		STATUS ENQUIRY	
5	->		RELEASE COMPLETE	
6		SS		
7	<-		RRC CONNECTION RELEASE	
8	->		RRC CONNECTION RELEASE COMPLETE	

Specific message contents:

None.

#### 10.1.2.5.6.5 Test requirements

After step 4 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

#### 10.1.2.5.7 Outgoing call / U4 call delivered / traffic channel allocation

##### 10.1.2.5.7.1 Definition

The call control entity of the UE being in the state, U4, a radio bearer establishment procedure is performed. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.5.7.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U4, "Call Delivered", when a traffic channel is allocated by the network performing the radio bearer establishment procedure, shall stay in CC-state U4.

#### References

TS 25.331 clause 8.2.1., TS 24.008 clause 5.2.1.9.

### 10.1.2.5.7.3 Test purpose

To verify that a CC-entity of the UE in CC-state U4, "Call Delivered", when a traffic channel is allocated by the network performing the radio bearer establishment procedure, stays in CC-state U4.

### 10.1.2.5.7.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U4 by using table 10.1.2/1.

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U4. The SS sends a RADIO BEARER SETUP for traffic channel to the UE. The UE shall respond with a RADIO BEARER SETUP COMPLETE message. The SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			Radio Bearer Setup Procedure	DTCH, See TS34.108
2		<-	STATUS ENQUIRY	
3		->	STATUS	cause 30#, state U4

#### Specific message contents:

None.

### 10.1.2.5.7.5 Test requirements

After step 1 the CC state U4, "Call delivered", shall remain unchanged.

### 10.1.2.5.8 Outgoing call / U4 call delivered / unknown message received

#### 10.1.2.5.8.1 Definition

The call control entity of the UE being in the state, U4, an unknown message is received by the UE. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

#### 10.1.2.5.8.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U4, "Call Delivered", having received an unknown message from its peer entity shall return a STATUS message.

## References

TS 24.008 clause 8.4.

### 10.1.2.5.8.3 Test purpose

To verify that a CC-entity of the UE in CC-state U4, "Call Delivered", having received an unknown message from its peer entity returns a STATUS message.

### 10.1.2.5.8.4 Method of test

## Related ICS/IXIT statements

- supported MO circuit switched basic services.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U4 by using table 10.1.2/4.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U4. The SS sends a message with message type not defined for the protocol discriminator to the UE. The UE shall respond with a STATUS message, and finally the SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		unknown message	message type not defined for PD cause 97#, state U4
2	->		STATUS	
3	<-		STATUS ENQUIRY	cause 30#, state U4
4	->		STATUS	

## Specific message contents:

None.

### 10.1.2.5.8.5 Test requirements

After step 1 a CC entity of the UE in CC state U3, "Mobile Originating Call Proceeding", shall return a STATUS message.

## 10.1.2.6 U10 call active

### 10.1.2.6.1 U10 call active / termination requested by the user

#### 10.1.2.6.1.1 Definition

The call control entity of the UE being in the state, U10, the user requests to terminate the call. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

#### 10.1.2.6.1.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U10, "Call Active", upon request by the user to terminate shall send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

#### References

TS 24.007 clause 6.2.2., TS 24.008 clause 5.4.3.

#### 10.1.2.6.1.3 Test purpose

To verify that the a CC-entity of the UE in CC-state U10, "Call Active", upon request by the user to terminate will send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

#### 10.1.2.6.1.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U10 by using table 10.1.2/1.

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U10. The user requests termination of the call. The UE shall send a DISCONNECT message. The SS checks by using the status enquiry procedure that the CC entity has entered the state U11, disconnect request.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				MMI action, terminate call U11  cause 30#, state U11
2	->		DISCONNECT	
3	<-		STATUS ENQUIRY	
4	->		STATUS	

Specific message contents:

None.

#### 10.1.2.6.1.5 Test requirements

After step 1 a CC entity of the UE in CC state U10, "Call Active", shall send a DISCONNECT message and enter the CC state U11, "Disconnect Request".

#### 10.1.2.6.2 U10 call active / RELEASE received

##### 10.1.2.6.2.1 Definition

The call control entity of the UE being in the state, U10, a RELEASE message is received by the UE. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.6.2.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U10, "Call Active", upon receipt of the RELEASE shall respond with the RELEASE COMPLETE message and enter the CC-state U0, "Null"
- 2) When the UE returns to the idle mode it shall release the MM-connection and the CC-entities relating to the seven mobile originating transaction identifiers shall be in CC-state U0, "Null"

#### References

Conformance requirement 1: TS 24.008 clause 5.4.2., TS 24.008 clause 5.4.4.

Conformance requirement 2: TS 24.008 clause 4.5.3., TS 24.008 clause 5.5.3.2.

##### 10.1.2.6.2.3 Test purpose

- 1) To verify that the a CC-entity of the UE in CC-state U10, "Call Active", upon receive of the RELEASE will respond with the RELEASE COMPLETE message and enter the CC-state U0, "Null"
- 2) To verify that the UE on returning to the idle mode releases the MM-connection and that the CC-entities relating to the seven mobile originating transaction identifiers are in CC-state U0, "Null"

##### 10.1.2.6.2.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U10 by using table 10.1.2/1.

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U10. The SS sends a RELEASE message to the UE. The

UE shall respond with a RELEASE COMPLETE message. The SS checks by using the status enquiry procedure that the CC entity has entered the state U0 with all the relevant transaction identifiers.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		<-	RELEASE	with cause "Normal, unspecified" the UE starts T3240
2		->	RELEASE COMPLETE	
3		<-	STATUS ENQUIRY	cause 81# (invalid TI value) repeat steps 3-4 to cover all the transaction identifiers from 000...110 the main signalling link shall be released.
4		->	RELEASE COMPLETE	
5		SS		
6		<-	RRC CONNECTION RELEASE	
7		->	RRC CONNECTION RELEASE COMPLETE	

#### Specific message contents:

None.

#### 10.1.2.6.2.5 Test requirements

After step 1 a CC entity of the UE in CC state U10, "Call Active", shall return a RELEASE COMPLETE message.

After step 3 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

#### 10.1.2.6.3 U10 call active / DISCONNECT with in band tones

##### 10.1.2.6.3.1 Definition

The call control entity of the UE being in the state, U10, a DISCONNECT message indicating availability of in band information is received by the UE. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.6.3.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U10, "Call Active", upon receipt of a DISCONNECT message with a Progress Indicator indicating in-band information, shall through-connect the speech channel to make in-band announcements available, if traffic channel is in speech mode. If DTCH is not in speech mode, the UE shall send a RELEASE message.

#### References

TS 24.008 clause 5.4.4.1.1., TS 24.008 clause 5.5.1.

##### 10.1.2.6.3.3 Test purpose

To verify that a CC-entity of the UE in CC-state U10, "Call Active", upon receipt of a DISCONNECT message with a Progress Indicator indicating in-band information, through-connects the speech channel to make in-band announcements available, if traffic channel is in speech mode. If DTCH is not in speech mode, the UE sends a RELEASE message.

##### 10.1.2.6.3.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.



## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U10 by using table 10.1.2/1.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U10. The SS sends a DISCONNECT message containing indication of in-band information availability to the UE. The SS checks that if channel mode is speech, the DTCH shall be through connected and the UE enters state U12, disconnect indication. If channel mode is not speech, the DTCH shall not be through connected and the UE enters state U19, release request.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		DISCONNECT	(note)
A2	SS			DTCH in speech mode: the SS will check that the audio path for in band tones is attached.
A3	<-		STATUS ENQUIRY	cause 30#, state U12
A4	->		STATUS	
B2	->		RELEASE	DTCH is not in speech mode: cause 30#, state U19
B3	<-		STATUS ENQUIRY	
B4	->		STATUS	

## Specific message contents:

NOTE: the Progress Indicator, Progress Description:

#8 in band information or appropriate pattern now available.

## 10.1.2.6.3.5 Test requirements

After step 1 a CC-entity of the UE in CC-state U10, "Call Active", shall through-connect the speech channel to make in-band announcements available, if traffic channel is in speech mode. If DTCH is not in speech mode, the UE shall send a RELEASE message.

## 10.1.2.6.4 U10 call active / DISCONNECT without in band tones

## 10.1.2.6.4.1 Definition

The call control entity of the UE being in the state, U10, a DISCONNECT message is received by the UE. The DISCONNECT message does not contain indication of in-band information availability. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

## 10.1.2.6.4.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U10, "Call Active", upon receipt of a DISCONNECT message without progress indicator, shall return a RELEASE message and enter the CC-state U19, "Release Request".

## References

TS 24.008 clause 5.4.4.

## 10.1.2.6.4.3 Test purpose

To verify that the a CC-entity of the UE in CC-state U10, "Call Active", upon receipt of a DISCONNECT message without progress indicator, returns a RELEASE message and enters the CC-state U19, "Release Request".

## 10.1.2.6.4.4 Method of test

## Related ICS/IXIT statements

- supported MO circuit switched basic services.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U10 by using table 10.1.2/1.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U10. The SS sends a DISCONNECT message not containing indication of in-band information availability to the UE. The UE shall respond with a RELEASE message. The SS checks by using the status enquiry procedure that the CC entity of the UE has entered the state U19, release request.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		DISCONNECT	without progress indicator
2	->		RELEASE	
3	<-		STATUS ENQUIRY	cause 30#, state U19
4	->		STATUS	

## Specific message contents:

None.

## 10.1.2.6.4.5 Test requirements

A CC-entity of the UE in CC-state U10, "Call Active", shall return a RELEASE message and enter the CC-state U19, "Release Request".

#### 10.1.2.6.5 U10 call active / RELEASE COMPLETE received

##### 10.1.2.6.5.1 Definition

The call control entity of the UE being in the state, U10, the call is cleared by a RELEASE COMPLETE message sent by the SS. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.6.5.2 Conformance requirement

- 1) A CC entity of the UE in CC-state U10, "active", upon receipt of a RELEASE COMPLETE message with valid cause value, shall enter CC state U0, "Null".
- 2) On returning to idle mode, the CC entities relating to the seven mobile originating transaction identifiers shall be in state U0, "Null".

#### References

Conformance requirement 1: TS 24.008, clause 5.4.2, TS 24.008, clause 5.4.4.

Conformance requirement 2: TS 24.008, clause 5.4.4.1.3.

##### 10.1.2.6.5.3 Test purpose

- 1) To verify that a CC entity of the UE in CC-state U10, "Call active" upon receipt of a RELEASE COMPLETE message with valid cause value, enters CC state U0, "Null".
- 2) To verify that in returning to idle mode, the CC entities relating to the seven mobile originating transaction identifiers are in state U0, "Null".

##### 10.1.2.6.5.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U10 by using table 10.1.2/1.

#### Test procedure

The SS sends a RELEASE COMPLETE message to the UE. The SS checks by using the status enquiry procedure that the CC entity has entered the state U0 with all the relevant transaction identifiers.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		RELEASE COMPLETE	note 1
2	<-		STATUS ENQUIRY	note 2
3	->		RELEASE COMPLETE	cause 81# (invalid TI value), repeat steps 2-3 to cover all the transaction identifiers from 000...110 the main signalling link shall be released.
4	SS			
5	<-		RRC CONNECTION RELEASE	
6	->		RRC CONNECTION RELEASE COMPLETE	

Specific message contents:

NOTE 1: With the cause value chosen arbitrarily.

NOTE 2: TI flag has the value indicating the UE as a originator of the call.

#### 10.1.2.6.5.5 Test requirements

After step 2 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

#### 10.1.2.6.6 U10 call active / SETUP received

##### 10.1.2.6.6.1 Definition

If the UE does not react correctly when receiving a SETUP message on a new Transaction Identifier during an active call, the active call may be lost.

This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.6.6.2 Conformance requirement

- 1) A UE that has a call established when receiving a SETUP message shall respond either with a CALL CONFIRMED message or a RELEASE COMPLETE message, both with cause #17 "user busy".
- 2) The call control state of the existing transaction shall not be affected by the incoming SETUP message.

Reference(s):

Conformance requirement 1: TS 24.008, clause 5.2.2.3.1.

Conformance requirement 2: TS 24.008, clause 5.1.1.

##### 10.1.2.6.6.3 Test purpose

- 1) To verify that a User Equipment that has a call established and receives a SETUP message answers either with a CALL CONFIRMED message with cause "user busy" if it supports call waiting, or with a RELEASE COMPLETE message with cause "user busy" otherwise.
- 2) To verify that after having sent this message, the UE is still in state U10 for the established call.

##### 10.1.2.6.6.4 Method of test

Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is idle updated with valid TMSI and CKSN.

The UE is brought into the state U10 by using table 10.1.2/1.

Related ICS/IXIT statement(s)

- supported MO circuit switched basic services.
- support of call waiting Y/N.

#### Test Procedure

The UE has a mobile originated call in the U10 state. When UE sends a SETUP message and SS receives it in the first call establishment, SS sends a CALL PROCEEDINF message without Network Call Control Capability IE.

The SS sends a SETUP message to the UE (with signal IE indicating "call waiting tone on" and without Network Call Control Capability IE).

If the UE does not support call waiting it shall answer by a RELEASE COMPLETE message.

If the UE supports call waiting it shall answer by a CALL CONFIRMED message followed by an ALERTING. The second transaction is then released by the SS with a RELEASE COMPLETE message.

In both cases the SS checks by using the status enquiry procedure that the CC entity of the UE is still in state U10, active call for the original call.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		<-	SETUP	this message establishes a second transaction The TI value shall be the same as the one that is in use for the MO call. The TI flag shall have the value specified for an MT call.
A2		->	RELEASE COMPLETE	if the UE does not support call waiting with cause user busy" with the TI of the second transaction
B2		->	CALL CONFIRMED	if the UE supports call waiting with cause user busy" with the TI of the second transaction
B3		->	ALERTING	with the TI of the second transaction
B4		<-	RELEASE COMPLETE	with the TI of the second transaction
5		<-	STATUS ENQUIRY	with the TI of the original transaction
6		->	STATUS	cause 30#, state U10 with the TI of the original transaction

NOTE: The Transaction Identifier of the second transaction shall be different from the one of the already established transaction.

#### Specific message contents

SETUP message contains a Signal IE with value "call waiting tone on" (H'07).

#### 10.1.2.6.6.5 Test requirements

After step 1 a UE that has a call established shall answer either with a CALL CONFIRMED message with cause "user busy" if it supports call waiting, or with a RELEASE COMPLETE message with cause "user busy" otherwise.

After step A2 or B2 the UE is still in state U10 for the established call.

### 10.1.2.7 U11 disconnect request

#### 10.1.2.7.1 U11 disconnect request / clear collision

##### 10.1.2.7.1.1 Definition

The call control entity of the UE being in the state, U11, a DISCONNECT message is received by the UE. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.7.1.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U11, "Disconnect Request", upon receipt of a DISCONNECT message, shall return to its peer entity the RELEASE message and enter the CC-state U19, "Release Request".

#### References

TS 24.008 clause 5.4.5.

##### 10.1.2.7.1.3 Test purpose

To verify that the a CC-entity of the UE in CC-state U11, "Disconnect Request", upon receipt of a DISCONNECT message, returns to its peer entity the RELEASE message and enters the CC-state U19, "Release Request".

##### 10.1.2.7.1.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U11 by using table 10.1.2/3.

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U11. The SS sends a DISCONNECT message to the UE. The UE shall respond with a RELEASE message. The SS checks by using the status enquiry procedure that the CC entity of the UE has entered the state U19, release request.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		DISCONNECT	cause 30#, state U19
2	->		RELEASE	
3	<-		STATUS ENQUIRY	
4	->		STATUS	

Specific message contents:

None.

#### 10.1.2.7.1.5 Test requirements

After step 1 a CC-entity of the UE in CC-state U11, "Disconnect Request", shall return the RELEASE message and enter the CC-state U19, "Release Request".

#### 10.1.2.7.2 U11 disconnect request / RELEASE received

##### 10.1.2.7.2.1 Definition

The call control entity of the UE being in the state, U11, a RELEASE message is received by the UE. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.7.2.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U11, "Disconnect Request", upon receipt of the RELEASE message shall return RELEASE COMPLETE and enter the CC-state U0, "Null".
- 2) On returning to the idle mode the UE shall release the MM-connection and the CC-entities relating to the seven mobile originating transaction identifiers shall be in CC-state U0, "Null".

#### References

Conformance requirement 1: TS 24.008 clause 5.4.3.

Conformance requirement 2: TS 24.008 clause 4.5.3., TS 24.008 clause 5.5.3.2., TS 24.008 clause 8.3.

##### 10.1.2.7.2.3 Test purpose

- 1) To verify that the a CC-entity of the UE in CC-state U11, "Disconnect Request", upon receipt of the RELEASE message shall return RELEASE COMPLETE and enter the CC-state U0, "Null".
- 2) To verify that the UE on returning to the idle mode releases the MM-connection and that the CC-entities relating to the seven mobile originating transaction identifiers are in CC-state U0, "Null".

##### 10.1.2.7.2.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U11 by using table 10.1.2/3.

### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U11. The SS sends a RELEASE message to the UE. The UE shall respond with a RELEASE COMPLETE message. The SS checks by using the status enquiry procedure that the CC entity has entered the state U0 with all the relevant transaction identifiers.

### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		<-	RELEASE	cause 81# (invalid TI value) repeat steps 3-4 to cover all the transaction identifiers from 000...110 the main signalling link shall be released.
2		->	RELEASE COMPLETE	
3		<-	STATUS ENQUIRY	
4		->	RELEASE COMPLETE	
5		SS		
6		<-	RRC CONNECTION RELEASE	
7		->	RRC CONNECTION RELEASE COMPLETE	

### Specific message contents:

None.

#### 10.1.2.7.2.5 Test requirements

After step 1 a CC-entity of the UE in CC-state U11, "Disconnect Request", shall return the RELEASE COMPLETE.

After step 3 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

#### 10.1.2.7.3 U11 disconnect request / timer T305 time-out

##### 10.1.2.7.3.1 Definition

The call control entity of the UE being in the state, U11, if no response is then received from the SS, timer T305 expires at the UE side. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.7.3.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U11, "Disconnect Request" shall on expiry of T305, proceed with the connection release procedure by sending the RELEASE message to its peer entity and shall enter the CC-state U19, "Release Request".

### References

TS 24.008 clause 5.4.3., TS 24.008 clause 11.3.



### 10.1.2.7.3.3 Test purpose

To verify that the CC-entity of the UE in CC-state U11, "Disconnect Request" shall on expiry of T305, proceed with the connection release procedure by sending the RELEASE message to its peer entity and enters the CC-state U19, "Release Request".

### 10.1.2.7.3.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U11 by using table 10.1.2/3.

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U11. Then T305 expires at the UE and the UE shall send a RELEASE message. The SS checks timer T305 accuracy and that the CC entity has entered the state U19, release request.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		SS waits until T305 expires at the UE
2		->	RELEASE	SS checks the time between DISCONNECT and RELEASE (note), check the timer T305 accuracy
3		<-	STATUS ENQUIRY	
4		->	STATUS	cause 30#, state U19

#### Specific message contents:

NOTE: With the same cause value as originally contained in the DISCONNECT message. An additional cause information element (#102 recovery on timer expiry) may be included.

### 10.1.2.7.3.5 Test requirements

Upon expiry of timer T305 a CC-entity of the UE in CC-state U11, "Disconnect Request", shall proceed with the connection release procedure by sending the RELEASE message and enter the CC-state U19, "Release Request".

#### 10.1.2.7.4 U11 disconnect request / lower layer failure

##### 10.1.2.7.4.1 Definition

The call control entity of the UE being in the state, U11, a lower layer failure is accomplished at the UE and consequently, communication at layer 3 level with the peer entity is terminated. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.7.4.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U11, "Disconnect Request" having detected a lower layer failure shall return to the idle mode. The CC entities relating to the seven mobile originating transaction identifiers shall be in state U0, "Null".

#### References

TS 24.008 clause 4.5.2.3., TS 24.008 clause 4.5.3., TS 24.008 clause 5.5.3.2., TS 25.331 clause 8.1.4., TS 24.008 clause 8.3.

##### 10.1.2.7.4.3 Test purpose

To verify that the a CC-entity of the UE in CC-state U11, "Disconnect Request" having detected a lower layer failure returns to the idle mode. The CC entities relating to the seven mobile originating transaction identifiers are thus in state U0, "Null".

##### 10.1.2.7.4.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U11 by using table 10.1.2/4.

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The UE is brought to the state U11. The SS generates a lower layer failure at the UE. The SS waits long enough to enable the UE to return to idle state listening to paging, and then pages UE to create RRC connection. Finally, the SS will check the state of the UE by using STATUS ENQUIRY with the relevant transaction identifiers.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		SS generates lower layer failure SS waits 20 s for the UE to return to listening to paging See TS34.108  cause 81# (invalid TI value) repeat steps 4-5 to cover all the transaction identifiers from 000...110 the main signalling link shall be released.
2		SS		
3			SS Initiated Establishment of RRC Connection	
4		<-	STATUS ENQUIRY	
5		->	RELEASE COMPLETE	
6		SS		
7		<-	RRC CONNECTION RELEASE	
8		->	RRC CONNECTION RELEASE COMPLETE	

Specific message contents:

None.

#### 10.1.2.7.4.5 Test requirements

After step 4 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

#### 10.1.2.7.5 U11 disconnect request / unknown message received

##### 10.1.2.7.5.1 Definition

The call control entity of the UE being in the state, U4, an unknown message is received by the UE. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.7.5.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U100, "Call Delivered", having received an unknown message from its peer entity shall return a STATUS message.

#### References

TS 24.008 clause 8.4.

##### 10.1.2.7.5.3 Test purpose

To verify that a CC-entity of the UE in CC-state U11, "Call Delivered", having received an unknown message from its peer entity returns a STATUS message.

##### 10.1.2.7.5.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U11 by using table 10.1.2/4.

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U11. The SS sends a message with message type not defined for the protocol discriminator to the UE. The UE shall respond with a STATUS message, and finally the SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		<-	unknown message	message type not defined for PD cause 97#, state U11
2		->	STATUS	
3		<-	STATUS ENQUIRY	cause 30#, state U11
4		->	STATUS	

#### Specific message contents:

None.

#### 10.1.2.7.5.5 Test requirements

After step 1 a CC-entity of the UE in CC-state U11, "Disconnect Request", shall return a STATUS message.

#### 10.1.2.8 U12 disconnect indication

##### 10.1.2.8.1 U12 disconnect indication / call releasing requested by the user

##### 10.1.2.8.1.1 Definition

The call control entity of the UE being in the state, U12, the user requests to terminate the call. This test is applicable only for user equipment supporting bearer capability for speech.

##### 10.1.2.8.1.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U12, "Disconnect Indication" being in network initiated call release phase, shall, upon receiving a call release request from the user send a RELEASE to its peer entity and enter CC-state U19, "Release Request".

#### References

TS 24.007 clause 6.2.2., TS 24.008 clause 5.4.4.

##### 10.1.2.8.1.3 Test purpose

To verify that a CC-entity of the UE in CC-state U12, "Disconnect Indication" being in network initiated call release phase, shall, upon receiving a call release request from the user sends a RELEASE to its peer entity and enters CC-state U19, "Release Request"

## 10.1.2.8.1.4 Method of test

## Related ICS/IXIT statements

- supported MO circuit switched basic services.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U12 by using Option A of table 10.1.2/1.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U12. The user requests termination of the call. The UE shall send a RELEASE message. The SS checks by using the status enquiry procedure that the CC entity has entered the state U19, release request.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				MMI action, "on hook"  cause 30#, state U19
2		->	RELEASE	
3		<-	STATUS ENQUIRY	
4		->	STATUS	

## Specific message contents:

None.

## 10.1.2.8.1.5 Test requirements

After step 1 a CC-entity of the UE in CC-state U12, "Disconnect Indication" being in network initiated call release phase, shall send a RELEASE message and enter CC-state U19, "Release Request".

## 10.1.2.8.2 U12 disconnect indication / RELEASE received

## 10.1.2.8.2.1 Definition

The call control entity of the UE being in the state, U12, a RELEASE message is received by the UE. This test is applicable only for user equipment supporting bearer capability for speech.

## 10.1.2.8.2.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U12, "Disconnect Indication", upon receipt of a RELEASE message shall return to its peer entity the RELEASE COMPLETE message and enter the CC-state U0, "Null".
- 2) On returning to the idle mode the UE shall release the MM-connection and the CC-entities relating to the seven mobile originating transaction identifiers shall be in CC-state U0, "Null".

## References

Conformance requirement 1: TS 24.008 clause 5.4.2

Conformance requirement 2: TS 24.008 clause 4.5.3., TS 24.008 clause 5.5.3.2., TS 24.008 clause 8.3.

## 10.1.2.8.2.3 Test purpose

- 1) To verify that a CC-entity of the UE in CC-state U12, "Disconnect Indication", upon receipt of a RELEASE message returns to its peer entity the RELEASE COMPLETE message and enters the CC-state U0, "Null".
- 2) To verify that the UE on returning to the idle mode releases the MM-connection and that the CC-entities relating to the seven mobile originating transaction identifiers are in CC-state U0, "Null".

## 10.1.2.8.2.4 Method of test

## Related ICS/IXIT statements

- supported MO circuit switched basic services.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U12 by using Option A of table 10.1.2/1.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U12. The SS sends a RELEASE message to the UE. The UE shall respond with a RELEASE COMPLETE message. The SS checks by using the status enquiry procedure that the CC entity has entered the state U0 with all the relevant transaction identifiers.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		RELEASE	cause 81# (invalid TI value) repeat steps 3-4 to cover all the transaction identifiers from 000...110 the main signalling link shall be released.
2	->		RELEASE COMPLETE	
3	<-		STATUS ENQUIRY	
4	->		RELEASE COMPLETE	
5		SS		
6	<-		RRC CONNECTION RELEASE	
7	->		RRC CONNECTION RELEASE COMPLETE	

## Specific message contents:

None.

#### 10.1.2.8.2.5 Test requirements

After step 1 a CC-entity of the UE in CC-state U12, "Disconnect Indication", shall return the RELEASE COMPLETE message.

After step 3 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

#### 10.1.2.8.3 U12 disconnect indication / lower layer failure

##### 10.1.2.8.3.1 Definition

The call control entity of the UE being in the state, U12, a lower layer failure is accomplished at the UE and consequently, communication at layer 3 level with the peer entity is terminated. This test is applicable only for user equipment supporting bearer capability for speech.

##### 10.1.2.8.3.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U12, "Disconnect Indication" having detected a lower layer failure shall return to idle mode. The CC-entities relating to the seven mobile originating transaction identifiers shall be in state U0, "Null".

#### References

TS 24.008 clause 4.5.3.2., TS 24.008 clause 4.5.3., TS 24.008 clause 5.5.3.2., TS 25.331 clause 8.1.4., TS 24.008 clause 8.3.

##### 10.1.2.8.3.3 Test purpose

To verify that a CC-entity of the UE in CC-state U12, "Disconnect Indication" having detected a lower layer failure returns to idle mode. The CC-entities relating to the seven mobile originating transaction identifiers are thus in state U0, "Null".

##### 10.1.2.8.3.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U12 by using Option A of table 10.1.2/3.

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The UE is brought to the state U12. The SS generates a lower layer failure at the UE. The SS waits long enough to enable the UE to return to idle state listening to paging, and then pages UE to create RRC connection. Finally, the SS will check the state of the UE by using STATUS ENQUIRY with the relevant transaction identifiers.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		SS generates lower layer failure SS waits 20 s for the UE to return to listening to paging See TS34.108  cause 81# (invalid TI value) repeat steps 4-5 to cover all the transaction identifiers from 000...110 the main signalling link shall be released.
2		SS		
3			SS Initiated Establishment of RRC Connection	
4		<-	STATUS ENQUIRY	
5		->	RELEASE COMPLETE	
6		SS		
7		<-	RRC CONNECTION RELEASE	
8		->	RRC CONNECTION RELEASE COMPLETE	

Specific message contents:

None.

#### 10.1.2.8.3.5 Test requirements

After step 4 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

#### 10.1.2.8.4 U12 disconnect indication / unknown message received

##### 10.1.2.8.4.1 Definition

The call control entity of the UE being in the state, U12, an unknown message is received by the UE. This test is applicable only for user equipment supporting bearer capability for speech.

##### 10.1.2.8.4.2 Conformance requirement

A CC-entity of the UE in CC-state U12, "Disconnect Indication" having received an unknown message from its peer entity shall return a STATUS message.

#### References

TS 24.008 clause 8.4.

##### 10.1.2.8.4.3 Test purpose

To verify that a CC-entity of the UE in CC-state U12, "Disconnect Indication" having received an unknown message from its peer entity returns a STATUS message.

##### 10.1.2.8.4.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:



The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U12 by using Option A of table 10.1.2/3.

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U12. The SS sends a message with message type not defined for the protocol discriminator to the UE. The UE shall respond with a STATUS message, and finally the SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		<-	unknown message	message type not defined for PD
2		->	STATUS	cause 97#, state U12
3		<-	STATUS ENQUIRY	
4		->	STATUS	cause 30#, state U12

#### Specific message contents:

None.

#### 10.1.2.8.4.5 Test requirements

After step 1 a CC-entity of the UE in CC-state U12, "Disconnect Indication", shall return a STATUS message.

#### 10.1.2.9 Outgoing call / U19 release request

##### 10.1.2.9.1 Outgoing call / U19 release request / timer T308 time-out

##### 10.1.2.9.1.1 Definition

The call control entity of the UE being in the state, U19, if no response is then received from the SS, timer T308 expires at the UE side. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.9.1.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U19, "Release Request" will, upon the first expiry of timer T308 send the RELEASE message to its peer entity and remain in the CC-state U19.

#### References

TS 24.008 clause 5.4.4.1.3.1, TS 24.008 clause 11.3.

##### 10.1.2.9.1.3 Test purpose

To verify that a CC-entity of the UE in CC-state U19, "Release Request" will, upon the first expiry of timer T308 send the RELEASE message to its peer entity and remain in the CC-state U19.

##### 10.1.2.9.1.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

## Initial conditions

### System Simulator:

1 cell, default parameters.

### User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U19 by using table 10.1.2/4.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U19. When T308 expires at the UE, the UE shall send a RELEASE message. The SS checks timer T308 accuracy and that the state of the CC entity has remained unchanged.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		SS waits until T308 at the UE
2		->	RELEASE	SS checks the time between the two RELEASE messages check the timer T308 accuracy
3		<-	STATUS ENQUIRY	
4		->	STATUS	cause 30#, state U19

## Specific message contents:

None.

### 10.1.2.9.1.5 Test requirements

Upon the first expiry of timer T308 (after step 1) a CC-entity of the UE in CC-state U19, "Release Request", shall send the RELEASE message and remain in the CC-state U19.

### 10.1.2.9.2 Outgoing call / U19 release request / 2nd timer T308 time-out

#### 10.1.2.9.2.1 Definition

The call control entity of the UE being in the state, U19, if no response is then received after timer T308 has expired two times in success at the UE. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

#### 10.1.2.9.2.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U19, "Release Request", upon the 2nd expiry of the timer T308, shall enter the CC-state U0, "Null".
- 2) Subsequently the UE shall proceed with releasing the MM-connection and enter the idle mode with the CC entities relating to the seven mobile originating transaction identifiers in state U0, "Null".

## References

Conformance requirement 1: TS 24.008 clause 5.4.4.1.3.1., TS 24.008 clause 11.3.

Conformance requirement 2: TS 24.008 clause 4.5.3., TS 24.008 clause 5.5.3.2.

## 10.1.2.9.2.3 Test purpose

- 1) To verify that a CC-entity of the UE in CC-state U19, "Release Request", upon the 2nd expiry of the timer T308, enters the CC-state U0, "Null".
- 2) To verify that subsequently the UE proceeds with releasing the MM-connection and enters the idle mode with the CC entities relating to the seven mobile originating transaction identifiers in state U0, "Null".

## 10.1.2.9.2.4 Method of test

## Related ICS/IXIT statements

- supported MO circuit switched basic services.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U19 by using table 10.1.2/4.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U19. The SS allows T308 expiry at the UE, and the UE shall repeat sending the RELEASE message and start timer T308 again. The SS allows again T308 expiry at the UE. The UE shall abort the RRC connection. The SS waits long enough to enable the UE to return to idle state listening to paging, and then pages UE to create RRC connection. Finally, the SS will check the state of the UE by using STATUS ENQUIRY with the relevant transaction identifiers.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		SS waits until T308 expiry at the UE
2	->		RELEASE	
3	<-		STATUS ENQUIRY	
4	->		STATUS	cause 30#, state U19
5		SS		SS waits until the second T308 expiry at the UE
6		SS		SS waits T3240 expiry at the UE
7		UE		the main signalling link shall be released.
8		SS		SS waits 10 s for the UE to return to listening to paging
9			SS Initiated Establishment of RRC Connection	See TS34.108
10	<-		STATUS ENQUIRY	
11	->		RELEASE COMPLETE	cause 81# (invalid TI value)
12		SS		repeat steps 10-11 to cover all the transaction identifiers from 000...110
13	<-		RRC CONNECTION RELEASE	the main signalling link shall be released.
14	->		RRC CONNECTION RELEASE COMPLETE	

Specific message contents:

None.

#### 10.1.2.9.2.5 Test requirements

Upon the 2nd expiry of the timer T308 (after step 5) a CC-entity of the UE in CC-state U19, "Release Request", shall enter the CC-state U0, "Null".

After step 10 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

#### 10.1.2.9.3 Outgoing call / U19 release request / RELEASE received

##### 10.1.2.9.3.1 Definition

The call control entity of the UE being in the state, U19, a RELEASE message is received by the UE. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.9.3.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U19, "Release Request", upon receipt of a RELEASE, shall release the MM-connection and enter the CC-state U0, "Null" with the CC entities relating to the seven mobile originating transaction identifiers in state U0, "Null".

#### References

TS 24.008 clause 5.4.5., TS 24.008 clause 11.3, TS 24.008 clause 5.5.3.2.

##### 10.1.2.9.3.3 Test purpose

To verify that a CC-entity of the UE in CC-state U19, "Release Request", upon receipt of a RELEASE, shall release the MM-connection and enters the CC-state U0, "Null" with the CC entities relating to the seven mobile originating transaction identifiers in state U0, "Null".

##### 10.1.2.9.3.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U19 by using table 10.1.2/4.

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U19. The SS sends a RELEASE message to the UE. The UE shall release the MM-connection. The SS checks by using the status enquiry procedure that the CC entity has entered the state U0 with all the relevant transaction identifiers.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		RELEASE	(note)  cause 81# (invalid TI value) repeat steps 2-3 to cover all the transaction identifiers from 000...110 the main signalling link shall be released.
2	<-		STATUS ENQUIRY	
3	->		RELEASE COMPLETE	
4		SS		
5	<-		RRC CONNECTION RELEASE	
6	->		RRC CONNECTION RELEASE COMPLETE	

Specific message contents:

NOTE: With the same cause number as originally contained in DISC and optional cause #102 recovery on timer expiry.

#### 10.1.2.9.3.5 Test requirements

After step 2 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

#### 10.1.2.9.4 Outgoing call / U19 release request / RELEASE COMPLETE received

##### 10.1.2.9.4.1 Definition

The call control entity of the UE being in the state, U19, a RELEASE COMPLETE message is received by the UE. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.9.4.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U19, "Release Request", upon receipt of a RELEASE COMPLETE, shall release the MM-connection and enter the CC-state U0, "Null" with the CC entities relating to the seven mobile originating transaction identifiers in state U0, "Null".

#### References

TS 24.008 clause 5.4.4.1.3., TS 24.008 clause 4.5.3, TS 24.008 clause 8.3.

##### 10.1.2.9.4.3 Test purpose

To verify that a CC-entity of the UE in CC-state U19, "Release Request", upon receipt of a RELEASE COMPLETE, shall release the MM-connection and enters the CC-state U0, "Null" with the CC entities relating to the seven mobile originating transaction identifiers in state U0, "Null".

##### 10.1.2.9.4.4 Method of test

#### Related ICS/IXIT statements

- supported MO circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U19 by using table 10.1.2/1.

### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U19. The SS sends a RELEASE COMPLETE message to the UE. The UE shall release the MM-connection. The SS checks by using the status enquiry procedure that the CC entity has entered the state U0 with all the relevant transaction identifiers.

### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		<-	RELEASE COMPLETE	cause 81# (invalid TI value) repeat steps 2-3 to cover all the transaction identifiers from 000...110 the main signalling link shall be released.
2		<-	STATUS ENQUIRY	
3		->	RELEASE COMPLETE	
4		SS		
5		<-	RRC CONNECTION RELEASE	
6		->	RRC CONNECTION RELEASE COMPLETE	

### Specific message contents:

None.

#### 10.1.2.9.4.5 Test requirements

After step 2 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

#### 10.1.2.9.5 Outgoing call / U19 release request / lower layer failure

##### 10.1.2.9.5.1 Definition

The call control entity of the UE being in the state, U19, a lower layer failure is accomplished at the UE and consequently, communication at layer 3 level with the peer entity is terminated. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

##### 10.1.2.9.5.2 Conformance requirement

A CC-entity of the UE in CC-state U19, "Release Request", having detected a lower layer failure, shall return to the idle mode, the CC entities relating to the seven mobile originating transaction identifiers shall be in state U0, "Null".

### References

TS 24.008 clause 4.5.2.3., TS 24.008 clause 4.5.3., TS 24.008 clause 5.5.3.2., TS 24.008 clause 8.3.

##### 10.1.2.9.5.3 Test purpose

To verify that a CC-entity of the UE in CC-state U19, "Release Request", having detected a lower layer failure, returns to the idle mode, the CC entities relating to the seven mobile originating transaction identifiers are in state U0, "Null".

## 10.1.2.9.5.4 Method of test

## Related ICS/IXIT statements

- supported MO circuit switched basic services.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U19 by using table 10.1.2/1.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The UE is brought to the state U19. The SS generates a lower layer failure at the UE. The SS waits long enough to enable the UE to return to idle state listening to paging, and then pages UE to create RRC connection. Finally, the SS will check the state of the UE by using STATUS ENQUIRY with the relevant transaction identifiers.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		SS generates lower layer failure SS waits 20 s for the UE to return to listening to paging See TS34.108
2		SS		
3			SS Initiated Establishment of RRC Connection	
4	<-		STATUS ENQUIRY	cause 81# (invalid TI value) repeat steps 4-5 to cover all the transaction identifiers from 000...110 the main signalling link shall be released.
5	->		RELEASE COMPLETE	
6		SS		
7	<-		RRC CONNECTION RELEASE	
8	->		RRC CONNECTION RELEASE COMPLETE	

## Specific message contents:

None.

## 10.1.2.9.5.5 Test requirements

After step 4 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

## 10.1.3 Establishment of an incoming call / Initial conditions

The tables below describe message exchanges which bring the UE in the requested initial states in case of an incoming call.

A state may be taken as initial only when all the states which lead to this initial states have been validated. The order will be U0, U6, U9, U7, U8, U10, U26 etc. as in the following tables.

**Table 10.1.3/1: Establishment of an incoming call, procedure 1**

Step	Direction		Message	Comments
	UE	SS		
1			SS Initiated Establishment of RRC Connection	See TS34.108  U6, (note 1) U9
2	->		PAGING RESPONSE	
3	<-		AUTHENTICATION REQUEST	
4	->		AUTHENTICATION RESPONSE	
5	<-		SECURITY MODE COMMAND	
6	->		SECURITY MODE COMPLETE	
7	<-		SETUP	
8	->		CALL CONFIRMED	
A9	->		CONNECT	U8, p = Y, (note 2)
B9	->		ALERTING	U7, p = N, (note 2) (note 3) U8
B10	UE			
B11	->		CONNECT	
12			Radio Bearer Setup Procedure	DTCH, See TS34.108 U10
13	<-		CONNECT ACKNOWLEDGE	

NOTE 1: With signal information included in the SETUP message.

NOTE 2: The UE is supporting immediate connect (p = Y/N). See ICS/IXIT statement.

NOTE 3: If necessary (see ICS/IXIT statement), the UE is made to accept the call in the way described in a ICS/IXIT statement.

**Table 10.1.3/2: Establishment of an incoming call, procedure 2**

Step	Direction		Message	Comments
	UE	SS		
1			SS Initiated Establishment of RRC Connection	See TS34.108  U6, (note 4) U9
2	->		PAGING RESPONSE	
3	<-		SECURITY MODE COMMAND	
4	->		SECURITY MODE COMPLETE	
5	<-		SETUP	
6	->		CALL CONFIRMED	
A7	->		CONNECT	U8, p = Y, (note 5) DTCH, See TS34.108
A8			Radio Bearer Setup Procedure	
B7	->		ALERTING	U7, p = N, (note 5) DTCH, See TS34.108 (note 6) U8
B8			Radio Bearer Setup Procedure	
B9	UE			
B10	->		CONNECT	
11	<-		AUTHENTICATION REQUEST	
12	->		AUTHENTICATION RESPONSE	
13	<-		CONNECT ACKNOWLEDGE	U10

NOTE 4: With signal information included in the SETUP message.

NOTE 5: The UE is supporting immediate connect (p = Y/N). See ICS/IXIT statement.

NOTE 6: If necessary (see ICS/IXIT statement), the UE is made to accept the call in the way described in a ICS/IXIT statement.



Table 10.1.3/3: Void

Table 10.1.3/4: Establishment of an incoming call, procedure 4

Step	Direction		Message	Comments
	UE	SS		
1			SS Initiated Establishment of RRC Connection	See TS34.108  U6, (note 11) U9 DTCH, See TS34.108
2		->	PAGING RESPONSE	
3		<-	SECURITY MODE COMMAND	
4		->	SECURITY MODE COMPLETE	
5		<-	SETUP	
6		->	CALL CONFIRMED	
7			Radio Bearer Setup Procedure	
A8		->	CONNECT	U8, p = Y, (note 12)
B8		->	ALERTING	U7, p = N, (note 12) (note 13) U8
B9	UE			
B10		->	CONNECT	
11		<-	AUTHENTICATION REQUEST	
12		->	AUTHENTICATION RESPONSE	
13		<-	CONNECT ACKNOWLEDGE	U10

NOTE 11: The signal information element is not included in the SETUP message.

NOTE 12: The UE is supporting immediate connect (p = Y/N). See ICS/IXIT statement.

NOTE 13: If necessary (see ICS/IXIT statement), the UE is made to accept the call in the way described in a ICS/IXIT statement.

### 10.1.3.1 Incoming call / U0 null state

#### 10.1.3.1.1 Incoming call / U0 null state / SETUP received with a non supported bearer capability

##### 10.1.3.1.1.1 Definition

The call control entity of the UE being in the state, U0, a SETUP message is received with only one bearer capability and this bearer capability is not supported by the UE. This test is applicable for all equipment.

##### 10.1.3.1.1.2 Conformance requirement

- 1) A CC entity of the UE, upon receipt of SETUP containing one bearer capability and this bearer capability is not supported, shall return a RELEASE COMPLETE with correct cause value to its peer entity and return to the idle mode. The CC-entities relating to the seven mobile terminating transaction identifiers shall be in the state U0,"Null".

### References

TS 24.008 clause 5.2.2.2., TS 24.008 annex B.

##### 10.1.3.1.1.3 Test purpose

To verify that a CC entity of the UE, upon receipt of SETUP containing one bearer capability and this bearer capability is not supported, returns a RELEASE COMPLETE with correct cause value to its peer entity, and returns to the idle mode. To verify that the CC-entities relating to the seven mobile terminating transaction identifiers are then in the state U0,"Null".

## 10.1.3.1.1.4 Method of test

## Related ICS/IXIT statements

- supported MO circuit switched basic services.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

## Test procedure

A mobile terminated call is initiated. The UE receives a SETUP message that contains a bearer capability not supported by the UE. The UE returns a RELEASE COMPLETE message. The SS checks by using the status enquiry procedure that the CC entity is still in the state U0 with all the relevant transaction identifiers.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			SS Initiated Establishment of RRC Connection	SS sends paging, See TS34.108  (note 1) (note 2)  Cause #81 (invalid TI value). Repeat steps 9-10 to cover all the transaction identifiers from 000... 110.
2	->		PAGING RESPONSE	
3	<-		AUTHENTICATION REQUEST	
4	->		AUTHENTICATION RESPONSE	
5	<-		SECURITY MODE COMMAND	
6	->		SECURITY MODE COMPLETE	
7	<-		SETUP	
8	->		RELEASE COMPLETE	
9	<-		STATUS ENQUIRY	
10	->		RELEASE COMPLETE	
11		SS		

## Specific message contents:

NOTE 1: With one bearer capability and that bearer capability is not supported by the UE.

NOTE 2: With cause #88 incompatible destination.

## 10.1.3.1.1.5 Test requirements

After step 7 a CC entity of the UE shall return a RELEASE COMPLETE message with cause value #88 (incompatible destination) and return to the idle mode.

After step 9 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

### 10.1.3.2 Incoming call / U6 call present

#### 10.1.3.2.1 Incoming call / U6 call present / automatic call rejection

##### 10.1.3.2.1.1 Definition

Although the state U6 is transient, the ability to refuse a call (automatically) in this state is tested, if it is implemented at the UE. The test is applicable for those equipments described above supporting at least one mobile terminating circuit switched basic service.

##### 10.1.3.2.1.2 Conformance requirement

- 1) A CC entity of the UE in CC-state U6, "Call Present", upon receipt of a rejection indication of the incoming call from the user, send RELEASE COMPLETE with the appropriate cause value to its peer entity and enter the CC-state U0, "Null". The CC entities relating to the seven mobile terminating transaction identifiers shall be in state U0, "Null".

#### References

TS 24.007 clause 6.2.2., TS 24.008 clause 5.2.2.3.1., TS 24.008 clause 5.5.3.2, TS 24.008 clause 8.3.

##### 10.1.3.2.1.3 Test purpose

To verify that a CC entity of the UE in CC-state U6, "Call Present", shall upon receipt of a rejection indication of the incoming call from the user, shall send RELEASE COMPLETE with the appropriate cause value to its peer entity and enter the CC-state U0, "Null". The CC entities relating to the seven mobile terminating transaction identifiers are then in state U0, "Null".

##### 10.1.3.2.1.4 Method of test

#### Related ICS/IXIT statements

- supported teleservices;
- the UE supports an ability to refuse a call after receipt of a SETUP message.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U6 by using table 10.1.3/2.

#### Test procedure

A teleservice is selected that is supported by the UE; if the UE supports speech, the selected teleservice is speech. If necessary, the UE is configured for that teleservice. Then a mobile terminated call is initiated. The call control entire of the UE is brought to the state U6 (Note: The state U6 is not checked, since it is not stable). The UE is made to refuse the call (the refusal may require some preliminary preparations in order to achieve refusal at this point). The UE shall send a RELEASE COMPLETE message and enter a call control state U0. The SS checks by using the status enquiry procedure that the CC entity has entered the state U0 with all the relevant transaction identifiers.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				the UE is made to refuse the call (note)  cause 81# (invalid TI value) repeat steps 3-4 to cover all the transaction identifiers from 000...110 the main signalling link shall be released.
2		->	RELEASE COMPLETE	
3		<-	STATUS ENQUIRY	
4		->	RELEASE COMPLETE	
5		SS		
6		<-	RRC CONNECTION RELEASE	
7		->	RRC CONNECTION RELEASE COMPLETE	

Specific message contents:

NOTE: With cause value #21 call rejected.

#### 10.1.3.2.1.5 Test requirements

After step 1 a CC entity of the UE shall return a RELEASE COMPLETE message with cause value #21 (call rejected) and return to the idle mode.

After step 11 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

### 10.1.3.3 Incoming call / U9 mobile terminating call confirmed

#### 10.1.3.3.1 Incoming call / U9 mobile terminating call confirmed / alerting or immediate connecting

##### 10.1.3.3.1.1 Definition

The call control entity of the UE having entered the state, U9, with signal information received in the preceding SETUP message, the subsequent behaviour of the UE is tested. This test is applicable for any equipment supporting at least one mobile terminating circuit switched basic service.

##### 10.1.3.3.1.2 Conformance requirement

- 1) A CC entity in CC-state U9, "Mobile Terminating Call Confirmed", (if signalled by the network in previous SETUP message that it may alert) shall either send a ALERTING message to its peer entity and enter state U7, or send a CONNECT message to its peer entity and enter U8.

#### References

TS 24.008 clause 5.2.2.3.2.

##### 10.1.3.3.1.3 Test purpose

To verify that a CC entity in CC-state U9, "Mobile Terminating Call Confirmed", (if signalled by the network in previous SETUP message that it may alert) will either send a ALERTING message to its peer entity and enter state U7, or send a CONNECT message to its peer entity and enter U8.

##### 10.1.3.3.1.4 Method of test

#### Related ICS/IXIT statements

- supported MT circuit switched basic services;

- MT circuit switched basic services for which immediate connect is not used.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U9 by using table 10.1.3/2.

#### Test procedure

An MT circuit switched basic service is selected that is supported by the UE; if the UE supports MT telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U9 by using a SETUP message containing signalling information element. (The state U9 is not a stable state in this case, and consequently it is not checked as an initial state.) If the UE supports immediate connect for the selected basic service ( $p = Y$ ), it sends a CONNECT message and enters the state U8, connect request. Otherwise ( $p = N$ ) the UE sends an ALERTING message and enters the state U7, call receiving. The SS checks by using the status enquiry procedure that the CC entity has entered its state as described.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
A11	->		CONNECT	$p = Y$
A12	<-		STATUS ENQUIRY	
A13	->		STATUS	cause 30#, state U8
B11	->		ALERTING	$p = N$
B12	<-		STATUS ENQUIRY	
B13	->		STATUS	cause 30#, state U7

Specific message contents:

None.

#### 10.1.3.3.1.5 Test requirements

A CC entity in CC-state U9, "Mobile Terminating Call Confirmed", (if signalled by the network in previous SETUP message that it may alert) shall either send an ALERTING message and enter state U7, or send a CONNECT message and enter U8.

#### 10.1.3.3.2 Incoming call / U9 mobile terminating call confirmed / DTCH assignment

##### 10.1.3.3.2.1 Definition

The call control entity of the UE being in the state, U9, a radio bearer establishment procedure is performed for traffic channel. This test is applicable for any equipment supporting at least one MT circuit switched basic service, for which immediate connect is not used.

##### 10.1.3.3.2.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed", when a traffic channel is allocated by the network performing the radio bearer establishment procedure, shall send a ALERTING message and enter state U7.

## References

TS 25.331 clause 8.2.1, TS 24.008 clause 5.2.2.7., TS 24.008 clause 5.2.2.3.2.

## 10.1.3.3.2.3 Test purpose

To verify that a CC-entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed", when a traffic channel is allocated by the network performing the radio bearer establishment procedure, shall send a ALERTING message and enters state U7.

## 10.1.3.3.2.4 Method of test

## Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U9 by using table 10.1.3/4.

## Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U9 (by using a SETUP message not containing the signal information element). The SS sends a RADIO BEARER SETUP for traffic channel to the UE. The UE shall respond with a RADIO BEARER SETUP COMPLETE message. The UE sends an ALERTING message and enters state U7, call received. The SS verifies by using the status enquiry procedure that the UE has entered the correct state.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			Radio Bearer Setup Procedure	DTCH, See TS34.108  cause 30#, state U7
2		->	ALERTING	
3		<-	STATUS ENQUIRY	
4		->	STATUS	

## Specific message contents:

None.

## 10.1.3.3.2.5 Test requirements

After step 1 a CC-entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed" shall send a ALERTING message and enter state U7.

### 10.1.3.3.3 Incoming call / U9 mobile terminating call confirmed / termination requested by the user

#### 10.1.3.3.3.1 Definition

The call control entity of the UE being in the state, U9, the user requests for releasing of the call. This test is applicable for any equipment supporting at least one MT circuit switched basic service for which immediate connection is not used and, in addition to this, the facility to send a DISCONNECT message in state U9.

#### 10.1.3.3.3.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed", upon request by the user to terminate shall send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

#### References

TS 24.007 clause 6.2.2., TS 24.008 clause 5.4.3.

#### 10.1.3.3.3.3 Test purpose

To verify that a CC-entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed", upon request by the user to terminate will send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

#### 10.1.3.3.3.4 Method of test

#### Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used;
- the UE supports user requested call clearing in the state U9.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U9 by using table 10.1.3/4.

#### Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U9 (by using a SETUP message not containing the signal information element). Then the user requests termination of the call, if possible. The UE sends a DISCONNECT message and enters state U11, disconnect request. The SS verifies by using the status enquiry procedure that the UE has entered the correct state.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				the UE is made to clear the call  cause 30#, state U11
2		->	DISCONNECT	
3		<-	STATUS ENQUIRY	
4		->	STATUS	

Specific message contents:

None.

#### 10.1.3.3.3.5 Test requirements

After step 1 a CC-entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed", shall send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

#### 10.1.3.3.4 Incoming call / U9 mobile terminating call confirmed / DISCONNECT received

##### 10.1.3.3.4.1 Definition

The call control entity of the UE being in the state, U9, a DISCONNECT message is received by the UE. This test is applicable for any equipment supporting at least one MT circuit switched basic service, for which immediate connect is not used.

##### 10.1.3.3.4.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed", upon receipt of a DISCONNECT shall return a RELEASE message and enter the CC-state U19, "Release Request".

#### References

TS 24.008 clause 5.4.4.

##### 10.1.3.3.4.3 Test purpose

To verify that a CC-entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed", upon receipt of a DISCONNECT returns a RELEASE message and enters the CC-state U19, "Release Request".

##### 10.1.3.3.4.4 Method of test

#### Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U9 by using table 10.1.3/4.



## Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U9. The SS sends a DISCONNECT message to the UE. The UE responds by sending a RELEASE message and enters state U19, release request. The SS verifies by using the status enquiry procedure that the UE has entered the correct state.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		<-	DISCONNECT	
2		->	RELEASE	
3		<-	STATUS ENQUIRY	
4		->	STATUS	cause 30#, state U19

## Specific message contents:

None.

### 10.1.3.3.4.5 Test requirements

After step 1 a CC-entity of the UE in CC-state U9, "UE Terminating Call Confirmed", shall return a RELEASE message and enter the CC-state U19, "Release Request".

### 10.1.3.3.5 Incoming call / U9 mobile terminating call confirmed / RELEASE received

#### 10.1.3.3.5.1 Definition

The call control entity of the UE being in the state, U9, a RELEASE message is received by the UE. This test is applicable for any equipment supporting at least one MT circuit switched basic service, for which immediate connect is not used.

#### 10.1.3.3.5.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed", upon receipt of a RELEASE shall return a RELEASE COMPLETE and enter the CC-state U0, "Null".
- 2) On returning to the idle mode the UE shall release the MM-connection and the CC-entities relating to the seven mobile terminating transaction identifiers shall be in CC-state U0, "Null".

## References

Conformance requirement 1: TS 24.008 clause 5.4.4.

Conformance requirement 2: TS 24.008 clause 4.5.3., TS 24.008 clause 5.5.3.2.,  
TS 24.008 clause 8.3.

### 10.1.3.3.5.3 Test purpose

- 1) To verify that a CC-entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed", upon receipt of a RELEASE will return a RELEASE COMPLETE and enter the CC-state U0, "Null".
- 2) To verify that the UE on returning to the idle mode releases the MM-connection and that the CC-entities relating to the seven mobile terminating transaction identifiers are in CC-state U0, "Null".

## 10.1.3.3.5.4 Method of test

## Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

## Initial conditions

## System Simulator:

1 cell, default parameters.

## User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U9 by using table 10.1.3/4.

## Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U9. The SS sends a RELEASE message to the UE. The UE responds by sending a RELEASE COMPLETE message and enters state U0, null. The SS verifies by using the status enquiry procedure that the UE has entered the correct state with the relevant transaction identifiers.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		RELEASE	with cause "Normal, unspecified"
2	->		RELEASE COMPLETE	
3	<-		STATUS ENQUIRY	
4	->		RELEASE COMPLETE	
5		SS		
6	<-		RRC CONNECTION RELEASE	cause 81# (invalid TI value) repeat steps 3-4 to cover all the transaction identifiers from 000...110 the main signalling link shall be released.
7	->		RRC CONNECTION RELEASE COMPLETE	

## Specific message contents:

None.

## 10.1.3.3.5.5 Test requirements

After step 1 a CC-entity of the UE in CC-state U9, "UE Terminating Call Confirmed", shall return a RELEASE COMPLETE message.

After step 3 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

### 10.1.3.3.6 Incoming call / U9 mobile terminating call confirmed / lower layer failure

#### 10.1.3.3.6.1 Definition

The call control entity of the UE being in the state, U9, a lower layer failure is accomplished at the UE and consequently, communication at layer 3 level with the peer entity is terminated. This test is applicable for any equipment supporting at least one MT circuit switched basic service, for which immediate connect is not used.

#### 10.1.3.3.6.2 Conformance requirement

- 1) A CC entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed", having detected a lower layer failure shall return to idle mode with the CC entities relating to the seven mobile terminating transaction identifiers in CC-state U0, "Null".

#### References

TS 24.008 clause 4.5.2.3., TS 24.008 clause 4.5.3., TS 24.008 clause 5.5.3.2., TS 24.008 clause 8.3.

#### 10.1.3.3.6.3 Test purpose

To verify that a CC entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed", having detected a lower layer failure returns to idle mode with the CC entities relating to the seven mobile terminating transaction identifiers in CC-state U0, "Null".

#### 10.1.3.3.6.4 Method of test

#### Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U9 by using table 10.1.3/4.

#### Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The UE is brought to the state U9. The SS generates a lower layer failure at the UE. The SS waits long enough to enable the UE to return to idle state listening to paging, and then pages UE to create RRC connection. Finally, the SS will check the state of the UE by using STATUS ENQUIRY with the relevant transaction identifiers.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		SS generates lower layer failure SS waits 20 s for the UE to return to listening to paging See TS34.108
2		SS		
3			SS Initiated Establishment of RRC Connection	cause 81# (invalid TI value) repeat steps 4-5 to cover all the transaction identifiers from 000...110 the main signalling link shall be released.
4		<-	STATUS ENQUIRY	
5		->	RELEASE COMPLETE	
6		SS		
7		<-	RRC CONNECTION RELEASE	
8		->	RRC CONNECTION RELEASE COMPLETE	

Specific message contents:

None.

#### 10.1.3.3.6.5 Test requirements

After step 4 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

#### 10.1.3.3.7 Incoming call / U9 mobile terminating call confirmed / unknown message received

##### 10.1.3.3.7.1 Definition

The call control entity of the UE being in the state, U9, an unknown message is received by the UE. This test is applicable for any equipment supporting at least MT circuit switched basic service, for which immediate connect is not used.

##### 10.1.3.3.7.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed" having received an unknown message from its peer entity shall return a STATUS message.

#### References

TS 24.008 clause 8.4.

##### 10.1.3.3.7.3 Test purpose

To verify that a CC-entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed" having received an unknown message from its peer entity returns a STATUS message.

##### 10.1.3.3.7.4 Method of test

#### Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U9 by using table 10.1.3/4.

#### Test procedure

A MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U9. The SS sends a message with message type not defined for the protocol discriminator to the UE. The UE shall respond with a STATUS message, and finally the SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		<-	unknown message	message type not defined for PD
2		->	STATUS	cause 97#, state U9
3		<-	STATUS ENQUIRY	
4		->	STATUS	cause 30#, state U9

Specific message contents:

None.

#### 10.1.3.3.7.5 Test requirements

After step 1 a CC-entity of the UE in CC-state U9, "UE Terminating Call Confirmed", shall return a STATUS message.

#### 10.1.3.4 Incoming call / U7 call received

##### 10.1.3.4.1 Incoming call / U7 call received / call accepted

##### 10.1.3.4.1.1 Definition

The call control entity of the UE being in the state, U7, a user accepts the incoming call. This test is applicable for any equipment supporting at least one mobile terminating circuit switched basic service for which immediate connect is not used.

##### 10.1.3.4.1.2 Conformance requirement

- 1) A CC entity of a UE in CC-state U7, "Call Received", upon a user accepting the incoming call, shall send a CONNECT message to its peer entity and enter the CC-state U8, "Connect Request".

#### References

TS 24.007 clause 6.2.2., TS 24.008 clause 5.2.2.5.

##### 10.1.3.4.1.3 Test purpose

To verify that a CC entity of a UE in CC-state U7, "Call Received", upon a user accepting the incoming call, shall send a CONNECT message to its peer entity and enter the CC-state U8, "Connect Request"

## 10.1.3.4.1.4 Method of test

## Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

## Initial conditions

## System Simulator:

1 cell, default parameters.

## User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U7 by using table 10.1.3/1.

## Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U7. The user accepts the incoming call. The UE sends a CONNECT message. The SS checks by using the status enquiry procedure that the CC entity has entered state U8, connect request.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				the UE is made to accept the call by the user  cause 30#, state U8
2		->	CONNECT	
3		<-	STATUS ENQUIRY	
4		->	STATUS	

## Specific message contents:

None.

## 10.1.3.4.1.5 Test requirements

After step 1 a CC entity of a UE in CC-state U7, "Call Received", shall send a CONNECT message and enter the CC-state U8, "Connect Request".

## 10.1.3.4.2 Incoming call / U7 call received / termination requested by the user

## 10.1.3.4.2.1 Definition

The call control entity of the UE being in the state, U7, a user requests to terminate incoming call. This test is applicable for any equipment supporting at least one mobile terminating circuit switched basic service for which immediate connect is not used.

## 10.1.3.4.2.2 Conformance requirement

- 1) A CC entity of a UE in CC-state U7, "Call Received", upon request by the user to terminate shall send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

## References

TS 24.007 clause 6.2.2., TS 24.008 clause 5.4.3.

## 10.1.3.4.2.3 Test purpose

To verify that a CC entity of a UE in CC-state U7, "Call Received", upon request by the user to terminate will send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

## 10.1.3.4.2.4 Method of test

## Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U7 by using table 10.1.3/1.

## Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U7. The user initiates clearing the incoming call. The UE sends a DISCONNECT message. The SS checks by using the status enquiry procedure that the CC entity has entered state U11, disconnect request.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				the UE is made to terminate/reject the call  cause 30#, state U11
2	->		DISCONNECT	
3	<-		STATUS ENQUIRY	
4	->		STATUS	

## Specific message contents:

None.

## 10.1.3.4.2.5 Test requirements

After step 1 a CC entity of a UE in CC-state U7, "Call Received", shall send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

### 10.1.3.4.3 Incoming call / U7 call received / DISCONNECT received

#### 10.1.3.4.3.1 Definition

The call control entity of the UE being in the state, U7, a DISCONNECT message is received by the UE. This test is applicable for any equipment supporting at least one mobile terminating circuit switched basic service for which immediate connect is not used.

#### 10.1.3.4.3.2 Conformance requirement

- 1) A CC entity of a UE in CC-state U7, "Call Received", upon receipt of a DISCONNECT with a progress indicator indicating in-band information from network, if a DTCH was not assigned, shall return a RELEASE message and enter the CC-state U19, "Release Request".

#### References

TS 24.008 clause 5.4.4.

#### 10.1.3.4.3.3 Test purpose

To verify that a CC entity of a UE in CC-state U7, "Call Received", upon receipt of a DISCONNECT with a progress indicator indicating in-band information from network, if a DTCH was not assigned, returns a RELEASE message and enters the CC-state U19, "Release Request".

#### 10.1.3.4.3.4 Method of test

#### Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U7 by using table 10.1.3/1.

#### Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U7. The SS sends a DISCONNECT message. The UE responds with a RELEASE message. The SS checks by using the status enquiry procedure that the CC entity has entered state U19, release request.



Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		DISCONNECT	(note)  cause 30#, state U19
2	->		RELEASE	
3	<-		STATUS ENQUIRY	
4	->		STATUS	

Specific message contents:

NOTE: With a progress indicator indicating in-band information; Progress Indicator, Progress Description #8.

#### 10.1.3.4.3.5 Test requirements

After step 1 a CC entity of a UE in CC-state U7, "Call Received", if a DTCH was not assigned, shall return a RELEASE message and enter the CC-state U19, "Release Request".

#### 10.1.3.4.4 Incoming call / U7 call received / RELEASE received

##### 10.1.3.4.4.1 Definition

The call control entity of the UE being in the state, U7, a RELEASE message is received by the UE. This test is applicable for any equipment supporting at least one mobile terminating circuit switched basic service for which immediate connect is not used.

##### 10.1.3.4.4.2 Conformance requirement

- 1) A CC entity of a UE in CC-state U7, "Call Received", upon receipt of a RELEASE shall return a RELEASE COMPLETE and enter the CC-state U0, "Null".
- 2) On returning to the idle mode the UE shall release the MM-connection and the CC-entities relating to the seven mobile terminating transaction identifiers shall be in CC-state U0, "Null".

#### References

Conformance requirement 1: TS 24.008 clause 5.4.4.

Conformance requirement 2: TS 24.008 clause 4.5.3., TS 24.008 clause 5.5.3.2.

##### 10.1.3.4.4.3 Test purpose

- 1) To verify that a CC entity of a UE in CC-state U7, "Call Received", upon receipt of a RELEASE will return a RELEASE COMPLETE and enter the CC-state U0, "Null".
- 2) To verify that the UE on returning to the idle mode releases the MM-connection and that the CC-entities relating to the seven mobile terminating transaction identifiers are in CC-state U0, "Null".

##### 10.1.3.4.4.4 Method of test

#### Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U7 by using table 10.1.3/1.

#### Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U7. The SS sends a RELEASE message. The UE responds with a RELEASE COMPLETE message. The SS checks by using the status enquiry procedure that the CC entity has entered state U0, null, with the relevant transaction identifiers.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		RELEASE	with cause "Normal, unspecified"
2	->		RELEASE COMPLETE	
3	<-		STATUS ENQUIRY	
4	->		RELEASE COMPLETE	
5		SS		
6	<-		RRC CONNECTION RELEASE	cause 81# (invalid TI value) repeat steps 3-4 to cover all the transaction identifiers from 000...110 the main signalling link shall be released.
7	->		RRC CONNECTION RELEASE COMPLETE	

Specific message contents:

None.

#### 10.1.3.4.4.5 Test requirements

After step 1 a CC entity of a UE in CC-state U7, "Call Received", shall return a RELEASE COMPLETE message.

After step 3 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

#### 10.1.3.4.5 Incoming call / U7 call received / lower layer failure

##### 10.1.3.4.5.1 Definition

The call control entity of the UE being in the state, U7, a lower layer failure is accomplished at the UE and consequently, communication at layer 3 level with the peer entity is terminated. This test is applicable for any equipment supporting at least one mobile terminating circuit switched basic service for which immediate connect is not used.

##### 10.1.3.4.5.2 Conformance requirement

- 1) A CC entity of a UE in CC-state U7, "Call Received", having detected a lower layer failure shall return to idle mode with the CC entities relating to the seven mobile terminating transaction identifiers in CC-state U0, "Null".

#### References

TS 24.008 clause 4.5.2.3., TS 24.008 clause 4.5.3., TS 24.008 clause 5.5.3.2., TS 24.008 clause 8.3.

### 10.1.3.4.5.3 Test purpose

To verify that a CC entity of a UE in CC-state U7, "Call Received", having detected a lower layer failure returns to idle mode with the CC entities relating to the seven mobile terminating transaction identifiers in CC-state U0, "Null".

### 10.1.3.4.5.4 Method of test

#### Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U7 by using table 10.1.3/2.

#### Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The UE is brought to the state U7. The SS generates a lower layer failure at the UE. The SS waits long enough to enable the UE to return to idle state listening to paging, and then pages UE to create RRC connection. Finally, the SS will check the state of the UE by using STATUS ENQUIRY with the relevant transaction identifiers.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		SS generates lower layer failure SS waits 20 s for the UE to return to listening to paging See TS34.108
2		SS		
3			SS Initiated Establishment of RRC Connection	
4	<-		STATUS ENQUIRY	cause 81# (invalid TI value) repeat steps 4-5 to cover all the transaction identifiers from 000...110 the main signalling link shall be released.
5	->		RELEASE COMPLETE	
6		SS		
7	<-		RRC CONNECTION RELEASE	
8	->		RRC CONNECTION RELEASE COMPLETE	

#### Specific message contents:

None.

### 10.1.3.4.5.5 Test requirements

After step 4 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

### 10.1.3.4.6 Incoming call / U7 call received / unknown message received

#### 10.1.3.4.6.1 Definition

The call control entity of the UE being in the state, U7, an unknown message is received by the UE. This test is applicable for any equipment supporting at least one mobile terminating circuit switched basic service for which immediate connect is not used.

#### 10.1.3.4.6.2 Conformance requirement

- 1) A CC entity of a UE in CC-state U7, "Call Received", having received an unknown message from its peer entity shall return a STATUS message.

#### References

TS 24.008 clause 8.4.

#### 10.1.3.4.6.3 Test purpose

To verify that a CC entity of a UE in CC-state U7, "Call Received", having received an unknown message from its peer entity returns a STATUS message.

#### 10.1.3.4.6.4 Method of test

#### Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U7 by using table 10.1.3/1.

#### Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U7. The SS sends a message with message type not defined for the protocol discriminator to the UE. The UE shall respond with a STATUS message, and finally the SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		unknown message	message type not defined for PD
2	->		STATUS	cause 97#, state U7
3	<-		STATUS ENQUIRY	
4	->		STATUS	cause 30#, state U7

Specific message contents:

None.

#### 10.1.3.4.6.5 Test requirements

After step 1 a CC entity of a UE in CC-state U7, "Call Received", shall return a STATUS message.

#### 10.1.3.4.7 Incoming call / U7 call received / DTCH assignment

##### 10.1.3.4.7.1 Definition

The call control entity of the UE being in the state, U7, a radio bearer establishment procedure is performed for traffic channel. This test is applicable for any equipment supporting at least one mobile terminating circuit switched basic service for which immediate connect is not used.

##### 10.1.3.4.7.2 Conformance requirement

- 1) A CC entity of a UE in CC-state U7, "Call Received", when a traffic channel is allocated by the network performing the radio bearer establishment procedure, shall stay in CC-state U7.

#### References

TS25.331 clause 8.2.1, TS 24.008 clause 5.2.2.7.

##### 10.1.3.4.7.3 Test purpose

To verify that a CC entity of a UE in CC-state U7, "Call Received", when a traffic channel is allocated by the network performing the radio bearer establishment procedure, stays in CC-state U7.

##### 10.1.3.4.7.4 Method of test

#### Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U7 by using table 10.1.3/1.

#### Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U7. The SS sends a RADIO BEARER SETUP for traffic channel to the UE. The UE shall respond with a RADIO BEARER SETUP COMPLETE message. The SS verifies by using the status enquiry procedure that the state of the CC entity has remained unchanged.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			Radio Bearer Setup Procedure	DTCH, See TS34.108 cause 30#, state U7
2		<-	STATUS ENQUIRY	
3		->	STATUS	

Specific message contents:

None.

#### 10.1.3.4.7.5 Test requirements

After step 1 the CC state U7, "Call Received", shall remain unchanged.

#### 10.1.3.4.8 Incoming call / U7 call received / RELEASE COMPLETE received

##### 10.1.3.4.8.1 Definition

The call control entity of the UE being in the state, U7, the call is cleared by a RELEASE COMPLETE message sent by the SS. This test is applicable for any equipment supporting at least one mobile terminating circuit switched basic service, for which immediate connect is not used.

##### 10.1.3.4.8.2 Conformance requirement

- 1) A CC entity of the UE in CC-state U7, "call received", upon receipt of a RELEASE COMPLETE message with valid cause value, shall enter CC state U0, "Null".
- 2) On returning to idle mode, the CC entities relating to the seven mobile terminating transaction identifiers shall be in state U0, "Null".

#### References

Conformance requirement 1: TS 24.008, clause 5.4.2, TS 24.008, clause 5.4.4.

Conformance requirement 2: TS 24.008, clause 5.4.4.1.3.

##### 10.1.3.4.8.3 Test purpose

- 1) To verify that a CC entity of the UE in CC-state U7, "Call received", upon receipt of a RELEASE COMPLETE message with valid cause value, enters CC state U0, "Null".
- 2) To verify that in returning to idle mode, the CC entities relating to the seven mobile terminating transaction identifiers are in state U0, "Null".

##### 10.1.3.4.8.4 Method of test

#### Related ICS/IXIT statements

- supported MT circuit switched basic services;

MT circuit switched basic services for which immediate connect is not used.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U7 by using table 10.1.3/1.

### Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected service is telephony. If necessary, the UE is configured for that basic service. The mobile terminated call is initiated. the CC entity of the UE is brought to U7. The SS sends a RELEASE COMPLETE message to the UE. The SS checks by using the status enquiry procedure that the CC entity has entered the state U0 with all the relevant transaction identifiers.

### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		<-	RELEASE COMPLETE	note 1
2		<-	STATUS ENQUIRY	
3		->	RELEASE COMPLETE	
4		SS		cause 81# (invalid TI value), note 2
5		<-	RRC CONNECTION RELEASE	repeat steps 2-3 to cover all the transaction identifiers from 000...110
6		->	RRC CONNECTION RELEASE COMPLETE	the main signalling link shall be released.

### Specific message contents:

NOTE 1: With the cause value chosen arbitrarily.

NOTE 2: TI flag has the value indicating the SS as a originator of the call.

### 10.1.3.4.8.5 Test requirements

After step 2 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

### 10.1.3.5 Incoming call / U8 connect request

#### 10.1.3.5.1 Incoming call / U8 connect request / CONNECT acknowledged

##### 10.1.3.5.1.1 Definition

The call control entity of the UE being in the state, U8, a CONNECT ACKNOWLEDGE message is received by the UE. This test is applicable for any equipment supporting at least one mobile terminating circuit switched basic service.

##### 10.1.3.5.1.2 Conformance requirement

A CC entity of a UE in CC-state U8, "Connect Request", upon receipt of CONNECT ACKNOWLEDGE shall enter the CC-state U10, "Call Active".

### References

TS 24.008 clause 5.2.2.6.

### 10.1.3.5.1.3 Test purpose

To verify that a CC entity of a UE in CC-state U8, "Connect Request", upon receipt of CONNECT ACKNOWLEDGE shall enter the CC-state U10, "Call Active".

### 10.1.3.5.1.4 Method of test

#### Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U8 by using table 10.1.3/2.

#### Test procedure

An MT circuit switched basic service is selected that is supported by the UE; if the UE supports MT telephony, the selected basic service is telephony. If necessary the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U8 (if the UE uses immediate connection for the selected basic service then p = Y, otherwise p = N). The SS sends a CONNECT ACKNOWLEDGE message. The SS checks by using the status enquiry procedure that the CC entity of the UE has entered state U10, active.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
A1			Radio Bearer Setup Procedure	p = Y, See TS34.108
2	<-		CONNECT ACKNOWLEDGE	cause 30#, state U10
3	<-		STATUS ENQUIRY	
4	->		STATUS	

#### Specific message contents:

None.

### 10.1.3.5.1.5 Test requirements

After step 2 a CC entity of a UE in CC-state U8, "Connect Request", shall enter the CC-state U10, "Call Active".

### 10.1.3.5.2 Incoming call / U8 connect request / timer T313 time-out

#### 10.1.3.5.2.1 Definition

The call control entity of the UE being in the state, U8, if no response is then received from the SS, timer T313 expires at the UE side. This test is applicable for any equipment supporting at least one mobile terminating circuit switched basic service.



#### 10.1.3.5.2.2 Conformance requirement

A CC entity of a UE in CC-state U8, "Connect Request", having waited for a reasonable length of time (e.g. expiry of timer T313) without receiving the appropriate protocol message to complete the incoming call, shall initiate the clearing of that incoming call by sending the CC message DISCONNECT and enter the CC-state U11, "Disconnect Request".

If an UE disconnects too early then, in the case of very late assignment of a traffic channel, systematic waste of radio resources may occur.

#### References

TS 24.008 clause 5.2.2.6., TS 24.008 clause 5.4.3.

#### 10.1.3.5.2.3 Test purpose

To verify that a CC entity of a UE in CC-state U8, "Connect Request", having waited for a reasonable length of time (e.g. expiry of timer T313) without receiving the appropriate protocol message to complete the incoming call, shall initiate the clearing of that incoming call by sending the CC message DISCONNECT and enter the CC-state U11, "Disconnect Request"

#### 10.1.3.5.2.4 Method of test

#### Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U8 by using table 10.1.3/2.

#### Test procedure

An MT circuit switched basic service is selected that is supported by the UE; if the UE supports MT telephony, the selected basic service is telephony. If necessary the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U8 (if the UE uses immediate connection for the selected basic service then p = Y, otherwise p = N). The T313 expires at the UE and the UE sends a DISCONNECT message and enters state U11, disconnect request. The SS checks by using the status enquiry procedure that the UE has entered the correct state.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
A1			Radio Bearer Setup Procedure	p = Y, See TS34.108
2		->	DISCONNECT	Shall not be sent before 15 seconds after entry into state U8. But, shall be sent before 1,1 * T313 after entry into state U8. cause 30#, state U11
3		<-	STATUS ENQUIRY	
4		->	STATUS	

Specific message contents:

None.

#### 10.1.3.5.2.5 Test requirements

Upon expiry of timer T313 without receiving the appropriate protocol message to complete the incoming call a CC entity of a UE in CC-state U8, "Connect Request", shall initiate the clearing of that incoming call by sending a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

#### 10.1.3.5.3 Incoming call / U8 connect request / termination requested by the user

##### 10.1.3.5.3.1 Definition

The call control entity of the UE being in the state, U10, the user requests for releasing of the call. This test is applicable for any equipment supporting at least one mobile terminating circuit switched basic service.

##### 10.1.3.5.3.2 Conformance requirement

- 1) A CC entity of a UE in CC-state U8, "Connect Request", upon request by the user to terminate shall send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

#### References

TS 24.007 clause 6.2.2., TS 24.008 clause 5.4.3.

##### 10.1.3.5.3.3 Test purpose

To verify that a CC entity of a UE in CC-state U8, "Connect Request", upon request by the user to terminate will send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

##### 10.1.3.5.3.4 Method of test

#### Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U8 by using table 10.1.3/2.

### Test procedure

An MT circuit switched basic service is selected that is supported by the UE; if the UE supports MT telephony, the selected basic service is telephony. If necessary the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U8 (if the UE uses immediate connection for the selected basic service then p = Y, otherwise p = N). Then the user requests termination of the call. The UE sends a DISCONNECT message and enters state U11, disconnect request. The SS verifies by using the status enquiry procedure that the UE has entered the correct state.

### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
A1			Radio Bearer Setup Procedure	p = Y, See TS34.108
2				the user requests to clear the call  cause 30#, state U11
3	->		DISCONNECT	
4	<-		STATUS ENQUIRY	
5	->		STATUS	

### Specific message contents:

None.

### 10.1.3.5.3.5 Test requirements

After step 2 a CC entity of a UE in CC-state U8, "Connect Request", shall send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

### 10.1.3.5.4 Incoming call / U8 connect request / DISCONNECT received with in-band information

#### 10.1.3.5.4.1 Definition

The call control entity of the UE being in the state, U8, a DISCONNECT message indicating availability of in band information is received by the UE. This test is applicable for any equipment supporting at least one mobile terminating circuit switched basic service.

#### 10.1.3.5.4.2 Conformance requirement

A CC entity of a UE in CC-state U8, "Connect Request", upon receipt of a DISCONNECT with progress indicator #8 shall enter CC-state U12, if the traffic channel is in speech mode. If the DTCH is not in speech mode, the UE shall send a RELEASE message and enter CC-state U19.

### References

TS 24.008 clause 5.4.4., TS 24.008 clause 5.5.1.

### 10.1.3.5.4.3 Test purpose

To verify that a CC entity of a UE in CC-state U8, "Connect Request", upon receipt of a DISCONNECT with progress indicator #8 enters CC-state U12, if the traffic channel is in speech mode, and that the UE sends a RELEASE message and enters CC-state U19 if the DTCH is not in speech mode.

## 10.1.3.5.4.4 Method of test

## Related ICS/IXIT statements

- supported MT circuit switched basic services.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U8 by using table 10.1.3/4.

## Test procedure

An MT circuit switched basic service is selected that is supported by the UE; if the UE supports MT telephony, the selected basic service is telephony. If necessary the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U8. The SS sends a DISCONNECT message containing indication of in-band information availability to the UE. If channel mode is speech, the UE enters state U12, disconnect indication. If channel mode is not speech, the UE sends a RELEASE message and enters state U19, release request.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		DISCONNECT	(note)
A2	<-		STATUS ENQUIRY	DTCH in speech mode:
A3	->		STATUS	cause 30#, state U12
B2	->		RELEASE	DTCH is not in speech mode:
B3	<-		STATUS ENQUIRY	cause 30#, state U19
B4	->		STATUS	

## Specific message contents:

NOTE: With a progress indicator indicating in-band information; Progress Indicator, Progress description #8.

## 10.1.3.5.4.5 Test requirements

After step 1 a CC entity of a UE in CC-state U8, "Connect Request", shall enter CC-state U12, if the traffic channel is in speech mode. If the DTCH is not in speech mode, the UE shall send a RELEASE message and enter CC-state U19.

## 10.1.3.5.5 Incoming call / U8 connect request / DISCONNECT received without in-band information

## 10.1.3.5.5.1 Definition

The call control entity of the UE being in the state, U8, a DISCONNECT message is received by the UE. The DISCONNECT message does not contain indication of in-band information availability. This test is applicable for any equipment supporting at least one mobile terminating circuit switched basic service.

#### 10.1.3.5.5.2 Conformance requirement

- 1) A CC entity of a UE in CC-state U8, "Connect Request", upon receipt of a DISCONNECT without progress indicator, shall return a RELEASE message and enter the CC-state U19, "Release Request".

#### References

TS 24.008 clause 5.4.4., TS 24.008 clause 5.4.4.1.2.

#### 10.1.3.5.5.3 Test purpose

To verify that a CC entity of a UE in CC-state U8, "Connect Request", upon receipt of a DISCONNECT without progress indicator, returns a RELEASE message and enters the CC-state U19, "Release Request".

#### 10.1.3.5.5.4 Method of test

#### Related ICS/IXIT statements

- supported MT circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U8 by using table 10.1.3/4.

#### Test procedure

An MT circuit switched basic service is selected that is supported by the UE; if the UE supports MT telephony, the selected basic service is telephony. If necessary the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U8. The SS sends a DISCONNECT message not containing indication of in-band information availability to the UE. The UE shall respond with a RELEASE message. The SS checks by using the status enquiry procedure that the CC entity of the UE has entered the state U19, release request.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		<-	DISCONNECT	(note) cause 30#, state U19
2		->	RELEASE	
3		<-	STATUS ENQUIRY	
4		->	STATUS	

#### Specific message contents:

NOTE: Without a progress indicator indicating in-band information.

#### 10.1.3.5.5.5 Test requirements

After step 1 a CC entity of a UE in CC-state U8, "Connect Request", shall return a RELEASE message and enter the CC-state U19, "Release Request".

### 10.1.3.5.6 Incoming call / U8 connect request / RELEASE received

#### 10.1.3.5.6.1 Definition

The call control entity of the UE being in the state, U8, a RELEASE message is received by the UE. This test is applicable for any equipment supporting at least one mobile terminating circuit switched basic service.

#### 10.1.3.5.6.2 Conformance requirement

- 1) A CC entity of a UE in CC-state U8, "Connect Request", upon receipt of a RELEASE shall return a RELEASE COMPLETE and enter the CC-state U0, "Null".
- 2) On returning to the idle mode the UE shall release the MM-connection and the CC-entities relating to the seven mobile terminating transaction identifiers shall be in CC-state U0, "Null".

#### References

Conformance requirement 1: TS 24.008 clause 5.4.4.

Conformance requirement 2: TS 24.008 clause 4.5.3., TS 24.008 clause 5.5.3.2.

#### 10.1.3.5.6.3 Test purpose

- 1) To verify that a CC entity of a UE in CC-state U8, "Connect Request", upon receipt of a RELEASE will return a RELEASE COMPLETE and enter the CC-state U0, "Null".
- 2) To verify that the UE on returning to the idle mode releases the MM-connection and that the CC-entities relating to the seven mobile terminating transaction identifiers are in CC-state U0, "Null".

#### 10.1.3.5.6.4 Method of test

#### Related ICS/IXIT statements

- supported MT circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U8 by using table 10.1.3/1.

#### Test procedure

An MT circuit switched basic service is selected that is supported by the UE; if the UE supports MT telephony, the selected basic service is telephony. If necessary the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U8. The SS sends a RELEASE message. The UE responds with a RELEASE COMPLETE message. The SS checks by using the status enquiry procedure that the CC entity has entered state U0, null, with the relevant transaction identifiers.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		RELEASE	with cause "Normal, unspecified"
2	->		RELEASE COMPLETE	
3	<-		STATUS ENQUIRY	
4	->		RELEASE COMPLETE	
5		SS		
6	<-		RRC CONNECTION RELEASE	cause 81# (invalid TI value) repeat steps 3-4 to cover all the transaction identifiers from 000...110 the main signalling link shall be released.
7	->		RRC CONNECTION RELEASE COMPLETE	

Specific message contents:

None.

#### 10.1.3.5.6.5 Test requirements

After step 1 a CC entity of a UE in CC-state U8, "Connect Request", shall return a RELEASE COMPLETE message.

After step 3 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

#### 10.1.3.5.7 Incoming call / U8 connect request / lower layer failure

##### 10.1.3.5.7.1 Definition

The call control entity of the UE being in the state, U8, a lower layer failure is accomplished at the UE and consequently, communication at layer 3 level with the peer entity is terminated. This test is applicable for any equipment supporting at least one mobile terminating circuit switched basic service.

##### 10.1.3.5.7.2 Conformance requirement

- 1) A CC entity of a UE in CC-state U8, "Connect Request", having detected a lower layer failure shall return to idle mode with the CC entities relating to the seven mobile terminating transaction identifiers in CC-state U0, "Null".

#### References

TS 24.008 clause 4.5.2.3., TS 24.008 clause 4.5.3., TS 24.008 clause 5.5.3.2.

##### 10.1.3.5.7.3 Test purpose

To verify that a CC entity of a UE in CC-state U8, "Connect Request", having detected a lower layer failure returns to idle mode with the CC entities relating to the seven mobile terminating transaction identifiers in CC-state U0, "Null".

##### 10.1.3.5.7.4 Method of test

#### Related ICS/IXIT statements

- supported MT circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U8 by using table 10.1.3/1.

### Test procedure

An MT circuit switched basic service is selected that is supported by the UE; if the UE supports MT telephony, the selected basic service is telephony. If necessary the UE is configured for that basic service. Then a mobile terminated call is initiated. The UE is brought to the state U8. The SS generates a lower layer failure at the UE. The SS waits long enough to enable the UE to return to idle state listening to paging, and then pages UE to create RRC connection. Finally, the SS will check the state of the UE by using STATUS ENQUIRY with the relevant transaction identifiers.

### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		SS generates lower layer failure
2		SS		SS waits 20 s for the UE to return to listening to paging
3		<-	SS Initiated Establishment of RRC Connection	See TS34.108
4		<-	STATUS ENQUIRY	
5		->	RELEASE COMPLETE	cause 81# (invalid TI value)
6		SS		repeat steps 4-5 to cover all the transaction identifiers from 000...110
7		<-	RRC CONNECTION RELEASE	the main signalling link shall be released.
8		->	RRC CONNECTION RELEASE COMPLETE	

Specific message contents:

None.

#### 10.1.3.5.7.5 Test requirements

After step 4 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

#### 10.1.3.5.8 Incoming call / U8 connect request / DTCH assignment

##### 10.1.3.5.8.1 Definition

The call control entity of the UE being in the state, U8, a radio bearer establishment procedure is performed for traffic channel. This test is applicable for any equipment supporting at least one mobile terminating circuit switched basic service.

##### 10.1.3.5.8.2 Conformance requirement

- 1) A CC entity of a UE in CC-state U8, "Connect Request", when a traffic channel is allocated by the network performing the radio bearer establishment procedure, shall stay in the CC-state U8.

### References

TS 25.331 clause 8.2.1., TS 24.008 clause 5.2.2.7.



### 10.1.3.5.8.3 Test purpose

To verify that a CC entity of a UE in CC-state U8, "Connect Request", when a traffic channel is allocated by the network performing the radio bearer establishment procedure, stays in the CC-state U8.s

### 10.1.3.5.8.4 Method of test

#### Related ICS/IXIT statements

- supported MT circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U8 by using table 10.1.3/1.

#### Test procedure

An MT circuit switched basic service is selected that is supported by the UE; if the UE supports MT telephony, the selected basic service is telephony. If necessary the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U8. The SS sends a RADIO BEARER SETUP for traffic channel to the UE. The UE shall respond with a RADIO BEARER SETUP COMPLETE message. The SS verifies by using the status enquiry procedure that the state of the CC entity has remained unchanged.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			Radio Bearer Setup Procedure	DTCH, See TS34.108
2	<-		STATUS ENQUIRY	
3		->	STATUS	cause 30#, state U8

#### Specific message contents:

None.

### 10.1.3.5.8.5 Test requirements

After step 1 the CC-state U8, "Connect Request", shall remain unchanged.

### 10.1.3.5.9 Incoming call / U8 connect request / unknown message received

#### 10.1.3.5.9.1 Definition

The call control entity of the UE being in the state, U8, an unknown message is received by the UE. This test is applicable for any equipment supporting at least one mobile terminating circuit switched basic service.

#### 10.1.3.5.9.2 Conformance requirement

- 1) A CC entity of a UE in CC-state U8, "Connect Request", having received an unknown message from its peer entity shall return a STATUS message.

## References

TS 24.008 clause 8.4.

### 10.1.3.5.9.3 Test purpose

To verify that a CC entity of a UE in CC-state U8, "Connect Request", having received an unknown message from its peer entity returns a STATUS message.

### 10.1.3.5.9.4 Method of test

## Related ICS/IXIT statements

- supported MT circuit switched basic services.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U8 by using table 10.1.3/1.

## Test procedure

An MT circuit switched basic service is selected that is supported by the UE; if the UE supports MT telephony, the selected basic service is telephony. If necessary the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U8. The SS sends a message with message type not defined for the protocol discriminator to the UE. The UE shall respond with a STATUS message, and finally the SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		<-	unknown message	message type not defined for PD cause 97#, state U8
2		->	STATUS	
3		<-	STATUS ENQUIRY	cause 30#, state U8
4		->	STATUS	

## Specific message contents:

None.

### 10.1.3.5.9.5 Test requirements

After step 1 a CC entity of a UE in CC-state U8, "Connect Request", shall return a STATUS message.

## 10.1.4 In call functions

### 10.1.4.1 In-call functions / DTMF information transfer

#### 10.1.4.1.1 In-call functions / DTMF information transfer / basic procedures

##### 10.1.4.1.1.1 Definition

Dual Tone Multi Frequency (DTMF) is an inband one out of four plus one out of four signalling system primarily used from terminal instruments in telecommunication networks. This test is applicable for any equipment supporting bearer capability for speech.

##### 10.1.4.1.1.2 Conformance requirement

- 1) An UE supporting the Mobile originating DTMF protocol control procedure, having a CC entity for speech in state U10, "Active": when made to send a DTMF tone, shall send a START DTMF message on the correct DCCH.
- 2) An UE supporting the Mobile originating DTMF protocol control procedure, having a CC entity for speech in state U10, "Active": when made to send a DTMF tone (the corresponding IA5 character being selected from among the ones supported), shall send a START DTMF message specifying the correct IA5 character in the "keypad information" field of the keypad facility information element.

#### References

TS 24.008 clause 5.5.7.

##### 10.1.4.1.1.3 Test purpose

- 1) To verify that an UE supporting the Mobile originating DTMF protocol control procedure, having a CC entity for speech in state U10, "Active": when made to send a DTMF tone, sends a START DTMF message on the correct DCCH.
- 2) To verify that an UE supporting the Mobile originating DTMF protocol control procedure, having a CC entity for speech in state U10, "Active": when made to send a DTMF tone (the corresponding IA5 character being selected from among the ones supported), sends a START DTMF message specifying the correct IA5 character in the "keypad information" field of the keypad facility information element.

##### 10.1.4.1.1.4 Method of test

#### Related ICS/IXIT statements

- supported teleservices;
- supported character set (e.g. 0-9, #, \*, A, B, C, D);
- if and how DTMF tone is indicated to the user.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is brought into the state U10 "Active" for speech by using Generic call setup procedure for mobile originating circuit switched call defined in TS34.108.

## Test procedure

The UE being in the call active state, a user causes a DTMF tone to be generated e.g. by depression of a key in the UE. A DTMF digit corresponding to the digit indicated by the user is sent in a START DTMF message by the UE. The SS will return a START DTMF ACKNOWLEDGE message to the UE. This acknowledgement may be used in the UE to generate an indication as a feedback for a successful transmission. Then the user indicates that the DTMF sending should cease e.g. by releasing the key. The UE will send a STOP DTMF message to the network which is acknowledged with STOP DTMF ACKNOWLEDGE by the SS.

The sequence described above is repeated for each of the applicable characters 0-9, #, \*, A, B, C, and D.

Then a case of rejecting a DTMF tone is tested and the state of the UE is verified.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	->	SS	START DTMF	the user causes DTMF tone to be generated the SS will verify that the transmitted information corresponds to the digit pressed
2	<-		START DTMF ACKNOWLEDGE	possible indication of a DTMF tone depending the ICS/IXIT statements
3	<-		STATUS ENQUIRY	
4	->		STATUS	cause 30#, state U10
5	->		STOP DTMF	
6	<-		STOP DTMF ACKNOWLEDGE	the DTMF tone indication shall be stopped
7				the steps 1-4 shall be repeated for each of the applicable characters 0-9, #, *, A, B, C, D.
8	<-		STATUS ENQUIRY	
9	->		STATUS	cause 30#, state U10
10	->		START DTMF	
11	<-		START DTMF REJECT	
12	<-		STATUS ENQUIRY	
13	->		STATUS	cause 30#, state U10

## Specific message contents:

None.

### 10.1.4.1.1.5 Test requirements

Upon a user making to send a DTMF tone a CC entity for speech in the CC state U10, "Active", shall send a START DTMF message on the DCCH to SS.

The SS will verify that the transmitted information corresponds to the digit pressed in the UE.

After step 7 (successful DTMF transmission) the CC-state U10, "Active", shall remain unchanged.

After step 11 (unsuccessful DTMF transmission) the CC-state U10, "Active", shall remain unchanged.

### 10.1.4.2 In-call functions / user notification

User notification procedure allows the network to notify a UE of any call-related event during the "active" state of a call. It also may allow a UE to notify the remote user of any appropriate call-related event during the "active" state of a call by sending a NOTIFY message containing a notification indicator to the network. No state change occurs at any of the interface sides during this procedure.

#### 10.1.4.2.1 In-call functions / User notification / UE terminated

##### 10.1.4.2.1.1 Definition

This is a case for testing user notification procedure terminated by the user equipment. The test is applicable for those equipments supporting at least one circuit switched basic service.

##### 10.1.4.2.1.2 Conformance requirement

- 1) A CC entity of a UE in CC-state U10, "active", upon receiving of a NOTIFY message shall remain in the active state.

#### References

TS 24.008 clause 5.3.1.

##### 10.1.4.2.1.3 Test purpose

To verify that a CC entity of a UE in CC-state U10, "active", upon receiving of a NOTIFY message remains in the active state.

##### 10.1.4.2.1.4 Method of test

#### Related ICS/IXIT statements

- supported circuit switched basic services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U10 "Active" by using Generic call setup procedure for mobile originating circuit switched calls defined in TS34.108.

#### Test procedure

The UE being in the call active state, the SS will send a NOTIFY message to the UE. The state of the UE is checked after that.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		<-	NOTIFY	cause 30#, state U10
2		<-	STATUS ENQUIRY	
3		->	STATUS	

#### Specific message contents:

None.

#### 10.1.4.2.1.5 Test requirements

After step 1 a CC entity of the UE in the CC-state U10, "active", shall remain in the active state.

#### 10.1.4.3 In-call functions / channel changes

The two following test cases are for testing some elementary radio resource level procedures during an active state of a call to ensure call maintenance also during Hard handover.

##### 10.1.4.3.1 In-call functions / channel changes / a successful channel change in active state/ Hard handover

###### 10.1.4.3.1.1 Definition

This is a case to test a change of the frequency of a physical channel during active state of a call. This test is applicable for any equipment supporting at least one mobile terminating circuit switched basic service.

###### 10.1.4.3.1.2 Conformance requirement

- 1) The UE being in the call active state after having successfully completed a physical channel reconfiguration, shall remain in the call active state.

#### References

TS 24.008 clause 5.3.4.3.2, and TS 25.331 clause 8.3.5.

###### 10.1.4.3.1.3 Test purpose

To verify that the UE being in the call active state after having successfully completed a physical channel reconfiguration remains in the call active state.

###### 10.1.4.3.1.4 Method of test

#### Related ICS/IXIT statements

- supported MT circuit switched basic services;

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U10 "Active" by using Generic call setup procedure for mobile originating circuit switched calls defined in TS34.108.

#### Test procedure

The UE being in the call active state, the SS initiated physical channel reconfiguration procedure causing an intracell change of channel by sending a PHYSICAL CHANNEL RECONFIGURATION message to the UE. The UE performs physical channel reconfiguration procedure and after the main signalling link is successfully established, the UE returns a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH using AM RLC. The state of the UE is then checked.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		PHYSICAL CHANNEL RECONFIGURATION	cause 30#, state U10
2	->		PHYSICAL CHANNEL RECONFIGURATION COMPLETE	
3	<-		STATUS ENQUIRY	
4	->		STATUS	

Specific message contents:

None.

#### 10.1.4.3.1.5 Test requirements

The UE being in the call active state after having successfully completed a physical channel reconfiguration, shall remain in the call active state.

#### 10.1.4.3.2 In-call functions / channel changes / an unsuccessful channel change in active mode/Hard handover

##### 10.1.4.3.2.1 Definition

This is a case to test an unsuccessful change of the frequency of a physical channel during active state of a call. This test is applicable for any equipment supporting at least one mobile terminating circuit switched basic service.

##### 10.1.4.3.2.2 Conformance requirement

- 1) The UE, when returning to the old channel after physical channel reconfiguration failure, shall remain in the call active state.

#### References

TS 24.008 clause 5.3.4.3.

##### 10.1.4.3.2.3 Test purpose

To verify that the UE, when returning to the old channel after physical channel reconfiguration failure, will remain in the call active state.

##### 10.1.4.3.2.4 Method of test

#### Related ICS/IXIT statements

- supported MT circuit switched basic services;

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U10 "Active" by using Generic call setup procedure for mobile originating circuit switched calls defined in TS34.108.

### Test procedure

The SS sends a PHYSICAL CHANNEL RECONFIGURATION message, but does not activate the assigned physical channel. The UE shall attempt try to activate the new channel (this is not verified) and shall then reactivate the "old" channel. The UE shall send a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC and shall set the cause value in IE "failure cause" to "physical channel failure". The state of the UE is then checked.

### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		<-	PHYSICAL CHANNEL RECONFIGURATION	The UE attempts and fails to re-configure the physical channel.
2		->	PHYSICAL CHANNEL RECONFIGURATION FAILURE	NOTE  cause 30#, state U10
3		<-	STATUS ENQUIRY	
4		->	STATUS	

### Specific message contents:

NOTE: With the cause value "physical channel failure".

#### 10.1.4.3.2.5 Test requirements

The UE being in the call active state after physical channel reconfiguration failure, shall remain in the call active state.

#### 10.1.4.4 In-call functions / UE terminated in-call modification

##### 10.1.4.4.1 In-call functions / UE terminated in-call modification / modify when new mode is not supported

###### 10.1.4.4.1.1 Definition

This is to test a special case of a in-call modification procedure, in which the new mode is not supported (and consequently not one of those negotiated and agreed during the establishment phase of the call). This test is applicable for any equipment supporting at least one circuit switched basic service.

###### 10.1.4.4.1.2 Conformance requirement

- 1) In the case that the UE supports the network originated in-call modification procedure, the UE after having received a MODIFY message with a new mode which is not the actual one and cannot be supported by the UE shall reject it by sending a MODIFY REJECT message or a STATUS message.
- 2) In the case that the UE does not support the network originated in-call modification procedure, the UE shall, when receiving a MODIFY message, treat the message as unknown and respond with a STATUS message.

### References

- 1) TS 24.008 clauses 5.3.4.3.4.2 and 5.3.4.4.



2) TS 24.008 clause 5.3.4.

#### 10.1.4.4.1.3 Test purpose

- 1) To verify that an UE supporting the network originated in-call modification procedure, after having received a MODIFY message with a new mode which is not the actual one and cannot be supported by the UE, rejects it by sending a MODIFY REJECT.
- 2) To verify that an UE not supporting the network originated in-call modification procedure, after having received a MODIFY message, responds with a STATUS message.

#### 10.1.4.4.1.4 Method of test

##### Related ICS/IXIT statements

- supported circuit switched basic services;
- the UE supports the network originated in-call modification procedure (p = Yes/No).

##### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U10 "Active" by using Generic call setup procedure for mobile originating circuit switched calls defined in TS34.108.

##### Test procedure

The UE being in the call active state, the SS initiates in-call modification procedure by sending a MODIFY message with new mode different from actual mode and one of those not supported by the UE. The UE either returns a MODIFY REJECT message with the old bearer capability or a STATUS message with reject cause #97, depending on the ICS/IXIT statement. The state of the UE is then checked.

##### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<-		MODIFY	with new mode different from actual one
2a	->		MODIFY REJECT	with the old call mode included OR, p = Yes
2b	->		STATUS	cause #97, state U10, p = No
3	<-		STATUS ENQUIRY	cause 30#, state U10
4	->		STATUS	

##### Specific message contents:

None.

#### 10.1.4.4.1.5 Test requirements

In the case that the UE supports the network originated in-call modification procedure, the UE after having received a MODIFY message with a new mode which is not the actual one and cannot be supported by the UE shall reject it by sending a MODIFY REJECT message and shall remain in the call active state.

In the case that the UE does not support the network originated in-call modification procedure, the UE shall, when receiving a MODIFY message, treat the message as unknown and respond with a STATUS message. The UE shall remain in the call active state.

#### 10.1.4.5 In-call functions / UE originated in-call modification

##### 10.1.4.5.1 In-call functions / UE originated in-call modification / a successful case of modifying

###### 10.1.4.5.1.1 Definition

This test is to test a successful case of in-call modification, which is triggered by the calling tone identification (CNG) received by the UE. This test is applicable for any equipment supporting any dual mode bearer capability service (Teleservice 61 - Alternate Speech/Group 3 fax).

###### 10.1.4.5.1.2 Conformance requirement

- 1) The procedure shall be initiated by the UE in the "active" state of the call. It shall send a MODIFY message including the new mode to be changed to; and enter the "mobile originating modify" state. The new mode given in the MODIFY message shall be one of those already negotiated and agreed during the establishment phase of the call. The UE shall stop sending user information according to the old mode and enter the state U26 "Mobile Originating Modify".
- 2) Upon receipt of the MODIFY COMPLETE message the UE shall start sending channel information according to the new call mode and enter the "active" state.

#### References

Conformance requirement 1: TS 24.008 clause 5.3.4.3.1.

Conformance requirement 2: TS 24.008 clause 5.3.4.3.2.

###### 10.1.4.5.1.3 Test purpose

- 1) To verify that the procedure is initiated by the UE in the "active" state of the call. It sends a MODIFY message including the new mode to be changed to; and enters the "mobile originating modify" state. The new mode given in the MODIFY message is one of those already negotiated and agreed during the establishment phase of the call. The MODIFY originating side stops sending user information.
- 2) To verify that upon receipt of the MODIFY COMPLETE message the UE starts sending channel information according to the new call mode and enters the "active" state.

###### 10.1.4.5.1.4 Method of test

#### Related ICS/IXIT statements

- a way to activate a dual mode call;
- a way to activate in-call modification;
- support of dual bearer capability services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

### Test procedure

The UE initiates a call for one of the supported dual mode services. The UE being in the call active state, in-call modification procedure is initiated for the selected service from the UE side. The UE shall send a MODIFY message with the new mode to the SS and the state of the UE is checked. The channel mode is modified with the RADIO BEARER RECONFIGURATION message including the appropriate channel mode for the new service. The SS then returns a MODIFY COMPLETE message. The state of the UE is then checked.

NOTE: ICM can be initiated by manual intervention at the UE.

### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The UE is made to initiate a dual mode call
2	->		RRC CONNECTION REQUEST	
3	<-		RRC CONNECTION SETUP	
4	->		RRC CONNECTION SETUP COMPLETE	
5	->		CM SERVICE REQUEST	
6	<-		AUTHENTICATION REQUEST	
7	->		AUTHENTICATION RESPONSE	
8	<-		SECURITY MODE COMMAND	
9	->		SECURITY MODE COMPLETE	
10	->		SETUP	as specified in specific message contents
11	<-		CALL PROCEEDING	as specified in specific message contents
12			Radio Bearer Setup Procedure	See TS34.108
13	<-		ALERTING	
14	<-		CONNECT	
15	->		CONNECT ACKNOWLEDGE	
16	->		MODIFY	as specified in specific message contents
17	<-		STATUS ENQUIRY	
18	->		STATUS	cause 30#, state U26
19	<-		RADIO BEARER RECONFIGURATION	as specified in specific message contents
20	->		RADIO BEARER RECONFIGURATION COMPLETE	
21	<-		MODIFY COMPLETE	contains the new mode as bearer capability
22	SS			allow at least 2 seconds for the UE to adapt for the new mode
23	<-		STATUS ENQUIRY	
24	->		STATUS	cause 30#, state U10
25	SS			verify that the UE starts sending user information according to the new mode

### Specific message contents:

SETUP message contains bearer capability 1 IE and bearer capability 2 IE for appropriate basic services.

CALL PROCEEDING message contains bearer capability 1 IE and bearer capability 2 IE for agreeing a dual mode call.

RADIO BEARER RECONFIGURATION message contains some IEs that is fit for BC in MODIFY message.

### 10.1.4.5.1.5 Test requirements

The UE shall send a MODIFY message including the new mode to be changed to; and enter the state U26 "Mobile Originating Modify". The new mode given in the MODIFY message shall be one of those already negotiated and

agreed during the establishment phase of the call. The UE shall stop sending user information according to the old mode.

After step 21 the UE shall start sending channel information according to the new call mode and enter the CC state U10 "Active".

#### 10.1.4.5.2 In-call functions / UE originated in-call modification / modify rejected

##### 10.1.4.5.2.1 Definition

This is to test a special case of a in-call modification procedure, in which the in-call modification is rejected. This test is applicable for any equipment supporting any dual mode bearer capability service (Teleservice 61 - Alternate Speech/Group 3 fax).

##### 10.1.4.5.2.2 Conformance requirement

- 1) Upon receipt of the MODIFY REJECT message with the old bearer capability the UE shall: resume sending user information according to the present call mode; resume interpreting received user information according to the present call mode; and enter the "active" state.

#### References

TS 24.008 clause 5.3.4.3.4.1.

##### 10.1.4.5.2.3 Test purpose

To verify that upon receipt of the MODIFY REJECT message with the old bearer capability the UE resumes sending user information according to the present call mode; resumes interpreting received user information according to the present call mode; and enters the "active" state.

##### 10.1.4.5.2.4 Method of test

#### Related ICS/IXIT statements

- supported teleservices;
- support of dual bearer capability services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

#### Test procedure

The UE initiates a call for one of the supported dual mode services. The UE being in the call active state, in-call modification procedure is initiated for the selected service from the UE side. The UE shall send a MODIFY message with new mode to the SS. The SS returns a MODIFY REJECT message. The state of the UE is then checked.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				MMI action to initiate a dual mode call Steps 2-13 of test case 10.1.4.5.1 are performed and the UE is in CC-state "Active"
2	->		MODIFY	MMI action to change the mode with cause #58 bearer capability not available and with old bearer capabilities
3	<-		MODIFY REJECT	
4	<-		STATUS ENQUIRY	cause 30#, state U10
5	->		STATUS	

Specific message contents:

None.

#### 10.1.4.5.2.5 Test requirements

After step 3 the UE shall resume sending user information according to the present call mode; resume interpreting received user information according to the present call mode; and enter the CC state U10 "Active".

#### 10.1.4.5.3 In-call functions / UE originated in-call modification / an abnormal case of acceptance

##### 10.1.4.5.3.1 Definition

This is to test a special case of a in-call modification procedure, in which the in-call modification is accepted incorrectly. This test is applicable for any equipment supporting any dual mode bearer capability service (Teleservice 61 - Alternate Speech/Group 3 fax).

##### 10.1.4.5.3.2 Conformance requirement

- 1) Upon receipt of the MODIFY COMPLETE message indicating a call mode which does not correspond to the requested one the UE shall discard it and take no action.

#### References

TS 24.008 clause 5.3.4.4.

##### 10.1.4.5.3.3 Test purpose

To verify that upon receipt of the MODIFY COMPLETE message indicating a call mode which does not correspond to the requested one the UE discards it and takes no action.

##### 10.1.4.5.3.4 Method of test

#### Related ICS/IXIT statements

- supported teleservices;
- support of dual bearer capability services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

### Test procedure

The UE initiates a call for one of the supported dual mode services. The UE being in the call active state, in-call modification procedure is initiated for the selected service from the UE side. The UE shall send a MODIFY message with new mode to the SS. The SS returns a MODIFY COMPLETE message specifying a mode that does not correspond to the requested one. It will be verified then that the UE shall not take any action and the state of the UE will be checked.

### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				MMI action to initiate a dual mode call Steps 2-13 of test case 10.1.4.5.1 are performed and the UE is in CC-state "Active"
2	->		MODIFY	MMI action to change the mode with a mode that does not correspond to the requested one
3	<-		MODIFY COMPLETE	
4	<-		STATUS ENQUIRY	cause 30#, state U26
5	->		STATUS	

### Specific message contents:

MODIFY COMPLETE message contains the Bearer capability IE that does not correspond to the requested one by the MODIFY message.

#### 10.1.4.5.3.5 Test requirements

After step 3 the UE shall discard received MODIFY REJECT message and take no action. The CC-entity of the UE in CC-state U26, "Mobile Originating Modify", shall remain in the call state U26.

#### 10.1.4.5.4 In-call functions / UE originated in-call modification / an abnormal case of rejection

##### 10.1.4.5.4.1 Definition

This is to test a special case of a in-call modification procedure, in which the in-call modification is rejected incorrectly. This test is applicable for any equipment supporting any dual mode bearer capability service (Teleservice 61 - Alternate Speech/Group 3 fax).

##### 10.1.4.5.4.2 Conformance requirement

- 1) Upon receipt of the MODIFY REJECT message indicating a call mode which does not correspond to the actual one the UE shall discard it and take no action.

### References

TS 24.008 clause 5.3.4.4.

#### 10.1.4.5.4.3 Test purpose

To verify that upon receipt of the MODIFY REJECT message indicating a call mode which does not correspond to the actual one the UE discards it and takes no action.

## 10.1.4.5.4.4 Method of test

## Related ICS/IXIT statements

- supported teleservices;
- support of dual bearer capability services.

## Initial conditions

## System Simulator:

1 cell, default parameters.

## User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

## Test procedure

The UE initiates a call for one of the supported dual mode services. The UE being in the call active state, in-call modification procedure is initiated for the selected service from the UE side. The UE shall send a MODIFY message with new mode to the SS. The SS returns a MODIFY REJECT message specifying a mode that does not correspond to the actual one. The state of the UE is then checked.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				MMI action to initiate a dual mode call Steps 2-13 of test case 10.1.4.5.1 are performed and the UE is in CC-state "Active"
2	->		MODIFY	MMI action to change the mode with a mode that does not correspond to the actual one
3	<-		MODIFY REJECT	
4	<-		STATUS ENQUIRY	cause 30#, state U26
5	->		STATUS	

## Specific message contents:

MODIFY REJECT message contains the Bearer capability IE that does not correspond to the actual one specified in the Bearer capability 1IE of the SETUP message. And also contains a cause value #58 "bearer capability not presently available".

## 10.1.4.5.4.5 Test requirements

After step 3 the UE shall discard received MODIFY REJECT message and take no action. The CC-entity of the UE in CC-state U26, "Mobile Originating Modify", shall remain in the call state U26.

## 10.1.4.5.5 In-call functions / UE originated in-call modification / time-out of timer T323

## 10.1.4.5.5.1 Definition

This is to test a special case of a in-call modification procedure, in which timer T323 expires in state U26, mobile originating modify. This test is applicable for any equipment supporting any dual mode bearer capability service Teleservice 61 - Alternate Speech/Group 3 fax).

## 10.1.4.5.5.2 Conformance requirement

- 1) Upon expiration of T323 the UE shall initiate the procedures for call clearing with cause #102 "recovery on timer expiry".

## References

TS 24.008 clause 5.3.4.3.4.3.

## 10.1.4.5.5.3 Test purpose

To verify that upon expiration of T323 the UE shall initiate the procedures for call clearing with cause #102 "recovery on timer expiry".

## 10.1.4.5.5.4 Method of test

## Related ICS/IXIT statements

- supported circuit switched basic services;
- support of dual bearer capability services.

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

## Test procedure

The UE initiates a call for one of the supported dual mode services. The UE being in the call active state, in-call modification procedure is initiated for the selected service from the UE side. The UE shall send a MODIFY message with new mode to the SS. The SS does not respond until timer T323 expires at the UE. The UE is expected to respond with a DISCONNECT message. The SS checks timer T323 accuracy between emission of MODIFY and reception of DISCONNECT messages, the state of the UE and a cause value from the DISCONNECT message.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				MMI action to initiate a dual mode call Steps 2-13 of test case 10.1.4.5.1 are performed and the UE is in CC-state "Active"
2	->		MODIFY	MMI action to change the mode
3		SS		the SS waits for the timer T323 expiry
4	->		DISCONNECT	cause value #102, the SS checks timer check the timer T323 accuracy
5	<-		STATUS ENQUIRY	
6	->		STATUS	cause 30#, state U11

Specific message contents:

None.



#### 10.1.4.5.5.5 Test requirements

Upon expiry of timer T323 the UE shall initiate the procedures for call clearing by sending a DISCONNECT message with cause #102 "recovery on timer expiry" and enter the CC-state U11, "Disconnect Request".

#### 10.1.4.5.6 In-call functions / UE originated in-call modification / a successful channel change in state mobile originating modify

##### 10.1.4.5.6.1 Definition

This is to test a special case of a in-call modification procedure, in which a change of a physical channel occurs in state U26, mobile originating modify. This test is applicable for any equipment supporting any dual mode bearer capability service (Teleservice 61 - Alternate Speech/Group 3 fax).

##### 10.1.4.5.6.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U26, "Mobile Originating Modify", after successful completion of a radio bearer reconfiguration procedure with a physical channel change shall remain in the call state U26.
- 2) Upon receipt of the MODIFY COMPLETE message the UE shall start sending user information according to the new call mode and enter the "active" state.

#### References

- 1) TS 24.008 clause 5.3.4.3.2, TS25.311 clause 8.3.5.
- 2) TS 24.008 clause 5.3.4.3.2.

##### 10.1.4.5.6.3 Test purpose

- 1) To verify that a CC-entity of the UE in CC-state U26, "Mobile Originating Modify", after successful completion of a radio bearer reconfiguration procedure remains in the call state U26.
- 2) To verify that upon receipt of the MODIFY COMPLETE message the UE starts sending user information according to the new call mode and enters the "active" state.

##### 10.1.4.5.6.4 Method of test

#### Related ICS/IXIT statements

- supported circuit switched basic services;
- support of dual bearer capability services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

#### Test procedure

The UE initiates a call for one of the supported dual mode services. The UE being in the call active state, in-call modification procedure is initiated for the selected service from the UE side. The UE shall send a MODIFY message with a new mode to the SS. The SS does not respond immediately, but performs radio bearer reconfiguration procedure including the appropriate channel mode for the new service. The state of the UE is then checked. The SS then returns a MODIFY COMPLETE message. The state of the UE is checked finally.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				MMI action to initiate a dual mode call Steps 2-13 of test case 10.1.4.5.1 are performed and the UE is in CC-state "Active"
2	->		MODIFY	MMI action to change the mode channel mode implied by the MODIFY message
3	<-		RADIO BEARER RECONFIGURATION	
4	->		RADIO BEARE RECONFIGURATION COMPLETE	cause 30#, state U26
5	<-		STATUS ENQUIRY	
6	->		STATUS	cause 30#, state U10
7	<-		MODIFY COMPLETE	
8	<-		STATUS ENQUIRY	
9	->		STATUS	

Specific message contents:

RADIO BEARER RECONFIGURATION message contains some IEs that is fit for BC in MODIFY message. And also contains the Frequency info IE with the value which is different from previous established one by Radio bearer establishment.

#### 10.1.4.5.6.5 Test requirements

After step 4 a CC-entity of the UE in CC-state U26, "Mobile Originating Modify", shall remain in the call state U26.

After step 7 the UE shall start sending user information according to the new call mode and enter the CC state U10, "Active".

#### 10.1.4.5.7 In-call functions / UE originated in-call modification / an unsuccessful channel change in state mobile originating modify

##### 10.1.4.5.7.1 Definition

This is to test a special case of a in-call modification procedure, in which an unsuccessful change of a physical channel occurs in state U26, mobile originating modify. This test is applicable for any equipment supporting any dual mode bearer capability service (Teleservice 61 - Alternate Speech/Group 3 fax).

##### 10.1.4.5.7.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U26, "Mobile Originating Modify", when returning to the old channel after handover failure and having established the link, shall remain in the call state U26.

#### References

TS 24.008 clause 5.3.4.3.2.

##### 10.1.4.5.7.3 Test purpose

To verify that a CC-entity of the UE in CC-state U26, "Mobile Originating Modify", when returning to the old channel after handover failure and having established the link, remains in the call state U26.

##### 10.1.4.5.7.4 Method of test

#### Related ICS/IXIT statements

- supported teleservices;

- support of dual bearer capability services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

#### Test procedure

The UE initiates a call for one of the supported dual mode services. The UE being in the call active state, in-call modification procedure is initiated for the selected service from the UE side. The UE shall send a MODIFY message with a new mode to the SS. The SS initiates handover procedure. When the UE tries to establish the main signalling link, it is prohibited by the SS. Then the UE shall return back to the old channel and re-establish correctly the link. The state of the UE is then checked.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				MMI action to initiate a dual mode call Steps 2-13 of test case 10.1.4.5.1 are performed and the UE is in CC-state "Active"
2	->		MODIFY	MMI action to change the mode
3	<-		RADIO BEARER RECONFIGURATION	
4		SS		the SS does not re-configure the physical channel
5	->		RADIO BEARER RECONFIGURATION FAILURE	after the UE has re-established the main signalling link in the old channel
6	<-		STATUS ENQUIRY	NOTE
7	->		STATUS	cause 30#, state U26

#### Specific message contents:

RADIO BEARER RECONFIGURATION message contains some IEs that is fit for BC in MODIFY message. And also contains the Frequency info IE with the value which is different from previous established one by Radio bearer establishment.

NOTE: With the cause value "physical channel failure".

#### 10.1.4.5.7.5 Test requirements

After step 5 a CC-entity of the UE in CC-state U26, "Mobile Originating Modify", shall remain in the call state U26.

#### 10.1.4.5.8 In-call functions / UE originated in-call modification / unknown message received

##### 10.1.4.5.8.1 Definition

This is to test a special case of a in-call modification procedure, in which an unknown message is received in state U26, mobile originating modify. This test is applicable for any equipment supporting any dual mode bearer capability service Teleservice 61 - Alternate Speech/Group 3 fax).

#### 10.1.4.5.8.2 Conformance requirement

A CC entity of a UE in CC-state U26, "Mobile Originating Modify", having received an unknown message from its peer entity shall return a STATUS message.

#### References

TS 24.008 clause 8.4.

#### 10.1.4.5.8.3 Test purpose

To verify that a CC entity of a UE in CC-state U26, "Mobile Originating Modify", having received an unknown message from its peer entity returns a STATUS message.

#### 10.1.4.5.8.4 Method of test

#### Related ICS/IXIT statements

- supported teleservices;
- support of dual bearer capability services.

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

#### Test procedure

The UE initiates a call for one of the supported dual mode services. The UE being in the call active state, in-call modification procedure is initiated for the selected service from the UE side. The UE shall send a MODIFY message with a new mode to the SS. The SS sends a message with message type not defined for the protocol discriminator. The state of the UE is then checked.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				MMI action to initiate a dual mode call Steps 2-13 of test case 10.1.4.5.1 are performed and the UE is in CC-state "Active"
2		->	MODIFY	MMI action to change the mode message type not defined for PD cause 97#, state U26
3		<-	unknown message	
4		->	STATUS	

#### Specific message contents:

None.

#### 10.1.4.5.8.5 Test requirements

After step 3 a CC entity of a UE in CC-state U26, "Mobile Originating Modify", shall return a STATUS message.

#### 10.1.4.5.9 In-call functions / UE originated in-call modification / a release complete received

##### 10.1.4.5.9.1 Definition

The call control entity of the UE being in the state, U26, the call is cleared by a RELEASE COMPLETE message sent by the SS. This test is applicable for any equipment supporting any dual mode bearer capability service (Teleservice 61 - Alternate Speech / Group 3 fax).

##### 10.1.4.5.9.2 Conformance requirement

- 1) A CC entity of the UE in CC-state U26, "mobile originating modify", upon receipt of a RELEASE COMPLETE message with valid cause value, shall enter CC state U0, "Null".
- 2) On returning to idle mode, the CC entities relating to the seven mobile originating transaction identifiers shall be in state U0, "Null".

##### Reference(s)

Conformance requirement 1: TS 24.008 clause 5.4.2, TS 24.008 clause 5.4.4.

Conformance requirement 2: TS 24.008 clause 5.4.4.1.3.

##### 10.1.4.5.9.3 Test purpose

- 1) To verify that a CC entity of the UE in CC-state U26, "mobile originating modify", upon receipt of a RELEASE COMPLETE message with valid cause value, enters CC state U0, "Null".
- 2) To verify that on returning to idle mode, the CC entities relating to the seven mobile originating transaction identifiers are in state U0, "Null".

##### 10.1.4.5.9.4 Method of test

##### Related ICS/IXIT statements

- a way to activate a dual mode call;
- a way to activate in-call modification;
- support of dual bearer capability services.

##### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

##### Test Procedure

The UE initiates a call for one of the supported dual mode services. The UE being in the call active state, in-call modification procedure is initiated for the selected service from the UE side. The UE shall send a MODIFY message with the new mode to the SS and the state of the UE is checked. The SS sends a RELEASE COMPLETE message to the UE. The SS checks by using the status enquiry procedure that the CC entity has entered the state U0 with all the relevant transaction identifiers.

NOTE: ICM can be initiated by manual intervention at the UE.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				MMI action to initiate a dual mode call Steps 2-13 of test case 10.1.4.5.1 are performed and the UE is in CC-state "Active"
2		->	MODIFY	as specified in specific message contents
3		<-	STATUS ENQUIRY	
4		->	STATUS	cause #30, state U26
5		<-	RELEASE COMPLETE	
6		<-	STATUS ENQUIRY	
7		->	RELEASE COMPLETE	cause #81 (invalid TI value)
8		SS		repeat steps 6 - 7 to cover all the transaction identifiers from 000 ... 110
9		<-	RRC CONNECTION RELEASE	the main signalling link shall be released
10		->	RRC CONNECTION RELEASE COMPLETE	

Specific message contents:

None.

#### 10.1.4.5.9.5 Test requirements

The UE shall send a MODIFY message and enter the state U26 "Mobile Originating Modify".

After step 7 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

## 10.2 Call Re-establishment

### 10.2.1 Call Re-establishment/call present, re-establishment allowed

#### 10.2.1.1 Definition

This is to test a successful case of a call re-establishment procedure. This test is applicable for any equipment supporting at least one bearer capability. If the UE does not perform call re-establishment procedure correctly, the network will waste resources.

#### 10.2.1.2 Conformance requirement

- 1) If the call is in the "active" state or "mobile originating modify" state, the indication from MM that re-establishment is possible shall cause call control to request re-establishment from the MM-connection, suspend any further message to be sent and await the completion of the re-establishment procedure.
- 2) When the call control entity is notified that the MM-connection is re-established, it shall then resume the transmission of possibly suspended messages and resume user data exchange when an appropriate channel is available.

#### References

- 1) TS 24.008 clause 4.5.1.6 and 5.5.4.2.
- 2) TS 24.008 clause 4.5.1.6 and 5.5.4.3.

### 10.2.1.3 Test purpose

The purpose of this test is to verify that the UE can correctly perform a call re-establishment procedure.

### 10.2.1.4 Method of test

#### Related ICS/IXIT statements

- supported teleservices.

#### Initial conditions

##### System Simulator:

The SS simulates cells A and B. The LAC of cell A is different from the LAC of cell B. The PLMN identities of cell A and B are equal.

The call re-establishment parameter concerning cell A is set to an arbitrary value.

Cell B is not barred. Cell B is indicated as a neighbour cell of cell A in SYSTEM INFORMATION messages of cell A. Cell reselect hysteresis parameter of cell A is set to zero.

##### User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN on cell A.

#### Test procedure

The UE is brought into the state U10 "Active" by using Generic call setup procedure for mobile originating circuit switched calls defined in TS34.108. The RF level of cell A is lowered so that cell B is to be selected (when the UE performs re-establishment after radio link failure), while keeping the C1 and C2 of cell A greater than zero. SS waits for at least 5 seconds. Then the SS stops transmission on the DTCH/DCCH. The UE shall re-establish the call on cell B using a CM RE-ESTABLISHMENT message. The SS performs security mode control and radio bearer establishment procedures. The UE shall through-connect the appropriate bearer channel. Then, the call is cleared by the SS.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				The UE is brought into the state U10 "Active" by using Generic call setup procedure for mobile originating circuit switched calls defined in TS34.108 (the appropriate bearer channel is through connected in both directions in DTCH)
2		SS		The RF level of cell A is lowered. The SS waits at least 5 seconds. The SS stops transmission on the DTCH/DCCH. this is sent on cell B.
3	->		RRC CONNECTION RE-ESTABLISHMENT REQUEST	
4	<-		RRC CONNECTION RE-ESTABLISHMENT	
5	->		RRC CONNECTION RE-ESTABLISHMENT COMPLETE	
6	->		CM REESTABLISHMENT REQUEST	note specific message contents
7	<-		SECURITY MODE COMMAND	SS starts deciphering after sending the message.
8	->		SECURITY MODE COMPLETE	Shall be sent enciphered. All following messages shall be sent enciphered.
9		SS		SS starts ciphering.
10			Radio Bearer Setup Procedure	See TS34.108
11		UE		The appropriate bearer channel is through connected in both directions. with cause value "Normal"
12	<-		DISCONNECT	
13	->		RELEASE	
14	<-		RELEASE COMPLETE	
15	<-		RRC CONNECTION RELEASE	The main signalling link is released.
16	->		RRC CONNECTION RELEASE COMPLETE	

Specific message contents:

CM RE-ESTABLISHMENT REQUEST message contains Ciphering key sequence number IE with the value which the UE was allocated in .

#### 10.2.1.5 Test requirements

After step 2 a CC entity of the UE in the "active" state, shall suspend any further message to be sent and await the completion of the re-establishment procedure.

After step 10 the UE resume user data exchange when an appropriate channel is available.

### 10.2.2 Call Re-establishment/call under establishment, transmission stopped

#### 10.2.2.1 Definition

This is to test a special case of a call re-establishment, in which it is not allowed for a UE to attempt re-establishment of a call, since the call has not been established yet. This test is applicable for any equipment supporting at least one mobile originated circuit switched basic service.

#### 10.2.2.2 Conformance requirement

When a lower layer failure occurs while an MM-connection is active, if the state of the call control entity is not "active", the UE shall release the MM-connection and shall not attempt call re-establishment.



## References

TS 24.008 clauses 4.5.1.6 and 5.5.4.2.

## 10.2.2.3 Test purpose

The purpose of this test is to verify that the UE does not attempt call re-establishment when it is not allowed to take place because of the call control state.

## 10.2.2.4 Method of test

## Related ICS/IXIT statements

- supported MO circuit switched basic services.

## Initial conditions

System Simulator:

The SS simulates cell A.

Cell A is not barred.

User Equipment:

The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

## Test procedure

The call control entity of the UE is brought to state U4, "call delivered" by using Generic call setup procedure for mobile originating circuit switched calls defined in TS34.108. The SS stops transmission on the DTCH/DCCH. The UE shall not require re-establishment of the call on cell A.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				the UE is made to initiate a call
2		->	RRC CONNECTION REQUEST	
3		<-	RRC CONNECTION SETUP	
4		->	RRC CONNECTION SETUP COMPLETE	
5		->	CM SERVICE REQUEST	
6		<-	AUTHENTICATION REQUEST	
7		->	AUTHENTICATION RESPONSE	
8		<-	SECURITY MODE COMMAND	
9		->	SECURITY MODE COMPLETE	SS starts deciphering after sending the message. All following messages shall be sent enciphered. SS starts ciphering.
10	SS			
11		->	SETUP	
12		<-	CALL PROCEEDING	See TS34.108 U4 the SS stops transmission on the DTCH/DCCH the UE shall not attempt re-establishment on cell A. This is checked for 30 seconds after the radio link failure.
13			Radio Bearer Setup Procedure	
14		<-	ALERTING	
15	SS			
16	UE			

Specific message contents:

None.

#### 10.2.2.5 Test requirements

After step 15 the UE that is not in "active" state, shall release the MM-connection and shall not attempt call re-establishment.

## 10.3 User to user signalling

### 10.3.1 Definition

The "user to user" information element is used to convey information between the mobile user and a remote ISDN user. This test is therefore applicable for any equipment supporting at least one mobile terminating circuit switched basic service.

NOTE: There is no test for an UE originating call including a "user-user" information element since it is not a mandatory UE feature.

### 10.3.2 Conformance requirement

The inclusion of the "user-user" information element in downlink call control messages shall cause no adverse effects on the operation of the UE.

### References

TS 24.008 clauses 5.2.2, 9.3.7, 9.3.23.1 and 10.5.4.25

### 10.3.3 Purpose of the test

The purpose of this test is to verify that inclusion of the "user-user" information element in either of the down link messages, SETUP or DISCONNECT causes no adverse effects on the operation of the UE.

### 10.3.4 Method of test

#### Related ICS/IXIT statement(s)

- Supported MT circuit switched basic services.
- Support of user-user information element, and details of suitable codings.

#### Initial conditions.

##### System Simulator:

The SS simulates 1 cell, with default parameters.

##### User Equipment:

The UE is in MM-state "idle updated", with a valid TMSI and CKSN.

#### Test procedure

The SS attempts to set up a mobile terminated call, with one of the supported circuit switched basic services which has been arbitrarily chosen, the generic call set up procedures for mobile terminating circuit switched calls, (either speech or data) as specified in TS34.108 clause 7. The default SETUP message contents are modified to include the user-user Information Element. The UE shall not respond adversely to the inclusion of the user-user information element.

After 30 seconds the SS sends a DISCONNECT message, again the UE shall not respond adversely to the inclusion of the user-user information element, but shall continue to clear down the call normally.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1				Generic Call Setup procedure for mobile terminating circuit switched calls defined in TS 34.108, depending on choice of Bearer Capability. The SETUP message contains the user-user IE, see Specific message contents. The SS waits 30 seconds. Message contains the user-user IE, see Specific message contents
2				
3		<-	DISCONNECT	
4		->	RELEASE	
5		<-	RELEASE COMPLETE	
6		<-	RRC CONNECTION RELEASE	
7		->	RRC CONNECTION RELEASE COMPLETE	

#### Specific message contents:

SETUP message contains user-user IE with the string coded in IA5 characters: for example "Call Setup".

DISCONNECT message contains user-user IE with the string coded in IA5 characters: for example "Call Disconnect". (The codings above are for example only. For the case of an UE which supports "user-user" signalling it may be necessary to add meaning to the data fields, see ICS/IXIT statement(s).)

NOTE: The codings above are for example only. For the case of an UE which supports "user-user" signalling it may be necessary to add meaning to the data fields, see ICS/IXIT statement(s).

#### 10.3.5 Test requirements

The inclusion of the "user-user" information element in downlink call control messages shall cause no adverse effects on the operation of the UE.

---

# 11 Session Management Procedures

## 11.1 PDP context activation

### 11.1.1 Initiated by the UE

#### 11.1.1.1 Attach initiated by context activation/QoS Offered by Network is the QoS Requested

##### 11.1.1.1.1 Definition

##### 11.1.1.1.2 Conformance requirement

PDP context activation shall initiate PS Attach by the UE to establish a GMM context, when the UE is PS Detached.

In order to request a PDP context activation, the UE sends an ACTIVATE PDP CONTEXT REQUEST message to the network, enters the state PDP-ACTIVE-PENDING and starts timer T3380. The message contains the selected NSAPI, PDP type, requested QoS and, if the UE requests a static address, the PDP address.

If the QoS offered by the network is the same as the QoS requested by the UE, then upon receipt of the message ACTIVATE PDP CONTEXT ACCEPT the UE shall stop timer T3380.

In GSM, the MS shall initiate establishment of the logical link for the LLC SAPI indicated by the network with the offered QoS and selected radio priority level if no logical link has been already established for that SAPI.

In UMTS, both the network and the MS shall store the LLC SAPI and the radio priority in the PDP context. If a UMTS to GSM system change is performed, the new SGSN shall initiate establishment of the logical link using the negotiated QoS profile, the negotiated LLC SAPI, and selected radio priority level stored in the PDP context as in a GSM to GSM Routing Area Update.

An MS, which is capable of operating in both GSM and UMTS, shall use a valid LLC SAPI, while an MS which is capable of operating only in UMTS shall indicate the LLC SAPI value as "LLC SAPI not assigned" in order to avoid unnecessary value range checking and any other possible confusion in the network.

NOTE: The radio priority level and the LLC SAPI parameters, though not used in UMTS, shall be included in the messages, in order to support handover between UMTS and GSM networks.

## Reference

3G TS 24.008 subclauses 6.1.3.1 and 6.1.3.1.1.

#### 11.1.1.1.3 Test purpose

To check the UE initiates a PS attach if one is not already active.

To test the behaviour of the UE when SS responds to a PDP context activation request with the requested QoS.

#### 11.1.1.1.4 Method of test

## Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE and is in GMM-state "GMM-DEREGISTERED, normal service" with valid P-TMSI and CKSN.

#### Related ICS/IXIT statements

- PS Supported      yes/no
- Method of context activation

#### Test procedure

If the UE is attached a detach request is sent from the SS. UE replies with DETACH ACCEPT. A PDP context activation is then requested by the user. The PS attach (ATTACH REQUEST) is then indirectly caused by a requested PDP context activation. The SS returns the ATTACH ACCEPT message to the UE. Now session management can proceed with PDP context activation.

On receipt of the ACTIVATE PDP CONTEXT REQUEST message an ACTIVATE PDP CONTEXT ACCEPT is returned by the SS with the same requested QoS. The contents of the ACTIVATE PDP CONTEXT REQUEST message shall then be checked. The SS then waits for T3380seconds to ensure T3380 has been stopped and no more ACTIVATE PDP CONTEXT REQUEST messages are sent by the UE. The SS then sends a MODIFY PDP CONTEXT REQUEST message to which the UE shall reply with a MODIFY PDP CONTEXT ACCEPT message to ensure the context has been set up.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		←	DETACH REQUEST	Only sent if the UE attaches at power-up, if not go to step 3.
2		→	DETACH ACCEPT	UE accepts the detach
3	UE			Initiate a context activation
4		→	ATTACH REQUEST	Request attach
5		←	ATTACH ACCEPT	Accept attach
6		→	ACTIVATE PDP CONTEXT REQUEST	Request a PDP context activation
7		←	ACTIVATE PDP CONTEXT ACCEPT	Accept the PDP context activation
8	SS			Wait for T3380 seconds to ensure no further activate request messages come from the UE
9		←	MODIFY PDP CONTEXT REQUEST (NETWORK TO UE DIRECTION)	SS sends a modify request to UE for the activated context
10		→	MODIFY PDP CONTEXT ACCEPT (UE TO NETWORK DIRECTION)	UE accepts the modification request from the network to show context is activated

#### Specific message contents

None.

#### 11.1.1.1.5 Test requirements

To pass the test UE has to:

- initiate a PS ATTACH if one is not already active
- when the network responds to a PDP context activation request, initiated by the UE, with the requested QoS, the UE has to complete the PDP context activation procedure. To check if the PDP context activation was successful, SS shall request PDP context modification and UE shall accept it.

### 11.1.1.2 QoS offered by the network is a lower QoS

#### 11.1.1.2.1 QoS accepted by UE

##### 11.1.1.2.1.1 Definition

##### 11.1.1.2.1.2 Conformance requirement

In order to request a PDP context activation, the UE sends an ACTIVATE PDP CONTEXT REQUEST message to the network enters the state PDP-ACTIVE-PENDING and starts timer T3380. If the QoS offered by the network is acceptable to UE, then upon receipt of the message ACTIVATE PDP CONTEXT ACCEPT the UE shall stop timer T3380.

In GSM, the MS shall initiate establishment of the logical link for the LLC SAPI indicated by the network with the offered QoS and selected radio priority level if no logical link has been already established for that SAPI.

In UMTS, both the network and the MS shall store the LLC SAPI and the radio priority in the PDP context.

#### Reference

3G TS 24.008 subclause 6.1.3.1.1.

##### 11.1.1.2.1.3 Test purpose

To test the behaviour of the UE when the SS responds to a PDP context activation request with a lower QoS than that requested.

##### 11.1.1.2.1.4 Method of test

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

#### Related ICS/IXIT statements

- PS Supported                      yes/no
- User setting of Minimum QoS supported                      yes/no
- Method of setting minimum QoS
- Method of context activation

#### Test procedure

The requested QoS and Minimum QoS are set. A context activation is requested by the user. On receipt of the ACTIVATE PDP CONTEXT REQUEST message an ACTIVATE PDP CONTEXT ACCEPT is returned by the SS with a QoS lower than the requested but higher than or equal to the minimum. The SS then sends a MODIFY PDP CONTEXT REQUEST message and the UE shall respond with a MODIFY PDP CONTEXT ACCEPT message to confirm the context is active.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			Initiate a context activation
2	→		ACTIVATE PDP CONTEXT REQUEST	Request a PDP context activation
3	←		ACTIVATE PDP CONTEXT ACCEPT	Accept a PDP context activation
4	←		MODIFY PDP CONTEXT REQUEST (NETWORK TO UE DIRECTION)	Send a modify request to UE for the activated context
5	→		MODIFY PDP CONTEXT ACCEPT (UE TO NETWORK DIRECTION)	Accept the modification request from network to show context is activated

Specific message contents

None.

#### 11.1.1.2.1.5 Test requirements

To pass the test UE shall:- when the network responds to a PDP context activation request, initiated by the UE, with the QoS lower than the requested but higher than or equal to the minimum, the UE has to complete the PDP context activation procedure. To see if the PDP context activation was successful, SS shall request PDP context modification and UE shall accept it.

#### 11.1.1.2.2 QoS rejected by UE

##### 11.1.1.2.2.1 Definition

##### 11.1.1.2.2.2 Conformance requirement

In order to request a PDP context activation, the UE sends an ACTIVATE PDP CONTEXT REQUEST message to the network.

Upon receipt of the message ACTIVATE PDP CONTEXT ACCEPT offering a QoS which is not acceptable to the UE, the UE shall initiate the PDP context deactivation procedure.

#### Reference

3G TS 24.008 subclause 6.1.3.1.1.

##### 11.1.1.2.2.3 Test purpose

To test the behaviour of the UE when the QoS offered by SS in response to a PDP context activation request is not acceptable to the UE.

##### 11.1.1.2.2.4 Method of test

Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

#### Related ICS/IXIT statements

- PS Supported            yes/no
- User setting of Minimum QoS supported            yes/no
- Method of setting minimum QoS
- Method of context activation

#### Test procedure

The requested QoS and Minimum QoS are set. A context activation is requested by the user. On receipt of the ACTIVATE PDP CONTEXT REQUEST message an ACTIVATE PDP CONTEXT ACCEPT message is returned by the SS with a QoS lower than the minimum. The UE shall then send a DEACTIVATE PDP CONTEXT REQUEST message. A DEACTIVATE PDP CONTEXT ACCEPT message will be sent in return by the SS.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			Initiate a context activation
2	→		ACTIVATE PDP CONTEXT REQUEST	Request a PDP context activation
3	←		ACTIVATE PDP CONTEXT ACCEPT	Accept the PDP context activation
4	→		DEACTIVATE PDP CONTEXT REQUEST	Deactivate the PDP context
5	←		DEACTIVATE PDP CONTEXT ACCEPT	Accept the PDP context deactivation

#### Specific message contents

None.

#### 11.1.1.2.2.5 Test requirements

The UE shall reject the QoS offered by the network in response to a PDP context activation request, if the QoS is not acceptable to the UE.

### 11.1.2 PDP context activation requested by the network, successful and unsuccessful

#### 11.1.2.1 Definition

This test needs to take into account the number of active PDP contexts supported simultaneously by the UE, to be able to test the response when all contexts are activated and the network tries to initiate a new context.

#### 11.1.2.2 Conformance requirement

- 1) Upon receipt of a REQUEST PDP CONTEXT ACTIVATION message:
  - If the UE accepts the request the UE shall then initiate the PDP context activation procedure.



- If the UE rejects the request, the UE shall send a REQUEST PDP CONTEXT ACTIVATION REJECT message with one of the following causes:

#26: insufficient resources;

#31: activation rejected, unspecified;

#40: feature not supported; or

#95 – 111: protocol errors.

- 2) The UE shall not ignore the request.
- 3) If the UE accepts the request, the ACTIVATE PDP CONTEXT REQUEST message sent by the UE shall contain the parameters requested by the network in the REQUEST PDP CONTEXT ACTIVATION message, except for the offered QoS which may be changed by the UE.
- 4) Whenever a REQUEST PDP CONTEXT ACTIVATION message is received by the UE specifying a transaction identifier relating to a PDP context not in state PDP-INACTIVE, the UE shall locally deactivate the old PDP context relating to the received transaction identifier. Furthermore, the UE shall continue with the activation procedure of a new PDP context as indicated in the received message.

## Reference

3G TS 24.008 clauses 6.1.3.1.2, 6.1.3.1.4 and 8.3.2.f)

3G TS 27.060 clause 7.3.3.

### 11.1.2.3 Test purpose

To test the behaviour of the UE upon receipt of a context activation request from the SS.

### 11.1.2.4 Method of test

#### Initial conditions

#### System Simulator:

1 cell, default parameters.

#### User Equipment:

The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

## Related ICS/IXIT statements

- PS Supported      yes/no
- Network requested PDP context activation supported    yes/no
- Number of network initiated PDP contexts supported

## Case 1

For an UE that supports PDP context activation requested by the network.

### Test procedure

A REQUEST PDP CONTEXT ACTIVATION message is sent by the SS. On receipt of the ACTIVATE PDP CONTEXT REQUEST message an ACTIVATE PDP CONTEXT ACCEPT message is returned by the SS. If all 7 contexts are supported then steps 5, 6 and 7 should not be performed. This is continued until the maximum number of contexts the UE supports are activated. When one more context is activated the UE shall return a REQUEST PDP

CONTEXT ACTIVATION REJECT message with cause set to 'insufficient resources'. A REQUEST PDP CONTEXT ACTIVATION message is then sent using a currently activated context transaction identifier. The UE shall activate this context in place of the previous context.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	←		REQUEST PDP CONTEXT ACTIVATION	SS sends Request a PDP context activation to UE
2	→		ACTIVATE PDP CONTEXT REQUEST	UE replies with a Request PDP context activation
3	←		ACTIVATE PDP CONTEXT ACCEPT	SS accepts the PDP context activation
4		SS		Steps 1-3 are repeated for the number of Network Initiated contexts supported NOTE: If all 7 contexts are supported steps 5, 6 and 7 should not be performed
5	←		REQUEST PDP CONTEXT ACTIVATION	SS requests a PDP context activation
6	→		REQUEST PDP CONTEXT ACTIVATION REJECT	The context activation request is rejected with cause 'insufficient resources'.
7	←		REQUEST PDP CONTEXT ACTIVATION	SS requests a PDP context activation for an existing context
8	→		ACTIVATE PDP CONTEXT REQUEST	UE requests a PDP context activation to replace the existing context
9	←		ACTIVATE PDP CONTEXT ACCEPT	SS accepts the PDP context activation

#### Case 2

For an UE that does not support PDP context activation requested by the network.

#### Test procedure

A REQUEST PDP CONTEXT ACTIVATION message is sent by the SS. The UE shall then send an REQUEST PDP CONTEXT ACTIVATION REJECT message.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	←		REQUEST PDP CONTEXT ACTIVATION	Request a PDP context activation
2	→		REQUEST PDP CONTEXT ACTIVATION REJECT	Reject the PDP context activation request with cause 'insufficient resources' or 'feature not supported'.

#### Specific message contents

None.

#### 11.1.2.5 Test requirements

An UE that is configured to support one or more PDP contexts simultaneously, with a number of active contexts lower than the maximum, shall accept PDP context activation initiated by the network.

The UE that does not support PDP Context Activation (a number of active contexts supported by the UE is equal to maximum or UE does not support PDP context) shall reject PDP context activation initiated by the network.

### 11.1.3 Abnormal Cases

#### 11.1.3.1 T3380 Expiry

##### 11.1.3.1.1 Definition

##### 11.1.3.1.2 Conformance requirement

- 1) On the first expiry of the timer T3380, the UE shall re-send the PDP CONTEXT ACTIVATION REQUEST
- 2) On the second expiry of the timer T3380, the UE shall re-send the PDP CONTEXT ACTIVATION REQUEST
- 3) On the third expiry of the timer T3380, the UE shall re-send the PDP CONTEXT ACTIVATION REQUEST
- 4) On the fourth expiry of the timer T3380, the UE shall re-send the PDP CONTEXT ACTIVATION REQUEST
- 5) On the fifth expiry of the timer T3380, the UE shall release all resources possibly allocated for this invocation and shall abort the procedure; no automatic PDP context activation re-attempt shall be performed.

#### Reference

3G TS 24.008 subclause 6.1.3.1.5 a).

##### 11.1.3.1.3 Test purpose

To test the behaviour of the UE when the SS does not reply to PDP CONTEXT ACTIVATION REQUEST.

##### 11.1.3.1.4 Method of test

#### Initial conditions

##### System Simulator:

1 cell, default parameters.

##### User Equipment:

The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

#### Related ICS/IXIT statements

- PS Supported      yes/no
- Method of activating a context

#### Test procedure

A context activation is requested by the user. The UE shall send the ACTIVATE PDP CONTEXT REQUEST message five times with T3380 seconds between each message. After this no further ACTIVATE PDP CONTEXT REQUEST messages shall be sent by the UE.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			Initiate a context activation
2	→		ACTIVATE PDP CONTEXT REQUEST	Request a PDP context activation
3		SS		T3380 seconds
4	→		ACTIVATE PDP CONTEXT REQUEST	Request a PDP context activation
5		SS		T3380 seconds
6	→		ACTIVATE PDP CONTEXT REQUEST	Request a PDP context activation
7		SS		T3380 seconds
8	→		ACTIVATE PDP CONTEXT REQUEST	Request a PDP context activation
9		SS		T3380 seconds
10	→		ACTIVATE PDP CONTEXT REQUEST	Request a PDP context activation
11		SS		Wait for T3380 seconds to ensure no further ACTIVATE PDP CONTEXT REQUEST messages are sent by the UE

Specific message contents

None.

#### 11.1.3.1.5 Test requirements

UE shall resend the ACTIVATE PDP CONTEXT REQUEST to SS five times in order to initiate PDP context, with expiry of timer T3380 between messages. After fifth try, UE shall send no more ACTIVATE PDP CONTEXT REQUEST to SS.

#### 11.1.3.2 Collision of UE initiated and network requested PDP context activation

##### 11.1.3.2.1 Definition

This test needs to take into account the number of PDP contexts supported by the UE, to be able to test the response when the network tries to initiate a new context.

##### 11.1.3.2.2 Conformance requirement

A collision of an MS initiated and a network requested PDP context activation procedure is identified by the MS if a REQUEST PDP CONTEXT ACTIVATION message is received from the network after the MS has sent an ACTIVATE PDP CONTEXT REQUEST message, and the MS has not yet received an ACTIVATE PDP CONTEXT ACCEPT or ACTIVATE PDP CONTEXT REJECT message.

#### Reference

3G TS 24.008 subclause 6.1.3.1.5 b), case: Static PDP address collision detected within the UE.

##### 11.1.3.2.3 Test purpose

To test the behaviour of the UE when there is a collision between an UE initiated and SS requested PDP context activation detected by the UE.

## 11.1.3.2.4 Method of test

## Initial conditions

## System Simulator:

1 cell, default parameters.

## User Equipment:

The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

## Related ICS/IXIT statements

- PS Supported      yes/no
- Method of PDP context activation

**Case 1**

For an UE that supports PDP context activation requested by the network.

## Test procedure

A context activation is requested by the user. After receipt of the ACTIVATE PDP CONTEXT REQUEST message the SS sends a REQUEST PDP CONTEXT ACTIVATION message followed by an ACTIVATE PDP CONTEXT ACCEPT message in a time less than T3380 (Use T3380/2). The UE shall send no messages within this time.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			Initiate a context activation
2	→		ACTIVATE PDP CONTEXT REQUEST	Request a PDP context activation
3	←		REQUEST PDP CONTEXT ACTIVATION	Request a PDP context activation request
4		SS		Wait for T3380/2 seconds to ensure UE does not resend ACTIVATE PDP CONTEXT REQUEST
5	←		ACTIVATE PDP CONTEXT ACCEPT	Accept the PDP context activation

**Case 2**

For an UE that does not support PDP context activation requested by the network.

## Test procedure

A context activation is requested by the user. After receipt of the ACTIVATE PDP CONTEXT REQUEST message the SS sends a REQUEST PDP CONTEXT ACTIVATION message. The UE shall send a REQUEST PDP CONTEXT ACTIVATION REJECT message with cause set to 'insufficient resources' or 'feature not supported'. The SS then sends an ACTIVATE PDP CONTEXT ACCEPT.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		UE		Initiate a context activation
2	→		ACTIVATE PDP CONTEXT REQUEST	Request a PDP context activation
3	←		REQUEST PDP CONTEXT ACTIVATION	Request a PDP context activation request
4	→		REQUEST PDP CONTEXT ACTIVATION REJECT	Cause set to 'insufficient resources' or 'feature not supported'.
5	←		ACTIVATE PDP CONTEXT ACCEPT	Accept the PDP context activation

Specific message contents

None.

#### 11.1.3.2.5 Test requirements

In the case of such collision,

- the UE that supports PDP context activation requested by the network shall discard the REQUEST PDP CONTEXT ACTIVATION message from SS and wait for an ACTIVATE PDP CONTEXT ACCEPT message.
- the UE that does not support PDP context activation requested by the network shall reject PDP context activation initiated by the SS.

### 11.1.4 Secondary PDP context activation procedures

#### 11.1.4.1 Successful Secondary PDP Context Activation Procedure Initiated by the UE

##### 11.1.4.1.1 QoS Offered by Network is the QoS Requested

###### 11.1.4.1.1.1 Definition

###### 11.1.4.1.1.2 Conformance requirement

In order to request a secondary PDP context activation, the UE sends an ACTIVATE SECONDARY PDP CONTEXT REQUEST message to the network, enters the state PDP-ACTIVE-PENDING and starts timer T3380. The message contains the selected NSAPI, a QoS profile, a requested LLC SAPI and the linked TI.

If the QoS offered by the network is the same as the QoS requested by the UE, then upon receipt of the message ACTIVATE SECONDARY PDP CONTEXT ACCEPT, the UE shall stop timer T3380.

In GSM the UE shall initiate establishment of the logical link for the LLC SAPI indicated by the network, with the offered QoS and selected radio priority level, if no logical link has been already established for that SAPI.

Although not used in UMTS, LLC SAPI shall be included in the messages, in order to support handover between UMTS and GSM networks.

#### Reference

3G TS 24.008 subclauses 6.1.3.2 and 6.1.3.2.1.

#### 11.1.4.1.1.3 Test purpose

To test the behaviour of the UE when SS responds to a Secondary PDP context activation request with the requested QoS.

#### 11.1.4.1.1.4 Method of test

##### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE and is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

##### Related ICS/IXIT statements

- PS Supported      yes/no
- Method of context activation

##### Test procedure

On receipt of the ACTIVATE SECONDARY PDP CONTEXT REQUEST message an ACTIVATE SECONDARY PDP CONTEXT ACCEPT is returned by the SS with the same requested QoS. The SS then waits for T3380 seconds to ensure T3380 has been stopped and no more ACTIVATE SECONDARY PDP CONREXT REQUEST messages are sent by the UE. The SS then sends a MODIFY PDP CONTEXT REQUEST message to which the UE shall reply with a MODIFY PDP CONTEXT ACCEPT message to ensure the context has been set up.

##### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	→		ACTIVATE SECONDARY PDP CONTEXT REQUEST	Request a Secondary PDP context activation
2	←		ACTIVATE SECONDARY PDP CONTEXT ACCEPT	Accept the Secondary PDP context activation
3		SS		Wait for T3380 seconds to ensure no further activate request messages come from the UE
4	←		MODIFY PDP CONTEXT REQUEST (NETWORK TO UE DIRECTION)	SS sends a modify request to UE for the activated context
5	→		MODIFY PDP CONTEXT ACCEPT (UE TO NETWORK DIRECTION)	UE accepts the modification request from the network to show context is activated

##### Specific message contents

None.

#### 11.1.4.1.1.5 Test requirements

To pass the test the UE has to:

- when the network responds to a Secondary PDP context activation request initiated by the UE, with the requested QoS, the UE shall complete the Secondary PDP context activation procedure. To check if the Secondary PDP context activation was successful, SS shall request PDP context modification and UE shall accept it.

#### 11.1.4.1.2 QoS Offered by Network is a lower QoS

##### 11.1.4.1.2.1 QoS accepted by UE

##### 11.1.4.1.2.1.1 Definition

##### 11.1.4.1.2.1.2 Conformance requirement

In order to request a Secondary PDP context activation, the UE sends an ACTIVATE SECONDARY PDP CONTEXT REQUEST message to the network, enters the state PDP-ACTIVE-PENDING and starts timer T3380. If the QoS offered by the network is acceptable to UE, then upon receipt of the message ACTIVATE SECONDARY PDP CONTEXT ACCEPT the UE shall stop timer T3380.

In GSM the UE shall initiate establishment of the logical link for the LLC SAPI indicated by the network, with the offered QoS and selected radio priority level, if no logical link has been already established for that SAPI.

#### Reference

3G TS 24.008 subclauses 6.1.3.2 and 6.1.3.2.1.

##### 11.1.4.1.2.1.3 Test purpose

To test the behaviour of the UE when the SS responds to a Secondary PDP context activation request with a lower QoS than that requested.

##### 11.1.4.1.2.1.4 Method of test

#### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

#### Related ICS/IXIT statements

- PS Supported                      yes/no
- User setting of Minimum QoS supported                      yes/no
- Method of setting minimum QoS
- Method of context activation

#### Test procedure

The requested QoS and Minimum QoS are set. A secondary context activation is requested by the user. On receipt of the ACTIVATE SECONDARY PDP CONTEXT REQUEST message an ACTIVATE SECONDARY PDP CONTEXT ACCEPT is returned by the SS with a QoS lower than the requested but higher than or equal to the minimum. The SS then sends a MODIFY PDP CONTEXT REQUEST message and the UE shall respond with a MODIFY PDP CONTEXT ACCEPT message to confirm the context is active.



Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			Initiate a context activation
2	→		ACTIVATE SECONDARY PDP CONTEXT REQUEST	Request a Secondary PDP context activation
3	←		ACTIVATE SECONDARY PDP CONTEXT ACCEPT	Accept a Secondary PDP context activation
4	←		MODIFY PDP CONTEXT REQUEST (NETWORK TO UE DIRECTION)	Send a modify request to UE for the activated context
5	→		MODIFY PDP CONTEXT ACCEPT (UE TO NETWORK DIRECTION)	Accept the modification request from network to show context is activated

Specific message contents

None.

#### 11.1.4.1.2.1.5 Test requirements

To pass the test UE shall:

- when the network responds to a Secondary PDP context activation request, initiated by the UE, with the QoS lower than the requested but higher than or equal to the minimum, the UE shall complete the Secondary PDP context activation procedure. To see if the PDP context activation was successful, SS shall request PDP context modification and UE shall accept it.

#### 11.1.4.1.2.2 QoS rejected by UE

##### 11.1.4.1.2.2.1 Definition

##### 11.1.4.1.2.2.2 Conformance requirement

In order to request a Secondary PDP context activation, the UE sends an ACTIVATE SECONDARY PDP CONTEXT REQUEST message to the network.

Upon receipt of the message ACTIVATE SECONDARY PDP CONTEXT ACCEPT offering a QoS which is not acceptable to the UE, the UE shall initiate the PDP context deactivation procedure.

#### Reference

3G TS 24.008 subclauses 6.1.3.2 and 6.1.3.2.1.

##### 11.1.4.1.2.2.3 Test purpose

To test the behaviour of the UE when the QoS offered by SS in response to a Secondary PDP context activation request is not acceptable to the UE.

##### 11.1.4.1.2.2.4 Method of test

Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

Related ICS/IXIT statements

- PS Supported            yes/no
- User setting of Minimum QoS supported            yes/no
- Method of setting minimum QoS
- Method of context activation

Test procedure

The requested QoS and Minimum QoS are set. A context activation is requested by the user. On receipt of the ACTIVATE SECONDARY PDP CONTEXT REQUEST message an ACTIVATE SECONDARY PDP CONTEXT ACCEPT message is returned by the SS with a QoS lower than the minimum. The UE shall then send a DEACTIVATE PDP CONTEXT REQUEST message for the secondary PDP context. A DEACTIVATE PDP CONTEXT ACCEPT message will be sent in return by the SS.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			Initiate a secondary context activation
2	→		ACTIVATE SECONDARY PDP CONTEXT REQUEST	Request a Secondary PDP context activation
3	←		ACTIVATE SECONDARY PDP CONTEXT ACCEPT	Accept the Secondary PDP context activation with QoS lower than Minimum QoS
4	→		DEACTIVATE PDP CONTEXT REQUEST	Request deactivation of the secondary PDP context
5	←		DEACTIVATE PDP CONTEXT ACCEPT	Accept the PDP context deactivation

Specific message contents

Tear down indicator IE shall not be included in the DEACTIVATE PDP CONTEXT REQUEST message because only the PDP context for this specific TI shall be deactivated.

#### 11.1.4.1.2.2.5 Test requirements

The UE shall reject the QoS offered by the network in response to a Secondary PDP context activation request, if the QoS is not acceptable to the UE.

#### 11.1.4.2 Abnormal cases

##### 11.1.4.2.1 T3380 Expiry

###### 11.1.4.2.1.1 Definition

###### 11.1.4.2.1.2 Conformance requirement

- 1) On the first expiry of the timer T3380, the UE shall re-send the ACTIVATE SECONDARY PDP CONTEXT REQUEST

- 2) On the second expiry of the timer T3380, the UE shall re-send the ACTIVATE SECONDARY PDP CONTEXT REQUEST
- 3) On the third expiry of the timer T3380, the UE shall re-send the ACTIVATE SECONDARY PDP CONTEXT REQUEST
- 4) On the fourth expiry of the timer T3380, the UE shall re-send the ACTIVATE SECONDARY PDP CONTEXT REQUEST
- 5) On the fifth expiry of the timer T3380, the UE shall release all resources possibly allocated for this invocation and shall abort the procedure; no automatic secondary PDP context activation re-attempt shall be performed.

#### Reference

3G TS 24.008 subclause 6.1.3.2.3 a).

#### 11.1.4.2.1.3 Test purpose

To test the behaviour of the UE when the SS does not reply to ACTIVATE SECONDARY PDP CONTEXT REQUEST message.

#### 11.1.4.2.1.4 Method of test

#### Initial conditions

##### System Simulator:

1 cell, default parameters.

##### User Equipment:

The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

#### Related ICS/IXIT statements

- PS Supported      yes/no
- Method of activating a context

#### Test procedure

A secondary PDP context activation is requested by the user. The UE shall send ACTIVATE SECONDARY PDP CONTEXT REQUEST message five times with T3380 seconds between each message. After this no further ACTIVATE SECONDARY PDP CONTEXT REQUEST messages shall be sent by the UE.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			Initiate a context activation
2	→		ACTIVATE SECONDARY PDP CONTEXT REQUEST	Request a Secondary PDP context activation
3		SS		T3380 seconds
4	→		ACTIVATE SECONDARY PDP CONTEXT REQUEST	Request a Secondary PDP context activation
5		SS		T3380 seconds
6	→		ACTIVATE SECONDARY PDP CONTEXT REQUEST	Request a Secondary PDP context activation
7		SS		T3380 seconds
8	→		ACTIVATE SECONDARY PDP CONTEXT REQUEST	Request a Secondary PDP context activation
9		SS		T3380 seconds
10	→		ACTIVATE SECONDARY PDP CONTEXT REQUEST	Request a Secondary PDP context activation
11		SS		Wait for T3380 seconds to ensure no further ACTIVATE SECONDARY PDP CONTEXT REQUEST messages are sent by the UE

Specific message contents

None.

#### 11.1.4.2.1.5 Test requirements

UE shall resend the ACTIVATE SECONDARY PDP CONTEXT REQUEST to SS five times in order to initiate a Secondary PDP context, with expiry of timer T3380 between messages. After fifth try, UE shall send no more ACTIVATE SECONDARY PDP CONTEXT REQUEST messages to SS.

*Editor's note: This heading is deleted because it is related to the network function.*

## 11.2 PDP context modification procedure

### 11.2.1 Network initiated PDP context modification

#### 11.2.1.1 Definition

This test can only be performed if minimum QoS can be set by the user.

#### 11.2.1.2 Conformance requirement

1) Upon receipt of a MODIFY PDP CONTEXT REQUEST message

- If the UE can accept the modification requested, the UE shall reply with the MODIFY PDP CONTEXT ACCEPT message.
- If the UE is unable to accept the modification requested, the UE shall initiate the PDP context deactivation procedure for the NSAPI that has been indicated in the message MODIFY PDP CONTEXT REQUEST - the reject cause IE value of the DEACTIVATE PDP CONTEXT REQUEST message shall indicate "QoS not accepted".

2) The UE shall either accept the modification request or deactivate the PDP context, it shall not ignore the modification request.

## Reference

3G TS 24.008 subclauses 6.1.3.3 and 6.1.3.3.1.

## 11.2.1.3 Test purpose

To test the behaviour of the UE upon receipt of a MODIFY PDP CONTEXT REQUEST message from SS.

## 11.2.1.4 Method of test

## Initial conditions

## System Simulator:

1 cell, default parameters.

## User Equipment:

The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

## Related ICS/IXIT statements

- PS Supported            yes/no
- User setting of Minimum QoS supported            yes/no
- Method of setting minimum QoS
- Method of activating a PDP context

## Test procedure

A PDP context is activated by the user and accepted by the SS. A MODIFY PDP CONTEXT REQUEST message is then sent to the UE with a QoS that is acceptable to the UE (higher than or equal to the minimum QoS set in the UE). The UE shall send a MODIFY PDP CONTEXT ACCEPT message in return. A MODIFY PDP CONTEXT REQUEST message is then sent to the UE with a QoS that is not acceptable to the UE (lower than the minimum QoS set in the UE). The UE shall send a DEACTIVATE PDP CONTEXT REQUEST message in return.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			Initiate a context activation
2	→		ACTIVATE PDP CONTEXT REQUEST	Activate a PDP context
3	←		ACTIVATE PDP CONTEXT ACCEPT	Accept the PDP context
4	←		MODIFY PDP CONTEXT REQUEST (NETWORK TO UE DIRECTION)	Request the modification of a PDP context, with QoS higher than or equal to the minimum QoS set in the UE
5	→		MODIFY PDP CONTEXT ACCEPT (UE TO NETWORK DIRECTION)	Accept the PDP context modification
6	←		MODIFY PDP CONTEXT REQUEST (NETWORK TO UE DIRECTION)	Request the modification of a PDP context, QoS lower than the minimum QoS set in the UE
7	→		DEACTIVATE PDP CONTEXT REQUEST	Reject the PDP context modification by deactivating the PDP context. Cause set to 'QoS not acceptable'
8	←		DEACTIVATE PDP CONTEXT ACCEPT	Accept the PDP context deactivation

Specific message contents

None.

#### 11.2.1.5 Test requirements

The UE shall:

- Accept PDP context modification initiated by the SS if QoS is higher than or equal to the minimum QoS set in the UE
- Reject PDP context modification initiated by the SS if QoS is lower than the minimum QoS set in the UE.

### 11.2.2 UE initiated PDP context modification (FFS)

### 11.2.3 Abnormal cases (FFS)

#### 11.2.3.1 T3381 expiry

#### 11.2.3.2 Collision of UE and network initiated PDP context modification procedures

## 11.3 PDP context deactivation procedure

### 11.3.1 PDP context deactivation initiated by the UE

#### 11.3.1.1 Definition

#### 11.3.1.2 Conformance requirement

The DEACTIVATE PDP CONTEXT REQUEST message sent by UE contains the transaction identifier in use for the PDP context to be deactivated and a cause code that typically indicates one of the following causes:

- #25: LLC or SMDCP failure(GSM only) ; #26: insufficient resources;
- #36: regular PDP context deactivation; or
- #37: QoS not accepted.

Upon receipt of the DEACTIVATE PDP CONTEXT ACCEPT message, the UE shall stop timer T3390.

- Whenever any session management message except REQUEST PDP CONTEXT ACTIVATION or SM-STATUS is received by the UE specifying a transaction identifier which is not recognised as relating to an active context or to a context that is in the process of activation or deactivation or has been [recently] deactivated, the UE shall send a SM-STATUS message with cause #81 "invalid transaction identifier value" using the received transaction identifier value including the extension octet and remain in the PDP-INACTIVE state.

#### Reference

3G TS 24.008 subclauses 6.1.3.4 ,6.1.3.4.1 and 8.3.2 (b).

#### 11.3.1.3 Test purpose

To test the behaviour of the UE upon receipt of a DEACTIVATE PDP CONTEXT ACCEPT message from the SS in PDP context deactivation procedure initiated by the UE.

## 11.3.1.4 Method of test

## Initial conditions

## System Simulator:

1 cell, default parameters.

## User Equipment:

The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

## Related ICS/IXIT statements

- PS Supported      yes/no
- Method of activating a PDP context
- Method of deactivating the PDP context

## Test procedure

A PDP context is activated by the user and accepted by the SS. The context deactivation is then requested by the user. The UE shall send a DEACTIVATE PDP CONTEXT REQUEST message to the SS. The SS shall then reply with a DEACTIVATE PDP CONTEXT ACCEPT message. The SS shall then wait for T3390 seconds to ensure T3390 has been stopped and that no further messages are sent from the UE. The SS shall then send a MODIFY PDP CONTEXT REQUEST for the deactivated context and the UE shall reply with an SM STATUS message with cause #81 'transaction identifier not known'.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			Initiate a context activation
2	→		ACTIVATE PDP CONTEXT REQUEST	Activate a PDP context
3	←		ACTIVATE PDP CONTEXT ACCEPT	Accept the PDP context
4	UE			Initiate a context deactivation
5	→		DEACTIVATE PDP CONTEXT REQUEST	Request a deactivation of a PDP context
6	←		DEACTIVATE PDP CONTEXT ACCEPT	Accept the PDP context deactivation
7	SS			Wait for T3390 seconds to ensure no further deactivate request messages are sent
8	←		MODIFY PDP CONTEXT REQUEST (NETWORK TO UE DIRECTION)	Send a modify request to UE for the deactivated context.
9	→		SM STATUS	Cause set to #81

## Specific message contents

None.

### 11.3.1.5 Test requirements

In PDP context deactivation procedure initiated by the UE, upon receipt of a DEACTIVATE PDP CONTEXT ACCEPT message from the SS, the UE shall deactivate PDP context associated with given PDP address and TI.

Then, upon modification procedure initiated by the network, for deactivated PDP context, UE shall reply with SM STATUS message with cause #81.

## 11.3.2 PDP context deactivation initiated by the network

### 11.3.2.1 Definition

### 11.3.2.2 Conformance requirement

The DEACTIVATE PDP CONTEXT REQUEST message sent by SS contains the transaction identifier in use for the PDP context to be deactivated and a cause code that typically indicates one of the following causes:

- # 25: LLC or SMDCP failure (GSM only);
- # 36: regular PDP context deactivation;
- # 38: network failure; or
- # 39: reactivation requested.

The UE shall, upon receipt of the DEACTIVATE PDP CONTEXT REQUEST message from network, reply with a DEACTIVATE PDP CONTEXT ACCEPT message.

- Whenever any session management message except REQUEST PDP CONTEXT ACTIVATION or SM-STATUS is received by the UE specifying a transaction identifier which is not recognised as relating to an active context or to a context that is in the process of activation or deactivation or has been [recently] deactivated, the UE shall send a SM-STATUS message with cause #81 "invalid transaction identifier value" using the received transaction identifier value and remain in the PDP-INACTIVE state.

### Reference

3G TS 24.008 subclauses 6.1.3.4, 6.1.3.4.2 and 8.3.2 (b).

### 11.3.2.3 Test purpose

To test the behaviour of the UE upon receipt of a DEACTIVATE PDP CONTEXT REQUEST message from the SS.

### 11.3.2.4 Method of test

#### Initial conditions

#### System Simulator:

1 cell, default parameters.

#### User Equipment:

The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

### Related ICS/IXIT statements

- PS Supported        yes/no
- Method of activating a PDP context



## Test procedure

A PDP context is activated by the user and accepted by the SS. A DEACTIVATE PDP CONTEXT REQUEST message is then sent by the SS. The UE shall reply with a DEACTIVATE PDP CONTEXT ACCEPT message. The SS shall then send a MODIFY PDP CONTEXT REQUEST for the deactivated context and the UE shall reply with an SM STATUS message with cause #81 'transaction identifier not known'.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE	→	ACTIVATE PDP CONTEXT REQUEST	Initiate a context activation
2				Activate a PDP context
3		←	ACTIVATE PDP CONTEXT ACCEPT	Accept the PDP context
4		←	DEACTIVATE PDP CONTEXT REQUEST	Request a deactivation of a PDP context
5		→	DEACTIVATE PDP CONTEXT ACCEPT	Accept the PDP context deactivation.
6		←	MODIFY PDP CONTEXT REQUEST (NETWORK TO UE DIRECTION)	Send a modify request to UE for the deactivated context.
7		→	SM STATUS	Cause set to #81

## Specific message contents

None.

## 11.3.2.5 Test requirements

Upon receipt of a request for deactivation of a PDP context from the SS, the UE shall deactivate PDP context. Then, upon modification procedure initiated by the network, for deactivated PDP context, UE shall reply with SM STATUS message with cause #81.

## 11.3.3 Abnormal cases

### 11.3.3.1 T3390 Expiry

#### 11.3.3.1.1 Definition

#### 11.3.3.1.2 Conformance requirement

- 1) On the first expiry of timer T3390, the UE shall resend the message DEACTIVATE PDP CONTEXT REQUEST
- 2) On the second expiry of timer T3390, the UE shall resend the message DEACTIVATE PDP CONTEXT REQUEST
- 3) On the third expiry of timer T3390, the UE shall resend the message DEACTIVATE PDP CONTEXT REQUEST
- 4) On the fourth expiry of timer T3390, the UE shall resend the message DEACTIVATE PDP CONTEXT REQUEST
- 5) On the fifth expiry of timer T3390, the UE shall release all resources allocated and shall erase the PDP context related data.

## Reference

3G TS 24.008 subclause 6.1.3.4.3 a) case In the UE.

### 11.3.3.1.3 Test purpose

To test the behaviour of the UE when the SS does not reply to a DEACTIVATE PDP CONTEXT REQUEST message from the UE.

### 11.3.3.1.4 Method of test

#### Initial conditions

##### System Simulator:

1 cell, default parameters.

##### User Equipment:

The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

#### Related ICS/IXIT statements

- PS Supported      yes/no
- Method of activating a PDP context
- Method of deactivating a PDP context

#### Test procedure

A PDP context is activated by the user and accepted by the SS. A context deactivation is then requested by the user. The UE shall send a DEACTIVATE PDP CONTEXT REQUEST message five times with T3390 seconds between each message. T3390 seconds after the fifth message the SS shall send a MODIFY PDP CONTEXT REQUEST message for the deactivated context and the UE shall reply with SM STATUS with cause set to #81 'Transaction identifier not known'.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			Initiate a context activation
2	→		ACTIVATE PDP CONTEXT REQUEST	Activate a PDP context
3		←	ACTIVATE PDP CONTEXT ACCEPT	Accept the PDP context
4	UE			Initiate a context deactivation
5	→		DEACTIVATE PDP CONTEXT REQUEST	Request a deactivation of a PDP context
6		SS		T3390 seconds
7	→		DEACTIVATE PDP CONTEXT REQUEST	Request a deactivation of a PDP context
8		SS		T3390 seconds
9	→		DEACTIVATE PDP CONTEXT REQUEST	Request a deactivation of a PDP context
10		SS		T3390 seconds
11	→		DEACTIVATE PDP CONTEXT REQUEST	Request a deactivation of a PDP context
12		SS		T3390 seconds
13	→		DEACTIVATE PDP CONTEXT REQUEST	Request a deactivation of a PDP context
14		SS		Wait T3390 seconds
15	←		MODIFY PDP CONTEXT REQUEST (NETWORK TO UE DIRECTION)	Try to modify the deactivated context.
16	→		SM STATUS	Cause set to #81

Specific message contents

None.

#### 11.3.3.1.5 Test requirements

If network does not reply to UE initiated PDP context deactivation procedure, the UE shall retransmit a DEACTIVATE PDP CONTEXT REQUEST five times, with T3390 timer expiry between the successive messages, before releasing resources allocated to the PDP context and deleting PDP context related data.

#### 11.3.3.2 Collision of UE and network initiated PDP context deactivation requests

##### 11.3.3.2.1 Definition

##### 11.3.3.2.2 Conformance requirement

If the UE and the network initiated PDP context deactivation requests collide, the UE and the network shall each reply with the message DEACTIVATE PDP CONTEXT ACCEPT and shall stop timer T3390 and T3395, respectively.

#### Reference

3G TS 24.008 subclause 6.1.3.4.3 b).

##### 11.3.3.2.3 Test purpose

To test the behaviour of the UE when there is a collision between an UE initiated and SS initiated context deactivation.

## 11.3.3.2.4 Method of test

## Initial conditions

## System Simulator:

1 cell, default parameters.

## User Equipment:

The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN

## Related ICS/IXIT statements

- PS Supported      yes/no
- Method of activating a PDP context
- Method of deactivating a PDP context

## Test procedure

A PDP context is activated by the user and accepted by the SS. A context deactivation is then requested by the user. Upon receipt of the DEACTIVATE PDP CONTEXT REQUEST message the SS sends a DEACTIVATE PDP CONTEXT REQUEST message. The UE shall reply with only one DEACTIVATE PDP CONTEXT ACCEPT message. Upon receipt of this message the SS sends a DEACTIVATE PDP CONTEXT ACCEPT message.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			Initiate a context activation
2	→		ACTIVATE PDP CONTEXT REQUEST	Activate a PDP context
3	←		ACTIVATE PDP CONTEXT ACCEPT	Accept the PDP context
4	UE			Initiate a context deactivation
5	→		DEACTIVATE PDP CONTEXT REQUEST	Request a deactivation of a PDP context
6	←		DEACTIVATE PDP CONTEXT REQUEST	Request a deactivation of a PDP context
7	→		DEACTIVATE PDP CONTEXT ACCEPT	Accept the PDP context deactivation
8	←		DEACTIVATE PDP CONTEXT ACCEPT	Accept the PDP context deactivation

## Specific message contents

None.

## 11.3.3.2.5 Test requirements

When UE and SS initiates PDP context deactivation requests collide, the UE shall reply with DEACTIVATE PDP CONTEXT ACCEPT to SS.

## 11.4 Unknown or Unforeseen Transaction Identifier/Non- semantical Mandatory Information Element Errors

### 11.4.1 Error cases

#### 11.4.1.1 Definition

#### 11.4.1.2 Conformance requirement

The mobile station shall ignore a session management message with TI EXT bit = 0. Otherwise, the following procedures shall apply:

- Whenever any session management message, except REQUEST PDP CONTEXT ACTIVATION or SM-STATUS, is received by the UE specifying a transaction identifier which is not recognized as relating to an active context or to a context that is in the process of activation or deactivation or has been [recently] deactivated, the UE shall send a SM-STATUS message with cause #81 "invalid transaction identifier value" using the received transaction identifier value including the extension octet and remain in the PDP-INACTIVE state.
- When a REQUEST PDP CONTEXT ACTIVATION message is received with a transaction identifier flag set to "1", this message shall be ignored.

When on receipt of a message,

- an "imperative message part" error; or
- a "missing mandatory IE" error

is diagnosed or when a message containing:

- a syntactically incorrect mandatory IE; or
- an IE unknown in the message, but encoded as "comprehension required" or
- an out of sequence IE encoded as "comprehension required"

is received, the UE shall proceed as follows:

If the message was a SM message the SM-STATUS message with cause # 96 "invalid mandatory information" shall be returned.

If a mobile station receives a GMM message or SM message with message type not defined for the PD or not implemented by the receiver, it shall return a status message (GMM STATUS or SM STATUS depending on the protocol discriminator) with cause #97 'message type non-existent or not implemented'.

If the mobile station receives a message not compatible with the protocol state, the mobile station shall ignore the message except for the fact that when the message was a SM message the SM-STATUS message with cause #98 'Message type not compatible with protocol state' shall be returned.

Other syntactic errors

This section applies to the analysis of the value part of an information element. It defines the following terminology:

- An IE is defined to be syntactically incorrect in a message if it contains at least one value defined as 'reserved', or if its value part violates syntactic rules given in the specification of the value part. However it is not a syntactical error that a type 4 standard IE specifies in its length indicator a greater length than possible according to the value part specification : extra bits are ignored.

### Reference

3G TS 24.008 clauses 8.3.2 and 8.5 and 3G TS 24.007 clause 11.4.2.

#### 11.4.1.3 Test purpose

To test the behaviour of the UE when messages with unknown or unforeseen transaction identifiers or non-semantical mandatory information element errors occur.

#### 11.4.1.4 Method of test

##### Initial conditions

System Simulator:

1 cell, default parameters.

User Equipment:

The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

##### Related ICS/IXIT statements

-

##### Test procedure

A PDP context activation is requested by the SS with the transaction identifier set to '1'. The UE shall not respond to this request.

A PDP context is then activated from the UE. Two invalid accept messages are then sent by the SS with T3380 seconds between them. After a further T3380 seconds a valid accept message is sent by the SS.

A deactivate message is then sent from the SS with the transaction identifier set to '111'. The UE shall reply with a SM STATUS message with transaction identifier set to '111'.

A deactivate message is then sent from the SS with a different transaction identifier to the one used in the activate request message sent by the UE. The UE shall reply with a SM STATUS message with cause #81 'invalid transaction identifier value'.

Three invalid modification messages are then sent to the UE in turn. The UE shall respond each time with a SM-STATUS message with cause # 96 "invalid mandatory information".

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	←		REQUEST PDP CONTEXT ACTIVATION	Request the activation of a PDP context with the transaction identifier flag set to "1"
2		SS		Wait 30 seconds to ensure UE does not request context activation
3	UE			Initiate a context request
4	→		ACTIVATE PDP CONTEXT REQUEST	Activate a PDP context from the UE
5	←		ACTIVATE PDP CONTEXT ACCEPT	Unknown IE encoded as 'comprehension required'
6	→		SM STATUS	Cause set to #96
7		SS		Wait T3380 seconds
8	→		ACTIVATE PDP CONTEXT REQUEST	Activate a PDP context from the UE (auto-generated)
9	←		ACTIVATE PDP CONTEXT ACCEPT	Out of sequence IE encoded as 'comprehension required'
10	→		SM STATUS	Cause set to #96
11		SS		Wait T3380 seconds
12	→		ACTIVATE PDP CONTEXT REQUEST	Activate a PDP context from the UE (auto-generated)
13	←		ACTIVATE PDP CONTEXT ACCEPT	Accept the PDP context
16	←		DEACTIVATE PDP CONTEXT REQUEST	Try to deactivate the context with a different transaction identifier to that used to activate the context
17	→		SM STATUS	Cause set to # 81
18	←		MODIFY PDP CONTEXT REQUEST(NETWORK TO UE DIRECTION)	Request the modification of the PDP context
19	→		SM STATUS	Cause set to # 96
20	←		MODIFY PDP CONTEXT REQUEST(NETWORK TO UE DIRECTION)	Request the modification of the PDP context
21	→		SM STATUS	Cause set to # 96
22	←		MODIFY PDP CONTEXT REQUEST(NETWORK TO UE DIRECTION)	Request the modification of the PDP context
23	→		SM STATUS	Cause set to # 96

11.4.1.5

Test requirements

TBD.

---

## 12 Elementary procedure for Packet Switched Mobility Management

### 12.1 Applicability, default conditions and default messages

All test cases for PS mobility management apply for all PS mobiles unless otherwise stated in a specific test. Within each test case, the ICS statement indicates whether the test shall be performed for mobiles that can only operate in mode - class A, only in mode - class C, or in both mode - class A and C. For some procedures, the mobile class is of no importance.

Note that only the layer 3 messages are described in the document. The mapping of the layer 3 messages to lower layers and the use of logical channels is not described in this document.

The terms 'PS/CS mode of operation' and 'PS mode of operation' are not used in this specification with some exceptions. Instead the terms 'UE operation mode A' and 'UE operation mode C' are used.

The default conditions and default message contents not specified in this clause must be set as in "PS default conditions"

Below is a list of the RAI values and the corresponding RAC, LAC and MCC used in the test cases:

RAI-1: MCC1/MNC1/LAC1/RAC1 (Used if only one cell)

RAI-2: MCC2/MNC1/LAC1/RAC1

RAI-3: MCC1/MNC1/LAC2/RAC1

RAI-4: MCC1/MNC1/LAC1/RAC2

RAI-5: MCC1/MNC1/LAC1/RAC3

If the User Equipment initial condition specifies that the mobile has a valid IMSI but the initial condition does not mention P-TMSI, then that shall be interpreted as that the mobile has no valid P-TMSI.

The tests are based on 3G TS 24.008.

### 12.2 PS attach procedure

This procedure is used to indicate for the network that the IMSI is available for traffic by establishment of a GMM context.

#### 12.2.1 Normal PS attach

The normal PS attach procedure is a GMM procedure used by PS UEs of UE operation mode A or C to IMSI attach for PS services only.

##### 12.2.1.1 PS attach / accepted

###### 12.2.1.1.1 Definition

###### 12.2.1.1.2 Conformance requirement

- 1) If the network accepts the PS attach procedure (signalled by an IMSI) and allocates a P-TMSI, the UE shall acknowledge the P-TMSI and continue communication with the P-TMSI.
- 2) If the network accepts the PS attach procedure (signalled by P-TMSI) and reallocates a new P-TMSI, the UE shall acknowledge the new P-TMSI and continue communication with the new P-TMSI.



- 3) If the network accepts the PS attach procedure (signalled by a P-TMSI) from the UE without reallocation of the old P-TMSI, the UE shall continue communication with the old P-TMSI.

#### Reference

3G TS 24.008 clause 4.7.3.1

#### 12.2.1.1.3 Test purpose

To test the behaviour of the UE if the network accepts the PS attach procedure.

The following cases are identified:

- 1) P-TMSI / P-TMSI signature is allocated
- 2) P-TMSI / P-TMSI signature is reallocated
- 3) Old P-TMSI / P-TMSI signature is not changed

#### 12.2.1.1.4 Method of test

##### Initial condition

System Simulator:

One cell operating in network operation mode III.

User Equipment:

The UE has a valid IMSI.

##### Related ICS/IXIT statements

Support of PS service Yes/No

UE operation mode A Yes/No

UE operation mode C Yes/No

Switch off on button Yes/No

Automatic PS attach procedure at switch on or power on Yes/No

##### Test procedure

- 1) The UE sends an ATTACH REQUEST message with identity IMSI. The SS allocates a P-TMSI and returns ATTACH ACCEPT message with a P-TMSI. The UE acknowledges the P-TMSI by sending ATTACH COMPLETE message. Further communication UE - SS is performed by the new P-TMSI.
- 2) The UE sends an ATTACH REQUEST message with identity P-TMSI. The SS reallocates a new P-TMSI and returns ATTACH ACCEPT message with the new P-TMSI. The UE acknowledges the P-TMSI by sending ATTACH COMPLETE message. Further communication UE - SS is performed by the new P-TMSI. The UE will not answer signalling addressed to the old P-TMSI.
- 3) The UE sends an ATTACH REQUEST message with identity P-TMSI. The SS accepts the P-TMSI and returns ATTACH ACCEPT message without any P-TMSI. Further communication UE - SS is performed by the old P-TMSI.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 26.
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->		ATTACH REQUEST	Attach type = 'PS only attached'
4	<-		ATTACH ACCEPT	Mobile identity = IMSI Attach result = 'PS attach'
5	->		ATTACH COMPLETE	Mobile identity = P-TMSI-2
6	<-		PACKET PAGING REQUEST	P-TMSI-2 signature
7	->		UPLINK RLC DATA BLOCK	Routing area identity = RAI-1 LLC PDU implicitly indicating paging response.
8	UE			The UE is switched off or power is removed (see ICS).
9	->		DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, PS detach'
10	UE			The UE is powered up or switched on and initiates an attach (see ICS).
11	->		ATTACH REQUEST	Attach type = 'PS attach'
12	<-		ATTACH ACCEPT	Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-1 Attach result = 'PS only attached'
13	->		ATTACH COMPLETE	Mobile identity = P-TMSI-1
14	<-		GMM INFORMATION	P-TMSI-1 signature
14b	->		GMM STATUS	Routing area identity = RAI-1 Message sent with P-TMSI-1 Message sent in case the UE does not support reception of GMM information message Cause #97
15	<-		PACKET PAGING REQUEST Or PAGING REQUEST TYPE 1	Mobile identity = P-TMSI-2 Both paging orders are for TBF establishment. PACKET PAGING REQUEST (used for NW mode III) PAGING REQUEST TYPE 1 (used for NW-mode II).
16	UE			No response from the UE to the request. This is checked for 10 seconds.
17	UE			The UE is switched off or power is removed (see ICS).
18	->		DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, PS detach'
19	UE			The UE is powered up or switched on and initiates an attach (see ICS).
20	->		ATTACH REQUEST	Attach type = 'PS attach'
21	<-		ATTACH ACCEPT	Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1 No new mobile identity assigned. P-TMSI and P-TMSI signature not included. Routing area identity = RAI-1 Attach result = 'PS only attached'
22	<-		PACKET PAGING REQUEST Or PAGING REQUEST TYPE 1	Mobile identity = P-TMSI-1 Both paging orders are for TBF establishment. PACKET PAGING REQUEST (used for NW mode III) PAGING REQUEST TYPE 1 (used for NW-mode II).
23	->		UPLINK RLC DATA BLOCK	LLC PDU implicitly indicating paging response.

24	UE		The UE is switched off or power is removed (see ICS).
25	->	DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, PS detach'
26	SS		The SS is set in network operation mode II.
27	UE		The UE is set in UE operation mode A (see ICS) and the test is repeated from step 2 to step 25.

#### 12.2.1.1.5 Test requirements

UE shall:

- initiate the PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on
- perform the following actions depending on the Mobile identity in the ATTACH REQUEST message and on the Mobile identity in the ATTACH ACCEPT message.

Case 1) The Mobile identity in the ATTACH REQUEST is the IMSI and the Mobile identity in the ATTACH ACCEPT message is the P-TMSI.

UE shall:

- acknowledge the P-TMSI by sending ATTACH COMPLETE message. Further communication UE - SS is performed by the P-TMSI.

Case 2) The Mobile identity in the ATTACH REQUEST is the P-TMSI and the Mobile identity in the ATTACH ACCEPT message is the new P-TMSI.

UE shall:

- acknowledge the new P-TMSI by sending ATTACH COMPLETE message. Further communication UE - SS is performed by the other P-TMSI.

Case 3) The Mobile identity in the ATTACH REQUEST is the P-TMSI and the Mobile identity in the ATTACH ACCEPT message is the same P-TMSI.

UE shall:

- acknowledge the same P-TMSI by sending ATTACH COMPLETE message. Further communication UE - SS is performed by the same P-TMSI.

#### 12.2.1.2 PS attach / rejected / IMSI invalid / illegal UE

##### 12.2.1.2.1 Definition

##### 12.2.1.2.2 Conformance requirement

- 1) If the network rejects a PS attach procedure from the User Equipment with the cause 'Illegal UE', the User Equipment shall consider USIM invalid for PS services until power is switched off or USIM is removed.
- 2) If the network rejects a PS attach procedure from the User Equipment with the cause 'Illegal UE' the User Equipment shall delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.

#### Reference

3G TS 24.008 clause 4.7.3.1

#### 12.2.1.2.3 Test purpose

To test the behaviour of the UE if the network rejects the PS attach procedure of the UE with the cause 'illegal UE'.

#### 12.2.1.2.4 Method of test

##### Initial condition

##### System Simulator:

Three cells (not simultaneously activated), cell A with MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC2/RAC1, cell C in MCC2/MNC1/LAC1/RAC1.

All three cells are operating in network operation mode II (in case of UE operation mode A), or in network operation mode III (in case of UE operation mode C).

##### User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

##### Related ICS/IXIT statements

Support of PS service Yes/No

UE operation mode C Yes/No

UE operation mode A Yes/No (only if mode C not supported)

Switch off on button Yes/No

Automatic PS attach procedure at switch on or power on Yes/No

##### Test procedure

The SS rejects a PS attach with the cause value 'Illegal UE'. The SS checks that the UE does not perform PS attach in the same or another PLMN.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE		ATTACH REQUEST	The following messages are sent and shall be received on cell A. The UE is set in UE operation mode C or B (see ICS).
2	SS			The SS is set in network operation mode II or III and activates cell A.
3	UE			The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.
4	->			Attach type = 'PS attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature
5	<-			Routing area identity = RAI-1 GMM cause = 'Illegal UE'.
6	SS			The following messages are sent and shall be received on cell B.
7	UE			The SS deactivates cell A and activates cell B. Cell B is preferred by the UE.
8	UE			No ATTACH REQUEST sent to the SS (SS waits 30 seconds).
9	UE			The UE initiates an attach by MMI or by AT command.
10	UE			No ATTACH REQUEST sent to the SS (SS waits 30 seconds).
11	SS			The following messages are sent and shall be received on cell C.
12	UE			The SS deactivates cell B and activates cell C. Cell C is preferred by the UE.
13	UE			No ATTACH REQUEST sent to the SS (SS waits 30 seconds).
14	UE			The UE initiates an attach by MMI or by AT command.
15	UE			No ATTACH REQUEST sent to the SS (SS waits 30 seconds).
16	UE			If possible (see ICS) switch off is performed. Otherwise the power is removed.
17	UE		ATTACH REQUEST	The UE is powered up or switched on and initiates an attach (see ICS).
18	->			Attach type = 'PS attach' Mobile identity = IMSI
19	<-			Attach result = 'PS only attached' Mobile identity = P-TMSI-1 P-TMSI-1 signature
20	->		ATTACH COMPLETE	Routing area identity = RAI-2
21	UE			The UE is switched off or power is removed (see ICS).
22	->		DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, PS detach'

## 12.2.1.2.5 Test requirements

UE shall:

- initiate a PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on
- check the GMM cause which is contained in the ATTACH REJECT message and stop timer T3310.
- set the PS update state to GU3 ROAMING NOT ALLOWD and delete stored P-TMSI, P-TMSI signature, RAI and PS ciphering key sequence number.

- not send the ATTACH REQUEST message to SS, even if there is an instruction of attach request from MMI or from AT command.

### 12.2.1.3 PS attach / rejected / IMSI invalid / PS services not allowed

#### 12.2.1.3.1 Definition

#### 12.2.1.3.2 Conformance requirement

- 1) If the network rejects a PS attach procedure from the User Equipment with the cause 'PS services not allowed', the User Equipment shall consider USIM invalid for PS services until power is switched off or USIM is removed.
- 2) If the network rejects a PS attach procedure from the User Equipment with the cause 'PS services not allowed' the User Equipment shall delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.

#### Reference

3G TS 24.008 clause 4.7.3.1

#### 12.2.1.3.3 Test purpose

To test the behaviour of the UE if the network rejects the PS attach procedure of the UE with the cause 'PS services not allowed' (no valid PS-subscription for the IMSI).

#### 12.2.1.3.4 Method of test

#### Initial condition

#### System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (HPLMN) and cell B in MCC2/MNC1/LAC1/RAC1.

Both cells are operating in network operation mode II.

#### User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

#### Related ICS/IXIT statements

Support of PS service Yes/No

UE operation mode C Yes/No

UE operation mode A Yes/No

USIM removal possible without powering down Yes/No

Switch off on button Yes/No

Automatic PS attach procedure at switch on or power on Yes/No

#### Test procedure

The SS rejects a normal attach with the cause value 'PS services not allowed'. The SS checks that the UE does not perform PS attach in another PLMN.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1 2	SS UE		ATTACH REQUEST	The following messages are sent and shall be received on cell A. The SS activates cell A. The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 16. The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE. Attach type = 'PS attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1 GMM cause = 'PS services not allowed'
3	UE			
4	->			
5	<-		ATTACH REJECT	
6 7 8	SS UE UE			The following messages are sent and shall be received on cell B. The SS deactivates cell A and activates cell B. Cell B is preferred by the UE. No ATTACH REQUEST sent to the SS (SS waits 30 seconds). If possible (see ICS) USIM removal is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed.
9	UE			
10	UE			
11	->		ATTACH REQUEST	The UE gets the USIM replaced, is powered up or switched on and initiates an attach (see ICS). Attach type = 'PS attach' Mobile identity = IMSI Attach result = 'PS only attached' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-2
12	<-		ATTACH ACCEPT	
13	->		ATTACH COMPLETE	
14	UE		DETACH REQUEST	The UE is switched off or power is removed (see ICS). Message not sent if power is removed. Detach type = 'power switched off, PS detach'
15	->			
16 17	UE			The SS deactivates cell B and activates cell A. The UE is set in UE operation mode A (see ICS) and the test is repeated from step 3 to step 15.

## 12.2.1.3.5 Test requirements

UE shall:

- initiate a PS attach procedure with information elements specified in the above Expected Sequence when UE is powered up or switched on.
- check the GMM cause which is contained in the ATTACH REJECT message and stop timer T3310.
- set the PS update state to GU3 ROAMING NOT ALLOWD.
- delete stored P-TMSI, P-TMSI signature, RAI and PS ciphering key sequence number.

## 12.2.1.4 PS attach / rejected / PLMN not allowed

### 12.2.1.4.1 Definition

### 12.2.1.4.2 Conformance requirement

- 1) If the network rejects a PS attach procedure from the User Equipment with the cause 'PLMN not allowed' the User Equipment shall:
  - 1.1 not perform PS attach when switched on in the same routing area or location area.
  - 1.2 not perform PS attach when in the same PLMN and when that PLMN is not selected manually.
  - 1.3 delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.
  - 1.4 store the PLMN in the 'forbidden PLMN' list.
- 2) If the network rejects a PS attach procedure from the User Equipment with the cause 'PLMN not allowed' the User Equipment shall perform PS attach when a new PLMN is entered.
- 3) If the network rejects a PS attach procedure from the User Equipment with the cause 'PLMN not allowed' and if after that the PLMN from which this rejection was received, is manually selected, the User Equipment shall perform a PS attach procedure.

### Reference

3G TS 24.008 clause 4.7.3.1

### 12.2.1.4.3 Test purpose

To test the behaviour of the UE if the network rejects the PS attach procedure of the UE with the cause 'PLMN not allowed'.

### 12.2.1.4.4 Method of test

#### Initial condition

#### System Simulator:

Four cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC1, cell C in MCC1/MNC1/LAC2/RAC1 and cell D in MCC2/MNC1/LAC1/RAC1. All four cells are operating in network operation mode II (in case of UE operation mode A), or in network operation mode III (in case of UE operation mode C).

#### User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode C	Yes/No
UE operation mode A	Yes/No (only if mode C not supported)
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

### Test procedure

The SS rejects a PS attach with the cause value 'PLMN not allowed'. The SS checks that the UE does not perform PS attach if activated in the same routing area or location area and performs PS attach only when a new PLMN is entered.



## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE	SS	ATTACH REQUEST	The following messages are sent and shall be received on cell A. The UE is set in UE operation mode C or B (see ICS).
2	SS			The SS is set in network operation mode II or III and activates cell A.
3	UE			The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.
4	->			Attach type = 'PS attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1
5	<-		ATTACH REJECT	GMM cause = 'PLMN not allowed'
6	UE			No ATTACH REQUEST sent to SS (SS waits 30 seconds).
7	SS			The following messages are sent and shall be received on cell B.
8	UE			The SS deactivates cell A and activates cell B.
9	UE			Cell B is preferred by the UE. No ATTACH REQUEST sent to SS (SS waits 30 seconds).
10	SS			The following messages are sent and shall be received on cell C.
11	UE			The SS deactivates cell B and activates cell C.
12	UE			Cell C is preferred by the UE. No ATTACH REQUEST sent to SS (SS waits 30 seconds).
13	SS		ATTACH REQUEST	The following messages are sent and shall be received on cell D.
14	UE			The SS deactivates cell C and activates cell D.
15	UE			Cell D is preferred by the UE.
16	->			The UE initiates an attach automatically, by MMI or by AT command.
17	<-		ATTACH ACCEPT	Attach type = 'PS attach' Mobile identity = IMSI Attach result = 'PS only attached'
18	->		ATTACH COMPLETE	Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-2
19	UE			The UE is switched off or power is removed (see ICS).
20	->		DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, PS detach'

## 12.2.1.4.5 Test requirements

UE shall:

- initiate a PS attach procedure with information elements specified in the above Expected Sequence when UE is powered on or switched on.
- check the GMM cause which is contained in the ATTACH REJECT message and stop timer T3310.
- perform the following actions depending on the PLMN or the routing area or the location area

Case 1) UE is in the same routing area or location area when the power is switched on,

UE shall:

- not perform PS attach.
- delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.
- store the PLMN in the 'forbidden PLMN' list.

Case2) UE is in the same PLMN, and this PLMN is not selected manually

UE shall:

- not perform PS attach.
- delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.
- store the PLMN in the 'forbidden PLMN' list.

Case3) UE is in a new location area.

UE shall:

- perform PS attach.

Case3) UE is in the new PLMN, and this PLMN is selected manually

UE shall

- perform PS attach.

## 12.2.1.5 PS attach / rejected / roaming not allowed in this location area

### 12.2.1.5.1 Definition

### 12.2.1.5.2 Conformance requirement

- 1) If the network rejects a PS attach procedure from the User Equipment with the cause 'roaming not allowed in this location area' the User Equipment shall:
  - 1.1 not perform PS attach when in the same location area.
  - 1.2 delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.
  - 1.3 store the LA in the 'forbidden location areas for roaming' list.
  - 1.4 perform PS attach when a new location area is entered.
  - 1.5 Periodically search for its HPLMN.
- 2) The User Equipment shall reset the list of 'Forbidden location areas for roaming' when switched off or when the USIM is removed.
- 3) The UE shall be capable of storing at least 6 entries in the list of 'Forbidden location areas for roaming'.

### Reference

3G TS 24.008 clause 4.7.3.1

### 12.2.1.5.3 Test purpose

#### Test purpose 1

To test that on receipt of a rejection using the 'roaming not allowed in this location area' cause code, the UE ceases trying to attach on that location area. Successful PS attach procedure is possible in other location areas.

#### Test purpose 2

To test that if the UE is switched off or the USIM is removed the list of 'forbidden location areas for roaming' is cleared.

#### Test purpose 3

To test that at least 6 entries can be held in the list of 'forbidden location areas for roaming' (the requirement in 3G TS 24.008 is to store at least 10 entries. This is not fully tested by the third procedure).

#### Test purpose 4

To test that if a cell of the Home PLMN is available then the UE returns to it in preference to any other available cell.

### 12.2.1.5.4 Method of test

#### 12.2.1.5.4.1 Test procedure 1

#### Initial condition

#### System Simulator:

Three cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC/LAC2/RAC1 and cell C in MCC1/MNC1/LAC1/RAC2.

All three cells are operating in network operation mode III.

#### User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

#### Related ICS/IXIT statements

Support of PS service	Yes/No	
UE operation mode C	Yes/No	
UE operation mode A	Yes/No	
Switch off on button	Yes/No	
Automatic PS attach procedure at switch on or power on	Yes/No	

#### Test procedure

The SS rejects a PS attach with the cause value 'Roaming not allowed in this area'. A new attempt for a PS attach is not possible. Successful PS attach / detach procedures are performed in another location area. A new attempt for a PS attach is performed in the 1<sup>st</sup> location area. This attempt shall not succeed, as the LA is on the forbidden list.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS	ATTACH REQUEST	The following messages are sent and shall be received on cell A. The SS activates cell A. The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 19. The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE. Attach type = 'PS attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1 GMM cause = 'Roaming not allowed in this area' No ATTACH REQUEST sent to SS (SS waits 30 seconds).
2		SS		
3		UE		
4	->			
5	<-			
6		UE		
7		SS	ATTACH REQUEST	The following messages are sent and shall be received on cell B. The SS Deactivates cell A and activates cell B. Cell B is preferred by the UE. The UE initiates an attach automatically, by MMI or by AT command. Attach type = 'PS attach' Mobile identity = IMSI Attach result = 'PS only attached' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-3
8		UE		
9		UE		
10	->			
11	<-			
12		UE		
13		UE	DETACH REQUEST DETACH ACCEPT	The UE initiates a PS detach (without power off) by MMI or by AT command . Detach type = 'normal detach, PS detach'
14	->			
15	<-			
16		SS		The following messages are sent and shall be received on cell C. The SS deactivates cell B and activates cell C. Cell C is preferred by the UE. No ATTACH REQUEST sent to SS (SS waits 30 seconds).
17		UE		
18		UE		
19		SS		The SS is set in network operation mode II. The UE is set in UE operation mode A (see ICS) and the test is repeated from step 3 to step 18.
20		UE		

## 12.2.1.5.4.2 Test procedure 2

## Initial condition

## System Simulator:

One cell operating in network operation mode II.

## User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

## Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode C	Yes/No
UE operation mode A	Yes/No (only if mode C not supported)
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

## Test procedure

The SS rejects a PS attach updating with the cause value 'Roaming not allowed in this area'. The UE is switched off for 10 seconds and switched on again. The SS check that a PS attach is possible on the cell on which the PS attach had been rejected.

If USIM removal is possible without switching off: The SS rejects a PS attach updating with the cause value 'Roaming not allowed in this area'. The USIM is removed and inserted in the UE. The SS check that a PS attach is possible on the cell on which the PS attach had been rejected.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE		ATTACH REQUEST  ATTACH REJECT	The UE is set in UE operation mode C or B (see ICS).
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->			Attach type = 'PS attach'
4	<-			Mobile identity = P-TMSI-1
5	UE			P-TMSI-1 signature
6	UE			Routing area identity = RAI-1
7	UE		ATTACH REQUEST  ATTACH ACCEPT  ATTACH COMPLETE  DETACH REQUEST	GMM cause = 'Roaming not allowed in this area'
8	->			No ATTACH REQUEST sent to the SS (SS waits 30 seconds).
9	<-			If possible (see ICS) switch off is performed. Otherwise the power is removed.
10	->			The UE is powered up or switched on and initiates an attach (see ICS).
11	UE			Attach type = 'PS attach'
12	->			Mobile identity = IMSI

## 12.2.1.5.4.3 Test procedure 3

## Initial condition

## System Simulator:

Six cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC2/RAC1, cell C in MCC1/MNC1/LAC3/RAC1, cell D in MCC1/MNC1/LAC4/RAC1, cell E in MCC1/MNC1/LAC5/RAC1, cell F in MCC1/MNC1/LAC6/RAC1.

All six cells are operating in network operation mode II (in case of UE operation mode A), or in network operation mode III (in case of UE operation mode C).

User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

#### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode C	Yes/No
UE operation mode A	Yes/No (only if mode C not supported)
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

#### Test procedure

The SS rejects a PS attach with the cause value 'Roaming not allowed in this area'. This is done for 6 different location areas. Then the SS checks that the UE does not attempt to perform an attach procedure on the non-allowed location areas.

Different types of UE may use different methods to periodically clear the list of forbidden areas (e.g. every day at 12am) for roaming. If the list is cleared while the test is being run, it may be necessary to re-run the test.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS	ATTACH REQUEST	<p>The following messages are sent and shall be received on cell A.</p> <p>The SS is set in network operation mode II or III and activates cell A.</p> <p>The UE is set in UE operation mode C or B (see ICS).</p> <p>The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.</p> <p>Attach type = 'PS attach'</p> <p>Mobile identity = P-TMSI-1</p> <p>P-TMSI-1 signature</p> <p>Routing area identity = RAI-1</p> <p>GMM cause = 'Roaming not allowed in this area'</p> <p>No ATTACH REQUEST sent to SS (SS waits 30 seconds)</p>
2		SS		
3		UE		
4		UE		
5	->			
6	<-			
7		SS	ATTACH REQUEST	<p>The following messages are sent and shall be received on cell B.</p> <p>The SS deactivates cell A and activates cell B. Cell B is preferred by the UE.</p> <p>The UE initiates an attach automatically, by MMI or by AT command.</p> <p>Attach type = 'PS attach'</p> <p>Mobile identity = IMSI</p> <p>GMM cause = 'Roaming not allowed in this area'</p> <p>No ATTACH REQUEST sent to SS (SS waits 30 seconds).</p>
8		SS		
9		UE		
10		UE		
11	->			
12	<-			
13		SS	ATTACH REQUEST	<p>The following messages are sent and shall be received on cell C.</p> <p>The SS deactivates cell B and activates cell C. Cell C is preferred by the UE.</p> <p>The UE initiates an attach automatically, by MMI or by AT command.</p> <p>Attach type = 'PS attach'</p> <p>Mobile identity = IMSI</p> <p>GMM cause = 'Roaming not allowed in this area'</p> <p>No ATTACH REQUEST sent to SS (SS waits 30 seconds).</p>
14		SS		
15		UE		
16		UE		
17	->			
18	<-			
19		SS	ATTACH REQUEST	<p>The following messages are sent and shall be received on cell D.</p> <p>The SS deactivates cell C and activates cell D. Cell D is preferred by the UE.</p> <p>The UE initiates an attach automatically, by MMI or by AT command.</p> <p>Attach type = 'PS attach'</p> <p>Mobile identity = IMSI</p> <p>GMM cause = 'Roaming not allowed in this area'</p> <p>No ATTACH REQUEST sent to SS (SS waits 30 seconds).</p>
20		SS		
21		UE		
22		UE		
23	->			
24	<-			
25		SS	ATTACH REQUEST	<p>The following messages are sent and shall be received on cell E.</p> <p>The SS deactivates cell D and activates cell E. Cell E is preferred by the UE.</p> <p>The UE initiates an attach automatically, by MMI or by AT command.</p> <p>Attach type = 'PS attach'</p> <p>Mobile identity = IMSI</p> <p>GMM cause = 'Roaming not allowed in this area'</p>
26		SS		
27		UE		
28		UE		
29	->			

30	UE		No ATTACH REQUEST sent to SS (SS waits 30 seconds).
31	SS	ATTACH REQUEST  ATTACH REJECT	The following messages are sent and shall be received on cell F. The SS deactivates cell E and activates cell F. Cell F is preferred by the UE.
32	UE		The UE initiates an attach automatically, by MMI or by AT command.
33	UE		Attach type = 'PS attach'
34	->		Mobile identity = IMSI
35	<-		GMM cause = 'Roaming not allowed in this area'
36	UE		No ATTACH REQUEST sent to SS (SS waits 30 seconds)
37	SS		The following messages are sent and shall be received on cell E. The SS deactivates cell F and activates cell E. Cell E is preferred by the UE.
38	SS		The UE initiates an attach automatically, by MMI or by AT command.
39	UE		No ATTACH REQUEST sent to SS (SS waits 30 seconds).
40	UE		
41	SS		The following messages are sent and shall be received on cell C. The SS deactivates cell E and activates cell C. Cell C is preferred by the UE.
42	SS		The UE initiates an attach automatically, by MMI or by AT command.
43	UE		No ATTACH REQUEST sent to SS (SS waits 30 seconds).
44	UE		
45	SS		The following messages are sent and shall be received on cell A. The SS deactivates cell C and activates cell A. Cell A will be preferred by the UE.
46	SS		The UE initiates an attach automatically, by MMI or by AT command.
47	UE		No ATTACH REQUEST sent to SS (SS waits 30 seconds).
48	UE		

#### 12.2.1.5.4.4 Test procedure4

##### Initial condition

##### System Simulator:

Two cells, cell A in MCC2/MNC1/LAC1/RAC1 (not HPLMN) and cell B in MCC1/MNC1/LAC1/RAC1 (HPLMN).

Both cells are operating in network operation mode II (in case of UE operation mode A), or in network operation mode III (in case of UE operation mode C).

##### User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-2.

##### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode C	Yes/No
UE operation mode A	Yes/No (only if mode C not supported)
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No



## Test procedure

The SS rejects a PS attach with the cause value 'Roaming not allowed in this area. Two cells are then available. The cell with the weakest level belongs to the HPLMN. It is checked that the UE returns to its HPLMN.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	SS			The following messages are sent and shall be received on cell A.
2	UE			The UE is set in UE operation mode C or B (see ICS).
3	SS			The SS is set in network operation mode II or III and activates cell A.
4	UE			The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.
5	->		ATTACH REQUEST	Attach type = 'PS attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-2
6	<-		ATTACH REJECT	GMM cause = 'Roaming not allowed in this area'
7	UE			No ATTACH REQUEST sent to SS (SS waits 30 seconds).
8	SS			The following messages are sent and shall be received on cell B.
9	UE			Activate cell B with a lower signal strength than cell A.
10	UE			The RF level of cell A is lowered until cell B is preferred by the UE.
11	UE			The UE initiates an attach automatically, by MMI or by AT command.
12	->		ATTACH REQUEST	Attach type = 'PS attach'
13	<-		ATTACH ACCEPT	Mobile identity = IMSI Attach result = 'PS only attached'
14	->		ATTACH COMPLETE	Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1
15	UE			The UE is switched off or power is removed (see ICS).
16	->		DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, PS detach'

## 12.2.1.5.5 Test requirements

UE shall:

- initiate a PS attach procedure with information elements specified in the above Expected Sequence when UE is powered up or switched on.
- check the GMM cause which is contained in the ATTACH REJECT message and stop timer T3310.
- not perform PS attach when UE is in the same location area.
- delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.
- store the LA in the 'forbidden location areas for roaming' list.
- perform PS attach when a new location area is entered.
- search for its HPLMN periodically.

When Switched off or when the USIM is removed,

UE shall:

- reset the 'forbidden location areas for roaming' list.

## 12.2.1.6 PS attach / abnormal cases / access barred due to access class control

### 12.2.1.6.1 Definition

### 12.2.1.6.2 Conformance requirement

- 1) The UE shall not perform PS attach procedure, but stays in the current serving cell and applies normal cell reselection process.
- 2) The User Equipment shall perform the PS attach procedure when:
  - 2.1 Access is granted.
  - 2.2 Cell is changed.

### Reference

3G TS 24.008 clause 4.7.3.1

### 12.2.1.6.3 Test purpose

#### Test purpose1

To test the behaviour of the UE in case of access class control (access is granted).

#### Test purpose2

To test the behaviour of the UE in case of access class control (access is granted).

### 12.2.1.6.4 Method of test

#### 12.2.1.6.4.1 Test procedure1

#### Initial condition

A random access class x (0-15) is selected. The USIM is programmed with this access class x. Communication with User Equipments using access class x is initially indicated to be barred.

#### System Simulator:

One cell operating in network operation mode III.  
Access class x barred.

#### User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode C	Yes/No

UE operation mode A      Yes/No

Switch off on button      Yes/No

Automatic PS attach procedure at switch on or power on      Yes/No

### Test procedure

The SS indicates access class x barred. A PS attach procedure is not performed.

The SS indicates that access class x is not barred. A PS attach procedure is performed.

### Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE		ATTACH REQUEST	The USIM is programmed with access class x.
2	UE			The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 12.
3	UE			The UE is powered up or switched on and attempts to initiate an attach (see ICS).
4	UE			No ATTACH REQUEST sent to SS, as access class X is barred (SS waits 30 seconds).
5	SS			The access class x is not barred anymore.
6	UE			The UE automatically initiates a PS attach.
7	->			Attach type = 'PS attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1
8	<-			Attach result = 'PS only attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-1
9	->			The UE is switched off or power is removed (see ICS). Message not sent if power is removed. Detach type = 'power switched off, PS detach'
10	UE			
11	->			
12	SS			The SS is set in network operation mode II.
13	UE			The UE is set in UE operation mode A (see ICS) and the test is repeated from step 2 to step 11.

#### 12.2.1.6.4.2 Test procedure2

##### Initial condition

A random access class x (0-15) is selected. The USIM is programmed with this access class x. Communication with User Equipments using access class x is indicated to be barred on cell A.

##### System Simulator:

Two cells, cell A in MCC1/MNC1/LAC1/RAC1 has access class x barred, cell B in MCC1/MNC1/LAC1/RAC1 has access class x not barred.

Both cells are operating in network operation mode II (in case of UE operation mode A), or in network operation mode III (in case of UE operation mode C).

##### User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-2 signature and RAI-1.

## Related ICS/IXIT statements

Support of PS service Yes/No

UE operation mode C Yes/No

UE operation mode A Yes/No Switch off on button Yes/No

Automatic PS attach procedure at switch on or power on Yes/No

## Test procedure

The SS indicates access class x barred. A PS attach procedure is not performed.

A cell change is performed into a cell where access class x is not barred. A PS attach procedure is performed.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE	SS		The USIM is programmed with access class x. The following messages are sent and shall be received on cell A. The SS is set in network operation mode II or III and activates cell A. The UE is set in UE operation mode C or B (see ICS). The UE is powered up or switched on and attempts to initiate an attach (see ICS). No ATTACH REQUEST sent to SS, as access class X is barred (SS waits 30 seconds).
2		SS		
3	UE			
4	UE			
5	UE			
6		SS	ATTACH REQUEST	The following messages are sent and shall be received on cell B. Activate cell B with a lower signal strength than cell A. The RF level of cell A is lowered until cell B is preferred by the UE. The UE automatically initiates an attach. Attach type = 'PS attach' Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-1 Attach result = 'PS only attached' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1
7	UE			
8	->			
9		<-		
10				
11	UE			
12	->			
			DETACH REQUEST	The UE is switched off or power is removed (see ICS). Message not sent if power is removed. Detach type = 'power switched off, PS detach'

## 12.2.1.6.5 Test requirements

UE shall:

- perform the following actions depending on the UE access class X.

Case 1) The UE access class X is barred,

UE shall:

- not perform a PS attach procedure.

- stay in the current serving cell.
- apply normal cell reselection process.

Case 2) The UE access class X is granted or serving cell is changed,

UE shall:

- initiate PS attach procedure..

## 12.2.1.7 PS attach / abnormal cases / change of cell into new routing area

### 12.2.1.7.1 Definition

### 12.2.1.7.2 Conformance requirement

When a change of cell into a new routing area is performed before ATTACH ACCEPT message is received by the UE, the UE shall abort the PS attach procedure and re-initiate it immediately.

### Reference

3G TS 24.008 clause 4.7.3.1

### 12.2.1.7.3 Test purpose

To test the behaviour of the UE in case of procedure collision.

### 12.2.1.7.4 Method of test

### Initial condition

### System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 and cell B in MCC1/MNC1/LAC1/RAC2.

Both cells are operating in network operation mode II (in case of UE operation mode A), or in network operation mode III (in case of UE operation mode C).

### User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode C	Yes/No
UE operation mode A	Yes/No (only if mode C not supported)
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

### Test procedure

The UE initiates a PS attach procedure. The ATTACH ACCEPT message is delayed from the SS. The UE performs a cell reselection to a cell in a new routing area. The UE shall re-initiate a PS attach procedure in the new routing area.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS	ATTACH REQUEST	The following messages are sent and shall be received on cell A.
2	UE			The UE is set in UE operation mode C or B (see ICS).
3		SS		The SS is set in network operation mode II or III and activates cell A.
4		UE		The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.
5	->			Attach type = 'PS attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1
6		SS	ATTACH REQUEST	No response to the ATTACH REQUEST message is given by the SS.
7		SS		The following messages are sent and shall be received on cell B.
8	UE			The SS deactivates cell A and activates cell B. Cell B is preferred by the UE.
9		UE		The UE automatically re-initiates the attach in the new cell.
10	->			Attach type = 'PS attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1
11	<-		ATTACH ACCEPT	No new mobile identity assigned. P-TMSI and P-TMSI signature not included. Attach result = 'PS only attached' Routing area identity = RAI-4
12	UE		DETACH REQUEST	The UE is switched off or power is removed (see ICS).
13	->			Message not sent if power is removed. Detach type = 'power switched off, PS detach'

## 12.2.1.7.5 Test requirements

UE shall:

- abort a PS attach procedure when a change of cell into a new routing area is performed before ATTACH ACCEPT or ATTACH REJECT message is received by the UE.
- re-initiate a PS attach procedure immediately with new information elements.

## 12.2.1.8 PS attach / abnormal cases / power off

## 12.2.1.8.1 Definition

## 12.2.1.8.2 Conformance requirement

When power is switched off before ATTACH ACCEPT message is received by the UE, the UE shall abort the PS attach procedure and perform a PS detach procedure.

## Reference

3G TS 24.008 clause 4.7.3.

## 12.2.1.8.3 Test purpose

To test the behaviour of the UE in case of procedure collision.

## 12.2.1.8.4 Method of test

## Initial condition

## System Simulator:

One cell operating in network operation mode III.

## User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

## Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode C	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

## Test procedure

The UE is switched off after initiating an attach procedure. A PS detach is automatically performed by the UE before power is switched off.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE		ATTACH REQUEST	The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 7.
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->			Attach type = 'PS attach'
4		SS		Mobile identity = P-TMSI-1
5		UE		P-TMSI-1 signature
6	->		DETACH REQUEST	Routing area identity = RAI-1
7		SS		No response to the ATTACH REQUEST message is given by the SS.
8		UE		The UE is powered off and initiates a PS detach (with power off) by
				Detach type = 'power switched off, PS detach'
				The SS is set in network operation mode II.
				The UE is set in UE operation mode A (see ICS) and the test is repeated from step 2 to step 6.

## 12.2.1.8.5 Test requirements

## UE shall:

- initiate a PS attach procedure with information elements specified in the above Expected Sequence when UE is powered up or switched on.

When power is switched off before ATTACH ACCEPT message is received,

## UE shall:

- abort the PS attach procedure and perform the PS detach procedure.

## 12.2.1.9 PS attach / abnormal cases / PS detach procedure collision

### 12.2.1.9.1 Definition

### 12.2.1.9.2 Conformance requirement

- 1) When a DETACH REQUEST message is received by the UE (any cause except re-attach) while waiting for an ATTACH ACCEPT message, the UE shall terminate the PS attach procedure and continue with the PS detach procedure.
- 2) When a DETACH REQUEST message is received by the UE (cause re-attach) while waiting for an ATTACH ACCEPT message, the UE shall ignore the PS detach procedure and continue with the PS attach procedure.

### Reference

3G TS 24.008 clause 4.7.3.1

### 12.2.1.9.3 Test purpose

To test the behaviour of the UE in case of procedure collision.

### 12.2.1.9.4 Method of test

#### Initial condition

#### System Simulator:

One cell operating in network operation mode II.

#### User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode C	Yes/No
UE operation mode A	Yes/No (only if mode C not supported)
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

### Test procedure

The UE initiates a PS attach procedure. The SS does not answer the PS attach procedure, but initiates a PS detach procedure (any cause except re-attach). The UE shall terminate the PS attach procedure and continue with the PS detach procedure.

The UE initiates a PS attach procedure. The SS does not answer the PS attach procedure, but initiates a PS detach procedure (cause re-attach). The UE shall ignore the PS detach procedure and continue with the PS attach.



## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE		ATTACH REQUEST	The UE is set in UE operation mode C or B (see ICS).
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->			Attach type = 'PS attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1
4	SS		DETACH REQUEST DETACH ACCEPT	The SS ignores the ATTACH REQUEST message and initiates a detach procedure.
5	<-			Detach type = 're-attach not required'
6	->			
7	UE		ATTACH REQUEST	The UE initiates the attach procedure by MMI or AT command.
8	->			Attach type = 'PS attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1
9	SS			The SS ignores the ATTACH REQUEST message and initiates a detach procedure.
10	<-		DETACH REQUEST	Detach type = 're-attach required'
11	UE			The UE ignores the DETACH REQUEST message and continue with the attach procedure.
12	<-			Attach result = 'PS only attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-1
13	->		ATTACH COMPLETE	
14	UE			The UE is switched off or power is removed (see ICS).
15	->			Message not sent if power is removed. Detach type = 'power switched off, PS detach'

## 12.2.1.9.5 Test requirements

UE shall:

initiate a PS attach procedure with information elements specified in the above Expected Sequence when UE is powered up or switched on.

Case1) GMM cause is not re-attach

When a DETACH REQUEST message is received by the UE while waiting for an ATTACH ACCEPT message,

UE shall:

- terminate the PS attach procedure and continue with the PS detach procedure.

Case2) GMM cause is re-attach

When a DETACH REQUEST message is received by the UE while waiting for an ATTACH ACCEPT message,

UE shall:

- ignore the PS detach procedure and continue with the PS attach procedure.

## 12.2.2 Combined PS attach

### 12.2.2.1 Combined PS attach / PS and non-PS attach accepted

#### 12.2.2.1.1 Definition

#### 12.2.2.1.2 Conformance requirement

- 1) If the network accepts the combined PS attach procedure (signalled by an IMSI) and allocates a P-TMSI, the UE shall acknowledge the P-TMSI and continue communication with the P-TMSI.
- 2) If the network accepts the combined PS attach procedure (signalled by P-TMSI) and reallocates a new P-TMSI, the UE shall acknowledge the new P-TMSI and continue communication with the new P-TMSI.
- 3) If the network accepts the combined PS attach procedure (signalled by a P-TMSI) from the UE without reallocation of the previously used P-TMSI, the UE shall continue communication with the previously used P-TMSI.
- 4) If the network accepts the combined PS attach procedure and determines that IMSI shall be used in CS operations, the UE shall continue communication with the IMSI for CS operations.
- 5) If the network accepts the combined PS attach procedure and determines that a TMSI shall be used in CS operations, the UE shall continue communication with the TMSI for CS operations.

#### Reference

3G TS 24.008 clause 4.7.3.2

#### 12.2.2.1.3 Test purpose

To test the behaviour of the UE if the network accepts the PS attach procedure.

The following cases are identified:

- 1) P-TMSI / P-TMSI signature is allocated
- 2) P-TMSI / P-TMSI signature is reallocated
- 3) Old P-TMSI / P-TMSI signature is not changed
- 4) Mobile terminating CS call is allowed with IMSI
- 5) Mobile terminating CS call is not allowed with TMSI

#### 12.2.2.1.4 Method of test

##### Initial condition

##### System Simulator:

One cell operating in network operation mode I.

##### User Equipment:

The UE has a valid IMSI.

##### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No

Switch off on button      Yes/No

Automatic PS attach procedure at switch on or power on      Yes/No

#### Test procedure

- 1) The UE sends an ATTACH REQUEST message with identity IMSI. The SS allocates a P-TMSI and returns ATTACH ACCEPT message with a P-TMSI. The UE acknowledges the P-TMSI by sending ATTACH COMPLETE message. Further communication UE - SS is performed by the new P-TMSI. For CS calls, the IMSI is used.
- 2) The UE is CS paged in order to verify that the IMSI is used for CS calls.
- 3) The UE is PS paged in order to verify that the new P-TMSI is used for PS services.
- 4) The UE sends an ATTACH REQUEST message with identity P-TMSI. The SS allocates a new P-TMSI and returns ATTACH ACCEPT message with the new P-TMSI and a new TMSI. The UE acknowledges the P-TMSI and the TMSI by sending ATTACH COMPLETE message. Further communication UE - SS is performed by the new P-TMSI. For CS calls, the new TMSI is used. The UE is CS paged in order to verify that the new TMSI is used for CS services.
- 5) The UE is PS paged in order to verify that the new P-TMSI is used for PS services. The UE will not answer signalling addressed to the old P-TMSI.
- 6) The UE sends an ATTACH REQUEST message with identity P-TMSI. The SS accepts the P-TMSI and returns ATTACH ACCEPT message without any P-TMSI. Further communication UE - SS is performed by the previously used P-TMSI.
- 7) The UE is PS paged in order to verify that the previously used P-TMSI is used for PS services.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The UE is set in UE operation mode A (see ICS).
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI
4	<-		ATTACH ACCEPT	TMSI status = no valid TMSI available Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-1 P-TMSI-1 signature Mobile identity = IMSI Routing area identity = RAI-1
5	->		ATTACH COMPLETE	
6	<-		PAGING REQUEST TYPE 1	Mobile identity = IMSI Paging order is for RRC-connection.
7	->		CHANNEL REQUEST	
8	<-		IMMEDIATE ASSIGNMENT	
9	->		PAGING RESPONSE	Mobile identity = IMSI
10	<-		CHANNEL RELEASE	After sending of this message, the SS waits for disconnection of the CS signalling link.
11	<-		PACKET PAGING REQUEST	Mobile identity = P-TMSI-1 Paging order is for TBF establishment. Comment: A TBF will be established on lower layers.
12	->		UPLINK RLC DATA BLOCK	LLC PDU implicitly indicating paging response. Comment: The TBF will be released on lower layers.
13	UE			The UE is switched off or power is removed (see ICS).
14	->		DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, combined PS / IMSI detach'
15	UE			The UE is powered up or switched on and initiates an attach (see ICS).
16	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature
17	<-		ATTACH ACCEPT	TMSI status = no valid TMSI available Routing area identity = RAI-1 Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature Mobile identity = TMSI-1 Routing area identity = RAI-1
18	->		ATTACH COMPLETE	
19	<-		GMM INFORMATION	Message sent with P-TMSI-2
19b	->		GMM STATUS	Message sent in case the UE does not support reception of GMM information message Cause #97
20	<-		PAGING REQUEST TYPE 1	Mobile identity = TMSI-1 Paging order is for RRC-connection.
21	->		CHANNEL REQUEST	
22	<-		IMMEDIATE ASSIGNMENT	
23	->		PAGING RESPONSE	Mobile identity = TMSI-1
24	<-		CHANNEL RELEASE	After sending of this message, the SS waits for disconnection of the CS signalling link.
25	<-		PACKET PAGING REQUEST	Mobile identity = P-TMSI-2 Paging order is for TBF establishment.
26	->		UPLINK RLC DATA BLOCK	LLC PDU implicitly indicating paging response.
27	<-		PACKET PAGING REQUEST	Mobile identity = P-TMSI-1 Paging order is for TBF establishment.
28	UE			No response from the UE to the request. This is checked for 10 seconds.

29	UE		The UE is switched off or power is removed (see ICS).
30	->	DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, combined PS / IMSI detach'
31	UE		The UE is powered up or switched on and initiates an attach (see ICS).
32	->	ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-1 TMSI status = valid TMSI available
33	<-	ATTACH ACCEPT	No new mobile identity assigned. TMSI and P-TMSI not included. Attach result = 'Combined PS / IMSI attached' P-TMSI-3 signature Routing area identity = RAI-1
34	<-	PACKET PAGING REQUEST	Mobile identity = P-TMSI-2 Paging order is for TBF establishment.
35	->	UPLINK RLC DATA BLOCK	LLC PDU implicitly indicating paging response.
36	UE		The UE is switched off or power is removed (see ICS).
37	->	DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, combined PS / IMSI detach'

#### 12.2.2.1.5 Test requirements

UE shall:

- initiate a PS attach procedure with information elements specified in the above Expected Sequence when UE is powered up or switched on.

Case 1) SS accept the combined PS attach procedure (signalled by an IMSI) and allocates a P-TMSI.

UE shall

- acknowledge the P-TMSI and continue communication with the P-TMSI.

Case 2) SS accepts the combined PS attach procedure (signalled by P-TMSI) and reallocates a new P-TMSI.

UE shall:

- acknowledge the new P-TMSI and continue communication with the new P-TMSI.

Case 3) SS accepts the combined PS attach procedure (signalled by a P-TMSI) from the UE without reallocation of the previously used P-TMSI.

UE shall:

- continue communication with the previously used P-TMSI.

Case 4) SS accepts the combined PS attach procedure and determines that IMSI shall be used in CS operations.

UE shall:

- continue communication with the IMSI for CS operations.

Case 5) SS accepts the combined PS attach procedure and determines that a TMSI shall be used in CS operations.

UE shall:

- continue communication with the TMSI for CS operations.

## 12.2.2.2 Combined PS attach / PS only attach accepted

### 12.2.2.2.1 Definition

### 12.2.2.2.2 Conformance requirement

- 1) If the network accepts the combined PS attach procedure, but GMM cause code 'IMSI unknown in HLR' is sent to the UE the User Equipment shall delete the stored TMSI, LAI and CKSN. The User Equipment shall consider USIM invalid for non-PS services until power is switched off or USIM is removed.
- 2) If the network accepts the combined PS attach procedure, but GMM cause code 'MSC temporarily not reachable', 'Network failure' or 'Congestion' is sent to the UE, an UE operation mode A UE may perform an MM IMSI attach procedure.

### Reference

3G TS 24.008 clause 4.7.3.2

### 12.2.2.2.3 Test purpose

#### Test propose1

To test the behaviour of the UE if the network accepts the PS attach procedure with indication PS only, GMM cause 'IMSI unknown in HLR'.

#### Test porpose2

To test the behaviour of the UE if the network accepts the PS attach procedure with indication PS only, GMM cause 'MSC temporarily not reachable', 'Network failure' or 'Congestion'.

### 12.2.2.2.4 Method of test

#### 12.2.2.2.4.1 Test porpose1

#### Initial condition

##### System Simulator:

One cell operating in network operation mode I.

##### User Equipment:

The UE has a valid IMSI.

### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

### Test procedure

The UE sends an ATTACH REQUEST message with identity IMSI. The SS allocates a P-TMSI and returns ATTACH ACCEPT message with a P-TMSI. GMM cause 'IMSI unknown in HLR' is indicated from SS. Further communication UE - SS is performed by the P-TMSI. CS services are not possible.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The UE is set in UE operation mode A.
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI
4	<-		ATTACH ACCEPT	TMSI status = no valid TMSI available Attach result = 'PS only attached' Mobile identity = P-TMSI-1 P-TMSI-1 signature GMM cause = 'IMSI unknown in HLR'
5	->		ATTACH COMPLETE	
6	<-		PACKET PAGING REQUEST	Mobile identity = IMSI Paging order is for RRC-connection.
7	UE			The UE shall not initiate an RRC connection. This is checked during 3 seconds.
8	UE			The UE is switched off or power is removed (see ICS).
9	->		DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, PS detach'

## 12.2.2.2.4.2 Test purpose2

## Initial condition

## System Simulator:

One cell operating in network operation mode I.

## User Equipment:

The UE has a valid TMSI, P-TMSI, P-TMSI signature and RAI.

## Related ICS/IXIT statements

Support of PS service      Yes/No  
 UE operation mode A      Yes/No  
 Automatic MM IMSI attach procedure for UE operation mode A UE      Yes/No  
 Switch off on button      Yes/No  
 Automatic PS attach procedure at switch on or power on      Yes/No

## Test procedure

The UE sends an ATTACH REQUEST message. The SS allocates a P-TMSI and returns ATTACH ACCEPT message with a P-TMSI. GMM cause 'MSC temporarily not reachable', 'Network failure' or 'Congestion' is indicated from SS. The cause code is arbitrarily chosen. This procedure is repeated four times. An UE operation mode A UE may then perform an MM IMSI attach procedure (according to the ICS statement). Further communication UE - SS is performed by the P-TMSI. The existence of a signalling channel is verified by a request for mobile identity. CS services are not possible as an IMSI attach procedure is not performed.

## Expected Sequence

Dependent whether the option 'Automatic MM IMSI attach procedure for UE operation mode A UE' is supported or not, the steps 1-22 or 23-53 apply depending on manufacturer (see ICS).

Step	Direction		Message	Comments
	UE	SS		
1	UE			The UE is set in UE operation mode A and no automatic MM IMSI attach procedure is indicated (see ICS).
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1 TMSI status = valid TMSI available
4	<-		ATTACH ACCEPT	Attach result = 'PS only attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature  Routing area identity = RAI-1 GMM cause = 'MSC temporarily not reachable', 'Network failure' or 'Congestion' (arbitrarily chosen)
5	->		ATTACH COMPLETE	
7	->		ROUTING AREA UPDATE REQUEST	Update type = 'Combined RA / LA updating with IMSI attach' P-TMSI-2 signature Routing area identity = RAI-1 TMSI status = no valid TMSI available
8	<-		ROUTING AREA UPDATE ACCEPT	No new mobile identity assigned. P-TMSI not included. Update result = 'RA updated' P-TMSI-3 signature Routing area identity = RAI-1 GMM cause = 'MSC temporarily not reachable', 'Network failure' or 'Congestion' (arbitrarily chosen)
10	->		ROUTING AREA UPDATE REQUEST	Update type = 'Combined RA / LA updating with IMSI attach' P-TMSI-3 signature Routing area identity = RAI-1 TMSI status = no valid TMSI available
11	<-		ROUTING AREA UPDATE ACCEPT	No new mobile identity assigned. P-TMSI not included. Update result = 'RA updated' P-TMSI-4 signature Routing area identity = RAI-1 GMM cause = 'MSC temporarily not reachable', 'Network failure' or 'Congestion' (arbitrarily chosen)
12	SS			The SS verifies that the time between the requests are T3311
13	->		ROUTING AREA UPDATE REQUEST	Update type = 'Combined RA / LA updating with IMSI attach' P-TMSI-4 signature Routing area identity = RAI-1 TMSI status = no valid TMSI available
14	<-		ROUTING AREA UPDATE ACCEPT	No new mobile identity assigned. P-TMSI not included. Update result = 'RA updated' P-TMSI-5 signature Routing area identity = RAI-1 GMM cause = 'MSC temporarily not reachable', 'Network failure' or 'Congestion' (arbitrarily chosen)
16	->		ROUTING AREA UPDATE REQUEST	Update type = 'Combined RA / LA updating with IMSI attach' P-TMSI-5 signature Routing area identity = RAI-1 TMSI status = no valid TMSI available



17	<-	ROUTING AREA UPDATE ACCEPT	No new mobile identity assigned. P-TMSI not included. Update result = 'RA updated' P-TMSI-6 signature Routing area identity = RAI-1 GMM cause = 'MSC temporarily not reachable', 'Network failure' or 'Congestion' (arbitrarily chosen)
19	<-	PACKET PAGING REQUEST	Mobile identity = IMSI
20	UE		Paging order is for RRC-connection.
21	UE		The UE shall not initiate an RRC connection. This is checked during 3 seconds.
22	->		The UE is switched off or power is removed (see ICS).
22	->	DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, PS detach'. Stop the sequence.
23	UE	ATTACH REQUEST	Automatic MM IMSI attach procedure is indicated (see ICS).
24	UE		The UE is powered up or switched on and initiates an attach (see ICS).
25	->		Attach type = 'Combined PS / IMSI attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1
26	<-		TMSI status = valid TMSI available No new mobile identity assigned. P-TMSI not included. Attach result = 'PS only attached' P-TMSI-2 signature Routing area identity = RAI-1
28	->	ROUTING AREA UPDATE REQUEST	GMM cause = 'MSC temporarily not reachable', 'Network failure' or 'Congestion' (arbitrarily chosen) Update type = 'Combined RA / LA updating with IMSI attach' P-TMSI-2 signature Routing area identity = RAI-1
29	<-	ROUTING AREA UPDATE ACCEPT	TMSI status = no valid TMSI available No new mobile identity assigned. P-TMSI not included. Update result = 'RA updated' P-TMSI-3 signature Routing area identity = RAI-1
31	->	ROUTING AREA UPDATE REQUEST	GMM cause = 'MSC temporarily not reachable', 'Network failure' or 'Congestion' (arbitrarily chosen) Update type = 'Combined RA / LA updating with IMSI attach' P-TMSI-3 signature Routing area identity = RAI-1
32	<-	ROUTING AREA UPDATE ACCEPT	TMSI status = no valid TMSI available No new mobile identity assigned. P-TMSI not included. Update result = 'RA updated' P-TMSI-4 signature Routing area identity = RAI-1
33	SS	ROUTING AREA UPDATE REQUEST	GMM cause = 'MSC temporarily not reachable', 'Network failure' or 'Congestion' (arbitrarily chosen) The SS verifies that the time between the requests are T3311
34	->		Update type = 'Combined RA / LA updating with IMSI attach' P-TMSI-4 signature Routing area identity = RAI-1 TMSI status = no valid TMSI available

35	<-	ROUTING AREA UPDATE ACCEPT	No new mobile identity assigned. P-TMSI not included. Update result = 'RA updated' P-TMSI-5 signature Routing area identity = RAI-1 GMM cause = 'MSC temporarily not reachable', 'Network failure' or 'Congestion' (arbitrarily chosen)
37	->	ROUTING AREA UPDATE REQUEST	Update type = 'Combined RA / LA updating with IMSI attach' P-TMSI-5 signature Routing area identity = RAI-1 TMSI status = no valid TMSI available
38	<-	ROUTING AREA UPDATE ACCEPT	No new mobile identity assigned. P No new mobile identity assigned. P-TMSI not included. Update result = 'RA updated' P-TMSI-6 signature Routing area identity = RAI-1 GMM cause = 'MSC temporarily not reachable', 'Network failure' or 'Congestion' (arbitrarily chosen)
39	SS		The SS verifies that the time between the requests are T3311
40	UE		An automatic MM IMSI attach procedure is initiated.
41	->	CHANNEL REQUEST	
42	<-	IMMEDIATE ASSIGNMENT	
43	->	LOCATION UPDATING REQ	Location updating type = IMSI attach.
44	<-	LOCATION UPDATING ACC	The SS allocates a new TMSI.
45	->	TMSI REALLOCATION COMP	Location updating type = IMSI attach.
46	<-	CHANNEL RELEASE	After sending of this message, the SS waits for disconnection of the CS signalling link.
47	<-	PACKET PAGING REQUEST	Mobile identity = TMSI-1 Paging order is for RRC-connection.
48	->	CHANNEL REQUEST	
49	<-	IMMEDIATE ASSIGNMENT	
50	->	PAGING RESPONSE	Mobile identity = TMSI-1
51	<-	CHANNEL RELEASE	After sending of this message, the SS waits for disconnection of the CS signalling link.
52	UE		The UE is switched off or power is removed (see ICS).
53	->	DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, PS detach'

#### 12.2.2.2.5 Test requirements

UE shall:

- initiate a Combined PS attach procedure with information elements specified in the above Expected Sequence when UE is powered up or switched on.
- check the GMM cause which is contained in the ATTACH ACCEPT message received from SS.
- perform the following actions depending on the GMM cause.

Case1) GMM cause = 'IMSI unknown in HLR'

UE shall

- delete stored TMSI, LAI, and ciphering key sequence number.
- consider USIM invalid for non-PS service until power is switching off or USIM is removed.

Case2) GMM cause = 'MSC temporarily not reachable' or 'Network failure' or 'Congestion',

UE shall:

- stop the timer T3310(if running), and shall increment the routing area update attempt counter.
- perform the following actions depending on the conditions described below.

Case 2-1) the routing area updating attempt counter is less than 5 and the stored RAI is equal to the RAI of the current serving cell and the GMM update status is equal to GU1 UPDATED:

UE shall

- keep the GMM update status GU1 UPDATED.
- change state to GMM-REGISTERED.ATTEMPTING-TO-UPDATE-MM.
- start timer T3311. When timer T3311 expires, the combined routing area update procedure indicating “combined RA/LA updating with IMSI attach” is triggered again.

Case 2-2) the routing area updating attempt counter is greater than or equal to 5

UE shall

- start timer T3302 and change state to GMM-REGISTERED.ATTEMPTING-TO-UPDATE-MM

### 12.2.2.3 Combined PS attach / PS attach while IMSI attach

#### 12.2.2.3.1 Definition

#### 12.2.2.3.2 Conformance requirement

If the PS UE is already attached for non-PS services by the MM specific attach procedure, but wants to perform an attach for PS services, the combined PS attach procedure is performed.

#### Reference

3G TS 24.008 clause 4.7.3.2

#### 12.2.2.3.3 Test purpose

To test the behaviour of the UE if PS attach performed while IMSI attached.

#### 12.2.2.3.4 Method of test

#### Initial condition

#### System Simulator:

One cell operating in network operation mode I. ATT flag is set.

#### User Equipment:

The UE has a valid TMSI-1, P-TMSI-1, P-TMSI signature and RAI-1.

#### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

## Test procedure

The UE attach for non-PS services. The UE does not answer to paging orders for PS. The UE attach for PS services. Paging orders for PS are answered.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The UE is set in UE operation mode C (see ICS) and configured not to perform a PS attach.
2	UE			The UE is powered up or switched on. No PS attach is performed (see ICS).
3	->		CHANNEL REQUEST	
4	<-		IMMEDIATE ASSIGNMENT	
5	->		LOCATION UPDATING REQ	Location updating type = IMSI attach.
6	<-		LOCATION UPDATING ACC	The SS allocates a new TMSI.
7	->		TMSI REALLOCATION COMP	Location updating type = IMSI attach.
8	<-		CHANNEL RELEASE	After sending of this message, the SS waits for disconnection of the CS signalling link.
9	<-		PACKET PAGING REQUEST	Mobile identity = P-TMSI-1
10	UE			Paging order is for TBF establishment.
				No response from the UE to the request. This is checked for 10 seconds.
11	UE			The UE is triggered to perform a PS attach (in combination with IMSI attach).
12	->		ATTACH REQUEST	Attach type = 'PS attach while IMSI attached' Mobile identity = P-TMSI-1 P-TMSI-1 signature Mobile identity = TMSI-1 Routing area identity = RAI-1
13	<-		ATTACH ACCEPT	TMSI status = valid TMSI available Attach result = 'Combined PS / IMSI attached' No new mobile identity assigned. TMSI and P-TMSI not included P-TMSI-2 signature Routing area identity = RAI-1
14	->		ATTACH COMPLETE	
15	<-		PACKET PAGING REQUEST	Mobile identity = P-TMSI-1
16	->		UPLINK RLC DATA BLOCK	Paging order is for TBF establishment. LLC PDU implicitly indicating paging response.
17	UE			The UE is switched off or power is removed (see ICS).
18	->		DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, combined PS / IMSI detach'

## 12.2.2.3.5 Test requirements

UE is already attached for non-PS service with the MM specific attach procedure.

UE shall:

- perform the combined PS attach procedure when UE want to attach for PS service.

## 12.2.2.4 Combined PS attach / rejected / IMSI invalid / illegal ME

### 12.2.2.4.1 Definition

### 12.2.2.4.2 Conformance requirement

- 1) If the network rejects a combined PS attach procedure from the User Equipment with the cause 'Illegal ME', the User Equipment shall consider USIM invalid for PS and non-PS services until power is switched off or USIM is removed.
- 2) If the network rejects a combined PS attach procedure from the User Equipment with the cause 'Illegal ME', the User Equipment shall delete the stored TMSI, LAI, CSKN, RAI, PS-CSKN, P-TMSI and P-TMSI signature.

### Reference

3G TS 24.008 clause 4.7.3.2

### 12.2.2.4.3 Test purpose

To test the behaviour of the UE if the network rejects the combined PS attach procedure of the UE with the cause 'Illegal ME'.

### 12.2.2.4.4 Method of test

#### Initial condition

#### System Simulator:

Three cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2, cell C in MCC2/MNC1/LAC1/RAC1.  
All three cells are operating in network operation mode I.

#### User Equipment:

The UE has a valid TMSI, P-TMSI, P-TMSI signature and RAI.

### Related ICS/IXIT statements

Support of PS service	Yes/No	
UE operation mode A	Yes/No	
USIM removal possible without powering down		Yes/No
Switch off on button	Yes/No	
Automatic PS attach procedure at switch on or power on		Yes/No

### Test procedure

The SS rejects a PS attach with the cause value 'Illegal ME'. The SS checks that the UE does not perform PS attach in the same or another PLMN. CS services are not possible as the USIM is blocked for CS services. PS services are not possible as the USIM is blocked for PS services.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	SS	ATTACH REQUEST	The following messages are sent and shall be received on cell A. The SS activates cell A. The UE is set in UE operation mode A (see ICS). The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE. Attach type = 'Combined PS / IMSI attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1 TMSI status = valid TMSI available GMM cause 'Illegal ME'. Mobile identity = IMSI Paging order is for RRC-connection. The UE shall not initiate an RRC connection. This is checked during 3 seconds.	
2	UE			
3	UE			
4	->			
5	<-			ATTACH REJECT
6	<-			PACKET PAGING REQUEST
7	UE			
8	<-			PACKET PAGING REQUEST
9	UE			
10	SS	PACKET PAGING REQUEST	The following messages are sent and shall be received on cell B. The SS deactivates cell A and activates cell B. Cell B is preferred by the UE. No ATTACH REQUEST sent to the SS (SS waits 30 seconds). Mobile identity = IMSI Paging order is for RRC-connection. The UE shall not initiate an RRC connection. This is checked during 3 seconds.	
11	UE			
12	UE			
13	<-			
14	UE			
15	SS	PACKET PAGING REQUEST	The following messages are sent and shall be received on cell C. The SS deactivates cell B and activates cell C. Cell C is preferred by the UE. No ATTACH REQUEST sent to the SS (SS waits 30 seconds). Mobile identity = IMSI Paging order is for TBF establishment. No response from the UE to the request. This is checked for 10seconds. If possible (see ICS) USIM removal is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed.	
16	UE			
17	UE			
18	<-			
19	UE			
20	UE			
21	UE	ATTACH REQUEST	The UE gets the USIM replaced, is powered up or switched on and initiates an attach (see ICS). Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI TMSI status = no valid TMSI available Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-1 P-TMSI-1 signature Mobile identity = TMSI-1 Routing area identity = RAI-2	
22	->			
23	<-			ATTACH ACCEPT
24	->			ATTACH COMPLETE
25	<-			PACKET PAGING REQUEST
26	->			CHANNEL REQUEST
27	<-			IMMEDIATE ASSIGNMENT

28	->	PAGING RESPONSE	Mobile identity = TMSI-1 After sending of this message, the SS waits for disconnection of the CS signalling link. The UE is switched off or power is removed (see ICS).
29	<-	CHANNEL RELEASE	
30	UE		
31	->	DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, combined PS / IMSI detach'

#### 12.2.2.4.5 Test requirements

UE shall:

- initiate a combined PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.
- check the GMM cause which is contained in the ATTACH REJECT message and stop the timer T3310.
- set the PS update status to GU3 ROAMING NOT ALLOWED.
- delete the stored P-TMSI, P-TMSI signature, RAI and PS ciphering key sequence number.
- consider USIM invalid for PS and non-PS services until power is switched off or USIM is removed.

#### 12.2.2.5 Combined PS attach / rejected / PS services and non-PS services not allowed

##### 12.2.2.5.1 Definition

##### 12.2.2.5.2 Conformance requirement

- 1) If the network rejects a combined PS attach procedure from the User Equipment with the cause 'PS services and non-PS services not allowed', the User Equipment shall consider USIM invalid for PS and non-PS services until power is switched off or USIM is removed.
- 2) If the network rejects a combined PS attach procedure from the User Equipment with the cause 'PS services and non-PS services not allowed', the User Equipment shall delete the stored TMSI, LAI, CSKN, RAI, PS-CKSN, P-TMSI and P-TMSI signature.

#### Reference

3G TS 24.008 clause 4.7.3.2

##### 12.2.2.5.3 Test purpose

To test the behaviour of the UE if the network rejects the combined PS attach procedure of the UE with the cause 'PS services and non-PS services not allowed'.

##### 12.2.2.5.4 Method of test

#### Initial condition

#### System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 and cell B in MCC2/MNC1/LAC1/RAC1.  
Both cells are operating in network operation mode I.

User Equipment:

The UE has a valid TMSI, P-TMSI, P-TMSI signature and RAI.

#### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

#### Test procedure

The SS rejects a PS attach with the cause value 'PS services and non-PS services not allowed'. The SS checks that the UE does not perform PS attach in the same or another PLMN. CS services are not possible as the USIM is blocked for CS services. PS services are not possible as the USIM is blocked for PS services.



## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		<p>The following messages are sent and shall be received on cell A.</p> <p>The SS activates cell A.</p> <p>The UE is set in UE operation mode A (see ICS).</p> <p>The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.</p> <p>Attach type = 'Combined PS / IMSI attach'</p> <p>Mobile identity = P-TMSI-1</p> <p>P-TMSI-1 signature</p> <p>Routing area identity = RAI-1</p> <p>TMSI status = valid TMSI available</p> <p>GMM cause 'PS services and non-PS services not allowed'</p> <p>No LOCATION UPDATING REQ with type 'IMSI attach' is sent to the SS</p> <p>(SS waits 30 seconds).</p> <p>Mobile identity = IMSI</p> <p>Paging order is for RRC-connection.</p> <p>The UE shall not initiate an RRC connection.</p> <p>This is checked during 3 seconds.</p> <p>Mobile identity = P-TMSI-1</p> <p>Paging order is for TBF establishment.</p> <p>No response from the UE to the request.</p> <p>This is checked for 10 seconds</p>
2	UE			
3	UE			
4	->		ATTACH REQUEST	
5	<-		ATTACH REJECT	
6	UE			
7	<-		PACKET PAGING REQUEST	
8	UE			
9	<-		PACKET PAGING REQUEST	
10	->			
11	UE			<p>Cell B is preferred by the UE.</p> <p>No ATTACH REQUEST sent to the SS</p> <p>(SS waits 30 seconds).</p> <p>No LOCATION UPDATING REQ with type 'IMSI attach' is sent to the SS</p> <p>(SS waits 30 seconds).</p> <p>Mobile identity = IMSI</p> <p>Paging order is for RRC-connection.</p> <p>The UE shall not initiate an RRC connection.</p> <p>This is checked during 3 seconds.</p> <p>Mobile identity = TMSI-1</p> <p>Paging order is for TBF establishment.</p> <p>No response from the UE to the request. This is checked for 10seconds.</p> <p>If possible (see ICS) switch off is performed.</p> <p>Otherwise the power is removed.</p>
12	UE			
13	UE			
14	<-		PACKET PAGING REQUEST	
15	UE			
16	<-		PACKET PAGING REQUEST	
17	UE			
18	UE			
19	UE			<p>The UE is powered up or switched on and initiates an attach (see ICS).</p> <p>Attach type = 'Combined PS / IMSI attach'</p> <p>Mobile identity = IMSI</p> <p>TMSI status = no valid TMSI available</p> <p>Attach result = 'Combined PS / IMSI attached'</p> <p>Mobile identity = P-TMSI-1</p> <p>P-TMSI-1 signature</p> <p>Mobile identity = TMSI-1</p> <p>Routing area identity = RAI-2</p> <p>Mobile identity = TMSI-1</p> <p>Paging order is for RRC-connection.</p> <p>Mobile identity = TMSI-1</p> <p>After sending of this message, the SS waits for disconnection of the CS signalling link.</p> <p>Mobile identity = TMSI-1</p> <p>Paging order is for TBF establishment.</p> <p>LLC PDU implicitly indicating paging response.</p>
20	->		ATTACH REQUEST	
21	<-		ATTACH ACCEPT	
22	->		ATTACH COMPLETE	
23	<-		PACKET PAGING REQUEST	
24	->		CHANNEL REQUEST	
25	<-		IMMEDIATE ASSIGNMENT	
26	->		PAGING RESPONSE	
27	<-		CHANNEL RELEASE	
28	<-		PACKET PAGING REQUEST	
29	->		UPLINK RLC DATA BLOCK	

30	UE		The UE is switched off or power is removed (see ICS).
31	->	DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, combined PS / IMSI detach'

#### 12.2.2.5.5 Test requirements

UE shall:

- initiate a combined PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.
- check the GMM cause which is contained in the ATTACH REJECT message and stop the timer T3310.
- set the PS update status to GU3 ROAMING NOT ALLOWED.
- delete the stored P-TMSI, P-TMSI signature, RAI and PS ciphering key sequence number.
- consider USIM invalid for PS and non-PS services until power is switched off or USIM is removed.

#### 12.2.2.6 Combined PS attach / rejected / PS services not allowed

##### 12.2.2.6.1 Definition

##### 12.2.2.6.2 Conformance requirement

- 1) If the network rejects a combined PS attach procedure from the User Equipment with the cause 'PS services not allowed', the User Equipment shall consider USIM invalid for PS services until power is switched off or USIM is removed.
- 2) If the network rejects a combined PS attach procedure from the User Equipment with the cause 'PS services not allowed' the User Equipment shall delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.
- 3) A PS class AUE shall perform an MM IMSI attach procedure.

#### Reference

3G TS 24.008 clause 4.7.3.2

##### 12.2.2.6.3 Test purpose

To test the behaviour of the UE if the network rejects the PS attach procedure of the UE with the cause 'PS services not allowed'.

##### 12.2.2.6.4 Method of test

#### Initial condition

#### System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 and cell B in MCC2/MNC1/LAC1/RAC1.  
Both cells are operating in network operation mode I.

#### User Equipment:

The UE has a valid TMSI, P-TMSI, P-TMSI signature and RAI.

## Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

## Test procedure

The SS rejects a normal attach with the cause value 'PS services not allowed'. The SS checks that the UE does not perform PS attach. PS services are not possible. An UE operation mode A UE shall perform an MM IMSI attach.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		<p>The following messages are sent and shall be received on cell A.</p> <p>The SS activates cell A.</p> <p>The UE is powered up or switched on and initiates an attach (see ICS).</p> <p>Attach type = 'Combined PS / IMSI attach'</p> <p>Mobile identity = P-TMSI-1</p> <p>P-TMSI-1 signature</p> <p>Routing area identity = RAI-2</p> <p>TMSI status = valid TMSI available</p> <p>GMM cause 'PS services not allowed'</p> <p>An automatic MM IMSI attach procedure is initiated.</p>
2		UE		
3		->	ATTACH REQUEST	
4		<-	ATTACH REJECT	
5		UE		
6		->	CHANNEL REQUEST	
7		<-	IMMEDIATE ASSIGNMENT	
8		->	LOCATION UPDATING REQ	
9		<-	LOCATION UPDATING ACC	
0		->	TMSI REALLOCATION COMP	
11		<-	CHANNEL RELEASE	
12		<-	PACKET PAGING REQUEST	
13		->	CHANNEL REQUEST	
14		<-	IMMEDIATE ASSIGNMENT	
15		->	PAGING RESPONSE	
16		<-	CHANNEL RELEASE	
17		SS		<p>The following messages are sent and shall be received on cell B.</p> <p>The SS deactivates cell A and activates cell B.</p> <p>Cell B is preferred by the UE.</p> <p>A location updating procedure is initiated.</p>
18		UE		
19		UE		
20		->	CHANNEL REQUEST	
21		<-	IMMEDIATE ASSIGNMENT	
22		->	LOCATION UPDATING REQ	
23		<-	LOCATION UPDATING ACC	
24		->	TMSI REALLOCATION COMP	
25		<-	CHANNEL RELEASE	
26		<-	PACKET PAGING REQUEST	
27		->	CHANNEL REQUEST	
28		<-	IMMEDIATE ASSIGNMENT	
29		->	PAGING RESPONSE	
30		<-	CHANNEL RELEASE	
31		<-	PACKET PAGING REQUEST	
32		UE		
33		UE		
34		UE		<p>The UE is powered up or switched on and initiates an attach (see ICS).</p>
35		->	ATTACH REQUEST	
36		<-	ATTACH ACCEPT	
37		->	ATTACH COMPLETE	

38	<-	PACKET PAGING REQUEST	Mobile identity = TMSI-2 Paging order is for RRC-connection.
39	->	CHANNEL REQUEST	
40	<-	IMMEDIATE ASSIGNMENT	
41	->	PAGING RESPONSE	Mobile identity = TMSI-2
42	<-	CHANNEL RELEASE	After sending of this message, the SS waits for disconnection of the CS signalling link.
43	UE		The UE is switched off or power is removed (see ICS).
44	->	DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, combined PS / IMSI detach'

#### 12.2.2.6.5 Test requirements

UE shall:

- initiate a combined PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.
- check the GMM cause which is contained in the ATTACH REJECT message and stop the timer T3310.
- set the PS update status to GU3 ROAMING NOT ALLOWED.
- delete stored P-TMSI, P-TMSI signature, RAI and PS ciphering key sequence number.
- consider USIM invalid for PS services until power is switched off or USIM is removed.
- perform an MM IMSI attach procedure, if the UE is PS class A.

#### 12.2.2.7 Combined PS attach / rejected / location area not allowed

##### 12.2.2.7.1 Definition

##### 12.2.2.7.2 Conformance requirement

- 1) If the network rejects a combined PS attach procedure from the User Equipment with the cause 'location area not allowed' the User Equipment shall:
  - 1.1 not perform combined PS attach when in the same location area.
  - 1.2 delete the stored LAI, CKSN, TMSI, RAI, PS-CKSN, P-TMSI and P-TMSI signature.
  - 1.3 store the LA in the 'forbidden location areas for regional provision of service'.
- 2) If the network rejects a combined PS attach procedure from the User Equipment with the cause 'location area not allowed' the User Equipment shall:
  - 2.1 perform combined PS attach when a new location area is entered.
  - 2.2 delete the list of forbidden LAs when power is switched off.

#### Reference

3G TS 24.008 clauses 4.7.3.2

##### 12.2.2.7.3 Test purpose

To test the behaviour of the UE if the network rejects the combined PS attach procedure with the cause 'Location Area not allowed'.

To test that the UE deletes the list of forbidden LAs when power is switched off.

#### 12.2.2.7.4 Method of test

Initial condition

System Simulator:

Three cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2, cell C in MCC1/MNC1/LAC2/RAC1.  
All cells are operating in network operation mode I.

User Equipment:

The UE has a valid TMSI, P-TMSI, P-TMSI signature and RAI.

Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

Test procedure

The SS rejects a combined PS attach with the cause value 'Location Area not allowed'. The SS checks that the UE does not perform combined PS attach while in the location area, performs PS attach when a new location area is entered and deletes the list of forbidden LAs when switched off. CS services are not possible unless an IMSI attach procedure is performed.

Different types of UE may use different methods to periodically clear the list of forbidden location areas (e.g. every day at 12am). If the list is cleared while the test is being run, it may be necessary to re-run the test.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		The following messages are sent and shall be received on cell A.
2		SS		The SS activates cell A.
3		UE		The UE is set in UE operation mode A (see ICS).
4		UE		The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.
5	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1 TMSI status = valid TMSI available
6	<-		ATTACH REJECT	GMM cause 'Location Area not allowed' No LOCATION UPDATING REQ with type 'IMSI attach' is sent to the SS (SS waits 30 seconds).
7	<-		PACKET PAGING REQUEST	Mobile identity = TMSI Paging order is for RRC-connection.
8	UE			The UE shall not initiate an RRC connection.
9	<-		PACKET PAGING REQUEST	This is checked during 3 seconds. Mobile identity = P-TMSI-1 Paging order is for TBF establishment.
10	->			No response from the UE to the request. This is checked for 10 seconds
11		SS		The following messages are sent and shall be received on cell B.
12		SS		The SS deactivates cell A and activates cell B.
13		UE		Cell B is preferred by the UE.
14		UE		No ATTACH REQUEST sent to SS (SS waits 30 seconds)
15		UE		No LOCATION UPDATING REQ with type 'IMSI attach' is sent to the SS (SS waits 30 seconds).
16	<-		PACKET PAGING REQUEST	Mobile identity = IMSI Paging order is for RRC-connection.
17	UE			The UE shall not initiate an RRC connection.
18	<-		PACKET PAGING REQUEST	This is checked during 3 seconds. Mobile identity = TMSI-1 Paging order is for TBF establishment.
19	UE			No response from the UE to the request. This is checked for 10seconds.
20	UE			The UE initiates an attach by MMI or AT command.
21		SS		No attach is performed by the UE. This is checked for 10 seconds.
22		SS		
23		UE		
24	->		ATTACH REQUEST	The following messages are sent and shall be received on cell C.
25		SS		The SS deactivates cell B and activates cell C.
26		SS		Cell C is preferred by the UE.
27		UE		Cell C is preferred by the UE.
28		UE		Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI TMSI status = no valid TMSI available
29		UE		Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI1 P-TMSI-1 signature Mobile identity = TMSI-1 Routing area identity = RAI-3
30	<-		ATTACH ACCEPT	
31		UE		
32	->		ATTACH COMPLETE	
33	<-		PACKET PAGING REQUEST	Mobile identity = TMSI-1 Paging order is for RRC-connection.
34	->		CHANNEL REQUEST	
35	<-		IMMEDIATE ASSIGNMENT	

29	->	PAGING RESPONSE	Mobile identity = TMSI-1
30	<-	CHANNEL RELEASE	After sending of this message, the SS waits for disconnection of the CS signalling link.
31	<-	PACKET PAGING REQUEST	Mobile identity = TMSI-1 Paging order is for TBF establishment.
32	->	UPLINK RLC DATA BLOCK	LLC PDU implicitly indicating paging response.
33	UE		The UE is switched off or power is removed (see ICS).
34	->	DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, combined PS / IMSI detach'
35	UE		The following messages are sent and shall be received on cell B. The SS deactivates cell C and activates cell B. Cell B is preferred by the UE.
36	UE		The UE is powered up or switched on and initiates an attach (see ICS).
37	->	ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-3 TMSI status = valid TMSI available
38	<-	ATTACH ACCEPT	Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature Mobile identity = TMSI-2 Routing area identity = RAI-4
39	->	ATTACH COMPLETE	
40	<-	PACKET PAGING REQUEST	Mobile identity = TMSI-2 Paging order is for RRC-connection.
41	->	CHANNEL REQUEST	
42	<-	IMMEDIATE ASSIGNMENT	
43	->	PAGING RESPONSE	Mobile identity = TMSI-2
44	<-	CHANNEL RELEASE	After sending of this message, the SS waits for disconnection of the CS signalling link.
45	<-	PACKET PAGING REQUEST	Mobile identity = TMSI-1 Paging order is for TBF establishment.
46	->	UPLINK RLC DATA BLOCK	LLC PDU implicitly indicating paging response.
47	UE		The UE is switched off or power is removed (see ICS).
48	->	DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, combined PS / IMSI detach'

#### 12.2.2.7.5 Test requirements

UE shall:

- initiate a combined PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.
- perform the following action depending on UE location.

When in the same location area, UE shall

- check the CMM cause which is contained in the ATTACH REJECT message and stop timer T3310.
- delete any stored LAI, CKSN, TMSI, RAI, PS-CKSN, P-TMSI and P-TMSI signature.
- store the LAI or the PLMN identity in the appropriate forbidden list("forbidden location areas for regional provision of service").

When a new location area is entered, UE shall

- perform combined PS attach when UE entered a new location area.



- delete the list of forbidden LAs when power is switched off.

### 12.2.2.8 Combined PS attach / abnormal cases / attempt counter check / miscellaneous reject causes

#### 12.2.2.8.1 Definition

#### 12.2.2.8.2 Conformance requirement

- 1) When a combined PS attach procedure is rejected with the attempt counter less than five, the User Equipment shall repeat the combined PS attach procedure after T3311 timeout.
- 2) When a combined PS attach procedure is rejected with the attempt counter five, the User Equipment shall delete the stored TMSI, LAI, CKSN, P-TMSI, P-TMSI signature, PS CKSN and RAI and start T3302.
- 3) When the T3302 expire, a new combined PS attach procedure shall be initiated.

GMM cause codes that can be selected are:

'IMSI unknown in HLR'  
'IMEI not accepted'  
'Illegal ME'  
'UE identity cannot be derived by the network'  
'Network failure'  
'Congestion'  
'retry upon entry into a new cell'  
'Semantically incorrect message'  
'Invalid mandatory information'  
'Message type non-existent or not implemented'  
'Message type not compatible with the protocol state'  
'Information element non-existent or not implemented'  
'Conditional IE error'  
'Message not compatible with the protocol state'  
'Protocol error, unspecified'

#### Reference

3G TS 24.008 clause 4.7.3.2

#### 12.2.2.8.3 Test purpose

To test the behaviour of the UE with respect to the attempt counter.

#### 12.2.2.8.4 Method of test

##### Initial condition

##### System Simulator:

One cell operating in network operation mode I.

##### User Equipment:

The UE has a valid TMSI, P-TMSI, P-TMSI signature and RAI.

##### Related ICS/IXIT statements

Support of PS service Yes/No

UE operation mode A Yes/No Automatic PS attach procedure at switch on or power on Yes/No

##### Test procedure

The UE initiates a combined PS attach procedure (attempt counter zero).

The SS rejects the attach with a random cause code.

The UE initiates a new combined PS attach procedure (attempt counter one) after T3311 expires.

The SS rejects the attach with a random cause code.

The UE initiates a new combined PS attach procedure (attempt counter two) after T3311 expires.

The SS rejects the attach with a random cause code.

The UE initiates a new combined PS attach procedure (attempt counter three) after T3311 expires.

The SS rejects the attach with a random cause code.

The UE initiates a new combined PS attach procedure (attempt counter four) after T3311 expires.

The SS rejects the attach with a random cause code.

The UE initiates a new combined PS attach procedure with attempt counter five (after T3311 expires).

The SS rejects the attach with a random cause code. The UE shall not perform a new successful attach procedure after 15 seconds.

The UE initiates a combined PS attach procedure with attempt counter zero after T3302 expires without P-TMSI, P-TMSI signature, PS CKSN and RAI.

T3302; set to 10 minutes.

T3311; 15 seconds.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The UE is set in UE operation mode A (see ICS).
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1 TMSI status = valid TMSI available
4	<-		ATTACH REJECT	Random GMM cause
5	SS			The SS verifies that the time between the attach requests is T3311
6	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1 TMSI status = valid TMSI available
7	<-		ATTACH REJECT	Random GMM cause
8	SS			The SS verifies that the time between the attach requests is T3311
9	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1 TMSI status = valid TMSI available
10	<-		ATTACH REJECT	Random GMM cause
11	SS			The SS verifies that the time between the attach requests is T3311
12	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1 TMSI status = valid TMSI available
13	<-		ATTACH REJECT	Random GMM cause
14	SS			The SS verifies that the time between the attach requests is T3311
15	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1 TMSI status = valid TMSI available
16	<-		ATTACH REJECT	Random GMM cause
17	UE			No LOCATION UPDATING REQ with type 'IMSI attach' is sent to the SS (SS waits 30 seconds).
18	<-		PACKET PAGING REQUEST	Mobile identity = TMSI Paging order is for RRC-connection.
19	UE			The UE shall not initiate an RRC connection. This is checked during 3 seconds.
20	<-		PACKET PAGING REQUEST	Mobile identity = TMSI-1 Paging order is for TBF establishment.
21	UE			No response from the UE to the request. This is checked for 10seconds.
22	SS			The SS verifies that the UE does not attempt to attach for T3302 .
23	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI TMSI status = no valid TMSI available
24	<-		ATTACH ACCEPT	Attach result = 'Combined PS / IMSI attached' Mobile identity P-TMSI-1 P-TMSI signature Mobile identity = TMSI-1 Routing area identity = RAI-1

25	->	ATTACH COMPLETE	Mobile identity = TMSI-1 Paging order is for RRC-connection.
26	<-	PACKET PAGING REQUEST	
27	->	CHANNEL REQUEST	Mobile identity = TMSI-1 After sending of this message, the SS waits for disconnection of the CS signalling link.
28	<-	IMMEDIATE ASSIGNMENT	
29	->	PAGING RESPONSE	Mobile identity = TMSI-1 Paging order is for TBF establishment.
30	<-	CHANNEL RELEASE	
31	<-	PACKET PAGING REQUEST	LLC PDU implicitly indicating paging response. The UE is switched off or power is removed (see ICS).
32	->	UPLINK RLC DATA BLOCK	
33	UE		Message not sent if power is removed. Detach type = 'power switched off, combined PS / IMSI detach'
34	->	DETACH REQUEST	

#### 12.2.2.8.5 Test requirements

UE shall:

- initiate a combined PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.
- perform the following actions depending on the conditions described below.

Case1) A combined PS attach procedure is rejected with the attempt counter less than five

UE shall:

- repeat the combine PS attach procedure after the timer T3311 timeout.

Case2) A combined PS attach procedure is rejected with the attempt counter five

UE shall:

- delete the stored TMSI, LAI, CKSN, P-TMSI, P-TMSI signature, PS CKSN and RAI and
- start the timer T3302.

Case3) The T3302 expires

UE shall:

- re-initiate a new combined PS attach procedure.

#### 12.2.2.9 Combined PS attach / abnormal cases / PS detach procedure collision

##### 12.2.2.9.1 Definition

##### 12.2.2.9.2 Conformance requirement

- 1) When a DETACH REQUEST message is received by the UE (any cause except re-attach) while waiting for an ATTACH ACCEPT message or ATTACH REJECT message, the UE shall terminate the combined PS attach procedure and continue with the combined PS detach procedure.
- 2) When a DETACH REQUEST message is received by the UE (cause re-attach) while waiting for an ATTACH ACCEPT message or ATTACH REJECT message, the UE shall ignore the combined PS detach procedure and continue with the combined PS attach procedure.

## Reference

3G TS 24.008 clause 4.7.3.2

## 12.2.2.9.3 Test purpose

To test the behaviour of the UE in case of procedure collision.

## 12.2.2.9.4 Method of test

## Initial condition

## System Simulator:

One cell operating in network operation mode I.

## User Equipment:

The UE has a valid TMSI, P-TMSI, P-TMSI signature and RAI.

## Related ICS/IXIT statements

Support of PS service Yes/No

UE operation mode A Yes/No Switch off on button Yes/No

Automatic PS attach procedure at switch on or power on Yes/No

## Test procedure

The UE initiates a combined PS attach procedure. The SS does not answer the combined PS attach procedure, but initiates a combined PS detach procedure (any cause except re-attach). The UE shall terminate the combined PS attach procedure and continue with the combined PS detach procedure. CS services are not possible as an IMSI attach procedure is not performed.

The UE initiates a combined PS attach procedure. The SS does not answer the combined PS attach procedure, but initiates a combined PS detach procedure (cause re-attach). The UE shall ignore the combined PS detach procedure and continue with the combined PS attach. CS services are also possible.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE		ATTACH REQUEST	The UE is set in UE operation mode B (see ICS).
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->			Attach type = 'Combined PS / IMSI attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1 TMSI status = valid TMSI available
4	SS			The SS ignores the ATTACH REQUEST message and initiates a detach procedure.
5	<-			Detach type = 're-attach not required'
6	->			
7	<-			Mobile identity = IMSI Paging order is for RRC-connection.
8	UE			The UE shall not initiate an RRC connection. This is checked during 3 seconds.
9	UE		ATTACH REQUEST	The UE is attached by MMI or AT command
10	->			Attach type = 'Combined PS / IMSI attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1 TMSI status = valid TMSI available
11	SS			The SS ignores the ATTACH REQUEST message and initiates a detach procedure.
12	<-			Detach type = 're-attach required'
13	UE			The UE ignores the DETACH REQUEST message and continue with the attach procedure
14	<-			ATTACH ACCEPT Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature Mobile identity = TMSI-2 Routing area identity = RAI-1 TMSI status = valid TMSI available
15	->			ATTACH COMPLETE
16	<-			PACKET PAGING REQUEST Mobile identity = TMSI-2 Paging order is for RRC-connection.
17	->			CHANNEL REQUEST
18	<-			IMMEDIATE ASSIGNMENT
19	->			PAGING RESPONSE
20	<-			CHANNEL RELEASE Mobile identity = TMSI-2 After sending of this message, the SS waits for disconnection of the CS signalling link.
21	<-			PACKET PAGING REQUEST Mobile identity = TMSI-2 Paging order is for TBF establishment.
22	->			UPLINK RLC DATA BLOCK
23	UE			LLC PDU implicitly indicating paging response. The UE is switched off or power is removed (see ICS).
24	->			DETACH REQUEST Message not sent if power is removed. Detach type = 'power switched off, combined PS / IMSI detach'

## 12.2.2.9.5 Test requirements

UE shall:

- initiate a combined PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.
- perform the following actions depending on the Detach type described below.

Case1) Detach type is not re-attach

UE shall:

- terminate the combined PS attach procedure.
- continue with the combined PS detach procedure.

Case2) Detach type is re-attach

UE shall:

- ignore the combined PS detach procedure.
- continue with the combined PS attach procedure.

## 12.3 PS detach procedure

### 12.3.1 UE initiated PS detach procedure

#### 12.3.1.1 PS detach / power off / accepted

##### 12.3.1.1.1 Definition

##### 12.3.1.1.2 Conformance requirement

The UE detaches the IMSI for PS services if the UE is switched off.

#### Reference

3G TS 24.008 clause 4.7.4.1

##### 12.3.1.1.3 Test purpose

To test the behaviour of the UE for the detach procedure.

##### 12.3.1.1.4 Method of test

#### Initial condition

System Simulator:

One cell operating in network operation mode II.

User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

#### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode C	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

#### Test procedure

The UE performs a PS attach procedure.

The UE sends a DETACH REQUEST message to the SS.

#### Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 8.
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->		ATTACH REQUEST	Attach type = 'PS attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature
4	<-		ATTACH ACCEPT	Routing area identity = RAI-1 Attach result = 'PS only attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature
5	->		ATTACH COMPLETE	Routing area identity = RAI-1
6	UE			The UE is switched off (see ICS).
7	->		DETACH REQUEST	Detach type = 'power switched off, PS detach'
8	UE			The UE is set in UE operation mode A(see ICS) and the test is repeated from step 2 to step 7.

#### 12.3.1.1.5 Test requirements

UE shall:

- initiate a PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

After the PS attach procedure is completed, UE shall:

- send the DETACH REQUEST message to SS with the Detach type = 'power switched off, PS detach'.

#### 12.3.1.2 PS detach / accepted

##### 12.3.1.2.1 Definition

##### 12.3.1.2.2 Conformance requirement

The UE detaches the IMSI for PS services if the UE is ordered to do so with MMI or AT commands.

#### Reference

3G TS 24.008 clause 4.7.4.1

##### 12.3.1.2.3 Test purpose

To test the behaviour of the UE for the detach procedure.

##### 12.3.1.2.4 Method of test

Initial condition

System Simulator:



One cell operating in network operation mode III.

User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

Related ICS/IXIT statements

Support of PS service      Yes/No  
 UE operation mode C      Yes/No  
 UE operation mode A      Yes/No Switch off on button Yes/No  
 Automatic PS attach procedure at switch on or power on      Yes/No

Test procedure

The UE performs a PS attach procedure and activates a PDP context.

The UE sends a DETACH REQUEST message to the SS.

The SS signal to the UE, but no response is received, as the signalling link is disconnected.

Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 11.
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->		ATTACH REQUEST	Attach type = 'PS attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature
4	<-		ATTACH ACCEPT	Routing area identity = RAI-1 No new mobile identity assigned. P-TMSI and P-TMSI signature not included. Attach result = 'PS only attached' Routing area identity = RAI-1
5	->		ATTACH COMPLETE	
6	UE			The UE initiates a PS detach (without power off) by MMI or AT command.
7	->		DETACH REQUEST	Detach type = 'normal detach, PS detach'
8	<-		DETACH ACCEPT	
9	<-		PACKET PAGING REQUEST Or PAGING REQUEST TYPE 1	Mobile identity = P-TMSI-1 Both paging orders are for TBF establishment. PACKET PAGING REQUEST (used for NW mode III) PAGING REQUEST TYPE 1 (used for NW-mode II).
10	UE			No response from the UE to the request. This is checked for 10 seconds.
11		SS		The SS is set in network operation mode II.
12		UE		The UE is set in UE operation mode A (see ICS) and the test is repeated from step 2 to step 10.

#### 12.3.1.2.5 Test requirements

UE shall:

- initiate a PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

After the PS attach procedure is completed, UE shall:

- sends the DETACH REQUEST message(without power off) to SS.
- start timer T3321.

When UE receives the DETACH ACCEPT message from SS before the timer T3321 is not expired, UE shall:

- stop timer T3321.

### 12.3.1.3 PS detach / abnormal cases / attempt counter check / procedure timeout

#### 12.3.1.3.1 Definition

#### 12.3.1.3.2 Conformance requirement

- 1) When a T3321 timeout has occurred during a PS detach procedure with the attempt counter less than five, the User Equipment shall repeat the PS detach procedure.
- 2) When a T3321 timeout has occurred during a PS detach procedure with the attempt counter five, the User Equipment shall not repeat the procedure.

#### Reference

3G TS 24.008 clause 4.7.4.1

#### 12.3.1.3.3 Test purpose

To test the behaviour of the UE with respect to the attempt counter.

#### 12.3.1.3.4 Method of test

##### Initial condition

##### System Simulator:

One cell operating in network operation mode III.

##### User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

#### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode C	Yes/No
UE operation mode A	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

#### Test procedure

The UE performs a PS attach procedure.

The UE initiates a PS detach procedure (attempt counter zero). The SS does not answer with DETACH ACCEPT message before T3321 timeout.

The UE initiates a new PS detach procedure (attempt counter one) after T3311 expires. The SS does not answer with DETACH ACCEPT message before T3321 timeout.

The UE initiates a new PS detach procedure (attempt counter two) after T3311 expires. The SS does not answer with DETACH ACCEPT message before T3321 timeout.

The UE initiates a new PS detach procedure (attempt counter three) after T3311 expires. The SS does not answer with DETACH ACCEPT message before T3321 timeout.

The UE initiates a new PS detach procedure (attempt counter four) after T3311 expires. The SS does not answer with DETACH ACCEPT message before T3321 timeout.

The UE initiates a new PS detach procedure with attempt counter five (after T3311 expires). The SS does not answer with DETACH ACCEPT message before T3321 timeout.

At T3321 timeout in the UE, the UE then deletes the logical link.

The UE performs a new PS attach procedure.

T3321; 15 seconds.

#### Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 22.
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->		ATTACH REQUEST	Attach type = 'PS attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature
4	<-		ATTACH ACCEPT	Routing area identity = RAI-1 No new mobile identity assigned. P-TMSI and P-TMSI signature not included. Attach result = 'PS only attached' Routing area identity = RAI-1
5	->		ATTACH COMPLETE	
6	UE			The UE initiates a PS detach (without power off) by MMI or AT command.
7	->		DETACH REQUEST	Detach type = 'normal detach, PS detach'
8	SS			No response is given from the SS.
9	SS			The SS verifies that the time between the detach requests is 15 seconds
10	->		DETACH REQUEST	Detach type = 'normal detach, PS detach'
11	SS			No response is given from the SS.
12	SS			The SS verifies that the time between the detach requests is 15 seconds
13	->		DETACH REQUEST	Detach type = 'normal detach, PS detach'
14	SS			No response is given from the SS.
15	SS			The SS verifies that the time between the detach requests is 15 seconds
16	->		DETACH REQUEST	Detach type = 'normal detach, PS detach'
17	SS			No response is given from the SS.
18	SS			The SS verifies that the time between the detach requests is 15 seconds
19	->		DETACH REQUEST	Detach type = 'normal detach, PS detach'
20	SS			No response is given from the SS.
	SS			The SS verifies that the time between the detach requests is 15 seconds
21	->		DETACH REQUEST	Detach type = 'normal detach, PS detach'
22	SS			No response is given from the SS.
23	SS			The SS is set in network operation mode II.
24	UE			The UE is set in UE operation mode A (see ICS) and the test is repeated from step 2 to step 22.

### 12.3.1.3.5 Test requirements

UE shall:

- initiate a PS attaché procedure with the information elements specified in the above Expected Sequence when the UE is powered up or switched on.

After the PS attach procedure is completed, UE shall:

- initiate a PS detach procedure(without power off).
- start timer T3321.

When a T3221 expires with the attempt counter less than five, UE shall:

- initiate a new PS detach procedure.
- increment the attempt counter.
- re-start timer T3321.

When a T3221 expires with the attempt counter five, UE shall:

- not repeat the procedure.

### 12.3.1.4 PS detach / abnormal cases / GMM common procedure collision

#### 12.3.1.4.1 Definition

#### 12.3.1.4.2 Conformance requirement

When any of the GMM common messages P-TMSI REALLOCATION COMMAND, GMM STATUS or GMM INFORMATION is received by the UE while waiting for a DETACH ACCEPT message with detach cause different from “power off”, the UE shall ignore the GMM common message.

#### Reference

3G TS 24.008 clause 4.7.4.1

#### 12.3.1.4.3 Test purpose

To test the behaviour of the UE in case of procedure collision.

#### 12.3.1.4.4 Method of test

#### Initial condition

#### System Simulator:

One cell operating in network operation mode II.

#### User Equipment:

The UE has a valid IMSI.

#### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode C	Yes/No
UE operation mode A	Yes/No (only if mode C not supported)

Switch off on button Yes/No

Automatic PS attach procedure at switch on or power on Yes/No

### Test procedure

The UE performs a PS attach.

The UE initiates a PS detach. The SS initiates a P-TMSI REALLOCATION COMMAND message, a GMM STATUS message and a GMM INFORMATION message. The UE shall ignore the GMM common messages and continue with the PS detach procedure.

The SS signal to the UE, but no response is received, as the signalling link is disconnected.

### Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The UE is set in UE operation mode C or B (see ICS).
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->		ATTACH REQUEST	Attach type = 'PS attach'
4	<-		ATTACH ACCEPT	Mobile identity = IMSI
5	->		ATTACH COMPLETE	Attach result = 'PS only attached'
6	UE			Mobile identity = P-TMSI-1
7	->		DETACH REQUEST	P-TMSI-1 signature
8	SS			Routing area identity = RAI-1
9	<-		P-TMSI REALLOCATION COMMAND	The UE initiates a detach (without power off) by MMI or AT command.
10	UE			Detach type = 'normal detach, PS detach'
11	SS			The SS sends a P-TMSI REALLOCATION COMMAND message
12	<-		GMM STATUS	The UE ignores the message.
13	UE			The SS sends a GMM STATUS message
14	SS			The UE ignores the message.
15	<-		GMM INFORMATION	The SS sends a GMM INFORMATION message
16	UE			The UE ignores the message.
17	<-		DETACH ACCEPT	The SS responds to the DETACH REQUEST
18	<-		PAGING REQUEST TYPE 1	Mobile identity = P-TMSI-1
19	UE			Paging order is for TBF establishment.
				No response from the UE to the request. This is checked for 10 seconds.

#### 12.3.1.4.5 Test requirements

UE shall:

- initiate a PS attaché procedure with the information elements specified in the above Expected Sequence when the UE is powered up or switched on.

After the PS attach procedure is completed, UE shall:

- initiate a PS detach procedure(without power off).

When any of the GMM common messages P-TMSI REALLOCATION COMMAND, GMM STATUS or GMM INFORMATION is received by the UE while waiting for a DETACH ACCEPT message with detach cause different from "power off, UE shall: .

- ignore any of the GMM common.

### 12.3.1.5 PS detach / power off / accepted

#### 12.3.1.5.1 Definition

#### 12.3.1.5.2 Conformance requirement

The UE detach the IMSI for PS and non-PS services.

#### Reference

3G TS 24.008 clause 4.7.4.1

#### 12.3.1.5.3 Test purpose

To test the behaviour of the UE for the detach procedure.

#### 12.3.1.5.4 Method of test

#### Initial condition

##### System Simulator:

One cell operating in network operation mode I.

##### User Equipment:

The UE has a valid IMSI.

#### Related ICS/IXIT statements

Support of PS service	Yes/No	
UE operation mode A	Yes/No	
Switch off on button	Yes/No	
Automatic PS attach procedure at switch on or power on	Yes/No	Yes/No

#### Test procedure

The UE performs a combined PS attach procedure (for PS and non-PS services).

The UE sends a DETACH REQUEST message to the SS. The UE then deletes the logical link.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The UE is set in UE operation mode A (see ICS).
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI
4	<-		ATTACH ACCEPT	TMSI status = no valid TMSI available Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1
5	->		ATTACH COMPLETE	
6	UE			The UE is switched off (see ICS).
7	->		DETACH REQUEST	Detach type = 'power switched off, combined PS / IMSI detach'

## 12.3.1.5.5 Test requirements

UE shall:

- initiate a combined PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

After the PS attach procedure is completed, UE shall:

- send the DETACH REQUEST message to SS with the Detach type = 'power switched off, combined PS / IMSI detach' after the PS attach procedure is completed.

## 12.3.1.6 PS detach / accepted / PS/IMSI detach

## 12.3.1.6.1 Definition

## 12.3.1.6.2 Conformance requirement

The UE detach the IMSI for PS and non-PS services.

## Reference

3G TS 24.008 clause 4.7.4.1

## 12.3.1.6.3 Test purpose

To test the behaviour of the UE for the detach procedure.

## 12.3.1.6.4 Method of test

## Initial condition

System Simulator:

One cell operating in network operation mode I.

User Equipment:

The UE has a valid IMSI.

## Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

## Test procedure

The UE performs a combined PS attach procedure (for PS and non-PS services).

The UE sends a DETACH REQUEST message to the SS. When the UE receives the DETACH ACCEPT, the UE then deletes the logical link.

The SS signal to the UE, but no response is received, as the signalling link is disconnected.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE		ATTACH REQUEST	The UE is set in UE operation mode A(see ICS).
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->			Attach type = 'Combined PS / IMSI attach'
4	<-			Mobile identity = IMSI TMSI status = no valid TMSI available Attach result = 'Combined PS / IMSI attached'
5	->		ATTACH COMPLETE	Mobile identity = P-TMSI-1 P-TMSI-1 signature Mobile identity = TMSI-1 Routing area identity = RAI-1
6	UE			The UE initiates a detach (without power off) by MMI or AT command.
7	->			Detach type = 'normal detach, combined PS / IMSI detach'
8	<-			
9	<-		PACKET PAGING REQUEST	Mobile identity = P-TMSI-1 Paging order is for TBF establishment.
10	UE			No response from the UE to the request. This is checked for 10 seconds.
11	<-			Mobile identity = IMSI Paging order is for RRC connection.
12	UE			The UE shall not initiate an RRC connection. This is checked during 3 seconds.

## 12.3.1.6.5 Test requirements

UE shall:

- initiate a combined PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

After the combined PS attach procedure is completed, UE shall:

- sends the DETACH REQUEST message(UE not switched off) to SS.
- shall start timer T3321.

When the UE receive the DETACH ACCEPT message from SS before the timer T3321 is not expired, the UE shall:

- stop timer T3321.



### 12.3.1.7 PS detach / accepted / IMSI detach

#### 12.3.1.7.1 Definition

#### 12.3.1.7.2 Conformance requirement

The UE shall detach for CS services.

#### Reference

3G TS 24.008 clause 4.7.4.1

#### 12.3.1.7.3 Test purpose

To test the behaviour of the UE for the detach procedure.

#### 12.3.1.7.4 Method of test

#### Initial condition

##### System Simulator:

One cell operating in network operation mode I.

##### User Equipment:

The UE has a valid IMSI.

#### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No
MMI controlled attach / detach procedures for non-PS services	Yes/No

#### Test procedure

The UE performs a combined PS attach procedure (for PS and non-PS services).

The UE performs an PS detach (for non-PS services).

CS services are not possible.

The UE attach for non-PS services by a routing area update procedure and CS services are again possible.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The UE is set in UE operation mode A (see ICS).
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI
4	<-		ATTACH ACCEPT	TMSI status = no valid TMSI available Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-1 P-TMSI-1 signature Mobile identity = TMSI-1 Routing area identity = RAI-1
5	->		ATTACH COMPLETE	
6	UE			The UE initiates a detach for non-PS services (without power off) (see ICS).
7	->		DETACH REQUEST	Detach type = 'normal detach, IMSI detach'
8	<-		DETACH ACCEPT	
9	<-		PACKET PAGING REQUEST	Mobile identity = P-TMSI-1 Paging order is for TBF establishment.
10	->		UPLINK RLC DATA BLOCK	LLC PDU implicitly indicating paging response.
11	<-		PACKET PAGING REQUEST	Mobile identity = TMSI-1 Paging order is for RRC connection.
12	UE			The UE shall not initiate an RRC connection. This is checked during 3 seconds.
13	UE			The UE initiates an attach for non-PS services by a RA update procedure (see ICS).
14	->		ROUTING AREA UPDATE REQUEST	Update type = 'Combined RA/LA updating' P-TMSI-1 signature
15	<-		ROUTING AREA UPDATE ACCEPT	Routing area identity = RAI-1 TMSI status = valid TMSI available Update result = 'Combined RA/LA updated' Mobile identity = P-TMSI-2 P-TMSI-2 signature Mobile identity = TMSI-1 Routing area identity = RAI-1
16	->		ROUTING AREA UPDATE COMPLETE	
17	<-		PACKET PAGING REQUEST	Mobile identity = TMSI-1 Paging order is for RRC connection.
18	->		CHANNEL REQUEST	
19	<-		IMMEDIATE ASSIGNMENT	
20	->		PAGING RESPONSE	Mobile identity = TMSI-1
21	<-		CHANNEL RELEASE	After sending of this message, the SS waits for disconnection of the CS signalling link.
22	UE			The UE is switched off or power is removed (see ICS).
23	->		DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, combined PS / IMSI detach'

## 12.3.1.7.5 Test requirements

UE shall:

- initiate a combined PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

After the combined PS attach procedure is completed, UE shall:

- sends the DETACH REQUEST message(UE not switched off) to SS.
- start timer T3321.

When the UE receives the DETACH ACCEPT message from SS before the timer T3321 is not expired, the UE shall:

- stop timer T3321.

### 12.3.1.8 PS detach / abnormal cases / change of cell into new routing area

#### 12.3.1.8.1 Definition

#### 12.3.1.8.2 Conformance requirement

When a change of cell into a new routing area is performed before DETACH ACCEPT message is received by the UE, the UE shall abort the PS detach procedure and re-initiate it after the routing area update procedure.

#### Reference

3G TS 24.008 clause 4.7.4.1

#### 12.3.1.8.3 Test purpose

To test the behaviour of the UE in case of procedure collision.

#### 12.3.1.8.4 Method of test

#### Initial condition

#### System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 and cell B in MCC1/MNC1/LAC1/RAC2.  
Both cells are operating in network operation mode I.

#### User Equipment:

The UE has a valid IMSI.

#### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

#### Test procedure

The UE performs a combined PS attach procedure (for PS and non-PS services).

The UE initiates a PS detach procedure. The DETACH ACCEPT message is delayed from the SS.

The UE performs a cell update into a new routing area.

The Ms shall re-initiate a PS detach procedure when the routing area update procedure is finished.

The UE deletes the logical link.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		The following messages are sent and shall be received on cell A.
2		SS		The SS activates cell A.
3		UE		The UE is set in UE operation mode A (see ICS).
4		UE		The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.
5	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI
6	<-		ATTACH ACCEPT	TMSI status = no valid TMSI available Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-1 P-TMSI-1 signature
7				Mobile identity = TMSI-1 Routing area identity = RAI-1
8	->		ATTACH COMPLETE	
9		UE		The UE initiates a PS detach (without power off) by MMI or AT command.
10	->		DETACH REQUEST	Detach type = 'normal detach, combined PS / IMSI detach'
11		SS		No response to the DETACH REQUEST message is given by the SS
12		SS		The following messages are sent and shall be received on cell B.
13		SS		The SS deactivates cell A and activates cell B. Cell B is preferred by the UE.
14		UE		The UE performs a RA update in the new cell.
15	->		ROUTING AREA UPDATE REQUEST	Update type = 'Combined RA/LA updating' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1
16	<-		ROUTING AREA UPDATE ACCEPT	TMSI status = valid TMSI available Update result = 'Combined RA/LA updated'
17				Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-4
18	->		ROUTING AREA UPDATE COMPLETE	
19	->		DETACH REQUEST	The detach is automatically re-attempted.
20				Detach type = 'normal detach, combined PS / IMSI detach'
21	->		DETACH ACCEPT	

## 12.3.1.8.5

## Test requirements

UE shall:

- initiate a combined PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

After the combined PS attach procedure is completed, UE shall:

- initiate a PS detach.

When a change of cell into a new routing area is performed before DETACH ACCEPT message by the UE, UE shall:

- abort a PS detach procedure.
- re-initiate a PS detach procedure after successfully performing a routing area updating procedure.

## 12.3.1.9 PS detach / abnormal cases / PS detach procedure collision

### 12.3.1.9.1 Definition

### 12.3.1.9.2 Conformance requirement

When a DETACH REQUEST is received by the UE while waiting for a DETACH ACCEPT message, the UE shall answer the network initiated PS detach procedure.

#### Reference

3G TS 24.008 clause 4.7.4.1

### 12.3.1.9.3 Test purpose

To test the behaviour of the UE in case of procedure collision.

### 12.3.1.9.4 Method of test

#### Initial condition

#### System Simulator:

One cell operating in network operation mode I.

#### User Equipment:

The UE has a valid IMSI.

#### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

#### Test procedure

The UE performs a combined PS attach procedure (for PS and non-PS services).

The UE initiates a PS detach. The SS does not answer the detach procedure, but initiates a detach procedure (cause re-attach not required). The UE shall continue with the network initiated detach procedure.

The UE deletes the logical link.

PS and CS services are not possible.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The UE is set in UE operation mode A(see ICS).
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI
4	<-		ATTACH ACCEPT	TMSI status = no valid TMSI available Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-1 P-TMSI-1 signature Mobile identity = TMSI-1 Routing area identity = RAI-1
5	->		ATTACH COMPLETE	
6	UE			The UE initiates a PS detach (without power off) by MMI or AT command.
7	->		DETACH REQUEST	Detach type = 'normal detach, combined PS / IMSI detach'
8	<-		DETACH REQUEST	Detach type = 're-attach not required'
9	->		DETACH ACCEPT	The UE answers the network initiated detach.
10	<-		DETACH ACCEPT	The SS answers the UE initiated detach.
11	<-		PACKET PAGING REQUEST	Mobile identity = P-TMSI-1 Paging order is for TBF establishment.
12	UE			No response from the UE to the request. This is checked for 10 seconds.
13	<-		PAGING REQUEST TYPE 1	Mobile identity = TMSI-1 Paging order is for RRC connection.
14	UE			The UE shall not initiate an RRC connection. This is checked during 3 seconds.

## 12.3.1.9.5 Test requirements

UE shall:

- initiate a combined PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

After the combined PS attach procedure is completed, UE shall:

- initiate a PS detach procedure.

When the UE receive DETACH REQUEST message from SS before UE initiated PS detach procedure has been completed, UE shall:

- send the DETACH ACCEPT message to SS

## 12.3.2 Network initiated PS detach procedure

## 12.3.2.1 PS detach / re-attach not required / accepted

## 12.3.2.1.1 Definition

## 12.3.2.1.2 Conformance requirement

The UE detach the IMSI for PS services.

## Reference

3G TS 24.008 clause 4.7.4.2

### 12.3.2.1.3 Test purpose

To test the behaviour of the UE for the detach procedure.

### 12.3.2.1.4 Method of test

## Initial condition

### System Simulator:

One cell operating in network operation mode II (in case of UE operation mode A), or in network operation mode III (in case of UE operation mode C).

### User Equipment:

The UE has a valid IMSI.

## Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode C	Yes/No
UE operation mode A	Yes/No (only if mode C not supported)
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

## Test procedure

The UE performs a PS attach procedure.

The SS sends a DETACH REQUEST message to the UE. The UE then deletes the logical link.

The SS signal to the UE, but no response is received, as the signalling link is disconnected.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		The SS is set in network operation mode II or III.
2	UE			The UE is set in UE operation mode A or C (see ICS).
3	UE			The UE is powered up or switched on and initiates an attach (see ICS).
4	->		ATTACH REQUEST	Attach type = 'PS attach'
5	<-		ATTACH ACCEPT	Mobile identity = IMSI Attach result = 'PS only attached'
6	->		ATTACH COMPLETE	Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1
7	UE			The UE initiates a PS detach (without power off) by MMI or AT command.
8	<-		DETACH REQUEST	Detach type = 're-attach not required'
9	->		DETACH ACCEPT	
10	<-		PACKET PAGING REQUEST Or PAGING REQUEST TYPE 1	Mobile identity = P-TMSI-1 Both paging orders are for TBF establishment. PACKET PAGING REQUEST (used for NW mode III) PAGING REQUEST TYPE 1 (used for NW-mode II).
11	UE			No response from the UE to the request. This is checked for 10 seconds.

## 12.3.2.1.5 Test requirements

UE shall:

- initiate PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

When UE receives the DETACH REQUEST message from SS and the detach type IE indicates 're-attach not required', the UE shall

- deactivate the PDP context and the logical link(s).
- send DETACH ACCEPT message to SS.

## 12.3.2.2 PS detach / rejected / IMSI invalid / PS services not allowed

## 12.3.2.2.1 Definition

## 12.3.2.2.2 Conformance requirement

- 1) If the network performs a PS detach procedure with the cause 'PS services not allowed', the User Equipment shall consider USIM invalid for PS services until power is switched off or USIM is removed.
- 2) If the network performs a PS detach procedure with the cause 'PS services not allowed' the User Equipment shall delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.

## Reference

3G TS 24.008 clause 4.7.4.2

## 12.3.2.2.3 Test purpose

To test the behaviour of the UE if the network order a PS detach procedure with the cause 'PS services not allowed' (no valid PS-subscription for the IMSI).



## 12.3.2.2.4 Method of test

## Initial condition

## System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (HPLMN) and cell B in MCC2/MNC1/LAC1/RAC1.

Both cells are operating in network operation mode II.

## User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

## Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode C	Yes/No
UE operation mode A	Yes/No
USIM removal possible without powering down	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

## Test procedure

The SS performs a detach with the cause value 'PS services not allowed'. The SS checks that the UE does not perform PS attach in another PLMN.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1 2	SS UE			<p>The following messages are sent and shall be received on cell A.</p> <p>The SS activates cell A.</p> <p>The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 19.</p> <p>The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.</p> <p>Attach type = 'PS attach'</p> <p>Mobile identity = P-TMSI-1</p> <p>P-TMSI-1 signature</p> <p>Routing area identity = RAI-1</p> <p>Attach result = 'PS only attached'</p> <p>Mobile identity = P-TMSI-2</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p> <p>Detach type = 're-attach not required'</p> <p>Cause = 'PS services not allowed'</p>
3	UE			
4	->		ATTACH REQUEST	
5	<-		ATTACH ACCEPT	
6 7	-> <-		ATTACH COMPLETE DETACH REQUEST	
8	->		DETACH ACCEPT	
9 10 11	SS UE UE			
12	UE			
13	UE			<p>The following messages are sent and shall be received on cell B.</p> <p>The SS deactivates cell A and activates cell B. Cell B is preferred by the UE.</p> <p>No ATTACH REQUEST sent to the SS (SS waits 30 seconds).</p> <p>If possible (see ICS) USIM removal is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed.</p> <p>The UE gets the USIM replaced, is powered up or switched on and initiates an attach (see ICS).</p> <p>Attach type = 'PS attach'</p> <p>Mobile identity = IMSI</p> <p>Attach result = 'PS only attached'</p> <p>Mobile identity = P-TMSI-1</p> <p>P-TMSI-1 signature</p> <p>Routing area identity = RAI-2</p> <p>The UE is switched off or power is removed (see ICS).</p> <p>Message not sent if power is removed.</p> <p>Detach type = 'power switched off, PS detach'</p>
14	->		ATTACH REQUEST	
15	<-		ATTACH ACCEPT	
16 17	-> UE		ATTACH COMPLETE	
18	->		DETACH REQUEST	
19 20	UE			
				<p>The SS deactivates cell B and activates cell A.</p> <p>The UE is set in UE operation mode A (see ICS) and the test is repeated from step 3 to step 18.</p>

## 12.3.2.2.5 Test requirements

UE shall:

- initiate a PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

After the completion of the PS attach procedure, and when UE receives the DETACH REQUEST message (Detach type = 're-attach not required', Cause = 'PS services not allowed') from SS, UE shall:

- delete the stored P-TMSI, P-TMSI signature, RAI and PS ciphering key sequence number.

- consider the USIM as invalid for PS service until power is switched off or USIM is removed.

### 12.3.2.3 PS detach / IMSI detach / accepted

#### 12.3.2.3.1 Definition

#### 12.3.2.3.2 Conformance requirement

The UE detach the IMSI for PS services.

#### Reference

3G TS 24.008 clause 4.7.4.2

#### 12.3.2.3.3 Test purpose

To test the behaviour of the UE for the detach procedure.

#### 12.3.2.3.4 Method of test

#### Initial condition

#### System Simulator:

One cell operating in network operation mode I.

#### User Equipment:

The UE has a valid IMSI.

#### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No
MMI controlled attach / detach procedures for non-PS services	Yes/No

#### Test procedure

The UE performs a combined PS attach procedure (for PS and non-PS services).

The SS sends a DETACH REQUEST message to the UE. The UE then performs an IMSI detach (detach for non-PS services) .

The SS signal to the UE, but no response is received, as the signalling link is disconnected.

The UE attach for non-PS services by a routing area update procedure. Both PS and CS services are possible.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The UE is set in UE operation mode A (see ICS).
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI
4	<-		ATTACH ACCEPT	TMSI status = no valid TMSI available Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-1 P-TMSI-1 signature Mobile identity = IMSI Routing area identity = RAI-1
5	->		ATTACH COMPLETE	
6	SS			The SS initiates a detach for non-PS services.
7	<-		DETACH REQUEST	Detach type = 'IMSI detach'
8	->		DETACH ACCEPT	
9	<-		PACKET PAGING REQUEST	Mobile identity = P-TMSI-1 Paging order is for TBF establishment.
10	->		UPLINK RLC DATA BLOCK	LLC PDU implicitly indicating paging response.
11	<-		PACKET PAGING REQUEST	Mobile identity = IMSI Paging order is for RRC-connection.
12	UE			The UE shall not initiate an RRC connection. This is checked during 3 seconds.
13	UE			The UE initiates an attach for non-PS services (see ICS).
14	->		ROUTING AREA UPDATE REQUEST	Update type = 'Combined RA/LA updating with IMSI attach' P-TMSI-1 signature Routing area identity = RAI-1
15	<-		ROUTING AREA UPDATE ACCEPT	TMSI status = no valid TMSI available Update result = 'Combined RA/LA updating' Mobile identity = P-TMSI-2 P-TMSI-2 signature Mobile identity = TMSI-1 Routing area identity = RAI-1
16	->		ROUTING AREA UPDATE COMPLETE	
17	<-		PACKET PAGING REQUEST	Mobile identity = TMSI-1 Paging order is for RRC-connection.
18	->		CHANNEL REQUEST	
19	<-		IMMEDIATE ASSIGNMENT	
20	->		PAGING RESPONSE	Mobile identity = TMSI-1
21	<-		CHANNEL RELEASE	After sending of this message, the SS waits for disconnection of the CS signalling link.
22	UE			The UE is switched off or power is removed (see ICS).
23	->		DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, combined PS / IMSI detach'

## 12.3.2.3.5 Test requirements

UE shall:

- initiate a combined PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

After the completion of the PS attach procedure, UE shall:

- receive DETACH REQUEST message (Detach type = 'IMSI detach') from SS.

- not deactivate the PDP context.
- and send the DETACH ACCEPT message to SS.

### 12.3.2.4 PS detach / re-attach requested / accepted

#### 12.3.2.4.1 Definition

#### 12.3.2.4.2 Conformance requirement

The UE shall deactivate the logical link and re-activate it.

#### Reference

3G TS 24.008 clause 4.7.4.2

#### 12.3.2.4.3 Test purpose

To test the behaviour of the UE for the detach procedure in case automatic re-attach.

#### 12.3.2.4.4 Method of test

#### Initial condition

#### System Simulator:

One cell in operating in network operation mode I.

#### User Equipment:

The UE has a valid TMSI, P-TMSI, P-TMSI signature and RAI.

#### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

#### Test procedure

The UE performs a combined PS attach procedure (for PS and non-PS services).

The SS sends a DETACH REQUEST message to the UE with cause re-attach. The UE then detach for PS and non-PS services. The UE automatically performs a new combined PS attach procedure (for PS and non-PS services) and PS and CS services are again possible.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The UE is set in UE operation mode A (see ICS).
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1 TMSI status = valid TMSI available
4	<-		ATTACH ACCEPT	Attach result = 'Combined PS / IMSI attached' Mobile identity = TMSI-1 Routing area identity = RAI-1 No new P-TMSI and P-TMSI signature assigned
5	->		ATTACH COMPLETE	
6	SS			The SS initiates a detach with re-attach.
7	<-		DETACH REQUEST	Detach type = 're-attach required'
8	->		DETACH ACCEPT	
9	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Mobile identity = TMSI-1 Routing area identity = RAI-1 TMSI status = valid TMSI available
10	<-		ATTACH ACCEPT	Attach result = 'Combined PS / IMSI attached' Mobile identity = TMSI-1 Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-1
11	->		ATTACH COMPLETE	
12	<-		PACKET PAGING REQUEST	Mobile identity = P-TMSI-2 Paging order is for TBF establishment.
13	->		UPLINK RLC DATA BLOCK	LLC PDU implicitly indicating paging response.
14	<-		PACKET PAGING REQUEST	Mobile identity = TMSI-1 Paging order is for RRC-connection.
15	->		CHANNEL REQUEST	
16	<-		IMMEDIATE ASSIGNMENT	
17	->		PAGING RESPONSE	Mobile identity = TMSI-1
18	<-		CHANNEL RELEASE	After sending of this message, the SS waits for disconnection of the CS signalling link.
19	UE			The UE is switched off or power is removed (see ICS).
20	->		DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, combined PS / IMSI detach'

## 12.3.2.4.5 Test requirements

UE shall:

- initiate a combined PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

After the completion of the combined PS attach procedure, UE shall:

- deactivate the PDP context and the logical link(s).
- send DETACH ACCEPT message to SS.

After UE completed PS detach procedure, UE shall:

- initiate a combined PS attach procedure.

### 12.3.2.5 PS detach / rejected / location area not allowed

#### 12.3.2.5.1 Definition

#### 12.3.2.5.2 Conformance requirement

- 1) If the network performs a PS detach procedure with the cause 'location area not allowed' the User Equipment shall:
  - 1.1 not perform combined PS attach when in the same location area.
  - 1.2 delete the stored LAI, CKSN, TMSI, RAI, PS-CKSN, P-TMSI and P-TMSI signature.
  - 1.3 store the LA in the 'forbidden location areas for regional provision of service'.
- 2) If the network performs a PS detach procedure with the cause 'location area not allowed' the User Equipment shall:
  - 2.1 perform combined PS attach when a new location area is entered.
  - 2.2 delete the list of forbidden LAs when power is switched off.

#### Reference

3G TS 24.008 clauses 4.7.4.2

#### 12.3.2.5.3 Test purpose

To test the behaviour of the UE if the network orders the PS detach procedure with the cause 'Location Area not allowed'.

To test that the UE deletes the list of forbidden LAs when power is switched off.

#### 12.3.2.5.4 Method of test

##### Initial condition

##### System Simulator:

Three cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2, cell C in MCC1/MNC1/LAC2/RAC1.  
All cells are operating in network operation mode I.

##### User Equipment:

The UE has a valid IMSI.

##### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

##### Test procedure

The SS orders a PS detach with the cause value 'Location Area not allowed'. The SS checks that the UE does not perform combined PS attach while in the location area, performs PS attach when a new location area is entered and

deletes the list of forbidden LAs when switched off. CS services are not possible unless an IMSI attach procedure is performed.

Different types of UE may use different methods to periodically clear the list of forbidden location areas (e.g. every day at 12am). If the list is cleared while the test is being run, it may be necessary to re-run the test.



## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		<p>The following messages are sent and shall be received on cell A.</p> <p>The SS activates cell A.</p> <p>The UE is set in UE operation mode A (see ICS).</p> <p>The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.</p> <p>Attach type = 'Combined PS / IMSI attach'</p> <p>Mobile identity = IMSI</p> <p>TMSI status = no valid TMSI available</p> <p>Attach result = 'Combined PS / IMSI attached'</p> <p>Mobile identity = P-TMSI-1</p> <p>P-TMSI-1 signature</p> <p>Mobile identity = TMSI-1</p> <p>Routing area identity = RAI-1</p>
2	UE			
3	UE			
4	->		ATTACH REQUEST	
5	<-		ATTACH ACCEPT	
6	->		ATTACH COMPLETE	
7	<-		DETACH REQUEST	
8	->		DETACH COMPLETE	
9	UE			<p>No LOCATION UPDATING REQ with type 'IMSI attach' is sent to the SS (SS waits 30 seconds).</p> <p>Mobile identity = IMSI</p> <p>Paging order is for RRC-connection.</p> <p>The UE shall not initiate an RRC connection. This is checked during 3 seconds.</p> <p>Mobile identity = P-TMSI-1</p> <p>Paging order is for TBF establishment.</p> <p>No response from the UE to the request. This is checked for 10 seconds</p>
10	<-		PACKET PAGING REQUEST	
11	UE			
12	<-		PACKET PAGING REQUEST	
13	->			
14	SS			<p>The following messages are sent and shall be received on cell B.</p> <p>The SS deactivates cell A and activates cell B. Cell B is preferred by the UE.</p> <p>The UE initiates an attach automatically, by MMI or by AT command.</p> <p>No ATTACH REQUEST sent to SS (SS waits 30 seconds)</p> <p>No LOCATION UPDATING REQ with type 'IMSI attach' is sent to the SS (SS waits 30 seconds).</p> <p>Mobile identity = IMSI</p> <p>Paging order is for RRC-connection.</p> <p>The UE shall not initiate an RRC connection. This is checked during 3 seconds.</p> <p>Mobile identity = P-TMSI-1</p> <p>Paging order is for TBF establishment.</p> <p>No response from the UE to the request. This is checked for 10 seconds</p>
15	UE			
16	UE			
17	UE			
18	UE			
19	<-		PACKET PAGING REQUEST	
20	UE			
21	<-		PACKET PAGING REQUEST	
22				
23	SS			
24	UE			<p>The following messages are sent and shall be received on cell C.</p> <p>The SS deactivates cell B and activates cell C. Cell C is preferred by the UE.</p> <p>The UE initiates an attach automatically, by MMI or by AT command.</p> <p>Attach type = 'Combined PS / IMSI attach'</p> <p>Mobile identity = IMSI</p> <p>TMSI status = no valid TMSI available</p>
25	UE			
26	->		ATTACH REQUEST	

27	<-	ATTACH ACCEPT	Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI1 P-TMSI-1 signature Mobile identity = TMSI-1 Routing area identity = RAI-3
28	->	ATTACH COMPLETE	
29	<-	PACKET PAGING REQUEST	Mobile identity = TMSI-1 Paging order is for RRC-connection.
30	->	CHANNEL REQUEST	
31	<-	IMMEDIATE ASSIGNMENT	
32	->	PAGING RESPONSE	Mobile identity = TMSI-1
33	<-	CHANNEL RELEASE	After sending of this message, the SS waits for disconnection of the CS signalling link.
34	<-	PACKET PAGING REQUEST	Mobile identity = P-TMSI-1 Paging order is for TBF establishment.
35	->	UPLINK RLC DATA BLOCK	LLC PDU implicitly indicating paging response.
36	UE		The UE is switched off or power is removed (see ICS).
37	->	DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, combined PS / IMSI detach'
38	UE		The following messages are sent and shall be received on cell B. The SS deactivates cell C and activates cell B. Cell B is preferred by the UE.
39	UE		The UE is powered up or switched on and initiates an attach (see ICS).
40	->	ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-3 TMSI status = valid TMSI available
41	<-	ATTACH ACCEPT	Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature Mobile identity = TMSI-2 Routing area identity = RAI-4
42	->	ATTACH COMPLETE	
43	<-	PACKET PAGING REQUEST	Mobile identity = TMSI-2 Paging order is for RRC-connection.
44	->	CHANNEL REQUEST	
45	<-	IMMEDIATE ASSIGNMENT	
46	->	PAGING RESPONSE	Mobile identity = TMSI-2
47	<-	CHANNEL RELEASE	After sending of this message, the SS waits for disconnection of the CS signalling link.
48	<-	PACKET PAGING REQUEST	Mobile identity = P-TMSI-2 Paging order is for TBF establishment.
49	->	UPLINK RLC DATA BLOCK	LLC PDU implicitly indicating paging response.
50	UE		The UE is switched off or power is removed (see ICS).
51	->	DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, combined PS / IMSI detach'

### 12.3.2.5.5 Test requirements

UE shall:

- initiate a PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

After the completion of the PS attach procedure, and when UE receive the DETACH REQUEST message (Detach type = 're-attach not required', Cause = 'Location Area not allowed') from SS, UE shall:

- perform the following action depending on UE location.

When in the same location area, UE shall:

- not perform combined PS attach.
- delete the stored RAI or LAI, P-TMSI, P-TMSI signature and PS ciphering key sequence number
- store the LA in the 'forbidden location areas for regional provision of service'.

When a new location area is entered, UE shall:

- perform combined PS attach.
- delete the list of forbidden LAs when power is switched off.

## 12.4 Routing area updating procedure

This procedure is used to update the actual routing area of an UE in the network.

### 12.4.1 Normal routing area updating

The routing area updating procedure is a GMM procedure used by PS UEs of UE operation mode A or C that are IMSI attached for PS services only.

#### 12.4.1.1 Routing area updating / accepted

##### 12.4.1.1.1 Definition

##### 12.4.1.1.2 Conformance requirement

- 1) If the network accepts the routing area updating procedure and reallocates a P-TMSI, the UE shall acknowledge the new P-TMSI and continue communication with the new P-TMSI.
- 2) If the network accepts the routing area updating procedure from the UE without reallocation of the old P-TMSI, the UE shall continue communication with the old P-TMSI.

#### Reference

3G TS 24.008 clause 4.7.5.1

##### 12.4.1.1.3 Test purpose

To test the behaviour of the UE if the network accepts the routing area updating procedure.

The following cases are identified:

- 1) P-TMSI / P-TMSI signature is reallocated
- 2) Old P-TMSI / P-TMSI signature is not changed

##### 12.4.1.1.4 Method of test

#### Initial condition

System Simulator:

Two cells, cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2.  
Both cells are operating in network operation mode II.

User Equipment:

The UE has a valid IMSI.

#### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
UE operation mode C	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

#### Test procedure

- 1) The UE sends a ROUTING AREA UPDATE REQUEST message. The SS reallocates the P-TMSI and returns ROUTING AREA UPDATE ACCEPT message with a new P-TMSI. The UE acknowledge the new P-TMSI by sending ROUTING AREA UPDATING COMPLETE message. Further communication UE - SS is performed by the new P-TMSI. The UE will not answer signalling addressed to the old P-TMSI.
- 2) The UE sends a ROUTING AREA UPDATING REQUEST message. The SS accepts the P-TMSI and returns ROUTING AREA UPDATING ACCEPT message without any P-TMSI. Further communication UE - SS is performed by the P-TMSI.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		<p>The following messages are sent and shall be received on cell A.</p> <p>The SS activates cell A.</p> <p>The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 22.</p> <p>The UE is powered up or switched on and initiates an attach (see ICS).</p> <p>Attach type = 'PS attach'</p> <p>Mobile identity = IMSI</p> <p>Attach result = 'PS only attached'</p> <p>Mobile identity = P-TMSI-2</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p>
2		UE		
3		UE		
4	->		ATTACH REQUEST	
5	<-		ATTACH ACCEPT	
6	->		ATTACH COMPLETE	
7		SS		<p>The following messages are sent and shall be received on cell B.</p> <p>Activate cell B with a lower signal strength than cell A The RF level of cell A is lowered until cell B is preferred by the UE.</p> <p>Update type = 'RA updating'</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p> <p>Update result = 'RA updated'</p> <p>Mobile identity = P-TMSI-1</p> <p>P-TMSI-1 signature</p> <p>Routing area identity = RAI-4</p> <p>Message sent with P-TMSI-1</p> <p>Message sent in case the UE does not support reception of GMM information message Cause #97</p> <p>Mobile identity = P-TMSI-2</p> <p>Both paging orders are for TBF establishment. PACKET PAGING REQUEST (used for NW mode III)</p> <p>PAGING REQUEST TYPE 1 (used for NW-mode II).</p> <p>No response from the UE to the request. This is checked for 10 seconds.</p>
8	->		ROUTING AREA UPDATING REQUEST	
9	<-		ROUTING AREA UPDATING ACCEPT	
10	->		ROUTING AREA UPDATING COMPLETE	
11	<-		GMM INFORMATION	
11b	->		GMM STATUS	
12	<-		PACKET PAGING REQUEST or PAGING REQUEST TYPE 1	
13		UE		<p>The following messages are sent and shall be received on cell A.</p> <p>Set the signal strength of cell A to a lower signal strength than cell B The RF level of cell B is lowered until cell A is preferred by the UE.</p> <p>Cell A is preferred by the UE.</p> <p>Update type = 'RA updating'</p> <p>P-TMSI-1 signature</p> <p>Routing area identity = RAI-4</p> <p>No new mobile identity assigned.</p> <p>P-TMSI not included.</p> <p>Update result = 'RA updated'</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p> <p>Mobile identity = P-TMSI-1</p> <p>Both paging orders are for TBF establishment. PACKET PAGING REQUEST (used for NW mode III)</p> <p>PAGING REQUEST TYPE 1 (used for NW-mode II).</p> <p>LLC PDU implicitly indicating paging response.</p>
14		SS		
15		UE		
16	->		ROUTING AREA UPDATING REQUEST	
17	<-		ROUTING AREA UPDATING ACCEPT	
18	<-		PACKET PAGING REQUEST or PAGING REQUEST TYPE 1	
19	->		UPLINK RLC DATA BLOCK	

20	UE		The UE is switched off or power is removed (see ICS).
21	->	DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, PS detach'
22	UE		The UE is set in UE operation mode A (see ICS) and the test is repeated from step 3 to step 21.

#### 12.4.1.1.5 Test requirements

UE shall:

- initiate a PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

After completing the PS attach procedure, UE shall:

- initiate a routing area updating procedure with the information elements specified in the above Expected Sequence when the RF level of the attached cell is lower than the RF level of the new cell.
- use the P-TMSI which is included in the ROUTING AREA UPDATING ACCEPT message.
- acknowledge the new P-TMSI and continue communication with the new P-TMSI.
- continue communication with the old P-TMSI.

#### 12.4.1.2 Routing area updating / rejected / IMSI invalid / illegal ME

##### 12.4.1.2.1 Definition

##### 12.4.1.2.2 Conformance requirement

- 1) If the network rejects a routing area updating procedure from the User Equipment with the cause 'Illegal ME', the User Equipment shall consider USIM invalid for PS services until power is switched off or USIM is removed.
- 2) If the network rejects a routing area updating procedure from the User Equipment with the cause 'Illegal ME', the User Equipment shall delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.

##### Reference

3G TS 24.008 clause 4.7.5.1

##### 12.4.1.2.3 Test purpose

To test the behaviour of the UE if the network rejects the routing area updating procedure of the UE with the cause 'Illegal ME'.

##### 12.4.1.2.4 Method of test

##### Initial condition

##### System Simulator:

Three cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2, cell C in MCC2/MNC1/LAC1/RAC1.

All three cells are operating in network operation mode II (in case of UE operation mode A), or in network operation mode III (in case of UE operation mode C).

User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

#### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode C	Yes/No
UE operation mode A	Yes/No (only if mode C not supported)
USIM removal possible without powering down	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

#### Test procedure

The SS rejects a routing area updating with the cause value 'Illegal ME'. The SS checks that the UE does not perform PS attach in the same or another PLMN.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE		ATTACH REQUEST	The following messages are sent and shall be received on cell A. The UE is set in UE operation mode C or B (see ICS).
2	SS			The SS is set in network operation mode II or III and activates cell A.
3	UE			The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.
4	->			Attach type = 'PS attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature
5	<-			Routing area identity = RAI-1 No new mobile identity assigned. P-TMSI and P-TMSI signature not included. Attach result = 'PS only attached' Routing area identity = RAI-1
6	SS		ROUTING AREA UPDATING REQUEST	The following messages are sent and shall be received on cell B.
7	UE			The SS deactivates cell A and activates cell B. Cell B is preferred by the UE.
8	->			Update type = 'RA updating' P-TMSI-2 signature
9	<-			Routing area identity = RAI-1 GMM cause = 'Illegal UE'
10	<-			Mobile identity = P-TMSI-2 Both paging orders are for TBF establishment. PACKET PAGING REQUEST (used for NW mode III) PAGING REQUEST TYPE 1 (used for NW-mode II).
11	UE			No response from the UE to the request. This is checked for 10 seconds.
12	SS		ATTACH REQUEST	The following messages are sent and shall be received on cell C.
13	UE			The SS deactivates cell B and activates cell C. Cell C is preferred by the UE.
14	UE			No ATTACH REQUEST sent to the SS (SS waits 30 seconds).
15	UE			If possible (see ICS) USIM removal is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed.
16	UE			The UE gets the USIM replaced, is powered up or switched on and initiates an attach (see ICS).
17	->			Attach type = 'PS only attached' Mobile identity = IMSI
18	<-			Attach result = 'PS attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature
19	->			Routing area identity = RAI-2
20	UE			The UE is switched off or power is removed (see ICS).
21	->			Message not sent if power is removed.

## 12.4.1.2.5

## Test requirements

UE shall:



- initiate a PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

After completing the PS attach procedure, UE shall:

- initiate a routing area updating procedure with the information elements specified in the above Expected Sequence.
- delete the stored P-TMSI, P-TMSI signature, RAI and PS ciphering key sequence number .
- consider the USIM as invalid for PS services until the UE is switched off or the USIM is removed.

### 12.4.1.3 Routing area updating / rejected / UE identity cannot be derived by the network

#### 12.4.1.3.1 Definition

#### 12.4.1.3.2 Conformance requirement

If the network rejects a routing area updating procedure from the User Equipment with the cause 'UE identity cannot be derived by the network', the User Equipment shall delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.

Depending on the manufacturer the UE may or may not perform a PS attach procedure.

#### Reference

3G TS 24.008 clause 4.7.5.1

#### 12.4.1.3.3 Test purpose

To test the behaviour of the UE if the network rejects the routing area updating procedure of the UE with the cause 'UE identity cannot be derived by the network'.

#### 12.4.1.3.4 Method of test

#### Initial condition

#### System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2.

Both cells are operating in network operation mode II (in case of UE operation mode A), or in network operation mode III (in case of UE operation mode C).

#### User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

#### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode C	Yes/No
UE operation mode A	Yes/No (only if mode C not supported)
Automatic attach procedure when UE identity cannot be derived by the network	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

## Test procedure

The SS rejects a normal routing area updating with the cause value 'UE identity cannot be derived by the network'. The UE detach locally. A new PS attach may be performed.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS	ATTACH REQUEST	<p>The following messages are sent and shall be received on cell A.</p> <p>The SS is set in network operation mode II or III and activates cell A.</p> <p>The UE is set in UE operation mode C or B (see ICS).</p> <p>The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.</p> <p>Attach type = 'PS attach'</p> <p>Mobile identity = P-TMSI-1</p> <p>P-TMSI-1 signature</p> <p>Routing area identity = RAI-1</p> <p>Attach result = 'PS only attached'</p> <p>Mobile identity = P-TMSI-2</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p>
2	UE			
3	UE			
4	->			
5	<-			
6	->			
7	SS		ROUTING AREA UPDATING REQUEST	<p>The following messages are sent and shall be received on cell B.</p> <p>The SS deactivates cell A and activates cell B. Cell B is preferred by the UE.</p> <p>Update type = 'RA updating'</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p> <p>GMM cause = 'UE identity cannot be derived by the network'</p> <p>If an automatic attach procedure by the UE is not possible when the UE identity cannot be derived by the network (see ICS) goto step 19. An Automatic PS attach procedure is initiated (see ICS).</p> <p>Attach type = 'PS attach'</p> <p>Mobile identity = IMSI</p> <p>Attach result = 'PS only attached'</p> <p>Mobile identity = P-TMSI-1</p> <p>P-TMSI-1 signature</p> <p>Routing area identity = RAI-4</p>
8	UE			
9	->			
10	<-			
11	UE			
12	UE			
13	->		ATTACH REQUEST	<p>Attach type = 'PS attach'</p> <p>Mobile identity = IMSI</p> <p>Attach result = 'PS only attached'</p> <p>Mobile identity = P-TMSI-1</p> <p>P-TMSI-1 signature</p> <p>Routing area identity = RAI-4</p>
14	<-			
15	->			
16	UE		DETACH REQUEST	<p>The UE is switched off or power is removed (see ICS).</p> <p>Message not sent if power is removed.</p> <p>Detach type = 'power switched off, PS detach'</p> <p>Stop the sequence</p>
17	->			
18				
19	<-		PACKET PAGING REQUEST Or PAGING REQUEST TYPE 1	<p>Mobile identity = P-TMSI-2</p> <p>Both paging orders are for TBF establishment. PACKET PAGING REQUEST (used for NW mode III)</p> <p>PAGING REQUEST TYPE 1 (used for NW-mode II).</p> <p>No response from the UE to the request, as the UE has detached locally. This is checked for 10 seconds.</p>
20	UE			

#### 12.4.1.3.5 Test requirements

UE shall:

- initiate a PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

After completing the PS attach procedure, UE shall:

- initiate a routing area updating procedure with the information elements specified in the above Expected Sequence.
- delete stored P-TMSI, P-TMSI signature, RAI and PS ciphering key sequence number.

#### 12.4.1.4 Routing area updating / rejected / location area not allowed

##### 12.4.1.4.1 Definition

##### 12.4.1.4.2 Conformance requirement

- 1) If the network rejects a routing area updating procedure from the User Equipment with the cause 'location area not allowed' the User Equipment shall:
  - 1.1 not perform PS attach when in the same location area.
  - 1.2 delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.
  - 1.3 store the LA in the 'forbidden location areas for regional provision of service'.
- 2) If the network rejects a routing area updating procedure from the User Equipment with the cause 'location area not allowed' the User Equipment shall:
  - 2.1 perform PS attach when a new location area is entered.
  - 2.2 delete the list of forbidden LAs after switch off (power off).

#### Reference

3G TS 24.008 clauses 4.7.5.1

##### 12.4.1.4.3 Test purpose

To test the behaviour of the UE if the network rejects the routing area updating procedure of the UE with the cause 'Location Area not allowed'.

To test that the UE deletes the list of forbidden LAs when power is switched off.

##### 12.4.1.4.4 Method of test

#### Initial condition

#### System Simulator:

Three cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2, cell C in MCC1/MNC1/LAC2/RAC1.  
All cells are operating in network operation mode III.

#### User Equipment:

The UE has a valid IMSI.

## Related ICS/IXIT statements

Support of PS service	Yes/No	
UE operation mode A	Yes/No	
UE operation mode C	Yes/No	
USIM removal possible without powering down	Yes/No	
Switch off on button	Yes/No	
Automatic PS attach procedure at switch on or power on	Yes/No	

## Test procedure

The SS rejects a routing area updating with the cause value 'Location Area not allowed'. The SS checks that the UE does not perform PS attach while in the location area, performs PS attach when a new location area is entered and deletes the list of forbidden LAs when switched off.

Different types of UE may use different methods to periodically clear the list of forbidden location areas (e.g. every day at 12am). If the list is cleared while the test is being run, it may be necessary to re-run the test.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1 2  3  4 5  6	SS  SS UE  UE  ->  -<  ->		ATTACH REQUEST  ATTACH ACCEPT  ATTACH COMPLETE	The following messages are sent and shall be received on cell C. The SS activates cell C. The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 33. The UE is powered up or switched on and initiates an attach (see ICS). Cell C is preferred by the UE. Attach type = 'PS attach' Mobile identity = IMSI Attach result = 'PS only attached' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-3
7 8 9  10 11  12	SS  ->  -<  -<  UE		ROUTING AREA UPDATING REQUEST  ROUTING AREA UPDATING REJECT Or PACKET PAGING REQUEST PAGING REQUEST TYPE 1	The following messages are sent and shall be received on cell B. The SS deactivates cell C and activates cell B. Cell B is preferred by the UE. Update type = 'RA updating' P-TMSI-1 signature Routing area identity = RAI-3 GMM cause = 'Location Area not allowed'  Mobile identity = P-TMSI-1 Both paging orders are for TBF establishment. PACKET PAGING REQUEST (used for NW mode III) PAGING REQUEST TYPE 1 (used for NW-mode II). No response from the UE to the request. This is checked for 10 seconds.
13 14 15	SS UE UE			The following messages are sent and shall be received on cell A. The SS deactivates cell B and activates cell A. Cell A is preferred by the UE. No ATTACH REQUEST sent to SS (SS waits 30 seconds)
16 17 18  19  20 21  22	SS UE ->  -<  -> UE  ->		ATTACH REQUEST  ATTACH ACCEPT  ATTACH COMPLETE  DETACH REQUEST	The following messages are sent and shall be received on cell C. The SS deactivates cell B and activates cell C. Cell C is preferred by the UE. Attach type = 'PS attach' Mobile identity = IMSI Attach result = 'PS only attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-3  If possible (see ICS) USIM removal is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed. Message not sent if power is removed. Detach type = 'power switched off, PS detach'
23  24	UE  ->		ATTACH REQUEST	The UE gets the USIM replaced, is powered up or switched on and initiates an attach (see ICS). Attach type = 'PS attach' Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-3

25	<-	ATTACH ACCEPT	Attach result = 'PS only attached' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-3
26	->	ATTACH COMPLETE	
27	SS		The following messages are sent and shall be received on cell A.
28			The SS deactivates cell C and activates cell A.
29	->	ROUTING AREA UPDATING REQUEST	Cell A is preferred by the UE. Update type = 'RA updating' P-TMSI-1 signature Routing area identity = RAI-3
30	<-	ROUTING AREA UPDATING ACCEPT	No new mobile identity assigned. P-TMSI and P-TMSI signature not included. Update result = 'RA updated' P-TMSI-2 signature Routing area identity = RAI-1
31	UE		The UE is switched off or power is removed (see ICS).
32	->	DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, PS detach'
33	SS		The SS is set in network operation mode II.
34	UE		The UE is set in UE operation mode A (see ICS) and the test is repeated from step 3 to step 32.

#### 12.4.1.4.5 Test requirements

UE shall:

- initiate a PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

After completing the PS attach procedure, UE shall:

- initiate a routing area updating procedure with the information elements specified in the above Expected Sequence.

When in the same location area, UE shall

- not perform PS attach..
- store the LA in the 'forbidden location areas for regional provision of service'.

When a new location area is entered, UE shall

- perform PS attach when a.
- delete the list of forbidden LAs when power is switched off.

#### 12.4.1.5 Routing area updating / abnormal cases / attempt counter check / miscellaneous reject causes

##### 12.4.1.5.1 Definition

##### 12.4.1.5.2 Conformance requirement

- 1) When a routing area updating procedure is rejected with the attempt counter less than five, the UE shall repeat the routing area updating procedure after T3330 timeout.

- 2) When a T3330 timeout has occurred during a routing area updating procedure with the attempt counter five, the UE shall start timer T3302.
- 3) When the T3302 expires, a new routing area updating procedure shall be initiated.

GMM cause codes that can be selected are:

‘IMSI unknown in HLR’  
‘IMEI not accepted’  
‘Illegal ME’  
‘UE identity cannot be derived by the network’  
‘Network failure’  
‘Congestion’  
‘retry upon entry into a new cell’  
‘Semantically incorrect message’  
‘Invalid mandatory information’  
‘Message type non-existent or not implemented’  
‘Message type not compatible with the protocol state’  
‘Information element non-existent or not implemented’  
‘Conditional IE error’  
‘Message not compatible with the protocol state’  
‘Protocol error, unspecified’

#### Reference

3G TS 24.008 clause 4.7.5.1

#### 12.4.1.5.3 Test purpose

To test the behaviour of the UE with respect to the attempt counter.

#### 12.4.1.5.4 Method of test

#### Initial condition

#### System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2.

Both cells are operating in network operation mode II (in case of UE operation mode A), or in network operation mode III (in case of UE operation mode C).

#### User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

## Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode C	Yes/No
UE operation mode A	Yes/No (only if mode C not supported)
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

## Test procedure

The UE initiates a routing area updating procedure (attempt counter zero).

The SS rejects the routing area updating procedure with a random cause code.

The UE initiates a new routing area updating procedure (attempt counter one) after T3311 expires.

The SS rejects the routing area updating procedure with a random cause code.

The UE initiates a new routing area updating procedure (attempt counter two) after T3311 expires.

The SS rejects the routing area updating procedure with a random cause code.

The UE initiates a new routing area updating procedure (attempt counter three) after T3311 expires.

The SS rejects the routing area updating procedure with a random cause code.

The UE initiates a new routing area updating procedure (attempt counter four) after T3311 expires.

The SS rejects the routing area updating procedure with a random cause code.

The UE initiates a new routing area updating procedure with attempt counter five (after T3311 expires).

The SS rejects the routing area updating procedure with a random cause code.

The UE shall not perform a new successful routing area updating procedure after T3311 seconds.

The UE initiates a routing area updating procedure with attempt counter zero after T3302 expires with the stored P-TMSI, P-TMSI signature, PS CKSN and RAI.

T3302; set to 10 minutes.

T3330; 15 seconds.



## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE	SS	ATTACH REQUEST	<p>The following messages are sent and shall be received on cell A.</p> <p>The UE is set in UE operation mode C or B (see ICS).</p> <p>The SS is set in network operation mode II or III and activates cell A.</p> <p>The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.</p> <p>Attach type = 'PS attach'</p> <p>Mobile identity = P-TMSI-1</p> <p>P-TMSI-1 signature</p> <p>Routing area identity = RAI-1</p> <p>No new mobile identity assigned.</p> <p>P-TMSI not included.</p> <p>Attach result = 'PS only attached'</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p>
2	SS	UE		
3	UE	SS		
4	->	SS		
5	<-	UE		
6	SS	SS	ROUTING AREA UPDATING REQUEST	<p>The following messages are sent and shall be received on cell B.</p> <p>The SS deactivates cell A and activates cell B. Cell B is preferred by the UE.</p> <p>Update type = 'RA updating'</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p> <p>Random GMM cause</p> <p>The SS verifies that the time between the routing area updating requests is 15 seconds</p> <p>Update type = 'RA updating'</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p> <p>Random GMM cause</p> <p>The SS verifies that the time between the routing area updating requests is 15 seconds</p> <p>Update type = 'RA updating'</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p> <p>Random GMM cause</p> <p>The SS verifies that the time between the routing area updating requests is 15 seconds</p> <p>Update type = 'RA updating'</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p> <p>Random GMM cause</p> <p>The SS verifies that the time between the routing area updating requests is 15 seconds</p> <p>Update type = 'RA updating'</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p> <p>Random GMM cause</p> <p>The SS verifies that the time between the routing area updating requests is 15 seconds</p> <p>Update type = 'RA updating'</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p> <p>Random GMM cause</p> <p>The SS verifies that the UE does not attempt to attach for 10 minutes .</p> <p>The SS shall release the PS signalling connection.</p>
7	SS	SS		
8	->	SS		
9	<-	SS		
10	SS	SS		
11	->	SS		
12	<-	SS		
13	SS	SS		
14	->	SS		
15	<-	SS		
16	SS	SS		
17	->	SS		
18	<-	SS		
19	SS	SS		
20	->	SS		
21	<-	SS		
22	SS	SS		
23	SS	SS		

24	->	ROUTING AREA UPDATING REQUEST	Update type = 'RA updating'
25	<-	ROUTING AREA UPDATING ACCEPT	P-TMSI-2 signature Routing area identity = RAI-1 Update result = 'RA updated' Mobile identity = P-TMSI-2 P-TMSI-3 signature Routing area identity = RAI-4
26	->	ROUTING AREA UPDATING COMPLETE	
27	UE		The UE is switched off or power is removed (see ICS).
28	->	DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, PS detach'

#### 12.4.1.5.5 Test requirements

UE shall:

- initiate a PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

After completing the PS attach procedure, UE shall :

- perform the following actions depending on the conditions described below.

Case 1) A routing area updating procedure is rejected from SS with the attempt counter less than five

UE shall:

- repeat the routing area updating procedure after T3330 timeout

Case2) A timer T3330 timeout has occurred during a routing area updating procedure with the attempt counter five

UE shall:

- start timer T3302

Case3) The T3302 expires

UE shall:

- initiate a new routing area updating procedure

#### 12.4.1.6 Routing area updating / abnormal cases / change of cell into new routing area

##### 12.4.1.6.1 Definition

##### 12.4.1.6.2 Conformance requirement

When a change of cell into a new routing area is performed before the routing area updating procedure is finished, the UE shall abort the routing area updating procedure and re-initiate it in the new routing area.

#### Reference

3G TS 24.008 clause 4.7.5.1

#### 12.4.1.6.3 Test purpose

To test the behaviour of the UE in case of procedure collision.

#### 12.4.1.6.4 Method of test

##### Initial condition

##### System Simulator:

Three cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2 and cell C In MCC1/MNC1/LAC1/RAC3.

All cells are operating in network operation mode II (in case of UE operation mode A), or in network operation mode III (in case of UE operation mode C).

##### User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

##### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode C	Yes/No
UE operation mode A	Yes/No (only if mode C not supported)
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

##### Test procedure

The UE initiates a routing area updating procedure. The ROUTING AREA UPDATE ACCEPT message is delayed from the SS. The UE performs a cell update into a new routing area. The UE shall re-initiate a routing area updating procedure in the new routing area.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS	ATTACH REQUEST	<p>The following messages are sent and shall be received on cell A.</p> <p>The SS activates cell A.</p> <p>The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 18.</p> <p>The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.</p> <p>Attach result = 'PS attach'</p> <p>Mobile identity = P-TMSI-1</p> <p>P-TMSI-1 signature</p> <p>Routing area identity = RAI-1</p> <p>Attach result = 'PS only attached'</p> <p>Mobile identity = P-TMSI-2</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p>
2		SS		
3		UE		
4	->			
5	<-			
6	->			
7		SS	ROUTING AREA UPDATING REQUEST	<p>The following messages are sent and shall be received on cell B.</p> <p>The SS deactivates cell A and activates cell B. Cell B is preferred by the UE.</p> <p>Update type = 'RA updating'</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p> <p>No response to the ROUTING AREA UPDATING REQUEST message is given by the SS</p>
8		SS		
9	->			
10		SS		
11		SS	ROUTING AREA UPDATING REQUEST	<p>The following messages are sent and shall be received on cell C.</p> <p>The SS deactivates cell B and activates cell C. Cell C is preferred by the UE.</p> <p>Update type = 'RA updating'</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p> <p>Update result = 'RA updated'</p> <p>Mobile identity = P-TMSI-2</p> <p>P-TMSI-3 signature</p> <p>Routing area identity = RAI-5</p>
12		SS		
13	->			
14	<-			
15	->			
16	UE			
17	->			
18		SS		<p>The UE is switched off or power is removed (see ICS).</p> <p>Message not sent if power is removed.</p> <p>Detach type = 'power switched off, PS detach'</p>
19		UE		

## 12.4.1.6.5 Test requirements

UE shall:

- initiate a PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

After completing the PS attach procedure, UE shall:

- initiate the routing area update procedure.

When change of cell into a new routing area is performed before the routing area updating procedure is finished, UE shall:

- abort the routing area updating procedure.
- re-initiate new routing area updating procedure in the new routing area.

#### 12.4.1.7 Routing area updating / abnormal cases / change of cell during routing area updating procedure

##### 12.4.1.7.1 Definition

##### 12.4.1.7.2 Conformance requirement

When a change of cell within a new routing area is performed before the routing area updating procedure is finished, the UE shall perform the cell update before the routing area updating procedure is finished.

##### Reference

3G TS 24.008 clause 4.7.5.1

##### 12.4.1.7.3 Test purpose

To test the behaviour of the UE in case of procedure collision.

##### 12.4.1.7.4 Method of test

##### Initial condition

##### System Simulator:

Three cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2 and cell C in MCC1/MNC1/LAC1/RAC2.  
All three cells are operating in network operation mode III.

##### User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

##### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode C	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

##### Test procedure

The UE initiates a routing area updating procedure. The ROUTING AREA UPDATE ACCEPT message is delayed from the SS. The UE performs a cell update within the routing area. The UE then waits for the ROUTING AREA UPDATE ACCEPT message.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE	SS	ATTACH REQUEST	<p>The following messages are sent and shall be received on cell A.</p> <p>The UE is set in UE operation mode C or B (see ICS).</p> <p>The SS is set in network operation mode II or III and activates cell A.</p> <p>The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.</p> <p>Attach result = 'PS attach'</p> <p>Mobile identity = P-TMSI-1</p> <p>P-TMSI-1 signature</p> <p>Routing area identity = RAI-1</p> <p>No new mobile identity assigned.</p> <p>P-TMSI not included.</p> <p>Attach result = 'PS only attached'</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p>
2	SS			
3	UE			
4	->			
5	<-			
6	SS		ROUTING AREA UPDATING REQUEST	<p>The following messages are sent and shall be received on cell B.</p> <p>The SS deactivates cell A and activates cell B. Cell B is preferred by the UE.</p> <p>Update type = 'RA updating'</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p> <p>No response to the ROUTING AREA UPDATING REQUEST message is given by the SS</p>
7	SS			
8	->			
9	SS			
10	SS		UPLINK RLC DATA BLOCK  ROUTING AREA UPDATING ACCEPT  ROUTING AREA UPDATING COMPLETE  DETACH REQUEST	<p>The following messages are sent and shall be received on cell C.</p> <p>The SS deactivates cell B and activates cell C. Cell C is preferred by the UE.</p> <p>LLC PDU implicitly indicating cell update.</p> <p>Update result = 'RA updated'</p> <p>Mobile identity = P-TMSI-2</p> <p>P-TMSI-3 signature</p> <p>Routing area identity = RAI-4</p> <p>The UE is switched off or power is removed (see ICS).</p> <p>Message not sent if power is removed.</p> <p>Detach type = 'power switched off, PS detach'</p>
11	SS			
12	->			
13	<-			
14	->			
15	UE			
16	->			

## 12.4.1.7.5 Test requirements

UE shall:

- initiate a PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

After completing the PS attach procedure, UE shall:

- initiate routing area update procedure.

When a change of cell within a new routing area is performed, UE shall:

- perform the cell update before the routing area updating procedure is finished.

## 12.4.1.8 Routing area updating / abnormal cases / P-TMSI reallocation procedure collision

### 12.4.1.8.1 Definition

### 12.4.1.8.2 Conformance requirement

When a P-TMSI REALLOCATION REQUEST message is received by the UE while waiting for a ROUTING AREA UPDATE ACCEPT message, the UE shall ignore the P-TMSI reallocation procedure and continue with the routing area updating procedure.

### Reference

3G TS 24.008 clause 4.7.5.1

### 12.4.1.8.3 Test purpose

To test the behaviour of the UE in case of procedure collision.

### 12.4.1.8.4 Method of test

### Initial condition

#### System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 and cell B in MCC1/MNC1/LAC1/RAC2.

Both cells are operating in network operation mode II (in case of UE operation mode A), or in network operation mode III (in case of UE operation mode C).

#### User Equipment:

The UE has a valid IMSI.

### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode C	Yes/No
UE operation mode A	Yes/No (only if mode C not supported)
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

### Test procedure

The UE initiates a routing area updating procedure. The SS does not answer the routing area updating procedure, but initiates a P-TMSI reallocation procedure. The UE shall ignore the P-TMSI reallocation procedure and continue with the routing area updating procedure.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE	SS	ATTACH REQUEST	The following messages are sent and shall be received on cell A. The UE is set in UE operation mode C or B (see ICS).
2	SS	UE		The SS is set in network operation mode II or III and activates cell A.
3	UE	SS		The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.
4	->	SS		Attach result = 'PS attach' Mobile identity = IMSI
5	<-	UE		Attach result = 'PS only attached' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1
6	->	SS		
7	SS	UE	ROUTING AREA UPDATING REQUEST	The following messages are sent and shall be received on cell B. The SS deactivates cell A and activates cell B. Cell B is preferred by the UE.
8	SS	UE		Update type = 'RA updating' P-TMSI-1 signature Routing area identity = RAI-1
9	->	SS		Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1
10	<-	UE		The UE ignores the P-TMSI reallocation request.
11	UE	SS		Update result = 'RA updated' Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-4
12	<-	SS		
13	->	UE		
14	UE	SS		The UE is switched off or power is removed (see ICS). Message not sent if power is removed.
15	->	SS		Detach type = 'power switched off, PS detach'

## 12.4.1.8.5 Test requirements

UE shall:

- initiate a PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

After completing the PS attach procedure, UE shall:

- initiate the routing area updating procedure.

When a P-TMSI REALLOCATION REQUEST message is received from SS while waiting for a ROUTING AREA UPDATE ACCEPT message, UE shall:

- ignore the P-TMSI reallocation procedure
- continue with the routing area updating procedure.



## 12.4.2 Combined routing area updating

The combined routing area updating procedure is a GMM procedure used by PS UEs of UE operation mode A that are IMSI attached for PS and non-PS services. In order to use the combined routing area updating procedure, the network must operate in network operation mode I.

### 12.4.2.1 Combined routing area updating / combined RA/LA accepted

#### 12.4.2.1.1 Definition

#### 12.4.2.1.2 Conformance requirement

- 1) If the network accepts the combined routing area updating procedure and reallocates a P-TMSI, the UE shall acknowledge the new P-TMSI and continue communication with the new P-TMSI.
- 2) If the network accepts the combined routing area updating procedure from the UE without reallocation of the old P-TMSI, the UE shall continue communication with the old P-TMSI.

#### Reference

3G TS 24.008 clause 4.7.5.2

#### 12.4.2.1.3 Test purpose

To test the behaviour of the UE if the network accepts the combined routing area updating procedure.

The following cases are identified:

- 1) P-TMSI / P-TMSI signature is reallocated
- 2) Old P-TMSI / P-TMSI signature is not changed
- 3) Mobile terminating CS call is allowed with IMSI
- 4) Mobile terminating CS call is allowed with TMSI

#### 12.4.2.1.4 Method of test

#### Initial condition

#### System Simulator:

Two cells, cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2.  
Both cells operating in network operation mode I.

#### User Equipment:

The UE has a valid IMSI.

#### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

#### Test procedure

- 1) A combined PS attach procedure is performed. The UE sends a ROUTING AREA UPDATE REQUEST message. The SS reallocates the P-TMSI, unassigns the TMSI and returns ROUTING AREA UPDATE

ACCEPT message with a new P-TMSI and IMSI. The UE acknowledge the new P-TMSI by sending ROUTING AREA UPDATING COMPLETE message. Further communication UE - SS is performed by the new P-TMSI. For CS calls, the IMSI is used

- 2) The UE is CS paged in order to verify that the IMSI is used for CS calls.
- 3) A combined PS attach procedure is performed. The UE sends an ROUTING AREA UPDATING REQUEST message. The SS accepts the P-TMSI signature and returns ROUTING AREA UPDATING ACCEPT message without any P-TMSI and with a new TMSI. The UE acknowledge the new TMSI by sending ROUTING AREA UPDATING COMPLETE message. Further communication UE-SS is performed by the old P-TMSI. For CS calls, the new TMSI is used.
- 4) The UE is CS paged in order to verify that the TMSI is used for CS calls.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The UE is set in UE operation mode A (see ICS).
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI
4	<-		ATTACH ACCEPT	TMSI status = no valid TMSI available Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature
5	->		ATTACH COMPLETE	Routing area identity = RAI-1
6	SS			The following messages are sent and shall be received on cell B. Activate cell B with a lower signal strength than cell A. The RF level of cell A is lowered until cell B is preferred by the UE.
7	->		ROUTING AREA UPDATING REQUEST	Update type = 'Combined RA/LA updating' P-TMSI-2 signature Routing area identity = RAI-1
8	<-		ROUTING AREA UPDATING ACCEPT	TMSI status = no valid TMSI available Update result = 'Combined RA/LA updated' Mobile identity = P-TMSI-1 P-TMSI-1 signature
9	->		ROUTING AREA UPDATING COMPLETE	Mobile identity = IMSI
10	<-		PACKET PAGING REQUEST	Routing area identity = RAI-4
11	->		UPLINK RLC DATA BLOCK	Mobile identity = P-TMSI-1 Paging order is for TBF establishment.
12	<-		PACKET PAGING REQUEST	LLC PDU implicitly indicating paging response.
13	->		CHANNEL REQUEST	Mobile identity = IMSI
14	<-		IMMEDIATE ASSIGNMENT	Paging order is for RRC-connection.
15	->		PAGING RESPONSE	
16	<-		CHANNEL RELEASE	Mobile identity = IMSI After sending of this message, the SS waits for disconnection of the CS signalling link.
17	SS			The following messages are sent and shall be received on cell A.
18	->		ROUTING AREA UPDATING REQUEST	The RF level of cell A is increased and the RF level of cell B is lowered until cell A is preferred by the UE. Update type = 'Combined RA/LA updating' P-TMSI-1 signature Routing area identity = RAI-4
19	<-		ROUTING AREA UPDATING ACCEPT	TMSI status = no valid TMSI available Update result = 'Combined RA/LA updated' Mobile identity = P-TMSI-2 P-TMSI-2 signature
20	->		ROUTING AREA UPDATING COMPLETE	Mobile identity = TMSI-1
21	<-		PACKET PAGING REQUEST	Routing area identity = RAI-1
22	->		UPLINK RLC DATA BLOCK	Mobile identity = P-TMSI-2 Paging order is for TBF establishment.
23	<-		PACKET PAGING REQUEST	LLC PDU implicitly indicating paging response.
24	->		CHANNEL REQUEST	Mobile identity = TMSI-1
25	<-		IMMEDIATE ASSIGNMENT	Paging order is for RRC-connection.

26	->	PAGING RESPONSE	Mobile identity = TMSI-1 After sending of this message, the SS waits for disconnection of the CS signalling link.
27	<-	CHANNEL RELEASE	
28	UE		The UE is switched off or power is removed (see ICS).
29	->	DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, combined PS / IMSI detach'

#### 12.4.2.1.5 Test requirements

UE shall :

- initiate a combined PS attach procedure with information elements specified in the above Expected Sequence when UE is powered up or switched on.

After completing the PS attach procedure, UE shall:

- initiate a combined routing area update procedure (Update type = 'Combined RA/LA updating') with the information elements specified above Expected Sequence when RF level of the attached cell is lower than the RF level of the new cell.
- acknowledge the new P-TMSI
- continue communication with the new P-TMSI If SS reallocates a P-TMSI.
- continue communication with the old P-TMSI If SS does not reallocate the old P-TMSI.

#### 12.4.2.2 Combined routing area updating / UE in CS operation at change of RA

##### 12.4.2.2.1 Definition

##### 12.4.2.2.2 Conformance requirement

PS UE that is in an ongoing CS transaction at change of routing area shall initiate the routing area updating procedure only after the CS transaction has been released.

##### Reference

3G TS 24.008 clause 4.7.5.2

##### 12.4.2.2.3 Test purpose

To test the behaviour of the UE when using the combined routing area updating procedure in cases where the UE is CS connected at change of RA.

##### 12.4.2.2.4 Method of test

##### Initial condition

System Simulator:

Two cells, cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2.  
Both cells operating in network operation mode I.

User Equipment:

The UE has a valid IMSI.

## Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

## Test procedure

A combined PS attach procedure is performed. The UE initiates a CS call. The routing area change. UE will not send a ROUTING AREA UPDATE REQUEST message until the CS operation is terminated.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The UE is set in UE operation mode A (see ICS).
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI
4	<-		ATTACH ACCEPT	TMSI status = no valid TMSI available Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature
5	->		ATTACH COMPLETE	Routing area identity = RAI-1
6	UE			A CS call is initiated.
7		SS		The following messages are sent and shall be received on cell B. Activate cell B with a lower signal strength than cell A. The RF level of cell A is lowered until cell B is preferred by the UE.
8	UE			No RA updating procedure is initiated.
9	UE			This is checked for 60 seconds.
10	->		ROUTING AREA UPDATING REQUEST	The CS call is terminated Update type = 'Combined RA/LA updating' P-TMSI-2 signature Routing area identity = RAI-1
11	<-		ROUTING AREA UPDATING ACCEPT	TMSI status = no valid TMSI available Update result = 'Combined RA/LA updated' Mobile identity = P-TMSI-1 P-TMSI-1 signature Mobile identity = IMSI
12	->		ROUTING AREA UPDATING COMPLETE	Routing area identity = RAI-4
13	<-		PACKET PAGING REQUEST	Mobile identity = P-TMSI-1
14	->		UPLINK RLC DATA BLOCK	Paging order is for TBF establishment. LLC PDU implicitly indicating paging response.
15	<-		PACKET PAGING REQUEST	Mobile identity = IMSI Paging order is for RRC-connection.
16	->		CHANNEL REQUEST	
17	<-		IMMEDIATE ASSIGNMENT	
18	->		PAGING RESPONSE	Mobile identity = IMSI
19	<-		CHANNEL RELEASE	After sending of this message, the SS waits for disconnection of the CS signalling link.
20	UE			The UE is switched off or power is removed (see ICS).
21	->		DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, combined PS / IMSI detach'

#### 12.4.2.2.5 Test requirements

UE shall :

- initiate a combined PS attach procedure with information elements specified in the above Expected Sequence when UE is powered up or switched on.

After completing the PS attach procedure, UE shall:

- initiate a CS call. at change of routing area.
- initiate a routing area updating procedure only after the CS transaction has been released.

#### 12.4.2.3 Combined routing area updating / RA only accepted

##### 12.4.2.3.1 Definition

##### 12.4.2.3.2 Conformance requirement

- 1) If the network accepts the combined PS attach procedure, but GMM cause code 'IMSI unknown in HLR' is sent to the UE the User Equipment shall delete the stored TMSI, LAI and CKSN. The User Equipment shall consider USIM invalid for non-PS services until power is switched off or USIM is removed.
- 2) If the network accepts the combined PS attach procedure, but GMM cause code 'MSC temporarily not reachable', 'Network failure' or 'Congestion' is sent to the UE, an UE operation mode A UE may perform an MM IMSI attach procedure.

#### Reference

3G TS 24.008 clause 4.7.3.2

##### 12.4.2.3.3 Test purpose

###### Test purpose1

To test the behaviour of the UE if the network accepts the routing area updating procedure with indication RA only, GMM cause 'IMSI unknown in HLR'.

###### Test purpose2

To test the behaviour of the UE if the network accepts the routing area updating procedure with indication RA only, GMM cause 'MSC temporarily not reachable', 'Network failure' or 'Congestion'.

##### 12.4.2.3.4 Method of test

###### Test Procedure1

###### Initial condition

###### System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2.  
Both cells operating in network operation mode I.

###### User Equipment:

The UE has a valid ITMSI.

## Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

## Test procedure

After attach, the UE sends an ROUTING AREA UPDATE REQUEST message. The SS allocates a P-TMSI and returns ROUTING AREA UPDATE ACCEPT message with a P-TMSI. GMM cause 'IMSI unknown in HLR' is indicated from SS. Further communication UE - SS is performed by the P-TMSI. CS services are not possible.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The UE is set in UE operation mode A (see ICS).
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI
4	<-		ATTACH ACCEPT	TMSI status = no valid TMSI available Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature
5	->		ATTACH COMPLETE	Routing area identity = RAI-1
6	SS			The following messages are sent and shall be received on cell B.
7	->		ROUTING AREA UPDATING REQUEST	The SS deactivates cell A and activates cell B. Update type = 'Combined RA/LA updating' P-TMSI-2 signature Routing area identity = RAI-1
8	<-		ROUTING AREA UPDATING ACCEPT	TMSI status = no valid TMSI available Update result = 'RA updated' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-4 GMM cause = 'IMSI unknown in HLR'
9	->		ROUTING AREA UPDATING COMPLETE	
10	<-		PACKET PAGING REQUEST	Mobile identity = P-TMSI-1 Paging order is for TBF establishment.
11	->		UPLINK RLC DATA BLOCK	LLC PDU implicitly indicating paging response.
12	<-		PACKET PAGING REQUEST	Mobile identity = IMSI Paging order is for RRC-connection.
13	UE			The UE shall not initiate an RRC connection. This is checked during 3 seconds.
14	UE			The UE is switched off or power is removed (see ICS).
15	->		DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, PS detach'

## Test Procedure2

## Initial condition

## System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2.  
Both cells operating in network operation mode I.

#### User Equipment:

The UE has a valid IMSI.

#### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Automatic MM IMSI attach procedure for UE operation mode A UE	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

#### Test procedure

After attach, the UE sends an ROUTING AREA UPDATE REQUEST message . The SS allocates a new P-TMSI signature and returns ROUTING AREA UPDATE ACCEPT message. GMM cause 'MSC temporarily not reachable', 'Network failure' or 'Congestion' is indicated from SS. The cause code is arbitrarily chosen. An UE operation mode A UE may perform an MM IMSI attach procedure (according to the ICS statement). Further communication UE - SS is performed by the P-TMSI. The existence of a signalling channel is verified by a request for mobile identity. CS services are not possible unless an IMSI attach procedure is performed.

#### Expected Sequence

Dependent whether the option 'Automatic MM IMSI attach procedure for UE operation mode A UE' is not supported or not, the steps 1-13 or 14-35 apply depending on manufacturer (see ICS).



Step	Direction		Message	Comments
	UE	SS		
1	UE			The following messages are sent and shall be received on cell A The UE is set in UE operation mode A and no automatic MM IMSI attach procedure is indicated (see ICS). The UE is powered up or switched on and initiates an attach (see ICS).
2	UE			
3	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI TMSI status = no valid TMSI available Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-1
4	<-		ATTACH ACCEPT	
5	->		ATTACH COMPLETE	
6	SS			The following messages are sent and shall be received on cell B. The SS deactivates cell A and activates cell B. Update type = 'Combined RA/LA updating' P-TMSI-2 signature Routing area identity = RAI-1 TMSI status = no valid TMSI available Update result = 'RA updated' Mobile identity = P-TMSI-1P-TMSI-1 signature Routing area identity = RAI-4 GMM cause = 'MSC temporarily not reachable', 'Network failure' or 'Congestion' (arbitrarily chosen)  Mobile identity = IMSI Paging order is for RRC-connection. The UE shall not initiate an RRC connection. This is checked during 3 seconds. The UE is switched off or power is removed (see ICS). Message not sent if power is removed. Detach type = 'power switched off, PS detach' Stop the sequence.
7	->		ROUTING AREA UPDATING REQUEST	
8	<-		ROUTING AREA UPDATING ACCEPT	
9	->		ROUTING AREA UPDATING COMPLETE	
10	<-		PACKET PAGING REQUEST	
11	UE			
12	UE			
13	->		DETACH REQUEST	
14	UE			The following messages are sent and shall be received on cell B Automatic MM IMSI attach procedure is indicated (see ICS). The UE is powered up or switched on and initiates an attach (see ICS). Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI TMSI status = no valid TMSI available Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-4
15	UE			
16	->		ATTACH REQUEST	
17	<-		ATTACH ACCEPT	
18	->		ATTACH COMPLETE	
19	SS			The following messages are sent and shall be received on cell A. The SS deactivates cell B and activates cell A. Update type = 'Combined RA/LA updating' P-TMSI-2 signature Routing area identity = RAI-4 TMSI status = no valid TMSI available
20	->		ROUTING AREA UPDATING REQUEST	

21	<-	ROUTING AREA UPDATING ACCEPT	Update result = 'RA updated' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1 GMM cause = 'MSC temporarily not reachable', 'Network failure' or 'Congestion' (arbitrarily chosen)
22	->	ROUTING AREA UPDATING COMPLETE	
23	->	CHANNEL REQUEST	
24	<-	IMMEDIATE ASSIGNMENT	
25	->	LOCATION UPDATING REQ	Location updating type = IMSI attach.
26	<-	LOCATION UPDATING ACC	The SS allocates a new TMSI.
27	->	TMSI REALLOCATION COMP	Location updating type = IMSI attach.
28	<-	CHANNEL RELEASE	After sending of this message, the SS waits for disconnection of the CS signalling link.
29	<-	PACKET PAGING REQUEST	Mobile identity = TMSI-1 Paging order is for RRC-connection.
30	->	CHANNEL REQUEST	
31	<-	IMMEDIATE ASSIGNMENT	
32	->	PAGING RESPONSE	Mobile identity = TMSI-1
33	<-	CHANNEL RELEASE	After sending of this message, the SS waits for disconnection of the CS signalling link.
34	UE		The UE is switched off or power is removed (see ICS).
35	->	DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, PS detach'

#### 12.4.2.3.5 Test requirements

UE shall :

- initiate a combined PS attach procedure with information elements specified in the above Expected Sequence when UE is powered up or switched on.

After completing the PS attach procedure, UE shall:

- initiate a combined routing area updating procedure.
- perform the following actions depending on the GMM cause.

Case 1) GMM cause = 'IMSI unknown in HLR'.

UE shall:

- delete the stored TMSI, LAI and CKSN.
- consider USIM invalid for non-PS services until power is switched off or USIM is removed.

Case 2) GMM cause = 'MSC temporarily not reachable', 'Network failure' or 'Congestion'.

UE shall:

- perform an MM IMSI attach procedure. (only applied UE operation mode A)

## 12.4.2.4 Combined routing area updating / rejected / PLMN not allowed

### 12.4.2.4.1 Definition

### 12.4.2.4.2 Conformance requirement

- 1) If the network rejects a combined routing area updating procedure from the User Equipment with the cause 'PLMN not allowed' the User Equipment shall:
  - 1.1 not perform combined GPRA attach when switched on in the same location area or PLMN.
  - 1.2 delete the stored RAI, PS-CKSN, P-TMSI, P-TMSI signature, TMSI CKSN and LAI.
  - 1.3 store the PLMN in the 'forbidden PLMN list'.

### Reference

3G TS 24.008 clause 4.7.5.2

### 12.4.2.4.3 Test purpose

To test the behaviour of the UE if the network rejects the combined routing area updating procedure of the UE with the cause 'PLMN not allowed'.

### 12.4.2.4.4 Method of test

#### Initial condition

#### System Simulator:

Four cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2, cell C in MCC1/MNC1/LAC2/RAC1 and cell D in MCC2/MNC1/LAC1/RAC1. All four cells are operating in network operation mode I

#### User Equipment:

The UE has a valid IMSI.

### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

### Test procedure

The SS rejects a combined routing area updating with the cause value 'PLMN not allowed'. The SS checks that the UE does not perform PS attach if activated in the same PLMN. The SS checks that the UE does not perform IMSI attach if activated in the same PLMN.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS	ATTACH REQUEST  ATTACH ACCEPT  ATTACH COMPLETE	The following messages are sent and shall be received on cell A. The SS activates cell A. The UE is powered up or switched on and initiates an attach (see ICS. Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI TMSI status = no valid TMSI available Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-1 Mobile identity = TMSI-1
2	UE			
3	->			
4	<-			
5	->			
7		SS	ROUTING AREA UPDATING REQUEST  ROUTING AREA UPDATING REJECT  PACKET PAGING REQUEST	The following messages are sent and shall be received on cell B. The SS deactivates cell A and activates cell B. Cell B is preferred by the UE. Update type = 'Combined RA/LA updating' P-TMSI-2 signature Routing area identity = RAI-1 TMSI status = valid TMSI available GMM cause = 'PLMN not allowed'  The UE initiates an attach by MMI or AT command. No ATTACH REQUEST sent to SS (SS waits 30 seconds). Mobile identity = P-TMSI-2 Paging order is for TBF establishment. No response from the UE to the request. This is checked for 10 seconds.
8	UE			
9	->			
10	<-			
11	UE			
12	UE			
13	<-			
14	UE			
15		SS	PACKET PAGING REQUEST	The following messages are sent and shall be received on cell C. The SS deactivates cell B and activates cell C. Cell C is preferred by the UE. The UE initiates an attach by MMI or by AT command. No ATTACH REQUEST sent to SS (SS waits 30 seconds). Mobile identity = TMSI-1 Paging order is for RRC-connection. The UE shall not initiate an RRC connection. This is checked during 3 seconds.
16	UE			
17	UE			
18	UE			
19	<-			
20	UE			
21		SS	PACKET PAGING REQUEST	The following messages are sent and shall be received on cell A. The SS deactivates cell C and activates cell A. Cell A is preferred by the UE. The UE initiates an attach by MMI or by AT command. No ATTACH REQUEST sent to SS (SS waits 30 seconds). Mobile identity = P-TMSI-2 Paging order is for TBF establishment. No response from the UE to the request. This is checked for 10 seconds.
22	UE			
23	UE			
24	UE			
25	<-			
26	UE			
27		SS		The following messages are sent and shall be received on cell D. The SS deactivates cell A and activates cell D. Cell D is preferred by the UE. The UE initiates an attach automatically, by MMI or by AT command.
28	UE			
29	UE			

30	->	ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI
31	<-	ATTACH ACCEPT	TMSI status = no valid TMSI available Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-2 Mobile identity = IMSI
32	->	ATTACH COMPLETE	
33	UE		The UE is switched off or power is removed (see ICS).
34	->	DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, combined PS / IMSI detach'

#### 12.4.2.4.5 Test requirements

UE shall :

- initiate a combined PS attach procedure with information elements specified in the above Expected Sequence when UE is powered up or switched on.

After completing the PS attach procedure, UE shall:

- initiate a combined routing area update procedure (Update type = 'Combined RA/LA updating') with the information elements specified above Expected Sequence
- delete the stored P-TMSI, P-TMSI signature, TMSI, RAI, LAI, ciphering key sequence number PS ciphering key sequence number.
- reset the location update attempt counter when UE receive the ROUTING AREA UPDATING REJECT message (GMM cause = 'PLMN not allowed') from SS.
- store the PLMN identity in the 'forbidden PLMN list'.
- not perform combined PS attach procedure when the UE is switched on in the same PLMN.

#### 12.4.2.5 Combined routing area updating / rejected / roaming not allowed in this location area

##### 12.4.2.5.1 Definition

##### 12.4.2.5.2 Conformance requirement

- 1) If the network rejects a combined routing area updating procedure from the User Equipment with the cause 'roaming not allowed in this location area' the User Equipment shall:
  - 1.1 not perform combined PS attach when in the same location area.
  - 1.2 delete the stored RAI, PS-CKSN, P-TMSI P-TMSI signature, TMSI, CKSN and LAI.
  - 1.3 store the LA in the 'forbidden location areas for roaming'.
  - 1.4 perform combined PS attach when a new location area is entered.
- 2) The User Equipment shall reset the list of 'Forbidden location areas for roaming' when switched off or when the USIM is removed.

## Reference

3G TS 24.008 clause 4.7.5.2

## 12.4.2.5.3 Test purpose

## Test purpose1

To test that on receipt of a rejection using the 'Roaming not allowed in this area' cause code, the UE ceases trying a routing area updating procedure on that location area. Successful combined routing area updating procedure is possible in other location areas.

## Test purpose2

To test that if the UE is switched off or the USIM is removed the list of 'forbidden location areas for roaming' is cleared.

## 12.4.2.5.4 Method of test

## 12.4.2.5.4.1 Test procedure1

## Initial condition

## System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC2/RAC1.

Both cells are operating in network operation mode I.

## User Equipment:

The UE has a valid IMSI.

## Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

## Test procedure

The SS rejects a combined routing area updating with the cause value 'Roaming not allowed in this area'. A new attempt for a combined PS attach is not possible. Successful combined PS attach procedure is performed in another location area. The UE is moved back to the 1<sup>st</sup> location area. A combined routing area updating shall not be performed, as the LA is on the forbidden list.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		<p>The following messages are sent and shall be received on cell A.</p> <p>The SS activates cell A.</p> <p>The UE is powered up or switched on and initiates an attach (see ICS).</p> <p>Attach type = 'Combined PS / IMSI attach'</p> <p>Mobile identity = IMSI</p> <p>TMSI status = no valid TMSI available</p> <p>Attach result = 'Combined PS / IMSI attached'</p> <p>Mobile identity = P-TMSI-2</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p> <p>Mobile identity = IMSI</p>
2		SS		
3		UE		
4	->		ATTACH REQUEST	
5	<-		ATTACH ACCEPT	
6			ATTACH COMPLETE	
7		SS		<p>The following messages are sent and shall be received on cell B.</p> <p>The SS deactivates cell A and activates cell B.</p> <p>Cell B is preferred by the UE.</p> <p>Update type = 'Combined RA/LA updating'</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p> <p>TMSI status = no valid TMSI available</p> <p>GMM cause = 'Roaming not allowed in this area'</p> <p>The UE initiates an attach by MMI or by AT command.</p> <p>No ATTACH REQUEST sent to SS (SS waits 30 seconds).</p> <p>Mobile identity = P-TMSI-2</p> <p>Paging order is for TBF establishment.</p> <p>No response from the UE to the request. This is checked for 10 seconds.</p> <p>Mobile identity = IMSI</p> <p>Paging order is for RRC-connection.</p> <p>The UE shall not initiate an RRC connection. This is checked during 3 seconds.</p>
8		SS		
9		UE		
10	->		ROUTING AREA UPDATING REQUEST	
11	<-		ROUTING AREA UPDATING REJECT	
12		UE		
13		UE		
14	->		PACKET PAGING REQUEST	
15				
16	<-		PACKET PAGING REQUEST	
17		SS		<p>The following messages are sent and shall be received on cell A.</p> <p>The SS deactivates cell B and activates cell A.</p> <p>Cell A is preferred by the UE.</p> <p>The UE initiates an attach automatically, by MMI or by AT command.</p> <p>Attach type = 'Combined PS / IMSI attach'</p> <p>Mobile identity = IMSI</p> <p>TMSI status = no valid TMSI available</p> <p>Attach result = 'Combined PS / IMSI attached'</p> <p>Mobile identity = P-TMSI-1</p> <p>P-TMSI-1 signature</p> <p>Routing area identity = RAI-1</p> <p>Mobile identity = TMSI-1</p> <p>Mobile identity = TMSI-1</p> <p>Paging order is for RRC-connection.</p> <p>Mobile identity = TMSI-1</p> <p>After sending of this message, the SS waits for disconnection of the CS signalling link.</p> <p>Mobile identity = P-TMSI-1</p> <p>Paging order is for TBF establishment.</p> <p>LLC PDU implicitly indicating paging response.</p>
18		SS		
19		UE		
20	->		ATTACH REQUEST	
21	<-		ATTACH ACCEPT	
22			ATTACH COMPLETE	
23	->		PACKET PAGING REQUEST	
24				
25	->		CHANNEL REQUEST	
26	<-		IMMEDIATE ASSIGNMENT	
27	->		PAGING RESPONSE	
28	<-		CHANNEL RELEASE	
29				
30	->		PACKET PAGING REQUEST	
31				
32	->		UPLINK RLC DATA BLOCK	

30	SS		The following messages are sent and shall be received on cell B.
31	UE		The SS deactivates cell A and activates cell B.
32	<-	PACKET PAGING REQUEST	No ROUTING AREA UPDATING REQUEST sent to SS
33	UE		(SS waits 30 seconds).
34	<-	PACKET PAGING REQUEST	Mobile identity = P-TMSI-2
35	UE		Paging order is for TBF establishment.
			No response from the UE to the request. This is checked for 10 seconds.
			Mobile identity = IMSI
			Paging order is for RRC-connection.
			The UE shall not initiate an RRC connection.
			This is checked during 3 seconds.

#### 12.4.2.5.4.2 Test procedure2

##### Initial condition

##### System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC/LAC2/RAC1.

Both cells are operating in network operation mode I.

##### User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

##### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
USIM removal possible without powering down	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

##### Test procedure

The SS rejects a combined routing area updating with the cause value 'Roaming not allowed in this area'. The UE is switched off for 10 seconds and switched on again. The SS checks that a combined PS attach is possible on the cell on which the previous combined routing area updating had been rejected.

If USIM removal is possible without switching off:

The SS rejects a routing area updating with the cause value 'Roaming not allowed in this area'. The USIM is removed and inserted in the UE. The SS checks that a PS attach procedure and routing area updating procedure is possible on the cell on which the routing area updating had previously been rejected.



## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		The following messages are sent and shall be received on cell A.
2		SS		The SS activates cell A.
3		UE		The UE is powered up or switched on and initiates an attach (see ICS).
4	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI
5	<-		ATTACH ACCEPT	TMSI status = no valid TMSI available Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-1
6	->		ATTACH COMPLETE	Mobile identity = IMSI
7		SS		The following messages are sent and shall be received on cell B.
8		SS		The SS deactivates cell A and activates cell B.
9		UE		Cell B is preferred by the UE.
10	->		ROUTING AREA UPDATING REQUEST	Update type = 'Combined RA/LA updating' P-TMSI-2 signature Routing area identity = RAI-1
11	<-		ROUTING AREA UPDATING REJECT	TMSI status = no valid TMSI available GMM cause = 'Roaming not allowed in this area'
12	UE			The UE initiates an attach by MMI or by AT command.
13	UE			No ATTACH REQUEST sent to SS (SS waits 30 seconds).
14	<-		PACKET PAGING REQUEST	Mobile identity = P-TMSI-2 Paging order is for TBF establishment.
15	UE			No response from the UE to the request. This is checked for 10 seconds.
16	<-		PACKET PAGING REQUEST	Mobile identity = IMSI Paging order is for RRC-connection.
17	UE			The UE shall not initiate an RRC connection. This is checked during 3 seconds.
18	UE			If possible (see ICS) USIM removal is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed.
19	UE			The UE gets the USIM replaced, is powered up or switched on and initiates an attach (see ICS).
20	UE			The UE initiates an attach by MMI or AT command.
21	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI
22	<-		ATTACH ACCEPT	TMSI status = no valid TMSI available Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1
23	->		ATTACH COMPLETE	Mobile identity = TMSI-1
24	<-		PACKET PAGING REQUEST	Paging order is for RRC-connection.
25	->		CHANNEL REQUEST	
26	<-		IMMEDIATE ASSIGNMENT	
27	->		PAGING RESPONSE	Mobile identity = TMSI-1
28	<-		CHANNEL RELEASE	After sending of this message, the SS waits for disconnection of the CS signalling link.
29	<-		PACKET PAGING REQUEST	Mobile identity = P-TMSI-1 Paging order is for TBF establishment.

29	->	UPLINK RLC DATA BLOCK	LLC PDU implicitly indicating paging response.
30	UE		The UE is switched off or power is removed (see ICS).
31	->	DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, combined PS/IMSI detach'

#### 12.4.2.5.5 Test requirements

UE shall :

- initiate a combined PS attach procedure with information elements specified in the above Expected Sequence when UE is powered up or switched on.

After completing the PS attach procedure, UE shall:

- initiate a combined routing area update procedure(Update type = 'Combined RA/LA updating') with the information elements specified above Expected Sequence
- delete the stored P-TMSI, P-TMSI signature, TMSI, RAI, LAI, ciphering key sequence number PS ciphering key sequence number.
- reset the location update attempt counter when UE receive the ROUTING AREA UPDATING REJECT message(GMM cause = 'Roaming not allowed in this area') from SS.
- store the LAI in the 'forbidden location areas for roaming'.
- not perform combined PS attach procedure when the UE is switched on in the same location area.
- perform combined PS attach procedure when a new location area is entered.

#### 12.4.2.6 Combined routing area updating / abnormal cases / access barred due to access class control

##### 12.4.2.6.1 Definition

##### 12.4.2.6.2 Conformance requirement

- 1) The UE shall not perform combined routing area updating procedure, but stays in the current serving cell and applies normal cell reselection process.
- 2) The User Equipment shall perform the combined routing area updating procedure when:
  - 2.1 Access is granted.
  - 2.2 Cell is changed.

#### Reference

3G TS 24.008 clause 4.7.5.2

##### 12.4.2.6.3 Test purpose

#### Test porpose1

To test the behaviour of the UE in case of access class control (access is granted).

## Test purpose2

To test the behaviour of the UE in case of access class control (cell is changed).

### 12.4.2.6.4 Method of test

#### 12.4.2.6.4.1 Test procedure1

#### Initial condition

A random access class x (0-15) is selected. The USIM is programmed with this access class x. Communication with User Equipments using access class x is initially indicated to be barred.

#### System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC/LAC1/RAC2.

Both cells are operating in network operation mode I.

Access class x barred.

#### User Equipment:

The UE has a valid P-TMSI, P-TMSI signature and RAI.

#### Related ICS/IXIT statements

Support of PS service      Yes/No

UE operation mode A      Yes/No

Switch off on button      Yes/No

Automatic PS attach procedure at switch on or power on      Yes/No

#### Test procedure

A PS attach procedure is performed. The routing area is changed. The SS indicates access class x barred. A routing area updating procedure is not performed.

The SS indicates that access class x is not barred. A routing area updating procedure is performed.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		<p>The following messages are sent and shall be received on cell A.</p> <p>The SS activates cell A.</p> <p>The UE is powered up or switched on and initiates an attach (see ICS).</p> <p>Attach type = 'Combined PS / IMSI attach'</p> <p>Mobile identity = IMSI</p> <p>TMSI status = no valid TMSI available</p> <p>Attach result = 'Combined PS / IMSI attached'</p> <p>Mobile identity = P-TMSI-2</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p> <p>Mobile identity = IMSI</p>
2		SS		
3		UE		
4	->		ATTACH REQUEST	
5	<-		ATTACH ACCEPT	
6			ATTACH COMPLETE	
7		SS		<p>The following messages are sent and shall be received on cell B.</p> <p>The SS deactivates cell A and activates cell B.</p> <p>Cell B is preferred by the UE.</p> <p>No ROUTING AREA UPDATE REQUEST sent to SS, as access class X is barred (SS waits 30 seconds).</p> <p>The access class x is not barred anymore.</p> <p>Update type = 'Combined RA/LA updating'</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p> <p>TMSI status = no valid TMSI available</p> <p>Update result = 'Combined RA/LA updated'</p> <p>Mobile identity = P-TMSI-1</p> <p>P-TMSI-1 signature</p> <p>Mobile identity = TMSI-1</p> <p>Routing area identity = RAI-4</p>
8		UE		
9		UE		
10		SS		
11	->		ROUTING AREA UPDATING REQUEST	
12	<-		ROUTING AREA UPDATING ACCEPT	
13	->		ROUTING AREA UPDATING COMPLETE	
14		UE		<p>The UE is switched off or power is removed (see ICS).</p> <p>Message not sent if power is removed.</p> <p>Detach type = 'power switched off, combined PS/IMSI detach'</p>
15	->		DETACH REQUEST	

## 12.4.2.6.4.2 Test procedure2

## Initial condition

A random access class x (0-15) is selected. The USIM is programmed with this access class x. Communication with User Equipments using access class x is indicated to be barred on cell A.

## System Simulator:

Three cells, cell A in MCC1/MNC1/LAC1/RAC1 has access class x not barred, cell B in MCC1/MNC1/LAC1/RAC2 has access class x barred, cell C in MCC1/MNC1/LAC1/RAC2 has access class x not barred.

All three cells are operating in network operation mode I.

User Equipment:

The UE has a valid IMSI.

#### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

#### Test procedure

A PS attach procedure is performed. The routing area is changed. The SS indicates access class x barred. A routing area updating procedure is not performed.

A cell change is performed into a cell where access class x is not barred. A routing area updating procedure is performed.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS	ATTACH REQUEST	The following messages are sent and shall be received on cell A. The SS activates cell A. The UE is powered up or switched on and initiates an attach (see ICS). Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI TMSI status = no valid TMSI available Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-1 Mobile identity = IMSI
2		SS		
3		UE		
4		->		
5		<-		
6			ATTACH ACCEPT	The following messages are sent and shall be received on cell B. The SS deactivates cell A and activates cell B. Cell B is preferred by the UE. No ROUTING AREA UPDATING REQUEST sent to SS, as access class X is barred (SS waits 30 seconds).
7		->	ATTACH COMPLETE	
8				
9		SS		
10		UE		
11		SS	ROUTING AREA UPDATING REQUEST	The following messages are sent and shall be received on cell C. The SS deactivates cell B and activates cell C. Cell C is preferred by the UE. Update type = 'Combined RA/LA updating' P-TMSI-2 signature Routing area identity = RAI-1 TMSI status = no valid TMSI available Update result = 'Combined RA/LA updated' Mobile identity = P-TMSI-1 P-TMSI-1 signature Mobile identity = IMSI Routing area identity = RAI-4
12		->		
13		<-	ROUTING AREA UPDATING ACCEPT	
14		->	ROUTING AREA UPDATING COMPLETE	
15		UE		
16		->	DETACH REQUEST	

## 12.4.2.6.5 Test requirements

UE shall:

- initiate a combined PS attach procedure with information elements specified in the above Expected Sequence when UE is powered up or switched on.

After completing the PS attach procedure, UE shall:

- not perform the combined routing area updating procedure.
- stay in the current serving cell.
- apply the normal cell reselection process.( as access class X is barred)
- perform the combined routing area updating procedure when the barred state is removed or because of a cell change.

## 12.4.2.7 Combined routing area updating / abnormal cases / attempt counter check / procedure timeout

### 12.4.2.7.1 Definition

### 12.4.2.7.2 Conformance requirement

- 1) When a T3330 timeout has occurred during a routing area updating procedure with the attempt counter less than five, the User Equipment shall repeat the routing area updating procedure after T3330 timeout.
- 2) When a T3330 timeout has occurred during a routing area updating procedure with the attempt counter five, the User Equipment shall start timer T3302.
- 3) When the T3302 expire, a new routing area updating procedure shall be initiated.

### Reference

3G TS 24.008 clause 4.7.5.2

### 12.4.2.7.3 Test purpose

To test the behaviour of the UE with respect to the attempt counter.

### 12.4.2.7.4 Method of test

#### Initial condition

#### System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC/LAC1/RAC2.

Both cells are operating in network operation mode I.

#### User Equipment:

The UE has a valid TMSI, P-TMSI, P-TMSI signature and RAI.

### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

### Test procedure

The UE initiates a routing area updating procedure (attempt counter zero). The SS does not answer with ROUTING AREA UPDATE ACCEPT message before T3330 timeout.

The UE initiates a new routing area updating procedure (attempt counter one) after T3311 expires. The SS does not answer with ROUTING AREA UPDATE ACCEPT message before T3330 timeout.

The UE initiates a new routing area updating procedure (attempt counter two) after T3311 expires. The SS does not answer with ROUTING AREA UPDATE ACCEPT message before T3330 timeout.

The UE initiates a new routing area updating procedure (attempt counter three) after T3311 expires. The SS does not answer with ROUTING AREA UPDATE ACCEPT message before T3330 timeout.

The UE initiates a new routing area updating procedure (attempt counter four) after T3311 expires. The SS does not answer with ROUTING AREA UPDATE ACCEPT message before T3330 timeout.

The UE initiates a new routing area updating procedure with attempt counter five (after T3311 expires). The SS does not answer with ATTACH ACCEPT message before T3330 timeout. The UE shall not perform a new successful routing area updating procedure after 15 seconds.

The UE initiates a routing area updating procedure with attempt counter zero after T3302 expires without P-TMSI, P-TMSI signature, PS CKSN and RAI.

T3302; set to 10 minutes

T3311; 15 seconds

T3330; 15 seconds



## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS	ATTACH REQUEST	The following messages are sent and shall be received on cell A. The SS activates cell A. The UE is powered up or switched on and initiates an attach (see ICS. Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI TMSI status = no valid TMSI available Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-1 Mobile identity = IMSI
2		SS		
3		UE		
4		->		
5		<-		
6			ATTACH ACCEPT	
7		->	ATTACH COMPLETE	
7		SS	ROUTING AREA UPDATING REQUEST	The following messages are sent and shall be received on cell B. The SS deactivates cell A and activates cell B. Cell B is preferred by the UE. Update type = 'Combined RA/LA updating' P-TMSI-2 signature Routing area identity = RAI-1 TMSI status = no valid TMSI available No response is given from the SS. The SS verifies that the time between the RA update requests is 15 seconds
8		UE		
9		->		
10		SS	ROUTING AREA UPDATING REQUEST	Update type = 'Combined RA/LA updating' P-TMSI-2 signature Routing area identity = RAI-1 TMSI status = no valid TMSI available No response is given from the SS. The SS verifies that the time between the RA update requests is 15 seconds
11		SS		
12		->		
13		SS	ROUTING AREA UPDATING REQUEST	Update type = 'Combined RA/LA updating' P-TMSI-2 signature Routing area identity = RAI-1 TMSI status = no valid TMSI available No response is given from the SS. The SS verifies that the time between the RA update requests is 15 seconds
14		SS		
15		->		
16		SS	ROUTING AREA UPDATING REQUEST	Update type = 'Combined RA/LA updating' P-TMSI-2 signature Routing area identity = RAI-1 TMSI status = no valid TMSI available No response is given from the SS. The SS verifies that the time between the RA update requests is 15 seconds
17		SS		
18		->		
19		SS	ROUTING AREA UPDATING REQUEST	Update type = 'Combined RA/LA updating' P-TMSI-2 signature Routing area identity = RAI-1 TMSI status = no valid TMSI available No response is given from the SS. The SS verifies that the time between the RA update requests is 15 seconds
20		SS		
21		->		
22		SS	ROUTING AREA UPDATING REQUEST	Update type = 'Combined RA/LA updating' P-TMSI-2 signature Routing area identity = RAI-1 TMSI status = no valid TMSI available No response is given from the SS. The SS verifies that the time between the RA update requests is T3302 seconds
23		SS		
24		->		
25		<-	ROUTING AREA UPDATING ACCEPT	Update type = 'Combined RA/LA updating' P-TMSI-2 signature Routing area identity = RAI-1 TMSI status = no valid TMSI available Update result = 'Combined RA/LA updated' Mobile identity = P-TMSI-1 P-TMSI-1 signature Mobile identity = IMSI Routing area identity = RAI-4

26	->	ROUTING AREA UPDATING COMPLETE	
27	UE		The UE is switched off or power is removed (see ICS).
28	->	DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, combined PS/IMSI detach'

#### 12.4.2.7.5 Test requirements

UE shall:

- initiate a combined PS attach procedure with information elements specified in the above Expected Sequence when UE is powered up or switched on.

After completing the PS attach procedure, UE shall:

- initiate a combined routing area updating procedure with information elements specified in the above Expected Sequence when UE is powered up or switched on.
- perform the following actions depending on the conditions described below.

Case 1) A timer T3330 timeout has occurred during a combined routing area updating procedure with the attempt counter less than five.

UE shall:

- repeat the combined routing area updating procedure after the timer T3330 timeout

Case2) A timer T3330 timeout has occurred during a combined routing area updating procedure with attempt counter five

UE shall:

- start the timer T3302

Case3) The timer T3302 expires

UE shall:

- initiate a new routing area updating procedure

#### 12.4.2.8 Combined routing area updating / abnormal cases / change of cell into new routing area

##### 12.4.2.8.1 Definition

##### 12.4.2.8.2 Conformance requirement

When a change of cell into a new routing area is performed before the routing area updating procedure is finished, the UE shall abort the routing area updating procedure and re-initiate it in the new routing area.

##### Reference

3G TS 24.008 clause 4.7.5.2

##### 12.4.2.8.3 Test purpose

To test the behaviour of the UE in case of procedure collision.

## 12.4.2.8.4 Method of test

## Initial condition

## System Simulator:

Three cells, cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2, cell C in MCC1/MNC1/LAC1/RAC3.

All three cells are operating in network operation mode I.

## User Equipment:

The UE has a valid IMSI.

## Related ICS/IXIT statements

Support of PS service	Yes/No	
UE operation mode A	Yes/No	
Switch off on button	Yes/No	
Automatic PS attach procedure at switch on or power on	Yes/No	

## Test procedure

The UE initiates a routing area updating procedure. The ROUTING AREA UPDATE ACCEPT message is delayed from the SS. The UE performs a cell update into a new routing area. The Ms shall re-initiate a routing area updating procedure in the new routing area. The UE shall not increment the attempt counter.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	SS		ATTACH REQUEST	The following messages are sent and shall be received on cell A. The SS activates cell A. The UE is powered up or switched on and initiates an attach (see ICS). Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI TMSI status = no valid TMSI available Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-1 Mobile identity = IMSI
2	SS			
3	UE			
4	->			
5	<-			
6			ROUTING AREA UPDATING REQUEST	The following messages are sent and shall be received on cell B. The SS deactivates cell A and activates cell B. Cell B is preferred by the UE. Update type = 'Combined RA/LA updating' P-TMSI-2 signature Routing area identity = RAI-1 TMSI status = no valid TMSI available No response id given from the SS.
7	SS			
8	UE			
9	->		ROUTING AREA UPDATING REQUEST	The following messages are sent and shall be received on cell A. Activate cell C with a lower signal strength than cell B. The RF level of cell B is lowered, and the RF level of cell C is increased, until cell C is preferred by the UE. Update type = 'Combined RA/LA updating' P-TMSI-2 signature Routing area identity = RAI-1 TMSI status = no valid TMSI available Update result = 'Combined RA/LA updated' Mobile identity = P-TMSI-1 P-TMSI-1 signature Mobile identity = IMSI Routing area identity = RAI-5
10	SS			
11	UE			
12	->			
13	<-			
14			ROUTING AREA UPDATING COMPLETE	The UE is switched off or power is removed (see ICS). Message not sent if power is removed. Detach type = 'power switched off, combined PS/IMSI detach'
15	UE			
16	->		DETACH REQUEST	

## 12.4.2.8.5 Test requirements

UE shall:

- initiate a combined PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

After completing the PS attach procedure, UE shall :

- initiate the routing area update procedure.

When change of cell into new routing area is performed before the routing area updating procedure is finished, UE shall:

- abort the routing area updating procedure.
- re-initiate new routing area updating procedure in the new routing area.

#### 12.4.2.9 Combined routing area updating / abnormal cases / change of cell during routing area updating procedure

##### 12.4.2.9.1 Definition

##### 12.4.2.9.2 Conformance requirement

When a change of cell within new routing area is performed before the routing area updating procedure is finished, the UE shall perform the cell update before the routing area updating procedure is finished.

##### Reference

3G TS 24.008 clause 4.7.5.2

##### 12.4.2.9.3 Test purpose

To test the behaviour of the UE in case of procedure collision.

##### 12.4.2.9.4 Method of test

##### Initial condition

##### System Simulator:

Three cells, cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2, cell C in MCC1/MNC1/LAC1/RAC2.

All three cells are operating in network operation mode I.

##### User Equipment:

The UE has a valid P-TMSI, P-TMSI signature and RAI.

##### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

##### Test procedure

The UE initiates a routing area updating procedure. The ROUTING AREA UPDATE ACCEPT message is delayed from the SS. The UE performs a cell update within the routing area. The UE then waits for the ROUTING AREA UPDATE ACCEPT message.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS	ATTACH REQUEST	The following messages are sent and shall be received on cell A. The SS activates cell A. The UE is powered up or switched on and initiates an attach (see ICS). Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI TMSI status = no valid TMSI available Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-1 Mobile identity = IMSI
2		SS		
3		UE		
4		->		
5		<-		
6			ROUTING AREA UPDATING REQUEST	The following messages are sent and shall be received on cell B. The SS deactivates cell A and activates cell B. Cell B is preferred by the UE. Update type = 'Combined RA/LA updating' P-TMSI-2 signature Routing area identity = RAI-1 TMSI status = no valid TMSI available No response id given from the SS.
7		SS		
8		UE		
9		->	UPLINK RLC DATA BLOCK ROUTING AREA UPDATING ACCEPT	The following messages are sent and shall be received on cell C. Activate cell C with a lower signal strength than cell B. The RF level of cell B is lowered until cell C is preferred by the UE. LLC PDU implicitly indicating cell update. Update result = 'Combined RA/LA updated' Mobile identity = P-TMSI-1 P-TMSI-1 signature Mobile identity = IMSI Routing area identity = RAI-4
10		SS		
11		UE		
12		->		
13		<-		
14			ROUTING AREA UPDATING COMPLETE	The UE is switched off or power is removed (see ICS). Message not sent if power is removed. Detach type = 'power switched off, combined PS/IMSI detach'
15		->		
16		UE	DETACH REQUEST	

## 12.4.2.9.5 Test requirements

UE shall:

- initiate a combined PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

After completing the PS attach procedure, UE shall:

- initiate routing area update procedure.

When a change of cell within a new routing area is performed before the routing area updating procedure is finished, UE shall:

- perform the cell update.

## 12.4.2.10 Combined routing area updating / abnormal cases / PS detach procedure collision

### 12.4.2.10.1 Definition

### 12.4.2.10.2 Conformance requirement

- 1) When a detach request is received with cause 'PS detach' or 'combined PS/IMSI detach' by the UE while waiting for a ROUTING AREA UPDATE ACCEPT message, the UE shall terminate the routing area updating procedure and continue with the PS detach procedure.
- 2) When a detach request is received with cause 'IMSI detach' by the UE while waiting for a ROUTING AREA UPDATE ACCEPT message, the UE shall ignore the detach request and continue with the routing area updating procedure.

### Reference

3G TS 24.008 clause 4.7.5.2

### 12.4.2.10.3 Test purpose

To test the behaviour of the UE in case of procedure collision.

### 12.4.2.10.4 Method of test

#### 12.4.2.10.4.1 Test procedure<sup>1</sup>

### Initial condition

#### System Simulator:

Two cells, cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2.  
Both cells are operating in network operation mode I.

#### User Equipment:

The UE has a valid IMSI.

### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

### Test procedure

The UE initiates a routing area updating procedure. The SS does not answer the routing area updating procedure, but initiates a PS detach procedure with cause 'PS detach' or 'combined PS/IMSI detach'. The UE shall terminate the routing area updating procedure and continue with the PS detach procedure.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS	ATTACH REQUEST	The following messages are sent and shall be received on cell A. The SS activates cell A. The UE is powered up or switched on and initiates an attach (see ICS. Attach type = 'Combined PS / IMSI attach' Mobile identity = IMSI TMSI status = no valid TMSI available Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-1 Mobile identity = IMSI
2		SS		
3		UE		
4		->		
5		<-		
6			ROUTING AREA UPDATING REQUEST	The following messages are sent and shall be received on cell B. The SS deactivates cell A and activates cell B. Cell B is preferred by the UE. Update type = 'Combined RA/LA updating' P-TMSI-2 signature Routing area identity = RAI-1 TMSI status = no valid TMSI available The SS ignores the ROUTING AREA UPDATING REQUEST message and initiates a detach procedure. Detach type = 're-attach not required'
7		SS		
8		UE		
9		->		
10		<-		
11			DETACH REQUEST	
		->	DETACH ACCEPT	

## 12.4.2.10.4.2 Test procedure2

## Initial condition

## System Simulator:

Two cells, cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2.  
Both cells are operating in network operation mode I.

## User Equipment:

The UE has a valid P-TMSI, P-TMSI signature and RAI.

## Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

## Test procedure

The UE initiates a routing area updating procedure. The SS does not answer the routing area updating procedure, but initiates a PS detach procedure with cause 'IMSI detach'. The UE shall ignore the detach procedure and continue with the routing area updating procedure.



## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	SS		ATTACH REQUEST	The following messages are sent and shall be received on cell A. The SS activates cell A. The UE is powered up or switched on and initiates an attach (see ICS. Attach type = 'Combined PS / IMSI attach' Mobile identity =IMSI TMSI status = no valid TMSI available Attach result = 'Combined PS / IMSI attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-1 Mobile identity = IMSI
2	SS			
3	UE			
4	->			
5	<-			
6	->		ATTACH COMPLETE	
6	SS		ROUTING AREA UPDATING REQUEST	The following messages are sent and shall be received on cell B. The SS deactivates cell A and activates cell B. Cell B is preferred by the UE. Update type = 'Combined RA/LA updating' P-TMSI-2 signature Routing area identity = RAI-1 TMSI status = no valid TMSI available The SS ignores the ROUTING AREA UPDATING REQUEST message and initiates a detach procedure.
7	UE			
8	->			
9	SS			
10	<-			
11	UE		DETACH REQUEST	Detach type = 'IMSI detach' The UE ignores the DETACH REQUEST message and continue the routing area updating procedure.
12	<-		ROUTING AREA UPDATING ACCEPT	Update result = 'Combined RA/LA updated' Mobile identity = P-TMSI-1 P-TMSI-1 signature Mobile identity = IMSI Routing area identity = RAI-4
13	->		ROUTING AREA UPDATING COMPLETE	
14	UE			The UE is switched off or power is removed (see ICS).
15	->		DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, combined PS/IMSI detach'

## 12.4.2.10.5 Test requirements

UE shall:

- initiate a combined PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

After completing the PS attach procedure, UE shall :

- initiate routing area update procedure.
- perform the follow actions depending on the conditions described below.

Case 1) UE receives a DETACH REQUEST message with cause 'PS detach' or 'combined PS/IMSI detach' from SS while waiting for a ROUTING AREA UPDATE ACCEPT message, UE shall:

- terminate the routing area updating procedure
- continue with the PS detach procedure.

Case 2) UE receives a DETACH REQUEST message with cause 'IMSI detach' from SS while waiting for a ROUTING AREA UPDATING ACCEPT message, UE shall:

- ignore the detach request.
- continue with the routing area updating procedure.

### 12.4.3 Periodic routing area updating

#### 12.4.3.1 Periodic routing area updating / accepted

##### 12.4.3.1.1 Definition

##### 12.4.3.1.2 Conformance requirement

The User Equipment shall perform a periodic routing area update procedure after a T3312 timeout.

##### Reference

3G TS 24.008 clause 4.7.2.2 and 4.7.5.1

##### 12.4.3.1.3 Test purpose

To test the behaviour of the UE with respect to the periodic routing area updating procedure.

##### 12.4.3.1.4 Method of test

##### Initial condition

##### System Simulator:

One cell operating in network operation mode II (in case of UE operation mode A), or in network operation mode III (in case of UE operation mode C).

##### User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

##### Related ICS/IXIT statements

Support of PS service	Yes/No	
UE operation mode C	Yes/No	
UE operation mode A	Yes/No	
USIM removal possible without powering down	Yes/No	
Switch off on button	Yes/No	
Automatic PS attach procedure at switch on or power on	Yes/No	

##### Test procedure

The UE initiates a PS attach procedure with identity P-TMSI. The SS reallocates the P-TMSI and returns ATTACH ACCEPT message with a new P-TMSI and timer T3312. The UE acknowledges the new P-TMSI by sending ATTACH COMPLETE message. A routing area updating procedure is performed at T3312 timeout.

T3312; set to 6 minutes.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 11.
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->		ATTACH REQUEST	Attach type = 'PS attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature
4	<-		ATTACH ACCEPT	Routing area identity = RAI-1 Attach result = 'PS only attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-1 T3312 = 6 minutes
5	->		ATTACH COMPLETE	
6	->		ROUTING AREA UPDATING REQUEST	Update type = 'Periodic updating' P-TMSI-2 signature Routing area identity = RAI-1
7		SS		The SS verifies that the time between the attach and the periodic RA updating is T3312
8	<-		ROUTING AREA UPDATING ACCEPT	No new mobile identity assigned. P-TMSI not included. Update result = 'RA updated' P-TMSI-3 signature Routing area identity = RAI-1
9	UE			The UE is switched off or power is removed (see ICS).
10	->		DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, PS detach'
11				The SS is set in network operation mode II.
12	UE			The UE is set in UE operation mode A (see ICS) and the test is repeated from step 3 to step 10.

## 12.4.3.1.5 Test requirements

UE shall:

- initiate a PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.
- set and start the timer T3312 when the ATTACH ACCEPT message and ROUTING AREA UPDATING ACCEPT message from SS. The value of the timer T3312 is sent by SS to UE in ATTACH ACCEPT message and ROUTING AREA UPDATING ACCEPT message.
- initiate a routing area updating procedure with Update type = 'Periodic updating' when the timer T3312 is expired.

## 12.4.3.2 Periodic routing area updating / accepted / T3312 default value

## 12.4.3.2.1 Definition

## 12.4.3.2.2 Conformance requirement

The User Equipment shall perform a periodic routing area update procedure after a T3312 timeout.

## Reference

3G TS 24.008 clause 4.7.2.2 and 4.7.5.2

## 12.4.3.2.3 Test purpose

To test the behaviour of the UE with respect to the periodic routing area updating procedure.

## 12.4.3.2.4 Method of test

## Initial condition

## System Simulator:

One cell operating in network operation mode I.

## User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

## Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

## Test procedure

The UE initiates a combined PS attach procedure. The SS reallocates the P-TMSI and returns ATTACH ACCEPT message with a new P-TMSI and timer T3312 is omitted. The UE acknowledge the new P-TMSI by sending ATTACH COMPLETE message. After 54 minutes, a periodic routing area updating procedure is initiated by the UE.

T3312; default value 54 minutes.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The UE is powered up or switched on and initiates an attach (see ICS).
2	->		ATTACH REQUEST	Attach type = 'Combined PS / IMSI attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1
3	<-		ATTACH ACCEPT	TMSI status = no valid TMSI available Attach result = 'Combined PS /IMSI attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature Mobile identity = TMSI-1 Routing area identity = RAI-1
4	->		ATTACH COMPLETE	
5	->		ROUTING AREA UPDATING REQUEST	Update type = 'Periodic updating' P-TMSI-2 signature Routing area identity = RAI-1
6		SS		TMSI status = valid TMSI available The SS verifies that the time between the attach request and the periodic RA updating is T3312
7	<-		ROUTING AREA UPDATING ACCEPT	No new mobile identity assigned. P-TMSI and TMSI not included. Update result = 'RAupdated' P-TMSI-3 signature Routing area identity = RAI-1
8	UE			The UE is switched off or power is removed (see ICS).
9	->		DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, combined PS/IMSI detach'

## 12.4.3.2.5 Test requirements

UE shall:

- initiate a PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.
- set and start the timer T3312 when the ATTACH ACCEPT message and ROUTING AREA UPDATING ACCEPT message from SS.
- initiate a routing area updating procedure with Update type = 'Periodic updating' when the timer T3312 is expired.

## 12.4.3.3 Periodic routing area updating / no cell available / network mode I

## 12.4.3.3.1 Definition

## 12.4.3.3.2 Conformance requirement

If the UE is both IMSI attached for PS and non-PS services, and if the UE lost coverage of the registered PLMN and timer T3312 expires; if the UE returns to coverage in a cell that supports PS and the network is in network operation mode I, then the UE shall perform a combined routing area update procedure.

## Reference

3G TS 24.008 clause 4.7.2.2 and 4.7.5.1.

## 12.4.3.3.3 Test purpose

To test the behaviour of the UE with respect to the periodic routing area updating procedure.

## 12.4.3.3.4 Method of test

## Initial condition

## System Simulator:

Two cells, cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2.

Cell A is in are operating in network operation mode II and cell B is in network operation mode I. operating in network operation mode II.

## User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

## Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

## Test procedure

The UE initiates a PS attach procedure and an IMSI attach procedure. The SS reallocates the P-TMSI and returns ATTACH ACCEPT message with a new P-TMSI and timer T3312. The UE acknowledge the new P-TMSI by sending ATTACH COMPLETE message. PS radio contact is distorted before T3312 timeout. PS radio contact is established again (after T3312 timeout), and a routing area updating procedure is performed immediately.

T3312; set to 6 minutes.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		The following messages are sent and shall be received on cell A.
2		SS		The SS activates cell A.
3		SS		The UE is set in UE operation mode A (see ICS).
4		UE	ATTACH REQUEST	The UE is powered up or switched on and initiates an attach (see ICS).
5	->			Attach type = 'PS attach'
				Mobile identity = P-TMSI-1
				P-TMSI-1 signature
				Routing area identity = RAI-1
6	<-		ATTACH ACCEPT	Attach result = 'PS only attached'
				Mobile identity = P-TMSI-2
				P-TMSI-2 signature
				Routing area identity = RAI-1
				T3312 = 6 minutes
7	->		ATTACH COMPLETE	
8	->		CHANNEL REQUEST	
9	<-		IMMEDIATE ASSIGNMENT	
10	->		LOCATION UPDATING REQ	Location updating type = IMSI attach.
11	<-		LOCATION UPDATING ACC	The SS allocates a new TMSI.
12	->		TMSI REALLOCATION COMP	Location updating type = IMSI attach.
	<-		CHANNEL RELEASE	After sending of this message, the SS waits for disconnection of the CS signalling link.
13		SS		After 5 minutes, the signal strength is lowered until the UE have lost contact with the SS.
14		SS		Wait 2 minutes.
15		SS		The following messages are sent and shall be received on cell B.
16		UE		The SS deactivates cell A and activates cell B.
17		UE		Cell B is preferred by the UE.
18	->		ROUTING AREA UPDATING REQUEST	The UE immediately start a combined RA updating procedure
				Update type = 'Combined RA/LA updating'
				P-TMSI-2 signature
				Routing area identity = RAI-1
				TMSI status = valid TMSI available
19	<-		ROUTING AREA UPDATING ACCEPT	Update result = 'Combined RA/LA updated'
				Mobile identity = P-TMSI-3
				P-TMSI-3 signature
				Mobile identity = TMSI-2
				Routing area identity = RAI-4
20		UE		The UE is switched off or power is removed (see ICS).
21	->		DETACH REQUEST	Message not sent if power is removed.
				Detach type = 'power switched off, combined PS / IMSI detach'

## 12.4.3.3.5 Test requirements

UE shall:

- initiate a PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

When the UE is both IMSI attached for PS and non-PS service, and if the MS lost coverage of the reiterated PLMN and the timer T3312 expires, if the UE returns to coverage in a cell that supports PS and the network is in network operation mode I, UE shall:

- perform the combined routing area update procedure indicating "combined RA/LA updating with IMSI attach".

#### 12.4.3.4 Combined periodic routing area updating / no cell available

##### 12.4.3.4.1 Definition

##### 12.4.3.4.2 Conformance requirement

If the UE is both IMSI attached for PS and non-PS services, and if the UE lost coverage of the registered PLMN and timer T3312 expires; if the UE returns to coverage in a cell that supports PS and the network is in network operation mode II, then the UE shall perform a periodic routing area update procedure and a periodic location update procedure.

##### Reference

3G TS 24.008 clause 4.7.2.2 and 4.7.5.2

##### 12.4.3.4.3 Test purpose

To test the behaviour of the UE with respect to the periodic routing area updating procedure.

##### 12.4.3.4.4 Method of test

##### Initial condition

##### System Simulator:

One cell operating in network operation mode II.

##### User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

##### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

##### Test procedure

The UE initiates a PS attach procedure and an IMSI attach procedure. The SS reallocates the P-TMSI and returns ATTACH ACCEPT message with a new P-TMSI and timer T3312. The UE acknowledges the new P-TMSI by sending ATTACH COMPLETE message. PS radio contact is distorted before T3312 timeout. PS radio contact is established again (after T3312 timeout), and a periodic routing area updating procedure and a periodic location update procedure is performed immediately.

T3312; set to 6 minutes.



## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The UE is powered up or switched on and initiates an attach (see ICS).
2	->		ATTACH REQUEST	Attach type = 'PS attach' Mobile identity = P-TMSI-1 P-TMSI-1 signature
3	<-		ATTACH ACCEPT	Routing area identity = RAI-1 Attach result = 'PS only attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-1 T3312 = 6 minutes
4	->		ATTACH COMPLETE	
5	->		CHANNEL REQUEST	
6	<-		IMMEDIATE ASSIGNMENT	
7	->		LOCATION UPDATING REQ	Location updating type = IMSI attach.
8	<-		LOCATION UPDATING ACC	The SS allocates a new TMSI.
9	->		TMSI REALLOCATION COMP	Location updating type = IMSI attach.
10	<-		CHANNEL RELEASE	After sending of this message, the SS waits for disconnection of the CS signalling link.
11	SS			After 5 minutes, the signal strength is lowered until the UE have lost contact with the SS.
12	SS			After 2 minutes, the signal strength is increased until the UE have got contact with the SS.
13	UE			The UE immediately start the periodic RA updating procedure
14	->		ROUTING AREA UPDATING REQUEST	Update type = 'Periodic updating' P-TMSI-2 signature Routing area identity = RAI-1
15	<-		ROUTING AREA UPDATING ACCEPT	No new mobile identity assigned. P-TMSI not included. Update result = 'RAupdated' P-TMSI-3 signature Routing area identity = RAI-1
16	->		CHANNEL REQUEST	
17	<-		IMMEDIATE ASSIGNMENT	
18	->		LOCATION UPDATING REQ	Location updating type = Periodic LA updating.
19	<-		LOCATION UPDATING ACC	
20	<-		CHANNEL RELEASE	After sending of this message, the SS waits for disconnection of the CS signalling link.
21	UE			The UE is switched off or power is removed (see ICS).
22	->		DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, PS detach'

## 12.4.3.4.5 Test requirements

UE shall:

- initiate a combined PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

When the UE is both IMSI attached for PS and non-PS service, and if the MS lost coverage of the reiterated PLMN and the timer T3312 expires, if the UE returns to coverage in a cell in the same RA that supports PS and that indicates that the network is in network operation mode II, UE shall:

- perform the periodic routing area updating procedure indicating "Periodic updating".
- perform the periodic location updating procedure.

## 12.5 P-TMSI reallocation

### 12.5.1 Definition

### 12.5.2 Conformance requirement

- 1) A User Equipment shall acknowledge a new P-TMSI when explicitly allocated.
- 2) The P-TMSI shall be updated on the USIM when the User Equipment is correctly deactivated in accordance with the manufacturer's instructions.
- 3) A User Equipment shall use the given P-TMSI in further communication with the network.

### Reference

3G TS 24.008 clause 4.7.6

### 12.5.3 Test purpose

To verify that the UE is able to receive and acknowledge a new P-TMSI by means of an explicit P-TMSI reallocation procedure.

To verify that the UE has stored the P-TMSI in a non-volatile memory.

The implicit reallocation procedure is tested in the attach procedure.

### 12.5.4 Method of test

#### Initial condition

#### System Simulator:

One cell operating in network operation mode II.

#### User Equipment:

The UE has a valid IMSI.

### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
UE operation mode C	Yes/No (only if mode A not supported)
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

### Test procedure

An explicit P-TMSI reallocation procedure is performed (P-TMSI reallocation command sent from the SS and acknowledged from the UE by P-TMSI reallocation complete). The UE is PS detached and switched off. Its power supply is interrupted for 10 seconds. The power supply is resumed and then the UE is switched on. A PS attach procedure is performed with the given P-TMSI as identity.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			<p>The UE is set in UE operation mode A (see ICS). If UE operation mode A not supported set the UE in operation mode C.</p> <p>The UE is powered up or switched on and initiates an attach (see ICS).</p> <p>Attach type = 'PS attach'</p> <p>Mobile identity = IMSI</p> <p>Attach result = 'PS only attached'</p> <p>Mobile identity = P-TMSI-1</p> <p>P-TMSI-1 signature</p> <p>Routing area identity = RAI-1</p>
2	UE			
3	->		ATTACH REQUEST	
4	<-		ATTACH ACCEPT	
5	->		ATTACH COMPLETE	
6	<-		P-TMSI REALLOCATION COMMAND	
7	->		P-TMSI REALLOCATION COMPLETE	
8	UE			
9	->		DETACH REQUEST	
10	UE			<p>The UE is powered up or switched on and initiates an attach (see ICS).</p> <p>Attach type = 'PS attach'</p> <p>Mobile identity = P-TMSI-2</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p> <p>No new mobile identity assigned.</p> <p>P-TMSI not included.</p> <p>Attach result = 'PS only attached'</p> <p>P-TMSI-3 signature</p> <p>Routing area identity = RAI-1</p> <p>Mobile identity = P-TMSI-2</p> <p>Paging order is for TBF establishment.</p> <p>LLC PDU implicitly indicating paging response.</p>
11	->		ATTACH REQUEST	
12	<-		ATTACH ACCEPT	
13	<-		PAGING REQUEST TYPE 1	
14	->		UPLINK RLC DATA BLOCK	
15	UE			
16	->		DETACH REQUEST	

## 12.5.5 Test requirements

UE shall:

- initiate a PS attach procedure with the information elements specified in the above Expected Sequence when UE is powered up or switched on.

After completing the PS attach procedure, and when UE receive of the P-TMSI REALLOCATION COMMAND message, UE shall:

- store the allocated Routing Area Identifier(RAI) and the allocated P-TMSI.
- acknowledge a new P-TMSI.
- send the P-TMSI and a P-TMSI REALLOCATION COMPLETE message to SS.
- update P-TMSI on the USIM when UE is correctly deactivated in accordance with the manufacturer's instructions.
- use the given P-TMSI in further communication with SS.

## 12.6 PS authentication and ciphering

### 12.6.1 Test of authentication

The purpose of this procedure is to verify the user identity. A correct response is essential to guarantee the establishment of the connection. If not, the connection will drop.

#### 12.6.1.1 Authentication accepted

##### 12.6.1.1.1 Definition

##### 12.6.1.1.2 Conformance requirement

A User Equipment shall correctly respond in an authentication and ciphering procedure by sending a response with the RES information field set to the same value as the one produced by the authentication and ciphering algorithm in the network.

#### Reference

3G TS 24.008 clause 4.7.7

##### 12.6.1.1.3 Test purpose

To test the behaviour of the UE if the network accepts the authentication and ciphering procedure.

##### 12.6.1.1.4 Method of test

#### Initial condition

#### System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2.  
Both cells are operating in network operation mode II.

#### User Equipment:

The UE has a valid IMSI.

#### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
UE operation mode C	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

#### Test procedure

A PS attach is performed, and the SS initiates an authentication and ciphering procedure.

The SS checks the value RES sent by the UE in the AUTHENTICATION AND CIPHERING RESPONSE message.

The UE initiates a routing area updating procedure and the SS checks the value of the PS Ciphering Key Sequence Number sent by the UE in the ROUTING AREA REQUEST message.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		<p>The following messages are sent and shall be received on cell A.</p> <p>The SS activates cell A.</p> <p>The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 17.</p> <p>The UE is powered up or switched on and initiates an attach (see ICS).</p> <p>Attach type = 'PS attach'</p> <p>Mobile identity = IMSI</p> <p>Request authentication.</p> <p>Set PS-CKSN-1</p> <p>RES</p> <p>The SS checks the RES value.</p> <p>Attach result = 'PS only attached'</p> <p>Mobile identity = P-TMSI-2</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p>
2		UE		
3		UE		
4	->		ATTACH REQUEST	
5	<-		AUTHENTICATION AND CIPHERING REQUEST	
6	->		AUTHENTICATION AND CIPHERING RESPONSE	
7		SS		
8	<-		ATTACH ACCEPT	
9	->		ATTACH COMPLETE	
10		SS		<p>The following messages are sent and shall be received on cell B.</p> <p>Activate cell B with a lower signal strength than cell A. The RF level of cell A is lowered until cell B is preferred by the UE.</p> <p>Update type = 'RA updating'</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p> <p>PS-CKSN-1</p> <p>The value of PS-CKSN is checked</p> <p>Update result = 'RA updated'</p> <p>Mobile identity = P-TMSI-1</p> <p>P-TMSI-1 signature</p> <p>Routing area identity = RAI-2</p> <p>The UE is switched off or power is removed (see ICS).</p> <p>Message not sent if power is removed.</p> <p>Detach type = 'power switched off, PS detach'</p>
11	->		ROUTING AREA UPDATING REQUEST	
12		SS		
13	<-		ROUTING AREA UPDATING ACCEPT	
14	->		ROUTING AREA UPDATING COMPLETE	
15		UE		
16	->		DETACH REQUEST	
17		UE		The UE is set in UE operation mode A (see ICS) and the test is repeated from step 1 to step 16.

## 12.6.1.1.5 Test requirements

UE shall:

- initiate a PS attach procedure with information elements specified in the above Expected Sequence when UE is powered on or switched on.

When the UE receives the AUTHENTICATION AND CIPHERING REQUEST message from SS, UE shall:

- send the AUTHENTICATION AND CIPHERING RESPONSE message with the RES information field set to the same value as the one produced by the authentication and ciphering algorithm in the network.

## 12.6.1.2 Authentication rejected by the network

### 12.6.1.2.1 Definition

### 12.6.1.2.2 Conformance requirement

- 1) After reception of an Authentication Reject message the UE shall:
  - 1.1 not perform normal routing area updating
  - 1.2 not perform periodic routing area updating
  - 1.3 not perform PS detach if switched off
- 2) The UE shall delete the stored RAI, PS-CKSN P-TMSI and P-TMSI signature. USIM shall be considered invalid until power is switched off or USIM is removed.

### Reference

3G TS 24.008 clauses 4.7.7

### 12.6.1.2.3 Test purpose

To test the behaviour of the UE if the network rejects the authentication and ciphering procedure.

### 12.6.1.2.4 Method of test

#### Initial condition

#### System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2.  
Both cells are operating in network operation mode II.

#### User Equipment:

The UE has a valid IMSI.

### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
UE operation mode C	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

### Test procedure

A PS attach is performed, and the SS rejects the authentication and ciphering procedure.

The SS checks that the UE does not perform normal routing area updating, does not perform periodic routing area updating and does not perform PS detach if switched off.

T3312; set to 10 minutes.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS	ATTACH REQUEST	<p>The following messages are sent and shall be received on cell A.</p> <p>The SS activates cell A.</p> <p>The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 14.</p> <p>The UE is powered up or switched on and initiates an attach (see ICS).</p> <p>Attach type = 'PS attach'</p> <p>Mobile identity = IMSI</p>
2	UE			
3	UE			
4	->			
5	<-			
6	->			
7	<-			
8	<-			
9	UE			
10		SS		<p>The following messages are sent and shall be received on cell B.</p> <p>Activate cell B with a lower signal strength than cell A. The RF level of cell A is lowered until cell B is preferred by the UE.</p> <p>No ROUTING AREA UPDATING REQUEST sent to the SS</p> <p>(SS waits 30 seconds).</p> <p>No periodic ROUTING AREA UPDATING REQUEST sent to the SS</p> <p>(SS waits T3310).</p> <p>The UE is switched off (see ICS).</p> <p>No DETACH REQUEST sent to the SS</p> <p>(SS waits 30 seconds).</p>
11	UE			
12	UE			
13	UE			
14	SS			
15	UE			<p>The UE is set in UE operation mode A (see ICS) and the test is repeated from step 1 to step 13.</p>

## 12.6.1.2.5 Test requirements

UE shall:

- initiate a PS attach procedure with information elements specified in the above Expected Sequence when UE is powered on or switched on.

After UE receives the AUTHENTICATION AND CIPHERING REJECT message, UE shall:

- not perform normal routing area updating when the RF level of the attached cell is lower than the RF level of the new cell.
- not perform a periodic routing area updating when the timer T3312 expires.
- not perform PS detach when UE is switched off.
- delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.
- consider the USIM as invalid until power is switched off or USIM is removed.

### 12.6.1.3 Authentication rejected by the UE

#### 12.6.1.3.1 GMM cause 'MAC failure'

##### 12.6.1.3.1.1 Definition

##### 12.6.1.3.1.2 Conformance requirement

If the UE considers the MAC code (supplied by the core network in the AUTN parameter) to be invalid, the UE shall send AUTHENTICATION AND CIPHERING FAILURE message with the reject cause 'MAC failure' to the System Simulator.

#### Reference

3G TS 24.008 clause 4.7.7

##### 12.6.1.3.1.3 Test purpose

To test the behaviors of the UE, when the UE considers the MAC code (supplied by the core network in the AUTN parameter) to be invalid.

##### 12.6.1.3.1.4 Method of test

#### Initial condition

##### System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2.  
Both cells are operating in network operation mode II.

The MAC (Message Authentication Code) code, which is included in AUTHENTICATION AND CIPHERING REQUEST, is invalid value.

##### User Equipment:

The UE has a valid IMSI.

#### Related ICS/IXIT statements

Support of PS service	Yes/No	
UE operation mode A	Yes/No	
UE operation mode C	Yes/No	
Switch off on button	Yes/No	
Automatic PS attach procedure at switch on or power on	Yes/No	Yes/No

#### Test procedure

A PS attach is performed, and the SS initiates an authentication and ciphering procedure.

The UE sends AUTHENTICATION AND CIPHERING FAILURE message with reject cause 'MAC failure' to the SS and starts timer T3214.

The SS initiates an identification procedure, upon receipt of a failure message with reject cause 'MAC failure'.

After the identification procedure is complete, the SS re-initiates an authentication and ciphering procedure.

T3360; set to 6 seconds.

T3318; set to 5 seconds.



T3319; set to 15 seconds.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		The following messages are sent and shall be received on cell A. The SS activates cell A. The UE is set in UE operation mode C (see ICS). If UE operation mode C is not supported, goto step 25.
2		UE		
3		UE		The following messages are sent and shall be received on cell A. The UE is powered up or switched on and initiates an attach (see ICS). Attach type = 'PS attach' Mobility identity = IMSI Request authentication. Invalid Message Authentication Code (MAC). The SS starts the timer T3360 GMM cause='MAC failure'  Identity type = IMSI Mobile identity = IMSI The SS checks that the P-TMSI originally used in the authentication challenge corresponded to the correct IMSI. Request authentication.  RES  The SS checks the RES value. Attach result = 'PS only attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-1
4				
5		UE		
6	->		ATTACH REQUEST	
7	<-		AUTHENTICATION AND CIPHERING REQUEST	
8		SS		
9	->		AUTHENTICATION AND CIPHERING FAILURE	
10	<-		IDENTITY REQUEST	
11	->		IDENTITY RESPONSE	
12		SS		
13	<-		AUTHENTICATION AND CIPHERING REQUEST	
14	->		AUTHENTICATION AND CIPHERING RESPONSE	
15		SS		
16	<-		ATTACH ACCEPT	
17	->		ATTACH COMPLETE	
18		SS		The following messages are sent and shall be received on cell B. Activate cell B with a lower signal strength than cell A. RF level of cell A is lowered until cell B is preferred by the UE. Update type = 'RA updating' P-TMSI-2 signature Routing area identity = RAI-1 PS-CKSN-1 The value of PS-CKSN is checked Update result = 'RA updated' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-2
19	->		ROUTING AREA UPDATING REQUEST	
20		SS		
21	<-		ROUTING AREA UPDATING ACCEPT	
22	->		ROUTING AREA UPDATING COMPLETE	
23		UE		
24	->		DETACH REQUEST	
25		UE		
				The UE is set in UE operation mode A (see ICS) and the test is repeated from step 1 to step 24.

#### 12.6.1.3.1.5 Test requirements

UE shall:

- initiate a PS attach procedure with information element specified in the above Expected Sequence when UE is powered on or switched on.
- send an AUTHENTICATION AND CIPHERING FAILURE message with GMM cause 'MAC failure' to the SS
- start timer T3318.

After UE receives the IDENTITY REQUEST message from SS, UE shall:

- stop timer T3318, if running.
- send the IDENTITY RESPONSE message to SS
- start the timer T3319.

After UE receives the second AUTHENTICATION AND CIPHERING REQUEST message (containing a valid MAC) from SS, UE shall:

- send the AUTHENTICATION AND CIPHERING RESPONSE message to SS
- resume any retransmission timers (i.e. T3310, T3321, T3330 or T3317), if they are not already running.

#### 12.6.1.3.2 GMM cause 'Synch failure'

##### 12.6.1.3.2.1 Definition

##### 12.6.1.3.2.2 Conformance requirement

If the UE considers the SQN (supplied by the core network in the AUTN parameter) to be out of range, the UE shall send AUTHENTICATION AND CIPHERING FAILURE message with the reject cause 'Synch failure' to the System Simulator.

##### Reference

3G TS 24.008 clause 4.7.7

##### 12.6.1.3.2.3 Test purpose

To test the behaviors of the UE, when the UE considers the SQN (supplied by the core network in the AUTN parameter) to be out of range.

##### 12.6.1.3.2.4 Method of test

##### Initial condition

##### System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2.  
Both cells are operating in network operation mode II.

##### User Equipment:

The UE has a valid IMSI.

## Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
UE operation mode C	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

## Test procedure

A PS attach is performed, and the SS initiates an authentication and ciphering procedure.

UE sends AUTHENTICATION AND CIPHERING FAILURE message with reject cause 'synch failure' to the SS and starts timer T3214.

SS re-initiates an authentication and ciphering procedure.

T3360; set to 6 seconds.

T3320; set to 15 seconds.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		The following messages are sent and shall be received on cell A.
2		UE		The SS activates cell A. The UE is set in UE operation mode C (see ICS). If UE operation mode C is not supported, goto step 21.
3		UE		The following messages are sent and shall be received on cell A. The UE is powered up or switched on and initiates an attach (see ICS).
4	->		ATTACH REQUEST	Attach type = 'PS attach' Mobility identity = IMSI
5	<-		AUTHENTICATION AND CIPHERING REQUEST	Request authentication. SQN is out of range.
6		SS		The SS starts the timer T3360
7	->		AUTHENTICATION AND CIPHERING FAILURE	GMM cause = 'Synch failure' AUTS parameter
8		SS		set new authentication vectors. (re-synchronisation)
9	<-		AUTHENTICATION AND CIPHERING REQUEST	Request authentication.
10	->		AUTHENTICATION AND CIPHERING RESPONSE	RES
11		SS		The SS checks the RES value.
12	<-		ATTACH ACCEPT	Attach result = 'PS only attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature
13	->		ATTACH COMPLETE	Routing area identity = RAI-1
14		SS		The following messages are sent and shall be received on cell B. Activate cell B with lower signal strength than cell A. RF level of cell A is lowered until cell B is preferred by the UE.
15	->		ROUTING AREA UPDATING REQUEST	Update type = 'RA updating' P-TMSI-2 signature Routing area identity = RAI-1 PS-CKSN-1
16		SS		The value of PS-CKSN is checked
17	<-		ROUTING AREA UPDATING ACCEPT	Update result = 'RA updated' Mobile identity = P-TMSI-1 P-TMSI-1 signature
18	->		ROUTING AREA UPDATING COMPLETE	Routing area identity = RAI-2
19		UE		The UE is switched off or power is removed (see ICS).
20	->		DETACH REQUEST	Message is not sent if power is removed. Detach type = 'power switched off, PS detach'
21		UE		The UE is set in UE operation mode A (see ICS) and the test is repeated from step 1 to step 20.

## 12.6.1.3.2.5

## Test requirements

UE shall:

- initiate a PS attach procedure with information element specified in the above Expected Sequence when UE is powered on or switched on.
- send AUTHENTICATION AND CIPHERING FAILURE message with GMM cause 'synch failure' to the SS
- start timer T3320.

After UE receives the second AUTHENTICATION AND CIPHERING REQUEST message from SS, UE shall:

- stop timer T3320, if running.
- send AUTHENTICATION AND CIPHERING RESPONSE message to SS.

## 12.6.2 Test of ciphering mode setting

The purpose of this procedure is to let the network to trigger the start and stop of stream ciphering.

The SS shall start and synchronise ciphering and deciphering according to GSM 03.20. The bitstream shall be generated by algorithm GEA/1.

### 12.6.2.1 Ciphering mode / start ciphering

#### 12.6.2.1.1 Definition

#### 12.6.2.1.2 Conformance requirement

- 1) When the UE receives the AUTHENTICATION AND CIPHERING REQUEST message during the attach procedure, with Ciphering indicator information element set to 'ciphering mode off', the User Equipment shall:
  - 1.1 responds with an AUTHENTICATION AND CIPHERING RESPONSE message
  - 1.2 not start ciphering
- 2) When the UE receives the AUTHENTICATION AND CIPHERING REQUEST message during the routing area updating procedure, with Ciphering indicator information element set to 'ciphering mode on', the User Equipment shall:
  - 2.1 responds with an AUTHENTICATION AND CIPHERING RESPONSE message
  - 2.2 start ciphering and deciphering with the algorithm indicated by the Ciphering algorithm information element
  - 2.3 the ciphering uses the cipher key determined during the authentication procedure

#### Reference

3G TS 24.008 clause 4.7.7

#### 12.6.2.1.3 Test purpose

To test the behaviour of the UE if the network accepts the authentication and ciphering procedure with ciphering.

#### 12.6.2.1.4 Method of test

#### Initial condition

System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2.

Both cells are operating in network operation mode II.

User Equipment:

The UE has a valid IMSI.

Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
UE operation mode C	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

Test procedure

A PS attach is performed. Authentication procedure without ciphering is performed.

The UE initiates a routing area updating procedure, and the SS initiates an authentication and ciphering procedure to start ciphering.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		The following messages are sent and shall be received on cell A.
2		UE		The SS activates cell A.
3		UE		The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 27.
4	->		ATTACH REQUEST	The UE is powered up or switched on and initiates an attach (see ICS). Attach type = 'PS attach' Mobile identity = IMSI Message not ciphered
5	<-		AUTHENTICATION AND CIPHERING REQUEST	Request authentication. Ciphering off Message not ciphered
6	->		AUTHENTICATION AND CIPHERING RESPONSE	RES Message not ciphered
7	<-		ATTACH ACCEPT	Attach result = 'PS only attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-1 Message not ciphered
8	->		ATTACH COMPLETE	Message not ciphered
9	<-		PAGING REQUEST TYPE 1	Mobile identity = P-TMSI-2 Paging order is for TBF establishment. Message not ciphered
10	->		UPLINK RLC DATA BLOCK	LLC PDU implicitly indicating paging response. Message not ciphered
11		SS		The following messages are sent and shall be received on cell B.
12	->		ROUTING AREA UPDATING REQUEST	Activate cell B with a lower signal strength than cell A. The RF level of cell A is lowered until cell B is preferred by the UE. Update type = 'RA updating' P-TMSI-2 signature Routing area identity = RAI-1 Message not ciphered
13	<-		AUTHENTICATION AND CIPHERING REQUEST	Request authentication. Ciphering on Message not ciphered
14	->		AUTHENTICATION AND CIPHERING RESPONSE	RES Message not ciphered
15	<-		ROUTING AREA UPDATING ACCEPT	Update result = 'RA updated' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-2 Message ciphered
16	->		ROUTING AREA UPDATING COMPLETE	Message ciphered
17	<-		PAGING REQUEST TYPE 1	Mobile identity = P-TMSI-1 Paging order is for TBF establishment. Message not ciphered
18	->		UPLINK RLC DATA BLOCK	LLC PDU implicitly indicating paging response. Message ciphered
19	<-		P-TMSI REALLOCATION COMMAND	Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-2 Message ciphered
20	->		P-TMSI REALLOCATION COMPLETE	Message ciphered



21	<-	IDENTITY REQUEST	Identity type = IMEI Message not ciphered
22	->	IDENTITY RESPONSE	Mobile identity = IMEI Message not ciphered
23	<-	P-TMSI REALLOCATION COMMAND	Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-2 Message ciphered
24	->	P-TMSI REALLOCATION COMPLETE	Message ciphered
25	UE		The UE is switched off or power is removed (see ICS).
26	->	DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, PS detach' Message ciphered
27	UE		The UE is set in UE operation mode A (see ICS) and the test is repeated from step 3 to step 26.

### 12.6.2.1.5 Test requirements

#### Case1)

UE shall:

- initiate a PS attach procedure with information elements specified in the above Expected Sequence when UE is powered on or switched on.

When the UE receives the AUTHENTICATION AND CIPHERING REQUEST message during the PS attach procedure, with Ciphering indicator information element set to 'ciphering mode off', UE shall:

- respond with an AUTHENTICATION AND CIPHERING RESPONSE message.
- not start ciphering.

#### Case2)

UE shall:

- initiate a routing area updating procedure with information elements specified in the above Expected Sequence.

When the UE receives the AUTHENTICATION AND CIPHERING REQUEST message during the routing area updating procedure, with Ciphering indicator information element set to 'ciphering mode on', UE shall:

- responds with an AUTHENTICATION AND CIPHERING RESPONSE message.
- start ciphering and deciphering with the algorithm indicated by the Ciphering algorithm information element.
- apply the ciphering that uses the cipher key determined during the authentication procedure.

## 12.6.2.2 Ciphering mode / stop ciphering

### 12.6.2.2.1 Definition

### 12.6.2.2.2 Conformance requirement

- 1) When the UE receives the AUTHENTICATION AND CIPHERING REQUEST message during the attach procedure, with Ciphering indicator information element set to 'ciphering mode on', the User Equipment shall:

- 1.1 responds with an AUTHENTICATION AND CIPHERING RESPONSE message

- 1.2 start ciphering and deciphering with the algorithm indicated by the Ciphering algorithm information element
- 1.3 the ciphering uses the cipher key determined during the authentication procedure
- 2) When the UE receives the AUTHENTICATION AND CIPHERING REQUEST message during the routing area updating procedure, with Ciphering indicator information element set to 'ciphering mode on', the User Equipment shall:
  - 2.1. responds with an AUTHENTICATION AND CIPHERING RESPONSE message
  - 2.2. start ciphering and deciphering with the algorithm indicated by the Ciphering algorithm information element
  - 2.3. the ciphering uses the cipher key determined during the authentication procedure

#### Reference

3G TS 24.008 clause 4.7.7

#### 12.6.2.2.3 Test purpose

To test the behaviour of the UE if the network accepts the authentication and ciphering procedure without ciphering.

#### 12.6.2.2.4 Method of test

#### Initial condition

##### System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2.  
Both cells are operating in network operation mode II.

##### User Equipment:

The UE has a valid IMSI.

#### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
UE operation mode C	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

#### Test procedure

A PS attach is performed, and the SS initiates an authentication and ciphering procedure to start ciphering.

The UE initiates a routing area updating procedure. A RA updating procedure is initiated, and authentication procedure without ciphering is performed. Ciphering is turned off.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		The following messages are sent and shall be received on cell A.
2		UE		The SS activates cell A.
3		UE		The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 21.
4	->		ATTACH REQUEST	The UE is powered up or switched on and initiates an attach (see ICS). Attach type = 'PS attach' Mobile identity = IMSI Message not ciphered
5	<-		AUTHENTICATION AND CIPHERING REQUEST	Request authentication. Ciphering on Message not ciphered
6	->		AUTHENTICATION AND CIPHERING RESPONSE	RES Message not ciphered
7	<-		ATTACH ACCEPT	Attach result = 'PS only attached' Mobile identity = P-TMSI-2 P-TMSI-2 signature Routing area identity = RAI-1 Message ciphered
8	->		ATTACH COMPLETE	Message ciphered
9	<-		PAGING REQUEST TYPE 1	Mobile identity = P-TMSI-2 Paging order is for TBF establishment. Message not ciphered
10	->		UPLINK RLC DATA BLOCK	LLC PDU implicitly indicating paging response. Message ciphered
11		SS		The following messages are sent and shall be received on cell B.
12	->		ROUTING AREA UPDATING REQUEST	Activate cell B with a lower signal strength than cell A The RF level of cell A is lowered until cell B is preferred by the UE. Update type = 'RA updating' P-TMSI-2 signature Routing area identity = RAI-1 Message not ciphered
13	<-		AUTHENTICATION AND CIPHERING REQUEST	Request authentication. Ciphering off Message not ciphered
14	->		AUTHENTICATION AND CIPHERING RESPONSE	RES Message not ciphered
15	<-		ROUTING AREA UPDATING ACCEPT	Update result = 'RA updated' Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-2 Message not ciphered
16	->		ROUTING AREA UPDATING COMPLETE	Message not ciphered
17	<-		PAGING REQUEST TYPE 1	Mobile identity = P-TMSI-1 Paging order is for TBF establishment.
18	->		UPLINK RLC DATA BLOCK	LLC PDU implicitly indicating paging response. Message not ciphered
19		UE		The UE is switched off or power is removed (see ICS).
20	->		DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, PS detach' Message not ciphered

21	UE		The UE is set in UE operation mode A (see ICS) and the test is repeated from step 1 to step 20.
----	----	--	---

Note that due to the test of ciphering, it is in this test case indicated whether each message is ciphered or not.

#### 12.6.2.2.5 Test requirements

Case1)

UE shall:

- initiate a PS attach procedure with information elements specified in the above Expected Sequence when UE is powered on or switched on.

When the UE receive the AUTHENTICATION AND CIPHERING REQUEST message form SS during the PS attach procedure, with Ciphering indicator information element set to 'ciphering mode on', UE shall:

- respond with an AUTHENTICATION AND CIPHERING RESPONSE message.
- start ciphering and deciphering with the algorithm indicated by the Ciphering algorithm information element.
- apply the ciphering that uses the cipher key determined during the authentication procedure.

Case2)

UE shall:

- initiate a routing area updating procedure with information elements specified in the above Expected Sequence.

When the UE receives the AUTHENTICATION AND CIPHERING REQUEST message during the routing area updating procedure, with Ciphering indicator information element set to 'ciphering mode on', UE shall:

- respond with an AUTHENTICATION AND CIPHERING RESPONSE message.
- start ciphering and deciphering with the algorithm indicated by the Ciphering algorithm information element.
- apply the ciphering that uses the cipher key determined during the authentication procedure.

### 12.6.2.3 Ciphering mode / IMEISV request

#### 12.6.2.3.1 Definition

#### 12.6.2.3.2 Conformance requirement

- 1) When the UE receives the AUTHENTICATION AND CIPHERING REQUEST message during the attach procedure, with Ciphering indicator information element set to 'ciphering mode on' and 'IMEISV requested', the User Equipment shall:

- 1.1 responds with an AUTHENTICATION AND CIPHERING RESPONSE message
- 1.2 include IMEISV
- 1.3 start ciphering and deciphering with the algorithm indicated by the Ciphering algorithm information element
- 1.4 the ciphering uses the cipher key determined during the authentication procedure

- 2) When the UE receives the AUTHENTICATION AND CIPHERING REQUEST message during the routing area updating procedure, with Ciphering indicator information element set to 'ciphering mode off' and 'IMEISV not requested', the User Equipment shall:

- 2.1 responds with an AUTHENTICATION AND CIPHERING RESPONSE message
- 2.2 not include IMEISV
- 2.3 not start ciphering

#### Reference

3G TS 24.008 clause 4.7.7

#### 12.6.2.3.3 Test purpose

To test the behaviour of the UE with respect to return IMEISV on request only.

#### 12.6.2.3.4 Method of test

#### Initial condition

##### System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2.

Both cells are operating in network operation mode II.

##### User Equipment:

The UE has a valid IMSI.

#### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
UE operation mode C	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

#### Test procedure

A PS attach is performed, and the SS initiates an authentication and ciphering procedure. IMEISV is requested.

The UE initiates a routing area updating procedure, and the SS initiates a new authentication and ciphering procedure without requesting IMEISV.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		<p>The following messages are sent and shall be received on cell A.</p> <p>The SS activates cell A.</p> <p>The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 21.</p> <p>The UE is powered up or switched on and initiates an attach (see ICS).</p> <p>Attach type = 'PS attach'</p> <p>Mobile identity = IMSI</p> <p>Message not ciphered</p> <p>Request authentication.</p> <p>Ciphering on</p> <p>IMEISV requested</p> <p>Message not ciphered</p> <p>RES</p> <p>Mobile identity = IMEISV</p> <p>Message not ciphered</p> <p>Attach result = 'PS attach'</p> <p>Mobile identity = P-TMSI-2</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p> <p>Message ciphered</p> <p>Message ciphered</p>
2		UE		
3		UE		
4	->		ATTACH REQUEST	
5	<-		AUTHENTICATION AND CIPHERING REQUEST	
6	->		AUTHENTICATION AND CIPHERING RESPONSE	
7	<-		ATTACH ACCEPT	
8	->		ATTACH COMPLETE	
9	<-		PAGING REQUEST TYPE 1	
10	->		UPLINK RLC DATA BLOCK	
11		SS		<p>The following messages are sent and shall be received on cell B.</p> <p>Activate cell B with a lower signal strength than cell A. The RF level of cell A is lowered until cell B is preferred by the UE.</p> <p>Update type = 'RA updating'</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p> <p>Message not ciphered</p> <p>Request authentication.</p> <p>Ciphering off</p> <p>IMEISV not requested</p> <p>Message not ciphered</p> <p>RES</p> <p>No IMEISV included</p> <p>Message not ciphered</p> <p>Update result = 'RA updated'</p> <p>Mobile identity = P-TMSI-1</p> <p>P-TMSI-1 signature</p> <p>Routing area identity = RAI-2</p> <p>Message not ciphered</p> <p>Message not ciphered</p>
12	->		ROUTING AREA UPDATING REQUEST	
13	<-		AUTHENTICATION AND CIPHERING REQUEST	
14	->		AUTHENTICATION AND CIPHERING RESPONSE	
15	<-		ROUTING AREA UPDATING ACCEPT	
16	->		ROUTING AREA UPDATING COMPLETE	
17	<-		PAGING REQUEST TYPE 1	
18	->		UPLINK RLC DATA BLOCK	
19		UE		

20	->	DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, PS detach' Message not ciphered
21	UE		The UE is set in UE operation mode A (see ICS) and the test is repeated from step 1 to step 20.

Note that due to the test of ciphering, it is in this test case indicated whether each message is ciphered or not.

#### 12.6.2.3.5 Test requirements

Case1)

UE shall:

- initiate a PS attach procedure with information elements specified in the above Expected Sequence when UE is powered on or switched on.

When the UE receives the AUTHENTICATION AND CIPHERING REQUEST message during the attach procedure, with Ciphering indicator information element set to 'ciphering mode on' and 'IMEISV requested', UE shall:

- respond with the AUTHENTICATION AND CIPHERING RESPONSE message.
- include the IMEISV in the AUTHENTICATION AND CIPHERING RESPONSE message.
- start ciphering and deciphering with the algorithm indicated by the Ciphering algorithm information element.
- apply the ciphering that uses the cipher key determined during the authentication procedure

Case2)

UE shall:

- initiate a routing area updating procedure with information elements specified in the above Expected Sequence.

When the UE receives the AUTHENTICATION AND CIPHERING REQUEST message during the routing area updating procedure, with Ciphering indicator information element set to 'ciphering mode off' and 'IMEISV not requested', UE shall:

- respond with the AUTHENTICATION AND CIPHERING RESPONSE message.
- not include the IMEISV in the AUTHENTICATION AND CIPHERING RESPONSE message.
- not start ciphering.

## 12.7 Identification procedure

The purpose of this procedure is to check that the UE gives its identity as requested by the network. If this procedure does not work, it will not be possible for the network to rely on the identity claimed by the UE.

### 12.7.1 General Identification

#### 12.7.1.1 Definition

#### 12.7.1.2 Conformance requirement

- 1) When requested by the network the User Equipment shall send its IMSI.

- 2) When requested by the network the User Equipment shall send its IMEI as stored in the Mobile Equipment.
- 3) When requested by the network the User Equipment shall send its IMEISV as stored in the Mobile Equipment.

#### Reference

3G TS 24.008 clauses 4.7.8

#### 12.7.1.3 Test purpose

To verify that the UE sends identity information as requested by the system. The following identities can be requested: IMSI, IMEI and IMEISV.

#### 12.7.1.4 Method of test

##### Initial condition

##### System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC2.

Both cells are operating in network operation mode II.

##### User Equipment:

The UE has a valid IMSI.

#### Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
UE operation mode C	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

#### Test procedure

The SS requests identity information from the UE:

- IMSI
- IMEI
- IMEISV



## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 14.
2	UE			The UE is powered up or switched on and initiates an attach (see ICS).
3	->		ATTACH REQUEST	Attach type = 'PS attach'
4	<-		ATTACH ACCEPT	Mobile identity = IMSI Attach result = 'PS only attached'
5	->		ATTACH COMPLETE	Mobile identity = P-TMSI-1 P-TMSI-1 signature Routing area identity = RAI-1
6	<-		IDENTITY REQUEST	Identity type = IMSI
7	->		IDENTITY RESPONSE	Mobile identity = IMSI
8	<-		IDENTITY REQUEST	Identity type = IMEI
9	->		IDENTITY RESPONSE	Mobile identity = IMEI
10	<-		IDENTITY REQUEST	Identity type = IMEISV
11	->		IDENTITY RESPONSE	Mobile identity = IMEISV
12	UE			The UE is switched off or power is removed (see ICS).
13	->		DETACH REQUEST	Message not sent if power is removed. Detach type = 'power switched off, PS detach'
14	UE			The UE is set in UE operation mode A (see ICS) and the test is repeated from step 2 to step 13.

## 12.7.1.5 Test requirements

UE shall:

- initiate a PS attach procedure with information elements specified in the above Expected Sequence when UE is powered on or switched on.

When SS requests an IMSI with the IDENTITY REQUEST message, UE shall:

- send the IDENTITY RESPONSE message with the Mobile identity = IMSI.

When SS requests an IMEI with the IDENTITY REQUEST message, UE shall:

- send the IDENTITY RESPONSE message with the Mobile identity = IMEI.

When SS requests an IMEISV with the IDENTITY REQUEST message, UE shall:

- send the IDENTITY RESPONSE message with the Mobile identity = IMEISV.

## 12.8 GMM READY timer handling

The READY timer is not applicable for UMTS.

### 12.8.1 Definition

### 12.8.2 Conformance requirement

If a READY timer value is received by an UE capable of both UMTS and GSM in the ATTACH ACCEPT or the ROUTING AREA UPDATE ACCEPT messages, then the received value shall be stored by the UE in order to be used at an intersystem change from UMTS to GSM.

## Reference

3G TS 24.008 clause 4.7.2.1

## 12.8.3 Test purpose

To verify the functionality of the READY timer.

## 12.8.4 Method of test

## 12.8.4.1 Test procedure1

## Initial condition

## System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1, cell B in MCC1/MNC1/LAC1/RAC1.

Both cells are operating in network operation mode II.

## User Equipment:

The UE has a valid IMSI.

## Related ICS/IXIT statements

Support of PS service	Yes/No
UE operation mode A	Yes/No
Switch off on button	Yes/No
Automatic PS attach procedure at switch on or power on	Yes/No

## Test procedure

An attach is performed.

T3314; set to 60 seconds

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		<p>The following messages are sent and shall be received on cell A.</p> <p>The SS activates cell A.</p> <p>The UE is set in UE operation mode A (see ICS). If UE operation mode A not supported set the UE in operation mode C.</p> <p>The UE is powered up or switched on and initiates an attach (see ICS).</p> <p>Attach type = 'PS attach'</p> <p>Mobile identity = IMSI</p> <p>Attach result = 'PS only attached'</p> <p>Mobile identity = P-TMSI-2</p> <p>P-TMSI-2 signature</p> <p>Routing area identity = RAI-1</p> <p>T3314 = 60 seconds</p>
2		UE		
3	->		ATTACH REQUEST	
4	<-		ATTACH ACCEPT	
5	->		ATTACH COMPLETE	
6	->	UE		<p>The UE is switched off or power is removed (see ICS).</p> <p>Message not sent if power is removed.</p> <p>Detach type = 'power switched off, PS detach'</p>
7	->		DETACH REQUEST	

## 12.8.5 Test requirements

When UE receives the ATTACH ACCEPT or the ROUTING AREA UPDATE ACCEPT messages, UE shall:

- store the received READY timer value.

## 8.613 General Tests

### 8.613.1 Emergency call / general

The purpose of these tests is to verify that the UE performs certain elementary procedures of the RRC, MM, and CC protocol correctly within a structured procedure. The term "structured procedure" is defined in 3GPP TS 23.108, where also examples of structured procedures are given.

The reason for this test purposes is twofold:

- the behaviour of the UE in an elementary procedure may depend on the preamble which precedes the elementary procedure;
- structured procedures tested in this subclause are used in other parts of this Technical Specification as preambles to establish the initial conditions for other tests; correct behaviour of an implementation under test in a preamble is essential for the validity of a test.

Mobile originating and terminating calls are tested in cases of both early and late assignment of the traffic channel; in one of the cases call release initiated by the network is tested, in another one, call release initiated by the UE. The tests in this subclause only cover the successful outcome of elementary procedures (i.e. they do not deal with abnormal cases).

In this subclause, the emergency call service is tested for user equipment that support narrow band speech (AMR) in the following cases:

- emergency call initiated in the idle mode state with authentication and security, for narrow band speech (AMR)
- emergency call initiated in the idle, no IMSI state (hence without authentication and without security), the network accepting the call, for narrow band speech (AMR)
- emergency call initiated in the idle, no IMSI state (hence without authentication and without security), the network rejecting the call, for narrow band speech (AMR)

These tests on emergency calls are only applicable to an UE supporting narrow band speech (AMR).

~~For an UE supporting narrow band speech (AMR) the test procedures in 8.6.2, 8.6.3, 8.6.4, 8.6.5 and 8.6.6 are performed once for narrow band speech (AMR).~~

~~For an UE not supporting speech but supporting at least one teleservice, for each of the test procedures in subclauses 8.6.2, 8.6.3, 8.6.4, and 8.6.5 a teleservice supported by the UE (see ICS statement) is chosen, and the test is performed corresponding to that teleservice (note that this teleservice is never a dual service).~~

~~In cases where a mobile originated call for the tested teleservice can be initiated both:~~

~~—— via the MMI; and~~

~~—— via the R or S interface,~~

### ~~8.613.26~~ Emergency call

Emergency call establishment can be initiated by an UE whether location updating has been successful or not and whether a USIM is inserted into the UE or not; but only if the UE is equipped for speech.

If the procedures tested in this subclause are not correctly implemented in the UE, establishment, maintenance and clearing of connections might fail in the essential case of emergency calls.

The tests of this subclause are only applicable to an UE supporting narrow band speech (AMR).

#### ~~8.613.26.1~~ Emergency call / idle mode with USIM

##### ~~8.613.26.1.1~~ Emergency call / idle mode with USIM / accept case

###### 13.2.1.1.1 Definition and applicability

This test is applicable to any User Equipment supporting narrow band speech (AMR).

#### ~~8.613.26.1.1.2~~ Conformance requirement

- 1) The UE in the "idle mode" state, as after a successful location update, after the number 112 has been entered by user, shall send a RRC CONNECTION REQUEST message with correct establishment cause ("emergency call").
- 2) After assignment of a dedicated channel the first layer message sent by the UE on the assigned dedicated channel shall be a CM SERVICE REQUEST message specifying the correct CKSN and TMSI , with CM Service Type "emergency call establishment".
- 3) Authentication and security mode setting shall be performed successfully.
- 4) After security mode setting acceptance by the network, the UE shall send an EMERGENCY SETUP message.

- 5), 6) The emergency call shall be correctly established. The assignment procedure shall be correctly performed.
- 7) After receipt of a CONNECT ACKNOWLEDGE message during correct establishment of the emergency call the DTCH shall be through connected in both directions if an appropriate DTCH is available.
- 8) The call shall be cleared correctly.

#### Requirement-Reference(s):

- For conformance requirement 1 and 2: 3GPP TS 25.331 subclause 8.1.3, 3GPP TS 24.008 subclause 5.2.1, 3GPP TS 24.008 subclause 4.5.1.5, 3GPP TS 22.030 clause 4.
- For conformance requirement 3: 3GPP TS 25.331, subclause 8.1.12, 3GPP TS 24.008 subclause 4.3.2.
- For conformance requirement 4: 3GPP TS 24.008, subclause 5.2.1.1.
- For conformance requirement 5 and 6: 3GPP TS 25.331, subclause 8.2.1.
- For conformance requirement 7: 3GPP TS 24.008, subclauses 5.2.1.6 and 5.1.3.
- For conformance requirement 8: 3GPP TS 24.008, subclause 5.4.

#### ~~8-613.26~~.1.1.3 Test purpose

- 1) To verify that an UE supporting speech in the MM state "idle mode", when made to call the number 112, sends a RRC CONNECTION REQUEST message with establishment cause "emergency call".
- 2) To verify that after assignment of a dedicated channel the first layer message sent by the UE on the assigned dedicated channel is a CM SERVICE REQUEST message specifying the correct CKSN and TMSI, with CM Service Type "emergency call establishment".
- 3) To verify that authentication and security mode setting are performed successfully.
- 4) To verify that after security mode setting acceptance by the SS, the UE sends an EMERGENCY SETUP message.
- 5) To verify that subsequently, the SS having sent a CALL PROCEEDING message and then an ALERT message and having initiated the assignment procedure of an appropriate speech traffic channel, the UE performs correctly that assignment procedure.
- 6) To verify subsequent correct performance of a connect procedure.
- 7) To verify that subsequently the UE has through connected the DTCH in both directions.
- 8) To verify that the call is cleared correctly.

#### ~~8-613.26~~.1.1.4 Method of test

##### Related ICS Statements

- Narrow band speech (AMR).
- Classmark.

##### Initial Conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE is in MM-state "idle mode" with valid TMSI and CKSN.

## Test procedure

The UE is made to initiate an emergency call. The call is established with late assignment. Having reached the active state, the call is cleared by the SS.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The "called number" 112 is entered.
2	-->		RRC CONNECTION REQUEST	Establishment cause is emergency call establishment.
3	<--		RRC CONNECTION SETUP	SS accepts the establishment of a RRC connection
4	-->		RRC CONNECTION SETUP COMPLETE	
5	-->		CM SERVICE REQUEST	<del>Message is contained in SABM.</del> The CM service type IE indicates "emergency call establishment".
6	<--		AUTHENTICATION REQUEST	IE Authentication Parameter AUTN shall be present in the message.
7	-->		AUTHENTICATION RESPONSE	SRES specifies correct value.
8	<--		SECURITY MODE COMMAND	SS starts deciphering after sending the message.
9	-->		SECURITY MODE COMPLETE	Shall be sent enciphered. All following messages shall be sent enciphered.
10	SS			SS starts ciphering.
11	-->		EMERGENCY SETUP	<del>If p1 = F/H, the message must contain one bearer capability IE indicating in the radio channel requirement field "dual rate/half rate preferred" or "dual rate/full rate preferred". If p1 = F, the message must either contain no bearer capability IE or contain one bearer capability IE indicating in the radio channel requirement field "full rate channel".</del>
12	<--		CALL PROCEEDING	
A13	<--		ALERTING	
B13	<--		RADIO BEARER SETUP	The rate of the channel is that one indicated by the EMERGENCY SETUP message, if that message did not offer a choice, and the rate is the preferred one else.
B14	-->		RADIO BEARER SETUP COMPLETE	
B15	<--		CONNECT	
B16	-->		CONNECT ACKNOWLEDGE	
17	UE			The DTCH is through connected in both directions.
18	<--		DISCONNECT	
19	-->		RELEASE	
20	<--		RELEASE COMPLETE	
21	<--		RRC CONNECTION RELEASE	The main signalling link is released.

## Specific Message Contents

None.

[8.613.26.2](#) Emergency call / ~~idle, no IMSI~~without USIM

[8.613.26.2.1](#) Emergency call / ~~idle, no IMSI~~without USIM / accept case

[13.2.2.1.1](#) Definition and applicability

This test is applicable to any User Equipment supporting narrow band speech (AMR).

**8-613.26.2.1.2 Conformance requirement**

- 1) The UE in the "idle mode" state, as after a successful location update, after the number 112 has been entered by user, shall send a RRC CONNECTION REQUEST message with correct establishment cause ("emergency call").
- 2) After assignment of a dedicated channel the first layer message sent by the UE on the assigned dedicated channel shall be a CM SERVICE REQUEST message specifying the correct IMEI and a non-available CKSN, with CM Service Type "emergency call establishment".
- 3) After security mode setting acceptance by the network, the UE shall send an EMERGENCY SETUP message.
- 4), 5) The emergency call shall be correctly established. The assignment procedure shall be correctly performed.
- 6) After receipt of a CONNECT ACKNOWLEDGE message during correct establishment of the emergency call the DTCH shall be through connected in both directions if an appropriate DTCH is available.
- 7) The call shall be cleared correctly.

**Requirement Reference(s):**

For conformance requirement 1 and 2: 3GPP TS 25.331 subclause 8.1.3, 3GPP TS 24.008 subclause 5.2.1, 3GPP TS 24.008 subclause 4.5.1.5, 3GPP TS 22.030 clause 4.

For conformance requirement 3: 3GPP TS 24.008, subclause 5.2.1.1.

For conformance requirements 4 and 5: 3GPP TS 25.331, subclause 8.2.1.

For conformance requirement 6: 3GPP TS 24.008, subclauses 5.2.1.6 and 5.1.3.

For conformance requirement 7: 3GPP TS 24.008, subclause 5.4.

**8-613.26.2.1.3 Test purpose**

- 1) To verify that the UE in the "idle, no IMSI" state (no USIM inserted) when made to call the number 112, sends a RRC CONNECTION REQUEST message with establishment cause "emergency call".
- 2) To verify that after assignment of a dedicated channel the first layer message sent by the UE on the assigned dedicated channel is a CM SERVICE REQUEST message in which the security key sequence number IE indicates "no key is available", the CM service type IE indicates "emergency number establishment", and the mobile identity IE specifies the IMEI of the UE.
- 3) To verify that after receipt of a CM SERVICE ACCEPT message from the SS, the UE sends an EMERGENCY SETUP message.
- 4) To verify that subsequently, the SS having sent a CALL PROCEEDING message and then an ALERT message and having initiated the assignment procedure of an appropriate speech traffic channel, the UE performs correctly that assignment procedure.
- 5) To verify subsequent correct performance of a connect procedure.
- 6) To verify that subsequently the UE has through connected the DTCH in both directions.
- 7) To verify that the call is cleared correctly.

**8-613.26.2.1.4 Method of test****Related ICS Statements**

- Narrow band speech (AMR).
- Classmark.



## Initial Conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE is in MM-state "idle, no IMSI", no USIM inserted.

## Test procedure

The UE is made to initiate an emergency call. The call is established without authentication, without security, with late assignment. Having reached the active state, the call is cleared by the SS.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The "called number" 112 is entered. Establishment cause is "emergency call". SS accepts the establishment of a RRC connection
2	-->		RRC CONNECTION REQUEST	
3	<--		RRC CONNECTION SETUP	
4	-->		RRC CONNECTION SETUP COMPLETE	
5	-->		CM SERVICE REQUEST	
				<del>Message is contained in SABM.</del> The CM service type IE indicates "emergency call establishment". The mobile identity IE specifies the IMEI of the UE. The cipher key sequence number IE indicates "no key is available". The mobile station classmark IE is as specified by the manufacturer in a ICS statement.
6	<--		CM SERVICE ACCEPT	The rate of the channel is one indicated by the EMERGENCY SETUP message.
7	-->		EMERGENCY SETUP	
8	<--		CALL PROCEEDING	
9	<--		ALERTING	
10	<--		RADIO BEARER SETUP	
11	-->		RADIO BEARER SETUP COMPLETE	The DTCH is through connected in both directions.
12	<--		CONNECT	
13	-->		CONNECT ACKNOWLEDGE	
14	UE			
15	<--		DISCONNECT	
16	-->		RELEASE	
17	<--		RELEASE COMPLETE	The main signalling link is released.
18	<--		RRC CONNECTION RELEASE	

## Specific Message Contents

None.

[8-613.26.2.2](#) Emergency call / ~~idle, no IMSI~~without USIM / reject case

[13.2.2.2.1](#) [Definition and applicability](#)

This test is applicable to any User Equipment supporting narrow band speech (AMR).

[8-613.26.2.2.2](#) Conformance requirement

- 1) The UE in the "idle, no IMSI" state (no USIM inserted), after the number 112 has been entered, shall send a RRC CONNECTION REQUEST message with correct establishment cause ("emergency call").

- 2) After assignment of a dedicated channel the first layer message sent by the UE on the assigned dedicated channel shall be a CM SERVICE REQUEST message specifying the correct IMEI and a non-available CKSN, with CM Service Type "emergency call establishment".
- 3) In the situation at the end of test purpose 2, when the UE receives a CM SERVICE REJECT message, it shall abandon the emergency call.

#### Requirement Reference(s):

For conformance requirement 1 and 2: 3GPP TS 25.331 subclause 8.1.3, 3GPP TS 24.008 subclause 5.2.1, 3GPP TS 24.008 subclause 4.5.1.5, 3GPP TS 22.030 clause 4.

For conformance requirement 3: 3GPP TS 25.331 subclause 8.1.12, 3GPP TS 24.008 subclause 4.5.1.1.

#### 8.613.26.2.2.3      Test purpose

- 1) To verify that the UE in the "idle, no IMSI" state (no USIM inserted) when made to call the number 112, sends a RRC CONNECTION REQUEST message with establishment cause "emergency call".
- 2) To verify that after assignment of a dedicated channel the first layer message sent by the UE on the assigned dedicated channel is a CM SERVICE REQUEST message in which the security key sequence number IE indicates "no key is available", the CM service type IE indicates "emergency call establishment", and the mobile identity IE specifies the IMEI of the UE.
- 3) To verify that after receipt of a CM SERVICE REJECT message from the SS, the UE abandons the emergency call establishment.

#### 8.613.26.2.2.4      Method of test

#### Related ICS statements

- Narrow band speech (AMR).
- Classmark.

#### Initial Conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE is in MM-state "idle, no IMSI", no USIM inserted.

#### Test procedure

The UE is made to initiate an emergency call. The call is established without authentication, without security, with early assignment. The SS responds to the CM SERVICE REQUEST from the UE with a CM SERVICE REJECT message specifying in the reject cause IE the reject cause value "IMEI not accepted". The SS then verifies for during 5 seconds that the UE does not send a layer 3 message. Then the call is cleared by the SS. The SS verifies during 20 seconds after disconnection of the main signalling link that the UE does not initiate a RRC connection establishment.

## Expected Sequence

Step	Direction		Message	Comments
	UE	SS		
1	UE			The "called number" 112 is entered.
2	-->		RRC CONNECTION REQUEST	Establishment cause is "emergency call".
3	<--		RRC CONNECTION SETUP	SS accepts the establishment of a RRC connection
4	-->		RRC CONNECTION SETUP COMPLETE CM SERVICE REQUEST	<del>Message is contained in SABM.</del> The CM service type IE indicates "emergency call establishment". The mobile identity IE specifies the IMEI of the UE. The cipher key sequence number IE indicates "no key is available". The mobile station classmark IE is as specified by the manufacturer in a ICS statement.
6	<--		CM SERVICE REJECT	the reject cause IE specifies reject cause value #5, "IMEI not accepted".
7	SS			During 5 seconds, the SS verifies that the UE does not send L3 messages.
8	<--		RRC CONNECTION RELEASE	The main signalling link is released.
9	SS			During 20 seconds, the SS verifies that the UE does not initiate a RRC connection establishment

## Specific Message Contents:

None.

## 14 Radio Bearer Services

### 14.1 General information for radio bearer tests

The role of radio bearer services is to cover all aspects of the radio interface transport. TS 34.108, clause 6.10 specifies reference radio bearer configurations to be tested.

The applicability of radio bearer tests is dependent on the UE uplink and downlink radio access capabilities and UE support tele- and bearer-services. See TS 34.123-2, Annex B for applicability of the specific test cases.

#### 14.1.1 UE radio bearer test mode activation procedure

The Radio Bearer Test Mode Activation procedure is used to get UE in the state for radio bearer testing using the radio bearer setup configurations as specified in TS 34.108, clause 6.10.

Step	Direction		Message	Comments
	UE	SS		
1	<--		SYSTEM INFORMATION (BCCH)	Broadcast
2	<--		PAGING (PCCH)	Paging
3	-->		RRC CONNECTION REQUEST (CCCH)	RRC
4	<--		RRC CONNECTION SETUP (CCCH)	RRC
5	-->		RRC CONNECTION SETUP COMPLETE (DCCH)	RRC
7	-->		PAGING RESPONSE (DCCH)	RR
8	<--		ACTIVATE RB TEST MODE (DCCH)	TC
9	-->		ACTIVATE RB TEST MODE COMPLETE (DCCH)	TC
10	<--		RADIO BEARER SETUP (DCCH)	RRC
11	-->		RADIO BEARER SETUP COMPLETE (DCCH)	RRC

## 14.2 Combinations on DPCH

### 14.2.1 Stand-alone UL:1.7 DL:1.7 kbps SRBs for DCCH

Implicitly tested

### 14.2.2 Stand-alone UL:3.4 DL:3.4 kbps SRBs for DCCH

Implicitly tested

### 14.2.3 Stand-alone UL:13.6 DL:13.6 kbps SRBs for DCCH

Implicitly tested

### 14.2.4 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

#### 14.2.4.1 Conformance requirement

The UE shall be able to establish the UTRAN requested radio bearers within the UE's signaled radio access capabilities be able to establish the UTRAN requested radio bearers.

The UE shall correctly transfer user data from peer to peer RLC entities according to the requested radio bearer configuration.

#### Reference(s)

3GPP TS 25.331, clause 8.2.1

3GPP TS 25.2xx series (Physical Layer)

3GPP TS 25.321 (MAC)

3GPP TS 25.322 (RLC)

#### 14.2.4.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.4.

#### 14.2.4.3 Method of test

Uplink TFS:

	<b>TFI</b>	<b>RAB subflow #1</b>	<b>RAB subflow #2</b>	<b>RAB subflow #3</b>	<b>DCCH</b>
TFS	TF0, bits	0x81 (alt. 1x0)	0x103	0x60	0x148
	TF1, bits	1x39	1x103	1x60	1x148
	TF2, bits	1x81	N/A	N/A	N/A

Uplink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, RAB subflow#2, RAB subflow#3,DCCH)</b>
UL_TFC0	(TF0, TF0, TF0, TF0)
UL_TFC1	(TF1, TF0, TF0, TF0)
UL_TFC2	(TF2, TF1, TF1, TF0)
UL_TFC3	(TF0, TF0, TF0, TF1)
UL_TFC4	(TF1, TF0, TF0, TF1)
UL_TFC5	(TF2, TF1, TF1, TF1)

Downlink TFS:

		<b>RAB subflow #1</b>	<b>RAB subflow #2</b>	<b>RAB subflow #3</b>	<b>DCCH</b>
TFS	TF0, bits	1x0	0x103	0x60	0x148
	TF1, bits	1x39	1x103	1x60	1x148
	TF2, bits	1x81	N/A	N/A	N/A

Downlink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, RAB subflow#2, RAB subflow#3,DCCH)</b>
DL_TFC0	(TF0, TF0, TF0, TF0)
DL_TFC1	(TF1, TF0, TF0, TF0)
DL_TFC2	(TF2, TF1, TF1, TF0)
DL_TFC3	(TF0, TF0, TF0, TF1)
DL_TFC4	(TF1, TF0, TF0, TF1)
DL_TFC5	(TF2, TF1, TF1, TF1)

Sub-tests:

<b>Sub-test</b>	<b>Downlink TFCS under test</b>	<b>Uplink TFCS under test</b>	<b>Implicitely tested</b>
1	DL_TFC1	UL_TFC1	DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3
2	DL_TFC2	UL_TFC2	DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5

Initial conditions

UE in idle mode

Test procedure Sub test 1:

- The SS setup the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.4 using the generic procedure for UE radio bearer test mode activation according to clause 14.1.1.
- The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC3} using the RRC transport format combination control procedure.
- The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 39 bits for RAB subflow#1, 103 bits for RAB subflow#2 and to 60 bits for RAB subflow#3.
- The SS transmits an RLC SDU of size 39 bits on RAB subflow#1, using transport format combination DL\_TFC1. No data is transmitted on RAB subflow#2 and RAB subflow#3.
- The SS checks that the content of the received RLC SDU returned in uplink on RAB subflow#1 has the correct content and is received having the correct transport format. The SS checks that no data is received on RAB subflow#2 or RAB subflow#3.
- The SS open the UE test loop.

Sub test 2:

- The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC2, UL\_TFC5} using the RRC transport format combination control procedure.

- h) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 81 bits for RAB subflow#1, 103 bits for RAB subflow#2 and to 60 bits for RAB subflow#3.
- i) The SS transmits an RLC SDU of size 81 bits on RAB subflow#1, an RLC SDU of size 103 bits on RAB subflow#2 and an RLC SDU of size 60 bits on RAB subflow#3 using transport format combination DL\_TFC2.
- j) The SS checks that the content of the received RLC SDUs returned in uplink on RAB subflow#1, RAB subflow#2 and RAB subflow#3 have the correct content and are received having the correct transport format.
- k) The SS may optionally open the UE test loop.
- l) The SS may optionally release the radio bearer.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			UE Radio Bearer Test Mode Activation	See generic procedures in clause 14.1.1 Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC3} UE test loop mode 1 is closed using RAB#1: UL RLC SDU size = 39 bits RAB#2: UL RLC SDU size = 103 bits RAB#3: UL RLC SDU size = 60 bits
2		←	TRANSPORT FORMAT COMBINATION CONTROL	
3		←	CLOSE UE TEST LOOP	
4		→	CLOSE UE TEST LOOP COMPLETE (DCCH)	DL_TFC1: RAB#1: 39 bits (TF1=1x39 bits) RAB#2: 0 bits (TF0=0x103 bits) RAB#3: 0 bits (TF0=0x60 bits)
5		←	DOWNLINK RLC SDU	
6		→	UPLINK RLC SDU	
7		←	OPEN UE TEST LOOP	UL_TFC1: RAB#1: 39 bits (TF1=1x39 bits) RAB#2: 0 bits (TF0=0x103 bits) RAB#3: 0 bits (TF0=0x60 bits)
8		→	OPEN UE TEST LOOP COMPLETE	
9		←	TRANSPORT FORMAT COMBINATION CONTROL	
10		←	CLOSE UE TEST LOOP	Transport format combinations is limited to {UL_TFC0, UL_TFC2, UL_TFC5} UE test loop mode 1 is closed using RAB#1: UL RLC SDU size = 81 bits RAB#2: UL RLC SDU size = 103 bits RAB#3: UL RLC SDU size = 60 bits
11		→	CLOSE UE TEST LOOP COMPLETE	
12		←	DOWNLINK RLC SDU	
13		→	UPLINK RLC SDU	DL_TFC2: RAB#1: 39 bits (TF2=1x39 bits) RAB#2: 103 bits (TF1=1x103 bits) RAB#3: 60 bits (TF1=1x60 bits)
14		←	OPEN UE TEST LOOP	UL_TFC2: RAB#1: 39 bits (TF2=1x39 bits) RAB#2: 103 bits (TF1=1x103 bits) RAB#3: 60 bits (TF1=1x60 bits)
15		→	OPEN UE TEST LOOP COMPLETE	Optional step
16			RB RELEASE	Optional step

#### 14.2.4.4 Test requirements

- At step 1 the UE shall send RADIO BEARER SETUP COMPLETE.
- At step 6 the UE transmitted transport format shall be

- TF1 (1x39) for RAB subflow#1.
3. At step 6 the UE shall return
- an RLC SDU on RAB subflow#1 with the same content as sent by SS; and
  - no data shall be received on RAB subflow#2 or RAB subflow#3.
4. At step 13 the UE transmitted transport format shall be
- TF2 (1x81) for RAB subflow#1; and
  - TF1 (1x103) for RAB subflow#2; and
  - TF1 (1x60) for RAB subflow#3.
5. At step 13 the UE shall return
- an RLC SDU on RAB subflow#1 with the same content as sent by SS; and
  - an RLC SDU on RAB subflow#2 with the same content as sent by SS; and
  - an RLC SDU on RAB subflow#3 with the same content as sent by SS.

## 14.2.5 Conversational / speech / UL:10.2 DL:10.2 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

### 14.2.5.1 Conformance requirement

See 14.2.4.1.

### 14.2.5.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.5.

### 14.2.5.3 Method of test

Uplink TFS:

	TFI	RAB subflow #1	RAB subflow #2	RAB subflow #3	DCCH
TFS	TF0, bits	0x65(alt. 1x0)	0x99	0x40	0x148
	TF1, bits	1x39	1x99	1x40	1x148
	TF2, bits	1x65	N/A	N/A	N/A

Uplink TFCS:

TFCI	(RAB subflow#1, RAB subflow#2, RAB subflow#3,DCCH)
UL_TFC0	(TF0, TF0, TF0, TF0)
UL_TFC1	(TF1, TF0, TF0, TF0)
UL_TFC2	(TF2, TF1, TF1, TF0)
UL_TFC3	(TF0, TF0, TF0, TF1)
UL_TFC4	(TF1, TF0, TF0, TF1)
UL_TFC5	(TF2, TF1, TF1, TF1)

Downlink TFS:



		RAB subflow #1	RAB subflow #2	RAB subflow #3	DCCH
TFS	TF0, bits	1x0	0x99	0x40	0x148
	TF1, bits	1x39	1x99	1x40	1x148
	TF2, bits	1x65	N/A	N/A	N/A

Downlink TFCS:

TFCI	(RAB subflow#1, RAB subflow#2, RAB subflow#3, DCCH)
DL_TFC0	(TF0, TF0, TF0, TF0)
DL_TFC1	(TF1, TF0, TF0, TF0)
DL_TFC2	(TF2, TF1, TF1, TF0)
DL_TFC3	(TF0, TF0, TF0, TF1)
DL_TFC4	(TF1, TF0, TF0, TF1)
DL_TFC5	(TF2, TF1, TF1, TF1)

Sub-tests:

Sub-test	Downlink TFCS under test	Uplink TFCS under test	Implicitely tested
1	DL_TFC1	UL_TFC1	DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3
2	DL_TFC2	UL_TFC2	DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5

Initial conditions

UE in idle mode

Test procedure

Sub test 1:

- The SS setup the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.5 using the generic procedure for UE radio bearer test mode activation according to clause 14.1.1.
- The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC3} using the RRC transport format combination control procedure.
- The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 39 bits for RAB subflow#1, 99 bits for RAB subflow#2 and to 40 bits for RAB subflow#3.
- The SS transmits an RLC SDU of size 39 bits on RAB subflow#1, using transport format combination DL\_TFC1. No data is transmitted on RAB subflow#2 and RAB subflow#3.
- The SS checks that the content of the received RLC SDU returned in uplink on RAB subflow#1 has the correct content and is received having the correct transport format. The SS checks that no data is received on RAB subflow#2 or RAB subflow#3.
- The SS open the UE test loop.

Sub test 2:

- The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC2, UL\_TFC5} using the RRC transport format combination control procedure.
- The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 65 bits for RAB subflow#1, 99 bits for RAB subflow#2 and to 40 bits for RAB subflow#3.
- The SS transmits an RLC SDU of size 65 bits on RAB subflow#1, an RLC SDU of size 99 bits on RAB subflow#2 and an RLC SDU of size 40 bits on RAB subflow#3 using transport format combination DL\_TFC2.

- j) The SS checks that the content of the received RLC SDUs returned in uplink on RAB subflow#1, RAB subflow#2 and RAB subflow#3 have the correct content and are received having the correct transport format.
- k) The SS may optionally open the UE test loop.
- l) The SS may optionally release the radio bearer.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			UE Radio Bearer Test Mode Activation	See generic procedures in clause 14.1.1 Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC3} UE test loop mode 1 is closed using RAB#1: UL RLC SDU size = 39 bits RAB#2: UL RLC SDU size = 99 bits RAB#3: UL RLC SDU size = 40 bits
2	←		TRANSPORT FORMAT COMBINATION CONTROL	
3	←		CLOSE UE TEST LOOP	
4	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	DL_TFC1: RAB#1: 39 bits (TF1=1x39 bits) RAB#2: 0 bits (TF0=1x99 bits) RAB#3: 0 bits (TF0=1x40 bits) UL_TFC1: RAB#1: 39 bits (TF1=1x39 bits) RAB#2: 0 bits (TF0=1x99 bits) RAB#3: 0 bits (TF0=1x40 bits)
5	←		DOWNLINK RLC SDU	
6	→		UPLINK RLC SDU	
7	←		OPEN UE TEST LOOP	Transport format combinations is limited to {UL_TFC0, UL_TFC2, UL_TFC5} UE test loop mode 1 is closed using RAB#1: UL RLC SDU size = 65 bits RAB#2: UL RLC SDU size = 99 bits RAB#3: UL RLC SDU size = 40 bits
8	→		OPEN UE TEST LOOP COMPLETE	
9	←		TRANSPORT FORMAT COMBINATION CONTROL	
10	←		CLOSE UE TEST LOOP	TC DL_TFC2: RAB#1: 65 bits (TF2=1x65 bits) RAB#2: 99 bits (TF1=1x99 bits) RAB#3: 40 bits (TF1=1x40 bits) UL_TFC2: RAB#1: 65 bits (TF2=1x65 bits) RAB#2: 99 bits (TF1=1x99 bits) RAB#3: 40 bits (TF1=1x40 bits)
11	→		CLOSE UE TEST LOOP COMPLETE	
12	←		DOWNLINK RLC SDU	
13	→		UPLINK RLC SDU	Optional step Optional step Optional step
14	←		OPEN UE TEST LOOP	
15	→		OPEN UE TEST LOOP COMPLETE	
16			RB RELEASE	

## 14.2.5.4 Test requirements

1. At step 1 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 6 the UE transmitted transport format shall be
  - TF1 (1x39) for RAB subflow#1.
3. At step 6 the UE shall return
  - an RLC SDU on RAB subflow#1 with the same content as sent by SS; and
  - no data shall be received on RAB subflow#2 or RAB subflow#3.
4. At step 13 the UE transmitted transport format shall be

- TF2 (1x65) for RAB subflow#1; and
- TF1 (1x99) for RAB subflow#2; and
- TF1 (1x40) for RAB subflow#3.

5. At step 13 the UE shall return

- an RLC SDU on RAB subflow#1 with the same content as sent by SS; and
- an RLC SDU on RAB subflow#2 with the same content as sent by SS; and
- an RLC SDU on RAB subflow#3 with the same content as sent by SS.

## 14.2.6 Conversational / speech / UL:7.95 DL:7.95 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

### 14.2.6.1 Conformance requirement

See 14.2.4.1.

### 14.2.6.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.6.

### 14.2.6.3 Method of test

Uplink TFS:

	TFI	RAB subflow #1	RAB subflow #2	DCCH
TFS	TF0, bits	0x75 (alt. 1x0)	0x84	0x148
	TF1, bits	1x39	1x84	1x148
	TF2, bits	1x75	N/A	N/A

Uplink TFCS:

TFCI	(RAB subflow#1, RAB subflow#2, DCCH)
UL_TFC0	(TF0, TF0, TF0)
UL_TFC1	(TF1, TF0, TF0)
UL_TFC2	(TF2, TF1, TF0)
UL_TFC3	(TF0, TF0, TF1)
UL_TFC4	(TF1, TF0, TF1)
UL_TFC5	(TF2, TF1, TF1)

Downlink TFS:

		RAB subflow #1	RAB subflow #2	DCCH
TFS	TF0, bits	1x0	0x84	0x148
	TF1, bits	1x39	1x84	1x148
	TF2, bits	1x75	N/A	N/A

Downlink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, RAB subflow#2, DCCH)</b>
DL_TFC0	(TF0, TF0, TF0)
DL_TFC1	(TF1, TF0, TF0)
DL_TFC2	(TF2, TF1, TF0)
DL_TFC3	(TF0, TF0, TF1)
DL_TFC4	(TF1, TF0, TF1)
DL_TFC5	(TF2, TF1, TF1)

Sub-tests:

<b>Sub-test</b>	<b>Downlink TFCS under test</b>	<b>Uplink TFCS under test</b>	<b>Implicitely tested</b>
1	DL_TFC1	UL_TFC1	DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3
2	DL_TFC2	UL_TFC2	DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5

Initial conditions

UE in idle mode

Test procedure

Sub test 1:

- a) The SS setup the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.6 using the generic procedure for UE radio bearer test mode activation according to clause 14.1.1.
- b) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC3} using the RRC transport format combination control procedure.
- c) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 39 bits for RAB subflow#1 and 84 bits for RAB subflow#2.
- d) The SS transmits an RLC SDU of size 39 bits on RAB subflow#1, using transport format combination DL\_TFC1. No data is transmitted on RAB subflow#2.
- e) The SS checks that the content of the received RLC SDU returned in uplink on RAB subflow#1 has the correct content and is received having the correct transport format. The SS checks that no data is received on RAB subflow#2.
- f) The SS open the UE test loop.

Sub test 2:

- g) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC2, UL\_TFC5} using the RRC transport format combination control procedure.
- h) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 75 bits for RAB subflow#1 and 84 bits for RAB subflow#2.
- i) The SS transmits an RLC SDU of size 75 bits on RAB subflow#1 and an RLC SDU of size 84 bits on RAB subflow#2 using transport format combination DL\_TFC2.
- j) The SS checks that the content of the received RLC SDUs returned in uplink on RAB subflow#1 and RAB subflow#2 have the correct content and are received having the correct transport format.
- k) The SS may optionally open the UE test loop.
- l) The SS may optionally release the radio bearer.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			UE Radio Bearer Test Mode Activation	See generic procedures in clause 14.1.1 Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC3} UE test loop mode 1 is closed using RAB#1: UL RLC SDU size = 39 bits RAB#2: UL RLC SDU size = 84 bits
2	←		TRANSPORT FORMAT COMBINATION CONTROL	
3	←		CLOSE UE TEST LOOP	
4	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	DL_TFC1: RAB#1: 39 bits (TF1=1x39 bits) RAB#2: 0 bits (TF0=0x84 bits) UL_TFC1: RAB#1: 39 bits (TF1=1x39 bits) RAB#2: 0 bits (TF0=0x84 bits)
5	←		DOWNLINK RLC SDU	
6	→		UPLINK RLC SDU	
7	←		OPEN UE TEST LOOP	Transport format combinations is limited to {UL_TFC0, UL_TFC2, UL_TFC5} UE test loop mode 1 is closed using RAB#1: UL RLC SDU size = 75 bits RAB#2: UL RLC SDU size = 84 bits
8	→		OPEN UE TEST LOOP COMPLETE	
9	←		TRANSPORT FORMAT COMBINATION CONTROL	
10	←		CLOSE UE TEST LOOP	TC DL_TFC2: RAB#1: 75 bits (TF2=1x75 bits) RAB#2: 84 bits (TF1=1x84 bits) UL_TFC2: RAB#1: 75 bits (TF2=1x75 bits) RAB#2: 84 bits (TF1=1x84 bits)
11	→		CLOSE UE TEST LOOP COMPLETE	
12	←		DOWNLINK RLC SDU	
13	→		UPLINK RLC SDU	Optional step Optional step Optional step
14	←		OPEN UE TEST LOOP	
15	→		OPEN UE TEST LOOP COMPLETE	
16			RB RELEASE	

#### 14.2.6.4 Test requirements

- At step 1 the UE shall send RADIO BEARER SETUP COMPLETE.
- At step 6 the UE transmitted transport format shall be
  - TF1 (1x39) for RAB subflow#1.
- At step 6 the UE shall return
  - an RLC SDU on RAB subflow#1 with the same content as sent by SS; and
  - no data shall be received on RAB subflow#2.
- At step 13 the UE transmitted transport format shall be
  - TF2 (1x75) for RAB subflow#1; and
  - TF1 (1x84) for RAB subflow#2.
- At step 13 the UE shall return
  - an RLC SDU on RAB subflow#1 with the same content as sent by SS; and
  - an RLC SDU on RAB subflow#2 with the same content as sent by SS.

## 14.2.7 Conversational / speech / UL:7.4 DL:7.4 kbps / CS RAB+ UL:3.4 DL:3.4 kbps SRBs for DCCH

### 14.2.7.1 Conformance requirement

See 14.2.4.1.

### 14.2.7.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.7.

### 14.2.7.3 Method of test

Uplink TFS:

	<b>TFI</b>	<b>RAB subflow #1</b>	<b>RAB subflow #2</b>	<b>DCCH</b>
TFS	TF0, bits	0x61 (alt. 1x0)	0x87	0x148
	TF1, bits	1x39	1x87	1x148
	TF2, bits	1x61	N/A	N/A

Uplink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, RAB subflow#2, DCCH)</b>
UL_TFC0	(TF0, TF0, TF0)
UL_TFC1	(TF1, TF0, TF0)
UL_TFC2	(TF2, TF1, TF0)
UL_TFC3	(TF0, TF0, TF1)
UL_TFC4	(TF1, TF0, TF1)
UL_TFC5	(TF2, TF1, TF1)

Downlink TFS:

		<b>RAB subflow #1</b>	<b>RAB subflow #2</b>	<b>DCCH</b>
TFS	TF0, bits	1x0	0x87	0x148
	TF1, bits	1x39	1x87	1x148
	TF2, bits	1x61	N/A	N/A

Downlink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, RAB subflow#2, DCCH)</b>
DL_TFC0	(TF0, TF0, TF0)
DL_TFC1	(TF1, TF0, TF0)
DL_TFC2	(TF2, TF1, TF0)
DL_TFC3	(TF0, TF0, TF1)
DL_TFC4	(TF1, TF0, TF1)
DL_TFC5	(TF2, TF1, TF1)

Sub-tests:

<b>Sub-test</b>	<b>Downlink TFCS under test</b>	<b>Uplink TFCS under test</b>	<b>Implicitely tested</b>
1	DL_TFC1	UL_TFC1	DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3
2	DL_TFC2	UL_TFC2	DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5

Initial conditions

UE in idle mode

### Test procedure

Sub test 1:

- a) The SS setup the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.7 using the generic procedure for UE radio bearer test mode activation according to clause 14.1.1.
- b) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC3} using the RRC transport format combination control procedure.
- c) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 39 bits for RAB subflow#1 and 87 bits for RAB subflow#2.
- d) The SS transmits an RLC SDU of size 39 bits on RAB subflow#1, using transport format combination DL\_TFC1. No data is transmitted on RAB subflow#2.
- e) The SS checks that the content of the received RLC SDU returned in uplink on RAB subflow#1 has the correct content and is received having the correct transport format. The SS checks that no data is received on RAB subflow#2.
- f) The SS open the UE test loop.

Sub test 2:

- g) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC2, UL\_TFC5} using the RRC transport format combination control procedure.
- h) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 61 bits for RAB subflow#1 and 87 bits for RAB subflow#2.
- i) The SS transmits an RLC SDU of size 61 bits on RAB subflow#1 and an RLC SDU of size 87 bits on RAB subflow#2 using transport format combination DL\_TFC2.
- j) The SS checks that the content of the received RLC SDUs returned in uplink on RAB subflow#1 and RAB subflow#2 have the correct content and are received having the correct transport format.
- k) The SS may optionally open the UE test loop.
- l) The SS may optionally release the radio bearer.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			UE Radio Bearer Test Mode Activation	See generic procedures in clause 14.1.1 Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC3} UE test loop mode 1 is closed using RAB#1: UL RLC SDU size = 39 bits RAB#2: UL RLC SDU size = 87 bits
2	←		TRANSPORT FORMAT COMBINATION CONTROL	
3	←		CLOSE UE TEST LOOP	
4	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	DL_TFC1: RAB#1: 39 bits (TF1=1x39 bits) RAB#2: 0 bits (TF0=0x87 bits) UL_TFC1: RAB#1: 39 bits (TF1=1x39 bits) RAB#2: 0 bits (TF0=0x87 bits)
5	←		DOWNLINK RLC SDU	
6	→		UPLINK RLC SDU	
7	←		OPEN UE TEST LOOP	Transport format combinations is limited to {UL_TFC0, UL_TFC2, UL_TFC5} UE test loop mode 1 is closed using RAB#1: UL RLC SDU size = 61 bits RAB#2: UL RLC SDU size = 87 bits
8	→		OPEN UE TEST LOOP COMPLETE	
9	←		TRANSPORT FORMAT COMBINATION CONTROL	
10	←		CLOSE UE TEST LOOP	TC DL_TFC2: RAB#1: 61 bits (TF2=1x61 bits) RAB#2: 87 bits (TF1=1x87 bits) UL_TFC2: RAB#1: 61 bits (TF2=1x61 bits) RAB#2: 87 bits (TF1=1x87 bits)
11	→		CLOSE UE TEST LOOP COMPLETE	
12	←		DOWNLINK RLC SDU	
13	→		UPLINK RLC SDU	Optional step Optional step Optional step
14	←		OPEN UE TEST LOOP	
15	→		OPEN UE TEST LOOP COMPLETE	
16			RB RELEASE	

#### 14.2.7.4 Test requirements

- At step 1 the UE shall send RADIO BEARER SETUP COMPLETE.
- At step 6 the UE transmitted transport format shall be
  - TF1 (1x39) for RAB subflow#1.
- At step 6 the UE shall return
  - an RLC SDU on RAB subflow#1 with the same content as sent by SS; and
  - no data shall be received on RAB subflow#2.
- At step 13 the UE transmitted transport format shall be
  - TF2 (1x61) for RAB subflow#1; and
  - TF1 (1x87) for RAB subflow#2.
- At step 13 the UE shall return
  - an RLC SDU on RAB subflow#1 with the same content as sent by SS; and
  - an RLC SDU on RAB subflow#2 with the same content as sent by SS.



## 14.2.8 Conversational / speech / UL:6.7 DL:6.7 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

### 14.2.8.1 Conformance requirement

See 14.2.4.1.

### 14.2.8.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.8.

### 14.2.8.3 Method of test

Uplink TFS:

	<b>TFI</b>	<b>RAB subflow #1</b>	<b>RAB subflow #2</b>	<b>DCCH</b>
TFS	TF0, bits	0x58 (alt. 1x0)	0x76	0x148
	TF1, bits	1x39	1x76	1x148
	TF2, bits	1x58	N/A	N/A

Uplink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, RAB subflow#2, DCCH)</b>
UL_TFC0	(TF0, TF0, TF0)
UL_TFC1	(TF1, TF0, TF0)
UL_TFC2	(TF2, TF1, TF0)
UL_TFC3	(TF0, TF0, TF1)
UL_TFC4	(TF1, TF0, TF1)
UL_TFC5	(TF2, TF1, TF1)

Downlink TFS:

		<b>RAB subflow #1</b>	<b>RAB subflow #2</b>	<b>DCCH</b>
TFS	TF0, bits	1x0	0x76	0x148
	TF1, bits	1x39	1x76	1x148
	TF2, bits	1x58	N/A	N/A

Downlink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, RAB subflow#2, DCCH)</b>
DL_TFC0	(TF0, TF0, TF0)
DL_TFC1	(TF1, TF0, TF0)
DL_TFC2	(TF2, TF1, TF0)
DL_TFC3	(TF0, TF0, TF1)
DL_TFC4	(TF1, TF0, TF1)
DL_TFC5	(TF2, TF1, TF1)

Sub-tests:

<b>Sub-test</b>	<b>Downlink TFCS under test</b>	<b>Uplink TFCS under test</b>	<b>Implicitely tested</b>
1	DL_TFC1	UL_TFC1	DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3
2	DL_TFC2	UL_TFC2	DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5

Initial conditions

UE in idle mode

### Test procedure

Sub test 1:

- a) The SS setup the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.8 using the generic procedure for UE radio bearer test mode activation according to clause 14.1.1.
- b) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC3} using the RRC transport format combination control procedure.
- c) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 39 bits for RAB subflow#1 and 76 bits for RAB subflow#2.
- d) The SS transmits an RLC SDU of size 39 bits on RAB subflow#1, using transport format combination DL TFC1. No data is transmitted on RAB subflow#2.
- e) The SS checks that the content of the received RLC SDU returned in uplink on RAB subflow#1 has the correct content and is received having the correct transport format. The SS checks that no data is received on RAB subflow#2.
- f) The SS open the UE test loop.

Sub test 2:

- g) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC2, UL\_TFC5} using the RRC transport format combination control procedure.
- h) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 58 bits for RAB subflow#1 and 76 bits for RAB subflow#2.
- i) The SS transmits an RLC SDU of size 58 bits on RAB subflow#1 and an RLC SDU of size 76 bits on RAB subflow#2 using transport format combination DL\_TFC2.
- j) The SS checks that the content of the received RLC SDUs returned in uplink on RAB subflow#1 and RAB subflow#2 have the correct content and are received having the correct transport format.
- k) The SS may optionally open the UE test loop.
- l) The SS may optionally release the radio bearer.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			UE Radio Bearer Test Mode Activation	See generic procedures in clause 14.1.1 Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC3} UE test loop mode 1 is closed using RAB#1: UL RLC SDU size = 39 bits RAB#2: UL RLC SDU size = 76 bits
2	←		TRANSPORT FORMAT COMBINATION CONTROL	
3	←		CLOSE UE TEST LOOP	
4	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	DL_TFC1: RAB#1: 39 bits (TF1=1x39 bits) RAB#2: 0 bits (TF0=1x76 bits) UL_TFC1: RAB#1: 39 bits (TF1=1x39 bits) RAB#2: 0 bits (TF0=1x76 bits)
5	←		DOWNLINK RLC SDU	
6	→		UPLINK RLC SDU	
7	←		OPEN UE TEST LOOP	Transport format combinations is limited to {UL_TFC0, UL_TFC2, UL_TFC5} UE test loop mode 1 is closed using RAB#1: UL RLC SDU size = 58 bits RAB#2: UL RLC SDU size = 76 bits
8	→		OPEN UE TEST LOOP COMPLETE	
9	←		TRANSPORT FORMAT COMBINATION CONTROL	
10	←		CLOSE UE TEST LOOP	TC DL_TFC2: RAB#1: 58 bits (TF2=1x58 bits) RAB#2: 76 bits (TF1=1x76 bits) UL_TFC2: RAB#1: 58 bits (TF2=1x58 bits) RAB#2: 76 bits (TF1=1x76 bits)
11	→		CLOSE UE TEST LOOP COMPLETE	
12	←		DOWNLINK RLC SDU	
13	→		UPLINK RLC SDU	Optional step Optional step Optional step
14	←		OPEN UE TEST LOOP	
15	→		OPEN UE TEST LOOP COMPLETE	
16			RB RELEASE	

#### 14.2.8.4 Test requirements

- At step 1 the UE shall send RADIO BEARER SETUP COMPLETE.
- At step 6 the UE transmitted transport format shall be
  - TF1 (1x39) for RAB subflow#1.
- At step 6 the UE shall return
  - an RLC SDU on RAB subflow#1 with the same content as sent by SS; and
  - no data shall be received on RAB subflow#2.
- At step 13 the UE transmitted transport format shall be
  - TF2 (1x58) for RAB subflow#1; and
  - TF1 (1x76) for RAB subflow#2.
- At step 13 the UE shall return
  - an RLC SDU on RAB subflow#1 with the same content as sent by SS; and
  - an RLC SDU on RAB subflow#2 with the same content as sent by SS.

## 14.2.9 Conversational / speech / UL:5.9 DL:5.9 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

### 14.2.9.1 Conformance requirement

See 14.2.4.1.

### 14.2.9.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.9.

### 14.2.9.3 Method of test

Uplink TFS:

	<b>TFI</b>	<b>RAB subflow #1</b>	<b>RAB subflow #2</b>	<b>DCCH</b>
TFS	TF0, bits	0x55 (alt. 1x0)	0x63	0x148
	TF1, bits	1x39	1x63	1x148
	TF2, bits	1x55	N/A	N/A

Uplink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, RAB subflow#2, DCCH)</b>
UL_TFC0	(TF0, TF0, TF0)
UL_TFC1	(TF1, TF0, TF0)
UL_TFC2	(TF2, TF1, TF0)
UL_TFC3	(TF0, TF0, TF1)
UL_TFC4	(TF1, TF0, TF1)
UL_TFC5	(TF2, TF1, TF1)

Downlink TFS:

		<b>RAB subflow #1</b>	<b>RAB subflow #2</b>	<b>DCCH</b>
TFS	TF0, bits	1x0	0x63	0x148
	TF1, bits	1x39	1x63	1x148
	TF2, bits	1x55	N/A	N/A

Downlink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, RAB subflow#2, DCCH)</b>
DL_TFC0	(TF0, TF0, TF0)
DL_TFC1	(TF1, TF0, TF0)
DL_TFC2	(TF2, TF1, TF0)
DL_TFC3	(TF0, TF0, TF1)
DL_TFC4	(TF1, TF0, TF1)
DL_TFC5	(TF2, TF1, TF1)

Sub-tests:

<b>Sub-test</b>	<b>Downlink TFCS under test</b>	<b>Uplink TFCS under test</b>	<b>Implicitely tested</b>
1	DL_TFC1	UL_TFC1	DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3
2	DL_TFC2	UL_TFC2	DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5

Initial conditions

UE in idle mode

### Test procedure

Sub test 1:

- a) The SS setup the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.9 using the generic procedure for UE radio bearer test mode activation according to clause 14.1.1.
- b) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC3} using the RRC transport format combination control procedure.
- c) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 39 bits for RAB subflow#1 and 63 bits for RAB subflow#2.
- d) The SS transmits an RLC SDU of size 39 bits on RAB subflow#1, using transport format combination DL\_TFC1. No data is transmitted on RAB subflow#2.
- e) The SS checks that the content of the received RLC SDU returned in uplink on RAB subflow#1 has the correct content and is received having the correct transport format. The SS checks that no data is received on RAB subflow#2.
- f) The SS open the UE test loop.

Sub test 2:

- g) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC2, UL\_TFC5} using the RRC transport format combination control procedure.
- h) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 55 bits for RAB subflow#1 and 63 bits for RAB subflow#2.
- i) The SS transmits an RLC SDU of size 55 bits on RAB subflow#1 and an RLC SDU of size 63 bits on RAB subflow#2 using transport format combination DL\_TFC2.
- j) The SS checks that the content of the received RLC SDUs returned in uplink on RAB subflow#1 and RAB subflow#2 have the correct content and are received having the correct transport format.
- k) The SS may optionally open the UE test loop.
- l) The SS may optionally release the radio bearer.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			UE Radio Bearer Test Mode Activation	See generic procedures in clause 14.1.1 Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC3} UE test loop mode 1 is closed using RAB#1: UL RLC SDU size = 39 bits RAB#2: UL RLC SDU size = 63 bits
2	←		TRANSPORT FORMAT COMBINATION CONTROL	
3	←		CLOSE UE TEST LOOP	
4	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	DL_TFC1: RAB#1: 39 bits (TF1=1x39 bits) RAB#2: 0 bits (TF0=0x63 bits) UL_TFC1: RAB#1: 39 bits (TF1=1x39 bits) RAB#2: 0 bits (TF0=0x63 bits)
5	←		DOWNLINK RLC SDU	
6	→		UPLINK RLC SDU	
7	←		OPEN UE TEST LOOP	Transport format combinations is limited to {UL_TFC0, UL_TFC2, UL_TFC5} UE test loop mode 1 is closed using RAB#1: UL RLC SDU size = 55 bits RAB#2: UL RLC SDU size = 63 bits
8	→		OPEN UE TEST LOOP COMPLETE	
9	←		TRANSPORT FORMAT COMBINATION CONTROL	
10	←		CLOSE UE TEST LOOP	TC DL_TFC2: RAB#1: 55 bits (TF2=1x55 bits) RAB#2: 63 bits (TF1=1x63 bits) UL_TFC2: RAB#1: 55 bits (TF2=1x55 bits) RAB#2: 63 bits (TF1=1x63 bits)
11	→		CLOSE UE TEST LOOP COMPLETE	
12	←		DOWNLINK RLC SDU	
13	→		UPLINK RLC SDU	Optional step Optional step Optional step
14	←		OPEN UE TEST LOOP	
15	→		OPEN UE TEST LOOP COMPLETE	
16			RB RELEASE	

#### 14.2.9.4 Test requirements

- At step 1 the UE shall send RADIO BEARER SETUP COMPLETE.
- At step 6 the UE transmitted transport format shall be
  - TF1 (1x39) for RAB subflow#1.
- At step 6 the UE shall return
  - an RLC SDU on RAB subflow#1 with the same content as sent by SS; and
  - no data shall be received on RAB subflow#2.
- At step 13 the UE transmitted transport format shall be
  - TF2 (1x55) for RAB subflow#1; and
  - TF1 (1x63) for RAB subflow#2.
- At step 13 the UE shall return
  - an RLC SDU on RAB subflow#1 with the same content as sent by SS; and
  - an RLC SDU on RAB subflow#2 with the same content as sent by SS.

## 14.2.10 Conversational / speech / UL:5.15 DL:5.15 kbps / CS RAB + UL:1.7 DL:1.7 kbps SRBs for DCCH

### 14.2.10.1 Conformance requirement

See 14.2.4.1.

### 14.2.10.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.10.

### 14.2.10.3 Method of test

Uplink TFS:

	<b>TFI</b>	<b>RAB subflow #1</b>	<b>RAB subflow #2</b>	<b>DCCH</b>
TFS	TF0, bits	0x49 (alt. 1x0)	0x54	0x148
	TF1, bits	1x39	1x54	1x148
	TF2, bits	1x49	N/A	N/A

Uplink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, RAB subflow#2, DCCH)</b>
UL_TFC0	(TF0, TF0, TF0)
UL_TFC1	(TF1, TF0, TF0)
UL_TFC2	(TF2, TF1, TF0)
UL_TFC3	(TF0, TF0, TF1)
UL_TFC4	(TF1, TF0, TF1)
UL_TFC5	(TF2, TF1, TF1)

Downlink TFS:

		<b>RAB subflow #1</b>	<b>RAB subflow #2</b>	<b>DCCH</b>
TFS	TF0, bits	1x0	0x54	0x148
	TF1, bits	1x39	1x54	1x148
	TF2, bits	1x49	N/A	N/A

Downlink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, RAB subflow#2, DCCH)</b>
DL_TFC0	(TF0, TF0, TF0)
DL_TFC1	(TF1, TF0, TF0)
DL_TFC2	(TF2, TF1, TF0)
DL_TFC3	(TF0, TF0, TF1)
DL_TFC4	(TF1, TF0, TF1)
DL_TFC5	(TF2, TF1, TF1)

Sub-tests:

<b>Sub-test</b>	<b>Downlink TFCS under test</b>	<b>Uplink TFCS under test</b>	<b>Implicitely tested</b>
1	DL_TFC1	UL_TFC1	DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3
2	DL_TFC2	UL_TFC2	DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5

Initial conditions

UE in idle mode

### Test procedure

Sub test 1:

- a) The SS setup the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.10 using the generic procedure for UE radio bearer test mode activation according to clause 14.1.1.
- b) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC3} using the RRC transport format combination control procedure.
- c) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 39 bits for RAB subflow#1 and 54 bits for RAB subflow#2.
- d) The SS transmits an RLC SDU of size 39 bits on RAB subflow#1, using transport format combination DL\_TFC1. No data is transmitted on RAB subflow#2.
- e) The SS checks that the content of the received RLC SDU returned in uplink on RAB subflow#1 has the correct content and is received having the correct transport format. The SS checks that no data is received on RAB subflow#2.
- f) The SS open the UE test loop.

Sub test 2:

- g) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC2, UL\_TFC5} using the RRC transport format combination control procedure.
- h) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 49 bits for RAB subflow#1 and 54 bits for RAB subflow#2.
- i) The SS transmits an RLC SDU of size 49 bits on RAB subflow#1 and an RLC SDU of size 54 bits on RAB subflow#2 using transport format combination DL\_TFC2.
- j) The SS checks that the content of the received RLC SDUs returned in uplink on RAB subflow#1 and RAB subflow#2 have the correct content and are received having the correct transport format.
- k) The SS may optionally open the UE test loop.
- l) The SS may optionally release the radio bearer.



Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			UE Radio Bearer Test Mode Activation	See generic procedures in clause 14.1.1 Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC3} UE test loop mode 1 is closed using RAB#1: UL RLC SDU size = 39 bits RAB#2: UL RLC SDU size = 54 bits
2	←		TRANSPORT FORMAT COMBINATION CONTROL	
3	←		CLOSE UE TEST LOOP	
4	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	DL_TFC1: RAB#1: 39 bits (TF1=1x39 bits) RAB#2: 0 bits (TF0=0x54 bits) UL_TFC1: RAB#1: 39 bits (TF1=1x39 bits) RAB#2: 0 bits (TF0=0x54 bits)
5	←		DOWNLINK RLC SDU	
6	→		UPLINK RLC SDU	
7	←		OPEN UE TEST LOOP	Transport format combinations is limited to {UL_TFC0, UL_TFC2, UL_TFC5} UE test loop mode 1 is closed using RAB#1: UL RLC SDU size = 49 bits RAB#2: UL RLC SDU size = 54 bits
8	→		OPEN UE TEST LOOP COMPLETE	
9	←		TRANSPORT FORMAT COMBINATION CONTROL	
10	←		CLOSE UE TEST LOOP	TC DL_TFC2: RAB#1: 49 bits (TF2=1x49 bits) RAB#2: 54 bits (TF1=1x54 bits) UL_TFC2: RAB#1: 49 bits (TF2=1x49 bits) RAB#2: 54 bits (TF1=1x54 bits)
11	→		CLOSE UE TEST LOOP COMPLETE	
12	←		DOWNLINK RLC SDU	
13	→		UPLINK RLC SDU	Optional step Optional step Optional step
14	←		OPEN UE TEST LOOP	
15	→		OPEN UE TEST LOOP COMPLETE	
16			RB RELEASE	

#### 14.2.10.4 Test requirements

- At step 1 the UE shall send RADIO BEARER SETUP COMPLETE.
- At step 6 the UE transmitted transport format shall be
  - TF1 (1x39) for RAB subflow#1.
- At step 6 the UE shall return
  - an RLC SDU on RAB subflow#1 with the same content as sent by SS; and
  - no data shall be received on RAB subflow#2.
- At step 13 the UE transmitted transport format shall be
  - TF2 (1x49) for RAB subflow#1; and
  - TF1 (1x54) for RAB subflow#2.
- At step 13 the UE shall return
  - an RLC SDU on RAB subflow#1 with the same content as sent by SS; and
  - an RLC SDU on RAB subflow#2 with the same content as sent by SS.

## 14.2.11 Conversational / speech / UL:4.75 DL:4.75 kbps / CS RAB + UL:1.7 DL:1.7 kbps SRBs for DCCH

### 14.2.11.1 Conformance requirement

See 14.2.4.1.

### 14.2.11.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.11.

### 14.2.11.3 Method of test

Uplink TFS:

	<b>TFI</b>	<b>RAB subflow #1</b>	<b>RAB subflow #2</b>	<b>DCCH</b>
TFS	TF0, bits	0x49 (alt. 1x0)	0x53	0x148
	TF1, bits	1x39	1x53	1x148
	TF2, bits	1x42	N/A	N/A

Uplink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, RAB subflow#2, DCCH)</b>
UL_TFC0	(TF0, TF0, TF0)
UL_TFC1	(TF1, TF0, TF0)
UL_TFC2	(TF2, TF1, TF0)
UL_TFC3	(TF0, TF0, TF1)
UL_TFC4	(TF1, TF0, TF1)
UL_TFC5	(TF2, TF1, TF1)

Downlink TFS:

		<b>RAB subflow #1</b>	<b>RAB subflow #2</b>	<b>DCCH</b>
TFS	TF0, bits	1x0	0x53	0x148
	TF1, bits	1x39	1x53	1x148
	TF2, bits	1x42	N/A	N/A

Downlink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, RAB subflow#2, DCCH)</b>
DL_TFC0	(TF0, TF0, TF0)
DL_TFC1	(TF1, TF0, TF0)
DL_TFC2	(TF2, TF1, TF0)
DL_TFC3	(TF0, TF0, TF1)
DL_TFC4	(TF1, TF0, TF1)
DL_TFC5	(TF2, TF1, TF1)

Sub-tests:

<b>Sub-test</b>	<b>Downlink TFCS under test</b>	<b>Uplink TFCS under test</b>	<b>Implicitely tested</b>
1	DL_TFC1	UL_TFC1	DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3
2	DL_TFC2	UL_TFC2	DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5

Initial conditions

UE in idle mode

## Test procedure

Sub test 1:

- a) The SS setup the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.11 using the generic procedure for UE radio bearer test mode activation according to clause 14.1.1.
- b) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC3} using the RRC transport format combination control procedure.
- c) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 39 bits for RAB subflow#1 and 53 bits for RAB subflow#2.
- d) The SS transmits an RLC SDU of size 39 bits on RAB subflow#1, using transport format combination DL\_TFC1. No data is transmitted on RAB subflow#2.
- e) The SS checks that the content of the received RLC SDU returned in uplink on RAB subflow#1 has the correct content and is received having the correct transport format. The SS checks that no data is received on RAB subflow#2.
- f) The SS open the UE test loop.

Sub test 2:

- g) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC2, UL\_TFC5} using the RRC transport format combination control procedure.
- h) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 42 bits for RAB subflow#1 and 53 bits for RAB subflow#2.
- i) The SS transmits an RLC SDU of size 42 bits on RAB subflow#1 and an RLC SDU of size 53 bits on RAB subflow#2 using transport format combination DL\_TFC2.
- j) The SS checks that the content of the received RLC SDUs returned in uplink on RAB subflow#1 and RAB subflow#2 have the correct content and are received having the correct transport format.
- k) The SS may optionally open the UE test loop.
- l) The SS may optionally release the radio bearer.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			UE Radio Bearer Test Mode Activation	See generic procedures in clause 14.1.1 Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC3} UE test loop mode 1 is closed using RAB#1: UL RLC SDU size = 39 bits RAB#2: UL RLC SDU size = 53 bits
2	←		TRANSPORT FORMAT COMBINATION CONTROL	
3	←		CLOSE UE TEST LOOP	
4	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	DL_TFC1: RAB#1: 39 bits (TF1=1x39 bits) RAB#2: 0 bits (TF0= 0x53 bits) UL_TFC1: RAB#1: 39 bits (TF1=1x39 bits) RAB#2: 0 bits (TF0= 0x53 bits)
5	←		DOWNLINK RLC SDU	
6	→		UPLINK RLC SDU	
7	←		OPEN UE TEST LOOP	Transport format combinations is limited to {UL_TFC0, UL_TFC2, UL_TFC5} UE test loop mode 1 is closed using RAB#1: UL RLC SDU size = 42 bits RAB#2: UL RLC SDU size = 53 bits
8	→		OPEN UE TEST LOOP COMPLETE	
9	←		TRANSPORT FORMAT COMBINATION CONTROL	
10	←		CLOSE UE TEST LOOP	TC DL_TFC2: RAB#1: 42 bits (TF2=1x42 bits) RAB#2: 53 bits (TF1=1x53 bits) UL_TFC2: RAB#1: 42 bits (TF2=1x42 bits) RAB#2: 53 bits (TF1=1x53 bits)
11	→		CLOSE UE TEST LOOP COMPLETE	
12	←		DOWNLINK RLC SDU	
13	→		UPLINK RLC SDU	Optional step Optional step Optional step
14	←		OPEN UE TEST LOOP	
15	→		OPEN UE TEST LOOP COMPLETE	
16			RB RELEASE	

#### 14.2.11.4 Test requirements

- At step 1 the UE shall send RADIO BEARER SETUP COMPLETE.
- At step 6 the UE transmitted transport format shall be
  - TF1 (1x39) for RAB subflow#1.
- At step 6 the UE shall return
  - an RLC SDU on RAB subflow#1 with the same content as sent by SS; and
  - no data shall be received on RAB subflow#2.
- At step 13 the UE transmitted transport format shall be
  - TF2 (1x42) for RAB subflow#1; and
  - TF1 (1x53) for RAB subflow#2.
- At step 13 the UE shall return
  - an RLC SDU on RAB subflow#1 with the same content as sent by SS; and
  - an RLC SDU on RAB subflow#2 with the same content as sent by SS.

## 14.2.12 Conversational / unknown / UL:28.8 DL:28.8 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

### 14.2.12.1 Conformance requirement

See 14.2.4.1.

### 14.2.12.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.12.

### 14.2.13.3 Method of test

Uplink TFS:

	<b>TFI</b>	<b>RAB subflow #1</b>	<b>DCCH</b>
TFS	TF0, bits	0x576	0x148
	TF1, bits	1x576	1x148
	TF2, bits	2x576	N/A

Uplink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, DCCH)</b>
UL_TFC0	(TF0, TF0)
UL_TFC1	(TF1, TF0)
UL_TFC2	(TF2, TF0)
UL_TFC3	(TF0, TF1)
UL_TFC4	(TF1, TF1)
UL_TFC5	(TF2, TF1)

Downlink TFS:

		<b>RAB subflow #1</b>	<b>DCCH</b>
TFS	TF0, bits	0x576	0x148
	TF1, bits	1x576	1x148
	TF2, bits	2x576	N/A

Downlink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, DCCH)</b>
DL_TFC0	(TF0, TF0)
DL_TFC1	(TF1, TF0)
DL_TFC2	(TF2, TF0)
DL_TFC3	(TF0, TF1)
DL_TFC4	(TF1, TF1)
DL_TFC5	(TF2, TF1)

Sub-tests:

<b>Sub-test</b>	<b>Downlink TFCS under test</b>	<b>Uplink TFCS under test</b>	<b>Implicitely tested</b>
1	DL_TFC1	UL_TFC1	DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3
2	DL_TFC2	UL_TFC2	DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5

Initial conditions

UE in idle mode

### Test procedure

Sub test 1:

- a) The SS setup the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.12 using the generic procedure for UE radio bearer test mode activation according to clause 14.1.1.
- b) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC3} using the RRC transport format combination control procedure.
- c) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 576 bits for RAB subflow#1.
- d) The SS transmits an RLC SDU of size 576 bits on RAB subflow#1, using transport format combination DL\_TFC1.
- e) The SS checks that the content of the received RLC SDU returned in uplink on RAB subflow#1 has the correct content and is received having the correct transport format. f) The SS open the UE test loop.

Sub test 2:

- g) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC2, UL\_TFC5} using the RRC transport format combination control procedure.
- h) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 1152 bits for RAB subflow#1.
- i) The SS transmits an RLC SDU of size 1152 bits on RAB subflow#1 using transport format combination DL\_TFC2.
- j) The SS checks that the content of the received RLC SDU returned in uplink on RAB subflow#1 has the correct content and are received having the correct transport format.
- k) The SS may optionally open the UE test loop.
- l) The SS may optionally release the radio bearer.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			UE Radio Bearer Test Mode Activation	See generic procedures in clause 14.1.1 Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC3} UE test loop mode 1 is closed using UL RLC SDU size = 576 bits
2	←		TRANSPORT FORMAT COMBINATION CONTROL	
3	←		CLOSE UE TEST LOOP	
4	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	DL_TFC1: 576 bits (TF1=1x576 bits) UL_TFC1: 576 bits (TF1=1x576 bits)
5	←		DOWNLINK RLC SDU	
6	→		UPLINK RLC SDU	
7	←		OPEN UE TEST LOOP	Transport format combinations is limited to {UL_TFC0, UL_TFC2, UL_TFC5} UE test loop mode 1 is closed using UL RLC SDU size = 1152 bits
8	→		OPEN UE TEST LOOP COMPLETE	
9	←		TRANSPORT FORMAT COMBINATION CONTROL	
10	←		CLOSE UE TEST LOOP	TC DL_TFC2: 1152 bits (TF2=2x576 bits) UL_TFC2: 1152 bits (TF2=2x576 bits)
11	→		CLOSE UE TEST LOOP COMPLETE	
12	←		DOWNLINK RLC SDU	
13	→		UPLINK RLC SDU	Optional step Optional step Optional step
14	←		OPEN UE TEST LOOP	
15	→		OPEN UE TEST LOOP COMPLETE	
16			RB RELEASE	

#### 14.2.12.4 Test requirements

1. At step 1 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 6 the UE transmitted transport format on RAB subflow#1 shall be TF1 (1x576).
3. At step 6 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.
4. At step 13 the UE transmitted transport format on RAB subflow#1 shall be TF2 (2x576).
5. At step 13 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.

### 14.2.13 Conversational / unknown / UL:64 DL:64 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

#### 14.2.13.1 Conversational / unknown / UL:64 DL:64 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 20 ms TTI

##### 14.2.13.1.1 Conformance requirement

See 14.2.4.1.

##### 14.2.13.1.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.13 for the 20 ms TTI case.

##### 14.2.13.1.3 Method of test

Uplink TFS:

	<b>TFI</b>	<b>RAB subflow #1</b>	<b>DCCH</b>
TFS	TF0, bits	0x640	0x148
	TF1, bits	2x640	1x148

Uplink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, DCCH)</b>
UL_TFC0	(TF0, TF0)
UL_TFC1	(TF1, TF0)
UL_TFC2	(TF0, TF1)
UL_TFC3	(TF1, TF1)

Downlink TFS:

	<b>TFI</b>	<b>RAB subflow #1</b>	<b>DCCH</b>
TFS	TF0, bits	0x640	0x148
	TF1, bits	2x640	1x148

Downlink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, DCCH)</b>
DL_TFC0	(TF0, TF0)
DL_TFC1	(TF1, TF0)
DL_TFC2	(TF0, TF1)
DL_TFC3	(TF1, TF1)

Sub-tests:

<b>Sub-test</b>	<b>Downlink TFCS Under test</b>	<b>Uplink TFCS under test</b>	<b>Implicitely tested</b>
1	DL_TFC1	UL_TFC1	DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC2

Initial conditions

UE in idle mode

Test procedure

- The SS setup the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.13 for the 20 ms TTI case using the generic procedure for UE radio bearer test mode activation according to clause 14.1.1.
- The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 1280 bits for RAB subflow#1.
- The SS transmits an RLC SDU of size 1280 bits on RAB subflow#1 using transport format combination DL\_TFC1
- The SS checks that the content of the received RLC SDUs returned in uplink on RAB subflow#1 and has the correct content and is received having the correct transport format.
- The SS may optionally open the UE test loop.
- The SS may optionally release the radio bearer.



Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			UE Radio Bearer Test Mode Activation	See generic procedures in clause 14.1.1 UE test loop mode 1 is closed using UL RLC SDU size = 1280 bits
2	←		CLOSE UE TEST LOOP	
3	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	
4	←		DOWNLINK RLC SDU	DL_TFC1: 1280 bits (TF1=2x640 bits) UL_TFC1: 1280 bits (TF1=2x640 bits)
5	→		UPLINK RLC SDU	
6	←		OPEN UE TEST LOOP	
7	→		OPEN UE TEST LOOP COMPLETE	Optional step
8			RB RELEASE	Optional step

#### 14.2.13.1.4 Test requirements

- At step 1 the UE shall send RADIO BEARER SETUP COMPLETE.
- At step 5 the UE transmitted transport format on RAB subflow#1 shall be TF1 (2x640).
- At step 5 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.

#### 14.2.13.2 Conversational / unknown / UL:64 DL:64 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 40 ms TTI

##### 14.2.13.2.1 Conformance requirement

See 14.2.4.1.

##### 14.2.13.2.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.13 for the 40 ms TTI case.

##### 14.2.13.2.3 Method of test

Uplink TFS:

	TFI	RAB subflow #1	DCCH
TFS	TF0, bits	0x640	0x148
	TF1, bits	4x640	1x148

Uplink TFCS:

TFCI	(RAB subflow#1, DCCH)
UL_TFC0	(TF0, TF0)
UL_TFC1	(TF1, TF0)
UL_TFC2	(TF0, TF1)
UL_TFC3	(TF1, TF1)

Downlink TFS:

	TFI	RAB subflow #1	DCCH
TFS	TF0, bits	0x640	0x148
	TF1, bits	4x640	1x148

Downlink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, DCCH)</b>
DL_TFC0	(TF0, TF0)
DL_TFC1	(TF1, TF0)
DL_TFC2	(TF0, TF1)
DL_TFC3	(TF1, TF1)

Sub-tests:

<b>Sub-test</b>	<b>Downlink TFCS Under test</b>	<b>Uplink TFCS under test</b>	<b>Implicitely tested</b>
1	DL_TFC1	UL_TFC1	DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC2

Initial conditions

UE in idle mode

Test procedure

- The SS setup the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.13 for the 40 ms TTI case using the generic procedure for UE radio bearer test mode activation according to clause 14.1.1.
- The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 2560 bits for RAB subflow#1.
- The SS transmits an RLC SDU of size 2560 bits on RAB subflow#1 using transport format combination DL\_TFC1
- The SS checks that the content of the received RLC SDUs returned in uplink on RAB subflow#1 and has the correct content and is received having the correct transport format.
- The SS may optionally open the UE test loop.
- The SS may optionally release the radio bearer.

Expected sequence

<b>Step</b>	<b>Direction</b>		<b>Message</b>	<b>Comments</b>
	<b>UE</b>	<b>SS</b>		
1			UE Radio Bearer Test Mode Activation	See generic procedures in clause 14.1.1 UE test loop mode 1 is closed using UL RLC SDU size = 2560 bits
2	←		CLOSE UE TEST LOOP	
3	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	DL_TFC1: 2560 bits (TF1=4x640 bits) UL_TFC1: 2560 bits (TF1=4x640 bits)
4	←		DOWNLINK RLC SDU	
5	→		UPLINK RLC SDU	
6	←		OPEN UE TEST LOOP	
7	→		OPEN UE TEST LOOP COMPLETE	Optional step
8			RB RELEASE	Optional step

#### 14.2.13.2.4 Test requirements

- At step 1 the UE shall send RADIO BEARER SETUP COMPLETE.
- At step 5 the UE transmitted transport format on RAB subflow#1 shall be TF1 (4x640).
- At step 5 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.

## 14.2.14 Conversational / unknown / UL:32 DL:32 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

### 14.2.14.1 Conversational / unknown / UL:32 DL:32 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 20 ms TTI

#### 14.2.14.1.1 Conformance requirement

See 14.2.4.1.

#### 14.2.14.1.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.14 for the 20 ms TTI case.

#### 14.2.14.1.3 Method of test

Uplink TFS:

	<b>TFI</b>	<b>RAB subflow #1</b>	<b>DCCH</b>
TFS	TF0, bits	0x640	0x148
	TF1, bits	1x640	1x148

Uplink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, DCCH)</b>
UL_TFC0	(TF0, TF0)
UL_TFC1	(TF1, TF0)
UL_TFC2	(TF0, TF1)
UL_TFC3	(TF1, TF1)

Downlink TFS:

	<b>TFI</b>	<b>RAB subflow #1</b>	<b>DCCH</b>
TFS	TF0, bits	0x640	0x148
	TF1, bits	1x640	1x148

Downlink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, DCCH)</b>
DL_TFC0	(TF0, TF0)
DL_TFC1	(TF1, TF0)
DL_TFC2	(TF0, TF1)
DL_TFC3	(TF1, TF1)

Sub-tests:

<b>Sub-test</b>	<b>Downlink TFCS Under test</b>	<b>Uplink TFCS under test</b>	<b>Implicitely tested</b>
1	DL_TFC1	UL_TFC1	DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC2

Initial conditions

UE in idle mode

Test procedure

- a) The SS setup the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.14 for the 20 ms TTI case using the generic procedure for UE radio bearer test mode activation according to clause 14.1.1.
- b) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 640 bits for RAB subflow#1.
- c) The SS transmits an RLC SDU of size 640 bits using transport format combination DL\_TFC1.
- d) The SS checks that the content of the received RLC SDUs returned in uplink on RAB subflow#1 and has the correct content and is received having the correct transport format.
- e) The SS may optionally open the UE test loop.
- f) The SS may optionally release the radio bearer.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			UE Radio Bearer Test Mode Activation	See generic procedures in clause 14.1.1 UE test loop mode 1 is closed using UL RLC SDU size = 640 bits
2	←		CLOSE UE TEST LOOP	
3	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	
4	←		DOWNLINK RLC SDU	DL_TFC1: 640 bits (TF1=1x640 bits) UL_TFC1: 640 bits (TF1=1x640 bits)
5	→		UPLINK RLC SDU	
6	←		OPEN UE TEST LOOP	
7	→		OPEN UE TEST LOOP COMPLETE	
8			RB RELEASE	Optional step

#### 14.2.14.1.4 Test requirements

1. At step 1 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 5 the UE transmitted transport format on RAB subflow#1 shall be TF1 (1x640).
3. At step 5 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.

#### 14.2.14.2 Conversational / unknown / UL:32 DL:32 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 40 ms TTI

##### 14.2.14.2.1 Conformance requirement

See 14.2.4.1.

##### 14.2.14.2.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.14 for the 40 ms TTI case.

##### 14.2.14.2.3 Method of test

Uplink TFS:

	<b>TFI</b>	<b>RAB subflow #1</b>	<b>DCCH</b>
TFS	TF0, bits	0x640	0x148
	TF1, bits	2x640	1x148

Uplink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, DCCH)</b>
UL_TFC0	(TF0, TF0)
UL_TFC1	(TF1, TF0)
UL_TFC2	(TF0, TF1)
UL_TFC3	(TF1, TF1)

Downlink TFS:

	<b>TFI</b>	<b>RAB subflow #1</b>	<b>DCCH</b>
TFS	TF0, bits	0x640	0x148
	TF1, bits	2x640	1x148

Downlink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, DCCH)</b>
DL_TFC0	(TF0, TF0)
DL_TFC1	(TF1, TF0)
DL_TFC2	(TF0, TF1)
DL_TFC3	(TF1, TF1)

Sub-tests:

<b>Sub-test</b>	<b>Downlink TFCS Under test</b>	<b>Uplink TFCS under test</b>	<b>Implicitely tested</b>
1	DL_TFC1	UL_TFC1	DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC2

Initial conditions

UE in idle mode

Test procedure

- The SS setup the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.14 for the 40 ms TTI case using the generic procedure for UE radio bearer test mode activation according to clause 14.1.1.
- The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 1280 bits for RAB subflow#1.
- The SS transmits an RLC SDU of size 1280 bits using transport format combination DL\_TFC1.
- The SS checks that the content of the received RLC SDUs returned in uplink on RAB subflow#1 and has the correct content and is received having the correct transport format.
- The SS may optionally open the UE test loop.
- The SS may optionally release the radio bearer.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			UE Radio Bearer Test Mode Activation	See generic procedures in clause 14.1.1 UE test loop mode 1 is closed using UL RLC SDU size = 1280 bits
2	←		CLOSE UE TEST LOOP	
3	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	
4	←		DOWNLINK RLC SDU	DL_TFC1: 1280 bits (TF1=2x640 bits) UL_TFC1: 1280 bits (TF1=2x640 bits)
5	→		UPLINK RLC SDU	
6	←		OPEN UE TEST LOOP	
7	→		OPEN UE TEST LOOP COMPLETE	Optional step
8			RB RELEASE	Optional step

#### 14.2.14.2.4 Test requirements

1. At step 1 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 5 the UE transmitted transport format on RAB subflow#1 shall be TF1 (2x640).
3. At step 5 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.

### 14.2.15 Streaming / unknown / UL:14.4/DL:14.4 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

#### 14.2.15.1 Conformance requirement

See 14.2.4.1.

#### 14.2.15.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.15.

#### 14.2.15.3 Method of test

Uplink TFS:

	TFI	RAB subflow #1	DCCH
TFS	TF0, bits	0x576	0x148
	TF1, bits	1x576	1x148

Uplink TFCS:

TFCI	(RAB subflow#1, DCCH)
UL_TFC0	(TF0, TF0)
UL_TFC1	(TF1, TF0)
UL_TFC2	(TF0, TF1)
UL_TFC3	(TF1, TF1)

Downlink TFS:

	<b>TFI</b>	<b>RAB subflow #1</b>	<b>DCCH</b>
TFS	TF0, bits	0x576	0x148
	TF1, bits	1x576	1x148

Downlink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, DCCH)</b>
DL_TFC0	(TF0, TF0)
DL_TFC1	(TF1, TF0)
DL_TFC2	(TF0, TF1)
DL_TFC3	(TF1, TF1)

Sub-tests:

<b>Sub-test</b>	<b>Downlink TFCS Under test</b>	<b>Uplink TFCS under test</b>	<b>Implicitely tested</b>
1	DL_TFC1	UL_TFC1	DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC2

Initial conditions

UE in idle mode

Test procedure

- The SS setup the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.15 using the generic procedure for UE radio bearer test mode activation according to clause 14.1.1.
- The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 576 bits for RAB subflow#1.
- The SS transmits an RLC SDU of size 576 bits using transport format combination DL\_TFC1.
- The SS checks that the content of the received RLC SDU returned in uplink on RAB subflow#1 has correct content and is received having the correct transport format.
- The SS may optionally open the UE test loop.
- The SS may optionally release the radio bearer.

Expected sequence

<b>Step</b>	<b>Direction</b>		<b>Message</b>	<b>Comments</b>
	<b>UE</b>	<b>SS</b>		
1			UE Radio Bearer Test Mode Activation	See generic procedures in clause 14.1.1 UE test loop mode 1 is closed using UL RLC SDU size = 576 bits
2	←		CLOSE UE TEST LOOP	
3		→	CLOSE UE TEST LOOP COMPLETE (DCCH)	DL_TFC1: 576 bits (TF1=1x576) UL_TFC1: 576 bits (TF1=1x576)
4	←		DOWNLINK RLC SDU	
5		→	UPLINK RLC SDU	
6	←		OPEN UE TEST LOOP	
7		→	OPEN UE TEST LOOP COMPLETE	Optional step
8			RB RELEASE	Optional step

#### 14.2.15.4 Test requirements

- At step 1 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 5 the UE transmitted transport format on RAB subflow#1 shall be TF1 (1x576).
3. At step 5 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.

### 14.2.16 Streaming / unknown / UL:28.8/DL:28.8 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

See test case 14.2.12.

### 14.2.17 Streaming / unknown / UL:57.6/DL:57.6 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

#### 14.2.17.1 Conformance requirement

See 14.2.4.1.

#### 14.2.17.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.17.

#### 14.2.17.3 Method of test

Uplink TFS:

	TFI	RAB subflow #1	DCCH
TFS	TF0, bits	0x576	0x148
	TF1, bits	1x576	0x148
	TF2, bits	2x576	N/A
	TF3, bits	3x576	N/A
	TF4, bits	4x576	N/A

Uplink TFCS:

TFCI	(RAB subflow#1, DCCH)
UL_TFC0	(TF0, TF0)
UL_TFC1	(TF1, TF0)
UL_TFC2	(TF2, TF0)
UL_TFC3	(TF3, TF0)
UL_TFC4	(TF4, TF0)
UL_TFC5	(TF0, TF1)
UL_TFC6	(TF1, TF1)
UL_TFC7	(TF2, TF1)
UL_TFC8	(TF3, TF1)
UL_TFC9	(TF4, TF1)

Downlink TFS:

	TFI	RAB subflow #1	DCCH
TFS	TF0, bits	0x576	0x148
	TF1, bits	1x576	0x148
	TF2, bits	2x576	N/A
	TF3, bits	3x576	N/A
	TF4, bits	4x576	N/A

Downlink TFCS:



<b>TFCI</b>	<b>(RAB subflow#1, DCCH)</b>
DL_TFC0	(TF0, TF0)
DL_TFC1	(TF1, TF0)
DL_TFC2	(TF2, TF0)
DL_TFC3	(TF3, TF0)
DL_TFC4	(TF4, TF0)
DL_TFC5	(TF0, TF1)
DL_TFC6	(TF1, TF1)
DL_TFC7	(TF2, TF1)
DL_TFC8	(TF3, TF1)
DL_TFC9	(TF4, TF1)

Sub-tests:

<b>Sub-test</b>	<b>Downlink TFCS Under test</b>	<b>Uplink TFCS under test</b>	<b>Implicitely tested</b>
1	DL_TFC1	UL_TFC1	DL_TFC0, DL_TFC5, DL_TFC6, UL_TFC0, UL_TFC5, UL_TFC6
2	DL_TFC2	UL_TFC2	DL_TFC0, DL_TFC5, DL_TFC7, UL_TFC0, UL_TFC5, UL_TFC7
3	DL_TFC3	UL_TFC3	DL_TFC0, DL_TFC5, DL_TFC8, UL_TFC0, UL_TFC5, UL_TFC8
4	DL_TFC4	UL_TFC4	DL_TFC0, DL_TFC5, DL_TFC9, UL_TFC0, UL_TFC5, UL_TFC9

Initial conditions

UE in idle mode

Test procedure

Sub-test 1:

- The SS setup the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.17 using the generic procedure for UE radio bearer test mode activation according to clause 14.1.1.
- The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC5, UL\_TFC6} for RAB subflow#1 using the RRC transport format combination control procedure.
- The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 576 bits for RAB subflow#1.
- The SS transmits an RLC SDU of size 576 bits using transport format combination DL\_TFC1 (1x576).
- The SS checks that the content of the received RLC SDU returned in uplink on RAB subflow#1 has correct content and is received having the correct transport format.
- The SS open the UE test loop.

Sub-test 2:

- The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC2, UL\_TFC5, UL\_TFC7} for RAB subflow#1 using the RRC transport format combination control procedure.
- The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 1152 bits for RAB subflow#1.
- The SS transmits an RLC SDU of size 1152 bits using transport format combination DL\_TFC2 (2x576).
- The SS checks that the content of the received RLC SDU returned in uplink on RAB subflow#1 has correct content and is received having the correct transport format.

k) The SS open the UE test loop.

Sub-test 3:

- l) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC3, UL\_TFC5, UL\_TFC8} for RAB subflow#1 using the RRC transport format combination control procedure.
- m) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 1728 bits for RAB subflow#1.
- n) The SS transmits an RLC SDU of size 1728 bits using transport format combination DL\_TFC3 (3x576).
- o) The SS checks that the content of the received RLC SDU returned in uplink on RAB subflow#1 has correct content and is received having the correct transport format.
- p) The SS open the UE test loop.
- q) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC4, UL\_TFC5, UL\_TFC9} for RAB subflow#1 using the RRC transport format combination control procedure.
- r) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 2304 bits for RAB subflow#1.
- s) The SS transmits an RLC SDU of size 2304 bits using transport format combination DL\_TFC4 (4x576).
- t) The SS checks that the content of the received RLC SDU returned in uplink on RAB subflow#1 has correct content and is received having the correct transport format.
- u) The SS may optionally open the UE test loop.
- v) The SS may optionally release the radio bearer.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			UE Radio Bearer Test Mode Activation	See generic procedures in clause 14.1.1
2	←		TRANSPORT FORMAT COMBINATION CONTROL	Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC5, UL_TFC6}
3	←		CLOSE UE TEST LOOP	UE test loop mode 1 is closed using UL RLC SDU size = 576 bits
4	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	
5	←		DOWNLINK RLC SDU	DL_TFC1: 576 bits (TF1=1x576 bits)
6	→		UPLINK RLC SDU	UL_TFC1: 576 bits (TF1=1x576 bits)
7	←		OPEN UE TEST LOOP	
8	→		OPEN UE TEST LOOP COMPLETE	
9	←		TRANSPORT FORMAT COMBINATION CONTROL	Transport format combinations is limited to {UL_TFC0, UL_TFC2, UL_TFC5, UL_TFC7}
10	←		CLOSE UE TEST LOOP	UE test loop mode 1 is closed using UL RLC SDU size = 1152 bits
11	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	
12	←		DOWNLINK RLC SDU	DL_TFC2: 1152 bits (TF2=2x576 bits)
13	→		UPLINK RLC SDU	UL_TFC2: 1152 bits (TF2=2x576 bits)
14	←		OPEN UE TEST LOOP	
15	→		OPEN UE TEST LOOP COMPLETE	
16	←		TRANSPORT FORMAT COMBINATION CONTROL	Transport format combinations is limited to {UL_TFC0, UL_TFC3, UL_TFC5, UL_TFC8}
17	←		CLOSE UE TEST LOOP	UE test loop mode 1 is closed using UL RLC SDU size = 1728 bits
18	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	
19	←		DOWNLINK RLC SDU	DL_TFC3: 1728 bits (TF3=3x576 bits)
20	→		UPLINK RLC SDU	UL_TFC3: 1728 bits (TF3=3x576 bits)
21	←		OPEN UE TEST LOOP	
22	→		OPEN UE TEST LOOP COMPLETE	
23	←		TRANSPORT FORMAT COMBINATION CONTROL	Transport format combinations is limited to {UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9}
24	←		CLOSE UE TEST LOOP	UE test loop mode 1 is closed using UL RLC SDU size = 2304 bits
25	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	
26	←		DOWNLINK RLC SDU	DL_TFC4: 2304 bits (TF4=4x576 bits)
27	→		UPLINK RLC SDU	UL_TFC4: 2304 bits (TF4=4x576 bits)
28	←		OPEN UE TEST LOOP	Optional step
29	→		OPEN UE TEST LOOP COMPLETE	Optional step
30			RB RELEASE	Optional step

## 14.2.17.4 Test requirements

1. At step 1 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 6 the UE transmitted transport format on RAB subflow#1 shall be TF1 (1x576).
3. At step 6 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.
4. At step 13 the UE transmitted transport format on RAB subflow#1 shall be TF2 (2x576).

5. At step 13 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.
6. At step 20 the UE transmitted transport format on RAB subflow#1 shall be TF3 (3x576).
7. At step 20 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.
8. At step 27 the UE transmitted transport format on RAB subflow#1 shall be TF4 (4x576).
9. At step 27 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.

## 14.2.18 Streaming / unknown / UL:0 DL:64 kbps / CS or PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

### 14.2.18.1 Conformance requirement

See 14.2.4.1.

### 14.2.18.2 Test purpose

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.18.

To be able to test the downlink radio bearer using the UE loopback function for the reference radio bearer UL:0 DL: 64 kbps,, the reference radio bearer configuration according to TS 34.108, clause 6.10.2.4.1.12 (Conversational/unknown/UL:28.8 kbps) is used in uplink. For all sub-tests UL\_TFC1 is used.

### 14.2.18.3 Method of test

Uplink TFS:

	<b>TFI</b>	<b>RAB subflow #1</b>	<b>DCCH</b>
TFS	TF0, bits	0x576	0x148
	TF1, bits	1x576	0x148
	TF2, bits	2x576	N/A

Uplink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, DCCH)</b>
UL_TFC0	(TF0, TF0)
UL_TFC1	(TF1, TF0)
UL_TFC2	(TF2, TF0)
UL_TFC3	(TF0, TF1)
UL_TFC4	(TF1, TF1)
UL_TFC5	(TF2, TF1)

Downlink TFS:

	<b>TFI</b>	<b>RAB subflow #1</b>	<b>DCCH</b>
TFS	TF0, bits	0x320	0x148
	TF1, bits	1x320	0x148
	TF2, bits	2x320	N/A
	TF3, bits	4x320	N/A
	TF4, bits	8x320	N/A

Downlink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, DCCH)</b>
DL_TFC0	(TF0, TF0)
DL_TFC1	(TF1, TF0)
DL_TFC2	(TF2, TF0)
DL_TFC3	(TF3, TF0)
DL_TFC4	(TF4, TF0)
DL_TFC5	(TF0, TF1)
DL_TFC6	(TF1, TF1)
DL_TFC7	(TF2, TF1)
DL_TFC8	(TF3, TF1)
DL_TFC9	(TF4, TF1)

Sub-tests:

<b>Sub-test</b>	<b>Downlink TFCS Under test</b>	<b>Uplink TFCS used to be able to return DL data</b>	<b>Implicitely tested</b>
1	DL_TFC1	UL_TFC1	DL_TFC0, DL_TFC5, DL_TFC6
2	DL_TFC2	UL_TFC1	DL_TFC0, DL_TFC5, DL_TFC7
3	DL_TFC3	UL_TFC1	DL_TFC0, DL_TFC5, DL_TFC8
4	DL_TFC4	UL_TFC1	DL_TFC0, DL_TFC5, DL_TFC9

Initial conditions

UE in idle mode

Test procedure

Sub-test 1:

- a) The SS setup the radio bearer using the generic procedure for UE radio bearer test mode activation according to clause 14.1.1. In downlink the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.18 shall be used; and in uplink the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.12 shall be used.
- b) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC4} for RAB subflow#1 using the RRC transport format combination control procedure.
- c) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 320 bits for RAB subflow#1.
- d) The SS transmits an RLC SDU of size 320 bits using transport format combination DL\_TFC1 (1x320).
- e) The SS checks the content of the received RLC SDU.
- f) The SS open the UE test loop.

Sub-test 2:

- g) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC4} for RAB subflow#1 using the RRC transport format combination control procedure.
- h) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 640 bits for RAB subflow#1.
- i) The SS transmits an RLC SDU of size 640 bits using transport format combination DL\_TFC2 (2x320).
- j) The SS checks the content of the received RLC SDU.
- k) The SS open the UE test loop.

Sub-test 3:

- l) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC4} for RAB subflow#1 using the RRC transport format combination control procedure.
- m) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 1280 bits for RAB subflow#1.
- n) The SS transmits an RLC SDU of size 1280 bits using transport format combination DL\_TFC3 (4x320).
- o) The SS checks the content of the received RLC SDU.
- p) The SS open the UE test loop.

Sub-test 4:

- q) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC4} for RAB subflow#1 using the RRC transport format combination control procedure.
- r) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 2560 bits for RAB subflow#1.
- s) The SS transmits an RLC SDU of size 2560 bits using transport format combination DL\_TFC4 (8x320).
- t) The SS checks the content of the received RLC SDU.
- u) The SS may optionally open the UE test loop.
- v) The SS may optionally release the radio bearer.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			UE Radio Bearer Test Mode Activation	See generic procedures in clause 14.1.1 Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC4} UE test loop mode 1 is closed using UL RLC SDU size = 320 bits
2	←		TRANSPORT FORMAT COMBINATION CONTROL	
3	←		CLOSE UE TEST LOOP	
4	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	DL_TFC1: 320 bits (TF1=1x320 bits) UL_TFC1: 320 bits (TF1=1x576 bits) 1xUL RLC PDU (320 bits + padding)
5	←		DOWNLINK RLC SDU	
6	→		UPLINK RLC SDU	
7	←		OPEN UE TEST LOOP	Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC4} UE test loop mode 1 is closed using UL RLC SDU size = 640 bits
8	→		OPEN UE TEST LOOP COMPLETE	
9	←		TRANSPORT FORMAT COMBINATION CONTROL	
10	←		CLOSE UE TEST LOOP	DL_TFC2: 640 bits (TF2=2x320) UL_TFC1: 640 bits (TF1=1x576 bits) 2xUL RLC PDU, padding the 2 <sup>nd</sup> RLC PDU
11	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	
12	←		DOWNLINK RLC SDU	
13	→		UPLINK RLC SDU	Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC4} UE test loop mode 1 is closed using UL RLC SDU size = 1280 bits
14	←		OPEN UE TEST LOOP	
15	→		OPEN UE TEST LOOP COMPLETE	
16	←		TRANSPORT FORMAT COMBINATION CONTROL	DL_TFC3: 1280 bits (TF3=4x320 bits) UL_TFC1: 1280 bits (TF1=1x576 bits) 3xRLC PDUs, padding the 3 <sup>rd</sup> RLC PDU
17	←		CLOSE UE TEST LOOP	
18	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	
19	←		DOWNLINK RLC SDU	Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC4} UE test loop mode 1 is closed using UL RLC SDU size = 2560 bits
20	→		UPLINK RLC SDU	
21	←		OPEN UE TEST LOOP	
22	→		OPEN UE TEST LOOP COMPLETE	DL_TFC4: 2560 bits (TF4=8x320 bits) UL_TFC1: 2560 bits (TF1=1x576 bits) 5xRLC PDUs, padding the 5 <sup>th</sup> RLC PDU
23	←		TRANSPORT FORMAT COMBINATION CONTROL	
24	←		CLOSE UE TEST LOOP	
25	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	Optional step Optional step Optional step
26	←		DOWNLINK RLC SDU	
27	→		UPLINK RLC SDU	
28	←		OPEN UE TEST LOOP	
29	→		OPEN UE TEST LOOP COMPLETE	
30			RB RELEASE	

## 14.2.18.4

## Test requirements

1. At step 1 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 6 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.
3. At step 13 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.

4. At step 20 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.
5. At step 27 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.

## 14.2.19 Streaming / unknown / UL:64 DL:0 kbps / CS or PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

### 14.2.19.1 Conformance requirement

See 14.2.4.1.

### 14.2.19.2 Test purpose

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.19.

To be able to test the uplink radio bearer using the UE loopback function for the reference radio bearer UL:64 DL: 0 kbps, the reference radio bearer configuration according to TS 34.108, clause 6.10.2.4.1.12 (Conversational/unknown/UL:28.8 kbps) is used in downlink. For all sub-tests DL\_TFC1 is used.

### 14.2.19.3 Method of test

Uplink TFS:

	<b>TFI</b>	<b>RAB subflow #1</b>	<b>DCCH</b>
TFS	TF0, bits	0x320	0x148
	TF1, bits	1x320	0x148
	TF2, bits	2x320	N/A
	TF3, bits	4x320	N/A
	TF4, bits	8x320	N/A

Uplink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, DCCH)</b>
UL_TFC0	(TF0, TF0)
UL_TFC1	(TF1, TF0)
UL_TFC2	(TF2, TF0)
UL_TFC3	(TF3, TF0)
UL_TFC4	(TF4, TF0)
UL_TFC5	(TF0, TF1)
UL_TFC6	(TF1, TF1)
UL_TFC7	(TF2, TF1)
UL_TFC8	(TF3, TF1)
UL_TFC9	(TF4, TF1)

Downlink TFS:

	<b>TFI</b>	<b>RAB subflow #1</b>	<b>DCCH</b>
TFS	TF0, bits	0x576	0x148
	TF1, bits	1x576	0x148
	TF2, bits	2x576	N/A

Downlink TFCS:



<b>TFCI</b>	<b>(RAB subflow#1, DCCH)</b>
DL_TFC0	(TF0, TF0)
DL_TFC1	(TF1, TF0)
DL_TFC2	(TF2, TF0)
DL_TFC3	(TF0, TF1)
DL_TFC4	(TF1, TF1)
DL_TFC5	(TF2, TF1)

Sub-tests:

<b>Sub-test</b>	<b>Uplink TFCS Under test</b>	<b>Downlink TFCS used to be able to return DL data</b>	<b>Implicitely tested</b>
1	UL_TFC1	DL_TFC1	UL_TFC0, UL_TFC5, UL_TFC6
2	UL_TFC2	DL_TFC1	UL_TFC0, UL_TFC5, UL_TFC7
3	UL_TFC3	DL_TFC1	UL_TFC0, UL_TFC5, UL_TFC8
4	UL_TFC4	DL_TFC1	UL_TFC0, UL_TFC5, UL_TFC9

Initial conditions

UE in idle mode

Test procedure

Sub-test 1:

- The SS setup the radio bearer using the generic procedure for UE radio bearer test mode activation according to clause 14.1.1. In uplink the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.19 shall be used; and in downlink the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.12 shall be used.
- The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC5, UL\_TFC6} for RAB subflow#1 using the RRC transport format combination control procedure.
- The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 320 bits for RAB subflow#1.
- The SS transmits an RLC SDU of size 576 bits using transport format combination DL\_TFC1 (1x576).
- The SS checks the content of the received RLC SDU and that it is received by the correct transport format.
- The SS open the UE test loop.

Sub-test 2:

- The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC2, UL\_TFC5, UL\_TFC7} for RAB subflow#1 using the RRC transport format combination control procedure.
- The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 640 bits for RAB subflow#1.
- The SS transmits an RLC SDU of size 640 bits using transport format combination DL\_TFC1 (1x576).
- The SS checks the content of the received RLC SDU and that it is received by the correct transport format.
- The SS open the UE test loop.

Sub-test 3:

- The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC3, UL\_TFC5, UL\_TFC8} for RAB subflow#1 using the RRC transport format combination control procedure.

- m) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 1280 bits for RAB subflow#1.
- n) The SS transmits an RLC SDU of size 1280 bits using transport format combination DL\_TFC1 (1x576).
- o) The SS checks the content of the received RLC SDU and that it is received by the correct transport format.
- p) The SS open the UE test loop.

Sub-test 4:

- q) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC4, UL\_TFC5, UL\_TFC9} for RAB subflow#1 using the RRC transport format combination control procedure.
- r) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 2560 bits for RAB subflow#1.
- s) The SS transmits an RLC SDU of size 2560 bits using transport format combination DL\_TFC1 (1x576).
- t) The SS checks the content of the received RLC SDU and that it is received by the correct transport format.
- u) The SS may optionally open the UE test loop.
- v) The SS may optionally release the radio bearer.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			UE Radio Bearer Test Mode Activation	See generic procedures in clause 14.1.1 Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC5, UL_TFC6} UE test loop mode 1 is closed using UL RLC SDU size = 320 bits
2	←		TRANSPORT FORMAT COMBINATION CONTROL	
3	←		CLOSE UE TEST LOOP	
4	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	DL_TFC1: 320 bits (TF1=1x576 bits) 1xRLC PDUs, padding UL_TFC1: 320 bits (TF1=1x320 bits)
5	←		DOWNLINK RLC SDU	
6	→		UPLINK RLC SDU	
7	←		OPEN UE TEST LOOP	Transport format combinations is limited to {UL_TFC0, UL_TFC2, UL_TFC5, UL_TFC7} UE test loop mode 1 is closed using UL RLC SDU size = 640 bits
8	→		OPEN UE TEST LOOP COMPLETE	
9	←		TRANSPORT FORMAT COMBINATION CONTROL	
10	←		CLOSE UE TEST LOOP	DL_TFC1: 640 bits (TF1=1x576 bits) 2 x RLC PDUs, padding the 2 <sup>nd</sup> RLC PDU UL_TFC2: 640 (TF2=2x320 bits)
11	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	
12	←		DOWNLINK RLC SDU	
13	→		UPLINK RLC SDU	Transport format combinations is limited to {UL_TFC0, UL_TFC3, UL_TFC5, UL_TFC8} UE test loop mode 1 is closed using UL RLC SDU size = 1280 bits
14	←		OPEN UE TEST LOOP	
15	→		OPEN UE TEST LOOP COMPLETE	
16	←		TRANSPORT FORMAT COMBINATION CONTROL	DL_TFC1: 1280 bits (TF1=1x576 bits) 3 x RLC PDUs, padding the 3 <sup>rd</sup> RLC PDU UL_TFC3: 1280 bits (TF3=4x320 bits)
17	←		CLOSE UE TEST LOOP	
18	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	
19	←		DOWNLINK RLC SDU	Transport format combinations is limited to {UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9} UE test loop mode 1 is closed using UL RLC SDU size = 2560 bits
20	→		UPLINK RLC SDU	
21	←		OPEN UE TEST LOOP	
22	→		OPEN UE TEST LOOP COMPLETE	DL_TFC1: 2560 bits (TF1=1x576 bits) 5 x RLC PDUs, padding the 5 <sup>th</sup> RLC PDU UL_TFC4: 2560 bits (TF4=8x320 bits)
23	←		TRANSPORT FORMAT COMBINATION CONTROL	
24	←		CLOSE UE TEST LOOP	
25	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	Optional step Optional step Optional step
26	←		DOWNLINK RLC SDU	
27	→		UPLINK RLC SDU	
28	←		OPEN UE TEST LOOP	Optional step Optional step Optional step
29	→		OPEN UE TEST LOOP COMPLETE	
30			RB RELEASE	

## 14.2.19.4 Test requirements

1. At step 1 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 6 the UE transmitted transport format on RAB subflow#1 shall be TF1 (1x320).
3. At step 6 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.

4. At step 13 the UE transmitted transport format on RAB subflow#1 shall be TF2 (2x320).
5. At step 13 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.
6. At step 20 the UE transmitted transport format on RAB subflow#1 shall be TF3 (4x320).
7. At step 20 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.
8. At step 27 the UE transmitted transport format on RAB subflow#1 shall be TF4 (8x320).
9. At step 27 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.

## 14.2.20 Streaming / unknown / UL:0 DL:128 kbps / CS or PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

### 14.2.20.1 Conformance requirement

See 14.2.4.1.

### 14.2.20.2 Test purpose

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.20.

To be able to test the downlink radio bearer using the UE loopback function for the reference radio bearer UL:0 DL:128 kbps, the reference radio bearer configuration according to TS 34.108, clause 6.10.2.4.1.12 (Conversational/unknown/UL:28.8 kbps) is used in uplink. For all sub-tests UL\_TFC1 is used.

### 14.2.20.3 Method of test

Uplink TFS:

	<b>TFI</b>	<b>RAB subflow #1</b>	<b>DCCH</b>
TFS	TF0, bits	0x576	0x148
	TF1, bits	1x576	0x148
	TF2, bits	2x576	N/A

Uplink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, DCCH)</b>
UL_TFC0	(TF0, TF0)
UL_TFC1	(TF1, TF0)
UL_TFC2	(TF2, TF0)
UL_TFC3	(TF0, TF1)
UL_TFC4	(TF1, TF1)
UL_TFC5	(TF2, TF1)

Downlink TFS:

	<b>TFI</b>	<b>RAB subflow #1</b>	<b>DCCH</b>
TFS	TF0, bits	0x320	0x148
	TF1, bits	1x320	0x148
	TF2, bits	2x320	N/A
	TF3, bits	4x320	N/A
	TF4, bits	8x320	N/A
	TF5, bits	16x320	N/A

Downlink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, DCCH)</b>
DL_TFC0	(TF0, TF0)
DL_TFC1	(TF1, TF0)
DL_TFC2	(TF2, TF0)
DL_TFC3	(TF3, TF0)
DL_TFC4	(TF4, TF0)
DL_TFC5	(TF5, TF0)
DL_TFC6	(TF0, TF1)
DL_TFC7	(TF1, TF1)
DL_TFC8	(TF2, TF1)
DL_TFC9	(TF3, TF1)
DL_TFC10	(TF4, TF1)
DL_TFC11	(TF5, TF1)

Sub-tests:

<b>Sub-test</b>	<b>Downlink TFCS Under test</b>	<b>Uplink TFCS used to be able to return DL data</b>	<b>Implicitely tested</b>
1	DL_TFC1	UL_TFC1	DL_TFC0, DL_TFC6, DL_TFC7
2	DL_TFC2	UL_TFC1	DL_TFC0, DL_TFC6, DL_TFC8
3	DL_TFC3	UL_TFC1	DL_TFC0, DL_TFC6, DL_TFC9
4	DL_TFC4	UL_TFC1	DL_TFC0, DL_TFC6, DL_TFC10
5	DL_TFC5	UL_TFC1	DL_TFC0, DL_TFC6, DL_TFC11

Initial conditions

UE in idle mode

Test procedure

Sub-test 1:

- The SS setup the radio bearer using the generic procedure for UE radio bearer test mode activation according to clause 14.1.1. In downlink the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.20 shall be used; and in uplink the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.12 shall be used.
- The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC4} for RAB subflow#1 using the RRC transport format combination control procedure.
- The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 320 bits for RAB subflow#1.
- The SS transmits an RLC SDU of size 320 bits using transport format combination DL\_TFC1 (1x320).
- The SS checks the content of the received RLC SDU.
- The SS open the UE test loop.

Sub-test 2:

- The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC4} for RAB subflow#1 using the RRC transport format combination control procedure.
- The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 640 bits for RAB subflow#1.
- The SS transmits an RLC SDU of size 640 bits using transport format combination DL\_TFC2 (2x320).

- j) The SS checks the content of the received RLC SDU.
- k) The SS open the UE test loop.

Sub-test 3:

- l) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC4} for RAB subflow#1 using the RRC transport format combination control procedure.
- m) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 1280 bits for RAB subflow#1.
- n) The SS transmits an RLC SDU of size 1280 bits using transport format combination DL\_TFC3 (4x320).
- o) The SS checks the content of the received RLC SDU.
- p) The SS open the UE test loop.

Sub-test 4:

- q) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC4} for RAB subflow#1 using the RRC transport format combination control procedure.
- r) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 2560 bits for RAB subflow#1.
- s) The SS transmits an RLC SDU of size 2560 bits using transport format combination DL\_TFC4 (8x320).
- t) The SS checks the content of the received RLC SDU.
- u) The SS open the UE test loop.

Sub-test 5:

- v) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC4} for RAB subflow#1 using the RRC transport format combination control procedure.
- x) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 5120 bits for RAB subflow#1.
- y) The SS transmits an RLC SDU of size 5120 bits using transport format combination DL\_TFC5 (16x320).
- z) The SS checks the content of the received RLC SDU.
- aa) The SS may optionally open the UE test loop.
- bb) The SS may optionally release the radio bearer.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			UE Radio Bearer Test Mode Activation	See generic procedures in clause 14.1.1 Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC4} UE test loop mode 1 is closed using UL RLC SDU size = 320 bits
2	←		TRANSPORT FORMAT COMBINATION CONTROL	
3	←		CLOSE UE TEST LOOP	
4	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	DL_TFC1: 320 bits (TF1=1x320 bits) UL_TFC1: 320 bits (TF1=1x576 bits) 1xUL RLC PDU (320 bits + padding)
5	←		DOWNLINK RLC SDU	
6	→		UPLINK RLC SDU	
7	←		OPEN UE TEST LOOP	Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC4} UE test loop mode 1 is closed using UL RLC SDU size = 640 bits
8	→		OPEN UE TEST LOOP COMPLETE	
9	←		TRANSPORT FORMAT COMBINATION CONTROL	
10	←		CLOSE UE TEST LOOP	DL_TFC2: 640 bits (TF2=2x320) UL_TFC1: 640 bits (TF1=1x576 bits) 2xUL RLC PDU, padding the 2 <sup>nd</sup> RLC PDU
11	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	
12	←		DOWNLINK RLC SDU	
13	→		UPLINK RLC SDU	Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC4} UE test loop mode 1 is closed using UL RLC SDU size = 1280 bits
14	←		OPEN UE TEST LOOP	
15	→		OPEN UE TEST LOOP COMPLETE	
16	←		TRANSPORT FORMAT COMBINATION CONTROL	DL_TFC3: 1280 bits (TF3=4x320 bits) UL_TFC1: 1280 bits (TF1=1x576 bits) 3xRLC PDUs, padding the 3 <sup>rd</sup> RLC PDU
17	←		CLOSE UE TEST LOOP	
18	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	
19	←		DOWNLINK RLC SDU	Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC4} UE test loop mode 1 is closed using UL RLC SDU size = 2560 bits
20	→		UPLINK RLC SDU	
21	←		OPEN UE TEST LOOP	
22	→		OPEN UE TEST LOOP COMPLETE	DL_TFC4: 2560 bits (TF4=8x320 bits) UL_TFC1: 2560 bits (TF1=1x576 bits) 5xRLC PDUs, padding the 5 <sup>th</sup> RLC PDU
23	←		TRANSPORT FORMAT COMBINATION CONTROL	
24	←		CLOSE UE TEST LOOP	
25	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC4} UE test loop mode 1 is closed using UL RLC SDU size = 5120 bits
26	←		DOWNLINK RLC SDU	
27	→		UPLINK RLC SDU	
28	←		OPEN UE TEST LOOP	DL_TFC5: 5120 bits (TF5=16x320 bits) UL_TFC1: 5120 bits (TF1=1x576 bits) 9xRLC PDUs, padding the 9 <sup>th</sup> RLC PDU
29	→		OPEN UE TEST LOOP COMPLETE	
30	←		TRANSPORT FORMAT COMBINATION CONTROL	
31	←		CLOSE UE TEST LOOP	
32	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	
33	←		DOWNLINK RLC SDU	
34	→		UPLINK RLC SDU	

35	←	OPEN UE TEST LOOP	Optional step
36	→	OPEN UE TEST LOOP COMPLETE	Optional step
37		RB RELEASE	Optional step

#### 14.2.20.4 Test requirements

1. At step 1 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 6 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.
3. At step 13 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.
4. At step 20 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.
5. At step 27 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.
6. At step 34 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.

### 14.2.21 Streaming / unknown / UL:128 DL:0 kbps / CS or PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

#### 14.2.21.1 Conformance requirement

See 14.2.4.1.

#### 14.2.21.2 Test purpose

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.21.

To be able to test the uplink radio bearer using the UE loopback function for the reference radio bearer UL:64 DL: 0 kbps, the reference radio bearer configuration according to TS 34.108, clause 6.10.2.4.1.12 (Conversational/unknown/UL:28.8 kbps) is used in downlink. For all sub-tests DL\_TFC1 is used.

#### 14.2.21.3 Method of test

Uplink TFS:

	<b>TFI</b>	<b>RAB subflow #1</b>	<b>DCCH</b>
TFS	TF0, bits	0x320	0x148
	TF1, bits	1x320	0x148
	TF2, bits	2x320	N/A
	TF3, bits	4x320	N/A
	TF4, bits	8x320	N/A
	TF5, bits	16x320	N/A

Uplink TFCS:



<b>TFCI</b>	<b>(RAB subflow#1, DCCH)</b>
UL_TFC0	(TF0, TF0)
UL_TFC1	(TF1, TF0)
UL_TFC2	(TF2, TF0)
UL_TFC3	(TF3, TF0)
UL_TFC4	(TF4, TF0)
UL_TFC5	(TF4, TF0)
UL_TFC6	(TF0, TF1)
UL_TFC7	(TF1, TF1)
UL_TFC8	(TF2, TF1)
UL_TFC9	(TF3, TF1)
UL_TFC10	(TF4, TF1)
UL_TFC11	(TF5, TF1)

Downlink TFS:

	<b>TFI</b>	<b>RAB subflow #1</b>	<b>DCCH</b>
TFS	TF0, bits	0x576	0x148
	TF1, bits	1x576	0x148
	TF2, bits	2x576	N/A

Downlink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, DCCH)</b>
DL_TFC0	(TF0, TF0)
DL_TFC1	(TF1, TF0)
DL_TFC2	(TF2, TF0)
DL_TFC3	(TF0, TF1)
DL_TFC4	(TF1, TF1)
DL_TFC5	(TF2, TF1)

Sub-tests:

<b>Sub-test</b>	<b>Uplink TFCS Under test</b>	<b>Downlink TFCS used to be able to return DL data</b>	<b>Implicitely tested</b>
1	UL_TFC1	DL_TFC1	UL_TFC0, UL_TFC6, UL_TFC7
2	UL_TFC2	DL_TFC1	UL_TFC0, UL_TFC6, UL_TFC8
3	UL_TFC3	DL_TFC1	UL_TFC0, UL_TFC6, UL_TFC9
4	UL_TFC4	DL_TFC1	UL_TFC0, UL_TFC6, UL_TFC10
5	UL_TFC5	DL_TFC1	UL_TFC0, UL_TFC6, UL_TFC11

Initial conditions

UE in idle mode

Test procedure

Sub-test 1:

- a) The SS setup the radio bearer using the generic procedure for UE radio bearer test mode activation according to clause 14.1.1. In uplink the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.21 shall be used; and in downlink the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.12 shall be used.
- b) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC6, UL\_TFC7} for RAB subflow#1 using the RRC transport format combination control procedure.

- c) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 320 bits for RAB subflow#1.
- d) The SS transmits an RLC SDU of size 576 bits using transport format combination DL\_TFC1 (1x576).
- e) The SS checks the content of the received RLC SDU and that it is received by the correct transport format.
- f) The SS open the UE test loop.

Sub-test 2:

- g) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC2, UL\_TFC6, UL\_TFC8} for RAB subflow#1 using the RRC transport format combination control procedure.
- h) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 640 bits for RAB subflow#1.
- i) The SS transmits an RLC SDU of size 640 bits using transport format combination DL\_TFC1 (1x576).
- j) The SS checks the content of the received RLC SDU and that it is received by the correct transport format.
- k) The SS open the UE test loop.

Sub-test 3:

- l) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC3, UL\_TFC6, UL\_TFC9} for RAB subflow#1 using the RRC transport format combination control procedure.
- m) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 1280 bits for RAB subflow#1.
- n) The SS transmits an RLC SDU of size 1280 bits using transport format combination DL\_TFC1 (1x576).
- o) The SS checks the content of the received RLC SDU and that it is received by the correct transport format.
- p) The SS open the UE test loop.

Sub-test 4:

- q) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC4, UL\_TFC6, UL\_TFC10} for RAB subflow#1 using the RRC transport format combination control procedure.
- r) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 2560 bits for RAB subflow#1.
- s) The SS transmits an RLC SDU of size 2560 bits using transport format combination DL\_TFC1 (1x576).
- t) The SS checks the content of the received RLC SDU and that it is received by the correct transport format.
- u) The SS open the UE test loop.

Sub-test 5:

- v) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC5, UL\_TFC6, UL\_TFC11} for RAB subflow#1 using the RRC transport format combination control procedure.
- x) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 5120 bits for RAB subflow#1.
- y) The SS transmits an RLC SDU of size 5120 bits using transport format combination DL\_TFC1 (1x576).
- z) The SS checks the content of the received RLC SDU and that it is received by the correct transport format.
- aa) The SS may optionally open the UE test loop.
- bb) The SS may optionally release the radio bearer.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			UE Radio Bearer Test Mode Activation	See generic procedures in clause 14.1.1
2	←		TRANSPORT FORMAT COMBINATION CONTROL	Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC6, UL_TFC7}
3	←		CLOSE UE TEST LOOP	UE test loop mode 1 is closed using UL RLC SDU size = 320 bits
4	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	
5	←		DOWNLINK RLC SDU	DL_TFC1: 320 bits (TF1=1x576 bits) 1xRLC PDUs, padding
6	→		UPLINK RLC SDU	UL_TFC1: 320 bits (TF1=1x320 bits)
7	←		OPEN UE TEST LOOP	
8	→		OPEN UE TEST LOOP COMPLETE	
9	←		TRANSPORT FORMAT COMBINATION CONTROL	Transport format combinations is limited to {UL_TFC0, UL_TFC2, UL_TFC6, UL_TFC8}
10	←		CLOSE UE TEST LOOP	UE test loop mode 1 is closed using UL RLC SDU size = 640 bits
11	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	
12	←		DOWNLINK RLC SDU	DL_TFC1: 640 bits (TF1=1x576 bits) 2 x RLC PDUs, padding the 2 <sup>nd</sup> RLC PDU
13	→		UPLINK RLC SDU	UL_TFC2: 640 (TF2=2x320 bits)
14	←		OPEN UE TEST LOOP	
15	→		OPEN UE TEST LOOP COMPLETE	
16	←		TRANSPORT FORMAT COMBINATION CONTROL	Transport format combinations is limited to {UL_TFC0, UL_TFC3, UL_TFC6, UL_TFC9}
17	←		CLOSE UE TEST LOOP	UE test loop mode 1 is closed using UL RLC SDU size = 1280 bits
18	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	
19	←		DOWNLINK RLC SDU	DL_TFC1: 1280 bits (TF1=1x576 bits) 3 x RLC PDUs, padding the 3 <sup>rd</sup> RLC PDU
20	→		UPLINK RLC SDU	UL_TFC3: 1280 bits (TF3=4x320 bits)
21	←		OPEN UE TEST LOOP	
22	→		OPEN UE TEST LOOP COMPLETE	
23	←		TRANSPORT FORMAT COMBINATION CONTROL	Transport format combinations is limited to {UL_TFC0, UL_TFC4, UL_TFC6, UL_TFC10}
24	←		CLOSE UE TEST LOOP	UE test loop mode 1 is closed using UL RLC SDU size = 2560 bits
25	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	
26	←		DOWNLINK RLC SDU	DL_TFC1: 2560 bits (TF1=1x576 bits) 5 x RLC PDUs, padding the 5 <sup>th</sup> RLC PDU
27	→		UPLINK RLC SDU	UL_TFC4: 2560 bits (TF4=8x320 bits)
28	←		OPEN UE TEST LOOP	
29	→		OPEN UE TEST LOOP COMPLETE	
30	←		TRANSPORT FORMAT COMBINATION CONTROL	Transport format combinations is limited to {UL_TFC0, UL_TFC5, UL_TFC6, UL_TFC11}
31	←		CLOSE UE TEST LOOP	UE test loop mode 1 is closed using UL RLC SDU size = 5120 bits
32	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	

33	←	DOWNLINK RLC SDU	DL_TFC1: 5120 bits (TF1=1x576 bits) 9 x RLC PDUs, padding the 9 <sup>th</sup> RLC PDU
34	→	UPLINK RLC SDU	UL_TFC5: 5120 bits (TF5=16x320 bits)
35	←	OPEN UE TEST LOOP	Optional step
36	→	OPEN UE TEST LOOP COMPLETE	Optional step
37		RB RELEASE	Optional step

#### 14.2.21.4 Test requirements

- At step 1 the UE shall send RADIO BEARER SETUP COMPLETE.
- At step 6 the UE transmitted transport format on RAB subflow#1 shall be TF1 (1x320).
- At step 6 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.
- At step 13 the UE transmitted transport format on RAB subflow#1 shall be TF2 (2x320).
- At step 13 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.
- At step 20 the UE transmitted transport format on RAB subflow#1 shall be TF3 (4x320).
- At step 20 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.
- At step 27 the UE transmitted transport format on RAB subflow#1 shall be TF4 (8x320).
- At step 27 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.
- At step 34 the UE transmitted transport format on RAB subflow#1 shall be TF5 (16x320).
- At step 34 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.

### 14.2.22 Streaming / unknown / UL:0 DL:384 kbps / CS or PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

#### 14.2.22.1 Conformance requirement

See 14.2.4.1.

#### 14.2.22.2 Test purpose

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.22.

To be able to test the downlink radio bearer using the UE loopback function for the reference radio bearer UL:0 DL:128 kbps, the reference radio bearer configuration according to TS 34.108, clause 6.10.2.4.1.12 (Conversational/unknown/UL:28.8 kbps) is used in uplink. For all sub-tests UL\_TFC1 is used.

#### 14.2.22.3 Method of test

Uplink TFS:

	TFI	RAB subflow #1	DCCH
TFS	TF0, bits	0x576	0x148
	TF1, bits	1x576	0x148
	TF2, bits	2x576	N/A

Uplink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, DCCH)</b>
UL_TFC0	(TF0, TF0)
UL_TFC1	(TF1, TF0)
UL_TFC2	(TF2, TF0)
UL_TFC3	(TF0, TF1)
UL_TFC4	(TF1, TF1)
UL_TFC5	(TF2, TF1)

Downlink TFS:

	<b>TFI</b>	<b>RAB subflow #1</b>	<b>DCCH</b>
TFS	TF0, bits	0x320	0x148
	TF1, bits	1x320	0x148
	TF2, bits	2x320	N/A
	TF3, bits	4x320	N/A
	TF4, bits	8x320	N/A
	TF5, bits	16x320	N/A
	TF6, bits	32x320	N/A
	TF7, bits	48x320	N/A

Downlink TFCS:

<b>TFCI</b>	<b>(RAB subflow#1, DCCH)</b>
DL_TFC0	(TF0, TF0)
DL_TFC1	(TF1, TF0)
DL_TFC2	(TF2, TF0)
DL_TFC3	(TF3, TF0)
DL_TFC4	(TF4, TF0)
DL_TFC5	(TF5, TF0)
DL_TFC6	(TF6, TF0)
DL_TFC7	(TF7, TF0)
DL_TFC8	(TF0, TF1)
DL_TFC9	(TF1, TF1)
DL_TFC10	(TF2, TF1)
DL_TFC11	(TF3, TF1)
DL_TFC12	(TF4, TF1)
DL_TFC13	(TF5, TF1)
DL_TFC14	(TF6, TF1)
DL_TFC15	(TF7, TF1)

Sub-tests:

<b>Sub-test</b>	<b>Downlink TFCS Under test</b>	<b>Uplink TFCS used to be able to return DL data</b>	<b>Implicitely tested</b>
1	DL_TFC1	UL_TFC1	DL_TFC0, DL_TFC8, DL_TFC9
2	DL_TFC2	UL_TFC1	DL_TFC0, DL_TFC8, DL_TFC10
3	DL_TFC3	UL_TFC1	DL_TFC0, DL_TFC8, DL_TFC11
4	DL_TFC4	UL_TFC1	DL_TFC0, DL_TFC8, DL_TFC12
5	DL_TFC5	UL_TFC1	DL_TFC0, DL_TFC8, DL_TFC13
6	DL_TFC5	UL_TFC1	DL_TFC0, DL_TFC8, DL_TFC14
7	DL_TFC5	UL_TFC1	DL_TFC0, DL_TFC8, DL_TFC15

Initial conditions

UE in idle mode

## Test procedure

### Sub-test 1:

- a) The SS setup the radio bearer using the generic procedure for UE radio bearer test mode activation according to clause 14.1.1. In downlink the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.22 shall be used; and in uplink the reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.12 shall be used.
- b) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC4} for RAB subflow#1 using the RRC transport format combination control procedure.
- c) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 320 bits for RAB subflow#1.
- d) The SS transmits an RLC SDU of size 320 bits using transport format combination DL\_TFC1 (1x320).
- e) The SS checks the content of the received RLC SDU.
- f) The SS open the UE test loop.

### Sub-test 2:

- g) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC4} for RAB subflow#1 using the RRC transport format combination control procedure.
- h) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 640 bits for RAB subflow#1.
- i) The SS transmits an RLC SDU of size 640 bits using transport format combination DL\_TFC2 (2x320).
- j) The SS checks the content of the received RLC SDU.
- k) The SS open the UE test loop.

### Sub-test 3:

- l) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC4} for RAB subflow#1 using the RRC transport format combination control procedure.
- m) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 1280 bits for RAB subflow#1.
- n) The SS transmits an RLC SDU of size 1280 bits using transport format combination DL\_TFC3 (4x320).
- o) The SS checks the content of the received RLC SDU.
- p) The SS open the UE test loop.

### Sub-test 4:

- q) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC4} for RAB subflow#1 using the RRC transport format combination control procedure.
- r) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 2560 bits for RAB subflow#1.
- s) The SS transmits an RLC SDU of size 2560 bits using transport format combination DL\_TFC4 (8x320).
- t) The SS checks the content of the received RLC SDU.
- u) The SS open the UE test loop.

### Sub-test 5:

- v) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC4} for RAB subflow#1 using the RRC transport format combination control procedure.

- x) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 5120 bits for RAB subflow#1.
- y) The SS transmits an RLC SDU of size 5120 bits using transport format combination DL\_TFC5 (16x320).
- z) The SS checks the content of the received RLC SDU.
- aa) The SS open the UE test loop.

Sub-test 6:

- bb) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC4} for RAB subflow#1 using the RRC transport format combination control procedure.
- cc) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 10240 bits for RAB subflow#1.
- dd) The SS transmits an RLC SDU of size 5120 bits using transport format combination DL\_TFC6 (32x320).
- ee) The SS checks the content of the received RLC SDU.
- ff) The SS open the UE test loop.

Sub-test 7:

- gg) The SS limits the UE allowed uplink transport format combinations to {UL\_TFC0, UL\_TFC1, UL\_TFC4} for RAB subflow#1 using the RRC transport format combination control procedure.
- hh) The SS close the test loop using UE test loop mode 1 setting UL RLC SDU size to 15360 bits for RAB subflow#1.
- ii) The SS transmits an RLC SDU of size 5120 bits using transport format combination DL\_TFC5 (48x320).
- kk) The SS checks the content of the received RLC SDU.
- ll) The SS may optionally open the UE test loop.
- mm) The SS may optionally release the radio bearer.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			UE Radio Bearer Test Mode Activation	See generic procedures in clause 14.1.1
2	←		TRANSPORT FORMAT COMBINATION CONTROL	Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC4}
3	←		CLOSE UE TEST LOOP	UE test loop mode 1 is closed using UL RLC SDU size = 320 bits
4	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	
5	←		DOWNLINK RLC SDU	DL_TFC1: 320 bits (TF1=1x320 bits)
6	→		UPLINK RLC SDU	UL_TFC1: 320 bits (TF1=1x576 bits) 1xUL RLC PDU (320 bits + padding)
7	←		OPEN UE TEST LOOP	
8	→		OPEN UE TEST LOOP COMPLETE	
9	←		TRANSPORT FORMAT COMBINATION CONTROL	Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC4}
10	←		CLOSE UE TEST LOOP	UE test loop mode 1 is closed using UL RLC SDU size = 640 bits
11	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	
12	←		DOWNLINK RLC SDU	DL_TFC2: 640 bits (TF2=2x320)
13	→		UPLINK RLC SDU	UL_TFC1: 640 bits (TF1=1x576 bits) 2xUL RLC PDU, padding the 2 <sup>nd</sup> RLC PDU
14	←		OPEN UE TEST LOOP	
15	→		OPEN UE TEST LOOP COMPLETE	
16	←		TRANSPORT FORMAT COMBINATION CONTROL	Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC4}
17	←		CLOSE UE TEST LOOP	UE test loop mode 1 is closed using UL RLC SDU size = 1280 bits
18	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	
19	←		DOWNLINK RLC SDU	DL_TFC3: 1280 bits (TF3=4x320 bits)
20	→		UPLINK RLC SDU	UL_TFC1: 1280 bits (TF1=1x576 bits) 3xRLC PDUs, padding the 3 <sup>rd</sup> RLC PDU
21	←		OPEN UE TEST LOOP	
22	→		OPEN UE TEST LOOP COMPLETE	
23	←		TRANSPORT FORMAT COMBINATION CONTROL	Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC4}
24	←		CLOSE UE TEST LOOP	UE test loop mode 1 is closed using UL RLC SDU size = 2560 bits
25	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	
26	←		DOWNLINK RLC SDU	DL_TFC4: 2560 bits (TF4=8x320 bits)
27	→		UPLINK RLC SDU	UL_TFC1: 2560 bits (TF1=1x576 bits) 5xRLC PDUs, padding the 5 <sup>th</sup> RLC PDU
28	←		OPEN UE TEST LOOP	
29	→		OPEN UE TEST LOOP COMPLETE	
30	←		TRANSPORT FORMAT COMBINATION CONTROL	Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC4}
31	←		CLOSE UE TEST LOOP	UE test loop mode 1 is closed using UL RLC SDU size = 5120 bits
32	→		CLOSE UE TEST LOOP COMPLETE (DCCH)	
33	←		DOWNLINK RLC SDU	DL_TFC5: 5120 bits (TF5=16x320 bits)
34	→		UPLINK RLC SDU	UL_TFC1: 5120 bits (TF1=1x576 bits) 9xRLC PDUs, padding the 9 <sup>th</sup> RLC PDU



35	←	OPEN UE TEST LOOP	
36	→	OPEN UE TEST LOOP COMPLETE	
37	←	TRANSPORT FORMAT COMBINATION CONTROL	Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC4}
38	←	CLOSE UE TEST LOOP	UE test loop mode 1 is closed using UL RLC SDU size = 10240 bits
39	→	CLOSE UE TEST LOOP COMPLETE (DCCH)	
40	←	DOWNLINK RLC SDU	DL_TFC6: 10240 bits (TF6=32x320 bits)
41	→	UPLINK RLC SDU	UL_TFC1: 10240 bits (TF1=1x576 bits) 18xRLC PDUs, padding the 18 <sup>th</sup> RLC PDU
42	←	OPEN UE TEST LOOP	
43	→	OPEN UE TEST LOOP COMPLETE	
44	←	TRANSPORT FORMAT COMBINATION CONTROL	Transport format combinations is limited to {UL_TFC0, UL_TFC1, UL_TFC4}
45	←	CLOSE UE TEST LOOP	UE test loop mode 1 is closed using UL RLC SDU size = 15360 bits
46	→	CLOSE UE TEST LOOP COMPLETE (DCCH)	
47	←	DOWNLINK RLC SDU	DL_TFC7: 15360 bits (TF7=48x320 bits)
48	→	UPLINK RLC SDU	UL_TFC1: 15360 bits (TF1=1x576 bits) 27xRLC PDUs, padding the 27 <sup>th</sup> RLC PDU
49	←	OPEN UE TEST LOOP	Optional step
50	→	OPEN UE TEST LOOP COMPLETE	Optional step
51		RB RELEASE	Optional step

#### 14.2.22.4 Test requirements

1. At step 1 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 6 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.
3. At step 13 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.
4. At step 20 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.
5. At step 27 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.
6. At step 34 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.
7. At step 41 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.
8. At step 48 the UE shall return an RLC SDU on RAB subflow#1 with the same content as sent by SS.

### 14.2.23 Interactive or background / UL:32 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

#### 14.2.23.1 Interactive or background / UL:32 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 10 ms TTI

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.23 for the uplink 10 ms TTI case.

#### 14.2.23.2 Interactive or background / UL:32 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 20 ms TTI

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.23 for the uplink 20 ms TTI case.

#### 14.2.24 Interactive or background / UL:64 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.24.

#### 14.2.25 Interactive or background / UL:32 DL: 64 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.25.

#### 14.2.26 Interactive or background / UL:64 DL: 64 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.26.

#### 14.2.27 Interactive or background / UL:64 DL:128 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.27.

#### 14.2.28 Interactive or background / UL:128 DL:128 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.28.

#### 14.2.29 Interactive or background / UL:64 DL:144 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.29.

#### 14.2.30 Interactive or background / UL:144 DL:144 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.30.

### 14.2.31 Interactive or background / UL:64 DL:256 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH

#### 14.2.31.1 Interactive or background / UL:64 DL:256 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH / 10 ms TTI

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.31 for the downlink 10 ms TTI case.

#### 14.2.31.2 Interactive or background / UL:64 DL:256 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH / 20 ms TTI

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.31 for the downlink 20 ms TTI case.

### 14.2.32 Interactive or background / UL:64 DL:384 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH

#### 14.2.32.1 Interactive or background / UL:64 DL:384 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH / 10 ms TTI

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.32 for the 10 ms TTI case.

#### 14.2.32.2 Interactive or background / UL:64 DL:384 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH / 20 ms TTI

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.32 for the 20 ms TTI case.

### 14.2.33 Interactive or background / UL:128 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

#### 14.2.33.1 Interactive or background / UL:128 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 10 ms TTI

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.33 for the 10 ms TTI case.

#### 14.2.33.2 Interactive or background / UL:128 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 20 ms TTI

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.33 for the 20 ms TTI case.

### 14.2.34 Interactive or background / UL:384 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

#### 14.2.34.1 Interactive or background / UL:384 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 10 ms TTI

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.34 for the 10 ms TTI case.

#### 14.2.34.2 Interactive or background / UL:384 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 20 ms TTI

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.34. for the 20 ms TTI case

### 14.2.35 Interactive or background / UL:64 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

#### 14.2.35.1 Interactive or background / UL:64 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 10 ms TTI

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.35 for the 10 ms TTI case.

#### 14.2.35.2 Interactive or background / UL:64 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 20 ms TTI

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.35 for the 20 ms TTI case.

### 14.2.36 Interactive or background / UL:128 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.36.

### 14.2.37 Interactive or background / UL:384 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

#### 14.2.37.1 Interactive or background / UL:384 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 10 ms TTI

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.37 for the 10 ms TTI case.

#### 14.2.37.2 Interactive or background / UL:384 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 20 ms TTI

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.37 for the 20 ms TTI case.

**14.2.38** Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB +  
Interactive or background / UL:32 DL:8 kbps / PS RAB + UL:3.4  
DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.38.

**14.2.39** Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB +  
Interactive or background / UL:32 DL:64 kbps / PS RAB+ UL:3.4 DL:  
3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.39.

**14.2.40** Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB +  
Interactive or background / UL:64 DL:64 kbps / PS RAB+ UL:3.4 DL:  
3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.40.

**14.2.41** Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB +  
Interactive or background / UL:64 DL:128 kbps / PS RAB + UL:3.4  
DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.41.

**14.2.42** Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB +  
Interactive or background / UL:64 DL:256 kbps / PS RAB + UL:3.4  
DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.42.

**14.2.43** Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB +  
Interactive or background / UL:64 DL:384 kbps / PS RAB + UL:3.4  
DL:3.4 kbps SRBs for DCCH

**14.2.43.1** Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or  
background / UL:64 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for  
DCCH / 10 ms TTI

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.43 for the 10 ms TTI case.

- 14.2.43.2 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 20 ms TTI

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.43 for the 20 ms TTI case.

- 14.2.44 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:128 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.44.

- 14.2.45 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Streaming / unknown / UL:57.6 DL:57.6 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.45.

- 14.2.46 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Streaming / unknown / UL:0 DL:64 kbps / CS or PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.46.

- 14.2.47 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Streaming / unknown / UL:0 DL:128 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.47.

- 14.2.48 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Streaming / unknown / UL:0 DL:384 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.48.

- 14.2.49 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Conversational / unknown / UL:64 DL:64 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.49.

**14.2.50** Conversational / unknown / UL:64 DL:64 kbps / CS RAB +  
Conversational / unknown / UL:64 DL:64 kbps / CS RAB + UL:3.4  
DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.50.

**14.2.51** Conversational / unknown / UL:64 DL:64 kbps / CS RAB +  
Interactive or background / UL:64 DL:64 kbps / PS RAB + UL:3.4  
DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.51.

**14.2.52** Conversational / unknown / UL:64 DL:64 kbps / CS RAB +  
Interactive or background / UL:64 DL:128 kbps / PS RAB + UL:3.4  
DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.52.

**14.2.53** Conversational / unknown / UL:64 DL:64 kbps / CS RAB +  
Interactive or background / UL:128 DL:128 kbps / PS RAB + UL:3.4  
DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.53.

**14.2.54** Interactive or background / UL:64 DL:128 kbps / PS RAB +  
Streaming / unknown / UL:0 DL:64 kbps / CS or PS RAB + UL:3.4  
DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.54.

**14.2.55** Interactive or background / UL:64 DL:128 kbps / PS RAB +  
Streaming / unknown / UL:0 DL:128 kbps / CS or PS RAB + UL:3.4  
DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.55.

## **14.3** Combinations on PDSCH and DPCH

**14.3.1** Interactive or background / UL:64 DL:256 kbps / PS RAB + UL:3.4  
DL: 3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.2.1.

### 14.3.2 Interactive or background / UL:64 DL:384 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.2.2.

### 14.3.3 Interactive or background / UL:64 DL:2048 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.2.3.

### 14.3.4 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:256 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.2.4.

### 14.3.5 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.2.5.

### 14.3.6 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.2.6.

## 14.4 Combinations on SCCPCH

### 14.4.1 Stand-alone signalling RB for PCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.3.1.

### 14.4.2 Interactive/Background 32 kbps PS RAB + SRBs for CCCH + SRB for DCCH + SRB for BCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.3.2.

### 14.4.3 Interactive/Background 32 kbps RAB + SRBs for PCCH + SRB for CCCH + SRB for DCCH + SRB for BCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.3.3.



## 14.5 Combinations on PRACH

### 14.5.1 Interactive/Background 32 kbps PS RAB + SRB for CCCH + SRB for DCCH

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.4.1.

---

## 15 Supplementary Services

This section is FFS.

---

## 16 Short message service (SMS)

Ref.: TS 23.040, TS 24.011 (point to point)  
TS 23.041, (cell broadcast)

### General

The purpose of these tests is to verify that the UE can handle UMTS system functions when submitting or receiving Short Messages (SM) between UE and a short message service centre as described in TS 23.040.

The procedures are based upon services provided by the Mobility Management (MM) sublayer and GPRS Mobility Management (GMM) sublayer which are not tested in this case.

The SMS comprises three basic services; SMS point to point services on CS mode, on PS mode and SMS cell broadcast service. The SMS point to point services on CS mode shall work in an active UE at any time independent of whether or not there is a speech or data call in progress. The SMS point to point services on PS mode shall work in an active UE at any time independent of whether or not there is a PDP context in progress. The SMS cell broadcast service only works when the UE is in idle mode.

Since the timer TC1M currently is not standardized, the value of TC1M shall be declared by the manufacturer (to be used in subclauses 16.1.1 and 16.1.2).

The manufacturer shall declare whether SMS messages are stored in the USIM and/or the ME. This shall be referred to as the SMS message store in the following tests.

Unless otherwise stated default message contents from 3GPP TS 34.108 applies for following tests.

### 16.1 Short message service point to point on CS mode

All of test cases in this subclause are applied to UE supporting CS mode.

#### 16.1.1 SMS mobile terminated

##### 16.1.1.1 Conformance requirements

An active UE shall be able to receive short message TPDU (SMS-DELIVER) at any time, independently of whether or not there is a speech or data call in progress. A report will always be returned to the SC, confirming that the UE has received the short message.

##### Reference

TS 23.040, subclause 3.1.

##### 16.1.1.2 Test purpose

To verify the ability of a UE to receive and decode the SMS where provided for the point to point service.

##### 16.1.1.3 Method of test

##### Initial Conditions

- System simulator:
  - 1 cell, default parameters.
- User Equipment:

- the UE shall be in "Idle, updated" state;
- the SMS message storage shall be empty.

#### Related ICS/IXIT Statements

Support for Short message MT/PP.

Description of the basic procedures to display a mobile terminated short message.

The value of timer TC1M.

Whether SMS messages are stored in the USIM and/or the ME.

Support for call control state U10.

#### Test procedure

- a) SS initiates the establishment of RRC Connection. After the completion of RRC Connection SS authenticates UE.  
  
After the SS receives SECURITY MODE COMPLETE, the SS sends a CP-DATA message. The information element of the CP-DATA message will be RP-DATA RPDU (SMS DELIVER TPDU).
- b) The SS waits a maximum of 25 seconds for the CP-ACK message and then a maximum of 60 seconds for the CP-DATA message containing the RP-ACK RPDU.
- c) The SS sends a CP-ACK to the UE within TC1M with no further CP-DATA messages and the SS initiates RRC Connection release.
- d) Steps a), b) and c) are repeated but the first CP-DATA message from the UE is not acknowledged. The second CP-DATA message from the UE is acknowledged by a CP-ACK within a time TC1M.
- e) Steps a) and b) are repeated. The SS is configured not to send CP-ACK. Then maximum 3 CP-DATA retransmissions may occur. After a duration of TC1M + 5 seconds after the last CP-DATA retransmission the SS then initiates the channel release. The 5 seconds is the appropriate time to wait to verify that the UE does not send more than the maximum allowed (3) CP-DATA retransmissions.
- f) The SMS message store shall be cleared manually by the operator.
- g) A data or speech call is established on a DTCH with the SS and the state U10 of call control is entered. The SS sends a PAGING TYPE 2.  
  
The SS sends a CP-DATA message. The information element of the CP-DATA message will be RP-DATA RPDU (SMS DELIVER TPDU). The SS waits a maximum of 25 seconds for the CP-ACK message and then a maximum of 60 seconds for the CP-DATA message containing the RP-ACK RPDU.
- h) The SS sends a CP-ACK to the UE within TC1M with no further CP-DATA messages and the SS initiates RRC Connection release. The SMS message store shall be cleared manually by the operator.
- i) Steps g) and h) are repeated but the first CP-DATA message from the UE is not acknowledged. The second CP-DATA message from the UE is acknowledged by a CP-ACK within a time TC1M.
- j) Step g) is repeated. The SS is configured not to send CP-ACK. Then maximum 3 CP-DATA retransmissions may occur. After a duration of TC1M + 15 seconds after the last CP-DATA retransmission the SS initiates the channel release. The 15 seconds is the appropriate time to wait to verify that the UE does not send more than the maximum allowed (3) CP-DATA retransmissions (during a call in progress).

- k) A data or speech call is established on a DTCH with the SS and the state U10 of call control shall be entered. DTCHThe speech call is cleared by the SS with a disconnect message. (The call clearing is continued on the DCCH in parallel to the following exchange of messages related to SMS).

The SS sends a CP-DATA RPDU (SMS DELIVER TPDU) message. The information element of the CP-DATA message is RP-DATA.

The SS waits a maximum of 25 seconds for the CP-ACK message and then a maximum of 60 seconds for the CP-DATA message containing the RP-ACK RPDU.

The SS sends a CP-ACK to the UE within TC1M with no further CP-DATA messages and the SS initiates channel release.

The SMS message store shall be cleared manually by the operator.

- l) A data or speech call is established with the SS and the state U10 of call control is entered. After the SS sends a PAGING TYPE 2,the speech call shall be cleared from the UE. (The call clearing is continued in parallel to the following exchange of messages related to SMS).

The SS sends a CP-DATA message. The information element of the CP-DATA message is RP-DATA RPDU (SMS DELIVER TPDU).

The SS waits a maximum of 25 seconds for the CP-ACK message and then a maximum of 60 seconds for the CP-DATA message containing the RP-ACK RPDU.

The SS sends a CP-ACK to the UE within TC1M with no further CP-DATA messages and the SS initiates RRC Connection release.

The SMS message store shall be cleared manually by the operator.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			Mobile terminated establishment of RRC connection Mobile terminated establishment of RRC connection	See TS34.108
2	-->		PAGING RESPONSE	
3	<--		AUTHENTICATION REQUEST	
4	-->		AUTHENTICATION RESPONSE	
5	<--		SECURITY MODE COMMAND	
6	-->		SECURITY MODE COMPLETE	
7	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU)
8		SS		Waits max 25 seconds for CP-ACK
9	-->		CP-ACK	
10		SS		Waits max 60 seconds for RP-ACK RPDU
11	-->		CP-DATA	Contains RP-ACK RPDU
12	<--		CP-ACK	
13		UE		There should be no further CP-DATA messages until the UE aborts the RRC connection .
14		UE		The UE shall indicate that an SM has arrived. If the UE provides the functionality to display MT messages, it is checked that the correct message is displayed
15			Mobile terminated establishment of RRC connection	See TS34.108

Step	Direction		Message	Comments
	UE	SS		
16	-->		PAGING RESPONSE	
17	<--		AUTHENTICATION REQUEST	
18	-->		AUTHENTICATION RESPONSE	
19	<--		SECURITY MODE COMMAND	
20	-->		SECURITY MODE COMPLETE	
21	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU)
22	SS			Waits max 25 seconds for CP-ACK
23	-->		CP-ACK	
24	SS			Waits max 60 seconds for RP-ACK RPDU
25	-->		CP-DATA	First CP-DATA from UE, contains RP-ACK RPDU
26	SS			First CP-DATA message not acknowledged by SS
27	-->		CP-DATA	Retransmitted CP-DATA from UE within twice TC1M, after step 25, contains RP-ACK RPDU
28	<--		CP-ACK	Second CP_DATA message is acknowledged
29	UE			There should be no further CP-DATA messages until the UE aborts the RRC connection.
30	UE			The UE shall indicate that an SM has arrived. If the UE provides the functionality to display MT messages, it is checked that the correct message is displayed
31			Mobile terminated establishment of RRC connection	See TS34.108
32	-->		PAGING RESPONSE	
33	<--		AUTHENTICATION REQUEST	
34	-->		AUTHENTICATION RESPONSE	
35	<--		SECURITY MODE COMMAND	
36	-->		SECURITY MODE COMPLETE	
37	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU)
38	SS			Waits max 25 seconds for CP-ACK
39	-->		CP-ACK	
40	SS			Waits max 60 seconds for RP-ACK RPDU
41	-->		CP-DATA	Contains RP-ACK RPDU
42	SS			First CP-DATA message not acknowledged by SS
43			CP-DATA	Retransmitted CP-DATA from UE within twice TC1M after step 41, contains RP-ACK RPDU
44	SS			Retransmitted CP-DATA message not acknowledged by SS
45	UE			Depending upon the maximum number of CP-DATA retransmissions implemented, step 43 and 44 may be repeated.
46	<--		RRC CONNECTION RELEASE	RRC connection is released after a duration of TC1M + 5 seconds after the last CP-DATA retransmission..
47	-->		RRC CONNECTION RELEASE COMPLETE	
48	UE			The UE shall indicate that an SM has arrived. If the UE provides the functionality to display MT messages, it is checked that the correct message is displayed
49	SS			A data or speech call is established on a DTCH and the state U10 of call control is entered.
50			PAGING TYPE 2	
51	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU)
52	SS			Waits max 25 seconds for CP-ACK
53	-->		CP-ACK	
54	SS			Waits max 60 seconds for RP-ACK RPDU
55	-->		CP-DATA	Contains RP-ACK RPDU
56	<--		CP-ACK	
57	<--		DISCONNECT	
58	-->		RELEASE	Disconnect the active call

Step	Direction		Message	Comments
	UE	SS		
59	UE			The UE shall indicate that an SM has arrived. If the UE provides the functionality to display MT messages, it is checked that the correct message is displayed
60	UE			Clear the SMS message store
61	SS			A data or speech call is established on a DTCH and the state U10 of call control is entered.
62	<--		PAGING TYPE 2	
63	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU)
64	SS			Waits max 25 seconds for CP-ACK
65	-->		CP-ACK	
66	SS			Waits max 60 seconds for RP-ACK RPDU
67	-->		CP-DATA	First CP-DATA from UE, contains RP-ACK RPDU
68	SS			First CP-DATA message not acknowledged by SS
69	-->		CP-DATA	Retransmitted CP-DATA message within twice TC1M after step 67, contains RP-ACK RPDU
70	<--		CP-ACK	Second CP-DATA message is acknowledged
71	<--		DISCONNECT	
72	-->		RELEASE	Disconnect the active call
74	UE			There should be no further CP-DATA messages until the UE aborts the RRC connection
75	UE			The UE shall indicate that an SM has arrived. If the UE provides the functionality to display MT messages, it is checked that the correct message is displayed
76	UE			Clear the SMS message store
77	SS			A data or speech call is established on a DTCH and the state U10 of call control is entered.
78	<--		PAGING TYPE 2	
	-->			
79	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU)
80	SS			Waits max 25 seconds for CP-ACK
81	-->		CP-ACK	
82	SS			Waits max 60 seconds for RP-ACK RPDU
83	-->		CP-DATA	First CP-DATA from UE, contains RP-ACK RPDU
84	SS			First CP-DATA message not acknowledged by SS
85	-->		CP-DATA	Transmitted CP-DATA message within twice TC1M after step 83, contains RP-ACK RPDU
86	SS			Retransmitted CP-DATA message not acknowledged by SS
87	UE			Depending on the maximum number of CP-DATA retransmissions implemented, step 85-86 may be repeated. The maximum number of retransmissions may however not exceed three.
88	<--		RRC CONNECTION RELEASE	RRC CONNECTION is released after a duration of TC1M + 15 seconds after the last CP-DATA retransmission.
89	-->		RRC CONNECTION RELEASE COMPLETE	
90	UE			The UE shall indicate that an SM has arrived. If the UE provides the functionality to display MT messages, it is checked that the correct message is displayed
91	UE			Clear the SMS message store
92	SS			A data or speech call is established on a DTCH and the state U10 of call control is entered.
93	<--		PAGING TYPE 2	Sent on DCCH associated with the DTCH
94	<--		DISCONNECT	The speech call is cleared by the SS. The call clearing is continued in parallel to the following exchange of messages related to SMS.
95	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU)
96	SS			Waits max 25 seconds for CP-ACK
97	-->		CP-ACK	
98	SS			Waits max 60 seconds for RP-ACK RPDU
99	-->		CP-DATA	Contains RP-ACK RPDU
100	<--		CP-ACK	

Step	Direction		Message	Comments
	UE	SS		
101	UE			There should be no further CP-DATA messages until the UE aborts the RR connection.
102	UE			The UE shall indicate that an SM has arrived. If the UE provides the functionality to display MT messages, it is checked that the correct message is displayed
103	UE			Clear the SMS message store
104	SS			A data or speech call is established on a DTCH and the state U10 of call control is entered.
105	<--		PAGING TYPE 2	
106	-->		DISCONNECT	The speech call is cleared from the UE. The call clearing is continued in parallel to the following exchange of messages related to SMS.
107	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU)
108	<--		RELEASE	This message is likely to be sent before all of the CP-DATA message has been sent on the DCCH.
109	-->		RELEASE COMPLETE	
110	-->		CP-ACK	shall be sent before 25 seconds after the start of step 107
111	SS			Waits max 60 seconds for RP-ACK RPDU
112	-->		CP-DATA	Contains RP-ACK RPDU
113	<--		CP-ACK	
114	UE			There should be no further CP-DATA messages until the UE aborts the RRC connection.
115	UE			The UE shall indicate that an SM has arrived. If the UE provides the functionality to display MT messages, it is checked that the correct message is displayed
116	UE			Clear the SMS message store

NOTE: Time values for SS wait time are chosen sufficiently high to be sure that the UE has enough time to respond to the different messages.

### Specific Message Contents

#### SMS DELIVER TPDU

Information element	Comment Value
TP-UDL	160
TP-UD (140 octets)	text of message (160 characters)

NOTE: The 160 characters in TP-UD shall include at least one occurrence of each character in the default alphabet (see TS 23.038, subclause 6.2.1).

#### 16.1.1.4 Test requirements

After step 7 UE shall receive SMS-DELIVER TPDU and send CP-ACK within 25 seconds and CP-DATA containing RP-ACK within 60 seconds.

After step 25 UE shall retransmit CP-DATA containing RP-ACK within twice TC1M.

After step 30 UE shall indicate that an SM has arrived.

After step 43 UE shall repeat CP-DATA retransmissions as many times as the decided maximum number.

After step 48 UE shall indicate that an SM has arrived.

After step 51 UE shall receive SMS-DELIVER TPDU and send CP-ACK within 25 seconds and CP-DATA containing RP-ACK within 60 seconds.

After step 67 UE shall retransmit CP-DATA containing RP-ACK within twice TC1M.



After step 74 UE shall indicate that an SM has arrived.

After step 79 UE shall repeat CP-DATA retransmissions as many times as the decided maximum number.

After step 90 UE shall indicate that an SM has arrived.

After step 95 UE shall receive SMS-DELIVER TPDU and send CP-ACK within 25 seconds and CP-DATA containing RP-ACK within 60 seconds.

After step 107 UE shall receive SMS-DELIVER TPDU and send CP-ACK within 25 seconds and CP-DATA containing RP-ACK within 60 seconds.

## 16.1.2 SMS mobile originated

### 16.1.2.1 Conformance requirements

An active UE shall be able to submit short message TPDU (SMS-SUBMIT) at any time, independently of whether or not there is a speech or data call in progress.

#### Reference

TS 23.040, subclause 3.1.

### 16.1.2.2 Test purpose

To verify that the UE is able to correctly send a short message where the SMS is provided for the point to point service. The test also verifies that the UE is capable of simultaneously receiving a network originated SM whilst sending a mobile originated SM.

### 16.1.2.3 Method of test

#### Initial Conditions

- System simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in "Idle, updated" state;
  - the SMS message storage shall be empty.

#### Related ICS/IXIT Statements

Support for Short message MO/PP.

Description of the basic procedures to display a mobile originated short message.

Support for state U10 of call control.

The value of timer TC1M.

Whether SMS messages are stored in the USIM and/or the ME.

Maximum length (characters) of a mobile originated short message.

#### Test procedure

- a) The UE shall be set up to send a SM to the SS. The SS responds to RRC CONNECTION REQUEST by allocating aCCCH. The SS receives RRC CONNECTION SETUP COMPLETE on DCCH and then performs the authentication.

- b) After receiving SECURITY MODE COMMAND UE shall send SECURITY COMMAND COMPLETE.
- c) The SS responds to the CP-DATA containing RP-DATA RPDU (SMS SUBMIT TPDU) from the UE with a CP-ACK message within TC1M followed by a CP-DATA message containing the correct RP-ACK RPDU. The SS waits a maximum of 25 seconds for the CP-ACK message.
- d) The SS sends a channel release message to the UE.
- e) Steps a) and b) are repeated. The SS is configured not to send the CP-ACK message. Then maximum 3 CP-DATA retransmissions may occur. After a duration of TC1M + 5 seconds after the last CP-DATA retransmission the SS initiates channel release. The 5 seconds is the appropriate time to wait to verify that the UE does not send more than the maximum CP-DATA retransmissions.
- f) Steps a) and b) are repeated. On receipt of the CP-DATA from the UE the SS sends a CP-ERROR message within TC1M containing a "Network Failure" cause. Then the SS initiates channel release.
- g) A data or speech call is established with the SS and the state U10 of call control is entered. The UE is setup to send an SM to the SS. After the reception of the CM SERVICE REQUEST, the SS sends a CM SERVICE ACCEPT message. h) The SS responds to the CP-DATA containing RP-DATA RPDU (SMS SUBMIT TPDU) from the UE with a CP-ACK message within TC1M followed by a CP-DATA message containing the correct RP-ACK RPDU. The SS waits a maximum of 25 seconds for the CP-ACK message. Then the SS sends a channel release message to the UE.
- i) Step g) is repeated. The SS is configured not to send the CP-ACK message. Then maximum 3 CP-DATA retransmissions may occur. After a duration of TC1M + 15 seconds after the last CP-DATA retransmission the SS initiates channel release. The 15 seconds is the appropriate time to wait to verify that the UE does not send more than the maximum CP-DATA retransmissions (during a call in progress).
- j) The SS is configured to receive a mobile originated SM. Steps a) and b) are repeated and, using the end of the CP-DATA message from the UE as a trigger, the SS sends a SM to the UE. In this case a new transaction identifier shall be used in the CP messages of SMS mobile terminated.
- k) The UE is set up to send an SM to the SS. On receipt of the CM SERVICE REQUEST the SS sends a CM SERVICE REJECT message with the reject cause set to "Service Option not supported" or "Service Option temporarily out of order". After 5 seconds the SS initiates channel release.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<--		SYSTEM INFORMATION	BCCH
2	-->		RRC CONNECTION REQUEST	CCCH
3	<--		RRC CONNECTION SETUP	CCCH
4	-->		RRC CONNECTION SETUP COMPLETE	DCCH
5	-->		CM SERVICE REQUEST	
6	<--		AUTHENTICATION REQUEST	
7	-->		AUTHENTICATION RESPONSE	
8	<--		SECURITY MODE COMMAND	
9	-->		SECURITY MODE COMPLETE	
10	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU)
11	<--		CP-ACK	Sent within TC1M after step 10
12	<--		CP-DATA	Contains RP-ACK RPDU
13		SS		Waits max 25 seconds for CP-ACK
14	-->		CP-ACK	
15	<--		RRC CONNECTION RELEASE	RRC connection is released.
16	-->		RRC CONNECTION RELEASE COMPLETE	
17	<--		SYSTEM INFORMATION	BCCH
18	-->		RRC CONNECTION REQUEST	CCCH
19	<--		RRC CONNECTION SETUP	CCCH

Step	Direction		Message	Comments
	UE	SS		
20	-->		RRC CONNECTION SETUP COMPLETE	DCCH
21				
22	-->		CM SERVICE REQUEST	
23	<--		AUTHENTICATION REQUEST	
24	-->		AUTHENTICATION RESPONSE	
25	<--		SECURITY MODE COMMAND	
26	-->		SECURITY MODE COMPLETE	
27	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU)
28	SS			SS configured not to send CP-ACK
29	-->		CP-DATA	Retransmitted CP-DATA message within twice TC1M after step 27
30	UE			Depending on the maximum number of CP-DATA retransmissions implemented, step 29 may be repeated. The maximum number of retransmissions may however not exceed three.
31	<--		RRC CONNECTION RELEASE	RRC CONNECTION is released after a duration of TC1M + 5 seconds after the last CP-DATA retransmission.
32	-->		RRC CONNECTION RELEASE COMPLETE	
33	<--		SYSTEM INFORMATION	BCCH
34	-->		RRC CONNECTION REQUEST	CCCH
35	<--		RRC CONNECTION SETUP	CCCH
36	-->		RRC CONNECTION SETUP COMPLETE	DCCH
37	-->		CM SERVICE REQUEST	
38	<--		AUTHENTICATION REQUEST	
39	-->		AUTHENTICATION RESPONSE	
40	<--		SECURITY MODE COMMAND	
41	-->		SECURITY MODE COMPLETE	
42	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU)
43	<--		CP-ERROR	Sent within TC1M containing "Network Failure" cause.
44	<--		RRC CONNECTION RELEASE	RRC CONNECTION is released.
45	-->		RRC CONNECTION RELEASE COMPLETE	
46	SS			A data or speech call is established on a DTCH and the state U10 of call control is entered.
47	UE			The UE is set up to send an SM
48	-->		CM SERVICE REQUEST	CM service type set to "short message "
49	<--		CM SERVICE ACCEPT	
50	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU)
51	<--		CP-ACK	Sent within TC1M after step 50
52	<--		CP-DATA	Contains RP-ACK RPDU
53	SS			Waits max 25 seconds for CP-ACK
54	-->		CP-ACK	
55	<--		RRC CONNECTION RELEASE	RRC CONNECTION is released.
56	-->		RRC CONNECTION RELEASE COMPLETE	
57	SS			A data or speech call is established on a DTCH and the state U10 of call control is entered.
58	-->		CM SERVICE REQUEST	CM service type set to "short message "
59	<--		CM SERVICE ACCEPT	
60	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU)
61	SS			SS configured not to send CP-ACK
62	-->		CP-DATA	Transmitted CP-DATA message within twice TC1M after step 60
63	UE			Depending on the maximum number of CP-DATA retransmissions implemented, step 62 may be repeated. The maximum number of retransmissions may however not exceed three.
64	<--		RRC CONNECTION RELEASE	RRC CONNECTION is released after a duration of TC1m + 15 seconds after the last CP-DATA retransmission.
65	-->		RRC CONNECTION RELEASE COMPLETE	

Step	Direction		Message	Comments
	UE	SS		
66	<--		SYSTEM INFORMATION	BCCH
67	-->		RRC CONNECTION REQUEST	CCCH
68	<--		RRC CONNECTION SETUP	CCCH
69	-->		RRC CONNECTION SETUP COMPLETE	DCCH
70	-->		CM SERVICE REQUEST	
71	<--		AUTHENTICATION REQUEST	
72	-->		AUTHENTICATION RESPONSE	
73	<--		SECURITY MODE COMMAND	
74	-->		SECURITY MODE COMPLETE	
75	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU)
76	SS			The SS sends an SM to the UE triggered by the end of the CP-DATA message from the UE
77	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU)
78	UE			The UE shall correctly receive the SM and indicate that a message has arrived. If the UE provides the functionality to display MT messages, it is checked that the correct message is displayed. In the MO case the UE shall send the CP-ACK message with transaction identifier assigned to this transfer. In the MT case the UE shall send a CP-ACK message and a CP-DATA message containing the RP-ACK RPDU. The transaction identifier shall be the same as chosen by the SS for the MT transfer.
79	-->		RRC CONNECTION REQUEST	
80	<--		RRC CONNECTION SETUP	
81	-->		RRC CONNECTION SETUP COMPLETE	
82	-->		CM SERVICE REQUEST	. CM service type set to "short message transfer"
83	<--		CM SERVICE REJ	Reject cause set to "Service Option not supported" or "Service Option temporarily out of order"
84	UE			
85	<--		RRC CONNECTION RELEASE	Sent 5 seconds after CM SERVICE REJ
86	-->		RRC CONNECTION RELEASE COMPLETE	

NOTE: Time values for SS wait times are chosen sufficiently high to be sure that the UE has enough time to respond to the different messages.

### Specific Message Contents

#### SMS SUBMIT TPDU

Information element	Comment Value
TP-UDL TP-UD (140 octets max)	as applicable maximum number of characters (text of message) as defined by the manufacturer (see ICS/IXIT)

#### 16.1.2.4 Test requirements

After step 9 UE shall send a CP-DATA containing RP-data. The RP-DATA shall contain SMS SUBMIT TPDU.

After step 27 UE shall retransmit a CP-DATA containing RP-data. The RP-DATA shall contain SMS SUBMIT TPDU.

After step 44 UE shall send the RRC CONNECTION RELEASE COMPLETE.

After step 49 UE shall send a CP-DATA containing RP-data. The RP-DATA shall contain SMS SUBMIT TPDU.

After step 60 UE shall repeat CP-DATA retransmissions as many times as the decided maximum number.

After step 77 UE shall correctly receive the SM and indicate that a message has arrived.

After step 83 UE shall not send CP-DATA.

### 16.1.3 Test of memory full condition and memory available notification:

The Memory Available Notification provides a means for the UE to notify the network that it has memory available to receive one or more short messages. The SMS status field in the USIM contains status information on the "memory available" notification flag.

#### 16.1.3.1 Conformance requirement

1. When a mobile terminated message is Class 2, the UE shall ensure that the message has been transferred to the SMS data field in the USIM before sending an acknowledgement to the SC. The UE shall return a protocol error message if the short message cannot be stored in the USIM and there is other short message storage available in the UE. If all the short message storage in the UE is already in use, the UE shall return "memory capability exceeded".
2. When the UE rejects a short message due to lack of available memory capability the need to transfer notification shall be stored in the USIM.
3. If the memory capability becomes available because memory is cleared, the value of the memory capability exceeded notification flag in the USIM is read. If the flag is set, the UE notifies the network that memory capability is now available. After a positive acknowledgement from the network, the ME unsets the memory capability exceeded notification flag in the USIM.

#### References

- TS 23.040, subclause 9.2.3.10, TS 23.038, clause 4.
- TS 23.040, subclause 10.3 (operation 14).
- TS 23.040, subclause 10.3 (operation 14).

#### 16.1.3.2 Test purpose

1. To verify that the UE sends the correct acknowledgement when its memory in the USIM becomes full.
2. To verify that the UE sends the correct acknowledgement when its memory in the ME and the USIM becomes full, and sets the "memory exceeded" notification flag in the USIM.
3. To verify that the UE performs the "memory available" procedure when its message store becomes available for receiving short messages, and only at this moment.

#### 16.1.3.3 Method of test

##### Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in the idle updated state;
  - the SMS message storage shall be empty;
  - the UE shall be connected to the USIM simulator. The following shall be present in the USIM simulator:
    - EF<sub>SMS</sub> with at least one record;
    - EF<sub>SMSstatus</sub> with SMS "Memory Cap. Exceed" notification flag set to "memory available";

- Service no. 4 (SMS) in EF<sub>SST</sub> set to allocated and activated.
- for storing of Class 1 Short Messages the UE shall be set up to store Short Messages in the ME memory (by way of MMI, as described in ICS/IXIT statement).

### Related ICS/IXIT Statements

Support for Short message MT/PP.

Description of the basic procedures to display a mobile terminated short message.

Whether SMS messages are stored in the USIM and/or the ME.

The value of timer TC1M.

### Test procedure

- a) step a) of subclause 16.1.5.3 (test of Class 2 Short Messages) is repeated until the UE sends a negative acknowledgement (RP-ERROR). The USIM simulator shall indicate if the "memory capability exceeded" notification flag has been set on the USIM.
- b) a Class 1 Short Message is sent to the UE.
- c) step b) is repeated until the UE sends a negative acknowledgement (RP-ERROR). The USIM simulator shall indicate if the "memory capability exceeded" notification flag has been set on the USIM.
- d) a Short Message is sent to the UE with the DCS field of the SMS-DELIVER TPDU set to 0.
- e) the SS prompts the operator to read a short message and to remove it from the message store of the UE.
- f) the SS waits for a RRC CONNECTION REQUEST from the UE, and sends a RRC CONNECTION SETUP.
- g) after the SS receives a RRC CONNECTION SETUP COMPLETE, the SS authenticates the UE and activates ciphering.
- h) the SS answers to the RP-SMMA from the UE with a CP-DATA containing a RP-ACK RPDU.
- i) after the UE has acknowledged the CP-DATA with a CP-ACK, the SS releases the RRC connection. The USIM simulator shall indicate if the "memory capability exceeded" notification flag has been unset on the USIM.
- j) step e) is repeated.

### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			Mobile terminated establishment of RRC connection	See TS34.108
2	-->		PAGING RESPONSE	
3	<--		AUTHENTICATION REQUEST	
4	-->		AUTHENTICATION RESPONSE	
5	<--		SECURITY MODE COMMAND	
6	-->		SECURITY MODE COMPLETE	
7	<--		CP-DATA	
8		SS		Contains RP-DATA RPDU (SMS DELIVER TPDU), Class 2 Short Message
9	-->		CP-ACK	Waits max 25 seconds for CP-ACK
10		SS		Waits max 60 seconds for RP-ACK RPDU
11	-->		CP-DATA	Contains RP-ACK RPDU
12	<--		CP-ACK	Within TC1M after step 11

Step	Direction		Message	Comments
	UE	SS		
13	<--		RRC CONNECTION RELEASE	RRC connection is released. Step 1-13 is repeated until UE sends a negative acknowledgement (RP-ERROR) in step 16. The RP-ERROR RPDU cause field shall be "Protocol error, unspecified" if there is message capability in the ME, or "Memory capability exceeded" if there is no message capability in the ME. If the total memory store of the UE is full, the ME shall set the "memory capability exceeded" notification flag on the USIM.
14	-->		RRC CONNECTION RELEASE COMPLETE	
15			Mobile terminated establishment of RRC connection	See TS34.108
16	-->		PAGING RESPONSE	
17	<--		AUTHENTICATION REQUEST	
18	-->		AUTHENTICATION RESPONSE	
19	<--		SECURITY MODE COMMAND	
20	-->		SECURITY MODE COMPLETE	
21	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU), Class 1 Short Message Waits max 25 seconds for CP-ACK
22	SS			
23	-->		CP-ACK	Waits max 60 seconds for RP-ACK RPDU Shall contain RP-ACK RPDU if there is memory capability in the ME. If not it shall contain RP-ERROR RPDU which cause field shall be "memory capability exceeded". If the total memory store of the UE now becomes full at this step, the ME shall set the "memory cap. exceed" notification flag on the USIM.
24	SS			
25	-->		CP-DATA	Within TC1M after step 25 RRC connection is released. Step 15-27 is repeated until the UE sends an RP-ERROR. The USIM simulator shall indicate if the "memory capability exceeded" notification flag has been set on the USIM.
26	<--		CP-ACK	
27	<--		RRC CONNECTION RELEASE	
28	-->		RRC CONNECTION RELEASE COMPLETE	
29			Mobile terminated establishment of RRC connection	See TS34.108
30	-->		PAGING RESPONSE	
31	<--		AUTHENTICATION REQUEST	
32	-->		AUTHENTICATION RESPONSE	
33	<--		SECURITY MODE COMMAND	
34	-->		SECURITY MODE COMPLETE	
35	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU) with TP-DCS set to 0 Waits max 25 seconds for CP-ACK
36	SS			
37	-->		CP-ACK	Waits max 60 seconds for RP-ACK RPDU Shall contain RP-ERROR RPDU with error cause "memory capability exceeded". Within TC1M after step 39 RRC connection is released.
38	SS			
39	-->		CP-DATA	
40	<--		CP-ACK	
41	<--		RRC CONNECTION RELEASE	
42	-->		RRC CONNECTION RELEASE COMPLETE	
43	SS			Prompts the operator to remove one of the short messages from the message store of the UE.
44	<--		SYSTEM INFORMATION	BCCH
45	-->		RRC CONNECTION REQUEST	CCCH
46	<--		RRC CONNECTION SETUP	CCCH
47	-->		RRC CONNECTION SETUP COMPLETE	DCCH

Step	Direction		Message	Comments
	UE	SS		
48	-->		CM SERVICE REQUEST	CM service type information element is set to "Short message transfer".  Contains RP-SMMA RPDU  Contains RP-ACK RPDU Acknowledge of CP-DATA containing the RP-ACK RPDU. The ME shall unset the "memory capability exceeded" notification flag on the USIM.
49	<--		CM SERVICE ACCEPT	
50	-->		CP-DATA	
51	<--		CP-ACK	
52	<--		CP-DATA	
53	-->		CP-ACK	RRC connection is released. The USIM simulator shall indicate if the "memory capability exceeded" notification flag has been unset on the USIM.
54	<--		RRC CONNECTION RELEASE	
55	-->		RRC CONNECTION RELEASE COMPLETE	
56		SS		Prompts the operator to remove one of the short messages from the message store of the UE.
57		UE		Shall not attempt to send a RP-SMMA RPDU. This is verified by checking that the UE does not send a CHANNEL REQUEST message with the establishment cause "Other services which can be completed with an SDCCH"

NOTE: Time values for SS wait time are chosen sufficiently high to be sure that the UE has enough time to respond to the different messages.

#### Specific Message Contents

##### SMS-DELIVER TPDU in step 7

Information element	CommentValue
TP-DCS	default alphabet, class 2 "11110010"B

##### SMS-DELIVER TPDU in step 21

TP-DCS	default alphabet, class 1 "11110001"B
--------	---------------------------------------

##### SMS-DELIVER TPDU in step 35

TP-DCS	default alphabet "00000000"B
--------	------------------------------

#### 16.1.3.4 Test requirements

After UE sends a negative acknowledgement (RP-ERROR) in step 11, the USIM simulator shall indicate if the "memory capability exceeded" notification flag has been set on the USIM.

After UE sends a negative acknowledgement (RP-ERROR) in step 23, the USIM simulator shall indicate if the "memory capability exceeded" notification flag has been set on the USIM.

After step 53 the ME shall unset the "memory capability exceeded" notification flag on the USIM.

After step 56 UE shall not attempt to send a RP-SMMA RPDU.



## 16.1.4 Test of the status report capabilities and of SMS-COMMAND:

This test applies to UEs which support the status report capabilities.

### 16.1.4.1 Conformance requirement

The SMS offers the SC the capabilities of informing the UE of the status of a previously sent mobile originated short message. This is achieved by the SC returning a status report TPDU (SMS-STATUS-REPORT) to the originating UE.

SMS-COMMAND enables an UE to invoke an operation at the SC.

The UE shall increment TP-MR by 1 for each SMS-SUBMIT or SMS-COMMAND being submitted.

### References

- TS 23.040, subclause 3.2.9.
- TS 23.040, subclause 9.2.3.6.

### 16.1.4.2 Test purpose

- 1) To verify that the UE is able to accept a SMS-STATUS-REPORT TPDU.
- 2) To verify that the UE is able to use the SMS-COMMAND functionality correctly and sends an SMS-COMMAND TPDU with the correct TP-Message-Reference.

### 16.1.4.3 Method of test

#### Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in the idle updated state.

#### Related ICS/IXIT Statements

Support of SMS MO/PP and MT/PP.

#### Test procedure

- a) The UE is made to send a Mobile Originated short message setting TP-SRR as in steps a) to d) of test 16.1.2 (SMS Mobile originated).
- b) The SS sends a CP-DATA message containing a RP-DATA RPDU itself containing an SMS-STATUS-REPORT TPDU.
- c) The SS sends a RRC CONNECTION RELEASE message.
- d) The UE is made to send an SMS-COMMAND message enquiring about the previously submitted short message.
- e)
- f) The SS acknowledges the CP-DATA message from the UE with a CP-ACK followed by a CP-DATA message containing an RP-ACK RPDU
- g) After receiving the CP-ACK from the UE, the SS releases the RRC connection by using a RRC CONNECTION RELEASE message.

- h) The UE is made to send an SMS-COMMAND message requiring to delete the previously submitted short message.
- i) steps e) to g) are repeated.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<--		SYSTEM INFORMATION	BCCH
2	-->		RRC CONNECTION REQUEST	CCCH
3	<--		RRC CONNECTION SETUP	CCCH
4	-->		RRC CONNECTION SETUP COMPLETE	DCCH
5	-->		CM SERVICE REQUEST	
6	<--		AUTHENTICATION REQUEST	
7	-->		AUTHENTICATION RESPONSE	
8	<--		SECURITY MODE COMMAND	
9	-->		SECURITY MODE COMPLETE	
10	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU)
11	<--		CP-ACK	Sent within TC1M after step 10
12	<--		CP-DATA	Contains RP-ACK RPDU
13	SS			Waits max 25 seconds for CP-ACK
14	-->		CP-ACK	
15	<--		RRC CONNECTION RELEASE	RRC connection is released.
16	-->		RRC CONNECTION RELEASE COMPLETE	
17			Mobile terminated establishment of RRC connection	See TS34.108
18	-->		PAGING RESPONSE	
19	<--		AUTHENTICATION REQUEST	
20	-->		AUTHENTICATION RESPONSE	
21	<--		SECURITY MODE COMMAND	
22	-->		SECURITY MODE COMPLETE	
23	<--		CP-DATA	Contains RP-DATA RPDU (SMS-STATUS-REPORT TPDU)
24	-->		CP-ACK	
25	-->		CP-DATA	Contains RP-ACK RPDU
26	<--		CP-ACK	
27	<--		RRC CONNECTION RELEASE	RRC connection is released.
28	-->		RRC CONNECTION RELEASE COMPLETE	
29	UE			The UE is made to send an SMS-COMMAND message enquiring about the previously submitted SM
30	<--		SYSTEM INFORMATION	BCCH
31	-->		RRC CONNECTION REQUEST	CCCH
32	<--		RRC CONNECTION SETUP	CCCH
33	-->		RRC CONNECTION SETUP COMPLETE	DCCH
34	-->		CM SERVICE REQUEST	
35	<--		AUTHENTICATION REQUEST	
36	-->		AUTHENTICATION RESPONSE	
37	<--		SECURITY MODE COMMAND	
38	-->		SECURITY MODE COMPLETE	
39	-->		CP-DATA	Contains RP-DATA RPDU (SMS-COMMAND TPDU) which shall contain the correct TP-MR
40	<--		CP-ACK	
41	<--		CP-DATA	Contains RP-ACK RPDU

Step	Direction		Message	Comments
	UE	SS		
42	-->		CP-ACK	RRC connection is released.
43	<--		RRC CONNECTION RELEASE	
44	-->		RRC CONNECTION RELEASE COMPLETE	
45	UE		The UE is made to send an SMS-COMMAND	message requiring to delete the previously submitted SM.
46	-->		RRC CONNECTION REQUEST	CCCH
47	<--		RRC CONNECTION SETUP	CCCH
48	-->		RRC CONNECTION SETUP COMPLETE	DCCH
49	-->		CM SERVICE REQUEST	
50	<--		AUTHENTICATION REQUEST	
51	-->		AUTHENTICATION RESPONSE	
52	<--		SECURITY MODE COMMAND	
53	-->		SECURITY MODE COMPLETE	
54	-->		CP-DATA	Contains RP-DATA RPDU (SMS-COMMAND TPDU) which shall contain the correct TP-MR
55	<--		CP-ACK	Contains RP-ACK RPDU
56	<--		CP-DATA	
57	-->		CP-ACK	RRC connection is released.
58	<--		RRC CONNECTION RELEASE	
59	-->		RRC CONNECTION RELEASE COMPLETE	

## Specific Message Contents

## SMS SUBMIT TPDU

Information element	Comment Value
TP-SRR	status report is requested "1"B

## SMS-STATUS-REPORT TPDU (SS to UE in step 23):

Information element	Comment Value
TP-MR	same as previous SMS-SUBMIT
TP-MMS	no more messages "1"B
TP-SRQ	result of SMS-SUBMIT "0"B
TP-RA	same as the Destination address of the SMS-SUBMIT
TP-ST	SM received "00000000"B

## first SMS-COMMAND TPDU (UE to SS in step 39)

Information element	Comment Value
TP-MR	TP-MR in previous SMS-SUBMIT plus "1"
TP-SRR	status report requested "1"B
TP-CT	Enquiry relating to previously submitted short message "00000000"B
TP-MN	not checked (TP-MR in previous SMS-SUBMIT)

second SMS-COMMAND TPDU (UE to SS in step 54)

Information element	Comment Value
TP-MR TP-CT TP-MN	TP-MR in previous SMS-COMMAND plus "1" Delete previously submitted short message "00000010"B not checked (TP-MR in previous SMS-SUBMIT)

#### 16.1.4.4 Test requirements

After step 23 UE accept a SMS-STATUS-REPORT TPDU.

After step 38 UE shall send a SMS-COMMAND TPDU with the correct TP-Message-Reference.

After step 53 UE shall send a SMS-COMMAND TPDU with the correct TP-Message-Reference.

### 16.1.5 Test of message class 0 to 3

The tests under this subclause only apply to a UE capable of displaying short messages (see ICS/IXIT).

#### 16.1.5.1 Short message class 0

##### 16.1.5.1.1 Conformance requirement

When a mobile terminated message is class 0 and the UE has the capability of displaying short messages, the UE shall display the message immediately and send an acknowledgement to the SC when the message has successfully reached the UE irrespective of whether there is memory available in the USIM or ME. The message shall not be automatically stored in the USIM or ME.

#### References

TS 23.038, clause 4.

##### 16.1.5.1.2 Test purpose

To verify that the UE will accept and display but not store a class 0 message, and that it will accept and display a class 0 message if its message store is full.

NOTE: failure of this test in a UE could cause it to reject a class 0 message when its SMS memory becomes full. This could lead to unwanted repetitions between the UE and the service centre.

##### 16.1.5.1.3 Method of test

#### Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in the idle updated state;
  - the UE message store shall be empty.

#### Related ICS/IXIT Statements

Support for Short message MT/PP.

Description of the basic procedures to display a mobile terminated short message.

The value of timer TC1M.

Whether SMS messages are stored in the USIM and/or the ME.

#### Test procedure

- a) The SS sends a class 0 message by using the method described in step a) of subclause 16.1.1 but with the TPDU described in this subclause.
- b) The UE message store shall be filled (for example by using the method of subclause 16.1.3 test of the memory available notification) with the same SMS-DELIVER TPDU except that TP-DCS is set to class 1.
- c) The SS sends a class 0 message as in step a).

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			Mobile terminated establishment of RRC connection	See TS34.108
2	-->		PAGING RESPONSE	
3	<--		AUTHENTICATION REQUEST	
4	-->		AUTHENTICATION RESPONSE	
5	<--		SECURITY MODE COMMAND	
6	-->		SECURITY MODE COMPLETE	
7	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU), Class 0 Short Message
8	-->		CP-ACK	
9	-->		CP-DATA	Contains RP-ACK RPDU.
10	<--		CP-ACK	
11	<--		RRC CONNECTION RELEASE	
12	-->		RRC CONNECTION RELEASE COMPLETE	
13		UE		The content of the short message shall be displayed by the ME. The UE shall not store the message. This can be checked by verifying that it is impossible to retrieve any short messages from the UE message store.
14		SS		The UE message store shall be filled (for example by using the method of 16.1.3) with Class 1 SMS-DELIVER TPDU.
15			Mobile terminated establishment of RRC connection	See TS34.108
16	-->		PAGING RESPONSE	
17	<--		AUTHENTICATION REQUEST	
18	-->		AUTHENTICATION RESPONSE	
19	<--		SECURITY MODE COMMAND	
20	-->		SECURITY MODE COMPLETE	
21	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU), Class 0 Short Message
22	-->		CP-ACK	
23	-->		CP-DATA	Contains RP-ACK RPDU.
24	<--		CP-ACK	
25	<--		RRC CONNECTION RELEASE	
26	-->		RRC CONNECTION RELEASE COMPLETE	
27		UE		The content of the short message shall be displayed by the ME.

### Specific Message Contents

SMS-DELIVER TPDU (containing a class 0 message) (SS to UE)

Information element	Comment	Value
TP-DCS	default alphabet, class 0	"1111 0000"B

SMS-DELIVER TPDU (containing a class 1 message to fill the UE message store) (SS to UE)

Information element	Comment	Value
TP-DCS	default alphabet, class 1	"1111 0001"B

#### 16.1.5.1.4 Test requirements

After step 7 UE shall accept and display but not store a class 0 message.

After step 21 UE shall accept and display a class 0 message.

### 16.1.5.2 Test of class 1 short messages

This test shall apply to UEs which support:

- storing of received Class 1 Short Messages; and
- displaying of stored Short Messages.

#### 16.1.5.2.1 Conformance requirement

When a mobile terminated message is class 1, the UE shall send an acknowledgement to the SC when the message has successfully reached the UE and can be stored, either in the ME or in the USIM.

### References

TS 23.038, clause 4.

#### 16.1.5.2.2 Test purpose

This procedure verifies that the UE acts correctly on receiving a class 1 message, i.e. that it stores the message in the ME or USIM and sends an acknowledgement (at RP and CP-Layer).

#### 16.1.5.2.3 Method of test

##### Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in the idle updated state;
  - the UE message store shall be empty;

- for storing of class 1 Short Messages, the UE shall be set up to store Short Messages in the ME memory (by way of MMI, as described in ICS/IXIT statement).

#### Related ICS/IXIT Statements

Support for Short message MT/PP.

Description of the basic procedures to display a mobile terminated short message.

The value of timer TC1M.

Whether SMS messages are stored in the USIM and/or the ME.

#### Test procedure

- The SS delivers a Short Message of class 1 to the UE as specified in subclause 16.1.1, step a).
- The Short Message is recalled (e.g. by means of the MMI).

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			Mobile terminated establishment of RRC connection	See TS34.108
2		-->	PAGING RESPONSE	
3	<--		AUTHENTICATION REQUEST	
4		-->	AUTHENTICATION RESPONSE	
5	<--		SECURITY MODE COMMAND	
6		-->	SECURITY MODE COMPLETE	
7	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU), Class 1 Short Message
8		-->	CP-ACK	
9		-->	CP-DATA	Contains RP-ACK RPDU.
10	<--		CP-ACK	
11	<--		RRC CONNECTION RELEASE	
12		-->	RRC CONNECTION RELEASE COMPLETE	
13	UE			The short message shall be recalled and displayed at the UE.

#### Specific Message Contents

SMS-DELIVER TPDU (containing a class 1 message) (SS to UE)

Information element	Comment	Value
TP-DCS	default alphabet, class 1	"1111 0001"B

#### 16.1.5.2.4 Test requirements

After step 7 UE shall store the message in the ME or USIM and send an acknowledgement.

### 16.1.5.3 Test of class 2 short messages

#### 16.1.5.3.1 Definition

Class 2 Short Messages are defined as USIM specific, and the UE shall ensure that a message of this class is stored on the USIM.

#### 16.1.5.3.2 Conformance requirement

When a mobile terminated message is Class 2, the UE shall ensure that the message has been correctly transferred to the SMS data field in the USIM before sending an acknowledgement to the SC. The UE shall return a "protocol error, unspecified" error message if the short message cannot be stored in the USIM and there is other short message storage available at the UE. If all the short message storage at the UE is already in use, the UE shall return "memory capacity exceeded".

#### Reference(s)

TS 23.040, subclause 9.2.3.10; TS 23.038, clause 4. TS 34.108, subclause 6.11.3.2.27

#### 16.1.5.3.3 Test purpose

This procedure verifies that the UE acts correctly on receiving a class 2 message, i.e. that it stores the message correctly in the USIM, and if this is not possible, returns a protocol error message, with the correct error cause, to the network.

There are 2 cases:

- 1) if the UE supports storing of short messages in the USIM and in the ME, and storage in the ME is not full, and the short message cannot be stored in the USIM, the error cause shall be "protocol error, unspecified";
- 2) if the UE supports storing of short messages in the USIM and not in the ME, and storage in the ME is not full, and the short message cannot be stored in the USIM, the error cause shall be "memory capacity exceeded".

NOTE: If the UE supports storing of short messages in the USIM and the ME, and storage in the ME is full, and the short message cannot be stored in the USIM, the error cause shall be "memory capacity exceeded". This case is not tested in this test.

#### 16.1.5.3.4 Method of test

##### Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in the idle updated state;
  - the ME message store shall be empty;
  - the ME shall be connected to the USIM simulator. The following shall be present in the USIM simulator:
    - EF<sub>SMS</sub> with at least two free records and one full record;
    - EF<sub>SMSstatus</sub> with SMS "Memory Cap. Exceed" notification flag set to "memory available";
    - Service no. 4 (SMS) in EF<sub>SST</sub> set to allocated and activated;
    - for storing of Class 1 Short Messages the UE shall be set up to store Short Messages in the ME memory (by way of MMI, as described in ICS/IXIT statement).



## Related ICS/IXIT Statements

Support for Short message MT/PP.

The value of timer TC1M.

Whether SMS messages are stored in the USIM and/or the ME.

## Test procedure

- a) The SS delivers a Short Message of class 2 to the UE as specified in subclause 16.1.1, step b).
- b) Following an attempt by the ME to store the short message in a free record of EF<sub>SMS</sub> in the USIM, the USIM simulator returns the status response "OK" ("90 00").
- c) Step a) is repeated.
- d) Following an attempt by the ME to store the short message in a free record of EF<sub>SMS</sub> in the USIM, the USIM simulator returns the status response "memory problem" ("92 40").
- e) The USIM simulator indicates if an attempt was made in steps a) and c) to store the messages and if the messages are stored according to the requirement.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		<	Mobile terminated establishment of RRC connection	See TS34.108
2	-->		PAGING RESPONSE	
3	<--		AUTHENTICATION REQUEST	
4	-->		AUTHENTICATION RESPONSE	
5	<--		SECURITY MODE COMMAND	
6	-->		SECURITY MODE COMPLETE	
7	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU), Class 2 Short Message
8	-->		CP-ACK	
9		ME		The ME shall correctly store the short message in a free record of EF <sub>SMS</sub> in the USIM, i.e. -the ME shall use a free record - the first byte of the record shall indicate "message received by UE from network" <ul style="list-style-type: none"> <li>- the TS-Service-Centre-Address shall be correctly stored</li> <li>- the TPDU shall be identical to that sent by the SS</li> <li>- bytes following the TPDU shall be set to "FF"</li> </ul>
10		USIM		The USIM simulator returns the status response "OK" ("90 00"). The USIM simulator shall indicate if an attempt was made by the ME to store the short message in the USIM.
11	-->		CP-DATA	Contains RP-ACK RPDU.
12	<--		CP-ACK	
13	<--		RRC CONNECTION RELEASE	
14	-->		RRC CONNECTION RELEASE COMPLETE	
15			Mobile terminated establishment of RRC connection	See TS34.108

Step	Direction		Message	Comments
	UE	SS		
16	-->		PAGING RESPONSE	Contains RP-DATA RPDU (SMS DELIVER TPDU), Class 2 Short Message
17	<--		AUTHENTICATION REQUEST	
18	-->		AUTHENTICATION RESPONSE	
19	<--		SECURITY MODE COMMAND	
20	-->		SECURITY MODE COMPLETE	
21	<--		CP-DATA	
22	-->		CP-ACK	The ME shall attempt to store the short message in a free record of EFSMS in the USIM. The USIM simulator returns the status response "memory problem" ("92 40"). The USIM simulator shall indicate if an attempt was made by the ME to store the short message in the USIM. Contains RP-ERROR RPDU with error cause "protocol error, unspecified" if the UE supports storing of short messages in the ME, or error cause "memory capacity exceeded" if not.
23	ME			
24	USIM			
25	-->		CP-DATA	
26	<--		CP-ACK	
27	<--		RRC CONNECTION RELEASE	
28	-->		RRC CONNECTION RELEASE COMPLETE	

### Specific Message Contents

#### SMS-DELIVER TPDU (containing a class 2 message) (SS to UE)

Information element	Comment	Value
TP-DCS	default alphabet, class 2	"1111 0010"B

#### 16.1.5.3.4 Test requirements

After step 10 UE shall confirm that the short message is stored in the USIM and send CP-DATA containing RP-ACK RPDU.

After step 24 UE shall confirm that the short message cannot be stored in the USIM and send CP-DATA containing RP-ERROR RPDU. If UE supports storing of short message in the ME, the error cause of RP-ERROR RPDU shall be "protocol error, unspecified", and if not the error cause of RP-ERROR RPDU shall be "memory capacity exceeded"

#### 16.1.5.4 Test of class 3 short messages

For further study.

#### 16.1.6 Test of short message type 0

For further study.

## 16.1.7 Test of the replace mechanism for SM type 1-7

### 16.1.7.1 Definition

### 16.1.7.2 Conformance requirement

On receipt of a short message, the UE shall check to see if the associated Protocol Identifier contains a Replace Short Message Type code. If such a code is present, then the UE will check the associated SC address (RP-OA) and originating address (TP-OA) and replace any existing stored message having the same Protocol Identifier code, SC address and originating address with the new short message.

### Reference(s)

TS 23.040; subclause 9.2.3.9.

### 16.1.7.3 Test purpose

This procedure verifies the correct implementation of the replace mechanism for Replace Short Messages.

### 16.1.7.4 Method of test

#### Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in the idle updated state;
  - the UE message store shall be empty.

#### Related ICS/IXIT Statements

Support for Short message MT/PP.

Description of the basic procedures to display a mobile terminated short message.

The value of timer TC1M.

#### Test procedure

- a) Two different numbers n and m are drawn randomly between 1 and 7. Two different addresses for TP-Originating-Address (TPOA1 and TPOA2) are drawn. Two different addresses for RP-Originating-Address (RPOA1 and RPOA2) are drawn.
- b) The SS delivers a short message to the UE as specified in subclause 16.1.1 step a). In the SMS-DELIVER TPDU, the TP-Protocol-Identifier parameter is "Replace Short Message Type n", the TP-Originating-Address is TPOA1, and the RP-Originating-Address is RPOA1.
- c) Step b) is repeated but with a different TP-Originating-Address (TPOA2), and different contents of TP-User-Data in the SMS-DELIVER TPDU. The other parameters are the same as in step b).
- d) Step c) is repeated but with RPOA2 in the RP-Originating-Address, and contents of TP-User-Data different from the former two messages. The other parameters are the same as in step c).
- e) Step d) is repeated but with the TP-Protocol-Identifier equal to "Replace Short Message Type m", and contents of TP-User-Data different from the former three messages. The other parameters are the same as in step d).
- f) Step e) is repeated but the contents of TP-User-Data are different from that used in step e).

g) The SS prompts the operator to display the Short Messages stored in the UE.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			Mobile terminated establishment of RRC connection	See TS34.108
2	-->		PAGING RESPONSE	
3	<--		AUTHENTICATION REQUEST	
4	-->		AUTHENTICATION RESPONSE	
5	<--		SECURITY MODE COMMAND	
6	-->		SECURITY MODE COMPLETE	
7	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU) TP-PID is "Replace Short Message Type n", TP-OA is TPOA1 and RP-OA is RPOA1
8	-->		CP-ACK	
9	-->		CP-DATA	Contains RP-ACK RPDU.
10	<--		CP-ACK	
11	<--		RRC CONNECTION RELEASE	
12	-->		RRC CONNECTION RELEASE COMPLETE	
13			Mobile terminated establishment of RRC connection	See TS34.108
14	-->		PAGING RESPONSE	
15	<--		AUTHENTICATION REQUEST	
16	-->		AUTHENTICATION RESPONSE	
17	<--		SECURITY MODE COMMAND	
18	-->		SECURITY MODE COMPLETE	
19	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU) TP-PID is "Replace Short Message Type n", TP-OA is TPOA2 and RP-OA is RPOA1, TP-UD different from step 7
20	-->		CP-ACK	
21	-->		CP-DATA	Contains RP-ACK RPDU.
22	<--		CP-ACK	
23	<--		RRC CONNECTION RELEASE	
24	-->		RRC CONNECTION RELEASE COMPLETE	
25			Mobile terminated establishment of RRC connection	See TS34.108
26	-->		PAGING RESPONSE	
27	<--		AUTHENTICATION REQUEST	
28	-->		AUTHENTICATION RESPONSE	
29	<--		SECURITY MODE COMMAND	
30	-->		SECURITY MODE COMPLETE	
31	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU) TP-PID is "Replace Short Message Type n", TP-OA is TPOA2 and RP-OA is RPOA2, TP-UD different from step 7 and 19
32	-->		CP-ACK	
33	-->		CP-DATA	Contains RP-ACK RPDU.

Step	Direction		Message	Comments
	UE	SS		
34	<--		CP-ACK	See TS34.108
35	<--		RRC CONNECTION RELEASE	
36	-->		RRC CONNECTION RELEASE COMPLETE	
37			Mobile terminated establishment of RRC connection	
38	-->		PAGING RESPONSE	
39	<--		AUTHENTICATION REQUEST	
40	-->		AUTHENTICATION RESPONSE	
41	<--		SECURITY MODE COMMAND	
42	-->		SECURITY MODE COMPLETE	
43	<--		CP-DATA	
44	-->		CP-ACK	Contains RP-DATA RPDU (SMS DELIVER TPDU) TP-PID is "Replace Short Message Type m", TP-OA is TPOA2 and RP-OA is RPOA2, TP-UD different from step 7, 19 and 31
45	-->		CP-DATA	
46	<--		CP-ACK	
47	<--		RRC CONNECTION RELEASE	
48	-->		RRC CONNECTION RELEASE COMPLETE	
49			Mobile terminated establishment of RRC connection	See TS34.108
50	-->		PAGING RESPONSE	Contains RP-DATA RPDU (SMS DELIVER TPDU) TP-PID is "Replace Short Message Type m", TP-OA is TPOA2 and RP-OA is RPOA2, TP-UD different from step 43
51	<--		AUTHENTICATION REQUEST	
52	-->		AUTHENTICATION RESPONSE	
53	<--		SECURITY MODE COMMAND	
54	-->		SECURITY MODE COMPLETE	
55	<--		CP-DATA	
56	-->		CP-ACK	
57	-->		CP-DATA	
58	<--		CP-ACK	
59	<--		RRC CONNECTION RELEASE	
60	-->		RRC CONNECTION RELEASE COMPLETE	
61	SS			Prompts the operator to display the Short Messages stored in the UE. Only the Short Messages delivered in step 7, 19, 31 and 55 shall be retrievable and displayed

## Specific Message Contents

## SMS-DELIVER TPDU

Information element	CommentValue
TP-MMS TP-PID	no more messages are waiting in SC "1"B binary 01000xxx, xxx represents n resp. m (see test method description)

### 16.1.7.5 Test requirements

After step 60 only the Short Messages delivered in step 7, 19, 31 and 55 shall be retrieved and displayed.

## 16.1.8 Test of the reply path scheme

### 16.1.8.1 Definition

### 16.1.8.2 Conformance requirement

When a replying UE receives an original mobile terminated short message it has:

- originating SME = TP-Originating Address in the SMS-DELIVER TPDU;
- original SC = RP-Originating Address in the RP-MT-DATA.

When submitting the reply mobile originated short message, the replying UE should use parameters as follows:

- TP-Destination Address in SMS-SUBMIT TPDU = originating SME;
- RP-Destination Address in RP-MO-DATA = original SC.

### Reference(s)

TS 23.040 Annex D.5,D.6

### 16.1.8.3 Test purpose

This procedure verifies that the UE is able to send a Reply Short Message back to the correct originating SME even if in the meantime it receives another Short Message.

### 16.1.8.4 Method of test

#### Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in the idle updated state;
  - the UE message store shall be empty.

#### Related ICS/IXIT Statements

Support for Short message MT/PP.

Support for Short message MO/PP.

Description of the basic procedures to display a mobile terminated short message.

Description of the basic procedures to send a mobile originated short message.

The value of timer TC1M.

## Test procedure

- a) The SS delivers a Short Message as specified in subclause 16.1.1, step b) with TP-Reply-Path set to 1.
- b) Step a) is repeated but with:
  - different TP-Originating-Address for the originating SME;
  - different RP-Originating-Address for the original SC; and
  - different message contents TP-User-Data.
- c) One of the two Short Messages is displayed (e.g. by means of the MMI) and the Reply Short Message is submitted (e.g. by means of the MMI).
- d) step c) is repeated for the other Short Message.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			Mobile terminated establishment of RRC connection	See TS34.108
2	-->		PAGING RESPONSE	
3	<--		AUTHENTICATION REQUEST	
4	-->		AUTHENTICATION RESPONSE	
5	<--		SECURITY MODE COMMAND	
6	-->		SECURITY MODE COMPLETE	
7	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU) TP-RP set to 1
8	-->		CP-ACK	Sent within TC1M after step 7
9	-->		CP-DATA	Contains RP-ACK RPDU.
10	<--		CP-ACK	
11	<--		RRC CONNECTION RELEASE	
12	-->		RRC CONNECTION RELEASE COMPLETE	
13			Mobile terminated establishment of RRC connection	See TS34.108
14	-->		PAGING RESPONSE	
15	<--		AUTHENTICATION REQUEST	
16	-->		AUTHENTICATION RESPONSE	
17	<--		SECURITY MODE COMMAND	
18	-->		SECURITY MODE COMPLETE	
19	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU) TP-OA, RP-OA and TP-UD different from step 7
20	-->		CP-ACK	Sent within TC1M after step 7
21	-->		CP-DATA	Contains RP-ACK RPDU.
22	<--		CP-ACK	
23	<--		RRC CONNECTION RELEASE	
24	-->		RRC CONNECTION RELEASE COMPLETE	
25	UE			One of the two Short Messages is displayed and the Reply Short Message is submitted.
26	<--		SYSTEM INFORMATION	BCCH
27	-->		RRC CONNECTION REQUEST	CCCH
28	<--		RRC CONNECTION SETUP	CCCH

Step	Direction		Message	Comments
	UE	SS		
29	-->		RRC CONNECTION SETUP COMPLETE	DCCH
30	-->		CM SERVICE REQUEST	
31	<--		AUTHENTICATION REQUEST	
32	-->		AUTHENTICATION RESPONSE	
33	<--		SECURITY MODE COMMAND	
34	-->		SECURITY MODE COMPLETE	
35	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU) RP-DA = RP-OA corresponding to the message displayed TP-DA = TP-OA corresponding to the message displayed
36	<--		CP-ACK	Sent within TC1M after step 35
37	<--		CP-DATA	Contains RP-ACK RPDU
38	SS			Waits max 25 seconds for CP-ACK
39	-->		CP-ACK	
40	<--		RRC CONNECTION RELEASE	RRC connection is released.
	-->		RRC CONNECTION RELEASE COMPLETE	
41	UE			The other Short Message is displayed and the Reply Short Message is submitted.
42	<--		SYSTEM INFORMATION	BCCH
43	-->		RRC CONNECTION REQUEST	CCCH
44	<--		RRC CONNECTION SETUP	CCCH
45	-->		RRC CONNECTION SETUP COMPLETE	DCCH
46	-->		CM SERVICE REQUEST	
47	<--		AUTHENTICATION REQUEST	
48	-->		AUTHENTICATION RESPONSE	
49	<--		SECURITY MODE COMMAND	
50	-->		SECURITY MODE COMPLETE	
51	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU) RP-DA = RP-OA corresponding to the Message displayed TP-DA = TP-OA corresponding to the message displayed
52	<--		CP-ACK	Sent within TC1M after step 51
53	<--		CP-DATA	Contains RP-ACK RPDU
54	SS			Waits max 25 seconds for CP-ACK
55	-->		CP-ACK	
56	<--		RRC CONNECTION RELEASE	RRC connection is released.
57	-->		RRC CONNECTION RELEASE COMPLETE	

### Specific Message Contents

#### SMS-DELIVER TPDU

Information element	Comment	Value
TP-MMS	no more messages are waiting in SC	"1"B
TP-RP	Reply Path exists	"1"B

#### 16.1.8.5 Test requirements

After step 34 UE shall send the Reply Short Message corresponding to one of two previously received short messages.

After step 50 UE shall send the Reply Short Message corresponding to the other of two previously received short messages.



## 16.1.9 Multiple SMS mobile originated

### 16.1.9.1 UE in idle mode

This test applies to UE supporting the ability of sending multiple short messages on the same RRC connection when there is no call in progress.

#### 16.1.9.1.1 Conformance requirements

When the UE chooses to use the same RRC connection to send another short message or a memory available notification, then:

- the UE shall transmit a CM SERVICE REQUEST for the new CM connection before the final CP-ACK (e.g. the one that acknowledges the CP-DATA that carried the RP-ACK) for the old MM connection is transmitted;
- before transmission of the first CP-DATA on the new MM connection, the UE shall transmit the CP-ACK for the old MM connection;
- the Transaction Identifier used on the new MM connection shall be different to that used on the old MM connection; and
- the UE shall not initiate establishment of the new MM connection before the final CP-DATA (e.g. the one carrying the RP-ACK) has been received.

#### Reference

- TS 23.040; subclause 3.1.
- TS 24.011; subclause 5.4.

#### 16.1.9.1.2 Test purpose

To verify that the UE is able to correctly send multiple short messages on the same RRC connection when using a DCCH.

#### 16.1.9.1.3 Method of test

##### Initial conditions

- System simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in "Idle, updated" state;
  - the SMS message storage shall be empty.

##### Related ICS/IXIT statements

Support for multiple short message MO/PP on the same RRC connection.

Description of how to enter multiple SMS.

Description of the basic procedures to display a mobile originated short message.

Whether SMS messages are stored in the USIM and/or the ME.

Foreseen final state of UE

Idle, updated.

### Test procedure

- a) The UE shall be set up to send 3 short messages as multiple SM to the SS. The SS answers correctly to RRC CONNECTION REQUEST on CCCH and then performs the authentication.
- b) After receiving SECURITY MODE COMMAND UE shall send SECURITY MODE COMPLETE.
- c) The SS responds to the CP-DATA containing RP-DATA RPDU (SMS SUBMIT TPDU) from the UE with a CP-ACK message followed by a CP-DATA message containing the correct RP-ACK RPDU. The Transaction Identifier used on this MM connection is 'x'.
- d) The UE shall transmit a CM SERVICE REQUEST for the new CM connection (for the second short message) before the final CP-ACK (the one that acknowledges the CP-DATA that carried the RP-ACK before) for the old MM connection is transmitted. The UE shall not initiate establishment of the new MM connection before the final CP-DATA (i.e. the one carrying the RP-ACK for the first short message) has been received. Before transmission of the first CP-DATA on the new MM connection, the UE shall transmit the CP-ACK for the old MM connection. The Transaction Identifier used on the new MM connection shall be y, where  $y < x$  (see procedure c)).
- e) The SS waits a maximum of 5 seconds after receiving the CM SERVICE REQUEST for the CP-ACK message from the UE.
- f) The SS responds to the CP-DATA containing RP-DATA RPDU (SMS SUBMIT TPDU) from the UE with a CP-ACK message followed by a CP-DATA message containing the correct RP-ACK RPDU.
- g) The UE shall transmit a CM SERVICE REQUEST for the new CM connection (for the third short message) before the final CP-ACK (the one that acknowledges the CP-DATA that carried the RP-ACK before) for the old MM connection is transmitted. Before transmission of the first CP-DATA on the new MM connection, the UE shall transmit the CP-ACK for the old MM connection. The Transaction Identifier used on the new MM connection shall be z, where  $z < y$  (see procedure d)). The UE shall not initiate establishment of the new MM connection before the final CP-DATA (i.e. the one carrying the RP-ACK for the second short message) has been received.
- h) The SS waits a maximum of 5 seconds after receiving the CM SERVICE REQUEST for the CP-ACK message from the UE.
- i) The SS responds to the CP-DATA containing RP-DATA RPDU (SMS SUBMIT TPDU) from the UE with a CP-ACK message followed by a CP-DATA message containing the correct RP-ACK RPDU.
- j) The SS waits a maximum of 5 seconds after sending CP-DATA for the CP-ACK message from the UE.
- k) The SS sends a RRC CONNECTION RELEASE to the UE.

### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<--		SYSTEM INFORMATION	BCCH
2	-->		RRC CONNECTION REQUEST	CCCH
3	<--		RRC CONNECTION SETUP	CCCH
4	-->		RRC CONNECTION SETUP COMPLETE	DCCH
5	-->		CM SERVICE REQUEST	
6	<--		AUTHENTICATION REQUEST	
7	-->		AUTHENTICATION RESPONSE	
8	<--		SECURITY MODE COMMAND	
9	-->		SECURITY MODE COMPLETE	

Step	Direction		Message	Comments
	UE	SS		
10	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU). The Transaction Identifier used in steps 10, 11, 12 and 14 shall be x.
11	<--		CP-ACK	Contains RP-ACK RPDU
12	<--		CP-DATA	
13	-->		CM SERVICE REQUEST	CM service type set to "Short message transfer".
14	-->		CP-ACK	Shall be sent within 5 seconds of step 13
15	<--		CM SERVICE ACCEPT	Contains RP-DATA RPDU (SMS SUBMIT TPDU). The Transaction Identifier used in steps 16, 17, 18 and 20 shall be y where y <> x (see step 10).
16	-->		CP-DATA	
17	<--		CP-ACK	Contains RP-ACK RPDU
18	<--		CP-DATA	
19	-->		CM SERVICE REQUEST	CM service type set to "Short message transfer".
20	-->		CP-ACK	Shall be sent within 5 seconds of step 19
21	<--		CM SERVICE ACCEPT	Contains RP-DATA RPDU (SMS SUBMIT TPDU). The Transaction Identifier used in steps 22, 23, 24 and 25 shall be z, where z <> y (see step 16).
22	-->		CP-DATA	
23	<--		CP-ACK	Contains RP-ACK RPDU
24	<--		CP-DATA	
25	-->		CP-ACK	Shall be sent within 5 seconds of step 24
26	<--		RRC CONNECTION RELEASE	RRC connection is released.
27	-->		RRC CONNECTION RELEASE COMPLETE	

#### 16.1.9.1.4 Test requirements

In step 12 the UE shall transmit a CM SERVICE REQUEST for the new CM connection (for the second short message) before the final CP-ACK for the old MM connection is transmitted.

In step 13 the UE shall transmit a CM SERVICE REQUEST for the new CM connection (for the third short message) before the final CP-ACK for the old MM connection is transmitted.

#### 16.1.9.2 UE in active mode

This test applies to UE supporting the ability of sending concatenated multiple short messages when there is a call in progress.

##### 16.1.9.2.1 Conformance requirements

When the UE chooses to use the same RRC connection to send another short message or a memory available notification, then:

- the UE shall transmit a CM SERVICE REQUEST for the new CM connection before the final CP-ACK (e.g. the one that acknowledges the CP-DATA that carried the RP-ACK) for the old MM connection is transmitted;
- before transmission of the first CP-DATA on the new MM connection, the UE shall transmit the CP-ACK for the old MM connection;
- the Transaction Identifier used on the new MM connection shall be different to that used on the old MM connection; and
- the UE shall not initiate establishment of the new MM connection before the final CP-DATA (e.g. the one carrying the RP-ACK) has been received.

## Reference

- TS 23.040; subclause 3.1.
- TS 24.011; subclause 5.4.

### 16.1.9.2.2 Test purpose

To verify that the UE is able to correctly concatenate multiple short messages on the same RRC connection when sent parallel to a call.

### 16.1.9.2.3 Method of test

#### Initial conditions

- System simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in "Idle, updated" state;
  - the SMS message storage shall be empty.

#### Related ICS/IXIT statements

Support for multiple short message MO/PP on the same RRC connection.

Description of how to enter multiple SMS.

Description of the basic procedures to display a mobile originated short message.

Support for state U10 of call control.

Whether SMS messages are stored in the USIM and/or the ME.

#### Foreseen final state of UE

Idle, updated.

#### Test procedure

- A data or speech call is established on a DTCH with the SS and the state U10 of call control is entered. The UE is set up to send 3 short messages as multiple SM to the SS. After the reception of the CM SERVICE REQUEST, the SS sends a CM SERVICE ACCEPT message.
- Steps c) to k) of the test procedure in subclause 16.1.9.1.3 are repeated.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		A data or speech call is established on a DTCH and the state U10 of call control is entered. The UE is set up to send 3 short messages as multiple SM Sent in a layer 2 frame on the DCCH. CM service type set to "short message transfer"
2	UE			
3	-->		CM SERVICE REQUEST	
4	<--		CM SERVICE ACCEPT	
7	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU). The Transaction Identifier used in steps 7, 8, 9 and 11 shall be x.
8	<--		CP-ACK	Contains RP-ACK RPDU Sent in a layer 2 frame on the DCCH. CM service type set to "short message transfer" Shall be sent within 5 seconds of step 10
9	<--		CP-DATA	
10	-->		CM SERVICE REQUEST	
11	-->		CP-ACK	Contains RP-DATA RPDU (SMS SUBMIT TPDU). The Transaction Identifier used in steps 13, 14, 15 and 17 shall be y where y <> x (see step 7).
12	<--		CM SERVICE ACCEPT	
13	-->		CP-DATA	
14	<--		CP-ACK	
15	<--		CP-DATA	Contains RP-ACK RPDU Sent in a layer 2 frame on the DCCH. CM service type set to "short message transfer" Shall be sent within 5 seconds of step 16
16	-->		CM SERVICE REQUEST	
17	-->		CP-ACK	
18	<--		CM SERVICE ACCEPT	Contains RP-DATA RPDU (SMS SUBMIT TPDU). The Transaction Identifier used in steps 19, 20, 21 and 22 shall be z, where z <> y (see step 13).
19	-->		CP-DATA	
20	<--		CP-ACK	
21	<--		CP-DATA	
22	-->		CP-ACK	Contains RP-ACK RPDU Shall be sent within 5 seconds of step 21
23	<--		RRC CONNECTION RELEASE	RRC connection is released.
24	-->		RRC CONNECTION RELEASE COMPLETE	

#### 16.1.9.2.4 Test requirements

In step 9 the UE shall transmit a CM SERVICE REQUEST for the new CM connection (for the second short message) before the final CP-ACK for the old MM connection is transmitted.

In step 15 the UE shall transmit a CM SERVICE REQUEST for the new CM connection (for the third short message) before the final CP-ACK for the old MM connection is transmitted.

## 16.2 Short message service point to point on PS mode

All of test cases in this subclause are applied to the UE supported PS mode.

### 16.2.1 SMS mobile terminated

#### 16.2.1.1 Conformance requirements

An active UE shall be able to receive short message TPDU (SMS-DELIVER) at any time, independently of whether or not there is a PDP context in progress. A report will always be returned to the SC, confirming that the UE has received the short message.

## Reference

TS 23.040, subclause 3.1.

### 16.2.1.2 Test purpose

To verify the ability of a UE to receive and decode the SMS where provided for the point to point service.

### 16.2.1.3 Method of test

#### Initial Conditions

- System simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in "Idle, updated" state;
  - the SMS message storage shall be empty.

#### Related ICS/IXIT Statements

Support for Short message MT/PP.

Description of the basic procedures to display a mobile terminated short message.

The value of timer TC1M.

Whether SMS messages are stored in the USIM and/or the ME.

Support for session management state "PDP-ACTIVE".

#### Test procedure

- a) The SS initiates the establishment of RRC Connection. After the completion of RRC Connection the SS authenticates the UE and activates ciphering.  
  
After the SS receives SECURITY MODE COMPLETE, the SS sends a CP-DATA message. The information element of the CP-DATA message will be RP-DATA RPDU (SMS DELIVER TPDU).
- b) The SS waits a maximum of 25 seconds for the CP-ACK message and then a maximum of 60 seconds for the CP-DATA message containing the RP-ACK RPDU.
- c) The SS sends a CP-ACK to the UE within TC1M with no further CP-DATA messages and the SS initiates channel release.
- d) Steps a), b) and c) are repeated but the first CP-DATA message from the UE is not acknowledged. The second CP-DATA message from the UE is acknowledged by a CP-ACK within a time TC1M.
- e) Steps a) and b) are repeated. The SS is configured not to send CP-ACK. Then maximum 3 CP-DATA retransmissions may occur. After a duration of TC1M + 5 seconds after the last CP-DATA retransmission the SS then initiates the channel release. The 5 seconds is the appropriate time to wait to verify that the UE does not send more than the maximum allowed (3) CP-DATA retransmissions.
- f) The SMS message store shall be cleared manually by the operator.
- g) A PDP context is established with the SS and the state PDP-ACTIVE of session management is entered. The SS sends a PAGING TYPE 2.

The SS sends a CP-DATA message. The information element of the CP-DATA message will be RP-DATA RPDU (SMS DELIVER TPDU). The SS waits a maximum of 25 seconds for the CP-ACK message and then a maximum of 60 seconds for the CP-DATA message containing the RP-ACK RPDU.

- h) The SS sends a CP-ACK to the UE within TC1M with no further CP-DATA messages and the SS initiates channel release. The SMS message store shall be cleared manually by the operator.
- i) Steps g) and h) are repeated but the first CP-DATA message from the UE is not acknowledged. The second CP-DATA message from the UE is acknowledged by a CP-ACK within a time TC1M.
- j) Step g) is repeated. The SS is configured not to send CP-ACK. Then maximum 3 CP-DATA retransmissions may occur. After a duration of TC1M + 15 seconds after the last CP-DATA retransmission the SS initiates the channel release. The 15 seconds is the appropriate time to wait to verify that the UE does not send more than the maximum allowed (3) CP-DATA retransmissions (during PDP context in progress).
- k) A PDP context is established with the SS and the state PDP-ACTIVE of session management is entered. The PDP context is cleared by the SS with a disconnect message. (The PDP context deactivating is continued in parallel to the following exchange of messages related to SMS).

The SS sends a CP-DATA RPDU (SMS DELIVER TPDU) message. The information element of the CP-DATA message is RP-DATA.

The SS waits a maximum of 25 seconds for the CP-ACK message and then a maximum of 60 seconds for the CP-DATA message containing the RP-ACK RPDU.

The SS sends a CP-ACK to the UE within TC1M with no further CP-DATA messages and the SS initiates channel release.

The SMS message store shall be cleared manually by the operator.

- l) A PDP context is established with the SS and the state PDP-ACTIVE of session management is entered. After the SS sends a PAGING TYPE 2, the PDP context shall be cleared from the UE. (The PDP context deactivating is continued in parallel to the following exchange of messages related to SMS).

The SS sends a CP-DATA message. The information element of the CP-DATA message is RP-DATA RPDU (SMS DELIVER TPDU).

The SS waits a maximum of 25 seconds for the CP-ACK message and then a maximum of 60 seconds for the CP-DATA message containing the RP-ACK RPDU.

The SS sends a CP-ACK to the UE within TC1M with no further CP-DATA messages and the SS initiates channel release.

The SMS message store shall be cleared manually by the operator.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			Mobile terminated establishment of RRC connection	See TS34.108
2	-->		SERVICE REQUEST	
3	<--		AUTHENTICATION AND CIPHERING REQUEST	
4	-->		AUTHENTICATION AND CIPHERING RESPONSE	
5	<--		SECURITY MODE COMMAND	Contains RP-DATA RPDU (SMS DELIVER TPDU)
6	-->		SECURITY MODE COMPLETE	
7	<--		CP-DATA	Waits max 25 seconds for CP-ACK
8	SS			
9	-->		CP-ACK	Waits max 60 seconds for RP-ACK RPDU
10	SS			
11	-->		CP-DATA	
12	<--		CP-ACK	

Step	Direction		Message	Comments
	UE	SS		
13	UE			There should be no further CP-DATA messages until the UE aborts the RR connection (disconnection of layer 2). The UE shall indicate that an SM has arrived. If the UE provides the functionality to display MT messages, it is checked that the correct message is displayed See TS34.108
14	UE			
15			Mobile terminated establishment of RRC connection	
16	-->		SERVICE REQUEST	
17	<--		AUTHENTICATION AND CIPHERING REQUEST	
18	-->		AUTHENTICATION AND CIPHERING RESPONSE	
19	<--		SECURITY MODE COMMAND	
20	-->		SECURITY MODE COMPLETE	
21	<--		CP-DATA	
22	SS			
23	-->		CP-ACK	Contains RP-DATA RPDU (SMS DELIVER TPDU) Waits max 25 seconds for CP-ACK
24	SS			Waits max 60 seconds for RP-ACK RPDU
25	-->		CP-DATA	First CP-DATA from UE, contains RP-ACK RPDU
26	SS			First CP-DATA message not acknowledged by SS
27	-->		CP-DATA	Retransmitted CP-DATA from UE within twice TC1M, after step 25, contains RP-ACK RPDU
28	<--		CP-ACK	Second CP-DATA message is acknowledged
29	UE			There should be no further CP-DATA messages until the UE aborts the RRC connection
30	UE			The UE shall indicate that an SM has arrived. If the UE provides the functionality to display MT messages, it is checked that the correct message is displayed See TS34.108
31			Mobile terminated establishment of RRC connection	
32	-->		SERVICE REQUEST	
33	<--		AUTHENTICATION AND CIPHERING REQUEST	
34	-->		AUTHENTICATION AND CIPHERING RESPONSE	
35	<--		SECURITY MODE COMMAND	
36	-->		SECURITY MODE COMPLETE	
37	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU) Waits max 25 seconds for CP-ACK
38	SS			
39	-->		CP-ACK	Waits max 60 seconds for RP-ACK RPDU
40	SS			Contains RP-ACK RPDU
41	-->		CP-DATA	First CP-DATA message not acknowledged by SS
42	SS			Retransmitted CP-DATA from UE within twice TC1M after step 41, contains RP-ACK RPDU
43			CP-DATA	Retransmitted CP-DATA message not acknowledged by SS
44	SS			Depending upon the maximum number of CP-DATA retransmissions implemented, step 43 and 44 may be repeated.
45	UE			RRC connection is released after a duration of TC1M + 5 seconds after the last CP-DATA retransmission..
46	<--		RRC CONNECTION RELEASE	
47	-->		RRC CONNECTION RELEASE COMPLETE	
48	UE			The UE shall indicate that an SM has arrived. If the UE provides the functionality to display MT messages, it is checked that the correct message is displayed
49	SS			A PDP context is established with the SS and the state PDP-ACTIVE of session management is entered.
50			PAGING TYPE 2	
51	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU) Waits max 25 seconds for CP-ACK
52	SS			
53	-->		CP-ACK	
54	SS			Waits max 60 seconds for RP-ACK RPDU
55	-->		CP-DATA	Contains RP-ACK RPDU



Step	Direction		Message	Comments
	UE	SS		
56	<--		CP-ACK	Deactivates an existing PDP context.
57	<--		DEACTIVATE PDP CONTEXT REQUEST	
58	-->		DEACTIVATE PDP CONTEXT ACCEPT	
59	UE			The UE shall indicate that an SM has arrived. If the UE provides the functionality to display MT messages, it is checked that the correct message is displayed Clear the SMS message store A PDP context is established with the SS and the state PDP-ACTIVE of session management is entered.
60	UE			
61	SS			
62	<--		PAGING TYPE 2	Contains RP-DATA RPDU (SMS DELIVER TPDU) Waits max 25 seconds for CP-ACK
63	<--		CP-DATA	
64	SS			
65	-->		CP-ACK	Waits max 60 seconds for RP-ACK RPDU First CP-DATA from UE, contains RP-ACK RPDU First CP-DATA message not acknowledged by SS Retransmitted CP-DATA message within twice TC1M after step 67, contains RP-ACK RPDU
66	SS			
67	-->		CP-DATA	
68	SS			Second CP-DATA message is acknowledged Deactivates an existing PDP context.
69	-->		CP-DATA	
70	<--		CP-ACK	
71	<--		DEACTIVATE PDP CONTEXT REQUEST	
72	-->		DEACTIVATE PDP CONTEXT ACCEPT	
73	UE			
74	UE			There should be no further CP-DATA messages until the UE aborts the RRC connection The UE shall indicate that an SM has arrived. If the UE provides the functionality to display MT messages, it is checked that the correct message is displayed Clear the SMS message store A PDP context is established with the SS and the state PDP-ACTIVE of session management is entered.
75	UE			
76	SS			
77	<--		PAGING TYPE 2	Contains RP-DATA RPDU (SMS DELIVER TPDU) Waits max 25 seconds for CP-ACK
78	<--		CP-DATA	
79	SS			
80	-->		CP-ACK	Waits max 60 seconds for RP-ACK RPDU First CP-DATA from UE, contains RP-ACK RPDU First CP-DATA message not acknowledged by SS Transmitted CP-DATA message within twice TC1M after step 82, contains RP-ACK RPDU
81	SS			
82	-->		CP-DATA	
83	SS			Retransmitted CP-DATA message not acknowledged by SS Depending on the maximum number of CP-DATA retransmissions implemented, step 83-84 may be repeated. The maximum number of retransmissions may however not exceed three.
84	-->		CP-DATA	
85	SS			
86	UE			RRC CONNECTION is released after a duration of TC1M + 15 seconds after the last CP-DATA retransmission.
87	<--		RRC CONNECTION RELEASE	
88	-->		RRC CONNECTION RELEASE COMPLETE	
89	UE			The UE shall indicate that an SM has arrived. If the UE provides the functionality to display MT messages, it is checked that the correct message is displayed Clear the SMS message store A PDP context is established with the SS and the state PDP-ACTIVE of session management is entered.
90	UE			
91	SS			
92	<--		PAGING TYPE 2	Sent on DCCH associated with the DTCH The PDP context is deactivated by the SS. The PDP context deactivating is continued in parallel to the following exchange of messages related to SMS. Contains RP-DATA RPDU (SMS DELIVER TPDU) Waits max 25 seconds for CP-ACK
93	<--		DEACTIVATE PDP CONTEXT REQUEST	
94	<--		CP-DATA	
95	SS			
96	-->		CP-ACK	

Step	Direction		Message	Comments
	UE	SS		
97		SS		Waits max 60 seconds for RP-ACK RPDU
98	-->		CP-DATA	Contains RP-ACK RPDU
99	<--		CP-ACK	
100	UE			There should be no further CP-DATA messages until the UE aborts the RR connection.
101	UE			The UE shall indicate that an SM has arrived. If the UE provides the functionality to display MT messages, it is checked that the correct message is displayed
102	UE			Clear the SMS message store
103	SS			A PDP context is established with the SS and the state PDP-ACTIVE of session management is entered.
104	<--		PAGING TYPE 2	
105	-->		DEACTIVATE PDP CONTEXT REQUEST	The PDP context is deactivated by the UE. The PDP context deactivation is continued in parallel to the following
106	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU)
107	<--		DEACTIVATE PDP CONTEXT REQUEST COMPLETE	
108	-->		CP-ACK	shall be sent before 25 seconds after the start of step 106
109	SS			Waits max 60 seconds for RP-ACK RPDU
110	-->		CP-DATA	Contains RP-ACK RPDU
111	<--		CP-ACK	
112	UE			There should be no further CP-DATA messages until the UE aborts the RRC connection.
113	UE			The UE shall indicate that an SM has arrived. If the UE provides the functionality to display MT messages, it is checked that the correct message is displayed
114	UE			Clear the SMS message store

NOTE: Time values for SS wait time are chosen sufficiently high to be sure that the UE has enough time to respond to the different messages.

### Specific Message Contents

#### SMS DELIVER TPDU

Information element	CommentValue
TP-UDL	160
TP-UD (140 octets)	text of message (160 characters)

NOTE: The 160 characters in TP-UD shall include at least one occurrence of each character in the default alphabet (see TS 23.038, subclause 6.2.1).

#### 16.2.1.4 Test requirements

After step 7 UE shall receive SMS-DELIVER TPDU and send CP-ACK within 25 seconds and CP-DATA containing RP-ACK within 60 seconds.

After step 25 UE shall retransmit CP-DATA containing RP-ACK within twice TC1M.

After step 30 UE shall indicate that an SM has arrived.

After step 43 UE shall repeat CP-DATA retransmissions as many times as the decided maximum number.

After step 48 UE shall indicate that an SM has arrived.

After step 51 UE shall receive SMS-DELIVER TPDU and send CP-ACK within 25 seconds and CP-DATA containing RP-ACK within 60 seconds.

After step 67 UE shall retransmit CP-DATA containing RP-ACK within twice TC1M.

After step 73 UE shall indicate that an SM has arrived.

After step 78 UE shall repeat CP-DATA retransmissions as many times as the decided maximum number.

After step 89 UE shall indicate that an SM has arrived.

After step 94 UE shall receive SMS-DELIVER TPDU and send CP-ACK within 25 seconds and CP-DATA containing RP-ACK within 60 seconds.

After step 106 UE shall receive SMS-DELIVER TPDU and send CP-ACK within 25 seconds and CP-DATA containing RP-ACK within 60 seconds.

## 16.2.2 SMS mobile originated

### 16.2.2.1 Conformance requirements

An active UE shall be able to submit short message TPDU (SMS-SUBMIT) at any time, independently of whether or not there is a PDP context in progress.

#### Reference

TS 23.040, subclause 3.1.

### 16.2.2.2 Test purpose

To verify that the UE is able to correctly send a short message where the SMS is provided for the point to point service. The test also verifies that the UE is capable of simultaneously receiving a network originated SM whilst sending a mobile originated SM.

### 16.2.2.3 Method of test

#### Initial Conditions

- System simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in "Idle, updated" state;
  - the SMS message storage shall be empty.

#### Related ICS/IXIT Statements

Support for Short message MO/PP.

Description of the basic procedures to display a mobile originated short message.

Support for state PDP-ACTIVE of session management.

The value of timer TC1M.

Whether SMS messages are stored in the USIM and/or the ME.

Maximum length (characters) of a mobile originated short message.

#### Test procedure

- a) The UE shall be set up to send a SM to the SS. The SS responds to RRC CONNECTION REQUEST by allocating a CCCH. The SS receives RRC CONNECTION SETUP COMPLETE on DCCH and then performs the authentication.

- b) After receiving SECURITY MODE COMMAND UE shall send SECURITY COMMAND COMPLETE.
- c) The SS responds to the CP-DATA containing RP-DATA RPDU (SMS SUBMIT TPDU) from the UE with a CP-ACK message within TC1M followed by a CP-DATA message containing the correct RP-ACK RPDU. The SS waits a maximum of 25 seconds for the CP-ACK message.
- d) The SS sends a channel release message to the UE.
- e) Steps a) and b) are repeated. The SS is configured not to send the CP-ACK message. Then maximum 3 CP-DATA retransmissions may occur. After a duration of TC1M + 5 seconds after the last CP-DATA retransmission the SS initiates channel release. The 5 seconds is the appropriate time to wait to verify that the UE does not send more than the maximum CP-DATA retransmissions.
- f) Steps a) and b) are repeated. On receipt of the CP-DATA from the UE the SS sends a CP-ERROR message within TC1M containing a "Network Failure" cause. Then the SS initiates channel release.
- g) A PDP context is established with the SS and the state PDP-ACTIVE of session management is entered. The UE is setup to send an SM to the SS. After the reception of the SERVICE REQUEST, the SS sends a SERVICE ACCEPT message.
- h) The SS responds to the CP-DATA containing RP-DATA RPDU (SMS SUBMIT TPDU) from the UE with a CP-ACK message within TC1M followed by a CP-DATA message containing the correct RP-ACK RPDU. The SS waits a maximum of 25 seconds for the CP-ACK message. Then the SS sends a channel release message to the UE.
- i) Step g) is repeated. The SS is configured not to send the CP-ACK message. Then maximum 3 CP-DATA retransmissions may occur. After a duration of TC1M + 15 seconds after the last CP-DATA retransmission the SS initiates channel release. The 15 seconds is the appropriate time to wait to verify that the UE does not send more than the maximum CP-DATA retransmissions (during a PDP context in progress).
- j) The SS is configured to receive a mobile originated SM. Steps a) and b) are repeated and, using the end of the CP-DATA message from the UE as a trigger, the SS sends a SM to the UE. In this case a new transaction identifier shall be used in the CP messages of SMS mobile terminated.
- k) The UE is set up to send an SM to the SS. On receipt of the SERVICE REQUEST the SS sends a SERVICE REJECT message with the reject cause set to "GPRS services not allowed". After 5 seconds the SS initiates channel release.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<--		SYSTEM INFORMATION	BCCH
2	-->		RRC CONNECTION REQUEST	CCCH
3	<--		RRC CONNECTION SETUP	CCCH
4	-->		RRC CONNECTION SETUP COMPLETE	DCCH
5	-->		SERVICE REQUEST	
6	<--		AUTHENTICATION AND CIPHERING REQUEST	
7	-->		AUTHENTICATION AND CIPHERING RESPONSE	
8	<--		SECURITY MODE COMMAND	
9	-->		SECURITY MODE COMPLETE	
10	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU)
11	<--		CP-ACK	Sent within TC1M after step 10
12	<--		CP-DATA	Contains RP-ACK RPDU
13		SS		Waits max 25 seconds for CP-ACK
14	-->		CP-ACK	
15	<--		RRC CONNECTION RELEASE	RRC connection is released.
16	-->		RRC CONNECTION RELEASE COMPLETE	
17	<--		SYSTEM INFORMATION	BCCH
18	-->		RRC CONNECTION REQUEST	CCCH

Step	Direction		Message	Comments
	UE	SS		
19	<--		RRC CONNECTION SETUP	CCCH
20	-->		RRC CONNECTION SETUP COMPLETE	DCCH
21	-->		SERVICE REQUEST	
22	<--		AUTHENTICATION AND CIPHERING REQUEST	
23	-->		AUTHENTICATION AND CIPHERING RESPONSE	
24	<--		SECURITY MODE COMMAND	
25	-->		SECURITY MODE COMPLETE	
26	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU)
27	SS			SS configured not to send CP-ACK
28	-->		CP-DATA	Retransmitted CP-DATA message within twice TC1M after step 26
29	UE			Depending on the maximum number of CP-DATA retransmissions implemented, step 28 may be repeated. The maximum number of retransmissions may however not exceed three.
30	<--		RRC CONNECTION RELEASE	RRC CONNECTION is released after a duration of TC1M + 5 seconds after the last CP-DATA retransmission.
31	-->		RRC CONNECTION RELEASE COMPLETE	
32	<--		SYSTEM INFORMATION	BCCH
33	-->		RRC CONNECTION REQUEST	CCCH
34	<--		RRC CONNECTION SETUP	CCCH
35	-->		RRC CONNECTION SETUP COMPLETE	DCCH
36	-->		SERVICE REQUEST	
37	<--		AUTHENTICATION AND CIPHERING REQUEST	
38	-->		AUTHENTICATION AND CIPHERING RESPONSE	
39	<--		SECURITY MODE COMMAND	
40	-->		SECURITY MODE COMPLETE	
41	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU)
42	<--		CP-ERROR	Sent within TC1M containing "Network Failure" cause.
43	<--		RRC CONNECTION RELEASE	RRC CONNECTION is released.
44	-->		RRC CONNECTION RELEASE COMPLETE	
45	SS			A PDP context is established with the SS and the state PDP-ACTIVE of session management is entered.
46	UE			The UE is set up to send an SM
47	-->		SERVICE REQUEST	
48	<--		SERVICE ACCEPT	
49	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU)
50	<--		CP-ACK	Sent within TC1M after step 49
51	<--		CP-DATA	Contains RP-ACK RPDU
52	SS			Waits max 25 seconds for CP-ACK
53	-->		CP-ACK	
54	<--		RRC CONNECTION RELEASE	RRC CONNECTION is released.
55	-->		RRC CONNECTION RELEASE COMPLETE	
56	SS			A PDP context is established with the SS and the state PDP-ACTIVE of session management is entered.
57	-->		SERVICE REQUEST	
58	<--		SERVICE ACCEPT	
59	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU)
60	SS			SS configured not to send CP-ACK
61	-->		CP-DATA	Transmitted CP-DATA message within twice TC1M after step 59
62	UE			Depending on the maximum number of CP-DATA retransmissions implemented, step 61 may be repeated. The maximum number of retransmissions may however not exceed three.

Step	Direction		Message	Comments
	UE	SS		
63	<--		RRC CONNECTION RELEASE	RRC CONNECTION is released after a duration of TC1m + 15 seconds after the last CP-DATA retransmission.
64	-->		RRC CONNECTION RELEASE COMPLETE	
65	<--		SYSTEM INFORMATION	BCCH
66	-->		RRC CONNECTION REQUEST	CCCH
67	<--		RRC CONNECTION SETUP	CCCH
68	-->		RRC CONNECTION SETUP COMPLETE	DCCH
69	-->		SERVICE REQUEST	
70	<--		AUTHENTICATION AND CIPHERING REQUEST	
71	-->		AUTHENTICATION AND CIPHERING RESPONSE	
72	<--		SECURITY MODE COMMAND	
73	-->		SECURITY MODE COMPLETE	
74	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU)
75	SS			The SS sends an SM to the UE triggered by the end of the CP-DATA message from the UE
76	<--		CP-DATA	Contains RP-DATA RPDU (SMS DELIVER TPDU)
77	UE			The UE shall correctly receive the SM and indicate that a message has arrived. If the UE provides the functionality to display MT messages, it is checked that the correct message is displayed. In the MO case the UE shall send the CP-ACK message with transaction identifier assigned to this transfer. In the MT case the UE shall send a CP-ACK message and a CP-DATA message containing the RP-ACK RPDU. The transaction identifier shall be the same as chosen by the SS for the MT transfer.
78	-->		RRC CONNECTION REQUEST	initiate outgoing call
79	<--		RRC CONNECTION SETUP	
80	-->		RRC CONNECTION SETUP COMPLETE	
81	-->		SERVICE REQUEST	
82	<--		SERVICE REJECT	Reject cause set to " GPRS services not allowed "
83	<--		RRC CONNECTION RELEASE	Sent 5 seconds after SERVICE REJ
84	-->		RRC CONNECTION RELEASE COMPLETE	

NOTE: Time values for SS wait times are chosen sufficiently high to be sure that the UE has enough time to respond to the different messages.

### Specific Message Contents

#### SMS SUBMIT TPDU

Information element	Comment Value
TP-UDL TP-UD (140 octets max)	as applicable maximum number of characters (text of message) as defined by the manufacturer (see ICS/IXIT)

#### 16.2.2.4 Test requirements

After step 9 UE shall send a CP-DATA containing RP-data. The RP-DATA shall contain SMS SUBMIT TPDU.

After step 26 UE shall retransmit a CP-DATA containing RP-data. The RP-DATA shall contain SMS SUBMIT TPDU.

After step 45 UE shall send the RRC CONNECTION RELEASE COMPLETE.

After step 48 UE shall send a CP-DATA containing RP-data. The RP-DATA shall contain SMS SUBMIT TPDU.

After step 71 UE shall repeat CP-DATA retransmissions as many times as the decided maximum number.

After step 76 UE shall correctly receive the SM and indicate that a message has arrived.

After step 82 UE shall not send CP-DATA.

### 16.2.3 Test of memory full condition and memory available notification:

The Memory Available Notification provides a means for the UE to notify the network that it has memory available to receive one or more short messages. The SMS status field in the USIM contains status information on the "memory available" notification flag.

#### 16.2.3.1 Conformance requirement

1. When a mobile terminated message is Class 2, the UE shall ensure that the message has been transferred to the SMS data field in the USIM before sending an acknowledgement to the SC. The UE shall return a protocol error message if the short message cannot be stored in the USIM and there is other short message storage available in the UE. If all the short message storage in the UE is already in use, the UE shall return "memory capability exceeded".
2. When the UE rejects a short message due to lack of available memory capability the need to transfer notification shall be stored in the USIM.
3. If the memory capability becomes available because memory is cleared, the value of the memory capability exceeded notification flag in the USIM is read. If the flag is set, the UE notifies the network that memory capability is now available. After a positive acknowledgement from the network, the ME unsets the memory capability exceeded notification flag in the USIM.

#### References

- TS 23.040, subclause 9.2.3.10, TS 23.038, clause 4.
- TS 23.040, subclause 10.3 (operation 14).
- TS 23.040, subclause 10.3 (operation 14).

#### 16.2.3.2 Test purpose

1. To verify that the UE sends the correct acknowledgement when its memory in the USIM becomes full.
2. To verify that the UE sends the correct acknowledgement when its memory in the ME and the USIM becomes full, and sets the "memory exceeded" notification flag in the USIM.
3. To verify that the UE performs the "memory available" procedure when its message store becomes available for receiving short messages, and only at this moment.

#### 16.2.3.3 Method of test

##### Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in the idle updated state;
  - the SMS message storage shall be empty;
  - the UE shall be connected to the USIM simulator. The following shall be present in the USIM simulator:

- EF<sub>SMS</sub> with at least one record;
- EF<sub>SMSstatus</sub> with SMS "Memory Cap. Exceed" notification flag set to "memory available";
- Service no. 4 (SMS) in EF<sub>SST</sub> set to allocated and activated.
- for storing of Class 1 Short Messages the UE shall be set up to store Short Messages in the ME memory (by way of MMI, as described in ICS/IXIT statement).

#### Related ICS/IXIT Statements

Support for Short message MT/PP.

Description of the basic procedures to display a mobile terminated short message.

Whether SMS messages are stored in the USIM and/or the ME.

The value of timer TC1M.

#### Test procedure

- a) step a) of subclause 16.2.5.3 (test of Class 2 Short Messages) is repeated until the UE sends a negative acknowledgement (RP-ERROR). The USIM simulator shall indicate if the "memory capability exceeded" notification flag has been set on the USIM.
- b) a Class 1 Short Message is sent to the UE.
- c) step b) is repeated until the UE sends a negative acknowledgement (RP-ERROR). The USIM simulator shall indicate if the "memory capability exceeded" notification flag has been set on the USIM.
- d) a Short Message is sent to the UE with the DCS field of the SMS-DELIVER TPDU set to 0.
- e) the SS prompts the operator to read a short message and to remove it from the message store of the UE.
- f) the SS waits for a RRC CONNECTION REQUEST from the UE, and sends a RRC CONNECTION SETUP.
- g) after the SS receives a RRC CONNECTION SETUP COMPLETE, the SS authenticates the UE and activates ciphering.
- h) the SS answers to the RP-SMMA from the UE with a CP-DATA containing a RP-ACK RPDU.
- i) after the UE has acknowledged the CP-DATA with a CP-ACK, the SS releases the RRC connection. The USIM simulator shall indicate if the "memory capability exceeded" notification flag has been unset on the USIM.
- j) step e) is repeated.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			Mobile terminated establishment of RRC connection	See TS34.108
2	-->		SERVICE REQUEST	
3	<--		AUTHENTICATION AND	
4	-->		CIPHERING REQUEST	
5	<--		AUTHENTICATION AND	
6	-->		CIPHERING RESPONSE	
7	<--		SECURITY MODE COMMAND	
8		SS	SECURITY MODE COMPLETE	Contains RP-DATA RPDU (SMS DELIVER TPDU), Class 2 Short Message
9	-->		CP-DATA	
10		SS		Waits max 25 seconds for CP-ACK
11	-->		CP-ACK	Waits max 60 seconds for RP-ACK RPDU
			CP-DATA	
				Contains RP-ACK RPDU



Step	Direction		Message	Comments
	UE	SS		
12	<--		CP-ACK	Within TC1M after step 11 RRC connection is released. Step 1-18 is repeated until UE sends a negative acknowledgement (RP-ERROR) in step 11. The RP-ERROR RPDU cause field shall be "Protocol error, unspecified" if there is message capability in the ME, or "Memory capability exceeded" if there is no message capability in the ME. If the total memory store of the UE is full, the ME shall set the "memory capability exceeded" notification flag on the USIM.
13	<--		RRC CONNECTION RELEASE	
14	-->		RRC CONNECTION RELEASE COMPLETE	
15			Mobile terminated establishment of RRC connection	
16	-->		SERVICE REQUEST	See TS34.108
17	<--		AUTHENTICATION AND CIPHERING REQUEST	
18	-->		AUTHENTICATION AND CIPHERING RESPONSE	
19	<--		SECURITY MODE COMMAND	
20	-->		SECURITY MODE COMPLETE	Contains RP-DATA RPDU (SMS DELIVER TPDU), Class 1 Short Message Waits max 25 seconds for CP-ACK
21	<--		CP-DATA	
22	SS			
23	-->		CP-ACK	
24	SS			Waits max 60 seconds for RP-ACK RPDU Shall contain RP-ACK RPDU if there is memory capability in the ME. If not it shall contain RP-ERROR RPDU which cause field shall be "memory capability exceeded". If the total memory store of the UE now becomes full at this step, the ME shall set the "memory cap. exceed" notification flag on the USIM.
25	-->		CP-DATA	
26	<--		CP-ACK	
27	<--		RRC CONNECTION RELEASE	
28	-->		RRC CONNECTION RELEASE COMPLETE	Within TC1M after step 25 RRC connection is released. Step 19-36 is repeated until the UE sends an RP-ERROR. The USIM simulator shall indicate if the "memory capability exceeded" notification flag has been set on the USIM.
29			Mobile terminated establishment of RRC connection	
30	-->		SERVICE REQUEST	
31	<--		AUTHENTICATION AND CIPHERING REQUEST	
32	-->		AUTHENTICATION AND CIPHERING RESPONSE	See TS34.108
33	<--		SECURITY MODE COMMAND	
34	-->		SECURITY MODE COMPLETE	
35	<--		CP-DATA	
36	SS			Contains RP-DATA RPDU (SMS DELIVER TPDU) with TP-DCS set to 0 Waits max 25 seconds for CP-ACK
37	-->		CP-ACK	
38	SS			
39	-->		CP-DATA	
40	<--		CP-ACK	Waits max 60 seconds for RP-ACK RPDU Shall contain RP-ERROR RPDU with error cause "memory capability exceeded". Within TC1M after step 39 RRC connection is released.
41	<--		RRC CONNECTION RELEASE	
42	-->		RRC CONNECTION RELEASE COMPLETE	
43	SS			
44	<--		SYSTEM INFORMATION	Prompts the operator to remove one of the short messages from the message store of the UE. BCCH CCCH DCCH
45	-->		RRC CONNECTION REQUEST	
46	<--		RRC CONNECTION SETUP	
47	-->		RRC CONNECTION SETUP COMPLETE	

Step	Direction		Message	Comments
	UE	SS		
48	-->		SERVICE REQUEST	Contains RP-SMMA RPDU
49	<--		SERVICE ACCEPT	
50	-->		CP-DATA	
51	<--		CP-ACK	
52	<--		CP-DATA	
53	-->		CP-ACK	
54	<--		RRC CONNECTION RELEASE	Contains RP-ACK RPDU Acknowledge of CP-DATA containing the RP-ACK RPDU. The ME shall unset the "memory capability exceeded" notification flag on the USIM. RRC connection is released. The USIM simulator shall indicate if the "memory capability exceeded" notification flag has been unset on the USIM.
55	-->		RRC CONNECTION RELEASE COMPLETE	
56		SS		Prompts the operator to remove one of the short messages from the message store of the UE. Shall not attempt to send a RP-SMMA RPDU. This is verified by checking that the UE does not send a CHANNEL REQUEST message with the establishment cause "Other services which can be completed with an SDCCH"
57		UE		

NOTE: Time values for SS wait time are chosen sufficiently high to be sure that the UE has enough time to respond to the different messages.

#### Specific Message Contents

##### SMS-DELIVER TPDU in step 7

Information element	Comment Value
TP-DCS	default alphabet, class 2 "11110010"B

##### SMS-DELIVER TPDU in step 21

TP-DCS	default alphabet, class 1 "11110001"B
--------	---------------------------------------

##### SMS-DELIVER TPDU in step 35

TP-DCS	default alphabet "00000000"B
--------	------------------------------

#### 16.2.3.4 Test requirements

After UE sends a negative acknowledgement (RP-ERROR) in step 11, the USIM simulator shall indicate if the "memory capability exceeded" notification flag has been set on the USIM.

After UE sends a negative acknowledgement (RP-ERROR) in step 23, the USIM simulator shall indicate if the "memory capability exceeded" notification flag has been set on the USIM.

After step 53 the ME shall unset the "memory capability exceeded" notification flag on the USIM.

After step 56 UE shall not attempt to send a RP-SMMA RPDU.

## 16.2.4 Test of the status report capabilities and of SMS-COMMAND:

This test applies to UEs which support the status report capabilities.

### 16.2.4.1 Conformance requirement

The SMS offers the SC the capabilities of informing the UE of the status of a previously sent mobile originated short message. This is achieved by the SC returning a status report TPDU (SMS-STATUS-REPORT) to the originating UE.

SMS-COMMAND enables an UE to invoke an operation at the SC.

The UE shall increment TP-MR by 1 for each SMS-SUBMIT or SMS-COMMAND being submitted.

### References

- TS 23.040, subclause 3.2.9.
- TS 23.040, subclause 9.2.3.6.

### 16.2.4.2 Test purpose

- 1) To verify that the UE is able to accept a SMS-STATUS-REPORT TPDU.
- 2) To verify that the UE is able to use the SMS-COMMAND functionality correctly and sends an SMS-COMMAND TPDU with the correct TP-Message-Reference.

### 16.2.4.3 Method of test

#### Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in the idle updated state.

#### Related ICS/IXIT Statements

Support of SMS MO/PP and MT/PP.

#### Test procedure

- a) The UE is made to send a Mobile Originated short message setting TP-SRR as in steps a) to d) of test 16.2.2 (SMS Mobile originated).
- b) The SS sends a CP-DATA message containing a RP-DATA RPDU itself containing an SMS-STATUS-REPORT TPDU.
- c) The SS sends a RRC CONNECTION RELEASE message.
- d) The UE is made to send an SMS-COMMAND message enquiring about the previously submitted short message.
- e)
- f) The SS acknowledges the CP-DATA message from the UE with a CP-ACK followed by a CP-DATA message containing an RP-ACK RPDU
- g) After receiving the CP-ACK from the UE, the SS releases the RRC connection by using a RRC CONNECTION RELEASE message.

- h) The UE is made to send an SMS-COMMAND message requiring to delete the previously submitted short message.
- i) steps e) to g) are repeated.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<--		SYSTEM INFORMATION	BCCH
2	-->		RRC CONNECTION REQUEST	CCCH
3	<--		RRC CONNECTION SETUP	CCCH
4	-->		RRC CONNECTION SETUP COMPLETE	DCCH
5	-->		SERVICE REQUEST	
6	<--		AUTHENTICATION AND CIPHERING REQUEST	
7	-->		AUTHENTICATION AND CIPHERING RESPONSE	
8	<--		SECURITY MODE COMMAND	
9	-->		SECURITY MODE COMPLETE	
10	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU)
11	<--		CP-ACK	Sent within TC1M after step 10
12	<--		CP-DATA	Contains RP-ACK RPDU
13	SS			Waits max 25 seconds for CP-ACK
14	-->		CP-ACK	
15	<--		RRC CONNECTION RELEASE	RRC connection is released.
16	-->		RRC CONNECTION RELEASE COMPLETE	
17			Mobile terminated establishment of RRC connection	See TS34.108
18	-->		SERVICE REQUEST	
19	<--		AUTHENTICATION AND CIPHERING REQUEST	
20	-->		AUTHENTICATION AND CIPHERING RESPONSE	
21	<--		SECURITY MODE COMMAND	
22	-->		SECURITY MODE COMPLETE	
23	<--		CP-DATA	Contains RP-DATA RPDU (SMS-STATUS-REPORT TPDU)
24	-->		CP-ACK	
25	-->		CP-DATA	Contains RP-ACK RPDU
26	<--		CP-ACK	
27	<--		RRC CONNECTION RELEASE	
28	-->		RRC CONNECTION RELEASE COMPLETE	
29	UE			The UE is made to send an SMS-COMMAND message enquiring about the previously submitted SM
30	<--		SYSTEM INFORMATION	BCCH
31	-->		RRC CONNECTION REQUEST	CCCH
32	<--		RRC CONNECTION SETUP	CCCH
33	-->		RRC CONNECTION SETUP COMPLETE	DCCH
34	-->		SERVICE REQUEST	
35	<--		AUTHENTICATION AND CIPHERING REQUEST	
36	-->		AUTHENTICATION AND CIPHERING RESPONSE	
37	<--		SECURITY MODE COMMAND	
38	-->		SECURITY MODE COMPLETE	
39	-->		CP-DATA	Contains RP-DATA RPDU (SMS-COMMAND TPDU) which shall contain the correct TP-MR
40	<--		CP-ACK	
41	<--		CP-DATA	Contains RP-ACK RPDU
42	-->		CP-ACK	
43	<--		RRC CONNECTION RELEASE	

Step	Direction		Message	Comments
	UE	SS		
44	-->		RRC CONNECTION RELEASE COMPLETE	message requiring to delete the previously submitted SM. CCCH CCCH DCCH  Contains RP-DATA RPDU (SMS-COMMAND TPDU) which shall contain the correct TP-MR  Contains RP-ACK RPDU
45	UE		The UE is made to send an SMS-COMMAND	
46	-->		RRC CONNECTION REQUEST	
47	<--		RRC CONNECTION SETUP	
48	-->		RRC CONNECTION SETUP COMPLETE	
49	-->		SERVICE REQUEST	
50	<--		AUTHENTICATION AND CIPHERING REQUEST	
51	-->		AUTHENTICATION AND CIPHERING RESPONSE	
52	<--		SECURITY MODE COMMAND	
53	-->		SECURITY MODE COMPLETE	
54	-->		CP-DATA	
55	<--		CP-ACK	
56	<--		CP-DATA	
57	-->		CP-ACK	
58	<--		RRC CONNECTION RELEASE	
59	-->		RRC CONNECTION RELEASE COMPLETE	

## Specific Message Contents

## SMS SUBMIT TPDU

Information element	Comment Value
TP-SRR	status report is requested "1"B

## SMS-STATUS-REPORT TPDU (SS to UE in step 23):

Information element	Comment Value
TP-MR	same as previous SMS-SUBMIT
TP-MMS	no more messages "1"B
TP-SRQ	result of SMS-SUBMIT "0"B
TP-RA	same as the Destination address of the SMS-SUBMIT
TP-ST	SM received "00000000"B

## first SMS-COMMAND TPDU (UE to SS in step 39)

Information element	Comment Value
TP-MR	TP-MR in previous SMS-SUBMIT plus "1"
TP-SRR	status report requested "1"B
TP-CT	Enquiry relating to previously submitted short message "00000000"B
TP-MN	not checked (TP-MR in previous SMS-SUBMIT)

## second SMS-COMMAND TPDU (UE to SS in step 54)

Information element	Comment Value
TP-MR	TP-MR in previous SMS-COMMAND plus "1"
TP-CT	Delete previously submitted short message "00000010"B
TP-MN	not checked (TP-MR in previous SMS-SUBMIT)

#### 16.2.4.4 Test requirements

After step 23 UE accept a SMS-STATUS-REPORT TPDU.

After step 39 UE shall send a SMS-COMMAND TPDU with the correct TP-Message-Reference.

After step 54 UE shall send a SMS-COMMAND TPDU with the correct TP-Message-Reference.

### 16.2.5 Test of message class 0 to 3

The tests under this subclause only apply to a UE capable of displaying short messages (see ICS/IXIT).

#### 16.2.5.1 Short message class 0

##### 16.2.5.1.1 Conformance requirement

When a mobile terminated message is class 0 and the UE has the capability of displaying short messages, the UE shall display the message immediately and send an acknowledgement to the SC when the message has successfully reached the UE irrespective of whether there is memory available in the USIM or ME. The message shall not be automatically stored in the USIM or ME.

#### References

TS 23.038, clause 4.

##### 16.2.5.1.2 Test purpose

To verify that the UE will accept and display but not store a class 0 message, and that it will accept and display a class 0 message if its message store is full.

NOTE: failure of this test in a UE could cause it to reject a class 0 message when its SMS memory becomes full. This could lead to unwanted repetitions between the UE and the service centre.

##### 16.2.5.1.3 Method of test

#### Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in the idle updated state;
  - the UE message store shall be empty.

#### Related ICS/IXIT Statements

Support for Short message MT/PP.

Description of the basic procedures to display a mobile terminated short message.

The value of timer TC1M.

Whether SMS messages are stored in the USIM and/or the ME.

## Test procedure

- a) The SS sends a class 0 message by using the method described in step a) of subclause 16.2.1 but with the TPDU described in this subclause.
- b) The UE message store shall be filled (for example by using the method of subclause 16.2.3 test of the memory available notification) with the same SMS-DELIVER TPDU except that TP-DCS is set to class 1.
- c) The SS sends a class 0 message as in step a).

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			Mobile terminated establishment of RRC connection	See TS34.108
2	-->		SERVICE REQUEST	
3	<--		AUTHENTICATION AND CIPHERING REQUEST	
4	-->		AUTHENTICATION AND CIPHERING RESPONSE	
5	<--		SECURITY MODE COMMAND	
6	-->		SECURITY MODE COMPLETE	
7	<--		CP-DATA	
8	-->		CP-ACK	Contains RP-DATA RPDU (SMS DELIVER TPDU), Class 0 Short Message
9	-->		CP-DATA	
10	<--		CP-ACK	
11	<--		RRC CONNECTION RELEASE	
12	-->		RRC CONNECTION RELEASE COMPLETE	Contains RP-ACK RPDU.
13	UE			
14	SS			
15			Mobile terminated establishment of RRC connection	The content of the short message shall be displayed by the ME. The UE shall not store the message. This can be checked by verifying that it is impossible to retrieve any short messages from the UE message store. The UE message store shall be filled (for example by using the method of 16.2.3) with Class 1 SMS-DELIVER TPDU. See TS34.108
16	-->		SERVICE REQUEST	
17	<--		AUTHENTICATION AND CIPHERING REQUEST	
18	-->		AUTHENTICATION AND CIPHERING RESPONSE	
19	<--		SECURITY MODE COMMAND	
20	-->		SECURITY MODE COMPLETE	
21	<--		CP-DATA	
22	-->		CP-ACK	Contains RP-DATA RPDU (SMS DELIVER TPDU), Class 0 Short Message
23	-->		CP-DATA	
24	<--		CP-ACK	
25	<--		RRC CONNECTION RELEASE	
26	-->		RRC CONNECTION RELEASE COMPLETE	Contains RP-ACK RPDU.
27	UE			
				The content of the short message shall be displayed by the ME.

## Specific Message Contents

SMS-DELIVER TPDU (containing a class 0 message) (SS to UE)

Information element	Comment	Value
TP-DCS	default alphabet, class 0	"1111 0000"B

SMS-DELIVER TPDU (containing a class 1 message to fill the UE message store) (SS to UE)

Information element	Comment	Value
TP-DCS	default alphabet, class 1	"1111 0001"B

## 16.2.5.1.4 Test requirements

After step 7 UE shall accept and display but not store a class 0 message.

After step 21 UE shall accept and display a class 0 message.

## 16.2.5.2 Test of class 1 short messages

This test shall apply to UEs which support:

- storing of received Class 1 Short Messages; and
- displaying of stored Short Messages.

## 16.2.5.2.1 Conformance requirement

When a mobile terminated message is class 1, the UE shall send an acknowledgement to the SC when the message has successfully reached the UE and can be stored, either in the ME or in the USIM.

**References**

TS 23.038, clause 4.

## 16.2.5.2.2 Test purpose

This procedure verifies that the UE acts correctly on receiving a class 1 message, i.e. that it stores the message in the ME or USIM and sends an acknowledgement (at RP and CP-Layer).

## 16.2.5.2.3 Method of test

## Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in the idle updated state;
  - the UE message store shall be empty;
  - for storing of class 1 Short Messages, the UE shall be set up to store Short Messages in the ME memory (by way of MMI, as described in ICS/IXIT statement).



## Related ICS/IXIT Statements

Support for Short message MT/PP.

Description of the basic procedures to display a mobile terminated short message.

The value of timer TC1M.

Whether SMS messages are stored in the USIM and/or the ME.

## Test procedure

- a) The SS delivers a Short Message of class 1 to the UE as specified in subclause 16.2.1, step a).
- b) The Short Message is recalled (e.g. by means of the MMI).

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			Mobile terminated establishment of RRC connection	See TS34.108  Contains RP-DATA RPDU (SMS DELIVER TPDU), Class 1 Short Message  Contains RP-ACK RPDU.  The short message shall be recalled and displayed at the UE.
2	-->		SERVICE REQUEST	
3	<--		AUTHENTICATION AND CIPHERING REQUEST	
4	-->		AUTHENTICATION AND CIPHERING RESPONSE	
5	<--		SECURITY MODE COMMAND	
6	-->		SECURITY MODE COMPLETE	
7	<--		CP-DATA	
8	-->		CP-ACK	
9	-->		CP-DATA	
10	<--		CP-ACK	
11	<--		RRC CONNECTION RELEASE	
12	-->		RRC CONNECTION RELEASE COMPLETE	
13	UE			

## Specific Message Contents

SMS-DELIVER TPDU (containing a class 1 message) (SS to UE)

Information element	Comment	Value
TP-DCS	default alphabet, class 1	"1111 0001"B

## 16.2.5.2.4 Test requirements

After step 7 UE shall store the message in the ME or USIM and send an acknowledgement.

## 16.2.5.3 Test of class 2 short messages

## 16.2.5.3.1 Definition

Class 2 Short Messages are defined as USIM specific, and the UE shall ensure that a message of this class is stored on the USIM.

#### 16.2.5.3.2 Conformance requirement

When a mobile terminated message is Class 2, the UE shall ensure that the message has been correctly transferred to the SMS data field in the USIM before sending an acknowledgement to the SC. The UE shall return a "protocol error, unspecified" error message if the short message cannot be stored in the USIM and there is other short message storage available at the UE. If all the short message storage at the UE is already in use, the UE shall return "memory capacity exceeded".

#### Reference(s)

TS 23.040, subclause 9.2.3.10; TS 23.038, clause 4. TS 34.108, subclause 6.11.3.2.27

#### 16.2.5.3.3 Test purpose

This procedure verifies that the UE acts correctly on receiving a class 2 message, i.e. that it stores the message correctly in the USIM, and if this is not possible, returns a protocol error message, with the correct error cause, to the network.

There are 2 cases:

- 1) if the UE supports storing of short messages in the USIM and in the ME, and storage in the ME is not full, and the short message cannot be stored in the USIM, the error cause shall be "protocol error, unspecified";
- 2) if the UE supports storing of short messages in the USIM and not in the ME, and storage in the ME is not full, and the short message cannot be stored in the USIM, the error cause shall be "memory capacity exceeded".

NOTE: If the UE supports storing of short messages in the USIM and the ME, and storage in the ME is full, and the short message cannot be stored in the USIM, the error cause shall be "memory capacity exceeded". This case is not tested in this test.

#### 16.2.5.3.4 Method of test

##### Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in the idle updated state;
  - the ME message store shall be empty;
  - the ME shall be connected to the USIM simulator. The following shall be present in the USIM simulator:
    - EF<sub>SMS</sub> with at least two free records and one full record;
    - EF<sub>SMSstatus</sub> with SMS "Memory Cap. Exceed" notification flag set to "memory available";
    - Service no. 4 (SMS) in EF<sub>SST</sub> set to allocated and activated;
    - for storing of Class 1 Short Messages the UE shall be set up to store Short Messages in the ME memory (by way of MMI, as described in ICS/IXIT statement).

##### Related ICS/IXIT Statements

Support for Short message MT/PP.

The value of timer TC1M.

Whether SMS messages are stored in the USIM and/or the ME.

## Test procedure

- a) The SS delivers a Short Message of class 2 to the UE as specified in subclause 16.2.1, step b).
- b) Following an attempt by the ME to store the short message in a free record of EF<sub>SMS</sub> in the USIM, the USIM simulator returns the status response "OK" ("90 00").
- c) Step a) is repeated.
- d) Following an attempt by the ME to store the short message in a free record of EF<sub>SMS</sub> in the USIM, the USIM simulator returns the status response "memory problem" ("92 40").
- e) The USIM simulator indicates if an attempt was made in steps a) and c) to store the messages and if the messages are stored according to the requirement.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			Mobile terminated establishment of RRC connection	See TS34.108
2	-->		SERVICE REQUEST	
3	<--		AUTHENTICATION AND CIPHERING REQUEST	
4	-->		AUTHENTICATION AND CIPHERING RESPONSE	
5	<--		SECURITY MODE COMMAND	
6	-->		SECURITY MODE COMPLETE	
7	<--		CP-DATA	
8	-->		CP-ACK	Contains RP-DATA RPDU (SMS DELIVER TPDU), Class 2 Short Message
9	ME			
10	USIM			
11	-->		CP-DATA	The ME shall correctly store the short message in a free record of EFSMS in the USIM, i.e. -the ME shall use a free record - the first byte of the record shall indicate "message received by UE from network" - the TS-Service-Centre-Address shall be correctly stored - the TPDU shall be identical to that sent by the SS - bytes following the TPDU shall be set to "FF"
12	<--		CP-ACK	
13	<--		RRC CONNECTION RELEASE	
14	-->		RRC CONNECTION RELEASE COMPLETE	
15			Mobile terminated establishment of RRC connection	
16	-->		SERVICE REQUEST	
17	<--		AUTHENTICATION AND CIPHERING REQUEST	
18	-->		AUTHENTICATION AND CIPHERING RESPONSE	See TS34.108
19	<--		SECURITY MODE COMMAND	
20	-->		SECURITY MODE COMPLETE	
21	<--		CP-DATA	
22	-->		CP-ACK	
23	ME			
				Contains RP-DATA RPDU (SMS DELIVER TPDU), Class 2 Short Message
				The ME shall attempt to store the short message in a free record of EFSMS in the USIM.

Step	Direction		Message	Comments
	UE	SS		
24		USIM		The USIM simulator returns the status response "memory problem" ("92 40"). The USIM simulator shall indicate if an attempt was made by the ME to store the short message in the USIM. Contains RP-ERROR RPDU with error cause "protocol error, unspecified" if the UE supports storing of short messages in the ME, or error cause "memory capacity exceeded" if not.
25	-->		CP-DATA	
26	<--		CP-ACK	
27	<--		RRC CONNECTION RELEASE	
28	-->		RRC CONNECTION RELEASE COMPLETE	

### Specific Message Contents

SMS-DELIVER TPDU (containing a class 2 message) (SS to UE)

Information element	Comment Value
TP-DCS	default alphabet, class 2 "1111 0010"B

#### 16.2.5.3.4 Test requirements

After step 10 UE shall confirm that the short message is stored in the USIM and send CP-DATA containing RP-ACK RPDU.

After step 24 UE shall confirm that the short message cannot be stored in the USIM and send CP-DATA containing RP-ERROR RPDU. If UE supports storing of short message in the ME, the error cause of RP-ERROR RPDU shall be "protocol error, unspecified", and if not the error cause of RP-ERROR RPDU shall be "memory capacity exceeded"

#### 16.2.5.4 Test of class 3 short messages

For further study.

#### 16.2.6 Test of short message type 0

For further study.

#### 16.2.7 Test of the replace mechanism for SM type 1-7

##### 16.2.7.1 Definition

##### 16.2.7.2 Conformance requirement

On receipt of a short message, the UE shall check to see if the associated Protocol Identifier contains a Replace Short Message Type code. If such a code is present, then the UE will check the associated SC address (RP-OA) and originating address (TP-OA) and replace any existing stored message having the same Protocol Identifier code, SC address and originating address with the new short message.

##### Reference(s)

TS 23.040; subclause 9.2.3.9.

##### 16.2.7.3 Test purpose

This procedure verifies the correct implementation of the replace mechanism for Replace Short Messages.

## 16.2.7.4 Method of test

## Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in the idle updated state;
  - the UE message store shall be empty.

## Related ICS/IXIT Statements

Support for Short message MT/PP.

Description of the basic procedures to display a mobile terminated short message.

The value of timer TC1M.

## Test procedure

- a) Two different numbers n and m are drawn randomly between 1 and 7. Two different addresses for TP-Originating-Address (TPOA1 and TPOA2) are drawn. Two different addresses for RP-Originating-Address (RPOA1 and RPOA2) are drawn.
- b) The SS delivers a short message to the UE as specified in subclause 16.2.1 step a). In the SMS-DELIVER TPDU, the TP-Protocol-Identifier parameter is "Replace Short Message Type n", the TP-Originating-Address is TPOA1, and the RP-Originating-Address is RPOA1.
- c) Step b) is repeated but with a different TP-Originating-Address (TPOA2), and different contents of TP-User-Data in the SMS-DELIVER TPDU. The other parameters are the same as in step b).
- d) Step c) is repeated but with RPOA2 in the RP-Originated-Address, and contents of TP-User-Data different from the former two messages. The other parameters are the same as in step c).
- e) Step d) is repeated but with the TP-Protocol-Identifier equal to "Replace Short Message Type m", and contents of TP-User-Data different from the former three messages. The other parameters are the same as in step d).
- f) Step e) is repeated but the contents of TP-User-Data are different from that used in step e).
- g) The SS prompts the operator to display the Short Messages stored in the UE.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			Mobile terminated establishment of RRC connection	See TS34.108
2	-->		SERVICE REQUEST	
3	<--		AUTHENTICATION AND CIPHERING REQUEST	
4	-->		AUTHENTICATION AND CIPHERING RESPONSE	
5	<--		SECURITY MODE COMMAND	
6	-->		SECURITY MODE COMPLETE	
7	<--		CP-DATA	
				Contains RP-DATA RPDU (SMS DELIVER TPDU) TP-PID is "Replace Short Message Type n", TP-OA is TPOA1 and RP-OA is RPOA1
8	-->		CP-ACK	Contains RP-ACK RPDU.
9	-->		CP-DATA	
10	<--		CP-ACK	

Step	Direction		Message	Comments
	UE	SS		
11	<--		RRC CONNECTION RELEASE	See TS34.108
12	-->		RRC CONNECTION RELEASE COMPLETE	
13			Mobile terminated establishment of RRC connection	
14	-->		SERVICE REQUEST	
15	<--		AUTHENTICATION AND CIPHERING REQUEST	
16	-->		AUTHENTICATION AND CIPHERING RESPONSE	
17	<--		SECURITY MODE COMMAND	
18	-->		SECURITY MODE COMPLETE	
19	<--		CP-DATA	
				Contains RP-DATA RPDU (SMS DELIVER TPDU) TP-PID is "Replace Short Message Type n", TP-OA is TPOA2 and RP-OA is RPOA1, TP-UD different from step 7
20	-->		CP-ACK	Contains RP-ACK RPDU.
21	-->		CP-DATA	
22	<--		CP-ACK	
23	<--		RRC CONNECTION RELEASE	
24	-->		RRC CONNECTION RELEASE COMPLETE	
25			Mobile terminated establishment of RRC connection	See TS34.108
26	-->		SERVICE REQUEST	
27	<--		AUTHENTICATION AND CIPHERING REQUEST	
28	-->		AUTHENTICATION AND CIPHERING RESPONSE	
29	<--		SECURITY MODE COMMAND	
30	-->		SECURITY MODE COMPLETE	
31	<--		CP-DATA	
				Contains RP-DATA RPDU (SMS DELIVER TPDU) TP-PID is "Replace Short Message Type n", TP-OA is TPOA2 and RP-OA is RPOA2, TP-UD different from step 7 and 19
32	-->		CP-ACK	Contains RP-ACK RPDU.
33	-->		CP-DATA	
34	<--		CP-ACK	
35	<--		RRC CONNECTION RELEASE	
36	-->		RRC CONNECTION RELEASE COMPLETE	
37			Mobile terminated establishment of RRC connection	See TS34.108
38	-->		SERVICE REQUEST	
39	<--		AUTHENTICATION AND CIPHERING REQUEST	
40	-->		AUTHENTICATION AND CIPHERING RESPONSE	
41	<--		SECURITY MODE COMMAND	
42	-->		SECURITY MODE COMPLETE	
43	<--		CP-DATA	
				Contains RP-DATA RPDU (SMS DELIVER TPDU) TP-PID is "Replace Short Message Type m", TP-OA is TPOA2 and RP-OA is RPOA2, TP-UD different from step 7, 19 and 31
44	-->		CP-ACK	Contains RP-ACK RPDU.
45	-->		CP-DATA	
46	<--		CP-ACK	
47	<--		RRC CONNECTION RELEASE	
48	-->		RRC CONNECTION RELEASE COMPLETE	
49			Mobile terminated establishment of RRC connection	See TS34.108
50	-->		SERVICE REQUEST	
51	<--		AUTHENTICATION AND CIPHERING REQUEST	

Step	Direction		Message	Comments
	UE	SS		
52	-->		AUTHENTICATION AND CIPHERING RESPONSE	Contains RP-DATA RPDU (SMS DELIVER TPDU) TP-PID is "Replace Short Message Type m", TP-OA is TPOA2 and RP-OA is RPOA2, TP-UD different from step 43
53	<--		SECURITY MODE COMMAND	
54	-->		SECURITY MODE COMPLETE	
55	<--		CP-DATA	
56	-->		CP-ACK	Contains RP-ACK RPDU.
57	-->		CP-DATA	
58	<--		CP-ACK	
59	<--		RRC CONNECTION RELEASE	
60	-->		RRC CONNECTION RELEASE COMPLETE	Prompts the operator to display the Short Messages stored in the UE. Only the Short Messages delivered in step 7, 19, 31 and 55 shall be retrievable and displayed
61		SS		

### Specific Message Contents

#### SMS-DELIVER TPDU

Information element	CommentValue
TP-MMS TP-PID	no more messages are waiting in SC "1"B binary 01000xxx, xxx represents n resp. m (see test method description)

#### 16.2.7.5 Test requirements

After step 60 only the Short Messages delivered in step 7, 19, 31 and 55 shall be retrieved and displayed.

## 16.2.8 Test of the reply path scheme

#### 16.2.8.1 Definition

#### 16.2.8.2 Conformance requirement

When a replying UE receives an original mobile terminated short message it has:

- originating SME = TP-Originating Address in the SMS-DELIVER TPDU;
- original SC = RP-Originating Address in the RP-MT-DATA.

When submitting the reply mobile originated short message, the replying UE should use parameters as follows:

- TP-Destination Address in SMS-SUBMIT TPDU = originating SME;
- RP-Destination Address in RP-MO-DATA = original SC.

#### Reference(s)

TS 23.040 Annex D.5,D.6

### 16.2.8.3 Test purpose

This procedure verifies that the UE is able to send a Reply Short Message back to the correct originating SME even if in the meantime it receives another Short Message.

### 16.2.8.4 Method of test

#### Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in the idle updated state;
  - the UE message store shall be empty.

#### Related ICS/IXIT Statements

Support for Short message MT/PP.

Support for Short message MO/PP.

Description of the basic procedures to display a mobile terminated short message.

Description of the basic procedures to send a mobile originated short message.

The value of timer TC1M.

#### Test procedure

- a) The SS delivers a Short Message as specified in subclause 16.2.1, step b) with TP-Reply-Path set to 1.
- b) Step a) is repeated but with:
  - different TP-Originating-Address for the originating SME;
  - different RP-Originating-Address for the original SC; and
  - different message contents TP-User-Data.
- c) One of the two Short Messages is displayed (e.g. by means of the MMI) and the Reply Short Message is submitted (e.g. by means of the MMI).
- d) step c) is repeated for the other Short Message.

#### Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1			Mobile terminated establishment of RRC connection	See TS34.108  Contains RP-DATA RPDU (SMS DELIVER TPDU) TP-RP set to 1 Sent within TC1M after step 7
2	-->		SERVICE REQUEST	
3	<--		AUTHENTICATION AND CIPHERING REQUEST	
4	-->		AUTHENTICATION AND CIPHERING RESPONSE	
5	<--		SECURITY MODE COMMAND	
6	-->		SECURITY MODE COMPLETE	
7	<--		CP-DATA	
8	-->		CP-ACK	



Step	Direction		Message	Comments
	UE	SS		
9	-->		CP-DATA	Contains RP-ACK RPDU.
10	<--		CP-ACK	
11	<--		RRC CONNECTION RELEASE	
12	-->		RRC CONNECTION RELEASE COMPLETE	
13			Mobile terminated establishment of RRC connection	See TS34.108
14	-->		SERVICE REQUEST	
15	<--		AUTHENTICATION AND CIPHERING REQUEST	
16	-->		AUTHENTICATION AND CIPHERING RESPONSE	
17	<--		SECURITY MODE COMMAND	Contains RP-DATA RPDU (SMS DELIVER TPDU) TP-OA, RP-OA and TP-UD different from step 7
18	-->		SECURITY MODE COMPLETE	
19	<--		CP-DATA	
20	-->		CP-ACK	
21	-->		CP-DATA	Sent within TC1M after step 7
22	<--		CP-ACK	Contains RP-ACK RPDU.
23	<--		RRC CONNECTION RELEASE	
24	-->		RRC CONNECTION RELEASE COMPLETE	
25	UE			
26	<--		SYSTEM INFORMATION	
27	-->		RRC CONNECTION REQUEST	BCCH
28	<--		RRC CONNECTION SETUP	CCCH
29	-->		RRC CONNECTION SETUP COMPLETE	DCCH
30	-->		SERVICE REQUEST	One of the two Short Messages is displayed and the Reply Short Message is submitted.
31	<--		AUTHENTICATION AND CIPHERING REQUEST	
32	-->		AUTHENTICATION AND CIPHERING RESPONSE	
33	<--		SECURITY MODE COMMAND	
34	-->		SECURITY MODE COMPLETE	Contains RP-DATA RPDU (SMS SUBMIT TPDU) RP-DA = RP-OA corresponding to the message displayed TP-DA = TP-OA corresponding to the message displayed
35	-->		CP-DATA	
36	<--		CP-ACK	
37	<--		CP-DATA	
38	SS			Sent within TC1M after step 35
39	-->		CP-ACK	Contains RP-ACK RPDU
40	<--		RRC CONNECTION RELEASE	Waits max 25 seconds for CP-ACK
41	-->		RRC CONNECTION RELEASE COMPLETE	
42	UE			RRC connection is released.
43	<--		SYSTEM INFORMATION	The other Short Message is displayed and the Reply Short Message is submitted.
44	-->		RRC CONNECTION REQUEST	
45	<--		RRC CONNECTION SETUP	
46	-->		RRC CONNECTION SETUP COMPLETE	
47	-->		SERVICE REQUEST	
48	<--		AUTHENTICATION AND CIPHERING REQUEST	
49	-->		AUTHENTICATION AND CIPHERING RESPONSE	
50	<--		SECURITY MODE COMMAND	
51	-->		SECURITY MODE COMPLETE	Contains RP-DATA RPDU (SMS SUBMIT TPDU) RP-DA = RP-OA corresponding to the Message displayed TP-DA = TP-OA corresponding to the message displayed
52	-->		CP-DATA	
53	<--		CP-ACK	
54	<--		CP-DATA	

Step	Direction		Message	Comments
	UE	SS		
55		SS		Waits max 25 seconds for CP-ACK
56	-->		CP-ACK	
57	<--		RRC CONNECTION RELEASE	RRC connection is released.
58	-->		RRC CONNECTION RELEASE COMPLETE	

## Specific Message Contents

### SMS-DELIVER TPDU

Information element	Comment	Value
TP-MMS	no more messages are waiting in SC	"1"B
TP-RP	Reply Path exists	"1"B

### 16.2.8.5 Test requirements

After step 34 UE shall send the Reply Short Message corresponding to one of two previously received short messages.

After step 51 UE shall send the Reply Short Message corresponding to the other of two previously received short messages.

## 16.2.9 Multiple SMS mobile originated

### 16.2.9.1 UE in idle mode

This test applies to UE supporting the ability of sending multiple short messages on the same RRC connection when there is no PDP context in progress.

#### 16.2.9.1.1 Conformance requirements

When the UE chooses to use the same RRC connection to send another short message or a memory available notification, then:

- the UE shall transmit a SERVICE REQUEST for the new CM connection before the final CP-ACK (e.g. the one that acknowledges the CP-DATA that carried the RP-ACK) for the old GMM context is transmitted;
- before transmission of the first CP-DATA on the new GMM context, the UE shall transmit the CP-ACK for the old GMM context;
- the Transaction Identifier used on the new GMM context shall be different to that used on the old GMM context; and
- the UE shall not initiate establishment of the new GMM context before the final CP-DATA (e.g. the one carrying the RP-ACK) has been received.

### Reference

- TS 23.040; subclause 3.1.
- TS 24.011; subclause 5.4.

#### 16.2.9.1.2 Test purpose

To verify that the UE is able to correctly send multiple short messages on the same RRC connection when using an DCCH.

### 16.2.9.1.3 Method of test

#### Initial conditions

- System simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in "Idle, updated" state;
  - the SMS message storage shall be empty.

#### Related ICS/IXIT statements

Support for multiple short message MO/PP on the same RRC connection.

Description of how to enter multiple SMS.

Description of the basic procedures to display a mobile originated short message.

Whether SMS messages are stored in the USIM and/or the ME.

#### Test procedure

- a) The UE shall be set up to send 3 short messages as multiple SM to the SS. The SS answers correctly to RRC CONNECTION REQUEST on CCCH and then performs the authentication.
- b) After receiving SECURITY MODE COMMAND UE shall send SECURITY COMMAND COMPLETE.
- c) The SS responds to the CP-DATA containing RP-DATA RPDU (SMS SUBMIT TPDU) from the UE with a CP-ACK message followed by a CP-DATA message containing the correct RP-ACK RPDU. The Transaction Identifier used on this MM connection is 'x'.
- d) The UE shall transmit a SERVICE REQUEST for the new CM connection (for the second short message) before the final CP-ACK (the one that acknowledges the CP-DATA that carried the RP-ACK before) for the old GMM context is transmitted. The UE shall not initiate establishment of the new GMM context before the final CP-DATA (i.e. the one carrying the RP-ACK for the first short message) has been received. Before transmission of the first CP-DATA on the new GMM context, the UE shall transmit the CP-ACK for the old GMM context. The Transaction Identifier used on the new GMM context shall be y, where  $y < x$  (see procedure c)).
- e) The SS waits a maximum of 5 seconds after receiving the SERVICE REQUEST for the CP-ACK message from the UE.
- f) The SS responds to the CP-DATA containing RP-DATA RPDU (SMS SUBMIT TPDU) from the UE with a CP-ACK message followed by a CP-DATA message containing the correct RP-ACK RPDU.
- g) The UE shall transmit a SERVICE REQUEST for the new CM connection (for the third short message) before the final CP-ACK (the one that acknowledges the CP-DATA that carried the RP-ACK before) for the old GMM context is transmitted. Before transmission of the first CP-DATA on the new GMM context, the UE shall transmit the CP-ACK for the old GMM context. The Transaction Identifier used on the new GMM context shall be z, where  $z < y$  (see procedure d)). The UE shall not initiate establishment of the new GMM context before the final CP-DATA (i.e. the one carrying the RP-ACK for the second short message) has been received.
- h) The SS waits a maximum of 5 seconds after receiving the SERVICE REQUEST for the CP-ACK message from the UE.
- i) The SS responds to the CP-DATA containing RP-DATA RPDU (SMS SUBMIT TPDU) from the UE with a CP-ACK message followed by a CP-DATA message containing the correct RP-ACK RPDU.
- j) The SS waits a maximum of 5 seconds after sending CP-DATA for the CP-ACK message from the UE.
- k) The SS sends a RRC CONNECTION RELEASE to the UE.

Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1	<--		SYSTEM INFORMATION	BCCH
2	-->		RRC CONNECTION REQUEST	CCCH
3	<--		RRC CONNECTION SETUP	CCCH
4	-->		RRC CONNECTION SETUP COMPLETE	DCCH
5	-->		SERVICE REQUEST	
6	<--		AUTHENTICATION AND CIPHERING REQUEST	
7	-->		AUTHENTICATION AND CIPHERING RESPONSE	
8	<--		SECURITY MODE COMMAND	
9	-->		SECURITY MODE COMPLETE	
10	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU). The Transaction Identifier used in steps 10, 11, 12 and 14 shall be x.
11	<--		CP-ACK	
12	<--		CP-DATA	Contains RP-ACK RPDU
13	-->		SERVICE REQUEST	
14	-->		CP-ACK	Shall be sent within 5 seconds of step 13
15	<--		SERVICE ACCEPT	
16	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU). The Transaction Identifier used in steps 16, 17, 18 and 20 shall be y where y <> x (see step 10).
17	<--		CP-ACK	
18	<--		CP-DATA	Contains RP-ACK RPDU
19	-->		SERVICE REQUEST	
20	-->		CP-ACK	Shall be sent within 5 seconds of step 19
21	<--		SERVICE ACCEPT	
22	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU). The Transaction Identifier used in steps 22, 23, 24 and 25 shall be z, where z <> y (see step 16).
23	<--		CP-ACK	
24	<--		CP-DATA	Contains RP-ACK RPDU
25	-->		CP-ACK	Shall be sent within 5 seconds of step 24
26	<--		RRC CONNECTION RELEASE	RRC connection is released.
27	-->		RRC CONNECTION RELEASE COMPLETE	

#### 16.2.9.1.4 Test requirements

In step 12 the UE shall transmit a SERVICE REQUEST for the new CM connection (for the second short message) before the final CP-ACK for the old GMM context is transmitted.

In step 17 the UE shall transmit a SERVICE REQUEST for the new CM connection (for the third short message) before the final CP-ACK for the old GMM context is transmitted.

#### 16.2.9.2 UE in active mode

This test applies to UE supporting the ability of sending concatenated multiple short messages when there is a PDP context in progress.

##### 16.2.9.2.1 Conformance requirements

When the UE chooses to use the same RRC connection to send another short message or a memory available notification, then:

- the UE shall transmit a SERVICE REQUEST for the new CM connection before the final CP-ACK (e.g. the one that acknowledges the CP-DATA that carried the RP-ACK) for the old GMM context is transmitted;
- before transmission of the first CP-DATA on the new GMM context, the UE shall transmit the CP-ACK for the old GMM context;
- the Transaction Identifier used on the new GMM context shall be different to that used on the old GMM context; and
- the UE shall not initiate establishment of the new GMM context before the final CP-DATA (e.g. the one carrying the RP-ACK) has been received.

#### Reference

- TS 23.040; subclause 3.1.
- TS 24.011; subclause 5.4.

#### 16.2.9.2.2 Test purpose

To verify that the UE is able to correctly concatenate multiple short messages on the same RRC connection when sent parallel to a PDP context.

#### 16.2.9.2.3 Method of test

##### Initial conditions

- System simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in "Idle, updated" state;
  - the SMS message storage shall be empty.

##### Related ICS/IXIT statements

Support for multiple short message MO/PP on the same RRC connection.

Description of how to enter multiple SMS.

Description of the basic procedures to display a mobile originated short message.

Support for state PDP-ACTIVATE of session management.

Whether SMS messages are stored in the USIM and/or the ME.

##### Test procedure

- a) A PDP context is established with the SS and the state PDP-ACTIVE of session management is entered. The UE is set up to send 3 short messages as multiple SM to the SS. After the reception of the SERVICE REQUEST, the SS sends a SERVICE ACCEPT message. b) Steps c) to k) of the test procedure in subclause 16.2.9.1.3 are repeated.

## Expected sequence

Step	Direction		Message	Comments
	UE	SS		
1		SS		A PDP context is established and the state PDP-ACTIVE of session management is entered.
2	UE			The UE is set up to send 3 short messages as multiple SM
3	-->		SERVICE REQUEST	
4	<--		SERVICE ACCEPT	
5	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU). The Transaction Identifier used in steps 5, 6, 7 and 9 shall be x.
6	<--		CP-ACK	
7	<--		CP-DATA	Contains RP-ACK RPDU
8	-->		SERVICE REQUEST	
9	-->		CP-ACK	Shall be sent within 5 seconds of step 8
10	<--		SERVICE ACCEPT	
11	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU). The Transaction Identifier used in steps 11, 12, 13 and 15 shall be y where y <> x (see step 5).
12	<--		CP-ACK	
13	<--		CP-DATA	Contains RP-ACK RPDU
14	-->		SERVICE REQUEST	
15	-->		CP-ACK	Shall be sent within 5 seconds of step 14
16	<--		SERVICE ACCEPT	
17	-->		CP-DATA	Contains RP-DATA RPDU (SMS SUBMIT TPDU). The Transaction Identifier used in steps 17, 18, 19 and 20 shall be z, where z <> y (see step 11).
18	<--		CP-ACK	
19	<--		CP-DATA	Contains RP-ACK RPDU
20	-->		CP-ACK	Shall be sent within 5 seconds of step 19
21	<--		RRC CONNECTION RELEASE	RRC connection is released.
22	-->		RRC CONNECTION RELEASE COMPLETE	

## 16.2.9.2.4 Test requirements

In step 7 the UE shall transmit a SERVICE REQUEST for the new CM connection (for the second short message) before the final CP-ACK for the old GMM context is transmitted.

In step 13 the UE shall transmit a SERVICE REQUEST for the new CM connection (for the third short message) before the final CP-ACK for the old GMM context is transmitted.

## 16.3 Short message service cell broadcast

## 16.3.1 Conformance requirements

In idle mode, the UE listens to the BCCH and to the paging sub-channel for the paging group it belongs to. The UE is required to receive and analyse the paging messages and immediate assignment messages sent on the paging subchannel corresponding to its paging subgroup.

## Reference

- TS 23.041; clause 8.
- TS 25.324; clause 11

## 16.3.2 Test purpose

This test verifies that an UE supporting SMS-CB is able to receive SMS-CB messages.

### 16.3.3 Method of test

#### Initial conditions

- System Simulator:
  - 1 cell, default parameters;
  - the SS provides a BCCH/CCCH to support the UE in idle mode;
  - periodic location updating is disabled.
- User Equipment:
  - the UE shall be in the idle updated state.

#### Related ICS/IXIT Statements

Support for short message transmission cell broadcast.

Description of the basic procedures to display a cell broadcasted short message.

#### Test procedure

Three Cell Broadcast (CB) messages are sent by the SS on the CBCH with message codes 0,1,1 in serial number fields respectively.

The UE shall respond to the page.

#### Expected sequence

Since the SMS-CB messages are sent continuously, a table is not applicable in this test.

#### Specific Message Contents:

#### Cell broadcast test message content

Information element	Comment Value
Message Type	CBS Message "1"B (see TS 25.324, subclause 11.1)
Message ID	
Serial Number	
- Geographical scope	"00"B
- Message code	see test procedure "0000000000"B or "0000000001"B
- Update number	as applicable
Data Coding Scheme	Default alphabet, English "00000001"B
CB Data	max 1246 octets

### 16.3.4 Test requirements

In consequence of test the UE shall ignore third message and store two messages.

## 16.4 Default message contents:

### 16.4.1 Default message contents for SM-CP protocol

#### CP-DATA

Protocol Discriminator	SMS messages ("1001"B)
Transaction Identifier	
TIO	any value from the set {0, ..., 6}
TI flag	0
Message type	00000001
CP-User data	
CP-USER Data IEI	"0000001"B
length indicator	
RPDU	max 248 octets

#### CP-ACK

Protocol Discriminator	SMS messages ("1001"B)
Transaction Identifier	
TIO	
TI flag	
Message type	00000100

#### CP-ERROR

Protocol Discriminator	SMS messages ("1001"B)
Transaction Identifier	
TIO	
TI flag	
Message type	00010000
CP-Cause	
CP-Cause IEI	"0000010"B
Cause value	see TS 24.011, subclause 8.1.4.2

### 16.4.2 Default message contents for SM-RP protocol

#### RP-DATA

Information element	Comment Value
RP-Message Type	"001"B (SS->UE) or "000"B (UE->SS)
RP-Message Reference	see TS 24.011, subclause 8.2.3
RP-Originator Address	see TS 24.011, subclause 8.2.5.1
RP-Destination Address	see TS 24.011, subclause 8.2.5.2
RP-User Data	see TS 24.011, subclause 8.2.5.3
RP-User Data IEI	"1000001"B
Length indicator	
TP-DATA	max 233 octets

#### RP-ACK

Information element	Comment Value
RP-Message Type	"010"B (UE->SS) or "011"B (SS->UE)
RP-Message Reference	see TS 24.011, subclause 8.2.3



## RP-ERROR

Information element	Comment Value
RP-Message Type	"100"B (UE->SS) or "101"B(SS->UE)
RP-Message Reference	see TS 24.011, subclause 8.2.3
RP-Cause	see TS 24.011, subclause 8.2.5.4
RP-User Data	see TS 24.011, subclause 8.2.5.3 : optional, may be present or not
RP-User Data IEI	"1000001"B
Length indicator	
TP-Data	max 233 octets

## RP-SMMA UE-&gt;SS)

Information element	Comment Value
RP-Message Type	"110"B (UE->SS)
RP-Message Reference	see TS 24.011, subclause 8.2.3

## 16.4.3 Default message contents for SM-TP protocol

## SMS DELIVER TPDU

Information element	Comment Value
TP-MTI	SMS DELIVER "00"B
TP-MMS	more messages are waiting in SC "0"B
TP-RP	no reply path "0"B
TP-UDHI	TP-UD contains only the SM"0"B
TP-SRI	no status report returned"0"B
TP-OA	an international number coded E.164
TP-PID	default "00000000"B
TP-DCS	default alphabet "00000000"B
TP-SCTS	any legal value (cf. TS 23.040)
TP-UDL	
TP-UD	max 140 octets

## SMS SUBMIT TPDU

Information element	Comment Value
TP-MTI	SMS SUBMIT"01"B
TP-RD	SC shall accept same SMS-SUBMIT "0"B
TP-VPF	TP-VP field not present "00"B
TP-RP	no reply path "0"B
TP-UDHI	TP-UD contains only the SM "00"B
TP-SRR	no request of status report "00"B
TP-MR	
TP-DA	an international number coded E164
TP-PID	default "00000000"B
TP-DCS	default alphabet "00000000"B
TP-VP	
TP-UDL	
TP-UD	max 140 octets

## SMS COMMAND TPDU

Information element	Comment Value
TP-MTI	SMS-COMMAND"10"B
TP-UDHI	TP-UD contains only the SM "00"B
TP-SRR	status report not requested "0"B
TP-MR	
TP-PID	default "00000000"B
TP-CT	
TP-MN	
TP-DA	an international number coded E164
TP-CDL	
TP-CD	

## SMS STATUS REPORT TPDU

Information element	Comment Value
TP-MTI	SMS-STATUS-REPORT"10"B
TP-MMS	no more messages "1"B
TP-SRQ	result of SMS-SUBMIT "0"B
TP-MR	
TP-RA	the destination address of the previous SM MO
TP-SCTS	any legal value (cf. TS 23.040, subclause 9.2.3.11)
TP-DT	any legal value (cf. TS 23.040, subclause 9.2.3.13)
TP-ST	see TS 23.040, subclause 9.2.3.15

---

## 17 User Equipment features (MMI, VHE, MexE, SAT)

### 17.1 Test of autocalling restrictions

#### 17.1.1 General

It is essential that all autocalling apparatus is prevented from continuously dialling a given number, to avoid machines repeatedly disturbing PSTN subscribers in error, or numerous repeat attempts to unobtainable numbers which cause waste of valuable network resources. Therefore autocalling restrictions are defined by TS 22.001.

The tests shall be performed using all of the call methods specified by the supplier in the IXIT statement TS 34.123-2. The supplier shall state any autocalling procedures implemented and how many times they can be repeated to a single number and the minimum re-attempt interval(s), i.e. the complete re-try schedule or algorithm with parameter values. The supplier shall further describe any automatic methods for making repeated calls to a single number. The supplier shall also state in the IXIT statement the number of B-party numbers that can be stored on the list of blacklisted numbers as described in TS 22.001, Annex E.

For an external R-interface the supplier shall state in the IXIT statement the procedure for autocalling restrictions for that interface and the possible parameter settings for the number of times the LTE can make a re-attempt and the minimum accepted time between re-attempts accepted by the UE. The conditions for clearing the autocalling constraints shall be stated in the IXIT statement.

For external interfaces the LTE must be programmed so that it clearly attempts to violate the autocalling constraints.

For all the tests in this clause the call setup procedure uses the Generic Setup Procedure for Circuit Switched connection as specified in TS 34.108 clause 7. A Radio Access Bearer to set up shall be selected from one of the speech or CS data bearers within the capability of the UE as specified in the ICS statement. Unless otherwise indicated, this procedure shall only run to the transmission by the SS or UE of the SETUP message (CC).

#### 17.1.2 Constraining the access to a single number (TS 22.001 category 3)

##### 17.1.2.1 Definition and applicability

This test checks that when an auto-dialled call to a B-party number fails due to a category 3 cause, only one retry to that number is permitted.

During this test the SETUP messages shall contain the same B-party number.

No manual intervention shall be performed except to initiate and end the test.

This test applies to all UE that support autocalling.

##### 17.1.2.2 Conformance requirement

A repeat call attempt may be made when a call attempt is unsuccessful for the reasons listed below (as defined in TS 24.008).

These reasons are classified in three major categories:

1. "Busy destination";
2. "Unobtainable destination - temporary";
3. "Unobtainable destination - permanent/long term".

NOTE: Cause values for each category are defined in TS 22.001, Annex E.

The table below describes a repeat call restriction pattern to any B number. This pattern defines a maximum number (n) of call repeat attempts; when this number n is reached, the associated B number shall be blacklisted by the UE until a manual re-set at the UE is performed in respect of that B number. When a repeat attempt to any one B number fails, or is blacklisted, this does not prevent calls being made to other B numbers.

For the categories 1 and 2 above, n shall be 10; for category 3, n shall be 1.

Call attempt	Minimum duration between call attempts
Initial call attempt	-
1st repeat attempt	5 sec
2nd repeat attempt	1 min
3rd repeat attempt	1 min
4th repeat attempt	1 min
5th repeat attempt	3 min
.	
.	
nth repeat attempt	3 min

Reference:

TS 22.001, Annex E.

#### 17.1.2.3 Test purpose

To ensure the correct behaviour of the UE to TS 22.001 Category 3.

#### 17.1.2.4 Method of test

Initial condition.

There shall be no numbers in the list of blacklisted numbers in the UE. The time set between the first re-attempt and the next re-attempt is set to the minimum value possible. The number of re-attempts is set to the lowest possible number, greater than 1, that is supported by the UE. The autocalling function is invoked for the B-party number to be used during the test.

Related ICS/IXIT Statement(s)

ICS: TBD.

PIXIT: Description of auto calling management:

- selection of the auto calling;
- indication that the call failed and a re-try is attempted;
- indication that a call finally failed.

## Test Procedure

Step	Direction		Message	Comments
	UE	SS		
1	UE			"called number" entered
2	→		GENERIC SETUP PROCEDURE MOBILE ORIGINATED, CS (Up to SETUP)	Establishment cause indicates "originating call".
3		←	RELEASE COMPLETE	Cause value from category 3 of TS 22.001, Annex E.
4		←	RRC CONNECTION RELEASE	The signalling link is released
5				The UE is invoking the auto calling function. The time between step 4 and 6 must be minimum 5 sec.
6	→		GENERIC SETUP PROCEDURE MOBILE ORIGINATED, CS (Up to SETUP)	Establishment cause indicates "originating call".
7		←	RELEASE COMPLETE	Cause value from category 3 of TS 22.001, Annex E.
8		←	RRC CONNECTION RELEASE	The main signalling link is released
9	UE			Clear the auto calling constraint after a minimum of 2 minutes from step 8.

## 17.1.2.5 Test requirements

The time between step 4 and 6 must be minimum 5 seconds.

No further call attempt shall be made after step 8.

## 17.1.3 Constraining the access to a single number (TS 22.001 categories 1 and 2)

## 17.1.3.1 Definition and applicability

This test checks that when an auto-dialled call to a B-party number fails due to a category 2 cause, the time between of retries complies with the requirements, and the number of retries does not exceed that declared by the UE manufacturer, and is never more than 10.

During this test the SETUP messages shall contain the same B-party number.

No manual intervention shall be performed except to initiate and end the test.

This test applies to all UE that support autocalling.

## 17.1.3.2 Conformance requirement

The UE must fulfil the requirements for category 1 and 2, see subclause 17.1.2.2.

## Reference:

TS 22.001, Annex E.

## 17.1.3.3 Test purpose

To ensure the correct behaviour of the UE to TS 22.001 Categories 1 and 2.

## 17.1.3.4 Method of test

## Initial condition

There shall be no numbers in the list of blacklisted numbers in the UE. The re-try scheme is set to give the shortest possible intervals between re-tries. The number of re-attempts is set to the maximum possible number (N), that is supported by the UE. The autocalling function is invoked for the B-party number to be used during the test.

## Related PICS/PIXIT Statement(s)

ICS: TBD

IXIT: Description of auto calling management:

- selection of the auto calling;
- indication that the call failed and a re-try is attempted;
- indication that a call finally failed.

## Test Procedure

A, UE originated, generic call setup is performed up to the SETUP message. The SS then releases the establishment with a cause value from category 1 or 2 ( TS 22.001, Annex E).

The UE is continuously making new generic call setup attempts invoked by the auto calling function after each RRC CONNECTION RELEASE from the SS.

Step	Direction		Message	Comments
	UE	SS		
1	UE			"called number" entered
2	→		GENERIC SETUP PROCEDURE MOBILE ORIGINATED, CS (Up to SETUP)	Establishment cause indicates "originating call".
3	←		RELEASE COMPLETE	Cause value from category 1 or 2 of TS 22.001, Annex E. This shall be chosen randomly, from both categories. Cause no. 27 shall be excluded if the UE has implemented in category 3 of TS 22.001, as declared in IXIT statement
4	←		RRC CONNECTION RELEASE	The signalling link is released
5				The UE is invoking the auto calling function. 1: At the first re-attempt the time between step 4 and 6 must be minimum 5 sec. 2: At the 2 <sup>nd</sup> , 3 <sup>rd</sup> and 4 <sup>th</sup> re-attempt the time between step 4 and 6 must be minimum 1 min. 3: At the 5 <sup>th</sup> to 10 <sup>th</sup> re-attempt the time between step 4 and 6 must be minimum 3 min.
6	→		GENERIC SETUP PROCEDURE MOBILE ORIGINATED, CS (Up to SETUP)	Establishment cause indicates "originating call".
7	←		RELEASE COMPLETE	Cause value from category 1 or 2 of TS 22.001, Annex E. This shall be chosen randomly, from both categories. Cause no. 27 shall be excluded if the UE has implemented in category 3 of TS 22.001, as declared in PIXIT statement
8	←		RRC CONNECTION RELEASE	The signalling link is released.
9				The auto calling function shall repeat step 5 to 8 (N-1) times. The UE shall not make more than maximum 10 re-attempts.
10	UE			Clear the auto calling constraint by manual intervention after a minimum of 4 minutes from step 9. Following the final completion of step 9 the UE initiate a call prior to manual intervention.

## 17.1.3.5 Test requirements

1: At the first re-attempt the time between step 4 and 6 must be minimum 5 sec. 2: At the 2<sup>nd</sup>, 3<sup>rd</sup> and 4<sup>th</sup> re-attempt the time between step 4 and 6 must be minimum 1 min. 3: At the 5<sup>th</sup> to 10<sup>th</sup> re-attempt the time between step 4 and 6 must be minimum 3 min.

The UE shall not make more than maximum 10 re-attempts.

## 17.1.4 Behaviour of the UE when its list of blacklisted numbers is full

### 17.1.4.1 Definition and applicability

This tests that the UE does not allow autocalling when its list of blacklisted numbers is full.

The number of B-party numbers that can be stored in the list of blacklisted numbers, as stated in the IXIT statement, is M.

This test shall only apply to UE that are capable of autocalling more than M B-party numbers.

### 17.1.4.2 Conformance requirement

The number of B numbers that can be held in the blacklist is at the manufacturers discretion but there shall be at least 8. However, when the blacklist is full the UE shall prohibit further automatic call attempts to any one number until the blacklist is manually cleared at the UE in respect of one or more B numbers.

### Reference

TS 22.001, Annex E.

### 17.1.4.3 Test purpose

To ensure the correct behaviour of the UE when its list of blacklisted numbers is full.

### 17.1.4.4 Method of test

#### Initial condition

The list of blacklisted numbers, in the UE, shall be full. This may be achieved as described in the procedure in clause 17.1.2, applied to M B-party numbers.

#### Related ICS/IXIT Statement(s)

PICS: TBD.

PIXIT: Description of auto calling management:

- selection of the auto calling;
- indication that the call failed and a re-try is attempted;
- indication that a call finally failed.

#### Test Procedure

The autocalling function is invoked for a B-party number that is not in the list of blacklisted numbers.

Clear the autocalling constraint by manual intervention after a minimum of 10 s.

### 17.1.4.5 Test requirements

The UE must not initiate a call.

---

## Annex A:

# Default RRC Message Contents

This clause contains the default values of RRC messages, other than those specified in TS 34.108 clauses 6 and 9. Unless indicated otherwise in specific test cases, they shall be transmitted by the system simulator in RRC messages, and which are required to be received from the UE under test.

The necessary L3 messages are listed in alphabetic order, with the exception of the SYSTEM INFORMATION messages, where it is the information elements which are listed in alphabetic order (this is because some information elements occur in several SYSTEM INFORMATION types).

In this clause, decimal values are normally used. However, sometimes a hexadecimal value, indicated by an "H", or a binary value, indicated by a "B" is used.

Default SYSTEM INFORMATION:

NOTE 1: SYSTEM INFORMATION BLOCK TYPE 1 (except for PLMN type "GSM-MAP"), SYSTEM INFORMATION BLOCK TYPE 8, SYSTEM INFORMATION BLOCK TYPE 9, SYSTEM INFORMATION BLOCK TYPE 10, SYSTEM INFORMATION BLOCK TYPE 14, SYSTEM INFORMATION BLOCK TYPE 15 and SYSTEM INFORMATION BLOCK TYPE 16 messages are not used.



## Contents of ACTIVE SET UPDATE message: AM

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB with PDCP information	Not Present
- RB identity	
- PDCP SN info	
Maximum allowed UL TX power	33dBm
Radio link addition information	( This IE is repeated for addition RL number.)
- Primary CPICH info	
- Primary scrambling code	The value is for additional cell
- Downlink DPCH info for each RL	
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- DPCH frame offset	0 chips
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- Spreading factor	Reference to TS34.108 clause 6.10 Parameter Set
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	
- Code number	1
- Scrambling code change	SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set)
- TPC combination index	No change
- SSdT Cell Identity	0
- Closed loop timing adjustment mode	-a
- TFCI combining indicator	Not Present
- Secondary CCPCH info	TRUE
- Selection Indicator	
- Primary CPICH usage for channel estimation	Not Present
- Secondary CPICH info	Primary CPICH may be used
- Secondary scrambling code	Not Present
- channelisation code	
- Secondary scrambling code	
- SSdT Indicator	1
- Spreading factor	FALSE
- Code number	Reference to TS34.108 clause 6.10 Parameter Set
- Pilot symbol existence	SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- TFCI existence	FALSE
- Fixed or Flexible Position	TRUE
- Timing offset	Flexible
	0

<ul style="list-style-type: none"> <li>- TFCS</li> <li>- Normal</li> <li>- TFCI Field 1 information</li> <li>- CHOICE TFCS representation</li> <li>- TFCS addition information</li> <li>- CHOICE CTFC Size</li> <li>- CTFC information</li> <li>- Power offset information</li> <li>- FACH/PCH information</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- References to system information blocks</li> <li>- Scheduling information</li> <li>Radio link removal information</li> <li>- Primary CPICH info</li> <li>- Primary scrambling code</li> <li>TX Diversity Mode</li> <li>SSDT information</li> </ul>	<p>( This IE is repeated for TFC number for PCH and FACH.)</p> <p>Addition</p> <p>Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set. Not Present</p> <p>( PCH ) ( This IE is repeated for TFI number.) Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set</p> <p>( FACH ) ( This IE is repeated for TFI number.) Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Not Present</p> <p>( This IE is repeated for removal RL number.)</p> <p>The value is for removal cell None Not Present</p>
--	---

## Contents of ACTIVE SET UPDATE COMPLETE message: AM

Information Element	Value/remark
Message Type	
Integrity check info	Not checked
Uplink integrity protection activation info	Not checked
Radio bearer uplink ciphering activation time info	Not checked
RB with PDCP information	Not checked

## Contents of ACTIVE SET UPDATE FAILURE message: AM

Information Element	Value/remark
Message Type	
Integrity check info	Not checked
Failure cause	Value will be checked

## Contents of CELL UPDATE message: TM

Information Element	Value/remark
Message Type	
U-RNTI	
- SRNC identity	0000 0000 0001B
- S-RNTI	0000 0000 0000 0000 0001B
Integrity check info	Not checked
Hyper frame number	Not checked
AM_RLC error indication(for c-plane)	Not checked
AM_RLC error indication(for u-plane)	Not checked
Cell update cause	See the test content
Protocol error indicator	Not checked
Measured results on RACH	Not checked
Protocol error information	Not checked

## Contents of CELL UPDATE CONFIRM message: UM

Information Element	Value/remark
Message Type	
U-RNTI	
- SRNC identity	0000 0000 0001B
- S-RNTI	0000 0000 0000 0000 0001B
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
New U-RNTI	Not Present
- SRNC identity	
- S-RNTI	
New C-RNTI	Not Present
DRX indicator	NoDRX
UTRAN DRX cycle length coefficient	Not Present
RLC reset indicator(for C-plane)	FALSE
RLC reset indicator(for U-plane)	FALSE
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
URA identity	0000 0000 0001B
RB with PDCP information	Not Present
- RB identity	
- PDCP SN info	
Maximum allowed UL TX power	33dBm
PRACH info	Not Present
- Available Signature	
- Signature	
- Signature	
- Signature	
- Signature	
- Signature	
- Signature	
- Signature	
- Signature	
- Available SF	
- Scrambling code number	
- Puncturing Limit	
- Available Sub Channel number	
- Sub channel number	
- Sub channel number	
- Sub channel number	
- Sub channel number	
- Sub channel number	
- Sub channel number	
- Sub channel number	
- Sub channel number	
- Sub channel number	
- Sub channel number	

<ul style="list-style-type: none"> <li>- Sub channel number</li> <li>- Sub channel number</li> </ul> <p>Downlink information common for one radio link</p> <ul style="list-style-type: none"> <li>- Primary CPICH info <ul style="list-style-type: none"> <li>- Primary scrambling code</li> </ul> </li> <li>- PDSCH with SHO DCH info <ul style="list-style-type: none"> <li>- DSCH radio link identifier</li> <li>- TFCI Combining set</li> </ul> </li> <li>- Radio link identifier <ul style="list-style-type: none"> <li>- Primary CPICH info <ul style="list-style-type: none"> <li>- Primary scrambling code</li> </ul> </li> </ul> </li> <li>- PDSCH code mapping</li> <li>- Downlink DPCH info for each RL <ul style="list-style-type: none"> <li>- Primary CPICH usage for channel estimation</li> </ul> </li> <li>- DPCH frame offset</li> <li>- Secondary CPICH info <ul style="list-style-type: none"> <li>- Secondary scrambling code</li> </ul> </li> <li>- Spreading factor</li> <li>- channelisation code</li> <li>- DL channelisation code <ul style="list-style-type: none"> <li>- Secondary scrambling code</li> </ul> </li> <li>- Code number <ul style="list-style-type: none"> <li>- Scrambling code change</li> </ul> </li> <li>- TPC combination index</li> <li>- SSDT Cell Identity</li> <li>- Closed loop timing adjustment mode</li> <li>- Secondary CCPCH info <ul style="list-style-type: none"> <li>- Selection Indicator</li> </ul> </li> <li>- Primary CPICH usage for channel estimation</li> <li>- Secondary CPICH info <ul style="list-style-type: none"> <li>- Secondary scrambling code</li> <li>- channelisation code</li> </ul> </li> <li>- Secondary scrambling code</li> <li>- SSDT Indicator <ul style="list-style-type: none"> <li>- Spreading factor</li> </ul> </li> <li>- Code number <ul style="list-style-type: none"> <li>- Pilot symbol existence</li> </ul> </li> <li>- TFCI existence</li> <li>- Fixed or Flexible Position</li> <li>- Timing offset</li> <li>- References to system information blocks</li> <li>- Scheduling information</li> </ul>	Not Present
--	-------------

## Contents of MEASUREMENT CONTROL message: AM

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Measurement Identity Number	1
Measurement Command	Setup
Measurement Reporting Mode	
- Measurement Report Transfer Mode	Acknowledged mode RLC
- Measurement Reporting/Event Trigger Reporting Mode	Event Trigger
Additional measurement list	
- CHOICE Measurement type	
- Intra-frequency measurement	
- Intra-frequency cell info	
- New intra-frequency cell	
- Intra-frequency cell-id	0
- cell info	
- Cell individual offset	0dB
- Reference time difference to cell	Not Present
- Primary CPICH info	
- Primary scrambling code	150
- Primary CPICH Tx power	Not Present
- Read SFN number	FALSE
- TX Diversity indicator	FALSE
- Intra-frequency measurement quantity	
- Filter coefficient	0
- Measurement quantity	CPICH RSCP
- Intra-frequency reporting quantity	
- Reporting quantities for active set cells	
- SFN-SFN observed time difference	No report
- Cell Identity	TRUE
- CPICH Ec/N0	FALSE
- CPICH RSCP	TRUE
- Pathloss	FALSE
- CFN-SFN observed time difference	FALSE
- Reporting quantities for monitored cells	
- SFN-SFN observed time difference	No report
- Cell Identity	TRUE
- CPICH Ec/N0	FALSE
- CPICH RSCP	TRUE
- Pathloss	FALSE
- CFN-CFN observed time difference	FALSE
- Reporting quantities for detected set cells	Not Present
- Reporting cell status	Not Present
- Measurement validity	Not Present
- Periodical reporting criteria	
- Amount of reporting	Infinity
- Reporting interval	64 sec
- Inter-system measurement	Not Present
- LCS measurement	Not Present
- Traffic Volume measurement	Not Present
- Quality measurement	Not Present
- UE internal measurement	Not Present
DPCH Compressed mode status info	Not Present

## Contents of MEASUREMENT CONTROL FAILURE message: AM

Information Element	Value/remark
Message Type	
Integrity check info	Not checked
Failure cause	See the test content

Contents of MEASUREMENT REPORT message: AM or UM

Information Element	Value/remark
Message Type	
Integrity check info	Not checked
Measurement identity number	1
Measured Results	
- Intra-frequency measured results	
- Cell measured results	
- Cell Identity	0000 0000 0000 0000 0000 0000 0010B
- SFN-SFN observed time difference	Not checked
- CFN-SFN observed time difference	Not checked
- Primary CPICH info	
- Primary scrambling code	150
- CPICH Ec/NO	Not checked
- CPICH RSCP	The presence should be checked
- Pathloss	Not checked
CN domain identity	Not checked
NAS message	Not checked
Measured results on RACH	Not checked

Contents of PAGING TYPE1 message: TM ( SMS in CS )

Information Element	Value/remark
Message Type	
Paging record	
- Paging cause	SMS
- CN domain identity	CS domain
- CHOICE UE identity	
- IMSI	Set to the same octed string as in the IMSI stored in the USIM card
BCCH modification info	Not Present

Contents of PAGING TYPE1 message: TM ( SMS in PS )

Information Element	Value/remark
Message Type	
Paging record	
- Paging cause	SMS
- CN domain identity	PS domain
- CHOICE UE identity	
- IMSI	Set to the same octed string as in the IMSI stored in the USIM card
BCCH modification info	Not Present

Contents of PAGING TYPE2 message: AM ( Speech in CS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Paging cause	Terminating Conversational Call
CN domain identity	CS domain
Paging Record Type identifier	Select the same type as in the IE "Initial UE Identity" in RRC CONNECTION REQUEST" message.

Contents of PHYSICAL CHANNEL RECONFIGURATION message: AM or UM ( The others of speech in CS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB with PDCP information	Not Present
- RB identity	
- PDCP SN info	
Frequency info	
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
Uplink DPCH info	
- Uplink DPCH power control info	
- DPCCH power offset	-6dB
- PC Preamble	8slot
- Power Control Algorithm	Algorithm1
- TPC step size	1dB
- Scrambling code type	Long
- Scrambling code number	0 ( 0 to 16777215)
- Number of DPDCH	Not Present(1)
- spreading factor	SF is reference to TS34.108 clause 6.10 Parameter Set
- TFCI existence	TRUE
- Number of FBI bit	Not Present(0)
- Puncturing Limit	Reference to TS34.108 clause 6.10 Parameter Set
Downlink information common for all radio links	
- Downlink DPCH info common for all RL	



- Downlink DPCH power control information	0 (single)
- DPC mode	Reference to TS34.108 clause 6.10 Parameter Set
- Spreading factor	Flexible
- Fixed or Flexible Position	TRUE
- TFCI existence	Not Present
- Number of bits for Pilot bits(SF=128,256)	0
- Downlink DPCH Offset Value	1
- DPCH compressed mode info	inactive
- TGPSI	
- TPGS status Flag	FDD Measurement
- Transmission gap pattern sequence configuration parameters	62
- TGMP	(Current CFN + (256 – TTI/10msec)) mod 256
- TGPRC	8
- TGCFN	10
- TGSN	5
- TGL1	15
- TGL2	35
- TGD	35
- TGPL1	Mode 1
- TGPL2	Mode 1
- RPP	DL
- ITPITP	SF/2
- UL/DL Mode	Not Present
- Downlink compressed mode method	A
- Uplink compressed mode method	2.0
- Downlink frame type	1.0
- DeltaSIR1	Not Present
- DeltaSIRafter1	Not Present
- DeltaSIR2	Not Present
- DeltaSIRafter2	None
- TX Diversity mode	Not Present
- SSDT information	
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- DPCH frame offset	0 chips
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	1
- Spreading factor	Reference to TS34.108 clause 6.10 Parameter Set
- Code number	SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Scrambling code change	No change
- TPC combination index	0
- SSDT Cell Identity	-a
- Closed loop timing adjustment mode	Not Present
- Secondary CCPCH info	Not Present
- Primary CPICH usage for channel estimation	
- Secondary CPICH info	
- Selection Indicator	
- Secondary scrambling code	

<ul style="list-style-type: none"><li>- channelisation code</li><li>- Secondary scrambling code</li><li>- SSDT Indicator</li><li>- Spreading factor</li><li>- Code number</li><li>- Pilot symbol existence</li><li>- TFCI existence</li><li>- Fixed or Flexible Position</li><li>- Timing offset</li><li>- TFCS</li><li>- FACH/PCH information</li><li>- TFS</li><li>- Dynamic Transport format information</li><li>- Number of Transport blocks</li><li>- RLC size</li><li>- Semi-static Transport Format information</li><li>- Transmission time interval</li><li>- Type of channel coding</li><li>- Coding Rate</li><li>- Rate matching attribute</li><li>- CRC size</li><li>- TFS</li><li>- Dynamic Transport format information</li><li>- Number of Transport blocks</li><li>- RLC size</li><li>- Semi-static Transport Format information</li><li>- Transmission time interval</li><li>- Type of channel coding</li><li>- Coding Rate</li><li>- Rate matching attribute</li><li>- CRC size</li><li>- References to system information blocks</li><li>- Scheduling information</li></ul>	<p>Not Present</p> <p>Not Present</p> <p>Not Present</p>
---	--

## Contents of PHYSICAL CHANNEL RECONFIGURATION message: AM or UM ( Speech in CS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB with PDCP information	Not Present
- RB identity	
- PDCP SN info	
Frequency info	
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
Uplink DPCH info	
- Uplink DPCH power control info	
- DPCCH power offset	-6dB
- PC Preamble	8slot
- Power Control Algorithm	Algorithm1
- TPC step size	1dB
- Scrambling code type	Long
- Scrambling code number	0 ( 0 to 16777215)
- Number of DPDCH	Not Present(1)
- spreading factor	SF is reference to TS34.108 clause 6.10 Parameter Set
- TFCI existence	TRUE
- Number of FBI bit	Not Present(0)
- Puncturing Limit	Reference to TS34.108 clause 6.10 Parameter Set
Downlink information common for all radio links	
- Downlink DPCH info common for all RL	
- Downlink DPCH power control information	
- DPC mode	0 (single)
- Spreading factor	Reference to TS34.108 clause 6.10 Parameter Set
- Fixed or Flexible Position	Flexible
- TFCI existence	FALSE
- Number of bits for Pilot bits(SF=128,256)	Not Present
- Downlink DPCH Offset Value	0
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	inactive
- Transmission gap pattern sequence configuration parameters	

- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- DPCH frame offset	0 chips
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	
- Spreading factor	1
- Code number	Reference to TS34.108 clause 6.10 Parameter Set SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Scrambling code change	No change
- TPC combination index	0
- SSDT Cell Identity	-a
- Closed loop timing adjustment mode	Not Present
- Secondary CCPCH info	Not Present
- Selection Indicator	
- Primary CPICH usage for channel estimation	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- Secondary scrambling code	
- SSDT Indicator	
- Spreading factor	
- Code number	
- Pilot symbol existence	
- TFCI existence	
- Fixed or Flexible Position	
- Timing offset	
- TFCS	Not Present
- FACH/PCH information	Not Present
- TFS	
- Dynamic Transport format information	

<ul style="list-style-type: none"> <li>- Number of Transport blocks</li> <li>- RLCsize</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- References to system information blocks</li> <li>- Scheduling information</li> </ul>	<p>Not Present</p>
---	--------------------

Contents of PHYSICAL CHANNEL RECONFIGURATION message: AM or UM ( Packet to CELL\_DCH from CELL\_DCH in PS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB with PDCP information	Not Present
- RB identity	
- PDCP SN info	
Frequency info	
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
Uplink DPCH info	
- Uplink DPCH power control info	
- DPCC power offset	-6dB
- PC Preamble	8slot
- Power Control Algorithm	Algorithm1
- TPC step size	1dB
- Scrambling code type	Long
- Scrambling code number	0 ( 0 to 16777215)
- Number of DPDCH	Not Present(1)
- spreading factor	SF is reference to TS34.108 clause 6.10 Parameter Set
- TFCI existence	TRUE
- Number of FBI bit	Not Present(0)
- Puncturing Limit	Reference to TS34.108 clause 6.10 Parameter Set
Downlink information common for all radio links	
- Downlink DPCH info common for all RL	
- Downlink DPCH power control information	
- DPC mode	0 (single)
- Spreading factor	Reference to TS34.108 clause 6.10 Parameter Set
- Fixed or Flexible Position	Flexible
- TFCI existence	TRUE
- Number of bits for Pilot bits(SF=128,256)	Not Present
- Downlink DPCH Offset Value	0
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	Inactive
- Transmission gap pattern sequence configuration parameters	

- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- DPCH frame offset	0 chips
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	
- Spreading factor	1
- Code number	Reference to TS34.108 clause 6.10 Parameter Set
	SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Scrambling code change	No change
- TPC combination index	0
- SSDT Cell Identity	-a
- Closed loop timing adjustment mode	Not Present
- Secondary CCPCH info	Not Present
- Selection Indicator	
- Primary CPICH usage for channel estimation	
- DPCH frame offset	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- Secondary scrambling code	
- SSDT Indicator	
- Spreading factor	
- Code number	
- Pilot symbol existence	
- TFCI existence	
- Fixed or Flexible Position	
- Timing offset	
- TFCS	Not Present
- FACH/PCH information	Not Present
- TFS	

<ul style="list-style-type: none"> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- References to system information blocks</li> <li>- Scheduling information</li> </ul>	<p>Not Present</p>
--	--------------------



Contents of PHYSICAL CHANNEL RECONFIGURATION message: AM or UM ( Packet to CELL\_DCH from CELL\_FACH in PS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB with PDCP information	Not Present
- RB identity	
- PDCP SN info	
Frequency info	
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
Uplink DPCH info	
- Uplink DPCH power control info	
- DPCCH power offset	-6dB
- PC Preamble	8slot
- Power Control Algorithm	Algorithm1
- TPC step size	1dB
- Scrambling code type	Long
- Scrambling code number	0 ( 0 to 16777215)
- Number of DPDCH	Not Present(1)
- spreading factor	SF is reference to TS34.108 clause 6.10 Parameter Set
- TFCI existence	TRUE
- Number of FBI bit	Not Present(0)
- Puncturing Limit	Reference to TS34.108 clause 6.10 Parameter Set
Downlink information common for all radio links	
- Downlink DPCH info common for all RL	
- Downlink DPCH power control information	
- DPC mode	0 (single)
- Spreading factor	Reference to TS34.108 clause 6.10 Parameter Set
- Fixed or Flexible Position	Flexible
- TFCI existence	TRUE
- Number of bits for Pilot bits(SF=128,256)	Not Present
- Downlink DPCH Offset Value	0
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	Inactive
- Transmission gap pattern sequence configuration parameters	

- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- DPCH frame offset	0 chips
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	
- Spreading factor	1
- Code number	Reference to TS34.108 clause 6.10 Parameter Set SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Scrambling code change	No change
- TPC combination index	0
- SSDT Cell Identity	-a
- Closed loop timing adjustment mode	Not Present
- Secondary CCPCH info	Not Present
- Selection Indicator	
- Primary CPICH usage for channel estimation	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- Secondary scrambling code	
- SSDT Indicator	
- Spreading factor	
- Code number	
- Pilot symbol existence	
- TFCI existence	
- Fixed or Flexible Position	
- Timing offset	
- TFCS	Not Present
- FACH/PCH information	Not Present
- TFS	
- Dynamic Transport format information	

<ul style="list-style-type: none"> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- References to system information blocks</li> <li>- Scheduling information</li> </ul>	<p>Not Present</p>
--	--------------------

Contents of PHYSICAL CHANNEL RECONFIGURATION message: AM or UM ( Packet to CELL\_FACH from CELL\_DCH in PS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB with PDCP information	Not Present
- RB identity	
- PDCP SN info	
Frequency info	
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
Uplink DPCH power control info	Not Present
PRACH info	
- Available Signature	
- Signature	0
- Signature	1
- Signature	2
- Signature	3
- Signature	4
- Signature	5
- Signature	6
- Signature	7
- Available SF	Reference to TS34.108 clause 6.10 Parameter Set
- Scrambling code number	0
- Puncturing Limit	Reference to TS34.108 clause 6.10 Parameter Set
- Available Sub Channel number	
- Sub channel number	0
- Sub channel number	1
- Sub channel number	2
- Sub channel number	3
- Sub channel number	4
- Sub channel number	5
- Sub channel number	6
- Sub channel number	7
- Sub channel number	8
- Sub channel number	9
- Sub channel number	10
- Sub channel number	11

Downlink information common for all radio links	Not Present
- Downlink DPCH info common for all RL	
- Downlink DPCH power control information	
- DPC mode	
- Spreading factor	
- Fixed or Flexible Position	
- TFCI existence	
- Number of bits for Pilot bits(SF=128,256)	
- Downlink DPCH Offset Value	
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	Inactive
- Transmission gap pattern sequence configuration parameters	
- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	Not Present
- Primary CPICH usage for channel estimation	
- DPCH frame offset	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	
- Spreading factor	
- Code number	
- Scrambling code change	
- TPC combination index	
- SSDT Cell Identity	
- Closed loop timing adjustment mode	
- Secondary CCPCH info	
- Spreading factor	Not Present
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- Secondary CPICH info	Not Present
- Secondary scrambling code	



Contents of PHYSICAL CHANNEL RECONFIGURATION message: AM or UM ( Packet to CELL\_FACH from CELL\_FACH in PS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	0000 0000 0000 0010B
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB with PDCP information	Not Present
- RB identity	
- PDCP SN info	
Frequency info	
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
Uplink DPCH power control info	Not Present
PRACH info	
- Available Signature	
- Signature	0
- Signature	1
- Signature	2
- Signature	3
- Signature	4
- Signature	5
- Signature	6
- Signature	7
- Available SF	Reference to TS34.108 clause 6.10 Parameter Set
- Scrambling code number	0
- Puncturing Limit	Reference to TS34.108 clause 6.10 Parameter Set
- Available Sub Channel number	
- Sub channel number	0
- Sub channel number	1
- Sub channel number	2
- Sub channel number	3
- Sub channel number	4
- Sub channel number	5
- Sub channel number	6
- Sub channel number	7
- Sub channel number	8
- Sub channel number	9
- Sub channel number	10
- Sub channel number	11

Downlink information common for all radio links	Not Present
- Downlink DPCH info common for all RL	
- Downlink DPCH power control information	
- DPC mode	
- Spreading factor	
- Fixed or Flexible Position	
- TFCI existence	
- Number of bits for Pilot bits(SF=128,256)	
- Downlink DPCH Offset Value	
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	inactive
- Transmission gap pattern sequence configuration parameters	
- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	150
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	Not Present
- Primary CPICH usage for channel estimation	
- DPCH frame offset	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	
- Spreading factor	
- Code number	
- Scrambling code change	
- TPC combination index	
- SSDT Cell Identity	
- Closed loop timing adjustment mode	
- Secondary CCPCH info	
- Selection Indicator	Not Present
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- Secondary CPICH info	Not Present
- Secondary scrambling code	





Contents of RADIO BEARER SETUP message: AM or UM ( The others of speech in CS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	
- Ciphering mode command	Start
- Ciphering algorithm	Standard UMTS Encryption Algorithm UEA1
- Activation time for DPCH	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
- Radio bearer downlink ciphering activation time info	Not Present
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	NoDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
Signalling RB information to setup	Not Present
- RB identity	
- CHOICE RLC info type	
- RLC info	
- CHOICE Uplink RLC mode	
- Transmission RLC discard	
- SDU discard mode	
- Timer_MRW	
- Timer discard	
- MaxMRW	
- Transmission window size	
- Receiving window size	
- CHOICE Downlink RLC mode	
- In-sequence delivery	
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	
- Uplink transport channel type	
- Transport channel identity	
- Logical channel identity	
- MAC logical channel priority	
- Logical channel max loss	
- Number of RLC logical channels	
- Downlink transport channel type	
- Transport channel identity	
- Logical channel identity	
RAB information for setup	
- RAB info	
- RAB identity	0000 0001B
- CN domain identity	CS domain
- Re-establishment timer	
- T314	20 seconds
- RB information to setup	
- RB identity	5
- PDCP info	Not Present

- RLC info	TM RLC
- CHOICE Uplink RLC mode	Not Present
- Transmission RLC discard	TM RLC
- CHOICE Downlink RLC mode	TRUE
Segmentation indication	
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	2
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	2
- Logical channel identity	1
RB information to be affected	(UM DCCH for RRC)
- RB identity	1
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1
RB information to be affected	(AM DCCH for RRC)
- RB identity	2
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
- MAC logical channel priority	2
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
RB information to be affected	(AM DCCH for NAS_DT High priority)
- RB identity	3
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	3
- MAC logical channel priority	3
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	3
RB information to be affected	(AM DCCH for NAS_DT Low priority)
- RB identity	4
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	4
- MAC logical channel priority	4

<ul style="list-style-type: none"> <li>- Logical channel max loss</li> <li>- Number of RLC logical channels</li> <li>- Downlink transport channel type</li> <li>- Transport channel identity</li> <li>- Logical channel identity</li> </ul>	0 1 DCH 1 4
UL Transport channel information for all transport channels	
<ul style="list-style-type: none"> <li>- TFC subset</li> <li>- Allowed Transport Format combination</li> </ul>	( This IE is repeated for TFC number.) 0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.) ( This IE is repeated for TFC number.)
<ul style="list-style-type: none"> <li>- UL DCH TFCS</li> <li>- Normal</li> <li>- TFCI Field 1 information</li> <li>- CHOICE TFCS representation</li> <li>- TFCS addition information</li> <li>- CHOICE CTFC Size</li> </ul>	Addition  Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set
<ul style="list-style-type: none"> <li>- CTFC information</li> <li>- Power offset information</li> <li>- CHOICE Gain Factors</li> <li>- Gain factor <math>\beta_c</math></li> <li>- Gain factor <math>\beta_d</math></li> <li>- Reference TFC ID</li> <li>- Power offset Pp-m</li> </ul>	Signalled Gain Factor 0 0 Not Present 0dB
Added or Reconfigured UL TrCH information	
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> </ul>	2  ( This IE is repeated for TFI number) Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set
Added or Reconfigured UL TrCH information	
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> </ul>	Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set If TrCH reconfiguration is executed then this is needed( e.g The rate of SRB for DCCH is changed.). 1
DRAC static information	
<ul style="list-style-type: none"> <li>- Transmission Time Validity</li> <li>- Time duration before retry</li> <li>- DRAC Class identity</li> </ul>	( This IE is repeated for TFI number) Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set
DL Transport channel information common for all transport channel	
<ul style="list-style-type: none"> <li>- SCCPCH TFCS</li> <li>- CHOICE DL parameters</li> <li>- DL DCH TFCS</li> <li>- Normal</li> <li>- TFCI Field 1 information</li> <li>- CHOICE TFCS representation</li> <li>- TFCS addition information</li> <li>- CHOICE CTFC Size</li> </ul>	Not Present Independent ( This IE is repeated for TFC number.)
<ul style="list-style-type: none"> <li>- CTFC information</li> <li>- Power offset information</li> </ul>	Addition  Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set Not Present
Added or Reconfigured DL TrCH information	
<ul style="list-style-type: none"> <li>- Transport channel identity</li> </ul>	2

- CHOICE DL parameters	SameAsUL
UL TrCH identity	2
- DCH quality target	0.00
- BLER Quality value	Not Present
- Transparent mode signalling info	If TrCH reconfiguration is executed then this is needed( e.g The rate of SRB for DCCH is changed.).
Added or Reconfigured DL TrCH information	1
- Transport channel identity	Independent
- CHOICE DL parameters	1
- UL TrCH identity	
- TFS	( This IE is repeated for TFI number)
- Dynamic Transport format information	Reference to TS34.108 clause 6.10 Parameter Set
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	Reference to TS34.108 clause 6.10 Parameter Set
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	0.00
- BLER Quality value	Not Present
- Transparent mode signalling info	
Frequency info	
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
Uplink DPCH info	
- Uplink DPCH power control info	
- DPCCH power offset	-6dB
- PC Preamble	8slot
- Power Control Algorithm	Algorithm1
- TPC step size	1dB
- Scrambling code type	Long
- Scrambling code number	0 ( 0 to 16777215)
- Number of DPDCH	Not Present(1)
- spreading factor	SF is reference to TS34.108 clause 6.10 Parameter Set
- TFCI existence	TRUE
- Number of FBI bit	Not Present(0)
- Puncturing Limit	Reference to TS34.108 clause 6.10 Parameter Set
Downlink information common for all radio links	
- Downlink DPCH info common for all RL	
- Downlink DPCH power control information	
- DPC mode	0 (single)
- Spreading factor	Reference to TS34.108 clause 6.10 Parameter Set
- Fixed or Flexible Position	Flexible
- TFCI existence	TRUE
- Number of bits for Pilot bits(SF=128,256)	Not Present
- Downlink DPCH Offset Value	0
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	inactive
- Transmission gap pattern sequence configuration parameters	
- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present

- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- DPCH frame offset	0 chips
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	
- Spreading factor	1
- Code number	Reference to TS34.108 clause 6.10 Parameter Set SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Scrambling code change	No change
- TPC combination index	0
- SSDT Cell Identity	-a
- Closed loop timing adjustment mode	Not Present
- Secondary CCPCH info	Not Present
- Selection Indicator	
- Primary CPICH usage for channel estimation	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- Secondary scrambling code	
- SSDT Indicator	
- Spreading factor	
- Code number	
- Pilot symbol existence	
- TFCI existence	
- Fixed or Flexible Position	
- Timing offset	
- TFCS	Not Present
- FACH/PCH information	Not Present
- TFS	
- Dynamic Transport format information	
- Number of Transport blocks	
- RLC size	
- Semi-static Transport Format information	
- Transmission time interval	
- Type of channel coding	
- Coding Rate	
- Rate matching attribute	
- CRC size	
- TFS	
- Dynamic Transport format information	
- Number of Transport blocks	
- RLC size	
- Semi-static Transport Format information	
- Transmission time interval	

<ul style="list-style-type: none"> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- References to system information blocks</li> <li>- Scheduling information</li> </ul>	Not Present
---	-------------

Contents of RADIO BEARER SETUP message: AM or UM ( Packet to CELL\_DCH from CELL\_DCH in PS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	
- Ciphering mode command	Start
- Ciphering algorithm	Standard UMTS Encryption Algorithm UEA1
- Activation time for DPCH	Not Present
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	5
- RLC sequence number	Current RLC SN + 2
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
Signalling RB information to setup	Not Present
- RB identity	
- CHOICE RLC info type	
- RLC info	
- CHOICE Uplink RLC mode	
- Transmission RLC discard	
- SDU discard mode	
- Timer_MRW	
- Timer discard	
- MaxMRW	
- Transmission window size	
- Receiving window size	
- CHOICE Downlink RLC mode	
- In-sequence delivery	
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	
- Uplink transport channel type	
- Transport channel identity	
- Logical channel identity	
- MAC logical channel priority	
- Logical channel max loss	
- Number of RLC logical channels	
- Downlink transport channel type	
- Transport channel identity	
- Logical channel identity	
RAB information for setup	
- RAB info	
- RAB identity	0000 0001B
- CN domain identity	PS domain
- Re-establishment timer	
- T314	20 seconds
- RB information to setup	
- RB identity	5
- PDCP info	Not Present



- RLC info	AM RLC
- CHOICE Uplink RLC mode	
- Transmission RLC discard	Max DAT retransmissions
- SDU discard mode	4
- MAX_DAT	100
- Timer_MRW	4
- MaxMRW	8
- Transmission window size	8
- Receiving window size	500
- Timer_RST	4
- Max_RST	
- Polling info	
- Timer_poll_prohibit	200
- Timer_poll	200
- Poll_SDU	1
- Last transmission PU poll	TRUE
- Last retransmission PU poll	TRUE
- Poll_Windows	99
- CHOICE Downlink RLC mode	AM RLC
- In-sequence delivery	TRUE
- Receiving window size	8
- Downlink RLC status info	
- Timer_status_prohibit	200
- Timer_EPC	200
- Missing PU indicator	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	2
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	2
- Logical channel identity	1
RB information to be affected	(UM DCCH for RRC)
- RB identity	1
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1
RB information to be affected	(AM DCCH for RRC)
- RB identity	2
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
- MAC logical channel priority	2
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
RB information to be affected	(AM DCCH for NAS_DT High priority)
- RB identity	3
- RB mapping info	

<ul style="list-style-type: none"> <li>- Information for each multiplexing option</li> <li>- Number of RLC logical channels</li> <li>- Uplink transport channel type</li> <li>- Transport channel identity</li> <li>- Logical channel identity</li> <li>- MAC logical channel priority</li> <li>- Logical channel max loss</li> <li>- Number of RLC logical channels</li> <li>- Downlink transport channel type</li> <li>- Transport channel identity</li> <li>- Logical channel identity</li> </ul>	1 DCH 1 3 3 0 1 DCH 1 3
RB information to be affected	(AM DCCH for NAS_DT Low priority)
<ul style="list-style-type: none"> <li>- RB identity</li> <li>- RB mapping info</li> <li>- Information for each multiplexing option</li> <li>- Number of RLC logical channels</li> <li>- Uplink transport channel type</li> <li>- Transport channel identity</li> <li>- Logical channel identity</li> <li>- MAC logical channel priority</li> <li>- Logical channel max loss</li> <li>- Number of RLC logical channels</li> <li>- Downlink transport channel type</li> <li>- Transport channel identity</li> <li>- Logical channel identity</li> </ul>	4  1 DCH 1 4 4 0 1 DCH 1 4
UL Transport channel information for all transport channels	
<ul style="list-style-type: none"> <li>- TFC subset</li> <li>- Allowed Transport Format combination</li> </ul>	( This IE is repeated for TFC number.) 0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.) ( This IE is repeated for TFC number.)
<ul style="list-style-type: none"> <li>- UL DCH TFCS</li> <li>- Normal</li> <li>- TFCI Field 1 information</li> <li>- CHOICE TFCS representation</li> <li>- TFCS addition information</li> <li>- CHOICE CTFC Size</li> </ul>	Addition  Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set Not Present
<ul style="list-style-type: none"> <li>- CTFC information</li> <li>- Power offset information</li> </ul>	
Added or Reconfigured UL TrCH information	
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> </ul>	2  ( This IE is repeated for TFI number) Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set If TrCH reconfiguration is executed then this is needed( e.g The rate of SRB for DCCH is changed.).
Added or Reconfigured UL TrCH information	1
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> </ul>	( This IE is repeated for TFI number) Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set
<ul style="list-style-type: none"> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> </ul>	Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set
DRAC static information	Not Present
<ul style="list-style-type: none"> <li>- Transmission Time Validity</li> <li>- Time duration before retry</li> </ul>	

- DRAC Class identity	
DL Transport channel information common for all transport channel	
- SCCPCH TFCS	Not Present
- CHOICE DL parameters	Independent
- DL DCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	
- CHOICE CTFC Size	Addition
- TFCS addition information	
- CHOICE CTFC Size	
- CTFC information	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10.
- Power offset information	Refer to TS34.108 clause 6.10 Parameter Set
Added or Reconfigured DL TrCH information	Not Present
- Transport channel identity	2
- CHOICE DL parameters	Independent
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	
- BLER Quality value	0.00
- Transparent mode signalling info	Not Present
Added or Reconfigured DL TrCH information	If TrCH reconfiguration is executed then this is needed( e.g The rate of SRB for DCCH is changed.).
- Transport channel identity	1
- TFS	
- CHOICE DL parameters	Independent
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	
- BLER Quality value	0.00
- Transparent mode signalling info	Not Present
Frequency info	
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
Uplink DPCH info	
- Uplink DPCH power control info	-6dB
- DPCCH power offset	8slot
- PC Preamble	Algorithm1
- Power Control Algorithm	1dB
- TPC step size	Long
- Scrambling code type	0 ( 0 to 16777215)
- Scrambling code number	Not Present(1)
- Number of DPDCH	SF is reference to TS34.108 clause 6.10 Parameter Set
- spreading factor	TRUE
- TFCI existence	Not Present(0)
- Number of FBI bit	Reference to TS34.108 clause 6.10 Parameter Set
- Puncturing Limit	
Downlink information common for all radio links	
- Downlink DPCH info common for all RL	
- Downlink DPCH power control information	
- DPC mode	0 (single)

- Spreading factor	Reference to TS34.108 clause 6.10 Parameter Set Flexible
- Fixed or Flexible Position	TRUE
- TFCI existence	Reference to TS34.108 clause 6.10 Parameter Set 0
- Number of bits for Pilot bits(SF=128,256)	1
- Downlink DPCH Offset Value	inactive
- DPCH compressed mode info	
- TGPSI	FDD Measurement
- TGPS Status Flag	62
- Transmission gap pattern sequence configuration parameters	(Current CFN + (256 – TTI/10msec)) mod 256
- TGMP	8
- TGPRC	10
- TGCFN	5
- TGSN	15
- TGL1	35
- TGL2	35
- TGD	Mode 1
- TGPL1	Mode 1
- TGPL2	DL
- RPP	SF/2
- ITP	Not Present
- UL/DL Mode	A
- Downlink compressed mode method	2.0
- Uplink compressed mode method	1.0
- Downlink frame type	Not Present
- DeltaSIR1	Not Present
- DeltaSIRafter1	Not Present
- DeltaSIR2	None
- DeltaSIRafter2	Not Present
- TX Diversity mode	
- SSDT information	
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- DPCH frame offset	0 chips
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	1
- Spreading factor	Reference to TS34.108 clause 6.10 Parameter Set SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Code number	No change
- Scrambling code change	0
- TPC combination index	-a
- SSDT Cell Identity	Not Present
- Closed loop timing adjustment mode	Not Present
- Secondary CCPCH info	
- Selection Indicator	
- Primary CPICH usage for channel estimation	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- Secondary scrambling code	
- SSDT Indicator	

<ul style="list-style-type: none"><li>- Spreading factor</li><li>- Code number</li><li>- Pilot symbol existence</li><li>- TFCI existence</li><li>- Fixed or Flexible Position</li><li>- Timing offset</li><li>- TFCS</li><li>- FACH/PCH information</li><li>- TFS</li><li>- Dynamic Transport format information</li><li>- Number of Transport blocks</li><li>- RLC size</li><li>- Semi-static Transport Format information</li><li>- Transmission time interval</li><li>- Type of channel coding</li><li>- Coding Rate</li><li>- Rate matching attribute</li><li>- CRC size</li><li>- TFS</li><li>- Dynamic Transport format information</li><li>- Number of Transport blocks</li><li>- RLC size</li><li>- Semi-static Transport Format information</li><li>- Transmission time interval</li><li>- Type of channel coding</li><li>- Coding Rate</li><li>- Rate matching attribute</li><li>- CRC size</li><li>- References to system information blocks</li><li>- Scheduling information</li></ul>	<p>Not Present</p> <p>Not Present</p> <p>Not Present</p>
--	--

Contents of RADIO BEARER SETUP message: AM or UM ( Packet to CELL\_DCH from CELL\_FACH in PS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	
- Ciphering mode command	Start
- Ciphering algorithm	Standard UMTS Encryption Algorithm UEA1
- Activation time for DPCH	Not Present
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	5
- RLC sequence number	Current RLC SN + 2
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
Signalling RB information to setup	Not Present
- RB identity	
- CHOICE RLC info type	
- RLC info	
- CHOICE Uplink RLC mode	
- Transmission RLC discard	
- SDU discard mode	
- Timer_MRW	
- Timer discard	
- MaxMRW	
- Transmission window size	
- Receiving window size	
- CHOICE Downlink RLC mode	
- In-sequence delivery	
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	
- Uplink transport channel type	
- Transport channel identity	
- Logical channel identity	
- MAC logical channel priority	
- Logical channel max loss	
- Number of RLC logical channels	
- Downlink transport channel type	
- Transport channel identity	
- Logical channel identity	
RAB information for setup	
- RAB info	
- RAB identity	0000 0001B
- CN domain identity	PS domain
- Re-establishment timer	
- T314	20 seconds
- RB information to setup	
- RB identity	5
- PDCP info	Not Present

- RLC info	AM RLC
- CHOICE Uplink RLC mode	
- Transmission RLC discard	Max DAT retransmissions
- CHOICE SDU discard mode	4
- MAX_DAT	100
- Timer_MRW	4
- MaxMRW	8
- Transmission window size	8
- Receiving window size	500
- Timer_RST	4
- Max_RST	
- Polling info	
- Timer_poll_prohibit	200
- Timer_poll	200
- Poll_SDU	1
- Last transmission PU poll	TRUE
- Last retransmission PU poll	TRUE
- Poll_Windows	99
- CHOICE Downlink RLC mode	AM RLC
- In-sequence delivery	TRUE
- Receiving window size	8
- Downlink RLC status info	
- Timer_status_prohibit	200
- Timer_EPC	200
- Missing PU indicator	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	2
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	2
- Logical channel identity	1
RB information to be affected	(UM DCCH for RRC)
- RB identity	1
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1
RB information to be affected	(AM DCCH for RRC)
- RB identity	2
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
- MAC logical channel priority	2
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
RB information to be affected	(AM DCCH for NAS_DT High priority)
- RB identity	3
- RB mapping info	

- Information for each multiplexing option	1
- Number of RLC logical channels	DCH
- Uplink transport channel type	1
- Transport channel identity	3
- Logical channel identity	3
- MAC logical channel priority	0
- Logical channel max loss	1
- Number of RLC logical channels	DCH
- Downlink transport channel type	1
- Transport channel identity	3
- Logical channel identity	(AM DCCH for NAS_DT Low priority)
RB information to be affected	4
- RB identity	
- RB mapping info	
- Information for each multiplexing option	1
- Number of RLC logical channels	DCH
- Uplink transport channel type	1
- Transport channel identity	4
- Logical channel identity	4
- MAC logical channel priority	0
- Logical channel max loss	1
- Number of RLC logical channels	DCH
- Downlink transport channel type	1
- Transport channel identity	4
- Logical channel identity	
UL Transport channel information for all transport channels	
- TFC subset	( This IE is repeated for TFC number.)
- Allowed Transport Format combination	0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.)
- UL DCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	Addition
- CHOICE TFCS representation	
- TFCS addition information	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10.
- CHOICE CTFC Size	Refer to TS34.108 clause 6.10 Parameter Set
- CTFC information	Signalled Gain Factor
- Power offset information	0
- CHOICE Gain Factors	0
- Gain factor $\beta_c$	Not Present
- Gain factor $\beta_d$	0dB
- Reference TFC ID	
- Power offset Pp-m	
Added or Reconfigured UL TrCH information	
- Transport channel identity	2
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
Added or Reconfigured UL TrCH information	
- Transport channel identity	1
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set



DRAC static information	Not Present
- Transmission Time Validity	
- Time duration before retry	
- DRAC Class identity	
DL Transport channel information common for all transport channel	
- SCCPCH TFCS	Not Present
- CHOICE DL parameters	Independent
- DL DCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	Addition
- CHOICE TFCS representation	
- TFCS addition information	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10.
- CHOICE CTFC Size	Refer to TS34.108 clause 6.10 Parameter Set
- CTFC information	Not Present
- Power offset information	
Added or Reconfigured DL TrCH information	
- Transport channel identity	2
- CHOICE DL parameters	Independent
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	
- BLER Quality value	0.00
- Transparent mode signalling info	Not Present
Added or Reconfigured DL TrCH information	
- Transport channel identity	1
- CHOICE DL parameters	Independent
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	
- BLER Quality value	0.00
- Transparent mode signalling info	Not Present
Frequency info	
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
Uplink DPCH info	
- Uplink DPCH power control info	
- DPCH power offset	-6dB
- PC Preamble	8slot
- Power Control Algorithm	Algorithm1
- TPC step size	1dB
- Scrambling code type	Long
- Scrambling code number	0 ( 0 to 16777215)
- Number of DPDCH	Not Present(1)
- spreading factor	SF is reference to TS34.108 clause 6.10 Parameter Set
- TFCI existence	TRUE
- Number of FBI bit	Not Present(0)
- Puncturing Limit	Reference to TS34.108 clause 6.10 Parameter Set
Downlink information common for all radio links	
- Downlink DPCH info common for all RL	

- Downlink DPCH power control information	0 (single)
- DPC mode	Reference to TS34.108 clause 6.10 Parameter Set Flexible
- Spreading factor	TRUE
- Fixed or Flexible Position	Reference to TS34.108 clause 6.10 Parameter Set
- TFCI existence	0
- Number of bits for Pilot bits(SF=128,256)	
- Downlink DPCH Offset Value	
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	inactive
- Transmission gap pattern sequence configuration parameters	
- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- DPCH frame offset	
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	1
- Spreading factor	Reference to TS34.108 clause 6.10 Parameter Set SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Code number	Set )
- Scrambling code change	No change
- TPC combination index	0
- SSDT Cell Identity	-a
- Closed loop timing adjustment mode	Not Present
- Secondary CCPCH info	Not Present
- Selection Indicator	
- Primary CPICH usage for channel estimation	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	

<ul style="list-style-type: none"><li>- Secondary scrambling code</li><li>- SSDT Indicator</li><li>- Spreading factor</li><li>- Code number</li><li>- Pilot symbol existence</li><li>- TFCI existence</li><li>- Fixed or Flexible Position</li><li>- Timing offset</li><li>- TFCS</li><li>- FACH/PCH information</li><li>- TFS<ul style="list-style-type: none"><li>- Dynamic Transport format information</li><li>- Number of Transport blocks</li><li>- RLC size</li></ul></li><li>- Semi-static Transport Format information<ul style="list-style-type: none"><li>- Transmission time interval</li><li>- Type of channel coding</li><li>- Coding Rate</li><li>- Rate matching attribute</li><li>- CRC size</li></ul></li><li>- TFS<ul style="list-style-type: none"><li>- Dynamic Transport format information</li><li>- Number of Transport blocks</li><li>- RLC size</li></ul></li><li>- Semi-static Transport Format information<ul style="list-style-type: none"><li>- Transmission time interval</li><li>- Type of channel coding</li><li>- Coding Rate</li><li>- Rate matching attribute</li><li>- CRC size</li></ul></li><li>- References to system information blocks</li><li>- Scheduling information</li></ul>	<p>Not Present</p> <p>Not Present</p> <p>Not Present</p>
---	--

Contents of RADIO BEARER SETUP message: AM or UM ( Packet to CELL\_FACH from CELL\_DCH in PS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	
- Ciphering mode command	start
- Ciphering algorithm	Standard UMTS Encryption Algorithm UEA1
- Activation time for DPCH	Not Present
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	5
- RLC sequence number	Current RLC SN + 2
Activation time	(256+CFN-(CFN MOD 8 + 8 ))MOD 256
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
Signalling RB information to setup	Not Present
- RB identity	
- CHOICE RLC info type	
- RLC info	
- CHOICE Uplink RLC mode	
- Transmission RLC discard	
- CHOICE SDU discard mode	
- Timer_MRW	
- Timer discard	
- MaxMRW	
- Transmission window size	
- Receiving window size	
- CHOICE Downlink RLC mode	
- In-sequence delivery	
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	
- Uplink transport channel type	
- Transport channel identity	
- Logical channel identity	
- MAC logical channel priority	
- Logical channel max loss	
- Number of RLC logical channels	
- Downlink transport channel type	
- Transport channel identity	
- Logical channel identity	
RAB information for setup	
- RAB info	(AM DTCH for PS domain)
- RAB identity	0000 0001B
- CN domain identity	PS domain
- Re-establishment timer	
- T314	20 seconds
- RB information to setup	
- RB identity	5
- PDCP info	Not Present

- RLC info	AM RLC
- CHOICE Uplink RLC mode	
- Transmission RLC discard	Max DAT retransmissions
- CHOICE SDU discard mode	4
- MAX_DAT	100
- Timer_MRW	4
- MaxMRW	8
- Transmission window size	8
- Receiving window size	500
- Timer_RST	4
- Max_RST	
- Polling info	
- Timer_poll_prohibit	200
- Timer_poll	200
- Poll_SDU	1
- Last transmission PU poll	TRUE
- Last retransmission PU poll	TRUE
- Poll_Windows	99
- CHOICE Downlink RLC mode	AM RLC
- In-sequence delivery	TRUE
- Receiving window size	8
- Downlink RLC status info	
- Timer_status_prohibit	200
- Timer_EPC	200
- Missing PU indicator	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	6
- MAC logical channel priority	6
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	1
RB information to be affected	(UM DCCH for RRC)
- RB identity	1
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	1
- MAC logical channel priority	2
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	1
RB information to be affected	(AM DCCH for RRC)
- RB identity	2
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	2
- MAC logical channel priority	3
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	2
RB information to be affected	(AM DCCH for NAS_DT High priority)
- RB identity	3
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	3
- MAC logical channel priority	4

- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	3
RB information to be affected	(AM DCCH for NAS_DT Low priority)
- RB identity	4
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	4
- MAC logical channel priority	5
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	4
RB information to be affected	(TM CCCH uplink for RRC)
- RB identity	0
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	5
- Logical channel max loss	0
- MAC logical channel priority	1
RB information to be affected	(UM CCCH for RRC)
- RB identity	0
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	5
RB information to be affected	(TM BCCH for RRC)
- RB identity	6
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	5
RB information to be affected	(TM PCCH for RRC)
- RB identity	7
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Downlink transport channel type	PCH
- Logical channel identity	1
UL Transport channel information for all transport channels	
- TFC subset	( This IE is repeated for TFC number.)
- Allowed Transport Format combination	0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.)
- UL DCH TFCS	Not Present
Added or Reconfigured UL TrCH information	
- Transport channel identity	1
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
DRAC static information	Not Present
- Transmission Time Validity	
- Time duration before retry	
- DRAC Class identity	

<p>DL Transport channel information common for all transport channel</p> <ul style="list-style-type: none"> <li>- SCCPCH TFCS</li> <li>- Normal</li> <li>- TFCI Field 1 information</li> <li>- CHOICE TFCS representation</li> <li>- TFCS addition information</li> <li>- CHOICE CTFC Size</li> <li>- CTFC information</li> <li>- Power offset information</li> <li>- CHOICE DL parameters</li> <li>- DL DCH TFCS</li> </ul> <p>Added or Reconfigured DL TrCH information</p> <ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul> <p>Added or Reconfigured DL TrCH information</p> <ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul> <p>Added or Reconfigured DL TrCH information</p> <ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul> <p>Added or Reconfigured DL TrCH information</p> <ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> </ul>	<p>( This IE is repeated for TFC number.)</p> <p>Addition</p> <p>Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set</p> <p>Independent Not Present</p> <p>1 Independent</p> <p>( This IE is repeated for TFI number) Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Not Present</p> <p>Not Present</p> <p>2 Independent</p> <p>( This IE is repeated for TFI number) Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Not Present</p> <p>Not Present</p> <p>3 Independent</p> <p>( This IE is repeated for TFI number) Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Not Present</p> <p>Not Present</p> <p>4 Independent</p> <p>( This IE is repeated for TFI number) Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set</p>
--	--

- Semi-static Transport Format information	Reference to TS34.108 clause 6.10 Parameter Set
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	Not Present
- BLER Quality value	Not Present
- Transparent mode signalling info	Not Present
Frequency info	
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
PRACH info	
- Available Signature	
- Signature	0
- Signature	1
- Signature	2
- Signature	3
- Signature	4
- Signature	5
- Signature	6
- Signature	7
- Available SF	Reference to TS34.108 clause 6.10 Parameter Set
- Scrambling code number	0
- Puncturing Limit	Reference to TS34.108 clause 6.10 Parameter Set
- Available Sub Channel number	
- Sub channel number	0
- Sub channel number	1
- Sub channel number	2
- Sub channel number	3
- Sub channel number	4
- Sub channel number	5
- Sub channel number	6
- Sub channel number	7
- Sub channel number	8
- Sub channel number	9
- Sub channel number	10
- Sub channel number	11
Downlink information common for all radio links	Not Present
- Downlink DPCH info common for all RL	
- Downlink DPCH power control information	
- DPC mode	
- Spreading factor	
- Fixed or Flexible Position	
- TFCI existence	
- Number of bits for Pilot bits(SF=128,256)	
- Downlink DPCH Offset Value	
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	Inactive
- Transmission gap pattern sequence configuration parameters	
- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A



- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	Not Present
- Primary CPICH usage for channel estimation	
- DPCH frame offset	0 chips
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	
- Spreading factor	Reference to TS34.108 clause 6.10 Parameter Set
- Code number	
- Scrambling code change	No change
- TPC combination index	
- SSDT Cell Identity	
- Closed loop timing adjustment mode	
- Secondary CCPCH info	
- Selection Indicator	Not Present
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- Secondary scrambling code	
- SSDT Indicator	1
- Spreading factor	FALSE
- Code number	Reference to TS34.108 clause 6.10 Parameter Set
- Pilot symbol existence	SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- TFCI existence	FALSE
- Fixed or Flexible Position	TRUE
- Timing offset	Flexible
- TFCS	0
- FACH/PCH information	Not Present
- TFS	Not Present
- Dynamic Transport format information	
- Number of Transport blocks	
- RLC size	
- Semi-static Transport Format information	
- Transmission time interval	
- Type of channel coding	
- Coding Rate	
- Rate matching attribute	
- CRC size	
- TFS	
- Dynamic Transport format information	
- Number of Transport blocks	
- RLC size	
- Semi-static Transport Format information	
- Transmission time interval	
- Type of channel coding	

<ul style="list-style-type: none"> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- References to system information blocks</li> <li>- Scheduling information</li> </ul>	<p>Not Present</p>
---	--------------------

Contents of RADIO BEARER SETUP message: AM or UM ( Packet to CELL\_FACH from CELL\_FACH in PS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	
- Ciphering mode command	start
- Ciphering algorithm	Standard UMTS Encryption Algorithm UEA1
- Activation time for DPCH	Not Present
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	5
- RLC sequence number	Current RLC SN
Activation time	(256+CFN-(CFN MOD 8 + 8 ))MOD 256
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
Signalling RB information to setup	Not Present
- RB identity	
- CHOICE RLC info type	
- RLC info	
- CHOICE Uplink RLC mode	
- Transmission RLC discard	
- CHOICE SDU discard mode	
- Timer_MRW	
- Timer discard	
- MaxMRW	
- Transmission window size	
- Receiving window size	
- CHOICE Downlink RLC mode	
- In-sequence delivery	
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	
- Uplink transport channel type	
- Transport channel identity	
- Logical channel identity	
- MAC logical channel priority	
- Logical channel max loss	
- Number of RLC logical channels	
- Downlink transport channel type	
- Transport channel identity	
- Logical channel identity	
RAB information for setup	(AM DTCH for PS domain)
- RAB info	
- RAB identity	0000 0001B
- CN domain identity	PS domain
- Re-establishment timer	
- T314	20 seconds
- RB information to setup	
- RB identity	5

- PDCP info	Not Present
- RLC info	
- CHOICE Uplink RLC mode	AM RLC
- Transmission RLC discard	
- CHOICE SDU discard mode	Max DAT retransmissions
- MAX_DAT	4
- Timer_MRW	100
- MaxMRW	4
- Transmission window size	8
- Receiving window size	8
- Timer_RST	500
- Max_RST	4
- Polling info	
- Timer_poll_prohibit	200
- Timer_poll	200
- Poll_SDU	1
- Last transmission PU poll	TRUE
- Last retransmission PU poll	TRUE
- Poll_Windows	99
- CHOICE Downlink RLC mode	AM RLC
- In-sequence delivery	TRUE
- Receiving window size	8
- Downlink RLC status info	
- Timer_status_prohibit	200
- Timer_EPC	200
- Missing PU indicator	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	6
- MAC logical channel priority	6
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	1
RB information to be affected	(UM DCCH for RRC)
- RB identity	1
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	1
- MAC logical channel priority	2
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	1
RB information to be affected	(AM DCCH for RRC)
- RB identity	2
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	2
- MAC logical channel priority	3
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	2
RB information to be affected	(AM DCCH for NAS_DT High priority)
- RB identity	3
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	3
- MAC logical channel priority	4

- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	3
RB information to be affected	(AM DCCH for NAS_DT Low priority)
- RB identity	4
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	4
- MAC logical channel priority	5
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	4
RB information to be affected	(TM CCCH uplink for RRC)
- RB identity	0
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	5
- MAC logical channel priority	1
- Logical channel max loss	0
RB information to be affected	(UM CCCH for downlink RRC)
- RB identity	0
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	6
RB information to be affected	(TM BCCH for RRC)
- RB identity	6
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	6
RB information to be affected	(TM PCCH for RRC)
- RB identity	7
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Downlink transport channel type	PCH
- Logical channel identity	1
UL Transport channel information for all transport channels	
- TFC subset	( This IE is repeated for TFC number.)
- Allowed Transport Format combination	0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.)
- UL DCH TFCs	Not Present
Added or Reconfigured UL TrCH information	
- Transport channel identity	1
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
DRAC static information	Not Present
- Transmission Time Validity	
- Time duration before retry	
- DRAC Class identity	

DL Transport channel information common for all transport channel	
- SCCPCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	
- CHOICE TFCS representation	Addition
- TFCS addition information	
- CHOICE CTFC Size	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set
- CTFC information	
- Power offset information	
- CHOICE DL parameters	Independent
- DL DCH TFCS	Not Present
Added or Reconfigured DL TrCH information	
- Transport channel identity	1
- CHOICE DL parameters	Independent
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Transport block size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	Not Present
- BLER Quality value	
- Transparent mode signalling info	Not Present
Added or Reconfigured DL TrCH information	
- Transport channel identity	2
- CHOICE DL parameters	Independent
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	Not Present
- BLER Quality value	
- Transparent mode signalling info	Not Present
Added or Reconfigured DL TrCH information	
- Transport channel identity	3
- CHOICE DL parameters	Independent
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	Not Present
- BLER Quality value	
- Transparent mode signalling info	Not Present
Added or Reconfigured DL TrCH information	
- Transport channel identity	4
- CHOICE DL parameters	Independent
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set

- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	Reference to TS34.108 clause 6.10 Parameter Set
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	Not Present
- BLER Quality value	Not Present
- Transparent mode signalling info	Not Present
Frequency info	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	33dBm
Maximum allowed UL TX power	
PRACH info	
- Available Signature	0
- Signature	1
- Signature	2
- Signature	3
- Signature	4
- Signature	5
- Signature	6
- Signature	7
- Available SF	Reference to TS34.108 clause 6.10 Parameter Set
- Scrambling code number	0
- Puncturing Limit	Reference to TS34.108 clause 6.10 Parameter Set
- Available Sub Channel number	
- Sub channel number	0
- Sub channel number	1
- Sub channel number	2
- Sub channel number	3
- Sub channel number	4
- Sub channel number	5
- Sub channel number	6
- Sub channel number	7
- Sub channel number	8
- Sub channel number	9
- Sub channel number	10
- Sub channel number	11
Downlink information common for all radio links	Not Present
- Downlink DPCH info common for all RL	
- Downlink DPCH power control information	
- DPC mode	
- Spreading factor	
- Fixed or Flexible Position	
- TFCI existence	
- Number of bits for Pilot bits(SF=128,256)	
- Downlink DPCH Offset Value	
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	Inactive
- Transmission gap pattern sequence configuration parameters	
- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TT/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present

- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	Not Present
- Primary CPICH usage for channel estimation	
- DPCH frame offset	0 chips
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	
- Spreading factor	
- Code number	
- Scrambling code change	
- TPC combination index	
- SSDT Cell Identity	
- Closed loop timing adjustment mode	
- Secondary CCPCH info	
- Selection Indicator	Not Present
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- Secondary scrambling code	
- SSDT Indicator	1
- Spreading factor	FALSE
- Code number	Reference to TS34.108 clause 6.10 Parameter Set SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Pilot symbol existence	FALSE
- TFCI existence	TRUE
- Fixed or Flexible Position	Flexible
- Timing offset	0
- TFCS	Not Present
- FACH/PCH information	Not Present
- TFS	
- Dynamic Transport format information	
- Number of Transport blocks	
- RLC size	
- Semi-static Transport Format information	
- Transmission time interval	
- Type of channel coding	
- Coding Rate	
- Rate matching attribute	
- CRC size	
- TFS	
- Dynamic Transport format information	
- Number of Transport blocks	
- RLC size	
- Semi-static Transport Format information	
- Transmission time interval	



<ul style="list-style-type: none"> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- References to system information blocks</li> <li>- Scheduling information</li> </ul>	<p>Not Present</p>
---	--------------------

Contents of RADIO BEARER RECONFIGURATION message : AM or UM ( The others of speech in CS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB information to reconfigure	Not Present
- RB identity	
- PDCP info	
- RLC info	
- CHOICE Uplink RLC mode	
- Transmission RLC discard	
- CHOICE SDU discard mode	
- Timer_MRW	
- Timer discard	
- MaxMRW	
- Transmission window size	
- Receiving window size	
- CHOICE Downlink RLC mode	
- In-sequence delivery	
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	
- Uplink transport channel type	
- Transport channel identity	
- Logical channel identity	
- MAC logical channel priority	
- Logical channel max loss	
- Number of RLC logical channels	
- Downlink transport channel type	
- Transport channel identity	
- Logical channel identity	
-RB suspend/resume	
RB information to be affected	(UM DCCH for RRC)
- RB identity	1
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1

- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1
RB information to be affected	(AM DCCH for RRC)
- RB identity	2
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
- MAC logical channel priority	2
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
RB information to be affected	(AM DCCH for NAS_DT High priority)
- RB identity	3
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	3
- MAC logical channel priority	3
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	3
RB information to be affected	(AM DCCH for NAS_DT Low priority)
- RB identity	4
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	4
- MAC logical channel priority	4
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	4
RB information to be affected	(TM DTCH)
- RB identity	5
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	2
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	2
- Logical channel identity	1
UL Transport channel information for all transport channels	
- TFC subset	( This IE is repeated for TFC number.)
- Allowed Transport Format combination	0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.)
- UL DCH TFCS	( This IE is repeated for TFC number.)

<ul style="list-style-type: none"> <li>- Normal</li> <li>- TFCI Field 1 information</li> <li>- CHOICE TFCS representation</li> <li>- TFCS addition information</li> <li>- CHOICE CTFC Size</li> <li>- CTFC information</li> <li>- Power offset information</li> <li>- CHOICE Gain Factor</li> <li>- Gain factor <math>\beta_c</math></li> <li>- Gain factor <math>\beta_d</math></li> <li>- Reference TFC ID</li> <li>- Power offset Pp-m</li> </ul>	<p>Addition</p> <p>Refer to TS34.108 clause 6.10 Parameter Set</p> <p>Signalled Gain Factor</p> <p>0</p> <p>0</p> <p>Not Present</p> <p>0dB</p> <p>Not Present</p>
Deleted UL TrCH information <ul style="list-style-type: none"> <li>- Transport channel identity</li> </ul>	
Added or Reconfigured UL TrCH information <ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> </ul>	<p>1</p> <p>( This IE is repeated for TFI number)</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Not Present</p>
DRAC static information <ul style="list-style-type: none"> <li>- Transmission Time Validity</li> <li>- Time duration before retry</li> <li>- DRAC Class identity</li> </ul>	
DL Transport channel information common for all transport channel <ul style="list-style-type: none"> <li>- SCCPCH TFCS</li> <li>- CHOICE DL parameters</li> <li>- DL DCH TFCS</li> <li>- Normal</li> <li>- TFCI Field 1 information</li> <li>- CHOICE TFCS representation</li> <li>- TFCS addition information</li> <li>- CHOICE CTFC Size</li> <li>- CTFC information</li> <li>- Power offset information</li> <li>- CHOICE Gain Factors</li> <li>- Gain factor <math>\beta_c</math></li> <li>- Gain factor <math>\beta_d</math></li> <li>- Reference TFC ID</li> <li>- Power offset Pp-m</li> </ul>	<p>Not Present</p> <p>Independent</p> <p>( This IE is repeated for TFC number.)</p> <p>Addition</p> <p>Number of bits used must be enough to cover all combinations of CTFC from clause 6.10.</p> <p>Refer to TS34.108 clause 6.10 Parameter Set</p> <p>Signalled Gain Factor</p> <p>0</p> <p>0</p> <p>Not Present</p> <p>0dB</p> <p>Not Present</p>
Deleted DL TrCH information <ul style="list-style-type: none"> <li>- Transport channel identity</li> </ul>	
Added or Reconfigured DL TrCH information <ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- UL TrCH Identity</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	<p>1</p> <p>SameAsUL</p> <p>1</p> <p>0.00</p> <p>Not Present</p>
Frequency info <ul style="list-style-type: none"> <li>- UARFCN uplink(Nu)</li> <li>- UARFCN downlink(Nd)</li> </ul>	<p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p>
Maximum allowed UL TX power	33dBm
Uplink DPCH info <ul style="list-style-type: none"> <li>-Uplink DPCH power control info</li> </ul>	
<ul style="list-style-type: none"> <li>- DPCCH power offset</li> <li>- PC Preamble</li> <li>- Power Control Algorithm</li> <li>- TPC step size</li> </ul>	<p>-6dB</p> <p>8slot</p> <p>Algorithm1</p> <p>1dB</p>

- Scrambling code type	Long
- Scrambling code number	0 ( 0 to 16777215)
- Number of DPDCH	Not Present(1)
- spreading factor	SF is reference to TS34.108 clause 6.10 Parameter Set
- TFCI existence	TRUE
- Number of FBI bit	Not Present(0)
- Puncturing Limit	Reference to TS34.108 clause 6.10 Parameter Set
Downlink information common for all radio links	
- Downlink DPCH info common for all RL	
- Downlink DPCH power control information	
- DPC mode	0 (single)
- Spreading factor	Reference to TS34.108 clause 6.10 Parameter Set
- Fixed or Flexible Position	Flexible
- TFCI existence	TRUE
- Number of bits for Pilot bits(SF=128,256)	Not Present
- Downlink DPCH Offset Value	0
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	Inactive
- Transmission gap pattern sequence configuration parameters	
- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	100
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- DPCH frame offset	0 chips
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	1
- Spreading factor	Reference to TS34.108 clause 6.10 Parameter Set
- Code number	SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Scrambling code change	No change



Contents of RADIO BEARER RECONFIGURATION message : AM or UM ( Speech in CS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	NoDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB information to reconfigure	Not Present
- RB identity	
- PDCP info	
- RLC info	
- CHOICE Uplink RLC mode	
- Transmission RLC discard	
- CHOICE SDU discard mode	
- Timer_MRW	
- Timer discard	
- MaxMRW	
- Transmission window size	
- Receiving window size	
- CHOICE Downlink RLC mode	
- In-sequence delivery	
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	
- Uplink transport channel type	
- Transport channel identity	
- Logical channel identity	
- MAC logical channel priority	
- Logical channel max loss	
- Number of RLC logical channels	
- Downlink transport channel type	
- Transport channel identity	
- Logical channel identity	
-RB suspend/resume	
RB information to be affected	(UM DCCH for RRC)
- RB identity	1
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1

- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1
RB information to be affected	(AM DCCH for RRC)
- RB identity	2
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
- MAC logical channel priority	2
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
RB information to be affected	(AM DCCH for NAS_DT High priority)
- RB identity	3
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	3
- MAC logical channel priority	3
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	3
RB information to be affected	(AM DCCH for NAS_DT Low priority)
- RB identity	4
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	4
- MAC logical channel priority	4
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	4
RB information to be affected	(DTCH TM)
- RB identity	5
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	2
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	2
- Logical channel identity	1
RB information to be affected	(DTCH TM)
- RB identity	6
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH



- Transport channel identity	3
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	3
- Logical channel identity	1
RB information to be affected	( This IE is needed for 12.2 kbps and 10.2 kbps)
- RB identity	7
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	4
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	4
- Logical channel identity	1
UL Transport channel information for all transport channels	
- TFC subset	( This IE is repeated for TFC number.)
- Allowed Transport Format combination	0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.)
- UL DCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	
- CHOICE TFCS representation	Addition
- TFCS addition information	
- CHOICE CTFC Size	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set
- CTFC information	
- Power offset information	
- CHOICE Gain Factors	Signalled Gain Factor
- Gain factor $\beta_c$	0
- Gain factor $\beta_d$	0
- Reference TFC ID	Not Present
- Power offset Pp-m	0dB
Deleted UL TrCH information	Not Present
- Transport channel identity	
Added or Reconfigured UL TrCH information	
- Transport channel identity	1
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
DRAC static information	Not Present
- Transmission Time Validity	
- Time duration before retry	
- DRAC Class identity	
DL Transport channel information common for all transport channel	
- SCCPCH TFCS	Not Present
- CHOICE DL parameters	Independent
- DL DCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	
- CHOICE TFCS representation	Addition
- TFCS addition information	

- CHOICE CTFC Size	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10.
- CTFC information	Refer to TS34.108 clause 6.10 Parameter Set
- Power offset information	Not Present
Deleted DL TrCH information	Not Present
- Transport channel identity	
Added or Reconfigured DL TrCH information	
- Transport channel identity	1
- CHOICE DL parameters	SameAsUL
- UL TrCH Identity	1
- DCH quality target	
- BLER Quality value	0.00
- Transparent mode signalling info	Not Present
Frequency info	
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
Uplink DPCH info	
- Uplink DPCH power control info	
- DPCCH power offset	-6dB
- PC Preamble	8slot
- Power Control Algorithm	Algorithm1
- TPC step size	1dB
- Scrambling code type	Long
- Scrambling code number	0 ( 0 to 16777215)
- Number of DPDCH	Not Present(1)
- spreading factor	SF is reference to TS34.108 clause 6.10 Parameter Set
- TFCI existence	TRUE
- Number of FBI bit	Not Present(0)
- Puncturing Limit	Reference to TS34.108 clause 6.10 Parameter Set
Downlink information common for all radio links	
- Downlink DPCH info common for all RL	
- Downlink DPCH power control information	
- DPC mode	0 (single)
- Spreading factor	Reference to TS34.108 clause 6.10 Parameter Set
- Fixed or Flexible Position	Flexible
- TFCI existence	TRUE
- Number of bits for Pilot bits(SF=128,256)	Not Present
- Downlink DPCH Offset Value	0
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	Inactive
- Transmission gap pattern sequence configuration parameters	
- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present

CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	100
- Primary scrambling code	Not Present
- PDSCH with SHO DCH info	
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- DPCH frame offset	0 chips
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	
- Spreading factor	1
- Code number	Reference to TS34.108 clause 6.10 Parameter Set SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Scrambling code change	No change
- TPC combination index	0
- SSDT Cell Identity	-a
- Closed loop timing adjustment mode	Not Present
- Secondary CCPCH info	Not Present
- Selection Indicator	
- Primary CPICH usage for channel estimation	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- Secondary scrambling code	
- SSDT Indicator	
- Spreading factor	
- Code number	
- Pilot symbol existence	
- TFCI existence	
- Fixed or Flexible Position	
- Timing offset	
- TFCS	Not Present
- FACH/PCH information	Not Present
- TFS	
- Dynamic Transport format information	
- Number of Transport blocks	
- RLC size	
- Semi-static Transport Format information	
- Transmission time interval	
- Type of channel coding	
- Coding Rate	
- Rate matching attribute	
- CRC size	
- TFS	
- Dynamic Transport format information	
- Number of Transport blocks	
- RLC size	
- Semi-static Transport Format information	
- Transmission time interval	
- Type of channel coding	
- Coding Rate	
- Rate matching attribute	
- CRC size	
- References to system information blocks	Not Present
- Scheduling information	

Contents of RADIO BEARER RECONFIGURATION message: AM or UM ( Packet to CELL\_DCH from CELL\_DCH in PS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB information to reconfigure	Not Present
- RB identity	
- PDCP info	
- PDCP info	
- RLC info	
- CHOICE Uplink RLC mode	
- Transmission RLC discard	
- CHOICE SDU discard mode	
- Timer_MRW	
- Timer discard	
- MaxMRW	
- Transmission window size	
- Receiving window size	
- CHOICE Downlink RLC mode	
- In-sequence delivery	
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	
- Uplink transport channel type	
- Transport channel identity	
- Logical channel identity	
- MAC logical channel priority	
- Logical channel max loss	
- Number of RLC logical channels	
- Downlink transport channel type	
- Transport channel identity	
- Logical channel identity	
-RB suspend/resume	
RB information to be affected	(UM DCCH for RRC)
- RB identity	1
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH

- Transport channel identity	1
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1
RB information to be affected	(AM DCCH for RRC)
- RB identity	2
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
- MAC logical channel priority	2
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
RB information to be affected	(AM DCCH for NAS_DT High priority)
- RB identity	3
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	3
- MAC logical channel priority	3
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	3
RB information to be affected	(AM DCCH for NAS_DT Low priority)
- RB identity	4
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	4
- MAC logical channel priority	4
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	4
RB information to be affected	(AM DTCH)
- RB identity	5
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	2
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	2
- Logical channel identity	1
UL Transport channel information for all transport channels	
- TFC subset	( This IE is repeated for TFC number.)
- Allowed Transport Format combination	0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108

<ul style="list-style-type: none"> <li>- UL DCH TFCS</li> <li>- Normal</li> <li>- TFCI Field 1 information</li> <li>- CHOICE TFCS representation</li> <li>- TFCS addition information</li> <li>- CHOICE CTFC Size</li> <li>- CTFC information</li> <li>- Power offset information</li> <li>- CHOICE Gain Factors</li> <li>- Gain factor <math>\beta_c</math></li> <li>- Gain factor <math>\beta_d</math></li> <li>- Reference TFC ID</li> <li>- Power offset Pp-m</li> </ul>	<p>clause 6.10 Parameter Set.) ( This IE is repeated for TFC number.)</p>
Deleted UL TrCH information	Addition
Added or Reconfigured UL TrCH information	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> </ul>	<p>Signalled Gain Factor 0 0 Not Present 0dB</p>
<ul style="list-style-type: none"> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> </ul>	Not Present
DRAC static information	1
<ul style="list-style-type: none"> <li>- Transmission Time Validity</li> <li>- Time duration before retry</li> <li>- DRAC Class identity</li> </ul>	( This IE is repeated for TFI number) Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set
DL Transport channel information common for all transport channel	Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Not Present
<ul style="list-style-type: none"> <li>- SCCPCH TFCS</li> <li>- CHOICE DL parameters</li> <li>- DL DCH TFCS</li> <li>- Normal</li> <li>- TFCI Field 1 information</li> <li>- CHOICE TFCS representation</li> <li>- TFCS addition information</li> <li>- CHOICE CTFC Size</li> <li>- CTFC information</li> <li>- Power offset information</li> <li>- CHOICE Gain Factors</li> <li>- Gain factor <math>\beta_c</math></li> <li>- Gain factor <math>\beta_d</math></li> <li>- Reference TFC ID</li> <li>- Power offset Pp-m</li> </ul>	Not Present Independent ( This IE is repeated for TFC number.)
Deleted DL TrCH information	Addition
Added or Reconfigured DL TrCH information	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- DCH quality target</li> </ul>	<p>Signalled Gain Factor 0 0 Not Present 0dB</p>
	Not Present
	1
	Independent
	( This IE is repeated for TFI number) Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set
	Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set

- BLER Quality value	0.00
- Transparent mode signalling info	Not Present
Frequency info	
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
Uplink DPCH info	
-Uplink DPCH power control info	
-DPCCH Power offset	-6dB
-PC Preamble	8slot
-Power Control Algorithm	Algorithm1
-TPC step size	1dB
- Scrambling code type	Long
- Scrambling code number	0 ( 0 to 16777215)
- Number of DPDCH	Not Present(1)
- spreading factor	SF is reference to TS34.108 clause 6.10 Parameter Set
- TFCI existence	TRUE
- Number of FBI bits	Not Present(0)
- Puncturing Limit	Reference to TS34.108 clause 6.10 Parameter Set
Downlink information common for all radio links	Not Present
- Downlink DPCH info common for all RL	
- Downlink DPCH power control information	
- DPC mode	0 (single)
- Spreading factor	Reference to TS34.108 clause 6.10 Parameter Set
- Fixed or Flexible Position	Flexible
- TFCI existence	TRUE
- Number of bits for Pilot bits(SF=128,256)	Not Present
- Downlink DPCH Offset Value	0
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	Inactive
- Transmission gap pattern sequence configuration parameters	
- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present

<ul style="list-style-type: none"> <li>- Downlink DPCH info for each RL</li> <li>- Primary CPICH usage for channel estimation</li> <li>- DPCH frame offset</li> <li>- Secondary CPICH info</li> <li>- Secondary scrambling code</li> <li>- channelisation code</li> <li>- DL channelisation code</li> <li>- Secondary scrambling code</li> <li>- Spreading factor</li> <li>- Code number</li> <li>- Scrambling code change</li> <li>- TPC combination index</li> <li>- SSST Cell Identity</li> <li>- Closed loop timing adjustment mode</li> <li>- Secondary CCPCH info</li> <li>- Selection Indicator</li> <li>- Primary CPICH usage for channel estimation</li> <li>- Secondary CPICH info</li> <li>- Secondary scrambling code</li> <li>- channelisation code</li> <li>- Secondary scrambling code</li> <li>- SSST Indicator</li> <li>- Spreading factor</li> <li>- Code number</li> <li>- Pilot symbol existence</li> <li>- TFCI existence</li> <li>- Fixed or Flexible Position</li> <li>- Timing offset</li> <li>- TFCS</li> <li>- FACH/PCH information</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- References to system information blocks</li> <li>- Scheduling information</li> </ul>	<p>Primary CPICH may be used 0 chips Not Present</p> <p>1 Reference to TS34.108 clause 6.10 Parameter Set SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set ) No change 0 -a Not Present Not Present</p> <p>Not Present Not Present</p> <p>Not Present</p>
---	---

Contents of RADIO BEARER RECONFIGURATION message : AM or UM ( Packet to CELL\_DCH from CELL\_FACH in PS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
<ul style="list-style-type: none"> <li>- message authentication code</li> <li>- RRC message sequence number</li> </ul>	
Integrity protection mode info	Not Present
<ul style="list-style-type: none"> <li>- Integrity protection mode command</li> <li>- Downlink integrity protection activation info</li> <li>- RRC message sequence number</li> <li>- RRC message sequence number</li> <li>- Integrity protection algorithm</li> </ul>	



- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB information to reconfigure	(UM DCCH for RRC)
- RB identity	1
- PDCP info	Not Present
- RLC info	Not Present
- CHOICE Uplink RLC mode	
- Transmission RLC discard	
- CHOICE SDU discard mode	
- MAX_DAT	
- CHOICE Downlink RLC mode	
- In-sequence delivery	
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1
RB information to reconfigure	(AM DCCH for RRC)
- RB identity	2
- PDCP info	Not Present
- RLC info	Not Present
- CHOICE Uplink RLC mode	
- Transmission RLC discard	
- SDU discard mode	
- MAX_DAT	
- Transmission window size	
- Receiving window size	
- Timer_RST	
- Max_RST	
- Polling info	
- Timer_poll_prohibit	
- Timer_poll	
- Poll_SDU	
- Last transmission PU poll	
- Last retransmission PU poll	
- Poll_Windows	
- CHOICE Downlink RLC mode	
- In-sequence delivery	
- Receiving window size	
- Downlink RLC status info	
- Timer_status_prohibit	
- Timer_EPC	
- Missing PU indicator	





<ul style="list-style-type: none"> <li>- MAC logical channel priority</li> <li>- Logical channel max loss</li> <li>- Number of RLC logical channels</li> <li>- Downlink transport channel type</li> <li>- Transport channel identity</li> <li>- Logical channel identity</li> </ul> <p>UL Transport channel information for all transport channels</p> <ul style="list-style-type: none"> <li>- TFC subset</li> <li>- Allowed Transport Format combination</li> </ul> <ul style="list-style-type: none"> <li>- UL DCH TFCS</li> <li>- Normal</li> <li>- TFCI Field 1 information</li> <li>- CHOICE TFCS representation</li> <li>- TFCS addition information</li> <li>- CHOICE CTFC Size</li> </ul> <ul style="list-style-type: none"> <li>- CTFC information</li> <li>- Power offset information</li> <li>- CHOICE Gain Factors</li> <li>- Gain factor <math>\beta_c</math></li> <li>- Gain factor <math>\beta_d</math></li> <li>- Reference TFC ID</li> <li>- Power offset Pp-m</li> </ul> <p>Deleted UL TrCH information</p> <ul style="list-style-type: none"> <li>- Transport channel identity</li> </ul> <p>Added or Reconfigured UL TrCH information</p> <ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> </ul> <p>Added or Reconfigured UL TrCH information</p> <ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> </ul> <p>DRAC static information</p> <ul style="list-style-type: none"> <li>- Transmission Time Validity</li> <li>- Time duration before retry</li> <li>- DRAC Class identity</li> </ul> <p>DL Transport channel information common for all transport channel</p> <ul style="list-style-type: none"> <li>- SCCPCH TFCS</li> <li>- CHOICE DL parameters</li> <li>- DL DCH TFCS</li> <li>- Normal</li> <li>- TFCI Field 1 information</li> <li>- CHOICE TFCS representation</li> <li>- TFCS addition information</li> <li>- CHOICE CTFC Size</li> </ul> <ul style="list-style-type: none"> <li>- CTFC information</li> </ul>	<p>( This IE is repeated for TFC number.) 0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.) ( This IE is repeated for TFC number.)</p> <p>Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set</p> <p>Signalled Gain Factor 0 0 Not Present 0dB</p> <p>Not Present</p> <p>1</p> <p>( This IE is repeated for TFI number) Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set</p> <p>2</p> <p>( This IE is repeated for TFI number) Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Not Present</p> <p>Not Present Independent ( This IE is repeated for TFC number.)</p> <p>Addition</p> <p>Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set</p>
--	--

- Power offset information	Not Present
Deleted DL TrCH information	
- Transport channel identity	3
Deleted DL TrCH information	
- Transport channel identity	4
Added or Reconfigured DL TrCH information	
- Transport channel identity	1
- CHOICE DL parameters	Independent
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	
- BLER Quality value	0.00
- Transparent mode signalling info	Not Present
Added or Reconfigured DL TrCH information	
- Transport channel identity	2
- CHOICE DL parameters	Independent
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	
- BLER Quality value	0.00
- Transparent mode signalling info	Not Present
Frequency info	
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
Uplink DPCH info	
-Uplink DPCH power control info	
-DPCH Power offset	-6dB
-PC Preamble	8slot
-Power Control Algorithm	Algorithm1
-TPC step size	1dB
- Scrambling code type	Long
- Scrambling code number	0 ( 0 to 16777215)
- Number of DPDCH	Not Present(1)
- spreading factor	SF is reference to TS34.108 clause 6.10 Parameter Set
- TFCI existence	TRUE
- Number of FBI bits	Not Present(0)
- Puncturing Limit	Reference to TS34.108 clause 6.10 Parameter Set
Downlink information common for all radio links	
- Downlink DPCH info common for all RL	
- Downlink DPCH power control information	
- DPC mode	0 (single)
- Spreading factor	Reference to TS34.108 clause 6.10 Parameter Set
- Fixed or Flexible Position	Flexible
- TFCI existence	TRUE
- Number of bits for Pilot bits(SF=128,256)	Reference to TS34.108 clause 6.10 Parameter Set
- Downlink DPCH Offset Value	0
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	Inactive
- Transmission gap pattern sequence configuration parameters	

- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- DPCH frame offset	0 chips
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	
- Spreading factor	1
- Code number	Reference to TS34.108 clause 6.10 Parameter Set SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Scrambling code change	No change
- TPC combination index	0
- SSDT Cell Identity	-a
- Closed loop timing adjustment mode	Not Present
- Secondary CCPCH info	Not Present
- Selection Indicator	
- Primary CPICH usage for channel estimation	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- Secondary scrambling code	
- SSDT Indicator	
- Spreading factor	
- Code number	
- Pilot symbol existence	
- TFCI existence	
- Fixed or Flexible Position	
- Timing offset	
- TFCS	Not Present
- FACH/PCH information	Not Present
- TFS	
- Dynamic Transport format information	

<ul style="list-style-type: none"> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- References to system information blocks</li> <li>- Scheduling information</li> </ul>	Not Present
--	-------------

Contents of RADIO BEARER RECONFIGURATION message : AM or UM( Packet to CELL\_FACH from CELL\_DCH in PS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
<ul style="list-style-type: none"> <li>- message authentication code</li> <li>- RRC message sequence number</li> </ul>	
Integrity protection mode info	Not Present
<ul style="list-style-type: none"> <li>- Integrity protection mode command</li> <li>- Downlink integrity protection activation info</li> <li>- RRC message sequence number</li> <li>- RRC message sequence number</li> <li>- Integrity protection algorithm</li> <li>- Integrity protection initialisation number</li> </ul>	
Ciphering mode info	Not Present
<ul style="list-style-type: none"> <li>- Ciphering mode command</li> <li>- Ciphering algorithm</li> <li>- Activation time for DPCH</li> <li>- Radio bearer downlink ciphering activation time info</li> <li>- Radio bearer identity</li> <li>- RLC sequence number</li> </ul>	
Activation time	(256+CFN-(CFN MOD 8 + 8 ))MOD 256
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
<ul style="list-style-type: none"> <li>- PLMN identity</li> <li>- CN common GSM-MAP NAS system information</li> <li>- CN domain identity</li> <li>- CN domain specific GSM-MAP NAS system information</li> </ul>	
RB information to reconfigure	(UM DCCH for RRC)
<ul style="list-style-type: none"> <li>- RB identity</li> <li>- PDCP info</li> <li>- RLC info</li> <li>- CHOICE Uplink RLC mode</li> <li>- Transmission RLC discard</li> <li>- CHOICE SDU discard mode</li> <li>- MAX_DAT</li> <li>- CHOICE Downlink RLC mode</li> <li>- In-sequence delivery</li> <li>- RB mapping info</li> <li>- Information for each multiplexing option</li> <li>- Number of RLC logical channels</li> </ul>	1 Not Present Not Present
	1

<ul style="list-style-type: none"> <li>- Uplink transport channel type</li> <li>- Logical channel identity</li> <li>- MAC logical channel priority</li> <li>- Logical channel max loss</li> <li>- Number of RLC logical channels</li> <li>- Downlink transport channel type</li> <li>- Logical channel identity</li> </ul>	RACH 1 2 0 1 FACH 1 (AM DCCH for RRC) 2 Not Present Not Present
RB information to reconfigure <ul style="list-style-type: none"> <li>- RB identity</li> <li>- PDCP info</li> <li>- RLC info</li> <li>- CHOICE Uplink RLC mode</li> <li>- Transmission RLC discard</li> <li>- CHOICE SDU discard mode</li> <li>- MAX_DAT</li> <li>- Transmission window size</li> <li>- Receiving window size</li> <li>- Timer_RST</li> <li>- Max_RST</li> <li>- Polling info</li> <li>- Timer_poll_prohibit</li> <li>- Timer_poll</li> <li>- Poll_SDU</li> <li>- Last transmission PU poll</li> <li>- Last retransmission PU poll</li> <li>- Poll_Windows</li> <li>- CHOICE Downlink RLC mode</li> <li>- In-sequence delivery</li> <li>- Receiving window size</li> <li>- Downlink RLC status info</li> <li>- Timer_status_prohibit</li> <li>- Timer_EPC</li> <li>- Missing PU indicator</li> <li>- RB mapping info</li> <li>- Information for each multiplexing option</li> <li>- Number of RLC logical channels</li> <li>- Uplink transport channel type</li> <li>- Logical channel identity</li> <li>- MAC logical channel priority</li> <li>- Logical channel max loss</li> <li>- Number of RLC logical channels</li> <li>- Downlink transport channel type</li> <li>- Logical channel identity</li> </ul>	1 RACH 2 3 0 1 FACH 2 (AM DCCH for NAS_DT High priority) 3 Not Present Not Present
RB information to reconfigure <ul style="list-style-type: none"> <li>- RB identity</li> <li>- PDCP info</li> <li>- RLC info</li> <li>- CHOICE Uplink RLC mode</li> <li>- Transmission RLC discard</li> <li>- SDU discard mode</li> <li>- MAX_DAT</li> <li>- Transmission window size</li> <li>- Receiving window size</li> <li>- Timer_RST</li> <li>- Max_RST</li> <li>- Polling info</li> <li>- Timer_poll_prohibit</li> <li>- Timer_poll</li> <li>- Poll_SDU</li> <li>- Last transmission PU poll</li> <li>- Last retransmission PU poll</li> <li>- Poll_Windows</li> <li>- CHOICE Downlink RLC mode</li> <li>- In-sequence delivery</li> <li>- Receiving window size</li> <li>- Downlink RLC status info</li> <li>- Timer_status_prohibit</li> <li>- Timer_EPC</li> </ul>	



<ul style="list-style-type: none"> <li>- Missing PU indicator</li> <li>- RB mapping info</li> <li>- Information for each multiplexing option <ul style="list-style-type: none"> <li>- Number of RLC logical channels</li> <li>- Uplink transport channel type</li> <li>- Logical channel identity</li> <li>- MAC logical channel priority</li> <li>- Logical channel max loss</li> </ul> </li> <li>- Number of RLC logical channels</li> <li>- Downlink transport channel type</li> <li>- Logical channel identity</li> </ul>	1 RACH 3 4 0 1 FACH 3 (AM DCCH for NAS_DT Low priority) 4 Not Present Not Present
RB information to reconfigure <ul style="list-style-type: none"> <li>- RB identity</li> <li>- PDCP info</li> <li>- RLC info <ul style="list-style-type: none"> <li>- CHOICE Uplink RLC mode <ul style="list-style-type: none"> <li>- Transmission RLC discard</li> <li>- CHOICE SDU discard mode <ul style="list-style-type: none"> <li>- MAX_DAT</li> </ul> </li> <li>- Transmission window size</li> <li>- Receiving window size</li> <li>- Timer_RST</li> <li>- Max_RST</li> <li>- Polling info <ul style="list-style-type: none"> <li>- Timer_poll_prohibit</li> <li>- Timer_poll</li> <li>- Poll_SDU</li> </ul> </li> <li>- Last transmission PU poll</li> <li>- Last retransmission PU poll</li> <li>- Poll_Windows</li> </ul> </li> <li>- CHOICE Downlink RLC mode <ul style="list-style-type: none"> <li>- In-sequence delivery</li> <li>- Receiving window size</li> <li>- Downlink RLC status info <ul style="list-style-type: none"> <li>- Timer_status_prohibit</li> <li>- Timer_EPC</li> </ul> </li> <li>- Missing PU indicator</li> </ul> </li> <li>- RB mapping info</li> <li>- Information for each multiplexing option <ul style="list-style-type: none"> <li>- Number of RLC logical channels</li> <li>- Uplink transport channel type</li> <li>- Logical channel identity</li> <li>- MAC logical channel priority</li> <li>- Logical channel max loss</li> </ul> </li> <li>- Number of RLC logical channels</li> <li>- Downlink transport channel type</li> <li>- Logical channel identity</li> </ul> </li></ul>	1 RACH 4 5 0 1 FACH 4 (AM DTCH) 5 Not Present Not Present
RB information to reconfigure <ul style="list-style-type: none"> <li>- RB identity</li> <li>- PDCP info</li> <li>- RLC info <ul style="list-style-type: none"> <li>- CHOICE Uplink RLC mode <ul style="list-style-type: none"> <li>- Transmission RLC discard</li> <li>- CHOICE SDU discard mode <ul style="list-style-type: none"> <li>- MAX_DAT</li> </ul> </li> <li>- Transmission window size</li> <li>- Receiving window size</li> <li>- Timer_RST</li> <li>- Max_RST</li> <li>- Polling info <ul style="list-style-type: none"> <li>- Timer_poll_prohibit</li> <li>- Timer_poll</li> <li>- Poll_SDU</li> </ul> </li> <li>- Last transmission PU poll</li> <li>- Last retransmission PU poll</li> <li>- Poll_Windows</li> </ul> </li> <li>- CHOICE Downlink RLC mode <ul style="list-style-type: none"> <li>- In-sequence delivery</li> </ul> </li> </ul> </li></ul>	

<ul style="list-style-type: none"> <li>- Receiving window size</li> <li>- Downlink RLC status info</li> <li>- Timer_status_prohibit</li> <li>- Timer_EPC</li> <li>- Missing PU indicator</li> </ul>	
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	6
- MAC logical channel priority	6
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	1
RB information to reconfigure	(TM CCCH uplink for RRC)
- RB identity	0
- PDCP info	Not Present
- RLC info	
- CHOICE Uplink RLC mode	TM RLC
- Transmission RLC discard	Not Present
- CHOICE Downlink RLC mode	TM RLC
Segmentation indication	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	5
- MAC logical channel priority	1
- Logical channel max loss	0
RB information to reconfigure	(UM CCCH downlink for RRC)
- RB identity	0
- PDCP info	Not Present
- RLC info	
- CHOICE Uplink RLC mode	Not Present
- CHOICE Downlink RLC mode	UM RLC
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	6
RB information to reconfigure	(TM BCCH for RRC)
- RB identity	6
- PDCP info	Not Present
- RLC info	
- CHOICE Uplink RLC mode	Not Present
- CHOICE Downlink RLC mode	TM RLC
Segmentation Indication	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	5
RB information to reconfigure	(TM PCCH for RRC)
- RB identity	7
- PDCP info	Not Present
- RLC info	
- CHOICE Uplink RLC mode	Not Present
- CHOICE Downlink RLC mode	TM RLC
Segmentation Indication	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Downlink transport channel type	PCH
- Logical channel identity	1
RB information to be affected	Not Present
- RB identity	
- RB mapping info	

<ul style="list-style-type: none"> <li>- Information for each multiplexing option</li> <li>- Number of RLC logical channels</li> <li>- Uplink transport channel type</li> <li>- Transport channel identity</li> <li>- Logical channel identity</li> <li>- MAC logical channel priority</li> <li>- Logical channel max loss</li> <li>- Number of RLC logical channels</li> <li>- Downlink transport channel type</li> <li>- Transport channel identity</li> <li>- Logical channel identity</li> </ul>	
UL Transport channel information for all transport channels	
<ul style="list-style-type: none"> <li>- TFC subset</li> <li>- Allowed Transport Format combination</li> </ul>	( This IE is repeated for TFC number.) 0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.) Not Present
<ul style="list-style-type: none"> <li>- UL DCH TFCS</li> </ul>	Not Present
Deleted UL TrCH information	
<ul style="list-style-type: none"> <li>- Transport channel identity</li> </ul>	Not Present
Added or Reconfigured UL TrCH information	
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> </ul>	1  ( This IE is repeated for TFI number) Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set
DRAC static information	
<ul style="list-style-type: none"> <li>- Transmission Time Validity</li> <li>- Time duration before retry</li> <li>- DRAC Class identity</li> </ul>	Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Not Present
DL Transport channel information common for all transport channel	
<ul style="list-style-type: none"> <li>- SCCPCH TFCS</li> <li>- Normal</li> <li>- TFCI Field 1 information</li> <li>- CHOICE TFCS representation</li> <li>- TFCS addition information</li> <li>- CHOICE CTFC Size</li> </ul>	( This IE is repeated for TFC number.)  Addition
<ul style="list-style-type: none"> <li>- CTFC information</li> <li>- Power offset information</li> </ul>	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set
<ul style="list-style-type: none"> <li>- CHOICE DL parameters</li> <li>- DL DCH TFCS</li> </ul>	Not Present Independent Not Present
Deleted DL TrCH information	
<ul style="list-style-type: none"> <li>- Transport channel identity</li> </ul>	Not Present
Added or Reconfigured DL TrCH information	
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	1 Independent  ( This IE is repeated for TFI number) Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set
Added or Reconfigured DL TrCH information	
<ul style="list-style-type: none"> <li>- Transport channel identity</li> </ul>	Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Not Present  Not Present
	2

- CHOICE DL parameters	Independent
- TFS	( This IE is repeated for TFI number)
- Dynamic Transport format information	Reference to TS34.108 clause 6.10 Parameter Set
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	
- Semi-static Transport Format information	Reference to TS34.108 clause 6.10 Parameter Set
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	Not Present
- BLER Quality value	
- Transparent mode signalling info	Not Present
Added or Reconfigured DL TrCH information	
- Transport channel identity	3
- CHOICE DL parameters	Independent
- TFS	( This IE is repeated for TFI number)
- Dynamic Transport format information	Reference to TS34.108 clause 6.10 Parameter Set
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	
- Semi-static Transport Format information	Reference to TS34.108 clause 6.10 Parameter Set
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	Not Present
- BLER Quality value	
- Transparent mode signalling info	Not Present
Added or Reconfigured DL TrCH information	
- Transport channel identity	4
- CHOICE DL parameters	Independent
- TFS	( This IE is repeated for TFI number)
- Dynamic Transport format information	Reference to TS34.108 clause 6.10 Parameter Set
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	
- Semi-static Transport Format information	Reference to TS34.108 clause 6.10 Parameter Set
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	Not Present
- BLER Quality value	
- Transparent mode signalling info	Not Present
Frequency info	
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
PRACH info	
- Available Signature	
- Signature	0
- Signature	1
- Signature	2
- Signature	3
- Signature	4
- Signature	5
- Signature	6
- Signature	7
- Available SF	Reference to TS34.108 clause 6.10 Parameter Set
- Scrambling code number	0
- Puncturing Limit	Reference to TS34.108 clause 6.10 Parameter Set
- Available Sub Channel number	
- Sub channel number	0
- Sub channel number	1
- Sub channel number	2
- Sub channel number	3

- Sub channel number	4
- Sub channel number	5
- Sub channel number	6
- Sub channel number	7
- Sub channel number	8
- Sub channel number	9
- Sub channel number	10
- Sub channel number	11
Downlink information common for all radio links	Not Present
- Downlink DPCH info common for all RL	
- Downlink DPCH power control information	
- DPC mode	
- Spreading factor	
- Fixed or Flexible Position	
- TFCI existence	
- Number of bits for Pilot bits(SF=128,256)	
- Downlink DPCH Offset Value	
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	Inactive
- Transmission gap pattern sequence configuration parameters	
- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	Not Present
- Primary CPICH usage for channel estimation	
- DPCH frame offset	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	
- Spreading factor	
- Code number	
- Scrambling code change	

<ul style="list-style-type: none"> <li>- TPC combination index</li> <li>- SSDT Cell Identity</li> <li>- Closed loop timing adjustment mode</li> <li>- Secondary CCPCH info</li> <li>- Selection Indicator</li> <li>- Primary CPICH usage for channel estimation</li> <li>- Secondary CPICH info</li> <li>- Secondary scrambling code</li> <li>- channelisation code</li> <li>- Secondary scrambling code</li> <li>- SSDT Indicator</li> <li>- Spreading factor</li> <li>- Code number</li>   <li>- Pilot symbol existence</li> <li>- TFCI existence</li> <li>- Fixed or Flexible Position</li> <li>- Timing offset</li> <li>- TFCS</li> <li>- FACH/PCH information</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- References to system information blocks</li> <li>- Scheduling information</li> </ul>	<p>Not Present Primary CPICH may be used Not Present</p> <p>1 FALSE Reference to TS34.108 clause 6.10 Parameter Set SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set ) FALSE TRUE Flexible 0 Not Present Not Present</p> <p>Not Present</p>
--	---

Contents of RADIO BEARER RECONFIGURATION message : AM or UM( Packet to CELL\_FACH from CELL\_FACH in PS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	0000 0000 0000 0010B
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB information to reconfigure	(UM DCCH for RRC)
- RB identity	1
- PDCP info	Not Present
- RLC info	Not Present
- CHOICE Uplink RLC mode	
- Transmission RLC discard	
- SDU discard mode	
- MAX_DAT	
- CHOICE Downlink RLC mode	
- In-sequence delivery	
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	1
- MAC logical channel priority	2
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	1
RB information to reconfigure	(AM DCCH for RRC)
- RB identity	2
- PDCP info	Not Present
- RLC info	Not Present
- CHOICE Uplink RLC mode	
- Transmission RLC discard	
- SDU discard mode	
- MAX_DAT	
- Transmission window size	
- Receiving window size	
- Timer_RST	
- Max_RST	
- Polling info	
- Timer_poll_prohibit	

<ul style="list-style-type: none"> <li>- Timer_poll</li> <li>- Poll_SDU</li> <li>- Last transmission PU poll</li> <li>- Last retransmission PU poll</li> <li>- Poll_Windows</li> <li>- CHOICE Downlink RLC mode</li> <li>- In-sequence delivery</li> <li>- Receiving window size</li> <li>- Downlink RLC status info</li> <li>- Timer_status_prohibit</li> <li>- Timer_EPC</li> <li>- Missing PU indicator</li> <li>- RB mapping info</li> <li>- Information for each multiplexing option</li> <li>- Number of RLC logical channels</li> <li>- Uplink transport channel type</li> <li>- Logical channel identity</li> <li>- MAC logical channel priority</li> <li>- Logical channel max loss</li> <li>- Number of RLC logical channels</li> <li>- Downlink transport channel type</li> <li>- Logical channel identity</li> </ul>	1 RACH 2 3 0 1 FACH 2 (AM DCCH for NAS_DT High priority) 3 Not Present Not Present
RB information to reconfigure <ul style="list-style-type: none"> <li>- RB identity</li> <li>- PDCP info</li> <li>- RLC info</li> <li>- CHOICE Uplink RLC mode</li> <li>- Transmission RLC discard</li> <li>- SDU discard mode</li> <li>- MAX_DAT</li> <li>- Transmission window size</li> <li>- Receiving window size</li> <li>- Timer_RST</li> <li>- Max_RST</li> <li>- Polling info</li> <li>- Timer_poll_prohibit</li> <li>- Timer_poll</li> <li>- Poll_SDU</li> <li>- Last transmission PU poll</li> <li>- Last retransmission PU poll</li> <li>- Poll_Windows</li> <li>- CHOICE Downlink RLC mode</li> <li>- In-sequence delivery</li> <li>- Receiving window size</li> <li>- Downlink RLC status info</li> <li>- Timer_status_prohibit</li> <li>- Timer_EPC</li> <li>- Missing PU indicator</li> <li>- RB mapping info</li> <li>- Information for each multiplexing option</li> <li>- Number of RLC logical channels</li> <li>- Uplink transport channel type</li> <li>- Logical channel identity</li> <li>- MAC logical channel priority</li> <li>- Logical channel max loss</li> <li>- Number of RLC logical channels</li> <li>- Downlink transport channel type</li> <li>- Logical channel identity</li> </ul>	3 Not Present Not Present
RB information to reconfigure <ul style="list-style-type: none"> <li>- RB identity</li> <li>- PDCP info</li> <li>- RLC info</li> <li>- CHOICE Uplink RLC mode</li> <li>- Transmission RLC discard</li> <li>- SDU discard mode</li> <li>- MAX_DAT</li> <li>- Transmission window size</li> <li>- Receiving window size</li> </ul>	1 RACH 3 4 0 1 FACH 3 (AM DCCH for NAS_DT Low priority) 4 Not Present Not Present



<ul style="list-style-type: none"> <li>- Timer_RST</li> <li>- Max_RST</li> <li>- Polling info</li> <li>- Timer_poll_prohibit</li> <li>- Timer_poll</li> <li>- Poll_SDU</li> <li>- Last transmission PU poll</li> <li>- Last retransmission PU poll</li> <li>- Poll_Windows</li> <li>- CHOICE Downlink RLC mode</li> <li>- In-sequence delivery</li> <li>- Receiving window size</li> <li>- Downlink RLC status info</li> <li>- Timer_status_prohibit</li> <li>- Timer_EPC</li> <li>- Missing PU indicator</li> <li>- RB mapping info</li> <li>- Information for each multiplexing option</li> <li>- Number of RLC logical channels</li> <li>- Uplink transport channel type</li> <li>- Logical channel identity</li> <li>- MAC logical channel priority</li> <li>- Logical channel max loss</li> <li>- Number of RLC logical channels</li> <li>- Downlink transport channel type</li> <li>- Logical channel identity</li> </ul>	1 RACH 4 5 0 1 FACH 4 (AM DTCH) 5 Not Present Not Present
RB information to reconfigure <ul style="list-style-type: none"> <li>- RB identity</li> <li>- PDCP info</li> <li>- RLC info</li> <li>- CHOICE Uplink RLC mode</li> <li>- Transmission RLC discard</li> <li>- SDU discard mode</li> <li>- MAX_DAT</li> <li>- Transmission window size</li> <li>- Receiving window size</li> <li>- Timer_RST</li> <li>- Max_RST</li> <li>- Polling info</li> <li>- Timer_poll_prohibit</li> <li>- Timer_poll</li> <li>- Poll_SDU</li> <li>- Last transmission PU poll</li> <li>- Last retransmission PU poll</li> <li>- Poll_Windows</li> <li>- CHOICE Downlink RLC mode</li> <li>- In-sequence delivery</li> <li>- Receiving window size</li> <li>- Downlink RLC status info</li> <li>- Timer_status_prohibit</li> <li>- Timer_EPC</li> <li>- Missing PU indicator</li> <li>- RB mapping info</li> <li>- Information for each multiplexing option</li> <li>- Number of RLC logical channels</li> <li>- Uplink transport channel type</li> <li>- Logical channel identity</li> <li>- MAC logical channel priority</li> <li>- Logical channel max loss</li> <li>- Number of RLC logical channels</li> <li>- Downlink transport channel type</li> <li>- Logical channel identity</li> </ul>	1 RACH 6 6 0 1 FACH 1 (TM CCCH uplink for RRC) 0 Not Present  TM RLC Not Present
RB information to reconfigure <ul style="list-style-type: none"> <li>- RB identity</li> <li>- PDCP info</li> <li>- RLC info</li> <li>- CHOICE Uplink RLC mode</li> <li>- Transmission RLC Discard</li> </ul>	   TM RLC Not Present

- CHOICE Downlink RLC mode	Not Present
Segmentation Indication	
- RB mapping info	1
- Information for each multiplexing option	RACH
- Number of RLC logical channels	5
- Uplink transport channel type	1
- Logical channel identity	0
- MAC logical channel priority	(UM CCCH for RRC)
- Logical channel max loss	0
RB information to reconfigure	Not Present
- RB identity	Not Present
- PDCP info	UM RLC
- RLC info	
- CHOICE Uplink RLC mode	
- CHOICE Downlink RLC mode	
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	6
RB information to reconfigure	(TM BCCH for RRC)
- RB identity	6
- PDCP info	Not Present
- RLC info	
- CHOICE Uplink RLC mode	Not Present
- CHOICE Downlink RLC mode	TM RLC
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	5
RB information to reconfigure	(TM PCCH for RRC)
- RB identity	7
- PDCP info	Not Present
- RLC info	
- CHOICE Uplink RLC mode	Not Present
- CHOICE Downlink RLC mode	TM RLC
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Downlink transport channel type	PCH
- Logical channel identity	1
RB information to be affected	Not Present
- RB identity	
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	
- Uplink transport channel type	
- Transport channel identity	
- Logical channel identity	
- MAC logical channel priority	
- Logical channel max loss	
- Number of RLC logical channels	
- Downlink transport channel type	
- Transport channel identity	
- Logical channel identity	
UL Transport channel information for all transport channels	
- TFC subset	( This IE is repeated for TFC number.)
- Allowed Transport Format combination	0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.)
- UL DCH TFCS	Not Present
Deleted UL TrCH information	
- Transport channel identity	Not Present
Added or Reconfigured UL TrCH information	
- Transport channel identity	1
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)

<ul style="list-style-type: none"> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> </ul>	<p>Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set</p>
<p>DRAC static information</p> <ul style="list-style-type: none"> <li>- Transmission Time Validity</li> <li>- Time duration before retry</li> <li>- DRAC Class identity</li> </ul>	<p>Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Not Present</p>
<p>DL Transport channel information common for all transport channel</p> <ul style="list-style-type: none"> <li>- SCCPCH TFCS</li> <li>- Normal</li> <li>- TFCI Field 1 information</li> <li>- CHOICE TFCS representation</li> <li>- TFCS addition information</li> <li>- CHOICE CTFC Size</li> <li>- CTFC information</li> <li>- Power offset information</li> <li>- CHOICE DL parameters</li> <li>- DL DCH TFCS</li> </ul>	<p>( This IE is repeated for TFC number.)</p> <p>Addition</p> <p>Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set Not Present Independent Not Present</p>
<p>Deleted DL TrCH information</p> <ul style="list-style-type: none"> <li>- Transport channel identity</li> </ul>	<p>Not Present</p>
<p>Added or Reconfigured DL TrCH information</p> <ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	<p>1</p> <p>Independent</p> <p>( This IE is repeated for TFI number)</p> <p>Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Not Present</p> <p>Not Present</p>
<p>Added or Reconfigured DL TrCH information</p> <ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	<p>2</p> <p>Independent</p> <p>( This IE is repeated for TFI number)</p> <p>Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Not Present</p> <p>Not Present</p>
<p>Added or Reconfigured DL TrCH information</p> <ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> </ul>	<p>3</p> <p>Independent</p> <p>( This IE is repeated for TFI number)</p> <p>Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p>

- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	Not Present
- BLER Quality value	Not Present
- Transparent mode signalling info	Not Present
Added or Reconfigured DL TrCH information	
- Transport channel identity	4
- CHOICE DL parameters	Independent
- TFS	( This IE is repeated for TFI number)
- Dynamic Transport format information	Reference to TS34.108 clause 6.10 Parameter Set
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	Reference to TS34.108 clause 6.10 Parameter Set
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	Not Present
- BLER Quality value	Not Present
- Transparent mode signalling info	Not Present
Frequency info	
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
PRACH info	
- Available Signature	
- Signature	0
- Signature	1
- Signature	2
- Signature	3
- Signature	4
- Signature	5
- Signature	6
- Signature	7
- Available SF	Reference to TS34.108 clause 6.10 Parameter Set
- Scrambling code number	0
- Puncturing Limit	Reference to TS34.108 clause 6.10 Parameter Set
- Available Sub Channel number	
- Sub channel number	0
- Sub channel number	1
- Sub channel number	2
- Sub channel number	3
- Sub channel number	4
- Sub channel number	5
- Sub channel number	6
- Sub channel number	7
- Sub channel number	8
- Sub channel number	9
- Sub channel number	10
- Sub channel number	11
Downlink information common for all radio links	Not Present
- Downlink DPCH info common for all RL	
- Downlink DPCH power control information	
- DPC mode	
- Spreading factor	
- Fixed or Flexible Position	
- TFCI existence	
- Number of bits for Pilot bits(SF=128,256)	
- Downlink DPCH Offset Value	
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	Inactive
- Transmission gap pattern sequence configuration parameters	
- TGMP	FDD Measurement

- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	150
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	Not Present
- Primary CPICH usage for channel estimation	
- DPCH frame offset	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	
- Spreading factor	
- Code number	
- Scrambling Code change	
- TPC combination index	
- SSDT Cell Identity	
- Closed loop timing adjustment mode	
- Secondary CCPCH info	
- Selection Indicator	Not Present
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- Secondary scrambling code	
- SSDT Indicator	1
- Spreading factor	FALSE
- Code number	Reference to TS34.108 clause 6.10 Parameter Set SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Pilot symbol existence	FALSE
- TFCI existence	TRUE
- Fixed or Flexible Position	Flexible
- Timing offset	0
- TFCS	Not Present
- FACH/PCH information	Not Present
- TFS	
- Dynamic Transport format information	
- Number of Transport blocks	

<ul style="list-style-type: none"> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- References to system information blocks</li> <li>- Scheduling information</li> </ul>	<p>Not Present</p>
--	--------------------

## Contents of RADIO BEARER RECONFIGURATION COMPLETE message: AM

Message Type	
Integrity check info	Not checked
Uplink integrity protection activation info	Not checked
Other information element	Not checked
Radio bearer uplink ciphering activation time info	Not checked
RB with PDCP information list	Not checked

## Contents of RADIO BEARER RELEASE message: AM or UM ( The others of speech in CS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB information to release	
- RB identity	5
RB information to be affected	(UM DCCH for RRC)
- RB identity	1
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1
RB information to be affected	(AM DCCH for RRC)
- RB identity	2
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
- MAC logical channel priority	2
- Logical channel max loss	0

<ul style="list-style-type: none"> <li>- Number of RLC logical channels</li> <li>- Downlink transport channel type</li> <li>- Transport channel identity</li> <li>- Logical channel identity</li> </ul>	1 DCH 1 2 (AM DCCH for NAS_DT High priority) 3
RB information to be affected <ul style="list-style-type: none"> <li>- RB identity</li> <li>- RB mapping info</li> <li>- Information for each multiplexing option</li> <li>- Number of RLC logical channels</li> <li>- Uplink transport channel type</li> <li>- Transport channel identity</li> <li>- Logical channel identity</li> <li>- MAC logical channel priority</li> <li>- Logical channel max loss</li> <li>- Number of RLC logical channels</li> <li>- Downlink transport channel type</li> <li>- Transport channel identity</li> <li>- Logical channel identity</li> </ul>	1 DCH 1 3 3 0 1 DCH 1 3 (AM DCCH for NAS_DT Low priority) 4
RB information to be affected <ul style="list-style-type: none"> <li>- RB identity</li> <li>- RB mapping info</li> <li>- Information for each multiplexing option</li> <li>- Number of RLC logical channels</li> <li>- Uplink transport channel type</li> <li>- Transport channel identity</li> <li>- Logical channel identity</li> <li>- MAC logical channel priority</li> <li>- Logical channel max loss</li> <li>- Number of RLC logical channels</li> <li>- Downlink transport channel type</li> <li>- Transport channel identity</li> <li>- Logical channel identity</li> </ul>	1 DCH 1 4 4 0 1 DCH 1 4
UL Transport channel information for all transport channels <ul style="list-style-type: none"> <li>- TFC subset</li> <li>- Allowed Transport Format combination</li> </ul>	( This IE is repeated for TFC number.) 0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.) ( This IE is repeated for TFC number.)
<ul style="list-style-type: none"> <li>- UL DCH TFCS</li> <li>- Normal</li> <li>- TFCI Field 1 information</li> <li>- CHOICE CTFC representation</li> <li>- TFCS addition information</li> <li>- CHOICE CTFC Size</li> </ul>	Addition  Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set
<ul style="list-style-type: none"> <li>- CTFC information</li> <li>- Power offset information</li> <li>- CHOICE Gain Factor</li> <li>- Gain factor <math>\beta_c</math></li> <li>- Gain factor <math>\beta_d</math></li> <li>- Reference TFC ID</li> <li>- Power offset Pp-m</li> </ul>	Signalled Gain Factor 0 0 Not Present 0dB
Deleted UL TrCH Information <ul style="list-style-type: none"> <li>- Transport channel identity</li> </ul>	2
Added or Reconfigured UL TrCH information <ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> </ul>	If TrCH reconfiguration is executed then this is needed( e.g The rate of SRB for DCCH is changed.). 1  ( This IE is repeated for TFI number) Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set
CPCH set ID	Not Present
DRAC static information	Not Preaent



<ul style="list-style-type: none"> <li>- Transmission Time Validity</li> <li>- Time duration before retry</li> <li>- DRAC Class Identity</li> </ul>	
DL Transport channel information common for all transport channel	
<ul style="list-style-type: none"> <li>- SCCPCH TFCS</li> <li>- CHOICE DL parameters</li> <li>- DL DCH TFCS</li> <li>- Normal</li> <li>- TFCI Field 1 information</li> <li>- CHOICE CTFC representation</li> <li>- TFCS addition information</li> <li>- CHOICE CTFC Size</li> </ul>	<p>Not Present Independent ( This IE is repeated for TFC number.)</p>
<ul style="list-style-type: none"> <li>- CTFC information</li> <li>- Power offset information</li> </ul>	<p>Addition</p> <p>Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set Not Present</p>
Deleted DL TrCH Information	2
<ul style="list-style-type: none"> <li>- Transport channel identity</li> </ul>	If TrCH reconfiguration is executed then this is needed( e.g The rate of SRB for DCCH is changed.).
Added or Reconfigured DL TrCH information	1
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	<p>Independent</p> <p>( This IE is repeated for TFI number) Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set</p>
Frequency info	0.00
<ul style="list-style-type: none"> <li>- UARFCN uplink(Nu)</li> <li>- UARFCN downlink(Nd)</li> </ul>	Not Present
Maximum allowed UL TX power	Reference to TS34.108 clause 6.10 Parameter Set
Uplink DPCH info	Reference to TS34.108 clause 6.10 Parameter Set 33dBm
<ul style="list-style-type: none"> <li>- Uplink DPCH power control info</li> <li>- DPCCH power offset</li> <li>- PC Preamble</li> <li>- Power Control Algorithm</li> <li>- TPC step size</li> <li>- Scrambling code type</li> <li>- Scrambling code number</li> <li>- Number of DPDCH</li> <li>- spreading factor</li> <li>- TFCI existence</li> <li>- Number of FBI bit</li> <li>- Puncturing Limit</li> </ul>	<p>-6dB 8slot Algorithm1 1dB Long 0 ( 0 to 16777215) Not Present(1) SF is reference to TS34.108 clause 6.10 Parameter Set TRUE Not Present(0) Reference to TS34.108 clause 6.10 Parameter Set</p>
Downlink information common for all radio links	
<ul style="list-style-type: none"> <li>- Downlink DPCH info common for all RL</li> <li>- Downlink DPCH power control information</li> <li>- DPC mode</li> <li>- Spreading factor</li> <li>- Fixed or Flexible Position</li> <li>- TFCI existence</li> <li>- Number of bits for Pilot bits(SF=128,256)</li> <li>- Downlink DPCH Offset Value</li> <li>- DPCH compressed mode info</li> <li>- TGPSI</li> <li>- TGPS Status Flag</li> <li>- Transmission gap pattern sequence configuration parameters</li> <li>- TGMP</li> <li>- TGPRC</li> </ul>	<p>0 (single) Reference to TS34.108 clause 6.10 Parameter Set N/A FALSE Reference to TS34.108 clause 6.10 Parameter Set 0</p> <p>1 inactive</p> <p>FDD Measurement 62</p>

- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- DPCH frame offset	0 chips
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	1
- Spreading factor	Reference to TS34.108 clause 6.10 Parameter Set
- Code number	SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Scrambling code change	No change
- TPC combination index	0
- SSDT Cell Identity	-a
- Closed loop timing adjustment mode	Not Present
- Secondary CCPCH info	Not Present
- Selection Indicator	
- Primary CPICH usage for channel estimation	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- Secondary scrambling code	
- SSDT Indicator	
- Spreading factor	
- Code number	
- Pilot symbol existence	
- TFCI existence	
- Fixed or Flexible Position	
- Timing offset	
- TFCS	Not Present
- FACH/PCH information	Not Present
- TFS	
- Dynamic Transport format information	
- Number of Transport blocks	
- RLC size	

<ul style="list-style-type: none"> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- References to system information blocks</li> <li>- Scheduling information</li> </ul>	<p>Not Present</p>
--	--------------------

Contents of RADIO BEARER RELEASE message: AM or UM ( Speech in CS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB information to release	
- RB identity	5
RB information to release	
- RB identity	6
RB information to release	
- RB identity	7
RB information to be affected	(UM DCCH for RRC)
- RB identity	1
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1
RB information to be affected	(AM DCCH for RRC)
- RB identity	2
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
- MAC logical channel priority	2
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
RB information to be affected	(AM DCCH for NAS_DT High priority)

- RB identity	3
- RB mapping info	
- Information for each multiplexing option	1
- Number of RLC logical channels	DCH
- Uplink transport channel type	1
- Transport channel identity	3
- Logical channel identity	3
- MAC logical channel priority	0
- Logical channel max loss	1
- Number of RLC logical channels	DCH
- Downlink transport channel type	1
- Transport channel identity	3
- Logical channel identity	(AM DCCH for NAS_DT Low priority)
RB information to be affected	4
- RB identity	
- RB mapping info	
- Information for each multiplexing option	1
- Number of RLC logical channels	DCH
- Uplink transport channel type	1
- Transport channel identity	4
- Logical channel identity	4
- MAC logical channel priority	0
- Logical channel max loss	1
- Number of RLC logical channels	DCH
- Downlink transport channel type	1
- Transport channel identity	4
- Logical channel identity	
UL Transport channel information for all transport channels	
- TFC subset	( This IE is repeated for TFC number.)
- Allowed Transport Format combination	0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.)
- UL DCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	Addition
- CHOICE CTFC representation	
- TFCS addition information	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set
- CHOICE CTFC Size	
- CTFC information	Signalled Gain Factor
- Power offset information	0
- CHOICE Gain Factor	0
- Gain factor $\beta_c$	Not Present
- Gain factor $\beta_d$	0dB
- Reference TFC ID	
- Power offset Pp-m	
Deleted UL TrCH Information	2
- Transport channel identity	
Deleted UL TrCH Information	3
- Transport channel identity	
Deleted UL TrCH Information	4
- Transport channel identity	
Added or Reconfigured UL TrCH information	If TrCH reconfiguration is executed then this is needed( e.g The rate of SRB for DCCH is changed.).
- Transport channel identity	1
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
CPCH set ID	Not Present
DRAC static information	Not Preaent
- Transmission Time Validity	

<ul style="list-style-type: none"> <li>- Time duration before retry</li> <li>- DRAC Class Identity</li> </ul>	
DL Transport channel information common for all transport channel	
<ul style="list-style-type: none"> <li>- SCCPCH TFCS</li> <li>- CHOICE DL parameters</li> <li>- DL DCH TFCS</li> <li>- Normal</li> <li>- TFCI Field 1 information</li> <li>- CHOICE CTFC representation</li> <li>- TFCS addition information</li> <li>- CHOICE CTFC Size</li> </ul>	<p>Not Present Independent ( This IE is repeated for TFC number.)</p>
<ul style="list-style-type: none"> <li>- CTFC information</li> <li>- Power offset information</li> </ul>	Addition
Deleted DL TrCH Information	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set
<ul style="list-style-type: none"> <li>- Transport channel identity</li> </ul>	Not Present
Deleted DL TrCH Information	2
<ul style="list-style-type: none"> <li>- Transport channel identity</li> </ul>	3
Deleted DL TrCH Information	4
<ul style="list-style-type: none"> <li>- Transport channel identity</li> </ul>	If TrCH reconfiguration is executed then this is needed( e.g The rate of SRB for DCCH is changed.).
Added or Reconfigured DL TrCH information	1
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- UL TrCH Identity</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- Bit mode RLC size info</li> <li>- Transport block size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	<p>Independent 1</p> <p>( This IE is repeated for TFI number) Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set</p> <p>0.00 Not Present</p>
Frequency info	
<ul style="list-style-type: none"> <li>- UARFCN uplink(Nu)</li> <li>- UARFCN downlink(Nd)</li> </ul>	<p>Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set</p>
Maximum allowed UL TX power	33dBm
Uplink DPCH info	
<ul style="list-style-type: none"> <li>- Uplink DPCH power control info</li> <li>- DPCCH power offset</li> <li>- PC Preamble</li> <li>- Power Control Algorithm</li> <li>- TPC step size</li> <li>- Scrambling code type</li> <li>- Scrambling code number</li> <li>- Number of DPDCH</li> <li>- spreading factor</li> <li>- TFCI existence</li> <li>- Number of FBI bit</li> <li>- Puncturing Limit</li> </ul>	<p>-6dB 8slot Algorithm1 1dB Long 0 ( 0 to 16777215) Not Present(1) SF is reference to TS34.108 clause 6.10 Parameter Set TRUE Not Present(0) Reference to TS34.108 clause 6.10 Parameter Set</p>
Downlink information common for all radio links	
<ul style="list-style-type: none"> <li>- Downlink DPCH info common for all RL</li> <li>- Downlink DPCH power control information</li> <li>- DPC mode</li> <li>- Spreading factor</li> <li>- Fixed or Flexible Position</li> <li>- TFCI existence</li> <li>- Number of bits for Pilot bits(SF=128,256)</li> <li>- Downlink DPCH Offset Value</li> <li>- DPCH compressed mode info</li> <li>- TGPSI</li> </ul>	<p>0 (single) Reference to TS34.108 clause 6.10 Parameter Set N/A FALSE Reference to TS34.108 clause 6.10 Parameter Set 0  1</p>

- TGPS Status Flag	inactive
- Transmission gap pattern sequence configuration parameters	
- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	$(\text{Current CFN} + (256 - \text{TTI}/10\text{msec})) \bmod 256$
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- DPCH frame offset	0 chips
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	1
- Spreading factor	Reference to TS34.108 clause 6.10 Parameter Set
- Code number	SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Scrambling code change	No change
- TPC combination index	0
- SSDT Cell Identity	-a
- Closed loop timing adjustment mode	Not Present
- Secondary CCPCH info	Not Present
- Selection Indicator	
- Primary CPICH usage for channel estimation	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- Secondary scrambling code	
- SSDT Indicator	
- Spreading factor	
- Code number	
- Pilot symbol existence	
- TFCI existence	
- Fixed or Flexible Position	
- Timing offset	
- TFCS	Not Present

<ul style="list-style-type: none"> <li>- FACH/PCH information</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- References to system information blocks</li> <li>- Scheduling information</li> </ul>	<p>Not Present</p> <p>Not Present</p>
---	---------------------------------------



Contents of RADIO BEARER RELEASE message: AM or UM ( Packet to CELL\_DCH from CELL\_DCH in PS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB information to release	5
- RB identity	
RB information to be affected	(UM DCCH for RRC)
- RB identity	1
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1
RB information to be affected	(AM DCCH for RRC)
- RB identity	2
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
- MAC logical channel priority	2
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
RB information to be affected	(AM DCCH for NAS_DT High priority)
- RB identity	3
- RB mapping info	
- Information for each multiplexing option	

- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	3
- MAC logical channel priority	3
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	3
RB information to be affected	(AM DCCH for NAS_DT Low priority)
- RB identity	4
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	4
- MAC logical channel priority	4
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	4
UL Transport channel information for all transport channels	
- TFC subset	( This IE is repeated for TFC number.)
- Allowed Transport Format combination	0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.)
- UL DCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	Addition
- CHOICE CTFC representation	
- TFCS addition information	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10.
- CHOICE CTFC Size	Refer to TS34.108 clause 6.10 Parameter Set
- CTFC information	Not Present
- Power offset information	
Deleted UL TrCH Information	
- Transport channel identity	2
Added or Reconfigured UL TrCH information	If TrCH reconfiguration is executed then this is needed( e.g The rate of SRB for DCCH is changed.).
- Transport channel identity	1
- CHOICE DL parameters	Independent
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
CPCH set ID	Not Present
DRAC static information	Not Preaent
- Transmission Time Validity	
- Time duration before retry	
- DRAC Class Identity	
DL Transport channel information common for all transport channel	
- SCCPCH TFCS	Not Present
- CHOICE DL parameters	
- DL DCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	
- CHOICE CTFC representation	Addition
- TFCS addition information	

- CHOICE CTFC Size	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10.
- CTFC information	Refer to TS34.108 clause 6.10 Parameter Set
- Power offset information	Not Present
Deleted DL TrCH Information	2
- Transport channel identity	If TrCH reconfiguration is executed then this is needed( e.g The rate of SRB for DCCH is changed.).
Added or Reconfigured DL TrCH information	1
- Transport channel identity	Independent
- CHOICE DL parameters	( This IE is repeated for TFI number)
- TFS	Reference to TS34.108 clause 6.10 Parameter Set
- Dynamic Transport format information	Reference to TS34.108 clause 6.10 Parameter Set
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	Reference to TS34.108 clause 6.10 Parameter Set
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	0.00
- BLER Quality value	Not Present
- Transparent mode signalling info	
Frequency info	
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
Uplink DPCH info	
- Uplink DPCH power control info	-6dB
- DPCCH power offset	8slot
- PC Preamble	Algorithm1
- Power Control Algorithm	1dB
- TPC step size	Long
- Scrambling code type	0 ( 0 to 16777215)
- Scrambling code number	Not Present(1)
- Number of DPDCH	SF is reference to TS34.108 clause 6.10 Parameter Set
- spreading factor	TRUE
- TFCI existence	Not Present(0)
- Number of FBI bit	Reference to TS34.108 clause 6.10 Parameter Set
- Puncturing Limit	
Downlink information common for all radio links	
- Downlink DPCH info common for all RL	0 (single)
- Downlink DPCH power control information	Reference to TS34.108 clause 6.10 Parameter Set
- DPC mode	N/A
- Spreading factor	FALSE
- Fixed or Flexible Position	Reference to TS34.108 clause 6.10 Parameter Set
- TFCI existence	0
- Number of bits for Pilot bits(SF=128,256)	
- Downlink DPCH Offset Value	1
- DPCH compressed mode info	inactive
- TGPSI	
- TGPS Status Flag	FDD Measurement
- Transmission gap pattern sequence configuration parameters	62
- TGMP	(Current CFN + (256 – TTI/10msec)) mod 256
- TGPRC	8
- TGCFN	10
- TGSN	5
- TGL1	15
- TGL2	35
- TGD	35
- TGPL1	Mode 1
- TGPL2	Mode 1
- RPP	DL
- ITP	SF/2
- UL/DL Mode	Not Present
- Downlink compressed mode method	
- Uplink compressed mode method	

- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- DPCH frame offset	0 chips
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	
- Spreading factor	1
- Code number	Reference to TS34.108 clause 6.10 Parameter Set SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Scrambling code change	No change
- TPC combination index	0
- SSDT Cell Identity	-a
- Closed loop timing adjustment mode	Not Present
- Secondary CCPCH info	Not Present
- Selection Indicator	
- Primary CPICH usage for channel estimation	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- Secondary scrambling code	
- SSDT Indicator	
- Spreading factor	
- Code number	
- Pilot symbol existence	
- TFCI existence	
- Fixed or Flexible Position	
- Timing offset	
- TFCS	Not Present
- FACH/PCH information	Not Present
- TFS	
- Dynamic Transport format information	
- Number of Transport blocks	
- RLC size	
- Semi-static Transport Format information	
- Transmission time interval	
- Type of channel coding	
- Coding Rate	
- Rate matching attribute	
- CRC size	
- TFS	
- Dynamic Transport format information	
- Number of Transport blocks	
- RLC size	
- Semi-static Transport Format information	
- Transmission time interval	

<ul style="list-style-type: none"> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- References to system information blocks</li> <li>- Scheduling information</li> </ul>	<p>Not Present</p>
---	--------------------

Contents of RADIO BEARER RELEASE message: AM or UM ( Packet to CELL\_DCH from CELL\_FACH in PS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB information to release	
- RB identity	5
RB information to release	
- RB identity	6
RB information to release	
- RB identity	7
RB information to release	
- RB identity	0
RB information to be affected	(UM DCCH for RRC)
- RB identity	1
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1
RB information to be affected	(AM DCCH for RRC)
- RB identity	2
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
- MAC logical channel priority	2
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH

- Transport channel identity	1
- Logical channel identity	2
RB information to be affected	(AM DCCH for NAS_DT High priority)
- RB identity	3
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	3
- MAC logical channel priority	3
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	3
RB information to be affected	(AM DCCH for NAS_DT Low priority)
- RB identity	4
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	4
- MAC logical channel priority	4
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	4
UL Transport channel information for all transport channels	
- TFC subset	( This IE is repeated for TFC number.)
- Allowed Transport Format combination	0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.)
- UL DCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	
- CHOICE CTFC representation	Addition
- TFCS addition information	
- CHOICE CTFC Siz	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set
- CTFC	
- Power offset information	Signalled Gain Factor
- CHOICE Gain Factors	0
- Gain factor $\beta_c$	0
- Gain factor $\beta_d$	Not Present
- Reference TFC ID	0dB
- Power offset Pp-m	Not Present
Deleted UL TrCH Information	
- Transport channel identity	
Added or Reconfigured UL TrCH information	
- Transport channel identity	1
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
CPCH set ID	Not Present
DRAC static information	Not Preaent
- Transmission Time Validity	
- Time duration before retry	

<ul style="list-style-type: none"> <li>- DRAC Class Identity</li> </ul>	
DL Transport channel information common for all transport channel	
<ul style="list-style-type: none"> <li>- SCCPCH TFCS</li> <li>- CHOICE DL parameters</li> <li>- DL DCH TFCS</li> <li>- Normal</li> <li>- TFCI Field 1 information</li> <li>- CHOICE CTFC representation</li> <li>- TFCS addition information</li> </ul>	<p>Not Present Independent ( This IE is repeated for TFC number.)</p>
<ul style="list-style-type: none"> <li>- CHOICE CTFC Size</li> </ul>	Addition
<ul style="list-style-type: none"> <li>- CTFC information</li> <li>- Power offset information</li> </ul>	<p>Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set Not Present</p>
Deleted DL TrCH Information	
<ul style="list-style-type: none"> <li>- Transport channel identity</li> </ul>	2
Deleted DL TrCH Information	
<ul style="list-style-type: none"> <li>- Transport channel identity</li> </ul>	3
Deleted DL TrCH Information	
<ul style="list-style-type: none"> <li>- Transport channel identity</li> </ul>	4
Added or Reconfigured DL TrCH information	
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	<p>1 Independent  ( This IE is repeated for TFI number) Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set  0.00 Not Present</p>
Frequency info	
<ul style="list-style-type: none"> <li>- UARFCN uplink(Nu)</li> <li>- UARFCN downlink(Nd)</li> </ul>	<p>Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set</p>
Maximum allowed UL TX power	33dBm
Uplink DPCH info	
<ul style="list-style-type: none"> <li>- Uplink DPCH power control info</li> <li>- DPCCH power offset</li> <li>- PC Preamble</li> <li>- Power Control Algorithm</li> <li>- TPC step size</li> <li>- Scrambling code type</li> <li>- Scrambling code number</li> <li>- Number of DPDCH</li> <li>- spreading factor</li> <li>- TFCI existence</li> <li>- Number of FBI bit</li> <li>- Puncturing Limit</li> </ul>	<p>-6dB 8slot Algorithm1 1dB Long 0 ( 0 to 16777215) Not Present(1) SF is reference to TS34.108 clause 6.10 Parameter Set TRUE Not Present(0) Reference to TS34.108 clause 6.10 Parameter Set</p>
Downlink information common for all radio links	
<ul style="list-style-type: none"> <li>- Downlink DPCH info common for all RL</li> <li>- Downlink DPCH power control information</li> <li>- DPC mode</li> <li>- Spreading factor</li> <li>- Fixed or Flexible Position</li> <li>- TFCI existence</li> <li>- Number of bits for Pilot bits(SF=128,256)</li> <li>- Downlink DPCH Offset Value</li> <li>- DPCH compressed mode info</li> <li>- TGPSI</li> <li>- TGPS Status Flag</li> <li>- Transmission gap pattern sequence configuration parameters</li> </ul>	<p>0 (single) Reference to TS34.108 clause 6.10 Parameter Set N/A FALSE Reference to TS34.108 clause 6.10 Parameter Set 0  1 inactive</p>



- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- DPCH frame offset	0 chips
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	
- Spreading factor	1
- Code number	Reference to TS34.108 clause 6.10 Parameter Set SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Scrambling code change	No change
- TPC combination index	0
- SSDT Cell Identity	-a
- Closed loop timing adjustment mode	Not Present
- Secondary CCPCH info	Not Present
- Selection Indicator	
- Primary CPICH usage for channel estimation	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- Secondary scrambling code	
- SSDT Indicator	
- Spreading factor	
- Code number	
- Pilot symbol existence	
- TFCI existence	
- Fixed or Flexible Position	
- Timing offset	
- TFCS	Not Present
- FACH/PCH information	Not Present
- TFS	
- Dynamic Transport format information	

<ul style="list-style-type: none"> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- References to system information blocks</li> <li>- Scheduling information</li> </ul>	Not Present
--	-------------

Contents of RADIO BEARER RELEASE message: AM or UM ( Packet to CELL\_FACH from CELL\_DCH in PS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
<ul style="list-style-type: none"> <li>- message authentication code</li> <li>- RRC message sequence number</li> </ul>	
Integrity protection mode info	Not Present
<ul style="list-style-type: none"> <li>- Integrity protection mode command</li> <li>- Downlink integrity protection activation info</li> <li>- RRC message sequence number</li> <li>- RRC message sequence number</li> <li>- Integrity protection algorithm</li> <li>- Integrity protection initialisation number</li> </ul>	
Ciphering mode info	Not Present
<ul style="list-style-type: none"> <li>- Ciphering mode command</li> <li>- Ciphering algorithm</li> <li>- Activation time for DPCH</li> <li>- Radio bearer downlink ciphering activation time info</li> <li>- Radio bearer identity</li> <li>- RLC sequence number</li> </ul>	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
<ul style="list-style-type: none"> <li>- PLMN identity</li> <li>- CN common GSM-MAP NAS system information</li> <li>- CN domain identity</li> <li>- CN domain specific GSM-MAP NAS system information</li> </ul>	
RB information to release	
<ul style="list-style-type: none"> <li>- RB identity</li> </ul>	5
RB information to be affected	(UM DCCH for RRC)
<ul style="list-style-type: none"> <li>- RB identity</li> <li>- RB mapping info</li> <li>- Information for each multiplexing option</li> <li>- Number of RLC logical channels</li> <li>- Uplink transport channel type</li> <li>- Logical channel identity</li> <li>- MAC logical channel priority</li> <li>- Logical channel max loss</li> <li>- Number of RLC logical channels</li> <li>- Downlink transport channel type</li> </ul>	1 1 1 2 0 1 FACH

- Logical channel identity	1
RB information to be affected	(AM DCCH for RRC)
- RB identity	2
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	2
- MAC logical channel priority	3
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	2
RB information to be affected	(AM DCCH for NAS_DT High priority)
- RB identity	3
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	3
- MAC logical channel priority	4
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	3
RB information to be affected	(AM DCCH for NAS_DT Low priority)
- RB identity	4
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	4
- MAC logical channel priority	5
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Transport channel identity	1
- Logical channel identity	4
RB information to be affected	(TM CCCH uplink for RRC)
- RB identity	0
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	5
- MAC logical channel priority	1
- Logical channel max loss	0
RB information to be affected	(UM CCCH downlink for RRC)
- RB identity	0
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	6
RB information to be affected	(TM BCCH for RRC)
- RB identity	6
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	5
RB information to be affected	(TM PCCH for RRC)
- RB identity	7
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Downlink transport channel type	PCH
- Logical channel identity	1

UL Transport channel information for all transport channels	
- TFC subset	( This IE is repeated for TFC number.)
- Allowed Transport Format combination	0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.)
- UL DCH TFCS	Not Present
Deleted UL TrCH Information	
- Transport channel identity	2
Added or Reconfigured UL TrCH information	
- Transport channel identity	1
- TFS	( This IE is repeated for TFI number)
- Dynamic Transport format information	Reference to TS34.108 clause 6.10 Parameter Set
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	Reference to TS34.108 clause 6.10 Parameter Set
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
CPCH set ID	Not Present
DRAC static information	Not Preaent
- Transmission Time Validity	
- Time duration before retry	
- DRAC Class Identity	
DL Transport channel information common for all transport channel	
- SCCPCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	
- CHOICE CTFC representation	Addition
- TFCS addition information	
- CHOICE CTFC Size	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10.
- CTFC information	Refer to TS34.108 clause 6.10 Parameter Set
- Power offset information	Not Present
- CHOICE DL parameters	Independent
- DL DCH TFCS	Not Present
Deleted DL TrCH Information	Not Present
- Transport channel identity	
Added or Reconfigured DL TrCH information	
- Transport channel identity	1
- CHOICE DL parameters	Independent
- TFS	( This IE is repeated for TFI number)
- Dynamic Transport format information	Reference to TS34.108 clause 6.10 Parameter Set
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	Reference to TS34.108 clause 6.10 Parameter Set
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	Not Present
- BLER Quality value	
- Transparent mode signalling info	Not Present
Added or Reconfigured DL TrCH information	
- Transport channel identity	2
- CHOICE DL parameters	Independent
- TFS	( This IE is repeated for TFI number)
- Dynamic Transport format information	Reference to TS34.108 clause 6.10 Parameter Set
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	Reference to TS34.108 clause 6.10 Parameter Set
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set

- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	Not Present
- BLER Quality value	
- Transparent mode signalling info	Not Present
Added or Reconfigured DL TrCH information	
- Transport channel identity	3
- CHOICE DL parameters	Independent
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	Not Present
- BLER Quality value	
- Transparent mode signalling info	Not Present
Frequency info	
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
PRACH info	
- Available Signature	
- Signature	0
- Signature	1
- Signature	2
- Signature	3
- Signature	4
- Signature	5
- Signature	6
- Signature	7
- Available SF	Reference to TS34.108 clause 6.10 Parameter Set
- Scrambling code number	0
- Puncturing Limit	Reference to TS34.108 clause 6.10 Parameter Set
- Available Sub Channel number	
- Sub channel number	0
- Sub channel number	1
- Sub channel number	2
- Sub channel number	3
- Sub channel number	4
- Sub channel number	5
- Sub channel number	6
- Sub channel number	7
- Sub channel number	8
- Sub channel number	9
- Sub channel number	10
- Sub channel number	11
Downlink information common for all radio links	Not Present
- Downlink DPCH info common for all RL	
- Downlink DPCH power control information	
- DPC mode	
- Spreading factor	
- Fixed or Flexible Position	
- TFCI existence	
- Number of bits for Pilot bits(SF=128,256)	
- Downlink DPCH Offset Value	
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	inactive
- Transmission gap pattern sequence configuration parameters	
- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256

- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	Not Present
- Primary CPICH usage for channel estimation	
- DPCH frame offset	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	
- Spreading factor	
- Code number	
- Scrambling code change	
- TPC combination index	
- SSDT Cell Identity	
- Closed loop timing adjustment mode	
- Secondary CCPCH info	
- Selection Indicator	Not Present
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- Secondary scrambling code	
- SSDT Indicator	1
- Spreading factor	FALSE
- Code number	Reference to TS34.108 clause 6.10 Parameter Set SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Pilot symbol existence	FALSE
- TFCI existence	TRUE
- Fixed or Flexible Position	Flexible
- Timing offset	0
- TFCS	Not Present
- FACH/PCH information	Not Present
- TFS	
- Dynamic Transport format information	
- Number of Transport blocks	
- RLC size	
- Semi-static Transport Format information	

<ul style="list-style-type: none"> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- References to system information blocks</li> <li>- Scheduling information</li> </ul>	<p>Not Present</p>
--	--------------------

Contents of RADIO BEARER RELEASE message: AM or UM ( Packet to CELL\_FACH from CELL\_FACH in PS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB information to release	
- RB identity	5
RB information to be affected	(UM DCCH for RRC)
- RB identity	1
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	1
- MAC logical channel priority	2
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	1
RB information to be affected	(AM DCCH for RRC)
- RB identity	2
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Transport channel identity	1
- Logical channel identity	2
- MAC logical channel priority	3
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	2
RB information to be affected	(AM DCCH for NAS_DT High priority)
- RB identity	3
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	3



- MAC logical channel priority	4
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	3
RB information to be affected	(AM DCCH for NAS_DT Low priority)
- RB identity	4
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	4
- MAC logical channel priority	5
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	4
RB information to be affected	(TM CCCH uplink for RRC)
- RB identity	0
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	5
- MAC logical channel priority	1
- Logical channel max loss	0
RB information to be affected	(UM CCCH downlink for RRC)
- RB identity	0
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	6
RB information to be affected	(TM BCCH for RRC)
- RB identity	6
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	5
RB information to be affected	(TM PCCH for RRC)
- RB identity	7
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Downlink transport channel type	PCH
- Logical channel identity	1
UL Transport channel information for all transport channels	
- TFC subset	( This IE is repeated for TFC number.)
- Allowed Transport Format combination	0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.)
- UL DCH TFCS	Not Present
Deleted UL TrCH Information	Not Present
- Transport channel identity	
Added or Reconfigured UL TrCH information	
- Transport channel identity	1
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
CPCH set ID	Not Present

DRAC static information	Not Present
- Transmission Time Validity	
- Time duration before retry	
- DRAC Class Identity	
DL Transport channel information common for all transport channel	
- SCCPCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	
- CHOICE CTFC representation	Addition
- TFCS addition information	
- CHOICE CTFC Size	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10.
- CTFC information	Refer to TS34.108 clause 6.10 Parameter Set
- Power offset information	Not Present
- CHOICE DL parameters	Independent
- DL DCH TFCS	Not Present
Deleted DL TrCH Information	4
- Transport channel identity	Not Present
Added or Reconfigured DL TrCH information	
- Transport channel identity	
- CHOICE DL parameters	
- TFS	
- Dynamic Transport format information	
- Number of Transport blocks	
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	
- Type of channel coding	
- Coding Rate	
- Rate matching attribute	
- CRC size	
- DCH quality target	
- BLER Quality value	
- Transparent mode signalling info	
Frequency info	
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
PRACH info	
- Available Signature	
- Signature	0
- Signature	1
- Signature	2
- Signature	3
- Signature	4
- Signature	5
- Signature	6
- Signature	7
- Available SF	Reference to TS34.108 clause 6.10 Parameter Set
- Scrambling code number	0
- Puncturing Limit	Reference to TS34.108 clause 6.10 Parameter Set
- Available Sub Channel number	
- Sub channel number	0
- Sub channel number	1
- Sub channel number	2
- Sub channel number	3
- Sub channel number	4
- Sub channel number	5
- Sub channel number	6
- Sub channel number	7
- Sub channel number	8
- Sub channel number	9
- Sub channel number	10
- Sub channel number	11
Downlink information common for all radio links	Not Present
- Downlink DPCH info common for all RL	

- Downlink DPCH power control information	
- DPC mode	
- Spreading factor	
- Fixed or Flexible Position	
- TFCI existence	
- Number of bits for Pilot bits(SF=128,256)	
- Downlink DPCH Offset Value	
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	inactive
- Transmission gap pattern sequence configuration parameters	
- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTl/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	Not Present
- Primary CPICH usage for channel estimation	
- DPCH frame offset	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	
- Code number	
- TPC combination index	
- SSDT Cell Identity	
- Closed loop timing adjustment mode	
- Secondary CCPCH info	
- Selection Indicator	Not Present
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- Secondary scrambling code	
- SSDT Indicator	1
- Spreading factor	FALSE
	Reference to TS34.108 clause 6.10 Parameter Set



- RLC info	UM RLC
- CHOICE Uplink RLC mode	
- Transmission RLC discard	Max DAT retransmissions
- SDU discard mode	4
- MAX_DAT	100
- Timer_MRW	4
- MaxMRW	UM RLC
- CHOICE Downlink RLC mode	
- RB mapping info	
- Information for each multiplexing option	1
- Number of RLC logical channels	DCH
- Uplink transport channel type	1
- Transport channel identity	1
- Logical channel identity	1
- MAC logical channel priority	0
- Logical channel max loss	1
- Number of RLC logical channels	DCH
- Downlink transport channel type	1
- Transport channel identity	1
- Logical channel identity	(AM DCCH for RRC)
Signalling RB information to setup	2
- RB identity	
- CHOICE RLC info type	
- RLC info	AM RLC
- CHOICE Uplink RLC mode	
- Transmission RLC discard	Max DAT retransmissions
- SDU discard mode	4
- MAX_DAT	100
- Timer_MRW	4
- MaxMRW	8
- Transmission window size	8
- Receiving window size	500
- Timer_RST	4
- Max_RST	
- Polling info	200
- Timer_poll_prohibit	200
- Timer_poll	1
- Poll_SDU	TRUE
- Last transmission PU poll	TRUE
- Last retransmission PU poll	99
- Poll_Windows	AM RLC
- CHOICE Downlink RLC mode	TRUE
- In-sequence delivery	8
- Receiving window size	
- Downlink RLC status info	200
- Timer_status_prohibit	200
- Timer_EPC	TRUE
- Missing PU indicator	
- RB mapping info	
- Information for each multiplexing option	1
- Number of RLC logical channels	DCH
- Uplink transport channel type	1
- Transport channel identity	2
- Logical channel identity	2
- MAC logical channel priority	0
- Logical channel max loss	1
- Number of RLC logical channels	DCH
- Downlink transport channel type	1
- Transport channel identity	2
- Logical channel identity	(AM DCCH for NAS_DT High priority)
Signalling RB information to setup	3
- RB identity	
- CHOICE RLC info type	
- RLC info	AM RLC
- CHOICE Uplink RLC mode	
- Transmission RLC discard	Max DAT retransmissions
- SDU discard mode	4
- MAX_DAT	

- Timer_MRW	100
- MaxMRW	4
- Transmission window size	8
- Receiving window size	8
- Timer_RST	500
- Max_RST	4
- Polling info	
- Timer_poll_prohibit	200
- Timer_poll	200
- Poll_SDU	1
- Last transmission PU poll	TRUE
- Last retransmission PU poll	TRUE
- Poll_Windows	99
- CHOICE Downlink RLC mode	AM RLC
- In-sequence delivery	TRUE
- Receiving window size	8
- Downlink RLC status info	
- Timer_status_prohibit	200
- Timer_EPC	200
- Missing PU indicator	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	3
- MAC logical channel priority	3
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	3
Signalling RB information to setup	(AM DCCH for NAS_DT Low priority)
- RB identity	4
- CHOICE RLC info type	
- RLC info	
- CHOICE Uplink RLC mode	AM RLC
- Transmission RLC discard	
- SDU discard mode	Max DAT retransmissions
- MAX_DAT	4
- Timer_MRW	100
- MaxMRW	4
- Transmission window size	8
- Receiving window size	8
- Timer_RST	500
- Max_RST	4
- Polling info	
- Timer_poll_prohibit	200
- Timer_poll	200
- Poll_SDU	1
- Last transmission PU poll	TRUE
- Last retransmission PU poll	TRUE
- Poll_Windows	99
- CHOICE Downlink RLC mode	AM RLC
- In-sequence delivery	TRUE
- Receiving window size	8
- Downlink RLC status info	
- Timer_status_prohibit	200
- Timer_EPC	200
- Missing PU indicator	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	4
- MAC logical channel priority	4
- Logical channel max loss	0

- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	4
RAB information for setup	
- RAB info	
- RAB identity	0000 0001B
- CN domain identity	CS domain
- Re-establishment timer	
- T314	20 seconds
- RB information to setup	
- RB identity	5
- PDCP info	Not Present
- RLC info	
- CHOICE Uplink RLC mode	TM RLC
- Transmission RLC Discard	Not Present
- CHOICE Downlink RLC mode	TM RLC
- Segmentation Indication	
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	2
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	2
- Logical channel identity	1
RB information to release	Not Present
RB information to reconfigure	Not Present
RB information to be affected	Not Present
- RB identity	
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	
- Uplink transport channel type	
- Transport channel identity	
- Logical channel identity	
- MAC logical channel priority	
- Logical channel max loss	
- Number of RLC logical channels	
- Downlink transport channel type	
- Transport channel identity	
- Logical channel identity	
UL Transport channel information for all transport channels	
- TFC subset	( This IE is repeated for TFC number.)
- Allowed Transport Format combination	0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.)
- UL DCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	
- CHOICE CTFC representation	Addition
- TFCS addition information	
- CHOICE CTFC Size	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set
- CTFC information	
- Power offset information	
- CHOICE Gain Factors	Signalled Gain Factor
- Gain factor $\beta_c$	0
- Gain factor $\beta_d$	0
- Reference TFC ID	Not Present
- Power offset Pp-m	0dB
Deleted UL TrCH information	Not Present
Added or Reconfigured UL TrCH information	

<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> </ul>	<p>1</p> <p>( This IE is repeated for TFI number)</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p>
<p>Added or Reconfigured UL TrCH information</p> <ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> </ul>	<p>2</p> <p>( This IE is repeated for TFI number)</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p>
<p>DRAC static information</p> <ul style="list-style-type: none"> <li>- Transmission Time Validity</li> <li>- Time duration before retry</li> <li>- DRAC Class identity</li> </ul>	<p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Not Present</p>
<p>DL Transport channel information common for all transport channel</p> <ul style="list-style-type: none"> <li>- SCCPCH TFCS</li> <li>- CHOICE DL parameters</li> <li>- DL DCH TFCS</li> <li>- Normal</li> <li>- TFCI Field 1 information</li> <li>- CHOICE CTFC representation</li> <li>- TFCS addition information</li> </ul>	<p>Not Present</p> <p>Independent</p> <p>( This IE is repeated for TFC number.)</p>
<ul style="list-style-type: none"> <li>- CHOICE CTFC Size</li> <li>- CTFC information</li> <li>- Power offset information</li> </ul>	<p>Addition</p> <p>Number of bits used must be enough to cover all combinations of CTFC from clause 6.10.</p> <p>Refer to TS34.108 clause 6.10 Parameter Set</p> <p>Not Present</p> <p>Not Present</p>
<p>Deleted DL TrCH information</p>	
<p>Added or Reconfigured DL TrCH information</p> <ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	<p>1</p> <p>Independent</p> <p>( This IE is repeated for TFI number)</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p>
	<p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p>
<p>Added or Reconfigured DL TrCH information</p> <ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> </ul>	<p>0.00</p> <p>Not Present</p> <p>2</p> <p>Independent</p> <p>( This IE is repeated for TFI number)</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p>
	<p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p>



- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	0.00
- BLER Quality value	Not Present
- Transparent mode signalling info	
Frequency info	
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
Uplink DPCH info	
- Uplink DPCH power control info	
- DPCCH power offset	-6dB
- PC Preamble	8slot
- Power Control Algorithm	Algorithm1
- TPC step size	1dB
- Scrambling code type	Long
- Scrambling code number	0 ( 0 to 16777215)
- Number of DPDCH	Not Present(1)
- spreading factor	SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- TFCI existence	TRUE
- Number of FBI bit	Not Present(0)
- Puncturing Limit	Reference to TS34.108 clause 6.10 Parameter Set
Downlink information common for all radio links	
- Downlink DPCH info common for all RL	
- Downlink DPCH power control information	
- DPC mode	0 (single)
- Spreading factor	Reference to TS34.108 clause 6.10 Parameter Set
- Fixed or Flexible Position	Flexible
- TFCI existence	TRUE
- Number of bits for Pilot bits(SF=128,256)	Not Present
- Downlink DPCH Offset Value	0
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	inactive
- Transmission gap pattern sequence configuration parameters	
- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present

Contents of RNTI REALLOCATION message: AM or UM

Information Element	Value/remark
Message Type	

Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
New U-RNTI	See the test content
- SRNC identity	
- S-RNTI	
New C-RNTI	See the test content
DRX indicator	NoDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB with PDCP information	Not Present
- RB identity	
- PDCP SN info	

## Contents of RNTI REALLOCATION COMPLETE message: AM

Information Element	Value/remark
Message Type	
Integrity check info	Not checked
Uplink integrity protection activation info	Not checked
Radio bearer uplink ciphering activation time info	Not checked
RB with PDCP information	Not checked

## Contents of RRC CONNECTION RE-ESTABLISHMENT message: UM ( Speech in CS )

Information Element	Value/remark
Message Type	
U-RNTI	Not Present
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	
- Ciphering mode command	start
- Ciphering algorithm	Standard UMTS Encryption Algorithm UEA1
- Activation time for DPCH	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	0
- RLC sequence number	Current RLC SN + 2
- Radio bearer identity	1
- RLC sequence number	Current RLC SN+2
- Radio bearer identity	2
- RLC sequence number	Current RLC SN+2
- Radio bearer identity	3
- RLC sequence number	Current RLC SN+2
- Radio bearer identity	4
- RLC sequence number	Current RLC SN+2
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
RLC reset indicator (for C-plane)	FALSE
RLC reset indicator (for U-plane)	FALSE
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
Signalling RB information to setup	(UM DCCH for RRC)
- RB identity	1
- CHOICE RLC info type	
- RLC info	
- CHOICE Uplink RLC mode	UM RLC
- Transmission RLC discard	
- SDU discard mode	Max DAT retransmissions
- MAX_DAT	4
- Timer_MRW	100
- MaxMRW	4
- CHOICE Downlink RLC mode	UM RLC
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1
Signalling RB information to setup	(AM DCCH for RRC)

- RB identity	2
- CHOICE RLC info type	
- RLC info	AM RLC
- CHOICE Uplink RLC mode	
- Transmission RLC discard	Max DAT retransmissions
- SDU discard mode	4
- MAX_DAT	100
- Timer_MRW	4
- MaxMRW	8
- Transmission window size	8
- Receiving window size	500
- Timer_RST	4
- Max_RST	
- Polling info	200
- Timer_poll_prohibit	200
- Timer_poll	1
- Poll_SDU	TRUE
- Last transmission PU poll	TRUE
- Last retransmission PU poll	99
- Poll_Windows	AM RLC
- CHOICE Downlink RLC mode	TRUE
- In-sequence delivery	8
- Receiving window size	
- Downlink RLC status info	200
- Timer_status_prohibit	200
- Timer_EPC	TRUE
- Missing PU indicator	
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
- MAC logical channel priority	2
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
Signalling RB information to setup	(AM DCCH for NAS_DT High priority)
- RB identity	3
- CHOICE RLC info type	
- RLC info	AM RLC
- CHOICE Uplink RLC mode	
- Transmission RLC discard	Max DAT retransmissions
- SDU discard mode	4
- MAX_DAT	100
- Timer_MRW	4
- MaxMRW	8
- Transmission window size	8
- Receiving window size	500
- Timer_RST	4
- Max_RST	
- Polling info	200
- Timer_poll_prohibit	200
- Timer_poll	1
- Poll_SDU	TRUE
- Last transmission PU poll	TRUE
- Last retransmission PU poll	99
- Poll_Windows	AM RLC
- CHOICE Downlink RLC mode	TRUE
- In-sequence delivery	8
- Receiving window size	
- Downlink RLC status info	200
- Timer_status_prohibit	200
- Timer_EPC	TRUE
- Missing PU indicator	
- RB mapping info	

- Information for each multiplexing option	1
- Number of RLC logical channels	DCH
- Uplink transport channel type	1
- Transport channel identity	3
- Logical channel identity	3
- MAC logical channel priority	0
- Logical channel max loss	1
- Number of RLC logical channels	DCH
- Downlink transport channel type	1
- Transport channel identity	3
- Logical channel identity	(AM DCCH for NAS_DT Low priority)
Signalling RB information to setup	4
- RB identity	
- CHOICE RLC info type	
- RLC info	AM RLC
- CHOICE Uplink RLC mode	
- Transmission RLC discard	Max DAT retransmissions
- SDU discard mode	4
- MAX_DAT	100
- Timer_MRW	4
- MaxMRW	8
- Transmission window size	8
- Receiving window size	500
- Timer_RST	4
- Max_RST	
- Polling info	
- Timer_poll_prohibit	200
- Timer_poll	200
- Poll_SDU	1
- Last transmission PU poll	TRUE
- Last retransmission PU poll	TRUE
- Poll_Windows	99
- CHOICE Downlink RLC mode	AM RLC
- In-sequence delivery	TRUE
- Receiving window size	8
- Downlink RLC status info	
- Timer_status_prohibit	200
- Timer_EPC	200
- Missing PU indicator	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	4
- MAC logical channel priority	4
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	4
RAB information for setup	
- RAB info	
- RAB identity	0000 0001B
- CN domain identity	CS domain
- Re-establishment timer	
- T314	20 seconds
- RB information to setup	
- RB identity	5
- PDCP info	Not Present
- RLC info	
- CHOICE Uplink RLC mode	TM RLC
- Transmission RLC Discard	Not Present
- CHOICE Downlink RLC mode	TM RLC
Segmentation Indication	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1

- Uplink transport channel type	DCH
- Transport channel identity	2
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	2
- Logical channel identity	1
- RB information to setup	
- RB identity	6
- PDCP info	Not Present
- RLC info	Not Present
- CHOICE Uplink RLC mode	TM RLC
- Transmission RLC Discard	Not Present
- CHOICE Downlink RLC mode	TM RLC
Segmentation indication	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	3
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	3
- Logical channel identity	1
- RB information to setup	( This IE is needed for 12.2 kbps and 10.2 kbps)
- RB identity	7
- PDCP info	Not Present
- RLC info	
- CHOICE Uplink RLC mode	TM RLC
- Transmission RLC Discard	Not Present
- CHOICE Downlink RLC mode	TM RLC
Segmentation Indication	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	4
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	4
- Logical channel identity	1
RB information to release	Not Present
RB information to reconfigure	Not Present
RB information to be affected	Not Present
- RB identity	
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	
- Uplink transport channel type	
- Transport channel identity	
- Logical channel identity	
- MAC logical channel priority	
- Logical channel max loss	
- Number of RLC logical channels	
- Downlink transport channel type	
- Transport channel identity	
- Logical channel identity	
UL Transport channel information for all transport channels	
- TFC subset	( This IE is repeated for TFC number.)

<ul style="list-style-type: none"> <li>- Allowed Transport Format combination</li> <li>- UL DCH TFCS <ul style="list-style-type: none"> <li>- Normal</li> <li>- TFCI Field 1 information</li> <li>- CHOICE CTFC representation</li> <li>- TFCS addition information</li> </ul> </li> <li>- CHOICE CTFC Size <ul style="list-style-type: none"> <li>- CTFC information</li> <li>- Power offset information</li> <li>- CHOICE Gain Factors <ul style="list-style-type: none"> <li>- Gain factor <math>\beta_c</math></li> <li>- Gain factor <math>\beta_d</math></li> </ul> </li> <li>- Reference TFC ID</li> <li>- Power offset Pp-m</li> </ul> </li> </ul> <p>Deleted UL TrCH information  Added or Reconfigured UL TrCH information</p> <ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> </ul> <p>Added or Reconfigured UL TrCH information</p> <ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> </ul> <p>Added or Reconfigured UL TrCH information</p> <ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> </ul> <p>Added or Reconfigured UL TrCH information</p> <ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> </ul> <p>DRAC static information</p> <ul style="list-style-type: none"> <li>- Transmission Time Validity</li> </ul>	<p>0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.)  (This IE is repeated for TFC number.)</p> <p>Addition</p> <p>Number of bits used must be enough to cover all combinations of CTFC from clause 6.10.  Refer to TS34.108 clause 6.10 Parameter Set</p> <p>Signalled Gain Factor</p> <p>0  0  Not Present  0dB  Not Present</p> <p>1</p> <p>( This IE is repeated for TFI number)  Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set</p> <p>2</p> <p>( This IE is repeated for TFI number)  Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set</p> <p>3</p> <p>( This IE is repeated for TFI number)  Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set  (This IE is needed for 12.2 kbps and 10.2 kbps)</p> <p>4</p> <p>( This IE is repeated for TFI number)</p> <p>Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set  Not Present</p>
---	--

<ul style="list-style-type: none"> <li>- Time duration before retry</li> <li>- DRAC Class identity</li> </ul>	
DL Transport channel information common for all transport channel	
<ul style="list-style-type: none"> <li>- SCCPCH TFCS</li> <li>- CHOICE DL parameters</li> <li>- DL DCH TFCS</li> <li>- Normal</li> <li>- TFCI Field 1 information</li> <li>- CHOICE CTFC representation</li> <li>- TFCS addition information</li> </ul>	<p>Not Present Independent ( This IE is repeated for TFC number.)</p> <p>Addition</p>
<ul style="list-style-type: none"> <li>- CHOICE CTFC Size</li> </ul>	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10.
<ul style="list-style-type: none"> <li>- CTFC information</li> <li>- Power offset information</li> </ul>	Refer to TS34.108 clause 6.10 Parameter Set
Deleted DL TrCH information	Not Present
Added or Reconfigured DL TrCH information	Not Present
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- UL TrCH Identity</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	1
Added or Reconfigured DL TrCH information	SameAsUL
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- UL TrCH Identity</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	1
Added or Reconfigured DL TrCH information	0.00
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- UL TrCH Identity</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	Not Present
Added or Reconfigured DL TrCH information	2
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- UL TrCH Identity</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	SameAsUL
Added or Reconfigured DL TrCH information	2
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- UL TrCH Identity</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	0.00
Added or Reconfigured DL TrCH information	Not Present
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- UL TrCH Identity</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	3
Added or Reconfigured DL TrCH information	SameAsUL
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- UL TrCH Identity</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	3
Added or Reconfigured DL TrCH information	0.00
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- UL TrCH Identity</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	Not Present
Added or Reconfigured DL TrCH information	( This IE is needed for 12.2 kbps and 10.2 kbps)
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- UL TrCH Identity</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	4
Added or Reconfigured DL TrCH information	SameAsUL
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- UL TrCH Identity</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	4
Added or Reconfigured DL TrCH information	0.00
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- UL TrCH Identity</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	Not Present
Frequency info	
<ul style="list-style-type: none"> <li>- UARFCN uplink(Nu)</li> <li>- UARFCN downlink(Nd)</li> </ul>	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	Reference to TS34.108 clause 6.10 Parameter Set
Uplink DPCH info	33dBm
<ul style="list-style-type: none"> <li>- Uplink DPCH power control info</li> <li>- DPCCH power offset</li> <li>- PC Preamble</li> <li>- Power Control Algorithm</li> <li>- TPC step size</li> <li>- Scrambling code type</li> <li>- Scrambling code number</li> <li>- Number of DPDCH</li> <li>- spreading factor</li> <li>- TFCI existence</li> <li>- Number of FBI bit</li> <li>- Puncturing Limit</li> </ul>	
Downlink information common for all radio links	
<ul style="list-style-type: none"> <li>- Downlink DPCH info common for all RL</li> <li>- Downlink DPCH power control information</li> <li>- DPC mode</li> <li>- Spreading factor</li> <li>- Fixed or Flexible Position</li> </ul>	<p>-6dB</p> <p>8slot</p> <p>Algorithm1</p> <p>1dB</p> <p>Long</p> <p>0 ( 0 to 16777215)</p> <p>Not Present(1)</p> <p>SF is reference to TS34.108 clause 6.10 Parameter Set</p> <p>TRUE</p> <p>Not Present(0)</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p>
Downlink information common for all radio links	0 (single)
<ul style="list-style-type: none"> <li>- Downlink DPCH info common for all RL</li> <li>- Downlink DPCH power control information</li> <li>- DPC mode</li> <li>- Spreading factor</li> <li>- Fixed or Flexible Position</li> </ul>	Reference to TS34.108 clause 6.10 Parameter Set
Downlink information common for all radio links	Fixed



- TFCI existence	FALSE
- Number of bits for Pilot bits(SF=128,256)	4 bits
- Downlink DPCH Offset Value	0
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	inactive
- Transmission gap pattern sequence configuration parameters	
- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- DPCH frame offset	0 chips
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	1
- Spreading factor	Reference to TS34.108 clause 6.10 Parameter Set
- Code number	SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Scrambling code change	No change
- TPC combination index	0
- SSDT Cell Identity	-a
- Closed loop timing adjustment mode	Not Present
- Secondary CCPCH info	Not Present
- Selection Indicator	
- Primary CPICH usage for channel estimation	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- Secondary scrambling code	
- SSDT Indicator	
- Spreading factor	
- Code number	

<ul style="list-style-type: none"><li>- Pilot symbol existence</li><li>- TFCI existence</li><li>- Fixed or Flexible Position</li><li>- Timing offset</li><li>- TFCS</li><li>- FACH/PCH information</li><li>- TFS</li><li>- Dynamic Transport format information</li><li>- Number of Transport blocks</li><li>- RLC size</li><li>- Semi-static Transport Format information</li><li>- Transmission time interval</li><li>- Type of channel coding</li><li>- Coding Rate</li><li>- Rate matching attribute</li><li>- CRC size</li><li>- TFS</li><li>- Dynamic Transport format information</li><li>- Number of Transport blocks</li><li>- RLC size</li><li>- Semi-static Transport Format information</li><li>- Transmission time interval</li><li>- Type of channel coding</li><li>- Coding Rate</li><li>- Rate matching attribute</li><li>- CRC size</li><li>- References to system information blocks</li><li>- Scheduling information</li></ul>	<p>Not Present</p> <p>Not Present</p> <p>Not Present</p>
---	--

Contents of RRC CONNECTION RE-ESTABLISHMENT message: UM ( Packet to CELL\_DCH from CELL\_DCH in PS )

Information Element	Value/remark
Message Type	
U-RNTI	Not Present
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	
- Ciphering mode command	start
- Ciphering algorithm	Standard UMTS Encryption Algorithm UEA1
- Activation time for DPCH	Not Present
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	0
- RLC sequence number	Current RLC SN + 2
- Radio bearer identity	1
- RLC sequence number	Current RLC SN+2
- Radio bearer identity	2
- RLC sequence number	Current RLC SN+2
- Radio bearer identity	3
- RLC sequence number	Current RLC SN+2
- Radio bearer identity	4
- RLC sequence number	Current RLC SN+2
Activation time	$(256 + CFN - (CFN \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
RLC reset indicator (for C-plane)	FALSE
RLC reset indicator (for U-plane)	FALSE
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
Signalling RB information to setup	(UM DCCH for RRC)
- RB identity	1
- CHOICE RLC info type	
- RLC info	
- CHOICE Uplink RLC mode	UM RLC
- Transmission RLC discard	
- SDU discard mode	Max DAT retransmissions
- MAX_DAT	4
- Timer_MRW	100
- MaxMRW	4
- CHOICE Downlink RLC mode	UM RLC
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1

Signalling RB information to setup	(AM DCCH for RRC)
- RB identity	2
- CHOICE RLC info type	
- RLC info	AM RLC
- CHOICE Uplink RLC mode	
- Transmission RLC discard	Max DAT retransmissions
- SDU discard mode	4
- MAX_DAT	100
- Timer_MRW	4
- MaxMRW	8
- Transmission window size	8
- Receiving window size	8
- Timer_RST	500
- Max_RST	4
- Polling info	
- Timer_poll_prohibit	200
- Timer_poll	200
- Poll_SDU	1
- Last transmission PU poll	TRUE
- Last retransmission PU poll	TRUE
- Poll_Windows	99
- CHOICE Downlink RLC mode	AM RLC
- In-sequence delivery	TRUE
- Receiving window size	8
- Downlink RLC status info	
- Timer_status_prohibit	200
- Timer_EPC	200
- Missing PU indicator	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
- MAC logical channel priority	2
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
Signalling RB information to setup	(AM DCCH for NAS_DT High priority)
- RB identity	3
- CHOICE RLC info type	
- RLC info	AM RLC
- CHOICE Uplink RLC mode	
- Transmission RLC discard	Max DAT retransmissions
- SDU discard mode	4
- MAX_DAT	100
- Timer_MRW	4
- MaxMRW	8
- Transmission window size	8
- Receiving window size	8
- Timer_RST	500
- Max_RST	4
- Polling info	
- Timer_poll_prohibit	200
- Timer_poll	200
- Poll_SDU	1
- Last transmission PU poll	TRUE
- Last retransmission PU poll	TRUE
- Poll_Windows	99
- CHOICE Downlink RLC mode	AM RLC
- In-sequence delivery	TRUE
- Receiving window size	8
- Downlink RLC status info	
- Timer_status_prohibit	200
- Timer_EPC	200
- Missing PU indicator	TRUE

- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	3
- MAC logical channel priority	3
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	3
Signalling RB information to setup	(AM DCCH for NAS_DT Low priority)
- RB identity	4
- CHOICE RLC info type	
- RLC info	
- CHOICE Uplink RLC mode	AM RLC
- Transmission RLC discard	
- SDU discard mode	Max DAT retransmissions
- MAX_DAT	4
- Timer_MRW	100
- MaxMRW	4
- Transmission window size	8
- Receiving window size	8
- Timer_RST	500
- Max_RST	4
- Polling info	
- Timer_poll_prohibit	200
- Timer_poll	200
- Poll_SDU	1
- Last transmission PU poll	TRUE
- Last retransmission PU poll	TRUE
- Poll_Windows	99
- CHOICE Downlink RLC mode	AM RLC
- In-sequence delivery	TRUE
- Receiving window size	8
- Downlink RLC status info	
- Timer_status_prohibit	200
- Timer_EPC	200
- Missing PU indicator	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	4
- MAC logical channel priority	4
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	4
RAB information for setup	
- RAB info	
- RAB identity	0000 0001B
- CN domain identity	PS domain
- Re-establishment timer	
- T314	20 seconds
- RB information to setup	
- RB identity	5
- PDCP info	Not Present
- RLC info	
- CHOICE Uplink RLC mode	AM RLC
- Transmission RLC discard	
- SDU discard mode	Max DAT retransmissions
- MAX_DAT	4
- Timer_MRW	100
- MaxMRW	4

- Transmission window size	8
- Receiving window size	8
- Timer_RST	500
- Max_RST	4
- Polling info	
- Timer_poll_prohibit	200
- Timer_poll	200
- Poll_SDU	1
- Last transmission PU poll	TRUE
- Last retransmission PU poll	TRUE
- Poll_Windows	99
- CHOICE Downlink RLC mode	AM RLC
- In-sequence delivery	TRUE
- Receiving window size	8
- Downlink RLC status info	
- Timer_status_prohibit	200
- Timer_EPC	200
- Missing PU indicator	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	2
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	2
- Logical channel identity	1
RB information to release	Not Present
RB information to reconfigure	Not Present
RB information to be affected	Not Present
- RB identity	
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	
- Uplink transport channel type	
- Transport channel identity	
- Logical channel identity	
- MAC logical channel priority	
- Logical channel max loss	
- Number of RLC logical channels	
- Downlink transport channel type	
- Transport channel identity	
- Logical channel identity	
UL Transport channel information for all transport channels	
- TFC subset	( This IE is repeated for TFC number.)
- Allowed Transport Format combination	0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.)
- UL DCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	
- CHOICE CTFC representation	Addition
- TFCS addition information	
- CHOICE CTFC Size	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set
- CTFC information	
- Power offset information	
- CHOICE Gain Factors	Signalled Gain Factor
- Gain factor $\beta_c$	0
- Gain factor $\beta_d$	0
- Reference TFC ID	Not Present
- Power offset Pp-m	0dB
Deleted UL TrCH information	Not Present
Added or Reconfigured UL TrCH information	

<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> </ul>	1
Added or Reconfigured UL TrCH information	( This IE is repeated for TFI number) Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> </ul>	2
DRAC static information	( This IE is repeated for TFI number) Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set
<ul style="list-style-type: none"> <li>- Transmission Time Validity</li> <li>- Time duration before retry</li> <li>- DRAC Class identity</li> </ul>	Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Not Present
DL Transport channel information common for all transport channel	
<ul style="list-style-type: none"> <li>- SCCPCH TFCS</li> <li>- CHOICE DL parameters</li> <li>- DL DCH TFCS</li> <li>- Normal</li> <li>- TFCI Field 1 information</li> <li>- CHOICE CTFC representation</li> <li>- TFCS addition information</li> </ul>	Not Present Independent ( This IE is repeated for TFC number.)
<ul style="list-style-type: none"> <li>- CHOICE CTFC Size</li> </ul>	Addition
<ul style="list-style-type: none"> <li>- CTFC information</li> <li>- Power offset information</li> </ul>	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10 Refer to TS34.108 clause 6.10 Parameter Set Not Present Not Present
Deleted DL TrCH information	
Added or Reconfigured DL TrCH information	1
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	Independent ( This IE is repeated for TFI number) Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set 0.00 Not Present
Added or Reconfigured DL TrCH information	2
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> </ul>	Independent ( This IE is repeated for TFI number) Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set  Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set

<ul style="list-style-type: none"> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	<p>Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set</p>
Frequency info	0.00
<ul style="list-style-type: none"> <li>- UARFCN uplink(Nu)</li> <li>- UARFCN downlink(Nd)</li> </ul>	Not Present
Maximum allowed UL TX power	Reference to TS34.108 clause 6.10 Parameter Set
Uplink DPCH info	Reference to TS34.108 clause 6.10 Parameter Set
<ul style="list-style-type: none"> <li>- Uplink DPCH power control info</li> <li>- DPCCH power offset</li> <li>- PC Preamble</li> <li>- Power Control Algorithm</li> <li>- TPC step size</li> <li>- Scrambling code type</li> <li>- Scrambling code number</li> <li>- Number of DPDCH</li> <li>- spreading factor</li> <li>- TFCI existence</li> <li>- Number of FBI bit</li> <li>- Puncturing Limit</li> </ul>	33dBm
Downlink information common for all radio links	-6dB
<ul style="list-style-type: none"> <li>- Downlink DPCH info common for all RL</li> <li>- Downlink DPCH power control information</li> <li>- DPC mode</li> <li>- Spreading factor</li> <li>- Fixed or Flexible Position</li> <li>- TFCI existence</li> <li>- Number of bits for Pilot bits(SF=128,256)</li> <li>- Downlink DPCH Offset Value</li> <li>- DPCH compressed mode info</li> <li>- TGPSI</li> <li>- TGPS Status Flag</li> <li>- Transmission gap pattern sequence configuration parameters</li> <li>- TGMP</li> <li>- TGPRC</li> <li>- TGCFN</li> <li>- TGSN</li> <li>- TGL1</li> <li>- TGL2</li> <li>- TGD</li> <li>- TGPL1</li> <li>- TGPL2</li> <li>- RPP</li> <li>- ITP</li> <li>- UL/DL Mode</li> <li>- Downlink compressed mode method</li> <li>- Uplink compressed mode method</li> <li>- Downlink frame type</li> <li>- DeltaSIR1</li> <li>- DeltaSIRafter1</li> <li>- DeltaSIR2</li> <li>- DeltaSIRafter2</li> <li>- TX Diversity mode</li> <li>- SSDT information</li> <li>- S field</li> <li>- Code Word Set</li> </ul>	8slot
	Algorithm1
	1dB
	Long
	0 ( 0 to 16777215)
	Not Present(1)
	SF is reference to TS34.108 clause 6.10 Parameter Set
	TRUE
	Not Present(0)
	Reference to TS34.108 clause 6.10 Parameter Set
	0 (single)
	Reference to TS34.108 clause 6.10 Parameter Set
	Flexible
	TRUE
	Reference to TS34.108 clause 6.10 Parameter Set
	0
	1
	inactive
	FDD Measurement
	62
	(Current CFN + (256 – TTI/10msec)) mod 256
	8
	10
	5
	15
	35
	35
	Mode 1
	Mode 1
	DL
	SF/2
	Not Present
	A
	2.0
	1.0
	Not Present
	Not Present
	None
	Not Present
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
<ul style="list-style-type: none"> <li>- Primary CPICH info</li> <li>- Primary scrambling code</li> <li>- PDSCH with SHO DCH info</li> <li>- DSCH radio link identifier</li> <li>- TFCI Combining set</li> </ul>	100
	Not Present



<ul style="list-style-type: none"> <li>- Radio link identifier</li> <li>- Primary CPICH info</li> <li>- Primary scrambling code</li> <li>- PDSCH code mapping</li> <li>- Downlink DPCH info for each RL</li> <li>- Primary CPICH usage for channel estimation</li> <li>- DPCH frame offset</li> <li>- Secondary CPICH info</li> <li>- Secondary scrambling code</li> <li>- channelisation code</li> <li>- DL channelisation code</li> <li>- Secondary scrambling code</li> <li>- Spreading factor</li> <li>- Code number</li> <li>- Scrambling code change</li> <li>- TPC combination index</li> <li>- SSDT Cell Identity</li> <li>- Closed loop timing adjustment mode</li> <li>- Secondary CCPCH info</li> <li>- Selection Indicator</li> <li>- Primary CPICH usage for channel estimation</li> <li>- Secondary CPICH info</li> <li>- Secondary scrambling code</li> <li>- channelisation code</li> <li>- Secondary scrambling code</li> <li>- SSDT Indicator</li> <li>- Spreading factor</li> <li>- Code number</li> <li>- Pilot symbol existence</li> <li>- TFCI existence</li> <li>- Fixed or Flexible Position</li> <li>- Timing offset</li> <li>- TFCS</li> <li>- FACH/PCH information</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- References to system information blocks</li> <li>- Scheduling information</li> </ul>	<p>Not Present</p> <p>Primary CPICH may be used 0 chips Not Present</p> <p>1 Reference to TS34.108 clause 6.10 Parameter Set SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set ) No change 0 -a Not Present Not Present</p> <p>Not Present Not Present</p> <p>Not Present</p>
---	--

Contents of RRC CONNECTION RE-ESTABLISHMENT message: UM ( Packet to CELL\_DCH from CELL\_FACH in PS )

Information Element	Value/remark
Message Type	
U-RNTI	Not Present
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	
- Ciphering mode command	start
- Ciphering algorithm	Standard UMTS Encryption Algorithm UEA1
- Activation time for DPCH	Not Present
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	0
- RLC sequence number	Current RLC SN + 2
- Radio bearer identity	1
- RLC sequence number	Current RLC SN+2
- Radio bearer identity	2
- RLC sequence number	Current RLC SN+2
- Radio bearer identity	3
- RLC sequence number	Current RLC SN+2
- Radio bearer identity	4
- RLC sequence number	Current RLC SN+2
Activation time	$(256 + CFN - (CFN \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
RLC reset indicator (for C-plane)	FALSE
RLC reset indicator (for U-plane)	FALSE
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
Signalling RB information to setup	(UM DCCH for RRC)
- RB identity	1
- CHOICE RLC info type	
- RLC info	
- CHOICE Uplink RLC mode	UM RLC
- Transmission RLC discard	
- SDU discard mode	Max DAT retransmissions
- MAX_DAT	4
- Timer_MRW	100
- MaxMRW	4
- CHOICE Downlink RLC mode	UM RLC
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	1

Signalling RB information to setup	(AM DCCH for RRC)
- RB identity	2
- CHOICE RLC info type	
- RLC info	
- CHOICE Uplink RLC mode	AM RLC
- Transmission RLC discard	
- SDU discard mode	Max DAT retransmissions
- MAX_DAT	4
- Timer_MRW	100
- MaxMRW	4
- Transmission window size	8
- Receiving window size	8
- Timer_RST	500
- Max_RST	4
- Polling info	
- Timer_poll_prohibit	200
- Timer_poll	200
- Poll_SDU	1
- Last transmission PU poll	TRUE
- Last retransmission PU poll	TRUE
- Poll_Windows	99
- CHOICE Downlink RLC mode	AM RLC
- In-sequence delivery	TRUE
- Receiving window size	8
- Downlink RLC status info	
- Timer_status_prohibit	200
- Timer_EPC	200
- Missing PU indicator	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
- MAC logical channel priority	2
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	2
Signalling RB information to setup	(AM DCCH for NAS_DT High priority)
- RB identity	3
- CHOICE RLC info type	
- RLC info	
- CHOICE Uplink RLC mode	AM RLC
- Transmission RLC discard	
- SDU discard mode	Max DAT retransmissions
- MAX_DAT	4
- Timer_MRW	100
- MaxMRW	4
- Transmission window size	8
- Receiving window size	8
- Timer_RST	500
- Max_RST	4
- Polling info	
- Timer_poll_prohibit	200
- Timer_poll	200
- Poll_SDU	1
- Last transmission PU poll	TRUE
- Last retransmission PU poll	TRUE
- Poll_Windows	99
- CHOICE Downlink RLC mode	AM RLC
- In-sequence delivery	TRUE
- Receiving window size	8
- Downlink RLC status info	
- Timer_status_prohibit	200
- Timer_EPC	200
- Missing PU indicator	TRUE

- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	3
- MAC logical channel priority	3
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	3
Signalling RB information to setup	(AM DCCH for NAS_DT Low priority)
- RB identity	4
- CHOICE RLC info type	
- RLC info	
- CHOICE Uplink RLC mode	AM RLC
- Transmission RLC discard	
- SDU discard mode	Max DAT retransmissions
- MAX_DAT	4
- Timer_MRW	100
- MaxMRW	4
- Transmission window size	8
- Receiving window size	8
- Timer_RST	500
- Max_RST	4
- Polling info	
- Timer_poll_prohibit	200
- Timer_poll	200
- Poll_SDU	1
- Last transmission PU poll	TRUE
- Last retransmission PU poll	TRUE
- Poll_Windows	99
- CHOICE Downlink RLC mode	AM RLC
- In-sequence delivery	TRUE
- Receiving window size	8
- Downlink RLC status info	
- Timer_status_prohibit	200
- Timer_EPC	200
- Missing PU indicator	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	4
- MAC logical channel priority	4
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	1
- Logical channel identity	4
RAB information for setup	
- RAB info	
- RAB identity	0000 0001B
- CN domain identity	PS domain
- Re-establishment timer	
- T314	20 seconds
- RB information to setup	
- RB identity	5
- PDCP info	Not Present
- RLC info	
- CHOICE Uplink RLC mode	AM RLC
- Transmission RLC discard	
- SDU discard mode	Max DAT retransmissions
- MAX_DAT	4
- Timer_MRW	100
- MaxMRW	4

- Transmission window size	8
- Receiving window size	8
- Timer_RST	500
- Max_RST	4
- Polling info	
- Timer_poll_prohibit	200
- Timer_poll	200
- Poll_SDU	1
- Last transmission PU poll	TRUE
- Last retransmission PU poll	TRUE
- Poll_Windows	99
- CHOICE Downlink RLC mode	AMR RLC
- In-sequence delivery	TRUE
- Receiving window size	8
- Downlink RLC status info	
- Timer_status_prohibit	200
- Timer_EPC	200
- Missing PU indicator	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	DCH
- Transport channel identity	2
- Logical channel identity	1
- MAC logical channel priority	1
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	DCH
- Transport channel identity	2
- Logical channel identity	1
RB information to release	Not Present
RB information to reconfigure	Not Present
RB information to be affected	Not Present
- RB identity	
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	
- Uplink transport channel type	
- Transport channel identity	
- Logical channel identity	
- MAC logical channel priority	
- Logical channel max loss	
- Number of RLC logical channels	
- Downlink transport channel type	
- Transport channel identity	
- Logical channel identity	
UL Transport channel information for all transport channels	
- TFC subset	( This IE is repeated for TFC number.)
- Allowed Transport Format combination	0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.)
- UL DCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	
- CHOICE CTFC representation	Addition
- TFCS addition information	
- CHOICE CTFC Size	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set
- CTFC information	
- Power offset information	
- CHOICE Gain Factors	Signalled Gain Factor
- Gain factor $\beta_c$	0
- Gain factor $\beta_d$	0
- Reference TFC ID	Not Present
- Power offset Pp-m	0dB
Deleted UL TrCH information	Not Present
Added or Reconfigured UL TrCH information	



<ul style="list-style-type: none"> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	<p>Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set</p>
Frequency info	0.00
<ul style="list-style-type: none"> <li>- UARFCN uplink(Nu)</li> <li>- UARFCN downlink(Nd)</li> </ul>	<p>Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set</p>
Maximum allowed UL TX power	33dBm
Uplink DPCH info	
<ul style="list-style-type: none"> <li>- Uplink DPCH power control info</li> <li>- DPCH power offset</li> <li>- PC Preamble</li> <li>- Power Control Algorithm</li> <li>- TPC step size</li> <li>- Scrambling code type</li> <li>- Scrambling code number</li> <li>- Number of DPDCH</li> <li>- spreading factor</li> <li>- TFCI existence</li> <li>- Number of FBI bit</li> <li>- Puncturing Limit</li> </ul>	<p>-6dB 8slot Algorithm1 1dB Long 0 ( 0 to 16777215) Not Present(1) SF is reference to TS34.108 clause 6.10 Parameter Set TRUE Not Present(0) Reference to TS34.108 clause 6.10 Parameter Set</p>
Downlink information common for all radio links	
<ul style="list-style-type: none"> <li>- Downlink DPCH info common for all RL</li> <li>- Downlink DPCH power control information</li> <li>- DPC mode</li> <li>- Spreading factor</li> <li>- Fixed or Flexible Position</li> <li>- TFCI existence</li> <li>- Number of bits for Pilot bits(SF=128,256)</li> <li>- Downlink DPCH Offset Value</li> <li>- DPCH compressed mode info</li> <li>- TGPSI</li> <li>- TGPS Status Flag</li> <li>- Transmission gap pattern sequence configuration parameters</li> <li>- TGMP</li> <li>- TGPRC</li> <li>- TGCFN</li> <li>- TGSN</li> <li>- TGL1</li> <li>- TGL2</li> <li>- TGD</li> <li>- TGPL1</li> <li>- TGPL2</li> <li>- RPP</li> <li>- ITP</li> <li>- UL/DL Mode</li> <li>- Downlink compressed mode method</li> <li>- Uplink compressed mode method</li> <li>- Downlink frame type</li> <li>- DeltaSIR1</li> <li>- DeltaSIRafter1</li> <li>- DeltaSIR2</li> <li>- DeltaSIRafter2</li> <li>- TX Diversity mode</li> <li>- SSDT information</li> <li>- S field</li> <li>- Code Word Set</li> </ul>	<p>0 (single) Reference to TS34.108 clause 6.10 Parameter Set Flexible TRUE Reference to TS34.108 clause 6.10 Parameter Set 0 1 inactive FDD Measurement 62 (Current CFN + (256 – TTI/10msec)) mod 256 8 10 5 15 35 35 Mode 1 Mode 1 DL SF/2 Not Present A 2.0 1.0 Not Present Not Present None Not Present</p>
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
<ul style="list-style-type: none"> <li>- Primary CPICH info</li> <li>- Primary scrambling code</li> <li>- PDSCH with SHO DCH info</li> <li>- DSCH radio link identifier</li> <li>- TFCI Combining set</li> </ul>	<p>100 Not Present</p>

<ul style="list-style-type: none"> <li>- Radio link identifier</li> <li>- Primary CPICH info</li> <li>- Primary scrambling code</li> <li>- PDSCH code mapping</li> <li>- Downlink DPCH info for each RL</li> <li>- Primary CPICH usage for channel estimation</li> <li>- DPCH frame offset</li> <li>- Secondary CPICH info</li> <li>- Secondary scrambling code</li> <li>- channelisation code</li> <li>- DL channelisation code</li> <li>- Secondary scrambling code</li> <li>- Spreading factor</li> <li>- Code number</li> <li>- Scrambling code change</li> <li>- TPC combination index</li> <li>- SSdT Cell Identity</li> <li>- Closed loop timing adjustment mode</li> <li>- Secondary CCPCH info</li> <li>- Selection Indicator</li> <li>- Primary CPICH usage for channel estimation</li> <li>- Secondary CPICH info</li> <li>- Secondary scrambling code</li> <li>- channelisation code</li> <li>- Secondary scrambling code</li> <li>- SSdT Indicator</li> <li>- Spreading factor</li> <li>- Code number</li> <li>- Pilot symbol existence</li> <li>- TFCI existence</li> <li>- Fixed or Flexible Position</li> <li>- Timing offset</li> <li>- TFCS</li> <li>- FACH/PCH information</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- References to system information blocks</li> <li>- Scheduling information</li> </ul>	<p>Not Present</p> <p>Primary CPICH may be used 0 chips Not Present</p> <p>1 Reference to TS34.108 clause 6.10 Parameter Set SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set ) No change 0 -a Not Present Not Present</p> <p>Not Present Not Present</p> <p>Not Present</p>
---	--



Contents of RRC CONNECTION RE-ESTABLISHMENT COMPLETE message: AM

Information Element	Value/remark
Message Type	
Integrity check info	Not checked
Uplink integrity protection activation info	Not checked
Hyper frame number	Not checked
Radio bearer uplink ciphering activation time info	SS must follow the IE to cipher on each RB.
RB with PDCP information list	Not checked
- RB with PDCP information	

Contents of RRC CONNECTION RE-ESTABLISHMENT REQUEST message: TM

Information Element	Value/remark
Message Type	
U-RNTI	Value is checked to see if it is equal to the previously assigned U-RNTI
Integrity check info	Not checked
Hyper frame number	Value if checked to see if it is equals to "maximum value in the currently used HFNs among CS and PS domains" + 1
AM_RLC error indication (for C-plane)	Not checked
AM_RLC error indication (for U-plane)	Not checked
Protocol error indicator	Value is checked to see if it is set to FALSE
Measured results on RACH	Not checked
Protocol error information	Should be absent as "Protocol error indicator" = FALSE

Contents of RRC CONNECTION REJECT message: UM

Information Element	Value/remark
Message Type	
Initial UE identity	Set to the UE's IMSI (GSM-MAP) or TMSI.
Rejection cause	Unspecified
Wait Time	0
Redirection info	Not Present

Contents of RRC CONNECTION SETUP message: UM ( Transition to CELL\_FACH )

Information Element	Value/remark
Message Type	
Initial UE identity	Reference to TS34.108 clause 6.10 Parameter Set
Activation time	(256+CFN-(CFN MOD 8 + 8 ))MOD 256
New U-RNTI	
- SRNC identity	0000 0000 0001B
- S-RNTI	0000 0000 0000 0000 0001B
New C-RNTI	0000 0000 0000 0001B
UTRAN DRX cycle length coefficient	5 ( 2 to 12 )
Capability update requirement	
- UE radio access capability update requirement	FALSE
- System specific capability update requirement	Not Present
Signalling RB information to setup	(UM DCCH for RRC)
- RB identity	1
- CHOICE RLC info type	
- RLC info	
- CHOICE Uplink RLC mode	UM RLC
- Transmission RLC discard	
- SDU discard mode	Max DAT retransmissions
- MAX_DAT	4
- Timer_MRW	100
- MaxMRW	4
- CHOICE Downlink RLC mode	UM RLC
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	1
- MAC logical channel priority	2
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	1
Signalling RB information to setup	(AM DCCH for RRC)
- RB identity	2
- CHOICE RLC info type	
- RLC info	
- CHOICE Uplink RLC mode	AM RLC
- Transmission RLC discard	
- SDU discard mode	Max DAT retransmissions
- MAX_DAT	4
- Timer_MRW	100
- MaxMRW	4
- Transmission window size	8
- Receiving window size	8
- Timer_RST	500
- Max_RST	4
- Polling info	
- Timer_poll_prohibit	200
- Timer_poll	200
- Poll_SDU	1
- Last transmission PU poll	TRUE
- Last retransmission PU poll	TRUE
- Poll_Windows	99
- CHOICE Downlink RLC mode	AM RLC
- In-sequence delivery	TRUE
- Receiving window size	8

- Downlink RLC status info	200
- Timer_status_prohibit	200
- Timer_EPC	200
- Missing PU indicator	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	2
- MAC logical channel priority	3
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	2
Signalling RB information to setup	(AM DCCH for NAS_DT High priority)
- RB identity	3
- CHOICE RLC info type	
- RLC info	
- CHOICE Uplink RLC mode	AM RLC
- Transmission RLC discard	
- SDU discard mode	Max DAT retransmissions
- MAX_DAT	4
- Timer_MRW	100
- MaxMRW	4
- Transmission window size	8
- Receiving window size	8
- Timer_RST	500
- Max_RST	4
- Polling info	
- Timer_poll_prohibit	200
- Timer_poll	200
- Poll_SDU	1
- Last transmission PU poll	TRUE
- Last retransmission PU poll	TRUE
- Poll_Windows	99
- CHOICE Downlink RLC mode	AM RLC
- In-sequence delivery	TRUE
- Receiving window size	8
- Downlink RLC status info	
- Timer_status_prohibit	200
- Timer_EPC	200
- Missing PU indicator	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	3
- MAC logical channel priority	4
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	3
Signalling RB information to setup	(AM DCCH for NAS_DT Low priority)
- RB identity	4
- CHOICE RLC info type	
- RLC info	
- CHOICE Uplink RLC mode	AM RLC
- Transmission RLC discard	
- SDU discard mode	Max DAT retransmissions
- MAX_DAT	4
- Timer_MRW	100
- MaxMRW	4
- Transmission window size	8
- Receiving window size	8
- Timer_RST	500
- Max_RST	4
- Polling info	
- Timer_poll_prohibit	200

- Timer_poll	200
- Poll_SDU	1
- Last transmission PU poll	TRUE
- Last retransmission PU poll	TRUE
- Poll_Windows	99
- CHOICE Downlink RLC mode	AM RLC
- In-sequence delivery	TRUE
- Receiving window size	8
- Downlink RLC status info	
- Timer_status_prohibit	200
- Timer_EPC	200
- Missing PU indicator	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	4
- MAC logical channel priority	5
- Logical channel max loss	0
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	4
Signalling RB information to setup	(TM CCCH for RRC)
- RB identity	0
- CHOICE RLC info type	
- RLC info	
- CHOICE Uplink RLC mode	TM RLC
- Transmission RLC Discard	Not Present
- CHOICE Downlink RLC mode	Not Present
Segmentation indication	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Uplink transport channel type	RACH
- Logical channel identity	5
- MAC logical channel priority	1
- Logical channel max loss	0
Signalling RB information to setup	(UM CCCH for RRC)
- RB identity	0
- CHOICE RLC info type	
- RLC info	
- CHOICE Uplink RLC mode	UM RLC
- Transmission RLC discard	
- SDU discard mode	
- MAX_DAT	Max DAT retransmissions
- Timer_MRW	4
- MaxMRW	100
- RB mapping info	4
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	5
Signalling RB information to setup	(TM BCCH for RRC)
- RB identity	6
- CHOICE RLC info type	
- RLC info	
- CHOICE Uplink RLC mode	Not Present
- CHOICE Downlink RLC mode	TM RLC
Segmentation indication	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	6
Signalling RB information to setup	(TM PCCH for RRC)
- RB identity	7
- CHOICE RLC info type	
- RLC info	

- CHOICE Uplink RLC mode	Not Present
- CHOICE Downlink RLC mode	TM RLC
Segmentation Indication	TRUE
- RB mapping info	
- Information for each multiplexing option	
- Number of RLC logical channels	1
- Downlink transport channel type	FACH
- Logical channel identity	1
UL Transport channel information for all transport channels	
- TFC subset	( This IE is repeated for TFC number.)
- Allowed Transport Format combination	0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.)
- UL DCH TFCS	Not Present
Added or Reconfigured UL TrCH information	
- Transport channel identity	1
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
DL Transport channel information common for all transport channel	
- SCCPCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	
- CHOICE CTFC representation	Addition
- TFCS addition information	
- CHOICE CTFC Size	
- CTFC information	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10.
- Power offset information	Refer to TS34.108 clause 6.10 Parameter Set
- CHOICE DL parameters	Not Present
- DL DCH TFCS	Independent
Added or Reconfigured DL TrCH information	Not Present
- Transport channel identity	1
- CHOICE DL parameters	Independent
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	
- BLER Quality value	0.00
- Transparent mode signalling info	Not Present
Frequency info	
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
PRACH info	
- Available Signature	
- Signature	0
- Signature	1
- Signature	2
- Signature	3
- Signature	4
- Signature	5

- Signature	6
- Signature	7
- Available SF	Reference to TS34.108 clause 6.10 Parameter Set
- Scrambling code number	0
- Puncturing Limit	Reference to TS34.108 clause 6.10 Parameter Set
- Available Sub Channel number	
- Sub channel number	0
- Sub channel number	1
- Sub channel number	2
- Sub channel number	3
- Sub channel number	4
- Sub channel number	5
- Sub channel number	6
- Sub channel number	7
- Sub channel number	8
- Sub channel number	9
- Sub channel number	10
- Sub channel number	11
Downlink information common for all radio links	Not Present
- Downlink DPCH info common for all RL	
- Downlink DPCH power control information	
- DPC mode	
- Spreading factor	
- Fixed or Flexible Position	
- TFCI existence	
- Number of bits for Pilot bits(SF=128,256)	
- Downlink DPCH Offset Value	
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	inactive
- Transmission gap pattern sequence configuration parameters	
- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink information for each radio links	Not Present
- Primary CPICH info	
- Primary scrambling code	
- PDSCH with SHO DCH info	
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	
- DL Scrambling Code	
- Signalling Method	
- Downlink DPCH info for each RL	

<ul style="list-style-type: none"> <li>- Primary CPICH usage for channel estimation</li> <li>- DPCH frame offset</li> <li>- Secondary CPICH info</li> <li>- Secondary scrambling code</li> <li>- channelisation code</li> <li>- DL channelisation code</li> <li>- Secondary scrambling code</li> <li>- Spreading factor</li> <li>- Code number</li> <li>- Scrambling code change</li> <li>- TPC combination index</li> <li>- SSdT Cell Identity</li> <li>- Closed loop timing adjustment mode</li> <li>- Secondary CCPCH info</li> <li>- Selection Indicator</li> <li>- Primary CPICH usage for channel estimation</li> <li>- Secondary CPICH info</li> <li>- Secondary scrambling code</li> <li>- channelisation code</li> <li>- Secondary scrambling code</li> <li>- SSdT Indicator</li> <li>- Spreading factor</li> <li>- Code number</li> <li>- Pilot symbol existence</li> <li>- TFCI existence</li> <li>- Fixed or Flexible Position</li> <li>- Timing offset</li> <li>- TFCS</li> <li>- FACH/PCH information</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- Scheduling information</li> </ul>	<p>Not Present</p> <p>Not Present</p>
--	---------------------------------------

## Contents of RRC STATUS message: AM

Information Element	Value/remark
Message Type	
Integrity check info	Not checked.
Protocol error information	
- Protocol error cause	Value will be checked.

Contents of SECURITY MODE FAILURE message : AM

Information Element	Value/remark
Message Type	
Integrity check info	Not checked
Failure cause	Value will be checked

Contents of TRANSPORT CHANNEL RECONFIGURATION message : AM or UM ( The others of speech in CS)

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB with PDCO info	Not Present
UL Transport channel information for all transport channels	
- TFC subset	( This IE is repeated for TFC number.)
- Allowed Transport Format combination	0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.)
- UL DCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	
- CHOICE CTFC representation	Addition
- TFCS addition information	
- CHOICE CTFC Size	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set
- CTFC information	
- Power offset information	
- CHOICE Gain Factors	Signalled Gain Factors
- Gain factor $\beta_c$	0
- Gain factor $\beta_d$	0
- Reference TFC ID	Not Present
- Power offset Pp-m	0dB
Added or Reconfigured UL TrCH information	
- Transport channel identity	1
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set



<ul style="list-style-type: none"> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> </ul>	Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set Not Present
DRAC static information <ul style="list-style-type: none"> <li>- Transmission Time Validity</li> <li>- Time duration before retry</li> <li>- DRAC Class identity</li> </ul>	
DL Transport channel information common for all transport channel <ul style="list-style-type: none"> <li>- SCCPCH TFCS</li> <li>- CHOICE DL parameters</li> <li>- DL DCH TFCS <ul style="list-style-type: none"> <li>- Normal</li> <li>- TFCI Field 1 information</li> <li>- CHOICE CTFC representation</li> <li>- TFCS addition information</li> </ul> </li> </ul>	Not Present Independent ( This IE is repeated for TFC number.)
<ul style="list-style-type: none"> <li>- CHOICE CTFC Size</li> </ul>	Addition
<ul style="list-style-type: none"> <li>- CTFC information</li> <li>- Power offset information</li> </ul>	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set Not Present
Added or Reconfigured DL TrCH information <ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- UL TrCH Identity</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	1 SameAsUL 1
Frequency info <ul style="list-style-type: none"> <li>- UARFCN uplink(Nu)</li> <li>- UARFCN downlink(Nd)</li> </ul>	0.00 Not Present
Maximum allowed UL TX power	Reference to TS34.108 clause 6.10 Parameter Set Reference to TS34.108 clause 6.10 Parameter Set 33dBm
Uplink DPCH info <ul style="list-style-type: none"> <li>-Uplink DPCH power control info</li> <li>- DPCCH power offset</li> <li>- PC Preamble</li> <li>- Power Control Algorithm</li> <li>- TPC step size</li> <li>- Scrambling code type</li> <li>- Scrambling code number</li> <li>- Number of DPDCH</li> <li>- spreading factor</li> <li>- TFCI existence</li> <li>- Number of FBI bit</li> <li>- Puncturing Limit</li> </ul>	-6dB 8slot Algorithm1 1dB Long 0 ( 0 to 16777215) Not Present(1) SF is reference to TS34.108 clause 6.10 Parameter Set TRUE Not Present(0) Reference to TS34.108 clause 6.10 Parameter Set
Downlink information common for all radio links <ul style="list-style-type: none"> <li>- Downlink DPCH info common for all RL</li> <li>- Downlink DPCH power control information</li> <li>- DPC mode</li> <li>- Spreading factor</li> <li>- Fixed or Flexible Position</li> <li>- TFCI existence</li> <li>- Number of bits for Pilot bits(SF=128,256)</li> <li>- Downlink DPCH Offset Value</li> <li>- DPCH compressed mode info</li> <li>- TGPSI</li> <li>- TGPS Status Flag</li> <li>- Transmission gap pattern sequence configuration parameters</li> <li>- TGMP</li> <li>- TGPRC</li> <li>- TGCFN</li> <li>- TGSN</li> <li>- TGL1</li> </ul>	0 (single) Reference to TS34.108 clause 6.10 Parameter Set Flexible TRUE Not Present 0 1 inactive  FDD Measurement 62 (Current CFN + (256 – TTI/10msec)) mod 256 8 10

- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- DPCH frame offset	0 chips
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	
- Spreading factor	1
- Code number	Reference to TS34.108 clause 6.10 Parameter Set SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Scrambling code change	No change
- TPC combination index	0
- SSDT Cell Identity	-a
- Closed loop timing adjustment mode	Not Present
- Secondary CCPCH info	Not Present
- Selection Indicator	
- Primary CPICH usage for channel estimation	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- Secondary scrambling code	
- SSDT Indicator	
- Spreading factor	
- Code number	
- Pilot symbol existence	
- TFCI existence	
- Fixed or Flexible Position	
- Timing offset	
- TFCS	Not Present
- FACH/PCH information	Not Present
- TFS	
- Dynamic Transport format information	
- Number of Transport blocks	
- RLC size	
- Semi-static Transport Format information	
- Transmission time interval	
- Type of channel coding	

<ul style="list-style-type: none"> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- References to system information blocks</li> <li>- Scheduling information</li> </ul>	<p>Not Present</p>
--	--------------------

Contents of TRANSPORT CHANNEL RECONFIGURATION message : AM or UM ( Speech in CS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	NoDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB with PDCP information	Not Present
UL Transport channel information for all transport channels	
- TFC subset	( This IE is repeated for TFC number.)
- Allowed Transport Format combination	0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.)
- UL DCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	
- CHOICE CTFC representation	Addition
- TFCS addition information	
- CHOICE CTFC Size	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set
- CTFC information	
- Power offset information	
- CHOICE Gain Factors	Signalled Gain Factors
- Gain factor $\beta_c$	0
- Gain factor $\beta_d$	0
- Reference TFC ID	Not Present
- Power offset Pp-m	0dB
Added or Reconfigured UL TrCH information	
- Transport channel identity	1
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
DRAC static information	Not Present
- Transmission Time Validity	

<ul style="list-style-type: none"> <li>- Time duration before retry</li> <li>- DRAC Class identity</li> </ul>	
DL Transport channel information common for all transport channel	
<ul style="list-style-type: none"> <li>- SCCPCH TFCS</li> <li>- CHOICE DL parameters</li> <li>- DL DCH TFCS</li> <li>- Normal</li> <li>- TFCI Field 1 information</li> <li>- CHOICE CTFC representation</li> <li>- TFCS addition information</li> </ul>	<p>Not Present Independent ( This IE is repeated for TFC number.)</p>
<ul style="list-style-type: none"> <li>- CHOICE CTFC Size</li> </ul>	Addition
<ul style="list-style-type: none"> <li>- CTFC information</li> <li>- Power offset information</li> </ul>	<p>Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set Not Present</p>
Added or Reconfigured DL TrCH information	
<ul style="list-style-type: none"> <li>- Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- UL TrCH Identity</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>	<p>1 SameAsUL 1</p>
Frequency info	
<ul style="list-style-type: none"> <li>- UARFCN uplink(Nu)</li> <li>- UARFCN downlink(Nd)</li> </ul>	<p>0.00 Not Present</p>
Maximum allowed UL TX power	Reference to TS34.108 clause 6.10 Parameter Set
Uplink DPCH info	Reference to TS34.108 clause 6.10 Parameter Set
<ul style="list-style-type: none"> <li>-Uplink DPCH power control info</li> <li>- DPCCH power offset</li> <li>- PC Preamble</li> <li>- Power Control Algorithm</li> <li>- TPC step size</li> <li>- Scrambling code type</li> <li>- Scrambling code number</li> <li>- Number of DPDCH</li> <li>- spreading factor</li> <li>- TFCI existence</li> <li>- Number of FBI bit</li> <li>- Puncturing Limit</li> </ul>	<p>33dBm</p> <p>-6dB 8slot Algorithm1 1dB Long 0 ( 0 to 16777215) Not Present(1) SF is reference to TS34.108 clause 6.10 Parameter Set TRUE Not Present(0) Reference to TS34.108 clause 6.10 Parameter Set</p>
Downlink information common for all radio links	
<ul style="list-style-type: none"> <li>- Downlink DPCH info common for all RL</li> <li>- Downlink DPCH power control information</li> <li>- DPC mode</li> <li>- Spreading factor</li> <li>- Fixed or Flexible Position</li> <li>- TFCI existence</li> <li>- Number of bits for Pilot bits(SF=128,256)</li> <li>- Downlink DPCH Offset Value</li> <li>- DPCH compressed mode info</li> <li>- TGPSI</li> <li>- TGPSI Status Flag</li> <li>- Transmission gap pattern sequence configuration parameters</li> <li>- TGMP</li> <li>- TGPRC</li> <li>- TGCFN</li> <li>- TGSN</li> <li>- TGL1</li> <li>- TGL2</li> <li>- TGD</li> <li>- TGPL1</li> <li>- TGPL2</li> <li>- RPP</li> <li>- ITP</li> <li>- UL/DL Mode</li> <li>- Downlink compressed mode method</li> <li>- Uplink compressed mode method</li> </ul>	<p>0 (single) Reference to TS34.108 clause 6.10 Parameter Set Flexible TRUE Not Present 0</p> <p>1 inactive</p> <p>FDD Measurement 62 (Current CFN + (256 – TTI/10msec)) mod 256 8 10 5 15 35 35 Mode 1 Mode 1 DL SF/2 Not Present</p>

- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- DPCH frame offset	0 chips
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	
- Spreading factor	1
- Code number	Reference to TS34.108 clause 6.10 Parameter Set SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Scrambling code change	No change
- TPC combination index	0
- SSDT Cell Identity	-a
- Closed loop timing adjustment mode	Not Present
- Secondary CCPCH info	Not Present
- Selection Indicator	
- Primary CPICH usage for channel estimation	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- Secondary scrambling code	
- SSDT Indicator	
- Spreading factor	
- Code number	
- Pilot symbol existence	
- TFCI existence	
- Fixed or Flexible Position	
- Timing offset	
- TFCS	Not Present
- FACH/PCH information	Not Present
- TFS	
- Dynamic Transport format information	
- Number of Transport blocks	
- RLC size	
- Semi-static Transport Format information	
- Transmission time interval	
- Type of channel coding	
- Coding Rate	
- Rate matching attribute	
- CRC size	
- TFS	
- Dynamic Transport format information	
- Number of Transport blocks	
- RLC size	
- Semi-static Transport Format information	
- Transmission time interval	

<ul style="list-style-type: none"> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- References to system information blocks</li> <li>- Scheduling information</li> </ul>	<p>Not Present</p>
---	--------------------

Contents of TRANSPORT CHANNEL RECONFIGURATION message : AM or UM ( Packet to CELL\_DCH from CELL\_DCH in PS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB with PDCP information	Not Present
UL Transport channel information for all transport channels	
- TFC subset	( This IE is repeated for TFC number.)
- Allowed Transport Format combination	0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.)
- UL DCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	
- CHOICE CTFC representation	Addition
- TFCS addition information	
- CHOICE CTFC Size	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set
- CTFC information	
- Power offset information	
- CHOICE Gain Factors	Signalled Gain Factors
- Gain factor $\beta_c$	0
- Gain factor $\beta_d$	0
- Reference TFC ID	Not Present
- Power offset Pp-m	0dB
Added or Reconfigured UL TrCH information	
- Transport channel identity	1
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set



DRAC static information	Not Present
- Transmission Time Validity	
- Time duration before retry	
- DRAC Class identity	
DL Transport channel information common for all transport channel	
- SCCPCH TFCS	Not Present
- CHOICE DL parameters	Independent
- DL DCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	
- CHOICE TFC representation	Addition
- TFCS addition information	
- CHOICE CTFC Size	
- CTFC information	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10.
- Power offset information	Refer to TS34.108 clause 6.10 Parameter Set
Added or Reconfigured DL TrCH information	Not Present
- Transport channel identity	1
- CHOICE DL parameters	Independent
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	
- BLER Quality value	0.00
- Transparent mode signalling info	Not Present
Frequency info	
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
Uplink DPCH info	
-Uplink DPCH power control info	
-DPCCH Power offset	-6dB
-PC Preamble	8slot
-Power Control Algorithm	Algorithm1
-TPC step size	1dB
-Scrambling code type	Long
-Scrambling code number	0 ( 0 to 16777215)
- Number of DPDCH	Not Present(1)
- spreading factor	SF is reference to TS34.108 clause 6.10 Parameter Set
- TFCI existence	TRUE
- Number of FBI bits	Not Present(0)
- Puncturing Limit	Reference to TS34.108 clause 6.10 Parameter Set
Downlink information common for all radio links	Not Present
- Downlink DPCH info common for all RL	
- Downlink DPCH power control information	
- DPC mode	0 (single)
- Spreading factor	Reference to TS34.108 clause 6.10 Parameter Set
- Fixed or Flexible Position	Flexible
- TFCI existence	TRUE
- Number of bits for Pilot bits(SF=128,256)	Not Present
- Downlink DPCH Offset Value	0
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	inactive
- Transmission gap pattern sequence configuration parameters	
- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256

- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	
- Primary scrambling code	100
- PDSCH with SHO DCH info	Not Present
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- DPCH frame offset	0 chips
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	1
- Spreading factor	Reference to TS34.108 clause 6.10 Parameter Set
- Code number	SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Scrambling code change	No change
- TPC combination index	0
- SSDT Cell Identity	-a
- Closed loop timing adjustment mode	Not Present
- Secondary CCPCH info	Not Present
- Selection Indicator	
- Primary CPICH usage for channel estimation	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- Secondary scrambling code	
- SSDT Indicator	
- Spreading factor	
- Code number	
- Pilot symbol existence	
- TFCI existence	
- Fixed or Flexible Position	
- Timing offset	
- TFCS	Not Present
- FACH/PCH information	Not Present
- TFS	
- Dynamic Transport format information	
- Number of Transport blocks	
- RLC size	
- Semi-static Transport Format information	

<ul style="list-style-type: none"> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- TFS</li> <li>- Dynamic Transport format information</li> <li>- Number of Transport blocks</li> <li>- RLC size</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- References to system information blocks</li> <li>- Scheduling information</li> </ul>	<p>Not Present</p>
--	--------------------

Contents of TRANSPORT CHANNEL RECONFIGURATION message : AM or UM ( Packet to CELL\_DCH from CELL\_FACH in PS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB with PDCP information	Not Present
UL Transport channel information for all transport channels	
- TFC subset	( This IE is repeated for TFC number.)
- Allowed Transport Format combination	0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.)
- UL DCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	
- CHOICE CTFC representation	Addition
- TFCS addition information	
- CHOICE CTFC Size	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to TS34.108 clause 6.10 Parameter Set
- CTFC information	
- Power offset information	
- CHOICE Gain Factors	Signalled Gain Factors
- Gain factor $\beta_c$	0
- Gain factor $\beta_d$	0
- Reference TFC ID	Not Present
- Power offset Pp-m	0dB
Added or Reconfigured UL TrCH information	
- Transport channel identity	1
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set

Added or Reconfigured UL TrCH information	2
- Transport channel identity	( This IE is repeated for TFI number)
- TFS	Reference to TS34.108 clause 6.10 Parameter Set
- Dynamic Transport format information	Reference to TS34.108 clause 6.10 Parameter Set
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	Reference to TS34.108 clause 6.10 Parameter Set
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Not Present
DRAC static information	
- Transmission Time Validity	
- Time duration before retry	
- DRAC Class identity	
DL Transport channel information common for all transport channel	
- SCCPCH TFCS	Not Present
- CHOICE DL parameters	
- DL DCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	Addition
- CHOICE CTFC representation	
- TFCS addition information	
- CHOICE CTFC Size	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10.
- CTFC information	Refer to TS34.108 clause 6.10 Parameter Set
- Power offset information	Not Present
Added or Reconfigured DL TrCH information	1
- Transport channel identity	Independent
- CHOICE DL parameters	
- TFS	( This IE is repeated for TFI number)
- Dynamic Transport format information	Reference to TS34.108 clause 6.10 Parameter Set
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	
- Semi-static Transport Format information	Reference to TS34.108 clause 6.10 Parameter Set
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	
- BLER Quality value	0.00
- Transparent mode signalling info	Not Present
Added or Reconfigured DL TrCH information	2
- Transport channel identity	Independent
- CHOICE DL parameters	
- TFS	( This IE is repeated for TFI number)
- Dynamic Transport format information	Reference to TS34.108 clause 6.10 Parameter Set
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	
- Semi-static Transport Format information	Reference to TS34.108 clause 6.10 Parameter Set
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	
- BLER Quality value	0.00
- Transparent mode signalling info	Not Present
Frequency info	
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
Uplink DPCH info	
-Uplink DPCH power control info	



- Spreading factor	Reference to TS34.108 clause 6.10 Parameter Set SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Code number	No change
- Scrambling code change	0
- TPC combination index	-a
- SSDT Cell Identity	Not Present
- Closed loop timing adjustment mode	Not Present
- Secondary CCPCH info	
- Selection Indicator	
- Primary CPICH usage for channel estimation	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- Secondary scrambling code	
- SSDT Indicator	
- Spreading factor	
- Code number	
- Pilot symbol existence	
- TFCl existence	
- Fixed or Flexible Position	
- Timing offset	
- TFCS	Not Present
- FACH/PCH information	Not Present
- TFS	
- Dynamic Transport format information	
- Number of Transport blocks	
- RLC size	
- Semi-static Transport Format information	
- Transmission time interval	
- Type of channel coding	
- Coding Rate	
- Rate matching attribute	
- CRC size	
- TFS	
- Dynamic Transport format information	
- Number of Transport blocks	
- RLC size	
- Semi-static Transport Format information	
- Transmission time interval	
- Type of channel coding	
- Coding Rate	
- Rate matching attribute	
- CRC size	
- References to system information blocks	Not Present
- Scheduling information	

Contents of TRANSPORT CHANNEL RECONFIGURATION message : AM or UM ( Packet to CELL\_FACH from CELL\_DCH in PS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	Not Present
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB with PDCP information	Not Present
UL Transport channel information for all transport channels	
- TFC subset	( This IE is repeated for TFC number.)
- Allowed Transport Format combination	0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.)
- UL DCH TFCS	Not Present
Added or Reconfigured UL TrCH information	
- Transport channel identity	1
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
DRAC static information	Not Present
- Transmission Time Validity	
- Time duration before retry	
- DRAC Class identity	
DL Transport channel information common for all transport channel	
- SCCPCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	
- CHOICE CTFC representation	Addition
- TFCS addition information	
- CHOICE CTFC Size	
- CTFC information	Refer to TS34.108 clause 6.10 Parameter Set



- Power offset information	Not Present
- CHOICE DL parameters	Independent
- DL DCH TFCs	Not Present
Added or Reconfigured DL TrCH information	1
- Transport channel identity	Independent
- CHOICE DL parameters	( This IE is repeated for TFI number)
- TFS	Reference to TS34.108 clause 6.10 Parameter Set
- Dynamic Transport format information	Reference to TS34.108 clause 6.10 Parameter Set
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	Reference to TS34.108 clause 6.10 Parameter Set
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	Not Present
- BLER Quality value	Not Present
- Transparent mode signalling info	Not Present
Added or Reconfigured DL TrCH information	2
- Transport channel identity	Independent
- CHOICE DL parameters	( This IE is repeated for TFI number)
- TFS	Reference to TS34.108 clause 6.10 Parameter Set
- Dynamic Transport format information	Reference to TS34.108 clause 6.10 Parameter Set
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	Reference to TS34.108 clause 6.10 Parameter Set
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	Not Present
- BLER Quality value	Not Present
- Transparent mode signalling info	Not Present
Added or Reconfigured DL TrCH information	3
- Transport channel identity	Independent
- CHOICE DL parameters	( This IE is repeated for TFI number)
- TFS	Reference to TS34.108 clause 6.10 Parameter Set
- Dynamic Transport format information	Reference to TS34.108 clause 6.10 Parameter Set
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	Reference to TS34.108 clause 6.10 Parameter Set
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	Not Present
- BLER Quality value	Not Present
- Transparent mode signalling info	Not Present
Added or Reconfigured DL TrCH information	4
- Transport channel identity	Independent
- CHOICE DL parameters	( This IE is repeated for TFI number)
- TFS	Reference to TS34.108 clause 6.10 Parameter Set
- Dynamic Transport format information	Reference to TS34.108 clause 6.10 Parameter Set
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	Reference to TS34.108 clause 6.10 Parameter Set
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
- DCH quality target	Not Present
- BLER Quality value	Not Present
- Transparent mode signalling info	Not Present
Frequency info	

- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
PRACH info	
- Available Signature	
- Signature	0
- Signature	1
- Signature	2
- Signature	3
- Signature	4
- Signature	5
- Signature	6
- Signature	7
- Available SF	Reference to TS34.108 clause 6.10 Parameter Set
- Scrambling code number	0
- Puncturing Limit	Reference to TS34.108 clause 6.10 Parameter Set
- Available Sub Channel number	
- Sub channel number	0
- Sub channel number	1
- Sub channel number	2
- Sub channel number	3
- Sub channel number	4
- Sub channel number	5
- Sub channel number	6
- Sub channel number	7
- Sub channel number	8
- Sub channel number	9
- Sub channel number	10
- Sub channel number	11
Downlink information common for all radio links	Not Present
- Downlink DPCH info common for all RL	
- Downlink DPCH power control information	
- DPC mode	
- Spreading factor	
- Fixed or Flexible Position	
- TFCI existence	
- Number of bits for Pilot bits(SF=128,256)	
- Downlink DPCH Offset Value	
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	inactive
- Transmission gap pattern sequence configuration parameters	
- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR1	Not Present
- DeltaSIRafter1	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present
CPCH SET info	Not Present

Downlink information for each radio links	
- Primary CPICH info	100
- Primary scrambling code	Not Present
- PDSCH with SHO DCH info	
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	Not Present
- Primary CPICH usage for channel estimation	
- DPCH frame offset	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	
- Spreading factor	
- Code number	
- Scrambling code change	
- TPC combination index	
- SSDT Cell Identity	
- Closed loop timing adjustment mode	
- Secondary CCPCH info	
- Selection Indicator	Not Present
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- Secondary scrambling code	
- SSDT Indicator	1
- Spreading factor	FALSE
- Code number	Reference to TS34.108 clause 6.10 Parameter Set SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Pilot symbol existence	FALSE
- TFCI existence	TRUE
- Fixed or Flexible Position	Flexible
- Timing offset	0
- TFCS	Not Present
- FACH/PCH information	Not Present
- TFS	
- Dynamic Transport format information	
- Number of Transport blocks	
- RLC size	
- Semi-static Transport Format information	
- Transmission time interval	
- Type of channel coding	
- Coding Rate	
- Rate matching attribute	
- CRC size	
- TFS	
- Dynamic Transport format information	
- Number of Transport blocks	
- RLC size	
- Semi-static Transport Format information	
- Transmission time interval	
- Type of channel coding	
- Coding Rate	
- Rate matching attribute	
- CRC size	
- References to system information blocks	Not Present
- Scheduling information	

Contents of TRANSPORT CHANNEL RECONFIGURATION message : AM or UM ( Packet to CELL\_FACH from CELL\_FACH in PS )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
Activation time	$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$
New U-RNTI	Not Present
New C-RNTI	0000 0000 0000 0010B
DRX indicator	noDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
RB with PDCP information	Not Present
UL Transport channel information for all transport channels	
- TFC subset	( This IE is repeated for TFC number.)
- Allowed Transport Format combination	0 to MaxTFCValue-1 ( MaxTFCValue is refer to TS34.108 clause 6.10 Parameter Set.)
- UL DCH TFCS	Not Present
Added or Reconfigured UL TrCH information	
- Transport channel identity	1
- TFS	
- Dynamic Transport format information	( This IE is repeated for TFI number)
- Number of Transport blocks	Reference to TS34.108 clause 6.10 Parameter Set
- RLC size	Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information	
- Transmission time interval	Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding	Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate	Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute	Reference to TS34.108 clause 6.10 Parameter Set
- CRC size	Reference to TS34.108 clause 6.10 Parameter Set
DRAC static information	Not Present
- Transmission Time Validity	
- Time duration before retry	
- DRAC Class identity	
DL Transport channel information common for all transport channel	
- SCCPCH TFCS	( This IE is repeated for TFC number.)
- Normal	
- TFCI Field 1 information	
- CHOICE CTFC representation	Addition
- TFCS addition information	
- CHOICE CTFC Size	Number of bits used must be enough to cover all combinations of CTFC from clause 6.10.

- CTFC information		Refer to TS34.108 clause 6.10 Parameter Set
- Power offset information		
- CHOICE DL parameters		Independent
- DL DCH TFCS		Not Present
Added or Reconfigured DL TrCH information		
- Transport channel identity	1	
- CHOICE DL parameters	Independent	
- TFS		( This IE is repeated for TFI number)
- Dynamic Transport format information		Reference to TS34.108 clause 6.10 Parameter Set
- Number of Transport blocks		Reference to TS34.108 clause 6.10 Parameter Set
- RLC size		Reference to TS34.108 clause 6.10 Parameter Set
- Semi-static Transport Format information		Reference to TS34.108 clause 6.10 Parameter Set
- Transmission time interval		Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding		Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate		Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute		Reference to TS34.108 clause 6.10 Parameter Set
- CRC size		Not Present
- DCH quality target		
- BLER Quality value		
- Transparent mode signalling info		Not Present
Added or Reconfigured DL TrCH information		
- Transport channel identity	2	
- CHOICE DL parameters	Independent	
- TFS		( This IE is repeated for TFI number)
- Dynamic Transport format information		Reference to TS34.108 clause 6.10 Parameter Set
- Number of Transport blocks		Reference to TS34.108 clause 6.10 Parameter Set
- RLC size		
- Semi-static Transport Format information		Reference to TS34.108 clause 6.10 Parameter Set
- Transmission time interval		Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding		Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate		Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute		Reference to TS34.108 clause 6.10 Parameter Set
- CRC size		Not Present
- DCH quality target		
- BLER Quality value		
- Transparent mode signalling info		Not Present
Added or Reconfigured DL TrCH information		
- Transport channel identity	3	
- CHOICE DL parameters	Independent	
- TFS		( This IE is repeated for TFI number)
- Dynamic Transport format information		Reference to TS34.108 clause 6.10 Parameter Set
- Number of Transport blocks		Reference to TS34.108 clause 6.10 Parameter Set
- RLC size		
- Semi-static Transport Format information		Reference to TS34.108 clause 6.10 Parameter Set
- Transmission time interval		Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding		Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate		Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute		Reference to TS34.108 clause 6.10 Parameter Set
- CRC size		Not Present
- DCH quality target		
- BLER Quality value		
- Transparent mode signalling info		Not Present
Added or Reconfigured DL TrCH information		
- Transport channel identity	4	
- CHOICE DL parameters	Independent	
- TFS		( This IE is repeated for TFI number)
- Dynamic Transport format information		Reference to TS34.108 clause 6.10 Parameter Set
- Number of Transport blocks		Reference to TS34.108 clause 6.10 Parameter Set
- RLC size		
- Semi-static Transport Format information		Reference to TS34.108 clause 6.10 Parameter Set
- Transmission time interval		Reference to TS34.108 clause 6.10 Parameter Set
- Type of channel coding		Reference to TS34.108 clause 6.10 Parameter Set
- Coding Rate		Reference to TS34.108 clause 6.10 Parameter Set
- Rate matching attribute		Reference to TS34.108 clause 6.10 Parameter Set
- CRC size		Not Present
- DCH quality target		
- BLER Quality value		
- Transparent mode signalling info		Not Present

Frequency info	
- UARFCN uplink(Nu)	Reference to TS34.108 clause 6.10 Parameter Set
- UARFCN downlink(Nd)	Reference to TS34.108 clause 6.10 Parameter Set
Maximum allowed UL TX power	33dBm
PRACH info	
- Available Signature	
- Signature	0
- Signature	1
- Signature	2
- Signature	3
- Signature	4
- Signature	5
- Signature	6
- Signature	7
- Available SF	Reference to TS34.108 clause 6.10 Parameter Set
- Scrambling code number	0
- Puncturing Limit	Reference to TS34.108 clause 6.10 Parameter Set
- Available Sub Channel number	
- Sub channel number	0
- Sub channel number	1
- Sub channel number	2
- Sub channel number	3
- Sub channel number	4
- Sub channel number	5
- Sub channel number	6
- Sub channel number	7
- Sub channel number	8
- Sub channel number	9
- Sub channel number	10
- Sub channel number	11
Downlink information common for all radio links	Not Present
- Downlink DPCH info common for all RL	
- Downlink DPCH power control information	
- DPC mode	
- Spreading factor	
- Fixed or Flexible Position	
- TFCI existence	
- Number of bits for Pilot bits(SF=128,256)	
- Downlink DPCH Offset Value	
- DPCH compressed mode info	
- TGPSI	1
- TGPS Status Flag	inactive
- Transmission gap pattern sequence configuration parameters	
- TGMP	FDD Measurement
- TGPRC	62
- TGCFN	(Current CFN + (256 – TTI/10msec)) mod 256
- TGSN	8
- TGL1	10
- TGL2	5
- TGD	15
- TGPL1	35
- TGPL2	35
- RPP	Mode 1
- ITP	Mode 1
- UL/DL Mode	DL
- Downlink compressed mode method	SF/2
- Uplink compressed mode method	Not Present
- Downlink frame type	A
- DeltaSIR1	2.0
- DeltaSIRafter1	1.0
- DeltaSIR2	Not Present
- DeltaSIRafter2	Not Present
- TX Diversity mode	None
- SSDT information	Not Present
- S field	
- Code Word Set	
Downlink PDSCH information	Not Present

CPCH SET info	Not Present
Downlink information for each radio links	
- Primary CPICH info	150
- Primary scrambling code	Not Present
- PDSCH with SHO DCH info	
- DSCH radio link identifier	
- TFCI Combining set	
- Radio link identifier	
- Primary CPICH info	
- Primary scrambling code	
- PDSCH code mapping	Not Present
- Downlink DPCH info for each RL	Not Present
- Primary CPICH usage for channel estimation	
- DPCH frame offset	
- Secondary CPICH info	
- Secondary scrambling code	
- channelisation code	
- DL channelisation code	
- Secondary scrambling code	
- Spreading factor	
- Code number	
- Scrambling code change	
- TPC combination index	
- SSDT Cell Identity	
- Closed loop timing adjustment mode	
- Secondary CCPCH info	
- Selection Indicator	Not Present
- Primary CPICH usage for channel estimation	Primary CPICH may be used
- Secondary CPICH info	Not Present
- Secondary scrambling code	
- channelisation code	
- Secondary scrambling code	
- SSDT Indicator	1
- Spreading factor	FALSE
- Code number	Reference to TS34.108 clause 6.10 Parameter Set SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set )
- Pilot symbol existence	FALSE
- TFCI existence	TRUE
- Fixed or Flexible Position	Flexible
- Timing offset	0
- TFCS	Not Present
- FACH/PCH information	Not Present
- TFS	
- Dynamic Transport format information	
- Number of Transport blocks	
- RLCsize	
- Semi-static Transport Format information	
- Transmission time interval	
- Type of channel coding	
- Coding Rate	
- Rate matching attribute	
- CRC size	
- TFS	
- Dynamic Transport format information	
- Number of Transport blocks	
- RLC size	
- Semi-static Transport Format information	
- Transmission time interval	
- Type of channel coding	
- Coding Rate	
- Rate matching attribute	
- CRC size	
- References to system information blocks	Not Present
- Scheduling information	

Contents of TRANSPORT CHANNEL RECONFIGURATION COMPLETE message: AM

Information Element	Value/remark
Message Type	
Integrity check info	Not checked
Uplink integrity protection activation info	Not checked
Other information element	Not checked
Radio bearer uplink ciphering activation time info	Not checked
RB with PDCP information list	Not checked

Contents of TRANSPORT FORMAT COMBINATION CONTROL message : AM or UM ( in CELL\_DCH )

Information Element	Value/remark
Message Type	
Integrity check info	Not Present
- Message authentication code	
- RRC Message sequence number	
DPCH TFCS in Uplink	
- Allowed Transport format combination index	0 (The TFC is constructed from ALL TF0)

Contents of UE CAPABILITY ENQUIRY message : [TBD]

Information Element	Value/remark
Message Type	
Integrity check info	Not checked
Capability update requirement	
- UE radio access capability update requirement	TRUE
- System specific capability update requirement	UE only supports 1 system
list	
- System specific capability update requirement	GSM

Contents of UE CAPABILITY INFORMATION message : AM or UM

Information Element	Value/remark
Message Type	
Integrity check info	Not checked
UE radio access capability	Value will be checked. Stated capability must be compatible with 34.123-2 (ICS statements) and the user settings
- ICS Version	
- PDCP Capability	
- RLC Capability	
- Transport channel capability	
- RF Capability	
- Physical channel capability	
- UE multi-mode/multi-RAT capability	
- Security Capability	
- LCS Capability	
- Measurement capability	
UE system specific capability	Value will be checked. UE must include the classmark information for the supported system



Contents of UE CAPABILITY INFORMATION CONFIRM message : UM

Information Element	Value/remark
Message Type	
Integrity check info	Not checked

Contents of URA UPDATE message: TM

Information Element	Value/remark
Message Type	
U-RNTI	
- SRNC identity	0000 0000 0001B
- S-RNTI	0000 0000 0000 0000 0001B
Integrity check info	Not checked
AM_RLC error indication	Not checked
URA update cause	See the test content
Protocol error indicator	Not checked
Protocol error information	Not checked

Contents of URA UPDATE CONFIRM message: UM

Information Element	Value/remark
Message Type	
U-RNTI	
- SRNC identity	0000 0000 0001B
- S-RNTI	0000 0000 0000 0000 0001B
Integrity check info	Not Present
- message authentication code	
- RRC message sequence number	
Integrity protection mode info	Not Present
- Integrity protection mode command	
- Downlink integrity protection activation info	
- RRC message sequence number	
- RRC message sequence number	
- Integrity protection algorithm	
- Integrity protection initialisation number	
Ciphering mode info	Not Present
- Ciphering mode command	
- Ciphering algorithm	
- Activation time for DPCH	
- Radio bearer downlink ciphering activation time info	
- Radio bearer identity	
- RLC sequence number	
New U-RNTI	Not Present
- SRNC identity	
- S-RNTI	
New C-RNTI	Not Present
DRX indicator	NoDRX
UTRAN DRX cycle length coefficient	Not Present
CN information info	Not Present
- PLMN identity	
- CN common GSM-MAP NAS system information	
- CN domain identity	
- CN domain specific GSM-MAP NAS system information	
URA identity	See the test content
RB with PDCP information	Not Present
- RB identity	
- PDCP SN info	

## Annex B (informative): Change history

Meeting -1st- Level	Doc-1st- Level	CR	Rev	Subject	Cat	Version- Current	Version -New	Doc-2nd- Level
TP-08				Approval of the specification		2.0.0	3.0.0	
TP-09	TP-000135	001		Idle mode test cases	F	3.0.0	3.1.0	T1-000165
TP-09	TP-000135	002		Section 8, RRC Tests: RLCSIZE	C	3.0.0	3.1.0	T1-000169
TP-09	TP-000135	003		Section 8, RRC Tests: HFN	C	3.0.0	3.1.0	T1-000170
TP-09	TP-000135	004		Section 8, RRC Tests: RLCParam	C	3.0.0	3.1.0	T1-000171
TP-09	TP-000135	005		Section 8, RRC Tests: RbIdentity	C	3.0.0	3.1.0	T1-000172
TP-09	TP-000135	006		Section 8, RRC Tests: TrCHParam	C	3.0.0	3.1.0	T1-000173
TP-09	TP-000135	007		Section 8, RRC Tests: UE Capability	C	3.0.0	3.1.0	T1-000174
TP-09	TP-000135	008		Section 8, RRC Tests: RB Mapping	C	3.0.0	3.1.0	T1-000175
TP-09	TP-000135	009		Section 8, RRC Tests: Paging Cause	C	3.0.0	3.1.0	T1-000176
TP-09	TP-000135	010		Section 8, RRC Tests: RRCConnRelease-TM	B	3.0.0	3.1.0	T1-000177
TP-09	TP-000135	011		Section 8, RRC Tests: SignallingRelease	B	3.0.0	3.1.0	T1-000178
TP-09	TP-000135	012		Section 8, RRC Tests: CipheringAndIntegrity	C	3.0.0	3.1.0	T1-000179
TP-09	TP-000135	013		Section 8, RRC Tests: Countercheck_rev	B	3.0.0	3.1.0	T1-000180
TP-09	TP-000135	014		Section 8, RRC Tests: RLCInfo	C	3.0.0	3.1.0	T1-000181
TP-09	TP-000135	015		Section 8, RRC Tests: CompressedMode	C	3.0.0	3.1.0	T1-000182
TP-09	TP-000135	016		Section 8, RRC Tests: SIB	F	3.0.0	3.1.0	T1-000183
TP-09	TP-000135	017		Section 8, RRC Tests: PhyCH	D	3.0.0	3.1.0	T1-000184
TP-09	TP-000135	018		Section 8, RRC Tests: Measurement	C	3.0.0	3.1.0	T1-000185
TP-09	TP-000135	019		Section 8, RRC Tests: FailureCases	C	3.0.0	3.1.0	T1-000186
TP-09	TP-000135	020		Section 8, RRC Tests: TFCS	C	3.0.0	3.1.0	T1-000187
TP-09	TP-000135	021		Section 8, RRC Tests: DPCHFrameOffset	C	3.0.0	3.1.0	T1-000188
TP-09	TP-000135	022		Section 8, RRC Tests: ReEstablishmentTimer	C	3.0.0	3.1.0	T1-000189
TP-09	TP-000135	023		Section 8, RRC Tests: InterFrequencyHardHandOver	F	3.0.0	3.1.0	T1-000206
TP-09	TP-000135	024		clause 12.4.1.5 "Routing area updating / abnormal cases / attempt counter check / miscellaneous reject causes"	C	3.0.0	3.1.0	T1-000211
TP-09	TP-000135	025		SM test cases	C	3.0.0	3.1.0	T1-000208
TP-09	TP-000135	026		MM : Authentication	F	3.0.0	3.1.0	T1-000207
TP-09	TP-000135	027		Update of radio bearer test cases (aligned to GSMA ISG version 1.3)	F	3.0.0	3.1.0	T1-000213
TP-09	TP-000135	028		MAC tests	B	3.0.0	3.1.0	T1-000218
TP-09	TP-000135	029		PDCP tests	B	3.0.0	3.1.0	T1-000166
TP-09	TP-000135	030		BMC tests	B	3.0.0	3.1.0	T1-000167
TP-09	TP-000135	031		RRC updates	F	3.0.0	3.1.0	T1-000168
TP-09	TP-000135	032		clause 12.6.1.2 "Authentication rejected"	F	3.0.0	3.1.0	T1-000210
TP-09	TP-000135	033		clause 12.6 "PS authentication and ciphering"	C	3.0.0	3.1.0	T1-000209

History

Document history		
V3.0.0	June 2000	Publication
V3.1.0	September 2000	Publication