Draft ETSI EN 303 146-3 V1.1.7 (2016-05)



Reconfigurable Radio Systems (RRS); Mobile Device (MD) information models and protocols; Part 3: Unified Radio Application Interface (URAI)

Reference DEN/RRS-0213 Keywords interface, mobile, SDR

ETSI

650 Route des Lucioles F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C Association à but non lucratif enregistrée à la Sous-Préfecture de Grasse (06) N° 7803/88

Important notice

The present document can be downloaded from: http://www.etsi.org/standards-search

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the only prevailing document is the print of the Portable Document Format (PDF) version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx

If you find errors in the present document, please send your comment to one of the following services: https://portal.etsi.org/People/CommiteeSupportStaff.aspx

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2016.
All rights reserved.

DECTTM, **PLUGTESTS**TM, **UMTS**TM and the ETSI logo are Trade Marks of ETSI registered for the benefit of its Members. **3GPP**TM and **LTE**TM are Trade Marks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

GSM® and the GSM logo are Trade Marks registered and owned by the GSM Association.

Contents

Intell	ectual Property Rights	²
Forev	word	
Mods	al verbs terminology	2
1	Scope	
2	References	
2.1	Normative references	
2.2	Informative references	
3	Definitions and abbreviations	6
3.1	Definitions	
3.2	Abbreviations	
4	Introduction	
5	System Identification.	5
5.1	Radio Computer Structure	
5.2	URAI System Requirement Mapping	
6	Notational Tools	1.
6.1	Notational Tools Information Model Classes	
6.2	Notational Tool for Interface Classes	
7	Information Model for Radio Computer	1′
7.1	Radio Computer	
7.2	Class Definitions for Information Model	
8	Interface Definition	27
8.1	Interface Overview	
8.2	Radio Application Management Services	
8.2.1	Overview on Radio Application Management Services	
8.2.2	Messages for Radio Application Management Services	
8.3	User Data Flow Services	
8.3.1	Overview on User Data Flow Services	
8.3.2	Messages for User Data Flow Services	
8.4	Multiradio Control Services	
8.4.1	Overview on Multiradio Control Services	
8.4.2	Messages for Multiradio Control Services	
8.5	Class Definitions for Interface	25
Anne	ex A (informative): Abstract Data Definitions	20
Anne	ex B (informative): URAI Qualification Methods for Validation	30
Histo	nrv	31

Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (https://ipr.etsi.org/).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Foreword

This draft European Standard (EN) has been produced by ETSI Technical Committee Reconfigurable Radio Systems (RRS), and is now submitted for the combined Public Enquiry and Vote phase of the ETSI standards EN Approval Procedure.

The present document is part 1 of a multi-part deliverable covering Mobile Device (MD) information models and protocols, as identified below:

Part 1: "Multiradio Interface (MURI)";

Part 2: "Reconfigurable Radio Frequency Interface (RRFI)";

Part 3: "Unified Radio Application Interface (URAI)";

Part 4: "Radio Programming Interface (RPI)".

Proposed national transposition dates		
Date of latest announcement of this EN (doa):	3 months after ETSI publication	
Date of latest publication of new National Standard or endorsement of this EN (dop/e):	6 months after doa	
Date of withdrawal of any conflicting National Standard (dow):	6 months after doa	

Modal verbs terminology

In the present document "shall", "shall not", "should", "should not", "may", "need not", "will", "will not", "can" and "cannot" are to be interpreted as described in clause 3.2 of the <u>ETSI Drafting Rules</u> (Verbal forms for the expression of provisions).

"must" and "must not" are NOT allowed in ETSI deliverables except when used in direct citation.

1 Scope

The scope of the present document is to define an information model and protocol for unified radio application interface for mobile device reconfiguration. The work is based on the Use Cases defined in ETSI TR 102 944 [i.1], on the system requirements defined in ETSI EN 302 969 [1] and on the radio reconfiguration related architecture for mobile devices defined in ETSI EN 303 095 [i.2] and on the mobile device information models and protocols related Multiradio Interface defined ETSI EN 303 146-1 [i.3].

2 References

2.1 Normative references

References are either specific (identified by date of publication and/or edition number or version number) or non-specific. For specific references, only the cited version applies. For non-specific references, the latest version of the referenced document (including any amendments) applies.

Referenced documents which are not found to be publicly available in the expected location might be found at http://docbox.etsi.org/Reference.

NOTE: While any hyperlinks included in this clause were valid at the time of publication, ETSI cannot guarantee their long term validity.

The following referenced documents are necessary for the application of the present document.

[1] ETSI EN 302 969 (V1.2.1) (11-2014): "Reconfigurable Radio Systems (RRS); Radio Reconfiguration related Requirements for Mobile Devices".

2.2 Informative references

References are either specific (identified by date of publication and/or edition number or version number) or non-specific. For specific references, only the cited version applies. For non-specific references, the latest version of the referenced document (including any amendments) applies.

NOTE: While any hyperlinks included in this clause were valid at the time of publication, ETSI cannot guarantee their long term validity.

The following referenced documents are not necessary for the application of the present document but they assist the user with regard to a particular subject area.

[i.1]	ETSI TR 102 944: "Reconfigurable Radio Systems (RRS); Use Cases for Baseband Interfaces for Unified Radio Applications of Mobile Device".
[i.2]	ETSI EN 303 095 (V1.2.1): "Reconfigurable Radio Systems (RRS); Radio Reconfiguration related Architecture for Mobile Devices".
[i.3]	ETSI EN 303 146-1: "Reconfigurable Radio Systems (RRS); Mobile Device Information Models and Protocols; Part 1: Multiradio Interface (MURI)".
[i.4]	ETSI EN 303 146-2: "Reconfigurable Radio Systems (RRS); Mobile Device Information Models and Protocols; Part 2: Reconfigurable Radio Frequency Interface (RRFI)".
[i.5]	ETSI TR 102 839: "Reconfigurable Radio Systems (RRS); Multiradio Interface for Software Defined Radio (SDR) Mobile Device Architecture and Services".
[i.6]	IEEE 1900.4-2009 TM : "IEEE Standard for Architectural Building Blocks Enabling Network-Device Distributed Decision Making for Optimized Radio Resource Usage in Heterogeneous Wireless Access Networks".
[i.7]	Recommendation ITU-T X.680: "Information technology - Abstract Syntax Notation One

(ASN.1): Specification of basic notation".

3 Definitions and abbreviations

3.1 Definitions

For the purposes of the present document, the following terms and definitions apply:

association: logical communication link to a Radio Access Network or a peer equipment

NOTE 1: Typically, some control signalling is necessary to maintain the association. No user data transfer may occur with only an association present, but a data flow may be established into an association for this purpose.

NOTE 2: Peer equipment is any communication counterpart of a reconfigurable mobile device. It can be reached by establishing a logical communication link (i.e. an association) between the reconfigurable mobile device and peer equipment.

channel: designated part of the information transfer capability having specified characteristics, provided at the user network interface

NOTE: It is the over-the-air wireless propagation channel which is used to convey an information signal from transmitter to receiver. This definition is specified in ETSI EN 303 095 [i.2].

communication services layer: layer related to communication services supporting generic applications

NOTE: A communication services layer supports generic applications like Internet access. In the present document, it consists of Administrator, Mobility Policy Manager (MPM), Networking stack and Monitor.

link: connection from one location to another through a given Radio Access Technology for the purpose of transmitting and receiving digital information

Radio Application (RA): software which enforces the generation of the transmit RF signals or the decoding of the receive RF signals

NOTE 1: The Software is executed on a particular radio platform or an RVM as part of the radio platform.

NOTE 2: RAs might have different forms of representation. They are represented as:

- source codes including Radio Library calls of Radio Library native implementation and Radio HAL calls;
- IRs including Radio Library calls of Radio Library native implementation and radio HAL calls;
- Executable codes for a particular radio platform.

radio computer: part of mobile device hardware working under ROS control and on which RAs are executed

NOTE: A Radio Computer typically includes programmable processors, hardware accelerators, peripherals, etc. RF part is considered to be part of peripherals.

Radio Control Framework (RCF): control framework which, as a part of the OS, extends OS capabilities in terms of radio resource management

NOTE: RCF is a control framework which consists of Configuration Manager (CM), Radio Connection Manager (RCM), Flow Controller (FC) and Multiradio Controller (MRC). The Resource Manager (RM) is typically part of OS.

3.2 Abbreviations

For the purposes of the present document, the following abbreviations apply:

ASN Abstract Syntax Notation ASN.1 Abstract Syntax Notation One

BLER BLock Error Rate
CM Configuration Manager

CSL	Communication Services Layer
FC	Flow Controller
ID	IDentification
MD	Mobile Device
MPM	Mobility Policy Manager
MRC	MultiRadio Controller
MURI	MUltiradio Interface
OS	Operating System
RA	Radio Application
DANI	
RAN	Radio Access Network
RAN RAP	Radio Access Network Radio Application Package
	114410 1144400 114411 0111
RAP	Radio Application Package
RAP RAT	Radio Application Package Radio Access Technology

RF Radio Frequency
RM Resource Manager
ROS Radio Operating System
RPI Radio Programming Interface

RRFI Reconfigurable Radio Frequency Interface SINR Signal to Interference plus Noise Ratio

UML Unified Modelling Language URA Unified Radio Applications

URAI Unified Radio Application Interface

4 Introduction

A reconfigurable MD is capable of running multiple radios simultaneously and of changing the set of radios by loading new Radio Application Package (RAP). All Radio Applications (RAs) are called Unified Radio Applications (URAs) when they exhibit a common behaviour from the reconfigurable MD's point of view [i.2]. In order to run multiple URAs, the reconfigurable MD will include Communication Services Layer (CSL), Radio Control Framework (RCF), Radio Platform and 4 sets of interfaces for their interconnection.




Figure 4.1: Four sets of interfaces for Reconfigurable MD

Figure 4.1 illustrates the Reconfigurable MD architecture with the 4 sets of interfaces, i.e.:

- MURI for interfacing CSL and RCF [i.3];
- RRFI for interfacing URA and RF Transceiver [i.4];
- URAI for interfacing URA and RCF which is the scope of the present document;
- RPI for allowing an independent and uniform production of RAs [i.5].

The present document defines UARI.




Figure 4.2: UML class diagram for Radio Computer interfaces

Figure 4.2 illustrates UML class diagram for Radio Computer interfaces. The reconfigurable MD may be seen as a Radio Computer where individual URAs are engineered as software entities [i.2].

The present document is organized as follows:

- Clause 5 describes the system identification;
- Clause 6 describes the notational tool for defining both information model classes and interface classes;
- Clause 7 describes the information model for radio computer; and
- Clause 8 describes the interface definition.

While UML is used for defining the information model and protocol related to URAI, other modelling languages could be used as well.

5 System Identification

5.1 Radio Computer Structure

Figure 5.1 illustrates how RCF and URA interact with each other using URAI.




Figure 5.1: Interconnection between RCF and URA using URAI for Reconfigurable MD

As shown in figure 5.1, URAI supports 3 kinds of services:

• Radio Application Management Services

These services are used by Radio Connection Manager (RCM) which is included in the RCF, to control URA functions such as reporting of discovered Peer Equipments, creating/terminating association with Peer Equipment, starting/stopping communication with Peer Equipment, etc.

• User Data Flow Services

These services are used by Flow Controller (FC) which is included in the RCF, to transmit user data to URA, or used by URA to transmit received user data to FC. These services also include management of data flow, which is provided by FC.

• Multiradio Control Services

These services are used by Multiradio Controller (MRC) which is included in RCF, to manage spectral resource usage.

The RCF and URA are defined in ETSI EN 303 095 [i.2].

5.2 URAI System Requirement Mapping

The Radio Computer components above described shall support the URAI system requirements shown in table 5.1 and described in clause 6 of ETSI EN 302 969 [1].

Table 5.1: Mapping of Radio Computer Components to the system requirements described in ETSI EN 302 969 [1]

Entity/Component/Unit	System Requirements [1]	Comments
Flow Controller	R-FUNC-RAT-05	If a reconfigurable MD allows parallel connections
		to RATs (in alignment to R-FUNC-RAT-01), various independent data flows should be
		maintained simultaneously. The requirement is
		described in clause 6.1.5 of ETSI EN 302 969 [1].
	R-FUNC-RA-04	Radio Applications should support the function of
		transferring receive (Rx)/transmit (Tx) data
		to/from the networking stack. The requirement is
Multiradio Controller	R-FUNC-RAT-01	described in clause 6.2.4 of ETSI EN 302 969 [1]. A reconfigurable MD should support parallel
Ividitiradio Controller	IN-1 ONG-RAT-01	connections to more than one Radio Access
		Technology. The requirement is described in
		clause 6.1.1 of ETSI EN 302 969 [1].
	R-FUNC-RAT-02	If a reconfigurable MD allows parallel connections
		to RATs, (in alignment to R-FUNC-RAT-01), in-device coexistence functionalities shall be
		implemented. The requirement is described in
		clause 6.1.2 of ETSI EN 302 969 [1].
	R-FUNC-RAT-03	If a reconfigurable MD allows parallel connections
		to RATs (in alignment to R-FUNC-RAT-01),
		seamless handover of data streams from one RAT to another RAT should be implemented. The
		requirement is described in clause 6.1.3 of ETSI
		EN 302 969 [1].
	R-FUNC-RAT-06	If a reconfigurable MD allows parallel connections
		to RATs (in alignment to R-FUNC-RAT-01), Link
		Adaptation techniques across multiple RATs should be implemented. The requirement is
		described in clause 6.1.6 of ETSI EN 302 969 [1].
	R-FUNC-MDR-03	The radio configuration of a reconfigurable MD
		shall be realized with the activation of Radio
		Applications (RA) and, if necessary, changing
		parameters of the activated RAs. The requirement is described in clause 6.4.3 of ETSI
		EN 302 969 [1].
Radio Connection Manager	R-FUNC-RAT-04	If policies are applied to a reconfigurable MD, the
		link selection functionality in the reconfigurable
		MD shall meet the related conditions. The requirement is described in clause 6.1.4 of ETSI
		EN 302 969 [1].
	R-FUNC-RAT-05	If a reconfigurable MD allows parallel connections
		to RATs (in alignment to R-FUNC-RAT-01),
		various independent data flows should be
		maintained simultaneously. The requirement is described in clause 6.1.5 of ETSI EN 302 969 [1].
	R-FUNC-RAT-06	If a reconfigurable MD allows parallel connections
		to RATs (in alignment to R-FUNC-RAT-01), Link
		Adaptation techniques across multiple RATs
		should be implemented. The requirement is described in clause 6.1.6 of ETSI EN 302 969 [1].
	R-FUNC-RA-03	Reconfigurable MDs should support concurrent
	11.010.10100	execution of Radio Applications. The requirement
		is described in clause 6.2.3 of ETSI
	D. FLINIO MDF. 33	EN 302 969 [1].
	R-FUNC-MDR-03	The radio configuration of a reconfigurable MD shall be realized with the activation of Radio
		Applications (RA) and, if necessary, changing
		parameters of the activated RAs. The
		requirement is described in clause 6.4.3 of ETSI
		EN 302 969 [1].

6 Notational Tools

6.1 Notational Tool for Information Model Classes

Table 6.1 shows a template for defining information model classes [i.6]. Each information model class is defined in clause 7.2 in accordance with the template shown in table 6.1.

NOTE: ASN.1 is used throughout the present document for abstract type definitions; however, alternative ways are possible and are not excluded.

Table 6.1: Template for defining Information Model Classes

Class <class name="">[(abstract class)]</class>			
<description class<="" of="" td="" the=""><td>SS></td><td></td><td></td></description>	SS>		
DERIVED FROM	<list of="" super-classes=""></list>		
ATTRIBUTES			
<attribute name=""> [<optional>]</optional></attribute>	Value type: <attribute type="" value=""></attribute>	Possible access: <attribute access="" qualifier=""></attribute>	Default value: <default value=""></default>
<description attri<="" of="" td="" the=""><td>ibute></td><td></td><td></td></description>	ibute>		
CONTAINED IN Classes, whose instances may contain an instance of this class. If this class is an abstract class, that is, it is used for further refinement only and will never be instantiated, then this list is empty.>			
<list an="" are:<="" be="" class.="" classes,="" constraints="" contained="" in="" instance="" instances="" may="" of="" p="" this="" used="" whose=""> [*] - zero or more instances, [+] - one or more instances, [<n>] - exactly n instances,</n> [<m>] - not less than m and not more than n instances.></m> </list>			
SUPPORTED List of event names that are detected by this class and lead potentially to a corresponding event report.>			

Further details on the template in table 6.1 are given below.

- <Class name> is the name of the Class as it appears in the corresponding model. Additional information is also included in case the class in question has been specified as an abstract one.
- DERIVED FROM field identifies the super class of the class in case of sub-classing.
- ATTRIBUTES field describes the attributes that have been defined in the class. More specifically:
 - <Attribute name> identifies the name of an attribute, as it is included in the class definition.
 - <Attribute value type> holds the type of the attribute specified in Abstract Syntax Notation One (ASN.1). Details related to the ASN.1 module are specified in annex A.
 - <Attribute access qualifier> provides information about the level of accessibility of the attribute. This may include: 'Read', 'Write', 'Read-Write', 'Add-Remove' (for list-type attributes), 'Read-Add-Remove', and 'None' (for internal access only).
- CONTAINED IN field includes a list of classes whose instances may contain an instance of this class; containment is a strong aggregation relationship, that is, a contained instance is for its lifetime bound to its container object and it is contained only in this one container.
- CONTAINS field provides a list of classes whose instances may be contained in an instance of the class in question.
- SUPPORTED EVENTS field includes a list of event names that are detected by this class and lead potentially to a corresponding event report.

6.2 Notational Tool for Interface Classes

Table 6.2 shows a template for defining interface classes for URAI. Each interface class for URAI will be defined in clause 8.5 in accordance with the template shown in table 6.2.

Table 6.2: Template for defining Interface Classes

Class <class name="">[(abstract class</class>)]	
<description class="" of="" the=""></description>		
OPERATIONS		
<operation name=""></operation>	Return type: <operation return="" type=""></operation>	Value type: <operation type="" value=""></operation>
<description of="" operation="" the=""></description>		

The template fields in table 6.2 are described below.

- <Class name> is the name of the Class as it appears in the corresponding model. Additional information is also included in case the class in question has been specified as an abstract one.
- OPERATIONS field describes the operations that have been defined in the class. More specifically:
 - < Operation name > identifies the name of an operation, as it is included in the class definition.
 - <Return type> identifies the type of return value at the corresponding operation. Details related to the ASN.1 module are specified in annex B.
 - <Value type> identifies the access levels for member functions: public, private, protected.

7 Information Model for Radio Computer

7.1 Radio Computer

Figure 7.1 shows the UML class diagram for Radio Computer classes related to URAI which are required to support Software Reconfiguration.




Figure 7.1: UML class diagram for Radio Computer classes related to URAI

The Radio Computer classes related to URAI are defined as follows:

RadioComputer

This class contains all URA(s) related information about resources and interactions related to hardware and software of a reconfigurable MD, for example, computational/spectral resource usage, collection of context information, channel measurement results, etc.

RadioOS

This class describes an installed Radio OS. Each instance of a RadioComputer class can relate to zero or one instance of RadioOS class (0,1). Each instance of RadioOS class is associated with zero or several instances of RadioApp class (0..*).

RadioApp

This class describes one currently active Radio Application. Each instance of a RadioComputer class can relate to zero or several instances of RadioApp class (0..*). Each instance of RadioApp class is associated with one instance of RadioOS class. Each instance of RadioApp class is associated with zero, one or many instances of Link class.

• RadioAppProfile

This class contains general information about the Radio Application, for example, Radio Application ID, current version of Radio Application, direction (downlink or uplink), links used to deliver this Radio Application, etc. Each instance of a Radio App class can have only one instance of Radio AppProfile class as a member.

RadioAppCapabilities

This class contains information about measurements supported by this Radio Application, for example, delay, loss, and bandwidth measurements. Each instance of a RadioApp class can have only one instance of RadioAppCapabilities class as a member.

• RadioAppMeasurements

This class contains measurements performed by this Radio Application, for example, delay, loss, and bandwidth measurements. Each instance of a RadioApp class can have only one instance of RadioAppMeasurements class as a member. Multiple measurements are contained within the instance of the class.

RCProfile

This class contains general information about the Radio Computer, for example, terminal Identification (ID). Each instance of a "RadioComputer" class can have only one instance of RCProfile class as a member.

RCMeasurements

This class contains current measurements (instantaneous measurement data and related metadata) related to Reconfigurable MD such as battery capacity, user mobility, MD location determination, and connection history information. Each instance of RadioComputer class shall have only one instance of RCMeasurements class as a member.

RCCapabilities

This class contains information about Radio Computer capabilities including hardware, software, transmission and measurement capabilities such as supported RATs and maximum transmission power. Each instance of RadioComputer class shall have only one instance of RCCapabilities class as a member.

Channel

This class contains one radio channel that may or may not be used by an active radio link. Each instance of RadioComputer class can have zero, one or several instances of Channel class as members (0..*). In case of an active radio link, at least one Channel class is available.

• ChannelProfile

This class contains general information about the radio channel such as channel ID, centre frequency, bandwidth, and used RAT. Each instance of Channel class shall have only one instance of Channel Profile class as a member.

• ChannelMeasurements

This class contains current measurements (instantaneous measurement data and related metadata) and the applied measurement configuration related to this radio channel such as interference and load measurements. Each instance of Channel class shall have only one instance of ChannelMeasurements class as a member.

Antenna

This class contains information about antenna selection. Each instance of Channel class shall have at least one instance of Antenna class as a member. (1..*).

AntennaProfile

This class contains general information about this antenna, such as antenna port, applicable frequency range and antenna gain. Each instance of Antenna class shall have only one instance of AntennaProfile class as a member.

• RCConfiguration

This class contains information about the current configuration of Radio Computer. Each instance of RadioComputer class shall have only one instance of RCConfiguration class as a member.

Link

This class contains information about one active URA and the corresponding connection between the Reconfigurable MD and the Radio Access Network (RAN). Each instance of RCConfiguration class has zero, one or several instances of Link class as members (0..*). Each instance of Link class is associated with one instance of RadioApp class.

LinkProfile

This class contains general information about this active connection, for example, link Identification (ID), serving cell ID, channel used, etc. Each instance of Link class shall have only one instance of LinkProfile class as a member.

LinkMeasurements

This class contains current measurements (instantaneous measurement data and related metadata) related to this active connection, such as Block Error Rate (BLER), power, and Signal to Interference plus Noise Ratio (SINR) measurements. Each instance of Link class shall have only one instance of LinkMeasurements class as a member.

• RFConfiguration

This class contains information about the configuration of the RF transceiver. Each instance of Link class shall have only one instance of RFConfiguration class as a member.

• TxPath

This class contains information about one transmit path. Each instance of RFConfiguration class has zero or one instance of TxPath class as a member (0,1).

RxPath

This class contains information about one receive path. Each instance of RFConfiguration class shall have only one instance of RxPath class as a member.

NOTE: The Channel Class is separate from the Link Class, but the Channel Measurements may be based on any MD configuration which may or may not be used for the final Link Configuration.

7.2 Class Definitions for Information Model

Each class of Radio Computer can be defined using the template presented in clause 6.1 and in accordance with the UML diagram of figure 7.1 which specifies the relations among all the classes of Radio Computer. Radio Computer classes defined in this way are shown in tables 7.1 to 7.21.

Table 7.1: RadioComputer Class

Class RadioComputer				
This class contains all URA	This class contains all URA related information about resources and interactions related to hardware			
and software of a reconfigurable MD.				
DERIVED FROM				
ATTRIBUTES				
CONTAINED IN				
CONTAINS RCCapabilities [1], RCConfiguration [1], RCMeasurements [1],				
Channel [*], RCProfile [1], RadioAPP [*], RadioOS [0-1]				
SUPPORTED EVENTS				

Table 7.2: RadioOS Class

Class RadioOS			
This class describes ins	talled Radio OS.		
DERIVED FROM			
ATTRIBUTES			
rOSID	Value type:	Possible access:	Default value:
10210	NameType	Read	Not specified
This attribute describes ID of Radio OS.			
-00)/	Value type:	Possible access:	Default value:
rOSVersion	Version	Read	Not specified
This attribute describes a version of Radio OS.			
CONTAINED IN	RadioComputer		
CONTAINS			
SUPPORTED EVENTS			

Table 7.3: RadioApp Class

Class RadioApp			
This class describes install	ed Radio Application.		
DERIVED FROM			
ATTRIBUTES	ATTRIBUTES		
This attribute contains a list of supported options.			
CONTAINED IN	RadioComputer		
CONTAINS RadioAppProfile [1], RadioAppCapabilities [1],			
RadioAppMeasurements [1]			
SUPPORTED EVENTS			

Table 7.4: RadioAppProfile Class

Class RadioAppProfile			
This class contains gener	al information about the	Radio Application.	
DERIVED FROM			
ATTRIBUTES	<u>.</u>		
Dedie Ann ID	Value type:	Possible access:	Default value:
RadioAppID	NameType	Read	Not specified
This attribute describes ID		lication.	
DAV/araiar	Value type:	Possible access:	Default value:
RAVersion	Version	Read	Not specified
This attribute describes a	version of Radio Applic	ation.	
din	Value type:	Possible access:	Default value:
direction	Direction	Read	Not specified
This attribute describes w	hether this Radio Appli	cation is downlink or uplin	k application or both.
	Value type:	Possible access:	Default value:
listOfSupportedOptions	RAOptionsList	Read	Not specified
This attribute contains a li versus mandatory feature		(i.e. optional features as	defined in related standard
listOfAssociatedLinks	Value type:	Possible access:	Default value:
IISTOTASSOCIATEGETINKS	Links	Read	Not specified
This attribute describes list of IDs of links used to transmit user data.			
CONTAINED IN	RadioApp		
CONTAINS			
SUPPORTED EVENTS			

Table 7.5: RadioAppCapabilities Class

Class RadioAppCapabilities				
This class contains informati	on about measurements suppor	rted by this Radio Ap	plication.	
DERIVED FROM	DERIVED FROM			
ATTRIBUTES				
listOfSupportedApplication	Value type:	Possible access:	Default value:	
Capabilities	ApplicationMeasurementsIds	Read	Not specified	
This attribute describes capa	abilities supported by this Radio	Application.		
CONTAINED IN RadioApp				
CONTAINS	ONTAINS			
SUPPORTED EVENTS				

Table 7.6: RadioAppMeasurements Class

Class RadioAppMeasur	Class RadioAppMeasurements				
This class contains meas	surements performed by this Rad	dio Application.			
DERIVED FROM					
ATTRIBUTES					
listOfActiveApplication	Value type:	Possible access:	Default value:		
Measurements	ApplicationMeasurements	Read-Add-Remove	Not specified		
This attribute describes i	neasurements that are currently	performed by the Ra	dio Application.		
requestOfContextInfor	Value type:	Possible access:	Default value:		
mations	ContextInformationInfo	Read	Not specified		
This attribute describes of	This attribute describes context information that are requested by other entity such as Monitor. There				
can be a request for one-time delivery, a request for cyclic delivery or request for conditional delivery.					
CONTAINED IN	RadioApp				
CONTAINS					
SUPPORTED EVENTS					

Table 7.7: RCProfile Class

Class RCProfile			
This class contains genera	I information about the	Radio Computer.	
DERIVED FROM			
ATTRIBUTES			
RCID	Value type:	Possible access:	Default value:
RCID	NameType	Read	Not specified
This attribute describes ID	of radio computer.		
CONTAINED IN	RadioComputer		
CONTAINS		_	
SUPPORTED EVENTS			

Table 7.8: RCMeasurements Class

Class RCMeasurements			
This class contains current m	easurements related to Re	configurable Radio terr	ninal.
DERIVED FROM			
ATTRIBUTES			
listOfActiveMeasurements	Value type:	Possible access:	Default value:
listoractivelyleasurements	ActiveMeasurementsList	Read-Add-Remove	Not specified
This attribute describes a list	of active measurements.		
CONTAINED IN	RadioComputer		
ONTAINS			
SUPPORTED EVENTS			

Table 7.9: RCCapabilities Class

Class RCCapabilities					
This class contains information abo	ut Radio Computer capabilitie	es including hardware,	software,		
transmission and measurement cap	pabilities.				
DERIVED FROM					
ATTRIBUTES					
listOfSupportedOptions	Value type:	Possible access:	Default value:		
listOfSupportedOptions	RCOptionsList	Read-Write	Not specified		
This attribute describes a list of sup	ported options.				
listOfSupportedPadiaInterfaces	Value type:	Possible access:	Default value:		
listOfSupportedRadioInterfaces	RadioInterfacesList	Read-Write	Not specified		
This attribute describes radio interfa	aces supported by this Radio	Computer.			
listOfSupportedChannels	Value type:	Possible access:	Default value:		
listOfSupportedChannels	ChannellDsList	Read-Write	Not specified		
This attributes describes frequency	channels supported by this F	Radio Computer.			
hardwareProfile	Value type:	Possible access:	Default value:		
naidwareFronie	HardwareInfo	Read-Write	Not specified		
This attributes describes hardware	capabilities of this Radio Con	nputer.			
softwareProfile	Value type:	Possible access:	Default value:		
SoftwareInfo Read-Write Not specified					
This attributes describes software capabilities of this Radio Computer.					
CONTAINED IN	RadioComputer				
CONTAINS					
SUPPORTED EVENTS					

Table 7.10: Channel Class

Class Channel	
This class describes one fre	equency channel that may or may not have active connections on it.
DERIVED FROM	
ATTRIBUTES	
CONTAINED IN	RadioComputer
CONTAINS	ChannelProfile [1], ChannelMeasurements [1], Antenna [+]
SUPPORTED EVENTS	

Table 7.11: ChannelProfile Class

Class ChannelProfile			
This class contains genera	I information about this	frequency channel.	
DERIVED FROM		· ·	
ATTRIBUTES			
channelID	Value type:	Possible access:	Default value:
Charmend	NameType	Read	Not specified
This attribute describes ID	of channel.		
channelFrequencyRange	Value type:	Possible access:	Default value:
	FrequencyRange	Read	Not specified
This attribute describes a v	alue of channel freque	ncy range.	
radioInterface	Value type:	Possible access:	Default value:
radiomienace	RadioInterface	Read	Not specified
This attribute describes a r	adio interface.		
cellID	Value type:	Possible access:	Default value:
CelliD	NameType	Read	Not specified
This attribute describes ID	of connected cell.		
CONTAINED IN	Channel		
CONTAINS			
SUPPORTED EVENTS		<u> </u>	

Table 7.12: ChannelMeasurements Class

Class ChannelMeasurement	S		
This class contains current me	easurements related to this fr	equency channel.	
DERIVED FROM			
ATTRIBUTES			
listOfChannelMeasurements	Value type: ChannelMeasurementsList	Possible access: Read	Default value: Not specified
This attribute describes a list of	of channel measurements.		
appliedMeasurementsConfi guration	Value type: ConfigurationMeasuremen ts	Possible access: Read	Default value: Not specified
This attribute describes config	uration option of the MD, e.g	. which Antenna(s) have	been used, which
RF front-end(s) have been use	ed, etc.		
CONTAINED IN	Channel		·
CONTAINS			
SUPPORTED EVENTS		·	·

Table 7.13: Antenna Class

Class Antenna		
This class contains information	n about antenna selection.	
DERIVED FROM		
ATTRIBUTES		
CONTAINED IN	Channel	
CONTAINS	AntennaProfile [1]	
SUPPORTED EVENTS		

Table 7.14: AntennaProfile Class

Class AntennaProfile	Class Antenna Profile				
This class contains genera	I information about t	this antenna.			
DERIVED FROM					
ATTRIBUTES					
antennalD	Value type:	Possible access:	Default value:		
antennaid	NameType	Read	Not specified		
This attribute describes II	This attribute describes ID of antenna.				
CONTAINED IN	Antenna				
CONTAINS					
SUPPORTED EVENTS					

Table 7.15: RCConfiguration Class

Class RCConfiguration	Class RCConfiguration		
This class contains informa	tion about the current configuration of Radio Computer.		
DERIVED FROM			
ATTRIBUTES			
CONTAINED IN	RadioComputer		
CONTAINS	Link [*]		
SUPPORTED EVENTS			

Table 7.16: Link Class

Class Link			
This class contains informa	tion about one active Radio Application and corresponding connection		
between Reconfigurable Ra	adio terminal and RANs.		
DERIVED FROM			
ATTRIBUTES	ATTRIBUTES		
CONTAINED IN	RCConfiguration		
CONTAINS	LinkProfile [1], LinkMeasurements [1], RFConfiguration [1]		
SUPPORTED EVENTS			

Table 7.17: LinkProfile Class

ATTRIBUTES IlinkID Value type: Read Read Not specified This attribute describes ID of link about activated connection. Value type: Possible access: Default value: Not specified	Class LinkProfile			
ATTRIBUTES IlinkID Value type: Read Read Not specified This attribute describes ID of link about activated connection. Value type: Possible access: Default value: Not specified	This class contains gene	eral information about this a	active connection.	
linkID Value type: NameType Read Not specified This attribute describes ID of link about activated connection. cellID Value type: Possible access: Default value: Not specified This attribute describes ID connected cell. associatedChannelID Value type: OptionalObjectName Possible access: Default value: Not specified This attribute describes ID of associated channel. IinkDirection Value type: OptionalObjectName Possible access: Default value: Not specified This attribute describes a direction of link. carrierFrequency Value type: Possible access: Default value: Not specified This attribute describes a value of carrier frequency. Institute describes a value of nominal power. Institute describes a value of nominal power. Institute describes a value of sampling rate. Institute describes a value of sampling rate. Institute describes a value of sampling rate. Institute describes a value of bandwidth Institu	DERIVED FROM			
NameType Read Not specified	ATTRIBUTES			
NameType Read Not specified	linkID	Value type:	Possible access:	Default value:
Value type: NameType Read-Write Not specified	IIIIKID	NameType	Read	Not specified
This attribute describes ID connected cell. associatedChannelID This attribute describes ID of associated channel. InkDirection This attribute describes a direction of link. CarrierFrequency This attribute describes a value of nominal power. SamplingRate This attribute describes a value of sampling rate. Bandwidth Value type: Possible access: Read-Write Possible access: Default value: Not specified Not specified Possible access: Default value: Not specified Not specified Possible access: Default value: Not specified Possible access: Read-Write Not specified Possible access: Default value: Not specified	This attribute describes I	D of link about activated co	onnection.	
This attribute describes ID connected cell. associatedChannelID	as IIID	Value type:	Possible access:	Default value:
AssociatedChannelID Value type: OptionalObjectName Read-Add-Remove Not specified	CelliD	NameType	Read-Write	Not specified
Associated Channell D Optional Object Name Read-Add-Remove Not specified This attribute describes ID of associated channel. Ilink Direction Value type: Possible access: Read Not specified This attribute describes a direction of link. Carrier Frequency Value type: Possible access: Default value: Not specified This attribute describes a value of carrier frequency. Inominal RFPower Value type: Possible access: Default value: Not specified This attribute describes a value of nominal power. Sampling Rate Value type: Possible access: Default value: Not specified This attribute describes a value of nominal power. Sampling Rate Read-Write Not specified This attribute describes a value of sampling rate. Bandwidth Value type: Possible access: Default value: Not specified This attribute describes a value of sampling rate. Bandwidth Read-Write Not specified This attribute describes a value of bandwidth. CONTAINED IN Link CONTAINS	This attribute describes I	D connected cell.		
This attribute describes ID of associated channel. Value type: Direction Value type: Direction Default value: Not specified Not speci	anna siata dChannallD	Value type:	Possible access:	Default value:
IlinkDirection	associatedChanneliD	OptionalObjectName	Read-Add-Remove	Not specified
This attribute describes a direction of link. CarrierFrequency Value type: FrequencyRange Read-Write This attribute describes a value of carrier frequency. Not specified This attribute describes a value of carrier frequency. Not specified This attribute describes a value of nominal power. SamplingRate This attribute describes a value of sampling rate. Bandwidth Value type: Sampling Rate Value type: Sampling Rate Value type: Sampling Rate Value type: Sampling Rate Not specified This attribute describes a value of sampling rate. Possible access: Read-Write Not specified This attribute describes a value of sampling rate. Bandwidth Read-Write Not specified This attribute describes a value of bandwidth. CONTAINED IN Link CONTAINS	This attribute describes I	D of associated channel.		
This attribute describes a direction of link. carrierFrequency This attribute describes a value of carrier frequency. InominalRFPower SamplingRate This attribute describes a value of sampling rate. Bandwidth This attribute describes a value of bandwidth. CONTAINED IN Link CONTAINS Value type: Possible access: Default value: Not specified Not specified Not specified Not specified Not spe	link Direction	Value type:	Possible access:	Default value:
CarrierFrequency Value type: FrequencyRange Read-Write Not specified	linkbirection	Direction	Read	Not specified
CarrierFrequency FrequencyRange Read-Write Not specified This attribute describes a value of carrier frequency. NominalRFPower Read Default value: AnaloguePower Read Not specified This attribute describes a value of nominal power. Value type: Possible access: Default value: SamplingRate Read-Write Not specified This attribute describes a value of sampling rate. Bandwidth Read-Write Not specified This attribute describes a value of bandwidth. CONTAINED IN Link CONTAINS	This attribute describes a	a direction of link.		
This attribute describes a value of carrier frequency. Not specified This attribute describes a value of carrier frequency. Not specified This attribute describes a value of nominal power. SamplingRate Value type: SamplingRate Value type: SamplingRate Possible access: Read Not specified Possible access: Read-Write Not specified This attribute describes a value of sampling rate. Bandwidth Value type: Bandwidth Possible access: Read-Write Not specified Not specified This attribute describes a value of bandwidth. CONTAINED IN Link CONTAINS	oorrior=roguenav	Value type:	Possible access:	Default value:
Not specified This attribute describes a value of nominal power. SamplingRate This attribute describes a value of sampling rate. Bandwidth This attribute describes a value of sampling rate. Bandwidth This attribute describes a value of bandwidth. CONTAINED IN Link Possible access: Read Not specified Possible access: Read-Write Possible access: Read-Write Not specified Not specified Not specified	carrierriequericy	FrequencyRange	Read-Write	Not specified
This attribute describes a value of nominal power. SamplingRate This attribute describes a value of nominal power. SamplingRate This attribute describes a value of sampling rate. Bandwidth This attribute describes a value of sampling rate. Bandwidth This attribute describes a value of bandwidth. CONTAINED IN Link CONTAINS Not specified	This attribute describes a	a value of carrier frequency	/.	
This attribute describes a value of nominal power. samplingRate Value type: SamplingRate Possible access: Read-Write Not specified This attribute describes a value of bandwidth CONTAINED IN Link CONTAINS	nominal DEDougr	Value type:	Possible access:	Default value:
samplingRate Value type: SamplingRate Read-Write Read-Write Not specified This attribute describes a value of sampling rate. Bandwidth Bandwidth This attribute describes a value of bandwidth. CONTAINED IN Link CONTAINS	nominaiRFPowei	AnaloguePower	Read	Not specified
SamplingRate SamplingRate Read-Write Not specified This attribute describes a value of sampling rate. Bandwidth Possible access: Default value: Bandwidth Read-Write Not specified This attribute describes a value of bandwidth. CONTAINED IN Link CONTAINS	This attribute describes a	a value of nominal power.		
This attribute describes a value of sampling rate. Bandwidth Bandwidth CONTAINED IN CONTAINS Sampling Rate Read-Write Not specified	sampling Pata	Value type:	Possible access:	Default value:
Bandwidth Value type: Bandwidth Read-Write This attribute describes a value of bandwidth. CONTAINED IN Link CONTAINS	SamplingRate	SamplingRate	Read-Write	Not specified
Bandwidth Read-Write Not specified This attribute describes a value of bandwidth. CONTAINED IN Link CONTAINS	This attribute describes a	a value of sampling rate.		· · · ·
This attribute describes a value of bandwidth. CONTAINED IN Link CONTAINS	Donalis dalah	Value type:	Possible access:	Default value:
CONTAINED IN Link CONTAINS	Bandwidth	Bandwidth	Read-Write	Not specified
CONTAINS	This attribute describes a	a value of bandwidth.		
	CONTAINED IN	Link		
SUPPORTED EVENTS	CONTAINS			
	SUPPORTED EVENTS			

Table 7.18: LinkMeasurements Class

Class LinkMeasurements	5		
This class contains curren	t measurements related to	this active connection.	
DERIVED FROM			
ATTRIBUTES	•		
receiveBLER	Value type:	Possible access:	Default value:
receivedLER	RxBLER	Read-Write	Not specified
This attribute describes a	value of BLER for received	d data.	
transmitPower	Value type:	Possible access:	Default value:
transmitrower	TxPower	Read-Write	Not specified
This attribute describes a	power of transmit signal.		
receiveSINR	Value type:	Possible access:	Default value:
receivesiink	RxSINR	Read-Write	Not specified
This attribute describes a	This attribute describes a value of SINR for received data.		
transmittedBits	Value type:	Possible access:	Default value:
transmittedbits	TxBits	Read-Write	Not specified
This attribute describes tra	ansmitted bits.		
CONTAINED IN	Link		
CONTAINS	·		·
SUPPORTED EVENTS			

Table 7.19: RFConfiguration Class

Class RFConfiguration		
This class contains information about the configuration of RF transceiver.		
DERIVED FROM		
ATTRIBUTES		
CONTAINED IN	Link	
CONTAINS	TxPath [0-1], RxPath [1]	
SUPPORTED EVENTS		

Table 7.20: TxPath Class

Class TxPath			
This class describes on	e transmit path.		
DERIVED FROM	DERIVED FROM		
ATTRIBUTES			
txStartTime	Value type: TxStartTime	Possible access: Read-Write	Default value: Not specified
This attribute defines th	e time when the transce	eiver start transmission.	
txStopTime	Value type: TxStopTime	Possible access: Read-Write	Default value: Not specified
This attribute defines th	e time when the transce	eiver stop transmission.	
CONTAINED IN	RFConfiguration	•	
CONTAINS			
SUPPORTED EVENTS			

Table 7.21: RxPath Class

Class RxPath				
This class describes one re	This class describes one receive path.			
DERIVED FROM	DERIVED FROM			
ATTRIBUTES				
rxStartTime	Value type:	Possible access:	Default value:	
1x3tart rime	RxStartTime	Read-Write	Not specified	
This attribute defines the tir	ne when the transceiver s	start reception.		
rxStopTime	Value type:	Possible access:	Default value:	
1x3top fille	RxStopTime	Read-Write	Not specified	
This attribute defines the time when the transceiver stop reception.				
CONTAINED IN	RFConfiguration			
CONTAINS				
SUPPORTED EVENTS				

8 Interface Definition

8.1 Interface Overview

Figure 8.1 illustrates a UML diagram for URAI. URAI supports 3 basic services (i.e. Radio Application Management Services, User Data Flow Services, and Multiradio Control Services) which are further detailed in clauses 8.2, 8.3 and 8.4 respectively.




Figure 8.1: UML diagram for URAI

8.2 Radio Application Management Services

8.2.1 Overview on Radio Application Management Services

Table 8.1 describes an overview on Radio Application Management Services which are associated with RCM. Class definition and related operations are described in clause 8.5.

Table 8.1: Overview on Radio Application Management Services

Radio Application Management Services	Explanation
Equipments.	URA reports RCM about the accessible peer equipment(s) found during the procedure of the discovery process. In the case when the reconfigurable MD is requested to be a peer equipment by another MD, the requesting MD shall be included as an accessible peer equipment too.
Equipment.	RCM requests URA to create/terminate association with an accessible peer equipment.
	Among the activated and associated URAs, RCM requests some selected URAs to perform actual transmission/reception of user data.

8.2.2 Messages for Radio Application Management Services

The interfaces for Radio Application Management Services are used to transmit the following messages:

- From RCF to URA:
 - Request of report discovered Peer Equipments.
 - Request of create/terminate association with Peer Equipment.
 - Request of start and stop communication with Peer Equipment.
- From URA to RCF:
 - Confirmation of association creation.
 - Confirmation of association termination.
 - Confirmation of start communication with Peer Equipment.
 - Confirmation of stop communication with Peer Equipment.
 - Failure of association creation.
 - Failure of association termination.
 - Failure of start communication with Peer Equipment.
 - Failure of stop communication with Peer Equipment.
 - Information about discovered Peer Equipments.

8.3 User Data Flow Services

8.3.1 Overview on User Data Flow Services

Table 8.2 describes an overview on User Data Flow Services which are associated with FC. Class definition and related operations are described in clause 8.5.

Table 8.2: Overview on User Data Flow Services

Radio Application Management Services	Explanation
Send user data. The transmit	
user data are received by the	
FC and then transferred to the	
URA based on those	In sending or receiving user data, there might be some conflicts in data flow between
information. Receive user	sender and receiver. URA requests FC to change the configuration of data flow.
dataURA indicates transfer of	
the received user data to	
FC.Data flow control.	

8.3.2 Messages for User Data Flow Services

The interfaces for User Data Flow Services are used to transmit the following messages:

- From RCF to URA:
 - Request of user data transfer.
- From URA to RCF:
 - Request for changing of data flow configuration.
 - Information related to URA.
 - Confirmation of user data transfer.
 - Failure of user data transfer.
 - Information about user data.

8.4 Multiradio Control Services

8.4.1 Overview on Multiradio Control Services

Table 8.3 describes an overview on Multiradio Control Services which are associated with MRC. Class definition and related operations are described in clause 8.5.

Table 8.3: Overview on Multiradio Control Services

Multiradio Control Services	Explanation	
Synchronize Radio Time	MRC request all the active URAs to operate with a unified synchronism.	

8.4.2 Messages for Multiradio Control Services

The interfaces for Multiradio Control Services are used to transmit the following messages:

- From RCF to URA:
 - Request of synchronize radio time.
- From URA to RCF:
 - Confirmation of synchronize radio time.
 - Failure of synchronize radio time.

8.5 Class Definitions for Interface

Each interface class related to URAI can be defined using the template presented in clause 6.2 and in accordance with the UML diagram of figure 8.1 which specifies the interface classes related to URAI. Tables 8.1 to 8.3 specify all the operations related to the three interface classes above described.

Table 8.4: RadioApplicationManagementServices Class

Class RadioApplicationManagementServices		
This class describes interfaces supporting Radio Applicat	ion Management Services.	
OPERATIONS		
reprotPeerEquipment	Return type:	Value type:
Teproti eerequipment	PeerEquipmentList	public
This operation is needed for getting the list of discovered	Peer Equipments.	
createNetAssociation	Return type:	Value type:
	INTEGER	public
This operation is needed for creating an association with		
 terminateNetAssociation	Return type:	Value type:
terminatervetAssociation	BOOLEAN	public
This operation is needed for terminating an association.		
startTransmission	Return type:	Value type:
Start ransmission	BOOLEAN	public
This operation is needed for starting user data transmissi	on with Peer Equipment.	
stopTransmission	Return type:	Value type:
Stop (Tarismission	BOOLEAN	public
This operation is needed for stopping user data transmiss	sion with Peer Equipment.	
etertPecenties	Return type:	Value type:
startReception	BOOLEAN	public
This operation is needed for starting user data reception.		
etan Pacantian	Return type:	Value type:
stopReception	BOOLEAN	public
This operation is needed for stopping user data reception		

Table 8.5: UserDataFlowServices Class

Class UserDataFlowServices		
This class describes interfaces supporting User data	Flow Services.	
OPERATIONS		
requestChangeofDataflow	Return type: BOOLEAN	Value type: public
This operation is needed for requesting change of dat	a flow.	
sendtoURA	Return type: UserData	Value type: public
This operation is needed for sending user data to URA	۹.	
receivefromURA	Return type: UserData	Value type: public
This operation is needed for receiving user data from	URA.	

Table 8.6: MultiradioControlServices Class

Class MultiradioControlServices		
This class describes interfaces supporting	Multiradio Control Services.	
OPERATIONS		
syncRadioTime	Return type: BOOLEAN	Value type: public
This operation is needed for synchronizin	g radio time.	

Annex A (informative): Abstract Data Definitions

The following ASN.1 in Recommendation ITU-T X.680 [i.7] module contains all necessary abstract data definitions used in the attribute definitions in clause 7.2 and clause 8.5.

```
ETSI-TS-103-146-3-Type-Definitions DEFINITIONS ::= BEGIN
             -- START Common Data Types
            -- START Name Related Data Types
            NameType ::= CHOICE
                    number INTEGER, string PrintableString
            }
            ObjectName
                           ::= SEQUENCE OF NameType
            OptionalObjectName
                                    ::= CHOICE {
                          ObjectName,
                     id
                     void
                                 NULL
            ObjectNameList ::= SEQUENCE OF ObjectName
             -- END Name Related Data Types
             -- START Version Related Data Types
                       ::= CHOICE {
            Version
                intVersion INTEGER, stringVersion PrintableString
            -- END Version Related Data Types
             -- END Common Data Types
             -- START Radio Application Related Data Types
            RAOptionID
                          ::= ENUMERATED
                 lte5Mhz,lte10Mhz, lte20Mhz, ...
                ptionsList ::= SEQUENCE OF SEQUENCE rAOptionName RAOptionTo
            RAOptionsList
                rAOptionValue SEQUENCE OF RAOptionID,
                                 ::= ENUMERATED
            RAMeasurementsID
                 observedDelay, observedDelayVariation, observedPacketLoss,
                 observedBandwidth, ...
            ApplicationMeasurements ::= SEQUENCE OF SEQUENCE rAMeasurementsName RAMeasurementsID,
                rAMeasurementsValue
                                         ANY
            }
```

```
ContextInformationID
                     ::= ENUMERATED {
    BER, SNR, SINR, Output Power Levels, estimates of propagation delay, estimates of
    link attenuation, ...
ContextInformationList ::= SEQUENCE OF SEQUENCE
   contextInformationName ContextInformationID,
   contextInformationValue
}
SendingDuration ::= ENUMERATED {
   0,10ms,20ms, ...
                   ::= CHOICE {
SendingCondition
   None, condition1, condition2, ...
\verb| ContextInformationInfo | ::= SEQUENCE | OF SEQUENCE | |
   cIIInfo ContextInformationList, period SendingDuration
   condition
                  SendingCondition
}
-- END Radio Application Related Data Types
-- START Radio Computer Related Data Types
RadioApplicationIDList
                          ::= SEQUENCE OF OptionalObjectName
RCOptionID ::= ENUMERATED
   mdrc-0, mdrc-1, mdrc-2, maximumTxPower, ...
 \begin{array}{lll} {\tt RCOptionsList} & ::= & {\tt SEQUENCE} & {\tt OF} & {\tt SEQUENCE} \\ {\tt rCOptionName} & {\tt RCOptionID}, \end{array} 
                  RCOptionID,
   rCOptionValue
                      ANY
RadioInterfaceID ::= ENUMERATED {
   umts, hsdpa, wimax, lte, wifi, gsm, ...
::= CHOICE {
}
RadioInterfacesList ::= SEQUENCE OF RadioInterfaceID
ChannelIDsList
                  ::= SEQUENCE OF OptionalObjectName
                  ::= ENUMERATED
HardwareInfo
   fixedPipeline, programmablePipeline, hybridPipeline, ...
               ::= ENUMERATED
SoftwareInfo
   rOSVersion, compiler, ...
             ::= ENUMERATED {
Direction
   downlink, uplink
instBLER REAL OPTIONAL
}
```

```
TxPower ::= SEQUENCE {
   power REAL,
   unit CHARACTER
}
RXSINR ::= SEQUENCE {
    accSINR REAL,
period REAL OPTIONAL,
     instSINR REAL OPTIONAL
Links ::= SEQUENCE OF OptionalObjectName
TxBits
             ::= SEQUENCE
    transmittedBit REAL,
                              CHARACTER
     unit
}
ActiveMeasurementID ::= ENUMERATED
   transmitPower, transportLoad, processingLoad, ...
ActiveMeasurementIDs
                                  ::= SEQUENCE OF {
    activeMeasurementID
ActiveMeasurementsList ::= SEQUENCE OF SEQUENCE { activeMeasurementID,
    activeMeasurementValue - SEQUENCE OF SEQUACTIVEMEASUREMENTID, ANY
FrequencyRange ::= SEQUENCE \{
    centralFrequency REAL,
     frequencyBand
                                    REAL
AnaloguePower ::= SEQUENCE {
   power REAL,
   unit CHARACTER
}
 \begin{array}{ccc} {\rm SamplingRate} & & ::= & {\rm SEQUENCE} \\ & {\rm samplingRate} & & {\rm REAL} \,, \end{array} 
     unit CHARACTER
}
\begin{array}{lll} {\tt Bandwidth} & ::= & {\tt SEQUENCE} & \big\{ \\ & {\tt bandWidth} & & {\tt REAL} \,, \\ \end{array}
     unit CHARACTERs
}
   StartTime ::= CHOIC absoluteTime GeneralizedTime, relativeTime INTEGER
TxStartTime
                                       CHOICE {
}
    StopTime ::= CHOIC
Undefined NULL,
absoluteTime GeneralizedTime,
relativeTime INTEGER
TxStopTime
                                       CHOICE {
    absoluteTime Generals:
                                       CHOICE {
RxStartTime
                         GeneralizedTime,
     relativeTime INTEGER
}
   StopTime ::= CHOIC
Undefined NULL,
absoluteTime GeneralizedTime,
relativeTime INTEGER
                                   CHOICE {
RxStopTime
}
```

```
ChannelMeasurementID
                           ::= ENUMERATED {
    channelInterference, channelLoad, ...
    nnelMeasurementsList ::= SEQUENCE OF SEQUENCE channelMeasurementName ChannelMeasurementID,
ChannelMeasurementsList
                                                          {
    channelMeasurementValue
}
ConfigurationMeasurements::=
                               ENUMERATED {
    antennaProt, RFfrontend, ...
-- END Radio Computer Related Data Types
______
-- START Unified Radio Application Interface Related Data Types
RadioAppParameterID ::= ENUMERATED {
    A, b, c, ...
RadioAppParameters ::= SEQUENCE OF SEQUENCE
    radioAppParameterName RadioAppParameterID, radioAppParameterValue ANY
RadioAppsList ::= SEQUENCE OF SEQUENCE {
   RadioAppID INTEGER,
   RadioAppName PrintableString
RadioMeasurementID ::= ENUMERATED {
   A, B, C, ...
RadioMeasurementsList ::= SEQUENCE OF SEQUENCE {
   radioMeasurementName RadioMeasurementID,
    radioMeasurementValue
                                ANY
}
                       ::= SEQUENCE OF OptionalObjectName
PeerEquimentId
PeerEquipmentList
                       ::= SEQUENCE OF {
    PeerEquipmentId
UserData ::= SEQUENCE OF {
    userDataID INTEGER,
                    INTEGER,
    userDataValue
-- END Unified Radio Application Interface Related Data Types
```

Annex B (informative): URAI Qualification Methods for Validation

The URAI requirements are basis for qualification methods to validate that the requirements can be met. A feature list exposing URAI capabilities is created. Qualification methods correspond to the feature list and they qualify features of a particular URAI implementation against the feature list.

The following qualification methods might be typically applied:

- Demonstration The operation of interfacing entities that rely on observable functional operation.
- Test The operation of interfacing entities using specialist test equipment to collect data for analysis.
- Analysis The processing of data obtained from methods, such as reduction, interpretation, or extrapolation of test results.
- Inspection The visual examination of interfacing entities, documentation, etc.
- Special qualification methods Methods for the interfacing entities, such as specialist tools, techniques, procedures, facilities, etc.

History

Document history			
V1.1.1	February 2016	Publication as ETSI TS 103 146-3	
V1.1.7	May 2016	EN Approval Procedure	AP 20160801: 2016-05-03 to 2016-08-01